

SECTION **WCS**

WARNING CHIME SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

CONTENTS

PRECAUTION	3	List of ECU Reference	17
PRECAUTIONS	3	WIRING DIAGRAM	18
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	3	WARNING CHIME SYSTEM	18
SYSTEM DESCRIPTION	4	Wiring Diagram	18
COMPONENT PARTS	4	BASIC INSPECTION	23
Component Parts Location	4	DIAGNOSIS AND REPAIR WORKFLOW	23
Combination Meter	4	Work Flow	23
SYSTEM	5	DTC/CIRCUIT DIAGNOSIS	25
WARNING CHIME SYSTEM	5	POWER SUPPLY AND GROUND CIRCUIT	25
WARNING CHIME SYSTEM : System Description	5	COMBINATION METER	25
WARNING CHIME SYSTEM : Fail-Safe	6	COMBINATION METER : Diagnosis Procedure	25
WARNING CHIME	6	BCM (BODY CONTROL MODULE)	25
WARNING CHIME : Light Reminder Warning	6	BCM (BODY CONTROL MODULE) : Diagnosis Procedure	25
WARNING CHIME : Parking Brake Release Warning Chime	7	METER BUZZER CIRCUIT	27
WARNING CHIME : Seat belt Warning	8	Component Function Check	27
DIAGNOSIS SYSTEM (COMBINATION METER)	9	Diagnosis Procedure	27
On Board Diagnosis Function	9	SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT	28
CONSULT Function (METER/M&A)	11	Component Function Check	28
DIAGNOSIS SYSTEM (BCM)	14	Diagnosis Procedure	28
COMMON ITEM	14	Component Inspection	29
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	14	PARKING BRAKE SWITCH SIGNAL CIRCUIT	30
BUZZER	15	Component Function Check	30
BUZZER : CONSULT Function (BCM - BUZZER)...	15	Diagnosis Procedure	30
ECU DIAGNOSIS INFORMATION	17	Component Inspection	30
BCM, COMBINATION METER	17	SYMPTOM DIAGNOSIS	31
		WARNING CHIME SYSTEM SYMPTOMS	31
		Symptom Table	31

WCS

THE LIGHT REMINDER WARNING DOES NOT SOUND	32	Diagnosis Procedure	33
Description	32	THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND	34
Diagnosis Procedure	32	Description	34
THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND	33	Diagnosis Procedure	34
Description	33		

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000013404997

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000012874464




No.	Component	Function
1.	Combination meter	<ul style="list-style-type: none"> Receives a buzzer output signal from the BCM via CAN communication and sounds the buzzer. Judges whether the parking brake is released using the vehicle speed signal and the parking brake switch signal, and sounds the buzzer if necessary.
2.	BCM	Based on the signals received from various units and switches, transmits the buzzer output signal to the combination meter via CAN communication. Refer to BCS-4, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.
3.	ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal to the combination meter via CAN communication. Refer to BRC-10, "Component Parts Location" for detailed installation location.
4.	Parking brake switch	Transmits the parking brake switch signal to the combination meter.
5.	Seat belt buckle switch LH	Transmits a seat belt buckle switch signal LH to the combination meter.

Combination Meter

INFOID:000000012874465

The combination meter has a built-in buzzer (1) and sounds the following warnings, according to signals from each switch and unit:

- Light reminder warning
- Parking brake release warning chime
- Seat belt warning



SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM

WARNING CHIME SYSTEM

WARNING CHIME SYSTEM : System Description

INFOID:000000012874466

SYSTEM DIAGRAM



DESCRIPTION

Combination Meter

The combination meter sounds the alarm buzzer installed in the combination meter when receiving the buzzer output signal transmitted from each unit.

BCM

BCM receives signals from various units and transmits a buzzer output signal to the combination meter via CAN communication if it judges that the warning buzzer should be activated.

WARNING CHIME FUNCTION LIST

Warning functions	Refer to
Light reminder warning	WCS-6, "WARNING CHIME : Light Reminder Warning"
Parking brake release warning chime	WCS-7, "WARNING CHIME : Parking Brake Release Warning Chime"
Seat belt warning	WCS-8, "WARNING CHIME : Seat belt Warning"

COMBINATION METER INPUT/OUTPUT SIGNAL (CAN COMMUNICATION SIGNAL)

Input signal

Signal name	Transmit unit
Vehicle speed signal	ABS actuator and electric unit (control unit)
Buzzer output signal	BCM

Output signal

Signal name	Reception unit
Vehicle speed signal	BCM

BCM INPUT/OUTPUT SIGNAL (CAN COMMUNICATION SIGNAL)

Input signal

SYSTEM

< SYSTEM DESCRIPTION >

Signal name	Transmit unit
Vehicle speed signal	Combination meter

Output signal

Signal name	Reception unit
Buzzer output signal	Combination meter

WARNING CHIME SYSTEM : Fail-Safe

INFOID:0000000012874467

The combination meter activates the fail-safe control, if CAN communication with each unit is malfunctioning.


Function	Specifications
Buzzer	The buzzer turns OFF by suspending communication.

WARNING CHIME

WARNING CHIME : Light Reminder Warning

INFOID:0000000012874468

SYSTEM DIAGRAM



WARNING CHIME OPERATION CONDITIONS

If all of the following conditions are fulfilled:

Operation conditions	
Ignition switch	OFF
Combination switch (Lighting switch)	1st or 2nd position
Driver side door	Open [front door switch LH ON]

WARNING CHIME CANCEL CONDITIONS

Warning is canceled if any of the following conditions are fulfilled:

Operation conditions	
Ignition switch	ON
Combination switch (Lighting switch)	OFF or AUTO position
Driver side door	Close [front door switch LH OFF]

SIGNAL PATH


1. BCM requires warning chime output to combination meter when it judges light reminder warning chime is necessary from signals below.

SYSTEM

< SYSTEM DESCRIPTION >

Signal name	Signal source
Ignition switch signal	—
Combination switch signal	Combination switch (Lighting switch) → BCM
Driver door switch signal	Front door switch LH → BCM


2. Combination meter sounds integrated buzzer, following the warning chime output requirement (below signal) from BCM.

Signal name	Signal source
Buzzer output signal	BCM  → Combination meter

WARNING CHIME : Parking Brake Release Warning Chime

INFOID:000000012874469

SYSTEM DIAGRAM



WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled:

Operation conditions	
Ignition switch	ON
Parking brake	During the operation (parking brake switch ON).
Vehicle speed	Approximately 4.3 MPH (7 km/h) or more.


WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions are fulfilled:

Operation conditions	
Ignition switch	OFF
Parking brake	Release condition (parking brake switch OFF).
Vehicle speed	Approximately 1.9 MPH (3 km/h) or less.

SIGNAL PATH

Combination meter sounds integrated buzzer when it judges that parking brake release warning chime is necessary from signals below.

Signal name	Signal source
Ignition switch signal	—
Parking brake switch signal	Parking brake switch → Combination meter
Vehicle speed signal	ABS actuator and electric unit (control unit)  → Combination meter

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS


SYSTEM

< SYSTEM DESCRIPTION >

WARNING CHIME : Seat belt Warning

INFOID:000000012874470

SYSTEM DIAGRAM



WARNING OPERATION CONDITIONS

If all of the following conditions are fulfilled:

Operation conditions	
Ignition switch	ON
Seat belt buckle switch LH	Unfastened (seat belt buckle switch LH ON)

WARNING CANCEL CONDITIONS

Warning is canceled if any of the following conditions are fulfilled:

Operation conditions	
Ignition switch	OFF
Seat belt buckle switch LH	Fastened (seat belt buckle switch LH OFF)
6 seconds after the start of warning sound.	

SIGNAL PATH

1. BCM requires warning chime output to combination meter, when it judges seat belt warning chime is necessary from signals below.

Signal name	Signal source
Ignition switch signal	—
Seat belt buckle switch signal LH	Seat belt buckle switch LH → Combination meter → CAN → BCM

2. Combination meter sounds integrated buzzer, following the warning chime output requirement (below signal) from BCM.

Signal name	Signal source
Buzzer output signal	BCM → CAN → Combination meter

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (COMBINATION METER)

On Board Diagnosis Function

INFOID:000000013399251

COMBINATION METER SELF-DIAGNOSIS MODE

The following meter functions can be checked during Combination Meter Self-Diagnosis Mode:

- Pointer sweep of speedometer, tachometer and gauges
- Illumination of all LCD segments and color patterns for meter displays
- Illumination of all lamps/LEDs that are controlled by the combination meter (regardless of switch status)


STARTING COMBINATION METER SELF-DIAGNOSIS MODE

NOTE:

- Check combination meter power supply and ground circuits if self-diagnosis mode does not start. Refer to [WCS-25, "COMBINATION METER : Diagnosis Procedure"](#). Replace combination meter if power supply and ground circuits are found to be normal and self-diagnosis mode does not start. Refer to [MWI-72, "Removal and Installation"](#).
- Combination meter self-diagnosis mode will function with the ignition switch in ON. Combination meter self-diagnosis mode will exit upon turning the ignition switch to OFF.

How to Initiate Self-Diagnosis Mode

1. Turn ignition switch OFF.
2. While pressing the trip reset switch (1), turn ignition switch ON.
3. Keep pressing the trip reset switch for 1 second or more.
4. Press the trip reset switch at least 3 times within 7 seconds after the ignition switch is turned ON.
5. "Work instruction code" is indicated in the top portion of information display and self-diagnosis is started.
6. The mode switches in the order shown below each time the trip reset switch is pressed.




NOTE:

If the trip reset switch is not operated for 20 seconds or more, the self-diagnosis mode is automatically canceled.

Test order	Test item	Description
1	Work instruction code	This item is displayed, but not used.
2	Part number	
3	Software code	
4	EEPROM code	
5	Hardware code	
6	P.C.B code	
7	Circuit check	The pointer of the following items moves from 0 to MAX twice. <ul style="list-style-type: none"> • Speedometer • Tachometer • Engine coolant temperature gauge • Fuel gauge NOTE: If any of the pointers does not sweep, replace combination meter.
8	Color check	Performs the color check of the information display.
9	Error code	Displays the error code of the following items: <ul style="list-style-type: none"> • Speedometer • Tachometer • Engine coolant temperature gauge • Fuel gauge • Meter control switch
10	Warning/indicator lamp check	All warning/indicator lamps illuminate.

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >



Item	Code	Description	Action to take/Reference
Ⓐ Speedometer	0	Normal	—
	1	A vehicle speed signal cannot be received from ABS actuator and electric unit (control unit).	Perform "Self Diagnostic Result" of "ABS." Refer to MWI-29, "DTC Index" .
	2	A vehicle speed signal received from the ABS actuator and electric unit (control unit) is abnormal.	
Ⓑ Tachometer	0	Normal	—
	1	An engine speed signal cannot be received from ECM.	Perform "Self Diagnostic Result" of "ECM." Refer to MWI-29, "DTC Index" .
Ⓒ Fuel gauge	0	Normal	—
	1	Fuel gauge circuit is shorted.	Refer to MWI-57, "Component Function Check" .
	2	Fuel gauge circuit is open.	
Ⓓ Engine coolant temperature gauge	0	Normal	—
	1	An engine coolant temperature signal cannot be received from ECM.	Perform "Self Diagnostic Result" of "ECM." Refer to MWI-29, "DTC Index" .
Ⓔ Meter control switch	0	Normal	—
	1	When judging that the illumination control switch signal circuit is shorted for 5 minutes or more.	Refer to MWI-55, "Diagnosis Procedure" .
	2	When judging that the trip reset switch signal circuit is shorted for 5 minutes or more.	
	3	When judging that both switch signal circuit are shorted for 5 minutes or more.	
Ⓕ —	0	Displays "0" constantly.	—
Ⓖ —	0	Displays "0" constantly.	—
Ⓗ —	0	Displays "0" constantly.	—

How to Reset Error Code

Error codes stored in combination meter can be reset by following the instructions below:

1. Turn ignition switch OFF.
2. While pressing the trip reset switch, turn ignition switch ON.
3. Keep pressing the trip reset switch for 1 second or more.
4. Press the trip reset switch at least 3 times within 7 seconds after the ignition switch is turned ON.
5. Turn ignition switch OFF.
6. Perform self-diagnosis and check that the error codes are reset.

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

CONSULT Function (METER/M&A)

INFOID:000000013399252

APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes shown.

METER/M&A Diagnosis mode	Description
Self Diagnostic Result	Displays combination meter self-diagnosis results.
Data Monitor	Displays combination meter input/output data in real time.
Work support	Displays diagnosis procedure of each work item.
Warning History	Lighting history of the warning lamp and indicator lamp can be checked.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

SELF DIAG RESULT

Refer to [MWI-29, "DTC Index"](#).

DATA MONITOR

Display Item List

X: Applicable

Display item [Unit]	MAIN SIGNALS	Description
SPEED METER	X	Displays the value of vehicle speed signal.
SPEED OUTPUT [mph or km/h]	X	Vehicle speed signal value transmitted to other units via CAN communication.
ODO OUTPUT [mph or km/h]		Odometer signal value transmitted to other units via CAN communication.
TACHO METER [rpm]	X	Value of the engine speed signal received from ECM via CAN communication.
FUEL METER [L]	X	Fuel level indicated on combination meter.
W TEMP METER [°F] or [°C]	X	Displays the value of engine coolant temperature signal, which is input from ECM.
ABS W/L [On/Off]		Displays [ON/OFF] condition of ABS warning indicator.
VDC/TCS IND [On/Off]		Displays [ON/OFF] condition of VDC OFF indicator lamp.
SLIP IND [On/Off]		Displays [ON/OFF] condition of SLIP indicator lamp.
BRAKE W/L [On/Off]		Displays [ON/OFF] condition of brake warning indicator.
DOOR W/L [On/Off]		Displays [ON/OFF] condition of door or back door warning message in the information display.
HI-BEAM IND [On/Off]		Displays [ON/OFF] condition of high beam indicator.
TURN IND [On/Off]		Displays [ON/OFF] condition of turn indicator.
LIGHT IND [On/Off]		Displays [ON/OFF] condition of light indicator.
FR FOG IND [On/Off]		Displays [ON/OFF] condition of front fog lamp indicator.
OIL W/L [On/Off]		Displays [ON/OFF] condition of low oil pressure warning message in the information display.
MIL [On/Off]		Displays [ON/OFF] condition of malfunction indicator.

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

Display item [Unit]	MAIN SIGNALS	Description
BA W/L [On/Off]		Displays [ON/OFF] condition of FEB warning lamp indicator.
ATC/T-AMT W/L [On/Off]		Displays [ON/OFF] condition of CVT check warning message in the information display.
CHAGE W/L [On/Off]		Displays [ON/OFF] condition of charge warning indicator.
4WD W/L [On/Off]		Displays [ON/OFF] condition of AWD warning message in the information display.
FUEL W/L [On/Off]		Displays [ON/OFF] condition of low-fuel warning message in the information display.
WASHER W/L [On/Off]		Displays [ON/OFF] condition of low washer fluid warning message in the information display.
AIR PRES W/L [On/Off]		Displays [ON/OFF] condition of tire pressure warning lamp.
KEY G/Y W/L [On/Off]		Displays [ON/OFF] condition of key green warning lamp.
EPS W/L [On/Off]		Displays [ON/OFF] condition of EPS warning indicator.
LCD		Displays the value of Intelligent Key system message indication.
ACC TARGET [On/Off]		Displays [ON/OFF] condition of vehicle ahead detection indicator in the information display.
ACC DISTANCE [Off, Short, Middle, Long]		Displays [Off, Short, Middle, Long] condition of set distance indicator in the information display.
SHIFT IND [P, R, N, D, L]		Displays shift selector position.
FUEL CAP W/L [On/Off]		Displays [ON/OFF] condition of loose fuel cap warning message in the information display.
PKB SW [On/Off]		Displays [ON/OFF] condition of parking brake switch.
BUCKLE SW [On/Off]		Displays [ON/OFF] condition of seat belt buckle switch LH.
BRAKE OIL SW [On/Off]		Displays [ON/OFF] condition of brake fluid level switch.
DISTANCE [Mi] or [km]		Displays distance to empty.
OUTSIDE TEMP [°F or °C]		Displays the ambient air temperature which is input from the ambient sensor.
FUEL LOW SIG [On/Off]		Displays [ON/OFF] condition of low-fuel warning signal.
STRG SW INPUT [SW 1-SW 10, NOT INPUT]		Displays [SW 1-SW 10, NOT INPUT] condition of steering switches.
BUZZER [On/Off]	X	Buzzer status (in the combination meter) is detected from the buzzer output signal received from each unit via CAN communication and the warning output condition of the combination meter.
BATTERY CIRCUIT STATUS [Normal/Open]		Displays [Normal/Open] condition of battery power supply circuit.
TPMS PRESS L [On/Off]		Displays [ON/OFF] condition of tire pressure low message in the information display.
BSW IND [On/Off]		Displays [ON/OFF] condition of blind spot warning indicator.
BSW W/L [On/Off]		Displays [ON/OFF] condition of blind spot warning in the information display.

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

WORK SUPPORT

Work support item	Description
Outside air temperature diagnosis	A possible malfunction can be narrowed down by following the displayed instructions.
Fuel meter diagnosis (Analog pointer)	
Warning/Indicator lamp diagnosis	

WARNING HISTORY

Special menu

Display item	Description
W/L ON HISTORY	Lighting history of warning lamp and indicator lamp can be checked.

W/L ON HISTORY

- “W/L ON HISTORY” indicates the “TIME” when the warning/indicator lamp is turned on.
- The “TIME” above is:
 - 0: The condition that the warning/indicator lamp has been turned on 1 or more times after starting the engine and waiting for 30 seconds.
 - 1 - 39: The number of times the engine was restarted after the 0 condition.
 - NO W/L ON HISTORY: No warning/indicator lamp history is stored.

NOTE:

- “W/L ON HISTORY” is not stored for approximately 30 seconds after the engine starts.
- Brake warning lamp does not store any history when the parking brake is applied or the brake fluid level gets low.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000013415355

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> • The vehicle specification can be read and saved. • The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions:

System	Sub System	Direct Diagnostic Mode						
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×	×		
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Back door open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				
Signal buffer system	SIGNAL BUFFER			×	×			
TPMS	AIR PRESSURE MONITOR		×	×	×			

FREEZE FRAME DATA (FFD)

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays it on CONSULT.

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed at the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) at the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status at the moment a particular DTC is detected*	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*).
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" *to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopped and selector lever is in P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"*
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK"*.) to low power consumption mode
	LOCK		Power supply position is "LOCK" (Ignition switch OFF)*
	OFF		Power supply position is "OFF" (Ignition switch OFF)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)
CRANKING	Power supply position is "CRANKING" (At engine cranking)		
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition is switched OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. 	

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met:

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

BUZZER

BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:0000000013415356

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.
VEH SPEED 1 [km/h]	Indicates vehicle speed signal received from ABS on CAN communication line.
TAIL LAMP SW [On/Off]	Indicates condition of combination switch.
FR FOG SW [On/Off]	Indicates condition of front fog lamp switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.

ACTIVE TEST

Test Item	Description
SEAT BELT WARN TEST	This test is able to check seat belt warning chime operation [On/Off].
LIGHT WARN ALM	This test is able to check light warning chime operation [On/Off].
REVERSE WARNING	This test is able to check reverse warning chime operation [On/Off].

BCM, COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM, COMBINATION METER

List of ECU Reference

INFOID:0000000012874475

ECU	Reference
BCM	BCS-30, "Reference Value"
	BCS-50, "Fail Safe"
	BCS-51, "DTC Inspection Priority Chart"
	BCS-52, "DTC Index"
COMBINATION METER	MWI-23, "Reference Value"
	MWI-28, "Fail-safe"
	MWI-29, "DTC Index"

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

WARNING CHIME SYSTEM


< WIRING DIAGRAM >

WIRING DIAGRAM

WARNING CHIME SYSTEM

Wiring Diagram

INFOID:000000012874476




AANWA1502GB

WARNING CHIME SYSTEM

< WIRING DIAGRAM >


WARNING CHIME SYSTEM CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	CS06FW-M2
Connector Color	WHITE




Terminal No.	6N	Color of Wire	W	Signal Name	-
--------------	----	---------------	---	-------------	---

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS16FW-CS
Connector Color	WHITE



Terminal No.	8P	Color of Wire	BG	Signal Name	-
9P	L	-	-	-	-
13P	W	-	-	-	-


Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH
Connector Color	GREEN



Terminal No.	10	Color of Wire	W	Signal Name	COMBI SW IN 5
--------------	----	---------------	---	-------------	---------------


11	BG	COMBI SW IN 4
12	R	COMBI SW IN 3
13	G	COMBI SW IN 2
14	P	COMBI SW IN 1
26	L	SHORTING INPUT

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH
Connector Color	BLACK




Terminal No.	59	Color of Wire	P	Signal Name	CAN-L
60	L	-	-	-	-
75	BG	COMBI SW OUT 5			
76	P	COMBI SW OUT 4			
77	R	COMBI SW OUT 3			
78	G	COMBI SW OUT 2			
79	W	COMBI SW OUT 1			

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH24FGY-NH
Connector Color	GRAY




Terminal No.	96	Color of Wire	BG	Signal Name	DR DOOR SW
--------------	----	---------------	----	-------------	------------

Connector No.	M23
Connector Name	COMBINATION METER
Connector Type	TH16FW-NH
Connector Color	WHITE



Terminal No.	43	Color of Wire	B	Signal Name	GND1
44	BG	-	-	-	POWER (IGN)
45	B	-	-	-	GND2
46	W	-	-	-	POWER (BAT)
52	P	-	-	-	CAN-L
53	L	-	-	-	CAN-H

Connector No.	M24
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH
Connector Color	WHITE




Terminal No.	26	Color of Wire	BR	Signal Name	PKG SW
27	BR	-	-	-	SEAT BELT SW (AS)
28	Y	-	-	-	SEAT BELT SW (DR)

A B C D E F G H I J K L M N O P

WARNING CHIME SYSTEM


< WIRING DIAGRAM >

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Type	TH32FW-NH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
14	BR	-

Connector No.	M175
Connector Name	JOINT CONNECTOR-M22
Connector Type	BJ30FW
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
23	BG	-
25	BG	-

Connector No.	E52
Connector Name	PARKING BRAKE SWITCH
Connector Type	P01FB-A
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	-

5G	L	-
13G	BR	-




Terminal No.	Color of Wire	Signal Name
76A	BG	-
84A	Y	-

Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FHA6-SA
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	GR	GND2
139	L	BAT POWER F/L
143	GR	GND1

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	BG	-
5	R	-
7	R	-
8	W	-
9	G	-
10	P	-
11	W	-
12	P	-
13	BG	-
14	G	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
--------------	---------------	-------------

AANIA4379GB

WARNING CHIME SYSTEM


< WIRING DIAGRAM >

Connector No.	B99
Connector Name	WIRE TO WIRE (WITHOUT POWER SEATS)
Connector Type	NS06FW-CS
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	G/W	-
6	B/W	-

Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Type	TH32MW-NH
Connector Color	WHITE




Terminal No.	14
Color of Wire	BR
Signal Name	-

Connector No.	B113
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	NH22FY-1V-EX
Connector Color	YELLOW



Terminal No.	10
Color of Wire	B
Signal Name	BUCKLE SW FR RH-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Type	TH80MDGY-CS16-TM4
Connector Color	GRAY




Terminal No.	76A
Color of Wire	O
Signal Name	-
Terminal No.	84A
Color of Wire	G/W
Signal Name	-

Connector No.	B74
Connector Name	WIRE TO WIRE (WITH POWER SEATS)
Connector Type	NS12FW-CS
Connector Color	WHITE




Terminal No.	2
Color of Wire	B/V
Signal Name	-
Terminal No.	3
Color of Wire	G/W
Signal Name	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4
Connector Color	WHITE



Terminal No.	5G
Color of Wire	P
Signal Name	-
Terminal No.	13G
Color of Wire	LG
Signal Name	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Type	TH04FW-NH
Connector Color	WHITE



Terminal No.	3
Color of Wire	O
Signal Name	-

A B C D E F G H I J K L M O P

WCS

AANIA4380GB

WARNING CHIME SYSTEM

< WIRING DIAGRAM >

Connector No.	B318
Connector Name	WIRE TO WIRE (WITHOUT POWER SEATS)
Connector Type	NS06MW-CS
Connector Color	WHITE



2	1
6	5
4	4
3	3

Terminal No.	Color of Wire	Signal Name
3	BR	-
6	P	-

Connector No.	B331
Connector Name	SEAT BELT BUCKLE SWITCH RH
Connector Type	TH04MW-NH
Connector Color	WHITE



4	3	2	1
---	---	---	---

Terminal No.	Color of Wire	Signal Name
3	P	-
4	BR	-

Connector No.	B223
Connector Name	WIRE TO WIRE
Connector Type	NS06MW-CS
Connector Color	WHITE



2	1
6	5
4	4
3	3

Terminal No.	Color of Wire	Signal Name
3	BR	-
6	P	-

Connector No.	B231
Connector Name	SEAT BELT BUCKLE SWITCH LH
Connector Type	TH04MW-NH
Connector Color	WHITE



4	3	2	1
---	---	---	---

Terminal No.	Color of Wire	Signal Name
3	P	-
4	BR	-

Connector No.	B300
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS
Connector Color	WHITE



5	4	3	2	1
12	11	10	9	8
7	6			

Terminal No.	Color of Wire	Signal Name
2	B	-
3	BG	-

Connector No.	B156
Connector Name	WIRE TO WIRE (WITHOUT POWER SEATS)
Connector Type	NS06FW-CS
Connector Color	WHITE



1	2
3	4
5	5
6	6

Terminal No.	Color of Wire	Signal Name
3	BR	-
6	B	-

Connector No.	B157
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-CS
Connector Color	WHITE



1	2	3	4	5
6	7	8	9	10
11	12			

Terminal No.	Color of Wire	Signal Name
2	B	-
3	BR	-

Connector No.	B220
Connector Name	WIRE TO WIRE (WITH POWER SEATS)
Connector Type	NS12MW-CS
Connector Color	WHITE



5	4	3	2	1
12	11	10	9	8
7	6			

Terminal No.	Color of Wire	Signal Name
2	P	-
3	BR	-

AANIA4381GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:0000000012874477

OVERALL SEQUENCE



DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

2. CHECK SYMPTOM

- Check the symptom based on the information obtained from the customer.
- Check if any other malfunctions are present.

>> GO TO 3.

3. CHECK CONSULT SELF-DIAGNOSIS RESULTS

Perform self-diagnosis. Refer to [MWI-29, "DTC Index"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M

WCS

O
P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

4. NARROW DOWN MALFUNCTIONING PARTS BY SYMPTOM DIAGNOSIS

Perform symptom diagnosis. Refer to [WCS-31. "Symptom Table"](#).

>> GO TO 5.

5. REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace malfunctioning parts.

NOTE:

If DTC is displayed, erase DTC after repairing or replacing malfunctioning parts.

>> GO TO 6.

6. FINAL CHECK

Check that the warning buzzer in the combination meter operates normally.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 2.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

COMBINATION METER : Diagnosis Procedure

INFOID:000000013399253

Regarding Wiring Diagram information, refer to [MWI-31, "Wiring Diagram"](#).

1. CHECK FUSES

Check that the following fuses are not blown:

Unit	Power source	Fuse No.
Combination meter	Battery	13
	Ignition switch ON or ACC	21
	Ignition switch ON or START	31

Is the fuse blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect combination meter harness connector M24.
2. Check voltage between combination meter harness connector M24 and ground.

Combination meter		Ground	Ignition switch position		
Connector	Terminal		OFF	ON or ACC	START
M24	14	(-)	0 V	Battery voltage	Battery voltage
M23	44		0 V	Battery voltage	Battery voltage
	46		Battery voltage	Battery voltage	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between combination meter harness connector M23, M24 and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M24	10	(-)	Yes
M23	43		
	45		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connector.

BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000013415357

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Regarding Wiring Diagram information, refer to [BCS-55. "Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Signal name	Fuse and fusible link No.
Fusible link battery power	L (40A)
BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M81.

2. Check voltage between BCM connector M81 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M81	131	—	Battery voltage
	139		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M81 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M81	134	—	Yes
	143		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

METER BUZZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

METER BUZZER CIRCUIT

Component Function Check

INFOID:000000012874480

1. CHECK OPERATION OF METER BUZZER

CONSULT

1. Select "BUZZER" of "BCM".
2. Select "LIGHT WARN ALM" in "Active Test" mode.

Is the inspection result normal?

- YES >> Inspection End.
NO >> Refer to [WCS-27, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000012874481

1. CHECK POWER SUPPLY OF COMBINATION METER

Check power supply of combination meter. Refer to [MWI-53, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-72, "Removal and Installation"](#).
NO >> Repair power supply circuit of combination meter.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

Component Function Check

INFOID:0000000012874482

1. CHECK COMBINATION METER INPUT SIGNAL

CONSULT

1. Select "Data Monitor" mode of "METER/M&A".
2. Select "BUCKLE SW".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition	Status
BUCKLE SW	When seat belt LH is fastened	OFF
	When seat belt LH is unfastened	ON

Is the inspection result normal?

- YES >> Inspection End.
NO >> Refer to [WCS-28, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000012874483

Regarding Wiring Diagram information, refer to [WCS-18, "Wiring Diagram"](#).

1. CHECK COMBINATION METER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector M24 terminal 28 and ground.

Combination meter			Condition	Voltage (Approx.)
Connector	Terminals			
M24	28	Ground	When driver seat belt is fastened	Battery voltage
			When driver seat belt is unfastened	0 V

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-72, "Removal and Installation"](#).
NO >> GO TO 2.

2. CHECK SEAT BELT BUCKLE SWITCH LH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter harness connector M24 and seat belt buckle switch LH harness connector B231.
3. Check continuity between combination meter harness connector M24 terminal 28 and seat belt buckle switch LH harness connector B231 terminal 4.

Combination meter		Seat belt buckle switch LH		Continuity
Connector	Terminal	Connector	Terminal	
M24	28	B231	4	Yes

4. Check continuity between combination meter harness connector M24 terminal 28 and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M24	28		No

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connector.

SEAT BELT BUCKLE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK SEAT BELT BUCKLE SWITCH LH GROUND CIRCUIT

Check harness continuity between seat belt buckle switch LH harness connector B231 terminal 3 and ground.

Seat belt buckle switch LH		Ground	Continuity
Connector	Terminal		
B231	3		Yes

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Repair or replace harness or connector.

Component Inspection

INFOID:000000012874484

1. CHECK SEAT BELT BUCKLE SWITCH LH

1. Turn ignition switch OFF.
2. Disconnect the seat belt buckle switch LH connector.
3. Check continuity between the seat belt buckle switch LH terminals 3 and 4.

Condition	Terminal	Continuity
When seat belt buckle LH is fastened	3- 4	No
When seat belt buckle LH is unfastened		Yes

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace the seat belt buckle switch LH. Refer to [SR-32, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

PARKING BRAKE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

PARKING BRAKE SWITCH SIGNAL CIRCUIT

Component Function Check

INFOID:0000000012874485

1.COMBINATION METER INPUT SIGNAL

CONSULT

1. Select "Data Monitor" mode of "METER/M&A".
2. Select "PKB SW".
3. Check that the function operates normally according to the following conditions:

Monitor item	Condition	Status
PKB SW	When parking brake is applied	ON
	When parking brake is released	OFF

Is the inspection result normal?

- YES >> Inspection End.
NO >> Refer to [WCS-30, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000012874486

Regarding Wiring Diagram information, refer to [WCS-18, "Wiring Diagram"](#).

1.CHECK PARKING BRAKE SWITCH CIRCUIT

1. Disconnect combination meter harness connector M24 and parking brake switch harness connector E52.
2. Check continuity between combination meter harness connector M24 terminal 26 and parking brake switch harness connector E52 terminal 1.

Combination meter		Parking brake switch		Continuity
Connector	Terminal	Connector	Terminal	
M24	26	E52	1	Yes

3. Check continuity between combination meter harness connector M24 terminal 26 and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M24	26		No

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace harness or connector.

Component Inspection

INFOID:0000000012874487

1.CHECK PARKING BRAKE SWITCH

Check continuity between parking brake switch terminal 1 and switch case ground.

Component	Terminal	Condition	Continuity
Parking brake switch	1	Parking brake applied	Yes
		Parking brake released	No

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace parking brake switch. Refer to [PB-10, "Removal and Installation"](#).

WARNING CHIME SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

WARNING CHIME SYSTEM SYMPTOMS

Symptom Table

INFOID:0000000012874488

CAUTION:

Perform the self-diagnosis with **CONSULT** before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
The light reminder warning does not sound.	<ul style="list-style-type: none">• Harness between BCM and front door switch LH.• Front door switch LH.• BCM• Combination meter	Refer to WCS-32 .
The parking brake release warning continues sounding or does not sound.	<ul style="list-style-type: none">• Harness between combination meter and parking brake switch.• Parking brake switch• BCM• Combination meter	Refer to WCS-34 .
The seat belt warning continues sounding or does not sound.	<ul style="list-style-type: none">• Harness between combination meter and seat belt buckle switch LH.• Seat belt buckle switch LH.• BCM• Combination meter	Refer to WCS-33 .
Warning chime does not sound at all.	Combination meter	Refer to WCS-27 .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

WCS

THE LIGHT REMINDER WARNING DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

THE LIGHT REMINDER WARNING DOES NOT SOUND

Description

INFOID:000000012874489

Light reminder warning does not sound even though headlamp is illuminated.

Diagnosis Procedure

INFOID:000000012874490

1.CHECK COMBINATION SWITCH (LIGHTING SWITCH) OPERATION

Check that the headlamps operate normally by operating the combination switch (lighting switch).

Do they operate normally?

YES >> GO TO 2.

NO >> Refer to [EXL-98, "Symptom Table"](#) (with LED headlamps) or [EXL-217, "Symptom Table"](#) (with halogen headlamps).

2.CHECK FRONT DOOR SWITCH LH SIGNAL CIRCUIT

Check the front door switch LH signal circuit. Refer to [DLK-202, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

3.CHECK FRONT DOOR SWITCH LH

Check the front door switch LH. Refer to [DLK-203, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Replace front door switch LH. Refer to [DLK-332, "Removal and Installation"](#).

THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

THE SEAT BELT WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

Description

INFOID:000000012874491

- Seat belt warning does not sound even though driver seat belt is not fastened.
- Seat belt warning sounds even though driver seat belt is fastened.

Diagnosis Procedure

INFOID:000000012874492

1. CHECK WARNING CHIME OPERATION

CONSULT

1. Select "BUZZER" of "BCM".
2. Select "SEAT BELT WARN TEST" in "Active Test" mode.
3. Touch "ON/OFF" to check that the function operates normally.

Component	CONSULT	Condition
Buzzer	SEAT BELT WARN TEST	ON
		OFF

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace combination meter. Refer to [MWI-72, "Removal and Installation"](#).

2. CHECK COMBINATION METER INPUT SIGNAL

Check the combination meter input signal. Refer to [WCS-28, "Component Function Check"](#).

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> GO TO 3.

3. CHECK SEAT BELT BUCKLE SWITCH LH CIRCUIT

Check the seat belt buckle switch LH circuit. Refer to [WCS-28, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness or connector.

4. CHECK SEAT BELT BUCKLE SWITCH LH

Check the seat belt buckle switch LH. Refer to [WCS-29, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the combination meter. Refer to [MWI-72, "Removal and Installation"](#).

NO >> Replace the seat belt buckle switch LH. Refer to [SR-32, "Removal and Installation"](#).

WCS

THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

< SYMPTOM DIAGNOSIS >

THE PARKING BRAKE RELEASE WARNING CONTINUES SOUNDING, OR DOES NOT SOUND

Description

INFOID:0000000012874493

- The parking brake warning buzzer sounds continuously during vehicle travel, even though the parking brake is released.
- The parking brake warning buzzer does not sound at all, even while driving the vehicle with the parking brake applied.

Diagnosis Procedure

INFOID:0000000012874494

1. CHECK PARKING BRAKE WARNING LAMP

1. Start the engine.
2. Check the operation of the brake warning lamp by operating the parking brake.

Condition	Warning lamp status
Parking brake applied	ON
Parking brake released	OFF

Is the inspection result normal?

- YES >> Replace the combination meter. Refer to [MWI-72, "Removal and Installation"](#).
NO >> GO TO 2.

2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

Check the parking brake switch signal circuit. Refer to [WCS-30, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connector.

3. CHECK PARKING BRAKE SWITCH UNIT

Check the parking brake switch. Refer to [WCS-30, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace the combination meter. Refer to [MWI-72, "Removal and Installation"](#).
NO >> Replace the parking brake switch. Refer to [PB-10, "Removal and Installation"](#).