

A
B
C

SECTION **BCS**

BODY CONTROL SYSTEM

CONTENTS

BCM	COMMON ITEM	15
PRECAUTION	COMMON ITEM : CONSULT Function (BCM -	
	COMMON ITEM)	15
PRECAUTIONS	DOOR LOCK	15
Precaution for Supplemental Restraint System	DOOR LOCK : CONSULT Function (BCM -	
(SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	DOOR LOCK)	16
	REAR DEFOGGER	16
SYSTEM DESCRIPTION	REAR DEFOGGER : CONSULT Function (BCM -	
	REAR DEFOGGER)	16
COMPONENT PARTS	BUZZER	17
	BUZZER : CONSULT Function (BCM - BUZZER)...	17
BODY CONTROL SYSTEM	INT LAMP	17
BODY CONTROL SYSTEM : Component Parts	INT LAMP : CONSULT Function (BCM - INT	
Location	LAMP)	17
POWER CONSUMPTION CONTROL SYSTEM	MULTI REMOTE ENT	18
POWER CONSUMPTION CONTROL SYSTEM :	MULTI REMOTE ENT : CONSULT Function	
Component Parts Location	(BCM - MULTI REMOTE ENT)	18
SYSTEM	HEADLAMP	19
	HEADLAMP : CONSULT Function (BCM - HEAD-	
BODY CONTROL SYSTEM	LAMP)	19
BODY CONTROL SYSTEM : System Description.....	WIPER	20
	WIPER : CONSULT Function (BCM - WIPER)	20
COMBINATION AND LIGHTING SWITCH READING SYSTEM	FLASHER	21
COMBINATION AND LIGHTING SWITCH READING SYSTEM : System Diagram	FLASHER : CONSULT Function (BCM - FLASHER)	21
COMBINATION AND LIGHTING SWITCH READING SYSTEM : System Description	AIR CONDITIONER	21
	AIR CONDITIONER : CONSULT Function (BCM -	
SIGNAL BUFFER	AIR CONDITIONER)	21
SIGNAL BUFFER : System Diagram	COMB SW	21
SIGNAL BUFFER : System Description	COMB SW : CONSULT Function (BCM - COMB	
	SW)	21
POWER CONSUMPTION CONTROL SYSTEM	BCM	22
POWER CONSUMPTION CONTROL SYSTEM :	BCM : CONSULT Function (BCM - BCM)	22
System Diagram		
POWER CONSUMPTION CONTROL SYSTEM :		
System Description		
DIAGNOSIS SYSTEM (BCM)		

BCS

IMMU	22	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Work Procedure	43
IMMU : CONSULT Function (BCM - IMMU)	22		
BATTERY SAVER	22	CONFIGURATION (BCM)	43
BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)	22	CONFIGURATION (BCM) : Description	44
		CONFIGURATION (BCM) : Work Procedure	44
		CONFIGURATION (BCM) : Configuration List	45
THEFT ALM	23	DTC/CIRCUIT DIAGNOSIS	46
THEFT ALM : CONSULT Function (BCM - THEFT ALM)	23		
RETAINED POWER	24	U1000 CAN COMM	46
RETAINED POWER : CONSULT Function (BCM - RETAINED PWR)	24	Description	46
		DTC Logic	46
		Diagnosis Procedure	46
SIGNAL BUFFER	24	U1010 CONTROL UNIT (CAN)	47
SIGNAL BUFFER : CONSULT Function (BCM - SIGNAL BUFFER)	24	DTC Logic	47
		Diagnosis Procedure	47
PANIC ALARM	24	C1735 IGN CIRCUIT OPEN	48
PANIC ALARM : CONSULT Function (BCM - PANIC ALARM)	24	DTC Logic	48
		Diagnosis Procedure	48
ECU DIAGNOSIS INFORMATION	25	POWER SUPPLY AND GROUND CIRCUIT	49
BCM (BODY CONTROL MODULE)	25	Diagnosis Procedure	49
Reference Value	25	COMBINATION AND LIGHTING SWITCH OUTPUT CIRCUIT	50
Fail-safe	35	Diagnosis Procedure	50
DTC Inspection Priority Chart	35	COMBINATION AND LIGHTING SWITCH INPUT CIRCUIT	52
DTC Index	35	Diagnosis Procedure	52
WIRING DIAGRAM	37	SYMPTOM DIAGNOSIS	54
BCM (BODY CONTROL MODULE)	37	COMBINATION AND LIGHTING SWITCH SYSTEM SYMPTOMS	54
Wiring Diagram	37	Symptom Table	54
BASIC INSPECTION	43	REMOVAL AND INSTALLATION	55
INSPECTION AND ADJUSTMENT	43	BCM (BODY CONTROL MODULE)	55
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM)	43	Exploded View	55
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Description	43	Removal and Installation	55

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006737481

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

COMPONENT PARTS

BODY CONTROL SYSTEM

BODY CONTROL SYSTEM : Component Parts Location

INFOID:000000006889163



1. BCM

POWER CONSUMPTION CONTROL SYSTEM



COMPONENT PARTS

< SYSTEM DESCRIPTION >

[BCM]

POWER CONSUMPTION CONTROL SYSTEM : Component Parts Location

INFOID:000000006889170



ALMIA05042Z

1. IPDM E/R

2. BCM (view with instrument panel and steering wheel removed)

3. Combination meter

BCS

SYSTEM

BODY CONTROL SYSTEM

BODY CONTROL SYSTEM : System Description

INFOID:000000006889162

OUTLINE

- BCM (Body Control Module) controls various electrical components. It receives the information required from CAN communication and the signals received from each switch and sensor.
- BCM has a combination and lighting switch reading function for reading the status of combination and lighting switches (light, turn signal, wiper and washer) in addition to functions for controlling the operation of various electrical components. It also has a signal transmission function, for other systems, and a power consumption control function that reduces the power consumption with the ignition switch OFF.
- BCM is equipped with a diagnosis function that operates with CONSULT and allows for various settings to be changed.

BCM FUNCTION LIST

System	Reference page
Combination and lighting switch reading system	BCS-7. "COMBINATION AND LIGHTING SWITCH READING SYSTEM : System Diagram"
Signal buffer system	BCS-12. "SIGNAL BUFFER : System Diagram"
Power consumption control system	BCS-12. "POWER CONSUMPTION CONTROL SYSTEM : System Diagram"
Headlamp system	EXL-8. "HEADLAMP SYSTEM : System Diagram - For USA" EXL-8. "HEADLAMP SYSTEM : System Diagram - For Canada"
Front fog lamp system	EXL-10. "FRONT FOG LAMP SYSTEM : System Diagram"
Daytime running light system	EXL-9. "DAYTIME RUNNING LIGHT SYSTEM : System Diagram - For USA" EXL-10. "DAYTIME RUNNING LIGHT SYSTEM : System Diagram - For Canada"
Turn signal and hazard warning lamp system	EXL-11. "TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Diagram"
Parking, license plate, side maker and tail lamps system	EXL-12. "PARKING, LICENSE PLATE AND TAIL LAMP SYSTEM : System Diagram"
Trailer tow system	EXL-12. "TAIL LAMPS : (TRAILER TOW SYSTEM) System Diagram"
Exterior lamp battery saver system	EXL-13. "EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description"
Interior room lamp control system	INL-7. "INTERIOR ROOM LAMP CONTROL SYSTEM : System Diagram"
Interior room lamp battery saver system	INL-9. "ILLUMINATION CONTROL SYSTEM : System Diagram"
Front wiper and washer system	WW-5. "System Diagram"
Manual air conditioner system	HAC-128. "FRONT MANUAL AIR CONDITIONING SYSTEM : System Diagram"
Warning chime system	WCS-6. "WARNING CHIME SYSTEM : System Diagram"
Power door lock system	DLK-10. "POWER DOOR LOCK SYSTEM : System Diagram"
Nissan vehicle immobilizer system-NATS (NVIS)	SEC-8. "NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Diagram"
Vehicle security system	SEC-7. "VEHICLE SECURITY SYSTEM : System Diagram"
Panic alarm	SEC-7. "VEHICLE SECURITY SYSTEM : System Diagram"
Rear window defogger system	DEF-8. "System Diagram"
Remote keyless entry system	DLK-12. "REMOTE KEYLESS ENTRY SYSTEM : System Diagram"

SYSTEM

[BCM]


< SYSTEM DESCRIPTION >

System	Reference page
Power window system	PWC-7, "System Diagram"
Retained accessory power (RAP) system	PWC-7, "System Diagram"

COMBINATION AND LIGHTING SWITCH READING SYSTEM

COMBINATION AND LIGHTING SWITCH READING SYSTEM : System Diagram

INFOID:000000006889164



COMBINATION AND LIGHTING SWITCH READING SYSTEM : System Description

INFOID:000000006889165

OUTLINE

- BCM reads the status of the combination and lighting switches (light, turn signal, wiper and washer) and recognizes the status of each switch.
- BCM has a combination of 5 output terminals (OUTPUT 1 - 5) and 5 input terminals (INPUT 1 - 5). It reads a maximum of 20 switch states.


COMBINATION AND LIGHTING SWITCH MATRIX

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

SYSTEM

Combination and lighting switch circuit




Combination and lighting switch INPUT-OUTPUT system list

System	INPUT 1	INPUT 2	INPUT 3	INPUT 4	INPUT 5
OUTPUT 1	—	FR WASHER	FR WIPER LOW	TURN LH	TURN RH
OUTPUT 2	FR WIPER HI	—	FR WIPER INT	PASSING	HEADLAMP 1
OUTPUT 3	INT VOLUME 1	—	—	HEADLAMP 2	HI BEAM
OUTPUT 4	—	INT VOLUME 3	—	—	TAIL LAMP
OUTPUT 5	INT VOLUME 2	—	—	FR FOG	—

COMBINATION AND LIGHTING SWITCH READING FUNCTION

Description


- BCM reads the status of the combination and lighting switches at 10 ms intervals normally.



< SYSTEM DESCRIPTION >

NOTE:

- BCM reads the status of the combination and lighting switches at 60 ms intervals when BCM is controlled at low power consumption control mode.
- BCM operates as follows and judges the status of the combination and lighting switches.
- It operates the transistor on OUTPUT side in the following order: OUTPUT 1 → 2 → 3 → 4 → 5, and outputs voltage waveform.
- The voltage waveform of OUTPUT corresponding to the formed circuit is input into the interface on INPUT side if any (1 or more) switches are ON.
- It reads this change of the voltage as the status signal of the combination and lighting switches.



Operation Example

In the following operation example, the combination of the status signals of the combination and lighting switches is replaced as follows: INPUT 1 - 5 to "1 - 5" and OUTPUT 1 - 5 to "A - E".


Example 1: When a switch (TAIL LAMP) is turned ON

SYSTEM

[BCM]

< SYSTEM DESCRIPTION >

- The circuit between OUTPUT 4 and INPUT 5 is formed when the TAIL LAMP switch is turned ON.



- BCM detects the combination and lighting switch status signal "5D" when the signal of OUTPUT 4 is input to INPUT 5.
- BCM judges that the TAIL LAMP switch is ON when the signal "5D" is detected.


Example 2: When some switches (TURN RH, TAIL LAMP) are turned ON

SYSTEM

[BCM]

< SYSTEM DESCRIPTION >

- The circuits between OUTPUT 1 and INPUT 5 and between OUTPUT 4 and INPUT 5 are formed when the TURN RH switch and TAIL LAMP switch are turned ON.



- BCM detects the combination and lighting switch status signal "5AD" when the signals of OUTPUT 1 and OUTPUT 4 are input to INPUT 5.
- BCM judges that the TURN RH switch and TAIL LAMP switch are ON when the signal "5AD" is detected.

WIPER INTERMITTENT DIAL POSITION

BCM judges the wiper intermittent dial 1 - 5 by the status of INT VOLUME 1, 2 and 3 switches.

Wiper intermittent dial position	Switch status		
	INT VOLUME 1	INT VOLUME 2	INT VOLUME 3
1	OFF	ON	OFF
2	OFF	ON	ON
3	OFF	OFF	ON
4	OFF	OFF	OFF
5	ON	ON	OFF


NOTE:

For details of wiper intermittent dial position, refer to [WW-5, "System Description"](#).

SIGNAL BUFFER

SIGNAL BUFFER : System Diagram

INFOID:000000006889166



SIGNAL BUFFER : System Description

INFOID:000000006889167

OUTLINE

BCM has the signal transmission function that outputs/transmits each input/received signal to each unit.


SIGNAL TRANSMISSION FUNCTION LIST

Signal name	Input	Output	Description
Ignition switch ON signal	Ignition switch	IPDM E/R (CAN)	Inputs the ignition switch signal and transmits it with CAN communication.
Brake switch signal	Stop lamp switch	IPDM E/R (CAN)	Inputs the brake switch signal and transmits it with CAN communication.
Door switch signal	Any door switch	<ul style="list-style-type: none"> Combination meter (CAN) IPDM E/R (CAN) 	Inputs the door switch signal and transmits it with CAN communication.
Blower fan ON signal	Front air control	ECM (CAN)	Inputs each signals, and transmits the blower fan ON signal and A/C ON signal via CAN communication.
A/C ON signal			
Oil pressure switch signal	IPDM E/R (CAN)	Combination meter (CAN)	Transmits the received oil pressure switch signal with CAN communication.

POWER CONSUMPTION CONTROL SYSTEM

POWER CONSUMPTION CONTROL SYSTEM : System Diagram

INFOID:000000006889168



POWER CONSUMPTION CONTROL SYSTEM : System Description

INFOID:00000006889169

OUTLINE

- BCM incorporates a power saving control function that reduces the power consumption according to the vehicle status.
- BCM switches the status (control mode) by itself with the power saving control function. It performs the sleep request to each unit (IPDM E/R and combination meter) that operates with the ignition switch OFF.

Normal mode (wake-up)

- CAN communication is normally performed with other units
- Each control with BCM is operating properly

CAN communication sleep mode (CAN sleep)

- CAN transmission is stopped
- Control with BCM only is operating

Low power consumption mode (BCM sleep)

- Low power consumption control is active
- CAN transmission is stopped

LOW POWER CONSUMPTION CONTROL WITH BCM

BCM reduces the power consumption with the following operation in the low power consumption mode.

- The reading interval of the switches changes from 10 ms interval to 60 ms interval.

Sleep mode activation

- BCM receives the sleep-ready signal (ready) from IPDM E/R and combination meter via CAN communication.
- BCM transmits the sleep wake up signal (sleep) to each unit when all of the CAN sleep conditions are fulfilled.
- Each unit stops the transmission of CAN communication with the sleep wake up signal. BCM is in CAN communication sleep mode.
- BCM is in the low power consumption mode and performs the low power consumption control when all of the BCM sleep conditions are fulfilled with CAN sleep condition.

Sleep condition

CAN sleep condition	BCM sleep condition
<ul style="list-style-type: none"> • Receiving the sleep-ready signal (ready) from all units • Ignition switch: OFF • Vehicle security system and panic alarm: No operation • Warning chime: No operation • Stop lamp switch: OFF • Turn signal indicator lamp: No operation • Exterior lamp: OFF • Door lock status: No change • CONSULT communication status: No communication • Door switch status: No change • Rear window defogger: OFF • Driver door lock status: No change • Key switch status: No change 	<ul style="list-style-type: none"> • Interior room lamp battery saver: Time out • RAP system: OFF • Nissan Vehicle Immobilizer System (NVIS) - NATS: No operation • Remote keyless entry receiver communication status: No communication

Wake-up operation

- BCM transmits sleep wake up signal (wake up) to each unit when any condition listed below is established, and then goes into normal mode from low power consumption mode.
- Each unit starts transmissions with CAN communication by receiving sleep wake up signals. Each unit transmits wake up signals to BCM with CAN communication to convey the start of CAN communication.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

< SYSTEM DESCRIPTION >

Wake-up condition

Wake-up condition

- Receiving the sleep-ready signal (Not-ready) from any units
- Hazard switch: ON
- HI BEAM switch: OFF → ON, ON → OFF
- PASSING switch: OFF → ON, ON → OFF
- HEADLAMP 1 switch: OFF → ON, ON → OFF
- HEADLAMP 2 switch: OFF → ON, ON → OFF
- TAIL LAMP switch: OFF → ON
- TURN RH: OFF → ON, ON → OFF
- TURN LH: OFF → ON, ON → OFF
- Driver door switch: OFF → ON, ON → OFF
- Passenger door switch: OFF → ON, ON → OFF
- Back door switch RH: OFF → ON, ON → OFF
- Back door switch LH: OFF → ON, ON → OFF
- Stop lamp switch: ON
- Door lock and unlock switch:
NEUTRAL → LOCK, NEUTRAL → UNLOCK
- Front door lock assembly (driver side) (door key cylinder switch):
NEUTRAL → LOCK, NEUTRAL → UNLOCK
- Remote keyless entry receiver communication: Receiving

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000006889171

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK			x	x	x		
Rear window defogger	REAR DEFOGGER			x	x			
Warning chime	BUZZER			x	x			
Interior room lamp timer	INT LAMP			x	x	x		
Remote keyless entry system	MULTI REMOTE ENT			x	x	x		
Exterior lamp	HEAD LAMP			x	x	x		
Wiper and washer	WIPER			x	x			
Turn signal and hazard warning lamps	FLASHER			x	x			
Air conditioner	AIR CONDITIONER			x				
Combination switch	COMB SW			x				
BCM	BCM	x	x			x	x	x
Immobilizer	IMMU		x		x			
Interior room lamp battery saver	BATTERY SAVER			x	x	x		
Vehicle security system	THEFT ALM			x	x	x		
RAP system	RETAINED PWR			x		x		
Signal buffer system	SIGNAL BUFFER			x	x			
Panic alarm system	PANIC ALARM				x			

DOOR LOCK

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK)

INFOID:000000006889172

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
KEY ON SW [On/Off]	Indicates condition of key switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of back door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of sliding door or back door switch.
ACC ON SW [On/Off]	Indicates condition of ignition switch ACC position.
KEYLESS LOCK [On/Off]	Indicates condition of lock signal from keyfob.
KEYLESS UNLOCK [On/Off]	Indicates condition of unlock signal from keyfob.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
VEHICLE SPEED [km/h/mph]	Indicates vehicle speed signal received from combination meter on CAN communication line.

ACTIVE TEST

Test Item	Description
DOOR LOCK	This test is able to check door lock operation [OTR ULK/DR UNLK/ALL ULK/ALL LCK].

WORK SUPPORT

Support Item	Setting	Description
DOOR LOCK-UNLOCK SET	On*	Automatic door locks function ON.
	Off	Automatic door locks function OFF.
AUTOMATIC DOOR LOCK SELECT	P RANGE	Doors lock automatically when shifted out of P (Park).
	VH SPD*	Doors lock automatically when vehicle speed reaches 24 km/h (15 mph).
AUTOMATIC DOOR UNLOCK SELECT	MODE6	Doors unlock automatically when key is removed.
	MODE5	Driver's door unlocks automatically when key is removed.
	MODE4	Driver's door unlocks automatically when shifted into P (Park).
	MODE3	Driver's door unlocks automatically when ignition is switched from ON to OFF.
	MODE2*	Doors unlock automatically when shifted into P (Park).
AUTOMATIC LOCK/UNLOCK SELECT	Lock/Unlock*	Automatic lock and unlock functions ON.
	Lock Only	Automatic lock function only ON.
	Unlock Only	Automatic unlock function only ON.
	Off	Automatic lock/unlock function OFF.

* : Initial setting

REAR DEFOGGER

REAR DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)

INFOID:000000006889173

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
ACC ON SW [On/Off]	Indicates condition of ignition switch ACC position.
REAR DEF SW [On/Off]	Indicates condition of rear window defogger switch.

ACTIVE TEST

Test Item	Description
REAR DEFOGGER	This test is able to check rear window defogger operation [Off/On].

BUZZER

BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:000000006889174

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
KEY ON SW [On/Off]	Indicates condition of key switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
TAIL LAMP SW [On/Off]	Indicates condition of lighting switch.
BUCKLE SW [On/Off]	Indicates condition of seat belt buckle switch.
VEHICLE SPEED [km/h/mpH]	Indicates vehicle speed signal received from combination meter on CAN communication line.

ACTIVE TEST

Test Item	Description
IGN KEY WARN ALM	This test is able to check key warning chime operation [Off/On].
SEAT BELT WARN TEST	This test is able to check seat belt warning operation [Off/On].
LIGHT WARN ALM	This test is able to check light reminder warning operation [Off/On].

INT LAMP

INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:000000006889175

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
KEY ON SW [On/Off]	Indicates condition of key switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of back door switch.
DOOR SW-RL [On/Off]	Indicates condition of sliding door switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEYLESS LOCK [On/Off]	Indicates condition of lock signal from keyfob.
KEYLESS UNLOCK [On/Off]	Indicates condition of unlock signal from keyfob.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
ACC ON SW [On/Off]	Indicates condition of ignition switch ACC position.

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

ACTIVE TEST

Test Item	Description
INT LAMP	This test is able to check interior room lamp operation [Off/On].

WORK SUPPORT

Support Item	Setting	Description
SET I/L D-UNLCK INTCON	Off	Interior room lamp timer function OFF.
	On*	Interior room lamp timer function ON.
ROOM LAMP TIMER SET	MODE4* 30 sec.	Sets the interior room lamp ON time (timer operation).
	MODE3 15 sec.	
	MODE2 7.5 sec.	
	MODE1 0 sec.	
ROOM LAMP ON TIME SET	MODE7 0 sec.	Sets the interior room lamp gradual brightening time.
	MODE6 5 sec.	
	MODE5 4 sec.	
	MODE4 3 sec.	
	MODE3 2 sec.	
	MODE2* 1 sec.	
	MODE1 0.5 sec.	
ROOM LAMP OFF TIME SET	MODE7 0 sec.	Sets the interior room lamp gradual dimming time.
	MODE6 5 sec.	
	MODE5 4 sec.	
	MODE4 3 sec.	
	MODE3 2 sec.	
	MODE2* 1 sec.	
	MODE1 0.5 sec.	
R LAMP TIMER LOGIC SET	MODE2	Interior room lamp timer activation synchronizing all doors.
	MODE1*	Interior room lamp timer activation synchronizing driver door only.

* : Initial setting

MULTI REMOTE ENT

MULTI REMOTE ENT : CONSULT Function (BCM - MULTI REMOTE ENT)

INFOID:000000006889176

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
KEY ON SW [On/Off]	Indicates condition of key switch.
ACC ON SW [On/Off]	Indicates condition of ignition switch ACC position.
KEYLESS LOCK [On/Off]	Indicates condition of lock signal from keyfob.
KEYLESS UNLOCK [On/Off]	Indicates condition of unlock signal from keyfob.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of back door switch.
DOOR SW-RL [On/Off]	Indicates condition of sliding door switch.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[BCM]

Monitor Item [Unit]	Description
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEYLESS PANIC [On/Off]	Indicates condition of panic signal from keyfob.

ACTIVE TEST

Test Item	Description
INT LAMP	This test is able to check interior room lamp operation [Off/On].
FLASHER	This test is able to check hazard reminder operation [Off/RH/LH].
HORN	This test is able to check horn operation [On].

WORK SUPPORT

Support Item	Setting	Description
REMO CONT ID REGIST	—	Keyfob ID code can be registered.
REMO CONT ID ERASUR	—	Keyfob ID code can be erased.
REMO CONT ID CONFIR	—	Keyfob ID code registration is displayed.
HORN CHIRP SET	Off	Horn chirp function can be changed in this mode.
	On*	
HAZARD LAMP SET	MODE4* Lock and Unlock	Hazard warning lamp function can be changed in this mode.
	MODE3 Lock Only	
	MODE2 Unlock Only	
	MODE1 OFF	
PANIC ALARM SET	MODE3 1.5 sec	Panic alarm operation can be changed in this mode.
	MODE2 OFF	
	MODE1* 0.5 sec	
AUTO LOCK SET	MODE7 5 min	Auto locking function can be changed in this mode.
	MODE6 4 min	
	MODE5 3 min	
	MODE4 2 min	
	MODE3* 1 min	
	MODE2 30 sec	
	MODE1 OFF	

*: Initial setting

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEADLAMP)

INFOID:000000006889177

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
ACC ON SW [On/Off]	Indicates condition of ignition switch ACC position.
HI BEAM SW [On/Off]	Indicates condition of combination switch.
HEAD LAMP SW 1 [On/Off]	Indicates condition of lighting switch.
HEAD LAMP SW 2 [On/Off]	
TAIL LAMP SW [On/Off]	
PASSING SW [On/Off]	Indicates condition of combination switch.

A
B
C
D
E
F
G
H
I
J
K
L
BCS

N
O

P

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
FR FOG SW [On/Off]	Indicates condition of front fog lamp switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of back door switch.
DOOR SW-RL [On/Off]	Indicates condition of sliding door switch.
TURN SIGNAL R [On/Off]	Indicates condition of combination switch.
TURN SIGNAL L [On/Off]	
KEY ON SW [On/Off]	Indicates condition of key switch.
KEYLESS LOCK [On/Off]	Indicates condition of lock signal from keyfob.
PKB SW [On/Off]	Indicates parking brake switch signal received from combination meter on CAN communication line.
ENGINE RUN [On/Off]	Indicates run condition of engine.
VEHICLE SPEED [km/h/mph]	Indicates vehicle speed signal received from combination meter on CAN communication line.

ACTIVE TEST

Test Item	Description
TAIL LAMP	This test is able to check tail lamp operation [Off/On].
HEAD LAMP	This test is able to check head lamp operation [Off/Lo/Hi].
FR FOG LAMP	This test is able to check front fog lamp operation [Off/On].
DAYTIME RUNNING LIGHT	This test is able to check daytime running light operation [Off/On].
ILL DIM SIGNAL	This test is able to check illumination dimming operation [Off/On].

WORK SUPPORT

Support Item	Setting	Description
BATTERY SAVER SET	Off	Exterior lamp battery saver function OFF.
	On*	Exterior lamp battery saver function ON.
ILL DELAY SET	MODE8	180 sec
	MODE7	150 sec
	MODE6	120 sec
	MODE5	90 sec
	MODE4	60 sec
	MODE3	30 sec
	MODE2	OFF
MODE1*	45 sec	Sets delay timer function operation time (all doors closed).

*: Initial setting

WIPER

WIPER : CONSULT Function (BCM - WIPER)

INFOID:000000006889178

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
IGN SW CAN [On/Off]	Indicates ignition switch ON signal received from IPDM E/R on CAN communication line.

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
FR WIPER HI [On/Off]	Indicates condition of front wiper operation of combination switch.
FR WIPER LOW [On/Off]	
FR WIPER INT [On/Off]	
FR WASHER SW [On/Off]	
INT VOLUME [1 - 5]	
FR WIPER STOP [On/Off]	Indicates front wiper motor auto stop signal received from IPDM E/R on CAN communication line.

ACTIVE TEST

Test Item	Description
FR WIPER	This test is able to check front wiper operation [Off/INT/Lo/Hi].

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000006889179

DATA MONITOR

Monitor Item [Unit]	Description
HAZARD SW [On/Off]	Indicates condition of hazard switch.
TURN SIGNAL R [On/Off]	Indicates condition of turn signal function of combination switch.
TURN SIGNAL L [On/Off]	

ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [Off/RH/LH].

AIR CONDITIONER

AIR CONDITIONER : CONSULT Function (BCM - AIR CONDITIONER)

INFOID:000000006889180

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
FAN ON SIG [On/Off]	Indicates condition of fan switch.
AIR COND SW [On/Off]	Indicates condition of A/C switch.
FR DEF SW [On/Off]	Indicates condition of front defroster switch.

COMB SW

COMB SW : CONSULT Function (BCM - COMB SW)

INFOID:000000006889182

DATA MONITOR

Monitor Item [Unit]	Description
TURN SIGNAL R [On/Off]	Indicates condition of turn signal operation of combination switch.
TURN SIGNAL L [On/Off]	
HI BEAM SW [On/Off]	Indicates condition of HI beam operation of combination switch.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
HEAD LAMP SW 1 [On/Off]	Indicates condition of lighting switch.
HEAD LAMP SW 2 [On/Off]	
TAIL LAMP SW [On/Off]	
PASSING SW [On/Off]	Indicates condition of passing switch operation of combination switch.
FR FOG SW [On/Off]	Indicates condition of front fog lamp switch.
FR WIPER HI [On/Off]	Indicates condition of front wiper operation of combination switch.
FR WIPER LOW [On/Off]	
FR WIPER INT [On/Off]	
FR WASHER SW [On/Off]	Indicates condition of front washer operation of combination switch.
INT VOLUME [1 - 5]	Indicates condition of intermittent wiper operation of combination switch.

BCM

BCM : CONSULT Function (BCM - BCM)

INFOID:000000006889183

ECU IDENTIFICATION

The BCM part number is displayed.

SELF DIAGNOSTIC RESULT

Refer to [BCS-35, "DTC Index"](#).

WORK SUPPORT

Support Item	Setting	Description
RESET SETTING VALUE	Reset	Returns BCM to initial value in factory shipment.
	Cancel	Cancels the reset function.

CONFIGURATION

Refer to [BCS-44, "CONFIGURATION \(BCM\) : Description"](#).

CAN DIAG SUPPORT MNTR

Refer to [LAN-12, "CAN Diagnostic Support Monitor"](#).

IMMU

IMMU : CONSULT Function (BCM - IMMU)

INFOID:000000006889184

SELF DIAGNOSTIC RESULT

Refer to [BCS-35, "DTC Index"](#).

ACTIVE TEST

Test Item	Description
THEFT IND	This test is able to check security indicator operation [Off/On].

BATTERY SAVER

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:000000006889185

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
KEY ON SW [On/Off]	Indicates condition of key switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of back door switch.
DOOR SW-RL [On/Off]	Indicates condition of sliding door switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEYLESS LOCK [On/Off]	Indicates condition of lock signal from keyfob.
KEYLESS UNLOCK [On/Off]	Indicates condition of unlock signal from keyfob.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
ACC SW [On/Off]	Indicates condition of ignition switch ACC position.

WORK SUPPORT

Support Item	Setting	Description
ROOM LAMP TIMER SET	MODE3	10 min
	MODE2	60 min
	MODE1*	15 min
		Sets the interior room lamp battery saver timer operating time.

*: Initial setting

THEFT ALM

THEFT ALM : CONSULT Function (BCM - THEFT ALM)

INFOID:000000006889187

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
ACC ON SW [On/Off]	Indicates condition of ignition switch ACC position.
KEY ON SW [On/Off]	Indicates condition of key switch.
KEYLESS LOCK [On/Off]	Indicates condition of lock signal from keyfob.
KEYLESS UNLOCK [On/Off]	Indicates condition of unlock signal from keyfob.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of back door switch.
DOOR SW-RL [On/Off]	Indicates condition of sliding door switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
TRANSPONDER [On/Off]	Indicates condition of key ID verification results.
AUTO RELOCK [On/Off]	Indicates condition of auto relock.

ACTIVE TEST

Test Item	Description
THEFT IND	This test is able to check security indicator lamp operation [Off/On].
VEHICLE SECURITY HORN	This test is able to check vehicle security horn operation [On].
HEADLAMP(HI)	This test is able to check vehicle security lamp operation [On].
FLASHER	This test is able to check hazard reminder operation [Off/RH/LH].

DIAGNOSIS SYSTEM (BCM)

[BCM]

< SYSTEM DESCRIPTION >

WORK SUPPORT

Support Item	Setting	Description
SECURITY ALARM SET	Off	Security alarm OFF.
	On*	Security alarm ON.
THEFT ALM TRG	Off/On	The switch which triggered vehicle security alarm is recorded [On]. This mode is able to confirm and erase the record of vehicle security alarm. The trigger data can be erased by touching [CLEAR].
	CLEAR	

*: Initial setting

RETAINED POWER

RETAINED POWER : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000006889188

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.

WORK SUPPORT

Support Item	Setting	Description	
RETAINED PWR SET	MODE3	2 min	Sets the retained accessory power operating time.
	MODE2	OFF	
	MODE1*	45 sec	

*: Initial setting

SIGNAL BUFFER

SIGNAL BUFFER : CONSULT Function (BCM - SIGNAL BUFFER)

INFOID:000000006889189

DATA MONITOR

Monitor Item [Unit]	Description
OIL PRESS SW [On/Off]	Indicates condition of oil pressure switch signal received from IPDM E/R on CAN communication line.
BRAKE SW [On/Off]	Indicates condition of stop lamp switch.

ACTIVE TEST

Test Item	Description
OIL PRESSURE SW	This test is able to check the oil pressure gauge operation [Off/On].

PANIC ALARM

PANIC ALARM : CONSULT Function (BCM - PANIC ALARM)

INFOID:000000006889192

ACTIVE TEST

Test Item	Description
HEAD LAMP (HI)	This test is able to check head lamp HI operation [On].
VEHICLE SECURITY HORN	This test is able to check vehicle security horn operation [On].

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000006889193

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
ACC SW	Ignition switch OFF or ON	Off
	Ignition switch ACC	On
ACC ON SW	Ignition switch OFF or ON	Off
	Ignition switch ACC	On
AIR COND SW	A/C switch OFF	Off
	A/C switch ON	On
BRAKE SW	Brake pedal released	Off
	Brake pedal applied	On
BUCKLE SW	Seat belt buckle unfastened	Off
	Seat belt buckle fastened	On
CDL LOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the LOCK side	On
CDL UNLOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the UNLOCK side	On
DOOR SW-AS	Front door RH closed	Off
	Front door RH opened	On
DOOR SW-DR	Front door LH closed	Off
	Front door LH opened	On
DOOR SW-RL	Sliding door or back doors closed	Off
	Sliding door or back doors opened	On
DOOR SW-RR	Back door RH closed	Off
	Back door RH opened	On
FAN ON SIG	Blower motor fan switch OFF	Off
	Blower motor fan switch ON	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER LOW	Front wiper switch OFF	Off
	Front wiper switch LO	On
FR WIPER HI	Front wiper switch OFF	Off
	Front wiper switch HI	On
FR WIPER INT	Front wiper switch OFF	Off
	Front wiper switch INT	On
FR WIPER STOP	Any position other than front wiper stop position	Off
	Front wiper stop position	On
HAZARD SW	When hazard switch is not pressed	Off
	When hazard switch is pressed	On

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]


Monitor Item	Condition	Value/Status
HEAD LAMP SW 1	Headlamp switch OFF	Off
	Headlamp switch 1st	On
HEAD LAMP SW 2	Headlamp switch OFF	Off
	Headlamp switch 1st	On
HI BEAM SW	High beam switch OFF	Off
	High beam switch HI	On
IGN ON SW	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
IGN SW CAN	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
INT VOLUME	Wiper intermittent dial is in a dial position of 1 - 5	1 - 5
KEY CYL LK-SW	Door key cylinder LOCK position	Off
	Door key cylinder other than LOCK position	On
KEY CYL UN-SW	Door key cylinder UNLOCK position	Off
	Door key cylinder other than UNLOCK position	On
KEY ON SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted into key cylinder	On
KEYLESS LOCK	LOCK button of keyfob is not pressed	Off
	LOCK button of keyfob is pressed	On
KEYLESS PANIC	PANIC button of keyfob is not pressed	Off
	PANIC button of keyfob is pressed	On
KEYLESS UNLOCK	UNLOCK button of keyfob is not pressed	Off
	UNLOCK button of keyfob is pressed	On
OIL PRESS SW	<ul style="list-style-type: none"> • Ignition switch OFF or ACC • Engine running 	Off
	Ignition switch ON	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
PKB SW	Parking brake switch disengaged	Off
	Parking brake switch engaged	On
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
TAIL LAMP SW	Lighting switch OFF	Off
	Lighting switch 1st position	On
TRANSPONDER	Key ID not verified	Off
	Key ID verified	On
TURN SIGNAL L	Turn signal switch OFF	Off
	Turn signal switch LH	On
TURN SIGNAL R	Turn signal switch OFF	Off
	Turn signal switch RH	On
VEHICLE SPEED	While driving	Equivalent to speedometer reading

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

TERMINAL LAYOUT



A
B
C
D
E
F
G
H
I
J
K
L

PHYSICAL VALUES

BCS

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
2 (L)	Ground	Input 5 signal	Input	Combination and lighting switches	OFF
				Combination switch	TURN RH
					HI BEAM
Lighting switch	HEADLAMP 1				
				TAIL LAMP	






PKIB4958J
1.0 V

N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




[BCM]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
3 (P)	Ground	Input 4 signal	Input	Combination, front fog lamps and lighting switches	OFF	0 V
				Front fog lamps switch	ON	
				Combination switch	TURN LH	
					PASSING	
Lighting switch	HEADLAMP 2	1.0 V				
4 (LG)	Ground	Input 3 signal	Input	Combination switch	OFF	0 V
					FR WIPER LOW	
					FR WIPER INT (any intermittent position)	
5 (O)	Ground	Input 2 signal	Input	Combination switch	OFF	0 V
					FR WASHER	
					Wiper intermittent dial 2	
					Wiper intermittent dial 3	
						1.0 V
6 (R)	Ground	Input 1 signal	Input	Combination switch	OFF	0 V
					FR WIPER HI	
					Wiper intermittent dial 1	
					Wiper intermittent dial 2	
					Wiper intermittent dial 5	
						1.0 V
7 (Y)	Ground	Key cylinder unlock sw signal	Input	Key cylinder switch	NEUTRAL position	
					UNLOCK position	0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
8 (SB)	Ground	Key cylinder lock sw signal	Input	Key cylinder switch	NEUTRAL position	12 V
					LOCK position	0 V
9 (LG)	Ground	Brake sw 1 signal	Input	Stop lamp switch	OFF (Brake pedal re- leased)	0 V
					ON (Brake pedal de- pressed)	Battery voltage
10 (BR)	Ground	Rear defogger sw signal	Input	Rear window defogger switch	OFF (Released)	12 V
					ON (Pressed)	0 V
11 (O)	Ground	ACC sw signal	Input	Ignition switch OFF	0 V	
				Ignition switch ACC or ON	Battery voltage	
12 (O)	Ground	Door switch (AS) signal	Input	Front door switch RH	OFF (Front door RH closed)	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p>
				ON (Front door RH open)	0 V	
13 (GR)	Ground	Door switch (RR) signal	Input	Back door switch upper RH	OFF (Back door RH closed)	0 V
				ON (Back door RH open)	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p>	
18 (P)	Ground	Keyless gnd signal	Input	Ignition switch ON	0 V	
19 (V)	Ground	Keyless tuner power supply signal	Input	Ignition switch OFF	Key inserted into ignition key cylinder	0 V
				Key removed from ignition key cylinder (Any door open)	5 V	
				Key removed from ignition key cylinder (Any door closed)	 <p style="text-align: right; font-size: small;">JPM1A0338JP</p>	






A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >




[BCM]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
20 (W)	Ground	Keyless tuner signal	Input	Ignition switch OFF	Key inserted into ignition key cylinder	0 V
					Waiting	 <p style="text-align: right; font-size: small;">PIIB7728J</p>
					Signal receiving	 <p style="text-align: right; font-size: small;">PIIB7729J</p>
21 (G)	Ground	Immobilizer one way communication (Clock) signal	Input/ Output	While waiting	Turn ignition switch ON.	Turn ignition switch ON: Pointer of tester should move.
23 (G)	Ground	Security indicator output signal	Input	Security indica- tor	ON	0 V
					Blinking (Ignition switch OFF)	 <p style="text-align: right; font-size: small;">JPMIA0014GB</p>
					OFF	12 V
25 (BR)	Ground	Immobilizer two way communication sig- nal	Input/ Output	While waiting	Turn ignition switch ON.	Turn ignition switch ON: Pointer of tester should move.
27 (GR)	Ground	Air con sw signal	Input	A/C switch	OFF	 <p style="text-align: right; font-size: small;">JPMIA0012GB</p>
					ON	0 V
28 (Y)	Ground	Blower fan sw signal	Input	Fan switch	Blower fan switch OFF	 <p style="text-align: right; font-size: small;">PKIB4960J</p>
					Blower fan switch ON	0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
		Signal name	Input/ Output			
+	-					
29 (O)	Ground	Hazard sw signal	Input	Hazard switch	OFF	Battery voltage
					ON	0 V
32 (SB)	Ground	Output 5 signal	Output	Combination switch	OFF	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p>
					ON	 <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p>
				Wiper intermittent dial 1		
				Wiper intermittent dial 2		
Combination switch	Wiper intermittent dial 5					
33 (G)	Ground	Output 4 signal	Output	Combination and lighting switches	OFF	 <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p>
					Lighting switch	TAIL LAMP
				Combination switch	Wiper intermittent dial 2	
					Wiper intermittent dial 3	







A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]


Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-					
34 (Y)	Ground	Output 3 signal	Output	Combination and lighting switches	OFF	 <small>PKIB4960J</small> 7.0 - 8.0 V
				Lighting switch	HEADLAMP 2	 <small>PKIB4958J</small> 1.2 V
				Combination switch	Wiper intermittent dial 5	
35 (BR)	Ground	Output 2 signal	Output	Combination and lighting switches	OFF	 <small>PKIB4960J</small> 7.0 - 8.0 V
				Lighting switch	HEADLAMP 1	 <small>PKIB4958J</small> 1.2 V
				Combination switch	FR WIPER INT (any intermittent position)	
36 (Y)	Ground	Output 1 signal	Output	Combination switch	OFF	 <small>PKIB4960J</small> 7.0 - 8.0 V
					TURN RH	 <small>PKIB4958J</small> 1.2 V
					TURN LH	
					FR WIPER LOW	
				FR WASHER		
37 (BR)	Ground	Key sw signal	Input	Key inserted into ignition key cylinder		Battery voltage
				Key removed from ignition key cylinder		0 V

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

[BCM]


Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
38 (R)	Ground	Ign sw signal	Input	Ignition switch OFF or ACC	0 V
				Ignition switch ON	Battery voltage
39 (L)	Ground	CAN-H signal	Input/ Output	—	—
40 (P)	Ground	CAN-L signal	Input/ Output	—	—
45 (GR)	Ground	Central door lock sw signal	Input	Door lock/unlock switch	NEUTRAL position
				LOCK position	0 V
46 (R)	Ground	Central door unlock sw signal	Input	Door lock/unlock switch	NEUTRAL position
				UNLOCK position	0 V
47 (SB)	Ground	Door switch (DR) signal	Input	Front door switch LH	OFF (Front door LH closed)
				ON (Front door LH open)	0 V
48 (O)	Ground	Door switch (RL) signal	Input	Back door switch lower LH, back door lower RH, secondary sliding door switch (with high roof) or sliding door switch	OFF (Back door LH, back door RH or sliding door closed)
				ON (Back door LH, back door RH or sliding door open)	0 V




1.0 - 1.5 V



1.0 - 1.5 V



7.0 - 8.0 V







7.0 - 8.0 V

A
B
C
D
E
F
G
H
I
J
K
L
BCS
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
51 (V)	Ground	Trailer flasher output (right) signal	Output	Turn signal switch RH ON	 <p style="text-align: right; font-size: small;">SKIA3009J</p>
52 (G)	Ground	Trailer flasher output (left) signal	Output	Turn signal switch LH ON	 <p style="text-align: right; font-size: small;">SKIA3009J</p>
56 (SB)	Ground	Battery saver output signal	Output	Interior room lamp battery saver activated	0 V
				Interior room lamp battery saver not activated	12 V
57 (LG)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
59 (W)	Ground	Door unlock output (DR) signal	Output	Front door LH actuator	Actuated to UNLOCK position 12 V Other than actuated to UNLOCK position 0 V
60 (Y)	Ground	Flasher output (left) signal	Output	Ignition switch ON	Turn signal switch OFF 0 V Turn signal switch LH ON  <p style="text-align: right; font-size: small;">PKIC6370E</p>
61 (G)	Ground	Flasher output (right) signal	Output	Ignition switch ON	Turn signal switch OFF 0 V Turn signal switch RH ON  <p style="text-align: right; font-size: small;">PKIC6370E</p>
63 (L)	Ground	Room lamp output signal	Output	Interior room lamp	OFF 12 V ON 0 V
65 (G)	Ground	Door lock output signal	Output	All door actuators	Actuated to LOCK position 12 V Other than actuated to LOCK position 0 V

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[BCM]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
66 (Y)	Ground	Door unlock output (AS, SD, BD) signal	Output	Back door lock, front door lock RH and sliding door lock actua- tors	Actuated to UNLOCK po- sition	12 V
					Other than actuated to UNLOCK position	0 V
67 (B)	Ground	Ground	Output	Ignition switch ON		0 V
68 (W)	Ground	Power window pow- er supply (RAP) sig- nal	Output	Ignition switch ON		12 V
69 (L)	Ground	Power window pow- er supply (battery) signal	Output	Ignition switch OFF		12 V
70 (R)	Ground	Battery power sup- ply (F/L)	Input	Ignition switch OFF		Battery voltage

Fail-safe

INFOID:000000006889195

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC is detected.

CONSULT display	Fail-safe	Cancellation
B2190: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC
B2191: DIFFERENCE OF KEY	Inhibit engine cranking	Erase DTC
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI SCANNING	Inhibit engine cranking	Ignition switch ON → OFF

HIGH FLASHER OPERATION

BCM detects the turn signal lamp circuit status by the current value.

BCM increases the turn signal lamp blinking speed if a bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while activating the hazard warning lamp.

DTC Inspection Priority Chart

INFOID:000000006889196

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	<ul style="list-style-type: none"> U1000: CAN COMM U1010: CONTROL UNIT (CAN)
2	<ul style="list-style-type: none"> B2190: NATS ANTENNA AMP B2191: DIFFERENCE OF KEY B2192: ID DISCORD BCM-ECM B2193: CHAIN OF BCM-ECM B2195: ANTI SCANNING
3	C1735: IGN CIRCUIT OPEN

DTC Index

INFOID:000000006889197

NOTE:

Details of time display

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM (BODY CONTROL MODULE)

[BCM]

< ECU DIAGNOSIS INFORMATION >

- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Reference
U1000: CAN COMM	—	SEC-38
U1010: CONTROL UNIT (CAN)	—	BCS-47
B2190: NATS ANTENNA AMP	×	SEC-40
B2191: DIFFERENCE OF KEY	×	SEC-42
B2192: ID DISCORD BCM-ECM	×	SEC-43
B2193: CHAIN OF BCM-ECM	×	SEC-45
B2195: ANTI SCANNING	×	SEC-46
C1735: IGN CIRCUIT OPEN	—	BCS-48

BCM (BODY CONTROL MODULE)

[BCM]


< WIRING DIAGRAM >

WIRING DIAGRAM

BCM (BODY CONTROL MODULE)

Wiring Diagram

INFOID:000000006737479



AAMWA0536GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


BCS

BCM (BODY CONTROL MODULE)

[BCM]

< WIRING DIAGRAM >

- ◀ FH ▶ : WITH HIGH ROOF
- ◀ PL ▶ : WITH POWER DOOR LOCKS
- ◀ PS ▶ : WITH POWER SEATS
- ◀ PW ▶ : WITH POWER WINDOWS




AAMWA0537GB

BCM (BODY CONTROL MODULE)

< WIRING DIAGRAM >

[BCM]



AAMWA0538GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCS


BCM (BODY CONTROL MODULE)

< WIRING DIAGRAM >


[BCM]

BCM (BODY CONTROL MODULE) CONNECTORS

Connector No.	M10
Connector Name	FRONT FOG LAMP SWITCH
Connector Color	WHITE



Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	P	-
3	-	-
4	V	-
5	BR	-
6	-	-

Terminal No.	Color of Wire	Signal Name
1	-	-
2	L	INPUT 5
3	P	INPUT 4
4	LG	INPUT 3
5	O	INPUT 2
6	R	INPUT 1
7	Y	KEY CYLINDER UNLOCK SW
8	SB	KEY CYLINDER LOCK SW
9	LG	BRAKE SW 1
10	BR	REAR DEFOGGER SW
11	O	ACC SW
12	O	DOOR SW (AS)
13	GR	DOOR SW (RR)
14	-	-
15	-	-

Terminal No.	Color of Wire	Signal Name
16	-	-
17	-	-
18	P	KEYLESS AND AUTO LIGHT SENSOR GND
19	V	KEYLESS TUNER POWER SUPPLY
20	W	KEYLESS TUNER SIGNAL
21	G	IMMOBILIZER ONE WAY COMMUNICATION (CLOCK)
22	-	-
23	G	SECURITY INDICATOR OUTPUT
24	-	-
25	BR	IMMOBILIZER TWO WAY COMMUNICATION
26	-	-
27	GR	AIR CON SW
28	Y	BLOWER FAN SW
29	O	HAZARD SW
30	-	-
31	-	-
32	SB	OUTPUT 5
33	G	OUTPUT 4
34	Y	OUTPUT 3
35	BR	OUTPUT 2
36	Y	OUTPUT 1
37	BR	KEY SW
38	R	IGN SW
39	L	CAN-H
40	P	CAN-L


AAM1A1033GB

BCM (BODY CONTROL MODULE)

[BCM]


< WIRING DIAGRAM >

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	R	-
2	P	OUTPUT 4
5	LG	OUTPUT 3
6	V	-
7	Y	INPUT 3
8	L	OUTPUT 5
9	BR	INPUT 2
10	G	INPUT 4
11	Y	INPUT 1
12	R	OUTPUT 1
13	SB	INPUT 5
14	O	OUTPUT 2

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
56	SB	BATTERY SAVER OUTPUT
57	LG	BATTERY (FUSE)
58	-	-
59	W	DOOR UNLOCK OUTPUT (DR)
60	Y	FLASHER OUTPUT (LEFT)
61	G	FLASHER OUTPUT (RIGHT)
62	-	-
63	L	ROOM LAMP OUTPUT
64	-	-
65	G	DOOR LOCK OUTPUT
66	Y	DOOR UNLOCK OUTPUT (AS;RR;RL,BD)
67	B	GND
68	W	POWER WINDOW POWER SUPPLY (RAP)
69	L	POWER WINDOW POWER SUPPLY (BATTERY)
70	R	BATTERY (FL)

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
41	-	-
42	-	-
43	-	-
44	-	-
45	GR	CENTRAL DOOR LOCK SW
46	R	CENTRAL DOOR UNLOCK SW
47	SB	DOOR SW (DR)
48	O	DOOR SW (SLIDE, BK LWR)
49	-	-
50	-	-
51	V	TRAILER FLASHER OUTPUT (RIGHT)
52	G	TRAILER FLASHER OUTPUT (LEFT)
53	-	-
54	-	-
55	-	-

AAMIA1034GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


BCS

BCM (BODY CONTROL MODULE)

< WIRING DIAGRAM >

[BCM]

Connector No.	M34
Connector Name	LIGHTING SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	ILL (+)
2	BR	INPUT 2
3	Y	INPUT 3
4	G	INPUT 4
5	L	OUTPUT 5
6	P	OUTPUT 4
7	-	-
8	BR	ILL (-)

ABMIA3751GB

BASIC INSPECTION

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM)

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Description

INFOID:000000006889198

BEFORE REPLACEMENT

When replacing BCM, save or print current vehicle specification with CONSULT configuration before replacement.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

AFTER REPLACEMENT

CAUTION:

- When replacing BCM, you must perform "After Replace ECU" with CONSULT.
- Complete the procedure of "After Replace ECU" in order.
- If you set incorrect "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- When replacing BCM, perform the system initialization (NATS).

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Work Procedure

INFOID:000000006889199

1. SAVING VEHICLE SPECIFICATION

CONSULT

Enter "Re/Programming, Configuration" and perform "Before Replace ECU" to save or print current vehicle specification.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

>> GO TO 2.

2. REPLACE BCM

Replace BCM. Refer to [BCS-55. "Removal and Installation"](#).

>> GO TO 3.

3. WRITING VEHICLE SPECIFICATION

CONSULT

1. Enter "Re/Programming, Configuration".
2. If "Before Replace ECU" operation was performed, automatically an "Operation Log Selection" screen will be displayed. Select the applicable file from the "Saved Data List" and press "Confirm" to write vehicle specification. Refer to [BCS-44. "CONFIGURATION \(BCM\) : Work Procedure"](#).
3. If "Before Replace ECU" operation was not performed, select "After Replace ECU" or "Manual Configuration" to write vehicle specification. Refer to [BCS-44. "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 4.

4. INITIALIZE BCM (NATS)

Perform BCM initialization. (NATS)

>> Work End.

CONFIGURATION (BCM)

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[BCM]

CONFIGURATION (BCM) : Description

INFOID:000000006889200

Vehicle specification needs to be written with CONSULT because it is not written after replacing BCM. Configuration has three functions as follows:

Function	Description
"Before Replace ECU"	<ul style="list-style-type: none">• Reads the vehicle configuration of current BCM.• Saves the read vehicle configuration.
"After Replace ECU"	Writes the vehicle configuration with manual selection.
"Select Saved Data List"	Writes the vehicle configuration with saved data.

CAUTION:

- When replacing BCM, you must perform "Select Saved Data List" or "After Replace ECU" with CONSULT.
- Complete the procedure of "Select Saved Data List" or "After Replace ECU" in order.
- If you set incorrect "Select Saved Data List" or "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Select Saved Data List" or "After Replace ECU" except for new BCM.

CONFIGURATION (BCM) : Work Procedure

INFOID:000000006889201

1. WRITING MODE SELECTION

CONSULT

Select "Reprogramming, Configuration" of BCM.

When writing saved data >> GO TO 2.

When writing manually >> GO TO 3.

2. PERFORM "SAVED DATA LIST"

CONSULT

Automatically "Operation Log Selection" window will display if "Before Replace ECU" was performed. Select applicable file from the "Save Data List" and press "Confirm".

>> Work End.

3. PERFORM "AFTER REPLACE ECU" OR "MANUAL CONFIGURATION"

CONSULT

1. Select "After Replace ECU" or "Manual Configuration".
2. Identify the correct model and configuration list. Refer to [BCS-45, "CONFIGURATION \(BCM\) : Configuration List"](#).
3. Confirm and/or change setting value for each item.
CAUTION:
Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.
4. Select "Next".
CAUTION:
Make sure to select "Next", confirm each setting value and press "OK" even if the indicated configuration of brand new BCM is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model can not be memorized.
5. When "Completed", select "End".

>> GO TO 4.

4. OPERATION CHECK

Confirm that each function controlled by BCM operates normally.

>> Work End.

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[BCM]

CONFIGURATION (BCM) : Configuration List

INFOID:000000006889202

CAUTION:

Thoroughly read and understand the vehicle specification. Incorrect settings may result in abnormal control of ECU.

MANUAL SETTING ITEM	
Items	Setting value
THEFT ALARM	WITH ⇔ WITHOUT
KEYLESS ENTRY	WITH ⇔ WITHOUT
AUTO LOCK&UNLOCK FUNC	WITH ⇔ WITHOUT

⇔: Items which confirm vehicle specifications

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM

Description

INFOID:000000006889203

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. Refer to [LAN-28. "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

DTC Logic

INFOID:000000006889204

DTC DETECTION LOGIC

DTC	DTC Detection Condition	Possible cause
U1000: CAN COMM	When BCM cannot communicate CAN communication signal continuously for 2 seconds or more.	CAN communication system

Diagnosis Procedure

INFOID:000000006889205

1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" of BCM.

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-15. "Trouble Diagnosis Flow Chart"](#).
- NO >> Refer to [GI-39. "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

[BCM]

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

DTC Logic

INFOID:000000006889206

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition	Possible cause
U1010	CONTROL UNIT (CAN)	BCM detected internal CAN communication circuit malfunction.	BCM

Diagnosis Procedure

INFOID:000000006889207

1. REPLACE BCM

When DTC "U1010" is detected, replace BCM.

>> Replace BCM. Refer to [BCS-55. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

C1735 IGN CIRCUIT OPEN

[BCM]

< DTC/CIRCUIT DIAGNOSIS >

C1735 IGN CIRCUIT OPEN

DTC Logic

INFOID:000000006889208

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition	Possible cause
C1735	IGN CIRCUIT OPEN	Detected following signals are different for 2 seconds; <ul style="list-style-type: none">Ignition switch ON signal inputted from ignition switchIgnition relay status signal received from IPDM E/R with CAN communication	<ul style="list-style-type: none">Harness or connector (Ignition power supply circuit)BCMIPDM E/R

NOTE:

BCM may detect that ignition switch is OFF when IGN power supply voltage is low.

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION

- Erase DTC.
- Turn the ignition switch OFF.
- Perform "Self Diagnostic Result".

Is any DTC detected?

- YES >> Refer to [BCS-48, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000006889209

1. CHECK BCM IGNITION POWER SUPPLY CIRCUIT

Check BCM ignition power supply circuit. Refer to [BCS-49, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the malfunctioning part.

2. CHECK IPDM E/R POWER SUPPLY CIRCUIT

Check IPDM E/R power supply circuit. Refer to [PCS-23, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair the malfunctioning part.

3. CHECK IPDM E/R IGNITION RELAY STATUS

ⓑ CONSULT

- Select "IGN RLY" of IPDM E/R data monitor item.
- While operating the ignition switch, check the monitor status.

Monitor item	Condition	Monitor status
IGN RLY	Ignition switch	OFF
		ON

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-55, "Removal and Installation"](#).
NO >> Replace IPDM E/R. Refer to [PCS-24, "Removal and Installation"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BCM]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000006889210

Regarding Wiring Diagram information, refer to [BCS-37. "Wiring Diagram"](#).

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

Terminal No.	Signal name	Fuses and fusible link No.
57	Battery power supply	22 (10A)
70		J (40A)
11	Ignition ACC or ON	9 (10A)
38	Ignition ON or START	12 (10A)

Is the fuse blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM connector and ground.

Terminals		(-)	Ignition switch position			
(+) BCM			Ground	OFF	ACC	ON
Connector	Terminal					
M20	70	Ground	Battery voltage	Battery voltage	Battery voltage	
	57		Approx. 0 V	Battery voltage	Battery voltage	
M18	11		Approx. 0 V	Approx. 0 V	Battery voltage	
	38					

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	67		Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

COMBINATION AND LIGHTING SWITCH OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BCM]

COMBINATION AND LIGHTING SWITCH OUTPUT CIRCUIT

Diagnosis Procedure

INFOID:000000006889211

Regarding Wiring Diagram information, refer to [BCS-37. "Wiring Diagram"](#).

1. CHECK OUTPUT 1 - 5 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM, combination switch, lighting switch and front fog lamps switch connectors.
3. Check continuity between BCM connector and combination switch connector.

Signal	BCM		Combination switch		Continuity
	Connector	Terminal	Connector	Terminal	
Output 1	M18	36	M28	11	Yes
Output 2		35		9	
Output 3		34		7	
Output 4		33		10	
Output 5		32		13	

4. Check continuity between BCM connector and lighting switch connector.

Signal	BCM		Lighting switch		Continuity
	Connector	Terminal	Connector	Terminal	
Output 2	M18	35	M34	2	Yes
Output 3		34		3	
Output 4		33		4	

5. Check continuity between BCM connector and front fog lamps switch connector.

Signal	BCM		Front fog lamps switch		Continuity
	Connector	Terminal	Connector	Terminal	
Output 5	M18	32	M10	1	Yes

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harnesses or connectors.

2. CHECK OUTPUT 1 - 5 CIRCUIT FOR SHORT

Check for continuity between BCM connector and ground.

Signal	BCM		Ground	Continuity
	Connector	Terminal		
Output 1	M18	36		No
Output 2		35		
Output 3		34		
Output 4		33		
Output 5		32		

Is the inspection result normal?

YES >> Repair harnesses or connectors.

NO >> GO TO 3.


COMBINATION AND LIGHTING SWITCH OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BCM]

3. CHECK BCM OUTPUT VOLTAGE

1. Connect BCM connector.
2. Check voltage between BCM connector and ground.

Signal	Terminals		Voltage (Approx.)
	(+)		
	BCM		
	Connector	Terminal	 <p>7.0 - 8.0 V</p>
Output 1	M18	36	
Output 2		35	
Output 3		34	
Output 4		33	
Output 5		32	
		Ground	

Is the inspection result normal?

- YES >> Replace malfunctioning switch.
 NO >> Replace BCM. Refer to [BCS-55, "Removal and Installation"](#).

BCS

COMBINATION AND LIGHTING SWITCH INPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BCM]

COMBINATION AND LIGHTING SWITCH INPUT CIRCUIT

Diagnosis Procedure

INFOID:000000006889212

Regarding Wiring Diagram information, refer to [BCS-37. "Wiring Diagram"](#).

1. CHECK INPUT 1 - 5 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM, combination switch, lighting switch and front fog lamps switch connectors.
3. Check continuity between BCM connector and combination switch connector.

Signal	BCM		Combination switch		Continuity
	Connector	Terminal	Connector	Terminal	
Input 1	M18	6	M28	12	Yes
Input 2		5		14	
Input 3		4		5	
Input 4		3		2	
Input 5		2		8	

4. Check continuity between BCM connector and lighting switch connector.

Signal	BCM		Lighting switch		Continuity
	Connector	Terminal	Connector	Terminal	
Input 4	M18	3	M34	6	Yes
Input 5		2		5	

5. Check continuity between BCM connector and front fog lamps switch connector.

Signal	BCM		Front fog lamps switch		Continuity
	Connector	Terminal	Connector	Terminal	
Input 4	M18	3	M10	2	Yes

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harnesses or connectors.

2. CHECK INPUT 1 - 5 CIRCUIT FOR SHORT

Check for continuity between BCM connector and ground.

Signal	BCM		Ground	Continuity
	Connector	Terminal		
Input 1	M18	6		No
Input 2		5		
Input 3		4		
Input 4		3		
Input 5		2		

Is the inspection result normal?

YES >> Repair harnesses or connectors.

NO >> GO TO 3.

3. CHECK BCM INPUT SIGNAL

COMBINATION AND LIGHTING SWITCH INPUT CIRCUIT

[BCM]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect BCM, combination switch and lighting switch connectors.
2. Turn ON any switch in the system that is malfunctioning.
3. Check voltage between BCM connector and ground.

Signal	Terminals		Voltage (Approx.)	
	(+)			(-)
	BCM			
	Connector	Terminal		
Input 1	M18	6	Ground	
Input 2		5		
Input 3		4		
Input 4		3		
Input 5		2		

Refer to [BCS-25. "Reference Value"](#).

Is the inspection result normal?

- Yes >> Replace BCM. Refer to [BCS-55. "Removal and Installation"](#).
 No >> Replace malfunctioning switch.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

COMBINATION AND LIGHTING SWITCH SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[BCM]

SYMPTOM DIAGNOSIS

COMBINATION AND LIGHTING SWITCH SYSTEM SYMPTOMS

Symptom Table

INFOID:000000006889214

1. Perform "Data Monitor" of CONSULT to check for any malfunctioning item.
2. Check the malfunction combinations.

Malfunctioning item: x

Data monitor item													Malfunction combination
FR FOG SW	FR WIPER HI	FR WIPER LOW	FR WASHER SW	FR WIPER INT	INT VOLUME	TURN SIGNAL R	TURN SIGNAL L	TAIL LAMP SW	HI BEAM SW	HEAD LAMP SW 1	HEAD LAMP SW 2	PASSING SW	
		x	x			x	x						A
	x			x						x		x	B
					x				x		x		C
					x			x					D
x					x								E
	x				x								F
			x		x								G
		x		x									H
x							x				x	x	I
						x		x	x	x			J
All Items												K	
If only one item is detected or the item is not applicable to the combinations A to K												L	

3. Identify the malfunctioning part from the agreed combination and repair or replace the part.

Malfunction combination	Malfunctioning part	Repair or replace
A	Output 1 signal circuit	Inspect the output signal circuit applicable to the malfunctioning part. Refer to BCS-50. "Diagnosis Procedure" .
B	Output 2 signal circuit	
C	Output 3 signal circuit	
D	Output 4 signal circuit	
E	Output 5 signal circuit	Inspect the input signal circuit applicable to the malfunctioning part. Refer to BCS-52. "Diagnosis Procedure" .
F	Input 1 signal circuit	
G	Input 2 signal circuit	
H	Input 3 signal circuit	
I	Input 4 signal circuit	
J	Input 5 signal circuit	Replace BCM. Refer to BCS-55. "Removal and Installation" .
K	BCM	
L	Combination or lighting switch	Replace malfunctioning switch.

BCM (BODY CONTROL MODULE)

< REMOVAL AND INSTALLATION >


[BCM]

REMOVAL AND INSTALLATION

BCM (BODY CONTROL MODULE)

Exploded View

INFOID:000000007079156



1. Body control module (BCM) A. Screws

Removal and Installation


INFOID:000000006737483

REMOVAL

CAUTION:

Before removing BCM, retrieve current BCM configuration to use for reference when configuring brand-new BCM after installation. Refer to [BCS-44, "CONFIGURATION \(BCM\) : Description"](#).

1. Disconnect the negative battery terminal.
2. Remove the combination meter. Refer to [MWI-64, "Removal and Installation"](#).
3. Remove the BCM screws (A).
4. Pull out the BCM (1).
5. Disconnect the harness connectors (B) from the BCM (1) and remove.



INSTALLATION

Installation is in the reverse order of removal.

- When replacing BCM, it must be configured. Refer to [BCS-45, "CONFIGURATION \(BCM\) : Configuration List"](#).
- When replacing BCM, perform initialization of NATS system and registration of all NATS ignition key IDs. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.