

STR

SECTION STR
STARTING SYSTEM

PRECAUTION	2	DIAGNOSIS AND REPAIR WORKFLOW	17
PRECAUTIONS	2	Work Flow	17
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	2		
PREPARATION	3	DTC/CIRCUIT DIAGNOSIS	20
PREPARATION	3	B TERMINAL CIRCUIT	20
Special Service Tool	3	Description	20
Commercial Service Tool	3	Diagnosis Procedure	20
SYSTEM DESCRIPTION	4	S CONNECTOR CIRCUIT	21
COMPONENT PARTS	4	Description	21
VQ40DE	4	Diagnosis Procedure	21
VQ40DE : Component Parts Location	4	SYMPTOM DIAGNOSIS	23
VQ40DE : Component Description	5	Starting System	23
VK56DE	5	Symptom Table	23
VK56DE : Component Parts Location	6	REMOVAL AND INSTALLATION	24
VK56DE : Component Description	7	STARTER MOTOR	24
SYSTEM	8	VQ40DE	24
System Diagram	8	VQ40DE : Exploded View	24
System Description	8	VQ40DE : Removal and Installation	24
WIRING DIAGRAM	9	VK56DE	25
STARTING SYSTEM	9	VK56DE : Exploded View	25
Wiring Diagram - With VQ40DE	9	VK56DE : Removal and Installation	25
Wiring Diagram - With VK56DE	13	SERVICE DATA AND SPECIFICATIONS (SDS)	27
BASIC INSPECTION	17	STARTER MOTOR	27
		Starter	27

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000006915216

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

PREPARATION

< PREPARATION >

PREPARATION

PREPARATION


Special Service Tool

INFOID:000000006751573

STR

A

The actual shapes of Kent-Moore tools may differ from those of special tools illustrated here.

Tool number (Kent Moore No.)	Description
— (—) Model GR8-1200 NI Multitasking battery and electrical diagnostic station	 Tests Batteries, starting and charging system and changes batteries. For operating instructions, refer to diagnostic station instruction manual. AWIIA1239ZZ

C

D

E

F

Commercial Service Tool

INFOID:000000006751574

G

H

I

J

K

L

M

N

O

P

Tool name	Description
Power tool	 Loosening nuts, screws, and bolts. PIIB1407E

COMPONENT PARTS

< SYSTEM DESCRIPTION >



SYSTEM DESCRIPTION

COMPONENT PARTS

VQ40DE

VQ40DE : Component Parts Location

INFOID:0000000006923486



ALBIA0700ZZ

1. IPDM E/R
2. Starter motor
3. BCM (view with instrument panel removed)
4. A/T assembly (with built in TCM)

COMPONENT PARTS

< SYSTEM DESCRIPTION >

VQ40DE : Component Description

INFOID:000000006923487

A

Component part	Description
TCM	TCM supplies power to the starter relay inside the IPDM E/R when the selector lever is shifted to the P or N position.
BCM	BCM sends a starter request signal to the CPU of the IPDM E/R over the CAN communication lines.
IPDM E/R	CPU inside IPDM E/R operates the starter relay at the request of the BCM over the CAN communication lines.
Starter motor	The starter motor plunger closes and the motor is supplied with battery power, which in turn cranks the engine, when the "S" terminal is supplied with electric power.

VK56DE

STR

C

D

E

F

G

H

I

J

K

L

M

N

O



P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

VK56DE : Component Parts Location

INFOID:0000000006751578



ALBIA0701ZZ

1. IPDM E/R
2. Starter motor
(view with intake manifold removed)
3. BCM
(view with instrument panel removed)
4. A/T assembly
(with built in TCM)

COMPONENT PARTS

< SYSTEM DESCRIPTION >

VK56DE : Component Description

INFOID:000000006751579

A

Component part	Description
TCM	TCM supplies power to the starter relay inside the IPDM E/R when the selector lever is shifted to the P or N position.
BCM	BCM sends a starter request signal to the CPU of the IPDM E/R over the CAN communication lines.
IPDM E/R	CPU inside IPDM E/R operates the starter relay at the request of the BCM over the CAN communication lines.
Starter motor	The starter motor plunger closes and the motor is supplied with battery power, which in turn cranks the engine, when the "S" terminal is supplied with electric power.

STR

C

D

E

F

G

H

I

J

K

L

M

N

O

P


SYSTEM

< SYSTEM DESCRIPTION >

SYSTEM

System Diagram

INFOID:0000000006751576



ANBIA1045GB

System Description

INFOID:0000000006751577

The starter motor plunger closes and provides a closed circuit between the battery and the starter motor. The starter motor is grounded to the cylinder block. With power and ground supplied, the starter motor operates.

STARTING SYSTEM

< WIRING DIAGRAM >


WIRING DIAGRAM STARTING SYSTEM

Wiring Diagram - With VQ40DE

INFOID:000000006923488

STR

STARTING SYSTEM - WITH VQ40DE



* : THIS CONNECTOR IS AN INTEGRAL PART OF THE FUSIBLE LINK BOX (BATTERY).

† : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

ABBWA0714GB

STARTING SYSTEM

< WIRING DIAGRAM >

STARTING SYSTEM CONNECTORS - WITH VQ40DE

<table border="1"> <tr><td>Connector No.</td><td>M26</td></tr> <tr><td>Connector Name</td><td>IGNITION SWITCH</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	M26	Connector Name	IGNITION SWITCH	Connector Color	WHITE	<table border="1"> <tr><td>Connector No.</td><td>M31</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	M31	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1"> <tr><td>Connector No.</td><td>E5</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	E5	Connector Name	WIRE TO WIRE	Connector Color	WHITE												
Connector No.	M26																															
Connector Name	IGNITION SWITCH																															
Connector Color	WHITE																															
Connector No.	M31																															
Connector Name	WIRE TO WIRE																															
Connector Color	WHITE																															
Connector No.	E5																															
Connector Name	WIRE TO WIRE																															
Connector Color	WHITE																															
<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>B</td><td>ST</td><td>—</td></tr> <tr><td>ST</td><td>G</td><td>—</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	B	ST	—	ST	G	—	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>B</td><td>ST</td><td>—</td></tr> <tr><td>ST</td><td>G</td><td>—</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	B	ST	—	ST	G	—	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1G</td><td>2G</td><td>3G</td></tr> <tr><td>6G</td><td>7G</td><td>8G</td></tr> <tr><td>9G</td><td>10G</td><td>—</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	1G	2G	3G	6G	7G	8G	9G	10G	—
Terminal No.	Color of Wire	Signal Name																														
B	ST	—																														
ST	G	—																														
Terminal No.	Color of Wire	Signal Name																														
B	ST	—																														
ST	G	—																														
Terminal No.	Color of Wire	Signal Name																														
1G	2G	3G																														
6G	7G	8G																														
9G	10G	—																														
<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>10G</td><td>Y</td><td>—</td></tr> <tr><td>96G</td><td>G</td><td>—</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	10G	Y	—	96G	G	—	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>10G</td><td>Y</td><td>—</td></tr> <tr><td>96G</td><td>G</td><td>—</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	10G	Y	—	96G	G	—	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1G</td><td>2G</td><td>3G</td></tr> <tr><td>6G</td><td>7G</td><td>8G</td></tr> <tr><td>9G</td><td>10G</td><td>—</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	1G	2G	3G	6G	7G	8G	9G	10G	—
Terminal No.	Color of Wire	Signal Name																														
10G	Y	—																														
96G	G	—																														
Terminal No.	Color of Wire	Signal Name																														
10G	Y	—																														
96G	G	—																														
Terminal No.	Color of Wire	Signal Name																														
1G	2G	3G																														
6G	7G	8G																														
9G	10G	—																														
<table border="1"> <tr><td>Connector No.</td><td>E70</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>GRAY</td></tr> </table> 	Connector No.	E70	Connector Name	WIRE TO WIRE	Connector Color	GRAY	<table border="1"> <tr><td>Connector No.</td><td>E51</td></tr> <tr><td>Connector Name</td><td>FUSE BLOCK (J/B)</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	E51	Connector Name	FUSE BLOCK (J/B)	Connector Color	WHITE	<table border="1"> <tr><td>Connector No.</td><td>E119</td></tr> <tr><td>Connector Name</td><td>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	E119	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Color	WHITE												
Connector No.	E70																															
Connector Name	WIRE TO WIRE																															
Connector Color	GRAY																															
Connector No.	E51																															
Connector Name	FUSE BLOCK (J/B)																															
Connector Color	WHITE																															
Connector No.	E119																															
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)																															
Connector Color	WHITE																															
<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>W</td><td>—</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	1	W	—	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>W</td><td>—</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	1	W	—	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>12</td><td>W</td><td>IGN SW(G1)</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	12	W	IGN SW(G1)												
Terminal No.	Color of Wire	Signal Name																														
1	W	—																														
Terminal No.	Color of Wire	Signal Name																														
1	W	—																														
Terminal No.	Color of Wire	Signal Name																														
12	W	IGN SW(G1)																														

ABBIA0899GB


STARTING SYSTEM

< WIRING DIAGRAM >

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
19	W	STARTER MOTOR
21	Y	IGN SW(ST)

Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L
48	BR	NPSW

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)



Terminal No.	Color of Wire	Signal Name
1	W	-


ABBIA0900GB

A
STR
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

STARTING SYSTEM

< WIRING DIAGRAM >

Connector No.	E209
Connector Name	STARTER MOTOR
Connector Color	GRAY



Connector No.	E209
Connector Name	STARTER MOTOR
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	W	-


Terminal No.	Color of Wire	Signal Name
2	W	-

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	BR	-

Terminal No.	Color of Wire	Signal Name
9	BR	-



Connector No.	F502
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	GRAY

Terminal No.	Color of Wire	Signal Name
8	G	START-RLY

ABBIA0901GB

STARTING SYSTEM

< WIRING DIAGRAM >


Wiring Diagram - With VK56DE

INFOID:0000000006751584

A

STR

STARTING SYSTEM - WITH VK56DE



* : THIS CONNECTOR IS AN INTEGRAL PART OF THE FUSIBLE LINK BOX (BATTERY).

† : THIS CONNECTOR IS NOT SHOWN IN HARNESS LAYOUT™ OF PG SECTION.

ABBWA0713GB

STARTING SYSTEM

< WIRING DIAGRAM >

STARTING SYSTEM CONNECTORS - WITH VK56DE


Connector No.	M26
Connector Name	IGNITION SWITCH
Connector Color	WHITE



Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	BR	—

Terminal No. 9 BR —

1G 2G 3G 4G 5G 6G 7G 8G 9G 10G 20G 21G 2G 6G 23G 34G 35G 36G 37G 38G 39G 40G 41G 4G 43G 44G 45G 46G 47G 48G 49G 50G
5G 5G 53G 54G 55G 56G 57G 58G 59G 60G 61G 6G 63G 64G 65G 66G 67G 68G 69G 70G
7G 72G 73G 74G 75G 76G 77G 78G 80G 81G 8G 83G 84G 85G 86G 87G 88G 89G 90G
9G 92G 93G 94G 95G 96G 97G 98G 99G 100G

1G|2G|3G|4G|5G|6G|7G|8G|9G|10G|20G|21G
2G|6G|23G|34G|35G|36G|37G|38G|39G|40G|41G
4G|43G|44G|45G|46G|47G|48G|49G|50G

5G|5G|53G|54G|55G|56G|57G|58G|59G|60G|61G
6G|63G|64G|65G|66G|67G|68G|69G|70G

7G|72G|73G|74G|75G|76G|77G|78G|80G|81G
8G|83G|84G|85G|86G|87G|88G|89G|90G


9G|92G|93G|94G|95G
96G|97G|98G|99G|100G

Terminal No.	Color of Wire	Signal Name
10G	Y	—
96G	G	—

Terminal No. 10G Y —

96G G —

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Connector No.	E51
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	E39
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2T	W	—

Terminal No. 2T W —


STARTING SYSTEM

< WIRING DIAGRAM >

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
19	W	STARTER MOTOR
21	Y	IGN SW(ST)

Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L
48	BR	NPSW

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)



Terminal No.	Color of Wire	Signal Name
9	BR	-


STR C D E F G H I J K L M Z O P

ABBIA0897GB

STARTING SYSTEM

< WIRING DIAGRAM >

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	F27
Connector Name	STARTER MOTOR
Connector Color	—




Terminal No.	Color of Wire	Signal Name
1	B/R	—

Connector No.	F28
Connector Name	STARTER MOTOR
Connector Color	GRAY



Connector No.	F34
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	—

Connector No.	F502
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	GRAY



Connector No.	F34
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	G	START-RLY

ABBIA0898GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006751575

STR

C

D

E

F

G

H

I

J

K

L


M

N

O

P

OVERALL SEQUENCE



DETAILED FLOW

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

NOTE:

To ensure a complete and thorough diagnosis, the battery, starter motor and generator test segments must be done as a set from start to finish.

1. DIAGNOSIS WITH MULTITASKING BATTERY DIAGNOSTIC STATION

Perform the starting system test with multitasking battery diagnostic station. For details and operating instructions, refer to diagnostic station instruction manual.

Test result

CRANKING NORMAL>>GO TO 2

LOW VOLTAGE>>GO TO 5

CHARGE BATTERY>>Perform the slow battery charging procedure. (Initial rate of charge is 10A for 12 hours.) Perform battery test again. Refer to diagnostic station instruction manual.

REPLACE BATTERY>>Before replacing battery, clean the battery cable clamps and battery posts. Perform battery test again. Refer to diagnostic station instruction manual. If second test result is "REPLACE BATTERY", then do so. Perform battery test again to confirm repair.

2. CRANKING CHECK

Check that the starter motor operates properly.

Does the engine crank normally?

YES >> GO TO 3

NO >> GO TO 4

3. ENGINE START CHECK

Check that the engine starts.

Does the engine start?

YES >> Starter motor is OK. Inspection end.

NO >> Perform further diagnosis of engine mechanical or engine control system. Refer to EM and EC sections. Once resolved, perform battery test again.

4. STARTER MOTOR ACTIVATION

Check that the starter motor operates.

Does the starter motor turn?

YES >> Check ring gear and starter motor drive pinion. Once resolved, perform battery test again.

NO >> GO TO 7

5. COMPARISON BETWEEN ENGINE COOLANT AND CRANKING VOLTAGE

Compare the engine coolant temperature and verify the cranking voltage is within specification.

Minimum Specification of Cranking Voltage Referencing Coolant Temperature

Engine coolant temperature [°C (°F)]	Voltage [V]
-30 to -20 (-22 to -4)	8.6
-19 to -10 (-2 to 14)	9.1
-9 to 0 (16 to 32)	9.5
More than 1 (More than 34)	9.9

Is the voltage less than the specified value?

YES >> GO TO 7

NO >> GO TO 6

6. STARTER OPERATION

Check the starter operation.

Does the starter motor turn smoothly?

YES >> Starter motor is OK. Inspection end.

NO >> GO TO 7

7. "B" TERMINAL CIRCUIT INSPECTION

Check "B" terminal circuit. Refer to [STR-20, "Diagnosis Procedure"](#).

Is "B" terminal circuit normal?

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

YES >> GO TO 8

NO >> Repair as needed.

A

8.“S” CONNECTOR CIRCUIT INSPECTION

Check “S” connector circuit. Refer to [STR-21, "Diagnosis Procedure"](#).

STR

Is “S” connector circuit normal?

C

YES >> GO TO 9

NO >> Repair as needed.

D

9.ENGINE ROTATION STATUS

Check that the engine can be rotated by hand.

F

Does the engine turn freely by hand?

G

YES >> Replace starter motor.

H

NO >> Perform further diagnosis of engine mechanical or powertrain mechanism. Refer to EM or TM sections. Once resolved, perform battery test again. Refer to diagnostic station instruction manual.

I

J

K

L

M

N

O

P

B TERMINAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

B TERMINAL CIRCUIT

Description

INFOID:0000000006751580

Terminal "1" (B) is constantly supplied with battery power.

Diagnosis Procedure

INFOID:0000000006751581

Regarding Wiring Diagram information, refer to [STR-9, "Wiring Diagram - With VQ40DE"](#) or [STR-13, "Wiring Diagram - With VK56DE"](#).

CAUTION:

Perform diagnosis under the condition that the engine cannot start by the following procedure.

1. Remove fuel pump fuse.
2. Crank or start the engine (where possible) until the fuel pressure is depleted.

1. CHECK TERMINAL 1 POWER SUPPLY VOLTAGE

1. Turn ignition switch OFF.
2. Make sure that starter motor connector E208 (VQ40DE) or F27 (VK56DE) terminal 1 connection is clean and tight.
3. Check voltage between starter motor connector E208 (VQ40DE) or F27 (VK56DE) terminal 1 and ground.

(+) Connector		(-) Terminal	Voltage
E208 (VQ40DE)		1	Ground
F27 (VK56DE)			Battery voltage

Is the inspection result normal?

YES >> GO TO 2

NO >> Check harness between battery and starter motor for open circuit.

2. CHECK BATTERY CABLE (VOLTAGE DROP TEST)

1. Shift the transmission into P (Park) or N (Neutral).
2. Check voltage between battery positive terminal and starter motor connector E208 (VQ40DE) or F27 (VK56DE) terminal 1 while cranking the engine.

(+) Connector		(-) Terminal	Condition	Voltage
E208 (VQ40DE)		1	Battery (+) terminal	While cranking the engine
F27 (VK56DE)				Less than 0.2V

Is the inspection result normal?

YES >> GO TO 3

NO >> Check harness between the battery and the starter motor for high resistance.

3. CHECK GROUND CIRCUIT STATUS (VOLTAGE DROP TEST)

Check voltage between starter motor case and battery negative terminal while cranking the engine.

(+)	(-)	Condition	Voltage
Starter motor case	Battery (-) terminal	While cranking the engine	Less than 0.2V

Is the inspection result normal?

YES >> Terminal 1 circuit is OK. Further inspection necessary. Refer to [STR-17, "Work Flow"](#).

NO >> Check the starter motor case to engine mounting for high resistance.

S CONNECTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

S CONNECTOR CIRCUIT

Description

INFOID:0000000006751582

Terminal "2" (S) is the power supply for the starter motor magnetic switch. Terminal 2 is supplied with power when the ignition switch is turned to the START position while the selector lever is in the P (Park) or N (Neutral) position.

A

STR

Diagnosis Procedure

INFOID:0000000006751583

C

Regarding Wiring Diagram information, refer to [STR-9, "Wiring Diagram - With VQ40DE"](#) or [STR-13, "Wiring Diagram - With VK56DE"](#).

D

CAUTION:

Perform diagnosis under the condition that engine cannot start by the following procedure.

E

1. Remove fuel pump fuse.
2. Crank or start the engine (where possible) until the fuel pressure is released.

F

1.CHECK STARTER MOTOR MAGNETIC SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect starter motor connector E209 (VQ40DE) or F28 (VK56DE).
3. Shift transmission into park or neutral.
4. Check voltage between starter motor connector E209 (VQ40DE) or F28 (VK56DE) terminal 2 and ground with the ignition in START.

G

H

(+)		(-)	Condition	Voltage
Connector	Terminal			
E209 (VQ40DE)				
F28 (VK56DE)	2	Ground	Ignition switch in START position	Battery voltage

I

J

Is the inspection result normal?

K

L

M

N

O

P

YES >> Magnetic switch circuit is OK. Further inspection is necessary. Refer to [STR-17, "Work Flow"](#).
NO >> GO TO 2

2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Check the IPDM E/R connector E120 and starter motor connector E209 (VQ40DE) or F28 (VK56DE) for damage, bent pins and loose connections.

Is the inspection result normal?

M

N

O

P

YES >> GO TO 3
NO >> Repair the terminal and connector.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect IPDM E/R connector E120 and starter motor connector E209 (VQ40DE) or F28 (VK56DE).
2. Check continuity between starter motor connector E209 (VQ40DE) or F28 (VK56DE) terminal 2 and IPDM E/R connector E120 terminal 19.

Connector	Terminal	Connector	Terminal	Continuity
Connector	Terminal			
E209 (VQ40DE)		E120		
F28 (VK56DE)	2		19	Yes

3. Check continuity between starter motor connector E209 (VQ40DE) or F28 (VK56DE) terminal 2 and ground.

Connector	Terminal	—	Continuity
Connector	Terminal		

S CONNECTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

E209 (VQ40DE)	2	Ground	No
F28 (VK56DE)			

Is the inspection result normal?

- YES >> Further inspection necessary. Refer to [STR-17, "Work Flow"](#).
NO >> Repair the harness.

STARTING SYSTEM

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

STARTING SYSTEM

Symptom Table

INFOID:000000006751585

STR

Symptom	Reference
No normal cranking	
Starter motor does not rotate	Refer to STR-17, "Work Flow" .

C

D

E

F

G

H

I

J

K

L

M

N

O

P

STARTER MOTOR

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION

STARTER MOTOR

VQ40DE

VQ40DE : Exploded View

INFOID:0000000006915219



1. Starter cover
2. Starter motor assembly
3. Starter cover plate (rear)
4. Transmission housing

VQ40DE : Removal and Installation

INFOID:0000000006915218


Removal

1. Disconnect the negative battery terminal. Refer to [PG-90, "Removal and Installation"](#).
2. Remove the front RH wheel and tire assembly using power tool.
3. Remove the front RH fender protector. Refer to [EXT-33, "Removal and Installation"](#).
4. Remove the exhaust manifold heat shield bolts and reposition the heat shield.
5. Remove starter cover bolts and starter cover.

STARTER MOTOR

< REMOVAL AND INSTALLATION >

6. Disconnect terminal S connector and terminal B nut.
7. Remove the two starter bolts, using power tools.
8. Remove the starter.



Installation

Installation is in the reverse order of removal.

- Tighten the front RH wheel and tire assembly to specification. Refer to [WT-63, "Adjustment"](#).


CAUTION:

Tighten terminal B nut carefully.

VK56DE

VK56DE : Exploded View

INFOID:000000006953171



- | | | |
|---------------------------|-------------------|---------------------|
| 1. Starter motor assembly | A. Terminal B nut | B. Terminal B cable |
| C. Terminal S connector | ← Engine front | |

VK56DE : Removal and Installation

INFOID:000000006953170

REMOVAL

1. Remove the intake manifold. Refer to [EM-165, "Removal and Installation"](#).

STARTER MOTOR

< REMOVAL AND INSTALLATION >

-
2. Remove the starter harness terminal B nut, and terminal B cable.
 3. Disconnect terminal S connector.
 4. Remove terminal S harness clips from brackets.
 5. Remove the two starter bolts, using power tools.
 6. Remove the starter.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

Tighten terminal B nut carefully.

STARTER MOTOR

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

STARTER MOTOR

Starter

INFOID:000000006751587

A
STR

Application - engine type	VQ40DE	VK56DE
Manufacturer	Mitsubishi	
Model number*	M001TA0072	M001T30671
Starter type	Reduction gear type	
System voltage	12V	
No-load	Terminal voltage	11V
	Current	Less than 120A
	Revolution	More than 3,100 rpm
*: Always check with Parts Department for the latest parts information.		

C

D

E

F

G

H

I

J

K

L

M

N

O

P