

A  
B  
C

# WT

## SECTION

### ROAD WHEELS & TIRES

## CONTENTS

WT

<b>PRECAUTION</b> .....	<b>Wiring Diagram</b> .....	19	F
<b>PRECAUTIONS</b> .....	<b>BASIC INSPECTION</b> .....	25	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	<b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....	25	G
	Work Flow .....	25	
<b>PREPARATION</b> .....	<b>ADDITIONAL SERVICE WHEN REPLACING LOW TIRE PRESSURE WARNING CONTROL UNIT</b> .....	27	H
<b>PREPARATION</b> .....	Description .....	27	I
Special Service Tool .....	Work Procedure .....	27	
Commercial Service Tool .....	<b>TRANSMITTER WAKE UP OPERATION</b> .....	28	J
<b>SYSTEM DESCRIPTION</b> .....	Description .....	28	K
<b>COMPONENT PARTS</b> .....	Work Procedure .....	28	
Component Parts Location .....	<b>ID REGISTRATION</b> .....	29	L
Component Description .....	Description .....	29	M
Low Tire Pressure Warning Control Unit .....	Work Procedure .....	29	
Transmitter .....	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	31	N
Tire Pressure Receiver .....	<b>C1704, C1705, C1706, C1707 LOW TIRE PRESSURE</b> .....	31	O
Low Tire Pressure Warning Light .....	DTC Logic .....	31	P
<b>SYSTEM</b> .....	Diagnosis Procedure .....	31	
System Description .....	<b>C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)</b> .....	33	
<b>DIAGNOSIS SYSTEM (LOW TIRE PRESSURE WARNING CONTROL UNIT)</b> .....	DTC Logic .....	33	
CONSULT Function .....	Diagnosis Procedure .....	33	
Self Diagnosis Without CONSULT .....	<b>C1716, C1717, C1718, C1719 TRANSMITTER (PRESSURE DATA)</b> .....	37	
<b>ECU DIAGNOSIS INFORMATION</b> .....	DTC Logic .....	37	
<b>LOW TIRE PRESSURE WARNING CONTROL UNIT</b> .....	Diagnosis Procedure .....	37	
Reference Value .....	<b>C1728 RECEIVER ID</b> .....	39	
DTC Inspection Priority Chart .....	DTC Logic .....	39	
DTC Index .....	Diagnosis Procedure .....	39	
<b>WIRING DIAGRAM</b> .....	<b>C1729 VEHICLE SPEED SIGNAL</b> .....	42	
<b>TIRE PRESSURE MONITORING SYSTEM</b> .....			

DTC Logic .....	42	<b>ID REGISTRATION CANNOT BE COMPLETED</b> .....	60
Diagnosis Procedure .....	42	Diagnosis Procedure .....	60
<b>C1750, C1751, C1752, C1753 RECEIVER</b> .....	44	<b>NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING</b> .....	61
DTC Logic .....	44	NVH Troubleshooting Chart .....	61
Diagnosis Procedure .....	44	<b>PERIODIC MAINTENANCE</b> .....	62
<b>C1754 LOW TIRE PRESSURE WARNING CONTROL UNIT</b> .....	47	<b>WHEEL</b> .....	62
DTC Logic .....	47	Inspection .....	62
Diagnosis Procedure .....	47	<b>WHEEL AND TIRE ASSEMBLY</b> .....	63
<b>C1755, C1756, C1757, C1758 POOR RECEIVING CONDITIONS</b> .....	50	Adjustment .....	63
DTC Logic .....	50	<b>UNIT REMOVAL AND INSTALLATION</b> ....	65
Diagnosis Procedure .....	50	<b>LOW TIRE PRESSURE WARNING CONTROL UNIT</b> .....	65
<b>U1000 CAN COMM CIRCUIT</b> .....	52	Exploded View .....	65
Description .....	52	Removal and Installation .....	65
DTC Logic .....	52	<b>TRANSMITTER</b> .....	66
Diagnosis Procedure .....	52	Exploded View .....	66
<b>U1010 CONTROL UNIT (CAN)</b> .....	53	Removal and Installation .....	66
Description .....	53	<b>TIRE PRESSURE RECEIVER</b> .....	68
DTC Logic .....	53	<b>FRONT TIRE PRESSURE RECEIVER</b> .....	68
Diagnosis Procedure .....	53	FRONT TIRE PRESSURE RECEIVER : Exploded View .....	68
<b>POWER SUPPLY AND GROUND CIRCUIT</b> ....	54	FRONT TIRE PRESSURE RECEIVER : Removal and Installation .....	68
Diagnosis Procedure .....	54	<b>REAR TIRE PRESSURE RECEIVER</b> .....	68
<b>SYMPTOM DIAGNOSIS</b> .....	55	REAR TIRE PRESSURE RECEIVER : Exploded View .....	68
<b>TPMS SYMPTOMS</b> .....	55	REAR TIRE PRESSURE RECEIVER : Removal and Installation .....	69
Symptom Table .....	55	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	70
<b>LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON</b> .....	56	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	70
Diagnosis Procedure .....	56	Road Wheel .....	70
<b>LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN OFF</b> .....	57	Tire .....	70
Diagnosis Procedure .....	57		
<b>LOW TIRE PRESSURE WARNING LAMP BLINKS</b> .....	58		
Diagnosis Procedure .....	58		
<b>"TIRE PRESSURE" INFORMATION IN DISPLAY UNIT DOES NOT EXIST</b> .....	59		
Diagnosis Procedure .....	59		

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006749884

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# PREPARATION

< PREPARATION >


## PREPARATION

### PREPARATION

#### Special Service Tool


INFOID:000000006749886

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV991B1000 (J-45295) Transmitter activation tool  WEIA0144E	<ul style="list-style-type: none"><li>• Transmitter wake up operation</li><li>• ID registration procedure</li></ul>

#### Commercial Service Tool

INFOID:000000006749887

Tool name	Description
Power tool  PIIB1407E	Loosening nuts, screws and bolts.

# COMPONENT PARTS



< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000006881090



- |   |                |   |
|---|----------------|---|
| 1. Combination meter  | 2. BCM         | 3. Low tire pressure warning control unit                           |
| 4. Tire pressure receiver front LH<br>Tire pressure receiver front RH | 5. Transmitter | 6. Tire pressure receiver rear LH<br>Tire pressure receiver rear RH |

ALEIA00672Z

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

## Component Description


INFOID:000000006881091

Component parts	Reference/Function
Transmitter	<a href="#">WT-6. "Transmitter"</a>
Tire pressure receiver	<a href="#">WT-7. "Tire Pressure Receiver"</a>
Low tire pressure warning control unit	<a href="#">WT-6. "Low Tire Pressure Warning Control Unit"</a>
Low tire pressure warning light	<a href="#">WT-7. "Low Tire Pressure Warning Light"</a>
BCM	<a href="#">BCS-6. "BODY CONTROL SYSTEM : System Description"</a>
ABS actuator and electric unit (control unit)	<a href="#">BRC-12. "VDC/TCS/ABS : System Description"</a>

### Low Tire Pressure Warning Control Unit

INFOID:000000006881092


- The low tire pressure warning control unit (1) receives the tire pressure signal as an input from the tire pressure receiver. The tire pressure receiver receives the tire pressure signal from the transmitter in each wheel through a radio signal.
- The low tire pressure warning control unit uses CAN communication to illuminate the low tire pressure warning light in the combination meter when low tire pressure or a system fault exists.
- The low tire pressure warning control unit has a self diagnosis function that allows it to detect system malfunctions.



### Transmitter

INFOID:000000006881093

A transmitter (1) integrated with an air valve is installed in each wheel (2), and transmits the detected air pressure in the form of a radio signal to the tire pressure receivers.




# COMPONENT PARTS

## < SYSTEM DESCRIPTION >

### Tire Pressure Receiver

INFOID:000000006881094

The front tire pressure receiver (1) and rear tire pressure receiver (2) receive the air pressure through a radio signal from the transmitter at each wheel, and send the air pressure signal to the low tire pressure warning control unit.




ALEIA00682Z

INFOID:000000006881095

### Low Tire Pressure Warning Light

The combination meter receives tire pressure status from the low tire pressure warning control unit using CAN communication. When a low tire pressure condition is sensed by the low tire pressure warning control unit, the combination meter low tire pressure warning light is activated.

A "CHECK TIRE" pressure warning will also be displayed in the vehicle information display. Refer to the Owner's Manual for additional information.



NNEIC00012Z

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# SYSTEM

< SYSTEM DESCRIPTION >


## SYSTEM

### System Description

INFOID:000000006881096

- The low tire pressure warning control unit has pressure judgment and trouble diagnosis functions. When the low tire pressure warning control unit detects low inflation pressure or another unusual symptom, the low tire pressure warning lamp in the combination meter is illuminated.
- If the tire pressure is less than the specified value, the low tire pressure warning lamp illuminates.
- The TPMS (Tire Pressure Monitoring System) is activated when vehicle speed is 40 km/h (25 MPH) or more.
- The tire pressure information for each wheel is displayed in the vehicle information display.

### SYSTEM DIAGRAM



### INPUT/OUTPUT SIGNAL

Component	Signal Description
Low tire pressure warning control unit	Transmits the low tire pressure warning lamp signal via CAN communication to combination meter.
BCM	Receives the hazard request signal via CAN communication from the low tire pressure warning control unit.
ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal (ABS) via CAN communication to low tire pressure warning control unit.

### LOW TIRE PRESSURE WARNING LAMP CONTROL CONDITION

Low tire pressure warning control unit uses CAN communication to illuminate the low tire pressure warning lamp in the combination meter.

Condition	Low tire pressure warning lamp
Ignition switch: OFF	OFF
Ignition switch: ON (System normal)	Warning lamp turns on for 1second, then turns OFF.
When tire pressure is low	ON
Tire pressure monitoring system malfunction	Warning lamp blinks 1 minute, then turns ON.
When performing transmitter wake-up operation	Refer to <a href="#">WT-28, "Work Procedure"</a> .

### HAZARD WARNING LAMP CONTROL CONDITION

The low tire pressure warning control unit transmits a hazard request signal to the BCM. The BCM flashes the hazard warning lamps under the following conditions:

- When the transmitter wake-up procedure for all wheels has been completed. Refer to [WT-28, "Work Procedure"](#).
- When ID registration of each wheel has been completed. Refer to [WT-29, "Work Procedure"](#).



# DIAGNOSIS SYSTEM (LOW TIRE PRESSURE WARNING CONTROL UNIT)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (LOW TIRE PRESSURE WARNING CONTROL UNIT)

### CONSULT Function

INFOID:000000006881098

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

#### FUNCTION

CONSULT can display each diagnostic item using the following direct diagnostic modes.

Direct Diagnostic Mode	Description
Ecu Identification	The low tire pressure warning control unit part number is displayed.
Self Diagnostic Result	The low tire pressure warning control unit self diagnostic results are displayed.
Data Monitor	The low tire pressure warning control unit input/output data is displayed in real time.
Active Test	The low tire pressure warning control unit activates outputs to test components.
Work support	The settings for low tire pressure warning control unit functions can be changed.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

#### ECU IDENTIFICATION

Part number of low tire pressure warning control unit is displayed.

#### SELF DIAGNOSTIC RESULT

Refer to [WT-18, "DTC Index"](#).

#### DATA MONITOR

Monitor Item [Unit]	Description
VHCL SPEED SE [km/h or mph]	Indicates vehicle speed signal received from ABS actuator and electric unit (control unit) on CAN communication line.
AIR PRESS FL [kPa, kg/cm <sup>2</sup> or Psi]	Indicates air pressure of front LH tire.
AIR PRESS FR [kPa, kg/cm <sup>2</sup> or Psi]	Indicates air pressure of front RH tire.
AIR PRESS RR [kPa, kg/cm <sup>2</sup> or Psi]	Indicates air pressure of rear RH tire.
AIR PRESS RL [kPa, kg/cm <sup>2</sup> or Psi]	Indicates air pressure of rear LH tire.
ID REGST FL1 [Done/Yet]	Indicates ID registration status of front LH transmitter.
ID REGST FR1 [Done/Yet]	Indicates ID registration status of front RH transmitter.
ID REGST RR1 [Done/Yet]	Indicates ID registration status of rear RH transmitter.
ID REGST RL1 [Done/Yet]	Indicates ID registration status of rear LH transmitter.
WARNING LAMP [Off/On]	Indicates condition of low tire pressure warning light in combination meter.
BUZZER [Off/On]	Indicates condition of buzzer in combination meter.

#### ACTIVE TEST

Test Item	Description
BUZZER	This test is able to check buzzer operation [Off/On].
WARN LAMP	This test is able to check low tire pressure warning light operation [Off/On].

#### WORK SUPPORT

# DIAGNOSIS SYSTEM (LOW TIRE PRESSURE WARNING CONTROL UNIT)

< SYSTEM DESCRIPTION >

Support Item	Description
ID REGIST	Refer to <a href="#">WT-29. "Description"</a> .

CAN DIAG SUPPORT MNTR

Refer to [LAN-15. "Trouble Diagnosis Flow Chart"](#).

# DIAGNOSIS SYSTEM (LOW TIRE PRESSURE WARNING CONTROL UNIT)

< SYSTEM DESCRIPTION >

Self Diagnosis Without CONSULT

INFOID:000000006881134

A

B

C

D

**WT**

F

G

H

I

J

K

L

M
















N

O

P


# DIAGNOSIS SYSTEM (LOW TIRE PRESSURE WARNING CONTROL UNIT)

## < SYSTEM DESCRIPTION >

Diagnosis items	Symptom (Ignition switch ON)	Low tire pressure warning lamp	Cause	Action
Low tire pressure warning lamp	The low tire pressure warning lamp illuminates for 1 second, then turns OFF.	  ON 1 sec > stays OFF <small>SEIA0592E</small>	Wake-up operation for all transmitters at wheels is completed.	No procedure. (No system malfunctions)
	The low tire pressure warning lamp repeats blinking ON for 2 seconds and OFF for 0.2 seconds.	 Blinks:  ON 2 sec > OFF 0.2 sec <small>SEIA0593E</small>	Wake-up operation for all transmitters at wheels is not completed.	Perform the wake-up operation for all transmitters at wheels. Refer to <a href="#">WT-28, "Work Procedure"</a> .
	The low tire pressure warning lamp blinks once.	 Blinks 1 time ON 0.3 sec > OFF 1.0 sec <small>JFEIC0090GB</small>	The front LH wheel transmitter is not activated.	Perform the wake-up operation for the transmitter at front LH wheel. Refer to <a href="#">WT-28, "Work Procedure"</a> .
	The low tire pressure warning lamp repeats blinking twice.	  Blinks 2 times ON 0.3 sec > OFF 0.3 sec <small>SEIA0595E</small>	The front right wheel transmitter is not activated.	Perform the wake-up operation for the transmitter at front right wheel. Refer to <a href="#">WT-28, "Work Procedure"</a> .
	The low tire pressure warning lamp repeats blinking for 3 times.	   Blinks 3 times ON 0.3 sec > OFF 0.3 sec <small>SEIA0596E</small>	The rear right wheel transmitter is not activated.	Perform the wake-up operation for the transmitter at rear right wheel. Refer to <a href="#">WT-28, "Work Procedure"</a> .
	The low tire pressure warning lamp repeats blinking for 4 times.	    Blinks 4 times ON 0.3 sec > OFF 0.3 sec <small>SEIA0597E</small>	The rear LH wheel transmitter is not activated.	Perform the wake-up operation for the transmitter at rear LH wheel. Refer to <a href="#">WT-28, "Work Procedure"</a> .
	The low tire pressure warning lamp turns ON and stays illuminated.	 Comes ON and stays ON <small>SEIA0598E</small>	Low tire pressure	Check the tire pressure for all wheels and adjust to the specified value. Refer to <a href="#">WT-70, "Tire"</a> .

# DIAGNOSIS SYSTEM (LOW TIRE PRESSURE WARNING CONTROL UNIT)

## < SYSTEM DESCRIPTION >

Diagnosis items	Symptom (Ignition switch ON)	Low tire pressure warning lamp	Cause	Action
Low tire pressure warning lamp	The low tire pressure warning lamp repeats blinking at 0.5-second intervals for 1 minute, and then stays illuminated.	 <p>Blinks 1 min</p> <p>ON 0.5 sec &gt; OFF 0.5 sec and stays ON</p> <p>SE1A078EE</p>	The combination meter fuse is open or removed (or pulled out).	Check and install the combination meter fuse. If necessary, replace the fuse.
			The low tire pressure warning control unit harness connector is removed.	Check the connection conditions of the low tire pressure warning control unit harness connector, and repair if necessary.
			Tire Pressure Monitoring System (TPMS) malfunction.	<ul style="list-style-type: none"> <li>Perform self-diagnosis.</li> <li>If necessary, perform transmitter ID registration. Refer to <a href="#">WT-29</a>, "<a href="#">Work Procedure</a>".</li> </ul>
Hazard warning lamp	The hazard warning lamp does not blink twice when the transmitter is activated.	—	The transmitter activation tool does not activate.	Replace the battery in the transmitter activation tool.
			The ignition switch is OFF when the transmitter wake-up operation is performed.	Turn the ignition switch ON when performing the transmitter wake-up operation.
			The transmitter activation tool is not used in the correct position.	Operate the transmitter activation tool in the correct position when performing the wake-up operation.
			The transmitter is already awake.	No procedure.

### NOTE:

If transmitter wake-up operation is not completed for two or more transmitters, the applicable low tire pressure warning lamp blinking patterns are displayed continuously.

(Example: Blinks once/OFF/blinks 3 times = Wake-up operation is not completed at the front LH wheel and rear RH wheel transmitters.)

# LOW TIRE PRESSURE WARNING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### LOW TIRE PRESSURE WARNING CONTROL UNIT

#### Reference Value

INFOID:000000006881099

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.


- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

#### VALUES ON THE DIAGNOSIS TOOL

Monitor item	Condition	Value/Status
VHCL SPEED SE	While driving	Equivalent to speedometer reading
AIR PRESS FL	Front left tire air pressure value*	kPa, kg/cm <sup>2</sup> , psi
AIR PRESS FR	Front right tire air pressure value*	kPa, kg/cm <sup>2</sup> , psi
AIR PRESS RL	Rear left tire air pressure value*	kPa, kg/cm <sup>2</sup> , psi
AIR PRESS RR	Rear right tire air pressure value*	kPa, kg/cm <sup>2</sup> , psi
ID REGST FL1	Front LH transmitter ID is registered	Done
	Front LH transmitter ID is not registered	Yet
ID REGST FR1	Front RH transmitter ID is registered	Done
	Front RH transmitter ID is not registered	Yet
ID REGST RR1	Rear RH transmitter ID is registered	Done
	Rear RH transmitter ID is not registered	Yet
ID REGST RL1	Rear LH transmitter ID is registered	Done
	Rear LH transmitter ID is not registered	Yet
BUZZER	Buzzer in combination meter OFF	Off
	Buzzer in combination meter ON	On
WARNING LAMP	Low tire pressure warning light ON	On
	Low tire pressure warning light OFF	Off

\*: Vehicle must be driven at 40 km/h (25 mph) or more for 10 minutes.





#### TERMINAL LAYOUT



#### PHYSICAL VALUES

# LOW TIRE PRESSURE WARNING CONTROL UNIT





< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
1 (P)	—	CAN-L	Input/ Output	—	—
2 (L)	—	CAN-H	Input/ Output	—	—
3 (Y)	Ground	Tire pressure receiver rear RH signal	Input	Ignition switch ON	Standby status  Approx. 4.5 V
				Ignition switch ON	When signal is received  Approx. 4.5 V
4 (L)	Ground	Tire pressure receiver rear LH signal	Input	Ignition switch ON	Standby status  Approx. 4.5 V
				Ignition switch ON	When signal is received  Approx. 4.5 V

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# LOW TIRE PRESSURE WARNING CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)	Description		Condition	Value (Approx.)	
	Signal name	Input/ Output			
5 (R)	Ground	Tire pressure receiver front RH signal	Input	Ignition switch ON	Standby status  Approx. 4.5 V
					When signal is received  Approx. 4.5 V
6 (W)	Ground	Tire pressure receiver front LH signal	Input	Ignition switch ON	Standby status  Approx. 4.5 V
					When signal is received  Approx. 4.5 V
7 (SB)	Ground	Tire pressure receiver rear RH power supply	Output	Ignition switch ON	Approx. 9 - 16 V
				Ignition switch OFF	0 V
8 (GR)	Ground	Tire pressure receiver rear LH power supply	Output	Ignition switch ON	Approx. 9 - 16 V
				Ignition switch OFF	0 V
9 (BR)	Ground	Tire pressure receiver front RH power supply	Output	Ignition switch ON	Approx. 9 - 16 V
				Ignition switch OFF	0 V
10 (LG)	Ground	Tire pressure receiver front LH power supply	Output	Ignition switch ON	Approx. 9 - 16 V
				Ignition switch OFF	0 V
15 (R)	Ground	Power supply	Input	Ignition switch ON	Battery voltage
				Ignition switch OFF	0 V
19 (R)	Ground	Tire pressure receiver rear RH signal (sensitivity)	Input	Ignition switch ON	Approx. 0.7 V
				Ignition switch OFF	0 V
20 (P)	Ground	Tire pressure receiver rear LH signal (sensitivity)	Input	Ignition switch ON	Approx. 0.7 V
				Ignition switch OFF	0 V



# LOW TIRE PRESSURE WARNING CONTROL UNIT

## < ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
		Signal name	Input/ Output		
21 (GR)	Ground	Tire pressure receiver front RH signal (sensitivity)	Input	Ignition switch ON	Approx. 0.7 V
				Ignition switch OFF	0 V
22 (O)	Ground	Tire pressure receiver front LH signal (sensitivity)	Input	Ignition switch ON	Approx. 0.7 V
				Ignition switch OFF	0 V
23 (LG)	Ground	Tire pressure receiver rear RH ground	Input	Always	0 V
24 (L)	Ground	Tire pressure receiver rear LH ground	Input	Always	0 V
25 (W)	Ground	Tire pressure receiver front RH ground	Input	Always	0 V
26 (G)	Ground	Tire pressure receiver front LH ground	Input	Always	0 V
30 (O)	Ground	Hazard	Output	When transmitter wake-up procedure for all wheels or ID registration of each wheel has been completed.	12 V
32 (B)	Ground	Ground	—	Always	0 V

## DTC Inspection Priority Chart

INFOID:000000006881100

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> <li>• U1000 CAN COMM CIRCUIT</li> <li>• U1010 CONTROL UNIT (CAN)</li> </ul>
2	<ul style="list-style-type: none"> <li>• C1704 LOW PRESSURE FL</li> <li>• C1705 LOW PRESSURE FR</li> <li>• C1706 LOW PRESSURE RR</li> <li>• C1707 LOW PRESSURE RL</li> </ul>
3	<ul style="list-style-type: none"> <li>• C1755 PR RECEIV COND FL</li> <li>• C1756 PR RECEIV COND FR</li> <li>• C1757 PR RECEIV COND RR</li> <li>• C1758 PR RECEIV COND RL</li> </ul>
4	<ul style="list-style-type: none"> <li>• C1708 [NO DATA] FL</li> <li>• C1709 [NO DATA] FR</li> <li>• C1710 [NO DATA] RR</li> <li>• C1711 [NO DATA] RL</li> </ul>
5	<ul style="list-style-type: none"> <li>• C1716 [PRESSDATA ERR] FL</li> <li>• C1717 [PRESSDATA ERR] FR</li> <li>• C1718 [PRESSDATA ERR] RR</li> <li>• C1719 [PRESSDATA ERR] RL</li> </ul>
7	<ul style="list-style-type: none"> <li>• C1728 RECEIVER ID NO REG</li> </ul>
8	<ul style="list-style-type: none"> <li>• C1729 VHCL SPEED SIG ERR</li> </ul>
9	<ul style="list-style-type: none"> <li>• C1750 [RECEIVER ERR] FL</li> <li>• C1751 [RECEIVER ERR] FR</li> <li>• C1752 [RECEIVER ERR] RR</li> <li>• C1753 [RECEIVER ERR] RL</li> </ul>
10	<ul style="list-style-type: none"> <li>• C1754 CONT UNIT (EEPROM)</li> </ul>

# LOW TIRE PRESSURE WARNING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

## DTC Index

INFOID:000000006881101

DTC	Items (CONSULT screen terms)	Reference
C1704	LOW PRESSURE FL	<a href="#">WT-31, "DTC Logic"</a>
C1705	LOW PRESSURE FR	
C1706	LOW PRESSURE RR	
C1707	LOW PRESSURE RL	
C1708	[NO DATA] FL	<a href="#">WT-33, "DTC Logic"</a>
C1709	[NO DATA] FR	
C1710	[NO DATA] RR	
C1711	[NO DATA] RL	
C1716	[PRESSDATA ERR] FL	<a href="#">WT-37, "DTC Logic"</a>
C1717	[PRESSDATA ERR] FR	
C1718	[PRESSDATA ERR] RR	
C1719	[PRESSDATA ERR] RL	
C1728	RECEIVER ID NO REG	<a href="#">WT-39, "DTC Logic"</a>
C1729	VHCL SPEED SIG ERR	<a href="#">WT-42, "DTC Logic"</a>
C1750	[RECEIVER ERR] FL	<a href="#">WT-44, "DTC Logic"</a>
C1751	[RECEIVER ERR] FR	
C1752	[RECEIVER ERR] RR	
C1753	[RECEIVER ERR] RL	
C1754	CONT UNIT (EEPROM)	<a href="#">WT-47, "DTC Logic"</a>
C1755	PR RECEIV COND FL	<a href="#">WT-50, "DTC Logic"</a>
C1756	PR RECEIV COND FR	
C1757	PR RECEIV COND RR	
C1758	PR RECEIV COND RL	
U1000	CAN COMM CIRCUIT	<a href="#">WT-52, "DTC Logic"</a>
U1010	CONTROL UNIT (CAN)	<a href="#">WT-53, "DTC Logic"</a>

**NOTE:**

If more than one DTC is displayed, refer to [WT-17, "DTC Inspection Priority Chart"](#).

# TIRE PRESSURE MONITORING SYSTEM

< WIRING DIAGRAM >


## WIRING DIAGRAM

### TIRE PRESSURE MONITORING SYSTEM

Wiring Diagram

INFOID:000000006749875

#### TIRE PRESSURE MONITORING SYSTEM



ABEWA0061GB


A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TIRE PRESSURE MONITORING SYSTEM

< WIRING DIAGRAM >


## TIRE PRESSURE MONITORING SYSTEM CONNECTORS

Connector No.	M14
Connector Name	JOINT CONNECTOR-M04
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
7	R	-
8	R	-
9	R	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
29	O	HAZARD SW

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
60	Y	FLASHER OUTPUT (LEFT)
61	G	FLASHER OUTPUT (RIGHT)

Connector No.	M23
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	Y	BATTERY
31	B	GND (POWER)
32	R	RUN START

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	CAN-H
13	P	CAN-L
21	B	GND (ILL)

# TIRE PRESSURE MONITORING SYSTEM

< WIRING DIAGRAM >


Connector No.	M39
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1Q	R	-
4Q	Y	-

Terminal No.	Color of Wire	Signal Name
51G	W	-
52G	LG	-
53G	Y	-
54G	SB	-
55G	L	-
56G	P	-
57G	R	-
58G	BR	-
62G	O	-
63G	G	-
64G	R	-
65G	LG	-
66G	P	-
67G	L	-
68G	GR	-
69G	W	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M45
Connector Name	JOINT CONNECTOR-M01
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
4	L	-
5	L	-
13	P	-
14	P	-

ABE1A0110GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WT


# TIRE PRESSURE MONITORING SYSTEM

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
21	GR	RSSI FR
22	O	RSSI FL
23	LG	GND RR
24	L	GND RL
25	W	GND FR
26	G	GND FL
27	-	-
28	-	-
29	-	-
30	O	HAZARD
31	-	-
32	B	GND


Terminal No.	Color of Wire	Signal Name
7	SB	VCC RR
8	GR	VCC RL
9	BR	VCC FR
10	LG	VCC FL
11	-	-
12	-	-
13	-	-
14	-	-
15	R	IGN
16	-	-
17	-	-
18	-	-
19	R	RSSI RR
20	P	RSSI RL

Connector No.	M90
Connector Name	LOW TIRE PRESSURE WARNING CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	CAN-L
2	L	CAN-H
3	Y	DATA RR
4	L	DATA RL
5	R	DATA FR
6	W	DATA FL


Connector No.	E43
Connector Name	TIRE PRESSURE RECEIVER FRONT LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	VCC
2	O	RSSI
3	W	SIG
4	G	GND

Terminal No.	Color of Wire	Signal Name
32C	GR	-
33C	L	-
34C	L	-
35C	P	-
38C	GR	-
39C	R	-
40C	SB	-
41C	Y	-

Connector No.	E41
Connector Name	WIRE TO WIRE
Connector Color	GRAY




ABEIA01116B

# TIRE PRESSURE MONITORING SYSTEM


< WIRING DIAGRAM >

Connector No.	E60
Connector Name	TIRE PRESSURE RECEIVER FRONT RH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	BR	VCC
2	GR	RSSI
3	R	SIG
4	W	GND

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
51G	W	-
52G	LG	-
53G	Y	-
54G	SB	-
55G	L	-
56G	P	-
57G	R	-
58G	BR	-
62G	O	-
63G	G	-
64G	R	-
65G	GR	-
66G	P	-
67G	L	-
68G	GR	-
69G	W	-

Connector No.	C1
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
32C	GR	-
33C	L	-
34C	L	-
35C	P	-
38C	GR	-
39C	R	-
40C	SB	-
41C	Y	-

Connector No.	C16
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	SB	-
3	R	-
4	Y	-
5	L	-
6	GR	-
7	P	-
8	L	-

ABEIA0112GB


A B C D E F G H I J K L M N O P

WT

# TIRE PRESSURE MONITORING SYSTEM


< WIRING DIAGRAM >

Connector No.	C110
Connector Name	TIRE PRESSURE RECEIVER REAR RH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	SB	VCC
2	R	RSSI
3	Y	SIG
4	GR	GND

Connector No.	C109
Connector Name	TIRE PRESSURE RECEIVER REAR LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	GR	VCC
2	P	RSSI
3	L	SIG
4	L	GND

Connector No.	C108
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	SB	-
3	R	-
4	Y	-
5	L	-
6	GR	-
7	P	-
8	L	-

ABEIA0115GB



# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

#### Work Flow

INFOID:000000006881102

#### 1. COLLECT INFORMATION FROM CUSTOMER

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

#### 2. TIRE PRESSURE INSPECTION

Check the tire pressure for all wheels. Refer to [WT-70, "Tire"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace tire(s) or wheel(s).

#### 3. CHECK LOW TIRE PRESSURE WARNING LIGHT

Check that the low tire pressure warning light illuminates for approximately 1 second after the ignition switch is turned ON, then turns OFF.

Does the low tire pressure warning light turn OFF?

YES >> GO TO 4.

NO >> GO TO 5.

#### 4. CHECK VEHICLE INFORMATION DISPLAY TIRE PRESSURE INFORMATION

Check that the tire pressure displayed in vehicle information display matches tire pressure inspection from step 2.

Does the vehicle information display match tire pressure inspection?

YES >> Inspection End.

NO >> Refer to [MWI-13, "INFORMATION DISPLAY : System Description"](#).

#### 5. CHECK VEHICLE INFORMATION DISPLAY PRESSURE WARNING

Check the vehicle information display for a "CHECK TIRE" pressure warning.

Is "CHECK TIRE" displayed in the vehicle information display?

YES >> GO TO 7.

NO >> GO TO 6.

#### 6. CHECK VEHICLE INFORMATION DISPLAY ERROR WARNING

Check the vehicle information display for a "TPMS ERROR" warning.

Is "TPMS ERROR" displayed in the vehicle information display?

YES >> GO TO 7.

NO >> GO TO 8.

#### 7. PERFORM SELF DIAGNOSTIC RESULT

Perform self diagnostic result. Refer to [WT-9, "CONSULT Function"](#).

Are any DTCs displayed?

YES >> Refer to [WT-18, "DTC Index"](#). If two or more DTCs are displayed, refer to [WT-17, "DTC Inspection Priority Chart"](#).

NO >> GO TO 8.

#### 8. PERFORM DIAGNOSIS APPLICABLE TO THE SYMPTOM

Perform diagnosis applicable to the symptom. Refer to [WT-55, "Symptom Table"](#).

>> GO TO 9.

## DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

---

### 9.FINAL CHECK

---

Perform self diagnostic result again, and check that the malfunction is repaired. After checking, erase the self diagnosis memory. Refer to [WT-9, "CONSULT Function"](#).

>> Inspection End.

# ADDITIONAL SERVICE WHEN REPLACING LOW TIRE PRESSURE WARNING CONTROL UNIT

< BASIC INSPECTION >

## ADDITIONAL SERVICE WHEN REPLACING LOW TIRE PRESSURE WARNING CONTROL UNIT

### Description

INFOID:000000006881103

When replacing low tire pressure warning control unit, transmitter ID registration is required.

### Work Procedure

INFOID:000000006881104

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### 1.PERFORM TRANSMITTER ID REGISTRATION

Perform transmitter ID registration.

>> Refer to [WT-29, "Work Procedure"](#).

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TRANSMITTER WAKE UP OPERATION

< BASIC INSPECTION >

## TRANSMITTER WAKE UP OPERATION

### Description

INFOID:000000006881105

When replacing transmitter, transmitter wake-up operation is required.

### Work Procedure

INFOID:000000006881106

#### NOTE:


The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs











1. Turn the ignition switch ON.
2. Press transmitter activation tool (J-45295) (1) against side of tire at location closest to transmitter.
3. Wait until indicator lamp turns OFF (approximately 5 seconds).

#### NOTE:

Perform wake-up procedure starting from front left wheel, then repeat procedure for front right wheel, rear right wheel, and rear left wheel.



4. Check that low tire pressure warning light blinks in pattern in following illustration. The pattern indicates that transmitter wake-up procedure for the wheel is completed.

Low tire pressure warning lamp blinking timing		Activation tire position
ON  OFF 	a : 0.3 sec. b : 1.0 sec.	Front LH
ON  OFF 	a : 0.3 sec. b : 1.0 sec.	Front RH
ON  OFF 	a : 0.3 sec. b : 1.0 sec.	Rear RH
ON  OFF 	a : 0.3 sec. b : 1.0 sec.	Rear LH
ON  OFF 	a : 2 sec. b : 0.2 sec.	All tires

JPEIC0089GB

5. Check that hazard warning lamps blink twice when transmitter wake-up procedure for all wheels is completed.
6. Check that low tire pressure warning light turns OFF, after transmitter wake-up procedure is completed for all wheels.
7. Perform the transmitter ID registration procedure. Refer to [WT-29, "Work Procedure"](#).

# ID REGISTRATION

< BASIC INSPECTION >

## ID REGISTRATION

### Description

INFOID:000000006881107

When replacing or rotating wheels, replacing transmitter or replacing low tire pressure warning control unit, transmitter ID registration is required.

### Work Procedure

INFOID:000000006881108

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs


#### WITH TRANSMITTER ACTIVATION TOOL

##### With CONSULT

1. Turn ignition switch ON.
2. On "WORK SUPPORT" select "ID REGIST".
3. Press transmitter activation tool (J-45295) (1) against side of tire at location closest to transmitter.
4. Wait until indicator lamp turns OFF (approximately 5 seconds).

#### NOTE:

Perform ID registration procedure starting from front left wheel, then repeat procedure for front right wheel, rear right wheel, and rear left wheel.



5. When ID registration is completed, check the following pattern at each wheel.

Sequence	ID registration position	Hazard warning lamp	CONSULT
1	Front LH	2 blinks	"Red" ↓ "Green"
2	Front RH		
3	Rear RH		
4	Rear LH		

6. After ID registration procedure for all wheels is completed, press "End" to end ID registration, and check that ID registration for all wheels is completed.

#### WITHOUT TRANSMITTER ACTIVATION TOOL


After rotating the tires, the TPMS sensor position needs to be relearned.

1. Decrease air pressure for at least 30 seconds continuously for each tire [more than 10 psi (34.5 kPa) within 30 seconds] to place the TPMS system into relearn mode for 30 minutes.
2. Adjust the tire pressure to the levels shown in the illustration.
3. On the combination meter, start the relearn procedure using the INFO knob as follows: SETTINGS→TPMS MENU→RE-LEARN→CONFIRM→LEARNING.  
The TPMS warning lamp flashes continuously when the system is relearning the tire positions.

#### NOTE:

The relearn procedure can be cancelled by placing the ignition switch in the OFF position or by driving the vehicle over 3 mph (5 km/h).

4. When the relearn procedure is successfully completed:



# ID REGISTRATION

## < BASIC INSPECTION >

---

- the message "RELEARN OK" is displayed in the combination meter.
  - the hazard lamps flash once.
  - the horn chirps once.
  - the combination meter chimes 3 times
5. Adjust the tire pressures to the cold tire pressure specification. Refer to [WT-70, "Tire"](#).
- If the tire pressures are correct, the TPMS warning lamp turns OFF.
  - If the tires are not inflated to the correct cold tire pressure, the TPMS warning lamp illuminates. Recheck the tire pressures and adjust as necessary.

If a different message is displayed or if the relearn procedure is stopped before completion, the new tire positions are not learned. Repeat the complete relearn procedure to reset the tire positions.

If "NOT READY→SEE MANUAL" is displayed, the tire sensors did not enter learn mode properly. Decrease the air pressure for at least 30 seconds continuously for each tire [more than 10 psi (34.5 kPa) within 30 seconds] to enter the proper mode. If the tire pressure cannot be reduced at least 10 psi (34.5 kPa) to adjust them to the relearn pressures, inflate the tires to at least 10 psi (34.5 kPa) above the specified pressures. Readjust the tire pressures according to the learn mode in step 2 and then select TPMS MENU→RE-LEARN→CONFIRM from the combination meter SETTINGS menu to complete the relearn procedure.

If "INCOMPLETE→SEE MANUAL" is displayed, the system could not detect the specific tire pressures shown in the learn mode diagram in step 2. Ensure each tire is set to its proper pressure according to the diagram and select TPMS MENU→RE-LEARN→CONFIRM from the combination meter SETTINGS menu to complete the relearn procedure.

If the relearn procedure does not work, check the following and retry the procedure:

- Devices which emit electronic interference should be turned OFF before starting the relearn procedure. The interference may prevent the system from learning the new tire positions. Turn OFF or remove sources of electrical interference. If necessary, move the vehicle to another location, then perform the complete relearn procedure to reset the tire positions.
- Use an air pump that is capable of inflating the tires to the required pressure specifications. The air pump must be capable of inflating a tire at least 10 psi (34.5 kPa) in 30 seconds.
- If the reset TPMS function is unintentionally selected, place the ignition switch in the OFF position, then to the ON position to end the relearn procedure.
- If the vehicle is not recognizing the new tire pressure levels, move the vehicle forward 40 inches (1 meter). Place the ignition switch in the OFF position, then to the ON position. Perform the relearn procedure beginning at step 1. Make sure that the tire pressures are increased or decreased at least 10 psi (34.5 kPa).

# C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

#### DTC Logic

INFOID:000000006881109

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible causes
C1704	LOW PRESSURE FL	Front LH wheel pressure drops to 283 kPa (2.89 kg/cm <sup>2</sup> , 41 psi) or less	Low tire pressure
C1705	LOW PRESSURE FR	Front RH wheel pressure drops to 283 kPa (2.89 kg/cm <sup>2</sup> , 41 psi) or less	
C1706	LOW PRESSURE RR	Rear RH wheel pressure drops to 431 kPa (4.39 kg/cm <sup>2</sup> , 62.5 psi) or less	
C1707	LOW PRESSURE RL	Rear LH wheel pressure drops to 431 kPa (4.39 kg/cm <sup>2</sup> , 62.5 psi) or less	

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM SELF DIAGNOSTIC RESULT

###### With CONSULT

1. Turn the ignition switch ON.
2. Check the tire pressure for all wheels and adjust to the specified value. Refer to [WT-70, "Tire"](#).
3. Perform "SELF DIAGNOSTIC RESULT".

Is DTC "C1704", "C1705", "C1706", or "C1707" detected?

- YES >> Proceed to [WT-31, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:000000006881110

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

##### 1. CHECK DATA MONITOR

###### With CONSULT

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Stop the vehicle.
3. On "DATA MONITOR" select "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".
4. Within 5 minutes after vehicle stopped, check that the tire pressures are within specification. Refer to [WT-70, "Tire"](#).

## C1704, C1705, C1706, C1707 LOW TIRE PRESSURE

< DTC/CIRCUIT DIAGNOSIS >

Monitor item	Displayed value
AIR PRESS FL	Approximately equal to the indication on tire gauge value for front LH tire
AIR PRESS FR	Approximately equal to the indication on tire gauge value for front RH tire
AIR PRESS RR	Approximately equal to the indication on tire gauge value for rear RH tire
AIR PRESS RL	Approximately equal to the indication on tire gauge value for rear LH tire

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace error-detected parts.



# C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

< DTC/CIRCUIT DIAGNOSIS >

## C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

### DTC Logic

INFOID:000000006881111

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1708	[NO DATA] FL	Tire pressure data signal from the front LH wheel transmitter cannot be detected.	<ul style="list-style-type: none"><li>• Harness or connector connection malfunction</li><li>• Transmitter ID registration incomplete</li><li>• Transmitter malfunction</li></ul>
C1709	[NO DATA] FR	Tire pressure data signal from the front RH wheel transmitter cannot be detected.	
C1710	[NO DATA] RR	Tire pressure data signal from the rear RH wheel transmitter cannot be detected.	
C1711	[NO DATA] RL	Tire pressure data signal from the rear LH wheel transmitter cannot be detected.	

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

##### With CONSULT

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Stop the vehicle.
3. Perform "SELF DIAGNOSTIC RESULT".

Is DTC "C1708", "C1709", "C1710" or "C1711" detected?

- YES >> Proceed to [WT-33, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000006881112

Regarding Wiring Diagram information, refer to [WT-19, "Wiring Diagram"](#).

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

#### 1. CHECK DATA MONITOR

##### With CONSULT

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Stop the vehicle.
3. On "DATA MONITOR" select "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".
4. Within 5 minutes after vehicle is stopped, read the values displayed on CONSULT.

Are all tire pressures displayed 0 kPa (psi)?

- YES >> GO TO 2.  
NO >> GO TO 8.

# C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

< DTC/CIRCUIT DIAGNOSIS >

## 2. CHECK RECEIVER POWER CIRCUIT CONTINUITY

1. Turn the ignition switch OFF.
2. Disconnect low tire pressure warning control unit and tire pressure receivers connectors.
3. Check continuity between low tire pressure warning control unit connector and tire pressure receiver connectors.

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M90	10	E43 (Front LH)	1	Yes
	9	E60 (Front RH)		
	8	C109 (Rear LH)		
	7	C110 (Rear RH)		

4. Check continuity between low tire pressure warning control unit connector and ground.

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M90	10	Ground	No
	9		
	8		
	7		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning harness or connector.

## 3. CHECK RECEIVER SIGNAL CIRCUIT

1. Check continuity between low tire pressure warning control unit connector and tire pressure receiver connectors.

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M90	6	E43 (Front LH)	2	Yes
	5	E60 (Front RH)		
	4	C109 (Rear LH)		
	3	C110 (Rear RH)		

2. Check the continuity between low tire pressure warning control unit connector and ground.

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M90	6	Ground	No
	5		
	4		
	3		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning harness or connector.

## 4. CHECK RECEIVER SIGNAL SENSITIVITY CIRCUIT

1. Check continuity between low tire pressure warning control unit connector and tire pressure receiver connectors.

# C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

## < DTC/CIRCUIT DIAGNOSIS >

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M90	22	E43 (Front LH)	2	Yes
	21	E60 (Front RH)		
	20	C109 (Rear LH)		
	19	C110 (Rear RH)		

2. Check the continuity between low tire pressure warning control unit harness connector and ground.

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M90	22	Ground	No
	21		
	20		
	19		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning harness or connector.

### 5. CHECK RECEIVER GROUND CIRCUIT

1. Check continuity between low tire pressure warning control unit connector and tire pressure receiver connectors.

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M90	26	E43 (Front LH)	4	Yes
	25	E60 (Front RH)		
	24	C109 (Rear LH)		
	23	C110 (Rear RH)		

2. Check the continuity between low tire pressure warning control unit harness connector and ground.

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M90	26	Ground	No
	25		
	24		
	23		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning harness or connector.

### 6. CHECK TIRE PRESSURE RECEIVER POWER SUPPLY CIRCUIT

1. Connect low tire pressure warning control unit harness connector.
2. Turn the ignition switch ON.
3. Check voltage between tire pressure receiver connector and ground.

# C1708, C1709, C1710, C1711 TRANSMITTER (NO DATA)

< DTC/CIRCUIT DIAGNOSIS >

Tire pressure receiver		—	Voltage
Connector	Terminal		
E43 (Front LH)	1	Ground	Approx. 9 - 16 V
E60 (Front RH)			
C109 (Rear LH)			
C110 (Rear RH)			

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace the low tire pressure warning control unit. Refer to [WT-65. "Removal and Installation"](#).

## 7. TIRE PRESSURE RECEIVER SIGNAL

Check tire pressure receiver signal. Refer to [WT-44. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace error-detected parts.

## 8. TRANSMITTER ID REGISTRATION

Perform transmitter ID registration. Refer to [WT-29. "Work Procedure"](#).

Is transmitter ID registration completed?

YES >> GO TO 9.

NO >> Replace applicable transmitter. Refer to [WT-66. "Removal and Installation"](#).

## 9. CHECK TIRE PRESSURE SIGNAL

### With CONSULT

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Stop the vehicle.
3. On "DATA MONITOR" select "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".
4. Within 5 minutes after vehicle stopped, check that the tire pressures are within specification. Refer to [WT-70. "Tire"](#).

Monitor item	Displayed value
AIR PRESS FL	Approximately equal to the indication on tire gauge value for front LH tire
AIR PRESS FR	Approximately equal to the indication on tire gauge value for front RH tire
AIR PRESS RR	Approximately equal to the indication on tire gauge value for rear RH tire
AIR PRESS RL	Approximately equal to the indication on tire gauge value for rear LH tire

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the low tire pressure warning control unit. Refer to [WT-65. "Removal and Installation"](#).

# C1716, C1717, C1718, C1719 TRANSMITTER (PRESSURE DATA)

< DTC/CIRCUIT DIAGNOSIS >

## C1716, C1717, C1718, C1719 TRANSMITTER (PRESSURE DATA)

### DTC Logic

INFOID:000000006881113

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1716	[PRESSDATA ERR] FL	Malfunction in the tire pressure data* from the front LH wheel transmitter.	• Transmitter ID registration incomplete • Transmitter malfunction
C1717	[PRESSDATA ERR] FR	Malfunction in the tire pressure data* from the front RH wheel transmitter.	
C1718	[PRESSDATA ERR] RR	Malfunction in the tire pressure data* from the rear RH wheel transmitter.	
C1719	[PRESSDATA ERR] RL	Malfunction in the tire pressure data* from the rear LH wheel transmitter.	

\*: In this case the low tire pressure warning control unit judges that the tire pressure is 879.08 kPa (8.96 kg/cm<sup>2</sup>, 127.5 psi).

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

##### With CONSULT

1. Turn the ignition switch ON.
2. Check the tire pressure for all wheels and adjust to the specified value. Refer to [WT-70, "Tire"](#).
3. Perform "SELF DIAGNOSTIC RESULT".

Is DTC "C1716", "C1717", "C1718", or "C1719" detected?

- YES >> Proceed to [WT-37, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000006881114

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

#### 1. CHECK TIRE PRESSURE

Check the air pressure of all wheels. Refer to pressure observed during "DTC CONFIRMATION PROCEDURE".

Is the inspection result normal?

- YES >> Replace the DTC-detected malfunctioning transmitter. Refer to [WT-66, "Removal and Installation"](#).  
NO >> GO TO 2.

#### 2. CHECK TIRE PRESSURE SIGNAL

##### With CONSULT

1. Perform transmitter ID registration for all wheels. Refer to [WT-29, "Work Procedure"](#).

## C1716, C1717, C1718, C1719 TRANSMITTER (PRESSURE DATA)

### < DTC/CIRCUIT DIAGNOSIS >

---

2. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
3. Stop the vehicle.
4. On "DATA MONITOR" select "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".
5. Within 5 minutes after vehicle is stopped, read the values displayed on CONSULT.

Are tire pressures displayed as 879.08 kPa (8.96 kg/cm<sup>2</sup>, 127.5 psi)?

- YES >> Replace transmitter that tire pressure is displayed as 879.08 kPa (8.96 kg/cm<sup>2</sup>, 127.5 psi). Refer to [WT-66, "Removal and Installation"](#).
- NO >> Perform "DTC CONFIRMATION PROCEDURE" again. Refer to [WT-37, "DTC Logic"](#).

# C1728 RECEIVER ID

< DTC/CIRCUIT DIAGNOSIS >

## C1728 RECEIVER ID

### DTC Logic

INFOID:000000006881115

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1728	RECEIVER ID NO REG	Receiver ID registration cannot be performed.	<ul style="list-style-type: none"><li>• Tire pressure receiver malfunction</li><li>• Low tire pressure warning control unit malfunction</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

##### With CONSULT

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Stop the vehicle.
3. Perform "SELF DIAGNOSTIC RESULT".

##### Is DTC "C1728" detected?

- YES >> Proceed to [WT-39, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000006881116

Regarding Wiring Diagram information, refer to [WT-19, "Wiring Diagram"](#).

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs


#### 1. CHECK TIRE PRESSURE RECEIVER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check the input signal waveform between the low tire pressure warning control unit connector and ground.


# C1728 RECEIVER ID

## < DTC/CIRCUIT DIAGNOSIS >

### STANDBY STATUS

Low tire pressure warning control unit		—	Value (Approx.)
Connector	Terminal		
M96	3	Ground	 <p style="text-align: center; margin-top: 5px;">Approx. 4.5 V</p>
	4		
	5		
	6		

### WHEN SIGNAL IS RECEIVED

Low tire pressure warning control unit		—	Value (Approx.)
Connector	Terminal		
M96	3	Ground	 <p style="text-align: center; margin-top: 5px;">Approx. 4.5 V</p>
	4		
	5		
	6		

### Is the inspection result normal?

YES >> Check connector for loose connection, then perform "DTC CONFIRMATION PROCEDURE" again. Refer to [WT-39, "DTC Logic"](#).

NO >> GO TO 2.

## 2. CHECK TIRE PRESSURE RECEIVER POWER SUPPLY CIRCUIT

1. Disconnect the tire pressure receiver connector.
2. Turn ignition switch ON.
3. Check voltage between tire pressure receiver connector and ground.

Tire pressure receiver		—	Voltage
Connector	Terminal		
E43 (Front LH)	1	Ground	Approx. 9 - 16 V
E60 (Front RH)			
C109 (Rear LH)			
C110 (Rear RH)			

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning harness or connector.

## 3. CHECK TIRE PRESSURE RECEIVER GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect low tire pressure warning control unit connector and tire pressure receiver connector.
3. Check continuity between low tire pressure warning control unit connector and tire pressure receiver connector.



# C1728 RECEIVER ID

## < DTC/CIRCUIT DIAGNOSIS >

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M90	26	E43 (Front LH)	4	Yes
	25	E60 (Front RH)		
	24	C109 (Rear LH)		
	23	C110 (Rear RH)		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning harness or connector.

### **4.**CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT CIRCUIT

Check the low tire pressure warning control unit circuit. Refer to [WT-47, "Diagnosis Procedure"](#).

Is the low tire pressure warning control unit circuit normal?

YES >> Replace the tire pressure receiver. Refer to [WT-68, "FRONT TIRE PRESSURE RECEIVER : Removal and Installation"](#) (Front), [WT-69, "REAR TIRE PRESSURE RECEIVER : Removal and Installation"](#) (Rear).

NO >> Repair or replace error-detected parts.

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# C1729 VEHICLE SPEED SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

## C1729 VEHICLE SPEED SIGNAL

### DTC Logic

INFOID:000000006881117

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1729	VHCL SPEED SIG ERR	Vehicle speed signal not detected.	<ul style="list-style-type: none"><li>• CAN communication malfunction</li><li>• Low tire pressure warning control unit malfunction</li><li>• ABS actuator and electric unit (control unit) malfunction</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

##### With CONSULT

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more without stopping.
2. Stop the vehicle.
3. Perform "SELF DIAGNOSTIC RESULT".

##### Is DTC "C1729" detected?

- YES >> Proceed to [WT-42, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000006881118

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

#### 1. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

##### With CONSULT

Perform "SELF DIAGNOSTIC RESULT" for "ABS". Refer to [BRC-32, "CONSULT Function \(ABS\)"](#).

##### Are any DTCs detected?

- YES >> Refer to [BRC-44, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. PERFORM LOW TIRE PRESSURE WARNING CONTROL UNIT SELF DIAGNOSTIC RESULT

##### With CONSULT

Perform "SELF DIAGNOSTIC RESULT" for "LOW TIRE PRESSURE WARNING CONTROL UNIT".

##### Is DTC "C1729" detected?

- YES >> Replace the low tire pressure warning control unit. Refer to [WT-65, "Removal and Installation"](#).  
NO >> GO TO 3.

#### 3. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT INPUT/OUTPUT SIGNAL

## C1729 VEHICLE SPEED SIGNAL

### < DTC/CIRCUIT DIAGNOSIS >

Check the low tire pressure warning control unit input/output signal values. Refer to [WT-14. "Reference Value"](#).

Is the inspection result normal?

YES >> Check pin terminal and connection of each harness connector for malfunctioning conditions.

NO >> Replace the low tire pressure warning control unit. Refer to [WT-65. "Removal and Installation"](#).

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

# C1750, C1751, C1752, C1753 RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

## C1750, C1751, C1752, C1753 RECEIVER

### DTC Logic

INFOID:000000006881119

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1750	[RECEIVER ERR] FL	The front LH tire pressure receiver does not receive a signal.	Tire pressure receiver malfunction
C1751	[RECEIVER ERR] FR	The front RH tire pressure receiver does not receive a signal.	
C1752	[RECEIVER ERR] RR	The rear RH tire pressure receiver does not receive a signal.	
C1753	[RECEIVER ERR] RL	The rear LH tire pressure receiver does not receive a signal.	

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

##### With CONSULT

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Stop the vehicle.
3. Perform "SELF DIAGNOSTIC RESULT".

Is DTC "C1750", "C1751", "C1752", or "C1753" detected?

- YES >> Proceed to [WT-44. "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000006881120

Regarding Wiring Diagram information, refer to [WT-19. "Wiring Diagram"](#).

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs


#### 1. CHECK TIRE PRESSURE RECEIVER INPUT SIGNAL

1. Turn ignition switch ON.
2. Check the input signal waveform between the low tire pressure warning control unit connector and ground.


# C1750, C1751, C1752, C1753 RECEIVER

## < DTC/CIRCUIT DIAGNOSIS >

### STANDBY STATUS

Low tire pressure warning control unit		—	Value (Approx.)
Connector	Terminal		
M90	3	Ground	 <p style="text-align: center;">Approx. 4.5 V</p>
	4		
	5		
	6		

### WHEN SIGNAL IS RECEIVED

Low tire pressure warning control unit		—	Value (Approx.)
Connector	Terminal		
M90	3	Ground	 <p style="text-align: center;">Approx. 4.5 V</p>
	4		
	5		
	6		

### Is the inspection result normal?

YES >> Check connector for loose connection, then perform "DTC CONFIRMATION PROCEDURE" again. Refer to [WT-44, "DTC Logic"](#).

NO >> GO TO 2.

## 2. CHECK TIRE PRESSURE RECEIVER POWER SUPPLY CIRCUIT

1. Disconnect tire pressure receiver connector.
2. Turn ignition switch ON.
3. Check voltage between tire pressure receiver connector and ground.

Tire pressure receiver		—	Voltage
Connector	Terminal		
E43 (Front LH)	1	Ground	Approx. 9 - 16 V
E60 (Front RH)			
C109 (Rear LH)			
C110 (Rear RH)			

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning harness or connector.

## 3. CHECK TIRE PRESSURE RECEIVER GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect low tire pressure warning control unit connector and tire pressure receiver connector.
3. Check continuity between low tire pressure warning control unit connector and tire pressure receiver connector.

## C1750, C1751, C1752, C1753 RECEIVER

### < DTC/CIRCUIT DIAGNOSIS >

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M90	26	E43 (Front LH)	4	Yes
	25	E60 (Front RH)		
	24	C109 (Rear LH)		
	23	C110 (Rear RH)		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning harness or connector.

#### **4.**CHECK FOR CHANGE TO THE TIRE PRESSURE RECEIVER INSTALLATION POSITION

##### **NOTE:**

Example: Front LH tire pressure receiver OK/NG judgment when DTC "C1750" is detected.

##### **ⓂWith CONSULT**

1. Exchange the positions of the front LH tire pressure receiver and the front RH tire pressure receiver.
2. Perform "DTC CONFIRMATION PROCEDURE" again. Refer to [WT-44, "DTC Logic"](#).

Is DTC "C1751" detected?

YES >> Replace the exchanged front RH tire pressure receiver.

NO >> Check the low tire pressure warning control unit circuit. Refer to [WT-47, "Diagnosis Procedure"](#).

# C1754 LOW TIRE PRESSURE WARNING CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

## C1754 LOW TIRE PRESSURE WARNING CONTROL UNIT

### DTC Logic

INFOID:000000006881121

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1754	CONT UNIT (EEPROM)	Memory (EEPROM) system malfunction is detected in the low tire pressure warning control unit	Low tire pressure warning control unit malfunction

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

##### With CONSULT

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more without stopping.
2. Stop the vehicle.
3. Perform "SELF DIAGNOSTIC RESULT".

##### Is DTC "C1754" detected?

- YES >> Proceed to [WT-47. "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000006881122

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

#### 1. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Perform the trouble diagnosis for power supply and ground circuit. Refer to [WT-54. "Diagnosis Procedure"](#).

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace error-detected parts.

#### 2. CHECK TIRE PRESSURE RECEIVER CIRCUIT

1. Disconnect the tire pressure receiver connector.
2. Check the continuity between the low tire pressure warning control unit connector and tire pressure receiver connector.

# C1754 LOW TIRE PRESSURE WARNING CONTROL UNIT

## < DTC/CIRCUIT DIAGNOSIS >

Low tire pressure warning control unit		Tire pressure receiver		Continuity
Connector	Terminal	Connector	Terminal	
M90	6	E43 (Front LH)	3	Yes
	22		2	
	10		1	
	26		4	
	5	E60 (Front RH)	3	
	21		2	
	9		1	
	25		4	
	4	C109 (Rear LH)	3	
	20		2	
	8		1	
	24		4	
	3	C110 (Rear RH)	3	
	19		2	
	7		1	
	23		4	

3. Check the continuity between the low tire pressure warning control unit connector and ground.

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M90	6	Ground	No
	22		
	10		
	26		
	5		
	21		
	9		
	25		
	4		
	20		
	8		
	24		
	3		
	19		
7			
23			

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning harness or connector.

### 3. PERFORM SELF DIAGNOSTIC RESULT AGAIN

#### With CONSULT

1. Check the tire pressure for all wheels and adjust to the specified value. Refer to [WT-70, "Tire"](#).
2. Perform transmitter ID registration for all wheels. Refer to [WT-29, "Work Procedure"](#).
3. Perform "SELF DIAGNOSTIC RESULT".



# C1754 LOW TIRE PRESSURE WARNING CONTROL UNIT

## < DTC/CIRCUIT DIAGNOSIS >

---

### Is DTC "C1754" detected?

- YES >> Replace the low tire pressure warning control unit. Refer to [WT-65, "Removal and Installation"](#).
- NO >> Check for looseness or damage at the harness connector pins of the low tire pressure warning control unit. Repair or replace if necessary.

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

# C1755, C1756, C1757, C1758 POOR RECEIVING CONDITIONS

< DTC/CIRCUIT DIAGNOSIS >

## C1755, C1756, C1757, C1758 POOR RECEIVING CONDITIONS

### DTC Logic

INFOID:000000006881123

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### DTC DETECTION LOGIC

#### NOTE:

If DTC C1755, C1756, C1757 or C1758 is detected along with C1708, C1709, C1710 or C1711, first diagnose C1755, C1756, C1757 or C1758.

DTC	Display Item	Malfunction detected condition	Possible causes
C1755	PR RECEIV COND FL	The data signal from the front LH wheel transmitter cannot be detected due to external electromagnetic interference for 10 minutes or more (DTC C1708 is displayed at the same time).	External electromagnetic interference
C1756	PR RECEIV COND FR	The data signal from the front RH wheel transmitter cannot be detected due to external electromagnetic interference for 10 minutes or more (DTC C1709 is displayed at the same time).	
C1757	PR RECEIV COND RR	The data signal from the rear RH wheel transmitter cannot be detected due to external electromagnetic interference for 10 minutes or more (DTC C1710 is displayed at the same time).	
C1758	PR RECEIV COND RL	The data signal from the rear LH wheel transmitter cannot be detected due to external electromagnetic interference for 10 minutes or more (DTC C1711 is displayed at the same time).	

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

##### With CONSULT

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Stop the vehicle.
3. Perform "SELF DIAGNOSTIC RESULT".

Is DTC "C1755", "C1756", "C1757", or "C1758" detected?

- YES >> Proceed to [WT-50, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000006881124

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

#### 1. TRANSMITTER ID REGISTRATION

Perform transmitter ID registration. Refer to [WT-29, "Work Procedure"](#).

Is transmitter ID registration completed?

- YES >> GO TO 2.  
NO >> Change the work location and perform ID registration again.

# C1755, C1756, C1757, C1758 POOR RECEIVING CONDITIONS

< DTC/CIRCUIT DIAGNOSIS >

## 2. CHECK TIRE PRESSURE SIGNAL

### With CONSULT

1. Drive for 3 minutes at a speed of 40 km/h (25 MPH) or more, then drive normally for 10 minutes.
2. Stop the vehicle.
3. On "DATA MONITOR" select "AIR PRESS FL", "AIR PRESS FR", "AIR PRESS RR" and "AIR PRESS RL".
4. Within 5 minutes after vehicle stopped, check that the tire pressures are within specification. Refer to [WT-70, "Tire"](#).

Monitor item	Displayed value
AIR PRESS FL	Approximately equal to the indication on tire gauge value for front LH tire
AIR PRESS FR	Approximately equal to the indication on tire gauge value for front RH tire
AIR PRESS RR	Approximately equal to the indication on tire gauge value for rear RH tire
AIR PRESS RL	Approximately equal to the indication on tire gauge value for rear LH tire

Is the inspection result normal?

YES >> GO TO 3.

NO >> Change the work location, then GO TO 1.

## 3. CHECK SELF DIAGNOSIS RESULT

### With CONSULT

1. Erase self-diagnosis memory for the low tire pressure warning control unit.
2. Turn ignition switch OFF, and wait for 10 seconds or more.
3. Perform "DTC CONFIRMATION PROCEDURE" again. Refer to [WT-50, "DTC Logic"](#).

Are DTC "C1755", "C1756", "C1757", or "C1758" and "C1708", "C1709", "C1710", or "C1711" detected?

YES >> Change the work location, then GO TO 1.

NO >> Check the input/output signal values. Refer to [WT-14, "Reference Value"](#).

# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## U1000 CAN COMM CIRCUIT

### Description

INFOID:000000006881125

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped on a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit communicates data but selectively reads required data only.

### DTC Logic

INFOID:000000006881126

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	Low tire pressure warning control unit is not communicating CAN communication signal for 2 seconds or more.	<ul style="list-style-type: none"><li>• CAN communication malfunction</li><li>• Malfunction of low tire pressure warning control unit</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

##### With CONSULT

1. Drive for several minutes at a speed of 40 km/h (25 MPH) or more.
2. Stop the vehicle.
3. Perform "SELF DIAGNOSTIC RESULT".

#### Is DTC "U1000" detected?

- YES >> Proceed to [WT-52. "Diagnosis Procedure"](#).
- NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000006881127

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

Proceed to [LAN-15. "Trouble Diagnosis Flow Chart"](#).

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

## U1010 CONTROL UNIT (CAN)

### Description

INFOID:000000006881128

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped on a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit communicates data but selectively reads required data only.

### DTC Logic

INFOID:000000006881129

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1010	CONTROL UNIT (CAN)	Detecting error during the initial diagnosis of CAN controller of low tire pressure warning control unit.	Malfunction of low tire pressure warning control unit

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

##### With CONSULT

1. Drive for several minutes at a speed of 40 km/h (25 MPH) or more.
2. Stop the vehicle.
3. Perform "SELF DIAGNOSTIC RESULT".

##### Is DTC "U1010" detected?

- YES >> Proceed to [WT-53, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000006881130

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

#### 1. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT

Check low tire pressure warning control unit connector for disconnection or deformation.

##### Is the inspection result normal?

- YES >> Replace low tire pressure warning control unit. Refer to [WT-65, "Removal and Installation"](#).  
NO >> Repair or replace error-detected parts.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT

### Diagnosis Procedure

INFOID:000000006881131

Regarding Wiring Diagram information, refer to [WT-19. "Wiring Diagram"](#).

### 1. CHECK FUSE/FUSIBLE LINK

1. Turn ignition switch OFF.
2. Check the 10 A fuse [No. 12 in fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace the fuse after repairing the affected circuit.

### 2. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT POWER SUPPLY CIRCUIT

1. Disconnect low tire pressure warning control unit connector.
2. Turn ignition switch ON.
3. Check voltage between low tire pressure warning control unit connector and ground.

Low tire pressure warning control unit		—	Voltage
Connector	Terminal		
M90	15	Ground	Battery voltage

4. Turn ignition switch OFF.
5. Check voltage between low tire pressure warning control unit connector and ground.

Low tire pressure warning control unit		—	Voltage
Connector	Terminal		
M90	15	Ground	0 V

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Check the following. If any items are damaged, repair or replace damaged parts.
- Harness for short or open between ignition switch and low tire pressure warning control unit harness connector
  - Battery voltage.

### 3. CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between low tire pressure warning control unit connector and ground.

Low tire pressure warning control unit		—	Continuity
Connector	Terminal		
M90	32	Ground	Yes

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair open circuit in harness or connectors.

# TPMS SYMPTOMS

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### TPMS SYMPTOMS

#### Symptom Table

INFOID:000000006915170

Symptom	Reference
Low tire pressure warning light does not turn ON.	<a href="#">WT-56</a>
Low tire pressure warning light does not turn OFF.	<a href="#">WT-57</a>
Low tire pressure warning light blinks.	<a href="#">WT-58</a>
Tire pressure information in vehicle information display does not exist.	<a href="#">WT-60</a>
ID registration cannot be completed.	<a href="#">WT-60</a>

A

B

C

D

WT

F

G

H

I

J

K

L

M

N

O

P

# LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

---

## LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN ON

### Diagnosis Procedure

INFOID:000000006915171

#### **NOTE:**

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### **1.**PERFORM SELF DIAGNOSTIC RESULT

---

Perform "SELF DIAGNOSTIC RESULT".

Is DTC "U1000" detected?

YES >> Malfunction in CAN communication system. Refer to [LAN-15, "Trouble Diagnosis Flow Chart"](#).

NO >> GO TO 2

### **2.**CHECK COMBINATION METER

---

Check combination meter operation. Refer to [MWI-8, "METER SYSTEM : System Description"](#).

Is the inspection result normal?

YES >> Replace low tire pressure warning control unit. Refer to [WT-65, "Removal and Installation"](#).

NO >> Replace combination meter. Refer to [MWI-64, "Removal and Installation"](#).



# LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

## LOW TIRE PRESSURE WARNING LAMP DOES NOT TURN OFF

### Diagnosis Procedure

INFOID:000000006915172

#### 1. INSPECT LOW TIRE PRESSURE WARNING CONTROL UNIT CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect low tire pressure warning control unit connector.
3. Check terminals for damage or loose connections.

Is the inspection result normal?

- YES >> GO TO 2  
NO >> Repair or replace damaged parts.

#### 2. LOW TIRE PRESSURE WARNING CONTROL UNIT POWER SUPPLY AND GROUND CIRCUITS

Check low tire pressure warning control unit power supply and ground circuits. Refer to [WT-54, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace low tire pressure warning control unit. Refer to [WT-65, "Removal and Installation"](#).  
NO >> Repair low tire pressure warning control unit circuits.

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# LOW TIRE PRESSURE WARNING LAMP BLINKS

< SYMPTOM DIAGNOSIS >

---

## LOW TIRE PRESSURE WARNING LAMP BLINKS

### Diagnosis Procedure

INFOID:000000006915173

#### **NOTE:**

If low tire pressure warning light repeats blinking ON for 2 seconds and OFF for 0.2 seconds, wake-up operation for all transmitters is not complete.

Carry out transmitter wake-up operation. Refer to [WT-28. "Work Procedure"](#).

### **1**.CHECK LOW TIRE PRESSURE WARNING CONTROL UNIT CONNECTOR

---

1. Turn ignition switch OFF.
2. Disconnect low tire pressure warning control unit connector.
3. Check terminals for damage or loose connections.

#### Is the inspection result normal?

- YES >> Replace low tire pressure warning control unit. Refer to [WT-65. "Removal and Installation"](#).  
NO >> Repair or replace damaged parts.

# "TIRE PRESSURE" INFORMATION IN DISPLAY UNIT DOES NOT EXIST

< SYMPTOM DIAGNOSIS >

## "TIRE PRESSURE" INFORMATION IN DISPLAY UNIT DOES NOT EXIST

### Diagnosis Procedure

INFOID:000000006915175

#### NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### 1.PERFORM SELF DIAGNOSTIC RESULT

Perform "SELF DIAGNOSTIC RESULT".

Is DTC "U1000" detected?

- YES >> Malfunction in CAN communication system. Refer to [LAN-15. "Trouble Diagnosis Flow Chart"](#).  
NO >> Check combination meter operation. Refer to [MWI-8. "METER SYSTEM : System Description"](#).

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ID REGISTRATION CANNOT BE COMPLETED

< SYMPTOM DIAGNOSIS >

---

## ID REGISTRATION CANNOT BE COMPLETED

### Diagnosis Procedure

INFOID:000000006915174

**NOTE:**

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

### 1. PERFORM ID REGISTRATION OF ALL TRANSMITTERS

---

Carry out ID registration of all transmitters. Refer to [WT-29. "Work Procedure"](#).

Can ID registration of all transmitters be completed?

YES >> Inspection End.

NO >> Refer to [WT-11. "Self Diagnosis Without CONSULT"](#).

# NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

## NOISE, VIBRATION, AND HARSHNESS (NVH) TROUBLESHOOTING

### NVH Troubleshooting Chart

INFOID:000000006749883

Use the chart below to help you find the cause of the symptom. If necessary, repair or replace these parts.

Symptom		Possible cause and SUSPECTED PARTS											Reference page				
		Out-of-round	Imbalance	Incorrect tire pressure	Uneven tire wear	Deformation or damage	Non-uniformity	Incorrect tire size	DIFFERENTIAL	FRONT AXLE AND FRONT SUSPENSION	REAR AXLE AND REAR SUSPENSION	TIRES	ROAD WHEEL	BRAKE	STEERING		
Noise	TIRES	x	x	x	x	x	x	x	x	x	x	x	x	x	x	WT-62	
		x	x	x	x	x	x	x	x	x	x	x	x	x	x	WT-63	
				x													WT-70
		x	x	x	x	x	x	x									FSU-8, "Front Wheel Alignment"
	ROAD WHEEL	x	x			x											—
		x	x			x											—
		x	x			x											WT-70
		x	x			x											DLN-31, "NVH Troubleshooting Chart"
Shake	TIRES	x	x	x	x	x	x	x	x	x	x	x	x	x	x	FAX-4, "NVH Troubleshooting Chart" (FAX), FSU-5, "NVH Troubleshooting Chart" (FSU)	
		x	x	x	x	x	x	x	x	x	x	x	x	x	x	RAX-4, "NVH Troubleshooting Chart" (RAX), RSU-4, "NVH Troubleshooting Chart" (RSU)	
																	Refer to TIRES in this chart.
																	Refer to ROAD WHEEL in this chart.
Vibration	TIRES															BR-6, "NVH Troubleshooting Chart"	
																ST-5, "NVH Troubleshooting Chart"	
Shimmy, shudder	TIRES																
Poor quality ride or handling	TIRES																
Poor quality ride or handling	ROAD WHEEL																

x: Applicable

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

WT

# WHEEL

< PERIODIC MAINTENANCE >

## PERIODIC MAINTENANCE

### WHEEL

#### Inspection

INFOID:000000006749888

#### STEEL WHEEL

1. Check tires for wear and improper inflation.
2. Check wheels for deformation, cracks, and other damage. If deformed, remove wheel and check wheel runout.
  - a. Remove tire from steel wheel and mount on a balancer machine.
  - b. Set two dial indicators as shown.
  - c. Set each dial indicator to 0.
  - d. Rotate wheel and check dial indicators at several points around the circumference of the wheel.
  - e. Calculate runout at each point as shown.

$$\text{Lateral deflection} = (W+X)/2$$


$$\text{Vertical deflection} = (Y+Z)/2$$

- f. Select maximum positive runout value and the maximum negative value. Add the two values to determine total runout. In case a positive or negative value is not available, use the maximum value (negative or positive) for total runout. If the total runout value exceeds the limit, replace the steel wheel.

#### Radial runout

Lateral deflection (A) : Refer to [WT-70, "Road Wheel"](#).

Vertical deflection (B) : Refer to [WT-70, "Road Wheel"](#).



AWBIA0186ZZ

# WHEEL AND TIRE ASSEMBLY

< PERIODIC MAINTENANCE >

## WHEEL AND TIRE ASSEMBLY

### Adjustment

INFOID:000000006749889

### BALANCING WHEELS (ADHESIVE WEIGHT TYPE)

#### Preparation Before Adjustment

Remove inner and outer balance weights from the road wheel using releasing agent, remove double-faced adhesive tape from the road wheel.

#### CAUTION:

- **Be careful not to scratch the road wheel during removal.**
- **After removing double-faced adhesive tape, wipe clean all traces of releasing agent from the road wheel.**

#### Wheel Balance Adjustment

- If a balancer machine has an adhesive weight mode setting, select the adhesive weight mode setting and skip Step 2. below. If a balancer machine only has the clip-on (rim flange) weight mode setting, follow Step 2. to calculate the correct size adhesive weight.

1. Set road wheel on balancer machine using the center hole as a guide. Start the balancer machine.
2. For balancer machines that only have a clip-on (rim flange) weight mode setting, follow this step to calculate the correct size adhesive weight to use. When inner and outer imbalance values are shown on the balancer machine indicator, multiply outer imbalance value by 5/3 (1.67) to determine balance weight that should be used. Select the outer balance weight with a value closest to the calculated value above and install in to the designated outer position of, or at the designated angle in relation to the road wheel.

- a. Indicated imbalance value  $\times 5/3$  (1.67) = balance weight to be installed

#### Calculation example:

$23 \text{ g (0.81 oz)} \times 5/3$  (1.67) = 38.33 g (1.35 oz)  $\Rightarrow$  40 g (1.41 oz)  
balance weight (closer to calculated balance weight value)


#### NOTE:

Note that balance weight value must be closer to the calculated balance weight value.

#### Example:

37.4  $\Rightarrow$  35 g (1.23 oz)

37.5  $\Rightarrow$  40 g (1.41 oz)




3. Install balance weight in the position shown.

#### CAUTION:

- **Do not install the inner balance weight before installing the outer balance weight.**
- **Before installing the balance weight, be sure to clean the mating surface of the road wheel.**
- When installing balance weight (1) to road wheel, set it into the grooved area (A) on the inner wall of the road wheel as shown so that the balance weight center (B) is aligned with the balancer machine indication position (angle) (C).

#### CAUTION:


- **Always use genuine NISSAN adhesive balance weights.**
- **Balance weights are non-reusable; always replace with new ones.**
- **Do not install more than three sheets of balance weight.**



# WHEEL AND TIRE ASSEMBLY

## < PERIODIC MAINTENANCE >


4. If calculated balance weight value exceeds 50 g (1.76 oz), install two balance weight sheets in line with each other as shown.  
**CAUTION:**  
**Do not install one balance weight sheet on top another.**
5. Start balancer machine again.
6. Install balance weight on inner side of road wheel in the balancer machine indication position (angle).  
**CAUTION:**  
**Do not install more than two balance weights.**
7. Start balancer machine. Make sure that inner and outer residual imbalance values are 5 g (0.17 oz) each or below.
8. If either residual imbalance value exceeds 5 g (0.17 oz), repeat installation procedures.



Wheel balance	Dynamic (At flange)	Static (At flange)
Maximum allowable imbalance	Refer to <a href="#">WT-70, "Road Wheel"</a> .	

## TIRE ROTATION

- Follow the maintenance schedule for tire rotation service intervals. Refer to [MA-7, "Introduction of Periodic Maintenance"](#).
- When installing the wheel, tighten wheel nuts to the specified torque.  
**CAUTION:**
  - Do not include the spare tire when rotating the tires.
  - When installing wheels, tighten them diagonally by dividing the work two to three times in order to prevent the wheels from developing any distortion.
  - Be careful not to tighten wheel nut at torque exceeding the criteria for preventing strain of disc rotor.



**Wheel nut tightening : 187 N·m (19 kg-m, 138 ft-lb) torque**

- Perform the transmitter ID registration, after tire rotation. Refer to [WT-29, "Work Procedure"](#).



# LOW TIRE PRESSURE WARNING CONTROL UNIT


< UNIT REMOVAL AND INSTALLATION >

## UNIT REMOVAL AND INSTALLATION

### LOW TIRE PRESSURE WARNING CONTROL UNIT

Exploded View

INFOID:000000006918413



1. Low tire pressure warning control unit


← Front

### Removal and Installation

INFOID:000000006918414

#### REMOVAL

1. Remove the instrument lower panel LH. Refer to [IP-18, "Removal and Installation"](#).
2. Disconnect low tire pressure warning control unit electrical connector.
3. Remove the lighting switch. Refer to [EXL-119, "Removal and Installation"](#).
4. Remove the low tire pressure warning control unit screw (A), using the access hole that was created by the removal of the lighting switch.
5. Remove the low tire pressure warning control unit.



#### INSTALLATION

Installation is in the reverse order of removal.

- Perform transmitter ID registration after replacing low tire pressure warning control unit. Refer to [WT-29, "Work Procedure"](#).


# TRANSMITTER

< UNIT REMOVAL AND INSTALLATION >

## TRANSMITTER

### Exploded View

INFOID:000000006918415




- |                |                 |              |
|----------------|-----------------|--------------|
| 1. Transmitter | 2. Grommet seal | 3. Valve nut |
| 4. Valve core  | 5. Cap          |              |

### Removal and Installation

INFOID:000000006918416

#### REMOVAL


1. Deflate tire. Unscrew transmitter retaining nut and allow transmitter to fall into tire.
2. Gently bounce tire so that transmitter falls to bottom of tire. Place on tire changing machine and break both tire beads, ensuring that the transmitter remains at the bottom of the tire.



3. Turn tire so that valve hole is at bottom and bounce tire so that transmitter (1) is near valve hole. Carefully lift tire onto turntable and position valve hole (and transmitter) 270° from mounting/dismounting head (2).
4. Lubricate the tire well with a suitable non-silicone lubricant, and remove first side of the tire. Reach inside the tire and remove the transmitter.

#### **CAUTION:**

**Do not use silicone lubricant. Use of silicone lubricant will deteriorate the tire and wheel.**




#### INSTALLATION

# TRANSMITTER

## < UNIT REMOVAL AND INSTALLATION >


1. Put first side of tire onto rim.



2. Mount transmitter (1) on rim (2) and tighten nut (3).

**CAUTION:**

**Do not reuse seal.**



3. Place wheel on turntable of tire machine. Ensure that transmitter (1) is 270° from mounting head (2) when second side of tire is fitted.

**NOTE:**


Do not touch transmitter at mounting head.

4. Lubricate the tire well with a suitable non-silicone lubricant, and fit second side of tire as normal. Ensure that tire does not rotate relative to rim.

**CAUTION:**

**Do not use silicone lubricant. Use of silicone lubricant will deteriorate the tire and wheel.**

5. Inflate tire and fit to appropriate wheel position.
6. Perform the transmitter wake-up operation after replacing transmitter. Refer to [WT-28, "Work Procedure"](#).



A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# TIRE PRESSURE RECEIVER


< UNIT REMOVAL AND INSTALLATION >

## TIRE PRESSURE RECEIVER

### FRONT TIRE PRESSURE RECEIVER

#### FRONT TIRE PRESSURE RECEIVER : Exploded View

INFOID:000000007257546



1. Front tire pressure receiver

← Front

#### FRONT TIRE PRESSURE RECEIVER : Removal and Installation

INFOID:000000006918418

##### REMOVAL

1. Remove the front fender protector. Refer to [EXT-33, "Removal and Installation"](#).
2. Disconnect front tire pressure receiver harness electrical connector.
3. Remove the front tire pressure receiver bolt.
4. Remove front tire pressure receiver.


##### INSTALLATION

Installation is in the reverse order of removal.

### REAR TIRE PRESSURE RECEIVER

#### REAR TIRE PRESSURE RECEIVER : Exploded View

INFOID:000000007257547



1. Rear tire pressure receiver

← Front

# TIRE PRESSURE RECEIVER


< UNIT REMOVAL AND INSTALLATION >

## REAR TIRE PRESSURE RECEIVER : Removal and Installation

INFOID:000000006918419

### REMOVAL

1. Remove the two clips (A) and the rear tire pressure receiver cover (1).
2. Disconnect the rear tire pressure receiver harness electrical connector.
3. Remove the rear tire pressure receiver bolt.
4. Remove rear tire pressure receiver.



### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
WT  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Road Wheel

INFOID:000000006749891

Item		Inside	Outside
Radial runout	Lateral mm (in)	0.8 (0.031) or less	0.8 (0.031) or less
	Vertical mm (in)	0.8 (0.031) or less	0.8 (0.031) or less
Allowable imbalance	Dynamic (at rim flange)	Less than 5 g (0.18 oz) (per side)	
	Static (at rim flange)	Less than 10 g (0.35 oz)	

#### Tire

INFOID:000000006749892

Unit: kPa (kg/cm<sup>2</sup>, psi)

Tire size	Air pressure			
	Conventional tire		Spare tire	
	Front	Rear	Front	Rear
LT245/70R17	350 (3.6, 50)	550 (5.6, 80)	350 (3.6, 50)	550 (5.6, 80)
LT245/75R17	350 (3.6, 50)	550 (5.6, 80)	350 (3.6, 50)	550 (5.6, 80)

\* Maintain spare tire pressure at 550 (5.6, 80) and adjust pressure according to the mounting position on the vehicle.