

# MWI

**SECTION**

## METER, WARNING LAMP & INDICATOR

A  
B  
C  
D  
E

### CONTENTS

|  |    |   |    |   |
|--|----|---|----|---|
| <b>PRECAUTION</b>  | 4  | FUEL GAUGE : System Diagram .....                     | 12 | F |
| <b>PRECAUTIONS</b>   | 4  | FUEL GAUGE : System Description .....                 | 12 |   |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ..... | 4  | <b>MASTER WARNING LAMP</b> .....                      | 12 | G |
| <b>PREPARATION</b>   | 5  | MASTER WARNING LAMP : System Diagram .....            | 13 | H |
| <b>PREPARATION</b>   | 5  | MASTER WARNING LAMP : System Description .....        | 13 | I |
| Commercial Service Tools .....   | 5  | <b>METER ILLUMINATION CONTROL</b> .....               | 13 | J |
| <b>SYSTEM DESCRIPTION</b>  | 6  | METER ILLUMINATION CONTROL : System Diagram .....     | 13 | K |
| <b>COMPONENT PARTS</b>   | 6  | METER ILLUMINATION CONTROL : System Description ..... | 13 | L |
| <b>METER SYSTEM</b>  | 6  | <b>METER EFFECT FUNCTION</b> .....                    | 13 | M |
| METER SYSTEM : Component Parts Location .....  | 6  | METER EFFECT FUNCTION : System Diagram .....          | 14 | W |
| METER SYSTEM : Component Description .....   | 7  | METER EFFECT FUNCTION : System Description .....      | 14 |   |
| <b>SYSTEM</b>  | 9  | <b>INFORMATION DISPLAY</b> .....                      | 15 |   |
| <b>METER SYSTEM</b>  | 9  | INFORMATION DISPLAY : System Diagram .....            | 15 |   |
| METER SYSTEM : System Diagram .....  | 9  | INFORMATION DISPLAY : System Description .....        | 15 |   |
| METER SYSTEM : System Description .....  | 9  | <b>COMPASS</b> .....                                  | 16 |   |
| METER SYSTEM : Arrangement of Combination  |    | COMPASS : Description .....                           | 16 |   |
| Meter .....  | 10 | <b>DIAGNOSIS SYSTEM (COMBINATION METER)</b> .....     | 19 |   |
| METER SYSTEM : Fail-Safe .....   | 10 | Description .....                                     | 19 |   |
| <b>SPEEDOMETER</b>   | 11 | CONSULT Function (METER/M&A) .....                    | 19 |   |
| SPEEDOMETER : System Diagram .....   | 11 | <b>ECU DIAGNOSIS INFORMATION</b> .....                | 24 |   |
| SPEEDOMETER : System Description .....   | 11 | <b>COMBINATION METER</b> .....                        | 24 |   |
| <b>TACHOMETER</b>  | 11 | Reference Value .....                                 | 24 |   |
| TACHOMETER : System Diagram .....  | 12 | Fail-Safe .....                                       | 28 |   |
| TACHOMETER : System Description .....  | 12 | DTC Index .....                                       | 29 |   |
| <b>ENGINE COOLANT TEMPERATURE GAUGE</b>  | 12 | <b>BCM (BODY CONTROL MODULE)</b> .....                | 30 |   |
| ENGINE COOLANT TEMPERATURE GAUGE : System Diagram .....  | 12 | List of ECU Reference .....                           | 30 |   |
| ENGINE COOLANT TEMPERATURE GAUGE : System Description .....                                      | 12 | <b>WIRING DIAGRAM</b> .....                           | 31 |   |
| <b>FUEL GAUGE</b>  | 12 | <b>METER SYSTEM</b> .....                             | 31 |   |

|  |           |   |           |
|--|-----------|---|-----------|
| Wiring Diagram .....                           | 31        | Component Inspection .....                    | 67        |
| <b>COMPASS .....</b>                           | <b>50</b> | <b>PARKING BRAKE SWITCH SIGNAL CIR-</b>       | <b>69</b> |
| Wiring Diagram .....                           | 50        | Description .....                             | 69        |
| <b>BASIC INSPECTION .....</b>                  | <b>52</b> | Component Function Check .....                | 69        |
| <b>DIAGNOSIS AND REPAIR WORK FLOW .....</b>    | <b>52</b> | Diagnosis Procedure .....                     | 69        |
| Work flow .....                                | 52        | Component Inspection .....                    | 69        |
| <b>DTC/CIRCUIT DIAGNOSIS .....</b>             | <b>54</b> | <b>STEERING SWITCH .....</b>                  | <b>70</b> |
| <b>U1000 CAN COMM CIRCUIT .....</b>            | <b>54</b> | Description .....                             | 70        |
| DTC Logic .....                                | 54        | Diagnosis Procedure .....                     | 70        |
| Diagnosis Procedure .....                      | 54        | Component Inspection .....                    | 70        |
| <b>U1010 CONTROL UNIT (CAN) .....</b>          | <b>55</b> | <b>SYMPTOM DIAGNOSIS .....</b>                | <b>72</b> |
| Description .....                              | 55        | <b>THE FUEL GAUGE INDICATOR DOES NOT</b>      | <b>72</b> |
| DTC Logic .....                                | 55        | Operate .....                                 | 72        |
| Diagnosis Procedure .....                      | 55        | Description .....                             | 72        |
| <b>B2205 VEHICLE SPEED .....</b>               | <b>56</b> | Diagnosis Procedure .....                     | 72        |
| Description .....                              | 56        | <b>THE ILLUMINATION CONTROL SWITCH IS</b>     | <b>73</b> |
| DTC Logic .....                                | 56        | Inoperative .....                             | 73        |
| Diagnosis Procedure .....                      | 56        | Description .....                             | 73        |
| <b>B2267 ENGINE SPEED .....</b>                | <b>57</b> | Diagnosis Procedure .....                     | 73        |
| Description .....                              | 57        | <b>THE TRIP RESET SWITCH IS INOPERATIVE..</b> | <b>74</b> |
| DTC Logic .....                                | 57        | Description .....                             | 74        |
| Diagnosis Procedure .....                      | 57        | Diagnosis Procedure .....                     | 74        |
| <b>B2268 WATER TEMP .....</b>                  | <b>58</b> | <b>THE OIL PRESSURE WARNING CONTIN-</b>       | <b>75</b> |
| Description .....                              | 58        | UES DISPLAYING, OR DOES NOT DISPLAY..         | 75        |
| DTC Logic .....                                | 58        | Description .....                             | 75        |
| Diagnosis Procedure .....                      | 58        | Diagnosis Procedure .....                     | 75        |
| <b>POWER SUPPLY AND GROUND CIRCUIT .....</b>   | <b>59</b> | <b>THE PARKING BRAKE RELEASE WARNING</b>      | <b>76</b> |
| <b>COMBINATION METER .....</b>                 | <b>59</b> | Continues Displaying, Or Does Not             | 76        |
| COMBINATION METER : Diagnosis Procedure ...    | 59        | Display .....                                 | 76        |
| <b>BCM (BODY CONTROL MODULE) .....</b>         | <b>59</b> | Description .....                             | 76        |
| BCM (BODY CONTROL MODULE) : Diagnosis          |           | Diagnosis Procedure .....                     | 76        |
| Procedure .....                                | 59        | <b>THE LOW WASHER FLUID WARNING CON-</b>      | <b>77</b> |
| <b>ILLUMINATION CONTROL SWITCH SIGNAL</b>      |           | TINUES DISPLAYING, or Does Not Dis-           |           |
| <b>CIRCUIT .....</b>                           | <b>61</b> | Play .....                                    | 77        |
| Diagnosis Procedure .....                      | 61        | Description .....                             | 77        |
| Component Inspection .....                     | 61        | Diagnosis Procedure .....                     | 77        |
| <b>TRIP RESET SWITCH SIGNAL CIRCUIT .....</b>  | <b>63</b> | <b>THE DOOR OPEN WARNING CONTINUES</b>        | <b>78</b> |
| Diagnosis Procedure .....                      | 63        | DISPLAYING, OR DOES NOT DISPLAY ..            | 78        |
| Component Inspection .....                     | 63        | Description .....                             | 78        |
| <b>FUEL LEVEL SENSOR SIGNAL CIRCUIT .....</b>  | <b>65</b> | Diagnosis Procedure .....                     | 78        |
| Description .....                              | 65        | <b>THE LIFTGATE OPEN WARNING CONTIN-</b>      | <b>79</b> |
| Component Function Check .....                 | 65        | UES DISPLAYING, OR DOES NOT DISPLAY..         | 79        |
| Diagnosis Procedure .....                      | 65        | Description .....                             | 79        |
| Component Inspection .....                     | 66        | Diagnosis Procedure .....                     | 79        |
| <b>WASHER FLUID LEVEL SWITCH CIRCUIT .....</b> | <b>67</b> | <b>THE STEERING SWITCHES ARE INOPERA-</b>     | <b>80</b> |
| Description .....                              | 67        | TIVE .....                                    | 80        |
| Diagnosis Procedure .....                      | 67        | Description .....                             | 80        |
|  |           | Diagnosis Procedure .....                     | 80        |

|   |           |     |
|---|-----------|-----|
| <b>THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT</b> ..... | <b>81</b> |     |
| Description .....   | 81        | A   |
| Diagnosis Procedure .....                                 | 81        |     |
| <b>REMOVAL AND INSTALLATION</b> .....                     | <b>82</b> | B   |
|   |           | C   |
|   |           | D   |
|   |           | E   |
|   |           | F   |
|   |           | G   |
|   |           | H   |
|   |           | I   |
|   |           | J   |
|   |           | K   |
|   |           | L   |
|   |           | M   |
|   |           | MWI |
|   |           | O   |
|   |           | P   |

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000009745915

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

## PREPARATION

< PREPARATION >

# PREPARATION

## PREPARATION

### Commercial Service Tools

INFOID:000000009174216

| Tool name  | Description  |
|------------|--|
| Power tool | <br>PIIB1407E<br>Loosening nuts, screws and bolts |

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### METER SYSTEM

METER SYSTEM : Component Parts Location

INFOID:0000000009174217



AWNIA2792ZZ

# COMPONENT PARTS

## < SYSTEM DESCRIPTION >

- |  |  |   |   |
|--|--|---|---|
| 1. Steering switch   | 2. Illumination control switch   | 3. Combination meter  | A |
| 4. Trip reset switch   | 5. Seat belt buckle switch (Driver seat)<br>(passenger similar)                  | 6. Parking brake switch   |   |
| 7. BCM<br>(view with combination meter removed)  | 8. Engine oil pressure sensor  | 9. ECM  | B |
| 10. TCM  | 11. Power steering control module  | 12. ABS actuator and electric unit (control unit)                 | C |
| 13. Ambient sensor<br>(view with front fascia removed)                                     | 14. CVT shift selector<br>(O/D OFF switch)                                       | 15. Washer fluid level switch<br>(view with front fascia removed) | D |
| 16. Fuel level sensor unit and fuel pump<br>(view with fuel pump inspection cover removed) | 17. Air bag diagnosis sensor unit<br>(view with center console assembly removed) | 18. A/C auto amp  | E |
| 19. Brake fluid level switch   |  |   | F |

## METER SYSTEM : Component Description

INFOID:000000009174218

| Unit   | Description   |     |
|--|---|-----|
| Combination meter                                | <p>Controls the following with the signals received from each unit via CAN communication and the signals from switches and sensors:</p> <ul style="list-style-type: none"> <li>• Speedometer</li> <li>• Tachometer</li> <li>• Engine coolant temperature gauge</li> <li>• Fuel gauge</li> <li>• Warning lamps</li> <li>• Indicator lamps</li> <li>• Meter illumination control</li> <li>• Meter effect function</li> <li>• Information display</li> </ul> | G   |
| Illumination control switch                      | Transmits the following signals to the combination meter: <ul style="list-style-type: none"> <li>• Illumination control switch signal (+)</li> <li>• Illumination control switch signal (-)</li> </ul>  | J   |
| Trip reset switch                                | Transmits the trip reset switch signal to the combination meter.  | K   |
| ECM  | Transmits the following signals to the combination meter via CAN communication: <ul style="list-style-type: none"> <li>• Engine speed signal</li> <li>• Engine coolant temperature signal</li> <li>• Engine oil pressure warning signal</li> <li>• Fuel consumption monitor signal</li> </ul>   | L   |
| ABS actuator and electric unit<br>(control unit) | Transmits the vehicle speed signal to the combination meter via CAN communication.  | M   |
| Power steering control module                    | Transmits the EPS signal to the combination meter via CAN communication.  |     |
| BCM  | Transmits the following signals to the combination meter via CAN communication: <ul style="list-style-type: none"> <li>• Tire pressure information</li> <li>• Position light request signal</li> <li>• Low tire pressure warning lamp signal</li> <li>• Door switch signal</li> <li>• Back door switch signal</li> </ul>  | MWI |
| TCM  | Transmits the shift selector position signal to the combination meter via CAN communication.  | O   |
| CVT shift selector<br>(O/D OFF switch)           | Transmits the O/D OFF switch signal to the combination meter.   | P   |
| Fuel level sensor unit                           | Transmits the fuel level sensor signal to the combination meter.  |     |
| Seat belt buckle switch (driver seat)            | Transmits the seat belt buckle switch (driver seat) signal to the combination meter.  |     |
| Air bag diagnosis sensor unit                    | Transmits the seat belt buckle switch (passenger seat) signal to the combination meter.   |     |
| Engine oil pressure sensor                       | Transmits the engine oil pressure sensor signal to the ECM.   |     |
| Ambient sensor                                   | Transmits the ambient sensor signal to the A/C auto amp.  |     |

## COMPONENT PARTS

### < SYSTEM DESCRIPTION >

| Unit                      | Description   |
|---------------------------|---|
| A/C auto amp.             | Transmits the ambient sensor signal to the combination meter via CAN communication.   |
| Parking brake switch      | Transmits the parking brake switch signal to the combination meter.   |
| Washer fluid level switch | Transmits the washer fluid level switch signal to the combination meter.  |
| Steering switch           | Transmits the following signals to the information display: <ul style="list-style-type: none"><li>• Display signal</li><li>• Menu up signal</li><li>• Menu down signal</li><li>• Enter signal</li><li>• Back signal</li></ul> |
| Brake fluid level switch  | Transmits the brake fluid level switch signal to the combination meter.   |

# SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM

### METER SYSTEM

#### METER SYSTEM : System Diagram

INFOID:0000000009174219



AWNIA2793GB

#### METER SYSTEM : System Description

INFOID:0000000009174220

##### COMBINATION METER

- The combination meter receives signals from switches, sensors and modules to control the following functions:
  - Speedometer/tachometer
  - Warning lamps
  - Indicator lamps
  - Meter illumination control
  - Meter effect function
  - Information display
- The combination meter has an integrated buzzer that is activated when it receives a signal from the BCM via CAN communication. Refer to [WCS-6, "WARNING CHIME SYSTEM : System Description"](#) for further details.
- The combination meter includes an on-board diagnosis function.
- The combination meter can be diagnosed with CONSULT.

A

B

C

D

E

F

G

H

I

J

K

L

M

O

P


MWI

# SYSTEM

< SYSTEM DESCRIPTION >

## METER SYSTEM : Arrangement of Combination Meter

INFOID:000000009174221



## METER SYSTEM : Fail-Safe

INFOID:000000009755007

### FAIL-SAFE

The combination meter activates the fail-safe control if CAN communication with each unit is malfunctioning.

# SYSTEM


## < SYSTEM DESCRIPTION >

| Function                         |                                | Specifications   |
|----------------------------------|--------------------------------|--|
| Speedometer                      |                                | Reset to zero by suspending communication.                   |
| Tachometer                       |                                |  |
| Engine coolant temperature gauge |                                |  |
| Illumination control             |                                | When suspending communication, changes to nighttime mode.    |
| Information display              | Odo/trip meter                 | An indicated value is maintained at communications blackout. |
|                                  | Shift position indicator       | The display turns OFF by suspending communication.           |
|                                  | Warning messages               | The display turns OFF by suspending communication.           |
| Buzzer                           |                                | The buzzer turns OFF by suspending communication.            |
| Warning lamp/indicator lamp      | ABS warning lamp               | The lamp turns ON by suspending communication.               |
|                                  | Slip indicator lamp            |  |
|                                  | Brake warning lamp             |  |
|                                  | O/D OFF indicator lamp         |  |
|                                  | Malfunction indicator lamp     |  |
|                                  | VDC OFF indicator lamp         |  |
|                                  | EPS warning lamp               | The lamp blinking caused by suspending communication.        |
|                                  | Low tire pressure warning lamp |  |
|                                  | High beam indicator lamp       |  |
|                                  | Turn signal indicator lamp     |  |
|                                  | Master warning lamp            |  |
|                                  | Front lamp indicator lamp      |  |
|                                  | Tow indicator lamp             | The lamp turns OFF by suspending communication.              |
|                                  | Tail lamp indicator lamp       |  |
|                                  | Air bag warning lamp           |  |
|                                  | Charge warning lamp            |  |
|                                  | Seat belt warning lamp         |  |
|                                  | Security indicator lamp        |  |

## SPEEDOMETER

### SPEEDOMETER : System Diagram

INFOID:000000009174223



A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

### SPEEDOMETER : System Description

INFOID:000000009174224

The ABS actuator and electric unit (control unit) receives each wheel speed sensor signal and provides a vehicle speed signal to the combination meter via CAN communication lines.


## TACHOMETER

# SYSTEM

< SYSTEM DESCRIPTION >

## TACHOMETER : System Diagram

INFOID:000000009174225



JSNIA2462GB

## TACHOMETER : System Description


INFOID:000000009174226

The crank position sensor sends a crankshaft position signal to the ECM. The ECM provides an engine speed signal to the combination meter via CAN communication lines. The tachometer indicates engine speed in revolutions per minute (rpm).

## ENGINE COOLANT TEMPERATURE GAUGE

## ENGINE COOLANT TEMPERATURE GAUGE : System Diagram

INFOID:000000009174227



AWNIA2579GB

## ENGINE COOLANT TEMPERATURE GAUGE : System Description


INFOID:000000009174228

The engine coolant temperature sensor sends an engine coolant temperature signal to the ECM. The ECM provides an engine coolant temperature signal to the combination meter via CAN communication lines. The engine coolant temperature gauge indicates the engine coolant temperature.

## FUEL GAUGE

## FUEL GAUGE : System Diagram

INFOID:000000009174229



JSNIA3000GB

## FUEL GAUGE : System Description

INFOID:000000009174230

The fuel level sensor unit sends a variable resistor signal to the combination meter. The fuel gauge indicates the approximate fuel level in the fuel tank.


## MASTER WARNING LAMP

# SYSTEM

< SYSTEM DESCRIPTION >

## MASTER WARNING LAMP : System Diagram

INFOID:000000009174231



## MASTER WARNING LAMP : System Description

INFOID:000000009174232


When receiving a signal from each unit, switch, or sensor, the combination meter turns ON/OFF the master warning lamp in synchronization with the following warnings on the information display:

- Door open warning
- Parking brake release warning
- Low fuel warning
- Low washer fluid warning
- Low tire pressure warning
- Fuel filler cap warning

## METER ILLUMINATION CONTROL

## METER ILLUMINATION CONTROL : System Diagram

INFOID:000000009174233



## METER ILLUMINATION CONTROL : System Description

INFOID:000000009174234

### METER ILLUMINATION ON/OFF CONTROL FUNCTION

Meter illumination control is enabled when the meter receives a signal from the BCM that the combination switch is in the AUTO (if equipped and activated) or parking lamp position and the meter switches from Daytime mode to Nighttime mode.

### METER ILLUMINATION CONTROL FUNCTION

The operation of the illumination control switch changes brightness of the meter illumination.

MWI

| Meter illumination | The number of adjustable steps |
|--------------------|--------------------------------|
| Daytime            | 22 steps                       |
| Nighttime          | 22 steps                       |

## METER EFFECT FUNCTION

O


P

# SYSTEM

< SYSTEM DESCRIPTION >

## METER EFFECT FUNCTION : System Diagram

INFOID:000000009174235



## METER EFFECT FUNCTION : System Description

INFOID:000000009174236

### ENGINE-START EFFECT FUNCTION

When recognizing an engine start, the combination meter controls the following items for producing the effect:

- Speedometer
- Tachometer
- Engine coolant temperature gauge
- Fuel gauge
- Meter illumination

#### Meter and Illumination Operations During Engine-start Effect

The combination meter controls the following items during the engine-start effect.

| Control item                     | Operation              |   |
|----------------------------------|------------------------|---|
| Speedometer                      | Sweeps the pointer.    |   |
| Tachometer                       | Sweeps the pointer.    |   |
| Engine coolant temperature gauge | Stops the pointer.     |   |
| Fuel gauge                       | Stops the pointer.     |   |
| Meter illumination               | Pointers               | Turns on the illumination at the effect level.            |
|                                  | Information display    | Turns on the illumination at the normal brightness level. |
|                                  | Other than those above | Increases the brightness to the effect level in stages.   |

#### NOTE:

The pointers are stopped and illumination is turned off while cranking the engine.

#### Engine Start Judgement

The combination meter judges “engine-start” and activates the engine-start effect only once when the following operational conditions are all satisfied.

| Condition                     |  |
|-------------------------------|--|
| Ignition switch               | ON position                                |
| Vehicle speed                 | Less than 0.6 MPH (1 km/h)                 |
| Engine state                  | Other than the time of cranking the engine |
|                               | 500 rpm or more                            |
| Information display (SETTING) | The setting of “EFFECT” is “ON.”           |

#### NOTE:

# SYSTEM


## < SYSTEM DESCRIPTION >

Engine-start effect exits when any of the above operational conditions is cancelled during the engine-start effect.

## INFORMATION DISPLAY

### INFORMATION DISPLAY : System Diagram

INFOID:000000009174237



AWNIA2795GB

### INFORMATION DISPLAY : System Description

INFOID:000000009174238

#### FUNCTION

The information display can indicate the following items:

- Outside air temperature
- Trip computer
- Intelligent Key operation information
- CVT shift position indicator
- Odometer
- Warning/Indication messages (door open, liftgate open, low oil pressure, CVT, 4WD, I-Key, low fuel, low washer fluid, release parking brake, low tire pressure and loose fuel cap).

#### OUTSIDE AIR TEMPERATURE INDICATION

The ambient temperature sensor sends the ambient sensor signal to the A/C auto amp. The a/c auto amp, then sends the signal to the combination meter via CAN communication lines.

#### LOOSE FUEL CAP MESSAGE

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# SYSTEM

## < SYSTEM DESCRIPTION >

The LOOSE FUEL CAP message will display in the information display when the fuel-filler cap is not tightened correctly. The message will turn off as soon as the ECM detects the fuel-filler cap is properly tightened. The ECM provides a loose fuel cap signal to the combination meter via CAN communication lines.

### LOW TIRE PRESSURE WARNING

This warning appears when the BCM detects low inflation pressure or a system malfunction. The BCM sends a signal to the combination meter via CAN communication to illuminate the low tire pressure warning lamp. In addition, a warning message will be displayed in the vehicle information display.

### DOOR OPEN WARNING

This warning appears when the ignition switch is ON and the door is open. The BCM receives a door switch signal from the door switch. The BCM sends the door switch signal to the combination meter via CAN communication lines.

### LIFTGATE OPEN WARNING

This warning appears when the ignition switch is ON and the liftgate is opened. The BCM receives a back door switch signal from the back door switch. The BCM sends the door switch signal to the combination meter via CAN communication lines.

### LOW FUEL WARNING

This warning appears when the fuel level in the fuel tank is less than approximately 2.5 US gal (9.6 L, 2.1 Imp gal). A variable resistor signal is supplied to the combination meter from the fuel level sensor unit to determine the amount of fuel in the fuel tank.

### LOW WINDSHIELD WASHER FLUID WARNING

When the windshield washer fluid level is low, the washer fluid level switch provides a ground signal to the combination meter and the warning is displayed. Once fluid is added, the switch opens and the warning is no longer displayed.

### RELEASE PARKING BRAKE WARNING

When the parking brake is applied, the parking brake switch provides a ground signal to the combination meter. When the vehicle speed is greater than 4 MPH (7 km/h), the message is displayed and the warning chime sounds.

### SHIFT POSITION INDICATOR

The combination meter activates the shift position indicator information based on signals received from TCM via CAN communication.

### LOW OIL PRESSURE WARNING

The low oil pressure warning appears in the information display when the combination meter receives a low engine oil pressure signal from the ECM via CAN communication.

### WARNING CHECK INDICATION

The combination meter can cause an interrupt on the information display to indicate a warning, based on signals received from each unit and switch.

Refer to Owner's Manual for additional information display items.

## COMPASS

### COMPASS : Description

INFOID:0000000009174239

## DESCRIPTION

# SYSTEM


## < SYSTEM DESCRIPTION >

With the ignition switch in the ON position, and the mode or (N) switch ON, the compass display will indicate the direction the vehicle is heading.

Vehicle direction is displayed as follows:

- N: north
- E: east
- S: south
- W: west

With HomeLink® universal transceiver



Without HomeLink® universal transceiver




WKIA4889E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
  
MWI  
  
O  
P

## ZONE VARIATION SETTING PROCEDURE

The difference between magnetic north and geographical north can sometimes be great enough to cause false compass readings. This difference is known as variance. In order for the compass to operate properly (accurately) in a particular zone, the zone variation must be calibrated using the following procedure.

Zone Variation Chart



WKIA4148E

1. Determine your location on the zone map.
2. Turn the ignition switch to the ON position.
3. Press and hold the (N) switch for about 5 seconds (with HomeLink universal transceiver) or the mode switch for about 8 seconds (without HomeLink universal transceiver). The current zone number will appear in the display.

# SYSTEM

## < SYSTEM DESCRIPTION >

4. Press the mode or (N) switch repeatedly until the desired zone number appears in the display.

Once the desired zone number is displayed, stop pressing the mode or (N) switch and the display will show a compass direction after a few seconds.

**NOTE:**

Use zone number 5 for Hawaii.


## CALIBRATION PROCEDURE

The compass display is equipped with an automatic correction function. If the compass display reads "CAL" or the direction is not shown correctly, perform the correction procedure below.

1. Press and hold the (N) switch for about 10 seconds (with HomeLink universal transceiver) or the mode switch for about 13 seconds (without HomeLink universal transceiver). The display will read "CAL".
2. Drive the vehicle slowly in a circle, in an open, safe place. The initial calibration is completed in about 3 turns.

**NOTE:**

In places where the terrestrial magnetism is extremely disturbed, the initial correction may start automatically.



# DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (COMBINATION METER)

### Description

INFOID:0000000009174240

#### COMBINATION METER SELF-DIAGNOSIS MODE

The following meter functions can be checked during Combination Meter Self-Diagnosis Mode:

- Pointer sweep of speedometer, tachometer and gauges.
- Illumination of all LCD segments and color patterns for meter displays.
- Illumination of all lamps/LEDs that are controlled by the combination meter (regardless of switch status).


#### STARTING COMBINATION METER SELF-DIAGNOSIS MODE

##### NOTE:

- Check combination meter power supply and ground circuits if self-diagnosis mode does not start. Refer to [MWI-59, "COMBINATION METER : Diagnosis Procedure"](#). Replace combination meter if power supply and ground circuits are found to be normal and self-diagnosis mode does not start. Refer to [MWI-82, "Removal and Installation"](#).
- Combination meter self-diagnosis mode will function with the ignition switch in ON. Combination meter self-diagnosis mode will exit upon turning the ignition switch to OFF.

##### How to Initiate Self-Diagnosis Mode

1. Press and hold the trip reset switch while turning the ignition switch ON. After 2 seconds release trip reset switch, then press the trip reset switch 3 times within 7 seconds after the ignition switch is turned ON.
2. When the diagnosis function is activated, the meter illuminates all of the following:
  - Warning lights/indicators.
  - Meter assembly.
  - Information display color bars red, green, blue and white (1).
  - Odometer, trip A/B odometers and CVT indicator LCD display segments (2).
3. Pressing and holding the trip reset switch performs the pointer sweep test.



### CONSULT Function (METER/M&A)

INFOID:0000000009174241

##### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

MWI

#### APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes shown.

| METER/M&A Diagnosis mode | Description   |
|--------------------------|---|
| Self Diagnostic Result   | Displays combination meter self-diagnosis results.                      |
| Data Monitor             | Displays combination meter input/output data in real time.              |
| Warning History          | Lighting history of the warning lamp and indicator lamp can be checked. |

#### SELF DIAG RESULT

Refer to [MWI-29, "DTC Index"](#).

#### DATA MONITOR

# DIAGNOSIS SYSTEM (COMBINATION METER)

## < SYSTEM DESCRIPTION >

### Display Item List

X: Applicable

| Display item [Unit]           | MAIN SIGNALS | Description   |
|-------------------------------|--------------|---|
| SPEED METER<br>[mph or km/h]  | X            | Displays the value of vehicle speed signal.                                       |
| SPEED OUTPUT<br>[mph or km/h] | X            | Vehicle speed signal value transmitted to other units via CAN communication.      |
| ODO OUTPUT<br>[mi or km]      |              | Odometer signal value transmitted to other units via CAN communication.           |
| TACHO METER<br>[rpm]          | X            | Value of the engine speed signal received from ECM via CAN communication.         |
| FUEL METER<br>[L]             | X            | Fuel level indicated on combination meter.  |
| W TEMP METER<br>[°F] or [°C]  | X            | Displays the value of engine coolant temperature signal, which is input from ECM. |
| ABS W/L<br>[On/Off]           |              | Displays [ON/OFF] condition of ABS warning indicator.                             |
| VDC/TCS IND<br>[On/Off]       |              | Displays [ON/OFF] condition of VDC OFF warning lamp.                              |
| SLIP IND<br>[On/Off]          |              | Displays [ON/OFF] condition of SLIP indicator lamp.                               |
| BRAKE W/L<br>[On/Off]         |              | Displays [ON/OFF] condition of brake warning indicator.                           |
| DOOR W/L<br>[ON/OFF]          |              | Displays [ON/OFF] condition of door open or liftgate open warning message.        |
| HI-BEAM IND<br>[ON/OFF]       |              | Displays [ON/OFF] condition of high beam indicator.                               |
| TURN IND<br>[On/Off]          |              | Displays [ON/OFF] condition of turn indicator.                                    |
| FR FOG IND<br>[On/Off]        |              | Displays [ON/OFF] condition of front fog lamp indicator.                          |
| LIGHT IND<br>[On/Off]         |              | Displays [ON/OFF] condition of light indicator.                                   |
| OIL W/L<br>[ON/OFF]           |              | Displays [ON/OFF] condition of low oil pressure warning message.                  |
| MIL<br>[ON/OFF]               |              | Displays [ON/OFF] condition of malfunction indicator.                             |
| CRUISE IND<br>[Off]           |              | Displays [ON/OFF] condition of CRUISE indicator in the information display.       |
| SET IND<br>[On/Off]           |              | Displays [ON/OFF] condition of SET indicator in the information display.          |
| O/D OFF IND<br>[On/Off]       |              | Displays [ON/OFF] condition of O/D OFF indicator.                                 |
| CVT IND<br>[On/Off]           |              | Displays [ON/OFF] condition of CVT indicator in the information display.          |
| 4WD W/L<br>[On/Off]           |              | Displays [ON/OFF] condition of 4WD warning message in the information display.    |
| FUEL W/L<br>[On/Off]          |              | Displays [ON/OFF] condition of low-fuel warning message.                          |
| WASHER W/L<br>[On/Off]        |              | Displays [ON/OFF] condition of low washer fluid warning message.                  |
| KEY G/Y W/L<br>[On/Off]       |              | Displays [ON/OFF] condition of key green warning lamp.                            |

# DIAGNOSIS SYSTEM (COMBINATION METER)

## < SYSTEM DESCRIPTION >

| Display item [Unit]                      | MAIN SIGNALS | Description   |     |
|--|--------------|---|-----|
| EPS W/L<br>[On/Off]                      |              | Displays [ON/OFF] condition of EPS warning indicator.   | A   |
| LCD<br>[B&P/Off]                         |              | Displays [B&P/Off] condition of the shift selector button.  | B   |
| SHIFT IND<br>[P,N,D,L]                   |              | Displays [P,N,D,L] shift selector position.   | C   |
| 4WD IND<br>[AUTO, LOCK, 2W]              |              | Displays [ON/OFF] condition of 4WD modes in the information display.  | D   |
| TOW MODE IND<br>[On/Off]                 |              | Displays [ON/OFF] condition of tow mode indicator.  | E   |
| FUEL CAP W/L<br>[On/Off]                 |              | Displays [ON/OFF] condition of loose fuel cap warning message.  | F   |
| O/D OFF SW<br>[On/Off]                   |              | Displays [ON/OFF] condition of O/D OFF switch.  | G   |
| COMP F/B SIG<br>[On/Off]                 |              | A/C compressor activation condition that ECM judges according to the water temperature and the acceleration degree.   | H   |
| PKB SW<br>[On/Off]                       |              | Displays [ON/OFF] condition of parking brake switch.  | I   |
| BRAKE OIL SW<br>[On/Off]                 |              | Displays [ON/OFF] condition of brake fluid level switch.  | J   |
| BUCKLE SW<br>[On/Off]                    |              | Displays [ON/OFF] condition of seat belt buckle switch (driver seat).   | K   |
| PASS BUCKLE SW<br>[On/Off]               |              | Displays [ON/OFF] condition of seat belt buckle switch (passenger seat).  | L   |
| TOW MODE SW<br>[On/Off]                  |              | Displays [ON/OFF] condition of tow mode switch.   | M   |
| DISTANCE<br>[mi] or [km]                 |              | Displays distance to empty.   | N   |
| OUTSIDE TEMP<br>[°F or °C]               |              | Displays the ambient temperature which is input from ambient sensor.  | O   |
| FUEL LOW SIG<br>[On/Off]                 |              | Displays the [ON/OFF] condition the fuel level low warning signal.  | P   |
| BUZZER<br>[On/Off]                       | X            | Buzzer status (in the combination meter) is detected from the buzzer output signal received from each unit via CAN communication and the warning output condition of the combination meter. | Q   |
| BATTERY CIRCUIT STATUS<br>[NORMAL/OPEN]  |              | Displays [NORMAL/OPEN] condition of battery circuit status.   | R   |
| PARKING AIDS DSP<br>[On/Off]             |              | Displays [On/Off] condition of parking aids display setting.  | MWI |
| PARKING AIDS SENSOR<br>[On/Off]          |              | Displays [On/Off] condition of parking aids sensor setting.   | S   |
| PARKING AIDS VOLUME<br>[Low/Medium/High] |              | Displays [Low/Medium/High] condition of parking aids volume.  | T   |
| PARKING AIDS RANGE<br>[Near/Medium/Far]  |              | Displays [Near/Medium/Far] condition of parking aids range.   | U   |
| TPMS DISP<br>[ON/OFF]                    |              | Displays [ON/OFF] condition of TPMS display.  | V   |
| TIRE STATUS FR<br>[ON/OFF]               |              | Displays [ON/OFF] condition of tire status.   | W   |
| TIRE STATUS FL<br>[ON/OFF]               |              | Displays [ON/OFF] condition of tire status.   | X   |

# DIAGNOSIS SYSTEM (COMBINATION METER)

## < SYSTEM DESCRIPTION >

| Display item [Unit]   | MAIN SIGNALS | Description  |
|---|--------------|--|
| TIRE STATUS RR<br>[ON/OFF]                                      |              | Displays [ON/OFF] condition of tire status.  |
| TIRE STATUS RL<br>[ON/OFF]                                      |              | Displays [ON/OFF] condition of tire status.  |
| SONER SET AVA<br>[Available/Unavailable]                        |              | Displays [AVAILABLE/UNAVAILABLE] condition of meter setting.                                   |
| STRG SW INPUT<br>[SW1,SW2,SW3,SW4,SW5,SW6,S<br>W7,SW8,SW9,SW10] |              | Displays [SW1,SW2,SW3,SW4,SW5,SW6,SW7,SW8,SW9,SW10] condition of steering switch.              |
| ITS SONER SET OUTPUT  |              | Displays status of sonar.  |
| SONAR DET STA<br>[ON/OFF]                                       |              | Displays [ON/OFF] condition of sonar detection area.   |
| SONAR WARN<br>[OFF/SENSOR DEACTIVE/SEN-<br>SOR ERROR]           |              | Displays [OFF/SENSOR DEACTIVE/SENSOR ERROR] condition of sonar warning.                        |
| SONAR DET DSP RC<br>[ON/OFF]                                    |              | Displays [ON/OFF] condition of RC sonar detection display.                                     |
| SONAR DSP AREA RC<br>[ON/OFF]                                   |              | Displays [ON/OFF] condition of RC sonar detection area image.                                  |
| SONAR DET DSP RL<br>[ON/OFF]                                    |              | Displays [ON/OFF] condition of RL sonar detection display.                                     |
| SONAR DSP AREA RL<br>[ON/OFF]                                   |              | Displays [ON/OFF] condition of RL sonar detection area image.                                  |
| SONAR DET DSP RR<br>[ON/OFF]                                    |              | Displays [ON/OFF] condition of RR sonar detection display.                                     |
| SONAR DSP AREA RR<br>[ON/OFF]                                   |              | Displays [ON/OFF] condition of RR sonar detection area image.                                  |
| SONAR DET DSP FC<br>[ON/OFF]                                    |              | Displays [ON/OFF] condition of FC sonar detection area.  |
| SONAR DSP AREA FC<br>[ON/OFF]                                   |              | Displays [ON/OFF] condition of FC sonar detection area image.                                  |
| SONAR DET DSP FL<br>[ON/OFF]                                    |              | Displays [ON/OFF] condition of FL sonar detection display.                                     |
| SONAR DSP AREA FL<br>[ON/OFF]                                   |              | Displays [ON/OFF] condition of FL sonar detection area image.                                  |
| SONAR DET DSP FR<br>[ON/OFF]                                    |              | Displays [ON/OFF] condition of FR sonar detection display.                                     |
| SONAR DSP AREA FR<br>[ON/OFF]                                   |              | Displays [ON/OFF] condition of FR sonar detection area image.                                  |
| SONAR DIST DSP<br>[ON/OFF]                                      |              | Displays sonar distance status.  |
| TPMS PRESS L<br>[ON/OFF]  |              | Displays [ON/OFF] condition of low tire pressure message in the information display.           |
| TPMS MALF<br>[ON/OFF]   |              | Displays [ON/OFF] condition of TPMS warning indicator.   |
| 4WD CL TMP H<br>[ON/OFF]  |              | Displays [ON/OFF] condition of 4WD clutch high temperature message in the information display. |
| 4WD TIRE CHCK<br>[ON/OFF]                                       |              | Displays [ON/OFF] condition of 4WD tire check message in the information display.              |
| 4WD SYS MALF<br>[ON/OFF]  |              | Displays [ON/OFF] condition of 4WD system malfunction message in the information display.      |

# DIAGNOSIS SYSTEM (COMBINATION METER)

## < SYSTEM DESCRIPTION >

| Display item [Unit]                               | MAIN SIGNALS | Description                                |
|---|--------------|--|
| TIRE PRESS FR<br>[kPa, kg/cm <sup>2</sup> or Psi] |              | Displays air pressure of front right tire. |
| TIRE PRESS FL<br>[kPa, kg/cm <sup>2</sup> or Psi] |              | Displays air pressure of front left tire.  |
| TIRE PRESS RR<br>[kPa, kg/cm <sup>2</sup> or Psi] |              | Displays air pressure of rear right tire.  |
| TIRE PRESS RL<br>[kPa, kg/cm <sup>2</sup> or Psi] |              | Displays air pressure of rear left tire.   |

### NOTE:

Some items are not available according to vehicle specification.

### Warning History

- Stores histories when warning/indicator lamp is turned on.
- “Warning History” indicates the “TIME” when the warning/indicator lamp is turned on.
- The “TIME” above is:
  - 0: The condition that the warning/indicator lamp has been turned on 1 or more times after starting the engine and waiting for 30 seconds.
  - 1 - 39: The number of times the engine was restarted after the 0 condition.
  - NO Warning History: Stores NO (0) turning on history of warning/indicator lamp.

### NOTE:

- Warning History is not stored for approximately 30 seconds after the engine starts.
- Brake warning lamp does not store any history when the parking brake is applied or the brake fluid level gets low.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION COMBINATION METER

### Reference Value

INFOID:0000000009174242

### VALUES ON THE DIAGNOSIS TOOL

| Monitor Item                  | Condition          |                                   | Value/Status  |
|-------------------------------|--------------------|-----------------------------------|---|
| SPEED METER<br>[mph or km/h]  | Ignition switch ON | While driving                     | Input value of vehicle speed signal (CAN communication signal)              |
| SPEED OUTPUT<br>[mph or km/h] | Ignition switch ON | While driving                     | Output value of vehicle speed signal (CAN communication signal)             |
| ODO OUTPUT<br>[mi or km]      | Ignition switch ON | —                                 | Output value of odometer signal (CAN communication signal)                  |
| TACHO METER<br>[rpm]          | Ignition switch ON | Engine running                    | Input value of engine speed signal (CAN communication signal)               |
| FUEL METER<br>[L]             | Ignition switch ON | —                                 | Input value of fuel level sensor signal                                     |
| W TEMP METER<br>[°F] or [°C]  | Ignition switch ON | —                                 | Input value of engine coolant temperature signal (CAN communication signal) |
| ABS W/L                       | Ignition switch ON | ABS warning lamp ON               | On  |
|                               |                    | ABS warning lamp OFF              | Off   |
| VDC/TCS IND                   | Ignition switch ON | VDC OFF indicator lamp ON         | On  |
|                               |                    | VDC OFF indicator lamp OFF        | Off   |
| SLIP IND                      | Ignition switch ON | VDC warning lamp ON               | On  |
|                               |                    | VDC warning lamp OFF              | Off   |
| BRAKE W/L                     | Ignition switch ON | Brake warning lamp ON             | On  |
|                               |                    | Brake warning lamp OFF            | Off   |
| DOOR W/L                      | Ignition switch ON | Door open warning ON              | On  |
|                               |                    | Other than the above              | Off   |
| HI-BEAM IND                   | Ignition switch ON | High beam indicator lamp ON       | On  |
|                               |                    | High beam indicator lamp OFF      | Off   |
| TURN IND                      | Ignition switch ON | Turn signal indicator lamp ON     | On  |
|                               |                    | Turn signal indicator lamp OFF    | Off   |
| FR FOG IND                    | Ignition switch ON | Front fog lamp indicator lamp ON  | On  |
|                               |                    | Front fog lamp indicator lamp OFF | Off   |
| LIGHT IND                     | Ignition switch ON | Tail lamp indicator lamp ON       | On  |
|                               |                    | Tail lamp indicator lamp OFF      | Off   |
| OIL W/L                       | Ignition switch ON | Oil pressure warning              | On  |
|                               |                    | Oil pressure warning              | Off   |
| MIL                           | Ignition switch ON | Malfunction indicator lamp ON     | On  |
|                               |                    | Malfunction indicator lamp OFF    | Off   |
| CRUISE IND                    | Ignition switch ON | CRUISE indicator ON               | On  |
|                               |                    | CRUISE indicator OFF              | Off   |
| SET IND                       | Ignition switch ON | SET indicator ON                  | On  |
|                               |                    | SET indicator OFF                 | Off   |

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

| Monitor Item                 | Condition          |   | Value/Status  |
|------------------------------|--------------------|---|---|
| O/D OFF IND                  | Ignition switch ON | O/D OFF indicator ON                              | On  |
|                              |                    | O/D OFF indicator OFF                             | Off   |
| CVT IND                      | Ignition switch ON | CVT indicator ON                                  | On  |
|                              |                    | CVT indicator OFF                                 | Off   |
| 4WD W/L                      | Ignition switch ON | 4WD warning lamp ON                               | On  |
|                              |                    | 4WD warning lamp OFF                              | Off   |
| FUEL W/L                     | Ignition switch ON | During low fuel level indication                  | On  |
|                              |                    | Except during low fuel level indication           | Off   |
| WASHER W/L                   | Ignition switch ON | Low washer fluid warning indication               | On  |
|                              |                    | Except during low washer fluid warning indication | Off   |
| KEY G/Y W/L                  | Ignition switch ON | KEY warning lamp (Green/Yellow) ON                | On  |
|                              |                    | KEY warning lamp (Green/Yellow) OFF               | Off   |
| EPS W/L                      | Ignition switch ON | EPS warning lamp ON                               | On  |
|                              |                    | EPS warning lamp OFF                              | Off   |
| LCD                          | Ignition switch ON | Shift selector button pressed                     | Off   |
|                              |                    | Shift selector button released                    | B&P   |
| SHIFT IND                    | Ignition switch ON | Shift position in park                            | P   |
|                              |                    | Shift position in neutral                         | N   |
|                              |                    | Shift position in drive                           | D   |
|                              |                    | Shift position in low                             | L   |
| 4WD IND                      | Engine running     | 4WD switch in AUTO position                       | AUTO  |
|                              |                    | 4WD switch in LOCK position                       | LOCK  |
| TOW MODE IND                 | Ignition switch ON | TOW mode indicator lamp ON                        | On  |
|                              |                    | TOW mode indicator lamp OFF                       | Off   |
| FUEL CAP W/L                 | Ignition switch ON | Fuel filler cap warning display ON                | On  |
|                              |                    | Fuel filler cap warning display OFF               | Off   |
| O/D OFF SW                   | Ignition switch ON | Overdrive control switch ON                       | On  |
|                              |                    | Overdrive control switch OFF                      | Off   |
| PKB SW                       | Ignition switch ON | Parking brake switch ON                           | On  |
|                              |                    | Parking brake switch OFF                          | Off   |
| BUCKLE SW                    | Ignition switch ON | Driver seat belt not fastened                     | On  |
|                              |                    | Driver seat belt fastened                         | Off   |
| BRAKE OIL SW                 | Ignition switch ON | Brake fluid level switch ON                       | On  |
|                              |                    | Brake fluid level switch OFF                      | Off   |
| PASS BUCKLE SW               | Ignition switch ON | Passenger seat belt not fastened                  | On  |
|                              |                    | Passenger seat belt fastened                      | Off   |
| TOW MODE SW                  | Ignition switch ON | TOW mode switch ON                                | On  |
|                              |                    | TOW mode switch OFF                               | Off   |
| DISTANCE<br>[mph or km/h]    | Ignition switch ON | —   | Distance to empty   |
| OUTSIDE TEMP<br>[°F] or [°C] | Ignition switch ON | —   | Displays the ambient air temperature which is input from the ambient sensor |
| FUEL LOW SIG                 | Ignition switch ON | During low fuel warning indication                | On  |
|                              |                    | Except during low fuel warning indication         | Off   |

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O


P

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition          |            | Value/Status |
|--------------|--------------------|------------|--------------|
| BUZZER       | Ignition switch ON | Buzzer ON  | On           |
|              |                    | Buzzer OFF | Off          |

## TERMINAL LAYOUT




## PHYSICAL VALUES

| Terminal No.<br>(Wire color) |        | Description                                       |                  | Condition                 |   | Value<br>(Approx.) |
|------------------------------|--------|---|------------------|---------------------------|---|--------------------|
| +                            | -      | Signal name                                       | Input/<br>Output |                           |   |                    |
| 1<br>(B)                     | Ground | Ground  | Input            | Ignition<br>switch<br>OFF | —   | Battery voltage    |
| 2<br>(B)                     | Ground | Ground  | Input            | Ignition<br>switch<br>ON  | —   | Battery voltage    |
| 3<br>(P)                     | Ground | Steering switch input 1                           | —                | —                         | —   | —                  |
| 4<br>(BG)                    | Ground | Steering switch input 2                           | —                | —                         | —   | —                  |
| 5<br>(P)                     | Ground | ACC   | —                | Ignition<br>switch<br>ON  | Ignition switch ACC or ON<br>power supply | Battery voltage    |
| 6<br>(V)                     | Ground | Security signal                                   | Input            | Ignition<br>switch<br>ON  | Security indicator ON                     | 0 V                |
|                              |        |   |                  |                           | Security indicator OFF                    | Battery voltage    |
| 7<br>(R)                     | Ground | Air bag signal                                    | Input            | Ignition<br>switch<br>ON  | Air bag warning lamp<br>ON                | —                  |
|                              |        |   |                  |                           | Air bag warning lamp<br>OFF               | —                  |
| 8<br>(G)                     | Ground | Passenger seat belt warn-<br>ing signal           | Input            | Ignition<br>switch<br>ON  | Fastened                                  | Battery voltage    |
|                              |        |   |                  |                           | Unfastened                                | 0 V                |
| 9<br>(Y)                     | Ground | Seat belt buckle switch sig-<br>nal (driver seat) | Input            | Ignition<br>switch<br>ON  | Fastened                                  | Battery voltage    |
|                              |        |   |                  |                           | Unfastened                                | 0 V                |
| 11<br>(BG)                   | Ground | Alternator signal                                 | Input            | Ignition<br>switch<br>ON  | Charge warning lamp ON                    | 2 V                |
|                              |        |   |                  |                           | Charge warning lamp OFF                   | Battery voltage    |
| 12<br>(G)                    | Ground | Parking brake switch signal                       | Input            | Ignition<br>switch<br>ON  | Parking brake applied                     | 0 V                |
|                              |        |   |                  |                           | Parking brake released                    | Battery voltage    |
| 14 <sup>1</sup><br>(Y)       | Ground | Steering switch output 1                          | —                | —                         | —   | —                  |

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

| Terminal No.<br>(Wire color) |        | Description                        |                  | Condition                   |  | Value<br>(Approx.)  |
|------------------------------|--------|------------------------------------|------------------|-----------------------------|--|---|
| +                            | -      | Signal name                        | Input/<br>Output |                             |  |   |
| 14 <sup>2</sup><br>(G)       | Ground | Steering switch output 1           | —                | —                           | —  | —   |
| 15 <sup>1</sup><br>(BR)      | Ground | Steering switch output 2           | —                | —                           | —  | —   |
| 15 <sup>2</sup><br>(W)       | Ground | Steering switch output 2           | —                | —                           | —  | —   |
| 16 <sup>1</sup><br>(G)       | —      | Steering switch output ground      | —                | —                           | —  | 0 V   |
| 16 <sup>2</sup><br>(B)       | —      | Steering switch output ground      | —                | —                           | —  | 0 V   |
| 19<br>(SB)                   | Ground | Tow mode switch signal             | Input            | Ignition switch ON          | Tow mode switch is pressed   | 0 V   |
|                              |        |                                    |                  |                             | Tow mode switch is released  | Battery voltage   |
| 21<br>(BG)                   | —      | Ignition signal                    | —                | Ignition switch ON or START | —  | Battery voltage   |
| 22<br>(W)                    | —      | Battery power supply               | —                | Ignition switch OFF         | —  | Battery voltage   |
| 23<br>(B)                    | Ground | Illumination control output signal | —                | Ignition switch ON          | —  | 0 V   |
| 24<br>(R)                    | Ground | Steering switch ground             | —                | Ignition switch ON          | —  | 0 V   |
| 25<br>(G)                    | Ground | Brake fluid level switch           | Input            | Ignition switch ON          | Brake fluid level low  | 0 V   |
|                              |        |                                    |                  |                             | Brake fluid level normal   | Battery voltage   |
| 26<br>(R)                    | Ground | Fuel level sensor ground           | —                | Ignition switch ON          | —  | 0 V   |
| 27<br>(W)                    | Ground | Fuel level sensor signal           | —                | —                           | —  | —   |
| 33<br>(BR)                   | Ground | Vehicle speed signal (2-pulse)     | Output           | Ignition switch ON          | Speedometer operated<br>[When vehicle speed is approx. 25 MPH (40 km/h)] | <b>NOTE:</b><br>The maximum voltage varies depending on the specification (destination unit). |
|                              |        |                                    |                  |                             |  |   |



JSNIA0015GB


MWI

O

P

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

| Terminal No.<br>(Wire color) |        | Description                       |                  | Condition          |  | Value<br>(Approx.)  |
|------------------------------|--------|-----------------------------------|------------------|--------------------|--|---|
| +                            | -      | Signal name                       | Input/<br>Output |                    |  | Value<br>(Approx.)  |
| 34<br>(GR)                   | Ground | Vehicle speed signal<br>(8-pulse) | Output           | Ignition switch ON | Speedometer operated<br>[When vehicle speed is approx. 25 MPH (40 km/h)] | <b>NOTE:</b><br>The maximum voltage varies depending on the specification (destination unit).<br><br>JSNIA0012GB |
| 38<br>(P)                    | Ground | CAN-L                             | —                | —                  | —  |   |
| 39<br>(L)                    | Ground | CAN-H                             | —                | —                  | —  | —   |
| 41<br>(LG)                   | Ground | Trip/Reset signal                 | Input            | Ignition switch ON | Trip/Reset switch is pressed   | 0 V   |
|                              |        |                                   |                  |                    | Other than the above   | 5 V   |
| 42<br>(Y)                    | Ground | Illumination down switch signal   | Input            | Ignition switch ON | Illumination switch down is pressed                                      | 0 V   |
|                              |        |                                   |                  |                    | Other than the above   | 5 V   |
| 47<br>(BR)                   | Ground | Illumination up switch signal     | Input            | Ignition switch ON | Illumination switch up is pressed  | 0 V   |
|                              |        |                                   |                  |                    | Other than the above   | 5 V   |
| 48<br>(G)                    | Ground | Switch ground                     | —                | —                  | —  | —   |
| 49<br>(P)                    | Ground | Washer fluid level switch signal  | Input            | Ignition switch ON | Washer fluid level switch ON   | 0 V   |
|                              |        |                                   |                  |                    | Washer fluid level switch OFF  | 5 V   |
| 52<br>(P)                    | Ground | O/D OFF switch signal             | Input            | Ignition switch ON | O/D OFF switch is pressed  | 0 V   |
|                              |        |                                   |                  |                    | O/D OFF switch is released   | Battery voltage   |

1: With base audio

2: Except base audio

## Fail-Safe

INFOID:0000000009174243

### FAIL-SAFE

The combination meter activates the fail-safe control if CAN communication with each unit is malfunctioning.

| Function                         |                          | Specifications   |  |
|----------------------------------|--------------------------|--|--|
| Speedometer                      |                          | Reset to zero by suspending communication.                   |  |
| Tachometer                       |                          |  |  |
| Engine coolant temperature gauge |                          |  |  |
| Illumination control             |                          | When suspending communication, changes to nighttime mode.    |  |
| Information display              | Odo/trip meter           | An indicated value is maintained at communications blackout. |  |
|                                  | Shift position indicator | The display turns OFF by suspending communication.           |  |
|                                  | Warning messages         | The display turns OFF by suspending communication.           |  |
| Buzzer                           |                          | The buzzer turns OFF by suspending communication.            |  |

# COMBINATION METER

## < ECU DIAGNOSIS INFORMATION >

|                             | Function                       | Specifications  |
|-----------------------------|--------------------------------|---|
| Warning lamp/indicator lamp | ABS warning lamp               | The lamp turns ON by suspending communication.        |
|                             | Slip indicator lamp            |   |
|                             | Brake warning lamp             |   |
|                             | O/D OFF indicator lamp         |   |
|                             | Malfunction indicator lamp     |   |
|                             | VDC OFF indicator lamp         |   |
|                             | EPS warning lamp               |   |
|                             | Low tire pressure warning lamp | The lamp blinking caused by suspending communication. |
|                             | High beam indicator lamp       | The lamp turns OFF by suspending communication.       |
|                             | Turn signal indicator lamp     |   |
|                             | Master warning lamp            |   |
|                             | Front lamp indicator lamp      |   |
|                             | Tow indicator lamp             |   |
|                             | Tail lamp indicator lamp       | The lamp turns off when disconnected.                 |
|                             | Air bag warning lamp           |   |
|                             | Charge warning lamp            |   |
|                             | Seat belt warning lamp         |   |
|                             | Security indicator lamp        |   |

## DTC Index

INFOID:000000009174244

| Display contents of CONSULT   | Diagnostic item is detected when...  | Refer to               |
|-------------------------------|--|------------------------|
| CAN COMM CIRCUIT<br>[U1000]   | When combination meter is not transmitting or receiving CAN communication signal for 2 seconds or more.                  | <a href="#">MWI-54</a> |
| CONTROL UNIT (CAN)<br>[U1010] | When detecting error during the initial diagnosis of the CAN controller of combination meter.                            | <a href="#">MWI-55</a> |
| VEHICLE SPEED CIRC<br>[B2205] | The abnormal vehicle speed signal is input from the ABS actuator and electric unit (control unit) for 2 seconds or more. | <a href="#">MWI-56</a> |
| TACHO METER<br>[B2267]        | If ECM continuously transmits abnormal engine speed signals for 2 seconds or more.                                       | <a href="#">MWI-57</a> |
| WATER TEMP METER<br>[B2268]   | If ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more.                        | <a href="#">MWI-58</a> |

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# **BCM (BODY CONTROL MODULE)**

< ECU DIAGNOSIS INFORMATION >

## **BCM (BODY CONTROL MODULE)**

### **List of ECU Reference**

INFOID:000000009174245

| ECU | Reference   |
|-----|---|
| BCM | <a href="#">BCS-30, "Reference Value"</a>               |
|     | <a href="#">BCS-55, "Wiring Diagram"</a>                |
|     | <a href="#">BCS-50, "Fail_Safe"</a>                     |
|     | <a href="#">BCS-50, "DTC_Inspection_Priority_Chart"</a> |
|     | <a href="#">BCS-52, "DTC_Index"</a>                     |

## METER SYSTEM

## < WIRING DIAGRAM >

# WIRING DIAGRAM

# METER SYSTEM

INFOID:000000009174246

A

B

C

D

E

F

G


H

1

M

O

P



METER

Revision: May 2013


MWI-31

2014 Pathfinder

## METER SYSTEM

## < WIRING DIAGRAM >

 : WITH TRAILER TOW




ABNWA1829GB

## **METER SYSTEM**

## < WIRING DIAGRAM >

[WO] : WITH OCCUPANT CLASSIFICATION SYSTEM




\* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

ABNWA1830GB

# METER SYSTEM


< WIRING DIAGRAM >



ABNW A1831GB

# METER SYSTEM

< WIRING DIAGRAM >



\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

ABNWIA1832GB

# METER SYSTEM


< WIRING DIAGRAM >

## METER CONNECTORS

|                 |                  |
|-----------------|------------------|
| Connector No.   | M4               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | WHITE            |

|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 8P           | BG            | -           |
| 13P          | W             | -           |

|                 |                 |
|-----------------|-----------------|
| Connector No.   | M6              |
| Connector Name  | TOW MODE SWITCH |
| Connector Color | GRAY            |

|              |               |             |
|--------------|---------------|-------------|
| Terminal No. | Color of Wire | Signal Name |
| 1            | SB            | -           |
| 4            | B             | -           |



|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M18                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | GREEN                     |

|              |               |                    |
|--------------|---------------|--------------------|
| Terminal No. | Color of Wire | Signal Name        |
| 18           | V             | SECURITY INDICATOR |

|                 |                   |
|-----------------|-------------------|
| Connector No.   | M23               |
| Connector Name  | COMBINATION METER |
| Connector Color | WHITE             |

|              |               |                   |
|--------------|---------------|-------------------|
| Terminal No. | Color of Wire | Signal Name       |
| 41           | LG            | TRIP/RESET        |
| 42           | Y             | ILLUMI DOWN SW    |
| 43           | -             | -                 |
| 44           | -             | -                 |
| 45           | -             | -                 |
| 46           | -             | -                 |
| 47           | BR            | ILLUMI UP SW      |
| 48           | G             | SW GND            |
| 49           | P             | WASHER LEVEL SW   |
| 50           | -             | -                 |
| 51           | -             | -                 |
| 52           | P             | O/D OFF/SPORTS SW |


 

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | M19                       |
| Connector Name  | BCM (BODY CONTROL MODULE) |
| Connector Color | BLACK                     |

|              |               |              |
|--------------|---------------|--------------|
| Terminal No. | Color of Wire | Signal Name  |
| 82           | W             | RL DOOR SW   |
| 93           | R             | RR DOOR SW   |
| 94           | G             | AS DOOR SW   |
| 96           | BG            | DR DOOR SW   |
| 97           | W             | BACK DOOR SW |

AANIA1140GB

# METER SYSTEM


< WIRING DIAGRAM >

| Terminal No. | Color of Wire | Signal Name                               | Terminal No. | Color of Wire | Signal Name     |
|--------------|---------------|---|--------------|---------------|-----------------|
| 12           | G             | PKB                                       | 25           | G             | BRAKE OIL SW    |
| 13           | -             | -   | 26           | R             | FUEL SENSOR GND |
| 14           | G             | STRG SW OUTPUT 1<br>(EXCEPT BASE AUDIO)   | 27           | W             | FUEL SENSOR     |
|              |               |   | 28           | -             | -               |
| 14           | Y             | STRG SW OUTPUT 1<br>(WITH BASE AUDIO)     | 29           | -             | -               |
|              |               |   | 30           | -             | -               |
| 15           | W             | STRG SW OUTPUT 2<br>(EXCEPT BASE AUDIO)   | 31           | -             | -               |
|              |               |   | 32           | -             | -               |
| 15           | BR            | STRG SW OUTPUT 2<br>(WITH BASE AUDIO)     | 33           | BR            | SPEED 2P/R      |
| 16           | B             | STRG SW OUTPUT GND<br>(EXCEPT BASE AUDIO) | 34           | GR            | SPEED 8P/R      |
|              |               |   | 35           | -             | -               |
| 16           | G             | STRG SW OUTPUT GND<br>(WITH BASE AUDIO)   | 36           | -             | -               |
| 17           | -             | -   | 37           | -             | -               |
| 18           | -             | -   | 38           | P             | CAN-L           |
| 19           | SB            | TOW/MODE SW                               | 39           | L             | CAN-H           |
| 20           | -             | -   | 40           | -             | -               |
| 21           | BG            | IGN                                       |              |               |                 |
| 22           | W             | BAT                                       |              |               |                 |
| 23           | B             | ILLUMI/CONT OUT                           |              |               |                 |
| 24           | R             | STRG SW GND                               |              |               |                 |

| Terminal No. | Color of Wire | Signal Name         |
|--------------|---------------|---------------------|
| 1            | B             | GND1                |
| 2            | B             | GND2                |
| 3            | P             | STRG SW INPUT 1     |
| 4            | BG            | STRG SW INPUT 2     |
| 5            | P             | ACC                 |
| 6            | V             | SECURITY            |
| 7            | R             | AIR BAG             |
| 8            | G             | AS BELT             |
| 9            | Y             | DR BUCKLE SW        |
| 10           | -             | -                   |
| 11           | BG            | ALTERNATOR (CHARGE) |

| Connector No. | Wire To Wire | Signal Name |
|---------------|--------------|-------------|
| 1             | R            | -           |
| 2             | B            | -           |
| 3             | BR           | -           |
| 4             | Y            | -           |
| 6             | G            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 24           | P             | -           |
| 31           | BG            | -           |
| 33           | R             | -           |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | R             | -           |
| 2            | B             | -           |
| 3            | BR            | -           |
| 4            | Y             | -           |
| 6            | G             | -           |

| Connector No. | Wire To Wire | Signal Name |
|---------------|--------------|-------------|
| 1             | R            | -           |
| 2             | B            | -           |
| 3             | BR           | -           |
| 4             | Y            | -           |
| 6             | G            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 24           | P             | -           |
| 31           | BG            | -           |
| 33           | R             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 24           | P             | -           |
| 31           | BG            | -           |
| 33           | R             | -           |

MWI  
MWI

O

P

M

K

L

G

T

D


A

ABNIA4746GB


# METER SYSTEM

< WIRING DIAGRAM >


|                 |                   |
|-----------------|-------------------|
| Connector No.   | M35               |
| Connector Name  | AIR BAG DIAGNOSIS |
| Connector Color | WHITE             |



| Terminal No. | Color of Wire | Signal Name       |
|--------------|---------------|-------------------|
| 23           | R             | AIRBAG W/L        |
| 24           | G             | SEATBELT REMINDER |
| 59           | L             | CAN-H             |
| 60           | P             | CAN-L             |



|                 |              |
|-----------------|--------------|
| Connector No.   | M31          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 44A          | W             | -           |
| 45A          | R             | -           |
| 65A          | W             | -           |
| 66A          | BG            | -           |
| 67A          | Y             | -           |
| 89A          | L             | -           |
| 90A          | P             | -           |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3G           | P             | -           |
| 12G          | G             | -           |
| 13G          | G             | -           |
| 33G          | G             | -           |
| 34G          | G             | -           |
| 35G          | P             | -           |
| 36G          | L             | -           |
| 49G          | P             | -           |
| 50G          | L             | -           |
| 54G          | BG            | -           |

ABNIA4747GB


# METER SYSTEM

< WIRING DIAGRAM >


|                 |                     |
|-----------------|---------------------|
| Connector No.   | M43                 |
| Connector Name  | JOINT CONNECTOR-M18 |
| Connector Color | WHITE               |



|                 |                     |
|-----------------|---------------------|
| Connector No.   | M43                 |
| Connector Name  | JOINT CONNECTOR-M18 |
| Connector Color | WHITE               |




|                 |                     |
|-----------------|---------------------|
| Connector No.   | M41                 |
| Connector Name  | JOINT CONNECTOR-M18 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | P             | -           |
| 2            | P             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | L             | -           |
| 2            | L             | -           |

| Terminal No. | Color of Wire | Signal Name   |
|--------------|---------------|---------------|
| 1            | P             | A/C AUTO AMP. |
| 2            | P             | WHITE         |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | R             | -           |
| 2            | B             | -           |
| 3            | LG            | -           |
| 4            | G             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | 15            | 14          |
| 2            | 13            | 12          |
| 3            | 11            | 10          |
| 4            | 9             | 8           |
| 5            | 7             | 6           |
| 6            | 5             | 4           |
| 7            | 3             | 2           |
| 8            | 1             | 1           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | 15            | 14          |
| 2            | 13            | 12          |
| 3            | 11            | 10          |
| 4            | 9             | 8           |
| 5            | 7             | 6           |
| 6            | 5             | 4           |
| 7            | 3             | 2           |
| 8            | 1             | 1           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | R             | -           |
| 2            | B             | -           |
| 3            | BR            | -           |
| 4            | Y             | -           |
| 5            | G             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | 15            | 14          |
| 2            | 13            | 12          |
| 3            | 11            | 10          |
| 4            | 9             | 8           |
| 5            | 7             | 6           |
| 6            | 5             | 4           |
| 7            | 3             | 2           |
| 8            | 1             | 1           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | 15            | 14          |
| 2            | 13            | 12          |
| 3            | 11            | 10          |
| 4            | 9             | 8           |
| 5            | 7             | 6           |
| 6            | 5             | 4           |
| 7            | 3             | 2           |
| 8            | 1             | 1           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | 2             | CAN-H       |
| 7            | G             | AMB SENS    |
| 21           | P             | CAN-L       |
| 26           | G             | SENS GND    |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | 2             | CAN-H       |
| 7            | G             | AMB SENS    |
| 21           | P             | CAN-L       |
| 26           | G             | SENS GND    |


A B C D E F G H I J K L M P Q R S T U V W Z MWI

ABNIA4748GB

# METER SYSTEM

< WIRING DIAGRAM >


|                 |                    |
|-----------------|--------------------|
| Connector No.   | M78                |
| Connector Name  | CVT SHIFT SELECTOR |
| Connector Color | WHITE              |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | P             | -           |
| 2            | B             | -           |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | R             | -           |
| 2            | B             | -           |
| 3            | LG            | -           |
| 4            | G             | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | M83          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 17           | L             | -           |
| 18           | P             | -           |
| 21           | G             | -           |
| 22           | R             | -           |



|                 |                   |
|-----------------|-------------------|
| Connector No.   | M140              |
| Connector Name  | TRIP RESET SWITCH |
| Connector Color | WHITE             |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 17           | BR            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 14           | B             | -           |
| 15           | GR            | -           |
| 17           | BR            | -           |

|                 |                             |
|-----------------|-----------------------------|
| Connector No.   | M113                        |
| Connector Name  | ILLUMINATION CONTROL SWITCH |
| Connector Color | WHITE                       |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | R             | -           |
| 2            | B             | -           |
| 3            | BR            | -           |
| 4            | Y             | -           |
| 5            | -             | -           |
| 6            | G             | -           |

ABNIA4749GB

# METER SYSTEM

< WIRING DIAGRAM >


|                 |                     |
|-----------------|---------------------|
| Connector No.   | E22                 |
| Connector Name  | JOINT CONNECTOR-M09 |
| Connector Color | WHITE               |



|                 |              |
|-----------------|--------------|
| Connector No.   | E22          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|                 |                     |
|-----------------|---------------------|
| Connector No.   | M170                |
| Connector Name  | JOINT CONNECTOR-M09 |
| Connector Color | WHITE               |




| Terminal No. | Color of Wire | Signal Name | Terminal No. | Color of Wire | Signal Name         |
|--------------|---------------|-------------|--------------|---------------|---------------------|
| 1            | G             | -           | 97           | 101           | POWER               |
| 2            | W             | -           | 105          | 09            | SUPPLY (EVAP)       |
| 9            | P             | -           | 106          | 10            | CONTROL SYSTEM      |
| 10           | L             | -           | 107          | W             | PRESSURE SENSOR,    |
| 11           | P             | -           | 108          | 11            | ENGINE OIL PRESSURE |
| 12           | G             | -           | 109          | 115           | SENSOR (SENSOR)     |
| 13           | W             | -           | 110          | 19            | -                   |
| 14           | P             | -           | 111          | 17            | -                   |
| 15           | L             | -           | 112          | G             | -                   |
| 16           | P             | -           | 113          | P             | CAN-L               |
| 17           | G             | -           | 114          | L             | CAN-H               |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 12           | G             | -           |
| 17           | G             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 12           | G             | -           |
| 17           | G             | -           |


| Terminal No. | Color of Wire | Signal Name   |
|--------------|---------------|---|
| 107          | W             | SENSOR POWER SUPPLY (EVAP)  |
| 112          | G             | SENSOR GROUND (EVAP CONTROL SYSTEM, ENGINE OIL PRESSURE SENSOR, ENGINE OIL PRESSURE SENSOR) |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 122          | WIRE TO WIRE  | -           |
| 126          | WHITE         | -           |
| 127          | WHITE         | -           |
| 128          | WHITE         | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 101          | P             | CAN-L       |
| 102          | W             | CAN-H       |
| 103          | WIRE TO WIRE  | -           |
| 104          | WHITE         | -           |
| 105          | WHITE         | -           |
| 106          | WHITE         | -           |
| 107          | W             | -           |
| 108          | WIRE TO WIRE  | -           |
| 109          | WHITE         | -           |
| 110          | WHITE         | -           |
| 111          | WHITE         | -           |
| 112          | WHITE         | -           |
| 113          | WHITE         | -           |
| 114          | WHITE         | -           |
| 115          | WHITE         | -           |
| 116          | WHITE         | -           |
| 117          | WHITE         | -           |
| 118          | WHITE         | -           |
| 119          | WHITE         | -           |
| 120          | WHITE         | -           |
| 121          | WHITE         | -           |
| 122          | WHITE         | -           |
| 123          | WHITE         | -           |
| 124          | WHITE         | -           |
| 125          | WHITE         | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 101          | P             | -           |
| 102          | W             | -           |
| 103          | WIRE TO WIRE  | -           |
| 104          | WHITE         | -           |
| 105          | WHITE         | -           |
| 106          | WHITE         | -           |
| 107          | W             | -           |
| 108          | WIRE TO WIRE  | -           |
| 109          | WHITE         | -           |
| 110          | WHITE         | -           |
| 111          | WHITE         | -           |
| 112          | WHITE         | -           |
| 113          | WHITE         | -           |
| 114          | WHITE         | -           |
| 115          | WHITE         | -           |
| 116          | WHITE         | -           |
| 117          | WHITE         | -           |
| 118          | WHITE         | -           |
| 119          | WHITE         | -           |
| 120          | WHITE         | -           |
| 121          | WHITE         | -           |
| 122          | WHITE         | -           |
| 123          | WHITE         | -           |
| 124          | WHITE         | -           |
| 125          | WHITE         | -           |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 122          | WIRE TO WIRE  | -           |
| 126          | WHITE         | -           |
| 127          | WHITE         | -           |
| 128          | WHITE         | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 101          | P             | -           |
| 102          | W             | -           |
| 103          | WIRE TO WIRE  | -           |
| 104          | WHITE         | -           |
| 105          | WHITE         | -           |
| 106          | WHITE         | -           |
| 107          | W             | -           |
| 108          | WIRE TO WIRE  | -           |
| 109          | WHITE         | -           |
| 110          | WHITE         | -           |
| 111          | WHITE         | -           |
| 112          | WHITE         | -           |
| 113          | WHITE         | -           |
| 114          | WHITE         | -           |
| 115          | WHITE         | -           |
| 116          | WHITE         | -           |
| 117          | WHITE         | -           |
| 118          | WHITE         | -           |
| 119          | WHITE         | -           |
| 120          | WHITE         | -           |
| 121          | WHITE         | -           |
| 122          | WHITE         | -           |
| 123          | WHITE         | -           |
| 124          | WHITE         | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 101          | P             | -           |
| 102          | W             | -           |
| 103          | WIRE TO WIRE  | -           |
| 104          | WHITE         | -           |
| 105          | WHITE         | -           |
| 106          | WHITE         | -           |
| 107          | W             | -           |
| 108          | WIRE TO WIRE  | -           |
| 109          | WHITE         | -           |
| 110          | WHITE         | -           |
| 111          | WHITE         | -           |
| 112          | WHITE         | -           |
| 113          | WHITE         | -           |
| 114          | WHITE         | -           |
| 115          | WHITE         | -           |
| 116          | WHITE         | -           |
| 117          | WHITE         | -           |
| 118          | WHITE         | -           |
| 119          | WHITE         | -           |
| 120          | WHITE         | -           |
| 121          | WHITE         | -           |
| 122          | WHITE         | -           |
| 123          | WHITE         | -           |
| 124          | WHITE         | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 101          | P             | -           |
| 102          | W             | -           |
| 103          | WIRE TO WIRE  | -           |
| 104          | WHITE         | -           |
| 105          | WHITE         | -           |
| 106          | WHITE         | -           |
| 107          | W             | -           |
| 108          | WIRE TO WIRE  | -           |
| 109          | WHITE         | -           |
| 110          | WHITE         | -           |
| 111          | WHITE         | -           |
| 112          | WHITE         | -           |
| 113          | WHITE         | -           |
| 114          | WHITE         | -           |
| 115          | WHITE         | -           |
| 116          | WHITE         | -           |
| 117          | WHITE         | -           |
| 118          | WHITE         | -           |
| 119          | WHITE         | -           |
| 120          | WHITE         | -           |
| 121          | WHITE         | -           |
| 122          | WHITE         | -           |
| 123          | WHITE         | -           |
| 124          | WHITE         | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 101          | P             | -           |
| 102          | W             | -           |
| 103          | WIRE TO WIRE  | -           |
| 104          | WHITE         | -           |
| 105          | WHITE         | -           |
| 106          | WHITE         | -           |
| 107          | W             | -           |
| 108          | WIRE TO WIRE  | -           |
| 109          | WHITE         | -           |
| 110          | WHITE         | -           |
| 111          | WHITE         | -           |
| 112          | WHITE         | -           |
| 113          | WHITE         | -           |
| 114          | WHITE         | -           |
| 115          | WHITE         | -           |
| 116          | WHITE         | -           |
| 117          | WHITE         | -           |
| 118          | WHITE         | -           |
| 119          | WHITE         | -           |
| 120          | WHITE         | -           |
| 121          | WHITE         | -           |
| 122          | WHITE         | -           |
| 123          | WHITE         | -           |
| 124          | WHITE         | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 101          | P             | -           |
| 102          | W             | -           |
| 103          | WIRE TO WIRE  | -           |
| 104          | WHITE         | -           |
| 105          | WHITE         | -           |
| 106          | WHITE         | -           |
| 107          | W             | -           |
| 108          | WIRE TO WIRE  | -           |
| 109          | WHITE         | -           |
| 110          | WHITE         | -           |
| 111          | WHITE         | -           |
| 112          | WHITE         | -           |
| 113          | WHITE         | -           |
| 114          | WHITE         | -           |
| 115          | WHITE         | -           |
| 116          | WHITE         | -           |
| 117          | WHITE         | -           |
| 118          | WHITE         | -           |
| 119          | WHITE         | -           |
| 120          | WHITE         | -           |
| 121          | WHITE         | -           |
| 122          | WHITE         | -           |
| 123          | WHITE         | -           |
| 124          | WHITE         | -           |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 101          | P             | -           |
| 102          | W             | -           |
| 103          | WIRE TO WIRE  | -           |
| 104          | WHITE         | -           |
| 105          | WHITE         | -           |
| 106          | WHITE         | -           |
| 107          | W             | -           |
| 108          | WIRE TO WIRE  | -           |
| 109          | WHITE         | -           |
| 110          | WHITE         | -           |
| 111          | WHITE         | -           |
| 112          | WHITE         | -           |
| 113          | WHITE         | -           |
| 114          | WHITE         | -           |
| 115          | WHITE         | -           |
| 116          | WHITE         | -           |
| 117          | WHITE         | -           |
| 118          | WHITE         | -           |
| 119          | WHITE         | -           |
| 120          | WHITE         | -           |
| 121          | WHITE         | -           |
| 122          | WHITE         | -           |
| 123          | WHITE         | -           |
| 124          | WHITE         | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 101          | P             | -           |
| 102          | W             | -           |
| 103          | WIRE TO WIRE  | -           |
| 104          | WHITE         | -           |
| 105          | WHITE         | -           |
| 106          | WHITE         | -           |
| 107          | W             | -           |
| 108          | WIRE TO WIRE  | -           |
| 109          | WHITE         | -           |
| 110          | WHITE         | -           |
| 111          | WHITE         | -           |
| 112          | WHITE         | -           |
| 113          | WHITE         | -           |
| 114          | WHITE         | -           |
| 115          | WHITE         | -           |
| 116          | WHITE         | -           |
| 117          | WHITE         | -           |
| 118          | WHITE         | -           |
| 119          | WHITE         | -           |
| 120          | WHITE         | -           |
| 121          | WHITE         | -           |
| 122          | WHITE         | -           |
| 123          | WHITE         | -           |
| 124          | WHITE         | -           |

# METER SYSTEM

< WIRING DIAGRAM >

|                 |                     |
|-----------------|---------------------|
| Connector No.   | E45                 |
| Connector Name  | JOINT CONNECTOR-E12 |
| Connector Color | BLUE                |




|                 |                     |
|-----------------|---------------------|
| Connector No.   | E44                 |
| Connector Name  | JOINT CONNECTOR-E01 |
| Connector Color | WHITE               |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | L             | -           |
| 2            | L             | -           |
| 3            | L             | -           |
| 7            | P             | -           |
| 8            | P             | -           |
| 9            | P             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2            | W             | -           |
| 3            | W             | -           |
| 15           | GR            | -           |
| 17           | B             | -           |
| 27           | G             | -           |
| 28           | G             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | LG            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | L             | -           |
| 2            | L             | -           |
| 3            | L             | -           |
| 7            | P             | -           |
| 8            | P             | -           |
| 9            | P             | -           |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6            | 5             | 3 2 1       |
| 5            | 4             | 3 2 1       |
| 4            | 3             | 3 2 1       |
| 3            | 2             | 3 2 1       |
| 2            | 1             | 3 2 1       |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6            | 5             | 3 2 1       |
| 5            | 4             | 3 2 1       |
| 4            | 3             | 3 2 1       |
| 3            | 2             | 3 2 1       |
| 2            | 1             | 3 2 1       |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | LG            | -           |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | L             | -           |
| 2            | L             | -           |
| 3            | L             | -           |
| 4            | L             | -           |




ABNIA4751GB

# METER SYSTEM

< WIRING DIAGRAM >



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3G           | P             | -           |
| 12G          | P             | -           |
| 13G          | W             | -           |
| 33G          | L_G           | -           |
| 34G          | W             | -           |
| 35G          | P             | -           |
| 36G          | L             | -           |
| 49G          | W             | -           |
| 50G          | G             | -           |
| 54G          | P             | -           |



|                 |                |
|-----------------|----------------|
| Connector No.   | E206           |
| Connector Name  | AMBIENT SENSOR |
| Connector Color | BLACK          |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | G             | -           |
| 2            | B             | -           |

|                 |                           |
|-----------------|---------------------------|
| Connector No.   | E208                      |
| Connector Name  | WASHER FLUID LEVEL SWITCH |
| Connector Color | BLACK                     |



ABNIA4752GB

|                 |           |
|-----------------|-----------|
| Connector No.   | E204      |
| Connector Name  | GENERATOR |
| Connector Color | -         |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5            | B             | -           |
| 6            | -             | -           |

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
MWI  
MWI

# METER SYSTEM

< WIRING DIAGRAM >

|                 |                                   |
|-----------------|-----------------------------------|
| Connector No.   | F15                               |
| Connector Name  | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Color | BLACK                             |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2            | GR            | —           |
| 23           | P             | CAN-L       |
| 33           | L             | CAN-H       |

|                 |           |
|-----------------|-----------|
| Connector No.   | F7        |
| Connector Name  | GENERATOR |
| Connector Color | BLACK     |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 18           | L             | —           |
| 19           | Y             | —           |
| 21           | G             | —           |

|                 |              |
|-----------------|--------------|
| Connector No.   | E209         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 23           | P             | —           |
| 33           | L             | —           |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | BR            | —           |
| 2            | LG            | —           |
| 3            | Y             | —           |

|                 |       |
|-----------------|-------|
| Connector No.   | F51   |
| Connector Name  | ECM   |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | BR            | —           |
| 2            | LG            | —           |
| 9            | P             | —           |
| 10           | L             | —           |
| 16           | GR            | —           |



ABNIA4753GB

## METER SYSTEM

## < WIRING DIAGRAM >

|                 |                     |
|-----------------|---------------------|
| Connector No.   | B11                 |
| Connector Name  | JOINT CONNECTOR-B09 |
| Connector Color | WHITE               |




The logo consists of a black square containing a white triangle pointing upwards. Inside the triangle is a stylized letter 'G'.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | P             | —           |
| 2            | P             | —           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | B17                 |
| Connector Name  | JOINT CONNECTOR-B12 |
| Connector Color | WHITE               |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | L             | -           |
| 2            | L             | -           |

|                 |                                  |
|-----------------|----------------------------------|
| Connector No.   | B9                               |
| Connector Name  | AIR BAG DIAGNOSIS<br>SENSOR UNIT |
| Connector Color | YELLOW                           |




 HS

| Terminal No. | Color of Wire | Signal Name                  |
|--------------|---------------|------------------------------|
| 29           | GR            | LH SEAT BELT BUCKLE SWITCH + |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | B16                 |
| Connector Name  | JOINT CONNECTOR-B11 |
| Connector Color | WHITE               |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | P             | -           |
| 2            | P             | -           |

|                 |                      |
|-----------------|----------------------|
| Connector No.   | B8                   |
| Connector Name  | FRONT DOOR SWITCH LH |
| Connector Color | WHITE                |



 H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | L             | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | B12                 |
| Connector Name  | JOINT CONNECTOR-B10 |
| Connector Color | WHITE               |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | L             | -           |
| 2            | L             | -           |

ABNIA4754GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
**MV**  
O  
P

# METER SYSTEM

< WIRING DIAGRAM >





AANIA1150GB



# METER SYSTEM

< WIRING DIAGRAM >

|                 |                                      |
|-----------------|--------------------------------------|
| Connector No.   | B72                                  |
| Connector Name  | FUEL LEVEL SENSOR UNIT AND FUEL PUMP |
| Connector Color | GRAY                                 |



|                 |              |
|-----------------|--------------|
| Connector No.   | B74          |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|                 |                     |
|-----------------|---------------------|
| Connector No.   | B80                 |
| Connector Name  | JOINT CONNECTOR-B15 |
| Connector Color | WHITE               |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2            | G             | -           |
| 5            | V             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | LG            | -           |
| 4            | B             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | —             | —           |
| 2            | —             | —           |
| 3            | —             | —           |
| 4            | —             | —           |
| 5            | —             | —           |
| 6            | —             | —           |
| 7            | —             | —           |
| 8            | —             | —           |
| 9            | —             | —           |
| 10           | —             | —           |
| 11           | —             | —           |
| 12           | —             | —           |
| 13           | —             | —           |
| 14           | —             | —           |
| 15           | —             | —           |
| 16           | —             | —           |
| 17           | —             | —           |
| 18           | —             | —           |
| 19           | —             | —           |
| 20           | —             | —           |
| 21           | —             | —           |
| 22           | —             | —           |
| 23           | —             | —           |
| 24           | —             | —           |
| 25           | —             | —           |
| 26           | —             | —           |
| 27           | —             | —           |
| 28           | —             | —           |
| 29           | —             | —           |
| 30           | —             | —           |
| 31           | —             | —           |
| 32           | —             | —           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | —             | —           |
| 2            | —             | —           |
| 3            | —             | —           |
| 4            | —             | —           |
| 5            | —             | —           |
| 6            | —             | —           |
| 7            | —             | —           |
| 8            | —             | —           |
| 9            | —             | —           |
| 10           | —             | —           |
| 11           | —             | —           |
| 12           | —             | —           |
| 13           | —             | —           |
| 14           | —             | —           |
| 15           | —             | —           |
| 16           | —             | —           |
| 17           | —             | —           |
| 18           | —             | —           |
| 19           | —             | —           |
| 20           | —             | —           |
| 21           | —             | —           |
| 22           | —             | —           |
| 23           | —             | —           |
| 24           | —             | —           |
| 25           | —             | —           |
| 26           | —             | —           |
| 27           | —             | —           |
| 28           | —             | —           |
| 29           | —             | —           |
| 30           | —             | —           |
| 31           | —             | —           |
| 32           | —             | —           |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1            | —             | —           |
| 2            | —             | —           |
| 3            | —             | —           |
| 4            | —             | —           |
| 5            | —             | —           |
| 6            | —             | —           |
| 7            | —             | —           |
| 8            | —             | —           |
| 9            | —             | —           |
| 10           | —             | —           |
| 11           | —             | —           |
| 12           | —             | —           |
| 13           | —             | —           |
| 14           | —             | —           |
| 15           | —             | —           |
| 16           | —             | —           |
| 17           | —             | —           |
| 18           | —             | —           |
| 19           | —             | —           |
| 20           | —             | —           |
| 21           | —             | —           |
| 22           | —             | —           |
| 23           | —             | —           |
| 24           | —             | —           |
| 25           | —             | —           |
| 26           | —             | —           |
| 27           | —             | —           |
| 28           | —             | —           |
| 29           | —             | —           |
| 30           | —             | —           |
| 31           | —             | —           |
| 32           | —             | —           |

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
MWI


# METER SYSTEM

< WIRING DIAGRAM >

|                 |                     |
|-----------------|---------------------|
| Connector No.   | B116                |
| Connector Name  | REAR DOOR SWITCH RH |
| Connector Color | WHITE               |




|                 |              |
|-----------------|--------------|
| Connector No.   | B124         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 18           | L             | -           |
| 19           | P             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | LG            | -           |
| 4            | GR            | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | B220         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




|                 |                                       |
|-----------------|---------------------------------------|
| Connector No.   | B200                                  |
| Connector Name  | SEAT BELT BUCKLE SWITCH (DRIVER SEAT) |
| Connector Color | WHITE                                 |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | LG            | -           |
| 4            | GR            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | GR            | -           |
| 4            | BG            | -           |

|                 |              |
|-----------------|--------------|
| Connector No.   | B300         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | LG            | -           |
| 4            | GR            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | GR            | -           |
| 4            | GR            | -           |


# METER SYSTEM

< WIRING DIAGRAM >


|                 |              |
|-----------------|--------------|
| Connector No.   | D501         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



|                 |   |
|-----------------|---|
| Connector No.   | B303  |
| Connector Name  | SEAT BELT BUCKLE SWITCH<br>(PASSENGER SEAT) |
| Connector Color | WHITE                                       |



|                 |              |
|-----------------|--------------|
| Connector No.   | D552         |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |




| Terminal No. | Color of Wire | Signal Name                |
|--------------|---------------|----------------------------|
| 11           | LG            | -(WITHOUT POWER BACK DOOR) |
| 11           | P             | -(WITH POWER BACK DOOR)    |
| 23           | B             | -                          |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | GR            | -           |
| 4            | BG            | -           |
|              |               |             |

| Terminal No. | Color of Wire | Signal Name                |
|--------------|---------------|----------------------------|
| 6            | B             | -                          |
| 12           | LG            | -(WITHOUT POWER BACK DOOR) |
| 12           | P             | -(WITH POWER BACK DOOR)    |

|                 |  |
|-----------------|--|
| Connector No.   | D557   |
| Connector Name  | BACK DOOR LOCK ASSEMBLY (WITH POWER BACK DOOR) |
| Connector Color | WHITE  |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 7            | G             | -           |
| 8            | B             | -           |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 3            | G             | -           |
| 4            | B             | -           |

| Terminal No. | Color of Wire | Signal Name                |
|--------------|---------------|----------------------------|
| 1            | LG            | -(WITHOUT POWER BACK DOOR) |
| 1            | P             | -(WITH POWER BACK DOOR)    |



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
MWI  
○  
□  
×

# COMPASS


< WIRING DIAGRAM >

COMPASS

Wiring Diagram

INFOID:0000000009174247

COMPASS




AANWA0704GB

# COMPASS

**< WIRING DIAGRAM >**


## COMPASS CONNECTORS

|                 |              |
|-----------------|--------------|
| Connector No.   | M1           |
| Connector Name  | WIRE TO WIRE |
| Connector Color | WHITE        |



H.S.

|                 |                  |
|-----------------|------------------|
| Connector No.   | M3               |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | WHITE            |



H.S.

|                 |                  |
|-----------------|------------------|
| Connector No.   | M68              |
| Connector Name  | FUSE BLOCK (J/B) |
| Connector Color | BROWN            |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5            | B             | -           |
| 9            | W             | -           |
| 10           | LG            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6N           | W             | -           |
| 12           | 1             | 2           |
| 13           | 2             | 3           |
| 14           | 3             | 4           |
| 15           | 4             | 5           |
| 16           | 5             | 6           |
| 17           | 6             | 7           |
| 18           | 7             | 8           |
| 19           | 8             | 9           |
| 20           | 9             | 10          |
| 21           | 10            | 11          |
| 22           | 11            | 12          |
| 23           | 12            | 13          |
| 24           | 13            | 14          |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2R           | LG            | -           |
| 3A           | LG            | -           |
| 3B           | LG            | -           |
| 3C           | LG            | -           |
| 3D           | LG            | -           |
| 3E           | LG            | -           |
| 3F           | LG            | -           |
| 3G           | LG            | -           |
| 3H           | LG            | -           |
| 3I           | LG            | -           |
| 3J           | LG            | -           |
| 3K           | LG            | -           |
| 3L           | LG            | -           |
| 3M           | LG            | -           |
| 3N           | LG            | -           |
| 3O           | LG            | -           |
| 3P           | LG            | -           |
| 3Q           | LG            | -           |
| 3R           | LG            | -           |
| 3S           | LG            | -           |
| 3T           | LG            | -           |
| 3U           | LG            | -           |
| 3V           | LG            | -           |
| 3W           | LG            | -           |
| 3X           | LG            | -           |
| 3Y           | LG            | -           |
| 3Z           | LG            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2R           | LG            | -           |
| 3A           | LG            | -           |
| 3B           | LG            | -           |
| 3C           | LG            | -           |
| 3D           | LG            | -           |
| 3E           | LG            | -           |
| 3F           | LG            | -           |
| 3G           | LG            | -           |
| 3H           | LG            | -           |
| 3I           | LG            | -           |
| 3J           | LG            | -           |
| 3K           | LG            | -           |
| 3L           | LG            | -           |
| 3M           | LG            | -           |
| 3N           | LG            | -           |
| 3O           | LG            | -           |
| 3P           | LG            | -           |
| 3Q           | LG            | -           |
| 3R           | LG            | -           |
| 3S           | LG            | -           |
| 3T           | LG            | -           |
| 3U           | LG            | -           |
| 3V           | LG            | -           |
| 3W           | LG            | -           |
| 3X           | LG            | -           |
| 3Y           | LG            | -           |
| 3Z           | LG            | -           |

|                 |                     |
|-----------------|---------------------|
| Connector No.   | M181                |
| Connector Name  | JOINT CONNECTOR-M36 |
| Connector Color | WHITE               |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5            | B             | -           |
| 9            | G             | -           |
| 10           | W             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2            | W             | -           |
| 4            | W             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 6            | W             | -           |
| 8            | B             | -           |
| 10           | G             | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2R           | LG            | -           |
| 3A           | LG            | -           |
| 3B           | LG            | -           |
| 3C           | LG            | -           |
| 3D           | LG            | -           |
| 3E           | LG            | -           |
| 3F           | LG            | -           |
| 3G           | LG            | -           |
| 3H           | LG            | -           |
| 3I           | LG            | -           |
| 3J           | LG            | -           |
| 3K           | LG            | -           |
| 3L           | LG            | -           |
| 3M           | LG            | -           |
| 3N           | LG            | -           |
| 3O           | LG            | -           |
| 3P           | LG            | -           |
| 3Q           | LG            | -           |
| 3R           | LG            | -           |
| 3S           | LG            | -           |
| 3T           | LG            | -           |
| 3U           | LG            | -           |
| 3V           | LG            | -           |
| 3W           | LG            | -           |
| 3X           | LG            | -           |
| 3Y           | LG            | -           |
| 3Z           | LG            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2R           | LG            | -           |
| 3A           | LG            | -           |
| 3B           | LG            | -           |
| 3C           | LG            | -           |
| 3D           | LG            | -           |
| 3E           | LG            | -           |
| 3F           | LG            | -           |
| 3G           | LG            | -           |
| 3H           | LG            | -           |
| 3I           | LG            | -           |
| 3J           | LG            | -           |
| 3K           | LG            | -           |
| 3L           | LG            | -           |
| 3M           | LG            | -           |
| 3N           | LG            | -           |
| 3O           | LG            | -           |
| 3P           | LG            | -           |
| 3Q           | LG            | -           |
| 3R           | LG            | -           |
| 3S           | LG            | -           |
| 3T           | LG            | -           |
| 3U           | LG            | -           |
| 3V           | LG            | -           |
| 3W           | LG            | -           |
| 3X           | LG            | -           |
| 3Y           | LG            | -           |
| 3Z           | LG            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2R           | LG            | -           |
| 3A           | LG            | -           |
| 3B           | LG            | -           |
| 3C           | LG            | -           |
| 3D           | LG            | -           |
| 3E           | LG            | -           |
| 3F           | LG            | -           |
| 3G           | LG            | -           |
| 3H           | LG            | -           |
| 3I           | LG            | -           |
| 3J           | LG            | -           |
| 3K           | LG            | -           |
| 3L           | LG            | -           |
| 3M           | LG            | -           |
| 3N           | LG            | -           |
| 3O           | LG            | -           |
| 3P           | LG            | -           |
| 3Q           | LG            | -           |
| 3R           | LG            | -           |
| 3S           | LG            | -           |
| 3T           | LG            | -           |
| 3U           | LG            | -           |
| 3V           | LG            | -           |
| 3W           | LG            | -           |
| 3X           | LG            | -           |
| 3Y           | LG            | -           |
| 3Z           | LG            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2R           | LG            | -           |
| 3A           | LG            | -           |
| 3B           | LG            | -           |
| 3C           | LG            | -           |
| 3D           | LG            | -           |
| 3E           | LG            | -           |
| 3F           | LG            | -           |
| 3G           | LG            | -           |
| 3H           | LG            | -           |
| 3I           | LG            | -           |
| 3J           | LG            | -           |
| 3K           | LG            | -           |
| 3L           | LG            | -           |
| 3M           | LG            | -           |
| 3N           | LG            | -           |
| 3O           | LG            | -           |
| 3P           | LG            | -           |
| 3Q           | LG            | -           |
| 3R           | LG            | -           |
| 3S           | LG            | -           |
| 3T           | LG            | -           |
| 3U           | LG            | -           |
| 3V           | LG            | -           |
| 3W           | LG            | -           |
| 3X           | LG            | -           |
| 3Y           | LG            | -           |
| 3Z           | LG            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2R           | LG            | -           |
| 3A           | LG            | -           |
| 3B           | LG            | -           |
| 3C           | LG            | -           |
| 3D           | LG            | -           |
| 3E           | LG            | -           |
| 3F           | LG            | -           |
| 3G           | LG            | -           |
| 3H           | LG            | -           |
| 3I           | LG            | -           |
| 3J           | LG            | -           |
| 3K           | LG            | -           |
| 3L           | LG            | -           |
| 3M           | LG            | -           |
| 3N           | LG            | -           |
| 3O           | LG            | -           |
| 3P           | LG            | -           |
| 3Q           | LG            | -           |
| 3R           | LG            | -           |
| 3S           | LG            | -           |
| 3T           | LG            | -           |
| 3U           | LG            | -           |
| 3V           | LG            | -           |
| 3W           | LG            | -           |
| 3X           | LG            | -           |
| 3Y           | LG            | -           |
| 3Z           | LG            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2R           | LG            | -           |
| 3A           | LG            | -           |
| 3B           | LG            | -           |
| 3C           | LG            | -           |
| 3D           | LG            | -           |
| 3E           | LG            | -           |
| 3F           | LG            | -           |
| 3G           | LG            | -           |
| 3H           | LG            | -           |
| 3I           | LG            | -           |
| 3J           | LG            | -           |
| 3K           | LG            | -           |
| 3L           | LG            | -           |
| 3M           | LG            | -           |
| 3N           | LG            | -           |
| 3O           | LG            | -           |
| 3P           | LG            | -           |
| 3Q           | LG            | -           |
| 3R           | LG            | -           |
| 3S           | LG            | -           |
| 3T           | LG            | -           |
| 3U           | LG            | -           |
| 3V           | LG            | -           |
| 3W           | LG            | -           |
| 3X           | LG            | -           |
| 3Y           | LG            | -           |
| 3Z           | LG            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2R           | LG            | -           |
| 3A           | LG            | -           |
| 3B           | LG            | -           |
| 3C           | LG            | -           |
| 3D           | LG            | -           |
| 3E           | LG            | -           |
| 3F           | LG            | -           |
| 3G           | LG            | -           |
| 3H           | LG            | -           |
| 3I           | LG            | -           |
| 3J           | LG            | -           |
| 3K           | LG            | -           |
| 3L           | LG            | -           |
| 3M           | LG            | -           |
| 3N           | LG            | -           |
| 3O           | LG            | -           |
| 3P           | LG            | -           |
| 3Q           | LG            | -           |
| 3R           | LG            | -           |
| 3S           | LG            | -           |
| 3T           | LG            | -           |
| 3U           | LG            | -           |
| 3V           | LG            | -           |
| 3W           | LG            | -           |
| 3X           | LG            | -           |
| 3Y           | LG            | -           |
| 3Z           | LG            | -           |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 2R           | LG            | -           |
| 3A           | LG            | -           |
| 3B           | LG            | -           |
| 3C           | LG            | -           |
| 3D           | LG            | -           |
| 3E           | LG            | -           |
| 3F           | LG            | -           |
| 3G           | LG            | -           |
| 3H           | LG            | -           |
| 3I           | LG            | -           |
| 3J           | LG            | -           |
| 3K           | LG            | -           |
| 3L           | LG            | -           |
| 3M           | LG            | -           |
| 3N           | LG            | -           |
| 3O           | LG            | -           |
| 3P           | LG            | -           |
| 3Q           | LG            | -           |
| 3R           | LG            | -           |
| 3S           | LG            | -           |
| 3T           | LG            | -           |
| 3U           | LG            | -           |
| 3V           | LG            | -           |
| 3W           | LG            | -           |
| 3X           | LG            | -           |
| 3Y           | LG            | -           |
| 3Z           | LG            | -           |

| Terminal No. | Color of Wire | Signal Name |
| --- | --- | --- |

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work flow

INFOID:000000009174248

OVERALL SEQUENCE



AWNIA2375GB

DETAILED FLOW

#### 1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

#### 2. CHECK SYMPTOM

- Check the symptom based on the information obtained from the customer.
- Check if any other malfunctions are present.

>> GO TO 3.

#### 3. CHECK CONSULT SELF-DIAGNOSIS RESULTS

Connect CONSULT and perform self-diagnosis. Refer to [MWI-29, "DTC Index"](#).

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

Are self-diagnosis results normal?

- YES    >> GO TO 4.
- NO      >> GO TO 5.

A

## 4. NARROW DOWN MALFUNCTIONING PARTS BY SYMPTOM DIAGNOSIS

Perform symptom diagnosis and narrow down the malfunctioning parts.

B

>> GO TO 5.

C

## 5. REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace malfunctioning parts.

D

**NOTE:**

If DTC is displayed, erase DTC after repairing or replacing malfunctioning parts.

E

>> GO TO 6.

F

## 6. FINAL CHECK

Check that the warning buzzer in the combination meter operates normally.

G

Does it operate normally?

H

- YES    >> Inspection End.

I

- NO      >> GO TO 1.

J

K

L

M

**MWI**

O

P

## U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

# DTC/CIRCUIT DIAGNOSIS

## U1000 CAN COMM CIRCUIT

### DTC Logic

INFOID:000000009174249

### DTC DETECTION LOGIC

| DTC   | CONSULT Display          | Detection Condition  | Possible Cause    |
|-------|--------------------------|--|-------------------|
| U1000 | CAN COMM CIRC<br>[U1000] | When combination meter is not receiving CAN communication signals for 2 seconds or more. | Combination meter |

### Diagnosis Procedure

INFOID:000000009174250

#### 1. CHECK CAN COMMUNICATION

Select Self-Diagnosis Results mode for METER/M&A with CONSULT.

>> GO TO LAN system. Refer to [LAN-20, "Trouble Diagnosis Flow Chart"](#).

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

## U1010 CONTROL UNIT (CAN)

### Description

INFOID:000000009174251

Initial diagnosis of combination meter.

### DTC Logic

INFOID:000000009174252

### DTC DETECTION LOGIC

| DTC   | CONSULT Display               | Detection Condition  | Possible Cause    |
|-------|-------------------------------|--|-------------------|
| U1010 | CONTROL UNIT (CAN)<br>[U1010] | When detecting error during the initial diagnosis of the CAN controller<br>of combination meter. | Combination meter |

### Diagnosis Procedure

INFOID:000000009174253

#### 1.REPLACE COMBINATION METER

When DTC U1010 is detected, replace combination meter. Refer to [MWI-82, "Removal and Installation".](#)

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

## B2205 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

### B2205 VEHICLE SPEED

#### Description

INFOID:0000000009174254

The ABS actuator and electric unit (control unit) provides a vehicle speed signal to the combination meter via CAN communication lines.

#### DTC Logic

INFOID:0000000009174255

| DTC   | CONSULT Display            | Detection Condition   | Possible Cause  |
|-------|----------------------------|---|---|
| B2205 | VEHICLE SPEED CIRC [B2205] | Malfunction is detected when an erroneous speed signal is received for 2 seconds or more. | <ul style="list-style-type: none"><li>Combination meter</li><li>ABS actuator and electric unit (control unit)</li></ul> |

#### Diagnosis Procedure

INFOID:0000000009174256

##### 1. CHECK COMBINATION METER INPUT SIGNAL

1. Start engine and select METER/M&A on CONSULT.
2. Using SPEED METER on Data Monitor, compare the value of DATA MONITOR with speedometer pointer of combination meter. Speedometer and DATA MONITOR indications should be close.

Is the inspection result normal?

YES    >> Perform ABS actuator and electric unit (control unit) self-diagnosis. Refer to [BRC-32, "CONSULT Function"](#).

NO    >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).

## B2267 ENGINE SPEED

< DTC/CIRCUIT DIAGNOSIS >

### B2267 ENGINE SPEED

#### Description

INFOID:000000009174257

The engine speed signal is transmitted from ECM to the combination meter via CAN communication.

#### DTC Logic

INFOID:000000009174258

#### DTC DETECTION LOGIC

| DTC   | CONSULT Display        | Detection Condition  | Possible Cause   |
|-------|------------------------|--|--|
| B2267 | TACHO METER<br>[B2267] | ECM continuously transmits abnormal engine speed signals for 2 seconds or more | <ul style="list-style-type: none"><li>• Crankshaft position sensor (POS)</li><li>• ECM</li></ul> |

#### Diagnosis Procedure

INFOID:000000009174259

##### 1 .PERFORM SELF-DIAGNOSIS OF ECM

Perform Self-Diagnostic Result of ECM, and repair or replace malfunctioning parts.

>> Refer to [EC-61, "CONSULT Function"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
MWI  
O  
P

## B2268 WATER TEMP

< DTC/CIRCUIT DIAGNOSIS >

### B2268 WATER TEMP

#### Description

INFOID:0000000009174260

The engine coolant temperature signal is transmitted from ECM to the combination meter via CAN communication.

#### DTC Logic

INFOID:0000000009174261

#### DTC DETECTION LOGIC

| DTC   | CONSULT Display             | Detection condition   | Probable Cause  |
|-------|-----------------------------|---|---|
| B2268 | WATER TEMP METER<br>[B2268] | ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more | <ul style="list-style-type: none"><li>• Engine coolant temperature sensor</li><li>• ECM</li></ul> |

#### Diagnosis Procedure

INFOID:0000000009174262

##### 1. PERFORM SELF-DIAGNOSIS OF ECM

Perform Self-Diagnosis Result of ECM, and repair or replace malfunctioning parts.

>> Refer to [EC-61, "CONSULT Function"](#).

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

### COMBINATION METER : Diagnosis Procedure

INFOID:000000009174263

Regarding Wiring Diagram information, refer to [MWI-31, "Wiring Diagram"](#).

#### 1. CHECK FUSES

Check that the following fuses are not blown.

| Unit              | Power source                | Fuse No. |
|-------------------|-----------------------------|----------|
| Combination meter | Battery                     | 13       |
|                   |                             | 65       |
|                   | Ignition switch ON or START | 31       |

Is the fuse blown?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit.

#### 2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect combination meter connector.
2. Check voltage between combination meter harness connector M24 terminals 5, 21, 22 and ground.

| Terminals |          | Ignition switch position |                 |                 |                 |
|-----------|----------|--------------------------|-----------------|-----------------|-----------------|
| (+) (-)   |          | OFF                      | ACC             | ON              | START           |
| Connector | Terminal |                          |                 |                 |                 |
| M24       | 22       | Ground                   | Battery voltage | Battery voltage | Battery voltage |
|           | 21       |                          | 0V              | 0V              | Battery voltage |
|           | 5        |                          | 0V              | Battery voltage | 0V              |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

#### 3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Check continuity between combination meter harness connector M24 terminals 1, 2 and ground.

| Terminals |          | Continuity |
|-----------|----------|------------|
| (+)       | (-)      |            |
| Connector | Terminal |            |
| M24       | 1        | Ground     |
|           | 2        |            |

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

#### BCM (BODY CONTROL MODULE)

### BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:000000009764355

Regarding Wiring Diagram information, refer to [BCS-55, "Wiring Diagram"](#).

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## 1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

| Terminal No. | Signal name                | Fuse and fusible link No. |
|--------------|----------------------------|---------------------------|
| 139          | Fusible link battery power | O (40A)                   |
| 131          | BCM battery fuse           | 1 (10A)                   |

Is the fuse or fusible link blown?

- YES    >> Replace the blown fuse or fusible link after repairing the affected circuit.  
NO      >> GO TO 2

## 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M81.
2. Check voltage between BCM connector M81 terminals 131, 139 and ground.

| BCM       |          | Ground | Voltage<br>(Approx.) |
|-----------|----------|--------|----------------------|
| Connector | Terminal |        |                      |
| M81       | 131      | —      | Battery voltage      |
|           | 139      |        |                      |

Is the inspection result normal?

- YES    >> GO TO 3  
NO      >> Repair or replace harness or connectors.

## 3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M81 terminals 134, 143 and ground.

| BCM       |          | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal |        |            |
| M81       | 134      | —      | Yes        |
|           | 143      |        |            |

Is the inspection result normal?

- YES    >> Inspection End.  
NO      >> Repair or replace harness or connectors.

# ILLUMINATION CONTROL SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## ILLUMINATION CONTROL SWITCH SIGNAL CIRCUIT

### Diagnosis Procedure

INFOID:000000009174265

Regarding Wiring Diagram information, refer to [MWI-31, "Wiring Diagram"](#).

#### 1.CHECK METER ILLUMINATION CONTROL SWITCH SIGNAL

1. Turn ignition switch ON.
2. Check voltage between the following terminals of the illumination control switch harness connector M113.

| Illumination control switch |           | Condition                                       | Voltage (Approx.) |
|-----------------------------|-----------|---|-------------------|
| Connector                   | Terminals |   |                   |
|                             | (+)       | (-)   |                   |
| M113                        | 4         | When illumination control switch (-) is pressed | 0 V               |
|                             |           | Other than the above                            | 5 V               |
|                             | 6         | When illumination control switch (+) is pressed | 0 V               |
|                             |           | Other than the above                            | 5 V               |

Is the inspection result normal?

YES >> Inspection End.  
NO >> GO TO 2.

#### 2.CHECK METER ILLUMINATION CONTROL SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter harness connector M23 and illumination control switch harness connector M113.
3. Check continuity between combination meter harness connector M23 and illumination control switch harness connector M113.

| Combination meter |          | Illumination control switch |          | Continuity |
|-------------------|----------|-----------------------------|----------|------------|
| Connector         | Terminal | Connector                   | Terminal |            |
| M23               | 42       | M113                        | 4        | Yes        |
|                   | 47       |                             | 3        |            |
|                   | 48       |                             | 6        |            |

4. Check continuity between combination meter harness connector and ground.

| Combination meter |          | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector         | Terminal |        |            |
| M23               | 42       | Ground | No         |
|                   | 47       |        |            |
|                   | 48       |        |            |

Is the inspection result normal?

YES >> Check illumination control switch. Refer to [MWI-61, "Component Inspection"](#).  
NO >> Repair or replace harness or connector.

### Component Inspection

INFOID:000000009174266

#### 1.CHECK METER ILLUMINATION CONTROL SWITCH

1. Turn ignition switch OFF.
2. Disconnect illumination control switch connector.
3. Check illumination control switch.

## ILLUMINATION CONTROL SWITCH SIGNAL CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

| Illumination control switch |   | Condition                                       | Continuity |  |
|-----------------------------|---|---|------------|--|
| Terminals                   |   |   |            |  |
| 4                           | 6 | When illumination control switch (-) is pressed | Yes        |  |
|                             |   | Other than the above                            | No         |  |
| 3                           |   | When illumination control switch (+) is pressed | Yes        |  |
|                             |   | Other than the above                            | No         |  |

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace illumination control switch. Refer to [MWI-83, "Removal and Installation"](#).

# TRIP RESET SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## TRIP RESET SWITCH SIGNAL CIRCUIT

### Diagnosis Procedure

INFOID:000000009174267

Regarding Wiring Diagram information, refer to [MWI-31, "Wiring Diagram"](#).

#### 1.CHECK TRIP RESET SWITCH SIGNAL

1. Turn ignition switch ON.
2. Check voltage between the following terminals of the trip reset switch harness connector M140.

| Trip reset switch |           |     | Condition                         | Voltage<br>(Approx.) |  |  |
|-------------------|-----------|-----|-----------------------------------|----------------------|--|--|
| Connector         | Terminals |     |                                   |                      |  |  |
|                   | (+)       | (-) |                                   |                      |  |  |
| M140              | 3         | 4   | When trip reset switch is pressed | 0 V                  |  |  |
|                   |           |     | Other than the above              | 5 V                  |  |  |

Is the inspection result normal?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2.CHECK TRIP RESET SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter harness connector M23 and trip reset switch harness connector M140.
3. Check continuity between combination meter harness connector M23 and trip reset switch harness connector M140.

| Combination meter |          | Trip reset switch |          | Continuity |
|-------------------|----------|-------------------|----------|------------|
| Connector         | Terminal | Connector         | Terminal |            |
| M23               | 41       | M140              | 3        |            |
|                   | 48       |                   | 4        | Yes        |

4. Check continuity between combination meter harness connector and ground.

| Combination meter |          | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector         | Terminal |        |            |
| M23               | 41       |        |            |
|                   | 48       |        | No         |

Is the inspection result normal?

- YES >> Check the trip reset switch. Refer to [MWI-63, "Component Inspection"](#).  
NO >> Repair or replace harness or connectors.

### Component Inspection

INFOID:000000009174268

#### 1.CHECK TRIP RESET SWITCH

1. Turn ignition switch OFF.
2. Disconnect trip reset switch connector.
3. Check trip reset switch.

| Trip reset switch | Condition | Continuity |
|-------------------|-----------|------------|
| Terminals         |           |            |

## TRIP RESET SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

|   |   |                                   |     |
|---|---|-----------------------------------|-----|
| 3 | 4 | When trip reset switch is pressed | Yes |
|   |   | Other than the above              | No  |

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace trip reset switch. Refer to [MWI-83, "Removal and Installation"](#).

# FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## FUEL LEVEL SENSOR SIGNAL CIRCUIT

### Description

INFOID:0000000009174269

The fuel level sensor unit and fuel pump detects the approximate fuel level in the fuel tank and transmits the fuel level signal to the combination meter.

### Component Function Check

INFOID:0000000009174270

#### 1. COMBINATION METER INPUT SIGNAL

1. Select METER/M&A on CONSULT.
2. Using FUEL METER of DATA MONITOR, compare the value of DATA MONITOR with fuel gauge pointer of combination meter.

| Fuel gauge pointer | Fuel tank volume [L]<br>(Approx.) |
|--------------------|-----------------------------------|
| Full               | 70.6                              |
| 3/4                | 54.1                              |
| 1/2                | 36.4                              |
| 1/4                | 20                                |
| Empty              | 0                                 |

Does the data monitor value approximately match the fuel gauge indication?

YES >> Inspection End.

NO >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).

### Diagnosis Procedure

INFOID:0000000009174271

Regarding Wiring Diagram information, refer to [MWI-31, "Wiring Diagram"](#).

#### 1. CHECK HARNESS CONNECTOR

1. Turn ignition switch OFF.
2. Check combination meter and fuel level sensor unit terminals (meter-side and harness-side) for poor connection.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace terminals or connectors.

#### 2. CHECK FUEL LEVEL SENSOR UNIT CIRCUIT

1. Disconnect combination meter harness connector M24 and fuel level sensor unit harness connector B72.
2. Check continuity between combination meter harness connector M24 and fuel level sensor unit and fuel pump harness connector B72.

MWI

| Fuel level sensor unit and fuel pump |          | Combination meter |          | Continuity |
|--------------------------------------|----------|-------------------|----------|------------|
| Connector                            | Terminal | Connector         | Terminal |            |
| B72                                  | 5        | M24               | 27       | Yes        |

3. Check continuity between fuel level sensor unit and fuel pump harness connector and ground.

O

| Connector | Terminal | Ground | Continuity |
|-----------|----------|--------|------------|
| B72       | 5        |        | No         |

P

Is the inspection result normal?

YES >> GO TO 3.

# FUEL LEVEL SENSOR SIGNAL CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

NO    >> Repair or replace harness or connectors.

## 3.CHECK FUEL LEVEL SENSOR UNIT GROUND CIRCUIT

1. Check continuity between combination meter harness connector M24 and fuel level sensor unit and fuel pump harness connector B72.

| Connector | Terminal | Connector | Terminal | Continuity |
|-----------|----------|-----------|----------|------------|
| B72       | 2        | M24       | 26       | Yes        |

2. Check continuity between fuel level sensor unit and fuel pump harness connector and ground.

| Connector | Terminal | Ground | Continuity |
|-----------|----------|--------|------------|
| B72       | 2        |        | No         |

Is the inspection result normal?

YES    >> GO TO 4.

NO    >> Repair or replace harness or connectors.

## 4.CHECK INSTALLATION CONDITION

Check fuel level sensor unit installation, and check whether the float arm interferes or binds with any of the internal components in the fuel tank.

Is the inspection result normal?

YES    >> Inspection End.

NO    >> Install the fuel level sensor unit properly. Refer to [FL-6, "Removal and Installation"](#).

## Component Inspection

INFOID:000000009174272

### 1.REMOVE FUEL LEVEL SENSOR UNIT

Remove the fuel level sensor unit. Refer to [FL-6, "Removal and Installation"](#).

>> GO TO 2.

### 2.CHECK FUEL LEVEL SENSOR UNIT AND FUEL PUMP

Check the resistance between terminals 2 and 5.


| Terminal | Float position<br>mm (in) |       |            | Resistance value<br>(Approx.) |
|----------|---------------------------|-------|------------|-------------------------------|
| 2        | *1                        | Empty | 15.7 (0.6) | 283Ω                          |
|          | *2                        | Full  | 133 (5.2)  | 51Ω                           |

\*1 and \*2: When float arm is in contact with stopper.

Is inspection result OK?

YES    >> Inspection End.

NO    >> Replace fuel level sensor unit and fuel pump. Refer to [FL-6, "Removal and Installation"](#).



# WASHER FLUID LEVEL SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## WASHER FLUID LEVEL SWITCH CIRCUIT

### Description

INFOID:0000000009174273

Transmits the washer fluid level switch signal to the combination meter.

### Diagnosis Procedure

INFOID:0000000009174274

Regarding Wiring Diagram information, refer to [MWI-31, "Wiring Diagram"](#).

#### 1.CHECK WASHER FLUID LEVEL SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter harness connector M24 and washer fluid level switch harness connector E208.
3. Check continuity between combination meter harness connector M24 and washer fluid level switch harness connector E208.

| Combination meter |          | Washer fluid level switch |          | Continuity |
|-------------------|----------|---------------------------|----------|------------|
| Connector         | Terminal | Connector                 | Terminal |            |
| M24               | 49       | E208                      | 1        | Yes        |

4. Check continuity between combination meter harness connector and ground.

| Combination meter |          | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector         | Terminal |        |            |
| M24               | 49       |        | No         |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

#### 2.CHECK WASHER FLUID LEVEL SWITCH GROUND CIRCUIT

Check continuity between washer fluid level switch connector and ground.

| Washer fluid level switch |          | Ground | Continuity |
|---------------------------|----------|--------|------------|
| Connector                 | Terminal |        |            |
| E208                      | 2        |        | Yes        |

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

### Component Inspection

INFOID:0000000009174275

#### 1.CHECK WASHER FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect washer fluid level switch connector.
3. Check washer fluid level switch.

| Washer fluid level switch |   | Condition                     | Continuity |
|---------------------------|---|-------------------------------|------------|
| Terminals                 |   |                               |            |
| 1                         | 2 | Washer fluid level switch ON  | Yes        |
|                           |   | Washer fluid level switch OFF | No         |

Is the inspection result normal?

## **WASHER FLUID LEVEL SWITCH CIRCUIT**

< DTC/CIRCUIT DIAGNOSIS >

YES    >> Inspection End.

NO    >> Replace washer fluid level switch. Refer to [WW-57, "Removal and Installation".](#)

---

# PARKING BRAKE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## PARKING BRAKE SWITCH SIGNAL CIRCUIT

### Description

INFOID:0000000009174276

Transmits the parking brake switch signal to the combination meter.

### Component Function Check

INFOID:0000000009174277

#### 1. COMBINATION METER INPUT SIGNAL

1. Start engine.
2. Monitor BRAKE W/L in DATA MONITOR while applying and releasing the parking brake.

| Condition              | CONSULT |
|------------------------|---------|
| Parking brake applied  | : ON    |
| Parking brake released | : OFF   |

>> Inspection End.

### Diagnosis Procedure

INFOID:0000000009174278

Regarding Wiring Diagram information, refer to [MWI-31, "Wiring Diagram"](#).

#### 1. CHECK PARKING BRAKE SWITCH CIRCUIT

1. Disconnect combination meter harness connector M24 and parking brake switch harness connector E52.
2. Check continuity between combination meter harness connector M24 terminal 12 and parking brake switch harness connector E52 terminal 1.

| Combination meter |          | Parking brake switch |          | Continuity |
|-------------------|----------|----------------------|----------|------------|
| Connector         | Terminal | Connector            | Terminal |            |
| M24               | 12       | E52                  | 1        | Yes        |

3. Check continuity between combination meter harness connector M24 terminal 12 and ground.

| Combination meter |          | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector         | Terminal |        |            |
| M24               | 12       |        |            |

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

### Component Inspection

INFOID:0000000009174279

#### 1. CHECK PARKING BRAKE SWITCH

Check continuity between parking brake switch terminal 1 and switch case ground.

| Component            | Terminal | Condition              | Continuity |
|----------------------|----------|------------------------|------------|
| Parking brake switch | 1        | Parking brake applied  | Yes        |
|                      |          | Parking brake released | No         |

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace parking brake switch. Refer to [PB-7, "Exploded View"](#).

MWI

# STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## STEERING SWITCH

### Description

INFOID:0000000009174280

When one of the steering switches is pushed, the resistance in the steering switch changes the signal to identify which button is controlling the information display.

### Diagnosis Procedure

INFOID:0000000009174281

Regarding Wiring Diagram information, refer to [MWI-31, "Wiring Diagram"](#).

#### 1. CHECK STEERING SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter harness connector M24 and spiral cable harness connector M30.
3. Check continuity between combination meter harness connector M24 and spiral cable harness connector M30.

| Combination meter |          | Spiral cable |          | Continuity |
|-------------------|----------|--------------|----------|------------|
| Connector         | Terminal | Connector    | Terminal |            |
| M24               | 3        | M30          | 24       | Yes        |
|                   | 4        |              | 31       |            |
|                   | 24       |              | 33       |            |

4. Check continuity between combination meter harness connector M24 and ground.

| Combination meter |          | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector         | Terminal |        |            |
| M24               | 3        |        | No         |
|                   | 4        |        |            |
|                   | 24       |        |            |

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

### Component Inspection

INFOID:0000000009174282

#### 1. CHECK STEERING SWITCH RESISTANCE

Check resistance between the following steering switch terminals.

| Terminal | Signal name | Condition  | Resistance ( $\Omega$ )<br>(Approx.) |
|----------|-------------|--|--------------------------------------|
| 14       | Display     | Depress DISPLAY switch. <input type="checkbox"/>   | 2023                                 |
|          | Back        | Depress BACK switch.        | 723                                  |
| 15       | Enter       | Depress ENTER switch.  | 2023                                 |
|          | Menu Up     | Depress ENTER switch up.    | 121                                  |
|          | Menu Down   | Depress ENTER switch down.  | 321                                  |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace steering wheel switch. Refer to [AV-368, "Removal and Installation"](#).

# STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

## 2.CHECK SPIRAL CABLE

Check continuity between the following spiral cable terminals.

| Terminals |    | Continuity |
|-----------|----|------------|
| 14        | 24 | Yes        |
| 15        | 31 |            |
| 17        | 33 |            |

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace spiral cable. Refer to [SR-15, "Removal and Installation".](#)

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# THE FUEL GAUGE INDICATOR DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### THE FUEL GAUGE INDICATOR DOES NOT OPERATE

#### Description

INFOID:000000009174283

Fuel gauge will not indicate from a certain position.

#### Diagnosis Procedure

INFOID:000000009174284

##### 1.CHECK COMBINATION METER INPUT SIGNAL

Perform component function check. Refer to [MWI-65, "Component Function Check"](#).

Does monitor value match fuel gauge reading?

YES >> GO TO 2.

NO >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).

##### 2.CHECK FUEL LEVEL SENSOR UNIT CIRCUITS

Check the fuel level sensor circuits. Refer to [MWI-65, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

##### 3.CHECK FUEL LEVEL SENSOR UNIT

Perform a unit check for the fuel level sensor unit. Refer to [MWI-66, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace fuel level sensor unit. Refer to [FL-6, "Removal and Installation"](#).

##### 4.CHECK FLOAT INTERFERENCE

Check that the float arm does not interfere with or binds to other components in the fuel tank.

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning parts.

# THE ILLUMINATION CONTROL SWITCH IS INOPERATIVE

< SYMPTOM DIAGNOSIS >

## THE ILLUMINATION CONTROL SWITCH IS INOPERATIVE

### Description

INFOID:0000000009174285

The illumination control switch is inoperative when pressed.

### Diagnosis Procedure

INFOID:0000000009174286

#### 1.CHECK ILLUMINATION CONTROL SWITCH CIRCUIT

Check the illumination control switch circuit. Refer to [MWI-61, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES    >> GO TO 2.

NO      >> Repair or replace harness or connectors.

#### 2.CHECK ILLUMINATION CONTROL SWITCH

Perform a unit check for the illumination control switch. Refer to [MWI-61, "Component Inspection"](#).

Is the inspection result normal?

YES    >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).

NO      >> Replace illumination control switch. Refer to [MWI-83, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# THE TRIP RESET SWITCH IS INOPERATIVE

< SYMPTOM DIAGNOSIS >

## THE TRIP RESET SWITCH IS INOPERATIVE

### Description

INFOID:000000009174287

The trip reset switch is inoperative when pressed.

### Diagnosis Procedure

INFOID:000000009174288

#### 1.CHECK TRIP RESET SWITCH CIRCUIT

Check the trip reset switch circuit. Refer to [MWI-63, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES    >> GO TO 2.

NO      >> Repair or replace harness or connectors.

#### 2.CHECK TRIP RESET SWITCH

Perform a unit check for the trip reset switch. Refer to [MWI-63, "Component Inspection"](#).

Is the inspection result normal?

YES    >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).

NO      >> Replace trip reset switch. Refer to [MWI-83, "Removal and Installation"](#).

# THE OIL PRESSURE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

## THE OIL PRESSURE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

### Description

INFOID:000000009174289

- The low oil pressure warning message stays on when oil pressure is normal.
- The low oil pressure warning message stays off when oil pressure is low.

### Diagnosis Procedure

INFOID:000000009174290

#### 1. CHECK COMBINATION METER INPUT

1. Start the engine and select METER/M&A on CONSULT.
2. Observe OIL W/L DATA MONITOR and the operation of the low oil pressure warning message in the information display.

| Component                        | Condition      | CONSULT |
|----------------------------------|----------------|---------|
| Low oil pressure warning message | Engine running | OFF     |

Is the inspection result normal?

- YES    >> Perform ECM self-diagnosis. Refer to [EC-61, "CONSULT Function"](#).  
NO     >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

## THE PARKING BRAKE RELEASE WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

### Description

INFOID:000000009174291

- The parking brake warning is displayed during vehicle travel even though the parking brake is released.
- The parking brake warning is not displayed even though driving the vehicle with the parking brake applied.

### Diagnosis Procedure

INFOID:000000009174292

#### 1. CHECK PARKING BRAKE WARNING LAMP OPERATION

1. Start engine.
2. Check the operation of the brake warning lamp while operating the parking brake.

| Condition              | Warning lamp status |
|------------------------|---------------------|
| Parking brake applied  | ON                  |
| Parking brake released | OFF                 |

Is the inspection result normal?

- YES    >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).  
NO     >> GO TO 2.

#### 2. CHECK PARKING BRAKE SWITCH SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Check the parking brake switch signal circuit. Refer to [MWI-69, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES    >> GO TO 3.  
NO     >> Repair or replace harness or connectors.

#### 3. CHECK PARKING BRAKE SWITCH UNIT

Perform a unit check for the parking brake switch. Refer to [MWI-69, "Component Inspection"](#).

Is the inspection result normal?

- YES    >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).  
NO     >> Replace parking brake switch. Refer to [PB-7, "Exploded View"](#).

# THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

## THE LOW WASHER FLUID WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

### Description

INFOID:000000009174293

- The warning is still displayed even after washer fluid is added.
- The warning is not displayed even though the washer tank is empty.

### Diagnosis Procedure

INFOID:000000009174294

#### 1. CHECK WASHER FLUID LEVEL SWITCH SIGNAL CIRCUIT

Check the washer fluid level switch signal circuit. Refer to [MWI-67, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES    >> GO TO 2.  
NO      >> Repair or replace harness or connectors.

#### 2. CHECK WASHER FLUID LEVEL SWITCH UNIT

Perform a unit check for the washer fluid level switch. Refer to [MWI-67, "Component Inspection"](#).

Is the inspection result normal?

- YES    >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).  
NO      >> Replace washer fluid level switch. Refer to [WW-57, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

## THE DOOR OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

### Description

INFOID:000000009174295

- The door open warning is displayed even though all of the doors are closed.
- The door open warning is not displayed even though a door is ajar.

### Diagnosis Procedure

INFOID:000000009174296

#### 1. CHECK BCM INPUT SIGNAL

Check the BCM input signal. Refer to [DLK-170, "Component Function Check"](#).

Is the inspection result normal?

- YES    >> GO TO 2.  
NO      >> GO TO 3.

#### 2. CHECK COMBINATION METER INPUT SIGNAL

Select the METER/M&A Data Monitor and check the DOOR W/L monitor value.

| DOOR W/L    |       |
|-------------|-------|
| Door open   | : On  |
| Door closed | : Off |

Is the inspection result normal?

- YES    >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).  
NO      >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

#### 3. CHECK DOOR SWITCH SIGNAL CIRCUIT

Check the door switch signal circuit. Refer to [DLK-170, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES    >> GO TO 4.  
NO      >> Repair or replace harness or connectors.

#### 4. CHECK DOOR SWITCH

Perform a unit check for the door switch. Refer to [DLK-171, "Component Inspection"](#).

Is the inspection result normal?

- YES    >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).  
NO      >> Replace applicable door switch. Refer to [DLK-313, "Removal and Installation"](#).

# THE LIFTGATE OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

< SYMPTOM DIAGNOSIS >

## THE LIFTGATE OPEN WARNING CONTINUES DISPLAYING, OR DOES NOT DISPLAY

### Description

INFOID:000000009174297

- The liftgate open warning is displayed continuously even though the liftgate is closed.
- The liftgate open warning is not displayed even though the liftgate is open.

### Diagnosis Procedure

INFOID:000000009174298

#### 1.CHECK BCM INPUT SIGNAL

Check the BCM input signal. Refer to [DLK-172, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> GO TO 3.

#### 2.CHECK COMBINATION METER INPUT SIGNAL

Select the METER/M&A Data Monitor and check the DOOR W/L monitor value.

| DOOR W/L |       |
|----------|-------|
| Open     | : On  |
| Closed   | : Off |

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).  
NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

#### 3.CHECK BACK DOOR SWITCH SIGNAL CIRCUIT

Check the back door switch signal circuit. Refer to [DLK-172, "Diagnosis Procedure \(With Power Back Door\)"](#) or [DLK-173, "Diagnosis Procedure \(Without Power Back Door\)"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace harness or connector.

#### 4.CHECK BACK DOOR SWITCH

Perform a unit check for the back door switch. Refer to [DLK-174, "Component Inspection \(With Power Back Door\)"](#) or [DLK-175, "Component Inspection \(Without Power Back Door\)"](#).

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).  
NO >> Replace back door switch. Refer to [DLK-308, "DOOR LOCK : Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

# THE STEERING SWITCHES ARE INOPERATIVE

< SYMPTOM DIAGNOSIS >

## THE STEERING SWITCHES ARE INOPERATIVE

### Description

INFOID:0000000009174299

One or more of the steering switches to control the information display are inoperative.

### Diagnosis Procedure

INFOID:0000000009174300

#### 1.CHECK STEERING SWITCH CIRCUIT

Check steering switch circuit. Refer to [MWI-70, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

#### 2.CHECK STEERING SWITCH RESISTANCE

Check steering switch resistance. Refer to [MWI-70, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace steering switch. Refer to [AV-48, "Removal and Installation"](#).

#### 3.CHECK SPIRAL CABLE

Check spiral cable for continuity. Refer to [MWI-70, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).

NO >> Replace spiral cable. Refer to [SR-15, "Removal and Installation"](#).

# THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

< SYMPTOM DIAGNOSIS >

## THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

### Description

INFOID:000000009174301

- The displayed ambient air temperature is higher than the actual temperature.
- The displayed ambient air temperature is lower than the actual temperature.

### Diagnosis Procedure

INFOID:000000009174302

#### 1. CHECK COMBINATION METER INPUT SIGNAL

1. Select METER/M&A on CONSULT.
2. Check OUTSIDE TEMP of DATA MONITOR.

Does the ambient temperature approximately match the CONSULT display?

YES >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).

NO >> GO TO 2.

#### 2. CHECK AMBIENT SENSOR SIGNAL CIRCUIT

Check the ambient sensor signal circuit. Refer to [HAC-86, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

#### 3. CHECK AMBIENT SENSOR

Check the ambient sensor. Refer to [HAC-87, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-82, "Removal and Installation"](#).

NO >> Replace ambient sensor. Refer to [HAC-158, "Removal and Installation"](#).

MWI

## COMBINATION METER

< REMOVAL AND INSTALLATION >

# REMOVAL AND INSTALLATION


## COMBINATION METER

### Removal and Installation

INFOID:000000009174303

#### REMOVAL

1. Remove cluster lid A. Refer to [IP-21, "Removal and Installation"](#).
2. Remove the combination meter screws (A).
3. Disconnect the harness connector from the combination meter (1) and remove.



#### INSTALLATION

Installation is in the reverse order of removal.

# TRIP RESET AND ILLUMINATION CONTROL SWITCH

< REMOVAL AND INSTALLATION >

## TRIP RESET AND ILLUMINATION CONTROL SWITCH


### Removal and Installation

INFOID:000000009174304


#### ILLUMINATION CONTROL SWITCH

##### Removal

1. Remove cluster lid A. Refer to [IP-21, "Removal and Installation"](#).
2. Release the harness connector from cluster lid A.



3. Release the clips (A) and remove illumination control switch (1) through the front of cluster lid A (2).




##### Installation

Installation is in the reverse order of removal.

#### TRIP RESET SWITCH

##### Removal


1. Remove cluster lid A. Refer to [IP-21, "Removal and Installation"](#).
2. Release the harness connector from cluster lid A.



## TRIP RESET AND ILLUMINATION CONTROL SWITCH

### < REMOVAL AND INSTALLATION >

3. Release the clips (A) and remove trip reset switch (1) through the front of cluster lid A (2).



ALNIA1440ZZ

### Installation

Installation is in the reverse order of removal.