

SECTION **PWC**

POWER WINDOW CONTROL SYSTEM

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

CONTENTS

LH FRONT ONLY AUTO DOWN	WIRING DIAGRAM17
PRECAUTION 6	POWER WINDOW SYSTEM17
PRECAUTIONS 6	Wiring Diagram - With Left Front Only Auto Down...17
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"6	BASIC INSPECTION26
Precaution for Work6	DIAGNOSIS AND REPAIR WORKFLOW26
PREPARATION 7	Work Flow26
PREPARATION 7	DTC/CIRCUIT DIAGNOSIS28
Special Service Tool7	POWER SUPPLY AND GROUND CIRCUIT28
SYSTEM DESCRIPTION 8	BCM28
COMPONENT PARTS 8	BCM : Diagnosis Procedure28
Component Parts Location8	POWER WINDOW MAIN SWITCH28
Component Description9	POWER WINDOW MAIN SWITCH : Description ...28
SYSTEM10	POWER WINDOW MAIN SWITCH : Component Function Check29
System Diagram10	POWER WINDOW MAIN SWITCH : Diagnosis Procedure29
System Description10	POWER WINDOW MAIN SWITCH : Component Inspection32
Fail-safe11	FRONT POWER WINDOW SWITCH33
DIAGNOSIS SYSTEM (BCM)12	FRONT POWER WINDOW SWITCH : Description33
COMMON ITEM12	FRONT POWER WINDOW SWITCH : Component Function Check33
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)12	FRONT POWER WINDOW SWITCH : Diagnosis Procedure33
RETAINED PWR13	FRONT POWER WINDOW SWITCH : Component Inspection35
RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)13	REAR POWER WINDOW SWITCH35
ECU DIAGNOSIS INFORMATION14	REAR POWER WINDOW SWITCH : Description...35
BCM (BODY CONTROL MODULE)14	REAR POWER WINDOW SWITCH : Component Function Check35
List of ECU Reference14	REAR POWER WINDOW SWITCH : Diagnosis Procedure35
POWER WINDOW MAIN SWITCH15	
Reference Value15	

PWC

REAR POWER WINDOW SWITCH : Component Inspection	37	WHEN POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure	53
POWER WINDOW MOTOR	38	WHEN FRONT POWER WINDOW SWITCH (PASSENGER SIDE) IS OPERATED	53
DRIVER SIDE	38	WHEN FRONT POWER WINDOW SWITCH (PASSENGER SIDE) IS OPERATED : Diagnosis Procedure	53
DRIVER SIDE : Description	38	WHEN BOTH POWER WINDOW MAIN SWITCH AND FRONT POWER WINDOW SWITCH ARE OPERATED	53
DRIVER SIDE : Component Function Check	38	WHEN BOTH POWER WINDOW MAIN SWITCH AND FRONT POWER WINDOW SWITCH ARE OPERATED : Diagnosis Procedure	53
DRIVER SIDE : Diagnosis Procedure	38	REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE	54
DRIVER SIDE : Component Inspection	39	WHEN POWER WINDOW MAIN SWITCH IS OPERATED	54
PASSENGER SIDE	39	WHEN POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure	54
PASSENGER SIDE : Description	39	WHEN REAR POWER WINDOW SWITCH LH IS OPERATED	54
PASSENGER SIDE : Component Function Check	39	WHEN REAR POWER WINDOW SWITCH LH IS OPERATED : Diagnosis Procedure	54
PASSENGER SIDE : Diagnosis Procedure	39	WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH LH ARE OPERATED	54
PASSENGER SIDE : Component Inspection	40	WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH LH ARE OPERATED : Diagnosis Procedure	54
REAR LH	41	REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE	55
REAR LH : Description	41	WHEN POWER WINDOW MAIN SWITCH IS OPERATED	55
REAR LH : Component Function Check	41	WHEN POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure	55
REAR LH : Diagnosis Procedure	41	WHEN REAR POWER WINDOW SWITCH RH IS OPERATED	55
REAR LH : Component Inspection	42	WHEN REAR POWER WINDOW SWITCH RH IS OPERATED : Diagnosis Procedure	55
REAR RH	42	WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH ARE OPERATED	55
REAR RH : Description	42	WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH ARE OPERATED : Diagnosis Procedure	55
REAR RH : Component Function Check	42	AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY	56
REAR RH : Diagnosis Procedure	42	DRIVER SIDE	56
REAR RH : Component Inspection	43	DRIVER SIDE : Diagnosis Procedure	56
ENCODER	45		
DRIVER SIDE	45		
DRIVER SIDE : Description	45		
DRIVER SIDE : Component Function Check	45		
DRIVER SIDE : Diagnosis Procedure	45		
DOOR SWITCH	48		
Component Function Check	48		
Diagnosis Procedure	48		
Component Inspection	49		
POWER WINDOW LOCK SWITCH	50		
Description	50		
Component Function Check	50		
SYMPTOM DIAGNOSIS	51		
POWER WINDOWS DO NOT OPERATE WITH POWER WINDOW MAIN SWITCH	51		
Diagnosis Procedure	51		
DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE	52		
Diagnosis Procedure	52		
FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE	53		
WHEN POWER WINDOW MAIN SWITCH IS OPERATED	53		

POWER WINDOW RETAINED POWER FUNCTION DOES NOT OPERATE NORMALLY	57	Component Parts Location	67	
Diagnosis Procedure	57	Component Description	68	A
DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS	58	SYSTEM	69	
Diagnosis Procedure	58	System Diagram	69	B
KEYLESS POWER WINDOW DOWN DOES NOT OPERATE	59	System Description	69	
Diagnosis Procedure	59	Fail-safe	70	C
POWER WINDOW LOCK SWITCH DOES NOT FUNCTION	60	DIAGNOSIS SYSTEM (BCM)	72	
Diagnosis Procedure	60	COMMON ITEM	72	D
POWER WINDOW SWITCH DOES NOT ILLUMINATE	61	COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	72	
DRIVER SIDE	61	RETAINED PWR	73	E
DRIVER SIDE : Diagnosis Procedure	61	RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)	73	
PASSENGER SIDE	61	ECU DIAGNOSIS INFORMATION	74	F
PASSENGER SIDE : Diagnosis Procedure	61	BCM (BODY CONTROL MODULE)	74	
REAR LH	61	List of ECU Reference	74	G
REAR LH : Diagnosis Procedure	61	POWER WINDOW MAIN SWITCH	75	
REAR RH	61	Reference Value	75	H
REAR RH : Diagnosis Procedure	61	Fail Safe	76	
REMOVAL AND INSTALLATION	62	FRONT POWER WINDOW SWITCH	78	I
MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH	62	Reference Value	78	
Removal and Installation	62	Fail Safe	79	J
POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH	63	WIRING DIAGRAM	80	
Removal and Installation	63	POWER WINDOW SYSTEM	80	
REAR POWER WINDOW SWITCH	64	Wiring Diagram - With Left & Right Front Auto Up/Down	80	
Removal and Installation	64	BASIC INSPECTION	89	PWC
LH & RH FRONT AUTO UP/DOWN		DIAGNOSIS AND REPAIR WORKFLOW	89	
PRECAUTION	65	Work Flow	89	L
PRECAUTIONS	65	ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL	91	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	65	Description	91	M
Precaution for Work	65	Work Procedure	91	
PREPARATION	66	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT	92	N
PREPARATION	66	Description	92	
Special Service Tool	66	Work Procedure	92	O
SYSTEM DESCRIPTION	67	SYSTEM INITIALIZATION	93	
COMPONENT PARTS	67	Description	93	P
		Work Procedure	93	
		CHECK ANTI-PINCH FUNCTION	94	
		Description	94	
		Work Procedure	94	
		DTC/CIRCUIT DIAGNOSIS	95	
		POWER SUPPLY AND GROUND CIRCUIT	95	

BCM	95	REAR RH : Component Inspection	110
BCM : Diagnosis Procedure	95	ENCODER	111
POWER WINDOW MAIN SWITCH	95	DRIVER SIDE	111
POWER WINDOW MAIN SWITCH : Description ...	95	DRIVER SIDE : Description	111
POWER WINDOW MAIN SWITCH : Component		DRIVER SIDE : Component Function Check	111
Function Check	96	DRIVER SIDE : Diagnosis Procedure	111
POWER WINDOW MAIN SWITCH : Diagnosis		PASSENGER SIDE	113
Procedure	96	PASSENGER SIDE : Description	113
POWER WINDOW MAIN SWITCH : Component		PASSENGER SIDE : Component Function Check	
Inspection	98	. 113	
POWER WINDOW MAIN SWITCH : Special Re-		PASSENGER SIDE : Diagnosis Procedure	113
pair Requirement	99	DOOR SWITCH	116
FRONT POWER WINDOW SWITCH	99	Component Function Check	116
FRONT POWER WINDOW SWITCH : Descrip-		Diagnosis Procedure	116
tion	99	Component Inspection	117
FRONT POWER WINDOW SWITCH : Compo-		POWER WINDOW LOCK SWITCH	118
nent Function Check	99	Description	118
FRONT POWER WINDOW SWITCH : Diagnosis		Component Function Check	118
Procedure	100	Special Repair Requirement	118
FRONT POWER WINDOW SWITCH : Special		POWER WINDOW SERIAL LINK	119
Repair Requirement	101	POWER WINDOW MAIN SWITCH	119
REAR POWER WINDOW SWITCH	101	POWER WINDOW MAIN SWITCH : Description .	119
REAR POWER WINDOW SWITCH : Description..	101	POWER WINDOW MAIN SWITCH : Component	
REAR POWER WINDOW SWITCH : Component		Function Check	119
Function Check	101	POWER WINDOW MAIN SWITCH : Diagnosis	
REAR POWER WINDOW SWITCH : Diagnosis		Procedure	119
Procedure	101	FRONT POWER WINDOW SWITCH	120
REAR POWER WINDOW SWITCH : Component		FRONT POWER WINDOW SWITCH : Descrip-	
Inspection	103	tion	120
POWER WINDOW MOTOR	104	FRONT POWER WINDOW SWITCH : Compo-	
DRIVER SIDE	104	nent Function Check	120
DRIVER SIDE : Description	104	FRONT POWER WINDOW SWITCH : Diagnosis	
DRIVER SIDE : Component Function Check	104	Procedure	121
DRIVER SIDE : Diagnosis Procedure	104	SYMPTOM DIAGNOSIS	123
DRIVER SIDE : Component Inspection	105	POWER WINDOWS DO NOT OPERATE	
DRIVER SIDE : Special Repair Requirement	105	WITH POWER WINDOW MAIN SWITCH	123
PASSENGER SIDE	105	Diagnosis Procedure	123
PASSENGER SIDE : Description	105	DRIVER SIDE POWER WINDOW ALONE	
PASSENGER SIDE : Component Function Check		DOES NOT OPERATE	124
.. 106		Diagnosis Procedure	124
PASSENGER SIDE : Diagnosis Procedure	106	FRONT PASSENGER SIDE POWER WIN-	
PASSENGER SIDE : Component Inspection	107	DOW ALONE DOES NOT OPERATE	125
PASSENGER SIDE : Special Repair Requirement		Diagnosis Procedure	125
.. 107		REAR LH SIDE POWER WINDOW ALONE	
REAR LH	107	DOES NOT OPERATE	126
REAR LH : Description	107	Diagnosis Procedure	126
REAR LH : Component Function Check	107	REAR RH SIDE POWER WINDOW ALONE	
REAR LH : Diagnosis Procedure	108	DOES NOT OPERATE	127
REAR LH : Component Inspection	108		
REAR RH	109		
REAR RH : Description	109		
REAR RH : Component Function Check	109		
REAR RH : Diagnosis Procedure	109		

Diagnosis Procedure	127	POWER WINDOW LOCK SWITCH DOES NOT FUNCTION	135	A
ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)	128	Diagnosis Procedure	135	
Diagnosis Procedure	128	POWER WINDOW SWITCH DOES NOT ILLUMINATE	136	B
ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)	129	DRIVER SIDE	136	
Diagnosis Procedure	129	DRIVER SIDE : Diagnosis Procedure	136	C
AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)	130	PASSENGER SIDE	136	
Diagnosis Procedure	130	PASSENGER SIDE : Diagnosis Procedure	136	D
AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)	131	REAR LH	136	
Diagnosis Procedure	131	REAR LH : Diagnosis Procedure	136	E
POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY	132	REAR RH	136	
Diagnosis Procedure	132	REAR RH : Diagnosis Procedure	136	F
DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS	133	REMOVAL AND INSTALLATION	137	
Diagnosis Procedure	133	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH	137	G
KEYLESS POWER WINDOW DOWN DOES NOT OPERATE	134	Removal and Installation	137	
Diagnosis Procedure	134	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH	138	H
		Removal and Installation	138	
		REAR POWER WINDOW SWITCH	139	I
		Removal and Installation	139	J

PWC

L
M
N
O
P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011153908

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- **When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.**
- **When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.**

Precaution for Work

INFOID:000000011153909

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[LH FRONT ONLY AUTO DOWN]

PREPARATION


PREPARATION

Special Service Tool

INFOID:0000000011153910

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim tool set	Removing trim components



AWJIA0483ZZ

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[LH FRONT ONLY AUTO DOWN]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000011153911



AWKIA2058ZZ

1. BCM (view with the combination meter removed)
2. Front power window motor LH (RH similar) (view with front door finisher removed)
3. Rear power window motor LH (RH similar) (view with rear door finisher removed)

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[LH FRONT ONLY AUTO DOWN]

- | | | |
|--|--|---|
| 4. Main power window and door lock/unlock switch | 5. Power window and door lock/unlock switch RH | 6. Rear power window switch LH (RH similar) |
| 7. Front door lock assembly LH (key cylinder switch) | 8. Front door switch LH (RH similar) | |

Component Description

INFOID:000000011153912

Component	Function
BCM	<ul style="list-style-type: none"> Supplies power to the window switches. Controls retained power.
Main power window and door lock/unlock switch	Directly controls all power window motors.
Power window and door lock/unlock switch RH	Controls power window motor of passenger door.
Rear power window switch	Controls right and left power window motors for the rear doors.
Power window motor	<ul style="list-style-type: none"> Integrates the ENCODER and WINDOW MOTOR. Starts operating with signals from each power window switch. Transmits power window motor rotation as a pulse signal to power window switch.
Front door lock assembly (door key cylinder switch)	Transmits operation condition of door key cylinder switch to power window main switch.
Front door switch LH/RH	Detects door open/close condition and transmits it to the BCM.


A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

SYSTEM

System Diagram

INFOID:000000011153913



System Description

INFOID:000000011153914

POWER WINDOW OPERATION

- Power window system is activated by the power window switch when the ignition switch is in the ON position or during the retained power operation after ignition switch turns OFF.
- Power window main switch can open/close door glass.
- Front and rear power window switch can open/close the corresponding door glass.
- Power window lock switch can lock all power windows other than driver seat.
- All power windows open when pressing Intelligent Key unlock button for 3 seconds.
- Power window serial link transmits the signals from power window main switch to each power window switch.

POWER WINDOW AUTO-OPERATION

- AUTO-DOWN operation can be performed when the front power window motor LH turns to AUTO.
- Encoder continues detecting the movement of power window motor and output the encoder pulse signal to power window switch while power window motor is operating.
- Power window motor is operable in case encoder is malfunctioning.
- AUTO-DOWN function does not operate if encoder is malfunctioning.

RETAINED POWER OPERATION

- Retained power operation is an additional power supply function that enables power window system to operate during the 45 seconds even when ignition switch is turned OFF.

Retained Power Function Cancel Conditions

- Front door CLOSE (door switch OFF)→OPEN (door switch ON).
- When ignition switch is ON again.
- When timer time passes. (45 seconds)

SYSTEM

< SYSTEM DESCRIPTION >

[LH FRONT ONLY AUTO DOWN]

POWER WINDOW LOCK FUNCTION

Ground circuit inside power window main switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the power window main switch.

DOOR KEY CYLINDER SWITCH OPERATION

Hold the door key cylinder to the LOCK or UNLOCK direction for 1 second or more to OPEN or CLOSE all power windows when ignition switch is OFF. In addition, it stops when key position is moved to N (NEUTRAL) when operating.

Operation Condition

- Ignition switch OFF.
- Hold door key cylinder to LOCK position for 1 second or more to perform CLOSE operation of the door glass.
- Hold door key cylinder to UNLOCK position for 1 second or more to perform OPEN operation of the door glass.

KEYLESS POWER WINDOW DOWN FUNCTION

All power windows open when the unlock button on Intelligent Key is activated and pressed for more than 3 seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed. The power window opening stops when the following operations are performed.

- When the unlock button is pressed for more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.

While retained power operation activate, keyless power window down function cannot be operated.

Fail-safe

INFOID:000000011153915

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when an error beyond the regulation value is detected between the fully closed position and the actual position of the glass.

Malfunction	Malfunction condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more that the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more that the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control:

- Auto-up operation
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LH FRONT ONLY AUTO DOWN]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000011615579

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Back door open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LH FRONT ONLY AUTO DOWN]

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Signal buffer system	SIGNAL BUFFER			×				
TPMS	AIR PRESSURE MONITOR		×	×	×	×		

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000011615580

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

DATA MONITOR

Monitor Item [Unit]	Description
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[LH FRONT ONLY AUTO DOWN]

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

List of ECU Reference

INFOID:000000011153918

ECU	Reference
BCM	BCS-30. "Reference Value"
	BCS-50. "Fail Safe"
	BCS-50. "DTC Inspection Priority Chart"
	BCS-52. "DTC Index"

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >


[LH FRONT ONLY AUTO DOWN]

POWER WINDOW MAIN SWITCH

Reference Value

INFOID:000000011153919

TERMINAL LAYOUT



PHYSICAL VALUES

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Terminal No. (Wire color)		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/ Output		
1 (B)	Ground	Ground	—	—	0
2 (Y)	16	Front power window motor RH DOWN signal	Output	When front RH switch in power window main switch is operated DOWN.	Battery voltage
4 (SB)	12	Encoder pulse signal 2	Input	When power window mo- tor operates.	<p>JMKIA0070GB</p>
5 (Y)	12	Encoder pulse signal 1	Input	When power window mo- tor operates.	<p>JMKIA0070GB</p>
6 (L)	Ground	Rear power window motor RH DOWN signal	Output	When rear RH switch in power window main switch is operated DOWN.	Battery voltage
7 (V)	Ground	Rear power window motor RH UP signal	Output	When rear RH switch in power window main switch is operated UP.	Battery voltage
8 (LG)	Ground	Rear power window motor LH DOWN signal	Output	When rear LH switch in power window main switch is operated DOWN.	Battery voltage

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >

[LH FRONT ONLY AUTO DOWN]

Terminal No. (Wire color)		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/ Output		
9 (SB)	Ground	Rear power window motor LH UP signal	Output	When rear LH switch in power window main switch is operated UP.	Battery voltage
10 (BR)	Ground	RAP signal	Input	IGN SW ON	Battery voltage
				Within 45 second after ignition switch is turned to OFF.	Battery voltage
				When driver side or passenger side door is opened during retained power operation.	0
12 (BR)	Ground	Encoder ground	—	—	0
14 (LG)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates.	10
16 (R)	2	Front power window motor RH UP signal	Output	When front RH switch in power window main switch is operated UP.	Battery voltage
17 (Y)	19	Front power window motor LH UP signal	Output	When front LH switch in power window main switch is operated UP.	Battery voltage
18 (Y)	Ground	Battery power supply	Input	—	Battery voltage
19 (L)	17	Front power window motor LH DOWN signal	Output	When front LH switch in power window main switch is operated DOWN.	Battery voltage


POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH FRONT ONLY AUTO DOWN]


POWER WINDOW SYSTEM CONNECTORS - WITH LEFT FRONT ONLY AUTO DOWN

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5N	Y	—
6N	W	—

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
94	G	AS DOOR SW
96	BG	DR DOOR SW

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE






Terminal No.	Color of Wire	Signal Name
10G	W	—

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH FRONT ONLY AUTO DOWN]



A
B
C
D
E
F
G
H
I
J

PWC


L
M
N
O
P

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH FRONT ONLY AUTO DOWN]


Connector No.	M167
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7
8	9	10	11	12	13	14
15	16					

Terminal No.	Color of Wire	Signal Name
1	Y	-
2	BR	-
3	B	-
8	V	-
9	L	-
10	SB	-
11	LG	-
14	R	-
15	Y	-


Connector No.	M158
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4
5	6	7	8
9	10		

Terminal No.	Color of Wire	Signal Name
3	R	-
4	Y	-
5	BR	- (WITH LEFT FRONT ONLY AUTO DOWN)
8	B	-

Connector No.	M157
Connector Name	WIRE TO WIRE
Connector Color	WHITE



7	6	5	4	3	2	1
16	15	14	13	12	11	10
9	8					

Terminal No.	Color of Wire	Signal Name
3	V	-
4	L	-
10	BR	-

Connector No.	M181
Connector Name	JOINT CONNECTOR-M36
Connector Color	WHITE



4	3	2	1
---	---	---	---

Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-


ABKIA4759GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH FRONT ONLY AUTO DOWN]

Connector No.	B51
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	B	-
4	Y	-
5	SB	-
8	BR	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10G	P	-

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH FRONT ONLY AUTO DOWN]


Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	21	Color of Wire	LG	Signal Name	-
--------------	----	---------------	----	-------------	---

Terminal No.	66A	Color of Wire	L	Signal Name	-
	94A		SB		-
	95A		BR		-
	100A		Y		-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	B161
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	3	Color of Wire	SB	Signal Name	-
	4		Y		-
	10		BR		-

Connector No.	B139
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	3	Color of Wire	B	Signal Name	-
	4		Y		-
	5		SB		-
	8		BR		-

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	3	Color of Wire	LG	Signal Name	-
--------------	---	---------------	----	-------------	---


ABKIA4761GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH FRONT ONLY AUTO DOWN]

Connector No.	D9
Connector Name	FRONT POWER WINDOW MOTOR LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	L	-
3	Y	-
4	LG	-
5	SB	-
6	BR	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	BR	-
3	B	-
8	V	-
9	L	-
10	SB	-
11	LG	-
14	R	-
15	Y	-


Connector No.	D24
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	Y	MOTOR DR UP
18	Y	B+
19	L	MOTOR DR DOWN

Terminal No.	Color of Wire	Signal Name
5	Y	ENCODER SIG-1 (DLP)
6	L	MOTOR RR DOWN
7	V	MOTOR RR UP
8	LG	MOTOR RL DOWN
9	SB	MOTOR RL UP
10	BR	IGN
11	-	-
12	BR	ENCODER GND
13	-	-
14	LG	ENCODER +
15	-	-
16	R	MOTOR AS UP

Connector No.	D23
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT FRONT ONLY AUTO DOWN)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	Y	MOTOR AS DOWN
3	-	-
4	SB	ENCODER SIG-2 (ULP)

ABKIA6404GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P





POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH FRONT ONLY AUTO DOWN]

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	SB	-
4	Y	-
5	BR	-
8	B	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	B	-
4	Y	-
5	SB	-
8	BR	-

Connector No.	D104
Connector Name	FRONT POWER WINDOW MOTOR RH (WITH LEFT FRONT ONLY AUTO DOWN)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	LG	-

Connector No.	D204
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Color	WHITE






Terminal No.	Color of Wire	Signal Name
1	LG	-
2	V	-

Connector No.	D125
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT FRONT ONLY AUTO DOWN)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
3	B	-
6	LG	-
7	V	-
8	BR	-
11	Y	-
12	SB	-

Connector No.	D208
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Color	WHITE


Terminal No.	Color of Wire	Signal Name
2	B	-
4	BR	-
5	V	-
6	LG	-
7	Y	-
8	SB	-

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH FRONT ONLY AUTO DOWN]

Connector No.	D308
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	B	-
4	BR	-
5	V	-
6	LG	-
7	Y	-
8	SB	-

Connector No.	D304
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	V	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	B	-
4	Y	-
5	SB	-
8	BR	-

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ABKIA6401GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH FRONT ONLY AUTO DOWN]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000011153921

OVERALL SEQUENCE



DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH FRONT ONLY AUTO DOWN]

>> GO TO 2.

2. CONFIRM THE SYMPTOM

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3. IDENTIFY THE MALFUNCTIONING SYSTEM WITH SYMPTOM DIAGNOSIS

Use Symptom diagnosis from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4. PERFORM THE COMPONENT DIAGNOSIS OF THE OF THE APPLICABLE SYSTEM

Perform the diagnosis with Component diagnosis of the applicable system.

>> GO TO 5.

5. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6. FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> Inspection End.

NO >> GO TO 3.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:000000011615581

Regarding Wiring Diagram information, refer to [BCS-55, "Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
139	Fusible link battery power	O (40A)
131	BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M81.

2. Check voltage between BCM connector M81 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M81	131	—	Battery voltage
	139		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M81 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M81	134	—	Yes
	143		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:000000011153923

- BCM supplies power.
- It operates each power window motor via corresponding power window switch and makes window move up/down when main power window and door lock/unlock switch is operated.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000011153924

Main Power Window And Door Lock/unlock Switch

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH FUNCTION

Check power window motor operation with main power window and door lock/unlock switch.

Is the inspection result normal?

- YES >> Main power window and door lock/unlock switch power supply and ground circuit are OK.
- NO >> Refer to [PWC-29, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000011153925

Regarding Wiring Diagram information, refer to [PWC-17, "Wiring Diagram - With Left Front Only Auto Down"](#).

Main Power Window And Door Lock/unlock Switch Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connectors D23, D24 and ground.

Terminal (+)		Terminal (-)	Voltage (Approx.)
Main power window and door lock/unlock switch	Terminal		
D23	10	Ground	Battery voltage
D24	18		

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM, main power window and door lock/unlock switch, power window and door lock/unlock switch RH, rear power window switch LH and rear power window switch RH.
3. Check continuity between BCM connector and main power window and door lock/unlock switch connectors.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M81	140	D23	10	Yes
	141	D24	18	

4. Check continuity between BCM connector M81 and ground.

BCM connector	Terminal	Ground	Continuity
M81	140		Ground
	141		

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the harness or connectors.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

3. Check continuity between main power window and door lock/unlock switch connector D23 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D23	1		Yes

Is the inspection result normal?

- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch LH) GO TO 5.
- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch RH) GO TO 6.
- YES >> Check main power window and door lock/unlock switch output signal (front power window switch LH) GO TO 7.
- YES >> Check main power window and door lock/unlock switch output signal (front power window switch RH) GO TO 8.
- NO >> Repair or replace the harness or connectors.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M81 and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
BCM connector	Terminal	Ground	
M81	140		Ground
	141		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
- NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

5. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH LH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch D23 and ground.

Terminal		(-)	Window switch position (rear LH)	Voltage (Approx.)
(+)				
Main power window and door lock/ unlock switch connector	Terminal	Ground		
D23	9		UP	Battery voltage
	8			DOWN
			8	UP
	8	DOWN		Battery voltage

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
- NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-62, "Removal and Installation"](#).

6. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH RH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch D23 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

Terminal		(-)	Window switch position (rear RH)	Voltage (Approx.)
(+) Main power window and door lock/unlock switch connector				
	Terminal			
D23	7	Ground	UP	Battery voltage
			DOWN	0
	6		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-62, "Removal and Installation"](#).

7. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (FRONT POWER WINDOW SWITCH LH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch D24 and ground.

Terminal		(-)	Window switch position (front LH)	Voltage (Approx.)
(+) Main power window and door lock/unlock switch connector				
	Terminal			
D24	17	Ground	UP	Battery voltage
			DOWN	0
	19		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-62, "Removal and Installation"](#).

8. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (FRONT POWER WINDOW SWITCH RH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch D23 and ground.

Terminal		(-)	Window switch position (front RH)	Voltage (Approx.)
(+) Main power window and door lock/unlock switch connector				
	Terminal			
D23	16	Ground	UP	Battery voltage
			DOWN	0
	2		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-62, "Removal and Installation"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

POWER WINDOW MAIN SWITCH : Component Inspection

INFOID:000000011153926

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

1. Check main power window and door lock/unlock switch D23.

Terminal		Main power window and door lock/unlock switch condition		Continuity
10	9	Rear LH	UP	Yes
10	7	Rear RH		
10	16	Front RH		
8	9	Rear LH	NEUTRAL	
6	7	Rear RH		
2	16	Front RH		
10	8	Rear LH	DOWN	
10	6	Rear RH		
10	2	Front RH		
1	12	-		

2. Check continuity between main power window and door lock/unlock switch D23 (power window lock switch) (Lock operation).

Terminal		Main power window and door lock/unlock switch condition		Continuity
9	1	Rear LH	UP	No
7		Rear RH		
16		Front RH		
8		Rear LH	NEUTRAL	
9		Rear RH		
7		Front RH		
6		Rear LH	DOWN	
2		Rear RH		
16		Front RH		
8		Rear LH	DOWN	
6		Rear RH		
2		Front RH		

3. Check continuity between main power window and door lock/unlock switch D23 (power window lock switch) (Unlock operation).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

Terminal	Main power window and door lock/unlock switch condition	Continuity
9	Rear LH	UP
7	Rear RH	
16	Front RH	
8	Rear LH	NEUTRAL
9	Rear RH	
7	Rear RH	
6	Front RH	
2	Rear LH	DOWN
16	Rear RH	
8	Front RH	

Is the inspection result normal?

- YES >> Main power window and door lock/unlock switch is OK.
- NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-62. "Removal and Installation"](#).

FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:0000000011153927

- BCM supplies power.
- Front power window motor RH will be operated if power window and door lock/unlock switch RH is operated.

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:0000000011153928

Power Window And Door Lock/unlock Switch RH

1. CHECK POWER WINDOW MOTOR FUNCTION

Check front power window motor operation with power window and door lock/unlock switch RH.

Is the inspection result normal?

- YES >> Power window and door lock/unlock switch RH power supply and ground circuit are OK.
- NO >> Refer to [PWC-33. "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

FRONT POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:0000000011153929

Regarding Wiring Diagram information, refer to [PWC-17. "Wiring Diagram - With Left Front Only Auto Down"](#).

Power Window And Door Lock/Unlock Switch RH Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT (POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH)

1. Turn ignition switch ON.
2. Check voltage between power window and door lock/unlock switch RH connector D125 and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Power window and door lock/unlock switch RH connector	Terminal	
D125	8	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM, power window and door lock/unlock switch RH, rear power window switch LH and rear power window switch RH.
3. Check continuity between BCM connector M81 and power window and door lock/unlock switch RH connector D125.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M81	140	D125	8	Yes

4. Check continuity between BCM connector M81 and ground.

BCM connector	Terminal	Ground	Continuity
M81	140		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the harness or connectors.

3. CHECK HARNESS CONTINUITY (POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and power window and door lock/unlock switch RH.
3. Check continuity between main power window and door lock/unlock switch connector D23 and power window and door lock/unlock switch RH connector D125.

Main power window and door lock/unlock switch connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
D23	2	D125	11	Yes
	16		12	

4. Check continuity between main power window and door lock/unlock switch connector D23 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D23	2		No
	16		

Is the inspection result normal?

YES >> GO TO 5

NO >> Repair or replace the harness or connectors.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M81 and ground.

Terminals			Voltage (Approx.)
(+)		(-)	
BCM connector	Terminal		
M81	140	Ground	Battery voltage

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

5. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

Refer to [PWC-35, "FRONT POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
- NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-63, "Removal and Installation"](#).

FRONT POWER WINDOW SWITCH : Component Inspection

INFOID:0000000011153930

COMPONENT INSPECTION

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH D125.

Terminal		Power window switch condition	Continuity
8	7	UP	Yes
11	6		
11	6	NEUTRAL	
7	12		
8	6	DOWN	
7	12		

Is the inspection result normal?

- YES >> Power window and door lock/unlock switch RH is OK.
- NO >> Replace power window and door lock/unlock switch RH. Refer to [PWC-63, "Removal and Installation"](#).

REAR POWER WINDOW SWITCH

REAR POWER WINDOW SWITCH : Description

INFOID:0000000011153931

- BCM supplies power.
- Rear power window motor will be operated if rear power window switch is operated. Rear power window switch.

REAR POWER WINDOW SWITCH : Component Function Check

INFOID:0000000011153932

PWC

Rear Power Window Switch

1. CHECK REAR POWER WINDOW MOTOR FUNCTION

Check rear power window motor operation with rear power window switch.

Is the inspection result normal?

- YES >> Rear power window switch power supply and ground circuit are OK.
- NO >> Refer to [PWC-35, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

REAR POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:0000000011153933

Regarding Wiring Diagram information, refer to [PWC-17, "Wiring Diagram - With Left Front Only Auto Down"](#).

Rear Power Window Switch Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rear power window switch connector and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

Terminal		Terminal	(-)	Condition	Voltage (Approx.)
(+)					
Rear power window switch connector		4	Ground	Ignition switch ON	Battery voltage
LH	D208				
RH	D308				

Is the inspection result normal?

- YES >> GO TO 2 (Rear power window switch LH).
- YES >> GO TO 3 (Rear power window switch RH).
- NO >> GO TO 4.

2. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH LH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch LH.
3. Check continuity between main power window and door lock/unlock switch connector and rear power window switch LH connector.

Main power window and door lock/ unlock switch connector	Terminal	Rear power window switch LH connector	Terminal	Continuity
D23	8	D208	7	Yes
	9		8	

4. Check continuity between main power window and door lock/unlock switch connector D23 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D23	8	Ground	No
	9		

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the harness or connectors.

3. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH RH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch RH.
3. Check continuity between main power window and door lock/unlock switch connector and rear power window switch RH connector.

Main power window and door lock/ unlock switch connector	Terminal	Rear power window switch RH connector	Terminal	Continuity
D23	6	D308	7	Yes
	7		8	

4. Check continuity between main power window and door lock/unlock switch connector D23 and ground.

Main power window and door lock/un- lock switch connector	Terminal	Ground	Continuity
D23	6	Ground	No
	7		

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the harness or connectors.

4. CHECK HARNESS CONTINUITY

POWER SUPPLY AND GROUND CIRCUIT

[LH FRONT ONLY AUTO DOWN]

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect BCM, power window and door lock/unlock switch RH, rear power window switch LH and rear power window switch RH.
2. Check continuity between BCM connector and rear power window switch connector.

BCM connector	Terminal	Rear power window switch connector		Terminal	Continuity
M81	140	LH	D208	4	Yes
		RH	D308		

3. Check continuity between BCM connector and ground.

BCM connector	Terminal	Ground	Continuity
M81	140		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

5. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-37, "REAR POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace rear power window switch. Refer to [PWC-64, "Removal and Installation"](#).

REAR POWER WINDOW SWITCH : Component Inspection

INFOID:0000000011153934

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Terminal		Power window switch condition	Continuity
4	5	UP	Yes
7	6		
7	6	NEUTRAL	
8	5		
8	5	DOWN	
4	6		

Is the inspection result normal?

YES >> Rear power window switch is OK.

NO >> Replace rear power window switch. Refer to [PWC-64, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

POWER WINDOW MOTOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000011153935

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch.

DRIVER SIDE : Component Function Check

INFOID:000000011153936

1. CHECK FRONT POWER WINDOW MOTOR LH CIRCUIT

Check front power window motor LH operation with the main power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Refer to [PWC-38, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000011153937

Regarding Wiring Diagram information, refer to [PWC-17, "Wiring Diagram - With Left Front Only Auto Down"](#).

Front Power Window Motor LH Circuit Check

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH.
3. Turn ignition switch ON.
4. Check voltage between front power window motor LH connector D9 and ground.

Terminal		Main power window and door lock/unlock switch condition	Voltage (Approx.)
(+)	(-)		
Front power window motor LH connector	Terminal		
	D9	Ground	
	1	UP	Battery voltage
		DOWN	0
	2	UP	0
		DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.
3. Check continuity between main power window and door lock/unlock switch connector D24 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D24	19	D9	2	Yes
	17		1	

4. Check continuity between main power window and door lock/unlock switch connector D24 and ground.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D24	19		No
	17		

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-62, "Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK FRONT POWER WINDOW MOTOR LH

Check front power window motor LH.

Refer to [PWC-39, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace front power window motor LH. Refer to [GW-18, "Removal and Installation"](#).

DRIVER SIDE : Component Inspection

INFOID:000000011153938

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR LH

Check motor operation by connecting the battery voltage directly to power window motor D9.

Terminal		Motor condition
(+)	(-)	
1	2	UP
2	1	DOWN

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Replace front power window motor LH. Refer to [GW-18, "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000011153939

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

PASSENGER SIDE : Component Function Check

INFOID:000000011153940

1. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH operation with main power window and door lock/unlock switch or power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Front power window motor RH is OK.

NO >> Refer to [PWC-39, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000011153941

Regarding Wiring Diagram information, refer to [PWC-17, "Wiring Diagram - With Left Front Only Auto Down"](#).

Front Power Window Motor RH Circuit Check

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH OUTPUT SIGNAL

1. Turn ignition switch OFF.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

2. Disconnect front power window motor RH.
3. Turn ignition switch ON.
4. Check voltage between front power window motor RH connector D104 and ground.

Terminal (+)		Terminal (-)	Front power window motor RH condition	Voltage (V) (Approx.)
Front power window motor RH connector	Terminal			
D104	1	Ground	UP	Battery voltage
			DOWN	0
	2		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector D125 and front power window motor RH connector D104.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D125	6	D104	2	Yes
	7		1	

4. Check continuity between power window and door lock/unlock switch connector D125 and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D125	6		
	7		

Is the inspection result normal?

- YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-63, "Removal and Installation"](#).
NO >> Repair or replace the harness or connectors.

3. CHECK FRONT POWER WINDOW MOTOR RH

Check front power window motor RH.

Refer to [PWC-40, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
NO >> Replace front power window motor RH. Refer to [GW-14, "Removal and Installation"](#).

PASSENGER SIDE : Component Inspection

INFOID:0000000011153942

COMPONENT INSPECTION

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to front power window motor RH D104.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

Terminal		Motor condition
(+)	(-)	
1	2	UP
2	1	DOWN

Is the inspection result normal?

YES >> Power window motor is OK.

NO >> Replace front power window motor RH. Refer to [GW-14, "Removal and Installation"](#).

REAR LH

REAR LH : Description

INFOID:0000000011153943

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch LH.

REAR LH : Component Function Check

INFOID:0000000011153944

1. CHECK REAR POWER WINDOW MOTOR LH CIRCUIT

Check rear power window motor LH operation with main power window and door lock/unlock switch or rear power window switch LH.

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Refer to [PWC-41, "REAR LH : Diagnosis Procedure"](#)

REAR LH : Diagnosis Procedure

INFOID:0000000011153945

Regarding Wiring Diagram information, refer to [PWC-17, "Wiring Diagram - With Left Front Only Auto Down"](#).

Rear Power Window Motor LH Circuit Check

1. CHECK REAR POWER WINDOW SWITCH LH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor LH.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor LH connector D204 and ground.

PWC

Terminal		Window condition	Voltage (Approx.)
(+)	(-)		
Rear power window motor LH connector D204	Terminal 2	UP	Battery voltage
		DOWN	0
	1	UP	0
		DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH.
3. Check continuity between rear power window switch LH connector D208 and rear power window motor LH connector D204.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

Rear power window switch LH connector	Terminal	Rear power window motor LH connector	Terminal	Continuity
D208	6	D204	1	Yes
	5		2	

4. Check continuity between rear power window switch LH connector D208 and ground.

Rear power window switch LH connector	Terminal	Ground	Continuity
D208	6		No
	5		

Is the inspection result normal?

- YES >> Check rear power window switch LH. Refer to [PWC-42, "REAR LH : Component Inspection"](#).
 NO >> Repair or replace the harness or connectors.

3. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-42, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
 NO >> Replace rear power window motor LH. Refer to [GW-19, "Removal and Installation"](#).

REAR LH : Component Inspection

INFOID:000000011153946

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR LH

Check motor operation by connecting the battery voltage directly to rear power window motor LH D204.

Terminal		Motor condition
(+)	(-)	
2	1	UP
1	2	DOWN

Is the inspection result normal?

- YES >> Rear power window motor LH is OK.
 NO >> Replace rear power window motor LH. Refer to [GW-19, "Removal and Installation"](#).

REAR RH

REAR RH : Description

INFOID:000000011153947

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch RH.

REAR RH : Component Function Check

INFOID:000000011153948

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check rear power window motor RH operation with operating power window main switch or rear power window switch RH.

Is the inspection result normal?

- YES >> Power window motor is OK.
 NO >> Refer to [PWC-42, "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:000000011153949

Regarding Wiring Diagram information, refer to [PWC-17, "Wiring Diagram - With Left Front Only Auto Down"](#).

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

Rear Power Window Motor RH Circuit Check

1. CHECK REAR POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor RH connector D304 and ground.

Terminal		Rear power window switch RH condition	Voltage (Approx.)
(+)	(-)		
Rear power window motor RH connector	Terminal		
D304	2	UP	Battery voltage
		DOWN	0
	1	UP	0
		DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH.
3. Check continuity between rear power window switch RH connector D308 and rear power window motor RH connector D304.

Rear power window switch RH connector	Terminal	Rear power window motor RH connector	Terminal	Continuity
D308	5	D304	2	Yes
	6		1	

4. Check continuity between rear power window switch RH connector D308 and ground.

Rear power window switch RH connector	Terminal	Ground	Continuity
D308	5	Ground	No
	6		

Is the inspection result normal?

YES >> Check rear power window switch RH. Refer to [PWC-43, "REAR RH : Component Inspection"](#).

NO >> Repair or replace harness or connectors.

3. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-43, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace rear power window motor RH. Refer to [GW-19, "Removal and Installation"](#).

REAR RH : Component Inspection

INFOID:000000011153950

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to rear power window motor RH D304.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

Terminal		Motor condition
(+)	(-)	
1	2	DOWN
2	1	UP

Is the inspection result normal?

YES >> Power window motor is OK.

NO >> Replace rear power window motor RH. Refer to [GW-19, "Removal and Installation"](#).

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

ENCODER DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000011153951

Detects condition of the front power window motor LH operation and transmits to main power window and door lock/unlock switch as pulse signal.

DRIVER SIDE : Component Function Check

INFOID:000000011153952

1. CHECK ENCODER OPERATION

Check front door glass LH perform AUTO DOWN operation normally with main power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-45, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000011153953


Regarding Wiring Diagram information, refer to [PWC-17, "Wiring Diagram - With Left Front Only Auto Down"](#).

Encoder Circuit Check

1. CHECK ENCODER OPERATION

1. Connect front power window motor LH.
2. Turn ignition switch ON.
3. Check signal between main power window and door lock/unlock switch connector D23 and ground with oscilloscope.

Signal name	Terminals			Signal (Reference value)
	(+)		(-)	
	Main power window and door lock/unlock switch connector	Terminal		
Encoder signal 1	D23	5	Ground	Refer to following signal
Encoder signal 2		4		



Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> GO TO 2.

2. CHECK FRONT POWER WINDOW MOTOR LH POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between front power window motor LH connector D9 and ground.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

Terminal			Voltage (Approx.)
(+)	(-)		
Front power window motor LH connector	Terminal		
D9	4	Ground	10

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector D23 and front power window motor connector D9.

Main power window and door lock/ unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D23	14	D9	4	Yes

4. Check continuity between main power window and door lock/unlock switch connector D23 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D23	14		No

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-62. "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH.
3. Check continuity between front power window motor LH connector D9 and ground.

Front power window motor LH connector	Terminal	Ground	Continuity
D9	6		Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

5. CHECK HARNESS CONTINUITY 2

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector D23 and front power window motor LH connector D9.

Main power window and door lock/ unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D23	12	D9	6	Yes

Is the inspection result normal?

YES >> Check main power window and door lock/unlock switch. Refer to [PWC-32. "POWER WINDOW MAIN SWITCH : Component Inspection"](#).

NO >> Repair or replace the harness or connectors.

6. CHECK HARNESS CONTINUITY 3

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window D23 and door lock/unlock switch connector and front power window motor LH connector D9.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D23	5	D9	3	Yes
	4		5	

3. Check continuity between main power window and door lock/unlock switch connector D23 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D23	5	Ground	No
	4		

Is the inspection result normal?

- YES >> Replace front power window motor LH. Refer to [GW-14, "Removal and Installation"](#).
- NO >> Repair or replace harness or connectors.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

DOOR SWITCH

Component Function Check

INFOID:0000000011153954

1.CHECK FUNCTION

1. Select DOOR LOCK of BCM using CONSULT.
2. Select DOOR SW-DR, DOOR SW-AS, DOOR SW-RL, DOOR SW-RR, in DATA MONITOR mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition		Status
DOOR SW-DR	Driver side door	Open	On
		Closed	Off
DOOR SW-AS	Passenger side door	Open	On
		Closed	Off
DOOR SW-RL	Rear door LH	Open	On
		Closed	Off
DOOR SW-RR	Rear door RH	Open	On
		Closed	Off

Is the inspection result normal?

- YES >> Door switch is OK.
 NO >> Refer to [PWC-48, "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:0000000011153955

Regarding Wiring Diagram information, refer to [DLK-75, "Wiring Diagram"](#).

1.CHECK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check signal between malfunctioning door switch harness connector and ground using oscilloscope.

(+)		Terminal	(-)	Signal (Reference value)
Door switch				
Connector				
Driver side	B8	3	Ground	
Passenger side	B108			
Rear LH	B18			
Rear RH	B116			

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between door switch harness connector and BCM harness connector.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

Door switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
Driver side	B8	3	M20	96
Passenger side	B108			94
Rear LH	B18			82
Rear RH	B116			93

3. Check continuity between door switch harness connector and ground.

Door switch		Terminal	Ground	Continuity
Connector	Terminal			
Driver side	B8	3	Ground	No
Passenger side	B108			
Rear LH	B18			
Rear RH	B116			

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR SWITCH

Refer to [PWC-49, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace malfunctioning door switch. Refer to [DLK-315, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000011153956

PWC

1.CHECK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check continuity between door switch terminals.

Door switch		Condition		Continuity
Terminal				
3	Ground contact is part of the switch.	Door switch	Pressed	No
			Released	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace malfunction door switch. Refer to [DLK-315, "Removal and Installation"](#).

POWER WINDOW LOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

POWER WINDOW LOCK SWITCH

Description

INFOID:0000000011153957

Ground circuit of main power window and door lock/unlock switch shuts off if power window lock switch of main power window and door lock/unlock switch is operated. This inhibits all operation, except for the main switch.

Component Function Check

INFOID:0000000011153958

1. CHECK POWER WINDOW LOCK SIGNAL

Exchange for a normal main power window and door lock/unlock switch, and check operation.

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-62. "Removal and Installation"](#).
- NO >> Check condition of harness and connector.

SYMPTOM DIAGNOSIS

POWER WINDOWS DO NOT OPERATE WITH POWER WINDOW MAIN SWITCH

Diagnosis Procedure

INFOID:000000011153959

1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.

[BCS-80, "Removal and Installation"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK POWER WINDOW MAIN SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check power window switch power supply and ground circuit.

Refer to [PWC-29, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011153960

1. CHECK DRIVER SIDE POWER WINDOW MOTOR

Check driver side power window motor.

Refer to [PWC-38. "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47. "Intermittent Incident"](#).

NO >> GO TO 1.

FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE WHEN POWER WINDOW MAIN SWITCH IS OPERATED

WHEN POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure

INFOID:000000011153961

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH circuit.

Refer to [PWC-33. "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47. "Intermittent Incident"](#).

NO >> GO TO 1.

WHEN FRONT POWER WINDOW SWITCH (PASSENGER SIDE) IS OPERATED

WHEN FRONT POWER WINDOW SWITCH (PASSENGER SIDE) IS OPERATED :
Diagnosis Procedure

INFOID:000000011153962

1. REPLACE POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Replace power window and door lock/unlock switch RH.

Refer to [PWC-63. "Removal and Installation"](#).

>> Inspection End.

WHEN BOTH POWER WINDOW MAIN SWITCH AND FRONT POWER WINDOW SWITCH ARE OPERATED

WHEN BOTH POWER WINDOW MAIN SWITCH AND FRONT POWER WINDOW
SWITCH ARE OPERATED : Diagnosis Procedure

INFOID:000000011153963

1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE) POWER SUPPLY AND GROUND CIR- CUIT

Check power window and door lock/unlock switch RH power supply and ground circuit.

Refer to [PWC-33. "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH circuit.

Refer to [PWC-33. "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47. "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE WHEN POWER WINDOW MAIN SWITCH IS OPERATED

WHEN POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure

INFOID:000000011153964

1. CHECK REAR POWER WINDOW SWITCH LH CIRCUIT

Check rear power window switch LH circuit.

Refer to [PWC-35, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> GO TO 1.

WHEN REAR POWER WINDOW SWITCH LH IS OPERATED

WHEN REAR POWER WINDOW SWITCH LH IS OPERATED : Diagnosis Procedure

INFOID:000000011153965

1. REPLACE REAR POWER WINDOW SWITCH LH

Replace rear power window switch LH.

Refer to [PWC-64, "Removal and Installation"](#).

>> Inspection End.

WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH LH ARE OPERATED

WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW
SWITCH LH ARE OPERATED : Diagnosis Procedure

INFOID:000000011153966

1. CHECK REAR POWER WINDOW SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check rear power window switch power supply and ground circuit.

Refer to [PWC-35, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-41, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> GO TO 1.

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE WHEN POWER WINDOW MAIN SWITCH IS OPERATED

WHEN POWER WINDOW MAIN SWITCH IS OPERATED : Diagnosis Procedure

INFOID:000000011153967

1. CHECK REAR POWER WINDOW SWITCH RH CIRCUIT

Check rear power window switch RH circuit.

Refer to [PWC-35, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> GO TO 1.

WHEN REAR POWER WINDOW SWITCH RH IS OPERATED

WHEN REAR POWER WINDOW SWITCH RH IS OPERATED : Diagnosis Procedure

INFOID:000000011153968

1. REPLACE REAR POWER WINDOW SWITCH RH

Replace rear power window switch RH.

Refer to [PWC-64, "Removal and Installation"](#).

>> Inspection End.

WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH ARE OPERATED

WHEN BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW
SWITCH RH ARE OPERATED : Diagnosis Procedure

INFOID:000000011153969

PWC

1. CHECK REAR POWER WINDOW SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check rear power window switch power supply and ground circuit.

Refer to [PWC-35, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-42, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> GO TO 1.

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY

DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000011153970

1. CHECK ENCODER (DRIVER SIDE) CIRCUIT

Check encoder (driver side) circuit.

Refer to [PWC-45, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> GO TO 1.

POWER WINDOW RETAINED POWER FUNCTION DOES NOT OPERATE NORMALLY

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

POWER WINDOW RETAINED POWER FUNCTION DOES NOT OPERATE NORMALLY

Diagnosis Procedure

INFOID:0000000011153971

1. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-172. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47. "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

Diagnosis Procedure

INFOID:000000011153972

1. CHECK FRONT DOOR LOCK ASSEMBLY LH (DOOR KEY CYLINDER SWITCH)

Check front door lock assembly LH (door key cylinder switch).

Refer to [DLK-193. "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47. "Intermittent Incident"](#).

NO >> Inspection End.

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011153973

1.CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [DLK-240, "Diagnosis Procedure"](#).

2.CHECK POWER WINDOW OPERATION

Check power window operation.

In the inspection result normal?

YES >> GO TO 3.

NO >> Refer to [PWC-29, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

Diagnosis Procedure

INFOID:000000011153974

1. REPLACE POWER WINDOW MAIN SWITCH

Replace power window main switch. Refer to [PWC-62, "Removal and Installation"](#).

>> Inspection End.

POWER WINDOW SWITCH DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

[LH FRONT ONLY AUTO DOWN]

POWER WINDOW SWITCH DOES NOT ILLUMINATE

DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:0000000011153975

1. REPLACE POWER WINDOW MAIN SWITCH

Replace power window main switch.
Refer to [PWC-62, "Removal and Installation"](#).

>> Inspection End.

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:0000000011153976

1. REPLACE POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Replace power window and door lock/unlock switch RH.
Refer to [PWC-63, "Removal and Installation"](#).

>> Inspection End.

REAR LH

REAR LH : Diagnosis Procedure

INFOID:0000000011153977

1. REPLACE REAR POWER WINDOW SWITCH LH

Replace rear power window switch LH.
Refer to [PWC-64, "Removal and Installation"](#).

>> Inspection End.

REAR RH

REAR RH : Diagnosis Procedure

INFOID:0000000011153978

1. REPLACE REAR POWER WINDOW SWITCH RH

Replace rear power window switch RH.
Refer to [PWC-64, "Removal and Installation"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P



MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< REMOVAL AND INSTALLATION >

[LH FRONT ONLY AUTO DOWN]

REMOVAL AND INSTALLATION


MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Removal and Installation

INFOID:000000011153979


REMOVAL

1. Remove the main power window and door lock/unlock switch from the front door finisher using a suitable tool.
2. Disconnect the harness connectors (A) from the main power window and door lock/unlock switch (1) and harness connector (B) from the mirror control switch (2).



3. Release the pawls, then separate the main power window and door lock/unlock switch (1) from the switch finisher (2).

○: Pawl



INSTALLATION

Installation is in the reverse order of removal.

NOTE:

When the main power window and door lock/unlock switch is removed or replaced, it is necessary to perform the initialization procedure. Refer to [PWC-26, "Work Flow"](#).

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

< REMOVAL AND INSTALLATION >

[LH FRONT ONLY AUTO DOWN]


POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Removal and Installation

INFOID:000000011153980


REMOVAL

1. Remove the power window and door lock/unlock switch (RH) from the front door finisher using a suitable tool.
2. Disconnect the harness connector (A) from the power window and door lock/unlock switch (RH) (1).



3. Release four pawls, then separate power window and door lock/unlock switch (RH) (1) from switch finisher (2).

○: Pawl



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

REAR POWER WINDOW SWITCH

< REMOVAL AND INSTALLATION >

[LH FRONT ONLY AUTO DOWN]


REAR POWER WINDOW SWITCH

Removal and Installation


INFOID:000000011153981

REMOVAL

1. Remove the rear door cup holder mat.
2. Remove the rear power window switch finisher screw (A) and the rear power window switch finisher (1) from the rear door finisher using a suitable tool.




3. Disconnect the harness connector (A) from the rear power window switch (1).



4. Release the two pawls, then separate the rear power window switch (1) from the switch finisher (2).

○: Pawl



INSTALLATION

Installation is in the reverse order of removal.

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011153982

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000011153983

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

PREPARATION

< PREPARATION >

[LH & RH FRONT AUTO UP/DOWN]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000011153984

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim tool set	Removing trim components



AWJIA0483ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[LH & RH FRONT AUTO UP/DOWN]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000011153985



1. BCM (view with the combination meter removed)

2. Front power window motor LH (RH similar) (view with front door finisher removed)

3. Rear power window motor LH (RH similar) (view with rear door finisher removed)

AWKIA2058ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[LH & RH FRONT AUTO UP/DOWN]

- | | | |
|--|--|---|
| 4. Main power window and door lock/unlock switch | 5. Power window and door lock/unlock switch RH | 6. Rear power window switch LH (RH similar) |
| 7. Front door lock assembly LH (key cylinder switch) | 8. Front door switch LH (RH similar) | |

Component Description

INFOID:000000011153986

Component	Function
BCM	<ul style="list-style-type: none">Supplies power to the window switches.Controls retained power.
Main power window and door lock/unlock switch	Directly controls all power window motors.
Power window and door lock/unlock switch RH	Controls power window motor of passenger door.
Rear power window switch	<ul style="list-style-type: none">Controls anti-pinch operation of power window.Controls right and left power window motors for the rear doors.
Power window motor	<ul style="list-style-type: none">Integrates the CPU and WINDOW MOTOR.Starts operating with signals from each power window switch.Transmits power window motor rotation as a pulse signal to power window switch.Controls anti-pinch operation for all windows.
Front door lock assembly (door key cylinder switch)	Transmits operation condition of door key cylinder switch to power window main switch.
Front door switch LH/RH	Detects door open/close condition and transmits it to the BCM.


SYSTEM

< SYSTEM DESCRIPTION >

[LH & RH FRONT AUTO UP/DOWN]

SYSTEM

System Diagram



System Description

INFOID:000000011153988

PWC

POWER WINDOW OPERATION

- Power window system is activated by the power window switch when the ignition switch is in the ON position or during the retained power operation after ignition switch turns OFF.
- Power window main switch can open/close door glass.
- Front and rear power window switch can open/close the corresponding door glass.
- Power window lock switch can lock all power windows other than driver seat.
- All power windows open when pressing Intelligent Key unlock button for 3 seconds.
- If door glass receives resistance that is more than the specified value and the power window is in the AUTO-UP operation, power window will move in the reverse direction (Anti-Pinch Function).

POWER WINDOW AUTO-OPERATION

- AUTO-UP/DOWN operation can be performed when each power window motor turns to AUTO.
- Power window switch reads the changes of the CPU signal and stops AUTO operation when door glass is at fully opened/closed position.
- Power window motor is operable in case of CPU malfunctioning.
- AUTO function does not operate if the CPU is malfunctioning.

POWER WINDOW SERIAL LINK

Power window main switch, front power window switch (passenger side) and BCM transmit and receive the signal by power window serial link.

The signal mentioned below is transmitted from BCM to power window main switch, front power window switch (passenger side).

- Keyless power window down signal.
- Door switch signal.

SYSTEM

< SYSTEM DESCRIPTION >

[LH & RH FRONT AUTO UP/DOWN]

The signal mentioned below is transmitted from power window main switch to front power window switch (passenger side).

- Front passenger side door window operation signal.
- Retained power operation signal.

RETAINED POWER OPERATION

- Retained power operation is an additional power supply function that enables power window system to operate during the 45 seconds even when ignition switch is turned OFF.

Retained Power Function Cancel Conditions

- Front door CLOSE (door switch OFF)→OPEN (door switch ON).
- When ignition switch is ON again.
- When timer time passes. (45 seconds)

POWER WINDOW LOCK FUNCTION

Ground circuit inside power window main switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the power window main switch.

ANTI-PINCH OPERATION

- Pinch foreign material in the door glass during Auto-Up operation, and it is the anti-pinch that lowers the door glass 150 mm (5.9 in) or 2 seconds when detected.
- CPU continues detecting the movement of power window motor and transmits to the power window switch as the CPU signal while power window motor is operating.
- Resistance is applied to the power window motor rotation that changes the frequency of CPU signal if foreign material is trapped in the door glass.
- Power window switch controls to lower the door glass for 150 mm (5.9 in) or 2 seconds after it detects CPU pulse signal frequency change.

Operation Condition

When all door glass AUTO-UP operation is performed (anti-pinch function does not operate just before the door glass closes and is fully closed)

NOTE:

Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower.

DOOR KEY CYLINDER SWITCH OPERATION

Hold the door key cylinder to the LOCK or UNLOCK direction for 1 second or more to OPEN or CLOSE all power windows when ignition switch is OFF. In addition, it stops when key position is moved to N (NEUTRAL) when operating.

Operation Condition

- Ignition switch OFF.
- Hold door key cylinder to LOCK position for 1 second or more to perform CLOSE operation of the door glass.
- Hold door key cylinder to UNLOCK position for 1 second or more to perform OPEN operation of the door glass.

KEYLESS POWER WINDOW DOWN FUNCTION

All power windows open when the unlock button on Intelligent Key is activated and pressed for more than 3 seconds with the ignition switch OFF. The windows keep opening if the unlock button is continuously pressed. The power window opening stops when the following operations are performed.

- When the unlock button is pressed for more than 15 seconds.
- When the ignition switch is turned ON while the power window opening is operated.
- When the unlock button is released.

While retained power operation activate, keyless power window down function cannot be operated.

Fail-safe

INFOID:000000011153989

FAIL-SAFE CONTROL

Window system switches to fail-safe control when a malfunction is detected in the CPU during UP and DOWN operation. Switches to fail-safe control when an error beyond the regulation value is detected between the fully closed position and the actual position of the glass.

SYSTEM

< SYSTEM DESCRIPTION >

[LH & RH FRONT AUTO UP/DOWN]

Malfunction	Malfunction condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control:

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LH & RH FRONT AUTO UP/DOWN]

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000011616122

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> • The vehicle specification can be read and saved. • The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Back door open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LH & RH FRONT AUTO UP/DOWN]

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Signal buffer system	SIGNAL BUFFER			x				
TPMS	AIR PRESSURE MONITOR		x	x	x	x		

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000011616123

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

DATA MONITOR

Monitor Item [Unit]	Description
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

[LH & RH FRONT AUTO UP/DOWN]

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

List of ECU Reference

INFOID:000000011153992

ECU	Reference
BCM	BCS-30. "Reference Value"
	BCS-50. "Fail Safe"
	BCS-50. "DTC Inspection Priority Chart"
	BCS-52. "DTC Index"

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >


[LH & RH FRONT AUTO UP/DOWN]

POWER WINDOW MAIN SWITCH

Reference Value

INFOID:000000011153993

TERMINAL LAYOUT



PHYSICAL VALUES

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Terminal No.		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/Output		
1 (B)	Ground	Ground	—	—	0
3 (BR)	Ground	Door key cylinder switch LOCK signal	Input	Key position (Neutral → Locked)	5 → 0
4 (SB)	12	Encoder pulse signal 2	Input	When power window motor operates.	<p>JMKIA0070GB</p>
5 (Y)	12	Encoder pulse signal 1	Input	When power window motor operates.	<p>JMKIA0070GB</p>
6 (L)	Ground	Rear power window motor RH DOWN signal	Output	When rear RH switch in power window main switch is operated DOWN.	Battery voltage
7 (V)	Ground	Rear power window motor RH UP signal	Output	When rear RH switch in power window main switch is operated UP.	Battery voltage
8 (LG)	Ground	Rear power window motor LH DOWN signal	Output	When rear LH switch in power window main switch is operated DOWN.	Battery voltage
9 (SB)	Ground	Rear power window motor LH UP signal	Output	When rear LH switch in power window main switch is operated UP.	Battery voltage


A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >

[LH & RH FRONT AUTO UP/DOWN]

Terminal No.		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/Output		
10 (BR)	Ground	RAP signal	Input	IGN SW ON	Battery voltage
				Within 45 second after ignition switch is turned to OFF.	Battery voltage
				When front LH or RH door is opened during retained power operation.	0
11 (P)	Ground	Power window serial link	Input/Output	IGN SW ON or power window timer operating.	 JPMIA0013GB
12 (BR)	Ground	Encoder ground	—	—	0
14 (LG)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates.	10
15 (SB)	Ground	Door key cylinder switch UNLOCK signal	Input	Key position (Neutral → Unlocked)	5 → 0
17 (Y)	19	Front door power window motor LH UP signal	Output	When front LH switch in power window main switch is operated UP.	Battery voltage
18 (Y)		Battery power supply	Input	—	Battery voltage
19 (L)	17	Front door power window motor LH DOWN signal	Output	When front LH switch in power window main switch is operated DOWN.	Battery voltage

Fail Safe

INFOID:000000011153994

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

Error	Error condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >

[LH & RH FRONT AUTO UP/DOWN]

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

FRONT POWER WINDOW SWITCH

< ECU DIAGNOSIS INFORMATION >


[LH & RH FRONT AUTO UP/DOWN]

FRONT POWER WINDOW SWITCH

Reference Value

INFOID:0000000011153995

TERMINAL LAYOUT



PHYSICAL VALUES

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Terminal No.		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/Output		
3 (Y)	Ground	Power window serial link	Input/Output	IGN SW ON or power window timer operating.	
4 (LG)	Ground	Encoder ground	—	—	0
5 (BG)	Ground	Encoder power supply	Output	When ignition switch ON or power window timer operates	10
7 (B)	Ground	Ground	—	—	0
8 (BR)	Ground	Battery power supply	Input	—	Battery voltage
9 (V)	4	Encoder pulse signal 1	Input	When power window motor operates.	
10 (W)	4	Encoder pulse signal 2	Input	When power window motor operates.	

FRONT POWER WINDOW SWITCH

< ECU DIAGNOSIS INFORMATION >

[LH & RH FRONT AUTO UP/DOWN]

Terminal No.		Description		Condition	Voltage (Approx.)
+	-	Signal name	Input/Output		
11 (L)	12	Power window motor UP signal	Output	When power window motor is UP at operated.	Battery voltage
12 (BR)	11	Power window motor DOWN signal	Output	When power window motor is DOWN at operated.	Battery voltage

Fail Safe

INFOID:0000000011153996

FAIL-SAFE CONTROL

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

Error	Error condition
Pulse sensor malfunction	When only one side of pulse signal is being detected for more than the specified value.
Both pulse sensors malfunction	When both pulse signals have not been detected for more than the specified value during glass open/close operation.
Pulse direction malfunction	When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction.
Glass recognition position malfunction 1	When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value.
Glass recognition position malfunction 2	When it detects pulse count more than the value of glass full stroke during glass open/close operation.
Malfunction of not yet updated closed position of glass	When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes).

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function
- Retained power function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window switch or in motor.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH & RH FRONT AUTO UP/DOWN]


WIRING DIAGRAM

POWER WINDOW SYSTEM

Wiring Diagram - With Left & Right Front Auto Up/Down

INFOID:000000011153997

POWER WINDOW SYSTEM - WITH LEFT AND RIGHT FRONT AUTO UP/DOWN



ABKWA2807GB


POWER WINDOW SYSTEM

[LH & RH FRONT AUTO UP/DOWN]

< WIRING DIAGRAM >


POWER WINDOW SYSTEM CONNECTORS - WITH LEFT AND RIGHT FRONT AUTO UP/DOWN

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5N	Y	-
6N	W	-

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
54	W	PW LIN/COM

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
94	G	AS DOOR SW
96	BG	DR DOOR SW

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10G	W	-

ABKIA4749GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH & RH FRONT AUTO UP/DOWN]


Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND 2
139	W	BAT POWER F/L
140	BR	P/W POWER SUPPLY IGN
141	Y	P/W POWER SUPPLY BAT
142	Y	BAT FRONT DOOR
143	B	GND 1

Terminal No.	Color of Wire	Signal Name
66A	BG	-
94A	SB	-
95A	BR	-
100A	LG	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	M157
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	V	-
4	L	-
10	BR	-

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
31	W	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	G	-

ABKIA4750GB

POWER WINDOW SYSTEM

[LH & RH FRONT AUTO UP/DOWN]

< WIRING DIAGRAM >


Terminal No.	Color of Wire	Signal Name
8	V	-
9	L	-
10	SB	-
11	LG	-

Connector No.	M167
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	BR	-
3	B	-

Connector No.	M158
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	Y	- (WITH LEFT AND RIGHT FRONT AUTO UP/DOWN)
8	B	-

Connector No.	M181
Connector Name	JOINT CONNECTOR-M36
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-

Connector No.	M170
Connector Name	JOINT CONNECTOR-M09
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
28	W	-
29	W	-
30	W	-

Connector No.	M188
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
39	W	-

ABKIA4751GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH & RH FRONT AUTO UP/DOWN]

Connector No.	B51
Connector Name	WIRE TO WIRE
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
3	B	-
4	Y	-
5	SB	-
8	BR	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10G	P	-

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH & RH FRONT AUTO UP/DOWN]

Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Terminal No.	21	Color of Wire	LG	Signal Name	-
--------------	----	---------------	----	-------------	---

Terminal No.	66A	94A	95A	100A	Color of Wire	L	SB	BR	Y	Signal Name	-	-	-	-
--------------	-----	-----	-----	------	---------------	---	----	----	---	-------------	---	---	---	---

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	B161
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7		
8	9	10	11	12	13	14	15	16

Connector No.	B139
Connector Name	WIRE TO WIRE
Connector Color	WHITE



5	4	3	2	1		
12	11	10	9	8	7	6

Terminal No.	3	4	10	Color of Wire	SB	Y	BR	Signal Name	-	-	-
--------------	---	---	----	---------------	----	---	----	-------------	---	---	---

Terminal No.	3	4	5	8	Color of Wire	B	Y	SB	BR	Signal Name	-	-	-	-
--------------	---	---	---	---	---------------	---	---	----	----	-------------	---	---	---	---

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



1	2	3	4
---	---	---	---

Terminal No.	3	Color of Wire	LG	Signal Name	-
--------------	---	---------------	----	-------------	---

ABKIA4753GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH & RH FRONT AUTO UP/DOWN]

Connector No.	D9
Connector Name	FRONT POWER WINDOW MOTOR LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	L	-
3	Y	-
4	LG	-
5	SB	-
6	BR	-

Connector No.	D3
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
39	Y	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	BR	-
3	B	-
8	V	-
9	L	-
10	SB	-
11	LG	-

Connector No.	D24
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	Y	MOTOR DR UP
18	Y	B+
19	L	MOTOR DR DOWN

Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	B	-
5	SB	-
6	BR	-



ABKIA4754GB

POWER WINDOW SYSTEM

< WIRING DIAGRAM >

[LH & RH FRONT AUTO UP/DOWN]



Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
31	Y	-



Terminal No.	Color of Wire	Signal Name
5	Y	ENCODER SIG-1 (DLP)
6	L	MOTOR RR DOWN
7	V	MOTOR RR UP
8	LG	MOTOR RL DOWN
9	SB	MOTOR RL UP
10	BR	IGN
11	Y	COM
12	BR	ENCODER GND
13	-	-
14	LG	ENCODER +
15	SB	UNLOCK CDL
16	-	-

Connector No.	D25
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT AND RIGHT FRONT AUTO UP/DOWN)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	-	-
3	BR	KEY CYL LOCK
4	SB	ENCODER SIG-2 (ULP)

Connector No.	D129
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT AND RIGHT FRONT AUTO UP/DOWN)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	Y	COM
4	LG	ENCODER
5	BG	ENCODER +
6	-	-
7	B	GND
8	BR	BAT
9	V	ENCODER SIG1
10	W	ENCODER SIG2
11	L	MOTOR UP
12	BR	MOTOR DOWN

Connector No.	D105
Connector Name	FRONT POWER WINDOW MOTOR RH (WITH LEFT AND RIGHT FRONT AUTO UP/DOWN)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	L	-
2	BR	-
3	LG	-
4	W	-
5	BG	-
6	V	-

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	BR	-
8	B	-

ABKIA6403GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


PWC

POWER WINDOW SYSTEM

< WIRING DIAGRAM >


[LH & RH FRONT AUTO UP/DOWN]

Connector No.	D208
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	B	-
4	BR	-
5	V	-
6	LG	-
7	Y	-
8	SB	-

Connector No.	D204
Connector Name	REAR POWER WINDOW MOTOR LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	V	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	B	-
4	Y	-
5	SB	-
8	BR	-

Connector No.	D308
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	B	-
4	BR	-
5	V	-
6	LG	-
7	Y	-
8	SB	-

Connector No.	D304
Connector Name	REAR POWER WINDOW MOTOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	V	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	B	-
4	Y	-
5	SB	-
8	BR	-

ABKIA6402GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH & RH FRONT AUTO UP/DOWN]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000011153998

OVERALL SEQUENCE



DETAILED FLOW

1. OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LH & RH FRONT AUTO UP/DOWN]

>> GO TO 2.

2. CONFIRM THE SYMPTOM

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3. IDENTIFY THE MALFUNCTIONING SYSTEM WITH SYMPTOM DIAGNOSIS

Use Symptom diagnosis from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4. PERFORM THE COMPONENT DIAGNOSIS OF THE OF THE APPLICABLE SYSTEM

Perform the diagnosis with Component diagnosis of the applicable system.

>> GO TO 5.

5. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6. FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> Inspection End.

NO >> GO TO 3.

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

< BASIC INSPECTION >

[LH & RH FRONT AUTO UP/DOWN]

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

Description

INFOID:0000000011153999

When the negative battery terminal is disconnected, the initialization is necessary for normal operation of power window system.

CAUTION:

The following specified operations can not be performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function

Work Procedure

INFOID:0000000011154000

1.SYSTEM INITIALIZATION

Perform system initialization. Refer to [PWC-93. "Work Procedure"](#).

>> GO TO 2.

2.CHECK ANTI-PINCH FUNCTION

Check anti-pinch function. Refer to [PWC-94. "Work Procedure"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

< BASIC INSPECTION >

[LH & RH FRONT AUTO UP/DOWN]

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

Description

INFOID:000000011154001

When the negative battery terminal is disconnected, the initialization is necessary for normal operation of power window system.

CAUTION:

The following specified operations can not be performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function

Work Procedure

INFOID:000000011154002

1.SYSTEM INITIALIZATION

Perform system initialization. Refer to [PWC-93. "Work Procedure"](#).

>> GO TO 2.

2.CHECK ANTI-PINCH FUNCTION

Check anti-pinch function. Refer to [PWC-94. "Work Procedure"](#).

>> Inspection End.

SYSTEM INITIALIZATION

< BASIC INSPECTION >

[LH & RH FRONT AUTO UP/DOWN]

SYSTEM INITIALIZATION

Description

INFOID:0000000011154003

If any of the following operations are performed, the initialization is necessary for normal operation of power window system.

- When control unit replaced.
- Electric power supply to power window switch or motor is interrupted by blown fuse or disconnection and connection of the negative battery terminal.
- Removal and installation of regulator assembly.
- Power supply to the power window main switch or power window motor is cut off by the removal of battery terminal or if the battery fuse is blown.
- Disconnection and connection of power window main switch harness connector.
- Removal and installation of motor from regulator assembly.
- Operation of regulator assembly as an independent unit.
- Removal and installation of door glass.
- Removal and installation of door glass run.

The following specified operations can not be performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function

Work Procedure

INFOID:0000000011154004

1.STEP 1

1. Disconnect battery negative terminal or power main switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate the power window switch to fully open the window. (This operation is not necessary if the window is already fully open).
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after the glass stops at fully closed position, keep pulling the switch for 4 seconds or more.
5. Retest the AUTO-UP function operation.

>> GO TO 2.

2.STEP 2

Check anti-pinch function. Refer to [PWC-94, "Work Procedure"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

CHECK ANTI-PINCH FUNCTION

< BASIC INSPECTION >

[LH & RH FRONT AUTO UP/DOWN]

CHECK ANTI-PINCH FUNCTION

Description

INFOID:000000011154005

If any of the following operations are performed, the initialization is necessary for normal operation of power window system.

- When control unit is replaced.
- Electric power supply to power window switch or motor is interrupted by blown fuse or disconnection and connection of the negative battery terminal.
- Removal and installation of regulator assembly.
- Power supply to the power window main switch or power window motor is cut off by the removal of battery terminal or if the battery fuse is blown.
- Disconnection and connection of power window main switch harness connector.
- Removal and installation of motor from regulator assembly.
- Operation of regulator assembly as an independent unit.
- Removal and installation of door glass.
- Removal and installation of door glass run.

The following specified operations can not be performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function

Work Procedure

INFOID:000000011154006

1. CHECK ANTI-PINCH FUNCTION

- Fully open the door window.
- Place a piece of wood near fully closed position.
- Close door glass completely with AUTO-UP.
- Check the following conditions
 - Check that glass lowers for approximately 150 mm (5.91 in.) without pinching piece of wood and stops.
 - Check that glass does not rise not when operating the power window main switch while lowering.

CAUTION:

- **Perform initial setting when AUTO-UP operation or anti-pinch function does not operate normally.**
- **Check that AUTO-UP operates before inspection when system initialization is performed.**
- **Do not check with hands and other body parts because they may be pinched. Do not get pinched.**

>> Inspection End.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM

BCM : Diagnosis Procedure

INFOID:000000011616201

Regarding Wiring Diagram information, refer to [BCS-55, "Wiring Diagram"](#).

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
139	Fusible link battery power	O (40A)
131	BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.
NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M81.
2. Check voltage between BCM connector M81 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M81	131	—	Battery voltage
	139		

Is the inspection result normal?

- YES >> GO TO 3
NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M81 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M81	134	—	Yes
	143		

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace harness or connectors.

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:000000011154008

- BCM supplies power.
- It operates each power window motor via corresponding power window switch and makes window move up/down when main power window and door lock/unlock switch is operated.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:000000011154009

Main Power Window And Door Lock/unlock Switch

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH FUNCTION

Check power window motor operation with main power window and door lock/unlock switch.

Is the inspection result normal?

- YES >> Main power window and door lock/unlock switch power supply and ground circuit are OK.
NO >> Refer to [PWC-96, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000011154010

Regarding Wiring Diagram information, refer to [PWC-80, "Wiring Diagram - With Left & Right Front Auto Up/Down"](#).

Main Power Window And Door Lock/unlock Switch Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between main power window and door lock/unlock switch connectors and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Main power window and door lock/unlock switch connector	Terminal	Battery voltage
D25	10	
D24	18	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM, main power window and door lock/unlock switch, power window and door lock/unlock switch RH, rear power window switch LH and rear power window switch RH.
3. Check continuity between BCM connector and main power window and door lock/unlock switch connectors.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M81	140	D25	10	Yes
	141	D24	18	

4. Check continuity between BCM connector M81 and ground.

BCM connector	Terminal	Ground	Continuity
M81	140		Ground
	141		

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the harness or connectors.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch.
3. Check continuity between main power window and door lock/unlock switch connector D25 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D25	1		Yes

Is the inspection result normal?

- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch LH) GO TO 5.
- YES >> Check main power window and door lock/unlock switch output signal (rear power window switch RH) GO TO 6.
- YES >> Check main power window and door lock/unlock switch output signal (front power window switch LH) GO TO 7.
- NO >> Repair or replace the harness and connectors.

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M81 and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM connector	Terminal	Battery voltage
M81	140	
	141	

Is the measurement value within the specification?

- YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
- NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

5. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH LH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch connector D25 and ground.

Terminal		Window switch position (rear LH)	Voltage (Approx.)
(+)	(-)		
Main power window and door lock/unlock switch connector	Terminal	Ground	Battery voltage
D25	9		
	8		UP
DOWN			Battery voltage

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
- NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-137, "Removal and Installation"](#). After that, refer to [PWC-99, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

6. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (REAR POWER WINDOW SWITCH RH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch connector D25 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

Terminal		(-)	Window switch position (rear RH)	Voltage (Approx.)
(+)				
Main power window and door lock/unlock switch connector	Terminal			
D25	7	Ground	UP	Battery voltage
			DOWN	0
	6		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-137, "Removal and Installation"](#).

7. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL (FRONT POWER WINDOW SWITCH LH)

1. Connect main power window and door lock/unlock switch.
2. Turn ignition switch ON.
3. Check voltage between main power window and door lock/unlock switch connector D25 and ground.

Terminal		(-)	Window switch position (front LH)	Voltage (Approx.)
(+)				
Main power window and door lock/unlock switch connector	Terminal			
D25	17	Ground	UP	Battery voltage
			DOWN	0
	19		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-137, "Removal and Installation"](#).

POWER WINDOW MAIN SWITCH : Component Inspection

INFOID:0000000011154011

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

1. Check main power window and door lock/unlock switch D25.

Terminal		Main power window and door lock/unlock switch condition		Continuity
10	9	Rear LH	UP	Yes
10	7	Rear RH		
8	9	Rear LH	NEUTRAL	
6	7	Rear RH		
10	8	Rear LH	DOWN	
10	6	Rear RH		
1	12	-		

2. Check continuity between main power window and door lock/unlock switch D25 (power window lock switch). (Lock operation).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

Terminal	Main power window and door lock/unlock switch condition	Continuity
9	Rear LH	UP
7	Rear RH	
8	Rear LH	NEUTRAL
9	Rear RH	
7	Rear LH	DOWN
6	Rear RH	

3. Check continuity between main power window and door lock/unlock switch D25 (power window lock switch). (Unlock operation).

Terminal	Main power window and door lock/unlock switch condition	Continuity
9	Rear LH	UP
7	Rear RH	
8	Rear LH	NEUTRAL
9	Rear RH	
6	Rear LH	DOWN
7	Rear RH	

Is the inspection result normal?

YES >> Main power window and door lock/unlock switch is OK.

NO >> Replace main power window and door lock/unlock switch. Refer to [PWC-137, "Removal and Installation"](#). After that, refer to [PWC-99, "POWER WINDOW MAIN SWITCH : Special Repair Requirement"](#).

POWER WINDOW MAIN SWITCH : Special Repair Requirement

INFOID:000000011154012

PWC

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "Work Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-94, "Work Procedure"](#).

Is the inspection result normal?

YES >> Inspection end.

NO >> Refer to [PWC-111, "DRIVER SIDE : Component Function Check"](#).

FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:000000011154013

- BCM supplies power.
- Front power window motor RH will be operated if power window and door lock/unlock switch RH is operated.

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000011154014

Power Window And Door Lock/unlock Switch RH

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

1. CHECK FRONT POWER WINDOW MOTOR RH FUNCTION

Check front power window motor RH operation with power window and door lock/unlock switch RH.

Is the inspection result normal?

- YES >> Power window and door lock/unlock switch RH power supply and ground circuit are OK.
- NO >> Refer to [PWC-100, "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

FRONT POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000011154015

Regarding Wiring Diagram information, refer to [PWC-80, "Wiring Diagram - With Left & Right Front Auto Up/Down"](#).

Power Window And Door Lock/unlock Switch RH Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

Check voltage between power window and door lock/unlock switch RH connector D129 and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Power window and door lock/unlock switch RH connector	Terminal	
D129	8	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM and power window and door lock/unlock switch RH.
3. Check continuity between BCM connector M81 and power window and door lock/unlock switch RH connector D129.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M81	141	D129	8	Yes

4. Check continuity between BCM connector M81 and ground.

BCM connector	Terminal	Ground	Continuity
M81	141		No

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the harness or connectors.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector D129 and ground.

Power window and door lock/unlock switch RH	Terminal	Ground	Continuity
D129	7		Yes

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
- NO >> Repair or replace the harness or connectors.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

4. CHECK BCM OUTPUT SIGNAL

1. Connect BCM.
2. Turn ignition switch ON.
3. Check voltage between BCM connector M81 and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
BCM connector	Terminal	
M81	141	Battery voltage

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
NO >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

FRONT POWER WINDOW SWITCH : Special Repair Requirement

INFOID:000000011154016

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.
Refer to [PWC-93, "Work Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.
Refer to [PWC-94, "Work Procedure"](#).

Is the inspection result normal?

- YES >> Inspection end.
NO >> Refer to [PWC-113, "PASSENGER SIDE : Component Function Check"](#).

REAR POWER WINDOW SWITCH

REAR POWER WINDOW SWITCH : Description

INFOID:000000011154017

- BCM supplies power.
- Rear power window motor will be operated if rear power window switch is operated. Rear power window switch.

REAR POWER WINDOW SWITCH : Component Function Check

INFOID:000000011154018

Rear Power Window Switch

1. CHECK REAR POWER WINDOW MOTOR FUNCTION

Check rear power window motor operation with rear power window switch.

Is the inspection result normal?

- YES >> Rear power window switch power supply and ground circuit are OK.
NO >> Refer to [PWC-101, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

REAR POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000011154019

Regarding Wiring Diagram information, refer to [PWC-80, "Wiring Diagram - With Left & Right Front Auto Up/Down"](#).

Rear Power Window Switch Power Supply Circuit Check

1. CHECK POWER SUPPLY CIRCUIT

Check voltage between rear power window switch connector and ground.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

Terminal		Terminal	(-)	Condition	Voltage (Approx.)
(+)					
Rear power window switch connector	Terminal	4	Ground	Ignition switch ON	Battery voltage
LH	D208				
RH	D308				

Is the inspection result normal?

- YES >> GO TO 2 (Rear power window switch LH).
- YES >> GO TO 3 (Rear power window switch RH).
- NO >> GO TO 4.

2. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH LH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch LH.
3. Check continuity between main power window and door lock/unlock switch connector D25 and rear power window switch LH connector D208.

Main power window and door lock/ unlock switch connector	Terminal	Rear power window switch LH connector	Terminal	Continuity
D25	8	D208	7	Yes
	9		8	

4. Check continuity between main power window and door lock/unlock switch connector D25 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D25	8		
	9		

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the harness or connectors.

3. CHECK HARNESS CONTINUITY (REAR POWER WINDOW SWITCH RH)

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and rear power window switch RH.
3. Check continuity between main power window and door lock/unlock switch connector D25 and rear power window switch RH connector D308.

Main power window and door lock/ unlock switch connector	Terminal	Rear power window switch RH connector	Terminal	Continuity
D25	6	D308	7	Yes
	7		8	

4. Check continuity between main power window and door lock/unlock switch connector D25 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D25	6		
	7		

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the harness or connectors.

4. CHECK HARNESS CONTINUITY

1. Disconnect BCM and rear power window switch.
2. Check continuity between BCM connector and rear power window switch connector.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

BCM connector	Terminal	Rear power window switch connector		Terminal	Continuity
M81	140	LH	D208	4	Yes
		RH	D308		

3. Check continuity between BCM connector M81 and ground.

BCM connector	Terminal	Ground	Continuity
M81	140		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

NO >> Repair or replace the harness or connectors.

5. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-103, "REAR POWER WINDOW SWITCH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace rear power window switch. Refer to [PWC-139, "Removal and Installation"](#).

REAR POWER WINDOW SWITCH : Component Inspection

INFOID:000000011154020

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW SWITCH LH

Check rear power window switch LH D208.

Terminal		Power window switch condition	Continuity
4	5	UP	Yes
7	6		
7	6	NEUTRAL	
8	5		
4	6	DOWN	
5	8		

Is the inspection result normal?

YES >> Rear power window switch LH is OK.

NO >> Replace rear power window switch. Refer to [PWC-139, "Removal and Installation"](#).

2. CHECK REAR POWER WINDOW SWITCH RH

Check rear power window switch RH D308.

Terminal		Power window switch condition	Continuity
4	5	UP	Yes
7	6		
7	6	NEUTRAL	
8	5		
4	6	DOWN	
5	8		

Is the inspection result normal?

YES >> Rear power window switch RH is OK.

NO >> Replace rear power window switch. Refer to [PWC-139, "Removal and Installation"](#).

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

POWER WINDOW MOTOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:0000000011154021

Door glass moves UP/DOWN by receiving the signal from power window main switch.

DRIVER SIDE : Component Function Check

INFOID:0000000011154022

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check front power window motor LH operation with operating main power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Refer to [PWC-104, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:0000000011154023

Regarding Wiring Diagram information, refer to [PWC-80, "Wiring Diagram - With Left & Right Front Auto Up/Down"](#).

Front Power Window Motor LH Circuit Check

1. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH OUTPUT SIGNAL

1. Disconnect front power window motor LH.
2. Turn ignition switch ON.
3. Check voltage between front power window motor LH connector D9 and ground.

Terminal (+)		Terminal (-)	Main power window and door lock/unlock switch condition	Voltage (Approx.)
Power window motor LH connector	Terminal			
D9	1	Ground	UP	Battery voltage
			DOWN	0
	2		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector D24 and front power window motor connector LH D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D24	17	D9	1	Yes
	19		2	

4. Check continuity between main power window and door lock/unlock switch connector D24 and ground.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D24	17		Ground
	19		

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-137, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).

NO >> Repair or replace the harness or connectors.

3. CHECK POWER WINDOW MOTOR

Check front power window motor LH.

Refer to [PWC-105, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace power window motor LH. Refer to [GW-14, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).

DRIVER SIDE : Component Inspection

INFOID:0000000011154024

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR LH

Check motor operation by connecting the battery voltage directly to power window motor D9.

Terminal		Motor condition
(+)	(-)	
2	1	DOWN
1	2	UP

Is the inspection result normal?

YES >> Front power window motor LH is OK.

NO >> Replace front power window motor LH. Refer to [GW-14, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).

DRIVER SIDE : Special Repair Requirement

INFOID:0000000011154025

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "Work Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-94, "Work Procedure"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [PWC-111, "DRIVER SIDE : Component Function Check"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:0000000011154026

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

PASSENGER SIDE : Component Function Check

INFOID:000000011154027

1. CHECK POWER WINDOW MOTOR CIRCUIT

Check power window motor operation with operating main power window and door lock/unlock switch or power window and door lock/unlock switch RH.

Is the inspection result normal?

YES >> Front power window motor RH is OK.

NO >> Refer to [PWC-106, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000011154028

Regarding Wiring Diagram information, refer to [PWC-80, "Wiring Diagram - With Left & Right Front Auto Up/Down"](#).

Front Power Window Motor RH Circuit Check

1. CHECK FRONT POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor RH.
3. Turn ignition switch ON.
4. Check voltage between front power window motor RH connector D105 and ground.

Terminal (+)		Terminal (-)	Front power window motor RH condition	Voltage (Approx.)
Front power window motor RH connector	Terminal			
D105	1	Ground	UP	Battery voltage
			DOWN	0
	2		UP	0
			DOWN	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect power window and door lock/unlock switch RH.
3. Check continuity between power window and door lock/unlock switch RH connector D129 and front power window motor RH connector D105.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D129	11	D105	1	Yes
	12		2	

4. Check continuity between power window and door lock/unlock switch RH connector D129 and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D129	11		Ground
	12		

Is the inspection result normal?

YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-138, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).

NO >> Repair or replace harness or connectors.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

3. CHECK FRONT POWER WINDOW MOTOR RH

Check front power window motor RH.

Refer to [PWC-107, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace front power window motor RH. Refer to [GW-14, "Removal and Installation"](#). After that, refer to [PWC-94, "Work Procedure"](#).

PASSENGER SIDE : Component Inspection

INFOID:000000011154029

COMPONENT INSPECTION

1. CHECK FRONT POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to front power window motor RH D105.

Terminal		Motor condition
(+)	(-)	
1	2	UP
2	1	DOWN

Is the inspection result normal?

YES >> Front power window motor RH is OK.

NO >> Replace front power window motor RH. Refer to [GW-14, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).

PASSENGER SIDE : Special Repair Requirement

INFOID:000000011154030

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "Work Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

2. CHECK ANTI-PINCH OPERATION

Check anti-pinch operation.

Refer to [PWC-94, "Work Procedure"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [PWC-113, "PASSENGER SIDE : Component Function Check"](#).

REAR LH

REAR LH : Description

INFOID:000000011154031

Door glass moves UP/DOWN by receiving the signal from power window main switch or rear power window switch LH.

REAR LH : Component Function Check

INFOID:000000011154032

1. CHECK REAR POWER WINDOW MOTOR LH CIRCUIT

Check rear power window motor LH operation with main power window and door lock/unlock switch or rear power window switch LH.

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Refer to [PWC-108, "REAR LH : Diagnosis Procedure"](#)

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

REAR LH : Diagnosis Procedure

INFOID:000000011154033

Regarding Wiring Diagram information, refer to [PWC-80, "Wiring Diagram - With Left & Right Front Auto Up/Down"](#).

Power Window Motor Circuit Check

1. CHECK REAR POWER WINDOW SWITCH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor LH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor LH connector D204 and ground.

Terminal (+)		Terminal (-)	Window condition	Voltage (Approx.)
Rear power window motor LH connector	Terminal			
D204	2	Ground	UP	Battery voltage
			DOWN	0
	1		UP	0
			DOWN	Battery voltage

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH.
3. Check continuity between rear power window switch LH connector D208 and rear power window motor LH connector D204.

Rear power window switch LH connector	Terminal	Rear power window motor LH connector	Terminal	Continuity
D208	5	D204	2	Yes
	6		1	

4. Check continuity between rear power window switch LH connector D208 and ground.

Rear power window switch LH connector	Terminal	Ground	Continuity
D208	5		No
	6		

Is the inspection result normal?

- YES >> Check rear power window switch LH. Refer to [PWC-103, "REAR POWER WINDOW SWITCH : Component Inspection"](#).
NO >> Repair or replace the harness or connectors.

3. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.
Refer to [PWC-108, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
NO >> Replace rear power window motor LH. Refer to [GW-19, "Removal and Installation"](#).

REAR LH : Component Inspection

INFOID:000000011154034

COMPONENT INSPECTION

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

1. CHECK REAR POWER WINDOW MOTOR LH

Check motor operation by connecting the battery voltage directly to rear power window motor LH D204.

Terminal		Motor condition
(+)	(-)	
1	2	DOWN
2	1	UP

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Replace rear power window motor LH. Refer to [GW-19, "Removal and Installation"](#).

REAR RH

REAR RH : Description

INFOID:000000011154035

Door glass moves UP/DOWN by receiving the signal from main power window and door lock/unlock switch or rear power window switch RH.

REAR RH : Component Function Check

INFOID:000000011154036

1. CHECK REAR POWER WINDOW MOTOR RH CIRCUIT

Check rear power window motor RH operation with operating main power window and door lock/unlock switch or rear power window switch RH.

Is the inspection result normal?

YES >> Rear power window motor RH is OK.

NO >> Refer to [PWC-109, "REAR RH : Diagnosis Procedure"](#).

REAR RH : Diagnosis Procedure

INFOID:000000011154037

Regarding Wiring Diagram information, refer to [PWC-80, "Wiring Diagram - With Left & Right Front Auto Up/Down"](#).

Rear Power Window Motor RH Circuit Check

1. CHECK REAR POWER WINDOW SWITCH RH OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor RH connector D304 and ground.

Terminal		Rear power window switch RH condition	Voltage (Approx.)
(+)	(-)		
Rear power window motor RH connector D304	2	UP	Battery voltage
		DOWN	0
	1	UP	0
		DOWN	Battery voltage

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

3. Check continuity between rear power window switch RH connector D308 and rear power window motor RH connector D304.

Rear power window switch RH connector	Terminal	Rear power window motor RH connector	Terminal	Continuity
D308	5	D304	2	Yes
	6		1	

4. Check continuity between rear power window switch RH connector D308 and ground.

Rear power window switch RH connector	Terminal	Ground	Continuity
D308	5	Ground	No
	6		

Is the inspection result normal?

YES >> Check rear power window switch RH. Refer to [PWC-103, "REAR POWER WINDOW SWITCH : Component Inspection"](#).

NO >> Repair or replace the harness or connectors.

3. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-110, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Replace rear power window motor RH. Refer to [GW-19, "Removal and Installation"](#).

REAR RH : Component Inspection

INFOID:0000000011154038

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR RH

Check motor operation by connecting the battery voltage directly to rear power window motor RH D304.

Terminal		Motor condition
(+)	(-)	
1	2	DOWN
2	1	UP

Is the inspection result normal?

YES >> Rear power window motor RH is OK.

NO >> Replace rear power window motor RH. Refer to [GW-19, "Removal and Installation"](#).

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

ENCODER DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000011154039

Detects condition of the front power window motor LH operation and transmits to main power window and door lock/unlock switch as pulse signal.

DRIVER SIDE : Component Function Check

INFOID:000000011154040

1. CHECK ENCODER OPERATION

Check front door glass LH perform AUTO open/close operation normally when operating main power window and door lock/unlock switch.

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-111, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000011154041


Regarding Wiring Diagram information, refer to [PWC-80, "Wiring Diagram - With Left & Right Front Auto Up/Down"](#).

Encoder Circuit Check

1. CHECK ENCODER OPERATION

1. Turn ignition switch ON.
2. Check signal between main power window and door lock/unlock switch connector D25 and ground with oscilloscope.

Signal name	Terminals		Signal (Reference value)
	(+)		
	Main power window and door lock/unlock switch connector	Terminal	
Encoder signal 1	D25	5	Ground
Encoder signal 2		4	



Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> GO TO 2.

2. CHECK FRONT POWER WINDOW MOTOR LH POWER SUPPLY

1. Turn ignition switch ON.
2. Check voltage between front power window motor LH connector D9 and ground.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

Terminal		Voltage (Approx.)
(+)	(-)	
Front power window motor LH connector	Terminal	
D9	4	Ground
		10

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Disconnect main power window and door lock/unlock switch and front power window motor LH.
3. Check continuity between main power window and door lock/unlock switch connector D25 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D25	14	D9	4	Yes

4. Check continuity between main power window and door lock/unlock switch connector D25 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D25	14		No

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-137, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).

NO >> Repair or replace the harness or connectors.

4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window motor LH.
3. Check continuity between front power window motor LH connector D9 and ground.

Front power window motor LH connector	Terminal	Ground	Continuity
D9	6		Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

5. CHECK HARNESS CONTINUITY 2

1. Disconnect main power window and door lock/unlock switch.
2. Check continuity between main power window and door lock/unlock switch connector D25 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D25	12	D9	6	Yes

Is the inspection result normal?

YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-137, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).

NO >> Repair or replace the harness or connectors.

6. CHECK HARNESS CONTINUITY 3

1. Disconnect main power window and door lock/unlock switch.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

- Check continuity between main power window and door lock/unlock switch connector D25 and front power window motor LH connector D9.

Main power window and door lock/unlock switch connector	Terminal	Front power window motor LH connector	Terminal	Continuity
D25	5	D9	3	Yes
	4		5	

- Check continuity between main power window and door lock/unlock switch connector D25 and ground.

Main power window and door lock/unlock switch connector	Terminal	Ground	Continuity
D25	5		No
	4		

Is the inspection result normal?

YES >> Replace front power window motor LH. Refer to [GW-14, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).

NO >> Repair or replace the harness or connectors.

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000011154042

Detects condition of the front power window motor RH operation and transmits to power window and door lock/unlock switch RH as pulse signal.

PASSENGER SIDE : Component Function Check

INFOID:000000011154043

1. CHECK ENCODER OPERATION

Check front door glass RH perform AUTO open/close operation normally when operating power window and door lock/unlock switch RH.

Is the inspection result normal?

YES >> Encoder operation is OK.

NO >> Refer to [PWC-113, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000011154044

Regarding Wiring Diagram information, refer to [PWC-80, "Wiring Diagram - With Left & Right Front Auto Up/Down"](#).

1. CHECK ENCODER SIGNAL

- Connect front power window motor RH.
- Turn ignition switch ON.
- Check signal between power window and door lock/unlock switch RH connector D129 and ground with oscilloscope.

Signal name	Terminals			Signal (Reference value)
	(+)		(-)	
	Power window and door lock/unlock switch RH connector	Terminal		
Encoder signal 1	D129	9	Ground	Refer to following signal
Encoder signal 2		10		


A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]



Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
 NO >> GO TO 2.

2. CHECK FRONT POWER WINDOW MOTOR RH POWER SUPPLY

- Turn ignition switch ON.
- Check voltage between front power window motor RH connector D105 and ground.

Terminal		Voltage (Approx.)
(+)	(-)	
Front power window motor RH connector	Terminal	10
D105	5	

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY 1

- Turn ignition switch OFF.
- Disconnect power window and door lock/unlock switch RH and front power window motor RH.
- Check continuity between power window and door lock/unlock switch RH connector D129 and front power window motor RH connector D105.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D129	5	D105	5	Yes

- Check continuity between power window and door lock/unlock switch RH connector D129 and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D129	5		No

Is the inspection result normal?

- YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-138, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).
 NO >> Repair or replace the harness or connectors.

4. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect front power window motor RH.
- Check continuity between front power window motor RH connector D105 and ground.

Front power window motor RH connector	Terminal	Ground	Continuity
D105	3		Yes

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> GO TO 5.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

5. CHECK HARNESS CONTINUITY 2

1. Disconnect power window and door lock/unlock switch RH.
2. Check continuity between power window and door lock/unlock switch RH connector D129 and front power window motor RH connector D105.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D129	4	D105	3	Yes

Is the inspection result normal?

- YES >> Replace power window and door lock/unlock switch RH. Refer to [PWC-138, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).
- NO >> Repair or replace the harness or connectors.

6. CHECK HARNESS CONTINUITY 3

1. Disconnect power window and door lock/unlock switch RH.
2. Check continuity between power window and door lock/unlock switch RH connector D129 and front power window motor RH connector D105.

Power window and door lock/unlock switch RH connector	Terminal	Front power window motor RH connector	Terminal	Continuity
D129	9	D105	6	Yes
	10		4	

3. Check continuity between power window and door lock/unlock switch RH connector D129 and ground.

Power window and door lock/unlock switch RH connector	Terminal	Ground	Continuity
D129	9	Ground	No
	10		

Is the inspection result normal?

- YES >> Replace front power window motor RH. Refer to [GW-14, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).
- NO >> Repair or replace the harness or connectors.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

DOOR SWITCH

Component Function Check

INFOID:0000000011154045

1.CHECK FUNCTION

1. Select DOOR LOCK of BCM using CONSULT.
2. Select DOOR SW-DR, DOOR SW-AS, DOOR SW-RL, DOOR SW-RR, in DATA MONITOR mode.
3. Check that the function operates normally according to the following conditions.

Monitor item	Condition		Status
DOOR SW-DR	Driver side door	Open	On
		Closed	Off
DOOR SW-AS	Passenger side door	Open	On
		Closed	Off
DOOR SW-RL	Rear door LH	Open	On
		Closed	Off
DOOR SW-RR	Rear door RH	Open	On
		Closed	Off

Is the inspection result normal?

- YES >> Door switch is OK.
 NO >> Refer to [PWC-116. "Diagnosis Procedure"](#).


Diagnosis Procedure

INFOID:0000000011154046

Regarding Wiring Diagram information, refer to [DLK-75. "Wiring Diagram"](#).

1.CHECK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check signal between malfunctioning door switch harness connector and ground using oscilloscope.

(+)		Terminal	(-)	Signal (Reference value)
Door switch				
Connector				
Driver side	B8	3	Ground	 <p>11.8 V</p>
Passenger side	B108			
Rear LH	B18			
Rear RH	B116			

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between door switch harness connector and BCM harness connector.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

Door switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
Driver side	B8	3	M20	96
Passenger side	B108			94
Rear LH	B18			82
Rear RH	B116			93

3. Check continuity between door switch harness connector and ground.

Door switch		Terminal	Ground	Continuity
Connector	Terminal			
Driver side	B8	3	Ground	No
Passenger side	B108			
Rear LH	B18			
Rear RH	B116			

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-80, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR SWITCH

Refer to [PWC-117, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace malfunctioning door switch. Refer to [DLK-315, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

Component Inspection

INFOID:000000011154047

PWC

1.CHECK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check continuity between door switch terminals.

Door switch		Condition		Continuity
Terminal				
3	Ground contact is part of the switch.	Door switch	Pressed	No
			Released	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace malfunction door switch. Refer to [DLK-315, "Removal and Installation"](#).

POWER WINDOW LOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

POWER WINDOW LOCK SWITCH

Description

INFOID:0000000011154048

Ground circuit of main power window and door lock/unlock switch shuts off if power window lock switch of main power window and door lock/unlock switch is operated. This inhibits all operation, except for the main switch.

Component Function Check

INFOID:0000000011154049

1. CHECK POWER WINDOW LOCK SIGNAL

Exchange for a normal main power window and door lock/unlock switch, and check operation.

Does power window lock operate?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-137, "Removal and Installation"](#). After that, refer to [PWC-118, "Special Repair Requirement"](#).
- NO >> Check condition of harness and connector.

Special Repair Requirement

INFOID:0000000011154050

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-91, "Work Procedure"](#).

Is the inspection result normal?

- YES >> Inspection end.
- NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

POWER WINDOW SERIAL LINK

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Description

INFOID:0000000011154051

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signal mentioned below is transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH

- Keyless power window down signal

The signal mentioned below is transmitted from main power window and door lock/unlock switch to power window and door lock/unlock switch RH

- Front door window RH operation signal
- Power window control by key cylinder switch signal
- Power window lock switch signal
- Retained power operation signal

POWER WINDOW MAIN SWITCH : Component Function Check

INFOID:0000000011154052

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL

Check ("CDL LOCK SW", "CDL UNLOCK SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT. Refer to [BCS-15. "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Monitor item	Condition
CDL LOCK SW	LOCK : ON
	UNLOCK : OFF
CDL UNLOCK SW	LOCK : OFF
	UNLOCK : ON

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> Refer to [PWC-119. "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:0000000011154053



Regarding Wiring Diagram information, refer to [PWC-80. "Wiring Diagram - With Left & Right Front Auto Up/Down"](#).

Power Window Serial Link Check

1. CHECK POWER WINDOW SWITCH OUTPUT SIGNAL


1. Remove Intelligent Key, and close front door LH and RH.
2. Check signal between BCM connector and ground with oscilloscope when door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".
3. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

Terminal		Signal (Reference value)
(+)	(-)	
BCM connector	Terminal	
M81	54	Ground



PIIA1297E

Is the inspection result normal?

- YES >> Power window serial link is OK.
 NO >> GO TO 2.

2. CHECK POWER WINDOW SERIAL LINK CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM and main power window and door lock/unlock switch.
- Check continuity between BCM connector M81 and main power window and door lock/unlock switch connector D25.

BCM connector	Terminal	Main power window and door lock/unlock switch connector	Terminal	Continuity
M81	54	D25	11	Yes

- Check continuity between BCM connector M81 and ground.

BCM connector	Terminal	Ground	Continuity
M81	54		No

Is the inspection result normal?

- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-137, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).
 NO >> Repair or replace harness or connectors.

FRONT POWER WINDOW SWITCH

FRONT POWER WINDOW SWITCH : Description

INFOID:000000011154054

Main power window and door lock/unlock switch, power window and door lock/unlock switch RH and BCM transmit and receive the signal by power window serial link.

The signal mentioned below is transmitted from BCM to main power window and door lock/unlock switch and power window and door lock/unlock switch RH

- Keyless power window down signal

The signal mentioned below is transmitted from main power window and door lock/unlock switch to power window and door lock/unlock switch RH

- Front door window RH operation signal
- Power window control by key cylinder switch signal
- Retained power operation signal
- Power window lock switch signal

FRONT POWER WINDOW SWITCH : Component Function Check

INFOID:000000011154055

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH OUTPUT SIGNAL

Check ("CDL LOCK SW", "CDL UNLOCK SW") in "DATA MONITOR" mode for "POWER DOOR LOCK SYSTEM" with CONSULT. Refer to [BCS-15, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

Monitor item	Condition
CDL LOCK SW	LOCK : ON
	UNLOCK : OFF
CDL UNLOCK SW	LOCK : OFF
	UNLOCK : ON

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> Refer to [PWC-121, "FRONT POWER WINDOW SWITCH : Diagnosis Procedure"](#).

FRONT POWER WINDOW SWITCH : Diagnosis Procedure


INFOID:000000011154056

Regarding Wiring Diagram information, refer to [PWC-80, "Wiring Diagram - With Left & Right Front Auto Up/Down"](#).

Power Window Serial Link Check

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

1. Remove Intelligent Key, and close the front door LH and RH.
2. Check signal between BCM connector and ground with oscilloscope when door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".
3. Check that signals which are shown in the figure below can be detected during 10 second just after door lock and unlock switch (LH and RH) is turned to "LOCK" or "UNLOCK".

Terminal		Signal (Reference value)
(+)	(-)	
BCM connector	Terminal	 <p style="text-align: right; font-size: x-small;">PIIA1297E</p>
M81	54	

Is the inspection result normal?

YES >> Power window serial link is OK.

NO >> GO TO 2.

2. CHECK POWER WINDOW SERIAL LINK CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check continuity between BCM connector M81 and power window and door lock/unlock switch RH connector D129.

BCM connector	Terminal	Power window and door lock/unlock switch RH connector	Terminal	Continuity
M81	54	D129	3	Yes

4. Check continuity between BCM connector M81 and ground.

BCM connector	Terminal	Ground	Continuity
M81	54		No

Is the inspection result normal?

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW SERIAL LINK

< DTC/CIRCUIT DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

-
- YES >> Replace main power window and door lock/unlock switch. Refer to [PWC-137, "Removal and Installation"](#). After that, refer to [PWC-93, "Work Procedure"](#).
- NO >> Repair or replace the harness or connectors.

SYMPTOM DIAGNOSIS

POWER WINDOWS DO NOT OPERATE WITH POWER WINDOW MAIN SWITCH

Diagnosis Procedure

INFOID:000000011154057

1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.
Refer to [BCS-74, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning parts.

2. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Check main power window and door lock/unlock switch.
Refer to [PWC-98, "POWER WINDOW MAIN SWITCH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check power window switch main power supply and ground circuit.
Refer to [PWC-96, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

4. CHECK MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH SERIAL CIRCUIT

Check main power window and door lock/unlock switch serial circuit.
Refer to [PWC-119, "POWER WINDOW MAIN SWITCH : Component Function Check"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).
- NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

DRIVER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011154058

1. CHECK FRONT POWER WINDOW MOTOR LH

Check front power window motor LH.

Refer to [PWC-104, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

FRONT PASSENGER SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011154059

1. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Check power window and door lock/unlock switch RH.

Refer to [PWC-99, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH SERIAL LINK CIRCUIT

Check power window and door lock/unlock switch RH serial link circuit.

Refer to [PWC-120, "FRONT POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK FRONT POWER WINDOW MOTOR RH CIRCUIT

Check front power window motor RH circuit.

Refer to [PWC-106, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

REAR LH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011154060

1. CHECK REAR POWER WINDOW SWITCH LH

Check rear power window switch LH.

Refer to [PWC-101, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-107, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

REAR RH SIDE POWER WINDOW ALONE DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011154061

1. CHECK REAR POWER WINDOW SWITCH RH

Check rear power window switch RH.

Refer to [PWC-101, "REAR POWER WINDOW SWITCH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.

Refer to [PWC-109, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000011154062

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "Work Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK DOOR WINDOW SLIDING PART

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-111, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)
< SYMPTOM DIAGNOSIS > **[LH & RH FRONT AUTO UP/DOWN]**

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (PASSENGER SIDE)

Diagnosis Procedure

INFOID:000000011154063

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.
Refer to [PWC-93. "Work Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning parts.

2. CHECK DOOR WINDOW SLIDING PART

- A foreign material adheres to window glass or glass run rubber.
- Glass run rubber wear or deformation.
- Sash is tilted too much or not enough.

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3. CHECK ENCODER CIRCUIT

Check encoder circuit.
Refer to [PWC-113. "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-47. "Intermittent Incident"](#).
- NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000011154064

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "Work Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK ENCODER

Check encoder.

Refer to [PWC-111, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATES NORMALLY (PASSENGER SIDE)

Diagnosis Procedure

INFOID:000000011154065

1. PERFORM INITIALIZATION PROCEDURE

Perform initialization procedure.

Refer to [PWC-93, "Work Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK ENCODER

Check encoder.

Refer to [PWC-113, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

Diagnosis Procedure

INFOID:000000011154066

1. CHECK FRONT DOOR SWITCH

Check front door switch.

Refer to [DLK-172, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning parts.

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

DOOR KEY CYLINDER SWITCH DOES NOT OPERATE POWER WINDOWS

Diagnosis Procedure

INFOID:000000011154067

1.PERFORM INITIALIZATION PROCEDURE

Initialization procedure is performed and operation is confirmed.

Refer to [PWC-93, "Work Procedure"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 2.

2.CHECK FRONT DOOR LOCK ASSEMBLY LH (DOOR KEY CYLINDER SWITCH)

Check front door lock assembly LH (door key cylinder switch).

Refer to [DLK-193, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

KEYLESS POWER WINDOW DOWN DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000011154068

1. CHECK INTELLIGENT KEY FUNCTION

Check Intelligent Key function.

Refer to [DLK-205. "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-47. "Intermittent Incident"](#).

NO >> Replace BCM. Refer to [BCS-80. "Removal and Installation"](#).

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

Diagnosis Procedure

INFOID:000000011154069

1. REPLACE MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Replace main power window and door lock/unlock switch.

Refer to [PWC-137. "Removal and Installation"](#). After that, [PWC-93. "Work Procedure"](#).

>> INSPECTION END

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW SWITCH DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

[LH & RH FRONT AUTO UP/DOWN]

POWER WINDOW SWITCH DOES NOT ILLUMINATE

DRIVER SIDE

DRIVER SIDE : Diagnosis Procedure

INFOID:000000011154070

1. REPLACE POWER WINDOW MAIN SWITCH

Replace power window main switch.

Refer to [PWC-137. "Removal and Installation"](#).

>> Inspection End.

PASSENGER SIDE

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000011154071

1. REPLACE POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Replace power window and door lock/unlock switch RH.

Refer to [PWC-138. "Removal and Installation"](#).

>> Inspection End.

REAR LH

REAR LH : Diagnosis Procedure

INFOID:000000011154072

1. REPLACE REAR POWER WINDOW SWITCH LH

Replace rear power window switch LH.

Refer to [PWC-139. "Removal and Installation"](#).

>> Inspection End.

REAR RH

REAR RH : Diagnosis Procedure

INFOID:000000011154073

1. REPLACE REAR POWER WINDOW SWITCH RH

Replace rear power window switch RH.

Refer to [PWC-139. "Removal and Installation"](#).

>> Inspection End.

MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

< REMOVAL AND INSTALLATION >

[LH & RH FRONT AUTO UP/DOWN]

REMOVAL AND INSTALLATION


MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH

Removal and Installation

INFOID:000000011154074


REMOVAL

1. Remove the main power window and door lock/unlock switch from the front door finisher using a suitable tool.
2. Disconnect the harness connectors (A) from the main power window and door lock/unlock switch (1) and harness connector (B) from the mirror control switch (2).



3. Release the pawls, then separate the main power window and door lock/unlock switch (1) from the switch finisher (2).

⊖: Pawl



INSTALLATION

Installation is in the reverse order of removal.

NOTE:

When the main power window and door lock/unlock switch is removed or replaced, it is necessary to perform the initialization procedure. Refer to [PWC-89, "Work Flow"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

< REMOVAL AND INSTALLATION >

[LH & RH FRONT AUTO UP/DOWN]


POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH

Removal and Installation

INFOID:000000011154075


REMOVAL

1. Remove the power window and door lock/unlock switch (RH) from the front door finisher using a suitable tool.
2. Disconnect the harness connector (A) from the power window and door lock/unlock switch (RH) (1).



3. Release four pawls, then separate power window and door lock/unlock switch (RH) (1) from switch finisher (2).

○: Pawl



INSTALLATION

Installation is in the reverse order of removal.

NOTE:

When the power window and door lock/unlock switch (RH) is removed or replaced, it is necessary to perform the initialization procedure. Refer to [PWC-89, "Work Flow"](#).

REAR POWER WINDOW SWITCH

< REMOVAL AND INSTALLATION >

[LH & RH FRONT AUTO UP/DOWN]


REAR POWER WINDOW SWITCH

Removal and Installation


INFOID:000000011154076

REMOVAL

1. Remove the rear door cup holder mat.
2. Remove the rear power window switch finisher screw (A) and the rear power window switch finisher (1) from the rear door finisher using a suitable tool.




3. Disconnect the harness connector (A) from the rear power window switch (1).



4. Release the two pawls, then separate the rear power window switch (1) from the switch finisher (2).

⊖: Pawl



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P