

# SECTION **INL**

## INTERIOR LIGHTING SYSTEM

### CONTENTS

<b>PRECAUTION</b> .....	3	<b>BATTERY SAVER</b> .....	10
<b>PRECAUTIONS</b> .....	3	BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER) .....	10
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3		
Precaution for Work .....	3		
<b>PREPARATION</b> .....	4	<b>ECU DIAGNOSIS INFORMATION</b> .....	11
<b>PREPARATION</b> .....	4	<b>BCM</b> .....	11
Special Service Tool .....	4	List of ECU Reference .....	11
<b>SYSTEM DESCRIPTION</b> .....	5	<b>WIRING DIAGRAM</b> .....	12
<b>COMPONENT PARTS</b> .....	5	<b>INTERIOR ROOM LAMP CONTROL SYSTEM</b> .....	12
Component Parts Location .....	5	Wiring Diagram .....	12
Component Description .....	5	<b>ILLUMINATION</b> .....	27
<b>SYSTEM</b> .....	6	Wiring Diagram .....	27
<b>INTERIOR ROOM LAMP CONTROL SYSTEM</b> .....	6	<b>BASIC INSPECTION</b> .....	45
INTERIOR ROOM LAMP CONTROL SYSTEM : System Diagram .....	6	<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	45
INTERIOR ROOM LAMP CONTROL SYSTEM : System Description .....	6	Work Flow .....	45
<b>ILLUMINATION CONTROL SYSTEM</b> .....	7	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	48
ILLUMINATION CONTROL SYSTEM : System Diagram .....	7	<b>POWER SUPPLY AND GROUND CIRCUIT</b> ....	48
ILLUMINATION CONTROL SYSTEM : System Description .....	7	<b>BCM</b> .....	48
<b>DIAGNOSIS SYSTEM (BCM)</b> .....	8	BCM : Diagnosis Procedure .....	48
<b>COMMON ITEM</b> .....	8	<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</b> .....	48
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) .....	8	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure .....	48
<b>INT LAMP</b> .....	9	<b>BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT</b> .....	50
INT LAMP : CONSULT Function (BCM - INT LAMP) .....	9	Description .....	50
		Component Function Check .....	50
		Diagnosis Procedure .....	50

<b>INTERIOR ROOM LAMP CONTROL CIRCUIT</b>	Bulb Replacement .....	62
... 52		
Description ..... 52		
Component Function Check ..... 52		
Diagnosis Procedure ..... 52		
<b>STEP LAMP CIRCUIT</b> ..... 54	<b>FOOT LAMP</b> .....	63
Description ..... 54		
Component Function Check ..... 54	<b>DRIVER SIDE</b> .....	63
Diagnosis Procedure ..... 54	DRIVER SIDE : Exploded View ..... 63	
<b>PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT</b> ..... 56	DRIVER SIDE : Removal and Installation ..... 63	
Description ..... 56	DRIVER SIDE : Bulb Replacement ..... 63	
Component Function Check ..... 56		
Diagnosis Procedure ..... 56		
<b>SYMPTOM DIAGNOSIS</b> ..... 58	<b>PASSENGER SIDE</b> .....	63
<b>INTERIOR LIGHTING SYSTEM SYMPTOMS</b> ... 58	PASSENGER SIDE : Exploded View ..... 64	
Symptom Table ..... 58	PASSENGER SIDE : Bulb Replacement ..... 64	
<b>REMOVAL AND INSTALLATION</b> ..... 59	<b>FRONT STEP LAMP</b> ..... 65	
<b>FRONT ROOM/MAP LAMP ASSEMBLY</b> ..... 59	Exploded View ..... 65	
Exploded View ..... 59	Removal and Installation ..... 65	
Removal and Installation ..... 59	Bulb or Lens Replacement ..... 65	
Bulb or Lens Replacement ..... 60		
<b>VANITY LAMP</b> ..... 61	<b>PERSONAL LAMP</b> ..... 66	
Exploded View ..... 61	Removal and Installation ..... 66	
Removal and Installation ..... 61	Bulb or Lens Replacement ..... 66	
Bulb or Lens Replacement ..... 61		
<b>GLOVE BOX LAMP</b> ..... 62	<b>CARGO LAMP</b> ..... 67	
Exploded View ..... 62	Exploded View ..... 67	
	Removal and Installation ..... 67	
	Bulb or Lens Replacement ..... 67	
	<b>ILLUMINATION CONTROL SWITCH</b> ..... 68	
	Removal and Installation ..... 68	
	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> ..... 69	
	<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> ..... 69	
	Bulb Specifications ..... 69	

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000012548981

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

### Precaution for Work

INFOID:0000000012548982

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

## PREPARATION

< PREPARATION >

# PREPARATION


## PREPARATION

### Special Service Tool

INFOID:0000000012548983

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components

  
AWJIA0483ZZ

# COMPONENT PARTS


< SYSTEM DESCRIPTION >

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:0000000012548984



1. BCM (view with combination meter removed)
2. Front door switch LH (RH similar)
3. Rear door switch LH (RH similar)
4. Back door lock assembly (door ajar switch)
5. Combination switch (lighting and turn signal switch)
6. Illumination control switch
7. Push-button ignition switch
8. IPDM E/R

#### Component Description

INFOID:0000000012548985

INL

Part name	Description
BCM	The BCM monitors the combination switch (lighting and turn signal switch) position. The BCM requests via CAN communication that the IPDM E/R activate the tail lamp relay.
IPDM E/R	The IPDM E/R activates the tail lamp relay based on inputs received from the BCM via the CAN communication.
Push-button ignition switch	Provides ignition status to the BCM.
Door switches	Provides door OPEN/CLOSED status to the BCM.
Combination switch (lighting and turn signal switch)	The combination switch (lighting and turn signal switch) provides input to the BCM about the combination switch (lighting and turn signal switch) position.
Back door lock assembly (door ajar switch)	Provides back door OPEN/CLOSED status to the BCM.
Illumination control switch	Controls the meter and illumination system brightness.

# SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM

### INTERIOR ROOM LAMP CONTROL SYSTEM

#### INTERIOR ROOM LAMP CONTROL SYSTEM : System Diagram

INFOID:0000000012548986



#### INTERIOR ROOM LAMP CONTROL SYSTEM : System Description

INFOID:0000000012548987

##### OUTLINE

- Front room/map lamp, personal lamps 2nd row and cargo lamp are controlled by the interior room lamp timer control function of the BCM when the lamp switch is in the DOOR position.
- Step lamps (if equipped) and foot lamps (if equipped) are controlled by the step lamp control function of the BCM.
- Push-button ignition switch illumination is controlled by the push-button ignition switch illumination control function of BCM.
- Interior room lamps are illuminated by the welcome light function of Intelligent Key system. Refer to [DLK-33, "WELCOME LIGHT FUNCTION : System Description"](#).

##### ROOM LAMP TIMER OPERATION

When the interior room lamp switch is in the DOOR position and when all conditions below are met, the BCM begins timer control (maximum 30 seconds) for interior room lamp ON/OFF.

- When the front door LH is unlocked [with Intelligent Key, main power window and door lock/unlock switch, power window and door lock/unlock switch RH or front door lock assembly LH (key cylinder switch)].
- When a door opens → closes.

Timer control is cancelled under the following conditions:

- When the front door LH is locked [with Intelligent Key, main power window and door lock/unlock switch, power window and door lock/unlock switch RH or front door lock assembly LH (key cylinder switch)].
- A door is opened (door switch turns ON).
- Ignition switch is turned ON.

##### INTERIOR LAMP BATTERY SAVER CONTROL

# SYSTEM

## < SYSTEM DESCRIPTION >

If an interior lamp is left ON and does not turn OFF even when the doors are closed, the BCM turns off power to the interior lamps automatically to save the battery 10 minutes after the ignition switch is turned OFF. The BCM controls power or ground to all interior lamps.

Vanity lamps (if equipped) are controlled by the battery saver control function of the BCM.


After the battery saver system turns the lamps OFF, the lamps will illuminate again when:

- A signal is received from an Intelligent Key or main power window and door lock/unlock switch, power window and door lock/unlock switch RH or when the front door lock assembly LH (key cylinder switch) is locked or unlocked.
- A door is opened or closed.

## ILLUMINATION CONTROL SYSTEM

### ILLUMINATION CONTROL SYSTEM : System Diagram

INFOID:0000000012548988



### ILLUMINATION CONTROL SYSTEM : System Description

INFOID:0000000012548989

The illumination lamps operation is dependent upon the position of the combination switch (lighting and turn signal switch). When the combination switch (lighting and turn signal switch) is placed in the AUTO (if equipped) or parking lamp position the BCM (body control module) receives input requesting the parking lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the tail lamp relay coil. When energized, this relay directs power to the parking and illumination lamps, which then illuminate. The illumination brightness can be controlled by the illumination control switch.

## BATTERY SAVER CONTROL

When the combination switch (lighting and turn signal switch) is in the AUTO (if equipped) or parking lamp position and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated. Under this condition, the illumination lamps remain illuminated for 45 seconds unless the combination switch (lighting and turn signal switch) position is changed. If the combination switch (lighting and turn signal switch) position is changed, then the illumination lamps are turned off after a 30 seconds delay. When the combination switch (lighting and turn signal switch) is turned from OFF to AUTO (if equipped) or parking lamp position after illumination lamps have been turned off by the battery saver control, the illumination lamps illuminate again.

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000012964831

##### **CAUTION:**

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> <li>• The vehicle specification can be read and saved.</li> <li>• The vehicle specification can be written when replacing BCM.</li> </ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

### SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode					
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration
Door lock	DOOR LOCK	x	x	x	x		
Rear window defogger	REAR DEFOGGER		x	x	x		
Warning chime	BUZZER		x	x			
Interior room lamp timer	INT LAMP		x	x	x		
Exterior lamp	HEADLAMP		x	x	x		
Wiper and washer	WIPER		x	x	x		
Turn signal and hazard warning lamps	FLASHER		x	x	x		
Air conditioner	AIR CONDITIONER		x				
Intelligent Key system	INTELLIGENT KEY	x	x	x	x		
Combination switch	COMB SW		x				
BCM	BCM	x	x			x	x
Immobilizer	IMMU		x	x	x		
Interior room lamp battery saver	BATTERY SAVER		x	x			
Back door open	TRUNK		x				
Vehicle security system	THEFT ALM		x	x	x		
RAP system	RETAINED PWR		x				

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

System	Sub System	Direct Diagnostic Mode					
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration
Signal buffer system	SIGNAL BUFFER			×	×		
TPMS	AIR PRESSURE MONITOR		×	×	×		

## INT LAMP

### INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:0000000012964833

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

## DATA MONITOR

Monitor Item [Unit]	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of back door switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.

## ACTIVE TEST

Test Item	Description
INT LAMP	This test is able to check interior room lamp operation [On/Off].
STEP LAMP TEST	This test is able to check step lamp operation [On/Off].

## WORK SUPPORT

#### NOTE:

The items listed below are the only applicable Work Support items for this vehicle. If other items are displayed on CONSULT, do not use or change the setting for these other items.

A  
B  
C  
D

E

F

G

H

I

J

K

INL

M

N

O

P

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Support Item	Setting	Description
SCENARIO LIGHTING SETTING	On	<b>NOTE:</b> Do not use this function since interior room lamp control is changed.
	Off*	
SET I/L D-UNLCK INTCON	On	Interior room lamp timer function ON.
	Off*	Interior room lamp timer function OFF.
FOG LAMP OVERRIDE	On	Fog lamp override function ON.
	Off*	Fog lamp override function OFF.

\*: Initial setting

## BATTERY SAVER

### BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:0000000012964834

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

## DATA MONITOR

Monitor Item [Unit]	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH SW [On/Off]	Indicates condition push-button ignition switch.
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of back door switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.

## ACTIVE TEST

Test item	Description
BATTERY SAVER	This test is able to check battery saver operation [On/Off].

&lt; ECU DIAGNOSIS INFORMATION &gt;

# ECU DIAGNOSIS INFORMATION

BCM

## List of ECU Reference

INFOID:000000012548993

ECU	Reference
BCM	<a href="#">BCS-31, "Reference Value"</a>
	<a href="#">BCS-50, "Fail_Safe"</a>
	<a href="#">BCS-51, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-52, "DTC Index"</a>

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# INTERIOR ROOM LAMP CONTROL SYSTEM


< WIRING DIAGRAM >

## WIRING DIAGRAM

### INTERIOR ROOM LAMP CONTROL SYSTEM

#### Wiring Diagram


INFOID:0000000012548994



ABLWA2936GB

# INTERIOR ROOM LAMP CONTROL SYSTEM


< WIRING DIAGRAM >



ABLWA2937GB

# INTERIOR ROOM LAMP CONTROL SYSTEM


< WIRING DIAGRAM >



ABLWA2938GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >




ABLWA2939GB

# INTERIOR ROOM LAMP CONTROL SYSTEM


< WIRING DIAGRAM >

## INTERIOR ROOM LAMP CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE


  


Terminal No.	Color of Wire	Signal Name
1	SB	-
2	LG	-
5	B	-

Terminal No.	Color of Wire	Signal Name
2N	BG	-
6N	W	-


Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY


Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY

ABLIA7122GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

**< WIRING DIAGRAM >**



ABLIA5083GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

**< WIRING DIAGRAM >**

<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M80</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Color</td><td>BLACK</td></tr> </table> 	Connector No.	M80	Connector Name	BCM (BODY CONTROL MODULE)	Connector Color	BLACK	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M81</td></tr> <tr><td>Connector Name</td><td>BCM (BODY CONTROL MODULE)</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	M81	Connector Name	BCM (BODY CONTROL MODULE)	Connector Color	WHITE	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>119</td><td>R</td><td>RF NIMOCCO</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	119	R	RF NIMOCCO	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>129</td><td>SB</td><td>BATTERY SAVER OUT</td></tr> <tr><td>131</td><td>W</td><td>BAT BCM FUSE</td></tr> <tr><td>134</td><td>B</td><td>GND 2</td></tr> <tr><td>136</td><td>LG</td><td>ROOM LAMP CONT</td></tr> <tr><td>139</td><td>W</td><td>BAT POWER F/L</td></tr> <tr><td>143</td><td>B</td><td>GND 1</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	129	SB	BATTERY SAVER OUT	131	W	BAT BCM FUSE	134	B	GND 2	136	LG	ROOM LAMP CONT	139	W	BAT POWER F/L	143	B	GND 1	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Connector No.</td><td>M84</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	M84	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>21</td><td>G</td><td>-</td></tr> <tr><td>22</td><td>R</td><td>-</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	21	G	-	22	R	-	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>SB</td><td>-</td></tr> <tr><td>2</td><td>W</td><td>-</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	1	SB	-	2	W	-
Connector No.	M80																																																																				
Connector Name	BCM (BODY CONTROL MODULE)																																																																				
Connector Color	BLACK																																																																				
Connector No.	M81																																																																				
Connector Name	BCM (BODY CONTROL MODULE)																																																																				
Connector Color	WHITE																																																																				
Terminal No.	Color of Wire	Signal Name																																																																			
119	R	RF NIMOCCO																																																																			
Terminal No.	Color of Wire	Signal Name																																																																			
129	SB	BATTERY SAVER OUT																																																																			
131	W	BAT BCM FUSE																																																																			
134	B	GND 2																																																																			
136	LG	ROOM LAMP CONT																																																																			
139	W	BAT POWER F/L																																																																			
143	B	GND 1																																																																			
Connector No.	M84																																																																				
Connector Name	WIRE TO WIRE																																																																				
Connector Color	WHITE																																																																				
Terminal No.	Color of Wire	Signal Name																																																																			
21	G	-																																																																			
22	R	-																																																																			
Terminal No.	Color of Wire	Signal Name																																																																			
1	SB	-																																																																			
2	W	-																																																																			

ABLIA7123GB

# INTERIOR ROOM LAMP CONTROL SYSTEM


< WIRING DIAGRAM >

Connector No.	M100
Connector Name	FOOT LAMP RH
Connector Color	BLACK



Connector No.	M168
Connector Name	WIRE TO WIRE
Connector Color	WHITE


Terminal No.	Color of Wire	Signal Name
1	SB	-
2	W	-



Terminal No.	Color of Wire	Signal Name
1	2	3
2	5	4
3	6	7
4	7	8
5	8	9
6	9	10


Terminal No.	Color of Wire	Signal Name
3	B	-

Terminal No.	Color of Wire	Signal Name
3	B	-



Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-

Connector No.	M170
Connector Name	JOINT CONNECTOR-M09
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	10	9
2	8	7
3	6	5
4	5	4
5	4	3
6	3	2
7	2	1







Terminal No.	Color of Wire	Signal Name
1	BR	-
2	Y	-
3	BR	-
19	W	-
20	SB	-
21	SB	-
39	W	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
INL  
Z  
M  
O  
P

ABLI A7124GB

# INTERIOR ROOM LAMP CONTROL SYSTEM






< WIRING DIAGRAM >



ABLIA7125GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

**< WIRING DIAGRAM >**



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
INL



# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >



Connector No.	R101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	R11
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	R102
Connector Name	VANITY LAMP RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	B	-
11	R	-
12	G	-

Terminal No.	Color of Wire	Signal Name
8	B	-
11	R	-
12	G	-

Terminal No.	Color of Wire	Signal Name
1	G	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	G	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	2	-
2	1	-
3	1	-
4	2	-

Terminal No.	Color of Wire	Signal Name
1	2	-
2	1	-
3	1	-
4	2	-

Connector No.	R103
Connector Name	VANITY LAMP LH
Connector Color	WHITE









Connector No.	R104
Connector Name	CARGO LAMP
Connector Color	WHITE



ABLIA7127GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

<table border="1"> <tr><td>Connector No.</td><td>R107</td></tr> <tr><td>Connector Name</td><td>FRONT ROOM/MAP LAMP ASSEMBLY</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  	Connector No.	R107	Connector Name	FRONT ROOM/MAP LAMP ASSEMBLY	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>B</td><td>-</td></tr> <tr><td>2</td><td>L</td><td>-</td></tr> <tr><td>3</td><td>R</td><td>-</td></tr> <tr><td>6</td><td>B</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	B	-	2	L	-	3	R	-	6	B	-	<table border="1"> <tr><td>Connector No.</td><td>D2</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  	Connector No.	D2	Connector Name	WIRE TO WIRE	Connector Color	WHITE									
Connector No.	R107																																					
Connector Name	FRONT ROOM/MAP LAMP ASSEMBLY																																					
Connector Color	WHITE																																					
Terminal No.	Color of Wire	Signal Name																																				
1	B	-																																				
2	L	-																																				
3	R	-																																				
6	B	-																																				
Connector No.	D2																																					
Connector Name	WIRE TO WIRE																																					
Connector Color	WHITE																																					
<table border="1"> <tr><td>Connector No.</td><td>D3</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  	Connector No.	D3	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>BR</td><td>-</td></tr> <tr><td>2</td><td>Y</td><td>-</td></tr> <tr><td>3</td><td>BR</td><td>-</td></tr> <tr><td>19</td><td>Y</td><td>-</td></tr> <tr><td>20</td><td>LG</td><td>-</td></tr> <tr><td>21</td><td>SB</td><td>-</td></tr> <tr><td>39</td><td>Y</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	BR	-	2	Y	-	3	BR	-	19	Y	-	20	LG	-	21	SB	-	39	Y	-	<table border="1"> <tr><td>Connector No.</td><td>D23</td></tr> <tr><td>Connector Name</td><td>MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT FRONT ONLY AUTO DOWN)</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  	Connector No.	D23	Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT FRONT ONLY AUTO DOWN)	Connector Color	WHITE
Connector No.	D3																																					
Connector Name	WIRE TO WIRE																																					
Connector Color	WHITE																																					
Terminal No.	Color of Wire	Signal Name																																				
1	BR	-																																				
2	Y	-																																				
3	BR	-																																				
19	Y	-																																				
20	LG	-																																				
21	SB	-																																				
39	Y	-																																				
Connector No.	D23																																					
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT FRONT ONLY AUTO DOWN)																																					
Connector Color	WHITE																																					
<table border="1"> <tr><td>Connector No.</td><td>D11</td></tr> <tr><td>Connector Name</td><td>FRONT STEP LAMP LH</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  	Connector No.	D11	Connector Name	FRONT STEP LAMP LH	Connector Color	WHITE	<table border="1"> <tr><td>Connector No.</td><td>D14</td></tr> <tr><td>Connector Name</td><td>FRONT DOOR LOCK ASSEMBLY LH</td></tr> <tr><td>Connector Color</td><td>GRAY</td></tr> </table>  	Connector No.	D14	Connector Name	FRONT DOOR LOCK ASSEMBLY LH	Connector Color	GRAY	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>LG</td><td>-</td></tr> <tr><td>2</td><td>Y</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	LG	-	2	Y	-															
Connector No.	D11																																					
Connector Name	FRONT STEP LAMP LH																																					
Connector Color	WHITE																																					
Connector No.	D14																																					
Connector Name	FRONT DOOR LOCK ASSEMBLY LH																																					
Connector Color	GRAY																																					
Terminal No.	Color of Wire	Signal Name																																				
1	LG	-																																				
2	Y	-																																				
<table border="1"> <tr><td>Connector No.</td><td>D1</td></tr> <tr><td>Connector Name</td><td>FRONT STEP LAMP RH</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table>  	Connector No.	D1	Connector Name	FRONT STEP LAMP RH	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>B</td><td>GND</td></tr> <tr><td>3</td><td>Y</td><td>LOCK CDL</td></tr> <tr><td>15</td><td>BR</td><td>UNLOCK CDL</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	B	GND	3	Y	LOCK CDL	15	BR	UNLOCK CDL	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>B</td><td>GND</td></tr> <tr><td>3</td><td>Y</td><td>LOCK CDL</td></tr> <tr><td>15</td><td>BR</td><td>UNLOCK CDL</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	B	GND	3	Y	LOCK CDL	15	BR	UNLOCK CDL						
Connector No.	D1																																					
Connector Name	FRONT STEP LAMP RH																																					
Connector Color	WHITE																																					
Terminal No.	Color of Wire	Signal Name																																				
1	B	GND																																				
3	Y	LOCK CDL																																				
15	BR	UNLOCK CDL																																				
Terminal No.	Color of Wire	Signal Name																																				
1	B	GND																																				
3	Y	LOCK CDL																																				
15	BR	UNLOCK CDL																																				

ABIA7128GB


A B C D E F G H I J K L M N O P Q R S T Z INL

# INTERIOR ROOM LAMP CONTROL SYSTEM


**< WIRING DIAGRAM >**

---

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	D25
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT AND RIGHT FRONT AUTO UP/DOWN)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
27	BR	-
28	Y	-
29	Y	-
30	LG	-
31	Y	-

Terminal No.	Color of Wire	Signal Name
1	B	GND
3	BR	KEY CYL LOCK
11	Y	COM
15	SB	UNLOCK CDL



Connector No.	D109
Connector Name	FRONT STEP LAMP RH
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
8	B	-



Terminal No.	Color of Wire	Signal Name
3	Y	COM
7	B	GND

Terminal No.	Color of Wire	Signal Name
1	LG	-
2	Y	-
3	B	-


Terminal No.	Color of Wire	Signal Name
1	LG	-
2	Y	-

ABLIA7129GB


# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >


Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D507
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	B	-
10	BR	-
12	LG	- (WITHOUT POWER BACK DOOR)
12	P	- (WITH POWER BACK DOOR)




Terminal No.	Color of Wire	Signal Name
1	BR	-
11	LG	- (WITHOUT POWER BACK DOOR)
11	P	- (WITH POWER BACK DOOR)
23	B	-


Connector No.	D557
Connector Name	BACK DOOR LOCK ASSEMBLY (WITH POWER BACK DOOR)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	B	-
10	P	-
12	G	-



Terminal No.	Color of Wire	Signal Name
6	B	-
10	P	-
12	G	-



Terminal No.	Color of Wire	Signal Name
3	G	-
4	B	-



Terminal No.	Color of Wire	Signal Name
3	G	-
4	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
INL


ABLIA7130GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

---

Connector No.	D566
Connector Name	AUTOMATIC BACK DOOR CLOSE SWITCH
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
3	P	-
4	BR	-

ABLIA7131GB


# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION

### Wiring Diagram


INFOID:0000000012548995



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
**INL**


# ILLUMINATION

< WIRING DIAGRAM >



# ILLUMINATION

## < WIRING DIAGRAM >




ABLWA3352GB

# ILLUMINATION


**< WIRING DIAGRAM >**

## ILLUMINATION CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M3
Connector Name	FUSE BLOCK (U/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R	-
24	B	-

Terminal No.	Color of Wire	Signal Name
6N	W	-
13P		-

Connector No.	M6
Connector Name	TOW MODE SWITCH
Connector Color	GRAY



Connector No.	M17
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	BG	-
13P	W	-

20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
10	W	COMBI SW IN 5
11	BG	COMBI SW IN 4
12	R	COMBI SW IN 3
13	G	COMBI SW IN 2
14	P	COMBI SW IN 1

ABLIA6718GB

# ILLUMINATION

< WIRING DIAGRAM >

A

B

C

D

E

F

G

H

I

K

L

M

N

O

P

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK

**H.S.**

60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61

Terminal No.	Color of Wire	Signal Name
48	R	HIGH SIDE START SW LED
59	P	CAN-L
60	L	CAN-H
75	BG	COMBI SW OUT 5
76	P	COMBI SW OUT 4
77	R	COMBI SW OUT 3
78	G	COMBI SW OUT 2
79	W	COMBI SW OUT 1

**H.S.**

46	45	44	43	42	41
52	51	50	49	48	47

Terminal No.	Color of Wire	Signal Name
42	Y	ILLUMI DOWN SW
47	BR	ILLUMI UP SW
48	G	SW GND

**H.S.**

Terminal No.	Color of Wire	Signal Name
1	B	GND 1
2	B	GND 2
21	BG	IGN
22	W	BAT
23	B	ILLUMI CONT OUT
38	P	CAN-L
39	L	CAN-H

**H.S.**


4	3	2	1
---	---	---	---

ABLIA5069GB

# ILLUMINATION


< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
10	P	-
11	W	-
12	P	-
13	BG	-
14	G	-



Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE

Connector No.	M27
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-
3	BR	-
4	Y	-
6	G	-

Terminal No.	Color of Wire	Signal Name
2	BG	-
5	R	-
7	R	-
8	W	-
9	G	-




Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-



Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
10G	W	-
35G	P	-
36G	L	-




ABLIA5070GB

# ILLUMINATION

< WIRING DIAGRAM >


Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	GRAY

Terminal No.	Color of Wire	Signal Name
89A	L	-
90A	P	-




Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Terminal No.	Color of Wire	Signal Name
3	R	-
4	B	-



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

ABLIA7132GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
INL

# ILLUMINATION


**< WIRING DIAGRAM >**

---

Connector No.	M53
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	YELLOW




Connector No.	M55
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-
3	BR	-
4	Y	-
6	G	-

Terminal No.	Color of Wire	Signal Name
6	B	-
7	R	-



Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1R	R	-
2	GR	-



Terminal No.	Color of Wire	Signal Name
3	R	-
4	B	-

ABLIA8336GB

# ILLUMINATION


< WIRING DIAGRAM >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
INL

Connector No.	M80
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND 2
139	W	BAT POWER F/L
143	B	GND 1

Terminal No.	Color of Wire	Signal Name
107	W	LOW SIDE START SW LED


Connector No.	M82
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-



Connector No.	M88
Connector Name	A/C 120V OUTLET MAIN SWITCH
Connector Color	BLACK



1	3	-
2	4	-
3	5	-



4	R	-
5	B	-

2	4	-
3	5	-

1	3	-
2	4	-
3	5	-


ABIA7134GB

# ILLUMINATION

**< WIRING DIAGRAM >**

---


Connector No.	M123
Connector Name	AUDIO UNIT
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	B	ILL (-)
9	R	ILL (+)

Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-
3	BR	-
4	Y	-
6	G	-


Connector No.	M113
Connector Name	ILLUMINATION CONTROL SWITCH
Connector Color	WHITE



Connector No.	M125
Connector Name	AV CONTROL UNIT (WITH MID AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
41	R	ILL




Terminal No.	Color of Wire	Signal Name
5	R	-
6	B	-

Connector No.	M146
Connector Name	A/C SWITCH ASSEMBLY
Connector Color	WHITE




Connector No.	M140
Connector Name	TRIP RESET SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Connector No.	M133
Connector Name	WARNING SYSTEM SWITCH
Connector Color	WHITE



Connector No.	M140
Connector Name	TRIP RESET SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
4	B	-


ABLIA8337GB

# ILLUMINATION

< WIRING DIAGRAM >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
INL

Connector No.	M148
Connector Name	A/C DISPLAY UNIT
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
8	R	-
9	B	-

Connector No.	M149
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
19	Y	-
20	W	-

Connector No.	M168
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	R	-
14	B	-


Connector No.	M185
Connector Name	AUTOMATIC BACK DOOR MAIN SWITCH
Connector Color	WHITE



Connector No.	M181
Connector Name	JOINT CONNECTOR-M36
Connector Color	WHITE



Connector No.	M175
Connector Name	JOINT CONNECTOR-M22
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-

Connector No.	M185
Connector Name	AUTOMATIC BACK DOOR MAIN SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
4	R	-


ABLIA5075GB

# ILLUMINATION

**< WIRING DIAGRAM >**

---


Connector No.	M186
Connector Name	AUTOMATIC BACK DOOR SWITCH
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
3	R	—
4	B	—

Terminal No.	Color of Wire	Signal Name
10	R	ILL+
11	B	ILL-

Connector No.	M192
Connector Name	DISPLAY UNIT (WITH BASE AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	B	—
11	R	—




Connector No.	M204
Connector Name	CVT SHIFT SELECTOR INDICATOR LAMP
Connector Color	BROWN




Connector No.	M203
Connector Name	CLIMATE CONTROLLED SEAT SWITCH (DRIVER SEAT)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	—
2	B	—



Terminal No.	Color of Wire	Signal Name
7	R	—
8	B	—




Terminal No.	Color of Wire	Signal Name
7	R	—
8	B	—

ABLIA8338GB


# ILLUMINATION

< WIRING DIAGRAM >

Connector No.	M212
Connector Name	4WD SHIFT SWITCH
Connector Color	BLACK



Connector No.	M214
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M220
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	B	-
7	R	-

Terminal No.	Color of Wire	Signal Name
12	1	-
13	2	-
14	3	-
15	4	-
16	5	-
17	6	-
18	7	-
19	8	-
20	9	-
21	10	-
22	11	-
23	12	-
24	13	-

Terminal No.	Color of Wire	Signal Name
4	B	-
7	R	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-




Connector No.	M232
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M221
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
9	B	-
11	R	-




INL M Z O P K M Z O P A B C D E F G H I J L N R S T V W X Y Z

# ILLUMINATION


**< WIRING DIAGRAM >**

---

Connector No.	M252
Connector Name	2ND ROW HEATED SEAT SWITCH LH
Connector Color	WHITE




Connector No.	M253
Connector Name	2ND ROW HEATED SEAT SWITCH RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
5	R	ILL (+)
6	B	ILL (-)

Terminal No.	Color of Wire	Signal Name
5	R	-
6	B	-

Terminal No.	Color of Wire	Signal Name
5	R	ILL (+)
6	B	ILL (-)



Terminal No.	Color of Wire	Signal Name
5	R	ILL (+)
6	B	ILL (-)



Terminal No.	Color of Wire	Signal Name
1	L	-
4	L	-
7	P	-
10	P	-



Terminal No.	Color of Wire	Signal Name
6M	L	-
17	R	-
18	B	-



ABLIA8340GB

# ILLUMINATION

< WIRING DIAGRAM >

<table border="1"> <tr><td>Connector No.</td><td>E70</td></tr> <tr><td>Connector Name</td><td>JOINT CONNECTOR-E14</td></tr> <tr><td>Connector Color</td><td>BLACK</td></tr> </table> 	Connector No.	E70	Connector Name	JOINT CONNECTOR-E14	Connector Color	BLACK	<table border="1"> <tr><td>Connector No.</td><td>E71</td></tr> <tr><td>Connector Name</td><td>JOINT CONNECTOR-E15</td></tr> <tr><td>Connector Color</td><td>BLACK</td></tr> </table> 	Connector No.	E71	Connector Name	JOINT CONNECTOR-E15	Connector Color	BLACK	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>P</td><td>-</td></tr> <tr><td>2</td><td>P</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	P	-	2	P	-	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>L</td><td>-</td></tr> <tr><td>2</td><td>L</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	L	-	2	L	-
Connector No.	E70																																
Connector Name	JOINT CONNECTOR-E14																																
Connector Color	BLACK																																
Connector No.	E71																																
Connector Name	JOINT CONNECTOR-E15																																
Connector Color	BLACK																																
Terminal No.	Color of Wire	Signal Name																															
1	P	-																															
2	P	-																															
Terminal No.	Color of Wire	Signal Name																															
1	L	-																															
2	L	-																															
<table border="1"> <tr><td>Connector No.</td><td>E119</td></tr> <tr><td>Connector Name</td><td>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	E119	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>28</td><td>P</td><td>CAN-L</td></tr> <tr><td>29</td><td>L</td><td>CAN-H</td></tr> <tr><td>41</td><td>B</td><td>GND (SIGNAL)</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	28	P	CAN-L	29	L	CAN-H	41	B	GND (SIGNAL)	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>10G</td><td>P</td><td>-</td></tr> <tr><td>35G</td><td>P</td><td>-</td></tr> <tr><td>36G</td><td>L</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	10G	P	-	35G	P	-	36G	L	-	
Connector No.	E119																																
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)																																
Connector Color	WHITE																																
Terminal No.	Color of Wire	Signal Name																															
28	P	CAN-L																															
29	L	CAN-H																															
41	B	GND (SIGNAL)																															
Terminal No.	Color of Wire	Signal Name																															
10G	P	-																															
35G	P	-																															
36G	L	-																															
<table border="1"> <tr><td>Connector No.</td><td>E121</td></tr> <tr><td>Connector Name</td><td>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	E121	Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>7</td><td>8</td><td>9 10 11</td></tr> <tr><td></td><td></td><td>12 13 14 15 16 17 18</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	7	8	9 10 11			12 13 14 15 16 17 18	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>7</td><td>B</td><td>GND (POWER)</td></tr> <tr><td>10</td><td>L</td><td>TAIL LH</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	7	B	GND (POWER)	10	L	TAIL LH							
Connector No.	E121																																
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)																																
Connector Color	WHITE																																
Terminal No.	Color of Wire	Signal Name																															
7	8	9 10 11																															
		12 13 14 15 16 17 18																															
Terminal No.	Color of Wire	Signal Name																															
7	B	GND (POWER)																															
10	L	TAIL LH																															


ABLIA5079GB

A B C D E F G H I J K L M N O P


# ILLUMINATION

< WIRING DIAGRAM >


Connector No.	B11	Connector No.	B12
Connector Name	JOINT CONNECTOR-B09	Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE	Connector Color	WHITE



Connector No.	B11	Connector No.	B12
Connector Name	JOINT CONNECTOR-B09	Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE	Connector Color	WHITE



Connector No.	B11	Connector No.	B12
Connector Name	JOINT CONNECTOR-B09	Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE	Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	—
2	P	—

Terminal No.	Color of Wire	Signal Name
1	L	—
2	L	—

Terminal No.	Color of Wire	Signal Name
16	15	14
17	12	11
18	10	9
19	8	7
20	6	5
21	4	3
22	2	1
23	—	—
24	—	—
25	—	—
26	—	—
27	—	—
28	—	—
29	—	—
30	—	—
31	—	—
32	—	—

Terminal No.	Color of Wire	Signal Name
1	P	—
2	P	—

Terminal No.	Color of Wire	Signal Name
1	L	—
2	L	—


Terminal No.	Color of Wire	Signal Name
18	L	—
19	P	—

Terminal No.	Color of Wire	Signal Name
1	L	—
2	L	—

# ILLUMINATION

< WIRING DIAGRAM >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
INL



Connector No.	B102
Connector Name	JOINT CONNECTOR-B14
Connector Color	WHITE


Connector No.	B103
Connector Name	JOINT CONNECTOR-B05
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	R11
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Connector No.	B124
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Terminal No.	Color of Wire	Signal Name
9	B	-
10	W	-

Terminal No.	Color of Wire	Signal Name
1	2	3
2	3	4
3	4	5
4	5	6
5	6	7
6	7	8
7	8	9
8	9	10
9	10	11
10	11	12
11	12	13
12	13	14
13	14	15
14	15	16
15	16	17
16	17	18
17	18	19
18	19	20
19	20	21
20	21	22
21	22	23
22	23	24
23	24	25
24	25	26
25	26	27
26	27	28
27	28	29
28	29	30
29	30	31
30	31	32

Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-


ABIA7137GB

# ILLUMINATION


**< WIRING DIAGRAM >**

---

Connector No.	R101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	R107
Connector Name	FRONT ROOM/MAP LAMP ASSEMBLY
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	B	-
10	W	-

Terminal No.	Color of Wire	Signal Name
13	V	-
14	BR	-


Terminal No.	Color of Wire	Signal Name
7	B	-
8	W	-

Connector No.	D22
Connector Name	DOOR MIRROR REMOTE CONTROL SWITCH (WITH AUTOMATIC DRIVE POSITIONER)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
13	V	-
14	BR	-

Terminal No.	Color of Wire	Signal Name
13	V	-
14	BR	-



Terminal No.	Color of Wire	Signal Name
13	V	-
14	BR	-

ABLIA7138GB

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000012548996

#### OVERALL SEQUENCE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

---

## DETAILED FLOW

### 1. INTERVIEW FOR MALFUNCTION

---

Find out what the customer's concerns are.

>> GO TO 2.

### 2. SYMPTOM CHECK

---

Verify the symptom from the customer's information.

>> GO TO 3.

### 3. BASIC INSPECTION

---

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4.

### 4. SELF-DIAGNOSIS WITH CONSULT

---

Perform the self-diagnosis with CONSULT. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

### 5. TROUBLE DIAGNOSIS BY DTC

---

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

### 6. FAIL-SAFE ACTIVATION CHECK

---

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

### 7. SYSTEM DIAGNOSIS

---

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

### 8. SYMPTOM DIAGNOSIS

---

Perform the symptom diagnosis, refer to [INL-58, "Symptom Table"](#). Specify the malfunctioning part.

>> GO TO 9.

### 9. MALFUNCTION PART REPAIR

---

Repair or replace the malfunctioning part.

>> GO TO 10.

### 10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

---

Perform the self-diagnosis with CONSULT. Verify that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

## DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

NO >> GO TO 11.

### 11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> Inspection End.

NO >> GO TO 3.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT BCM

#### BCM : Diagnosis Procedure

INFOID:0000000012964836

Regarding Wiring Diagram information, refer to [BCS-55, "Wiring Diagram"](#).

#### 1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
139	Fusible link battery power	O (40A)
131	BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

- YES >> Replace the blown fuse or fusible link after repairing the affected circuit.  
NO >> GO TO 2

#### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M81.
2. Check voltage between BCM connector M81 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M81	131	—	Battery voltage
	139		

Is the inspection result normal?

- YES >> GO TO 3  
NO >> Repair or replace harness or connectors.

#### 3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M81 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M81	134	—	Yes
	143		

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

#### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

#### IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:0000000012964837

Regarding Wiring Diagram information, refer to [PCS-21, "Wiring Diagram"](#).

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## 1. CHECK FUSIBLE LINKS

Check that the following fusible links are not blown.

Terminal No.	Signal name	Fusible link No.
1	Fusible link main	E (80A)
2	Fusible link IPDM E/R	A (250A), C (80A)
3	Fusible link ignition switch	A (250A), B (100A), K (40A)

Is the fusible link blown?

- YES >> Replace the blown fusible link after repairing the affected circuit.  
NO >> GO TO 2

## 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R connectors E118 and E120.
2. Check voltage between IPDM E/R connectors and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E118	1	—	Battery voltage
	2		
E120	3	—	—

Is the inspection result normal?

- YES >> GO TO 3  
NO >> Repair or replace harness or connectors.

## 3. CHECK GROUND CIRCUIT

1. Disconnect IPDM E/R connectors E119 and E121.
2. Check continuity between IPDM E/R connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E121	7	—	Yes
	41		

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

# BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

### Description

INFOID:0000000012548999

Provides the battery saver output/power supply. Also cuts the power supply when the interior room lamp battery saver is activating.

### Component Function Check

INFOID:0000000012549000

#### 1. CHECK BATTERY SAVER OUTPUT/POWER SUPPLY FUNCTION

##### (H)CONSULT

1. Turn ignition switch ON.
2. Turn each interior room lamp ON:
  - Front room/map lamp assembly
  - Vanity lamps (if equipped)
  - Personal lamps 2nd row
  - Cargo lamp
3. Open the driver door to turn ON the following lamps:
  - Front step lamps (if equipped)
  - Foot lamps (if equipped)
4. Select BATTERY SAVER of BCM(BATTERY SAVER) active test item.
5. While operating the test item, check that each interior room lamp turns ON/OFF.

**OFF : Interior room lamp OFF**

**ON : Interior room lamp ON**

##### Is the inspection result normal?

YES >> Battery saver output/power supply circuit is normal.

NO >> Refer to [INL-50, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012549001

Regarding Wiring Diagram information, refer to [INL-12, "Wiring Diagram"](#).

#### 1. CHECK BATTERY SAVER OUTPUT/POWER SUPPLY OUTPUT

##### (H)CONSULT

1. Turn ignition switch ON.
2. Select BATTERY SAVER of BCM(BATTERY SAVER) active test item.
3. While operating the test item, check voltage between BCM connector M81 terminal 129 and ground.

(+) Connector		(-) Terminal	Test item	Voltage (Approx.)
Connector	Terminal		BATTERY SAVER	
M81	129	Ground	OFF	0V
			ON	Battery voltage

##### Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace BCM after making sure battery saver output/power supply circuit is not shorted to voltage. Refer to [BCS-81, "Removal and Installation"](#).

#### 2. CHECK BATTERY SAVER OUTPUT/POWER SUPPLY OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the following connectors:
  - BCM M81
  - Front step lamp LH D11(if equipped)
  - Front step lamp RH D109 (if equipped)

## BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

- Foot lamp LH M99 (if equipped)
  - Foot lamp RH M100 (if equipped)
  - Front room/map lamp assembly R107
  - Vanity lamp LH R103 (if equipped)
  - Vanity lamp RH R102 (if equipped)
  - Cargo lamp R104
  - Personal lamps 2nd row R106
3. Check continuity between BCM connector M81 terminal 129 and interior room lamp connector terminal in question.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BCM		Each interior room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M81	129	Front step lamp LH (if equipped)	D11	1
		Front step lamp RH (if equipped)	D109	1
		Foot lamp LH (if equipped)	M99	1
		Foot lamp RH (if equipped)	M100	1
		Front room/map lamp assembly	R107	1
		Vanity lamp LH (if equipped)	R103	1
		Vanity lamp RH (if equipped)	R102	1
		Cargo lamp	R104	2
		Personal lamps 2nd row	R106	2

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connector.

## 3.CHECK BATTERY SAVER OUTPUT/POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM connector M81 terminal 129 and ground.

J  
K  
L  
INL

Connector	Terminal	—	Continuity
M81	129	Ground	No

### Is the inspection result normal?

YES >> Check that each interior room lamp has no internal short circuit.

NO >> Repair or replace harness or connector.

M  
N  
O  
P

# INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## INTERIOR ROOM LAMP CONTROL CIRCUIT

### Description

INFOID:0000000012549002

Controls the room lamp control circuit (ground side) to turn the room lamps ON and OFF.

### Component Function Check

INFOID:0000000012549003

#### CAUTION:

Before performing the diagnosis, check that the following are normal:

- Battery saver output/power supply
- Front room/map lamp bulb
- Personal lamps 2nd row bulb
- Cargo lamp bulb

### 1.CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

#### CONSULT

1. Set the front room/map lamp switch, personal lamps 2nd row switch and cargo lamp switch to DOOR.
2. Turn ignition switch ON.
3. Select INT LAMP of BCM(INT LAMP) active test item.
4. While operating the test item, check that each interior room lamp turn ON/OFF.

On : Interior room lamp On

Off : Interior room lamp Off

#### Does the interior room lamp turn ON/OFF?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-52, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012549004

Regarding Wiring Diagram information, refer to [INL-12, "Wiring Diagram"](#).

### 1.CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

#### CONSULT

1. Turn ignition switch ON.
2. Select INT LAMP of BCM(INT LAMP) active test item.
3. While operating the test item, check voltage between BCM harness connector M81 terminal 136 and ground.

BCM		Ground	Test item		Voltage (Approx.)
Connector	Terminal		INT LAMP	On	
M81	136			Off	
					Battery voltage

#### Is the inspection result normal?

YES >> Interior room lamp control circuit is operating normally.

Fixed ON>>GO TO 3.

Fixed OFF>>GO TO 2.

### 2.CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector M81, front room/map lamp assembly harness connector R107 and cargo lamp harness connector R104.
3. Check continuity between BCM harness connector M81 terminal 136 and front room/map lamp assembly harness connector R107 terminal 3 and cargo lamp harness connector R104 terminal 3.

# INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BCM		Interior room lamp			Continuity
Connector	Terminal	Connector	Terminal		
M81	136	Front room/map lamp	R107	3	Yes
		Cargo lamp	R104	3	

4. Reconnect the front room/map lamp assembly harness connector.
5. Check continuity between BCM harness connector M81 terminal 136 and personal lamps 2nd row harness connector R106 terminal 3.

BCM		Personal lamps 2nd row		Continuity
Connector	Terminal	Connector	Terminal	
M81	136	R106	3	Yes

Is the inspection result normal?

YES >> Check interior room lamps for an open. If NG, replace lamp in question. Refer to [INL-59, "Removal and Installation"](#) (front room/map lamp assembly) or [INL-66, "Removal and Installation"](#) (personal lamps 2nd row) or [INL-67, "Removal and Installation"](#) (cargo lamp). If OK, replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

## 3.CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector M81, front room/map lamp assembly harness connector R107 and cargo lamp harness connector R104.
3. Check continuity between BCM harness connector M81 terminal 136 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M81	136		No

Is the inspection result normal?

YES >> Check interior room lamps for an open. If NG, replace lamp in question. Refer to [INL-59, "Removal and Installation"](#) (front room/map lamp assembly) or [INL-66, "Removal and Installation"](#) (personal lamps 2nd row) or [INL-67, "Removal and Installation"](#) (cargo lamp). If OK, replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## STEP LAMP CIRCUIT

### Description

INFOID:0000000012549005

Controls the step lamp control circuit (ground side) to turn the step lamps (if equipped) and foot lamps (if equipped) ON and OFF.

### Component Function Check

INFOID:0000000012549006

#### CAUTION:

Before performing the diagnosis, check that the following is normal:

- Battery saver output/power supply
- Front step lamp bulb (if equipped)
- Foot lamp bulb (if equipped)

#### 1.CHECK STEP LAMP OPERATION

##### CONSULT

1. Turn ignition switch ON.
2. Select STEP LAMP TEST of BCM(INT LAMP) active test item.
3. While operating the test items, check that front step lamp (if equipped) and foot lamp (if equipped) turns ON/OFF.

On : Step lamp and foot lamp ON

Off : Step lamp and foot lamp OFF

##### Is the inspection result normal?

YES >> Step lamp circuit is normal.

NO >> Refer to [INL-54, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012549007

Regarding Wiring Diagram information, refer to [INL-12, "Wiring Diagram"](#).

#### 1.CHECK STEP LAMP OUTPUT

##### CONSULT

1. Turn ignition switch ON.
2. Select STEP LAMP TEST of BCM (INT LAMP) active test item.
3. While operating the test item, check voltage between BCM harness connector M18 terminal 21 and ground.

BCM		Ground	STEP LAMP TEST	Voltage (Approx.)
Connector	Terminal			
M18	21			
			On	0V
			Off	Battery voltage

##### Is the inspection result normal?

YES >> Step lamp control circuit is operating normally.

Fixed ON>>GO TO 3.

Fixed OFF>>GO TO 2.

#### 2.CHECK STEP LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the following harness connectors:
  - BCM M18
  - Front step lamp LH D11(if equipped)
  - Front step lamp RH D109 (if equipped)
  - Foot lamp LH M99 (if equipped)
  - Foot lamp RH M100 (if equipped)

## STEP LAMP CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between BCM harness connector M18 terminal 21 and the following lamp harness connector terminal.

BCM		Step lamp			Continuity
Connector	Terminal	Connector		Terminal	
M18	21	Front step lamp LH (if equipped)	D11	2	Yes
		Front step lamp RH (if equipped)	D109		
		Foot lamp LH (if equipped)	M99		
		Foot lamp RH (if equipped)	M100		

Is the inspection result normal?

YES >> Check front step lamp (if equipped) or foot lamp (if equipped) for an open. If NG, replace lamp in question. Refer to [INL-65, "Removal and Installation"](#) (step lamp) (if equipped) or [INL-63, "DRIVER SIDE : Removal and Installation"](#) (foot lamp) (if equipped). If OK, replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

### 3.CHECK STEP LAMP SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the following harness connectors:
  - BCM M18
  - Front step lamp LH D11(if equipped)
  - Front step lamp RH D109 (if equipped)
  - Foot lamp LH M99 (if equipped)
  - Foot lamp RH M100 (if equipped)
3. Check continuity between BCM harness connector M18 terminal 21 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M18	21		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

### Description

INFOID:0000000012549008

Provides the power supply and the ground to control the push-button ignition switch illumination.

### Component Function Check

INFOID:0000000012549009

#### 1.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

##### (B)CONSULT

1. Turn the ignition switch ON.
2. Select ENGINE SW ILLUMI of BCM (INTELLIGENT KEY) active test item.
3. While operating the test items, check that the push-button ignition switch illumination turns ON/OFF.

On : Push-button ignition switch illumination ON

Off : Push-button ignition switch illumination OFF

Does the push-button ignition switch illumination turn ON/OFF?

YES >> Push-button ignition switch illumination circuit is normal.

NO >> Refer to [INL-56, "Diagnosis Procedure"](#) .

### Diagnosis Procedure

INFOID:0000000012549010

Regarding Wiring Diagram information, refer to [INL-27, "Wiring Diagram"](#).

#### 1.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

##### (B)CONSULT

1. Turn the ignition switch ON.
2. Select ENGINE SW ILLUMI of BCM (INTELLIGENT KEY) active test item.
3. While operating the test item, check voltage between push-button ignition switch connector M17 terminal 5 and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
Push-button ignition switch	Ground	ENGINE SW ILLUMI	5 V
Connector			
M17			0 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 2.

#### 2.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector M19 and the push-button ignition switch harness connector M17.
3. Check continuity between BCM harness connector M19 terminal 48 and the push-button ignition switch harness connector M17 terminal 5.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M19	48	M17	5	Yes

Is the inspection result normal?

YES >> GO TO 3.

# PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness or connector.

## 3. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM harness connector M19 terminal 48 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M19	48		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Repair or replace harness or connector.

## 4. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect push-button ignition switch harness connector M17.
3. Check continuity between push-button ignition switch harness connector M17 terminal 6 and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M17	6		Yes

Is the inspection result normal?

YES >> Replace push-button ignition switch. Refer to [SEC-153, "Removal and Installation"](#).

NO >> GO TO 5.

## 5. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND OPEN CIRCUIT

1. Disconnect BCM harness connector M80.
2. Check continuity between BCM harness connector M80 terminal 107 and push-button ignition switch harness connector M17 terminal 6.

Push-button ignition switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M17	6	M80	107	Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### INTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000012549011

##### CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All the following lamps do not turn ON: <ul style="list-style-type: none"><li>• Front room/map lamp</li><li>• Personal lamps 2nd row</li><li>• Foot lamp LH/RH (if equipped)</li><li>• Step lamp LH/RH (if equipped)</li><li>• Cargo lamp</li><li>• Vanity lamp LH/RH (if equipped)</li></ul>	<ul style="list-style-type: none"><li>• Harness between BCM and each interior room lamp</li><li>• BCM</li></ul>	Battery saver output/power supply circuit Refer to <a href="#">INL-50</a> .
<ul style="list-style-type: none"><li>• Interior room lamp does not turn ON even though the door is open. (It turns ON when turning the interior room lamp ON.)</li><li>• Interior room lamp does not turn OFF even though the door is closed.</li></ul>	<ul style="list-style-type: none"><li>• Harness between BCM and each door switch</li><li>• Harness between BCM and each interior room lamp</li><li>• BCM</li></ul>	Door switch circuit Refer to <a href="#">DLK-168</a> .  Interior room lamp control circuit Refer to <a href="#">INL-52</a> .
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to <a href="#">BCS-18</a> .
<ul style="list-style-type: none"><li>• Step lamps (if equipped) and foot lamps (if equipped) do not turn ON even though the door is open.</li><li>• Step lamps (if equipped) and foot lamps (if equipped) do not turn OFF even though the door is closed.</li></ul>	<ul style="list-style-type: none"><li>• Harness between BCM and each step lamp (if equipped) or foot lamp (if equipped)</li><li>• BCM</li></ul>	Door switch circuit Refer to <a href="#">DLK-168</a> .  Step lamp circuit Refer to <a href="#">INL-54</a> .
Push-button ignition switch illumination does not illuminate.	<ul style="list-style-type: none"><li>• Harness between BCM and push-button ignition switch</li><li>• BCM</li></ul>	Push-button ignition switch illumination circuit Refer to <a href="#">INL-56</a> .
Interior room lamp battery saver does not activate.	BCM	Replace BCM. Refer to <a href="#">BCS-81</a> .

# FRONT ROOM/MAP LAMP ASSEMBLY


< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### FRONT ROOM/MAP LAMP ASSEMBLY

#### Exploded View

INFOID:000000012549012



1. Front room/map lamp assembly A. LED

#### Removal and Installation


INFOID:000000012549013

##### CAUTION:

Do not attempt to separate the front room/map lamp assembly from the headlining prior to removing headlining, or damage to the components may occur.

##### REMOVAL

1. Remove the headlining. Refer to [INT-27, "Removal and Installation"](#).
2. Remove the bracket screws, then remove front room/map lamp assembly bracket (1) from front room/map assembly (3) and position aside.
3. Disconnect the harness connectors from front room/map lamp assembly (3).
4. Release the front room/map lamp assembly back plate (2) metal clips and remove from headlining.  
□: Metal clip
5. Release the back plate pawls (A) using a suitable tool and remove the front room/map lamp assembly (3).  
○: Pawl



#### INSTALLATION

Installation is in the reverse order of removal.

##### CAUTION:

## FRONT ROOM/MAP LAMP ASSEMBLY

### < REMOVAL AND INSTALLATION >

**Visually check the metal clips and pawls for deformation and damage during installation. Replace with new ones if necessary.**

#### Bulb or Lens Replacement

INFOID:0000000012549014

**WARNING:**

**Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.**

**CAUTION:**

**Do not attempt to separate the LED bulb from the front room/map lamp assembly or damage to the components may occur**

The LED bulb is replaced as part of the front room/map lamp assembly. Refer to [INL-59, "Removal and Installation"](#)


# VANITY LAMP

< REMOVAL AND INSTALLATION >

## VANITY LAMP

### Exploded View

INFOID:0000000012549015



1. Lens

2. Bulb

Pawl

### Removal and Installation

INFOID:0000000012549016

#### CAUTION:

Do not attempt to separate the vanity lamp from the sun visor or damage to the components may occur.

The vanity lamp is replaced as part of the sun visor. Refer to [INT-27, "Removal and Installation"](#).

### Bulb or Lens Replacement

INFOID:0000000012549017

#### WARNING:

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

#### CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.
- Do not attempt to separate the vanity lamp from the sun visor or damage to the components may occur.

1. Insert a suitable tool into the gap between the lens and vanity lamp, then gently release the lens pawls and remove.
2. Grasp the bulb and pull straight out of the vanity lamp to remove.
3. Install vanity lamp bulb to vanity lamp.
4. Install the vanity lamp lens.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P


# GLOVE BOX LAMP

< REMOVAL AND INSTALLATION >

## GLOVE BOX LAMP

### Exploded View

INFOID:0000000012549018



1. Glove box assembly

2. Bulb

3. Bulb socket

### Bulb Replacement

INFOID:0000000012549019

#### **WARNING:**

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

#### **CAUTION:**

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.

1. Remove glove box. Refer to [IP-26, "Removal and Installation"](#).
2. Rotate the bulb socket counterclockwise and remove.
3. Grasp the bulb and pull straight out of the bulb socket to remove.
4. Install glove box lamp bulb to bulb socket.
5. Insert bulb socket into glove box and rotate clockwise to lock in position.
6. Install glove box. Refer to [IP-26, "Removal and Installation"](#).


# FOOT LAMP

< REMOVAL AND INSTALLATION >

## FOOT LAMP DRIVER SIDE

### DRIVER SIDE : Exploded View

INFOID:0000000012549020



AWLIA1975ZZ

1. Bulb socket
2. Instrument lower panel LH
3. Foot lamp housing
4. Bulb

### DRIVER SIDE : Removal and Installation

INFOID:0000000012549021

The foot lamp housing is replaced as part of the instrument lower panel LH. Refer to [IP-25, "Removal and Installation"](#).

### DRIVER SIDE : Bulb Replacement

INFOID:0000000012549022

#### **WARNING:**

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

#### **CAUTION:**

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.

1. Remove instrument lower panel LH. Refer to [IP-25, "Removal and Installation"](#).
2. Rotate the bulb socket counterclockwise and remove.
3. Grasp the bulb and pull straight out of the bulb socket to remove.
4. Install foot lamp bulb to bulb socket.
5. Insert bulb socket into foot lamp housing and rotate clockwise to lock in position.
6. Install the instrument lower panel LH. Refer to [IP-25, "Removal and Installation"](#).

### PASSENGER SIDE

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O


P

# FOOT LAMP

< REMOVAL AND INSTALLATION >

PASSENGER SIDE : Exploded View

INFOID:0000000012549023



1. Bulb                            2. Bulb socket                            3. Instrument panel substrate

Front

PASSENGER SIDE : Bulb Replacement

INFOID:0000000012549024

**WARNING:**

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

**CAUTION:**

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.

1. Reach under instrument panel on RH side, locate foot lamp socket, rotate the bulb socket and remove.
2. Grasp the bulb and pull straight out of the bulb socket to remove.
3. Install foot lamp bulb to bulb socket.
4. Insert bulb socket into instrument panel substrate and rotate to lock in position.


# FRONT STEP LAMP

< REMOVAL AND INSTALLATION >

## FRONT STEP LAMP

### Exploded View

INFOID:0000000012549025



1. Step lamp harness connector

2. Step lamp

3. Bulb

### Removal and Installation

INFOID:0000000012549026

#### REMOVAL

1. Insert a suitable tool into the gap between the front step lamp and front door finisher and gently release the pawls and the front step lamp.
2. Disconnect the harness connector from the front step lamp and remove.

#### INSTALLATION

Installation is in the reverse order of removal.

### Bulb or Lens Replacement

INFOID:0000000012549027

#### **WARNING:**

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

#### **CAUTION:**

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.

INL

1. Remove the front step lamp. Refer to [INL-65, "Removal and Installation"](#).
2. Grasp the bulb and pull straight out from the front step lamp to remove.
3. Install the front step lamp bulb to front step lamp.
4. Install the front step lamp. Refer to [INL-65, "Removal and Installation"](#)

M

N

O

P

# PERSONAL LAMP

< REMOVAL AND INSTALLATION >

## PERSONAL LAMP

### Removal and Installation

INFOID:0000000012549028

#### REMOVAL

The personal lamp is serviced as part of headlining. Refer to [INT-27, "Removal and Installation"](#)

#### Bulb or Lens Replacement

INFOID:0000000012549029

##### **WARNING:**

**Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.**

##### **CAUTION:**

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.
- Do not attempt to separate the personal lamp from the headlining or damage may occur.

1. Insert a suitable tool into the gap between the lens and personal lamp, then gently release the lens pawls and remove.
2. Grasp the bulb and pull straight out from its socket to remove.
3. Install personal lamp bulb to personal lamp.
4. Install the personal lamp lens.


# CARGO LAMP

< REMOVAL AND INSTALLATION >

## CARGO LAMP

### Exploded View

INFOID:0000000012549030



1. Cargo lamp                    2. Bulb                    3. Lens  
A. Pawls to release first for lens re- B. Pawl to install first for lens in- C. Pawl  
moval                            stallation  
[ ] Metal clip

### Removal and Installation

INFOID:0000000012549031

#### REMOVAL

1. Insert a suitable tool into the gap between the headlining and cargo lamp and gently release the metal clips and remove.
2. Disconnect the harness connector from cargo lamp.

#### INSTALLATION

Installation is in the reverse order of removal.

### Bulb or Lens Replacement

INFOID:0000000012549032

#### WARNING:

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

#### CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.
- Release and insert pawl as indicated in exploded view or damage may occur.

1. Beginning at the switch end, insert a suitable tool into the gap between the lens and cargo lamp, then gently release the lens pawls and remove.
2. Push the tab to release one bulb end, then grasp the bulb and pull out the second end from its socket to remove.
3. Install cargo lamp bulb to cargo lamp.
4. Insert pawl at the end opposite the switch first, then insert the remaining two pawls to lock the lens in position.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

INL

# ILLUMINATION CONTROL SWITCH

< REMOVAL AND INSTALLATION >


## ILLUMINATION CONTROL SWITCH

### Removal and Installation


INFOID:0000000012549033

#### Removal

1. Remove cluster lid A. Refer to [IP-21, "Removal and Installation"](#).
2. Release the harness connector from cluster lid A.



3. Release the pawls (A) and remove illumination control switch (1) through the front of cluster lid A (2).



#### INSTALLATION

Installation is in the reverse order of removal.

## **SERVICE DATA AND SPECIFICATIONS (SDS)**

< SERVICE DATA AND SPECIFICATIONS (SDS)

# **SERVICE DATA AND SPECIFICATIONS (SDS)**

## **SERVICE DATA AND SPECIFICATIONS (SDS)**

### **Bulb Specifications**

INFOID:000000012549034

Item	Wattage (W)*
Front room/map lamp	LED
Illumination control switch	—
Vanity lamp (if equipped)	—
Glove box lamp	3.4
Foot lamp (if equipped)	3.4
Step lamp (if equipped)	3.8
Personal lamp	8
Cargo lamp	8

\*:Always check with the parts department for the latest parts information.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P