

# SECTION WW

## WIPER & WASHER

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## CONTENTS

<b>BASIC INSPECTION .....</b>	3	Component Function Check .....	20
<b>DIAGNOSIS AND REPAIR WORKFLOW .....</b>	3	Diagnosis Procedure .....	20
Work Flow .....	3		
<b>FUNCTION DIAGNOSIS .....</b>	4		
<b>FRONT WIPER AND WASHER SYSTEM .....</b>	4	<b>FRONT WIPER AUTO STOP SIGNAL CIRCUIT .....</b>	22
System Diagram .....	4	Component Function Check .....	22
System Description .....	4	Diagnosis Procedure .....	22
Component Parts Location .....	7	<b>FRONT WIPER MOTOR GROUND CIRCUIT .....</b>	24
Component Description .....	7	Diagnosis Procedure .....	24
<b>REAR WIPER AND WASHER SYSTEM .....</b>	8	<b>WASHER SWITCH .....</b>	25
System Diagram .....	8	Description .....	25
System Description .....	8	Component Inspection .....	25
Component Parts Location .....	10	<b>REAR WIPER MOTOR CIRCUIT .....</b>	27
Component Description .....	10	Component Function Check .....	27
<b>DIAGNOSIS SYSTEM (BCM) .....</b>	11	Diagnosis Procedure .....	27
<b>COMMON ITEM .....</b>	11	<b>REAR WIPER AUTO STOP SIGNAL CIRCUIT .....</b>	29
COMMON ITEM : CONSULT-III Function (BCM -		Component Function Check .....	29
COMMON ITEM) .....	11	Diagnosis Procedure .....	29
<b>WIPER .....</b>	11	<b>FRONT WIPER AND WASHER SYSTEM .....</b>	30
WIPER : CONSULT-III Function (BCM - WIPER) ...	12	Wiring Diagram .....	30
<b>DIAGNOSIS SYSTEM (IPDM E/R) .....</b>	13	<b>REAR WIPER AND WASHER SYSTEM .....</b>	35
Diagnosis Description .....	13	Wiring Diagram .....	35
CONSULT - III Function (IPDM E/R) .....	15	<b>ECU DIAGNOSIS .....</b>	42
<b>COMPONENT DIAGNOSIS .....</b>	17	<b>BCM (BODY CONTROL MODULE) .....</b>	42
<b>WIPER AND WASHER FUSE .....</b>	17	Reference Value .....	42
Description .....	17	Terminal Layout .....	45
Diagnosis Procedure .....	17	Physical Values .....	45
<b>FRONT WIPER MOTOR LO CIRCUIT .....</b>	18	Wiring Diagram .....	51
Component Function Check .....	18	Fail Safe .....	54
Diagnosis Procedure .....	18	DTC Inspection Priority Chart .....	55
<b>FRONT WIPER MOTOR HI CIRCUIT .....</b>	20	DTC Index .....	55
<b>IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) .....</b>	57		

WW

Reference Value .....	57	<b>PRECAUTION .....</b>	<b>76</b>
Terminal Layout .....	58	<b>PRECAUTION .....</b>	<b>76</b>
Physical Values .....	59	Precalution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	76
Wiring Diagram .....	63	Precalutions Necessary for Steering Wheel Rota- tion after Battery Disconnect .....	76
Fail Safe .....	67		
DTC Index .....	69		
<b>SYMPTOM DIAGNOSIS .....</b>	<b>70</b>	<b>ON-VEHICLE REPAIR .....</b>	<b>78</b>
<b>WIPER AND WASHER SYSTEM SYMPTOMS</b>		<b>FRONT WIPER AND WASHER SYSTEM .....</b>	<b>78</b>
... 70		Removal and Installation .....	78
Symptom Table .....	70	Washer Nozzle Adjustment .....	82
<b>NORMAL OPERATING CONDITION .....</b>	<b>73</b>	<b>REAR WIPER AND WASHER SYSTEM .....</b>	<b>83</b>
Description .....	73	Removal and Installation .....	83
<b>FRONT WIPER DOES NOT OPERATE .....</b>	<b>74</b>	Rear Washer Nozzle Adjustment .....	86
Description .....	74		
Diagnosis Procedure .....	74		

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000005256347

#### DETAILED FLOW

##### 1. LISTEN TO CUSTOMER COMPLAINT

Listen to customer complaint. Get detailed information about the conditions and environment when the symptom occurs.

>> GO TO 2

##### 2. VERIFY THE SYMPTOM WITH OPERATIONAL CHECK

Verify the symptom with operational check. Refer to [WW-13, "Diagnosis Description"](#).

>> GO TO 3

##### 3. GO TO APPROPRIATE TROUBLE DIAGNOSIS

Go to appropriate trouble diagnosis. Refer to [WW-70, "Symptom Table"](#).

>> GO TO 4

##### 4. REPAIR OR REPLACE

Repair or replace the specific parts.

>> GO TO 5

##### 5. FINAL CHECK

Final check.

Is inspection result normal?

YES >> Inspection End.

NO >> Refer to [GI-37, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER AND WASHER SYSTEM


< FUNCTION DIAGNOSIS >

## FUNCTION DIAGNOSIS

### FRONT WIPER AND WASHER SYSTEM

#### System Diagram

INFOID:0000000005256348



#### System Description

INFOID:0000000005256349

#### OUTLINE

The front wiper is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Front wiper control function

Control by IPDM E/R

- Front wiper control function
- Relay control function

#### FRONT WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front wiper request signal to IPDM E/R with CAN communication depending on each operating condition of the front wiper.
- IPDM E/R turns ON/OFF the integrated front wiper relay and the front wiper high relay according to the front wiper request signal. IPDM E/R provides the power supply to operate the front wiper HI/LO operation.

#### FRONT WIPER LO OPERATION

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the front wiper LO operating condition.

Front wiper LO operating condition

- Ignition switch ON
- Front wiper switch LO or front wiper switch MIST (while pressing)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).

#### FRONT WIPER HI OPERATION

- BCM transmits the front wiper request signal (HI) to IPDM E/R with CAN communication according to the front wiper HI operating condition.

Front wiper HI operating condition

- Ignition switch ON
- Front wiper switch HI
- IPDM E/R turns ON the integrated front wiper relay and the front wiper high relay according to the front wiper request signal (HI).

#### FRONT WIPER INT OPERATION (LINKED WITH VEHICLE SPEED)

# FRONT WIPER AND WASHER SYSTEM

## < FUNCTION DIAGNOSIS >

- BCM transmits the front wiper request signal (INT) to IPDM E/R with CAN communication according to the front wiper INT operation condition and the intermittent operation delay interval judged value.

Front wiper INT operating condition


- Ignition switch ON
- Front wiper switch INT

Intermittent operation delay interval judgment

- BCM calculates the intermittent operation delay interval from the vehicle speed signal received from the wiper dial position and the combination meter with CAN communication.

Wiper intermittent dial position	Intermittent operation interval	Intermittent operation delay Interval (s)			
		Vehicle speed			
		Vehicle stopped or less than 5 km/h (3.1 MPH)	5 km/h (3.1 MPH) or more or less than 35 km/h (21.7 MPH)	35 km/h (21.7 MPH) or more or less than 65 km/h (40.4 MPH)	65 km/h (40.4 MPH) or more
1	Short ↑ ↓ Long	0.8	0.6	0.4	0.24
2		4	3	2	1.2
3		10	7.5	5	3
4		16	12	8	4.8
5		24	18	12	7.2
6		32	24	16	9.6
7		42	31.5	21	12.6

- IPDM E/R turns the integrated front wiper relay ON so that the front wiper is operated only once according to the front wiper request signal (INT).
- BCM detects stop position/except stop position of the front wiper motor according to the front wiper stop position signal received from IPDM E/R with CAN communication.
- BCM transmits the front wiper request signal (INT) again after the intermittent operation delay interval after the front wiper motor is stopped.



JPLIA0094GB


## FRONT WIPER AUTO STOP OPERATION

- BCM stops transmitting the front wiper request signal when the front wiper switch is turned OFF.
- IPDM E/R detects the front wiper auto stop signal from the front wiper motor and detects the front wiper motor position (stop position/except stop position).

# FRONT WIPER AND WASHER SYSTEM

## < FUNCTION DIAGNOSIS >

- When the front wiper request signal is stopped, IPDM E/R turns ON the front wiper relay until the front wiper motor returns to the stop position.



### NOTE:

- BCM stops the transmitting of the front wiper request signal when the ignition switch is OFF.
- IPDM E/R turns the front wiper relay OFF when the ignition switch is OFF.

## FRONT WIPER OPERATION LINKED WITH WASHER

- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication according to the washer linked operating condition of the front wiper.
- BCM transmits the front wiper request signal (LO) so that the front wiper operates approximately 3 times when the front washer switch OFF is detected.

### Washer linked operating condition of front wiper

- Ignition switch ON
- Front washer switch ON (0.4 second or more)
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).
- The front and rear washer motor is grounded through the combination switch with the front washer switch ON.

## FRONT WIPER DROP WIPE OPERATION

- BCM controls the front wiper to operate once according to the conditions of front wiper drop wipe operation.

### Front wiper drop wipe operating condition

- Ignition switch ON
- Front wiper switch OFF
- Front washer switch OFF
- BCM transmits the front wiper request signal (LO) to IPDM E/R with CAN communication so that the front wiper operate once three seconds after front wiper operation linked with washer.
- IPDM E/R turns ON the integrated front wiper relay according to the front wiper request signal (LO).

## FRONT WIPER FAIL-SAFE OPERATION


- IPDM E/R performs the fail-safe function when the front wiper auto stop circuit is malfunctioning. Refer to [WW-67, "Fail Safe"](#).

# FRONT WIPER AND WASHER SYSTEM

< FUNCTION DIAGNOSIS >

## Component Parts Location

INFOID:0000000005256350



ALLIA0617ZZ

1. BCM M18, M20 (view with instrument lower panel LH removed)
2. Front and rear washer motor E105
3. Washer fluid reservoir
4. Front wiper motor E23 (view with cowl top removed)
5. IPDM E/R E121, E122, E124
6. Combination switch M28

## Component Description

INFOID:0000000005256351

Part	Description
BCM	<ul style="list-style-type: none"> <li>Judges each switch status by the combination switch reading function.</li> <li>Requests (with CAN communication) the front wiper relay and the front wiper high relay ON to IPDM E/R.</li> </ul>
IPDM E/R	<ul style="list-style-type: none"> <li>Controls the integrated relay according to the request (with CAN communication) from BCM.</li> <li>Performs the auto stop control of the front wiper.</li> </ul>
Combination switch (Wiper and washer switch)	Refer to <a href="#">WW-4. "System Diagram"</a> .
Combination meter	Transmits the vehicle speed signal to BCM with CAN communication.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K


WW  
M  
N  
O  
P

# REAR WIPER AND WASHER SYSTEM

< FUNCTION DIAGNOSIS >

## REAR WIPER AND WASHER SYSTEM

### System Diagram



### System Description

INFOID:0000000005256353

#### OUTLINE

The rear wiper is controlled by each function of BCM.

#### Control by BCM

- Combination switch reading function
- Rear wiper control function

#### REAR WIPER BASIC OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM controls the rear wiper to start or stop.

#### REAR WIPER ON OPERATION

- BCM supplies power to the rear wiper motor according to the rear wiper ON operating condition.

#### Rear wiper ON operating condition


- Ignition switch ON
- Rear wiper switch ON

#### REAR WIPER INT OPERATION

- BCM supplies power to the rear wiper motor according to the INT operating condition.

#### Rear wiper INT operating condition

- Ignition switch ON
- Rear wiper switch INT
- BCM controls the rear wiper to operate once.
- BCM detects the rear wiper motor stopping position.
- BCM supplies power to the rear wiper motor after an intermittent from the stop of the rear wiper motor.




#### REAR WIPER AUTO STOP OPERATION

- BCM stops supplying power to the rear wiper motor when the rear wiper switch is turned OFF.

## REAR WIPER AND WASHER SYSTEM

### < FUNCTION DIAGNOSIS >

- BCM reads an auto stop signal from the rear wiper motor to detect a rear wiper motor position.
- When the rear wiper motor is at other than the stopping position, BCM continues to supply power to the rear wiper motor until it returns to the stopping position.



#### NOTE:

BCM stops supplying power to the rear wiper motor when the ignition switch is turned OFF.

### REAR WIPER OPERATION LINKED WITH WASHER

- BCM supplies power to the rear wiper motor according to the washer linked operating condition of rear wiper. When the rear washer switch is turned OFF, BCM controls rear wiper to operate approximately three times.

Washer linked operating condition of rear wiper

- Ignition switch ON
- Rear washer switch ON (0.4 second or more)
- Front and rear washer motor becomes grounded through the combination switch when the rear washer switch is turned ON.

### REAR WIPER DROP WIPE OPERATION

- BCM controls the rear wiper to operate once according to the rear wiper drop wipe operating condition.

Rear wiper drop wipe operating condition

- Ignition switch ON
- Rear wiper switch OFF
- Rear washer switch OFF
- BCM controls the rear wiper so that it operates once time approximately three seconds later after the washer interlocking operation of the rear wiper.

### REAR WIPER FAIL-SAFE OPERATION


BCM performs the fail-safe function when the rear wiper auto stop circuit is malfunctioning. Refer to [BCS-53, "Fail Safe"](#).

# REAR WIPER AND WASHER SYSTEM

## < FUNCTION DIAGNOSIS >

### Component Parts Location

INFOID:0000000005256354



ALLIA0618ZZ

1. BCM M18, M19, M20 (view with instrument lower panel LH removed)
2. Front and rear washer motor connector E105
3. Washer fluid reservoir
4. Combination switch M28
5. Rear washer nozzle
6. Rear wiper motor D602
7. Glass hatch ajar switch D503

### Component Description

INFOID:0000000005256355

Part	Description
BCM	<ul style="list-style-type: none"><li>• Judges each switch status by the combination switch reading function.</li><li>• Supplies power to the rear wiper motor.</li><li>• Performs the auto stop control of the rear wiper.</li></ul>
Combination switch (Wiper and washer switch)	Refer to <a href="#">WW-4, "System Diagram"</a> .

# DIAGNOSIS SYSTEM (BCM)

< FUNCTION DIAGNOSIS >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT-III Function (BCM - COMMON ITEM)

INFOID:000000005484553

##### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
WORK SUPPORT	Changes the setting for each system function.
SELF-DIAG RESULTS	Displays the diagnosis results judged by BCM. Refer to <a href="#">BCS-54, "DTC Index"</a> .
CAN DIAG SUPPORT MNTR	Monitors the reception status of CAN communication viewed from BCM.
DATA MONITOR	The BCM input/output signals are displayed.
ACTIVE TEST	The signals used to activate each device are forcibly supplied from BCM.
ECU IDENTIFICATION	The BCM part number is displayed.
CONFIGURATION	<ul style="list-style-type: none"><li>Enables to read and save the vehicle specification.</li><li>Enables to write the vehicle specification when replacing BCM.</li></ul>

##### SYSTEM APPLICATION

BCM can perform the following functions for each system.

##### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

System	Sub system selection item	Diagnosis mode		
		WORK SUPPORT	DATA MONITOR	ACTIVE TEST
BCM	BCM	x		
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER		x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Remote keyless entry system <sup>1</sup>	MULTI REMOTE ENT	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER		x	x
Air conditioner	AIR CONDITIONER		x	
Intelligent Key system <sup>2</sup>	INTELLIGENT KEY		x	
Combination switch	COMB SW		x	
Immobilizer	IMMU		x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Back door open	TRUNK		x	x
RAP (retained accessory power)	RETAINED PWR	x	x	x
Signal buffer system	SIGNAL BUFFER		x	x
TPMS (tire pressure monitoring system)	AIR PRESSURE MONITOR	x	x	x
Vehicle security system	THEFT ALM	x	x	x
Panic alarm	PANIC ALARM			x

1: With remote keyless entry system

2: With Intelligent Key

## WIPER

## **DIAGNOSIS SYSTEM (BCM)**

## < FUNCTION DIAGNOSIS >

---

WIPER : CONSULT-III Function (BCM - WIPER)

INFOID:0000000005484554

## WORK SUPPORT

Work Item	Setting Item	Description
WIPER SPEED SETTING	ON*	With vehicle speed (Front wiper intermittent time linked with the vehicle speed and wiper intermittent dial position)
	OFF	Without vehicle speed (Front wiper intermittent time linked with the wiper intermittent dial position)

\*: Factory setting

## DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [ON/OFF]	Ignition switch ON status judged from ignition power supply
IGN SW CAN [ON/OFF]	Ignition switch ON status received from IPDM E/R with CAN communication
FR WIPER HI [ON/OFF]	Each switch status that BCM judges from the combination switch reading function
FR WIPER LOW [ON/OFF]	
FR WIPER INT [ON/OFF]	
FR WASHER SW [ON/OFF]	
INT VOLUME [1 - 7]	Each switch status that BCM judges from the combination switch reading function
FR WIPER STOP [ON/OFF]	Front wiper motor (stop position) status received from IPDM E/R with CAN communication
VEHICLE SPEED [km/h]	The value of the vehicle speed signal received from combination meter with CAN communication
RR WIPER ON [ON/OFF]	Each switch status that BCM judges from the combination switch reading function
RR WIPER INT [ON/OFF]	
RR WASHER SW [ON/OFF]	
RR WIPER STOP [ON/OFF]	Rear wiper motor (stop position) status input from the rear wiper motor

## ACTIVE TEST

Test Item	Operation	Description
FR WIPER	HI	Transmits the front wiper request signal (HI) to IPDM E/R with CAN communication to operate the front wiper HI operation.
	LO	Transmits the front wiper request signal (LO) to IPDM E/R with CAN communication to operate the front wiper LO operation.
	INT	Transmits the front wiper request signal (INT) to IPDM E/R with CAN communication to operate the front wiper INT operation.
	OFF	Stops transmitting the front wiper request signal to stop the front wiper operation.
RR WIPER	ON	Outputs the voltage to operate the rear wiper motor.
	OFF	Stops the voltage to stop.

# DIAGNOSIS SYSTEM (IPDM E/R)

< FUNCTION DIAGNOSIS >

## DIAGNOSIS SYSTEM (IPDM E/R)

### Diagnosis Description

INFOID:000000005484555

#### AUTO ACTIVE TEST

##### Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure low warning indicator
- Oil pressure gauge
- Rear window defogger
- Front wipers
- Tail, license and parking lamps
- Front fog lamps (if equipped)
- Headlamps (Hi, Lo)
- A/C compressor (magnetic clutch)
- Cooling fan

##### Operation Procedure

1. Close the hood and front door RH, and lift the wiper arms from the windshield (to prevent windshield damage due to wiper operation).
- NOTE:**  
When auto active test is performed with hood opened, sprinkle water on windshield before hand.
2. Turn ignition switch OFF.
3. Turn the ignition switch ON and, within 20 seconds, press the front door switch LH 10 times. Then turn the ignition switch OFF.
4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

##### NOTE:


When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.

##### CAUTION:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-55, "Description"](#) (with Intelligent Key system), [DLK-226, "Description"](#) (without Intelligent Key system).
- Do not start the engine.

##### Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following 7 steps are repeated 3 times.




Operation sequence	Inspection Location	Operation
1	Rear window defogger	10 seconds
2	Front wipers	LO for 5 seconds → HI for 5 seconds

# DIAGNOSIS SYSTEM (IPDM E/R)

## < FUNCTION DIAGNOSIS >

Operation sequence	Inspection Location	Operation
3	Tail, license, front fog and parking lamps	10 seconds
4	Headlamps	LO for 10 seconds → HI on-off for 5 seconds
5	A/C compressor (magnetic clutch)	ON ⇄ OFF 5 times
6	Cooling fan	10 seconds

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Oil pressure low warning indicator does not operate	Perform auto active test. Does the oil pressure low warning indicator operate?	YES
		NO
Oil pressure gauge does not operate	Perform auto active test. Does the oil pressure gauge operate?	YES
		NO
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES
		NO

# DIAGNOSIS SYSTEM (IPDM E/R)

## < FUNCTION DIAGNOSIS >

Symptom	Inspection contents	Possible cause
Any of the following components do not operate • Front wipers • Tail lamps • License plate lamps • Parking lamps • Front fog lamps (if equipped) • Headlamps (Hi, Lo)	Perform auto active test. Does the applicable system operate?	YES BCM signal input system
		NO <ul style="list-style-type: none"> <li>Lamp or front wiper motor malfunction</li> <li>Lamp or front wiper motor ground circuit</li> <li>Harness or connector between IPDM E/R and applicable system</li> <li>IPDM E/R (integrated relay malfunction)</li> </ul>
A/C compressor does not operate	Perform auto active test. Does the A/C compressor operate?	YES <ul style="list-style-type: none"> <li>BCM signal input circuit</li> <li>CAN communication signal between BCM and ECM</li> <li>CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>Magnetic clutch malfunction</li> <li>Harness or connector between IPDM E/R and magnetic clutch</li> <li>IPDM E/R (integrated relay malfunction)</li> </ul>
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES <ul style="list-style-type: none"> <li>ECM signal input circuit</li> <li>CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>Cooling fan motor malfunction</li> <li>Harness or connector between IPDM E/R and cooling fan</li> <li>IPDM E/R (integrated relay malfunction)</li> </ul>

## CONSULT - III Function (IPDM E/R)

INFOID:000000005484556

K

WW

### APPLICATION ITEM

CONSULT-III performs the following functions via CAN communication with IPDM E/R.

M

N

O

P

Diagnosis mode	Description
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAGNOSTIC

Refer to [PCS-30, "DTC Index"](#).

### DATA MONITOR

Monitor item

Monitor Item [Unit]	MAIN SIGNALS	Description
MOTOR FAN REQ [1/2/3/4]	×	Displays the status of the cooling fan speed request signal received from ECM via CAN communication.
AC COMP REQ [OFF/ON]	×	Displays the status of the A/C request signal received from AV control unit via CAN communication.

# DIAGNOSIS SYSTEM (IPDM E/R)

## < FUNCTION DIAGNOSIS >

Monitor Item [Unit]	MAIN SIG- NAL(S)	Description
TAIL&CLR REQ [OFF/ON]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [OFF/ON]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [OFF/ON]	×	Displays the status of the high beam request signal received from BCM via CAN communication.
FR FOG REQ [OFF/ON]	×	Displays the status of the front fog lamp request signal received from BCM via CAN communication.
FR WIP REQ [STOP/1LOW/LOW/HI]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper auto stop signal judged by IPDM E/R.
WIP PROT [OFF/Block]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
ST RLY REQ [OFF/ON]		Displays the status of the starter request signal received from ECM via CAN communication.
IGN RLY [OFF/ON]	×	Displays the status of the ignition relay judged by IPDM E/R.
RR DEF REQ [OFF/ON]	×	Displays the status of the rear defogger request signal received from AV control unit via CAN communication.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
DTRL REQ [OFF]		Displays the status of the daytime light request signal received from BCM via CAN communication.
THFT HRN REQ [OFF/ON]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [OFF/ON]		Displays the status of the horn reminder signal received from BCM via CAN communication.

## ACTIVE TEST

### Test item

Test item	Operation	Description
REAR DEFOGGER	OFF	OFF
	ON	Operates rear window defogger relay.
FRONT WIPER	OFF	OFF
	LO	Operates the front wiper relay.
	HI	Operates the front wiper relay and front wiper high relay.
MOTOR FAN	1	OFF
	2	OFF
	3	Operates the cooling fan relay.
	4	Operates the cooling fan relay.
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and the headlamp (LH/RH) high relays alternately at 1 second intervals.
	Fog	Operates the front fog lamp relay
HORN	ON	Operates horn relay for 20 ms.

## WIPER AND WASHER FUSE

< COMPONENT DIAGNOSIS >

# COMPONENT DIAGNOSIS

## WIPER AND WASHER FUSE

### Description

INFOID:000000005256360

Fuse list

Unit	Location	Fuse No.	Capacity
Front wiper motor	IPDM E/R	39	30 A
Front and rear washer motor	Fuse block (J/B)	15	10 A

### Diagnosis Procedure

INFOID:000000005256361

#### 1. CHECK FUSES

Check that the following fuses are not blown.

Unit	Location	Fuse No.	Capacity
Front wiper motor	IPDM E/R	39	30 A
Front and rear washer motor	Fuse block (J/B)	15	10 A

#### Is the fuse blown?

YES    >> Replace the fuse after repairing the applicable circuit.

NO      >> The fuse is normal.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER MOTOR LO CIRCUIT

< COMPONENT DIAGNOSIS >

## FRONT WIPER MOTOR LO CIRCUIT

### Component Function Check

INFOID:0000000005256362

#### 1. CHECK FRONT WIPER LO OPERATION

☒ IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).

2. Check that the front wiper operates at the LO operation.

Ⓐ CONSULT-III ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.

2. While operating the test item, check front wiper operation.

**LO** : Front wiper (LO) operation

**OFF** : Stop the front wiper.

Is front wiper (LO) operation normal?

YES >> Front wiper motor LO circuit is normal.

NO >> Refer to [WW-18, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000005256363

Regarding Wiring Diagram information, refer to [WW-30, "Wiring Diagram"](#).

#### 1. CHECK FRONT WIPER MOTOR FUSE

1. Turn the ignition switch OFF.

2. Check that the following fuse is not blown.

Unit	Location	Fuse No.	Capacity
Front wiper motor	IPDM E/R	39	30 A

Is the fuse blown?

YES >> GO TO 2

NO >> GO TO 3

#### 2. CHECK FRONT WIPER MOTOR (LO) SHORT CIRCUIT

1. Disconnect IPDM E/R and front wiper motor.

2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E121	32		No


Does continuity exist?

YES >> Repair or replace harness.

NO >> Replace the fuse. (Replace IPDM E/R if the fuse is blown again.)

#### 3. CHECK FRONT WIPER MOTOR (LO) OUTPUT VOLTAGE

Ⓐ CONSULT-III ACTIVE TEST




# FRONT WIPER MOTOR LO CIRCUIT

## < COMPONENT DIAGNOSIS >

1. Turn the ignition switch ON.
2. Select "FRONT WIPER" of IPDM E/R active test item.
3. While operating the test item, check voltage between IPDM E/R harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R Connector	Terminal E121	FRONT WIPER Ground	
			LO      Battery voltage
	32		OFF      0V



Is the measurement value normal?

YES >> GO TO 4

NO >> Replace IPDM E/R. Refer to [PCS-33, "Removal and Installation of IPDM E/R"](#).

## 4. CHECK FRONT WIPER MOTOR (LO) OPEN CIRCUIT


1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R and front wiper motor.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E121	32	E23	1	Yes

Does continuity exist?

YES >> Replace front wiper motor. Refer to [WW-78, "Removal and Installation"](#).

NO >> Repair or replace harness.



# FRONT WIPER MOTOR HI CIRCUIT

< COMPONENT DIAGNOSIS >

## FRONT WIPER MOTOR HI CIRCUIT

### Component Function Check

INFOID:0000000005256364

#### 1. CHECK FRONT WIPER HI OPERATION

##### IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the front wiper operates at the HI operation.

##### CONSULT-III ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.
2. While operating the test item, check front wiper operation.

**HI : Front wiper (HI) operation**

**OFF : Stop the front wiper.**

Is front wiper (HI) operation normal?

YES >> Front wiper motor HI circuit is normal.

NO >> Refer to [WW-20, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000005256365

Regarding Wiring Diagram information, refer to [WW-30, "Wiring Diagram"](#).

#### 1. CHECK FRONT WIPER MOTOR FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuse is not blown.

Unit	Location	Fuse No.	Capacity
Front wiper motor	IPDM E/R	39	30 A

Is the fuse blown?

YES >> GO TO 2  
NO >> GO TO 3


#### 2. CHECK FRONT WIPER MOTOR (HI) SHORT CIRCUIT

1. Disconnect IPDM E/R and front wiper motor.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E121	35		No

Does continuity exist?

YES >> Repair or replace harness.  
NO >> Replace the fuse. (Replace IPDM E/R if the fuse is blown again.)



#### 3. CHECK FRONT WIPER MOTOR (HI) OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

# FRONT WIPER MOTOR HI CIRCUIT

## < COMPONENT DIAGNOSIS >

1. Turn the ignition switch ON.
2. Select "FRONT WIPER" of IPDM E/R active test item.
3. While operating the test item, check voltage between IPDM E/R harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R Connector	Terminal	FRONT WIPER	
			Battery voltage
			0 V
Ground		HI	

Is the measurement value normal?

YES >> GO TO 4

NO >> Replace IPDM E/R. Refer to [PCS-33, "Removal and Installation of IPDM E/R"](#).

## 4. CHECK FRONT WIPER MOTOR (HI) OPEN CIRCUIT



1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R and front wiper motor.
3. Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E121	35	E23	4	Yes

Does continuity exist?

YES >> Replace front wiper motor. Refer to [WW-78, "Removal and Installation"](#).

NO >> Repair or replace harness.



# FRONT WIPER AUTO STOP SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

## FRONT WIPER AUTO STOP SIGNAL CIRCUIT

### Component Function Check

INFOID:0000000005256366

#### 1. CHECK FRONT WIPER (AUTO STOP) SIGNAL CHECK

##### CONSULT-III DATA MONITOR

1. Select "FR WIPER STOP" of IPDM E/R data monitor item.
2. Operate the front wiper.
3. Check that "FR WIPER STOP" changes to "ON" and "OFF" linked with the wiper operation.

Monitor item	Condition		Monitor status
FR WIPER STOP	Front wiper motor	Stop position	ON
		Except stop position	OFF

Is the status of item normal?

- YES >> Front wiper auto stop signal circuit is normal.  
NO >> Refer to [WW-22, "Diagnosis Procedure"](#).

### Diagnosis Procedure


INFOID:0000000005256367

Regarding Wiring Diagram information, refer to [WW-30, "Wiring Diagram"](#).

#### 1. CHECK FRONT WIPER MOTOR (AUTO STOP) OUTPUT VOLTAGE

1. Turn the ignition switch ON.
2. Check voltage between IPDM E/R harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
IPDM E/R	Ground	
Connector	Terminal	Battery voltage
E122	43	




Is the measurement value normal?

- YES >> GO TO 3  
NO >> GO TO 2

#### 2. CHECK FRONT WIPER MOTOR (AUTO STOP) SHORT CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R and front wiper motor.
3. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Continuity
Connector	Terminal	
E122	43	No



Does continuity exist?

- YES >> Repair or replace harness.  
NO >> Replace IPDM E/R. Refer to [PCS-33, "Removal and Installation of IPDM E/R"](#).

#### 3. CHECK FRONT WIPER MOTOR (AUTO STOP) CIRCUIT CONTINUITY

# FRONT WIPER AUTO STOP SIGNAL CIRCUIT

## < COMPONENT DIAGNOSIS >


Check continuity between IPDM E/R harness connector and front wiper motor harness connector.

IPDM E/R		Front wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
E122	43	E23	5	Yes

### Does continuity exist?

YES    >> Replace front wiper motor. Refer to [WW-78, "Removal and Installation"](#).

NO      >> Repair or replace harness.



# FRONT WIPER MOTOR GROUND CIRCUIT

< COMPONENT DIAGNOSIS >

## FRONT WIPER MOTOR GROUND CIRCUIT

### Diagnosis Procedure

INFOID:000000005256368

Regarding Wiring Diagram information, refer to [WW-30, "Wiring Diagram".](#)


#### 1. CHECK FRONT WIPER MOTOR (GROUND) OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect front wiper motor.
3. Check continuity between front wiper motor harness connector and ground.

Front wiper motor		Ground	Continuity
Connector	Terminal		
E23	2		Yes

#### Does continuity exist?

- YES    >> Front wiper motor ground circuit is normal.  
NO    >> Repair or replace harness.



# WASHER SWITCH


< COMPONENT DIAGNOSIS >

## WASHER SWITCH

### Description

INFOID:0000000005256369

- Washer switch is integrated with combination switch.
- Combination switch switches polarity between front washer operating and rear washer operating to supply power to the front and rear washer motor on ground.



### Component Inspection

INFOID:0000000005256370

#### 1. CHECK FRONT WASHER SWITCH

1. Turn the ignition switch OFF.
2. Disconnect combination switch.
3. Check continuity between the combination switch terminals.

A: Terminal 14


B: Terminal 12

C: Terminal 13

D: Terminal 11

	OFF	FR	RR
A		○	○
B		○	○
C		○	○
D		○	○

JPLIA0164GB



Combination switch		Condition	Continuity
Terminal			
11	12	Front washer switch ON	Yes
13	14		

Does continuity exist?

YES >> GO TO 2

NO >> Replace combination switch. Refer to [WW-78, "Removal and Installation"](#).

#### 2. CHECK REAR WASHER SWITCH

# WASHER SWITCH

## < COMPONENT DIAGNOSIS >

Check continuity between the combination switch terminals.

A: Terminal 14


B: Terminal 12

C: Terminal 13

D: Terminal 11

	OFF	FR	RR
A		○	○
B		○	○
C	○		○
D	○	○	

JPLIA0164GB



ALLIA0840ZZ

Combination switch		Condition	Continuity
Terminal			
11	14	Rear washer switch ON	Yes
12	13		

### Does continuity exist?

YES >> Wiper and washer switch is normal.

NO >> Replace combination switch. Refer to [WW-78, "Removal and Installation".](#)

# REAR WIPER MOTOR CIRCUIT

< COMPONENT DIAGNOSIS >

## REAR WIPER MOTOR CIRCUIT

### Component Function Check

INFOID:000000005256371

#### 1. CHECK REAR WIPER ON OPERATION

##### CONSULT-III ACTIVE TEST

1. Select "RR WIPER" of BCM active test item.
2. While operating the test item, check rear wiper operation.

**ON : Rear wiper ON operation**

**OFF : Stop the rear wiper.**

Is rear wiper operation normal?

YES >> Rear wiper motor circuit is normal.

NO >> Refer to [WW-27, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005256372


Regarding Wiring Diagram information, refer to [WW-35, "Wiring Diagram"](#).

#### 1. CHECK REAR WIPER MOTOR OUTPUT VOLTAGE

##### CONSULT-III ACTIVE TEST

1. Turn the ignition switch OFF.
2. Disconnect rear wiper motor.
3. Turn the ignition switch ON.
4. Select "RR WIPER" of BCM active test item.
5. While operating the test item, check voltage between BCM harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
BCM		REAR WIPER	
Connector	Terminal		
M19	55	Ground	Battery voltage
			0V



Is the measurement value normal?

YES >> GO TO 2

NO >> GO TO 3

#### 2. CHECK REAR WIPER MOTOR GROUND CIRCUIT


1. Turn the ignition switch OFF.
2. Check continuity between rear wiper motor harness connector and ground.

Rear wiper motor		Ground	Continuity
Connector	Terminal		
D602	42		Yes

Does continuity exist?

YES >> Replace rear wiper motor. Refer to [WW-83, "Removal and Installation"](#).

NO >> Repair or replace harness.



# REAR WIPER MOTOR CIRCUIT

< COMPONENT DIAGNOSIS >

## 3. CHECK GLASS HATCH AJAR SWITCH CIRCUIT


1. Disconnect BCM.
2. Turn ignition switch OFF.
3. Make sure hatch glass is closed
4. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M19	42		No

Does continuity exist?

- YES    >> Repair harness if shorted. If not, refer to [SEC-47, "Diagnosis Procedure"](#) (with Intelligent Key system) or [SEC-148, "Diagnosis Procedure"](#) (without Intelligent Key system).

NO    >> GO TO 4



## 4. CHECK REAR WIPER MOTOR OPEN CIRCUIT


1. Check continuity between BCM harness connector and rear wiper motor harness connector.

BCM		Rear wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
M19	55	D602	4	Yes

Does continuity exist?

YES    >> GO TO 5

NO    >> Repair or replace harness.



## 5. CHECK REAR WIPER MOTOR SHORT CIRCUIT


Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M19	55		No

Does continuity exist?

YES    >> Repair or replace harness.

NO    >> Replace BCM. Refer to [BCS-59, "Removal and Installation"](#).



# REAR WIPER AUTO STOP SIGNAL CIRCUIT

< COMPONENT DIAGNOSIS >

## REAR WIPER AUTO STOP SIGNAL CIRCUIT

### Component Function Check

INFOID:000000005256373

#### 1. CHECK REAR WIPER (AUTO STOP) OPERATION

##### CONSULT-III DATA MONITOR

1. Select "WIPER" of BCM data monitor item.
2. Operate the rear wiper.
3. Check that "RR WIPER STOP" changes to "ON" and "OFF" linked with the wiper operation.

Monitor item	Condition		Monitor status
RR WIPER STOP	Rear wiper motor	Stop position	ON
		Except stop position	OFF

Is the status of item normal?

- YES >> Rear wiper auto stop signal circuit is normal.  
NO >> Refer to [WW-29, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005256374

Regarding Wiring Diagram information, refer to [WW-35, "Wiring Diagram"](#).


#### 1. CHECK REAR WIPER MOTOR AUTO STOP CIRCUITS

1. Turn ignition switch OFF.
2. Disconnect BCM and rear wiper motor.
3. Check continuity between BCM harness connector terminals and rear wiper motor harness connector terminals.

BCM		Rear wiper motor		Continuity
Connector	Terminal	Connector	Terminal	
M19	44	D602	2	Yes

Is inspection result normal?

- YES >> GO TO 2  
NO >> Repair or replace harness.




#### 2. CHECK AUTO STOP CIRCUITS FOR SHORT TO GROUND

Check continuity between BCM harness connector terminals and ground.

BCM		Ground	Continuity
Connector	Terminal		
M19	44		No

Is inspection result normal?

- YES >> Replace BCM. Refer to [BCS-59, "Removal and Installation"](#).  
NO >> Repair or replace harness.




# **FRONT WIPER AND WASHER SYSTEM**

## < COMPONENT DIAGNOSIS >

## **FRONT WIPER AND WASHER SYSTEM**

## Wiring Diagram

INFOID:000000005256375




# FRONT WIPER AND WASHER SYSTEM

## < COMPONENT DIAGNOSIS >

### FRONT WIPER AND WASHER SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9P	W/G	-
15P	W/R	-

Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

ABLIA0384GB

# FRONT WIPER AND WASHER SYSTEM


**< COMPONENT DIAGNOSIS >**

Terminal No.	Color of Wire	Signal Name
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3
11	O	WASHER MOTOR (RR+)
12	B	GND
13	L	WASHER MOTOR (RR-)
14	W/G	IGN



Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3



Terminal No.	Color of Wire	Signal Name
M91		
Connector Name	WIRE TO WIRE	
Connector Color	WHITE	



Terminal No.	Color of Wire	Signal Name
78G	O	—
79G	L	—



Terminal No.	Color of Wire	Signal Name
M31		
Connector Name	WIRE TO WIRE	
Connector Color	WHITE	





ABLIA0385GB

# FRONT WIPER AND WASHER SYSTEM

**< COMPONENT DIAGNOSIS >**

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E23
Connector Name	FRONT WIPER MOTOR
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
7	W	-

Terminal No.	Color of Wire	Signal Name
1	GR	-
2	B	-
4	L	-
5	G	-


Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-



Connector No.	E105
Connector Name	FRONT AND REAR WASHER MOTOR
Connector Color	BLACK




Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
32	GR	FR WIPER LO
35	L	FR WIPER HI

ABLIA1650GB


A B C D E F G H I J K L M N O P Q R S T U V W Z

# FRONT WIPER AND WASHER SYSTEM

## < COMPONENT DIAGNOSIS >


Terminal No.	Color of Wire	Signal Name
78G	O	--
79G	L	--

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK
	

Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)



ABLIA1651GB

# REAR WIPER AND WASHER SYSTEM


< COMPONENT DIAGNOSIS >

## REAR WIPER AND WASHER SYSTEM

### Wiring Diagram

INFOID:0000000005256376

#### REAR WIPER AND WASHER SYSTEM



ABLWA0543GB

# REAR WIPER AND WASHER SYSTEM

**< COMPONENT DIAGNOSIS >**

---

## REAR WIPER AND WASHER SYSTEM CONNECTORS


Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9P	W/G	—
15P	W/R	—

Terminal No.	Color of Wire	Signal Name
4	V	INPUT 3
5	L	INPUT 2

Terminal No.	Color of Wire	Signal Name
6	R	INPUT 1
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW



Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
42	LG	GLASS HATCH SW
44	O	REAR WIPER AUTO STOP SW 1



Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4

# REAR WIPER AND WASHER SYSTEM

**< COMPONENT DIAGNOSIS >**

Terminal No.	Color of Wire	Signal Name
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3
11	O	WASHER MOTO (RR+)
12	B	GND
13	L	WASHER MOTO (RR-)
14	W/G	IGN


Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3


Terminal No.	Color of Wire	Signal Name
78G	O	—
79G	L	—

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
67	B	GND (POWER)
70	W	BAT (F/L)

Terminal No.	Color of Wire	Signal Name
78G	O	—
79G	L	—



ABLIA0388GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
WW  
Z  
M  
O  
P

## **REAR WIPER AND WASHER SYSTEM**

## < COMPONENT DIAGNOSIS >


Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	W	—

Terminal No.	Color of Wire	Signal Name
78G	O	-
79G	L	-

Terminal No.	Color of Wire	Signal Name
55J	O	—
56J	LG	—
74J	W	—



Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Connector No.	E105
Connector Name	FRONT AND REAR WASHER MOTOR
Connector Color	BLACK

1G	2G	3G	4G	5G
6G	7G	8G	9G	10G
11G	12G	13G	14G	15G
16G	17G	18G	19G	20G
21G	22G	23G	24G	25G
26G	27G	28G	29G	30G
31G	32G	33G	34G	35G
36G	37G	38G	39G	40G
41G	42G	43G	44G	45G
46G	47G	48G	49G	50G
51G	52G	53G	54G	55G
56G	57G	58G	59G	60G
61G	62G	63G	64G	65G
66G	67G	68G	69G	70G
71G	72G	73G	74G	75G
76G	77G	78G	79G	80G

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Connector No.	E105
Connector Name	FRONT AND REAR WASHER MOTOR
Connector Color	BLACK

ABLIA0389GB

# REAR WIPER AND WASHER SYSTEM

< COMPONENT DIAGNOSIS >

Connector No.	B43
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	LG	-

Connector No.	D401
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
55J	O	-
56J	LG	-
74J	W	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABLIA0390GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
WW  
Z

# REAR WIPER AND WASHER SYSTEM


**< COMPONENT DIAGNOSIS >**

---

Connector No.	D402
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
4	O	-




Connector No.	D404
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	B	-
6	LG	-

Connector No.	D408
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	D405
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	LG	-
1	-	-

Connector No.	D503
Connector Name	GLASS HATCH AJAR SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	-	-
6	LG	-

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	LG	-
1	-	-

Connector No.	D502
Connector Name	GLASS HATCH OPEN SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	-	-
6	LG	-

# REAR WIPER AND WASHER SYSTEM

## < COMPONENT DIAGNOSIS >

Connector No.	D602
Connector Name	REAR WIPER MOTOR
Connector Color	WHITE



Connector No.	D601
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-
3	O	-
4	W	-

Terminal No.	Color of Wire	Signal Name
2	R	-
3	O	-
4	W	-

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

ABLIA1653GB

## BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

# ECU DIAGNOSIS

## BCM (BODY CONTROL MODULE)

### Reference Value

INFOID:0000000005484834

### VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
AIR COND SW	A/C switch OFF	OFF
	A/C switch ON	ON
AUT LIGHT SYS	Outside of the room is dark	OFF
	Outside of the room is bright	ON
AUTO LIGHT SW	Lighting switch OFF	OFF
	Lighting switch AUTO	ON
BACK DOOR SW	Back door closed	OFF
	Back door opened	ON
CDL LOCK SW	Door lock/unlock switch does not operate	OFF
	Press door lock/unlock switch to the LOCK side	ON
CDL UNLOCK SW	Door lock/unlock switch does not operate	OFF
	Press door lock/unlock switch to the UNLOCK side	ON
DOOR SW-AS	Front door RH closed	OFF
	Front door RH opened	ON
DOOR SW-DR	Front door LH closed	OFF
	Front door LH opened	ON
DOOR SW-RL	Rear door LH closed	OFF
	Rear door LH opened	ON
DOOR SW-RR	Rear door RH closed	OFF
	Rear door RH opened	ON
ENGINE RUN	Engine stopped	OFF
	Engine running	ON
FR FOG SW	Front fog lamp switch OFF	OFF
	Front fog lamp switch ON	ON
FR WASHER SW	Front washer switch OFF	OFF
	Front washer switch ON	ON
FR WIPER LOW	Front wiper switch OFF	OFF
	Front wiper switch LO	ON
FR WIPER HI	Front wiper switch OFF	OFF
	Front wiper switch HI	ON
FR WIPER INT	Front wiper switch OFF	OFF
	Front wiper switch INT	ON
FR WIPER STOP	Any position other than front wiper stop position	OFF
	Front wiper stop position	ON
HAZARD SW	When hazard switch is not pressed	OFF
	When hazard switch is pressed	ON
LIGHT SW 1ST	Lighting switch OFF	OFF
	Lighting switch 1st	ON

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status	
HEAD LAMP SW1	Headlamp switch OFF	OFF	A
	Headlamp switch 1st	ON	
HEAD LAMP SW2	Headlamp switch OFF	OFF	B
	Headlamp switch 1st	ON	
HI BEAM SW	High beam switch OFF	OFF	C
	High beam switch HI	ON	
IGN ON SW	Ignition switch OFF or ACC	OFF	D
	Ignition switch ON	ON	
IGN SW CAN	Ignition switch OFF or ACC	OFF	E
	Ignition switch ON	ON	
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7	
I-KEY LOCK <sup>1</sup>	LOCK button of Intelligent Key is not pressed	OFF	F
	LOCK button of Intelligent Key is pressed	ON	
I-KEY UNLOCK <sup>1</sup>	UNLOCK button of Intelligent Key is not pressed	OFF	G
	UNLOCK button of Intelligent Key is pressed	ON	
KEY ON SW	Mechanical key is removed from key cylinder	OFF	H
	Mechanical key is inserted to key cylinder	ON	
KEYLESS LOCK <sup>2</sup>	LOCK button of key fob is not pressed	OFF	I
	LOCK button of key fob is pressed	ON	
KEYLESS UNLOCK <sup>2</sup>	UNLOCK button of key fob is not pressed	OFF	J
	UNLOCK button of key fob is pressed	ON	
OIL PRESS SW	• Ignition switch OFF or ACC • Engine running	OFF	K
	Ignition switch ON	ON	
PASSING SW	Other than lighting switch PASS	OFF	WW
	Lighting switch PASS	ON	
PUSH SW <sup>1</sup>	Return to ignition switch to LOCK position	OFF	M
	Press ignition switch	ON	
REAR DEF SW	Rear window defogger switch OFF	OFF	N
	Rear window defogger switch ON	ON	
RR WASHER SW	Rear washer switch OFF	OFF	O
	Rear washer switch ON	ON	
RR WIPER INT	Rear wiper switch OFF	OFF	P
	Rear wiper switch INT	ON	
RR WIPER ON	Rear wiper switch OFF	OFF	
	Rear wiper switch ON	ON	
RR WIPER STOP	Rear wiper stop position	OFF	
	Other than rear wiper stop position	ON	
TAIL LAMP SW	Lighting switch OFF	OFF	
	Lighting switch 1ST	ON	
TRNK OPNR SW	When back door opener switch is not pressed	OFF	
	When back door opener switch is pressed	ON	
TURN SIGNAL L	Turn signal switch OFF	OFF	
	Turn signal switch LH	ON	

## **BCM (BODY CONTROL MODULE)**

### < ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status
TURN SIGNAL R	Turn signal switch OFF	OFF
	Turn signal switch RH	ON
VEHICLE SPEED	While driving	Equivalent to speedometer reading

1: With Intelligent Key

2: With remote keyless entry system


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Terminal Layout

INFOID:000000005484835

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P










Physical Values

LIIA2443E

INFOID:000000005484836





# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)		
				Ignition switch	Operation or condition			
1	BR	Ignition keyhole illumination	Output	OFF	Door is locked (SW OFF)		Battery voltage	
					Door is unlocked (SW ON)		0V	
2	P	Combination switch input 5	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4		 SKIA5291E	
3	SB	Combination switch input 4	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4		 SKIA5292E	
4	V	Combination switch input 3	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4		 SKIA5291E	
5	L	Combination switch input 2	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4		 SKIA5292E	
6	R	Combination switch input 1						
9	Y	Rear window defogger switch	Input	ON	Rear window defogger switch ON	0V	 SKIA5292E	
					Rear window defogger switch OFF	5V		
11	G/B	Ignition switch (ACC or ON)	Input	ACC or ON	Ignition switch ACC or ON	Battery voltage		
12	LG	Front door switch RH	Input	OFF	ON (open)	0V	 SKIA5292E	
					OFF (closed)	Battery voltage		
13	L	Rear door switch RH	Input	OFF	ON (open)	0V	 SKIA5292E	
					OFF (closed)	Battery voltage		
15	W	Tire pressure warning check connector	Input	OFF	—	5V		
18	BR	Remote keyless entry receiver and optical sensor (ground)	Output	OFF	—	0V		

# BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
19	V	Remote keyless entry receiver (power supply)	Output	OFF	Ignition switch OFF	 LIIA1893E
20	G	Remote keyless entry receiver (signal)	Input	OFF	Stand-by (keyfob buttons released)	 LIIA1894E
					When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed)	 LIIA1895E
21	GR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage.
22	V	BUS	—	—	Ignition switch ON or power window timer operates	 PIIA2344E
23	G	Security indicator lamp	Output	OFF	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0V
25	BR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage.
27	W	Compressor ON signal	Input	ON	A/C switch OFF	5V
					A/C switch ON	0V
28	LG	Front blower monitor	Input	ON	Front blower motor OFF	Battery voltage
					Front blower motor ON	0V
29	G	Hazard switch	Input	OFF	ON	0V
					OFF	5V
30 <sup>1</sup>	G	Back door opener switch	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
30 <sup>2</sup>	SB	Back door opener switch	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage

A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
 J  
 K  
 WW  
 M  
 N  
 O  
 P



# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
32	O	Combination switch output 5	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
33	GR	Combination switch output 4	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
34	G	Combination switch output 3	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
35	BR	Combination switch output 2	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
36	LG	Combination switch output 1				
37 <sup>1</sup>	B	Key switch and key lock solenoid	Input	OFF	Key inserted	Battery voltage
					Key inserted	0V
37 <sup>2</sup>	B	Key switch and ignition knob switch	Input	OFF	Intelligent Key inserted	Battery voltage
					Intelligent Key inserted	0V
38	W/R	Ignition switch (ON)	Input	ON	—	Battery voltage
39	L	CAN-H	—	—	—	—
40	P	CAN-L	—	—	—	—
42	LG	Glass hatch ajar switch	Input	ON	Glass hatch open	0V
					Glass hatch closed	Battery voltage
43	P	Back door latch switch	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
44	O	Rear wiper auto stop switch	Input	ON	Rise up position (rear wiper arm on stopper)	0V
					A Position (full clockwise stop position)	Battery voltage
					Forward sweep (counterclockwise direction)	Fluctuating
					B Position (full counterclockwise stop position)	0V
					Reverse sweep (clockwise direction)	Fluctuating
47	GR	Front door switch LH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
48	P	Rear door switch LH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
49	L	Cargo lamp	Output	OFF	Any door open (ON)	0V
					All doors closed (OFF)	Battery voltage
51	O	Trailer turn signal (right)	Output	ON	Turn right ON	 SKIA3009J
52	LG	Trailer turn signal (left)	Output	ON	Turn left ON	 SKIA3009J
53	L	Back door latch actuator	Output	OFF	OFF	0
					ON	Battery voltage
55	W	Rear wiper output circuit 1	Output	ON	OFF	0
					ON	Battery voltage
56	R/Y	Battery saver output	Output	OFF	30 minutes after ignition switch is turned OFF	0V
					ON	—
57	R/Y	Battery power supply	Input	OFF	—	Battery voltage
58	W	Optical sensor	Input	ON	When optical sensor is illuminated	3.1V or more
					When optical sensor is not illuminated	0.6V or less
59	GR	Front door lock assembly LH actuator (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage

A

B

C

D

E

F

G

H

I

J

K

WW

M



N

O

P

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
60	LG	Turn signal (left)	Output	ON	Turn left ON	 SKIA3009J
61	G	Turn signal (right)	Output	ON	Turn right ON	 SKIA3009J
63	BR	Interior room/map lamp	Output	OFF	Any door switch ON (open) OFF (closed)	0V Battery voltage
65	V	All door lock actuators (lock)	Output	OFF	OFF (neutral) ON (lock)	0V Battery voltage
66	L	Front door lock actuator RH, rear door lock actuators LH/RH and glass hatch lock actuator (unlock)	Output	OFF	OFF (neutral) ON (unlock)	0V Battery voltage
67	B	Ground	Input	ON	—	0V
68	O	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
69	L	Power window power supply	Output	—	—	Battery voltage
70	W	Battery power supply	Input	OFF	—	Battery voltage

1: With remote keyless entry system


2: With Intelligent Key system

## **BCM (BODY CONTROL MODULE)**

## < ECU DIAGNOSIS >

## Wiring Diagram


INFOID:000000005484837



ABMWA0471GB

## **BCM (BODY CONTROL MODULE)**

## < ECU DIAGNOSIS >




ABMWA0472GB

# BCM (BODY CONTROL MODULE)

**< ECU DIAGNOSIS >**

## BCM (BODY CONTROL MODULE) CONNECTORS

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	KEY RING OUTPUT
2	P	INPUT 5
3	SB	INPUT 4
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
7	--	--
8	--	--
9	Y	REAR DEFOGGER SW
10	--	--

Terminal No.	Color of Wire	Signal Name
1	G/B	ACC SW
11	LG	DOOR SW (AS)
12	L	DOOR SW (RR)
13	--	--
14	--	--
15	W	TPMS MODE TRIGGER SW
16	--	--
17	--	--
18	BR	KEYLESS AND AUTOLIGHT SENSOR GND
19	V	KEYLESS TUNER POWER SUPPLY OUTPUT
20	G	KEYLESS TUNER SIGNAL
21	GR	IMMobilizer ANTENNA SIG (CLOCK)
22	V	ANTI-PINCH SERIAL LINK (RX,TX)
23	G	SECURITY INDICATOR OUTPUT

Terminal No.	Color of Wire	Signal Name
25	BR	IMMOBILIZER ANTENNA SIGNAL (TX,RX)
26	--	--
27	W	AIRCON SW
28	LG	BLOWER FAN SW
29	G	HAZARD SW
30	SB	BACK DOOR AUTO CLOSURE (WITH INTELLIGENT KEY SYSTEM)
31	--	--
32	O	LIFTGATE OPENER SW (WITHOUT INTELLIGENT KEY SYSTEM)
33	GR	KEYLESS AND AUTOLIGHT SENSOR GND
34	G	KEYLESS TUNER SIGNAL
35	BR	IMMobilizer ANTENNA SIG (CLOCK)
36	LG	ANTI-PINCH SERIAL LINK (RX,TX)
37	B	SECURITY INDICATOR OUTPUT
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
52	LG	TRAILER FLASHER OUTPUT (LEFT)
53	L	LIFTGATE OPENER OUTPUT
54	--	--
55	W	REAR WIPER MOTOR OUTPUT


Terminal No.	Color of Wire	Signal Name
44	O	REAR WIPER AUTO STOP SW1
45	--	--
46	--	--
47	GR	DOOR SW (DR)
48	P	DOOR SW (RL)
49	L	LUGGAGE LAMP OUTPUT
50	--	--
51	O	TRAILER FLASHER OUTPUT (RIGHT)

ABMIA1287GB


# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Connector No.	M20	Terminal No.	Color of Wire	Signal Name
Connector Name	BCM (BODY CONTROL MODULE)	61	G	FLASHER OUTPUT (RIGHT)
Connector Color	BLACK	62	-	-
		63	BR	ROOM LAMP
		64	-	-
		65	V	DOOR LOCK OUTPUT (ALL)
		66	L	DOOR UNLOCK OUTPUT (OTHER)
		67	B	GND (POWER)
		68	O	POWER WINDOW POWER SUPPLY OUTPUT (LINKED TO RAP)
		69	L	POWER WINDOW POWER SUPPLY OUTPUT (BAT)
		70	W	BAT (F/L)



Connector No.	M28	Terminal No.	Color of Wire	Signal Name
Connector Name	COMBINATION SWITCH	1	LG	INPUT 1
Connector Color	WHITE	2	BR	INPUT 2
		3	G	INPUT 3
		4	GR	INPUT 4
		5	O	INPUT 5
		6	R	OUTPUT 1
		7	L	OUTPUT 2
		8	P	OUTPUT 5
		9	SB	OUTPUT 4
		10	V	OUTPUT 3
		11	O	WASHER MOTOR (RR+)
		12	B	GND
		13	L	WASHER MOTOR (RR-)
		14	W/G	IGN



Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3
11	O	WASHER MOTOR (RR+)
12	B	GND
13	L	WASHER MOTOR (RR-)
14	W/G	IGN

ABMIA1288GB

INFOID:0000000005484838

## Fail Safe

### Fail-safe index

BCM performs fail-safe control when any DTC listed below is detected.

# BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS >

Display contents of CONSULT	Fail-safe	Cancellation
U1000: CAN COMM CIRCUIT	Inhibit engine cranking	When the BCM re-establishes communication with the other modules.

## DTC Inspection Priority Chart

INFOID:000000005484839

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	<ul style="list-style-type: none"><li>• U1000: CAN COMM CIRCUIT</li></ul>
2	<ul style="list-style-type: none"><li>• B2190: NATS ANTENNA AMP</li><li>• B2191: DIFFERENCE OF KEY</li><li>• B2192: ID DISCORD BCM-ECM</li><li>• B2193: CHAIN OF BCM-ECM</li><li>• B2013: STRG COMM 1</li><li>• B2552: INTELLIGENT KEY</li><li>• B2590: NATS MALFUNCTION</li></ul>
3	<ul style="list-style-type: none"><li>• C1729: VHCL SPEED SIG ERR</li><li>• C1735: IGNITION SIGNAL</li></ul>
4	<ul style="list-style-type: none"><li>• C1704: LOW PRESSURE FL</li><li>• C1705: LOW PRESSURE FR</li><li>• C1706: LOW PRESSURE RR</li><li>• C1707: LOW PRESSURE RL</li><li>• C1708: [NO DATA] FL</li><li>• C1709: [NO DATA] FR</li><li>• C1710: [NO DATA] RR</li><li>• C1711: [NO DATA] RL</li><li>• C1712: [CHECKSUM ERR] FL</li><li>• C1713: [CHECKSUM ERR] FR</li><li>• C1714: [CHECKSUM ERR] RR</li><li>• C1715: [CHECKSUM ERR] RL</li><li>• C1716: [PRESSDATA ERR] FL</li><li>• C1717: [PRESSDATA ERR] FR</li><li>• C1718: [PRESSDATA ERR] RR</li><li>• C1719: [PRESSDATA ERR] RL</li><li>• C1720: [CODE ERR] FL</li><li>• C1721: [CODE ERR] FR</li><li>• C1722: [CODE ERR] RR</li><li>• C1723: [CODE ERR] RL</li><li>• C1724: [BATT VOLT LOW] FL</li><li>• C1725: [BATT VOLT LOW] FR</li><li>• C1726: [BATT VOLT LOW] RR</li><li>• C1727: [BATT VOLT LOW] RL</li></ul>

## DTC Index

INFOID:000000005484840

### NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
  - 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

# BCM (BODY CONTROL MODULE)

## < ECU DIAGNOSIS >

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Tire pressure monitor warning lamp ON	Reference page
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	—	—	—	<a href="#">BCS-33</a>
B2013: STRG COMM 1	—	—	—	<a href="#">SEC-29</a>
B2190: NATS ANTENNA AMP	—	—	—	<a href="#">SEC-32</a> (with I-Key), <a href="#">SEC-136</a> (without I-Key)
B2191: DIFFERENCE OF KEY	—	—	—	<a href="#">SEC-35</a> (with I-Key), <a href="#">SEC-139</a> (without I-Key)
B2192: ID DISCORD BCM-ECM	—	—	—	<a href="#">SEC-36</a> (with I-Key), <a href="#">SEC-140</a> (without I-Key)
B2193: CHAIN OF BCM-ECM	—	—	—	<a href="#">SEC-38</a> (with I-Key), <a href="#">SEC-142</a> (without I-Key)
B2552: INTELLIGENT KEY	—	—	—	<a href="#">SEC-40</a>
B2590: NATS MALFUNCTION	—	—	—	<a href="#">SEC-41</a>
C1708: [NO DATA] FL	—	—	—	<a href="#">WT-14</a>
C1709: [NO DATA] FR	—	—	—	<a href="#">WT-14</a>
C1710: [NO DATA] RR	—	—	—	<a href="#">WT-14</a>
C1711: [NO DATA] RL	—	—	—	<a href="#">WT-14</a>
C1712: [CHECKSUM ERR] FL	—	—	—	<a href="#">WT-16</a>
C1713: [CHECKSUM ERR] FR	—	—	—	<a href="#">WT-16</a>
C1714: [CHECKSUM ERR] RR	—	—	—	<a href="#">WT-16</a>
C1715: [CHECKSUM ERR] RL	—	—	—	<a href="#">WT-16</a>
C1716: [PRESSDATA ERR] FL	—	—	—	<a href="#">WT-18</a>
C1717: [PRESSDATA ERR] FR	—	—	—	<a href="#">WT-18</a>
C1718: [PRESSDATA ERR] RR	—	—	—	<a href="#">WT-18</a>
C1719: [PRESSDATA ERR] RL	—	—	—	<a href="#">WT-18</a>
C1720: [CODE ERR] FL	—	—	—	<a href="#">WT-16</a>
C1721: [CODE ERR] FR	—	—	—	<a href="#">WT-16</a>
C1722: [CODE ERR] RR	—	—	—	<a href="#">WT-16</a>
C1723: [CODE ERR] RL	—	—	—	<a href="#">WT-16</a>
C1724: [BATT VOLT LOW] FL	—	—	—	<a href="#">WT-16</a>
C1725: [BATT VOLT LOW] FR	—	—	—	<a href="#">WT-16</a>
C1726: [BATT VOLT LOW] RR	—	—	—	<a href="#">WT-16</a>
C1727: [BATT VOLT LOW] RL	—	—	—	<a href="#">WT-16</a>
C1729: VHCL SPEED SIG ERR	—	—	—	<a href="#">WT-19</a>
C1735: IGNITION SWITCH	—	—	—	—

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

### Reference Value

INFOID:000000005484841

### VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
MOTOR FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc. 0 - 100 %
AC COMP REQ	A/C switch OFF	OFF
	A/C switch ON	ON
TAIL&CLR REQ	Lighting switch OFF	OFF
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)	ON
HL LO REQ	Lighting switch OFF	OFF
	Lighting switch 2ND HI or AUTO (Light is illuminated)	ON
HL HI REQ	Lighting switch OFF	OFF
	Lighting switch HI	ON
FR FOG REQ	Lighting switch 2ND or AUTO (Light is illuminated)	Front fog lamp switch OFF OFF
		• Front fog lamp switch ON • Daytime light activated (Canada only) ON
FR WIP REQ	Ignition switch ON	Front wiper switch OFF STOP
		Front wiper switch INT 1LOW
		Front wiper switch LO LOW
		Front wiper switch HI HI
WIP AUTO STOP	Ignition switch ON	Front wiper stop position STOP P
		Any position other than front wiper stop position ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally OFF
		Front wiper stops at fail-safe operation BLOCK
ST RLY REQ	Ignition switch OFF or ACC	OFF
		ON
IGN RLY	Ignition switch START	OFF
		ON
RR DEF REQ	Rear defogger switch OFF	OFF
	Rear defogger switch ON	ON
OIL P SW	Ignition switch OFF, ACC or engine running	Open
	Ignition switch ON	Close
DTRL REQ	Daytime light system requested OFF with CONSULT-III.	OFF
	Daytime light system requested ON with CONSULT-III.	ON
THFT HRN REQ	Not operated	OFF
	• Panic alarm is activated • Horn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM	ON

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)


## < ECU DIAGNOSIS >

Monitor Item	Condition	Value/Status
HORN CHIRP	Not operated	OFF
	Door locking with keyfob or Intelligent Key (if equipped) (horn chirp mode)	ON

## Terminal Layout

INFOID:000000005484842

### TERMINAL LAYOUT — TYPE A




WKIA5852E

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

TERMINAL LAYOUT —TYPE B



**NOTE:**

Numbers preceded by an "F" represent the fuse numbers imprinted on the IPDM E/R. The other numbers represent the fuse numbers as they appear in the wiring diagrams.

AAMIA0364GB

## Physical Values

INFOID:0000000005484843

## PHYSICAL VALUES




# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)
				Ignition switch	Operation or condition	
1	W	Battery power supply	Input	OFF	—	Battery voltage
2	R	Battery power supply	Input	OFF	—	Battery voltage
3	G	ECM relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
4	P	ECM relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
6	V	Throttle control motor relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
7	BR	ECM relay control	Input	—	Ignition switch ON or START	0V
					Ignition switch OFF or ACC	Battery voltage
8	W/R	Fuse 54	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
10	R/B	Fuse 45	Output	ON	Daytime light system active	0V
					Daytime light system inactive	Battery voltage
11	Y	A/C compressor	Output	ON or START	A/C switch ON or defrost A/C switch	Battery voltage
					A/C switch OFF or defrost A/C switch	0V
12	W/G	Ignition switch supplied power	Input	—	OFF or ACC	0V
					ON or START	Battery voltage
13	R	Fuel pump relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
14	W/G	Fuse 49	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
15	W/R	Fuse 50 (ABS)	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
16	W/G	Fuse 51	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
17	W/G	Fuse 55	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
19	W	Starter motor	Output	START	—	Battery voltage
20	BR	Cooling fan motor (low)	Output	ON or START	—	Battery voltage
21	GR	Ignition switch supplied power	Input	—	OFF or ACC	0V
					START	Battery voltage
22	G	Battery power supply	Output	OFF	—	Battery voltage
23	LG	Door mirror defogger output signal	Output	—	When rear defogger switch is ON	Battery voltage
					When raker defogger switch is OFF	0V

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)
				Ignition switch	Operation or condition	
24	P	Cooling fan motor (high)	Output	—	Conditions correct for cooling fan operation	Battery voltage
					Conditions not correct for cooling fan operation	0V
27	W	Fuse 38	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
28	R	LH front parking and front side marker lamp	Output	OFF	Lighting switch 1st position	OFF 0V
					ON	Battery voltage
29	G	Trailer tow relay	Output	ON	Lighting switch 1st position	OFF 0V
					ON	Battery voltage
30	R/B	Fuse 53	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
32	GR	Wiper low speed signal	Output	ON or START	Wiper switch	OFF Battery voltage
					LO or INT	0V
35	L	Wiper high speed signal	Output	ON or START	Wiper switch	OFF, LO, INT Battery voltage
					HI	0V
37	Y	Power generation command signal	Output	—	Ignition switch ON	(V)  6.3 V JPMIA0001GB
					40% is set on "Active test," "ALTERNATOR DUTY" of "ENGINE"	(V)  3.8 V JPMIA0002GB
					40% is set on "Active test," "ALTERNATOR DUTY" of "ENGINE"	(V)  1.4 V JPMIA0003GB
38	B	Ground	Input	—	—	0V
39	L	CAN-H	—	ON	—	—
40	P	CAN-L	—	ON	—	—
42	GR	Oil pressure switch	Input	—	Engine running	Battery voltage
					Engine stopped	0V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
WW  
M  
N  
O  
P

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition			Reference value (Approx.)
				Ignition switch	Operation or condition		
43	G	Wiper auto stop signal	Input	ON or START	Wiper switch	OFF, LO, INT	Battery voltage
44	R	Daytime light relay control	Input	ON	Daytime light system active		0V
					Daytime light system inactive		Battery voltage
45	LG	Horn relay control	Input	ON	When door locks are operated using keyfob or Intelligent Key (if equipped) (OFF → ON)*		Battery voltage → 0V
46	V	Fuel pump relay control	Input	—	Ignition switch ON or START		0V
					Ignition switch OFF or ACC		Battery voltage
47	O	Throttle control motor relay control	Input	—	Ignition switch ON or START		0V
					Ignition switch OFF or ACC		Battery voltage
48	R	Starter relay (inhibit switch)	Input	ON or START	Selector lever in "P" or "N"		0V
					Selector lever any other position		Battery voltage
49	GR	Front RH parking and front side marker lamp	Output	OFF	Lighting switch 1st position	OFF	0V
						ON	Battery voltage
50	W	Front fog lamp (LH)	Output	ON or START	Lighting switch must be in the 2nd position (LOW beam is ON) and the front fog lamp switch	OFF	0V
						ON	Battery voltage
51	V	Front fog lamp (RH)	Output	ON or START	Lighting switch must be in the 2nd position (LOW beam is ON) and the front fog lamp switch	OFF	0V
						ON	Battery voltage
52	P	LH low beam head-lamp	Output	—	Lighting switch in 2nd position		Battery voltage
54	R	RH low beam head-lamp	Output	—	Lighting switch in 2nd position		Battery voltage
55	G	LH high beam head-lamp	Output	—	Lighting switch in 2nd position and placed in HIGH or PASS position		Battery voltage
56	L	RH high beam head-lamp	Output	—	Lighting switch in 2nd position and placed in HIGH or PASS position		Battery voltage
57	GR	Parking, license, and tail lamp	Output	ON	Lighting switch 1st position	OFF	0V
						ON	Battery voltage
59	B	Ground	Input	—	—		0V
60	GR	Rear window defogger relay	Output	ON or START	Rear defogger switch ON		Battery voltage
					Rear defogger switch OFF		0V
61	R/B	Fuse 32	Output	OFF	—		Battery voltage


# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

\*: When horn reminder is ON

## Wiring Diagram

INFOID:000000005484844




ABMWA0473GB

**IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)**

## < ECU DIAGNOSIS >

**FL** : WITH FRONT FOG LAMPS  
**N** : FOR CANADA



ABMWA0474GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) CONNECTORS

Connector No.	E30
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	-




Terminal No.	Color of Wire	Signal Name
3	R	-

Connector No.	E118
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	F/L USM
2	R	F/L MAIN

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
6	V	ETC
7	BR	ECM RLY CONT
8	W/R	O2 SENSOR
9	-	-
10	R/B	DTRL RLY SUPPLY
11	Y	A/C COMPRESSOR
12	W/G	IGN SW (IG)
13	R	FUEL PUMP
14	W/G	A/T CU IGN SUPPLY
15	W/R	ABS IGN SUPPLY
16	W/G	REVERSE LAMP
17	W/G	INJECTOR
18	-	-
23	LG	HEATED MIRROR
24	P	MOTOR FAN 2

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)



< ECU DIAGNOSIS >

Connector No.	Color of Wire	Signal Name
25	—	—
26	—	—
27	W	TTOW REV LAMP
28	R	CLEARANCE FRONT LH
29	G	TRAILER RLY CONT
30	R/B	ECM BAT




Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
31	—	—	32	GR	FR WIPER LO
33	—	—	34	—	—
35	L	FR WIPER HI	36	—	—

Connector No.	Color of Wire	Signal Name
E123	—	—
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	—	—
BROWN	—	—



Connector No.	Color of Wire	Signal Name	Connector No.	Color of Wire	Signal Name
E124	—	—	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	—	—
BLACK	—	—	CONNECTOR NAME	—	—
ECM BAT	—	—	CONNECTOR COLOR	—	—



Connector No.	Color of Wire	Signal Name
57	GR	TAIL LAMP
58	—	—
59	B	GND (POWER)
60	GR	RR DEF
61	R/B	TRAIL RLY SUPPLY
62	—	—

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
49	GR	ILLUMINATION	57	GR	TAIL LAMP
50	W	FR FOG LAMP LH	58	—	—
51	V	FR FOG LAMP RH	59	B	GND (POWER)
52	P	H/LAMP LO LH	60	GR	RR DEF
53	—	—	61	R/B	TRAIL RLY SUPPLY
54	R	H/LAMP LO RH	62	—	—
55	G	H/LAMP HI LH			
56	L	H/LAMP HI RH			

ABMIA1291GB

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

Connector No.	E129
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-

ABMIA1292GB

INFOID:000000005484845

Fail Safe

## CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

## < ECU DIAGNOSIS >

Control part	Fail-safe in operation
Cooling fan	<ul style="list-style-type: none"> <li>• Turns ON the cooling fan relay when the ignition switch is turned ON</li> <li>• Turns OFF the cooling fan relay when the ignition switch is turned OFF</li> </ul>

If No CAN Communication Is Available With BCM

Control part	Fail-safe in operation
Headlamp	<ul style="list-style-type: none"> <li>• Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>• Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>• Headlamp (LH/RH) high relays OFF</li> </ul>
• Parking lamps • License plate lamps • Tail lamps	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp relay when the ignition switch is turned ON</li> <li>• Turns OFF the tail lamp relay when the ignition switch is turned OFF</li> </ul>
Front wiper	<ul style="list-style-type: none"> <li>• The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>• The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.</li> </ul>
Rear window defogger	Rear window defogger relay OFF
A/C compressor	A/C relay OFF
Front fog lamps (if equipped)	Front fog lamp relay OFF

## IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Ignition switch	Ignition relay	Tail lamp relay
ON	ON	—
OFF	OFF	—

### NOTE:

The tail lamp turns OFF when the ignition switch is turned ON.

## FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper auto stop signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 second activation and 20 second stop five times.

Ignition switch	Front wiper switch	Auto stop signal
ON	OFF	Front wiper stop position signal cannot be input 10 seconds.
	ON	The signal does not change for 10 seconds.

### NOTE:

This operation status can be confirmed on the IPDM E/R “DATA MONITOR” that displays “Block” for the item “WIP PROT” while the wiper is stopped.

## STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

# IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS >

## DTC Index

INFOID:000000005484846

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

CONSULT-III display	Fail-safe	TIME <sup>NOTE</sup>		Refer to
No DTC is detected. further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	×	CRNT	1 – 39	<a href="#">PCS-16</a>

### NOTE:

The details of TIME display are as follows.

- CRNT: The malfunctions that are detected now
- 1 - 39: The number is indicated when it is normal at present and a malfunction was detected in the past. It increases like 0 → 1 → 2 ⋯ 38 → 39 after returning to the normal condition whenever IGN OFF → ON. It is fixed to 39 until the self-diagnosis results are erased if it is over 39. It returns to 0 when a malfunction is detected again in the process.

# WIPER AND WASHER SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### WIPER AND WASHER SYSTEM SYMPTOMS

#### Symptom Table

INFOID:0000000005256389

##### CAUTION:

Perform the self-diagnosis with CONSULT-III before performing the diagnosis by symptom. Perform the diagnosis by DTC if DTC is detected.

Symptom	Probable malfunction location	Inspection item
Front wiper does not operate.	HI only	• Combination switch • Harness between combination switch and BCM • BCM
		• IPDM E/R • Harness between IPDM E/R and front wiper motor • Front wiper motor
		Front wiper request signal • BCM • IPDM E/R
	LO and INT	• Combination switch • Harness between combination switch and BCM • BCM
		• IPDM E/R • Harness between IPDM E/R and front wiper motor • Front wiper motor
		Front wiper request signal • BCM • IPDM E/R
	INT only	• Combination switch • Harness between combination switch and BCM • BCM
		Front wiper request signal • BCM • IPDM E/R
	HI, LO, and INT	SYMPOTM DIAGNOSIS “FRONT WIPER DOES NOT OPERATE” Refer to <a href="#">WW-74, "Diagnosis Procedure"</a> .

# WIPER AND WASHER SYSTEM SYMPTOMS

## < SYMPTOM DIAGNOSIS >

Symptom	Probable malfunction location	Inspection item	
Front wiper does not stop.	HI only	• Combination switch • BCM  Front wiper request signal • BCM • IPDM E/R  IPDM E/R	Combination switch Refer to <a href="#">BCS-56, "Symptom Table"</a> .  IPDM E/R DATA MONITOR "FR WIP REQ"  —
		• Combination switch • BCM  Front wiper request signal • BCM • IPDM E/R	Combination switch Refer to <a href="#">BCS-56, "Symptom Table"</a> .
		IPDM E/R	—
	LO only	• Combination switch • BCM  Front wiper request signal • BCM • IPDM E/R	Combination switch Refer to <a href="#">BCS-56, "Symptom Table"</a> .
		IPDM E/R	—
		• Combination switch • BCM  Front wiper request signal • BCM • IPDM E/R	Combination switch Refer to <a href="#">BCS-56, "Symptom Table"</a> .
		IPDM E/R	IPDM E/R DATA MONITOR "FR WIP REQ"
		• Combination switch • Harness between combination switch and BCM • BCM	Combination switch Refer to <a href="#">BCS-56, "Symptom Table"</a> .
		BCM	—
Front wiper does not operate normally.	Intermittent adjustment cannot be performed.	Check the vehicle speed detection wiper setting. Refer to <a href="#">BCS-23, "WIPER : CONSULT-III Function (BCM - WIPER)"</a> .	—
	Wiper is not linked to the washer operation.	• Combination switch • Harness between combination switch and BCM • BCM	Combination switch Refer to <a href="#">BCS-56, "Symptom Table"</a> .
		BCM	—
	Does not return to stop position (Repeatedly operates for 10 seconds and then stops for 20 seconds. After that, it stops the operation).	• IPDM E/R • Harness between IPDM E/R and front wiper motor • Front wiper motor	Front wiper auto stop signal circuit Refer to <a href="#">WW-22, "Component Function Check"</a> .
Rear wiper does not operate.	ON only	• Combination switch • Harness between combination switch and BCM • BCM	Combination switch Refer to <a href="#">BCS-56, "Symptom Table"</a> .
	INT only	• Combination switch • Harness between combination switch and BCM • BCM	Combination switch Refer to <a href="#">BCS-56, "Symptom Table"</a> .
	ON and INT	• Combination switch • Harness between combination switch and BCM • BCM	Combination switch Refer to <a href="#">BCS-56, "Symptom Table"</a> .
		• BCM • Harness between rear wiper motor and BCM • Harness between rear wiper motor and ground • Rear wiper motor • Glass hatch ajar switch	Combination switch Refer to <a href="#">WW-27, "Component Function Check"</a> .

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

## WIPER AND WASHER SYSTEM SYMPTOMS

### < SYMPTOM DIAGNOSIS >

Symptom		Probable malfunction location	Inspection item
Rear wiper does not stop.	ON only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul>	Rear wiper motor circuit Refer to <a href="#">WW-27, "Component Function Check"</a> .
	INT only	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-56, "Symptom Table"</a> .
Rear wiper does not operate normally.	Wiper is not linked to the washer operation.	<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between rear wiper motor and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-56, "Symptom Table"</a> .
	Rear wiper does not return to the Stop position (Stops after a five-second operation).	<ul style="list-style-type: none"> <li>• BCM</li> <li>• Harness between rear wiper motor and BCM</li> <li>• Rear wiper motor</li> </ul>	Rear wiper auto stop signal circuit Refer to <a href="#">WW-29, "Component Function Check"</a> .
	Rear wiper stops after operating for five seconds when ignition switch is turned ON.		—

## **NORMAL OPERATING CONDITION**

< SYMPTOM DIAGNOSIS >

### **NORMAL OPERATING CONDITION**

#### **Description**

INFOID:000000005256390

#### **FRONT WIPER MOTOR PROTECTION FUNCTION**

- IPDM E/R may stop the front wiper to protect the front wiper motor if any obstruction (operation resistance) such as a large amount of snow is detected during the front wiper operation.
- At that time turn OFF the front wiper and remove the foreign object. Then wait for approximately 20 seconds or more and reactivate the front wiper. The wiper will operate normally.

#### **REAR WIPER MOTOR PROTECTION FUNCTION**

- BCM may stop rear wiper to protect the rear wiper motor when the rear wiper is stopped for 5 seconds or more due to a snowfall.
- Rear wiper operates normally one minute after the obstacles are removed with rear wiper OFF.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## FRONT WIPER DOES NOT OPERATE

### Description

INFOID:0000000005256391

The front wiper does not operate under any operation conditions.

### Diagnosis Procedure

INFOID:0000000005256392

Regarding Wiring Diagram information, refer to [WW-30, "Wiring Diagram"](#).

### 1. CHECK WIPER RELAY OPERATION

#### ☒ IPDM E/R AUTO ACTIVE TEST

1. Start IPDM E/R auto active test. Refer to [PCS-12, "Diagnosis Description"](#).
2. Check that the front wiper operates at the LO/HI operation.

#### Ⓐ CONSULT-III ACTIVE TEST

1. Select "FRONT WIPER" of IPDM E/R active test item.
2. While operating the test item, check front wiper operation.

**LO : Front wiper LO operation**

**HI : Front wiper HI operation**

**OFF : Stop the front wiper.**

Is front wiper operation normal?

YES >> GO TO 5

NO >> GO TO 2

### 2. CHECK FRONT WIPER MOTOR FUSE

1. Turn the ignition switch OFF.

2. Check that the following fuse is not blown.

Unit	Location	Fuse No.	Capacity
Front wiper motor	IPDM E/R	39	30 A

Is the fuse blown?

YES >> Replace the fuse after repairing the applicable circuit.

NO >> GO TO 3

### 3. CHECK FRONT WIPER MOTOR GROUND OPEN CIRCUIT

1. Disconnect front wiper motor.
2. Check continuity between front wiper motor harness connector and ground.

Front wiper motor		Ground	Continuity
Connector	Terminal		
E23	2		Yes


Does continuity exist?

YES >> GO TO 4

NO >> Repair or replace harness.

### 4. CHECK FRONT WIPER MOTOR OUTPUT VOLTAGE

#### Ⓐ CONSULT-III ACTIVE TEST




# FRONT WIPER DOES NOT OPERATE

## < SYMPTOM DIAGNOSIS >

1. Turn the ignition switch ON.
2. Select "FRONT WIPER" of IPDM E/R active test item.
3. With operating the test item, check voltage between IPDM E/R harness connector and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
IPDM E/R		FRONT WIP- ER	Ground
Connector	Terminal		
E121	32		LO
	35		OFF
			HI
			OFF



Is the measurement value normal?

- YES >> Replace front wiper motor. Refer to [WW-78, "Removal and Installation"](#).  
 NO >> Replace IPDM E/R. Refer to [PCS-33, "Removal and Installation of IPDM E/R"](#).

## 5. CHECK FRONT WIPER REQUEST SIGNAL INPUT

### CONSULT-III DATA MONITOR

1. Select "FR WIP REQ" of IPDM E/R data monitor item.
2. Switch the front wiper switch to HI and LO.
3. With operating the front wiper switch, check the status of "FR WIP REQ".

Monitor item	Condition	Monitor status	
FR WIP REQ	Front wiper switch HI	HI	ON
		STOP	OFF
	Front wiper switch LO	1LOW	ON
		STOP	OFF

Is the status of item normal?

- YES >> Replace IPDM E/R. Refer to [PCS-33, "Removal and Installation of IPDM E/R"](#).  
 NO >> GO TO 6

## 6. CHECK COMBINATION SWITCH

1. Perform the inspection of the combination switch. Refer to [BCS-56, "Symptom Table"](#).

Is combination switch normal?

- YES >> Replace BCM. Refer to [BCS-59, "Removal and Installation"](#).  
 NO >> Repair or replace the applicable parts.

## PRECAUTION

< PRECAUTION >

# PRECAUTION

## PRECAUTION

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000005511851

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

### Precautions Necessary for Steering Wheel Rotation after Battery Disconnect

INFOID:0000000005548425

#### **NOTE:**

- Before removing and installing any control units, first turn the push-button ignition switch to the LOCK position, then disconnect both battery cables.
- After finishing work, confirm that all control unit connectors are connected properly, then re-connect both battery cables.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If a DTC is detected, perform trouble diagnosis according to self-diagnosis results.

This vehicle is equipped with a push-button ignition switch and a steering lock unit.

If the battery is disconnected or discharged, the steering wheel will lock and cannot be turned.

If turning the steering wheel is required with the battery disconnected or discharged, follow the procedure below before starting the repair operation.

### OPERATION PROCEDURE

1. Connect both battery cables.

#### **NOTE:**

Supply power using jumper cables if battery is discharged.

2. Carry the Intelligent Key or insert it to the key slot and turn the push-button ignition switch to ACC position. (At this time, the steering lock will be released.)
3. Disconnect both battery cables. The steering lock will remain released with both battery cables disconnected and the steering wheel can be turned.
4. Perform the necessary repair operation.

## **PRECAUTION**

### < PRECAUTION >

- 
- 5. When the repair work is completed, re-connect both battery cables. With the brake pedal released, turn the push-button ignition switch from ACC position to ON position, then to LOCK position. (The steering wheel will lock when the push-button ignition switch is turned to LOCK position.)
  - 6. Perform self-diagnosis check of all control units using CONSULT-III.

A

B

C

D

E

F

G

H

I

J

K

WW

M

N

O

P

# FRONT WIPER AND WASHER SYSTEM

< ON-VEHICLE REPAIR >

## ON-VEHICLE REPAIR

### FRONT WIPER AND WASHER SYSTEM

#### Removal and Installation

INFOID:0000000005256394


#### FRONT WIPER ARMS

##### Removal

1. Remove wiper arm covers and wiper arm nuts.
2. Remove front RH wiper arm and front LH wiper arm.
3. Remove front RH and LH blade assembly from the front RH and LH arm assembly.

##### Installation

1. Operate wiper motor one full cycle, then turn "OFF" (Auto Stop).
2. Clean up the pivot area as shown. This will reduce possibility of wiper arm looseness.



3. Install front RH and LH blade assembly on the front RH and LH arm.
4. Install front RH wiper arm and front LH wiper arm.
5. Ensure that wiper blades stop within proper clearance.


#### FRONT WIPER ARM ADJUSTMENT

1. Operate windshield washer and wiper motor one full cycle, then turn "OFF" (Auto Stop).
2. Lift the wiper blade up and then rest it onto glass surface, check the blade clearance "L1" and "L2".

**Clearance "L1" : 24.5 - 39.5 mm (0.965 - 1.555 in)**

**Clearance "L2" : 23.5 - 38.5 mm (0.925 - 1.516 in)**

3. Remove wiper arm covers and wiper arm nuts.
4. Adjust front wiper arms on wiper motor pivot shafts to obtain above specified blade clearances.
5. Tighten wiper arm nuts to specified torque, and install wiper arm covers.




**Front wiper arm nuts : 23.6 N·m (2.4 kg-m, 17 ft-lb)**

# FRONT WIPER AND WASHER SYSTEM

< ON-VEHICLE REPAIR >  
WIPER MOTOR AND LINKAGE

SEC. 288




AWKIA1471ZZ

- |                          |  |                               |
|--------------------------|--|-------------------------------|
| 1. Wiper arm covers      | 2. Front LH wiper arm and blade assembly | 3. Wiper frame assembly       |
| 4. Wiper motor           | 5. Front RH wiper arm and blade assembly | A. Wiper arm nuts             |
| B. Wiper arm frame bolts | C. Wiper motor bolts                     | D. Wiper motor pivot arm bolt |

## Removal

1. Remove the cowl top. Refer to [EXT-19, "Removal and Installation"](#).
2. Remove wiper frame bolts, disconnect the wiper motor connector and remove the wiper frame assembly.



LKIA0534E

3. Remove wiper motor from wiper frame assembly.

## Installation

### CAUTION:

- Do not drop the wiper motor or cause it to contact other parts.
- Check the grease conditions of the motor arm and wiper link joint(s). Apply grease if necessary.

1. Connect wiper motor to connector. Turn the wiper switch ON to operate wiper motor, then turn the wiper switch OFF (auto stop).
2. Disconnect wiper motor electrical connector.
3. Install wiper motor to wiper frame assembly, and install wiper frame assembly.
4. Connect wiper motor electrical connector.
5. Install cowl top. Refer to [EXT-19, "Removal and Installation"](#).

WW

M

N

O


P

# FRONT WIPER AND WASHER SYSTEM

< ON-VEHICLE REPAIR >

## WASHER HOSE LAYOUT

SEC. 289



WKIA4139E

1. Rear washer nozzle

2. Washer nozzles

3. Washer fluid reservoir

## WASHER NOZZLES

### Removal

1. Remove the cowl top. Refer to [EXT-19, "Removal and Installation"](#).
2. Remove washer nozzles.


### Installation

Installation is in the reverse order of removal.

## WIPER AND WASHER SWITCH

### Removal

1. Remove instrument lower cover LH. Refer to [IP-11, "Exploded View"](#).
2. Remove steering column cover lower and steering column cover upper.
3. Disconnect wiper and washer switch connector.
4. Pinch tabs at wiper and washer switch base and slide switch away from steering column.



WKIA0071E

### Installation

Installation is in the reverse order of removal.

## WASHER FLUID RESERVOIR


### Removal

1. Remove the front fender protector RH. Refer to [EXT-23, "Removal and Installation of Front Fender Protector"](#).


# FRONT WIPER AND WASHER SYSTEM

## < ON-VEHICLE REPAIR >


2. Remove clip, then remove washer fluid reservoir filler neck from washer fluid reservoir.



3. Disconnect front and rear washer hoses.
4. Disconnect front and rear washer motor connector.
5. Disconnect washer fluid level sensor connector.



6. Remove washer fluid reservoir screws and remove washer fluid reservoir.



### Installation

Installation is in the reverse order of removal.

#### CAUTION:

After installation, add water up to the upper level of the washer fluid reservoir inlet and check for water leaks.

### WASHER MOTOR


#### Removal

1. Remove RH front fender protector. Refer to [EXT-23, "Removal and Installation of Front Fender Protector"](#).
2. Disconnect the front washer hoses.
3. Disconnect the front washer motor connectors.

# FRONT WIPER AND WASHER SYSTEM

## < ON-VEHICLE REPAIR >

4. Slide retaining ring upward to release front and rear washer motor.



5. Remove front washer motor from washer fluid reservoir.

Installation

Installation is in the reverse order of removal.


**CAUTION:**

**When installing front washer motor, there should be no packing twists, etc.**

## WASHER FLUID LEVEL SENSOR

Removal

1. Remove washer fluid reservoir.
2. Lift level sensor out of washer fluid reservoir in the direction of the arrow as shown.




Installation

Installation is in the reverse order of removal.

## Washer Nozzle Adjustment

INFOID:0000000005256395

- This vehicle is equipped with non-adjustable washer nozzles.
- If not satisfied with washer fluid spray coverage, confirm that the washer nozzle is installed correctly.
- If the washer nozzle is installed correctly, and the washer fluid spray coverage is not satisfactory, replace the washer nozzle.



# REAR WIPER AND WASHER SYSTEM

< ON-VEHICLE REPAIR >

## REAR WIPER AND WASHER SYSTEM


### Removal and Installation

INFOID:000000005256396

#### REAR WIPER ARM


##### Removal

1. Remove wiper arm cover, and remove rear wiper arm nut.
2. Remove the wiper arm.
3. Remove wiper blade from the wiper arm.



##### Installation

1. Operate rear wiper motor one full cycle, then turn "OFF" (Auto Stop).
2. Clean pivot area as shown. This will reduce the possibility of wiper arm looseness.



3. Install wiper blade on the wiper arm.
4. Install wiper arm so that the arm rests in the stopper and tighten rear wiper arm nut.
5. Install wiper arm cover.

#### REAR WIPER MOTOR

A

B

C

D

E

F

G

H

I

J

K

WW

M


N

O

P

# REAR WIPER AND WASHER SYSTEM


< ON-VEHICLE REPAIR >



- |                                |                              |                         |
|--------------------------------|------------------------------|-------------------------|
| 1. Rear wiper motor cover      | 2. Rear wiper motor          | 3. Plate                |
| 4. Rear wiper motor cover base | 5. Bracket                   | 6. Grommet              |
| 7. Spacer                      | 8. Washer                    | 9. Rear wiper motor nut |
| 10. Pivot cap                  | 11. Rear wiper arm and blade | 12. Wiper arm nut       |
| 13. Wiper arm cover            | 14. Cap nut                  | 15. Gasket              |
| 16. Gasket                     | 17. Stud                     | 18. Grommet             |
| 19. Nut                        |                              |                         |

## Removal

1. Remove wiper arm. Refer to [WW-83, "Removal and Installation"](#).
2. Remove pivot cap.
3. Remove rear wiper motor nut.
4. Remove rear wiper motor cover.
5. Disconnect rear wiper motor connector.
6. Remove nut and remove rear wiper motor.



7. Remove rear wiper motor cover base.
8. Remove bracket.

## Installation


### CAUTION:

- Do not drop the wiper motor or cause it to contact other parts.  
Installation is in the reverse order of removal.

# REAR WIPER AND WASHER SYSTEM

< ON-VEHICLE REPAIR >

## REAR WASHER TUBE LAYOUT




- 1 Washer fluid reservoir  
4 Check valve

- 2 Washer fluid tube to rear door

- 3 Rear washer nozzle

### NOTE:

Connect the check valve (2) to the washer fluid tube (1) so that the directional arrow on the check valve (2) points towards the washer nozzle tube (3).



## REAR WASHER NOZZLE

### Removal

1. Disconnect rear washer tube from rear washer nozzle.
2. Release retaining clips and remove washer nozzle.

### Installation

Installation is in the reverse order of removal.

### NOTE:

Inspect rear washer nozzle for proper spray pattern, adjust as necessary. Refer to [WW-86, "Rear Washer Nozzle Adjustment"](#).

## WASHER MOTOR

### Removal

1. Remove RH front fender protector. Refer to [EXT-23, "Removal and Installation of Front Fender Protector"](#).
2. Disconnect the rear washer hoses.
3. Disconnect the rear washer motor connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

WW

M

N


O

P

## REAR WIPER AND WASHER SYSTEM

### < ON-VEHICLE REPAIR >

- Slide retaining ring upward to release rear washer motor.



- Remove rear washer motor from washer fluid reservoir.

Installation

Installation is in the reverse order of removal.

**CAUTION:**

**When installing rear washer motor, there should be no packing twists, etc.**

### WASHER MOTOR

Refer to [WW-78](#).

### Rear Washer Nozzle Adjustment

INFOID:000000005256397

- Adjust washer nozzle with suitable tool as shown in the figure.

**Adjustable range :  $\pm 15^\circ$  (In any direction)**

