

**SECTION IP**  
**INSTRUMENT PANEL**

A  
B  
C  
D  
E  
F  
G  
H  
I  
IP  
K  
L  
M  
N  
O  
P

**CONTENTS**

<b>PRECAUTION</b> .....	2	<b>INSTRUMENT LOWER PANEL LH</b> .....	14
<b>PRECAUTIONS</b> .....	2	Removal and Installation .....	14
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	2	<b>CLUSTER LID C</b> .....	15
Precaution Necessary for Steering Wheel Rotation After Battery Disconnect .....	2	Removal and Installation .....	15
Precaution for Work .....	3	<b>CLUSTER LID D</b> .....	17
<b>PREPARATION</b> .....	4	Removal and Installation .....	17
<b>PREPARATION</b> .....	4	<b>UPPER GLOVE BOX</b> .....	18
Special Service Tool .....	4	Removal and Installation .....	18
Commercial Service Tool .....	4	<b>INSTRUMENT LOWER PANEL RH AND GLOVE BOX</b> .....	19
<b>SYMPTOM DIAGNOSIS</b> .....	5	Removal and Installation .....	19
<b>SQUEAK AND RATTLE TROUBLE DIAGNOSES</b> .....	5	<b>A/T FINISHER</b> .....	20
Work Flow .....	5	Removal and Installation .....	20
Generic Squeak and Rattle Troubleshooting .....	7	<b>CENTER CONSOLE</b> .....	21
Diagnostic Worksheet .....	9	Removal and Installation .....	21
<b>REMOVAL AND INSTALLATION</b> .....	11	<b>UNIT DISASSEMBLY AND ASSEMBLY</b> ...	22
<b>INSTRUMENT PANEL ASSEMBLY</b> .....	11	<b>CENTER CONSOLE ASSEMBLY</b> .....	22
Exploded View .....	11	Disassembly and Assembly .....	22
Removal and Installation .....	12	<b>INSTRUMENT LOWER PANEL RH AND GLOVE BOX</b> .....	24
<b>CLUSTER LID A</b> .....	13	Exploded View .....	24
Removal and Installation .....	13	Disassembly and Assembly .....	24

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006247939

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000006247940

#### **NOTE:**

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT-III to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

#### OPERATION PROCEDURE

1. Connect both battery cables.

#### **NOTE:**

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.

# PRECAUTIONS

## < PRECAUTION >

5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT-III.

### Precaution for Work

INFOID:000000006826738

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components.
  - Water soluble dirt: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the dirty area.  
Then rub with a soft and dry cloth.
  - Oily dirt: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the dirty area.  
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

IP

# PREPARATION

< PREPARATION >

## PREPARATION


### PREPARATION

#### Special Service Tool


INFOID:000000006247941

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.


Tool number (Kent-Moore No.) Tool name	Description
— (J-39570) Chassis ear	Locating the noise
— (J-43980) NISSAN Squeak and Rattle kit	Repairing the cause of noise
— (J-46534) Trim tool set	For removing trim



SBT839



SBT840




AWJIA0483ZZ

#### Commercial Service Tool

INFOID:000000006247942

(Kent-Moore No.) Tool name	Description
(J-39565) Engine ear	Locating the noise
Power tool	Loosening bolts, screws and nuts.



SIIA0995E



PIIB1407E

# SQUEAK AND RATTLE TROUBLE DIAGNOSES


< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### SQUEAK AND RATTLE TROUBLE DIAGNOSES

#### Work Flow

INFOID:000000006832779



SBT842

#### CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any customer's comments; refer to [IP-9, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, be sure to diagnose and repair the noise that the customer is concerned about. This can be accomplished by test driving the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak —(Like tennis shoes on a clean floor)  
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping.
- Creak—(Like walking on an old wooden floor)  
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle—(Like shaking a baby rattle)  
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock —(Like a knock on a door)  
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick—(Like a clock second hand)  
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump—(Heavy, muffled knock noise)  
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz—(Like a bumble bee)  
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending upon the person. A noise that you may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

#### DUPLICATE THE NOISE AND TEST DRIVE

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when you confirm the repair.

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
  - 2) Tap or push/pull around the area where the noise appears to be coming from.
  - 3) Rev the engine.
  - 4) Use a floor jack to recreate vehicle "twist".
  - 5) At idle, apply engine load (electrical load, half-clutch on M/T model, drive position on CVT and A/T models).
  - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
  - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

## CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

## LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis Ear: J-39570, Engine Ear: J-39565 and mechanic's stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
  - removing the components in the area that you suspect the noise is coming from.  
Do not use too much force when removing clips and fasteners, otherwise clips and fasteners can be broken or lost during the repair, resulting in the creation of new noise.
  - tapping or pushing/pulling the component that you suspect is causing the noise.  
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
  - feeling for a vibration with your hand by touching the component(s) that you suspect is (are) causing the noise.
  - placing a piece of paper between components that you suspect are causing the noise.
  - looking for loose components and contact marks.  
Refer to [IP-7. "Generic Squeak and Rattle Troubleshooting"](#).

## REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
  - separate components by repositioning or loosening and retightening the component, if possible.
  - insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A NISSAN Squeak and Rattle Kit (J-43980) is available through your authorized NISSAN Parts Department.

### **CAUTION:**

**Do not use excessive force as many components are constructed of plastic and may be damaged.**

**Always check with the Parts Department for the latest parts information.**

**The following materials are contained in the NISSAN Squeak and Rattle Kit (J-43980). Each item can be ordered separately as needed.**

#### **URETHANE PADS [1.5 mm (0.059 in) thick]**

Insulates connectors, harness, etc.

76268-9E005: 100×135 mm (3.94×5.31 in)/76884-71L01: 60×85 mm (2.36×3.35 in)/76884-71L02: 15×25 mm (0.59×0.98 in)

#### **INSULATOR (Foam blocks)**

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50×50 mm (1.97×1.97 in)/73982-50Y00: 10 mm (0.39 in) thick, 50×50 mm (1.97×1.97 in)

#### **INSULATOR (Light foam block)**

80845-71L00: 30 mm (1.18 in) thick, 30×50 mm (1.18×1.97 in)

#### **FELT CLOTH TAPE**

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15×25 mm (0.59×0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll. The following materials not found in the kit can also be used to repair squeaks and rattles.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

### UHMW (TEFLON) TAPE

Insulates where slight movement is present. Ideal for instrument panel applications.

### SILICONE GREASE

Used instead of UHMW tape that will be visible or not fit.

Note: Will only last a few months.

### SILICONE SPRAY

Use when grease cannot be applied.

### DUCT TAPE

Use to eliminate movement.

### CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

## Generic Squeak and Rattle Troubleshooting

INFOID:000000006832780

Refer to Table of Contents for specific component removal and installation information.

### INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. Cluster lid A and the instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar finisher
4. Instrument panel to windshield
5. Instrument panel pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicone spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

### CAUTION:

**Do not use silicone spray to isolate a squeak or rattle. If you saturate the area with silicone, you will not be able to recheck the repair.**

### CENTER CONSOLE

Components to pay attention to include:

1. Shift selector assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

### DOORS

Pay attention to the:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. You can usually insulate the areas with felt cloth tape or insulator foam blocks from the NISSAN Squeak and Rattle Kit (J-43980) to repair the noise.

### TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the owner.

In addition look for:

1. Trunk lid bumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together

A  
B  
C  
D  
E  
F  
G  
H  
I  
IP  
K  
L  
M  
N  
O  
P

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

---

### 4. A loose license plate or bracket

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

### SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sun visor shaft shaking in the holder
3. Front or rear windshield touching headliner and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

### OVERHEAD CONSOLE (FRONT AND REAR)

Overhead console noises are often caused by the console panel clips not being engaged correctly. Most of these incidents are repaired by pushing up on the console at the clip locations until the clips engage.

In addition look for:

1. Loose harness or harness connectors.
2. Front console map/reading lamp lens loose.
3. Loose screws at console attachment points.

### SEATS

When isolating seat noise it's important to note the position the seat is in and the load placed on the seat when the noise is present. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

### UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component installed to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator installation pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine rpm or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.



# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## Diagnostic Worksheet

INFOID:000000006832781




Dear Customer:

We are concerned about your satisfaction with your vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your vehicle right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

### SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

#### I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

A  
B  
C  
D  
E  
F  
G  
H  
I  
IP  
K  
L  
M  
N  
O  
P

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

\_\_\_\_\_

\_\_\_\_\_

### II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- |   |  |
|---|--|
| <input type="checkbox"/> Anytime                      | <input type="checkbox"/> After sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning      | <input type="checkbox"/> When it is raining or wet     |
| <input type="checkbox"/> Only when it is cold outside | <input type="checkbox"/> Dry or dusty conditions       |
| <input type="checkbox"/> Only when it is hot outside  | <input type="checkbox"/> Other:                        |

### III. WHEN DRIVING:

- Through driveways
- Over rough roads
- Over speed bumps
- Only about \_\_\_\_ mph
- On acceleration
- Coming to a stop
- On turns: left, right or either (circle)
- With passengers or cargo
- Other: \_\_\_\_\_
- After driving \_\_\_\_ miles or \_\_\_\_ minutes

### IV. WHAT TYPE OF NOISE

- Squeak (like tennis shoes on a clean floor)
- Creak (like walking on an old wooden floor)
- Rattle (like shaking a baby rattle)
- Knock (like a knock at the door)
- Tick (like a clock second hand)
- Thump (heavy muffled knock noise)
- Buzz (like a bumble bee)

### TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

\_\_\_\_\_

\_\_\_\_\_

\_\_\_\_\_

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: \_\_\_\_\_ Customer Name \_\_\_\_\_

W.O.# \_\_\_\_\_ Date: \_\_\_\_\_

This form must be attached to Work Order

LATA0071E

# INSTRUMENT PANEL ASSEMBLY

< REMOVAL AND INSTALLATION >


## REMOVAL AND INSTALLATION

### INSTRUMENT PANEL ASSEMBLY

Exploded View

INFOID:000000006247946

SEC. 248 • 280 • 487 • 680



- 1. Display unit bracket RH/LH
- 4. Instrument stay RH/LH
- 7. Instrument lower panel LH
- 10. Combination meter
- 13. Column cover lower

- 2. Steering member assembly
- 5. Knee protector brace
- 8. Cluster lid A
- 11. Steering lock escutcheon
- 14. Cluster lid C

- 3. Knee protector
- 6. Speaker grille RH/LH
- 9. Side ventilator grille RH/LH
- 12. Column cover upper
- 15. Display unit

AWJIA04622Z

# INSTRUMENT PANEL ASSEMBLY

## < REMOVAL AND INSTALLATION >

- |                                       |                                     |                               |
|---------------------------------------|-------------------------------------|-------------------------------|
| 16. Center ventilator grill RH/LH     | 17. Cluster lid D                   | 18. AV control unit           |
| 19. A/C and AV switch assembly        | 20. Lower glove box latch assembly  | 21. Lower glove box           |
| 22. Fuse block cover                  | 23. Lower glove box damper assembly | 24. Lower instrument panel RH |
| 25. Upper glove box door              | 26. Upper glove box                 | 27. Instrument side finisher  |
| 28. Instrument panel and pad assembly | 29. Passenger air bag module        |                               |

## Removal and Installation

INFOID:000000006247947

### INSTRUMENT PANEL

#### Removal

#### **CAUTION:**

**Before servicing, turn the ignition switch off, disconnect both battery terminals, then wait at least three minutes.**

1. Disconnect both the negative and positive battery terminals, then wait at least three minutes.
2. Remove the center console. Refer to [IP-21, "Removal and Installation"](#).
3. Remove the combination meter. Refer to [MWI-88, "Removal and Installation"](#).
4. Remove front pillar upper finisher. Refer to [INT-19, "Removal and Installation"](#).
5. Remove optical sensor. Refer to [EXL-147, "Removal and Installation"](#).
6. Remove AV control unit. Refer to [AV-33, "Removal and Installation"](#) for BASE AUDIO, [AV-113, "Removal and Installation"](#) for MID AUDIO, [AV-256, "Removal and Installation"](#) for BOSE AUDIO WITHOUT NAVIGATION, or [AV-420, "Removal and Installation"](#) for BOSE AUDIO WITH NAVIGATION.
7. Remove display unit, if equipped. Refer to [AV-115, "Removal and Installation"](#) for MID AUDIO, [AV-258, "Removal and Installation"](#) for BOSE AUDIO WITHOUT NAVIGATION, or [AV-422, "Removal and Installation"](#) for BOSE AUDIO WITH NAVIGATION.
8. Remove cluster lid D. Refer to [IP-17, "Removal and Installation"](#).
9. Disconnect GPS antenna (if equipped).
10. Remove the passenger air bag module. Refer to [SR-9, "Removal and Installation"](#).
11. Remove the instrument stay RH/LH bolts.
12. Remove instrument panel and pad assembly.
  - Disconnect all remaining harnesses.

#### Installation

Installation is in the reverse order of removal.

### STEERING COLUMN COVER

#### Removal

1. Remove front pillar lower finisher LH. Refer to [INT-19, "Removal and Installation"](#).
2. Remove instrument lower panel LH. Refer to [IP-14, "Removal and Installation"](#).
3. Remove the steering column cover screws, then remove the steering column upper and lower covers.

#### Installation

Installation is in the reverse order of removal.


# CLUSTER LID A

< REMOVAL AND INSTALLATION >

## CLUSTER LID A

### Removal and Installation

INFOID:000000006826739



- |                             |                  |                               |
|-----------------------------|------------------|-------------------------------|
| 1. Combination meter        | 2. Cluster lid A | 3. Ignition key lamp assembly |
| 4. Steering lock escutcheon | □ Metal clip     |                               |

### REMOVAL

1. Remove front pillar upper finisher LH. Refer to [INT-19, "Removal and Installation"](#).
2. Remove instrument lower panel LH. Refer to [IP-14, "Removal and Installation"](#).
3. Remove steering lock escutcheon.
4. Remove the screws, release the clips, and remove cluster lid A.

### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
IP  
K  
L  
M  
N  
O  
P

# INSTRUMENT LOWER PANEL LH

< REMOVAL AND INSTALLATION >


## INSTRUMENT LOWER PANEL LH

### Removal and Installation

INFOID:000000006826740

#### REMOVAL

1. Remove front pillar lower finisher LH. Refer to [INT-19. "Removal and Installation"](#).
2. Remove instrument lower panel LH, using power tool.
3. Pull rearward to release instrument lower panel LH.
4. Disconnect instrument lower panel LH harness connectors.



#### INSTALLATION

Installation is in the reverse order of removal.

# CLUSTER LID C


< REMOVAL AND INSTALLATION >

## CLUSTER LID C

### Removal and Installation

INFOID:000000006826741

#### WITHOUT DISPLAY UNIT



1. Storage tray

2. Cluster lid C

3. Cluster lid C screw


#### REMOVAL

1. Remove A/T finisher. Refer to [IP-20. "Removal and Installation"](#).
2. Remove storage tray, then remove cluster lid C screw.
3. Pull cluster lid C rearward to release clips.
4. Disconnect harness connectors, then remove cluster lid C.

#### INSTALLATION

Installation is in the reverse order of removal.

#### WITH DISPLAY UNIT



1. Instrument panel

2. Cluster lid C

A. Cluster lid C bolt

△ Clip C103

□ Metal clip

#### REMOVAL

1. Remove A/T finisher. Refer to [IP-20. "Removal and Installation"](#).
2. Remove the center console bin screws and center console bin.
3. Remove cluster lid C bolts, then release the clips and remove cluster lid C.

## CLUSTER LID C

### < REMOVAL AND INSTALLATION >

---

4. Disconnect electrical connectors and remove cluster lid C.

#### INSTALLATION

Installation is in the reverse order of removal.



# CLUSTER LID D


< REMOVAL AND INSTALLATION >

## CLUSTER LID D

### Removal and Installation

INFOID:000000006826742

#### EXPLODED VIEW



1. Cluster lid D

A. Cluster lid D screw

#### REMOVAL

1. Remove A/T finisher. Refer to [IP-20, "Removal and Installation"](#).
2. Remove instrument lower panel LH. Refer to [IP-14, "Removal and Installation"](#).
3. Remove instrument lower panel RH and glove box. Refer to [IP-19, "Removal and Installation"](#).
4. Remove cluster lid C. Refer to [IP-15, "Removal and Installation"](#).
5. Disconnect the electrical connectors and remove cluster lid D.

#### INSTALLATION

Installation is in the reverse order of removal.

# UPPER GLOVE BOX

< REMOVAL AND INSTALLATION >

---

## UPPER GLOVE BOX

### Removal and Installation

INFOID:000000006826743

#### REMOVAL

1. Remove instrument lower panel RH and glove box. Refer to [IP-19, "Removal and Installation"](#).
2. Remove cluster lid C. Refer to [IP-15, "Removal and Installation"](#).
3. Remove upper glove box.
  - a. Remove upper glove box screws.
  - b. Pull upper glove box rearward and release from instrument panel to remove.

#### INSTALLATION

Installation is in the reverse order of removal.

# INSTRUMENT LOWER PANEL RH AND GLOVE BOX

< REMOVAL AND INSTALLATION >

## INSTRUMENT LOWER PANEL RH AND GLOVE BOX

### Removal and Installation

INFOID:000000006826744

#### REMOVAL

1. Remove front pillar lower finisher. Refer to [INT-19, "Removal and Installation"](#).
2. Remove instrument lower panel RH screws, using power tool.
3. Remove instrument lower panel RH and lower glove box.

#### INSTALLATION

Installation is in the reverse order of removal.

**NOTE:**

Install upper glove box before installing lower glove box.

A  
B  
C  
D  
E  
F  
G  
H  
I  
IP  
K  
L  
M  
N  
O  
P

# A/T FINISHER


< REMOVAL AND INSTALLATION >

## A/T FINISHER

### Removal and Installation

INFOID:000000006826745

#### EXPLODED VIEW



- |                  |                              |                        |
|------------------|------------------------------|------------------------|
| 1. Cluster lid D | 2. Center console front base | 3. Cup holder finisher |
| 4. A/T finisher  | ← Front                      | ⊠ Metal clip           |

#### REMOVAL

1. Remove cup holder finisher.
2. Release the shift selector handle clip, then remove shift selector handle. Refer to [TM-170, "Exploded view"](#).
3. Pull up to release clips and disconnect the connectors, then remove the A/T finisher.

#### INSTALLATION

Installation is in the reverse order of removal.

# CENTER CONSOLE


< REMOVAL AND INSTALLATION >

## CENTER CONSOLE

### Removal and Installation

INFOID:000000006826746

#### REMOVAL



← Vehicle front

1. Remove instrument lower panel RH and glove box. Refer to [IP-19, "Removal and Installation"](#).
2. Remove cup holder finisher.
3. Remove A/T finisher. Refer to [IP-20, "Removal and Installation"](#).
4. Remove center console screws, then lift center console rear base away from center console front base and disconnect harness connectors.
5. Disconnect harness connectors, then remove center console front base.

#### INSTALLATION

Installation is in the reverse order of removal.

# CENTER CONSOLE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


## UNIT DISASSEMBLY AND ASSEMBLY

### CENTER CONSOLE ASSEMBLY

#### Disassembly and Assembly

INFOID:000000006247949

#### EXPLODED VIEW



- |   |                              |   |
|---|------------------------------|---|
| 1. Console bin upper                      | 2. A/T finisher              | 3. Console bin lower                        |
| 4. Center console front base              | 5. Cup holder finisher       | 6. Bracket                                  |
| 7. Center console rear base               | 8. Bracket DVD (if equipped) | 9. Wire harness bracket                     |
| 10. Rear finisher assembly                | 11. Rear cup holder assembly | 12. Ventilator console grille (if equipped) |
| 13. Rear air control (rear) (if equipped) | 14. Hinge                    | 15. Center console lid                      |
| 16. Center console bin                    | 17. Cup holder insert        | 18. Cup holder assembly                     |
| A. Screw                                  | B. Bolt                      | ← Vehicle front                             |

☐ Metal clip

#### DISASSEMBLY

1. Remove center console. Refer to [IP-12, "Removal and Installation"](#).
2. Remove center console lid.
3. Remove latch from center console lid.
4. Remove hinge from center console lid.
5. Remove rear finisher assembly.
6. Remove rear cup holder assembly.

# CENTER CONSOLE ASSEMBLY

## < UNIT DISASSEMBLY AND ASSEMBLY >

7. Remove DVD player, if equipped. Refer to [AV-267, "Removal and Installation of DVD Player"](#) for BOSE AUDIO WITHOUT NAVIGATION, or [AV-428, "Removal and Installation of DVD Player"](#) for BOSE AUDIO WITH NAVIGATION. A
8. Disconnect center console harness connectors.
9. Remove cup holder insert and cup holder assembly. B
10. Remove center console bin.
11. Remove center console bracket. C
12. Remove wire harness bracket.

## ASSEMBLY

Assembly is in the reverse order of disassembly. D

E

F

G

H

I

IP

K

L

M

N

O

P


# INSTRUMENT LOWER PANEL RH AND GLOVE BOX

< UNIT DISASSEMBLY AND ASSEMBLY >

## INSTRUMENT LOWER PANEL RH AND GLOVE BOX

Exploded View

INFOID:000000006826747



- |                                   |   |                                |
|-----------------------------------|---|--------------------------------|
| 1. Upper glove box                | 2. Upper glove box lid                  | 3. Instrument lower panel (RH) |
| 4. Fuse block cover               | 5. Lower glove box latch assembly cover | 6. Lower glove box             |
| 7. Lower glove box latch assembly | 8. Damper hook                          | 9. Lower glove box damper      |

### Disassembly and Assembly

INFOID:000000006826748

#### LOWER GLOVE BOX

##### Disassembly

1. Remove fuse block cover.
2. Remove damper hook.
3. Remove lower glove box latch cover.
4. Remove lower glove box latch assembly.

##### Assembly

Assembly is in the reverse order of disassembly.

#### UPPER GLOVE BOX

##### Disassembly

1. Remove upper glove box lid screws.
2. Remove upper glove box lid.

##### Assembly

Assembly is in the reverse order of disassembly.