

SECTION AV

AUDIO, VISUAL & NAVIGATION SYSTEM

CONTENTS

BASE AUDIO			
BASIC INSPECTION	9	SYMPTOM DIAGNOSIS	29
DIAGNOSIS AND REPAIR WORKFLOW	9	AUDIO SYSTEM	29
Work Flow	9	AUDIO UNIT	29
SYSTEM DESCRIPTION	11	AUDIO UNIT : Symptom Table	29
AUDIO SYSTEM	11	NORMAL OPERATING CONDITION	30
System Diagram	11	Description	30
System Description	11	PRECAUTION	31
Component Parts Location	11	PRECAUTIONS	31
Component Description	12	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	31
DTC/CIRCUIT DIAGNOSIS	13	Precaution Necessary for Steering Wheel Rotation After Battery Disconnect	31
POWER SUPPLY AND GROUND CIRCUIT	13	Precaution for Work	32
AUDIO UNIT	13	PREPARATION	33
AUDIO UNIT : Diagnosis Procedure	13	PREPARATION	33
FRONT DOOR SPEAKER	14	Special Service Tool	33
Description	14	Commercial Service Tools	33
Diagnosis Procedure	14	REMOVAL AND INSTALLATION	34
FRONT TWEETER	16	AUDIO UNIT	34
Description	16	Removal and Installation	34
Diagnosis Procedure	16	FRONT TWEETER	36
REAR DOOR SPEAKER	18	Removal and Installation	36
Description	18	FRONT DOOR SPEAKER	37
Diagnosis Procedure	18	Removal and Installation	37
ECU DIAGNOSIS INFORMATION	20	REAR DOOR SPEAKER	38
AUDIO UNIT	20	Removal and Installation	38
Reference Value	20	AUDIO ANTENNA	39
WIRING DIAGRAM	22	Location of Antenna	39
BASE AUDIO SYSTEM	22	Window Antenna Repair	39
Wiring Diagram	22		

A
B
C
D
E
F
G
H
I
J
K
L
M
AV

ANTENNA AMP.	41	Description	63
Removal and Installation	41		
MID AUDIO			
BASIC INSPECTION	42	U1310 AV CONTROL UNIT	64
DIAGNOSIS AND REPAIR WORKFLOW	42	Description	64
Work Flow	42	DTC Logic	64
SYSTEM DESCRIPTION	44	POWER SUPPLY AND GROUND CIRCUIT	65
AUDIO SYSTEM	44	AV CONTROL UNIT	65
System Diagram	44	AV CONTROL UNIT : Diagnosis Procedure	65
System Description	44	DISPLAY UNIT	66
Component Parts Location	45	DISPLAY UNIT : Diagnosis Procedure	66
Component Description	46	A/C AND AV SWITCH ASSEMBLY	67
REAR VIEW MONITOR SYSTEM	47	A/C AND AV SWITCH ASSEMBLY : Diagnosis	
System Diagram	47	Procedure	67
System Description	47	REAR VIEW CAMERA	68
Component Parts Location	47	REAR VIEW CAMERA : Diagnosis Procedure	68
Component Description	48	RGB (R: RED) SIGNAL CIRCUIT	70
DIAGNOSIS SYSTEM (AV CONTROL UNIT) ...	49	Description	70
AV CONTROL UNIT	49	Diagnosis Procedure	70
AV CONTROL UNIT : Diagnosis Description	49	RGB (G: GREEN) SIGNAL CIRCUIT	71
AV CONTROL UNIT : CONSULT Function	54	Description	71
A/C AND AV SWITCH ASSEMBLY	55	Diagnosis Procedure	71
A/C AND AV SWITCH ASSEMBLY : Component		RGB (B: BLUE) SIGNAL CIRCUIT	72
Function Check	55	Description	72
DTC/CIRCUIT DIAGNOSIS	56	Diagnosis Procedure	72
U1000 CAN COMM CIRCUIT	56	RGB SYNCHRONIZING SIGNAL CIRCUIT	73
Description	56	Description	73
DTC Logic	56	Diagnosis Procedure	73
Diagnosis Procedure	56	RGB AREA (YS) SIGNAL CIRCUIT	74
U1010 CONTROL UNIT (CAN)	57	Description	74
Description	57	Diagnosis Procedure	74
DTC Logic	57	HORIZONTAL SYNCHRONIZING (HP) SIG-	
Diagnosis Procedure	57	NAL CIRCUIT	75
U1200 AV CONTROL UNIT	58	Description	75
Description	58	Diagnosis Procedure	75
DTC Logic	58	VERTICAL SYNCHRONIZING (VP) SIGNAL	
U1216 AV CONTROL UNIT	59	CIRCUIT	76
Description	59	Description	76
DTC Logic	59	Diagnosis Procedure	76
U1240 SWITCH CONN	60	FRONT DOOR SPEAKER	77
Description	60	Description	77
U1243 DISPLAY UNIT	61	Diagnosis Procedure	77
Description	61	FRONT TWEETER	79
DTC Logic	61	Description	79
Diagnosis Procedure	61	Diagnosis Procedure	79
U1300 AV COMM CIRCUIT	63	REAR DOOR SPEAKER	81
		Description	81
		Diagnosis Procedure	81

STEERING SWITCH	83	STEERING SWITCH	120	
Description	83	Removal and Installation	120	A
Diagnosis Procedure	83	AUDIO ANTENNA	121	
REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT	85	Location of Antenna	121	B
Description	85	Window Antenna Repair	121	
Diagnosis Procedure	85	AUXILIARY INPUT JACK	123	C
ECU DIAGNOSIS INFORMATION	86	Removal and Installation	123	
AV CONTROL UNIT	86	ANTENNA AMP.	124	D
Reference Value	86	Removal and Installation	124	
DTC Index	91	REAR VIEW CAMERA	125	E
DISPLAY UNIT	92	Removal and Installation	125	
Reference Value	92	BOSE AUDIO WITHOUT NAVIGATION		
WIRING DIAGRAM	95	BASIC INSPECTION	126	F
MID AUDIO SYSTEM	95	DIAGNOSIS AND REPAIR WORKFLOW	126	
Wiring Diagram	95	Work Flow	126	G
SYMPTOM DIAGNOSIS	109	SYSTEM DESCRIPTION	128	
AUDIO SYSTEM	109	AUDIO SYSTEM	128	H
Symptom Table	109	System Diagram	128	
NORMAL OPERATING CONDITION	110	System Description	128	I
Description	110	Component Parts Location	130	
PRECAUTION	111	Component Description	131	J
PRECAUTIONS	111	REAR VIEW MONITOR SYSTEM	132	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	111	System Diagram	132	K
Precaution Necessary for Steering Wheel Rotation After Battery Disconnect	111	System Description	132	
Precaution for Work	112	Component Parts Location	133	L
PREPARATION	113	Component Description	134	
PREPARATION	113	DVD PLAYER	135	M
Special Service Tool	113	System Diagram	135	
Commercial Service Tools	113	System Description	135	
REMOVAL AND INSTALLATION	114	Component Parts Location	136	
AV CONTROL UNIT	114	Component Description	136	
Removal and Installation	114	HANDS-FREE PHONE SYSTEM	138	
DISPLAY UNIT	116	System Diagram	138	
Removal and Installation	116	System Description	138	
FRONT TWEETER	117	Component Parts Location	139	
Removal and Installation	117	Component Description	140	
FRONT DOOR SPEAKER	118	HANDS-FREE PHONE SYSTEM	138	
Removal and Installation	118	System Diagram	138	
REAR DOOR SPEAKER	119	System Description	138	
Removal and Installation	119	Component Parts Location	139	
		Component Description	140	
		DIAGNOSIS SYSTEM (AV CONTROL UNIT)	141	
		AV CONTROL UNIT	141	O
		AV CONTROL UNIT : Diagnosis Description	141	
		AV CONTROL UNIT : CONSULT Function	147	
		A/C AND AV SWITCH ASSEMBLY	147	P
		A/C AND AV SWITCH ASSEMBLY : Component Function Check	148	
		DIAGNOSIS SYSTEM (BLUETOOTH CONTROL UNIT)	149	
		Diagnosis Description	149	
		Work Flow	149	

DTC/CIRCUIT DIAGNOSIS	150	SUBWOOFER	165
		SUBWOOFER : Diagnosis Procedure	166
U1000 CAN COMM CIRCUIT	150	SATELLITE RADIO TUNER	166
Description	150	SATELLITE RADIO TUNER : Diagnosis Procedure	166
DTC Logic	150		
Diagnosis Procedure	150	REAR VIEW CAMERA	167
U1010 CONTROL UNIT (CAN)	151	REAR VIEW CAMERA : Diagnosis Procedure	167
Description	151		
DTC Logic	151	DVD PLAYER	168
Diagnosis Procedure	151	DVD PLAYER : Diagnosis Procedure	168
U1200 AV CONTROL UNIT	152	VIDEO MONITOR	169
Description	152	VIDEO MONITOR : Diagnosis Procedure	169
DTC Logic	152		
U1216 AV CONTROL UNIT	153	BLUETOOTH CONTROL UNIT	170
Description	153	BLUETOOTH CONTROL UNIT : Diagnosis Procedure	170
DTC Logic	153		
U1240 SWITCH CONN	154	MICROPHONE	171
Description	154	MICROPHONE : Diagnosis Procedure	171
U1243 DISPLAY UNIT	155	RGB (R: RED) SIGNAL CIRCUIT	173
Description	155	Description	173
DTC Logic	155	Diagnosis Procedure	173
Diagnosis Procedure	155	RGB (G: GREEN) SIGNAL CIRCUIT	174
U1248 DVD DECK CONN	157	Description	174
Description	157	Diagnosis Procedure	174
DTC Logic	157	RGB (B: BLUE) SIGNAL CIRCUIT	175
Diagnosis Procedure	157	Description	175
U1255 SATELLITE RADIO TUNER	158	Diagnosis Procedure	175
Description	158	RGB SYNCHRONIZING SIGNAL CIRCUIT	176
DTC Logic	158	Description	176
Diagnosis Procedure	158	Diagnosis Procedure	176
U1256 HAND FREE CONN	159	RGB AREA (YS) SIGNAL CIRCUIT	177
Description	159	Description	177
U1300 AV COMM CIRCUIT	160	Diagnosis Procedure	177
Description	160	HORIZONTAL SYNCHRONIZING (HP) SIGNAL CIRCUIT	178
U1310 AV CONTROL UNIT	161	Description	178
Description	161	Diagnosis Procedure	178
DTC Logic	161	VERTICAL SYNCHRONIZING (VP) SIGNAL CIRCUIT	179
POWER SUPPLY AND GROUND CIRCUIT ..	162	Description	179
AV CONTROL UNIT	162	Diagnosis Procedure	179
AV CONTROL UNIT : Diagnosis Procedure	162	FRONT DOOR SPEAKER	180
DISPLAY UNIT	163	Description	180
DISPLAY UNIT : Diagnosis Procedure	163	Diagnosis Procedure	180
A/C AND AV SWITCH ASSEMBLY	164	FRONT TWEETER	183
A/C AND AV SWITCH ASSEMBLY : Diagnosis Procedure	164	Description	183
BOSE SPEAKER AMP	165	Diagnosis Procedure	183
BOSE SPEAKER AMP : Diagnosis Procedure	165	REAR DOOR SPEAKER	186
		Description	186

Diagnosis Procedure	186	BOSE AUDIO SYSTEM	225	A
REAR TWEETER	189	Wiring Diagram - Without Navigation System	225	
Description	189	SYMPTOM DIAGNOSIS	249	B
Diagnosis Procedure	189	AUDIO SYSTEM	249	
SUBWOOFER	192	Symptom Table	249	C
Description	192	NORMAL OPERATING CONDITION	251	
Diagnosis Procedure	192	Description	251	D
AMP ON SIGNAL CIRCUIT	195	PRECAUTION	252	
Description	195	PRECAUTIONS	252	E
Diagnosis Procedure	195	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	252	
STEERING SWITCH	196	Precaution Necessary for Steering Wheel Rota- tion After Battery Disconnect	252	F
Description	196	Precaution for Work	253	
Diagnosis Procedure	196	PREPARATION	254	G
COMMUNICATION SIGNAL CIRCUIT	198	PREPARATION	254	
SATELLITE RADIO TUNER	198	Special Service Tool	254	H
SATELLITE RADIO TUNER : Description	198	Commercial Service Tools	254	
SATELLITE RADIO TUNER : Diagnosis Proce- dure	198	REMOVAL AND INSTALLATION	255	I
SOUND SIGNAL CIRCUIT	201	AV CONTROL UNIT	255	
SATELLITE RADIO TUNER	201	Removal and Installation	255	J
SATELLITE RADIO TUNER : Description	201	DISPLAY UNIT	257	
SATELLITE RADIO TUNER : Diagnosis Proce- dure	201	Removal and Installation	257	K
MICROPHONE SIGNAL CIRCUIT	203	FRONT TWEETER	258	
Description	203	Removal and Installation	258	L
Diagnosis Procedure	203	FRONT DOOR SPEAKER	259	
REAR VIEW CAMERA IMAGE SIGNAL CIR- CUIT	205	Removal and Installation	259	M
Description	205	REAR DOOR SPEAKER	260	
Diagnosis Procedure	205	Removal and Installation of Rear Door Speaker ..	260	
ECU DIAGNOSIS INFORMATION	206	REAR DOOR TWEETER	261	
AV CONTROL UNIT	206	Removal and Installation of Rear Tweeter	261	
Reference Value	206	STEERING SWITCH	262	AV
DTC Index	212	Removal and Installation	262	
DISPLAY UNIT	214	MICROPHONE	263	O
Reference Value	214	Removal and Installation	263	
BOSE SPEAKER AMP	217	BLUETOOTH CONTROL UNIT	264	P
Reference Value	217	Removal and Installation	264	
SATELLITE RADIO TUNER	219	BOSE SPEAKER AMP	265	
Reference Value	219	Removal and Installation	265	
DVD PLAYER	221	SUBWOOFER	266	
Reference Value	221	Removal and Installation	266	
BLUETOOTH CONTROL UNIT	223	DVD ENTERTAINMENT SYSTEM	267	
Reference Value	223			
WIRING DIAGRAM	225			

Removal and Installation of DVD Player	267	AV CONTROL UNIT	295
Removal and Installation of Video Monitor	267	AV CONTROL UNIT : Diagnosis Description	295
AUDIO ANTENNA	268	AV CONTROL UNIT : CONSULT Function	306
Location of Antenna	268	A/C AND AV SWITCH ASSEMBLY	307
Window Antenna Repair	268	A/C AND AV SWITCH ASSEMBLY : Component	
AUXILIARY INPUT JACK	270	Function Check	307
Removal and Installation	270	DTC/CIRCUIT DIAGNOSIS	309
ANTENNA AMP.	271	U1000 CAN COMM CIRCUIT	309
Removal and Installation	271	Description	309
SATELLITE RADIO ANTENNA	272	DTC Logic	309
Removal and Installation	272	Diagnosis Procedure	309
SATELLITE RADIO TUNER	273	U1010 CONTROL UNIT (CAN)	310
Removal and Installation	273	Description	310
REAR VIEW CAMERA	274	DTC Logic	310
Removal and Installation	274	Diagnosis Procedure	310
BOSE AUDIO WITH NAVIGATION			
BASIC INSPECTION	275	U1200 AV CONTROL UNIT	311
DIAGNOSIS AND REPAIR WORKFLOW	275	Description	311
Work Flow	275	DTC Logic	311
SYSTEM DESCRIPTION	277	U1201 AV CONTROL UNIT	312
AUDIO SYSTEM	277	Description	312
System Diagram	277	DTC Logic	312
System Description	277	U1204 GPS COMM	313
Component Parts Location	279	Description	313
Component Description	280	DTC Logic	313
NAVIGATION SYSTEM	281	U1205 GPS ROM	314
System Diagram	281	Description	314
System Description	281	DTC Logic	314
Component Parts Location	284	U1206 GPS RAM	315
Component Description	285	Description	315
REAR VIEW MONITOR SYSTEM	286	DTC Logic	315
System Diagram	286	U1207 GPS RTC	316
System Description	286	Description	316
Component Parts Location	287	DTC Logic	316
Component Description	288	U1216 AV CONTROL UNIT	317
DVD PLAYER	289	Description	317
System Diagram	289	DTC Logic	317
System Description	289	U1217 AV CONTROL UNIT	318
Component Parts Location	290	Description	318
Component Description	290	DTC Logic	318
HANDS-FREE PHONE SYSTEM	292	U1218 AV CONTROL UNIT	319
System Diagram	292	Description	319
System Description	292	DTC Logic	319
Component Parts Location	293	U1219 AV CONTROL UNIT	320
Component Description	294	Description	320
DIAGNOSIS SYSTEM (AV CONTROL UNIT) .	295	DTC Logic	320
		U1220 AV CONTROL UNIT	321
		Description	321

DTC Logic	321	SUBWOOFER	337	
U121A AV CONTROL UNIT	322	SUBWOOFER : Diagnosis Procedure	338	A
Description	322	REAR VIEW CAMERA	338	
DTC Logic	322	REAR VIEW CAMERA : Diagnosis Procedure	338	B
U121B AV CONTROL UNIT	323	DVD PLAYER	339	
Description	323	DVD PLAYER : Diagnosis Procedure	339	C
DTC Logic	323	VIDEO MONITOR	340	
U121C AV CONTROL UNIT	324	VIDEO MONITOR : Diagnosis Procedure	340	D
Description	324	MICROPHONE	341	
DTC Logic	324	MICROPHONE : Diagnosis Procedure	341	D
U121D AV CONTROL UNIT	325	RGB (R: RED) SIGNAL CIRCUIT	343	
Description	325	Description	343	E
DTC Logic	325	Diagnosis Procedure	343	
U121E AV CONTROL UNIT	326	RGB (G: GREEN) SIGNAL CIRCUIT	344	
Description	326	Description	344	F
DTC Logic	326	Diagnosis Procedure	344	
U121F AV CONTROL UNIT	327	RGB (B: BLUE) SIGNAL CIRCUIT	345	
Description	327	Description	345	G
DTC Logic	327	Diagnosis Procedure	345	
Diagnosis Procedure	327	RGB SYNCHRONIZING SIGNAL CIRCUIT ...	346	
U1243 DISPLAY UNIT	328	Description	346	H
Description	328	Diagnosis Procedure	346	
DTC Logic	328	RGB AREA (YS) SIGNAL CIRCUIT	347	
Diagnosis Procedure	328	Description	347	I
U1244 GPS ANTENNA	330	Diagnosis Procedure	347	J
Description	330	HORIZONTAL SYNCHRONIZING (HP) SIG-		
DTC Logic	330	NAL CIRCUIT	348	
Diagnosis Procedure	330	Description	348	K
U1258 SATELLITE RADIO ANTENNA	331	Diagnosis Procedure	348	
Description	331	VERTICAL SYNCHRONIZING (VP) SIGNAL		
DTC Logic	331	CIRCUIT	349	
Diagnosis Procedure	331	Description	349	L
U1300 AV COMM CIRCUIT	332	Diagnosis Procedure	349	
Description	332	FRONT DOOR SPEAKER	350	
U1310 AV CONTROL UNIT	333	Description	350	M
Description	333	Diagnosis Procedure	350	
DTC Logic	333	FRONT TWEETER	353	
POWER SUPPLY AND GROUND CIRCUIT ...	334	Description	353	O
AV CONTROL UNIT	334	Diagnosis Procedure	353	
AV CONTROL UNIT : Diagnosis Procedure	334	REAR DOOR SPEAKER	356	
DISPLAY UNIT	335	Description	356	P
DISPLAY UNIT : Diagnosis Procedure	335	Diagnosis Procedure	356	
A/C AND AV SWITCH ASSEMBLY	336	REAR TWEETER	359	
A/C AND AV SWITCH ASSEMBLY : Diagnosis		Description	359	
Procedure	336	Diagnosis Procedure	359	
BOSE SPEAKER AMP	337	SUBWOOFER	362	
BOSE SPEAKER AMP : Diagnosis Procedure	337	Description	362	

Diagnosis Procedure	362	PREPARATION	419
AMP ON SIGNAL CIRCUIT	365	PREPARATION	419
Description	365	Special Service Tool	419
Diagnosis Procedure	365	Commercial Service Tools	419
STEERING SWITCH	366	REMOVAL AND INSTALLATION	420
Description	366	AV CONTROL UNIT	420
Diagnosis Procedure	366	Removal and Installation	420
MICROPHONE SIGNAL CIRCUIT	368	DISPLAY UNIT	422
Description	368	Removal and Installation	422
Diagnosis Procedure	368	FRONT TWEETER	423
REAR VIEW CAMERA IMAGE SIGNAL CIR- CUIT	370	Removal and Installation	423
Description	370	FRONT DOOR SPEAKER	424
Diagnosis Procedure	370	Removal and Installation	424
ECU DIAGNOSIS INFORMATION	371	REAR DOOR SPEAKER	425
AV CONTROL UNIT	371	Removal and Installation of Rear Door Speaker ..	425
Reference Value	371	REAR DOOR TWEETER	426
DTC Index	376	Removal and Installation of Rear Tweeter	426
DISPLAY UNIT	378	BOSE SPEAKER AMP	427
Reference Value	378	Removal and Installation	427
BOSE SPEAKER AMP	381	SUBWOOFER	428
Reference Value	381	Removal and Installation	428
DVD PLAYER	383	DVD ENTERTAINMENT SYSTEM	429
Reference Value	383	Removal and Installation of DVD Player	429
WIRING DIAGRAM	385	Removal and Installation of Video Monitor	429
BOSE AUDIO SYSTEM	385	AUDIO ANTENNA	430
Wiring Diagram - With Navigation System	385	Location of Antenna	430
SYMPTOM DIAGNOSIS	407	Window Antenna Repair	430
MULTI AV SYSTEM	407	AUXILIARY INPUT JACK	432
Symptom Table	407	Removal and Installation	432
NORMAL OPERATING CONDITION	409	ANTENNA AMP.	433
Description	409	Removal and Installation	433
PRECAUTION	417	GPS ANTENNA	434
PRECAUTIONS	417	Removal and Installation	434
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	417	SATELLITE RADIO ANTENNA	435
Precaution Necessary for Steering Wheel Rota- tion After Battery Disconnect	417	Removal and Installation	435
Precaution for Trouble Diagnosis	418	STEERING SWITCH	436
Precaution for Harness Repair	418	Removal and Installation	436
Precaution for Work	418	MICROPHONE	437
		Removal and Installation	437
		REAR VIEW CAMERA	438
		Removal and Installation	438


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000007347574

OVERALL SEQUENCE



DETAILED FLOW

1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3

3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[BASE AUDIO]

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

4. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

5. FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Has the symptom been repaired?


YES >> Inspection End.

NO >> GO TO 2

SYSTEM DESCRIPTION

AUDIO SYSTEM

System Diagram



System Description

AUDIO SYSTEM


The audio system consists of the following components

- Audio unit
- Window antenna (audio)
- Front door speakers
- Front tweeters
- Rear door speakers

When the audio system is on, radio signals are received by the window antenna. The audio unit then sends audio signals to the front door speakers, front tweeters and rear speakers.

Refer to Owner's Manual for audio system operating instructions.

Component Parts Location



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[BASE AUDIO]

1. Front tweeter LH M109
2. Audio unit M38, M60
3. Front tweeter RH M111
4. Front door speaker
LH D12
RH D112
5. Rear door speaker
LH D209
RH D309

Component Description

INFOID:000000007347578

Part name	Description
Audio unit	Controls audio system functions
Front door speakers	<ul style="list-style-type: none">• Outputs audio signal from audio unit• Outputs high, mid and low range sounds
Front tweeters	<ul style="list-style-type: none">• Outputs audio signal from audio unit• Outputs high range sounds
Rear door speakers	<ul style="list-style-type: none">• Outputs audio signal from audio unit• Outputs high, mid and low range sounds

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT AUDIO UNIT

AUDIO UNIT : Diagnosis Procedure

INFOID:000000007347579

Regarding Wiring Diagram information, refer to [AV-22, "Wiring Diagram"](#).

1. CHECK FUSES

Check that the following fuses are not blown.

Unit	Terminals	Signal name	Fuse No.
Audio unit	19	Battery power	29
	7	Ignition switch ACC or ON	4

Are the fuses OK?


YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect audio unit connector M38.
2. Check voltage between the audio unit connector M38 and ground.

(+)		(-)	OFF	ACC	ON
Connector	Terminal				
M38	19	Ground	Battery voltage	Battery voltage	Battery voltage
	7	Ground	0V	Battery voltage	Battery voltage



Are the voltage results as specified?

YES >> GO TO 3

NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.

3. GROUND CIRCUIT CHECK

Inspect audio unit case ground.

Does case ground pass inspection?

YES >> Inspection End.

NO >> Repair audio unit case ground.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[BASE AUDIO]

FRONT DOOR SPEAKER

Description

INFOID:000000007347580

The audio unit sends audio signals to the front door speakers using the front door speaker circuits.

Diagnosis Procedure

INFOID:000000007347581

Regarding Wiring Diagram information, refer to [AV-22, "Wiring Diagram"](#).

1. CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. HARNESS CHECK

1. Disconnect audio unit connector M38 (A) and suspect speaker connector (B).
2. Check continuity between audio unit harness connector M38 (A) terminal and suspect speaker harness connector (B) terminal.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M38	2	D12	1	Yes
	3		2	
	11	D112	1	
	12		2	

3. Check continuity between audio unit harness connector M38 (A) terminal and ground.


A		—	Continuity
Connector	Terminal		
M38	2	Ground	No
	3		
	11		
	12		

Are continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3. FRONT SPEAKER SIGNAL CHECK




AWNIA00312Z

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[BASE AUDIO]


1. Connect audio unit connector and front speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector terminals with CONSULT or oscilloscope.

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
M38	2	3	Receive audio signal	 <small>SKIA0177E</small>
	11	12		

Is the audio signal voltage as specified?

YES >> Replace speaker. Refer to [AV-37, "Removal and Installation"](#).

NO >> Replace audio unit. Refer to [AV-34, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

FRONT TWEETER

Description

INFOID:000000007347582

The audio unit sends audio signals to the front tweeters using the front tweeter circuits.

Diagnosis Procedure

INFOID:000000007347583

Regarding Wiring Diagram information, refer to [AV-22, "Wiring Diagram"](#).

1. CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.


2. HARNESS CHECK

1. Disconnect audio unit connector M38 (A) and suspect front tweeter connector (B).
2. Check continuity between audio unit harness connector M38 (A) and suspect front tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M38	2	M109	1	Yes
	3		2	
	11	M111	1	
	12		2	

3. Check continuity between audio unit harness connector M38 (A) and ground.

A		—	Continuity
Connector	Terminal		
M38	2	Ground	No
	3		
	11		
	12		



AWNIA003122

Are the continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.


3. TWEETER SIGNAL CHECK

FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[BASE AUDIO]


1. Connect audio unit connector and front tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M38	2	3	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
	11	12		

Is the audio signal voltage as specified?

YES >> Replace tweeter. Refer to [AV-36, "Removal and Installation"](#).

NO >> Replace audio unit. Refer to [AV-34, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[BASE AUDIO]

REAR DOOR SPEAKER

Description

INFOID:000000007347584

The audio unit sends audio signals to the rear door speakers using the rear door speaker circuits.

Diagnosis Procedure

INFOID:000000007347585

Regarding Wiring Diagram information, refer to [AV-22, "Wiring Diagram"](#).

1. CONNECTOR CHECK

Check the audio unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. HARNESS CHECK

1. Disconnect audio unit connector M38 (A) and suspect speaker connector.
2. Check continuity between audio unit harness connector M38 (A) and suspect speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M38	4	D207	1	Yes
	5		2	
	13	D307	1	
	14		2	

3. Check continuity between audio unit harness connector M38 (A) and ground.


A		—	Continuity
Connector	Terminal		
M38	4	Ground	No
	5		
	13		
	14		

Are the continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3. REAR SPEAKER SIGNAL CHECK




REAR DOOR SPEAKER

[BASE AUDIO]

< DTC/CIRCUIT DIAGNOSIS >


1. Connect audio unit connector and rear door speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between audio unit harness connector terminals with CONSULT or oscilloscope.

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
M38	4	5	Receive audio signal	 <small>SKIA0177E</small>
	13	14		

Is the audio signal voltage as specified?

YES >> Replace rear speaker. Refer to [AV-38. "Removal and Installation"](#).

NO >> Replace audio unit. Refer to [AV-34. "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[BASE AUDIO]


ECU DIAGNOSIS INFORMATION

AUDIO UNIT

Reference Value

INFOID:000000007347586

TERMINAL LAYOUT




PHYSICAL VALUES

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-					
2 (BR)	3 (L)	Audio signal front LH	Output	Ignition switch ON	Audio output	<p>SKIA0177E</p>
4 (G)	5 (B)	Audio signal rear LH	Output	Ignition switch ON	Audio output	<p>SKIA0177E</p>
7 (G/B)	Ground	ACC signal	Input	Ignition switch ON	Ignition switch ACC or ON	Battery voltage
8 (GR)	—	Illumination control	—	—	—	—
9 (R)	Ground	Illumination power	Input	Ignition switch ON	Lighting switch ON	Battery voltage
11 (LG)	12 (R)	Audio signal front RH	Output	Ignition switch ON	Audio output	<p>SKIA0177E</p>

AUDIO UNIT

< ECU DIAGNOSIS INFORMATION >

[BASE AUDIO]

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value
+	-					
13 (GR)	14 (O)	Audio signal rear RH	Output	Ignition switch ON	Audio output	
19 (Y)	Ground	Battery power	Input	-	-	Battery voltage
22	—	Antenna main	—	—	—	—
23	—	Antenna power	Output	Ignition switch ON	With AM/FM radio se- lected	Battery voltage

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P


WIRING DIAGRAM

BASE AUDIO SYSTEM

Wiring Diagram

INFOID:000000007347587

BASE AUDIO SYSTEM



*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

ABNWA1325GB


BASE AUDIO SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
4P	G/B	-

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	L	-
3	BR	- (WITHOUT BOSE AUDIO SYSTEM)

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
77G	Y	-

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
71M	GR	-
72M	O	-

ABNIA3308GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

BASE AUDIO SYSTEM


< WIRING DIAGRAM >

[BASE AUDIO]



Terminal No.	Color of Wire	Signal Name
9	R	TAIL/ILL RLY
10	-	-
11	LG	FR SP RH (+)
12	R	FR SP RH (-)
13	GR	RR SP RH (+)
14	O	RR SP RH (-)
15	-	-
16	-	-
17	-	-
18	-	-
19	Y	BAT
20	-	-


Connector No.	M38
Connector Name	AUDIO UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	BR	FR SP LH (+)
3	L	FR SP LH (-)
4	G	RR SP LH (+)
5	B	RR SP LH (-)
6	-	-
7	G/B	ACC
8	GR	ILL CONT OUT


Terminal No.	Color of Wire	Signal Name
3J	G	-(WITHOUT BOSE AUDIO SYSTEM)
8J	B	-(WITHOUT BOSE AUDIO SYSTEM)

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R	-
11	LG	-(WITHOUT BOSE AUDIO SYSTEM)

Connector No.	M60
Connector Name	AUDIO UNIT
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
21	-	-
22	-	ANT MAIN
23	-	ANT +B

ABNIA3309GB

BASE AUDIO SYSTEM

< WIRING DIAGRAM >

[BASE AUDIO]

Connector No.	M501
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	L	-

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-
2	L	-

Connector No.	M602
Connector Name	ANTENNA AMP.
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

Connector No.	M601
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

Connector No.	M502
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

ABNIA3310GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

BASE AUDIO SYSTEM

< WIRING DIAGRAM >

[BASE AUDIO]

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4	5
6	7	8	9	10
11	12			



Terminal No.	Color of Wire	Signal Name
5	G	– (WITHOUT BOSE AUDIO SYSTEM)
12	B	– (WITHOUT BOSE AUDIO SYSTEM)

Terminal No.	Color of Wire	Signal Name
77G	Y	–

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1G	2G	3G	4G	5G
6G	7G	8G	9G	10G



11G	12G	13G	14G	15G	16G	17G	18G	19G	20G	21G
22G	23G	24G	25G	26G	27G	28G	29G	30G		
31G	32G	33G	34G	35G	36G	37G	38G	39G	40G	41G
42G	43G	44G	45G	46G	47G	48G	49G	50G		
51G	52G	53G	54G	55G	56G	57G	58G	59G	60G	61G
62G	63G	64G	65G	66G	67G	68G	69G	70G		

71G	72G	73G	74G	75G
76G	77G	78G	79G	80G

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1	2	3	4	5
6	7	8	9	10
11	12			



Terminal No.	Color of Wire	Signal Name
5	GR	–
12	O	–

Terminal No.	Color of Wire	Signal Name
3J	G	– (WITHOUT BOSE AUDIO SYSTEM)
8J	B	– (WITHOUT BOSE AUDIO SYSTEM)

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE

1J	2J	3J	4J	5J
6J	7J	8J	9J	10J



11J	12J	13J	14J	15J	16J	17J	18J	19J	20J	21J
22J	23J	24J	25J	26J	27J	28J	29J	30J		
31J	32J	33J	34J	35J	36J	37J	38J	39J	40J	41J
42J	43J	44J	45J	46J	47J	48J	49J	50J		
51J	52J	53J	54J	55J	56J	57J	58J	59J	60J	61J
62J	63J	64J	65J	66J	67J	68J	69J	70J		

71J	72J	73J	74J	75J
76J	77J	78J	79J	80J

ABNIA3311GB

BASE AUDIO SYSTEM

< WIRING DIAGRAM >


[BASE AUDIO]

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
2	L/R	-
3	L/W	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
71M	GR	-
72M	O	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	L/B	-
11	W/B	-

ABNIA3312GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

BASE AUDIO SYSTEM

< WIRING DIAGRAM >


[BASE AUDIO]

Connector No.	D309
Connector Name	REAR DOOR SPEAKER RH (WITHOUT BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	O	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

Connector No.	D209
Connector Name	REAR DOOR SPEAKER LH (WITHOUT BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	O	-

ABNIA3313GB

SYMPTOM DIAGNOSIS

AUDIO SYSTEM

AUDIO UNIT

AUDIO UNIT : Symptom Table

INFOID:000000007347588

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> • Audio unit power supply and ground circuit • Audio unit 	<ul style="list-style-type: none"> • AV-13 • AV-34
All speakers do not sound	<ul style="list-style-type: none"> • Speaker circuit shorted to ground • Audio unit 	<ul style="list-style-type: none"> • AV-22 • AV-34
One or several speakers do not sound	<ul style="list-style-type: none"> • Front door speaker • Front tweeter • Rear door speaker 	<ul style="list-style-type: none"> • AV-14 • AV-16 • AV-18
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BASE AUDIO]

NORMAL OPERATING CONDITION

Description

INFOID:000000007347589

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

NOISE

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	<ul style="list-style-type: none"> • Ignition components
The occurrence of the noise is linked with the operation of the fuel pump.		<ul style="list-style-type: none"> • Fuel pump condenser
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	<ul style="list-style-type: none"> • Relay malfunction, audio unit malfunction
	The noise occurs when various motors are operating.	<ul style="list-style-type: none"> • Motor case ground • Motor
The noise occurs constantly, not just under certain conditions.		<ul style="list-style-type: none"> • Rear defogger coil malfunction • Open circuit in printed heater • Poor ground of antenna feeder line
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		<ul style="list-style-type: none"> • Ground wire of body parts • Ground due to improper part installation • Wiring connections or a short circuit

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007347590

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000007833551

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

PRECAUTIONS

< PRECAUTION >

[BASE AUDIO]

5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT.

Precaution for Work

INFOID:000000007347591

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components.
 - Water soluble dirt: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the dirty area.
Then rub with a soft and dry cloth.
 - Oily dirt: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the dirty area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[BASE AUDIO]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000007347592

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim tool set	Removing trim components




AWJIA04832Z

Commercial Service Tools

INFOID:000000007347593

Tool name	Description
Power tool	Loosening nuts, screws and bolts



PIIB1407E

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P


REMOVAL AND INSTALLATION

AUDIO UNIT

Removal and Installation

INFOID:000000007347594

Removal and Installation



1. Audio unit 2. Audio unit brackets (LH) and (RH) 3. Cluster lid C

REMOVAL

1. Disconnect the battery negative terminal.
2. Remove the cluster lid C. Refer to [IP-16. "Removal and Installation"](#).
3. Remove the audio unit screws, using power tool.
4. Remove the audio unit and disconnect audio unit connectors.
5. Remove the audio unit brackets screws and remove the audio unit brackets.

INSTALLATION

AUDIO UNIT

< REMOVAL AND INSTALLATION >

[BASE AUDIO]

Installation is in the reverse order of removal.

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- L
- M
- AV**
- O
- P

FRONT TWEETER

Removal and Installation


INFOID:000000007347595

REMOVAL

CAUTION:

Use a suitable tool to prevent damage to the front tweeter speaker grille trim and the instrument panel.

1. Remove the front tweeter grille.
2. Remove the front tweeter screws (A).
3. Pull out the front tweeter speaker (1) and disconnect front tweeter connector, then remove the front tweeter speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[BASE AUDIO]


FRONT DOOR SPEAKER

Removal and Installation

INFOID:000000007347596

REMOVAL

1. Remove the front door finisher. Refer to [INT-15, "Removal and Installation"](#).
2. Remove the front door speaker screws (A).
3. Pull out the front door speaker (1), and disconnect the front door speaker connector and remove the front door speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[BASE AUDIO]


REAR DOOR SPEAKER

Removal and Installation

INFOID:000000007347597

REMOVAL

1. Remove the rear door finisher. Refer to [INT-15. "Removal and Installation"](#).
2. Remove the rear door speaker screws (A).
3. Disconnect the rear door speaker connector (B) and remove rear door speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[BASE AUDIO]

AUDIO ANTENNA

Location of Antenna

INFOID:000000007347598



1. Audio unit M38, M60

2. Harness connector
M78, M501

3. Harness connector
M502, M601

4. Antenna feeder

5. Antenna amp.
M602


6. Window antenna grid

Window Antenna Repair

INFOID:000000007347599

ELEMENT CHECK

1. Attach probe circuit tester (ohm setting) to antenna terminal on each side.




A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[BASE AUDIO]


- When measuring continuity, wrap tin foil around the top of probe. Then, press the foil against the wire with your finger.



2. If an element is broken, no continuity will exist.



3. To locate a break, move probe along element. Tester indication will change abruptly when probe passes the broken point.



ELEMENT REPAIR

Refer to [DEF-45, "Filament Repair"](#).

ANTENNA AMP.

< REMOVAL AND INSTALLATION >

[BASE AUDIO]


ANTENNA AMP.

Removal and Installation

INFOID:000000007347600

REMOVAL

1. Remove the luggage side upper and lower RH finishers. Refer to [INT-25. "Removal and Installation"](#).
2. Detach the antenna amp. harness clip (D), disconnect the antenna amp. connector (A), harness connector (B), then remove the antenna amp. screw (C) and remove the antenna amp. (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000007347601

OVERALL SEQUENCE



DETAILED FLOW

1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3

3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

DIAGNOSIS AND REPAIR WORKFLOW

[MID AUDIO]

< BASIC INSPECTION >

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

4. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

5. FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Has the symptom been repaired?

YES >> Inspection End.

NO >> GO TO 2

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O


P

SYSTEM DESCRIPTION

AUDIO SYSTEM

System Diagram

INFOID:000000007347602



System Description

INFOID:000000007347603

AUDIO SYSTEM

AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[MID AUDIO]

The audio system consists of the following components

- AV control unit
- Display unit
- Window antenna
- Steering wheel audio control switches
- A/C and AV switch assembly
- Front door speakers
- Front tweeters
- Rear door speakers

When the audio system is on, radio signals are received by the window antenna. The AV control unit then sends audio signals to the front door speakers, front tweeters and rear door speakers.


Refer to Owner's Manual for audio system operating instructions.

SPEED SENSITIVE VOLUME SYSTEM

The volume level of this system goes up and down automatically in proportion to vehicle speed. The control level can be set by the customer. Refer to the Owner's Manual for operating instructions.

Component Parts Location

INFOID:000000007347604



1. Steering wheel audio control switches
2. Front tweeter LH M109
3. AV control unit M131, M132, M133, M134, M135
4. A/C and AV switch assembly M98
5. Display unit M93
6. Front tweeter RH M111

AWNIA22952Z

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[MID AUDIO]

- | | | |
|---------------------------|--|--|
| 7. Aux. jack M85 | 8. Front door speaker
LH D12
RH D112 | 9. Rear door speaker
LH D209
RH D309 |
| 10. Rear view camera D551 | | |

Component Description

INFOID:000000007347605

Part name	Description
AV control unit	Controls audio system functions
Display unit	Displays audio and climate control related information
A/C and AV switch assembly	<ul style="list-style-type: none"> All audio and A/C operations can be operated switch signal is output to the AV control unit and A/C auto amp
Steering wheel audio control switches	<ul style="list-style-type: none"> Audio operation can be operated Steering switch signal (operation signal) is output to AV control unit
Front door speakers	<ul style="list-style-type: none"> Outputs audio signal from AV control unit Outputs high, mid and low range sounds
Front tweeters	<ul style="list-style-type: none"> Outputs audio signal from AV control unit Outputs high range sounds
Rear door speakers	<ul style="list-style-type: none"> Outputs audio signal from AV control unit Outputs high, mid and low range sounds
Antenna amp.	<ul style="list-style-type: none"> Radio signal received by window antenna is amplified and sent to AV control unit Power (antenna amp. ON signal) is supplied from AV control unit


REAR VIEW MONITOR SYSTEM

< SYSTEM DESCRIPTION >

[MID AUDIO]

REAR VIEW MONITOR SYSTEM


System Diagram



System Description

When the shift selector is in the R position, the AV control unit receives camera image signals from the rear view camera and sends the camera image signals to the display unit which shows a view to the rear of the vehicle. Lines which indicate the vehicle clearance and distances are also displayed.

Component Parts Location



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

REAR VIEW MONITOR SYSTEM

< SYSTEM DESCRIPTION >

[MID AUDIO]

1. Steering wheel audio control switches
2. Front tweeter LH M109
3. AV control unit M131, M132, M133, M134, M135
4. A/C and AV switch assembly M98
5. Display unit M93
6. Front tweeter RH M111
7. Aux. jack M85
8. Front door speaker
LH D12
RH D112
9. Rear door speaker
LH D209
RH D309
10. Rear view camera D551

Component Description

INFOID:000000007347609

Part name	Description
AV control unit	<ul style="list-style-type: none">• Receives reverse signal from back-up lamp relay• Sends camera ON signal to rear view camera• Receives image signal from rear view camera• Sends camera image signal to display unit
Rear view camera	<ul style="list-style-type: none">• Receives camera ON signal from AV control unit• Sends image signal to the AV control unit
Display unit	<ul style="list-style-type: none">• Receives camera image signal from AV control unit

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[MID AUDIO]

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

AV CONTROL UNIT

AV CONTROL UNIT : Diagnosis Description

INFOID:000000007347610

DESCRIPTION


- Diagnosis function consists of the "Self-Diagnosis" mode performed automatically and the "Confirmation/Adjustment" mode operated manually.
- "Self-Diagnosis" mode checks for connections between the units constituting this system, analyzes each individual unit at the same time, and displays the results on the LCD screen.
- "Confirmation/Adjustment" mode is used to perform trouble diagnosis that requires operation and judgment by an operator (trouble that cannot be automatically judged by the system), to check/change the set value, and to display the error history of the AV control unit.

DIAGNOSIS ITEM

Mode		Description	
Self-diagnosis		<ul style="list-style-type: none"> • AV control unit diagnosis • Analyzes connection between the AV control unit, front display and switches. 	
CONFIRMATION/ ADJUSTMENT	Display diagnosis	Color spectrum bar	Color tone of the screen can be checked by the display of a color bar.
		Gradation bar	Shading of the screen can be checked by the display of a gray scale.
	Vehicle signals		The following vehicle signals are analyzed: Vehicle speed signal, parking brake signal, light signal, ignition switch signal, and reverse signal.
	Speaker test		Connection can be checked by sending a test tone to each speaker.
	Climate control		Start automatic air conditioner self-diagnosis
	Error history		Diagnosis results previously stored in the memory are displayed in this mode.
	Vehicle CAN diagnosis		The transmitting/receiving of CAN communication can be monitored.
	AV COMM diagnosis		The transmitting/receiving of AV communication can be monitored.
	Delete connection log		Erase the error history and connection history of the unit.
	Initialize settings		All audio settings are reset to default levels.

OPERATION PROCEDURE

1. Start the engine.
2. Turn the audio system off.
3. While pressing the "SETTING" button, turn the volume control dial counterclockwise 30 clicks or more.




DIAGNOSIS SYSTEM (AV CONTROL UNIT)

[MID AUDIO]

< SYSTEM DESCRIPTION >

- The initial trouble diagnosis screen will be displayed, and items “Self-Diagnosis” and “Confirmation/Adjustment” can be selected.




SELF-DIAGNOSIS

- Perform self-diagnosis by selecting “Self-Diagnosis”.
 - Self-diagnosis subdivision screen is displayed, and the self-diagnosis mode starts.
 - A bar graph visible on the center of the self-diagnosis subdivision screen indicates progress of the trouble diagnosis.


NOTE:

Self-diagnosis requires approximately 10 seconds to complete.



- Diagnosis results are displayed after the self-diagnosis is completed. The unit names and the connection lines are color-coded according to the diagnostic results.


Diagnosis results	Unit	Connection line
Normal	Green	Green
Connection malfunction	Gray	Yellow
Unit malfunction ^{Note}	Red	Green



Note:

- Only the AV control unit is displayed in red.
- If multiple malfunctions occur at the same time for a single unit, the screen switch colors are determined according to the following order of priority: red > yellow > gray.

- Select a component on the “Self Diagnosis” screen and comments for the diagnosis results will be shown.






Self-Diagnosis Results

DIAGNOSIS SYSTEM (AV CONTROL UNIT)


< SYSTEM DESCRIPTION >

[MID AUDIO]

Area with yellow connection lines	Description	Possible malfunction location / Action to take
 <p style="text-align: right; font-size: small;">AWNIA2259GB</p>	<p>AV control unit malfunction is detected</p>	<p>Replace the AV control unit. Refer to AV-114. "Removal and Installation".</p>
 <p style="text-align: right; font-size: small;">AWNIA2260GB</p>	<p>Poor connection is detected for the display unit</p>	<ul style="list-style-type: none"> • Harness or connector • AV control unit • Display unit
 <p style="text-align: right; font-size: small;">AWNIA2261GB</p>	<p>Switch malfunction is detected</p>	<p>Perform A/C and AV switch assembly diagnostics. Refer to AV-55. "A/C AND AV SWITCH ASSEMBLY : Component Function Check".</p>

CONFIRMATION/ADJUSTMENT MODE

1. Start the diagnosis function and select "Confirmation/Adjustment". The confirmation/adjustment mode indicates where each item can be checked or adjusted.
2. Select each item on the "Confirmation/Adjustment" mode screen to display the relevant trouble diagnosis screen. Press the "BACK" button or touch "BACK" on the touch screen to return to the initial Confirmation/Adjustment Mode screen.




DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >


[MID AUDIO]

Display Diagnosis



Vehicle Signals

A comparison check can be made of each actual vehicle signal and the signals recognized by the system.



Diagnosis item	Display	Vehicle status	Remarks
Vehicle speed	ON	Vehicle speed > 0 km/h	Changes in indication may be delayed by approximately 1.5 seconds. This is normal.
	OFF	Vehicle speed = 0 km/h	
	—	Ignition switch in ACC position	
Parking brake	ON	Parking brake is applied.	
	OFF	Parking brake is released.	
Lights	ON	Light switch ON	Block the light beam from the auto light optical sensor.
	OFF	Light switch OFF	
Ignition	ON	Ignition switch ON	—
	OFF	Ignition switch in ACC position	
Reverse	ON	Selector lever in R position	Changes in indication may be delayed by approximately 1.5 seconds. This is normal.
	OFF	Selector lever in any position other than R	
	—	Ignition switch in ACC position	


Speaker Test

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[MID AUDIO]

Select "Speaker Test" to display the speaker diagnosis screen. Press "Start" to generate a test tone in speakers. Touch "End" to stop the test tones.



Error History

The self-diagnosis results are judged depending on whether any error occurs from when "Self-diagnosis" is selected until the self-diagnosis results are displayed.


However, the diagnosis results are judged normal if an error has occurred before the ignition SW is turned ON and then no error has occurred until the self-diagnosis start. Check the "Error History" to detect any error that may have occurred before the self-diagnosis start because of this situation.

Count up method A

- The counter resets to 0 if an error occurs when IGN switch is turned ON. The counter increases by 1 if the condition is normal at a next IGN ON cycle.
- The counter upper limit is 39. Any counts exceeding 39 are ignored. The counter can be reset (no error-record display) with the "Delete log" switch or CONSULT.

Count up method B


- The counter increases by 1 if an error occurs when IGN switch is ON. The counter will not decrease even if the condition is normal at the next IGN ON cycle.
- The counter upper limit is 50. Any counts exceeding 50 are ignored. The counter can be reset (no error-record display) with the "Delete log" switch or CONSULT.



Display method of occurrence frequency	Error history display item
Count up method A	CAN communication line, control unit (CAN), AV communication line, control unit (AV communication)
Count up method B	Other than above

Vehicle CAN Diagnosis

- CAN communication status and error counter is displayed.
- The error counter displays "OK" if any malfunction was not detected in the past and displays "0" if a malfunction is detected. It increases by 1 if the condition is normal at the next ignition switch ON cycle. The upper limit of the counter is 39.
- The error counter is erased if reset.




AV COMM Diagnosis

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

[MID AUDIO]


< SYSTEM DESCRIPTION >

- AV communication status and error counter is displayed.
- The error counter displays “OK” if any malfunction was not detected in the past and displays “0” if a malfunction is detected. It increases by 1 if the condition is normal at the next ignition switch ON cycle. The upper limit of the counter is 39.
- The error counter is erased if reset.




Delete Unit Connection Log

Deletes any unit connection records and error records from the AV control unit memory. (Clear the records of the unit that has been removed)



Initialize Settings

Initializes the AV control unit memory.



AV CONTROL UNIT : CONSULT Function

INFOID:000000007347611

CONSULT can display each diagnostic item using the diagnostic test modes shown following.

MULTI AV diagnosis mode	Description
ECU IDENTIFICATION	The part number of AV control unit can be checked.
SELF-DIAGNOSTIC RESULT	Displays AV control unit self-diagnosis results.
DATA MONITOR	Displays AV control unit input/output data in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

DATA MONITOR

Display Item List

Display item [unit]	ALL SIGNALS	SELECTION FROM MENU	Description
VHCL SPD SIG [ON/OFF]	X	X	Displays “ON” when vehicle speed > 0 km/h. Displays “OFF” when vehicle speed = 0 km/h.
PKB SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of parking brake switch.
ILLUM SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of lighting switch.

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[MID AUDIO]

Display item [unit]	ALL SIGNALS	SELECTION FROM MENU	Description
IGN SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of ignition switch.
REV SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of back-up lamp switch.

A/C AND AV SWITCH ASSEMBLY

A/C AND AV SWITCH ASSEMBLY : Component Function Check

INFOID:000000007347612


A/C and AV switch assembly self-diagnosis function

Description

The ON/OFF operation (continuity) of each switch in the A/C and AV switch assembly can be checked.

Self-diagnosis mode

- Press the “BACK” button and the “UP” button within 10 seconds after turning the ignition switch from OFF to ACC and hold them for 3 seconds or more. When the self-diagnosis mode starts, a beep will sound and all LED indicators of the switch will illuminate.
- The continuity of each switch and control dial of the A/C and AV switch assembly can be checked. If the switch is operating normally, the system will beep and the LED's will illuminate when each switch is operated.



Finishing self-diagnosis mode

Self-diagnosis mode is canceled when the ignition switch is turned OFF.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000007347613

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-53, "CAN Communication Signal Chart"](#).

DTC Logic

INFOID:000000007347614

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
U1000	CAN COMM CIRCUIT	When AV control unit is not transmitting or receiving CAN communication signal for 2 seconds or more.	CAN communication system

Diagnosis Procedure

INFOID:000000007347615

1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" of "MULTI AV".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to "LAN system". Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).
- NO >> Refer to GI section. Refer to [GI-37, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000007347616

Initial diagnosis of AV control unit.

DTC Logic

INFOID:000000007347617

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
U1010	CONTROL UNIT (CAN)	CAN initial diagnosis malfunction is detected	AV control unit

Diagnosis Procedure

INFOID:000000007347618

1. REPLACE AV CONTROL UNIT

When DTC U1010 is detected, replace AV control unit. Refer to [AV-114. "Removal and Installation"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

U1200 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

U1200 AV CONTROL UNIT

Description

INFOID:000000007347619

Replace the AV control unit if this DTC is displayed. Refer to [AV-114. "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347620

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U1200	Control Unit FLASH- ROM [U1200]	An internal malfunction is detected in AV control unit (FLASH-ROM).	Replace AV control unit. Refer to AV-114. "Removal and Installation" .

U1216 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

U1216 AV CONTROL UNIT

Description

INFOID:000000007347621

Replace the AV control unit if this DTC is displayed. Refer to [AV-114. "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347622

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U1216	CAN CONT [U1216]	Internal malfunction of AV control unit (CAN controller) is detected.	Replace AV control unit. Refer to AV-114. "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

U1240 SWITCH CONN

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

U1240 SWITCH CONN

Description

INFOID:000000007347623

U1240 is indicated when malfunction occurs in communication signal of multi AV system. Indicated simultaneously, without fail, with the malfunction of control units connected to AV control unit with communication line. Determine the possible malfunction cause from the table below.

Self-diagnosis results display item

DTC	Display contents of CONSULT	DTC Detection Condition	Possible causes
U1240	<ul style="list-style-type: none">SWITCH CONN [U1240]	<ul style="list-style-type: none">A/C and AV switch assembly power supply and ground circuit malfunction is detectedA malfunction is detected in communication circuit between AV control unit and A/C and AV switch assemblyA malfunction is detected in communication signal between AV control unit and A/C and AV switch assembly	<ul style="list-style-type: none">A/C and AV switch assembly power supply and ground circuitsCommunication circuit between AV control unit and A/C and AV switch assembly

U1243 DISPLAY UNIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

U1243 DISPLAY UNIT

Description

INFOID:000000007347624

Part name	Description
DISPLAY UNIT	<ul style="list-style-type: none"> • Display image is controlled by the serial communication from AV control unit. • Inputs the RGB image signal (RGB, RGB area and RGB synchronizing) from AV control unit and the auxiliary image signal from the auxiliary input jacks. • Outputs the synchronizing signals (HP and VP) to the AV control unit.

DTC Logic

INFOID:000000007347625

DTC	Display contents of CONSULT	DTC Detection Condition	Possible causes
U1243	FRONT DISP CONN [U1243]	<ul style="list-style-type: none"> • Display unit power supply and ground circuit malfunction is detected • Malfunction is detected on communication circuit between display unit and AV control unit • Malfunction is detected on communication signal between display unit and AV control unit 	<ul style="list-style-type: none"> • Display unit power supply and ground circuit • Communication circuit between display unit and AV control unit

Diagnosis Procedure

INFOID:000000007347626

Regarding Wiring Diagram information, refer to [AV-95. "Wiring Diagram"](#).

1. CHECK DISPLAY UNIT POWER SUPPLY AND GROUND CIRCUIT

Check display unit power supply and ground circuit. Refer to [AV-66. "DISPLAY UNIT : Diagnosis Procedure"](#).

Is inspection result OK?


YES >> GO TO 2

NO >> Repair malfunctioning parts.

2. CHECK CONTINUITY OF COMMUNICATION CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector and AV control unit connector.
3. Check continuity between display unit harness connector M93 (A) terminals 11, 22 and AV control unit harness connector M133 (B) terminals 56, 44.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	11	M133	56	Yes
	22		44	



4. Check continuity between display unit harness connector M93 (A) terminals 11, 22 and ground.

A		—	Continuity
Connector	Terminal		
M93	11	Ground	No
	22		

Are continuity results as specified?

YES >> GO TO 3

U1243 DISPLAY UNIT

[MID AUDIO]


< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair harness or connector.

3. CHECK COMMUNICATION SIGNAL

1. Connect display unit connector and AV control unit connector.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 11 and ground with an oscilloscope or CONSULT.

(+)		(-)	Reference signal
Connector	Terminal		
M93	11	Ground	



Are voltage readings as specified?


YES >> GO TO 4

NO >> Replace AV control unit. Refer to [AV-114. "Removal and Installation"](#).

4. CHECK COMMUNICATION SIGNAL

Check signal between display unit harness connector M93 terminal 22 and ground with an oscilloscope or CONSULT.

(+)		(-)	Reference signal
Connector	Terminal		
M93	22	Ground	



Are voltage readings as specified?

YES >> Inspection End.

NO >> Replace display unit. Refer to [AV-116. "Removal and Installation"](#).

U1300 AV COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

U1300 AV COMM CIRCUIT

Description

INFOID:000000007347627

U1300 is indicated when malfunction occurs in communication signal of multi AV system. Indicated simultaneously, without fail, with the malfunction of control units connected to AV control unit with communication line. Determine the possible malfunction cause from the table below.

Self-diagnosis results display item

DTC	Display contents of CONSULT	DTC Detection Condition	Possible causes
U1300 U1240	<ul style="list-style-type: none">AV COMM CIRCUIT [U1300]SWITCH CONN [U1240]	<ul style="list-style-type: none">A/C and AV switch assembly power supply and ground circuit malfunction is detectedA malfunction is detected in communication circuit between AV control unit and A/C and AV switch assemblyA malfunction is detected in communication signal between AV control unit and A/C and AV switch assembly	<ul style="list-style-type: none">A/C and AV switch assembly power supply and ground circuitsCommunication circuit between AV control unit and A/C and AV switch assembly

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

U1310 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

U1310 AV CONTROL UNIT

Description

INFOID:000000007347628

Replace the AV control unit if this DTC is displayed. Refer to [AV-114. "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347629

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U1310	CONTROL UNIT (AV) [U1310]	An initial diagnosis error is detected in AV communication circuit.	Replace AV control unit. Refer to AV-114. "Removal and Installation" .

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

POWER SUPPLY AND GROUND CIRCUIT

AV CONTROL UNIT

AV CONTROL UNIT : Diagnosis Procedure

INFOID:000000007347630

Regarding Wiring Diagram information, refer to [AV-95. "Wiring Diagram"](#).

1. CHECK FUSES

Check that the following fuses of the AV control unit are not are not blown.

Unit	Terminals	Signal name	Fuse No.
AV control unit	19	Battery power	29
	7	Ignition switch ACC or ON	4
	104	Ignition switch ON or START	12

Are the fuses OK?

YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. POWER SUPPLY CIRCUIT CHECK


- Disconnect AV control unit connectors M131 and M135.
- Check voltage between the AV control unit connectors M131 and M135 and ground.

Connector	(+)		(-)	OFF	ACC	ON
	Terminal					
M131	7	Ground	0V	Battery voltage	Battery voltage	
	19	Ground	Battery voltage	Battery voltage	Battery voltage	
M135	104	Ground	0V	0V	Battery voltage	

Are the voltage results as specified?

YES >> GO TO 3

- NO >>
- Check connector housings for disconnected or loose terminals.
 - Repair harness or connector.



3. GROUND CIRCUIT CHECK

- Turn ignition switch OFF.
- Check continuity between AV control unit harness connectors M131, M133, M134, M135 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

(+)		(-)	Continuity
Connector	Terminal		
M131	20	Ground	Yes
M133	54		
M134	68		
M135	85		

Are the continuity results as specified?

- YES >> Inspection End.
- NO >> Repair AV control unit ground.

DISPLAY UNIT

DISPLAY UNIT : Diagnosis Procedure

INFOID:000000007347631

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).


1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch to ACC.
2. Check voltage between display unit harness connector M93 and ground.

Signal name	Connector	Terminal	Ignition switch position	Value (Approx.)
Inverter VCC	M93	2	ACC	9V
Signal VCC		3		

Does specified voltage exist?


- YES >> GO TO 3
- NO >> GO TO 2



2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the display unit connector M93 and the AV control unit connector M133.
3. Check continuity between the display unit harness connector M93 (A) and the AV control unit connector M133 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	2	M133	59	Yes
	3		47	



4. Check continuity between the display unit harness connector M93 (A) and ground.

A		—	Continuity
Connector	Terminal		
M93	2	Ground	No
	3		

Are continuity results as specified?

- YES >> Check AV control unit power and ground supply. Refer to [AV-65, "AV CONTROL UNIT : Diagnosis Procedure"](#).
- NO >> Repair harness or connector.

POWER SUPPLY AND GROUND CIRCUIT

[MID AUDIO]

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector.
3. Check continuity between display unit harness connector and ground.

Connector	Terminal	—	Continuity
M93	1	Ground	Yes

Does continuity exist?

- YES >> Inspection End.
 NO >> Repair harness or connector.

A/C AND AV SWITCH ASSEMBLY

A/C AND AV SWITCH ASSEMBLY : Diagnosis Procedure

INFOID:000000007347632

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).

1. CHECK FUSE

Check that the fuse of the AC and AV switch assembly is not blown.

Unit	Terminal	Signal name	Fuse No.
A/C and AV switch assembly	2	Ignition switch ACC or ON	4

Is the fuse OK?

- YES >> GO TO 2
 NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. POWER SUPPLY CIRCUIT CHECK



1. Disconnect A/C and AV switch assembly connector M98.
2. Check voltage between the A/C and AV switch assembly connector M98 and ground.

(+)		(-)	OFF	ACC	ON
Connector	Terminal				
M98	2	Ground	0V	Battery voltage	Battery voltage

Are the voltage results as specified?

- YES >> GO TO 3
 NO >> • Check connector housings for disconnected or loose terminals.
 • Repair harness or connector.

3. GROUND CIRCUIT CHECK



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

POWER SUPPLY AND GROUND CIRCUIT

[MID AUDIO]


< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Check continuity between A/C and AV switch assembly harness connector M98 and ground.

Connector	Terminal	—	Continuity
M98	1	Ground	Yes

Are the continuity results as specified?

- YES >> Inspection End.
 NO >> Repair harness or ground.



REAR VIEW CAMERA

REAR VIEW CAMERA : Diagnosis Procedure

INFOID:000000007347633

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).

1. CHECK POWER SUPPLY CIRCUIT (REAR VIEW CAMERA SIDE)

NOTE:

Apply parking brakes before proceeding.

1. Turn ignition switch ON.
2. Shift transmission into reverse.
3. Check voltage between rear view camera harness connector D551 terminal 2 and ground.

(+)		(-)	Transmission position	Value (Approx.)
Connector	Terminal			
D551	2	Ground	Reverse	12V

Is voltage reading approximately 12 volts?

- YES >> GO TO 4.
 NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT (CONTINUITY)

1. Turn ignition switch OFF.
2. Disconnect rear view camera and AV control unit connectors.
3. Check continuity between rear view camera harness connector D551 terminal 2 and AV control unit harness connector M134 terminal 105.

Connector	Terminal	Connector	Terminal	Continuity
D551	2	M134	105	Yes

4. Check continuity between rear view camera harness connector D551 terminal 2 and ground.

Connector	Terminal	—	Continuity
D551	2	Ground	No

Are continuity test results as specified?

- YES >> GO TO 3.
 NO >> Repair harness or connector.

3. CHECK REVERSE POSITION INPUT SIGNAL

1. Turn ignition switch ON.
2. Shift transmission into reverse.
3. Check voltage between AV control unit harness connector M134 terminal 105 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

(+)		(-)	Transmission position	Value (Approx.)
Connector	Terminal			
M134	105	Ground	Reverse	12V

Is voltage reading approximately 12 volts?

- YES >> Replace AV control unit. Refer to [AV-114, "Removal and Installation"](#).
NO >> Check harness for open or short between AV control unit and back-up lamp relay.

4.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear view camera harness connector.
3. Check continuity between rear view camera harness connector D551 terminal 1 and ground.

Connector	Terminal	—	Continuity
D551	1	Ground	Yes

Does continuity exist?

- YES >> Inspection End.
NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

RGB (R: RED) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

RGB (R: RED) SIGNAL CIRCUIT

Description

INFOID:000000007347634

Transmit the image displayed with AV control unit with RGB signal to the display unit.

Diagnosis Procedure

INFOID:000000007347635

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).

1. CHECK CONTINUITY RGB (R: RED) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M133.
3. Check continuity between display unit harness connector M93 (A) terminal 17 and AV control unit harness connector M133 (B) terminal 40.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	17	M133	40	Yes

4. Check continuity between display unit harness connector M93 (A) terminal 17 and ground.


A		—	Continuity
Connector	Terminal		
M93	17	Ground	No

Are the continuity results as specified?

- YES >> GO TO 2
 NO >> Repair harness or connector.



2. CHECK RGB (R: RED) SIGNAL

1. Connect display unit connector M93 and AV control unit connector M133.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 17 and ground.

(+)		(-)	Condition	Reference signal
Connector	Terminal			
M93	17	Ground	Receive audio signal	 <p>SKIB2238J</p>

Are the voltage readings as specified?

- YES >> Replace display unit. Refer to [AV-116, "Removal and Installation"](#).
 NO >> Replace AV control unit. Refer to [AV-114, "Removal and Installation"](#).



RGB (G: GREEN) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

RGB (G: GREEN) SIGNAL CIRCUIT

Description

INFOID:000000007347636

Transmit the image displayed with AV control unit with RGB signal to the display unit.


Diagnosis Procedure

INFOID:000000007347637

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).

1. CHECK CONTINUITY RGB (G: GREEN) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M133.
3. Check continuity between display unit harness connector M93 (A) terminal 6 and AV control unit harness connector M133 (B) terminal 39.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	6	M133	39	Yes

4. Check continuity between display unit harness connector M93 (A) terminal 6 and ground.

A		—	Continuity
Connector	Terminal		
M93	6	Ground	No


Are the continuity results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK RGB (G: GREEN) SIGNAL

1. Connect display unit connector M93 and AV control unit connector M133.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 6 and ground.



(+)		(-)	Condition	Reference signal
Connector	Terminal			
M93	6	Ground	Receive audio signal	<p>SK1B2236J</p>

Are voltage readings as specified?

YES >> Replace display unit. Refer to [AV-116, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-114, "Removal and Installation"](#).

RGB (B: BLUE) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

RGB (B: BLUE) SIGNAL CIRCUIT

Description

INFOID:000000007347638

Transmit the image displayed with AV control unit with RGB signal to the display unit.

Diagnosis Procedure

INFOID:000000007347639

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).

1. CHECK CONTINUITY RGB (B: BLUE) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M133.
3. Check continuity between display unit harness connector M93 (A) terminal 18 and AV control unit harness connector M133 (B) terminal 38.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	18	M133	38	Yes

4. Check continuity between display unit harness connector M93 (A) terminal 18 and ground.


A		—	Continuity
Connector	Terminal		
M93	18	Ground	No

Are continuity results as specified?

- YES >> GO TO 2
 NO >> Repair harness or connector.



2. CHECK RGB (B: BLUE) SIGNAL

1. Connect display unit connector M93 and AV control unit connector M133.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 18 and ground.

(+)		(-)	Condition	Reference signal
Connector	Terminal			
M93	18	Ground	Receive audio signal	 <p>SKIB2237J</p>

Are voltage readings as specified?

- YES >> Replace display unit. Refer to [AV-116, "Removal and Installation"](#).
 NO >> Replace AV control unit. Refer to [AV-114, "Removal and Installation"](#).



RGB SYNCHRONIZING SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

RGB SYNCHRONIZING SIGNAL CIRCUIT

Description

INFOID:000000007347640

Transmit the RGB synchronizing signal to the display unit so as to synchronize the RGB image displayed with AV control unit.


Diagnosis Procedure

INFOID:000000007347641

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).

1. CHECK CONTINUITY RGB SYNCHRONIZING SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M133.
3. Check continuity between display unit harness connector M93 (A) terminal 19 and AV control unit harness connector M133 (B) terminal 41.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	19	M133	41	Yes

4. Check continuity between display unit harness connector M93 (A) terminal 19 and ground.

A		—	Continuity
Connector	Terminal		
M93	19	Ground	No


Are continuity results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK RGB SYNCHRONIZING SIGNAL

1. Connect display unit connector M93 and AV control unit connector M133.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 19 and ground.



(+)		(-)	Condition	Reference signal
Connector	Terminal			
M93	19	Ground	Receive audio signal	

Are voltage readings as specified?

YES >> Replace display unit. Refer to [AV-116, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-114, "Removal and Installation"](#).

RGB AREA (YS) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

RGB AREA (YS) SIGNAL CIRCUIT

Description

INFOID:000000007347642

Transmits the display area of RGB image displayed by AV control unit with RGB area (YS) signal to display unit.


Diagnosis Procedure

INFOID:000000007347643

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).

1. CHECK CONTINUITY RGB AREA (YS) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M133.
3. Check continuity between display unit harness connector M93 (A) terminal 9 and AV control unit harness connector M133 (B) terminal 43.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	9	M133	43	Yes

4. Check continuity between display unit harness connector M93 (A) terminal 9 and ground.

A		—	Continuity
Connector	Terminal		
M93	9	Ground	No


Are continuity results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK RGB SYNCHRONIZING SIGNAL

1. Connect display unit connector M93 and AV control unit connector M133.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 9 and ground.



(+)		(-)	Condition	Reference signal
Connector	Terminal			
M93	9	Ground	Receive audio signal	<p style="text-align: right; font-size: small;">PKIB4948J</p>

Are voltage readings as specified?

YES >> Replace display unit. Refer to [AV-116, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-114, "Removal and Installation"](#).

HORIZONTAL SYNCHRONIZING (HP) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

HORIZONTAL SYNCHRONIZING (HP) SIGNAL CIRCUIT

Description

INFOID:000000007347644

In composite image (AUX image, camera image), transmit the vertical synchronizing (VP) signal and horizontal synchronizing (HP) signal from display unit to AV control unit so as to synchronize the RGB images displayed with AV control unit such as the image quality adjusting menu, etc.


Diagnosis Procedure

INFOID:000000007347645

Regarding Wiring Diagram information, refer to [AV-95. "Wiring Diagram"](#).

1. CHECK CONTINUITY HORIZONTAL SYNCHRONIZING (HP) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M133.
3. Check continuity between display unit harness connector M93 (A) terminal 8 and AV control unit harness connector M133 (B) terminal 45.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	8	M133	45	Yes

4. Check continuity between display unit harness connector M93 (A) terminal 8 and ground.

A		—	Continuity
Connector	Terminal		
M93	8	Ground	No


Are continuity results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK HORIZONTAL SYNCHRONIZING (HP) SIGNAL

1. Connect display unit connector M93 and AV control unit connector M133.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 8 and ground.



(+) Connector		(-)	Condition	Reference signal
Connector	Terminal			
M93	8	Ground	Receive audio signal	<p>SK1B3601E</p>

Are voltage readings as specified?

YES >> Replace AV control unit. Refer to [AV-114. "Removal and Installation"](#).

NO >> Replace display unit. Refer to [AV-116. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

VERTICAL SYNCHRONIZING (VP) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

VERTICAL SYNCHRONIZING (VP) SIGNAL CIRCUIT

Description

INFOID:000000007347646

In composite image (AUX image, camera image), transmit the vertical synchronizing (VP) signal and horizontal synchronizing (HP) signal from display unit to AV control unit so as to synchronize the RGB images displayed with AV control unit such as the image quality adjusting menu, etc.


Diagnosis Procedure

INFOID:000000007347647

Regarding Wiring Diagram information, refer to [AV-95. "Wiring Diagram"](#).

1. CHECK CONTINUITY VERTICAL SYNCHRONIZING (VP) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M133.
3. Check continuity between display unit harness connector M93 (A) terminal 20 and AV control unit harness connector M133 (B) terminal 57.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	20	M133	57	Yes

4. Check continuity between display unit harness connector M93 (A) terminal 20 and ground.


A		—	Continuity
Connector	Terminal		
M93	20	Ground	No

Are continuity results as specified?

- YES >> GO TO 2
 NO >> Repair harness or connector.

2. CHECK VERTICAL SYNCHRONIZING (VP) SIGNAL

1. Connect display unit connector M93 and AV control unit connector M133.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 20 and ground.



(+) Connector		(-) Terminal	Condition	Reference signal
M93	20	Ground	Receive audio signal	<p>SKIB3598E</p>

Are voltage readings as specified?

- YES >> Replace AV control unit. Refer to [AV-114. "Removal and Installation"](#).
 NO >> Replace display unit. Refer to [AV-116. "Removal and Installation"](#).

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

FRONT DOOR SPEAKER

Description

INFOID:000000007347648

The AV control unit sends audio signals to the front door speakers using the front door speaker circuits.

Diagnosis Procedure

INFOID:000000007347649

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).

1. CONNECTOR CHECK

Check the AV control unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. HARNESS CHECK

1. Disconnect AV control unit connector M131 and suspect speaker connector.
2. Check continuity between AV control unit harness connector M131 (A) terminal and suspect speaker harness connector (B) terminal.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M131	2	D12	1	Yes
	3		2	
	11	D112	1	
	12		2	

3. Check continuity between AV control unit harness connector M131 (A) terminal and ground.


A		—	Continuity
Connector	Terminal		
M131	2	Ground	No
	3		
	11		
	12		

Are continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3. FRONT SPEAKER SIGNAL CHECK




FRONT DOOR SPEAKER

[MID AUDIO]


< DTC/CIRCUIT DIAGNOSIS >

1. Connect AV control unit connector M131 and front speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M131 terminals with CONSULT or oscilloscope.

Con- nec- tor	(+)		(-)		Condi- tion	Reference signal
	Termi- nal	Termi- nal	Termi- nal	Termi- nal		
M131	2	3	11	12	Receive audio signal	 <p style="text-align: center; font-size: small;">SKIA0177E</p>
	11	12				

Is the audio signal voltage as specified?

- YES >> Replace speaker. Refer to [AV-118, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-114, "Removal and Installation"](#).



FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

FRONT TWEETER

Description

INFOID:000000007347650

The AV control unit sends audio signals to the front tweeters using the front tweeter circuits.

Diagnosis Procedure

INFOID:000000007347651

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).

1.CONNECTOR CHECK

Check the AV control unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.


2.HARNES CHECK

1. Disconnect AV control unit connector M131 and suspect front tweeter connector.
2. Check continuity between AV control unit harness connector M131 (A) and suspect front tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M131	2	M109	1	Yes
	3		2	
	11	M111	1	
	12		2	

3. Check continuity between AV control unit harness connector M131 (A) and ground.

A		—	Continuity
Connector	Terminal		
M131	2	Ground	No
	3		
	11		
	12		



Are the continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.


3.FRONT TWEETER SIGNAL CHECK

FRONT TWEETER

[MID AUDIO]


< DTC/CIRCUIT DIAGNOSIS >

1. Connect AV control unit connector M131 and front tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M131 terminals with CONSULT or oscilloscope.

(+)		(-)		Condi- tion	Reference signal
Connector	Terminal	Terminal	Terminal		
M131	2	3	11	12	 <p>SKIA0177E</p>
	11	12			

Is the audio signal voltage as specified?

- YES >> Replace the suspect front tweeter. Refer to [AV-117, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-114, "Removal and Installation"](#).



REAR DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

REAR DOOR SPEAKER

Description

INFOID:000000007347652

The AV control unit sends audio signals to the rear speakers using the rear speaker circuits.

Diagnosis Procedure

INFOID:000000007347653

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).

1. CONNECTOR CHECK

Check the AV control unit and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.


2. HARNESS CHECK

1. Disconnect AV control unit connector M131 and suspect rear speaker connector.
2. Check continuity between AV control unit harness connector M131 (A) and suspect rear speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M131	4	D209	1	Yes
	5		2	
	13	D309	1	
	14		2	

3. Check continuity between AV control unit harness connector M131 (A) and ground.

A		—	Continuity
Connector	Terminal		
M131	4	Ground	No
	5		
	13		
	14		



Are the continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.


3. REAR SPEAKER SIGNAL CHECK

REAR DOOR SPEAKER

[MID AUDIO]


< DTC/CIRCUIT DIAGNOSIS >

1. Connect AV control unit connector and rear speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M131 terminals with CONSULT or oscilloscope.

(+)		(-)		Condition	Reference signal
Connector	Terminal	Terminal	Terminal		
M131	4	5	14	Receive audio signal	 <p>(V)</p> <p>1</p> <p>0</p> <p>-1</p> <p>1 ms</p> <p>SKIA0177E</p>
	13	14			

Is the audio signal voltage as specified?

- YES >> Replace the suspect rear door speaker. Refer to [AV-119, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-114, "Removal and Installation"](#).



STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

STEERING SWITCH

Description

INFOID:000000007347654

When one of the steering wheel AV control switches is pushed, the resistance in the steering wheel AV control switch circuit changes depending on which button is pushed.

Diagnosis Procedure


INFOID:000000007347655

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).

1. CHECK STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE

1. Disconnect steering wheel audio control switch connector M102.
2. Check resistance between steering switch connector terminals.

Terminal	Signal name	Condition	Resistance (Ω) (Approx.)	
16	17	Seek (down)	Depress ▽ switch.	165
		Volume (down)	Depress VOL down switch.	652
		Power	Depress PWR switch.	0
20	17	Seek (up)	Depress △ switch.	165
		Volume (up)	Depress VOL up switch.	652
		Mode	Depress MODE switch.	0



Do the steering wheel audio control switches check OK?


YES >> GO TO 2

NO >> Replace steering wheel audio control switch. Refer to [AV-120, "Removal and Installation"](#).

2. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M131 and spiral cable connector M30.
3. Check continuity between AV control unit harness connector M131 (A) and spiral cable harness connector M30 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M131	6	M30	24	Yes
	15		31	
	16		32	



4. Check continuity between AV control unit connector 1312 (A) and ground.

A		—	Continuity
Connector	Terminal		
M131	6	Ground	No
	15		
	16		

Are the continuity results as specified?

YES >> GO TO 3

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

STEERING SWITCH

[MID AUDIO]


< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair harness.

3. SPIRAL CABLE CHECK

1. Disconnect spiral cable connector M102.
2. Check continuity between spiral cable harness connector M30 (A) and M102 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M30	24	M102	20	Yes
	31		17	
	32		16	



Is continuity present?

YES >> Inspection End.

NO >> Replace spiral cable. Refer to [SR-7, "Removal and Installation"](#).

REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[MID AUDIO]

REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

Description

INFOID:000000007347656

Rear view camera signals are transmitted from the rear view camera to the AV control unit using the camera signal circuits.

Diagnosis Procedure

INFOID:000000007347657

Regarding Wiring Diagram information, refer to [AV-95, "Wiring Diagram"](#).

1. CHECK CAMERA IMAGE SIGNAL CIRCUIT CONTINUITY

NOTE:

Apply parking brakes before proceeding.

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M134 and rear view camera connector D551.
3. Check continuity between AV control unit harness connector M134 terminals 64, 65, 72 and rear view camera harness connector D551 terminals 3, 5 and 6.

64 - 5 : Continuity should exist.

65 - 6 : Continuity should exist.

72 - 3 : Continuity should exist.

4. Check continuity between AV control unit harness connector M134 terminals 64, 65, 72 and ground.

64, 65, 72 - Ground : Continuity should not exist.

Is inspection result OK?


YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK CAMERA IMAGE SIGNAL

1. Connect AV control unit connector M134 and rear view camera connector D551.
2. Turn ignition switch ON.
3. Shift transmission into reverse.
4. Check signal between AV control unit harness connector M134 terminals 64 and 65.

64 - 65 :



SKIB2251J

Is inspection result OK?

YES >> Replace AV control unit. Refer to [AV-114, "Removal and Installation"](#).

NO >> Replace rear view camera. Refer to [AV-125, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MID AUDIO]

ECU DIAGNOSIS INFORMATION

AV CONTROL UNIT

Reference Value


INFOID:000000007347658

VALUES ON THE DIAGNOSIS TOOL

CONSULT data monitor item

Display Item	Display	Vehicle status	Remarks
VHCL SPD SIG	ON	Vehicle speed >0 km/h (0 MPH)	Changes in indication may be delayed. This is normal.
	OFF	Vehicle speed =0 km/h (0 MPH)	
PKB SIG	ON	Parking brake is applied.	Changes in indication may be delayed. This is normal.
	OFF	Parking brake is released.	
ILLUM SIG	ON	Block the light beam from the auto light optical sensor when the light SW is ON .	—
	OFF	Expose the auto light optical sensor to light when the light SW is OFF or ON.	
IGN SIG	ON	Ignition switch ON	—
	OFF	Ignition switch in ACC position	
REV SIG	ON	Selector lever in R position	Changes in indication may be delayed. This is normal.
	OFF	Selector lever in any position other than R	

TERMINAL LAYOUT







PHYSICAL VALUES

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MID AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
2 (BR)	3 (L)	Sound signal front door speaker and front tweeter LH	Output	Ignition switch ON	Audio output	 <small>SKIB3609E</small>
4 (G)	5 (B)	Sound signal rear door speaker and rear tweeter LH	Output	Ignition switch ON	Audio output	 <small>SKIB3609E</small>
6 (Y)	15 (L)	Steering switch signal A	Input	Ignition switch ON	Press and hold MODE switch.	0V
					Press and hold Δ switch.	0.75V
					Press and hold VOL up switch	2V
					Except for above.	5V
7 (G/Y)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
9 (V)	Ground	Illumination signal	Input	OFF	Lighting switch is OFF.	0V
					Lighting switch is ON.	Battery voltage
11 (LG)	12 (R)	Sound signal front door speaker and front tweeter RH	Output	Ignition switch ON	Voice output	 <small>SKIB3609E</small>
13 (GR)	14 (O)	Sound signal rear door speaker and rear tweeter RH	Output	Ignition switch ON	Voice output	 <small>SKIB3609E</small>
15 (L)	Ground	Steering switch signal GND	—	Ignition switch ON	—	0V





A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >






[MID AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
16 (G)	15 (L)	Steering switch signal B	Input	Ignition switch ON	Press and hold POWER switch	0V
					Press and hold ∇ switch	0.75V
					Press and hold VOL down switch	2V
					Except for above	5V
19 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
20 (B)	Ground	Ground	—	Ignition switch ON	—	0V
34	—	Antenna main	—	—	—	—
35	—	Antenna power	Output	Ignition switch ON	With AM/FM radio selected	12V
36 (G)	Ground	AUX image signal	Output	Ignition switch ON	When AUX mode is selected	 <small>SKIB2251J</small>
37 (R)	Ground	AUX image ground	—	Ignition switch ON	—	0V
38 (R)	Ground	RGB signal (B: blue)	Output	Ignition switch ON	Start confirmation/adjustment mode, and then display color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.	 <small>SKIB2237J</small>
39 (B)	Ground	RGB signal (G: green)	Output	Ignition switch ON	Start confirmation/adjustment mode, and then display color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.	 <small>SKIB2236J</small>
40 (W)	Ground	RGB signal (R: red)	Output	Ignition switch ON	Start confirmation/adjustment mode, and then display color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.	 <small>SKIB2238J</small>

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MID AUDIO]




Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
41 (R)	Ground	RGB synchronizing signal	Output	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">SKIB3603E</p>
42	—	RGB synchronizing ground	—	Ignition switch ON	—	0V
43 (G)	Ground	RGB area (YS) signal	Output	Ignition switch ON	RGB image	5V
					AUX image	 <p style="text-align: right; font-size: small;">PKIB4948J</p>
44 (LG)	Ground	Communication signal (DISP→CONT)	Input	Ignition switch ON	When adjusting display brightness	 <p style="text-align: right; font-size: small;">PKIB5039J</p>
45 (B)	Ground	Horizontal synchronizing (HP) signal	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">SKIB3601E</p>
46 (BR)	Ground	Signal ground	—	Ignition switch	—	0V
47 (R)	Ground	Signal VCC	Output	Ignition switch ACC	—	9V
54 (B)	Ground	Ground	—	Ignition switch ON	—	0V
56 (V)	Ground	Communication signal (CONT→DISP)	Output	Ignition switch ON	When adjusting display brightness	 <p style="text-align: right; font-size: small;">PKIB5039J</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >



[MID AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
57 (W)	Ground	Vertical synchronizing (VP) signal	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">SKIB3598E</p>
58 (SB)	Ground	Inverter ground	—	Ignition switch ON	—	0V
59 (O)	Ground	Inverter VCC	Output	Ignition switch ACC	—	9V
64 (W)	Ground	Rear view camera video signal ground	—	Ignition switch ON	—	0V
65 (B)	Ground	Rear view camera video in (+)	Input	Ignition switch ON	With rear view camera ON	 <p style="text-align: right; font-size: small;">SKIB2251J</p>
68 (B)	Ground	Rear view camera signal (ground)	—	Ignition switch ON	—	0V
72	—	Shield	—	—	—	—
85 (B)	Ground	Ground	—	Ignition switch ON	—	0V
86 (L)	—	CAN-H	Input/ Output	—	—	—
87 (P)	—	CAN-L	Input/ Output	—	—	—
88 (L)	—	AV communication signal 1 (H)	Input/ Output	—	—	—
89 (P)	—	AV communication signal 1 (L)	Input/ Output	—	—	—
90 (L)	—	AV communication signal 2 (H)	Input/ Output	—	—	—
91 (P)	—	AV communication signal 2 (L)	Input/ Output	—	—	—
95 (W)	97 (R)	AUX audio signal RH	Input	Ignition switch ON	When AUX mode is selected	 <p style="text-align: right; font-size: small;">SKIB3609E</p>

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[MID AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
96 (B)	97 (R)	AUX audio signal LH	Input	Ignition switch ON	When AUX mode is select- ed	
101 (GR)	Ground	A/C and AV switch assem- bly ground	—	Ignition switch ON	—	0V
103 (SB)	Ground	CD eject signal	Input	—	Pressing the eject switch	0V
					Except for above	3.3V
104 (W/G)	Ground	Ignition signal	Input	Ignition switch ON	—	Battery voltage
105 (W)	Ground	Reverse signal	Input	Ignition switch ON	R position	Battery voltage
					Other than R position	0V
106 (G)	Ground	Parking brake signal	Input	Ignition switch ON	Parking brake ON	0V
					Parking brake OFF	Battery voltage
107 (LG)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	When vehicle speed is ap- prox. 40 km/h (25MPH)	

DTC Index

INFOID:000000007347659

Self-diagnosis results display item

Error item	Refer to
CAN COMM CIRCUIT [U1000]	AV-56, "DTC Logic"
CONTROL UNIT (CAN) [U1010]	AV-57, "DTC Logic"
Control Unit FLASH-ROM [U1200]	AV-58, "DTC Logic"
CAN CONT [U1216]	AV-59, "DTC Logic"
SWITCH CONN [U1240]	AV-60, "Description"
FRONT DISP CONN [U1243]	AV-61, "DTC Logic"
AV COMM CIRCUIT [U1300]	AV-63, "Description"
CONTROL UNIT (AV) [U1310]	AV-64, "DTC Logic"

AV

DISPLAY UNIT

< ECU DIAGNOSIS INFORMATION >


[MID AUDIO]

DISPLAY UNIT

Reference Value

INFOID:000000007347660

TERMINAL LAYOUT








PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
1 (B)	Ground	Ground	—	Ignition switch ON	—	0V
2 (O)	Ground	Inverter VCC	Input	Ignition switch ACC	—	9V
3 (R)	Ground	Signal VCC	Input	Ignition switch ACC	—	9V
4 (R)	Ground	AUX image ground	—	Ignition switch ON	—	0V
6 (B)	Ground	RGB signal (G: green)	Input	Ignition switch ON	Start confirmation/adjust- ment mode, and then dis- play color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNO- SIS screen.	<p>SKIB2236J</p>
8 (B)	Ground	Horizontal synchronizing (HP) signal	Output	Ignition switch ON	—	<p>SKIB3601E</p>

DISPLAY UNIT

< ECU DIAGNOSIS INFORMATION >

[MID AUDIO]



Terminal (Wire color)		Description		Condition	Reference value (Approx.)
+	-	Signal name	Input/ Output		
9 (G)	Ground	RGB area (YS) signal	Input	Ignition switch ON	At RGB image displayed 5V
				Ignition switch ON	At rear view camera image displayed  PKIB4948J
11 (V)	Ground	Communication signal (CONT→DISP)	Input	Ignition switch ON	When adjusting display-brightness  PKIB5039J
13 (SB)	Ground	Inverter ground	—	Ignition switch ON	— 0V
14 (BR)	Ground	Signal ground	—	Ignition switch ON	— 0V
15 (G)	—	AUX image synchronizing signal	Input	—	—
17 (W)	Ground	RGB signal (R: red)	Input	Ignition switch ON	Start confirmation/adjustment mode, and then display color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.  SKIB2238J
18 (R)	Ground	RGB signal (B: blue)	Input	Ignition switch ON	Start confirmation/adjustment mode, and then display color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.  SKIB2237J
19 (R)	Ground	RGB synchronizing signal	Input	Ignition switch ON	—  SKIB3603E

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

DISPLAY UNIT

< ECU DIAGNOSIS INFORMATION >

[MID AUDIO]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
20 (W)	Ground	Vertical synchronizing (VP) signal	Output	Ignition switch On	—	 <p style="text-align: right; font-size: small;">SKIB3598E</p>
22 (LG)	Ground	Communication signal (DISP→CONT)	Output	Ignition switch ON	When adjusting display- brightness	 <p style="text-align: right; font-size: small;">PKIB5039J</p>

MID AUDIO SYSTEM

[MID AUDIO]


< WIRING DIAGRAM >

WIRING DIAGRAM

MID AUDIO SYSTEM

Wiring Diagram

INFOID:000000007347661



*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

ABNWA1039GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

MID AUDIO SYSTEM

< WIRING DIAGRAM >

[MID AUDIO]




ABNWA1344GB

MID AUDIO SYSTEM

< WIRING DIAGRAM >

[MID AUDIO]



*: THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

ABNWA1334GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV


MID AUDIO SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2P	W/G	-
4P	G/B	-

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	L	-
3	BR	-(WITHOUT BOSE AUDIO SYSTEM)

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	LG	SPEED OUT 8

Connector No.	M30
Connector Name	COMBINATION SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
24	Y	STRG SW A (UP)
31	L	GND
32	G	STRG SW B (DOWN)

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
54G	SB	-
77G	Y	-

MID AUDIO SYSTEM

< WIRING DIAGRAM >

[MID AUDIO]


Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3J	G	– (WITHOUT BOSE AUDIO SYSTEM)
8J	B	– (WITHOUT BOSE AUDIO SYSTEM)

Terminal No.	Color of Wire	Signal Name
5M	SHIELD	–
8M	B	–
9M	W	–
65M	G/Y	–
71M	GR	–
72M	O	–

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M85
Connector Name	AUX IN JACK
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	AUX AUDIO RH+
2	R	AUX GND
4	B	AUX AUDIO LH+

Connector No.	M78
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	–	–
3	–	–

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R	–
11	LG	– (WITHOUT BOSE AUDIO SYSTEM)

ABNIA33334GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

MID AUDIO SYSTEM

< WIRING DIAGRAM >


[MID AUDIO]

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-


Connector No.	M93
Connector Name	DISPLAY UNIT (WITHOUT NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	O	INV VCC
3	R	SIG VCC
4	R	COMP IN-
5	-	-
6	B	G
7	-	-
8	B	HP

Terminal No.	Color of Wire	Signal Name
9	G	YS
10	-	-
11	V	IT DISP
12	-	-
13	SB	INV GND
14	BR	SIG GND
15	G	COMP IN SYNC
16	-	-
17	W	R
18	R	B
19	R	RGB SYNC
20	W	VP
21	-	-
22	LG	DISP IT
23	-	-
24	-	-

Connector No.	M98
Connector Name	A/C AND AV SWITCH ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	G/Y	ACC
3	LG	ILL
4	BR	ILL CONT GND
5	L	M CAN1-H
6	P	M CAN1-L
7	GR	SW GND
8	SB	CD DVD EJECT

Terminal No.	Color of Wire	Signal Name
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	Y	RR DEFOG

Connector No.	M102
Connector Name	COMBINATION SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
16	L	-
17	BR	-
20	W	-

ABNIA3335GB

MID AUDIO SYSTEM

< WIRING DIAGRAM >

[MID AUDIO]

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	L	-

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-
2	L	-


Connector No.	M132
Connector Name	AV CONTROL UNIT (WITH MID AUDIO SYSTEM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
33	-	-
34	-	ANT MAIN
35	-	ANT +B

Terminal No.	Color of Wire	Signal Name
9	V	ILL+
10	-	-
11	LG	FR SPRH (+)
12	R	FR SPRH (-)
13	GR	RR SPRH (+)
14	O	RR SPRH (-)
15	L	STRG SW GND
16	G	STRG SW B
17	-	-
18	-	-
19	Y	+B
20	B	GND

Connector No.	M131
Connector Name	AV CONTROL UNIT (WITH MID AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	BR	FR SP LH (+)
3	L	FR SP LH (-)
4	G	RR SP LH (+)
5	B	RR SP LH (-)
6	Y	STRG SW A
7	G/Y	ACC
8	-	-

ABNIA3336GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

MID AUDIO SYSTEM

< WIRING DIAGRAM >


[MID AUDIO]

Connector No.	M134
Connector Name	AV CONTROL UNIT (WITH MID AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
60	-	-
61	-	-
62	-	-
63	-	-
64	W	VTR -
65	B	VTR +
66	-	-
67	-	-
68	B	RV CAM SIG
69	-	-
70	-	-
71	-	-
72	SHIELD	COMP IN SHIELD
73	-	-
74	-	-
75	-	-

Connector No.	M133
Connector Name	AV CONTROL UNIT (WITH MID AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
36	G	COMP OUT+
37	R	COMP OUT-
38	R	B
39	B	G
40	W	R
41	R	RGB SYNC
42	-	-
43	G	YS
44	LG	DISP IT
45	B	HP
46	BR	SIG GND
47	R	SIG VCC
48	-	-
49	-	-
50	-	-
51	-	-
52	-	-
53	-	-
54	B	GND
55	-	-
56	V	IT DISP
57	W	VP
58	SB	INV GND
59	O	INV VCC

ABNIA3337GB

MID AUDIO SYSTEM


< WIRING DIAGRAM >

[MID AUDIO]

Terminal No.	Color of Wire	Signal Name
101	GR	SW GND
102	-	-
103	SB	CD EJECT
104	W/G	IGN
105	W	REVERSE SIG
106	G	PKB SIG
107	LG	SPEED 8P


Terminal No.	Color of Wire	Signal Name
85	B	GND
86	L	CAN-H
87	P	CAN-L
88	L	M CAN1 H
89	P	M CAN1 L
90	L	M CAN2 H
91	P	M CAN2 L
92	-	-
93	-	-
94	SHIELD	HP SHIELD
95	W	AUX AUDIO RH+
96	B	AUX AUDIO LH+
97	R	AUX GND
98	-	-
99	-	-
100	-	-

Connector No.	M135
Connector Name	AV CONTROL UNIT (WITH MID AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
76	-	-
77	-	-
78	-	-
79	-	-
80	-	-
81	-	-
82	-	-
83	-	-
84	-	-

Connector No.	M601
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

Connector No.	M502
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

Connector No.	M501
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

ABNIA3338GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

MID AUDIO SYSTEM

< WIRING DIAGRAM >


[MID AUDIO]

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	—

Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	LG	—

Connector No.	M602
Connector Name	ANTENNA AMP.
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	—	—
3	—	—

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
16	W/G	REVERSE LAMP

Connector No.	E53
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	G	—

Connector No.	E45
Connector Name	BACK-UP LAMP RELAY
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	LG	—
2	W/G	—
3	SB	—
5	W/G	—


ABNIA2661GB

MID AUDIO SYSTEM

< WIRING DIAGRAM >

[MID AUDIO]


Connector No.	F9
Connector Name	A/T ASSEMBLY
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
7	LG	-

Terminal No.	Color of Wire	Signal Name
54G	SB	-
77G	Y	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	G	-(WITHOUT BOSE AUDIO SYSTEM)
12	B	-(WITHOUT BOSE AUDIO SYSTEM)

Connector No.	F502
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
7	O	REV LAMP RLY

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	LG	-

ABNIA2662GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

MID AUDIO SYSTEM

< WIRING DIAGRAM >


[MID AUDIO]

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-


Terminal No.	Color of Wire	Signal Name
3J	G	-(WITHOUT BOSE AUDIO SYSTEM)
8J	B	-(WITHOUT BOSE AUDIO SYSTEM)




Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
5M	SHIELD	-
8M	B	-
9M	W	-
65M	G/Y	-
71M	GR	-
72M	O	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B107
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-
5	G/Y	-
6	SHIELD	-


ABNIA2663GB

MID AUDIO SYSTEM

< WIRING DIAGRAM >

[MID AUDIO]

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	L/B	-
11	W/B	-

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	L/R	-
3	L/W	-

Connector No.	D209
Connector Name	REAR DOOR SPEAKER LH (WITHOUT BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	O	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

ABNIA2664GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

MID AUDIO SYSTEM

< WIRING DIAGRAM >

[MID AUDIO]

Connector No.	D450
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-
5	G/Y	-
6	SHIELD	-

Connector No.	D309
Connector Name	REAR DOOR SPEAKER RH (WITHOUT BOSE AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	O	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

Connector No.	D551
Connector Name	REAR VIEW CAMERA
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	GND
2	G/Y	ACC
3	SHIELD	DRAIN
5	W	CAMERA -
6	B	CAMERA +

Connector No.	D550
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
3	G/Y	-
6	W	-
7	B	-
8	SHIELD	-

Connector No.	D451
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
3	G/Y	-
6	W	-
7	B	-
8	SHIELD	-

ABNIA2665GB

AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[MID AUDIO]

SYMPTOM DIAGNOSIS

AUDIO SYSTEM

Symptom Table

INFOID:000000007347662

AUDIO SYSTEM

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> AV control unit power supply and ground circuit AV control unit 	<ul style="list-style-type: none"> AV-65 AV-49
Steering switch does not operate	<ul style="list-style-type: none"> Steering switch AV control unit 	<ul style="list-style-type: none"> AV-83 AV-49
All speakers do not sound	<ul style="list-style-type: none"> Speaker circuit shorted to ground AV control unit 	<ul style="list-style-type: none"> AV-95 AV-49
One or several speakers do not sound	<ul style="list-style-type: none"> Front door speaker Front tweeter Rear door speaker 	<ul style="list-style-type: none"> AV-77 AV-79 AV-81
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

CD

Symptom	Possible cause	Reference page
CD cannot be inserted.	AV control unit	AV-49
CD cannot be ejected.		
The CD cannot be played.		
The sound skips, stops suddenly, or is distorted.		

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[MID AUDIO]

NORMAL OPERATING CONDITION

Description

INFOID:000000007347663

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

NOISE

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	<ul style="list-style-type: none"> • Ignition components
The occurrence of the noise is linked with the operation of the fuel pump.		<ul style="list-style-type: none"> • Fuel pump condenser
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	<ul style="list-style-type: none"> • Relay malfunction, audio unit malfunction
	The noise occurs when various motors are operating.	<ul style="list-style-type: none"> • Motor case ground • Motor
The noise occurs constantly, not just under certain conditions.		<ul style="list-style-type: none"> • Rear defogger coil malfunction • Open circuit in printed heater • Poor ground of antenna feeder line
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		<ul style="list-style-type: none"> • Ground wire of body parts • Ground due to improper part installation • Wiring connections or a short circuit

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007347664

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000007347665

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

PRECAUTIONS

< PRECAUTION >

[MID AUDIO]

5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT.

Precaution for Work

INFOID:000000007347666

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components.
 - Water soluble dirt: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the dirty area.
Then rub with a soft and dry cloth.
 - Oily dirt: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the dirty area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[MID AUDIO]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000007347667

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim tool set	Removing trim components




AWJIA04832Z

Commercial Service Tools

INFOID:000000007347668

Tool name	Description
Power tool	Loosening nuts, screws and bolts



PIIB1407E

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AV CONTROL UNIT

< REMOVAL AND INSTALLATION >


[MID AUDIO]

REMOVAL AND INSTALLATION

AV CONTROL UNIT

Removal and Installation

INFOID:000000007347669



- | | | |
|-----------------------------|----------------------|-------------------------------|
| 1. Cluster lid C | 2. Display unit | 3. AV control unit |
| 4. AV control unit brackets | 5. Tuner knob switch | 6. A/C and AV switch assembly |
| 7. Volume knob switch | 8. Volume knob | 9. Temp knobs RH and LH |
| 10. Enter button | 11. Tuner knob | |

AV CONTROL UNIT

< REMOVAL AND INSTALLATION >

[MID AUDIO]

CAUTION:

Only remove and replace the A/C or AV switch assembly knobs if damaged or missing. The knobs must not be removed from switches when removing and installing the A/C or AV switch assembly to prevent damage to the switch assembly.

REMOVAL

1. Disconnect the battery negative terminal.
2. Remove the cluster lid C. Refer to [JP-16, "Removal and Installation"](#).
3. Remove the AV control unit screws, using a power tool.
4. Remove the AV control unit.
5. Remove the A/C and AV switch assembly screws, then remove the A/C and AV switch assemblies as necessary.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV


DISPLAY UNIT

Removal and Installation


INFOID:000000007347670

REMOVAL

1. Remove cluster lid C. Refer to [IP-16. "Removal and Installation"](#).
2. Remove the display unit screws (A).
3. Pull out the display unit (1), then disconnect the display unit connectors and remove the display unit (1).



4. Remove the A/C auto amp.screws (A), remove the (C103) fasteners (B) from the display unit assembly brackets and remove the A/C auto amp. (1).
5. Remove the display unit bracket unit screws (C) and remove the display unit brackets (2).



INSTALLATION

Installation is in reverse order of removal.

FRONT TWEETER

< REMOVAL AND INSTALLATION >

[MID AUDIO]

FRONT TWEETER

Removal and Installation


INFOID:000000007347671

REMOVAL

CAUTION:

Use a suitable tool to prevent damage to the front tweeter speaker grille trim and the instrument panel.

1. Remove the front tweeter grille.
2. Remove the front tweeter screws (A).
3. Pull out the front tweeter speaker (1) and disconnect front tweeter connector, then remove the front tweeter speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[MID AUDIO]


FRONT DOOR SPEAKER

Removal and Installation

INFOID:000000007347672

REMOVAL

1. Remove the front door finisher. Refer to [INT-15, "Removal and Installation"](#).
2. Remove the front door speaker screws (A).
3. Pull out the front door speaker (1), and disconnect the front door speaker connector and remove the front door speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[MID AUDIO]


REAR DOOR SPEAKER

Removal and Installation

INFOID:000000007347673

REMOVAL

1. Remove the rear door finisher. Refer to [INT-15. "Removal and Installation"](#).
2. Remove the rear door speaker screws (A).
3. Disconnect the rear door speaker connector (B) and remove rear door speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

STEERING SWITCH


< REMOVAL AND INSTALLATION >

[MID AUDIO]

STEERING SWITCH

Removal and Installation

INFOID:000000007347674



1. Steering wheel


2. Steering wheel audio control switches


REMOVAL

1. Remove the driver air bag module. Refer to [SR-5, "Removal and Installation"](#).
2. Remove the steering wheel audio control switch assembly screws.
3. Disconnect the steering wheel audio control switches connector.
4. Remove the steering wheel audio control switches by pulling on steering wheel audio control switches to release the pawls.

CAUTION:

Do not tilt steering wheel audio control switches during removal or damage may occur to the pawls.

-  Pawl



INSTALLATION

Installation is in the reverse order of removal.

AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[MID AUDIO]

AUDIO ANTENNA

Location of Antenna

INFOID:000000007347675




- | | | |
|-------------------------|--------------------------------|---------------------------------|
| 1. AV control unit M132 | 2. Harness connector M78, M501 | 3. Harness connector M502, M601 |
| 4. Antenna feeder | 5. Antenna amp. M602 | 6. Window antenna grid |

Window Antenna Repair

INFOID:000000007347676

ELEMENT CHECK

1. Attach probe circuit tester (ohm setting) to antenna terminal on each side.




AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[MID AUDIO]


- When measuring continuity, wrap tin foil around the top of probe. Then, press the foil against the wire with your finger.



2. If an element is broken, no continuity will exist.



3. To locate a break, move probe along element. Tester indication will change abruptly when probe passes the broken point.



ELEMENT REPAIR

Refer to [DEF-45, "Filament Repair"](#).

AUXILIARY INPUT JACK

< REMOVAL AND INSTALLATION >

[MID AUDIO]

AUXILIARY INPUT JACK

Removal and Installation

INFOID:000000007347677

Removal

1. Remove the A/T finisher. Refer to [IP-21. "Removal and Installation"](#).
2. Remove the auxiliary input jack.

Installation

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

ANTENNA AMP.

< REMOVAL AND INSTALLATION >

[MID AUDIO]


ANTENNA AMP.

Removal and Installation

INFOID:000000007347678

REMOVAL

1. Remove the luggage side upper and lower RH finishers. Refer to [INT-25. "Removal and Installation"](#).
2. Detach the antenna amp. harness clip (D), disconnect the antenna amp. connector (A), harness connector (B), then remove the antenna amp. screw (C) and remove the antenna amp. (1).



INSTALLATION

Installation is in the reverse order of removal.

REAR VIEW CAMERA


< REMOVAL AND INSTALLATION >

[MID AUDIO]

REAR VIEW CAMERA

Removal and Installation

INFOID:000000007347681



1. Rear view camera A. Rear view camera connector B. Rear view camera harness clip

REMOVAL

1. Remove the license lamp finisher. Refer to [EXT-23. "Removal and Installation"](#).
2. Disconnect the rear view camera connector.
3. Detach the rear view camera harness clip.
4. Detach the rear view camera to release, then pull out to remove the rear view camera while feeding the rear view camera harness and connector through the back door.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000007347682

OVERALL SEQUENCE



DETAILED FLOW

1.GET INFORMATION FOR SYMPTOM

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2

2.CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer. Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 3

3.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

DIAGNOSIS AND REPAIR WORKFLOW

[BOSE AUDIO WITHOUT NAVIGATION]

< BASIC INSPECTION >

Is malfunctioning part detected?

YES >> GO TO 4

NO >> GO TO 2

4.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure.

>> GO TO 5

5.FINAL CHECK

Refer to confirmed symptom in step 2, and make sure that the symptom is not detected.

Was the repair confirmed?

YES >> Inspection End.

NO >> GO TO 2

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

AUDIO SYSTEM

< SYSTEM DESCRIPTION >


[BOSE AUDIO WITHOUT NAVIGATION]

SYSTEM DESCRIPTION

AUDIO SYSTEM

System Diagram

INFOID:000000007347683



AWNIA2298GB

System Description

INFOID:000000007347684

AUDIO SYSTEM

AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]

The audio system consists of the following components

- AV control unit
- Display unit
- BOSE speaker amp.
- Window antenna
- Steering wheel audio control switches
- A/C and AV switch assembly
- Front door speakers
- Front tweeters
- Rear door speakers
- Rear tweeters
- Subwoofer

When the audio system is on, radio signals are received by the window antenna. The AV control unit then sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the front door speakers, front tweeters, rear door speakers, rear tweeters and the subwoofer. Refer to Owner's Manual for audio system operating instructions.

SATELLITE RADIO SYSTEM

The satellite radio system consists of the following components

- Satellite antenna
- Satellite radio tuner

When the satellite radio system is on, radio signals are supplied to the satellite radio tuner from the satellite antenna. The satellite radio tuner then sends audio signals to the AV control unit. Refer to Owner's Manual for satellite radio system operating instructions.

SPEED SENSITIVE VOLUME SYSTEM

Volume level of this system goes up and down automatically in proportion to the vehicle speed. The control level can be selected by the customer. Refer to Owner's Manual for operating instructions.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV


AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]

Component Parts Location

INFOID:000000007347685



AWN1A22992Z

- | | | |
|--|--------------------------|--|
| 1. Steering wheel audio control switches | 2. Front tweeter LH M109 | 3. AV control unit M42, M43, M44, M45, M46, M69, M70 |
| 4. A/C and AV switch assembly M98 | 5. Display unit M93 | 6. Front tweeter RH M111 |
| 7. Satellite radio tuner M41, M129 | 8. Aux jack M85 | 9. Front door speaker LH D12
RH D112 |

AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]

- | | | |
|--|---|-------------------|
| 10. Rear tweeter
LH D208
RH D308 | 11. Rear door speaker
LH D207
RH D307 | 12. Subwoofer B72 |
| 13. BOSE speaker amp B74 & B75 (located under driver seat) | 14. Rear view camera D551 | |

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

Component Description

INFOID:000000007347686

Part name	Description
AV control unit	Controls audio system and satellite radio system functions
Display unit	Displays all audio and climate control related information
BOSE speaker amp.	Receives power (amp ON) and audio signals from audio unit and outputs audio signals to each speaker.
Steering wheel audio control switches	<ul style="list-style-type: none"> Audio operation can be operated Steering wheel audio control switch signal is output to audio unit
Front door speakers	<ul style="list-style-type: none"> Outputs audio signal from BOSE speaker amp. Outputs high, mid and low range sounds
Front tweeters	<ul style="list-style-type: none"> Outputs audio signal from BOSE speaker amp. Outputs high range sounds
Rear door speakers	<ul style="list-style-type: none"> Outputs audio signal from BOSE speaker amp. Outputs high, mid and low range sounds
Rear tweeters	<ul style="list-style-type: none"> Outputs audio signal from BOSE speaker amp. Outputs high range sounds
Subwoofer	<ul style="list-style-type: none"> Outputs audio signal from BOSE speaker amp. Outputs low range sounds
Satellite radio tuner	<ul style="list-style-type: none"> Receives radio signals from satellite antenna Sends audio signals to AV control unit
Satellite antenna	Audio signal (satellite radio) is received and output to AV control unit.

AV


REAR VIEW MONITOR SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< SYSTEM DESCRIPTION >

REAR VIEW MONITOR SYSTEM

System Diagram



System Description

INFOID:000000007347688

When the shift selector is in the R position the AV control unit receives the reverse signal and turns on the rear view camera. The display unit receives camera image signals from the rear view camera. The display unit then shows a view to the rear of the vehicle. Lines which indicate the vehicle clearance and distances are also displayed.


REAR VIEW MONITOR SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000007347689



- | | | |
|--|--------------------------|--|
| 1. Steering wheel audio control switches | 2. Front tweeter LH M109 | 3. AV control unit M42, M43, M44, M45, M46, M69, M70 |
| 4. A/C and AV switch assembly M98 | 5. Display unit M93 | 6. Front tweeter RH M111 |
| 7. Satellite radio tuner M41, M129 | 8. Aux jack M85 | 9. Front door speaker LH D12
RH D112 |

AWNIA22992Z

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

REAR VIEW MONITOR SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< SYSTEM DESCRIPTION >

- | | | |
|--|---|-------------------|
| 10. Rear tweeter
LH D208
RH D308 | 11. Rear door speaker
LH D207
RH D307 | 12. Subwoofer B72 |
| 13. BOSE speaker amp B74 & B75 (located under driver seat) | 14. Rear view camera D551 | |

Component Description

INFOID:000000007347690

Part name	Description
AV control unit	<ul style="list-style-type: none">• Receives reverse signal from back-up lamp relay• Sends camera ON signal to rear view camera• Receives image signal from rear view camera• Sends camera image signal to display unit
Rear view camera	<ul style="list-style-type: none">• Receives camera ON signal from AV control unit• Sends image signal to the AV control unit
Display unit	<ul style="list-style-type: none">• Receives camera image signal from AV control unit


DVD PLAYER

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]

DVD PLAYER

System Diagram



System Description

INFOID:000000007347692

The DVD entertainment system consists of the following components

- AV control unit
- Display unit
- DVD player
- Video monitor
- A/C and AV switch assembly
- Steering wheel audio control switches
- BOSE speaker amp.
- Front tweeters
- Front door speakers
- Rear tweeters
- Rear door speakers
- Subwoofer

When the DVD entertainment system is on, video signals are sent from the DVD player to the video monitor. Audio signals are sent to the AV control unit. Audio signals can be directed through wired or wireless infrared headphones or through the BOSE speaker amp. to the vehicle speakers. Refer to the Owner's Manual for complete DVD entertainment system operating instructions.

AV


DVD PLAYER

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]

Component Parts Location

INFOID:000000007347693



- | | | |
|--|--|--|
| 1. Steering wheel audio control switches | 2. AV control unit M42, M43, M44, M45, M46, M69, M70 | 3. A/C and AV switch assembly M98 |
| 4. Display unit M93 | 5. DVD player M205 (located in center console) | 6. Infrared headphone and remote receiver/transmitter (part of video monitor assembly) |
| 7. Video monitor B76 | | |

Component Description

INFOID:000000007347694

Part name	Description
DVD player	<ul style="list-style-type: none"> Outputs DVD video to video monitor Outputs DVD audio to the AV control unit
Video monitor	<ul style="list-style-type: none"> Receives and displays the DVD video signal
AV control unit	<ul style="list-style-type: none"> Controls audio system and DVD entertainment system functions
BOSE speaker amp.	<ul style="list-style-type: none"> Receives audio signals from the AV control unit Outputs amplified audio signals to the speakers
A/C and AV switch assembly	<ul style="list-style-type: none"> All audio and A/C operations can be operated Switch signal is output to the AV control unit and A/C auto amp
Steering wheel audio control switches	<ul style="list-style-type: none"> Audio operation can be operated Steering switch signal (operation signal) is output to AV control unit
Front door speakers	<ul style="list-style-type: none"> Outputs audio signal from BOSE speaker amp. Outputs high, mid and low range sounds
Front and rear tweeters	<ul style="list-style-type: none"> Outputs audio signal from BOSE speaker amp. Outputs high range sounds

DVD PLAYER

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]

Part name	Description
Rear door speakers	<ul style="list-style-type: none">• Outputs audio signal from BOSE speaker amp.• Outputs high, mid and low range sounds
Subwoofer	<ul style="list-style-type: none">• Outputs audio signal from BOSE speaker amp.• Outputs low range sounds

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P


HANDS-FREE PHONE SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]

HANDS-FREE PHONE SYSTEM

System Diagram



System Description

Refer to the owner's manual for Bluetooth telephone system operating instructions.

NOTE:

Cellular telephones must have their wireless connection set up (paired) before using the Bluetooth telephone system.

Bluetooth telephone system allows users who have a Bluetooth cellular telephone to make a wireless connection between their cellular telephone and the Bluetooth control unit. Hands-free cellular telephone calls can be sent and received. Personal memos can be created using the Nissan Voice Recognition system. Some Bluetooth cellular telephones may not be recognized by the Bluetooth control unit. When a cellular telephone or the Bluetooth control unit is replaced, the telephone must be paired with the Bluetooth control unit. Different cellular telephones may have different pairing procedures. Refer to the cellular telephone operating manual.

BLUETOOTH CONTROL UNIT

When the ignition switch is turned to ACC or ON, the Bluetooth control unit will power up. During power up, the Bluetooth control unit is initialized and performs various self checks. Initialization may take up to 10 seconds. If a phone is present in the vehicle and paired with the Bluetooth control unit, Nissan Voice Recognition will then become active. Bluetooth telephone functions can be turned off using the Nissan Voice Recognition system.

STEERING WHEEL AUDIO CONTROL SWITCHES

When buttons on the steering wheel audio control switch are pushed, the resistance in steering wheel audio control switch circuit changes depending on which button is pushed. The Bluetooth control unit uses this signal to perform various functions while navigating through the voice recognition system.

The following functions can be performed using the steering wheel audio control switch:

- Initiate Self Diagnosis of the Bluetooth telephone system
- Start a voice recognition session
- Answer and end telephone calls
- Adjust the volume of calls
- Record memos

MICROPHONE

The microphone is located in the roof console assembly. The microphone sends a signal to the Bluetooth control unit. The microphone can be actively tested during self-diagnosis.

AV CONTROL UNIT

The AV control unit receives signals from the Bluetooth control unit and sends audio signals to the speakers.


HANDS-FREE PHONE SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000007347697



- | | | |
|--|--------------------------|--|
| 1. Steering wheel audio control switches | 2. Front tweeter LH M109 | 3. AV control unit M42, M43, M44, M45, M46, M69, M70 |
| 4. A/C and AV switch assembly M98 | 5. Display unit M93 | 6. Front tweeter RH M111 |
| 7. Satellite radio tuner M41, M129 | 8. Aux jack M85 | 9. Front door speaker
LH D12
RH D112 |

AWNIA22992Z

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

HANDS-FREE PHONE SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< SYSTEM DESCRIPTION >

- | | | |
|--|---|-------------------|
| 10. Rear tweeter
LH D208
RH D308 | 11. Rear door speaker
LH D207
RH D307 | 12. Subwoofer B72 |
| 13. BOSE speaker amp B74 & B75 (located under driver seat) | 14. Rear view camera D551 | |

Component Description

INFOID:000000007347698

Part name	Description
AV control unit	<ul style="list-style-type: none">Receives telephone voice signal from Bluetooth control unit.Sends telephone voice and voice guidance signals to the speakers.
Door speaker	Receives telephone voice and voice guidance signals from the AV control unit.
Front tweeter	
Center speaker	
Steering wheel audio control switches	<ul style="list-style-type: none">Start a voice recognition sessionAnswer and end telephone callsAdjust the volume level
Microphone	Sends voice signals to Bluetooth control unit
Bluetooth control unit	Controls hands-free phone functions
Bluetooth antenna	Sends telephone voice signal to bluetooth control unit

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

AV CONTROL UNIT

AV CONTROL UNIT : Diagnosis Description

INFOID:000000007347699

DESCRIPTION


- Diagnosis function consists of the “Self-Diagnosis” mode performed automatically and the “Confirmation/Adjustment” mode operated manually.
- “Self-Diagnosis” mode checks for connections between the units constituting this system, analyzes each individual unit at the same time, and displays the results on the LCD screen.
- “Confirmation/Adjustment” mode is used to perform trouble diagnosis that requires operation and judgment by an operator (trouble that cannot be automatically judged by the system), to check/change the set value, and to display the error history of the AV control unit.

DIAGNOSIS ITEM

Mode		Description	
Self-diagnosis		<ul style="list-style-type: none"> • AV control unit diagnosis • Analyzes connection between the AV control unit, front display, Bluetooth, DVD deck, Satellite tuner and switches. 	
CONFIRMATION/ ADJUSTMENT	Display diagnosis	Color spectrum bar	Color tone of the screen can be checked by the display of a color bar.
		Gradation bar	Shading of the screen can be checked by the display of a gray scale.
	Vehicle signals		The following vehicle signals are analyzed: Vehicle speed signal, parking brake signal, light signal, ignition switch signal, and reverse signal.
	Speaker test		Connection can be checked by sending a test tone to each speaker.
	Climate control		Start automatic air conditioner self test.
	Error history		Diagnosis results previously stored in the memory are displayed in this mode.
	Vehicle CAN diagnosis		The transmitting/receiving of CAN communication can be monitored.
	AV COMM diagnosis		The transmitting/receiving of AV communication can be monitored.
	Delete unit connection log		Erase the error history and connection history of the unit.
	Initialize settings		All audio settings are reset to default levels.

OPERATION PROCEDURE

1. Start the engine.
2. Turn the audio system off.
3. While pressing the “SETTING” button, turn the volume control dial counterclockwise 30 clicks or more. (When the self-diagnosis mode is started, a short beep will be heard.)




DIAGNOSIS SYSTEM (AV CONTROL UNIT)

[BOSE AUDIO WITHOUT NAVIGATION]

< SYSTEM DESCRIPTION >

- The initial trouble diagnosis screen will be displayed, and items “Self-Diagnosis” and “Confirmation/Adjustment” can be selected.




SELF-DIAGNOSIS

- Perform self-diagnosis by selecting “Self-Diagnosis”.
 - Self-diagnosis subdivision screen is displayed, and the self-diagnosis mode starts.
 - A bar graph visible on the center of the self-diagnosis subdivision screen indicates progress of the trouble diagnosis.

NOTE:

Self-diagnosis requires approximately 10 seconds to complete.




- Diagnosis results are displayed after the self-diagnosis is completed. The unit names and the connection lines are color-coded according to the diagnostic results.


Diagnosis results	Unit	Connection line
Normal	Green	Green
Connection malfunction	Gray	Yellow
Unit malfunction ^{Note}	Red	Green

Note:

- Only the AV control unit is displayed in red.
- If multiple malfunctions occur at the same time for a single unit, the screen switch colors are determined according to the following order of priority: red > yellow > gray.



- Select a component on the “Self-Diagnosis” screen and comments for the diagnosis results will be shown.







Self-Diagnosis Results

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]

Area with yellow connection lines	Description	Possible malfunction location / Action to take
 <p style="text-align: right; font-size: small;">AWNIA2267GB</p>	<p>AV control unit malfunction is detected</p>	<p>Replace the AV control unit. Refer to AV-255. "Removal and Installation".</p>
 <p style="text-align: right; font-size: small;">AWNIA2268GB</p>	<p>Poor connection is detected for the display unit</p>	<ul style="list-style-type: none"> • Harness or connector • AV control unit • Display unit
 <p style="text-align: right; font-size: small;">AWNIA2269GB</p>	<p>Switch malfunction is detected</p>	<p>Perform A/C and AV switch assembly diagnostics. Refer to AV-148. "A/C AND AV SWITCH ASSEMBLY : Component Function Check".</p>
 <p style="text-align: right; font-size: small;">AWNIA2270GB</p>	<p>Poor connection is detected for the DVD player.</p>	<ul style="list-style-type: none"> • Harness or connector • AV control unit • DVD player



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

DIAGNOSIS SYSTEM (AV CONTROL UNIT)


< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]


Area with yellow connection lines	Description	Possible malfunction location / Action to take
 <p>AWNIA2271GB</p>	<p>Poor connection is detected for the Bluetooth control unit</p>	<ul style="list-style-type: none"> • Harness or connector • AV control unit • Bluetooth control unit
 <p>AWNIA2272GB</p>	<p>Poor connection is detected for the satellite radio tuner.</p>	<ul style="list-style-type: none"> • Harness or connector • AV control unit • Satellite radio tuner

CONFIRMATION/ADJUSTMENT MODE

1. Start the diagnosis function and select “Confirmation/Adjustment”. The confirmation/adjustment mode indicates where each item can be checked or adjusted.
2. Select each item on the “Confirmation/Adjustment” mode screen to display the relevant trouble diagnosis screen. Touch “BACK” on the display unit or press the “BACK” switch to return to the initial Confirmation/Adjustment Mode screen.



Display Diagnosis



Color Spectrum Bar

If colors are abnormal, please refer to the service manual for diagnosis information.

WHITE, YELLOW, CYAN, GREEN, RED, BLUE, BLACK

- CYAN: Close to light blue
- MAGENTA: Close to purplish red

Gradation Bar

If colors are abnormal, please refer to the service manual for diagnosis information.

Black ← GRAY → WHITE

•The gray-scale image is indicated 32-step gradation.

ALNIA0260GB


Vehicle Signals

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

[BOSE AUDIO WITHOUT NAVIGATION]

< SYSTEM DESCRIPTION >


A comparison check can be made of each actual vehicle signal and the signals recognized by the system.



Diagnosis item	Display	Vehicle status	Remarks
Vehicle speed	ON	Vehicle speed > 0 km/h	Changes in indication may be delayed by approximately 1.5 seconds. This is normal.
	OFF	Vehicle speed = 0 km/h	
	-	Ignition switch in ACC position	
Parking brake	ON	Parking brake is applied.	
	OFF	Parking brake is released.	
Lights	ON	Light switch ON	
	OFF	Light switch OFF	
Ignition	ON	Ignition switch ON	-
	OFF	Ignition switch in ACC position	
Reverse	ON	Selector lever in R position	Changes in indication may be delayed by approximately 1.5 seconds. This is normal.
	OFF	Selector lever in any position other than R	
	-	Ignition switch in ACC position	

Speaker Test

Select "Speaker Test" to display the speaker diagnosis screen. Press "Start" to generate a test tone in speakers. Press "End" to stop the test tones.




Error History

The self-diagnosis results are judged depending on whether any error occurs from when "Self-diagnosis" is selected until the self-diagnosis results are displayed.

However, the diagnosis results are judged normal if an error has occurred before the ignition SW is turned ON and then no error has occurred until the self-diagnosis start. Check the "Error History" to detect any error that may have occurred before the self-diagnosis start because of this situation.

Count up method A

- The counter resets to 0 if an error occurs when IGN switch is turned ON. The counter increases by 1 if the condition is normal at a next IGN ON cycle.



DIAGNOSIS SYSTEM (AV CONTROL UNIT)

[BOSE AUDIO WITHOUT NAVIGATION]


< SYSTEM DESCRIPTION >

- The counter upper limit is 39. Any counts exceeding 39 are ignored. The counter can be reset (no error record display) with the “Delete log” switch or CONSULT.
- Count up method B
- The counter increases by 1 if an error occurs when IGN switch is ON. The counter will not decrease even if the condition is normal at the next IGN ON cycle.
- The counter upper limit is 50. Any counts exceeding 50 are ignored. The counter can be reset (no error record display) with the “Delete log” switch or CONSULT.

Display method of occurrence frequency	Error history display item
Count up method A	CAN communication line, control unit (CAN), AV communication line, control unit (AV communication)
Count up method B	Other than above


Vehicle CAN Diagnosis

- CAN communication status and error counter is displayed.
- The error counter displays “OK” if any malfunction was not detected in the past and displays “0” if a malfunction is detected. It increases by 1 if the condition is normal at the next ignition switch ON cycle. The upper limit of the counter is 39.
- The error counter is erased if reset.



AV COMM Diagnosis

- AV communication status and error counter is displayed.
- The error counter displays “OK” if any malfunction was not detected in the past and displays “0” if a malfunction is detected. It increases by 1 if the condition is normal at the next ignition switch ON cycle. The upper limit of the counter is 39.
- The error counter is erased if reset.



Delete Unit Connection Log

Deletes any unit connection records and error records from the AV control unit memory. (Clear the records of the unit that has been removed)




Initialize Settings

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]

Initializes the AV control unit memory.



AV CONTROL UNIT : CONSULT Function

INFOID:000000007347700

CONSULT can display each diagnostic item using the diagnostic test modes shown following.

MULTI AV diagnosis mode	Description
ECU IDENTIFICATION	The part number of AV control unit can be checked.
SELF DIAGNOSTIC RESULT	Displays AV control unit self-diagnosis results.
DATA MONITOR	Displays AV control unit input/output data in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

Self-diagnosis results display item

Error item	Refer to
CAN COMM CIRCUIT [U1000]	AV-150, "Description"
CONTROL UNIT (CAN) [U1010]	AV-151, "Description"
Control Unit FLASH-ROM [U1200]	AV-152, "Description"
CAN CONT [U1216]	AV-153, "Description"
SWITCH CONN [U1240]	AV-154, "Description"
FRONT DISP CONN [U1243]	AV-155, "Description"
DVD DECK CONN [U1248]	AV-157, "Description"
SAT CONN [U1255]	AV-158, "Description"
HAND FREE CONN [U1256]	AV-159, "Description"
AV COMM CIRCUIT [U1300]	AV-160, "Description"
CONTROL UNIT (AV) [U1310]	AV-161, "Description"

DATA MONITOR

Display Item List

Display item [unit]	ALL SIGNALS	SELECTION FROM MENU	Description
VHCL SPD SIG [ON/OFF]	X	X	Displays "ON" when vehicle speed > 0 km/h. Displays "OFF" when vehicle speed = 0 km/h.
PKB SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of parking brake switch.
ILLUM SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of lighting switch.
IGN SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of ignition switch.
REV SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of back-up lamp switch.

A/C AND AV SWITCH ASSEMBLY

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]

A/C AND AV SWITCH ASSEMBLY : Component Function Check

INFOID:000000007347701


A/C and AV switch assembly self-diagnosis function

Description

The ON/OFF operation (continuity) of each switch in the A/C and AV switch assembly can be checked.

Self-diagnosis mode

- Press the “BACK” button and the “UP” button within 10 seconds after turning the ignition switch from OFF to ACC and hold them for 3 seconds or more. When the self-diagnosis mode starts, a beep will sound and all LED indicators of the switch will illuminate.
- The continuity of each switch and control dial of the A/C and AV switch assembly can be checked. If the switch is operating normally, the system will beep and the LED's will illuminate when each switch is operated.



Finishing self-diagnosis mode

Self-diagnosis mode is canceled when the ignition switch is turned OFF.

DIAGNOSIS SYSTEM (BLUETOOTH CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITHOUT NAVIGATION]

DIAGNOSIS SYSTEM (BLUETOOTH CONTROL UNIT)

Diagnosis Description


INFOID:000000007347702


The Bluetooth control unit has two diagnostic checks. The first diagnostic check is performed automatically every ignition cycle during control unit initialization. The second diagnostic check is performed by the technician using the steering wheel audio control switches prior to trouble diagnosis.


BLUETOOTH CONTROL UNIT INITIALIZATION CHECKS


- Internal control unit failure
- Bluetooth antenna connection open or shorted
- Steering wheel audio control switches (SEND/END) stuck closed
- Vehicle speed pulse count
- Microphone connection test (with playback to operator)
- Bluetooth inquiry check

OPERATION PROCEDURE

1. Turn ignition switch to ACC or ON.
2. Wait for the Bluetooth system to complete initialization. This may take up to 10 seconds.
3. Press and hold the steering wheel audio control switch  button for at least 5 seconds. The Bluetooth system will begin to play a verbal prompt.



4. While the prompt is playing, press and hold the steering wheel audio control switch  button until you hear the “Diagnostics mode” prompt. The Bluetooth system will sound a 5 second beep.
5. While the beep is sounding, press and hold the steering wheel audio control switch END button again until you hear prompts.
6. The Bluetooth system has now entered into the diagnostic mode. Results of the diagnostic checks will be verbalized to the technician. Refer to [AV-149, "Work Flow"](#).
7. After the failure records are reported, an interactive microphone test will be performed. Follow the voice prompt. If the microphone test fails refer to [AV-149, "Work Flow"](#).
8. Self-diagnosis mode is complete when the voice prompt says “All diagnostic functions completed”.



Work Flow

INFOID:000000007347703

Failure Message	Action
“Internal failure”	Replace Bluetooth control unit. Refer to AV-264, "Removal and Installation" .
“Bluetooth antenna open”	1. Inspect harness connection.
“Bluetooth antenna shorted”	2. Replace Bluetooth antenna. Refer to AV-264, "Removal and Installation" .
“Phone/Send for Hands Free System is stuck”	Check steering wheel audio control switches. Refer to AV-196, "Description" .
“Phone/End for the Hands Free System is stuck”	
“Microphone test” (failed interactive test)	1. Inspect harness between Bluetooth control unit and microphone. 2. Replace microphone. Refer to AV-263, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000007347704

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-13, "How to Use CAN Communication Signal Chart"](#).

DTC Logic

INFOID:000000007347705

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
U1000	CAN COMM CIRCUIT	When AV control unit is not transmitting or receiving CAN communication signal for 2 seconds or more.	CAN communication system

Diagnosis Procedure

INFOID:000000007347706

1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" of "MULTI AV".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to "LAN system". Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).
- NO >> Refer to GI section. Refer to [GI-37, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000007347707

Initial diagnosis of AV control unit.

DTC Logic

INFOID:000000007347708

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
U1010	CONTROL UNIT (CAN)	CAN initial diagnosis malfunction is detected	AV control unit

Diagnosis Procedure

INFOID:000000007347709

1. REPLACE AV CONTROL UNIT

When DTC U1010 is detected, replace AV control unit. Refer to [AV-255. "Removal and Installation"](#).

>> Inspection End.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

U1200 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

U1200 AV CONTROL UNIT

Description

INFOID:000000007347710

Replace the AV control unit if this DTC is displayed. Refer to [AV-255. "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347711

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U1200	Control Unit FLASH- ROM [U1200]	An internal malfunction is detected in AV control unit (FLASH-ROM).	Replace AV control unit. Refer to AV-255. "Removal and Installation" .

U1216 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

U1216 AV CONTROL UNIT

Description

INFOID:000000007347712

Replace the AV control unit if this DTC is displayed. Refer to [AV-255, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347713

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U1216	CAN CONT [U1216]	Internal malfunction of AV control unit (CAN controller) is detected.	Replace AV control unit. Refer to AV-255, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

U1240 SWITCH CONN

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

U1240 SWITCH CONN

Description

INFOID:000000007347714

U1240 is indicated when malfunction occurs in communication signal of multi AV system. Indicated simultaneously, without fail, with the malfunction of control units connected to AV control unit with communication line. Determine the possible malfunction cause from the table below.

Self-diagnosis results display item

DTC	Display contents of CONSULT	DTC Detection Condition	Possible causes
U1240	<ul style="list-style-type: none">SWITCH CONN [U1240]	<ul style="list-style-type: none">A/C and AV switch assembly power supply and ground circuit malfunction is detectedA malfunction is detected in communication circuit between AV control unit and A/C and AV switch assemblyA malfunction is detected in communication signal between AV control unit and A/C and AV switch assembly	<ul style="list-style-type: none">A/C and AV switch assembly power supply and ground circuitsCommunication circuit between AV control unit and A/C and AV switch assembly

U1243 DISPLAY UNIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

U1243 DISPLAY UNIT

Description

INFOID:000000007347715

Part name	Description
DISPLAY UNIT	<ul style="list-style-type: none"> • Display image is controlled by the serial communication from AV control unit. • Inputs the RGB image signal (RGB, RGB area and RGB synchronizing) from AV control unit and the auxiliary image signal from the auxiliary input jacks. • Outputs the synchronizing signals (HP and VP) to the AV control unit.

DTC Logic

INFOID:000000007347716

DTC	Display contents of CONSULT	DTC Detection Condition	Possible causes
U1243	FRONT DISP CONN [U1243]	<ul style="list-style-type: none"> • Display unit power supply and ground circuit malfunction is detected • Malfunction is detected on communication circuit between display unit and AV control unit • Malfunction is detected on communication signal between display unit and AV control unit 	<ul style="list-style-type: none"> • Display unit power supply and ground circuit • Communication circuit between display unit and AV control unit

Diagnosis Procedure

INFOID:000000007347717

Regarding Wiring Diagram information, refer to [AV-225. "Wiring Diagram - Without Navigation System"](#).

1. CHECK DISPLAY UNIT POWER SUPPLY AND GROUND CIRCUIT

Check display unit power supply and ground circuit. Refer to [AV-163, "DISPLAY UNIT : Diagnosis Procedure"](#).

Is inspection result OK?


YES >> GO TO 2

NO >> Repair malfunctioning parts.

2. CHECK CONTINUITY OF COMMUNICATION CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector and AV control unit connector.
3. Check continuity between display unit harness connector M93 (A) terminals 11, 22 and AV control unit harness connector M45 (B) terminals 56, 44.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	11	M45	56	Yes
	22		44	



4. Check continuity between display unit harness connector M93 (A) terminals 11, 22 and ground.

A		—	Continuity
Connector	Terminal		
M93	11	Ground	No
	22		

Are continuity results as specified?

YES >> GO TO 3

U1243 DISPLAY UNIT


[BOSE AUDIO WITHOUT NAVIGATION]


< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair harness or connector.

3. CHECK COMMUNICATION SIGNAL

1. Connect display unit connector and AV control unit connector.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 11 and ground with an oscilloscope or CONSULT.

(+)		(-)	Reference signal
Connector	Terminal		
M93	11	Ground	




Are voltage readings as specified?


YES >> GO TO 4

NO >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).

4. CHECK COMMUNICATION SIGNAL

Check signal between display unit harness connector M93 terminal 22 and ground with an oscilloscope or CONSULT.

(+)		(-)	Reference signal
Connector	Terminal		
M93	22	Ground	



Are voltage readings as specified?

YES >> Inspection End.

NO >> Replace display unit. Refer to [AV-257, "Removal and Installation"](#).

U1248 DVD DECK CONN

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

U1248 DVD DECK CONN

Description

INFOID:000000007347718

U1248 is indicated when a malfunction occurs in the communication signal of the DVD player. Indicated simultaneously, without fail, with the malfunction of control units connected to AV control unit with communication line. Determine the possible malfunction cause from the table below.

DTC Logic

INFOID:000000007347719

DTC	Display contents of CONSULT	DTC Detection Condition	Possible causes
U1248	DVD DECK CONN [U1248]	<ul style="list-style-type: none">DVD player power supply and ground circuit malfunction is detectedMalfunction is detected on communication circuit between DVD player and AV control unitMalfunction is detected on communication signal between DVD player and AV control unit	<ul style="list-style-type: none">DVD player power supply and ground circuitCommunication circuit between DVD player and AV control unit

Diagnosis Procedure

INFOID:000000007347720

1. CHECK DVD PLAYER POWER SUPPLY AND GROUND CIRCUIT

Check DVD player power supply and ground circuit. Refer to [AV-168, "DVD PLAYER : Diagnosis Procedure"](#).

Is inspection result OK?

- YES >> Inspection End.
- NO >> Repair malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



U1255 SATELLITE RADIO TUNER

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

U1255 SATELLITE RADIO TUNER

Description

INFOID:000000007347721

Part name	Description
SATELLITE RADIO TUNER	<ul style="list-style-type: none">Inputs the satellite radio signal from satellite radio antenna and outputs it to the AV control unit.It is controlled with the communication (communication signal, request signal) from AV control unit.

DTC Logic

INFOID:000000007347722

DTC	Display contents of CONSULT	DTC Detection Condition	Possible causes
U1255	SAT CONN [U1255]	The satellite radio tuner power supply and ground circuit malfunction is detected	Satellite radio tuner power supply and ground circuit

Diagnosis Procedure

INFOID:000000007347723

1. CHECK SATELLITE RADIO TUNER POWER SUPPLY AND GROUND CIRCUIT

Check satellite radio tuner power supply and ground circuit. Refer to [AV-166. "SATELLITE RADIO TUNER : Diagnosis Procedure"](#).

Is inspection result OK?

- YES >> Inspection End.
- NO >> Repair malfunctioning parts.

U1256 HAND FREE CONN

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

U1256 HAND FREE CONN

Description

INFOID:000000007347724

U1256 is indicated when malfunction occurs in communication signal of multi AV system. Indicated simultaneously, without fail, with the malfunction of control units connected to AV control unit with communication line. Determine the possible malfunction cause from the table below.

Self-diagnosis results display item

DTC	Display contents of CONSULT	DTC Detection Condition	Possible causes
U1256	<ul style="list-style-type: none">HAND FREE CONN [U1256]	<ul style="list-style-type: none">Bluetooth control unit power supply and ground circuit malfunction is detectedA malfunction is detected in communication circuit between AV control unit and Bluetooth control unitA malfunction is detected in communication signal between AV control unit and Bluetooth control unit	<ul style="list-style-type: none">Bluetooth control unit power supply and ground circuitsCommunication circuit between AV control unit and Bluetooth control unit

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

U1300 AV COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

U1300 AV COMM CIRCUIT

Description

INFOID:000000007347725

U1300 is indicated when malfunction occurs in communication signal of multi AV system. Indicated simultaneously, without fail, with the malfunction of control units connected to AV control unit with communication line. Determine the possible malfunction cause from the table below.

Self-diagnosis results display item

DTC	Display contents of CONSULT	DTC Detection Condition	Possible causes
U1300 U1240	<ul style="list-style-type: none">• AV COMM CIRCUIT [U1300]• SWITCH CONN [U1240]	<ul style="list-style-type: none">• A/C and AV switch assembly power supply and ground circuit malfunction is detected• A malfunction is detected in communication circuit between AV control unit and A/C and AV switch assembly• A malfunction is detected in communication signal between AV control unit and A/C and AV switch assembly	<ul style="list-style-type: none">• A/C and AV switch assembly power supply and ground circuits• Communication circuit between AV control unit and A/C and AV switch assembly

U1310 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

U1310 AV CONTROL UNIT

Description

INFOID:000000007347726

Replace the AV control unit if this DTC is displayed. Refer to [AV-255, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347727

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U1310	CONTROL UNIT (AV) [U1310]	An initial diagnosis error is detected in AV communication circuit.	Replace AV control unit. Refer to AV-255, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

POWER SUPPLY AND GROUND CIRCUIT

AV CONTROL UNIT

AV CONTROL UNIT : Diagnosis Procedure

INFOID:000000007347728

Regarding Wiring Diagram information, refer to [AV-225. "Wiring Diagram - Without Navigation System"](#).

1. CHECK FUSES

Check that the following fuses of the AV control unit are not are not blown.

Unit	Terminals	Signal name	Fuse No.
AV control unit	19	Battery power	29
	7	Ignition switch ACC or ON	4
	104	Ignition switch ON or START	12

Are the fuses OK?

YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. POWER SUPPLY CIRCUIT CHECK


1. Disconnect AV control unit connectors M42 and M70.
2. Check voltage between the AV control unit connectors M42 and M70 and ground.

Connector	(+)	(-)	OFF	ACC	ON
	Terminal				
M42	7	Ground	0V	Battery voltage	Battery voltage
	19	Ground	Battery voltage	Battery voltage	Battery voltage
M70	104	Ground	0V	0V	Battery voltage

Are the voltage results as specified?

YES >> GO TO 3

NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.



3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Check continuity between AV control unit harness connectors M42, M45, M46, M70 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

(+)		(-)	Continuity
Connector	Terminal		
M42	20	Ground	Yes
M45	54		
M46	68		
M70	85		

Are the continuity results as specified?

- YES >> Inspection End.
- NO >> Repair AV control unit ground.

DISPLAY UNIT

DISPLAY UNIT : Diagnosis Procedure


INFOID:000000007347729

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch to ACC.
- Check voltage between display unit harness connector M93 and ground.

Connector	Terminal	Ignition switch position	Value (Approx.)
M93	2	ACC	9V
	3		




Does specified voltage exist?

- YES >> GO TO 3
- NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect the display unit connector M93 and the AV control unit connector M45.
- Check continuity between the display unit harness connector M93 (A) and the AV control unit connector M45 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	2	M45	59	Yes
	3		47	



- Check continuity between the display unit harness connector M93 (A) and ground.

A		—	Continuity
Connector	Terminal		
M93	2	Ground	No
	3		

Are continuity results as specified?

- YES >> Check AV control unit power and ground supply. Refer to [AV-162, "AV CONTROL UNIT : Diagnosis Procedure"](#).
- NO >> Repair harness or connector.

POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector.
3. Check continuity between display unit harness connector and ground.

Connector	Terminal	—	Continuity
M93	1	Ground	Yes

Does continuity exist?

- YES >> Inspection End.
 NO >> Repair harness or connector.

A/C AND AV SWITCH ASSEMBLY

A/C AND AV SWITCH ASSEMBLY : Diagnosis Procedure

INFOID:000000007347730

Regarding Wiring Diagram information, refer to [AV-225. "Wiring Diagram - Without Navigation System"](#).

1. CHECK FUSE

Check that the fuse of the AC and AV switch assembly is not blown.

Unit	Terminal	Signal name	Fuse No.
A/C and AV switch assembly	2	Ignition switch ACC or ON	4

Is the fuse OK?

- YES >> GO TO 2
 NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. POWER SUPPLY CIRCUIT CHECK



1. Disconnect A/C and AV switch assembly connector M98.
2. Check voltage between the A/C and AV switch assembly connector M98 and ground.

(+)		(-)	OFF	ACC	ON
Connector	Terminal				
M98	2	Ground	0V	Battery voltage	Battery voltage

Are the voltage results as specified?

- YES >> GO TO 3
 NO >> • Check connector housings for disconnected or loose terminals.
 • Repair harness or connector.

3. GROUND CIRCUIT CHECK



POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]


< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Check continuity between A/C and AV switch assembly harness connector M98 and ground.

Connector	Terminal	—	Continuity
M98	1	Ground	Yes

Does continuity exist?

- YES >> Inspection End.
 NO >> Repair harness or ground.



BOSE SPEAKER AMP

BOSE SPEAKER AMP : Diagnosis Procedure

INFOID:000000007347731

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1.CHECK FUSE

Check that the BOSE speaker amp. fuse is not blown.

Unit	Terminal	Signal name	Fuse No.
BOSE speaker amp.	1	Battery power	29

Are the fuses OK?

- YES >> GO TO 2
 NO >> Be sure to eliminate cause of malfunction before installing new fuse.


2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BOSE speaker amp. connector.
3. Check voltage between BOSE speaker amp. harness connector B74 terminal 1 and ground.

(+)		(-)	Voltage (approx.)
Connector	Terminal		
B74	1	Ground	Battery voltage

Is battery voltage present?

- YES >> GO TO 3
 NO >> Check harness between BOSE speaker amp. and fuse.




3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BOSE speaker amp. connector.
3. Check continuity between BOSE speaker amp. harness connector B74 terminal 17 and ground.

(+)		(-)	Continuity
Connector	Terminal		
B74	17	Ground	Yes

Does continuity exist?

- YES >> Inspection End.
 NO >> Repair harness or connector.



SUBWOOFER

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

SUBWOOFER : Diagnosis Procedure

INFOID:000000007347732

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1.CHECK FUSE

Check that the subwoofer fuse is not blown.

Unit	Terminal	Signal name	Fuse No.
Subwoofer	6	Battery power	17

Is the fuse OK?

YES >> GO TO 2

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect subwoofer connector.
3. Check voltage between subwoofer harness connector B72 terminal 6 and ground.

(+)		(-)	Voltage (approx.)
Connector	Terminal		
B72	6	Ground	Battery voltage

Is battery voltage present?

YES >> GO TO 3

NO >> Check harness between subwoofer and fuse.



3.CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Check continuity between subwoofer harness connector B72 terminal 5 and ground.

(+)		(-)	Continuity
Connector	Terminal		
B72	5	Ground	Yes

Does continuity exist?

YES >> Inspection End.

NO >> Repair harness or connector.



SATELLITE RADIO TUNER

SATELLITE RADIO TUNER : Diagnosis Procedure

INFOID:000000007347733

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1.CHECK FUSES

Check that the following fuses of the satellite radio tuner (factory installed) are not blown.

Unit	Terminals	Signal name	Fuse No.
Satellite radio tuner (factory installed)	32	Battery power	17
	36	Ignition switch ACC or ON	4

POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >


Are the fuses OK?

- YES >> GO TO 2
 NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. POWER SUPPLY CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner (factory installed) connector M41.
3. Check voltage between the satellite radio tuner (factory installed) and ground.

(+)		(-)	OFF	ACC	ON
Connector	Terminal				
M41	32	Ground	Battery voltage	Battery voltage	Battery voltage
	36		0V	Battery voltage	Battery voltage



Are the voltage readings as specified?

- YES >> GO TO 3
 NO >> • Check connector housings for disconnected or loose terminals.
 • Repair harness or connector.

3. GROUND CIRCUIT CHECK

Inspect satellite radio tuner (factory installed) case ground.

Does case ground pass inspection?

- YES >> Inspection End.
 NO >> Repair satellite radio tuner (factory installed) case ground.

REAR VIEW CAMERA

REAR VIEW CAMERA : Diagnosis Procedure

INFOID:000000007347734

Regarding Wiring Diagram information, refer to [AV-225. "Wiring Diagram - Without Navigation System"](#).

1. CHECK POWER SUPPLY CIRCUIT (REAR VIEW CAMERA SIDE)

NOTE:

Apply parking brakes before proceeding.

1. Turn ignition switch ON.
2. Shift transmission into reverse.
3. Check voltage between rear view camera harness connector D551 terminal 2 and ground.

(+)		(-)	Transmission position	Value (Approx.)
Connector	Terminal			
D551	2	Ground	Reverse	12V

Is voltage reading approximately 12 volts?

- YES >> GO TO 4.
 NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT (CONTINUITY)

1. Turn ignition switch OFF.
2. Disconnect rear view camera and AV control unit connectors.
3. Check continuity between rear view camera harness connector D551 terminal 2 and AV control unit harness connector M134 terminal 105.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

Connector	Terminal	Connector	Terminal	Continuity
D551	2	M134	105	Yes

4. Check continuity between rear view camera harness connector D551 terminal 2 and ground.

Connector	Terminal	—	Continuity
D551	2	Ground	No

Are continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK REVERSE POSITION INPUT SIGNAL

1. Turn ignition switch ON.
2. Shift transmission into reverse.
3. Check voltage between AV control unit harness connector M134 terminal 105 and ground.

(+)		(-)	Transmission position	Value (Approx.)
Connector	Terminal			
M134	105	Ground	Reverse	12V

Is voltage reading approximately 12 volts?

YES >> Replace AV control unit. Refer to [AV-255. "Removal and Installation"](#).

NO >> Check harness for open or short between AV control unit and back-up lamp relay.

4.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear view camera harness connector.
3. Check continuity between rear view camera harness connector D551 terminal 1 and ground.

Connector	Terminal	—	Continuity
D551	1	Ground	Yes

Does continuity exist?

YES >> Inspection End.

NO >> Repair harness or connector.

DVD PLAYER

DVD PLAYER : Diagnosis Procedure

INFOID:000000007347735

Regarding Wiring Diagram information, refer to [AV-225. "Wiring Diagram - Without Navigation System"](#).

1.CHECK FUSE

Check that the following fuses of the DVD player are not blown.

Unit	Terminal	Signal name	Fuse No.
DVD player	21	Battery power	29
	24	Ignition switch ACC or ON	4

Is the fuse OK?

YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2.POWER SUPPLY CIRCUIT CHECK


POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect DVD player connector M205.
2. Check voltage between the DVD player connector M205 and ground.

(+)		(-)	OFF	ACC	ON
Connector	Terminal				
M205	21	Ground	Battery voltage	Battery voltage	Battery voltage
	24		0V	Battery voltage	Battery voltage




Are the voltage results as specified?

- YES >> GO TO 3
 NO >> • Check connector housings for disconnected or loose terminals.
 • Repair harness or connector.

3. GROUND CIRCUIT CHECK

1. Turn ignition switch OFF.
2. Check continuity between DVD player harness connector M205 terminal 5 and ground.

Connector	Terminal	—	Continuity
M205	5	Ground	Yes



Does continuity exist?

- YES >> Inspection End.
 NO >> Repair DVD player ground.

VIDEO MONITOR

VIDEO MONITOR : Diagnosis Procedure

INFOID:000000007347736

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).


1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch to ACC.
2. Check voltage between video monitor harness connector B76 and ground.

(+)		(-)	Ignition switch position	Value (Approx.)
Connector	Terminal			
B76	16	Ground	ACC	Battery voltage

Does battery voltage exist?

- YES >> GO TO 3
 NO >> GO TO 2



2. CHECK POWER SUPPLY CIRCUIT


POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect the video monitor connector B76 and the DVD player connector M205.
3. Check continuity between the video monitor harness connector B76 (A) and the DVD player connector M205 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B76	16	M205	9	Yes



4. Check continuity between video monitor harness connector B76 (A) and ground.

A		—	Continuity
Connector	Terminal		
B76	16	Ground	No

Are continuity results as specified?


YES >> Check DVD player power and ground supply. Refer to [AV-168, "DVD PLAYER : Diagnosis Procedure"](#).

NO >> Repair harness or connector.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect video monitor connector.
3. Check continuity between video monitor harness connector B76 and ground.

Connector	Terminal	—	Continuity
B76	12	Ground	Yes
	15		



Does continuity exist?

YES >> Inspection End.

NO >> Repair harness or connector.

BLUETOOTH CONTROL UNIT

BLUETOOTH CONTROL UNIT : Diagnosis Procedure

INFOID:000000007347737

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1.CHECK FUSE

Check that the following fuses of the Bluetooth control unit are not blown.

Power source	Fuse No.
Battery	29
Ignition switch ACC or ON	4
Ignition switch ON or START	12

Are the fuses OK?

YES >> GO TO 2

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT


POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

Check voltage between Bluetooth control unit harness connector and ground.

(+)		(-)	OFF	ACC	ON
Connector	Terminal				
B124	1	Ground	Battery voltage	Battery voltage	Battery voltage
	2		0V	Battery voltage	Battery voltage
	3		0V	0V	Battery voltage



Are the voltage results as specified?


YES >> GO TO 3

NO >> Check harness between Bluetooth control unit and fuse.

3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect Bluetooth control unit connector B124.
3. Check continuity between Bluetooth control unit harness connector and ground.

Connector	Terminal	—	Continuity
B124	4	Ground	Yes
	21		
	22		
	24		



Does continuity exist?

YES >> Inspection End.

NO >> Repair harness or connector.

MICROPHONE

MICROPHONE : Diagnosis Procedure

INFOID:000000007347738

Regarding Wiring Diagram information, refer to [AV-225. "Wiring Diagram - Without Navigation System"](#).

1.CHECK POWER SUPPLY CIRCUIT (MICROPHONE SIDE)


Check voltage between microphone harness connector and ground.

(+)		(-)	Value (Approx.)
Connector	Terminal		
R8	4	Ground	5V

Is proper voltage present?

YES >> GO TO 4

NO >> GO TO 2



2.CHECK POWER SUPPLY CIRCUIT (CONTINUITY)

POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect Bluetooth control unit and microphone connectors.
3. Check continuity between microphone harness connector R8 (A) terminal 4 and Bluetooth control unit harness connector B124 (B) terminal 29.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
R8	4	B124	29	Yes

4. Check continuity between microphone harness connector R8 (A) terminal 4 and ground.

A		—	Continuity
Connector	Terminal		
R8	4	Ground	No

Are continuity results as specified?

- YES >> GO TO 3
 NO >> Repair harness or connector.

3. CHECK POWER SUPPLY CIRCUIT (BLUETOOTH CONTROL UNIT SIDE)

1. Connect Bluetooth control unit connector.
2. Turn ignition switch ON.
3. Check voltage between Bluetooth control unit harness connector and ground.

(+)		(-)	Value (Approx.)
Connector	Terminal		
B124	29	Ground	5V

Is proper voltage present?

- YES >> Inspection End.
 NO >> Replace Bluetooth control unit. Refer to [AV-264](#), "Removal and Installation".




4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect Bluetooth control unit and microphone connectors.
3. Check continuity between microphone harness connector R8 terminal 2 and Bluetooth control unit harness connector B124 terminal 8.

Connector	Terminal	Connector	Terminal	Continuity
R8	2	B124	8	Yes

Is continuity present?

- YES >> Inspection End.
 NO >> Repair harness or connector.



RGB (R: RED) SIGNAL CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

RGB (R: RED) SIGNAL CIRCUIT

Description

INFOID:000000007347739

Transmit the image displayed with AV control unit with RGB signal to the display unit.


Diagnosis Procedure

INFOID:000000007347740

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1. CHECK CONTINUITY RGB (R: RED) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M45.
3. Check continuity between display unit harness connector M93 (A) terminal 17 and AV control unit harness connector M45 (B) terminal 40.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	17	M45	40	Yes

4. Check continuity between display unit harness connector M93 (A) terminal 17 and ground.

A		—	Continuity
Connector	Terminal		
M93	17	Ground	No


Are the continuity results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK RGB (R: RED) SIGNAL

1. Connect display unit connector M93 and AV control unit connector M45.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 17 and ground.



(+)		(-)	Condition	Reference signal
Connector	Terminal			
M93	17	Ground	Receive audio signal	<p>SK1B2238J</p>

Are the voltage readings as specified?

YES >> Replace display unit. Refer to [AV-257, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

RGB (G: GREEN) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

RGB (G: GREEN) SIGNAL CIRCUIT

Description

INFOID:000000007347741

Transmit the image displayed with AV control unit with RGB signal to the display unit.

Diagnosis Procedure


INFOID:000000007347742

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1. CHECK CONTINUITY RGB (G: GREEN) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M45.
3. Check continuity between display unit harness connector M93 (A) terminal 6 and AV control unit harness connector M45 (B) terminal 39.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	6	M45	39	Yes



4. Check continuity between display unit harness connector M93 (A) terminal 6 and ground.

A		—	Continuity
Connector	Terminal		
M93	6	Ground	No


Are the continuity results as specified?

- YES >> GO TO 2
 NO >> Repair harness or connector.

2. CHECK RGB (G: GREEN) SIGNAL

1. Connect display unit connector M93 and AV control unit connector M45.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 6 and ground.

(+)		(-)	Condition	Reference signal
Connector	Terminal			
M93	6	Ground	Receive audio signal	



Are voltage readings as specified?

- YES >> Replace display unit. Refer to [AV-257, "Removal and Installation"](#).
 NO >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).

RGB (B: BLUE) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

RGB (B: BLUE) SIGNAL CIRCUIT

Description

INFOID:000000007347743

Transmit the image displayed with AV control unit with RGB signal to the display unit.

Diagnosis Procedure


INFOID:000000007347744

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1. CHECK CONTINUITY RGB (B: BLUE) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M45.
3. Check continuity between display unit harness connector M93 (A) terminal 18 and AV control unit harness connector M45 (B) terminal 38.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	18	M45	38	Yes



4. Check continuity between display unit harness connector M93 (A) terminal 18 and ground.

A		—	Continuity
Connector	Terminal		
M93	18	Ground	No

Are continuity results as specified?


YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK RGB (B: BLUE) SIGNAL

1. Connect display unit connector M93 and AV control unit connector M45.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 18 and ground.

(+) Connector		(-)	Condition	Reference signal
Connector	Terminal			
M93	18	Ground	Receive audio signal	<p>SK1B2237J</p>



Are voltage readings as specified?

YES >> Replace display unit. Refer to [AV-257, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

RGB SYNCHRONIZING SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

RGB SYNCHRONIZING SIGNAL CIRCUIT

Description

INFOID:000000007347745

Transmit the RGB synchronizing signal to the display unit so as to synchronize the RGB image displayed with AV control unit.

Diagnosis Procedure


INFOID:000000007347746

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1. CHECK CONTINUITY RGB SYNCHRONIZING SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M45.
3. Check continuity between display unit harness connector M93 (A) terminal 19 and AV control unit harness connector M45 (B) terminal 41.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	19	M45	41	Yes



4. Check continuity between display unit harness connector M93 (A) terminal 19 and ground.

A		—	Continuity
Connector	Terminal		
M93	19	Ground	No


Are continuity results as specified?

- YES >> GO TO 2
 NO >> Repair harness or connector.

2. CHECK RGB SYNCHRONIZING SIGNAL

1. Connect display unit connector M93 and AV control unit connector M45.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 19 and ground.

(+)		(-)	Condition	Reference signal
Connector	Terminal			
M93	19	Ground	Receive audio signal	



Are voltage readings as specified?

- YES >> Replace display unit. Refer to [AV-257, "Removal and Installation"](#).
 NO >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).

RGB AREA (YS) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

RGB AREA (YS) SIGNAL CIRCUIT

Description

INFOID:000000007347747

Transmits the display area of RGB image displayed by AV control unit with RGB area (YS) signal to display unit.


Diagnosis Procedure

INFOID:000000007347748

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1. CHECK CONTINUITY RGB AREA (YS) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M45.
3. Check continuity between display unit harness connector M93 (A) terminal 9 and AV control unit harness connector M45 (B) terminal 43.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	9	M45	43	Yes

4. Check continuity between display unit harness connector M93 (A) terminal 9 and ground.

A		—	Continuity
Connector	Terminal		
M93	9	Ground	No


Are continuity results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK RGB SYNCHRONIZING SIGNAL

1. Connect display unit connector M93 and AV control unit connector M45.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 9 and ground.



(+) Connector		(-)	Condition	Reference signal
Connector	Terminal			
M93	9	Ground	Receive audio signal	<p>PK1B4948.J</p>

Are voltage readings as specified?

YES >> Replace display unit. Refer to [AV-257, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).

HORIZONTAL SYNCHRONIZING (HP) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

HORIZONTAL SYNCHRONIZING (HP) SIGNAL CIRCUIT

Description

INFOID:000000007347749

In composite image (AUX image, camera image), transmit the vertical synchronizing (VP) signal and horizontal synchronizing (HP) signal from display unit to AV control unit so as to synchronize the RGB images displayed with AV control unit such as the image quality adjusting menu, etc.


Diagnosis Procedure

INFOID:000000007347750

Regarding Wiring Diagram information, refer to [AV-225. "Wiring Diagram - Without Navigation System"](#).

1. CHECK CONTINUITY HORIZONTAL SYNCHRONIZING (HP) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M45.
3. Check continuity between display unit harness connector M93 (A) terminal 8 and AV control unit harness connector M45 (B) terminal 45.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	8	M45	45	Yes

4. Check continuity between display unit harness connector M93 (A) terminal 8 and ground.


A		—	Continuity
Connector	Terminal		
M93	8	Ground	No

Are continuity results as specified?

- YES >> GO TO 2
 NO >> Repair harness or connector.

2. CHECK HORIZONTAL SYNCHRONIZING (HP) SIGNAL

1. Connect display unit connector M93 and AV control unit connector M45.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 8 and ground.



(+) Connector		(-) Terminal	Condition	Reference signal
M93	8	Ground	Receive audio signal	

Are voltage readings as specified?

- YES >> Replace AV control unit. Refer to [AV-255. "Removal and Installation"](#).
 NO >> Replace display unit. Refer to [AV-257. "Removal and Installation"](#).

VERTICAL SYNCHRONIZING (VP) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

VERTICAL SYNCHRONIZING (VP) SIGNAL CIRCUIT

Description

INFOID:000000007347751

In composite image (AUX image, camera image), transmit the vertical synchronizing (VP) signal and horizontal synchronizing (HP) signal from display unit to AV control unit so as to synchronize the RGB images displayed with AV control unit such as the image quality adjusting menu, etc.


Diagnosis Procedure

INFOID:000000007347752

Regarding Wiring Diagram information, refer to [AV-225. "Wiring Diagram - Without Navigation System"](#).

1. CHECK CONTINUITY VERTICAL SINCHRONIZING (VP) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M93 and AV control unit connector M45.
3. Check continuity between display unit harness connector M93 (A) terminal 20 and AV control unit harness connector M45 (B) terminal 57.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M93	20	M45	57	Yes

4. Check continuity between display unit harness connector M93 (A) terminal 20 and ground.

A		—	Continuity
Connector	Terminal		
M93	20	Ground	No


Are continuity results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK VERTICAL SINCHRONIZING (VP) SIGNAL

1. Connect display unit connector M93 and AV control unit connector M45.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M93 terminal 20 and ground.



(+)		(-)	Condition	Reference signal
Connector	Terminal			
M93	20	Ground	Receive audio signal	<p>SK1B3598E</p>

Are voltage readings as specified?

YES >> Replace AV control unit. Refer to [AV-255. "Removal and Installation"](#).

NO >> Replace display unit. Refer to [AV-257. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

FRONT DOOR SPEAKER

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

FRONT DOOR SPEAKER

Description

INFOID:000000007347753

The AV control unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the front door speakers using the audio signal circuits.

Diagnosis Procedure

INFOID:000000007347754

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1.CONNECTOR CHECK

Check the AV control unit, BOSE speaker amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.HARNES CHECK

1. Disconnect BOSE speaker amp. connector B75 and suspect speaker connector.
2. Check continuity between BOSE speaker amp. harness connector B75 (A) and suspect speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B75	13	D12	1	Yes
	14		2	
	15	D112	1	
	16		2	

3. Check continuity between BOSE speaker amp. harness connector B75 (A) and ground.


A		—	Continuity
Connector	Terminal		
B75	13	Ground	No
	14		
	15		
	16		

Are continuity test results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3.FRONT SPEAKER SIGNAL CHECK



ALNIA0530GB

FRONT DOOR SPEAKER

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect BOSE speaker amp. connector B75 and suspect speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B75 terminals with CONSULT or oscilloscope.

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
B75	13	14	Receive audio signal	
	15	16		

Is audio signal voltage as specified?

YES >> Replace suspect speaker. Refer to [AV-259. "Removal and Installation"](#).

NO >> GO TO 4

4. HARNESS CHECK

1. Disconnect AV control unit connector M69 and BOSE speaker amp. connector B75.
2. Check continuity between AV control unit harness connector M69 (A) and BOSE speaker amp. harness connector B75 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M69	113	B75	30	Yes
	119		29	
	109		28	
	115		27	

3. Check continuity between AV control unit harness connector M69 (A) and ground.



A		—	Continuity
Connector	Terminal		
M69	113	Ground	No
	119		
	109		
	115		

Are continuity test results as specified?

YES >> GO TO 5

NO >> Repair harness or connector.

5. FRONT SPEAKER SIGNAL CHECK



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P


AV

FRONT DOOR SPEAKER

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >


1. Connect AV control unit connector and BOSE speaker amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M69 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M69	113	119	Receive audio signal	
	109	115		

SKIA0177E

Are the audio signal voltage readings as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-265, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).



FRONT TWEETER

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

FRONT TWEETER

Description

INFOID:000000007347755

The AV control unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the tweeters using the audio signal circuits.

Diagnosis Procedure

INFOID:000000007347756

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1.CONNECTOR CHECK

Check the AV control unit, BOSE speaker amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.HARNES CHECK

1. Disconnect BOSE speaker amp. connector B75 and suspect tweeter connector.
2. Check continuity between BOSE speaker amp. harness connector B75 (A) and suspect tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B75	13	M109	1	Yes
	14		2	
	15	M111	1	
	16		2	

3. Check continuity between BOSE speaker amp. harness connector B75 (A) and ground.


A		—	Continuity
Connector	Terminal		
B75	13	Ground	No
	14		
	15		
	16		

Are continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3.FRONT TWEETER SIGNAL CHECK



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV


FRONT TWEETER

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect BOSE speaker amp. connector B75 and suspect tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B75 terminals with CONSULT or oscilloscope.

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
B75	13	14	Receive audio signal	
	15	16		



Is audio signal voltage as specified?

YES >> Replace suspect tweeter. Refer to [AV-258. "Removal and Installation"](#).

NO >> GO TO 4

4. HARNESS CHECK

1. Disconnect AV control unit connector M69 and BOSE speaker amp. connector B75.
2. Check continuity between AV control unit harness connector M69 (A) and BOSE speaker amp. harness connector B75 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M69	113	B75	30	Yes
	119		29	
	109		28	
	115		27	

3. Check continuity between AV control unit harness connector M69 (A) and ground.


A		—	Continuity
Connector	Terminal		
M69	113	Ground	No
	119		
	109		
	115		

Are continuity results as specified?

YES >> GO TO 5

NO >> Repair harness or connector.

5. FRONT TWEETER SIGNAL CHECK



FRONT TWEETER

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >


1. Connect AV control unit connector and BOSE speaker amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M69 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M69	113	119	Receive audio signal	
	109	115		

SKIA0177E

Are the audio signal voltage readings as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-265, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

REAR DOOR SPEAKER

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

REAR DOOR SPEAKER

Description

INFOID:000000007347757

The AV control unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the rear door speakers using the audio signal circuits.

Diagnosis Procedure

INFOID:000000007347758

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1. CONNECTOR CHECK

Check the AV control unit, BOSE speaker amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. HARNESS CHECK

1. Disconnect BOSE speaker amp. connectors B75 and suspect speaker connector.
2. Check continuity between BOSE speaker amp. harness connectors B75 (A) and suspect speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B75	9	D207	1	Yes
	10		2	
	11	D307	1	
	12		2	

3. Check continuity between BOSE speaker amp. harness connectors B75 (A) and ground.


Connector	Terminal	-	Continuity
B75	9	Ground	No
	10		
	11		
	12		

Are the continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3. REAR DOOR SPEAKER SIGNAL CHECK



ALNIA0533GB

REAR DOOR SPEAKER


[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect BOSE speaker amp. connectors and suspect speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connectors B75 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B75	9	10	Receive audio signal	
	11	12		

SKIA0177E



Are audio signal voltage readings as specified?

YES >> Replace suspect speaker. Refer to [AV-261, "Removal and Installation of Rear Tweeter"](#).

NO >> GO TO 4


4. HARNESS CHECK

1. Disconnect AV control unit connector M69 and BOSE speaker amp. connector B75.
2. Check continuity between AV control unit harness connector M69 (A) and BOSE speaker amp. harness connector B75 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M69	112	B75	26	Yes
	118		25	
	108		24	
	114		23	

3. Check continuity between AV control unit harness connector M69 (A) and ground.

A		—	Continuity
Connector	Terminal		
M69	112	Ground	No
	118		
	108		
	114		



Are the continuity results as specified?

YES >> GO TO 5

NO >> Repair harness or connector.


5. REAR DOOR SPEAKER SIGNAL CHECK

REAR DOOR SPEAKER

[BOSE AUDIO WITHOUT NAVIGATION]


< DTC/CIRCUIT DIAGNOSIS >

1. Connect AV control unit connector M69 and BOSE speaker amp. connector B75.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M69 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M69	112	118	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
	108	114		

Is the audio signal voltage reading as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-265, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).



REAR TWEETER

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

REAR TWEETER

Description

INFOID:000000007347759

The AV control unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the rear tweeters using the audio signal circuits.

Diagnosis Procedure

INFOID:000000007347760

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1.CONNECTOR CHECK

Check the AV control unit, BOSE speaker amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.


2.HARNES CHECK

1. Disconnect BOSE speaker amp. connectors B75 and suspect tweeter connector.
2. Check continuity between BOSE speaker amp. harness connectors B75 (A) and suspect tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B75	9	D208	1	Yes
	10		2	
	11	D308	1	
	12		2	

3. Check continuity between BOSE speaker amp. harness connectors B75 (A) and ground.

Connector	Terminal	-	Continuity
B75	9	Ground	No
	10		
	11		
	12		



Are the continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3.REAR TWEETER SIGNAL CHECK

REAR TWEETER


[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect BOSE speaker amp. connectors and suspect tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connectors B75 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B75	9	10	Receive audio signal	
	11	12		

SKIA0177E



Are audio signal voltage readings as specified?

YES >> Replace suspect tweeter. Refer to [AV-261, "Removal and Installation of Rear Tweeter"](#).

NO >> GO TO 4


4. HARNESS CHECK

1. Disconnect AV control unit connector M69 and BOSE speaker amp. connector B75.
2. Check continuity between AV control unit harness connector M69 (A) and BOSE speaker amp. harness connector B75 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M69	112	B75	26	Yes
	118		25	
	108		24	
	114		23	

3. Check continuity between AV control unit harness connector M69 (A) and ground.

A		—	Continuity
Connector	Terminal		
M69	112	Ground	No
	118		
	108		
	114		



Are the continuity results as specified?

YES >> GO TO 5

NO >> Repair harness or connector.


5. REAR TWEETER SIGNAL CHECK

REAR TWEETER

[BOSE AUDIO WITHOUT NAVIGATION]


< DTC/CIRCUIT DIAGNOSIS >

1. Connect AV control unit connector M69 and BOSE speaker amp. connector B75.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M69 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M69	112	118	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
	108	114		

Is the audio signal voltage reading as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-265, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

SUBWOOFER

Description

INFOID:000000007347761

The AV control unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the subwoofer using the audio signal circuits.

Diagnosis Procedure

INFOID:000000007347762

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1. CONNECTOR CHECK

Check the AV control unit, BOSE speaker amp. and subwoofer connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. VERIFY SUBWOOFER POWER AND GROUND SUPPLY

Check power and ground supply to the subwoofer. Refer to [AV-166, "SUBWOOFER : Diagnosis Procedure"](#)

Did the power and ground supply check OK?

YES >> GO TO 3

NO >> Repair harness or connector.

3. HARNESS CHECK

1. Disconnect BOSE speaker amp. connectors and subwoofer connector.
2. Check continuity between BOSE speaker amp. harness connectors B74 (A) and B75 (B) and subwoofer harness connector B72 (C).

Connector	Terminal	Connector	Terminal	Continuity
A: B74	3	C: B72	1	Yes
	19		2	
B: B75	22		4	

3. Check continuity between BOSE speaker amp. harness connector B74 (A) and B75 (B) and ground.


Connector	Terminal	-	Continuity
A: B74	3	Ground	No
	19		
B: B75	22		

Are the continuity results as specified?

YES >> GO TO 4

NO >> Repair harness or connector.

4. SUBWOOFER AMP ON SIGNAL CHECK



SUBWOOFER

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect BOSE speaker amp. connector B74.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check voltage between subwoofer connector B72 terminal 4 and ground.

(+)		(-)	Voltage
Connector	Terminal		
B72	4	Ground	Battery voltage


Are the voltage readings as specified?

YES >> GO TO 5

NO >> Replace BOSE speaker amp. Refer to [AV-265, "Removal and Installation"](#).

5.SUBWOOFER AUDIO SIGNAL CHECK

1. Connect BOSE speaker amp. connectors and subwoofer connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B74 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B74	19	3	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>



Is the audio signal voltage as specified?

YES >> Replace subwoofer. Refer to [AV-266, "Removal and Installation"](#).

NO >> GO TO 6

6.HARNESS CHECK

1. Turn ignition switch OFF.



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

SUBWOOFER

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

- Disconnect AV control unit connector M69 and BOSE speaker amp. connector B75.
- Check continuity between AV control unit harness connector M69 (A) and BOSE speaker amp. harness connector B75 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M69	112	B75	26	Yes
	118		25	
	108		24	
	114		23	

- Check continuity between AV control unit harness connector M69 (A) and ground.

A		—	Continuity
Connector	Terminal		
M69	112	Ground	No
	118		
	108		
	114		


Are the continuity results as specified?

YES >> GO TO 7

NO >> Repair harness or connector.

7. BACK DOOR SPEAKER SIGNAL CHECK


- Connect AV control unit connector M69 and BOSE speaker amp. connector B75.
- Turn ignition switch to ACC.
- Push "POWER" switch.
- Check the signal between AV control unit harness connector M69 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M69	112	118	Receive audio signal	
	108	114		


Is the audio signal voltage reading as specified?

YES >> Replace BOSE speaker amp. Refer to [AV-265, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).



ALNIA0538GB



ALNIA0356GB

AMP ON SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

AMP ON SIGNAL CIRCUIT

Description

INFOID:000000007347763

When the audio system is turned on, a voltage signal is supplied from the AV control unit to the BOSE speaker amp. When this signal is received, the BOSE speaker amp. will turn on.

Diagnosis Procedure

INFOID:000000007347764

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).


1. CHECK AMP ON SIGNAL (BOSE SPEAKER AMP)

1. Turn audio system ON.
2. Check voltage between BOSE speaker amp. harness connector B75 terminal 31 and ground.

(+)		(-)	Value (Approx.)
Connector	Terminal		
B75	31	Ground	Battery Voltage

Is battery voltage present?

- YES >> Inspection End.
NO >> GO TO 2




2. CHECK AMP ON SIGNAL (AV CONTROL UNIT)

Check voltage between AV control unit harness connector M69 terminal 110 and ground.

(+)		(-)	Value (Approx.)
Connector	Terminal		
M69	110	Ground	Battery Voltage

Is battery voltage present?

- YES >> Repair harness or connector.
NO >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

STEERING SWITCH

Description

INFOID:000000007347765

When one of the steering wheel AV control switches is pushed, the resistance in the steering wheel AV control switch circuit changes depending on which button is pushed.


Diagnosis Procedure


INFOID:000000007347766

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1. CHECK STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE

1. Turn ignition switch OFF.
2. Disconnect steering wheel audio control switch connector M102.
3. Check resistance between steering switch connector terminals.

Terminal	Signal name	Condition	Resistance (Ω) (Approx.)	
16	17	Seek (down)	Depress ▽ switch.	165
		Volume (down)	Depress VOL down switch.	652
		Mode/End	Depress MODE switch.	0
20	17	Seek (up)	Depress △ switch.	165
		Volume (up)	Depress VOL up switch.	652
		Phone/Send	Depress  switch.	0



Do the steering wheel audio control switches check OK?


YES >> GO TO 2

NO >> Replace steering wheel audio control switch. Refer to [AV-262, "Removal and Installation"](#).

2. CHECK HARNESS

1. Disconnect AV control unit connector M42 and spiral cable connector M30.
2. Check continuity between AV control unit harness connector M42 (A) and spiral cable harness connector M30 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M42	6	M30	24	Yes
	15		31	
	16		32	



3. Check continuity between AV control unit connector M42 (A) and ground.

A		—	Continuity
Connector	Terminal		
M42	6	Ground	No
	15		
	16		

Are the continuity results as specified?

STEERING SWITCH

[BOSE AUDIO WITHOUT NAVIGATION]


< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3
- NO >> Repair harness.

3. SPIRAL CABLE CHECK

1. Disconnect spiral cable connector M102.
2. Check continuity between spiral cable harness connector M30 (A) and M102 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M30	24	M102	20	Yes
	31		17	
	32		16	



Is continuity present?

- YES >> Inspection End.
- NO >> Replace spiral cable. Refer to [SR-7. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

COMMUNICATION SIGNAL CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

COMMUNICATION SIGNAL CIRCUIT SATELLITE RADIO TUNER

SATELLITE RADIO TUNER : Description

INFOID:000000007347767

Communication signals are exchanged between the AV control unit and satellite radio tuner using the communication circuits.

SATELLITE RADIO TUNER : Diagnosis Procedure


INFOID:000000007347768

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1.CHECK HARNESS - 1

1. Turn ignition switch OFF.
2. Disconnect satellite radio tuner (factory installed) connector M41 and AV control unit connector M136.
3. Check continuity between satellite radio tuner (factory installed) harness connector M41 (A) terminal 28 and AV control unit harness connector M136 (B) terminal 28.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M41	28	M136	28	Yes



4. Check continuity between satellite radio tuner (factory installed) harness connector M41 (A) terminal 28 and ground.

A		—	Continuity
Connector	Terminal		
M41	28	Ground	No


Are continuity results as specified?

- YES >> GO TO 2
NO >> Repair harness or connector.

2.CHECK HARNESS - 2

1. Check continuity between satellite radio tuner (factory installed) harness connector M41 (A) terminal 29 and AV control unit harness connector M136 (B) terminal 29.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M41	29	M136	29	Yes



2. Check continuity between satellite radio tuner (factory installed) harness connector M41 (A) terminal 29 and ground.

A		—	Continuity
Connector	Terminal		
M41	29	Ground	No

Are continuity results as specified?

- YES >> GO TO 3
NO >> Repair harness or connector.

COMMUNICATION SIGNAL CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK HARNESS - 3

1. Check continuity between satellite radio tuner (factory installed) harness connector M41 (A) terminal 30 and AV control unit harness connector M136 (B) terminal 30.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M41	30	M136	30	Yes

2. Check continuity between satellite radio tuner (factory installed) harness connector M41 (A) terminal 30 and ground.

A		—	Continuity
Connector	Terminal		
M41	30	Ground	No


Are continuity results as specified?

YES >> GO TO 4

NO >> Repair harness or connector.

4. CHECK REQ1 SIGNAL

1. Connect satellite radio tuner (factory installed) connector and AV control unit connector.
2. Turn ignition switch to ACC
3. Check signal between satellite radio tuner (factory installed) harness connector M41 terminal 28 and ground with CONSULT or oscilloscope.

(+)		(-)	Reference signal
Connector	Terminal		
M41	28	Ground	 <p>SKIB3825E</p>


Are voltage readings as specified?




YES >> GO TO 5

NO >> Replace AV control unit. Refer to [AV-255. "Removal and Installation"](#).

5. CHECK TXD SIGNAL

Check signal between satellite radio tuner (factory installed) harness connector M41 terminal 29 and ground with CONSULT or oscilloscope.

(+)		(-)	Reference signal
Connector	Terminal		
M41	29	Ground	 <p>SKIB3824E</p>



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

COMMUNICATION SIGNAL CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >


Are the voltage readings as specified?


YES >> GO TO 6

NO >> Replace satellite radio tuner. Refer to [AV-273. "Removal and Installation"](#).

6. CHECK RXD SIGNAL

Check signal between satellite radio tuner (factory installed) harness connector M41 terminal 30 and ground with CONSULT or oscilloscope.

(+)		(-)	Reference signal
Connector	Terminal		
M41	30	Ground	 <p style="text-align: center;">SKIB3826E</p>



Are the voltage readings as specified?

YES >> Replace satellite radio tuner. Refer to [AV-273. "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-255. "Removal and Installation"](#).

SOUND SIGNAL CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

SOUND SIGNAL CIRCUIT SATELLITE RADIO TUNER

SATELLITE RADIO TUNER : Description

INFOID:000000007347769

Left and right channel audio signals are supplied from the satellite radio tuner to the AV control unit through the sound signal circuits.

SATELLITE RADIO TUNER : Diagnosis Procedure

INFOID:000000007347770


Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

LEFT CHANNEL

1. CHECK HARNESS

- Turn ignition switch OFF.
- Disconnect satellite radio tuner (factory installed) connector M41 and AV control unit connector M136.
- Check continuity between satellite radio tuner (factory installed) connector M41 (A) and AV control unit connector M136 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M41	21	M43	21	Yes
	22		22	



- Check continuity between satellite radio tuner (factory installed) connector M41 (A) and ground.

A		—	Continuity
Connector	Terminal		
M41	21	Ground	No
	22		

Are continuity results as specified?


YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK LEFT CHANNEL AUDIO SIGNAL

- Connect satellite radio tuner (factory installed) and AV control unit.
- Turn ignition switch ON.
- Check signal between satellite radio tuner (factory installed) connector M41 terminals 21 and 22 with CONSULT or oscilloscope.

(+)		(-)	Reference signal
Connector	Terminal		
M41	22	21	



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

SOUND SIGNAL CIRCUIT

[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

Are voltage readings as specified?


- YES >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).
 NO >> Replace satellite radio tuner. Refer to [AV-273, "Removal and Installation"](#).

RIGHT CHANNEL

1. CHECK HARNESS

- Turn ignition switch OFF.
- Disconnect satellite radio tuner (factory installed) connector M41 and AV control unit connector M136.
- Check continuity between satellite radio tuner (factory installed) M41 (A) and AV control unit M136 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M41	23	M136	23	Yes
	24		24	



- Check continuity between satellite radio tuner (factory installed) connector M41 (A) and ground.

A		—	Continuity
Connector	Terminal		
M41	23	Ground	No
	24		


Are continuity results as specified?

- YES >> GO TO 2
 NO >> Repair harness or connector.

2. CHECK RIGHT CHANNEL AUDIO SIGNAL

- Connect satellite radio tuner (factory installed) and AV control unit.
- Turn ignition switch ON.
- Check signal between satellite radio tuner (factory installed) connector M41 terminals 23 and 24 with CONSULT or oscilloscope.

(+)		(-)	Reference signal
Connector	Terminal		
M41	24	23	<p>The oscilloscope shows a periodic waveform between terminals 23 and 24 of connector M41. The vertical axis is labeled (V) with markings at 1 and -1. The horizontal axis is labeled with a 2ms scale bar. The waveform is a complex, multi-frequency signal. The diagram is labeled SKIB3609E.</p>



Are voltage readings as specified?

- YES >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).
 NO >> Replace satellite radio tuner. Refer to [AV-273, "Removal and Installation"](#).

MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

MICROPHONE SIGNAL CIRCUIT

Description

INFOID:000000007347771

Voice signals are transmitted from the microphone to the Bluetooth control unit using the microphone signal circuits.

Diagnosis Procedure


INFOID:000000007347772

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1. CHECK HARNESS BETWEEN BLUETOOTH CONTROL UNIT AND MICROPHONE

1. Turn ignition switch OFF.
2. Disconnect Bluetooth control unit connector and microphone connector.
3. Check continuity between Bluetooth control unit harness connector B124 (A) and microphone harness connector R8 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B124	7	R8	1	Yes
	8		2	
	29		4	



4. Check continuity between Bluetooth control unit harness connector B124 (A) and ground.

A		—	Continuity
Connector	Terminal		
B124	7	Ground	No
	8		
	29		

Are the continuity test results as specified?

- YES >> GO TO 2
 NO >> Repair harness or connector.


2. CHECK MICROPHONE POWER SUPPLY

1. Connect Bluetooth control unit connector and microphone connector.
2. Turn ignition switch ON.
3. Check voltage between microphone harness connector R8 terminal 4 and ground.

4 - Ground : Approx. 5V

Is voltage reading approx. 5 volts?

- YES >> GO TO 3
 NO >> Replace Bluetooth control unit. Refer to [AV-264, "Removal and Installation"](#).



3. CHECK MICROPHONE SIGNAL

MICROPHONE SIGNAL CIRCUIT



[BOSE AUDIO WITHOUT NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

Check signal between Bluetooth control unit harness connector B124 terminals 7 and 8.

7 - 8:

When giving a voice



Are voltage readings as specified?

- YES >> Replace Bluetooth control unit. Refer to [AV-264, "Removal and Installation"](#).
- NO >> Replace microphone. Refer to [AV-263, "Removal and Installation"](#).

REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

Description

INFOID:000000007347773

Rear view camera signals are transmitted from the rear view camera to the AV control unit using the camera signal circuits.

Diagnosis Procedure

INFOID:000000007347774

Regarding Wiring Diagram information, refer to [AV-225, "Wiring Diagram - Without Navigation System"](#).

1. CHECK CAMERA IMAGE SIGNAL CIRCUIT CONTINUITY

NOTE:

Apply parking brakes before proceeding.

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M134 and rear view camera connector D551.
3. Check continuity between AV control unit harness connector M134 terminals 64, 65, 72 and rear view camera harness connector D551 terminals 3, 5 and 6.

64 - 5 : Continuity should exist.

65 - 6 : Continuity should exist.

72 - 3 : Continuity should exist.

4. Check continuity between AV control unit harness connector M134 terminals 64, 65, 72 and ground.

64, 65, 72 - Ground : Continuity should not exist.

Is inspection result OK?


YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK CAMERA IMAGE SIGNAL

1. Connect AV control unit connector M134 and rear view camera connector D551.
2. Turn ignition switch ON.
3. Shift transmission into reverse.
4. Check signal between AV control unit harness connector M134 terminals 64 and 65.

64 - 65 :



SKIB2251J

Is inspection result OK?

YES >> Replace AV control unit. Refer to [AV-255, "Removal and Installation"](#).

NO >> Replace rear view camera. Refer to [AV-274, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]

ECU DIAGNOSIS INFORMATION

AV CONTROL UNIT

Reference Value


INFOID:000000007347775

VALUES ON THE DIAGNOSIS TOOL

CONSULT data monitor item

Display Item	Display	Vehicle status	Remarks
VHCL SPD SIG	ON	Vehicle speed >0 km/h (0 MPH)	Changes in indication may be delayed. This is normal.
	OFF	Vehicle speed =0 km/h (0 MPH)	
PKB SIG	ON	Parking brake is applied.	Changes in indication may be delayed. This is normal.
	OFF	Parking brake is released.	
ILLUM SIG	ON	Block the light beam from the auto light optical sensor when the light SW is ON .	—
	OFF	Expose the auto light optical sensor to light when the light SW is OFF or ON.	
IGN SIG	ON	Ignition switch ON	—
	OFF	Ignition switch in ACC position	
REV SIG	ON	Selector lever in R position	Changes in indication may be delayed. This is normal.
	OFF	Selector lever in any position other than R	

TERMINAL LAYOUT








PHYSICAL VALUES

Terminal (Wire color)		Description		Condition	Reference value (Approx.)	
+	-	Signal name	Input/ Output			
6 (Y)	15 (L)	Steering switch signal A	Input	Ignition switch ON	Pressing switch	0V
				Pressing switch	0.75V	
				Pressing VOL up switch	2V	
				Except for above	5V	
7 (G/Y)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
9 (V)	Ground	Illumination signal	Input	OFF	Lighting switch is OFF.	0V
				ON	Lighting switch is ON.	Battery voltage

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]







Terminal (Wire color)		Description		Condition	Reference value (Approx.)	
+	-	Signal name	Input/ Output			
15 (L)	Ground	Steering switch signal ground	—	Ignition switch ON	0V	
16 (G)	15 (L)	Steering switch signal B	Input	Ignition switch ON	Pressing MODE switch	0V
					Pressing ▽ switch	0.75V
					Pressing VOL down switch	2V
					Except for above	5V
19 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
20 (B)	Ground	Ground	—	Ignition switch ON	0V	
22 (R)	21 (G)	Satellite radio sound signal LH	Input	Ignition switch ON	When satellite radio mode is selected 	
24 (B)	23 (W)	Satellite radio sound signal RH	Input	Ignition switch ON	When satellite radio mode is selected 	
28 (O)	Ground	Request signal (SAT→CONT)	Input	Ignition switch ON	When satellite radio mode is selected 	
29 (P)	Ground	Communication signal (SAT→CONT)	Input	Ignition switch ON	When satellite radio mode is selected 	
30 (L)	Ground	Communication signal (CONT→SAT)	Output	Ignition switch ON	When satellite radio mode is selected 	

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >





[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
34	—	Antenna main	—	—	—	—
35	—	Antenna B+	—	—	—	—
36 (G)	Ground	AUX image signal	Output	Ignition switch ON	When AUX mode is selected	 <small>SKIB2251J</small>
37 (R)	Ground	AUX image ground	—	Ignition switch ON	—	0V
38 (R)	Ground	RGB signal (B: blue)	Output	Ignition switch ON	Start confirmation/adjustment mode, and then display color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.	 <small>SKIB2237J</small>
39 (B)	Ground	RGB signal (G: green)	Output	Ignition switch ON	Start confirmation/adjustment mode, and then display color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.	 <small>SKIB2236J</small>
40 (W)	Ground	RGB signal (R: red)	Output	Ignition switch ON	Start confirmation/adjustment mode, and then display color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.	 <small>SKIB2238J</small>
41 (R)	Ground	RGB synchronizing signal	Output	Ignition switch ON	—	 <small>SKIB3603E</small>
43 (G)	Ground	RGB area (YS) signal	Output	Ignition switch ON	RGB image	5V
					AUX image	 <small>FKIB4948J</small>

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]





Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
44 (LG)	Ground	Communication signal (DISP→CONT)	Input	Ignition switch ON	When adjusting display brightness	 <p style="text-align: right; font-size: small;">PKIB5039J</p>
45 (B)	Ground	Horizontal synchronizing (HP) signal	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">SKIB3601E</p>
46 (BR)	Ground	Signal ground	—	Ignition switch	—	0V
47 (R)	Ground	Signal VCC	Output	Ignition switch ACC	—	9V
54 (B)	Ground	Ground	—	Ignition switch ON	—	0V
56 (V)	Ground	Communication signal (CONT→DISP)	Output	Ignition switch ON	When adjusting display brightness	 <p style="text-align: right; font-size: small;">PKIB5039J</p>
57 (W)	Ground	Vertical synchronizing (VP) signal	Input	Ignition switch On	—	 <p style="text-align: right; font-size: small;">SKIB3598E</p>
58 (SB)	Ground	Inverter ground	—	Ignition switch ON	—	0V
59 (O)	Ground	Inverter VCC	Output	Ignition switch ACC	—	9V
64 (W)	Ground	Rear view camera video signal ground	—	Ignition switch ON	—	0V

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >





[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
65 (B)	Ground	Rear view camera video in (+)	Input	Ignition switch ON	With rear view camera ON	 <p style="text-align: right; font-size: small;">SKIB2251J</p>
66 (G)	Ground	DVD player video signal (+)	Input	Ignition switch ON	With DVD player operating	 <p style="text-align: right; font-size: small;">SKIB2251J</p>
68 (B)	Ground	Rear view camera signal (ground)	—	Ignition switch ON	—	0V
72	—	Shield	—	—	—	—
74 (R)	Ground	DVD player video ground	—	Ignition switch ON	—	0V
77 (B)	76 (R)	Headphone RH audio signal	Output	Ignition switch ON	With DVD player operating	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
80 (GR)	79 (SB)	Microphone signal	Input	Ignition switch ON	—	—
83 (R)	82 (G)	DVD player audio signal RH	Input	Ignition switch ON	With DVD player operating	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
85 (B)	Ground	Ground	—	Ignition switch ON	—	0V
86 (L)	—	CAN-H	Input/ Output	—	—	—
87 (P)	—	CAN-L	Input/ Output	—	—	—
88 (L)	—	AV communication signal 1 (H)	Input/ Output	—	—	—
89 (P)	—	AV communication signal 1 (L)	Input/ Output	—	—	—

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
90 (L)	—	AV communication signal 2 (H)	Input/ Output	—	—	—
91 (P)	—	AV communication signal 2 (L)	Input/ Output	—	—	—
93 (G)	92 (W)	Headphone LH audio sig- nal	Output	Ignition switch ON	With DVD player operating	
94	—	Shield	—	—	—	—
95 (W)	97 (R)	AUX audio signal RH	Input	Ignition switch ON	When AUX mode is select- ed	
96 (B)	97 (R)	AUX audio signal LH	Input	Ignition switch ON	When AUX mode is select- ed	
98 (W)	99 (B)	DVD player audio signal LH	Input	Ignition switch ON	With DVD player operating	
101 (GR)	Ground	A/C and AV switch assem- bly ground	—	Ignition switch ON	—	0V
103 (SB)	Ground	CD eject signal	Input	—	Pressing the eject switch	0V
					Except for above	3.3V
104 (W/G)	Ground	Ignition signal	Input	Ignition switch ON	—	Battery voltage
105 (W)	Ground	Reverse signal	Input	Ignition switch ON	R position	Battery voltage
					Other than R position	0V
106 (G)	Ground	Parking brake signal	Input	Ignition switch ON	Parking brake ON	0V
					Parking brake OFF	Battery voltage






A
B
C
D
E
F
G
H
I
J
K
L
M

AV

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
107 (LG)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	When vehicle speed is ap- prox. 40 km/h (25MPH)	 <p style="text-align: right; font-size: small;">SKIA6649J</p>
108 (G/R)	114 (B)	Rear RH pre-amp. audio signal	Output	Ignition switch ON	Audio output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
109 (G/Y)	115 (G/O)	Front RH pre-amp. audio signal	Output	Ignition switch ON	Audio output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
110 (SB)	Ground	Amp. ON signal	Output	Ignition switch ON	Audio output	Battery voltage
112 (BR/W)	118 (BR/Y)	Rear LH pre-amp. audio signal	Output	Ignition switch ON	Audio output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
113 (BR)	119 (B)	Front LH pre-amp. audio signal	Output	Ignition switch ON	Audio output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>

DTC Index

INFOID:000000007347776

Self-diagnosis results display item

Error item	Refer to
CAN COMM CIRCUIT [U1000]	AV-150. "DTC Logic"
CONTROL UNIT (CAN) [U1010]	AV-151. "DTC Logic"
Control Unit FLASH-ROM [U1200]	AV-152. "DTC Logic"
CAN CONT [U1216]	AV-153. "DTC Logic"

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]

Error item	Refer to
SWITCH CONN [U1240]	AV-154. "Description"
FRONT DISP CONN [U1243]	AV-155. "DTC Logic"
DVD DECK CONN [U1248]	AV-157. "DTC Logic"
SAT CONN [U1255]	AV-158. "DTC Logic"
HAND FREE CONN [U1256]	AV-159. "Description"
AV COMM CIRCUIT [U1300]	AV-160. "Description"
CONTROL UNIT (AV) [U1310]	AV-161. "DTC Logic"

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P

DISPLAY UNIT

< ECU DIAGNOSIS INFORMATION >


[BOSE AUDIO WITHOUT NAVIGATION]

DISPLAY UNIT

Reference Value

INFOID:000000007347777

TERMINAL LAYOUT








PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
1 (B)	Ground	Ground	—	Ignition switch ON	—	0V
2 (O)	Ground	Inverter VCC	Input	Ignition switch ACC	—	9V
3 (R)	Ground	Signal VCC	Input	Ignition switch ACC	—	9V
4 (R)	Ground	AUX image ground	—	Ignition switch ON	—	0V
6 (B)	Ground	RGB signal (G: green)	Input	Ignition switch ON	Start confirmation/adjust- ment mode, and then dis- play color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNO- SIS screen.	<p>SKIB2236J</p>
8 (B)	Ground	Horizontal synchronizing (HP) signal	Output	Ignition switch ON	—	<p>SKIB3601E</p>

DISPLAY UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]



Terminal (Wire color)		Description		Condition	Reference value (Approx.)
+	-	Signal name	Input/ Output		
9 (G)	Ground	RGB area (YS) signal	Input	Ignition switch ON	At RGB image displayed 5V
				At rear view camera image displayed	 PKIB4948J
11 (V)	Ground	Communication signal (CONT→DISP)	Input	Ignition switch ON	When adjusting display-brightness  PKIB5039J
13 (SB)	Ground	Inverter ground	—	Ignition switch ON	— 0V
14 (BR)	Ground	Signal ground	—	Ignition switch ON	— 0V
15 (G)	—	AUX image synchronizing signal	Input	—	—
17 (W)	Ground	RGB signal (R: red)	Input	Ignition switch ON	Start confirmation/adjustment mode, and then display color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.  SKIB2238J
18 (R)	Ground	RGB signal (B: blue)	Input	Ignition switch ON	Start confirmation/adjustment mode, and then display color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.  SKIB2237J
19 (R)	Ground	RGB synchronizing signal	Input	Ignition switch ON	—  SKIB3603E

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

DISPLAY UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
20 (W)	Ground	Vertical synchronizing (VP) signal	Output	Ignition switch On	—	 <p style="text-align: right; font-size: small;">SKIB3598E</p>
22 (LG)	Ground	Communication signal (DISP→CONT)	Output	Ignition switch ON	When adjusting display-brightness	 <p style="text-align: right; font-size: small;">PKIB5039J</p>

BOSE SPEAKER AMP

< ECU DIAGNOSIS INFORMATION >


[BOSE AUDIO WITHOUT NAVIGATION]

BOSE SPEAKER AMP

Reference Value

INFOID:000000007347778

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
1 (Y)	Ground	Battery power	Input	—	—	Battery voltage
9 (B)	10 (G)	Audio signal rear door speaker and tweeter LH	Output	Ignition switch ON	Audio output	 SKIB3609E
11 (GR)	12 (O)	Audio signal rear door speaker and tweeter RH	Output	Ignition switch ON	Audio output	 SKIB3609E
13 (LG)	14 (L)	Audio signal front door speaker and tweeter LH	Output	Ignition switch ON	Audio output	 SKIB3609E
15 (W)	16 (R)	Audio signal front door speaker and tweeter RH	Output	Ignition switch ON	Audio output	 SKIB3609E






A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

BOSE SPEAKER AMP

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
17 (B)	Ground	Ground	—	Ignition switch ON	—	0V
19 (SB)	3 (B)	Audio signal subwoofer	Output	Ignition switch ON	Audio output	
22 (Y)	Ground	Subwoofer amp. ON signal	Output	Ignition switch ACC	Audio output	Battery voltage
24 (G/R)	23 (B)	Audio signal rear RH	Input	Ignition switch ON	Audio input	
26 (BR/W)	25 (BR/Y)	Audio signal rear LH	Input	Ignition switch ON	Audio input	
28 (G/Y)	27 (G/O)	Audio signal front RH	Input	Ignition switch ON	Audio input	
30 (BR)	29 (B)	Audio signal front LH	Input	Ignition switch ON	Audio input	
31 (SB)	Ground	Amp. ON signal	Input	Ignition switch ON	Audio output	Battery voltage

SATELLITE RADIO TUNER


< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]

SATELLITE RADIO TUNER

Reference Value

INFOID:000000007347779



PHYSICAL VALUES


Terminal		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/Output			
22 (R)	21 (G)	Satellite radio sound signal LH	Output	Ignition switch ON	When satellite radio mode is selected	<p>SKIB3609E</p>
24 (B)	23 (W)	Satellite radio sound signal RH	Output	Ignition switch ON	When satellite radio mode is selected	<p>SKIB3609E</p>
28 (O)	Ground	Request signal (SAT→CONT)	Output	Ignition switch ON	When satellite radio mode is selected	<p>SKIA9299J</p>
29 (P)	Ground	Communication signal (SAT→CONT)	Output	Ignition switch ON	When satellite radio mode is selected	<p>SKIA9300J</p>

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

SATELLITE RADIO TUNER

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]

Terminal		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
30 (L)	Ground	Communication signal (CONT→SAT)	Input	Ignition switch ON	When satellite radio mode is selected	 <p style="text-align: right; font-size: small;">SKIA9301J</p>
32 (R/B)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
36 (G/B)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
37	—	Satellite antenna	Input	—	—	—

DVD PLAYER


< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]

DVD PLAYER

Reference Value

INFOID:000000007347780





PHYSICAL VALUES

Terminal		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/Output			
1 (B)	2 (W)	DVD audio signal LH	Output	Ignition switch ON	With operation of the DVD player	<p>SKIB3609E</p>
5 (B)	Ground	Ground	—	Ignition switch ON	—	0V
6 (BR)	Ground	Illumination control (pulse width modulated)	—	—	With lighting switch ON	—
7 (L)	Ground	CAN communication	Input/Output	Ignition switch ON	—	—
9 (BR)	Ground	Video monitor power supply	Output	Ignition switch ON	With DVD player operation	12V
10 (GR)	Ground	Switch power	Output	Ignition switch ON	With DVD player operation	5V
12 (W/L)	Ground	VTR (+)	Output	Ignition switch ON	With DVD player operation	—
13 (O/L)	Ground	VTR (-)	Output	Ignition switch ON	With DVD player operation	—
14 (Y)	Ground	Display ground	—	Ignition switch ON	With DVD player operation	0V
16 (V)	—	Data receive	Input	—	—	—

DVD PLAYER

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITHOUT NAVIGATION]

Terminal		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
17 (R)	18 (G)	DVD audio signal RH	Output	Ignition switch ON	With DVD player operation	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
21 (Y)	Ground	Battery power	Input	—	—	12V
22 (SB)	Ground	Illumination power	Input	—	With instrument illumination ON	12V
23 (P)	Ground	CAN communication	Input/ Output	Ignition switch ON	—	0V
24 (G/B)	Ground	ACC power	Input	Ignition switch ACC or ON	—	12V
26 (P)	Ground	Ground	Input	Ignition switch ON	—	0V
28 (G)	Ground	Video out	Input	Ignition switch ACC or ON	—	 <p style="text-align: right; font-size: small;">SKIB2251J</p>
32 (LG)	—	Data transmit	Output	—	—	—

BLUETOOTH CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[BOSE AUDIO WITHOUT NAVIGATION]

BLUETOOTH CONTROL UNIT

Reference Value

INFOID:000000007347781

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-			Ignition switch	Operation	
1 (R/Y)	Ground	Battery power	Input	-	-	Battery voltage
2 (G/Y)	Ground	ACC power	Input	ACC/ON	-	Battery voltage
3 (W/G)	Ground	IGN power	Input	ON/ START	-	Battery voltage
4 (B)	-	Ground	-	-	-	-
7 (R)	-	Mic-in signal	Input	-	-	-
8	-	Shield	-	-	-	-
9 (GR)	10 (SB)	Audio out	Output	ACC/ON	Bluetooth control unit sends audio signal	<p>SKIB3609E</p>
21 (B)	-	Ground	-	-	-	-
22 (B)	-	Ground	-	-	-	-
24 (B)	-	Ground	-	-	-	-
28 (SB)	Ground	Vehicle speed input signal (8- pulse)	Input	ON	When vehicle speed is approx. 40 km/h (25 mph)	<p>PKIA1935E</p>
29 (G)	Ground	Microphone power	Output	ON	With Bluetooth ON	5V

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

BLUETOOTH CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[BOSE AUDIO WITHOUT NAVIGATION]

Terminal (Wire color)		Item	Signal input/ output	Condition		Reference value (Approx.)
+	-			Ignition switch	Operation	
33 (B)	-	Bluetooth an- tenna	-	-	-	-
34 (B)	-	Bluetooth an- tenna	-	-	-	-
35 (L)	-	M-CAN H	-	-	-	-
36 (P)	-	M-CAN L	-	-	-	-

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >




BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >

WD: WITH DVD ENTERTAINMENT SYSTEM




ABNWA1332GB

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >




* : THIS CONNECTOR IS NOT SHOWN IN "HARNES LAYOUT" OF PG SECTION.

ABNWA1333GB

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >




ABNWA1523GB

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

BOSE AUDIO SYSTEM CONNECTORS - WITHOUT NAVIGATION SYSTEM

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	L	-
3	G	-(WITH BOSE AUDIO SYSTEM)

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2P	W/G	-
4P	G/B	-
16P	R/B	-

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	G	-
6	R	-
7	SHIELD	-

Connector No.	M30
Connector Name	COMBINATION SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
24	Y	STRG SW A (UP)
31	L	GND
32	G	STRG SW B (DOWN)

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	LG	SPEED OUT 8

ABNIA2618GB


BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
54G	SB	-
77G	Y	-


Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
41M	G	-
42M	GR	-
47M	SB	-
49M	G/Y	-
50M	R	-
65M	G/Y	-
71M	GR	-
72M	O	-

Terminal No.	Color of Wire	Signal Name
2M	R/Y	-
5M	SHIELD	-
8M	B	-
9M	W	-
31M	SB	-
32M	L	-
33M	P	-
35M	L	-
36M	P	-
37M	W/G	-
39M	SHIELD	-

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABNIA2619GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV


BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
39J	BR/Y	-
41J	BR	-
42J	W	-
43J	R	-
45J	SB	-
46J	G/R	-
47J	G/O	-
49J	BR/W	-
50J	B	-
79J	R/B	-(WITHOUT BASE AUDIO SYSTEM)

Terminal No.	Color of Wire	Signal Name
1J	R	-
2J	L	-
3J	GR	-(WITH BOSE AUDIO SYSTEM)
6J	W	-
7J	LG	-
8J	O	-(WITH BOSE AUDIO SYSTEM)
9J	Y	-
32J	B	-
33J	G	-
36J	B	-
38J	G/Y	-



Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
25	-	-
26	-	-
27	-	-
28	O	REQ (TO HU)
29	P	TX (FROM HU)
30	L	RX (TO HU)
31	-	-
32	R/B	BACKUP
33	-	-
34	-	-
35	-	-
36	G/B	ACC

Connector No.	M41
Connector Name	SATELLITE RADIO TUNER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	G	SAT LCH (-)
22	R	SAT LCH (+)
23	W	SAT RCH (-)
24	B	SAT RCH (+)

ABNIA3327GB


BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
7	G/Y	ACC
8	-	-
9	V	ILL+
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	L	STRG SW GND
16	G	STRG SW B
17	-	-
18	-	-
19	Y	+B
20	B	GND


Connector No.	M42
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITHOUT NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-
4	-	-
5	-	-
6	Y	STRG SW A

Terminal No.	Color of Wire	Signal Name
26	-	-
27	-	-
28	O	REQ1 (TO HU)
29	P	RX (TO HU)
30	L	TX (FROM HU)
31	-	-
32	-	-

Connector No.	M43
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITHOUT NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	G	N BUS LH-
22	R	N BUS LH+
23	W	N BUS RH-
24	B	N BUS RH+
25	-	-

Connector No.	M44
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITHOUT NAVI)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
33	-	-
34	-	ANT MAIN
35	-	ANT +B

ABNIA2621GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

BOSE AUDIO SYSTEM


[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
55	-	-
56	V	IT DISP
57	W	VP
58	SB	INV GND
59	O	INV VCC


Terminal No.	Color of Wire	Signal Name
42	-	-
43	G	YS
44	LG	DISP IT
45	B	HP
46	BR	SIG GND
47	R	SIG VCC
48	-	-
49	-	-
50	-	-
51	-	-
52	-	-
53	-	-
54	B	GND

Connector No.	M45
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITHOUT NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
36	G	COMP OUT+
37	R	COMP OUT-
38	R	B
39	B	G
40	W	R
41	R	RGB SYNC

Connector No.	M56
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
3	L	-
4	G	-
6	R	-
9	R	-
10	W	-
11	B	-
12	L	-
13	P	-
16	G/B	-

Terminal No.	Color of Wire	Signal Name
66	G	COMP1 IN+
67	-	-
68	B	RV CAM SIG
69	-	-
70	-	-
71	-	-
72	SHIELD	COMP IN SHIELD
73	-	-
74	R	COMP1 IN-
75	-	-

Connector No.	M46
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITHOUT NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
60	-	-
61	-	-
62	-	-
63	-	-
64	W	VTR -
65	B	VTR +

ABNIA3328GB


BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
114	B	RR RH PRE-
115	G/O	FR RH PRE-
116	-	-
117	-	-
118	BR/Y	RR LH PRE-
119	B	FR LH PRE-

Connector No.	M69
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITHOUT NAV)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
108	G/R	RR RH PRE+
109	G/Y	FR RH PRE+
110	SB	AMP ON
111	-	-
112	BR/W	RR LH PRE+
113	BR	FR LH PRE+

Connector No.	M64
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	Y	-

Terminal No.	Color of Wire	Signal Name
101	GR	SW GND
102	-	-
103	SB	CD EJECT
104	W/G	IGN
105	W	REVERSE SIG
106	G	PKB SIG
107	LG	SPEED 8P

Terminal No.	Color of Wire	Signal Name
85	B	GND
86	L	CAN-H
87	P	CAN-L
88	L	M CAN1 H
89	P	M CAN1 L
90	L	M CAN2 H
91	P	M CAN2 L
92	W	HP LH-
93	G	HP LH+
94	SHIELD	HP SHIELD
95	W	AUX AUDIO RH+
96	B	AUX AUDIO LH+
97	R	AUX GND
98	W	AUDIO BUS LH-
99	B	AUDIO BUS LH+
100	-	-

Connector No.	M70
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITHOUT NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
76	R	HP RH-
77	B	HP RH+
78	-	-
79	SB	TEL VOICE (TO IT)-
80	GR	TEL VOICE (TO IT)+
81	-	-
82	G	AUDIO BUS RH-
83	R	AUDIO BUS RH+
84	-	-

ABNIA3329GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]


< WIRING DIAGRAM >

Connector No.	M78
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	R	-
11	W	-(WITH BOSE AUDIO SYSTEM)

Connector No.	M73
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	-	-

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-

Connector No.	M85
Connector Name	AUX IN JACK
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	AUX AUDIO RH+
2	R	AUX GND
4	B	AUX AUDIO LH+


ABNIA3330GB

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >


Connector No.	M98
Connector Name	A/C AND AV SWITCH ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	G/Y	ACC
3	LG	ILL
4	BR	ILL CONT GND
5	L	M CAN1-H
6	P	M CAN1-L
7	GR	SW GND
8	SB	CD DVD EJECT
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	Y	RR DEFOG

Terminal No.	Color of Wire	Signal Name
6	B	G
7	-	-
8	B	HP
9	G	YS
10	-	-
11	V	IT DISP
12	-	-
13	SB	INV GND
14	BR	SIG GND
15	G	COMP IN SYNC
16	-	-
17	W	R
18	R	B
19	R	RGB SYNC
20	W	VP
21	-	-
22	LG	DISP IT
23	-	-
24	-	-

Connector No.	M93
Connector Name	DISPLAY UNIT (WITHOUT NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	O	INV VCC
3	R	SIG VCC
4	R	COMP IN-
5	-	-

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	W	-
2	L	-

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-
2	L	-

Connector No.	M102
Connector Name	COMBINATION SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
16	L	-
17	BR	-
20	W	-

ABNIA2625GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]


< WIRING DIAGRAM >

Connector No.	M129
Connector Name	SATELLITE RADIO TUNER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
37	-	-

Connector No.	M201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	G	-
3	L	-
4	G	-
6	R	-
9	R	-
10	W	-
11	B	-
12	L	-
13	P	-
16	G/B	-

Connector No.	M202
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	Y	-

Connector No.	M205
Connector Name	DVD PLAYER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	FES L+ OUTPUT
2	W	FES L- OUTPUT
3	-	-
4	-	-

Terminal No.	Color of Wire	Signal Name
5	B	GND
6	BR	ILL-
7	L	M CAN2 H
8	-	-
9	BR	+B
10	GR	SW POWER +5
11	-	-
12	W/L	VTR+
13	O/L	VTR-
14	Y	GND
15	-	-
16	V	DATA RX1 (LCD->DVD)
17	R	FES R+ OUTPUT
18	G	FES R- OUTPUT

Terminal No.	Color of Wire	Signal Name
19	-	-
20	-	-
21	Y	+B
22	SB	ILL+
23	P	M CAN2 L
24	G/B	ACC
25	-	-
26	P	GND
27	-	-
28	G	VIDEO OUT
29	-	-
30	-	-
31	-	-
32	LG	DATA TX1 (DVD->LCD)

ABNIA3332GB

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >

Connector No.	M350
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	-	-

Terminal No.	Color of Wire	Signal Name
1	Y	-
2	GR	-
4	V	-
5	LG	-
6	BR	-
9	O/L	-
10	W/L	-
11	B	-
14	P	-

Connector No.	M210
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M502
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

Connector No.	M501
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

Connector No.	M351
Connector Name	SATELLITE ANTENNA
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	-	-

ABNIA2627GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]


< WIRING DIAGRAM >

Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	9	Color of Wire	LG	Signal Name	-
--------------	---	---------------	----	-------------	---

Connector No.	M602
Connector Name	ANTENNA AMP.
Connector Color	GRAY



Terminal No.	2	Color of Wire	-	Signal Name	-
3	-	-	-	-	-

Connector No.	M601
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Terminal No.	2	Color of Wire	-	Signal Name	-
3	-	-	-	-	-

Connector No.	E53
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK




Terminal No.	1	Color of Wire	G	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	E45
Connector Name	BACK-UP LAMP RELAY
Connector Color	BROWN



Terminal No.	1	Color of Wire	LG	Signal Name	-
2	-	W/G	-	-	-
3	-	SB	-	-	-
5	-	W/G	-	-	-

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	1	Color of Wire	G	Signal Name	-
--------------	---	---------------	---	-------------	---


ABNIA2628GB

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]


< WIRING DIAGRAM >

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
16	W/G	REVERSE LAMP

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
54G	SB	-
77G	Y	-

Connector No.	F9
Connector Name	A/T ASSEMBLY
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
7	LG	-

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	LG	-

Connector No.	F502
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
7	O	REV LAMP RLY

Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	B	-(WITH BOSE AUDIO SYSTEM)
12	G	-(WITH BOSE AUDIO SYSTEM)

ABNIA2629GB

BOSE AUDIO SYSTEM


[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >


Terminal No.	Color of Wire	Signal Name
38J	G/Y	-
39J	BR/Y	-
41J	BR	-
42J	W	-
43J	R	-
45J	SB	-
46J	G/R	-
47J	G/O	-
49J	BR/W	-
50J	B	-
79J	R/B	-(WITHOUT BASE AUDIO SYSTEM)

Terminal No.	Color of Wire	Signal Name
1J	R	-
2J	L	-
3J	GR	-(WITH BOSE AUDIO SYSTEM)
6J	W	-
7J	LG	-
8J	O	-(WITH BOSE AUDIO SYSTEM)
9J	Y	-
32J	B	-
33J	G	-
36J	B	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B74
Connector Name	BOSE SPEAKER AMP.
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	Y	BATT
2	-	-
3	B	WOOFER-
4	-	-
17	B	GND
18	-	-
19	SB	WOOFER+
20	-	-

Connector No.	B72
Connector Name	SUBWOOFER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	WOOFER-
2	SB	WOOFER+
4	Y	AMP ON
5	B	GND
6	R/B	BATT


ABNIA2630GB

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]


< WIRING DIAGRAM >

Connector No.	B77
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	GR	-
4	V	-
5	LG	-
6	BR	-
9	O/L	-
10	W/L	-
11	B	-
14	P	-

Connector No.	B76
Connector Name	VIDEO MONITOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	FES L CH INPUT-
2	G	FES L CH INPUT+
3	B	FES R CH INPUT-
4	R	FES R CH INPUT+
5	GR	SW POWER +5
6	-	-
7	O/L	VIDEO IN-
8	W/L	VIDEO IN+
9	-	-
10	-	-
11	-	-
12	Y	GND
13	LG	DATA RX (DVD->LCD)
14	V	DATA TX (DVD->DVD)
15	P	GND
16	BR	FILTERED BATT

Connector No.	B75
Connector Name	BOSE SPEAKER AMP.
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
5	-	-
6	-	-
7	-	-
8	-	-
9	B	RR DR LH+ OUT
10	G	RR DR LH- OUT
11	GR	RR DR RH+ OUT
12	O	RR DR RH- OUT
13	LG	FR DR LH+ OUT
14	L	FR DR LH- OUT
15	W	FR DR RH+ OUT
16	R	FR DR RH- OUT
21	-	-
22	Y	WOOFER CTRL
23	B	RR RH-(IN)
24	G/R	RR RH+(IN)
25	BR/Y	RR LH-(IN)
26	BR/W	RR LH+(IN)
27	G/O	FR RH-(IN)
28	G/Y	FR RH+(IN)
29	B	FR LH-(IN)
30	BR	FR LH+(IN)
31	SB	AMP ON
32	-	-

ABNIA2631GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P




BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]


< WIRING DIAGRAM >

Connector No.	B107
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-
5	G/Y	-
6	SHIELD	-

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

Terminal No.	Color of Wire	Signal Name
18	-	-
19	-	-
20	-	-
21	B	CONT 2
22	B	CONT 3
23	-	-
24	B	CONT 5
25	-	-
26	-	-
27	-	-
28	SB	SPEED SIGNAL
29	G	MIC POWER
30	-	-
31	-	-
32	-	-

Terminal No.	Color of Wire	Signal Name
4	B	GND
5	-	-
6	-	-
7	R	MIC IN+
8	SHIELD	MIC IN-
9	GR	AUDIO OUT+
10	SB	AUDIO OUT-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	-	-
17	-	-

Connector No.	B124
Connector Name	BLUETOOTH CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/Y	BATT
2	G/Y	ACC
3	W/G	IGN

ABNIA2632GB

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >


Connector No.	B134
Connector Name	BLUETOOTH CONTROL UNIT
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
33	B	BT ANTENNA
34	B	BT ANTENNA SHLD

Terminal No.	Color of Wire	Signal Name
37	-	-
38	-	-
39	-	-
40	-	-
41	-	-
42	-	-

Connector No.	B125
Connector Name	BLUETOOTH CONTROL UNIT
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
35	L	M CAN1 H
36	P	M CAN1 L

Terminal No.	Color of Wire	Signal Name
41M	G	-
42M	GR	-
47M	SB	-
49M	G/Y	-
50M	R	-
65M	G/Y	-
71M	GR	-
72M	O	-

Terminal No.	Color of Wire	Signal Name
2M	R/Y	-
5M	SHIELD	-
8M	B	-
9M	W	-
31M	SB	-
32M	L	-
33M	P	-
35M	L	-
36M	P	-
37M	W/G	-
39M	SHIELD	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABNIA3333GB


A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
2	L/R	-
3	L/W	-

Connector No.	F8
Connector Name	MICROPHONE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	MIC OUT +
2	SHIELD	MIC OUT -
4	G	MIC POWER

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	-
6	R	-
7	SHIELD	-

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	L/B	-
11	W/B	-

Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

ABNIA2634GB

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]

< WIRING DIAGRAM >

Connector No.	D208
Connector Name	REAR TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	O	-

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH (WITH BOSE AUDIO SYSTEM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	O	-

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

Connector No.	D308
Connector Name	REAR TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	O	-

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH (WITH BOSE AUDIO SYSTEM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	O	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

ABNIA2635GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

BOSE AUDIO SYSTEM

[BOSE AUDIO WITHOUT NAVIGATION]


< WIRING DIAGRAM >

Connector No.	D550
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
3	G/Y	-
6	W	-
7	B	-
8	SHIELD	-

Connector No.	D451
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
3	G/Y	-
6	W	-
7	B	-
8	SHIELD	-

Connector No.	D450
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-
5	G/Y	-
6	SHIELD	-

Connector No.	D551
Connector Name	REAR VIEW CAMERA
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	G/Y	ACC
3	SHIELD	DRAIN
5	W	CAMERA -
6	B	CAMERA +

ABNIA2636GB

AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

SYMPTOM DIAGNOSIS

AUDIO SYSTEM

Symptom Table

INFOID:000000007347783

AUDIO SYSTEM

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> AV control unit power supply and ground circuit AV control unit 	<ul style="list-style-type: none"> AV-162 AV-141
Steering switch does not operate	<ul style="list-style-type: none"> Steering switch AV control unit 	<ul style="list-style-type: none"> AV-196 AV-141
All speakers do not sound	<ul style="list-style-type: none"> Speaker circuit shorted to ground AV control unit BOSE speaker amp. ON signal BOSE speaker amp. power supply and ground circuit BOSE speaker amp. 	<ul style="list-style-type: none"> AV-225 AV-141 AV-195 AV-165 AV-265
One or several speakers do not sound	<ul style="list-style-type: none"> Front door speaker Front tweeter Rear door speaker Rear tweeter Subwoofer 	<ul style="list-style-type: none"> AV-180 AV-183 AV-186 AV-189 AV-192
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

CD

Symptom	Possible cause	Reference page
CD cannot be inserted.	AV control unit	AV-141
CD cannot be ejected.		
The CD cannot be played.		
The sound skips, stops suddenly, or is distorted.		

SATELLITE RADIO

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> Satellite radio tuner power supply and ground circuit Satellite radio tuner communication circuit Satellite radio tuner 	<ul style="list-style-type: none"> AV-166 AV-198 AV-273
Right or left channel does not sound	<ul style="list-style-type: none"> Satellite radio tuner audio signal circuit Satellite radio tuner 	<ul style="list-style-type: none"> AV-201 AV-273

DVD PLAYER

Symptom	Possible cause	Reference page
DVD player inoperative	<ul style="list-style-type: none"> DVD player power supply and ground circuit DVD player 	<ul style="list-style-type: none"> AV-168 AV-267
No sound when playing a DVD	<ul style="list-style-type: none"> Audio signal circuits AV control unit DVD player 	<ul style="list-style-type: none"> AV-221 AV-141 AV-267

AUDIO SYSTEM

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

Symptom	Possible cause	Reference page
Video monitor is inoperative/does not display properly	<ul style="list-style-type: none">• Video monitor power supply and ground circuit• Video out circuit• DVD player• Video monitor	<ul style="list-style-type: none">• AV-169• AV-221• AV-267• AV-267
DVD remote control is inoperative/does not operate properly	<ul style="list-style-type: none">• DVD remote control• DVD player	<ul style="list-style-type: none">• AV-267
Headphones inoperative	<ul style="list-style-type: none">• Headphone batteries• DVD player	<ul style="list-style-type: none">• AV-267

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITHOUT NAVIGATION]

NORMAL OPERATING CONDITION

Description

INFOID:000000007347784

The majority of the audio concerns are the result of outside causes (bad CD, electromagnetic interference, etc.).

NOISE

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	<ul style="list-style-type: none"> • Ignition components
The occurrence of the noise is linked with the operation of the fuel pump.		<ul style="list-style-type: none"> • Fuel pump condenser
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	<ul style="list-style-type: none"> • Relay malfunction, AV control unit malfunction
	The noise occurs when various motors are operating.	<ul style="list-style-type: none"> • Motor case ground • Motor
The noise occurs constantly, not just under certain conditions.		<ul style="list-style-type: none"> • Rear defogger coil malfunction • Open circuit in printed heater • Poor ground of antenna feeder line
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		<ul style="list-style-type: none"> • Ground wire of body parts • Ground due to improper part installation • Wiring connections or a short circuit

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007347785

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- **When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.**
- **When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.**

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000007347786

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.

PRECAUTIONS

< PRECAUTION >

[BOSE AUDIO WITHOUT NAVIGATION]

5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT.

Precaution for Work

INFOID:000000007347787

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components.
 - Water soluble dirt: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the dirty area.
Then rub with a soft and dry cloth.
 - Oily dirt: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the dirty area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

PREPARATION

[BOSE AUDIO WITHOUT NAVIGATION]

< PREPARATION >


PREPARATION

PREPARATION

Special Service Tool


INFOID:000000007347788

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim tool set  AWJIA04832Z	Removing trim components

Commercial Service Tools

INFOID:000000007347789

Tool name	Description
Power tool  PIIB1407E	Loosening nuts, screws and bolts

AV CONTROL UNIT

< REMOVAL AND INSTALLATION >


[BOSE AUDIO WITHOUT NAVIGATION]

REMOVAL AND INSTALLATION

AV CONTROL UNIT

Removal and Installation

INFOID:000000007347790



- | | | |
|-----------------------------|----------------------|-------------------------------|
| 1. Cluster lid C | 2. Display unit | 3. AV control unit |
| 4. AV control unit brackets | 5. Tuner knob switch | 6. A/C and AV switch assembly |
| 7. Volume knob switch | 8. Volume knob | 9. Temp knobs RH and LH |
| 10. Enter button | 11. Tuner knob | |

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AV CONTROL UNIT

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]

CAUTION:

Only remove and replace the A/C or AV switch assembly knobs if damaged or missing. The knobs must not be removed from switches when removing and installing the A/C or AV switch assembly to prevent damage to the switch assembly.

REMOVAL

1. Disconnect the battery negative terminal.
2. Remove the cluster lid C. Refer to [IP-16. "Removal and Installation"](#).
3. Remove the AV control unit screws, using a power tool.
4. Remove the AV control unit.
5. Remove the A/C and AV switch assembly screws, then remove the A/C and AV switch assemblies as necessary.

INSTALLATION

Installation is in the reverse order of removal.

DISPLAY UNIT

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]


DISPLAY UNIT

Removal and Installation


INFOID:000000007347791

REMOVAL

1. Remove cluster lid C. Refer to [IP-16. "Removal and Installation"](#).
2. Remove the display unit screws (A).
3. Pull out the display unit (1), then disconnect the display unit connectors and remove the display unit (1).



4. Remove the A/C auto amp screws (A), remove the (C103) fasteners (B) from the display unit assembly brackets and remove the A/C auto amp. (1).
5. Remove the display unit bracket unit screws (C) and remove the display unit brackets (2).



INSTALLATION

Installation is in reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

FRONT TWEETER

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]

FRONT TWEETER

Removal and Installation


INFOID:000000007347792

REMOVAL

CAUTION:

Use a suitable tool to prevent damage to the front tweeter speaker grille trim and the instrument panel.

1. Remove the front tweeter grille.
2. Remove the front tweeter screws (A).
3. Pull out the front tweeter speaker (1) and disconnect front tweeter connector, then remove the front tweeter speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]


FRONT DOOR SPEAKER

Removal and Installation

INFOID:000000007347793

REMOVAL

1. Remove the front door finisher. Refer to [INT-15, "Removal and Installation"](#).
2. Remove the front door speaker screws (A).
3. Pull out the front door speaker (1), and disconnect the front door speaker connector and remove the front door speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]


REAR DOOR SPEAKER

Removal and Installation of Rear Door Speaker

INFOID:000000007347794

REMOVAL

1. Remove the rear door finisher. Refer to [INT-15. "Removal and Installation"](#).
2. Remove the rear door speaker screws (A).
3. Disconnect the rear door speaker connector (B) and remove rear door speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

REAR DOOR TWEETER

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]


REAR DOOR TWEETER

Removal and Installation of Rear Tweeter

INFOID:000000007347795

REMOVAL

1. Remove rear door finisher. Refer to [INT-15. "Removal and Installation"](#).
2. Remove the rear tweeter screws (A) and remove the rear tweeter (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

STEERING SWITCH


< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]

STEERING SWITCH

Removal and Installation

INFOID:000000007347796



1. Steering wheel


2. Steering wheel audio control switches


REMOVAL

1. Remove the driver air bag module. Refer to [SR-5, "Removal and Installation"](#).
2. Remove the steering wheel audio control switch assembly screws.
3. Disconnect the steering wheel audio control switches connector.
4. Remove the steering wheel audio control switches by pulling on steering wheel audio control switches to release the pawls.

CAUTION:

Do not tilt steering wheel audio control switches during removal or damage may occur to the pawls.

-  Pawl



INSTALLATION

Installation is in the reverse order of removal.

MICROPHONE

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]


MICROPHONE

Removal and Installation

INFOID:000000007347797

REMOVAL

1. Remove the front roof console finisher. Refer to [INT-22. "Removal and Installation"](#).
2. Detach the microphone (1) from the front console finisher tabs (A).
3. Disconnect the microphone connector (B) and remove the microphone (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

BLUETOOTH CONTROL UNIT


< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]

BLUETOOTH CONTROL UNIT

Removal and Installation

INFOID:000000007347798



- | | | |
|--------------------------------|----------------------------------|--------------------------------------|
| 1. Bluetooth antenna | 2. Bluetooth control unit | A. Bluetooth control unit connectors |
| B. Bluetooth antenna connector | C. Bluetooth control unit screws | D. Bluetooth antenna screws |

← Vehicle front

REMOVAL

1. Remove the RH front seat. Refer to [SE-33. "Removal and Installation"](#).
2. Disconnect the Bluetooth control unit connectors.
3. Remove the Bluetooth control unit bracket screws and remove the Bluetooth control unit assembly.
4. Remove the Bluetooth control unit screws.
5. Transfer the Bluetooth antenna to the new Bluetooth control unit.

INSTALLATION

Installation is in the reverse order of removal.

BOSE SPEAKER AMP

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]

BOSE SPEAKER AMP


Removal and Installation


INFOID:000000007830127

REMOVAL

NOTE:

Do not remove the LH front seat from the vehicle.

1. Remove LH front seat bolts, disconnect the LH front seat electrical harness connector. Refer to [SE-33](#), "[Removal and Installation](#)".
2. Tilt the LH front seat back to access the BOSE speaker amp. (1), then remove the BOSE speaker amp. screws (B).
 - : Vehicle front
3. Disconnect the Bose speaker amp. connectors (A) and remove Bose speaker amp. (1) from the bracket (2).
4. Then remove the BOSE speaker amp. bracket screws (C) and remove bracket (2).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

SUBWOOFER

< REMOVAL AND INSTALLATION >


[BOSE AUDIO WITHOUT NAVIGATION]

SUBWOOFER

Removal and Installation

INFOID:000000007347800

BOSE SYSTEM



1. Subwoofer

2. Subwoofer connector

Removal

1. Remove the luggage side lower finisher LH. Refer to [INT-25. "Removal and Installation"](#).
2. Remove subwoofer bolts and nuts.
3. Disconnect the subwoofer connector and remove the subwoofer.

Installation

Installation is in the reverse order of removal.

DVD ENTERTAINMENT SYSTEM

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]


DVD ENTERTAINMENT SYSTEM

Removal and Installation of DVD Player

INFOID:000000007347801

REMOVAL

1. Remove the center console assembly. Refer to [IP-22. "Removal and Installation"](#).
2. Disconnect the DVD player connector (A).
3. Remove the DVD player screws (B), then remove the DVD player (1).
4. Remove the DVD player bracket screws and then remove DVD player brackets.



INSTALLATION


Installation is in reverse order of removal.

Removal and Installation of Video Monitor

INFOID:000000007347802

REMOVAL

1. Release the clips and remove the video monitor finisher from headlining.
2. Press the release tabs and remove the cover.
3. Remove the video monitor screws.
4. Gently lower the assembly and disconnect the connector, then remove the video monitor from the headlining.



INSTALLATION

Installation is in reverse order of removal.

AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]

AUDIO ANTENNA

Location of Antenna

INFOID:000000007347803




- | | | |
|---------------------------------------|--|-----------------------------------|
| 1. Antenna amp.
M602 | 2. Window antenna grid connector bracket | 3. Window antenna grid |
| 4. Satellite antenna
M351 | 5. Harness connector
M73, M350 | 6. Satellite antenna feeder |
| 7. Satellite radio tuner
M41, M129 | 8. AV control unit M43, M44 | 9. Harness connector
M78, M501 |
| 10. Harness connector
M502, M601 | 11. Antenna feeder | |

Window Antenna Repair

INFOID:000000007347804

ELEMENT CHECK

1. Attach probe circuit tester (ohm setting) to antenna terminal on each side.




AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]


- When measuring continuity, wrap tin foil around the top of probe. Then, press the foil against the wire with your finger.



2. If an element is broken, no continuity will exist.



3. To locate a break, move probe along element. Tester indication will change abruptly when probe passes the broken point.



ELEMENT REPAIR

Refer to [DEF-45, "Filament Repair"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AUXILIARY INPUT JACK

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]

AUXILIARY INPUT JACK

Removal and Installation

INFOID:000000007347805

Removal

1. Remove the A/T finisher. Refer to [IP-21, "Removal and Installation"](#).
2. Remove the auxiliary input jack.

Installation

Installation is in the reverse order of removal.

ANTENNA AMP.

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]


ANTENNA AMP.

Removal and Installation

INFOID:000000007347806

REMOVAL

1. Remove the luggage side upper and lower RH finishers. Refer to [INT-25. "Removal and Installation"](#).
2. Detach the antenna amp. harness clip (D), disconnect the antenna amp. connector (A), harness connector (B), then remove the antenna amp. screw (C) and remove the antenna amp. (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

SATELLITE RADIO ANTENNA

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]


SATELLITE RADIO ANTENNA

Removal and Installation

INFOID:000000007347807

REMOVAL

1. Remove the front roof console finisher. Refer to [INT-22, "Removal and Installation"](#).
2. Disconnect the satellite antenna connector.
3. Remove the satellite antenna nut.
4. Remove the satellite antenna.



INSTALLATION

Installation is in the reverse order of removal.

SATELLITE RADIO TUNER

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]


SATELLITE RADIO TUNER

Removal and Installation

INFOID:000000007347808

REMOVAL

1. Disconnect the battery negative terminal.
2. Disconnect the satellite radio tuner connectors.
3. Remove satellite radio tuner screws (A), and remove satellite radio tuner from above the parking brake pedal.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

REAR VIEW CAMERA


< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITHOUT NAVIGATION]

REAR VIEW CAMERA

Removal and Installation

INFOID:000000007347809



1. Rear view camera A. Rear view camera connector B. Rear view camera harness clip

REMOVAL

1. Remove the license lamp finisher. Refer to [EXT-23, "Removal and Installation"](#).
2. Disconnect the rear view camera connector.
3. Detach the rear view camera harness clip.
4. Detach the rear view camera to release, then pull out to remove the rear view camera while feeding the rear view camera harness and connector through the back door.

INSTALLATION

Installation is in the reverse order of removal.


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000007347810

OVERALL SEQUENCE



- Reference 1... Refer to [AV-306, "AV CONTROL UNIT : CONSULT Function"](#).
- Reference 2... Refer to [AV-407, "Symptom Table"](#).

DETAILED FLOW

1. CHECK SYMPTOM

Check the malfunction symptoms by performing the following items.

- Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred).
- Check the symptom.

>> GO TO 2

2. SELF-DIAGNOSIS (CONSULT)

1. Connect CONSULT and perform "SELF-DIAGNOSIS" for "MULTI AV".

NOTE:

Skip to step 4 of the diagnosis procedure if "MULTI AV" is not displayed.

2. Check if any DTC No. is displayed in the self-diagnosis results.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

DIAGNOSIS AND REPAIR WORKFLOW

[BOSE AUDIO WITH NAVIGATION]

< BASIC INSPECTION >

Is any DTC displayed?

YES >> GO TO 3

NO >> GO TO 4

3. CHECK SELF-DIAGNOSIS RESULTS (CONSULT)

1. Check the DTC No. indicated in the self-diagnosis results.
2. Perform the relevant diagnosis referring to the DTC No. list. Refer to [AV-376, "DTC Index"](#).

NOTE:

Start with the diagnosis for the CAN communication system if "CAN COMM CIRCUIT [U1000] or CONTROL UNIT (CAN) [U1010]" is displayed.

>> GO TO 5

4. PERFORM DIAGNOSIS BY SYMPTOM

Perform the relevant diagnosis referring to the diagnosis chart by symptom. Refer to [AV-407, "Symptom Table"](#).

>> GO TO 5

5. REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace the identified malfunctioning parts.

NOTE:

Erase the stored self-diagnosis results after repairing or replacing the relevant components if any DTC No. has been indicated in the self-diagnosis results.

>> GO TO 6

6. CHECK AFTER REPAIR

1. Perform self-diagnosis for "MULTI AV" with CONSULT after repairing or replacing the malfunctioning parts.
2. Check if any DTC No. is displayed in the self-diagnosis results.

Is any DTC displayed?

YES >> GO TO 3

NO >> GO TO 7

7. FINAL CHECK

Perform the operation check to confirm that the malfunction symptom is solved or that any other symptoms are present.

Are any symptoms present?

YES >> GO TO 4

NO >> Inspection End.

AUDIO SYSTEM

< SYSTEM DESCRIPTION >


[BOSE AUDIO WITH NAVIGATION]

SYSTEM DESCRIPTION

AUDIO SYSTEM

System Diagram

INFOID:000000007347811



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

System Description

INFOID:000000007347812

AUDIO SYSTEM

AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

The audio system consists of the following components

- AV control unit
- Display unit
- BOSE speaker amp.
- Window antenna
- Steering wheel audio control switches
- A/C and AV switch assembly
- Front door speakers
- Front tweeters
- Rear door speakers
- Rear tweeters
- Subwoofer

When the audio system is on, radio signals are received by the window antenna. The AV control unit then sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the front door speakers, front tweeters, rear door speakers, rear tweeters and the subwoofer. Refer to Owner's Manual for audio system operating instructions.

SATELLITE RADIO SYSTEM

The satellite radio system consists of the following components

- Satellite antenna
- AV control unit

When the satellite radio system is on, radio signals are supplied to the AV control unit from the satellite antenna. The AV control unit then sends audio signals to the BOSE speaker amp. Refer to Owner's Manual for satellite radio system operating instructions.

SPEED SENSITIVE VOLUME SYSTEM

Volume level of this system goes up and down automatically in proportion to the vehicle speed. The control level can be selected by the customer. Refer to Owner's Manual for operating instructions.


AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

Component Parts Location

INFOID:000000007347813



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

- | | | |
|--|--------------------------|--|
| 1. Steering wheel audio control switches | 2. Front tweeter LH M109 | 3. AV control unit M23, M37, M39, M44, M48, M71, M72 |
| 4. A/C and AV switch assembly M98 | 5. Display unit M92 | 6. Front tweeter RH M111 |

AUDIO SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

- | | | |
|---|--|--|
| 7. Aux. jack M85 | 8. Compact Flash insert slot | 9. Front door speaker
LH D12
RH D112 |
| 10. Rear door speaker
LH D207
RH D307 | 11. Rear tweeter
LH D208
RH D308 | 12. Subwoofer B72 |
| 13. BOSE speaker amp B74, B75 (located under driver seat) | 14. Rear view camera D551 | 15. Microphone R8 |


Component Description

INFOID:000000007347814

Part name	Description
AV control unit	Controls audio system and satellite radio system functions
Display unit	<ul style="list-style-type: none"> • Touch screen controls all audio and A/C operations • Displays all audio and climate control related information
BOSE speaker amp.	Receives power (amp ON) and audio signals from AV control unit and outputs audio signals to each speaker.
Steering wheel audio control switches	<ul style="list-style-type: none"> • Audio operation can be operated • Steering wheel audio control switch signal is output to AV control unit
Front door speakers	<ul style="list-style-type: none"> • Outputs audio signal from BOSE speaker amp. • Outputs high, mid and low range sounds
Front tweeters	<ul style="list-style-type: none"> • Outputs audio signal from BOSE speaker amp. • Outputs high range sounds
Rear door speakers	<ul style="list-style-type: none"> • Outputs audio signal from BOSE speaker amp. • Outputs high, mid and low range sounds
Rear tweeters	<ul style="list-style-type: none"> • Outputs audio signal from BOSE speaker amp. • Outputs high range sounds
Subwoofer	<ul style="list-style-type: none"> • Outputs audio signal from BOSE speaker amp. • Outputs low range sounds
Satellite antenna	Audio signal (satellite radio) is received and output to AV control unit.

NAVIGATION SYSTEM

System Diagram



System Description

INFOID:000000007347816

NOTE:


Refer to NAVIGATION System Owner's Manual for system operation.

The navigation system periodically calculates the vehicle's current position according to the following three signals: Travel distance of the vehicle as determined by the vehicle speed sensor, turning angle of the vehicle as determined by the gyroscope (angular velocity sensor), and the direction of vehicle travel as determined by the GPS antenna (GPS information).

The current position of the vehicle is then identified by comparing the calculated vehicle position with map data read from the map data, which is stored in the hard disk drive (HDD) (map-matching), and indicated on the screen with a current-location mark.

By comparing the vehicle position detection results found by the GPS and by map-matching, more accurate vehicle position data can be used.

The current vehicle position will be calculated by detecting the distance the vehicle moved from the previous calculation point and its direction.



TRAVEL DISTANCE

Travel distance calculations are based on the vehicle speed input signal. Therefore, the calculation may become incorrect as the tires wear down. To prevent this, an automatic distance fine adjustment function has been adopted.

TRAVEL DIRECTION

Change in the travel direction of the vehicle is calculated by a gyroscope (angular velocity sensor) and a GPS antenna (GPS information). As the gyroscope and GPS antenna have both merit and demerit, input signals from them are prioritized in each situation. However, this order of priority may change in accordance with more detailed travel conditions so that the travel direction is detected more accurately.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

NAVIGATION SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

Type	Advantage	Disadvantage
Gyroscope (angular velocity sensor)	<ul style="list-style-type: none"> Can detect the vehicle's turning angle quite accurately. 	<ul style="list-style-type: none"> Direction errors may accumulate when the vehicle is driven for long distances without stopping.
GPS antenna (GPS information)	<ul style="list-style-type: none"> Can detect the vehicle's travel direction (North/South/East/West). 	<ul style="list-style-type: none"> Correct direction cannot be detected when the vehicle speed is low.

MAP-MATCHING

Map-matching is a function that repositions the vehicle on the road map when a new location is judged to be the most accurate. This is done by comparing the current vehicle position, calculated by the method described in the position detection principle, with the road map data around the vehicle, read from the map data stored on the HDD.

Therefore, the vehicle position may not be corrected after the vehicle is driven over a certain distance or time in which GPS information is hard to receive. In this case, the current-location mark on the display must be corrected manually.

CAUTION:

The road map data is based on data stored on the HDD.

- In map-matching, alternative routes to reach the destination will be shown and prioritized, after the road on which the vehicle is currently driven has been judged and the current-location mark has been repositioned.

If there is an error in distance and/or direction, the alternative routes will be shown in different order of priority, and the wrong road can be avoided.

If two roads are running in parallel, they are of the same priority. Therefore, the current-location mark may appear on either of them alternately, depending on maneuvering of the steering wheel and configuration of the road.





- Map-matching does not function correctly when the road on which the vehicle is driving is new and not recorded on the HDD, or when the road pattern stored in the map data and the actual road pattern are different due to repair.

When driving on a road not present in the map, the map-matching function may find another road and position the current-location mark on it. Then, when the correct road is detected, the current-location mark may leap to it.

- Effective range for comparing the vehicle position and travel direction calculated by the distance and direction with the road data read from the HDD is limited. Therefore, when there is an excessive gap between the current vehicle position and the position on the map, correction by map-matching is not possible.

GPS (GLOBAL POSITIONING SYSTEM)

GPS (Global Positioning System) has been developed and controlled by the US Department of Defense. The system utilizes GPS satellite (NAVSTAR), sending out radio waves while flying on an orbit around the earth at the height of approx. 21,000 km (13,000 miles). The GPS receiver calculates the vehicle's position in three dimensions (latitude/longitude/altitude) according to the time lag of the radio waves received from four or more GPS satellites (three-dimensional positioning). If radio waves were received only from three GPS satellites, the GPS receiver calculates the vehicle's position in two dimensions (latitude/longitude), utilizing the altitude data calculated previously by using radio waves from four or more GPS satellites (two-dimensional positioning).



NAVIGATION SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

Accuracy of the GPS will deteriorate under the following conditions.

- In two-dimensional positioning, the GPS accuracy will deteriorate when the altitude of the vehicle position changes.
- There may be an error of approximately 10 m (30 ft.) in position detected by three-dimensional positioning, which is more accurate than two-dimensional positioning. The accuracy can be even lower depending on the arrangement of the GPS satellites utilized for the positioning.
- Position detection is not possible when the vehicle is in an area where radio waves from the GPS satellite do not reach, such as in a tunnel, parking lot in a building, and under an elevated highway. Radio waves from the GPS satellites may not be received when some object is located over the GPS antenna.
- Position correction by GPS is not available while the vehicle is stopped.

A

B

C

D

E

F

G

H

I

J

K

L

M

AV

O

P


NAVIGATION SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

Component Parts Location

INFOID:000000007347817



- | | |
|--|--------------------------|
| 1. Steering wheel audio control switches | 2. Front tweeter LH M109 |
| 4. A/C and AV switch assembly M98 | 5. Display unit M92 |

- | |
|--|
| 3. AV control unit M23, M37, M39, M44, M48, M71, M72 |
| 6. Front tweeter RH M111 |

NAVIGATION SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

- | | | |
|---|--|--|
| 7. Aux. jack M85 | 8. Compact Flash insert slot | 9. Front door speaker
LH D12
RH D112 |
| 10. Rear door speaker
LH D207
RH D307 | 11. Rear tweeter
LH D208
RH D308 | 12. Subwoofer B72 |
| 13. BOSE speaker amp B74, B75 (located under driver seat) | 14. Rear view camera D551 | 15. Microphone R8 |

Component Description

INFOID:000000007347818

Part name	Description
AV control unit	<ul style="list-style-type: none"> Controls each operation of the navigation system DVD-ROM drive is built in Voice guidance signal is output to BOSE speaker amp.
BOSE speaker amp.	Voice guidance signal is input from AV control unit, and it is output to speakers.
Tweeter	Voice guidance signal from BOSE speaker amp. is output.
Steering wheel audio control switches	<ul style="list-style-type: none"> Each operation of navigation system can be performed Switch operating signal is output to AV control unit
Microphone	Sends voice signals to AV control unit
GPS antenna	GPS signal is received and is output to AV control unit.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV


REAR VIEW MONITOR SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

REAR VIEW MONITOR SYSTEM

System Diagram



System Description

INFOID:000000007347820

When the shift selector is in the R position, the display unit receives camera image signals from the rear view camera which shows a view to the rear of the vehicle. Lines which indicate the vehicle clearance and distances are also displayed.


REAR VIEW MONITOR SYSTEM

[BOSE AUDIO WITH NAVIGATION]

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000007347821



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

- | | | |
|--|--------------------------|--|
| 1. Steering wheel audio control switches | 2. Front tweeter LH M109 | 3. AV control unit M23, M37, M39, M44, M48, M71, M72 |
| 4. A/C and AV switch assembly M98 | 5. Display unit M92 | 6. Front tweeter RH M111 |

REAR VIEW MONITOR SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

- | | | |
|---|--|--|
| 7. Aux. jack M85 | 8. Compact Flash insert slot | 9. Front door speaker
LH D12
RH D112 |
| 10. Rear door speaker
LH D207
RH D307 | 11. Rear tweeter
LH D208
RH D308 | 12. Subwoofer B72 |
| 13. BOSE speaker amp B74, B75 (located under driver seat) | 14. Rear view camera D551 | 15. Microphone R8 |

Component Description

INFOID:000000007347822

Part name	Description
AV control unit	<ul style="list-style-type: none">• Receives reverse signal from back-up lamp relay• Sends camera ON signal to rear view camera
Rear view camera	<ul style="list-style-type: none">• Receives camera ON signal from AV control unit• Sends image signal to the display unit
Display unit	<ul style="list-style-type: none">• Receives image signal from rear view camera


DVD PLAYER

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

DVD PLAYER

System Diagram



System Description

INFOID:000000007347824

The DVD entertainment system consists of the following components

- AV control unit
- Display unit
- DVD player
- Video monitor
- A/C and AV switch assembly
- Steering wheel audio control switches
- BOSE speaker amp.
- Front tweeters
- Front door speakers
- Rear tweeters
- Rear door speakers
- Subwoofer

When the DVD entertainment system is on, video signals are sent from the DVD player to the video monitor. Audio signals are sent to the AV control unit. Audio signals can be directed through wireless infrared headphones or through the BOSE speaker amp. to the vehicle speakers. Refer to the Owner's Manual for complete DVD entertainment system operating instructions.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV


DVD PLAYER

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

Component Parts Location

INFOID:000000007347825



- | | | |
|--|--|--|
| 1. Steering wheel audio control switches | 2. AV control unit M23, M37, M39, M44, M48, M71, M72 | 3. A/C and AV switch assembly M98 |
| 4. Display unit M92 | 5. DVD player M205 (located in center console) | 6. Infrared headphone and remote receiver/transmitter (part of video monitor assembly) |
| 7. Video monitor B76 | | |

Component Description

INFOID:000000007347826

Part name	Description
DVD player	<ul style="list-style-type: none"> Outputs DVD video to video monitor Outputs DVD audio to the AV control unit
Video monitor	<ul style="list-style-type: none"> Receives and displays the DVD video signal
AV control unit	<ul style="list-style-type: none"> Controls audio system and DVD entertainment system functions
BOSE speaker amp.	<ul style="list-style-type: none"> Receives audio signals from the AV control unit Outputs amplified audio signals to the speakers
A/C and AV switch assembly	<ul style="list-style-type: none"> All audio and A/C operations can be operated Switch signal is output to the AV control unit and A/C auto amp
Steering wheel audio control switches	<ul style="list-style-type: none"> Audio operation can be operated Steering switch signal (operation signal) is output to AV control unit
Front door speakers	<ul style="list-style-type: none"> Outputs audio signal from BOSE speaker amp. Outputs high, mid and low range sounds
Front and rear tweeters	<ul style="list-style-type: none"> Outputs audio signal from BOSE speaker amp. Outputs high range sounds

DVD PLAYER

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

Part name	Description
Rear door speakers	<ul style="list-style-type: none">• Outputs audio signal from BOSE speaker amp.• Outputs high, mid and low range sounds
Subwoofer	<ul style="list-style-type: none">• Outputs audio signal from BOSE speaker amp.• Outputs low range sounds

A

B

C

D

E

F

G

H

I

J

K

L

M


AV

O

P

HANDS-FREE PHONE SYSTEM

System Diagram



System Description

INFOID:000000007347828

Refer to the Owner's Manual for Bluetooth telephone system operating instructions.

NOTE:

Cellular telephones must have their wireless connection set up (paired) before using the Bluetooth telephone system.

Bluetooth telephone system allows users who have a Bluetooth equipped cellular telephone to make a wireless connection between their cellular telephone and the AV control unit. Hands-free cellular telephone calls can be sent and received. Personal memos can be created using the Nissan Voice Recognition system. Some Bluetooth cellular telephones may not be recognized by the AV control unit. When a cellular telephone or the AV control unit is replaced, the telephone must be paired with the AV control unit. Different cellular telephones may have different pairing procedures. Refer to the cellular telephone operating manual and the vehicle Owner's Manual for more information.

AV CONTROL UNIT

When the ignition switch is turned to ACC or ON, the AV control unit will power up. During power up, the Bluetooth feature is initialized and performs various self checks. Initialization may take up to 10 seconds. If a phone is present in the vehicle and paired with the AV control unit, Nissan Voice Recognition will then become active. Bluetooth telephone functions can be turned off using the Nissan Voice Recognition system.

STEERING WHEEL AUDIO CONTROL SWITCHES

When buttons on the steering wheel audio control switch are pushed, the resistance in steering wheel audio control switch circuit changes depending on which button is pushed. The AV control unit uses this signal to perform various functions while navigating through the voice recognition system.

The following functions can be performed using the steering wheel audio control switch:

- Initiate Self Diagnosis of the Bluetooth telephone system
- Start a voice recognition session
- Answer and end telephone calls
- Adjust the volume of calls
- Record memos

MICROPHONE

The microphone is located in the roof console assembly. The microphone sends a signal to the AV control unit. The microphone can be actively tested during self-diagnosis.


HANDS-FREE PHONE SYSTEM

[BOSE AUDIO WITH NAVIGATION]

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000007347829



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

- | | | |
|--|--------------------------|--|
| 1. Steering wheel audio control switches | 2. Front tweeter LH M109 | 3. AV control unit M23, M37, M39, M44, M48, M71, M72 |
| 4. A/C and AV switch assembly M98 | 5. Display unit M92 | 6. Front tweeter RH M111 |

HANDS-FREE PHONE SYSTEM

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

- | | | |
|---|--|--|
| 7. Aux. jack M85 | 8. Compact Flash insert slot | 9. Front door speaker
LH D12
RH D112 |
| 10. Rear door speaker
LH D207
RH D307 | 11. Rear tweeter
LH D208
RH D308 | 12. Subwoofer B72 |
| 13. BOSE speaker amp B74, B75 (located under driver seat) | 14. Rear view camera D551 | 15. Microphone R8 |

Component Description

INFOID:000000007347830

Part name	Description
AV control unit	<ul style="list-style-type: none"> Receives telephone voice signal from Antenna and Microphone Sends telephone voice and voice guidance signals to the speakers
BOSE speaker amp.	<ul style="list-style-type: none"> Receives audio signals from the AV control unit Outputs amplified audio signals to the speakers.
Front door speaker	Receives telephone voice and voice guidance signals from the AV control unit through the BOSE speaker amp.
Front tweeter	
Steering wheel audio control switches	<ul style="list-style-type: none"> Start a voice recognition session Answer and end telephone calls Adjust the volume level
Microphone	Sends voice signals to Bluetooth control unit
Bluetooth antenna	Sends telephone voice signal to Bluetooth control unit

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

AV CONTROL UNIT

AV CONTROL UNIT : Diagnosis Description

INFOID:000000007347831

DESCRIPTION

- Diagnosis function consists of the “Self-Diagnosis” mode performed automatically and the “Confirmation/Adjustment” mode operated manually.
- “Self-Diagnosis” mode checks for connections between the units constituting this system, analyzes each individual unit at the same time, and displays the results on the LCD screen.
- “Confirmation/Adjustment” mode is used to perform trouble diagnosis that requires operation and judgment by an operator (trouble that cannot be automatically judged by the system), to check/change the set value, and to display the error history of the AV control unit.

DIAGNOSIS ITEM

Mode	Description
Self-diagnosis	<ul style="list-style-type: none">• AV control unit diagnosis.• Analyzes connection between the AV control unit, front display, switches, DVD deck, GPS antenna and SAT antenna.

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

DIAGNOSIS SYSTEM (AV CONTROL UNIT)


[BOSE AUDIO WITH NAVIGATION]

< SYSTEM DESCRIPTION >

Mode		Description	
CONFIRMATION/ ADJUSTMENT	Display diagnosis	Color spectrum bar	Color tone of the screen can be checked by the display of a color bar.
		Gradation bar	Shading of the screen can be checked by the display of a gray scale.
		Touch panel	<ul style="list-style-type: none"> • Touch panel calibration. • Touch panel response check.
	Vehicle signals		The following vehicle signals are analyzed: Vehicle speed signal, parking brake signal, light signal, ignition switch signal, and reverse signal.
	Speaker test		Connection can be checked by sending a test tone to each speaker.
	Navigation	Steering angle adjustment	Confirm/adjust the steering angle when there is a difference between the displayed vehicle mark turning angle and actual.
		Speed calibration	Confirm/adjust the speed calibration when there is a difference between the displayed vehicle mark location and actual.
		XM SAT subscription status	Check the subscription status of the XM NAV Traffic subscription.
	Error history		Diagnosis results previously stored in the memory are displayed in this mode.
	Synchronize FES clock		Turns FES (Family Entertainment System) clock synchronization function ON/OFF.
	Vehicle CAN diagnosis		The transmitting/receiving of CAN communication can be monitored.
	AV COMM diagnosis		The transmitting/receiving of AV communication can be monitored.
	Hands-free phone	Hands-free volume adjustment	Adjust hands-free volume (low, medium, high).
		Voice microphone test	Test microphone operation.
		Delete hands-free memory	Erase hands-free system memory.
	Bluetooth	Confirm/Change passkey	Confirm and change the Bluetooth passkey.
		Confirm/Change device name	Confirm and change a device name stored in Bluetooth.
	SAT	Change channel	Any necessary channels required to receive traffic information from the satellite radio system can be set.
		Change application ID	Any application ID's required to receive traffic information from the satellite radio system can be set.
		Diag	Not used.
Delete unit connection log		Erase the error history and connection history of the unit.	
Initialize settings		All audio settings are reset to default levels.	

OPERATION PROCEDURE

1. Start the engine.
2. Turn the audio system off.
3. While pressing the "SETTING" button, turn the volume control dial counterclockwise 30 clicks or more.




ALN1A0446GB

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

[BOSE AUDIO WITH NAVIGATION]

< SYSTEM DESCRIPTION >

- The initial trouble diagnosis screen will be displayed, and items “Self-Diagnosis” and “Confirmation/Adjustment” can be selected.




SELF-DIAGNOSIS

- Perform self-diagnosis by selecting “Self-Diagnosis”.
 - Self-diagnosis subdivision screen is displayed, and the self-diagnosis mode starts.
 - A bar graph visible on the center of the self-diagnosis subdivision screen indicates progress of the trouble diagnosis.


NOTE:

Self-diagnosis requires approximately 10 seconds to complete.



- Diagnosis results are displayed after the self-diagnosis is completed. The unit names and the connection lines are color-coded according to the diagnostic results.


Diagnosis results	Unit	Connection line
Normal	Green	Green
Connection malfunction	Gray	Yellow
Unit malfunction ^{Note}	Red	Green



Note:

- Only the AV control unit is displayed in red.
- If multiple malfunctions occur at the same time for a single unit, the screen switch colors are determined according to the following order of priority: red > yellow > gray.

- Select a component on the “Self-Diagnosis” screen and comments for the diagnosis results will be shown.



Self-Diagnosis Results





A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >



[BOSE AUDIO WITH NAVIGATION]

Area with yellow connection lines	Description	Possible malfunction location / Action to take
 <p style="text-align: right; font-size: small;">AWNIA2280GB</p>	<p>AV control unit malfunction is detected.</p>	<p>Replace the AV control unit. Refer to AV-420, "Removal and Installation".</p>
 <p style="text-align: right; font-size: small;">AWNIA2281GB</p>	<p>Poor connection is detected for the display unit.</p>	<ul style="list-style-type: none"> • Harness or connector. • AV control unit. • Display unit.
 <p style="text-align: right; font-size: small;">AWNIA2282GB</p>	<p>Switch malfunction is detected.</p>	<p>Perform A/C and AV switch assembly diagnostics. Refer to AV-307, "A/C AND AV SWITCH ASSEMBLY : Component Function Check".</p>
 <p style="text-align: right; font-size: small;">AWNIA2283GB</p>	<p>Poor connection is detected for the DVD player.</p>	<ul style="list-style-type: none"> • Harness or connector. • AV control unit. • DVD player.

DIAGNOSIS SYSTEM (AV CONTROL UNIT)


< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

Area with yellow connection lines	Description	Possible malfunction location / Action to take
 <p style="text-align: right; font-size: small;">AWNIA2284GB</p>	<p>Poor connection is detected for the GPS antenna.</p>	<ul style="list-style-type: none"> • Harness or connector. • AV control unit. • GPS antenna.
 <p style="text-align: right; font-size: small;">AWNIA2285GB</p>	<p>Poor connection is detected for the satellite radio tuner.</p>	<ul style="list-style-type: none"> • Harness or connector. • AV control unit. • Satellite radio tuner.

CONFIRMATION/ADJUSTMENT MODE

1. Start the diagnosis function and select "Confirmation/Adjustment". The confirmation/adjustment mode indicates where each item can be checked or adjusted.
2. Select each item on the "Confirmation/Adjustment" mode screen to display the relevant trouble diagnosis screen. Touch "BACK" on the display or press the "BACK" button to return to the initial Confirmation/Adjustment Mode screen.



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

Display Diagnosis




The tint of the color bar indication is as per the following list if RGB signal error is detected.

- R (red) signal error** : Light blue (Cyan) tint
- G (green) signal error** : Purple (Magenta) tint
- B (blue) signal error** : Yellow tint

Vehicle Signals

A comparison check can be made of each actual vehicle signal and the signals recognized by the system.



DIAGNOSIS SYSTEM (AV CONTROL UNIT)


< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

Diagnosis item	Display	Vehicle status	Remarks
Vehicle speed	ON	Vehicle speed > 0 km/h	Changes in indication may be delayed by approximately 1.5 seconds. This is normal.
	OFF	Vehicle speed = 0 km/h	
	—	Ignition switch in ACC position	
Parking brake	ON	Parking brake is applied.	
	OFF	Parking brake is released.	
Lights	ON	Light switch ON	Block the light beam from the auto light optical sensor.
	OFF	Light switch OFF	
Ignition	ON	Ignition switch ON	—
	OFF	Ignition switch in ACC position	
Reverse	ON	Selector lever in R position	Changes in indication may be delayed by approximately 1.5 seconds. This is normal.
	OFF	Selector lever in any position other than R	
	—	Ignition switch in ACC position	

Speaker Test


Select “Speaker Test” to display the speaker diagnosis screen. Press “Start” to generate a test tone in speakers. Touch “End” to stop the test tones.



Navigation


STEERING ANGLE ADJUSTMENT

The steering angle output value detected with the gyroscope is adjusted.



SPEED CALIBRATION

During normal driving, distance error caused by tire wear and tire pressure change is automatically adjusted for by the automatic distance correction function. This function, on the other hand, is for immediate adjustment, in cases such as driving with tire chain fitted on tires.




DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

XM SAT SUBSCRIPTION STATUS

The XM NavTraffic subscription status can be checked.



Error History

The self-diagnosis results are judged depending on whether any error occurs from when "Self-diagnosis" is selected until the self-diagnosis results are displayed.


However, the diagnosis results are judged normal if an error has occurred before the ignition SW is turned ON and then no error has occurred until the self-diagnosis start. Check the "Error History" to detect any error that may have occurred before the self-diagnosis start because of this situation.

Count up method A

- The counter resets to 0 if an error occurs when IGN switch is turned ON. The counter increases by 1 if the condition is normal at a next IGN ON cycle.
- The counter upper limit is 39. Any counts exceeding 39 are ignored. The counter can be reset (no error record display) with the "Delete log" switch or CONSULT.

Count up method B

- The counter increases by 1 if an error occurs when IGN switch is ON. The counter will not decrease even if the condition is normal at the next IGN ON cycle.
- The counter upper limit is 50. Any counts exceeding 50 are ignored. The counter can be reset (no error record display) with the "Delete log" switch or CONSULT.



Display method of occurrence frequency	Error history display item
Count up method A	CAN communication line, control unit (CAN), AV communication line, control unit (AV communication)
Count up method B	Other than above

Error item

Some error items may be displayed simultaneously according to the cause. If some error items are displayed simultaneously, the detection of the cause can be performed by the combination of display items

Error item	Description	Possible malfunction factor/Action to take
CAN COMM CIRCUIT	CAN communication malfunction is detected.	Perform diagnosis with CONSULT, and then repair the malfunctioning parts according to the diagnosis results. Refer to AV-306, "AV CONTROL UNIT : CONSULT Function" .

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

Error item	Description	Possible malfunction factor/Action to take
CONTROL UNIT (CAN)	CAN initial diagnosis malfunction is detected.	Replace the AV control unit. Refer to AV-420, "Removal and Installation" .
CONTROL UNIT (AV)	AV communication circuit initial diagnosis malfunction is detected.	
FLASH-ROM Error Of Control Unit	AV control unit malfunction is detected.	
Connection Of Gyro		
XM SERIAL COMM Error		
CAN Controller Memory Error		
Bluetooth Module Connection Error		
HDD CONN Error		
HDD READ Error		
HDD WRITE Error		
HDD COMM Error		
HDD ACCESS Error		
DSP CONN Error		
DSP COMM Error		
Internal Communication Error		AV control unit power supply and ground circuit. Refer to AV-334, "AV CONTROL UNIT : Diagnosis Procedure" .
GPS Communication Error	GPS malfunction is detected.	An intermittent error caused by strong radio interference may be detected unless any symptoms (GPS reception error, etc.) occur. Replace the AV control unit if the malfunction occurs constantly. Refer to AV-420, "Removal and Installation" .
GPS ROM Error		
GPS RAM Error		
GPS RTC Error		
Front Display Connection Error	<ul style="list-style-type: none"> • Display unit power supply and ground circuit malfunction is detected. • Malfunction is detected on communication circuit between display unit and AV control unit. • Malfunction is detected on communication signal between display unit and AV control unit. 	<ul style="list-style-type: none"> • Display unit power supply and ground circuit. Refer to AV-335, "DISPLAY UNIT : Diagnosis Procedure". • Communication circuit between display unit and AV control unit.
GPS Antenna Error	GPS antenna connection malfunction is detected.	GPS antenna.
XM Antenna Connection Error	Poor connection is detected in satellite radio antenna.	Satellite radio antenna.
<ul style="list-style-type: none"> • AV COMM CIRCUIT • Switches Connection Error 	<ul style="list-style-type: none"> • A/C and AV switch assembly power supply and ground circuit malfunction is detected. • A malfunction is detected in AV communication circuit between AV control unit and A/C and AV switch assembly. • A malfunction is detected in AV communication signal between AV control unit and A/C and AV switch assembly. 	<ul style="list-style-type: none"> • A/C and AV switch assembly power supply and ground circuits. Refer to AV-336, "A/C AND AV SWITCH ASSEMBLY : Diagnosis Procedure". • AV communication circuit between AV control unit and A/C and AV switch assembly.

Vehicle CAN Diagnosis


A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

[BOSE AUDIO WITH NAVIGATION]


< SYSTEM DESCRIPTION >

- CAN communication status and error counter is displayed.
- The error counter displays “OK” if any malfunction was not detected in the past and displays “0” if a malfunction is detected. It increases by 1 if the condition is normal at the next ignition switch ON cycle. The upper limit of the counter is 39.
- The error counter is erased if reset.




AV COMM Diagnosis

- AV communication status and error counter is displayed.
- The error counter displays “OK” if any malfunction was not detected in the past and displays “0” if a malfunction is detected. It increases by 1 if the condition is normal at the next ignition switch ON cycle. The upper limit of the counter is 39.
- The error counter is erased if reset.



Hands-free Phone


The hands-free phone reception volume adjustment, microphone and speaker test, and memory erase functions are also available.



Bluetooth

Passkey confirmation/change

- The passkey of Bluetooth can be confirmed and changed.
- The passkey can be changed by four digits within 0 to 9.




Device name check/change

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

[BOSE AUDIO WITH NAVIGATION]


< SYSTEM DESCRIPTION >

- The device name of Bluetooth can be confirmed and changed.
- The device name can be changed by sixteen digits within A to Z (small character can be used) and - (hyphen).




SAT

- Change Channel
- Any necessary channels required to receive traffic information from the satellite radio system can be set.




- Change Application ID
- Any application ID's required to receive traffic information from the satellite radio system can be set.



Delete Unit Connection Log

Deletes any unit connection records and error records from the AV control unit memory. (Clear the records of the unit that has been removed)



Initialize Settings


A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

< SYSTEM DESCRIPTION >

[BOSE AUDIO WITH NAVIGATION]

Initializes the AV control unit memory.



AV CONTROL UNIT : CONSULT Function

INFOID:000000007347832

CONSULT can display each diagnostic item using the diagnostic test modes shown following.

MULTI AV diagnosis mode	Description
ECU IDENTIFICATION	The part number of AV control unit can be checked.
SELF DIAGNOSTIC RESULT	Displays AV control unit self-diagnosis results.
DATA MONITOR	Displays AV control unit input/output data in real time.
CAN DIAG SUPPORT MNTR	The result of transmit/receive diagnosis of CAN communication can be read.

Self-diagnosis results

- In CONSULT self-diagnosis, self-diagnosis results and error history are displayed collectively.
- The current malfunction indicates “CRNT”. The past malfunction indicates “PAST”.
- The timing is displayed as “0” if any of the error codes [U1000], [U1010], [U1300] and [U1310] is detected. The counter increases by 1 if the condition is normal at the next ignition switch ON cycle.

Self-diagnosis results display item

Error item	Description	Possible malfunction factor/Action to take
CAN COMM CIRCUIT[U1000]	CAN communication malfunction is detected	Perform diagnosis with CONSULT, and then repair the malfunctioning parts according to the diagnosis results. Refer to AV-309, "Description" .
CONTROL UNIT (CAN) [U1010]	CAN initial diagnosis malfunction is detected	Replace the AV control unit
CONTROL UNIT (AV) [U1310]	AV communication circuit initial diagnosis malfunction is detected	
Control Unit FLASH-ROM [U1200]	AV control unit malfunction is detected	
Gyro NO CONN [U1201]		
CAN CONT [U1216]		
BLUETOOTH CONN [U1217]		
HDD CONN [U1218]		
HDD READ [U1219]		
XM SERIAL COMM [U1220]		
HDD WRITE [U121A]		
HDD COMM [U121B]		
HDD ACCESS [U121C]		
DSP CONN [U121D]		
DSP COMM [U121E]		
INTERNAL COMM [U121F]		AV control unit power supply and ground circuit

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

[BOSE AUDIO WITH NAVIGATION]

< SYSTEM DESCRIPTION >

Error item	Description	Possible malfunction factor/Action to take
GPS COMM [U1204]	GPS malfunction is detected	An intermittent error caused by strong radio interference may be detected unless any symptoms (GPS reception error, etc.) occur. Replace the AV control unit if the malfunction occurs constantly.
GPS ROM [U1205]		
GPS RAM [U1206]		
GPS RTC [U1207]		
FRONT DISP CONN [U1243]	<ul style="list-style-type: none"> Display unit power supply and ground circuit malfunction is detected Malfunction is detected on communication circuit between display unit and AV control unit Malfunction is detected on communication signal between display unit and AV control unit 	<ul style="list-style-type: none"> Display unit power supply and ground circuit Communication circuit between display unit and AV control unit
GPS ANTENNA CONN [U1244]	GPS antenna connection malfunction is detected	GPS antenna
XM ANTENNA CONN [U1258]	Poor connection is detected in satellite radio antenna	Satellite radio antenna
<ul style="list-style-type: none"> AV COMM CIRCUIT [U1300] SWITCHE CONN [U1240] 	<ul style="list-style-type: none"> Multifunction switch power supply and ground circuit malfunction is detected A malfunction is detected in AV communication circuit between AV control unit and multifunction switch A malfunction is detected in AV communication signal between AV control unit and multifunction switch 	<ul style="list-style-type: none"> Multifunction switch power supply and ground circuits AV communication circuit between AV control unit and multifunction switch

DATA MONITOR

Display Item List

Display item [unit]	ALL SIGNALS	SELECTION FROM MENU	Description
VHCL SPD SIG [ON/OFF]	X	X	Displays "ON" when vehicle speed > 0 km/h. Displays "OFF" when vehicle speed = 0 km/h.
PKB SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of parking brake switch.
ILLUM SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of lighting switch.
IGN SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of ignition switch.
REV SIG [ON/OFF]	X	X	Displays [ON/OFF] condition of back-up lamp switch.

A/C AND AV SWITCH ASSEMBLY

A/C AND AV SWITCH ASSEMBLY : Component Function Check

INFOID:000000007347833

A/C and AV switch assembly self-diagnosis function

Description

The ON/OFF operation (continuity) of each switch in the A/C and AV switch assembly can be checked.


Self-diagnosis mode

DIAGNOSIS SYSTEM (AV CONTROL UNIT)

[BOSE AUDIO WITH NAVIGATION]

< SYSTEM DESCRIPTION >

- Press the “BACK” button and the “UP” button within 10 seconds after turning the ignition switch from OFF to ACC and hold them for 3 seconds or more. When the self-diagnosis mode starts, a beep will sound and all LED indicators of the switch will illuminate.
- The continuity of each switch and control dial of the A/C and AV switch assembly can be checked. If the switch is operating normally, the system will beep and the LED’s will illuminate when each switch is operated.



Finishing self-diagnosis mode

Self-diagnosis mode is canceled when the ignition switch is turned OFF.

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000007347834

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-13, "How to Use CAN Communication Signal Chart"](#).

DTC Logic

INFOID:000000007347835

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
U1000	CAN COMM CIRCUIT	When AV control unit is not transmitting or receiving CAN communication signal for 2 seconds or more.	CAN communication system

Diagnosis Procedure

INFOID:000000007347836

1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" of "MULTI AV".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to "LAN system". Refer to [LAN-14, "Trouble Diagnosis Flow Chart"](#).
- NO >> Refer to GI section. Refer to [GI-37, "Intermittent Incident"](#).



U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000007347837

Initial diagnosis of AV control unit.

DTC Logic

INFOID:000000007347838

DTC DETECTION LOGIC

DTC	Display contents of CONSULT	Diagnostic item is detected when ...	Probable malfunction location
U1010	CONTROL UNIT (CAN)	CAN initial diagnosis malfunction is detected	AV control unit

Diagnosis Procedure

INFOID:000000007347839

1. REPLACE AV CONTROL UNIT

When DTC U1010 is detected, replace AV control unit. Refer to [AV-420. "Removal and Installation"](#).

>> Inspection End.

U1200 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1200 AV CONTROL UNIT

Description

INFOID:000000007347840

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347841

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U1200	Control Unit FLASH- ROM [U1200]	An internal malfunction is detected in AV control unit (FLASH-ROM).	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

U1201 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1201 AV CONTROL UNIT

Description

INFOID:000000007347842

Replace the AV control unit if this DTC is displayed. Refer to [AV-420. "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347843

DTC DETECTION LOGIC

DTC	CONSULT display	Detection condition	Action to take
U1201	GYRO NO CONN [U1201]	An internal malfunction is detected in AV control unit (gyrocompass disconnection).	Replace AV control unit. Refer to AV-420. "Removal and Installation" .

U1204 GPS COMM

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1204 GPS COMM

Description

INFOID:000000007347844

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347845

DTC DETECTION LOGIC

DTC	CONSULT display	Detection condition	Action to take
U1204	GPS COMM [U1204]	An internal malfunction is detected in AV control unit (GPS malfunction).	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

U1205 GPS ROM

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1205 GPS ROM

Description

INFOID:000000007347846

Replace the AV control unit if this DTC is displayed. Refer to [AV-420. "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347847

DTC DETECTION LOGIC

DTC	CONSULT display	Detection condition	Action to take
U1205	GPS ROM [U1205]	An internal malfunction is detected in AV control unit (GPS malfunction).	Replace AV control unit. Refer to AV-420. "Removal and Installation" .

U1206 GPS RAM

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1206 GPS RAM

Description

INFOID:000000007347848

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347849

DTC DETECTION LOGIC

DTC	CONSULT display	Detection condition	Action to take
U1206	GPS RAM [U1206]	An internal malfunction is detected in AV control unit (GPS malfunction).	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

U1207 GPS RTC

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1207 GPS RTC

Description

INFOID:000000007347850

Replace the AV control unit if this DTC is displayed. Refer to [AV-420. "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347851

DTC DETECTION LOGIC

DTC	CONSULT display	Detection condition	Action to take
U1207	GPS RTC [U1207]	An internal malfunction is detected in AV control unit (GPS malfunction).	Replace AV control unit. Refer to AV-420. "Removal and Installation" .

U1216 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1216 AV CONTROL UNIT

Description

INFOID:000000007347852

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347853

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U1216	CAN CONT [U1216]	Internal malfunction of AV control unit (CAN controller) is detected.	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

U1217 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1217 AV CONTROL UNIT

Description

INFOID:000000007347854

Replace the AV control unit if this DTC is displayed. Refer to [AV-420. "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347855

DTC DETECTION LOGIC

DTC	CONSULT display	Detection condition	Action to take
U1217	BLUETOOTH CONN [U1217]	An internal malfunction is detected in AV control unit (Bluetooth module connection malfunction).	Replace AV control unit. Refer to AV-420. "Removal and Installation" .

U1218 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1218 AV CONTROL UNIT

Description

INFOID:000000007347856

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• Integrates HDD (hard disk drive) allowing map data and music data to be stored.• It is the master unit of the MULTI AV system, and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• The AV control unit includes the audio, hands-free phone, voice control, navigation, and vehicle information functions.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347857

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U1218	HDD-CONN [U1218]	Internal malfunction of AV control unit (HDD connection malfunction) is detected.	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



U1219 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1219 AV CONTROL UNIT

Description

INFOID:000000007347858

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• Integrates HDD (hard disk drive) allowing map data and music data to be stored.• It is the master unit of the MULTI AV system, and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• The AV control unit includes the audio, hands-free phone, voice control, navigation, and vehicle information functions.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347859

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U1219	HDD-READ [U1219]	Internal malfunction of AV control unit (HDD read malfunction) is detected.	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

U1220 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1220 AV CONTROL UNIT

Description

INFOID:000000007347860

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347861

DTC DETECTION LOGIC

DTC	CONSULT display	Detection condition	Action to take
U1220	XM SERIAL COMM [U1220]	An internal malfunction is detected in AV control unit (satellite radio tuner communication malfunction).	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

U121A AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U121A AV CONTROL UNIT

Description

INFOID:000000007347862

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• Integrates HDD (hard disk drive) allowing map data and music data to be stored.• It is the master unit of the MULTI AV system, and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• The AV control unit includes the audio, hands-free phone, voice control, navigation, and vehicle information functions.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347863

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U121A	HDD-WRITE [U121A]	Internal malfunction of AV control unit (HDD write malfunction) is detected.	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

U121B AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U121B AV CONTROL UNIT

Description

INFOID:000000007347864

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none"> Integrates HDD (hard disk drive) allowing map data and music data to be stored. It is the master unit of the MULTI AV system, and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit. The AV control unit includes the audio, hands-free phone, voice control, navigation, and vehicle information functions. It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function. It inputs the automatic brightness ON/OFF signals that are required for the display dimming control. It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347865

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U121B	HDD-COMM [U121B]	Internal malfunction of AV control unit (HDD communication error) is detected.	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



U121C AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U121C AV CONTROL UNIT

Description

INFOID:000000007347866

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• Integrates HDD (hard disk drive) allowing map data and music data to be stored.• It is the master unit of the MULTI AV system, and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• The AV control unit includes the audio, hands-free phone, voice control, navigation, and vehicle information functions.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347867

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U121C	HDD-ACCESS [U121C]	Internal malfunction of AV control unit (HDD access error) is detected.	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

U121D AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U121D AV CONTROL UNIT

Description

INFOID:000000007347868

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none"> Integrates HDD (hard disk drive) allowing map data and music data to be stored. It is the master unit of the MULTI AV system, and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit. The AV control unit includes the audio, hands-free phone, voice control, navigation, and vehicle information functions. It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function. It inputs the automatic brightness ON/OFF signals that are required for the display dimming control. It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347869

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U121D	DSP CONN [U121D]	Internal malfunction of AV control unit (DSP connection error) is detected.	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

U121E AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U121E AV CONTROL UNIT

Description

INFOID:000000007347870

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• Integrates HDD (hard disk drive) allowing map data and music data to be stored.• It is the master unit of the MULTI AV system, and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• The AV control unit includes the audio, hands-free phone, voice control, navigation, and vehicle information functions.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347871

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U121E	DSP COMM [U121E]	Internal malfunction of AV control unit (DSP communication error) is detected.	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

U121F AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U121F AV CONTROL UNIT

Description

INFOID:000000007347872

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">Integrates HDD (hard disk drive) allowing map data and music data to be stored.It is the master unit of the MULTI AV system, and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.The AV control unit includes the audio, hands-free phone, voice control, navigation, and vehicle information functions.It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347873

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U121F	INTERNAL COMM [U121F]	Internal malfunction of AV control unit (internal communication error) is detected.	AV control unit power supply and ground circuit

Diagnosis Procedure

INFOID:000000007347874

1. CHECK AV CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check audio control unit power supply and ground circuit. Refer to [AV-334, "AV CONTROL UNIT : Diagnosis Procedure"](#).

Is inspection result OK?

- YES >> Inspection End.
- NO >> Repair malfunctioning parts.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



U1243 DISPLAY UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1243 DISPLAY UNIT

Description

INFOID:000000007347875

Part name	Description
DISPLAY UNIT	<ul style="list-style-type: none"> • Display image is controlled by the serial communication from AV control unit. • RGB image signal is input from AV control unit (RGB, RGB area and RGB synchronizing). Auxiliary image signal is input from the auxiliary input jack. Camera image signal is input from the rear view camera. • Synchronize signal (HP, VP) is output to AV control unit. • Touch panel function can be operated for each system by touching a display directly.

DTC Logic

INFOID:000000007347876

DTC	Display contents of CONSULT	DTC Detection Condition	Possible causes
U1243	FRONT DISP CONN [U1243]	<ul style="list-style-type: none"> • Display unit power supply and ground circuit malfunction is detected • Malfunction is detected on communication circuit between display unit and AV control unit • Malfunction is detected on communication signal between display unit and AV control unit 	<ul style="list-style-type: none"> • Display unit power supply and ground circuit • Communication circuit between display unit and AV control unit

Diagnosis Procedure

INFOID:000000007347877

Regarding Wiring Diagram information, refer to [AV-385. "Wiring Diagram - With Navigation System"](#).

1. CHECK DISPLAY UNIT POWER SUPPLY AND GROUND CIRCUIT

Check display unit power supply and ground circuit. Refer to [AV-335. "DISPLAY UNIT : Diagnosis Procedure"](#).

Is inspection result OK?

YES >> GO TO 2


NO >> Repair malfunctioning parts.

2. CHECK CONTINUITY COMMUNICATION CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M92 and AV control unit connector M37.
3. Check continuity between display unit harness connector M92 (A) terminals 11, 22 and AV control unit harness connector M37 (B) terminals 30, 31.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M92	11	M37	30	Yes
	22		31	

4. Check continuity between display unit harness connector M92 (A) terminals 11, 22 and ground.



A		—	Continuity
Connector	Terminal		
M92	11	Ground	No
	22		

U1243 DISPLAY UNIT

[BOSE AUDIO WITH NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >


Are continuity results as specified?

- YES >> GO TO 3
- NO >> Repair harness or connector.

3. CHECK COMMUNICATION SIGNAL

1. Connect display unit connector M92 and AV control unit connector M37.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M92 terminal 11 and ground.

Connector	Terminals		Reference Signal
	(+)	(-)	
M92	11	Ground	<p>PKIB5039J</p>




Are voltage readings as specified?

- YES >> GO TO 4
- NO >> Replace AV control unit. Refer to [AV-420. "Removal and Installation"](#).

4. CHECK COMMUNICATION SIGNAL

Check signal between display unit harness connector M92 terminal 22 and ground.

Connector	Terminals		Reference Signal
	(+)	(-)	
M92	22	Ground	<p>PKIB5039J</p>



Are voltage readings as specified?

- YES >> Inspection End.
- NO >> Replace display unit. Refer to [AV-422. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

U1244 GPS ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1244 GPS ANTENNA

Description

INFOID:000000007347878

The GPS antenna receives satellite GPS signals.

DTC Logic

INFOID:000000007347879

DTC DETECTION LOGIC

DTC	CONSULT display	Detection condition
U1244	GPS ANTENNA CONN [U1244]	GPS antenna connection malfunction is detected.

Diagnosis Procedure

INFOID:000000007347880

Regarding Wiring Diagram information, refer to [AV-385. "Wiring Diagram - With Navigation System"](#).

1. GPS ANTENNA CHECK

Inspect GPS antenna and antenna feeder for damage or poor connection.

Is the GPS antenna and feeder clean and undamaged?

- YES >> GO TO 2
- NO >> Repair or replace malfunctioning parts.


2. CHECK AV CONTROL UNIT VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between AV control unit connector M72 terminal 109 and ground.

109 - Ground : Approx. 5V

Is the voltage reading as specified?

- YES >> Replace GPS antenna. Refer to [AV-434. "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-420. "Removal and Installation"](#).



U1258 SATELLITE RADIO ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1258 SATELLITE RADIO ANTENNA

Description

INFOID:000000007347881

Part name	Description
SATELLITE RADIO ANTENNA	Satellite radio signal is received and sent to audio control unit.

DTC Logic

INFOID:000000007347882

DTC	Display contents of CONSULT	DTC Detection Condition	Possible causes
U1258	XM ANETNNA CONN [U1258]	Satellite radio antenna connection malfunction is detected	Satellite radio antenna disconnection

Diagnosis Procedure

INFOID:000000007347883

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. SATELLITE RADIO ANTENNA CHECK

Visually check satellite radio antenna and antenna feeder.

Is inspection result OK?

YES >> GO TO 2

NO >> Repair malfunctioning parts.

2. CHECK AV CONTROL UNIT VOLTAGE


1. Disconnect AV control unit connector M71.
2. Turn ignition switch ON.
3. Check voltage between AV control unit connector M71 terminal 108 and ground.

108 - Ground : Approx. 5 V

Is voltage approximately 5 volts?

YES >> Replace satellite radio antenna. Refer to [AV-435, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M

AV

U1300 AV COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1300 AV COMM CIRCUIT

Description

INFOID:000000007347884

U1300 is indicated when malfunction occurs in communication signal of multi AV system. Indicated simultaneously, without fail, with the malfunction of control units connected to AV control unit with communication line. Determine the possible malfunction cause from the table below.

Self-diagnosis results display item

DTC	Display contents of CONSULT	DTC Detection Condition	Possible causes
U1300 U1240	<ul style="list-style-type: none">• AV COMM CIRCUIT [U1300]• SWITCH CONN [U1240]	<ul style="list-style-type: none">• A/C and AV switch assembly power supply and ground circuit malfunction is detected• A malfunction is detected in communication circuit between AV control unit and A/C and AV switch assembly• A malfunction is detected in communication signal between AV control unit and A/C and AV switch assembly	<ul style="list-style-type: none">• A/C and AV switch assembly power supply and ground circuits• Communication circuit between AV control unit and A/C and AV switch assembly

U1310 AV CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

U1310 AV CONTROL UNIT

Description

INFOID:000000007347885

Replace the AV control unit if this DTC is displayed. Refer to [AV-420, "Removal and Installation"](#).

Part name	Description
AV CONTROL UNIT	<ul style="list-style-type: none">• It is the master unit of the MULTI AV system and it is connected to each control unit by means of communication. It operates each system according to communication signals from the AV control unit.• AV control unit includes audio function and vehicle information function.• It is connected to ECM and combination meter via CAN communication to obtain necessary information for the vehicle information function.• It inputs the automatic brightness ON/OFF signals that are required for the display dimming control.• It inputs the signals for driving status recognition (vehicle speed, reverse and parking brake).

DTC Logic

INFOID:000000007347886

DTC	Display contents of CONSULT	DTC Detection Condition	Action to take
U1310	CONTROL UNIT (AV) [U1310]	An initial diagnosis error is detected in AV communication circuit.	Replace AV control unit. Refer to AV-420, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

POWER SUPPLY AND GROUND CIRCUIT

AV CONTROL UNIT

AV CONTROL UNIT : Diagnosis Procedure

INFOID:000000007347887

Regarding Wiring Diagram information, refer to [AV-385. "Wiring Diagram - With Navigation System"](#).

1. CHECK FUSES

Check that the following AV control unit fuses are not blown.

Unit	Terminals	Signal name	Fuse No.
AV control unit	19, 69, 71	Battery power	29
	7, 72	Ignition switch ACC or ON	4
	82	Ignition switch ON or START	12

Are the fuses OK?

YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect AV control unit connectors M39 and M48.
2. Check voltage between the AV control unit connectors M39 and M48 and ground.

(+) Connector		Terminal	(-)	OFF	ACC	ON
M39		7	Ground	0V	Battery voltage	Battery voltage
		19	Ground	Battery voltage	Battery voltage	Battery voltage
M48		69	Ground	Battery voltage	Battery voltage	Battery voltage
		71	Ground	Battery voltage	Battery voltage	Battery voltage
		72	Ground	0V	Battery voltage	Battery voltage
		82	Ground	0V	0V	Battery voltage


Are the voltage results as specified?

YES >> GO TO 3

- NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.

3. GROUND CIRCUIT CHECK

1. Ignition OFF.
2. Check continuity between AV control unit harness connector M39, M48 and ground.



POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

(+)		(-)	Continuity
Connector	Terminal		
M39	20	Ground	Yes
	68		
M48	70		
	87		
	89		
	90		

Are the continuity results as specified?

- YES >> Inspection End.
- NO >> Repair AV control unit ground.

DISPLAY UNIT

DISPLAY UNIT : Diagnosis Procedure

INFOID:000000007347888

Regarding Wiring Diagram information, refer to [AV-385. "Wiring Diagram - With Navigation System"](#).

1.CHECK FUSES

Check that the following display unit fuses are not blown.

Unit	Terminals	Signal name	Fuse No.
Display unit	2	Battery power	29
	3	Ignition switch ACC or ON	4


Are the fuses OK?

- YES >> GO TO 2
- NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch to ACC
2. Check voltage between display unit harness connector M92 and ground.

Connector	Terminal	Ignition switch position	Value (Approx.)
M92	2	ACC	Battery voltage
	3		



Does specified voltage exist?

- YES >> GO TO 3.
- NO >>
 - Check connector housings for disconnected or loose terminals.
 - Repair harness or connector.


3.CHECK GROUND CIRCUIT

POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITH NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect display unit connector.
3. Check continuity between display unit harness connector M92 and ground.



(+)		(-)	Continuity
Connector	Terminal		
M92	1	Ground	Yes
	13		

Does continuity exist?

- YES >> Inspection End.
 NO >> Repair harness or connector.

A/C AND AV SWITCH ASSEMBLY

A/C AND AV SWITCH ASSEMBLY : Diagnosis Procedure

INFOID:000000007347889

Regarding Wiring Diagram information, refer to [AV-385. "Wiring Diagram - With Navigation System"](#).

1. CHECK FUSE

Check that the A/C and AV switch assembly fuse is not blown.


Unit	Terminal	Signal name	Fuse No.
A/C and AV switch assembly	2	Ignition switch ACC or ON	4

Is the fuse OK?

- YES >> GO TO 2
 NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect A/C and AV switch assembly connector M98.
2. Check voltage between the A/C and AV switch assembly connector M98 and ground.



(+)		(-)	OFF	ACC	ON
Connector	Terminal		0V	Battery voltage	Battery voltage
M98	2	Ground			

Are the voltage results as specified?

- YES >> GO TO 3
 NO >> • Check connector housings for disconnected or loose terminals.
 • Repair harness or connector.

3. GROUND CIRCUIT CHECK

POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITH NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Ignition OFF.
2. Check continuity between A/C and AV switch assembly harness connector M98 and ground.

(+)		(-)	Continuity
Connector	Terminal		
M98	1	Ground	Yes

Are the continuity results as specified?

- YES >> Inspection End.
 NO >> Repair A/C and AV switch assembly ground.

BOSE SPEAKER AMP

BOSE SPEAKER AMP : Diagnosis Procedure

INFOID:000000007347890

Regarding Wiring Diagram information, refer to [AV-385. "Wiring Diagram - With Navigation System"](#).

1.CHECK FUSE

Check that the BOSE speaker amp. fuse is not blown.

Unit	Terminal	Signal name	Fuse No.
BOSE speaker amp.	1	Battery power	29

Are the fuses OK?

- YES >> GO TO 2
 NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BOSE speaker amp. connector.
3. Check voltage between BOSE speaker amp. harness connector B74 terminal 1 and ground.

(+)		(-)	Voltage (approx.)
Connector	Terminal		
B74	1	Ground	Battery voltage

Is battery voltage present?

- YES >> GO TO 3
 NO >> Check harness between BOSE speaker amp. and fuse.

3.CHECK GROUND CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect BOSE speaker amp. connector.
3. Check continuity between BOSE speaker amp. harness connector B74 terminal 17 and ground.

(+)		(-)	Continuity
Connector	Terminal		
B74	17	Ground	Yes


Does continuity exist?

- YES >> Inspection End.
 NO >> Repair harness or connector.


SUBWOOFER



ALNIA0316GB



ALNIA0527GB



ALNIA0526GB

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

SUBWOOFER : Diagnosis Procedure

INFOID:000000007347891

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CHECK FUSE

Check that the subwoofer fuse is not blown.

Unit	Terminal	Signal name	Fuse No.
Subwoofer	6	Battery power	17

Is the fuse OK?

YES >> GO TO 2

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2. CHECK POWER SUPPLY CIRCUIT


1. Turn ignition switch OFF.
2. Disconnect subwoofer connector.
3. Check voltage between subwoofer harness connector B72 terminal 6 and ground.

(+)		(-)	Voltage (approx.)
Connector	Terminal		
B72	6	Ground	Battery voltage

Is battery voltage present?

YES >> GO TO 3

NO >> Check harness between subwoofer and fuse.



3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between subwoofer harness connector B72 terminal 5 and ground.

(+)		(-)	Continuity
Connector	Terminal		
B72	5	Ground	Yes

Does continuity exist?

YES >> Inspection End.

NO >> Repair harness or connector.

REAR VIEW CAMERA

REAR VIEW CAMERA : Diagnosis Procedure

INFOID:000000007347892

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CHECK POWER SUPPLY CIRCUIT (REAR VIEW CAMERA SIDE)

NOTE:

Apply parking brakes before proceeding.

1. Turn ignition switch ON.
2. Shift transmission into reverse.
3. Check voltage between rear view camera harness connector D551 terminal 2 and ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

(+)		(-)	Transmission position	Value (Approx.)
Connector	Terminal			
D551	2	Ground	Reverse	12V

Is voltage reading approximately 12 volts?

YES >> GO TO 4.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT (CONTINUITY)

1. Turn ignition switch OFF.
2. Disconnect rear view camera and AV control unit connectors.
3. Check continuity between rear view camera harness connector D551 terminal 2 and AV control unit harness connector M48 terminal 84.

Connector	Terminal	Connector	Terminal	Continuity
D551	2	M48	84	Yes

4. Check continuity between rear view camera harness connector D551 terminal 2 and ground.

Connector	Terminal	—	Continuity
D551	2	Ground	No

Are continuity test results as specified?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK REVERSE POSITION INPUT SIGNAL

1. Turn ignition switch ON.
2. Shift transmission into reverse.
3. Check voltage between AV control unit harness connector M48 terminal 84 and ground.

(+)		(-)	Transmission position	Value (Approx.)
Connector	Terminal			
M48	84	Ground	Reverse	12V

Is voltage reading approximately 12 volts?

YES >> Replace AV control unit. Refer to [AV-420. "Removal and Installation"](#).

NO >> Check harness for open or short between AV control unit and back-up lamp relay.

4. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear view camera harness connector.
3. Check continuity between rear view camera harness connector D551 terminal 1 and ground.

Connector	Terminal	—	Continuity
D551	1	Ground	Yes

Does continuity exist?

YES >> Inspection End.

NO >> Repair harness or connector.

DVD PLAYER

DVD PLAYER : Diagnosis Procedure

INFOID:000000007347893

Regarding Wiring Diagram information, refer to [AV-385. "Wiring Diagram - With Navigation System"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

1. CHECK FUSE

Check that the following fuses of the DVD player are not blown.

Unit	Terminal	Signal name	Fuse No.
DVD player	21	Battery power	29
	24	Ignition switch ACC or ON	4

Is the fuse OK?


YES >> GO TO 2

NO >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse.

2. POWER SUPPLY CIRCUIT CHECK

1. Disconnect DVD player connector M205.
2. Check voltage between the DVD player connector M205 and ground.

(+)		(-)	OFF	ACC	ON
Connector	Terminal				
M205	21	Ground	Battery voltage	Battery voltage	Battery voltage
	24		0V	Battery voltage	Battery voltage



Are the voltage results as specified?

YES >> GO TO 3

NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.

3. GROUND CIRCUIT CHECK


1. Turn ignition switch OFF.
2. Check continuity between DVD player harness connector M205 terminal 5 and ground.

Connector	Terminal	—	Continuity
M205	5	Ground	Yes

Does continuity exist?

YES >> Inspection End.

NO >> Repair DVD player ground.



VIDEO MONITOR

VIDEO MONITOR : Diagnosis Procedure

INFOID:000000007347894

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch to ACC.

POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITH NAVIGATION]


< DTC/CIRCUIT DIAGNOSIS >

- Check voltage between video monitor harness connector B76 and ground.

(+)		(-)	Ignition switch position	Value (Approx.)
Connector	Terminal			
B76	16	Ground	ACC	Battery voltage

Does battery voltage exist?

- YES >> GO TO 3
NO >> GO TO 2



2.CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect the video monitor connector B76 and the DVD player connector M205.
- Check continuity between the video monitor harness connector B76 (A) and the DVD player connector M205 (B).


A		B		Continuity
Connector	Terminal	Connector	Terminal	
B76	16	M205	9	Yes

- Check continuity between video monitor harness connector B76 (A) and ground.

A		—	Continuity
Connector	Terminal		
B76	16	Ground	No

Are continuity results as specified?

- YES >> Check DVD player power and ground supply. Refer to [AV-339, "DVD PLAYER : Diagnosis Procedure"](#).
NO >> Repair harness or connector.




3.CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect video monitor connector.
- Check continuity between video monitor harness connector B76 and ground.

Connector	Terminal	—	Continuity
B76	12	Ground	Yes
	15		

Does continuity exist?

- YES >> Inspection End.
NO >> Repair harness or connector.



MICROPHONE

MICROPHONE : Diagnosis Procedure

INFOID:000000007347895

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1.CHECK POWER SUPPLY CIRCUIT

POWER SUPPLY AND GROUND CIRCUIT

[BOSE AUDIO WITH NAVIGATION]


< DTC/CIRCUIT DIAGNOSIS >

Check voltage between microphone harness connector R8 terminal 4 and ground.

(+)		(-)	Ignition switch position	Value (Approx.)
Connector	Terminal			
R8	4	Ground	ON	5V

Is approximately 5V present?

- YES >> GO TO 3
NO >> GO TO 2



2. CHECK POWER SUPPLY CIRCUIT (CONTINUITY)

- Turn ignition switch OFF.
- Disconnect microphone and AV control unit harness connectors.
- Check continuity between microphone harness connector R8 (A) terminal 4 and AV control unit harness connector M48 (B) terminal 73.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
R8	4	M48	73	Yes

- Check continuity between microphone harness connector R8 (A) terminal 4 and ground.

A		—	Continuity
Connector	Terminal		
R8	4	Ground	No

Are the continuity test results as specified?

- YES >> Replace the AV control unit. Refer to [AV-420, "Removal and Installation"](#).
NO >> Repair harness or connector.



3. CHECK GROUND CIRCUIT

- Turn ignition switch OFF.
- Disconnect microphone harness connector R8 and AV control unit harness connector M48.
- Check continuity between microphone harness connector R8 (A) terminal 2 and AV control unit harness connector M48 (B) terminal 74.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
R8	2	M48	74	Yes

Does continuity exist?

- YES >> Inspection End.
NO >> Repair harness or connector.



RGB (R: RED) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

RGB (R: RED) SIGNAL CIRCUIT

Description

INFOID:000000007347896

Transmit the image displayed with audio control unit with RGB signal to the display unit.


Diagnosis Procedure

INFOID:000000007347897

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CHECK CONTINUITY RGB (R: RED) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M92 and AV control unit connector M37.
3. Check continuity between display unit harness connector M92 (A) terminal 17 and AV control unit harness connector M37 (B) terminal 21.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M92	17	M37	21	Yes

4. Check continuity between display unit harness connector M92 (A) terminal 17 and ground.

A		—	Continuity
Connector	Terminal		
M92	17	Ground	No


Are the continuity results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK RGB (R: RED) SIGNAL

1. Connect display unit connector M92 and AV control unit connector M37.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M92 terminal 17 and ground.



(+)		(-)	Condition	Reference signal
Connector	Terminal			
M92	17	Ground	Receive audio signal	

Are the voltage readings as specified?

YES >> Replace display unit. Refer to [AV-422, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

RGB (G: GREEN) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

RGB (G: GREEN) SIGNAL CIRCUIT

Description

INFOID:000000007347898

Transmit the image displayed with AV control unit with RGB signal to the display unit.

Diagnosis Procedure


INFOID:000000007347899

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CHECK CONTINUITY RGB (G: GREEN) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M92 and AV control unit connector M37.
3. Check continuity between display unit harness connector M92 (A) terminal 6 and AV control unit harness connector M37 (B) terminal 22.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M92	6	M37	22	Yes



4. Check continuity between display unit harness connector M92 (A) terminal 6 and ground.

A		—	Continuity
Connector	Terminal		
M92	6	Ground	No


Are the continuity results as specified?

- YES >> GO TO 2
 NO >> Repair harness or connector.

2. CHECK RGB (G: GREEN) SIGNAL

1. Connect display unit connector M92 and AV control unit connector M37.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M92 terminal 6 and ground.

(+)		(-)	Condition	Reference signal
Connector	Terminal			
M92	6	Ground	Receive audio signal	



Are voltage readings as specified?

- YES >> Replace display unit. Refer to [AV-422, "Removal and Installation"](#).
 NO >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).

RGB (B: BLUE) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

RGB (B: BLUE) SIGNAL CIRCUIT

Description

INFOID:000000007347900

Transmit the image displayed with AV control unit with RGB signal to the display unit.


Diagnosis Procedure

INFOID:000000007347901

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CHECK CONTINUITY RGB (B: BLUE) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M92 and AV control unit connector M37.
3. Check continuity between display unit harness connector M92 (A) terminal 18 and AV control unit harness connector M37 (B) terminal 23.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M92	18	M37	23	Yes

4. Check continuity between display unit harness connector M92 (A) terminal 18 and ground.

A		—	Continuity
Connector	Terminal		
M92	18	Ground	No


Are continuity results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK RGB (B: BLUE) SIGNAL

1. Connect display unit connector M92 and AV control unit connector M37.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M92 terminal 18 and ground.



(+)		(-)	Condition	Reference signal
Connector	Terminal			
M92	18	Ground	Receive audio signal	

Are voltage readings as specified?

YES >> Replace display unit. Refer to [AV-422, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).

RGB SYNCHRONIZING SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

RGB SYNCHRONIZING SIGNAL CIRCUIT

Description

INFOID:000000007347902

Transmit the RGB synchronizing signal to the display unit so as to synchronize the RGB image displayed with AV control unit.

Diagnosis Procedure


INFOID:000000007347903

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CHECK CONTINUITY RGB SYNCHRONIZING SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M92 and AV control unit connector M37.
3. Check continuity between display unit harness connector M92 (A) terminal 19 and AV control unit harness connector M37 (B) terminal 25.

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M92	19	M37	25	Yes



4. Check continuity between display unit harness connector M92 (A) terminal 19 and ground.

A		—	Continuity
Connector	Terminal		
M92	19	Ground	No

Are continuity results as specified?


YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK RGB SYNCHRONIZING SIGNAL

1. Connect display unit connector M92 and AV control unit connector M37.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M92 terminal 19 and ground.

(+)		(-)	Condition	Reference signal
Connector	Terminal			
M92	19	Ground	Receive audio signal	<p>SKIB3603E</p>



Are voltage readings as specified?

YES >> Replace display unit. Refer to [AV-422, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).

RGB AREA (YS) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

RGB AREA (YS) SIGNAL CIRCUIT

Description

INFOID:000000007347904

Transmits the display area of RGB image displayed by AV control unit with RGB area (YS) signal to display unit.


Diagnosis Procedure

INFOID:000000007347905

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CHECK CONTINUITY RGB AREA (YS) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M92 and AV control unit connector M37.
3. Check continuity between display unit harness connector M92 (A) terminal 9 and AV control unit harness connector M37 (B) terminal 27.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M92	9	M37	27	Yes

4. Check continuity between display unit harness connector M92 (A) terminal 9 and ground.

A		—	Continuity
Connector	Terminal		
M92	9	Ground	No


Are continuity results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK RGB SYNCHRONIZING SIGNAL

1. Connect display unit connector M92 and AV control unit connector M37.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M92 terminal 9 and ground.



(+) Connector		(-)	Condition	Reference signal
Connector	Terminal			
M92	9	Ground	Receive audio signal	

Are voltage readings as specified?

YES >> Replace display unit. Refer to [AV-422, "Removal and Installation"](#).

NO >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).

HORIZONTAL SYNCHRONIZING (HP) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

HORIZONTAL SYNCHRONIZING (HP) SIGNAL CIRCUIT

Description

INFOID:000000007347906

In composite image (AUX image, camera image), transmit the vertical synchronizing (VP) signal and horizontal synchronizing (HP) signal from display unit to AV control unit so as to synchronize the RGB images displayed with AV control unit such as the image quality adjusting menu, etc.


Diagnosis Procedure

INFOID:000000007347907

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CHECK CONTINUITY HORIZONTAL SYNCHRONIZING (HP) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M92 and AV control unit connector M37.
3. Check continuity between display unit harness connector M92 (A) terminal 8 and AV control unit harness connector M37 (B) terminal 28.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M92	8	M37	28	Yes

4. Check continuity between display unit harness connector M92 (A) terminal 8 and ground.


A		—	Continuity
Connector	Terminal		
M92	8	Ground	No

Are continuity results as specified?

- YES >> GO TO 2
 NO >> Repair harness or connector.

2. CHECK HORIZONTAL SYNCHRONIZING (HP) SIGNAL

1. Connect display unit connector M92 and AV control unit connector M37.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M92 terminal 8 and ground.



(+) Connector		(-) Terminal	Condition	Reference signal
M92	8	Ground	Receive audio signal	<p>SKIB3601E</p>

Are voltage readings as specified?

- YES >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).
 NO >> Replace display unit. Refer to [AV-422, "Removal and Installation"](#).

VERTICAL SYNCHRONIZING (VP) SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

VERTICAL SYNCHRONIZING (VP) SIGNAL CIRCUIT

Description

INFOID:000000007347908

In composite image (AUX image, camera image), transmit the vertical synchronizing (VP) signal and horizontal synchronizing (HP) signal from display unit to AV control unit so as to synchronize the RGB images displayed with AV control unit such as the image quality adjusting menu, etc.


Diagnosis Procedure

INFOID:000000007347909

Regarding Wiring Diagram information, refer to [AV-385. "Wiring Diagram - With Navigation System"](#).

1. CHECK CONTINUITY VERTICAL SINCHRONIZING (VP) SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect display unit connector M92 and AV control unit connector M37.
3. Check continuity between display unit harness connector M92 (A) terminal 20 and AV control unit harness connector M37 (B) terminal 29.



A		B		Continuity
Connector	Terminal	Connector	Terminal	
M92	20	M37	29	Yes

4. Check continuity between display unit harness connector M92 (A) terminal 20 and ground.

A		—	Continuity
Connector	Terminal		
M92	20	Ground	No


Are continuity results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK VERTICAL SINCHRONIZING (VP) SIGNAL

1. Connect display unit connector M92 and AV control unit connector M37.
2. Turn ignition switch ON.
3. Check signal between display unit harness connector M92 terminal 20 and ground.



(+)		(-)	Condition	Reference signal
Connector	Terminal			
M92	20	Ground	Receive audio signal	

Are voltage readings as specified?

YES >> Replace AV control unit. Refer to [AV-420. "Removal and Installation"](#).

NO >> Replace display unit. Refer to [AV-422. "Removal and Installation"](#).

FRONT DOOR SPEAKER

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

FRONT DOOR SPEAKER

Description

INFOID:000000007347910

The AV control unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the front door speakers using the audio signal circuits.

Diagnosis Procedure

INFOID:000000007347911

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CONNECTOR CHECK

Check the AV control unit, BOSE speaker amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. HARNESS CHECK

1. Disconnect BOSE speaker amp. connector B75 and suspect speaker connector.
2. Check continuity between BOSE speaker amp. harness connector B75 (A) and suspect speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B75	13	D12	1	Yes
	14		2	
	15	D112	1	
	16		2	

3. Check continuity between BOSE speaker amp. harness connector B75 (A) and ground.


A		—	Continuity
Connector	Terminal		
B75	13	Ground	No
	14		
	15		
	15		

Are continuity test results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3. FRONT SPEAKER SIGNAL CHECK



ALNIA0530GB

FRONT DOOR SPEAKER

[BOSE AUDIO WITH NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect BOSE speaker amp. connector B75 and suspect speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B75 terminals with CONSULT or oscilloscope.

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
B75	13	14	Receive audio signal	
	15	16		

Is audio signal voltage as specified?

YES >> Replace suspect speaker. Refer to [AV-424. "Removal and Installation"](#).

NO >> GO TO 4

4. HARNESS CHECK

1. Disconnect AV control unit connector M39 and BOSE speaker amp. connector B75.
2. Check continuity between AV control unit harness connector M39 (A) and BOSE speaker amp. harness connector B75 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M39	2	B75	30	Yes
	3		29	
	11		28	
	12		27	

3. Check continuity between AV control unit harness connector M39 (A) and ground.



A		—	Continuity
Connector	Terminal		
M39	2	Ground	No
	3		
	11		
	12		

Are continuity test results as specified?

YES >> GO TO 5

NO >> Repair harness or connector.

5. FRONT SPEAKER SIGNAL CHECK



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P


AV

FRONT DOOR SPEAKER

[BOSE AUDIO WITH NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >


1. Connect AV control unit connector and BOSE speaker amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M39 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M39	2	3	Receive audio signal	
	11	12		

SKIA0177E

Are the audio signal voltage readings as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-427, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).



AWNIA00322Z

FRONT TWEETER

Description

INFOID:000000007347912

The AV control unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the tweeters using the audio signal circuits.

Diagnosis Procedure

INFOID:000000007347913

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1.CONNECTOR CHECK

Check the AV control unit, BOSE speaker amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair the terminal and connector.


2.HARNES CHECK

1. Disconnect BOSE speaker amp. connector B75 and suspect tweeter connector.
2. Check continuity between BOSE speaker amp. harness connector B75 (A) and suspect tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B75	13	M109	1	Yes
	14		2	
	15	M111	1	
	16		2	

3. Check continuity between BOSE speaker amp. harness connector B75 (A) and ground.

A		—	Continuity
Connector	Terminal		
B75	13	Ground	No
	14		
	15		
	16		



Are continuity test results as specified?

- YES >> GO TO 3
- NO >> Repair harness or connector.

3.FRONT TWEETER SIGNAL CHECK

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV


FRONT TWEETER

[BOSE AUDIO WITH NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect BOSE speaker amp. connector B75 and suspect tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B75 terminals with CONSULT or oscilloscope.

Connector	Terminal		Condition	Reference signal
	(+)	(-)		
B75	13	14	Receive audio signal	
	15	16		



Is audio signal voltage as specified?

YES >> Replace suspect tweeter. Refer to [AV-423. "Removal and Installation"](#).

NO >> GO TO 4


4. HARNESS CHECK

1. Disconnect AV control unit connector M39 and BOSE speaker amp. connector B75.
2. Check continuity between AV control unit harness connector M39 (A) and BOSE speaker amp. harness connector B75 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M39	2	B75	30	Yes
	3		29	
	11		28	
	12		27	

3. Check continuity between AV control unit harness connector M39 (A) and ground.

A		—	Continuity
Connector	Terminal		
M39	2	Ground	No
	3		
	11		
	12		



Are continuity test results as specified?

YES >> GO TO 5

NO >> Repair harness or connector.

5. FRONT TWEETER SIGNAL CHECK

FRONT TWEETER

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]


1. Connect AV control unit connector and BOSE speaker amp. connector.
2. Turn ignition switch ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M39 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M39	2	3	Receive audio signal	
	11	12		

SKIA0177E

Are the audio signal voltage readings as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-427, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

REAR DOOR SPEAKER

[BOSE AUDIO WITH NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

REAR DOOR SPEAKER

Description

INFOID:000000007347914

The AV control unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the rear door speakers using the audio signal circuits.

Diagnosis Procedure

INFOID:000000007347915

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CONNECTOR CHECK

Check the AV control unit, BOSE speaker amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. HARNESS CHECK

1. Disconnect BOSE speaker amp. connectors B75 and suspect speaker connector.
2. Check continuity between BOSE speaker amp. harness connectors B75 (A) and suspect speaker harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B75	9	D207	1	Yes
	10		2	
	11	D307	1	
	12		2	

3. Check continuity between BOSE speaker amp. harness connectors B75 (A) and ground.


Connector	Terminal	-	Continuity
B75	9	Ground	No
	10		
	11		
	12		

Are the continuity test results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3. REAR DOOR SPEAKER SIGNAL CHECK



ALNIA0533GB

REAR DOOR SPEAKER


[BOSE AUDIO WITH NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect BOSE speaker amp. connectors and suspect speaker connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connectors B75 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B75	9	10	Receive audio signal	
	11	12		

SKIA0177E



Are audio signal voltage readings as specified?

YES >> Replace suspect speaker. Refer to [AV-425, "Removal and Installation of Rear Door Speaker"](#).

NO >> GO TO 4


4. HARNESS CHECK

1. Disconnect AV control unit connector M39 and BOSE speaker amp. connector B75.
2. Check continuity between AV control unit harness connector M39 (A) and BOSE speaker amp. harness connector B75 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M39	4	B75	26	Yes
	5		25	
	13		24	
	14		23	

3. Check continuity between AV control unit harness connector M39 (A) and ground.

A		—	Continuity
Connector	Terminal		
M39	4	Ground	No
	5		
	13		
	14		



Are the continuity test results as specified?

YES >> GO TO 5

NO >> Repair harness or connector.

5. REAR DOOR SPEAKER SIGNAL CHECK

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

REAR DOOR SPEAKER

[BOSE AUDIO WITH NAVIGATION]


< DTC/CIRCUIT DIAGNOSIS >

1. Connect AV control unit connector M39 and BOSE speaker amp. connector B75.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M39 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M39	4	5	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>
	13	14		

Is the audio signal voltage reading as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-427, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).



REAR TWEETER

Description

INFOID:000000007347916

The AV control unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the rear tweeters using the audio signal circuits.

Diagnosis Procedure

INFOID:000000007347917

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1.CONNECTOR CHECK

Check the AV control unit, BOSE speaker amp. and speaker connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair the terminal and connector.


2.HARNES CHECK

1. Disconnect BOSE speaker amp. connectors B75 and suspect tweeter connector.
2. Check continuity between BOSE speaker amp. harness connectors B75 (A) and suspect tweeter harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
B75	9	D208	1	Yes
	10		2	
	11	D308	1	
	12		2	

3. Check continuity between BOSE speaker amp. harness connectors B75 (A) and ground.

Connector	Terminal	-	Continuity
B75	9	Ground	No
	10		
	11		
	12		



Are the continuity test results as specified?

- YES >> GO TO 3
- NO >> Repair harness or connector.

3.REAR TWEETER SIGNAL CHECK

REAR TWEETER


[BOSE AUDIO WITH NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect BOSE speaker amp. connectors and suspect tweeter connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connectors B75 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B75	9	10	Receive audio signal	
	11	12		

SKIA0177E



Are audio signal voltage readings as specified?

YES >> Replace suspect tweeter. Refer to [AV-425, "Removal and Installation of Rear Door Speaker"](#).

NO >> GO TO 4


4. HARNESS CHECK

1. Disconnect AV control unit connector M39 and BOSE speaker amp. connector B75.
2. Check continuity between AV control unit harness connector M39 (A) and BOSE speaker amp. harness connector B75 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M39	4	B75	26	Yes
	5		25	
	13		24	
	14		23	

3. Check continuity between AV control unit harness connector M39 (A) and ground.

A		—	Continuity
Connector	Terminal		
M39	4	Ground	No
	5		
	13		
	14		



Are the continuity test results as specified?

YES >> GO TO 5

NO >> Repair harness or connector.


5. REAR TWEETER SIGNAL CHECK

REAR TWEETER

< DTC/CIRCUIT DIAGNOSIS >


[BOSE AUDIO WITH NAVIGATION]

1. Connect AV control unit connector M39 and BOSE speaker amp. connector B75.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M39 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M39	4	5	Receive audio signal	 <small>SKIA0177E</small>
	13	14		

Is the audio signal voltage reading as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-427, "Removal and Installation"](#).
- NO >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

SUBWOOFER

Description

INFOID:000000007347918

The AV control unit sends audio signals to the BOSE speaker amp. The BOSE speaker amp. amplifies the audio signals before sending them to the subwoofer using the audio signal circuits.

Diagnosis Procedure

INFOID:000000007347919

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CONNECTOR CHECK

Check the AV control unit, BOSE speaker amp. and subwoofer connectors for the following:

- Proper connection
- Damage
- Disconnected or loose terminals

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. VERIFY SUBWOOFER POWER AND GROUND SUPPLY

Check power and ground supply to the subwoofer. Refer to [AV-338, "SUBWOOFER : Diagnosis Procedure"](#)

Did the power and ground supply check OK?

YES >> GO TO 3

NO >> Repair harness or connector.

3. HARNESS CHECK

1. Disconnect BOSE speaker amp. connectors and subwoofer connector.
2. Check continuity between BOSE speaker amp. harness connectors B74 (A) and B75 (B) and subwoofer harness connector B72 (C).

Connector	Terminal	Connector	Terminal	Continuity
A: B74	3	C: B72	1	Yes
	19		2	
B: B75	22		4	

3. Check continuity between BOSE speaker amp. harness connector B74 (A) and B75 (B) and ground.


Connector	Terminal	-	Continuity
A: B74	3	Ground	No
	19		
B: B75	22		

Are the continuity test results as specified?

YES >> GO TO 4

NO >> Repair harness or connector.

4. SUBWOOFER AMP ON SIGNAL CHECK



SUBWOOFER

[BOSE AUDIO WITH NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect BOSE speaker amp. connector B74.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check voltage between subwoofer connector B72 terminal 4 and ground.

(+)		(-)	Voltage
Connector	Terminal		
B72	4	Ground	Battery voltage


Are the voltage readings as specified?

YES >> GO TO 5

NO >> Replace BOSE speaker amp. Refer to [AV-427, "Removal and Installation"](#)

5.SUBWOOFER AUDIO SIGNAL CHECK

1. Connect BOSE speaker amp. connectors and subwoofer connector.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between BOSE speaker amp. harness connector B74 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
B74	19	3	Receive audio signal	 <p style="text-align: right; font-size: small;">SKIA0177E</p>



Is the audio signal voltage as specified?

YES >> Replace subwoofer. Refer to [AV-428, "Removal and Installation"](#).

NO >> GO TO 6

6.HARNESS CHECK

1. Turn ignition switch OFF.



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

SUBWOOFER

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

2. Disconnect AV control unit connector M39 and BOSE speaker amp. connector B75.
3. Check continuity between AV control unit harness connector M39 (A) and BOSE speaker amp. harness connector B75 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M39	4	B75	26	Yes
	5		25	
	13		24	
	14		23	

4. Check continuity between AV control unit harness connector M39 (A) and ground.


A		—	Continuity
Connector	Terminal		
M39	4	Ground	No
	5		
	13		
	14		

Are the continuity test results as specified?

- YES >> GO TO 7
 NO >> Repair harness or connector.



7. BACK DOOR SPEAKER SIGNAL CHECK

1. Connect AV control unit connector M39 and BOSE speaker amp. connector B75.
2. Turn ignition switch to ACC.
3. Push "POWER" switch.
4. Check the signal between AV control unit harness connector M39 terminals with CONSULT or oscilloscope.

Connector	Terminals		Condition	Reference signal
	(+)	(-)		
M39	4	5	Receive audio signal	
	13	14		

Is the audio signal voltage reading as specified?

- YES >> Replace BOSE speaker amp. Refer to [AV-427, "Removal and Installation"](#).
 NO >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).



AMP ON SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

AMP ON SIGNAL CIRCUIT

Description

INFOID:000000007347920

When the audio system is turned on, a voltage signal is supplied from the AV control unit to the BOSE speaker amp. When this signal is received, the BOSE speaker amp. will turn on.

Diagnosis Procedure

INFOID:000000007347921

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).


1. CHECK AMP ON SIGNAL (BOSE SPEAKER AMP)

1. Turn audio system ON.
2. Check voltage between BOSE speaker amp. harness connector B75 terminal 31 and ground.

(+)		(-)	Value (Approx.)
Connector	Terminal		
B75	31	Ground	Battery Voltage

Is battery voltage present?

- YES >> Inspection End.
NO >> GO TO 2




2. CHECK AMP ON SIGNAL (AV CONTROL UNIT)

Check voltage between AV control unit harness connector M39 terminal 1 and ground.

(+)		(-)	Value (Approx.)
Connector	Terminal		
M39	1	Ground	Battery Voltage

Is battery voltage present?

- YES >> Repair harness or connector.
NO >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

STEERING SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

STEERING SWITCH

Description

INFOID:000000007347922

When one of the steering wheel audio control switches is pushed, the resistance in the steering wheel audio control switch circuit changes depending on which button is pushed.


Diagnosis Procedure


INFOID:000000007347923

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CHECK STEERING WHEEL AUDIO CONTROL SWITCH RESISTANCE

1. Turn ignition switch OFF.
2. Disconnect steering wheel audio control switch connector M102.
3. Check resistance between steering switch connector terminals.

Terminal	Signal name	Condition	Resistance (Ω) (Approx.)	
16	17	Seek (down)	Depress ▽ switch.	165
		Volume (down)	Depress VOL down switch.	652
		Mode/End	Depress MODE switch.	0
20	17	Seek (up)	Depress △ switch.	165
		Volume (up)	Depress VOL up switch.	652
		Phone/Send	Depress  switch.	0



Do the steering wheel audio control switches check OK?


YES >> GO TO 2

NO >> Replace steering wheel audio control switch. Refer to [AV-436, "Removal and Installation"](#).

2. CHECK HARNESS

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector M39 and spiral cable connector M30.
3. Check continuity between AV control unit harness connector M39 (A) and spiral cable harness connector M30 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M39	6	M30	24	Yes
	15		31	
	16		32	



4. Check continuity between AV control unit connector M39 (A) and ground.

A		—	Continuity
Connector	Terminal		
M39	6	Ground	No
	15		
	16		

STEERING SWITCH

[BOSE AUDIO WITH NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >


Are the continuity results as specified?

- YES >> GO TO 3
- NO >> Repair harness.

3. SPIRAL CABLE CHECK

1. Disconnect spiral cable connector M102.
2. Check continuity between spiral cable harness connector M30 (A) and M102 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M30	24	M102	20	Yes
	31		17	
	32		16	



Does continuity exist?

- YES >> Inspection End.
- NO >> Replace spiral cable. Refer to [SR-7, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

MICROPHONE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

MICROPHONE SIGNAL CIRCUIT

Description

INFOID:000000007347924

Voice signals are transmitted from the microphone to the AV control unit using the microphone signal circuits.

Diagnosis Procedure

INFOID:000000007347925

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. VERIFY MICROPHONE POWER AND GROUND SUPPLY

Check power and ground supply to the microphone. Refer to [AV-341, "MICROPHONE : Diagnosis Procedure"](#).

Did the power and ground supply check OK?

YES >> GO TO 2

NO >> • Check connector housings for disconnected or loose terminals.
• Repair harness or connector.

2. CHECK HARNESS BETWEEN AV CONTROL UNIT AND MICROPHONE

1. Turn ignition switch OFF.
2. Disconnect AV control unit connector and microphone connector.
3. Check continuity between AV control unit harness connector M48 (A) and microphone harness connector R8 (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
M48	75	R8	1	Yes
	74		2	
	73		4	

4. Check continuity between AV control unit harness connector M48 (A) and ground.


A		—	Continuity
Connector	Terminal		
M48	75	Ground	No
	74		
	73		

Are the continuity results as specified?

YES >> GO TO 3

NO >> Repair harness or connector.

3. CHECK MICROPHONE SIGNAL




MICROPHONE SIGNAL CIRCUIT

[BOSE AUDIO WITH NAVIGATION]

< DTC/CIRCUIT DIAGNOSIS >

Check signal between AV control unit harness connector M48 terminals 74 and 75 with CONSULT or oscilloscope.

Connector	(+)	(-)	Reference signal
	Terminal	Terminal	
M48	75	74	<p>While speaking into MIC</p> <p>PKIB5037J</p>



Are voltage readings as specified?

- YES >> Replace AV control unit. Refer to [AV-420, "Removal and Installation"](#).
- NO >> Replace microphone. Refer to [AV-437, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

REAR VIEW CAMERA IMAGE SIGNAL CIRCUIT

Description

INFOID:000000007347926

Rear view camera signals are transmitted from the rear view camera to the display unit using the camera signal circuits.

Diagnosis Procedure

INFOID:000000007347927

Regarding Wiring Diagram information, refer to [AV-385, "Wiring Diagram - With Navigation System"](#).

1. CHECK CAMERA IMAGE SIGNAL CIRCUIT CONTINUITY

NOTE:

Apply parking brakes before proceeding.

1. Turn ignition switch OFF.
2. Disconnect display unit connector M92 and rear view camera connector D551.
3. Check continuity between display unit harness connector M92 terminals 12, 14, 24 and rear view camera harness connector D551 terminals 3, 5 and 6.

12 - 6 : Continuity should exist.

14 - 5 : Continuity should exist.

24 - 3 : Continuity should exist.

4. Check continuity between display unit harness connector M92 terminals 14, 12, 24 and ground.

12, 14, 24 - Ground : Continuity should not exist.

Is inspection result OK?


YES >> GO TO 2

NO >> Repair harness or connector.

2. CHECK CAMERA IMAGE SIGNAL

1. Connect display unit connector M92 and rear view camera connector D551.
2. Turn ignition switch ON.
3. Shift transmission into reverse.
4. Check signal between display unit harness connector M92 terminals 12 and 14.

12 - 14 :



SKIB2251J

Is inspection result OK?

YES >> Replace display unit. Refer to [AV-422, "Removal and Installation"](#).

NO >> Replace rear view camera. Refer to [AV-438, "Removal and Installation"](#).

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITH NAVIGATION]

ECU DIAGNOSIS INFORMATION

AV CONTROL UNIT

Reference Value


INFOID:000000007347928

VALUES ON THE DIAGNOSIS TOOL

CONSULT data monitor item

Display Item	Display	Vehicle status	Remarks
VHCL SPD SIG	ON	Vehicle speed >0 km/h (0 MPH)	Changes in indication may be delayed. This is normal.
	OFF	Vehicle speed =0 km/h (0 MPH)	
PKB SIG	ON	Parking brake is applied.	Changes in indication may be delayed. This is normal.
	OFF	Parking brake is released.	
ILLUM SIG	ON	Block the light beam from the auto light optical sensor when the light SW is ON.	—
	OFF	Expose the auto light optical sensor to light when the light SW is OFF or ON.	
IGN SIG	ON	Ignition switch ON	—
	OFF	Ignition switch in ACC position	
REV SIG	ON	Selector lever in R position	Changes in indication may be delayed. This is normal.
	OFF	Selector lever in any position other than R	

TERMINAL LAYOUT



PHYSICAL VALUES








Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/Output			
1 (SB)	Ground	Amp. ON signal	Output	Ignition switch ON	—	Battery voltage
2 (BR)	3 (B)	Pre-amp. audio signal front LH	Output	Ignition switch ON	Audio output	

SKIB3609E

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >







[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
4 (BR/W)	5 (BR/Y)	Pre-amp. audio signal rear LH	Output	Ignition switch ON	Audio output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
6 (Y)	15 (L)	Steering switch signal A	Input	Ignition switch ON	Pressing  switch	0V
					Pressing  switch	0.75V
					Pressing VOL up switch	2V
					Except for above	5V
7 (G/Y)	Ground	ACC power supply	Input	Ignition switch ACC	-	Battery voltage
9 (V)	Ground	Illumination signal	Input	Ignition switch OFF	Lighting switch is OFF.	0V
					Lighting switch is ON.	Battery voltage
11 (G/Y)	12 (G/O)	Pre-amp. audio signal front RH	Output	Ignition switch ON	Audio output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
13 (G/R)	14 (B)	Audio signal rear RH	Output	Ignition switch ON	Audio output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
15 (L)	Ground	Steering switch signal ground	—	Ignition switch ON	—	0V
16 (G)	15 (L)	Steering switch signal B	Input	Ignition switch ON	Pressing  switch	0V
					Pressing  switch	0.75V
					Pressing VOL down switch	2V
					Except for above	5V
19 (Y)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
20 (B)	Ground	Ground	—	Ignition switch ON	—	0V

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
21 (L)	Ground	RGB signal (R: red)	Output	Ignition switch ON	Start confirmation/adjust- ment mode, and then dis- play color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.	
22 (G)	Ground	RGB signal (G: green)	Output	Ignition switch ON	Start confirmation/adjust- ment mode, and then dis- play color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.	
23 (Y)	Ground	RGB signal (B: blue)	Output	Ignition switch ON	Start confirmation/adjust- ment mode, and then dis- play color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.	
25 (R)	Ground	RGB synchronizing signal	Output	Ignition switch ON	—	
27 (G)	Ground	RGB area (YS) signal	Output	Ignition switch ON	At RGB image displayed	5V
27 (G)	Ground	RGB area (YS) signal	Output	Ignition switch ON	At rear view camera image displayed	
28 (B)	Ground	Horizontal synchronizing (HP) signal	Input	Ignition switch ON	—	







A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >




[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
29 (W)	Ground	Vertical synchronizing (VP) signal	Input	Ignition switch ON	—	 <p style="text-align: right; font-size: small;">SKIB3598E</p>
30 (V)	Ground	Communication signal (CONT→DISP)	Output	Ignition switch ON	When adjusting display brightness	 <p style="text-align: right; font-size: small;">FKIB5039J</p>
31 (LG)	Ground	Communication signal (DISP→CONT)	Input	Ignition switch ON	When adjusting display brightness	 <p style="text-align: right; font-size: small;">FKIB5039J</p>
34	—	Antenna main	—	—	—	—
35	—	Antenna B+	—	—	—	—
42 (W)	58 (B)	DVD audio signal LH	Input	Ignition switch ON	When DVD player is operating	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
43 (R)	59 (G)	DVD audio signal RH	Input	Ignition switch ON	When DVD player is operating	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
48 (SB)	Ground	CD/DVD eject signal	Input	—	Pressing the eject switch	0V
					Except for above	3.3V
50 (B)	51 (R)	AUX jack audio signal LH	Input	Ignition switch ON	When AUX mode is selected	 <p style="text-align: right; font-size: small;">SKIB3609E</p>

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITH NAVIGATION]


Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
61 (G)	45 (W)	Headphone LH audio signal	Output	Ignition switch ON	When DVD player is operating	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
62 (R)	46 (B)	Headphone RH audio signal	Output	Ignition switch ON	When DVD player is operating	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
65 (GR)	Ground	A/C and AV switch assembly ground	—	Ignition switch ON	—	0V
66 (W)	51 (R)	AUX jack audio signal RH	Input	Ignition switch ON	When AUX mode is selected	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
68 (B)	Ground	Ground	—	Ignition switch ON	—	0V
69 (R/B)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
70 (B)	Ground	Ground	—	Ignition switch ON	—	0V
71 (R/B)	Ground	Battery power supply	Input	Ignition switch OFF	—	Battery voltage
72 (G/Y)	Ground	ACC power supply	Input	Ignition switch ACC	—	Battery voltage
73 (G)	Ground	MIC power	Output	Ignition switch ON	—	5V
74	—	Shield	—	—	—	—
75 (R)	—	MIC signal	Input	Ignition switch ON	—	—
76	—	Shield	—	—	—	—
82 (W/G)	Ground	IGN ON or START power supply	Input	Ignition switch ON or START	—	Battery voltage

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
83 (G)	Ground	Parking brake signal	Input	Ignition switch ON	Parking brake ON	0V
					Parking brake OFF	Battery voltage
84 (W)	Ground	Reverse signal	Input	Ignition switch ON	R position	Battery voltage
					Other than R position	0V
85 (LG)	Ground	Vehicle speed signal (8-pulse)	Input	Ignition switch ON	When vehicle speed is approx. 40 km/h (25MPH)	 <p style="text-align: right; font-size: small;">SKIA6649J</p>
87 (B)	—	Ground	Input	—	—	0V
89 (B)	—	Ground	Input	—	—	0V
90 (B)	—	Ground	Input	—	—	0V
95 (L)	—	AV communication signal 2 (H)	Input/ Output	—	—	—
96 (P)	—	AV communication signal 2 (L)	Input/ Output	—	—	—
97 (L)	—	AV communication signal 1 (H)	Input/ Output	—	—	—
98 (P)	—	AV communication signal 1 (L)	Input/ Output	—	—	—
99 (L)	—	CAN-H	Input/ Output	—	—	—
100 (P)	—	CAN-L	Input/ Output	—	—	—
108	—	Satellite antenna signal	Input	—	—	—
109	—	GPS antenna	Input	—	—	—
110	—	GPS antenna	Input	—	—	—

DTC Index

INFOID:000000007347929

Self-diagnosis results display item

Error item	Refer to
CAN COMM CIRCUIT [U1000]	AV-309. "DTC Logic"
CONTROL UNIT (CAN) [U1010]	AV-310. "DTC Logic"
Control Unit FLASH-ROM [U1200]	AV-311. "DTC Logic"
Gyro NO CONN [U1201]	AV-312. "DTC Logic"
CAN CONT [U1216]	AV-317. "DTC Logic"
BLUETOOTH CONN [U1217]	AV-318. "DTC Logic"
HDD CONN [U1218]	AV-319. "DTC Logic"
HDD READ [U1219]	AV-320. "DTC Logic"

AV CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITH NAVIGATION]

Error item	Refer to
XM SERIAL COMM [U1220]	AV-321, "DTC Logic"
HDD WRITE [U121A]	AV-322, "DTC Logic"
HDD COMM [U121B]	AV-323, "DTC Logic"
HDD ACCESS [U121C]	AV-324, "DTC Logic"
DSP CONN [U121D]	AV-325, "DTC Logic"
DSP COMM [U121E]	AV-326, "DTC Logic"
INTERNAL COMM [U121F]	AV-327, "DTC Logic"
GPS COMM [U1204]	AV-313, "DTC Logic"
GPS ROM [U1205]	AV-314, "DTC Logic"
GPS RAM [U1206]	AV-315, "DTC Logic"
GPS RTC [U1207]	AV-316, "DTC Logic"
FRONT DISP CONN [U1243]	AV-328, "DTC Logic"
GPS ANTENNA CONN [U1244]	AV-330, "DTC Logic"
XM ANTENNA CONN [U1258]	AV-331, "DTC Logic"
AV COMM CIRCUIT [U1300]	AV-332, "Description"
CONTROL UNIT (AV) [U1310]	AV-333, "DTC Logic"

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

DISPLAY UNIT

< ECU DIAGNOSIS INFORMATION >


[BOSE AUDIO WITH NAVIGATION]

DISPLAY UNIT

Reference Value

INFOID:000000007347930

TERMINAL LAYOUT









PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
1 (B)	Ground	Ground	—	Ignition switch ON	—	0V
2 (Y)	Ground	Battery power	Input	—	—	Battery voltage
3 (V)	Ground	ACC power	Input	Ignition switch ACC	—	Battery voltage
4 (R)	Ground	DVD video (-)	—	Ignition switch ON	When DVD mode is select- ed	0V
6 (G)	Ground	RGB signal (G: green)	Input	Ignition switch ON	Start confirmation/adjust- ment mode, and then dis- play color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNO- SIS screen.	<p>SKIB2236J</p>
8 (B)	Ground	Horizontal synchronizing (HP) signal	Output	Ignition switch ON	—	<p>SKIB3601E</p>
9 (G)	Ground	RGB area (YS) signal	Input	Ignition switch ON	At RGB image displayed	5V
					At rear view camera image displayed	<p>PKIB4948J</p>

DISPLAY UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
11 (V)	Ground	Communication signal (CONT→DISP)	Input	Ignition switch ON	When adjusting display brightness	 <p>PKIB5039J</p>
12 (B)	14 (W)	Rear view camera video (+)	Input	Ignition switch ON	Transmission in reverse	 <p>SKIB2251J</p>
13 (B)	Ground	Ground	—	Ignition switch ON	—	0V
14 (W)	Ground	Rear view camera video (-)	—	Ignition switch ON	Transmission in reverse	0V
15 (G)	4 (R)	DVD video (+)	Input	Ignition switch ON	When DVD mode is select- ed	 <p>SKIB2251J</p>
17 (L)	Ground	RGB signal (R: red)	Input	Ignition switch ON	Start confirmation/adjust- ment mode, and then dis- play color bar by select- ing "Color Spectrum Bar" on DISPLAY DIAGNOSIS screen.	 <p>SKIB2238J</p>
18 (Y)	Ground	RGB signal (B: blue)	Input	Ignition switch ON	Start confirmation/adjust- ment mode, and then dis- play color bar by selecting "Color Spectrum Bar" on DISPLAY DIAGNO- SIS screen.	 <p>SKIB2237J</p>
19 (R)	Ground	RGB synchronizing signal	Input	Ignition switch ON	—	 <p>SKIB3603E</p>

A
B
C
D
E
F
G
H
I
J
K
L
M



AV

O
P

DISPLAY UNIT

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
20 (W)	Ground	Vertical synchronizing (VP) signal	Output	Ignition switch On	—	 <p style="text-align: right; font-size: small;">SKIB3598E</p>
22 (LG)	Ground	Communication signal (DISP→CONT)	Output	Ignition switch ON	When adjusting display brightness	 <p style="text-align: right; font-size: small;">PKIB5039J</p>
24	—	Shield	—	—	—	—

BOSE SPEAKER AMP

< ECU DIAGNOSIS INFORMATION >


[BOSE AUDIO WITH NAVIGATION]

BOSE SPEAKER AMP

Reference Value

INFOID:000000007347931

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
1 (Y)	Ground	Battery power	Input	—	—	Battery voltage
9 (B)	10 (G)	Audio signal rear door speaker and tweeter LH	Output	Ignition switch ON	Audio output	 <small>SKIB3609E</small>
11 (GR)	12 (O)	Audio signal rear door speaker and tweeter RH	Output	Ignition switch ON	Audio output	 <small>SKIB3609E</small>
13 (LG)	14 (L)	Audio signal front door speaker and tweeter LH	Output	Ignition switch ON	Audio output	 <small>SKIB3609E</small>
15 (W)	16 (R)	Audio signal front door speaker and tweeter RH	Output	Ignition switch ON	Audio output	 <small>SKIB3609E</small>






A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

BOSE SPEAKER AMP

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITH NAVIGATION]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
17 (B)	Ground	Ground	—	Ignition switch ON	—	0V
19 (SB)	3 (B)	Audio signal subwoofer	Output	Ignition switch ON	Audio output	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
22 (Y)	Ground	Subwoofer amp. ON signal	Output	Ignition switch ACC	Audio output	Battery voltage
24 (G/R)	23 (B)	Audio signal rear RH	Input	Ignition switch ON	Audio input	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
26 (BR/W)	25 (BR/Y)	Audio signal rear LH	Input	Ignition switch ON	Audio input	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
28 (G/Y)	27 (G/O)	Audio signal front RH	Input	Ignition switch ON	Audio input	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
30 (BR)	29 (B)	Audio signal front LH	Input	Ignition switch ON	Audio input	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
31 (SB)	Ground	Amp. ON signal	Input	Ignition switch ON	Audio output	Battery voltage

DVD PLAYER


< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITH NAVIGATION]

DVD PLAYER

Reference Value

INFOID:000000007347932





PHYSICAL VALUES

Terminal		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/Output			
1 (B)	2 (W)	DVD audio signal LH	Output	Ignition switch ON	With operation of the DVD player	<p>SKIB3609E</p>
5 (B)	Ground	Ground	—	Ignition switch ON	—	0V
6 (BR)	Ground	Illumination control (pulse width modulated)	—	—	With lighting switch ON	—
7 (L)	Ground	CAN communication	Input/Output	Ignition switch ON	—	—
9 (BR)	Ground	Video monitor power supply	Output	Ignition switch ON	With DVD player operation	12V
10 (GR)	Ground	Switch power	Output	Ignition switch ON	With DVD player operation	5V
12 (W/L)	Ground	VTR (+)	Output	Ignition switch ON	With DVD player operation	—
13 (O/L)	Ground	VTR (-)	Output	Ignition switch ON	With DVD player operation	—
14 (Y)	Ground	Display ground	—	Ignition switch ON	With DVD player operation	0V
16 (V)	—	Data receive	Input	—	—	—

DVD PLAYER

< ECU DIAGNOSIS INFORMATION >

[BOSE AUDIO WITH NAVIGATION]

Terminal		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output			
17 (R)	18 (G)	DVD audio signal RH	Output	Ignition switch ON	With DVD player operation	 <p style="text-align: right; font-size: small;">SKIB3609E</p>
21 (Y)	Ground	Battery power	Input	—	—	12V
22 (SB)	Ground	Illumination power	Input	—	With instrument illumination ON	12V
23 (P)	Ground	CAN communication	Input/ Output	Ignition switch ON	—	0V
24 (G/B)	Ground	ACC power	Input	Ignition switch ACC or ON	—	12V
26 (P)	Ground	Ground	Input	Ignition switch ON	—	0V
28 (G)	Ground	Video out	Input	Ignition switch ACC or ON	—	 <p style="text-align: right; font-size: small;">SKIB2251J</p>
32 (LG)	—	Data transmit	Output	—	—	—


< WIRING DIAGRAM >

WIRING DIAGRAM

BOSE AUDIO SYSTEM

Wiring Diagram - With Navigation System

INFOID:000000007347933




ABNWA1326GB

BOSE AUDIO SYSTEM

< WIRING DIAGRAM >

[BOSE AUDIO WITH NAVIGATION]




ABNWA1328GB

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P


BOSE AUDIO SYSTEM CONNECTORS - WITH NAVIGATION SYSTEM

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	G	-
6	R	-
7	SHIELD	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2P	W/G	-
4P	G/B	-
16P	R/B	-

Connector No.	M8
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
2	L	-
3	G	-(WITH BOSE AUDIO SYSTEM)

Connector No.	M23
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
36	-	-
37	-	-
38	-	-
39	-	-
40	-	-
41	-	-

Terminal No.	Color of Wire	Signal Name
42	W	AUDIO BUS LH +
43	R	AUDIO BUS RH +
44	-	-
45	W	HP LH -
46	B	HP LH -
47	-	-
48	SB	CD-DVD-EJECT
49	SHIELD	AUX SHIELD
50	B	AUX AUDIO LH +
51	R	AUX GND
52	-	-
53	-	-

Terminal No.	Color of Wire	Signal Name
54	-	-
55	-	-
56	-	-
57	-	-
58	B	AUDIO BUS LH -
59	G	AUDIO BUS RH -
60	-	-
61	G	HP LH +
62	R	HP RH +
63	-	-
64	-	-
65	GR	SW GND
66	W	AUX AUDIO RH +
67	-	-


ABNIA3314GB

BOSE AUDIO SYSTEM

[BOSE AUDIO WITH NAVIGATION]


< WIRING DIAGRAM >

Connector No.	M30
Connector Name	COMBINATION SWITCH
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
24	Y	STRG SW A (UP)
31	L	GND
32	G	STRG SW B (DOWN)

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	LG	SPEED OUT 8

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5M	SHIELD	-
8M	B	-
9M	W	-
65M	G/Y	-
71M	GR	-
72M	O	-

Terminal No.	Color of Wire	Signal Name
54G	SB	-
77G	Y	-

ABNIA2638GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

BOSE AUDIO SYSTEM

< WIRING DIAGRAM >


[BOSE AUDIO WITH NAVIGATION]

Connector No.	M39
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	SB	AMP ON
2	BR	FR LH PRE+
3	B	FR LH PRE-
4	BR/W	RR LH PRE+
5	BR/Y	RR LH PRE-
6	Y	STRG SW A
7	G/Y	ACC
8	-	-
9	V	ILL+
10	-	-
11	G/Y	FR_RH_PRE+
12	G/O	FR_RH_PRE-
13	G/R	RR_RH_PRE+
14	B	RR_RH_PRE-
15	L	STRG_SW_GND
16	G	STRG_SW_B
17	-	-
18	-	-
19	Y	+B
20	B	GND

Connector No.	M37
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	L	R
22	G	G
23	Y	B
24	-	-
25	R	RGB SYNC
26	-	-
27	G	YS
28	B	HP
29	W	VP
30	V	IT DISP
31	LG	DISP IT
32	-	-


ABNIA2639GB

BOSE AUDIO SYSTEM

< WIRING DIAGRAM >

[BOSE AUDIO WITH NAVIGATION]


Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1J	R	-
2J	L	-
3J	GR	-(WITH BOSE AUDIO SYSTEM)
6J	W	-
7J	LG	-
8J	O	-(WITH BOSE AUDIO SYSTEM)
9J	Y	-
32J	B	-
33J	G	-
36J	B	-

Terminal No.	Color of Wire	Signal Name
38J	G/Y	-
39J	BR/Y	-
41J	BR	-
42J	W	-
43J	R	-
45J	SB	-
46J	G/R	-
47J	G/O	-
49J	BRW	-
50J	B	-
79J	R/B	-(WITHOUT BASE AUDIO SYSTEM)

Connector No.	M48
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
68	B	GND
69	R/B	+B
70	B	GND
71	R/B	+B
72	G/Y	ACC
73	G	MIC VCC (PWR)
74	SHIELD	MIC GND (IN -)
75	R	MIC SIG (IN +)

Terminal No.	Color of Wire	Signal Name
77	-	-
78	-	-
79	-	-
80	-	-
81	-	-
82	W/G	IGN
83	G	PKB SIG
84	W	REVERSE SIG
85	LG	SPEED 8P
86	-	-
87	B	RV CAM SIG
88	-	-
89	B	RESERVE 2
90	B	RESERVE 3
91	-	-
92	-	-

Terminal No.	Color of Wire	Signal Name
93	-	-
94	-	-
95	L	M-CAN2-H
96	P	M-CAN2-L
97	L	M-CAN1-H
98	P	M-CAN1-L
99	L	CAN-H
100	P	CAN-L
101	-	-
102	-	-
103	-	-
104	-	-
105	-	-
106	-	-
107	-	-

ABNIA2640GB

A B C D E F G H I J K L M N O P

AV

BOSE AUDIO SYSTEM

< WIRING DIAGRAM >

[BOSE AUDIO WITH NAVIGATION]


Connector No.	M64
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	2	Color of Wire	Y	Signal Name	-
--------------	---	---------------	---	-------------	---

Terminal No.	Color of Wire	Signal Name
10	W	-
11	B	-
12	L	-
13	P	-
16	G/B	-

Connector No.	M56
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	1	Color of Wire	G	Signal Name	-
4	4	G	-	-	-
6	6	R	-	-	-
9	9	R	-	-	-

Connector No.	M73
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	1	Color of Wire	-	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	M72
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITH NAVI)
Connector Color	GRAY



Terminal No.	109	Color of Wire	-	Signal Name	GPS ANT
110	110	SHIELD	-	GPS ANT	GPS ANT

Connector No.	M71
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITH NAVI)
Connector Color	VIOLET



Terminal No.	108	Color of Wire	-	Signal Name	SAT ANT
--------------	-----	---------------	---	-------------	---------


ABNIA2641GB

BOSE AUDIO SYSTEM

[BOSE AUDIO WITH NAVIGATION]

< WIRING DIAGRAM >

Connector No.	M80
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITH NAVI)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
33	-	-
34	-	ANT MAIN
35	-	ANT +B

Connector No.	M78
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

Connector No.	M75
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	R	-
11	W	-(WITH BOSE AUDIO SYSTEM)

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-

Connector No.	M85
Connector Name	AUX IN JACK
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	AUX AUDIO RH+
2	R	AUX GND
4	B	AUX AUDIO LH+

ABNIA3315GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

BOSE AUDIO SYSTEM

< WIRING DIAGRAM >


[BOSE AUDIO WITH NAVIGATION]

Connector No.	M92
Connector Name	DISPLAY UNIT (WITH NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	Y	+B
3	V	ACC
4	R	COMP1 IN-
5	-	-

Connector No.	M98
Connector Name	A/C AND AV SWITCH ASSEMBLY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	G/Y	ACC
3	LG	ILL
4	BR	ILL CONT GND
5	L	M CANT-L
6	P	M CANT-H
7	GR	SW GND
8	SB	CD DVD EJECT

Terminal No.	Color of Wire	Signal Name
6	G	G
7	-	-
8	B	HP
9	G	YS
10	-	-
11	V	IT DISP
12	B	COMP2 IN+
13	B	GND
14	W	COMP2 IN-

Terminal No.	Color of Wire	Signal Name
15	G	COMP1 IN+
16	-	-
17	L	R
18	Y	B
19	R	RGB SYNC
20	W	VP
21	-	-
22	LG	DISP IT
23	-	-
24	SHIELD	COMP2 IN SHIELD

Terminal No.	Color of Wire	Signal Name
9	-	-
10	-	-
11	-	-
12	-	-
13	-	-
14	-	-
15	-	-
16	Y	RR DEFOG

Connector No.	M102
Connector Name	COMBINATION SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
16	L	-
17	BR	-
20	W	-

ABNIA2643GB

BOSE AUDIO SYSTEM

< WIRING DIAGRAM >

[BOSE AUDIO WITH NAVIGATION]

Connector No.	M111
Connector Name	FRONT TWEETER RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	W	-
2	L	-

Connector No.	M109
Connector Name	FRONT TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	G	-
2	L	-

Connector No.	M202
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	Y	-

Terminal No.	Color of Wire	Signal Name
10	W	-
11	B	-
12	L	-
13	P	-
16	G/B	-

Connector No.	M201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
4	G	-
6	R	-
9	R	-

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

ABNIA2644GB

BOSE AUDIO SYSTEM


< WIRING DIAGRAM >

[BOSE AUDIO WITH NAVIGATION]

Terminal No.	Color of Wire	Signal Name
24	G/B	ACC
25	-	-
26	P	GND
27	-	-
28	G	VIDEO OUT
29	-	-
30	-	-
31	-	-
32	LG	DATA TX1 (DVD->LCD)

Terminal No.	Color of Wire	Signal Name
7	L	M CAN2 H
8	-	-
9	BR	+B
10	GR	SW POWER +5
11	-	-
12	W/L	VTR+
13	O/L	VTR-
14	Y	GND
15	-	-
16	V	DATA RX1 (LCD->DVD)
17	R	FES R+ OUTPUT
18	G	FES R- OUTPUT
19	-	-
20	-	-
21	Y	+B
22	SB	ILL+
23	P	M CAN2 L

Connector No.	M205
Connector Name	DVD PLAYER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	FES L+ OUTPUT
2	W	FES L- OUTPUT
3	-	-
4	-	-
5	B	GND
6	BR	ILL-

Connector No.	M351
Connector Name	SATELLITE ANTENNA
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	-	-

Connector No.	M350
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	-	-

Connector No.	M210
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	GR	-
4	V	-
5	LG	-
6	BR	-
9	O/L	-
10	W/L	-
11	B	-
14	P	-


ABNIA2645GB

BOSE AUDIO SYSTEM

[BOSE AUDIO WITH NAVIGATION]

< WIRING DIAGRAM >

Connector No.	M601
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

Connector No.	M502
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

Connector No.	M501
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
2	-	-
3	-	-

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-

Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	LG	-

Connector No.	M602
Connector Name	ANTENNA AMP.
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	-	-
2	-	-
3	-	-

ABNIA2646GB



A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

BOSE AUDIO SYSTEM

< WIRING DIAGRAM >



[BOSE AUDIO WITH NAVIGATION]

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
16	W/G	REVERSE_LAMP

Connector No.	E53
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	G	-

Connector No.	E45
Connector Name	BACK-UP LAMP RELAY
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	W/G	-
3	SB	-
5	W/G	-

Connector No.	F14
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	LG	-

Connector No.	F9
Connector Name	A/T ASSEMBLY
Connector Color	GREEN

Terminal No.	Color of Wire	Signal Name
7	LG	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
54G	SB	-
77G	Y	-

ABNIA2647GB

BOSE AUDIO SYSTEM


[BOSE AUDIO WITH NAVIGATION]

< WIRING DIAGRAM >

Connector No.	F502
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	GRAY




Connector No.	B6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	7	Color of Wire	O	Signal Name	REV LAMP RLY
--------------	---	---------------	---	-------------	--------------

Terminal No.	5	Color of Wire	B	Signal Name	-(WITH BOSE AUDIO SYSTEM)
Terminal No.	12	Color of Wire	G	Signal Name	-(WITH BOSE AUDIO SYSTEM)

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	1J	Color of Wire	R	Signal Name	-
Terminal No.	2J	Color of Wire	L	Signal Name	-
Terminal No.	3J	Color of Wire	GR	Signal Name	-(WITH BOSE AUDIO SYSTEM)
Terminal No.	6J	Color of Wire	W	Signal Name	-
Terminal No.	7J	Color of Wire	LG	Signal Name	-
Terminal No.	8J	Color of Wire	O	Signal Name	-(WITH BOSE AUDIO SYSTEM)
Terminal No.	9J	Color of Wire	Y	Signal Name	-
Terminal No.	32J	Color of Wire	B	Signal Name	-
Terminal No.	33J	Color of Wire	G	Signal Name	-
Terminal No.	36J	Color of Wire	B	Signal Name	-

Terminal No.	38J	Color of Wire	G/Y	Signal Name	-
Terminal No.	39J	Color of Wire	BR/Y	Signal Name	-
Terminal No.	41J	Color of Wire	BR	Signal Name	-
Terminal No.	42J	Color of Wire	W	Signal Name	-
Terminal No.	43J	Color of Wire	R	Signal Name	-
Terminal No.	45J	Color of Wire	SB	Signal Name	-
Terminal No.	46J	Color of Wire	G/R	Signal Name	-
Terminal No.	47J	Color of Wire	G/O	Signal Name	-
Terminal No.	49J	Color of Wire	BR/W	Signal Name	-
Terminal No.	50J	Color of Wire	B	Signal Name	-
Terminal No.	79J	Color of Wire	R/B	Signal Name	-(WITHOUT BASE AUDIO SYSTEM)

ABNIA2648GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

BOSE AUDIO SYSTEM

< WIRING DIAGRAM >

[BOSE AUDIO WITH NAVIGATION]

Connector No.	B75
Connector Name	BOSE SPEAKER AMP.
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
5	-	-
6	-	-
7	-	-
8	-	-
9	B	RR DR LH+ OUT
10	G	RR DR LH- OUT
11	GR	RR DR RH+ OUT
12	O	RR DR RH- OUT
13	LG	FR DR LH+ OUT
14	L	FR DR LH- OUT
15	W	FR DR RH+ OUT
16	R	FR DR RH- OUT
21	-	-
22	Y	WOOFER CTRL
23	B	RR RH- IN
24	G/R	RR RH+ IN
25	BR/Y	RR LH- IN
26	BR/W	RR LH+ IN
27	G/O	FR RH- IN
28	G/Y	FR RH+ IN
29	B	FR LH- IN
30	BR	FR LH+ IN
31	SB	AMP ON
32	-	-

Connector No.	B74
Connector Name	BOSE SPEAKER AMP.
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	Y	BATT
2	-	-
3	B	WOOFER- OUT
4	-	-
17	B	GND
18	-	-
19	SB	WOOFER+ OUT
20	-	-

Connector No.	B72
Connector Name	SUBWOOFER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	WOOFER-
2	SB	WOOFER+
4	Y	AMP ON
5	B	GND
6	R/B	BATT


ABNIA2649GB

BOSE AUDIO SYSTEM

[BOSE AUDIO WITH NAVIGATION]

< WIRING DIAGRAM >


Connector No.	B77
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	GR	-
4	V	-
5	LG	-
6	BR	-
9	O/L	-
10	W/L	-
11	B	-
14	P	-


Terminal No.	Color of Wire	Signal Name
8	W/L	VIDEO IN+
9	-	-
10	-	-
11	-	-
12	Y	GND
13	LG	DATA RX (DVD->LCD)
14	V	DATA TX (LCD->DVD)
15	P	GND
16	BR	FILTERED BATT

Connector No.	B76
Connector Name	VIDEO MONITOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	FES L CH INPUT-
2	G	FES L CH INPUT+
3	B	FES R CH INPUT-
4	R	FES R CH INPUT+
5	GR	SW POWER +5
6	-	-
7	O/L	VIDEO IN-

Connector No.	B107
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-
5	G/Y	-
6	SHIELD	-

Connector No.	B106
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

ABNIA2650GB


A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

BOSE AUDIO SYSTEM

< WIRING DIAGRAM >

[BOSE AUDIO WITH NAVIGATION]


Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	-
6	R	-
7	SHIELD	-

Terminal No.	Color of Wire	Signal Name
5M	SHIELD	-
8M	B	-
9M	W	-
65M	G/Y	-
71M	GR	-
72M	O	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	D12
Connector Name	FRONT DOOR SPEAKER LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L/W	-
2	L/R	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
2	L/R	-
3	L/W	-

Connector No.	R8
Connector Name	MICROPHONE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	MIC OUT +
2	SHIELD	MIC OUT -
4	G	MIC POWER


ABNIA2651GB

BOSE AUDIO SYSTEM

[BOSE AUDIO WITH NAVIGATION]

< WIRING DIAGRAM >

Connector No.	D201
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

Connector No.	D112
Connector Name	FRONT DOOR SPEAKER RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W/B	-
2	L/B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	L/B	-
11	W/B	-

Connector No.	D301
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	GR	-
12	O	-

Connector No.	D208
Connector Name	REAR TWEETER LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	O	-

Connector No.	D207
Connector Name	REAR DOOR SPEAKER LH (WITH BOSE AUDIO SYSTEM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	O	-

ABNIA3325GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


AV

BOSE AUDIO SYSTEM

< WIRING DIAGRAM >

[BOSE AUDIO WITH NAVIGATION]

Connector No.	D450
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-
5	G/Y	-
6	SHIELD	-

Connector No.	D308
Connector Name	REAR TWEETER RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	O	-

Connector No.	D307
Connector Name	REAR DOOR SPEAKER RH (WITH BOSE AUDIO SYSTEM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	O	-

Connector No.	D551
Connector Name	REAR VIEW CAMERA
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	GND
2	G/Y	ACC
3	SHIELD	DRAIN
5	W	CAMERA -
6	B	CAMERA +

Connector No.	D550
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
3	G/Y	-
6	W	-
7	B	-
8	SHIELD	-

Connector No.	D451
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
3	G/Y	-
6	W	-
7	B	-
8	SHIELD	-

ABNIA3326GB

MULTI AV SYSTEM

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

SYMPTOM DIAGNOSIS

MULTI AV SYSTEM

Symptom Table

INFOID:000000007347934

AUDIO SYSTEM

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> AV control unit power supply and ground circuit AV control unit 	<ul style="list-style-type: none"> AV-334 AV-295
Steering switch does not operate	<ul style="list-style-type: none"> Steering switch AV control unit 	<ul style="list-style-type: none"> AV-366 AV-295
All speakers do not sound	<ul style="list-style-type: none"> Speaker circuit shorted to ground AV control unit BOSE speaker amp. ON signal BOSE speaker amp. power supply and ground circuit BOSE speaker amp. 	<ul style="list-style-type: none"> AV-385 AV-295 AV-365 AV-337 AV-427
One or several speakers do not sound	<ul style="list-style-type: none"> Front door speaker Front tweeter Rear tweeter Rear door speaker Subwoofer 	<ul style="list-style-type: none"> AV-350 AV-353 AV-359 AV-356 AV-362
Buzz/rattle sound from speaker	The majority of buzz/rattle sounds are not indicative of an issue with the speaker, usually something nearby the speaker is causing the buzz/rattle.	Refer to "SQUEAK AND RATTLE TROUBLE DIAGNOSIS" in the appropriate interior trim section.

NAVIGATION SYSTEM

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> AV control unit power supply and ground circuit AV control unit 	<ul style="list-style-type: none"> AV-334 AV-295
Steering switch does not operate	<ul style="list-style-type: none"> Steering switch AV control unit 	<ul style="list-style-type: none"> AV-366 AV-295
Voice activated control does not operate	<ul style="list-style-type: none"> Microphone Steering switch AV control unit 	<ul style="list-style-type: none"> AV-368 AV-366 AV-295

HANDS-FREE PHONE SYSTEM

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> AV control unit power supply and ground circuit AV control unit 	<ul style="list-style-type: none"> AV-334 AV-295
Steering switch does not operate	<ul style="list-style-type: none"> Steering switch AV control unit 	<ul style="list-style-type: none"> AV-366 AV-295
Voice activated control does not operate	<ul style="list-style-type: none"> Microphone Steering switch AV control unit 	<ul style="list-style-type: none"> AV-368 AV-366 AV-295

REAR VIEW MONITOR

Symptom	Possible cause	Reference page
Inoperative	<ul style="list-style-type: none"> Rear view camera power supply and ground circuit Rear view camera image signal circuit Rear view camera 	<ul style="list-style-type: none"> AV-338 AV-370 AV-438

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

MULTI AV SYSTEM

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

DVD PLAYER

Symptom	Possible cause	Reference page
DVD player inoperative	<ul style="list-style-type: none">• DVD player power supply and ground circuit• DVD player	<ul style="list-style-type: none">• AV-339• AV-429
No sound when playing a DVD	<ul style="list-style-type: none">• Audio signal circuits• AV control unit• DVD player	<ul style="list-style-type: none">• AV-383• AV-295• AV-429
Video monitor is inoperative/does not display properly	<ul style="list-style-type: none">• Video monitor power supply and ground circuits• Video out circuit• DVD player• Video monitor	<ul style="list-style-type: none">• AV-340• AV-383• AV-429• AV-429
DVD remote control is inoperative/does not operate properly	<ul style="list-style-type: none">• DVD remote control• DVD player	<ul style="list-style-type: none">• AV-429
Headphones inoperative	<ul style="list-style-type: none">• Headphone batteries• DVD player	<ul style="list-style-type: none">• AV-429

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

NORMAL OPERATING CONDITION

Description

INFOID:000000007347935

AUDIO SYSTEM

The majority of the audio troubles are the result of outside causes (bad CD, electromagnetic interference, etc.).

Noise

The following noise results from variations in field strength, such as fading noise and multi-path noise, or external noise from trains and other sources. It is not a malfunction.

- Fading noise: This noise occurs because of variations in the field strength in a narrow range due to mountains or buildings blocking the signal.
- Multi-path noise: This noise results from the waves sent directly from the broadcast station arriving at the antenna at a different time from the waves which reflect off mountains or buildings.

The vehicle itself can be a source of noise if noise prevention parts or electrical equipment is malfunctioning. Check if noise is caused and/or changed by engine speed, ignition switch turned to each position, and operation of each piece of electrical equipment, and determine the cause.

NOTE:

The source of the noise can be found easily by listening to the noise while removing the fuses of electrical components, one by one.

Type of Noise and Possible Cause

Occurrence condition		Possible cause
Occurs only when engine is ON.	A continuous growling noise occurs. The speed of the noise varies with changes in the engine speed.	<ul style="list-style-type: none"> • Ignition components
The occurrence of the noise is linked with the operation of the fuel pump.		<ul style="list-style-type: none"> • Fuel pump condenser
Noise only occurs when various electrical components are operating.	A cracking or snapping sound occurs with the operation of various switches.	<ul style="list-style-type: none"> • Relay malfunction, audio unit malfunction
	The noise occurs when various motors are operating.	<ul style="list-style-type: none"> • Motor case ground • Motor
The noise occurs constantly, not just under certain conditions.		<ul style="list-style-type: none"> • Rear defogger coil malfunction • Open circuit in printed heater • Poor ground of antenna feeder line
A cracking or snapping sound occurs while the vehicle is being driven, especially when it is vibrating excessively.		<ul style="list-style-type: none"> • Ground wire of body parts • Ground due to improper part installation • Wiring connections or a short circuit

NAVIGATION SYSTEM

Basic Operation

Symptom	Cause	Remedy
No image is shown.	Display brightness adjustment is set fully to DARK side.	Adjust the display brightness.
No guide sound is heard. Audio guide volume is too low or too high.	Volume control is set to OFF, MIN or MAX.	Adjust the audio guide volume.
	Audio guidance is not available while the vehicle is driving on a dark pink route.	System is not malfunctioning.
Screen is too dark. Motion of the image is too slow.	Temperature inside the vehicle is low.	Wait until the temperature inside the vehicle reaches the proper temperature.
Small black or bright spots appear on the screen.	Symptom peculiar to a liquid crystal display (display unit).	System is not malfunctioning.

Vehicle Mark

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Symptom	Cause	Remedy
Map screen and BIRDVIEW™ Name of the place vary with the screen.	Some thinning of the character data is done to prevent the display becoming to complex. In some cases and in some locations, the display contents may differ. The same place name, street name, etc. may not be displayed every time on account of the data processing.	System is not malfunctioning.
Vehicle mark is not positioned correctly.	Vehicle is transferred by ferry or by towing after its ignition switch is turned to OFF.	Drive the vehicle for a while in the GPS satellite signal receiving condition.
Screen will not switch to nighttime mode after the lighting switch is turned ON.	The daytime screen is selected by the "SWITCH SCREENS" when the last time the screen dimming setting is done. Switching between daytime/nighttime screen may be inhibited by the automatic illumination adjustment function.	Perform screen dimming and select the nighttime screen by "SWITCH SCREENS".
Map screen will not scroll in accordance with the vehicle travel.	Current location is not displayed.	Press "MAP" button to display the current location.
Vehicle mark will not be shown.	Current location is not displayed.	Press "MAP" button to display the current location.
Accuracy indicator (GPS satellite mark) on the map screen stays gray.	GPS satellite signal is intercepted because the vehicle is in or behind a building.	Move the vehicle out to an open space.
	GPS satellite signal cannot be received because an obstacle is placed on top of the instrument panel.	Do not place anything on top of the meter display (instrument panel).
	GPS satellites are not visible from current location.	Wait until GPS satellites are visible by moving the vehicle.
Vehicle location accuracy is low.	Accuracy indicator (GPS satellite mark) on the map screen stays gray.	Current location is not determined.
	Vehicle speed setting by the vehicle speed pulse has been deviated (advanced or retarded) from the actual vehicle speed because tire chain is fitted or the system has been used on another vehicle.	Drive the vehicle for a while [for approx. 30 minutes at approx. 30 km/h (19 MPH)] and the deviation will be automatically adjusted. If advancement or retard still occur, perform the distance adjustment by CONFIRMATION/ADJUSTMENT mode of diagnosis function.
	Map data has error or omission. (Vehicle mark is always deviated to the same position.)	As a rule, an updated map DVD-ROM will be released once a year.

Destination, Passing Points and Menu Items Cannot be Selected/Set

Symptom	Cause	Remedy
Destination cannot be set.	Destination to be set is on an expressway.	Set the destination on an ordinary road.
Passing point is not searched when re-searching the route.	The vehicle has already passed the passing point, or the system judged so.	To include the passing points that have been passed into the route again, set the route again.
Route information will not be displayed.	Route searching has not been done.	Set the destination and perform route searching.
	Vehicle mark is not on the recommended route.	Drive on the recommended route.
	Route guide is turned OFF.	Turn route guide ON.
	Route information is not available on the dark pink route.	System is not malfunctioning.
After the route searching, no guide sign will appear as the vehicle goes near the entrance/exit to the toll road.	Vehicle mark is not on the recommended route. (On the display, only guide signs related to the recommended route will be shown.)	Drive on the recommended route.

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Symptom	Cause	Remedy
Automatic route searching is not possible.	Vehicle is driving on a highway (gray route), or no recommended route is available.	Drive on a road to be searched. Or re-search the route manually. In this case, however, the whole route will be searched.
Performed automatic detour search (or detour search). However, the result is the same as that of the previous search.	Performed search with every conditions considered. However, the result is the same as that of the previous search.	System is not malfunctioning.
Passing points cannot be set.	More than five passing points were set.	Passing points can be set up to five. To stop at more than five points, perform sharing in several steps.
When setting the route, the starting point cannot be selected.	The current vehicle location is always set as the starting point of a route.	System is not malfunctioning.
Some menu items cannot be selected.	The vehicle is being driven.	Stop the vehicle at a safe place and then operate the system.

Voice Guide

Symptom	Cause	Remedy
Voice guide will not operate.	Note: Voice guide is only available at intersections that satisfy certain conditions (indicated by ● on the map). Therefore, guidance may not be given even when the route on the map changes direction.	System is not malfunctioning.
	The vehicle is not on the recommended route.	Return to the recommended route or re-search the route.
	Voice guide is turned OFF.	Turn voice guide ON.
	Route guide is turned OFF.	Turn route guide ON.
Voice guide does not match the actual road pattern.	Voice guide may vary with the direction to which the vehicle is turn and the connection of the road to other roads.	Drive in conformity to the actual traffic rules.

Route Search

Symptom	Cause	Remedy
No route is shown.	No road to be searched is found around the destination.	Find wider road (orange road or wider) nearby and reset the destination and passing points onto it. Take care of the traveling direction when there are separate up and down roads.
	Starting point and the destination are too close.	Set the destination at more distant point.
	Conditional traffic regulation (day of the week/ time of the day) is set at the area around the current location or the destination.	Turn the time-regulating search conditions OFF. Turn "Avoid regulation time" in the search conditions OFF.
Indicated route is intermittent.	In some areas, highways (gray routes) are not used for the search ^(Note) Therefore, the route to the current location or the passing points may be intermittent.	System is not malfunctioning.
When the vehicle has passed the recommended route, it is deleted from the screen.	A recommended route is controlled by each section. When the vehicle has passed the passing point 1, then the map data from the starting point up to the passing point 1 will be deleted. (The data may remain undeleted in some area.)	System is not malfunctioning.

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]


Symptom	Cause	Remedy
Detouring route is recommended.	In some areas, highways (gray routes) are not used for the search. (Note). Therefore, detour route may be recommended.	Set the route closer to the basic route (gray route).
	A detour route may be shown when some traffic regulation (one-way traffic, etc.) is set at the area around the starting point or the destination.	Slightly move the starting point or the destination, or set the passing point on the route of your choice.
	In the area where highways (gray routes) are used for the search, left turn has priority around the current location and the destination (passing points). For this reason, the recommended route may be detouring.	System is not malfunctioning.
Landmarks on the map do not match the actual ones.	This can be happen due to omission or error in the map data.	As a rule, an updated map DVD-ROM will be released once a year. Wait until the latest map has become available.
Recommended route is far from the starting point, passing points, and destination.	Starting point, passing points, and destination of the route guide were set far from the desired points because route searching data around these area were not stored.	Reset the destination onto the road nearby. If this road is one of the highways (gray routes), an ordinary road nearby may be displayed as the recommended route.

NOTE:

Except for the ordinance-designated cities. (Malfunctioning areas may be changed in the updated map disc.)

Examples of Current-Location Mark Displacement







Vehicle's travel amount is calculated by reading its travel distance and turning angle. Therefore, if the vehicle is driven in the following manner, an error will occur in the vehicle's current location display. If correct location has not been restored after driving the vehicle for a while, perform location correction.



NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]





Cause (condition) –: While driving ooo: Display	Driving condition	Remarks (correction, etc.)
Y-intersections  <small>ELK0192D</small>	At a Y intersection or similar gradual division of roads, an error in the direction of travel deduced by the sensor may result in the current-location mark appearing on the wrong road.	If after travelling about 10 km (6 miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.
Spiral roads  <small>ELK0193D</small>	When driving on a large, continuous spiral road (such as loop bridge), turning angle error is accumulated and the vehicle mark may deviate from the correct location.	
Straight roads  <small>ELK0194D</small>	When driving on a long, straight road and slow curve without stopping, map-matching does not work effectively enough and distance errors may accumulate. As a result, the vehicle mark may deviate from the correct location when the vehicle is turned at a corner.	
Zigzag roads  <small>ELK0195D</small>	When driving on a zigzag road, the map may be matched to other roads in the similar direction nearby at every turn, and the vehicle mark may deviate from the correct location.	
Roads laid out in a grid pattern  <small>ELK0196D</small>	When driving where roads are laid out in a grid pattern, or where many roads are running in the similar direction nearby, the map may be matched to them by mistake and the vehicle mark may deviate from the correct location.	
Parallel roads  <small>ELK0197D</small>	When two roads are running in parallel (such as highway and sideway), the map may be matched to the other road by mistake and the vehicle mark may deviate from the correct location.	

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >



[BOSE AUDIO WITH NAVIGATION]

	Cause (condition) -: While driving ooo: Display	Driving condition	Remarks (correction, etc.)
Place	In a parking lot  <small>SEL709V</small>	When driving in a parking lot, or other location where there are no roads on the map, matching may place the vehicle mark on a nearby road. When the vehicle returns to the road, the vehicle mark may have deviated from the correct location. When driving in circle or turning the steering wheel repeatedly, direction errors accumulate, and the vehicle mark may deviate from the correct location.	If after travelling about 10 km (6 miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.
	Turntable  <small>SEL710V</small>	When the ignition switch is OFF, the navigation system cannot get the signal from the gyroscope (angular speed sensor). Therefore, the displayed direction may be wrong and the correct road may not be easily returned to after rotating the vehicle on a turntable with the ignition OFF.	
	Slippery roads	On snow, wet roads, gravel, or other roads where tires may slip easily, accumulated mileage errors may cause the vehicle mark to deviate from the correct road.	
	Slopes	When parking in sloped garages, when travelling on banked roads, or in other cases where the vehicle turns when tilted, an error in the turning angle will occur, and the vehicle mark may deviate from the road.	
Map data	Road not displayed on the map screen  <small>SEL699V</small>	When driving on new roads or other roads not displayed on the map screen, map matching does not function correctly and matches the location to a nearby road. When the vehicle returns to a road which is on the map, the vehicle mark may deviate from the correct road.	
	Different road pattern (Changed due to repair)  <small>ELK0201D</small>	If the road pattern stored in the map data and the actual road pattern are different, map matching does not function correctly and matches the location to a nearby road. The vehicle mark may deviate from the correct road.	
Vehicle	Use of tire chains	When tire chains are used, the mileage is not correctly detected, and the vehicle mark may deviate from the correct road.	Drive the vehicle for a while. If the distance still deviates, adjust it by using the distance adjustment function. (If the tire chain is removed, recover the original value.)

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

Cause (condition) –: While driving ooo: Display	Driving condition	Remarks (correction, etc.)
Precautions for driving	Just after the engine is started	If the vehicle is driven just after the engine is started when the gyroscope (angular speed sensor) correction is not completed, the vehicle can lose its direction and may have deviated from the correct location. Wait for a short while before driving after starting the engine.
	Continuous driving without stopping	When driving long distances without stopping, direction errors may accumulate, and the current-location mark may deviate from the correct road. Stop and adjust the orientation.
	Abusive driving	Spinning the wheels or engaging in other kinds of abusive driving may result in the system being unable perform correct detection, and may cause the vehicle mark to deviate from the correct road. If after travelling about 10 km (6 miles) the correct location has not been restored, perform location correction and, if necessary, direction correction.
How to correct location	Position correction accuracy 	If the accuracy of location settings is poor, accuracy may be reduced when the correct road cannot be found, particularly in places where there are many roads. Enter in the road displayed on the screen with an accuracy of approx. 1mm. Caution: Whenever possible, use detailed map for the correction.
	Direction when location is corrected 	If the accuracy of location settings during correction is poor, accuracy may be reduced afterwards. Perform direction correction.

Location Correction by Map-Matching is Slow

- The map-matching function needs to refer to the data of the surrounding area. It is necessary to drive some distance for the function to work.
- Because map-matching operates on this principle, when there are many roads running in similar directions in the surrounding area, no matching determination may be made. The location may not be corrected until some special feature is found.

Name of Road is Not Displayed

The current road name may not be displayed if there are no road names displayed on the map screen.

Contents of Display Differ for Birdview™ and the (Flat) Map Screen

Difference of the BIRDVIEW™ screen from the flat map screen are as follows.

- The current place name displays names which are primarily in the direction of vehicle travel.
- The amount of time before the vehicle travel or turn angle is updated on the screen is longer than for the (flat) map display.
- The conditions for display of place names, roads, and other data are different for nearby areas and for more distant areas.
- Some thinning of the character data is done to prevent the display becoming too complex. In some cases and in some locations, the display contents may differ.
- The same place name, street name, etc. may be displayed multiple times.

Vehicle Mark Shows a Position Which is Completely Wrong

In the following cases, the vehicle mark may appear on completely different position in the map depending on the GPS satellite signal receiving conditions. In this case, perform location correction and direction correction.

- When location correction has not been done
- If the receiving conditions of the GPS satellite signal is poor, if the vehicle mark becomes out of place, it may move to a completely different location and not come back if location correction is not done. The position will be corrected if the GPS signal can be received.
- When the vehicle has traveled by ferry, or when the vehicle has been being towed

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BOSE AUDIO WITH NAVIGATION]

- Because calculation of the current location cannot be done when traveling with the ignition off, for example when traveling by ferry or when being towed, the location before travel is displayed. If the precise location can be detected with GPS, the location will be corrected.

Vehicle Mark Jumps

In the following cases, the vehicle mark may appear to jump as a result of automatic correction of the current location.

- When map matching has been done
 - If the current location and the vehicle mark are different when map matching is done, the vehicle mark may seem to jump. At this time, the location may be “corrected” to the wrong road or to a location which is not on a road.
- When GPS location correction has been done
 - If the current location and the vehicle mark are different when the location is corrected using GPS measurements, the vehicle mark may seem to jump. At this time, the location may be “corrected” to a location which is not on a road.

Vehicle Mark is in a River or Sea

The navigation system moves the vehicle mark with no distinction between land and rivers or sea. If the vehicle mark is somehow out of place, it may appear that the vehicle is driving in a river or the sea.

Vehicle Mark Automatically Rotates

The system wrongly memorizes the rotating status as stopping when the ignition switch is turned ON with the turntable rotating. That causes the vehicle mark to rotate when the vehicle is stopped.

When Driving on Same Road, Sometimes Vehicle Mark is in Right Place and Sometimes it is in Wrong Place

The conditions of the GPS antenna (GPS data) and gyroscope (angular speed sensor) change gradually. Depending on the road traveled and the operation of the steering wheel, the location detection results will be different. Therefore, even on a road on which the location has never been wrong, conditions may cause the vehicle mark to deviate.

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007347936

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:000000007347937

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

PRECAUTIONS

< PRECAUTION >

[BOSE AUDIO WITH NAVIGATION]

- When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
- Perform a self-diagnosis check of all control units using CONSULT.

Precaution for Trouble Diagnosis

INFOID:000000007347938

AV COMMUNICATION SYSTEM


- Do not apply voltage of 7.0 V or higher to the measurement terminals.
- Use the tester with its open terminal voltage being 7.0 V or less.
- Be sure to turn ignition switch OFF and disconnect the battery cable from the negative terminal before checking the circuit.

Precaution for Harness Repair


INFOID:000000007347939

AV COMMUNICATION SYSTEM

- Solder the repaired parts, and wrap with tape. [Frays of twisted line must be within 110 mm (4.33 in).]



- Do not perform bypass wire connections for the repair parts. (The spliced wire will become separated and the characteristics of twisted line will be lost.)



Precaution for Work

INFOID:000000007347940

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components.
 - Water soluble dirt: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the dirty area. Then rub with a soft and dry cloth.
 - Oily dirt: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the dirty area. Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

[BOSE AUDIO WITH NAVIGATION]


PREPARATION

PREPARATION

Special Service Tool


INFOID:000000007347941

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim tool set  <p style="text-align: center;">AWJIA04832Z</p>	Removing trim components

Commercial Service Tools

INFOID:000000007347942

Tool name	Description
Power tool  <p style="text-align: center;">PIIB1407E</p>	Loosening nuts, screws and bolts

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P

AV

AV CONTROL UNIT

< REMOVAL AND INSTALLATION >


[BOSE AUDIO WITH NAVIGATION]

REMOVAL AND INSTALLATION

AV CONTROL UNIT

Removal and Installation

INFOID:000000007347943



- 1. Cluster lid C
- 4. AV control unit brackets
- 7. Volume knob switch
- 10. Enter button

- 2. Display unit
- 5. Tuner knob switch
- 8. Volume knob
- 11. Tuner knob

- 3. AV control unit
- 6. A/C and AV switch assembly
- 9. Temp knobs RH and LH

AV CONTROL UNIT

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]

CAUTION:

Only remove and replace the A/C or AV switch assembly knobs if damaged or missing. The knobs must not be removed from switches when removing and installing the A/C or AV switch assembly to prevent damage to the switch assembly.

REMOVAL

1. Disconnect the battery negative terminal.
2. Remove the cluster lid C. Refer to [JP-16, "Removal and Installation"](#).
3. Remove the AV control unit screws, using a power tool.
4. Remove the AV control unit.
5. Remove the A/C and AV switch assembly screws, then remove the A/C and AV switch assemblies as necessary.

INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

DISPLAY UNIT

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]


DISPLAY UNIT

Removal and Installation


INFOID:000000007347944

REMOVAL

1. Remove cluster lid C. Refer to [IP-16. "Removal and Installation"](#).
2. Remove the display unit screws (A).
3. Pull out the display unit (1), then disconnect the display unit connectors and remove the display unit (1).



4. Remove the A/C auto amp.screws (A), remove the (C103) fasteners (B) from the display unit assembly brackets and remove the A/C auto amp. (1).
5. Remove the display unit bracket unit screws (C) and remove the display unit brackets (2).



INSTALLATION

Installation is in reverse order of removal.

FRONT TWEETER

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]

FRONT TWEETER

Removal and Installation


INFOID:000000007347945

REMOVAL

CAUTION:

Use a suitable tool to prevent damage to the front tweeter speaker grille trim and the instrument panel.

1. Remove the front tweeter grille.
2. Remove the front tweeter screws (A).
3. Pull out the front tweeter speaker (1) and disconnect front tweeter connector, then remove the front tweeter speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

FRONT DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]


FRONT DOOR SPEAKER

Removal and Installation

INFOID:000000007347946

REMOVAL

1. Remove the front door finisher. Refer to [INT-15, "Removal and Installation"](#).
2. Remove the front door speaker screws (A).
3. Pull out the front door speaker (1), and disconnect the front door speaker connector and remove the front door speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

REAR DOOR SPEAKER

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]


REAR DOOR SPEAKER

Removal and Installation of Rear Door Speaker

INFOID:000000007347947

REMOVAL

1. Remove the rear door finisher. Refer to [INT-15. "Removal and Installation"](#).
2. Remove the rear door speaker screws (A).
3. Disconnect the rear door speaker connector (B) and remove rear door speaker (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

REAR DOOR TWEETER

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]


REAR DOOR TWEETER

Removal and Installation of Rear Tweeter

INFOID:000000007347948

REMOVAL

1. Remove rear door finisher. Refer to [INT-15. "Removal and Installation"](#).
2. Remove the rear tweeter screws (A) and remove the rear tweeter (1).



INSTALLATION

Installation is in the reverse order of removal.

BOSE SPEAKER AMP

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]

BOSE SPEAKER AMP

Removal and Installation


INFOID:000000007830128

REMOVAL

NOTE:

Do not remove the LH front seat from the vehicle.

1. Remove LH front seat bolts, disconnect the LH front seat electrical harness connector. Refer to [SE-33](#), "[Removal and Installation](#)".
2. Tilt the LH front seat back to access the BOSE speaker amp. (1), then remove the BOSE speaker amp. screws (B).
 - ↶: Vehicle front
3. Disconnect the Bose speaker amp. connectors (A) and remove Bose speaker amp. (1) from the bracket (2).
4. Then remove the BOSE speaker amp. bracket screws (C) and remove bracket (2).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

AV

SUBWOOFER

< REMOVAL AND INSTALLATION >


[BOSE AUDIO WITH NAVIGATION]

SUBWOOFER

Removal and Installation

INFOID:000000007347950

BOSE



1. Subwoofer
2. Subwoofer connector

Removal

1. Remove the luggage side lower finisher LH. Refer to [INT-25. "Removal and Installation"](#).
2. Remove subwoofer bolts and nuts.
3. Disconnect the subwoofer connector and remove the subwoofer.

Installation

Installation is in the reverse order of removal.

DVD ENTERTAINMENT SYSTEM

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]


DVD ENTERTAINMENT SYSTEM

Removal and Installation of DVD Player

INFOID:000000007347951

REMOVAL

1. Remove the center console assembly. Refer to [IP-22. "Removal and Installation"](#).
2. Disconnect the DVD player connector (A).
3. Remove the DVD player screws (B), then remove the DVD player (1).
4. Remove the DVD player bracket screws, then remove DVD player brackets.



INSTALLATION


Installation is in reverse order of removal.

Removal and Installation of Video Monitor

INFOID:000000007347952

REMOVAL

1. Release the clips and remove the video monitor finisher from headlining.
2. Press the release tabs and remove the cover.
3. Remove the video monitor screws.
4. Gently lower the assembly and disconnect the connector, then remove the video monitor from the headlining.



INSTALLATION

Installation is in reverse order of removal.

AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]

AUDIO ANTENNA

Location of Antenna

INFOID:000000007347953



AWNIA1796ZZ


- | | | |
|---------------------------------|--------------------------------|-----------------------------|
| 1. AV control unit M44, M71 | 2. Harness connector M78, M501 | 3. Satellite antenna feeder |
| 4. Harness connector M502, M601 | 5. Harness connector M73, M350 | 6. Satellite antenna M351 |
| 7. Antenna feeder | 8. Antenna amp. M602 | 9. Window antenna grid |

Window Antenna Repair

INFOID:000000007347954

ELEMENT CHECK

1. Attach probe circuit tester (ohm setting) to antenna terminal on each side.




AUDIO ANTENNA


< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]


- When measuring continuity, wrap tin foil around the top of probe. Then, press the foil against the wire with your finger.



2. If an element is broken, no continuity will exist.



3. To locate a break, move probe along element. Tester indication will change abruptly when probe passes the broken point.



ELEMENT REPAIR

Refer to [DEF-45, "Filament Repair"](#).

AUXILIARY INPUT JACK

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]

AUXILIARY INPUT JACK

Removal and Installation

INFOID:000000007347955

Removal

1. Remove the A/T finisher. Refer to [IP-21, "Removal and Installation"](#).
2. Remove the auxiliary input jack.

Installation

Installation is in the reverse order of removal.

ANTENNA AMP.

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]


ANTENNA AMP.

Removal and Installation

INFOID:000000007347956

REMOVAL

1. Remove the luggage side upper and lower RH finishers. Refer to [INT-25. "Removal and Installation"](#).
2. Detach the antenna amp. harness clip (D), disconnect the antenna amp. connector (A), harness connector (B), then remove the antenna amp. screw (C) and remove the antenna amp. (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
AV
O
P


GPS ANTENNA

Removal and Installation

INFOID:000000007347957

REMOVAL

1. Remove the cluster lid C. Refer to [IP-16. "Removal and Installation"](#).
2. Remove the GPS antenna screws (A), detach the GPS antenna harness clip (B).
3. Remove GPS antenna and feeder assembly (1) out of the instrument panel.



INSTALLATION

Installation is in the reverse order of removal.

SATELLITE RADIO ANTENNA

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]


SATELLITE RADIO ANTENNA

Removal and Installation

INFOID:000000007347958

REMOVAL

1. Remove the front roof console finisher. Refer to [INT-22. "Removal and Installation"](#).
2. Disconnect the satellite antenna connector.
3. Remove the satellite antenna nut.
4. Remove the satellite antenna.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

AV

STEERING SWITCH


< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]

STEERING SWITCH

Removal and Installation

INFOID:000000007347959



1. Steering wheel


2. Steering wheel audio control switches


REMOVAL

1. Remove the driver air bag module. Refer to [SR-5, "Removal and Installation"](#).
2. Remove the steering wheel audio control switch assembly screws.
3. Disconnect the steering wheel audio control switches connector.
4. Remove the steering wheel audio control switches by pulling on steering wheel audio control switches to release the pawls.

CAUTION:

Do not tilt steering wheel audio control switches during removal or damage may occur to the pawls.

-  Pawl



INSTALLATION

Installation is in the reverse order of removal.

MICROPHONE

< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]


MICROPHONE

Removal and Installation

INFOID:000000007347960

REMOVAL

1. Remove the front roof console finisher. Refer to [INT-22. "Removal and Installation"](#).
2. Detach the microphone (1) from the front console finisher tabs (A).
3. Disconnect the microphone connector (B) and remove the microphone (1).



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
L
M

AV

O
P

REAR VIEW CAMERA


< REMOVAL AND INSTALLATION >

[BOSE AUDIO WITH NAVIGATION]

REAR VIEW CAMERA

Removal and Installation

INFOID:000000007347961



1. Rear view camera A. Rear view camera connector B. Rear view camera harness clip

REMOVAL

1. Remove the license lamp finisher. Refer to [EXT-23, "Removal and Installation"](#).
2. Disconnect the rear view camera connector.
3. Detach the rear view camera harness clip.
4. Detach the rear view camera to release, then pull out to remove the rear view camera while feeding the rear view camera harness and connector through the back door.

INSTALLATION

Installation is in the reverse order of removal.