

EXL

SECTION EXTERIOR LIGHTING SYSTEM

A
B
C
D
E

F
G
H
I
J
K
L
M
N
O
P

EXL

CONTENTS

BASIC INSPECTION	4	Component Parts Location	19
DIAGNOSIS AND REPAIR WORKFLOW	4	Component Description	20
Work Flow	4		
SYSTEM DESCRIPTION	7		
HEADLAMP	7	COMBINATION SWITCH READING SYSTEM
System Diagram	7	21
System Description	7	System Diagram	21
Component Parts Location	7	System Description	21
Component Description	8	Component Parts Location	24
DAYTIME RUNNING LIGHT SYSTEM	9		
System Diagram	9	TRAILER TOW
System Description	9	25
Component Parts Location	10	System Diagram	25
Component Description	10	System Description	25
AUTO LIGHT SYSTEM	12	Component Parts Location	26
System Diagram	12	Component Description	26
System Description	12		
Component Parts Location	13	DIAGNOSIS SYSTEM (BCM)
Component Description	13	27
FRONT FOG LAMP	15	COMMON ITEM
System Diagram	15	COMMON ITEM : CONSULT Function (BCM -	
System Description	15	COMMON ITEM)	27
Component Parts Location	15		
Component Description	16	HEADLAMP
TURN SIGNAL AND HAZARD WARNING			HEADLAMP : CONSULT Function (BCM - HEAD	
LAMPS	17	LAMP)	28
System Diagram	17		
System Description	17	FLASHER
Component Parts Location	17	FLASHER : CONSULT Function (BCM - FLASH-	
Component Description	18	ER)	29
PARKING, LICENSE PLATE AND TAIL				
LAMPS	19	COMB SW
System Diagram	19	COMB SW : CONSULT Function (BCM - COMB	
System Description	19	SW)	29
			DIAGNOSIS SYSTEM (IPDM E/R)
			Diagnosis Description	31
			CONSULT Function (IPDM E/R)	33
			DTC/CIRCUIT DIAGNOSIS
			POWER SUPPLY AND GROUND CIRCUIT35
			BCM (BODY CONTROL MODULE)35

BCM (BODY CONTROL MODULE) : Diagnosis Procedure	35	DTC Index	76
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	36	WIRING DIAGRAM	77
IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure	36	HEADLAMP	77
Wiring Diagram	77		
DAYTIME LIGHT SYSTEM	81	Wiring Diagram	81
Wiring Diagram	81		
AUTO LIGHT SYSTEM	89	Wiring Diagram	89
Wiring Diagram	89		
FRONT FOG LAMP SYSTEM	97	Wiring Diagram	97
Wiring Diagram	97		
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM	101	Wiring Diagram	101
Wiring Diagram	101		
PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM	107	Wiring Diagram	107
Wiring Diagram	107		
STOP LAMP	114	Wiring Diagram	114
Wiring Diagram	114		
BACK-UP LAMP	119	Wiring Diagram	119
Wiring Diagram	119		
TRAILER TOW	123	Wiring Diagram	123
Wiring Diagram	123		
SYMPTOM DIAGNOSIS	132		
EXTERIOR LIGHTING SYSTEM SYMPTOMS.	132		
Symptom Table	132		
NORMAL OPERATING CONDITION	134		
Description	134		
BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM	135		
Description	135		
Diagnosis Procedure	135		
DAYTIME LIGHT SYSTEM INOPERATIVE	136		
Description	136		
Diagnosis Procedure	136		
BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON	137		
Description	137		
Diagnosis Procedure	137		
PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON	138		
Description	138		
Diagnosis Procedure	138		
BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON	139		
Description	139		

Diagnosis Procedure	139	Removal and Installation	147
PRECAUTION	140	FRONT FOG LAMP	148
PRECAUTIONS	140	Bulb Replacement	148
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	140	Removal and Installation	148
Precaution Necessary for Steering Wheel Rota- tion After Battery Disconnect	140	LIGHTING & TURN SIGNAL SWITCH	149
Precaution for Work	141	Removal and Installation	149
PERIODIC MAINTENANCE	142	HAZARD SWITCH	150
ADJUSTMENT AND INSPECTION	142	Removal and Installation	150
HEADLAMP	142	HIGH-MOUNTED STOP LAMP	151
HEADLAMP : Aiming Adjustment	142	High-Mounted Stop Lamp	151
FRONT FOG LAMP	143	LICENSE PLATE LAMP	152
FRONT FOG LAMP : Aiming Adjustment	143	Bulb Replacement	152
UNIT REMOVAL AND INSTALLATION ...	145	Removal and Installation	152
HEADLAMP	145	REAR COMBINATION LAMP	153
Bulb Replacement	145	Bulb Replacement	153
Removal and Installation	145	Removal and Installation	153
Disassembly and Assembly	146	SERVICE DATA AND SPECIFICATIONS (SDS)	154
OPTICAL SENSOR	147	BULB SPECIFICATIONS	154
		Headlamp	154
		Exterior Lamp	154

A

B

C

D

E

F

G

H

J

K

EXL

M

N

O

P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:0000000007355103

OVERALL SEQUENCE



AWLIA1837GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Find out what the customer's concerns are.

>> GO TO 2

2. SYMPTOM CHECK

Verify the symptom from the customer's information.

>> GO TO 3

3. BASIC INSPECTION

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4

4. SELF-DIAGNOSIS WITH CONSULT

Perform the self diagnosis with CONSULT. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5

NO >> GO TO 6

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9

6. FAIL-SAFE ACTIVATION CHECK

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7

NO >> GO TO 8

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis. Specify the malfunctioning part.

>> GO TO 9

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform the self diagnosis with CONSULT. Verify that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

YES >> GO TO 5

NO >> GO TO 11

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> Inspection End.

NO >> GO TO 3

HEADLAMP


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

HEADLAMP

System Diagram

INFOID:000000007355104



AWLIA1909GB

System Description

INFOID:000000007355105

Control of the headlamp system operation is dependent upon the position of the combination switch (lighting and turn signal switch). When the lighting switch is placed in the 2nd position, the BCM (body control module) receives input requesting the headlamps and park lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls the headlamp high and headlamp low relay coils. When energized, these relays direct power to the respective headlamps, which then illuminate.


HIGH BEAM OPERATION/FLASH-TO-PASS OPERATION

With the lighting switch in the 2ND position and placed in HIGH position, the BCM receives input requesting the headlamp high beams to illuminate. The flash to pass feature can be used any time and also sends a signal to the BCM. This input is communicated to the IPDM E/R via the CAN communication lines. The CPU of the combination meter controls the ON/OFF status off the HIGH BEAM indicator. The CPU of the IPDM E/R controls the headlamp high relay coil which supplies power to the high beam headlamps.

The combination meter receives a high beam request signal (ON) via the CAN communication lines and turns the high beam indicator lamp ON.

Component Parts Location

INFOID:000000007355106



WKIA4957E

HEADLAMP

< SYSTEM DESCRIPTION >

1. IPDM E/R E122, E123, E124
2. BCM M18, M20 (view with lower instrument panel LH removed)
3. Combination switch (lighting and turn signal switch) M28
4. Combination meter M24

Component Description

INFOID:000000007355107


Part name	Description
BCM	<ul style="list-style-type: none">• Receives lighting switch requests via BCM combination switch reading function.• Sends headlamp high/low request signal to the IPDM E/R.
IPDM E/R	Activates the headlamp high and headlamp low relays upon request from the BCM.
Combination switch (lighting and turn signal switch)	Outputs lighting requests to the BCM.

DAYTIME RUNNING LIGHT SYSTEM

< SYSTEM DESCRIPTION >

DAYTIME RUNNING LIGHT SYSTEM

System Diagram



System Description

INFOID:0000000007355109

The headlamp system for Canada vehicles is equipped with a daytime light control that activates the high beam headlights at approximately half illumination whenever the engine is operating. If the parking brake is depressed before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is depressed.

OPERATION

The BCM monitors inputs from the parking brake switch and the combination switch (lighting and turn signal switch) to determine when to activate the daytime light system. The BCM sends a daytime light request to the IPDM E/R via the CAN communication lines. The IPDM E/R grounds the daytime light relay 1 which in turn, provides power to the ground side of the LH high beam lamp. Power flows backward through the LH high beam lamp to the IPDM E/R, through the high beam fuses, through the RH high beam lamp circuit to the RH high beam lamp and on to ground. The high beam lamps are wired in series which causes them to illuminate at a reduced intensity.

A
B
C
D
E
F
G
H
I
J
K

EXL


M
N
O
P

DAYTIME RUNNING LIGHT SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000007355110



WKIA4958E

- | | | |
|--|---|---|
| 1. IPDM E/R E119, E122, E123, E124 | 2. Parking brake switch E53 | 3. BCM M18, M20 (view with lower instrument panel LH removed) |
| 4. ECM E16 (view with ECM cover removed) | 5. Generator E205, E209 | 6. Daytime light relay 1, E103 |
| 7. Daytime light relay 2, E104 | 8. Combination switch (lighting and turn signal switch) M28 | 9. Combination meter M24 |

Component Description

INFOID:000000007355111

Part name	Description
BCM	<ul style="list-style-type: none"> Receives combination switch (lighting and turn signal switch) inputs via BCM combination switch reading function. Receives parking brake depressed input from the parking brake switch. Receives engine running status from the ECM via CAN communication.
IPDM E/R	Receives daytime light request from the BCM and activates the daytime light relay.
Combination switch (lighting and turn signal switch)	Outputs lighting requests to the BCM.

DAYTIME RUNNING LIGHT SYSTEM

< SYSTEM DESCRIPTION >

Park brake switch	Outputs parking brake status to the combination meter which forwards that information to the BCM via CAN communication.
ECM	Outputs engine running status to the BCM.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P


AUTO LIGHT SYSTEM

< SYSTEM DESCRIPTION >

AUTO LIGHT SYSTEM

System Diagram

INFOID:0000000007355112



System Description

INFOID:0000000007355113

The auto light control system has an optical sensor that detects outside brightness.

When the lighting switch is in AUTO position, it automatically turns ON/OFF the parking, license plate, tail and headlamps in accordance with the ambient light. Sensitivity can be adjusted in four steps. For the details, Refer to [BCS-21, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)".](#)

AUTO LIGHT OPERATION

The auto light system operates the low beam and high beam headlamps, parking lamps, tail lamps and license plate lamps. The BCM monitors the combination switch (lighting and turn signal switch) position as a part of the BCM combination switch reading function. When the lighting switch is in the AUTO position, the BCM automatically turns the lamps ON/OFF according to ambient light brightness.

NOTE:


Timing for when lamps turn ON/OFF can be changed by the CONSULT. Refer to [BCS-21, "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)".](#)

AUTO LIGHT SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000007355114



WKIA4959E

EXL

1. IPDM E/R E122, E123, E124
2. BCM M18, M19, M20 (view with lower instrument panel LH removed)
3. Combination switch (lighting and turn signal switch) M28
4. Combination meter M24
5. Rear door switch
LH B18
RH B116
6. Optical sensor M145
7. Back door latch (door ajar switch)
D502
8. Front door switch
LH B8
RH B108

M

N

O

P

Component Description

INFOID:000000007355115

Part name	Description
BCM	BCM (Body Control Module) controls auto light operation according to signals from optical sensor, lighting switch, door switches, and ignition switch.
IPDM E/R	IPDM E/R (Intelligent Power Distribution Module Engine Room) operates parking, license plate, tail and headlamps according to CAN communication signals from BCM.
Combination switch (lighting switch)	The lighting switch outputs lighting requests to the BCM.

AUTO LIGHT SYSTEM

< SYSTEM DESCRIPTION >

Optical sensor	Optical sensor detects ambient brightness and converts light (lux) to voltage, then sends the optical sensor signal to BCM.
Door switches	Provides door OPEN input to BCM for auto light timer.


FRONT FOG LAMP

< SYSTEM DESCRIPTION >

FRONT FOG LAMP

System Diagram

INFOID:0000000007355116



AWLIA1719GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

System Description

INFOID:0000000007355117


The front fog lamps are activated with the combination switch (lighting and turn signal switch). The lighting switch signal to the BCM is monitored with the BCM combination switch reading function. When the fog lamps are turned ON with the lighting switch, the BCM sends a front fog lamp request signal via CAN communication lines to the IPDM E/R. The IPDM E/R grounds the front fog lamp relay coil to activate the front fog lamps.

FRONT FOG LAMP OPERATION

When the lighting switch is in front fog lamp ON position and also in 1ST or 2ND position or AUTO position (headlamp is ON), the BCM detects FR FOG ON and the HEAD LAMP1, 2 ON or the AUTO LIGHT ON. The BCM sends a front fog lamp request ON signal via the CAN communication lines to the IPDM E/R. The IPDM E/R then turns ON the front fog lamp relay sending power to the front fog lamps.

Component Parts Location

INFOID:0000000007355118



WKIA4960E

1. IPDM E/R E122, E123, E124
2. BCM M18, M20 (view with lower instrument panel LH removed)
3. Combination switch (lighting and turn signal switch) M28
4. Combination meter M24

FRONT FOG LAMP

< SYSTEM DESCRIPTION >

Component Description

INFOID:000000007355119


Part name	Description
BCM	<ul style="list-style-type: none">• Receives lighting switch requests via BCM combination switch reading function.• Sends headlamp high/low request signal to the IPDM E/R.
IPDM E/R	Activates the front fog lamp relay upon request from the BCM.
Combination switch (lighting and turn signal switch)	Outputs lighting requests to the BCM.

TURN SIGNAL AND HAZARD WARNING LAMPS

< SYSTEM DESCRIPTION >

TURN SIGNAL AND HAZARD WARNING LAMPS

System Diagram



System Description

INFOID:0000000007355121

TURN SIGNAL OPERATION

When the turn signal switch is in LH or RH position with the ignition switch in ON position, the BCM detects the TURN RH or TURN LH ON request. The BCM outputs the flasher signal to the respective turn signal lamp. The BCM also sends a turn indicator signal ON request via the CAN communication lines to the combination meter. The combination meter then activates the appropriate turn signal indicator and audible buzzer.

HAZARD LAMP OPERATION

When the hazard switch is in ON position, the BCM detects the hazard switch signal ON. The BCM outputs the flasher signal (right and left). The BCM sends a hazard indicator signal ON request via the CAN communication lines to the combination meter. The combination meter then activates the hazard indicator and audible buzzer.


REMOTE KEYLESS ENTRY OPERATION

The remote keyless entry receiver transmits a hazard request signal to the BCM, then BCM controls hazard lamps.

Refer to [SEC-19, "System Description"](#).

Component Parts Location

INFOID:0000000007355122



TURN SIGNAL AND HAZARD WARNING LAMPS

< SYSTEM DESCRIPTION >

1. BCM M18, M20 (view with lower instrument panel LH removed)
2. Combination switch (lighting and turn signal switch) M28
3. Combination meter M24
4. Hazard switch M55

Component Description

INFOID:000000007355123

Part name	Description
BCM	Controls turn signal and hazard flasher operation.
Combination switch (lighting and turn signal switch)	Lighting and turn signal switch requests are output to the BCM.
Hazard switch	Hazard flasher request signal is output to the BCM.
Combination meter	Outputs turn and hazard indicator as requested by the BCM.


PARKING, LICENSE PLATE AND TAIL LAMPS

< SYSTEM DESCRIPTION >

PARKING, LICENSE PLATE AND TAIL LAMPS

System Diagram

INFOID:0000000007355124



ABLIA2837GB

System Description

INFOID:0000000007355125

PARKING, LICENSE PLATE AND TAIL LAMPS OPERATION

When the lighting switch is in 1ST position, BCM detects the LIGHTING SWITCH 1ST POSITION ON. The BCM sends a parking light ON request via the CAN communication lines to the IPDM E/R. The IPDM E/R then activates the tail lamp relay which sends power to the parking and instrument illumination circuits.

EXTERIOR LAMP BATTERY SAVER CONTROL

With the combination switch (lighting and turn signal switch) in the 2ND position and the ignition switch is turned from ON or ACC to OFF, the battery saver feature is activated.


Under this condition, the headlamps remain illuminated for 5 minutes (early production) or 45 seconds (late production) unless the lighting switch position is changed. If the lighting switch position is changed, then the headlamps are turned off.

This setting can be changed by CONSULT. Refer to [BCS-24, "BATTERY SAVER : CONSULT Function \(BCM - BATTERY SAVER\)".](#)

Component Parts Location

INFOID:0000000007355126

EXL



WKIA4963E

1. IPDM E/R E121, E122, E123, E124
2. BCM M18, M20 (view with lower instrument panel LH removed)
3. Combination switch (lighting and turn signal switch) M28
4. Combination meter M24

PARKING, LICENSE PLATE AND TAIL LAMPS

< SYSTEM DESCRIPTION >

Component Description

INFOID:000000007355127

Part name	Description
BCM	<ul style="list-style-type: none">• Receives lighting switch requests via BCM combination switch reading function.• Sends parking light request signal to the IPDM E/R.
IPDM E/R	Activates the tail lamp relay upon request of the BCM.
Combination switch (lighting and turn signal switch)	Outputs lighting requests to the BCM.


COMBINATION SWITCH READING SYSTEM

< SYSTEM DESCRIPTION >

COMBINATION SWITCH READING SYSTEM

System Diagram

INFOID:0000000007827516



System Description


INFOID:0000000007827517

OUTLINE

- BCM reads the status of the combination switch (light, turn signal, wiper and washer) and recognizes the status of each switch.
- BCM has a combination of 5 output terminals (OUTPUT 1 - 5) and 5 input terminals (INPUT 1 - 5) and reads a maximum of 20 switch states.

COMBINATION SWITCH MATRIX

Combination switch circuit



Combination switch INPUT-OUTPUT system list

System	INPUT 1	INPUT 2	INPUT 3	INPUT 4	INPUT 5
OUTPUT 1	—	FR WASHER	FR WIPER LOW	TURN LH	TURN RH
OUTPUT 2	FR WIPER HI	—	FR WIPER INT	PASSING	HEADLAMP 1
OUTPUT 3	INT VOLUME 1	RR WASHER	—	HEADLAMP 2	HI BEAM

COMBINATION SWITCH READING SYSTEM


< SYSTEM DESCRIPTION >

System	INPUT 1	INPUT 2	INPUT 3	INPUT 4	INPUT 5
OUTPUT 4	RR WIPER INT	INT VOLUME 3	AUTO LIGHT	—	TAIL LAMP
OUTPUT 5	INT VOLUME 2	RR WIPER ON	—	FR FOG	—

COMBINATION SWITCH READING FUNCTION

Description


- BCM reads the status of the combination switch at 10 ms intervals normally.



NOTE:

BCM reads the status of the combination switch at 60 ms intervals when BCM is controlled at low power consumption control mode.

- BCM operates as follows and judges the status of the combination switch.
- It operates the transistor on OUTPUT side in the following order: OUTPUT 1 → 2 → 3 → 4 → 5, and outputs voltage waveform.
- The voltage waveform of OUTPUT corresponding to the formed circuit is input into the interface on INPUT side if any (1 or more) switches are ON.
- It reads this change of the voltage as the status signal of the combination switch.



Operation Example


In the following operation example, the combination of the status signals of the combination switch is replaced as follows: INPUT 1 - 5 to "1 - 5" and OUTPUT 1 - 5 to "A - E".

Example 1: When a switch (TAIL LAMP) is turned ON

COMBINATION SWITCH READING SYSTEM

< SYSTEM DESCRIPTION >


- The circuit between OUTPUT 4 and INPUT 5 is formed when the TAIL LAMP switch is turned ON.



- BCM detects the combination switch status signal "5D" when the signal of OUTPUT 4 is input to INPUT 5.
- BCM judges that the TAIL LAMP switch is ON when the signal "5D" is detected.

Example 2: When some switches (TURN RH, TAIL LAMP) are turned ON

- The circuits between OUTPUT 1 and INPUT 5 and between OUTPUT 4 and INPUT 5 are formed when the TURN RH switch and TAIL LAMP switch are turned ON.



- BCM detects the combination switch status signal "5AD" when the signals of OUTPUT 1 and OUTPUT 4 are input to INPUT 5.
- BCM judges that the TURN RH switch and TAIL LAMP switch are ON when the signal "5AD" is detected.

WIPER INTERMITTENT DIAL POSITION SETTING (FRONT WIPER INTERMITTENT OPERATION)
BCM judges the wiper intermittent dial 1 - 7 by the status of INT VOLUME 1, 2, and 3 switches.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


COMBINATION SWITCH READING SYSTEM

< SYSTEM DESCRIPTION >

Wiper intermittent dial position	Intermittent operation delay interval	INT VOLUME switch ON/OFF status		
		INT VOLUME 1	INT VOLUME 2	INT VOLUME 3
1	Short ↑	ON	ON	ON
2		ON	ON	OFF
3		ON	OFF	OFF
4		OFF	OFF	OFF
5		OFF	OFF	ON
6		OFF	ON	ON
7		OFF	ON	OFF

Component Parts Location

INFOID:0000000007827518



ALMIA0308ZZ

1. BCM M18, M19, M20 (view with lower instrument panel LH removed)
2. Combination switch (lighting and turn signal switch) M28
3. Combination switch (wiper and washer switch) M28


TRAILER TOW

< SYSTEM DESCRIPTION >

TRAILER TOW

System Diagram

INFOID:0000000007355131



ABLIA2788GB

System Description

INFOID:0000000007355132

TRAILER TAIL LAMP OPERATION

The trailer tail lamps are controlled by the trailer tow relay 1 located in the IPDM E/R. With the combination switch (lighting and turn signal switch) in the 1st position, the BCM detects the LIGHTING SWITCH 1ST POSITION ON. The BCM sends a parking light ON request via the CAN communication lines to the IPDM E/R. The IPDM E/R then activates the tail lamp relay which activates the trailer tow relay 1 and sends power to the trailer connector.

TRAILER TURN SIGNAL LAMP OPERATION

The trailer turn signal lamps are controlled by the BCM. When the turn signal switch is in the LH or RH position with the ignition switch ON, the combination switch (lighting and turn signal switch) sends a signal to the BCM. The BCM detects the TURN RH or TURN LH ON request. The BCM sends a control signal to the respective trailer turn relay which sends power to the trailer connector.

TRAILER HAZARD LAMP OPERATION

The trailer hazard lamps are controlled by the BCM. When the hazard switch is pressed, the BCM detects the the hazard ON request. The BCM then sends a control signal to both trailer turn relays which sends power to the trailer connector.

TRAILER BRAKE LAMP OPERATION

The trailer brake lamps are controlled by the BCM. When the brake pedal is depressed, the combination meter receives a stop lamp switch signal from the stop lamp switch. The combination meter then sends the brake signal to the BCM via the CAN communication lines. The BCM then sends a control signal to both trailer turn relays which sends power to the trailer connector.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O


P

TRAILER TOW

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:0000000007355133



1. Stop lamp switch E38 (view with lower instrument panel LH removed)
2. Brake pedal
3. BCM, M18, M19, M20 (view with lower instrument panel LH removed)
4. Trailer turn relay LH E163
5. IPDM E/R E121, E122, E124
6. Trailer turn relay RH E164
7. Trailer tow relay 2 E140
8. Trailer tow relay 1 E148
9. Combination switch (lighting and turn signal switch) M28
10. Combination meter M24

Component Description

INFOID:0000000007355134

Part name	Description
BCM	<ul style="list-style-type: none">• Receives lighting and turn signal requests from combination switch (lighting and turn signal switch).• Receives stop lamp signal requests from combination meter via CAN communication.• Sends lighting signal request to the IPDM E/R to control the tail lamp relay via CAN communication.• Sends turn/hazard/brake control signal to the trailer turn relays.
IPDM E/R	Activates the tail lamp relay upon request from the BCM via CAN communication.
Combination meter	<ul style="list-style-type: none">• Receives stop lamp switch signal from stop lamp switch.• Sends stop lamp signal request to the BCM via CAN communication.
Combination switch (lighting and turn signal switch)	Outputs lighting and turn signal requests to the BCM.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000007827519

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> • The vehicle specification can be read and saved. • The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK			×	×	×		
Rear window defogger	REAR DEFOGGER			×	×			
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Remote keyless entry system	MULTI REMOTE ENT			×	×	×		
Exterior lamp	HEAD LAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY			×				
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×	×		
Back door open	TRUNK			×	×			
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×	×	×		
Signal buffer system	SIGNAL BUFFER			×	×			
TPMS	AIR PRESSURE MONITOR		×	×	×	×		
Panic alarm system	PANIC ALARM				×			

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)

INFOID:0000000007827520

DATA MONITOR

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
ACC ON SW [On/Off]	Indicates condition of ignition switch ACC position.
HI BEAM SW [On/Off]	
HEAD LAMP SW 1 [On/Off]	
HEAD LAMP SW 2 [On/Off]	
LIGHT SW 1ST [On/Off]	Indicates condition of combination switch.
AUTO LIGHT SW [On/Off]	
PASSING SW [On/Off]	
FR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
BACK DOOR SW [On/Off]	Indicates condition of back door switch.
TURN SIGNAL R [On/Off]	
TURN SIGNAL L [On/Off]	Indicates condition of combination switch.
OPTICAL SENSOR [V]	Indicates voltage signal from optical sensor.

ACTIVE TEST

Test Item	Description
TAIL LAMP	This test is able to check tail lamp operation [Off/On].
HEAD LAMP	This test is able to check head lamp operation [Off/Lo/Hi].
FR FOG LAMP	This test is able to check front fog lamp operation [Off/On].

WORK SUPPORT

Support Item	Setting	Description
BATTERY SAVER SET	Off	Exterior lamp battery saver function OFF.
	On*	Exterior lamp battery saver function ON.
CUSTOM A/LIGHT SETTING	MODE4	Less sensitive setting than normal setting (Turns ON later than normal operation).
	MODE3	More sensitive setting than MODE 2 (Turns ON earlier than MODE 2).
	MODE2	More sensitive setting than normal setting (Turns ON earlier than normal operation).
	MODE1*	Normal.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Support Item	Setting		Description
ILL DELAY SET	MODE8	180 sec	Sets delay timer function operation time (All doors closed).
	MODE7	150 sec	
	MODE6	120 sec	
	MODE5	90 sec	
	MODE4	60 sec	
	MODE3	30 sec	
	MODE2	OFF	
	MODE1*	45 sec	

*: Initial setting

A

FLASHER

B

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000007827521

C

DATA MONITOR

D

Monitor Item [Unit]	Description
IGN ON SW [On/Off]	Indicates condition of ignition switch ON position.
HAZARD SW [On/Off]	Indicates condition of hazard switch.
TURN SIGNAL R [On/Off]	Indicates condition of turn signal function of combination switch.
TURN SIGNAL L [On/Off]	
BRAKE SW [On/Off]	Indicates condition of brake switch.

E

ACTIVE TEST

F

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [Off/LH/RH].

G

COMB SW

H

COMB SW : CONSULT Function (BCM - COMB SW)

INFOID:000000007827522

I

DATA MONITOR

J

Monitor Item [Unit]	Description
TURN SIGNAL R [On/Off]	Indicates condition of turn signal operation of combination switch.
TURN SIGNAL L [On/Off]	Indicates condition of turn signal operation of combination switch.
HI BEAM SW [On/Off]	Indicates condition of hi beam operation of combination switch.
HEAD LAMP SW 1 [On/Off]	Indicates condition of headlamp operation of combination switch.
HEAD LAMP SW 2 [On/Off]	Indicates condition of headlamp operation of combination switch.
LIGHT SW 1ST [On/Off]	Indicates condition of lighting operation of combination switch.
PASSING SW [On/Off]	Indicates condition of passing switch operation of combination switch.
AUTO LIGHT SW [On/Off]	Indicates condition of auto light operation of combination switch.
FR FOG SW [On/Off]	Indicates condition of front fog light operation of combination switch.
FR WIPER HI [On/Off]	Indicates condition of front wiper operation of combination switch.
FR WIPER LOW [On/Off]	
FR WIPER INT [On/Off]	
FR WASHER SW [On/Off]	Indicates condition of front washer operation of combination switch.
INT VOLUME [1 - 7]	Indicates condition of intermittent wiper operation of combination switch.

K

L

M

N

O

P

EXL

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
RR WIPER ON [On/Off]	Indicates condition of rear wiper operation of combination switch.
RR WIPER INT [On/Off]	
RR WASHER SW [On/Off]	Indicates condition of rear washer operation of combination switch.

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (IPDM E/R)

Diagnosis Description

INFOID:0000000007827530

AUTO ACTIVE TEST

Description

In auto active test mode, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure low warning indicator
- Oil pressure gauge
- Rear window defogger
- Front wipers
- Tail, license and parking lamps
- Front fog lamps (if equipped)
- Headlamps (Hi, Lo)
- A/C compressor (magnetic clutch)
- Cooling fan

Operation Procedure

1. Close the hood and front door RH, and lift the wiper arms from the windshield (to prevent windshield damage due to wiper operation).
- NOTE:**
When auto active test is performed with hood opened, sprinkle water on windshield before hand.
2. Turn ignition switch OFF.
 3. Turn the ignition switch ON and, within 20 seconds, press the front door switch LH 10 times. Then turn the ignition switch OFF.
 4. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.
 5. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:

When auto active test mode has to be cancelled halfway through test, turn ignition switch OFF.


CAUTION:

- If auto active test mode cannot be actuated, check door switch system. Refer to [DLK-56, "Description"](#) (with Intelligent Key system), [DLK-229, "Description"](#) (without Intelligent Key system).
- Do not start the engine.

Inspection in Auto Active Test Mode

When auto active test mode is actuated, the following 7 steps are repeated 3 times.

EXL



WKIA4991E

M

N

O

P


Operation sequence	Inspection Location	Operation
1	Rear window defogger	10 seconds
2	Front wipers	LO for 5 seconds → HI for 5 seconds

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

Operation sequence	Inspection Location	Operation
3	Tail, license, front fog and parking lamps	10 seconds
4	Headlamps	LO for 10 seconds → HI on-off for 5 seconds
5	A/C compressor (magnetic clutch)	ON ⇄ OFF 5 times
6	Cooling fan	10 seconds

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test mode

Symptom	Inspection contents	Possible cause
Oil pressure low warning indicator does not operate	Perform auto active test. Does the oil pressure low warning indicator operate?	YES
		NO
Oil pressure gauge does not operate	Perform auto active test. Does the oil pressure gauge operate?	YES
		NO
Rear window defogger does not operate	Perform auto active test. Does the rear window defogger operate?	YES
		NO

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

Symptom	Inspection contents	Possible cause
Any of the following components do not operate • Front wipers • Tail lamps • License plate lamps • Parking lamps • Front fog lamps (if equipped) • Headlamps (Hi, Lo)	Perform auto active test. Does the applicable system operate?	YES BCM signal input system
		NO <ul style="list-style-type: none"> Lamp or front wiper motor malfunction Lamp or front wiper motor ground circuit Harness or connector between IPDM E/R and applicable system IPDM E/R (integrated relay malfunction)
A/C compressor does not operate	Perform auto active test. Does the A/C compressor operate?	YES <ul style="list-style-type: none"> BCM signal input circuit CAN communication signal between BCM and ECM CAN communication signal between ECM and IPDM E/R
		NO <ul style="list-style-type: none"> Magnetic clutch malfunction Harness or connector between IPDM E/R and magnetic clutch IPDM E/R (integrated relay malfunction)
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES <ul style="list-style-type: none"> ECM signal input circuit CAN communication signal between ECM and IPDM E/R
		NO <ul style="list-style-type: none"> Cooling fan motor malfunction Harness or connector between IPDM E/R and cooling fan IPDM E/R (integrated relay malfunction)

CONSULT Function (IPDM E/R)

INFOID:000000007827531

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

EXL

Direct Diagnostic Mode	Description
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SELF DIAGNOSTIC RESULT

Refer to [EXL-76, "DTC Index"](#).

M

N

O

DATA MONITOR

P

Monitor Item [Unit]	Main Signals	Description
MOTOR FAN REQ [1/2/3/4]	×	Indicates cooling fan speed signal received from ECM on CAN communication line
AC COMP REQ [On/Off]	×	Indicates A/C compressor request signal received from ECM on CAN communication line

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Main Signals	Description
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
ST RLY REQ [On/Off]		Indicates starter request signal received from ECM on CAN communication line
IGN RLY [On/Off]	×	Indicates condition of ignition relay
RR DEF REQ [On/Off]	×	Indicates rear defogger request signal received from BCM on CAN communication line
OIL P SW [Open/Close]		Indicates condition of oil pressure switch
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line

ACTIVE TEST

Test item	Description
REAR DEFOGGER	This test is able to check rear defogger operation [On/Off].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].
MOTOR FAN	This test is able to check cooling fan operation [4/3/2/1].
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/TAIL/Off].
HORN	This test is able to check horn operation [On].

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

BCM (BODY CONTROL MODULE)

BCM (BODY CONTROL MODULE) : Diagnosis Procedure

INFOID:0000000007827523

Regarding Wiring Diagram information, refer to [BCS-46, "Wiring Diagram"](#).

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

Terminal No.	Signal name	Fuses and fusible link No.
57	Battery power supply	21 (10A)
70		G (50A)
11	Ignition ACC or ON	4 (10A)
38	Ignition ON or START	1 (10A)

Is the fuse blown?


YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM.
3. Check voltage between BCM harness connector and ground.

Connector	Terminals		Power source	Condition	Voltage (V) (Ap-prox.)
	(+)	(-)			
M18	11	Ground	ACC power supply	Ignition switch ACC or ON	Battery voltage
	38	Ground	Ignition power supply	Ignition switch ON or START	Battery voltage
M20	57	Ground	Battery power supply	Ignition switch OFF	Battery voltage
	70	Ground	Battery power supply	Ignition switch OFF	Battery voltage



Is the measurement value normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >


Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	67		Yes

Does continuity exist?

YES >> Inspection End.

NO >> Repair or replace harness.



LIIA0915E

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) : Diagnosis Procedure

INFOID:000000007827532

Regarding Wiring Diagram information, refer to [PCS-22, "Wiring Diagram".](#)

1. CHECK FUSES AND FUSIBLE LINK

Check that the following IPDM E/R fuses or fusible link are not blown.

Terminal No.	Signal name	Fuses and fusible link No.
1	Battery	A, D
2	Battery	C

Is the fuse blown?


YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2

2. CHECK BATTERY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R.
3. Check voltage between IPDM E/R harness connectors and ground.

Terminals		Ignition switch position		
(+)	(-)	OFF	ON	START
Connector	Terminal			
E118	1	Ground	Battery voltage	Battery voltage
	2		Battery voltage	Battery voltage



Is the measurement value normal?

YES >> GO TO 3

NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.

POWER SUPPLY AND GROUND CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between IPDM E/R harness connectors and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E122 (A)	38		
E124 (B)	59		Yes

Does continuity exist?

- YES >> Inspection End.
NO >> Repair or replace harness.



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

HEADLAMP (HI) CIRCUIT

Description

INFOID:0000000007355143

The IPDM E/R (intelligent power distribution module engine room) controls the headlamp high relay based on inputs from the BCM via the CAN communication lines. When the headlamp high relay is energized, power flows through fuses 34 and 35, located in the IPDM E/R. Power then flows to the front headlamp high beam.

Component Function Check

INFOID:0000000007355144

1. CHECK HEADLAMP (HI) OPERATION

WITHOUT CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-9, "Diagnosis Description"](#).
2. Check that the headlamp switches to the high beam.

NOTE:

HI/LO is repeated 1 second each when using the IPDM E/R auto active test.

WITH CONSULT

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With the test item operating, check that the headlamp switches to high beam.

Hi : Headlamp switches to the high beam.

Off : Headlamp OFF

Does the headlamp switch to high beam?

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-38, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000007355145

Regarding Wiring Diagram information, refer to [EXL-77, "Wiring Diagram"](#) or [EXL-81, "Wiring Diagram"](#).

1. CHECK HEADLAMP (HI) FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

Unit	Location	Fuse No.	Capacity
Headlamp HI (LH)	IPDM E/R	35	10A
Headlamp HI (RH)	IPDM E/R	34	10A

Is the fuse open?


YES >> Replace the fuse after repairing the affected circuit.

NO >> GO TO 2

2. CHECK HEADLAMP (HI) OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the front headlamp connector.
3. Turn the ignition switch ON.
4. Turn the high beam headlamps ON.
5. With the high beam headlamps ON, check the voltage between the headlamp connector and ground.

(+)	(-)	Voltage
Connector	Terminal	



HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

LH	E11 (without DTRL)	1	Ground	Battery voltage
	E6 (with DTRL)			
RH	E107			

Is battery voltage present?


YES >> GO TO 4

NO >> GO TO 3

3.CHECK HEADLAMP (HI) CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector E123.
3. Check continuity between the IPDM E/R harness connector (A) and the front headlamp harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
LH	E123	55	E11 (without DTRL)	Yes
			E6 (with DTRL)	
RH		56	E107	



Does continuity exist?


YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation of IPDM E/R"](#).

NO >> Repair the harnesses or connectors.

4.CHECK FRONT HEADLAMP (HI) GROUND CIRCUIT

Check continuity between the front headlamp harness connector terminal 2 and ground.

Connector	Terminal	—	Continuity
LH	E11 (without DTRL)	2	Yes
	E6 (with DTRL)		
RH	E107		



Does continuity exist?

YES >> Inspect the headlamp bulb.

NO (Except LH with DTRL)>> Repair the harness.

NO (LH with DTRL)>> GO TO 5.

5.CHECK CONTINUITY BETWEEN FRONT HEADLAMP LH (HI) AND DAYTIME LIGHT RELAY 1

1. Disconnect daytime light relay 1 connector.
2. Check continuity between front headlamp LH harness connector and daytime light relay 1 harness connector.

Front headlamp LH		Daytime light relay 1		Continuity
Connector	Terminal	Connector	Terminal	
E6	2	E103	3	Yes

Does continuity exist?

YES >> GO TO 6.

NO >> Repair the harness or connector.

6.CHECK DAYTIME LIGHT RELAY 1 GROUND CIRCUIT

Check continuity between daytime light relay 1 harness connector and ground.

HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Daytime light relay 1		Ground	Continuity
Connector	Terminal		
E103	4		Yes

Does continuity exist?

YES >> GO TO 7.

NO >> Repair the harness or connector.

7.CHECK DAYTIME LIGHT RELAY 1

Check daytime light relay 1. Refer to [EXL-46, "Component Inspection"](#)

Is the inspection result normal?

YES >> Inspect the headlamp bulb.

NO >> Replace daytime light relay 1.

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

HEADLAMP (LO) CIRCUIT

Description

INFOID:0000000007355146

The IPDM E/R (intelligent power distribution module engine room) controls the headlamp low relay based on inputs from the BCM via the CAN communication lines. When the headlamp low relay is energized, power flows through fuses 40 and 41, located in the IPDM E/R. Power then flows to the front headlamp low beams.

Component Function Check

INFOID:0000000007355147

1. CHECK HEADLAMP (LO) OPERATION

WITHOUT CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-9, "Diagnosis Description"](#).
2. Check that the headlamp is turned ON.

NOTE:

HI/LO is repeated 1 second each when using the IPDM E/R auto active test.

WITH CONSULT

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With the test items operating, check that the headlamp is turned ON.

Lo : Headlamp ON

Off : Headlamp OFF

Is the headlamp turned ON?

YES >> Headlamp (LO) is normal.

NO >> Refer to [EXL-41, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000007355148

Regarding Wiring Diagram information, refer to [EXL-77, "Wiring Diagram"](#) or [EXL-81, "Wiring Diagram"](#).

1. CHECK HEADLAMP (LO) FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

Unit	Location	Fuse No.	Capacity
Headlamp LO (LH)	IPDM E/R	40	15A
Headlamp LO (RH)	IPDM E/R	41	15A

Is the fuse open?


YES >> Replace the fuse after repairing the affected circuit.

NO >> GO TO 2

2. CHECK HEADLAMP (LO) OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the front headlamp connector.
3. Turn the ignition switch ON.
4. Turn the low beam headlamps ON.
5. With the low beam headlamps ON, check the voltage between the headlamp connector terminal 3 and ground.

(+)	(-)	Voltage
Connector	Terminal	



HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

LH	E11 (without DTRL)	3	Ground	Battery voltage
	E6 (with DTRL)			
RH	E107			

Is battery voltage present?

YES >> GO TO 8


NO (Except LH with DTRL)>>CHECK HEADLAMP (LO) CIRCUIT FOR OPEN GO TO 3

NO (LH with DTRL) >> CHECK HEADLAMP (LO) CIRCUIT FOR OPEN GO TO 4

3. CHECK HEADLAMP (LO) CIRCUIT FOR OPEN (EXCEPT LH WITH DTRL)

1. Turn the ignition switch OFF.
 2. Disconnect IPDM E/R connector E123.
 3. Check continuity between the IPDM E/R harness connector (A) and the front headlamp harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
LH	E123	52	E11	3
RH		54	E107	



Does continuity exist?

YES >> Replace IPDM E/R. Refer to PCS-29, "Removal and Installation of IPDM E/R".

NO >> Repair the harnesses or connectors.

4. CHECK HEADLAMP (LO) CIRCUIT FOR OPEN (LH WITH DTRL)

1. Turn the ignition switch OFF.
 2. Disconnect IPDM E/R connector E123 and daytime light relay 2 connector.
 3. Check continuity between the IPDM E/R harness connector and the daytime light relay 2 harness connector.

IPDM E/R		Daytime light relay 2		Continuity
Connector	Terminal	Connector	Terminal	
E123	52	E104	5	Yes
			2	

4. Check continuity between the daytime light relay 2 harness connector and the front headlamp LH harness connector.

Daytime light relay 2		Front headlamp LH		Continuity
Connector	Terminal	Connector	Terminal	
E104	3	E6	3	Yes

Does continuity exist?

YES >> GO TO 5

NO >> Repair the harnesses or connectors.

5. CHECK DAYTIME LIGHT RELAY 2 CIRCUIT FOR OPEN

1. Check continuity between the daytime light relay 2 harness connector and the front headlamp LH harness connector.

Daytime light relay 2		Front headlamp LH		Continuity
Connector	Terminal	Connector	Terminal	
E104	3	E6	3	Yes

2. Check continuity between the daytime light relay 2 harness connector and ground.

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Daytime light relay 2		Ground	Continuity
Connector	Terminal		
E104	3		No

Is the measurement value normal?

YES >> GO TO 6

NO >> Repair the harnesses or connectors.

6.CHECK DAYTIME LIGHT RELAY 2 GROUND CIRCUIT

Check continuity between daytime light relay 2 harness connector and ground.

Daytime light relay 2		Ground	Continuity
Connector	Terminal		
E104	1		Yes

Does continuity exist?

YES >> GO TO 7

NO >> Repair the harness or connector.

7.CHECK DAYTIME LIGHT RELAY 2

Check daytime light relay 2. Refer to [EXL-44, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation of IPDM E/R"](#).

NO >> Replace daytime light relay 2.

8.CHECK FRONT HEADLAMP (LO) GROUND CIRCUIT

Check continuity between the front headlamp harness connector terminal 2 and ground.


Connector	Terminal	—	Continuity
LH	E11 (without DTRL)	2	Yes
	E6 (with DTRL)		
RH	E107	Ground	

Does continuity exist?

YES >> Inspect the headlamp bulb.

NO (Except LH with DTRL)>> Repair the harness.

NO (LH with DTRL)>> GO TO 9



9.CHECK CONTINUITY BETWEEN FRONT HEADLAMP LH (HI) AND DAYTIME LIGHT RELAY 1

1. Disconnect daytime light relay 1 connector.
2. Check continuity between front headlamp LH harness connector and daytime light relay 1 harness connector.

Front headlamp LH		Daytime light relay 1		Continuity
Connector	Terminal	Connector	Terminal	
E6	2	E103	3	Yes

Does continuity exist?

YES >> GO TO 10

NO >> Repair the harness or connector.

10.CHECK DAYTIME LIGHT RELAY 1 GROUND CIRCUIT

Check continuity between daytime light relay 1 harness connector and ground.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Daytime light relay 1		Ground	Continuity
Connector	Terminal		
E103	4		Yes

Does continuity exist?

YES >> GO TO 11

NO >> Repair the harness or connector.

11. CHECK DAYTIME LIGHT RELAY 1

Check daytime light relay 1. Refer to [EXL-46, "Component Inspection"](#)

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation of IPDM E/R"](#).

NO >> Replace daytime light relay 1.

Component Inspection

INFOID:000000007355149

1. CHECK DAYTIME LIGHT RELAY 2

1. Turn ignition switch OFF.
2. Remove daytime light relay 2.
3. Check the continuity between daytime light relay 2 terminals under the following conditions.

Terminals	Condition	Continuity
3 and 5	12V direct current supply between terminals 1 and 2	Yes
	No current supply	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace daytime light relay 2.

DAYTIME LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DAYTIME LIGHT RELAY CIRCUIT

Description

INFOID:0000000007355150

The BCM sends a daytime light request to the IPDM E/R via the CAN communication lines. The power flows backward through fuse 45 located in IPDM E/R to daytime light relay 1 and LH high beam lamp to IPDM E/R, through the high beam fuses, through the RH high beam lamp and on to ground. The high beam lamps are wired in series which causes them to illuminate at a reduced intensity.

Diagnosis Procedure

INFOID:0000000007355151

Regarding Wiring Diagram information, refer to [EXL-81, "Wiring Diagram"](#).

1.CHECK DAYTIME LIGHT RELAY 1 FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuse is not open.

Unit	Location	Fuse No.	Capacity
Daytime light relay 1	IPDM E/R	45	10A

Is the fuse open?

- YES >> Replace the fuse after repairing the affected circuit.
NO >> GO TO 2

2.CHECK IPDM E/R OUTPUT SIGNAL

1. Turn the ignition switch OFF.
2. Disconnect the daytime light relay 1 connector.
3. Turn the ignition switch ON.
4. Check the voltage between the daytime light relay 1 harness connector and ground.

(+)	(-)	Voltage	
Connector	Terminal		
E103	2	Ground	Battery voltage
	5		

Is battery voltage present?

- YES >> GO TO 3
NO >> GO TO 5

3.CHECK DAYTIME LIGHT RELAY 1 CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector E122.
3. Check continuity between the IPDM E/R harness connector and the daytime light relay 1 harness connector.

IPDM E/R	Daytime light relay 1			Continuity
Connector	Terminal	Connector	Terminal	
E122	44	E103	1	Yes

4. Check continuity between the daytime light relay 1 harness connector and ground.

Connector	Terminal	—	Continuity
E103	1	Ground	No

Is the measurement value normal?

DAYTIME LIGHT RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

YES >> GO TO 4

NO >> Repair the harnesses or connectors.

4.CHECK DAYTIME LIGHT RELAY 1

Check daytime light relay 1. Refer to [EXL-46, "Component Inspection"](#).

Is the inspection result normal?

YES >> Check headlamp (HI) circuit. If OK, replace IPDM E/R. Refer to [PCS-29, "Removal and Installation of IPDM E/R"](#). If NG, refer to [EXL-38, "Diagnosis Procedure"](#).

NO >> Replace daytime light relay1.

5.CHECK DAYTIME LIGHT RELAY CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector E119.
3. Check continuity between the IPDM E/R harness connector and the daytime light relay 1 harness connector.

IPDM E/R		Daytime light relay 1		Continuity
Connector	Terminal	Connector	Terminal	
E119	10	E103	2	Yes
			5	

Does continuity exist?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation of IPDM E/R"](#).

NO >> Repair the harnesses or connectors.

Component Inspection

INFOID:0000000007355152

1. CHECK DAYTIME LIGHT RELAY 1

1. Turn ignition switch OFF.
2. Remove daytime light relay 1.
3. Check the continuity between daytime light relay 1 terminals under the following conditions.

Terminals	Condition	Continuity
3 and 5	12V direct current supply between terminals 1 and 2	Yes
	No current supply	No
3 and 4	12V direct current supply between terminals 1 and 2	No
	No current supply	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace daytime light relay 1

FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT FOG LAMP CIRCUIT

Description

INFOID:0000000007355153

The IPDM E/R (intelligent power distribution module engine room) controls the front fog lamp relay based on inputs from the BCM via the CAN communication lines. When the front fog lamp relay is energized, power flows from the front fog lamp relay in the IPDM E/R to the front fog lamps.

Component Function Check

INFOID:0000000007355154

1.CHECK FRONT FOG LAMP OPERATION

WITHOUT CONSULT

1. Activate IPDM E/R auto active test. Refer to [PCS-9, "Diagnosis Description"](#).
2. Check that the front fog lamp is turned ON.

WITH CONSULT

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, Check that the front fog lamp is turned ON.

Fog : Front fog lamp ON

Off : Front fog lamp OFF

Is the front fog lamp turned ON?

YES >> Front fog lamp circuit is normal.

NO >> Refer to [EXL-47, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000007355155

Regarding Wiring Diagram information, refer to [EXL-97, "Wiring Diagram"](#).

1.CHECK FRONT FOG LAMP FUSE

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	56	20A

Is the fuse open?


YES >> Replace the fuse after repairing the affected circuit.

NO >> GO TO 2

2.CHECK FRONT FOG LAMP OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect the front fog lamp connector.
3. Turn the ignition switch ON.
4. Turn the front fog lamps ON.
5. Check the voltage between the fog lamp connector and ground.

(+)		(-)	Voltage
Connector	Terminal		
LH	E101	1	
RH	E102	1	



Is battery voltage present?

YES >> GO TO 4

NO >> GO TO 3

FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK FRONT FOG LAMP OPEN CIRCUIT


1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector E123.
3. Check continuity between the IPDM E/R harness connector (A) and the front fog lamp harness connector (B).

A		B		Continuity	
Connector	Terminal	Connector	Terminal		
LH	E123	50	E101	1	Yes
RH		51	E102	1	

Does continuity exist?

YES >> Replace IDPM E/R. Refer to [PCS-29, "Removal and Installation of IPDM E/R"](#).

NO >> Repair the harnesses or connectors.



ALLIA0628GB

4. CHECK FRONT FOG LAMP GROUND CIRCUIT

1. Disconnect the front fog lamp connector.
2. Check continuity between the front fog lamp harness connector terminal and ground.

Connector	Terminal	—	Continuity
LH	E101	2	Ground
RH	E102	2	

Does continuity exist?

YES >> Inspect the fog lamp bulb.

NO >> Repair the harness.

PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

PARKING LAMP CIRCUIT

Description

INFOID:0000000007355156

The IPDM E/R (intelligent power distribution module engine room) controls the tail lamp relay based on inputs from the BCM via the CAN communication lines. When the tail lamp relay is energized, power flows through fuse 36 and 37, located in the IPDM E/R. Power then flows to the front and rear combination lamps, license plate lamps.

Component Function Check

INFOID:0000000007355157

1. CHECK PARKING LAMP OPERATION

WITHOUT CONSULT

1. Activate IPDM E/R auto active test. Refer to [PCS-9, "Diagnosis Description"](#).
2. Check that the parking lamp is turned ON.

WITH CONSULT

1. Select "EXTERNAL LAMPS" of IPDM E/R active test item.
2. With operating the test items, check that the parking lamp is turned ON.

TAIL : Parking lamp ON

Off : Parking lamp OFF

Is the parking lamp turned ON?

- YES >> Parking lamp circuit is normal.
NO >> Refer to [EXL-49, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000007355158

Regarding Wiring Diagram information, refer to [EXL-107, "Wiring Diagram"](#).

1. CHECK PARKING LAMP FUSES

1. Turn the ignition switch OFF.
2. Check that the following fuses are not open.

Unit	Location	Fuse No.	Capacity
Parking lamps	IPDM E/R	36	10A
		37	10A

Is the fuse open?

- YES >> Replace the fuse after repairing the affected circuit.
NO >> GO TO 2

2. CHECK TAIL LAMP RELAY OUTPUT (VOLTAGE)

1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp connector, front side marker lamp connector, rear combination lamp connector and license plate lamp connector.
3. Turn the ignition switch ON.
4. Turn the parking lamps ON.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O


P

PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

5. With the parking lamps ON, check voltage between the front combination lamp connector and ground.


(+)		Terminal	(-)	Voltage
Connector				
LH	E27		2	Ground
RH	E111			Battery voltage



AWLIA1671ZZ

6. With the parking lamps ON, check voltage between the front side marker lamp connector and ground.


(+)		Terminal	(-)	Voltage
Connector				
LH	E17		1	Ground
RH	E108			Battery voltage



AWLIA1672ZZ

7. With the parking lamps ON, check voltage between the rear combination lamp connector and ground.


(+)		Terminal	(-)	Voltage
Connector				
LH	B35		1	Ground
RH	B105			Battery voltage



ALLIA0632GB

8. With the parking lamps ON, check voltage between the license plate lamp connector and ground

(+)		Terminal	(-)	Voltage
Connector				
LH	D506		1	Ground
RH	D507			Battery voltage



ALLIA0633GB

Are voltage readings as specified?

YES >> GO TO 4

NO >> GO TO 3


3.CHECK PARKING, LICENSE PLATE AND TAIL LAMP CIRCUIT (OPEN)

PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >


1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between the IPDM E/R harness connector (A)(B) and the front parking lamp harness connector (C).

Connector	Terminal	Connector	Terminal	Continuity
LH	A: E121	28	C: E27	
RH	B: E123	49	C: E111	2 Yes




4. Check continuity between the IPDM E/R harness connector (A)(B) and the front side marker lamp harness connector (C).

Connector	Terminal	Connector	Terminal	Continuity
LH	A: E121	28	C: E17	
RH	B: E123	49	C: E108	1 Yes



5. Check continuity between the IPDM E/R harness connector (A) and the rear combination lamp harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
LH	E124	57	B35	
RH			B105	1 Yes



PARKING LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >


6. Check continuity between the IPDM E/R harness connector (A) and license plate lamp connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
E124	57	D506	1	Yes
		D507		

Are continuity results as specified?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation of IPDM E/R".](#)


NO >> Repair the harnesses or connectors.



4. CHECK PARKING, LICENSE AND TAIL LAMP GROUND CIRCUITS


1. Check continuity between the front parking lamp harness connector and ground.

Connector	Terminal	—	Continuity
LH	E27	1	Yes
RH	E111		




2. Check continuity between the front side marker lamp harness connector and ground.

Connector	Terminal	—	Continuity
LH	E17	2	Yes
RH	E108		



3. Check continuity between the rear combination lamp harness connector and ground.

Connector	Terminal	—	Continuity
LH	B35	5	Yes
RH	B105		



PARKING LAMP CIRCUIT


< DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between the license plate lamp harness connector and ground.

Connector	Terminal	—	Continuity
D506	2	Ground	Yes
D507			

Are continuity results as specified?

- YES >> Inspect the parking lamp bulb.
NO >> Repair the harness.



A
B
C
D
E
F
G
H
I
J
K
L
EXL
M
N
O
P

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

TURN SIGNAL LAMP CIRCUIT

Description

INFOID:0000000007355159

The BCM monitors inputs from the combination switch (lighting and turn signal switch) to determine when to activate the turn signals. The BCM outputs voltage direction to the left and right turn signals during turn signal operation or both during hazard warning operation. The BCM sends a turn signal indicator request to the combination meter via the CAN communication lines.

The BCM performs the fast flasher operation (fail-safe) if any bulb or harness of the turn signal lamp circuit is open.

NOTE:

Turn signal lamp blinks at normal speed when using the hazard warning lamp.

Component Function Check

INFOID:0000000007355160

1.CHECK TURN SIGNAL LAMP

WITH CONSULT

1. Select "FLASHER" of BCM (FLASHER) active test item.
2. With operating the test items, check that the turn signal lamp blinks.

LH : Turn signal lamp LH blinking

RH : Turn signal lamp RH blinking

Off : The turn signal lamp OFF

Does the turn signal lamp blink?

YES >> Turn signal lamp circuit is normal.

NO >> Refer to [EXL-54, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000007355161

Regarding Wiring Diagram information, refer to [EXL-101, "Wiring Diagram"](#).

1.CHECK TURN SIGNAL LAMP BULB

Check the applicable lamp bulb to be sure the proper bulb standard is in use and the bulb is not open.


Is the bulb OK?

YES >> GO TO 2

NO >> Replace the bulb.

2.CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE

1. Turn the ignition switch OFF.
2. Disconnect front combination lamp connector and rear combination lamp connector.
3. Turn the ignition switch ON.
4. With turn signal switch operating, check the voltage between the front combination lamp harness connector and ground.


(+) Connector		Terminal	(-)	Voltage
Connector	Terminal			
E27	LH			
E111	RH	3	Ground	 PKID0926E

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

5. With turn signal switch operating, check the voltage between the rear combination lamp harness connector and ground.

(+)		(-)	Voltage
Connector	Terminal		
B35	LH		
B105	RH	4	Ground



PKID0926E


Is voltage reading as specified?

- YES >> GO TO 3
NO >> GO TO 5

3.CHECK TURN SIGNAL LAMP CIRCUIT FOR OPEN


- Turn the ignition switch OFF.
- Disconnect BCM connector M20, front combination lamp connector and rear combination lamp connector.
- Check continuity between the BCM harness connector M20 (A) and the front combination lamps harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
Front LH	M20	60	E27	Yes
Front RH		61	E111	



4. Check continuity between the BCM harness connector M20 (A) and the rear combination lamp harness connector (B).

A		B		Continuity
Connector	Terminal	Connector	Terminal	
Rear LH	M20	60	B35	Yes
Rear RH		61	B105	




Are continuity results as specified?

- YES >> GO TO 4
NO >> Repair the harnesses or connectors.

4.CHECK TURN SIGNAL LAMP SHORT CIRCUIT

Check continuity between the BCM harness connector M20 and ground.

Connector	Terminal	—	Continuity
LH	M20	60	No
RH		61	



Does continuity exist?

- YES >> Repair the harnesses or connectors.
NO >> Replace BCM. Refer to [BCS-53, "Removal and Installation"](#).

5.CHECK TURN SIGNAL LAMP GROUND CIRCUIT


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

1. Check continuity between the front combination lamp harness connector and ground.

Connector	Terminal	—	Continuity
Front LH	E27	1	Ground
Front RH	E111		Yes




2. Check continuity between the rear combination lamp harness connector and ground.

Connector	Terminal	—	Continuity
Rear LH	B35	5	Ground
Rear RH	B105		Yes

Are continuity results as specified?

- YES >> Replace the malfunctioning lamp.
 NO >> Repair the harnesses or connectors.



OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

OPTICAL SENSOR

Description

INFOID:0000000007355162

The optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to the BCM.

Component Function Check

INFOID:0000000007355163

1.CHECK OPTICAL SENSOR SIGNAL BY CONSULT

WITH CONSULT

1. Turn the ignition switch ON.
2. Select "OPTICAL SENSOR" of BCM (HEAD LAMP) DATA MONITOR item.
3. Turn the lighting switch to AUTO.
4. With the optical sensor illuminating, check the monitor status.

Monitor item	Condition	Voltage
OPTICAL SENSOR	When illuminating	3.1V or more *
	When shutting off light	0.6V or less

*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

Is the item status normal?

YES >> Optical sensor is normal.

NO >> Refer to [EXL-57, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000007355164

Regarding Wiring Diagram information, refer to [EXL-89, "Wiring Diagram"](#).

1.CHECK OPTICAL SENSOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM connector M18 and optical sensor connector M145.
3. Check continuity between BCM harness connector and optical sensor harness connector.

BCM		Optical sensor		Continuity
Connector	Terminal	Connector	Terminal	
M18	18	M145	3	Yes

4. Check continuity between BCM harness connector and ground.

BCM		—	Continuity
Connector	Terminal		
M18	18	Ground	No

Are continuity results as specified?

YES >> GO TO 2

NO >> Repair harness or connector.

2.CHECK OPTICAL SENSOR SIGNAL CIRCUIT

1. Check continuity between BCM harness connector and optical sensor harness connector.

BCM		Optical sensor		Continuity
Connector	Terminal	Connector	Terminal	
M20	58	M145	4	Yes

OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between BCM harness connector M20 and ground.

BCM		—	Continuity
Connector	Terminal		
M20	58	Ground	No

Are the continuity results as specified?

- YES >> Replace the optical sensor. Refer to [EXL-147, "Removal and Installation"](#).
NO >> Repair harness or connector.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000007827524

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
ACC ON SW	Ignition switch OFF or ON	Off
	Ignition switch ACC	On
AIR COND SW	A/C switch OFF	Off
	A/C switch ON	On
AIR PRESS FL	Front left tire air pressure value	kPa, kg/cm ² , psi
AIR PRESS FR	Front right tire air pressure value	kPa, kg/cm ² , psi
AIR PRESS RL	Rear left tire air pressure value	kPa, kg/cm ² , psi
AIR PRESS RR	Rear right tire air pressure value	kPa, kg/cm ² , psi
AUTO LIGHT SW	Lighting switch OFF	Off
	Lighting switch AUTO	On
BACK DOOR SW	Back door closed	Off
	Back door opened	On
BRAKE SW	Brake pedal released	Off
	Brake pedal applied	On
BUCKLE SW	Seat belt buckle unfastened	Off
	Seat belt buckle fastened	On
BUZZER	Buzzer in combination meter OFF	Off
	Buzzer in combination meter ON	On
CDL LOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the LOCK side	On
CDL UNLOCK SW	Door lock/unlock switch does not operate	Off
	Press door lock/unlock switch to the UNLOCK side	On
DOOR SW-AS	Front door RH closed	Off
	Front door RH opened	On
DOOR SW-DR	Front door LH closed	Off
	Front door LH opened	On
DOOR SW-RL	Rear door LH closed	Off
	Rear door LH opened	On
DOOR SW-RR	Rear door RH closed	Off
	Rear door RH opened	On
FAN ON SIG	Blower motor fan switch OFF	Off
	Blower motor fan switch ON	On

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
FR WASHER SW	Front washer switch OFF	Off
	Front washer switch ON	On
FR WIPER LOW	Front wiper switch OFF	Off
	Front wiper switch LO	On
FR WIPER HI	Front wiper switch OFF	Off
	Front wiper switch HI	On
FR WIPER INT	Front wiper switch OFF	Off
	Front wiper switch INT	On
FR WIPER STOP	Any position other than front wiper stop position	Off
	Front wiper stop position	On
HAZARD SW	When hazard switch is not pressed	Off
	When hazard switch is pressed	On
HEAD LAMP SW 1	Headlamp switch OFF	Off
	Headlamp switch 1st	On
HEAD LAMP SW 2	Headlamp switch OFF	Off
	Headlamp switch 1st	On
HI BEAM SW	High beam switch OFF	Off
	High beam switch HI	On
ID REGST FL1	ID registration of front left tire incomplete	YET
	ID registration of front left tire complete	DONE
ID REGST FR1	ID registration of front right tire incomplete	YET
	ID registration of front right tire complete	DONE
ID REGST RL1	ID registration of rear left tire incomplete	YET
	ID registration of rear left tire complete	DONE
ID REGST RR1	ID registration of rear right tire incomplete	YET
	ID registration of rear right tire complete	DONE
IGN ON SW	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
IGN SW CAN	Ignition switch OFF or ACC	Off
	Ignition switch ON	On
INT VOLUME	Wiper intermittent dial is in a dial position 1 - 7	1 - 7
I-KEY LOCK ¹	LOCK button of Intelligent Key is not pressed	Off
	LOCK button of Intelligent Key is pressed	On
I-KEY PANIC ¹	PANIC button of Intelligent Key is not pressed	Off
	PANIC button of Intelligent Key is pressed	On
I-KEY PW DWN ¹	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed for greater than 3 seconds and driver's window operating in DOWN direction	On
I-KEY UNLOCK ¹	UNLOCK button of Intelligent Key is not pressed	Off
	UNLOCK button of Intelligent Key is pressed	On
KEY CYL LK-SW	Door key cylinder LOCK position	Off
	Door key cylinder other than LOCK position	On

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
KEY CYL UN-SW	Door key cylinder UNLOCK position	Off
	Door key cylinder other than UNLOCK position	On
KEY ON SW	Mechanical key is removed from key cylinder	Off
	Mechanical key is inserted to key cylinder	On
KEYLESS LOCK ²	LOCK button of key fob is not pressed	Off
	LOCK button of key fob is pressed	On
KEYLESS PANIC ²	PANIC button of key fob is not pressed	Off
	PANIC button of key fob is pressed	On
KEYLESS UNLOCK ²	UNLOCK button of key fob is not pressed	Off
	UNLOCK button of key fob is pressed	On
LIGHT SW 1ST	Lighting switch OFF	Off
	Lighting switch 1st	On
OIL PRESS SW	• Ignition switch OFF or ACC • Engine running	Off
	Ignition switch ON	On
OPTICAL SENSOR	Bright outside of the vehicle	Close to 5V
	Dark outside of the vehicle	Close to 0V
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
PUSH SW ¹	Return to ignition switch to LOCK position	Off
	Press ignition switch	On
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
RR WASHER SW	Rear washer switch OFF	Off
	Rear washer switch ON	On
RR WIPER INT	Rear wiper switch OFF	Off
	Rear wiper switch INT	On
RR WIPER ON	Rear wiper switch OFF	Off
	Rear wiper switch ON	On
RR WIPER STOP	Rear wiper stop position	Off
	Other than rear wiper stop position	On
TURN SIGNAL L	Turn signal switch OFF	Off
	Turn signal switch LH	On
TURN SIGNAL R	Turn signal switch OFF	Off
	Turn signal switch RH	On
VEHICLE SPEED	While driving	Equivalent to speedometer reading
WARNING LAMP	Low tire pressure warning lamp in combination meter OFF	Off
	Low tire pressure warning lamp in combination meter ON	On

1: With Intelligent Key

2: With remote keyless entry system


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal Layout

INFOID:0000000007827525







Physical Values

LIIA2443E

INFOID:0000000007827526

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
1	BR	Ignition keyhole illumination	Output	OFF	Door is locked (SW OFF)	Battery voltage
					Door is unlocked (SW ON)	0V
2	P	Combination switch input 5	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
3	SB	Combination switch input 4	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
4	V	Combination switch input 3	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
5	L	Combination switch input 2	Input	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
6	R	Combination switch input 1				
9	Y	Rear window defogger switch	Input	ON	Rear window defogger switch ON	0V
					Rear window defogger switch OFF	5V
11	G/B	Ignition switch (ACC or ON)	Input	ACC or ON	Ignition switch ACC or ON	Battery voltage
12	LG	Front door switch RH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
13	L	Rear door switch RH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
15	W	Tire pressure warning check connector	Input	OFF	—	5V
18	BR	Remote keyless entry receiver and optical sensor (ground)	Output	OFF	—	0V

A

B

C

D

E

F

G

H

I

J

K

EXL

M





N

O

P





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
19	V	Remote keyless entry receiver (power supply)	Output	OFF	Ignition switch OFF	 LIIIA1893E
20	G	Remote keyless entry receiver (signal)	Input	OFF	Stand-by (keyfob buttons released)	 LIIIA1894E
					When remote keyless entry receiver receives signal from keyfob (keyfob buttons pressed)	 LIIIA1895E
21	GR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage.
22	V	BUS	—	—	Ignition switch ON or power window timer operates	 PIIA2344E
23	G	Security indicator lamp	Output	OFF	Goes OFF → illuminates (Every 2.4 seconds)	Battery voltage → 0V
25	BR	NATS antenna amp.	Input	OFF → ON	Ignition switch (OFF → ON)	Just after turning ignition switch ON: Pointer of tester should move for approx. 1 second, then return to battery voltage.
27	W	Compressor ON signal	Input	ON	A/C switch OFF	5V
					A/C switch ON	0V
28	R	Front blower monitor	Input	ON	Front blower motor OFF	Battery voltage
					Front blower motor ON	0V
29	G	Hazard switch	Input	OFF	ON	0V
					OFF	5V
30 ¹	G	Back door opener switch	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
30 ²	SB	Back door opener switch	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage

BCM (BODY CONTROL MODULE)



< ECU DIAGNOSIS INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
32	O	Combination switch output 5	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
33	GR	Combination switch output 4	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
34	G	Combination switch output 3	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5291E
35	BR	Combination switch output 2	Output	ON	Lighting, turn, wiper OFF Wiper dial position 4	 SKIA5292E
36	LG	Combination switch output 1				
37 ¹	B	Key switch and key lock solenoid	Input	OFF	Key inserted	Battery voltage
					Key inserted	0V
37 ²	B	Key switch and ignition knob switch	Input	OFF	Intelligent Key inserted	Battery voltage
					Intelligent Key inserted	0V
38	W/R	Ignition switch (ON)	Input	ON	—	Battery voltage
39	L	CAN-H	—	—	—	—
40	P	CAN-L	—	—	—	—
42	LG	Glass hatch ajar switch	Input	ON	Glass hatch open	0V
					Glass hatch closed	Battery voltage
43	P	Back door latch switch	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage

A
 B
 C
 D
 E
 F
 G
 H
 I
 J
 K
 EXL
 M
 N
 O
 P



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
44	O	Rear wiper auto stop switch	Input	ON	Rise up position (rear wiper arm on stopper)	0V
					A Position (full clockwise stop position)	Battery voltage
					Forward sweep (counterclockwise direction)	Fluctuating
					B Position (full counterclockwise stop position)	0V
					Reverse sweep (clockwise direction)	Fluctuating
47	GR	Front door switch LH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
48	P	Rear door switch LH	Input	OFF	ON (open)	0V
					OFF (closed)	Battery voltage
49	L	Cargo lamp	Output	OFF	Any door open (ON)	0V
					All doors closed (OFF)	Battery voltage
51	O	Trailer turn signal (right)	Output	ON	Turn right ON	 SKIA3009J
52	LG	Trailer turn signal (left)	Output	ON	Turn left ON	 SKIA3009J
53	L	Back door latch actuator	Output	OFF	OFF	0
					ON	Battery voltage
55	W	Rear wiper output circuit 1	Output	ON	OFF	0
					ON	Battery voltage
56	R/Y	Battery saver output	Output	OFF	15 minutes (early production) or 10 minutes (late production) after ignition switch is turned OFF	0V
					ON	—
57	R/Y	Battery power supply	Input	OFF	—	Battery voltage
58	W	Optical sensor	Input	ON	When optical sensor is illuminated	3.1V or more
					When optical sensor is not illuminated	0.6V or less
59	GR	Front door lock assembly LH actuator (unlock)	Output	OFF	OFF (neutral)	0V
					ON (unlock)	Battery voltage

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value or waveform (Approx.)
				Ignition switch	Operation or condition	
60	LG	Turn signal (left)	Output	ON	Turn left ON	 SKIA3009J
61	G	Turn signal (right)	Output	ON	Turn right ON	 SKIA3009J
63	BR	Interior room/map lamp	Output	OFF	Any door switch ON (open) OFF (closed)	0V Battery voltage
65	V	All door lock actuators (lock)	Output	OFF	OFF (neutral) ON (lock)	0V Battery voltage
66	L	Front door lock actuator RH, rear door lock actuators LH/RH and glass hatch lock actuator (unlock)	Output	OFF	OFF (neutral) ON (unlock)	0V Battery voltage
67	B	Ground	Input	ON	—	0V
68	W/R	Power window power supply (RAP)	Output	—	Ignition switch ON	Battery voltage
					Within 45 seconds after ignition switch OFF	Battery voltage
					More than 45 seconds after ignition switch OFF	0V
					When front door LH or RH is open or power window timer operates	0V
69	L	Power window power supply	Output	—	—	Battery voltage
70	W	Battery power supply	Input	OFF	—	Battery voltage

1: With remote keyless entry system

2: With Intelligent Key system

Fail Safe

INFOID:0000000007827527

Fail-safe index

BCM performs fail-safe control when any DTC listed below is detected.

Display contents of CONSULT	Fail-safe	Cancellation
U1000: CAN COMM CIRCUIT	Inhibit engine cranking	When the BCM re-establishes communication with the other modules.

DTC Inspection Priority Chart

INFOID:0000000007827528

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Priority	DTC
1	• U1000: CAN COMM CIRCUIT
2	• B2190: NATS ANTENNA AMP • B2191: DIFFERENCE OF KEY • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2013: STRG COMM 1 • B2552: INTELLIGENT KEY • B2590: NATS MALFUNCTION
3	• C1729: VHCL SPEED SIG ERR • C1735: IGNITION SIGNAL
4	• C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1712: [CHECKSUM ERR] FL • C1713: [CHECKSUM ERR] FR • C1714: [CHECKSUM ERR] RR • C1715: [CHECKSUM ERR] RL • C1716: [PRESSDATA ERR] FL • C1717: [PRESSDATA ERR] FR • C1718: [PRESSDATA ERR] RR • C1719: [PRESSDATA ERR] RL • C1720: [CODE ERR] FL • C1721: [CODE ERR] FR • C1722: [CODE ERR] RR • C1723: [CODE ERR] RL • C1724: [BATT VOLT LOW] FL • C1725: [BATT VOLT LOW] FR • C1726: [BATT VOLT LOW] RR • C1727: [BATT VOLT LOW] RL

DTC Index

INFOID:000000007827529

NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Low tire pressure warning lamp ON	Reference page
No DTC is detected. Further testing may be required.	—	—	—	—
U1000: CAN COMM CIRCUIT	X	—	—	BCS-29
B2013: STRG COMM 1	—	—	—	SEC-30
B2190: NATS ANTENNA AMP	—	—	—	SEC-33 (with I-Key) SEC-132 (without I-Key)
B2191: DIFFERENCE OF KEY	—	—	—	SEC-36 (with I-Key) SEC-135 (without I-Key)

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

CONSULT display	Fail-safe	Intelligent Key warning lamp ON	Low tire pressure warning lamp ON	Reference page
B2192: ID DISCORD BCM-ECM	—	—	—	SEC-37 (with I-Key) SEC-136 (without I-Key)
B2193: CHAIN OF BCM-ECM	—	—	—	SEC-39 (with I-Key) SEC-138 (without I-Key)
B2552: INTELLIGENT KEY	—	—	—	SEC-41
B2590: NATS MALFUNCTION	—	—	—	SEC-42
C1708: [NO DATA] FL	—	—	X	WT-14
C1709: [NO DATA] FR	—	—	X	WT-14
C1710: [NO DATA] RR	—	—	X	WT-14
C1711: [NO DATA] RL	—	—	X	WT-14
C1712: [CHECKSUM ERR] FL	—	—	X	WT-16
C1713: [CHECKSUM ERR] FR	—	—	X	WT-16
C1714: [CHECKSUM ERR] RR	—	—	X	WT-16
C1715: [CHECKSUM ERR] RL	—	—	X	WT-16
C1716: [PRESSDATA ERR] FL	—	—	X	WT-18
C1717: [PRESSDATA ERR] FR	—	—	X	WT-18
C1718: [PRESSDATA ERR] RR	—	—	X	WT-18
C1719: [PRESSDATA ERR] RL	—	—	X	WT-18
C1720: [CODE ERR] FL	—	—	X	WT-16
C1721: [CODE ERR] FR	—	—	X	WT-16
C1722: [CODE ERR] RR	—	—	X	WT-16
C1723: [CODE ERR] RL	—	—	X	WT-16
C1724: [BATT VOLT LOW] FL	—	—	X	WT-16
C1725: [BATT VOLT LOW] FR	—	—	X	WT-16
C1726: [BATT VOLT LOW] RR	—	—	X	WT-16
C1727: [BATT VOLT LOW] RL	—	—	X	WT-16
C1729: VHCL SPEED SIG ERR	—	—	X	WT-20
C1735: IGNITION SWITCH	—	—	X	WT-21

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Reference Value

INFOID:0000000007827533

VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
MOTOR FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc. 1, 2, 3, 4
AC COMP REQ	A/C switch OFF	Off
	A/C switch ON	On
TAIL&CLR REQ	Lighting switch OFF	Off
	Lighting switch 1ST, 2ND, HI or AUTO (Light is illuminated)	On
HL LO REQ	Lighting switch OFF	Off
	Lighting switch 2ND HI or AUTO (Light is illuminated)	On
HL HI REQ	Lighting switch OFF	Off
	Lighting switch HI	On
FR FOG REQ	Lighting switch 2ND or AUTO (Light is illuminated)	Front fog lamp switch OFF Off
		• Front fog lamp switch ON • Daytime light activated (Canada only) On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF Stop
		Front wiper switch INT 1LOW
		Front wiper switch LO Low
		Front wiper switch HI Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position STOP P
		Any position other than front wiper stop position ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally Off
		Front wiper stops at fail-safe operation BLOCK
ST RLY REQ	Ignition switch OFF or ACC	Off
		On
IGN RLY	Ignition switch START	Off
		On
RR DEF REQ	Ignition switch OFF or ACC	Off
		On
OIL P SW	Rear defogger switch OFF	Open
		Close
DTRL REQ	Rear defogger switch ON	Off
		On
THFT HRN REQ	Not operated <ul style="list-style-type: none">Panic alarm is activatedHorn is activated with VEHICLE SECURITY (THEFT WARNING) SYSTEM	Off
		On


IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
HORN CHIRP	Not operated	Off
	Door locking with keyfob or Intelligent Key (if equipped) (horn chirp mode)	On

Terminal Layout

INFOID:000000007827534



NOTE:

Numbers preceded by an "F" represent the fuse numbers imprinted on the IPDM E/R. The other numbers represent the fuse numbers as they appear in the wiring diagrams.

AAMIA0386GB

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

Physical Values




INFOID:000000007827535

PYHICAL VALUES

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)
				Ignition switch	Operation or condition	
1	W	Battery power supply	Input	OFF	—	Battery voltage
2	R	Battery power supply	Input	OFF	—	Battery voltage
3	G	ECM relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
4	P	ECM relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
6	V	Throttle control motor relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
7	BR	ECM relay control	Input	—	Ignition switch ON or START	0V
					Ignition switch OFF or ACC	Battery voltage
8	W/R	Fuse 54	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
10	R/B	Fuse 45	Output	ON	Daytime light system active	0V
					Daytime light system inactive	Battery voltage
11	Y	A/C compressor	Output	ON or START	A/C switch ON or defrost A/C switch	Battery voltage
					A/C switch OFF or defrost A/C switch	0V
12	W/G	Ignition switch supplied power	Input	—	OFF or ACC	0V
					ON or START	Battery voltage
13	R	Fuel pump relay	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
14	W/G	Fuse 49	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
15	W/R	Fuse 50 (ABS)	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
16	W/G	Fuse 51	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
17	W/G	Fuse 55	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
19	W	Starter motor	Output	START	—	Battery voltage
20	BR	Cooling fan motor (low)	Output	ON or START	—	Battery voltage
21	GR	Ignition switch supplied power	Input	—	OFF or ACC	0V
					START	Battery voltage
22	G	Battery power supply	Output	OFF	—	Battery voltage
23	LG	Door mirror defogger output signal	Output	—	When rear defogger switch is ON	Battery voltage
					When raker defogger switch is OFF	0V

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)
				Ignition switch	Operation or condition	
24	P	Cooling fan motor (high)	Output	—	Conditions correct for cooling fan operation	Battery voltage
					Conditions not correct for cooling fan operation	0V
27	W	Fuse 38	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
28	R	LH front parking and front side marker lamp	Output	OFF	Lighting switch 1st position	OFF 0V
					ON	Battery voltage
29	G	Trailer tow relay	Output	ON	Lighting switch 1st position	OFF 0V
					ON	Battery voltage
30	R/B	Fuse 53	Output	—	Ignition switch ON or START	Battery voltage
					Ignition switch OFF or ACC	0V
32	GR	Wiper low speed signal	Output	ON or START	Wiper switch	OFF Battery voltage
					LO or INT	0V
35	L	Wiper high speed signal	Output	ON or START	Wiper switch	OFF, LO, INT Battery voltage
					HI	0V
37	Y	Power generation command signal	Output	—	Ignition switch ON	(V)  6.3 V JPMIA0001GB
					40% is set on "Active test," "ALTERNATOR DUTY" of "ENGINE"	(V)  3.8 V JPMIA0002GB
					40% is set on "Active test," "ALTERNATOR DUTY" of "ENGINE"	(V)  1.4 V JPMIA0003GB
38	B	Ground	Input	—	—	0V
39	L	CAN-H	—	ON	—	—
40	P	CAN-L	—	ON	—	—
42	GR	Oil pressure switch	Input	—	Engine running	Battery voltage
					Engine stopped	0V

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

Terminal	Wire color	Signal name	Signal input/output	Measuring condition		Reference value (Approx.)
				Ignition switch	Operation or condition	
43	G	Wiper auto stop signal	Input	ON or START	Wiper switch OFF, LO, INT	Battery voltage
44	R	Daytime light relay control	Input	ON	Daytime light system active	0V
					Daytime light system inactive	Battery voltage
45	LG	Horn relay control	Input	ON	When door locks are operated using keyfob or Intelligent Key (if equipped) (OFF → ON)*	Battery voltage → 0V
46	V	Fuel pump relay control	Input	—	Ignition switch ON or START	0V
					Ignition switch OFF or ACC	Battery voltage
47	O	Throttle control motor relay control	Input	—	Ignition switch ON or START	0V
					Ignition switch OFF or ACC	Battery voltage
48	R	Starter relay (range switch)	Input	ON or START	Selector lever in "P" or "N"	0V
					Selector lever any other position	Battery voltage
49	GR	Front RH parking and front side marker lamp	Output	OFF	Lighting switch 1st position	0V
					ON	Battery voltage
50	W	Front fog lamp (LH)	Output	ON or START	Lighting switch must be in the 2nd position (LOW beam is ON) and the front fog lamp switch	0V
					ON	Battery voltage
51	V	Front fog lamp (RH)	Output	ON or START	Lighting switch must be in the 2nd position (LOW beam is ON) and the front fog lamp switch	0V
					ON	Battery voltage
52	P	LH low beam head-lamp	Output	—	Lighting switch in 2nd position	Battery voltage
54	R	RH low beam head-lamp	Output	—	Lighting switch in 2nd position	Battery voltage
55	G	LH high beam head-lamp	Output	—	Lighting switch in 2nd position and placed in HIGH or PASS position	Battery voltage
56	L	RH high beam head-lamp	Output	—	Lighting switch in 2nd position and placed in HIGH or PASS position	Battery voltage
57	GR	Parking, license, and tail lamp	Output	ON	Lighting switch 1st position	0V
					ON	Battery voltage
59	B	Ground	Input	—	—	0V
60	GR	Rear window defogger relay	Output	ON or START	Rear defogger switch ON	Battery voltage
					Rear defogger switch OFF	0V
61	R/B	Fuse 32	Output	OFF	—	Battery voltage

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

*: When horn reminder is ON

Fail Safe

INFOID:0000000007827536

CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

Control part	Fail-safe in operation
Cooling fan	<ul style="list-style-type: none">Turns ON the cooling fan relay when the ignition switch is turned ONTurns OFF the cooling fan relay when the ignition switch is turned OFF

If No CAN Communication Is Available With BCM

Control part	Fail-safe in operation
Headlamp	<ul style="list-style-type: none">Turns ON the headlamp low relay when the ignition switch is turned ONTurns OFF the headlamp low relay when the ignition switch is turned OFFHeadlamp high relay OFF
• Parking lamps • License plate lamps • Tail lamps	<ul style="list-style-type: none">Turns ON the tail lamp relay when the ignition switch is turned ONTurns OFF the tail lamp relay when the ignition switch is turned OFF
Front wiper	<ul style="list-style-type: none">The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the INT mode and the front wiper motor is operating.
Rear window defogger	Rear window defogger relay OFF
A/C compressor	A/C relay OFF
Front fog lamps (if equipped)	Front fog lamp relay OFF

IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Ignition switch	Ignition relay	Tail lamp relay
ON	ON	—
OFF	OFF	—

NOTE:

The tail lamp turns OFF when the ignition switch is turned ON.

FRONT WIPER CONTROL

IPDM E/R detects front wiper stop position by a front wiper auto stop signal.

When a front wiper auto stop signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 second activation and 20 second stop five times.

Ignition switch	Front wiper switch	Auto stop signal
ON	OFF	Front wiper stop position signal cannot be input 10 seconds.
	ON	The signal does not change for 10 seconds.

NOTE:

This operation status can be confirmed on the IPDM E/R “DATA MONITOR” that displays “Block” for the item “WIP PROT” while the wiper is stopped.

IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

< ECU DIAGNOSIS INFORMATION >

STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

DTC Index

INFOID:000000007827537

CONSULT display	Fail-safe	TIME ^{NOTE}	Refer to
No DTC is detected. further testing may be required.	—	—	—
U1000: CAN COMM CIRCUIT	×	CRNT	1 – 39 PCS-13

NOTE:

The details of TIME display are as follows.

- CRNT: The malfunctions that are detected now
- 1 - 39: The number is indicated when it is normal at present and a malfunction was detected in the past. It increases like 0 → 1 → 2 ⋯ 38 → 39 after returning to the normal condition whenever IGN OFF → ON. It is fixed to 39 until the self-diagnosis results are erased if it is over 39. It returns to 0 when a malfunction is detected again in the process.

HEADLAMP


< WIRING DIAGRAM >

WIRING DIAGRAM

HEADLAMP

Wiring Diagram

INFOID:000000007355176




HEADLAMP

< WIRING DIAGRAM >

HEADLAMP CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



H.S.

Terminal No.	Color of Wire	Signal Name
5P	W/G	—
8P	R/Y	—
15P	W/R	—


Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



H.S.

Terminal No.	Color of Wire	Signal Name
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




H.S.

ABLIA0398GB

HEADLAMP

< WIRING DIAGRAM >


Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R/Y	BATTERY
11	P	CAN-L
12	L	CAN-H
13	GR	GROUND
16	W/G	RUN START
23	B	POWER GND

Terminal No.	Color of Wire	Signal Name
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5
9	SB	OUTPUT 4
10	V	OUTPUT 3

Connector No.	M167
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	W	-


ABLIA3340GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
O
P

HEADLAMP


< WIRING DIAGRAM >

Connector No.	E11
Connector Name	FRONT HEADLAMP LH (WITHOUT DAYTIME LIGHT SYSTEM)
Connector Color	BLACK
	



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Terminal No.	Color of Wire	Signal Name
1	G	-
2	B	-
3	P	-




Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-
3	R	-



Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)



Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L




DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

DAYTIME LIGHT SYSTEM

Wiring Diagram


INFOID:0000000007355177



ABLWA1603GB

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >




ABLWA1633GB

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

DAYTIME LIGHT SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




H.S.

Terminal No.	Color of Wire	Signal Name
5P	W/G	—
8P	R/Y	—
15P	W/R	—

Terminal No.	Color of Wire	Signal Name
7	W	—

WIRE TO WIRE

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



H.S.


Connector No.	M18
Connector Name	BCM (BODY MODULE)
Connector Color	WHITE



H.S.

Terminal No.	Color of Wire	Signal Name
6	R	INPUT 1
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



H.S.

Terminal No.	Color of Wire	Signal Name
67	B	GND (POWER)
70	W	BAT (F/L)


ABLIA0401GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
P


DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >





Terminal No.	Color of Wire	Signal Name
9	SB	OUTPUT 4
10	V	OUTPUT 3



Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5




ABLT A2802GP


DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E6
Connector Name	FRONT HEADLAMP LH (WITH DAYTIME LIGHT SYSTEM)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	G	-
2	B	-
3	SB	-

Terminal No.	Color of Wire	Signal Name
7	W	-




Connector No.	E40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	P	-

Connector No.	M167
Connector Name	JOINT CONNECTOR M02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
6	L	-
7	L	-
9	L	-
10	P	-
12	P	-
13	P	-

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
10	P	-
11	L	-

ABLIA3342GB

A B C D E F G H I J K L M N O P EXL

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

Connector No.	E104
Connector Name	DAYTIME LIGHT RELAY 2
Connector Color	BLUE



Connector No.	E103
Connector Name	DAYTIME LIGHT RELAY 1
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	R	-
2	R/B	-
3	B	-
4	GR	-
5	R/B	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-
3	SB	-
5	P	-

Terminal No.	Color of Wire	Signal Name
42	41	40
43	47	39
44	46	38
45	45	37



Connector No.	E107
Connector Name	FRONT HEADLAMP RH
Connector Color	BLACK



Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	R/B	DTRL RLY SUPPLY
2	B	-
3	R	-

ABLIA3343GB

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >


Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
52	P	H/LAMP LO LH
54	R	H/LAMP LO RH
55	G	H/LAMP HI LH
56	L	H/LAMP HI RH




Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)




Connector No.	E201
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
8	P	-



Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABLIA334GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
Z
M
O
P

DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

Connector No.	E211
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Connector No.	E209
Connector Name	GENERATOR
Connector Color	-



Connector No.	E205
Connector Name	GENERATOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	P	L
5	B	E

Terminal No.	Color of Wire	Signal Name
1	P	-
		-

ABLIA3345GB


AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

AUTO LIGHT SYSTEM

Wiring Diagram

INFOID:000000007355178




AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


AUTO LIGHT SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
15P	W/R	-


Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4

ABLIA3346GB

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
12	LG	DOOR SW (AS)
13	L	DOOR SW (RR)
18	BR	KEYLESS AND AUTO LIGHT SENSOR GND
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L


AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


Terminal No.	Color of Wire	Signal Name
9	SB	OUTPUT 4
10	V	OUTPUT 3

A

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
58	W	AUTO LIGHT SENSOR INPUT 2
67	B	GND (POWER)
70	W	BAT (F/L)



Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5

B

C

D

E

F

G

H

I

K

EXL

M


Z

O

P

Terminal No.	Color of Wire	Signal Name
57M	LG	-
58M	L	-

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABLIA0408GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
60J	P	-
61J	GR	-
66J	P	-

Terminal No.	Color of Wire	Signal Name
7	6	5
16	5	4
15	4	3
14	3	2
13	2	1
12	11	-
11	10	-
10	9	-




Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-




Connector No.	M145
Connector Name	OPTICAL SENSOR
Connector Color	BLACK



6	L	-
9	L	-
10	P	-



1	2	3
2	3	4
3	4	5
4	5	6
5	6	7
6	7	8
7	8	9
8	9	10
9	10	11
10	11	12
11	12	13
12	13	14
13	14	15
14	15	16
15	16	17
16	17	18
17	18	19
18	19	20




7	W	-
10	P	-
13	P	-

ABLIA3347GB


AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
52	P	H/LAMP LO LH
54	R	H/LAMP LO RH
55	G	H/LAMP HI LH
56	L	H/LAMP HI RH

Terminal No.	Color of Wire	Signal Name
18	—	—
20	—	—
21	—	—
22	—	—



Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	P	—
11	L	—

Terminal No.	Color of Wire	Signal Name
8	—	—
9	—	—
10	—	—



Terminal No.	Color of Wire	Signal Name
38	B	FRONT DOOR SWITCH LH
39	—	WHITE



Terminal No.	Color of Wire	Signal Name
2	P	—

Terminal No.	Color of Wire	Signal Name
2	GR	—
59	B	GND (POWER)

Terminal No.	Color of Wire	Signal Name
57	GR	TAIL LAMP
59	B	GND (POWER)

A B C D E F G H I J K L M N O P EXL Z M O P


ABLIA3348GB

AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


Terminal No.	Color of Wire	Signal Name
60J	P	-
61J	GR	-
66J	P	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	P	-

Terminal No.	Color of Wire	Signal Name
2	LG	-



Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	L	-




Terminal No.	Color of Wire	Signal Name
2	L	-

ABLIA3349GB


AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
57M	LG	-
58M	L	-



Terminal No.	Color of Wire	Signal Name
4	P	-




Terminal No.	Color of Wire	Signal Name
4	P	-




Terminal No.	Color of Wire	Signal Name
4	P	-




Terminal No.	Color of Wire	Signal Name
4	P	-



Terminal No.	Color of Wire	Signal Name
4	P	-



Terminal No.	Color of Wire	Signal Name
1	B	-



A

B

C

D

E

F

G

H

I

K

EXL

M

Z

O


P

ABLIA3350GB


AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

Connector No.	D502
Connector Name	BACK DOOR LATCH
Connector Color	WHITE



Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	-	-

Terminal No.	Color of Wire	Signal Name
3	P	-
4	BR	-

ABLIA3351GB


FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

FRONT FOG LAMP SYSTEM

Wiring Diagram

INFOID:000000007355179




FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >


FRONT FOG LAMP CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
15P	W/R	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	W	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
67	B	GND (POWER)
70	W	BAT (F/L)

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4

ABLIA0413GB

FRONT FOG LAMP SYSTEM


< WIRING DIAGRAM >

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5

Terminal No.	Color of Wire	Signal Name
9	SB	OUTPUT 4
10	V	OUTPUT 3




Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-




Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-



Terminal No.	Color of Wire	Signal Name
7	W	-
10	P	-
13	P	-



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
M
Z
O
P

ABLIA3352GB

FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

Connector No.	E102
Connector Name	FRONT FOG LAMP RH
Connector Color	BLACK




Connector No.	E101
Connector Name	FRONT FOG LAMP LH
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name	Color of Wire	Signal Name
1	W	-	V	-
2	B	-	B	-

Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L

Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
59	B	GND (POWER)
50	W	FR FOG LAMP LH
51	V	FR FOG LAMP RH

ABLIA3353GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM


< WIRING DIAGRAM >

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

Wiring Diagram

INFOID:0000000007355180

TURN SIGNAL AND HAZARD WARNING LAMPS





ABLWA1606GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

TURN SIGNAL AND HAZARD WARNING LAMPS CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5P	W/G	—
8P	R/Y	—
15P	W/R	—

Terminal No.	Color of Wire	Signal Name
7	W	—

Connector No.	M18	Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)	Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE	Connector Color	BLACK
Terminal No.	Color of Wire	Signal Name	Signal Name
6	R	INPUT 1	IGN SW
29	G	HAZARD SW	CAN-H
32	O	OUTPUT 5	CAN-L
33	GR	OUTPUT 4	IGN SW
34	G	OUTPUT 3	W/R
35	BR	OUTPUT 2	V/R
36	LG	OUTPUT 1	P
38	W/R		
39	L		
40	P		
Terminal No.	Color of Wire	Signal Name	Signal Name
2	P	INPUT 5	FLASHER OUTPUT (LEFT)
3	SB	INPUT 4	FLASHER OUTPUT (RIGHT)
4	V	INPUT 3	GND (POWER)
5	L	INPUT 2	BAT (F/L)

ABLIA1676GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
9	SB	OUTPUT 4
10	V	OUTPUT 3

A

B

C

D

E

F

G

H

I

J

K

EXL



M

N

O

P

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R/Y	BATTERY
11	P	CAN-L
12	L	CAN-H
13	GR	GROUND
16	W/G	RUN START
23	B	POWER GND

Terminal No.	Color of Wire	Signal Name
1	LG	INPUT 1
2	BR	INPUT 2
3	G	INPUT 3
4	GR	INPUT 4
5	O	INPUT 5
6	R	OUTPUT 1
7	L	OUTPUT 2
8	P	OUTPUT 5

Terminal No.	Color of Wire	Signal Name
53G	G	-


Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABLIA2809GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >



ABLIA3354GB

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

Connector No.	E111
Connector Name	FRONT COMBINATION
Connector Color	LAMP RH



Connector No.	E27
Connector Name	FRONT COMBINATION
Connector Color	LAMP LH



Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-
3	LG	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-
3	LG	-



Terminal No.	Color of Wire	Signal Name
1	B	-
2	GR	-
3	G	-

Terminal No.	Color of Wire	Signal Name
1	GR	-
2	G	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	GR	-
3	G	-



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	G	-




ABLIA335GB

A B C D E F G H I J K M O P EXL


TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >


Connector No.	B105
Connector Name	REAR COMBINATION LAMP
Connector Color	RH WHITE



Terminal No.	Color of Wire	Signal Name
59J	G	-




Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
59M	G	-
	B	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	G	-
5	B	-


Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

Wiring Diagram



PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

PARKING, LICENSE PLATE AND TAIL LAMPS CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
15P	W/R	-




Terminal No.	Color of Wire	Signal Name
7	W	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	R	INPUT 1
32	O	OUTPUT 5
33	GR	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L




Terminal No.	Color of Wire	Signal Name
2	P	INPUT 5
3	SB	INPUT 4
4	V	INPUT 3
5	L	INPUT 2

PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4M	V	-
49G	V	-
49G	V	-
49G	V	-

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	W	-

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
49G	V	-

Connector No.	M167
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-
10	P	-
13	P	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL


PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

Connector No.	E27
Connector Name	FRONT COMBINATION LAMP LH
Connector Color	GRAY



Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E17
Connector Name	FRONT SIDE MARKER LAMP LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
10	P	-
11	L	-

Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-
3	LG	-



Connector No.	E108
Connector Name	FRONT SIDE MARKER LAMP RH
Connector Color	GRAY



Connector No.	E34
Connector Name	WIRE TC WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
2	GR	-
3	G	-

Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-


PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

Connector No.	E123
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Connector No.	E122
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
38	B	GND (SIGNAL)
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
49	GR	ILLUMINATION


Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E124
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
57	GR	TAIL LAMP
59	B	GND (POWER)




ABLIA3359GB


PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


Connector No.	B105
Connector Name	REAR COMBINATION
Connector Color	WHITE



Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B35
Connector Name	REAR COMBINATION
Connector Color	LAMP LH




Terminal No.	Color of Wire	Signal Name
4	GR	—
5	B	—


Terminal No.	Color of Wire	Signal Name
1	GR	—
5	B	—

Terminal No.	Color of Wire	Signal Name
1	V	—
5	B	—

Terminal No.	Color of Wire	Signal Name
4M	V	—
5	B	—



Terminal No.	Color of Wire	Signal Name
4	L	—
5	—	—




PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

Connector No.	D506
Connector Name	LICENSE PLATE LAMP LH
Connector Color	BROWN




Connector No.	D451
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
2	B	-

Connector No.	D450
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
4	L	-

Connector No.	D507
Connector Name	LICENSE PLATE LAMP RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-

Connector No.	D550
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
4	L	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-

A

B

C

D

E

F

G

H

I

K

EXL

M

N

O

P

ABLIA3361GB

STOP LAMP


< WIRING DIAGRAM >

STOP LAMP

Wiring Diagram

INFOID:0000000007355182

: WITH VK56DE
 : WITH VQ40DE



STOP LAMP

ABLWA1608GB

STOP LAMP



< WIRING DIAGRAM >

STOP LAMP CONNECTORS

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Connector No.	E12
Connector Name	STOP LAMP RELAY
Connector Color	BLUE




ABLIA1678GB


STOP LAMP

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
35	V	BRK OUT (OFF)
41	SB	STOP LAMP SW



Connector No.	E125		
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) (WITH VQ40DE)		
Connector Color	BLACK		
	Color of Wire	Signal Name	
39	SB	STOP LAMP SW	




Terminal No.	Color of Wire	Signal Name
39	SB	STOP LAMP SW

Terminal No.	Color of Wire	Signal Name
35	V	BRK OUT (OFF)
41	SB	STOP LAMP SW




Terminal No.	Color of Wire	Signal Name
8Q	R/B	-




STOP LAMP

< WIRING DIAGRAM >


Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B35
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE




Connector No.	B105
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	Y	-
5	B	-

Terminal No.	Color of Wire	Signal Name
7	R	-

Terminal No.	Color of Wire	Signal Name
7	R	-



Terminal No.	Color of Wire	Signal Name
3M	L	-


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

ABLIA0430GB


STOP LAMP

< WIRING DIAGRAM >


Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D408
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D404
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	-	-

Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

ABLIA0431GB

BACK-UP LAMP


< WIRING DIAGRAM >

BACK-UP LAMP

Wiring Diagram

INFOID:0000000007355183

BACK-UP LAMP



* : THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

ABLWA1202GB

BACK-UP LAMP


< WIRING DIAGRAM >

BACK-UP LAMP CONNECTORS


Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Connector No.	M36
Connector Name	WIRE TO WIRE
Connector Color	WHITE


Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
54G	SB	—




Terminal No.	Color of Wire	Signal Name
56M	BR	—




Terminal No.	Color of Wire	Signal Name
58J	SB	—



Terminal No.	Color of Wire	Signal Name
75J	7M	—



Terminal No.	Color of Wire	Signal Name
75J	7M	—



Terminal No.	Color of Wire	Signal Name
16	W/G	REVERSE LAMP

BACK-UP LAMP

< WIRING DIAGRAM >

Connector No.	F9
Connector Name	A/T ASSEMBLY
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
7	LG	-

5 4 3 2 1
10 9 8 7 6


Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
54G	SB	-


1G	2G	3G	4G	5G	6G	7G	8G	9G	20G	21G
2G										
3G										
4G										
5G										
6G										
7G										
8G	7G									
9G	8G									
20G	19G	18G	17G	16G	15G	14G	13G	12G	11G	10G
21G	20G	19G	18G	17G	16G	15G	14G	13G	12G	11G

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
7	LG	-

5 4 3 2 1
10 9 8 7 6



Terminal No.	Color of Wire	Signal Name
54G	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
3	SB	-

5 4 3 2 1
10 9 8 7 6

Terminal No.	Color of Wire	Signal Name
5	B	-

5 4 3 2 1
10 9 8 7 6


Terminal No.	Color of Wire	Signal Name

<tbl_r cells="3" ix="1" maxcspan="1" maxrspan="1" used

BACK-UP LAMP


< WIRING DIAGRAM >

Connector No.	B105
Connector Name	REAR COMBINATION LAMP
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
58J	SB	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
3	BR	-
5	B	-



Terminal No.	Color of Wire	Signal Name
56M	BR	-

Connector No.	B149
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABLIA1680GB


TRAILER TOW

< WIRING DIAGRAM >

TRAILER TOW

Wiring Diagram


INFOID:0000000007355184



A B C D E F G H I J K L M N O P Q R S EXL

TRAILER TOW

< WIRING DIAGRAM >




ABLWA1610GB

TRAILER TOW


< WIRING DIAGRAM >

TRAILER TOW CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5P	W/G	—
8P	R/Y	—
15P	W/R	—

Terminal No.	Color of Wire	Signal Name
7	W	—




Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	V	INPUT 3
5	L	INPUT 2
6	R	INPUT 1
32	O	OUTPUT 5
33	G/R	OUTPUT 4
34	G	OUTPUT 3
35	BR	OUTPUT 2
36	LG	OUTPUT 1
38	W/R	IGN SW
39	L	CAN-H
40	P	CAN-L

Connector No.	M19
Connector Name	ECM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
51	O	TRAILER FLASHER OUTPUT (RIGHT)
52	LG	TRAILER FLASHER OUTPUT (LEFT)

EXL M Z O P K M Z O P EXL A B C D E F G H I J K L

TRAILER TOW

< WIRING DIAGRAM >

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
3	R/Y	BATTERY	11	P	CAN-L
12	L	CAN-H	13	GR	GROUND
16	W/G	FUN START	23	B	POWER GND
33	LG	BRAKE PEDAL SW	9	SB	OUTPUT 4
			10	V	OUTPUT 3

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
2	BR	INPUT 2	3	G	INPUT 3
4	GR	INPUT 4	5	O	INPUT 5
6	R	OUTPUT 1	7	L	OUTPUT 2
8	P	OUTPUT 5	9	SB	OUTPUT 4
10	V	OUTPUT 3			

Terminal No.	Color of Wire	Signal Name	Terminal No.	Color of Wire	Signal Name
1G	O	-	2G	BR	-
31G	O	-	32G	LG	-
49G	V	-	50G	L	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




ABLIA2805GB


TRAILER TOW

< WIRING DIAGRAM >

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M167
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
6	L	—
7	L	—
9	L	—
10	P	—
12	P	—
13	P	—

Terminal No.	Color of Wire	Signal Name
10	P	—
11	L	—

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/B	—
2	Y	—

Terminal No.	Color of Wire	Signal Name
10	P	—
11	L	—

Connector No.	E38
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R/B	—
2	Y	—

Terminal No.	Color of Wire	Signal Name
10	P	—
11	L	—


ABLIA3362GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
EXL
M
Z
O
P

TRAILER TOW

< WIRING DIAGRAM >


Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
19C	V	-
20C	B	-
21C	R	-
22C	BR	-

H.S.

Terminal No.	Color of Wire	Signal Name
19C	V	-
20C	B	-
21C	R	-
22C	BR	-



H.S.

Terminal No.	Color of Wire	Signal Name
2C	G	-
3C	V	-
4C	Y	-

Connector No.	E41
Connector Name	WIRE TO WIRE
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
27	W/G	TTOW REV LAMP
29	G	TRAILER RLY CONT



Terminal No.	Color of Wire	Signal Name
27	W/G	TTOW REV LAMP
29	G	TRAILER RLY CONT



Terminal No.	Color of Wire	Signal Name
1	W/G	-
2	B	-



Terminal No.	Color of Wire	Signal Name
1	W/G	-
2	B	-
3	GR	-
5	V	-
6	Y	-
7	V	-

Terminal No.	Color of Wire	Signal Name
57	GR	TAIL LAMP
59	B	GND (POWER)
61	R/B	TRAIL RLY SUPPLY




ABLIA3363GB

TRAILER TOW

< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
1G	O	-
2G	BR	-
31G	O	-
32G	LG	-
49G	V	-
50G	L	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	B	-
3	R/B	-
5	R	-




Terminal No.	Color of Wire	Signal Name
1	O	-
2	B	-
3	V	-
5	L	-



Connector No.	E163
Connector Name	TRAILER TURN RELAY LH
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	B	-
3	V	-





Terminal No.	Color of Wire	Signal Name
1	O	-
2	B	-
3	G	-
5	L	-

ABLIA3364GB

TRAILER TOW


< WIRING DIAGRAM >




TRAILER TOW

< WIRING DIAGRAM >

Connector No.	C128
Connector Name	TRAILER (TRAILER TOW 4 PIN)
Connector Color	BLACK




Connector No.	C126
Connector Name	TRAILER (TRAILER TOW 7 PIN)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
2	V	-
3	BR	-
4	L	-
5	G	-
6	R	-
7	B	-

Terminal No.	Color of Wire	Signal Name
2	W	-
3	G	-
4	V	-
7	B	-
8	BR	-

Connector No.	C125
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	G	-
3	BR	-
4	W	-



Terminal No.	Color of Wire	Signal Name
1	R	-
2	L	-

Terminal No.	Color of Wire	Signal Name
1	-	STOP/TURN LH
2	-	GROUND
3	-	ELECTRIC BRAKE
4	-	STOP/TURN RH
5	-	BATTERY
6	-	RUNNING LAMPS
7	-	BACK-UP LAMPS



Connector No.	C129
Connector Name	TRAILER RECEPTACLE
Connector Color	BLACK

A B C D E F G H I J K M Z O P EXL

ABLIA4024GB

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

EXTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:0000000007355185

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp does not switch to the high beam.	One side	<ul style="list-style-type: none"> Fuse Harness between IPDM E/R and the front headlamp Front headlamp IPDM E/R 	Headlamp (HI) circuit Refer to EXL-38 .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM" Refer to EXL-135 .	
High beam indicator lamp is not turned ON. (Headlamp switches to the high beam.)		<ul style="list-style-type: none"> Combination meter BCM 	<ul style="list-style-type: none"> Combination meter. Data monitor "HI-BEAM IND" BCM (HEAD LAMP) Active test "HEADLAMP"
Headlamp does not switch to the low beam.	One side	<ul style="list-style-type: none"> Daytime light relay 2 Harness between IPDM, daytime light relay 2 and front combination lamp LH. Front combination lamp (Low beam) 	Headlamp (LO) circuit Refer to EXL-44 .
	Both sides	<ul style="list-style-type: none"> Combination switch (lighting and turn signal switch) Harness between the combination switch (lighting and turn signal switch) and BCM BCM 	Combination switch (lighting and turn signal switch) Refer to BCS-8 .
		High beam request signal	IPDM E/R Data monitor "HL HI REQ"
		IPDM E/R	—
Headlamp does not turn ON.	One side	<ul style="list-style-type: none"> Fuse Bulb Harness between IPDM E/R and the front headlamp Front headlamp IPDM E/R 	Headlamp (LO) circuit Refer to EXL-41 .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to EXL-137 .	
Headlamp does not turn OFF.	When the ignition switch is turned ON	<ul style="list-style-type: none"> BCM Combination switch (lighting and turn signal switch) 	Combination switch (lighting and turn signal switch) Refer to BCS-8 .
	The ignition switch is turned OFF (After activating the battery saver).	IPDM E/R	—

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

Symptom	Possible cause	Inspection item
Headlamp is not turned ON/OFF with the lighting switch AUTO.	<ul style="list-style-type: none"> Combination switch (lighting and turn signal switch) Harness between the combination switch (lighting and turn signal switch) and BCM BCM 	Combination switch (lighting and turn signal switch) Refer to BCS-8 .
	<ul style="list-style-type: none"> Optical sensor Harness between the optical sensor and BCM BCM 	Optical sensor Refer to EXL-57 .
Daytime light system does not activate.	<ul style="list-style-type: none"> Either high beam bulb Parking brake switch Combination switch (lighting and turn signal switch) BCM IPDM E/R Daytime light relay Harness between IPDM E/R and daytime light relay. 	Daytime light system description. Refer to EXL-9, "System Description" .
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> Front fog lamp bulb Harness between IPDM E/R and the front fog lamp IPDM E/R
	Both side	Symptom diagnosis "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to EXL-139 .
Parking lamp is not turned ON.	One side	<ul style="list-style-type: none"> Fuse Parking lamp bulb Harness between IPDM E/R and the front/rear combination lamp Front/rear combination lamp IPDM E/R
	Both sides	Symptom diagnosis "PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to EXL-138 .
Turn signal lamp does not blink. Turn signal indicator lamp does not blink.	Indicator lamp is normal. (The applicable side performs the high flasher activation.)	<ul style="list-style-type: none"> Harness between BCM and each turn signal lamp Turn signal lamp bulb Door mirror (if equipped with turn signals in the door mirrors)
Turn signal indicator lamp does not blink.	One side	Combination meter
	Both sides (Always)	<ul style="list-style-type: none"> Turn signal indicator lamp signal Combination meter BCM
	Both sides (Does blink when activating the hazard warning lamp with the ignition switch OFF)	<ul style="list-style-type: none"> The combination meter power supply and the ground circuit Combination meter

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:0000000007355186

AUTO LIGHT SYSTEM

The auto light system may not turn the headlamp ON/OFF immediately after passing a dark area or a bright area (short tunnel, sky bridge, shadowed area etc.). This is normal.

BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

< SYMPTOM DIAGNOSIS >

BOTH SIDE HEADLAMPS DO NOT SWITCH TO HIGH BEAM

Description

INFOID:000000007355187

The headlamps (both sides) do not switch to high beam when the lighting switch is in the HI or PASS setting.

Diagnosis Procedure

INFOID:000000007355188

1. COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-8, "System Description"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning part.

2. CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

WITH CONSULT DATA MONITOR

1. Select "HL HI REQ" of IPDM E/R DATA MONITOR item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2ND)	HI or PASS	ON
		Except for HI or PASS	OFF

Is the monitor item status normal?

YES >> GO TO 3

NO >> Replace BCM. Refer to [BCS-53, "Removal and Installation"](#).

3. HEADLAMP (HI) CIRCUIT INSPECTION

Check the headlamp (HI) circuit. Refer to [EXL-38, "Description"](#).

Is the headlamp (HI) circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

DAYTIME LIGHT SYSTEM INOPERATIVE

< SYMPTOM DIAGNOSIS >

DAYTIME LIGHT SYSTEM INOPERATIVE

Description

INFOID:0000000007355189

The daytime light system is inoperative even though the combination switch (lighting and turn signal switch) and parking brake switch are in the normal setting, also whenever engine is operating.

Diagnosis Procedure

INFOID:0000000007355190

NOTE:

Before performing the diagnosis, check that the following is normal.

- High beam lamp function
- Parking brake warning lamp
- Engine operation status

1. COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-50, "Symptom Table"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2. CHECK DAYTIME LIGHT REQUEST SIGNAL INPUT

(B) WITH CONSULT DATA MONITOR

1. Parking brake switch is released.
2. Start engine.
3. Select "DTRL REQ" of IPDM E/R DATA MONITOR item.
4. While operating the combination switch (lighting and turn signal switch), check the monitor status.

Monitor item	Condition	Monitor status
DTRL REQ	combination switch (lighting and turn signal switch)	1ST or OFF
		Except for 1ST or OFF

Is the item status normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-53, "Removal and Installation"](#).

3. DAYTIME LIGHT RELAY CIRCUIT INSPECTION

Check the daytime light relay circuit. Refer to [EXL-45, "Diagnosis Procedure"](#).

Is the daytime light relay circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

Description

INFOID:0000000007355191

The headlamps (both sides) do not turn ON in any lighting switch setting.

Diagnosis Procedure

INFOID:0000000007355192

1. CHECK COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWTICH)

Check the combination switch (lighting and turn signal switch). Refer to [BCS-8, "System Description"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning part.

2. CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

 WITH CONSULT DATA MONITOR

1. Select "HL LO REQ" of IPDM E/R DATA MONITOR item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL LO REQ	Lighting switch	2ND	ON
		OFF	OFF

Is the monitor item status normal?

YES >> GO TO 3

NO >> Replace BCM. Refer to [BCS-53, "Removal and Installation"](#).

3. HEADLAMP (LO) CIRCUIT INSPECTION

Check the headlamp (LO) circuit. Refer to [EXL-41, "Description"](#).

Is the headlamp (LO) circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

PARKING, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON

Description

INFOID:0000000007355193

The parking, license plate and tail lamps do not turn ON in with any lighting switch setting.

Diagnosis Procedure

INFOID:0000000007355194

1. COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-8, "System Description"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning part.

2. CHECK TAIL LAMP RELAY REQUEST SIGNAL INPUT

 WITH CONSULT DATA MONITOR

1. Select "TAIL&CLR REQ" of IPDM E/R DATA MONITOR item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
TAIL&CLR REQ	Lighting switch	1ST	ON
		OFF	OFF

Is the monitor item status normal?

YES >> GO TO 3

NO >> Replace BCM. Refer to [BCS-53, "Removal and Installation"](#).

3. PARK LAMP CIRCUIT INSPECTION

Check the parking lamp circuit. Refer to [EXL-49, "Description"](#).

Is the tail lamp circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

Description

INFOID:000000007355195

The front fog lamps do not turn ON in any setting.

Diagnosis Procedure

INFOID:000000007355196

1. COMBINATION SWITCH (LIGHTING AND TURN SIGNAL SWITCH) INSPECTION

Check the combination switch (lighting and turn signal switch). Refer to [BCS-8, "System Description"](#).

Is the combination switch (lighting and turn signal switch) normal?

YES >> GO TO 2

NO >> Repair or replace the malfunctioning part.

2. CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

 WITH CONSULT DATA MONITOR

1. Select "FR FOG REQ" of IPDM E/R DATA MONITOR item.
2. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition	Monitor status	
FR FOG REQ	Front fog lamp switch (Lighting switch 2ND)	ON	ON
		OFF	OFF

Is the monitor item status normal?

YES >> GO TO 3

NO >> Replace BCM. Refer to [BCS-53, "Removal and Installation"](#).

3. FRONT FOG LAMP CIRCUIT INSPECTION

Check the front fog lamp circuit. Refer to [EXL-47, "Description"](#).

Is the front fog lamp circuit normal?

YES >> Replace IPDM E/R. Refer to [PCS-29, "Removal and Installation of IPDM E/R"](#).

NO >> Repair or replace the malfunctioning part.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000007355197

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution Necessary for Steering Wheel Rotation After Battery Disconnect

INFOID:0000000007355198

NOTE:

- This Procedure is applied only to models with Intelligent Key system and NATS (NISSAN ANTI-THEFT SYSTEM).
- Remove and install all control units after disconnecting both battery cables with the ignition knob in the "LOCK" position.
- Always use CONSULT to perform self-diagnosis as a part of each function inspection after finishing work. If DTC is detected, perform trouble diagnosis according to self-diagnostic results.

For models equipped with the Intelligent Key system and NATS, an electrically controlled steering lock mechanism is adopted on the key cylinder.

For this reason, if the battery is disconnected or if the battery is discharged, the steering wheel will lock and steering wheel rotation will become impossible.

If steering wheel rotation is required when battery power is interrupted, follow the procedure below before starting the repair operation.

OPERATION PROCEDURE

1. Connect both battery cables.

NOTE:

Supply power using jumper cables if battery is discharged.

2. Use the Intelligent Key or mechanical key to turn the ignition switch to the "ACC" position. At this time, the steering lock will be released.
3. Disconnect both battery cables. The steering lock will remain released and the steering wheel can be rotated.
4. Perform the necessary repair operation.

PRECAUTIONS

< PRECAUTION >

5. When the repair work is completed, return the ignition switch to the "LOCK" position before connecting the battery cables. (At this time, the steering lock mechanism will engage.)
6. Perform a self-diagnosis check of all control units using CONSULT.

A

Precaution for Work

INFOID:000000007355199

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components.
 - Water soluble dirt: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the dirty area.
Then rub with a soft and dry cloth.
 - Oily dirt: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the dirty area.
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol, or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

ADJUSTMENT AND INSPECTION

< PERIODIC MAINTENANCE >


PERIODIC MAINTENANCE

ADJUSTMENT AND INSPECTION

HEADLAMP

HEADLAMP : Aiming Adjustment

INFOID:0000000007355200




NOTE:

- For headlamp aiming details, refer to the regulations in your area.
- If vehicle front body has been repaired and /or the front combination lamp assembly has been removed or replaced, check headlamp aiming.
- Before performing aiming adjustment, check the following:
 - Confirm headlamp aiming switch is set to "0" (zero) position.
 - Ensure all tires are inflated to correct pressure.
 - Place vehicle and screen on level surface.
 - Ensure there is no load in vehicle other than the driver (or equivalent weight placed in driver's position). Coolant and engine oil filled to correct level, and fuel tank full.
 - Confirm spare tire, jack and tools are properly stowed.
 - Aim each headlamp individually and ensure other headlamp beam pattern is blocked from screen.
 - Use adjusting screw to perform aiming adjustment

LOW BEAM AND HIGH BEAM

ADJUSTMENT AND INSPECTION

< PERIODIC MAINTENANCE >



1	Adjustment screen	2	Headlamp bulb center (HV point)	A	Minimum acceptable vertical aim dimension (see aiming chart)
B	Maximum acceptable vertical aim dimension (see aiming chart)	C	H-V point	D	Distance of headlamp aiming screen from vehicle 7.62 m (25 ft.)
E	Maximum aim evaluation distance from vertical center on aiming screen 399mm (3° R).	F	Minimum aim evaluation distance from vertical center on aiming screen 133 mm (1°R)	G	Aim evaluation area
H	Horizontal aiming evaluation line.		↖ Right		

Aiming Chart

A (Minimum acceptable vertical aim dimension)	-3.3 mm (0.13 in)	0.025° up
B (Maximum acceptable vertical aim dimension)	36.6 mm (1.44 in)	0.275° down

EXL

NOTE:

- By regulation, no means for horizontal aim adjustment is provided from the factory; only vertical aim is adjustable.
- Basic illuminating area for evaluation and/or adjustment should be within range shown on aiming chart.

1. Use adjustment screw to perform aiming adjustment.

• **Cover the opposite lamp and ensure fog lamps (if equipped) are turned off.**

CAUTION:

Do not tighten adjustment screw beyond specified torque or damage may occur.

Adjustment torque **1.67 N·m (17 kg·cm, 14.8 in-lb)**

2. Adjust beam pattern until cut-off line (top edge of illumination area) is positioned at the specified height off ground. Measure cut-off line within distance J on H-line. See aiming chart.

FRONT FOG LAMP

FRONT FOG LAMP : Aiming Adjustment

INFOID:0000000007355201

The fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb. Before performing aiming adjustment, make sure of the following.

- Keep all tires inflated to correct pressure.

ADJUSTMENT AND INSPECTION


< PERIODIC MAINTENANCE >

- Place vehicle on level ground.
- See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver seat.


Adjust aiming in the vertical direction by turning the adjustment screw.

NOTE:


Use a Phillips screwdriver to adjust. Turn screw clockwise to raise pattern and counterclockwise to lower pattern.



1. Set the distance between the screen and the center of the fog lamp lens as shown.



2. Turn front fog lamps ON.
 3. Remove front portion of fender protector(s) for adjustment screw access. Refer to [EXT-25, "Removal and Installation of Front Fender Protector"](#)
 4. Adjust front fog lamps using adjustment screw so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown.
- When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.



HEADLAMP

< UNIT REMOVAL AND INSTALLATION >

UNIT REMOVAL AND INSTALLATION

HEADLAMP

Bulb Replacement

INFOID:000000007355202

A

CAUTION:

Leaving bulbs removed from the headlamp housing for a long period of time can deteriorate the performance of the lens and reflector (dirt, clouding). Always prepare a new bulb and have it on hand when replacing a bulb.

C

HEADLAMP

Removal

D

NOTE:

Reach through engine room for bulb replacement access.

E

1. Turn front headlamp switch OFF.
2. Disconnect the electrical connector.
3. Rotate the headlamp bulb retaining ring counterclockwise and remove.
4. Pull the headlamp bulb straight out from the headlamp assembly.

F

CAUTION:

Grasp only the plastic base when handling the bulb. Never touch the glass envelope.

G

Installation

H

Installation is in the reverse order of removal.

I

CAUTION:

After installing bulb, be sure to install the bulb socket and plastic cap securely to ensure watertightness.

J

FRONT TURN SIGNAL/PARKING LAMP

K

Removal

L

NOTE:

Reach through engine room for bulb replacement access.

M

1. Turn the bulb socket counterclockwise to unlock it.
2. Pull the bulb to remove it from the socket.

N

Installation

O

Installation is in the reverse order of removal.

P

CAUTION:

After installing the bulb, be sure to install the bulb socket securely for watertightness.

EXL

FRONT SIDE MARKER LAMP

Q

Removal

R

NOTE:

Reach through engine room for bulb replacement access.

S

1. Turn the bulb socket counterclockwise to unlock it.
2. Pull the bulb to remove it from the socket.

T

Installation

U

Installation is in the reverse order of removal.

V

CAUTION:

After installing the bulb, be sure to install the bulb socket securely for watertightness.

Removal and Installation

INFOID:000000007355203

W

FRONT COMBINATION LAMP

X

Removal

Y

1. Partially remove front portion of front fender protector. Refer to [EXT-25, "Removal and Installation of Front Fender Protector".](#)

Z

HEADLAMP

< UNIT REMOVAL AND INSTALLATION >

2. Remove the front bumper. Refer to [EXT-15, "Removal and Installation"](#).
3. Remove the front combination lamp bolts.
4. Disconnect the front combination lamp connector and remove front combination lamp.

Installation


Installation is in the reverse order of removal.

Front combination lamp bolts : 6.0 Nm (0.61 kg-m, 53 in-lb)

Disassembly and Assembly

INFOID:0000000007355204

FRONT COMBINATION LAMP



1. Headlamp assembly
2. Headlamp bulb
3. Headlamp bulb retaining ring
4. Wiring harness assembly
5. Front side marker lamp bulb
6. Front turn signal/parking lamp bulb
7. Headlamp bulb sealing ring

DISASSEMBLY

CAUTION:

Leaving bulb removed from the headlamp housing for a long period of time can deteriorate the performance of the lens and reflector (dirt, clouding). Always prepare a new bulb and have it on hand when replacing a bulb.

1. Rotate headlamp bulb retaining ring counterclockwise and remove.

CAUTION:

Grasp only the plastic base when handling headlamp bulb. Never touch the glass envelope.

2. Turn front turn signal/parking lamp bulb socket counterclockwise to unlock and remove socket.
3. Turn front side marker lamp bulb socket counterclockwise to unlock and remove socket.

ASSEMBLY

Installation is in the reverse order of removal.

CAUTION:

After installing bulb, be sure to install the bulb socket and plastic cap securely to ensure watertightness.

OPTICAL SENSOR

< UNIT REMOVAL AND INSTALLATION >

OPTICAL SENSOR

Removal and Installation

INFOID:000000007355205

REMOVAL

1. Remove the optical sensor and bezel from the center of the instrument panel.
2. Disconnect the optical sensor connector.
3. Remove the optical sensor from the bezel.

A

INSTALLATION

Installation is in the reverse order of removal.

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

FRONT FOG LAMP

< UNIT REMOVAL AND INSTALLATION >

FRONT FOG LAMP

Bulb Replacement

INFOID:0000000007355206


1. Partially remove the front portion of the front fender protector. Refer to [EXT-25, "Removal and Installation of Front Fender Protector"](#)
2. Disconnect fog lamp connector.
3. Turn the bulb counterclockwise to remove it.

WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from it.
- Do not leave bulb out of fog lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of fog lamp. When replacing bulb, be sure to replace it with new one.



Removal and Installation

INFOID:0000000007355207

FRONT FOG LAMP

The fog lamp is a semi-sealed beam type which uses a replaceable halogen bulb.

Removal


1. Partially remove the front portion of the front fender protector. Refer to [EXT-25, "Removal and Installation of Front Fender Protector"](#)
2. Disconnect fog lamp connector.
3. Remove fog lamp screws and pull fog lamp rearward out of front bumper.

WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from it.
- Do not leave bulb out of fog lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of fog lamp. When replacing bulb, be sure to replace it with new one.



Installation

Installation is in the reverse order of removal.

LIGHTING & TURN SIGNAL SWITCH

< UNIT REMOVAL AND INSTALLATION >


LIGHTING & TURN SIGNAL SWITCH

Removal and Installation

INFOID:0000000007355208

REMOVAL

1. Remove instrument lower panel (LH). Refer to [IP-11, "Exploded View"](#).
2. Remove steering column cover.
3. Disconnect the lighting and turn signal switch connector.
4. While pressing tabs, pull lighting and turn signal switch toward driver door and release from the steering column.



INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

HAZARD SWITCH

< UNIT REMOVAL AND INSTALLATION >

HAZARD SWITCH

Removal and Installation

INFOID:0000000007355209

REMOVAL

1. Remove cluster lid C. Refer to [IP-11, "Exploded View"](#).
2. Remove the screws and remove the hazard switch.

INSTALLATION

Installation is in the reverse order of removal.

HIGH-MOUNTED STOP LAMP

< UNIT REMOVAL AND INSTALLATION >

HIGH-MOUNTED STOP LAMP

High-Mounted Stop Lamp

INFOID:000000007355210


BULB REPLACEMENT

The high-mounted stop lamp bulbs are not serviceable.

REMOVAL AND INSTALLATION

Removal

1. Remove back door finisher and window garnish. Refer to [INT-27, "Removal and Installation"](#).
2. Disconnect high-mounted stop lamp connector.
3. Remove nuts and remove high-mounted stop lamp.



Installation

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

LICENSE PLATE LAMP

< UNIT REMOVAL AND INSTALLATION >

LICENSE PLATE LAMP

Bulb Replacement

INFOID:0000000007355211

LICENSE PLATE LAMP

Removal

1. Remove back door finisher. Refer to [EXT-23, "Removal and Installation"](#).
2. Turn bulb socket counterclockwise and remove bulb socket.
3. Remove license plate lamp bulb.

Installation

Installation is in the reverse order of removal.

Removal and Installation

INFOID:0000000007355212

LICENSE PLATE LAMP

Removal

1. Remove license lamp finisher. Refer to [EXT-23, "Removal and Installation"](#).
2. Disconnect license plate lamp harness connector.
3. Remove license plate lamp screw and remove license plate lamp.

Installation

Installation is in the reverse order of removal.

REAR COMBINATION LAMP

< UNIT REMOVAL AND INSTALLATION >


REAR COMBINATION LAMP

Bulb Replacement

INFOID:0000000007355213

REMOVAL

1. Remove rear combination lamp bolts.
2. Pull rear combination lamp to remove from the vehicle.
3. Turn bulb socket counterclockwise and unlock it.
4. Remove bulb.



INSTALLATION

Installation is in the reverse order of removal.

Removal and Installation

INFOID:0000000007355214

REMOVAL

1. Remove rear combination lamp bolts.
2. Pull rear combination lamp to remove from the vehicle.
3. Disconnect rear combination lamp connector.

INSTALLATION

Installation is in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

BULB SPECIFICATIONS

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

BULB SPECIFICATIONS

Headlamp

INFOID:000000007355215

Item	Wattage (W)*
Low/High	55/65

*: Always check with the Parts Department for the latest parts information.

Exterior Lamp

INFOID:000000007355216

Item	Wattage (W)*
Front combination lamp	Turn signal lamp/parking lamp
	Side marker
Rear combination lamp	Stop/Tail lamp
	Turn signal lamp
Back-up lamp	18
Front fog lamp	55
License plate lamp	5
High-mounted stop lamp	*

*: Always check with the Parts Department for the latest parts information.