

# SECTION CHG

## CHARGING SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

### CONTENTS

<b>PRECAUTION .....</b>	3	<b>CHARGING SYSTEM PRELIMINARY INSPECTION .....</b>	20
<b>PRECAUTIONS .....</b>	3	Diagnosis Procedure .....	20
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	<b>POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM OPERATION INSPECTION .....</b>	21
Precaution for Power Generation Voltage Variable Control System .....	3	Diagnosis Procedure .....	21
<b>PREPARATION .....</b>	4	<b>B TERMINAL CIRCUIT .....</b>	23
<b>PREPARATION .....</b>	4	Description .....	23
Special Service Tool .....	4	Diagnosis Procedure .....	23
Commercial Service Tool .....	4	<b>L TERMINAL CIRCUIT (OPEN) .....</b>	24
<b>SYSTEM DESCRIPTION .....</b>	5	Description .....	24
<b>COMPONENT PARTS .....</b>	5	Diagnosis Procedure .....	24
Component Parts Location .....	5	<b>L TERMINAL CIRCUIT (SHORT) .....</b>	26
Component Description .....	6	Description .....	26
<b>CHARGING SYSTEM .....</b>	7	Diagnosis Procedure .....	26
System Diagram .....	7	<b>S TERMINAL CIRCUIT .....</b>	27
System Description .....	7	Description .....	27
Component Description .....	7	Diagnosis Procedure .....	27
<b>POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM .....</b>	8	<b>SYMPTOM DIAGNOSIS .....</b>	28
System Diagram .....	8	<b>CHARGING SYSTEM .....</b>	28
System Description .....	8	Symptom Table .....	28
<b>WIRING DIAGRAM .....</b>	9	<b>REMOVAL AND INSTALLATION .....</b>	29
<b>CHARGING SYSTEM .....</b>	9	<b>GENERATOR .....</b>	29
Wiring Diagram .....	9	Exploded View .....	29
<b>BASIC INSPECTION .....</b>	14	Removal and Installation .....	29
<b>DIAGNOSIS AND REPAIR WORKFLOW .....</b>	14	Inspection .....	30
Work Flow (With EXP-800 NI or GR8-1200 NI) ....	14	<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	31
Work Flow (Without EXP-800 NI or GR8-1200 NI)...	17	<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	31
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	20		

CHG

---

Generator .....	31
-----------------	----

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000011151071

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

### Precaution for Power Generation Voltage Variable Control System

INFOID:0000000011151072

#### **CAUTION:**

For this model, the battery current sensor that is installed to the battery cable at the negative terminal measures the charging/discharging current of the battery, and performs various controls. If the electrical component or the ground wire is connected directly to the battery terminal, the current other than that being measured with the battery current sensor is charging to or discharging from the battery. This condition causes the malfunction of the control, and then the battery discharge may occur. Do not connect the electrical component or the ground wire directly to the battery terminal.

CHG

## PREPARATION

< PREPARATION >



# PREPARATION

## PREPARATION

### Special Service Tool

INFOID:0000000011151073

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.)	Description
— —) Model GR8-1200 NI Multitasking battery and electrical diagnostic station	 Tests batteries, starting and charging systems and charges batteries. For operating instructions, refer to diagnostic station instruction manual.  AWIIA1239ZZ
— —) Model EXP-800 NI Battery and electrical diagnostic analyzer	 Tests batteries and charging systems. For operating instructions, refer to diagnostic analyzer instruction manual.  JSMIA0806ZZ

### Commercial Service Tool

INFOID:0000000011151074

Tool name	Description
Power tool	 Loosening nuts, screws and bolts  PIIB1407E

## COMPONENT PARTS


< SYSTEM DESCRIPTION >

# SYSTEM DESCRIPTION

## COMPONENT PARTS

### Component Parts Location

INFOID:0000000011151075



AWMIA1325ZZ

CHG

- 1. Generator
- 2. ECM
- 3. IPDM E\I
- 4. Combination Meter
- 5. Battery current sensor

N

O

P

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

## Component Description

INFOID:000000011151076

Component part	Description
Generator (IC regulator)	<p>The IC regulator controls the power generation voltage by the target power generation voltage based on the received PWM command signal.</p> <p>When there is no PWM command signal, the generator performs the normal power generation according to the characteristic of the IC regulator.</p>
ECM	<p>The battery current sensor detects the charging/discharging current of the battery. The ECM judges the battery condition based on this signal.</p> <p>The ECM judges whether to request more output via the power generation voltage variable control according to the battery condition.</p> <p>When performing the power generation voltage variable control, the ECM calculates the target power generation voltage according to the battery condition and sends the calculated value as the power generation command value to the IPDM E/R.</p>
IPDM E/R	The IPDM E/R converts the received power generation command value into a pulse width modulated (PWM) command signal and sends it to the IC regulator.
Combination meter (charge warning lamp)	<p>The IC regulator warning function activates to illuminate the charge warning lamp if any of the following symptoms occur while generator is operating:</p> <ul style="list-style-type: none"><li>·Excessive voltage is produced.</li><li>·No voltage is produced.</li></ul>
Battery current sensor	The battery current sensor is located on the negative battery cable terminal. The battery current sensor detects the charging/discharging current of the battery and sends a voltage signal to the ECM according to the current value detected.


# CHARGING SYSTEM

< SYSTEM DESCRIPTION >

## CHARGING SYSTEM

### System Diagram

INFOID:0000000011151077



AWMIA1334GB

### System Description

INFOID:0000000011151078

The generator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

### Component Description

INFOID:0000000011151079

Component part		Description
Generator	Terminal "1"	Refer to <a href="#">CHG-23, "Description"</a> .
	Terminal "2"	Refer to <a href="#">CHG-24, "Description"</a> .
	Terminal "3"	Refer to <a href="#">CHG-27, "Description"</a> .
	Terminal "4"	Used for the power generation voltage variable control system. Refer to <a href="#">CHG-8, "System Description"</a> .
Combination meter (Charge warning lamp)		The IC regulator warning function activates to illuminate the charge warning lamp if any of the following symptoms occur while generator is operating: <ul style="list-style-type: none"> <li>• Excessive voltage is produced.</li> <li>• No voltage is produced.</li> </ul>
IPDM E/R		Used for the power generation voltage variable control system. Refer to <a href="#">CHG-8, "System Description"</a> .

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P


# POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM

< SYSTEM DESCRIPTION >

## POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM

### System Diagram

INFOID:0000000011151080



### System Description

INFOID:0000000011151081

Power generation variable voltage control system has been adopted. By varying the voltage to the generator, engine load due to power generation of the generator is reduced and fuel consumption is decreased.

#### NOTE:

When any malfunction is detected in the power generation variable voltage control system, power generation is performed according to the characteristic of the IC regulator in the generator.


# CHARGING SYSTEM

< WIRING DIAGRAM >

## WIRING DIAGRAM CHARGING SYSTEM

### Wiring Diagram

INFOID:0000000011151082




# CHARGING SYSTEM

< WIRING DIAGRAM >

## CHARGING SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	BG	-

Terminal No.	Color of Wire	Signal Name
11	BG	ALTERNATOR (CHARGE)
21	BG	IGN


Terminal No.	Color of Wire	Signal Name
54G	BG	-

Terminal No.	Color of Wire	Signal Name
20	BG	-
19	BG	-
18	BG	-
17	BG	-
16	BG	-
15	BG	-
14	BG	-
13	BG	-
12	BG	-
11	BG	-
10	BG	-
9	BG	-
8	BG	-
7	BG	-
6	BG	-
5	BG	-
4	BG	-
3	BG	-
2	BG	-
1	BG	-

Terminal No.	Color of Wire	Signal Name
39	BG	-
38	BG	-
37	BG	-
36	BG	-
35	BG	-
34	BG	-
33	BG	-
32	BG	-
31	BG	-
30	BG	-
29	BG	-
28	BG	-
27	BG	-
26	BG	-
25	BG	-
24	BG	-
23	BG	-
22	BG	-
21	BG	-
20	BG	-



Terminal No.	Color of Wire	Signal Name
1	LG	E2
2	LG	WIRE TO WIRE
3	LG	WHITE




AAMIA1245GB


# CHARGING SYSTEM

< WIRING DIAGRAM >

Connector No.	E16
Connector Name	ECM (FOR MEXICO)
Connector Color	GRAY




Connector No.	E14
Connector Name	JOINT CONNECTOR-E05
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name	Signal Name
113	P	CAN-L	CAN-L
114	L	CAN-H	CAN-H

Terminal No.	Color of Wire	Signal Name	Signal Name
123	P	CAN-L	CAN-L
124	L	CAN-H	CAN-H

Terminal No.	Color of Wire	Signal Name
121	P	CAN-L
122	L	CAN-H



Terminal No.	Color of Wire	Signal Name	Signal Name
113	P	CAN-L	CAN-L
114	L	CAN-H	CAN-H



Terminal No.	Color of Wire	Signal Name
7	B	GND (POWER)

Terminal No.	Color of Wire	Signal Name
28	P	CAN-L
29	L	CAN-H
41	B	GND (SIGNAL)

Terminal No.	Color of Wire	Signal Name
2	L	-
4	L	-
8	P	-
10	P	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P  
Q  
R  
S  
T  
U  
V  
W  
X  
Y  
Z  
CHG


# CHARGING SYSTEM

< WIRING DIAGRAM >

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
54G	P	-



Connector No.	F6
Connector Name	GENERATOR
Connector Color	-



Terminal No.	Color of Wire	Signal Name
5	B	-
6	B	-



Connector No.	F7
Connector Name	GENERATOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	Y	-
3	LG	-



Terminal No.	Color of Wire	Signal Name
62	63	64
63	64	65
64	65	66
65	66	67
66	67	70
67	70	71
68	69	72
69	72	73


Terminal No.	Color of Wire	Signal Name
71	LG	ALTC

ABMIA4868GB

# CHARGING SYSTEM

< WIRING DIAGRAM >

Connector No.	F32
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	F34
Connector Name	BATTERY CURRENT SENSOR
Connector Color	GRAY



Connector No.	F39
Connector Name	FUSIBLE LINK BOX (BATTERY)
Connector Color	-



Connector No.	F52
Connector Name	ECM (FOR MEXICO)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	Y	-
3	G	-
4	W	-

Terminal No.	Color of Wire	Signal Name
64	G	SENSOR GROUND (BATTERY CURRENT SENSOR)
68	Y	BATTERY TEMPERATURE SENSOR
69	W	BATTERY CURRENT SENSOR
87	LG	SENSOR POWER SUPPLY (BATTERY CURRENT SENSOR)

Terminal No.	Color of Wire	Signal Name
66	W	BATTERY CURRENT SENSOR
67	Y	BATTERY TEMPERATURE SENSOR
68	G	SENSOR GROUND (BATTERY CURRENT SENSOR)
75	LG	SENSOR POWER SUPPLY (BATTERY CURRENT SENSOR)

ABMIA6883GB

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

CHG

## DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

# BASIC INSPECTION

## DIAGNOSIS AND REPAIR WORKFLOW

Work Flow (With EXP-800 NI or GR8-1200 NI)

INFOID:000000011151083

### CHARGING SYSTEM DIAGNOSIS WITH EXP-800 NI OR GR8-1200 NI

To test the charging system, use the following special service tools:

- EXP-800 NI Battery and electrical diagnostic analyzer
- GR8-1200 NI Multitasking battery and electrical diagnostic station


**NOTE:**

Refer to the applicable Instruction Manual for proper charging system diagnosis procedures.

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

OVERALL SEQUENCE



DETAILED FLOW

**NOTE:**

To ensure a complete and thorough diagnosis, the battery, stator and generator test segments must be done as a set from start to finish.

## 1. PRELIMINARY INSPECTION

Perform the preliminary inspection. Refer to [CHG-20, "Diagnosis Procedure"](#).

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

---

>> GO TO 2.

## 2. STOP POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM

---

Stop the operation of the power generation voltage variable control in either of the following procedures.

- After selecting “ENGINE” using CONSULT, set the DUTY value of “ALTERNATOR DUTY” to 0 % by selecting “ALTERNATOR DUTY” of “Active Test”. Continue “Active Test” until the end of inspection. (When the DUTY value is 0 or 100 %, the normal power generation is performed according to the characteristic of the IC regulator of the generator.)
- Turn the ignition switch OFF, and disconnect the battery current sensor connector. [However, DTC (P1550–P1554) of the engine might remain. After finishing the inspection, connect the battery current sensor connector and erase the self diagnosis results history of the engine using CONSULT.]

>> GO TO 3.

## 3. DIAGNOSIS WITH EXP-800 NI OR GR8-1200 NI

---

Perform the charging system test using Multitasking battery and electrical diagnostic station GR8-1200 NI or Battery and electrical diagnostic analyzer EXP-800 NI. Refer to the applicable Instruction Manual for proper testing procedures.

### Test result

NO PROBLEMS>>Charging system is normal and will also show “DIODE RIPPLE” test result.

NO VOLTAGE>>GO TO 4.

LOW VOLTAGE>>GO TO 12.

HIGH VOLTAGE>>GO TO 14.

EXCESSIVE RIPPLE, OPEN PHASE, OPEN DIODE or SHORTED DIODE>>Replace the generator. Refer to [CHG-29, "Removal and Installation"](#). Perform “DIODE RIPPLE” test again using Multitasking battery and electrical diagnostic station GR8-1200 NI or Battery and electrical diagnostic analyzer EXP-800 NI to confirm repair.

## 4. INSPECTION WITH CHARGE WARNING LAMP (IGNITION SWITCH IS ON)

---

Turn the ignition switch ON.

### Does the charge warning lamp illuminate?

YES >> GO TO 6.

NO >> GO TO 5.

## 5. “L” TERMINAL CIRCUIT (OPEN) INSPECTION

---

Check “L” terminal circuit (open). Refer to [CHG-24, "Diagnosis Procedure"](#).

### Is the “L” terminal circuit normal?

YES >> Replace generator. Refer to [CHG-29, "Removal and Installation"](#).

NO >> Repair as needed.

## 6. INSPECTION WITH CHARGE WARNING LAMP (IDLING)

---

Start the engine and run it at idle.

### Does the charge warning lamp turn OFF?

YES >> GO TO 9.

NO >> GO TO 7.

## 7. “L” TERMINAL CIRCUIT (SHORT) INSPECTION

---

Check “L” terminal circuit (short). Refer to [CHG-26, "Diagnosis Procedure"](#).

### Is the “L” terminal circuit normal?

YES >> GO TO 8.

NO >> Repair as needed.

## 8. “S” TERMINAL CIRCUIT INSPECTION

---

Check “S” terminal circuit. Refer to [CHG-27, "Diagnosis Procedure"](#).

### Is the “S” terminal circuit normal?

YES >> GO TO 10.

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

NO >> Repair as needed.

## 9. INSPECTION WITH CHARGE WARNING LAMP (ENGINE AT 3,000 RPM)

Increase and maintain the engine speed at 3,000 rpm.

Does the charge warning lamp remain off?

YES >> GO TO 11.

NO >> GO TO 10.

## 10. INSPECTION OF GENERATOR PULLEY

Check generator pulley. Refer to [CHG-30, "Inspection"](#).

Is generator pulley normal?

YES >> Replace generator. Refer to [CHG-29, "Removal and Installation"](#).

NO >> Repair as needed.

## 11. "B" TERMINAL CIRCUIT INSPECTION

Check "B" terminal circuit. Refer to [CHG-23, "Diagnosis Procedure"](#).

Is "B" terminal circuit normal?

YES >> Replace generator. Refer to [CHG-29, "Removal and Installation"](#).

NO >> Repair as needed.

## 12. "B" TERMINAL CIRCUIT INSPECTION

Check "B" terminal circuit. Refer to [CHG-23, "Diagnosis Procedure"](#).

Is "B" terminal circuit normal?

YES >> GO TO 13.

NO >> Repair as needed.

## 13. INSPECTION OF GENERATOR PULLEY

Check generator pulley. Refer to [CHG-30, "Inspection"](#).

Is generator pulley normal?

YES >> Replace generator. Refer to [CHG-29, "Removal and Installation"](#).

NO >> Repair as needed.

## 14. "S" TERMINAL CIRCUIT INSPECTION

Check "S" terminal circuit. Refer to [CHG-27, "Diagnosis Procedure"](#).

Is the "S" terminal circuit normal?

YES >> Replace generator. Refer to [CHG-29, "Removal and Installation"](#).

NO >> Repair as needed.

## Work Flow (Without EXP-800 NI or GR8-1200 NI)

INFOID:0000000011151084

CHG

### OVERALL SEQUENCE

Before performing a generator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test.

- Before starting, inspect the fusible link.

N


O

P

# DIAGNOSIS AND REPAIR WORKFLOW

## < BASIC INSPECTION >

- Use fully charged battery.



## DETAILED FLOW

### 1. PRELIMINARY INSPECTION

Perform the preliminary inspection. Refer to [CHG-20, "Diagnosis Procedure"](#).

>> GO TO 2.

### 2. STOP POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM

Stop the operation of the power generation voltage variable control in either of the following procedures:

- After selecting “ENGINE” using CONSULT, set the DUTY value of “ALTERNATOR DUTY” to 0 % by selecting “ALTERNATOR DUTY” with “Active Test”. Continue “Active Test” until the end of inspection. (When the DUTY value is 0 or 100 %, the normal power generation is performed according to the characteristic of the IC regulator of the generator.)
- Turn the ignition switch OFF, and disconnect the battery current sensor connector. [However, DTC (P1550 - P1554) of the engine might remain. After finishing the inspection, connect the battery current sensor connector and erase the self-diagnostic results history of the engine using CONSULT.]

>> GO TO 3.

### 3. INSPECTION WITH CHARGE WARNING LAMP (IGNITION SWITCH IS TURNED ON)

When ignition switch is turned ON.

Does the charge warning lamp illuminate?

# DIAGNOSIS AND REPAIR WORKFLOW

## < BASIC INSPECTION >

YES >> GO TO 4.  
NO >> GO TO 10.

A

## 4. INSPECTION WITH CHARGE WARNING LAMP (IDLING)

Start the engine and run it at idle

B

Does the charge warning lamp turn OFF?

YES >> GO TO 5.  
NO >> GO TO 6.

C

## 5. INSPECTION WITH CHARGE WARNING LAMP (ENGINE AT 2,500 RPM)

Increase and maintain the engine speed at 2,500 rpm.

D

Does the charge warning lamp illuminate?

YES >> GO TO 8.  
NO >> Inspection End.

E

## 6. "L" TERMINAL CIRCUIT (SHORT) INSPECTION

Check terminal "L" circuit for (short). Refer to [CHG-26, "Diagnosis Procedure"](#).

F

Is the inspection result normal?

YES >> GO TO 7.  
NO >> Repair as needed.

G

## 7. "S" TERMINAL CIRCUIT INSPECTION

Check terminal "S" circuit. Refer to [CHG-27, "Diagnosis Procedure"](#).

H

Is the inspection result normal?

YES >> GO TO 8.  
NO >> Repair as needed.

I

## 8. MEASURE "B" TERMINAL VOLTAGE

Start engine. With engine running at 2,500 rpm, measure "B" terminal voltage.

J

What voltage does the measurement result show?

Less than 13.0 V>>GO TO 9.  
More than 16.0 V>>Replace generator. Refer to [CHG-29, "Removal and Installation"](#).

K

## 9. "B" TERMINAL CIRCUIT INSPECTION

L

Check "B" terminal circuit. Refer to [CHG-23, "Diagnosis Procedure"](#).

M

Is the inspection result normal?

YES >> Replace generator. Refer to [CHG-29, "Removal and Installation"](#).  
NO >> Repair as needed.

N

## 10. INSPECTION WITH CHARGE WARNING LAMP (IGNITION SWITCH IS ON)

CHG

1. Disconnect generator connector and apply ground to "L" terminal.
2. Turn the ignition switch ON.

O

Does the charge warning lamp illuminate?

YES >> Replace generator. Refer to [CHG-29, "Removal and Installation"](#).  
NO >> GO TO 11.

P

## 11. CHECK "L" TERMINAL CIRCUIT (OPEN)

Check "L" terminal circuit (OPEN). Refer to [CHG-24, "Diagnosis Procedure"](#).

>> Repair as needed.

# CHARGING SYSTEM PRELIMINARY INSPECTION

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### CHARGING SYSTEM PRELIMINARY INSPECTION

#### Diagnosis Procedure

INFOID:000000011151085

#### 1.CHECK BATTERY TERMINALS CONNECTION

Check if battery terminals are clean and tight.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair battery terminal connection. Confirm repair by performing complete Charging system test using EXP-800 NI or GR8-1200 NI (if available). Refer to the applicable Instruction Manual for proper testing procedures.

#### 2.CHECK FUSE

Check for blown fuse and fusible link.

Unit	Power source (Power supply terminals)	Fuse or Fusible Link
Generator	Battery (terminal 3)	Fuse 57
	Battery (terminal 1)	Fusible Link A
Combination meter	Ignition switch ON (terminal 2)	Fuse 31

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the blown fuse or fusible link after repairing the affected circuit.

#### 3.CHECK GENERATOR GROUND TERMINAL CONNECTION

Check if connector F7 terminals 5 and 6 are clean.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair connection.

#### 4.CHECK DRIVE BELT TENSION

Check drive belt tension. Refer to [CHG-29, "Removal and Installation"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair as needed.

# POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM OPERATION INSPECTION

< DTC/CIRCUIT DIAGNOSIS >

## POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM OPERATION INSPECTION

### Diagnosis Procedure

INFOID:000000011151086

Regarding Wiring Diagram information. Refer to [CHG-9, "Wiring Diagram"](#).

#### **CAUTION:**

When performing this inspection, always use a charged battery that has completed the battery inspection. (When the charging rate of the battery is low, the response speed of the voltage change will become slow. This can cause an incorrect inspection.)

#### 1. CHECK ECM (CONSULT)

Perform ECM self-diagnosis with CONSULT. Refer to [EC-72, "CONSULT Function"](#) (USA and Canada) or [EC-581, "CONSULT Function"](#) (Mexico).

##### Self-diagnostic results content

No malfunction detected>> GO TO 2.

Malfunction detected>> Check applicable parts, and repair or replace corresponding parts.

#### 2. CHECK OPERATION OF POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM

1. Connect CONSULT and start the engine.
2. The selector lever is in "P" or "N" position and all of the electric loads and A/C, etc. are turned OFF.
3. Select "ALTERNATOR DUTY" in "Active Test" of "ENGINE", and then check the value of "BATTERY VOLT" monitor when DUTY value of "DUTY" is set to 40.0 %.

##### **"BATTERY VOLT"**

**2 seconds after setting the DUTY value of "ALTERNATOR DUTY" to 40.0 % : 12 - 13.6 V**

4. Check the value of "BATTERY VOLT" monitor when DUTY value of "DUTY" is set to 80.0%.

##### **"BATTERY VOLT"**

**20 seconds after setting the DUTY value of "ALTERNATOR DUTY" to 80.0 % : +0.5 V or more against the value of "BATTERY VOLT" monitor when DUTY value is 40.0 %**

##### Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 3.

#### 3. CHECK IPDM E/R (CONSULT)

Perform IPDM E/R self-diagnosis with CONSULT. Refer to [PCS-9, "CONSULT Function \(IPDM E/R\)"](#).

##### Is the inspection result normal?

No malfunction detected>> GO TO 4.

Malfunction detected>> Check applicable parts, and repair or replace corresponding parts.

#### 4. CHECK HARNESS BETWEEN GENERATOR AND IPDM E/R

1. Turn ignition switch OFF.
2. Disconnect generator connector and IPDM E/R connector.
3. Check continuity between generator harness connector and IPDM E/R harness connector.

# POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM OPERATION INSPECTION

## < DTC/CIRCUIT DIAGNOSIS >

Generator		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F7	4	F24	71	Yes

4. Check continuity between generator harness connector and ground.

Generator		—	Continuity
Connector	Terminal		
F7	4	Ground	No

Is the inspection result normal?

YES    >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO     >> Repair harness or connectors between IPDM E/R and generator.

## B TERMINAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

### B TERMINAL CIRCUIT

#### Description

INFOID:0000000011151087

"B" terminal circuit supplies power to charge the battery and to operate the vehicles electrical system.

#### Diagnosis Procedure

INFOID:0000000011151088

Regarding Wiring Diagram information. Refer to [CHG-9, "Wiring Diagram"](#).

#### 1. CHECK "B" TERMINAL CONNECTION

1. Turn ignition switch OFF.
2. Check if "B" terminal is clean and tight.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair terminal "B" connection. Confirm repair by performing complete Charging system test using the EXP-800 NI or GR8-1200 NI (if available). Refer to applicable Instruction Manual for proper testing procedures.

#### 2. CHECK "B" TERMINAL CIRCUIT

Check voltage between generator "B" terminal and ground.

(+) Generator		(-)	Voltage (Approx.)
Connector	Terminal		
F6	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness for open between generator and fusible link.

#### 3. CHECK "B" TERMINAL CONNECTION (VOLTAGE DROP TEST)

1. Start engine, then engine running at idle and warm.
2. Check voltage between battery positive terminal and generator connector "B" terminal.

(+) Generator		(-)	Voltage (Approx.)
Connector	Terminal		
F6	1	Battery positive terminal	Less than 0.2V

Is the inspection result normal?

YES >> "B" terminal circuit is normal. Refer to [CHG-14, "Work Flow \(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-17, "Work Flow \(Without EXP-800 NI or GR8-1200 NI\)"](#).

NO >> Check harness between battery and generator for continuity.

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

# L TERMINAL CIRCUIT (OPEN)

< DTC/CIRCUIT DIAGNOSIS >

## L TERMINAL CIRCUIT (OPEN)

### Description

INFOID:0000000011151089

The "L" terminal circuit controls the charge warning lamp. The charge warning lamp turns ON when the ignition switch is set to ON or START. When the generator is providing sufficient voltage with the engine running, the charge warning lamp turns OFF. If the charge warning lamp illuminates with the engine running, a malfunction is indicated.

### Diagnosis Procedure

INFOID:0000000011151090

Regarding Wiring Diagram information. Refer to [CHG-9, "Wiring Diagram"](#).

#### 1. CHECK "L" TERMINAL CONNECTION

1. Turn ignition switch OFF.
2. Check if "L" terminal is clean and tight.

##### Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair "L" terminal connection. Confirm repair by performing complete Charging system test using EXP-800 NI or GR8-1200 NI (if available). Refer to applicable Instruction Manual for proper testing procedures.

#### 2. CHECK "L" TERMINAL CIRCUIT (OPEN)

1. Disconnect the generator connector.
2. Apply ground to generator harness connector terminal.
3. Check condition of the charge warning lamp with the ignition switch in the ON position.

Generator		Ground	Condition	
Connector	Terminal		Ignition switch position	Charge warning lamp
F7	2		ON	Illuminate

##### Does it illuminate?

YES >> "L" terminal circuit is normal. Refer to [CHG-14, "Work Flow \(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-17, "Work Flow \(Without EXP-800 NI or GR8-1200 NI\)"](#).

NO >> GO TO 3.

#### 3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the battery cable from the negative terminal.
2. Disconnect the combination meter connector.
3. Check continuity between generator harness connector and combination meter harness connector.

Generator		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
F7	2	M24	11	Yes

##### is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the harness or connectors.

#### 4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check continuity between combination meter harness connector and fuse block (J/B).

Combination meter		Fuse box (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M24	21	M4	8P	Yes

## L TERMINAL CIRCUIT (OPEN)

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the harness or connectors.

### 5.CHECK POWER SUPPLY CIRCUIT

1. Connect the battery cable to the negative terminal.
2. Check voltage between combination meter harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
M24	21	Ground	When the ignition switch is in ON position	Battery voltage

Is the inspection result normal?

YES >> Replace the combination meter. Refer to MWI-85, "Removal and Installation".

NO >> Repair or replace the harness or connectors.

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

# L TERMINAL CIRCUIT (SHORT)

< DTC/CIRCUIT DIAGNOSIS >

## L TERMINAL CIRCUIT (SHORT)

### Description

INFOID:0000000011151091

The terminal "L" circuit controls the charge warning lamp. The charge warning lamp turns ON when the ignition switch is set to ON or START. When the generator is providing sufficient voltage with the engine running, the charge warning lamp turns off. If the charge warning lamp illuminates with the engine running, a malfunction is indicated.

### Diagnosis Procedure

INFOID:0000000011151092

Regarding Wiring Diagram information, refer to [CHG-9, "Wiring Diagram"](#).

#### 1. CHECK "L" TERMINAL CIRCUIT (SHORT)

1. Turn ignition switch OFF.
2. Disconnect generator connector.
3. Turn ignition switch ON.

Does charge warning lamp illuminate?

YES >> GO TO 2.

NO >> Refer to [CHG-14, "Work Flow \(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-17, "Work Flow \(Without EXP-800 NI or GR8-1200 NI\)"](#).

#### 2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

1. Turn ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect combination meter connector.
4. Check continuity between the combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
F7	2		No

Is the inspection result normal?

YES >> Replace the combination meter. Refer to [MWI-85, "Removal and Installation"](#).

NO >> Repair or replace the harness or connectors.

## S TERMINAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

### S TERMINAL CIRCUIT

#### Description

INFOID:0000000011151093

The output voltage of the generator is controlled by the IC regulator at terminal "S" detecting the input voltage from battery.

The "S" terminal circuit detects the battery voltage to adjust the generator output voltage with the IC voltage regulator.

#### Diagnosis Procedure

INFOID:0000000011151094

Regarding Wiring Diagram information. Refer to [CHG-9, "Wiring Diagram"](#).

#### 1.CHECK "S" TERMINAL CONNECTION

1. Turn ignition switch OFF.
2. Check if "S" terminal is clean and tight.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair "S" terminal connection. Confirm repair by performing complete Charging system test using EXP-800 NI or GR8-1200 NI (if available). Refer to the applicable Instruction Manual for proper testing procedures.

#### 2.CHECK "S" TERMINAL CIRCUIT

Check voltage between generator harness connector and ground.

(+) Generator		(-)	Voltage (Approx.)
Connector	Terminal		
F7	3	Ground	Battery voltage

Is the inspection result normal?

YES >> Refer to [CHG-14, "Work Flow \(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-17, "Work Flow \(Without EXP-800 NI or GR8-1200 NI\)"](#).

NO >> Check harness for open between generator and fuse.

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### CHARGING SYSTEM

#### Symptom Table

INFOID:000000011151095

Symptom	Reference
Battery discharged	
The charge warning lamp does not illuminate when the ignition switch is set to ON.	Refer to <a href="#">CHG-14, "Work Flow (With EXP-800 NI or GR8-1200 NI)"</a> or <a href="#">CHG-17, "Work Flow (Without EXP-800 NI or GR8-1200 NI)"</a> .
The charge warning lamp does not turn OFF after the engine starts.	
The charging warning lamp turns ON when increasing the engine speed.	


# GENERATOR

< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION GENERATOR

### Exploded View

INFOID:0000000011151096



1 - 3 Tightening order

6. Generator bracket

4. Generator

◀ Front

5. B terminal nut

### Removal and Installation

INFOID:0000000011151097

#### REMOVAL

1. Remove the battery tray. Refer to [PG-97, "Removal and Installation"](#).
2. Remove the radiator. Refer to [CO-15, "Removal and Installation"](#).
3. Remove the fan shroud and motor assembly. Refer to [CO-17, "Removal and Installation"](#).
4. Remove the front wheel and tire (RH) using power tool. Refer to [WT-58, "Adjustment"](#).
5. Remove the drive belt auto-tensioner. Refer to [EM-14, "Removal and Installation of Drive Belt Auto-tensioner"](#).
6. Disconnect the harness connectors from generator.
7. Release the harness retainers.
8. Remove the bolts and generator bracket.
9. Remove the generator.

#### INSTALLATION

Installation is in the reverse order of removal.

- Temporarily tighten bolts and nut then tighten nut and bolts in the specified numerical order. Refer to [CHG-29, "Exploded View"](#).

#### CAUTION:

**Be sure to tighten "B" terminal nut carefully.**

- Install generator and check tension of belt. Refer to [EM-12, "Checking Drive Belt"](#).

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P

# GENERATOR

## < REMOVAL AND INSTALLATION >

- For this model, the power generation voltage variable control system that controls the power generation voltage of the generator has been adopted. Therefore, the power generation voltage variable control system operation inspection should be performed after replacing the generator, and then make sure that the system operates normally. Refer to [CHG-7, "System Description"](#).

## Inspection

INFOID:000000011151098

### GENERATOR PULLEY INSPECTION

Perform the following.

- Make sure that generator pulley does not rattle.
- Make sure that generator pulley nut is tight.

**NOTE:**

Replace the generator as an assembly if necessary.

## SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

# SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

Generator

INFOID:000000011151099

Application	VQ35DE
Type*	A003TJ3991ZC
Nominal rating	12V-150A
Ground polarity	Negative
Minimum revolution under no-load	1,000 rpm
Hot output current (when 13.5 volts are applied)	More than 122A/2,500 rpm More than 144A/5,000 rpm
Regulated output voltage	14.1 - 14.7V @ 20°C (68°F)
Adjustment range of power generation voltage variable control	11.4 - 15.6 V

\*: Always check with the Parts Department for the latest parts information.

A

B

C

D

E

F

G

H

I

J

K

L

CHG

N

O

P