

# SECTION **SEC**

## SECURITY CONTROL SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

### CONTENTS

<b>WITH INTELLIGENT KEY SYSTEM</b>		
<b>PRECAUTION</b> .....	<b>4</b>	
<b>PRECAUTIONS</b> .....	<b>4</b>	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	<b>4</b>	
<b>SYSTEM DESCRIPTION</b> .....	<b>5</b>	
<b>COMPONENT PARTS</b> .....	<b>5</b>	
Component Parts Location .....	<b>5</b>	
Component Description .....	<b>6</b>	
CVT Shift Selector (Park Position Switch) .....	<b>6</b>	
BCM .....	<b>6</b>	
ECM .....	<b>7</b>	
IPDM E/R .....	<b>7</b>	
NATS Antenna Amp. ....	<b>7</b>	
Combination Meter .....	<b>7</b>	
Door Switch .....	<b>7</b>	
Outside Key Antenna .....	<b>7</b>	
Hood Switch .....	<b>7</b>	
Inside Key Antenna .....	<b>7</b>	
Remote Keyless Entry Receiver .....	<b>7</b>	
Intelligent Key .....	<b>7</b>	
Push-button Ignition Switch .....	<b>8</b>	
Security Indicator Lamp .....	<b>8</b>	
Starter Control Relay .....	<b>8</b>	
Starter Relay .....	<b>8</b>	
Stop Lamp Switch .....	<b>8</b>	
Transmission Range Switch .....	<b>8</b>	
Vehicle Information Display .....	<b>8</b>	
<b>SYSTEM</b> .....	<b>9</b>	
<b>INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION</b> .....	<b>9</b>	
INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Diagram .....	<b>9</b>	
INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description .....	<b>9</b>	
<b>NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS</b> ...	<b>11</b>	
NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Diagram .....	<b>12</b>	
NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description .....	<b>12</b>	
<b>VEHICLE SECURITY SYSTEM</b> .....	<b>14</b>	
VEHICLE SECURITY SYSTEM : System Diagram .....	<b>14</b>	
VEHICLE SECURITY SYSTEM : System Description .....	<b>14</b>	
<b>DIAGNOSIS SYSTEM (BCM)</b> .....	<b>18</b>	
<b>COMMON ITEM</b> .....	<b>18</b>	
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) .....	<b>18</b>	
<b>INTELLIGENT KEY</b> .....	<b>19</b>	
INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) .....	<b>19</b>	
<b>THEFT ALM</b> .....	<b>22</b>	
THEFT ALM : CONSULT Function (BCM - THEFT ALM) .....	<b>22</b>	
<b>IMMU</b> .....	<b>23</b>	
IMMU : CONSULT Function (BCM - IMMU) .....	<b>23</b>	
<b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....	<b>24</b>	
CONSULT Function (IPDM E/R) .....	<b>24</b>	
<b>ECU DIAGNOSIS INFORMATION</b> .....	<b>26</b>	
<b>ECM, IPDM E/R, BCM</b> .....	<b>26</b>	
List of ECU Reference .....	<b>26</b>	
<b>WIRING DIAGRAM</b> .....	<b>27</b>	
<b>ENGINE START FUNCTION</b> .....	<b>27</b>	
Wiring Diagram .....	<b>27</b>	
<b>NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS</b> .....	<b>44</b>	



Wiring Diagram .....	44	DTC Logic .....	93
Diagnosis Procedure .....		Diagnosis Procedure .....	93
<b>VEHICLE SECURITY SYSTEM .....</b>	<b>56</b>	<b>B2190 NATS ANTENNA AMP. ....</b>	<b>96</b>
Wiring Diagram .....	56	Description .....	96
<b>BASIC INSPECTION .....</b>	<b>73</b>	DTC Logic .....	96
<b>DIAGNOSIS AND REPAIR WORK FLOW .....</b>	<b>73</b>	Diagnosis Procedure .....	96
Work Flow .....	73	<b>B2191, P1615 DIFFERENCE OF KEY .....</b>	<b>98</b>
<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT .....</b>	<b>76</b>	Description .....	98
<b>ECM .....</b>	<b>76</b>	DTC Logic .....	98
ECM : Description .....	76	Diagnosis Procedure .....	98
ECM : Work Procedure .....	76	<b>B2192 ID DISCORD, IMMU-ECM .....</b>	<b>99</b>
<b>BCM .....</b>	<b>76</b>	DTC Logic .....	99
BCM : Description .....	76	Diagnosis Procedure .....	99
BCM : Work Procedure .....	76	<b>B2193 CHAIN OF ECM-IMMU .....</b>	<b>100</b>
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>78</b>	DTC Logic .....	100
<b>P1610 LOCK MODE .....</b>	<b>78</b>	Diagnosis Procedure .....	100
Description .....	78	<b>B2195 ANTI-SCANNING .....</b>	<b>101</b>
DTC Logic .....	78	DTC Logic .....	101
Diagnosis Procedure .....	78	Diagnosis Procedure .....	101
<b>P1611 ID DISCORD, IMMU-ECM .....</b>	<b>79</b>	<b>B2196 DONGLE UNIT .....</b>	<b>102</b>
DTC Logic .....	79	Description .....	102
Diagnosis Procedure .....	79	DTC Logic .....	102
<b>P1612 CHAIN OF ECM-IMMU .....</b>	<b>80</b>	Diagnosis Procedure .....	102
DTC Logic .....	80	<b>B2198 NATS ANTENNA AMP. ....</b>	<b>104</b>
Diagnosis Procedure .....	80	DTC Logic .....	104
<b>P1614 CHAIN OF IMMU-KEY .....</b>	<b>81</b>	Diagnosis Procedure .....	104
DTC Logic .....	81	<b>B2555 STOP LAMP .....</b>	<b>106</b>
Diagnosis Procedure .....	81	DTC Logic .....	106
<b>B210B STARTER CONTROL RELAY .....</b>	<b>83</b>	Diagnosis Procedure .....	106
DTC Logic .....	83	Component Inspection .....	107
Diagnosis Procedure .....	83	<b>B2556 PUSH-BUTTON IGNITION SWITCH ...</b>	<b>108</b>
<b>B210C STARTER CONTROL RELAY .....</b>	<b>84</b>	DTC Logic .....	108
DTC Logic .....	84	Diagnosis Procedure .....	108
Diagnosis Procedure .....	84	Component Inspection .....	109
<b>B210D STARTER RELAY .....</b>	<b>86</b>	<b>B2557 VEHICLE SPEED .....</b>	<b>110</b>
DTC Logic .....	86	DTC Logic .....	110
Diagnosis Procedure .....	86	Diagnosis Procedure .....	110
<b>B210E STARTER RELAY .....</b>	<b>88</b>	<b>B2560 STARTER CONTROL RELAY .....</b>	<b>111</b>
DTC Logic .....	88	Description .....	111
Diagnosis Procedure .....	88	DTC Logic .....	111
<b>B210F TRANSMISSION RANGE SWITCH .....</b>	<b>90</b>	Diagnosis Procedure .....	111
Description .....	90	<b>B2601 SHIFT POSITION .....</b>	<b>112</b>
DTC Logic .....	90	DTC Logic .....	112
Diagnosis Procedure .....	90	Diagnosis Procedure .....	112
<b>B2110 TRANSMISSION RANGE SWITCH .....</b>	<b>93</b>	Component Inspection .....	114
Description .....	93	<b>B2602 SHIFT POSITION .....</b>	<b>115</b>
		DTC Logic .....	115
		Diagnosis Procedure .....	115
		Component Inspection .....	116

<b>B2603 SHIFT POSITION</b> .....	<b>118</b>	Component Inspection .....	140	A
DTC Logic .....	118	<b>HORN FUNCTION</b> .....	<b>141</b>	B
Diagnosis Procedure .....	118	Component Function Check .....	141	
Component Inspection .....	121	Diagnosis Procedure .....	141	C
<b>B2604 SHIFT POSITION</b> .....	<b>122</b>	<b>SECURITY INDICATOR LAMP</b> .....	<b>143</b>	D
DTC Logic .....	122	Component Function Check .....	143	
Diagnosis Procedure .....	122	Diagnosis Procedure .....	143	E
<b>B2605 SHIFT POSITION</b> .....	<b>125</b>	<b>SYMPTOM DIAGNOSIS</b> .....	<b>145</b>	F
DTC Logic .....	125	<b>INTELLIGENT KEY SYSTEM SYMPTOMS</b> ...	<b>145</b>	G
Diagnosis Procedure .....	125	Diagnosis Procedure .....	145	
<b>B2608 STARTER RELAY</b> .....	<b>128</b>	<b>ENGINE CAN NOT START</b> .....	<b>146</b>	H
DTC Logic .....	128	Description .....	146	
Diagnosis Procedure .....	128	Diagnosis Procedure .....	146	I
<b>B2617 STARTER RELAY CIRCUIT</b> .....	<b>130</b>	<b>ENGINE DOES NOT START WHEN INTELLI-</b>		J
Description .....	130	<b>  GENT KEY IS INSIDE OF VEHICLE</b> .....	<b>147</b>	
DTC Logic .....	130	Description .....	147	
Diagnosis Procedure .....	130	Diagnosis Procedure .....	147	
<b>B261E VEHICLE TYPE</b> .....	<b>132</b>	<b>ENGINE DOES NOT START WHEN INTELLI-</b>		
Description .....	132	<b>  GENT KEY IS INSIDE OF VEHICLE (ONE</b>		
DTC Logic .....	132	<b>  KEY)</b> .....	<b>149</b>	
Diagnosis Procedure .....	132	Description .....	149	
<b>B26F3 STARTER CONTROL RELAY</b> .....	<b>134</b>	Diagnosis Procedure .....	149	
DTC Logic .....	134	<b>DOOR DOES NOT LOCK/UNLOCK AND EN-</b>		
Diagnosis Procedure .....	134	<b>  GINE DOES NOT START (REQ SW/PUSH</b>		
<b>B26F4 STARTER CONTROL RELAY</b> .....	<b>135</b>	<b>  SW) (ONE KEY)</b> .....	<b>150</b>	
DTC Logic .....	135	Description .....	150	
Diagnosis Procedure .....	135	Diagnosis Procedure .....	150	
<b>B26F7 BCM</b> .....	<b>136</b>	<b>REMOVAL AND INSTALLATION</b> .....	<b>152</b>	<b>SEC</b>
DTC Logic .....	136	<b>NATS ANTENNA AMP.</b> .....	<b>152</b>	
Diagnosis Procedure .....	136	Exploded View .....	152	
<b>B26F8 BCM</b> .....	<b>137</b>	Removal and Installation .....	152	L
DTC Logic .....	137	<b>PUSH-BUTTON IGNITION SWITCH</b> .....	<b>153</b>	
Diagnosis Procedure .....	137	Exploded View .....	153	
<b>HEADLAMP FUNCTION</b> .....	<b>138</b>	Removal and Installation .....	153	M
Component Function Check .....	138	<b>IMMOBILIZER CONTROL MODULE</b> .....	<b>154</b>	
Diagnosis Procedure .....	138	Removal and Installation .....	154	N
<b>HOOD SWITCH</b> .....	<b>139</b>			O
Component Function Check .....	139			P
Diagnosis Procedure .....	139			

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000012549504

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[WITH INTELLIGENT KEY SYSTEM]

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000012549505



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

AWKIA3781ZZ

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

- |  |  |  |
|--|--|--|
| 1. BCM (view with combination meter removed) | 2. IPDM E/R  | 3. Combination meter                         |
| 4. Security indicator lamp                   | 5. Push-button ignition switch   | 6. NATS antenna amp.                         |
| 7. Inside key antenna (console)              | 8. Inside key antenna (luggage room) (view with rear carpet removed)             | 9. Horn (view with right head light removed) |
| 10. Stop lamp switch                         | 11. CVT shift selector (park position switch) (view with center console removed) | 12. Outside key antenna (drivers side)       |
| 13. Outside key antenna (passenger side)     | 14. Outside key antenna (rear bumper)  | 15. Transmission range switch                |

## Component Description

INFOID:000000012549506

Component	Reference
CVT shift selector (park position switch)	<a href="#">SEC-6</a>
BCM	<a href="#">SEC-6</a>
ECM	<a href="#">SEC-7</a>
IPDM E/R	<a href="#">SEC-7</a>
NATS antenna amp.	<a href="#">SEC-7</a>
Combination meter	<a href="#">SEC-7</a>
Door switch	<a href="#">SEC-7</a>
Hood switch	<a href="#">SEC-7</a>
Outside key antenna	<a href="#">SEC-7</a>
Inside key antenna	<a href="#">SEC-7</a>
Intelligent Key	<a href="#">SEC-7</a>
Push-button ignition switch	<a href="#">SEC-8</a>
Remote keyless entry receiver	<a href="#">SEC-7</a>
Security indicator lamp	<a href="#">SEC-8</a>
Starter control relay	<a href="#">SEC-8</a>
Starter relay	<a href="#">SEC-8</a>
Stop lamp switch	<a href="#">SEC-8</a>
Transmission range switch	<a href="#">SEC-8</a>
Vehicle information display	<a href="#">SEC-8</a>

## CVT Shift Selector (Park Position Switch)

INFOID:000000012549507

Park position switch detects that CVT shift selector is in the P (Park) position and then transmits the signal to BCM and IPDM E/R.

BCM confirms the CVT shift selector position with the following 5 signals:

- P (Park) position signal from CVT shift selector (park position switch)
- P/N position signal from TCM
- P (Park) position signal from IPDM E/R (CAN)
- P/N position signal from IPDM E/R (CAN)
- P/N position signal from TCM (CAN)

IPDM E/R confirms the CVT shift selector position with the following 3 signals:

- P (Park) position signal from CVT shift selector (park position switch)
- P/N position signal from TCM
- P/N position signal from BCM (CAN)

## BCM

INFOID:000000012549508

BCM controls INTELLIGENT KEY SYSTEM (ENGINE START FUNCTION), NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)], and VEHICLE SECURITY SYSTEM.

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

BCM performs the ID verification between BCM and Intelligent Key when the Intelligent Key is carried into the detection area of inside key antenna and push-button ignition switch is pressed. If the ID verification result is OK, push-button ignition switch operation is available.

Then, when the power supply position is turned ON, BCM performs ID verification between BCM and ECM. If the ID verification result is OK, ECM can start engine.

## ECM

INFOID:0000000012549509

ECM controls the engine.

When power supply position is turned ON, BCM starts communication with ECM and performs the ID verification between BCM and ECM.

If the verification result is OK, the engine can start. If the verification result is NG, the engine can not start.

## IPDM E/R

INFOID:0000000012549510

IPDM E/R has the starter relay and starter control relay inside. Starter relay and starter control relay are used for the engine starting function. IPDM E/R controls these relays while communicating with BCM.

## NATS Antenna Amp.

INFOID:0000000012549511

The ID verification is performed between BCM and transponder in Intelligent Key via NATS antenna amp. when Intelligent Key backside is contacted to push-button ignition switch in case that Intelligent Key battery is discharged. If the ID verification result is OK, the operation of starting engine is available.

## Combination Meter

INFOID:0000000012549512

Combination meter transmits the vehicle speed signal to BCM via CAN communication.

BCM also receives the vehicle speed signal from ABS actuator and electric unit (control unit) via CAN communication. BCM compares both signals to detect the vehicle speed.

## Door Switch

INFOID:0000000012549513

Door switch detects door open/close condition and then transmits ON/OFF signal to BCM.

## Outside Key Antenna

INFOID:0000000012549514

Outside key antennas detects whether Intelligent Key is inside the vehicle and transmits the signal to BCM. Three outside key antennas are installed outside key antenna RH, outside key antenna LH and outside key antenna rear bumper.

## Hood Switch

INFOID:0000000012549515

Hood switch detects that hood is open/closed, and then transmits the signal to IPDM E/R. IPDM E/R transmits hood switch signal to BCM via CAN communication.

## Inside Key Antenna

INFOID:0000000012549516

Inside key antenna detects whether Intelligent Key is inside the vehicle and transmits the signal to BCM.

Two inside key antennas are installed in the console and luggage room.

## Remote Keyless Entry Receiver

INFOID:0000000012549517

Remote keyless entry receiver receives each button operation signal and electronic key ID signal from Intelligent Key and then transmits the signal to BCM.

## Intelligent Key

INFOID:0000000012549518

Each Intelligent Key has an individual electronic ID and transmits the ID signal by request from BCM.

Carrying the Intelligent Key whose ID is registered in BCM, the driver can perform, remote start, door lock/unlock operation, remote back door, panic alarm and push-button ignition switch operation.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

### Push-button Ignition Switch

INFOID:000000012549519

Push-button ignition switch detects that push-button is pressed and then transmits the signal to BCM. BCM changes the power supply position with the operation of push-button ignition switch. BCM maintains the power supply position status while push-button is not operated.

### Security Indicator Lamp

INFOID:000000012549520

Security indicator lamp is located on combination meter. Security indicator lamp blinks when power supply position is any position other than ON to warn that NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)] is on board.

### Starter Control Relay

INFOID:000000012549521

Engine starting system functions by controlling both starter relay and starter control relay. Both relays are integrated in IPDM E/R. Starter relay is controlled by BCM and starter control relay is controlled by IPDM E/R on request from BCM. IPDM E/R transmits starter relay and starter control relay status signal to BCM via CAN communication.

### Starter Relay

INFOID:000000012549522

Engine starting system functions by controlling both starter relay and starter control relay. Both relays are integrated in IPDM E/R. Starter relay is controlled by BCM, and starter control relay is controlled by IPDM E/R on request from BCM. IPDM E/R transmits starter relay and starter control relay status signal to BCM via CAN communication.

### Stop Lamp Switch

INFOID:000000012549523

Stop lamp switch detects that brake pedal is depressed, and then transmits the signal to BCM.

### Transmission Range Switch

INFOID:000000012549524

Transmission range switch is integrated in CVT assembly, and detects the CVT shift selector position. TCM receives the transmission range switch signal and then transmits the P/N position signal to BCM and IPDM E/R.

BCM confirms the CVT shift selector position with the following 5 signals:

- P (Park) position signal from CVT shift selector (park position switch)
- P/N position signal from TCM
- P (Park) position signal from IPDM E/R (CAN)
- P/N position signal from IPDM E/R (CAN)
- P/N position signal from TCM (CAN)

IPDM E/R confirms the CVT shift selector position with the following 3 signals:

- P (Park) position signal from CVT shift selector (park position switch)
- P/N position signal from TCM
- P/N position signal from BCM (CAN)

### Vehicle Information Display

INFOID:000000012549525

Vehicle information display is integrated in combination meter. Various information and warnings regarding the Intelligent Key System are displayed.




SYSTEM

INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Diagram

INFOID:000000012549526



INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description

INFOID:000000012549527

SYSTEM DESCRIPTION

- The engine start function of Intelligent Key system makes it possible to start and stop the engine without using the key, based on the electronic ID verification. The electronic ID verification is performed between BCM and Intelligent Key when the push-button ignition switch is pressed while the Intelligent Key is within the detection area of inside key antenna.

**NOTE:**

The driver should carry the Intelligent Key at all times.

- Intelligent Key has 2 IDs [Intelligent Key ID and NVIS (NATS) ID]. It can perform the door lock/unlock operation and the push-button ignition switch operation when the registered Intelligent Key is carried.
- When Intelligent Key battery is discharged, engine can be started by operating push-button ignition switch after contacting Intelligent Key backside to push-button ignition switch. At that time, the NVIS (NATS) ID verification is performed.
- If the ID is successfully verified, when push-button ignition switch is pressed, the engine can be started.
- Up to 4 Intelligent Keys can be registered (Including the standard Intelligent Key) upon request from the customer.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

SEC

L  
M  
N  
O  
P

# SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

- For initialization and registration of Intelligent Keys, refer to CONSULT Immobilizer mode and follow the on-screen instructions.

**NOTE:**

Refer to [DLK-21, "INTELLIGENT KEY SYSTEM : System Description"](#) for any functions other than engine start function of Intelligent Key system.

## PRECAUTIONS FOR INTELLIGENT KEY SYSTEM

**The transponder [the chip for NVIS (NATS) ID verification] is integrated into the Intelligent Key. In that case, the NVIS (NATS) ID verification can be performed when Intelligent Key backside is contacted to push-button ignition switch. If verification result is OK, engine can be started.**

## OPERATION WHEN INTELLIGENT KEY IS CARRIED

1. When the push-button ignition switch is pressed, the BCM activates the inside key antenna and transmits the request signal to the Intelligent Key.
2. The Intelligent Key receives the request signal and transmits the Intelligent Key ID signal to the BCM.
3. BCM receives the Intelligent Key ID signal via remote keyless entry receiver and verifies it with the registered ID.
4. BCM turns ACC relay ON and transmits the ignition power supply ON signal to IPDM E/R.
5. IPDM E/R turns the ignition relay ON and starts the ignition power supply.
6. BCM detects that the selector lever position and brake pedal operating condition.
7. BCM transmits the starter request signal to IPDM E/R and turns the starter relay in IPDM E/R ON if BCM judges that the engine start condition\* is satisfied.
8. IPDM E/R turns the starter control relay ON when receiving the starter request signal.
9. Power supply is supplied through the starter relay and the starter control relay to operate the starter motor.

**CAUTION:**

**If a malfunction is detected in the Intelligent Key system, the "KEY" warning lamp in the combination meter illuminates. At that time, the engine cannot be started.**

10. When BCM receives feedback signal from ECM indicating that the engine is started, the BCM transmits a stop signal to IPDM E/R and stops cranking by turning OFF the starter motor relay. (If engine start is unsuccessful, cranking stops automatically within 5 seconds.)

**CAUTION:**

**When the Intelligent Key is carried outside of the vehicle (inside key antenna detection area) while the power supply is in the ACC or ON position, even if the engine start condition\* is satisfied, the engine cannot be started.**

\*: For the engine start condition, refer to the table below "POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION".

## OPERATION RANGE

Engine can be started when Intelligent Key is inside the vehicle. However, sometimes engine may not start when Intelligent Key is on instrument panel or in glove box.

## ENGINE START OPERATION WHEN INTELLIGENT KEY IS CONTACTED TO PUSH-BUTTON IGNITION SWITCH

When Intelligent Key battery is discharged, the NVIS (NATS) ID verification between transponder in Intelligent Key and BCM is performed when Intelligent Key backside is contacted to push-button ignition switch. If the verification result is OK, engine can be started.

## POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION

The power supply position changing operation can be performed with the following operations.

**NOTE:**

- When an Intelligent Key is within the detection area of inside key antenna and when Intelligent Key backside is contacted to push-button ignition switch, it is equivalent to the operations below.
- When starting the engine, the BCM monitors under the engine start conditions:
  - Brake pedal operating condition
  - Selector lever position
  - Vehicle speed

Vehicle speed: less than 4 km/h (2.5 MPH)

# SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
LOCK → ACC	—	Not depressed	1
LOCK → ACC → ON	—	Not depressed	2
LOCK → ACC → ON → OFF	—	Not depressed	3
LOCK → START ACC → START ON → START	P or N position	Depressed	1
Engine is running → OFF	—	—	1

Vehicle speed: 4 km/h (2.5 MPH) or more

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
Engine is running → ACC	—	—	Emergency stop operation
Engine stall return operation while driving	N position	Not depressed	1

Emergency stop operation

- Press and hold the push-button ignition switch for 2 seconds or more.
- Press the push-button ignition switch 3 times or more within 1.5 seconds.

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC


# SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Diagram

INFOID:000000012549528



ALKIA2854GB

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description

INFOID:000000012549529

### SYSTEM DESCRIPTION

- The NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)] prevents the engine from being started by Intelligent Key whose ID is not registered to the vehicle (BCM). It has higher protection against auto theft involving the duplication of mechanical keys.
- The ignition key integrated in the Intelligent Key cannot start the engine. When the Intelligent Key battery is discharged, the NVIS (NATS) ID verification is performed between the transponder integrated with Intelligent Key and BCM via NATS antenna amp. when the Intelligent Key backside is contacted to push-button ignition switch. If the verification results are OK, the engine start operation can be performed by the push-button ignition switch operation.
- Locate the security indicator lamp and apply the anti-theft system equipment sticker that warns that the NVIS (NATS) is on-board the model.
- Security indicator lamp always blinks when the power supply position is any position other than ON.
- Up to 4 Intelligent Keys can be registered (including the standard ignition key) upon request from the owner.
- Specified registration is required when replacing ECM, BCM or Intelligent Key.
- For initialization and registration of Intelligent Keys, refer to CONSULT Immobilizer mode and follow the on-screen instructions.
- Possible symptom of NVIS (NATS) malfunction is "Engine cannot start". The engine can not be started because of other than NVIS (NATS) malfunction, so start the trouble diagnosis according to [SEC-73. "Work Flow"](#).

# SYSTEM

## < SYSTEM DESCRIPTION >

## [WITH INTELLIGENT KEY SYSTEM]

- If ECM other than genuine part is installed, the engine cannot be started. For ECM replacement procedure, refer to [EC-508, "Removal and Installation"](#) (USA and Canada) or [EC-885, "Removal and Installation"](#) (Mexico).

### PRECAUTIONS FOR KEY REGISTRATION

- The ID registration is a procedure that erases the current NVIS (NATS) ID once, and then reregisters a new ID. Therefore before starting the registration operation, collect all registered Intelligent Keys from the customer.
- When registering the Intelligent Key, perform only one procedure to simultaneously register both ID [NVIS (NATS) ID and Intelligent Key ID].

### SECURITY INDICATOR LAMP

- Warns that the vehicle is equipped with NVIS (NATS).
- Security indicator lamp always blinks when the power supply position is any position other than ON.

#### NOTE:

Because security indicator lamp is highly efficient, the battery is barely affected.

### ENGINE START OPERATION WHEN INTELLIGENT KEY IS CONTACTED TO PUSH-BUTTON IGNITION SWITCH

1. When brake pedal is depressed while selector lever is in the P (Park) position, BCM activates NATS antenna amp. that is located behind push-button ignition switch.
2. When Intelligent Key (transponder built-in) backside is contacted to push-button ignition switch, BCM starts NVIS (NATS) ID verification between BCM and Intelligent Key (transponder built-in) via NATS antenna amp.
3. When the NVIS (NATS) ID verification result is OK, buzzer in combination meter sounds and BCM transmits the result to ECM.
4. BCM turns ACC relay ON and transmits ignition power supply ON signal to IPDM E/R.
5. IPDM E/R turns the ignition relay ON and starts the ignition power supply.
6. BCM detects that the selector lever position is P (Park) or N (Neutral).
7. BCM transmits starter request signal to IPDM E/R and turns the starter relay in IPDM E/R ON if BCM judges that the engine start condition\* is satisfied.
8. IPDM E/R turns the starter control relay ON when receiving the starter request signal.
9. Power supply is supplied through the starter relay and the starter control relay to operate the starter motor.
10. When BCM receives feedback signal from ECM indicating that the engine is started, BCM transmits a stop signal to IPDM E/R and stops cranking by turning off the starter motor relay. (If engine start is unsuccessful, cranking stops automatically within 5 seconds.)

\*: For the engine start condition, refer to the table "POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION" below.

### POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION

The power supply position changing operation can be performed with the following operations.

#### NOTE:

- When an Intelligent Key is within the detection area of inside key antenna and when Intelligent Key backside is contacted to push-button ignition switch, it is equivalent to the operations below.
- When starting the engine, the BCM monitors under the engine start conditions:
  - Brake pedal operating condition
  - Selector lever position
  - Vehicle speed

Vehicle speed: less than 4 km/h (2.5 MPH)

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
LOCK → ACC	—	Not depressed	1
LOCK → ACC → ON	—	Not depressed	2
LOCK → ACC → ON → OFF	—	Not depressed	3

# SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
LOCK → START ACC → START ON → START	P (Park) or N (Neutral) position	Depressed	1
Engine is running → OFF	—	—	1

Vehicle speed: 4 km/h (2.5 MPH) or more

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
Engine is running → ACC	—	—	Emergency stop operation
Engine stall return operation while driving	N (Neutral) position	Not depressed	1


Emergency stop operation

- Press and hold the push-button ignition switch for 2 seconds or more.
- Press the push-button ignition switch 3 times or more within 1.5 seconds.

## VEHICLE SECURITY SYSTEM

### VEHICLE SECURITY SYSTEM : System Diagram

INFOID:000000012549530



### VEHICLE SECURITY SYSTEM : System Description

INFOID:000000012549531

- The vehicle security system has two alarm functions (theft warning alarm and panic alarm) and reduces the possibility of a theft or mischief by activating horns and headlamps intermittently.

# SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

## < SYSTEM DESCRIPTION >


- The panic alarm does not start when the theft warning alarm is activating and the panic alarm stops when the theft warning alarm is activated.
- The priority of the functions are as per the following.

Priority	Function
1	Theft warning alarm
2	Panic alarm

## THEFT WARNING ALARM

- The theft warning alarm function activates horns and headlamps intermittently when BCM detects that any door or hood is opened by unauthorized means while the system is in the ARMED state.
- Security indicator lamp on combination meter always blinks when power supply position is any position other than ON. Security indicator lamp blinking warns that the vehicle is equipped with a vehicle security system.

### Operation Flow



No.	System state	Switching condition					
		A	B				
1	DISARMED to PRE-ARMED	When all conditions of A and one condition of B is satisfied.	<table border="1"> <tr> <th>A</th> <th>B</th> </tr> <tr> <td> <ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Closed</li> <li>Hood: Closed</li> </ul> </td> <td> <ul style="list-style-type: none"> <li>All doors are locked by:                             <ul style="list-style-type: none"> <li>Door key cylinder LOCK switch</li> <li>LOCK button of Intelligent Key</li> <li>Door request switch</li> </ul> </li> </ul> </td> </tr> </table>	A	B	<ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Closed</li> <li>Hood: Closed</li> </ul>	<ul style="list-style-type: none"> <li>All doors are locked by:                             <ul style="list-style-type: none"> <li>Door key cylinder LOCK switch</li> <li>LOCK button of Intelligent Key</li> <li>Door request switch</li> </ul> </li> </ul>
A	B						
<ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Closed</li> <li>Hood: Closed</li> </ul>	<ul style="list-style-type: none"> <li>All doors are locked by:                             <ul style="list-style-type: none"> <li>Door key cylinder LOCK switch</li> <li>LOCK button of Intelligent Key</li> <li>Door request switch</li> </ul> </li> </ul>						
2	PRE-ARMED to ARMED	When all of the following conditions are satisfied for 30 seconds.	<table border="1"> <tr> <th>A</th> <th>B</th> </tr> <tr> <td> <ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Locked</li> <li>Hood: Closed</li> </ul> </td> <td></td> </tr> </table>	A	B	<ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Locked</li> <li>Hood: Closed</li> </ul>	
A	B						
<ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Locked</li> <li>Hood: Closed</li> </ul>							
3	ARMED to ALARM	When one condition of A and one condition of B are satisfied.	<table border="1"> <tr> <th>A</th> <th>B</th> </tr> <tr> <td>Intelligent Key: Not used</td> <td> <ul style="list-style-type: none"> <li>Any door: Open</li> <li>Hood: Open</li> </ul> </td> </tr> </table>	A	B	Intelligent Key: Not used	<ul style="list-style-type: none"> <li>Any door: Open</li> <li>Hood: Open</li> </ul>
A	B						
Intelligent Key: Not used	<ul style="list-style-type: none"> <li>Any door: Open</li> <li>Hood: Open</li> </ul>						
4	DISARMED to PRE-RESET	When all conditions of A and one condition of B is satisfied.	<table border="1"> <tr> <th>A</th> <th>B</th> </tr> <tr> <td> <ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Closed</li> <li>Hood: Open</li> </ul> </td> <td> <ul style="list-style-type: none"> <li>All doors are locked by:                             <ul style="list-style-type: none"> <li>Door key cylinder LOCK switch</li> <li>LOCK button of Intelligent Key</li> <li>Door request switch</li> </ul> </li> </ul> </td> </tr> </table>	A	B	<ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Closed</li> <li>Hood: Open</li> </ul>	<ul style="list-style-type: none"> <li>All doors are locked by:                             <ul style="list-style-type: none"> <li>Door key cylinder LOCK switch</li> <li>LOCK button of Intelligent Key</li> <li>Door request switch</li> </ul> </li> </ul>
A	B						
<ul style="list-style-type: none"> <li>Power supply position: OFF/LOCK</li> <li>All doors: Closed</li> <li>Hood: Open</li> </ul>	<ul style="list-style-type: none"> <li>All doors are locked by:                             <ul style="list-style-type: none"> <li>Door key cylinder LOCK switch</li> <li>LOCK button of Intelligent Key</li> <li>Door request switch</li> </ul> </li> </ul>						
5	PRE-ARMED to PRE-RESET	When one of the following conditions is satisfied.	<ul style="list-style-type: none"> <li>Hood: Open</li> </ul>				
6	ARMED to PRE-RESET	No conditions.					
7	ALARM to PRE-RESET						

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# SYSTEM

## < SYSTEM DESCRIPTION >

## [WITH INTELLIGENT KEY SYSTEM]

No.	System state	Switching condition	
8	PRE-RESET to DISARMED	When one of the following conditions is satisfied.	<ul style="list-style-type: none"> <li>• Power supply position: ACC/ON/CRANKING/RUN</li> <li>• Door key cylinder UNLOCK switch: ON</li> <li>• UNLOCK button of Intelligent Key: ON</li> <li>• Door request switch: ON</li> <li>• Back door opener switch: ON</li> <li>• UNLOCK switch of door lock and unlock switch: ON</li> <li>• Any door: Open</li> </ul>
9	PRE-RESET to PRE-ARMED	When all of the following conditions are satisfied.	<ul style="list-style-type: none"> <li>• Power supply position: OFF/LOCK</li> <li>• All doors: Closed</li> <li>• Hood: Closed</li> </ul>
10	PRE-ARMED to DISARMED	When one of the following conditions is satisfied.	<ul style="list-style-type: none"> <li>• Power supply position: ACC/ON/CRANKING/RUN</li> <li>• Door key cylinder UNLOCK switch: ON</li> <li>• UNLOCK button of Intelligent Key: ON</li> <li>• AUTO BACK DOOR button of Intelligent Key: ON</li> <li>• Door request switch: ON</li> <li>• Back door opener switch: ON</li> <li>• Any door: Open</li> </ul>
11	ARMED to DISARMED	When one of the following conditions is satisfied.	<ul style="list-style-type: none"> <li>• Power supply position: ACC/ON/CRANKING/RUN</li> <li>• Door key cylinder UNLOCK switch: ON</li> <li>• UNLOCK button of Intelligent Key: ON</li> <li>• AUTO BACK DOOR button of Intelligent Key: ON</li> <li>• Door request switch: ON</li> <li>• Back door opener switch: ON</li> </ul>
12	ALARM to DISARMED		
13	RE-ALARM	When one of the following conditions is satisfied after the ALARM operation is finished.	<ul style="list-style-type: none"> <li>• Any door: Open</li> <li>• Hood: Open</li> </ul>

### NOTE:

- BCM ignores the door key cylinder UNLOCK switch signal input for 1 second after the door key cylinder LOCK switch signal input.
- To lock/unlock all doors by operating remote controller button of Intelligent Key or door request switch, Intelligent Key must be within the detection area of outside key antenna. For details, refer to [DLK-21. "INTELLIGENT KEY SYSTEM : System Description"](#).
- To open back door by operating back door opener switch, Intelligent Key must be within the detection area of outside key antenna. For details, refer to [DLK-21. "INTELLIGENT KEY SYSTEM : System Description"](#).

### DISARMED Phase

The vehicle security system is not set in the DISARMED phase. The vehicle security system stays in this phase while any door is open because it is assumed that the owner is inside or nearby the vehicle. Security indicator lamp blinks every 2.4 seconds.

When the vehicle security system is reset, each phase switches to the DISARMED phase directly.

### PRE-ARMED Phase

The PRE-ARMED phase is the transient state between the DISARMED phase and the ARMED phase. This phase is maintained for 30 seconds so that the owner can reset the setting due to a mis-operation. This phase switches to the ARMED phase when vehicle conditions are not changed for 30 seconds. Security indicator lamp illuminates while being in this phase.

To reset the PRE-ARMED phase, refer to the switching condition of No. 10 in the table above.

### ARMED Phase

The vehicle security system is set and BCM monitors all necessary inputs. If any door or hood is opened without using Intelligent Key, vehicle security system switches to the ALARM phase. Security indicator lamp blinks every 2.4 seconds.

To reset the ARMED phase, refer to the switching condition of No. 11 in the table above.

### ALARM Phase

BCM transmits "Theft Warning Horn Request" signal and "High Beam Request" signal intermittently to IPDM E/R via CAN communication. In this phase, horns and headlamps are activated intermittently for approximately 50 seconds to warn that the vehicle is accessed by unauthorized means. ON/OFF timing of horns and headlamps are synchronized. After 50 seconds, the vehicle security system returns to the ARMED phase. At this time, if BCM still detects unauthorized access to the vehicle, the system is switched to the ALARM phase again. This RE-ALARM operation is carried out a maximum of 2 times.

To cancel the ALARM operation, refer to the switching condition of No. 12 in the table above.



# SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

## NOTE:

If a battery terminal is disconnected during the ALARM phase, theft warning alarm stops. But when the battery terminal is reconnected, theft warning alarm is activated again.

## PRE-RESET Phase

The PRE-RESET phase is the transient state between each phase and DISARMED phase. If only the condition of hood is not satisfied, the system switches to the PRE-RESET phase. Then, when any condition is changed, the system switches to the DISARMED phase or PRE-ARMED phase.

## PANIC ALARM

- The panic alarm function activates horns and headlamps intermittently when the owner presses the PANIC ALARM button of Intelligent Key outside the vehicle while the power supply position is OFF or LOCK.
- When BCM receives panic alarm signal from Intelligent Key, BCM transmits "Theft Warning Horn Request" signal and "High Beam Request" signal intermittently to IPDM E/R via CAN communication. To prevent the activation due to mis-operation of Intelligent Key by owner, the panic alarm function is activated when BCM receives the signal for 0.4 - 0.6 seconds.
- Panic alarm operation is maintained for 25 seconds.
- Panic alarm operation is cancelled when BCM receives one of the following signals:
  - LOCK button of Intelligent Key: ON
  - UNLOCK button of Intelligent Key: ON
  - PANIC ALARM button of Intelligent Key: Long pressed
  - Any door request switch: ON

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000012958283

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
ECU Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> <li>The vehicle specification can be read and saved.</li> <li>The vehicle specification can be written when replacing BCM.</li> </ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

### SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		×	×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Exterior lamp	HEADLAMP			×	×	×		
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×	×		
Air conditioner	AIR CONDITIONER			×				
Intelligent Key system	INTELLIGENT KEY		×	×	×	×		
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×	×	×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Back door open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

System	Sub System	Direct Diagnostic Mode						
		ECU Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Signal buffer system	SIGNAL BUFFER			×	×			
TPMS	AIR PRESSURE MONITOR		×	×	×			

## INTELLIGENT KEY

### INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000012958284

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

### SELF DIAGNOSTIC RESULT

Refer to [BCS-52, "DTC Index"](#).

### DATA MONITOR

Monitor Item [Unit]	Main	Description
REQ SW -DR [On/Off]	×	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	×	Indicates condition of door request switch RH.
REQ SW -BD/TR [On/Off]	×	Indicates condition of back door request switch.
PUSH SW [On/Off]		Indicates condition of push-button ignition switch.
SHFTLCK SLNID PWR SPLY [On/Off]	×	Indicates condition of power supply to shiftlock solenoid.
BRAKE SW 1 [On/Off]	×	Indicates condition of brake switch.
BRAKE SW 2 [On/Off]		Indicates condition of brake switch.
DETE/CANCL SW [On/Off]	×	Indicates condition of P (park) position.
SFT PN/N SW [On/Off]	×	Indicates condition of P (park) or N (neutral) position.
UNLK SEN -DR [On/Off]	×	Indicates condition of door unlock sensor.
PUSH SW -IPDM [On/Off]		Indicates condition of push-button ignition switch received from IPDM E/R on CAN communication line.
IGN RLY1 -F/B [On/Off]		Indicates condition of ignition relay 1 received from IPDM E/R on CAN communication line.
DETE SW -IPDM [On/Off]		Indicates condition of detent switch received from TCM on CAN communication line.
SFT PN -IPDM [On/Off]		Indicates condition of P (park) or N (neutral) position from TCM on CAN communication line.
SFT P -MET [On/Off]		Indicates condition of P (park) position from TCM on CAN communication line.
SFT N -MET [On/Off]		Indicates condition of N (neutral) position from IPDM E/R on CAN communication line.
ENGINE STATE [STOP/START/CRANK/RUN]	×	Indicates condition of engine state from ECM on CAN communication line.
VEH SPEED 1 [mph/km/h]	×	Indicates condition of vehicle speed signal received from ABS on CAN communication line.
VEH SPEED 2 [mph/km/h]	×	Indicates condition of vehicle speed signal received from combination meter on CAN communication line.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	Main	Description
DOOR STAT-DR [LOCK/READY/UNLK]	×	Indicates condition of driver side door status.
DOOR STAT-AS [LOCK/READY/UNLK]	×	Indicates condition of passenger side door status.
DOOR STAT-RR [LOCK/READY/UNLK]	×	Indicates condition of rear right side door status.
DOOR STAT-RL [LOCK/READY/UNLK]	×	Indicates condition of rear left side door status.
BK DOOR STATE [LOCK/READY/UNLK]	×	Indicates condition of back door status.
ID OK FLAG [Set/Reset]		Indicates condition of Intelligent Key ID.
PRMT ENG STRT [Set/Reset]		Indicates condition of engine start possibility.
PRMT RKE STRT [Set/Reset]		Indicates condition of engine start possibility from Intelligent Key.
I-KEY OK FLAG [Key ON/Key OFF]	×	Indicates condition of Intelligent Key OK flag.
PRBT ENG STRT [Set/Reset]		Indicates condition of engine start prohibit.
ID AUTHENT CANCEL TIMER [STOP]		Indicates condition of Intelligent Key ID authentication.
ACC BATTERY SAVER [STOP]		Indicates condition of battery saver.
CRNK PRBT TMR [On/Off]		Indicates condition of crank prohibit timer.
AUT CRNK TMR [On/Off]		Indicates condition of automatic engine crank timer from Intelligent Key.
CRNK PRBT TME [sec]		Indicates condition of engine crank prohibit time.
AUT CRNK TMR [sec]		Indicates condition of automatic engine crank time from Intelligent Key.
CRANKING TME [sec]		Indicates condition of engine cranking time from Intelligent Key.
DETE SW PWR [On/Off]		Indicates condition of detent switch voltage.
IGN RLY3 -REQ [On/Off]		Indicates condition of front blower motor relay control request.
ACC RLY -REQ [On/Off]		Indicates condition of accessory relay control request.
RKE OPE COUN1 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE OPE COUN2 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE-LOCK [On/Off]		Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]		Indicates condition of unlock signal from Intelligent Key.
RKE-TR/BD [On/Off]		Indicates condition of back door open signal from Intelligent Key.
RKE-PANIC [On/Off]		Indicates condition of panic signal from Intelligent Key.
RKE-MODE CHG [On/Off]		Indicates condition of mode change signal from Intelligent Key.
RKE PBD [On/Off]		Indicates condition of power back door signal from Intelligent Key.

## ACTIVE TEST

Test Item	Description
INTELLIGENT KEY LINK (CAN)	This test is able to check Intelligent Key identification number [Off/ID No1/ID N02/ID No3/ID No4/ID No5].
INT LAMP	This test is able to check interior room lamp operation [On/Off].
FLASHER	This test is able to check hazard lamp operation [LH/RH/Off].
HORN	This test is able to check horn operation [On].
BATTERY SAVER	This test is able to check battery saver operation [On/Off].
TRUNK/BACK DOOR	This test is able to check back door actuator operation [Open].
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation [On/Off].
INSIDE BUZZER	This test is able to check combination meter warning chime operation [Take Out/Knob/Key/Off].
INDICATOR	This test is able to check combination meter warning lamp operation [KEY ON/KEY IND/Off].
IGN CONT2	This test is able to check ignition relay-2 control operation [On/Off].
ENGINE SW ILLUMI	This test is able to check push-button ignition switch START indicator operation [On/Off].

# DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

## < SYSTEM DESCRIPTION >

Test Item	Description
PUSH SWITCH INDICATOR	This test is able to check push-button ignition switch indicator operation [On/Off].
ACC CONT	This test is able to check accessory relay control operation [On/Off].
IGN CONT1	This test is able to check ignition relay-1 control operation [On/Off].
ST CONT LOW	This test is able to check starter control relay operation [On/Off].
IGNITION RELAY	This test is able to check ignition relay operation [On/Off].
REVERSE LAMP TEST	This test is able to check reverse lamp illumination operation [On/Off].
DOOR HANDLE LAMP TEST	This test is able to check door handle lamp illumination operation [On/Off].
TRUNK/LUGGAGE LAMP TEST	This test is able to check cargo lamp illumination operation [On/Off].
KEYFOB P/W TEST	This test is able to check power window operation using the Intelligent Key [P/W up/down OFF/Send P/W down ON/Send P/W up ON].
SHIFTLOCK SORENOID TEST	This test is able to check shift lock solenoid operation [On/Off].

## WORK SUPPORT

Support Item	Setting	Description	
IGN/ACC BATTERY SAVER	On*	Battery saver function ON.	
	Off	Battery saver function OFF.	
REMOTE ENGINE STARTER	On*	Remote engine start function ON.	
	Off	Remote engine start function OFF.	
ANSWER BACK I-KEY LOCK UNLOCK	BUZZER*	Buzzer reminder function by door lock/unlock request switch ON.	
	HORN	Horn chirp reminder function by door lock request switch ON.	
	Off	No reminder function by door lock/unlock request switch.	
	INVALID	This mode is not used.	
ANSWERBACK KEYLESS LOCK UNLOCK	On*	Buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.	
	Off	No buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.	
WELCOME LIGHT OP SET	On*	Door handle lamp function from request switch ON.	
	Off	Door handle lamp function from request switch OFF.	
ANSWER BACK	On*	Horn chirp reminder when doors are locked with Intelligent Key.	
	Off	No horn chirp reminder when doors are locked with Intelligent Key.	
RETRACTABLE MIRROR SET	On	Retractable mirror set ON.	
	Off*	Retractable mirror set OFF.	
CONFIRM KEY FOB ID	—	Intelligent Key ID code registration can be checked.	
LOCK/UNLOCK BY I-KEY	On*	Door lock/unlock function from Intelligent Key ON.	
	Off	Door lock/unlock function from Intelligent Key OFF.	
ENGINE START BY I-KEY	On*	Engine start function from Intelligent Key ON.	
	Off	Engine start function from Intelligent Key OFF.	
TRUNK/GLASS HATCH OPEN	On*	Buzzer reminder function by back door request switch ON.	
	Off	Buzzer reminder function by back door request switch OFF.	
INTELLIGENT KEY LINK SET	On	Intelligent Key link set ON.	
	Off*	Intelligent Key link set OFF.	
SHORT CRANKING OUTPUT	Start	70 msec	Starter motor operation duration times.
		100 msec	
		200 msec	
	End	—	

# DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

## < SYSTEM DESCRIPTION >

Support Item	Setting	Description
INSIDE ANT DIAGNOSIS	—	This function allows inside key antenna self-diagnosis.
AUTO LOCK SET	MODE7	5 min
	MODE6	4 min
	MODE5	3 min
	MODE4	2 min
	MODE3*	1 min
	MODE2	30 sec
	MODE1	Off

\*: Initial Setting

## THEFT ALM

### THEFT ALM : CONSULT Function (BCM - THEFT ALM)

INFOID:0000000012958285

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

## DATA MONITOR

Monitored Item	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
REQ SW -BD/TR [On/Off]	Indicates condition of back door request switch.
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of back door switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
TR/BD OPEN SW [On/Off]	Indicates condition of back door opener switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.
RKE-TR/BD [On/Off]	Indicates condition of back door open signal from Intelligent Key.

## ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [LH/RH/Off].
THEFT IND	This test is able to check security indicator lamp operation [On/Off].
VEHICLE SECURITY HORN	This test is able to check vehicle security horn operation [On].
HEAD LAMP(HI)	This test is able to check vehicle security lamp operation [On].

## WORK SUPPORT

# DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

Support Item	Setting	Description
SECURITY ALARM SET	On	Security alarm ON.
	Off	Security alarm OFF.

## IMMU

IMMU : CONSULT Function (BCM - IMMU)

INFOID:000000012958286

### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

## SELF DIAGNOSTIC RESULT

Refer to [BCS-52. "DTC Index"](#).

## DATA MONITOR

Monitor Item [Unit]	Description
CONFIRM ID ALL [Yet/DONE]	Switches to DONE when an Intelligent Key is registered.
CONFIRM ID4 [Yet/DONE]	
CONFIRM ID3 [Yet/DONE]	
CONFIRM ID2 [Yet/DONE]	
CONFIRM ID1 [Yet/DONE]	
TP 4 [Yet/DONE]	DONE indicates the number of Intelligent Key ID which has been registered.
TP 3 [Yet/DONE]	
TP 2 [Yet/DONE]	
TP 1 [Yet/DONE]	
NOT REGISTERED	Indicates [ID OK] when key ID that is registered is received or is not yet received. Indicates [ID NG] when key ID that is not registered is received.
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.

## ACTIVE TEST

Test Item	Description
THEFT IND	This test is able to check security indicator operation [On/Off].

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

## DIAGNOSIS SYSTEM (IPDM E/R)

### CONSULT Function (IPDM E/R)

INFOID:000000012958287

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
ECU Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

#### ECU IDENTIFICATION

The IPDM E/R part number is displayed.

#### SELF DIAGNOSTIC RESULT

Refer to [PCS-20, "DTC Index"](#).

#### DATA MONITOR

Monitor Item [Unit]	Main Signals	Description
RAD FAN REQ [%]	×	Indicates cooling fan speed signal received from ECM on CAN communication line
AC COMP REQ [On/Off]	×	Indicates A/C compressor request signal received from ECM on CAN communication line
TAIL&CLR REQ [On/Off]	×	Indicates position light request signal received from BCM on CAN communication line
HL LO REQ [On/Off]	×	Indicates low beam request signal received from BCM on CAN communication line
HL HI REQ [On/Off]	×	Indicates high beam request signal received from BCM on CAN communication line
FR FOG REQ [On/Off]	×	Indicates front fog light request signal received from BCM on CAN communication line
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Indicates front wiper request signal received from BCM on CAN communication line
WIP AUTO STOP [STOP P/ACT P]	×	Indicates condition of front wiper auto stop signal
WIP PROT [Off/BLOCK]	×	Indicates condition of front wiper fail-safe operation
IGN RLY1 -REQ [On/Off]		Indicates ignition switch ON signal received from BCM on CAN communication line
IGN RLY [On/Off]	×	Indicates condition of ignition relay
PUSH SW [On/Off]		Indicates condition of push-button ignition switch
INTER/NP SW [On/Off]		Indicates condition of CVT shift position
ST RLY CONT [On/Off]		Indicates starter relay status signal received from BCM on CAN communication line
IHBT RLY -REQ [On/Off]		Indicates starter control relay signal received from BCM on CAN communication line



# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

Monitor Item [Unit]	Main Signals	Description
ST/INHI RLY [Off/ ST /INHI]		Indicates condition of starter relay and starter control relay
DETENT SW [On/Off]		Indicates condition of CVT shift selector (park position switch)
DTRL REQ [Off]		Indicates daytime light request signal received from BCM on CAN communication line
HOOD SW [On/Off]		Indicates condition of hood switch
THFT HRN REQ [On/Off]		Indicates theft warning horn request signal received from BCM on CAN communication line
HORN CHIRP [On/Off]		Indicates horn reminder signal received from BCM on CAN communication line
HOOD SW 2 [On/Off]		Indicates condition of hood switch

## ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [On].
FRONT WIPER	This test is able to check wiper motor operation [Hi/Lo/Off].
MOTOR FAN	This test is able to check cooling fan operation [4/3/2/1].
EXTERNAL LAMPS	This test is able to check external lamp operation [Fog/Hi/Lo/Tail/Off].

## CAN DIAG SUPPORT MNTR

Refer to [LAN-18. "CAN Diagnostic Support Monitor"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# ECU DIAGNOSIS INFORMATION

## ECM, IPDM E/R, BCM

### List of ECU Reference

INFOID:0000000012549537

ECU		Reference
ECM (USA and Canada)	Reference Value	<a href="#">EC-84, "Reference Value"</a>
	Fail-safe	<a href="#">EC-100, "Fail-safe"</a>
	DTC Inspection Priority Chart	<a href="#">EC-102, "DTC Inspection Priority Chart"</a>
	DTC Index	<a href="#">EC-104, "DTC Index"</a>
ECM (Mexico)	Reference Value	<a href="#">EC-575, "Reference Value"</a>
	Fail-safe	<a href="#">EC-589, "Fail-safe"</a>
	DTC Inspection Priority Chart	<a href="#">EC-590, "DTC Inspection Priority Chart"</a>
	DTC Index	<a href="#">EC-592, "DTC Index"</a>
IPDM E/R	Reference Value	<a href="#">PCS-12, "Reference Value"</a>
	Fail-safe	<a href="#">PCS-19, "Fail Safe"</a>
	DTC Index	<a href="#">PCS-20, "DTC Index"</a>
BCM	Reference Value	<a href="#">BCS-31, "Reference Value"</a>
	Fail-safe	<a href="#">BCS-50, "Fail Safe"</a>
	DTC Inspection Priority Chart	<a href="#">BCS-51, "DTC Inspection Priority Chart"</a>
	DTC Index	<a href="#">BCS-52, "DTC Index"</a>

# ENGINE START FUNCTION

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

## WIRING DIAGRAM


### ENGINE START FUNCTION

#### Wiring Diagram

INFOID:0000000012549538

#### INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

(YF) : WITH REQUEST SWITCH



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC


ABKWA3143GB

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

YR : WITH REQUEST SWITCH




ABKWA3144GB

# ENGINE START FUNCTION

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]



ABKWA3145GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >




ABKWA2798GB

# ENGINE START FUNCTION

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]



ABKWA2799GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# ENGINE START FUNCTION

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]


## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2N	BG	-
4N	V	-
5N	Y	-
6N	W	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13P	W	-

Connector No.	M17
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	BG	-
4	B	-
7	P	-
8	G	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	G	ENG START SW
18	V	SECURITY INDICATOR
20	W	SHIFT P
25	W	BRAKE SW FUSE
27	G	BRAKE SW LAMP
39	G	SHIFT N/P

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
59	P	CAN-L
60	L	CAN-H
62	W	STARTER RELAY OUT
69	G	AT DEVICE OUT
70	P	IGN USM OUT 1

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
82	W	RL DOOR SW
93	R	RR DOOR SW
94	G	AS DOOR SW
96	BG	DR DOOR SW
99	P	ROOM ANT 3 B
100	W	ROOM ANT 3 A
101	R	REAR BUMPER ANT B
102	G	REAR BUMPER ANT A




# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	GND1
2	B	GND2
6	V	SECURITY
22	W	BAT
38	P	CAN-L
39	L	CAN-H

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10G	W	-
35G	P	-
36G	L	-
44G	G	-
62G	G	-
63G	P	-
64G	W	-
67G	W	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
15A	R	-
16A	G	-
49A	P	-
50A	W	-
65A	W	-
66A	BG	-
89A	L	-
90A	P	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


SEC

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

Connector No.	M56
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	R	-
18	W	-

Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	M41
Connector Name	JOINT CONNECTOR-M18
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	M80
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
111	P	ACC LED
114	W	AS DOOR ANT A
115	BG	AS DOOR ANT B
116	W	ROOM ANT A
119	R	RF NIMOCO
121	G	DR DOOR ANT B
122	P	DR DOOR ANT A
128	R	ROOM ANT B

Connector No.	M78
Connector Name	CVT SHIFT SELECTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	G	-
6	W	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
9R	G	-
10R	W	-


ABKIA7228GB

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	M86
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	BG	-
2	R	-
3	GR	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-
21	G	-
22	R	-

Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND 2
138	V	BAT REAR DOOR
139	W	BAT POWER F/L
142	Y	BAT FRONT DOOR
143	B	GND 1

Connector No.	M181
Connector Name	JOINT CONNECTOR-M36
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-

Connector No.	M168
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	G	-
12	P	-

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	BG	-
26	W	-

ABKIA7229GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# ENGINE START FUNCTION

< WIRING DIAGRAM >


[WITH INTELLIGENT KEY SYSTEM]

Connector No.	M255
Connector Name	INSIDE KEY ANTENNA (CONSOLE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	M232
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	W	-
11	B	-

Connector No.	M214
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	B	-
18	W	-

Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5M	Y	-
7M	R	-

Connector No.	E14
Connector Name	JOINT CONNECTOR-E05
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	W	-
3	W	-

Connector No.	M259
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10	W	-
11	B	-

ABKIA7230GB

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	E38
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	R	-

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
12	Y	-
13	Y	-

Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
4	L	-
7	P	-
10	P	-

Connector No.	E70
Connector Name	JOINT CONNECTOR-E14
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	E71
Connector Name	JOINT CONNECTOR-E15
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
28	P	CAN-L
29	L	CAN-H
31	BG	DETENT SW
33	R	START CONT
37	W	CLUTCH I/L SW
38	P	PUSH START SW
41	B	GND (SIGNAL)
43	L	IGN SIGNAL

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	3	Color of Wire	G	Signal Name	F/L IGNSW
--------------	---	---------------	---	-------------	-----------

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	7	Color of Wire	B	Signal Name	GND (POWER)
--------------	---	---------------	---	-------------	-------------

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	F17
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	51	Color of Wire	W	Signal Name	STARTER MOTOR
--------------	----	---------------	---	-------------	---------------


ABKIA7232GB

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	L	-

Connector No.	F36
Connector Name	TRANSMISSION RANGE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
7	L	-
10	G	-

Connector No.	F24
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
63	L	INHIBIT SW
66	G	NP SW

Connector No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	B12
Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	B11
Connector Name	JOINT CONNECTOR-B09
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

ABKIA7233GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


SEC

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

Connector No.	B17
Connector Name	JOINT CONNECTOR-B12
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	B18
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	SB	-

Connector No.	B32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
15A	G	-
16A	W	-
49A	G	-
50A	W	-
65A	SB	-
66A	L	-
89A	L	-
90A	P	-

Connector No.	B76
Connector Name	INSIDE KEY ANTENNA (LUGGAGE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	W	-
2	G	-

ABKIA7234GB



# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	B102
Connector Name	JOINT CONNECTOR-B14
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-
21	LG	-
22	LG	-

Connector No.	B77
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	W	-
10	G	-

Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	LG	-

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	LG	-

Connector No.	B103
Connector Name	JOINT CONNECTOR-B05
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

ABKIA7235GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# ENGINE START FUNCTION

< WIRING DIAGRAM >


[WITH INTELLIGENT KEY SYSTEM]

Connector No.	B403
Connector Name	OUTSIDE KEY ANTENNA (REAR BUMPER)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	W	-
2	G	-

Connector No.	B400
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
9	W	-
10	G	-

Connector No.	B124
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
25	Y	-
26	LG	-

Connector No.	D15
Connector Name	FRONT OUTSIDE HANDLE ASSEMBLY LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	Y	-

Connector No.	D3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	Y	-
12	LG	-

ABKIA7236GB

# ENGINE START FUNCTION


< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

Connector No.	D115
Connector Name	FRONT OUTSIDE HANDLE ASSEMBLY RH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	Y	-

ABKIA7237GB

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS


< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

### Wiring Diagram

INFOID:000000012549539




NVIS

ABKWA2800GB

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


SEC

ABKWA3146GB

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]




ABKWA2801GB

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]



ABKWA2802GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC


# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

## NVIS CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2N	BG	-
6N	W	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13P	W	-

Connector No.	M17
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	BG	-
4	B	-
7	P	-
8	G	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
1	G	ENG START SW
18	V	SECURITY INDICATOR
20	W	SHIFT P
25	W	BRAKE SW FUSE
27	G	BRAKE SW LAMP
39	G	SHIFT N/P

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
52	W	AUDIO DONGLE
59	P	CAN-L
60	L	CAN-H
62	W	STARTER RELAY OUT
69	G	AT DEVICE OUT
70	P	IGN USM OUT 1

Connector No.	M21
Connector Name	NATS ANTENNA AMP.
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BG	-
3	P	-




# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS


< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M29
Connector Name	DONGLE UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
4	B	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND1
2	B	GND2
6	V	SECURITY
22	W	BAT
38	P	CAN-L
39	L	CAN-H

Terminal No.	Color of Wire	Signal Name
10G	W	-
35G	P	-
36G	L	-
44G	G	-
62G	G	-
63G	P	-
64G	W	-
67G	W	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

ABKIA6389GB

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]


Connector No.	M41
Connector Name	JOINT CONNECTOR-M18
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
89A	L	-
90A	P	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	M78
Connector Name	CVT SHIFT SELECTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	G	-
6	W	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
9R	G	-
10R	W	-

Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-



ABKIA4736GB

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >



[WITH INTELLIGENT KEY SYSTEM]

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-

Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND 2
139	W	BAT POWER F/L
143	B	GND 1

Connector No.	M80
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
111	P	ACC LED
126	P	IMMO START BUTTON ANT B
127	BG	IMMO START BUTTON ANT A

Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5M	Y	-
7M	R	-

Connector No.	E14
Connector Name	JOINT CONNECTOR-E05
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
2	W	-
3	W	-

Connector No.	M181
Connector Name	JOINT CONNECTOR-M36
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-

AAKIA0933GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >


[WITH INTELLIGENT KEY SYSTEM]

Connector No.	E38
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	R	-

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
12	Y	-
13	Y	-

Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
4	L	-
7	P	-
10	P	-

Connector No.	E70
Connector Name	JOINT CONNECTOR-E14
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	E71
Connector Name	JOINT CONNECTOR-E15
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
28	P	CAN-L
29	L	CAN-H
31	BG	DETENT SW
33	R	START CONT
37	W	CLUTCH I/L SW
38	P	PUSH START SW
41	B	GND (SIGNAL)
43	L	IGN SIGNAL

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

Connector No.	E121	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Signal Name
Connector Name			
Connector Color	WHITE		

<table border="1" style="border-collapse: collapse;"> <tr><td style="padding: 2px;">7</td><td style="padding: 2px;">8</td><td style="padding: 2px;">9</td><td style="padding: 2px;">10</td><td style="padding: 2px;">11</td></tr> <tr><td style="padding: 2px;">12</td><td style="padding: 2px;">13</td><td style="padding: 2px;">14</td><td style="padding: 2px;">15</td><td style="padding: 2px;">16</td><td style="padding: 2px;">17</td><td style="padding: 2px;">18</td></tr> </table>	7	8	9	10	11	12	13	14	15	16	17	18	<table border="1" style="border-collapse: collapse;"> <tr><td style="padding: 2px;">Color of Wire</td><td style="padding: 2px;">Signal Name</td></tr> <tr><td style="padding: 2px;">B</td><td style="padding: 2px;">GND (POWER)</td></tr> </table>	Color of Wire	Signal Name	B	GND (POWER)
7	8	9	10	11													
12	13	14	15	16	17	18											
Color of Wire	Signal Name																
B	GND (POWER)																

Connector No.	E120	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Signal Name
Connector Name			
Connector Color	WHITE		


<table border="1" style="border-collapse: collapse;"> <tr><td style="padding: 2px;">3</td><td style="padding: 2px;">4</td></tr> <tr><td style="padding: 2px;">5</td><td style="padding: 2px;">6</td></tr> </table>	3	4	5	6	<table border="1" style="border-collapse: collapse;"> <tr><td style="padding: 2px;">Color of Wire</td><td style="padding: 2px;">Signal Name</td></tr> <tr><td style="padding: 2px;">G</td><td style="padding: 2px;">F/L IGNSW</td></tr> </table>	Color of Wire	Signal Name	G	F/L IGNSW
3	4								
5	6								
Color of Wire	Signal Name								
G	F/L IGNSW								

Connector No.	F17	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	Signal Name
Connector Name			
Connector Color	BLACK		

<table border="1" style="border-collapse: collapse;"> <tr><td style="padding: 2px;">51</td></tr> </table>	51	<table border="1" style="border-collapse: collapse;"> <tr><td style="padding: 2px;">Color of Wire</td><td style="padding: 2px;">Signal Name</td></tr> <tr><td style="padding: 2px;">W</td><td style="padding: 2px;">STARTER MOTOR</td></tr> </table>	Color of Wire	Signal Name	W	STARTER MOTOR
51						
Color of Wire	Signal Name					
W	STARTER MOTOR					

Terminal No.	Color of Wire	Signal Name
10G	P	-
35G	P	-
36G	L	-
44G	W	-
62G	P	-
63G	L	-
64G	R	-
67G	BG	-



ABKIA7239GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

Connector No.	B11
Connector Name	JOINT CONNECTOR-B09
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	F36
Connector Name	TRANSMISSION RANGE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
7	L	-
10	G	-

Connector No.	F24
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
63	L	INHIBIT SW
66	G	NP SW

Connector No.	B17
Connector Name	JOINT CONNECTOR-B12
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	B12
Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

ABKIA6391GB

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >


Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
89A	L	-
90A	P	-

Connector No.	B32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
32	31	30	29	28	27	26	25	24	23	22	21	20	19	18	17

Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

Connector No.	B124
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

Connector No.	B103
Connector Name	JOINT CONNECTOR-B05
Connector Color	WHITE



4	3	2	1
---	---	---	---

Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	B102
Connector Name	JOINT CONNECTOR-B14
Connector Color	WHITE



4	3	2	1
---	---	---	---

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

ABK1A6392GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# VEHICLE SECURITY SYSTEM


[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

## VEHICLE SECURITY SYSTEM

### Wiring Diagram

INFOID:000000012549540




ABKWA2803GB



# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >



ABKWA2804GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >



# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

ABKWA2806GB


# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

## VEHICLE SECURITY SYSTEM CONNECTORS

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4N	V	-
5N	Y	-
6N	W	-

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13P	W	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
18	V	SECURITY INDICATOR
19	Y	CENTRAL DOOR LOCK SW
24	SB	DOOR KEY/C UNLOCK SW
34	BR	CENTRAL DOOR UNLOCK SW

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
54	W	PW LIN/COM
59	P	CAN-L
60	L	CAN-H
70	P	IGN USM OUT 1
71	R	DR REQUEST SW
72	G	AS REQUEST SW
74	BR	DOOR KEY/C LOCK SW

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
82	W	RL DOOR SW
83	BG	BACK DOOR REQUEST SW
93	R	RR DOOR SW
94	G	AS DOOR SW
96	BG	DR DOOR SW
97	W	BACK DOOR SW
101	R	REAR BUMPER ANT B
102	G	REAR BUMPER ANT A

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	V	SECURITY
22	W	BAT

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	M41
Connector Name	JOINT CONNECTOR-M18
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
65A	W	-
66A	BG	-
89A	L	-
90A	P	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10G	W	-
35G	P	-
36G	L	-
63G	P	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC


ABKIA4741GB

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	M80
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
114	W	AS DOOR ANT A
115	BG	AS DOOR ANT B
121	G	DR DOOR ANT B
122	P	DR DOOR ANT A

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
12	W	-

Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
27	BR	-
28	Y	-
31	W	-

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-
21	G	-
22	R	-

Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND 2
138	V	BAT REAR DOOR
139	W	BAT POWER F/L
142	Y	BAT FRONT DOOR
143	B	GND 1


ABKIA6394GB

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	M158
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	B	-

Connector No.	M167
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	B	-

Connector No.	M168
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	Y	-
3	BR	-
21	SB	-
39	W	-

Connector No.	M170
Connector Name	JOINT CONNECTOR-M09
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
28	W	-
29	W	-
30	W	-

Connector No.	M181
Connector Name	JOINT CONNECTOR-M36
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	W	-
2	W	-

Connector No.	E3
Connector Name	ANTI THEFT DIODE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	Y	-

ABKIA4743GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


SEC

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
4	L	-
7	P	-
10	P	-

Connector No.	E14
Connector Name	JOINT CONNECTOR-E05
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
7	Y	-
8	Y	-

Connector No.	E5
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	G	-

Connector No.	E71
Connector Name	JOINT CONNECTOR-E15
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	E70
Connector Name	JOINT CONNECTOR-E14
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

ABKIA4744GB




# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >


Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	B	GND (POWER)

Terminal No.	Color of Wire	Signal Name
23	LG	HORN SW
28	P	CAN-L
29	L	CAN-H
41	B	GND (SIGNAL)
43	L	IGN SIGNAL

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Connector No.	E205
Connector Name	HOOD SWITCH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	R	-
3	B	-

Terminal No.	Color of Wire	Signal Name
10G	P	-
35G	P	-
36G	L	-
63G	L	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



ABKIA4775GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	E220
Connector Name	HORN (HIGH)
Connector Color	BLACK




Terminal No.	1	Color of Wire	G	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	94	Color of Wire	LG	Signal Name	HOODSW 2
	96		R		HOODSW

Connector No.	E207
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	8	Color of Wire	G	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	E223
Connector Name	HORN (LOW)
Connector Color	BLACK



Terminal No.	2	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	E222
Connector Name	HORN (LOW)
Connector Color	BLACK



Terminal No.	1	Color of Wire	G	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	E221
Connector Name	HORN (HIGH)
Connector Color	BLACK



Terminal No.	2	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---

AAKIA0957GB

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

Connector No.	B12
Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	B11
Connector Name	JOINT CONNECTOR-B09
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	B8
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	L	-

Connector No.	B18
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	SB	-

Connector No.	B17
Connector Name	JOINT CONNECTOR-B12
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

AAKIA0958GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


SEC

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	B32
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
12	G	-

Connector No.	B46
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
11	G	-
23	GR	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
65A	SB	-
66A	L	-
89A	L	-
90A	P	-

Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-
21	LG	-
22	LG	-


ABKIA4745GB

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	3	Color of Wire	LG	Signal Name	-
--------------	---	---------------	----	-------------	---

Connector No.	B103
Connector Name	JOINT CONNECTOR-B05
Connector Color	WHITE




Terminal No.	1	Color of Wire	P	Signal Name	-
2	P	-	-		

Connector No.	B102
Connector Name	JOINT CONNECTOR-B14
Connector Color	WHITE



Terminal No.	1	Color of Wire	L	Signal Name	-
2	L	-	-		

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	3	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	B124
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	18	Color of Wire	L	Signal Name	-
19	P	-	-		

Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	3	Color of Wire	LG	Signal Name	-
--------------	---	---------------	----	-------------	---

ABKIA6395GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


SEC

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	D23
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT FRONT ONLY AUTO DOWN)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	GND
3	Y	LOCK CDL
15	BR	UNLOCK CDL

Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	B	-
5	SB	-
6	BR	-

Connector No.	D3
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	BR	-
2	Y	-
3	BR	-
21	SB	-
39	Y	-

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
27	BR	-
28	Y	-
31	Y	-

Connector No.	D25
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH (WITH LEFT AND RIGHT FRONT AUTO UP/DOWN)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
3	BR	KEY CYL LOCK
11	Y	COM
15	SB	UNLOCK CDL



ABKIA6396GB

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]



< WIRING DIAGRAM >

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	P	-(WITH POWER BACK DOOR)
11	LG	-(WITHOUT POWER BACK DOOR)
23	B	-

Connector No.	D129
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT AND RIGHT FRONT AUTO UP/DOWN)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	Y	COM
7	B	GND

Connector No.	D125
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH (WITH LEFT FRONT ONLY AUTO DOWN)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	BR	-
3	B	-

Connector No.	D557
Connector Name	BACK DOOR LOCK ASSEMBLY (WITH POWER BACK DOOR)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	G	-
8	B	-

Connector No.	D552
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
6	B	-
12	G	-

Connector No.	D507
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
6	B	-
12	P	-(WITH POWER BACK DOOR)
12	LG	-(WITHOUT POWER BACK DOOR)

ABKIA6397GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


SEC

# VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

Connector No.	D565
Connector Name	BACK DOOR LOCK ASSEMBLY (WITHOUT POWER BACK DOOR)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	G	-
4	B	-

ABKIA7243GB



# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[WITH INTELLIGENT KEY SYSTEM]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000012549541

OVERALL SEQUENCE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

DETAILED FLOW

# DIAGNOSIS AND REPAIR WORK FLOW

[WITH INTELLIGENT KEY SYSTEM]

< BASIC INSPECTION >

---

## 1. GET INFORMATION FOR SYMPTOM

---

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

---

## 2. CHECK DTC

---

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

---

## 3. CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

---

## 4. CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

---

## 5. PERFORM DTC CONFIRMATION PROCEDURE

---

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-51. "DTC Inspection Priority Chart"](#) and determine trouble diagnosis order.

**NOTE:**

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.  
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-47. "Intermittent Incident"](#).

---

## 6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

---

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

---

## 7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

---

# DIAGNOSIS AND REPAIR WORK FLOW

[WITH INTELLIGENT KEY SYSTEM]

< BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-47. "Intermittent Incident"](#).

## 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

## 9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

< BASIC INSPECTION >

[WITH INTELLIGENT KEY SYSTEM]

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ECM

##### ECM : Description

INFOID:0000000012549542

Performing the following procedure can automatically activate recommunication of ECM and BCM, but only when the ECM is replaced with a new one\*.

\*: New one means an ECM that has never been energized on-board.

(In this step, initialization procedure by CONSULT is not necessary)

##### NOTE:

- If multiple keys are attached to the key holder, separate them before beginning work.
- Distinguish keys with unregistered key IDs from those with registered IDs.

##### ECM : Work Procedure

INFOID:0000000012549543

#### 1. PERFORM ECM RECOMMUNICATING FUNCTION

1. Install ECM.
2. Contact backside of registered Intelligent Key\* to push-button ignition switch, then turn ignition switch to ON.  
\*: To perform this step, use the key that is used before performing ECM replacement.
3. Maintain ignition switch in the ON position for at least 5 seconds.
4. Turn ignition switch to OFF.
5. Check that the engine starts.

>> GO TO 2.

#### 2. PERFORM ADDITIONAL SERVICE WHEN REPLACING ECM

Perform [EC-154. "Work Procedure"](#) (USA and Canada) or [EC-639. "Work Procedure"](#) (Mexico).

>> END

#### BCM

##### BCM : Description

INFOID:0000000012958288

##### BEFORE REPLACEMENT

When replacing BCM, save or print current vehicle specification with CONSULT configuration before replacement.

##### NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

##### AFTER REPLACEMENT

##### CAUTION:

- When replacing BCM, you must perform "After Replace ECU" with CONSULT.
- Complete the procedure of "After Replace ECU" in order.
- If you set incorrect "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- When replacing BCM, perform the system initialization (NATS).

##### BCM : Work Procedure

INFOID:0000000012958289

#### 1. SAVING VEHICLE SPECIFICATION

##### CONSULT

Enter "Re/Programming, Configuration" and perform "Before Replace ECU" to save or print current vehicle specification.

##### NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

## ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

< BASIC INSPECTION >

[WITH INTELLIGENT KEY SYSTEM]

>> GO TO 2.

### 2. REPLACE BCM

Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

>> GO TO 3.

### 3. WRITING VEHICLE SPECIFICATION

#### CONSULT

1. Enter "Re/Programming, Configuration".
2. If "Before Replace ECU" operation was performed, automatically an "Operation Log Selection" screen will be displayed. Select the applicable file from the "Saved Data List" and press "Confirm" to write vehicle specification. Refer to [BCS-65, "CONFIGURATION \(BCM\) : Work Procedure"](#).
3. If "Before Replace ECU" operation was not performed, select "After Replace ECU" or "Manual Configuration" to write vehicle specification. Refer to [BCS-65, "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 4.

### 4. REGISTER INTELLIGENT KEYS

For initialization and registration of Intelligent Keys, refer to CONSULT Immobilizer mode and follow the on-screen instructions.

>> Work End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# DTC/CIRCUIT DIAGNOSIS

## P1610 LOCK MODE

### Description

INFOID:0000000012549546

ECM forcibly switches to the mode that inhibits engine start, when engine start operation is performed 5 times or more while communication between ECM and BCM is not normal.

### DTC Logic

INFOID:0000000012549547

### DTC DETECTION LOGIC

**NOTE:**

- If DTC P1610 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC P1610 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1610	LOCK MODE	When ECM detects a communication malfunction between ECM and BCM 5 times or more.	—

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self-Diagnostic Result" mode of "ENGINE" using CONSULT.

**Is DTC detected?**

- YES >> Go to [SEC-78, "Diagnosis Procedure"](#).
- NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012549548

#### 1. CHECK ENGINE START FUNCTION

1. Check that there are no DTC's except for DTC P1610 detected.  
If detected, erase the DTC after fixing.
2. Turn ignition switch OFF.
3. Contact the registered Intelligent Key backside to push-button ignition switch and wait 5 seconds.
4. Turn ignition switch ON.
5. Turn ignition switch OFF and wait 5 seconds.
6. Repeat steps 3 and 5 twice (a total of 3 times).
7. Check that engine can start.

>> Inspection End.

# P1611 ID DISCORD, IMMUECM

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## P1611 ID DISCORD, IMMUECM

### DTC Logic

INFOID:000000012549549

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1611	ID DISCORD, IMMUECM	The ID verification results between BCM and ECM are NG.	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• BCM</li><li>• ECM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self-Diagnostic Result" mode of "ENGINE" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-79, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549550

#### 1. PERFORM INITIALIZATION

Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with reregistered Intelligent Key?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2. CHECK SELF DIAGNOSTIC RESULT

1. Select "Self Diagnostic Result" mode of "ENGINE" using CONSULT.
2. Erase DTC.
3. Perform DTC CONFIRMATION PROCEDURE for DTC P1611. Refer to [SEC-79, "DTC Logic"](#).

#### Is DTC detected?

- YES >> GO TO 3.  
NO >> Inspection End.

#### 3. REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with registered Intelligent Key?

- YES >> Inspection End.  
NO >> GO TO 4.

#### 4. REPLACE ECM

1. Replace ECM. Refer to [EC-508, "Removal and Installation"](#) (USA and Canada) or [EC-885, "Removal and Installation"](#) (Mexico).
2. Perform "ADDITIONAL SERVICE WHEN REPLACING ECM". Refer to [EC-154, "Work Procedure"](#) (USA and Canada) or [EC-639, "Work Procedure"](#) (Mexico).

>> Inspection End.

# P1612 CHAIN OF ECM-IMMU

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## P1612 CHAIN OF ECM-IMMU

### DTC Logic

INFOID:000000012549551

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC P1612 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC P1612 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1612	CHAIN OF BCM-ECM	Inactive communication between BCM and ECM	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• ECM</li><li>• BCM</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> Go to [SEC-80, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:000000012549552

##### 1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT.

Check BCM power supply and ground circuit. Refer to [BCS-74, "Diagnosis Procedure"](#).

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace the harness.

##### 2. CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.

Check ECM power supply and ground circuit. Refer to [EC-188, "Diagnosis Procedure"](#) (USA and Canada) or [EC-666, "Diagnosis Procedure"](#) (Mexico).

##### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace the harness.

##### 3. PERFORM DTC CONFIRMATION PROCEDURE.

Perform the DTC confirmation procedure. Refer to [SEC-80, "DTC Logic"](#).

##### Does the DTC return?

- YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).  
NO >> Inspection End.



# P1614 CHAIN OF IMMU-KEY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## P1614 CHAIN OF IMMU-KEY

### DTC Logic

INFOID:000000012549553

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1614	CHAIN OF IMMU-KEY	Inactive communication between NATS antenna amp. and BCM	<ul style="list-style-type: none"><li>• Harness or connectors (NATS antenna amp. circuit is open or shorted.)</li><li>• NATS antenna amp.</li><li>• BCM</li><li>• Intellegent Key fob</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE 1

1. Contact Intelligent Key back side to push-button ignition switch.
2. Check DTC in "Self-Diagnostic Result" mode of "ENGINE" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-81. "Diagnosis Procedure"](#).  
NO >> GO TO 2.

#### 2.PERFORM DTC CONFIRMATION PROCEDURE 2

1. Press the push-button ignition switch.
2. Check DTC in "Self-Diagnostic Result" mode of "ENGINE" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-81. "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549554

Regarding Wiring Diagram information, refer to [SEC-44. "Wiring Diagram"](#).

SEC

#### 1.CONNECTOR INSPECTION

1. Disconnect BCM and NATS antenna amp.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace as necessary.

#### 2.CHECK NATS ANTENNA AMP. CIRCUIT

1. Disconnect BCM connector and NATS antenna amp. connector.
2. Check continuity between BCM harness connector and NATS antenna amp. harness connector.

BCM		NATS antenna amp.		Continuity
Connector	Terminal	Connector	Terminal	
M80	126	M21	3	Yes
	127		1	

3. Check continuity between BCM harness connector and ground.

# P1614 CHAIN OF IMMU-KEY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

BCM		Ground	Continuity
Connector	Terminal		
M80	126		No
	127		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

## 3. CHECK NATS ANTENNA AMP INPUT SIGNAL

1. Turn ignition switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M80	126, 127	Ground	When Intelligent Key is in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA3839GB</p>
			When Intelligent Key is not in the antenna detection area	 <p style="text-align: right; font-size: small;">JMKIA5951GB</p>

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Replace NATS antenna amp. Refer to [SEC-152, "Removal and Installation"](#).

# B210B STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B210B STARTER CONTROL RELAY

### DTC Logic

INFOID:0000000012549555

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B210B is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B210B is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B210B	START CONT RLY ON	When comparing the following items, IPDM E/R detects that starter control relay is stuck in the ON position for 1 second or more: <ul style="list-style-type: none"><li>• Starter control relay signal (CAN) from BCM.</li><li>• Starter relay status signal (CAN) from BCM.</li><li>• Starter control relay and starter relay status signal (IPDM E/R input).</li><li>• Starter control relay control signal (IPDM E/R output).</li></ul>	<ul style="list-style-type: none"><li>• IPDM E/R</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the power supply position to start under the following conditions and wait for at least 1 second:
  - CVT selector lever is in the P (Park) or N (Neutral) position.
  - Depress the brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-83, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012549556

#### 1. INSPECTION START

Perform "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

#### Is display history of DTC B210B CRNT?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
NO >> Refer to [GI-47, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B210C STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B210C STARTER CONTROL RELAY

### DTC Logic

INFOID:000000012549557

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B210C is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B210C is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).
- When IPDM E/R power supply voltage is low (Approx. 7 - 8 V for about 1 second), the DTC B210C may be detected.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B210C	START CONT RLY OFF CIRC	When comparing the following items, IPDM E/R detects that starter control relay is stuck in the OFF position for 1 second or more: <ul style="list-style-type: none"> <li>• Starter control relay signal (CAN) from BCM.</li> <li>• Starter relay status signal (CAN) from BCM.</li> <li>• Starter control relay and starter relay status signal (IPDM E/R input).</li> <li>• Starter control relay control signal (IPDM E/R output).</li> </ul>	<ul style="list-style-type: none"> <li>• IPDM E/R</li> <li>• BCM</li> <li>• Battery</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the power supply position to start under the following conditions and wait for at least 1 second:
  - CVT selector lever is in the P (Park) or N (Neutral) position.
  - Depress the brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-84, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549558

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. PERFORM SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

#### Is display history of DTC B210C CRNT?

- YES >> GO TO 2.  
NO >> Refer to [GI-47, "Intermittent Incident"](#).

#### 2. CHECK STARTER CONTROL RELAY CONTROL CIRCUITS VOLTAGE

Check voltage between IPDM E/R connectors and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E119	33	—	Battery voltage

#### Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
NO >> GO TO 3.

# B210C STARTER CONTROL RELAY

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## 3. CHECK STARTER CONTROL RELAY CONTROL CIRCUIT CONTINUITY

1. Disconnect IPDM E/R connector E119 and BCM connector M19.
2. Check continuity between IPDM E/R connector E119 and BCM connector M19.

IPDM E/R		BCM		Continuity
Connector	Terminal	Connector	Terminal	
E119	33	M19	62	Yes

3. Check continuity between IPDM E/R connector E119 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E119	33	—	No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).  
NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B210D STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B210D STARTER RELAY

### DTC Logic

INFOID:000000012549559

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B210D is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B210D is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).
- If DTC B210D is displayed with DTC B2617, first perform the trouble diagnosis for DTC B2617. Refer to [SEC-130, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B210D	STARTER RELAY ON CIRC	When comparing the following items, IPDM E/R detects that starter control relay is stuck in the ON position for 5 second or more: <ul style="list-style-type: none"><li>• Starter control relay signal (CAN) from BCM.</li><li>• Starter relay status signal (CAN) from BCM.</li><li>• Starter control relay and starter relay status signal (IPDM E/R input).</li><li>• Starter control relay control signal (IPDM E/R output).</li></ul>	<ul style="list-style-type: none"><li>• Harness or connectors (starter motor relay control circuit open or short).</li><li>• IPDM E/R</li><li>• BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Ignition switch ON under the following conditions and wait for at least 1 second:
  - CVT selector lever is in the P (Park) or N (Neutral) position.
  - Do not depress the brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-86, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549560

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. PERFORM SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

#### Is display history of DTC B210D CRNT?

- YES >> GO TO 2.  
NO >> Refer to [GI-47, "Intermittent Incident"](#).

#### 2. CHECK STARTER CONTROL RELAY CONTROL CIRCUITS VOLTAGE

Check voltage between IPDM E/R connectors and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E119	33	—	Battery voltage

#### Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
NO >> GO TO 3.

# B210D STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## 3. CHECK STARTER CONTROL RELAY CONTROL CIRCUIT CONTINUITY

1. Disconnect IPDM E/R connectors E119 and BCM connector M19.
2. Check continuity between IPDM E/R connector E119 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E119	33	—	No

Is the inspection result normal?

- YES >> Refer to [SEC-128. "Diagnosis Procedure"](#).  
NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B210E STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B210E STARTER RELAY

### DTC Logic

INFOID:000000012549561

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B210E is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B210E is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).
- When IPDM E/R power supply voltage is low (Approx. 7 - 8 V for about 1 second), the DTC B210F may be detected.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B210E	STARTER RELAY OFF	When comparing the following items, IPDM E/R detects that starter control relay is stuck in the OFF position for 5 second or more: <ul style="list-style-type: none"><li>• Starter control relay signal (CAN) from BCM.</li><li>• Starter relay status signal (CAN) from BCM.</li><li>• Starter control relay and starter relay status signal (IPDM E/R input).</li><li>• Starter control relay control signal (IPDM E/R output).</li></ul>	<ul style="list-style-type: none"><li>• IPDM E/R</li><li>• BCM</li><li>• Battery</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions and wait for at least 1 second:
  - CVT selector lever is in the P (Park) or N (Neutral) position.
  - Do not depress the brake pedal.
2. Check "Self Diagnostic Result" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [SEC-88, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:000000012549562

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

##### 1. PERFORM SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

##### Is display history of DTC B210E CRNT?

- YES >> GO TO 2.  
NO >> Refer to [GI-47, "Intermittent Incident"](#).

##### 2. CHECK STARTER CONTROL RELAY CONTROL CIRCUITS VOLTAGE

Check voltage between IPDM E/R connectors and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E119	33	—	Battery voltage

##### Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
NO >> GO TO 3.



# B210E STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## 3. CHECK STARTER CONTROL RELAY CONTROL CIRCUIT CONTINUITY

1. Disconnect IPDM E/R connector E119 and BCM connector M19
2. Check continuity between IPDM E/R connector E119 and BCM connector M19.

IPDM E/R		BCM		Continuity
Connector	Terminal	Connector	Terminal	
E119	33	M19	62	Yes

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-81. "Removal and Installation"](#).  
NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B210F TRANSMISSION RANGE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B210F TRANSMISSION RANGE SWITCH

### Description

INFOID:0000000012549563

IPDM E/R confirms the shift position with the following signals.

- Transmission range switch
- Shift position signal from BCM (CAN)

### DTC Logic

INFOID:0000000012549564

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B210F is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#)
- If DTC B210F is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B210F	TRANSMISSION RANGE SWITCH	IPDM E/R detects a mismatch between the signals below for 1 second or more. <ul style="list-style-type: none"><li>• Transmission range switch input signal</li><li>• Shift position signal from BCM (CAN)</li></ul>	<ul style="list-style-type: none"><li>• Harness or connectors</li><li>• Transmission range switch circuit is open or shorted</li><li>• Transmission range switch</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions and wait for at least 1 second.
  - CVT selector lever is in the P (Park) or N (Neutral) position
  - Do not depress the brake pedal
2. Check "Self-diagnostic result" with CONSULT.

##### Is DTC detected?

- YES >> Refer to [SEC-90, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012549565

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#) or [PCS-21, "Wiring Diagram"](#).

##### 1. CHECK DTC WITH BCM

Refer to [BCS-52, "DTC Index"](#).

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace malfunctioning parts.

##### 2. CHECK TRANSMISSION RANGE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Turn ignition switch ON.
4. Check voltage between IPDM E/R harness connector E119 terminal 37 and ground under following condition.

# B210F TRANSMISSION RANGE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

IPDM E/R		Ground	Condition		Voltage (V)
Connector	Terminal				
E119	37	Ground	CVT selector lever	P (Park) or N (Neutral)	Battery voltage
				Other than above	0

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> GO TO 3.

## 3. CHECK TRANSMISSION RANGE SWITCH CIRCUIT FOR CONTINUITY

- Turn ignition switch OFF.
- Check continuity between IPDM E/R harness connector terminals 63 and 66.

IPDM E/R			Condition	Continuity	
Connector	Terminals				
F24	63	66	Transmission range switch	P or N	Yes
				Other	No

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

## 4. CHECK TRANSMISSION RANGE SWITCH CIRCUIT FOR SHORT

Check continuity between IPDM E/R harness connector terminals 63, 66 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
F24	63	Ground	No
	66		

Is the inspection result normal?

YES >> Replace the IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> Repair or replace harness.

## 5. CHECK TRANSMISSION RANGE SWITCH INPUT SIGNAL CIRCUIT

- Disconnect transmission range switch harness connector.
- Check continuity between transmission range switch and IPDM E/R harness connectors.

Transmission range switch		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F36	7	F24	63	Yes
	10		66	

- Check continuity between transmission range switch harness connector and ground.

Transmission range switch		Ground	Continuity
Connector	Terminal		
F36	7	Ground	No
	10		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## B210F TRANSMISSION RANGE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

---

### 6. CHECK INTERMITTENT INCIDENT

---

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

# B2110 TRANSMISSION RANGE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2110 TRANSMISSION RANGE SWITCH

### Description

INFOID:0000000012549566

IPDM E/R confirms the shift position with the following signals.

- Transmission range switch
- Shift position signal from BCM (CAN)

### DTC Logic

INFOID:0000000012549567

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2110 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2110 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2110	TRANSMISSION RANGE SWITCH	IPDM E/R detects mismatch between the signal below for 1 second or more. <ul style="list-style-type: none"><li>• Transmission range switch input signal</li></ul>	<ul style="list-style-type: none"><li>• Harness or connectors</li><li>• Transmission range switch circuit is open or shorted</li><li>• Transmission range switch</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the ignition switch ON under the following conditions and wait for at least 1 second.
  - CVT selector lever is in the P (Park) or N (Neutral) position
  - Do not depress the brake pedal
2. Check "Self-diagnostic result" with CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-93, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012549568

SEC

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#) or [PCS-21, "Wiring Diagram"](#).

#### 1. CHECK DTC WITH BCM

Refer to [BCS-52, "DTC Index"](#).

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace malfunctioning parts.

#### 2. CHECK TRANSMISSION RANGE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R harness connector.
3. Turn ignition switch ON.
4. Check voltage between IPDM E/R harness connector E119 terminal 37 and ground under following condition.

# B2110 TRANSMISSION RANGE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

IPDM E/R		Ground	Condition		Voltage (V)
Connector	Terminal				
E119	37	Ground	CVT selector lever	P (Park) or N (Neutral)	Battery voltage
				Other than above	0

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> GO TO 3.

## 3. CHECK TRANSMISSION RANGE SWITCH CIRCUIT FOR CONTINUITY

1. Turn ignition switch OFF.
2. Check continuity between IPDM E/R harness connector terminals 63 and 66.

IPDM E/R			Condition		Continuity
Connector	Terminals				
F24	63	66	Transmission range switch	P or N	Yes
				Other	No

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

## 4. CHECK TRANSMISSION RANGE SWITCH CIRCUIT FOR SHORT

Check continuity between IPDM E/R harness connector terminals 63, 66 and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
F24	63	Ground	No
	66		

Is the inspection result normal?

YES >> Replace the IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

NO >> Repair or replace harness.

## 5. CHECK TRANSMISSION RANGE SWITCH INPUT SIGNAL CIRCUIT

1. Disconnect transmission range switch harness connector.
2. Check continuity between transmission range switch and IPDM E/R harness connectors.

Transmission range switch		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F36	7	F24	63	Yes
	10		66	

3. Check continuity between transmission range switch harness connector and ground.

Transmission range switch		Ground	Continuity
Connector	Terminal		
F36	7	Ground	No
	10		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair harness or connector.

## 6. CHECK INTERMITTENT INCIDENT

# B2110 TRANSMISSION RANGE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

Refer to [GI-47. "Intermittent Incident"](#).

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# B2190 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2190 NATS ANTENNA AMP.

### Description

INFOID:0000000012549569

Performs ID verification through BCM and Intelligent Key when push-button ignition switch is pressed. Prohibits starting of the engine when an unregistered ID of Intelligent Key is used.

### DTC Logic

INFOID:0000000012549570

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2190	NATS ANTENNA AMP	Inactive communication between NATS antenna amp. and BCM.	<ul style="list-style-type: none"> <li>• Harness or connectors (The NATS antenna amp. circuit is open or shorted)</li> <li>• NATS antenna amp.</li> <li>• BCM</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE 1

1. Contact Intelligent Key back side to push-button ignition switch.
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-96, "Diagnosis Procedure"](#).  
 NO >> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION PROCEDURE 2

1. Press the push-button ignition switch.
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-96, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012549571

Regarding Wiring Diagram information, refer to [SEC-44, "Wiring Diagram"](#).

#### 1. CONNECTOR INSPECTION

1. Disconnect BCM and NATS antenna amp.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace as necessary.

#### 2. CHECK NATS ANTENNA AMP. CIRCUIT

1. Disconnect BCM connector and NATS antenna amp. connector.
2. Check continuity between BCM harness connector and NATS antenna amp. harness connector.

BCM		NATS antenna amp.		Continuity
Connector	Terminal	Connector	Terminal	
M80	126	M21	3	Yes
	127		1	

3. Check continuity between BCM harness connector and ground.



# B2190 NATS ANTENNA AMP.

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M80	126		No
	127		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3. CHECK NATS ANTENNA AMP INPUT SIGNAL

- Turn ignition switch ON.
- Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M80	126, 127	Ground	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA3839GB</p>
			When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA5951GB</p>

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Replace NATS antenna amp. Refer to [SEC-152, "Removal and Installation"](#).

SEC

# B2191, P1615 DIFFERENCE OF KEY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2191, P1615 DIFFERENCE OF KEY

### Description

INFOID:000000012549572

Performs ID verification through BCM and Intelligent Key when push-button ignition switch is pressed. Prohibits starting of the engine when an unregistered ID of Intelligent Key is used.

### DTC Logic

INFOID:000000012549573

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2191 P1615	DIFFERENCE OF KEY	The ID verification results between BCM and Intelligent Key are NG. The registration is necessary.	<ul style="list-style-type: none"><li>Intelligent Key</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

- Place the back side of the Intelligent Key up to the push-button ignition switch.
- Press the push-button ignition switch.
- Check "Self-Diagnostic Result" with CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-98, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549574

#### 1. PERFORM INITIALIZATION

Perform initialization with CONSULT. Re-register all Intelligent Keys. For initialization and registration of Intelligent Key, refer to CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with re-registered Intelligent Key?

- YES >> Intelligent Key was unregistered.  
NO >> Intelligent Key fob is malfunctioning.
  - Replace Intelligent Key fob.
  - Perform initialization again.

# B2192 ID DISCORD, IMMUECM

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2192 ID DISCORD, IMMUECM

### DTC Logic

INFOID:000000012549575

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2192	ID DISCORD BCM-ECM	The ID verification results between BCM and ECM are NG.	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• BCM</li><li>• ECM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-99, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549576

#### 1. PERFORM INITIALIZATION

Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with reregistered Intelligent Key?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2. CHECK SELF-DIAGNOSIS RESULT

1. Select "Self Diagnostic Result" mode of "BCM" using CONSULT.
2. Erase DTC.
3. Perform DTC CONFIRMATION PROCEDURE for DTC B2192. Refer to [SEC-99, "DTC Logic"](#).

#### Is DTC detected?

- YES >> GO TO 3.  
NO >> Inspection End.

#### 3. REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with registered Intelligent Key?

- YES >> Inspection End.  
NO >> GO TO 4.

#### 4. REPLACE ECM

1. Replace ECM. Refer to [EC-508, "Removal and Installation"](#) (USA and Canada) or [EC-885, "Removal and Installation"](#) (Mexico).
2. Perform "ADDITIONAL SERVICE WHEN REPLACING ECM". Refer to [EC-154, "Work Procedure"](#) (USA and Canada) or [EC-639, "Work Procedure"](#) (Mexico).

>> Inspection End.

# B2193 CHAIN OF ECM-IMMU

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2193 CHAIN OF ECM-IMMU

### DTC Logic

INFOID:000000012549577

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2193 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2193 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2193	CHAIN OF BCM-ECM	Inactive communication between BCM and ECM	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• ECM</li><li>• BCM</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> GO TO [SEC-100, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:000000012549578

##### 1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT.

Check BCM power supply and ground circuit. Refer to [BCS-74, "Diagnosis Procedure"](#).

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace the harness.

##### 2. CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.

Check ECM power supply and ground circuit. Refer to [EC-188, "Diagnosis Procedure"](#) (USA and Canada) or [EC-666, "Diagnosis Procedure"](#) (Mexico).

##### Is the inspection result normal?

- YES >> Replace ECM. Refer to [EC-508, "Removal and Installation"](#) (USA and Canada) or [EC-885, "Removal and Installation"](#) (Mexico). GO TO 3.  
NO >> Repair or replace the harness.

##### 3. PERFORM DTC CONFIRMATION PROCEDURE.

Perform the DTC confirmation procedure. Refer to [SEC-100, "DTC Logic"](#).

##### Does the DTC return?

- YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).  
NO >> Inspection End.

# B2195 ANTI-SCANNING

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## B2195 ANTI-SCANNING

### DTC Logic

INFOID:000000012549579

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2195	ANTI-SCANNING	ID verification between BCM and ECM that is out of the designated specification is detected.	ID verification request out of the designated specification

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-101, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549580

#### 1. CHECK SELF-DIAGNOSTIC RESULT 1

1. Select "Self-Diagnostic Result" mode of "BCM" using CONSULT.
2. Erase DTC.
3. Perform DTC CONFIRMATION PROCEDURE for DTC B2195. Refer to [SEC-101, "DTC Logic"](#).

#### Is DTC detected?

- YES >> GO TO 2.  
NO >> Inspection End.

#### 2. CHECK EQUIPMENT OF THE VEHICLE

Check that unspecified accessory part related to engine start is not installed.

#### Is unspecified accessory part related to engine start installed?

- YES >> GO TO 3.  
NO >> GO TO 4.

#### 3. CHECK SELF DIAGNOSTIC RESULT 2

1. Obtain the customers approval to remove unspecified accessory part related to engine start, and then remove it.
2. Select "Self-Diagnostic Result" of "BCM" using CONSULT.
3. Erase DTC.
4. Perform DTC CONFIRMATION PROCEDURE for DTC B2195. Refer to [SEC-101, "DTC Logic"](#).

#### Is DTC detected?

- YES >> GO TO 4.  
NO >> Inspection End.

#### 4. REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

# B2196 DONGLE UNIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2196 DONGLE UNIT

### Description

INFOID:0000000012549581

BCM performs ID verification between BCM and dongle unit.  
When verification result is OK, BCM permits cranking.

### DTC Logic

INFOID:0000000012549582

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2196 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2196 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2196	DONGLE NG	The ID verification results between BCM and dongle unit is NG.	<ul style="list-style-type: none"><li>• Harness or connectors (Dongle unit circuit is open or shorted.)</li><li>• Dongle unit</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn ignition switch OFF.
3. Turn ignition switch ON.
4. Check "Self-diagnosis result" using CONSULT.

#### Is the DTC detected?

- YES >> Refer to [SEC-102, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012549583

Regarding Wiring Diagram information, refer to [SEC-44, "Wiring Diagram"](#).

#### 1. PERFORM INITIALIZATION

1. Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.
2. Start the engine.

#### Dose the engine start?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2. CHECK DONGLE UNIT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and dongle unit connector.
3. Check continuity between BCM harness connector and dongle unit harness connector.

BCM		Dongle unit		Continuity
Connector	Terminal	Connector	Terminal	
M19	52	M29	1	Yes

4. Check continuity between BCM harness connector and ground.

# B2196 DONGLE UNIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

BCM		Ground	Continuity
Connector	Terminal		
M19	52		No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

## 3.CHECK DONGLE UNIT GROUND CIRCUIT

Check continuity between dongle unit harness connector and ground.

Dongle unit		Ground	Continuity
Connector	Terminal		
M29	4		Yes

Is the inspection result normal?

YES >> Replace dongle unit.

NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B2198 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2198 NATS ANTENNA AMP.

### DTC Logic

INFOID:000000012549584

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2198	NATS ANTENNA AMP	Inactive communication between NATS antenna amp. and BCM.	<ul style="list-style-type: none"><li>• Harness or connectors (The NATS antenna amp. circuit is open or shorted)</li><li>• NATS antenna amp.</li><li>• BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE 1

1. Contact Intelligent Key back side to push-button ignition switch.
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-104, "Diagnosis Procedure"](#).  
NO >> GO TO 2.

#### 2.PERFORM DTC CONFIRMATION PROCEDURE 2

1. Press the push-button ignition switch.
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-104, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549585

Regarding Wiring Diagram information, refer to [SEC-44, "Wiring Diagram"](#).

#### 1.CONNECTOR INSPECTION

1. Disconnect BCM and NATS antenna amp.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace as necessary.

#### 2.CHECK NATS ANTENNA AMP. CIRCUIT

1. Disconnect BCM connector and NATS antenna amp. connector.
2. Check continuity between BCM harness connector and NATS antenna amp. harness connector.

BCM		NATS antenna amp.		Continuity
Connector	Terminal	Connector	Terminal	
M80	126	M21	3	Yes
	127		1	

3. Check continuity between BCM harness connector and ground.



# B2198 NATS ANTENNA AMP.

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M80	126		No
	127		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

## 3. CHECK NATS ANTENNA AMP INPUT SIGNAL

1. Turn ignition switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M80	126, 127	Ground	When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA3839GB</p>
			When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JMKIA5951GB</p>

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).

NO >> Replace NATS antenna amp. Refer to [SEC-152, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B2555 STOP LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2555 STOP LAMP

### DTC Logic

INFOID:000000012549586

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2555	STOP LAMP	BCM makes a comparison between the upper voltage and lower voltage of stop lamp switch. It judges from their values to detect the malfunctioning circuit.	<ul style="list-style-type: none"> <li>• Harness or connectors (Stop lamp switch circuit is open or shorted.)</li> <li>• Stop lamp switch</li> <li>• Fuse</li> <li>• BCM</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Depress the brake pedal and wait 1 second or more.
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-106. "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549587

Regarding Wiring Diagram information, refer to [SEC-27. "Wiring Diagram"](#).

#### 1. CHECK STOP LAMP SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check voltage between stop lamp switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Stop lamp switch			
Connector	Terminal	Ground	Battery voltage
E38	1		

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO-1 >> Check 10 A fuse [No. 10, located in the fuse block (J/B)].  
 NO-2 >> Check harness for open or short between stop lamp switch and fuse.

#### 2. CHECK STOP LAMP SWITCH INPUT SIGNAL

1. Connect stop lamp switch connector.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
BCM				
Connector	Terminal	Ground	Brake pedal	Battery voltage
M18	27			
		Not depressed	0	

#### Is the inspecting result normal?

- YES >> GO TO 3.  
 NO >> GO TO 4.

# B2555 STOP LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## 3. REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

## 4. CHECK STOP LAMP SWITCH CIRCUIT

1. Disconnect stop lamp switch connector.
2. Check continuity between stop lamp switch harness connector and BCM harness connector.

Stop lamp switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
E38	2	M18	27	Yes

3. Check continuity between stop lamp switch harness connector and ground.

Stop lamp switch		Ground	Continuity
Connector	Terminal		
E38	2		No

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 5. CHECK STOP LAMP SWITCH

Refer to [SEC-107, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace stop lamp switch. Refer to [BR-20, "Exploded View"](#).

## 6. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

## Component Inspection

INFOID:0000000012549588

### 1. CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch terminals.

Stop lamp switch		Condition	Continuity
Terminal			
1	2	Brake pedal	No
			Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace stop lamp switch. Refer to [BR-20, "Exploded View"](#).

# B2556 PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2556 PUSH-BUTTON IGNITION SWITCH

### DTC Logic

INFOID:000000012549589

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2556	PUSH-BTN IGN SW	BCM detects the push-button ignition switch stuck at ON for 100 seconds or more.	<ul style="list-style-type: none"><li>• Harness or connectors (Push-button ignition switch circuit is shorted.)</li><li>• Push-button ignition switch</li><li>• BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch under the following condition:
  - Brake pedal: Not depressed
2. Release push-button ignition switch and wait 100 seconds or more.
3. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-108. "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549590

Regarding Wiring Diagram information, refer to [SEC-27. "Wiring Diagram"](#).

#### 1. CHECK PUSH-BUTTON IGNITION SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check voltage between push-button ignition switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Push-button ignition switch			
Connector	Terminal	Ground	12
M17	8		

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 2.

#### 2. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT

1. Disconnect BCM connector and IPDM E/R connector.
2. Check continuity between push-button ignition switch harness connector and BCM harness connector.

Push-button ignition switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M17	8	M18	1	Yes

3. Check continuity between push-button ignition switch harness connector and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M17	8		No

# B2556 PUSH-BUTTON IGNITION SWITCH

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace harness.

## 3. REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

## 4. CHECK PUSH-BUTTON IGNITION SWITCH

Refer to [SEC-109, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Replace push-button ignition switch. Refer to [SEC-153, "Removal and Installation"](#).

## 5. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

## Component Inspection

INFOID:0000000012549591

### 1. CHECK PUSH-BUTTON IGNITION SWITCH

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check continuity between push-button ignition switch terminals.

Push-button ignition switch		Condition		Continuity
Terminal				
4	8	Push-button ignition switch	Pressed	Yes
			Not pressed	No

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace push-button ignition switch. Refer to [SEC-153, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B2557 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2557 VEHICLE SPEED

### DTC Logic

INFOID:000000012549592

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2557 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2557 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible causes
B2557	VEHICLE SPEED	BCM detects one of the following conditions for 10 seconds continuously. <ul style="list-style-type: none"><li>• Vehicle speed signal from combination meter is 10 km/h (6.2 MPH) or more, and vehicle speed signal from ABS actuator and electric unit (control unit) is 4 km/h (2.5 MPH) or less.</li><li>• Vehicle speed signal from combination meter is 4 km/h (2.5 MPH) or less, and vehicle speed signal from ABS actuator and electric unit (control unit) is 10 km/h (6.2 MPH) or more.</li></ul>	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• Combination meter</li><li>• ABS actuator and electric unit (control unit)</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and wait 10 seconds or more.
2. Drive the vehicle at a vehicle speed of 10 km/h (6.2 MPH) or more for 10 seconds or more.
3. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-110, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549593

#### 1. CHECK DTC OF "ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)"

Check DTC in "Self-Diagnostic Result" mode of "ABS" using CONSULT.

#### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [BRC-47, "DTC Index"](#) (Type 1) or [BRC-206, "DTC Index"](#) (Type 2).  
NO >> GO TO 2.

#### 2. CHECK DTC OF "COMBINATION METER"

Check DTC in "Self-Diagnostic Result" mode of "METER/M&A" using CONSULT.

#### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-29, "DTC Index"](#).  
NO >> GO TO 3.

#### 3. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#) .

>> Inspection End.

# B2560 STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2560 STARTER CONTROL RELAY

### Description

INFOID:0000000012549594

Starter control relay, integrated in IPDM E/R, permits the starter relay operation when in N (Neutral) or P (Park) position.

### DTC Logic

INFOID:0000000012549595

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2560 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2560 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC	Self-diagnosis name	DTC detecting condition	Possible causes
B2560	STARTER CONTROL RELAY	BCM detects a mismatch between the OFF request of starter control relay to IPDM E/R and the feedback. (The feedback is ON instead of OFF.)	• IPDM E/R

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions and wait for at least 2 seconds:
  - CVT selector lever is in the P (Park) position.
  - Depress the brake pedal.
2. Check "Self-Diagnostic Result" with CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-111, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012549596

#### 1. CHECK DTC WITH IPDM E/R

Check "Self Diagnostic Result" with CONSULT. Refer to [PCS-20, "DTC Index"](#).

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace malfunctioning parts.

#### 2. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B2601 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2601 SHIFT POSITION

### DTC Logic

INFOID:000000012549597

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2601 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2601 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2601	SHIFT POSITION	When there is a difference between P (Park) range signal from CVT shift selector (park position switch) and P (Park) position signal from IPDM E/R (CAN).	<ul style="list-style-type: none"><li>• Harness or connectors (CAN communication line is open or shorted.)</li><li>• Harness or connectors [CVT shift selector (park position switch) circuit is open or shorted.]</li><li>• CVT shift selector (park position switch)</li><li>• BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Shift the selector lever to the P (Park) position.
2. Turn ignition switch ON and wait 2 seconds or more.
3. Shift the selector lever to any position other than P (Park) and wait 2 seconds or more.
4. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-112, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549598

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. CHECK CVT SHIFT SELECTOR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "DETE/CANCEL SW" and "DETENT SW - IPDM" in DATA MONITOR mode with CONSULT.
3. Check "DETE/CANCEL SW" and "DETENT SW - IPDM" indication under the following conditions.

Monitor item	Condition		Indication
DETE/CANCEL SW	CVT Shift selector	In any position other than P (Park)	OFF
		P (Park)	ON
DETENT SW - IPDM	CVT Shift selector	In any position other than P (Park)	OFF
		P (Park)	ON

#### Is the inspection result normal?

- YES >> Refer to [GI-47, "Intermittent Incident"](#).  
NO-1 >> If DETE/CANCEL SW function is incorrect. GO TO 2.  
NO-2 >> If DETENT SW - IPDM function is incorrect. GO TO 5.



# B2601 SHIFT POSITION

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## 2. CHECK CVT SHIFT SELECTOR CIRCUIT (BCM)

1. Disconnect BCM connector and IPDM E/R connector.
2. Check continuity between CVT shift selector (park position switch) harness connector and BCM harness connector.

CVT shift selector (park position switch)		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M78	6	M18	20	Yes

3. Check continuity between CVT shift selector (park position switch) harness connector and ground.

CVT shift selector (park position switch)		Ground	Continuity
Connector	Terminal		
M78	6		No

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

## 3. CONNECTOR INSPECTION

1. Disconnect BCM.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace as necessary.

## 4. REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

## 5. CHECK CVT SHIFT SELECTOR CIRCUIT (IPDM E/R)

Check continuity between CVT shift selector (park position switch) harness connector and IPDM E/R harness connector.

CVT shift selector (park position switch)		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
M78	6	E119	31	Yes

Is the inspection result normal?

- YES >> GO TO 6.  
 NO >> Repair or replace harness.

## 6. CONNECTOR INSPECTION

1. Disconnect IPDM E/R.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 7.  
 NO >> Repair or replace as necessary.

## 7. REPLACE IPDM E/R

1. Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).

>> Inspection End.

SEC

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

# B2601 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## Component Inspection

INFOID:000000012549599

### 1. CHECK CVT SHIFT SELECTOR (PARK POSITION SWITCH)

1. Turn ignition switch OFF.
2. Disconnect CVT shift selector connector.
3. Check continuity between CVT shift selector (park position switch) terminals.

CVT shift selector (park position switch)		Condition	Continuity
Terminal			
5	6	Selector lever	P (Park) position No
			Other than above Yes

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace CVT shift selector. Refer to [TM-198, "Removal and Installation"](#) (RE0F10E) or [TM-416, "Removal and Installation"](#) (RE0F10J).

# B2602 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2602 SHIFT POSITION

### DTC Logic

INFOID:000000012549600

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2602 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2602 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2602	SHIFT POSITION	BCM detects the following status for 10 seconds. <ul style="list-style-type: none"> <li>• Selector lever is in the P (Park) position</li> <li>• Vehicle speed is 4 km/h (2.5 MPH) or more</li> <li>• Ignition switch is in the ON position</li> </ul>	<ul style="list-style-type: none"> <li>• Harness or connectors (CAN communication line is open or shorted.)</li> <li>• Harness or connectors [CVT shift selector (park position switch) circuit is open or shorted.]</li> <li>• CVT shift selector (park position switch)</li> <li>• Combination meter</li> <li>• BCM</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine.
2. Drive vehicle at a speed of 4 km/h (2.5 MPH) or more for 10 seconds or more.
3. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-115, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549601

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. CHECK CVT SHIFT SELECTOR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "DETE/CANCEL SW" and "VEH SPEED 1" in DATA MONITOR mode with CONSULT.
3. Check "DETE/CANCEL SW" and "VEH SPEED 1" indication under the following conditions.

Monitor item	Condition		Indication
DETE/CANCEL SW	CVT Shift selector	In any position other than P (Park)	OFF
		P (Park)	ON
VEH SPEED 1	Vehicle not moving		0
	Vehicle moving		Varies

#### Is the inspection result normal?

- YES >> Refer to [GI-47, "Intermittent Incident"](#).  
 NO-1 >> If DETE/CANCEL SW is incorrect. GO TO 4.  
 NO-2 >> If VEH SPEED 1 is incorrect. GO TO 2.

#### 2. CHECK DTC OF COMBINATION METER

## B2602 SHIFT POSITION

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

Check DTC in "Self-Diagnostic Result" mode of "METER/M&A" using CONSULT.

Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-29, "DTC Index"](#).  
NO >> GO TO 3.

### 3. CHECK DTC OF ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Check DTC in "Self-Diagnostic Result" mode of "ABS" using CONSULT.

Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [BRC-47, "DTC Index"](#) (Type 1) or [BRC-206, "DTC Index"](#) (Type 2).  
NO >> GO TO 6.

### 4. CHECK CVT SHIFT SELECTOR CIRCUIT

1. Disconnect BCM connector and IPDM E/R connector.
2. Check continuity between CVT shift selector (park position switch) harness connector and BCM harness connector.

CVT shift selector (park position switch)		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M78	6	M18	20	Yes

3. Check continuity between CVT shift selector (park position switch) harness connector and ground.

CVT shift selector (park position switch)		Ground	Continuity
Connector	Terminal		
M78	6		No

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair or replace harness.

### 5. CHECK CVT SHIFT SELECTOR (PARK POSITION SWITCH)

Refer to [SEC-116, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Replace CVT shift selector. Refer to [TM-198, "Removal and Installation"](#) (RE0F10E) or [TM-416, "Removal and Installation"](#) (RE0F10J).

### 6. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

## Component Inspection

INFOID:0000000012549602

### 1. CHECK CVT SHIFT SELECTOR (PARK POSITION SWITCH)

1. Turn ignition switch OFF.
2. Disconnect CVT shift selector connector.
3. Check continuity between CVT shift selector (park position switch) terminals.

CVT shift selector (park position switch)		Condition		Continuity
Terminal				
5	6	Selector lever	P (Park) position	No
			Other than above	Yes

Is the inspection result normal?

- YES >> Inspection End.

## B2602 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

NO >> Replace CVT shift selector. Refer to [TM-198. "Removal and Installation"](#) (RE0F10E) or [TM-416. "Removal and Installation"](#) (RE0F10J).

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# B2603 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2603 SHIFT POSITION

### DTC Logic

INFOID:0000000012549603

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2603 is displayed with DTC B2601, first perform the trouble diagnosis for DTC B2601. Refer to [SEC-112, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible causes
B2603	SHIFT POSI STATUS	BCM detects the following status when ignition switch is in the ON position. <ul style="list-style-type: none"><li>• P (Park) position signal from TCM: approx. 0 V</li><li>• CVT shift selector (park position switch) signal: approx. 0 V</li></ul>	<ul style="list-style-type: none"><li>• Harness or connector [CVT shift selector (park position switch) circuit is open or shorted.]</li><li>• Harness or connectors (TCM circuit is open or shorted.)</li><li>• CVT shift selector (park position switch)</li><li>• CVT assembly (TCM)</li><li>• BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE 1

1. Shift the selector lever to the P (Park) position.
2. Turn ignition switch ON and wait 1 second or more.
3. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-118, "Diagnosis Procedure"](#).  
NO >> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION PROCEDURE 2

1. Shift the selector lever to any position other than P (Park) and wait 1 second or more.
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-118, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012549604

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. CHECK CVT SHIFT SELECTOR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "DETE/CANCEL SW" and "SFT PN/N SW" in DATA MONITOR mode with CONSULT.
3. Check "DETE/CANCEL SW" and "SFT PN/N SW" indication under the following conditions.

Monitor item	Condition		Indication
DETE/CANCEL SW	CVT Shift selector	In any position other than P (Park)	OFF
		P (Park)	ON
SFT PN/N SW	CVT Shift selector	In any position other than P (Park)	OFF
		P (Park)	ON

#### Is the inspection result normal?

# B2603 SHIFT POSITION

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Refer to [GI-47, "Intermittent Incident"](#).
- NO-1 >> If DETE/CANCEL SW is incorrect. GO TO 6.
- NO-2 >> If SFT PN/N SW is incorrect. GO TO 2.

## 2.CHECK BCM INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)	
BCM					
Connector	Terminal				
M18	39	Ground	Selector lever	P or N position	12
				Other than above	0

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 3.

## 3.CHECK BCM INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Disconnect transmission range switch connector.
4. Check continuity between transmission range switch harness connector and BCM harness connector.

Transmission range switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
F36	10	M18	39	Yes

5. Check continuity between transmission range switch harness connector and ground.

Transmission range switch		Ground	Continuity
Connector	Terminal		
F36	10		No

Is the inspection result normal?

- YES >> Refer to [GI-47, "Intermittent Incident"](#).
- NO >> GOT TO 5.

## 4.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

## 5.CHECK DTC OF TCM

Check DTC in "Self Diagnostic Result" mode of "TCM" using CONSULT.

Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [TM-65, "DTC Index"](#) (RE0F10E) or [TM-286, "DTC Index"](#) (RE0F10J).
- NO >> Perform the trouble diagnosis related to the TCM power and ground circuits. Refer to [TM-176, "Diagnosis Procedure"](#) (RE0F10E) or [TM-394, "Diagnosis Procedure"](#)(RE0F10J).

## 6.CHECK CVT SHIFT SELECTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect CVT shift selector (park position switch) connector.
3. Check voltage between CVT shift selector (park position switch) harness connector and ground.

## B2603 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

(+)		(-)	Voltage (V) (Approx.)
CVT shift selector (park position switch)			
Connector	Terminal		
M78	5	Ground	12

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace harness.

### 7. CHECK CVT SHIFT SELECTOR POWER SUPPLY CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between CVT shift selector (park position switch) harness connector and BCM harness connector.

CVT shift selector (park position switch)		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M78	5	M19	69	Yes

3. Check continuity between CVT shift selector (park position switch) harness connector and ground.

CVT shift selector (park position switch)		Ground	Continuity
Connector	Terminal		
M78	5		No

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

### 8. CHECK CVT SHIFT SELECTOR CIRCUIT

1. Disconnect BCM connector and IPDM E/R connector.
2. Check continuity between CVT shift selector (park position switch) harness connector and BCM harness connector.

CVT shift selector (park position switch)		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M78	6	M18	20	Yes

3. Check continuity between CVT shift selector (park position switch) harness connector and ground.

CVT shift selector (park position switch)		Ground	Continuity
Connector	Terminal		
M78	6		No

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace harness.

### 9. CHECK CVT SHIFT SELECTOR (PARK POSITION SWITCH)

Refer to [SEC-121, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace CVT shift selector. Refer to [TM-198, "Removal and Installation"](#) (RE0F10E) or [TM-416, "Removal and Installation"](#) (RE0F10J).

### 10. REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.



# B2603 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

>> Inspection End.

## Component Inspection

INFOID:000000012549605

### 1. CHECK CVT SHIFT SELECTOR (PARK POSITION SWITCH)

1. Turn ignition switch OFF.
2. Disconnect CVT shift selector connector.
3. Check continuity between CVT shift selector (park position switch) terminals.

CVT shift selector (park position switch)		Condition	Continuity	
Terminal				
5	6	Selector lever	P (Park) position	No
			Other than above	Yes

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace CVT shift selector. Refer to [TM-198, "Removal and Installation"](#) (RE0F10E) or [TM-416, "Removal and Installation"](#) (RE0F10J).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B2604 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2604 SHIFT POSITION

### DTC Logic

INFOID:000000012549606

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2604 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2604 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2604	PNP/CLUTCH SW	<p>The following states are detected for 5 seconds while ignition switch is ON:</p> <ul style="list-style-type: none"> <li>• P/N position signal is sent from TCM but shift position signal input (CAN) from TCM is other than P (Park) and N (Neutral)</li> <li>• P/N position signal is not sent from TCM but shift position signal input (CAN) from TCM is P (Park) or N (Neutral)</li> </ul>	<ul style="list-style-type: none"> <li>• Harness or connectors (CAN communication line is open or shorted.)</li> <li>• Harness or connectors (TCM circuit is open or shorted.)</li> <li>• TCM</li> <li>• BCM</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Shift the selector lever to the P (Park) position.
2. Turn ignition switch ON and wait 5 seconds or more.
3. Shift the selector lever to the N (Neutral) position and wait 5 seconds or more.
4. Shift the selector lever to any position other than P (Park) and N (Neutral) and wait 5 seconds or more.
5. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-122, "Diagnosis Procedure"](#).
- NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549607

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. CHECK CVT SHIFT SELECTOR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "SFT P -MET", "SFT N -MET" and "SFT PN/N SW" in DATA MONITOR mode with CONSULT.
3. Check "SFT P -MET", "SFT N -MET" and "SFT PN/N SW" indication under the following conditions.

Monitor item	Condition		Indication
SFT P -MET	CVT Shift selector	Selector lever is in any position except the P (Park) position	OFF
		Selector lever is in the P (Park) position	ON

# B2604 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

Monitor item	Condition		Indication
SFT N -MET	CVT Shift selector	Selector lever is in any position except the N (Neutral) position	OFF
		Selector lever is in the N (Neutral) position	ON
SFT PN/N SW	CVT Shift selector	Selector lever is in and position except the P (Park) or N (Neutral) position	OFF
		Selector lever is in the P (Park) or N (Neutral) position	ON

Is the inspection result normal?

- YES >> Refer to [GI-47. "Intermittent Incident"](#).
- NO-1 >> If SFT N -MET or SFT P -MET is incorrect. GO TO 7.
- NO-2 >> If SFT PN/N SW is incorrect. GO TO 2.

## 2. CHECK DTC OF TCM

Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [TM-65. "DTC Index" \(RE0F10E\)](#) or [TM-286. "DTC Index" \(RE0F10J\)](#).
- NO >> GO TO 3.

## 3. CHECK BCM INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
BCM				
Connector	Terminal			
M18	39	Ground	Selector lever	P (Park) or N (Neutral) position 12
			Other than above	0

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 5.

## 4. REPLACE BCM

1. Replace BCM. Refer to [BCS-81. "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

## 5. CHECK BCM INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect transmission range switch connector.
3. Disconnect BCM connector.
4. Check continuity between transmission range switch harness connector and BCM harness connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## B2604 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

Transmission range switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
F36	10	M18	39	Yes

5. Check continuity between transmission range switch harness connector and ground.

Transmission range switch		Ground	Continuity
Connector	Terminal		
F36	10		No

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Repair or replace harness.

### 6. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

### 7. CHECK CVT SHIFT SELECTOR RANGE SWITCH FUNCTION (METER)

1. Turn ignition switch ON.
2. Select "SHIFT IND" in DATA MONITOR mode (METER) with CONSULT.
3. Check "SHIFT IND" indication under the following conditions.

Monitor item	Condition		Indication
SHIFT IND	CVT Shift selector	P (Park) position	P
		N (Neutral) position	N

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Refer to [TM-111, "Component Inspection"](#) (RE0F10E) or [TM-331, "Component Inspection"](#) (RE0F10J).

# B2605 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2605 SHIFT POSITION

### DTC Logic

INFOID:000000012549608

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2605 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2605 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2605	PNP/CLUTCH SW	When ignition switch is ON, P/N position signal input from TCM and P/N position signal (CAN) input from IPDM E/R do not match.	<ul style="list-style-type: none"> <li>• Harness or connectors (CAN communication line is open or shorted.)</li> <li>• Harness or connectors (TCM circuit is open or shorted.)</li> <li>• IPDM E/R</li> <li>• BCM</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Shift the selector lever to the P (Park) position.
2. Turn ignition switch ON and wait 1 second or more.
3. Shift the selector lever to the N (Neutral) position and wait 1 second or more.
4. Shift the selector lever to any position other than P (Park) and N (Neutral) and wait 1 second or more.
5. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-125, "Diagnosis Procedure"](#).
- NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549609

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. CHECK CVT SHIFT SELECTOR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "SFT PN-IPDM" and "SFT PN/N SW" in DATA MONITOR mode with CONSULT.
3. Check "SFT PN-IPDM" and "SFT PN/N SW" indication under the following conditions.

Monitor item	Condition		Indication
SFT PN-IPDM	CVT Shift selector	Any position other than P (Park) or N (Neutral) position	OFF
		P (Park) or N (Neutral) position	ON
SFT PN/N SW	CVT Shift selector	Any position other than P (Park) or N (Neutral) position	OFF
		P (Park) or N (Neutral) position	ON

#### Is the inspection result normal?

- YES >> Refer to [GI-47, "Intermittent Incident"](#).

# B2605 SHIFT POSITION

[WITH INTELLIGENT KEY SYSTEM]

## < DTC/CIRCUIT DIAGNOSIS >

- NO-1 >> If SFT PN-IPDM is incorrect. GO TO 2.
- NO-2 >> If SFT PN/N SW is incorrect. GO TO 5.

### 2.CHECK IPDM E/R INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Turn ignition switch ON.
4. Check voltage between IPDM E/R harness connector and ground.

(+)		(-)	Condition		Voltage (V) (Approx.)
IPDM E/R					
Connector	Terminal				
F24	66	Ground	Selector lever	P (Park) or N (Neutral) position	12
				Other than above	0

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32. "Removal and Installation"](#).
- NO >> GO TO 3.

### 3.CHECK IPDM E/R INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between IPDM E/R harness connector and transmission range switch harness connector.

IPDM E/R		Transmission range switch		Continuity
Connector	Terminal	Connector	Terminal	
E119	37	F36	10	Yes

4. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E119	37		

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace harness.

### 4.REPLACE IPDM E/R

1. Replace IPDM E/R. Refer to [PCS-32. "Removal and Installation"](#).

>> Inspection End.

### 5.CHECK BCM INPUT SIGNAL

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition		Voltage (V) (Approx.)
BCM					
Connector	Terminal				
M18	39	Ground	Selector lever	P (Park) or N (Neutral) position	12
				Other than above	0

Is the inspection result normal?

- YES >> GO TO 6.

# B2605 SHIFT POSITION

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 7.

## 6. REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

## 7. CHECK BCM INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect transmission range switch connector.
3. Disconnect BCM connector.
4. Check continuity between transmission range switch harness connector and BCM harness connector.

Transmission range switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
F36	10	M18	39	Yes

5. Check continuity between TCM harness connector and ground.

Transmission range switch		Ground	Continuity
Connector	Terminal		
F36	10		No

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

## 8. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B2608 STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2608 STARTER RELAY

### DTC Logic

INFOID:000000012549610

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2608 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2608 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2608	STARTER RELAY	BCM outputs starter motor relay OFF signal but BCM receives starter motor relay ON signal from IPDM E/R (CAN).	<ul style="list-style-type: none"><li>• Harness or connectors (CAN communication line is open or shorted.)</li><li>• Harness or connectors (Starter relay circuit is open or shorted.)</li><li>• IPDM E/R</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch under the following conditions to start engine.
  - Shift selector lever: In the P (Park) position
  - Brake pedal: Depressed
2. Wait 1 second after engine started.
3. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-128, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549611

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. CHECK DTC OF IPDM E/R

Check DTC in "Self-Diagnostic Result" mode of "IPDM E/R" using CONSULT.

#### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [PCS-20, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. CHECK BCM POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
BCM				
Connector	Terminal			
M19	62	Ground	Selector lever	N (Neutral) or P (Park) position 12
				Other than above 0

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 3.



# B2608 STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## 3. CHECK STARTER RELAY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Disconnect BCM connector.
4. Check continuity between IPDM E/R harness connector and BCM harness connector.

IPDM E/R		BCM		Continuity
Connector	Terminal	Connector	Terminal	
E119	33	M19	62	Yes

5. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E119	33		No

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
NO >> Repair or replace harness.

## 4. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B2617 STARTER RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2617 STARTER RELAY CIRCUIT

### Description

INFOID:000000012549612

Located in IPDM E/R, it runs the starter motor. The starter relay is turned ON by the BCM when the ignition switch is in START position. IPDM E/R transmits the starter relay ON signal to BCM via CAN communication.

### DTC Logic

INFOID:000000012549613

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2617 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B2617 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2617	STARTER RELAY CIRCUIT	<ul style="list-style-type: none"><li>• An immediate operation of starter relay is requested by BCM, but there is no response for more than 1 second</li><li>• BCM is not commanding starter relay activation, but BCM detects starter relay output is active</li></ul>	<ul style="list-style-type: none"><li>• Harness or connectors (Starter relay circuit is open or shorted.)</li><li>• IPDM E/R</li><li>• BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions and wait for at least 1 second.
  - CVT selector lever is in the P (Park) position.
  - Do not depress the brake pedal.
2. Check "Self-Diagnostic Result" with CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-130, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549614

Regarding Wiring Diagram information, refer to [SEC-27, "Wiring Diagram"](#).

#### 1. CHECK STARTER RELAY

1. Turn ignition switch ON.
2. Check voltage between BCM harness connector and ground under the following condition.

BCM		Ground	Condition	Voltage (V)
Connector	Terminal			
M19	62	Ground	Ignition switch cranking	0
			Ignition switch ON (Park or Neutral)	Battery voltage
			Other than above	0

#### Is the measurement value within the specification.

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2. CHECK STARTER RELAY CIRCUIT

# B2617 STARTER RELAY CIRCUIT

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector and IPDM E/R harness connector.
3. Check continuity between IPDM E/R harness connector and BCM harness connector.

IPDM E/R		BCM		Continuity
Connector	Terminal	Connector	Terminal	
E119	33	M19	62	Yes

4. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E119	33	Ground	No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-81. "Removal and Installation"](#).  
NO >> Repair harness or connector.

## 3. CHECK INTERMITTENT INCIDENT

Refer to [GI-47. "Intermittent Incident"](#).

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B261E VEHICLE TYPE

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## B261E VEHICLE TYPE

### Description

INFOID:0000000012549615

There are two types of vehicles.

- HEV
- Conventional

### DTC Logic

INFOID:0000000012549616

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B261E is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B261E is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B261E	VEHICLE TYPE	Difference of BCM configuration.	<ul style="list-style-type: none"><li>• BCM mis-configuration</li><li>• Wrong ECM installed</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions.
  - Shift selector lever is in the P (Park) or N (Neutral) position
  - Do not depress brake pedal
2. Check "Self-Diagnostic Result" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-132, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012549617

#### 1. INSPECTION START

1. Turn ignition switch ON.
2. Check "Self-diagnostic result" using CONSULT.
3. Touch "ERASE".
4. Perform DTC Confirmation Procedure. Refer to [SEC-132, "DTC Logic"](#).

#### Is the 1st trip DTC B261E displayed again?

- YES >> GO TO 2.  
NO >> Inspection End.

#### 2. PERFORM BCM CONFIGURATION.

Perform the BCM configuration. Refer to [BCS-65, "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 3.

#### 3. INSPECTION START

1. Turn ignition switch ON.
2. Check "Self-diagnostic result" using CONSULT.
3. Touch "ERASE".
4. Perform DTC Confirmation Procedure.  
Refer to [SEC-132, "DTC Logic"](#).

#### Is the 1st trip DTC B261E displayed again?

- YES >> GO TO 4.  
NO >> Inspection End.

## B261E VEHICLE TYPE

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

### 4. CONFIRM ECM PART NUMBER.

Confirm the part number of the installed ECM is correct.

Is the ECM part number correct?

YES >> Replace BCM. Refer to [BCS-81. "Removal and Installation"](#).

NO >> Replace ECM. Refer to [EC-508. "Removal and Installation"](#) (USA and Canada) or [EC-885. "Removal and Installation"](#) (Mexico).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B26F3 STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B26F3 STARTER CONTROL RELAY

### DTC Logic

INFOID:000000012549618

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B26F3 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B26F3 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B26F3	START CONT RLY ON	BCM requests IPDM E/R to turn starter control relay OFF, but BCM cannot receive starter control relay OFF state signal from IPDM E/R (CAN).	<ul style="list-style-type: none"><li>• Harness or connectors (CAN communication line is open or shorted.)</li><li>• IPDM E/R</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch under the following conditions to start engine:
  - Shift selector lever: In the P (Park) position
  - Brake pedal: Depressed
2. Wait 2 seconds after engine started.
3. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-134, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549619

#### 1. CHECK DTC OF IPDM E/R

Check DTC in "Self-Diagnostic Result" mode of "IPDM E/R" using CONSULT.

#### Is DTC detected?

- YES >> Perform the diagnosis procedure related to the detected DTC. Refer to [PCS-20, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

# B26F4 STARTER CONTROL RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B26F4 STARTER CONTROL RELAY

### DTC Logic

INFOID:000000012549620

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B26F4 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-68, "DTC Logic"](#).
- If DTC B26F4 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-69, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B26F4	START CONT RELAY OFF	BCM requests IPDM E/R to turn starter control relay ON, but BCM cannot receive starter control relay ON state signal from IPDM E/R.	<ul style="list-style-type: none"><li>• Harness or connectors (CAN communication line is open or shorted.)</li><li>• IPDM E/R</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch under the following conditions to start engine, and wait 1 second or more.
  - Shift selector lever: In the P (Park) position
  - Brake pedal: Depressed
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-135, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549621

#### 1. CHECK DTC OF IPDM E/R

Check DTC in "Self-Diagnostic Result" mode of "IPDM E/R" using CONSULT.

#### Is DTC detected?

- YES >> Perform the diagnosis procedure related to the detected DTC. Refer to [PCS-20, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

**B26F7 BCM****DTC Logic**

INFOID:000000012549622

**DTC DETECTION LOGIC**

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B26F7	BCM	Inside key antenna output circuit in BCM is malfunctioning.	BCM

**DTC CONFIRMATION PROCEDURE****1.PERFORM DTC CONFIRMATION PROCEDURE**

1. Press door request switch.
2. Turn ignition switch ON.
3. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

**Is DTC detected?**

- YES >> GO TO [SEC-136, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

**Diagnosis Procedure**

INFOID:000000012549623

**1.INSPECTION START**

1. Turn ignition switch ON.
2. Select "Self-Diagnostic Result" mode of "BCM" using CONSULT.
3. Touch "ERASE".
4. Perform DTC CONFIRMATION PROCEDURE for DTC B26F7. Refer to [SEC-136, "DTC Logic"](#).

**Is DTC detected?**

- YES >> GO TO 2.  
 NO >> Inspection End.

**2.REPLACE BCM**

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

&gt;&gt; Inspection End.



## B26F8 BCM

### DTC Logic

INFOID:000000012549624

### DTC DETECTION LOGIC

**NOTE:**

DTC B26F8 can be detected even though the related circuit is not used in this vehicle.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B26F8	BCM	Starter control replay control signal and feedback circuit signal (inside BCM) does not match.	BCM

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait 1 second.
2. Check DTC in "Self-Diagnostic Result" mode of "BCM" using CONSULT.

Is DTC detected?

- YES >> GO TO [SEC-137, "Diagnosis Procedure"](#).
- NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012549625

#### 1. INSPECTION START

1. Turn ignition switch ON.
2. Select "Self-Diagnostic Result" mode of "BCM" using CONSULT.
3. Touch "ERASE".
4. Perform DTC CONFIRMATION PROCEDURE for DTC B26F8.  
Refer to [SEC-137, "DTC Logic"](#).

Is DTC detected?

- YES >> GO TO 2.
- NO >> Inspection End.

#### 2. REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# HEADLAMP FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## HEADLAMP FUNCTION

### Component Function Check

INFOID:0000000012549626

#### 1.CHECK FUNCTION

1. Perform HEAD LAMP(HI) in ACTIVE TEST mode of THEFT ALM of BCM using CONSULT.
2. Check headlamps operation.

Test item		Description	
HEAD LAMP (HI)	ON	Headlamps (Hi)	Light
	OFF		Does not light

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Refer to [SEC-138, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012549627

#### 1.CHECK HEADLAMP FUNCTION

Refer to [SEC-138, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace the malfunctioning parts.

#### 2.CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

# HOOD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## HOOD SWITCH

### Component Function Check

INFOID:000000012549628

#### 1.CHECK FUNCTION

1. Select HOOD SW in Data Monitor mode of IPDM E/R using CONSULT.
2. Check HOOD SW indication under the following condition.

Monitor item	Condition		Indication
HOOD SW	Hood	Open	ON
		Close	OFF

Is the indication normal?

- YES >> Hood switch is OK.  
 NO >> Go to [SEC-139, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000012549629

Regarding Wiring Diagram information, refer to [SEC-56, "Wiring Diagram"](#).

#### 1.CHECK HOOD SWITCH SIGNAL CIRCUITS

1. Turn ignition switch OFF.
2. Disconnect hood switch connector.
3. Check voltage between hood switch harness connector and ground.

(+)		(-)	Voltage (V)
Hood switch			
Connector	Terminal	Ground	Battery voltage
E205	1		
	2		

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 2.

#### 2.CHECK HOOD SWITCH SIGNAL CIRCUITS

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and hood switch harness connector.

IPDM E/R		Hood switch		Continuity
Connector	Terminal	Connector	Terminal	
E218	94	E205	1	Yes
	96		2	

3. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E218	94	Ground	No
	96		

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-32, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

# HOOD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## 3.CHECK HOOD SWITCH GROUND CIRCUIT

Check continuity between hood switch harness connector and ground.

Hood switch		Ground	Continuity
Connector	Terminal		
E205	3		Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4.CHECK HOOD SWITCH

Refer to [SEC-140, "Component Inspection"](#) .

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace hood switch. Refer to [DLK-269, "HOOD LOCK : Removal and Installation"](#).

## 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-47, "Intermittent Incident"](#).

>> Inspection End.

## Component Inspection

INFOID:000000012549630

## 1.CHECK HOOD SWITCH

1. Turn ignition switch OFF.
2. Disconnect hood switch connector.
3. Check continuity between hood switch terminals.

Hood switch		Condition	Continuity	
Terminal				
1	3	Hood switch	Press	Yes
		Release	No	
2		Press	No	
		Release	Yes	

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace hood switch. Refer to [DLK-269, "HOOD LOCK : Removal and Installation"](#).

# HORN FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## HORN FUNCTION

### Component Function Check

INFOID:000000012549631

#### 1.CHECK FUNCTION

1. Perform VEHICLE SECURITY HORN in ACTIVE TEST mode of THEFT ALM of BCM using CONSULT.
2. Check the horn operation.

Test item		Description	
VEHICLE SECURITY HORN	ON	Horn	Sounds (for 0.5 sec)

Is the operation normal?

- YES >> Inspection End.  
 NO >> Go to [SEC-141, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000013027881

Regarding Wiring Diagram information, refer to [SEC-56, "Wiring Diagram"](#).

#### 1.CHECK HORN FUNCTION

Check horn function with horn switch.

Does the horn sound?

- YES >> GO TO 2.  
 NO >> Refer to [HRN-3, "Wiring Diagram"](#).

#### 2.CHECK HORN RELAY POWER SUPPLY

1. Turn ignition switch ON.
2. Perform "Active Test" of "HORN" using CONSULT.
3. Using an oscilloscope or analog voltmeter to check voltage between IPDM E/R connector and ground.

IPDM E/R		Ground	Test item	Voltage (V) (Approx.)
Connector	Terminal			
E119	23	Ground	HORN	Battery voltage → 0 → Battery voltage
			Other than above	Battery voltage

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> GO TO 3.

#### 3.CHECK HORN RELAY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R and horn relay connector.
3. Check continuity between IPDM E/R harness connector and horn relay harness connector.

IPDM E/R		Horn relay		Continuity
Connector	Terminal	Connector	Terminal	
E119	23	H-1	1	Yes

4. Check continuity between IPDM E/R harness connector and ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# HORN FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

IPDM E/R		Ground	Continuity
Connector	Terminal		
E119	23	Ground	No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4.CHECK INTERMITTENT INCIDENT

Refer to [GI-47. "Intermittent Incident"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-32. "Removal and Installation"](#).

NO >> Repair or replace the malfunctioning part.

# SECURITY INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## SECURITY INDICATOR LAMP

### Component Function Check

INFOID:000000012549633

#### 1.CHECK FUNCTION

1. Perform THEFT IND in ACTIVE TEST mode of IMMU of BCM using CONSULT.
2. Check security indicator lamp operation.

Test item		Description	
THEFT IND	ON	Security indicator lamp	Illuminates
	OFF		Does not illuminate

Is the inspection result normal?

- YES >> Inspection End.  
 NO >> Go to [SEC-143, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000012549634

Regarding Wiring Diagram information, refer to [SEC-56, "Wiring Diagram"](#).

#### 1.CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check voltage between combination meter harness connector and ground.

(+)		(-)	Voltage (V)
Combination meter			
Connector	Terminal	Ground	Battery voltage
M24	22		

Is the inspection result normal?

- YES >> GO TO 2.  
 NO-1 >> Check 10 A fuse [No. 13, located in the fuse block (J/B)].  
 NO-2 >> Check harness for open or short between combination meter and fuse.

#### 2.CHECK SECURITY INDICATOR LAMP SIGNAL

1. Connect combination meter connector.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Voltage (V)
BCM			
Connector	Terminal	Ground	Battery voltage
M18	18		

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 4.

#### 3.REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# SECURITY INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## 4. CHECK SECURITY INDICATOR LAMP CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between combination meter harness connector and BCM harness connector.

Combination meter		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M24	6	M18	18	Yes

3. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M24	6		No

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-85. "Removal and Installation"](#).  
NO >> Repair or replace harness.



# INTELLIGENT KEY SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## SYMPTOM DIAGNOSIS

### INTELLIGENT KEY SYSTEM SYMPTOMS

#### Diagnosis Procedure

INFOID:0000000013320665

**NOTE:**

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

**SYMPTOM TABLE 1 (BOTH INTELLIGENT KEYS HAVE THE SAME SYMPTOMS)**

No.	Door lock operation (remote keyless entry)	Door lock operation (request switch) or back door open operation (opener switch of back door panel)	Engine started with push-button ignition switch operation (registered Intelligent Key is within the detection area of inside key antenna)	Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch)	Symptom
1	OK	OK	No start	No start	<a href="#">SEC-146</a>
2	OK	NG	OK	OK	<a href="#">DLK-229</a>
3	OK	NG	No crank, No start	OK	<a href="#">DLK-231</a>
4	NG	NG	No crank, No start	OK	<a href="#">DLK-233</a>
5	NG	NG	No start	No start	<a href="#">DLK-234</a>
6	OK	OK	No crank, No start	OK	<a href="#">SEC-147</a>
7	NG	OK	OK	OK	<a href="#">DLK-236</a>
8	NG	NG	OK	OK	<a href="#">DLK-237</a>
9	Poor range	OK	OK	OK	<a href="#">DLK-238</a>

**SYMPTOM TABLE 2 (ONE INTELLIGENT KEY HAS THE SYMPTOM, OTHER KEYS OPERATE NORMALLY)**

No.	Door lock operation (remote keyless entry)	Door lock operation (request switch) or back door open operation (opener switch of back door panel)	Engine started with push-button ignition switch operation (Intelligent Key is within the detection area of inside key antenna)	Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch)	Symptom
1	NG	OK	OK	OK	<a href="#">DLK-240</a>
2	NG	NG	No crank, No start	OK	<a href="#">DLK-241</a>
3	NG	NG	No crank, No start	No crank, No start	<a href="#">DLK-243</a>
4	OK	OK	No crank, No start	No crank, No start	<a href="#">SEC-149</a>
5	OK	NG	No crank, No start	OK	<a href="#">SEC-150</a>
6	Poor range	OK	OK	OK	<a href="#">DLK-245</a>

SEC

# ENGINE CAN NOT START

< SYMPTOM DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## ENGINE CAN NOT START

### Description

INFOID:000000013320666

Engine does not start when push-button ignition switch is pressed.

### SYMPTOM TABLE (BOTH INTELLIGENT KEYS HAVE THE SAME SYMPTOMS)

Door lock operation (remote keyless entry)	Door lock operation (request switch) or back door open operation (opener switch of back door panel)	Engine started with push-button ignition switch operation (registered Intelligent Key is within the detection area of inside key antenna)	Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch)
OK	OK	No start	No start

### CONDITIONS OF VEHICLE (OPERATING CONDITIONS)

“ENGINE START BY I-KEY” setting in “Work support” mode of “INTELLIGENT KEY” of “BCM” is ON.

### DIAGNOSIS PROCEDURE

Refer to [SEC-146, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000013320667

#### 1. CHECK INTELLIGENT KEY SYSTEM SYMPTOM TABLE

Check Intelligent Key system symptom table.

Refer to [DLK-228, "Diagnosis Procedure"](#).

>> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS RESULT

Select “Self Diagnostic Result” mode of all systems, and check if DTC is detected.

>> Follow troubleshooting for each DTC.

# ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE [WITH INTELLIGENT KEY SYSTEM]

< SYMPTOM DIAGNOSIS >

## ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE

### Description

INFOID:000000013320668

Engine does not start when push-button ignition switch is pressed while carrying Intelligent Key.

#### NOTE:

- Before starting diagnosis check that vehicle condition is as shown in “Conditions of vehicle”, and check each symptom.
- The engine start function, door lock function, power distribution system, and NATS-IVIS/NVIS in the Intelligent Key system are closely related to each other regarding control. The vehicle security function can operate only when the door lock and power distribution system are operating normally.

### SYMPTOM TABLE (BOTH INTELLIGENT KEYS HAVE THE SAME SYMPTOMS)

Door lock operation (remote keyless entry)	Door lock operation (request switch) or back door open operation (opener switch of back door panel)	Engine started with push-button ignition switch operation (registered Intelligent Key is within the detection area of inside key antenna)	Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch)
OK	OK	No crank, No start	OK

### CONDITIONS OF VEHICLE (OPERATING CONDITIONS)

- “ENGINE START BY I-KEY” setting in “Work support” mode of “INTELLIGENT KEY” of “BCM” is ON.
- One or more Intelligent Keys with a registered Intelligent Key ID are in the vehicle.

### DIAGNOSIS PROCEDURE

Refer to [SEC-147. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000013320669

#### 1. CHECK INTELLIGENT KEY SYSTEM SYMPTOM TABLE

Check Intelligent Key system symptom table.  
Refer to [DLK-228. "Diagnosis Procedure"](#).

>> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS RESULT

Select “Self Diagnostic Result” mode of “BCM”, and check if DTC is detected.

Is DTC detected?

- YES >> Perform the trouble diagnosis for the detected DTC.
- NO >> GO TO 3.

#### 3. CHECK “ENGINE START BY I-KEY” SETTING IN “WORK SUPPORT”

1. Select “INTELLIGENT KEY” of “BCM” using CONSULT.
2. Select “ENGINE START BY I-KEY” of “Work support” mode.
3. Check “ENGINE START BY I-KEY” in “Work support”.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Set “On” in “ENGINE START BY I-KEY”.

#### 4. CHECK INSIDE KEY ANTENNA

Use SIGNAL TECH II to check each inside key antenna. For the inspection method and how to use SIGNAL TECH II, refer to “NISSAN/INFINITI SIGNAL TECH II USER GUIDE”.

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace malfunctioning parts.

# ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE

< SYMPTOM DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

---

## 5. REPLACE BCM

---

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

# ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE (ONE KEY)

< SYMPTOM DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE (ONE KEY)

### Description

INFOID:000000013320670

Engine does not start when push-button ignition switch is pressed. (One Intelligent Key has the symptom, other keys operate normally.)

SYMPTOM TABLE (ONE INTELLIGENT KEY HAS THE SYMPTOM, OTHER KEYS OPERATE NORMALLY)

Door lock operation (remote keyless entry)	Door lock operation (request switch) or back door open operation (opener switch of back door panel)	Engine started with push-button ignition switch operation (Intelligent Key is within the detection area of inside key antenna)	Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch)
OK	OK	No crank, No start	No crank, No start

### DIAGNOSIS PROCEDURE

Refer to [SEC-149, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000013320671

#### 1. CHECK INTELLIGENT KEY SYSTEM SYMPTOM TABLE

Check Intelligent Key system symptom table.  
Refer to [DLK-228, "Diagnosis Procedure"](#).

>> GO TO 2.

#### 2. REGISTER INTELLIGENT KEY

1. Register the Intelligent Key.
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.  
NO >> GO TO 3.

#### 3. REPLACE INTELLIGENT KEY

1. Replace the Intelligent Key and perform registration again.
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.  
NO >> GO TO 4.

#### 4. REPLACE BCM

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.  
NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# DOOR DOES NOT LOCK/UNLOCK AND ENGINE DOES NOT START (REQ SW/PUSH SW) (ONE KEY)

< SYMPTOM DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## DOOR DOES NOT LOCK/UNLOCK AND ENGINE DOES NOT START (REQ SW/PUSH SW) (ONE KEY)

### Description

INFOID:000000013320672

Door does not lock/unlock with door request switch, and engine does not start when push-button ignition switch is pressed while carrying Intelligent Key. (One Intelligent Key has the symptom, other keys operate normally.)

SYMPTOM TABLE (ONE INTELLIGENT KEY HAS THE SYMPTOM, OTHER KEYS OPERATE NORMALLY)

Door lock operation (remote keyless entry)	Door lock operation (request switch) or back door open operation (opener switch of back door panel)	Engine started with push-button ignition switch operation (Intelligent Key is within the detection area of inside key antenna)	Engine started with push-button ignition switch operation (registered Intelligent Key placed next to push-button ignition switch)
OK	NG	No crank, No start	OK

### DIAGNOSIS PROCEDURE

Refer to [SEC-150, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000013320673

#### 1. CHECK INTELLIGENT KEY SYSTEM SYMPTOM TABLE

Check Intelligent Key system symptom table.

Refer to [DLK-228, "Diagnosis Procedure"](#).

>> GO TO 2.

#### 2. CHECK INTELLIGENT KEY LOW BATTERY WARNING

Check that the Intelligent Key low battery warning operates.

Is the Intelligent Key low battery warning operated?

YES >> Replace Intelligent Key battery. Refer to [DLK-291, "Removal and Installation"](#).

NO >> GO TO 3.

#### 3. CHECK INTELLIGENT KEY BATTERY

Check the Intelligent Key battery.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace Intelligent Key battery. Refer to [DLK-291, "Removal and Installation"](#).

#### 4. REGISTER INTELLIGENT KEY

1. Register the Intelligent Key.

2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 5.

#### 5. REPLACE INTELLIGENT KEY

1. Replace the Intelligent Key and perform registration again.

2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 6.

#### 6. REPLACE BCM

# DOOR DOES NOT LOCK/UNLOCK AND ENGINE DOES NOT START (REQ SW/ PUSH SW) (ONE KEY)

< SYMPTOM DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

1. Replace BCM. Refer to [BCS-81, "Removal and Installation"](#).
2. Check operation after replacement.

Is the inspection result normal?

YES >> Inspection End.

NO >> Check intermittent incident. Refer to [GI-47, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

## NATS ANTENNA AMP.

< REMOVAL AND INSTALLATION >


[WITH INTELLIGENT KEY SYSTEM]

# REMOVAL AND INSTALLATION

## NATS ANTENNA AMP.

Exploded View

INFOID:000000012549649



1. NATS antenna amp.

2. Push-button ignition switch

## Removal and Installation

INFOID:000000012549650

### REMOVAL

1. Remove the instrument lower panel LH. Refer to [IP-25. "Removal and Installation"](#).
2. Disconnect the harness connector from the NATS antenna amp and the push button ignition switch.
3. Release the pawl on each side of NATS antenna amp and remove from the instrument pad (LH).
4. Release the pawl on each side and remove the NATS antenna amp from the push-button ignition switch.

### INSTALLATION

Installation is in the reverse order of removal.



# PUSH-BUTTON IGNITION SWITCH


< REMOVAL AND INSTALLATION >

[WITH INTELLIGENT KEY SYSTEM]

## PUSH-BUTTON IGNITION SWITCH

Exploded View

INFOID:000000012549651



1. NATS antenna amp.

2. Push-button ignition switch

## Removal and Installation

INFOID:000000012549652

### REMOVAL

1. Remove the instrument lower panel LH. Refer to [IP-25. "Removal and Installation"](#).
2. Disconnect the harness connector from the NATS antenna amp and the push button ignition switch.
3. Release the pawl on each side of NATS antenna amp and remove from the instrument pad (LH).
4. Release the pawl on each side and remove the NATS antenna amp from the push-button ignition switch.

### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# IMMOBILIZER CONTROL MODULE

< REMOVAL AND INSTALLATION >

[WITH INTELLIGENT KEY SYSTEM]

---

## IMMOBILIZER CONTROL MODULE

### Removal and Installation

INFOID:000000012549653

The immobilizer control module is integrated into the body control module (BCM). For removal and installation, refer to [BCS-81, "Removal and Installation"](#).