

SECTION **EL**

When you read wiring diagrams:

- Read GI section, "HOW TO READ WIRING DIAGRAMS".

When you perform trouble diagnoses, read GI section, "HOW TO FOLLOW FLOW CHART IN TROUBLE DIAGNOSES" and "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

CONTENTS

PRECAUTIONS	2	COMBINATION SWITCH	38
Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER".....	2	Combination Switch/Check.....	38
HARNES CONNECTOR	3	Replacement.....	39
Description	3	Steering Switch/Check.....	40
STANDARDIZED RELAY	4	HEADLAMP	41
Description	4	Component Parts and Harness Connector	
POWER SUPPLY ROUTING	6	Location	41
Schematic	6	System Description (For U.S.A.)	41
Wiring Diagram — POWER —	7	Schematic (For U.S.A.).....	43
Fuse	16	Wiring Diagram (For U.S.A.) — H/LAMP —	44
Fusible Link.....	16	Trouble Diagnoses/Auto Light Operation	47
Circuit Breaker Inspection	16	Headlamp/Trouble Diagnoses	54
GROUND DISTRIBUTION	17	Daytime Light System/System Description (For Canada)	55
Engine Room Harness	17	Operation (Daytime light system for Canada).....	56
Main Harness.....	18	Schematic (For Canada)	57
Engine Control Harness	20	Wiring Diagram (For Canada) — DTRL —	58
Engine Harness	22	Trouble Diagnoses (For Canada)	62
Body Harness	23	Bulb Replacement	64
Body No. 2 Harness	24	Bulb Specifications	64
BATTERY	25	Aiming Adjustment	64
How to Handle Battery	25	EXTERIOR LAMP	66
Service Data and Specifications (SDS).....	28	Parking, License and Tail Lamps/System	
STARTING SYSTEM	29	Description	66
System Description.....	29	Parking, License and Tail Lamps/Schematic.....	67
Wiring Diagram — START —	30	Parking, License and Tail Lamps/Wiring Diagram	
Construction.....	31	— TAIL/L —	68
Removal and Installation	31	Parking, License and Tail Lamps/Trouble	
Pinion/Clutch Check	32	Diagnoses	72
Service Data and Specifications (SDS).....	32	Stop Lamp/Schematic.....	73
CHARGING SYSTEM	33	Stop Lamp/Wiring Diagram — STOP/L —	74
System Description.....	33	Back-up Lamp/Wiring Diagram — BACK/L —	77
Wiring Diagram — CHARGE —	34	Front Fog Lamp/System Description.....	78
Trouble Diagnoses.....	35	Front Fog Lamp/Wiring Diagram — F/FOG —	79
Construction.....	36	Front Fog Lamp Aiming Adjustment.....	80
Removal and Installation	36	Bulb Specifications	80
Service Data and Specifications (SDS).....	37		

CONTENTS (Cont'd)

Turn Signal and Hazard Warning Lamps/ System Description	81	Wiper Linkage.....	146
Turn Signal and Hazard Warning Lamps/ Schematic	83	HORN, CIGARETTE LIGHTER AND CLOCK	147
Turn Signal and Hazard Warning Lamps/ Wiring Diagram — TURN —	84	Wiring Diagram — HORN —	147
Turn Signal and Hazard Warning Lamps/ Trouble Diagnoses.....	87	REAR WINDOW DEFOGGER	149
Combination Flasher Unit Check.....	87	Component Parts and Harness Connector	
Bulb Specifications	88	Location	149
INTERIOR LAMP	89	System Description.....	149
Illumination/System Description.....	89	Schematic.....	150
Illumination/Schematic.....	90	Wiring Diagram — DEF —	151
Illumination/Wiring Diagram — ILL —	91	Trouble Diagnoses.....	154
Vanity Mirror and Trunk Room Lamps/System Description	97	Filament Check.....	158
Bulb Specifications	97	Filament Repair	159
Vanity Mirror and Trunk Room Lamps/Wiring Diagram — INT —	98	AUDIO AND POWER ANTENNA	160
METER AND GAUGES	99	Audio/System Description.....	160
Component Parts and Harness Connector		Audio/Schematic.....	161
Location	99	Audio/Wiring Diagram — AUDIO —	162
System Description.....	99	Power Antenna/System Description	169
Combination Meter	100	Power Antenna/Wiring Diagram — P/ANT —	170
Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram — METER —	101	Trouble Diagnoses.....	171
Trouble Diagnoses.....	103	Location of Antenna.....	173
WARNING LAMPS	107	Antenna Rod Replacement	173
Warning Lamps/System Description.....	107	Window Antenna Repair	174
Schematic	109	TELEPHONE	176
Wiring Diagram — WARN —	110	Telephone Pre Wire/Schematic	176
Trouble Diagnoses.....	114	Telephone Pre Wire/Wiring Diagram	
Electrical Components Inspection	117	— PHONE —	177
A/T Indicator/Schematic.....	118	TRUNK LID AND FUEL FILLER LID OPENER	180
A/T Indicator/Wiring Diagram — AT/IND —	119	Wiring Diagram — T&FLID —	180
WARNING CHIME	122	ELECTRIC SUNROOF	182
Component Parts and Harness Connector		Wiring Diagram — SROOF —	182
Location	122	DOOR MIRROR	184
System Description.....	122	Wiring Diagram — MIRROR —	184
Wiring Diagram — CHIME —	124	INSIDE MIRROR	185
Trouble Diagnoses.....	126	Auto Anti-dazzling Inside Mirror/Wiring Diagram	
WIPER AND WASHER	132	— I/MIRR —	185
Component Parts and Harness Connector		POWER SEAT (Passenger Side)	186
Location	132	Power Seat/Schematic	186
System Description.....	132	Power Seat/Wiring Diagram — SEAT —	187
Front Wiper and Washer/Schematic.....	134	HEATED SEAT	191
Front Wiper and Washer/Wiring Diagram		Heated Seat/Wiring Diagram — HSEAT —	191
— WIPER —	135	AUTOMATIC SPEED CONTROL DEVICE (ASCD)	193
Trouble Diagnoses.....	138	Component Parts and Harness Connector	
Wiper Installation and Adjustment.....	145	Location	193
Washer Nozzle Adjustment	145	System Description.....	194
Washer Tube Layout	146	Schematic	196
		Wiring Diagram — ASCD —	197
		Trouble Diagnoses.....	202
		ASCD Wire Adjustment	215
		IVMS (LAN) — SYSTEM DESCRIPTION	216
		Overall Description	216
		Component Parts Location.....	217
		System Diagram	218

CONTENTS (Cont'd)

Sleep/Wake-up Control.....	219	REAR POWER WINDOW SWITCH ILLUMINATION	
Fail-safe System.....	219	— IVMS	339
BCM (Body Control Module)/Schematic.....	220	System Description.....	339
Local Control Units (LCUs)/Schematic.....	222	Schematic.....	340
IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM	226	Wiring Diagram — SW/ILL —.....	341
CONSULT.....	226	Trouble Diagnoses.....	344
IVMS Communication Diagnoses Results List.....	230	THEFT WARNING SYSTEM — IVMS	346
On-board Diagnosis.....	233	Component Parts Harness Connector Location.....	346
On-board Diagnosis — Mode I (IVMS communication diagnosis).....	234	System Description.....	347
On-board Diagnosis — Mode II (Switch monitor).....	236	Schematic.....	349
Main Power Supply, Ground and Communication Circuits/Schematic.....	238	Wiring Diagram — THEFT —.....	350
Main Power Supply, Ground and Communication Circuits/Wiring Diagram — COMM —.....	239	Trouble Diagnoses.....	358
Work Flow.....	243	AUTOMATIC DRIVE POSITIONER — IVMS	373
Power Supply and Ground Circuit Check.....	244	Component Parts and Harness Connector Location.....	373
Data Lines Circuit Check.....	246	System Description.....	374
POWER WINDOW — IVMS	247	Schematic.....	378
Component Parts and Harness Connector Location.....	247	Wiring Diagram — AUT/DP —.....	379
System Description.....	247	Trouble Diagnoses.....	390
Schematic.....	248	IPPS (Infiniti Personal Protection System — NATS)	422
Wiring Diagram — WINDOW —.....	249	Component Parts and Harness Connector Location.....	422
Trouble Diagnoses.....	253	System Description.....	423
POWER DOOR LOCK — IVMS	262	System Composition.....	423
Component Parts and Harness Connector Location.....	262	Wiring Diagram — NATS —.....	424
System Description.....	263	Trouble Diagnoses.....	425
Schematic.....	264	INTEGRATED HOMELINK TRANSMITTER	440
Wiring Diagram — D/LOCK —.....	265	Wiring Diagram — TRNSMT —.....	440
Trouble Diagnoses.....	269	Trouble Diagnoses.....	441
MULTI-REMOTE CONTROL SYSTEM — IVMS	283	LOCATION OF ELECTRICAL UNITS	442
Component Parts and Harness Connector Location.....	283	Engine Compartment.....	442
System Description.....	284	Luggage Compartment.....	443
Schematic.....	286	Passenger Compartment.....	444
Wiring Diagram — MULTI —.....	287	HARNES LAYOUT	446
Trouble Diagnoses.....	293	Outline.....	446
Replacing Remote Controller or BCM.....	303	How to Read Harness Layout.....	447
INTERIOR ILLUMINATION CONTROL — IVMS	306	Engine Room Harness.....	448
System Description.....	306	Instrument Harness.....	451
Schematic.....	310	Main Harness.....	452
Wiring Diagram — ROOM/L —.....	311	Engine Control Harness.....	454
Trouble Diagnoses.....	318	Body Harness and Tail Harness.....	456
STEP LAMP — IVMS	328	Body No. 2 Harness.....	458
Component Parts and Harness Connector Locations.....	328	Engine Harness.....	460
System Description.....	329	Room Lamp Harness.....	461
Schematic.....	330	Air Bag Harness.....	462
Wiring Diagram — STEP/L —.....	331	Front Door Harness.....	463
Trouble Diagnoses.....	336	Rear Door Harness.....	464
		SPLICE LOCATION	465
		How to Read Splice Location.....	465
		Engine Room Harness.....	466
		Main Harness.....	468

CONTENTS (Cont'd)

Instrument Harness469	FUSE BLOCK — Junction Box (J/B).....Foldout
Engine Control Harness470	Terminal Arrangement.....Foldout
Engine Harness471	FUSE AND FUSIBLE LINK BOXFoldout
Body Harness and Tail Harness.....472	Terminal Arrangement.....Foldout
Body No. 2 Harness473	ELECTRICAL UNITSFoldout
Room Lamp Harness.....474	Terminal Arrangement.....Foldout
SUPER MULTIPLE JUNCTION (SMJ)Foldout	JOINT CONNECTOR (J/C)Foldout
Terminal Arrangement.....Foldout	Terminal Arrangement.....Foldout

WIRING DIAGRAM REFERENCE CHART

ECCS	EC SECTION	
A/T CONTROL, SHIFT LOCK CONTROL	AT SECTION	LC
TRACTION CONTROL SYSTEM	BR SECTION	
SRS "AIR BAG"	RS SECTION	
AIR CONDITIONER	HA SECTION	EC
STEERING SYSTEM	ST SECTION	

GI

MA

EV

LC

EC

EE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

PRECAUTIONS

Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

The Supplemental Restraint System “Air Bag” and “Seat Belt Pre-tensioner”, used along with a seat belt, help to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.

HARNESS CONNECTOR

Description


HARNESS CONNECTOR

- All harness connectors have been modified to prevent accidental looseness or disconnection.
- The connector can be disconnected by pushing or lifting the locking section.

CAUTION:

Do not pull the harness when disconnecting the connector.

[Example]



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


SEL769D

STANDARDIZED RELAY

Description

NORMAL OPEN, NORMAL CLOSED AND MIXED TYPE RELAYS


Relays can mainly be divided into three types: normal open, normal closed and mixed type relays.



SEL881H

TYPE OF STANDARDIZED RELAYS













1M 1 Make 2M 2 Make
 1T 1 Transfer 1M-1B 1 Make 1 Break



SEL882H

STANDARDIZED RELAY

Description (Cont'd)

Type	Outer view	Circuit	Connector symbol and connection	Case color
1T				BLACK
2M				BROWN
1M-1B				GRAY
1M				BLUE

The arrangement of terminal numbers on the actual relays may differ from those shown above.

GI

MA

EM

LC

EC

EE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IX



POWER SUPPLY ROUTING

Wiring Diagram — POWER —

EL-POWER-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA



Refer to last page (Foldout page).

E66, M12
M4, B3



EL

IDX

POWER SUPPLY ROUTING


Wiring Diagram — POWER — (Cont'd)

EL-POWER-02




POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)




CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT



Refer to last page (Foldout page).

- (E66), (M12)
- (E70), (E81)
- (M22)


HA
EL
IDX



POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-04




Refer to last page (Foldout page).

- (E63)
- (E64)
- (M1)
- (B1)
- (B2)

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-05



Refer to last page (Foldout page).


- (E61)
- (E62)
- (M1)
- (B2)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-06



Refer to last page (Foldout page).

(E64)


(M1)

(B1)

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-07



Refer to last page (Foldout page).


- (E61)
- (E62)
- (M1)
- (B1)

GI
MA
EM
LG
EG
FE
AT
PD
FA
FA
BR
ST
RS
BT
FA
EL
DX

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-08



Refer to last page (Foldout page).

E61

E63



M1

B2

POWER SUPPLY ROUTING

Wiring Diagram — POWER — (Cont'd)

EL-POWER-09



Refer to last page (Foldout page).


- E61
- E64
- M1

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

EL


IDX

POWER SUPPLY ROUTING



Fuse

- If fuse is blown, be sure to eliminate cause of problem before installing new fuse.
- Use fuse of specified rating. Never use fuse of more than specified rating.
- Do not partially install fuse; always insert it into fuse holder properly.
- Remove fuse for "ELECTRICAL PARTS (BAT)" if vehicle is not used for a long period of time.





Fusible Link

A melted fusible link can be detected either by visual inspection or by feeling with finger tip. If its condition is questionable, use circuit tester or test lamp.

CAUTION:

- If fusible link should melt, it is possible that critical circuit (power supply or large current carrying circuit) is shorted. In such a case, carefully check and eliminate cause of problem.
- Never wrap outside of fusible link with vinyl tape. Important: Never let fusible link touch any other wiring harness, vinyl or rubber parts.



Circuit Breaker Inspection


For example, when current is 30A, the circuit is broken within 8 to 20 seconds.

Circuit breakers are used in the following systems.

- Electric sunroof
- Power seat
- Main power supply, ground and communication circuits — IVMS
- Power window — IVMS
- Power door lock — IVMS
- Multi-remote control — IVMS
- Interior lamp control — IVMS
- Step lamp — IVMS
- Illumination — IVMS
- Automatic drive positioner — IVMS
- Theft warning system — IVMS

GROUND DISTRIBUTION


Engine Room Harness



GI
 MA
 EM
 EC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 DX



GROUND DISTRIBUTION

Main Harness



GROUND DISTRIBUTION


Main Harness (Cont'd)



GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX



GROUND DISTRIBUTION

Engine Control Harness



GROUND DISTRIBUTION



Engine Control Harness (Cont'd)



CI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 EA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX




GROUND DISTRIBUTION

Engine Control Harness (Cont'd)



CEL497


Engine Harness



CEL498

GROUND DISTRIBUTION




Body Harness



GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

GROUND DISTRIBUTION

Body No. 2 Harness



BATTERY

CAUTION:

- If it becomes necessary to start the engine with a booster battery and jumper cables, use a 12-volt booster battery.
- After connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- Never add distilled water through the hole used to check specific gravity.

GI

MA

EM

EG

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX





How to Handle Battery

METHODS OF PREVENTING OVER-DISCHARGE

The following precautions must be taken to prevent over-discharging a battery.

- The battery surface (particularly its top) should always be kept clean and dry.
- The terminal connections should be clean and tight.
- At every routine maintenance, check the electrolyte level. This also applies to batteries designated as "low maintenance" and "maintenance-free".
- When the vehicle is not going to be used over a long period of time, disconnect the negative battery terminal. (If the vehicle has an extended storage switch, turn it off.)



- Check the charge condition of the battery. Periodically check the specific gravity of the electrolyte. Keep a close check on charge condition to prevent over-discharge.

CHECKING ELECTROLYTE LEVEL



WARNING:

Do not allow battery fluid to come in contact with skin, eyes, fabrics, or painted surfaces. After touching a battery, do not touch or rub your eyes until you have thoroughly washed your hands. If acid contacts eyes, skin or clothing, immediately flush with water for 15 minutes and seek medical attention.

BATTERY

How to Handle Battery (Cont'd)

- Remove the cell plug using a suitable tool.
- Add distilled water up to the MAX level.




SULPHATION

A battery will be completely discharged if it is left unattended for a long time and the specific gravity will become less than 1.100. This may result in sulphation on the cell plates.

To determine if a battery has been "sulphated", note its voltage and current when charging it. As shown in the figure, less current and higher voltage are observed in the initial stage of charging sulphated batteries.

A sulphated battery may sometimes be brought back into service by means of a long, slow charge, 12 hours or more, followed by a battery capacity test.



SPECIFIC GRAVITY CHECK

1. Read hydrometer and thermometer indications at eye level.

BATTERY

How to Handle Battery (Cont'd)

2. Use the chart below to correct your hydrometer reading according to electrolyte temperature.

Hydrometer temperature correction

Battery electrolyte temperature °C (°F)	Add to specific gravity reading	
71 (160)	0.032	GI
66 (150)	0.028	
60 (140)	0.024	WA
54 (129)	0.020	
49 (120)	0.016	
43 (110)	0.012	EM
38 (100)	0.008	
32 (90)	0.004	
27 (80)	0	LC
21 (70)	-0.004	
16 (60)	-0.008	EC
10 (50)	-0.012	
4 (39)	-0.016	
-1 (30)	-0.020	FE
-7 (20)	-0.024	
-12 (10)	-0.028	
-18 (0)	-0.032	AT

Corrected specific gravity	Approximate charge condition	
1.260 - 1.280	Fully charged	PD
1.230 - 1.250	3/4 charged	FA
1.200 - 1.220	1/2 charged	
1.170 - 1.190	1/4 charged	RA
1.140 - 1.160	Almost discharged	
1.110 - 1.130	Completely discharged	BR

CHARGING THE BATTERY

CAUTION:

- a. Do not "quick charge" a fully discharged battery.
- b. Keep the battery away from open flame while it is being charged.
- c. When connecting the charger, connect the leads first, then turn on the charger. Do not turn on the charger first, as this may cause a spark.
- d. If battery electrolyte temperature rises above 60°C (140°F), stop charging. Always charge battery at a temperature below 60°C (140°F).

Charging rates:

Amps	Time
50	1 hour
25	2 hours
10	5 hours
5	10 hours

EL

IDX

BATTERY

How to Handle Battery (Cont'd)

Do not charge at more than 50 ampere rate.

Note: The ammeter reading on your battery charger will automatically decrease as the battery charges. This indicates that the voltage of the battery is increasing normally as the state of charge improves. The charging amps indicated above refer to initial charge rate.

- If, after charging, the specific gravity of any two cells varies more than .050, the battery should be replaced.

Service Data and Specifications (SDS)

Type		80D26R
Capacity	V-AH	12-55
Cold cranking current (For reference value)	A	582

STARTING SYSTEM

System Description

Power is supplied at all times

- to ignition switch terminal ①
- through 30A fusible link (letter **G**, located in the fuse, fusible link and relay box).

With the ignition switch in the START position, power is supplied

- from ignition switch terminal ④
- to inhibitor switch terminal ①
- through inhibitor switch terminal ②, with the selector lever in the P or N position
- to terminal ① of the starter motor windings.

The starter motor plunger closes and provides a closed circuit between the battery and starter motor. The starter motor is grounded to the engine block. With power and ground supplied, cranking occurs and the engine starts.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

STARTING SYSTEM

Wiring Diagram — START —

EL-START-01



STARTING SYSTEM

Pinion/Clutch Check

1. Inspect pinion teeth.
 - Replace pinion if teeth are worn or damaged. (Also check condition of ring gear teeth.)
2. Inspect reduction gear teeth.
 - Replace reduction gear if teeth are worn or damaged. (Also check condition of armature shaft gear teeth.)
3. Check to see if pinion locks in one direction and rotates smoothly in the opposite direction.
 - If it locks or rotates in both directions, or unusual resistance is evident, replace.

Service Data and Specifications (SDS)

STARTER

Type		M2T84671
		MITSUBISHI make
		Reduction gear type
System voltage	V	12
No-load		
Terminal voltage	V	11.0
Current	A	Less than 145
Revolution	rpm	More than 3,300
Minimum diameter of commutator	mm (in)	31.4 (1.236)
Minimum length of brush	mm (in)	11.0 (0.433)
Brush spring tension	N (kg, lb)	30.9 - 37.7 (3.15 - 3.85, 6.95 - 8.47)
Clearance between pinion front edge and pinion stopper	mm (in)	0.5 - 2.0 (0.020 - 0.079)

CHARGING SYSTEM

System Description

The alternator provides DC voltage to operate the vehicle's electrical system and to keep the battery charged. The voltage output is controlled by the IC regulator.

Power is supplied at all times to alternator terminal ③ through:

- 120A fusible link (letter **a**, located in the fuse, fusible link and relay box), and
- 7.5A fuse (No. **62**, located in the fuse, fusible link and relay box).

Terminal ⑥ supplies power to charge the battery and operate the vehicle's electrical system. Output voltage is controlled by the IC regulator at terminal ③ detecting the input voltage. The charging circuit is protected by the 120A fusible link.

Terminal ⑤ of the alternator supplies ground through body ground **E112**.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. **4**, located in the fuse block (J/B)]
- to combination meter terminal **41** for the charge warning lamp.

Ground is supplied to terminal **25** of the combination meter through terminal **L** of the alternator. With power and ground supplied, the charge warning lamp will illuminate. When the alternator is providing sufficient voltage with the engine running, the ground is opened and the charge warning lamp will go off.

If the charge warning lamp illuminates with the engine running, a fault is indicated.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX



CHARGING SYSTEM

Wiring Diagram — CHARGE —


EL-CHARGE-01



Refer to EL-POWER.



Refer to last page (Foldout page).




Trouble Diagnoses

Before conducting an alternator test, make sure that the battery is fully charged. A 30-volt voltmeter and suitable test probes are necessary for the test. The alternator can be checked easily by referring to the Inspection Table.

- Before starting, inspect the fusible link.
- Use fully charged battery.

WITH IC REGULATOR



Warning lamp: "CHARGE" warning lamp in combination meter

★ When field circuit is open, check condition of rotor coil, rotor slip ring and brush. If necessary, replace faulty parts with new ones.



MALFUNCTION INDICATOR

The IC regulator warning function activates to illuminate "CHARGE" warning lamp, if any of the following symptoms occur while alternator is operating:

- B terminal is disconnected.
- S terminal is disconnected or related circuit is open.
- Field circuit is open.
- Excessive voltage is produced.

CHARGING SYSTEM

Construction



Removal and Installation

REMOVAL

1. Remove engine upper cover.
2. Remove drive belt from alternator.
3. Disconnect harness connector.
4. Remove alternator.

INSTALLATION

To install, reverse the removal procedure.

CHARGING SYSTEM

Service Data and Specifications (SDS)

ALTERNATOR

Type		LR1110-707B	GI
		HITACHI make	
Nominal rating	V-A	12 - 110	MA
Ground polarity		Negative	
Minimum revolution under no-load (When 13.5 volts is applied)	rpm	Less than 1,000	EM
Hot output current (When 13.5 volts is applied)	A/rpm	More than 34/1,300 More than 82/2,500 More than 105/5,000	LC
Regulated output voltage	V	14.1 - 14.7	EC
Minimum length of brush	mm (in)	6.0 (0.236)	
Brush spring pressure	N (g, oz)	1.000 - 3.432 (102 - 350, 3.60 - 12.34)	FE
Slip ring minimum outer diameter	mm (in)	26.0 (1.024)	AT

PD

FA

RA

BR

ST

RS

BT



HA

EL

IDX

COMBINATION SWITCH


Combination Switch/Check



FRONT WIPER SWITCH

	OFF	INT	LO	HI	WASH
13	<input type="checkbox"/>	<input type="checkbox"/>			
14	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>		
15		<input type="checkbox"/>	<input type="checkbox"/>		
16			<input type="checkbox"/>	<input type="checkbox"/>	
17		<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
18					<input type="checkbox"/>

VARIABLE INTERMITTENT WIPER VOLUME



FRONT FOG LAMP SWITCH

	ON	OFF
31	<input type="checkbox"/>	<input type="checkbox"/>
32	<input type="checkbox"/>	<input type="checkbox"/>

TURN SIGNAL SWITCH




	L	N	R
1	<input type="checkbox"/>		<input type="checkbox"/>
2	<input type="checkbox"/>		<input type="checkbox"/>
3	<input type="checkbox"/>		

LIGHTING SWITCH

	OFF	AUTO	1ST	2ND
5			<input type="checkbox"/>	<input type="checkbox"/>
11			<input type="checkbox"/>	
8				<input type="checkbox"/>
12				<input type="checkbox"/>
42		<input type="checkbox"/>		
(8)		<input type="checkbox"/>		

	A	B	C
(5)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
7	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
6	<input type="checkbox"/>		<input type="checkbox"/>
(8)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
10	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
9	<input type="checkbox"/>		<input type="checkbox"/>
(12)			<input type="checkbox"/>

COMBINATION SWITCH



Replacement



For removal and installation of spiral cable, refer to RS section ["SUPPLEMENTAL RESTRAINT SYSTEM (SRS)", "Installation — Air Bag Module and Spiral Cable"].

- Each switch can be replaced without removing combination switch base.
- To remove combination switch base, remove base attaching screw.
- Before installing steering wheel, align turn signal cancel tab with the notch of combination switch.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX


COMBINATION SWITCH

Steering Switch/Check



HEADLAMP

Component Parts and Harness Connector Location



System Description (For U.S.A.)

Power is supplied at all times

- to headlamp relay terminal ①, and
- through 15A fuse [No. 53, located in the fuse, fusible link and relay box]
- to headlamp relay terminal ⑤, and
- through 15A fuse [No. 54, located in the fuse, fusible link and relay box]
- to headlamp relay terminal ⑦, and
- through 7.5A fuse [No. 14, located in the fuse block (J/B)].
- to BCM terminal ⑩⑤.

When the ignition switch is in the ON or START position, power is supplied

- through 7.5A fuse [No. 32, located in the fuse block (J/B)]
- to BCM terminal ⑥⑧.

Ground is supplied

- to BCM terminals ⑤⑥ and ⑩③
- to illumination time control switch terminal ③
- through body grounds (M14) and (M47), and
- to the lighting switch terminals ⑧ and ⑤
- through body grounds (E22) and (E36).

HEADLAMP SWITCH OPERATION

Low beam operation

When the lighting switch is turned to 2ND and LOW ("B") positions, ground is supplied

- to headlamp relay terminal ②
- from the lighting switch terminal ⑫.

Headlamp relay is then energized, and power is supplied

- from the headlamp relay terminal ⑥
- to terminal ② of the LH headlamp, and
- from the headlamp relay terminal ③
- to terminal ② of the RH headlamp.

Ground is supplied

- to terminal ① of the LH headlamp
- from the lighting switch terminal ⑦, and
- to terminal ① of the RH headlamp

CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX

HEADLAMP

System Description (For U.S.A.) (Cont'd)

- from the lighting switch terminal ⑩ .

With power and ground supplied, the low beam headlamps illuminate.

High beam operation/flash-to-pass operation

When the lighting switch is turned to 2ND and HIGH ("A") or PASS ("C") positions, ground is supplied

- to headlamp relay terminal ②
- from the lighting switch terminal ⑫ .

Headlamp relay is then energized, and power is supplied

- from the headlamp relay terminal ⑥
- to terminal ② of the LH headlamp, and
- to combination meter terminal ③④ for the HIGH BEAM indicator
- from headlamp relay terminal ③
- to terminal ② of the RH headlamp.

Ground is supplied

- to terminal ③ of the LH headlamp, and
- to combination meter terminal ③③
- from the lighting switch terminal ⑥
- to terminal ③ of the RH headlamp
- from the lighting switch terminal ⑨ .

With power and ground supplied, the high beam headlamps illuminate.

AUTO LIGHT OPERATION

BCM is connected to the optical sensor. The optical sensor sends a signal to BCM according to outside brightness.

When the lighting switch is turned to AUTO position, ground is supplied

- to BCM terminal ⑭
- from the lighting switch terminal ⑫ .

When ignition switch is set to ON or START and outside is darker than the prescribed level, ground is supplied

- to headlamp relay terminal ②
- from the BCM terminal ⑤ .

Headlamp relay is then energized, and headlamps (Low or High) illuminate according to switch position

Auto light operation allows headlamps to turn off when outside is brighter than the prescribed level.

Or the ignition switch is turned to OFF position. (When shut off delay function is canceled.)


For parking, license and tail lamp auto operation, refer to "EXTERIOR LAMP".

SHUT OFF DELAY

While the headlamps are lit in the auto-light operation mode, the ignition switch is turned from the "ON" to the "OFF" position. The BCM no longer receives a voltage signal at terminal ⑥⑧ . This starts the auto light shut off delay timer. The timer is set based on the resistance value at BCM terminal ⑤⑦ . With the timer running, the headlamps remain lit. When the timer reaches the end of its cycle, the headlamps turn off. Headlamp lighting time can be adjusted from about 0 to 3 minutes. (This function is not applicable to the tail lamps.)

HEADLAMP

Schematic (For U.S.A.)





GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HEADLAMP

Wiring Diagram (For U.S.A.) — H/LAMP —

EL-H/LAMP-01





Refer to last page (Foldout page).
 E66, M12
 E70, E81
 M6, N1

HEADLAMP

Wiring Diagram (For U.S.A.) — H/LAMP — (Cont'd)

EL-H/LAMP-02



Refer to last page (Foldout page).

E66, M12
E70, E81
M22



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL

IDX

HEADLAMP

Wiring Diagram (For U.S.A.) — H/LAMP — (Cont'd)



Refer to last page (Foldout page).

(M6) (N1)

(M1)






(M22)

Trouble Diagnoses/Auto Light Operation

CONSULT

CONSULT inspection procedure

1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.
3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".

6. Touch "AUTO LIGHT SYSTEM".

- DATA MONITOR and ACTIVE TEST are available for the auto light.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

HEADLAMP

Trouble Diagnoses/Auto Light Operation (Cont'd)

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

HEADLAMP

Trouble Diagnoses/Auto Light Operation (Cont'd)

SYMPTOM CHART

PROCEDURE	DIAGNOSTIC PROCEDURE				
REFERENCE PAGE	EL-50	EL-50	EL-51	EL-52	EL-53
SYMPTOM	DIAGNOSTIC PROCEDURE 1 (Lighting switch "AUTO" check)	DIAGNOSTIC PROCEDURE 2 (Auto light output check)	DIAGNOSTIC PROCEDURE 3 (Optical sensor check)	DIAGNOSTIC PROCEDURE 4 (ACC and IGN input signal check)	DIAGNOSTIC PROCEDURE 5 (illumination time control switch check)
When outside is dark, neither tail lamps nor headlamps turn on by auto light operation.	X		X	X	
When outside is dark, tail lamps turn on but headlamps do not turn on by auto light operation.		X			
When outside is dark, headlamps turn on but tail lamps do not turn on by auto light operation.		X			
Light does not turn off when ignition key switch is turned to "OFF". (when shut off delay is canceled.)				X	
When outside is bright, neither tail lamps nor headlamps turn off by auto light operation.			X		
Shut off delay does not work properly.				X	X


GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IX

HEADLAMP

Trouble Diagnoses/Auto Light Operation (Cont'd)

DIAGNOSTIC PROCEDURE 1

[Lighting switch (AUTO) check]



CHECK LIGHTING SWITCH (AUTO) INPUT SIGNAL.

A CONSULT

See "AUTO LIGHT SW" in DATA MONITOR mode.

When lighting switch is in AUTO:

AUTO LIGHT SW ON
When lighting switch is OFF:
AUTO LIGHT SW OFF

OR
ON-BOARD

Perform On-board diagnosis — Mode II (Switch monitor) for light switch. Refer to EL-236.

Refer to wiring diagram in EL-45.

NG → Check the following.


- Lighting switch
- Harness for open or short between BCM and lighting switch
- Ground circuit for lighting switch

OK ↓

Lighting switch (AUTO) is OK.

DIAGNOSTIC PROCEDURE 2

(Auto light output check)



CHECK AUTO LIGHT OUTPUT SIGNAL/CIRCUIT.

A CONSULT

See "HEADLAMP RELAY" and "TAIL LAMP RELAY" in ACTIVE TEST mode, and turn lighting switch to AUTO position. **Headlamp and tail lamp should turn on.**

OR
B TESTER

1. Turn the ignition switch to ON position or lighting switch to AUTO position.
2. Check voltage between BCM terminal ⑤ or ⑾ and ground.


Output condition	Voltage [V]
Sensor not struck by light (Determined to be "dark" by sensor)	0
Sensor struck by light	Approx. 12

Refer to wiring diagram in EL-45.

OK ↓

Auto light output is OK.

NG → Check harness for open or short between BCM and headlamp relay or tail lamp relay.







HEADLAMP

Trouble Diagnoses/Auto Light Operation (Cont'd)

DIAGNOSTIC PROCEDURE 3

(Optical sensor check)



CHECK OPTICAL SENSOR INPUT SIGNAL.

A CONSULT

See "OPTICAL SEN" in DATA MONITOR mode.

When optical sensor is struck by light:

More than 3V

When optical sensor is not struck by light:

Approx. 0.5V

B TESTER

1. Turn the ignition switch to ACC position.
2. Check voltage between BCM terminal ⑤ and ground.

Condition of optical sensor	Voltage [V]
Sensor struck by light	More than 3
Sensor not struck by light	Approx. 0.5

Refer to wiring diagram in EL-46.

C CHECK OPTICAL SENSOR OPEN CIRCUIT.

1. Disconnect BCM connector and optical sensor connector.
2. Check harness continuity between BCM connector and optical sensor connector.

Terminals		Continuity
BCM	Optical sensor	
⑤	③	Yes
⑤	②	
⑤	①	

D CHECK OPTICAL SENSOR SHORT CIRCUIT.

Check harness continuity between BCM connector and body ground.

Terminals	Continuity
⑤ - ground	No
⑥ - ground	
⑦ - ground	

Replace optical sensor.

OK → Optical sensor is OK.

NG → Repair harness.

NG → Repair harness.



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HEADLAMP

Trouble Diagnoses/Auto Light Operation (Cont'd)

DIAGNOSTIC PROCEDURE 4

(ACC and IGN input signal check)



CHECK ACC AND IGN INPUT SIGNAL.

A CONSULT

See "IGN ON SW" and "IGN ACC SW" in DATA MONITOR mode.

When ignition switch is ON:

IGN ON SW ON

IGN ACC SW ON

When ignition switch is ACC:

IGN ON SW OFF

IGN ACC SW ON

When ignition switch is OFF:

IGN ON SW OFF

IGN ACC SW OFF

OR

B TESTER

Check voltage between BCM terminal ⑥ or ⑦ and ground.

Terminals	Ignition switch position			
	OFF	ACC	ON	START
⑥ - Ground	Approx. 0V	Battery voltage		Approx. 0V
⑦ - Ground	Approx. 0V		Battery voltage	

Refer to wiring diagram in EL-46.

OK

ACC and IGN input signal is OK.

NG

Check the following.


- 7.5A fuse [No. 23], located in the fuse block (J/B)
- 7.5A fuse [No. 32], located in the fuse block (J/B)
- Harness for open or short between fuse and BCM

HEADLAMP

Trouble Diagnoses/Auto Light Operation (Cont'd)

DIAGNOSTIC PROCEDURE 5

(Illumination time control switch check)



CHECK ILLUMINATION TIME CONTROL SWITCH INPUT SIGNAL.

A CONSULT

See "ILLUM TIME" in DATA MONITOR mode.

When time control switch is fully turned to short time

Approx. 0 kΩ

When time control switch is fully turned to long time

Approx. 1 kΩ

B TESTER

1. Disconnect BCM connector.
2. Check resistance between BCM terminal ⑤ and ground.

Time control switch condition	Resistance (kΩ)
Fully short	Approx. 0
Fully long	Approx. 1

Refer to wiring diagram in EL-46.

OK

Illumination time control switch is OK.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST



RS

BT

HA

EL

IDX



C CHECK ILLUMINATION TIME CONTROL SWITCH.

1. Disconnect illumination time control switch.
2. Check resistance between illumination time control switch terminals ① and ③.

Time control switch condition	Resistance (kΩ)
Fully short	Approx. 0
Fully long	Approx. 1

NG

Replace illumination time control switch.

OK

Check the following:

- Illumination time control switch ground circuit.
- Harness for open or short between BCM and illumination time control switch

HEADLAMP

Headlamp/Trouble Diagnoses

Symptom	Possible cause	Repair order
LH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. 15A fuse 3. Lighting switch 4. Headlamp relay 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check 15A fuse (No. <u>54</u>, located in fusible link). 3. Check lighting switch. 4. Check headlamp relay.
RH headlamps do not operate.	<ol style="list-style-type: none"> 1. Bulb 2. 15A fuse 3. Lighting switch 4. Headlamp relay 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check 15A fuse (No. <u>53</u>, located in fusible link). 3. Check lighting switch. 4. Check headlamp relay.
Neither headlamp illuminates.	<ol style="list-style-type: none"> 1. Headlamp relay 2. Lighting switch 3. Lighting switch ground circuit. 4. Open in headlamp relay circuit 	<ol style="list-style-type: none"> 1. Check headlamp relay. 2. Check lighting switch. 3. Check lighting switch ground circuit. 4. Check harness between headlamp relay terminal <u>②</u> and lighting switch terminal <u>⑫</u> for an open circuit.
LH high beam does not operate, but LH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH high beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check harness between lighting switch terminal <u>⑥</u> and LH headlamp for an open circuit. 3. Check lighting switch.
LH low beam does not operate, but LH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in LH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check harness between lighting switch terminal <u>⑦</u> and LH headlamp for an open circuit. 3. Check lighting switch.
RH high beam does not operate, but RH low beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH high beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check harness between lighting switch terminal <u>⑨</u> and RH headlamp for an open circuit. 3. Check lighting switch.
RH low beam does not operate, but RH high beam operates.	<ol style="list-style-type: none"> 1. Bulb 2. Open in RH low beam circuit 3. Lighting switch 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check harness between lighting switch terminal <u>⑩</u> and RH headlamp for an open circuit. 3. Check lighting switch.
High beam indicator does not work.	<ol style="list-style-type: none"> 1. Bulb 2. Open in high beam circuit 	<ol style="list-style-type: none"> 1. Check bulb in combination meter. 2-1. Check harness between lighting switch and combination meter for an open circuit. 2-2. Verify battery positive voltage is present at terminal <u>⑬</u> of combination meter, when high beam illuminates.

Daytime Light System/System Description (For Canada)

The headlamp system for Canada vehicles contains a daytime light control unit that activates the high beam headlamps at approximately half illumination whenever the engine is running. If the parking brake is applied before the engine is started the daytime lights will not be illuminated. The daytime lights will illuminate once the parking brake is released. Thereafter, the daytime lights will continue to operate when the parking brake is applied.

Power is supplied at all times

- to headlamp relay terminal ① , and
- through 15A fuse (No. 53 , located in the fuse and fusible link box)
- to headlamp relay terminal ⑤ , and
- through 15A fuse (No. 54 , located in the fuse and fusible link box)
- to headlamp relay terminal ⑦ .

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 20], located in the fuse block (J/B)
- to daytime light control unit terminal ③ .

With the ignition switch in the START position, power is supplied

- through 7.5A fuse [No. 34 , located in the fuse block (J/B)]
- to daytime light control unit terminal ② .

Ground is supplied to daytime light control unit terminal ⑩ through body grounds E22 and E36 .

GI
MA
EM
LC
EC
FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

HEADLAMP SWITCH OPERATION

When the lighting switch is turned to 2ND or PASS ("C") positions, ground is supplied

- to headlamp relay terminal ②
- from the lighting switch terminal ⑫ .

Headlamp relay is then energized, and power is supplied

- from the headlamp relay terminal ⑥
- to combination meter terminal ③④ for the HIGH BEAM indicator and
- through daytime light control unit terminals ⑤ and ⑥
- to terminal ② of the LH headlamp.

Power is also supplied

- from the headlamp relay terminal ③
- through daytime light control unit terminals ④ and ⑦
- to terminal ② of the RH headlamp.

Low beam operation

When the lighting switch is turned to 2ND and LOW ("B") positions, ground is supplied

- to terminal ① of the LH headlamp
- through daytime light control unit terminals ⑪ and ⑫
- through lighting switch terminals ⑩ and ⑧
- through body grounds E22 and E36 .

Ground is also supplied

- to terminal ① of the RH headlamp
- through daytime light control unit terminals ⑧ and ⑮
- through lighting switch terminals ⑦ and ⑤
- through body grounds E22 and E36 .

With power and ground supplied, the low beam headlamps illuminate.

High beam operation/flash-to-pass operation

When the lighting switch is turned to 2ND and HIGH ("A") or PASS ("C") positions, ground is supplied

- to terminal ③ of LH headlamp and combination meter terminal ③③ for the HIGH BEAM indicator
- through daytime light control unit terminals ⑩ and ⑬
- through lighting switch terminals ⑨ and ⑧
- through body grounds E22 and E36 .

Ground is also supplied

- to terminal ③ of RH headlamp
- through daytime light control unit terminals ⑨ and ⑭
- through lighting switch terminals ⑥ and ⑤
- through body grounds E22 and E36 .

With power and ground supplied, the high beam headlamps illuminate.

HEADLAMP

Daytime Light System/System Description (For Canada) (Cont'd)

AUTO LIGHT OPERATION

For auto light operation, refer to "HEADLAMP" (EL-41).

DAYTIME LIGHT OPERATION

With the engine running, the lighting switch in the OFF or 1ST position and parking brake released, power is supplied

- through daytime light control unit terminal ⑦
- to terminal ② of RH headlamp
- through terminal ③ of RH headlamp
- to daytime light control unit terminal ⑨
- through daytime light control unit terminal ⑥
- to terminal ② of LH headlamp.

Ground is supplied to terminal ③ of LH headlamp.

- through daytime light control unit terminals ⑩ and ⑯
- through body grounds (E22) and (E36).

Because the high beam headlamps are now wired in series, they operate at half illumination.

Operation (Daytime light system for Canada)

After starting the engine with the lighting switch in the "OFF" or "1ST" position, the headlamp high beam automatically turns on. Lighting switch operations other than the above are the same as conventional light systems.

Engine		With engine stopped									With engine running									
		OFF			1ST			2ND			OFF			1ST			2ND			
		A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	A	B	C	
Headlamp	High beam	X	X	○	X	X	○	○	X	○	△*	△*	○	△*	△*	○	○	○	X	○
	Low beam	X	X	X	X	X	X	X	○	X	X	X	X	X	X	X	X	X	○	X
Parking and tail lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○	○
License and instrument illumination lamp		X	X	X	○	○	○	○	○	○	X	X	X	○	○	○	○	○	○	○

○ : Lamp "ON"

X : Lamp "OFF"

△ : Lamp dims.


□ : Added functions

*: When starting the engine with the parking brake released, the daytime light will come ON.

When starting the engine with the parking brake pulled, the daytime light won't come ON.

HEADLAMP






Schematic (For Canada)



CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HEADLAMP Wiring Diagram (For Canada) — DTRL — (Cont'd)

EL-DTRL-02



Refer to last page (Foldout page).

E66, M12

E70, E81

M22

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA



EL

IDX

HEADLAMP

Wiring Diagram (For Canada) — DTRL — (Cont'd)

EL-DTRL-03








Refer to last page (Foldout page).

- (E66), (M12)
- (E64)

HEADLAMP

Wiring Diagram (For Canada) — DTRL — (Cont'd)



Refer to last page (Foldout page).

M6, N1

M1

M22














G
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HEADLAMP

Trouble Diagnoses (For Canada)






DAYTIME LIGHT CONTROL UNIT INSPECTION TABLE

(Data are reference values.)

Terminal No.	Item	Condition	Judgement standard
1	Alternator	 When turning ignition switch to "ON"	1V or less
		 When engine is running	Battery positive voltage
		 When turning ignition switch to "OFF"	1V or less
2	Start signal	 When turning ignition switch to "ST"	Battery positive voltage
		 When turning ignition switch to "ON" from "ST"	1V or less
		 When turning ignition switch to "OFF"	1V or less
3	Power source	 When turning ignition switch to "ON"	Battery positive voltage
		 When turning ignition switch to "ST"	Battery positive voltage
		 When turning ignition switch to "OFF"	1V or less
4	Power source	When lighting switch is turned to "2ND" or PASS ("C") position	Battery positive voltage
		Except the above	1V or less
5	Power source	When lighting switch is turned to "2ND" or PASS ("C") position	Battery positive voltage
		Except the above	1V or less
6	LH headlamp control (ground)	When lighting switch is turned to "2ND" or PASS ("C") position	Battery positive voltage
		  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage
		Except the above	1V or less
7	RH headlamp control (ground)	When lighting switch is turned to "2ND" or PASS ("C") position	Battery positive voltage
		  When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Battery positive voltage
		Except the above	1V or less


HEADLAMP

Trouble Diagnoses (For Canada) (Cont'd)

Terminal No.	Item	Condition		Judgement standard
8	RH low beam		When turning lighting switch "2ND" and LOW ("B") position	1V or less
9	RH high beam		When turning lighting switch to "2ND" and HIGH ("A") or PASS ("C") positions	1V or less
		 	When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	Approx. half battery voltage
10	LH high beam		When turning lighting switch to "2ND" and HIGH ("A") or PASS ("C") positions	1V or less
		 	When releasing parking brake with engine running and turning lighting switch to "OFF" (daytime light operation) CAUTION: Block wheels and ensure selector lever is in N or P position.	1V or less
11	LH low beam		When turning lighting switch "2ND" and LOW ("B") position	1V or less
12	Lighting switch (LH low beam)		When turning lighting switch "2ND" and LOW ("B") position	1V or less
13	Lighting switch (LH high beam)		When turning lighting switch "2ND" and HIGH ("A") or PASS ("C") position	1V or less
14	Lighting switch (RH high beam)		When turning lighting switch "2ND" and HIGH ("A") or PASS ("C") position	1V or less
15	Lighting switch (RH low beam)		When turning lighting switch "2ND" and LOW ("B") position	1V or less
16	Ground		—	—
17	Parking brake switch		When parking brake is released	Battery positive voltage
			When parking brake is set	1.5V or less

CI
MA
EM
LC
EC
FE
AT
PD
EA
RA
BR
ST
RS
BT
HA
EL
IDX

HEADLAMP



Bulb Replacement

The headlamp is a semi-sealed beam type which uses a replaceable halogen bulb. The bulb can be replaced from the engine compartment side without removing the headlamp body.

- **Grasp only the plastic base when handling the bulb. Never touch the glass envelope.**

1. Disconnect the battery cable.
2. Turn the bulb retaining ring counterclockwise until it is free from the headlamp reflector, and then remove it.
3. Disconnect the harness connector from the back side of the bulb.
4. Remove the headlamp bulb carefully. Do not shake or rotate the bulb when removing it.
5. Install in the reverse order of removal.

CAUTION:

- **Do not leave headlamp reflector without bulb for a long period of time. Dust, moisture, smoke, etc. entering headlamp body may affect the performance of the headlamp. Remove headlamp bulb from the headlamp reflector just before a replacement bulb is installed.**

Bulb Specifications

Item	Wattage (W)
Semi-sealed beam High/Low	60/55


Aiming Adjustment

When performing headlamp aiming adjustment, use an aiming machine, aiming wall screen or headlamp tester. Aimers should be in good repair, calibrated and operated in accordance with respective operation manuals.

If any aimer is not available, aiming adjustment can be done as follows:

For details, refer to the regulations in your own country.

- a. **Keep all tires inflated to correct pressures.**
- b. **Place vehicle and tester on one and same flat surface.**
- c. **See that there is no-load in vehicle (coolant, engine oil filled up to correct level and full fuel tank) other than the driver (or equivalent weight placed in driver's position).**




Before performing aiming adjustment, make sure of the following.

- a. **Keep all tires inflated to correct pressure.**
- b. **Place vehicle on level ground.**
- c. **See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.**


HEADLAMP

Aiming Adjustment (Cont'd)


LOW BEAM



1. Open the hood.
2. Adjust the vertical indicator by turning the adjusting screw (vertical direction).
The bubble in the gauge should be centered on the "O" mark as shown in the figure.



3. Adjust the horizontal indicator by turning the adjusting screw. (horizontal direction)
The inner red line should align with the indicator line.



If the vehicle front body has been repaired and/or the headlamp assembly has been replaced, check aiming. Use the aiming chart shown in the figure.

- Upper edge and left edge of high intensity zone should be within the range shown at left. Adjust headlamps accordingly.
 - Dotted lines in illustration show center of headlamp.
- "H": Horizontal center line of headlamps
 "W_L": Distance between each headlamp center

EXTERIOR LAMP

Parking, License and Tail Lamps/System Description

Power is supplied at all times

- to tail lamp relay terminals ① and ⑥
- through 15A fuse [No. ⑥③], located in the fuse, fusible link and relay box].

Ground is supplied

- to the lighting switch terminals ⑤ and ⑧
- through body grounds ②② and ③⑥.

SWITCH OPERATION

When the lighting switch is turned to 1ST or 2ND position, ground is supplied

- to tail lamp relay terminal ②
- from the lighting switch terminal ⑩.

Tail lamp relay is then energized, and power is supplied

- from tail lamp relay terminal ⑦
- to power terminals of parking, license and tail lamps.

With power supplied, parking, license and tail lamps illuminate.

AUTO LIGHT OPERATION

BCM is connected to the optical sensor. The optical sensor sends a signal to BCM according to outside brightness.

When the lighting switch is turned to AUTO position, ground is supplied

- to BCM terminal ⑭
- from the lighting switch terminal ④.

When ignition switch is set to ON or START and outside is darker than the prescribed level, ground is supplied

- to tail lamp relay terminal ②
- from the BCM terminal ⑩.

Tail lamp relay is then energized, and parking, license and tail lamps illuminate.


Auto light operation allows these lamps to turn off when outside is brighter than the prescribed level.

Or the ignition switch is turned to the OFF position.

For detailed wiring diagram of auto light, refer to "HEADLAMP".

EXTERIOR LAMP

Parking, License and Tail Lamps/Schematic









GI
MA
EM
LC
LC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

EXTERIOR LAMP

Parking, License and Tail Lamps/Wiring Diagram — TAIL/L —

EL-TAIL/L-01







Refer to last page (Foldout page).
 E66, M12
 E70, E81
 M4, B3
 M22

EXTERIOR LAMP

Parking, License and Tail Lamps/Wiring Diagram — TAIL/L — (Cont'd)

EL-TAIL/L-04



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX


EXTERIOR LAMP

Parking, License and Tail Lamps/Trouble Diagnoses

Symptom	Possible cause	Repair order
Parking, license and tail lamps do not operate.	<ol style="list-style-type: none">1. 15A fuse2. Tail lamp relay3. Lighting switch4. Open in tail lamp relay circuit	<ol style="list-style-type: none">1. Check 15A fuse (No. 63), located in fuse, fusible link and relay box).2. Check tail lamp relay.3. Check lighting switch.4. Check harness between tail lamp relay terminal ② and lighting switch terminal ⑩ for an open circuit.
Individual lamps do not operate.	<ol style="list-style-type: none">1. Bulb2. Lamp ground3. Open circuit	<ol style="list-style-type: none">1. Check bulb.2. Check lamp ground circuit.3. Check harness between power supply terminal of lamp and tail lamp relay terminal ⑦ for an open circuit.
Auto light malfunctioning.	—	Refer to trouble diagnoses in "HEADLAMP" (EL-47).

EXTERIOR LAMP

Stop Lamp/Schematic



(RS) : Models with rear air spoiler



(ER) : Models without rear air spoiler

- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

EXTERIOR LAMP

Stop Lamp/Wiring Diagram — STOP/L —

EL-STOP/L-01







Refer to last page (Foldout page).

M4, B3
M1

EXTERIOR LAMP

Stop Lamp/Wiring Diagram — STOP/L — (Cont'd)

EL-STOP/L-02



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA



EL

IDX

EXTERIOR LAMP

Stop Lamp/Wiring Diagram — STOP/L — (Cont'd)





EL-STOP/L-03



EXTERIOR LAMP

Back-up Lamp/Wiring Diagram — BACK/L —

EL-BACK/L-01



Refer to last page (Foldout page).
B1

CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL
IDX

Front Fog Lamp/System Description

Power is supplied at all times

- to fog lamp relay terminal ③
- through 15A fuse [No. 40], located in the fuse block (J/B),
- to headlamp relay terminal ⑤
- through 15A fuse (No. 53, located in the fuse, fusible link and relay box) and
- to headlamp relay terminal ①.

When the lighting switch in the 2ND position, ground is supplied

- to headlamp relay terminal ②
- through lighting switch terminal ⑫
- to lighting switch terminal ⑧
- through body grounds (E22) and (E36).

The headlamp relay is energized and power is supplied

- to fog lamp relay terminal ②
- from headlamp relay terminal ③.

FOG LAMP OPERATION

The fog lamp switch is built into the combination switch. The lighting switch must be in the 2ND position and LOW ("B") position for fog lamp operation. With the fog lamp switch in the ON position, ground is supplied

- to fog lamp relay terminal ①
- through front fog lamp switch terminal ⑩
- to front fog lamp switch terminal ⑩
- through lighting switch terminal ⑩
- to lighting switch terminal ⑧
- through body grounds (E22) and (E36).


The fog lamp relay is energized and power is supplied

- from fog lamp relay terminal ⑤
- to terminal ① of each fog lamp.

Ground is supplied to terminal ② of each fog lamp through body grounds (E22) and (E36). With power and ground supplied, the fog lamps illuminate.

EXTERIOR LAMP

Front Fog Lamp/Wiring Diagram — F/FOG —




EL-F/FOG-01

Refer to EL-POWER.

To EL-H/LAMP. DTRL

Refer to last page (Foldout page).



- E66, M12
- E70, E81
- M4, B3
- M49, F63
- B2

EL

FDX




EXTERIOR LAMP

Front Fog Lamp Aiming Adjustment

Before performing aiming adjustment, make sure of the following.

- Keep all tires inflated to correct pressure.
- Place vehicle on level ground.
- Check that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver's seat.

Adjust aiming in the vertical direction by turning the adjusting screw.



- Set the distance between the screen and the center of the fog lamp lens as shown at left.
- Turn front fog lamps ON.

- Adjust front fog lamps so that the top edge of the high intensity zone is 100 mm (4 in) below the height of the fog lamp centers as shown at left.
 - When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.

Bulb Specifications

Item	Wattage (W)
Front fog lamp	55

Turn Signal and Hazard Warning Lamps/ System Description

TURN SIGNAL OPERATION

With the hazard switch in the OFF position and the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 19], located in the fuse block (J/B)
- to hazard switch terminal ②
- through terminal ① of the hazard switch
- to combination flasher unit terminal ①
- through terminal ③ of the combination flasher unit
- to turn signal switch terminal ①.

Ground is supplied to combination flasher unit terminal ② through body grounds M14 and M47.

LH turn

When the turn signal switch is moved to the LH position, power is supplied from turn signal switch terminal ③ to

- front combination lamp LH terminal ③
- rear combination lamp LH terminal ②
- combination meter terminal ③.

Ground is supplied to the front combination lamp LH terminal ② through body grounds E22 and E36.

Ground is supplied to the rear combination lamp LH terminal ④ through body grounds T12, B22 and B35.

Ground is supplied to combination meter terminal ③ through body grounds M14 and M47.

With power and ground supplied, the combination flasher unit controls the flashing of the LH turn signal lamps.

RH turn

When the turn signal switch is moved to the RH position, power is supplied from turn signal switch terminal ② to

- front combination lamp RH terminal ③
- rear combination lamp RH terminal ②
- combination meter terminal ③.

Ground is supplied to the front combination lamp RH terminal ② through body grounds E22 and E36.

Ground is supplied to the rear combination lamp RH terminal ④ through body grounds T12, B22 and B35.

Ground is supplied to combination meter terminal ③ through body grounds M14 and M47.

With power and ground supplied, the combination flasher unit controls the flashing of the RH turn signal lamps.

HAZARD LAMP OPERATION

Power is supplied at all times to hazard switch terminal ③ through:

- 10A fuse [No. 13], located in the fuse block (J/B).

With the hazard switch in the ON position, power is supplied

- through terminal ① of the hazard switch
- to combination flasher unit terminal ①
- through terminal ③ of the combination flasher unit
- to hazard switch terminal ④.

Ground is supplied to combination flasher unit terminal ② through body grounds M14 and M47.

Power is supplied through terminal ⑤ of the hazard switch to

- front combination lamp LH terminal ③
- rear combination lamp LH terminal ②
- combination meter terminal ③.

Power is supplied through terminal ⑥ of the hazard switch to

- front combination lamp RH terminal ③
- rear combination lamp RH terminal ②
- combination meter terminal ③.

Ground is supplied to terminal ② of each front combination lamp through body grounds E22 and E36.

Ground is supplied to terminal ④ of each rear combination lamp through body grounds T12, B22 and B35.

Ground is supplied to combination meter terminal ③ through body grounds M14 and M47.

With power and ground supplied, the combination flasher unit controls the flashing of the hazard warning lamps.

WITH MULTI-REMOTE CONTROL SYSTEM

Power is supplied at all times

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/ System Description (Cont'd)

- through 10A fuse [No. 13], located in the fuse block (J/B)]
- to multi-remote control relay terminals ①, ③ and ⑥.

Ground is supplied to multi-remote control relay terminal ②, when the multi-remote control system is triggered through the BCM (Body Control Module).

Refer to "MULTI-REMOTE CONTROL SYSTEM" (EL-284).

The multi-remote control relay is energized.

Power is supplied through terminal ⑤ of the multi-remote control relay

- to front combination lamp LH terminal ③,
- to rear combination lamp LH terminal ② and
- to combination meter terminal ③⑤.

Power is supplied through terminal ⑦ of the multi-remote control relay

- to front combination lamp RH terminal ③,
- to rear combination lamp RH terminal ② and
- to combination meter terminal ③②.

Ground is supplied to terminal ② of each front combination lamp through body grounds E22 and E36.

Ground is supplied to terminal ④ of each rear combination lamp through body grounds T12, B22 and B35.



Ground is supplied to combination meter terminal ③① through body grounds M14 and M47.

With power and ground supplied, the BCM controls the flashing of the hazard warning lamps.

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/ Wiring Diagram — TURN —

EL-TURN-01





Refer to last page (Foldout page).

- (E66) (M12)
- (E70) (E81)
- (M6) (N1)
- (M50) (B101)
- (M1)

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/ Wiring Diagram — TURN — (Cont'd)

EL-TURN-03




Refer to last page (Foldout page).
 E70, E81
 E62
 E64
 M1
 B1

EXTERIOR LAMP

Turn Signal and Hazard Warning Lamps/ Trouble Diagnoses

Symptom	Possible cause	Repair order
Turn signal and hazard warning lamps do not operate.	<ol style="list-style-type: none"> 1. Hazard switch 2. Combination flasher unit 3. Open in combination flasher unit circuit 	<ol style="list-style-type: none"> 1. Check hazard switch. 2. Refer to combination flasher unit check. (EL-87) 3. Check wiring to combination flasher unit for open circuit.
Turn signal lamps do not operate but hazard warning lamps operate.	<ol style="list-style-type: none"> 1. 7.5A fuse 2. Hazard switch 3. Turn signal switch 4. Open in turn signal switch circuit 	<ol style="list-style-type: none"> 1. Check 7.5A fuse [No. 19], located in the fuse block (J/B)]. Turn ignition switch ON and verify battery positive voltage is present at terminal ② of hazard switch. 2. Check hazard switch. 3. Check turn signal switch. 4. Check L/B wire between combination flasher unit and turn signal switch for open circuit.
Hazard warning lamps do not operate but turn signal lamps operate.	<ol style="list-style-type: none"> 1. 10A fuse 2. Hazard switch 3. Open in hazard switch circuit 	<ol style="list-style-type: none"> 1. Check 10A fuse [No. 13], located in the fuse block (J/B)]. Verify battery positive voltage is present at terminal ③ of hazard switch. 2. Check hazard switch. 3. Check L/B wire between combination flasher unit and hazard switch for open circuit.
Front turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (E22) and (E36) 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds (E22) and (E36).
Rear turn signal lamp LH or RH does not operate.	<ol style="list-style-type: none"> 1. Bulb 2. Grounds (T12), (B22) and (B35) 	<ol style="list-style-type: none"> 1. Check bulb. 2. Check grounds (T12), (B22) and (B35).
LH and RH turn indicators do not operate.	<ol style="list-style-type: none"> 1. Grounds (M14) and (M47) 	<ol style="list-style-type: none"> 1. Check grounds (M14) and (M47).
LH or RH turn indicator does not operate.	<ol style="list-style-type: none"> 1. Bulb 	<ol style="list-style-type: none"> 1. Check bulb in combination meter.



Combination Flasher Unit Check

- Before checking, ensure that bulbs meet specifications.
- Connect a battery and test lamp to the combination flasher unit, as shown. Combination flasher unit is properly functioning if it blinks when power is supplied to the circuit.

EXTERIOR LAMP

Bulb Specifications

Item	Wattage (W)
Headlamp (Semi-sealed beam)	
High/Low	60/55
Front fog lamp	55
Front combination lamp	
Parking/Turn signal lamp	8/27
Rear combination lamp	
Turn signal lamp	21
Stop/Tail lamp	21/5
Tail lamp (Trunk lid side)	5
Back-up lamp	21
License lamp	5
High-mounted stop lamp (Models with rear air spoiler)	3.8
High-mounted stop lamp (Models without rear air spoiler)	18

INTERIOR LAMP

Illumination/System Description

Power is supplied at all times

- through 15A fuse (No. 63, located in the fuse, fusible link and relay box)
- to tail lamp relay terminals ① and ⑥.

Ground is supplied to tail lamp relay terminal ②, when the lighting switch is moved to the 1ST or 2ND position. The tail lamp relay is energized.

The lighting switch must be in the 1ST or 2ND position for illumination.

The illumination control switch that controls the amount of current to the illumination system. As the amount of current increases, the illumination becomes brighter.


The following chart shows the power and ground connector terminals for the components included in the illumination system.

Component	Connector No.	Power terminal	Ground terminal
Combination meter	(N12), (N13)	⑥	⑩
Rear cigarette lighter	(D45), (D65)	③	— (Unit ground)
Rear ashtray	(D44), (D64)	①	②
Illumination control switch	(N23)	①	⑤
Glove box lamp	(M26)	①	②
ASCD main switch	(N3)	⑤	⑥
TCS switch	(N7)	⑤	⑥
Radio	(N20)	⑧	⑦
Illumination time control switch	(N8)	②	④
Front cigarette lighter	(N6)	②	— (Unit ground)
A/C control unit	(N17)	①	④
Hazard switch	(N22)	⑦	⑧
A/T device	(M36)	③	④
Power window main switch	(D12)	②	①
Auto anti-dazzling inside mirror	(R4)	③	④
Driver door control unit	(D13)	②	⑩
Passenger door control unit	(D29)	②	⑩
Telephone switch	(N25)	④	⑩

The ground for all of the components except for rear ashtray, and rear cigarette lighter, glove box lamp and front cigarette lighter are controlled through terminals ④ and ⑤ of the illumination control switch and body grounds (M14) and (M47).

INTERIOR LAMP



Illumination/Schematic



INTERIOR LAMP

Illumination/Wiring Diagram — ILL —

EL-ILL-01



Refer to last page (Foldout page).

- (E66) (M12)
- (E70) (E81)
- (M6) (N1)
- (M22)



GI
MA
EM
LC
EC
FE
AT
PD
FA
FA
BR
ST
RS
BT
HA

EL

IDX

INTERIOR LAMP Illumination/Wiring Diagram — ILL — (Cont'd)

EL-ILL-02





Refer to last page (Foldout page).

- (M50) . (B101)
- (E62)
- (M1)
- (M22)
- (B1)

INTERIOR LAMP

Illumination/Wiring Diagram — ILL — (Cont'd)

EL-ILL-03



Refer to last page (Foldout page).

M6, N1

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

INTERIOR LAMP

Illumination/Wiring Diagram — ILL — (Cont'd)


EL-ILL-04






INTERIOR LAMP

Illumination/Wiring Diagram — ILL — (Cont'd)


EL-ILL-05



CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT



Refer to last page (Foldout page).







EL

IDX

INTERIOR LAMP

Illumination/Wiring Diagram — ILL — (Cont'd)

EL-ILL-06



Refer to last page (Foldout page).
M48, D21

INTERIOR LAMP

Vanity Mirror and Trunk Room Lamps/System Description

Power is supplied at all times

- through 10A fuse [No. 27] located in the fuse block (J/B)]
- to vanity mirror lamp (driver's is side) terminal ①,
- to vanity mirror lamp (passenger side) terminal ① and
- to trunk room lamp terminal ①.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

VANITY MIRROR LAMP

With vanity mirror lamp switch ON, ground is supplied

- to vanity mirror lamp terminal ②
- through body grounds (M14) and (M47).

With power and ground supplied, the vanity mirror lamp turns ON.

TRUNK ROOM LAMP

When the trunk room lamp switch is in OPEN position, ground is supplied

- to trunk room lamp terminal ②
- through trunk room switch terminal ①
- to trunk room lamp switch terminal ②
- through body grounds (B22), (B35) and (T12).

With power and ground supplied, the trunk room lamp turns ON.








Bulb Specifications

Item	Wattage (W)
Vanity mirror lamp	1.4
Trunk room lamp	3.4

INTERIOR LAMP

Vanity Mirror and Trunk Room Lamps/Wiring Diagram — INT —


EL-INT/L-01



Refer to last page (Foldout page).



Component Parts and Harness Connector Location



System Description

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 4], located in the fuse block (J/B).
- to combination meter terminal ④.

Ground is supplied

- to combination meter terminals ⑭, ⑳ and ④③
- through body grounds ①④ and ①④⑦.

FUEL GAUGE

The fuel gauge indicates the approximate fuel level in the fuel tank.

The fuel gauge is regulated by a variable ground signal supplied

- to combination meter terminal ① for the fuel gauge
- from terminal ⑤ of the fuel tank gauge unit
- through terminal ④ of the fuel tank gauge unit and
- through body grounds ①②② and ①③⑤.

WATER TEMPERATURE GAUGE

The water temperature gauge indicates the engine coolant temperature. The reading on the gauge is based on the resistance of the thermal transmitter.

As the temperature of the coolant increases, the resistance of the thermal transmitter decreases. A variable ground is supplied to terminal ④⑥ of the combination meter for the water temperature gauge. The needle on the gauge moves from "C" to "H".

TACHOMETER

The tachometer indicates engine speed in revolutions per minute (rpm).

The tachometer is regulated by a signal

- from terminal ⑤ of the ECM (ECCS control module)
- to combination meter terminal ②⑨ for the tachometer.

SPEEDOMETER

The vehicle speed sensor provides a voltage signal to the combination meter for the speedometer.

The voltage is supplied


- to combination meter terminals ⑧ and ⑨ for the speedometer
- from terminals ① and ② of the vehicle speed sensor.

The speedometer converts the voltage into the vehicle speed displayed.


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

METER AND GAUGES

Combination Meter



(US) : For U.S.A.
(CA) : For Canada




(N12)



(N13)







(N14)



METER AND GAUGES

Speedometer, Tachometer, Temp. and Fuel Gauges/Wiring Diagram — METER —

EL-METER-01



Refer to last page (Foldout page).

- (M6) (N1)
- (M49) (F63)
- (M1)
- (F69)


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL

DX

Trouble Diagnoses

INSPECTION/FUEL GAUGE AND/OR WATER TEMPERATURE GAUGE



A

CHECK POWER SUPPLY CIRCUIT.


- 1) Turn ignition switch "ON".
- 2) Check voltage between combination meter terminal ④ and ground.

Battery voltage should exist.

NG

Check the following.

- 7.5A fuse [No. ④], located in the fuse block (J/B)
- Harness for open or short between fuse and combination meter



B


CHECK GROUND CIRCUIT FOR GAUGES.

Check continuity between combination meter terminals ⑬, ⑭ and ground.

Continuity should exist.




NG

Repair harness or connector.







METER AND GAUGES

Trouble Diagnoses (Cont'd)











INSPECTION/TACHOMETER



METER AND GAUGES

Trouble Diagnoses (Cont'd)

INSPECTION/SPEEDOMETER AND VEHICLE SPEED SENSOR



METER AND GAUGES


Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

Fuel tank gauge unit check

- For removal, refer to FE section.

Check the resistance between terminals ④ and ⑤.




Ohmmeter		Float position		Resistance value (Ω)
(+)	(-)	mm (in)		
⑤	④	*1	Full	70 (2.76)
		*2	1/2	189 (7.44)
		*3	Empty	308 (12.13)

*1 and *3: When float rod is in contact with stopper.

Thermal transmitter check


Check the resistance between the terminals of thermal transmitter and body ground.



Water temperature	Resistance
60°C (140°F)	Approx. 170 - 210Ω
100°C (212°F)	Approx. 47 - 53Ω

Vehicle speed sensor signal check

1. Remove vehicle speed sensor from transmission.
2. Turn vehicle speed sensor pinion quickly and measure voltage between terminals ② and ①.



Warning Lamps/System Description

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 4], located in the fuse block (J/B)
- to combination meter terminals 41.

Ground is supplied:

- to combination meter terminals 31 and
- A/T device (OD control switch) terminal 2
- through body grounds M14 and M47.

Ground is supplied:

- to fuel tank gauge unit terminal 4, and
- seat belt buckle switch terminal 14
- through body grounds E22 and E35.

Ground is supplied:

- to brake fluid level switch terminal 2 and
- washer level switch terminal 2
- through body grounds E22 and E38.

AIR BAG WARNING LAMP

During prove out or when an air bag malfunction occurs, the ground path is interrupted

- from the air bag diagnosis sensor unit terminal 15
- to combination meter terminal 28.

Ground is supplied

- through combination meter terminal 31.

With power and ground supplied, the air bag warning lamp (LEDs) illuminate.

For further information, refer to RS section ("TROUBLE DIAGNOSES").

DOOR WARNING LAMP

Door warning lamp is controlled by BCM.

When one of the passenger door is opened, ground is supplied to the BCM terminal 28, 32, 33 or 37.

And then ground is supplied

- to combination meter terminal 15
- from BCM terminal 111

With power and ground supplied, the door warning lamp illuminates.

LOW OIL PRESSURE WARNING LAMP

Low oil pressure causes oil pressure switch terminal 1 to provide ground to combination meter terminal 27.

With power and ground supplied, the low oil pressure warning lamp illuminates.

CHARGE WARNING LAMP

During prove out or when a alternator malfunction occurs, ground is supplied

- to combination meter terminals 25 and 40
- from alternator terminal 3.

With power and ground supplied, the charge warning lamp, brake lamp and tail and stop lamp illuminate.

LOW WASHER LEVEL WARNING LAMP

When the washer fluid level is low, ground is supplied

- to combination meter terminal 45
- from washer fluid level switch terminal 1.

With power and ground supplied, the low washer level warning lamp illuminates.

OD OFF WARNING LAMP

When an A/T system malfunction occurs, or OD control switch is in OFF position, ground is supplied

- to combination meter terminal 24
- from A/T control unit terminal 3.

With power and ground supplied, the OD warning lamp blinks or illuminates.

For further information, refer to AT section ("TROUBLE DIAGNOSES").

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

WARNING LAMPS

Warning Lamps/System Description (Cont'd)

LOW FUEL LEVEL WARNING LAMP

The amount of fuel in the fuel tank is determined by the fuel level sensor in the fuel tank. A signal is sent from fuel tank gauge unit terminal ⑥ to combination meter terminal ④. The fuel level sensor will illuminate the low fuel level warning lamp when the fuel level is low.

With power and ground supplied, the low fuel level warning lamp illuminates.

ABS WARNING LAMP

When an ABS malfunction occurs, ground is supplied

- to combination meter terminal ①
- from ABS/TCS control unit terminal ⑳.

With power and ground supplied, the ABS warning lamp illuminates.

For further information, refer to BR section ("TROUBLE DIAGNOSES").

TCS OFF WARNING LAMP

When TCS off switch is in OFF position, or an ABS/TCS malfunction occurs, ground is supplied

- to combination meter terminal ②
- from ABS/TCS control unit terminal ①①

With power and ground supplied, the TCS off warning lamp illuminates.

For further information, refer to BR section ("TROUBLE DIAGNOSES").

SLIP WARNING LAMP

When TCS is in operation, or a TCS malfunction occurs, ground is supplied

- to combination meter terminal ①①
- from ABS/TCS control unit terminal ①①

With power and ground supplied, the slip warning lamp illuminates.

For further information, refer to BR section ("TROUBLE DIAGNOSES").

SEAT BELT WARNING LAMP

When the driver's seat belt is unfastened, ground is supplied

- to combination meter terminal ⑬
- through air bag diagnoses sensor unit terminal ①⑥ and ②②
- from seat belt buckle switch terminal ④①.

With power and ground supplied, the seat belt warning lamp illuminates.

BRAKE WARNING LAMP

When the parking brake is applied, or the brake fluid level is low, ground is supplied

- to combination meter terminal ⑫
- from parking brake switch terminal ①, or
- brake fluid level switch terminal ①.

With power and ground supplied, the brake warning lamp illuminates.

TAIL AND STOP WARNING LAMP

When one of the stop lamp bulbs is burned out with the stop lamp switch depressed, or one of the tail lamp bulbs is burned out with the lighting switch in the 1ST or 2ND position, ground is supplied.

- to combination meter terminal ④④
- from stop and tail lamp sensor terminal ③

With power and ground is supplied, the tail and stop lamp warning lamp illuminates.

MALFUNCTION INDICATOR LAMP

During prove out or when an engine control malfunction occurs, ground is supplied


- to combination meter terminal ④②
- from ECM terminal ①③.

With power and ground supplied, the malfunction indicator lamp illuminates.

For further information, refer to EC section ["Malfunction Indicator Lamp (MIL)", "ON-BOARD DIAGNOSTIC SYSTEM DESCRIPTION"].

WARNING LAMPS

Schematic








GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX

WARNING LAMPS

Wiring Diagram — WARN —

EL-WARN-01



Refer to last page (Foldout page).

M6, N1



M1

M22

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-02



Refer to last page (Foldout page).

- E66, M12
- M4, B3
- M6, N1
- B9

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

HA








EL

IOX

WARNING LAMPS

Wiring Diagram — WARN — (Cont'd)

EL-WARN-03



* : This connector is not shown in "HARNES LAYOUT", EL section.


Refer to last page (Foldout page).

- (M4), (B3)
- (M6), (N1)
- (M50), (B101)
- (B103)

WARNING LAMPS




Wiring Diagram — WARN — (Cont'd)

EL-WARN-04



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

US : For U.S.A.
CA : For Canada




Refer to last page (Foldout page).

- E66 M12
- M4 B3
- M6 N1
- M49 F63
- F69

EA
EL
IDX

WARNING LAMPS




Trouble Diagnoses


CONSULT

CONSULT inspection procedure


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.
3. Turn ignition switch "ON".
4. Touch "START".




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "DOOR OPEN WARNING".




- DATA MONITOR and ACTIVE TEST are available for door open warning lamp.

WARNING LAMPS

Trouble Diagnoses (Cont'd)

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B).

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


DX

WARNING LAMPS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE

SYMPTOM: Door warning lamp is not operating correctly.



CHECK WARNING LAMP OPERATION.
A **CONSULT**


Perform "DOOR OPEN WARNING" in "Active Test" mode.
 Check warning lamp operation.
Warning lamp should illuminate.

NG → Check the following.

- Bulb
- Power supply circuit for warning lamp
- Harness for open or short between BCM and warning lamp

B

1. Disconnect BCM connector.
 2. Turn ignition switch to "ON" position.
 3. Apply ground to BCM terminal (111).
- Warning lamp should illuminate.**



CHECK DOOR SWITCH INPUT SIGNAL.
C **CONSULT**

See "DOOR SWITCH" in DATA MONITOR mode.


When door is open:
DOOR SW ON
 When door is closed:
DOOR SW OFF

NG → Check the following.

- Door switch
- Door switch ground condition (Front door) or door switch ground circuit (Rear door)
- Harness for open or short between door switch and BCM

ON-BOARD

Check all doors switches in Switch monitor (Mode II) mode.
 (Refer to On-board Diagnosis, EL-236.)



OK →

CHECK IGNITION SWITCH ON SIGNAL.
D **CONSULT**

See "IGN ON SW" in DATA MONITOR mode.


When ignition switch is ON:
IGN ON SW ON
 When ignition switch is ACC or OFF:
IGN ON SW OFF

NG → Check the following.


- 7.5A fuse [No. 32], located in the fuse block (J/B)]
- Harness for open or short between fuse and BCM

ON-BOARD

Check voltage between BCM terminal (68) and ground.



Condition of ignition switch	Voltage [V]
ON	Approx. 12
ACC or OFF	0




OK →

Replace BCM.


Electrical Components Inspection

FUEL WARNING LAMP SENSOR CHECK

- It will take a short time for the bulb to light.



OIL PRESSURE SWITCH CHECK





	Oil pressure kPa (kg/cm ² , psi)	Continuity
Engine start	More than 10 - 20 (0.1 - 0.2, 1 - 3)	NO
Engine stop	Less than 10 - 20 (0.1 - 0.2, 1 - 3)	YES

Check the continuity between the terminals of oil pressure switch and body ground.

DIODE CHECK

- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.


NOTE: Specification may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for the tester to be used.



- Diodes for warning lamps are built into the combination meter printed circuit.

WARNING LAMPS



A/T Indicator/Schematic



WARNING LAMPS

A/T Indicator/Wiring Diagram — AT/IND —

EL-AT/IND-01



Refer to last page (Foldout page).

M4, B3

B1

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL



IDX

Next page

WARNING LAMPS

A/T Indicator/Wiring Diagram — AT/IND — (Cont'd)

EL-AT/IND-02





Refer to last page (Foldout page).

- E66, M12
- M6, N1

WARNING LAMPS

A/T Indicator/Wiring Diagram — AT/IND — (Cont'd)

EL-AT/IND-03



Refer to last page (Foldout page).

- (E66) (M12)
- (E70) (E81)
- (M22)


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
FA

EL

IDX

WARNING CHIME

Component Parts and Harness Connector Location



System Description

FUNCTION

- The following warning chime functions are controlled by BCM.

Item	Details of control
Ignition key warning chime	Sounds warning chime when driver's door is opened with key in ignition key cylinder and ignition switch "OFF" or "ACC" position.
Light warning chime	Sounds warning chime when driver's door is opened with light switch in the 1st or 2nd position or fog lamp switch in ON position and ignition switch "OFF" or "ACC" position.
Seat belt warning chime	Sounds warning chime for about 6 seconds if ignition switch is turned "ON" when driver's seat belt is unfastened

IGNITION KEY WARNING CHIME

Power is supplied at all times

- through 10A fuse [No. 28], located in the fuse block (J/B)
- to key switch terminal ③.
- through 10A fuse [No. 12], located in the fuse block (J/B)
- to warning chime terminal ①.

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. 32], located in the fuse block (J/B)
- to BCM terminal ⑥.

Ground is supplied to BCM terminal ⑩ through driver side door switch terminal ① when driver side switch is in OPEN position.

With the key in the ignition key cylinder, the ignition switch in the ACC or OFF position, and the driver's door open, ground is supplied to warning chime terminal ③ from BCM terminal ⑫. The warning chime will then sound.

LIGHT WARNING CHIME

Power is supplied at all times

- through 10A fuse [No. 12], located in the fuse block (J/B)
- to warning chime terminal ①.
- Through 15A fuse [No. 63], located in the fuse, fusible link and relay box

WARNING CHIME

System Description (Cont'd)

- to tail lamp relay terminals ① and ⑥ .

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. ③②, located in the fuse block (J/B)]
- to BCM terminal ⑥⑧ .

When the lighting switch is in the 1ST or 2ND position, ground is supplied

- to tail lamp relay terminal ②
- from body grounds ②② and ③⑤
- through lighting switch terminals ①① and ⑤ .

Tail lamp relay is then energized, and power is supplied

- to BCM terminal ③
- from tail lamp relay terminal ⑦
- through 7.5A fuse [No. ②②, located in the fuse block (J/B)].

With the lighting switch in the 1ST, 2ND position and the driver's door OPEN, the warning chime will sound in the same manner as ignition key warning chime.

GI

MA

EM

LC

SEAT BELT WARNING CHIME

Power is supplied at all times

- through 10A fuse [No. ①②, located in the fuse block (J/B)]
- to warning chime terminal ① .

With the ignition switch in the ON or START position, power is supplied

- through 7.5A fuse [No. ③②, located in the fuse block (J/B)]
- to BCM terminal ⑥⑧

Ground is supplied to BCM terminal ③④ through seat belt buckle switch terminals ④① and ④④ , when seat belt buckle switch is in UNFASTENED position, and body grounds ②② and ③⑤ .

The warning buzzer sounds for about 6 seconds, when ignition switch is turned from OFF to ON and seat belt is unfastened.

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX

WARNING CHIME




Trouble Diagnoses


CONSULT

CONSULT inspection procedure


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "IGN KEY WARN ALM", "LIGHT WARN ALM" or "SEAT BELT TIMER".




- DATA MONITOR and ACTIVE TEST are available for the warning chime.

WARNING CHIME

Trouble Diagnoses (Cont'd)

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

PS

BT

HA

EL


IDX

WARNING CHIME

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

REFERENCE PAGE	EL-128	EL-129	EL-129	EL-130
SYMPTOM	DIAGNOSTIC PROCEDURE 1 (Lighting switch input signal check)	DIAGNOSTIC PROCEDURE 2 (Key switch input signal check)	DIAGNOSTIC PROCEDURE 3 (Seat belt buckle switch input signal check)	DIAGNOSTIC PROCEDURE 4
Light warning buzzer does not activate.	X			X
Ignition key warning buzzer does not activate.		X		X
Seat belt warning buzzer does not activate.			X	X
All warning buzzers do not activate.				X



DIAGNOSTIC PROCEDURE 1

(Lighting switch input signal check)

CHECK LIGHTING SWITCH INPUT SIGNAL

A  CONSULT

See "HD/LMP 1ST SW" in DATA MONITOR mode.


When lighting switch is in 1ST or 2ND:

HD/LMP 1ST SW ON

When lighting switch is OFF:

HD/LMP 1ST SW OFF

OR

 ON-BOARD

Check lighting switch in Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-236.)

NG

Check the following.

- 7.5A fuse [No. 22], located in the fuse block (J/B)
- Harness for open or short between fuse and BCM.

OK



Go to Procedure 4.

WARNING CHIME

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

(Key switch input signal check)



CHECK KEY SWITCH INPUT SIGNAL

A CONSULT

See "IGN KEY SW" in DATA MONITOR mode.
When key is inserted in ignition key cylinder:

IGN KEY SW ON

When key is removed from ignition key cylinder:

IGN KEY SW OFF

B TESTER

Check voltage between BCM terminal ⑥ and ground.

Condition of key switch	Voltage [V]
Key is inserted	Approx. 12
Key is removed	0

NG


Check the following.

- Key switch
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-131)
- 10A fuse [No. 28], located in the fuse block (J/B)]
- Harness for open or short between key switch and fuse
- Harness for open or short between BCM and key switch.

OK

Go to Procedure 4.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



DIAGNOSTIC PROCEDURE 3

(Seat belt buckle switch input signal check)

CHECK SEAT BELT BUCKLE SWITCH INPUT SIGNAL

A CONSULT

See "SEAT BELT SW" in DATA MONITOR mode.

When driver's seat belt is not fastened:

SEAT BELT SW ON

When driver's seat belt is fastened:

SEAT BELT SW OFF

OR

ON-BOARD

Check seat belt buckle switch in Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-236.)

NG

Check the following.

- Seat belt buckle switch
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-131).
- Seat belt buckle switch ground circuit
- Harness for open or short between BCM and seat belt buckle switch


OK

Go to procedure 4.

WARNING CHIME

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4



CHECK DOOR SWITCH INPUT SIGNAL.
A CONSULT


See "DOOR SW-DR" in DATA MONITOR mode.
 When driver's door is open:
DOOR SW-DR ON
 When driver's door is closed:
DOOR SW-DR OFF OR

ON-BOARD

NG

Check the following.

- Driver door switch
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-131).
- Driver door switch ground condition
- Harness for open or short between driver door switch and BCM



Check driver side door switch in Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-236.)

OK


CHECK IGNITION SWITCH ON SIGNAL.
B CONSULT

See "IGN ON SW" in DATA MONITOR mode.
 When ignition switch is ON:
IGN ON SW ON
 When ignition switch is ACC or OFF:
IGN ON SW OFF OR

NG

Check the following.

- 7.5A fuse [No. 32], located in the fuse block (J/B)
- Harness for open or short between fuse and BCM




TESTER

Check voltage between BCM terminal 68 and ground.

Condition of ignition switch	Voltage [V]
ON	Approx. 12
ACC or OFF	0

OK



Perform "WARN ALM" in ACTIVE TEST mode.
 Check chime operation.
If CONSULT is not available, skip this procedure and go to the next procedure below.

OK


System is OK.

E

CHECK WARNING CHIME.
 1. Disconnect warning chime connector.
 2. Apply 12V direct current to warning chime and check operation.

NG

Replace chime.




Check the following.

- 10A fuse [No. 12] located in the fuse block (J/B)
- Harness for open or short between fuse and chime
- Harness for open or short between chime and BCM.

WARNING CHIME


Trouble Diagnoses (Cont'd) ELECTRICAL COMPONENTS INSPECTION



Key switch (insert)

Check continuity between terminals when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.


Terminal No.	Condition	Continuity
③ - ④	Key is inserted	Yes
	Key is removed	No



Driver side door switch

Check continuity between terminal and switch body ground when door switch is pushed and released.

Terminal No.	Condition	Continuity
① - ground	Door switch is pushed.	No
	Door switch is released.	Yes



Seat belt buckle switch


Check continuity between terminals when seat belt is fastened and unfastened.

Terminal No.	Condition	Continuity
⑭ - ④①	Seat belt is fastened.	No
	Seat belt is unfastened.	Yes

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

WIPER AND WASHER

Component Parts and Harness Connector Location



SEL945U

System Description

WIPER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. 11], located in the fuse block (J/B)]
- to front wiper motor terminal ③.

Ground is supplied to front wiper switch terminals ⑰ and ⑳ through body grounds (E22) and (E36).

Low and high speed wiper operation

When the front wiper switch is placed in the LO position, ground is supplied

- through terminal ⑭ of the front wiper switch
- to front wiper motor terminal ⑤.

With power and ground supplied, the front wiper motor operates at low speed.

When the front wiper switch is placed in the HI position, ground is supplied

- through terminal ⑯ of the front wiper switch
- to front wiper motor terminal ④.

With power and ground supplied, the front wiper motor operates at high speed.

Auto stop operation

When the front wiper switch is placed in the OFF position, the front wiper motor will continue to operate until the wiper arms reach the base of the windshield (Auto stop).

When the front wiper switch is placed in the OFF position, ground is supplied

- from terminal ⑭ of the front wiper switch
- to front wiper motor terminal ⑤, in order to continue front wiper motor operation at low speed.

Ground is also supplied until the wiper arms reaches the base of the windshield

- through terminal ⑬ of the front wiper switch
- to wiper relay terminal ③
- through terminal ④ of the wiper relay
- to front wiper motor terminal ②
- through terminal ① of the front wiper motor, and
- through body grounds (E22) and (E36).

When the wiper arms reach the base of the windshield, the switch in the front wiper motor moves to the "STOP" position. The ground path is interrupted and the front wiper motor stops.

Intermittent operation

Intermittent operation is controlled by the BCM.

WIPER AND WASHER

System Description (Cont'd)

When the front wiper switch is placed in the INT position, ground is supplied .

- to BCM terminal ⑨
- from front wiper switch terminal ⑮
- through body grounds (E22) and (E36) .

The desired interval time is input

- to BCM terminal ④⑨
- from front wiper switch terminal ⑲ and
- to BCM terminal ④⑨
- from combination meter terminal ⑮ (vehicle speed pulse).

Based on these three inputs, an intermittent ground is supplied

- to front wiper relay terminal ②
- from BCM terminal ⑦ .

With power and ground supplied, the front wiper relay is activated.

When activated, an intermittent ground is supplied

- to front wiper motor terminal ⑤
- through the front wiper switch terminal ⑭
- to front wiper switch terminal ⑬
- through front wiper relay terminal ③
- to front wiper relay terminal ⑤
- through body grounds (E22) and (E36) .

Front wiper motor operates at desired interval with BCM terminal ⑨ grounded.

Intermittent operation can be adjusted from:

Approx. 4 - 19 sec.: (when vehicle is stopped)

Approx. 0.4 - 12 sec.: (when vehicle is moving)

Judgement on vehicle stopped or moving:

Stopped → Moving: More than 4 km/h (2 MPH)

Moving → Stopped: Less than 2 km/h (1 MPH)

WASHER OPERATION

With the ignition switch in the ACC or ON position, power is supplied

- through 20A fuse [No. ⑪], located in the fuse block (J/B)]
- to front washer motor terminal ② .

When the lever is pulled to the WASH position, ground is supplied

- to washer motor terminal ① , and
- to BCM terminal ④
- from terminal ⑮ of the front wiper switch
- through terminal ⑰ of the front wiper switch, and
- through body grounds (E22) and (E36) .

With power and ground supplied, the washer motor operates.

The front wiper motor operates at low speed for about 3 seconds. This feature is controlled by the BCM in the same manner as the intermittent operation.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

WIPER AND WASHER

Front Wiper and Washer/Wiring Diagram — WIPER —

EL-WIPER-01



Refer to last page (Foldout page).

- E66, M12
- E70, E81
- M49, F63
- E61
- M1
- M22



EL

IDX

WIPER AND WASHER

Front Wiper and Washer/Wiring Diagram — WIPER — (Cont'd)

EL-WIPER-02






Refer to last page (Foldout page).

- (E66) (M12)
- (E70) (E81)
- (M22)

WIPER AND WASHER

Front Wiper and Washer/Wiring Diagram — WIPER — (Cont'd)

EL-WIPER-03




Refer to last page (Foldout page).

- M4 . B3
- M6 . N1
- M1
- M22

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL

IDX




Trouble Diagnoses


CONSULT

CONSULT inspection procedure


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "WIPER".




- DATA MONITOR and ACTIVE TEST are available for the wiper and washer.

WIPER AND WASHER

Trouble Diagnoses (Cont'd)

WORK FLOW



NOTICE:


- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

WIPER AND WASHER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

SYMPTOM: Intermittent wiper does not operate.



CHECK INTERMITTENT WIPER SWITCH INPUT SIGNAL.

A CONSULT

See "INT SW" in DATA MONITOR mode. When wiper switch is in INT position:

INT SW ON

When wiper switch is in OFF position:

INT SW OFF

OR

ON-BOARD

Check wiper switch (INT) in Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-236.)

Refer to wiring diagram in EL-136.


OK

NG

Check the following.

- Front wiper switch
- Harness for open or short between BCM and wiper switch

Note: When "Data monitor" is operating, intermittent wiper do not operate.



CHECK WIPER AUTO STOP SIGNAL.

B CONSULT

See "WIP AUTO STOP" in DATA MONITOR mode, and turn wiper switch to LO or HI position.

When wiper switch is in INT or OFF:

WIP AUTO STOP ACC

When wiper switch is in LO or HI:

WIP AUTO STOP GND

OR

C TESTER

1. Turn ignition switch to ACC.
2. Turn wiper switch to LO or HI position.
3. Check voltage between BCM connector terminal ③ and ground.

Wiper condition	Voltage [V]
Moving	0
Stop	Approx. 12


Refer to wiring diagram in EL-135.

OK

NG

Check the following.


- Wiper motor
- Wiper ground circuit
- Harness for open or short between BCM and wiper motor



A

WIPER AND WASHER

Trouble Diagnoses (Cont'd)



Ⓐ

CHECK IGNITION SWITCH ACC SIGNAL.

D CONSULT

See "IGN ACC SW" in DATA MONITOR mode.

When ignition switch is ACC or ON
IGN ACC SW ON

When ignition switch is OFF
IGN ACC SW OFF

OR

E TESTER

Check voltage between BCM terminal ⑥ and ground.



Condition of ignition switch	Voltage [V]
ACC or ON	Approx. 12
OFF	0

Refer to wiring diagram in EL-135.

NG

Check the following.

- 7.5A fuse [No. 23], located in the fuse block (J/B)]
- Harness for open or short between fuse and BCM



OK

F CONSULT

CHECK WIPER OPERATION.

See "WIPER AMP" in ACTIVE TEST mode.

Perform operation shown on display.

Wiper motor should operate.

Note:
If CONSULT is not available, skip this procedure and go to procedure 5.

OK

Replace BCM.

NG

Go to procedure 5.


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

WIPER AND WASHER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

SYMPTOM: Intermittent time of wiper cannot be adjusted.



CHECK INTERMITTENT WIPER VOLUME INPUT SIGNAL.

A CONSULT

See "INT RESIST" in DATA MONITOR mode while turning intermittent wiper volume.

Position of wiper knob	Resistance [kΩ]
Short interval	Approx. 0
Long interval	Approx. 1

OR

B TESTER

Measure resistance between BCM terminal 48 and ground while turning intermittent wiper volume.

Position of wiper knob	Resistance [kΩ]
Short interval	Approx. 0
Long interval	Approx. 1

Refer to wiring diagram in EL-136.

NG

Check front wiper switch.


NG

Replace intermittent wiper volume.

OK

Check the following.

- Harness for open or short between BCM and intermittent wiper volume
- Intermittent wiper volume ground circuit




WIPER AND WASHER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

SYMPTOM: Wiper and washer activate individually but not in combination.



CHECK WASHER SWITCH INPUT SIGNAL.

A CONSULT

See "WASH SW" in DATA MONITOR mode.

When washer switch is ON:

WASH SW ON

When washer switch is OFF:

WASH SW OFF

OR



ON-BOARD

Check wiper switch (WASH) in Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-236).

Refer to wiring diagram in EL-136.


NG

Check the following.

- Front wiper switch
- Harness for open or short between BCM and wiper switch

OK

Replace BCM.



DIAGNOSTIC PROCEDURE 4

SYMPTOM: Intermittent wiper operates, but there is no change in intermittent time between when vehicle is stopped and moving.

Does speedometer operate normally?

No

Check speedometer and vehicle speed sensor circuit. Refer to EL-105.

Yes

A

CHECK VEHICLE SPEED SENSOR PULL UP VOLTAGE.

1. Turn ignition switch to ACC.
 2. Check voltage between BCM terminal ④ and ground.
- Approx. 5V should exist.**

Refer to wiring diagram in EL-137.

NG

Replace BCM.

OK

Check harness for open or short between BCM terminal ④ and combination meter terminal ⑩.




G
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX

WIPER AND WASHER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

SYMPTOM: Wiper and washer activate individually but intermittent wiper and washer combination does not operate.



A

CHECK POWER SUPPLY CIRCUIT FOR FRONT WIPER RELAY.

1. Disconnect front wiper relay.
2. Turn wiper switch to OFF or INT position.
3. Turn ignition switch to ACC position.
4. Check voltage between front wiper relay connector terminal ① or ③ and ground.

Battery voltage should exist.

Refer to wiring diagram in EL-135.

NG

Check the following.

- 20A fuse [No. 11], located in the fuse block (J/B)
- Harness for open or short

OK

B

CHECK GROUND CIRCUIT FOR FRONT WIPER RELAY.

Check continuity between front wiper connector terminal ⑤ and ground.

Continuity should exist.

NG

Repair harness.

OK

Check front wiper relay.

NG

Replace relay.

OK

C

CHECK BCM OUTPUT SIGNAL.

1. Connect front wiper relay.
2. Turn ignition switch to ACC.
3. Check voltage between BCM connector terminal ⑦ and ground.


OK

Check harness for open or short between front wiper relay and BCM.

Wiper switch condition	Voltage [V]
Wash	0 (for 0.7 sec.)
OFF	Approx. 12

NG

Replace BCM.



Wiper Installation and Adjustment

1. Prior to wiper arm installation, turn on wiper switch to operate wiper motor and then turn it "OFF" (Auto Stop).
 2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L₁" & "L₂" immediately before tightening nut.
 3. Eject washer fluid. Turn on wiper switch to operate wiper motor and then turn it "OFF".
 4. Ensure that wiper blades stop within clearance "L₁" & "L₂".
Clearance "L₁": 20 - 34 mm (0.79 - 1.34 in)
Clearance "L₂": 23 - 37 mm (0.91 - 1.46 in)
- Tighten wiper arm nuts to specified torque.
Front wiper: 21 - 26 N·m (2.1 - 2.7 kg·m, 15 - 20 ft·lb)

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

FA


EL

IDX


BT

FA

EL




- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.



Washer Nozzle Adjustment

- Adjust washer nozzle with suitable tool as shown in the figure at left.
Adjustable range: ±10°




Unit: mm (in)

*1	240 (9.45)	*8	136 (5.35)
*2	337 (13.27)	*9	8 (0.31)
*3	606 (23.86)	*10	216 (8.50)
*4	422 (16.61)	*11	149 (5.87)
*5	198 (7.80)	*12	540 (21.26)
*6	286 (11.26)	*13	376 (14.80)
*7	436 (17.17)	*14	385 (15.16)

*1: The diameter of a circle is less than 80 mm (3.15 in).


*2 - 7: The radius of the arc across the end of these areas is less than 40 mm (1.57 in).

WIPER AND WASHER



Washer Tube Layout

Wiper Linkage



REMOVAL

1. Remove 4 bolts that secure wiper motor.
2. Detach wiper motor from wiper linkage at ball joint.
3. Remove wiper linkage.

Be careful not to break ball joint rubber boot.



INSTALLATION

- Grease ball joint portion before installation.
1. Installation is the reverse order of removal.

HORN, CIGARETTE LIGHTER AND CLOCK

Wiring Diagram — HORN —

EL-HORN-01




Refer to last page (Foldout page).
 E66 M12
 M6 N1
 M1

* : This connector is not shown in "HARNES LAYOUT", EL section.

GI
 WA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

REAR WINDOW DEFOGGER

Component Parts and Harness Connector Location



System Description

FUNCTION

- The following time control function is controlled by BCM.

Item	Details of control
Rear window defogger timer	Turn off rear window defogger about 15 minutes after the rear window defogger switch is turned "ON".

REAR WINDOW DEFOGGER TIMER

The rear window defogger system is controlled by the BCM.

Power is supplied at all times

- through 15A fuse [No. 38], located in the fuse block (J/B)
- to the rear window defogger relay terminal ⑥, and
- through 15A fuse [No. 39], located in the fuse block (J/B)
- to the rear window defogger relay terminal ③.

With the ignition switch in the ON or START position, power is supplied

- to the rear window defogger relay terminal ① and,
- to BCM terminal ⑥⑥
- through 7.5A fuse [No. 32], located in the fuse block (J/B).

When the rear window defogger switch is ON, ground is supplied

- through terminal ② of the rear window defogger switch (A/C control unit)
- to BCM terminal ⑩.

Terminal ① of the BCM then supplies ground to the rear window defogger relay terminal ②.


With power and ground supplied, the rear window defogger relay is energized to operate rear window defogger for about 15 minutes.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
FA
EL
IDX

REAR WINDOW DEFOGGER


Wiring Diagram — DEF —

EL-DEF-01



Refer to EL-POWER.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA



Refer to last page (Foldout page).

- (M4), (B3)
- (M1)
- (M22)
- (B1)
- (B2)

EL






*: This connector is not shown in "HARNES LAYOUT", EL section.

IDX


REAR WINDOW DEFOGGER

Wiring Diagram — DEF — (Cont'd)

EL-DEF-02




Refer to last page (Foldout page).



REAR WINDOW DEFOGGER

Wiring Diagram — DEF — (Cont'd)

EL-DEF-03



Refer to EL-POWER.

Refer to last page (Foldout page).



- (M4) (B3)
- (M11) (D1)
- (M48) (D21)
- (M1)


CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

HA

EL

IDX

REAR WINDOW DEFOGGER




Trouble Diagnoses


CONSULT

CONSULT inspection procedure


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "REAR DEFOGGER".




- DATA MONITOR and ACTIVE TEST are available for the rear window defogger.

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE

SYMPTOM: Rear window defogger does not activate or does not turn off after activating.



CHECK REAR WINDOW DEFOGGER SWITCH INPUT SIGNAL.

A CONSULT

See "DEFOGGER SW" in DATA MONITOR mode.
When defogger switch is pushed (turned ON):

DEFOGGER SW ON

When defogger switch is pushed again (turned OFF):

DEFOGGER SW OFF

ON-BOARD

Check rear window defogger switch in Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-236.)

NG


Check rear window defogger switch (combined with A/C control unit).

OK

NG

Replace rear window defogger switch.

Check harness for open or short between BCM and rear window defogger switch.



CHECK IGNITION SWITCH ON SIGNAL.

B CONSULT

See "IGN ON SW" in DATA MONITOR mode.

When ignition switch is ON:

IGN ON SW ON

When ignition switch is ACC or OFF:

IGN ON SW OFF

TESTER



Check voltage between BCM terminal ⑥ and ground.

Condition of ignition switch	Voltage [V]
ON	Approx. 12
ACC or OFF	0

NG

Check the following.

- 7.5A fuse [No. 32], located in the fuse block (J/B)
- Harness for open or short between fuse and BCM



CHECK REAR WINDOW DEFOGGER OUTPUT SIGNAL.

1. Disconnect BCM connector.
2. Check voltage between BCM terminal ① and ground.

Condition of ignition switch	Voltage [V]
ON	Approx. 12
OFF	0

NG

Check rear window defogger relay.

OK

NG

Replace relay.

Check the following.



- 7.5A fuse [No. 32], located in the fuse block (J/B)
- Harness for open or short between fuse and rear window defogger relay
- Harness for open or short between rear window defogger relay and BCM

Connect BCM connector.

Ⓐ

REAR WINDOW DEFOGGER

Trouble Diagnoses (Cont'd)



①

REAR WINDOW DEFOGGER ACTIVE TEST.

E **CONSULT**

Perform "RR DEFOGGER RLY" in ACTIVE TEST mode. Check rear defogger relay operation.

OR

F **TESTER**

1. Turn ignition switch to ON.
2. Check voltage between BCM terminal ① and ground.

Condition of rear defogger switch	Voltage [V]
ON	0
OFF	Approx. 12





OK

NG → Replace BCM.

Check rear window defogger circuit.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

REAR WINDOW DEFOGGER



Filament Check

1. Attach probe circuit tester (in volt range) to middle portion of each filament.

• When measuring voltage, wrap tin foil around the top of the negative probe. Then press the foil against the wire with your finger.

2. If a filament is burned out, circuit tester registers 0 or 12 volts.

3. To locate burned out point, move probe along filament. Tester needle will swing abruptly when probe passes the point.

REAR WINDOW DEFOGGER

Filament Repair

REPAIR EQUIPMENT

1. Conductive silver composition (Dupont No. 4817 or equivalent)
2. Ruler 30 cm (11.8 in) long
3. Drawing pen
4. Heat gun
5. Alcohol
6. Cloth

GI

MA

EM

REPAIRING PROCEDURE

1. Wipe broken heat wire and its surrounding area clean with a cloth dampened in alcohol.
2. Apply a small amount of conductive silver composition to tip of drawing pen.

LC

EC

Shake silver composition container before use.

3. Place ruler on glass along broken line. Deposit conductive silver composition on break with drawing pen. Slightly overlap existing heat wire on both sides [preferably 5 mm (0.20 in)] of the break.
4. After repair has been completed, check repaired wire for continuity. This check should be conducted 10 minutes after silver composition is deposited.

FE

AT

Do not touch repaired area while test is being conducted.

PD

FA

RA

BR

ST




RS

BT

HA

EL

IDX



5. Apply a constant stream of hot air directly to the repaired area for approximately 20 minutes with a heat gun. A minimum distance of 3 cm (1.2 in) should be kept between repaired area and hot air outlet. If a heat gun is not available, let the repaired area dry for 24 hours.

Audio/System Description

Refer to Owner's Manual for audio system operating instructions.

Power is supplied at all times

- through 15A fuse (No. 58, located in the fuse, fusible link and relay box)
- to radio terminal 6 .
- to BOSE speaker amp. terminal 27 and
- to audio amp. relay terminal 3 .
- through 10A fuse [No. 12, located in the fuse block (J/B)]
- to CD auto changer terminal 52 .

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 8, located in the fuse block (J/B)]
- to radio terminal 10 and
- to CD auto changer terminal 56 .

Ground is supplied through the case of the radio and CD auto changer terminal 55 .

When the radio is turned to the ON position, power is supplied

- through radio terminal 12
- to BOSE speaker amp. terminal 25 , and
- to audio amp. relay terminal 1 .

The audio amp. relay is energized, power is supplied

- through audio amp. relay terminal 5
- to LH and RH rear speaker terminal 3 .


When the radio is turned to the ON position, audio signals are supplied

- through terminals 13 , 14 , 15 , 16 , 1 , 2 , 3 and 4 of radio
- to terminals 21 , 34 , 23 , 36 , 20 , 33 , 22 and 35 of the BOSE speaker amp.
- through terminals 30 , 31 , 28 , 29 , 37 , 24 , 18 , 17 , 32 , 19 , 41 and 42 of the BOSE speaker amp.
- to tweeters and the front and rear door speakers and rear speakers terminals 1 and 2 .

AUDIO AND POWER ANTENNA

Audio/Schematic

BOSE SYSTEM




- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX

AUDIO AND POWER ANTENNA



Audio/Wiring Diagram — AUDIO —

BOSE SYSTEM

EL-AUDIO-01



Refer to last page (Foldout page).





- (E66), (M12)
- (M6), (N1)
- (M1)

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO — (Cont'd)

BOSE SYSTEM

EL-AUDIO-04



Refer to last page (Foldout page).

- (M4) (B3)
- (M11) (D1)
- (M48) (D21)



GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO — (Cont'd)

BOSE SYSTEM

EL-AUDIO-05



Refer to last page (Foldout page).


- (M4) . (B3)
- (M50) . (B101)

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO — (Cont'd)

BOSE SYSTEM

EL-AUDIO-06



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(B25) W

4	2
3	1

(B28) W

17	18	19	20	21	22	23	24	25	26	27	28	29
30	31	32	33	34	35	36	37	38	39	40	41	42

(B30) GY

1	2	3	4	5	6	7			
8	9	10	11	12	13	14	15	16	

(B111) GY

1	2
---	---

(D47) BR

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL



IDX

AUDIO AND POWER ANTENNA

Audio/Wiring Diagram — AUDIO — (Cont'd)

BOSE SYSTEM

EL-AUDIO-07



Refer to last page (Foldout page).

- (M4), (B3)
- (M6), (N1)
- (M50), (B101)
- (B1)

AUDIO AND POWER ANTENNA

Power Antenna/System Description

Power is supplied at all times

- through 10A fuse [No. 28], located in the fuse block (J/B)
- to power antenna timer and motor terminal ⑥ .

With the ignition switch in the ACC or ON position, power is supplied

- through 10A fuse [No. 8], located in the fuse block (J/B)
- to radio terminal ⑩ .

Ground is supplied to the power antenna timer and motor terminal ② through body grounds B22 and B35 .

When the radio is turned to the ON position, battery positive voltage is supplied

- through radio terminal ⑤
- to power antenna timer and motor terminal ④ .

The antenna raises and is held in the extended position.

When the radio is turned to the OFF position, battery positive voltage is interrupted

- from radio terminal ⑤
- to power antenna timer and motor terminal ④ .

The antenna retracts.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

AUDIO AND POWER ANTENNA

Power Antenna/Wiring Diagram — P/ANT —

EL-P/ANT-01



Refer to last page (Foldout page).

(M4) (B3)
 (M6) (N1)
 (M1)
 (B1)

AUDIO AND POWER ANTENNA

Trouble Diagnoses

RADIO (BOSE SYSTEM)

Symptom	Possible causes	Repair order
Radio inoperative (no digital display and no sound from speakers).	<ol style="list-style-type: none"> 10A fuse Poor radio case ground Radio 	<ol style="list-style-type: none"> Check 10A fuse [No. 8], located in the fuse block (J/B). Turn ignition switch ACC or ON and verify that battery positive voltage is present at terminal ⑩ of radio. Check radio case ground. Remove radio for repair.
Radio controls are operational, but no sound is heard from any speaker.	<ol style="list-style-type: none"> AMP ON signal Audio amp. relay Audio amp. relay ground Poor speaker amp. case ground Speaker amp. output Speaker amp. 	<ol style="list-style-type: none"> Turn ignition switch ACC and radio ON. Verify battery positive voltage is present from radio terminal ⑩ to BOSE speaker amp. terminal ⑤ and audio amp. relay terminal ①. Check audio amp. relay. Check audio amp. relay ground (Terminal ②). Check speaker amp. case ground. Check speaker amp. output voltage. Remove speaker amp. for repair.
Radio presets are lost when ignition switch is turned OFF.	<ol style="list-style-type: none"> 15A fuse Radio 	<ol style="list-style-type: none"> Check 15A fuse [No. 58], located in the fuse, fusible link and relay box] and verify that battery positive voltage is present at terminal ⑥ of radio. Remove radio for repair.
Individual speaker is noisy or inoperative.	<ol style="list-style-type: none"> Speaker Speaker ground Power supply Radio/speaker amp. output Speaker circuit Radio/speaker amp. Speaker 	<ol style="list-style-type: none"> Check speaker. Check speaker ground (Terminal ④ : RR LH, ④ : RR RH). Check power supply for speaker (Terminal ③ : RR LH, ③ : RR RH). Check radio/speaker amp. output voltage. Check wires for open or short between radio, amp. and speaker. Remove radio or speaker amp. for repair. Replace speaker.
AM stations are weak or noisy (FM stations OK).	<ol style="list-style-type: none"> Antenna Poor radio ground Radio 	<ol style="list-style-type: none"> Check antenna. Check radio ground. Remove radio for repair.
FM stations are weak or noisy (AM stations OK).	<ol style="list-style-type: none"> Window antenna Radio 	<ol style="list-style-type: none"> Check window antenna. Remove radio for repair.
Radio generates noise in AM and FM modes with engine running.	<ol style="list-style-type: none"> Poor radio ground Loose or missing ground bonding straps Ignition condenser or rear window defogger noise suppressor condenser Alternator Ignition coil or secondary wiring Radio 	<ol style="list-style-type: none"> Check radio ground. Check ground bonding straps. Replace ignition condenser or rear window defogger noise suppressor condenser. Check alternator. Check ignition coil and secondary wiring. Remove radio for repair.
Radio generates noise in AM and FM modes with accessories on (switch pops and motor noise).	<ol style="list-style-type: none"> Poor radio ground Antenna Accessory ground Faulty accessory 	<ol style="list-style-type: none"> Check radio ground. Check antenna. Check accessory ground. Replace accessory.

POWER ANTENNA

Symptom	Possible causes	Repair order
Power antenna does not operate.	<ol style="list-style-type: none"> 10A fuse Radio signal Grounds (B22) and (B35) Power antenna timer and motor 	<ol style="list-style-type: none"> Check 10A fuse [No. 28], located in the fuse block (J/B). Verify that battery positive voltage is present at terminal ⑥ of power antenna timer and motor. Turn ignition switch to ACC or ON and radio ON. Verify that battery positive voltage is present at terminal ④ of power antenna timer and motor. Check grounds (B22) and (B35). Check power antenna timer and motor.

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

AUDIO AND POWER ANTENNA

Trouble Diagnoses (Cont'd)

CD AUTOCHANGER


Symptom	Possible causes	Repair order
No play of the CD after CD play button is pushed.		
There is no error code shown on the radio.	<ol style="list-style-type: none"> 1. Radio (The radio is not working.) 2. Harness connection (Magazine does not eject.) 3. Changer 	<ol style="list-style-type: none"> 1. Remove the radio for repair. 2. Check harness connection. 3. Remove the changer for repair.
Error code [CD Err] is shown on the radio.	<ol style="list-style-type: none"> 1. Discs 2. Magazine does not eject or a disc remains in CD player. 3. Changer 	<ol style="list-style-type: none"> 1. Inspect discs. (Refer to testing magazines and discs.) 2. Reset the changer. (Disconnect harness connector at the changer and reconnect after 30 sec.) 3. Remove the changer for repair.
CD skipping.	<ol style="list-style-type: none"> 1. Rough road driving 2. Discs 3. Bracket 4. Changer 	<ol style="list-style-type: none"> 1. System is not malfunctioning. 2. Inspect discs. (Refer to testing magazines and discs.) 3. Check and repair bracket and installation of changer. 4. Remove the changer for repair.
Error code [CD no disk] is shown on the radio after CD play button is pressed.	<ol style="list-style-type: none"> 1. Magazine setting 2. Magazine 3. Changer 	<ol style="list-style-type: none"> 1. Confirm the magazine is pushed completely. 2. Inspect magazine. (Refer to testing magazines and discs.) 3. Remove the changer for repair.
Error code [CD HHHH] is shown on the radio after CD play button is pressed.	<ol style="list-style-type: none"> 1. Overheat 2. Reset the Error code 3. Radio or changer 	<ol style="list-style-type: none"> 1. Turn the radio off. Open the trunk lid to lower the trunk room and changer temperature. 2. Reset the radio or changer. (Disconnect harness connector at the radio or changer and reconnect.) 3. Remove the radio or changer for repair.

Testing magazines and discs

1. Confirm discs are installed correctly into the magazine (not upside down).
2. Visually inspect/compare the customer's discs with each other and other discs.
Identify any of the following conditions:
 - Discs with a large outside diameter. [Normal size is 120 mm (4.72 in).]
 - Discs with rough or lipped edges.
 - Discs with excessive thickness [Normal size is 1.2 mm (0.047 in).]
 - Discs with scratches, abrasions, or pits on the surface.
 - Discs with grease/oil, fingerprints, foreign material.
 - Discs are warped due to excessive heat exposure.
3. Slide/place the discs in and out of the various magazine positions.
Identify any discs and/or positions that require additional force for placement/ejection. If interference (sticking, excessive tensions) is found, replace the magazine or the discs.


- Note**
- Discs which are marginally out of specification (ex. dirty, scratched and so on) may play correctly on a home stereo.
However, when used in the automotive environment skipping may occur due to the added vehicle movement and/or vibration due to road conditions. Autochangers should not be replaced when discs are at fault.
 - Use a soft damp cloth to wipe the discs starting from the center outward in radial direction. Never use chemical cleaning solutions to clean the discs.

Location of Antenna



CEL427

GI
MA
EM
LC
EC
FE
AT




CEL428

Antenna Rod Replacement

REMOVAL

1. Remove antenna nut and antenna base.



CEL429

2. Withdraw antenna rod while raising it by operating antenna motor.

PD
FA
RA
BR
ST
RS
BT
FA

EL


IDX

AUDIO AND POWER ANTENNA

Antenna Rod Replacement (Cont'd)

INSTALLATION



1. Lower antenna rod by operating antenna motor.
2. Insert gear section of antenna rope into place with it facing toward antenna motor.
3. As soon as antenna rope is wound on antenna motor, stop antenna motor. Insert antenna rod lower end into antenna motor pipe.
4. Retract antenna rod completely by operating antenna motor.
5. Install antenna nut and base.



Window Antenna Repair


ELEMENT CHECK

1. Attach probe circuit tester (in ohm range) to antenna terminal on each side.
2. If an element is broken, no continuity will exist.



AUDIO AND POWER ANTENNA

Window Antenna Repair (Cont'd)



3. To locate broken point, move probe along element. Tester needle will swing abruptly when probe passes the point.

ELEMENT REPAIR

Refer to REAR WINDOW DEFOGGER "Filament Repair" (EL-159).

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

TELEPHONE




Telephone Pre Wire/Schematic



TELEPHONE

Telephone Pre Wire/Wiring Diagram — PHONE —

EL-PHONE-01



Refer to last page (Foldout page).

- (M4) (B3)
- (M6) (N1)
- (M1)
- (B1)

GF
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL


IDX

TELEPHONE

Telephone Pre Wire/Wiring Diagram

— PHONE — (Cont'd)

EL-PHONE-02



2	23	●	18	1		
28	27	8	11	12	24	6

(B15)
W



9	8	12	24	○	15	22	19
23	11	18	1	6	14	20	2

(B32)
W

TELEPHONE

Telephone Pre Wire/Wiring Diagram — PHONE — (Cont'd)

EL-PHONE-03



Refer to last page (Foldout page).

- E66, M12
- E70, E81
- M4, B3
- M22

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA



EL

IDX


TRUNK LID AND FUEL FILLER LID OPENER

Wiring Diagram — T&FLID —

EL-T&FLID-01




Refer to last page (Foldout page).




ELECTRIC SUNROOF

Wiring Diagram — SROOF —

EL-SROOF-01



Refer to EL-POWER.



Refer to last page (Foldout page).



- E66, M12
- M4, B3
- M1

ELECTRIC SUNROOF

Wiring Diagram — SROOF — (Cont'd)

EL-SROOF-02

Preceding page





* : This connector is not shown in "HARNES LAYOUT", EL section.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

DOOR MIRROR

Wiring Diagram — MIRROR —

EL-MIRROR-01




Refer to last page (Foldout page).

- (M11) (D1)
- (M48) (D21)
- (M1)

INSIDE MIRROR





Auto Anti-dazzling Inside Mirror/Wiring Diagram — I/MIRR —

EL-I/MIRR-01




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

Refer to last page (Foldout page).




EL
IDX

Power Seat/Schematic




Power Seat/Wiring Diagram — SEAT —

EL-SEAT-01



G
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA





Refer to last page (Foldout page).
 E66, M12
 M4, B3
 M50, B101

*: This connector is not shown in "HARNESS LAYOUT", EL section.

POWER SEAT (Passenger Side)

Power Seat/Wiring Diagram — SEAT — (Cont'd)

EL-SEAT-02






* : This connector is not shown in "HARNESS LAYOUT", EL section.

POWER SEAT (Passenger Side)

Power Seat/Wiring Diagram — SEAT — (Cont'd)

EL-SEAT-03






*: This connector is not shown in "HARNESS LAYOUT", EL section.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX

POWER SEAT (Passenger Side)

Power Seat/Wiring Diagram — SEAT — (Cont'd)

EL-SEAT-04





* : This connector is not shown in "HARNESS LAYOUT", EL section.

HEATED SEAT

Heated Seat/Wiring Diagram — HSEAT —

EL-HSEAT-01



* : This connector is not shown in "HARNES LAYOUT", EL section.



Refer to last page (Foldout page).
(B1)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IOX

HEATED SEAT

Heated Seat/Wiring Diagram — HSEAT — (Cont'd)


EL-HSEAT-02



* : This connector is not shown in "HARNESS LAYOUT", EL section.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Component Parts and Harness Connector Location



SEL936U

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

System Description

Refer to Owner's Manual for ASCD operating instructions.

When the ignition switch is in the ON or START position, power is supplied

- through 7.5A fuse [No. 32], located in the fuse block (J/B)]
- to ASCD main switch terminal ① and
- to ASCD hold relay terminal ③ .

When ASCD main switch is in the ON position, power is supplied

- from terminal ② of the ASCD main switch
- to ASCD control unit terminal ④ and
- to park/neutral position relay terminal ④
- from terminal ③ of the ASCD main switch
- to ASCD hold relay terminal ② .

Ground is supplied

- to ASCD hold relay terminal ①
- through body grounds M14 and M47 .

With power and ground supplied, the ASCD hold relay is activated, and power is supplied

- from terminal ⑤ of the ASCD hold relay
- through ASCD main switch terminals ② and ③
- to ASCD hold relay terminal ② .

Power remains supplied to ASCD control unit terminal ④ and park/neutral position relay terminal ④ when the ASCD main switch is released to the N (neutral) position.

Ground is supplied

- to ASCD control unit terminal ③
- through body grounds M14 and M47 .

Inputs

At this point, the system is ready to activate or deactivate, based on inputs from the following:

- speedometer in the combination meter
- stop lamp switch
- ASCD steering switch
- park/neutral position relay
- ASCD brake switch.

A vehicle speed input is supplied

- to ASCD control unit terminal ⑦
- from terminal 16 of the combination meter.

Power is supplied at all times

- through 15A fuse [No. 37], located in the fuse block (J/B)]
- to stop lamp switch terminal ① .

When the brake pedal is depressed, power is supplied

- from terminal ② of the stop lamp switch
- to ASCD control unit terminal 11 .

Power is supplied at all times

- through 15A fuse (No. 64, located in the fuse, fusible link and relay box)
- to horn relay terminal ①
- through terminal ② of the horn relay
- to ASCD steering switch terminal ① .

When the SET/COAST switch is depressed, power is supplied

- from terminal ② of the ASCD steering switch
- to ASCD control unit terminal ② .

When the RESUME/ACCEL switch is depressed, power is supplied

- from terminal ③ of the ASCD steering switch
- to ASCD control unit terminal ① .

When the CANCEL switch is depressed, power is supplied

- to ASCD control unit terminal ① and ② .

When the system is activated, power is supplied

- to ASCD control unit terminal ⑤ .

Power is interrupted when

- the selector lever is placed in P or N or
- the ASCD brake switch is depressed.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

System Description (Cont'd)

Outputs

The ASCD pump controls the throttle drum via the ASCD wire based on inputs from the ASCD control unit. The ASCD pump consists of a vacuum motor, an air valve, and a release valve.

Power is supplied

- from terminal ⑧ of the ASCD control unit
- to ASCD pump terminal ①.

GI

Ground is supplied to the vacuum motor

- from terminal ⑨ of the ASCD control unit
- to ASCD pump terminal ④.

MA

Ground is supplied to the air valve

- from terminal ⑩ of the ASCD control unit
- to ASCD pump terminal ②.

EM

Ground is supplied to the release valve

- from terminal ⑭ of the ASCD control unit
- to ASCD pump terminal ③.

LC

When the system is activated, power is supplied

- from terminal ⑬ of the ASCD control unit
- to combination meter terminal ⑳ and
- to A/T control unit terminal ⑳.

EC

Ground is supplied

- to combination meter terminal ㉑
- through body grounds (M14) and (M47).

FE

With power and ground supplied, the CRUISE indicator illuminates.

AT

When vehicle speed is approximately 8 km/h (5 MPH) below set speed, a signal is sent

- from terminal ⑫ of the ASCD control unit
- to A/T control unit terminal ㉒.

PC

When this occurs, the A/T control unit cancels overdrive.

After vehicle speed is approximately 3 km/h (2 MPH) above set speed, overdrive is reactivated.

FA

RA

BR

ST

RS

BT


HA

EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)



Schematic



AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD —

EL-ASCD-01



Refer to last page (Foldout page).

M6, N1
M1

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-02





Refer to last page (Foldout page).

- (E66) (M12)
- (M4) (B3)
- (B1)
- (B9)

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-03



Refer to last page (Foldout page).

E66 (M12)
M1

* : This connector is not shown in "HARNES LAYOUT", EL section.



CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

FA
EL
EX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-04








Refer to last page (Foldout page).
 E66, M12
 M50, B101
 B103

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Wiring Diagram — ASCD — (Cont'd)

EL-ASCD-05



Refer to last page (Foldout page).

- (M4) (B3)
- (M6) (N1)
- (M1)
- (B9)


GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT

HA

EL

DX


AUTOMATIC SPEED CONTROL DEVICE (ASCD)




Trouble Diagnoses

CONSULT


1. Turn off ignition switch.
2. Connect "CONSULT" to data link connector for CONSULT.




3. Turn on ignition switch.
4. Turn on ASCD main switch.
5. Touch START (on CONSULT display).
6. Touch ASCD.
7. Touch SELF-DIAG RESULTS.



- Self-diagnostic results are shown on display. Refer to table on the next page.



8. Touch DATA MONITOR.



- Touch START.
- Data monitor results are shown on display. Refer to table on the next page.

For further information, read the CONSULT Operation Manual.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

Self-diagnostic results

Diagnostic item	Description	Repair/Check order
* NO SELF DIAGNOSTIC FAILURE INDICATED. FURTHER TESTING MAY BE REQUIRED.**	<ul style="list-style-type: none"> Even if no self diagnostic failure is indicated, further testing may be required as far as the customer complains. 	—
POWER SUPPLY-VALVE	<ul style="list-style-type: none"> The power supply circuit for the ASCD pump is open. (An abnormally high voltage is entered.) 	Diagnostic procedure 7 (EL-212)
VACUUM PUMP	<ul style="list-style-type: none"> The vacuum pump circuit is open or shorted. (An abnormally high or low voltage is entered.) 	Diagnostic procedure 7 (EL-212)
AIR VALVE	<ul style="list-style-type: none"> The air valve circuit is open or shorted. (An abnormally high or low voltage is entered.) 	Diagnostic procedure 7 (EL-212)
RELEASE VALVE	<ul style="list-style-type: none"> The release valve circuit is open or shorted. (An abnormally high or low voltage is entered.) 	Diagnostic procedure 7 (EL-212)
VHCL SP-S/FAILSAFE	<ul style="list-style-type: none"> The vehicle speed sensor or the fail-safe circuit is malfunctioning. 	Diagnostic procedure 6 (EL-211)
CONTROL UNIT	<ul style="list-style-type: none"> The ASCD control unit is malfunctioning. 	Replace ASCD control unit.
BRAKE SW/STOP/L SW	<ul style="list-style-type: none"> The brake switch or stop lamp switch is malfunctioning. 	Diagnostic procedure 4 (EL-209)

Data monitor

Monitored item	Description
BRAKE SW	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the brake switch circuit.
STOP LAMP SW	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the stop lamp switch circuit.
SET SW	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the set switch circuit.
RESUME/ACC SW	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the resume/accelerate switch circuit.
CANCEL SW	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the cancel circuit.
VHCL SPEED SE	<ul style="list-style-type: none"> The present vehicle speed computed from the vehicle speed sensor signal is displayed.
SET VHCL SPD	<ul style="list-style-type: none"> The preset vehicle speed is displayed.
VACUUM PUMP	<ul style="list-style-type: none"> The operation time of the vacuum pump is displayed.
AIR VALVE	<ul style="list-style-type: none"> The operation time of the air valve is displayed.
PW SUP-VALVE	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the circuit for the air valve and the release valve.
CRUISE LAMP	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the cruise lamp circuit.
A/T-OD CANCEL	<ul style="list-style-type: none"> Indicates [ON/OFF] condition of the OD cancel circuit.
FAIL SAFE-LOW	<ul style="list-style-type: none"> The fail-safe (LOW) circuit function is displayed.
FAIL SAFE-SPD	<ul style="list-style-type: none"> The fail-safe (SPEED) circuit function is displayed.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

FAIL-SAFE SYSTEM

When the fail-safe system senses a malfunction, it deactivates ASCD operation. The CRUISE indicator in the combination meter will then flash.




Malfunction detection conditions

Detection conditions	ASCD operation during malfunction detection
<ul style="list-style-type: none"> ● ASCD steering (RESUME/ACCEL, CANCEL, SET/COAST) switch is stuck. ● Vacuum motor ground circuit or power circuit is open or shorted. ● Air valve ground circuit or power circuit is open or shorted. ● Release valve ground circuit or power circuit is open or shorted. ● Vehicle speed sensor is faulty. ● ASCD control unit internal circuit is malfunctioning. 	<ul style="list-style-type: none"> ● ASCD is deactivated. ● Vehicle speed memory is canceled.
<ul style="list-style-type: none"> ● ASCD brake switch or stop lamp switch is faulty. 	<ul style="list-style-type: none"> ● ASCD is deactivated. ● Vehicle speed memory is not canceled.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

Fail-safe system check



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

PROCEDURE	Diagnostic procedure									
REFERENCE PAGE	EL-202	EL-205	EL-207	EL-207	EL-208	EL-209	EL-210	EL-211	EL-212	EL-213
SYMPTOM	Self-diagnosis in CONSULT	Fail-safe system check	DIAGNOSTIC PROCEDURE 1 (POWER SUPPLY AND GROUND CIRCUIT CHECK)	DIAGNOSTIC PROCEDURE 2 (ASCD MAIN SWITCH CHECK)	DIAGNOSTIC PROCEDURE 3 (ASCD HOLD RELAY CHECK)	DIAGNOSTIC PROCEDURE 4 (ASCD BRAKE/STOP LAMP SWITCH CHECK)	DIAGNOSTIC PROCEDURE 5 (ASCD STEERING SWITCH CHECK)	DIAGNOSTIC PROCEDURE 6 (VEHICLE SPEED SENSOR CHECK)	DIAGNOSTIC PROCEDURE 7 (ASCD PUMP CIRCUIT CHECK)	DIAGNOSTIC PROCEDURE 8 (ASCD ACTUATOR/PUMP CHECK)
ASCD cannot be set. ("CRUISE" indicator lamp does not blink.)	X		X	X	X		X	X		
ASCD cannot be set. ("CRUISE" indicator lamp blinks.★1)	X	X				X	X	X	X	
Vehicle speed does not decrease after SET/COAST switch has been pressed.	X						X			X
Vehicle speed does not return to the set speed after RESUME/ACCEL switch has been pressed.★2	X						X			X
Vehicle speed does not increase after RESUME/ACCEL switch has been pressed.	X						X			X
System is not released after CANCEL switch (steering) has been pressed.	X						X			X
Large difference between set speed and actual vehicle speed.	X									X
Deceleration is greatest immediately after ASCD has been set.	X									X

★1: It indicates that system is in fail-safe.



★2: If vehicle speed is greater than 48 km/h (30 MPH) after system has been released, pressing RESUME/ACCEL switch returns vehicle speed to the set speed previously achieved. However, doing so when the ASCD main switch is turned to "OFF", vehicle speed will not return to the set speed since the memory is canceled.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

(POWER SUPPLY AND GROUND CIRCUIT CHECK)



1. Turn ignition switch ON.
2. Turn ASCD main switch "ON" to make sure indicators illuminate.

NG → Go to DIAGNOSTIC PROCEDURE 2 (ASCD MAIN SWITCH CHECK).

A

CHECK POWER SUPPLY CIRCUIT FOR ASCD CONTROL UNIT.

1. Disconnect ASCD control unit connector.
2. Turn ignition switch ON.
3. Turn ASCD main switch "ON".
4. Check voltage between control unit connector terminal ④ and ground.
Battery voltage should exist.

Refer to wiring diagram in EL-198.

NG → Go to DIAGNOSTIC PROCEDURE 3 (ASCD HOLD RELAY CIRCUIT CHECK). Refer to EL-208.

B


CHECK GROUND CIRCUIT FOR ASCD CONTROL UNIT.

Check continuity between ASCD control unit harness terminal ③ and ground.

Refer to wiring diagram in EL-200.

NG → Repair harness.

OK → Go to next procedure.



DIAGNOSTIC PROCEDURE 2 (ASCD MAIN SWITCH CHECK)

A

CHECK POWER SUPPLY FOR ASCD MAIN SWITCH.

1. Disconnect main switch connector.
2. Measure voltage between main switch terminals ① and ④.
Battery voltage should exist.

Refer to wiring diagram in EL-197.

NG → Check the following.

- 7.5A fuse [No. 32], located in the fuse block (J/B)
- Harness for open or short between fuse and ASCD main switch
- Ground circuit for ASCD main switch

Check ASCD main switch. Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-214).

NG → Replace ASCD main switch.

OK → Go to next procedure.


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

(ASCD HOLD RELAY CIRCUIT CHECK)



A

CHECK POWER SUPPLY CIRCUIT FOR ASCD HOLD RELAY.


1. Disconnect ASCD hold relay
2. Do approx. 12 volts exist between ASCD hold relay terminal ③ and ground?

Refer to wiring diagram in EL-197.

No

Check the following.

- 7.5A fuse [No. 32], located in the fuse block (J/B)]
- Harness for open or short between fuse and ASCD hold relay




B

CHECK GROUND CIRCUIT FOR ASCD HOLD RELAY.

Does continuity exist between ASCD hold relay terminal ① and ground?

No

Repair harness.



C

CHECK ASCD HOLD RELAY CIRCUIT.

Does continuity exist between ASCD hold relay terminals ② and ⑤?

Yes

Check ASCD hold relay.

No

CHECK ASCD MAIN SWITCH.

Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-214).

NG

Replace ASCD main switch.

OK





Go to next procedure.

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4

(ASCD BRAKE/STOP LAMP SWITCH CHECK)



A

CHECK BRAKE/STOP LAMP CIRCUIT FOR ASCD CONTROL UNIT.

See "BRAKE SW" in "Data monitor" mode.

When brake pedal is depressed or A/T selector lever is in "N" or "P" range:

BRAKE SW OFF

When both brake pedal is released and A/T selector lever is not in "N" or "P" range:

BRAKE SW ON

OR

1. Disconnect control unit connector.

2. Turn ignition switch ON.

3. Turn ASCD main switch "ON".

4. Check voltage between control unit connector terminal ⑤ and ground.

When brake pedal is depressed or A/T selector lever is in "N" or "P" range:

Approx. 0V

When brake pedal is released and A/T selector lever is not in "N" or "P" range:

Battery voltage should exist.

Refer to wiring diagram in EL-198.

CHECK THE FOLLOWING.

- ASCD brake switch Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-214).
- Inhibitor switch Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-0).
- ASCD hold relay
- Park/neutral position relay
- Diode (B10), (B11) Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-214).
- Harness for open or short

B

CHECK STOP LAMP SWITCH CIRCUIT.

See "STOP LAMP SW" in "Data monitor" mode.

STOP LAMP SW

When brake pedal is released:

OFF

When brake pedal is depressed:

ON

OR

1. Disconnect control unit connector.

2. Check voltage between control unit terminal ⑪ and ground.

Condition		Voltage [V]
Stop lamp switch	Depressed	Approx. 12
	Released	0

Refer to wiring diagram in EL-199.

CHECK THE FOLLOWING.

- 15A fuse [No. 37, located in the fuse block (J/B)]
- Harness for open or short between ASCD control unit and stop lamp switch.
- Stop lamp switch Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-214).

OK

ASCD cancel switch is OK.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

(ASCD STEERING SWITCH CHECK)

A

☆ MONITOR ☆ NO FAIL

SET SW ON

RESUME/ACC ON

CANCEL SW ON

RECORD

SEL293U

A

CHECK ASCD STEERING SWITCH CIRCUIT FOR ASCD CONTROL UNIT.

See "SET SW", "RESUME/ACC SW" and "CANCEL SW" in "Data monitor" mode.


SET SW, RESUME/ACC SW and CANCEL SW

When switch is pressed: ON

When switch is released: OFF

OR


OK → ASCD steering switch is OK.



1. Disconnect control unit connector.
2. Check voltage between control unit terminal and ground.

	Terminal No.		Switch condition	
	⊕	⊖	Pressed	Released
SET/COAST SW	②	ground	12V	0V
RESUME/ACC SW	①	ground	12V	0V
CANCEL SW	②	ground	12V	0V
	①	ground	12V	0V

Refer to wiring diagram in EL-199.



NG

CHECK POWER SUPPLY FOR ASCD STEERING SWITCH.

Does horn work?

- NG → Check the following.
- 15A fuse (No. 64, located in the fuse, fusible link and relay box)
 - Horn relay
 - Harness for open or short between horn relay and fuse

OK

B

CHECK ASCD STEERING SWITCH.

Check continuity between terminals by pushing each switch.

NG → Replace ASCD steering switch.

Switch	Terminal		
	①	②	③
SET/COAST	○ — ○		
RESUME/ACCEL	○		○
CANCEL	○ — ▶ ○		
	○ — ▶ ○		

OK

Check harness for open or short between ASCD steering switch and ASCD control unit.


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

(VEHICLE SPEED SENSOR CHECK)

A



☆ MONITOR ☆ NO FAIL


VHCL SPEED SE 45mph

RECORD


SEL084T

A

CHECK VEHICLE SPEED SENSOR CIRCUIT.

 See "VHCL SPEED SE" in "Data monitor" mode while driving.


OR

 1. Apply wheel chocks and jack up drive wheel.
 2. Disconnect ASCD control unit connector.
 3. Connect voltmeter between ASCD control unit terminal ⑦ and ground.
 4. Slowly turn drive wheel.
 5. Check deflection of voltmeter pointer.

Refer to wiring diagram in EL-201.

OK → Vehicle speed sensor is OK.

GI
MA
EM
LC
EC
FE
AT



NG

Does speedometer operate normally?

No → Check speedometer and vehicle speed sensor circuit. Refer to EL-105.

Yes → Check harness for open or short between ASCD control unit terminal ⑦ and combination meter terminal ⑩.

PD
FA
RA
BR
ST
RS
BT
HA

EL


IDX

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

(ASCD PUMP CIRCUIT CHECK)



A

CHECK ASCD PUMP.

1. Disconnect ASCD pump connector.
2. Measure resistance between control unit harness terminals ① and ②, ③, ④.

Terminals	Resistance [Ω]	
①	④	Approx. 3
	②	Approx. 65
	③	Approx. 65

Refer to wiring diagram in EL-200.

NG → Replace ASCD pump.

OK

Check harness for open or short between ASCD pump and ASCD control unit.



If a self-diagnostic result has already been accomplished, check using the following table.




CONSULT self-diagnostic result	Check circuit	
	ASCD control unit terminal	ASCD pump terminal
POWER SUPPLY-VALVE	⑧	①
VACUUM PUMP	⑨	④
AIR VALVE	⑩	②
RELEASE VALVE	⑪	③

AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

(ASCD ACTUATOR/PUMP CHECK)



A

CHECK VACUUM HOSE.
Check vacuum hose (between ASCD actuator and ASCD pump) for breakage, cracks or fracture.

NG → Repair or replace hose.

OK ↓

CHECK ASCD WIRE.
Check wire for improper installation, rust formation or breaks.

NG → Repair or replace wire. Refer to "ASCD WIRE ADJUSTMENT" (EL-215).

OK ↓

B

CHECK ASCD ACTUATOR.

1. Disconnect vacuum hose from ASCD actuator.
2. Apply -40 kPa (-0.41 kg/cm^2 , -5.8 psi) vacuum to ASCD actuator with hand vacuum pump.

ASCD wire should move to pull throttle drum.

3. Wait 10 seconds and check for decrease in vacuum pressure.

Vacuum pressure decrease:
Less than 2.7 kPa (0.028 kg/cm^2 , 0.39 psi)

NG → Replace ASCD actuator.

OK ↓

C

CHECK ASCD PUMP.

1. Disconnect vacuum hose from ASCD pump and ASCD pump connector.
2. If necessary remove ASCD pump.
3. Connect vacuum gauge to ASCD pump.
4. Apply 12V direct current to ASCD pump and check operation.

NG → Replace ASCD pump.

OK ↓

	12V direct current supply terminals		Operation
	⊕	⊖	
Air valve	①	②	Close
Release valve		③	Close
Vacuum motor		④	Operate

A vacuum pressure of at least -40 kPa (-0.41 kg/cm^2 , -5.8 psi) should be generated.

OK ↓

INSPECTION END

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


AUTOMATIC SPEED CONTROL DEVICE (ASCD)

Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION


ASCD main switch

Check continuity between terminals by pushing switch to each position.



Switch position	Terminals					
	1	2	3	4	5	6
ON	○	○	○	○	ILL.	
N		○	○	○	○	
OFF					○	

ASCD brake switch and stop lamp switch




Condition	Continuity	
	ASCD brake switch	Stop lamp switch
When brake pedal is depressed	No	Yes
When brake pedal is released	Yes	No

Check each switch after adjusting brake pedal — refer to BR section.

Inhibitor switch

Check continuity between terminals by setting selector lever to each position.




Selector lever position	Terminal		
	③	⑦	⑨
"N"	○	○	○
"P"	○	○	
Others			

Diode


- Check continuity using an ohmmeter.
- Diode is functioning properly if test results are as shown in the figure at left.

NOTE: Specifications may vary depending on the type of tester. Before performing this inspection, be sure to refer to the instruction manual for your tester.



Terminals		Continuity
①	②	
		Yes

ASCD Wire Adjustment



CAUTION:

- Be careful not to twist ASCD wire when removing it.
- Do not tense ASCD wire excessively during adjustment.

Adjust the tension of ASCD wire in the following manner.

- (1) Loosen lock nut and adjusting nut.
- (2) Make sure that accelerator wire is properly adjusted. Refer to FE section ("ACCELERATOR CONTROL SYSTEM").
- (3) Tighten adjusting nut just until throttle drum starts to move.
- (4) Loosen adjusting nut again 1/2 to 1 turn.
- (5) Tighten lock nut.

GI

WA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

Overall Description

OUTLINE

The In-Vehicle Multiplexing System, IVMS (LAN system), consists of a BCM (Body Control Module) and five LCUs (Local Control Units). Some switches and electrical loads are connected to each LCU. Some electrical systems are directly connected to the BCM. Control of each LCU, (which is provided by a switch and electrical load), is accomplished by the BCM, via multiplex data lines (A-1, A-2 or A-3) connected between them.

BCM (Body Control Module)

The BCM, which is a master unit of the IVMS (LAN), consists of microprocessor, memory and communication LSI sections and has communication and control functions. It receives data signals from the LCUs and sends electrical load data signals to them.

LCU (Local Control Unit)

The LCUs, which are slave units of the BCM, have only a communication function and consist of communication LSI and input-output interface circuits. They receive data signals from the BCM, control the ON/OFF operations of electrical loads and the sleep operation, as well as send switch signals to the BCM.


CONTROLLED SYSTEMS

The IVMS controls several body-electrical systems. The systems included in the IVMS are as follows:

- Power window
- Power door lock
- Multi-remote control system
- Theft warning system
- Interior illumination control system
- Step lamp
- Illumination (Power window switch illumination)
- Auto drive positioner
- Auto light (Refer to "HEADLAMP".)
- Door open warning (Refer to "WARNING LAMPS".)
- Ignition key warning (Refer to "WARNING CHIME".)
- Light warning (Refer to "WARNING CHIME".)
- Seat belt warning (Refer to "WARNING CHIME".)
- Wiper amp. (Refer to "WIPER AND WASHER".)
- Rear window defogger timer (Refer to "REAR WINDOW DEFOGGER".)
- Trouble-diagnosing system
 - with CONSULT
 - ON-BOARD

Also, IVMS has the "sleep/wake-up control" function. IVMS puts itself (the whole IVMS system) to sleep under certain conditions to prevent unnecessary power consumption. Then, when a certain input is detected, the system wakes itself up. For more detailed information, refer to "Sleep/Wake-up Control".

Component Parts Location




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

System Diagram


● : Output
○ : Input

- | | | |
|---|--|---|
| <ul style="list-style-type: none"> ● Telescopic motor ● Tilt motor ● Seat memory indicator-1 ● Seat memory indicator-2 ● Trunk lid opener actuator ● Ignition key hole illumination ● Door warning lamp ● Rear window defogger relay ● Console lamp ● Map lamp LH ● Map lamp RH ● Footwell lamp ● Rear personal lamp LH ● Rear personal lamp RH ● Front wiper relay ● Headlamp relay ● Tail lamp relay | <ul style="list-style-type: none"> ● Multi-remote control relay ● Security indicator ● Theft warning horn relay ● Theft warning lamp relay ● Warning chime ○ Trunk room lamp switch ○ Hood switch ○ Trunk lid key cylinder switch (Unlock) ○ Seat belt buckle switch (Driver side) ○ Front door key cylinder switch (Driver side)(Unlock) ○ Door key cylinder switch (Passenger side)(Unlock) ○ Illumination time control switch | <ul style="list-style-type: none"> ○ Telescopic switch (Forward) ○ Telescopic switch (Backward) ○ Tilt switch (Up) ○ Tilt switch (Down) ○ ADP cancel switch ○ Tilt sensor ○ Telescopic sensor ○ Seat memory switch-1 ○ Seat memory switch-2 ○ Seat set switch ○ Driver side door switch ○ Passenger side door switch ○ Rear door switch LH ○ Rear door switch RH ○ Ignition switch (START) ○ Ignition switch (ON) ○ Ignition switch (ACC) ○ Key switch (Insert) |
|---|--|---|



Sleep/Wake-up Control


SLEEP CONTROL



“Sleep” control prevents unnecessary power consumption. After the following conditions are met, the BCM suspends the communication between itself and all LCU’s. The whole IVMS is set in the “sleep” mode.

- Ignition switch “OFF”
- All electrical loads (in the IVMS) “OFF”
- Timer “OFF”

WAKE-UP CONTROL



As shown above, when the BCM detects a “wake-up” signal, it wakes up the whole system and starts communicating again. The “sleep” mode of all LCUs is now canceled, and the BCM returns to the normal control mode. When any one of the following switches are turned ON, the “sleep” mode is canceled:

- | | |
|--|--|
| <ul style="list-style-type: none"> ● Ignition key switch (Insert)* ● Ignition switch “ACC” or “ON” ● Lighting switch (1st) ● Door switches (all doors) ● Multi-remote controller ● Trunk room lamp switch ● Hood switch | <ul style="list-style-type: none"> ● Driver’s side door key cylinder switch (Unlock) ● Passenger side door key cylinder switch (Unlock) ● Trunk lid key cylinder switch (Unlock) ● Steering tilt switch ● Steering telescopic switch ● All switches combined or connected with LCU |
|--|--|


* Also, when key is pulled out of ignition (ignition key switch is turned from ON to OFF), the “sleep” mode is canceled.

Fail-safe System

Fail-safe system operates when the signal from LCU is judged to be malfunctioning by BCM. If LCU sends no signal or an abnormal signal to BCM a certain number of times in succession, the IVMS is set in a fail-safe condition. In the fail-safe condition, the electrical loads controlled by the switch on the questionable LCU will be operated at fail-safe side.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX


BCM (Body Control Module)/Schematic



BCM (BODY CONTROL MODULE)

IVMS (LAN) — SYSTEM DESCRIPTION


BCM (Body Control Module)/Schematic (Cont'd)



CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX

Local Control Units (LCUs)/Schematic


DRIVER'S DOOR CONTROL UNIT (LCU01)



IVMS (LAN) — SYSTEM DESCRIPTION

Local Control Units (LCUs)/Schematic (Cont'd)

PASSENGER DOOR CONTROL UNIT (LCU02)




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


IVMS (LAN) — SYSTEM DESCRIPTION

Local Control Units (LCUs)/Schematic (Cont'd)

REAR RH DOOR CONTROL UNIT (LCU03)




REAR LH DOOR CONTROL UNIT (LCU04)




IVMS (LAN) — SYSTEM DESCRIPTION

Local Control Units (LCUs)/Schematic (Cont'd)

DRIVER'S SEAT CONTROL UNIT (LCU05)




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




CONSULT

CONSULT INSPECTION PROCEDURE


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.



3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Perform each diagnostic item according to the item application chart as follows:

For further information, read the CONSULT Operation Manual.

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

CONSULT (Cont'd)

DIAGNOSTIC ITEMS APPLICATION

Test item	Diagnosed system	MODE				
		IVMS COMM DIAGNOSIS	WAKE-UP DIAGNOSIS	SELF-DIAGNOSTIC RESULTS	DATA MONITOR	ACTIVE TEST
IVMS-COMM CHECK	IVMS communication and wake-up function	X	X			
POWER WINDOW	Power window				X	X
DOOR LOCK	Power door lock			X	X	X
MULTI-REMOTE CONT SYS	Multi-remote control				X	X
THEFT WARNING SYSTEM	Theft warning system				X	X
INTERIOR ILLUMINATION	Interior illumination control system				X	X
STEP LAMP	Step lamps				X	X
ILLUM LAMP	Illumination				X	X
AUTO DRIVE POSITIONER	Automatic drive positioner			X	X	X
AUTO LIGHT	Headlamp				X	X
DOOR OPEN WARNING	Warning lamps				X	X
IGN KEY WARN ALM	Warning chime				X	X
LIGHT WARN ALM	Warning chime				X	X
SEAT BELT TIMER	Warning chime				X	X
WIPER	Wiper and washer				X	X
REAR DEFOGGER	Rear window defogger				X	X

X: Applicable

For diagnostic item in each control system, read the CONSULT Operation Manual.






DIAGNOSTIC ITEMS DESCRIPTION

MODE	Description
IVMS COMM DIAGNOSIS	Diagnosis of continuity in the communication line(s), and of the function of the communication interface between the body control module and the local control units, accomplished by transmitting a signal from the body control module to the local control units.
WAKE-UP DIAGNOSIS	Diagnosis of the "wake-up" function of local control units by having a technician input the switch data into the local control unit that is in the temporary "sleep" condition.
SELF-DIAGNOSTIC RESULTS	—
DATA MONITOR	Displays data relative to the body control module (BCM) input signals and various control related data for each system.
ACTIVE TEST	Turns on/off actuators, relay and lamps according to the commands transmitted by the CONSULT unit.

NOTE: When CONSULT diagnosis is operating, some systems under IVMS control do not operate.

CONSULT (Cont'd)











IVMS COMMUNICATION DIAGNOSIS



IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

CONSULT (Cont'd)

WAKE-UP DIAGNOSIS



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

IVMS Communication Diagnoses Results List

Diagnostic item	Number of malfunctioning LCU	CONSULT diagnosis result	On-board diagnosis (Mode 1) code No.	Expected cause	Service procedure
IVMS system is in good order	—	NO FAILURE	11	—	—
Communication malfunctioning	One	POWER WINDOW C/U-DR [COMM FAIL]	24	1. Malfunctioning LCU	1. Replace LCU.*
		POWER WINDOW C/U-AS [COMM FAIL]	34		
		POWER WINDOW C/U-RR [COMM FAIL]	41		
		POWER WINDOW C/U-RL [COMM FAIL]	44		
		POWER SEAT C/U-DR [COMM FAIL]	47		
	Two or more	Combination of POWER WINDOW C/U-DR [COMM FAIL] POWER WINDOW C/U-AS [COMM FAIL] POWER WINDOW C/U-RR [COMM FAIL] POWER WINDOW C/U-RL [COMM FAIL] POWER SEAT C/U-DR [COMM FAIL]	Combination of 24 34 41 44 47	1. Malfunctioning LCU	1. Replace LCU.*
All	BCM [COMM FAIL]	24, 34, 41, 44 and	1. Malfunctioning BCM 2. Malfunctioning all LCUs	1. Replace BCM.* 2. Replace all LCUs.*	
	BCM [COMM FAIL 2]	47			

*: Before replacing BCM/LCU, clear the memory of diagnoses result and perform communication diagnoses again.
If the diagnoses result is still NG, replace BCM/LCU.

NOTE: When CONSULT indicates [PAST COMM FAIL] or [PAST NO RESPONSE], erase the memory and perform communication diagnoses again.

To erase the memory, perform the procedure below.

Erase the memory by CONSULT or turn the ignition to "OFF" position and remove 7.5A fuse [No. 14], located in the fuse block (J/B).

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

IVMS Communication Diagnoses Results List (Cont'd)

Diagnostic item	Number of malfunctioning LCU	CONSULT diagnosis result	On-board diagnosis (Mode 1) code No.	Expected cause	Service procedure (Reference page)
Communication via data line not responded	One	POWER WINDOW C/U-DR [NO RESPONSE]	25	1. Power supply circuit for LCU	1. Check power supply circuit of the LCU in question. (EL-245)
		POWER WINDOW C/U-AS [NO RESPONSE]	35	2. Poor connection at LCU connector.	2. Check connector connection of LCU in question.
		POWER WINDOW C/U-RR [NO RESPONSE]	42	3. Ground circuit of the LCU	3. Check ground circuit of the LCU in question. (EL-244)
POWER WINDOW C/U-RL [NO RESPONSE]		45	4. Open circuit in the data line	4. Check open circuit in the data line between BCM and LCU in question. (EL-246)	
POWER SEAT C/U-DR [NO RESPONSE]		48	5. Malfunctioning LCU	5. Replace LCU.*	
Communication via data line not responded	Two or more	Combination of POWER WINDOW C/U-DR [NO RESPONSE] POWER WINDOW C/U-AS [NO RESPONSE] POWER WINDOW C/U-RR [NO RESPONSE] POWER WINDOW C/U-RL [NO RESPONSE] POWER SEAT C/U-DR [NO RESPONSE]	Combination of 25 35 42 45 48	Combination of causes below 1. Power supply circuit for LCU 2. Poor connection at LCU connector 3. Open circuit in the data line	1. Check power supply circuit of the LCU in question. (EL-245) 2. Check connector connection of LCU in question. 3. Check open circuit in the data line between BCM and LCU in question. (EL-246)
		All	BCM/HARNESS [COMM LINE]	25, 35, 42, 45 and 48	1. Short circuit in the data line
2. Poor connection at BCM connector 3. Open circuit in the data line between BCM and all LCUs. 4. Malfunctioning BCM 5. Short circuit in the data line of LCU internal circuit	2. Check connector connection of BCM. 3. Check open circuit in the data line between BCM and all LCUs. (EL-246) 4. Replace BCM.* 5. Disconnect each LCUs one by one to check whether the other LCUs operate properly.				

*: Before replacing BCM/LCU, clear the memory of diagnoses result and perform communication diagnoses again.
If the diagnoses result is still NG, replace BCM/LCU.

NOTE: When CONSULT indicates [PAST COMM FAIL] or [PAST NO RESPONSE], erase the memory and perform communication diagnoses again.

To erase the memory, perform the procedure below.

Erase the memory by CONSULT or turn the ignition to "OFF" position and remove 7.5A fuse [No. 14], located in the fuse block (J/B).

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

IVMS Communication Diagnoses Results List (Cont'd)

Diagnostic item	Number of malfunctioning LCU	CONSULT diagnosis result	On-board diagnosis (Mode 1) code No.	Expected cause	Service procedure
Sleep control of LCU is malfunctioning	One	POWER WINDOW C/U-DR [SLEEP]	—	1. Malfunctioning LCU	1. Replace LCU.*
		POWER WINDOW C/U-AS [SLEEP]			
	POWER WINDOW C/U-RR [SLEEP]	—	1. Malfunctioning LCU	1. Replace LCU.*	
POWER WINDOW C/U-RL [SLEEP]					
	Two or more	POWER SEAT C/U-DR [SLEEP]			
		Combination of above results	—	1. Malfunctioning LCU	1. Replace LCU.*
		All of above results	—	1. Malfunctioning BCM 2. Malfunctioning all LCUs	1. Replace BCM.* 2. Replace all LCUs.*



*: Before replacing BCM/LCU, clear the memory of diagnoses result and perform communication diagnoses again.

If the diagnoses result is still NG, replace BCM/LCU.

NOTE: When CONSULT indicates [PAST COMM FAIL] or [PAST NO RESPONSE], erase the memory and perform communication diagnoses again.

To erase the memory, perform the procedure below.

Erase the memory by CONSULT or turn the ignition to "OFF" position and remove 7.5A fuse [No. 14], located in the fuse block (J/B).



On-board Diagnosis

ON-BOARD DIAGNOSTIC RESULTS INDICATOR LAMP

Front map lamps and step lamps (all seats) act as the indicators for the on-board diagnosis Mode I, II, III and IV. Seat memory indicator-1 and 2 act as the indicators for the on-board diagnosis Mode V. These lamps blink simultaneously in response to diagnostic results.

GI
 MA
 EM
 LC
 EC
 FE
 AT

ON-BOARD DIAGNOSTIC FUNCTION

Mode	Function		Self-diagnostic results indicator lamp			Reference page
			Interior lamp	Step lamps (all seats)	Automatic drive positioner indicator lamps	
Mode I	IVMS communication diagnosis	Diagnosing any abnormality or inability of communication between BCM and LCUs (DATA LINES A-1, A-2 and A-3).	X	X	—	EL-234
Mode II	Switch monitor	Monitoring conditions of switches connected to BCM and LCUs.	X	X	—	EL-236
Mode III	Power door lock self-diagnosis	—	X	X	—	EL-272
Mode IV	Power window operation	Automatically operating driver side window	X	X	—	EL-254
Mode V	Automatic drive positioner self-diagnosis	—	—	—	X	EL-394


X: Applicable
 —: Not applicable

- NOTE:
- When on-board diagnosis Mode I, II, III or IV is operating, all systems under IVMS control do not operate.
 - When on-board diagnosis Mode V is operating, automatic drive positioner does not operate.
 - The step lamp of malfunctioning LCU does not blink.

PD
 EA
 RA
 BR
 ST
 RS
 BT
 HA

EL

FDX




On-board Diagnosis — Mode I (IVMS communication diagnosis)

HOW TO PERFORM MODE I

Condition

- Ignition switch: OFF
- **Lighting switch: OFF**
- Rear window defogger switch: OFF
- Doors: Closed
- Interior lamp switch: AUTO
- Driver side map lamp switch: OFF
- Passenger side map lamp switch: OFF
- Selector lever: "P" range




*: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

On-board Diagnosis — Mode I (IVMS communication diagnosis) (Cont'd)

DESCRIPTION


In this mode, a malfunction code is indicated by the number of flashes from the front map lamps and step lamps as shown below:



After indicator lamp turns on for 2 seconds then off for 2 seconds, it flashes [cycling ON (0.5 sec.)/OFF (0.5 sec.)] to indicate a malfunction code of the first digit. Then, 1 second after indicator lamp turns off, it again flashes [cycling ON (0.5 sec.)/OFF (0.5 sec.)] to indicate a malfunction code of the second digit. For example, the indicator lamp goes on and off for 0.5 seconds twice and after 1.0 seconds, it goes on and off for 0.5 seconds four times. This indicates malfunction code "24".

Malfunction code table

Code No.	Malfunctioning LCU	Detected items	Diagnostic procedure
24	Driver door control unit (LCU01)	Malfunctioning communication	Refer to Consult DIAGNOSTIC CHART, "COMM FAIL" (EL-230).
25		No response from data line A-1	Refer to Consult DIAGNOSTIC CHART, "NO RESPONSE" (EL-231).
34	Passenger door control unit (LCU02)	Malfunctioning communication	Refer to Consult DIAGNOSTIC CHART, "COMM FAIL" (EL-230).
35		No response from data line A-2	Refer to Consult DIAGNOSTIC CHART, "NO RESPONSE" (EL-231).
41	Rear RH door control unit (LCU03)	Malfunctioning communication	Refer to Consult DIAGNOSTIC CHART, "COMM FAIL" (EL-230).
42		No response from data line A-1	Refer to Consult DIAGNOSTIC CHART, "NO RESPONSE" (EL-231).
44	Rear LH door control unit (LCU04)	Malfunctioning communication	Refer to Consult DIAGNOSTIC CHART, "COMM FAIL" (EL-230).
45		No response from data line A-2	Refer to Consult DIAGNOSTIC CHART, "NO RESPONSE" (EL-231).
47	Driver's seat control unit (LCU05)	Malfunctioning communication	Refer to Consult DIAGNOSTIC CHART, "COMM FAIL" (EL-230).
48		No response from data line A-3	Refer to Consult DIAGNOSTIC CHART, "NO RESPONSE" (EL-231).
11	No malfunction		—




On-board Diagnosis — Mode II (Switch monitor)

HOW TO PERFORM MODE II

Condition

- Ignition switch: OFF
- **Lighting switch: OFF**
- Rear window defogger switch: OFF
- Doors: Closed
- Interior lamp switch: AUTO
- Driver side map lamp switch: OFF
- Passenger side map lamp switch: OFF
- Selector lever: "P" range




IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

On-board Diagnosis — Mode II (Switch monitor) (Cont'd)

DESCRIPTION

In this mode, when BCM detects the input signal from a switch in IVMS as shown below, the detection is indicated by the front map lamp and front step lamps with buzzer.




SEL396SA

Switch monitor item


BCM	<ul style="list-style-type: none"> ● Lighting switch (1st) ● Lighting switch (AUTO) ● Wiper switch (INT) ● Wiper switch (WASH) ● Door switch (driver's side) ● Door switch (passenger side) ● Door switch (Rear LH) ● Door switch (Rear RH) ● Rear window defogger switch ● Detention switch ● Driver's side seat belt buckle switch ● Trunk room lamp switch ● Hood switch ● Trunk lid key cylinder switch (UNLOCK) ● Steering tilt switch (UP/DOWN) ● Steering telescopic switch (FORWARD/BACKWARD) ● Auto drive positioner cancel switch ● Seat memory switch-1 ● Seat memory switch-2 ● Seat set switch ● Multi remote controller switch 	LCU 02	<ul style="list-style-type: none"> ● Door unlock sensor ● Passenger power window sub-switch (UP/DOWN)
		LCU 03	<ul style="list-style-type: none"> ● Door unlock sensor ● Power window sub-switch (Rear RH) (UP/DOWN)
		LCU 04	<ul style="list-style-type: none"> ● Door unlock sensor ● Power window sub-switch (Rear LH) (UP/DOWN)
		LCU 05	<ul style="list-style-type: none"> ● Slide switch (FR/RR) ● Reclining switch (FR/RR) ● Front lifter switch (UP/DOWN) ● Rear lifter switch (UP/DOWN)
			<ul style="list-style-type: none"> ● Power seat switch (Driver's side)
LCU 01	<ul style="list-style-type: none"> ● Power window lock switch ● Power window main switches (UP/DOWN) ● Power window automatic switch ● Door lock & unlock switch (LOCK/UNLOCK) ● Door unlock sensor 		

Main Power Supply, Ground and Communication Circuits/Schematic




Main Power Supply, Ground and Communication Circuits/Wiring Diagram — COMM —

EL-COMM-01





GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX



Refer to last page (Foldout page).
M1
M22

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

Main Power Supply, Ground and Communication Circuits/Wiring Diagram — COMM — (Cont'd)




Refer to last page (Foldout page).

- (E66) (M12)
- (M4) (B3)
- (M11) (D1)
- (M48) (D21)

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

Main Power Supply, Ground and Communication Circuits/Wiring Diagram — COMM — (Cont'd)

EL-COMM-03



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(B25) W (B106) W (D46) W (D66) W

(1 1 1 1 1 1) (B123) GY

Refer to last page (Foldout page).

(M4) (B3)
(M50) (B101)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA



EL

IDX

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

Main Power Supply, Ground and Communication Circuits/Wiring Diagram — COMM — (Cont'd)

EL-COMM-04




*: This connector is not shown in "HARNESS LAYOUT", EL section.

Refer to last page (Foldout page).
M4, B3
M22

IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

Work Flow




NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B).



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Power Supply and Ground Circuit Check

GROUND CIRCUIT CHECK






Control unit	Terminals	Continuity
BCM	⑤⑥ - Ground	Yes
	⑪⑬ - Ground	
LCU01, LCU02, LCU03 and LCU04	⑭ - Ground	
LCU05	⑭ - Ground ⑮ - Ground	



IVMS (LAN) — TROUBLE DIAGNOSES SYSTEM

Power Supply and Ground Circuit Check (Cont'd)

POWER SUPPLY CIRCUIT CHECK



Control unit	Terminals	Ignition switch position			
		OFF	ACC	ON	START
BCM	(104) - Ground	Battery voltage			
	(105) - Ground	Battery voltage			
	(55) - Ground	Approx. 0V	Battery voltage		Approx. 0V
	(68) - Ground	Approx. 0V		Battery voltage	
	(55) - Ground	Approx. 0V			Battery voltage
LCU01, LCU02, LCU03 and LCU04	(15) - Ground	Battery voltage			
LCU05	(16) - Ground	Battery voltage			

Note:
CONSULT (data monitor) may be used to check for the ignition switch input (ACC, ON, START).

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST





RS

BT

HA

EL

IDX



Data Lines Circuit Check

DATA LINES OPEN CIRCUIT CHECK

NOTE: When checking data line circuit, disconnect BCM and all LCU connectors.

1. Disconnect BCM and LCU connectors.
2. Check continuity between BCM and LCU terminals.

Control unit	Terminals		Continuity
	LCU	BCM	
LCU01	③	⑦⑩	Yes
LCU02	③	⑥①	
LCU03	③	⑦⑩	
LCU04	③	⑥①	
LCU05	②②	⑥⑦	

DATA LINES SHORT CIRCUIT CHECK


1. Disconnect BCM and all LCU connectors.
2. Check continuity between BCM terminal and body ground.

Terminals	Continuity
⑥① - Ground	No
⑥⑦ - Ground	
⑦⑩ - Ground	

3. Check voltage between BCM terminal and body ground.

Terminals	Voltage [V]
⑥① - Ground	0
⑥⑦ - Ground	
⑦⑩ - Ground	

Component Parts and Harness Connector Location



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

System Description

OUTLINE

Power window system consists of

- a BCM (Body Control Module)
- four LCUs (Local Control Module)
- four power window regulators

BCM is connected to each LCU via DATA LINE A-1 or A-2 and LCUs supply power and ground to each power window regulator.


When ignition switch is in the "ON" position, power window will be operated depending on power window sub/main switch (which is combined with each LCU) condition.

OPERATIVE CONDITION

- Power windows can be raised or lowered with each sub-switch or the power window main switch located on the driver's door trim when ignition key is in the "ON" position and power window lock switch on the driver's door trim is unlocked.
- When power window lock switch is locked, no windows can be raised or lowered except for driver side window.
- When ignition key is in the "ON" position, to fully open the driver side window, press down completely on the automatic switch (main switch) and release it; it needs not be held. The window will automatically open/close all the way. To stop the window, pull up/press down then release the switch.


EL
DX

Schematic




Wiring Diagram — WINDOW —

EL-WINDOW-01



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA



Refer to last page (Foldout page).

M1
M22


EL

IDX

POWER WINDOW — IVMS

Wiring Diagram — WINDOW — (Cont'd)

EL-WINDOW-04




1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

B25 W, B106 W, D46 W, D66 W

1	1	1	1	1	1
---	---	---	---	---	---

B123 GY, 1 2 B, D43 B, D63 B



Trouble Diagnoses

CONSULT

CONSULT inspection procedure

1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.
3. Turn ignition switch "ON".
4. Touch "START".

GI

MA


EM

LC

EC

FE

AT




5. Touch "IVMS".

PD

FA

RA

BR




6. Touch "POWER WINDOW".

ST

RS

BT


HA



- DATA MONITOR and ACTIVE TEST are available for the power window.

EL

IDX




POWER WINDOW — IVMS

Trouble Diagnoses (Cont'd)

ON-BOARD DIAGNOSIS — MODE IV (DRIVER POWER WINDOW AUTOMATIC OPERATION)

How to perform mode IV



Condition

- Ignition switch: OFF
- **Lighting switch: 1st**
- Rear window defogger switch: OFF
- Front LH window: Closed
- Doors: Closed
- Interior lamp switch: AUTO
- Driver side map lamp switch: OFF
- Passenger side map lamp switch: OFF
- Selector lever: "P" range

Turn ignition switch "ON".

Return ignition switch to "OFF" and press rear window defogger switch more than 10 times during 10 seconds.

Self-diagnostic results indicator lamps should turn on.

Keep rear window defogger switch pressed ON, and turn ignition switch "ON" within 5 seconds after the indicator lamps turn on.

Indicator lamps turn off.

After a second

Mode IV is performed.

Turn ignition switch "OFF".
or
Drive the vehicle more than 7 km/h (4 mile/h).

DIAGNOSIS END* (Be sure to turn off the lighting switch.)

*: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.


POWER WINDOW — IVMS

Trouble Diagnoses (Cont'd)

ON-BOARD DIAGNOSIS — MODE IV (Driver power window automatic operation)

Description

In mode IV, driver window is automatically operated. In conjunction with power window motor (DOWN and UP) "ON", indicator lamps (Front map lamps and front step lamps) turn on. When power window "lock" is detected, power window motor will stop and the indicator lamps will turn off.




NOTE: As soon as manual switches (each seat's power window switch) turn ON, driver power window motor stops and diagnosis ends.

* While power window motor is being operated, electrical ripple occurs.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)

WORK FLOW




NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

POWER WINDOW — IVMS

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK



GI
MA
EM
LC
EC
FE
AT


SYMPTOM CHART

PROCEDURE		Diagnostic procedure					
REFERENCE PAGE		EL-258	EL-258	EL-259	EL-259	EL-260	EL-261
SYMPTOM		Procedure 1 (Ignition switch ON signal check)	Procedure 2 (Power window lock switch check)	Procedure 3 (Power window main switch check)	Procedure 4 (Power window sub-switch check)	Procedure 5 (Power window regulator check)	Procedure 6 (Power window automatic switch check)
1	All power window do not operate.	X					
2	One or more of the power windows do not operate by turning either sub or main switch.					X	
3	One or more of the sub-switches do not function.				X		
4	One or more of the main switches on driver's door trim do not function.			X			
5	Power window lock switch on main switch does not lock and/or unlock all windows.		X				
6	Driver power window automatic operation does not function.						X

PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1 (Ignition switch ON signal check)



CHECK IGNITION SWITCH ON SIGNAL.

A CONSULT

See "IGN ON SW" in DATA MONITOR mode.

When ignition switch is ON:

IGN ON SW ON

When ignition switch is ACC or OFF:

IGN ON SW OFF

OR

B TESTER

Check voltage between BCM terminal ⑥ and ground.


Condition of ignition switch	Voltage [V]
ON	Approx. 12
ACC or OFF	0

Refer to wiring diagram in EL-249.

NG


Check the following.

- 7.5A fuse [No. ③], located in the fuse block (J/B)]
- Harness for open or short between fuse and BCM



OK

Ignition switch ON signal is OK.



DIAGNOSTIC PROCEDURE 2 (Power window lock switch check)

CHECK POWER WINDOW LOCK SWITCH INPUT SIGNAL.

A CONSULT

See "MAIN SW LOCK" in DATA MONITOR mode.

"MAIN SW LOCK" should change from "OFF" to "ON" when pushing power window lock switch.

OR

ON-BOARD

Check power window lock switch operation in Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-236.)

NG

Replace LCU01.

OK

Power window lock switch is OK.

POWER WINDOW — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3


[Power window main switch (Driver side, Passenger side, Rear LH, RH) check]

A ☆ MONITOR □

MAIN SW AS-UP	OFF
MAIN/S AS-DWN	OFF
MAIN SW RR-UP	OFF
MAIN/S RR-DWN	OFF
MAIN SW RL-UP	OFF
MAIN/S RL-DWN	OFF
P/W SW DR-UP	OFF
P/W SW DR-DWN	OFF
P/W SW DR-AUT	OFF

RECORD

SEL440T



CI
MA
EM
LC
EC
FE
AT

A ☆ MONITOR □


P/W SW AS-UP	OFF
P/W SW AS-DWN	OFF
P/W SW RR-UP	OFF
P/W SW RR-DWN	OFF
P/W SW RL-UP	OFF
P/W SW RL-DWN	OFF

RECORD

SEL455T

DIAGNOSTIC PROCEDURE 4

[Power window sub-switch (Passenger side, Rear LH, RH) check]



PD
FA
RA
BR
ST
RS
BT
HA



EL

IDX



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5


(Power window regulator check)




OK → Power window regulator is OK.



NG → Replace LCU for malfunctioning portion.



Refer to wiring diagram in EL-250, 251 or 252.




NG → Replace power window regulator motor.

OK → Check harness for open or short between power window switch, and power window regulator motor.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

(Power window automatic switch check)




CHECK POWER WINDOW AUTO SWITCH INPUT SIGNAL.

A CONSULT

See "P/W SW DR AUT" in DATA MONITOR mode.

"P/W SW DR AUT" should change from "ON" to "OFF" when completely pushing in or pulling out driver power window switch.

NG → Replace LCU01.



OR

ON-BOARD

Check power window switch driver auto operation in switch monitor (Mode II) mode.

(Refer to On-board Diagnosis, EL-236.)

OK ↓

CHECK POWER WINDOW LOCK SIGNAL.

B CONSULT

See "P/W LOCK SIG" in DATA MONITOR mode.

"P/W LOCK SIG" should change from "ON" to "OFF" when the window is moving.

NG → Replace LCU01.

OR

ON-BOARD

Perform On-board diagnosis Mode IV.

(Refer to EL-254.)


Electrical ripple should occur, when the window is moving.

OK ↓

Check the system again.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IX

Component Parts and Harness Connector Location



SEL940U

System Description

POWER SUPPLY AND GROUND

Power is supplied at all times

- through 10A fuse [No. 28], located in the fuse block (J/B)
- to key switch terminal ③.

Power is supplied to BCM terminal 69 through key switch terminal ④ when key switch is in ON position (key is inserted in the ignition key cylinder).

BCM is connected to LCU01, LCU02, LCU03 and LCU04 as DATA LINE A-1 or A-2.

When door switch is in OPEN position, ground is supplied

- to BCM terminal 32 or 37
- through front LH or RH door switch terminal ①.

When door is unlocked, ground is supplied

- to each door LCU terminal 5
- from terminal 2 of each door unlock sensor.

When the door is locked with the key, ground is supplied

- to LCU01 or LCU02 terminal 7
- from terminal 3 of the key cylinder switch LH or
- from terminal 1 of the key cylinder switch RH
- through body grounds M14 and M47.

When the door is unlocked with the key, ground is supplied

- to BCM terminal 31 or 27
- from terminal 1 of the key cylinder switch LH or
- from terminal 3 of the key cylinder switch RH
- through body grounds M14 and M47.

When lock/unlock signal is sent to BCM or LCU, BCM sends a lock/unlock signal to LCUs via DATA LINE A-1 or A-2. LCUs then supply power and ground to each door lock actuator.

OPERATION

- The lock & unlock switch (SW) on driver's door trim can lock and unlock all doors.
- With the lock knob on front LH or RH door set to "LOCK", all doors are locked.
- With the door key inserted in the key cylinder on front LH or RH door, turning it to "LOCK", will lock all doors; turning it to "UNLOCK" once unlocks the corresponding door; turning it to "UNLOCK" again within 5 seconds after the first unlock operation unlocks all of the other doors.

However, if the ignition key is in the ignition key cylinder and one or more of the front doors are open, setting the lock & unlock switch, lock knob, or the door key to "LOCK" locks the doors once but then immediately unlocks them. — (KEY REMINDER DOOR SYSTEM)

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


FA

EL

IDX






POWER DOOR LOCK — IVMS

Schematic



Wiring Diagram — D/LOCK —

EL-D/LOOK-01



Refer to last page (Foldout page).

- (E66) (M12)
- (M4) (B3)
- (M11) (D1)
- (M48) (D21)
- (M50) (B101)
- (E64)
- (M1)
- (M22)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL


IDX

POWER DOOR LOCK — IVMS

Wiring Diagram — D/LOCK — (Cont'd)


EL-D/LOCK-02

DATA LINE



Preceding page

Preceding page







Refer to last page (Foldout page).

- (E66) (M12)
- (M4) (B3)
- (M11) (D1)
- (M50) (B101)


POWER DOOR LOCK — IVMS

Wiring Diagram — D/LOCK — (Cont'd)

EL-D/LOCK-03




Refer to last page (Foldout page).




POWER DOOR LOCK — IVMS

Wiring Diagram — D/LOCK — (Cont'd)


EL-D/LOCK-04




--- : DATA LINE



Refer to last page (Foldout page).





Trouble Diagnoses

CONSULT

CONSULT inspection procedure

1. Turn ignition switch "OFF".
2. Connect "CONSULT" to Data link connector.
3. Turn ignition switch "ON".
4. Touch "START".

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT

HA

EL

IDX




5. Touch "IVMS".

PD

FA

RA

BR



6. Touch "DOOR LOCK".

ST


RS

BT

HA

EL


IDX



- DATA MONITOR, ACTIVE TEST, and SELF-DIAGNOSIS are available for the power door lock.






EL

IDX



POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd) HOW TO PERFORM SELF-DIAGNOSIS



POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

SELF DIAGNOSTIC RESULT LIST

Diagnostic result	Explanation	Diagnostic procedure	Reference page
DOOR LOCK MOTOR-DR	The circuit for the driver side door lock actuator/unlock sensor is malfunctioning.	Procedure 5 (Door unlock sensor check) Procedure 6 (Door lock actuator check)	EL-281 EL-282
DOOR LOCK MOTOR-AS	The circuit for the passenger side door lock actuator/unlock sensor is malfunctioning.		
DOOR LOCK MOTOR-RR/RH	The circuit for the rear RH side door lock actuator/unlock sensor is malfunctioning.		
DOOR LOCK MOTOR-RR/LH	The circuit for the rear LH side door lock actuator/unlock sensor is malfunctioning.		
*NO SELF DIAGNOSTIC FAILURE INDICATED/FURTHER TESTING MAY BE REQUIRED.**	No malfunction in the above items	—	—

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL


IDX

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

ON-BOARD DIAGNOSIS — MODE III (POWER DOOR LOCK OPERATION)

How to perform mode III



Condition

- Ignition switch: OFF
- **Lighting switch: 1st**
- Rear window defogger switch: OFF
- Doors: Closed
- Interior lamp switch: AUTO
- Driver side map lamp switch: OFF
- Passenger side map lamp switch: OFF
- Selector lever: "P" range

Turn ignition switch "ON".

Return ignition switch to "OFF" and press rear window defogger switch more than 10 times during 10 seconds.

Self-diagnostic results indicator lamps should turn on.

Rear window defogger switch holds OFF.

Turn ignition switch "ON" within 5 seconds after the indicator lamps turn on.

Indicator lamps turn off.

After a second

Mode III is performed.

Turn ignition switch "OFF".

DIAGNOSIS END*1 (Be sure to turn off the lighting switch.)


*1: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

Description

In this mode, a malfunction code is indicated by the number of flashes from the front map lamps and step lamps as shown below:



After indicator lamp turns ON for 2 seconds and then turns OFF, it flashes to indicate a malfunction code. For example, the indicator lamp goes on and off for 0.5 seconds three times. This indicates malfunction code "3".

Malfunction code table


Code No.	Detected items	Diagnostic procedure	Reference page
1	Driver door lock actuator/unlock sensor	Procedure 5 (Door unlock sensor check)	EL-281
2	Passenger door lock actuator/unlock sensor		
3	Rear RH door lock actuator/unlock sensor	Procedure 6 (Door lock actuator check)	EL-282
4	Rear LH door lock actuator/unlock sensor		
9	No malfunction in the above items	—	—

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

SYMPTOM CHART

PROCEDURE	Self-diagnosis		Diagnostic procedure						—
REFERENCE PAGE	EL-270	EL-272	EL-276	EL-277	EL-278	EL-279	EL-281	EL-282	EL-229
SYMPTOM	CONSULT	On-board diagnosis (Mode II)	Procedure 1 (Door switch check)	Procedure 2 (Key switch check)	Procedure 3 (Lock & unlock switch check)	Procedure 4 (Door key cylinder switch check)	Procedure 5 (Door unlock sensor check)	Procedure 6 (Door lock actuator check)	Wake-up diagnosis
Key reminder door system does not operate properly.	X	X	X	X			X	X	
Specific door lock actuator does not operate.	X	X					X	X	
Power door lock does not operate with door lock and unlock switch on power window main switch.	X	X			X				X (LCU01)
Power door lock does not operate with front door key cylinder operation.	X	X				X			X (LCU01, LCU02)
Power door lock does not operate with front door lock knob switch.	X	X					X		X (LCU01, LCU02)

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

(Front door switch check)



CHECK FRONT DOOR SWITCH INPUT SIGNAL.

A CONSULT

See "DOOR SWITCH" in DATA MONITOR mode.

When door is open:

DOOR SW ON

When door is closed:

DOOR SW OFF


OR

ON-BOARD

Check front door switches in Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-236.)

Refer to wiring diagram in EL-265.

OK → Door switch is OK.



NG

B

CHECK DOOR SWITCH.

- 1) Disconnect door switch connector.
- 2) Check continuity between terminal and switch body ground.

	Terminals	Condition	Continuity
Front door switch	① - ground	Pressed	No
		Released	Yes

NG → Replace door switch.

OK


- Check the following.
- Door switch ground condition
 - Harness for open or short between door switch and BCM

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2

[Key switch (Insert) check]



CHECK KEY SWITCH INPUT SIGNAL.

A CONSULT

See "IGN KEY SW" in DATA MONITOR mode.

When key is inserted in ignition key cylinder:

IGN KEY SW ON

When key is removed from ignition key cylinder:

IGN KEY SW OFF

OR



B TESTER

Check voltage between BCM terminal ⑥ and ground.

Condition of key switch	Voltage [V]
Key is inserted	Approx. 12
Key is removed	0

Refer to wiring diagram in EL-265.

OK → Ignition key switch is OK.



C CHECK KEY SWITCH.
1) Disconnect key switch connector.
2) Check continuity between key switch (insert) terminals ③ and ④ when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.

Condition	Continuity
Key is inserted	Yes
Key is removed	No

NG → Replace key switch (insert).

OK → Check the following.

- 10A fuse [No. 28], located in fuse block (J/B)
- Harness for open or short between key switch and fuse
- Harness for open or short between BCM and key switch


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
FA
EL
IDX

POWER DOOR LOCK — IVMS


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

(Lock & unlock switch check)



CHECK DOOR LOCK & UNLOCK SWITCH INPUT SIGNAL.

A  CONSULT

See "DOOR LK SW-LK or UN" in DATA MONITOR mode.


When lock & unlock switch is turned to lock:

DOOR LK SW-LK ON

When lock & unlock switch is turned to unlock:

DOOR LK SW-UN ON

OR

 ON-BOARD

Check door lock & unlock switch operation in Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-236.)

OK


Lock & unlock switch is OK.

NG

Replace driver door control unit (LCU01).

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4-(1)
(Door key cylinder lock switch check)




CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (LOCK SIGNAL).

A CONSULT

See "KEY CYL LK" in DATA MONITOR mode.
"KEY CYL LK" should be "ON" when key inserted in door key cylinder was turned to lock.

OK → Door key cylinder switch (lock) is OK.



B TESTER

Check voltage between LCU01/02 terminal ⑦ and ground.

Key position	Voltage [V]
Neutral/Unlock	Approx. 5
Lock	0

Refer to wiring diagram in EL-266 or 267.

NG

C

CHECK DOOR KEY CYLINDER SWITCH.

- 1) Disconnect door key cylinder switch connector.
- 2) Check continuity between door key cylinder switch terminals.


Terminals	Key position	Continuity
LH: ③ - ②	Neutral/Unlock	No
RH: ① - ②	Lock	Yes

NG → Replace door key cylinder switch.

OK

Check the following.

- Door key cylinder switch ground circuit
- Harness for open or short between LCU and door key cylinder switch




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4-(2) (Door key cylinder unlock switch check)




CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (UNLOCK SIGNAL).

A  CONSULT


See "KEY CYL UN" in DATA MONITOR mode.

"KEY CYL UN" should be "ON" when key inserted in door key cylinder was turned to unlock.

OK → Door key cylinder switch (unlock) is OK.



OR

B  TESTER

Check voltage between BCM terminals ② or ③ and ground.

	Terminals		Key position	Voltage [V]
	⊕	⊖		
LH	③	Ground	Neutral/Lock	Approx. 12
			Unlock	0
RH	②	Ground	Neutral/Lock	Approx. 12
			Unlock	0

Refer to wiring diagram in EL-265.

NG

C

CHECK DOOR KEY CYLINDER SWITCH.

- 1) Disconnect door key cylinder switch connector.
- 2) Check continuity between door key cylinder switch terminals.


Terminals	Key position	Continuity
LH: ① - ②	Neutral/Lock	No
RH: ③ - ②	Unlock	Yes

NG → Replace door key cylinder switch.

OK

Check the following.

- Door key cylinder switch ground circuit
- Harness for open or short between BCM and door key cylinder switch



POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

(Door unlock sensor check)

A


☆ MONITOR

LOCK SIG-DR	UNLK
LOCK SIG-AS	LOCK
LOCK SG-RR/RH	UNLK
LOCK SG-RR/LH	UNLK

RECORD

SEL457S

CHECK DOOR UNLOCK SENSOR INPUT SIGNAL.

A  **CONSULT**


See "LOCK SIG SW" in DATA MONITOR mode.

When door is locked:
LOCK SIG LOCK

When door is unlocked:
LOCK SIG UNLK



OR

ON-BOARD



 Check door lock knob operation in Switch monitor (Mode II) mode.
(Refer to On-board Diagnosis, EL-236.)



Refer to wiring diagram in EL-266, 267 or 268.


B

Door lock actuator connectors

Front LH :  Rear LH : 

Front RH :  Rear RH : 



SEL025V

NG

B

CHECK DOOR UNLOCK SENSOR.

- 1) Disconnect door lock actuator connector.
- 2) Check continuity between door lock actuator (door unlock sensor) terminals ② and ④.

Condition	Continuity
Locked	No
Unlocked	Yes

OK

Check the following.

- Harness for open or short between LCU and door unlock sensor
- Ground circuit for door unlock sensor

OK → Door unlock sensor is OK.

NG → Replace door lock actuator.


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

POWER DOOR LOCK — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6

(Door lock actuator check)



CHECK DOOR LOCK MOTOR OPERATION.


A CONSULT

See "DR LOCK MTR" in ACTIVE TEST mode.

Perform operation shown on display. **Door lock motor should operate.**

OR

OK → Door lock actuator is OK.



ON-BOARD

Perform On-board Diagnosis Mode III. (Refer to EL-272.)

Door lock motor should operate.

NG

B


Check voltage between LCU connector terminals ⑰ or ⑱ and body ground.

Door lock operation	Terminals		Voltage
	⊕	⊖	
Lock	⑱	Ground	Battery voltage
Unlock	⑰	Ground	Battery voltage

Refer to wiring diagram in EL-266, 267 or 268.

NG → Replace LCU for malfunctioning portion.

OK



C

CHECK DOOR LOCK ACTUATOR.

1. Disconnect door lock actuator.
2. Apply 12V DC direct current to door lock actuator and check operation.


Door lock operation	Terminals	
	⊕	⊖
Lock	③	①
Unlock	①	③

NG → Replace door lock actuator.

OK

Check harness for open or short between door lock actuator and LCU.

Component Parts and Harness Connector Location



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
ER
ST
RS
BT
HA
EL
DX

System Description

POWER SUPPLY AND GROUND

Power is supplied at all times

- through 10A fuse [No. 13], located in the fuse block (J/B)]
- to multi-remote control relay terminals ①, ③ and ⑥.

Terminal ② of multi-remote control relay is connected to BCM terminal ⑥.

Power is supplied at all times

- through 7.5A fuse [No. 14], located in the fuse block (J/B)]
- to theft warning horn relay terminal ① and theft warning lamp relay terminal ①.

Theft warning horn relay terminal ② and theft warning lamp relay terminal ② are connected to BCM terminal 15.

Power is supplied at all times

- through 20A fuse [No. 26], located in the fuse block (J/B)]
- to trunk lid opener actuator terminal ①.

Trunk lid opener actuator terminal ② is connected to BCM terminal 109 through trunk lid opener cancel switch. BCM is connected to LCU01, LCU02, LCU03 and LCU04 as DATA LINE A-1 or A-2.

Power is supplied at all times

- through 10A fuse [No. 28], located in the fuse block (J/B)]
- to key switch terminal ③.

When the key switch is in ON position (key is inserted in ignition key cylinder), power is supplied

- through key switch terminal ④
- to BCM terminal 69.

When any of the four door switches is in OPEN position, ground is supplied

- to BCM terminal 32 (37, 33, 29)
- through door switches body grounds.

When a door is unlocked, each door LCU terminal ⑤ receives a ground signal from terminal ② of each door unlock sensor.

Remote controller signal input

- through window antenna
- to BCM terminal 89.

The multi-remote control system controls operation of the

- power door lock
- trunk lid opener
- panic alarm
- hazard reminder

OPERATING PROCEDURE

BCM can receive signals from remote controller when key switch is in OFF position (key is not in cylinder). It then sends the signals to LCUs as DATA LINE A-1 or A-2.

Power door lock operation

- Key switch OFF signal (key is not in key cylinder)
- Door switch CLOSE signal (all doors closed)

The two above signals are already input into BCM. At this point, BCM receives a LOCK signal from remote controller. BCM will then send a LOCK signal

- from its terminals 70 and 61 (DATA LINES A-1 and A-2)
- to each door control unit (LCU) terminal ③.

When BCM receives a LOCK signal from remote controller, ground is supplied

- to multi-remote control relay terminal ②
- through BCM terminal ⑥.

Multi-remote control relay is now energized and door lock actuators lock all doors. (Hazard warning lamps flash twice as a reminder — **HAZARD REMINDER.**)

When an UNLOCK signal is sent from remote controller once, driver's door will be unlocked.

Then, if an UNLOCK signal is sent from remote controller again within 3 seconds, all other doors will be unlocked. For detailed description, refer to "POWER DOOR LOCK — IVMS" (EL-263).

System Description (Cont'd)

Trunk lid opener operation

When a TRUNK OPEN signal is sent from remote controller, if the trunk lid opener cancel switch is in the ON position, ground is supplied

- to trunk lid opener actuator terminal ②
- through trunk lid cancel switch terminals ① and ② , and
- through BCM terminal ⑩.

Then power and ground are supplied, trunk lid opener actuator opens trunk lid.

Panic alarm operation

Multi-remote control system activates horn and headlamps intermittently when an ALARM signal is sent from remote controller to multi-remote control system.

For detailed description, refer to "THEFT WARNING SYSTEM — IVMS" (EL-347).

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

HA

EL

IDX



Schematic



MULTI-REMOTE CONTROL SYSTEM — IVMS

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-02








*: This connector is not shown in "HARNES LAYOUT", EL section.

Refer to last page (Foldout page).
 (E66) (M12)
 (M4) (B3)
 (M50) (B101)
 (E64)
 (M1)
 (M22)
 (B2)


MULTI-REMOTE CONTROL SYSTEM — IVMS

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-03



Refer to last page (Foldout page).





GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 DX

MULTI-REMOTE CONTROL SYSTEM — IVMS

Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-04




Refer to last page (Foldout page).

- (E66) · (M12)
- (M4) · (B3)
- (M11) · (D1)
- (M50) · (B101)




MULTI-REMOTE CONTROL SYSTEM — IVMS

Wiring Diagram — MULTI — (Cont'd)


EL-MULTI-05



--- : DATA LINE



Refer to last page (Foldout page).



CI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA



EL

IDX

MULTI-REMOTE CONTROL SYSTEM — IVMS


Wiring Diagram — MULTI — (Cont'd)

EL-MULTI-06



Refer to last page (Foldout page).

- M4, B3
- M50, B101



Trouble Diagnoses

CONSULT

CONSULT inspection procedure

1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.
3. Turn ignition switch "ON".
4. Touch "START".

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST


RS

BT


HA

EL


IDX




5. Touch "IVMS".



6. Touch "MULTI-REMOTE CONT SYS".




- DATA MONITOR and ACTIVE TEST are available for the multi-remote control system.



Trouble Diagnoses (Cont'd)

WORK FLOW




NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

Trouble Diagnoses (Cont'd)


TROUBLE SYMPTOM

- All functions of remote control system do not function.



GI
MA
EM
LC
EC
FE
AT
PD

- Multi-remote controller does not operate a part of the functions.




FA
RA
BR
ST
RS
BT
HA
EL
IDX

Note: • The unlock and trunk open operation of multi-remote control system does not activate with the ignition key inserted in the ignition key cylinder.
• The lock operation of multi-remote control system does not activate with the key inserted in the ignition key cylinder or if one of the doors is opened.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1




A

CHECK REMOTE CONTROLLER BATTERY.
Remove battery and measure voltage across battery positive and negative terminals, ⊕ and ⊖.

Measuring terminal		Standard value
⊕	⊖	
Battery positive terminal ⊕	Battery negative terminal ⊖	2.5 - 3.0V

Note:
Remote controller does not function if battery is not set correctly.




DIAGNOSTIC PROCEDURE 2

A

CHECK ANTENNA FEEDER CABLE.

- 1) Disconnect feeder cable connector from BCM.
- 2) Remove rear pillar garnish and disconnect feeder cable connector from rear window glass antenna. (Feeder cable connector is the one at bottom left.)
- 3) Check continuity between the feeder cable connectors.
Continuity should exist.
- 4) Check continuity between the feeder cable connector terminal and ground.
Continuity should exist.

NG → Replace feeder cable.




B

CHECK REAR WINDOW GLASS ANTENNA.

- 1) Remove rear pillar garnish and disconnect feeder cable connector from rear window glass antenna.
- 2) Check continuity between glass antenna terminal and end of glass antenna.
Continuity should exist.

Note: When checking continuity, wrap tin foil around top of the probe. Then press the foil against the wire with your finger.

NG → Repair glass window antenna. Refer to REAR WINDOW DEFOGGER "Filament Repair".



OK → Antenna of multi-remote control is OK.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

A

☆ MONITOR		<input type="checkbox"/>
DOOR SW-DR	OFF	
DOOR SW-AS	OFF	
DOOR SW-RL	OFF	
DOOR SW-RR	OFF	

RECORD

SEL575U

CHECK DOOR SWITCH INPUT SIGNAL.

A CONSULT

See "DOOR SWITCH" in DATA MONITOR mode.

When door is open:
DOOR SW ON

When door is closed:
DOOR SW OFF

OR

Check the following.

- Door switch
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-302).
- Door switch ground condition (Front door) or door switch ground circuit (Rear door)
- Harness for open or short between BCM and door switch

B

☆ MONITOR		<input type="checkbox"/>
LOCK SIG-DR	UNLK	
LOCK SIG-AS	LOCK	
LOCK SG-RR/RH	UNLK	
LOCK SG-RR/LH	UNLK	

RECORD

SEL457S

ON-BOARD

Check all doors switches in Switch monitor (Mode II) mode.
(Refer to On-board Diagnosis, EL-236.)

Refer to wiring diagram in EL-289.

CHECK DOOR UNLOCK SENSOR INPUT SIGNAL.

B CONSULT

See "LOCK SIG SW" in DATA MONITOR mode.

When door is locked:
LOCK SIG LOCK

When door is unlocked:
LOCK SIG UNLK

OR

Check the following.

- Door unlock sensor
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-302)
- Door unlock sensor ground circuit
- Harness for open or short between LCU and unlock sensor

C

☆ MONITOR		<input type="checkbox"/>
IGN ACC SW	ON	


RECORD

SEL919U

ON-BOARD

Check door lock knob operation in Switch monitor (Mode II) mode.
(Refer to On-board Diagnosis, EL-236.)

Refer to wiring diagram in EL-290, 291 or 292.



CHECK IGNITION SWITCH "ACC" CIRCUIT.

C CONSULT

See "IGN ACC SW" in DATA MONITOR mode.

When ignition switch is ACC or ON:
IGN ACC SW ON

When ignition switch is OFF:
IGN ACC SW OFF

OR

Check the following.

- 7.5A fuse [No. 23], located in fuse block (J/B)]
- Harness for open or short between BCM and fuse

D TESTER

Check voltage between BCM terminal ⑥ and ground.

Condition of ignition switch	Voltage [V]
ACC or ON	Approx. 12
OFF	0

Refer to wiring diagram in EL-287.



Ⓐ

CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL

IDX

Trouble Diagnoses (Cont'd)



Ⓐ

↓

CHECK KEY SWITCH INPUT SIGNAL.

E **CONSULT**

See "IGN KEY SW" in DATA MONITOR mode.

When key is inserted in ignition key cylinder:

IGN KEY SW ON

When key is removed from ignition key cylinder:

IGN KEY SW OFF

OR

F **TESTER**

Check voltage between BCM terminals Ⓒ and ground.

Condition	Voltage [V]
Key is inserted	Approx. 12
Key is removed	0

Refer to wiring diagram in EL-288.

NG →

Check the following.

- 10A fuse [No. 28], located in fuse block (J/B)]
- Key switch
Refer to "ELECTRICAL COMPONENTS INSPECTION" (EL-302).
- Harness for open or short between key switch and fuse
- Harness for open or short between BCM and key switch


OK

↓

Check operation parts in multi-remote control system for function.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4



CHECK HAZARD INDICATOR OPERATION.

Yes → Hazard indicator is OK.

A CONSULT

See "HAZARD" in ACTIVE TEST mode. Perform operation shown on display. **Hazard warning lamp should illuminate.**

OR

B

1. Disconnect control unit connector.
 2. Apply ground to BCM terminal ⑥.
- Does hazard indicator illuminate?**


Refer to wiring diagram in EL-288.

No

Check multi-remote control relay.

NG → Replace.

OK



C

CHECK POWER SUPPLY FOR MULTI-REMOTE CONTROL RELAY.

NG → Check the following.
• 10A fuse [No. 13], located in fuse block (J/B)
• Harness for open or short between multi-remote control relay and fuse

1. Disconnect multi-remote control relay connector.
 2. Check voltage between terminal ① and ground.
- Battery voltage should exist.**

OK

D



CHECK MULTI-REMOTE CONTROL RELAY CIRCUIT.

NG → Check harness for open or short.

1. Disconnect multi-remote control relay connector.
 2. Check voltage between terminals ③ and ⑤.
 3. Check voltage between terminals ⑥ and ⑦.
- Battery voltage should exist.**

OK


Check harness for open or short between BCM and multi-remote control relay.



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5




CHECK MULTI-REMOTE CONTROLLER OPERATION.

A CONSULT

See "TRUNK BTN-CON" in DATA MONITOR mode.

"TRUNK BTN-CON" should be "ON" when trunk lid opener button on multi-remote controller is continuously pressed for more than 1 second.

NG → Replace multi-remote controller.



OR
B ON-BOARD

Check trunk open signal from multi-remote controller in Switch monitor (Mode II) mode.
(Refer to On-board Diagnosis, EL-236).

OK ↓


CHECK TRUNK LID OPENER CIRCUIT.

B CONSULT

See "TRUNK OPEN S/V" in ACTIVE TEST mode.

Perform operation shown on display.
Trunk lid opener should operate.

OK → Trunk opener operation is OK.



OR
C TESTER


Check voltage between BCM connector terminal (109) and ground.
Battery voltage should exist.

Refer to wiring diagram in EL-288.

NG ↓

Check harness for open or short between BCM and trunk lid opener cancel switch.

Trouble Diagnoses (Cont'd)
DIAGNOSTIC PROCEDURE 6



A

CHECK TRUNK LID OPENER ACTUATOR.

1. Disconnect trunk lid opener actuator connector.
2. Check to see if trunk lid opens when 12V DC is applied across trunk lid opener actuator connector terminals ① and ②.

Refer to wiring diagram in EL-288.

NG → Replace trunk lid opener actuator.

OK ↓

Check the following.

- 7.5A fuse [No. 26], located in fuse block (J/B)
- Trunk lid opener cancel switch
- Harness for open or short between fuse and trunk lid opener actuator
- Harness for open or short between trunk lid opener actuator and cancel switch
- Harness for open or short between trunk lid opener cancel switch and BCM

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX




Trouble Diagnoses (Cont'd)

ELECTRICAL COMPONENTS INSPECTION

Door switches

Check continuity between terminals and switch body ground when door switch is pushed and released.


	Terminal No.	Condition	Continuity
Front door switch	① - ground	Door switch is pushed.	No
		Door switch is released.	Yes
Rear door switches	① - ②	Door switch is pushed.	No
		Door switch is released.	Yes



Door lock actuator (Door unlock sensor)

Check continuity between terminals when door is locked and unlocked.

Terminal No.	Condition	Continuity
④ - ②	Door is locked.	No
	Door is unlocked.	Yes



Key switch (insert)

Check continuity between terminals when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.

Terminal No.	Condition	Continuity
③ - ④	Key is inserted.	Yes
	Key is removed.	No

Replacing Remote Controller or BCM


Enter the identity (ID) code manually when:

- remote controller or BCM is replaced.
- an additional remote controller is activated.

ID Code Entry Procedure

To enter the ID code, follow the procedures below.

PROCEDURE 1 (Without CONSULT)



NOTE

- If you need to activate more than two additional new remote controllers, repeat the procedure "Additional ID code entry" for each new remote controller.
- If the same ID code that exists in the memory is input, the entry will be ignored.
- Entry of maximum four ID codes is allowed and any attempt to enter more will be ignored.


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL


IDX

MULTI-REMOTE CONTROL SYSTEM — IVMS


Replacing Remote Controller or BCM (Cont'd) PROCEDURE 2 (With CONSULT)




1. Turn ignition switch "OFF".
2. Connect "CONSULT" to Data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "REMOTE CONT ID REG".





7. Touch "START".
- **At this time, the original ID codes are eliminated. (Then power door lock will lock, unlock, and the hazard warning lamp will flash twice.)**

MULTI-REMOTE CONTROL SYSTEM — IVMS

Replacing Remote Controller or BCM (Cont'd)

8. Push lock button on the new remote controller once.



- At this time, the new ID code is entered. (Then power door lock will lock, unlock, and the hazard warning lamp will flash twice.)

Additional ID code entry

9. Push lock button on the additional remote controller once.
- Maximum of four ID are able to be entered. Any attempt to enter more will be ignored.
10. Touch "END".
- After entering the identity (ID) code, check the operation of multi-remote control system.

NOTE

- If you need to activate more than two additional new remote controllers, repeat the procedure "Additional ID code entry" for each new remote controller.
- If the same ID code that exists in the memory is input, the entry will be ignored.
- Entry of maximum four ID codes is allowed and any attempt to enter more will be ignored.

GT

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX

System Description

OUTLINE

Interior illumination system turns interior illumination lamps on and off while operating the timer. The system operates by means of key switch, lighting switch, each door switch, driver side door unlock sensor, and switches of each lamp. This system is controlled by BCM.



TIMER OPERATION

The timer controls the lighting time of the interior illumination lamps via operation of the driver side door switch, key switch, driver side unlock sensor, and ignition key switch.

Switch	Operation
Driver side door unlock sensor	With driver side door closed and key removed from ignition key cylinder, the timer operates when driver side door unlock signal is received. The timer cancels itself when driver side door lock signal is received.
Driver side door switch	The timer operates when driver side door is opened and then closed.
Ignition key switch	The timer cancels itself when ignition key is in ACC or ON position while it is operating.
Key switch (Insert)	With driver side door closed, when key is removed from ignition key cylinder, the timer operates.

- For details of turning on/off function of each of the lamps, see the following charts.


BATTERY SAVER

When the main illumination switch and personal lamp switch are in AUTO position with ignition key in OFF or ACC position, if interior illumination lamps are turned on by door switch open signal and remain lit for more than 30 minutes, the lamps turn off automatically.

INTERIOR ILLUMINATION CONTROL — IVMS

System Description (Cont'd)

TURN ON/OFF MODE OF DRIVER SIDE DOOR OPEN/CLOSE



Note: Illumination lamp lighting is available in both 100% and 35% luminosity modes.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA


EL

IDX


INTERIOR ILLUMINATION CONTROL — IVMS

System Description (Cont'd)

TURN ON/OFF MODE OF PASSENGER SIDE DOOR OPEN/CLOSE



TURN ON/OFF MODE OF REAR DOOR OPEN/CLOSE




Note: Illumination lamp lighting is available in both 100% and 35% luminosity modes.

INTERIOR ILLUMINATION CONTROL — IVMS

System Description (Cont'd)


TURN ON/OFF MODE OF EACH SWITCH CONDITION



Note: Illumination lamp lighting is available in both 100% and 35% luminosity modes.


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Schematic



INTERIOR ILLUMINATION CONTROL — IVMS


Wiring Diagram — ROOM/L —



EL-ROOM/L-01

Refer to EL-POWER.

- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA



Refer to last page (Foldout page).
 (E70), (E81)
 (M1)
 (M22)



EL

 IDX

INTERIOR ILLUMINATION CONTROL — IVMS

Wiring Diagram — ROOM/L — (Cont'd)

EL-ROOM/L-02





Refer to last page (Foldout page).

- (E66) (M12)
- (E64)
- (M1)
- (M22)


INTERIOR ILLUMINATION CONTROL — IVMS

Wiring Diagram — ROOM/L — (Cont'd)


EL-ROOM/L-03



(M15)
W



(M61)
GY



(R5)
W

Refer to last page (Foldout page).

(M1)

(M22)

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

FA


EL

DX

INTERIOR ILLUMINATION CONTROL — IVMS

Wiring Diagram — ROOM/L — (Cont'd)

EL-ROOM/L-04



1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18		

(M15)
W

1	1	1	1	1	1
---	---	---	---	---	---

(M61)
GY

	○	1	
5	4	3	2

(R7)
W

(R8)
W


Refer to last page (Foldout page).

(M22)


INTERIOR ILLUMINATION CONTROL — IVMS

Wiring Diagram — ROOM/L — (Cont'd)


EL-ROOM/L-05



GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX





Refer to last page (Foldout page).



INTERIOR ILLUMINATION CONTROL — IVMS

Wiring Diagram — ROOM/L — (Cont'd)

EL-ROOM/L-06





Refer to last page (Foldout page).
 M4, B3
 M50, B101
 M22

INTERIOR ILLUMINATION CONTROL — IVMS

Wiring Diagram — ROOM/L — (Cont'd)


EL-ROOM/L-07



Refer to last page (Foldout page).

- (E66), (M12)
- (M4), (B3)
- (M11), (D1)

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
EL
 IDX




Trouble Diagnoses


CONSULT

CONSULT inspection procedure


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.
3. Turn ignition switch "ON".
4. Touch "START".




5. Touch "IVMS".



6. Touch "INTERIOR ILLUMINATION".




- DATA MONITOR and ACTIVE TEST are available for the interior illumination.



INTERIOR ILLUMINATION CONTROL — IVMS

Trouble Diagnoses (Cont'd)

WORK FLOW



GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX


NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

INTERIOR ILLUMINATION CONTROL — IVMS



Trouble Diagnoses (Cont'd)

WORK FLOW



Trouble Diagnoses (Cont'd)

DOOR UNLOCK SENSOR CHECK (DRIVER SIDE)



CHECK DOOR UNLOCK SENSOR INPUT SIGNAL. (DRIVER SIDE)

A **CONSULT**

See "LOCK SIG SW" in DATA MONITOR mode.
"LOCK SIG SW" should be "LOCK" when lock knob was locked.

OR

ON-BOARD

Check driver's side door lock knob operation in Switch monitor (Mode II) mode. (Refer to On-board Diagnoses, EL-236.)

Refer to wiring diagram in EL-317.

OK → Door unlock sensor is OK.

B

CHECK DOOR UNLOCK SENSOR.

- 1) Disconnect door lock actuator connector.
- 2) Check continuity between door lock actuator (door unlock sensor) terminals ② and ④.

Condition	Continuity
Locked	No
Unlocked	Yes

NG → Replace door lock actuator.


OK

Check the following.

- Harness for open or short between LCU and door unlock sensor
- Ground circuit for door unlock sensor

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

Trouble Diagnoses (Cont'd) DOOR SWITCH CHECK



CHECK DOOR SWITCH INPUT SIGNAL.

A **CONSULT**

See "DOOR SWITCH" in DATA MONITOR mode.

When door is open:

DOOR SW ON


When door is closed:

DOOR SW OFF

OR

OK

Door switch is OK.




ON-BOARD

Check all doors switches in Switch monitor (Mode II) mode.

(Refer to On-board Diagnosis, EL-236.)

Refer to wiring diagram in EL-316.


NG



NG

Replace door switch.



OK



Check the following.


- Door switch ground condition (Front door) or door switch ground circuit (Rear door)
- Harness for open or short between door switch and BCM

Trouble Diagnoses (Cont'd)
LIGHTING SWITCH (1ST) CHECK



CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
DX

Trouble Diagnoses (Cont'd) KEY SWITCH (INSERT) CHECK



CHECK KEY SWITCH INPUT SIGNAL.

A **CONSULT**

See "IGN KEY SW" in DATA MONITOR mode.


When key is inserted in ignition key cylinder:

IGN KEY SW ON

When key is removed from ignition key cylinder:

IGN KEY SW OFF

OK → Key switch is OK.




B **TESTER**

Check voltage between BCM terminals ⑥ and ground.

Condition of key switch	Voltage [V]
Key is inserted	Approx. 12
Key is removed	0

Refer to wiring diagram in EL-312.



C

CHECK KEY SWITCH.

- 1) Disconnect key switch connector.
- 2) Check continuity between key switch (insert) terminals ③ and ④ when key is inserted in ignition key cylinder and key is removed from ignition key cylinder.

NG → Replace key switch (insert).

Condition	Continuity
Key is inserted	Yes
Key is removed	No



OK

Check the following.

- 10A fuse [No. 28], located in fuse block (J/B)
- Harness for open or short between key switch and fuse
- Harness for open or short between BCM and key switch

Trouble Diagnoses (Cont'd)

IGNITION KEY SWITCH (ACC AND IGN) INPUT SIGNAL CHECK



CHECK ACC AND IGN INPUT SIGNAL.

A CONSULT

See "IGN ON SW" and "IGN ACC SW" in DATA MONITOR mode.

When ignition switch is ON:

IGN ON SW ON

IGN ACC SW ON

When ignition switch is ACC:

IGN ON SW OFF

IGN ACC SW ON

When ignition switch is OFF:

IGN ON SW OFF

IGN ACC SW OFF

OR

B TESTER

Check voltage between BCM terminal ⑥ or ⑥ and ground.

Terminals	Ignition switch position			
	OFF	ACC	ON	START
⑥ - Ground	Approx. 0V	Battery voltage		Approx. 0V
⑥ - Ground	Approx. 0V		Battery voltage	

Refer to wiring diagram in EL-312.

OK

ACC and IGN input signal is OK.

NG

Check the following.

- 7.5A fuse [No. 23], located in the fuse block (J/B)
- 7.5A fuse [No. 32], located in the fuse block (J/B)
- Harness for open or short between fuse and BCM

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

Trouble Diagnoses (Cont'd)

INTERIOR LAMP AND PERSONAL LAMP SWITCH CHECK



A

CHECK LAMP SWITCHES INPUT SIGNAL.

1. Disconnect BCM connector.
2. Check continuity between BCM terminals and ground.

Switch	Terminals	Condition	Continuity
Interior lamp	② - Ground	ON	Yes
		AUTO/OFF	No
	⑤ - Ground	OFF	Yes
		AUTO/ON	No
Rear personal lamp LH/RH	④ - Ground	FULL	Yes
		HALF/AUTO	No

Refer to wiring diagram in EL-313 or 314.

NG

Check the following.

- Lamp switch
- Lamp switch ground circuit
- Harness for open or short between BCM and lamp switch

OK

Lamp switches are OK.

INTERIOR ILLUMINATION CONTROL — IVMS

Trouble Diagnoses (Cont'd) ILLUMINATION LAMP CHECK


A

■ ACTIVE TEST ■

FR PERSONAL LAMP OFF
or
(FOOT LAMP OFF)
(CONSOLE LAMP OFF)
(RR PERSONAL LAMP OFF)
(KEY RING ILLUM OFF)

ON OFF

SEL923U



Check illumination lamp bulb. NG → Replace bulb.

OK ↓

Check 10A fuse [No. 27] located in the fuse block (J/B). NG → Replace fuse.

OK ↓

CHECK ILLUMINATION LAMP OPERATION. NG → Check the following.

- Turn each lamp switch to the following conditions.
Map lamp LH/RH switch: OFF
Interior lamp switch: AUTO
Rear personal lamp LH/RH switch: OFF

A **CONSULT**

See "FR PERSONAL LAMP (Front map lamp)", "FOOT LAMP (Footwell lamp)", "CONSOLE LAMP", "RR PERSONAL LAMP" or "KEY RING ILLUM" in ACTIVE TEST mode.

Perform operation shown on display.
Illumination lamp should illuminate.

OR

B

- Disconnect BCM connector.
- Apply ground to each terminal of BCM connector.

Does illumination lamp turn on?

Illumination lamp	Terminals
Console lamp	②
Footwell lamp	⑬
Front map lamp LH	④⑥
Front map lamp RH	④④
Rear personal lamp RH	⑤⑦
Rear personal lamp LH	⑤①
Ignition key hole illumination	①①①


Refer to wiring diagram in EL-313, 314 or 315.

OK ↓

Illumination lamps and circuit is OK.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
FDX

Component Parts and Harness Connector Locations



System Description

POWER SUPPLY AND GROUND

Power is supplied at all times

- to BCM terminal (105)
- through 7.5A fuse [No. 14], located in the fuse block (J/B)].

Power is supplied at all times

- to all step lamps terminal ①
- through 10A fuse [No. 27], located in the fuse block (J/B)].

Ground is supplied to terminal ⑭ of LCU01 and LCU02 through body grounds (M14) and (M47).

Ground is also supplied to terminal ⑭ of LCU03 and LCU04 through body grounds (B105) and (B118) or (B22) and (B35).

OPERATING PROCEDURE

BCM is connected to LCU01, LCU02, LCU03 and LCU04 as DATA LINE A-1 or A-2.

When any door switch is in OPEN position, ground is supplied

- to BCM terminal ⑳, ㉑, ㉒, or ㉓
- through driver side, passenger side, rear LH or RH door switch.

Then BCM sends a signal to the LCU to turn on step lamp. With ground supplied, step lamp turns on.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS


BT

MA

EL

IDX



Schematic



STEP LAMP — IVMS

Wiring Diagram — STEP/L — (Cont'd)

EL-STEP/L-02




Refer to last page (Foldout page).
 (M4) (B3)
 (M50) (B101)
 (M22)

STEP LAMP — IVMS

Wiring Diagram — STEP/L — (Cont'd)


EL-STEP/L-03



— : DATA LINE

Refer to EL-POWER.

Refer to last page (Foldout page).








- (E66) (M12)
- (M4) (B3)
- (M11) (D1)
- (M48) (D21)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
FA
EL
IDX

STEP LAMP — IVMS

Wiring Diagram — STEP/L — (Cont'd)

EL-STEP/L-04




Refer to last page (Foldout page).


- (M11) (D1)
- (M48) (D21)
- (M50) (B101)
- (M1)
- (B1)

STEP LAMP — IVMS


Wiring Diagram — STEP/L — (Cont'd)




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT



Refer to last page (Foldout page).



HA
EL
IX




Trouble Diagnoses


CONSULT

CONSULT inspection procedure


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "STEP LAMP".




- DATA MONITOR and ACTIVE TEST are available for the step lamp.

STEP LAMP — IVMS

Trouble Diagnoses (Cont'd)

WORK FLOW



NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

G'

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

STEP LAMP — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE

SYMPTOM: Step lamp does not illuminate/does not go off when door is opened/closed.


A

☆ MONITOR		<input type="checkbox"/>
DOOR SW-DR	OFF	
DOOR SW-AS	OFF	
DOOR SW-RL	OFF	
DOOR SW-RR	OFF	

RECORD

SEL575U

CHECK DOOR SWITCH INPUT SIGNAL.

A  **CONSULT**

See "DOOR SWITCH" in DATA MONITOR mode.

When door is open:
DOOR SW ON


When door is closed:
DOOR SW OFF

NG →


Check the following.

- Door switch
- Door switch ground condition (Front door) or door switch ground circuit (Rear door)
- Harness for open or short between door switch and BCM

B


 **DISCONNECT**

Step lamp connector (D8, D27, D46, D62)



SEL673UA

OR

 **ON-BOARD**

Check all doors switches in Switch monitor (Mode II) mode.
(Refer to On-board Diagnosis, EL-236.)

Refer to wiring diagram in EL-332.

OK ↓

Check step lamp bulb.

NG → **Replace bulb.**

B

CHECK POWER SUPPLY CIRCUIT.

1. Disconnect step lamp connector.
2. Check voltage between step lamp terminal ① and ground.

Battery voltage should exist.
Refer to wiring diagram in EL-334 or 335.

NG →

Check the following.

- 10A fuse [No. 27], located in the fuse block (J/B).
- Harness for open or short between fuse and step lamp

OK ↓

Check harness for open or short between step lamp and LCU.

System Description

REAR POWER WINDOW SWITCH ILLUMINATION

Power is supplied at all times

- to tail lamp relay terminals ① and ⑥
- through 15A fuse [No. ⑥3], located in the fuse, fusible link and relay box].

Ground is supplied

- to the lighting switch terminal ⑤
- through body grounds ②2 and ③6.

When the lighting switch is turned to 1ST or 2ND position, ground is supplied

- to tail lamp relay terminal ②
- from the lighting switch terminal ⑪.

Tail lamp relay is then energized, and power is supplied

- from tail lamp relay terminal ⑦
- through 7.5A fuse [No. ②2], located in the fuse block (J/B)].
- to BCM terminal ③.

BCM is connected to LCU03 and LCU04 as DATA LINE A-1 or A-2.

Rear power window switch illuminations are combined with LCUs.

When lighting switch is turned to 1ST or 2ND position, BCM sends a signal to turn on rear power window switch illuminations.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IX

REAR POWER WINDOW SWITCH ILLUMINATION — IVMS


Schematic




REAR POWER WINDOW SWITCH ILLUMINATION — IVMS

Wiring Diagram — SW/ILL —

EL-SW/ILL-01



Refer to EL-POWER.



Refer to last page (Foldout page).

- (E70) (E81)
- (M1)
- (M22)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL



IDX

REAR POWER WINDOW SWITCH ILLUMINATION — IVMS

Wiring Diagram — SW/ILL — (Cont'd)

EL-SW/ILL-02

▬ : DATA LINE








Refer to last page (Foldout page).

- (M4) (B3)
- (M50) (B106)
- (M22)

REAR POWER WINDOW SWITCH ILLUMINATION — IVMS

Wiring Diagram — SW/ILL — (Cont'd)

EL-SW/ILL-03



Refer to last page (Foldout page).


- (E66), (M12)
- (M4), (B3)
- (M50), (B101)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT

EL

IDX

REAR POWER WINDOW SWITCH ILLUMINATION — IVMS




Trouble Diagnoses


CONSULT

CONSULT inspection procedure


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "ILLUM LAMP".




- DATA MONITOR and ACTIVE TEST are available for the rear power window switch illumination.

REAR POWER WINDOW SWITCH ILLUMINATION — IVMS

Trouble Diagnoses (Cont'd)

WORK FLOW




NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the "disconnected" data will be memorized by the BCM. (While BCM memorizes the "disconnected" data, IVMS communication diagnosis of CONSULT will display "PAST NO RESPONSE".) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to "OFF" position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Component Parts Harness Connector Location



System Description

DESCRIPTION

1. Setting the theft warning system

Disarmed phase

When the vehicle is being driven or when doors or trunk lid is open, the theft warning system is set in the disarmed phase on the assumption that the owner is inside or near the vehicle.

Pre-armed phase and armed phase

The theft warning system turns into the “pre-armed” phase when hood, trunk lid and all doors are closed and locked by key or multi-remote controller. (The security indicator lamp illuminates for 30 seconds.) After about 30 seconds, the system automatically shifts into the “armed” phase (the system is set).

2. Canceling the set theft warning system

When the following (a) or (b) operation is performed, the armed phase is canceled.

- (a) Unlock the doors with the key or multi-remote controller.
- (b) Open the trunk lid with the key or multi-remote controller. When the trunk lid is closed after opening the trunk lid with the key or multi-remote controller, the system returns to the armed phase.

3. Activating the alarm operation of the theft warning system

Make sure the system is in the armed phase.

When the following operation (a), (b) or (c) is performed, the system sounds the horns and flashes the head-lamps for about 2.5 minutes.

- (a) Engine hood or any door is opened before unlocking door with key or multi remote controller.
- (b) Door is unlocked without using key or multi remote controller.
- (c) Trunk lid is opened without using key or multi-remote controller.

POWER SUPPLY

Power is supplied at all times

- through 10A fuse [No. 28], located in the fuse block (J/B)]
- to security indicator lamp terminal ① .

Power is supplied at all times

- through 7.5A fuse [No. 14], located in the fuse block (J/B)]
- to BCM terminal 105 .

With the ignition switch in the ACC or ON position, power is supplied

- through 7.5A fuse [No. 23], located in the fuse block (J/B)]
- to BCM terminal 60 .

With the ignition switch in the ON position, power is supplied

- through 7.5A fuse [No. 32], located in the fuse block (J/B)]
- to BCM terminal 69 .

BCM is connected to LCU01, LCU02, LCU03 and LCU04 as DATA LINE A-1 or A-2.

THEFT WARNING SYSTEM ACTIVATION (Without key or remote controller used to lock doors)

The operation of the theft warning system is controlled by the doors, hood and trunk lid.

To activate the theft warning system, BCM must receive signals indicating the doors, hood and trunk lid are closed and the doors are locked.

When a door is open, BCM terminal 29 , 32 , 33 or 37 receives a ground signal from each door switch.

When a door is unlocked, each door LCU terminal 5 receives a ground signal from terminal 2 of each door unlock sensor.

When the hood is open, BCM terminal 20 receives a ground signal

- from terminal ① of the hood switch
- through body grounds E22 and E36 .

When the trunk lid is open, BCM terminal 19 receives a ground signal

- from terminal ① of the trunk room lamp switch
- through body grounds T12 , B22 and B35 .

When the theft warning system is in armed phase

If none of the described conditions exist, the theft warning system will alarm automatically.

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT

HA

EL

IDX

THEFT WARNING SYSTEM — IVMS

System Description (Cont'd)

THEFT WARNING SYSTEM ACTIVATION (With key or remote controller used to lock doors)

If the key is used to lock doors, LCU01 or LCU02 terminal ⑦ receives a ground signal

- from terminal ③ of the key cylinder switch LH or
- from terminal ① of the door key cylinder switch RH
- through body grounds (M14) and (M47)

If this signal or lock signal from remote controller is received by BCM, the theft warning system will activate automatically.

Once the theft warning system has been activated, BCM terminal ⑥⑤ supplies ground to terminal ② of the security indicator lamp.

The security lamp will illuminate for approximately 30 seconds and then blink.

Now the theft warning system is in armed phase.

THEFT WARNING SYSTEM ALARM OPERATION

The theft warning system is triggered by

- opening a door
- the trunk lid
- opening the hood
- unlocking door without using the key or multi-remote controller.

Once the theft warning system is in armed phase, if BCM receives a ground signal at terminal ⑳⑧, ⑳②, ⑳③, ⑳⑦ (door switch), ⑳⑨ (trunk room lamp switch) or ⑳⑩ (hood switch), or LCU receives a ground signal at terminal ⑤ (door unlock sensor) the theft warning system will be triggered. The headlamps flash and the horn sounds intermittently.

Power is supplied at all times

- through 7.5A fuse (No. ⑭④, located in fuse and fusible link box)
- to theft warning lamp relay terminal ① and
- to theft warning horn relay terminal ①.

When the theft warning system is triggered, ground is supplied intermittently

- from terminal ①⑤ of BCM
- to theft warning lamp relay terminal ② and
- to theft warning horn relay terminal ②.

The headlamps flash and the horn sounds intermittently.

The alarm automatically turns off after 2 or 3 minutes but will reactivate if the vehicle is tampered with again.

THEFT WARNING SYSTEM DEACTIVATION

To deactivate the theft warning system, a door or the trunk lid must be unlocked with the key or remote controller.

When the key is used to unlock a door, BCM terminal ③① or ③⑦ receives a ground signal

- from terminal ① of the key cylinder switch LH or
- from terminal ③ of the key cylinder switch RH.

When the key is used to unlock the trunk lid, BCM terminal ③⑨ receives a ground signal from terminal ① of the trunk lid key cylinder switch.

When the BCM receives either one of these signals or unlock signal from remote controller, the theft warning system is deactivated. (Disarmed phase)

PANIC ALARM OPERATION

Multi-remote control system may or may not operate theft warning system (horn and headlamps) as required.

When the multi-remote control system is triggered, ground is supplied intermittently.


- from BCM terminal ①⑤
- to theft warning lamp relay terminal ② and
- to theft warning horn relay terminal ②.

The headlamp flashes and the horn sounds intermittently.

The alarm automatically turns off after 30 seconds or when smart entrance control unit receives any signal from multi-remote controller.

THEFT WARNING SYSTEM — IVMS

Schematic





CI
MA
EM
LC
EC
TE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-02



Refer to last page (Foldout page).


- (M4) (B3)
- (M6) (N1)
- (M50) (B101)
- (M1)
- (M22)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-03



Refer to last page (Foldout page).





- (E66) (M12)
- (M4) (B3)
- (M22)

THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-04



Refer to last page (Foldout page).



E66, M12
M4, B3
M11, D1
M50, B101

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-05




Refer to last page (Foldout page).
 M4 B3
 M48 D21


THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)


EL-THEFT-06



--- : DATA LINE



Refer to last page (Foldout page).



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT



EL

IDX

THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-07




Refer to last page (Foldout page).
 (E66) (M12)


THEFT WARNING SYSTEM — IVMS

Wiring Diagram — THEFT — (Cont'd)

EL-THEFT-08




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT



Refer to last page (Foldout page).

- E66, M12
- M50, B101
- M22

HA
EL
IDX




Trouble Diagnoses


CONSULT

CONSULT inspection procedure


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".




6. Touch "THEFT WARNING SYSTEM".



- DATA MONITOR and ACTIVE TEST are available for the theft warning system.

WORK FLOW



CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

NOTICE:


- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14] located in the fuse block (J/B)].

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK

The system operation is canceled by turning ignition switch to "ACC" at any step between START and ARMED in the following flow chart.



After performing preliminary check, go to symptom chart on next page.

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

Before starting trouble diagnoses below, perform preliminary check, EL-360.

Symptom numbers in the symptom chart correspond with those of preliminary check.

SYMPTOM CHART

PROCEDURE		—		Diagnostic procedure							—	
REFERENCE PAGE		EL-360	EL-245	EL-362	EL-365	EL-366	EL-367	EL-369	EL-370	EL-371	EL-295	EL-229
SYMPTOM		Preliminary check	Power supply circuit check for BCM	Diagnostic Procedure 1 (Door, hood and trunk room lamp switch check)	Diagnostic Procedure 2 (Security indicator lamp check)	Diagnostic Procedure 3 (Door unlock sensor check)	Diagnostic Procedure 4 (Door key cylinder switch check)	Diagnostic Procedure 5 (Trunk lid key cylinder switch check)	Diagnostic Procedure 6 (Theft warning horn alarm check)	Diagnostic Procedure 7 (Headlamp alarm check)	Check "MULTI-REMOTE CONTROL" system.	WAKE-UP DIAGNOSES
1	Theft warning system cannot be set by ...	All items	X	X	X		X					
		Door out side key	X					X				X (LCU01, LCU02)
		Multi-remote control	X								X	
Theft warning indicator does not turn "ON".		X	X		X							
2	*1 Theft warning system does not alarm when ...	Any door is opened.	X		X							
		Any door is unlocked without using key or multi-remote controller	X				X					X (LCU01, 02, 03, 04)
3	Theft warning alarm does not activate.	Horn alarm	X						X			
		Headlamp alarm	X							X		
4	Theft warning system cannot be canceled by ...	Door out side key	X				X					X (LCU01, LCU02)
		Trunk lid key	X					X				
		Multi-remote control	X								X	

X : Applicable

*1: Make sure the system is in the armed phase.


GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IDX

THEFT WARNING SYSTEM — IVMS


Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1-(1)

(Door switch check)



CHECK DOOR SWITCH INPUT SIGNAL.

A  CONSULT

See "DOOR SWITCH" in DATA MONITOR mode.

When door is open:


DOOR SW ON

When door is closed:


DOOR SW OFF

OK

Door switch is OK.



OR


 ON-BOARD

Check all door switches in Switch monitor (Mode II) mode.

(Refer to On-board Diagnosis, EL-236.)

Refer to wiring diagram in EL-351.

NG



B

CHECK DOOR SWITCH.

- 1) Disconnect door switch connector.
- 2) Check continuity between terminals or switch body ground.

NG

Replace door switch.

	Terminals	Condition	Continuity
Front door switch	① - ground	Pressed	No
		Released	Yes
Rear door switch	① - ②	Pressed	No
		Released	Yes

OK

Check the following.



- Door switch ground condition (Front door) or door switch ground circuit (Rear door)
- Harness for open or short between door switch and BCM

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1-(2)

(Hood switch check)



CHECK HOOD SWITCH INPUT SIGNAL. **OK** → Hood switch is OK.

A CONSULT
See "HOOD SWITCH" in DATA MONITOR mode.
When hood is open:
HOOD SWITCH ON
When hood is closed:
HOOD SWITCH OFF

OR
ON-BOARD
Check hood switch in Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-236.)
Refer to wiring diagram in EL-352.

NG
Check hood switch and hood fitting condition. **NG** → Adjust installation of hood switch or hood.

OK
B CHECK HOOD SWITCH.
1) Disconnect hood switch connector.
2) Check continuity between hood switch terminals. **NG** → Replace hood switch.

Terminals	Condition	Continuity
① - ②	Pushed	No
	Released	Yes


OK
Check the following.
• Hood switch ground circuit
• Harness for open or short between BCM and hood switch

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
iDX

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1-(3) (Trunk room lamp switch check)



CHECK TRUNK ROOM LAMP SWITCH INPUT SIGNAL.

A CONSULT

See "TRUNK SWITCH" in DATA MONITOR mode.

When trunk lid is open:

TRUNK SWITCH ON

When trunk lid is closed:

TRUNK SWITCH OFF

OR


ON-BOARD

Check trunk room lamp switch in Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-236.)

Refer to wiring diagram in EL-352.

OK

Trunk room lamp switch is OK.



B

CHECK TRUNK ROOM LAMP SWITCH.

1) Disconnect trunk room lamp switch connector.

2) Check continuity between trunk room lamp switch terminals.

Terminals	Condition	Continuity
① - ②	Closed	No
	Open	Yes

NG

Replace trunk room lamp switch.

NG

OK




Check the following.

- Trunk room lamp switch ground circuit
- Harness for open or short between BCM and trunk room lamp switch

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 2 (Security indicator lamp check)



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3

(Door unlock sensor check)


A

☆ MONITOR		<input type="checkbox"/>
LOCK SIG-DR	UNLK	
LOCK SIG-AS	LOCK	
LOCK SG-RR/RH	UNLK	
LOCK SG-RR/LH	UNLK	


RECORD

SEL457S


CHECK DOOR UNLOCK SENSOR INPUT SIGNAL. OK → Door unlock sensor is OK.

A  **CONSULT**
 See "LOCK SIG SW" in DATA MONITOR mode.
 When door is locked:
LOCK SIG LOCK
 When door is unlocked:
LOCK SIG UNLK

B




Door lock actuator connectors
 Front LH : (D7) Rear LH : (D48)
 Front RH : (D26) Rear RH : (D68)



SEL025V

OR

 **ON-BOARD**
 Check door lock knob operation in Switch monitor (Mode II) mode.
 (Refer to On-board Diagnoses, EL-236.)
 Refer to wiring diagram in EL-353, 354 or 355.

NG ↓

B NG → Replace door lock actuator.

CHECK DOOR UNLOCK SENSOR.
 1) Disconnect door lock actuator connector.
 2) Check continuity between door lock actuator (door unlock sensor) terminals ② and ④.

Condition	Continuity
Locked	No
Unlocked	Yes

OK ↓


Check the following.

- Harness for open or short between LCU and door unlock sensor
- Ground circuit for door unlock sensor

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4-(2) (Door key cylinder unlock switch check)




CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL (UNLOCK SIGNAL).

A CONSULT

See "KEY CYL UN" in DATA MONITOR mode.

"KEY CYL UN" should be "ON" when key inserted in door key cylinder was turned to unlock.

OK → Door key cylinder switch (unlock) is OK.



OR

B TESTER

Check voltage between BCM terminals ② or ③ and ground.

	Terminals		Key position	Voltage [V]
	⊕	⊖		
LH	③	Ground	Neutral/Lock	Approx. 12
			Unlock	0
RH	②	Ground	Neutral/Lock	Approx. 12
			Unlock	0

Refer to wiring diagram in EL-350.

NG

C

CHECK DOOR KEY CYLINDER SWITCH.

- 1) Disconnect door key cylinder switch connector.
- 2) Check continuity between door key cylinder switch terminals.


Terminals	Key position	Continuity
LH: ① - ②	Neutral/Lock	No
RH: ③ - ②	Unlock	Yes

NG → Replace door key cylinder switch.

OK

Check the following.



- Door key cylinder switch ground circuit
- Harness for open or short between BCM and door key cylinder switch



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

(Trunk lid key unlock signal check)



CHECK TRUNK LID KEY CYLINDER SWITCH INPUT SIGNAL (UNLOCK SIGNAL).

A **CONSULT**

See "TRUNK UNLK SW" in DATA MONITOR mode.

When key in key cylinder is at "NEUTRAL" position,
TRUNK UNLK SW OFF

When key is "UNLOCK" position,
TRUNK UNLK SW ON

OR

ON-BOARD

Check trunk lid key cylinder switch in Switch monitor (Mode II) mode. (Refer to On-board Diagnosis, EL-236.)

Refer to wiring diagram in EL-352.

OK → Trunk lid key unlock switch is OK.

B

CHECK TRUNK LID KEY CYLINDER SWITCH (UNLOCK SWITCH).

1) Disconnect trunk lid key cylinder switch connector.

2) Check continuity between trunk lid key cylinder switch terminals.

Terminals	Condition	Continuity
① - ②	Neutral	No
	Unlocked	No

NG → Replace trunk lid key cylinder switch.

OK

Check the following.


- Trunk lid key cylinder switch ground circuit
- Harness for open or short between trunk lid key cylinder switch and BCM

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

THEFT WARNING SYSTEM — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 6 (Theft warning horn alarm check)



CHECK THEFT WARNING HORN ALARM OPERATION.


A CONSULT

See "ALARM RELAY" in ACTIVE TEST mode.

Perform operation shown on display.

Theft warning horn alarm should operate.

Yes → Horn alarm is OK.



B

1. Disconnect BCM connector.
2. Apply ground to BCM terminal ⑮.

Does horn alarm activate?


Refer to wiring diagram in EL-357.

OR

No

Check theft warning horn relay.

NG → Replace.



C

CHECK POWER SUPPLY FOR THEFT WARNING HORN RELAY.


1. Disconnect theft warning horn relay connector.
2. Check voltage between terminal ① and ground.

Battery voltage should exist.

NG → Check the following.

- 7.5A fuse [No. 14], located in the fuse block (J/B)]
- Harness for open or short between theft warning horn relay and fuse

OK



D

CHECK THEFT WARNING HORN RELAY CIRCUIT.

1. Disconnect theft warning horn relay connector.
2. Check voltage between terminals ③ and ⑤.
3. Check voltage between terminals ⑥ and ⑦.

Battery voltage should exist.

Battery voltage should exist.


NG → Check harness for open or short.

OK

Check harness for open or short between theft warning horn relay and BCM.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7 (Theft warning headlamp alarm check)




Yes → Headlamp alarm is OK.

A CONSULT

See "ALARM RELAY" in ACTIVE TEST mode. Perform operation shown on display. **Theft warning headlamp alarm should operate.**

OR



B

1. Disconnect BCM connector.
2. Apply ground to BCM terminal ⑮.


Does headlamp alarm activate?

Refer to wiring diagram in EL-357.

No → Does headlamp come on when turning lighting switch "ON"?

No → Check headlamp system. Refer to "HEADLAMP".

Yes →



Check theft warning lamp relay.

NG → Replace.

OK →

C


CHECK POWER SUPPLY FOR THEFT WARNING LAMP RELAY.

1. Disconnect theft warning lamp relay connector.
2. Check voltage between terminal ① and ground.

Battery voltage should exist.

NG → Check the following.

- 7.5A fuse [No. 14, located in the fuse block (J/B)]
- Harness for open or short between theft warning lamp relay and fuse



D

CHECK THEFT WARNING LAMP RELAY CIRCUIT.

1. Disconnect theft warning lamp relay connector.
2. Check voltage between terminals ③ and ⑤.
3. Check voltage between terminals ⑥ and ⑦.

Battery voltage should exist.

Battery voltage should exist.

NG → Check harness for open or short.


OK → Check harness for open or short between theft warning lamp relay and BCM.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDOX

THEFT WARNING SYSTEM — IVMS

NOTE

Component Parts and Harness Connector Location



SEL022V

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL
FDX

System Description

OPERATIVE CONDITION

The drive position can be set in 2 ways, manually and automatically.

Manual operation

The driver's seat can be adjusted for sliding, reclining, front cushion height, rear cushion height, and lumbar support with the LH power seat switches. The steering column can be adjusted for tilt and reach (telescopic) with the steering switch. The manual operation can be adjusted with the IGN key in any position.

Automatic operation

The driver's seat and steering column are adjusted to the proper positions for the driver automatically, in 3 different ways: MEMORY AUTOMATIC SET, AUTOMATIC EXITING SETTING and AUTOMATIC SET RETURN. (Automatic Drive Positioner = ADP)

CONDITIONS INHIBITING AUTOMATIC OPERATION

Automatic memory setting procedures are suspended under any of the following conditions:

- (a) When vehicle speed is more than 7 km/h (4 MPH).
- (b) When driver's side power seat switch, tilt or telescopic steering switch is turned on.
- (c) When any two of the switches (set switch and memory switches 1 and 2) are turned ON.
- (d) When cancel switch is turned on.
- (e) When selector lever is in any position other than "P".
- (f) When ignition switch is turned to "START" position.
(Operation resumes when ignition switch is returned to "ON".)
- (g) When any of the following malfunctions are detected:
 - Steering tilt lock detection
(Steering tilt lock is sensed when tilt sensor signal value does not change for a certain period of time.)
 - Steering tilt/telescopic sensor failure detection
(Sensor failure is sensed when sensor output is less than 0.1 volts or greater than 4.9 volts.)
 - Detention switch abnormality detection
(Detention switch failure is sensed when detention switch remains off for at least 2 seconds at a vehicle speed of greater than 7 km/h (4 MPH).

FAIL-SAFE SYSTEM

Output failure

When the ignition switch is in the ON position, if any of the parts (indicated in the following chart) move more than the specified amount within a period "T2" when no "ON" input is sent from any of the switches (indicated in the following chart), or an output from the automatic drive positioner is not produced, an output failure is sensed. Motor operation will be suspended automatically, and all automatic operations will be ineffective. (In this case, the motor will not operate manually.)

OPERATED PORTION	T2	Allowable measurement
Seat sliding	Approx. 2.5 sec.	Within 6 mm (0.24 in)
Seat reclining	Same as above	Change angle within 1°
Steering tilt	Same as above	Change angle within 1°

Absolving

- When moving selector lever back to "P" position after having moved it to any position except "P", fail-safe operation will be canceled.
- If self-diagnosis is performed using CONSULT, fail-safe operation will be canceled.

AUTOMATIC DRIVE POSITIONER — IVMS

System Description (Cont'd)

INITIALIZATION

After reconnecting battery cable, perform initialization procedure A or B. If initialization has not been performed, automatic drive positioner will not operate.

PROCEDURE A

- (1) Insert key in the ignition key cylinder. (Ignition switch is in "OFF" position.)
- (2) Open → close → open driver side door. (Do not perform with the door switch operation.)
- (3) End


PROCEDURE B

- (1) Drive the vehicle at more than 30 km/h (19 MPH).
- (2) End

MEMORY AUTOMATIC SET

Two drive positions can be retained in the memory. Press memory switch to set driver's seat to preset position.

(1) PROCEDURE FOR STORING MEMORY



NOTE: (1) When memory switch for which driver's seat positions are already retained in memory is pressed, new seat positions will be retained in memory in place of the previously set positions.


(2) Drive position is erased from the memory when battery cable is disconnected. After connecting battery cable, perform initialization procedures.

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 IX

AUTOMATIC DRIVE POSITIONER — IVMS

System Description (Cont'd)

(2) SELECTING THE MEMORIZED POSITION



- NOTES: (1) Do not keep cancel switch pressed as it will not operate.
 (2) Automatic exiting setting will be performed.
 (3) The driver's seat position and steering adjustment (see the following Table) operate simultaneously in the order of priority.


The order of priority	Operated portion
1	Seat sliding
2	Steering telescopic
3	Steering tilt
4	Seat reclining
5	Seat front lifting
6	Seat rear lifting

AUTOMATIC EXITING SETTING

For ease of entry and exit, move driver's seat to "exiting" position.

"Exiting" positions:


Driver's seat ... Slides about 40 mm (1.57 in) rear from normal sitting position.



GI
MA
EM
LC
EC

AUTOMATIC SET RETURN

With driver's seat set to the "exiting" position, operating one of the following procedures moves it to the position previously retained in memory.




FE
AT
PD
FA
RA
BR
ST
RS
BT
HA

EL


IDX

AUTOMATIC DRIVE POSITIONER — IVMS

Schematic



Wiring Diagram — AUT/DP —




EL-AUT/DP-01

Refer to EL-POWER.

DATA LINE

BCM (BODY CONTROL MODULE) M22

Refer to last page (Foldout page).



- (E66), (M12)
- (E64)
- (M1)
- (M22)

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA






EL

IDX

AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-02






Refer to last page (Foldout page).

- (E66) (M12)
- (M4) (B3)
- (M22)

AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-03



Refer to last page (Foldout page).


- (M4) (B3)
- (M6) (N1)
- (M1)
- (M22)

GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 DX

AUTOMATIC DRIVE POSITIONER — IVMS


Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-04



Refer to last page (Foldout page).


- (M11) (D1)
- (M22)




AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-05



GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT



Refer to last page (Foldout page).


- (E66), (M12)
- (E70), (E81)
- (M4), (B3)
- (M22)

HA
EL
 IDX

AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-06





Refer to last page (Foldout page).
 (E66) (M12)
 (E70) (E81)
 (M22)

AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-07



Refer to last page (Foldout page).






M4, B3

*: This connector is not shown in "HARNESS LAYOUT", EL section.

AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-08






*: This connector is not shown in "HARNESS LAYOUT", EL section.

AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-09





* : This connector is not shown in "HARNESS LAYOUT", EL section.

AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-10







* : This connector is not shown in "HARNESS LAYOUT", EL section.


AUTOMATIC DRIVE POSITIONER — IVMS

Wiring Diagram — AUT/DP — (Cont'd)

EL-AUT/DP-11



*: This connector is not shown in "HARNESS LAYOUT", EL section.




Trouble Diagnoses


CONSULT

CONSULT inspection procedure


1. Turn ignition switch "OFF".
2. Connect "CONSULT" to the data link connector.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "IVMS".



6. Touch "AUTO DRIVE POSITIONER".



- DATA MONITOR, ACTIVE TEST, and SELF-DIAGNOSIS are available for the automatic drive positioner.

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

HOW TO PERFORM SELF-DIAGNOSIS

A

■ SELF-DIAG RESULTS ■

TOUCH **START**.
BOTH THE SEAT AND THE STEERING COLUMN MOVE TO DIAGNOSE. AFTER THEY COME TO A STOP, TRY TO DRIVE THE CAR AT THE SPEED OF 4 mph [7 km/h] OR MORE WITHIN 15 sec.

START

SEL161T

B

■ SELF-DIAG RESULTS ■

NOW CHECKING
[SEAT/STEERING SYSTEM]

SEL162T

C

■ SELF-DIAG RESULTS ■

FAILURE DETECTED

* NO SELF DIAGNOSTIC FAILURE INDICATED.

FURTHER TESTING MAY BE REQUIRED. **

ERASE **PRINT**

SEL164T

D

■ SELF-DIAG RESULTS ■


FAILURE DETECTED

SEAT LIFTER-RR

VEHICLE SPEED SENSOR

ERASE **PRINT**

SEL165T



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

SELF DIAGNOSTIC RESULT LIST

Diagnostic item	Explanation	Diagnostic procedure	Reference page
*NO SELF DIAGNOSTIC FAILURE INDICATED/FURTHER TESTING MAY BE REQUIRED.**	Normal The automatic drive positioner system is in good order.	—	—
SEAT SLIDE	Condition: While the seat slide is moving backward for 2.5 seconds, then forward for 2.5 seconds. If the number of seat slide sensor pulses changes 2 times or less, the seat slide is determined to be malfunctioning.	PROCEDURE 5 (Sliding sensor check) PROCEDURE 11 (Sliding motor check)	EL-404 EL-410
SEAT RECLINING	Condition: While the seat is reclining forward for 2.5 seconds, then backward for 2.5 seconds. If the number of seat reclining sensor pulses changes 2 times or less, the seat reclining device is determined to be malfunctioning.	PROCEDURE 6 (Reclining sensor check) PROCEDURE 12 (Reclining motor check)	EL-405 EL-411
SEAT LIFTER-FR	Condition: While the lifter's front section is moving down for 2.5 seconds, then up for 2.5 seconds. If the number of sensor pulses (located in the front section of the seat lifter) changes 2 times or less, the front seat lifter is determined to be malfunctioning.	PROCEDURE 7 [Lifting sensor (front) check] PROCEDURE 13 [Lifting motor (front) check]	EL-406 EL-412
SEAT LIFTER-RR	Condition: While the lifter's rear section is moving down for 2.5 seconds, then up for 2.5 seconds. If the number of sensor pulses (located in the rear section of the seat lifter) changes 2 times or less, the rear seat lifter is determined to be malfunctioning.	PROCEDURE 8 [Lifting sensor (rear) check] PROCEDURE 14 [Lifting motor (rear) check]	EL-407 EL-413
STEERING TELESCO	Condition: While steering telesco is moving forward for 1 second, then backward for 1 second. If telesco sensor output changes 0.2 volts or less, the steering telesco section is determined to be malfunctioning.	PROCEDURE 4 (Telescopic sensor check) PROCEDURE 10 (Telescopic motor check)	EL-403 EL-409
STEERING TILT	Condition: While the steering wheel is tilting up for 1 second, then down for 1 second. If tilt sensor output changes 0.2 volts or less, the steering tilt device is determined to be malfunctioning.	PROCEDURE 3 (Tilt sensor check) PROCEDURE 9 (Tilt motor check)	EL-402 EL-408
VEHICLE SPEED SENSOR	If the vehicle speed sensor output of less than 7 km/h (4 MPH) is detected within 15 seconds after completing self-diagnosis on the seat and steering systems, the vehicle speed sensor is determined to be malfunctioning.	PROCEDURE 19 (Vehicle speed sensor check)	EL-418
DETENT SW [PAST INPUT FAIL]	If a vehicle speed of greater than 7 km/h (4 MPH) is detected while the AT selector lever is set to "P", the detent switch input system is determined to be malfunctioning.	PROCEDURE 19 (Detent switch check)	EL-418

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

Diagnostic item	Explanation	Diagnostic procedure	Reference page
SEAT SLIDE [PAST OUTPUT FAIL]	When neither manual input nor ADP output signal is produced, if the seat slides greater than 6 mm (0.24 in) within 2.5 seconds after the seat slide sensor receives an input signal, the seat slide output system is determined to be malfunctioning.	—	—
SEAT RECLINING [PAST OUTPUT FAIL]	When neither manual input nor ADP output signal is produced, if the seat reclines greater than 1° within 2.5 seconds after the seat reclining sensor receives an input signal, the seat reclining output system is determined to be malfunctioning.	—	—
STEERING TILT [PAST OUTPUT FAIL]	When neither manual input signal nor ADP output signal is produced, if the steering wheel tilts greater than 1° within 2.5 seconds after the steering tilt sensor receives an input signal, the steering tilt output system is determined to be malfunctioning.	—	—
TELESCO SEN [PAST]	If a voltage greater than 4.9 volts (in relation to the sensor power source of 5 volts) or less than 0.1 volts is detected across the telescopic sensor, the telescopic sensor system is determined to be malfunctioning.	PROCEDURE 4 (Telescopic sensor check)	EL-403
TILT SEN [PAST]	If a voltage greater than 4.9 volts (in relation to the sensor power source of 5 volts) or less than 0.1 volts is detected across the steering tilt sensor, the tilt sensor system is determined to be malfunctioning.	PROCEDURE 3 (Tilt sensor check)	EL-402


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

ON-BOARD DIAGNOSIS — Mode V (Automatic drive positioner operation)

How to perform mode V



*1: If no self-diagnostic failure is indicated, Mode V will end after the vehicle speed sensor diagnosis is performed.













*2: Diagnosis ends after self-diagnostic results have been indicated for 10 minutes if left unattended.

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

Description

In this mode, a malfunction code is indicated by the number of flashes from the automatic drive positioner indicator lamps (indicator lamp 1, indicator lamp 2) as shown below.

Code No.	Detected items	Indication of seat memory switches 1 and 2	Explanation
1	Seat sliding	IND1, IND2 	While the seat motors are moving for 2.5 seconds, if the number of seat sliding/reclining/lifting sensor pulses changes 2 times or less, the seat device is determined to be malfunctioning.
2	Seat reclining	IND1, IND2 	
3	Seat lifting front	IND1, IND2 	
4	Seat lifting rear	IND1, IND2 	
7	Steering telescopic	IND1, IND2 	While the steering motors are moving, if the steering sensor output changes 0.2 volts or less, the steering device is determined to be malfunctioning.
8	Steering tilt	IND1, IND2 	
11	Vehicle speed sensor circuit	IND1, IND2 	If the vehicle speed sensor output of less than 7 km/h (4 MPH) is detected, the vehicle speed sensor is determined to be malfunctioning.
-	No malfunction in the above items	SW1 IND  SW2 IND  0.5 sec.  0.5 sec.  5 sec. 	—


SEL015V

Code No.	Detected items	Diagnostic procedure	Reference page	Code No.	Detected items	Diagnostic procedure	Reference page
1	Seat sliding	PROCEDURE 5 (Sliding sensor check) PROCEDURE 11 (Sliding motor check)	EL-404 EL-410	7	Steering telescopic	PROCEDURE 4 (Telescopic sensor check) PROCEDURE 10 (Telescopic motor check)	EL-403 EL-409
2	Seat reclining	PROCEDURE 6 (Reclining sensor check) PROCEDURE 12 (Reclining motor check)	EL-405 EL-411	8	Steering tilt	PROCEDURE 3 (Tilt sensor check) PROCEDURE 9 (Tilt motor check)	EL-402 EL-408
3	Seat lifting front	PROCEDURE 7 [Lifting sensor (front) check] PROCEDURE 13 [Lifting motor (front) check]	EL-406 EL-412	11	Vehicle speed sensor	PROCEDURE 19 (Vehicle speed sensor check)	EL-418
4	Seat lifting rear	PROCEDURE 8 [Lifting sensor (rear) check] PROCEDURE 14 [Lifting motor (rear) check]	EL-407 EL-413				

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

WORK FLOW




NOTICE:

- When LCU connectors are disconnected for more than 1 minute such as during trouble diagnoses, the “disconnected” data will be memorized by the BCM. (While BCM memorizes the “disconnected” data, IVMS communication diagnosis of CONSULT will display “PAST NO RESPONSE”.) Therefore, after reconnecting the LCU connectors, erase the memory.
- To erase the memory, perform the procedure below.
Erase the memory with CONSULT (Refer to EL-228.) or turn the ignition switch to “OFF” position and remove 7.5A fuse [No. 14 located in the fuse block (J/B)].

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

PRELIMINARY CHECK



*1: After reconnecting battery cable, perform initialization procedure A or B.
If initialization has not been performed, automatic drive positioner will not operate.

PROCEDURE A

- (1) Insert key in the ignition key cylinder. (Ignition switch is in "OFF" position.)
- (2) Open → close → open driver side door. (Do not perform with the door switch operation.)
- (3) End

PROCEDURE B

- (1) Drive the vehicle at more than 30 km/h (19 MPH).
- (2) End

*2: If only seat slide operates during automatic exit setting, the problem may be due to mechanical tilt mechanism failure. (In this case, all other automatic operation items do not operate.)

After performing preliminary check, go to symptom chart on next page.

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)


Before starting trouble diagnoses below, perform preliminary check, EL-397. Symptom numbers in the symptom chart correspond with those of preliminary check.

SYMPTOM CHART

PROCEDURE		Self-diagnosis		Diagnostic procedure									
		EL-391	EL-394	EL-400	EL-400	EL-402	EL-403	EL-404	EL-405	EL-406	EL-407	EL-408	EL-409
REFERENCE PAGE		EL-391	EL-394	EL-400	EL-400	EL-402	EL-403	EL-404	EL-405	EL-406	EL-407	EL-408	EL-409
SYMPTOM		CONSULT	On-board diagnosis (Mode III)	DIAGNOSTIC PROCEDURE 1 (Power supply and ground circuit for LCU05)	DIAGNOSTIC PROCEDURE 2 (Power supply and ground circuit for tilt/telescopic motor)	DIAGNOSTIC PROCEDURE 3 (Tilt sensor check)	DIAGNOSTIC PROCEDURE 4 (Telescopic sensor check)	DIAGNOSTIC PROCEDURE 5 (Sliding sensor check)	DIAGNOSTIC PROCEDURE 6 (Reclining sensor check)	DIAGNOSTIC PROCEDURE 7 (Lifting sensor (front) check)	DIAGNOSTIC PROCEDURE 8 (Lifting sensor (rear) check)	DIAGNOSTIC PROCEDURE 9 (Tilt motor check)	DIAGNOSTIC PROCEDURE 10 (Telescopic motor check)
1	No seat system functions operate.			X									
2	No steering system functions operate.	X	X		X	X	X						
3	Some of the seat system functions do not operate during automatic/manual operation.	Sliding	X	X									
		Reclining	X	X									
		Lifting (Front)	X	X									
		Lifting (Rear)	X	X									
4	Some of the steering system functions do not operate during automatic/manual operation.	Tilt	X	X								X	
		Telescopic	X	X									X
5	No functions operate during automatic operation, and some/all functions do not operate during manual operation.												
6	Some of the seat system functions do not operate during automatic operation.	Sliding	X	X				X					
		Reclining	X	X					X				
		Lifting (Front)	X	X						X			
		Lifting (Rear)	X	X							X		
7	No automatic operation functions operate.	X	X			X	X						
8	Drive position cannot be retained in the memory.												
9	Does not operate during manual operation. (Operates during automatic operation.)	Seat	Sliding										
			Reclining										
			Lifting (Front)										
			Lifting (Rear)										
			Lumber support										
10	Steering	Tilt											
		Telescopic											
11	Automatic operation can not be canceled.												
12	Memory indicator does not light up.												

X: Applicable

AUTOMATIC DRIVE POSITIONER — IVMS



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

(Power supply and ground circuit for LCU05)


Power supply circuit check

Check voltage between LCU05 terminal ⑩ and ground.
(Refer to wiring diagram in EL-385).

Terminals	Ignition switch position			
	OFF	ACC	ON	START
⑩ - Ground	Battery voltage			

If NG, check the following.


- Circuit breaker-2
- Harness for open or short between circuit breaker-2 and LCU05



Ground circuit check

Check continuity between LCU05 terminal ⑭ and ground.
(Refer to wiring diagram in EL-386.)

Terminals	Continuity
⑭ - Ground	Yes



DIAGNOSTIC PROCEDURE 2

(Power supply and ground circuit for tilt/telescopic motor)

Power supply circuit check

Check voltage between BCM terminal ⑩④ and ground.
(Refer to wiring diagram in EL-380.)

Terminals	Ignition switch position			
	OFF	ACC	ON	START
⑩④ - Ground	Battery voltage			

If NG, check the following.


- Circuit breaker-2
- Harness for open or short between circuit breaker-2 and BCM

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

Ground circuit check

Check continuity between BCM terminal (114) and ground.
(Refer to wiring diagram in EL-379.)



Terminals	Continuity
(114) - Ground	Yes

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT





HA

EL

IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3 (Tilt sensor check)



CHECK TILT SENSOR INPUT SIGNAL. OK → Tilt sensor is OK.

A **CONSULT**

See "TILT SEN" in DATA MONITOR mode.

Steering column in the uppermost position:
Approx. 2V

Steering column in the lowermost position:
Approx. 4V

OR

B **TESTER**

Check voltage between BCM terminals ④ and ⑤.

Steering column position	Voltage [V]
Uppermost	Approx. 2
Lowermost	Approx. 4

Refer to wiring diagram in EL-384.

NG

C

CHECK TILT SENSOR OPEN CIRCUIT. NG → Repair harness.

1. Disconnect BCM connector and tilt sensor connector.

2. Check harness continuity between BCM connector and tilt sensor connector.

Terminals		Continuity
BCM	Tilt sensor	
④	①	Yes
⑤	②	
⑥	③	

OK

D

CHECK TILT SENSOR SHORT CIRCUIT. NG → Repair harness.

Check harness continuity between BCM connector terminals and ground.


Terminals	Continuity
④ - ground	No
⑤ - ground	
⑥ - ground	

OK

Replace tilt sensor.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 4 (Telescopic sensor check)



CHECK TELESCOPIC SENSOR INPUT SIGNAL.

A **CONSULT**

See "TELESCO SEN" in DATA MONITOR mode.


Steering column in the extreme front end position:

Approx. 4.5V

Steering column in the extreme rear end position:

Approx. 0.5V

OK → Telescopic sensor is OK.




B **TESTER**

Check voltage between BCM terminals ③ and ②.

Steering column position	Voltage
Extreme front end	Approx. 4.5V
Extreme rear end	Approx. 0.5V

Refer to wiring diagram in EL-384.



NG


C

CHECK TELESCOPIC SENSOR OPEN CIRCUIT.

1. Disconnect BCM connector and telescopic sensor connector.
2. Check harness continuity between BCM connector and telescopic sensor connector.

Terminals		Continuity
BCM	Telescopic sensor	
③	①	Yes
②	②	
④	③	

NG → Repair harness.



OK

D

CHECK TELESCOPIC SENSOR SHORT CIRCUIT.

Check harness continuity between BCM connector terminals and ground.

Terminals	Continuity
③ - ground	No
② - ground	
④ - ground	

NG → Repair harness.


OK

Replace telescopic sensor.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5 (Sliding sensor check)



A

CHECK SLIDING SENSOR INPUT SIGNAL. OK → Sliding sensor is OK.

Measure voltage between LCU05 terminal ⑳ and ground with oscilloscope when power seat slide is operated.

Refer to wiring diagram in EL-387.

NG


B

CHECK SLIDING SENSOR OPEN CIRCUIT. NG → Repair harness.

1. Disconnect LCU05 connector and sliding motor connector.
2. Check harness continuity between LCU05 connector and sliding motor connector.

Terminals		Continuity
LCU05	Slide motor (Sliding sensor)	
⑳	⑳	Yes
㉑	㉑	

OK



C


CHECK SLIDING SENSOR SHORT CIRCUIT. NG → Repair harness.

Check harness continuity between LCU05 connector and ground.

Terminals	Continuity
⑳ - ground	No
㉑ - ground	







OK

Replace sliding sensor.



Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 6 (Reclining sensor check)



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7 [Lifting sensor (front) check]



A

CHECK LIFTING SENSOR (FRONT) INPUT SIGNAL.
Measure voltage between LCU05 terminal ① and ground with oscilloscope when power seat lifting (front) is operated.

Refer to wiring diagram in EL-388.

OK → Lifting sensor (front) is OK.

NG ↓

B


CHECK LIFTING SENSOR (FRONT) OPEN CIRCUIT.

1. Disconnect LCU05 connector and lifting device connector.
2. Check harness continuity between LCU05 connector and lifting device connector.

Terminals		Continuity
LCU05	Lifting device (Sliding sensor)	
①	①	Yes
②	②	

NG → Repair harness.

OK ↓



C


CHECK LIFTING SENSOR (FRONT) SHORT CIRCUIT.
Check harness continuity between LCU05 connector and ground.

Terminals	Continuity
② - ground	No
③ - ground	

NG → Repair harness.

OK ↓

Replace lifting sensor (front).









AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8




[Lifting sensor (rear) check]



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 9 (Tilt motor check)



A

TILT MOTOR ACTIVE TEST CONSULT

See "TILT MOTOR" in ACTIVE TEST mode.
Perform operation shown on display.
Tilt motor should operate.
Note: If CONSULT is not available, start with diagnostic procedure B .

OK → Tilt motor is OK.

NG

B

CHECK OUTPUT SIGNAL TO TILT MOTOR.
Check voltage between BCM connector terminals (102) or (103) and ground.

Condition of tilt switch	Terminals		Voltage [V]
	⊕	⊖	
Up	(103)	ground	Approx. 12
Down	(102)	ground	Approx. 12

Refer to wiring diagram in EL-384.

NG → Replace BCM.

OK

C

CHECK TILT MOTOR.
1. Disconnect tilt motor connector.
2. Apply 12V DC direct current to motor and check operation.

Terminals		Operation
⊕	⊖	
①	②	Up
②	①	Down




NG → Replace tilt motor.

OK

Check harness for operation between BCM and tilt motor.

Trouble Diagnoses (Cont'd)

**DIAGNOSTIC PROCEDURE 10
(Telescopic motor check)**



A

TELESCOPIC MOTOR ACTIVE TEST CONSULT

See "TELESCO MOTOR" in ACTIVE TEST mode.
Perform operation shown on display.
Telescopic motor should operate.
Note: If CONSULT is not available, start with diagnostic procedure B.

OK → Telescopic motor is OK.

B

CHECK OUTPUT SIGNAL TO TELESCOPIC MOTOR.

Check voltage between BCM connector terminals (101) or (107) and ground.

Condition of telescopic switch	Terminals		Voltage [V]
	⊕	⊖	
Forward	(101)	ground	Approx. 12
Backward	(107)	ground	Approx. 12

Refer to wiring diagram in EL-384.

NG → Replace BCM.

C

CHECK TELESCOPIC MOTOR.

1. Disconnect telescopic motor connector.
2. Apply 12V DC direct current to motor and check operation.

Terminals		Operation
⊕	⊖	
①	②	Forward
②	①	Upward

OK →

NG → Replace telescopic motor.


OK

Check harness for operation between BCM and telescopic motor.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IOX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 11 (Sliding motor check)




A

SLIDING MOTOR ACTIVE TEST CONSULT

See "SEAT MOTOR" in ACTIVE TEST mode.
Perform operation shown on display.
Sliding motor should operate.
Note: If CONSULT is not available, start with diagnostic procedure B.

OK → Sliding motor is OK.



NG ↓


B

CHECK OUTPUT SIGNAL TO SLIDING MOTOR.
Check voltage between LCU05 connector terminals ① or ⑧ and ground.

Condition of sliding switch	Terminals		Voltage [V]
	⊕	⊖	
Forward	①	ground	Approx. 12
Backward	⑧	ground	Approx. 12

Refer to wiring diagram in EL-387.

NG → Replace LCU05.



OK ↓

C

CHECK SLIDING MOTOR.
1. Disconnect sliding motor connector.
2. Apply 12V DC direct current to motor and check operation.

Terminals		Operation
⊕	⊖	
①	⑧	Forward
⑧	①	Backward




NG → Replace sliding motor.

OK ↓

Check harness for operation between LCU05 and sliding motor.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 12 (Reclining motor check)



A

RECLINING MOTOR ACTIVE TEST CONSULT

See "SEAT RECLINING" in ACTIVE TEST mode. Perform operation shown on display. **Reclining motor should operate.**
Note: If CONSULT is not available, start with diagnostic procedure B .

OK → Reclining motor is OK.

B

CHECK OUTPUT SIGNAL TO RECLINING MOTOR.

Check voltage between LCU05 connector terminals ② or ⑨ and ground.

Condition of reclining switch	Terminals		Voltage [V]
	⊕	⊖	
Forward	②	ground	Approx. 12
Backward	⑨	ground	Approx. 12

Refer to wiring diagram in EL-387.

NG → Replace LCU05.

C

CHECK RECLINING MOTOR.

1. Disconnect reclining motor connector.
2. Apply 12V DC direct current to motor and check operation.

Terminals		Operation
⊕	⊖	
②	⑨	Forward
⑨	②	Backward

NG → Replace reclining motor.



OK

Check harness for operation between LCU05 and reclining motor.



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 13 [Lifting motor (Front) check]



OK → Lifting motor (front) is OK.



NG → Replace LCU05.




NG → Replace lifting motor (front).

OK → Check harness for operation between LCU05 and lifting motor (front).

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 14

[Lifting motor (Rear) check]




A

LIFTING MOTOR (REAR) ACTIVE TEST CONSULT

See "SEAT LIFTER RR" in ACTIVE TEST mode.
Perform operation shown on display.
Lifting motor (rear) should operate.
Note: If CONSULT is not available, start with diagnostic procedure B .

OK → Lifting motor (rear) is OK.



B


CHECK OUTPUT SIGNAL TO LIFTING MOTOR (REAR).
Check voltage between LCU05 connector terminals ⑥ or ④ and ground.

NG → Replace LCU05.

Condition of lifting switch (rear)	Terminals		Voltage [V]
	⊕	⊖	
Up	⑥	ground	Approx. 12
Down	④	ground	Approx. 12

Refer to wiring diagram in EL-389.

OK



C

CHECK LIFTING MOTOR (REAR).
1. Disconnect lifting device connector.
2. Apply 12V DC direct current to motor and check operation.

NG → Replace lifting motor (rear).

Terminals		Operation
⊕	⊖	
⑥	④	Up
④	⑥	Down



OK

Check harness for operation between LCU05 and lifting motor (rear).

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 15 (Lifting limit switch check)



A

CHECK LIMIT SWITCH.
 1. Disconnect lifting device connector.
 2. Check continuity between lifting device (limit switch) terminals.

	Terminals	Condition of seat lifting	Continuity
Front	⑬ - ⑭	Fully up	No
		Except the above	Yes
Front	③ - ⑭	Fully down	No
		Except the above	Yes
Rear	⑤ - ⑮	Fully up	No
		Except the above	Yes
Rear	⑬ - ⑰	Fully down	No
		Except the above	Yes

Refer to wiring diagram in EL-388 or 389.

NG → Replace limit switch.

OK

B

CHECK GROUND CIRCUIT FOR LIMIT SWITCH.
 Check continuity between lifting device terminal ⑭ (for limit switch front) or ⑮ (for limit switch rear) and ground.
Continuity should exist.

NG → Repair harness.

OK

Check harness for open or short between LCU05 and limit switch.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 16

(Tilt/telescopic switch check)


A

☆ MONITOR □

TELESCO SW-FR	OFF
TELESCO SW-RR	OFF
TILT SW-UP	OFF
TILT SW-DOWN	OFF

RECORD

SEL006V



CHECK TILT/TELESCOPIC SWITCH INPUT SIGNAL.

A CONSULT

See "TELESCO SW - FR/RR, TILT SW - UP/DOWN" in DATA MONITOR mode. **These switches should change from "OFF" to "ON" when switch is operated.**

OR

ON-BOARD

Check tilt/telescopic switch operation is switch monitor (Mode II) mode. (Refer to On-board diagnosis EL-236.)

Refer to wiring diagram in EL-383.

NG

B

CHECK TILT/TELESCOPIC SWITCH.

1. Disconnect ADP steering switch connector.
2. Check continuity between ADP steering switch terminals.

Switch	Condition	Terminal				
		②	③	④	⑤	⑥
Tilt	Up		○—○			
	Down		○—○	○—○		
Telescopic	Forward		○—○		○—○	
	Backward	○—○				

OK

Check the following.

- Ground circuit for ADP steering switch.
- Harness for open or short between BCM and ADP steering switch.

OK → Tilt/telescopic switch is OK.

NG → Replace ADP steering switch.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IX

Trouble Diagnoses (Cont'd)


DIAGNOSTIC PROCEDURE 17 (Power seat switch check)

A ☆ MONITOR □

SLIDE SW-FR	OFF
SLIDE SW-RR	OFF
RECLN SW-FR	OFF
RECLN SW-RR	OFF
LIFT FR SW-UP	OFF
LIFT FR SW-DN	OFF
LIFT RR SW-UP	OFF
LIFT RR SW-DN	OFF

RECORD

SEL009V



CHECK POWER SEAT SWITCH INPUT SIGNAL. OK → Power seat switch is OK.

A CONSULT

See "SLIDE SW, RECLN SW, LIFT FR, RR" in DATA MONITOR mode.
These switches should change from "OFF" to "ON" when switch is operated.

OR

ON-BOARD

Check each power seat switch operation in switch monitor (Mode II) mode.
 (Refer to On-board diagnosis EL-236.)

Refer to wiring diagram in EL-385.

NG

B NG → Replace power seat switch.

CHECK POWER SEAT SWITCH.

1. Disconnect power seat switch connector.
2. Check continuity between power seat switch terminals.

Switch	Con- dition	Terminals									
		(17)	(18)	(19)	(23)	(24)	(25)	(26)	(27)		
Sliding	For- ward	○	○								
	Back- ward	○			○						
Reclin- ing	For- ward	○	○								
	Back- ward	○				○					
Lifting (Front)	Up	○			○						
	Down	○						○			
Lifting (Rear)	Up	○							○		
	Down	○								○	



OK

Check the following.

- Ground circuit for power seat switch.
- Harness for open or short between LCU05 and power seat switch.

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 18 (Cancel switch check)



CHECK CANCEL SWITCH INPUT SIGNAL. OK → Cancel switch is OK.

A CONSULT

See "CANCEL SW" in DATA MONITOR mode.

When cancel switch is ON:
CANCEL SW ON

When cancel switch is OFF:
CANCEL SW OFF

ON-BOARD

Check cancel switch in switch monitor (Mode II) mode.
(Refer to On-board Diagnosis EL-236.)

Refer to wiring diagram in EL-383.

NG

B

CHECK CANCEL SWITCH. NG → Replace ADP steering switch.

1. Disconnect ADP steering switch connector.

2. Check continuity between ADP steering switch terminals.

Terminals	Cancel switch condition	Continuity
① - ③	ON	Yes
① - ③	OFF	No

OK

Check the following.


- Ground circuit for ADP steering switch
- Harness for open or short between BCM and ADP steering switch.

CI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 19

(Key, detention, door switch and vehicle speed sensor check)



CHECK KEY SWITCH INPUT SIGNAL.

A **CONSULT**

See "IGN KEY SW" in DATA MONITOR mode.

When key is inserted in ignition key cylinder:

IGN KEY SW ON

When key is removed from ignition key cylinder:

IGN KEY SW OFF

OR

B **TESTER**

Check voltage between BCM terminals 69 and ground.



Condition	Voltage [V]
Key is inserted	Approx. 12
Key is removed	0

Refer to wiring diagram in EL-379.

NG

Check the following.

- 10A fuse [No. 28], located in fuse block (J/B)]
- Key switch
- Harness for open or short between key switch and fuse
- Harness for open or short between BCM and key switch



CHECK IGNITION SWITCH INPUT SIGNAL (ACC, ON AND START)

C **CONSULT**

See "IGN ACC SW, IGN ON SW, IGN START SW" in DATA MONITOR mode.

These switches should change from "OFF" to "ON" when ignition key switch is turned to each position.

OR

D **TESTER**

Check voltage between BCM terminals and ground.

Terminals	Ignition key switch position			
	OFF	ACC	ON	START
⊕ ⊖	Approx. 0V	Battery voltage	Approx. 0V	Approx. 0V
Ⓜ ground	Approx. 0V	Battery voltage		
Ⓢ ground	Approx. 0V		Battery voltage	

Refer to wiring diagram in EL-379.

OK

Check the following.


- 7.5A fuse [No. 23] located in the fuse block (J/B)]
- 7.5A fuse [No. 32] located in the fuse block (J/B)]
- 7.5A fuse [No. 34] located in the fuse block (J/B)]
- Harness for open or short between BCM and fuse

A

(Go to next page.)

AUTOMATIC DRIVE POSITIONER — IVMS

Trouble Diagnoses (Cont'd)



A

CHECK DETENTION SWITCH INPUT SIGNAL
E CONSULT

See "DETENT SW" in DATA MONITOR mode.
"DETENT SW" should be "ON" when setting A/T selector lever in "P" position.

OR


ON-BOARD

Check detention switch operation in switch monitor (Mode II) mode.
 (Refer to On-board Diagnoses, EL-236.)

Refer to wiring diagram in EL-380.

NG → Check the following.

- Detention switch
- Harness for open or short



CHECK DRIVER DOOR SWITCH INPUT SIGNAL
F CONSULT

See "DOOR SW DR" in DATA MONITOR mode.
 When driver's door is open:
DOOR SW-DR ON
 When driver's door is closed:
DOOR SW-DR OFF

OR


ON-BOARD

Check driver's door switch operation in Switch monitor (Mode II) mode.
 (Refer to On-board Diagnoses EL-236.)

Refer to wiring diagram in EL-383.

NG → Check the following.

- Driver door switch
- Driver door switch ground condition
- Harness for open or short between driver door switch and BCM



CHECK VEHICLE SPEED SENSOR.
 Does speedometer operate normally?

No → Check speedometer and vehicle speed sensor circuit.
 Refer to EL-105.

G

CHECK VEHICLE SPEED SENSOR PULL UP VOLTAGE

1. Turn ignition switch to ACC.
2. Check voltage between BCM terminal ④ and ground.

Approx. 5V should exist.

Refer to wiring diagram in EL-381.

NG → Replace BCM.

Check harness for open or short between BCM terminal ④ and combination meter terminal ⑩.



NG → Repair harness.

INSPECTION END

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 20 (Seat memory switch check)



CHECK SEAT MEMORY SWITCH INPUT SIGNAL. OK → Seat memory switch is OK.

A CONSULT

See "SET SW, MEMORY SW-1, 2" in DATA MONITOR mode.

These switches should change from "OFF" to "ON" when switch is operated.

OR

ON-BOARD

Check each seat memory switch operation in Switch monitor (Mode II) mode. (Refer to On-board diagnosis EL-236.)

Refer to wiring diagram in EL-382.

NG

B

CHECK SEAT MEMORY SWITCH. NG → Replace seat memory switch.

1. Disconnect seat memory switch connector.
2. Check continuity between seat memory switch terminals.

Switch	Terminals			
	①	②	③	④
Memory-1	○			○
Memory-2		○		○
Set			○	○




OK

Check the following.

- Ground circuit for seat memory switch
- Harness for open or short between BCM and seat memory switch.

Trouble Diagnoses (Cont'd)

**DIAGNOSES PROCEDURE 21
(Memory indicator check)**




**DIAGNOSTIC PROCEDURE 22
(Lumbar support check)**

Symptom	Possible cause	Repair order
Power lumbar support moves neither forward nor backward.	1. Power supply circuit for power lumbar support switch. 2. Ground circuit 3. Lumbar support motor 4. Lumbar support motor circuit	1. Verify battery voltage is present at terminal ⑩ of power seat switch. 2. Check ground circuit for power seat switch terminal ⑭. 3. Check lumbar support motor. 4. Check harness for open or short between lumbar support motor and power seat switch.
Power lumbar support does not move forward or backward.	1. Lumbar support switch	1. Check power seat switch.

Refer to wiring diagram in EL-386.

Component Parts and Harness Connector Location



System Description


NATS (Nissan Anti-Theft System) has the following immobilizer functions:

- Since only NATS ignition keys, whose ID nos. have been registered into the ECM and IMMU of NATS, allow the engine to run, operation of a stolen vehicle without a NATS registered key is prevented by NATS. That is to say, NATS will immobilize the engine if someone tries to start it without the registered key of NATS.
- All of the originally supplied ignition key IDs (except for card plate key) have been NATS registered. If requested by the vehicle owner, a maximum of five key IDs can be registered into the NATS components.
- The security indicator blinks when the ignition switch is in “OFF” or “ACC” position. Therefore, NATS warns outsiders that the vehicle is equipped with the anti-theft system.
- When NATS detects trouble, the security indicator lamp lights up while ignition key is in the “ON” position.
- NATS trouble diagnoses, system initialization and additional registration of other NATS ignition key IDs must be carried out using CONSULT hardware and CONSULT NATS software. When NATS initialization has been completed, the ID of the inserted ignition key is automatically NATS registered. Then, if necessary, additional registration of other NATS ignition key IDs can be carried out. Regarding the procedures of NATS initialization and NATS ignition key ID registration, refer to CONSULT operation manual, NATS.
- **When servicing a malfunction of the NATS (indicated by lighting up of Security Indicator Lamp) or registering another NATS ignition key ID no., it may be necessary to re-register original key identification. Therefore, be sure to receive all keys from vehicle owner.**

System Composition


The immobilizer function of the NATS consists of the following:

- NATS ignition key
- NATS antenna amp. located in the ignition key cylinder
- NATS immobilizer control unit (NATS IMMU)
- Engine control module (ECM)
- Security indicator



Wiring Diagram — NATS —

EL-NATS-01




Refer to EL-POWER.

NATS IMMU (M38)

NATS ANTENNA AMP. (E73)


Refer to last page (Foldout page).



- (E66), (M12)
- (M6), (N1)
- (M49), (F63)
- (M1)
- (M22)
- (F69)

Trouble Diagnoses

WORK FLOW





GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
FA
EL
IDX

Trouble Diagnoses (Cont'd)

CONSULT INSPECTION PROCEDURE


1. Turn off ignition switch.
2. Connect "CONSULT" to Data link connector for CONSULT.



3. Insert NATS program card into CONSULT.

◀ **Program card**
NATS-E960U

4. Turn on ignition switch.
5. Touch "START".



6. Perform each diagnostic test mode according to each service procedure.

For further information, see the CONSULT Operation Manual, NATS.

IPPS (Infiniti Personal Protection System — NATS)

Trouble Diagnoses (Cont'd)

CONSULT DIAGNOSTIC TEST MODE FUNCTION

CONSULT DIAGNOSTIC TEST MODE	Description
C/U INITIALIZATION	When replacing any of the following three components, C/U initialization is necessary. [NATS ignition key/IMMU/ECM]
SELF-FUNCTION CHECK	ECM checks its own NATS communication interface by itself.
SELF-DIAGNOSTIC RESULTS	Detected items (screen terms) are as shown in the chart below.

HOW TO READ SELF-DIAGNOSTIC RESULTS

Result display screen (When no malfunction is detected)

■ SELF-DIAG RESULTS ■ □

FAILURE DETECTED TIME
*NO SELF DIAGNOSTIC FAILURE INDICATED.
FURTHER TESTING MAY BE REQUIRED. **

ERASE PRINT

Result display screen (When malfunction is detected)

■ SELF-DIAG RESULTS ■ □ ← Page mark

FAILURE DETECTED TIME
IMMU 0 ← Time data*
DIFFERENCE OF KEY 1
This indicates how many times the vehicle was driven after the last detection of a malfunction. If the malfunction is being detected currently, the time data will be "0".

ERASE PRINT ← When touched, the self-diagnostic results are printed out.

Detected items →

When touched, the self-diagnostic results stored in the engine control module (ECM) are erased.

SEL332UC

* If trip number is more than 1, MIL does not blink.

SELF-DIAGNOSTIC RESULTS ITEM CHART

Detected items (Screen terms)	Description	Reference page
IMMU	ECM received the signal from IMMU that IMMU is malfunctioning.	EL-430
ECM	ECM is malfunctioning.	EL-430
CHAIN OF ECM-IMMU	Communication impossible between ECM and IMMU.	EL-431
DIFFERENCE OF KEY	IMMU can receive the key ID signal but the result of ID verification between key ID and IMMU is NG.	EL-433
CHAIN OF IMMU-KEY	IMMU cannot receive the key ID signal.	EL-434
ID DISCORD, IMM-ECM	The result of ID verification between IMMU and ECM is NG. System initialization is required.	EL-436
ELECTRONIC NOISE	Noise (interference) interfered into NATS communication lines during communicating.	EL-437
DON'T ERASE BEFORE CHECKING ENG DIAG	Engine trouble data and NATS trouble data have been detected in ECM.	EL-425
LOCK MODE	When an unregistered ignition key is used, or if the starting operation is carried out 5 or more times consecutively with the ignition key, IMMU or ECM malfunctioning, NATS will shift the mode to one which prevents the engine from being started.	EL-439

IPPS (Infiniti Personal Protection System — NATS)

Trouble Diagnoses (Cont'd)

SYMPTOM MATRIX CHART 1 (Self-diagnosis related item)

SYMPTOM	Displayed "SELF-DIAG RESULTS" on CONSULT screen.	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)	REFERENCE PART NO. OF ILLUSTRATION ON NEXT PAGE
<ul style="list-style-type: none"> ● Security indicator lighting up* ● Engine will start. 	IMMU	PROCEDURE 1 (EL-430)	IMMU	A
	ECM	PROCEDURE 2 (EL-430)	ECM	B
<ul style="list-style-type: none"> ● Security indicator lighting up* ● Engine hard to start 	CHAIN OF ECM-IMMU	PROCEDURE 3 (EL-431)	Open circuit in battery voltage line of IMMU circuit	C1
			Open circuit in ignition line of IMMU circuit	C2
			Open circuit in ground line of IMMU circuit	C3
			Open circuit in communication line between IMMU and ECM	C4
			Short circuit between IMMU and ECM communication line and battery voltage line	C4
			Short circuit between IMMU and ECM communication line and ground line	C4
			Open circuit in power source line of ANT/AMP circuit	E3
			ECM	B
	IMMU	A		
	DIFFERENCE OF KEY	PROCEDURE 4 (EL-433)	Unregistered key	D
			IMMU	A
	CHAIN OF IMMU-KEY	PROCEDURE 5 (EL-434)	Communication line between ANT/AMP and IMMU; Open circuit or short circuit of battery voltage line or short circuit of ground line	E1
				E2
			Open circuit in power source line of ANT/AMP circuit	E3
Open circuit in ground line of ANT/AMP circuit			E4	
Malfunction of key ID chip			E5	
IMMU			A	
Antenna amp.	E6			

*: When NATS detects trouble, the security indicator lights up while ignition key is in the "ON" position.

IPPS (Infiniti Personal Protection System — NATS)

Trouble Diagnoses (Cont'd)


SYMPTOM	Displayed "SELF-DIAG RESULTS" on CONSULT screen.	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)	REFERENCE PART NO. OF ILLUSTRATION ON NEXT PAGE
<ul style="list-style-type: none"> Security indicator lighting up* Engine hard to start 	ID DISCORD, IMM-ECM	PROCEDURE 6 (EL-436)	System initialisation has not yet been completed.	F
	ELECTRONIC NOISE	PROCEDURE 7 (EL-437)	ECM	F
	LOCK MODE	PROCEDURE 9 (EL-439)	LOCK MODE	D
<ul style="list-style-type: none"> MIL staying ON Security indicator lighting up* 	DON'T ERASE BEFORE CHECKING ENG DIAG	WORK FLOW (EL-425)	Engine trouble data and NATS trouble data have been detected in ECM	—

*: When NATS detects trouble, the security indicator lights up while ignition key is in the "ON" position.

SYMPTOM MATRIX CHART 2 (Non self-diagnosis related item)

SYMPTOM	DIAGNOSTIC PROCEDURE (Reference page)	SYSTEM (Malfunctioning part or mode)
Security ind. does not light up.	PROCEDURE 8 (EL-438)	Security ind.
		Open circuit between Fuse and NATS IMM
		Continuation of initialization mode
		NATS IMM


DIAGNOSTIC SYSTEM DIAGRAM



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 1

Self-diagnostic results:
"IMMU" displayed on CONSULT screen



A



Confirm SELF-DIAGNOSTIC RESULTS "IMMU" displayed on CONSULT screen.
Ref. part No.* A.


Yes

Replace IMMU.



Perform initialisation with CONSULT.
For the operation of initialization, refer to "CONSULT operation manual NATS".

* Ref. part No.: reference part No. of Diagnostic System Diagram on EL-429.



DIAGNOSTIC PROCEDURE 2

Self-diagnostic results:
"ECM" displayed on CONSULT screen

A



Confirm SELF-DIAGNOSTIC RESULTS "ECM" displayed on CONSULT screen.
Ref. part No. B.

Replace ECM.

















Perform initialization with CONSULT.
For the operation of initialization, refer to "CONSULT operation manual NATS".

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 3


Self-diagnostic results:

"CHAIN OF ECM-IMMU" displayed on CONSULT screen



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)



F


CHECK COMMUNICATION LINE CIRCUIT.

- 1) Disconnect ECM connector and IMMU connector.
- 2) Check voltage between the following terminals and ground.
ECM ⑦①, ECM ⑦②, IMMU ⑤ and IMMU ⑥

Voltage: 0V

NG

Communication line is short-circuited with battery voltage line or ignition switch ON line.
Repair harness or connectors.
Ref. part No. C4




G

Check continuity between the following terminals and ground.
ECM ⑦①, ECM ⑦②, IMMU ⑤ and IMMU ⑥

Continuity should not exist.

NG

Communication line is short-circuited with ground line.
Repair harness or connectors.
Ref. part No. C4



H


CHECK NATS ANTENNA AMP. CIRCUIT.

- 1) Disconnect NATS antenna amp. connector.
- 2) Turn ignition switch "ON".
- 3) Check voltage between antenna amp. terminal ① and ground.

Voltage:
6 sec. after turning ignition switch "ON"
Approx. 4.7V

NG


NATS antenna amp. +5V line is short-circuited with battery voltage line or ground line.
Repair harness or connectors.
Ref. part No. E3



I

SELF-FUNCTION CHECK

- 1) Connect ECM connector and disconnect IMMU connector.
- 2) Turn ignition switch "ON".
- 3) Touch "SELF-FUNCTION CHECK" on CONSULT "SELECT DIAG MODE" screen.



J

Touch "START". ECM will then check its communication interface by itself.





NG

K (See next page.)

ECM is malfunctioning. Replace ECM.
Ref. part No. B

Perform initialisation with CONSULT. For the operation of initialization, refer to "CONSULT operation manual NATS".

Trouble Diagnoses (Cont'd)



⑧

IMMU is malfunctioning.
Replace IMMUN.
Ref. part No. A

☎ Perform initialization with CONSULT.
For the operation of initialization, refer to "CONSULT operation manual NATS".

DIAGNOSTIC PROCEDURE 4

Self-diagnostic results:
"DIFFERENCE OF KEY" displayed on CONSULT screen

A ☎ Confirm SELF-DIAGNOSTIC RESULTS "DIFFERENCE OF KEY" displayed on CONSULT screen.

☎ Perform initialization with CONSULT.
Re-register all NATS ignition key IDs.
For the operation of initialization, refer to "CONSULT operation manual NATS".

Start engine.

END
(Ignition key ID was unregistered.)
Ref. part No. D

Initialization incompleted or failed with CONSULT

B IMMUN is malfunctioning.
Replace IMMUN.
Ref. part No. A





☎ Perform initialization with CONSULT.
For the operation of initialization, refer to "CONSULT operation manual NATS".

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 5

Self-diagnostic results:
 "CHAIN OF IMMU-KEY" displayed on CONSULT screen



A Confirm SELF-DIAGNOSTIC RESULTS "CHAIN OF IMMU-KEY" displayed on CONSULT screen.

OK
CHECK NATS IGNITION KEY ID CHIP.
 1) Connect NATS antenna amp. connector.
 2) Pull the ignition key out.
 3) Start engine with another registered NATS ignition key.

Start OK
 Ignition key ID chip was malfunctioning.
 Replace the ignition key.
Ref. part No. E5

Start NG
B **CHECK IMMU FUNCTION 1.**
 1) Connect IMMU connector and NATS antenna amp. connector.
 2) Check voltage between IMMU terminal ① and ground.

Voltage

Time (After turning ignition switch "ON".)	Voltage [V]
For approx. 0.5 sec.	Approx. 2.3 - 5
After 1 sec.	0

NG
 Perform initialization with CONSULT. For the operation of initialization, refer to "CONSULT operation manual NATS".

NG
 Replace IMMU.
Ref. part No. A

OK
C **CHECK IMMU FUNCTION 2.**
 1) Disconnect NATS antenna amp. connector.
 2) Turn ignition switch "ON".
 3) Check voltage between IMMU terminal ⑫ and ground.
Voltage:
6 sec. after turning ignition switch "ON"
Approx. 4.5 - 5V

NG
 Replace IMMU.
Ref. part No. A


NG
 Perform initialization with CONSULT. For the operation of initialization, refer to "CONSULT operation manual NATS".

OK
D **CHECK IMMU OUTPUT VOLTAGE.**
 1) Turn the ignition switch "ON".
 2) Check voltage between IMMU terminal ② and ground.
Voltage:
6 sec. after turning ignition switch "ON"
Approx. 4.7V

NG
 Replace IMMU.
Ref. part No. A

OK
 (A)

Trouble Diagnoses (Cont'd)



E


CHECK IMMU GROUND CIRCUIT.

- 1) Turn the ignition switch "OFF".
- 2) Connect IMMU connector.
- 3) Check continuity between IMMU terminal ⑩ and ground.

Continuity should exist.

NG → Replace IMMU.
Ref. part No. A

OK → **F**



F

CHECK ANTENNA AMP. CIRCUIT.


- 1) Disconnect IMMU connector and NATS antenna amp. connector.
- 2) Check continuity between the following IMMU terminals and NATS antenna amp. terminals.

IMMU terminal	NATS antenna amp. terminal	Ref. part No.
⑩	③	E1
①	②	E2

Continuity should exist.

NG → Perform initialization with CONSULT. For the operation of initialization, refer to "CONSULT operation manual NATS".

OK → **G**



G


Check continuity between the following terminals and ground.

IMMU terminal	NATS antenna amp. terminal	Ref. part No.
⑩	③	E1
①	②	E2

Continuity should not exist.

NG → Communication line is short-circuited with ground line. Repair harness or connectors.

OK → **H**



H


Check voltage between the following terminals and ground.

IMMU terminal	NATS antenna amp. terminal	Ref. part No.
⑩	③	E1
①	②	E2

Voltage: 0V

NG → Communication line is short-circuited with battery voltage line or ignition switch "ON" line. Repair harness or connectors.

OK → **I**



I

CHECK ANTENNA AMP. POWER SOURCE CIRCUIT.

- 1) Connect IMMU connector.
- 2) Check voltage between NATS antenna amp. terminal ① and ground.




Voltage:
6 sec. after turning ignition switch "ON"
Approx. 4.7V

NG → Power source line is open circuit. Repair harness or connector. Ref. part No. E3

OK → **B**

IPPS (Infiniti Personal Protection System — NATS)



Trouble Diagnoses (Cont'd)



DIAGNOSTIC PROCEDURE 6

Self-diagnostic results:




"ID DISCORD, IMM-ECM" displayed on CONSULT screen



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 7

Self-diagnostic results:
 "ELECTRONIC NOISE" displayed on CONSULT screen



GI
 MA
 EM
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 RS
 BT
 HA
 EL
 DX

Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 8

“SECURITY IND. DOES NOT LIGHT UP”

Check 10A fuse [No. 28], located in the fuse block (J/B).

NG

Replace fuse.

OK



NATS INITIALIZATION

- 1) Install the 10A fuse.
 - 2) Perform initialization with CONSULT.
- For the operation of initialization, refer to “CONSULT operation manual NATS”.

Turn ignition switch “OFF”.

Start engine and turn ignition switch “OFF”.

Check the security ind. lighting.

OK

END

NG

A

Check voltage between security ind. connector terminal ① and ground.

Voltage: Battery voltage

NG

Check harness for open or short between fuse and security ind.

OK

CHECK INDICATOR LAMP.

NG

Repair harness.

OK

B

CHECK NATS IMMU FUNCTION

- 1) Connect NATS IMMU connector.
 - 2) Disconnect security ind. connector.
 - 3) Check continuity between NATS IMMU terminal ⑩ and ground.
- Continuity should exist intermittently.**



NG

NATS IMMU is malfunctioning. Replace IMMU.

OK

Perform initialization with CONSULT. For the operation of initialization, refer to “CONSULT operation manual NATS”.





Check harness for open or short between security indicator and NATS IMMU.



Trouble Diagnoses (Cont'd)

DIAGNOSTIC PROCEDURE 9

Self-diagnostic results:
"LOCK MODE" displayed on CONSULT screen





*: There is a trace that an engine-start was tried with incorrect key or procedure. No abnormality exists in the system itself.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX


INTEGRATED HOMELINK TRANSMITTER

Wiring Diagram — TRNSMT —


EL-TRNSMT-01



M15
W



M61
GY






R2
W

Refer to last page (Foldout page).

M1

INTEGRATED HOMELINK TRANSMITTER




Trouble Diagnoses

DIAGNOSTIC PROCEDURE

SYMPTOM: Transmitter does not activate receiver.

Before conducting the procedure given below, make sure that system receiver (garage door opener, etc.) operates with original, hand-held transmitter. If NG, receiver or hand-held transmitter is at fault, not vehicle related.





*For details, refer to Technical Service Bulletin.

GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IOX



LOCATION OF ELECTRICAL UNITS

Engine Compartment




LOCATION OF ELECTRICAL UNITS

Luggage Compartment




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

Passenger Compartment




A Instrument panel LH side



LOCATION OF ELECTRICAL UNITS

Passenger Compartment (Cont'd)



CEL437


GI
MA
EV
LC
EC
FE
AT
PD
FA
RA
BR
ST
KS
BT
HA

EL

DX

HARNESS LAYOUT


Outline



HARNESS LAYOUT

How to Read Harness Layout

Example:



The following Harness Layouts use a map style grid to help locate connectors on the drawings:

- Main Harness
- Engine Room Harness (Engine Compartment)
- Body Harness
- Body No. 2 Harness

To use the grid reference

- 1) Find the desired connector number on the connector list.
- 2) Find the grid reference.
- 3) On the drawing, find the crossing of the grid reference letter column and number row.
- 4) Find the connector number in the crossing zone.
- 5) Follow the line (if used) to the connector.

CONNECTOR SYMBOL

Main symbols of connector (in Harness Layout) are indicated in the below.

Connector type	Water proof type		Standard type	
	Male	Female	Male	Female
<ul style="list-style-type: none"> ● Cavity: Less than 4 ● Relay connector 				
<ul style="list-style-type: none"> ● Cavity: From 5 to 8 				
<ul style="list-style-type: none"> ● Cavity: More than 9 	—	—		
<ul style="list-style-type: none"> ● Ground terminal etc. 	—			

GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX

HARNESS LAYOUT

Engine Room Harness



HARNESS LAYOUT

Engine Room Harness (Cont'd)


B2	(E1)	-	Fuse, fusible link and relay box				
B1	(E2)	-	Fuse, fusible link and relay box				
B1	(E3)	BR/6	Headlamp relay				
B1	(E4)	L/4	Cooling fan relay-1				
B1	(E5)	W/3	Horn relay				
C1	(E6)	B/5	Front wiper relay				
C1	(E7)	L/4	Cooling fan relay-2				
B1	(E8)	GY/6	Tail lamp relay				
B1	(E9)	GY/6	Park/Neutral position relay				
B1	(E10)	BR/6	Theft warning lamp relay				
D2	(E11)	B/8	To (F4)				
D2	(E12)	GY/8	To (F3)				
D2	(E13)	GY/8	To (F2)				
C2	(E14)	GY/6	To (F1)				
D3	(E15)	B/2	ABS relay unit				
A4	(E16)	GY/2	Front washer motor				
B4	(E17)	BR/2	Washer level switch				
A4	(E18)	GY/2	Front fog lamp RH				
B2	(E19)	B/6	To (E102)				
C3	(E20)	GY/1	To (E103)				
C3	(E21)	GY/8	To (E101)				
A2	(E22)	-	Body ground				
A3	(E23)	BR/3	Front combination lamp RH				
A4	(E24)	B/3	Headlamp RH (For U.S.A.)				
A3	(E25)	B/3	Headlamp RH (For Canada)				
C2	(E26)	GY/2	Dropping resistor				
B3	(E27)	B/4	Cooling fan motor-2				
B4	(E28)	B/1	Horn low				
C4	(E29)	B/1	Horn high				
B4	(E30)	B/2	Ambient sensor				
C4	(E31)	B/4	Cooling fan motor-1				
E4	(E32)	BR/3	Front combination lamp LH				
D4	(E33)	B/3	Headlamp LH (For Canada)				
D4	(E34)	B/3	Headlamp LH (For U.S.A.)				
C4	(E35)	B/4	Triple-pressure switch				
E3	(E36)	-	Body ground				
D5	(E37)	GY/2	Front fog lamp LH				
E3	(E38)	GY/2	Hood switch				
E3	(E39)	GY/8	Daytime light control unit (For Canada)				
F4	(E40)	GY/6	Daytime light control unit (For Canada)				
F3	(E41)	GY/4	Daytime light control unit (For Canada)				
F3	(E42)	B/1	Theft warning horn				
F2	(E43)	GY/4	ASCD pump				
E2	(E44)	GY/2	Brake fluid level switch				
E3	(E45)	GY/2	Front wheel sensor LH				
B2	(E46)	GY/6	Joint connector-13				
B2	(E47)	W/6	Joint connector-14				
B2	(E48)	W/6	Joint connector-15				

★ : Be sure to connect and securely lock connectors after the repairs.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)

CI
MA
EM
LC
EC
EE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

HARNESS LAYOUT


Engine Room Harness (Cont'd)



★ : Be sure to connect and securely lock connectors after the repairs. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)

HARNESS LAYOUT

Instrument Harness



- W/2 : Ignition key hole illumination
- W/12 : A/C control unit
- W/12 : Radio
- B/6 : Radio
- W/10 : Radio
- W/6 : Radio
- W/8 : Hazard switch
- W/3 : Illumination control switch
- GY/6 : Joint connector-18
- W/6 : Telephone switch

- N16 : Ignition key hole illumination
- N17 : A/C control unit
- N18 : Radio
- N19 : Radio
- N20 : Radio
- N21 : Radio
- N22 : Hazard switch
- N23 : Illumination control switch
- N24 : Joint connector-18
- N25 : Telephone switch

- SMJ : To M6
- B/6 : To M7
- W/6 : ASCD main switch
- W/3 : Front cigarette lighter
- W/6 : TCS switch
- W/4 : Illumination time control switch
- W/2 : Security indicator
- W/3 : Warning chime
- W/4 : Optical sensor
- BR/16 : Combination meter
- W/14 : Combination meter
- W/16 : Combination meter
- B/2 : Sunload sensor


★ : Be sure to connect and securely lock connectors after the repairs. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)

EL
 FA
 BT
 RS
 ST
 BR
 RA
 FA
 PD
 AT
 FE
 EC
 LC
 EM
 MA
 GI

HARNES LAYOUT

Main Harness (Cont'd)

A3	(M1)	SMJ	Fuse block (J/B)	E1	(M31)	B/6	Bi-level door motor
A2	(M2)	L/4	Sunroof relay	F2	(M32)	W/20	To (Z1)
A3	(M3)	B/6	To (B4)	E2	(M33)	W/8	Power steering control unit
A3	(M4)	SMJ	To (B3)	F3	(M34)	W/3	Intake sensor
B3	(M5)	GY/14	Data link connector for CONSULT	D2	(M35)	BR/10	Mode door motor
B3	(M6)	SMJ	To (N1)	E4	(M36)	W/12	A/T device
B3	(M7)	B/6	To (N2)	E3	(M38)	W/12	NATS IMMU
A2	(M11)	W/40	To (D1)	E2	(M39)	B/3	Combination flasher unit
B3	(M12)	SMJ	To (E66)	E3	(M40)	B/6	Rear vent door motor
B2	(M13)	B/1	Parking brake switch	D3	(M41)	W/2	In-vehicle sensor
A2	(M14)	-	Body ground	C3	(M42)	B/2	Footwell lamp (Driver's side)
A1	(M15)	W/18	To (R1)	D3	(M43)	B/6	Air mix door motor
B2	(M16)	W/2	Diode	C3	(M44)	W/20	A/C auto amp.
B2	(M17)	W/2	Diode	C2	(M45)	W/16	A/C auto amp.
C2	(M18)	W/12	Shift lock control unit	D2	(M46)	GY/20	A/C auto amp.
C3	(M19)	B/20	ASCD control unit	G2	(M47)	-	Body ground
C2	(M20)	B/2	Stop lamp switch	G2	(M48)	W/40	To (D21)
C2	(M21)	L/2	ASCD brake switch	G3	(M49)	W/48	To (F63)
D2	(M22)	SMJ	BCM (Body control module)	G2	(M50)	W/48	To (B101)
D2	(M23)	L/4	ASCD hold relay	B3	(M51)	L/12	Joint connector-1
E2	(M24)	W/2	Trunk lid opener cancel switch	A3	(M52)	G/12	Joint connector-2
E2	(M25)	BR/2	Glove box lamp switch	A3	(M53)	G/12	Joint connector-3
F3	(M26)	W/2	Glove box lamp	B2	(M54)	G/12	Joint connector-4
F3	(M27)	W/2	Blower motor	F1	(M55)	B/12	Joint connector-5
G3	(M28)	B/2	Footwell lamp (Passenger side)	F1	(M56)	G/12	Joint connector-6
F3	(M29)	W/4	Fan control amp.	B4	(M57)	G/12	Joint connector-7
F2	(M30)	W/8	Intake door motor	B3	(M58)	L/12	Joint connector-8
				A4	(M59)	B/12	Joint connector-9
				D1	(M60)	W/6	Joint connector-10
				E2	(M61)	GY/6	Joint connector-11
				E2	(M62)	W/6	Joint connector-12




★ : Be sure to connect and securely lock connectors after the repairs.
 Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)

GI
 MA
 EV
 LC
 EC
 FE
 AT
 PD
 FA
 RA
 BR
 ST
 BS
 BT
 HA
 EL
 IX

HARNESS LAYOUT

Engine Control Harness



Engine control harness

C1★	F1	GY/6	: To	E14
C1★	F2	GY/8	: To	E13
C1★	F3	GY/8	: To	E12
D1	F4	B/8	: To	E11
D1	F5	GY/6	: Front wiper motor	
E1	F6	GY/1	: Check connector	
D1	F7	B/8	: ABS relay unit	
C2	F8	B/6	: ABS actuator	
C1	F9	L/4	: Air conditioner relay	
C2	F11	GY/2	: Front wheel sensor RH	
D2★	F12	GY/3	: Front heated oxygen sensor RH	
D2★	F13	GY/3	: Intake valve timing control position sensor RH	
D2★	F14	GY/8	: To	F131
C2★	F15	GY/3	: Ignition coil (With power transistor No.8)	
C2★	F16	GY/3	: Ignition coil (With power transistor No.6)	
C2★	F17	GY/3	: Ignition coil (With power transistor No.4)	
C2★	F18	GY/3	: Ignition coil (With power transistor No.2)	
E1★	F20	B/2	: EGR valve & EVAP canister purge control solenoid valve	
E1★	F21	GY/4	: To	F121
D4	F22	GY/6	: To	F101
D2	F23	GY/2	: Condenser	
C3★	F24	-	: Engine ground	
C4★	F25	-	: Engine ground	
C3★	F26	GY/8	: To	F106
C3★	F27	B/2	: Intake valve timing control solenoid valve RH	
C3★	F28	B/1	: Thermal transmitter	
C3★	F29	B/2	: Intake valve timing control solenoid valve LH	
D3★	F30	GY/6	: IACV-AAC valve	
D4★	F31	GY/4	: Camshaft position sensor	
E4★	F32	GY/3	: Mass air flow sensor	
E4★	F33	GY/2	: Intake air temperature sensor	
E4★	F34	GY/3	: Ignition coil (With power transistor No.1)	
F3★	F35	GY/3	: Ignition coil (With power transistor No.3)	
E4	F36	PU/2	: IACV-FICD solenoid valve	
F3★	F37	BR/3	: Secondary throttle position sensor	
F4★	F38	GY/4	: Throttle position switch	
F3★	F39	B/4	: Throttle position switch	
F3★	F40	GY/3	: Ignition coil (With power transistor No.7)	
F3★	F41	GY/3	: Ignition coil (With power transistor No.5)	
F3	F42	B/2	: Throttle motor	
F2★	F43	GY/2	: EGR temperature sensor	
F2★	F44	GY/3	: Intake valve timing control position sensor LH	
F2★	F45	GY/3	: Front heated oxygen sensor LH	

B4★	F61	W/1	: To	F62
B4★	F62	W/1	: To	F61
A4★	F63	W/48	: To	M49
B4	F64	W/30	: To	B102
A4	F65	GY/2	: Resistor	
B4★	F66	L/4	: ECCS relay	
B5★	F67	L/4	: Fuel pump relay	
B5	F68	L/4	: Throttle motor relay	
A5★	F69	SMJ	: ECM (ECCS control module)	
B5	F70	L/4	: Fog lamp relay	
A5	F74	B/16	: TAC module	
A5★	F75	B/20	: TAC module	
B5	F76	-	: Body ground	

Engine control sub-harness-1

D4	F101	GY/6	: To	F22
E3	F102	B/2	: Injector No.1	
E3	F103	B/2	: Injector No.3	
F3	F104	B/2	: Injector No.5	
F2	F105	B/2	: Injector No.7	
C2★	F106	GY/8	: To	F26
C3★	F107	B/2	: Injector No.2	
D2★	F108	B/2	: Injector No.4	
E3★	F109	B/2	: Injector No.6	
D3★	F110	GY/2	: Engine coolant temperature sensor	
E1★	F111	B/2	: Injector No.8	

Engine control sub-harness-2

E1★	F121	GY/4	: To	F21
E2★	F122	B/2	: Knock sensor LH	
F1★	F123	B/2	: Knock sensor RH	

Engine control sub-harness-3


D1★	F131	GY/8	: To	F14
E1★	F132	GY/2	: Crankshaft position sensor (OBD)	
F1★	F133	GY/4	: Rear heated oxygen sensor RH	

★ : Be sure to connect and securely lock connectors after the repairs.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)

EL
 HA
 BT
 RS
 ST
 BR
 RA
 FA
 PD
 AT
 FE
 EC
 LG
 EM
 MA
 GI

HARNESS LAYOUT

Body Harness and Tail Harness



HARNES LAYOUT

Body Harness and Tail Harness (Cont'd)

Body harness


B2★	(B1)	W/16	: Fuse block (J/B)
B2	(B2)	W/6	: Fuse block (J/B)
B3★	(B3)	SMJ	: To (M4)
A2	(B4)	B/6	: To (M3)
A3	(B5)	W/2	: Circuit breaker-1
A2	(B6)	W/2	: Circuit breaker-2
A3	(B7)	L/4	: Door mirror defogger relay
A2	(B8)	BR/6	: Rear window defogger relay
A4★	(B9)	SMJ	: A/T control unit
B4★	(B10)	W/2	: Diode
B4★	(B11)	W/2	: Diode
C3	(B12)	W/8	: Driver's seat control unit (LCU05)
D3	(B13)	B/2	: Front power socket
C2	(B14)	W/6	: Telephone switch
C3	(B15)	W/12	: Handset
C3	(B16)	L/4	: Heated seat switch (Driver's side)
B2★	(B17)	GY/3	: Revolution sensor
C2★	(B18)	BR/8	: A/T solenoid valve
C2★	(B19)	GY/8	: Inhibitor switch
B2★	(B20)	GY/2	: Vehicle speed sensor
C2★	(B21)	BR/3	: Turbine revolution sensor
B4	(B22)	-	: Body ground
B4	(B23)	BR/1	: Front door switch (Driver's side)
C4	(B24)	BR/4	: Seat belt pre-tensioner (Driver's side)
B3	(B25)	W/18	: To (D41)
D3★	(B26)	GY/16	: To (B11)
D3	(B27)	W/2	: Condenser
E3	(B28)	W/4	: Rear speaker LH
E2★	(B29)	W/6	: Fuel pump, Fuel tank gauge unit
E3	(B30)	GY/26	: BOSE speaker amp.
E4	(B31)	B/4	: Receiver
E4	(B32)	W/16	: Receiver
E4	(B33)	B/6	: Receiver
D4	(B34)	W/6	: Power antenna timer and motor
D4	(B35)	-	: Body ground

D3	(B36)	W/12	: To (T1)
D4★	(B37)	W/4	: Fuel pump control module (FPCM)
A3★	(B38)	GY/6	: Joint connector-16
C3	(B39)	W/4	: Heated seat switch (Passenger side)


Tail harness

E3	(T1)	W/12	: To (B36)
F4	(T2)	W/4	: Rear combination lamp LH (Trunk lid)
F3★	(T3)	W/2	: License lamp LH
F3	(T4)	W/2	: High-mounted stop lamp (Models with rear air spoiler)
F3	(T5)	B/2	: Trunk lid opener actuator
F3	(T6)	W/2	: License lamp RH
G3	(T7)	W/4	: Rear combination lamp RH (Trunk lid)
G3	(T8)	W/3	: Trunk lid key cylinder switch (Unlock switch)
E4	(T9)	W/4	: Rear combination lamp LH (Fender)
G4	(T10)	W/12	: Stop and Tail lamp sensor
F4	(T11)	W/2	: Trunk room lamp switch
F4	(T12)	-	: Body ground
G3	(T13)	W/4	: Rear combination lamp RH (Fender)

(B10) : Diode



(B11) : Diode




★ : Be sure to connect and securely lock connectors after the repairs.
Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)

EL
 IDX
 HA
 BT
 EC
 ST
 BR
 RA
 FA
 PD
 AT
 FE
 EC
 LC
 EW
 MA
 GI

HARNESS LAYOUT

Body No. 2 Harness



HARNESS LAYOUT


Body No. 2 Harness (Cont'd)

Body No.2 harness

- G3 (B101) W/48 : To (M50)
- F3 (B102) W/30 : To (F64)
- F3 (B103) SMJ : ABS/TCS control unit
- E4 (B104) W/6 : Power seat switch (Passenger side)
- F4* (B105) - : Body ground
- F4 (B106) W/18 : To (D61)
- F4 (B107) BR/1 : Front door switch (Passenger side)
- E4 (B108) BR/4 : Seat belt pre-tensioner (Passenger side)
- D3 (B109) B/1 : Condenser (Rear window defogger)
- C3 (B110) W/4 : Rear speaker RH
- A3* (B111) GY/16 : To (B26)
- C4 (B112) GY/4 : Rear wheel sensor
- D3 (B113) W/2 : Diode
- D3 (B114) L/4 : Fuel lid opener relay
- C3 (B115) BR/6 : Multi-remote control relay
- D3 (B116) L/4 : Audio amp. relay
- C3 (B117) BR/6 : Theft warning horn relay
- D5* (B118) - : Body ground
- C4 (B119) BR/2 : Fuel lid opener actuator
- B3 (B120) GY/4 : To (B151)
- D4* (B121) W/2 : Dropping resistor
- C4 (B122) W/16 : CD auto changer
- E5* (B123) GY/6 : Joint connector-17
- B2 (B124) B/1 : Rear window defogger (Ground cable)

Body No.2 sub-harness

- B3 (B151) GY/4 : To (B120)
- B3 (B152) W/2 : High-mounted stop lamp (Models with rear air spoiler)
- B4 (B153) W/2 : Trunk room lamp




★ : Be sure to connect and securely lock connectors after the repairs. Failure to do so may cause the on-board diagnostic system to light up the MIL as an open circuit detection. (Refer to EC section.)


EL
 FA
 BT
 RS
 ST
 BR
 RA
 FA
 PD
 AT
 FE
 EC
 LC
 EM
 MA
 GI

HARNESS LAYOUT


Engine Harness



Engine ground




★ E101	GY/8	:	To	E21
★ E102	B/6	:	To	E19
E103	GY/1	:	To	E20
E104	-	:	Fuse, fusible link and relay box	
E105	-	:	Engine ground	
E106	GY/2	:	Power steering oil pressure switch	
E107	-	:	Alternator	
★ E108	GY/4	:	Alternator	
E109	-	:	Fusible link box (Battery (+))	
E110	-	:	Fusible link box (F/L)	
E111	-	:	Fuse, fusible link and relay box	
E112	-	:	Body ground	
E113	BR/2	:	Power steering solenoid valve	
E114	B/1	:	Compressor	
E115	B/1	:	Oil pressure switch	
E116	GY/1	:	Starter motor	
E117	-	:	Starter motor	
E118	GY/2	:	Inhibitor switch	
★ E119	GY/4	:	Rear heated oxygen sensor LH	



Body ground

HARNES LAYOUT

Room Lamp Harness




- (R1) W/18 : To (M15)
- (R2) W/2 : Vanity mirror lamp (Driver's side)
- (R3) W/1 : To sunroof harness
- (R4) W/4 : Auto anti-dazzling inside mirror
- (R5) W/8 : Interior lamp
- (R6) W/2 : Vanity mirror lamp (Passenger side)
- (R7) W/6 : Rear personal lamp LH
- (R8) W/6 : Rear personal lamp RH

- GT
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- FA
- EL**
- IDX

HARNESS LAYOUT

Air Bag Harness




HARNESS LAYOUT

DRIVER'S SIDE

Front Door Harness

- (D1)** W/40 : To **(M11)**
- (D2)** BR/3 : Door mirror actuator (Driver's side)
- (D3)** GY/2 : Door mirror defogger (Driver's side)
- (D4)** W/8 : Seat memory switch
- (D5)** BR/2 : Tweeter LH
- (D6)** BR/3 : Front door key cylinder switch (Driver's side)
- (D7)** GY/4 : Front door lock actuator (Driver's side)
- (D8)** W/2 : Front step lamp (Driver's side)
- (D9)** B/2 : Front power window regulator (Driver's side)
- (D10)** W/10 : Door mirror remote control switch
- (D11)** W/3 : Trunk lid and fuel lid opener switch
- (D12)** W/2 : Front power window main switch illumination
- (D13)** W/18 : Driver's door control unit (LCU01)
- (D14)** BR/2 : Front door speaker LH



CEL456


GI
MA
EM
LC
EC
FE
AT
PD
FA
RA

BR
ST
RS
BT

HA
EL
IDX

PASSENGER SIDE

- (D21)** W/40 : To **(M48)**
- (D22)** BR/3 : Door mirror actuator (Passenger side)
- (D23)** GY/2 : Door mirror defogger (Passenger side)
- (D24)** BR/2 : Tweeter RH
- (D25)** BR/3 : Front door key cylinder switch (Passenger side)
- (D26)** GY/4 : Front door lock actuator (Passenger side)
- (D27)** W/2 : Front step lamp (Passenger side)
- (D28)** B/2 : Front power window regulator (Passenger side)
- (D29)** W/18 : Passenger door control unit (LCU02)
- (D30)** BR/2 : Front door speaker RH




CEL457


HARNESS LAYOUT

LH SIDE

Rear Door Harness




RH SIDE



SPLICE LOCATION

How to Read Splice Location

- "GT2", "T4" etc., which are shown in the wiring diagram, refer to wiring harness splice points. These points are located in shaded areas "GB2", "T4", etc. in illustrations under the title "SPLICE LOCATION".
- Wiring harness splice points are subject to change without prior notice.




GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

CEL460


SPLICE LOCATION

Engine Room Harness



SPLICE LOCATION


Engine Room Harness (Cont'd)



- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX


SPLICE LOCATION

Main Harness



SPLICE LOCATION


Instrument Harness



- GI
- MA
- EM
- LC
- EC
- FE
- AT
- PD
- FA
- RA
- BR
- ST
- RS
- BT
- HA
- EL**
- IDX


SPLICE LOCATION

Engine Control Harness



SPLICE LOCATION

Engine Harness



GI

MA

EM

LC

EC

FE

AT

PD

FA

RA

BR

ST

RS

BT


HA

EL

IDX


SPLICE LOCATION

Body Harness and Tail Harness



SPLICE LOCATION

Body No. 2 Harness



GI
MA
EM
LC
EC
FE
AT
PD
FA
RA
BR
ST
RS
BT
HA
EL
IDX

SPLICE LOCATION

Room Lamp Harness

