

A
B
C
D
E
F
G
H
I
J
K
L
M

WW

SECTION

WIPER, WASHER & HORN

CONTENTS

| | |
|--|--|
| <p>PRECAUTION 2</p> <p>Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 2</p> <p>Wiring Diagrams and Trouble Diagnosis 2</p> <p>FRONT WIPER AND WASHER SYSTEM 3</p> <p>Component Parts and Harness Connector Location... 3</p> <p>System Description 3</p> <p> WIPER OPERATION 3</p> <p> WASHER OPERATION 5</p> <p>Schematic 6</p> <p>Wiring Diagram — WIPER — 7</p> <p>Terminals and Reference Values for BCM 10</p> <p>Work Flow 10</p> <p>Preliminary Check 10</p> <p> SETTING CHANGE FUNCTIONS 10</p> <p> INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT 11</p> <p>CONSULT-II Function 11</p> <p> CONSULT-II BASIC OPERATION 12</p> <p> WORK SUPPORT 13</p> <p> DATA MONITOR 13</p> <p> ACTIVE TEST 13</p> <p>On Board Diagnosis 13</p> <p> DIAGNOSIS ITEM FOR FRONT WIPER AND WASHER SYSTEM 13</p> <p> SWITCH MONITOR 14</p> <p>Intermittent Wiper Does Not Operate 15</p> <p>Intermittent Time of Wiper Cannot be Adjusted 17</p> <p>Wiper and Washer Activate Individually but Not In Combination 17</p> <p>Intermittent Wiper Operates, but There Is No Change In Intermittent Time Between When Vehicle Is Stopped and Moving 18</p> <p>Wiper and Washer Activate Individually but Intermittent Wiper and Washer Combination Does Not Operate 19</p> <p>Removal and Installation of Front Wiper Arms, Adjustment of Front Wiper Arms Stop Location 20</p> <p>Removal and Installation of Front Wiper Motor and</p> | <p>Linkage 21</p> <p> REMOVAL 21</p> <p> INSTALLATION 21</p> <p>Washer Nozzle Adjustment 22</p> <p>Washer Tube Layout 22</p> <p>Removal and Installation of Washer Nozzle 23</p> <p> REMOVAL 23</p> <p> INSTALLATION 23</p> <p>Inspection of Washer Nozzle 23</p> <p> INSPECTION OF CHECK VALVE 23</p> <p>Wiper and Washer Switch Circuit Check 23</p> <p> INSPECTION OF SWITCH CIRCUIT 23</p> <p>Removal and Installation of Front Wiper and Washer Switch 23</p> <p> REMOVAL 23</p> <p> INSTALLATION 24</p> <p>Removal and Installation of Washer Tank 24</p> <p> REMOVAL 24</p> <p> INSTALLATION 24</p> <p>Removal and Installation for Washer Motor 25</p> <p> REMOVAL 25</p> <p> INSTALLATION 25</p> <p>CIGARETTE LIGHTER 26</p> <p> Wiring Diagram — CIGAR — 26</p> <p> Removal and Installation 27</p> <p> REMOVAL 27</p> <p> INSTALLATION 27</p> <p>POWER SOCKET 28</p> <p> Wiring Diagram — CIGAR — 28</p> <p> Removal and Installation 29</p> <p> REMOVAL 29</p> <p> INSTALLATION 29</p> <p>HORN 30</p> <p> Wiring Diagram — HORN — 30</p> <p> Removal and installation 31</p> <p> REMOVAL (HORN HI) 31</p> <p> INSTALLATION (HORN HI) 31</p> <p> REMOVAL (HORN LOW) 31</p> <p> INSTALLATION (HORN LOW) 31</p> |
|--|--|

PRECAUTION

PRECAUTION

PFP:00011

Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”

EKS00F5H

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Wiring Diagrams and Trouble Diagnosis

EKS0011Q

When you read wiring diagrams, refer to the followings:

- Refer to [GI-14, "How to Read Wiring Diagrams"](#) .
- Refer to [PG-2, "POWER SUPPLY ROUTING"](#) for power distribution circuit.

When you perform trouble diagnosis, refer to the followings:

- Refer to [GI-10, "HOW TO FOLLOW TEST GROUPS IN TROUBLE DIAGNOSES"](#) .
- Refer to [GI-26, "How to Perform Efficient Diagnosis for an Electrical Incident"](#) .


FRONT WIPER AND WASHER SYSTEM

FRONT WIPER AND WASHER SYSTEM

PFP:28810

Component Parts and Harness Connector Location

EKS00EXS



PKIA8799E

System Description

EKS00EXR

Through the adoption of vehicle speed detect-type intermittent wiper, Front Wiper System changes wiper's intermittent time when the engine is stopped and while driving.

Vehicle speed signal is sent from the combination meter to BCM. BCM controls intermittent activation time and coupled activation of washer and wiper.

WIPER OPERATION

Description

The wiper switch is controlled by a lever built into the combination switch. There are three wiper switch positions.

- LO speed
- HI speed
- INT (intermittent)

Power is supplied at all times

- through 10A fuse [No.3, located in the fuse block (J/B) No.1]
- to BCM terminal 105.

With the ignition switch in the ON or START position, power is supplied

- through 20A fuse [No.34, located in the fuse block (J/B) No.2]
- to front wiper motor terminal 4 and
- to front wiper relay terminal 1
- through 10A fuse [No.1, located in the fuse block (J/B) No.1]

A
B
C
D
E
F
G
H
I
J
L
M

FRONT WIPER AND WASHER SYSTEM

- to BCM terminal 68
- through 10A fuse [No.9, located in the fuse block (J/B) No.1]
- to combination meter terminal 59.

Ground is supplied to front wiper switch terminals 17 and 20 through grounds M25 and M115.

Low (MIST) and High Speed Wiper Operation

When the front wiper switch is placed in the LO or MIST position, ground is supplied

- through front wiper switch terminal 14
- to front wiper motor terminal 6.

With power and ground supplied, the front wiper motor operates at low speed.

When the front wiper switch is placed in the HI position, ground is supplied

- through front wiper switch terminal 16
- to front wiper motor terminal 5.

With power and ground supplied, the front wiper motor operates at high speed.

Auto Stop Operation

When the front wiper switch is placed in the OFF position, the front wiper motor will continue to operate until the wiper arms reach the base of the windshield (Auto stop). When the front wiper switch is placed in the OFF position, ground is supplied

- from front wiper switch terminal 14
- to front wiper motor terminal 6, in order to continue front wiper motor operation at low speed.

Ground is also supplied until the wiper arms reaches the base of the windshield

- through front wiper switch terminal 13
- to front wiper relay terminal 3
- through front wiper relay terminal 4
- to front wiper motor terminal 3
- through front wiper motor terminal 1, and
- through grounds E42 and E62.

When the wiper arms reach the base of the windshield, the switch in the front wiper motor moves to the "STOP" position. The ground path is interrupted and the front wiper motor stops.

Intermittent Operation

Intermittent operation is controlled by the BCM. When the front wiper switch is placed in the INT position, ground is supplied

- to BCM terminal 9
- from front wiper switch terminal 15
- through grounds M25 and M115.

The desired interval time is input

- to front wiper switch terminal 19
- from BCM terminal 48
- to BCM terminal 49
- from combination meter terminal 18 (vehicle speed pulse).

The desired interval time is input

- to front wiper relay terminal 2
- from BCM terminal 128.

With power and ground supplied, the front wiper relay is activated. When activated, an intermittent ground is supplied

- to front wiper motor terminal 6
- through front wiper switch terminal 14
- to front wiper switch terminal 13
- through front wiper relay terminal 3
- to front wiper relay terminal 5

FRONT WIPER AND WASHER SYSTEM

- through grounds E24 and E44.

Front wiper motor operates at desired interval with BCM terminal 9 grounded. Intermittent operation can be adjusted from:

- Approx. 0.9 - 45sec. (when vehicle is stopped)
- Approx. 0.4 - 30 sec. (when vehicle is moving)

Judgement on vehicle stopped or moving:

- Stopped → Moving: More than 5 km/h (3 MPH)
- Moving → Stopped: Less than 2 km/h (1 MPH)

WASHER OPERATION

With the ignition switch in the ON or START position, power is supplied

- through 20A fuse [No. 34, located in the fuse block (J/B) No. 2]
- to front washer motor terminal 1.

When the lever is pulled to the WASH position, ground is supplied

- to front washer motor terminal 2, and
- to BCM terminal 4
- from front wiper switch terminal 18
- through front wiper switch terminal 17
- through grounds M25 and M115.

With power and ground supplied, the front washer motor operates. The front wiper motor operates at low speed for about 3 seconds. This feature is controlled by the BCM in the same manner as the intermittent operation.

A

B

C

D

E

F

G

H

I

J





WW

L

M

FRONT WIPER AND WASHER SYSTEM

WW-WIPER-03



REFER TO THE FOLLOWING.

(M1) - FUSE BLOCK-JUNCTION BOX (J/B) NO.1

(M4) - ELECTRICAL UNITS

A
B
C
D
E
F
G
H
I
J
L
M



WW

TKWM0432E

FRONT WIPER AND WASHER SYSTEM

Terminals and Reference Values for BCM

EKS00EXV

| Terminal No. | Wire color | Item | Condition | | Reference value | |
|--------------|------------|------------------------------------|-----------------|--|--|-----------------|
| | | | Ignition switch | Operation or condition | | |
| 4 | P | Washer switch signal | ON | Front wiper switch | WASH | Approx. 0V |
| | | | | | OFF | Battery voltage |
| 9 | OR | Front wiper switch INT signal | ON | Front wiper switch | INT | Approx. 0V |
| | | | | | OFF | Approx. 8V |
| 48 | G/OR | Intermittent wiper volume signal | ON | Wiper intermittent interval | Long | Approx. 3.6V |
| | | | | | Short | Approx. 0V |
| 49 | PU/W | Vehicle speed signal (2-pulse) | ON | Vehicle speed approx. 40 km/h |  ELF1080D | |
| 56 | B | Ground | ON | — | Approx. 0V | |
| 68 | W/B | ignition on signal | ON | — | Battery voltage | |
| 105 | Y/L | Battery power supply | OFF | — | Battery voltage | |
| 113 | B | Ground | ON | — | Approx. 0V | |
| 124 | SB | Front wiper auto stop signal | ON | Front wiper is moving. | Approx. 0V | |
| | | | | Front wiper is stopped. | Battery voltage | |
| 128 | R/Y | Front wiper motor operation signal | ON | Front wiper switch: INT position (Wiper dial position 4) |  PKIA6250E | |

Work Flow

EKS00EXW

1. Confirm the symptom or customer complaint.
2. Understand the system description. Refer to [WW-3, "System Description"](#) .
3. Perform preliminary Check. Refer to [WW-10, "Preliminary Check"](#) .
4. According to the trouble diagnosis chart, repair or replace the cause of the malfunction.
5. Does wiper function operate normally? If it operates normally, GO TO 6. If not, GO TO 4.
6. INSPECTION END

Preliminary Check

EKS00EXX

SETTING CHANGE FUNCTIONS

- With CONSULT-II, each function can be changed in setting, refer to [WW-13, "WORK SUPPORT"](#) .

CAUTION:

After the setting was changed, the new setting will be maintained even if the battery was disconnected.

| Setting change mode | CONSULT-II (WORK SUPPORT) | Description |
|---|---------------------------|-------------|
| Wiper intermittent speed control by vehicle speed | ON | Activated |
| | OFF | Inactivated |

FRONT WIPER AND WASHER SYSTEM

INSPECTION FOR POWER SUPPLY AND GROUND CIRCUIT

1. CHECK FUSE

Check if any of the following fuses in BCM are blown.

| Unit | Power source | Fuse No. |
|------|-----------------------------|----------|
| BCM | Battery | 3 |
| | Ignition switch ON or START | 1 |

Refer to [WW-7. "Wiring Diagram — WIPER —"](#) .

OK or NG


OK >> GO TO 2.

NG >> If fuse is blown, be sure to eliminate cause of malfunction before installing new fuse. Refer to [PG-2. "POWER SUPPLY ROUTING"](#) .

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector.
2. Check voltage between BCM harness connector terminals and ground.

| Terminals | | (-) | Ignition switch position | | |
|-----------|------------------------|--------|--------------------------|-----------------|-----------------|
| (+) | | | OFF | ACC | ON |
| Connector | Terminals (Wire color) | | Battery voltage | Battery voltage | Battery voltage |
| M4 | 105 (Y/L) | Ground | Battery voltage | Battery voltage | Battery voltage |
| | 68 (W/B) | | 0V | 0V | Battery voltage |



OK or NG


OK >> GO TO 3.

NG >> Check harness for open or short power supply circuit.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between BCM harness connector terminals and ground.

| Terminals | | Continuity |
|-----------|-----------------------|---------------|
| Connector | Terminal (Wire color) | |
| BCM (M4) | 56 (B) | Ground Yes |
| | 113 (B) | |



OK or NG

OK >> INSPECTION END

NG >> Repair harness.

CONSULT-II Function

EKS00EXY


- CONSULT-II executes the following functions by combining data received and command transmitted via the communication line from BCM. IVMS communication inspection, work support by part, self-diagnosis, data monitor, and active test display.

FRONT WIPER AND WASHER SYSTEM


| IVMS diagnosis part | Check item and diagnosis mode | Description |
|---------------------|-------------------------------|---|
| WIPER | WORK SUPPORT | Changes the setting for each function. |
| | DATA MONITOR | Displays data relative to BCM input signals and various control related data for each system. |
| | ACTIVE TEST | Device operation can be checked by applying a drive signal to device. |
| BCM PART NUMBER. | | Displays BCM part No. |

CONSULT-II BASIC OPERATION


- With ignition switch OFF, connect "CONSULT-II" and "CONSULT-II CONVERTER" to data link connector, and turn ignition switch ON.




- Touch "START (NISSAN BASED VHCL)".



- Touch "IVMS".
If "IVMS" is not indicated, refer to [GI-38, "CONSULT-II Data Link Connector \(DLC\) Circuit"](#).



- Check the model specification, and touch either "WITH SUNROOF" or "WITHOUT SUNROOF" on "SELECT SYS COND" SCREEN.
- Touch "OK". If the selection is wrong, touch "CANCEL".
- Select the desired part to be diagnosed on "SELECT TEST ITEM" screen.



FRONT WIPER AND WASHER SYSTEM

WORK SUPPORT

Operation Procedure

1. Touch "WIPER" on "SELECT TEST ITEM" screen.
2. Touch "WORK SUPPORT" on "SELECT DIAG MODE" screen.
3. Touch "WIP INT VHCL SPD ADJ" on "SELECT WORK ITEM" screen.
4. Touch "START".
 - Wiper intermittent speed control by vehicle speed can be canceled or resumed.
5. Touch "CURRENT SETTING" for changing "CURRENT SETTING".
For no changing "CURRENT SETTING", touch "END".

| "CURRENT SETTING" | Wiper intermittent speed control |
|-------------------|----------------------------------|
| "ON" | Activated |
| "OFF" | Inactivated |

6. Touch "END" after customizing is completed.

DATA MONITOR

Operation Procedure

1. Touch "WIPER" on the "SELECT TEST ITEM" screen
2. Touch "DATA MONITOR" on the "SELECT DIAG MODE" screen.
3. Touch either "ALL SIGNALS" or "SELECTION FROM MENU" on the "DATA MONITOR" screen.
4. Touch "START".

Date Monitor Item

| Monitored item | Description |
|----------------|---|
| IGN ON SW | Indicates "IGN [ON] / ACC or OFF [OFF]" condition of ignition switch signal. |
| INT SW | Indicates " INT position [ON] / Others [OFF]" condition of front wiper switch signal. |
| WASH SW | Indicates "WASH position [ON] / Others [OFF]" condition of front wiper switch signal. |
| VHCL SPEED SE | Indicates "Vehicle is moving [RUN] / Vehicle stopped [STOP]" condition of vehicle speed signal. |
| WIPR AUTO STP | Indicates "INT or OFF position [IGN] / LO or HI position [OFF]" condition of front wiper switch signal. |
| INTRESIST | Indicates " Intermittent resistance value [approx. 0 to 1]" condition front wiper switch signal. |

ACTIVE TEST

Operation Procedure

1. Touch "WIPER" on "SELECT TEST ITEM" screen.
2. Touch "ACTIVE TEST" on "SELECT DIAG MODE" screen.
3. Touch the item to be tested, and check the operation.

| Test item "WIPER AMP" | Front wiper motor operation |
|-----------------------|-----------------------------|
| "ON" | Operate |
| "OFF" | Stop |

4. During the operation check, touching "OFF" deactivates the operation.

On Board Diagnosis

EKS00EXZ

- IVMS can check communication diagnosis, switch monitor, and central locking system self diagnosis using on board diagnosis.
- Map lamps and step lamps (all seats) act as the indicators for on board diagnosis.


DIAGNOSIS ITEM FOR FRONT WIPER AND WASHER SYSTEM

| Diagnosis item | Description |
|----------------|---------------------------------------|
| Switch monitor | It can check wiper and washer switch. |

FRONT WIPER AND WASHER SYSTEM


SWITCH MONITOR

How to Perform Switch Monitor



Diagnosis Result Display

- Detects the status change (switch ON/OFF operation) of switch to be checked, and turns on/off indicator lamps (the map lamp and step lamp). Also sounds the buzzer for 0.5 seconds.
- If a malfunction is detected, no indicator lamp and buzzer react.



Cancel of Switch Monitor

- Ignition switch is turned OFF.
- Drive the vehicle at more than 7 km/h (4MPH).

FRONT WIPER AND WASHER SYSTEM

EKS00EY0

Intermittent Wiper Does Not Operate

1. CHECK INTERMITTENT FRONT WIPER SWITCH INPUT SIGNAL

☑ With CONSULT-II
See "INT SW" in "DATA MONITOR" mode.

When front wiper switch is in INT position : INT SW ON

When front wiper switch is in OFF position : INT SW OFF

NOTE:

When "Data monitor" is operating, intermittent wiper does not operate.


⊗ Without CONSULT-II
Check front wiper switch (INT) in switch monitor mode. Refer to [WW-14. "SWITCH MONITOR"](#).

OK or NG

OK >> GO TO 2.

NG >> Check the following.

- Front wiper switch
- Harness for open or short between BCM and front wiper switch
- Front wiper switch ground circuit




2. CHECK WIPER AUTO STOP SIGNAL

☑ With CONSULT-II
See "WIPR AUTO STP" in "DATA MONITOR" mode, and turn front wiper switch to LO or HI position.

When front wiper switch is in INT or OFF position : WIPER AUTO STP IGN

When front wiper switch is in LO or HI : WIPER AUTO STP GND



⊗ Without CONSULT-II

1. Turn ignition switch ON.
2. Turn front wiper switch to LO or HI position.
3. Check voltage between BCM harness connector terminal and ground.


| Terminals | | | Condition | Voltage |
|-----------|-----------------------|--------|-----------|-----------------|
| BCM (+) | | (-) | | |
| Connector | Terminal (Wire color) | | | |
| E204 | 124 (SB) | Ground | Moving | Approx. 0V |
| | | | Stopped | Battery voltage |

OK or NG

OK >> GO TO 3.

NG >> Check the following.

- Front wiper motor
- Front wiper motor ground circuit
- Harness for open or short between BCM and front wiper motor




FRONT WIPER AND WASHER SYSTEM

3. CHECK IGNITION SWITCH ON SIGNAL


① With CONSULT-II
See "IGN ON SW" in "DATA MONITOR" mode.

When ignition switch is ON : IGN ON SW ON
When ignition switch is ACC or OFF : IGN ON SW OFF



⊗ Without CONSULT-II
Check voltage between BCM harness connector M4 terminal 68 (W/B) and ground.

Ignition switch is ON : Battery voltage should exist.
Ignition switch is ACC or OFF : Approx. 0V



OK or NG

- OK >> GO TO 4.
NG >> Check the following.
- 10A fuse [No. 1, located in fuse block (J/B) No. 1]
 - Harness for open or short between fuse and BCM

4. CHECK WIPER OPERATION

① With CONSULT-II
See "WIPER AMP" in "ACTIVE TEST" mode. Perform operation shown on display.


Front wiper motor should operate.

NOTE:

If CONSULT-II is not available, skip this procedure and go to [WW-19, "Wiper and Washer Activate Individually but Intermittent Wiper and Washer Combination Does Not Operate"](#).

OK or NG

- OK >> Replace BCM.
NG >> Go to [WW-19, "Wiper and Washer Activate Individually but Intermittent Wiper and Washer Combination Does Not Operate"](#).



FRONT WIPER AND WASHER SYSTEM

Intermittent Time of Wiper Cannot be Adjusted

EKS00EY1

1. CHECK INTERMITTENT WIPER VOLUME INPUT SIGNAL

④ With CONSULT-II

See "INT RESIST" in "DATA MONITOR" mode while turning intermittent wiper volume.

Short interval : Approx. 0 kohm

Long interval : Approx. 1 kohm

| DATA MONITOR | |
|--------------|----------|
| MONITOR | |
| INT RESIST | XXX kohm |
| RECORD | |


SEL506W

⊗ Without CONSULT-II

1. Turn ignition switch OFF.
2. Disconnect the BCM connector.
3. Measure resistance between BCM harness connector M4 terminal 48 (G/OR) and ground while turning intermittent wiper volume.

Short interval : Approx. 0 KΩ

Long interval : Approx. 1 KΩ



OK or NG

OK >> Replace BCM.

NG >> GO TO 2.

2. CHECK FRONT WIPER SWITCH

Check front wiper switch. Refer to [WW-23, "Wiper and Washer Switch Circuit Check"](#).

OK or NG

OK >> Check the following.

- Harness for open or short between BCM and intermittent wiper volume
- Front wiper switch ground circuit

NG >> Replace front wiper switch.

Wiper and Washer Activate Individually but Not In Combination

EKS00EY2

1. CHECK WASHER SWITCH INPUT SIGNAL

④ With CONSULT-II

See "WASH SW" in "DATA MONITOR" mode.

When front washer switch is ON : WASH SW ON

When front washer switch is OFF : WASH SW OFF

⊗ Without CONSULT-II

Check front wiper switch (WASH) in switch monitor mode. Refer to [WW-14, "SWITCH MONITOR"](#).

OK or NG

OK >> Replace BCM.

NG >> Check harness for open or short between BCM and front wiper switch.

| DATA MONITOR | |
|--------------|-----|
| MONITOR | |
| WASH SW | OFF |
| RECORD | |

SEL507W

FRONT WIPER AND WASHER SYSTEM

Intermittent Wiper Operates, but There Is No Change In Intermittent Time Between When Vehicle Is Stopped and Moving

EKS00EY3

1. CHECK THE SYMPTOM

Check that speedometer in combination meter operates normally.

OK or NG

OK >> GO TO 2.


NG >> Check the vehicle speed signal. Refer to [DI-15, "Diagnosis Flow"](#) in DI section.

2. FUNCTIONAL INSPECTION

① With CONSULT-II

With "VHCL SPEED SE" on DATA MONITOR, check the vehicle speed signal. Refer to [WW-13, "DATA MONITOR"](#).

| Monitor item [OPERATION or UNIT] | Contents |
|----------------------------------|---|
| VHCL SPEED SE "<7km/>7km" | The present vehicle speed (less than 7 km/h (4 MPH), or 7 km/h (4 MPH) or higher) is displayed. |



② Without CONSULT-II

GO TO 3.

OK or NG

OK >> System is OK.

NG >> GO TO 3.

3. VEHICLE SPEED INPUT/OUTPUT INSPECTION

Start the engine, and check voltage between BCM harness connector M4 terminal 49 (PU/W) and ground, using an oscilloscope.


Voltage waveform

[When vehicle speed is approx. 40km/h (25MPH)]

OK or NG

OK >> Replace BCM.

NG >> GO TO 4.



FRONT WIPER AND WASHER SYSTEM


4. HARNESS CONTINUITY INSPECTION

1. Turn ignition switch OFF.
2. Disconnect BCM connectors and combination meter connector.
3. Check continuity between BCM harness connector M4 terminal 49 (PU/W) and combination meter harness connector M41 terminal 18 (PU/W).

49 (PU/W) - 18 (PU/W) : Continuity should exist.

4. Check continuity between BCM harness connector M4 terminal 49 (PU/W) and ground.

49 (PU/W) - Ground : Continuity should not exist.



OK or NG

- OK >> Replace combination meter.
NG >> Repair harness or connector.


Wiper and Washer Activate Individually but Intermittent Wiper and Washer Combination Does Not Operate

EKS00EY4

1. CHECK POWER SUPPLY CIRCUIT FOR FRONT WIPER RELAY

1. Turn ignition switch OFF.
2. Remove front wiper relay.
3. Turn ignition switch ON.
4. Check voltage between front wiper relay harness connector E4 terminal 1 (LG) and ground.

1 (LG) - Ground : Battery voltage should exist.




OK or NG

- OK >> GO TO 2.
NG >> Check the following.
- 20A fuse [No. 34, located in fuse block (J/B) No.2]
 - Harness for open or short between front wiper relay and fuse

2. CHECK GROUND CIRCUIT FOR FRONT WIPER RELAY

1. Turn ignition switch OFF.
2. Check continuity between front wiper relay harness connector E4 terminal 5 (B) and ground.

5 (B) - Ground : Continuity should exist.



OK or NG

- OK >> GO TO 3.
NG >> Repair harness ground circuit.

FRONT WIPER AND WASHER SYSTEM


3. CHECK FRONT WIPER RELAY

Apply battery voltage to between front wiper relay terminal 1 and 2 and check continuity between terminal 3 and 5.

3 - 5 : Continuity should exist.

OK or NG

- OK >> GO TO 4.
- NG >> Replace the front wiper relay.




4. CHECK BCM OUTPUT SIGNAL

1. Connect front wiper relay.
2. Turn ignition switch ON.
3. Check voltage between BCM harness connector E204 terminal 128 (R/Y) and ground.

Wash : Approx. 0V (for 0.7sec.)
OFF : Battery voltage should exist.

OK or NG

- OK >> Repair harness between front wiper relay and BCM.
- NG >> Replace the BCM.



Removal and Installation of Front Wiper Arms, Adjustment of Front Wiper Arms Stop Location

EKS00EY5

1. Prior to wiper arm installation, turn on front wiper switch to operate front wiper motor and then turn it "OFF" (Auto stop).
2. Lift the blade up and then set it down onto glass surface to set the blade center to clearance "L1" and "L2" immediately before tightening nut.
3. Eject washer fluid. Turn on front wiper switch to operate front wiper motor and then turn it "OFF".
4. Ensure that wiper blades stop within clearance "L1" and "L2".



Clearance "L1" : 32.5 - 47.5 mm (1.280 - 1.870 in)

Clearance "L2" : 24.5 - 39.5 mm (0.965 - 1.555 in)

- Tighten wiper arm nuts to specified torque.

Front wiper arm mounting nuts : 23.6 N-m (2.4 kg-m, 17 ft-lb)


- Before reinstalling wiper arm, clean up the pivot area as illustrated. This will reduce possibility of wiper arm looseness.



FRONT WIPER AND WASHER SYSTEM

Removal and Installation of Front Wiper Motor and Linkage


EKS00EY6



1. Wiper link
2. Wiper link
3. Wiper frame
4. Front wiper motor

REMOVAL

1. Operate front wiper motor, and stop it at the auto stop position.
2. Remove wiper arm from the vehicle.
3. Remove cowl top cover. Refer to [EI-20, "COWL TOP"](#) .
4. Disconnect front wiper motor connector.
5. Remove bracket and front wiper motor assembly.
6. Remove wiper link from wiper frame.
7. Remove front wiper motor from wiper frame.



INSTALLATION

1. Connect front wiper motor to connector. Turn front wiper switch ON to operate front wiper motor, and then turn front wiper switch OFF (auto stop).
2. Disconnect front wiper motor connector.
3. Install front wiper motor to wiper frame.
4. Install wiper link to wiper frame and motor arm.
5. Install front wiper motor assembly to the vehicle.
6. Connect front wiper motor connector. Turn front wiper switch ON to operate front wiper motor, and then turn front wiper switch OFF (auto stop).
7. Install bracket to the vehicle.
8. Install cowl top cover. Refer to [EI-20, "COWL TOP"](#) .
9. Install wiper arm.

CAUTION:

- Do not drop front wiper motor or cause it to contact other parts.

A
B
C
D
E
F
G
H
I
J
L
M

WW

FRONT WIPER AND WASHER SYSTEM


- Check the grease conditions of motor arm and wiper link joint (at retainer). Apply grease if necessary.

Washer Nozzle Adjustment

EKS00GCF


- Adjust washer nozzle with suitable tool as shown in the figure at left.

Adjustable range : $\pm 10^\circ$




Unit: mm (in)

| Spray position | H (height) | L (length) | h (spray point area) |
|----------------|--------------|---------------|----------------------|
| 1 | 192.7 (7.59) | 420.4 (16.55) | 165.3 (6.51) |
| 2 | 226.9 (8.93) | 293.8 (11.57) | 172.3 (6.78) |
| 3 | 204.9 (8.07) | 69.3 (2.73) | 133.8 (5.27) |
| 4 | 120.6 (4.75) | 174.8 (6.88) | 164.5 (6.48) |
| 5 | 246.8 (9.72) | 299.2 (11.78) | 179.2 (7.06) |
| 6 | 140.5 (5.53) | 458 (18.03) | 190.6 (7.50) |



Washer Tube Layout

EKS00EY8




FRONT WIPER AND WASHER SYSTEM

Removal and Installation of Washer Nozzle

EKS00EY9


REMOVAL

1. Push washer nozzle firmly toward either left or right to pull out.
2. Remove washer hose from washer nozzle.



INSTALLATION

1. After connecting washer hose, press nozzle from cowl top cover surface.
2. Assemble nozzle and socket.
3. Adjust nozzle injection position.




Inspection of Washer Nozzle

INSPECTION OF CHECK VALVE

EKS00EYA

Blow air in the injection direction, and check that air flows only one way. Make sure that the reverse direction (inhale) is not possible.




Wiper and Washer Switch Circuit Check

INSPECTION OF SWITCH CIRCUIT

EKS00EYB

Check continuity between each terminal when wiper and washer switch is operating using a circuit tester.

| Operation interval (intermittent wiper with vehicle speed detection function) | Resistance value (kΩ) |
|---|-----------------------|
| 1 [Interval (Max.)] | Approx. 1 |
| 2 | Approx. 0.6 |
| 3 | Approx. 0.3 |
| 4 [Interval (Min.)] | Approx. 0 |



Removal and Installation of Front Wiper and Washer Switch


EKS00GCG

REMOVAL

1. Remove steering column cover. Refer to [IP-10, "Removal and Installation"](#) in IP section.
2. Remove front wiper and washer switch connector.

FRONT WIPER AND WASHER SYSTEM

3. Remove screw and then remove wiper and washer switch from the base.




INSTALLATION

Installation is in the reverse order of removal.


Removal and Installation of Washer Tank REMOVAL

EKS00EYD

1. Pull out washer tank inlet.



2. Remove fender protector, refer to [EI-21, "FENDER PROTECTOR"](#).
3. Remove washer motor connector.
4. Remove washer tank installation screw and pawl.
5. Remove washer hose, and remove washer tank from the vehicle.



INSTALLATION

Tighten washer tank screw to specified torque.

Washer tank screw : 4.5 N-m (0.46 kg-m, 40 in-lb)

CAUTION:

After installation, add water up to the upper level of washer tank inlet, and check for water leaks.


FRONT WIPER AND WASHER SYSTEM

Removal and Installation for Washer Motor

EKS00EYE

REMOVAL

1. Remove fender protector. Refer to [EI-21, "FENDER PROTECTOR"](#) .
2. Remove washer motor connector and hose.
3. Pull out washer motor in the direction of the arrow in the figure, and remove washer motor from washer tank.



INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

When installing washer motor, there should be no packing twists, etc.

A

B

C

D

E

F

G

H

I

J

WW

L

M

CIGARETTE LIGHTER



PFP:35330

EKS001JG

WW-CIGAR-01

CIGARETTE LIGHTER

Wiring Diagram — CIGAR —



REFER TO THE FOLLOWING.
 (E205) -SUPER MULTIPLE JUNCTION (SMJ)
 (M1), (E201) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

★: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.


TKWM0433E

CIGARETTE LIGHTER

Removal and Installation

REMOVAL

1. Remove A/T console finisher. Refer to [IP-11, "WORK STEPS"](#) in IP section.
2. Pull out the cigarette lighter.
3. Remove socket.
4. Press out ring from the back of ashtray.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M

WW

POWER SOCKET



PFP:253A2

POWER SOCKET

Wiring Diagram — CIGAR —

EKS001JI

WW-CIGAR-01



REFER TO THE FOLLOWING.

- (E205) -SUPER MULTIPLE JUNCTION (SMJ)
- (M1), (E201) -FUSE BLOCK-JUNCTION BOX (J/B) NO.1

★: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.

TKWM0433E


POWER SOCKET

Removal and Installation

EKS00145

REMOVAL

1. Remove console box assembly. Refer to [IP-11, "WORK STEPS"](#) in IP section.
2. Disconnect power socket connector.
3. Remove inner socket and socket from console finisher while pressing hook on inner socket.
4. Remove socket from inner socket while pressing hook.



INSTALLATION

Installation is in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M

WW

HORN




PFP:25610

HORN

Wiring Diagram — HORN —

EKS001JK

WW-HORN-01



REFER TO THE FOLLOWING.

- (E205) -SUPER MULTIPLE JUNCTION (SMJ)
- (E3) -FUSE,FUSIBLE LINK AND RELAY BLOCK (J/B)
- (E204) -ELECTRICAL UNITS

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT", PG SECTION.


TKWM0109E

HORN

Removal and installation

REMOVAL (HORN HI)

1. Remove mass air flow sensor cover. Refer to [EM-11, "ENGINE ROOM COVER"](#) .
2. Disconnect horn connector.
3. Remove horn.




INSTALLATION (HORN HI)

Tighten horn bolt to specified torque.

Horn bolt  : 6.8 N·m (0.69 kg·m, 60 in·lb)

REMOVAL (HORN LOW)

1. Remove front grille. Refer to [EI-19, "FRONT GRILLE"](#) .
2. Disconnect horn connector.
3. Remove horn.



INSTALLATION (HORN LOW)

Tighten horn bolt to specified torque.

Horn bolt  : 17.1 N·m (1.7 kg·m, 13 ft·lb)

EKS001JL

A
B
C
D
E
F
G
H
I
J
L
M

WW

HORN
