

SECTION **LAN**
LAN SYSTEM

A
B
C

CONTENTS

D
E

CAN FUNDAMENTAL		HOW TO USE THIS SECTION	31	F
HOW TO USE THIS MANUAL	15	Information	31	
HOW TO USE THIS SECTION	15	Abbreviation List	31	G
Information	15	PRECAUTION	32	
PRECAUTION	16	PRECAUTIONS	32	H
PRECAUTIONS	16	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	32	
Precautions for Trouble Diagnosis	16	Precautions for Trouble Diagnosis	32	I
Precautions for Harness Repair	16	Precautions for Harness Repair	32	
SYSTEM DESCRIPTION	17	SYSTEM DESCRIPTION	34	J
SYSTEM	17	COMPONENT PARTS	34	
CAN COMMUNICATION SYSTEM	17	Component Parts Location	34	K
CAN COMMUNICATION SYSTEM : System Description	17	SYSTEM	36	
DIAG ON CAN	17	CAN COMMUNICATION SYSTEM	36	L
DIAG ON CAN : System Description	17	CAN COMMUNICATION SYSTEM : System Description	36	
TROUBLE DIAGNOSIS	19	CAN COMMUNICATION SYSTEM : CAN Communication Control Circuit	42	LAN
Component Description	19	CAN COMMUNICATION SYSTEM : CAN System Specification Chart	42	
Condition of Error Detection	19	CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart	44	N
Symptom When Error Occurs in CAN Communication System	20	WIRING DIAGRAM	52	
CAN Diagnosis with CONSULT	22	CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)	52	O
Self-Diagnosis	23	Wiring Diagram	52	
CAN Diagnostic Support Monitor	23	CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)	61	P
How to Use CAN Communication Signal Chart	25	Wiring Diagram	61	
BASIC INSPECTION	26	CAN SYSTEM (WITH ICC)	74	
DIAGNOSIS AND REPAIR WORKFLOW	26	Wiring Diagram	74	
Trouble Diagnosis Flow Chart	26			
Trouble Diagnosis Procedure	26			
CAN				
HOW TO USE THIS MANUAL	31			

N
O
P

BASIC INSPECTION	90	MAIN LINE BETWEEN ICC AND LANE CIRCUIT	109
DIAGNOSIS AND REPAIR WORKFLOW	90	Diagnosis Procedure	109
Interview Sheet	90	ECM BRANCH LINE CIRCUIT	110
DTC/CIRCUIT DIAGNOSIS	91	Diagnosis Procedure	110
MALFUNCTION AREA CHART	91	DLC BRANCH LINE CIRCUIT	111
CAN Communication Circuit	91	Diagnosis Procedure	111
ITS Communication Circuit	92	DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	112
Chassis Communication Circuit	92	Diagnosis Procedure	112
MAIN LINE BETWEEN DLC AND HVAC CIRCUIT	93	DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	113
Diagnosis Procedure	93	Diagnosis Procedure	113
MAIN LINE BETWEEN HVAC AND AV CIRCUIT	94	IPDM-E BRANCH LINE CIRCUIT	114
Diagnosis Procedure	94	Diagnosis Procedure	114
MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT	95	TCM BRANCH LINE CIRCUIT	115
Diagnosis Procedure	95	Diagnosis Procedure	115
MAIN LINE BETWEEN ABS AND ADP CIRCUIT	97	CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	117
Diagnosis Procedure	97	Diagnosis Procedure	117
MAIN LINE BETWEEN ADP AND AVM CIRCUIT	98	CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	118
Diagnosis Procedure	98	Diagnosis Procedure	118
MAIN LINE BETWEEN AVM AND SONAR CIRCUIT	99	HVAC BRANCH LINE CIRCUIT	119
Diagnosis Procedure	99	Diagnosis Procedure	119
MAIN LINE BETWEEN SONAR AND DLC CIRCUIT	101	M&A BRANCH LINE CIRCUIT	120
Diagnosis Procedure	101	Diagnosis Procedure	120
MAIN LINE BETWEEN ADP AND ICC CIRCUIT	102	A-BAG BRANCH LINE CIRCUIT	121
Diagnosis Procedure	102	Diagnosis Procedure	121
MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT	103	AFS BRANCH LINE CIRCUIT	122
Diagnosis Procedure	103	Diagnosis Procedure	122
MAIN LINE BETWEEN EPS/DAST 3 AND STRG CIRCUIT	105	AV BRANCH LINE CIRCUIT	123
Diagnosis Procedure	105	Diagnosis Procedure	123
MAIN LINE BETWEEN RDR-L AND AVM CIRCUIT	106	HBA BRANCH LINE CIRCUIT	124
Diagnosis Procedure	106	Diagnosis Procedure	124
MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT	107	TCU BRANCH LINE CIRCUIT	125
Diagnosis Procedure	107	Diagnosis Procedure	125
		BCM BRANCH LINE CIRCUIT	126
		Diagnosis Procedure	126
		ABS BRANCH LINE CIRCUIT	127
		Diagnosis Procedure	127
		ADP BRANCH LINE CIRCUIT	129
		Diagnosis Procedure	129
		PSB BRANCH LINE CIRCUIT	131

Diagnosis Procedure	131	Diagnosis Procedure	155	
ICC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	132	CAN GATEWAY		A
Diagnosis Procedure	132	PRECAUTION	157	
ICC BRANCH LINE CIRCUIT (CHASSIS COMMUNICATION CIRCUIT)	133	PRECAUTIONS	157	B
Diagnosis Procedure	133	Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	157	C
EPS/DAST 3 BRANCH LINE CIRCUIT	134	SYSTEM DESCRIPTION	158	
Diagnosis Procedure	134	COMPONENT PARTS	158	D
4WD BRANCH LINE CIRCUIT	135	Component Parts Location	158	
Diagnosis Procedure	135	SYSTEM	159	E
CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)	136	System Description	159	
Diagnosis Procedure	136	DIAGNOSIS SYSTEM (CAN GATEWAY)	160	F
STRG BRANCH LINE CIRCUIT	137	CONSULT Function	160	
Diagnosis Procedure	137	ECU DIAGNOSIS INFORMATION	161	
RDR-L BRANCH LINE CIRCUIT	138	CAN GATEWAY	161	G
Diagnosis Procedure	138	Reference Value	161	
RDR-R BRANCH LINE CIRCUIT	139	DTC Inspection Priority Chart	161	H
Diagnosis Procedure	139	DTC Index	162	
AVM BRANCH LINE CIRCUIT	140	WIRING DIAGRAM	163	
Diagnosis Procedure	140	CAN GATEWAY SYSTEM	163	I
APA BRANCH LINE CIRCUIT	141	Wiring Diagram	163	
Diagnosis Procedure	141	BASIC INSPECTION	165	J
BSW/BUZZER BRANCH LINE CIRCUIT	142	ADDITIONAL SERVICE WHEN REPLACING CAN GATEWAY	165	K
Diagnosis Procedure	142	Description	165	
LASER BRANCH LINE CIRCUIT	143	Work Procedure	165	
Diagnosis Procedure	143	CONFIGURATION (CAN GATEWAY)	166	L
SONAR BRANCH LINE CIRCUIT	144	Work Procedure	166	
Diagnosis Procedure	144	Configuration List	166	
DAST 1 BRANCH LINE CIRCUIT	145	DTC/CIRCUIT DIAGNOSIS	167	LAN
Diagnosis Procedure	145	U1000 CAN COMM CIRCUIT	167	
LANE BRANCH LINE CIRCUIT	146	DTC Description	167	N
Diagnosis Procedure	146	Diagnosis Procedure	167	
CAN COMMUNICATION CIRCUIT	147	U1010 CONTROL UNIT (CAN)	168	O
Diagnosis Procedure	147	DTC Description	168	
CAN COMMUNICATION CIRCUIT 1	149	Diagnosis Procedure	168	
Diagnosis Procedure	149	B2600 CONFIG ERROR	169	P
CAN COMMUNICATION CIRCUIT 2	151	DTC Description	169	
Diagnosis Procedure	151	WRONG DATA	169	
CHASSIS COMMUNICATION CIRCUIT	153	WRONG DATA : Diagnosis Procedure	169	
Diagnosis Procedure	153	NOT CONFIGURED	169	
ITS COMMUNICATION CIRCUIT	155	NOT CONFIGURED : Diagnosis Procedure	169	

POWER SUPPLY AND GROUND CIRCUIT ..	171	MAIN LINE BETWEEN DLC AND HVAC CIR-	191
Diagnosis Procedure	171	CUIT	191
REMOVAL AND INSTALLATION	172	Diagnosis Procedure	191
CAN GATEWAY	172	MAIN LINE BETWEEN HVAC AND AV CIR-	192
Removal and Installation	172	CUIT	192
CAN SYSTEM (TYPE 1)		Diagnosis Procedure	192
DTC/CIRCUIT DIAGNOSIS	173	ECM BRANCH LINE CIRCUIT	193
MAIN LINE BETWEEN DLC AND HVAC CIR-	173	Diagnosis Procedure	193
CUIT	173	DLC BRANCH LINE CIRCUIT	194
Diagnosis Procedure	173	Diagnosis Procedure	194
MAIN LINE BETWEEN HVAC AND AV CIR-	174	IPDM-E BRANCH LINE CIRCUIT	195
CUIT	174	Diagnosis Procedure	195
Diagnosis Procedure	174	TCM BRANCH LINE CIRCUIT	196
ECM BRANCH LINE CIRCUIT	175	Diagnosis Procedure	196
Diagnosis Procedure	175	HVAC BRANCH LINE CIRCUIT	198
DLC BRANCH LINE CIRCUIT	176	Diagnosis Procedure	198
Diagnosis Procedure	176	M&A BRANCH LINE CIRCUIT	199
IPDM-E BRANCH LINE CIRCUIT	177	Diagnosis Procedure	199
Diagnosis Procedure	177	A-BAG BRANCH LINE CIRCUIT	200
TCM BRANCH LINE CIRCUIT	178	Diagnosis Procedure	200
Diagnosis Procedure	178	AV BRANCH LINE CIRCUIT	201
HVAC BRANCH LINE CIRCUIT	180	Diagnosis Procedure	201
Diagnosis Procedure	180	TCU BRANCH LINE CIRCUIT	202
M&A BRANCH LINE CIRCUIT	181	Diagnosis Procedure	202
Diagnosis Procedure	181	BCM BRANCH LINE CIRCUIT	203
A-BAG BRANCH LINE CIRCUIT	182	Diagnosis Procedure	203
Diagnosis Procedure	182	ABS BRANCH LINE CIRCUIT	204
AV BRANCH LINE CIRCUIT	183	Diagnosis Procedure	204
Diagnosis Procedure	183	CCM BRANCH LINE CIRCUIT (CAN COM-	206
BCM BRANCH LINE CIRCUIT	184	MUNICATION CIRCUIT)	206
Diagnosis Procedure	184	Diagnosis Procedure	206
ABS BRANCH LINE CIRCUIT	185	STRG BRANCH LINE CIRCUIT	207
Diagnosis Procedure	185	Diagnosis Procedure	207
CCM BRANCH LINE CIRCUIT (CAN COM-	187	CAN COMMUNICATION CIRCUIT	208
MUNICATION CIRCUIT)	187	Diagnosis Procedure	208
Diagnosis Procedure	187	CAN SYSTEM (TYPE 3)	
STRG BRANCH LINE CIRCUIT	188	DTC/CIRCUIT DIAGNOSIS	210
Diagnosis Procedure	188	MAIN LINE BETWEEN DLC AND HVAC CIR-	210
CAN COMMUNICATION CIRCUIT	189	CUIT	210
Diagnosis Procedure	189	Diagnosis Procedure	210
CAN SYSTEM (TYPE 2)		MAIN LINE BETWEEN HVAC AND AV CIR-	211
DTC/CIRCUIT DIAGNOSIS	191	CUIT	211
		Diagnosis Procedure	211
		ECM BRANCH LINE CIRCUIT	212

Diagnosis Procedure	212	Diagnosis Procedure	235	
DLC BRANCH LINE CIRCUIT	213	IPDM-E BRANCH LINE CIRCUIT	236	A
Diagnosis Procedure	213	Diagnosis Procedure	236	
IPDM-E BRANCH LINE CIRCUIT	214	TCM BRANCH LINE CIRCUIT	237	B
Diagnosis Procedure	214	Diagnosis Procedure	237	
TCM BRANCH LINE CIRCUIT	215	HVAC BRANCH LINE CIRCUIT	239	C
Diagnosis Procedure	215	Diagnosis Procedure	239	
HVAC BRANCH LINE CIRCUIT	217	M&A BRANCH LINE CIRCUIT	240	D
Diagnosis Procedure	217	Diagnosis Procedure	240	
M&A BRANCH LINE CIRCUIT	218	A-BAG BRANCH LINE CIRCUIT	241	E
Diagnosis Procedure	218	Diagnosis Procedure	241	
A-BAG BRANCH LINE CIRCUIT	219	AV BRANCH LINE CIRCUIT	242	F
Diagnosis Procedure	219	Diagnosis Procedure	242	
AV BRANCH LINE CIRCUIT	220	TCU BRANCH LINE CIRCUIT	243	G
Diagnosis Procedure	220	Diagnosis Procedure	243	
BCM BRANCH LINE CIRCUIT	221	BCM BRANCH LINE CIRCUIT	244	H
Diagnosis Procedure	221	Diagnosis Procedure	244	
ABS BRANCH LINE CIRCUIT	222	ABS BRANCH LINE CIRCUIT	245	I
Diagnosis Procedure	222	Diagnosis Procedure	245	
EPS/DAST 3 BRANCH LINE CIRCUIT	224	EPS/DAST 3 BRANCH LINE CIRCUIT	247	J
Diagnosis Procedure	224	Diagnosis Procedure	247	
CCM BRANCH LINE CIRCUIT (CAN COM- MUNICATION CIRCUIT)	225	CCM BRANCH LINE CIRCUIT (CAN COM- MUNICATION CIRCUIT)	248	K
Diagnosis Procedure	225	Diagnosis Procedure	248	
STRG BRANCH LINE CIRCUIT	226	STRG BRANCH LINE CIRCUIT	249	L
Diagnosis Procedure	226	Diagnosis Procedure	249	
DAST 1 BRANCH LINE CIRCUIT	227	DAST 1 BRANCH LINE CIRCUIT	250	LAN
Diagnosis Procedure	227	Diagnosis Procedure	250	
CAN COMMUNICATION CIRCUIT	228	CAN COMMUNICATION CIRCUIT	251	N
Diagnosis Procedure	228	Diagnosis Procedure	251	
CHASSIS COMMUNICATION CIRCUIT	230	CHASSIS COMMUNICATION CIRCUIT	253	O
Diagnosis Procedure	230	Diagnosis Procedure	253	
CAN SYSTEM (TYPE 4)		CAN SYSTEM (TYPE 5)		P
DTC/CIRCUIT DIAGNOSIS	232	DTC/CIRCUIT DIAGNOSIS	255	
MAIN LINE BETWEEN DLC AND HVAC CIR- CUIT	232	MAIN LINE BETWEEN DLC AND HVAC CIR- CUIT	255	
Diagnosis Procedure	232	Diagnosis Procedure	255	
MAIN LINE BETWEEN HVAC AND AV CIR- CUIT	233	MAIN LINE BETWEEN HVAC AND AV CIR- CUIT	256	
Diagnosis Procedure	233	Diagnosis Procedure	256	
ECM BRANCH LINE CIRCUIT	234	MAIN LINE BETWEEN ABS AND ADP CIR- CUIT	257	
Diagnosis Procedure	234	Diagnosis Procedure	257	
DLC BRANCH LINE CIRCUIT	235			

MAIN LINE BETWEEN ADP AND AVM CIRCUIT	258	ADP BRANCH LINE CIRCUIT	280
Diagnosis Procedure	258	Diagnosis Procedure	280
MAIN LINE BETWEEN AVM AND SONAR CIRCUIT	259	EPS/DAST 3 BRANCH LINE CIRCUIT	282
Diagnosis Procedure	259	Diagnosis Procedure	282
MAIN LINE BETWEEN SONAR AND DLC CIRCUIT	261	CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)	283
Diagnosis Procedure	261	Diagnosis Procedure	283
MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT	262	STRG BRANCH LINE CIRCUIT	284
Diagnosis Procedure	262	Diagnosis Procedure	284
ECM BRANCH LINE CIRCUIT	264	AVM BRANCH LINE CIRCUIT	285
Diagnosis Procedure	264	Diagnosis Procedure	285
DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	265	SONAR BRANCH LINE CIRCUIT	286
Diagnosis Procedure	265	Diagnosis Procedure	286
DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	266	DAST 1 BRANCH LINE CIRCUIT	287
Diagnosis Procedure	266	Diagnosis Procedure	287
IPDM-E BRANCH LINE CIRCUIT	267	CAN COMMUNICATION CIRCUIT 1	288
Diagnosis Procedure	267	Diagnosis Procedure	288
TCM BRANCH LINE CIRCUIT	268	CAN COMMUNICATION CIRCUIT 2	290
Diagnosis Procedure	268	Diagnosis Procedure	290
CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	270	CHASSIS COMMUNICATION CIRCUIT	292
Diagnosis Procedure	270	Diagnosis Procedure	292
CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	271	CAN SYSTEM (TYPE 6)	
Diagnosis Procedure	271	DTC/CIRCUIT DIAGNOSIS	294
HVAC BRANCH LINE CIRCUIT	272	MAIN LINE BETWEEN DLC AND HVAC CIRCUIT	294
Diagnosis Procedure	272	Diagnosis Procedure	294
M&A BRANCH LINE CIRCUIT	273	MAIN LINE BETWEEN HVAC AND AV CIRCUIT	295
Diagnosis Procedure	273	Diagnosis Procedure	295
A-BAG BRANCH LINE CIRCUIT	274	MAIN LINE BETWEEN ABS AND ADP CIRCUIT	296
Diagnosis Procedure	274	Diagnosis Procedure	296
AV BRANCH LINE CIRCUIT	275	MAIN LINE BETWEEN ADP AND ICC CIRCUIT	297
Diagnosis Procedure	275	Diagnosis Procedure	297
TCU BRANCH LINE CIRCUIT	276	MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT	298
Diagnosis Procedure	276	Diagnosis Procedure	298
BCM BRANCH LINE CIRCUIT	277	MAIN LINE BETWEEN EPS/DAST 3 AND STRG CIRCUIT	300
Diagnosis Procedure	277	Diagnosis Procedure	300
ABS BRANCH LINE CIRCUIT	278	MAIN LINE BETWEEN RDR-L AND AVM CIRCUIT	301
Diagnosis Procedure	278	Diagnosis Procedure	301

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT	302	ADP BRANCH LINE CIRCUIT	325	
Diagnosis Procedure	302	Diagnosis Procedure	325	A
MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT	304	PSB BRANCH LINE CIRCUIT	327	
Diagnosis Procedure	304	Diagnosis Procedure	327	B
MAIN LINE BETWEEN ICC AND LANE CIRCUIT	306	ICC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	328	
Diagnosis Procedure	306	Diagnosis Procedure	328	C
ECM BRANCH LINE CIRCUIT	307	ICC BRANCH LINE CIRCUIT (CHASSIS COMMUNICATION CIRCUIT)	329	
Diagnosis Procedure	307	Diagnosis Procedure	329	D
DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	308	EPS/DAST 3 BRANCH LINE CIRCUIT	330	
Diagnosis Procedure	308	Diagnosis Procedure	330	E
DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	309	CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)	331	
Diagnosis Procedure	309	Diagnosis Procedure	331	F
IPDM-E BRANCH LINE CIRCUIT	310	STRG BRANCH LINE CIRCUIT	332	
Diagnosis Procedure	310	Diagnosis Procedure	332	G
TCM BRANCH LINE CIRCUIT	311	RDR-L BRANCH LINE CIRCUIT	333	
Diagnosis Procedure	311	Diagnosis Procedure	333	H
CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	313	RDR-R BRANCH LINE CIRCUIT	334	
Diagnosis Procedure	313	Diagnosis Procedure	334	I
CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	314	AVM BRANCH LINE CIRCUIT	335	
Diagnosis Procedure	314	Diagnosis Procedure	335	J
HVAC BRANCH LINE CIRCUIT	315	APA BRANCH LINE CIRCUIT	336	
Diagnosis Procedure	315	Diagnosis Procedure	336	K
M&A BRANCH LINE CIRCUIT	316	BSW/BUZZER BRANCH LINE CIRCUIT	337	
Diagnosis Procedure	316	Diagnosis Procedure	337	L
A-BAG BRANCH LINE CIRCUIT	317	LASER BRANCH LINE CIRCUIT	338	
Diagnosis Procedure	317	Diagnosis Procedure	338	LAN
AFS BRANCH LINE CIRCUIT	318	SONAR BRANCH LINE CIRCUIT	339	
Diagnosis Procedure	318	Diagnosis Procedure	339	N
AV BRANCH LINE CIRCUIT	319	DAST 1 BRANCH LINE CIRCUIT	340	
Diagnosis Procedure	319	Diagnosis Procedure	340	O
HBA BRANCH LINE CIRCUIT	320	LANE BRANCH LINE CIRCUIT	341	
Diagnosis Procedure	320	Diagnosis Procedure	341	P
TCU BRANCH LINE CIRCUIT	321	CAN COMMUNICATION CIRCUIT 1	342	
Diagnosis Procedure	321	Diagnosis Procedure	342	
BCM BRANCH LINE CIRCUIT	322	CAN COMMUNICATION CIRCUIT 2	344	
Diagnosis Procedure	322	Diagnosis Procedure	344	
ABS BRANCH LINE CIRCUIT	323	CHASSIS COMMUNICATION CIRCUIT	346	
Diagnosis Procedure	323	Diagnosis Procedure	346	
		ITS COMMUNICATION CIRCUIT	348	
		Diagnosis Procedure	348	
		CAN SYSTEM (TYPE 7)		

DTC/CIRCUIT DIAGNOSIS	350	ECM BRANCH LINE CIRCUIT	371
MAIN LINE BETWEEN DLC AND HVAC CIR- CUIT	350	Diagnosis Procedure	371
Diagnosis Procedure	350	DLC BRANCH LINE CIRCUIT	372
MAIN LINE BETWEEN HVAC AND AV CIR- CUIT	351	Diagnosis Procedure	372
Diagnosis Procedure	351	IPDM-E BRANCH LINE CIRCUIT	373
ECM BRANCH LINE CIRCUIT	352	Diagnosis Procedure	373
Diagnosis Procedure	352	TCM BRANCH LINE CIRCUIT	374
DLC BRANCH LINE CIRCUIT	353	Diagnosis Procedure	374
Diagnosis Procedure	353	HVAC BRANCH LINE CIRCUIT	376
IPDM-E BRANCH LINE CIRCUIT	354	Diagnosis Procedure	376
Diagnosis Procedure	354	M&A BRANCH LINE CIRCUIT	377
TCM BRANCH LINE CIRCUIT	355	Diagnosis Procedure	377
Diagnosis Procedure	355	A-BAG BRANCH LINE CIRCUIT	378
HVAC BRANCH LINE CIRCUIT	357	Diagnosis Procedure	378
Diagnosis Procedure	357	AV BRANCH LINE CIRCUIT	379
M&A BRANCH LINE CIRCUIT	358	Diagnosis Procedure	379
Diagnosis Procedure	358	TCU BRANCH LINE CIRCUIT	380
A-BAG BRANCH LINE CIRCUIT	359	Diagnosis Procedure	380
Diagnosis Procedure	359	BCM BRANCH LINE CIRCUIT	381
AV BRANCH LINE CIRCUIT	360	Diagnosis Procedure	381
Diagnosis Procedure	360	ABS BRANCH LINE CIRCUIT	382
BCM BRANCH LINE CIRCUIT	361	Diagnosis Procedure	382
Diagnosis Procedure	361	4WD BRANCH LINE CIRCUIT	384
ABS BRANCH LINE CIRCUIT	362	Diagnosis Procedure	384
Diagnosis Procedure	362	CCM BRANCH LINE CIRCUIT (CAN COM- MUNICATION CIRCUIT)	385
4WD BRANCH LINE CIRCUIT	364	Diagnosis Procedure	385
Diagnosis Procedure	364	STRG BRANCH LINE CIRCUIT	386
CCM BRANCH LINE CIRCUIT (CAN COM- MUNICATION CIRCUIT)	365	Diagnosis Procedure	386
Diagnosis Procedure	365	CAN COMMUNICATION CIRCUIT	387
STRG BRANCH LINE CIRCUIT	366	Diagnosis Procedure	387
Diagnosis Procedure	366	CAN SYSTEM (TYPE 9)	
CAN COMMUNICATION CIRCUIT	367	DTC/CIRCUIT DIAGNOSIS	389
Diagnosis Procedure	367	MAIN LINE BETWEEN DLC AND HVAC CIR- CUIT	389
CAN SYSTEM (TYPE 8)		Diagnosis Procedure	389
DTC/CIRCUIT DIAGNOSIS	369	MAIN LINE BETWEEN HVAC AND AV CIR- CUIT	390
MAIN LINE BETWEEN DLC AND HVAC CIR- CUIT	369	Diagnosis Procedure	390
Diagnosis Procedure	369	ECM BRANCH LINE CIRCUIT	391
MAIN LINE BETWEEN HVAC AND AV CIR- CUIT	370	Diagnosis Procedure	391
Diagnosis Procedure	370	DLC BRANCH LINE CIRCUIT	392
		Diagnosis Procedure	392

IPDM-E BRANCH LINE CIRCUIT	393	IPDM-E BRANCH LINE CIRCUIT	416	
Diagnosis Procedure	393	Diagnosis Procedure	416	A
TCM BRANCH LINE CIRCUIT	394	TCM BRANCH LINE CIRCUIT	417	
Diagnosis Procedure	394	Diagnosis Procedure	417	B
HVAC BRANCH LINE CIRCUIT	396	HVAC BRANCH LINE CIRCUIT	419	
Diagnosis Procedure	396	Diagnosis Procedure	419	C
M&A BRANCH LINE CIRCUIT	397	M&A BRANCH LINE CIRCUIT	420	
Diagnosis Procedure	397	Diagnosis Procedure	420	D
A-BAG BRANCH LINE CIRCUIT	398	A-BAG BRANCH LINE CIRCUIT	421	
Diagnosis Procedure	398	Diagnosis Procedure	421	E
AV BRANCH LINE CIRCUIT	399	AV BRANCH LINE CIRCUIT	422	
Diagnosis Procedure	399	Diagnosis Procedure	422	F
BCM BRANCH LINE CIRCUIT	400	TCU BRANCH LINE CIRCUIT	423	
Diagnosis Procedure	400	Diagnosis Procedure	423	G
ABS BRANCH LINE CIRCUIT	401	BCM BRANCH LINE CIRCUIT	424	
Diagnosis Procedure	401	Diagnosis Procedure	424	H
EPS/DAST 3 BRANCH LINE CIRCUIT	403	ABS BRANCH LINE CIRCUIT	425	
Diagnosis Procedure	403	Diagnosis Procedure	425	I
4WD BRANCH LINE CIRCUIT	404	EPS/DAST 3 BRANCH LINE CIRCUIT	427	
Diagnosis Procedure	404	Diagnosis Procedure	427	J
CCM BRANCH LINE CIRCUIT (CAN COM- MUNICATION CIRCUIT)	405	4WD BRANCH LINE CIRCUIT	428	
Diagnosis Procedure	405	Diagnosis Procedure	428	K
STRG BRANCH LINE CIRCUIT	406	CCM BRANCH LINE CIRCUIT (CAN COM- MUNICATION CIRCUIT)	429	
Diagnosis Procedure	406	Diagnosis Procedure	429	L
DAST 1 BRANCH LINE CIRCUIT	407	STRG BRANCH LINE CIRCUIT	430	
Diagnosis Procedure	407	Diagnosis Procedure	430	LAN
CAN COMMUNICATION CIRCUIT	408	DAST 1 BRANCH LINE CIRCUIT	431	
Diagnosis Procedure	408	Diagnosis Procedure	431	N
CHASSIS COMMUNICATION CIRCUIT	410	CAN COMMUNICATION CIRCUIT	432	
Diagnosis Procedure	410	Diagnosis Procedure	432	O
CAN SYSTEM (TYPE 10)		CHASSIS COMMUNICATION CIRCUIT	434	
DTC/CIRCUIT DIAGNOSIS	412	Diagnosis Procedure	434	P
MAIN LINE BETWEEN DLC AND HVAC CIR- CUIT	412	CAN SYSTEM (TYPE 11)		
Diagnosis Procedure	412	DTC/CIRCUIT DIAGNOSIS	436	
MAIN LINE BETWEEN HVAC AND AV CIR- CUIT	413	MAIN LINE BETWEEN DLC AND HVAC CIR- CUIT	436	
Diagnosis Procedure	413	Diagnosis Procedure	436	
ECM BRANCH LINE CIRCUIT	414	MAIN LINE BETWEEN HVAC AND AV CIR- CUIT	437	
Diagnosis Procedure	414	Diagnosis Procedure	437	
DLC BRANCH LINE CIRCUIT	415	MAIN LINE BETWEEN ABS AND ADP CIR- CUIT	438	
Diagnosis Procedure	415	Diagnosis Procedure	438	

MAIN LINE BETWEEN ADP AND AVM CIRCUIT	439	ADP BRANCH LINE CIRCUIT	461
Diagnosis Procedure	439	Diagnosis Procedure	461
MAIN LINE BETWEEN AVM AND SONAR CIRCUIT	440	EPS/DAST 3 BRANCH LINE CIRCUIT	463
Diagnosis Procedure	440	Diagnosis Procedure	463
MAIN LINE BETWEEN SONAR AND DLC CIRCUIT	442	4WD BRANCH LINE CIRCUIT	464
Diagnosis Procedure	442	Diagnosis Procedure	464
MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT	443	CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)	465
Diagnosis Procedure	443	Diagnosis Procedure	465
ECM BRANCH LINE CIRCUIT	445	STRG BRANCH LINE CIRCUIT	466
Diagnosis Procedure	445	Diagnosis Procedure	466
DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	446	AVM BRANCH LINE CIRCUIT	467
Diagnosis Procedure	446	Diagnosis Procedure	467
DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	447	SONAR BRANCH LINE CIRCUIT	468
Diagnosis Procedure	447	Diagnosis Procedure	468
IPDM-E BRANCH LINE CIRCUIT	448	DAST 1 BRANCH LINE CIRCUIT	469
Diagnosis Procedure	448	Diagnosis Procedure	469
TCM BRANCH LINE CIRCUIT	449	CAN COMMUNICATION CIRCUIT 1	470
Diagnosis Procedure	449	Diagnosis Procedure	470
CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	451	CAN COMMUNICATION CIRCUIT 2	472
Diagnosis Procedure	451	Diagnosis Procedure	472
CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	452	CHASSIS COMMUNICATION CIRCUIT	474
Diagnosis Procedure	452	Diagnosis Procedure	474
HVAC BRANCH LINE CIRCUIT	453	CAN SYSTEM (TYPE 12)	
Diagnosis Procedure	453	DTC/CIRCUIT DIAGNOSIS	476
M&A BRANCH LINE CIRCUIT	454	MAIN LINE BETWEEN DLC AND HVAC CIRCUIT	476
Diagnosis Procedure	454	Diagnosis Procedure	476
A-BAG BRANCH LINE CIRCUIT	455	MAIN LINE BETWEEN HVAC AND AV CIRCUIT	477
Diagnosis Procedure	455	Diagnosis Procedure	477
AV BRANCH LINE CIRCUIT	456	MAIN LINE BETWEEN ABS AND ADP CIRCUIT	478
Diagnosis Procedure	456	Diagnosis Procedure	478
TCU BRANCH LINE CIRCUIT	457	MAIN LINE BETWEEN ADP AND ICC CIRCUIT	479
Diagnosis Procedure	457	Diagnosis Procedure	479
BCM BRANCH LINE CIRCUIT	458	MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT	480
Diagnosis Procedure	458	Diagnosis Procedure	480
ABS BRANCH LINE CIRCUIT	459	MAIN LINE BETWEEN EPS/DAST 3 AND STRG CIRCUIT	482
Diagnosis Procedure	459	Diagnosis Procedure	482

MAIN LINE BETWEEN RDR-L AND AVM CIRCUIT	483	BCM BRANCH LINE CIRCUIT	504	A
Diagnosis Procedure	483	Diagnosis Procedure	504	
MAIN LINE BETWEEN AVM AND SONAR CIRCUIT	484	ABS BRANCH LINE CIRCUIT	505	B
Diagnosis Procedure	484	Diagnosis Procedure	505	
MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT	486	ADP BRANCH LINE CIRCUIT	507	C
Diagnosis Procedure	486	Diagnosis Procedure	507	
MAIN LINE BETWEEN ICC AND LANE CIRCUIT	488	PSB BRANCH LINE CIRCUIT	509	D
Diagnosis Procedure	488	Diagnosis Procedure	509	
ECM BRANCH LINE CIRCUIT	489	ICC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	510	E
Diagnosis Procedure	489	Diagnosis Procedure	510	
DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	490	ICC BRANCH LINE CIRCUIT (CHASSIS COMMUNICATION CIRCUIT)	511	F
Diagnosis Procedure	490	Diagnosis Procedure	511	
DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	491	EPS/DAST 3 BRANCH LINE CIRCUIT	512	G
Diagnosis Procedure	491	Diagnosis Procedure	512	
IPDM-E BRANCH LINE CIRCUIT	492	4WD BRANCH LINE CIRCUIT	513	H
Diagnosis Procedure	492	Diagnosis Procedure	513	
TCM BRANCH LINE CIRCUIT	493	CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)	514	I
Diagnosis Procedure	493	Diagnosis Procedure	514	
CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	495	STRG BRANCH LINE CIRCUIT	515	J
Diagnosis Procedure	495	Diagnosis Procedure	515	
CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	496	RDR-L BRANCH LINE CIRCUIT	516	K
Diagnosis Procedure	496	Diagnosis Procedure	516	
HVAC BRANCH LINE CIRCUIT	497	RDR-R BRANCH LINE CIRCUIT	517	L
Diagnosis Procedure	497	Diagnosis Procedure	517	
M&A BRANCH LINE CIRCUIT	498	AVM BRANCH LINE CIRCUIT	518	LAN
Diagnosis Procedure	498	Diagnosis Procedure	518	
A-BAG BRANCH LINE CIRCUIT	499	APA BRANCH LINE CIRCUIT	519	N
Diagnosis Procedure	499	Diagnosis Procedure	519	
AFS BRANCH LINE CIRCUIT	500	BSW/BUZZER BRANCH LINE CIRCUIT	520	O
Diagnosis Procedure	500	Diagnosis Procedure	520	
AV BRANCH LINE CIRCUIT	501	LASER BRANCH LINE CIRCUIT	521	P
Diagnosis Procedure	501	Diagnosis Procedure	521	
HBA BRANCH LINE CIRCUIT	502	SONAR BRANCH LINE CIRCUIT	522	
Diagnosis Procedure	502	Diagnosis Procedure	522	
TCU BRANCH LINE CIRCUIT	503	DAST 1 BRANCH LINE CIRCUIT	523	
Diagnosis Procedure	503	Diagnosis Procedure	523	
		LANE BRANCH LINE CIRCUIT	524	
		Diagnosis Procedure	524	
		CAN COMMUNICATION CIRCUIT 1	525	
		Diagnosis Procedure	525	

CAN COMMUNICATION CIRCUIT 2	527	CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	549
Diagnosis Procedure	527	Diagnosis Procedure	549
CHASSIS COMMUNICATION CIRCUIT	529	HVAC BRANCH LINE CIRCUIT	550
Diagnosis Procedure	529	Diagnosis Procedure	550
ITS COMMUNICATION CIRCUIT	531	M&A BRANCH LINE CIRCUIT	551
Diagnosis Procedure	531	Diagnosis Procedure	551
CAN SYSTEM (TYPE 13)			
DTC/CIRCUIT DIAGNOSIS	533	A-BAG BRANCH LINE CIRCUIT	552
MAIN LINE BETWEEN DLC AND HVAC CIRCUIT	533	Diagnosis Procedure	552
Diagnosis Procedure	533	AV BRANCH LINE CIRCUIT	553
MAIN LINE BETWEEN HVAC AND AV CIRCUIT	534	Diagnosis Procedure	553
Diagnosis Procedure	534	BCM BRANCH LINE CIRCUIT	554
MAIN LINE BETWEEN ABS AND ADP CIRCUIT	535	Diagnosis Procedure	554
Diagnosis Procedure	535	ABS BRANCH LINE CIRCUIT	555
MAIN LINE BETWEEN ADP AND AVM CIRCUIT	536	Diagnosis Procedure	555
Diagnosis Procedure	536	ADP BRANCH LINE CIRCUIT	557
MAIN LINE BETWEEN AVM AND SONAR CIRCUIT	537	Diagnosis Procedure	557
Diagnosis Procedure	537	EPS/DAST 3 BRANCH LINE CIRCUIT	559
MAIN LINE BETWEEN SONAR AND DLC CIRCUIT	539	Diagnosis Procedure	559
Diagnosis Procedure	539	CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)	560
MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT	540	Diagnosis Procedure	560
Diagnosis Procedure	540	STRG BRANCH LINE CIRCUIT	561
ECM BRANCH LINE CIRCUIT	542	Diagnosis Procedure	561
Diagnosis Procedure	542	AVM BRANCH LINE CIRCUIT	562
DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	543	Diagnosis Procedure	562
Diagnosis Procedure	543	SONAR BRANCH LINE CIRCUIT	563
DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	544	Diagnosis Procedure	563
Diagnosis Procedure	544	DAST 1 BRANCH LINE CIRCUIT	564
IPDM-E BRANCH LINE CIRCUIT	545	Diagnosis Procedure	564
Diagnosis Procedure	545	CAN COMMUNICATION CIRCUIT 1	565
TCM BRANCH LINE CIRCUIT	546	Diagnosis Procedure	565
Diagnosis Procedure	546	CAN COMMUNICATION CIRCUIT 2	567
CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	548	Diagnosis Procedure	567
Diagnosis Procedure	548	CHASSIS COMMUNICATION CIRCUIT	569
		Diagnosis Procedure	569
		CAN SYSTEM (TYPE 14)	
		DTC/CIRCUIT DIAGNOSIS	571
		MAIN LINE BETWEEN DLC AND HVAC CIRCUIT	571
		Diagnosis Procedure	571
		MAIN LINE BETWEEN HVAC AND AV CIRCUIT	572
		Diagnosis Procedure	572

MAIN LINE BETWEEN ABS AND ADP CIRCUIT	573	A-BAG BRANCH LINE CIRCUIT	594	A
Diagnosis Procedure	573	Diagnosis Procedure	594	
MAIN LINE BETWEEN ADP AND ICC CIRCUIT	574	AFS BRANCH LINE CIRCUIT	595	B
Diagnosis Procedure	574	Diagnosis Procedure	595	
MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT	575	AV BRANCH LINE CIRCUIT	596	C
Diagnosis Procedure	575	Diagnosis Procedure	596	
MAIN LINE BETWEEN EPS/DAST 3 AND STRG CIRCUIT	577	HBA BRANCH LINE CIRCUIT	597	D
Diagnosis Procedure	577	Diagnosis Procedure	597	
MAIN LINE BETWEEN RDR-L AND AVM CIRCUIT	578	BCM BRANCH LINE CIRCUIT	598	E
Diagnosis Procedure	578	Diagnosis Procedure	598	
MAIN LINE BETWEEN AVM AND SONAR CIRCUIT	579	ABS BRANCH LINE CIRCUIT	599	F
Diagnosis Procedure	579	Diagnosis Procedure	599	
MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT	581	ADP BRANCH LINE CIRCUIT	601	G
Diagnosis Procedure	581	Diagnosis Procedure	601	
MAIN LINE BETWEEN ICC AND LANE CIRCUIT	583	PSB BRANCH LINE CIRCUIT	603	H
Diagnosis Procedure	583	Diagnosis Procedure	603	
ECM BRANCH LINE CIRCUIT	584	ICC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	604	I
Diagnosis Procedure	584	Diagnosis Procedure	604	
DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	585	ICC BRANCH LINE CIRCUIT (CHASSIS COMMUNICATION CIRCUIT)	605	J
Diagnosis Procedure	585	Diagnosis Procedure	605	
DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	586	EPS/DAST 3 BRANCH LINE CIRCUIT	606	K
Diagnosis Procedure	586	Diagnosis Procedure	606	
IPDM-E BRANCH LINE CIRCUIT	587	CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)	607	L
Diagnosis Procedure	587	Diagnosis Procedure	607	
TCM BRANCH LINE CIRCUIT	588	STRG BRANCH LINE CIRCUIT	608	LAN
Diagnosis Procedure	588	Diagnosis Procedure	608	
CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)	590	RDR-L BRANCH LINE CIRCUIT	609	N
Diagnosis Procedure	590	Diagnosis Procedure	609	
CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)	591	RDR-R BRANCH LINE CIRCUIT	610	O
Diagnosis Procedure	591	Diagnosis Procedure	610	
HVAC BRANCH LINE CIRCUIT	592	AVM BRANCH LINE CIRCUIT	611	P
Diagnosis Procedure	592	Diagnosis Procedure	611	
M&A BRANCH LINE CIRCUIT	593	APA BRANCH LINE CIRCUIT	612	
Diagnosis Procedure	593	Diagnosis Procedure	612	
		BSW/BUZZER BRANCH LINE CIRCUIT	613	
		Diagnosis Procedure	613	
		LASER BRANCH LINE CIRCUIT	614	
		Diagnosis Procedure	614	
		SONAR BRANCH LINE CIRCUIT	615	
		Diagnosis Procedure	615	

DAST 1 BRANCH LINE CIRCUIT	616	CAN COMMUNICATION CIRCUIT 2	620
Diagnosis Procedure	616	Diagnosis Procedure	620
LANE BRANCH LINE CIRCUIT	617	CHASSIS COMMUNICATION CIRCUIT	622
Diagnosis Procedure	617	Diagnosis Procedure	622
CAN COMMUNICATION CIRCUIT 1	618	ITS COMMUNICATION CIRCUIT	624
Diagnosis Procedure	618	Diagnosis Procedure	624

HOW TO USE THIS MANUAL

HOW TO USE THIS SECTION

Information

INFOID:000000009755444

- “CAN FUNDAMENTAL” of LAN Section describes the basic knowledge of the CAN communication system and the method of trouble diagnosis.
- For information peculiar to a vehicle and inspection procedure, refer to “CAN”.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

PRECAUTION

PRECAUTIONS

Precautions for Trouble Diagnosis

INFOID:000000009755435

CAUTION:

Follow the instructions listed below. Failure to do this may cause damage to parts:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.
- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.


Precautions for Harness Repair

INFOID:000000009755436

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

SYSTEM DESCRIPTION

SYSTEM

CAN COMMUNICATION SYSTEM

CAN COMMUNICATION SYSTEM : System Description

INFOID:000000009755445


CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DIAG ON CAN

DIAG ON CAN : System Description

INFOID:000000009755446

SYSTEM DIAGRAM



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

SYSTEM

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

Name	Harness	Description
DDL1	Tx Rx	For communications with the diagnostic tool. (CAN-H and CAN-L are used for controlling)
DDL2	K-LINE	For communications with the diagnostic tool. (CAN-H and CAN-L are used for controlling)
Diag on CAN	CAN-H CAN-L	For communications with the diagnostic tool. (CAN-H and CAN-L are also used for control and diagnoses.)


DESCRIPTION

“Diag on CAN” is a diagnosis method which uses the CAN communication line for the communication between the control unit and the diagnostic tool.

TROUBLE DIAGNOSIS

Component Description

INFOID:000000009755447



Component	Description
Main line	CAN communication line between splices
Branch line	CAN communication line between splice and a control unit
Splice	A point connecting a branch line with a main line
Termination circuit	Circuit connected across the CAN communication system. (Resistor)

Condition of Error Detection

INFOID:000000009755448

DTC (e.g. U1000 and U1001) of CAN communication is indicated on SELF-DIAG RESULTS on CONSULT if a CAN communication signal is not transmitted or received between units for 2 seconds or more.

CAN COMMUNICATION SYSTEM ERROR

- CAN communication line open (CAN-H, CAN-L, or both)
- CAN communication line short (ground, between CAN communication lines, other harnesses)
- Error of CAN communication control circuit of the unit connected to CAN communication line

WHEN DTC OF CAN COMMUNICATION IS INDICATED EVEN THOUGH CAN COMMUNICATION SYSTEM IS NORMAL

- Removal/installation of parts: Error may be detected when removing and installing CAN communication unit and related parts while turning the ignition switch ON. (A DTC except for CAN communication may be detected.)
- Fuse blown out (removed): CAN communication of the unit may cease.
- Voltage drop: Error may be detected if voltage drops due to discharged battery when turning the ignition switch ON (Depending on the control unit which carries out CAN communication).
- Error may be detected if the power supply circuit of the control unit, which carries out CAN communication, malfunctions (Depending on the control unit which carries out CAN communication).
- Error may be detected if reprogramming is not completed normally.

NOTE:

CAN communication system is normal if DTC of CAN communication is indicated on SELF-DIAG RESULTS of CONSULT under the above conditions. Erase the memory of the self-diagnosis of each control unit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

Symptom When Error Occurs in CAN Communication System

INFOID:000000009755449


In CAN communication system, multiple control units mutually transmit and receive signals. Each control unit cannot transmit and receive signals if any error occurs on CAN communication line. Under this condition, multiple control units related to the root cause malfunction or go into fail-safe mode.

ERROR EXAMPLE

NOTE:

Each vehicle differs in symptom of each control unit under fail-safe mode and CAN communication line wiring.

Example: Main Line Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Open Circuit




Unit name	Major symptom
ECM	Engine torque limiting is affected, and shift harshness increases.
BCM	<ul style="list-style-type: none"> • Reverse warning buzzer does not sound. • The front wiper moves under continuous operation mode even though the front wiper switch being in the intermittent position.
EPS control unit	The steering effort increases.
Combination meter	<ul style="list-style-type: none"> • The shift position indicator and OD OFF indicator turn OFF. • The speedometer is inoperative. • The odo/trip meter stops.
ABS actuator and electric unit (control unit)	Normal operation.
TCM	No impact on operation.
IPDM E/R	When the ignition switch is ON, <ul style="list-style-type: none"> • The headlamps (Lo) turn ON. • The cooling fan continues to rotate.

TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

Example: TCM Branch Line Open Circuit




Unit name	Major symptom
ECM	Engine torque limiting is affected, and shift harshness increases.
BCM	Reverse warning buzzer does not sound.
EPS control unit	Normal operation.
Combination meter	<ul style="list-style-type: none"> • Shift position indicator and O/D OFF indicator turn OFF. • Warning lamps turn ON.
ABS actuator and electric unit (control unit)	Normal operation.
TCM	No impact on operation.
IPDM E/R	Normal operation.

NOTE:

The model (all control units on CAN communication system are Diag on CAN) cannot perform CAN diagnosis with CONSULT if the following error occurs. The error is judged by the symptom.

Error	Difference of symptom
Data link connector branch line open circuit	Normal operation.
CAN-H, CAN-L harness short-circuit	Most of the control units which are connected to the CAN communication system enter fail-safe mode or are deactivated.

Example: Data Link Connector Branch Line Open Circuit



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >


[CAN FUNDAMENTAL]

Unit name	Major symptom
ECM	Normal operation.
BCM	
EPS control unit	
Combination meter	
ABS actuator and electric unit (control unit)	
TCM	
IPDM E/R	

NOTE:

When data link connector branch line is open, transmission and reception of CAN communication signals are not affected. Therefore, no symptoms occur. However, be sure to repair malfunctioning circuit.

Example: CAN-H, CAN-L Harness Short Circuit



Unit name	Major symptom
ECM	<ul style="list-style-type: none"> • Engine torque limiting is affected, and shift harshness increases. • Engine speed drops.
BCM	<ul style="list-style-type: none"> • Reverse warning buzzer does not sound. • The front wiper moves under continuous operation mode even though the front wiper switch being in the intermittent position. • The room lamp does not turn ON. • The engine does not start (if an error or malfunction occurs while turning the ignition switch OFF.) • The steering lock does not release (if an error or malfunction occurs while turning the ignition switch OFF.)
EPS control unit	The steering effort increases.
Combination meter	<ul style="list-style-type: none"> • The tachometer and the speedometer do not move. • Warning lamps turn ON. • Indicator lamps do not turn ON.
ABS actuator and electric unit (control unit)	Normal operation.
TCM	No impact on operation.
IPDM E/R	When the ignition switch is ON, <ul style="list-style-type: none"> • The headlamps (Lo) turn ON. • The cooling fan continues to rotate.

CAN Diagnosis with CONSULT

INFOID:000000009755450

CAN diagnosis on CONSULT extracts the root cause by receiving the following information.

TROUBLE DIAGNOSIS

[CAN FUNDAMENTAL]

< SYSTEM DESCRIPTION >

- Response to the system call
- Control unit diagnosis information
- Self-diagnosis
- CAN diagnostic support monitor

Self-Diagnosis

INFOID:000000009755451

If communication signals cannot be transmitted or received among control units communicating via CAN communication line, CAN communication-related DTC is displayed on the CONSULT "Self Diagnostic Result" screen.

NOTE:

The following table shows examples of CAN communication-related DTC. For other DTC, refer to the applicable sections.

DTC	Self-diagnosis item (CONSULT indication)	DTC detection condition		Inspection/Action
U1000	CAN COMM CIRCUIT	ECM	When ECM is not transmitting or receiving CAN communication signal of OBD (emission-related diagnosis) for 2 seconds or more.	Start the inspection. Refer to the applicable section of the indicated control unit.
		Except for ECM	When a control unit (except for ECM) is not transmitting or receiving CAN communication signal for 2 seconds or more.	
U1001	CAN COMM CIRCUIT	When ECM is not transmitting or receiving CAN communication signal other than OBD (emission-related diagnosis) for 2 seconds or more.		
U1002	SYSTEM COMM	When a control unit is not transmitting or receiving CAN communication signal for 2 seconds or less.		
U1010	CONTROL UNIT(CAN)	When an error is detected during the initial diagnosis for CAN controller of each control unit.		

CAN Diagnostic Support Monitor

INFOID:000000009755452

MONITOR ITEM (CONSULT)

Example: CAN DIAG SUPPORT MNTR indication

Without PAST				With PAST			
BCM				ENGINE			
MONITOR ITEM	PRESENT	PAST		MONITOR ITEM	PRESENT	PAST	
INITIAL DIAG	OK	-		TRANSMIT DIAG	OK	OK	
TRANSMIT DIAG	OK	-		VDC/TCS/ABS	OK	5	
ECM	OK	-		METER/M&A	Not diagnosed	-	
METER/M&A	OK	-		BCM/SEC	OK	OK	
TCM	OK	-		ICC	Not diagnosed	-	
IPDM E/R	OK	-		HVAC	Not diagnosed	-	
I-KEY	OK	-		TCM	OK	OK	
				EPS	OK	OK	
				IPDM E/R	OK	5	
				e4WD	Not diagnosed	-	
				AWD/4WD	Not diagnosed	-	

JSMIA0964GB

Without PAST

Item	PRESENT	Description
Initial diagnosis	OK	Normal at present
	NG	Control unit error (Except for some control units)

TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

Item	PRESENT	Description
Transmission diagnosis	OK	Normal at present
	UNKWN	Unable to transmit signals for 2 seconds or more.
		Diagnosis not performed
Control unit name (Reception diagnosis)	OK	Normal at present
	UNKWN	Unable to receive signals for 2 seconds or more.
		Diagnosis not performed
		No control unit for receiving signals. (No applicable optional parts)

With PAST

Item	PRESENT	PAST	Description
Transmission diagnosis	OK	OK	Normal at present and in the past
		1 – 39	Normal at present, but unable to transmit signals for 2 seconds or more in the past. (The number indicates the number of ignition switch cycles from OFF to ON.)
	UNKWN	0	Unable to transmit signals for 2 seconds or more at present.
Control unit name (Reception diagnosis)	OK	OK	Normal at present and in the past
		1 – 39	Normal at present, but unable to receive signals for 2 seconds or more in the past. (The number indicates the number of ignition switch cycles from OFF to ON.)
	UNKWN	0	Unable to receive signals for 2 seconds or more at present.
	Not diagnosed	-	-
-			No control unit for receiving signals. (No applicable optional parts)

TROUBLE DIAGNOSIS

< SYSTEM DESCRIPTION >

[CAN FUNDAMENTAL]

How to Use CAN Communication Signal Chart

INFOID:000000009755453

The CAN communication signal chart lists the signals transmitted/received among control units. It is useful for detecting the root cause by finding a signal related to the symptom, and by checking transmission and reception unit.


Example: Tachometer does not move even though the engine rotates.

T: Transmit R: Receive

Signal name/Connecting unit	ECM	BCM	M&A	STRG	ABS	IPDM-E
A/C compressor feedback signal	T		R			
A/C compressor request signal	T					R
Accelerator pedal position signal	T				R	
Cooling fan motor operation signal	T					R
Engine coolant temperature signal	T		R			
Engine speed signal	T		R		R	
Fuel consumption monitor signal	T		R			
Malfunction indicator lamp signal	T		R			
A/C switch signal	R	T				
Ignition switch signal		T				R
Sleep/wake up signal		T	R			R

No communication between ECM and M&A (Combination meter).

It indicates that an error occurs between ECM and Combination meter (Shaded area).



JSMIA0446GB

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


LAN

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Trouble Diagnosis Flow Chart

INFOID:000000009239056



Trouble Diagnosis Procedure

INFOID:000000009755454

INTERVIEW WITH CUSTOMER

Interview with the customer is important to detect the root cause of CAN communication system errors and to understand vehicle condition and symptoms for proper trouble diagnosis.

Points in interview

- What: Parts name, system name
- When: Date, Frequency
- Where: Road condition, Place
- In what condition: Driving condition/environment
- Result: Symptom

Notes for checking error symptoms:


- Check normal units as well as error symptoms.
- Example: Circuit between ECM and the combination meter is judged normal if the customer indicates tachometer functions normally.
- When a CAN communication system error is present, multiple control units may malfunction or go into fail-safe mode.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

- Indication of the combination meter is important to detect the root cause because it is the most obvious to the customer, and it performs CAN communication with many units.



INSPECTION OF VEHICLE CONDITION

Check whether the symptom is reproduced or not.

NOTE:

Do not turn the ignition switch OFF or disconnect the battery cable while reproducing the error. The error may temporarily correct itself, making it difficult to determine the root cause.

CHECK OF CAN SYSTEM TYPE (HOW TO USE CAN SYSTEM TYPE SPECIFICATION CHART)

Determine CAN system type based on vehicle equipment.

NOTE:

- This chart is used if CONSULT does not automatically recognize CAN system type.
- There are two styles for CAN system type specification charts. Depending on the number of available system types, either style A or style B may be used.

CAN System Type Specification Chart (Style A)

NOTE:

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

CAN system type is easily checked with the vehicle equipment identification information shown in the chart.

Example:
Vehicle is equipped as follows: Wagon, AWD, VQ35DE, CVT, VDC, and Intelligent Key system. (○ shows an example of CAN system type.)

CAN System Specification Chart
Determine CAN system type from the following specification chart.

Body type	Wagon					
Axle	2WD			AWD		
Engine	QR25DE		VQ35DE			
Transmission	A/T			CVT		
Brake control	ABS				VDC	
Intelligent Key system		×		×		×
CAN system type	1	2	3	4	5	6
CAN communication control unit						
ECM	×	×	×	×	×	×
AWD control unit					×	×
Air bag diagnosis sensor unit	×	×	×	×	×	×
BCM	×	×	×	×	×	×
Intelligent Key unit		×		×		×
Steering angle sensor					×	×
EPS control unit	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×
TCM	×	×	×	×	×	×
IPDM E/R	×	×	×	×	×	×

× : Applicable

VEHICLE EQUIPMENT IDENTIFICATION INFORMATION
NOTE:
Check CAN system type from the vehicle shape and equipment.

(A)

1. VDC OFF switch
A. With VDC

(B)

2. Ignition knob
B. With Intelligent Key system

For the above case, CAN system type is "6".

JSMIA0529GB

Check the vehicle equipment with the vehicle identification number plate.

Check the vehicle equipment.

The number indicates the CAN system type of the vehicle.

In the above example,

- Checking VDC OFF switch leads to judge whether or not VDC is equipped.
- Checking the ignition knob leads to judge whether or not Intelligent Key system is equipped.

CAN System Type Specification Chart (Style B)

NOTE:

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

CAN system type is easily checked with the vehicle equipment identification information shown in the chart.

Example:
Vehicle is equipped as follows: Sedan, 2WD, MR20DE, CVT, ABS, Active AFS, Intelligent Key system, Navigation system and Automatic drive positioner. (○ shows an example of CAN system type.)

CAN System Specification Chart
Refer to the specification as shown in the chart.

Body type	Sedan		
Axle	2WD		AWD
Engine	HR15DE	MR20DE	HR15DE
Transmission	A/T	CVT	A/T
Brake control		ABS	
Specification chart	XX.XX. SPECIFICATION CHART A.	XX.XX. SPECIFICATION CHART B.	XX.XX. SPECIFICATION CHART C.

×: Applicable

Check the vehicle equipment with the vehicle identification number plate.
Check the vehicle equipment.
Select the applicable vehicle equipment. Refer to the specification chart.

SPECIFICATION CHART B
Determine CAN system type from the following specification chart.

Body type	Sedan													
Axle	2WD													
Engine	MR20DE													
Transmission	CVT													
Brake control	ABS													
Active AFS		×			×	×			×	×		×	×	×
Intelligent Key system			×		×		×	×	×	×	×	×	×	×
Navigation system				×		×	×	×	×	×	×	×	×	×
Automatic drive positioner									×		×	×	×	×
CAN system type	9	10	11	12	13	14	15	16	17	18	19	20		
CAN communication control unit														
ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
AFS control unit		×			×	×				×	×		×	
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×

×: Applicable

Check the vehicle equipment.
The number indicates the CAN system type of the vehicle.

VEHICLE EQUIPMENT IDENTIFICATION INFORMATION
NOTE:
Check CAN system type from the vehicle shape and equipment.

In the above example,

- Checking Xenon bulb and bending lamp lead to judge whether or not Active AFS is equipped.
- Checking the ignition knob leads to judge whether or not Intelligent Key system is equipped.
- Checking display and multifunction switch lead to judge whether or not Navigation system is equipped.
- Checking seat memory switch leads to judge whether or not Automatic drive positioner is equipped.

1. Bending lamp 2. Xenon bulb 3. Ignition knob
4. Display 5. Multifunction switch 6. Seat memory switch
A. With active AFS B. With Intelligent Key system C. With navigation system
D. With automatic drive positioner

For the above case, CAN system type is "20".

JSMIA0530GB

CREATE INTERVIEW SHEET

Fill out the symptom described by the customer, vehicle condition, and CAN system type on the interview sheet.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[CAN FUNDAMENTAL]

Interview Sheet (Example)

CAN Communication System Diagnosis Interview Sheet	
Date received:	3, Feb. 2006
Type: DBA-KG11	VIN No.: KG11-005040
Model: BDRARGZG11EDA-E-J-	
First registration: 10, Jan. 2001	Mileage: 62,140
CAN system type: Type 19	
Symptom (Results from interview with customer)	
<ul style="list-style-type: none">· Headlamps suddenly turn ON while driving the vehicle.· The engine does not restart after stopping the vehicle and turning the ignition switch OFF.· The cooling fan continues rotating while turning the ignition switch ON.	
Condition at inspection	
Error Symptom: Present / Past	
<p>The engine does not start.</p> <p>While turning the ignition switch ON,</p> <ul style="list-style-type: none">· The headlamps (Lo) turn ON, and the cooling fan continues rotating.· The interior lamp does not turn ON.	

JSMA0531GB

DETECT THE ROOT CAUSE

CAN diagnosis function of CONSULT detects the root cause.

HOW TO USE THIS SECTION

< HOW TO USE THIS MANUAL >

[CAN]

HOW TO USE THIS MANUAL

HOW TO USE THIS SECTION

Information

INFOID:000000009239058

- “CAN” of LAN Section describes information peculiar to a vehicle and inspection procedures.
- For trouble diagnosis procedure, refer to [LAN-26, "Trouble Diagnosis Flow Chart"](#) of “CAN FUNDAMENTAL”.

Abbreviation List

INFOID:000000009239059

Unit name abbreviations in CONSULT CAN diagnosis and in this section are as per the following list.

Abbreviation	Unit name
4WD	AWD control unit
A-BAG	Air bag diagnosis sensor unit
ABS	ABS actuator and electric unit (control unit)
ADP	Driver seat control unit
AFS	AFS control unit
APA	Accelerator pedal actuator
AV	Display control unit
AVM	Around view monitor control unit
BCM	BCM
BSW/BUZZER	Driver assistance buzzer control module
CCM	Chassis control module
CGW	CAN gateway
DAST1	Steering angle main control module
DLC	Data link connector
ECM	ECM
EPS/DAST3	Steering force control module
HBA	High beam assist control module
HVAC	A/C auto amp.
ICC	ADAS control unit
IPDM-E	IPDM E/R
LANE	Lane camera unit
LASER	ICC sensor
M&A	Combination meter
PSB	Pre-crash seat belt control unit (driver side)
RDR-L	Side radar LH
RDR-R	Side radar RH
SONAR	Sonar control unit
STRG	Steering angle sensor
TCM	TCM
TCU	TCU

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009239060

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions for Trouble Diagnosis

INFOID:000000009239061

CAUTION:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.
- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.


Precautions for Harness Repair

INFOID:000000009239062

- Solder the repaired area and wrap tape around the soldered area.

NOTE:

A fray of twisted lines must be within 110 mm (4.33 in).



PRECAUTIONS


[CAN]

< PRECAUTION >

- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

COMPONENT PARTS

[CAN]


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009239063



COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CAN]

① Lane camera unit	② High beam assist control module	③ IPDM E/R	A
④ ICC sensor	⑤ TCM	⑥ Steering angle main control module	
⑦ ABS actuator and electric unit (control unit)	⑧ BCM	⑨ Chassis control module	B
⑩ AWD control unit	⑪ Driver seat control unit	⑫ Pre-crash seat belt control unit (driver side)	
⑬ Side radar LH	⑭ ADAS control unit	⑮ Side radar RH	C
⑯ Around view monitor control unit	⑰ AFS control unit	⑱ Steering force control module	
⑲ ECM	⑳ Driver assistance buzzer control module	㉑ Display control unit	D
㉒ Combination meter	㉓ CAN gateway	㉔ Data link connector	
㉕ Accelerator pedal actuator	㉖ Steering angle sensor	㉗ TCU	E
㉘ Air bag diagnosis sensor unit	㉙ A/C auto amp.	㉚ Sonar control unit	
			F
			G
			H
			I
			J
			K
			L
			LAN
			N
			O
			P

< SYSTEM DESCRIPTION >

SYSTEM


CAN COMMUNICATION SYSTEM

CAN COMMUNICATION SYSTEM : System Description

INFOID:000000009725747

SYSTEM DIAGRAM

Without Around View Monitor




SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

With Around View Monitor, Without ICC




A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

< SYSTEM DESCRIPTION >

With ICC



DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.


CAN Communication Signal Generation

SYSTEM

[CAN]

< SYSTEM DESCRIPTION >


- Termination circuits (resistors) are connected across the CAN communication system. When transmitting a CAN communication signal, each control unit passes a current to the CAN-H line and the current returns to the CAN-L line.




- The current flows separately into the termination circuits connected across the CAN communication system and the termination circuits drop voltage to generate a potential difference between the CAN-H line and the CAN-L line.

NOTE:


A signal with no current passage is called "Recessive" and one with current passage is called "Dominant".



- The system produces digital signals for signal communications, by using the potential difference.



The Construction of CAN Communication Signal (Message)




A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

No.	Message name	Description
1	Start of frame (1 bit)	Start of message.
2	Arbitration of field (11 bit)	Priorities of message-sending are shown when there is a possibility that multiple messages are sent at the same time.
3	Control field (6 bit)	Signal quantity in data field is shown.
4	Data field (0-64 bit)	Actual signal is shown.
5	CRC field (16 bit)	<ul style="list-style-type: none"> The transmitting control unit calculates sending data in advance and writes the calculated value in a message. The receiving control unit calculates received data and judges that the data reception is normal when the calculated value is the same as the value written in the sent data.
6	ACK field (2 bit)	The completion of normal reception is sent to the transmitting unit.
7	End of frame (7 bit)	End of message.

CAN Communication Line


The CAN communication line is a twisted pair wire consisting of strands of CAN-H ① and CAN-L ② and has noise immunity.



NOTE:

The CAN communication system has the characteristics of noise-resistant because this system produces digital signals by using the potential difference between the CAN-H line and the CAN-L line and has the twisted pair wire structure.

Since the CAN-H line and the CAN-L line are always adjacent to each other, the same degree of noise occurs, respectively, when a noise ① occurs. Although the noise changes the voltage, the potential difference ② between the CAN-H line and the CAN-L line is insensitive to noise. Therefore, noise-resistant signals can be obtained.



CAN Signal Communications


Each control unit of the CAN communication system transmits signals through the CAN communication control circuit included in the control unit and receives only necessary signals from each control unit to perform various kinds of control.

SYSTEM


[CAN]

< SYSTEM DESCRIPTION >

• Example: Transmitted signals



• Example: Received signals



NOTE:

The above signal names and signal communications are provided for reference purposes. For CAN communications signals of this vehicle, refer to [LAN-44. "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

SYSTEM


< SYSTEM DESCRIPTION >

[CAN]

CAN COMMUNICATION SYSTEM : CAN Communication Control Circuit

INFOID:000000009725746

CAN communication control circuit is incorporated into the control unit and transmits/receives CAN communication signals.



Component	System description
CAN controller	It controls CAN communication signal transmission and reception, error detection, etc.
Transceiver IC	It converts digital signal into CAN communication signal, and CAN communication signal into digital signal.
Noise filter	It eliminates noise of CAN communication signal.
Termination circuit* (Resistance of approx. 120 Ω)	Generates a potential difference between CAN-H and CAN-L.

*: These are the only control units wired with both ends of CAN communication system.

CAN COMMUNICATION SYSTEM : CAN System Specification Chart

INFOID:000000009239064

Determine CAN system type from the following specification chart.

NOTE:

Refer to [LAN-26, "Trouble Diagnosis Procedure"](#) for how to use CAN system specification chart.

Body type	Sedan													
	2WD						AWD							
Axle														
Engine	VQ37VHR													
Transmission	A/T													
Brake control	VDC													
Telematics system		×		×		×		×		×		×	×	×
Direct adaptive steering			×	×	×	×	×	×			×	×	×	×
Automatic drive positioner					×	×	×	×					×	×
ICC system							×	×						×
CAN system type	1	2	3	4	13	5	14	6	7	8	9	10	11	12
CAN communication unit														
ECM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Data link connector	×	×	×	×	×	×	×	×	×	×	×	×	×	×
IPDM E/R	×	×	×	×	×	×	×	×	×	×	×	×	×	×
TCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
CAN gateway					×	×	×	×					×	×

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

Body type	Sedan													
Axle	2WD							AWD						
Engine	VQ37VHR													
Transmission	A/T													
Brake control	VDC													
Telematics system		×		×		×		×		×		×	×	×
Direct adaptive steering			×	×	×	×	×	×			×	×	×	×
Automatic drive positioner					×	×	×	×					×	×
ICC system							×	×						×
CAN system type	1	2	3	4	13	5	14	6	7	8	9	10	11	12
A/C auto amp.	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Combination meter	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Air bag diagnosis sensor unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×
AFS control unit							×	×						×
Display control unit	×	×	×	×	×	×	×	×	×	×	×	×	×	×
High beam assist control module							×	×						×
TCU		×		×		×		×		×		×	×	×
BCM	×	×	×	×	×	×	×	×	×	×	×	×	×	×
ABS actuator and electric unit (control unit)	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Driver seat control unit					×	×	×	×					×	×
Pre-crash seat belt control unit							×	×						×
ADAS control unit							×	×						×
Steering force control module			×	×	×	×	×	×			×	×	×	×
AWD control unit									×	×	×	×	×	×
Chassis control module	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Steering angle sensor	×	×	×	×	×	×	×	×	×	×	×	×	×	×
Side radar LH							×	×						×
Side radar RH							×	×						×
Around view monitor control unit					×	×	×	×					×	×
Accelerator pedal actuator							×	×						×
Driver assistance buzzer control module							×	×						×
Sonar control unit					×	×	×	×					×	×
ICC sensor							×	×						×
Steering angle main control module			×	×	×	×	×	×			×	×	×	×
Lane camera unit							×	×						×
ITS communication unit														
ADAS control unit							×	×						×
Side radar LH							×	×						×
Side radar RH							×	×						×
Around view monitor control unit					×	×	×	×					×	×
Accelerator pedal actuator							×	×						×
Driver assistance buzzer control module							×	×						×
Sonar control unit					×	×	×	×					×	×
ICC sensor							×	×						×
Chassis communication unit														

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

SYSTEM

[CAN]

< SYSTEM DESCRIPTION >


Body type	Sedan													
Axle	2WD						AWD							
Engine	VQ37VHR													
Transmission	A/T													
Brake control	VDC													
Telematics system		×		×		×		×		×		×	×	×
Direct adaptive steering			×	×	×	×	×	×			×	×	×	×
Automatic drive positioner					×	×	×	×					×	×
ICC system							×	×						×
CAN system type	1	2	3	4	13	5	14	6	7	8	9	10	11	12
Steering angle main control module			×	×	×	×	×	×			×	×	×	×
Lane camera unit							×	×						×

×: Applicable

VEHICLE EQUIPMENT IDENTIFICATION INFORMATION

NOTE:

Check CAN system type from the vehicle shape and equipment.



- ① Telematics switch
- ② Power steering warning lamp
- ③ Seat memory switch
- ④ DISTANCE switch
- Ⓐ With telematics system
- Ⓑ With direct adaptive steering
- Ⓒ With automatic drive positioner
- Ⓓ With ICC system

CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart

INFOID:000000009239065

Refer to [LAN-25, "How to Use CAN Communication Signal Chart"](#) for how to use CAN communication signal chart.

NOTE:

Refer to [LAN-31, "Abbreviation List"](#) for the abbreviations of the connecting units.

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

T: Transmit R: Receive

Signal name	ECM	TCM	M&A	IPDM-E	BCM	AFS	HBA	A-BAG	AV	TCU	HVAC	CGW	STRG	4WD	ABS	PSB	ADP	EPS/DAST 3	ICC	CCM	SONAR	AVM
A/C compressor request signal	T			R																		
Accelerator pedal malfunction signal	T																			R		
Accelerator pedal position signal	T	R												R	R				R	R		
ASCD OD cancel request signal	T	R																				
ASCD operation signal	T	R																				
ASCD status signal	T		R																			
Closed throttle position signal	T	R																	R			
Cooling fan speed request signal	T			R																		
ECM malfunction signal	T																			R		
ECO drive indicator control signal	T		R																			
ECO pedal reaction force control signal	T																		R			
ECO pedal reaction force setting signal	T								R													
	R								T													
Engine and A/T integrated control signal	T	R																				
	R	T																				
Engine coolant temperature signal	T		R								R											
Engine speed signal	T	R	R			R								R	R				R	R	R	
Engine status signal	T		R		R				R	R									R			
Engine torque signal	T																				R	
Fuel consumption monitor signal	T		R						R													
Fuel filler cap warning display signal	T		R						R													
Brake pedal position switch	T																		R			
ICC prohibition signal	T																		R			
ICC steering switch signal	T																		R			
Malfunctioning indicator lamp signal	T		R							R												
Power generation command value signal	T			R																		
Stop lamp switch signal	T																		R			
		R			T																	
													R	T					R			
Wide open throttle position signal	T	R																				
A/T CHECK indicator lamp signal		T	R			R																

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

Signal name	ECM	TCM	M&A	IPDM-E	BCM	AFS	HBA	A-BAG	AV	TCU	HVAC	CGW	STRG	4WD	ABS	PSB	ADP	EPS/DAST3	ICC	CCM	SONAR	AVM
A/T self-diagnosis signal	R	T																				
Current gear position signal	R	T													R				R	R		
Input speed signal		T																	R			
Manual mode shift refusal signal		T	R																			
N range signal		T			R																	
NAVI shift control indication request signal	R	T																				
	T								R													
NAVI shift control status signal		T							R													
Next gear position signal	R	T																				
Output shaft revolution signal	R	T																	R			
P range signal		T			R																	
Shift position signal		T	R		R	R			R						R		R	R	R	R		
Shift schedule signal	R	T																				
TCM malfunction signal		T																			R	
Brake fluid level switch signal			T												R							
Combination meter malfunction signal			T																		R	
Distance to empty signal			T						R													
Fuel filler cap warning reset signal	R		T																			
Fuel level low warning signal			T						R													
Fuel level sensor signal	R		T																			
Manual mode downshift signal		R	T																			
Manual mode signal		R	T																			
Manual mode upshift signal		R	T																			
Market information signal			T																		R	
Non-manual mode signal		R	T																			
Odometer signal			T		R	R	R											R				
Paddle shifter downshift signal*2		R	T																			
Paddle shifter upshift signal*2		R	T																			
Parking brake switch signal			T		R				R					R	R				R	R		
Seat belt buckle switch signal (driver side)			T		R																	
Vehicle speed signal	R	R	T	R	R	R	R		R		R					R	R					
			R		R										T		R		R	R		R
A/C compressor feedback signal	R			T							R											

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

Signal name	ECM	TCM	M&A	IPDM-E	BCM	AFS	HBA	A-BAG	AV	TCU	HVAC	CGW	STRG	4WD	ABS	PSB	ADP	EPS/DAST 3	ICC	CCM	SONAR	AVM	A
Detention switch signal				T	R												R						B
Front wiper stop position signal				T	R																		C
High beam status signal	R			T			R																D
Hood switch signal				T	R																		E
Low beam status signal	R			T		R	R																F
Push-button ignition switch status signal				T	R																		G
BCM malfunction signal					T																R		H
Blower fan motor switch signal	R				T																		I
Buzzer output signal			R		T																		J
			R														T						K
Daytime running light request signal				R	T																		L
Dimmer signal			R		T																R		M
Door lock status signal					T					R													N
Door switch signal			R	R	T												R	R					O
Door unlock signal					T												R						P
Front fog light request signal			R	R	T																		Q
Front wiper request signal				R	T																R	R ³	R
Handle position signal					T												R						R
High beam assist indicator lamp signal			R		T																		S
High beam request signal			R	R	T																		T
Horn reminder signal				R	T																		U
Ignition switch ON signal				R	T												R						V
				T	R																		W
Ignition switch signal					T												R	R					X
Interlock/PNP switch signal				R	T																		Y
				T	R																		Z
Low beam request signal				R	T																		AA
Low tire pressure warning lamp signal			R		T					R													AB
Key ID signal			R		T					R	R						R						AC
Meter display signal			R		T																		AD
			R																				AE
Meter ring illumination request signal			R		T																		AF
Oil pressure switch signal			R		T																		AG
				T	R					R													AH
Position light request signal			R	R	T																		AI

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

Signal name	ECM	TCM	M&A	IPDM-E	BCM	AFS	HBA	A-BAG	AV	TCU	HVAC	CGW	STRG	4WD	ABS	PSB	ADP	EPS/DAST3	ICC	CCM	SONAR	AVM
Rear window defogger control signal	R			R T	T				R													
Shipping mode status signal			R		T																	
Sleep wake up signal			R	R	T					R		R				R	R					
Starter control relay signal				R	T																	
Starter relay status signal			R	R T	T R																	
Starting mode signal					T												R					
Theft warning horn request signal				R	T																	
Tire pressure data signal			R		T				R													
TPMS malfunction warning lamp signal			R		T				R													
Trunk switch signal			R		T																	R
Turn indicator signal			R		T														R	R [*] ₃		
Turn signal switch signal ^{*3}					T														R	R	R	
AFS warning signal			R			T																
High beam assist request signal					R		T															
High beam assist system status signal					R		T															
Car crash information signal								T		R												
A/C switch operation signal									T		R											
AV system malfunction signal									T												R	
Camera switch signal									T													R
Curve signal		R							T													
Drive mode characteristics customizing signal									T												R	
Heated seat switch operation signal									T		R											
NAVI shift control switch signal		R							T													
Rear window defogger switch signal					R				T													
Road data signal		R							T													
System selection signal									T										R	R [*] ₃		
System setting signal					R				T								R					
					T				R													
User information signal			R						T		R						R		R	R		
Voice recognition signal									T		R											

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

Signal name	ECM	TCM	M&A	IPDM-E	BCM	AFS	HBA	A-BAG	AV	TCU	HVAC	CGW	STRG	4WD	ABS	PSB	ADP	EPS/DAST 3	ICC	CCM	SONAR	AVM			
Door lock/unlock request signal					R					T														A	
Sleep-ready signal					R					T														B	
				T	R																				C
Wake up signal					R					T															D
			T		R																				
A/C display signal				T	R																				E
A/C evaporator temperature signal	R								R		T														
A/C ON signal	R										T														F
Ambient sensor signal			R								T														
Ambient temperature signal*3											T									R	R	R			G
Blower fan ON signal	R										T														
Heated seat switch indicator signal									R		T														
Target A/C evaporator temperature signal	R										T														
Steering angle sensor malfunction signal						R							T		R	R		R	R						I
Steering angle sensor signal						R			R				T		R	R		R	R	R		R			J
															T					R					
Steering angle speed signal													T			R			R						
Steering calibration signal						R							T			R									
AWD warning lamp signal			R											T											
A/T shift schedule change demand signal		R													T										
ABS malfunction signal															T				R	R					
ABS operation signal		R													T	R			R	R					
ABS warning lamp signal			R							R					T				R						LAN
Brake fluid pressure signal															T					R					
Brake switch signal															T					R					
Brake warning lamp signal			R												T										N
			T							R															
Decel G signal															T					R					O
EBD operation signal															T					R					
Engine torque request signal	R														T										P
Front LH wheel speed signal														R	T				R		R				
Front RH wheel speed signal														R	T				R		R				
Rear LH wheel speed signal														R	T					R		R			

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

Signal name	ECM	TCM	M&A	IPDM-E	BCM	AFS	HBA	A-BAG	AV	TCU	HVAC	CGW	STRG	4WD	ABS	PSB	ADP	EPS/DAST3	ICC	CCM	SONAR	AVM
Rear RH wheel speed signal														R	T					R		R
Side G signal		R													T			R	R	R		
Stop lamp switch signal															T					R		
TCS gear keep request signal		R													T							
TCS malfunction signal															T				R	R		
TCS operation signal															T				R	R		
VDC malfunction signal															T				R	R		
VDC OFF indicator lamp signal			R												T							
VDC OFF switch signal															T				R	R		
VDC operation signal															T				R	R		
VDC warning lamp signal			R							R					T							
Yaw rate signal															T			R	R	R		
Direct Adaptive Steering malfunction signal						R									R [*] ₃			T	R [*] ₃	R [*] ₃	R [*] ₃	
Power steering warning lamp signal			R															T				
Steering pinion angle signal						R									R			T	R [*] ₃	R [*] ₃	R [*] ₃	
Steering torque signal	R																	T				
FEB warning lamp signal			R																T			
FEB operation signal																R			T			
ICC operation signal	R																		T	R [*] ₁		
ICC sensor signal ^{*3}																			T	R	R	
ICC warning lamp signal			R																T			
Active Lane Control display signal ^{*3}			R																	T		
Active Trace Control display signal			R																	T		
Active Trace Control signal															R					T		
Brake fold status signal															R					T		
Brake fluid pressure control signal															R					T		
Brake hold request signal															R					T		
Chassis control malfunction signal			R																	T		
Drive mode display signal									R											T		
Drive mode signal		R							R						R			R	R	T		
	R	T																	R			
Driver assistance buzzer signal																			R	T		

SYSTEM

< SYSTEM DESCRIPTION >

[CAN]

Signal name	ECM	TCM	M&A	IPDM-E	BCM	AFS	HBA	A-BAG	AV	TCU	HVAC	CGW	STRG	4WD	ABS	PSB	ADP	EPS/DAST 3	ICC	CCM	SONAR	AVM
Interrupt display signal			R																	T		
Key link signal			R						R		R						R		R	T		
Log-in permit signal			R						R		R						R		R	T		
Steering angle value command signal*3																		R		T		
Tire display signal			R																	T		
Turn display signal			R																	T		
Vehicle display signal			R																	T		
Sonar status signal																					T	R
MOD beep sound output request signal																					R	T
View change signal									R													T

*1: With ICC system

*2: Models with paddle shifter

*3: With Direct Adaptive Steering and Active Lane Control

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

[CAN]


< WIRING DIAGRAM >

WIRING DIAGRAM

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

Wiring Diagram

INFOID:000000009239066



CAN SYSTEM (WITHOUT AROUND VIEW MONITOR)

*: This connector is not shown in "Harness Layout".


2013/05/17

JRMWD9949GB

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]



JRMWD9950GB

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR)

Connector No.	E12
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
28	21	5	2	22	45	6	47	48	46							



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	
2	LG	
3	P	
4	V	
5	W	
6	V	
7	P	
8	LG	
9	LG	
10	P	
11	LG	
12	GR	
13	GR	
14	Y	
15	W	
16	B	
17	B	
18	B	
19	G	
20	W	
21	W	
22	W	
23	EG	
24	EG	
25	R	
26	R	
27	SB	
28	SB	
29	V	
30	V	
31	R	
32	R	
33	L	
34	B	
35	B	
36	EG	
37	GR	
38	GR	
39	P	
40	P	
41	SB	
42	BR	
43	EG	
44	EG	
45	R	
46	R	
47	SB	
48	SB	
49	V	
50	V	
51	R	
52	R	
53	W	
54	W	
55	W	
56	GR	
57	GR	
58	GR	
59	GR	
60	BR	
61	Y	
62	Y	
63	W	
64	W	
65	W	
66	W	
67	W	
68	B	
69	L	
70	L	
71	V	
72	V	
73	V	
74	BR	
75	BR	
76	B	
77	B	
78	B	
79	B	
80	B	
81	B	
82	B	
83	B	
84	L	
85	L	
86	B	
87	B	
88	G	

Connector No.	E18
Connector Name	WIRE TO WIRE
Connector Type	TH8BFW-CS16-TM4

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	
2	G	
3	L	

01	GR	
02	GR	
03	Y	
04	V	
05	V	
06	BR	
07	BR	
08	BR	
09	BR	
10	P	
11	BG	
12	LG	
13	GR	
14	Y	
15	W	
16	W	
17	B	
18	B	
19	G	
20	W	
21	W	
22	W	
23	EG	
24	EG	
25	R	
26	R	
27	SB	
28	SB	
29	V	
30	V	
31	R	
32	R	
33	L	
34	B	
35	B	
36	EG	
37	GR	
38	GR	
39	P	
40	P	
41	SB	
42	BR	
43	EG	
44	EG	
45	R	
46	R	
47	SB	
48	SB	
49	V	
50	V	
51	R	
52	R	
53	W	
54	W	
55	W	
56	GR	
57	GR	
58	GR	
59	GR	
60	BR	
61	Y	
62	Y	
63	W	
64	W	
65	W	
66	W	
67	W	
68	B	
69	L	
70	L	
71	V	
72	V	
73	V	
74	BR	
75	BR	
76	B	
77	B	
78	B	
79	B	
80	B	
81	B	
82	B	
83	B	
84	L	
85	L	
86	B	
87	B	
88	G	

Connector No.	E39
Connector Name	FUSE BLOCK (J1B)
Connector Type	TH10FB-NH

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	
2	GR	
3	Y	
4	V	
5	V	
6	BR	
7	BR	
8	BR	
9	BR	
10	P	
11	BG	
12	LG	
13	GR	
14	Y	
15	W	
16	W	
17	B	
18	B	
19	G	
20	W	
21	W	
22	W	
23	EG	
24	EG	
25	R	
26	R	
27	SB	
28	SB	
29	V	
30	V	
31	R	
32	R	
33	L	
34	B	
35	B	
36	EG	
37	GR	
38	GR	
39	P	

Connector No.	E600
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS

1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	
2	GR	
3	Y	
4	V	
5	V	
6	BR	
7	BR	
8	BR	
9	BR	
10	P	
11	BG	
12	LG	
13	GR	
14	Y	
15	W	
16	W	
17	B	
18	B	
19	G	
20	W	
21	W	
22	W	
23	EG	
24	EG	
25	R	
26	R	
27	SB	
28	SB	
29	V	
30	V	
31	R	
32	R	
33	L	
34	B	
35	B	
36	EG	
37	GR	
38	GR	
39	P	

21	--
22	--
23	--
24	--
25	--
26	--
27	--
28	--
29	--
30	--
31	--
32	--
33	--
34	--
35	--
36	--
37	--
38	--
39	--
40	--
41	--
42	--
43	--
44	--
45	--
46	--
47	--
48	--

Connector No.	E601
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH8BFW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
2	BR	URAT (TX/RX)
3	P	RECLINER SW (DOWNWARD)
4	P	PULSE (RECLINER)
5	V	PULSE TELESCOPIO
6	GY	ADDRESS 2
7	G	IND. 2
8	V	SLIDE SW (BACKWARD)
9	W	RECLINER SW (BACKWARD)
10	O	TILT SW (DOWNWARD)
11	G	LIFTER SW (DOWNWARD)
12	SB	POWER SUPPLY (ENCODER)
13	P	CAN-L
14	LG	PULSE (SLIDE SENSOR)
15	W	PULSE (LIFTER FRONT)
16	GY	PULSE (LIFTER REAR)
17	SB	PULSE (LIFTER SENSOR)
18	W	ADDRESS 1
19	W	IND. 1
20	GY	SLIDE SW (FORWARD)
21	SB	RECLINER SW (FORWARD)
22	W	TILT SW (UPWARD)
23	W	TILT SW (UPWARD)
24	P	LIFTER SW (UPWARD)
25	Y	
26	GY	
27	L	


CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR)


Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Type	SAA38MB-RSS-SHZ8



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L/Y	
2	SHIELD	
3	L/B	
4	SHIELD	
5	BR	
6	SB	
7	G	
8	W	
9	W	
10	Y	
11	P	
12	SB	
13	G	
14	G	
15	LG	
16	BR	
17	L	
18	P	
19	GR	
20	G	
21	V	
22	Y	
23	L	
24	GR	
25	V	
26	BR	
27	V	
28	BR	
29	R	
30	R	
31	P	
32	G	
33	B	


34	EG	-
35	G	-
36	W	-
37	SHIELD	-
38	L	-
39	P	-
40	R	-
41	W	-
42	LG	-
43	G	-
44	V	-
45	Y	-
46	SHIELD	-
47	W	-
48	BR	-
49	G	-
50	G	-
51	SB	-
52	R	-

Connector No.	E22
Connector Name	CHASSIS CONTROL MODULE
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	P	CAN-L [Without Gateway]
3	R	CAN-L [With Gateway]
4	L	CAN-H
5	V	DRIVE MODE SELECT SW (UP)
6	G	DRIVE MODE SELECT SW (DOWN)
7	W	CHASSIS COMM-L
8	W	CHASSIS COMM-L
10	G	CAN COMM-H
11	V	CAN COMM-H
12	B	CHASSIS COMM-H
13	L	CHASSIS COMM-H
14	L	
15	L	
16	L	
17	L	
18	P	
19	GR	
20	G	
21	V	
22	Y	
23	L	
24	GR	
25	V	
26	BR	
27	V	
28	BR	
29	R	
30	R	
31	P	
32	G	
33	B	


Connector No.	E25
Connector Name	WIRE TO WIRE
Connector Type	TH8FW-C516-TM



Terminal No.	Color Of Wire	Signal Name [Specification]
2	W	
3	BR	
4	GR	
5	SB	
6	V	
7	L	
10	BR	
11	L	
12	GR	
13	W	
14	B	
15	SB	
16	Y	
17	BR	
18	P	
31	GR	
32	GR	
35	GR	
36	R	
37	V	
38	L	
39	Y	
40	SB	
41	LG	
44	Y	
45	W	
46	B	
47	G	
48	SHIELD	
49	R	
51	PL	
52	W	
53	V	
54	P	
55	W	
56	W	
59	SB	

57	EG	-
58	W	-
59	V	-
61	R	-
64	Y	-
65	SB	-
66	GR	-
67	LG	-
68	EG	-
71	LG	-
72	V	-
73	G	-
74	BR	-
75	V	-
76	P	-
78	P	-
82	SB	-
83	SB	-
86	EG	-
81	G	-
92	Y	-
94	GR	-
95	EG	-
96	W	-
97	LG	-
98	L	-
99	P	-
100	SHIELD	-

Connector No.	E28
Connector Name	STEERING ANGLE MAIN CONTROL MODULE
Connector Type	RHZ4FE-R28-LH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	TORQUE SENSOR MAIN SIGNAL
2	SB	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (S)
3	LG	TORQUE SENSOR SUB SIGNAL
4	G	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (S)
5	W	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (S)
6	L	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (S)
7	SB	TORQUE SENSOR GROUND

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN


CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR)

Terminal No.	Color Of Wire	Signal Name [Specification]
10	B	VDC REF SW SIGNAL
11	P	VACUUM SENSOR GROUND
12	SHIELD	VACUUM SENSOR GROUND
13	G	IGN
14	L	IGN
15	W	CHASSIS COMMUNICATION-L
17	BG	BACK UP SIGNAL FROM STEERING ANGLE SENSOR CONTROL MODULE
18	SB	BACK UP SIGNAL FROM STEERING ANGLE SENSOR CONTROL MODULE
19	Y	FLEXRAY COMMUNICATION-H
20	GR	FLEXRAY COMMUNICATION-L
22	GR	BACK UP SIGNAL FROM STEERING ANGLE SENSOR CONTROL MODULE
23	BR	CAN WAKE UP
24	P	BACK UP SIGNAL TO STEERING FORCE CONTROL MODULE
25	G	EXTERIOR POWER SUPPLY FROM STEERING ANGLE SENSOR CONTROL MODULE
30	B	GROUND
32	GR	GROUND



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	GROUND
2	V	GROUND
3	L	GROUND
4	P	GROUND
7	L	GROUND
8	W	GROUND
13	G	GROUND
15	BR	GROUND
17	W	GROUND
18	G	GROUND
19	L	GROUND
22	BR	GROUND
23	Y	GROUND
24	R	GROUND
25	L	GROUND
28	W	GROUND
30	G	GROUND
31	Y	GROUND
32	LG	GROUND




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	B	GROUND
3	G	GROUND
4	Y	VALVE BATTERY
5	LG	MOTOR BATTERY
5	V	STOP LAMP SW SIGNAL (With IGC)
7	GR	STOP LAMP SW SIGNAL (With ASCD)
8	G	RR LH WHEEL SENSOR SIGNAL
9	BR	RR RH WHEEL SENSOR SIGNAL
10	GR	FR LH WHEEL SENSOR SIGNAL
11	GR	FR RH WHEEL SENSOR SIGNAL
13	R	VACUUM SENSOR SIGNAL
15	B	CHASSIS COMMUNICATION-L (With Gateway)
16	P	CHASSIS COMMUNICATION-H (With Gateway)
17	Y	RR RH WHEEL SENSOR SIGNAL
18	V	RR LH WHEEL SENSOR SIGNAL
19	SB	FR LH WHEEL SENSOR SIGNAL
20	BG	FR RH WHEEL SENSOR SIGNAL
25	L	CAN-H
28	G	VACUUM SENSOR POWER SUPPLY

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	GROUND
2	V	GROUND
3	L	GROUND
4	P	GROUND
7	L	GROUND
8	W	GROUND
13	G	GROUND
15	BR	GROUND
17	W	GROUND
18	G	GROUND
19	L	GROUND
22	BR	GROUND
23	Y	GROUND
24	R	GROUND
25	L	GROUND
28	W	GROUND
30	G	GROUND
31	Y	GROUND
32	LG	GROUND




Terminal No.	Color Of Wire	Signal Name [Specification]
19	G	GROUND
22	BG	GROUND
23	LG	GROUND
27	GR	GROUND
28	P	GROUND
29	L	GROUND
31	G	GROUND
33	SB	GROUND
34	Y	GROUND
35	G	GROUND
36	SB	GROUND
37	GR	GROUND
38	GR	GROUND
41	GR	GROUND
43	V	GROUND


Terminal No.	Color Of Wire	Signal Name [Specification]
19	G	GROUND
22	BG	GROUND
23	LG	GROUND
27	GR	GROUND
28	P	GROUND
29	L	GROUND
31	G	GROUND
33	SB	GROUND
34	Y	GROUND
35	G	GROUND
36	SB	GROUND
37	GR	GROUND
38	GR	GROUND
41	GR	GROUND
43	V	GROUND



Terminal No.	Color Of Wire	Signal Name [Specification]
10F	W	GROUND
11F	G	GROUND
12F	W	GROUND
13F	V	GROUND
22F	BR	GROUND
23F	P	GROUND
24F	L	GROUND
25F	R	GROUND
26F	L	GROUND
27F	L	GROUND
28F	L	GROUND
29F	L	GROUND




Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	IGNITION POWER SUPPLY
2	P	BATTERY POWER SUPPLY MEMORY BACK-UP
3	L	CAN-H
4	LG	GROUND
5	B	GROUND
6	GR	IGNITION POWER SUPPLY
7	BG	BACK-UP LAMP RELAY
8	P	CAN-L
9	GR	STARTER RELAY
10	B	GROUND




Terminal No.	Color Of Wire	Signal Name [Specification]
19	G	GROUND
22	BG	GROUND
23	LG	GROUND
27	GR	GROUND
28	P	GROUND
29	L	GROUND
31	G	GROUND
33	SB	GROUND
34	Y	GROUND
35	G	GROUND
36	SB	GROUND
37	GR	GROUND
38	GR	GROUND
41	GR	GROUND
43	V	GROUND

Terminal No.	Color Of Wire	Signal Name [Specification]
10F	W	GROUND
11F	G	GROUND
12F	W	GROUND
13F	V	GROUND
22F	BR	GROUND
23F	P	GROUND
24F	L	GROUND
25F	R	GROUND
26F	L	GROUND
27F	L	GROUND
28F	L	GROUND
29F	L	GROUND



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	IGNITION POWER SUPPLY
2	P	BATTERY POWER SUPPLY MEMORY BACK-UP
3	L	CAN-H
4	LG	GROUND
5	B	GROUND
6	GR	IGNITION POWER SUPPLY
7	BG	BACK-UP LAMP RELAY
8	P	CAN-L
9	GR	STARTER RELAY
10	B	GROUND



JRMWD9953GB


CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR)


Connector No.	F12
Connector Name	WIRE TO WIRE
Connector Type	SAAS08B-RSS-SUZS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	
2	SHIELD	
3	BR	
4	SHIELD	
5	BR	
6	GR	
7	G	
8	W	
9	W	
10	G	
11	R	
12	P	
13	L	
14	LG	
15	P	
16	Y	
17	Y	
18	P	
19	GR	
20	BG	
21	LG	
22	W	
23	Y	
24	LG	
25	V	
26	W	
27	V	
28	BR	
29	LG	
30	B	
31	B	
32	GR	
33	B	
34	BG	
35	LG	
36	SB	

37	SHIELD	-
38	Y	-
39	Y	-
40	G	-
41	B	-
42	GR	-
43	R	-
44	BG	-
45	Y	-
46	SHIELD	-
47	W	-
48	LG	-
49	L	-
50	R	-
51	SB	-
52	G	-

Connector No.	F100
Connector Name	TO TRANSMISSION CONTROL MODULE
Connector Type	SP10FG




Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	IGNITION POWER SUPPLY
2	-	BATTERY POWER SUPPLY/MEMORY BACK-UP
3	-	CAN-H
4	-	K-LINE
5	-	GROUND
6	-	IGNITION POWER SUPPLY
7	-	BACK-UP LAMP RELAY
8	-	CAN-L
9	-	STARTER RELAY
10	-	GROUND

Connector No.	M5
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	M5BXY-EX



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	IGN
2	Y	ASZ (+)
3	Y/R	BR1 (-)
4	Y/B	BR2 (-)
5	Y	BR2 (+)
6	Y/R	ASI (+)
7	Y/B	ASI (-)
8	Y/G	ASZ (+)
9	Y	ASZ (-)
18	Y	EC25+
19	BR	EC25-
20	Y/R	ACT_VENT+
21	Y/B	ACT_VENT-
22	SHIELD	GNL
23	V	AMBAG W/L
24	GR	AIR OIE IND
51	G	SATELLITE RH2 (+)
52	R	SIDE SENS RH2+
53	V	SIDE SENS LH2+
54	L	SIDE SENS LH2-
57	LG	IVGS
59	L	CAN-H
60	P	CAN-L

Connector No.	M4
Connector Name	BOM (BODY CONTROL MODULE)
Connector Type	M4BEB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
18	R	PUSH-BTN IGN SKULL PWR
52	G	COM LINE
53	Y	COM LINE
55	R	RAIN SENSOR
59	P	CAN-L
60	L	CAN-H
61	G	REAR WINDOW DEF RLY CONT
62	R	STARTER RLY CONT
64	V	I-KEY WARM BUZZER
65	B	OUTS HD LAMP CONT
66	B	BLOWER FAN RLY CONT
67	W/B	IGN RLYAY (F/B) CONT
68	R	DIMMER
69	GR	A.T. SHIFT SELECT PWR SPLY
70	B	IGN RELAY (UPDR) RLY CONT
71	G	PASS LOCK SW
72	SB	PASS LOCK SW
75	BR	COMBI SW INPUT 3
76	BG	COMBI SW INPUT 4
77	V	COMBI SW INPUT 3
78	Y	COMBI SW INPUT 2
79	LG	COMBI SW INPUT 1
80	L	TR LID CORNER SW

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]


CAN SYSTEM (WITHOUT AROUND VIEW MONITOR)

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	T1188MM-CSS16-TM4




63	BR	-
64	W	-
65	W	-
70	LG	-
71	W	-
72	B	-
74	L	-
75	W	-
76	BR	-
77	B	-
81	B	-
83	BG	-
84	L	-
85	W	-
86	G	-
87	G	-
89	GR	-
84	GR	-
96	W	-
97	V	-
98	BR	-

Connector No.	M25
Connector Name	DATA LINK CONNECTOR
Connector Type	B018FW




Terminal No.	Color Of Wire	Signal Name [Specification]
3	SB	AV COMM (L)
4	B	EARTH
5	B	EARTH
6	L	CAN-H
7	W	RESERVE
8	LG	AV COMM (W)
12	R	CAN-H
13	L	CAN-H
14	P	CAN-L
16	W	POWER

Connector No.	M37
Connector Name	ECM
Connector Type	RH24FG-R2B-FL-L-Z



Terminal No.	Color Of Wire	Signal Name [Specification]
88	BR	ACCELERATOR PEDAL POSITION SENSOR 1
89	BR	ACCELERATOR PEDAL POSITION SENSOR 2
89	W	SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR)
100	G	SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 1)
101	G	ASD STEERING SWITCH
101	SB	ICD STEERING SWITCH
102	LG	EVAP CONTROL SYSTEM PRESSURE SENSOR
103	L	SENSOR POWER SUPPLY (ANGLENT PEDAL POSITION SENSOR)
104	R	SENSOR GROUND (ANGLENT PEDAL POSITION SENSOR 2)
105	L	REFRIGERANT PRESSURE SENSOR
106	P	FUEL TANK TEMPERATURE SENSOR
107	GR	SENSOR GROUND (FUEL TANK TEMPERATURE SENSOR)
108	Y	SENSOR GROUND (ASD STEERING SWITCH)
109	BR	TRANSMISSION RANGE SWITCH
110	Y	ENGINE STOP SWITCH
112	V	CHD PRESSURE SWITCH
113	P	CAN COMMUNICATION LINE
114	L	CAN COMMUNICATION LINE
117	V	DATA LINK CONNECTOR
121	LG	EVAP CANISTER VENT CONTROL VALVE
122	B	STOP LAMP SWITCH
123	B	ECM GROUND
124	B	ECM GROUND
125	R	POWER SUPPLY FOR ECM
126	BG	BRAKE PEDAL POSITION SWITCH
127	B	ECM GROUND
128	B	ECM GROUND

Connector No.	M39
Connector Name	WIRE TO WIRE
Connector Type	T1182FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	BR	-
3	LG	-
3	SB	-
4	P	-
4	R	- [Without Gateway]
4	R	- [With Gateway]
7	L	-
8	W	-
13	G	-
15	R	-
17	BR	-
18	BG	-
27	LG	-
28	BR	-
29	W/B	-
30	W	-
31	W	-
32	LG	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Type	T1188MM-CSS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	-
3	L	-
4	V	-

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >


[CAN]

CAN SYSTEM (WITHOUT AROUND VIEW MONITOR)

9	W/B	-	-
10	W	-	-
11	W	-	-
12	B	-	-
13	GR	-	-
14	B	-	-
15	SB	-	-
16	B	-	-
17	LG	-	-
18	B	-	-
31	W	-	-
32	V	-	-
35	BG	-	-
36	G	-	-
37	B	-	-
38	L	-	-
39	Y	-	-
40	GR	-	-
41	L	-	-
44	BR	-	-
45	W	-	-
46	G	-	-
47	R	-	-
48	SHIELD	-	-
49	B	-	-
50	BR	-	-
51	L	-	-
52	W	-	-
53	G	-	-
54	L	-	-
55	P	-	-
56	BG	-	-
57	GR	-	-
58	B	-	-
59	SB	-	-
61	W/B	-	-
64	Y	-	-
65	R	-	-
66	V	-	-
67	LG	-	-
68	BG	-	-
71	V	-	-
72	LG	-	-
73	G	-	-
74	BR	-	-
75	B	-	-
78	G	-	-
79	R	-	-
83	R	-	-

88	V	-	-
89	R	-	-
92	R	-	-
94	BG	-	-
95	BR	-	-
96	W	-	-
97	LG	-	-
98	Y	-	-
99	BR	-	-
100	SHIELD	-	-

Connector No.	M42
Connector Name	AWD CONTROL UNIT
Connector Type	TH18PW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	AWD SOL (+)
2	Y	AWD SOL (-)
3	W/B	FLUID TEMP (-)
4	L	FLUID TEMP (+)
5	G	AWD SOL
6	W	AWD SOL BAT
7	B	GND
8	BG	GND
9	B	GND
10	B	GND
11	B	GND
13	LG	FLUID TEMP (+)
15	W	FLUID TEMP (-)
16	P	BATTERY POWER SUPPLY
16	R	CAN-L [Without Gateway]
16	R	CAN-L [With Gateway]

Connector No.	M58
Connector Name	COMBINATION METER
Connector Type	TH18PW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
41	L	CAN-H
42	W	CAN-L
43	B	ILLUMINATION CONTROL SIGNAL
44	Y	FUEL LEVEL SENSOR GROUND
45	W	BATTERY POWER SUPPLY
46	R	IGNITION SIGNAL
47	LG	AV COMMUNICATION SIGNAL (H)
48	SB	AV COMMUNICATION SIGNAL (L)
51	BR	FUEL LEVEL SENSOR SIGNAL
52	B	GROUND

Connector No.	M71
Connector Name	STEERING FORCE CONTROL MODULE
Connector Type	PH24FB-R22L-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	P	STEERING FORCE MOTOR RESOLVET SIGNAL (H-SS)
4	W	STEERING FORCE MOTOR RESOLVET SIGNAL (H-SS)
5	G	STEERING FORCE MOTOR RESOLVET SIGNAL (H-SS)
6	G	STEERING FORCE MOTOR RESOLVET SIGNAL (H-SS)
7	G	STEERING FORCE MOTOR RESOLVET SIGNAL (H-SS)
8	B	STEERING FORCE MOTOR RESOLVET SIGNAL (H-SS)
9	B	STEERING FORCE MOTOR RESOLVET SIGNAL (H-SS)
10	B	STEERING FORCE MOTOR RESOLVET SIGNAL (H-SS)
11	R	STEERING FORCE MOTOR RESOLVET SIGNAL (H-SS)
12	L	CAN COMMUNICATION-H
13	L	CAN COMMUNICATION-L [Without Gateway]
14	L	CAN COMMUNICATION-L [With Gateway]
15	P	CAN COMMUNICATION-L [Without Gateway]
16	R	CAN COMMUNICATION-L [With Gateway]
17	Y	BACK UP SIGNAL FROM STEERING ANGLE MAIN CONTROL MODULE

18	V	BACK UP SIGNAL FROM STEERING ANGLE MAIN CONTROL MODULE
19	W	BACK UP SIGNAL FROM STEERING ANGLE MAIN CONTROL MODULE
20	W	BACK UP SIGNAL FROM STEERING ANGLE MAIN CONTROL MODULE
21	W	BACK UP SIGNAL FROM STEERING ANGLE MAIN CONTROL MODULE
22	BG	BACK UP SIGNAL FROM STEERING ANGLE MAIN CONTROL MODULE
23	BR	CAN WAKE UP
24	R	BACK UP SIGNAL FROM STEERING ANGLE MAIN CONTROL MODULE
25	W	IGNITION POWER SUPPLY
26	R/W	STEERING CLUTCH +
27	W/B	IGNITION POWER SUPPLY FROM STEERING ANGLE MAIN CONTROL MODULE
28	R	STEERING CLUTCH -
29	L	FORCE MOTOR TEMPERATURE SENSOR -
30	B	GROUND
31	R	FORCE MOTOR TEMPERATURE SENSOR +
32	B	GROUND

Connector No.	M77
Connector Name	STEERING ANGLE SENSOR
Connector Type	TH08FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	GROUND
2	R	CAN-L [Without Gateway]
3	R	CAN-L [With Gateway]
4	G	IGN
5	L	CAN-H

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

JRMWD9956GB


CAN SYSTEM (WITHOUT AROUND VIEW MONITOR SYSTEM)

< WIRING DIAGRAM >

[CAN]


CAN SYSTEM (WITHOUT AROUND VIEW MONITOR)

Connector No.	M81
Connector Name	TCU
Connector Type	TH40PW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
2	B	BAT
3	W	GND
7	G	AMBIENT SENS
9	R	SUNLOAD SENS
13	V	IGN SW ACC
16	P	LIN
17	R	DOOR MOTOR PWM SPLY
18	P	BLOWER MOTOR CONT
20	L	HEAT STG WHL RLY CONT
21	P	CAN-L
22	B	GND
23	W	IGN ON
24	B	IGN SW
25	G	SENS GND
27	LG	IN-VEHICLE SENS
28	BR	INTAKE SENS
30	BG	EXH GAS/OUT ODOO DTCT SENS
37	B	GND
38	BG	IONIZER CONT
40	BG	ECV CONT

Connector No.	M100
Connector Name	DISPLAY CONTROL UNIT
Connector Type	TH24PW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
16	SB	AV COMM (L)
17	P	CAN-L
19	R	DIMMER SIGNAL
20	BR	REVERSE SIGNAL
22	SB	GND
24	BR	CAMERA SWITCH SIGNAL
28	LG	AV COMM (R)
29	L	CAN-H
30	R	IGN
31	R	VEHICLE SPEED SIGNAL (8-PULSE)
33	SB	ACC

34	Y	BAT
----	---	-----



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	V	-
11C	V	-
13C	L	-
14C	Y	-
15C	R	-
16C	R	-
17C	L	-
18C	BG	- [Without DRPO]
18C	P	- [With DRPO]
19C	B	-
20C	W	-
21C	L	-
22C	L	-
23C	L	-
25C	LG	-
26C	SB	-
27C	P	-
28C	W	-
29C	W	-
30C	R	-
31C	W	-
32C	R	-
33C	B	-
34C	WB	-
34C	SB	-
35C	W	-
36C	SB	-
38C	V	-
39C	P	-
40C	G	-
41C	P	-

JRMWD9957GB

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

[CAN]


< WIRING DIAGRAM >

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

Wiring Diagram

INFOID:000000009239067

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)



*: This connector is not shown in "Harness Layout".

2013/06/04

JRMWD9959GB


A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

< WIRING DIAGRAM >

[CAN]




JRMWD9960GB

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

< WIRING DIAGRAM >

[CAN]



JRMWD9961GB

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Type	TH88FW-CS



HS

Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	
2	LG	
3	P	
4	LG	
5	P	
6	V	
7	P	
17	R	- [Without Gateway]
21	BG	- [With Gateway]
22	BR	
23	BG	
28	R	
33	L	
43	B	
45	G	
47	BG	
48	GR	

HS

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	TH88FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	
2	G	
3	L	

4	G	
6	R	
7	V	
8	LG	
9	BR	
10	P	
11	BG	
12	LG	
13	GR	
24	Y	
25	W	
31	B	
32	B	
33	B	
34	G	
35	P	
36	W	
37	SB	
38	LG	
40	P	
41	SB	
42	BR	
43	BG	
44	BG	
46	R	
51	SB	
52	V	
54	R	
57	R	
58	W	
59	GR	
62	BG	
63	BR	
64	Y	
65	W	
70	R	
71	W	
72	B	
74	L	
75	V	
76	BR	
77	B	
81	B	
83	BG	
84	L	
85	B	
86	B	
88	G	

01	GR	
04	GR	
06	Y	
37	V	
39	BR	


Connector No.	B37
Connector Name	WIRE TO WIRE
Connector Type	TH88FW-NH



HS

Terminal No.	Color Of Wire	Signal Name [Specification]
2	SHIELD	
3	R	
4	L	
5	R	
7	P	


Connector No.	B59
Connector Name	FUSE BLOCK (J/B)
Connector Type	TH10FB-NH



HS

Terminal No.	Color Of Wire	Signal Name [Specification]
10H	P	
3H	R	
4H	R	
6H	L	
7H	LG	
8H	P	

Connector No.	B59
Connector Name	AROUND VIEW MONITOR CONTROL UNIT
Connector Type	TH148FW-NH



HS

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	
2	B	
3	G	
5	LG	
6	P	
19	LG	AV COMM(H)
20	P	AV COMM(L)
23	SHIELD	AV COMM GND
25	BG	REVERSE SIGNAL
27	L	CAN-H
28	P	CAN-L (With ADAS)
28	R	CAN-L (With ASCD)
30	W	RETRACT MOTOR OPERATION SIGNAL (OPEN)
32	G	RETRACT MOTOR OPERATION SIGNAL (CLOSE)

Connector No.	B82
Connector Name	WIRE TO WIRE
Connector Type	TH88FW-CS16-TM4



HS

Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	
3	R	
3	R	- (With BOSE system)
4	SHIELD	
5	G	

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

Terminal No.	Color Of Wire	Signal Name [Specification]
7	BR	-
8	BG	-
9	LG	-
10	W	-
11	GR	-
12	Y	-
13	R	-
14	BG	-
15	GR	-
16	V	-
17	P	-
18	L	-
19	D	-
20	GR	-
21	R	-
22	P	-
23	W	-
24	V	-
25	SB	-
26	G	-
29	P	-
30	LG	-
36	R	-
37	R	-
38	W	-
39	W	-
40	C	-
42	SHIELD	-
47	CS	-
48	BG	-
49	G	-
52	Y	-
53	R	-
54	GR	-
57	R	-
58	P	-
59	LG	-
62	P	-
63	L	-
64	W	-
68	LG	-
69	P	-
71	R	-
72	G	-
73	SHIELD	-
76	GR	-


Connector No.	Wire To Wire
84	BR
85	BG
86	LG
87	W
88	GR
89	Y
90	V
92	W
93	R
94	R
95	Y
96	W
97	L
99	BR
100	BR

Connector No.	Wire To Wire
B72	TH38FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	SHIELD	-
3	R	-
4	L	-
5	R	-
7	P	-

Connector No.	Wire To Wire
B60D	WIRE TO WIRE
NS16MW-GS	NS16MW-GS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
3	-	-
4	-	-
5	-	-
6	-	-
7	-	-
17	-	-
21	-	-
22	-	-
23	-	-
25	-	-
33	-	-
43	-	-
45	-	-
46	-	-
47	-	-
48	-	-


Connector No.	Wire To Wire
B601	DRIVER SEAT CONTROL UNIT
TH32FW-NH	TH32FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	BR	-
3	R	-
4	P	-

Terminal No.	Color Of Wire	Signal Name [Specification]
5	V	-
9	CT	-
10	AD	-
11	AD	-
12	SB	-
13	W	-
14	W	-
15	W	-
16	W	-
17	P	-
18	LG	-
19	W	-
20	GY	-
21	SB	-
22	O	-
23	W	-
24	Y	-
25	Y	-
26	GY	-
27	L	-
28	Y	-

Connector No.	Wire To Wire
E10	WIRE TO WIRE
SAAS3MB-FSS-SRZ	SAAS3MB-FSS-SRZ



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L/Y	-
2	SHIELD	-
3	L/B	-
4	SHIELD	-
5	BR	-
6	SB	-
7	G	-
8	W	-
9	W	-
10	Y	-
11	P	-
12	SB	-
13	L	-
14	G	-

A B C D E F G H I J K L N O P

LAN

JRMWD9963GB

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)


15	LG	
16	BR	
17	Y	
18	P	
19	GR	
20	G	
21	V	
22	Y	
23	L	
24	GR	
25	V	
26	BR	
27	W	
28	V	
29	BR	
30	R	
31	P	
32	G	
33	B	
34	BG	
35	LG	
36	W	
37	SHIELD	
38	L	
39	P	
40	R	
41	W	
42	LG	
43	G	
44	Y	
45	Y	
46	SHIELD	
47	W	
48	BR	
49	G	
50	B	
51	SB	
52	R	

Connector No.	E22
Connector Name	CHASSIS CONTROL MODULE
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	CAN-L [Without Gateway]
2	R	CAN-L [With Gateway]
3	R	CAN-H
4	L	CAN-H
5	V	DRIVE MODE SELECT SW (UP)
6	G	DRIVE MODE SELECT SW (DOWN)
7	W	CHASSIS COMM-L
8	W	CHASSIS COMM-L
10	G	IGN
11	L	CHASSIS COMM-H
12	B	GROUND
19	L	CHASSIS COMM-H

Connector No.	E25
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM1




Terminal No.	Color Of Wire	Signal Name [Specification]
2	W	
3	LG	
4	GR	
6	L	
7	L	
10	BR	
11	L	
12	GR	
13	W	
14	B	

15	BR	
16	Y	
17	BR	
18	P	
19	Y	
31	P	
32	GR	
35	GR	
36	R	
37	V	
38	L	
39	Y	
40	SB	
41	LG	
44	Y	
45	Y	
46	B	
47	G	
48	SHIELD	
49	R	
50	BR	
51	L	
52	W	
53	V	
54	P	
55	W	
56	SB	
57	BG	
58	B	
59	BR	
64	Y	
65	SB	
66	GR	
67	LG	
68	BG	
71	LG	
72	V	
73	G	
74	BR	
75	V	
76	P	
79	SB	
80	LG	
81	LG	
82	Y	
84	GR	
85	BG	
86	W	
87	LG	

68	L	
69	P	
100	SHIELD	



Connector No.	E26
Connector Name	STEERING ANGLE MAIN CONTROL MODULE
Connector Type	R124FE-R28-L-LH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	TORQUE SENSOR MAIN SIGNAL
2	Y	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SI-S3)
3	LG	TORQUE SENSOR SUB SIGNAL
4	G	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SI-S3)
5	W	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SI-S3)
6	L	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SI-S3)
7	SB	TORQUE SENSOR GROUND
8	P	TORQUE SENSOR POWER SUPPLY
10	R	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SI-S3)
11	BR	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SI-S3)
14	W	CHASSIS COMMUNICATION-L
15	W	CHASSIS COMMUNICATION-L
17	BG	BACK UP SIGNAL FROM STEERING ANGLE SUB CONTROL MODULE
18	SB	BACK UP SIGNAL FROM STEERING ANGLE SUB CONTROL MODULE
19	Y	FLUXRAY COMMUNICATION-H
20	GR	FLUXRAY COMMUNICATION-L
22	GR	BACK UP SIGNAL TO STEERING ANGLE SUB CONTROL MODULE
23	BR	CAN WAKE UP
24	P	BACK UP SIGNAL TO STEERING ANGLE SUB CONTROL MODULE
25	G	DRIVE MODE SELECT SW (UP) STEERING ANGLE SUB CONTROL MODULE
30	B	GROUND
32	GR	GROUND

JRMWD9964GB


CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

< WIRING DIAGRAM >

[CAN]


CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

Connector No.	E53
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT CONTROL UNIT
Connector Type	SAZ30FB-SL24-U




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	B	GROUND
3	L	VALVE BATTERY
4	V	MOTOR BATTERY
5	LG	STOP LAMP SW SIGNAL (With ICC)
7	GR	RR LH WHEEL SENSOR SIGNAL
8	G	RR LH WHEEL SENSOR POWER SUPPLY
9	BR	FR RH WHEEL SENSOR SIGNAL
10	GR	FR RH WHEEL SENSOR POWER SUPPLY
13	R	VACUUM SENSOR SIGNAL
15	P	CAN-L (Without Gateway)
15	R	CAN-H (With Gateway)
17	Y	RR RH WHEEL SENSOR SIGNAL
18	V	RR RH WHEEL SENSOR POWER SUPPLY
19	SB	FR LH WHEEL SENSOR SIGNAL
20	EG	FR LH WHEEL SENSOR POWER SUPPLY
25	L	CAN-H
28	G	VACUUM SENSOR POWER SUPPLY
30	R	VDC OFF SW SIGNAL
32	SHIELD	VACUUM SENSOR GROUND
34	G	IGN

Connector No.	E57
Connector Name	WIRE TO WIRE
Connector Type	TH132MW-H4




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	V	-
4	P	-
4	R	-
7	L	-
8	W	-
13	G	-
15	BR	-
17	W	-
18	EG	-
27	LG	-
28	BR	-
29	W	-
30	G	-
32	LG	-

Connector No.	E64
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS38FW-C5



Terminal No.	Color Of Wire	Signal Name [Specification]
2E	P	-
3E	V	-
4E	GR	-
6E	L	-

Connector No.	E65
Connector Name	FUSE BLOCK (J/B)
Connector Type	TH12PW-H4



Terminal No.	Color Of Wire	Signal Name [Specification]
10E	W	-
11E	W	-
12E	W	-
13E	W	-
14E	W	-
15E	W	-
16E	W	-
17E	BR	-
18E	P	-
19E	P	-
20E	L	-
21E	L	-
22E	R	-
23E	R	-
24E	R	-
25E	R	-
26E	R	-
27E	R	-
28E	R	-
29E	R	-
30E	R	-
31E	R	-
32E	R	-
33E	R	-
34E	R	-
35E	R	-
36E	R	-
37E	R	-
38E	R	-
39E	R	-
40E	R	-
41E	R	-
42E	R	-
43E	R	-
44E	R	-
45E	R	-
46E	R	-
47E	R	-
48E	R	-
49E	R	-
50E	R	-
51E	R	-
52E	R	-
53E	R	-
54E	R	-
55E	R	-
56E	R	-
57E	R	-
58E	R	-
59E	R	-
60E	R	-
61E	R	-
62E	R	-
63E	R	-
64E	R	-
65E	R	-
66E	R	-
67E	R	-
68E	R	-
69E	R	-
70E	R	-
71E	R	-
72E	R	-
73E	R	-
74E	R	-
75E	R	-
76E	R	-
77E	R	-
78E	R	-
79E	R	-
80E	R	-
81E	R	-
82E	R	-
83E	R	-
84E	R	-
85E	R	-
86E	R	-
87E	R	-
88E	R	-
89E	R	-
90E	R	-
91E	R	-
92E	R	-
93E	R	-
94E	R	-
95E	R	-
96E	R	-
97E	R	-
98E	R	-
99E	R	-
100E	R	-


Connector No.	E121
Connector Name	INTELLIGENT POWER DISTRIBUTION MODULE FRONT ROOM
Connector Type	TH23PW-H4



Terminal No.	Color Of Wire	Signal Name [Specification]
19	G	-
22	EG	-
27	GR	-
28	P	-
29	L	-
31	G	-
33	SB	-
34	Y	-


35	G	-
39	GR	-
39	GR	-
38	BR	-
41	GR	-
43	V	-

Connector No.	F2
Connector Name	A/T ASSEMBLY
Connector Type	PK10FG-D5Y



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	IGNITION POWER SUPPLY
2	P	BATTERY POWER SUPPLY / MEMORY BACK-UP
3	L	CAN-H
4	LG	K-LINE
5	B	GROUND
6	B	GROUND
7	EG	IGNITION POWER SUPPLY
8	EG	BACK-UP LAMP RELAY
9	GR	STARTER RELAY
10	B	GROUND

Connector No.	F12
Connector Name	WIRE TO WIRE
Connector Type	SAA38FB-R58-SH2Z



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

JRMWD9965GB

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

[CAN]

< WIRING DIAGRAM >

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L/Y	IGN RELAY (F/R) CONT
2	SHIELD	IGN RELAY (F/R) SW
3	L/B	PASS LOCK REG SW
4	SHIELD	PASS LOCK REG SW
5	BR	COMBI SW INPUT 5
6	GR	COMBI SW INPUT 4
7	GR	COMBI SW INPUT 3
8	W	COMBI SW INPUT 2
9	W	COMBI SW INPUT 1
10	G	TR LID OPEN SW
11	R	
12	P	
13	L	
14	LG	
15	P	
16	Y	
17	L	
18	P	
19	GR	
20	BG	
21	LG	
22	W	
23	Y	
24	LG	
25	V	
26	W	
27	V	
28	BR	
29	LG	
30	R	
31	P	
32	GR	
33	B	
34	BG	
35	LG	
36	SB	
37	SHIELD	
38	W	
39	Y	
40	G	
41	B	
42	GR	
43	R	
44	BG	
45	Y	
46	SHIELD	
47	W	
48	LG	


5	Y	DRP (+)
8	Y/B	AST (+)
7	Y/B	AST (-)
8	Y/B	ASZ (+)
9	Y	ASZ (-)
18	Y	ECZS+
19	BR	ECZS-
20	Y/R	ACT VENT+
21	Y/B	ACT VENT-
22	SHIELD	GND
23	V	AIRBAG W/L
24	G	
25	GR	A/E OFF IND
31	G	SATELLITE REL (+)
32	Y	SATELLITE REL (-)
33	Y	SIDE SEAS LH+
34	L	SIDE SEAS LH-
37	LG	IVCS
39	L	CAN-H
60	P	CAN-L

Connector No.	F100
Connector Name	TOYOTA TRANSMISSION CONTROL MODULE
Connector Type	SP10FG



Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	IGNITION POWER SUPPLY
2	-	BATTERY POWER SUPPLY (MEMORY BACK-UP)
3	-	CAN-H
4	-	K-LINE
5	-	GROUND
6	-	IGNITION POWER SUPPLY
7	-	BACK-UP LAMP RELAY
8	-	CAN-
9	-	STAGE RELAY
10	-	GROUND

Connector No.	M5
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	NH2BFY-EX



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	IGN
2	B	GND
3	Y/R	DRL (+)
4	Y/B	DRL (-)

5	Y	DRP (+)
8	Y/B	AST (+)
7	Y/B	AST (-)
8	Y/B	ASZ (+)
9	Y	ASZ (-)
18	Y	ECZS+
19	BR	ECZS-
20	Y/R	ACT VENT+
21	Y/B	ACT VENT-
22	SHIELD	GND
23	V	AIRBAG W/L
24	G	
25	GR	A/E OFF IND
31	G	SATELLITE REL (+)
32	Y	SATELLITE REL (-)
33	Y	SIDE SEAS LH+
34	L	SIDE SEAS LH-
37	LG	IVCS
39	L	CAN-H
60	P	CAN-L

Connector No.	M14
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH90FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
48	R	PUSH-BTN IGN SW ILL PWR
52	G	DONGLE LINK
54	V	COMM LINE
55	R	RAIN SENSOR
59	P	CAN-L
60	L	CAN-H
62	R	REAR WINDOGE RLY CONT
63	V	STARTER RLY CONT
64	V	KEY WARN BUZZER
65	B	OUTS HD LAMP CONT
66	B	BLOWER FAN RLY CONT
67	W/B	IGN RELAY (F/R) CONT
68	R	DIMMER
69	GR	A.T. SHIFT SELECT PWR SPPLY

70	B	IGN RELAY (F/R) CONT
71	G	IGN RELAY (F/R) SW
72	SB	PASS LOCK REG SW
75	BR	COMBI SW INPUT 5
76	BG	COMBI SW INPUT 4
77	V	COMBI SW INPUT 3
78	Y	COMBI SW INPUT 2
79	LG	COMBI SW INPUT 1
80	L	TR LID OPEN SW

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	TH98MP-C51P-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	
2	G	
3	SB	
4	BR	
7	W	
8	V	
9	BR	
10	P	
11	BR	
12	LG	
13	GR	
24	Y	
25	W	
31	BR	
32	B	
33	B	
34	V	
36	W	
37	SB	
38	LG	
40	P	
41	G	
42	BR	

JRMWD9966GB

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

Terminal No.	Color	OF	Signal Name [Specification]
43	BR		
44	BR		
45	BR		
51	V		
52	V		
54	R		
55	R		
57	W		
58	V		
59	BG		
62	BG		
63	BR		
64	Y		
65	W		
70	LG		
71	W		
72	B		
74	L		
75	W		
76	BR		
77	B		
81	B		
83	BG		
84	L		
85	W		
86	B		
88	G		
91	GR		
94	GR		
96	V		
97	V		
98	BR		


Connector No.	M22
Connector Name	WIRE TO WIRE
Connector Type	TH88MM-CSS16-TM4



Terminal No.	Color	OF	Signal Name [Specification]
1	LG		
2	R		
3	R		
4	SHIELD		
5	G		
6	BG		
7	LG		
8	P		
9	SHIELD		
10	V		
11	GR		
12	V		
13	LG		
14	G		
15	B		
16	SB		
17	Y		
18	L		
19	G		
20	GR		
21	R		
22	W		
23	L		
24	V		
25	LG		
26	GR		
28	SB		
29	LG		
36	R		
37	R		
38	W		
39	V		
45	G		
46	SHIELD		
47	G		
48	BR		
49	SB		
52	Y		
53	R		
54	GR		
56	SB		
57	SB		
58	LG		
62	L		
64	W		
66	R		


Terminal No.	Color	OF	Signal Name [Specification]
88	L		
91	R		
92	R		
93	G		
94	SHIELD		
96	V		
98	BR		
85	BR		
86	V		
87	LG		
89	BR		
90	V		
92	W		
93	R		
94	R		
95	W		
96	W		
97	L		
98	L		
99	BR		
100	BR		

Connector No.	M24
Connector Name	CAN GATEWAY
Connector Type	TH12FW-NH




Terminal No.	Color	OF	Signal Name [Specification]
1	L		
2	L		
3	W		
4	L		
5	B		
6	L		
7	P		
8	GR		
9	R		
10	GR		
11	B		
12	R		

Connector No.	M25
Connector Name	DATA LINK CONNECTOR
Connector Type	ED18EW



Terminal No.	Color	OF	Signal Name [Specification]
3	SB		
4	B		
5	B		
6	L		
7	V		
8	W		
11	LG		
12	R		
13	L		
14	P		
16	W		

Connector No.	M27
Connector Name	ECM
Connector Type	FR24ECY-R28-R-LH-Z



Terminal No.	Color	OF	Signal Name [Specification]
87	Y		
88	BR		
89	R		
90	G		
101	SB		
102	LG		
103	L		
104	R		

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

JRMWD9967GB

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)


< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

Connector No.	Wire	Signal Name [Specification]
103	B	REF FERRAM PRESSURE SENSOR
104	B	FUEL TANK TEMPERATURE SENSOR
107	GR	WIRE TO WIRE
108	Y	SENSOR GROUND (ASD, ICC, STEERING SWITCH)
109	BR	TRANSMISSION RANGE SWITCH
110	V	ENGINE SPEED SIGNAL OUTPUT
112	V	GNDA PDPPRES/FTPRES
113	P	CAN COMMUNICATION LINE
114	L	CAN COMMUNICATION LINE
117	V	DATA LINK CONNECTOR
121	LG	EVAP CANISTER VENT CONTROL VALVE
122	SB	STOP LAMP SWITCH
123	B	ECM GROUND
124	B	ECM GROUND
125	B	POWER WINDOW PWR EGM
126	BG	POWER WINDOW POSITON SWITCH
127	B	ECM GROUND
128	B	ECM GROUND

Connector No.	M39
Connector Name	WIRE TO WIRE
Connector Type	TH16FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W/B	-
2	SB	-
3	L	-
4	P	- [Without Gateway]
4	R	- [With Gateway]
7	L	-
8	W	-
13	G	-
15	R	-
16	EC	-
17	EC	-
27	LG	-
28	BR	-
29	W/B	-
30	Y	-
31	W	-
32	LG	-


Connector No.	M4D
Connector Name	WIRE TO WIRE
Connector Type	TH16MW-CSI6-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	GR	-
3	V	-
4	W/B	-
6	V	-
7	V	-
10	W	-
11	W	-
12	B	-
13	GR	-
14	B	-
15	SB	-
16	B	-
17	LG	-
18	B	-
19	V	-
22	V	-
25	BG	-
26	BG	-
37	B	-
38	L	-
39	Y	-
40	GR	-
41	L	-
44	BR	-
45	W	-
46	G	-
47	R	-
48	SHIELD	-
49	BR	-
50	BR	-
51	L	-
52	W	-
53	G	-
54	Y	-
55	P	-
56	BG	-

Terminal No.	Color Of Wire	Signal Name [Specification]
57	GR	-
58	B	-
59	SB	-
61	W/B	-
64	Y	-
65	R	-
66	V	-
67	LG	-
68	BG	-
71	V	-
72	LG	-
73	R	-
74	BR	-
75	B	-
76	B	-
78	S	-
83	R	-
86	V	-
91	W	-
92	R	-
94	BG	-
95	BR	-
96	W	-
97	LG	-
98	Y	-
99	BR	-
100	SHIELD	-


Connector No.	M42
Connector Name	AWD CONTROL UNIT
Connector Type	TH16FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	AWD SOL (+)
2	Y	AWD SOL (-)
3	W/B	FLUID TEMP (-)
7	G	IGN
8	L	CAN-H
9	BG	AWD SOL BAT
10	B	GND

Terminal No.	Color Of Wire	Signal Name [Specification]
11	B	GND
13	LG	FLUID TEMP (+)
15	W	BATTERY POWER SUPPLY
16	P	CAN-L [Without Gateway]
16	R	CAN-L [With Gateway]

Connector No.	M58
Connector Name	COMBINATION METER
Connector Type	TH16FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
41	L	CAN-H
42	P	ILLUMINATION CONTROL SIGNAL
43	B	FUEL LEVEL SENSOR GROUND
44	Y	BATTERY POWER SUPPLY
45	W	BATTERY POWER SUPPLY
46	R	IGNITION SIGNAL
47	LG	AV COMMUNICATION SIGNAL (+)
48	SB	AV COMMUNICATION SIGNAL (-)
51	BR	FUEL LEVEL SENSOR SIGNAL
52	B	GROUND

Connector No.	MTI
Connector Name	STEERING FORCE CONTROL MODULE
Connector Type	RI24FB-R28-L-RH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	P	STEERING FORCE MOTOR RESCOVER SIGNAL (S1-S2)
4	W	STEERING FORCE MOTOR RESCOVER SIGNAL (S1-S2)
5	G	STEERING FORCE MOTOR RESCOVER SIGNAL (S2-S4)

JRMWD9968GB

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

Terminal No.	Color Of Wire	Signal Name [Specification]
6	O	STEERING FORCE MOTOR RESERVE SIGNAL (SC-30)
10	B	STEERING FORCE MOTOR SIGNAL (SC-30)
11	R	STEERING FORCE MOTOR RESERVE SIGNAL (SC-30)
14	L	CAN COMMUNICATION-H
15	P	CAN COMMUNICATION-L (Without Gateway)
17	Y	CAN COMMUNICATION-L (With Gateway)
18	Y	BACK UP SIGNAL FROM STEERING ANGLE MAIN CONTROL MODULE
20	V	BACK UP SIGNAL FROM STEERING ANGLE SUB CONTROL MODULE
22	BG	FLEXRAY COMMUNICATION-L
23	BR	FLEXRAY COMMUNICATION-L
24	R	CAN WAKE UP
25	W	IGNITION POWER SUPPLY
26	R/Y	STEERING CLUTCH +
27	R	STEERING CLUTCH -
28	R	FORCE MOTOR TEMPERATURE SENSOR
30	B	GROUND
31	R	FORCE MOTOR TEMPERATURE SENSOR +
32	B	GROUND

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	W	-
4	BR	-
5	G	-
9	B	-
10	V	-
11	LG	-
12	W	-
13	G	-
14	B	-
16	R	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	W	-
4	BR	-
5	G	-
9	B	-
10	V	-
11	LG	-
12	W	-
13	G	-
14	B	-
16	R	-

Terminal No.	Color Of Wire	Signal Name [Specification]
17	J	SHIELD
18	C	-
19	L	-
21	B	-
22	R	-
23	V	-
25	W	-
26	B	-
27	R	-
28	GR	-
29	W	-
31	W	-
32	L	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	R	CAN-L (With Gateway)
4	G	CAN-L (With Gateway)
5	L	IGN
	L	CAN-H

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	R	CAN-L (With Gateway)
4	G	CAN-L (With Gateway)
5	L	IGN
	L	CAN-H


Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	CENTER SENSOR SIGNAL FRONT RH
2	G	CORNER SENSOR SIGNAL FRONT RH
3	W	CORNER SENSOR SIGNAL FRONT LH
4	GR	CORNER SENSOR SIGNAL FRONT RH
5	L	CAN-H
6	R	CAN-L (With Gateway)
9	G	CENTER SENSOR SIGNAL REAR RH
10	BG	CORNER SENSOR SIGNAL REAR RH
12	R	IGN
13	B	FRONT SENSOR GND
14	B	REAR SENSOR GND
15	B	GROUND
18	GR	FRONT BUZZER DRIVE SIGNAL
19	GR	BUZZER POWER SUPPLY
21	BR	CORNER SENSOR SIGNAL FRONT LH
22	W	CORNER SENSOR SIGNAL REAR LH

Connector No.	Connector Name	Connector Type
MT7	STEERING ANGLE SENSOR	TH36PW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	R	CAN-L (With Gateway)
4	G	CAN-L (With Gateway)
5	L	IGN
	L	CAN-H


Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	R	CAN-L (With Gateway)
4	G	CAN-L (With Gateway)
5	L	IGN
	L	CAN-H



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	BAT
2	B	GROUND
3	V	ACC
4	R	IGN
5	SB	ACC OUTPUT
6	SB	-
7	B	GROUND
9	L	CAN-H
14	B	AUDIO TYPE RECOGNITION SIGNAL
18	L	MICROPHONE SIGNAL
19	G	MICROPHONE VCC
20	SHIELD	SHIELD
21	L	MICROPHONE VCC
22	G	SOUND SIGNAL

Terminal No.	Color Of Wire	Signal Name [Specification]
23	SHIELD	SHIELD
24	G	SSS CALL SIGNAL
32	BR	SSS SWITCHED SIGNAL

Connector No.	Connector Name	Connector Type
M88	A/C AUTO AMP	TH46PW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
2	B	GROUND
3	W	BAT
7	G	AMBIENT SENS
9	R	SUNLOAD SENS
13	V	IGN SW ACC
16	P	IGN SW LIN
17	R	DOOR MOTOR PWR SRLY
18	P	BLOWER MOTOR CONT
20	L	HEAT STRG WHL RLY CONT
21	B	IGN SW GND
22	B	IGN SW ON
23	W	SEAS GND
26	B	SEAS GND
27	LG	RH-VEHICLE SENS
28	BR	INTAKE SENS
30	BG	EXH GAS/OUT ODO/D TCT SENS
37	B	GROUND
38	BG	IONIZER CONT
40	BG	EDV CONT

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)


Connector No.	M159
Wire To Wire	
Connector Name	TH16MW-NH
Connector Type	



HS

Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	
2	BR	
3	R	
4	W	
5	P	
6	Y	
7	P	
8	R/W	
10	R	
11	SHIELD	
13	L	
14	L	
15	L	

Connector No.	M160
Wire To Wire	
Connector Name	DISPLAY CONTROL UNIT
Connector Type	TH24EW-NH



HS

Terminal No.	Color Of Wire	Signal Name [Specification]
17	SB	
18	R	
19	R	
20	BR	
22	B	
25	SB	
26	BR	
28	LG	

32	L	GM-H
33	R	GM
34	SB	VEHICLE SPEED SIGNAL (6-PULSE)
35	R	ACC
36	SB	ACC
37	Y	BAT

Connector No.	M133
Wire To Wire	
Connector Name	FUSE BLOCK (1/B)
Connector Type	TH40FW-NH




HS

Terminal No.	Color Of Wire	Signal Name [Specification]
10C	V	
11C	V	
13C	L	
14C	Y	
15C	R	
16C	R	
17C	L	
18C	BG	
19C	P	
20C	B	
21C	W	
22C	L	
23C	L	
24C	L	
25C	LG	
26C	SB	
27C	P	
28C	W	
29C	W	
30C	R	
31C	R	
32C	R	
33C	R	
34C	W/B	
35C	SB	
36C	R	
37C	W	
38C	SB	
39C	V	

3G	P	
4G	G	
5G	P	
6G	G	
7C	G	
8C	V	

Connector No.	M155
Wire To Wire	
Connector Name	TH16FW-NH
Connector Type	



HS

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	
3	R	
5	R	
8	P	
9	P	
7	R	
10	R	
11	SHIELD	
13	L	
14	L	
15	L	

Connector No.	RS
Wire To Wire	
Connector Name	TH132MW-NH
Connector Type	



HS

Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	
2	GR	
3	GR	
4	BR	
5	R	
6	G	
7	B	
10	BR	
11	SB	
12	GR	
14	B	
16	V	
17	SHIELD	
18	R	
19	L	
21	LG	
22	V	
23	GR	
25	W	
26	B	
27	BR	
28	BG	
29	EG	
31	W	
32	L	

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH AROUND VIEW MONITOR, WITHOUT ICC)

Connector No.	R13
Connector Name	LANE CAMERA UNIT
Connector Type	TYPEW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	CAN GND
4	E	GM+H
5	B	GND
7	V	IGN
8	W	CAN-L

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


LAN

JRMWD9971GB

CAN SYSTEM (WITH ICC)

< WIRING DIAGRAM >

[CAN]




JRMWD9973GB

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

CAN SYSTEM (WITH ICC)

< WIRING DIAGRAM >

[CAN]




JRMWD9974GB

CAN SYSTEM (WITH ICC)

< WIRING DIAGRAM >

[CAN]



JRMWD9975GB

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P


CAN SYSTEM (WITH ICC)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH ICC)


Connector No.	B1
Connector Name	ADAS CONTROL UNIT
Connector Type	TH24FT-NH



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
2	R	CAN-L
5	B	GROUND
6	L	ITS COMM-H
7	P	ITS COMM-L
8	L	CHASSIS COMM-H
9	V	CHASSIS COMM-L
12	GR	IGNITION
17	V	BRAKE HOLD RLY DRIVE SIGNAL

Connector No.	B3
Connector Name	WIRE TO WIRE
Connector Type	NS16FT-CS



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
7	R	-
8	B	-
9	P	-
14	B	-
15	W	-
16	BR	-

Connector No.	B5
Connector Name	WIRE TO WIRE
Connector Type	TH16MM-NH



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
2	B	-
3	BR	-
4	SHIELD	-
5	P	-
6	L	-
7	GR	-
10	B	-
11	B	-
12	SB	-
13	SHIELD	-
14	P	-
15	L	-

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Type	NS16FT-CS




H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	LG	-
5	W	-
6	V	-
7	P	-
17	R	-

21	EG	-
22	BR	-
23	EG	-
24	Y	-
33	L	-
43	B	-
45	G	-
46	EG	-
47	R	-
48	GR	-

Connector No.	B19
Connector Name	WIRE TO WIRE
Connector Type	TH80FT-CS18-TM4



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	L	-
4	LG	-
5	V	-
6	LG	-
9	BR	-
10	P	-
11	EG	-
12	LG	-
13	GR	-
24	Y	-
25	W	-
31	B	-
32	B	-
33	B	-
34	LG	-
35	P	-
36	W	-
37	SB	-
38	LG	-
40	P	-
41	SB	-

42	BR	-
43	EG	-
44	EG	-
45	SB	-
52	V	-
54	R	-
55	R	-
57	W	-
58	V	-
59	GR	-
62	EG	-
63	BR	-
64	Y	-
65	W	-
70	R	-
71	W	-
72	B	-
74	L	-
75	V	-
76	BR	-
77	B	-
81	B	-
83	EG	-
84	L	-
85	V	-
86	B	-
88	G	-
91	GR	-
94	GR	-
95	V	-
98	BR	-


CAN SYSTEM (WITH ICC)

< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH ICC)

Connector No.	B19
Connector Name	PRE-CRASH SEAT BELT CONTROL UNIT (DRIVER SIDE)
Connector Type	TH18FT-CS2




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	SIG BATT
2	G	OUT 1
4	R	CAN LO
6	W	BACKL SW LH NO
8	BR	LOCAL COMM 2
9	SHIELD	SHIELD GND
10	R	SENS POWER 1
12	B	OUT 2
14	L	CAN HI
16	Y	LOCAL COMM 1
17	W	SENS GND 1
18	B	SIG GND 1
19	Y	MOTOR BATT
20	B	MOTOR GND

Connector No.	B37
Connector Name	WIRE TO WIRE
Connector Type	TH08BMF-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	SHIELD	
3	R	
4	L	
5	R	
7	P	

Connector No.	B39
Connector Name	FUSE BLOCK (J/B)
Connector Type	TH10FB-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
10H	P	
3H	L	
4H	R	
6H	L	
7H	LG	
8H	P	

Connector No.	B50
Connector Name	AROUND VIEW MONITOR CONTROL UNIT
Connector Type	TH40FPW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GND
2	Y	BATT
3	LG	IGN
4	P	ACC
19	LG	AV COMM (H)
20	P	SHIELD
23	SHIELD	AV COMM (L)
25	BG	AV COMM GND
27	L	REVERSE SIGNAL
28	P	CAN-H
28	R	CAN-L [With ADAS]
30	W	CAN-L [With ASCD]
32	G	RETRACT MOTOR OPERATION SIGNAL (OPEN)
		RETRACT MOTOR OPERATION SIGNAL (CLOSE)

Connector No.	B52
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	
7	R	
8	SHIELD	
9	P	
14	B	
15	W	
16	BR	

Connector No.	B52
Connector Name	WIRE TO WIRE
Connector Type	TH8FPW-CS18-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	
2	L	
3	R	
3	R	- [With BOSE system]
4	W	- [Without BOSE system]
4	SHIELD	
5	G	
6	W	
7	BR	
7	W	- [Without BOSE system]
8	B	- [With BOSE system]
8	Y	- [Without BOSE system]
9	SHIELD	
10	V	

11	GR	
12	Y	
13	R	
14	BG	
15	GR	
16	Y	
17	P	
18	L	
19	R	
20	GR	
21	R	
22	P	
23	W	
24	V	
25	SB	
26	G	
29	P	
30	LG	
36	R	
37	R	
38	W	
39	W	
45	G	
46	SHIELD	
47	G	
48	BG	
49	G	
52	Y	
53	R	
54	GR	
57	R	
58	P	
59	LG	
62	P	
63	L	
64	W	
66	LG	
68	L	
69	P	
71	R	
72	G	
73	SHIELD	
76	GR	
84	BR	
85	BG	
86	W	
87	LG	
89	LG	
90	V	
92	W	

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN SYSTEM (WITH ICC)

CAN SYSTEM (WITH ICC)

83	R	--
84	R	--
85	Y	--
86	W	--
87	L	--
89	BR	--
100	BR	--

Connector No.	B72
Connector Name	WIRE TO WIRE
Connector Type	TH08FW-NH



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	--
2	SHIELD	--
3	R	--
4	L	--
5	R	--
7	P	--

Connector No.	B87
Connector Name	WIRE TO WIRE
Connector Type	TH18FW-NH




H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	--
2	B	--
3	BR	--
4	SHIELD	--
5	R	--
6	L	--
7	GR	--

10	B	--
12	SB	--
13	SHIELD	--
14	P	--
15	L	--


Connector No.	B82
Connector Name	SIDE RADAR LH
Connector Type	AAC08FB-WP-SP



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	R	ITS COMM-L
3	L	ITS COMM-H
4	GR	IGNITION
5	BR	BLIND SPOT WARNING/BLIND SPOT INTERVENTION INDICATOR

Connector No.	B53
Connector Name	SIDE RADAR RH
Connector Type	AAC08FB-WP



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	RIGHT/LEFT SWITCHING SIGNAL
2	P	GROUND
3	R	ITS COMM-L
4	L	ITS COMM-H
5	GR	IGNITION
6	SB	BLIND SPOT WARNING/BLIND SPOT INTERVENTION INDICATOR

Connector No.	B600
Connector Name	WIRE TO WIRE
Connector Type	HS18MW-CS



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	--	--
2	--	--
5	--	--
6	--	--
7	--	--
17	--	--
21	--	--
22	--	--
23	--	--
28	--	--
33	--	--
43	--	--
45	--	--
46	--	--
47	--	--
48	--	--

Connector No.	B601
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH22PW-NH



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
2	BR	UART (TX/RX)
3	R	START SW
4	P	PULSE (RECLINER)

5	V	PULSE (TELESCOPIE)
6	GY	ADDRESS 2
7	G	--
8	Y	SLIDE SW (BACKWARD)
9	W	RECLINER SW (BACKWARD)
10	O	TILT SW (DOWNWARD)
11	G	LIFTER SW (DOWNWARD)
12	SB	POWER SUPPLY (ENGINEER)
17	P	CAN-L
18	LG	PULSE (SLIDE SENSOR)
19	W	PULSE (LIFTER FRONT)
20	GY	PULSE (LIFTER REAR)
21	SB	PULSE (TILT SENSOR)
22	O	ADDRESS 1
23	W	IND. 1
24	P	SLIDE SW (FORWARD)
25	Y	RECLINER SW (FORWARD)
26	GY	TILT SW (UPWARD)
27	L	LIFTER SW (UPWARD)
28	Y	SET SW

Connector No.	E10
Connector Name	WIRE TO WIRE
Connector Type	ISAA38MB-RSB-SH28



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L/Y	--
2	SHIELD	--
3	L/B	--
4	SHIELD	--
5	BR	--
6	SB	--
7	G	--
8	W	--
9	W	--
10	Y	--
11	P	--
12	SB	--
13	L	--
14	G	--

CAN SYSTEM (WITH ICC)


< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH ICC)

15	LG	--
16	BR	--
17	L	--
18	D	--
19	GR	--
20	G	--
21	Y	--
22	Y	--
23	L	--
24	GR	--
25	V	--
26	BR	--
27	W	--
28	V	--
29	BR	--
30	R	--
31	P	--
32	G	--
33	B	--
34	BG	--
35	LG	--
36	W	--
37	SHIELD	--
38	L	--
39	P	--
40	R	--
41	W	--
42	LG	--
43	G	--
44	V	--
45	Y	--
46	SHIELD	--
47	BR	--
48	R	--
49	G	--
50	B	--
51	SB	--
52	R	--


Connector No.	E14
Connector Name	WIRE TO WIRE
Connector Type	SAA18MB-RS-D-S1Z2



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
4	Y	--
5	L	--
6	B	--
7	BR	--
8	LG	--
9	W	--
11	V	--
12	R	--
13	B	--
14	P	--
15	GR	--
16	V	--
17	B	--
18	P	--
21	B	--
22	SHIELD	--
23	P	--
24	V	--
25	B	--
27	B	--
28	B	--


Connector No.	E22
Connector Name	CHASSIS CONTROL MODULE
Connector Type	TH24FW-NH



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
3	P	CAN-L [Without Gateway]
4	R	CAN-L [With Gateway]
5	L	CAN-H
6	G	DRIVE MODE SELECT SW (UP)
7	W	DRIVE MODE SELECT SW (DOWN)
8	W	CHASSIS COMM-L
9	W	CHASSIS COMM-L
10	G	IGN
11	L	CHASSIS COMM-H
12	B	GROUND
19	L	CHASSIS COMM-H

Connector No.	E25
Connector Name	WIRE TO WIRE
Connector Type	TH28FW-LS16-TM4



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
2	W	--
3	LG	--
4	BR	--
6	V	--
7	L	--
10	BR	--
11	L	--
12	GR	--
13	W	--
14	B	--

15	SB	--
16	Y	--
17	BR	--
18	P	--
19	Y	--
31	GR	--
35	GR	--
36	R	--
37	V	--
38	L	--
39	Y	--
40	SB	--
41	LG	--
44	Y	--
45	W	--
46	B	--
47	G	--
48	SHIELD	--
49	R	--
50	BR	--
51	L	--
52	W	--
53	V	--
54	P	--
55	W	--
56	SB	--
57	BG	--
58	B	--
59	W	--
61	R	--
64	Y	--
69	SB	--
69	GR	--
68	LG	--
68	BG	--
71	LG	--
72	V	--
73	G	--
74	BR	--
75	V	--
78	P	--
79	SB	--
83	R	--
86	BG	--
91	G	--
92	Y	--
94	GR	--
95	BG	--
96	W	--
97	LG	--

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

JRMWD9979GB

CAN SYSTEM (WITH ICC)


< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH ICC)


Connector No.	E26
Connector Name	STEERING ANGLE MAIN CONTROL MODULE
Connector Type	RH24FE-R28-L-LH

Terminal No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32		
Color	BR	L	P	SHIELD																														
Wire																																		
Signal Name [Specification]	TORQUE SENSOR MAIN SIGNAL	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SH-SL)	TORQUE SENSOR SUB SIGNAL	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SH-SL)	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SP-SL)	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SP-SL)	TORQUE SENSOR GROUND	TORQUE SENSOR POWER SUPPLY	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SH-SL)	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SP-SL)	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SP-SL)	CHASSIS COMMUNICATION-H	CHASSIS COMMUNICATION-L	BACK UP SIGNAL FROM STEERING ANGLE CONTROL MODULE	BACK UP SIGNAL FROM STEERING ANGLE SUB CONTROL MODULE	BACK UP SIGNAL TO STEERING ANGLE SUB CONTROL MODULE	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SH-SL)	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SP-SL)	CHASSIS COMMUNICATION-H	CHASSIS COMMUNICATION-L	BACK UP SIGNAL FROM STEERING ANGLE SUB CONTROL MODULE	BACK UP SIGNAL TO STEERING ANGLE SUB CONTROL MODULE	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SH-SL)	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SP-SL)	CHASSIS COMMUNICATION-H	CHASSIS COMMUNICATION-L	BACK UP SIGNAL FROM STEERING ANGLE SUB CONTROL MODULE	BACK UP SIGNAL TO STEERING ANGLE SUB CONTROL MODULE	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SH-SL)	STEERING ANGLE MAIN MOTOR RESOLVER SIGNAL (SP-SL)	CHASSIS COMMUNICATION-H	CHASSIS COMMUNICATION-L	BACK UP SIGNAL FROM STEERING ANGLE SUB CONTROL MODULE	BACK UP SIGNAL TO STEERING ANGLE SUB CONTROL MODULE




Connector No.	E25
Connector Name	ABS ACTUATOR AND ELECTRIC LIMIT CONTROL UNIT
Connector Type	SAZ20FE-SU24-U

Terminal No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
Color	B	B	G	Y	LG	V	GR	G	BR	GR	R	R	P	R	P	R	R	R	R	R	R	R	R	R	R
Wire																									
Signal Name [Specification]	GROUND	GROUND	VALVE BATTERY	MOTOR BATTERY	STOP LAMP SW SIGNAL (With I/C)	STOP LAMP SW SIGNAL (With ASD)	RR LH WHEEL SENSOR SIGNAL	RR LH WHEEL SENSOR SIGNAL	FR RH WHEEL SENSOR SIGNAL	FR RH WHEEL SENSOR SIGNAL	VACUUM SENSOR SIGNAL	CAN-L (Without Gateway)	CAN-L (With Gateway)	RR RH WHEEL SENSOR SIGNAL	RR RH WHEEL SENSOR SIGNAL	FR LH WHEEL SENSOR SIGNAL	FR LH WHEEL SENSOR SIGNAL	VACUUM SENSOR SIGNAL	VACUUM SENSOR POWER SUPPLY	VICG OFF SW SIGNAL	VACUUM SENSOR GROUND	IGN			



Connector No.	E47
Connector Name	WIPE TO WIRE
Connector Type	TH22HW-NH

Terminal No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	
Color	G	V	L	P	R	L	W	G	BR	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W	W
Wire																									
Signal Name [Specification]																									



Connector No.	E65
Connector Name	FUSE BLOCK (J/B)
Connector Type	TH12FH-NH

Terminal No.	10F	11F	12F	1F	2F	3F	4F	5F	6F	7F	8F	9F
Color	W	W	W	V	BR	P	P	P	R	L	L	L
Wire												
Signal Name [Specification]												



Connector No.	E76
Connector Name	WIPE TO WIRE
Connector Type	SA418FB-RS10-SJ22

Terminal No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	
Color	W	W	W	V	BR	P	P	P	R	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
Wire																																	
Signal Name [Specification]																																	




Connector No.	E64
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS08FW-GS

Terminal No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	
Color	G	P	V	GR	GR	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
Wire																																	
Signal Name [Specification]																																	



Connector No.	E78
Connector Name	WIPE TO WIRE
Connector Type	SA418FB-RS10-SJ22

Terminal No.	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	
Color	W	W	W	V	BR	P	P	P	R	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	
Wire																																	
Signal Name [Specification]																																	



JRMWD9980GB

CAN SYSTEM (WITH ICC)


< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH ICC)

Terminal No.	Color	Wire	Signal Name [Specification]
14	R	--	--
15	G	--	--
16	V	--	--
17	B	--	--
18	B	--	--
21	B	--	--
22	SHIELD	--	--
23	P	--	--
24	L	--	--
25	V	--	--
26	B	--	--
27	B	--	--
28	B	--	--

Connector No.	E80
Connector Name	ICC SENSOR
Connector Type	IAZ08FB



HS

Terminal No.	Color	Wire	Signal Name [Specification]
1	R	--	IGNITION
3	L	--	ITS COMB-H
6	Y	--	ITS COMB-L
8	B	--	GROUND

Connector No.	E121
Connector Name	IPM (FOR INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	TH32FW-NH



HS

Terminal No.	Color	Wire	Signal Name [Specification]
19	G	--	--
22	DG	--	--
23	G	--	--
24	GR	--	--
26	P	--	--
28	L	--	--
31	G	--	--
33	SB	--	--
34	G	--	--
35	G	--	--
36	SR	--	--
37	GR	--	--
38	BR	--	--
41	GR	--	--
43	V	--	--


Connector No.	FZ
Connector Name	A/T ASSEMBLY
Connector Type	FRK0FG-DGY



HS

Terminal No.	Color	Wire	Signal Name [Specification]
1	GR	--	IGNITION POWER SUPPLY
2	P	--	BATTERY POWER SUPPLY (MEMORY BACK-UP)
3	L	--	CAN-H
4	LG	--	K-LINE
5	B	--	GROUND
6	GR	--	IGNITION POWER SUPPLY
7	BG	--	BACK-UP LAMP RELAY
8	P	--	CAN-L
9	GR	--	STARTER RELAY
10	B	--	GROUND

Connector No.	F12
Connector Name	WIRE TO WIRE
Connector Type	SA33FB-RSS-SHE3



HS

Terminal No.	Color	Wire	Signal Name [Specification]
1	L/Y	--	--
2	SHIELD	--	--
3	L/B	--	--
4	SHIELD	--	--
5	BR	--	--
6	GR	--	--
7	G	--	--
8	W	--	--
9	W	--	--
10	G	--	--
11	R	--	--
12	P	--	--
13	L	--	--
14	LG	--	--
15	P	--	--
16	Y	--	--
17	L	--	--
18	GR	--	--
19	BG	--	--
20	LG	--	--
21	LG	--	--
22	W	--	--
23	Y	--	--
24	LG	--	--
25	V	--	--
26	W	--	--
27	V	--	--
28	BR	--	--
29	LG	--	--
30	R	--	--
31	P	--	--
32	GR	--	--
33	B	--	--
34	BG	--	--
35	LG	--	--
36	SB	--	--

Terminal No.	Color	Wire	Signal Name [Specification]
37	SHIELD	--	--
38	W	--	--
39	Y	--	--
40	G	--	--
41	B	--	--
42	GR	--	--
43	GR	--	--
44	BG	--	--
45	Y	--	--
46	SHIELD	--	--
47	W	--	--
48	LG	--	--
49	L	--	--
50	R	--	--
51	SB	--	--
52	G	--	--

Connector No.	F100
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Type	ISP10FG




Terminal No.	Color	Wire	Signal Name [Specification]
1	--	--	IGNITION POWER SUPPLY
2	--	--	BATTERY POWER SUPPLY (MEMORY BACK-UP)
3	--	--	CAN-H
4	--	--	K-LINE
5	--	--	GROUND
6	--	--	IGNITION POWER SUPPLY
7	--	--	BACK-UP LAMP RELAY
8	--	--	CAN-L
9	--	--	STARTER RELAY
10	--	--	GROUND

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN


CAN SYSTEM (WITH ICC)

Connector No.	M4
Connector Name	AFS CONTROL UNIT
Connector Type	TH24ET-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
6	BR	HEIGHT SENSOR SIGNAL
8	GR	SWIVEL ACTUATOR LIN SIGNAL
11	B	GROUND
12	R	IGNITION POWER SUPPLY
13	P	CAN-L
19	P	SWIVEL ACTUATOR GROUND
21	LG	HEIGHT SENSOR POWER SUPPLY
22	SB	AMING MOTOR DRIVE SIGNAL
23	GR	HEIGHT SENSOR GROUND
24	B	AMING MOTOR GROUND


Connector No.	M5
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	TH28ET-EX



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	IGN
2	B	GND
3	Y/R	DR1 (+)
4	Y/B	DR1 (-)
5	Y	DR2 (+)
6	Y/R	AS1 (+)
7	Y/B	AS1 (-)
8	Y/G	AS2 (+)
9	Y	AS2 (-)

18	Y	EC23+
19	BR	EC23-
20	Y/R	ACT-VENT+
21	Y/B	ACT-VENT-
22	SHIELD	GND
23	V	ARBAG W/L
24	G	ARBAG W/L
25	GR	A/B OFF/IND
51	G	SATELLITE RH2 (+)
52	R	SIDE SENS RH2-
53	V	SIDE SENS LH2+
54	L	SIDE SENS LH2-
57	LG	IVCS
59	L	CAN-H
60	P	CAN-L

Connector No.	M14
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
48	R	PUSH-ETH/IGN SW ILL PWR
52	G	DOUBLE LINK
54	V	COM1 LIN
55	R	RAIN SENSOR
59	P	CAN-H
60	L	CAN-L
61	G	REAR WINDOW DEF RLY CONT
62	R	STARTER RLY CONT
64	V	F-KEY WARN BUZZER
65	B	OUTS HD LAMP CONT
66	B	BLOWER FAN RLY CONT
67	W/B	IGN RLY AY (F/B) CONT
68	R	DIMMER
69	GR	A/T SHIFT SELECT PWR SPLY
70	B	IGN RLY AY (PDM L/R) CONT
71	G	DR DOOR REG SW
72	SB	PASS DOOR REG SW
75	BR	COMBI SW INPUT 5
76	BG	COMBI SW INPUT 4

77	V	COMBI SW INPUT 3
78	R	COMBI SW INPUT 2
79	LG	COMBI SW INPUT 1
80	L	TR LIP OPKR SW

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-C516-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	
2	G	
3	SB	
4	BR	
5	R	
6	W	
7	W	
8	V	
9	BR	
10	P	
11	BR	
12	LG	
13	LG	
14	Y	
15	W	
16	W	
17	BR	
18	B	
19	B	
20	V	
21	V	
22	P	
23	SB	
24	LG	
25	G	
26	W	
27	W	
28	B	
29	B	
30	V	
31	V	
32	B	
33	B	
34	V	
35	P	
36	W	
37	SB	
38	LG	
40	P	
41	G	
42	BR	
43	BR	
44	BR	
46	BR	
51	Y	
52	V	

54	R	
55	R	
56	W	
57	W	
58	BG	
59	BG	
62	EG	
63	BR	
64	Y	
65	W	
70	LG	
71	W	
72	B	
74	L	
75	W	
76	BR	
77	B	
81	B	
83	BG	
84	L	
85	W	
86	B	
88	G	
91	GR	
94	GR	
96	W	
97	V	
98	BR	

Connector No.	M22
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-C516-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	
2	L	
3	R	
4	SHIELD	
5	G	
6	BG	
7	LG	


CAN SYSTEM (WITH ICC)

CAN SYSTEM (WITH ICC)

8	P	--
9	SHIELD	--
10	V	--
11	GR	--
12	GR	--
13	LG	--
14	LG	--
15	P	--
16	SB	-- (With DCM)
17	V	-- (Without DCM)
18	Y	--
19	L	--
20	GR	--
21	R	--
22	W	--
23	L	--
24	V	--
25	LG	--
26	GR	--
29	SB	--
30	LG	--
36	R	--
37	R	--
38	W	--
39	V	--
45	G	--
46	SHIELD	--
47	G	--
48	BR	--
49	SB	--
52	R	--
53	GR	--
57	R	--
58	SB	--
59	LG	--
62	V	--
63	L	--
64	W	--
66	R	--
68	L	--
69	P	--
71	R	--
72	G	--
73	SHIELD	--
76	V	--
84	BR	--
85	BR	--
86	V	--

87	LG	--
89	BR	--
90	V	--
92	R	--
94	R	--
95	Y	--
96	W	--
97	L	--
99	BR	--
100	BR	--

Connector No.	M24
Connector Name	CAN GATEWAY
Connector Type	TH1ZFV-NH




Terminal No.	Color	Wire	Signal Name [Specification]
1	L	L	CAN-H
3	W	W	BATTERY
4	L	L	CAN2-H
5	B	B	GRD
6	B	B	CAN2-H
7	L	L	IGN SW
9	R	R	IGN SW
10	R	R	AV COMM (H)
11	B	B	CAN-L
12	R	R	CAN2-L

Connector No.	M25
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color	Wire	Signal Name [Specification]
3	SB	SB	AV COMM (L)
4	B	B	EARTH
5	B	B	EARTH
6	L	L	CAN-H
7	V	V	K-LINE
8	W	W	IGN SW
11	LG	LG	AV COMM (H)
12	R	R	CAN-L
13	L	L	CAN-H
14	P	P	CAN-L
16	W	W	POWER


Connector No.	M37
Connector Name	ECM
Connector Type	RH24FGV-R28-R-LH-Z



Terminal No.	Color	Wire	Signal Name [Specification]
87	Y	Y	ACCELERATOR PEDAL POSITION SENSOR 1
88	BR	BR	ACCELERATOR PEDAL POSITION SENSOR 2
89	W	W	RESERVE POWER SUPPLY ACCELERATOR PEDAL POSITION SENSOR 1
100	G	G	RESERVE POWER SUPPLY ACCELERATOR PEDAL POSITION SENSOR 2
101	SB	SB	ASCD STEERING SWITCH
102	LG	LG	ECM STEERING SWITCH
104	L	R	EVAP CONTROL SYSTEM PRESSURE SENSOR
			RESERVE POWER SUPPLY ACCELERATOR PEDAL POSITION SENSOR 1
			RESERVE POWER SUPPLY ACCELERATOR PEDAL POSITION SENSOR 2

105	L	L	REFRIGERANT PRESSURE SENSOR
106	P	P	FUEL TANK TEMPERATURE SENSOR
107	GR	GR	SENSOR GROUND (ASCD) (3) STEERING SWITCH
108	BR	BR	RESERVE POWER SUPPLY ACCELERATOR PEDAL POSITION SENSOR 1
109	BR	BR	RESERVE POWER SUPPLY ACCELERATOR PEDAL POSITION SENSOR 2
110	V	V	ENGINE SPEED SIGNAL SWITCH
112	V	V	ENGINE SPEED SIGNAL SWITCH
113	V	V	ENGINE SPEED SIGNAL SWITCH
114	L	L	CAN COMMUNICATION LINE
117	V	V	DATA LINK CONNECTOR
121	LG	LG	EVAP CANISTER VENT CONTROL VALVE
122	SB	SB	STOP LAMP SWITCH
123	B	B	ECM GROUND
124	B	B	ECM GROUND
125	R	R	POWER SUPPLY FOR ECM
126	BG	BG	BRAKE PEDAL POSITION SWITCH
127	B	B	ECM GROUND
128	B	B	ECM GROUND

Connector No.	M39
Connector Name	WIRE TO WIRE
Connector Type	TH1ZFV-NH



Terminal No.	Color	Wire	Signal Name [Specification]
2	W/B	W/B	--
3	SB	SB	--
4	P	P	-- (Without Gateway)
4	P	P	-- (With Gateway)
7	L	L	--
8	W	W	--
13	G	G	--
15	R	R	--
17	BR	BR	--
18	BG	BG	--
27	LG	LG	--
28	BR	BR	--
29	W/B	W/B	--
30	Y	Y	--
31	W	W	--
32	LG	LG	--

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN SYSTEM (WITH ICC)

CAN SYSTEM (WITH ICC)

Connector No.	IM40
Connector Name	WIRE TO WIRE
Connector Type	TH18FW-NH




H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	-
3	L	-
4	V	-
6	W/B	-
7	V	-
10	W	-
11	W	-
12	B	-
13	GR	-
14	B	-
15	SB	-
16	B	-
17	LG	-
18	B	-
31	W	-
32	RG	-
33	G	-
37	B	-
38	B	-
39	Y	-
40	GR	-
41	L	-
44	BR	-
45	W	-
46	G	-
47	R	-
48	SHIELD	-
49	B	-
50	BR	-
51	L	-
52	W	-
53	G	-
54	Y	-
55	P	-
56	BG	-

CAN SYSTEM (WITH ICC)

Connector No.	IM42
Connector Name	AWD CONTROL UNIT
Connector Type	TH18FW-NH



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
57	GR	-
58	B	-
59	SB	-
60	W/B	-
64	Y	-
65	R	-
66	V	-
67	LG	-
68	BG	-
71	V	-
72	LG	-
73	R	-
74	BR	-
75	B	-
78	G	-
79	R	-
83	R	-
86	V	-
91	W	-
92	R	-
94	BG	-
95	BR	-
96	W	-
97	LG	-
98	Y	-
99	BR	-
100	SHIELD	-

CAN SYSTEM (WITH ICC)

Connector No.	IM56
Connector Name	DRIVER ASSISTANCE BUZZER CONTROL MODULE
Connector Type	TH18FW-NH




H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	IGNITION
3	L	ITS COMM-H
5	B	GROUND
8	R	WARNING BUZZER SIGNAL
11	Y	ITS COMM-L
13	B	GROUND
16	G	WARNING BUZZER SIGNAL GROUND

CAN SYSTEM (WITH ICC)

Connector No.	IM67
Connector Name	WIRE TO WIRE
Connector Type	RH12FB




H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	G	-
3	L	-
4	W	-
5	G	-
6	Y	-
7	B	-
9	Y	-
10	L	-
11	R	-
12	BR	-

CAN SYSTEM (WITH ICC)

Connector No.	IM71
Connector Name	STEERING FORCE CONTROL MODULE
Connector Type	RH24FB-R28-L-RH



H.S.

Terminal No.	Color Of Wire	Signal Name [Specification]
2	L	CAN-H
4	P	ILLUMINATION CONTROL SIGNAL
43	B	FUEL LEVEL SENSOR GROUND
44	Y	BATTERY POWER SUPPLY
45	W	IGNITION SIGNAL

CAN SYSTEM (WITH ICC)


< WIRING DIAGRAM >

[CAN]


CAN SYSTEM (WITH ICC)

6	O	STEERING FORCE MOTOR RESOLVE SIGNAL (SF-SL)
10	B	STEERING FORCE MOTOR RESOLVE SIGNAL (M-FS)
11	R	STEERING FORCE MOTOR RESOLVE SIGNAL (RF-FS)
14	L	CAN COMMUNICATION-L (Without Gateway)
15	R	CAN COMMUNICATION-R (Without Gateway)
17	Y	CAN COMMUNICATION-L (With Gateway)
18	Y	CAN COMMUNICATION-R (With Gateway)
19	W	BACK UP SIGNAL FROM STEERING ANGLE SENSOR CONTROL MODULE
20	V	FLEXBAY COMMUNICATION-H
22	BG	FLEXBAY COMMUNICATION-L
23	BR	CAN WAKE UP
24	R	BACK UP SIGNAL TO STEERING ANGLE SENSOR CONTROL MODULE
25	W	IGNITION POWER SUPPLY
26	R/W	STEERING CLUTCH +
27	W/B	IGNITION POWER SUPPLY TO STEERING ANGLE SENSOR CONTROL MODULE
28	R	STEERING CLUTCH -
29	L	FORCE MOTOR TEMPERATURE SENSOR -
30	B	GROUND
31	R	FORCE MOTOR TEMPERATURE SENSOR +
32	B	GROUND

Connector No.	IM74
Connector Name	WIRE TO WIRE
Connector Type	INS12FW-OS




Connector No.	IM75
Connector Name	WIRE TO WIRE
Connector Type	TH32FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	W	-
4	BR	-
5	R	-
6	G	-
7	B	-
10	V	-
11	LG	-
12	W	-
13	G	-
14	B	-
16	R	-
17	SHIELD	-
18	G	-
19	L	-
21	B	-
22	Y	-
25	W	-
26	B	-
27	GR	-
28	GR	-
29	W	-
31	W	-
32	L	-

Connector No.	IM76
Connector Name	SOMAR CONTROL UNIT
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	CENTER SENSOR SIGNAL FRONT RH
2	LG	CENTER SENSOR SIGNAL FRONT LH
3	W	CORNER SENSOR SIGNAL FRONT LH
4	GR	CORNER SENSOR SIGNAL FRONT RH
5	L	CAN-H
6	R	CAN-L (With Gateway)
9	G	CAN-L (Without Gateway)
10	BG	CENTER SENSOR SIGNAL REAR RH
12	R	IGN
13	B	CORNER SENSOR SIGNAL REAR RH
14	B	FRONT SENSOR GND
15	B	REAR SENSOR GND
18	GR	FRONT BUZZER DRIVE SIGNAL
19	P	BUZZER POWER SUPPLY
21	BR	CENTER SENSOR SIGNAL REAR LH
22	W	CORNER SENSOR SIGNAL REAR LH


Connector No.	IM77
Connector Name	STEERING ANGLE SENSOR
Connector Type	TH8BFW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	P	CAN-L (Without Gateway)
2	R	CAN-L (With Gateway)
4	G	IGN

Connector No.	IM78
Connector Name	TCU
Connector Type	TH40BFW-NH

Connector No.	IM81
Connector Name	TCU
Connector Type	TH40BFW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	BAT
2	B	GND
3	V	ACC
4	R	IGN
5	SB	ACC OUTPUT
6	SB	-
7	B	GND
9	L	CAN-H
10	P	CAN-L
14	B	AUDIO TYPE RECOGNITION SIGNAL
18	L	MICROPHONE VCC
19	G	MICROPHONE SIGNAL
20	SHIELD	SHIELD
21	L	MICROPHONE VCC
22	G	SOUND SIGNAL
23	SHIELD	SHIELD
34	SH	SOS CAN SWITCH SIGNAL
35	BR	SOS SWITCH LED SIGNAL

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN SYSTEM (WITH ICC)

CAN SYSTEM (WITH ICC)

Connector No.	M88
Connector Name	A/C AUTO AMP.
Connector Type	TH48FW-NH



H.S.

Terminal No.	Color	Wire	Signal Name [Specification]
1	L	R	CAN-H
2	B	BR	GND
3	W	R	BAT
7	G	P	AMBIENT SENS
9	R	P	SUNLOAD SENS
13	V	P	IGN SW ACC
16	P	R	IGN SW ON
17	R	R/W	DOOR MOTOR PWR SPRLY
18	P	R	BLOWER MOTOR CONT
20	L	L	HEAT STRG WHL RLY CONT
21	P	P	CAN-L
22	B	B	GND
23	W	W	IGN SW ON
26	B	B	SENS GND
27	EG	EG	IN-VEHICLE SENS
28	BR	BR	INTAKE SENS
30	EG	EG	EXH GAS/OUT GND/DIGT SENS
31	B	B	GND
38	EG	EG	IONIZER CONT
40	EG	EG	ECU CONT

H.S.

Connector No.	M95
Connector Name	WIRE TO WIRE
Connector Type	TH168MM-NH




H.S.

Terminal No.	Color	Wire	Signal Name [Specification]
1	R	R	-
3	BR	BR	-
5	R	R	- [With Gateway]
6	P	P	- [Without Gateway]
7	P	P	- [Without Gateway]
9	R/W	R/W	- [With Gateway]
10	R	R	-
11	SHIELD	SHIELD	-
13	L	L	-
14	L	L	-
15	L	L	-

H.S.

Connector No.	M100
Connector Name	DISPLAY CONTROL UNIT
Connector Type	TH24FW-NH




H.S.

Terminal No.	Color	Wire	Signal Name [Specification]
16	SB	P	AV COMM (L)
17	P	P	CAN-L
19	R	R	DIMMER SIGNAL
20	BR	BR	REVERSE SIGNAL
22	B	B	GND
25	SB	SB	-
26	BR	BR	CAMERA SWITCH SIGNAL

H.S.

28	LG	AV COMM (H)
29	L	CAN-H
30	R	VEHICLE SPEED SIGNAL (8-PULSE)
31	W	ACC
33	SD	ACC
34	Y	BAT

Connector No.	M124
Connector Name	ACCELERATOR PEDAL ACTUATOR/ACCELERATOR PEDAL POSITION SENSOR
Connector Type	RH12FB




H.S.

Terminal No.	Color	Wire	Signal Name [Specification]
1	BR	BR	BATTERY
2	G	G	IGNITION
3	L	L	ITS COMM-H
4	W	W	-
5	G	G	-
6	Y	Y	-
7	B	B	GROUND
9	Y	Y	ITS COMM-L
10	L	L	-
11	L	L	-
12	BR	BR	-

H.S.

Connector No.	M125
Connector Name	WIRE TO WIRE
Connector Type	RH12MB




H.S.

Terminal No.	Color	Wire	Signal Name [Specification]
1	BR	BR	-
2	G	G	-
3	L	L	-

4	L	- [With ASCD]
4	W	- [With ASCD]
5	G	- [With ASCD]
6	W	- [With ASCD]
8	Y	- [With ASCD]
9	Y	- [With ASCD]
10	GR	- [With ASCD]
10	L	- [With ADAS]
11	V	- [With ADAS]
12	BR	- [With ADAS]
12	P	- [With ASCD]

Connector No.	M133
Connector Name	FUSE BLOCK (J/FB)
Connector Type	TH48FW-NH



H.S.

Terminal No.	Color	Wire	Signal Name [Specification]
15C	Y	Y	-
17C	Y	Y	-
13C	Y	Y	-
14C	Y	Y	-
15C	R	R	-
16C	R	R	-
17C	L	L	-
18C	EG	EG	- [Without DRPO]
18C	P	P	- [With DRPO]
19C	B	B	-
20C	W	W	-
21C	L	L	-
22C	L	L	-
23C	L	L	-
25C	LG	LG	-
26C	SB	SB	-
27C	P	P	-
28C	W	W	-
29C	W	W	-
2C	R	R	-

H.S.

CAN SYSTEM (WITH ICC)


< WIRING DIAGRAM >

[CAN]

CAN SYSTEM (WITH ICC)

30C	R	-
31C	W	-
32C	R	-
33C	B	-
34C	WB	-
35C	SB	-
36C	W	-
37C	W	-
38C	W	-
39C	V	-
3C	P	-
40C	G	-
4C	P	-
5C	P	-
6C	G	-
7C	G	-
9C	V	-


Connector No.	M155
Connector Name	WIRE TO WIRE
Connector Type	TH1BFV-NH



HS

Terminal No.	Color Of Wire	Signal Name [Specification]
3	R	-
5	R	-
6	R	-
7	R	-
8	R	-
9	R/W	-
10	R	-
11	SHIELD	-
13	L	-
14	L	-
15	L	-

Connector No.	R2
Connector Name	WIRE TO WIRE
Connector Type	TH3ZBM-NH



HS

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	BG	-
3	SB	-
4	R	-
5	Y	-
6	BR	-
7	W	-
8	B	-
9	GR	-
10	BR	-
11	GR	-
12	V	-

Connector No.	R3
Connector Name	WIRE TO WIRE
Connector Type	TH3ZBM-NH



HS

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	GR	-
3	W	-
4	BR	-
5	R	-
6	G	-
7	B	-
10	BR	-

11	SB	-
12	GR	-
14	B	-
15	-	-
16	SHIELD	-
18	L	-
19	L	-
21	L5	-
22	V	-
23	GR	-
25	W	-
26	B	-
27	BR	-
28	BG	-
29	BG	-
31	W	-
32	L	-

HS




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	CAN GND
4	L	CAN-H
5	B	GND
7	V	IGN
8	W	CAN-L

Connector No.	R13
Connector Name	LANE CAMERA UNIT
Connector Type	TH3BFV-NH

11	SB	-
12	GR	-
14	B	-
15	-	-
16	SHIELD	-
18	L	-
19	L	-
21	L5	-
22	V	-
23	GR	-
25	W	-
26	B	-
27	BR	-
28	BG	-
29	BG	-
31	W	-
32	L	-

HS



Terminal No.	Color Of Wire	Signal Name [Specification]
3	B	GND
6	GR	AUTO ANTI-LOCK BRAKE SYSTEM (ABS) CONTROL SIGNAL
9	BR	IGNITION POWER SUPPLY
10	BG	AUTO ANTI-LOCKING OUTSIDE MIRROR GROUND
11	GR	BATTERY POWER SUPPLY
12	BR	CAN-H

Connector No.	R9
Connector Name	AUTO ANTI-LOCKING INSIDE MIRROR
Connector Type	TH12FW-NH-B

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

JRMWD9987GB

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Interview Sheet

INFOID:000000009239068

CAN Communication System Diagnosis Interview Sheet

Date received:

Type:

VIN No.:

Model:

First registration:

Mileage:

CAN system type:

Symptom (Results from interview with customer)

Condition at inspection

Error symptom : Present / Past

SKIB8898E

MALFUNCTION AREA CHART

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

DTC/CIRCUIT DIAGNOSIS

MALFUNCTION AREA CHART

CAN Communication Circuit

INFOID:000000009239070

MAIN LINE

Malfunction area	Reference
Main line between data link connector and A/C auto amp.	LAN-93, "Diagnosis Procedure"
Main line between A/C auto amp. and display control unit	LAN-94, "Diagnosis Procedure"
Main line between ABS actuator and electric unit (control unit) and driver seat control unit	LAN-97, "Diagnosis Procedure"
Main line between driver seat control unit and around view monitor control unit	LAN-98, "Diagnosis Procedure"
Main line between around view monitor control unit and sonar control unit	LAN-99, "Diagnosis Procedure"
Main line between sonar control unit and data link connector	LAN-93, "Diagnosis Procedure"
Main line between driver seat control unit and ADAS control unit	LAN-102, "Diagnosis Procedure"
Main line between ADAS control unit and steering force control module	LAN-103, "Diagnosis Procedure"
Main line between steering force control module and data link connector	LAN-105, "Diagnosis Procedure"

BRANCH LINE

Malfunction area	Reference
ECM branch line circuit	LAN-110, "Diagnosis Procedure"
Data link connector	LAN-111, "Diagnosis Procedure"
Data link connector branch line circuit (CAN communication circuit 1)	LAN-112, "Diagnosis Procedure"
Data link connector branch line circuit (CAN communication circuit 2)	LAN-113, "Diagnosis Procedure"
IPDM E/R branch line circuit	LAN-114, "Diagnosis Procedure"
TCM branch line circuit	LAN-115, "Diagnosis Procedure"
CAN gateway branch line circuit (CAN communication circuit 1)	LAN-117, "Diagnosis Procedure"
CAN gateway branch line circuit (CAN communication circuit 2)	LAN-118, "Diagnosis Procedure"
A/C auto amp. branch line circuit	LAN-119, "Diagnosis Procedure"
Combination meter branch line circuit	LAN-120, "Diagnosis Procedure"
Air bag diagnosis sensor unit branch line circuit	LAN-121, "Diagnosis Procedure"
AFS control unit branch line circuit	LAN-122, "Diagnosis Procedure"
Display control unit branch line circuit	LAN-123, "Diagnosis Procedure"
High beam assist control module branch line circuit	LAN-124, "Diagnosis Procedure"
TCU branch line circuit	LAN-125, "Diagnosis Procedure"
BCM branch line circuit	LAN-126, "Diagnosis Procedure"
ABS actuator and electric unit (control unit) branch line circuit	LAN-127, "Diagnosis Procedure"
Driver seat control unit branch line circuit	LAN-129, "Diagnosis Procedure"
Pre-crash seat belt control unit (driver side) branch line circuit	LAN-131, "Diagnosis Procedure"
ADAS control unit branch line circuit (CAN communication circuit 2)	LAN-132, "Diagnosis Procedure"
Steering force control module branch line circuit	LAN-134, "Diagnosis Procedure"
AWD control unit branch line circuit	LAN-135, "Diagnosis Procedure"
Chassis control module branch line circuit	LAN-136, "Diagnosis Procedure"
Steering angle sensor branch line circuit	LAN-137, "Diagnosis Procedure"

SHORT CIRCUIT

MALFUNCTION AREA CHART

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

Malfunction area	Reference
CAN communication circuit	LAN-147. "Diagnosis Procedure"
CAN communication circuit 1	LAN-149. "Diagnosis Procedure"
CAN communication circuit 2	LAN-151. "Diagnosis Procedure"

ITS Communication Circuit

INFOID:000000009239071

MAIN LINE

Malfunction area	Reference
Main line between side radar LH and around view monitor control unit	LAN-106. "Diagnosis Procedure"
Main line between around view monitor control unit and sonar control unit	LAN-99. "Diagnosis Procedure"

BRANCH LINE

Malfunction area	Reference
Side radar LH branch line circuit	LAN-138. "Diagnosis Procedure"
Side radar RH branch line circuit	LAN-139. "Diagnosis Procedure"
Around view monitor control unit branch line circuit	LAN-140. "Diagnosis Procedure"
Accelerator pedal actuator branch line circuit	LAN-141. "Diagnosis Procedure"
Driver assistance buzzer control module	LAN-142. "Diagnosis Procedure"
Sonar control unit	LAN-144. "Diagnosis Procedure"
ICC sensor branch line circuit	LAN-143. "Diagnosis Procedure"

SHORT CIRCUIT OR OPEN CIRCUIT

Malfunction area	Reference
ITS communication circuit	LAN-155. "Diagnosis Procedure"

Chassis Communication Circuit

INFOID:000000009755663

MAIN LINE

Malfunction area	Reference
Main line between steering angle main control module and lane camera unit	LAN-95. "Diagnosis Procedure"
Main line between steering angle main control module and ADAS control unit	LAN-107. "Diagnosis Procedure"
Main line between ADAS control unit and lane camera unit	LAN-109. "Diagnosis Procedure"

BRANCH LINE

Malfunction area	Reference
Steering angle main control module branch line circuit	LAN-145. "Diagnosis Procedure"
ADAS control unit branch line circuit (Chassis communication circuit)	LAN-133. "Diagnosis Procedure"
Lane camera unit branch line circuit	LAN-117. "Diagnosis Procedure"

SHORT CIRCUIT

Malfunction area	Reference
Chassis communication circuit	LAN-153. "Diagnosis Procedure"

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009239078

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the fuse block (J/B).

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.
NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009239082

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT

Diagnosis Procedure

INFOID:000000009719311

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M19
 - Harness connector B18
 - Harness connector M40
 - Harness connector E25

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Steering angle main control module
 - Harness connectors E25 and M40
2. Check the continuity between the harness connectors.

Steering angle main control module harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E26	14	E25	51	Existed
	15		52	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the steering angle main control module and the harness connector E25.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M19 and B18.
2. Check the continuity between the harness connectors M40 and M19.

Side radar LH harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M40	51	M19	74	Existed
	52		75	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connectors M40 and M19.

4.CHECK CONNECTOR

Check the continuity between the harness connector terminals.

Connector No.	Terminal No.		Continuity
B18	74	84	Existed
	75	85	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the main line between the harness connector B18.

MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M75 and R3.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M19	84	M75	32	Existed
	85		31	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the steering angle main control module and the lane camera unit.

NO >> Repair the main line between the harness connectors M19 and the lane camera unit.

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

Diagnosis Procedure

INFOID:000000009755672

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B39 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Fuse block (J/B) harness connector B39
 - ABS actuator and electric unit (control unit)
2. Check the continuity between the harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Fuse block (J/B) terminals		Continuity
Connector No.	Terminal No.	Terminal No.		
E35	25	6H		Existed
	15	4H		Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of driver seat control unit.
2. Check the continuity between the harness connector and the driver seat control unit harness connector.

Fuse block (J/B) harness connector		Driver seat control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B39	6H	B601	1	Existed
	4H		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the driver seat control unit.

NO >> Repair the main line between the harness connector B39 and the driver seat control unit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN ADP AND AVM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN ADP AND AVM CIRCUIT

Diagnosis Procedure

INFOID:000000009719612

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B37
 - Harness connector B72

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B600 and B12
 - Harness connectors B37 and B72
2. Check the continuity between the harness connector terminals.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B12	1	B37	4	Existed
	17		3	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of around view monitor control unit.
2. Check the continuity between the harness connector and the around view monitor control unit.

Harness connector		Around view monitor control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B72	4	B50	27	Existed
	3		28	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the driver seat control unit and the around view monitor control unit.

NO >> Replace the body harness.

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

Diagnosis Procedure

INFOID:000000009719613

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connectors B62
 - Harness connectors M22

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Harness connectors B62 and M22
2. Check the continuity between the around view monitor control unit harness connector and the harness connector.
 - With around view monitor, without ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	63	Existed
	28		53	Existed

- With ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	18	Existed
	28		17	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M95 and M155.
2. Check the continuity between the harness connectors.
 - With around view monitor, without ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	63	M95	15	Existed
	53		7	Existed

- With ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	18	M95	14	Existed
	17		6	Existed

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the around view monitor control unit and the sonar control unit.

NO >> Repair the main line between the harness connectors M22 and sonar control unit.

MAIN LINE BETWEEN SONAR AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN SONAR AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000009719614

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - CAN gateway
 - Harness connectors M155 and M95
4. Check the continuity between the harness connector and the data link connector.

Harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M95	15	M25	13	Existed
	7		12	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the sonar control unit and the data link connector.

NO >> Repair the main line between the sonar control unit and data link connector.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN ADP AND ICC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN ADP AND ICC CIRCUIT

Diagnosis Procedure

INFOID:000000009719615

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - CAN gateway
 - Harness connectors B600 and B12
 - ADAS control unit
4. Check the continuity between the harness connector and the ADAS control unit harness connector.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B12	1	B1	1	Existed
	17		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the driver seat control unit and the ADAS control unit.

NO >> Replace the body harness.

MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT

Diagnosis Procedure

INFOID:000000009719617

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B37
 - Harness connector B72
 - Harness connector B62
 - Harness connector M22

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ADAS control unit
 - Harness connectors B37 and B72
2. Check the continuity between the ADAS control unit harness connector and the harness connector.

ADAS control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	1	B37	4	Existed
	2		3	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B62 and M22.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B72	4	B62	63	Existed
	3		53	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the body harness.

4.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of steering force control module.
2. Check the continuity between the harness connector and the steering force control module.

Harness connector		Steering force control module harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	63	M71	14	Existed
	53		15	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

YES (Past error)>>Error was detected in the main line between the ADAS control unit and the steering force control module.

NO >> Repair the main line between the harness connector M22 and the steering force control module.

MAIN LINE BETWEEN EPS/DAST 3 AND STRG CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN EPS/DAST 3 AND STRG CIRCUIT

Diagnosis Procedure

INFOID:000000009719795

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following harness connectors.
 - CAN gateway
 - Steering force control module
4. Check the continuity between the steering force control module harness connector and the data link connector.

Steering force control module harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M71	14	M25	13	Existed
	15		12	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the steering force control module and the data link connector.

NO >> Repair the main line between the steering force control module and the data link connector.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN RDR-L AND AVM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN RDR-L AND AVM CIRCUIT

Diagnosis Procedure

INFOID:000000009719796

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B3
 - Harness connector B52

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B87 and B8
 - Harness connectors B3 and B52
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B87	6	B3	1	Existed
	5		9	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of around view monitor control unit.
2. Check the continuity between the harness connector and the around view monitor control unit harness connector.

Harness connector		Around view monitor control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B52	1	B50	27	Existed
	9		28	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the side radar LH and the around view monitor control unit control unit.

NO >> Replace the body harness.

MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT

Diagnosis Procedure

INFOID:000000009720262

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Chassis control module
 - Harness connectors E25
 - Harness connectors M40
 - Harness connector M19
 - Harness connectors B18
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Steering angle main control module
 - Harness connectors E25 and M40
2. Check the continuity between the steering angle main control module harness connector and harness connector.

Steering angle main control module harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E26	14	E25	51	Existed
	15		52	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the steering angle main control module harness connector and harness connector E25.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M19 and B18.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M40	51	M19	74	Existed
	52		75	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between harness connectors M40 and M19.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the harness connector B18 and ADAS control unit harness connector.

Harness connector		ADAS control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

B18	74	B1	8	Existed
	75		9	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the steering angle main control module and the ADAS control unit.

NO >> Replace the body harness.

MAIN LINE BETWEEN ICC AND LANE CIRCUIT

[CAN]

< DTC/CIRCUIT DIAGNOSIS >

MAIN LINE BETWEEN ICC AND LANE CIRCUIT

Diagnosis Procedure

INFOID:000000009720263

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Chassis control module
 - Harness connector B18
 - Harness connector M19

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ADAS control unit
 - Harness connectors B18 and M19
2. Check the continuity between the harness connector terminals.

ADAS control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	8	B18	84	Existed
	9		85	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M75 and R3.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M19	84	M75	32	Existed
	85		31	Existed

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
 YES (Past error)>>Error was detected in the main line between the ADAS control unit and the lane camera unit.
 NO >> Repair the main line between the harness connectors M19 and lane camera unit.

LAN

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239089

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 4.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ECM. Refer to [EC-578, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ECM branch line.

NO >> Repair the power supply and the ground circuit.

4.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009720267

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009720268

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 1 side).

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009720269

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector branch line.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	13	12	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 2 side).

NO >> Repair the data link connector branch line.

LAN

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239108

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009720264

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> GO TO 5.

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Replace the joint connector.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).
 YES (Past error)>>Error was detected in the TCM branch line.
 NO >> Repair the power supply and the ground circuit.

5.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

F2	3	E65	9F	Existed
	8		5F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

[CAN]

< DTC/CIRCUIT DIAGNOSIS >

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009239091

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors of CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of CAN gateway.
2. Check the resistance between the CAN gateway harness connector terminals.

CAN gateway harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	1	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172. "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 1 side).
- NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009239092

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - CAN gateway
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172. "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 2 side).
- NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the CAN gateway harness connector and the harness connector.

CAN gateway harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	4	M133	13C	Existed
	10		2C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
- NO >> Repair the harness between the CAN gateway harness connector M24 and the harness connector M133.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239093

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

M&A BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239098

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the combination meter branch line.
NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239095

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the main harness.

2. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

YES >> Replace the main harness.

NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

AFS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

AFS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239107

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AFS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AFS control unit.
2. Check the resistance between the AFS control unit harness connector terminals.

AFS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M4	1	13	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AFS control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AFS control unit. Refer to [EXL-128, "AFS CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AFS control unit. Refer to [EXL-181, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AFS control unit branch line.
NO >> Repair the power supply and the ground circuit.

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239097

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the display control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

HBA BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

HBA BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009720270

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Auto anti- dazzling inside mirror (High beam assist control module)
 - Harness connector R2
 - Harness connector M74

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of auto anti - dazzling inside mirror (High beam assist control module).
2. Check the resistance between the auto anti - dazzling inside mirror (High beam assist control module) harness connector terminals.

Auto anti - dazzling inside mirror (High beam assist control module) harness connector			Resistance (Ω)
Connector No.	Terminal No.		
R9	12	11	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the anti - dazzling inside mirror (High beam assist control module) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the anti - dazzling inside mirror (High beam assist control module). Refer to [EXL-128. "HIGH BEAM ASSIST CONTROL MODULE : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the inside mirror. Refer to [MIR-45. "Removal and Installation"](#) (With automatic drive positioner system) or [MIR-80. "Removal and Installation"](#) (Without automatic drive positioner system).

YES (Past error)>>Error was detected in the anti - dazzling inside mirror (High beam assist control module) branch line.

NO >> Repair the power supply and the ground circuit.

TCU BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

TCU BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239096

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the TCU for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCU.
2. Check the resistance between the TCU harness connector terminals.

TCU harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M81	9	10	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the TCU branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCU. Refer to [AV-589, "TCU : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the TCU. Refer to [AV-597, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the TCU branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239102

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239106

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
E35	25	15	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B)
- NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

ADP BRANCH LINE CIRCUIT

[CAN]

< DTC/CIRCUIT DIAGNOSIS >

ADP BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239109

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the follow terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit
 - Harness connectors B600 and B12
 - Harness connectors B39 and fuse block (J/B) side connector (Models without around view monitor system)

Is the inspection result normal?

- YES - 1 >> Models with around view monitor system: GO TO 2.
YES - 2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway. (Models with around view monitor system)
2. Disconnect the connector of driver seat control unit.
3. Check the resistance between the driver seat control unit harness connector terminals.

Driver seat control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B601	1	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO - 1 >> Models without around view monitor system: GO TO 5.
NO - 2 >> Models with around view monitor system: Repair the driver seat control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [ADP-75, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error) >> Replace the driver seat control unit. Refer to [ADP-145, "Removal and Installation"](#).
YES (Past error) >> Error was detected in the driver seat control unit branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector B39.
2. Check the continuity between the driver seat control unit harness connector B601 and the harness connector.

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

Driver seat control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B601	1	B39	3H	Existed
	17		8H	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the driver seat control unit harness connector B601 and the harness connector B39.

PSB BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

PSB BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239111

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - CAN gateway
 - Pre-crash seat belt control unit (driver side)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of pre-crash seat belt control unit (driver side).
3. Check the resistance between the pre-crash seat belt control unit (driver side) harness connector terminals.

Pre-crash seat belt control unit (driver side) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
B19	14	4	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the pre-crash seat belt control unit (driver side) branch line.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the pre-crash seat belt control unit (driver side). Refer to [SBC-62, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the seat belt pre-tensioner retractor (driver side). Refer to [SBC-76, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the pre-crash seat belt control unit (driver side) branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ICC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

ICC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009239110

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - CAN gateway

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of ADAS control unit.
3. Check the resistance between the ADAS control unit harness connector terminals.

ADAS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B1	1	2	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-160, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-161, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ADAS control unit branch line.

NO >> Repair the power supply and the ground circuit.

ICC BRANCH LINE CIRCUIT (CHASSIS COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

ICC BRANCH LINE CIRCUIT (CHASSIS COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009730064

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ADAS control unit.
2. Check the resistance between the ADAS control unit harness connector terminals.

ADAS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B1	8	9	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-160, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-161, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ADAS control unit branch line circuit (chassis communication circuit side).

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009720466

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering force control module
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering force control module.
3. Check the resistance between the steering force control module harness connector terminals.

Steering force control module harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M71	14	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering force control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering force control module. Refer to [STC-427, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering control module branch line.
NO >> Repair the power supply and the ground circuit.

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239104

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - AWD control unit
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of AWD control unit.
3. Check the resistance between the AWD control unit harness connector terminals.

AWD control unit harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M42	8	16	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the AWD control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-55. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009797489

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239103

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

RDR-L BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

RDR-L BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239112

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar LH
 - Harness connector B87
 - Harness connector B8

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of side radar LH.
2. Check the resistance between the side radar LH harness connector terminals.

Side radar LH harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B92	4	3	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar LH. Refer to [DAS-359, "SIDE RADAR LH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar LH. Refer to [DAS-386, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar LH branch line.

NO >> Repair the power supply and the ground circuit.

RDR-R BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

RDR-R BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239113

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar RH
 - Harness connector B87
 - Harness connector B8

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of side radar RH.
2. Check the resistance between the side radar RH harness connector terminals.

Side radar RH harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B93	4	3	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the side radar RH branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar RH. Refer to [DAS-360, "SIDE RADAR RH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar RH. Refer to [DAS-386, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar RH branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

AVM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009720502

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Around view monitor control unit
 - CAN gateway (Models without ICC)

Is the inspection result normal?

YES-1 >> Models without ICC: GO TO 2.

YES-2 >> Models with ICC: GO TO 3.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models without ICC).
2. Disconnect the connector of around view monitor control unit.
3. Check the resistance between the around view monitor control unit harness connector terminals.

Around view monitor control unit harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
B50	27	28	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the around view monitor control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the around view monitor control unit. Refer to [AV-435. "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the around view monitor control unit. Refer to [AV-458. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the around view monitor control unit branch line.

NO >> Repair the power supply and the ground circuit.

APA BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

APA BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239114

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Accelerator pedal actuator / accelerator pedal position sensor
 - Harness connector M125
 - Harness connector M67

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of accelerator pedal actuator / accelerator pedal position sensor.
2. Check the resistance between the accelerator pedal actuator harness connector terminals.

Accelerator pedal actuator / accelerator pedal position sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M124	3	9	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the accelerator pedal actuator branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the accelerator pedal actuator / accelerator pedal position sensor. Refer to [DAS-359, "ACCELERATOR PEDAL ACTUATOR : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the accelerator pedal assembly. Refer to [ACC-4, "MODELS WITH DISTANCE CONTROL ASSIST SYSTEM : Removal and Installation"](#).

YES (Past error)>>Error was detected in the accelerator pedal actuator branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

BSW/BUZZER BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

BSW/BUZZER BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009720553

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the drive assistance buzzer control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of drive assistance buzzer control module.
2. Check the resistance between the drive assistance buzzer control module harness connector terminals.

Drive assistance buzzer control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M56	3	11	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the drive assistance buzzer control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the drive assistance buzzer control module. Refer to [DAS-361, "DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the drive assistance buzzer control module. Refer to [DAS-389, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the drive assistance buzzer control module branch line.
NO >> Repair the power supply and the ground circuit.

LASER BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

LASER BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239116

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ICC sensor
 - Harness connector E76
 - Harness connector E14
 - Harness connector E25
 - Harness connector M40

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ICC sensor.
2. Check the resistance between the ICC sensor harness connector terminals.

ICC sensor harness connector		Resistance (Ω)
Connector No.	Terminal No.	
E80	3	Approx. 108 – 132
	6	

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the ICC sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ICC sensor. Refer to [CCS-118. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ICC sensor. Refer to [CCS-135. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ICC sensor branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

SONAR BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

SONAR BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009720554

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Sonar control unit
 - Harness connector M95
 - Harness connector M155
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of sonar control unit.
3. Check the resistance between the sonar control unit harness connector terminals.

Sonar control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M76	5	6	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the sonar control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the sonar control unit. Refer to [AV-435, "SONAR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the sonar control unit. Refer to [AV-462, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the sonar control unit branch line.
NO >> Repair the power supply and the ground circuit.

DAST 1 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

DAST 1 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009720555

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle main control module
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of steering angle main control module.
3. Check the resistance between the steering angle main control module harness connector terminals.

Steering angle main control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E26	14	15	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the steering angle main control module branch line.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle main control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the steering angle main control module. Refer to [STC-428, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the steering angle main control module branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

LANE BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

LANE BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009239115

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Lane camera unit
 - Harness connector R13
 - Harness connector M75
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of lane camera unit.
3. Check the resistance between the lane camera unit harness connector terminals.

Lane camera unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
R13	4	8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the lane camera unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the lane camera unit. Refer to [DAS-610, "LANE CAMERA UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the lane camera unit. Refer to [DAS-620, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the lane camera unit branch line.

NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009239117

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

CAN COMMUNICATION CIRCUIT 1

Diagnosis Procedure

INFOID:000000009239118

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 1.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 1.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CAN COMMUNICATION CIRCUIT 2

[CAN]

< DTC/CIRCUIT DIAGNOSIS >

CAN COMMUNICATION CIRCUIT 2

Diagnosis Procedure

INFOID:000000009239119

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 2.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	13	Not existed
	12	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	13		Not existed
	12		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK CAN GATEWAY TERMINATION CIRCUIT

1. Remove the CAN gateway.
2. Check the resistance between the CAN gateway terminals.

CAN gateway		Resistance (Ω)
Terminal No.		
4	10	Approx. 108 – 132
6	12	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the CAN gateway.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 6.
Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 2.

NOTE:

CAN gateway has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

CHASSIS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009239120

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and/or CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and/or CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on chassis communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the chassis control module harness connector.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	7	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Chassis control module harness connector		Ground	Continuity
Connector No.	Terminal No.		
M22	19		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK CHASSIS CONTROL MODULE TERMINATION CIRCUIT

1. Remove the chassis control module.
2. Check the resistance between the chassis control module terminals.

Chassis control module		Resistance (Ω)
Terminal No.		
19	7	Approx. 108 – 132
11	8	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 6.

NO >> Replace the chassis control module.

6. CHECK SYMPTOM

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CHASSIS COMMUNICATION CIRCUIT

[CAN]

< DTC/CIRCUIT DIAGNOSIS >

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 7.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

7.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of chassis communication circuit.

NOTE:

Chassis control module has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

ITS COMMUNICATION CIRCUIT

[CAN]

< DTC/CIRCUIT DIAGNOSIS >

ITS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009720810

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1, CAN communication circuit 2 and ITS communication circuit have no malfunction.

Are the CAN communication 1 and CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ADAS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ADAS control unit
 - ICC sensor
2. Check the continuity between the ADAS control unit harness connector and the ICC sensor harness connector.

ADAS control unit harness connector		ICC sensor harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	6	E80	3	Existed
	7		6	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness between the ADAS control unit and the ICC sensor.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

1. Disconnect the following harness connectors.
 - Side radar LH
 - Side radar RH
 - Around view monitor control unit
 - Accelerator pedal actuator / accelerator pedal position sensor
 - Driver assistance buzzer control module
 - Sonar control unit
2. Check the continuity between the ADAS control unit harness connector terminals.

ADAS control unit harness connector			Continuity
Connector No.	Terminal No.		
B1	6	7	Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the ADAS control unit harness connector and the ground.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN]

ADAS control unit harness connector		Ground	Continuity
Connector No.	Terminal No.		
B1	6		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

6.CHECK TERMINATION CIRCUIT

1. Remove the ADAS control unit and the ICC sensor.
2. Check the resistance between the ADAS control unit terminals.

ADAS control unit		Resistance (Ω)
Terminal No.		
6	7	Approx. 108 – 132

3. Check the resistance between the ICC sensor terminals.

ICC sensor		Resistance (Ω)
Terminal No.		
3	6	Approx. 108 – 132

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace the ADAS control unit and/or the ICC sensor.

7.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 8.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

8.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of ITS communication circuit.

NOTE:

ADAS control unit and ICC sensor have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009755511

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

A
B
C
D
E
F
G
H
I
J
K
L

LAN


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009755485




① CAN gateway

A Over the instrument lower panel

SYSTEM

System Description

INFOID:000000009755486



- The CAN gateway system communicates between two CAN communication circuits.
- This system selects and transmits only necessary information.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DIAGNOSIS SYSTEM (CAN GATEWAY)

[CAN GATEWAY]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (CAN GATEWAY)

CONSULT Function

INFOID:000000009755487

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with CAN gateway.

Diagnosis mode	Function Description
Self Diagnostic Result	Displays the diagnosis results judged by CAN gateway.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.
ECU Identification	The CAN gateway part number is displayed.
Configuration	<ul style="list-style-type: none">Read and save the vehicle specification.Write the vehicle specification when replacing CAN gateway.

SELF DIAGNOSTIC RESULT

Refer to [LAN-162, "DTC Index"](#).

- When "CRNT" is displayed on "Self Diagnostic Result"
 - The system is presently malfunctioning.
- When "PAST" is displayed on "Self Diagnostic Result"
 - System malfunction in the past is detected, but the system is presently normal.

Freeze Frame Data (FFD)

When DTC is detected, a vehicle state shown below is recorded and displayed on CONSULT.

Item name	Display item
IGN COUNTER (0 – 39)	<p>The number of times that ignition switch is turned ON after the DTC is detected is displayed.</p> <ul style="list-style-type: none">When "0" is displayed: It indicates that the system is presently malfunctioning.When except "0" is displayed: It indicates that system malfunction in the past is detected, but the system is presently normal. <p>NOTE: Each time when ignition switch is turned OFF to ON, numerical number increases in 1 → 2 → 3...38 → 39. When the operation number of times exceeds 39, the number do not increase and "39" is displayed until self-diagnosis result is erased.</p>

CAN DIAG SUPPORT MONITOR

The results of transmit/receive diagnosis of CAN communication can be read.

ECU IDENTIFICATION

The part number of CAN gateway is displayed.

CONFIGURATION

Configuration includes functions as follows.

Function	Description
Read / Write Configuration	Before Replace ECU <ul style="list-style-type: none">Reads the vehicle configuration of current CAN gateway.Saves the read vehicle configuration.
	After Replace ECU <ul style="list-style-type: none">Writes the vehicle configuration with saved data.
Manual Configuration	Writes the vehicle configuration with manual selection.

CAUTION:

Follow the instructions listed below. Failure to do this may cause malfunctions to the CAN gateway.:

- When replacing CAN gateway, you must perform "Read / Write Configuration" or "Manual Configuration" with CONSULT.
- Complete the procedure of "Read / Write Configuration" or "Manual Configuration" in order.
- If you set incorrect "Read / Write Configuration" or "Manual Configuration", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Read / Write Configuration" or "Manual Configuration" except for new CAN gateway.

CAN GATEWAY

< ECU DIAGNOSIS INFORMATION >

[CAN GATEWAY]


ECU DIAGNOSIS INFORMATION

CAN GATEWAY

Reference Value

INFOID:000000009755488

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Standard	Reference value
+	-	Signal name	Input/ Output			
1 (L)	—	CAN-H (CAN communication circuit 1)	Input/ Output	—	—	—
3 (W)	5 (B) 11 (B)	Battery power supply	Input	Ignition switch OFF	6 – 16 V	Battery voltage
4 (L)	—	CAN-H (CAN communication circuit 2)	Input/ Output	—	—	—
6 (L)	—	CAN-H (CAN communication circuit 2)	Input/ Output	—	—	—
7 (P)	—	CAN-L (CAN communication circuit 1)	Input/ Output	—	—	—
9 (R)	5 (B) 11 (B)	Ignition power supply	Input	Ignition switch ON	4.5 – 16 V	Battery voltage
10 (R)	—	CAN-L (CAN communication circuit 2)	Input/ Output	—	—	—
12 (R)	—	CAN-L (CAN communication circuit 2)	Input/ Output	—	—	—

LAN

DTC Inspection Priority Chart

INFOID:000000009755489

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	<ul style="list-style-type: none"> • B2600: CONFIG ERROR • U1010: CONTROL UNIT(CAN)
2	U1000: CAN COMM CIRCUIT

CAN GATEWAY

< ECU DIAGNOSIS INFORMATION >

[CAN GATEWAY]


DTC Index

INFOID:000000009755490

DTC	CONSULT display	Reference
—	No DTC is detected. Further testing may be required.	—
U1000	CAN COMM CIRCUIT	LAN-167, "DTC Description"
U1010	CONTROL UNIT(CAN)	LAN-168, "DTC Description"
B2600	CONFIG ERROR	LAN-169, "DTC Description"
	WRONG DATA	
	NOT CONFIGURED	

WIRING DIAGRAM
CAN GATEWAY SYSTEM
Wiring Diagram

INFOID:000000009755491



CAN GATEWAY SYSTEM

LAN

2013/05/17

JRMWD9988GB


CAN GATEWAY SYSTEM

< WIRING DIAGRAM >

[CAN GATEWAY]


CAN GATEWAY SYSTEM

Connector No.	M324
Connector Name	CAN GATEWAY
Connector Type	TH12FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	CAN-H
2	W	BATTERY
3	L	CAN-H
4	L	CAN-H
5	B	GND
6	L	CAN-H
7	P	CAN-L
8	R	IGN
9	R	IGN
10	R	CANZ-L
11	B	GND
12	R	CANZ-L

Connector No.	M133
Connector Name	FUSE BLOCK (J/B)
Connector Type	TH46FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	V	-
11C	V	-
12C	Y	-
13C	Y	-
14C	R	-
15C	R	-
16C	R	-
17C	L	-
18C	BG	- [Without DRPO]
18C	P	- [With DRPO]

18C	B	-
19C	W	-
21C	L	-
22C	L	-
23C	L	-
25C	LG	-
26C	SB	-
27C	P	-
28C	W	-
29C	W	-
2C	R	-
30C	R	-
31C	W	-
32C	R	-
33C	W/B	-
34C	SB	-
35C	SB	-
36C	R	-
37C	W	-
38C	SB	-
39C	V	-
3C	P	-
40C	G	-
4C	P	-
5C	P	-
6C	G	-
7C	G	-
8C	V	-

BASIC INSPECTION

ADDITIONAL SERVICE WHEN REPLACING CAN GATEWAY

Description

INFOID:000000009755492

BEFORE REPLACEMENT

When replacing CAN gateway, save or print current vehicle specification with CONSULT configuration before replacement.

NOTE:

If “Before Replace ECU” of “Read / Write Configuration” can not be used, use the “Manual Configuration” after replacing CAN gateway.

AFTER REPLACEMENT

CAUTION:

Follow the instructions listed below. Failure to do this may cause malfunctions to the CAN gateway.:

- When replacing CAN gateway, you must perform “Read / Write Configuration” or “Manual Configuration” with CONSULT.
- Complete the procedure of “Read / Write Configuration” or “Manual Configuration” in order.
- If you set incorrect “Read / Write Configuration” or “Manual Configuration”, incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform “Read / Write Configuration” or “Manual Configuration” except for new CAN gateway.

Work Procedure

INFOID:000000009755493

1. SAVING VEHICLE SPECIFICATION

ⓂCONSULT Configuration

Perform “Before Replace ECU” of “Read / Write Configuration” to save or print current vehicle specification.

NOTE:

If “Before Replace ECU” of “Read / Write Configuration” can not be used, use the “Manual Configuration” after replacing CAN gateway.

>> GO TO 2.

2. REPLACE CAN GATEWAY

Replace CAN gateway. Refer to [LAN-172, "Removal and Installation"](#).

>> GO TO 3.

3. WRITING VEHICLE SPECIFICATION

ⓂCONSULT Configuration

Perform “After Replace ECU” of “Read / Write Configuration” or “Manual Configuration” to write vehicle specification. Refer to [LAN-166, "Work Procedure"](#).

>> WORK END

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CONFIGURATION (CAN GATEWAY)

Work Procedure

INFOID:000000009755494

1. WRITING MODE SELECTION

ⓅCONSULT Configuration
Select "Re/programming, Configuration" of CAN gateway.

When writing saved data>>GO TO 2.
When writing manually>>GO TO 3.

2. PERFORM "AFTER REPLACE ECU" OF "READ / WRITE CONFIGURATION"

ⓅCONSULT Configuration
Perform "After Replace ECU" of "Read / Write Configuration".

>> GO TO 4.

3. PERFORM "MANUAL CONFIGURATION"

ⓅCONSULT Configuration
1. Select "Manual Configuration".
2. Identify the correct model and configuration list. Refer to [LAN-166, "Configuration List"](#)

NOTE:

If items are not displayed, go to step 4.

3. Confirm and/or change setting value for each item.
4. Touch "Next".
5. Touch "OK".

NOTE:

Make sure to select "OK" even if the indicated configuration of brand new CAN gateway is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model can not be memorized.

6. Check that the configuration has been successfully written and touch "End".

>> GO TO 4.

4. CHECK ALL ECU SELF-DIAGNOSIS RESULTS

1. Erase all ECU self-diagnosis results using CONSULT.
2. Turn the ignition switch OFF.
3. Turn the ignition switch ON and wait for 2 seconds or more.
4. Check that all ECU self-diagnosis results have no DTC (e.g. U1000 and U1001) of CAN communication.

>> WORK END

Configuration List

INFOID:000000009790566

CAUTION:
Check vehicle specifications before servicing.

MANUAL SETTING ITEM		NOTE
Items	Setting value	
ENGINE TYPE	TYPE 1 ⇔ TYPE 2	<ul style="list-style-type: none"> TYPE 1: VQ37VHR engine models TYPE 2: OM651 engine models
ADP or PSB	WITHOUT ⇔ WITH	<ul style="list-style-type: none"> WITHOUT: Without automatic drive positioner and pre-crash seat belt system WITH: With automatic drive positioner or pre-crash seat belt system

⇔: Items which confirm vehicle specifications.

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

DTC Description

INFOID:000000009755495

DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-44, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

DTC DETECTION LOGIC

DTC	Trouble diagnosis (Trouble diagnosis contents)	Detecting condition
U1000	CAN COMM CIRCUIT (CAN communication circuit)	When CAN gateway cannot communicate CAN communication signal continuously for 2 seconds or more.

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

Only the CAN signal transmission of control unit which cannot communicate cannot be transmitted

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓜ With CONSULT

1. Turn ignition switch ON and wait at least 2 seconds or more.
2. Select "Self Diagnostic Result" mode of "CAN GATEWAY" using CONSULT.
3. Check DTC.

Is DTC U1000 detected?

- YES >> Proceed to [LAN-167, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: [GI-43, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000009755496

1. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

1. Turn ignition switch ON.
2. Erase DTC.
3. Perform DTC confirmation procedure again. Refer to [LAN-167, "DTC Description"](#).
4. Check DTC.

Is DTC U1000 displayed?

- YES >> Perform trouble diagnosis procedure for CAN communication system. Refer to [LAN-26, "Trouble Diagnosis Flow Chart"](#).
- NO >> INSPECTION END

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

U1010 CONTROL UNIT (CAN)

DTC Description

INFOID:000000009755497

DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real-time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independently). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-44, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

DTC DETECTION LOGIC

DTC	Trouble diagnosis (Trouble diagnosis contents)	Detecting condition
U1010	CONTROL UNIT (CAN) [Control unit (CAN)]	When an error is detected during the initial diagnosis for CAN controller of CAN gateway.

POSSIBLE CAUSE

CAN gateway

FAIL-SAFE

Transmission and reception of the signal between CAN communication circuit 1 and CAN communication circuit 2 are stopped

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

With CONSULT

1. Turn ignition switch ON and wait at least 2 seconds or more.
2. Select "Self Diagnostic Result" mode of "CAN GATEWAY" using CONSULT.
3. Check DTC.

Is DTC U1010 detected?

- YES >> Proceed to [LAN-168, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: [GI-43, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000009755498

1. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

1. Turn ignition switch ON.
2. Erase DTC.
3. Perform DTC confirmation procedure again. Refer to [LAN-168, "DTC Description"](#).
4. Check DTC.

Is DTC U1010 displayed?

- YES >> Replace CAN gateway. Refer to [LAN-172, "Removal and Installation"](#).
- NO >> INSPECTION END

B2600 CONFIG ERROR

DTC Description

INFOID:000000009755499

DTC DETECTION LOGIC

DTC	Trouble diagnosis (Trouble diagnosis contents)		Detecting condition
B2600	CONFIG ERROR (Configuration error)	WRONG DATA (Wrong data)	When errors are detected in the configuration data stored in the CAN gateway.
		NOT CONFIGURED (Not configured)	When no data are stored in the CAN gateway.

POSSIBLE CAUSE

CAN gateway

FAIL-SAFE

Transmission and reception of the signal between CAN communication circuit 1 and CAN communication circuit 2 are stopped

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

④ With CONSULT

- Turn ignition switch ON and wait at least 2 seconds or more.
- Select "Self Diagnostic Result" mode of "CAN GATEWAY" using CONSULT.
- Check DTC.

Is DTC B2600 detected?

YES-1 ("CONFIG ERROR WRONG DATA" is detected.)>>Proceed to [LAN-169, "WRONG DATA : Diagnosis Procedure"](#).

YES-2 ("CONFIG ERROR NOT CONFIGURED" is detected.)>>Proceed to [LAN-169, "NOT CONFIGURED : Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: [GI-43, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

WRONG DATA

WRONG DATA : Diagnosis Procedure

INFOID:000000009755500

1. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

- Turn ignition switch ON.
- Erase DTC.
- Perform DTC confirmation procedure again. Refer to [LAN-169, "DTC Description"](#).
- Check DTC.

Is DTC B2600 displayed?

YES >> Replace CAN gateway. Refer to [LAN-172, "Removal and Installation"](#).

NO >> INSPECTION END

NOT CONFIGURED

NOT CONFIGURED : Diagnosis Procedure

INFOID:000000009755501

1. PERFORM CONFIGURATION OF CAN GATEWAY

Perform CAN gateway Configuration. Refer to [LAN-166, "Work Procedure"](#).

>> GO TO 2.

2. PERFORM DTC CONFIRMATION PROCEDURE AGAIN

- Turn ignition switch ON.

B2600 CONFIG ERROR

[CAN GATEWAY]

< DTC/CIRCUIT DIAGNOSIS >

2. Perform DTC confirmation procedure again. Refer to [LAN-169. "DTC Description"](#).
3. Check DTC.

Is DTC B2600 displayed?

- YES >> Replace CAN gateway. Refer to [LAN-172. "Removal and Installation"](#).
NO >> INSPECTION END

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN GATEWAY]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000009755502

1. CHECK FUSE

Check that the following fuse are not blown.

Signal name	Fuse No.
Battery power supply	17
Ignition power supply	14

Is the fuse fusing?

YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the connector of CAN gateway.
3. Check voltage between CAN gateway harness connector and ground.

Terminals		Condition	Voltage (Standard)	Voltage (Reference value)
(+)	(-)			
CAN gateway		Ignition switch		
Connector	Terminal			
M24	3	OFF	6 – 16 V	Battery voltage
	9	ON	4.5 – 16 V	Battery voltage

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between CAN gateway harness connector and ground.

CAN gateway		Ground	Continuity
Connector	Terminal		
M24	5		Existed
	11		

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

REMOVAL AND INSTALLATION

CAN GATEWAY

Removal and Installation

INFOID:000000009755503

NOTE:

Before replacing CAN gateway, perform “Before Replace ECU” of “Read / Write Configuration” to save or print current vehicle specification. Refer to [LAN-165, "Description"](#).

REMOVAL

1. Remove instrument lower panel LH. Refer to [IP-12, "Removal and Installation"](#).
2. Disconnect CAN gateway connector.
3. Remove mounting screw to remove CAN gateway.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

To prevent malfunction, be sure to perform “After Replace ECU” of “Read / Write Configuration” or “Manual Configuration” when replacing CAN gateway. Refer to [LAN-165, "Description"](#).

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009789037

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
 YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.
 NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009789040

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789042

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ECM. Refer to [EC-578. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ECM branch line.

NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789043

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789044

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

4.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789045

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

F2	3	E65	9F	Existed
	8		5F	Existed

A
B
C
D
E
F
G
H
I
J
K
L

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

LAN

N
O
P

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789046

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789047

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
- NO >> Repair the combination meter branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the combination meter branch line.
- NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789048

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

YES >> Replace the main harness.

NO >> Replace parts whose air bag system has a malfunction.

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789049

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the display control unit branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789051

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789052

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
E35	25	15	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B)

NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009798677

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789056

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009790833

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 1)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009789094

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.
NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009789095

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789097

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ECM. Refer to [EC-578. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ECM branch line.

NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789098

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789099

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the IPDM E/R branch line.

NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789100

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

F2	3	E65	9F	Existed
	8		5F	Existed

A
B
C
D
E
F
G
H
I
J
K
L

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

LAN

N
O
P

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789101

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789102

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector		Resistance (Ω)
Connector No.	Terminal No.	
M58	41 42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789103

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

YES >> Replace the main harness.

NO >> Replace parts whose air bag system has a malfunction.

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789104

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the display control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

TCU BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

TCU BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789111

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the TCU for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCU.
2. Check the resistance between the TCU harness connector terminals.

TCU harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M81	9	10	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the TCU branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCU. Refer to [AV-589, "TCU : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the TCU. Refer to [AV-597, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the TCU branch line.
NO >> Repair the power supply and the ground circuit.

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789112

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789113

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity
Connector No.	Terminal No.	
M24	4	Existed
	10	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)
Connector No.	Terminal No.	
E35	25	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B)
- NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009798678

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789124

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009790834

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 2)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009789125

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.

NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009789126

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

LAN

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789128

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-578, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789129

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789130

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789131

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

F2	3	E65	9F	Existed
	8		5F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789132

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789133

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789134

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789138

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the display control unit branch line.
 NO >> Repair the power supply and the ground circuit.

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789139

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789140

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity
Connector No.	Terminal No.	
M24	4	Existed
	10	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)
Connector No.	Terminal No.	
E35	25	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B)
- NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789142

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering force control module
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering force control module.
3. Check the resistance between the steering force control module harness connector terminals.

Steering force control module harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M71	14	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering force control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering force control module. Refer to [STC-427, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering control module branch line.
NO >> Repair the power supply and the ground circuit.

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009798679

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789144

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

DAST 1 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

DAST 1 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789146

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle main control module
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of steering angle main control module.
3. Check the resistance between the steering angle main control module harness connector terminals.

Steering angle main control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E26	14	15	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the steering angle main control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle main control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the steering angle main control module. Refer to [STC-428, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the steering angle main control module branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009790742

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

CHASSIS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009790743

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and/or CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and/or CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on chassis communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the chassis control module harness connector.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	7	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Chassis control module harness connector		Ground	Continuity
Connector No.	Terminal No.		
M22	19		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK CHASSIS CONTROL MODULE TERMINATION CIRCUIT

1. Remove the chassis control module.
2. Check the resistance between the chassis control module terminals.

Chassis control module		Resistance (Ω)
Terminal No.		
19	7	Approx. 108 – 132
11	8	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 6.

NO >> Replace the chassis control module.

6. CHECK SYMPTOM

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 3)]

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 7.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

7.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of chassis communication circuit.

NOTE:

Chassis control module has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009789147

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.

NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009789148

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

LAN

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789151

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-578, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789152

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789153

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789154

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

F2	3	E65	9F	Existed
	8		5F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789155

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789156

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789157

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789158

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the display control unit branch line.
 NO >> Repair the power supply and the ground circuit.

TCU BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

TCU BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789161

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the TCU for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCU.
2. Check the resistance between the TCU harness connector terminals.

TCU harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M81	9	10	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the TCU branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCU. Refer to [AV-589, "TCU : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the TCU. Refer to [AV-597, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the TCU branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789162

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the BCM branch line.
 NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789163

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
E35	25	15	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B)

NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789164

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering force control module
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering force control module.
3. Check the resistance between the steering force control module harness connector terminals.

Steering force control module harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M71	14	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering force control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering force control module. Refer to [STC-427, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering control module branch line.
NO >> Repair the power supply and the ground circuit.

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009798681

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789166

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

DAST 1 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

DAST 1 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789167

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle main control module
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of steering angle main control module.
3. Check the resistance between the steering angle main control module harness connector terminals.

Steering angle main control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E26	14	15	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the steering angle main control module branch line.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle main control module. Refer to [STC-407](#), "[Diagnosis Procedure](#)".

Is the inspection result normal?

YES (Present error)>>Replace the steering angle main control module. Refer to [STC-428](#), "[Removal and Installation](#)".

YES (Past error)>>Error was detected in the steering angle main control module branch line.

NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009789168

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

CHASSIS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009789169

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and/or CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and/or CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on chassis communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the chassis control module harness connector.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	7	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Chassis control module harness connector		Ground	Continuity
Connector No.	Terminal No.		
M22	19		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK CHASSIS CONTROL MODULE TERMINATION CIRCUIT

1. Remove the chassis control module.
2. Check the resistance between the chassis control module terminals.

Chassis control module		Resistance (Ω)
Terminal No.		
19	7	Approx. 108 – 132
11	8	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 6.

NO >> Replace the chassis control module.

6. CHECK SYMPTOM

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 4)]

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 7.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

7.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of chassis communication circuit.

NOTE:

Chassis control module has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009789171

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.

NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009789172

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

Diagnosis Procedure

INFOID:000000009789173

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B39 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Fuse block (J/B) harness connector B39
 - ABS actuator and electric unit (control unit)
2. Check the continuity between the harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Fuse block (J/B) terminals	Continuity
Connector No.	Terminal No.	Terminal No.	
E35	25	6H	Existed
	15	4H	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of driver seat control unit.
2. Check the continuity between the harness connector and the driver seat control unit harness connector.

Fuse block (J/B) harness connector		Driver seat control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B39	6H	B601	1	Existed
	4H		17	Existed

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the driver seat control unit.
NO >> Repair the main line between the harness connector B39 and the driver seat control unit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN ADP AND AVM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

MAIN LINE BETWEEN ADP AND AVM CIRCUIT

Diagnosis Procedure

INFOID:000000009789174

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B37
 - Harness connector B72

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B600 and B12
 - Harness connectors B37 and B72
2. Check the continuity between the harness connector terminals.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B12	1	B37	4	Existed
	17		3	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of around view monitor control unit.
2. Check the continuity between the harness connector and the around view monitor control unit.

Harness connector		Around view monitor control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B72	4	B50	27	Existed
	3		28	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the driver seat control unit and the around view monitor control unit.

NO >> Replace the body harness.

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

Diagnosis Procedure

INFOID:000000009789175

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connectors B62
 - Harness connectors M22

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Harness connectors B62 and M22
2. Check the continuity between the around view monitor control unit harness connector and the harness connector.
 - With around view monitor, without ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	63	Existed
	28		53	Existed

- With ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	18	Existed
	28		17	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M95 and M155.
2. Check the continuity between the harness connectors.
 - With around view monitor, without ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	63	M95	15	Existed
	53		7	Existed

- With ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	18	M95	14	Existed
	17		6	Existed

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the around view monitor control unit and the sonar control unit.

NO >> Repair the main line between the harness connectors M22 and sonar control unit.

MAIN LINE BETWEEN SONAR AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

MAIN LINE BETWEEN SONAR AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000009789176

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - CAN gateway
 - Harness connectors M155 and M95
4. Check the continuity between the harness connector and the data link connector.

Harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M95	15	M25	13	Existed
	7		12	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the sonar control unit and the data link connector.

NO >> Repair the main line between the sonar control unit and data link connector.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT

Diagnosis Procedure

INFOID:000000009797486

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M19
 - Harness connector B18
 - Harness connector M40
 - Harness connector E25

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Steering angle main control module
 - Harness connectors E25 and M40
2. Check the continuity between the harness connectors.

Steering angle main control module harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E26	14	E25	51	Existed
	15		52	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the steering angle main control module and the harness connector E25.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M19 and B18.
2. Check the continuity between the harness connectors M40 and M19.

Side radar LH harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M40	51	M19	74	Existed
	52		75	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connectors M40 and M19.

4.CHECK CONNECTOR

Check the continuity between the harness connector terminals.

Connector No.	Terminal No.		Continuity
B18	74	84	Existed
	75	85	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the main line between the harness connector B18.

MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M75 and R3.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M19	84	M75	32	Existed
	85		31	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the steering angle main control module and the lane camera unit.

NO >> Repair the main line between the harness connectors M19 and the lane camera unit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789179

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ECM. Refer to [EC-578, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ECM branch line.

NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009790745

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 1 side).

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

LAN

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009790746

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector branch line.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	13	12	Approx. 54 – 66

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 2 side).
NO >> Repair the data link connector branch line.

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789182

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the IPDM E/R branch line.
 NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

- YES >> Replace the fuse block (J/B).
 NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789183

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

F2	3	E65	9F	Existed
	8		5F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009789184

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors of CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of CAN gateway.
2. Check the resistance between the CAN gateway harness connector terminals.

CAN gateway harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	1	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 1 side).
- NO >> Repair the power supply and the ground circuit.

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009790748

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - CAN gateway
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 2 side).
- NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the CAN gateway harness connector and the harness connector.

CAN gateway harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	4	M133	13C	Existed
	10		2C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
- NO >> Repair the harness between the CAN gateway harness connector M24 and the harness connector M133.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789186

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789187

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
- NO >> Repair the combination meter branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the combination meter branch line.
- NO >> Repair the power supply and the ground circuit.

LAN

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789188

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the main harness.

2. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

YES >> Replace the main harness.

NO >> Replace parts whose air bag system has a malfunction.

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789189

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the display control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

TCU BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

TCU BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789190

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the TCU for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCU.
2. Check the resistance between the TCU harness connector terminals.

TCU harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M81	9	10	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the TCU branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCU. Refer to [AV-589, "TCU : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the TCU. Refer to [AV-597, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the TCU branch line.
NO >> Repair the power supply and the ground circuit.

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789191

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789192

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity
Connector No.	Terminal No.	
M24	4	Existed
	10	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)
Connector No.	Terminal No.	
E35	25	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B)
- NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

ADP BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789193

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the follow terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit
 - Harness connectors B600 and B12
 - Harness connectors B39 and fuse block (J/B) side connector (Models without around view monitor system)

Is the inspection result normal?

- YES - 1>> Models with around view monitor system: GO TO 2.
YES - 2>> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway. (Models with around view monitor system)
2. Disconnect the connector of driver seat control unit.
3. Check the resistance between the driver seat control unit harness connector terminals.

Driver seat control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B601	1	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO - 1 >> Models without around view monitor system: GO TO 5.
NO - 2 >> Models with around view monitor system: Repair the driver seat control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [ADP-75, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the driver seat control unit. Refer to [ADP-145, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the driver seat control unit branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector B39.
2. Check the continuity between the driver seat control unit harness connector B601 and the harness connector.

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

Driver seat control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B601	1	B39	3H	Existed
	17		8H	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the driver seat control unit harness connector B601 and the harness connector B39.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789194

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering force control module
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering force control module.
3. Check the resistance between the steering force control module harness connector terminals.

Steering force control module harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M71	14	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering force control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering force control module. Refer to [STC-427, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering control module branch line.
NO >> Repair the power supply and the ground circuit.

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009798682

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789196

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

AVM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789197

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Around view monitor control unit
 - CAN gateway (Models without ICC)

Is the inspection result normal?

YES-1 >> Models without ICC: GO TO 2.

YES-2 >> Models with ICC: GO TO 3.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models without ICC).
2. Disconnect the connector of around view monitor control unit.
3. Check the resistance between the around view monitor control unit harness connector terminals.

Around view monitor control unit harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
B50	27	28	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the around view monitor control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the around view monitor control unit. Refer to [AV-435. "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the around view monitor control unit. Refer to [AV-458. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the around view monitor control unit branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

SONAR BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

SONAR BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789198

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Sonar control unit
 - Harness connector M95
 - Harness connector M155
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of sonar control unit.
3. Check the resistance between the sonar control unit harness connector terminals.

Sonar control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M76	5	6	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the sonar control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the sonar control unit. Refer to [AV-435, "SONAR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the sonar control unit. Refer to [AV-462, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the sonar control unit branch line.
NO >> Repair the power supply and the ground circuit.

DAST 1 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

DAST 1 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789199

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle main control module
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of steering angle main control module.
3. Check the resistance between the steering angle main control module harness connector terminals.

Steering angle main control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E26	14	15	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the steering angle main control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle main control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the steering angle main control module. Refer to [STC-428, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the steering angle main control module branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

CAN COMMUNICATION CIRCUIT 1

Diagnosis Procedure

INFOID:000000009790749

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 1.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 1.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

CAN COMMUNICATION CIRCUIT 2

Diagnosis Procedure

INFOID:000000009790750

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 2.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	13	Not existed
	12	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	13		Not existed
	12		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK CAN GATEWAY TERMINATION CIRCUIT

1. Remove the CAN gateway.
2. Check the resistance between the CAN gateway terminals.

CAN gateway		Resistance (Ω)
Terminal No.		
4	10	Approx. 108 – 132
6	12	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the CAN gateway.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 6.
Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 2.

NOTE:

CAN gateway has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

CHASSIS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009789201

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and/or CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and/or CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on chassis communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the chassis control module harness connector.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	7	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Chassis control module harness connector		Ground	Continuity
Connector No.	Terminal No.		
M22	19		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK CHASSIS CONTROL MODULE TERMINATION CIRCUIT

1. Remove the chassis control module.
2. Check the resistance between the chassis control module terminals.

Chassis control module		Resistance (Ω)
Terminal No.		
19	7	Approx. 108 – 132
11	8	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 6.

NO >> Replace the chassis control module.

6. CHECK SYMPTOM

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 5)]

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 7.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

7.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of chassis communication circuit.

NOTE:

Chassis control module has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009789203

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.

NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009789204

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

Diagnosis Procedure

INFOID:000000009789206

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B39 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Fuse block (J/B) harness connector B39
 - ABS actuator and electric unit (control unit)
2. Check the continuity between the harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Fuse block (J/B) terminals	Continuity
Connector No.	Terminal No.	Terminal No.	
E35	25	6H	Existed
	15	4H	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of driver seat control unit.
2. Check the continuity between the harness connector and the driver seat control unit harness connector.

Fuse block (J/B) harness connector		Driver seat control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B39	6H	B601	1	Existed
	4H		17	Existed

Is the inspection result normal?

YES (Present error)>>>Check CAN system type decision again.

YES (Past error)>>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the driver seat control unit.

NO >> Repair the main line between the harness connector B39 and the driver seat control unit.

MAIN LINE BETWEEN ADP AND ICC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

MAIN LINE BETWEEN ADP AND ICC CIRCUIT

Diagnosis Procedure

INFOID:000000009789210

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - CAN gateway
 - Harness connectors B600 and B12
 - ADAS control unit
4. Check the continuity between the harness connector and the ADAS control unit harness connector.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B12	1	B1	1	Existed
	17		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the driver seat control unit and the ADAS control unit.

NO >> Replace the body harness.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT

Diagnosis Procedure

INFOID:000000009789211

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B37
 - Harness connector B72
 - Harness connector B62
 - Harness connector M22

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ADAS control unit
 - Harness connectors B37 and B72
2. Check the continuity between the ADAS control unit harness connector and the harness connector.

ADAS control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	1	B37	4	Existed
	2		3	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B62 and M22.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B72	4	B62	63	Existed
	3		53	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the body harness.

4.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of steering force control module.
2. Check the continuity between the harness connector and the steering force control module.

Harness connector		Steering force control module harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	63	M71	14	Existed
	53		15	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

YES (Past error)>>Error was detected in the main line between the ADAS control unit and the steering force control module.

NO >> Repair the main line between the harness connector M22 and the steering force control module.

A

B

C

D

E

F

G

H

I

J

K

L

N

O

P

LAN

MAIN LINE BETWEEN EPS/DAST 3 AND STRG CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

MAIN LINE BETWEEN EPS/DAST 3 AND STRG CIRCUIT

Diagnosis Procedure

INFOID:0000000097892.12

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following harness connectors.
 - CAN gateway
 - Steering force control module
4. Check the continuity between the steering force control module harness connector and the data link connector.

Steering force control module harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M71	14	M25	13	Existed
	15		12	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the steering force control module and the data link connector.

NO >> Repair the main line between the steering force control module and the data link connector.

MAIN LINE BETWEEN RDR-L AND AVM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

MAIN LINE BETWEEN RDR-L AND AVM CIRCUIT

Diagnosis Procedure

INFOID:000000009789213

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B3
 - Harness connector B52

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B87 and B8
 - Harness connectors B3 and B52
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B87	6	B3	1	Existed
	5		9	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of around view monitor control unit.
2. Check the continuity between the harness connector and the around view monitor control unit harness connector.

Harness connector		Around view monitor control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B52	1	B50	27	Existed
	9		28	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the side radar LH and the around view monitor control unit control unit.

NO >> Replace the body harness.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

Diagnosis Procedure

INFOID:000000009789208

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connectors B62
 - Harness connectors M22

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Harness connectors B62 and M22
2. Check the continuity between the around view monitor control unit harness connector and the harness connector.
 - With around view monitor, without ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	63	Existed
	28		53	Existed

- With ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	18	Existed
	28		17	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M95 and M155.
2. Check the continuity between the harness connectors.
 - With around view monitor, without ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	63	M95	15	Existed
	53		7	Existed

- With ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	18	M95	14	Existed
	17		6	Existed

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the around view monitor control unit and the sonar control unit.

NO >> Repair the main line between the harness connectors M22 and sonar control unit.

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT

Diagnosis Procedure

INFOID:000000009789214

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Chassis control module
 - Harness connectors E25
 - Harness connectors M40
 - Harness connector M19
 - Harness connectors B18
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Steering angle main control module
 - Harness connectors E25 and M40
2. Check the continuity between the steering angle main control module harness connector and harness connector.

Steering angle main control module harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E26	14	E25	51	Existed
	15		52	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the steering angle main control module harness connector and harness connector E25.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M19 and B18.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M40	51	M19	74	Existed
	52		75	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between harness connectors M40 and M19.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the harness connector B18 and ADAS control unit harness connector.

Harness connector		ADAS control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

B18	74	B1	8	Existed
	75		9	Existed

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the steering angle main control module and the ADAS control unit.

NO >> Replace the body harness.

LAN

MAIN LINE BETWEEN ICC AND LANE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

MAIN LINE BETWEEN ICC AND LANE CIRCUIT

Diagnosis Procedure

INFOID:000000009789215

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Chassis control module
 - Harness connector B18
 - Harness connector M19

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ADAS control unit
 - Harness connectors B18 and M19
2. Check the continuity between the harness connector terminals.

ADAS control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	8	B18	84	Existed
	9		85	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M75 and R3.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M19	84	M75	32	Existed
	85		31	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ADAS control unit and the lane camera unit.

NO >> Repair the main line between the harness connectors M19 and lane camera unit.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789216

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-578. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009789220

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 1 side).

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009790751

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector branch line.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	13	12	Approx. 54 – 66

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 2 side).
NO >> Repair the data link connector branch line.

LAN

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789218

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789219

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

F2	3	E65	9F	Existed
	8		5F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009789221

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors of CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of CAN gateway.
2. Check the resistance between the CAN gateway harness connector terminals.

CAN gateway harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	1	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172. "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 1 side).
- NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009790752

1.CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - CAN gateway
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 5.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172. "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 2 side).
- NO >> Repair the power supply and the ground circuit.

5.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the CAN gateway harness connector and the harness connector.

CAN gateway harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	4	M133	13C	Existed
	10		2C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
- NO >> Repair the harness between the CAN gateway harness connector M24 and the harness connector M133.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789222

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789223

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789224

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

AFS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789225

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AFS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AFS control unit.
2. Check the resistance between the AFS control unit harness connector terminals.

AFS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M4	1	13	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the AFS control unit branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AFS control unit. Refer to [EXL-128, "AFS CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AFS control unit. Refer to [EXL-181, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the AFS control unit branch line.
 NO >> Repair the power supply and the ground circuit.

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789226

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the display control unit branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

HBA BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

HBA BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789227

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Auto anti- dazzling inside mirror (High beam assist control module)
 - Harness connector R2
 - Harness connector M74

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of auto anti - dazzling inside mirror (High beam assist control module).
2. Check the resistance between the auto anti - dazzling inside mirror (High beam assist control module) harness connector terminals.

Auto anti - dazzling inside mirror (High beam assist control module) harness connector			Resistance (Ω)
Connector No.	Terminal No.		
R9	12	11	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the anti - dazzling inside mirror (High beam assist control module) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the anti - dazzling inside mirror (High beam assist control module). Refer to [EXL-128. "HIGH BEAM ASSIST CONTROL MODULE : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the inside mirror. Refer to [MIR-45. "Removal and Installation"](#) (With automatic drive positioner system) or [MIR-80. "Removal and Installation"](#) (Without automatic drive positioner system).

YES (Past error)>>Error was detected in the anti - dazzling inside mirror (High beam assist control module) branch line.

NO >> Repair the power supply and the ground circuit.

TCU BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

TCU BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789228

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the TCU for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCU.
2. Check the resistance between the TCU harness connector terminals.

TCU harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M81	9	10	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the TCU branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCU. Refer to [AV-589, "TCU : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the TCU. Refer to [AV-597, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the TCU branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789229

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the BCM branch line.
 NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789230

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
E35	25	15	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B)

NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

ADP BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789231

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the follow terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit
 - Harness connectors B600 and B12
 - Harness connectors B39 and fuse block (J/B) side connector (Models without around view monitor system)

Is the inspection result normal?

- YES - 1 >> Models with around view monitor system: GO TO 2.
 YES - 2 >> Models without around view monitor system: GO TO 3.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway. (Models with around view monitor system)
2. Disconnect the connector of driver seat control unit.
3. Check the resistance between the driver seat control unit harness connector terminals.

Driver seat control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B601	1	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
 NO - 1 >> Models without around view monitor system: GO TO 5.
 NO - 2 >> Models with around view monitor system: Repair the driver seat control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [ADP-75, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error) >> Replace the driver seat control unit. Refer to [ADP-145, "Removal and Installation"](#).
 YES (Past error) >> Error was detected in the driver seat control unit branch line.
 NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector B39.
2. Check the continuity between the driver seat control unit harness connector B601 and the harness connector.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

Driver seat control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B601	1	B39	3H	Existed
	17		8H	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the driver seat control unit harness connector B601 and the harness connector B39.

PSB BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789232

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - CAN gateway
 - Pre-crash seat belt control unit (driver side)

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of pre-crash seat belt control unit (driver side).
3. Check the resistance between the pre-crash seat belt control unit (driver side) harness connector terminals.

Pre-crash seat belt control unit (driver side) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
B19	14	4	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the pre-crash seat belt control unit (driver side) branch line.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the pre-crash seat belt control unit (driver side). Refer to [SBC-62, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the seat belt pre-tensioner retractor (driver side). Refer to [SBC-76, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the pre-crash seat belt control unit (driver side) branch line.
- NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ICC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

ICC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009789233

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - CAN gateway

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of ADAS control unit.
3. Check the resistance between the ADAS control unit harness connector terminals.

ADAS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B1	1	2	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-160, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-161, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ADAS control unit branch line.

NO >> Repair the power supply and the ground circuit.

ICC BRANCH LINE CIRCUIT (CHASSIS COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

ICC BRANCH LINE CIRCUIT (CHASSIS COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009790754

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ADAS control unit.
2. Check the resistance between the ADAS control unit harness connector terminals.

ADAS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B1	8	9	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-160, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-161, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ADAS control unit branch line circuit (chassis communication circuit side).

NO >> Repair the power supply and the ground circuit.

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789235

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering force control module
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering force control module.
3. Check the resistance between the steering force control module harness connector terminals.

Steering force control module harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M71	14	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering force control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering force control module. Refer to [STC-427, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering control module branch line.
NO >> Repair the power supply and the ground circuit.

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009798683

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789237

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

RDR-L BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

RDR-L BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789238

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar LH
 - Harness connector B87
 - Harness connector B8

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of side radar LH.
2. Check the resistance between the side radar LH harness connector terminals.

Side radar LH harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B92	4	3	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar LH. Refer to [DAS-359, "SIDE RADAR LH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar LH. Refer to [DAS-386, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar LH branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

RDR-R BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789239

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar RH
 - Harness connector B87
 - Harness connector B8

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of side radar RH.
2. Check the resistance between the side radar RH harness connector terminals.

Side radar RH harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B93	4	3	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the side radar RH branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar RH. Refer to [DAS-360, "SIDE RADAR RH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar RH. Refer to [DAS-386, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar RH branch line.

NO >> Repair the power supply and the ground circuit.

AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

AVM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789240

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Around view monitor control unit
 - CAN gateway (Models without ICC)

Is the inspection result normal?

YES-1 >> Models without ICC: GO TO 2.

YES-2 >> Models with ICC: GO TO 3.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models without ICC).
2. Disconnect the connector of around view monitor control unit.
3. Check the resistance between the around view monitor control unit harness connector terminals.

Around view monitor control unit harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
B50	27	28	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the around view monitor control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the around view monitor control unit. Refer to [AV-435, "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the around view monitor control unit. Refer to [AV-458, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the around view monitor control unit branch line.

NO >> Repair the power supply and the ground circuit.

APA BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789241

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Accelerator pedal actuator / accelerator pedal position sensor
 - Harness connector M125
 - Harness connector M67

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of accelerator pedal actuator / accelerator pedal position sensor.
2. Check the resistance between the accelerator pedal actuator harness connector terminals.

Accelerator pedal actuator / accelerator pedal position sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M124	3	9	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the accelerator pedal actuator branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the accelerator pedal actuator / accelerator pedal position sensor. Refer to [DAS-359, "ACCELERATOR PEDAL ACTUATOR : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the accelerator pedal assembly. Refer to [ACC-4, "MODELS WITH DISTANCE CONTROL ASSIST SYSTEM : Removal and Installation"](#).
 YES (Past error)>>Error was detected in the accelerator pedal actuator branch line.
 NO >> Repair the power supply and the ground circuit.

BSW/BUZZER BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

BSW/BUZZER BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789242

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the drive assistance buzzer control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of drive assistance buzzer control module.
2. Check the resistance between the drive assistance buzzer control module harness connector terminals.

Drive assistance buzzer control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M56	3	11	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the drive assistance buzzer control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the drive assistance buzzer control module. Refer to [DAS-361, "DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the drive assistance buzzer control module. Refer to [DAS-389, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the drive assistance buzzer control module branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

LASER BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789243

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ICC sensor
 - Harness connector E76
 - Harness connector E14
 - Harness connector E25
 - Harness connector M40

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ICC sensor.
2. Check the resistance between the ICC sensor harness connector terminals.

ICC sensor harness connector		Resistance (Ω)
Connector No.	Terminal No.	
E80	3 6	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the ICC sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ICC sensor. Refer to [CCS-118. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ICC sensor. Refer to [CCS-135. "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the ICC sensor branch line.
 NO >> Repair the power supply and the ground circuit.

SONAR BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

SONAR BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789244

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Sonar control unit
 - Harness connector M95
 - Harness connector M155
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of sonar control unit.
3. Check the resistance between the sonar control unit harness connector terminals.

Sonar control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M76	5	6	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the sonar control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the sonar control unit. Refer to [AV-435, "SONAR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the sonar control unit. Refer to [AV-462, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the sonar control unit branch line.
NO >> Repair the power supply and the ground circuit.

DAST 1 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

DAST 1 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789245

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle main control module
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of steering angle main control module.
3. Check the resistance between the steering angle main control module harness connector terminals.

Steering angle main control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E26	14	15	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the steering angle main control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle main control module. Refer to [STC-407](#), "[Diagnosis Procedure](#)".

Is the inspection result normal?

YES (Present error)>>Replace the steering angle main control module. Refer to [STC-428](#), "[Removal and Installation](#)".

YES (Past error)>>Error was detected in the steering angle main control module branch line.

NO >> Repair the power supply and the ground circuit.

LANE BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

LANE BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789246

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Lane camera unit
 - Harness connector R13
 - Harness connector M75
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of lane camera unit.
3. Check the resistance between the lane camera unit harness connector terminals.

Lane camera unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
R13	4	8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the lane camera unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the lane camera unit. Refer to [DAS-610, "LANE CAMERA UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the lane camera unit. Refer to [DAS-620, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the lane camera unit branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

CAN COMMUNICATION CIRCUIT 1

Diagnosis Procedure

INFOID:000000009790756

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 1.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 1.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

CAN COMMUNICATION CIRCUIT 2

Diagnosis Procedure

INFOID:000000009789247

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 2.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	13	Not existed
	12	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	13		Not existed
	12		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK CAN GATEWAY TERMINATION CIRCUIT

1. Remove the CAN gateway.
2. Check the resistance between the CAN gateway terminals.

CAN gateway		Resistance (Ω)
Terminal No.		
4	10	Approx. 108 – 132
6	12	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the CAN gateway.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 6.
Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 2.

NOTE:

CAN gateway has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

CHASSIS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009789248

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and/or CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and/or CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on chassis communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the chassis control module harness connector.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	7	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Chassis control module harness connector		Ground	Continuity
Connector No.	Terminal No.		
M22	19		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK CHASSIS CONTROL MODULE TERMINATION CIRCUIT

1. Remove the chassis control module.
2. Check the resistance between the chassis control module terminals.

Chassis control module		Resistance (Ω)
Terminal No.		
19	7	Approx. 108 – 132
11	8	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 6.

NO >> Replace the chassis control module.

6. CHECK SYMPTOM

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 7.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

7.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of chassis communication circuit.

NOTE:

Chassis control module has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

ITS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009789249

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1, CAN communication circuit 2 and ITS communication circuit have no malfunction.

Are the CAN communication 1 and CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ADAS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ADAS control unit
 - ICC sensor
2. Check the continuity between the ADAS control unit harness connector and the ICC sensor harness connector.

ADAS control unit harness connector		ICC sensor harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	6	E80	3	Existed
	7		6	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness between the ADAS control unit and the ICC sensor.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

1. Disconnect the following harness connectors.
 - Side radar LH
 - Side radar RH
 - Around view monitor control unit
 - Accelerator pedal actuator / accelerator pedal position sensor
 - Driver assistance buzzer control module
 - Sonar control unit
2. Check the continuity between the ADAS control unit harness connector terminals.

ADAS control unit harness connector			Continuity
Connector No.	Terminal No.		
B1	6	7	Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the ADAS control unit harness connector and the ground.

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 6)]

ADAS control unit harness connector		Ground	Continuity
Connector No.	Terminal No.		
B1	6		
	7		Not existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

6.CHECK TERMINATION CIRCUIT

1. Remove the ADAS control unit and the ICC sensor.
2. Check the resistance between the ADAS control unit terminals.

ADAS control unit		Resistance (Ω)
Terminal No.		
6	7	Approx. 108 – 132

3. Check the resistance between the ICC sensor terminals.

ICC sensor		Resistance (Ω)
Terminal No.		
3	6	Approx. 108 – 132

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace the ADAS control unit and/or the ICC sensor.

7.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 8.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

8.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of ITS communication circuit.

NOTE:

ADAS control unit and ICC sensor have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009789250

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.

NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009789251

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789252

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ECM. Refer to [EC-578, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ECM branch line.

NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789253

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789254

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789255

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

F2	3	E65	9F	Existed
	8		5F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789256

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789257

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789258

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789259

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the display control unit branch line.
 NO >> Repair the power supply and the ground circuit.

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789260

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789261

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
E35	25	15	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B)
- NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789262

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - AWD control unit
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of AWD control unit.
3. Check the resistance between the AWD control unit harness connector terminals.

AWD control unit harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M42	8	16	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the AWD control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-55. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009798767

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789264

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009789265

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 7)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009789266

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.
NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009789267

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789268

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-578. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789269

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789270

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the IPDM E/R branch line.

NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789271

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

F2	3	E65	9F	Existed
	8		5F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789272

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

M&A BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789273

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the combination meter branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789274

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

YES >> Replace the main harness.

NO >> Replace parts whose air bag system has a malfunction.

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789275

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the display control unit branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

TCU BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

TCU BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789276

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the TCU for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCU.
2. Check the resistance between the TCU harness connector terminals.

TCU harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M81	9	10	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the TCU branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCU. Refer to [AV-589, "TCU : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the TCU. Refer to [AV-597, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the TCU branch line.
NO >> Repair the power supply and the ground circuit.

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789277

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789278

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity
Connector No.	Terminal No.	
M24	4	Existed
	10	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)
Connector No.	Terminal No.	
E35	25	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B)
- NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789279

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - AWD control unit
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of AWD control unit.
3. Check the resistance between the AWD control unit harness connector terminals.

AWD control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M42	8	16	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the AWD control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-55. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009798835

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789281

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009789282

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 8)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009789283

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
 YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.
 NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009789284

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789286

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-578. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789287

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789288

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> GO TO 4.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the IPDM E/R branch line.
 NO >> Repair the power supply and the ground circuit.

4.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

- YES >> Replace the fuse block (J/B).
 NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789289

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

F2	3	E65	9F	Existed
	8		5F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789290

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

M&A BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789291

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the combination meter branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789292

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

YES >> Replace the main harness.

NO >> Replace parts whose air bag system has a malfunction.

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789293

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the display control unit.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the display control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

BCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789294

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the BCM branch line.
NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789295

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
E35	25	15	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B)

NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789296

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering force control module
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering force control module.
3. Check the resistance between the steering force control module harness connector terminals.

Steering force control module harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M71	14	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering force control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering force control module. Refer to [STC-427, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering control module branch line.
NO >> Repair the power supply and the ground circuit.

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789297

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - AWD control unit
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of AWD control unit.
3. Check the resistance between the AWD control unit harness connector terminals.

AWD control unit harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M42	8	16	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the AWD control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-55. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009798836

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789299

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

DAST 1 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

DAST 1 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009789300

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle main control module
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of steering angle main control module.
3. Check the resistance between the steering angle main control module harness connector terminals.

Steering angle main control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E26	14	15	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the steering angle main control module branch line.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle main control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the steering angle main control module. Refer to [STC-428, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the steering angle main control module branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009789301

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector			Continuity
Connector No.	Terminal No.		
M25	6	14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

CHASSIS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009789303

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and/or CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and/or CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on chassis communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the chassis control module harness connector.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	7	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Chassis control module harness connector		Ground	Continuity
Connector No.	Terminal No.		
M22	19		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK CHASSIS CONTROL MODULE TERMINATION CIRCUIT

1. Remove the chassis control module.
2. Check the resistance between the chassis control module terminals.

Chassis control module		Resistance (Ω)
Terminal No.		
19	7	Approx. 108 – 132
11	8	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 6.

NO >> Replace the chassis control module.

6. CHECK SYMPTOM

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 9)]

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 7.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

7.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of chassis communication circuit.

NOTE:

Chassis control module has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009790539

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.

NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009790540

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790544

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ECM. Refer to [EC-578, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ECM branch line.

NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

DLC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

DLC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790545

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit.

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790546

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790547

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

F2	3	E65	9F	Existed
	8		5F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790548

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790549

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790550

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790551

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the display control unit branch line.
 NO >> Repair the power supply and the ground circuit.

TCU BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

TCU BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790836

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the TCU for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCU.
2. Check the resistance between the TCU harness connector terminals.

TCU harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M81	9	10	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the TCU branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCU. Refer to [AV-589, "TCU : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the TCU. Refer to [AV-597, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the TCU branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790552

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the BCM branch line.
 NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790553

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
E35	25	15	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B)

NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790554

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering force control module
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering force control module.
3. Check the resistance between the steering force control module harness connector terminals.

Steering force control module harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M71	14	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering force control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering force control module. Refer to [STC-427, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering control module branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790555

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - AWD control unit
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of AWD control unit.
3. Check the resistance between the AWD control unit harness connector terminals.

AWD control unit harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M42	8	16	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the AWD control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-55. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009799537

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790557

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

DAST 1 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

DAST 1 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790558

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle main control module
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of steering angle main control module.
3. Check the resistance between the steering angle main control module harness connector terminals.

Steering angle main control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E26	14	15	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the steering angle main control module branch line.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle main control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the steering angle main control module. Refer to [STC-428, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the steering angle main control module branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

CAN COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009790559

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector			Continuity
Connector No.	Terminal No.		
M25	6	14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

CAN COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication system.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

CHASSIS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009790560

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and/or CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and/or CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on chassis communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the chassis control module harness connector.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	7	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Chassis control module harness connector		Ground	Continuity
Connector No.	Terminal No.		
M22	19		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK CHASSIS CONTROL MODULE TERMINATION CIRCUIT

1. Remove the chassis control module.
2. Check the resistance between the chassis control module terminals.

Chassis control module		Resistance (Ω)
Terminal No.		
19	7	Approx. 108 – 132
11	8	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 6.

NO >> Replace the chassis control module.

6. CHECK SYMPTOM

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 10)]

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 7.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

7.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of chassis communication circuit.

NOTE:

Chassis control module has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009790564

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.

NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009790565

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

Diagnosis Procedure

INFOID:000000009790567

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B39 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Fuse block (J/B) harness connector B39
 - ABS actuator and electric unit (control unit)
2. Check the continuity between the harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Fuse block (J/B) terminals	Continuity
Connector No.	Terminal No.	Terminal No.	
E35	25	6H	Existed
	15	4H	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of driver seat control unit.
2. Check the continuity between the harness connector and the driver seat control unit harness connector.

Fuse block (J/B) harness connector		Driver seat control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B39	6H	B601	1	Existed
	4H		17	Existed

Is the inspection result normal?

YES (Present error)>>>Check CAN system type decision again.

YES (Past error)>>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the driver seat control unit.

NO >> Repair the main line between the harness connector B39 and the driver seat control unit.

MAIN LINE BETWEEN ADP AND AVM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

MAIN LINE BETWEEN ADP AND AVM CIRCUIT

Diagnosis Procedure

INFOID:000000009790568

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B37
 - Harness connector B72

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B600 and B12
 - Harness connectors B37 and B72
2. Check the continuity between the harness connector terminals.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B12	1	B37	4	Existed
	17		3	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of around view monitor control unit.
2. Check the continuity between the harness connector and the around view monitor control unit.

Harness connector		Around view monitor control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B72	4	B50	27	Existed
	3		28	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the driver seat control unit and the around view monitor control unit.

NO >> Replace the body harness.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

Diagnosis Procedure

INFOID:000000009790569

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connectors B62
 - Harness connectors M22

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Harness connectors B62 and M22
2. Check the continuity between the around view monitor control unit harness connector and the harness connector.
 - With around view monitor, without ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	63	Existed
	28		53	Existed

- With ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	18	Existed
	28		17	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M95 and M155.
2. Check the continuity between the harness connectors.
 - With around view monitor, without ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	63	M95	15	Existed
	53		7	Existed

- With ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	18	M95	14	Existed
	17		6	Existed

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the around view monitor control unit and the sonar control unit.

NO >> Repair the main line between the harness connectors M22 and sonar control unit.

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

MAIN LINE BETWEEN SONAR AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

MAIN LINE BETWEEN SONAR AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000009790570

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - CAN gateway
 - Harness connectors M155 and M95
4. Check the continuity between the harness connector and the data link connector.

Harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M95	15	M25	13	Existed
	7		12	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the sonar control unit and the data link connector.

NO >> Repair the main line between the sonar control unit and data link connector.

MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT

Diagnosis Procedure

INFOID:000000009799540

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M19
 - Harness connector B18
 - Harness connector M40
 - Harness connector E25

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Steering angle main control module
 - Harness connectors E25 and M40
2. Check the continuity between the harness connectors.

Steering angle main control module harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E26	14	E25	51	Existed
	15		52	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the steering angle main control module and the harness connector E25.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M19 and B18.
2. Check the continuity between the harness connectors M40 and M19.

Side radar LH harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M40	51	M19	74	Existed
	52		75	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connectors M40 and M19.

4.CHECK CONNECTOR

Check the continuity between the harness connector terminals.

Connector No.	Terminal No.		Continuity
B18	74	84	Existed
	75	85	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the main line between the harness connector B18.

MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M75 and R3.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M19	84	M75	32	Existed
	85		31	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the steering angle main control module and the lane camera unit.

NO >> Repair the main line between the harness connectors M19 and the lane camera unit.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790572

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ECM. Refer to [EC-578. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ECM branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009790760

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 1 side).

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009790690

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector branch line.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	13	12	Approx. 54 – 66

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 2 side).
NO >> Repair the data link connector branch line.

LAN

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790574

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790575

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).
 YES (Past error)>>Error was detected in the TCM branch line.
 NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

F2	3	E65	9F	Existed
	8		5F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009790689

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

YES >> Perform a diagnosis of the indicated DTC.

NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors of CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of CAN gateway.
2. Check the resistance between the CAN gateway harness connector terminals.

CAN gateway harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	1	7	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the CAN gateway branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 1 side).

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009790761

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - CAN gateway
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172. "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 2 side).
- NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the CAN gateway harness connector and the harness connector.

CAN gateway harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	4	M133	13C	Existed
	10		2C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
- NO >> Repair the harness between the CAN gateway harness connector M24 and the harness connector M133.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790679

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790680

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790681

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790682

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the display control unit branch line.
 NO >> Repair the power supply and the ground circuit.

TCU BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

TCU BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790683

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the TCU for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCU.
2. Check the resistance between the TCU harness connector terminals.

TCU harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M81	9	10	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the TCU branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCU. Refer to [AV-589, "TCU : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the TCU. Refer to [AV-597, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the TCU branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790684

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the BCM branch line.
 NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790685

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
E35	25	15	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B)

NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

ADP BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790686

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the follow terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit
 - Harness connectors B600 and B12
 - Harness connectors B39 and fuse block (J/B) side connector (Models without around view monitor system)

Is the inspection result normal?

- YES - 1 >> Models with around view monitor system: GO TO 2.
 YES - 2 >> Models without around view monitor system: GO TO 3.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway. (Models with around view monitor system)
2. Disconnect the connector of driver seat control unit.
3. Check the resistance between the driver seat control unit harness connector terminals.

Driver seat control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B601	1	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
 NO - 1 >> Models without around view monitor system: GO TO 5.
 NO - 2 >> Models with around view monitor system: Repair the driver seat control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [ADP-75, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error) >> Replace the driver seat control unit. Refer to [ADP-145, "Removal and Installation"](#).
 YES (Past error) >> Error was detected in the driver seat control unit branch line.
 NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector B39.
2. Check the continuity between the driver seat control unit harness connector B601 and the harness connector.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

Driver seat control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B601	1	B39	3H	Existed
	17		8H	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the driver seat control unit harness connector B601 and the harness connector B39.

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790687

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering force control module
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering force control module.
3. Check the resistance between the steering force control module harness connector terminals.

Steering force control module harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M71	14	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering force control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering force control module. Refer to [STC-427, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering control module branch line.
NO >> Repair the power supply and the ground circuit.

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790688

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - AWD control unit
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of AWD control unit.
3. Check the resistance between the AWD control unit harness connector terminals.

AWD control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M42	8	16	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the AWD control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-55. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009799879

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790692

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

AVM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790693

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Around view monitor control unit
 - CAN gateway (Models without ICC)

Is the inspection result normal?

YES-1 >> Models without ICC: GO TO 2.

YES-2 >> Models with ICC: GO TO 3.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models without ICC).
2. Disconnect the connector of around view monitor control unit.
3. Check the resistance between the around view monitor control unit harness connector terminals.

Around view monitor control unit harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
B50	27	28	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the around view monitor control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the around view monitor control unit. Refer to [AV-435. "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the around view monitor control unit. Refer to [AV-458. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the around view monitor control unit branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

SONAR BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

SONAR BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790694

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Sonar control unit
 - Harness connector M95
 - Harness connector M155
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of sonar control unit.
3. Check the resistance between the sonar control unit harness connector terminals.

Sonar control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M76	5	6	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the sonar control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the sonar control unit. Refer to [AV-435, "SONAR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the sonar control unit. Refer to [AV-462, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the sonar control unit branch line.
NO >> Repair the power supply and the ground circuit.

DAST 1 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

DAST 1 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790695

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle main control module
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of steering angle main control module.
3. Check the resistance between the steering angle main control module harness connector terminals.

Steering angle main control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E26	14	15	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the steering angle main control module branch line.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle main control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the steering angle main control module. Refer to [STC-428, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the steering angle main control module branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

CAN COMMUNICATION CIRCUIT 1

Diagnosis Procedure

INFOID:000000009790766

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 1.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector			Continuity
Connector No.	Terminal No.		
M25	6	14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 1.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

CAN COMMUNICATION CIRCUIT 2

Diagnosis Procedure

INFOID:000000009790696

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 2.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	13	Not existed
	12	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	13		Not existed
	12		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK CAN GATEWAY TERMINATION CIRCUIT

1. Remove the CAN gateway.
2. Check the resistance between the CAN gateway terminals.

CAN gateway		Resistance (Ω)
Terminal No.		
4	10	Approx. 108 – 132
6	12	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the CAN gateway.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 6.
Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 2.

NOTE:

CAN gateway has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

CHASSIS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009790697

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and/or CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and/or CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on chassis communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the chassis control module harness connector.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	7	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Chassis control module harness connector		Ground	Continuity
Connector No.	Terminal No.		
M22	19		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK CHASSIS CONTROL MODULE TERMINATION CIRCUIT

1. Remove the chassis control module.
2. Check the resistance between the chassis control module terminals.

Chassis control module		Resistance (Ω)
Terminal No.		
19	7	Approx. 108 – 132
11	8	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 6.

NO >> Replace the chassis control module.

6. CHECK SYMPTOM

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 11)]

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 7.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

7.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of chassis communication circuit.

NOTE:

Chassis control module has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009790698

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.

NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009790699

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

Diagnosis Procedure

INFOID:000000009790701

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B39 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Fuse block (J/B) harness connector B39
 - ABS actuator and electric unit (control unit)
2. Check the continuity between the harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Fuse block (J/B) terminals	Continuity
Connector No.	Terminal No.	Terminal No.	
E35	25	6H	Existed
	15	4H	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of driver seat control unit.
2. Check the continuity between the harness connector and the driver seat control unit harness connector.

Fuse block (J/B) harness connector		Driver seat control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B39	6H	B601	1	Existed
	4H		17	Existed

Is the inspection result normal?

YES (Present error)>>>Check CAN system type decision again.

YES (Past error)>>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the driver seat control unit.

NO >> Repair the main line between the harness connector B39 and the driver seat control unit.

MAIN LINE BETWEEN ADP AND ICC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

MAIN LINE BETWEEN ADP AND ICC CIRCUIT

Diagnosis Procedure

INFOID:000000009790705

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - CAN gateway
 - Harness connectors B600 and B12
 - ADAS control unit
4. Check the continuity between the harness connector and the ADAS control unit harness connector.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B12	1	B1	1	Existed
	17		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the driver seat control unit and the ADAS control unit.

NO >> Replace the body harness.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT

Diagnosis Procedure

INFOID:000000009790706

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B37
 - Harness connector B72
 - Harness connector B62
 - Harness connector M22

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ADAS control unit
 - Harness connectors B37 and B72
2. Check the continuity between the ADAS control unit harness connector and the harness connector.

ADAS control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	1	B37	4	Existed
	2		3	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B62 and M22.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B72	4	B62	63	Existed
	3		53	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the body harness.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of steering force control module.
2. Check the continuity between the harness connector and the steering force control module.

Harness connector		Steering force control module harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	63	M71	14	Existed
	53		15	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

YES (Past error)>>Error was detected in the main line between the ADAS control unit and the steering force control module.

NO >> Repair the main line between the harness connector M22 and the steering force control module.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN EPS/DAST 3 AND STRG CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

MAIN LINE BETWEEN EPS/DAST 3 AND STRG CIRCUIT

Diagnosis Procedure

INFOID:000000009790707

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following harness connectors.
 - CAN gateway
 - Steering force control module
4. Check the continuity between the steering force control module harness connector and the data link connector.

Steering force control module harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M71	14	M25	13	Existed
	15		12	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the steering force control module and the data link connector.

NO >> Repair the main line between the steering force control module and the data link connector.

MAIN LINE BETWEEN RDR-L AND AVM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

MAIN LINE BETWEEN RDR-L AND AVM CIRCUIT

Diagnosis Procedure

INFOID:000000009790708

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B3
 - Harness connector B52

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B87 and B8
 - Harness connectors B3 and B52
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B87	6	B3	1	Existed
	5		9	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of around view monitor control unit.
2. Check the continuity between the harness connector and the around view monitor control unit harness connector.

Harness connector		Around view monitor control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B52	1	B50	27	Existed
	9		28	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the side radar LH and the around view monitor control unit control unit.

NO >> Replace the body harness.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

Diagnosis Procedure

INFOID:000000009790703

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connectors B62
 - Harness connectors M22

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Harness connectors B62 and M22
2. Check the continuity between the around view monitor control unit harness connector and the harness connector.
 - With around view monitor, without ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	63	Existed
	28		53	Existed

- With ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	18	Existed
	28		17	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M95 and M155.
2. Check the continuity between the harness connectors.
 - With around view monitor, without ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	63	M95	15	Existed
	53		7	Existed

- With ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	18	M95	14	Existed
	17		6	Existed

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the around view monitor control unit and the sonar control unit.

NO >> Repair the main line between the harness connectors M22 and sonar control unit.

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT

Diagnosis Procedure

INFOID:000000009790709

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Chassis control module
 - Harness connectors E25
 - Harness connectors M40
 - Harness connector M19
 - Harness connectors B18
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Steering angle main control module
 - Harness connectors E25 and M40
2. Check the continuity between the steering angle main control module harness connector and harness connector.

Steering angle main control module harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E26	14	E25	51	Existed
	15		52	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the steering angle main control module harness connector and harness connector E25.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M19 and B18.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M40	51	M19	74	Existed
	52		75	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between harness connectors M40 and M19.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the harness connector B18 and ADAS control unit harness connector.

Harness connector		ADAS control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

B18	74	B1	8	Existed
	75		9	Existed

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the steering angle main control module and the ADAS control unit.

NO >> Replace the body harness.

LAN

MAIN LINE BETWEEN ICC AND LANE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

MAIN LINE BETWEEN ICC AND LANE CIRCUIT

Diagnosis Procedure

INFOID:000000009790710

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Chassis control module
 - Harness connector B18
 - Harness connector M19

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ADAS control unit
 - Harness connectors B18 and M19
2. Check the continuity between the harness connector terminals.

ADAS control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	8	B18	84	Existed
	9		85	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M75 and R3.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M19	84	M75	32	Existed
	85		31	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ADAS control unit and the lane camera unit.

NO >> Repair the main line between the harness connectors M19 and lane camera unit.

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790711

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ECM. Refer to [EC-578. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ECM branch line.

NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009790768

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 1 side).

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009790712

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector branch line.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	13	12	Approx. 54 – 66

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 2 side).
NO >> Repair the data link connector branch line.

LAN

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790713

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790714

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

F2	3	E65	9F	Existed
	8		5F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009790769

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors of CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of CAN gateway.
2. Check the resistance between the CAN gateway harness connector terminals.

CAN gateway harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	1	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172. "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 1 side).
- NO >> Repair the power supply and the ground circuit.

LAN

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009790715

1.CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - CAN gateway
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 5.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172. "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 2 side).
- NO >> Repair the power supply and the ground circuit.

5.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the CAN gateway harness connector and the harness connector.

CAN gateway harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	4	M133	13C	Existed
	10		2C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
- NO >> Repair the harness between the CAN gateway harness connector M24 and the harness connector M133.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790716

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790717

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A-BAG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790718

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2. CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

AFS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790719

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AFS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AFS control unit.
2. Check the resistance between the AFS control unit harness connector terminals.

AFS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M4	1	13	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the AFS control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AFS control unit. Refer to [EXL-128, "AFS CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AFS control unit. Refer to [EXL-181, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the AFS control unit branch line.
 NO >> Repair the power supply and the ground circuit.

AV BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790720

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the display control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

HBA BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790721

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Auto anti- dazzling inside mirror (High beam assist control module)
 - Harness connector R2
 - Harness connector M74

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of auto anti - dazzling inside mirror (High beam assist control module).
2. Check the resistance between the auto anti - dazzling inside mirror (High beam assist control module) harness connector terminals.

Auto anti - dazzling inside mirror (High beam assist control module) harness connector			Resistance (Ω)
Connector No.	Terminal No.		
R9	12	11	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the anti - dazzling inside mirror (High beam assist control module) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the anti - dazzling inside mirror (High beam assist control module). Refer to [EXL-128. "HIGH BEAM ASSIST CONTROL MODULE : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the inside mirror. Refer to [MIR-45. "Removal and Installation"](#) (With automatic drive positioner system) or [MIR-80. "Removal and Installation"](#) (Without automatic drive positioner system).
- YES (Past error)>>Error was detected in the anti - dazzling inside mirror (High beam assist control module) branch line.
- NO >> Repair the power supply and the ground circuit.

TCU BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

TCU BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790722

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the TCU for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of TCU.
2. Check the resistance between the TCU harness connector terminals.

TCU harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M81	9	10	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the TCU branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCU. Refer to [AV-589, "TCU : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the TCU. Refer to [AV-597, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the TCU branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790723

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the BCM branch line.
 NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790724

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
E35	25	15	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B)
- NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

ADP BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790725

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the follow terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit
 - Harness connectors B600 and B12
 - Harness connectors B39 and fuse block (J/B) side connector (Models without around view monitor system)

Is the inspection result normal?

- YES - 1 >> Models with around view monitor system: GO TO 2.
 YES - 2 >> Models without around view monitor system: GO TO 3.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway. (Models with around view monitor system)
2. Disconnect the connector of driver seat control unit.
3. Check the resistance between the driver seat control unit harness connector terminals.

Driver seat control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B601	1	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
 NO - 1 >> Models without around view monitor system: GO TO 5.
 NO - 2 >> Models with around view monitor system: Repair the driver seat control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [ADP-75, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error) >> Replace the driver seat control unit. Refer to [ADP-145, "Removal and Installation"](#).
 YES (Past error) >> Error was detected in the driver seat control unit branch line.
 NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector B39.
2. Check the continuity between the driver seat control unit harness connector B601 and the harness connector.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

Driver seat control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B601	1	B39	3H	Existed
	17		8H	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the driver seat control unit harness connector B601 and the harness connector B39.

PSB BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790726

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - CAN gateway
 - Pre-crash seat belt control unit (driver side)

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of pre-crash seat belt control unit (driver side).
3. Check the resistance between the pre-crash seat belt control unit (driver side) harness connector terminals.

Pre-crash seat belt control unit (driver side) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
B19	14	4	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the pre-crash seat belt control unit (driver side) branch line.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the pre-crash seat belt control unit (driver side). Refer to [SBC-62, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the seat belt pre-tensioner retractor (driver side). Refer to [SBC-76, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the pre-crash seat belt control unit (driver side) branch line.
- NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ICC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

ICC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009790727

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - CAN gateway

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of ADAS control unit.
3. Check the resistance between the ADAS control unit harness connector terminals.

ADAS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B1	1	2	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-160, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-161, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ADAS control unit branch line.

NO >> Repair the power supply and the ground circuit.

ICC BRANCH LINE CIRCUIT (CHASSIS COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

ICC BRANCH LINE CIRCUIT (CHASSIS COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009799544

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ADAS control unit.
2. Check the resistance between the ADAS control unit harness connector terminals.

ADAS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B1	8	9	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-160, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-161, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ADAS control unit branch line circuit (chassis communication circuit side).

NO >> Repair the power supply and the ground circuit.

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790770

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering force control module
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering force control module.
3. Check the resistance between the steering force control module harness connector terminals.

Steering force control module harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M71	14	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering force control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering force control module. Refer to [STC-427, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering control module branch line.
NO >> Repair the power supply and the ground circuit.

4WD BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

4WD BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790771

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - AWD control unit
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of AWD control unit.
3. Check the resistance between the AWD control unit harness connector terminals.

AWD control unit harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M42	8	16	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the AWD control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AWD control unit. Refer to [DLN-46. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AWD control unit. Refer to [DLN-55. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AWD control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009799703

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790728

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

RDR-L BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

RDR-L BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790729

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar LH
 - Harness connector B87
 - Harness connector B8

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of side radar LH.
2. Check the resistance between the side radar LH harness connector terminals.

Side radar LH harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B92	4	3	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar LH. Refer to [DAS-359, "SIDE RADAR LH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar LH. Refer to [DAS-386, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar LH branch line.

NO >> Repair the power supply and the ground circuit.

RDR-R BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

RDR-R BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790730

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar RH
 - Harness connector B87
 - Harness connector B8

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of side radar RH.
2. Check the resistance between the side radar RH harness connector terminals.

Side radar RH harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B93	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the side radar RH branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar RH. Refer to [DAS-360, "SIDE RADAR RH : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the side radar RH. Refer to [DAS-386, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the side radar RH branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

AVM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

AVM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790731

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Around view monitor control unit
 - CAN gateway (Models without ICC)

Is the inspection result normal?

YES-1 >> Models without ICC: GO TO 2.

YES-2 >> Models with ICC: GO TO 3.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models without ICC).
2. Disconnect the connector of around view monitor control unit.
3. Check the resistance between the around view monitor control unit harness connector terminals.

Around view monitor control unit harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
B50	27	28	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the around view monitor control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the around view monitor control unit. Refer to [AV-435. "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the around view monitor control unit. Refer to [AV-458. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the around view monitor control unit branch line.

NO >> Repair the power supply and the ground circuit.

APA BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

APA BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790732

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Accelerator pedal actuator / accelerator pedal position sensor
 - Harness connector M125
 - Harness connector M67

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of accelerator pedal actuator / accelerator pedal position sensor.
2. Check the resistance between the accelerator pedal actuator harness connector terminals.

Accelerator pedal actuator / accelerator pedal position sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M124	3	9	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the accelerator pedal actuator branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the accelerator pedal actuator / accelerator pedal position sensor. Refer to [DAS-359, "ACCELERATOR PEDAL ACTUATOR : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the accelerator pedal assembly. Refer to [ACC-4, "MODELS WITH DISTANCE CONTROL ASSIST SYSTEM : Removal and Installation"](#).

YES (Past error)>>Error was detected in the accelerator pedal actuator branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

BSW/BUZZER BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

BSW/BUZZER BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790733

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the drive assistance buzzer control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of drive assistance buzzer control module.
2. Check the resistance between the drive assistance buzzer control module harness connector terminals.

Drive assistance buzzer control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M56	3	11	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the drive assistance buzzer control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the drive assistance buzzer control module. Refer to [DAS-361, "DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the drive assistance buzzer control module. Refer to [DAS-389, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the drive assistance buzzer control module branch line.
NO >> Repair the power supply and the ground circuit.

LASER BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

LASER BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790734

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ICC sensor
 - Harness connector E76
 - Harness connector E14
 - Harness connector E25
 - Harness connector M40

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ICC sensor.
2. Check the resistance between the ICC sensor harness connector terminals.

ICC sensor harness connector		Resistance (Ω)
Connector No.	Terminal No.	
E80	3	Approx. 108 – 132
	6	

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the ICC sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ICC sensor. Refer to [CCS-118. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ICC sensor. Refer to [CCS-135. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ICC sensor branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

SONAR BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

SONAR BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790735

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Sonar control unit
 - Harness connector M95
 - Harness connector M155
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of sonar control unit.
3. Check the resistance between the sonar control unit harness connector terminals.

Sonar control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M76	5	6	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the sonar control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the sonar control unit. Refer to [AV-435, "SONAR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the sonar control unit. Refer to [AV-462, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the sonar control unit branch line.
NO >> Repair the power supply and the ground circuit.

DAST 1 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

DAST 1 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790736

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle main control module
 - Chassis control module

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of steering angle main control module.
3. Check the resistance between the steering angle main control module harness connector terminals.

Steering angle main control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E26	14	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle main control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle main control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle main control module. Refer to [STC-428, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle main control module branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

LANE BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

LANE BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009790737

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Lane camera unit
 - Harness connector R13
 - Harness connector M75
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of lane camera unit.
3. Check the resistance between the lane camera unit harness connector terminals.

Lane camera unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
R13	4	8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the lane camera unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the lane camera unit. Refer to [DAS-610, "LANE CAMERA UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the lane camera unit. Refer to [DAS-620, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the lane camera unit branch line.

NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

CAN COMMUNICATION CIRCUIT 1

Diagnosis Procedure

INFOID:000000009790762

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 1.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 1.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

CAN COMMUNICATION CIRCUIT 2

Diagnosis Procedure

INFOID:000000009790738

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 2.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	13	Not existed
	12	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	13		Not existed
	12		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK CAN GATEWAY TERMINATION CIRCUIT

1. Remove the CAN gateway.
2. Check the resistance between the CAN gateway terminals.

CAN gateway		Resistance (Ω)
Terminal No.		
4	10	Approx. 108 – 132
6	12	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the CAN gateway.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 6.
Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 2.

NOTE:

CAN gateway has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

CHASSIS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009790739

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and/or CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and/or CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on chassis communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the chassis control module harness connector.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	7	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Chassis control module harness connector		Ground	Continuity
Connector No.	Terminal No.		
M22	19		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK CHASSIS CONTROL MODULE TERMINATION CIRCUIT

1. Remove the chassis control module.
2. Check the resistance between the chassis control module terminals.

Chassis control module		Resistance (Ω)
Terminal No.		
19	7	Approx. 108 – 132
11	8	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 6.

NO >> Replace the chassis control module.

6. CHECK SYMPTOM

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 7.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

7.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of chassis communication circuit.

NOTE:

Chassis control module has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

ITS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009790740

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1, CAN communication circuit 2 and ITS communication circuit have no malfunction.

Are the CAN communication 1 and CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ADAS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ADAS control unit
 - ICC sensor
2. Check the continuity between the ADAS control unit harness connector and the ICC sensor harness connector.

ADAS control unit harness connector		ICC sensor harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	6	E80	3	Existed
	7		6	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness between the ADAS control unit and the ICC sensor.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

1. Disconnect the following harness connectors.
 - Side radar LH
 - Side radar RH
 - Around view monitor control unit
 - Accelerator pedal actuator / accelerator pedal position sensor
 - Driver assistance buzzer control module
 - Sonar control unit
2. Check the continuity between the ADAS control unit harness connector terminals.

ADAS control unit harness connector			Continuity
Connector No.	Terminal No.		
B1	6	7	Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the ADAS control unit harness connector and the ground.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 12)]

ADAS control unit harness connector		Ground	Continuity
Connector No.	Terminal No.		
B1	6		
	7		Not existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

6.CHECK TERMINATION CIRCUIT

1. Remove the ADAS control unit and the ICC sensor.
2. Check the resistance between the ADAS control unit terminals.

ADAS control unit		Resistance (Ω)
Terminal No.		
6	7	Approx. 108 – 132

3. Check the resistance between the ICC sensor terminals.

ICC sensor		Resistance (Ω)
Terminal No.		
3	6	Approx. 108 – 132

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace the ADAS control unit and/or the ICC sensor.

7.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 8.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

8.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of ITS communication circuit.

NOTE:

ADAS control unit and ICC sensor have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009791194

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.

NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009791195

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

Diagnosis Procedure

INFOID:000000009791196

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B39 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Fuse block (J/B) harness connector B39
 - ABS actuator and electric unit (control unit)
2. Check the continuity between the harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Fuse block (J/B) terminals	Continuity
Connector No.	Terminal No.	Terminal No.	
E35	25	6H	Existed
	15	4H	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of driver seat control unit.
2. Check the continuity between the harness connector and the driver seat control unit harness connector.

Fuse block (J/B) harness connector		Driver seat control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B39	6H	B601	1	Existed
	4H		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the driver seat control unit.

NO >> Repair the main line between the harness connector B39 and the driver seat control unit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN ADP AND AVM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

MAIN LINE BETWEEN ADP AND AVM CIRCUIT

Diagnosis Procedure

INFOID:000000009791197

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B37
 - Harness connector B72

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B600 and B12
 - Harness connectors B37 and B72
2. Check the continuity between the harness connector terminals.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B12	1	B37	4	Existed
	17		3	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of around view monitor control unit.
2. Check the continuity between the harness connector and the around view monitor control unit.

Harness connector		Around view monitor control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B72	4	B50	27	Existed
	3		28	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the driver seat control unit and the around view monitor control unit.

NO >> Replace the body harness.

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

Diagnosis Procedure

INFOID:000000009791198

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connectors B62
 - Harness connectors M22

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Harness connectors B62 and M22
2. Check the continuity between the around view monitor control unit harness connector and the harness connector.
 - With around view monitor, without ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	63	Existed
	28		53	Existed

- With ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	18	Existed
	28		17	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M95 and M155.
2. Check the continuity between the harness connectors.
 - With around view monitor, without ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	63	M95	15	Existed
	53		7	Existed

- With ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	18	M95	14	Existed
	17		6	Existed

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the around view monitor control unit and the sonar control unit.

NO >> Repair the main line between the harness connectors M22 and sonar control unit.

MAIN LINE BETWEEN SONAR AND DLC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

MAIN LINE BETWEEN SONAR AND DLC CIRCUIT

Diagnosis Procedure

INFOID:000000009791199

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - CAN gateway
 - Harness connectors M155 and M95
4. Check the continuity between the harness connector and the data link connector.

Harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M95	15	M25	13	Existed
	7		12	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the sonar control unit and the data link connector.

NO >> Repair the main line between the sonar control unit and data link connector.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT

Diagnosis Procedure

INFOID:000000009799761

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M19
 - Harness connector B18
 - Harness connector M40
 - Harness connector E25

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Steering angle main control module
 - Harness connectors E25 and M40
2. Check the continuity between the harness connectors.

Steering angle main control module harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E26	14	E25	51	Existed
	15		52	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the steering angle main control module and the harness connector E25.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M19 and B18.
2. Check the continuity between the harness connectors M40 and M19.

Side radar LH harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M40	51	M19	74	Existed
	52		75	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between the harness connectors M40 and M19.

4.CHECK CONNECTOR

Check the continuity between the harness connector terminals.

Connector No.	Terminal No.		Continuity
B18	74	84	Existed
	75	85	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair the main line between the harness connector B18.

MAIN LINE BETWEEN DAST 1 AND LANE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M75 and R3.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M19	84	M75	32	Existed
	85		31	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the steering angle main control module and the lane camera unit.

NO >> Repair the main line between the harness connectors M19 and the lane camera unit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791201

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ECM. Refer to [EC-578, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ECM branch line.

NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009791202

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 1 side).

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009791203

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector branch line.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	13	12	Approx. 54 – 66

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 2 side).
NO >> Repair the data link connector branch line.

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791204

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the IPDM E/R branch line.

NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791205

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

F2	3	E65	9F	Existed
	8		5F	Existed

A
B
C
D
E
F
G
H
I
J
K
L

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

LAN

N
O
P

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009791206

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors of CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of CAN gateway.
2. Check the resistance between the CAN gateway harness connector terminals.

CAN gateway harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	1	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 1 side).
- NO >> Repair the power supply and the ground circuit.

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009791207

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - CAN gateway
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 2 side).
- NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the CAN gateway harness connector and the harness connector.

CAN gateway harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	4	M133	13C	Existed
	10		2C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
- NO >> Repair the harness between the CAN gateway harness connector M24 and the harness connector M133.

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791208

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791209

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector		Resistance (Ω)
Connector No.	Terminal No.	
M58	41 42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791210

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791212

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the display control unit branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791213

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the BCM branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the BCM branch line.
 NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791214

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
E35	25	15	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B)

NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

ADP BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791215

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the follow terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit
 - Harness connectors B600 and B12
 - Harness connectors B39 and fuse block (J/B) side connector (Models without around view monitor system)

Is the inspection result normal?

- YES - 1 >> Models with around view monitor system: GO TO 2.
 YES - 2 >> Models without around view monitor system: GO TO 3.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway. (Models with around view monitor system)
2. Disconnect the connector of driver seat control unit.
3. Check the resistance between the driver seat control unit harness connector terminals.

Driver seat control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B601	1	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
 NO - 1 >> Models without around view monitor system: GO TO 5.
 NO - 2 >> Models with around view monitor system: Repair the driver seat control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [ADP-75, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error) >> Replace the driver seat control unit. Refer to [ADP-145, "Removal and Installation"](#).
 YES (Past error) >> Error was detected in the driver seat control unit branch line.
 NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector B39.
2. Check the continuity between the driver seat control unit harness connector B601 and the harness connector.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

Driver seat control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B601	1	B39	3H	Existed
	17		8H	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the driver seat control unit harness connector B601 and the harness connector B39.

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791216

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering force control module
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering force control module.
3. Check the resistance between the steering force control module harness connector terminals.

Steering force control module harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M71	14	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering force control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering force control module. Refer to [STC-427, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering control module branch line.
NO >> Repair the power supply and the ground circuit.

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009799837

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791219

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

AVM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791220

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Around view monitor control unit
 - CAN gateway (Models without ICC)

Is the inspection result normal?

- YES-1 >> Models without ICC: GO TO 2.
 YES-2 >> Models with ICC: GO TO 3.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models without ICC).
2. Disconnect the connector of around view monitor control unit.
3. Check the resistance between the around view monitor control unit harness connector terminals.

Around view monitor control unit harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
B50	27	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
 NO >> Repair the around view monitor control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the around view monitor control unit. Refer to [AV-435. "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the around view monitor control unit. Refer to [AV-458. "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the around view monitor control unit branch line.
 NO >> Repair the power supply and the ground circuit.

SONAR BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

SONAR BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791221

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Sonar control unit
 - Harness connector M95
 - Harness connector M155
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of sonar control unit.
3. Check the resistance between the sonar control unit harness connector terminals.

Sonar control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M76	5	6	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the sonar control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the sonar control unit. Refer to [AV-435, "SONAR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the sonar control unit. Refer to [AV-462, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the sonar control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DAST 1 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

DAST 1 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791222

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle main control module
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of steering angle main control module.
3. Check the resistance between the steering angle main control module harness connector terminals.

Steering angle main control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E26	14	15	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the steering angle main control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle main control module. Refer to [STC-407](#), "[Diagnosis Procedure](#)".

Is the inspection result normal?

YES (Present error)>>Replace the steering angle main control module. Refer to [STC-428](#), "[Removal and Installation](#)".

YES (Past error)>>Error was detected in the steering angle main control module branch line.

NO >> Repair the power supply and the ground circuit.

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

CAN COMMUNICATION CIRCUIT 1

Diagnosis Procedure

INFOID:000000009791223

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 1.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	6 14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 1.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

CAN COMMUNICATION CIRCUIT 2

Diagnosis Procedure

INFOID:000000009791224

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 2.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	13	Not existed
	12	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	13		Not existed
	12		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK CAN GATEWAY TERMINATION CIRCUIT

1. Remove the CAN gateway.
2. Check the resistance between the CAN gateway terminals.

CAN gateway		Resistance (Ω)
Terminal No.		
4	10	Approx. 108 – 132
6	12	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the CAN gateway.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

- Reproduced>>GO TO 6.
Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 2.

NOTE:

CAN gateway has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

CHASSIS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009791225

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and/or CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and/or CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on chassis communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the chassis control module harness connector.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	7	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Chassis control module harness connector		Ground	Continuity
Connector No.	Terminal No.		
M22	19		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK CHASSIS CONTROL MODULE TERMINATION CIRCUIT

1. Remove the chassis control module.
2. Check the resistance between the chassis control module terminals.

Chassis control module		Resistance (Ω)
Terminal No.		
19	7	Approx. 108 – 132
11	8	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 6.

NO >> Replace the chassis control module.

6. CHECK SYMPTOM

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 13)]

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 7.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

7.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of chassis communication circuit.

NOTE:

Chassis control module has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

DTC/CIRCUIT DIAGNOSIS

MAIN LINE BETWEEN DLC AND HVAC CIRCUIT

Diagnosis Procedure

INFOID:000000009791226

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M65.
2. Check the continuity between the fuse block (J/B) terminals.

Fuse block (J/B)		Continuity
Terminal No.	Terminal No.	
23C	22C	Existed
5C	4C	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/C auto amp.
2. Check the continuity between the fuse block (J/B) harness connector and the A/C auto amp. harness connector.

Fuse block (J/B) harness connector		A/C auto amp. harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M133	22C	M88	1	Existed
	4C		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the data link connector and the A/C auto amp.

NO >> Repair the main line between the fuse block (J/B) harness connector M133 and the A/C auto amp.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

MAIN LINE BETWEEN HVAC AND AV CIRCUIT

Diagnosis Procedure

INFOID:000000009791227

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM
 - A/C auto amp.
 - Display control unit
4. Check the continuity between the A/C auto amp. harness connector and the display control unit harness connector.

A/C auto amp. harness connector		Display control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M88	1	M100	29	Existed
	21		17	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the A/C auto amp. and the display control unit.

NO >> Repair the main line between the A/C auto amp. and the display control unit.

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

MAIN LINE BETWEEN ABS AND ADP CIRCUIT

Diagnosis Procedure

INFOID:000000009791229

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B39 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Fuse block (J/B) harness connector B39
 - ABS actuator and electric unit (control unit)
2. Check the continuity between the harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Fuse block (J/B) terminals	Continuity
Connector No.	Terminal No.	Terminal No.	
E35	25	6H	Existed
	15	4H	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the fuse block (J/B).

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of driver seat control unit.
2. Check the continuity between the harness connector and the driver seat control unit harness connector.

Fuse block (J/B) harness connector		Driver seat control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B39	6H	B601	1	Existed
	4H		17	Existed

Is the inspection result normal?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the main line between the ABS actuator and electric unit (control unit) and the driver seat control unit.
NO >> Repair the main line between the harness connector B39 and the driver seat control unit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

MAIN LINE BETWEEN ADP AND ICC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

MAIN LINE BETWEEN ADP AND ICC CIRCUIT

Diagnosis Procedure

INFOID:000000009791233

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - CAN gateway
 - Harness connectors B600 and B12
 - ADAS control unit
4. Check the continuity between the harness connector and the ADAS control unit harness connector.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B12	1	B1	1	Existed
	17		2	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the driver seat control unit and the ADAS control unit.

NO >> Replace the body harness.

MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT

Diagnosis Procedure

INFOID:000000009791234

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B37
 - Harness connector B72
 - Harness connector B62
 - Harness connector M22

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ADAS control unit
 - Harness connectors B37 and B72
2. Check the continuity between the ADAS control unit harness connector and the harness connector.

ADAS control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	1	B37	4	Existed
	2		3	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B62 and M22.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B72	4	B62	63	Existed
	3		53	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the body harness.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of steering force control module.
2. Check the continuity between the harness connector and the steering force control module.

Harness connector		Steering force control module harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	63	M71	14	Existed
	53		15	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

MAIN LINE BETWEEN ICC AND EPS/DAST 3 CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

YES (Past error)>>Error was detected in the main line between the ADAS control unit and the steering force control module.

NO >> Repair the main line between the harness connector M22 and the steering force control module.

MAIN LINE BETWEEN EPS/DAST 3 AND STRG CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

MAIN LINE BETWEEN EPS/DAST 3 AND STRG CIRCUIT

Diagnosis Procedure

INFOID:000000009791235

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following harness connectors.
 - CAN gateway
 - Steering force control module
4. Check the continuity between the steering force control module harness connector and the data link connector.

Steering force control module harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M71	14	M25	13	Existed
	15		12	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the steering force control module and the data link connector.

NO >> Repair the main line between the steering force control module and the data link connector.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN RDR-L AND AVM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

MAIN LINE BETWEEN RDR-L AND AVM CIRCUIT

Diagnosis Procedure

INFOID:000000009791236

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B3
 - Harness connector B52

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors B87 and B8
 - Harness connectors B3 and B52
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B87	6	B3	1	Existed
	5		9	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of around view monitor control unit.
2. Check the continuity between the harness connector and the around view monitor control unit harness connector.

Harness connector		Around view monitor control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B52	1	B50	27	Existed
	9		28	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the side radar LH and the around view monitor control unit control unit.

NO >> Replace the body harness.

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

Diagnosis Procedure

INFOID:000000009791231

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connectors B62
 - Harness connectors M22

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Around view monitor control unit
 - Harness connectors B62 and M22
2. Check the continuity between the around view monitor control unit harness connector and the harness connector.
 - With around view monitor, without ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	63	Existed
	28		53	Existed

- With ICC

Around view monitor control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B50	27	B62	18	Existed
	28		17	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M95 and M155.
2. Check the continuity between the harness connectors.
 - With around view monitor, without ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	63	M95	15	Existed
	53		7	Existed

- With ICC

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	18	M95	14	Existed
	17		6	Existed

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

MAIN LINE BETWEEN AVM AND SONAR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the around view monitor control unit and the sonar control unit.

NO >> Repair the main line between the harness connectors M22 and sonar control unit.

MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT

Diagnosis Procedure

INFOID:000000009791237

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Chassis control module
 - Harness connectors E25
 - Harness connectors M40
 - Harness connector M19
 - Harness connectors B18
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Steering angle main control module
 - Harness connectors E25 and M40
2. Check the continuity between the steering angle main control module harness connector and harness connector.

Steering angle main control module harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E26	14	E25	51	Existed
	15		52	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the main line between the steering angle main control module harness connector and harness connector E25.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M19 and B18.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M40	51	M19	74	Existed
	52		75	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the main line between harness connectors M40 and M19.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ADAS control unit.
2. Check the continuity between the harness connector B18 and ADAS control unit harness connector.

Harness connector		ADAS control unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

MAIN LINE BETWEEN DAST 1 AND ICC CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

B18	74	B1	8	Existed
	75		9	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the steering angle main control module and the ADAS control unit.

NO >> Replace the body harness.

MAIN LINE BETWEEN ICC AND LANE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

MAIN LINE BETWEEN ICC AND LANE CIRCUIT

Diagnosis Procedure

INFOID:000000009791238

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Chassis control module
 - Harness connector B18
 - Harness connector M19

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ADAS control unit
 - Harness connectors B18 and M19
2. Check the continuity between the harness connector terminals.

ADAS control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	8	B18	84	Existed
	9		85	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the body harness.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M75 and R3.
2. Check the continuity between the harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M19	84	M75	32	Existed
	85		31	Existed

Is the inspection result normal?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the main line between the ADAS control unit and the lane camera unit.

NO >> Repair the main line between the harness connectors M19 and lane camera unit.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

ECM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

ECM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791239

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M37	114	113	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-188, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ECM. Refer to [EC-578, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ECM branch line.

NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the fuse block (J/B) harness connector M133.
2. Check the continuity between the ECM harness connector and the fuse block (J/B) harness connector.

ECM harness connector		Fuse block (J/B) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M37	114	M133	21C	Existed
	113		3C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the ECM harness connector M37 and the harness connector M133.

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009791241

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Data link connector
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	6	14	Approx. 54 – 66

Is the measurement value within the specification?

YES (Present error)>>Check CAN system type decision again.

YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 1 side).

NO >> GO TO 3.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M25	6	M133	23C	Existed
	14		5C	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the data link connector M25 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

DLC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009791242

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector branch line.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M25	13	12	Approx. 54 – 66

Is the measurement value within the specification?

- YES (Present error)>>Check CAN system type decision again.
YES (Past error)>>Error was detected in the data link connector branch line circuit (CAN communication circuit 2 side).
NO >> Repair the data link connector branch line.

IPDM-E BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

IPDM-E BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791243

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - IPDM E/R
 - Harness connector E64 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E121	29	28	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PCS-36. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the IPDM E/R. Refer to [PCS-37. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the IPDM E/R branch line.
NO >> Repair the power supply and the ground circuit.

4. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the harness connector E64.
2. Check the continuity between the IPDM E/R harness connector and harness connector.

IPDM E/R harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E121	29	E64	6E	Existed
	28		2E	Existed

Is the measurement value within the specification?

- YES >> Replace the fuse block (J/B).
NO >> Repair the harness between the IPDM E/R harness connector E121 and harness connector E64.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

TCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791244

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - A/T assembly
 - Harness connector F12
 - Harness connector E10
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector		Resistance (Ω)
Connector No.	Terminal No.	
F2	3 8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> GO TO 5.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Remove the joint connector. Refer to [TM-218, "Exploded View"](#)
2. Check the continuity between the A/T assembly harness connector side and the TCM harness connector side of the joint connector.

A/T assembly harness connector side	TCM harness connector	Continuity
Terminal No.	Terminal No.	
3	3	Existed
8	8	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the joint connector.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [TM-181, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the control valve & TCM. Refer to [TM-218, "Exploded View"](#).

YES (Past error)>>Error was detected in the TCM branch line.

NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector E65.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TCM BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

F2	3	E65	9F	Existed
	8		5F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the A/T assembly harness connector F2 and the harness connector E65.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 1)

Diagnosis Procedure

INFOID:000000009791245

1. CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors of CAN gateway for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of CAN gateway.
2. Check the resistance between the CAN gateway harness connector terminals.

CAN gateway harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	1	7	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the CAN gateway branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 1 side).
- NO >> Repair the power supply and the ground circuit.

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

CGW BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009791246

1.CHECK DTC

Check DTC of the CAN gateway with CONSULT.

Is U1010 or B2600 indicated?

- YES >> Perform a diagnosis of the indicated DTC.
- NO >> GO TO 2.

2.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - CAN gateway
 - Harness connector M133 and fuse block (J/B) side connector

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair the terminal and connector.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> GO TO 5.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the CAN gateway. Refer to [LAN-171, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the CAN gateway. Refer to [LAN-172, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the CAN gateway branch line (CAN communication circuit 2 side).
- NO >> Repair the power supply and the ground circuit.

5.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector M133.
2. Check the continuity between the CAN gateway harness connector and the harness connector.

CAN gateway harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M24	4	M133	13C	Existed
	10		2C	Existed

Is the inspection result normal?

- YES >> Replace the fuse block (J/B).
- NO >> Repair the harness between the CAN gateway harness connector M24 and the harness connector M133.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

HVAC BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

HVAC BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791247

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/C auto amp. for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/C auto amp.
2. Check the resistance between the A/C auto amp. harness connector terminals.

A/C auto amp. harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M88	1	21	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the A/C auto amp. branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the A/C auto amp. Refer to [HAC-92, "A/C AUTO AMP. : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the A/C auto amp. Refer to [HAC-113, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the A/C auto amp. branch line.
NO >> Repair the power supply and the ground circuit.

M&A BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791248

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M58	41	42	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the combination meter branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [MWI-104, "COMBINATION METER : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the combination meter. Refer to [MWI-126, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the combination meter branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

A-BAG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791249

WARNING:

- Before servicing, turn ignition switch OFF, disconnect battery negative terminal, and wait 3 minutes or more. (To discharge backup capacitor.)
- Never use unspecified tester or other measuring device.

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the air bag diagnosis sensor unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the main harness.

2.CHECK AIR BAG DIAGNOSIS SENSOR UNIT

Check the air bag diagnosis sensor unit. Refer to [SRC-36, "Work Flow"](#).

Is the inspection result normal?

- YES >> Replace the main harness.
NO >> Replace parts whose air bag system has a malfunction.

AFS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

AFS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791250

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the AFS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of AFS control unit.
2. Check the resistance between the AFS control unit harness connector terminals.

AFS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M4	1	13	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the AFS control unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the AFS control unit. Refer to [EXL-128, "AFS CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the AFS control unit. Refer to [EXL-181, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the AFS control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

AV BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791251

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.
2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M100	29	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the display control unit.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-239, "DISPLAY CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the display control unit. Refer to [AV-277, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the display control unit branch line.
 NO >> Repair the power supply and the ground circuit.

HBA BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791252

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Auto anti- dazzling inside mirror (High beam assist control module)
 - Harness connector R2
 - Harness connector M74

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of auto anti - dazzling inside mirror (High beam assist control module).
2. Check the resistance between the auto anti - dazzling inside mirror (High beam assist control module) harness connector terminals.

Auto anti - dazzling inside mirror (High beam assist control module) harness connector		Resistance (Ω)
Connector No.	Terminal No.	
R9	12 11	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the anti - dazzling inside mirror (High beam assist control module) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the anti - dazzling inside mirror (High beam assist control module). Refer to [EXL-128. "HIGH BEAM ASSIST CONTROL MODULE : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the inside mirror. Refer to [MIR-45. "Removal and Installation"](#) (With automatic drive positioner system) or [MIR-80. "Removal and Installation"](#) (Without automatic drive positioner system).
 YES (Past error)>>Error was detected in the anti - dazzling inside mirror (High beam assist control module) branch line.
 NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

BCM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791253

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M14	60	59	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the BCM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the BCM. Refer to [BCS-98, "Removal and Installation"](#).
 YES (Past error)>>Error was detected in the BCM branch line.
 NO >> Repair the power supply and the ground circuit.

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

ABS BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791254

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ABS actuator and electric unit (control unit)
 - Harness connector E65 and fuse block (J/B) side connector

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of ABS actuator and electric unit (control unit).
3. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
E35	25	15	Approx. 54 - 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> GO TO 5.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-154, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-178, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the ABS actuator and electric unit (control unit) branch line.
NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of harness connector E65.
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.
 - With around view monitor system

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ABS BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	6F	Existed
	15		7F	Existed

- Without around view monitor system

ABS actuator and electric unit (control unit) harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E35	25	E65	8F	Existed
	15		3F	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B)

NO >> Repair the harness between the ABS actuator and electric unit (control unit) harness connector E35 and the harness connector E65

ADP BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791255

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the follow terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit
 - Harness connectors B600 and B12
 - Harness connectors B39 and fuse block (J/B) side connector (Models without around view monitor system)

Is the inspection result normal?

- YES - 1 >> Models with around view monitor system: GO TO 2.
 YES - 2 >> Models without around view monitor system: GO TO 3.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway. (Models with around view monitor system)
2. Disconnect the connector of driver seat control unit.
3. Check the resistance between the driver seat control unit harness connector terminals.

Driver seat control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B601	1	17	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
 NO - 1 >> Models without around view monitor system: GO TO 5.
 NO - 2 >> Models with around view monitor system: Repair the driver seat control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [ADP-75, "DRIVER SEAT CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error) >> Replace the driver seat control unit. Refer to [ADP-145, "Removal and Installation"](#).
 YES (Past error) >> Error was detected in the driver seat control unit branch line.
 NO >> Repair the power supply and the ground circuit.

5. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connector B39.
2. Check the continuity between the driver seat control unit harness connector B601 and the harness connector.

A
B
C
D
E
F
G
H
I
J
K
L
LAN
N
O
P

ADP BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

Driver seat control unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B601	1	B39	3H	Existed
	17		8H	Existed

Is the inspection result normal?

YES >> Replace the fuse block (J/B).

NO >> Repair the harness between the driver seat control unit harness connector B601 and the harness connector B39.

PSB BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791256

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - CAN gateway
 - Pre-crash seat belt control unit (driver side)

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of pre-crash seat belt control unit (driver side).
3. Check the resistance between the pre-crash seat belt control unit (driver side) harness connector terminals.

Pre-crash seat belt control unit (driver side) harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
B19	14	4	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
- NO >> Repair the pre-crash seat belt control unit (driver side) branch line.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the pre-crash seat belt control unit (driver side). Refer to [SBC-62, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the seat belt pre-tensioner retractor (driver side). Refer to [SBC-76, "Removal and Installation"](#).
- YES (Past error)>>Error was detected in the pre-crash seat belt control unit (driver side) branch line.
- NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

ICC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

ICC BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT 2)

Diagnosis Procedure

INFOID:000000009791257

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - CAN gateway

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway.
2. Disconnect the connector of ADAS control unit.
3. Check the resistance between the ADAS control unit harness connector terminals.

ADAS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B1	1	2	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-160, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-161, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ADAS control unit branch line.

NO >> Repair the power supply and the ground circuit.

ICC BRANCH LINE CIRCUIT (CHASSIS COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

ICC BRANCH LINE CIRCUIT (CHASSIS COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009791258

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ADAS control unit
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ADAS control unit.
2. Check the resistance between the ADAS control unit harness connector terminals.

ADAS control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B1	8	9	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Replace the body harness.

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ADAS control unit. Refer to [DAS-160, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ADAS control unit. Refer to [DAS-161, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ADAS control unit branch line circuit (chassis communication circuit side).

NO >> Repair the power supply and the ground circuit.

EPS/DAST 3 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

EPS/DAST 3 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791259

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering force control module
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace (if shield line is open) the root cause (CAN communication circuit 2 side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering force control module.
3. Check the resistance between the steering force control module harness connector terminals.

Steering force control module harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M71	14	15	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Replace the body harness.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering force control module. Refer to [STC-407, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering force control module. Refer to [STC-427, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering control module branch line.
NO >> Repair the power supply and the ground circuit.

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

CCM BRANCH LINE CIRCUIT (CAN COMMUNICATION CIRCUIT)

Diagnosis Procedure

INFOID:000000009799878

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Chassis control module
 - Harness connectors E47
 - Harness connectors M39
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of chassis control module.
3. Check the resistance between the chassis control module harness connector terminals.

Chassis control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E22	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the chassis control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the chassis control module. Refer to [DAS-541, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the chassis control module. Refer to [DAS-542, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the chassis control module branch line.
NO >> Repair the power supply and the ground circuit.

STRG BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

STRG BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791261

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle sensor
 - CAN gateway (Models with around view monitor system)

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity	
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit).

3.CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of steering angle sensor.
3. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector		Resistance (Ω)	
Connector No.	Terminal No.		
M77	5	2	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the steering angle sensor branch line

4.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-123. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the steering angle sensor. Refer to [BRC-180. "Removal and Installation"](#).
YES (Past error)>>Error was detected in the steering angle sensor branch line.
NO >> Repair the power supply and the ground circuit.

RDR-L BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

RDR-L BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791262

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar LH
 - Harness connector B87
 - Harness connector B8

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of side radar LH.
2. Check the resistance between the side radar LH harness connector terminals.

Side radar LH harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B92	4	3	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Replace the body harness.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar LH. Refer to [DAS-359, "SIDE RADAR LH : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the side radar LH. Refer to [DAS-386, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the side radar LH branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

RDR-R BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

RDR-R BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791263

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Side radar RH
 - Harness connector B87
 - Harness connector B8

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of side radar RH.
2. Check the resistance between the side radar RH harness connector terminals.

Side radar RH harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B93	4	3	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the side radar RH branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the side radar RH. Refer to [DAS-360, "SIDE RADAR RH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the side radar RH. Refer to [DAS-386, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the side radar RH branch line.

NO >> Repair the power supply and the ground circuit.

AVM BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791264

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Around view monitor control unit
 - CAN gateway (Models without ICC)

Is the inspection result normal?

YES-1 >> Models without ICC: GO TO 2.

YES-2 >> Models with ICC: GO TO 3.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector		Continuity
Connector No.	Terminal No.	
M24	4	6
	10	12
		Existed
		Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models without ICC).
2. Disconnect the connector of around view monitor control unit.
3. Check the resistance between the around view monitor control unit harness connector terminals.

Around view monitor control unit harness connector		Resistance (Ω)
Connector No.	Terminal No.	
B50	27	28
	28	
		Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the around view monitor control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the around view monitor control unit. Refer to [AV-435. "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the around view monitor control unit. Refer to [AV-458. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the around view monitor control unit branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

APA BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791265

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Accelerator pedal actuator / accelerator pedal position sensor
 - Harness connector M125
 - Harness connector M67

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of accelerator pedal actuator / accelerator pedal position sensor.
2. Check the resistance between the accelerator pedal actuator harness connector terminals.

Accelerator pedal actuator / accelerator pedal position sensor harness connector		Resistance (Ω)
Connector No.	Terminal No.	
M124	3 9	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
 NO >> Repair the accelerator pedal actuator branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the accelerator pedal actuator / accelerator pedal position sensor. Refer to [DAS-359, "ACCELERATOR PEDAL ACTUATOR : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the accelerator pedal assembly. Refer to [ACC-4, "MODELS WITH DISTANCE CONTROL ASSIST SYSTEM : Removal and Installation"](#).
 YES (Past error)>>Error was detected in the accelerator pedal actuator branch line.
 NO >> Repair the power supply and the ground circuit.

BSW/BUZZER BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

BSW/BUZZER BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791266

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the drive assistance buzzer control module for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of drive assistance buzzer control module.
2. Check the resistance between the drive assistance buzzer control module harness connector terminals.

Drive assistance buzzer control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M56	3	11	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 3.
NO >> Repair the drive assistance buzzer control module branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the drive assistance buzzer control module. Refer to [DAS-361, "DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the drive assistance buzzer control module. Refer to [DAS-389, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the drive assistance buzzer control module branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

LASER BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

LASER BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791267

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ICC sensor
 - Harness connector E76
 - Harness connector E14
 - Harness connector E25
 - Harness connector M40

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ICC sensor.
2. Check the resistance between the ICC sensor harness connector terminals.

ICC sensor harness connector		Resistance (Ω)
Connector No.	Terminal No.	
E80	3	Approx. 108 – 132
	6	

Is the measurement value within the specification?

YES >> GO TO 3.

NO >> Repair the ICC sensor branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ICC sensor. Refer to [CCS-118. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the ICC sensor. Refer to [CCS-135. "Removal and Installation"](#).

YES (Past error)>>Error was detected in the ICC sensor branch line.

NO >> Repair the power supply and the ground circuit.

SONAR BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

SONAR BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791268

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Sonar control unit
 - Harness connector M95
 - Harness connector M155
 - CAN gateway

Is the inspection result normal?

- YES-1 >> Models with around view monitor system: GO TO 2.
YES-2 >> Models without around view monitor system: GO TO 3.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of CAN gateway.
2. Check the continuity between the CAN gateway harness connector terminals.

CAN gateway harness connector			Continuity
Connector No.	Terminal No.		
M24	4	6	Existed
	10	12	Existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair the root cause (CAN communication circuit 2).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of CAN gateway (Models with around view monitor system).
2. Disconnect the connector of sonar control unit.
3. Check the resistance between the sonar control unit harness connector terminals.

Sonar control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M76	5	6	Approx. 54 – 66

Is the measurement value within the specification?

- YES >> GO TO 4.
NO >> Repair the sonar control unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the sonar control unit. Refer to [AV-435, "SONAR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES (Present error)>>Replace the sonar control unit. Refer to [AV-462, "Removal and Installation"](#).
YES (Past error)>>Error was detected in the sonar control unit branch line.
NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

DAST 1 BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

DAST 1 BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791269

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Steering angle main control module
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of steering angle main control module.
3. Check the resistance between the steering angle main control module harness connector terminals.

Steering angle main control module harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E26	14	15	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the steering angle main control module branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle main control module. Refer to [STC-407](#), "[Diagnosis Procedure](#)".

Is the inspection result normal?

YES (Present error)>>Replace the steering angle main control module. Refer to [STC-428](#), "[Removal and Installation](#)".

YES (Past error)>>Error was detected in the steering angle main control module branch line.

NO >> Repair the power supply and the ground circuit.

LANE BRANCH LINE CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

LANE BRANCH LINE CIRCUIT

Diagnosis Procedure

INFOID:000000009791270

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Lane camera unit
 - Harness connector R13
 - Harness connector M75
 - Chassis control module

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of chassis control module.
2. Check the continuity between the chassis control module harness connector terminals.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	11	Existed
	7	8	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check the harness and repair or replace (if shield line is open) the root cause (chassis communication circuit side).

3. CHECK HARNESS FOR OPEN CIRCUIT

1. Connect the connector of chassis control module.
2. Disconnect the connector of lane camera unit.
3. Check the resistance between the lane camera unit harness connector terminals.

Lane camera unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
R13	4	8	Approx. 54 – 66

Is the measurement value within the specification?

YES >> GO TO 4.

NO >> Repair the lane camera unit branch line.

4. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the lane camera unit. Refer to [DAS-610, "LANE CAMERA UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES (Present error)>>Replace the lane camera unit. Refer to [DAS-620, "Removal and Installation"](#).

YES (Past error)>>Error was detected in the lane camera unit branch line.

NO >> Repair the power supply and the ground circuit.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

CAN COMMUNICATION CIRCUIT 1

Diagnosis Procedure

INFOID:000000009791271

1.CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 1.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector			Continuity
Connector No.	Terminal No.		
M25	6	14	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3.CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	6		Not existed
	14		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4.CHECK ECM AND BCM TERMINATION CIRCUIT

1. Remove the ECM and the BCM.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
114	113	Approx. 108 – 132

3. Check the resistance between the BCM terminals.

BCM		Resistance (Ω)
Terminal No.		
60	59	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the ECM and/or the BCM.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

CAN COMMUNICATION CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 1.

NOTE:

ECM and BCM have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

CAN COMMUNICATION CIRCUIT 2

Diagnosis Procedure

INFOID:000000009791272

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication circuit 2.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector		Continuity
Connector No.	Terminal No.	
M25	13	Not existed
	12	

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M25	13		Not existed
	12		Not existed

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK CAN GATEWAY TERMINATION CIRCUIT

1. Remove the CAN gateway.
2. Check the resistance between the CAN gateway terminals.

CAN gateway		Resistance (Ω)
Terminal No.		
4	10	Approx. 108 – 132
6	12	Approx. 108 – 132

Is the measurement value within the specification?

- YES >> GO TO 5.
NO >> Replace the CAN gateway.

5. CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

Inspection result

- Reproduced >> GO TO 6.
Non-reproduced >> Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

CAN COMMUNICATION CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

6. CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of CAN communication circuit 2.

NOTE:

CAN gateway has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the "Symptom (Results from interview with customer)" are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A

B

C

D

E

F

G

H

I

J

K

L

LAN

N

O

P

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

CHASSIS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009791273

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1 and/or CAN communication circuit 2 have no malfunction.

Are the CAN communication 1 and/or CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and/or CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on chassis communication circuit.
4. Check terminals and connectors for damage, bend and loose connection.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the chassis control module harness connector.

Chassis control module harness connector			Continuity
Connector No.	Terminal No.		
E22	19	7	Not existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Chassis control module harness connector		Ground	Continuity
Connector No.	Terminal No.		
M22	19		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK CHASSIS CONTROL MODULE TERMINATION CIRCUIT

1. Remove the chassis control module.
2. Check the resistance between the chassis control module terminals.

Chassis control module		Resistance (Ω)
Terminal No.		
19	7	Approx. 108 – 132
11	8	Approx. 108 – 132

Is the measurement value within the specification?

YES >> GO TO 6.

NO >> Replace the chassis control module.

6. CHECK SYMPTOM

CHASSIS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 7.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

7.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of chassis communication circuit.

NOTE:

Chassis control module has two termination circuits. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L

LAN

N
O
P

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

ITS COMMUNICATION CIRCUIT

Diagnosis Procedure

INFOID:000000009791274

1. CHECK CAN DIAGNOSIS

Check the CAN diagnosis results from CONSULT to see that the CAN communication circuit 1, CAN communication circuit 2 and ITS communication circuit have no malfunction.

Are the CAN communication 1 and CAN communication 2 circuits normal?

YES >> GO TO 2.

NO >> Check and repair CAN communication circuit 1 and CAN communication circuit 2.

2. CONNECTOR INSPECTION

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ADAS control unit for damage, bend and loose connection (unit side and connector side).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the terminal and connector.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - ADAS control unit
 - ICC sensor
2. Check the continuity between the ADAS control unit harness connector and the ICC sensor harness connector.

ADAS control unit harness connector		ICC sensor harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B1	6	E80	3	Existed
	7		6	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harness between the ADAS control unit and the ICC sensor.

4. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

1. Disconnect the following harness connectors.
 - Side radar LH
 - Side radar RH
 - Around view monitor control unit
 - Accelerator pedal actuator / accelerator pedal position sensor
 - Driver assistance buzzer control module
 - Sonar control unit
2. Check the continuity between the ADAS control unit harness connector terminals.

ADAS control unit harness connector			Continuity
Connector No.	Terminal No.		
B1	6	7	Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

5. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the ADAS control unit harness connector and the ground.

ITS COMMUNICATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CAN SYSTEM (TYPE 14)]

ADAS control unit harness connector		Ground	Continuity
Connector No.	Terminal No.		
B1	6		Not existed
	7		Not existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Check the harness and repair or replace [if shield line or fuse block (J/B) is short] the root cause.

6.CHECK TERMINATION CIRCUIT

1. Remove the ADAS control unit and the ICC sensor.
2. Check the resistance between the ADAS control unit terminals.

ADAS control unit		Resistance (Ω)
Terminal No.		
6	7	Approx. 108 – 132

3. Check the resistance between the ICC sensor terminals.

ICC sensor		Resistance (Ω)
Terminal No.		
3	6	Approx. 108 – 132

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace the ADAS control unit and/or the ICC sensor.

7.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 8.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

8.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect one of the unit connectors of ITS communication circuit.

NOTE:

ADAS control unit and ICC sensor have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace the unit whose connector was disconnected.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

LAN