

SECTION **BCS**

BODY CONTROL SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L

CONTENTS

PRECAUTION	COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)
3	17
PRECAUTIONS	DOOR LOCK
3	18
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	DOOR LOCK : CONSULT Function (BCM - DOOR LOCK)
3	18
Precautions for Removing Battery Terminal	REAR WINDOW DEFOGGER
3	19
SYSTEM DESCRIPTION	REAR WINDOW DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)
5	20
COMPONENT PARTS	BUZZER
5	20
BODY CONTROL SYSTEM	BUZZER : CONSULT Function (BCM - BUZZER)
5	20
BODY CONTROL SYSTEM : Component Parts Location	INT LAMP
5	21
POWER CONSUMPTION CONTROL SYSTEM	INT LAMP : CONSULT Function (BCM - INT LAMP)
5	21
POWER CONSUMPTION CONTROL SYSTEM : Component Parts Location	HEADLAMP
6	22
SYSTEM	HEADLAMP : CONSULT Function (BCM - HEAD LAMP)
7	22
BODY CONTROL SYSTEM	WIPER
7	24
BODY CONTROL SYSTEM : System Description	WIPER : CONSULT Function (BCM - WIPER)
7	24
BODY CONTROL SYSTEM : Fail-safe	FLASHER
8	26
COMBINATION SWITCH READING SYSTEM	FLASHER : CONSULT Function (BCM - FLASHER)
8	26
COMBINATION SWITCH READING SYSTEM : System Description	INTELLIGENT KEY
9	26
SIGNAL BUFFER SYSTEM	INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)
12	26
SIGNAL BUFFER SYSTEM : System Description ...	COMB SW
12	30
POWER CONSUMPTION CONTROL SYSTEM	COMB SW : CONSULT Function (BCM - COMB SW)
13	30
POWER CONSUMPTION CONTROL SYSTEM : System Description	BCM
13	31
SHIPPING MODE CONTROL SYSTEM	BCM : CONSULT Function (BCM - BCM)
15	31
SHIPPING MODE CONTROL SYSTEM : System Description	IMMU
15	31
DIAGNOSIS SYSTEM (BCM)	IMMU : CONSULT Function (BCM - IMMU)
17	31
COMMON ITEM	BATTERY SAVER
17	32

BCS

N
O
P

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)	32	U1000 CAN COMM	86
		DTC Description	86
		Diagnosis Procedure	86
TRUNK	33	U1010 CONTROL UNIT (CAN)	87
TRUNK : CONSULT Function (BCM - TRUNK)	33	DTC Description	87
		Diagnosis Procedure	87
THEFT ALM	33	U0415 VEHICLE SPEED	88
THEFT ALM : CONSULT Function (BCM - THEFT)	33	DTC Description	88
		Diagnosis Procedure	88
RETAINED PWR	34	B2562 LOW VOLTAGE	89
RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)	34	DTC Description	89
		Diagnosis Procedure	89
SIGNAL BUFFER	35	B259A ROOM LAMP FUSE	90
SIGNAL BUFFER : CONSULT Function (BCM - SIGNAL BUFFER)	35	DTC Description	90
		Diagnosis Procedure	90
ECU DIAGNOSIS INFORMATION	36	POWER SUPPLY AND GROUND CIRCUIT	92
		Diagnosis Procedure	92
BCM	36	COMBINATION SWITCH OUTPUT CIRCUIT ...	93
Reference Value	36	Diagnosis Procedure	93
Fail-safe	61	COMBINATION SWITCH INPUT CIRCUIT	95
DTC Inspection Priority Chart	62	Diagnosis Procedure	95
DTC Index	63	SYMPTOM DIAGNOSIS	97
WIRING DIAGRAM	65	COMBINATION SWITCH SYSTEM SYMPTOMS	97
		Symptom Table	97
BCM	65	NORMAL OPERATING CONDITION	98
Wiring Diagram	65	Description	98
BASIC INSPECTION	81	REMOVAL AND INSTALLATION	99
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT	81	BCM	99
Description	81	Removal and Installation	99
Work Procedure	81	COMBINATION SWITCH	100
		Removal and Installation	100
CONFIGURATION (BCM)	83		
Description	83		
Work Procedure	83		
Configuration list	84		
SHIPPING MODE CANCEL OPERATION	85		
Work Procedure	85		
DTC/CIRCUIT DIAGNOSIS	86		

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000013503491

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery or batteries, and wait at least 3 minutes before performing any service.


Precautions for Removing Battery Terminal

INFOID:000000013503493

When disconnecting the battery terminal, pay attention to the following.

- Always use a 12V battery as power source.
- Never disconnect battery terminal while engine is running.
- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
- For vehicles with the engine listed below, remove the battery terminal after a lapse of the specified time:

BR08DE	: 4 minutes	V9X engine	: 4 minutes
D4D engine	: 20 minutes	YD25DDTi	: 2 minutes
HR09DET	: 12 minutes	YS23DDT	: 4 minutes
HRA2DDT	: 12 minutes	YS23DDTT	: 4 minutes
K9K engine	: 4 minutes	ZD30DDTi	: 60 seconds
M9R engine	: 4 minutes	ZD30DDTT	: 60 seconds
R9M engine	: 4 minutes		



SEF289H

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- After high-load driving, if the vehicle is equipped with the V9X engine, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery terminal.

NOTE:

A
B
C
D
E
F
G
H
I
J
K
L
BCS
N
O
P

PRECAUTIONS

< PRECAUTION >

- Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.
- Example of high-load driving
 - Driving for 30 minutes or more at 140 km/h (86 MPH) or more.
 - Driving for 30 minutes or more on a steep slope.
- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

COMPONENT PARTS

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

COMPONENT PARTS

BODY CONTROL SYSTEM

BODY CONTROL SYSTEM : Component Parts Location

INFOID:000000012792437



① BCM

A Behind of dash side finisher RH

POWER CONSUMPTION CONTROL SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


BCS

COMPONENT PARTS

< SYSTEM DESCRIPTION >

POWER CONSUMPTION CONTROL SYSTEM : Component Parts Location

INFOID:000000012792438



JMMIA2256ZZ

- | | | |
|---|---|---|
| ① Steering force control module
Refer to STC-113, "Component Parts Location" . | ② IPDM E/R
Refer to PCS-5, "Component Parts Location" . | ③ BCM
Refer to BCS-5, "BODY CONTROL SYSTEM : Component Parts Location" . |
| ④ TCU
Refer to AV-699, "Component Parts Location" . | ⑤ CAN gateway
Refer to LAN-282, "Component Parts Location" . | ⑥ Combination meter |
| ⑦ Driver seat control unit
Refer to ADP-7, "Component Parts Location" . | ⑧ Pre-crash seat belt control unit (driver side)
Refer to SBC-5, "PRE-CRASH SEAT BELT SYSTEM : Component Parts Location" . | |

SYSTEM

< SYSTEM DESCRIPTION >

SYSTEM

BODY CONTROL SYSTEM

BODY CONTROL SYSTEM : System Description

INFOID:000000012792439

OUTLINE

- BCM (Body Control Module) controls the various electrical components. It inputs the information required to the control from CAN communication and the signal received from each switch and sensor.
- BCM has combination switch reading function for reading the operation status of combination switches (light, turn signal, wiper and washer) in addition to a function for controlling the operation of various electrical components. It also has the signal transmission function as the passed point of signal and the power saving control function that reduces the power consumption with the ignition switch OFF.
- BCM is equipped with the diagnosis function that performs the diagnosis with CONSULT and various settings.

BCM CONTROL FUNCTION LIST

System	Reference
Combination switch reading system	BCS-9, "COMBINATION SWITCH READING SYSTEM : System Description"
Signal buffer system	BCS-12, "SIGNAL BUFFER SYSTEM : System Description"
Power consumption control system	BCS-13, "POWER CONSUMPTION CONTROL SYSTEM : System Description"
Shipping mode control system	BCS-15, "SHIPPING MODE CONTROL SYSTEM : System Description"
Headlamp system	EXL-18, "HEADLAMP SYSTEM : System Description"
Auto light system	EXL-20, "AUTO LIGHT SYSTEM : System Description"
High beam assist system	EXL-23, "HIGH BEAM ASSIST SYSTEM : System Description"
Daytime running light system	EXL-27, "DAYTIME RUNNING LIGHT SYSTEM : System Description"
Turn signal and hazard warning lamp system	EXL-34, "TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description"
Parking, license plate side marker and tail lamps system	EXL-35, "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description"
Front fog lamp system	EXL-43, "FRONT FOG LAMP SYSTEM : System Description"
Exterior lamp battery saver system	EXL-45, "EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description"
Interior room lamp control system	INL-8, "INTERIOR ROOM LAMP CONTROL SYSTEM : System Description"
Interior room lamp battery saver system	INL-12, "INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description"
Illumination control system	INL-14, "ILLUMINATION CONTROL SYSTEM : System Description"
Front wiper and washer system	<ul style="list-style-type: none"> • WW-9, "FRONT WIPER AND WASHER SYSTEM (WITH RAIN SENSOR) : System Description" (With rain sensor) • WW-14, "FRONT WIPER AND WASHER SYSTEM (WITHOUT RAIN SENSOR) : System Description" (Without rain sensor)
Rear window defogger system	DEF-7, "System Description"
Warning chime system	WCS-7, "WARNING CHIME SYSTEM : System Description"
Power door lock system	DLK-16, "System Description"
Intelligent Key system	DLK-19, "INTELLIGENT KEY SYSTEM : System Description"
Trunk lid opener system	DLK-46, "System Description"

SYSTEM

< SYSTEM DESCRIPTION >

System	Reference	
Intelligent Key system/Engine start function	SEC-10, "INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description"	
Infiniti Vehicle Immobilizer System-NATS	SEC-19, "INFINITI VEHICLE IMMOBILIZER SYSTEM-NATS : System Description"	
Vehicle security system	Theft warning alarm	SEC-27, "VEHICLE SECURITY SYSTEM : System Description"
	Panic alarm	
Power window system	PWC-10, "System Description"	
TPMS (Tire Pressure Monitoring System)	WT-11, "System Description"	

BODY CONTROL SYSTEM : Fail-safe

INFOID:000000013502995

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

Display contents of CONSULT	Fail-safe
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking
B2195: ANTI-SCANNING	Inhibit engine cranking
B2198: NATS ANTENNA AMP	Inhibit engine cranking
B219B: ID DISCORD SVT-BCM	Inhibit engine cranking
B2608: STARTER RELAY	Inhibit engine cranking
B260F: ENG STATE SIG LOST	Inhibit engine cranking
B261B: RES ENG RUN STUCK MALFNC	Fuel cut
B26F1: IGN RELAY OFF	Inhibit engine cranking
B26F2: IGN RELAY ON	Inhibit engine cranking
B26F3: START CONT RLY ON	Inhibit engine cranking
B26F4: START CONT RLY OFF	Inhibit engine cranking
B26F7: BCM	Inhibit engine cranking by Intelligent Key system
B26FE: HOOD SW CAN DIAG ERROR	Inhibit remote engine start

FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

BCM detects the rain sensor serial link error and the rain sensor malfunction.

BCM controls the following fail-safe when rain sensor has a malfunction.

- Front wiper switch AUTO and sensing rain drop: The condition just before the activation of fail-safe is maintained until the front wiper switch is turned OFF.
- Front wiper switch AUTO and not sensing rain drop: Front wiper is LO operation until the front wiper switch is turned off.

FAIL-SAFE CONTROL OF COMBINATION SWITCH READING FUNCTION CAUSED BY LOW POWER SUPPLY VOLTAGE

If voltage of battery power supply lower, BCM maintains combination switch reading to the status when input voltage is less than approximately 9 V.

NOTE:

When voltage of battery power supply is approximately 9 V or more, combination switch reading function returns to normal operation.

COMBINATION SWITCH READING SYSTEM


SYSTEM

< SYSTEM DESCRIPTION >

COMBINATION SWITCH READING SYSTEM : System Description

INFOID:000000012792441

SYSTEM DIAGRAM




NOTE:

- *: If so equipped.
- TAIL LAMP switch links lighting switch 1ST and 2ND positions.

OUTLINE

- BCM reads the status of the combination switch (light, turn signal, wiper and washer) and recognizes the status of each switch.
- BCM has a combination of 5 output terminals (OUTPUT 1 - 5) and 5 input terminals (INPUT 1 - 5). It reads a maximum of 20 switch status.

COMBINATION SWITCH MATRIX



NOTE:

- *: If so equipped.
- TAIL LAMP switch links lighting switch 1ST and 2ND positions.

Combination switch INPUT-OUTPUT system list

System	OUTPUT 1	OUTPUT 2	OUTPUT 3	OUTPUT 4	OUTPUT 5
INPUT 1	—	FR WASHER	FR WIPER LOW	TURN LH	TURN RH
INPUT 2	FR WIPER HI	—	FR WIPER INT/AU-TO*	PASSING	HEADLAMP 1

SYSTEM

< SYSTEM DESCRIPTION >

System	OUTPUT 1	OUTPUT 2	OUTPUT 3	OUTPUT 4	OUTPUT 5
INPUT 3	WIP VOLUME 1	RR WASHER*	—	HEADLAMP 2	HI BEAM
INPUT 4	RR WIPER INT*	WIP VOLUME 3	AUTO LIGHT*	—	TAIL LAMP
INPUT 5	WIP VOLUME 2	RR WIPER ON*	RR FOG*	FR FOG*	—


NOTE:

- *: If so equipped.
- Headlamp has a dual system switch.

COMBINATION SWITCH READING FUNCTION

Description


- BCM reads the status of the combination switch at 10 ms interval normally.



NOTE:

BCM reads the status of the combination switch at 60 ms interval when BCM is controlled at low power consumption control mode.

- BCM operates as follows and judges the status of the combination switch.
- It operates the transistor on OUTPUT side in the following order: OUTPUT 5 → 4 → 3 → 2 → 1, and outputs voltage waveform.
- The voltage waveform of OUTPUT corresponding to the formed circuit is input into the interface on INPUT side if any (1 or more) switches are ON.
- It reads this change of the voltage as the status signal of the combination switch.



Operation Example


In the following operation example, the combination of the status signals of the combination switch is replaced as follows: INPUT 1 - 5 to "1 - 5" and OUTPUT 1 - 5 to "A - E".

SYSTEM

< SYSTEM DESCRIPTION >

Example 1: When a switch (TURN RH switch) is turned ON

- The circuit between OUTPUT 4 and INPUT 5 is formed when the TAIL LAMP switch is turned ON.




NOTE:

- *: If so equipped.
- TAIL LAMP switch links lighting switch 1ST and 2ND positions.
- BCM detects the combination switch status signal "1E" when the signal of OUTPUT 5 is input to INPUT 1.
- BCM judges that the TURN RH switch is ON when the signal "1E" is detected.

Example 2: When some switches (TURN RH switch, FR WIPER LOW switch) are turned ON

- The circuits between OUTPUT 5 and INPUT 1 and between OUTPUT 3 and INPUT 1 are formed when the TURN RH switch and FR WIPER LOW switch are turned ON.



NOTE:

- *: If so equipped.
- TAIL LAMP switch links lighting switch 1ST and 2ND positions.
- BCM detects the combination switch status signal "1CE" when the signals of OUTPUT 3 and OUTPUT 5 are input to INPUT 1.
- BCM judges that the TURN RH switch and FR WIPER LOW switch are ON when the signal "1CE" is detected.

WIPER VOLUME DIAL POSITION

BCM judges the INT VOLUME 1 - 7 by the status of WIP VOLUME 1, 2 and 3 switches.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

SYSTEM

< SYSTEM DESCRIPTION >

CONSULT data monitor		Switch status		
Monitor item	Value/Status	WIP VOLUME 1	WIP VOLUME 2	WIP VOLUME 3
INT VOLUME	1	ON	ON	ON
	2	ON	ON	OFF
	3	ON	OFF	OFF
	4	OFF	OFF	OFF
	5	OFF	OFF	ON
	6	OFF	ON	ON
	7	OFF	ON	OFF

NOTE:


For details of wiper volume dial position, refer to [WW-9, "FRONT WIPER AND WASHER SYSTEM \(WITH RAIN SENSOR\) : System Description"](#) (with rain sensor) or [WW-14, "FRONT WIPER AND WASHER SYSTEM \(WITHOUT RAIN SENSOR\) : System Description"](#) (without rain sensor).

SIGNAL BUFFER SYSTEM

SIGNAL BUFFER SYSTEM : System Description

INFOID:000000012792442

SYSTEM DIAGRAM



OUTLINE

BCM has the signal transmission function that outputs/transmits each input/received signal to each unit.

Signal transmission function list

SYSTEM

< SYSTEM DESCRIPTION >


Signal name	Input	Output	Description
Oil pressure switch signal	IPDM E/R (CAN)	<ul style="list-style-type: none"> Combination meter (CAN) TCU (CAN) 	Transmits the received oil pressure switch signal via CAN communication.
Door switch signal	Any door switch	<ul style="list-style-type: none"> Combination meter (CAN) Driver seat control unit (CAN) IPDM E/R (CAN) Pre-crash seat belt control unit (CAN) Around view monitor control unit (CAN) 	Inputs the door switch signal and transmits it via CAN communication.
Trunk switch signal	Trunk room lamp switch	Combination meter (CAN)	Inputs the trunk room lamp switch signal and transmits trunk switch signal via CAN communication.
<ul style="list-style-type: none"> Ignition switch ON signal Ignition switch signal 	Push-button ignition switch (Push switch)	<ul style="list-style-type: none"> Driver seat control unit (CAN) IPDM E/R (CAN) Pre-crash seat belt control unit (CAN) 	Inputs the push-button ignition switch (push switch) signal and transmits the ignition switch status judged with BCM via CAN communication.
Interlock/PNP switch signal	TCM	IPDM E/R (CAN)	Inputs the P/N position signal via CAN communication.
Stop lamp switch signal	Stop lamp switch	TCM (CAN)	Inputs the stop lamp switch 1 signal and stop lamp switch 2 signal, and transmits it via CAN communication.

POWER CONSUMPTION CONTROL SYSTEM

POWER CONSUMPTION CONTROL SYSTEM : System Description

INFOID:0000000012792443

SYSTEM DIAGRAM



OUTLINE

SYSTEM

< SYSTEM DESCRIPTION >

- BCM incorporates a power saving control function that reduces the power consumption according to the vehicle status.
- BCM switches the status (control mode) by itself with the power saving control function. It performs the sleep request to each unit (IPDM E/R, combination meter, TCU, driver seat control unit, pre-crash seat belt control unit, CAN gateway and steering force control module) that operates with the ignition switch OFF.

Normal mode (wake-up)

- CAN communication is normally performed with other units
- Each control with BCM is operating properly

CAN communication sleep mode (CAN sleep)

- CAN transmission is stopped
- Control with BCM only is operating

Low power consumption mode (BCM sleep)

- Low power consumption control is active
- CAN transmission is stopped

LOW POWER CONSUMPTION CONTROL WITH BCM

BCM reduces the power consumption with the following operation in the low power consumption mode.

- The reading interval of the each switches changes from 10 ms interval to 60 ms interval.

Sleep mode activation

- BCM receives the sleep-ready signal (ready) from IPDM E/R and TCU via CAN communication.
- BCM transmits the sleep wake up signal (sleep) to each unit when all of the CAN sleep conditions are fulfilled.
- Each unit stops the transmission of CAN communication with the sleep wake up signal. BCM is in CAN communication sleep mode.
- BCM is in the low power consumption mode and perform the low power consumption control when all of the BCM sleep conditions are fulfilled with CAN sleep condition.

Sleep condition

CAN sleep condition	BCM sleep condition
<ul style="list-style-type: none"> • Receiving the sleep-ready signal (ready) from all units • 1 minute after turning Ignition switch OFF • Warning chime: Not operation • Intelligent Key warning buzzer: Not operation • Stop lamp switch: OFF • Turn signal indicator lamp: Not operation • Exterior lamp: OFF • Door lock status: No change • CONSULT communication status: Not communication • Meter display signal: Non-transmission • Door switch status: No change 	<ul style="list-style-type: none"> • Interior room lamp battery saver: Time out* • Infiniti Vehicle Immobilizer System (IVIS) - NATS: Not operation • Remote keyless entry receiver communication status: No communication • RAP system: OFF

NOTE:

*: Refer to [INL-12. "INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description"](#) for details of the interior room lamp battery saver time.

Wake-up operation

- BCM transmits sleep wake up signal (wake up) to each unit when any condition listed below is established, and then goes into normal mode from low power consumption mode.
- Each unit starts transmissions with CAN communication by receiving sleep wake up signals. Each unit transmit wake up signals to BCM with CAN communication to convey the start of CAN communication.

SYSTEM

< SYSTEM DESCRIPTION >

Wake-up condition


BCM wake-up condition	CAN wake-up condition
<ul style="list-style-type: none"> Door key cylinder switch: NEUTRAL → LOCK, NEUTRAL → UNLOCK Door lock and unlock switch: NEUTRAL → LOCK, NEUTRAL → UNLOCK Extended storage fuse switch: OFF → ON, ON → OFF Trunk lid opener cancel switch: OFF → ON, ON → OFF Front door lock assembly (driver side) (unlock sensor): OFF → ON, ON → OFF One touch unlock sensor (driver door) signal: Receiving One touch unlock sensor (passenger door) signal: Receiving Power window or sunroof communication: Receiving 	<ul style="list-style-type: none"> Receiving the sleep-ready signal (Not-ready) from any units Push-button ignition switch (push switch): OFF → ON Hazard switch: OFF → ON HI BEAM switch: OFF → ON, ON → OFF PASSING switch: OFF → ON, ON → OFF HEADLAMP 1 switch: OFF → ON, ON → OFF HEADLAMP 2 switch: OFF → ON, ON → OFF TAIL LAMP switch: OFF → ON FR FOG switch: OFF → ON, ON → OFF Driver door switch: OFF → ON, ON → OFF Passenger door switch: OFF → ON, ON → OFF Rear RH door switch: OFF → ON, ON → OFF Rear LH door switch: OFF → ON, ON → OFF Trunk room lamp switch: OFF → ON, ON → OFF Driver door request switch: OFF → ON Passenger door request switch: OFF → ON Trunk lid opener switch: OFF → ON Trunk lid opener request switch: OFF → ON Stop lamp switch: ON Remote keyless entry receiver communication: Receiving

SHIPPING MODE CONTROL SYSTEM

SHIPPING MODE CONTROL SYSTEM : System Description

INFOID:000000012792444

SYSTEM DIAGRAM



DESCRIPTION

- BCM switches the status (shipping mode or normal mode) by itself according to the extended storage fuse switch condition, and transmits shipping mode status signal to combination meter and each unit via CAN communication.
- When shipping mode function operates, each control unit does not detect DTCs.
- BCM control functions are limited in shipping mode. Refer to [BCS-98, "Description"](#).
- The combination meter displays extended storage fuse warning message* on the information display, and turns the turn signal indicator lamp (LH/RH) ON, when BCM is in shipping mode.

SYSTEM

< SYSTEM DESCRIPTION >

*: When shipping mode function operates, "SHIPPING MODE ON PUSH STORAGE FUSE" is displayed.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000012792445

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

x: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	x	x	x
Rear window defogger	REAR DEFOGGER	x	x	x
Warning chime	BUZZER		x	x
Interior room lamp timer	INT LAMP	x	x	x
Exterior lamp	HEAD LAMP	x	x	x
Wiper and washer	WIPER	x	x	x
Turn signal and hazard warning lamps	FLASHER	x	x	x
—	AIR CONDITONER*		x	x
<ul style="list-style-type: none"> Intelligent Key system Engine start system 	INTELLIGENT KEY	x	x	x
Combination switch	COMB SW		x	
Body control system	BCM	x		
IVIS - NATS	IMMU	x	x	x
Interior room lamp battery saver	BATTERY SAVER	x	x	x
Trunk lid open	TRUNK		x	
Vehicle security system	THEFT ALM	x	x	x
RAP system	RETAINED PWR		x	
Signal buffer system	SIGNAL BUFFER		x	x
—	AIR PRESSURE MONITOR*			x

*: This item is not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected*	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*)
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" *to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"*
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK"*.) to low power consumption mode
	LOCK		Power supply position is "LOCK" (Ignition switch OFF)*
	OFF		Power supply position is "OFF" (Ignition switch OFF)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)
CRANKING	Power supply position is "CRANKING" (At engine cranking)		
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. 	

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

DOOR LOCK

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK)

INFOID:000000013502495

BCM CONSULT FUNCTION

CONSULT performs the following functions via CAN communication with BCM.

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item	Description
DOOR LOCK-UNLOCK SET	Selective unlock function mode can be changed to operation with this mode <ul style="list-style-type: none"> On: Operate Off: Non-operation
AUTO UNLOCK TYPE	Automatic door lock/unlock function (unlock operation) mode can be selected from the following in this mode <ul style="list-style-type: none"> MODE1: All doors are unlocked MODE2: Only driver door is unlocked
AUTO LOCK FUNCTION	Automatic door lock/unlock function (lock operation) mode can be selected from the following in the mode <ul style="list-style-type: none"> MODE1: All doors are locked when vehicle speed more than 24 km/h (15 MPH) MODE2: All doors are locked when shifting the selector lever from P position to other than the P position MODE3: Non-operation Off: Non-operation
AUTO UNLOCK FUNCTION	Automatic door lock/unlock function (unlock operation) mode can be selected from the following in this mode <ul style="list-style-type: none"> MODE1: All doors are unlocked when the power supply position is changed from ON to OFF MODE2: All doors are unlocked when shifting the selector lever from any position other than the P to P position MODE3: Non-operation Off: Non-operation
SIGNATURE LIGHT SETTING	Signature light function can be changed to operation with this mode <ul style="list-style-type: none"> On: Operate Off: Non-operation

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Contents
REQ SW -DR	Indicated [On/Off] condition of door request switch (driver side)
REQ SW -AS	Indicated [On/Off] condition of door request switch (passenger side)
REQ SW -BD/TR	Indicated [On/Off] condition of trunk lid opener request switch
DOOR SW-DR	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK	NOTE: This item is displayed, but cannot be monitored
CDL LOCK SW	Indicated [On/Off] condition of lock signal from door lock and unlock switch
CDL UNLOCK SW	Indicated [On/Off] condition of unlock signal from door lock and unlock switch
KEY CYL LK-SW	Indicated [On/Off] condition of lock signal from door key cylinder switch
KEY CYL UN-SW	Indicated [On/Off] condition of unlock signal from door key cylinder switch
SHOCK SENSOR	NOTE: This item is displayed, but cannot be monitored

ACTIVE TEST

Test item	Description
DOOR LOCK	This test is able to check door lock/unlock operation <ul style="list-style-type: none"> ALL LOCK: The all door lock actuators are locked. ALL UNLK: The all door lock actuators are unlocked.

REAR WINDOW DEFOGGER

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

REAR WINDOW DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)

INFOID:0000000013502985

WORK SUPPORT

Service item	Setting item	Description
SET R-DEF TIMER	MODE1*	NOTE: Do not use this function.
	MODE2	
	MODE3	

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Description
PUSH SW	Indicates [On/Off] condition of push switch
REAR DEF SW	Displays "Press (On)/other (Off)" status determined with the rear window defogger switch

ACTIVE TEST

Test Item	Description
REAR DEFOGGER	Rear window defogger operates when "On" on CONSULT screen is touched

BUZZER

BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:0000000013502509

CONSULT APPLICATION ITEMS

Test item	Diagnosis mode	Description
BUZZER	Self Diagnostic Result	Displays the diagnosis results judged by BCM.
	Data Monitor	Displays BCM input data in real time.
	Active Test	Operation of electrical loads can be checked by sending driving signal to them.
	Ecu Identification	The BCM part number is displayed.

SELF DIAG RESULT

Refer to [BCS-63, "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Display item [Unit]	Description
PUSH SW [On/Off]	Status of push-button ignition switch judged by BCM.
UNLK SEN-DR [On/Off]	Status of unlock sensor judged by BCM.
VEH SPEED 1 [km/h]	Value of vehicle speed signal received from combination meter with CAN communication line.
TAIL LAMP SW [On/Off]	Status of lighting switch judged by BCM using the combination switch readout function.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Display item [Unit]	Description
FR FOG SW [On/Off]	Status of front fog lamp switch judged by BCM using the combination switch readout function.
DOOR SW-DR [On/Off]	Status of driver side door switch judged by BCM.
CDL LOCK SW [On/Off]	Status of door lock unlock switch judged by BCM.

ACTIVE TEST

Display item [Unit]	Description
SEAT BELT WARN TEST	The seat belt warning chime operation can be checked by operating the relevant function (On/Off).
LIGHT WARN ALM	The light warning chime operation can be checked by operating the relevant function (On/Off).
REVERSE WARNING	This item is displayed, but cannot be monitored.

NOTE:

Some items are not available according to vehicle specification.

INT LAMP

INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:000000013502506

WORK SUPPORT

Service item	Setting item	Setting
SCENARIO LIGHTING SETTING	On	NOTE: Do not use this function since interior room lamp control is changed.
	Off*	
SET I/L D-UNLCK INTCON	On	Without interior room lamp timer function
	Off*	With interior room lamp timer function
FOG LAMP OVERRIDE	On	With front fog override function
	Off*	Without front fog override function

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW -DR [On/Off]	Indicated [On/Off] condition of door request switch (driver side)
REQ SW -AS [On/Off]	Indicated [On/Off] condition of door request switch (passenger side)
REQ SW -RR [On/Off]	NOTE: This item is displayed, but cannot be monitored
REQ SW -RL [On/Off]	NOTE: This item is displayed, but cannot be monitored
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
UNLK SEN -DR [On/Off]	Indicates [On/Off] condition of driver door UNLOCK status
DOOR SW-DR [On/Off]	Indicated [On/Off] condition of front door switch (driver side)

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
DOOR SW-AS [On/Off]	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR [On/Off]	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL [On/Off]	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK [On/Off]	NOTE: This item is displayed, but cannot be monitored
CDL LOCK SW [On/Off]	Indicated [On/Off] condition of lock signal from door lock and unlock switch
CDL UNLOCK SW [On/Off]	Indicated [On/Off] condition of unlock signal from door lock and unlock switch
KEY CYL LK-SW [On/Off]	Indicated [On/Off] condition of lock signal from door key cylinder switch
KEY CYL UN-SW [On/Off]	Indicated [On/Off] condition of unlock signal from door key cylinder switch
TRNK/HAT MNTR [On/Off]	Indicates [On/Off] condition of trunk room lamp switch
RKE-LOCK [On/Off]	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK [On/Off]	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key

ACTIVE TEST

Test item	Operation	Description
INT LAMP	On	Outputs interior room lamp control signal.
	Off	Stops interior room lamp control signal.
STEP LAMP TEST	On	Outputs step lamp control signal.
	Off	Stops step lamp control signal.

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)

INFOID:000000013502504

WORK SUPPORT

Service item	Setting item	Setting
CUSTOM A/LIGHT SETTING	MODE 1*	Normal
	MODE 2	More sensitive setting than normal setting. (Turns ON earlier than normal operation.)
	MODE 3	More sensitive setting than MODE 2. (Turns ON earlier than MODE 2.)
	MODE 4	Less sensitive setting than normal setting. (Turns ON later than normal operation.)

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Service item	Setting item	Setting
ILL DELAY SET	MODE 1*	45 sec.
	MODE 2	Without delay timer function
	MODE 3	30 sec.
	MODE 4	60 sec.
	MODE 5	90 sec.
	MODE 6	120 sec.
	MODE 7	150 sec.
	MODE 8	180 sec.
TWILIGHT On	MODE 1	Without twilight function
	MODE 2*	With twilight ON function
WIPER LINK	MODE 1	Without wiper link function
	MODE 2	With wiper LO and HI
	MODE 3*	With wiper INT, LO and HI
	MODE 4	NOTE: This item is displayed, but cannot be used.

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description	
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch	
ENGINE STATE [STOP/STALL/CRANK/RUN]	Indicates [STOP/STALL/CRANK/RUN] condition of engine states	
VEH SPEED 1 [km/h]	Indicates [km/h] condition of vehicle speed signal from combination meter	
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function.	
TURN SIGNAL L [On/Off]		
TAIL LAMP SW [On/Off]		
HI BEAM SW [On/Off]		
HEAD LAMP SW1 [On/Off]		
HEAD LAMP SW2 [On/Off]		
PASSING SW [On/Off]		
AUTO LIGHT SW [On/Off]		
FR FOG SW [On/Off]		
RR FOG SW [On/Off]		
		NOTE: This item is displayed, but cannot be monitored.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
DOOR SW-DR [On/Off]	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS [On/Off]	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR [On/Off]	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL [On/Off]	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK [On/Off]	NOTE: This item is displayed, but cannot be monitored.
OPTI SEN (DTCT) [V]	The value of outside brightness voltage input from the optical sensor
OPTI SEN (FILT) [V]	The value of outside brightness voltage filtered by BCM
OPTICAL SENSOR [On/Off/NG]	NOTE: This item is displayed, but cannot be monitored.

ACTIVE TEST

Test item	Operation	Description
FR FOG LAMP	On	Transmits the front fog light request signal to IPDM E/R via CAN communication to turn the front fog lamp ON.
	Off	Stops the front fog light request signal transmission.
RR FOG LAMP	On	NOTE: This item is displayed, but cannot be tested.
	Off	
DAYTIME RUNNING LIGHT	On	Transmits the daytime running light request signal to IPDM E/R via CAN communication to turn the daytime running light ON.
	Off	Stops the daytime running light request signal transmission.
ILL DIM SIGNAL	On	<ul style="list-style-type: none"> Transmits the dimmer signal to combination meter via CAN communication and dims combination meter. Transmits the dimmer signal to display control unit and dims display.
	Off	Stops the dimmer signal transmission.

WIPER

WIPER : CONSULT Function (BCM - WIPER)

INFOID:000000013502508

WORK SUPPORT

Service item	Setting item	Description
RAIN SENSOR*1	On*3	With rain sensor (Front wiper intermittent time linked with the rain sensor, vehicle speed, and AUTO dial position)
	Off	Without rain sensor (Front wiper intermittent time linked with the vehicle speed and AUTO dial position)
WIPER SPEED SETTING*2	On	Linked with vehicle speed (Front wiper intermittent time linked with the vehicle speed and wiper intermittent dial position.)
	Off*3	Not linked with vehicle speed (Front wiper intermittent time linked with the wiper intermittent dial position.)

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Service item	Setting item	Description	
FR RR DRIP	On*3	Front wiper drop wipe ON	The setting of drop wipe operation can be changed
	Off	Front wiper drop wipe OFF	

*1: With rain sensor

*2: Without rain sensor

*3: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item [Unit]	Description
PUSH SW [Off/On]	The switch status input from push-button ignition switch.
VEH SPEED 1 [km/h]	Displays the value of the vehicle speed signal received from combination meter via CAN communication.
FR WIPER HI [Off/On]	Status of each switch judged by BCM using the combination switch reading function
FR WIPER LOW [Off/On]	
FR WASHER SW [Off/On]	
FR WIPER INT [Off/On]	
FR WIPER STOP [Off/On]	Displays the status of the front wiper position signal received from IPDM E/R via CAN communication.
INT VOLUME [1 – 7]	Status of each switch judged by BCM using the combination switch reading function
RR WIPER ON [Off/On]	NOTE: The item is indicated, but not monitored.
RR WIPER INT [Off/On]	NOTE: The item is indicated, but not monitored.
RR WASHER SW [Off/On]	NOTE: The item is indicated, but not monitored.
RR WIPER STOP [Off/On]	NOTE: The item is indicated, but not monitored.
H/L WSR SW [Off/On]	NOTE: This item is indicated, but not monitored
RAIN SENSOR* [OFF/LOW/HIGH/SPLASH/NG]	Request signal from rain sensor detected by BCM is displayed

*: For models without rain sensor, this item is displayed, but can not be monitored.

ACTIVE TEST

Test item	Operation	Description
FR WIPER	Hi	Transmits the front wiper request signal (HI) to IPDM E/R via CAN communication to operate the front wiper HI operation.
	Lo	Transmits the front wiper request signal (LO) to IPDM E/R via CAN communication to operate the front wiper LO operation.
	INT	Transmits the front wiper request signal (INT) to IPDM E/R via CAN communication to operate the front wiper INT operation.
	Off	Stops transmitting the front wiper request signal to stop the front wiper operation.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test item	Operation	Description
RR WIPER	NOTE: The item is indicated, but not used.	
HEADLAMP WASHER	NOTE: The item is indicated, but not used.	

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000013502505

WORK SUPPORT

Service item	Setting item	Setting
3-TIME FLASHER SETTING	On*	With 3-time flasher function
	Off	Without 3-time flasher function

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW -DR [On/Off]	Indicated [On/Off] condition of door request switch (driver side)
REQ SW -AS [On/Off]	Indicated [On/Off] condition of door request switch (passenger side)
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
TURN SIGNAL R [On/Off]	Each switch status that BCM detects from the combination switch reading function.
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	The switch status input from the hazard switch.
RKE-LOCK [On/Off]	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK [On/Off]	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-PANIC [On/Off]	NOTE: This item is displayed, but cannot be monitored.

ACTIVE TEST

Test item	Operation	Description
FLASHER	RH	Outputs the voltage to blink the right side turn signal lamps.
	LH	Outputs the voltage to blink the left side turn signal lamps.
	Off	Stops the voltage to turn the turn signal lamps OFF.

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000013502496

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item	Description	
INSIDE ANT DIAGNOSIS	This function allows inside key antenna self-diagnosis	A
LOCK/UNLOCK BY I-KEY	Door lock function (door request switch) mode can be changed to operation in this mode • On: Operate • Off: Non-operation	B
ENGINE START BY I-KEY	Engine start function mode can be changed to operation with this mode • On: Operate • Off: Non-operation	C
TRUNK/GLASS HATCH OPEN	Reminder function (trunk lid opener request switch) mode can be changed to operation with this mode • On: Operate • Off: Non-operation	D
AUTO LOCK SET	Auto door lock operation time can be changed in this mode • MODE 1: OFF • MODE 2: 30 sec. • MODE 3: 1 minute • MODE 4: 2 minutes • MODE 5: 3 minutes • MODE 6: 4 minutes • MODE 7: 5 minutes	E
SHORT CRANKING OUTPUT	Starter motor can operate during the times below • 70 msec • 100 msec • 200 msec	F
CONFIRM KEY FOB ID	It can be checked whether Intelligent Key ID code is registered or not in this mode	G
RETRACTABLE MIRROR SET	NOTE: This item is displayed, but cannot be used	H
TOUCH SENSOR UNLOCK FUNCTION SETTING	One touch unlock function can be changed to operation with this mode • On: Operate • Off: Non-operation	I
IGN/ACC BATTERY SAVER	Ignition battery saver system mode can be changed to operation with this mode • On: Operate • Off: Non-operation	J
REMOTE ENGINE START	NOTE: This item is displayed, but cannot be used	K
INTELLIGENT KEY LINK SET	NOTE: This item is displayed, but cannot be used	L
ANSWER BACK	Reminder function (door request switch and Intelligent Key) mode can be selected from the following with this mode • On: S mode (buzzer or horn reminder non-operation) • Off: C mode (buzzer or horn operate)	BCS
ANSWER BACK I-KEY LOCK UNLOCK	Reminder function (door request switch) mode can be selected from the following with this mode • BUZZER: Sound Intelligent Key warning buzzer • HORN: Sound horn • Off: Only hazard warning lamp operate • INVALID: This item is displayed, but cannot be used	N
ANSWERBACK KEYLESS LOCK UNLOCK	Reminder function (Intelligent Key) mode can be selected from the following with this mode • On: Horn and hazard warning lamp operate • Off: Only hazard warning lamp operate	O
WELCOME LIGHT OP SET	NOTE: This item is displayed, but cannot be used	P

SELF-DIAG RESULT

Refer to [BCS-63, "DTC Index"](#).

DATA MONITOR

NOTE:

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition
REQ SW -DR	Indicates [On/Off] condition of front door request switch (driver side)
REQ SW -AS	Indicates [On/Off] condition of front door request switch (passenger side)
REQ SW -BD/TR	Indicates [On/Off] condition of trunk lid opener request switch
PUSH SW	Indicates [On/Off] condition of push-button ignition switch
SHFTLCK SLNID PWR SPLY	Indicates [On/Off] condition of the power supply from BCM to shift lock solenoid
CLUCH SW	NOTE: This item is displayed, but cannot be monitored
BRAKE SW 1	Indicates [On/Off]* condition of stop lamp switch power supply
BRAKE SW 2	Indicates [On/Off] condition of stop lamp switch
DETE/CANCL SW	Indicates [On/Off] condition of P position
SFT PN/N SW	Indicates [On/Off] condition of P or N position
UNLK SEN -DR	Indicates [On/Off] condition of driver door UNLOCK status
PUSH SW -IPDM	Indicates [On/Off] condition of push-button ignition switch
IGN RLY1 -F/B	Indicates [On/Off] condition of ignition relay 1
DETE SW -IPDM	Indicates [On/Off] condition of P position
SFT PN -IPDM	Indicates [On/Off] condition of P or N position
SFT P -MET	Indicates [On/Off] condition of P position
SFT N -MET	Indicates [On/Off] condition of N position
ENGINE STATE	Indicates [STOP/STALL/CRANK/RUN] condition of engine states
VEH SPEED 1	Display the vehicle speed signal received from combination meter by numerical value [km/h]
VEH SPEED 2	Display the vehicle speed signal received from ABS or VDC or TCM by numerical value [km/h]
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver door status
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger door status
DOOR STAT-RR	Indicates [LOCK/READY/UNLK] condition of rear door RH status
DOOR STAT-RL	Indicates [LOCK/READY/UNLK] condition of rear door LH status
BK DOOR STATE	NOTE: This item is displayed, but cannot be monitored
ID OK FLAG	Indicates [Set/Reset] condition of Intelligent Key ID
PRMT ENG STRT	Indicates [Set/Reset] condition of engine start possibility
PRMT RKE STRT	NOTE: This item is displayed, but cannot be monitored
I-KEY OK FLAG	Indicates [KEY On/NOT On] condition of Intelligent Key ID and Intelligent Key is detected inside vehicle
PRBT ENG STRT	Indicates whether or not the engine is in start prohibited status
ID AUTHENT CANCEL TIMER	Indicates whether or not it is in engine start possible status when Intelligent Key verification is unnecessary
ACC BATTERY SAVER	Indicates [On/Off] whether or not ignition battery saver is in operation
CRNK PRBT TMR	Indicates [On/Off] whether or not in cranking prohibited status due to starter motor protection function operation
AUT CRANK TMR	Indicates [On/Off] whether or not in AUTO CRANKING MODE status
CRNK PRBT TME	Indicates the time for changing from cranking prohibited status to cranking possible status
AUT CRANK TMR	Indicates the time that AUTO CRANKING MODE operates
CRANKING TME	Indicates the cranking operation time

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Condition
SHORT CRANK	NOTE: This item is displayed, but not used
DETE SW PWR	Indicates [On/Off] condition of the power supply from BCM to the A/T shift selector (detention switch)
IGN RLY3-REQ	Indicates [On/Off] condition of blower relay control signal
ACC RLY-REQ	Indicates [On/Off] condition of accessory relay control signal
RKE OPE COUN1	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing
RKE OPE COUN2	NOTE: This item is displayed, but cannot be monitored
TRNK/HAT MNTR	Indicates [On/Off] condition of trunk room lamp switch
RKE-LOCK	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-TR/BD	Indicates [On/Off] condition of trunk open signal from Intelligent Key
RKE-PANIC	Indicates [On/Off] condition of panic alarm signal from Intelligent Key
RKE-MODE CHG	NOTE: This item is displayed, but cannot be monitored
RKE PBD	NOTE: This item is displayed, but cannot be monitored

*: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

ACTIVE TEST

Test item	Description
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation <ul style="list-style-type: none"> • On: Operates • Off: Non-operation
INSIDE BUZZER	This test is able to check warning chime in combination meter operation <ul style="list-style-type: none"> • Take Out: Take away warning chime sounds when CONSULT screen is touched • Key: Key warning chime sounds when CONSULT screen is touched • Knob: OFF position warning chime sounds when CONSULT screen is touched • Off: Non-operation
INDICATOR	This test is able to check information display (combination meter) operation <ul style="list-style-type: none"> • KEY ON: [Intelligent Key system malfunction] displays when CONSULT screen is touched • KEY IND: [Steering lock unit ID registration complete] displays when CONSULT screen is touched • Off: Non-operation
INT LAMP	This test is able to check interior room lamp operation <ul style="list-style-type: none"> • On: Operates • Off: Non-operation
FLASHER	This test is able to check hazard warning lamp operation The hazard warning lamps are activated after "LH/RH/Off" on CONSULT screen is touched
HORN	This test is able to check horn operation <ul style="list-style-type: none"> • On: Operates
IGN CONT2	This test is able to operate the blower relay in fuse block (J/B) <ul style="list-style-type: none"> • On: Operates • Off: Non-operation
ENGINE SW ILLUMI	This test is able to check push-ignition switch illumination operation Push-ignition switch illumination illuminates when "On" on CONSULT screen is touched
PUSH SWITCH INDICATOR	This test is able to check push-ignition switch indicator operation when "On" on CONSULT screen is touched
ACC CONT	This test is able to operate the accessory relay in fuse block (J/B) <ul style="list-style-type: none"> • On: Operates • Off: Non-operation

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test item	Description
IGN CONT1	This test is able to operate the ignition relay in IPDM E/R <ul style="list-style-type: none"> • On: Operates • Off: Non-operation
IGNITION RELAY	This test is able to operate the ignition relay in fuse block (J/B) <ul style="list-style-type: none"> • On: Operates • Off: Non-operation
ST CONT LOW	This test is able to operate the starter relay in IPDM E/R <ul style="list-style-type: none"> • On: Non-operation • Off: Operates
BATTERY SAVER	This test is able to check interior room lamp battery saver operation <ul style="list-style-type: none"> • On: Outputs interior room lamp power supply to turn interior room lamps ON. • Off: Cuts interior room lamp power supply to turn interior room lamps OFF.
TRUNK/BACK DOOR	This test is able to check trunk lid open operation. This actuator opens when "Open" on CONSULT screen is touched.
RETRACTABLE MIRROR	NOTE: This item is displayed, but cannot be used
INTELLIGENT KEY LINK(CAN)	NOTE: This item is displayed, but cannot be used
REVERSE LAMP TEST	NOTE: This item is displayed, but cannot be used
DOOR HANDLE LAMP TEST	This test is able to check outside handle lamp operation <ul style="list-style-type: none"> • On: Operates • Off: Non-operation
DR SEAT LAMP TEST	NOTE: This item is displayed, but cannot be used
AS SEAT LAMP TEST	NOTE: This item is displayed, but cannot be used
SHIFT SPOT LAMP TEST	NOTE: This item is displayed, but cannot be used
TRUNK/LUGGAGE LAMP TEST	This test is able to check trunk room lamp operation <ul style="list-style-type: none"> • On: Operates • Off: Non-operation
KEYFOB P/W TEST	This test is able to check keyless power window up/down operation <ul style="list-style-type: none"> • Up: Non-operation • Down*: Power window and sunroof open • Off: Non-operation
SHIFTLOCK SORENOID TEST	NOTE: This item is displayed, but cannot be used

*: When ignition switch is OFF, driver door opened, power window and sunroof is closed.

COMB SW

COMB SW : CONSULT Function (BCM - COMB SW)

INFOID:000000012792454

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [UNIT]	Description
FR WIPER HI [Off/On]	Displays the status of the FR WIPER HI switch in combination switch judged by BCM with the combination switch reading function.
FR WIPER LOW [Off/On]	Displays the status of the FR WIPER LOW switch in combination switch judged by BCM with the combination switch reading function.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item [UNIT]	Description	
FR WASHER SW [Off/On]	Displays the status of the FR WASHER switch in combination switch judged by BCM with the combination switch reading function.	A
FR WIPER INT [Off/On]	Displays the status of the FR WIPER INT/AUTO switch in combination switch judged by BCM with the combination switch reading function.	B
INT VOLUME [1 - 7]	Displays the status of wiper volume dial position judged by BCM with the combination switch reading function.	C
RR WIPER ON [Off/On]	NOTE: This item is displayed, but cannot be monitored	D
RR WIPER INT [Off/On]	NOTE: This item is displayed, but cannot be monitored	E
RR WASHER SW [Off/On]	NOTE: This item is displayed, but cannot be monitored	F
TURN SIGNAL R [Off/On]	Displays the status of the TURN RH switch in combination switch judged by BCM with the combination switch reading function.	G
TURN SIGNAL L [Off/On]	Displays the status of the TURN LH switch in combination switch judged by BCM with the combination switch reading function.	H
TAIL LAMP SW [Off/On]	Displays the status of the TAIL LAMP switch in combination switch judged by BCM with the combination switch reading function.	I
HI BEAM SW [Off/On]	Displays the status of the HI BEAM switch in combination switch judged by BCM with the combination switch reading function.	J
HEAD LAMP SW 1 [Off/On]	Displays the status of the HEADLAMP 1 switch in combination switch judged by BCM with the combination switch reading function.	K
HEAD LAMP SW 2 [Off/On]	Displays the status of the HEADLAMP 2 switch in combination switch judged by BCM with the combination switch reading function.	L
PASSING SW [Off/On]	Displays the status of the PASSING switch in combination switch judged by BCM with the combination switch reading function.	
AUTO LIGHT SW [Off/On]	Displays the status of the AUTO LIGHT switch in combination switch judged by BCM with the combination switch reading function.	
FR FOG SW [Off/On]	Displays the status of the FR FOG switch in combination switch judged by BCM with the combination switch reading function.	
RR FOG SW [Off/On]	NOTE: This item is displayed, but cannot be monitored	

BCM

BCM : CONSULT Function (BCM - BCM)

INFOID:000000012792455

WORK SUPPORT

BCS

Item	Description	
RESET SETTING VALUE	Return a value set with Work Support of each system to a default value in factory shipment.	N

IMMU

IMMU : CONSULT Function (BCM - IMMU)

INFOID:000000013502500

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item	Content
CONFIRM ID ALL	Indicates [Yet] at all time. Switches to [Done] when a registered Intelligent Key backside is contacted to push-button ignition switch.
CONFIRM ID4	
CONFIRM ID3	
CONFIRM ID2	
CONFIRM ID1	
NOT REGISTERED	Indicates [ID OK] when key ID that is registered is received or is not yet received. Indicates [ID NG] when key ID that is not registered is received.
TP 4	Indicates the number of IDs that are registered.
TP 3	
TP 2	
TP 1	
PUSH SW	Indicates [On/Off] condition of push-button ignition switch.

ACTIVE TEST

Test item	Description
THEFT IND	This test is able to check security indicator lamp operation. Security indicator lamp is turned on when "On" on CONSULT screen touched.

BATTERY SAVER

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:000000013502507

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW -DR [On/Off]	Indicated [On/Off] condition of door request switch (driver side)
REQ SW -AS [On/Off]	Indicated [On/Off] condition of door request switch (passenger side)
REQ SW -RR [On/Off]	NOTE: This item is displayed, but cannot be monitored
REQ SW -RL [On/Off]	NOTE: This item is displayed, but cannot be monitored
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
UNLK SEN -DR [On/Off]	Indicates [On/Off] condition of driver door UNLOCK status
DOOR SW-DR [On/Off]	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS [On/Off]	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR [On/Off]	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL [On/Off]	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK [On/Off]	NOTE: This item is displayed, but cannot be monitored

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
CDL LOCK SW [On/Off]	Indicated [On/Off] condition of lock signal from door lock and unlock switch
CDL UNLOCK SW [On/Off]	Indicated [On/Off] condition of unlock signal from door lock and unlock switch
KEY CYL LK-SW [On/Off]	Indicated [On/Off] condition of lock signal from door key cylinder switch
KEY CYL UN-SW [On/Off]	Indicated [On/Off] condition of unlock signal from door key cylinder switch
TRNK/HAT MNTR [On/Off]	Indicates [On/Off] condition of trunk room lamp switch
RKE-LOCK [On/Off]	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK [On/Off]	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key

ACTIVE TEST

Test item	Operation	Description
BATTERY SAVER	Off	Outputs interior room lamp power supply.
	On	Stops interior room lamp power supply.

TRUNK

TRUNK : CONSULT Function (BCM - TRUNK)

INFOID:000000013502497

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Contents
PUSH SW	Indicates [On/Off] condition of push-button ignition switch
UNLK SEN -DR	Indicates [On/Off] condition of unlock sensor
VEH SPEED 1	Indicates [km/h] condition of vehicle speed signal from combination meter
KEY CYL SW-TR	NOTE: This item is displayed, but cannot be monitored
TR CANCEL SW	Indicates [On/Off] condition of trunk lid opener cancel switch
TR/BD OPEN SW	Indicates [On/Off] condition of trunk lid opener switch
TRNK/HAT MNTR	Indicates [On/Off] condition of trunk room lamp switch
RKE-TR/BD	Indicates [On/Off] condition of trunk open signal from Intelligent Key

THEFT ALM

THEFT ALM : CONSULT Function (BCM - THEFT)

INFOID:000000013502498

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitored Item	Description
REQ SW -DR	Indicates [On/Off] condition of door request switch (driver side).
REQ SW -AS	Indicates [On/Off] condition of door request switch (passenger side).

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitored Item	Description
REQ SW -RR	NOTE: This item is indicated, but not monitored.
REQ SW -RL	NOTE: This item is indicated, but not monitored.
REQ SW -BD/TR	Indicates [On/Off] condition of trunk lid opener request switch.
PUSH SW	Indicates [On/Off] condition of push-button ignition switch
UNLK SEN -DR	Indicates [On/Off] condition of driver door UNLOCK status.
DOOR SW-DR	Indicates [On/Off] condition of front door switch (driver side).
DOOR SW-AS	Indicates [On/Off] condition of front door switch (passenger side).
DOOR SW-RR	Indicates [On/Off] condition of rear door switch RH.
DOOR SW-RL	Indicates [On/Off] condition of rear door switch LH.
DOOR SW-BK	NOTE: This item is indicated, but not monitored.
CDL LOCK SW	Indicates [On/Off] condition of lock signal from door lock/unlock switch.
CDL UNLOCK SW	Indicates [On/Off] condition of unlock signal from door lock/unlock switch.
KEY CYL LK-SW	Indicates [On/Off] condition of lock signal from door key cylinder switch.
KEY CYL UN-SW	Indicates [On/Off] condition of unlock signal from door key cylinder switch.
KEY CYL SW-TR	NOTE: This item is indicated, but not monitored.
TR/BD OPEN SW	Indicates [On/Off] condition of trunk lid opener switch.
TRNK/HAT MNTR	Indicates [On/Off] condition of trunk room lamp switch.
SEN CANCEL SW	NOTE: This item is indicated, but not monitored.
RKE-LOCK	Indicates [On/Off] condition of LOCK signal from Intelligent Key.
RKE-UNLOCK	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key.
RKE-TR/BD	Indicates [On/Off] condition of TRUNK OPEN signal from Intelligent Key.

WORK SUPPORT

Service Item	Description
SECURITY ALARM SET	This mode is able to confirm and change security alarm "On" - "Off" setting.

ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation. Turn signal lamp is activated after "LH" or "RH" on CONSULT screen is touched.
THEFT IND	This test is able to check security indicator lamp operation. Security indicator lamp is turned on when "On" on CONSULT screen is touched.
VEHICLE SECURITY HORN	This test is able to check horn operation. Horn is activated for 0.5 seconds after "On" on CONSULT screen is touched.
HEADLAMP(HI)	This test is able to check headlamps operation. Headlamps are turned on when "On" on CONSULT screen is touched.

RETAIND PWR

RETAIND PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000013502503

Data monitor

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Description
DOOR SW-DR	Indicates [ON/OFF] condition of driver side door switch.
DOOR SW-AS	Indicates [ON/OFF] condition of passenger side door switch.

SIGNAL BUFFER

SIGNAL BUFFER : CONSULT Function (BCM - SIGNAL BUFFER)

INFOID:000000012792461

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [UNIT]	Description
PUSH SW [Off/On]	Displays the status of the push-button ignition switch (push switch) judged by BCM.

ACTIVE TEST

Test item	Operation	Description
OIL PRESSURE SW	Off	OFF
	On	BCM transmits the oil pressure switch signal to the combination meter via CAN communication, which illuminates the oil pressure warning lamp in the combination meter.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM

Reference Value

INFOID:0000000012792463

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT MONITOR ITEM

Monitor Item	Condition	Value/Status
CONFIRM ID ALL	The Intelligent Key ID that the NATS antenna amp. receives is not recognized by any Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the NATS antenna amp. receives is recognized by any Intelligent Key ID registered to BCM.	Done
CONFIRM ID4	The Intelligent Key ID that the NATS antenna amp. receives is not recognized by the fourth Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the NATS antenna amp. receives is recognized by the fourth Intelligent Key ID registered to BCM.	Done
CONFIRM ID3	The Intelligent Key ID that the NATS antenna amp. receives is not recognized by the third Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the NATS antenna amp. receives is recognized by the third Intelligent Key ID registered to BCM.	Done
CONFIRM ID2	The Intelligent Key ID that the NATS antenna amp. receives is not recognized by the second Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the NATS antenna amp. receives is recognized by the second Intelligent Key ID registered to BCM.	Done
CONFIRM ID1	The Intelligent Key ID that the NATS antenna amp. receives is not recognized by the first Intelligent Key ID registered to BCM.	Yet
	The Intelligent Key ID that the NATS antenna amp. receives is recognized by the first Intelligent Key ID registered to BCM.	Done
NOT REGISTERED	BCM detects registered Intelligent Key ID, or BCM does not detect Intelligent Key ID.	ID OK
	BCM detects non-registration Intelligent Key ID.	ID NG
TP 4	The ID of fourth Intelligent Key is not registered to BCM	Yet
	The ID of fourth Intelligent Key is registered to BCM	Done
TP 3	The ID of third Intelligent Key is not registered to BCM	Yet
	The ID of third Intelligent Key is registered to BCM	Done
TP 2	The ID of second Intelligent Key is not registered to BCM	Yet
	The ID of second Intelligent Key is registered to BCM	Done
TP 1	The ID of first Intelligent Key is not registered to BCM	Yet
	The ID of first Intelligent Key is registered to BCM	Done
REQ SW -DR	Driver door request switch is not pressed	Off
	Driver door request switch is pressed	On
REQ SW -AS	Passenger door request switch is not pressed	Off
	Passenger door request switch is pressed	On
REQ SW -RR	NOTE: The item is indicated, but not monitored.	Off
REQ SW -RL	NOTE: The item is indicated, but not monitored.	Off

BCM

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition		Value/Status	
REQ SW -BD/TR	Trunk lid opener request switch is not pressed		Off	A
	Trunk lid opener request switch is pressed		On	
PUSH SW	Push-button ignition switch (push switch) is not pressed		Off	B
	Push-button ignition switch (push switch) is pressed		On	
SHFTLCK SLNID PWR SPLY	When BCM is not supplying power to shift lock solenoid		Off	C
	When BCM is supplying power to shift lock solenoid		On	
CLUCH SW	NOTE: The item is indicated, but not monitored.		Off	D
BRAKE SW 1	The brake pedal is not depressed		Off	E
	The brake pedal is depressed		On	
BRAKE SW 2	The brake pedal is depressed when No. 19 fuse is blown		Off	E
	The brake pedal is not depressed when No. 19 fuse is blown, or No. 10 fuse is normal		On	
DETE/CANCL SW	Selector lever in P position	Release selector button	Off	F
		Push selector button	On	
	Selector lever in any position other than P		On	
SFT PN/N SW	Selector lever in any position other than P or N		Off	G
	Selector lever in P or N position		On	
S/L -LOCK	NOTE: The item is indicated, but not monitored.		Off	H
S/L -UNLOCK	NOTE: The item is indicated, but not monitored.		Off	I
S/L RELAY-F/B	NOTE: The item is indicated, but not monitored.		Off	J
S/L LIMIT SW1	NOTE: The item is indicated, but not monitored.		Off	J
S/L LIMIT SW2	NOTE: The item is indicated, but not monitored.		Off	K
UNLK SEN -DR	Driver door is locked		Off	K
	Driver door is unlocked		On	
PUSH SW -IPDM	Push-button ignition switch (push-switch) is not pressed		Off	L
	Push-button ignition switch (push-switch) is pressed		On	
IGN RLY1 -F/B	Ignition switch in OFF or ACC position		Off	BCS
	Ignition switch in ON position		On	
DETE SW -IPDM	Selector lever in any position other than P		Off	N
	Selector lever in P position	Push selector button	On	
		Release selector button	On	
SFT PN -IPDM	Selector lever in any position other than P or N		Off	O
	Selector lever in P or N position		On	
SFT P -MET	Selector lever in any position other than P		Off	P
	Selector lever in P position		On	
SFT N -MET	Selector lever in any position other than N		Off	P
	Selector lever in N position		On	
ENGINE STATE	Engine stopped		STOP	
	While the engine stalls		STALL	
	At engine cranking		CRANK	
	Engine running		RUN	

BCM

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
S/L LOCK-IPDM	NOTE: The item is indicated, but not monitored.	Off
S/L UNLK-IPDM	NOTE: The item is indicated, but not monitored.	Off
S/L RELAY-REQ	NOTE: The item is indicated, but not monitored.	Off
VEH SPEED 1	While driving	Equivalent to speedometer reading
VEH SPEED 2	While driving	Equivalent to speedometer reading
S/L ACK	NOTE: The item is indicated, but not monitored.	STAT
DOOR STAT-DR	Driver door is locked	LOCK
	Driver door is unlocked	UNLOCK
DOOR STAT-AS	Passenger door is locked	LOCK
	Passenger door is unlocked	UNLOCK
DOOR STAT-RR	Rear door RH is locked	LOCK
	Rear door RH is unlocked	UNLOCK
DOOR STAT-RL	Rear door LH is locked	LOCK
	Rear door LH is unlocked	UNLOCK
BK DOOR STATE	Trunk lid is locked	LOCK
	Trunk lid is unlocked	UNLOCK
ID OK FLAG	NOTE: The item is indicated, but not monitored.	Reset
PRMT ENG STRT	When the engine start is prohibited	Reset
	When the engine start is permitted	Set
PRMT RKE STRT	NOTE: The item is indicated, but not monitored.	Reset
I-KEY OK FLAG	Intelligent Key ID and Intelligent Key is detected outside vehicle	NOT On
	Intelligent Key ID and Intelligent Key is detected inside vehicle	KEY On
PRBT S/L LOCK	NOTE: The item is indicated, but not monitored.	Reset
PRBT ENG STRT	Not activated fail safe function	Reset
	Engine start is prohibited by fail safe function	SET
ID AUTHENT CANCEL TIMER	Engine start is prohibited without Intelligent Key	STOP
	Engine start is permitted without Intelligent Key	OPRAT
ACC BATTERY SAVER	ACC battery saver timer is stop	STOP
	ACC battery saver timer is running	OPRAT
CRNK PRBT TMR	Cranking is permitted	Off
	Cranking is prohibited	On
AUT CRANK TMR	Not auto cranking	Off
	During auto cranking	On
CRNK PRBT TME	Cranking prohibit timer	sec
AUT CRANK TMR	Auto cranking timer	sec
CRANKING TME	Cranking timer	sec
SHORT CRANK	NOTE: The item is indicated, but not monitored.	—

BCM

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
ST RLY-REQ	NOTE: The item is indicated, but not monitored.	Off	A
IGN RLY1 -REQ	NOTE: The item is indicated, but not monitored.	Off	B
IGN RLY2 -REQ	NOTE: The item is indicated, but not monitored.	Off	C
DETE SW PWR	NOTE: The item is indicated, but not monitored.	Off	
IGN RLY3-REQ	NOTE: The item is indicated, but not monitored.	Off	D
S/L PWR	NOTE: The item is indicated, but not monitored.	Off	
ACC RLY-REQ	NOTE: The item is indicated, but not monitored.	Off	E
RKE OPE COUN1	During the operation of the Intelligent Key	Operation frequency of the key	F
RKE OPE COUN2	NOTE: The item is indicated, but not monitored.	—	
FR WIPER HI	Other than front wiper switch HI	Off	G
	Front wiper switch HI	On	
FR WIPER LOW	Other than front wiper switch LO	Off	H
	Front wiper switch LO	On	
FR WASHER SW	Front washer switch OFF	Off	I
	Front washer switch ON	On	
FR WIPER INT	Other than front wiper switch INT/AUTO	Off	J
	Front wiper switch INT/AUTO	On	
FR WIPER STOP	Front wiper is not in STOP position	Off	K
	Front wiper is in STOP position	On	
INT VOLUME	Wiper volume dial is in a dial position 1 - 7	Wiper volume dial position	
RR WIPER ON	NOTE: The item is indicated, but not monitored.	Off	L
RR WIPER INT	NOTE: The item is indicated, but not monitored.	Off	
RR WASHER SW	NOTE: The item is indicated, but not monitored.	Off	BCS
RR WIPER STOP	NOTE: The item is indicated, but not monitored.	Off	
TURN SIGNAL R	Other than turn signal switch RH	Off	N
	Turn signal switch RH	On	
TURN SIGNAL L	Other than turn signal switch LH	Off	O
	Turn signal switch LH	On	
TAIL LAMP SW	Other than lighting switch 1ST or 2ND	Off	P
	Lighting switch 1ST or 2ND	On	
HI BEAM SW	Other than lighting switch HI	Off	
	Lighting switch HI	On	
HEAD LAMP SW 1	Other than lighting switch 2ND	Off	
	Lighting switch 2ND	On	

BCM

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status
HEAD LAMP SW 2	Other than lighting switch 2ND	Off
	Lighting switch 2ND	On
PASSING SW	Other than lighting switch PASS	Off
	Lighting switch PASS	On
AUTO LIGHT SW	Other than lighting switch AUTO	Off
	Lighting switch AUTO	On
FR FOG SW	Front fog lamp switch OFF	Off
	Front fog lamp switch ON	On
RR FOG SW	NOTE: The item is indicated, but not monitored.	Off
DOOR SW-DR	Driver door closed	Off
	Driver door opened	On
DOOR SW-AS	Passenger door closed	Off
	Passenger door opened	On
DOOR SW-RR	Rear RH door closed	Off
	Rear RH door opened	On
DOOR SW-RL	Rear LH door closed	Off
	Rear LH door opened	On
DOOR SW-BK	NOTE: The item is indicated, but not monitored.	Off
CDL LOCK SW	Other than power door lock switch LOCK	Off
	Power door lock switch LOCK	On
CDL UNLOCK SW	Other than power door lock switch UNLOCK	Off
	Power door lock switch UNLOCK	On
KEY CYL LK-SW	Other than driver door key cylinder LOCK position	Off
	Driver door key cylinder LOCK position	On
KEY CYL UN-SW	Other than driver door key cylinder UNLOCK position	Off
	Driver door key cylinder UNLOCK position	On
KEY CYL SW-TR	NOTE: The item is indicated, but not monitored.	Off
HAZARD SW	Hazard switch is OFF	Off
	Hazard switch is ON	On
REAR DEF SW	Rear window defogger switch OFF	Off
	Rear window defogger switch ON	On
H/L WSR SW	NOTE: The item is indicated, but not monitored.	Off
TR CANCEL SW	Trunk lid opener cancel switch OFF	Off
	Trunk lid opener cancel switch ON	On
TR/BD OPEN SW	Trunk lid opener switch OFF	Off
	While the trunk lid opener switch is turned ON	On
TRNK/HAT MNTR	Trunk lid closed	Off
	Trunk lid opened	On
FAN ON SIG	NOTE: The item is indicated, but not monitored.	Off
AIR COND SW	NOTE: The item is indicated, but not monitored.	Off

BCM

< ECU DIAGNOSIS INFORMATION >

Monitor Item	Condition	Value/Status	
SEN CANCEL SW	NOTE: The item is indicated, but not monitored.	Off	A
THERMO AMP	NOTE: The item is indicated, but not monitored.	Off	B
RKE-LOCK	LOCK button of the Intelligent Key is not pressed	Off	C
	LOCK button of the Intelligent Key is pressed	On	
RKE-UNLOCK	UNLOCK button of the Intelligent Key is not pressed	Off	D
	UNLOCK button of the Intelligent Key is pressed	On	
RKE-TR/BD	TRUNK OPEN button of the Intelligent Key is not pressed	Off	E
	TRUNK OPEN button of the Intelligent Key is pressed	On	
RKE-PANIC	NOTE: The item is indicated, but not monitored.	Off	F
RKE-MODE CHG	NOTE: The item is indicated, but not monitored.	Off	G
RKE PBD	NOTE: The item is indicated, but not monitored.	Off	H
SHOCK SENSOR	Air bag signal (NORMAL) is detected.	NOMAL	I
	Air bag signal (AIR BAG OPEN) is detected.	On	
	Air bag signal is not detected.	Off	
OPTI SEN (DTCT)	Bright outside of the vehicle	Close to 5 V	J
	Dark outside of the vehicle	Close to 0 V	
OPTI SEN (FILT)	Bright outside of the vehicle (Lighting switch AUTO)	Close to 5 V	K
	Dark outside of the vehicle (Lighting switch AUTO)	Close to 1.50 V	
OPTICAL SENSOR	NOTE: The item is indicated, but not monitored.	Off	L
RAIN SENSOR	No rain (or very light rain)	Off	M
	Light rain	LOW	
	Heavy rain	HIGH	
	When liquid is splashed on the front window	SPLSH	
	Rain sensor internal error	NG	

BCS

N


O

P

BCM

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT








PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
1 (R)	Ground	Push-button ignition switch (Push switch)	Input	Push-button ignition switch (push switch)	Pressed	0 - 1.5 V
					Not pressed	9 - 16 V
3 (Y)	Ground	Sensor power supply	Output	Ignition switch	OFF	0 V
					ON	4.65 - 5.5 V
4 (BG)	Ground	Optical sensor	Input	Ignition switch ON	When bright outside of the vehicle	Close to 5 V
					When dark outside of the vehicle	Close to 0 V
5*1 (LG)	Ground	Shock status	Input	—		—

JMMIA1399ZZ

BCM

< ECU DIAGNOSIS INFORMATION >




Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
10 (W)	Ground	Combination switch OUTPUT 5	Output	Combination switch	All switches OFF	0 V
					Turn signal switch RH	
					Lighting switch 1ST	
					Lighting switch 2ND	
					Lighting switch HI	
11 (SB)	Ground	Combination switch OUTPUT 4	Output	Combination switch	All switches OFF	0 V
					Turn signal switch LH	
					Lighting switch 2ND	
					Lighting switch PASS	
					Front fog lamp switch ON	
12 (L)	Ground	Combination switch OUTPUT 3	Output	Combination switch	All switches OFF	0 V
					Front wiper switch LO	
					Front wiper switch MIST	
					Front wiper switch INT/ AUTO	
					Lighting switch AUTO	
13 (G)	Ground	Combination switch OUTPUT 2	Output	Combination switch	All switches OFF	0 V
					Front washer switch ON	
Any of the condition below with all switches OFF <ul style="list-style-type: none"> • INT VOLUME 1 • INT VOLUME 5 • INT VOLUME 6 NOTE: "INT VOLUME" in "DATA MONITOR" mode of "BCM" using CONSULT.					10.7 V	
14 (P)	Ground	Combination switch OUTPUT 1	Output	Combination switch	All switches OFF	0 V
					Front wiper switch HI	
Any of the condition below with all switches OFF <ul style="list-style-type: none"> • INT VOLUME 1 • INT VOLUME 2 • INT VOLUME 3 • INT VOLUME 6 • INT VOLUME 7 NOTE: "INT VOLUME" in "DATA MONITOR" mode of "BCM" using CONSULT.					10.7 V	

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS





BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
15 (G)	Ground	One touch unlock sensor (driver door)	Input	Driver door out- side handle grip (backside)	Touch  JSMIA1404GB	
				Other than the above	9 - 16 V	
16 (G)	Ground	One touch unlock sensor (passenger door)	Input	Passenger door outside handle grip (backside)	Touch  JSMIA1404GB	
				Other than the above	9 - 16 V	
17 (P)	Ground	Receiver and sensor ground	Input	Ignition switch OFF	0 V	
18 (L)	Ground	Security indicator lamp control	Output	Security indica- tor lamp	ON Blinking (Ignition switch OFF)  JPMIA0014GB	
				OFF	12 V	
20 (R)	Ground	Detention switch	Input	Selector lever	P position (Release selec- tor button)	0 - 1.5 V
					Any position other than P	9 - 16 V
21 (SB)	Ground	Step lamp and foot lamp control	Output	Step lamp and foot lamp	ON	0 - 1.5 V
					OFF	9 - 16 V
25 (R)	Ground	Stop lamp switch 2	Input	Ignition switch OFF	9 - 16 V	
26 (R)	Ground	Extended storage fuse switch	Input	Extended stor- age fuse switch	ON (Ignition switch OFF)	9 - 16 V
					OFF	0 V
27 (P)	Ground	Stop lamp switch 1	Input	Stop lamp switch	OFF (Brake pedal is not depressed)	0 V
					ON (Brake pedal is de- pressed)	9 - 16 V

BCM

< ECU DIAGNOSIS INFORMATION >




Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
30 (W)	Ground	Front door lock as- sembly driver side (Unlock sensor)	Input	Driver door	 <p style="text-align: right;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
					UNLOCK status (Unlock sensor switch ON)
33 (V)	Ground	Trunk lid opener cancel switch	Input	Trunk lid opener cancel switch	 <p style="text-align: right;">PKIB4956J</p> <p style="text-align: center;">0 V</p>
					ON
36 (G)	Ground	Hazard switch	Input	Hazard switch	 <p style="text-align: right;">JPMIA0012GB</p> <p style="text-align: center;">1.1 V</p>
					Pressed
39 (BR)	Ground	P/N position	Input	Selector lever	 <p style="text-align: right;">JSMA1472GB</p> <p style="text-align: center;">11.8 V</p>
					Except P and N positions

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P





BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
48 (R)	Ground	Push-button ignition switch illumination power supply	Output	Push-button ig- nition switch	OFF	0 V
					ACC NOTE: The pulse cycle changes depending on illumination at push-button ignition switch.	
52*2 (G)	Ground	Dongle link	Input/ Output	Ignition switch OFF		9 V
52*2 (G)	Ground	Dongle link	Input/ Output	Ignition switch OFF		5 V
54 (V)	Ground	Communication line	Input/ Output	Ignition switch ON		
54 (V)	Ground	Communication line	Input/ Output	Ignition switch ON		9.0 - 10 V
55 (R)	Ground	Rain sensor serial link	Input/ Output	Ignition switch OFF		12 V
				Ignition switch ON		
55 (R)	Ground	Rain sensor serial link	Input/ Output	Ignition switch ON		8.7 V
59 (P)	Ground	CAN-L	Input/ Output	—		—
60 (L)	Ground	CAN-H	Input/ Output	—		—
61 (G)	Ground	Rear window defog- ger relay control	Output	Ignition switch ON	Rear window defogger is not activated	9 - 16 V
					Rear window defogger is activated	0 - 1.5 V
62 (R)	Ground	Starter relay control	Output	Ignition switch ON	When selector lever is in P or N position	9 - 16 V
					When selector lever is not in P or N position	0 - 0.5 V




BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
64 (V)	Ground	Intelligent Key warn- ing buzzer	Output	Intelligent Key warning buzzer	0 – 0.5 V	
					Sounding NOTE: The pulse cycle changes depending on buzzer sounds. <div style="text-align: right;">  <p style="font-size: small; margin-top: 5px;">JMMIA1407GB</p> </div>	
				Not sounding	9 – 16 V	
65 (B)	Ground	Outside handle lamp control	Output	Outside handle lamp	ON	0 – 0.5 V
					OFF	9 – 16 V
66 (Y)*3 (B)*4	Ground	Blower relay control	Output	Ignition switch	OFF or ACC	0 – 0.5 V
					ON	9 – 16 V
67 (W/B)	Ground	Ignition relay (F/B) control	Output	Ignition switch	OFF or ACC	0 – 0.5 V
					ON	9 – 16 V
68 (R)	Ground	Dimmer signal	Output	Ignition switch ON	Either of the following conditions <ul style="list-style-type: none"> • Lighting switch OFF • The area around the ve- hicle is bright (Shine a light on the optical sen- sor) 	0 V
					The area around the vehi- cle is dark (Block the light from the optical sensor)	12 V
69 (GR)	Ground	Detention switch power supply	Output	Ignition switch	ACC or ON	9 – 16 V
					For 15 seconds after igni- tion switch OFF	
					After 15 seconds after ig- nition switch OFF	
70 (B)	Ground	Ignition relay (IPDM E/R) control	Output	Ignition switch	OFF or ACC	9 – 16 V
					ON	0 – 0.5 V
71 (G)	Ground	Driver door request switch	Input	Driver door re- quest switch	ON (Pressed)	0 – 1.5 V
					OFF (Not pressed)	9 – 16 V
72 (SB)	Ground	Passenger door re- quest switch	Input	Passenger door request switch	ON (Pressed)	0 – 1.5 V
					OFF (Not pressed) <div style="text-align: right;">  <p style="font-size: small; margin-top: 5px;">JPMA0016GB</p> </div>	





BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
75 (BR)	Ground	Combination switch INPUT 5	Input	Combination switch	All switches OFF  1.4 V
					Front fog lamp switch ON  1.3 V
					Any of the condition below with all switches OFF • INT VOLUME 1 • INT VOLUME 2 • INT VOLUME 6 • INT VOLUME 7 NOTE: "INT VOLUME" in "DATA MONITOR" mode of "BCM" using CONSULT.  1.3 V

BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
		Signal name	Input/ Output			
+	-					
76 (BG)	Ground	Combination switch INPUT 4	Input	Combination switch	All switches OFF	 1.4 V
					Lighting switch AUTO	 1.3 V
					Lighting switch 1ST	 1.3 V
					Any of the condition below with all switches OFF	 1.3 V
					<ul style="list-style-type: none"> • INT VOLUME 1 • INT VOLUME 5 • INT VOLUME 6 <p>NOTE: "INT VOLUME" in "DATA MONITOR" mode of "BCM" using CONSULT.</p>	





A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P






BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
77 (V)	Ground	Combination switch INPUT 3	Input	Combination switch	All switches OFF  1.4 V
					Lighting switch HI  1.3 V
					Lighting switch 2ND  1.3 V
					Any of the condition below with all switches OFF • INT VOLUME 1 • INT VOLUME 2 • INT VOLUME 3 NOTE: "INT VOLUME" in "DATA MONITOR" mode of "BCM" using CONSULT.  1.3 V

BCM

< ECU DIAGNOSIS INFORMATION >






Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
78 (Y)	Ground	Combination switch INPUT 2	Input	Combination switch	All switches OFF <div style="text-align: right;">  <p>1.4 V</p> </div>
					Lighting switch PASS <div style="text-align: right;">  <p>1.3 V</p> </div>
					Lighting switch 2ND <div style="text-align: right;">  <p>1.3 V</p> </div>
					Front wiper switch INT/ AUTO <div style="text-align: right;">  <p>1.3 V</p> </div>
					Front wiper switch HI <div style="text-align: right;">  <p>1.3 V</p> </div>

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
79 (LG)	Ground	Combination switch INPUT 1	Input	Combination switch	All switches OFF	 <p style="text-align: right; margin-right: 50px;">JPMIA0041GB</p> <p style="text-align: center;">1.4 V</p>
					Turn signal switch LH	 <p style="text-align: right; margin-right: 50px;">JPMIA0037GB</p> <p style="text-align: center;">1.3 V</p>
					Turn signal switch RH	 <p style="text-align: right; margin-right: 50px;">JPMIA0036GB</p> <p style="text-align: center;">1.3 V</p>
					Front wiper switch LO	 <p style="text-align: right; margin-right: 50px;">JPMIA0038GB</p> <p style="text-align: center;">1.3 V</p>
					Front washer switch ON	 <p style="text-align: right; margin-right: 50px;">JPMIA0039GB</p> <p style="text-align: center;">1.3 V</p>
80 (L)	Ground	Trunk lid opener switch	Input	Trunk lid opener switch	ON (Pressed)	0 - 1.5 V
					OFF (Not pressed)	9 - 16 V

BCM

< ECU DIAGNOSIS INFORMATION >





Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
82 (W)	Ground	Rear LH door switch	Input	Rear LH door switch	<p style="text-align: right;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
					OFF (When rear LH door closed)
83 (L)	Ground	Trunk lid opener request switch	Input	Trunk lid opener request switch	<p style="text-align: right;">JMMIA1408GB</p>
					ON (Pressed)
85 (P)	Ground	Trunk room lamp control	Output	Trunk room lamp	<p>OFF</p> <p>ON</p> <p style="text-align: center;">9 - 16 V</p> <p style="text-align: center;">0 - 1 V</p>
					OFF (Actuator is not activated)
91 (GR)	Ground	Trunk lid open	Output	Trunk lid	<p>OFF (Actuator is not activated)</p> <p>OPEN (Actuator is activated)</p> <p style="text-align: center;">0 V</p> <p style="text-align: center;">9 - 16 V</p>
					Turn signal switch OFF
92 (W)	Ground	Turn signal RH output (Side and rear)	Output	Ignition switch ON	<p style="text-align: right;">PKID0926E</p> <p style="text-align: center;">6.5 V</p> <p style="text-align: center;">(Turn signal lamp turn on: 9 - 16 V)</p>
					Turn signal switch RH
93 (G)	Ground	Rear RH door switch	Input	Rear RH door switch	<p style="text-align: right;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
					OFF (When rear RH door closed)
				ON (When rear door RH opened)	0 V

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
94 (GR)	Ground	Passenger door switch	Input	Passenger door switch	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
				OFF (When passenger door closed)	ON (When passenger door opened)
96 (V)	Ground	Driver door switch	Input	Driver door switch	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
				OFF (When driver door closed)	ON (When driver door opened)
97 (R)	Ground	Trunk room lamp switch	Input	Trunk room lamp switch	 <p style="text-align: right; font-size: small;">JPMIA0011GB</p> <p style="text-align: center;">11.8 V</p>
				OFF (When trunk lid closed)	ON (When trunk lid opened)
99 (GR)	Ground	Inside key antenna (Trunk room) (-)	Output	Ignition switch ON and any door is open	 <p style="text-align: right; font-size: small;">JSMIA1413GB</p>
				When Intelligent Key is not in the antenna detection area	When Intelligent Key is in the antenna detection area

BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
100 (W)	Ground	Inside key antenna (Trunk room) (+)	Output	Ignition switch ON and any door is open	
				When Intelligent Key is in the antenna detection area	
101 (BG)	Ground	Rear bumper anten- na (-)	Output	When pressing the trunk lid opener request switch with all doors are locked and igni- tion switch OFF	
				When Intelligent Key is in the antenna detection area	
102 (LG)	Ground	Rear bumper anten- na (+)	Output	When pressing the trunk lid opener request switch with all doors are locked and igni- tion switch OFF	
				When Intelligent Key is in the antenna detection area	





A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
103 (Y)	Ground	Turn signal LH out- put (Side and rear)	Output	Ignition switch ON	0 V
				Turn signal switch OFF	 <p style="text-align: right; font-size: small;">PKID0926E</p> 6.5 V (Turn signal lamp turn on: 9 - 16 V)
105 (V)	Ground	Turn signal RH out- put (Front)	Output	Ignition switch ON	0 V
				Turn signal switch OFF	 <p style="text-align: right; font-size: small;">PKID0926E</p> 6.5 V (Turn signal lamp turn on: 9 - 16 V)
107 (P)	Ground	Push-button ignition switch illumination ground	Input	Ignition switch ON	0 V
111 (Y)	Ground	ACC/ON indicator lamp	Output	Ignition switch	OFF
				ACC or ON	9 - 16 V
113 (SB)	Ground	Accessory relay control	Output	Ignition switch	OFF
				ACC or ON	0 - 1.5 V
114 (LG)	Ground	Passenger door an- tenna (+)	Output	When pressing the front door request switch (passenger side) with all doors are locked and igni- tion switch OFF	 <p style="text-align: right; font-size: small;">JSMIA1506GB</p>
				When Intelligent Key is not in the antenna detec- tion area	 <p style="text-align: right; font-size: small;">JSMIA1507GB</p>

BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
115 (V)	Ground	Passenger door antenna (-)	Output	When pressing the front door request switch (passenger side) with all doors are locked and ignition switch OFF	
				When Intelligent Key is in the antenna detection area	
116 (BR)	Ground	Inside key antenna (Console) (+)	Output	When Intelligent Key is not in the antenna detection area	
				When Intelligent Key is in the antenna detection area	
117 (W/B)	Ground	Turn signal LH output (Front)	Output	Turn signal switch OFF	0 V
				Turn signal switch ON	<p style="text-align: center;">6.5 V (Turn signal lamp turn on: 9 - 16 V)</p>

A
B
C
D
E
F
G
H
I
J
K
L
BCS
N
O
P

BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
119 (L)	Ground	Remote keyless entry receiver communication	Input	Ignition switch ON	Waiting	<p style="text-align: right; font-size: small;">JMMIA1409GB</p>
					When operating either button on Intelligent Key	<p style="text-align: right; font-size: small;">JMMIA1410GB</p>
121 (SB)	Ground	Driver door antenna (-)	Output	When pressing the front door request switch (driver side) with all doors are locked and ignition switch OFF	When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JSMIA1506GB</p>
					When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JSMIA1507GB</p>
122 (BG)	Ground	Driver door antenna (+)	Output	When pressing the front door request switch (driver side) with all doors are locked and ignition switch OFF	When Intelligent Key is not in the antenna detection area	<p style="text-align: right; font-size: small;">JSMIA1506GB</p>
					When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JSMIA1507GB</p>

BCM

< ECU DIAGNOSIS INFORMATION >



Terminal No. (Wire color)		Description		Condition	Value (Approx.)	
+	-	Signal name	Input/ Output			
123 (R)	Ground	Inside key antenna (Instrument lower) (+)	Output	Ignition switch ON and any door is open	<p style="text-align: right; font-size: small;">JSMIA1348GB</p>	
				When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JSMIA1406GB</p>	
124 (G)	Ground	Inside key antenna (Instrument lower) (-)	Output	Ignition switch ON and any door is open	<p style="text-align: right; font-size: small;">JSMIA1413GB</p>	
				When Intelligent Key is in the antenna detection area	<p style="text-align: right; font-size: small;">JSMIA1414GB</p>	
126 (B)	Ground	NATS antenna amp.	Input/ Output	Intelligent Key: Intelligent Key battery is re- moved	Brake pedal: Depressed	<p style="text-align: right; font-size: small;">JSKIA3178ZZ</p>
127 (W)	Ground	NATS antenna amp.	Input/ Output	Intelligent Key: Intelligent Key battery is re- moved	Brake pedal: Depressed	<p style="text-align: right; font-size: small;">JSMIA1415GB</p>

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
128 (GR)	Ground	Inside key antenna (Console) (-)	Output	Ignition switch ON and any door is open	When Intelligent Key is not in the antenna detec- tion area	 JSMIA1413GB
					When Intelligent Key is in the antenna detection area	 JSMIA1414GB
129 (LG)	Ground	Interior room lamp power supply	Output	Interior room lamp battery saver is activated. (Cuts the interior room lamp power supply)	0 V	
				Interior room lamp battery saver is not acti- vated. (Outputs the interior room lamp power sup- ply)	9 – 16 V	
130 (P)	Ground	Passenger door UN- LOCK	Output	Passenger door	UNLOCK (Actuator is acti- vated)	9 – 16 V
					Other then UNLOCK (Actu- ator is not activated)	0 V
131 (Y)	Ground	Battery power sup- ply	Input	Ignition switch OFF	9 – 16 V	
132 (V)	Ground	Rear door LH/RH LOCK	Output	Rear door LH/ RH	LOCK (Actuator is activat- ed)	9 – 16 V
					Other then LOCK (Actua- tor is not activated)	0 V
133 (BR)	Ground	Rear door LH/RH UNLOCK	Output	Rear door LH/ RH	UNLOCK (Actuator is acti- vated)	9 – 16 V
					Other then UNLOCK (Actu- ator is not activated)	0 V
134 (B)	Ground	Ground	Output	Ignition switch OFF	0 V	
135 (V)	Ground	Front doors and fuel lid LOCK	Output	Front doors and fuel lid	LOCK (Actuator is activat- ed)	9 – 16 V
					Other then LOCK (Actua- tor is not activated)	0 V
136 (V)	Ground	Interior room lamp control	Output	Map lamp and personal lamp (Door position)	When all doors are closed (Interior room lamp is turned OFF)	0 V
					Any doors opens (Interior room lamp is turned ON)	9 – 16 V
137 (LG)	Ground	Driver door and fuel lid UNLOCK	Output	Driver door and fuel lid	UNLOCK (Actuator is acti- vated)	9 – 16 V
					Other then UNLOCK (Actu- ator is not activated)	0 V

BCM

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
138 (R)*3 (P)*4	Ground	Rear doors lock actuator power supply	Input	Ignition switch ON	9 – 16 V
139 (W)	Ground	Battery power supply (F/L)	Input	Ignition switch OFF	9 – 16 V
140 (BR)	Ground	Ignition switch ON	Output	Ignition switch OFF	0 V
				Within 45 second after ignition switch is turned OFF	9 – 16 V
				Ignition switch ON	
141 (R)	Ground	Power supply (BAT)	Output	Ignition switch OFF	9 – 16 V
142 (R)	Ground	Front door and fuel filler lid lock actuator power supply	Input	Ignition switch ON	9 – 16 V
143 (B)	Ground	Ground	Output	Ignition switch OFF	0 V

*1: This harness is connected but not used.

*2: For Canada

*3: For 2.0L turbo gasoline engine models

*4: Except for 2.0L turbo gasoline engine models

Fail-safe

INFOID:000000012792464

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

Display contents of CONSULT	Fail-safe
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking
B2195: ANTI-SCANNING	Inhibit engine cranking
B2198: NATS ANTENNA AMP	Inhibit engine cranking
B219B: ID DISCORD SVT-BCM	Inhibit engine cranking
B2608: STARTER RELAY	Inhibit engine cranking
B260F: ENG STATE SIG LOST	Inhibit engine cranking
B261B: RES ENG RUN STUCK MALFNC	Fuel cut
B26F1: IGN RELAY OFF	Inhibit engine cranking
B26F2: IGN RELAY ON	Inhibit engine cranking
B26F3: START CONT RLY ON	Inhibit engine cranking
B26F4: START CONT RLY OFF	Inhibit engine cranking
B26F7: BCM	Inhibit engine cranking by Intelligent Key system
B26FE: HOOD SW CAN DIAG ERROR	Inhibit remote engine start

FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

BCM detects the rain sensor serial link error and the rain sensor malfunction.

BCM controls the following fail-safe when rain sensor has a malfunction.

- Front wiper switch AUTO and sensing rain drop: The condition just before the activation of fail-safe is maintained until the front wiper switch is turned OFF.
- Front wiper switch AUTO and not sensing rain drop: Front wiper is LO operation until the front wiper switch is turned off.

BCM

< ECU DIAGNOSIS INFORMATION >

FAIL-SAFE CONTROL OF COMBINATION SWITCH READING FUNCTION CAUSED BY LOW POWER SUPPLY VOLTAGE

If voltage of battery power supply lower, BCM maintains combination switch reading to the status when input voltage is less than approximately 9 V.

NOTE:

When voltage of battery power supply is approximately 9 V or more, combination switch reading function returns to normal operation.

DTC Inspection Priority Chart

INFOID:000000012792465

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC
1	B2562: LOW VOLTAGE
2	<ul style="list-style-type: none"> • U1000: CAN COMM • U1010: CONTROL UNIT (CAN)
3	<ul style="list-style-type: none"> • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI-SCANNING • B2196: DONGLE NG • B2198: NATS ANTENNA AMP • B219B: ID DISCORD SVT-BCM • B261B: RES ENG RUN STUCK MALFNC • B26FE: HOOD SW CAN DIAG ERROR
4	<ul style="list-style-type: none"> • B2555: STOP LAMP • B2556: PUSH-BTN IGN SW • B2557: VEHICLE SPEED • B2601: SHIFT POSITION • B2602: SHIFT POSITION • B2603: SHIFT POSI STATUS • B2604: PNP/CLUTCH SW • B2605: PNP/CLUTCH SW • B2608: STARTER RELAY • B260F: ENG STATE SIG LOST • B2614: BCM • B2615: BCM • B2616: BCM • B2618: BCM • B261A: PUSH-BTN IGN SW • B261E: VEHICLE TYPE • B26F1: IGN RELAY OFF • B26F2: IGN RELAY ON • B26F3: START CONT RLY ON • B26F4: START CONT RLY OFF • B26F6: BCM • B26F7: BCM • B26F8: BCM • B26FC: KEY REGISTRATION • B26FF: INTELLIGENT TUNER COMM ERROR • U0415: VEHICLE SPEED
5	<ul style="list-style-type: none"> • B2621: INSIDE ANTENNA • B2622: INSIDE ANTENNA • B2623: INSIDE ANTENNA
6	<ul style="list-style-type: none"> • B259A: ROOM LAMP FUSE BLOWN • B259B: DR TOUCH SENSOR • B259C: PASS TOUCH SENSOR • B2626: OUTSIDE ANTENNA • B2627: OUTSIDE ANTENNA • B2628: OUTSIDE ANTENNA

BCM

< ECU DIAGNOSIS INFORMATION >

DTC Index

INFOID:000000012792466

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

IGN counter is displayed on Freeze Frame Data. For details of Freeze Frame Data, refer to [BCS-17, "COMMON ITEM : CONSULT Function \(BCM - COMMON ITEM\)"](#).

x:Applicable

CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning display	Security indicator lamp ON	Reference
No DTC is detected. Further testing may be required.	—	—	—	—	—
U1000: CAN COMM	—	—	—	—	BCS-86
U1010: CONTROL UNIT (CAN)	—	—	—	—	BCS-87
U0415: VEHICLE SPEED	—	—	x	—	BCS-88
B2192: ID DISCORD BCM-ECM	x	—	—	x	SEC-101
B2193: CHAIN OF BCM-ECM	x	—	—	x	SEC-102
B2195: ANTI-SCANNING	x	—	—	x	SEC-104
B2196: DONGLE NG	x	—	—	—	SEC-105
B2198: NATS ANTENNA AMP	x	—	—	x	SEC-107
B219B: ID DISCORD SVT-BCM	x	—	—	x	SEC-153
B2555: STOP LAMP	—	x	x	—	SEC-109
B2556: PUSH-BTN IGN SW	—	x	x	—	SEC-112
B2557: VEHICLE SPEED	x	x	x	—	SEC-114
B2562: LOW VOLTAGE	—	x	—	—	BCS-89
B259A: ROOM LAMP FUSE BLOWN	—	—	—	—	BCS-90
B259B: DR TOUCH SENSOR	—	x	—	—	DLK-83
B259C: PASS TOUCH SENSOR	—	x	—	—	DLK-85
B2601: SHIFT POSITION	x	x	x	—	SEC-116
B2602: SHIFT POSITION	x	x	x	—	SEC-118
B2603: SHIFT POSI STATUS	x	x	x	—	SEC-121
B2604: PNP/CLUTCH SW	x	x	x	—	SEC-125
B2605: PNP/CLUTCH SW	x	x	x	—	SEC-128
B2608: STARTER RELAY	x	x	x	—	SEC-131
B260F: ENG STATE SIG LOST	x	x	x	—	SEC-133
B2614: BCM	—	x	x	—	PCS-81
B2615: BCM	—	x	x	—	PCS-84
B2616: BCM	—	x	x	—	PCS-87
B2618: BCM	—	x	x	—	PCS-90
B261A: PUSH-BTN IGN SW	—	x	x	—	PCS-92
B261B: RES ENG RUN STUCK MALFNC	x	x	x	—	SEC-155
B2621: INSIDE ANTENNA	—	x	—	—	DLK-87
B2622: INSIDE ANTENNA	—	x	—	—	DLK-90
B2623: INSIDE ANTENNA	—	x	—	—	DLK-93

BCM

< ECU DIAGNOSIS INFORMATION >


CONSULT display	Fail-safe	Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition	Intelligent Key warning display	Security indicator lamp ON	Reference
B2626: OUTSIDE ANTENNA	—	×	—	—	DLK-96
B2627: OUTSIDE ANTENNA	—	×	—	—	DLK-98
B2628: OUTSIDE ANTENNA	—	×	—	—	DLK-100
B26F1: IGN RELAY OFF	×	×	×	—	PCS-94
B26F2: IGN RELAY ON	×	×	×	—	PCS-96
B26F3: START CONT RLY ON	×	×	×	—	SEC-135
B26F4: START CONT RLY OFF	×	×	×	—	SEC-137
B26F6: BCM	—	×	×	—	PCS-98
B26F7: BCM	×	×	×	—	SEC-139
B26F8: BCM	—	×	×	—	SEC-140
B26FC: KEY REGISTRATION	—	×	×	—	SEC-141
B26FE: HOOD SW CAN DIAG ERROR	×	×	×	—	SEC-141
B26FF: INTELLIGENT TUNER COMM ERROR	—	×	×	—	DLK-102

WIRING DIAGRAM

BCM

Wiring Diagram

INFOID:000000012792467



*: This connector is not shown in "Harness Layout".

2016/02/15


JRMWJ4645GB

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM


< WIRING DIAGRAM >



JRMWJ4646GB

BCM

< WIRING DIAGRAM >




JRMWJ4647GB

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM


< WIRING DIAGRAM >



JRMWJ4648GB

BCM

< WIRING DIAGRAM >



JRMWJ4649GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCS

BCM (BODY CONTROL MODULE)

Connector No.	B22
Connector Name	REAR COMBINATION LAMP (RH/BODY SIDE)
Connector Type	NSD4MW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	P	-
3	SB	-
4	B	-

Connector No.	B23
Connector Name	REAR COMBINATION LAMP (RH/BODY SIDE)
Connector Type	NSD4MW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	R	-
3	V	-
4	B	-

Connector No.	B42
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	V	-

Connector No.	B44
Connector Name	REAR DOOR SWITCH LH
Connector Type	TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	W	-

Connector No.	B67
Connector Name	TRUNK ROOM LAMP
Connector Type	S02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
2	GR	-

Connector No.	B70
Connector Name	FRONT DOOR SWITCH (PASSENGER SIDE)
Connector Type	TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	GR	-

Connector No.	B71
Connector Name	INSIDE KEY ANTENNA (TRUNK ROOM)
Connector Type	RK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	ANT+
2	GR	ANT-

Connector No.	B76
Connector Name	FUEL FILLER LID LOCK ACTUATOR
Connector Type	MD4FW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	GR	-

Connector No.	B78
Connector Name	REAR DOOR SWITCH RH
Connector Type	TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	R	-


BCM (BODY CONTROL MODULE)

Connector No.	B95
Connector Name	OUTSIDE KEY ANTENNA (REAR BUMPER)
Connector Type	RK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	ANT+
2	GR	ANT-

Connector No.	B97
Connector Name	PRE-CHAIR SEAT BELT CONTROL UNIT (DRIVER SIDE)
Connector Type	NH18FW-CSZ



Terminal No.	Color Of Wire	Signal Name [Specification]
2	G	OUT_1
4	R	CAN_LO
6	W	BACKLE SW LH_NO
10	R	SENS_TOWER
12	B	OUT_2
14	L	CAN_HI
16	Y	LOCAL_COMM_1
17	W	SENS_GND
19	BR	MOTOR_BAT [With 2.0L turbo gasoline engine]
19	Y	MOTOR_BAT [With V160 engine]
20	B	MOTOR_GND

Connector No.	B151
Connector Name	IGNITION RELAY
Connector Type	MS02FL-M2-4C



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	R	-
5	LG	-

Connector No.	B601
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH32FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
2	BR	LMRT (TX/RX)
3	B	START SW
4	B	PULSE (RECLINER)
5	V	PULSE (TELESCOPIC)
9	GY	ADDRESS 2
7	G	IND 2
8	V	SLIDE SW (BACKWARD)
9	W	RECLINER SW (BACKWARD)
10	O	TEL SW (DOWNWARD)
11	G	LIFTER SW (DOWNWARD)
12	SB	POWER SUPPLY (ENCODER)
17	P	CAN-L
18	LG	PULSE (SLIDE SENSOR)
19	W	PULSE (LIFTER FRONT)
20	GY	PULSE (LIFTER REAR)

21	SB	PULSE (TILT SENSOR)
22	O	ADDRESS 1
23	W	IND 1
24	P	SLIDE SW (FORWARD)
25	Y	RECLINER SW (FORWARD)
26	GY	TILT SW (UPWARD)
27	L	LIFTER SW (UPWARD)
28	Y	SET SW

Connector No.	B614
Connector Name	POWER SEAT SWITCH
Connector Type	HS10FW-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
33	-	-
34	-	-
35	-	-
36	-	-
38	-	-
39	-	-
40	-	-
41	-	-
42	-	-
43	-	-

Connector No.	D1
Connector Name	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)
Connector Type	ED6FGY-4S



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	LG	-
3	W	-
4	B	-
5	Y	-
6	V	-

Connector No.	D3
Connector Name	DOOR MIRROR (DRIVER SIDE)
Connector Type	TH2AMW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	-
3	G	-
5	B	-
6	W	-
7	L	-
10	Y	-
11	GR	-
12	L	-
14	B	-
17	SHIELD	-
18	R	-
19	B	-

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P



JRMWJ4651GB


BCM (BODY CONTROL MODULE)

Connector No.	D5
Connector Name	FRONT OUTSIDE MIRROR ASSEMBLY (DRIVER SIDE)
Connector Type	RH04FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	B	-
3	BR	-
4	GR	-

Connector No.	D8
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3	V	ENCODER POWER SUPPLY
4	V	IGNITION POWER SUPPLY
5	G	FRONT POWER WINDOW MOTOR (DRIVER SIDE) DOWN SIGNAL
6	L	FRONT POWER WINDOW MOTOR (DRIVER SIDE) UP SIGNAL
7	B	GROUND
9	BR	BATTERY POWER SUPPLY
10	B	ENCODER GROUND
11	GR	ENCODER SIGNAL 1
12	BR	ENCODER SIGNAL 2
13	SB	POWER WINDOW SERIAL LINK
15	V	DOOR KEY CYLINDER SWITCH LOCK SIGNAL
16	Y	DOOR KEY CYLINDER SWITCH UNLOCK SIGNAL

Connector No.	D10
Connector Name	FRONT ONE TOUCH UNLOCK SENSOR ASSEMBLY (PASSENGER SIDE)
Connector Type	RH04FLGY




Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	R	-
3	B	-
4	L	-

Connector No.	D16
Connector Name	STEP LAMP (DRIVER SIDE)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	Y	-

Connector No.	D17
Connector Name	DOOR MIRROR (PASSENGER SIDE)
Connector Type	TH24MW-AH




Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	-
3	W	-
5	B	-
6	R	-
7	BS	-
10	G	-
11	V	-
12	Y	-
14	B	-
17	SHIELD	-
18	G	-
19	B	-

Connector No.	D19
Connector Name	FRONT OUTSIDE MIRROR ASSEMBLY (PASSENGER SIDE)
Connector Type	RH04FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	B	-
3	BR	-
4	GR	-

Connector No.	D21
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	ENCODER GROUND
4	V	ENCODER POWER SUPPLY
8	L	FRONT POWER WINDOW MOTOR (PASSENGER SIDE) UP SIGNAL
9	G	FRONT POWER WINDOW MOTOR (PASSENGER SIDE) DOWN SIGNAL
10	Y	IGNITION POWER SUPPLY
11	B	GROUND
12	GR	ENCODER SIGNAL 1
15	BR	ENCODER SIGNAL 2
16	GR	POWER WINDOW SERIAL LINK

Connector No.	D22
Connector Name	FRONT ONE TOUCH UNLOCK SENSOR ASSEMBLY (PASSENGER SIDE)
Connector Type	RH04FLGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	R	-
3	B	-
4	L	-

BCM (BODY CONTROL MODULE)

Connector No.	D28
Connector Name	FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE)
Connector Type	ED6FGY-RS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	P	-



Connector No.	D30
Connector Name	STEP LAMP (PASSENGER SIDE)
Connector Type	TB0ZFW

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	Y	-

Connector No.	D33
Connector Name	REAR POWER WINDOW SWITCH LH
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3	BR	ENCODER GROUND
4	SB	ENCODER POWER SUPPLY
8	R	REAR POWER WINDOW MOTOR LH UP SIGNAL
9	L	REAR POWER WINDOW MOTOR LH DOWN SIGNAL
10	W	IGNITION POWER SUPPLY
11	B	GROUND
12	GR	ENCODER SIGNAL 1
15	BG	ENCODER SIGNAL 2
16	Y	POWER WINDOW SERIAL LINK

Connector No.	D37
Connector Name	REAR DOOR LOCK ASSEMBLY LH
Connector Type	ED6FGY-RS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	BR	-
5	V	-
6	BR	-

Connector No.	D43
Connector Name	REAR POWER WINDOW SWITCH RH
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3	V	ENCODER GROUND
4	SB	ENCODER POWER SUPPLY
8	R	REAR POWER WINDOW MOTOR RH UP SIGNAL
9	L	REAR POWER WINDOW MOTOR RH DOWN SIGNAL
10	W	IGNITION POWER SUPPLY
11	B	GROUND
12	GR	ENCODER SIGNAL 1
15	BG	ENCODER SIGNAL 2
16	Y	POWER WINDOW SERIAL LINK

Connector No.	D46
Connector Name	REAR DOOR LOCK ASSEMBLY RH
Connector Type	ED6FGY-RS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	V	-
5	BR	-
6	V	-

Connector No.	D56
Connector Name	DOOR MIRROR (DRIVER SIDE)
Connector Type	TH24MW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	R	-
3	G	-
5	B	-
6	W	-
7	L	-
8	SB	-
9	P	-
10	Y	-
11	GR	-
12	BG	-
13	V	-
14	B	-
17	SHIELD	-
18	R	-
19	B	-
21	BR	-
22	LG	-
23	W	-
24	G	-

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

JRMWJ4653GB

BCM (BODY CONTROL MODULE)


Connector No.	D57
Connector Name	DOOR MIRROR (PASSENGER SIDE)
Connector Type	TH24M/W-NH



Connector No.	E17
Connector Name	FRONT TURN SIGNAL LAMP LH
Connector Type	RH02FB



Connector No.	E35
Connector Name	ABS MOTOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	SAZ30FB-SIZ4-U



Connector No.	E45
Connector Name	INTELLIGENT KEY WARNING BUZZER
Connector Type	RK03FER



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	R	-
3	W	-
5	B	-
6	R	-
7	BG	-
8	LG	-
9	SB	-
10	G	-
11	V	-
12	Y	-
13	Y	-
14	B	-
17	SHIELD	-
18	G	-
19	B	-
21	P	-
22	BR	-
23	W	-
24	GR	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	B	-

Connector No.	E18
Connector Name	FRONT TURN SIGNAL LAMP RH
Connector Type	RH02FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GND
2	B	GND
3	G	VALVE BATTERY [With VRS0 engine]
3	P	VALVE BATTERY [With 2.0L turbo gasoline engine]
4	Y	MOTOR BATTERY
5	LG	STOP LAMP SW SIGNAL [With ADAS]
5	V	STOP LAMP SW SIGNAL [With ASCD]
7	GR	RR LH WHEEL SENSOR SIGNAL
8	G	RR LH WHEEL SENSOR POWER SUPPLY
9	BR	FR RH WHEEL SENSOR SIGNAL
10	GR	FR RH WHEEL SENSOR POWER SUPPLY
13	R	VACUUM SENSOR SIGNAL
15	P	CAN-L [Without Gateway]
15	R	CAN-L [With Gateway]
17	Y	RR RH WHEEL SENSOR SIGNAL
18	LG	RR RH WHEEL SENSOR POWER SUPPLY [With VRS0 engine]
18	V	RR RH WHEEL SENSOR POWER SUPPLY [With VRS0 engine]
19	SB	FR LH WHEEL SENSOR SIGNAL
20	BG	FR LH WHEEL SENSOR POWER SUPPLY
25	L	CAN-H
28	G	VACUUM SENSOR POWER SUPPLY
30	R	VDC OFF SW SIGNAL
32	SHIELD	VACUUM SENSOR GROUND
34	G	IGN

Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	(JBAT)
3	BG	BUZZER SIGNAL [With VRS0 engine]
3	LG	BUZZER SIGNAL [With 2.0L turbo gasoline engine]

Connector No.	E57
Connector Name	STOP LAMP SWITCH
Connector Type	MDHFV-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B	-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	- [With ASCD]
1	L	- [With ADAS]
2	GR	- [With ASCD]
2	LG	- [With ADAS]
3	BR	-
4	V	-

BCM (BODY CONTROL MODULE)

Connector No.	E64
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS08FW-CS



Terminal No.	Color Of Wire	Signal Name (Specification)
1E	G	-
2E	P	-
3E	V	-
4E	GR	-
6E	L	-
7E	BG	-

Connector No.	E65
Connector Name	FUSE BLOCK (J/B)
Connector Type	TH12FW-NH




Terminal No.	Color Of Wire	Signal Name (Specification)
10E	W	-
11E	G	(Color of wire differs depending on production)
12E	R	(Color of wire differs depending on production)
12F	W	- (With VR30 engine)
1E	R	- (With 2.0L turbo gasoline engine)
2F	BR	-
3F	P	-
5F	P	-
6F	L	-
7F	R	-
8F	L	-
9F	L	-

Connector No.	E120
Connector Name	IPDM (R) INTELLIGENT POWER DISTRIBUTION MODULE ENGINE (BODY)
Connector Type	NS12FW-CS



Terminal No.	Color Of Wire	Signal Name (Specification)
7	B/W	-
9	P	-
10	LG	-
11	V	-
13	BG	-
14	SB	-
15	BR	-
17	GR	-
18	L	-

Connector No.	E121
Connector Name	IPDM (R) INTELLIGENT POWER DISTRIBUTION MODULE ENGINE (BODY)
Connector Type	TH32FW-AH



Terminal No.	Color Of Wire	Signal Name (Specification)
19	L	- (With 2.0L turbo gasoline engine)
19	P	- (With VR30 engine)
22	BG	-
23	GR	- (With VR30 engine)
23	LG	- (With 2.0L turbo gasoline engine and without start theft mode)
27	GR	-
28	P	-
29	L	-
31	G	-
32	SB	-

33	SB	-
34	Y	-
35	G	-
36	SB	- (With VR30 engine)
36	W	- (With 2.0L turbo gasoline engine)
37	GR	-
38	BR	-
41	GR	-
43	V	-

Connector No.	F2
Connector Name	A/T ASSEMBLY
Connector Type	RK10FG-D6Y



Terminal No.	Color Of Wire	Signal Name (Specification)
1	GR	IGNITION POWER SUPPLY (With 2.0L turbo gasoline engine)
1	L	IGNITION POWER SUPPLY (With VR30 engine)
2	P	BATTERY POWER SUPPLY (MEMORY BACK-UP)
3	L	CAN-H
4	R	K-LINE
5	B	GROUND (With 2.0L turbo gasoline engine)
5	BR	GROUND (With VR30 engine)
6	GR	IGNITION POWER SUPPLY
7	BG	BACK-UP LAMP RELAY
8	P	CAN-L
9	V	STARTER RELAY
10	B	GROUND

Connector No.	F100
Connector Name	TCM
Connector Type	SP10FG



Terminal No.	Color Of Wire	Signal Name (Specification)
1	-	IGNITION POWER SUPPLY
2	-	BATTERY POWER SUPPLY (MEMORY BACK-UP)
3	-	CAN-H
4	-	K-LINE
5	-	GROUND
6	-	IGNITION POWER SUPPLY
7	-	BACK-UP LAMP RELAY
8	-	CAN-L
9	-	STARTER RELAY
10	-	GROUND

Connector No.	M1
Connector Name	INTEGRAL SWITCH
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name (Specification)
2	R	ILLUMINATION SIGNAL
3	LG	AV COMM (L)
4	SB	AV COMM (H)
7	W/B	DISK EJECT SIGNAL
8	G	HAZARD SIGNAL
13	B	GND
14	SB	ACC (For 2.0L turbo gasoline engine)
14	V	ACC (For VR30 engine)
15	B	ILLUMINATION CONTROL SIGNAL
16	BG	DISK EJECT SIGNAL GROUND


A
B
C
D
E
F
G
H
I
J
K
L
N
O
P




BCM (BODY CONTROL MODULE)

18	R	IGN [For VR30 engine]
18	W	IGN [For 2.0L turbo gasoline engine]
19	BR	CAMERA SWITCH SIGNAL
20	LG	AIR BAG INDICATOR OFF SIGNAL

Connector No.	M15
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	NH28FYEX



Connector No.	M7
Connector Name	A/T SHIFT SELECTOR
Connector Type	TH12FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	-
2	GR	-
3	BG	-
4	B	-
5	G	-
7	R	-
8	P	- [With VR30 engine]
8	V	- [With 2.0L turbo gasoline engine]
9	B	-
10	GR	-
11	R	-


Connector No.	M13
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	PUSH SW
3	Y	SENS PWR SPLY
4	BG	OPTICAL SENSOR
5	LG	-
10	W	COMBI SW OUTPUT 5
11	SB	COMBI SW OUTPUT 4
12	L	COMBI SW OUTPUT 3
13	G	COMBI SW OUTPUT 2
14	P	COMBI SW OUTPUT 1

15	G	ONE TOUCH UNLK SENS (DR)
16	G	ONE TOUCH UNLK SENS (PASS)
17	P	RECEIVER/SENSOR GND
18	L	SECURITY IND LAMP CONT
20	R	DETENT SW
21	SB	STEP LAMP CONT
25	R	STOP LAMP SW2
26	R	EXTENDED STORAGE FUSE SW
27	P	STOP LAMP SW
30	W	DR DOOR UNLK SENS
32	V	TR LID OP CANCEL SW
36	G	H24RD SW
39	BR	7/R POSITION


Connector No.	M14
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
48	R	PUSH BTN IGN SW ILL PWR
52	G	DONGLE LINK
54	V	COMMI LINE
55	R	RAIN SENSOR
59	P	CAN-L
61	G	CAN-H
62	R	REAR WINDOW DEF RLY CONT
64	V	STARTER RLY CONT
64	V	1 KEY WARN BUZZER
65	B	OUTS HD LAMP CONT
66	B	BLOWER FAN RLY CONT [With VR30 engine]
66	V	BLOWER FAN RLY CONT [With gasoline engine]
67	W/B	IGN RLYACT (7/8) CONT
68	R	DIMMER
69	GR	A/T SHIFT SELECT PWR SPLY
70	B	IGN RLYACT (IPDM EFR) CONT
71	G	DR DOOR REC SW
72	SB	PASS DOOR REC SW
75	BR	COMBI SW INPUT 5
76	BG	COMBI SW INPUT 4
77	V	COMBI SW INPUT 3

78	Y	COMBI SW INPUT 2
79	LG	COMBI SW INPUT 1
80	L	TR LID OPNR SW

Connector No.	M15
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH24FGV-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
82	W	REAR LH DOOR SW
83	L	TR LID OPEN REQ SW
85	P	TR ROOM LAMP CONT
91	GR	TRUNK LID OPEN
92	W	TURN SIG RH OUTPUT (SIDE REAR)
93	G	REAR RH DOOR SW
94	GR	PASSENGER DOOR SW
96	V	DRIVER DOOR SW
97	R	TR ROOM LAMP SW
99	GR	INSIDE KEY ANT (TRUNK) -
100	W	INSIDE KEY ANT (TRUNK) +
101	BG	REAR BMRP ANT -
102	LG	REAR BMRP ANT +
103	Y	TURN SIG LH OUTPUT (SIDE REAR)


Connector No.	M15
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH24FB-NH



BCM (BODY CONTROL MODULE)

Terminal No.	Color Of Wire	Signal Name [Specification]
105	V	TURN SIG RH OUTPUT (FRONT)
107	P	PUSH-BTN IGN SW ILL GND
111	Y	ACC/ON IND
113	SB	ACC RELAY CONT
114	LG	PASSENGER DOOR ANT +
115	V	PASSENGER DOOR ANT -
116	BR	INSIDE KEY ANT (CONSOLE) +
117	W/B	TURN SIG LH OUTPUT (FRONT)
119	L	K15.5 EXT RECDY COMM
121	SB	DRIVER DOOR ANT -
122	BG	DRIVER DOOR ANT +
123	R	INSIDE KEY ANT (INSTRUMENT LOWER) +
124	G	INSIDE KEY ANT (INSTRUMENT LOWER) -
126	B	NATS ANT AMP
127	W	NATS ANT AMP
128	GR	INSIDE KEY ANT (CONSOLE) -


Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FHA6-5A



Terminal No.	Color Of Wire	Signal Name [Specification]
129	LG	INT ROOM LAMP PWR SPLY
130	P	PASS DOOR UNLK OUTPUT
131	Y	BAT (GUSE)
132	V	RR, RL DOOR LK OUTPUT
133	BR	RR, RL DOOR UNLK OUTPUT
134	B	GND
135	V	FRONT DOOR, FL LID, LL OUTPUT
136	V	INT ROOM LAMP-CONT
137	LG	FRONT DOOR, FL LID UNLK OUTPUT
138	P	REAR DOORS ACT PWR SPLY (With VRS0 engine)
139	W	BAT (FL)
140	BR	IGN ON
141	R	PWR SPLY (BAT)
142	R	FRONT DOORS, FL LID ACT PWR SPLY
143	B	GND




Connector No.	M24
Connector Name	CAN GATEWAY
Connector Type	TH12FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H [CAN COMMUNICATION CIRCUIT 1]
3	W	BATTERY POWER SUPPLY
4	L	CAN-H [CAN COMMUNICATION CIRCUIT 2]
5	B	GROUND
6	L	CAN-H [CAN COMMUNICATION CIRCUIT 2]
7	P	CAN-L [CAN COMMUNICATION CIRCUIT 1]
9	R	IGNITION POWER SUPPLY (except with VRS0 engine and without IS8)
10	R	CAN-L [CAN COMMUNICATION CIRCUIT 2]
11	B	GROUND
12	R	CAN-L [CAN COMMUNICATION CIRCUIT 2]

Connector No.	M25
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	M_CAN_L
4	B	EARTH
5	B	EARTH
6	L	CAN-H
7	V	KLINE (With 2.0L turbo gasoline engine)
8	W	IGN_SW
11	SB	M_CAN_H
12	R	CAN-L

13	L	CAN-H
14	P	CAN-L
16	W	POWER



Connector No.	M27
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	FR WASH MOTOR
2	SB	OUTPUT 4
5	L	OUTPUT 3
6	B	GND
7	V	INPUT 3
8	W	OUTPUT 5
9	Y	INPUT 2
10	BG	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M32
Connector Name	DONGLE UNIT
Connector Type	TH04FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	DATA&SV SUPPLY
4	B	GND

Connector No.	M38
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TH08FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	W	-
4	B	-
5	R	-
6	P	-
7	Y	-
8	BR	-

Connector No.	M51
Connector Name	NATS ANTENNA AMP
Connector Type	NH03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
3	B	-

BCM (BODY CONTROL MODULE)

Connector No.	M57
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
6	GR	STOP/START OFF SWITCH INDICATOR SIGNAL
7	G	SECURITY SIGNAL
8	B	-
11	W	ALTERNATOR SIGNAL
12	G	LED HEADLAMP (RH) WARNING SIGNAL
13	BR	LED HEADLAMP (LH) WARNING SIGNAL
14	V	ACC POWER SUPPLY
16	V	AIR BAG SIGNAL
17	BR	METER CONTROL SWITCH GROUND
18	SB	TRIP/RESET SIGNAL
21	B	STEERING SWITCH SIGNAL GROUND
22	P	STEERING SWITCH SIGNAL A
23	W/B	STEERING SWITCH SIGNAL B
24	L	WASHER LEVEL SWITCH SIGNAL
25	LG	BRAKE FLUID LEVEL SWITCH SIGNAL
26	V	PARKING BRAKE SWITCH SIGNAL
27	G	PASSENGER SEAT BELT WARNING SIGNAL
28	W	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
30	G	MANUAL MODE SIGNAL (WITH 2.0L turbo gasoline engine)
30	SB	MANUAL MODE SIGNAL (WITH VR30 engine)
31	G	NON-MANUAL MODE SIGNAL (WITH VR30 engine)
31	L	NON-MANUAL MODE SIGNAL (WITH 2.0L turbo gasoline engine)
32	BG	MANUAL MODE SHIFT UP SIGNAL
32	GR	MANUAL MODE SHIFT DOWN SIGNAL (WITH VR30 engine)
32	P	MANUAL MODE SHIFT DOWN SIGNAL (WITH 2.0L turbo gasoline engine)
34	BG	PADDLE SHIFTER UP SWITCH SIGNAL
34	G	PADDLE SHIFTER DOWN SWITCH SIGNAL
35	V	ILLUMINATION CONTROL SWITCH SIGNAL (+)
37	GR	ILLUMINATION CONTROL SWITCH SIGNAL (-)
38	R	VEHICLE SPEED SIGNAL (8-PULSE)

Connector No.	M58
Connector Name	COMBINATION METER
Connector Type	TH12FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
41	L	CAN-H
42	P	CAN-L
43	B	ILLUMINATION CONTROL SIGNAL
44	Y	FUEL LEVEL SENSOR GROUND
45	W	BATTERY POWER SUPPLY
46	BG	IGNITION SIGNAL (Except with VR30 engine and without IS)
46	R	IGNITION SIGNAL (With VR30 engine and without IS)
47	SB	AV COMMUNICATION SIGNAL (H)
48	LG	AV COMMUNICATION SIGNAL (L)
51	BR	FUEL LEVEL SENSOR SIGNAL
52	B	GROUND

Connector No.	M60
Connector Name	TRIPLE SWITCH
Connector Type	TH12FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	R	-
5	B	-
6	R	-
7	B	-
9	R	INDICATOR+
11	GR	INDICATOR-

Connector No.	M84
Connector Name	TRUNK LID OPENER CANCEL SWITCH
Connector Type	502FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	B	-

Connector No.	M91
Connector Name	OPTICAL SENSOR
Connector Type	TK03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	SENSOR_POWER
2	BG	SENSOR_OUTPUT
3	P	SENSOR_GND

Connector No.	M100
Connector Name	DISPLAY CONTROL UNIT
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
16	LG	AV COMM (L)
17	P	CAN-L
19	R	DIMMER SIGNAL
20	BR	REVERSE SIGNAL
22	B	GND
26	BR	CAMERA SWITCH SIGNAL
28	SB	AV COMM (H)
29	L	CAN-H
30	R	IGN (For VR30 engine)
30	W	IGN (For 2.0L turbo gasoline engine)
31	R	VEHICLE SPEED SIGNAL (8-PULSE)
33	SB	ACC (Except for VR30 engine and with IS)
33	V	ACC (For VR30 engine and with IS)
34	Y	BAT

Connector No.	M109
Connector Name	INSIDE KEY ANTENNA (INSTRUMENT LOWER)
Connector Type	RK02FGV



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	ANT+
2	G	ANT-

BCM (BODY CONTROL MODULE)

Connector No.	M113
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	AAC04FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	+12V
2	L	SIGNAL
3	P	GND

Connector No.	M114
Connector Name	INSIDE KEY ANTENNA (CONSOLE)
Connector Type	RK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	ANT+
2	GR	ANT-

Connector No.	M132
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS18FAW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
11B	UG	-
13B	P	-
14B	G	-
15B	Y	-
16B	Y	-
2B	B	-
4B	W	-
5B	R	-
9B	Y	-

Connector No.	M133
Connector Name	FUSE BLOCK (J/B)
Connector Type	TH40FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	V	-
12C	L	-
14C	L	-
15C	R	-
16C	R	-
17C	L	-
18C	BG	- [Without DRPO]
18C	P	- [With DRPO]
19C	B	-
1C	R	-

20C	W	-
21C	L	-
22C	L	-
23C	L	-
25C	LG	-
26C	SB	-
27C	P	-
28C	W	-
29C	W	-
3C	R	-
36C	R	-
37C	W	-
38C	SB	-
39C	V	-
3C	P	-
40C	G	-
4C	P	-
5C	P	-
6C	G	-
7C	G	-
8C	G	-
9C	V	-

Connector No.	M144
Connector Name	TCU
Connector Type	TH40FB-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	BAT
2	SB	ACC [For 2.0L turbo gasoline engine]
2	V	ACC [For VR30 engine]
3	SB	ACC OUTPUT
5	BR	SOS SWITCH-LED SIGNAL

6	L	CAN-H
7	P	CAN-L
10	R	IGN [For VR30 engine]
10	W	IGN [For 2.0L turbo gasoline engine]
11	SHIELD	MICROPHONE SIGNAL GND
12	R	MICROPHONE OUTPUT SIGNAL
15	SHIELD	SHIELD
17	G	MICROPHONE SIGNAL
18	L	MICROPHONE LYCC
36	SB	AV COMM (H)
37	LG	AV COMM (L)
28	B	GROUND
29	B	GROUND
30	SHIELD	SHIELD
31	B	SOUND SIGNAL (+)
32	W	SOUND SIGNAL (-)
37	G	SOS CALL SWITCH SIGNAL

Connector No.	F4
Connector Name	MAP LAMP
Connector Type	TH08FEW-1V-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	L	-
3	BR	-
6	B	-
7	SB	-
8	BG	-

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


BCM (BODY CONTROL MODULE)

Connector No.	R5
Connector Name	RAIN SENSOR
Connector Type	AAB03FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	R	-
3	B	-

Connector No.	R10
Connector Name	SUNROOF MOTOR ASSEMBLY
Connector Type	YEALDFGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	IGN
3	Y	IGN ON
5	P	TILT DOWN/SIDE OPEN
6	W	PMW SPAY (BAT)
8	GR	VEHICLE SPEED
9	V	SUNROOF SLIDE OPEN (INTELLIGENT KEY)
10	SB	TILT UP/SIDE CLOSE

Connector No.	R21
Connector Name	PERSONAL LAMP
Connector Type	TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	O	-
3	BR	-
4	B/W	-

Connector No.	R23
Connector Name	VANITY MIRROR LAMP (PASSENGER SIDE)
Connector Type	MCAD2FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B/L	-
2	V	-

Connector No.	R24
Connector Name	VANITY MIRROR LAMP (DRIVER SIDE)
Connector Type	MCAD2FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B/L	-
2	V	-

Connector No.	T27
Connector Name	TRUNK LID OPERER REQUEST SWITCH ASSEMBLY
Connector Type	TH04MMV-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	B	-
3	B	-
4	R	-

Connector No.	T53
Connector Name	TRUNK LID LOCK ASSEMBLY
Connector Type	TB03FW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	L	-
3	G	-

JRMWJ4660GB

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

< BASIC INSPECTION >

BASIC INSPECTION

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

Description

INFOID:0000000012792468

Perform the following operations when replacing BCM. (For details, refer to [BCS-81, "Work Procedure"](#).)

BEFORE REPLACEMENT

When replacing BCM, save or print current vehicle specification with CONSULT configuration before replacement.

NOTE:

If "Before Replace ECU" of "Read / Write Configuration" cannot be used, use the "Manual Configuration" after replacing BCM.

AFTER REPLACEMENT

CAUTION:

When replacing BCM, always perform "Read / Write Configuration" or "Manual Configuration" with CONSULT. Or not doing so, BCM control function does not operate normally.

- Complete the procedure of "Read / Write Configuration" in order.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- If you set incorrect "Read / Write Configuration" or "Manual Configuration", incidents might occur.

NOTE:

When replacing BCM, perform the system initialization (NATS and TPMS) (if equipped).

Work Procedure

INFOID:0000000012792469

1. SAVING VEHICLE SPECIFICATION (BCM)

CONSULT Configuration

Perform "Before Replace ECU" of "Read / Write Configuration" to save or print current vehicle specification. Refer to [BCS-83, "Description"](#).

NOTE:

If "Before Replace ECU" of "Read / Write Configuration" cannot be used, use the "Manual Configuration" after replacing BCM.

>> GO TO 2.

2. SAVING VEHICLE SPECIFICATION (TPMS) (IF EQUIPPED)

CONSULT Configuration

Perform "Before Replace ECU" of "Read / Write Configuration" to save or print current vehicle specification. Refer to [WT-42, "Work Procedure \(Before Replacement\)"](#).

NOTE:

If "Before Replace ECU" of "Read / Write Configuration" cannot be used, use the "Manual Configuration" after replacing BCM.

>> GO TO 3.

3. REPLACE BCM

Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).

>> GO TO 4.

4. WRITING VEHICLE SPECIFICATION (BCM)

CONSULT Configuration

Perform "After Replace ECU" of "Read / Write Configuration" or "Manual Configuration" to write vehicle specification. Refer to [BCS-83, "Description"](#).

>> GO TO 5.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

< BASIC INSPECTION >

5. INITIALIZE BCM (NATS)

Perform BCM initialization (NATS).

>> GO TO 6.

6. INITIALIZE BCM (TPMS) (IF EQUIPPED)

Perform BCM initialization (TPMS). Refer to [WT-42, "Work Procedure \(After Replacement\)"](#).

>> WORK END

CONFIGURATION (BCM)

< BASIC INSPECTION >

CONFIGURATION (BCM)

Description

INFOID:000000012792470

Vehicle specification needs to be written with CONSULT because it is not written after replacing BCM. Configuration has three functions as follows. (For details, refer to [BCS-83. "Work Procedure".](#))

Function		Description
Read / Write Configuration	Before Replace ECU	<ul style="list-style-type: none">• Reads the vehicle configuration of current BCM.• Saves the read vehicle configuration.
	After Replace ECU	Writes the vehicle configuration with saved data.
Manual Configuration		Writes the vehicle configuration with manual selection.

NOTE:

Manual setting item: Items which need selection by vehicle specifications

Automatic setting item: Items which are written in automatically (Setting cannot be changed)

For some models and specifications, the automatic setting item may not be displayed.

CAUTION:

When replacing BCM, always perform "Re/programming, Configuration" with CONSULT. Or not doing so, BCM control function does not operate normally.

- Complete the procedure of "Read / Write Configuration" in order.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Read / Write Configuration" except for new BCM.
- If you set incorrect "Read / Write Configuration", incidents might occur.

Work Procedure

INFOID:000000012792471

1. WRITING MODE SELECTION

 CONSULT Configuration

Select "Re/programming, Configuration" of BCM.

When writing saved data>>GO TO 2.

When writing manually>>GO TO 3.

2. PERFORM "AFTER REPLACE ECU" OF "READ / WRITE CONFIGURATION"

 CONSULT Configuration

Perform "After Replace ECU" of "Read / Write Configuration".

>> WORK END

3. PERFORM "MANUAL CONFIGURATION"

 CONSULT Configuration

1. Select "Manual Configuration".
2. Identify the correct model and configuration list. Refer to [BCS-84. "Configuration list".](#)
3. Confirm and/or change setting value for each item.

CAUTION:

Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.

NOTE:

If items are not displayed, touch "Next". Refer to [BCS-84. "Configuration list"](#) for written items and setting value.

4. Touch "Next".
5. Touch "OK".

CAUTION:

Make sure to select "OK" even if the indicated configuration of brand new BCM is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model cannot be memorized.

6. Check that the configuration has been successfully written and touch "End".

CONFIGURATION (BCM)

< BASIC INSPECTION >

>> GO TO 4.

4. OPERATION CHECK

Confirm that each function controlled by BCM operates normally.

>> WORK END

Configuration list

INFOID:000000012792472

CAUTION:

- Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.
- The “setting value” of this vehicle is as follows: Never select any other value than the setting value shown below. (If there is only 1 item in “setting value” that means that item is the only choice for this certain vehicle.)

SETTING ITEM		NOTE
Items	Setting value	
FR FOG LAMP	MODE1	MODE1: With front fog lamp
TR CANCEL SW	WITH ⇔ WITHOUT	<ul style="list-style-type: none"> • WITH: Except for Mexico • WITHOUT: For Mexico
RAIN SENSOR CONFIG	WITH ⇔ WITHOUT	<ul style="list-style-type: none"> • WITH: With rain sensor • WITHOUT: Without rain sensor
DONGLE	WITH ⇔ WITHOUT	<ul style="list-style-type: none"> • WITH: For Canada models • WITHOUT: Except for Canada models
CAN ERR DETECT HPCM or VCM	WITHOUT	WITHOUT: Except for hybrid models
CAN ERR DETECT TELEMATICS	WITH ⇔ WITHOUT	<ul style="list-style-type: none"> • WITH: With telematics system • WITHOUT: Without telematics system
HBA SYSTEM	WITH ⇔ WITHOUT	<ul style="list-style-type: none"> • WITH: With high beam assist system • WITHOUT: Without high beam assist system
KEY FOB FREQUENCY TYPE	MODE2 ⇔ MODE3	<ul style="list-style-type: none"> • MODE2: For Mexico • MODE3: Except for Mexico
Key Fob Type	LCK/UNLCK/TRNK/ALRM ⇔ ENST/LCK/UNLCK/TRK/ALRM	<ul style="list-style-type: none"> • LCK/UNLCK/TRNK/ALRM: Without remote engine start function • ENST/LCK/UNLCK/TRK/ALRM: With remote engine start function
ONE TOUCH UNLOCK SENSOR	MODE1	MODE1: With one touch unlock function
INTELLIGENT KEY TYPE	MODE2	MODE2: With door request switch
ALT TYPE	GASOLINE	GASOLINE: Gasoline engine models
TRANSMISSION	AT with ABS ⇔ AT (TYPE1)	<ul style="list-style-type: none"> • AT with ABS: Except 2.0L turbo gasoline engine models • AT (TYPE1): 2.0L turbo gasoline engine models
AUTO CRANK TIME	MODE1 ⇔ MODE3	<ul style="list-style-type: none"> • MODE1: Except 2.0L turbo gasoline engine models • MODE3: 2.0L turbo gasoline engine models

⇔: Items which confirm vehicle specifications

SHIPPING MODE CANCEL OPERATION

< BASIC INSPECTION >

SHIPPING MODE CANCEL OPERATION

Work Procedure

INFOID:000000012792473

1. SHIPPING MODE CANCEL OPERATION

1. Turn ignition switch OFF.
2. Push in (switch on) the extended storage fuse switch. Refer to [PG-254, "How To Check"](#).
3. Turn ignition switch ON.
4. Turn ignition switch OFF and wait at least 2 seconds.

>> GO TO 2.

2. SHIPPING MODE CANCEL CHECK

1. Turn ignition switch ON.
2. Check that extended storage fuse warning message is not displayed on information display.

>> WORK END

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

U1000 CAN COMM

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM

DTC Description

INFOID:000000012792474

DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only. CAN Communication Signal Chart. Refer to [LAN-67. "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart \(2.0L Turbo Gasoline Engine Models\)"](#).

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition
U1000	CAN COMM (CAN communication circuit)	When BCM cannot communicate CAN communication signal continuously for 2 seconds or more.

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

—

Diagnosis Procedure

INFOID:000000012792475

1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" of BCM.

Is DTC "U1000" displayed?

- YES >> Refer to [LAN-41. "Trouble Diagnosis Flow Chart"](#).
NO-1 >> To check malfunction symptom before repair: Refer to [GI-45. "Intermittent Incident"](#).
NO-2 >> Confirmation after repair: INSPECTION END

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

DTC Description

INFOID:000000012792476

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition
U1010	CONTROL UNIT (CAN) [Control unit (CAN)]	BCM detected internal CAN communication circuit malfunction.

POSSIBLE CAUSE

BCM

FAIL-SAFE

—

Diagnosis Procedure

INFOID:000000012792477

1. REPLACE BCM

When DTC "U1010" is detected, replace BCM.

>> Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

U0415 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

U0415 VEHICLE SPEED

DTC Description

INFOID:000000012792478

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition
U0415	VEHICLE SPEED (Vehicle speed)	When the vehicle speed signal received from the ABS actuator and electric unit (control unit) remains abnormal for 2 seconds or more.

POSSIBLE CAUSE

- ABS actuator and electric unit (control unit)
- BCM

FAIL-SAFE

—

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION

1. Erase the DTC.
2. Turn ignition switch OFF.
3. Perform the "Self Diagnostic Result" of BCM with CONSULT, when passed 2 seconds or more after the ignition switch is turned ON.

Is any DTC detected?

YES >> Refer to [BCS-88. "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-45. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000012792479

1. ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAG RESULTS

Perform "Self-Diagnostic Result" of ABS actuator and electric unit (control unit) with CONSULT. Refer to [BRC-72. "DTC Index"](#).

Is any DTC detected?

YES >> Repair or replace the malfunctioning part.

NO >> Replace BCM. Refer to [BCS-99. "Removal and Installation"](#).

B2562 LOW VOLTAGE

< DTC/CIRCUIT DIAGNOSIS >

B2562 LOW VOLTAGE

DTC Description

INFOID:000000012792480

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition
B2562	LOW VOLTAGE (Low voltage)	When the power supply voltage to BCM remains less than 8.8 V for 120 seconds or more

POSSIBLE CAUSE

- Harness or connector (power supply circuit)
- BCM

FAIL-SAFE

—

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION

1. Erase DTC.
2. Turn ignition switch OFF.
3. Perform the "Self Diagnostic Result" of BCM with CONSULT, when passed 120 seconds or more after the ignition switch is turned ON.

Is any DTC detected?

YES >> Refer to [BCS-89, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-45, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000012792481

1. CHECK POWER SUPPLY CIRCUIT

Check BCM power supply circuit. Refer to [BCS-92, "Diagnosis Procedure"](#).

Is the circuit normal?

YES >> Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).

NO >> Repair the malfunctioning part.

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

B259A ROOM LAMP FUSE

< DTC/CIRCUIT DIAGNOSIS >

B259A ROOM LAMP FUSE

DTC Description

INFOID:000000012792482

DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition
B259A	ROOM LAMP FUSE BLOWN (Room lamp fuse blown)	When BCM detects that power supply voltage is supplied to fusible link battery power, but not to BCM battery fuse for 2 minutes when ignition switch is ON.

POSSIBLE CAUSE

- Fuse
- Harness or connector (power supply circuit is open or shorted)
- Harness or connector (interior room lamp power supply circuit is shorted)
- BCM

FAIL-SAFE

—

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION

1. Erase DTC.
2. Turn ignition switch OFF.
3. Perform the "Self Diagnostic Result" of BCM with CONSULT, after the ignition switch has been turned ON for 2 minutes or more.

Is any DTC detected?

- YES >> Refer to [BCS-90, "Diagnosis Procedure"](#).
NO-1 >> To check malfunction symptom before repair: Refer to [GI-45, "Intermittent Incident"](#).
NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000012792483

1. CHECK FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not blown (open).

Signal name	Fuse No.
Battery power supply	20 (10 A)

Is the fuse blown (open)?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK BCM FUSE CIRCUIT

1. Disconnect BCM connectors.
2. Check voltage between BCM harness connector and ground.

(+)		(-)	Voltage
BCM			
Connector	Terminal		
M17	131	Ground	9 – 16 V

Is the measurement value normal?

- YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).
NO >> Repair harness or connector.

3. CHECK BCM FUSE CIRCUIT FOR SHORT TO GROUND

1. Disconnect BCM connectors.

B259A ROOM LAMP FUSE

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	131		Not existed

Does continuity exist?

YES >> Repair harness or connector.

NO >> GO TO 4.

4. CHECK INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT FOR SHORT TO GROUND

1. Disconnect following connectors.

- Map lamp
- Personal lamp
- Vanity mirror lamp (both sides)
- Outside handle lamp (both sides)
- Step lamp (ALL)
- Trunk room lamp

2. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	129		Not existed

Does continuity exist?

YES >> Repair harness or connector.

NO >> Check interior room lamp. If result is normal, replace BCM. Refer to [BCS-99. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000012792484

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown (open).

Signal name	Fuse and fusible link No.
Battery power supply	20 (10 A)
	M (40 A)

Is the fuse or fusible link blown (open)?

YES >> Replace the blown (open) fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Voltage
BCM			
Connector	Terminal	Ground	9 – 16 V
M17	131		
	139		

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		Existed
M17	134		
	143		

Does continuity exist?

YES >> INSPECTION END

NO >> Repair harness or connector.

COMBINATION SWITCH OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

COMBINATION SWITCH OUTPUT CIRCUIT

Diagnosis Procedure

INFOID:000000012792485

1. CHECK OUTPUT 1 - 5 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM and combination switch connectors.
3. Check continuity between BCM harness connector and combination switch harness connector.

System	BCM		Combination switch		Continuity
	Connector	Terminal	Connector	Terminal	
OUTPUT 1	M13	14	M27	12	Existed
OUTPUT 2		13		14	
OUTPUT 3		12		5	
OUTPUT 4		11		2	
OUTPUT 5		10		8	

Does continuity exist?

YES >> GO TO 2.

NO >> Repair harnesses or connectors.

2. CHECK OUTPUT 1 - 5 CIRCUIT FOR SHORT

Check for continuity between BCM harness connector and ground.

System	BCM		Ground	Continuity
	Connector	Terminal		
OUTPUT 1	M13	14	Ground	Not existed
OUTPUT 2		13		
OUTPUT 3		12		
OUTPUT 4		11		
OUTPUT 5		10		

Does continuity exist?

YES >> Repair harnesses or connectors.

NO >> GO TO 3.

3. CHECK COMBINATION SWITCH INTERNAL CIRCUIT

1. Connect BCM connector.
2. Turn ON any switch in the system that is malfunctioning.
3. Check voltage between BCM harness connector and ground.

NOTE:

Check that the combination switch outputs a signal from combination switch input system.

System	(+)		(-)	Voltage (Approx.)
	BCM			
	Connector	Terminal		
OUTPUT 1	M27	12	Ground	Refer to BCS-36 . "Reference Value".
OUTPUT 2		14		
OUTPUT 3		5		
OUTPUT 4		2		
OUTPUT 5		8		

Is the measurement value normal?

YES >> Replace BCM. Refer to [BCS-99](#). "Removal and Installation".

COMBINATION SWITCH OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace combination switch. Refer to [BCS-100, "Removal and Installation"](#).

COMBINATION SWITCH INPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

COMBINATION SWITCH INPUT CIRCUIT

Diagnosis Procedure

INFOID:000000012792486

1. CHECK INPUT 1 - 5 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM and combination switch connectors.
3. Check continuity between BCM harness connector and combination switch harness connector.

System	BCM		Combination switch		Continuity
	Connector	Terminal	Connector	Terminal	
INPUT 1	M14	79	M27	11	Existed
INPUT 2		78		9	
INPUT 3		77		7	
INPUT 4		76		10	
INPUT 5		75		13	

Does continuity exist?

YES >> GO TO 2.

NO >> Repair harnesses or connectors.

2. CHECK INPUT 1 - 5 CIRCUIT FOR SHORT

Check for continuity between BCM harness connector and ground.

System	BCM		Ground	Continuity
	Connector	Terminal		
INPUT 1	M14	79	Ground	Not existed
INPUT 2		78		
INPUT 3		77		
INPUT 4		76		
INPUT 5		75		

Does continuity exist?

YES >> Repair harnesses or connectors.

NO >> GO TO 3.

3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

System	(+)		(-)	Voltage (Approx.)
	BCM			
	Connector	Terminal		
INPUT 1	M14	79	Ground	Refer to BCS-36, "Reference Value" .
INPUT 2		78		
INPUT 3		77		
INPUT 4		76		
INPUT 5		75		

Is the measurement value normal?

Yes >> GO TO 4.

No >> Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).

4. CHECK BCM INPUT SIGNAL

COMBINATION SWITCH INPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

1. Connect combination switch connector.
2. Turn ON any switch in the system that is malfunction.
3. Check voltage between BCM harness connector and ground.

System	(+)		(-)	Voltage (Approx.)
	BCM			
	Connector	Terminal		
INPUT 1	M14	79	Ground	Refer to BCS-36 . "Reference Value".
INPUT 2		78		
INPUT 3		77		
INPUT 4		76		
INPUT 5		75		

Is the measurement value normal?

- Yes >> Replace BCM. Refer to [BCS-99](#). "Removal and Installation".
- No >> Replace combination switch. Refer to [BCS-100](#). "Removal and Installation".

COMBINATION SWITCH SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

COMBINATION SWITCH SYSTEM SYMPTOMS

Symptom Table

INFOID:0000000012792487

1. Perform "Data Monitor" of CONSULT to check for any malfunctioning item.
2. Check the malfunction combinations.

Malfunction item: x

Data monitor item														Malfunction combination
FR WIPER HI	FR WIPER LOW	FR WASHER SW	FR WIPER INT	INT VOLUME	TURN SIGNAL R	TURN SIGNAL L	TAIL LAMP SW	HI BEAM SW	HEAD LAMP SW 1	HEAD LAMP SW 2	PASSING SW	AUTO LIGHT SW	FR FOG SW	
	x	x			x	x								A
x			x						x		x			B
				x				x		x				C
				x			x					x		D
				x									x	E
x				x										F
		x		x										G
	x		x									x		H
						x				x	x		x	I
					x		x	x	x					J
All Items														K
If only one item is detected or the item is not applicable to the combinations A to K														L
All Items are normal														M

3. Identify the malfunctioning part from the agreed combination and repair or replace the part.

Malfunction combination	Malfunctioning part	Repair or replace
A	Combination switch INPUT 1 circuit	Inspect the combination switch output circuit applicable to the malfunctioning part. Refer to BCS-95, "Diagnosis Procedure" .
B	Combination switch INPUT 2 circuit	
C	Combination switch INPUT 3 circuit	
D	Combination switch INPUT 4 circuit	
E	Combination switch INPUT 5 circuit	
F	Combination switch OUTPUT 1 circuit	Inspect the combination switch input circuit applicable to the malfunctioning part. Refer to BCS-93, "Diagnosis Procedure" .
G	Combination switch OUTPUT 2 circuit	
H	Combination switch OUTPUT 3 circuit	
I	Combination switch OUTPUT 4 circuit	
J	Combination switch OUTPUT 5 circuit	
K	BCM	Replace BCM. Refer to BCS-99, "Removal and Installation" .
L	Combination switch	Replace combination switch. Refer to BCS-100, "Removal and Installation" .
M	Connector and harness	Check intermittent incident. Refer to GI-45, "Intermittent Incident" .

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION

Description

INFOID:000000012792488

SHIPPING MODE

- Shipping mode inhibits battery power consumption during transportation or storage of the vehicle. Vehicle is set to shipping mode before being shipped from the factory.
- When ignition switch is OFF, BCM operates shipping mode.
- BCM control function is limited in shipping mode. Remote keyless entry function is not operated during the shipping mode.
- For shipping mode cancel operation, refer to [BCS-85. "Work Procedure"](#).

NOTE:

Do not cancel shipping mode during storage of the vehicle. Always cancel shipping mode before delivery of the vehicle to customer.

BCM

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

BCM

Removal and Installation


INFOID:0000000012792489

CAUTION:

Before replacing BCM, perform “Before Replace ECU” of “Read / Write Configuration” to save or print current vehicle specification. Refer to [BCS-81, "Description"](#).

REMOVAL

1. Disconnect the battery cable from the negative terminal.
2. Remove the dash side finisher RH. Refer to [INT-31, "DASH SIDE FINISHER : Removal and Installation"](#).
3. Remove the BCM mounting nut (A) and mounting bolt (B).
4. Disconnect the harness connectors from the BCM (1).



INSTALLATION

Install in the reverse order of removal.

CAUTION:

Be sure to perform “After Replace ECU” of “Read / Write Configuration” or “Manual Configuration” when replacing BCM. Refer to [BCS-81, "Description"](#).

NOTE:

- Be sure to perform the system initialization (NATS) when replacing BCM.
- Be sure to perform the system initialization (TPMS) when replacing BCM.

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

COMBINATION SWITCH

< REMOVAL AND INSTALLATION >


COMBINATION SWITCH

Removal and Installation

INFOID:000000012792490

REMOVAL

1. Remove steering column cover. Refer to [IP-13. "Removal and Installation"](#).
2. Remove screws (A) and disconnect connector (2) then pull up combination switch (1) to remove it.



INSTALLATION

Install in the reverse order of removal.