

A
B
C

SECTION INL

INTERIOR LIGHTING SYSTEM

D
E

CONTENTS

PRECAUTION	COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	F
3	16	
PRECAUTIONS	INT LAMP	G
3	17	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	INT LAMP : CONSULT Function (BCM - INT LAMP)	
3	17	
Precautions for Removing Battery Terminal	BATTERY SAVER	H
3	19	
SYSTEM DESCRIPTION	BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)	
5	19	
COMPONENT PARTS	INTELLIGENT KEY	I
5	20	
INTERIOR LIGHTING SYSTEM	INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)	
5	20	
INTERIOR LIGHTING SYSTEM : Interior Lamp Appearance and Bulb Specifications	ECU DIAGNOSIS INFORMATION	J
5	25	
INTERIOR LIGHTING SYSTEM : Component Parts Location	BCM	K
6	25	
SYSTEM	List of ECU Reference	
8	25	
INTERIOR ROOM LAMP CONTROL SYSTEM	WIRING DIAGRAM	INL
8	26	
INTERIOR ROOM LAMP CONTROL SYSTEM : System Description	INTERIOR ROOM LAMP CONTROL SYSTEM	
8	26	
INTERIOR ROOM LAMP CONTROL SYSTEM : Circuit Diagram	Wiring Diagram	M
11	26	
INTERIOR ROOM LAMP BATTERY SAVER SYSTEM	ILLUMINATION	N
11	42	
INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description	Wiring Diagram	
12	42	
INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : Circuit Diagram	BASIC INSPECTION	O
13	58	
ILLUMINATION CONTROL SYSTEM	DIAGNOSIS AND REPAIR WORK FLOW	
13	58	
ILLUMINATION CONTROL SYSTEM : System Description	Work Flow	P
14	58	
ILLUMINATION CONTROL SYSTEM : Circuit Diagram	DTC/CIRCUIT DIAGNOSIS	
15	61	
DIAGNOSIS SYSTEM (BCM)	INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT	
16	61	
COMMON ITEM	Component Function Check	
16	61	
	Diagnosis Procedure	
	61	
	INTERIOR ROOM LAMP CONTROL CIRCUIT	
	63	

Component Function Check	63	GLOVE BOX LAMP	81
Diagnosis Procedure	63	Exploded View	81
TRUNK ROOM LAMP CIRCUIT	65	Replacement	81
Component Function Check	65	STEP LAMP	82
Diagnosis Procedure	65	Exploded View	82
STEP LAMP CIRCUIT	67	Removal and Installation	82
Component Function Check	67	Replacement	83
Diagnosis Procedure	67	PERSONAL LAMP	84
OUTSIDE HANDLE LAMP CIRCUIT	69	Exploded View	84
Component Function Check	69	Removal and Installation	84
Diagnosis Procedure	69	Replacement	85
PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT	71	TRUNK ROOM LAMP	87
Component Function Check	71	Exploded View	87
Diagnosis Procedure	71	Removal and Installation	87
SYMPTOM DIAGNOSIS	73	Replacement	88
INTERIOR LIGHTING SYSTEM SYMPTOMS...	73	OUTSIDE HANDLE LAMP	89
Symptom Table	73	Exploded View	89
REMOVAL AND INSTALLATION	74	Replacement	89
MAP LAMP	74	CONSOLE BOX LAMP	90
Exploded View	74	Exploded View	90
MAP LAMP	74	Replacement	90
MAP LAMP : Removal and Installation	74	KICKING PLATE LAMP	91
MAP LAMP : Replacement	75	Exploded View	91
MAP LAMP BRACKET	75	Replacement	91
MAP LAMP BRACKET : Removal and Installation..	75	SERVICE DATA AND SPECIFICATIONS (SDS)	92
VANITY MIRROR LAMP	79	SERVICE DATA AND SPECIFICATIONS (SDS)	92
Exploded View	79	Bulb Specifications	92
Replacement	79		

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000012789601

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery or batteries, and wait at least 3 minutes before performing any service.


Precautions for Removing Battery Terminal

INFOID:000000013472608

When disconnecting the battery terminal, pay attention to the following.

- Always use a 12V battery as power source.
- Never disconnect battery terminal while engine is running.
- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
- For vehicles with the engine listed below, remove the battery terminal after a lapse of the specified time:

BR08DE	: 4 minutes	V9X engine	: 4 minutes
D4D engine	: 20 minutes	YD25DDTi	: 2 minutes
HR09DET	: 12 minutes	YS23DDT	: 4 minutes
HRA2DDT	: 12 minutes	YS23DDTT	: 4 minutes
K9K engine	: 4 minutes	ZD30DDTi	: 60 seconds
M9R engine	: 4 minutes	ZD30DDTT	: 60 seconds
R9M engine	: 4 minutes		



NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- After high-load driving, if the vehicle is equipped with the V9X engine, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery terminal.

NOTE:

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

PRECAUTIONS

< PRECAUTION >

- Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.
- Example of high-load driving
 - Driving for 30 minutes or more at 140 km/h (86 MPH) or more.
 - Driving for 30 minutes or more on a steep slope.
- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

COMPONENT PARTS

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

COMPONENT PARTS

INTERIOR LIGHTING SYSTEM

INTERIOR LIGHTING SYSTEM : Interior Lamp Appearance and Bulb Specifications

INFOID:000000012789603



JMLIA7355ZZ

No.	Item	Type	Wattage (W)
①	Push-button ignition switch illumination	LED	—
②	Map lamp	LED	—
③	Map lamp illumination (Integrated into map lamp assembly)	LED	—
④	Vanity mirror lamp	—	1.8
⑤	Glove box lamp	Wedge	1.4
⑥	Step lamp	Wedge	5.0
⑦	Personal lamp	Wedge	8.0
⑧	Trunk room lamp	Wedge	3.4
⑨	Outside handle lamp	LED	—
⑩	Console box lamp	Wedge	2.0
⑪	Kicking plate lamp*	LED	—

*: If equipped.


A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

INTERIOR LIGHTING SYSTEM : Component Parts Location

INFOID:000000012789604



JMLIA7347ZZ

No.	Component	Function	
①	Personal lamp	Refer to INL-5, "INTERIOR LIGHTING SYSTEM : Interior Lamp Appearance and Bulb Specifications" .	
②	Front outside handle	Request switch	Refer to DLK-11, "DOOR LOCK SYSTEM : Door Request Switch" .
		One touch unlock sensor	Refer to DLK-13, "DOOR LOCK SYSTEM : One Touch Unlock Sensor Assembly" .
		Outside handle lamp	Refer to INL-5, "INTERIOR LIGHTING SYSTEM : Interior Lamp Appearance and Bulb Specifications" .
③	Map lamp	Refer to INL-5, "INTERIOR LIGHTING SYSTEM : Interior Lamp Appearance and Bulb Specifications" .	
④	Door lock and unlock switch	Refer to DLK-10, "DOOR LOCK SYSTEM : Door Lock and Unlock Switch" .	

COMPONENT PARTS

< SYSTEM DESCRIPTION >

No.	Component	Function
⑤	BCM	<ul style="list-style-type: none"> • Activates the interior room lamp timer depending on the vehicle condition to turn the interior room lamps ON/OFF. • Operates the interior room lamp battery saver depending on the vehicle condition to turn interior room lamps OFF. • Detects each switch condition by the combination switch reading function. • Judges the illumination lamp ON/OFF status depending on the vehicle condition. And then transmits request signal to IPDM E/R and combination meter (via CAN communication). Refer to BCS-5, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location.
⑥	IPDM E/R	Controls the integrated relay according to the request signal from BCM (via CAN communication). Refer to PCS-5, "Component Parts Location" for detailed installation location.
⑦	Step lamp	Refer to INL-5, "INTERIOR LIGHTING SYSTEM : Interior Lamp Appearance and Bulb Specifications" .
⑧	Kicking plate lamp	Refer to INL-5, "INTERIOR LIGHTING SYSTEM : Interior Lamp Appearance and Bulb Specifications" .
⑨	Door switch	Refer to DLK-11, "DOOR LOCK SYSTEM : Door Switch" .
⑩	Trunk lid lock assembly (Trunk room lamp switch)	Refer to DLK-14, "DOOR LOCK SYSTEM : Trunk Lid Lock Assembly" .
⑪	Inside key antenna (Trunk room)	Refer to DLK-12, "DOOR LOCK SYSTEM : Inside Key Antenna" .
⑫	Trunk room lamp	Refer to INL-5, "INTERIOR LIGHTING SYSTEM : Interior Lamp Appearance and Bulb Specifications" .
⑬	Combination meter	Controls the meter illumination according to the request signal from BCM (via CAN communication).
⑭	Combination switch (Lighting & turn signal switch)	Refer to BCS-9, "COMBINATION SWITCH READING SYSTEM : System Description" .
⑮	Push-button ignition switch (Push-button ignition switch illumination)	Refer to INL-5, "INTERIOR LIGHTING SYSTEM : Interior Lamp Appearance and Bulb Specifications" .
⑯	Inside key antenna (Console)	Refer to DLK-12, "DOOR LOCK SYSTEM : Inside Key Antenna" .
⑰	Display control unit	Controls the brightness of display according to the request signal from BCM.
⑱	Remote keyless entry receiver	Refer to DLK-13, "DOOR LOCK SYSTEM : Remote Keyless Entry Receiver" .
⑲	Inside key antenna (Instrument lower)	Refer to DLK-12, "DOOR LOCK SYSTEM : Inside Key Antenna" .
⑳	Optical sensor	Refer to EXL-16, "Optical Sensor" .
㉑	Vanity mirror lamp	Refer to INL-5, "INTERIOR LIGHTING SYSTEM : Interior Lamp Appearance and Bulb Specifications" .

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM

INTERIOR ROOM LAMP CONTROL SYSTEM

INTERIOR ROOM LAMP CONTROL SYSTEM : System Description

INFOID:000000012789605

SYSTEM DIAGRAM



OUTLINE

- Following lamps are controlled by interior room lamp timer control function of BCM.
 - Map lamp*
 - Personal lamp*
 - Outside handle lamp
 - Kicking plate lamp
- Trunk room lamp is controlled by trunk room lamp control function of BCM.
- Step lamp is controlled by step lamp control function of BCM.
- Push-button ignition switch illumination is controlled by push-button ignition switch illumination control function of BCM.
- Illumination ring of meter is controlled by meter ring illumination control function of BCM and meter effect function of combination meter.


*: Interior room lamp time control operates when the switch position is DOOR.

INTERIOR ROOM LAMP TIMER CONTROL

SYSTEM

< SYSTEM DESCRIPTION >

Interior Room Lamp Timer Basic Operation



- Following lamps turn ON and OFF (gradual brightening and dimming*) by the interior room lamp timer.
 - Map lamp
 - Personal lamp
 - Outside handle lamp
 - Kicking plate lamp
 - Timer operating time is 15 seconds.
 - Brightening time is 1 second and dimming time is 3 seconds.*
 - BCM judges the vehicle condition with the following items and activates the interior room lamp timer.
 - Ignition switch status
 - Door switch signal
 - Door lock/unlock signal (remote keyless entry receiver, door lock and unlock switch, each door request switch, one touch unlock sensor, door key cylinder switch)
- *: Except for outside handle lamp.

NOTE:

Factory setting of interior room lamp is with interior room lamp timer control. This setting can be set to without by using CONSULT. Refer to [INL-17, "INT LAMP : CONSULT Function \(BCM - INT LAMP\)"](#).

Interior Room Lamp ON Operation

- BCM always turns the interior room lamp ON when any door opens.
- BCM activates the interior room lamp timer in any of the following condition to turn the interior room lamp ON for a period of time.
 - Status of all doors are OPEN → CLOSE
 - Ignition switch is turned ON → OFF
 - Door unlock signal is detected when all doors close with ignition switch OFF

NOTE:

The timer restarts if new condition is input during the timer operating time.

Interior Room Lamp OFF Operation

BCM stops the timer in any of the following condition to turn the interior room lamp OFF.

- The timer operating time is expired
- Ignition switch is turned OFF → ON
- Door lock signal is detected with all doors close.

STEP LAMP CONTROL

BCM turns step lamp ON when the following condition is detected.

- Any door is opened

BCM turns step lamp OFF when the following condition is detected.

- All doors are closed

TRUNK ROOM LAMP CONTROL

BCM turns trunk room lamp ON when the following condition is detected.

- Trunk room lamp switch is ON

BCM turns trunk room lamp OFF when the following condition is detected.

- Trunk room lamp switch is OFF

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CONTROL

SYSTEM

< SYSTEM DESCRIPTION >

Push-button Ignition Switch Illumination Basic Operation

BCM provides the power supply to turn the push-button ignition switch illumination ON.

Heart Beat Operation

BCM repeats brightening and dimming operation of push-button ignition switch illumination when the following condition is satisfied.

- Any of the following condition with ignition switch OFF/ACC
 - Engine start permission is entered
 - Driver side door is LOCK → UNLOCK
 - Driver side door is open

Push-button Ignition Switch Illumination ON Operation

BCM turns the push-button ignition switch illumination ON in any of the following condition.

- Ignition switch ON
- Tail lamp is turned ON with ignition OFF/ACC

Dimming Operation

When ignition switch is changed from ON to OFF while tail lamp is OFF, ignition switch illumination dims to 50% brightness.

Push-button Ignition Switch Illumination OFF Operation

BCM turns the push-button ignition switch illumination OFF in any of the following condition.

- Tail lamp is turned OFF with ignition OFF/ACC
- Any of the following condition is satisfied during heart beat operation or dimming operation.
 - Status does not change for 16 seconds
 - Driver side door is UNLOCK → LOCK

METER RING ILLUMINATION CONTROL

Illumination ring of meter is controlled by each function of BCM and combination meter.

Control by BCM

- Meter ring illumination control function

Control by combination meter

- Meter effect function (Refer to [MWI-59, "METER EFFECT FUNCTION : System Description".](#))

Meter Ring Illumination Control Function

BCM transmits meter ring illumination request signal to combination meter via CAN communication when all of the following conditions are satisfied.


- Ignition switch is in LOCK position
- Driver side door is OPEN → CLOSE with intelligent key left inside the vehicle

SYSTEM

< SYSTEM DESCRIPTION >

INTERIOR ROOM LAMP CONTROL SYSTEM : Circuit Diagram

INFOID:000000012789606



INTERIOR ROOM LAMP BATTERY SAVER SYSTEM


SYSTEM

< SYSTEM DESCRIPTION >

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000012789607

SYSTEM DIAGRAM



OUTLINE

- Interior room lamp battery saver is controlled by BCM.
- BCM turns applicable lamps OFF depending on the vehicle condition. This function prevent battery discharge if the driver neglects, turning OFF any lamps.

Applicable lamps

- Personal lamp
- Map lamp
- Trunk room lamp
- Step lamp
- Outside handle lamp
- Vanity mirror lamp
- Kicking plate lamp

INTERIOR ROOM LAMP BATTERY SAVER FUNCTION


- BCM provides the interior room lamp power supply continuously when the ignition switch position is ON.
- When the ignition switch is turned OFF, BCM operates timer for 10 minutes to cut the interior room lamp power supply.
- BCM restart the timer when any of the following signal changes while operating the timer.
 - Ignition switch status
 - Door switch signal
 - Door lock/unlock signal (remote keyless entry receiver, door lock and unlock switch, each door request switch, one touch unlock sensor, door key cylinder switch)

SYSTEM

< SYSTEM DESCRIPTION >

INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : Circuit Diagram

INFOID:000000012789608



ILLUMINATION CONTROL SYSTEM


SYSTEM

< SYSTEM DESCRIPTION >

ILLUMINATION CONTROL SYSTEM : System Description

INFOID:000000012789609

SYSTEM DIAGRAM



OUTLINE

Each illumination lamp is controlled by each function of BCM, IPDM E/R and combination meter.

Control by BCM

- Parking, license plate and tail lamp control function

Control by IPDM E/R

- Relay control function

Control by combination meter

- Meter illumination control function (Refer to [MWI-58, "METER ILLUMINATION CONTROL : System Description"](#).)

ILLUMINATION CONTROL


- BCM transmits position light request signal to IPDM E/R and combination meter according to tail lamp ON condition. Refer to [EXL-35, "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description"](#).
- IPDM E/R turns the integrated tail lamp relay ON according to position light request signal. It provides the power supply to each illumination lamp.
- Combination meter controls each illumination brightness according to the illumination control switch signal from illumination control switch.
- Combination meter enters in the nighttime mode according to position light request signal.

SYSTEM

< SYSTEM DESCRIPTION >

ILLUMINATION CONTROL SYSTEM : Circuit Diagram

INFOID:000000012789610



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000013409689

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER	×	×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
—	AIR CONDITONER*		×	×
<ul style="list-style-type: none"> Intelligent Key system Engine start system 	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
IVIS - NATS	IMMU	×	×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Trunk lid open	TRUNK		×	
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
—	AIR PRESSURE MONITOR*			×

*: This item is not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected*	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*)
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" *to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"*
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK"*.) to low power consumption mode
	LOCK		Power supply position is "LOCK" (Ignition switch OFF)*
	OFF		Power supply position is "OFF" (Ignition switch OFF)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN		Power supply position is "RUN" (Ignition switch ON with engine running)
CRANKING	Power supply position is "CRANKING" (At engine cranking)		
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. 	

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

INT LAMP

INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:000000012789612

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Service item	Setting item	Setting
SCENARIO LIGHTING SETTING	On	NOTE: Do not use this function since interior room lamp control is changed.
	Off*	
SET I/L D-UNLCK INTCON	On	Without interior room lamp timer function
	Off*	With interior room lamp timer function
FOG LAMP OVERRIDE	On	With front fog override function
	Off*	Without front fog override function

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW -DR [On/Off]	Indicated [On/Off] condition of door request switch (driver side)
REQ SW -AS [On/Off]	Indicated [On/Off] condition of door request switch (passenger side)
REQ SW -RR [On/Off]	NOTE: This item is displayed, but cannot be monitored
REQ SW -RL [On/Off]	NOTE: This item is displayed, but cannot be monitored
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
UNLK SEN -DR [On/Off]	Indicates [On/Off] condition of driver door UNLOCK status
DOOR SW-DR [On/Off]	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS [On/Off]	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR [On/Off]	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL [On/Off]	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK [On/Off]	NOTE: This item is displayed, but cannot be monitored
CDL LOCK SW [On/Off]	Indicated [On/Off] condition of lock signal from door lock and unlock switch
CDL UNLOCK SW [On/Off]	Indicated [On/Off] condition of unlock signal from door lock and unlock switch
KEY CYL LK-SW [On/Off]	Indicated [On/Off] condition of lock signal from door key cylinder switch
KEY CYL UN-SW [On/Off]	Indicated [On/Off] condition of unlock signal from door key cylinder switch
TRNK/HAT MNTR [On/Off]	Indicates [On/Off] condition of trunk room lamp switch
RKE-LOCK [On/Off]	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK [On/Off]	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test item	Operation	Description
INT LAMP	On	Outputs interior room lamp control signal.
	Off	Stops interior room lamp control signal.
STEP LAMP TEST	On	Outputs step lamp control signal.
	Off	Stops step lamp control signal.

BATTERY SAVER

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:000000012789613

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW -DR [On/Off]	Indicated [On/Off] condition of door request switch (driver side)
REQ SW -AS [On/Off]	Indicated [On/Off] condition of door request switch (passenger side)
REQ SW -RR [On/Off]	NOTE: This item is displayed, but cannot be monitored
REQ SW -RL [On/Off]	NOTE: This item is displayed, but cannot be monitored
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
UNLK SEN -DR [On/Off]	Indicates [On/Off] condition of driver door UNLOCK status
DOOR SW-DR [On/Off]	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS [On/Off]	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR [On/Off]	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL [On/Off]	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK [On/Off]	NOTE: This item is displayed, but cannot be monitored
CDL LOCK SW [On/Off]	Indicated [On/Off] condition of lock signal from door lock and unlock switch
CDL UNLOCK SW [On/Off]	Indicated [On/Off] condition of unlock signal from door lock and unlock switch
KEY CYL LK-SW [On/Off]	Indicated [On/Off] condition of lock signal from door key cylinder switch
KEY CYL UN-SW [On/Off]	Indicated [On/Off] condition of unlock signal from door key cylinder switch
TRNK/HAT MNTR [On/Off]	Indicates [On/Off] condition of trunk room lamp switch
RKE-LOCK [On/Off]	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK [On/Off]	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

ACTIVE TEST

Test item	Operation	Description
BATTERY SAVER	Off	Outputs interior room lamp power supply.
	On	Stops interior room lamp power supply.

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000013409717

WORK SUPPORT

Monitor item	Description
INSIDE ANT DIAGNOSIS	This function allows inside key antenna self-diagnosis
LOCK/UNLOCK BY I-KEY	Door lock function (door request switch) mode can be changed to operation in this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
ENGINE START BY I-KEY	Engine start function mode can be changed to operation with this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
TRUNK/GLASS HATCH OPEN	Reminder function (trunk lid opener request switch) mode can be changed to operation with this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
AUTO LOCK SET	Auto door lock operation time can be changed in this mode <ul style="list-style-type: none"> • MODE 1: OFF • MODE 2: 30 sec. • MODE 3: 1 minute • MODE 4: 2 minutes • MODE 5: 3 minutes • MODE 6: 4 minutes • MODE 7: 5 minutes
SHORT CRANKING OUTPUT	Starter motor can operate during the times below <ul style="list-style-type: none"> • 70 msec • 100 msec • 200 msec
CONFIRM KEY FOB ID	It can be checked whether Intelligent Key ID code is registered or not in this mode
RETRACTABLE MIRROR SET	NOTE: This item is displayed, but cannot be used
TOUCH SENSOR UNLOCK FUNCTION SETTING	One touch unlock function can be changed to operation with this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
IGN/ACC BATTERY SAVER	Ignition battery saver system mode can be changed to operation with this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation
REMOTE ENGINE START	NOTE: This item is displayed, but cannot be used
INTELLIGENT KEY LINK SET	NOTE: This item is displayed, but cannot be used
ANSWER BACK	Reminder function (door request switch and Intelligent Key) mode can be selected from the following with this mode <ul style="list-style-type: none"> • On: S mode (buzzer or horn reminder non-operation) • Off: C mode (buzzer or horn operate)

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor item	Description
ANSWER BACK I-KEY LOCK UNLOCK	Reminder function (door request switch) mode can be selected from the following with this mode <ul style="list-style-type: none"> • BUZZER: Sound Intelligent Key warning buzzer • HORN: Sound horn • Off: Only hazard warning lamp operate • INVALID: This item is displayed, but cannot be used
ANSWERBACK KEYLESS LOCK UNLOCK	Reminder function (Intelligent Key) mode can be selected from the following with this mode <ul style="list-style-type: none"> • On: Horn and hazard warning lamp operate • Off: Only hazard warning lamp operate
WELCOME LIGHT OP SET	NOTE: This item is displayed, but cannot be used

SELF-DIAG RESULT

Refer to [BCS-63, "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition
REQ SW -DR	Indicates [On/Off] condition of front door request switch (driver side)
REQ SW -AS	Indicates [On/Off] condition of front door request switch (passenger side)
REQ SW -BD/TR	Indicates [On/Off] condition of trunk lid opener request switch
PUSH SW	Indicates [On/Off] condition of push-button ignition switch
SHFTLCK SLNID PWR SPLY	Indicates [On/Off] condition of the power supply from BCM to shift lock solenoid
CLUCH SW	NOTE: This item is displayed, but cannot be monitored
BRAKE SW 1	Indicates [On/Off]* condition of stop lamp switch power supply
BRAKE SW 2	Indicates [On/Off] condition of stop lamp switch
DETE/CANCL SW	Indicates [On/Off] condition of P position
SFT PN/N SW	Indicates [On/Off] condition of P or N position
UNLK SEN -DR	Indicates [On/Off] condition of driver door UNLOCK status
PUSH SW -IPDM	Indicates [On/Off] condition of push-button ignition switch
IGN RLY1 -F/B	Indicates [On/Off] condition of ignition relay 1
DETE SW -IPDM	Indicates [On/Off] condition of P position
SFT PN -IPDM	Indicates [On/Off] condition of P or N position
SFT P -MET	Indicates [On/Off] condition of P position
SFT N -MET	Indicates [On/Off] condition of N position
ENGINE STATE	Indicates [STOP/STALL/CRANK/RUN] condition of engine states
VEH SPEED 1	Display the vehicle speed signal received from combination meter by numerical value [km/h]
VEH SPEED 2	Display the vehicle speed signal received from ABS or VDC or TCM by numerical value [km/h]
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver door status
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger door status
DOOR STAT-RR	Indicates [LOCK/READY/UNLK] condition of rear door RH status
DOOR STAT-RL	Indicates [LOCK/READY/UNLK] condition of rear door LH status
BK DOOR STATE	NOTE: This item is displayed, but cannot be monitored
ID OK FLAG	Indicates [Set/Reset] condition of Intelligent Key ID
PRMT ENG STRT	Indicates [Set/Reset] condition of engine start possibility

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Monitor Item	Condition
PRMT RKE STRT	NOTE: This item is displayed, but cannot be monitored
I-KEY OK FLAG	Indicates [KEY On/NOT On] condition of Intelligent Key ID and Intelligent Key is detected inside vehicle
PRBT ENG STRT	Indicates whether or not the engine is in start prohibited status
ID AUTHENT CANCEL TIMER	Indicates whether or not it is in engine start possible status when Intelligent Key verification is unnecessary
ACC BATTERY SAVER	Indicates [On/Off] whether or not ignition battery saver is in operation
CRNK PRBT TMR	Indicates [On/Off] whether or not in cranking prohibited status due to starter motor protection function operation
AUT CRANK TMR	Indicates [On/Off] whether or not in AUTO CRANKING MODE status
CRNK PRBT TME	Indicates the time for changing from cranking prohibited status to cranking possible status
AUT CRANK TMR	Indicates the time that AUTO CRANKING MODE operates
CRANKING TME	Indicates the cranking operation time
SHORT CRANK	NOTE: This item is displayed, but not used
DETE SW PWR	Indicates [On/Off] condition of the power supply from BCM to the A/T shift selector (detention switch)
IGN RLY3-REQ	Indicates [On/Off] condition of blower relay control signal
ACC RLY-REQ	Indicates [On/Off] condition of accessory relay control signal
RKE OPE COUN1	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing
RKE OPE COUN2	NOTE: This item is displayed, but cannot be monitored
TRNK/HAT MNTR	Indicates [On/Off] condition of trunk room lamp switch
RKE-LOCK	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-TR/BD	Indicates [On/Off] condition of trunk open signal from Intelligent Key
RKE-PANIC	Indicates [On/Off] condition of panic alarm signal from Intelligent Key
RKE-MODE CHG	NOTE: This item is displayed, but cannot be monitored
RKE PBD	NOTE: This item is displayed, but cannot be monitored

*: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

ACTIVE TEST

Test item	Description
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation <ul style="list-style-type: none"> • On: Operates • Off: Non-operation
INSIDE BUZZER	This test is able to check warning chime in combination meter operation <ul style="list-style-type: none"> • Take Out: Take away warning chime sounds when CONSULT screen is touched • Key: Key warning chime sounds when CONSULT screen is touched • Knob: OFF position warning chime sounds when CONSULT screen is touched • Off: Non-operation
INDICATOR	This test is able to check information display (combination meter) operation <ul style="list-style-type: none"> • KEY ON: [Intelligent Key system malfunction] displays when CONSULT screen is touched • KEY IND: [Steering lock unit ID registration complete] displays when CONSULT screen is touched • Off: Non-operation

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Test item	Description	
INT LAMP	This test is able to check interior room lamp operation <ul style="list-style-type: none"> • On: Operates • Off: Non-operation 	A
FLASHER	This test is able to check hazard warning lamp operation The hazard warning lamps are activated after "LH/RH/Off" on CONSULT screen is touched	B
HORN	This test is able to check horn operation <ul style="list-style-type: none"> • On: Operates 	C
IGN CONT2	This test is able to operate the blower relay in fuse block (J/B) <ul style="list-style-type: none"> • On: Operates • Off: Non-operation 	D
ENGINE SW ILLUMI	This test is able to check push-ignition switch illumination operation Push-ignition switch illumination illuminates when "On" on CONSULT screen is touched	
PUSH SWITCH INDICATOR	This test is able to check push-ignition switch indicator operation when "On" on CONSULT screen is touched	E
ACC CONT	This test is able to operate the accessory relay in fuse block (J/B) <ul style="list-style-type: none"> • On: Operates • Off: Non-operation 	F
IGN CONT1	This test is able to operate the ignition relay in IPDM E/R <ul style="list-style-type: none"> • On: Operates • Off: Non-operation 	G
IGNITION RELAY	This test is able to operate the ignition relay in fuse block (J/B) <ul style="list-style-type: none"> • On: Operates • Off: Non-operation 	H
ST CONT LOW	This test is able to operate the starter relay in IPDM E/R <ul style="list-style-type: none"> • On: Non-operation • Off: Operates 	I
BATTERY SAVER	This test is able to check interior room lamp battery saver operation <ul style="list-style-type: none"> • On: Outputs interior room lamp power supply to turn interior room lamps ON. • Off: Cuts interior room lamp power supply to turn interior room lamps OFF. 	J
TRUNK/BACK DOOR	This test is able to check trunk lid open operation. This actuator opens when "Open" on CONSULT screen is touched.	
RETRACTABLE MIRROR	NOTE: This item is displayed, but cannot be used	K
INTELLIGENT KEY LINK(CAN)	NOTE: This item is displayed, but cannot be used	
REVERSE LAMP TEST	NOTE: This item is displayed, but cannot be used	INL
DOOR HANDLE LAMP TEST	This test is able to check outside handle lamp operation <ul style="list-style-type: none"> • On: Operates • Off: Non-operation 	M
DR SEAT LAMP TEST	NOTE: This item is displayed, but cannot be used	N
AS SEAT LAMP TEST	NOTE: This item is displayed, but cannot be used	
SHIFT SPOT LAMP TEST	NOTE: This item is displayed, but cannot be used	O
TRUNK/LUGGAGE LAMP TEST	This test is able to check trunk room lamp operation <ul style="list-style-type: none"> • On: Operates • Off: Non-operation 	P
KEYFOB P/W TEST	This test is able to check keyless power window up/down operation <ul style="list-style-type: none"> • Up: Non-operation • Down*: Power window and sunroof open • Off: Non-operation 	
SHIFTLOCK SORENOID TEST	NOTE: This item is displayed, but cannot be used	

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

* : When ignition switch is OFF, driver door opened, power window and sunroof is closed.

BCM

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM

List of ECU Reference

INFOID:0000000012789615

ECU	Reference
BCM	BCS-36, "Reference Value"
	BCS-61, "Fail-safe"
	BCS-62, "DTC Inspection Priority Chart"
	BCS-63, "DTC Index"

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

INTERIOR ROOM LAMP CONTROL SYSTEM


< WIRING DIAGRAM >

WIRING DIAGRAM

INTERIOR ROOM LAMP CONTROL SYSTEM

Wiring Diagram

INFOID:000000012789616




2016/02/15

JRLWG0828GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >




JRLWG0829GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >




JRLWG0830GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	L	-
4	LG	-
5	Y	-
6	R	-
7	V	-
8	LG	-
10	BG	-
11	BG	-
12	LG	-
13	GR	-
14	R	-
15	L	-
16	V	-
18	W	-
19	BR	-
20	W	-
22	R	-
23	V	-
24	R	- [With 2.0L turbo gasoline engine]
24	X	- [With VR30 engine]
25	P	- [With 2.0L turbo gasoline engine (without gateway)]
25	V	- [With 2.0L turbo gasoline engine and with gateway]
26	G	- [With VR30 engine]
27	R	-
28	R	-
31	B	- [With VR30 engine]
31	BR	- [With 2.0L turbo gasoline engine]
32	B	-
33	B	-
34	LG	-
35	P	-
36	W	-

37	SB	-
38	LG	-
40	P	-
41	SB	-
42	BR	-
43	BG	-
44	BG	-
46	R	-
50	W	-
51	SB	-
52	V	-
53	LG	-
54	R	-
55	R	-
57	W	-
58	W	-
59	GR	-
60	G	-
61	G	-
62	BG	-
63	BR	-
64	Y	-
66	R	-
70	R	-
71	W	-
72	B	-
73	W	-
74	L	-
75	V	- [Without paddle shift]
75	V	- [With paddle shift]
76	BR	-
77	B	-
78	SB	-
79	V	-
79	W	- [With 2.0L turbo gasoline engine]
81	B	-
82	R	-
83	BG	-
84	L	-
85	R	- [Without paddle shift]
85	V	- [With paddle shift]
86	B	-
88	G	-
89	V	- [With 2.0L turbo gasoline engine]
89	W	- [With VR30 engine]
91	GR	-
94	GR	-
96	Y	-
97	V	-

98	BR	- [With VR30 engine and with BOSE system]
98	Y	- [Except with VR30 engine and with BOSE system]

Connector No.	B42
Connector Name	FRONT DOOR SWITCH (DRIVER SIDE)
Connector Type	TH04FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	V	-

Connector No.	B44
Connector Name	REAR DOOR SWITCH LH
Connector Type	TH04FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	W	-

Connector No.	B62
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	- [With 2.0L turbo gasoline engine and without BOSE system]
1	LG	- [With VR30 engine]
1	W	- [With 2.0L turbo gasoline engine and with BOSE system]
2	L	- [With VR30 engine]
2	SHIELD	- [With 2.0L turbo gasoline engine]
3	BR	- [With VR30 engine and with BOSE system]
3	R	- [With 2.0L turbo gasoline engine]
3	W	- [With VR30 engine and without BOSE system]
4	SHIELD	- [With VR30 engine]
4	Y	- [With 2.0L turbo gasoline engine]
5	G	- [With VR30 engine and without BOSE system]
5	V	- [With 2.0L turbo gasoline engine]
6	BG	- [With VR30 engine]
6	BR	- [With 2.0L turbo gasoline engine]
7	B	- [With 2.0L turbo gasoline engine and with BOSE system]
7	BR	- [With VR30 engine and without BOSE system]
7	W	- [With VR30 engine and with BOSE system]
7	Y	- [With 2.0L turbo gasoline engine and without BOSE system]
8	B	- [With VR30 engine and with BOSE system]
8	G	- [With 2.0L turbo gasoline engine]
8	Y	- [With VR30 engine and without BOSE system]
9	LG	- [With 2.0L turbo gasoline engine]
9	SHIELD	- [With VR30 engine]
10	V	-
11	GR	-
12	Y	-
13	R	-
14	BG	-
15	BG	- [With 2.0L turbo gasoline engine]
15	GR	- [With VR30 engine]
16	V	-
17	P	-
18	L	-
19	R	-
20	GR	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

JRLWG0831GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

INTERIOR ROOM LAMP CONTROL SYSTEM

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	ANT+
2	GR	ANT-

Connector No.	Signal Name [Specification]
878	REAR DOOR SWITCH RH

Connector No.	Signal Name [Specification]
TH06FW/NH	

Terminal No.	Color Of Wire	Signal Name [Specification]
3	R	

Connector No.	Signal Name [Specification]
B116	JOINT CONNECTOR-806

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	ANT+
2	GR	ANT-

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	
2	L	
3	L	
4	L	
5	L	
6	L	
7	R	
8	R	
9	R	
10	V	
11	V	
12	V	
13	V	
14	V	
15	V	
16	V	
17	V	
18	V	
19	V	
20	V	
21	V	
22	V	
23	V	
24	V	
25	V	
26	V	
27	V	
28	V	
29	V	
30	V	
31	V	
32	V	
33	V	
34	V	
35	V	
36	V	
37	V	
38	V	
39	V	
40	V	
41	V	
42	V	
43	V	
44	V	
45	V	
46	V	
47	V	
48	V	
49	V	
50	V	
51	V	
52	V	
53	V	
54	V	
55	V	
56	V	
57	V	
58	V	
59	V	
60	V	
61	V	
62	V	
63	V	
64	V	
65	V	
66	V	
67	V	
68	V	
69	V	
70	V	
71	V	
72	V	
73	V	
74	V	
75	V	
76	V	
77	V	
78	V	
79	V	
80	V	
81	V	
82	V	
83	V	
84	V	
85	V	
86	V	
87	V	
88	V	
89	V	
90	V	
91	V	
92	V	
93	V	
94	V	
95	V	
96	V	
97	V	
98	V	
99	V	
100	V	

Terminal No.	Color Of Wire	Signal Name [Specification]
11	V	
12	P	
13	R	
14	SHIELD	
15	B	
16	SHIELD	
17	SHIELD	
18	L	
19	SHIELD	
20	L	
21	L	
22	P	
23	P	
24	P	
25	Y	

Connector No.	Signal Name [Specification]
B118	JOINT CONNECTOR-804

Connector Type	Signal Name [Specification]
24342_4GAZA	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	
2	SHIELD	
3	SHIELD	
4	SHIELD	
5	SHIELD	
6	SHIELD	
7	R	

Terminal No.	Color Of Wire	Signal Name [Specification]
7	V	
8	LG	
9	R	
10	V	
11	LG	
12	SHIELD	
13	L	
14	P	
15	L	
16	L	
17	L	
18	L	
19	SHIELD	
20	L	
21	L	
22	R	
23	R	
24	R	

Connector No.	Signal Name [Specification]
D1	FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE)

Connector Type	Signal Name [Specification]
ED0FGY-RS	

Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	
2	LG	
3	W	
4	B	
5	V	
6	V	

Connector No.	Signal Name [Specification]
D4	WIRE TO WIRE

Connector Type	Signal Name [Specification]
NH60FW-1S12	

Terminal No.	Color Of Wire	Signal Name [Specification]
2	S8	
4	BG	
5	R	
6	V	
7	LG	
8	G	
9	GR	
10	Y	
11	SHIELD	
12	B6	
13	L	
14	B	
15	Y	
16	GR	
17	R	
18	GR	
19	R	
20	W	
21	LG	
22	W	
23	L	
24	G	
25	BR	
26	R	
27	BR	
28	V	

A B C D E F G H I J K L M N O P

INL

JRLWG0833GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

INTERIOR ROOM LAMP CONTROL SYSTEM


29	B	-	-
30	W	-	-
31	P	-	-
32	Y	-	-
33	BR	-	-
34	L	-	-
35	R	-	-
36	GR	-	-
37	G	-	-
40	LG	-	- (Color of wire differs depending on production)
40	P	-	- (Color of wire differs depending on production)
41	L	-	-
43	BG	-	-
44	Y	-	-
46	W	-	-
47	R	-	-
49	BR	-	-
50	B	-	-
52	V	-	-
53	GR	-	-
55	GR	-	- (Color of wire differs depending on production)
55	SB	-	- (Color of wire differs depending on production)
56	BR	-	-
57	R	-	-
58	L	-	-
59	V	-	-
60	G	-	-
61	BG	-	-
62	Y	-	-
63	SB	-	-
64	B	-	-
65	Y	-	-
66	BR	-	-
68	Y	-	-
69	L	-	-
70	W	-	-
71	LG	-	-
72	P	-	-

Connector No.	D5
Connector Name	FRONT COURSE INJECTOR ASSEMBLY (DRIVER SIDE)
Connector Type	RHD4FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	B	-
3	BR	-
4	GR	-

Connector No.	D8
Connector Name	POWER WINDOW MAIN SWITCH
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3	V	ENCODER POWER SUPPLY
4	Y	IGNITION POWER SUPPLY
5	G	FRONT POWER WINDOW MOTOR (DRIVER SIDE) DOWN SIGNAL
6	L	FRONT POWER WINDOW MOTOR (DRIVER SIDE) UP SIGNAL
7	b	GROUND
9	BR	BATTERY POWER SUPPLY
10	B	ENCODER GROUND
11	GR	ENCODER SIGNAL 1
12	BR	ENCODER SIGNAL 2
13	SB	POWER WINDOW SERIAL LINK
15	V	DOOR KEY CYLINDER SWITCH LOCK SIGNAL
16	Y	DOOR KEY CYLINDER SWITCH UNLOCK SIGNAL

Connector No.	D10
Connector Name	FRONT REAR DOOR UNLOCK ASSEMBLY (DRIVER SIDE)
Connector Type	RHD4FLGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	R	-
3	B	-
4	L	-

Connector No.	D16
Connector Name	STEP LAMP (DRIVER SIDE)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	Y	-

Connector No.	D18
Connector Name	WIRE TO WIRE
Connector Type	NH60FW-TS12



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	P	-
4	SB	-
5	BR	-
6	Y	-
7	LG	-
8	W	-
9	L	-
10	L	-
11	GR	-
13	Y	-
14	R	-
16	R	-
17	B	-
18	W	-
19	B	-
20	G	-
21	SHIELD	-
22	GR	-
23	BG	-
24	B	-
25	BR	-
26	V	-
27	G	-
28	V	-
29	Y	-
30	R	-
49	LG	-
52	P	-
55	L	-
56	Y	-
57	R	-
58	SB	-
59	R	-
60	G	-
63	B	-

JRLWG0834GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

INTERIOR ROOM LAMP CONTROL SYSTEM

64	Y	-	-	ENCODER SIGNAL 2
65	BR	-	-	POWER WINDOW SERIAL LINK
66	GR	-	-	
69	W	-	-	
70	L	-	-	
71	BG	-	-	
72	Y	-	-	

Connector No.	D19
Connector Name	FRONT OUTSIDE HANDLE ASSEMBLY (PASSENGER SIDE)
Connector Type	RH04FB




Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	B	-
3	BR	-
4	GR	-

Connector No.	D21
Connector Name	FRONT POWER WINDOW SWITCH (PASSENGER SIDE)
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	ENCODER GROUND
4	V	ENCODER POWER SUPPLY
8	L	FRONT POWER WINDOW MOTOR (PASSENGER SIDE) UP SIGNAL
9	G	FRONT POWER WINDOW MOTOR (PASSENGER SIDE) DOWN SIGNAL
10	Y	IGNITION POWER SUPPLY
11	B	GROUND
12	GR	ENCODER SIGNAL 1

Connector No.	E25
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
6	V	-
7	L	-
8	BG	- [With VR30 engine]
8	BR	- [With 2.0L turbo gasoline engine]
9	B	- [With 2.0L turbo gasoline engine]
9	GR	- [With VR30 engine] [Color of wire differs depending on production]
9	LG	- [With VR30 engine] [Color of wire differs depending on production]
10	BR	-
11	L	-
12	GR	- [With VR30 engine]
12	P	- [With 2.0L turbo gasoline engine]
13	SHIELD	- [With 2.0L turbo gasoline engine]
13	W	- [With VR30 engine]
14	B	-
15	GR	- [With 2.0L turbo gasoline engine]
15	S8	- [With VR30 engine]
16	BR	- [With 2.0L turbo gasoline engine]
16	Y	- [With VR30 engine]
17	BR	- [With VR30 engine]
17	GR	- [With 2.0L turbo gasoline engine]
18	G	- [With 2.0L turbo gasoline engine]
18	P	- [With VR30 engine]
19	V	-
31	W	- [With 2.0L turbo gasoline engine]
31	Y	- [With VR30 engine]
32	G	- [With 2.0L turbo gasoline engine]
32	GR	- [With VR30 engine]
33	L	- [With VR30 engine]
33	Y	- [With 2.0L turbo gasoline engine]
34	P	-
35	GR	-
36	R	-
37	L	- [With 2.0L turbo gasoline engine]
37	V	- [With VR30 engine]
38	L	- [With VR30 engine]

Connector No.	D30
Connector Name	STEP LAMP (PASSENGER SIDE)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	Y	-

38	P	- [With 2.0L turbo gasoline engine and without gateway]
38	BR	- [With 2.0L turbo gasoline engine and with gateway]
39	R	- [With 2.0L turbo gasoline engine]
39	Y	- [With VR30 engine]
40	S8	-
41	LG	-
44	Y	-
45	L	- [With 2.0L turbo gasoline engine]
45	W	- [With VR30 engine]
46	B	- [With VR30 engine]
46	Y	- [With 2.0L turbo gasoline engine]
47	G	-
48	SHIELD	-
49	R	-
50	BR	- [With VR30 engine]
50	GR	- [With 2.0L turbo gasoline engine]
51	L	-
52	W	-
53	V	-
54	P	- [With VR30 engine]
54	W	- [With 2.0L turbo gasoline engine]
55	B	- [With VR30 engine]
55	W	- [With 2.0L turbo gasoline engine]
56	BG	- [With 2.0L turbo gasoline engine]
56	S8	- [With VR30 engine]
57	BG	- [With VR30 engine]
57	W	- [With 2.0L turbo gasoline engine]
58	B	- [Color of wire differs depending on production]
58	B/W	- [Color of wire differs depending on production]
59	W	-
61	R	-
64	Y	-
65	BR	- [Color of wire differs depending on production]
65	GR	- [Color of wire differs depending on production]
66	GR	-
67	LG	-
68	BG	-
69	L	-
70	R	-
71	G	- [With 2.0L turbo gasoline engine]
71	LG	- [With VR30 engine]
72	L	- [With 2.0L turbo gasoline engine]
72	V	- [With VR30 engine]
73	G	- [With VR30 engine]
73	W	- [With 2.0L turbo gasoline engine]
74	BR	- [With VR30 engine]
74	L	- [With 2.0L turbo gasoline engine]
75	P	- [With 2.0L turbo gasoline engine and without gateway]
75	R	- [With 2.0L turbo gasoline engine and with gateway]
75	V	- [With VR30 engine]

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

INTERIOR ROOM LAMP CONTROL SYSTEM

76	G	-	-
77	Y	-	-
78	LG	- [With 2.0L turbo gasoline engine and with ADAS]	-
78	P	- [With VR30 engine]	-
78	V	- [With 2.0L turbo gasoline engine and without ADAS]	-
79	SB	-	- [Without Gateway]
80	G	-	- [Without Gateway]
81	R	-	-
82	V	-	- [Without Gateway]
83	BR	- [With 2.0L turbo gasoline engine]	-
83	R	- [With VR30 engine]	-
84	LG	-	- [With VR30 engine]
86	BG	-	-
87	G	-	-
89	LG	-	-
90	G	- [With VR30 engine]	-
90	GR	- [With 2.0L turbo gasoline engine]	-
91	G	-	-
93	BG	-	-
94	GR	- [With VR30 engine]	-
94	L	- [With 2.0L turbo gasoline engine]	-
95	BG	- [With VR30 engine]	-
95	P	- [With 2.0L turbo gasoline engine and without gateway]	-
95	R	- [With 2.0L turbo gasoline engine and with gateway]	-
96	W	-	-
97	LG	-	-
98	L	-	-
99	LG	- [With 2.0L turbo gasoline engine]	-
99	P	- [With VR30 engine]	-
100	SHIELD	-	-


Connector No.	E220
Connector Name	JOINT CONNECTOR-E05
Connector Type	MH24FF-J



Terminal No.	Color	Wire	Signal Name (Specification)
3	W	-	-
4	L	-	-
7	W	-	-
8	L	-	-


11	W	-	-
12	L	-	- [Without Gateway]
15	P	-	- [Without Gateway]
16	R	-	- [With Gateway]
15	L	-	- [Without Gateway]
19	P	-	- [Without Gateway]
19	R	-	- [Without Gateway]
20	L	-	-
23	P	-	- [Without Gateway]
23	R	-	- [With Gateway]
24	L	-	-

Connector No.	M13
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Terminal No.	Color	Wire	Signal Name (Specification)
1	R	-	PUSH SW
3	Y	-	SENS PWRSPLY
4	BG	-	OPTICAL SENSOR
5	LG	-	-
10	W	-	COMBI SW OUTPUT 5
11	SB	-	COMBI SW OUTPUT 4
12	L	-	COMBI SW OUTPUT 3
13	G	-	COMBI SW OUTPUT 2
14	P	-	COMBI SW OUTPUT 1
15	G	-	ONE TOUCH UNLK SENS (DR)
16	G	-	ONE TOUCH UNLK SENS (PASS)
17	P	-	RECEIVER/SENSOR GND
18	L	-	SECURITY IND LAMP CONT
20	R	-	DETENT SW
21	SB	-	STEP LAMP CONT
25	R	-	STOP LAMP SWZ
26	R	-	EXTENDED STORAGE FUSE SW
27	P	-	STOP LAMP SW
30	W	-	DR DOOR UNLK SENS
33	V	-	TR LID OP-CANCEL SW
36	G	-	HAZARD SW
39	BR	-	P/N POSITION

Connector No.	M14
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH




Terminal No.	Color	Wire	Signal Name (Specification)
48	R	-	PUSH-BTN IGN SW (LL PWR)
52	G	-	DONGLE LINK
54	V	-	COMMI LINE
55	R	-	RAIN SENSOR
59	P	-	CAN-L
60	L	-	CAN-H
61	G	-	REAR WINDOW DEF RLY CONT
62	R	-	STARTER RLY CONT
64	V	-	L-KEY WARN BUZZER
65	B	-	OUTS HD LAMP CONT
66	B	-	BLOWER FAN RLY CONT [With VR30 engine]
66	Y	-	BLOWER FAN RLY CONT [With 2.0L turbo gasoline engine]
67	W/B	-	IGN RLYAY (F/B) CONT
68	R	-	DIMMER
69	GR	-	A/T SHIFT SELECT PWRSPLY
70	B	-	IGN RLYAY (IPDM E/R) CONT
71	G	-	DR DOOR REQ SW
72	SB	-	PASS DOOR REQ SW
75	BR	-	COMBI SW INPUT 5
76	BG	-	COMBI SW INPUT 4
77	V	-	COMBI SW INPUT 3
78	Y	-	COMBI SW INPUT 2
79	LG	-	COMBI SW INPUT 1
80	L	-	TR LID OP-PR SW

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH24FB-NH



Terminal No.	Color	Wire	Signal Name (Specification)
105	V	-	TURN SIG RH OUTPUT (FRONT)
107	P	-	PUSH-BTN IGN SW (LL GND)
110	Y	-	ACCION IND
113	SB	-	ACC-RELAY CONT
114	LG	-	PASSENGER DOOR ANT +
115	V	-	PASSENGER DOOR ANT -

Connector No.	M15
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH24FG-VNH



Terminal No.	Color	Wire	Signal Name (Specification)
82	W	-	REAR LH DOOR SW
83	L	-	TR LID OPEN REQ SW
85	P	-	TR ROOM LAMP CONT
91	GR	-	-TRUNK LID OPEN
92	W	-	TURN SIG RH OUTPUT (SIDE-REAR)
93	G	-	REAR RH DOOR SW
94	GR	-	PASSENGER DOOR SW
96	V	-	DRIVER DOOR SW
97	R	-	TR ROOM LAMP SW
99	GR	-	INSIDE KEY ANT (TRUNK) -
100	W	-	INSIDE KEY ANT (TRUNK) +
101	BG	-	REAR BMPR ANT -
102	LG	-	REAR BMPR ANT +
103	Y	-	TURN SIG LH OUTPUT (SIDE-REAR)

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH24FB-NH



JRLWG0836GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

INTERIOR ROOM LAMP CONTROL SYSTEM

116	BR	INSIDE KEY ANT (CONSOLE) +
117	W/B	TURN SIG LFT OUTPUT (FRONT)
119	L	KYLS ENT RECEIV COMAM
121	SB	DRIVER DOOR ANT -
122	BG	DRIVER DOOR ANT +
123	R	INSIDE KEY ANT (INSTRUMENT LOWER) +
124	G	INSIDE KEY ANT (INSTRUMENT LOWER) -
126	W	MAX ANT AMP
132	W	MAX ANT AMP
128	GR	INSIDE KEY ANT (CONSOLE) -

Connector No.		M17
Connector Name		BCM (BODY CONTROL MODULE)
Connector Type		FEA09FW-FHAG-5A



131	132	133	134	135	136	137	138	139	140	141	142	143	144	145
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

Terminal No.	Color Of Wire	Signal Name [Specification]
129	LG	INT ROOM LAMP PWR SPLY
130	P	PASS DOOR UNLK OUTPUT
131	Y	BAT (FUSE)
132	V	RR, RL DOOR LK OUTPUT
133	BR	RR, RL DOOR UNLK OUTPUT
134	B	GND
135	V	FRONT DOOR FL LID LK OUTPUT
136	V	INT ROOM LAMP CONT
137	LG	FRONT DOOR FL LID UNLK OUTPUT
138	P	REAR DOORS ACT PWR SPLY (With VR30 engine)
139	W	REAR DOORS ACT PWR SPLY (With 2.0L turbo gasoline engine)
140	BR	BAT (F/L)
141	R	IGN ON
142	R	PWR SPT (BAT)
143	B	FRONT DOORS, FL LID ACT PWR SPLY
		GND

Connector No.		M19
Connector Name		WIRE TO WIRE
Connector Type		TH80MW-CS16-TM4



41	G	-
42	BR	-
43	BR	-
44	BR	-
46	BG	-
50	W	-
51	V	-
52	V	-
53	LG	-
54	R	-
55	R	-
57	W	-
58	V	-
59	BG	-
60	G	-
61	G	-
62	BG	-
63	BR	-
64	Y	-
66	R	-
70	LG	-
71	W	-
72	B	-
73	W	-
74	L	-
75	W	-
76	BR	-
77	B	-
78	S/B	-
79	P	- [With VR30 engine]
79	W	- [With 2.0L turbo gasoline engine]
81	B	-
82	R	-
83	BG	-
84	L	-
85	W	-
86	B	-
88	G	-
89	V	- [With 2.0L turbo gasoline engine]
89	W	- [With VR30 engine]
91	GR	-
94	GR	-
96	W	-
97	V	-
98	BR	- [With VR30 engine and with BOSE system]
98	Y	- [Except with VR30 engine and with BOSE system]

Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	SB	-
4	BR	-
5	Y	-
6	R	-
7	W	-
8	V	-
10	BG	-
11	BR	-
12	LG	-
13	GR	-
14	R	-
15	L	-
16	V	-
18	W	-
19	BR	-
20	W	-
22	SB	-
23	R	-
24	Y	- [With 2.0L turbo gasoline engine]
24	Y	- [With VR30 engine]
25	P	- [With 2.0L turbo gasoline engine]
25	W	- [With VR30 engine]
26	G	-
27	R	-
28	R	-
31	BR	-
32	B	-
33	B	-
34	V	-
35	P	-
36	W	-
37	SB	-
38	LG	-
40	P	-

Connector No.		M22
Connector Name		WIRE TO WIRE
Connector Type		TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	L	- [With VR30 engine]
2	SHIELD	- [With 2.0L turbo gasoline engine]
3	BR	- [With VR30 engine]
3	R	- [With 2.0L turbo gasoline engine]
4	SHIELD	- [With VR30 engine]
4	Y	- [With 2.0L turbo gasoline engine]
5	G	- [With VR30 engine]
5	V	- [With 2.0L turbo gasoline engine]
6	BG	- [With VR30 engine]
6	BR	- [With 2.0L turbo gasoline engine]
7	LG	- [With VR30 engine]
7	P	- [With 2.0L turbo gasoline engine]
8	G	- [With 2.0L turbo gasoline engine]
8	P	- [With VR30 engine]
9	LG	- [With 2.0L turbo gasoline engine]
9	V	- [With VR30 engine]
10	V	-
11	GR	-
12	V	-
13	LG	-
14	LG	-
15	BR	- [With 2.0L turbo gasoline engine]
15	P	- [With VR30 engine]
16	S/B	-
16	V	- [With DCU]
17	Y	- [Without DCU]
18	L	-
19	G	-
20	GR	-
21	R	-
22	V	-
23	L	-
24	BG	- [With 2.0L turbo gasoline engine]
24	V	- [With VR30 engine]
25	L	- [With 2.0L turbo gasoline engine]

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >


INTERIOR ROOM LAMP CONTROL SYSTEM

25	SB	- [With VR30 engine]
26	G	- [With VR30 engine]
27	W	- [With 2.0L turbo gasoline engine]
29	R	-
30	SB	- [With VR30 engine]
30	W	- [With 2.0L turbo gasoline engine]
31	SHIELD	-
32	L	-
33	B	- [With VR30 engine]
33	LG	- [With 2.0L turbo gasoline engine]
34	SHIELD	-
34	LG	- [With VR30 engine]
35	W	- [With 2.0L turbo gasoline engine]
36	R	- [With VR30 engine]
36	V	- [With 2.0L turbo gasoline engine]
37	R	- [With VR30 engine]
37	V	- [With 2.0L turbo gasoline engine]
38	W	-
39	P	- [With VR30 engine and without BOSE system]
39	R	- [With 2.0L turbo gasoline engine]
39	V	- [With VR30 engine and with BOSE system]
40	G	-
41	L	-
42	R	-
43	SHIELD	-
44	P	-
45	B	- [With 2.0L turbo gasoline engine]
45	G	- [With VR30 engine]
46	SHIELD	-
47	G	-
48	BG	- [Except with VR30 engine and with BOSE system]
48	BR	- [With VR30 engine and with BOSE system]
49	G	-
50	V	-
51	V	-
52	L	- [With 2.0L turbo gasoline engine]
52	Y	- [With VR30 engine]
53	R	-
54	GR	-
55	L	-
56	P	-
57	R	-
58	LG	-
59	SB	-
61	L	-
62	P	- [With 2.0L turbo gasoline engine]
62	V	- [With VR30 engine]
63	L	-
64	W	-

66	R	-
68	L	-
69	P	- [With 2.0L turbo gasoline engine]
71	GR	- [With VR30 engine]
71	R	- [With 2.0L turbo gasoline engine]
72	G	- [With VR30 engine]
72	V	- [With 2.0L turbo gasoline engine]
73	LG	- [With VR30 engine]
73	SHIELD	- [With 2.0L turbo gasoline engine]
74	LG	- [With VR30 engine]
74	L	- [With 2.0L turbo gasoline engine]
75	D	-
76	SB	- [With 2.0L turbo gasoline engine]
76	V	- [With VR30 engine]
77	Y	-
78	L	-
79	G	-
80	GR	- [With 2.0L turbo gasoline engine]
80	W	- [With VR30 engine]
81	B	- [With VR30 engine]
81	R	- [With 2.0L turbo gasoline engine]
82	G	- [With 2.0L turbo gasoline engine]
82	SHIELD	- [With VR30 engine]
83	R	- [With 2.0L turbo gasoline engine]
83	W	- [With VR30 engine]
84	BR	- [With VR30 engine]
84	SHIELD	- [With 2.0L turbo gasoline engine]
85	BR	- [With VR30 engine]
85	G	- [With 2.0L turbo gasoline engine]
86	R	- [With 2.0L turbo gasoline engine]
86	V	- [With VR30 engine]
87	LG	- [With 2.0L turbo gasoline engine]
87	SHIELD	- [With VR30 engine]
89	BR	- [With VR30 engine]
89	LG	- [With 2.0L turbo gasoline engine]
90	SB	- [With 2.0L turbo gasoline engine]
90	V	- [With VR30 engine]
92	L	- [With 2.0L turbo gasoline engine]
92	W	- [With VR30 engine]
93	R	- [With VR30 engine]
93	SHIELD	- [With 2.0L turbo gasoline engine]
94	R	-
95	L	- [With 2.0L turbo gasoline engine]
95	Y	- [With VR30 engine]
96	R	- [With 2.0L turbo gasoline engine]
96	W	- [With VR30 engine]
97	L	- [With VR30 engine]
97	R	- [With 2.0L turbo gasoline engine]
98	BR	-
99	BR	- [With VR30 engine and with BOSE system]


99	P	- [With 2.0L turbo gasoline engine]
99	Y	- [With VR30 engine and without BOSE system]
100	BR	- [With VR30 engine]
100	W	- [With 2.0L turbo gasoline engine]

Connector No.	IM25
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	M, CAN, L
4	B	EARTH
5	B	EARTH
6	L	CAN-H
7	V	KLINE [With 2.0L turbo gasoline engine]
7	W	IGN, SW
8	W	KLINE [With VR30 engine]
11	SB	M, CAN, H
12	L	CAN-L
13	L	CAN-H
14	P	CAN-L
16	W	POWER

Connector No.	IM27
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-WH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	FR WASH MOTOR
2	SR	OUTPUT 4
5	L	OUTPUT 3
6	B	GND
7	V	INPUT 3
8	W	OUTPUT 5
9	Y	INPUT 2
10	BG	INPUT 4
11	LG	INPUT 1
12	G	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	IM33
Connector Name	WIRE TO WIRE
Connector Type	NH60MM-TS12



Terminal No.	Color Of Wire	Signal Name [Specification]
2	W	-
4	G	-
5	G	-
6	R	-
7	R	-
8	GR	-
9	GR	-
10	GR	-
10	W	-
11	SHIELD	-
12	B	-
13	SB	-
14	LG	-
15	Y	-
16	Y	-
17	P	-
18	W/B	-
19	LG	- [With DRPO]
19	Y	- [Without DRPO]
20	V	-
21	B	-


INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

INTERIOR ROOM LAMP CONTROL SYSTEM


22	BG	- [Without DRPO]
22	G	- [With DRPO]
23	L	-
24	Y	-
25	BG	- [Without DRPO]
25	L	- [With DRPO]
26	Y	-
27	GR	-
28	V	-
29	B	-
30	W	-
31	B	-
32	SB	-
33	L	-
34	BR	-
35	LG	-
36	W	-
37	B	-
40	P	-
41	SB	-
43	W	- [Except with VR30 engine and without ISS]
43	Y	- [With VR30 engine and without ISS]
44	BG	-
46	BR	-
47	G	-
49	V	-
50	B	-
52	BR	-
53	B	-
55	BG	-
56	LG	-
57	V	-
58	R	-
59	G	-
60	L	-
61	G	-
62	R	-
63	V	-
64	R	-
65	BR	-
66	P	-
68	V	-
69	V	-
70	W	-
71	LG	-
72	V	-

Connector No.	M34
Connector Name	WIRE TO WIRE
Connector Type	NH80MW-TS12



57	G	-
58	G	-
59	LG	-
60	R	-
63	B	-
64	R	-
65	BR	-
66	V	-
69	BR	-
70	V	-
71	SB	-
72	W	-

Connector No.	M38
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TH88FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	W	-
4	B	-
5	R	-
6	P	-
7	Y	-
8	BR	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
6	W/B	-
7	V	-
8	BG	- [With VR30 engine]
8	BR	- [With 2.0L turbo gasoline engine]
9	LG	- [With VR30 engine]
9	P	- [With 2.0L turbo gasoline engine]
10	W	-
11	W	- [With VR30 engine]
11	Y	- [With 2.0L turbo gasoline engine]
12	B	- [With VR30 engine]
12	BR	- [With 2.0L turbo gasoline engine]
13	GR	- [With VR30 engine]
13	SHIELD	- [With 2.0L turbo gasoline engine]
14	B	-
15	BG	- [With 2.0L turbo gasoline engine]
15	SR	- [With VR30 engine]
16	B	-
16	BR	- [With 2.0L turbo gasoline engine]
17	LG	-
18	B	- [With VR30 engine]
18	W/B	- [With 2.0L turbo gasoline engine]
19	Y	-
31	W	-
32	G	- [With 2.0L turbo gasoline engine]
32	V	- [With VR30 engine]
33	L	- [With VR30 engine]
33	Y	- [With 2.0L turbo gasoline engine]
34	P	-
35	BG	-
36	G	-
37	B	- [With VR30 engine]
37	L	- [With 2.0L turbo gasoline engine]
38	L	- [With VR30 engine]
38	P	- [With 2.0L turbo gasoline engine and without gateway]
38	R	- [With 2.0L turbo gasoline engine and with gateway]

JRLWG0839GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

INTERIOR ROOM LAMP CONTROL SYSTEM


< WIRING DIAGRAM >

INTERIOR ROOM LAMP CONTROL SYSTEM

39	R	-	[With 2.0L turbo gasoline engine]
39	GR	-	[With VR30 engine]
40	GR	-	-
41	L	-	-
44	BR	-	-
45	L	-	[With 2.0L turbo gasoline engine]
45	W	-	[With VR30 engine]
46	G	-	[With VR30 engine]
46	Y	-	[With 2.0L turbo gasoline engine]
47	BG	-	[With 2.0L turbo gasoline engine]
47	R	-	[With VR30 engine]
48	SHIELD	-	-
49	B	-	[With VR30 engine]
49	G	-	[With 2.0L turbo gasoline engine]
50	B	-	[With 2.0L turbo gasoline engine]
50	BR	-	[With VR30 engine]
51	L	-	-
52	W	-	-
53	G	-	-
54	SB	-	[With 2.0L turbo gasoline engine]
54	Y	-	[With VR30 engine]
55	B	-	[With 2.0L turbo gasoline engine]
55	P	-	[With VR30 engine]
56	BG	-	[With VR30 engine]
56	GR	-	[With 2.0L turbo gasoline engine]
57	GR	-	[With VR30 engine]
57	P	-	[With 2.0L turbo gasoline engine]
58	B	-	-
59	SB	-	-
61	W/B	-	-
64	Y	-	-
65	R	-	-
66	P	-	[Color of wire differs depending on production]
66	V	-	[Color of wire differs depending on production]
67	LG	-	-
68	BG	-	-
69	L	-	-
70	R	-	-
71	V	-	[With VR30 engine]
71	W	-	[With 2.0L turbo gasoline engine]
72	L	-	[With 2.0L turbo gasoline engine]
72	LG	-	[With VR30 engine]
73	R	-	[With VR30 engine]
73	W	-	[With 2.0L turbo gasoline engine]
74	BR	-	[With VR30 engine]
74	L	-	[With 2.0L turbo gasoline engine]
75	B	-	[With VR30 engine]
75	P	-	[With 2.0L turbo gasoline engine and without gateway]
75	R	-	[With 2.0L turbo gasoline engine and with gateway]
76	W/B	-	-

77	SB	-	-
78	G	-	[With VR30 engine]
78	LG	-	[With 2.0L turbo gasoline engine]
79	R	-	-
80	G	-	-
81	R	-	-
82	LG	-	-
83	BR	-	[With 2.0L turbo gasoline engine]
83	R	-	[With VR30 engine]
84	V	-	-
86	V	-	-
87	G	-	-
89	V	-	-
90	G	-	[With VR30 engine]
90	V	-	[With 2.0L turbo gasoline engine]
91	W	-	-
92	G	-	-
93	BR	-	-
94	GR	-	[With VR30 engine]
94	L	-	[With 2.0L turbo gasoline engine]
95	BR	-	[With VR30 engine]
95	P	-	[With 2.0L turbo gasoline engine and without gateway]
95	R	-	[With 2.0L turbo gasoline engine and with gateway]
96	W	-	-
97	LG	-	-
98	Y	-	-
99	BR	-	[With VR30 engine]
99	LG	-	[With 2.0L turbo gasoline engine]
100	SHIELD	-	-

Connector No.	M58
Connector Name	COMBINATION METER
Connector Type	TH12FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
41	L	CAN-H
42	P	CAN-L
43	B	ILLUMINATION CONTROL SIGNAL
44	Y	FUEL LEVEL SENSOR GROUND
45	W	BATTERY POWER SUPPLY


46	BG	IGNITION SIGNAL [except with VR30 engine and without IS]
46	R	IGNITION SIGNAL [with VR30 engine and without IS]
47	SB	AV COMMUNICATION SIGNAL (H)
48	LG	AV COMMUNICATION SIGNAL (L)
51	BR	FUEL LEVEL SENSOR SIGNAL
52	B	GROUND

Connector No.	M109
Connector Name	INSIDE KEY ANTENNA (INSTRUMENT LOWER)
Connector Type	RK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	ANT+
2	G	ANT-

Connector No.	M113
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	AA004FB




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	+12V SIGNAL
2	L	SIGNAL
3	P	GND

Connector No.	M114
Connector Name	INSIDE KEY ANTENNA (CONSOLE)
Connector Type	RK02FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	ANT+
2	GR	ANT-

Connector No.	M133
Connector Name	FUSE BLOCK (I/B)
Connector Type	TH40FV-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	V	-
12C	L	-
13C	L	-
14C	Y	-
15C	R	-
16C	R	-
17C	L	-
18C	BG	- [Without DPRO]
18C	P	- [With DPRO]
19C	B	-
20C	W	-
21C	L	-
22C	L	-
23C	L	-
25C	LG	-
26C	SB	-
27C	P	-

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

INTERIOR ROOM LAMP CONTROL SYSTEM

28C	W	-	-	-	-
29C	W	-	-	-	-
2C	R	-	-	-	-
30C	R	-	-	-	-
31C	W	-	-	-	-
32C	R	-	-	-	-
33C	R	-	-	-	-
34C	W/B	-	-	-	-
35C	SB	-	-	-	-
36C	R	-	-	-	-
37C	W	-	-	-	-
38C	SB	-	-	-	-
39C	V	-	-	-	-
40C	G	-	-	-	-
4C	P	-	-	-	-
5C	P	-	-	-	-
6C	G	-	-	-	-
7C	G	-	-	-	-
8C	G	-	-	-	-
9C	V	-	-	-	-

Connector No.	M1159
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	BR	-
4	R	-
5	GR	-
6	R	- [With VR30 engine and with SS]
7	L	- [Except with VR30 engine and with SS]
8	W	-
9	SHIELD	-
10	W	-
11	R	-
12	L	-

13	G	-	-	-	-
14	Y	-	-	-	-
15	B	-	-	-	-
17	B	-	-	-	-
19	R	-	-	-	-
20	BG	-	-	-	- [Except with VR30 engine and with BOSE system]
20	BR	-	-	-	- [With VR30 engine and with BOSE system]
21	R	-	-	-	-
22	G	-	-	-	-
24	B	-	-	-	-
25	W	-	-	-	-
26	R	-	-	-	-
27	P	-	-	-	-
28	B	-	-	-	-
29	G	-	-	-	-
30	L	-	-	-	-
31	W	-	-	-	-
32	W	-	-	-	-
33	L	-	-	-	-
36	V	-	-	-	-
38	LG	-	-	-	-
40	W	-	-	-	-

Connector No.	M1160
Connector Name	WIRE TO WIRE
Connector Type	NS08FW-C5




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	LG	-
3	BR	-
4	R	-
6	B	-
7	R	-
8	V	-

Connector No.	M1171
Connector Name	JOINT CONNECTOR-M01
Connector Type	2434Z_4GA2A



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	B	-
4	B	-
5	B	-
6	B	-
7	B	-
8	B	-
9	B	-
10	G	-
11	G	-
14	B	-
15	B	-
16	SB	- [With VR30 engine]
16	Y	- [With 2.0L turbo gasoline engine]
17	SB	- [With VR30 engine]
17	Y	- [With 2.0L turbo gasoline engine]
18	SB	- [With VR30 engine]
18	Y	- [With 2.0L turbo gasoline engine]
19	G	-
20	G	-
22	LG	- [With VR30 engine]
22	SB	- [With 2.0L turbo gasoline engine]
23	LG	- [With VR30 engine]
23	SB	- [With 2.0L turbo gasoline engine]
24	LG	- [With VR30 engine]
24	SB	- [With 2.0L turbo gasoline engine]

Connector No.	M1175
Connector Name	JOINT CONNECTOR-M05
Connector Type	NH20FL-DC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	L	-
3	L	-
4	L	-
5	L	-
6	L	-
7	L	-
8	L	-
10	P	-
11	P	-
12	P	-
13	P	-
14	P	-
15	P	-
16	P	- [With VR30 engine]
16	R	- [With 2.0L turbo gasoline engine]
17	P	- [With VR30 engine]
17	R	- [With 2.0L turbo gasoline engine]
19	R	- [With VR30 engine and with SS]
19	W	- [Except with VR30 engine and with SS]
20	R	- [With VR30 engine and with SS]
20	W	- [Except with VR30 engine and with SS]

JRLWG0841GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	M177
Connector Name	JOINT CONNECTOR-M07
Connector Type	24342_4GAZA



9	5	4	3	2	1
12	11	10	9	8	7
18	17	16	15	14	13
24	23	22	21	20	19

Connector No.	M178
Connector Name	JOINT CONNECTOR-M08
Connector Type	NH20FW-9C



9	8	7	6	5	4	3	2	1	
20	18	17	16	15	14	13	12	11	10

Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	L	-
3	BR	-
6	B	-
7	SA	-
8	BG	-

Connector No.	R6
Connector Name	WIRE TO WIRE
Connector Type	TH16MW-NH



1	2	3	4	5	6	7	8
9	10	11	12	13	14	15	16

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	BR	-
3	B	-
4	V	-
6	S8	-
7	W	- [With ANC]
8	BG	- [Without ANC]
9	R	-
11	LG	-
12	G	-
13	B	-
14	L	-

Connector No.	R4
Connector Name	MAP LAMP
Connector Type	TH08FW-1V-NH



1	2	3	6	7	8
---	---	---	---	---	---

Connector No.	R14
Connector Name	WIRE TO WIRE
Connector Type	TH16FW-NH



8	7	6	5	4	3	2	1
16	15	14	13	12	11	10	9

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	GR	-
4	V	-
6	S8	-
7	W	-
8	BR	-
9	R	-
11	LG	-
12	G	-
13	B	-
14	L	-

Connector No.	R15
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	LG	-
3	BR	-
4	V	-
5	BG	-
6	GR	-
7	BR	-
9	SHIELD	-
10	GR	-

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

INTERIOR ROOM LAMP CONTROL SYSTEM

11	R	-	-	-	-
12	L	-	-	-	-
13	G	-	-	-	-
14	Y	-	-	-	-
15	B	-	-	-	-
17	SB	-	-	-	-
19	BG	-	-	-	-
20	BR	-	-	-	-
21	R	-	-	-	-
22	G	-	-	-	-
24	B	-	-	-	-
25	BG	-	-	-	-
25	P	-	-	-	-
26	BR	-	-	-	-
27	GR	-	-	-	-
28	B	-	-	-	-
29	R	-	-	-	-
30	L	-	-	-	-
31	V	-	-	-	-
32	W	-	-	-	-
33	L	-	-	-	-
36	BR	-	-	-	-
38	SB	-	-	-	-
40	W	-	-	-	-

- [Without BOSE system]
 - [With BOSE system]

- [Color of wire differs depending on production]
 - [Color of wire differs depending on production]

Connector No.	R16
Connector Name	WIRE TO WIRE
Connector Type	NS08BMW-CS



1	2	3
4	5	6
7	8	9

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	R	-
3	Y	-
4	W	-
6	B	-
7	GR	-
8	V	-

Connector No.	R21
Connector Name	PERSONAL LAMP
Connector Type	TH04FW-AH



2	3	4
---	---	---

Terminal No.	Color Of Wire	Signal Name [Specification]
2	O	-
3	BR	-
4	B/W	-

Connector No.	R23
Connector Name	VANITY MIRROR LAMP (PASSENGER SIDE)
Connector Type	MCAD2FW



1	2
---	---

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B/L	-
2	V	-

Connector No.	R24
Connector Name	VANITY MIRROR LAMP (DRIVER SIDE)
Connector Type	MCAD2FW



1	2
---	---

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B/L	-
2	V	-

Connector No.	T48
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



7	6	5	4	3	2	1
16	15	14	13	12	11	10
9	8	7	6	5	4	3
2	1	0	9	8	7	6

Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	BG	-
4	L	-
5	P	-
6	G	-
8	B	-
9	R	-
10	P	-
11	L	-
13	G	-
13	L	- [With around view monitor]
14	B	- [With rear view monitor]
14	R	- [With around view monitor]
15	B	- [With around view monitor]
15	W	- [With rear view monitor]
16	R	- [With rear view monitor]
16	W	- [With around view monitor]

Connector No.	T53
Connector Name	TRUNK LID LOCK ASSEMBLY
Connector Type	TB03FW-LC



1	2	3
---	---	---

Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	L	-
3	G	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL


ILLUMINATION

< WIRING DIAGRAM >

ILLUMINATION


Wiring Diagram

INFOID:000000012789617



ILLUMINATION

< WIRING DIAGRAM >




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

ILLUMINATION

< WIRING DIAGRAM >




JRLWG0846GB

ILLUMINATION

< WIRING DIAGRAM >

- ◊OG> : Without CAN gateway
- ◊WG> : With CAN gateway
- ◊TD> : With 2.0L turbo gasoline engine without automatic drive positioner
- ◊OD> : Except 2.0L turbo gasoline engine without automatic drive positioner
- ◊OM> : Without automatic drive positioner



JRLWG0847GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

ILLUMINATION

< WIRING DIAGRAM >

ILLUMINATION

Connector No.	B118
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-C3.16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	L	-
4	LG	-
5	Y	-
6	R	-
7	V	-
8	LG	-
10	BG	-
11	BG	-
12	LG	-
13	GR	-
14	R	-
15	L	-
16	V	-
18	W	-
19	BR	-
20	W	-
22	R	-
23	V	-
24	R	- [With 2.0L turbo gasoline engine]
24	Y	- [With VR30 engine]
25	P	- [With 2.0L turbo gasoline engine and without gateway]
25	V	- [With 2.0L turbo gasoline engine and with gateway]
25	W	- [With VR30 engine]
26	G	-
27	R	-
28	R	-
31	B	- [With VR30 engine]
31	BR	- [With 2.0L turbo gasoline engine]
32	B	-
33	B	-
34	LG	-
35	P	-
36	W	-

37	SB	-
38	LG	-
40	P	-
41	SB	-
43	BG	-
44	BG	-
46	R	-
50	W	-
51	SB	-
52	V	-
53	LG	-
54	R	-
55	R	-
57	W	-
58	V	-
59	GR	-
60	G	-
61	G	-
62	BG	-
63	BR	-
64	Y	-
66	R	-
70	R	-
71	W	-
72	B	-
73	W	-
74	L	-
75	R	- [Without paddle shift]
75	V	- [With paddle shift]
76	BR	-
77	B	-
78	SB	-
79	V	- [With VR30 engine]
79	W	- [With 2.0L turbo gasoline engine]
81	B	-
82	R	-
83	BG	-
84	L	-
85	R	- [Without paddle shift]
85	V	- [With paddle shift]
86	B	-
88	G	-
89	V	- [With 2.0L turbo gasoline engine]
89	W	- [With VR30 engine]
91	GR	-
94	GR	-
96	Y	-
97	V	-

98	BR	- [With VR30 engine and with BOSE system]
98	Y	- [Except with VR30 engine and with BOSE system]

Connector No.	B116
Connector Name	JOINT CONNECTOR-B06
Connector Type	24342_4G42A



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	L	-
3	L	-
4	L	-
5	L	-
6	L	-
7	R	-
8	R	- [With Gateway]
8	R	- [Without Gateway]
9	R	- [With Gateway]
9	V	- [Without Gateway]
10	R	- [With VR30 engine]
10	V	- [With 2.0L turbo gasoline engine]
11	V	-
12	P	-
13	R	- [With Gateway]
13	R	- [Without Gateway]
14	SHIELD	-
15	B	- [With 2.0L turbo gasoline engine]
15	B	- [With VR30 engine]
16	L	- [With VR30 engine]
16	L	- [Without VR30 engine]
17	SHIELD	- [With 2.0L turbo gasoline engine]
17	SHIELD	- [With VR30 engine]
18	L	- [With 2.0L turbo gasoline engine]
18	L	- [Without VR30 engine]
19	SHIELD	- [With 2.0L turbo gasoline engine]
19	SHIELD	- [Without VR30 engine]
20	L	- [With 2.0L turbo gasoline engine]
20	SHIELD	- [Without VR30 engine]
21	L	-

22	P	-
23	P	-
24	P	- [With VR30 engine]
24	Y	- [With 2.0L turbo gasoline engine]

Connector No.	B118
Connector Name	JOINT CONNECTOR-B04
Connector Type	24342_4G42A



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	- [With VR30 engine]
1	SHIELD	- [With 2.0L turbo gasoline engine]
2	LG	- [With VR30 engine]
2	SHIELD	- [With 2.0L turbo gasoline engine]
3	SHIELD	-
4	LG	- [With VR30 engine]
4	SHIELD	- [With 2.0L turbo gasoline engine]
5	LG	- [With VR30 engine]
5	SHIELD	- [With 2.0L turbo gasoline engine]
6	LG	- [With VR30 engine]
6	SHIELD	- [With 2.0L turbo gasoline engine]
7	R	- [Color of wire differs depending on production]
7	V	- [Color of wire differs depending on production]
8	LG	- [With 2.0L turbo gasoline engine]
8	R	- [With VR30 engine and without paddle shift]
8	V	- [With VR30 engine and with paddle shift]
9	LG	- [With 2.0L turbo gasoline engine]
9	R	- [With VR30 engine and without paddle shift]
9	V	- [With VR30 engine and with paddle shift]
10	LG	- [With 2.0L turbo gasoline engine]
10	SHIELD	- [With VR30 engine]
11	LG	- [With 2.0L turbo gasoline engine]
11	SHIELD	- [With VR30 engine]
12	LG	- [With 2.0L turbo gasoline engine]
12	SHIELD	- [With VR30 engine]
13	L	- [With VR30 engine]
13	P	- [With 2.0L turbo gasoline engine and without gateway]
13	R	- [With 2.0L turbo gasoline engine and with gateway]
14	L	- [With VR30 engine]

ILLUMINATION

< WIRING DIAGRAM >

ILLUMINATION

14	P	- [With 2.0L turbo gasoline engine and without gateway]
14	R	- [With 2.0L turbo gasoline engine and with gateway]
15	L	- [With VR30 engine]
15	R	- [With 2.0L turbo gasoline engine]
16	L	-
17	L	-
18	L	-
19	L	- [With 2.0L turbo gasoline engine]
19	SHIELD	- [With VR30 engine]
20	SHIELD	- [With 2.0L turbo gasoline engine]
21	L	- [With VR30 engine]
21	SHIELD	- [With 2.0L turbo gasoline engine]
23	R	- [With VR30 engine]
23	R	-
24	R	-

Connector No.	BI28
Connector Name	DIODE-1
Connector Type	ET02-2W



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	BG	-


Connector No.	D4
Connector Name	WIRE TO WIRE
Connector Type	NH80PW-TS12



Terminal No.	Color Of Wire	Signal Name [Specification]
2	SB	-
4	BG	-
5	R	-
6	V	-
7	LG	-
8	G	-
9	GR	-
10	Y	-
11	SHIELD	-
12	BG	-
13	L	-
14	B	-
15	Y	-
16	GR	-
17	R	-
18	GR	-
19	R	-
20	W	-
21	LG	-
22	W	-
23	L	-
24	G	-
25	BR	-
26	R	-
27	BR	-
28	V	-
29	B	-
30	W	-
31	P	-
32	Y	-
33	BR	-
34	L	-
35	R	-
36	GR	-
37	G	-
40	LG	- [Color of wire differs depending on production]

40	P	- [Color of wire differs depending on production]
41	L	-
43	BG	-
44	Y	-
46	W	-
47	R	-
49	BR	-
50	B	-
52	V	-
53	GR	-
53	GR	- [Color of wire differs depending on production]
55	SB	- [Color of wire differs depending on production]
56	BR	-
57	R	-
58	L	-
59	V	-
60	G	-
61	BG	-
62	Y	-
63	SB	-
64	B	-
65	Y	-
66	BR	-
68	Y	-
69	L	-
70	W	-
71	LG	-
72	P	-

Connector No.	D9
Connector Name	SEAT MEMORY SWITCH
Connector Type	TH16PW-WH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	BR	-
3	GR	- [Color of wire differs depending on production]
3	SB	- [Color of wire differs depending on production]
4	B	-
5	BG	-

6	W	-
7	LG	- [Color of wire differs depending on production]
7	P	- [Color of wire differs depending on production]
8	L	-
9	G	-

Connector No.	E25
Connector Name	WIRE TO WIRE
Connector Type	TH80PW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
6	V	-
7	L	-
8	BG	- [With VR30 engine]
8	BR	- [With 2.0L turbo gasoline engine]
9	B	- [With 2.0L turbo gasoline engine]
9	GR	- [With VR30 engine] [Color of wire differs depending on production]
9	LG	- [With VR30 engine] [Color of wire differs depending on production]
10	BR	-
11	L	-
12	GR	- [With VR30 engine]
12	P	- [With 2.0L turbo gasoline engine]
13	SHIELD	- [With 2.0L turbo gasoline engine]
13	W	- [With VR30 engine]
14	B	-
15	GR	- [With 2.0L turbo gasoline engine]
15	SB	- [With VR30 engine]
16	BR	- [With 2.0L turbo gasoline engine]
16	B	- [With VR30 engine]
17	BR	- [With VR30 engine]
17	GR	- [With 2.0L turbo gasoline engine]
18	G	- [With 2.0L turbo gasoline engine]
18	P	- [With VR30 engine]
19	Y	-
31	W	- [With 2.0L turbo gasoline engine]
31	Y	- [With VR30 engine]
32	G	- [With 2.0L turbo gasoline engine]
32	GR	- [With VR30 engine]
33	L	- [With VR30 engine]

A B C D E F G H I J K M N O P

INL

JRLWG0849GB

ILLUMINATION



< WIRING DIAGRAM >

ILLUMINATION

33	Y	- [With 2.0L turbo gasoline engine]
34	P	- [With 2.0L turbo gasoline engine]
35	GR	- [With VR30 engine]
36	R	- [With 2.0L turbo gasoline engine]
37	L	- [With 2.0L turbo gasoline engine and without gateway]
38	L	- [With VR30 engine]
38	P	- [With 2.0L turbo gasoline engine and without gateway]
38	R	- [With 2.0L turbo gasoline engine and with gateway]
39	BR	- [With 2.0L turbo gasoline engine]
39	X	- [With VR30 engine]
40	SB	- [With VR30 engine]
41	LG	- [With VR30 engine]
44	Y	- [With 2.0L turbo gasoline engine]
45	L	- [With VR30 engine]
45	W	- [With VR30 engine]
46	B	- [With 2.0L turbo gasoline engine]
46	Y	- [With 2.0L turbo gasoline engine]
47	G	- [With VR30 engine]
48	SHIELD	- [With VR30 engine]
49	R	- [With VR30 engine]
50	BR	- [With VR30 engine]
50	GR	- [With 2.0L turbo gasoline engine]
51	L	- [With VR30 engine]
52	W	- [With VR30 engine]
53	V	- [With VR30 engine]
54	P	- [With 2.0L turbo gasoline engine]
54	W	- [With 2.0L turbo gasoline engine]
55	B	- [With VR30 engine]
55	W	- [With VR30 engine]
56	BG	- [With 2.0L turbo gasoline engine]
56	SB	- [With VR30 engine]
57	BG	- [With VR30 engine]
57	W	- [With 2.0L turbo gasoline engine]
58	B	- [Color of wire differs depending on production]
58	B/W	- [Color of wire differs depending on production]
59	W	- [Color of wire differs depending on production]
61	R	- [With VR30 engine]
64	Y	- [Color of wire differs depending on production]
65	BR	- [Color of wire differs depending on production]
65	GR	- [Color of wire differs depending on production]
66	GR	- [Color of wire differs depending on production]
67	LG	- [Color of wire differs depending on production]
68	BG	- [Color of wire differs depending on production]
69	L	- [Color of wire differs depending on production]
70	R	- [Color of wire differs depending on production]
71	G	- [With 2.0L turbo gasoline engine]
71	LG	- [With VR30 engine]
72	L	- [With 2.0L turbo gasoline engine]
72	V	- [With VR30 engine]

73	G	- [With VR30 engine]
74	W	- [With 2.0L turbo gasoline engine]
74	BR	- [With VR30 engine]
74	L	- [With 2.0L turbo gasoline engine]
75	P	- [With 2.0L turbo gasoline engine and without gateway]
75	R	- [With 2.0L turbo gasoline engine and with gateway]
75	V	- [With VR30 engine]
76	G	- [With VR30 engine]
77	Y	- [With VR30 engine]
78	LG	- [With 2.0L turbo gasoline engine and with ADAS]
78	P	- [With VR30 engine]
78	V	- [With 2.0L turbo gasoline engine and without ADAS]
79	SB	- [With VR30 engine]
80	G	- [With VR30 engine]
81	R	- [With VR30 engine]
82	V	- [With VR30 engine]
83	BR	- [With 2.0L turbo gasoline engine]
83	R	- [With VR30 engine]
84	LG	- [With VR30 engine]
86	BG	- [With VR30 engine]
87	G	- [With VR30 engine]
89	LG	- [With VR30 engine]
90	G	- [With 2.0L turbo gasoline engine]
90	GR	- [With VR30 engine]
91	G	- [With VR30 engine]
93	BG	- [With VR30 engine]
94	GR	- [With VR30 engine]
94	L	- [With 2.0L turbo gasoline engine]
95	BG	- [With VR30 engine]
95	P	- [With 2.0L turbo gasoline engine and without gateway]
95	R	- [With 2.0L turbo gasoline engine and with gateway]
96	W	- [With VR30 engine]
97	LG	- [With VR30 engine]
98	L	- [With VR30 engine]
99	LG	- [With 2.0L turbo gasoline engine]
99	P	- [With VR30 engine]
100	SHIELD	- [With VR30 engine]

Connector No.	E47
Connector Name	WIRE TO WIRE
Connector Type	TH32MVA-NH


Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	- [Color of wire differs depending on production]
1	Y	- [Color of wire differs depending on production]
2	V	- [Color of wire differs depending on production]
3	L	- [Without Gateway]
4	P	- [Without Gateway]
4	R	- [With Gateway]
5	W	- [With Gateway]
6	SB	- [With Gateway]
7	BR	- [Color of wire differs depending on production]
7	L	- [Color of wire differs depending on production]
8	W	- [Without BOSE system]
9	BG	- [Without BOSE system]
10	V	- [With BOSE system]
11	SB	- [With BOSE system]
12	G	- [With BOSE system]
13	G	- [With BOSE system]
15	BR	- [With BOSE system]
16	P	- [With BOSE system]
17	SHIELD	- [With BOSE system]
19	Y	- [With BOSE system]
20	W	- [With BOSE system]
21	G	- [With BOSE system]
22	R	- [With BOSE system]
23	BR	- [With BOSE system]
24	R	- [With BOSE system]
25	L	- [With BOSE system]
26	BG	- [With BOSE system]
27	LG	- [With BOSE system]
28	BR	- [With BOSE system]
29	W	- [With BOSE system]
30	Y	- [With BOSE system]
31	G	- [With BOSE system]
32	GR	- [With BOSE system]

Connector No.	E64
Connector Name	FUSE BLOCK (I/B)
Connector Type	NS08FWCS




Terminal No.	Color Of Wire	Signal Name [Specification]
1E	G	- [With VR30 engine]
2E	P	- [With VR30 engine]
3E	V	- [With VR30 engine]
4E	GR	- [With VR30 engine]
6E	L	- [With VR30 engine]
7E	BG	- [With VR30 engine]

Connector No.	E120
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	NS12FWCS

Terminal No.	Color Of Wire	Signal Name [Specification]
7	B/W	- [With VR30 engine]
9	P	- [With VR30 engine]
10	LG	- [With VR30 engine]
11	V	- [With VR30 engine]
13	BG	- [With VR30 engine]
14	SB	- [With VR30 engine]
15	BR	- [With VR30 engine]
17	GR	- [With VR30 engine]
18	L	- [With VR30 engine]

JRLWG0850GB

ILLUMINATION

< WIRING DIAGRAM >

ILLUMINATION

Connector No.	E123
Connector Name	IPM FOR INTELLIGENT POWER DISTRIBUTION MOBILE ENGINE (RODM)
Connector Type	TH32FW-AH



13	22	23	27	28	29	31	32	33	34
35	36	37	38	39	41	43			

Terminal No.	Color Of Wire	Signal Name [Specification]
19	L	- [With 2.0L turbo gasoline engine]
19	P	- [With VR30 engine]
22	BG	-
23	GR	- [With VR30 engine]
23	LG	- [With 2.0L turbo gasoline engine and without Anti theft device]
23	P	- [With 2.0L turbo gasoline engine and with Anti theft device]
27	GR	-
28	P	-
29	L	-
31	G	-
32	SB	-
33	SB	-
34	Y	-
35	G	-
36	SB	- [With VR30 engine]
36	W	- [With 2.0L turbo gasoline engine]
37	GR	-
38	BR	-
41	GR	-
43	V	-

Connector No.	E126
Connector Name	IPM FOR INTELLIGENT POWER DISTRIBUTION MOBILE ENGINE (RODM)
Connector Type	TH16FW-AH



80	83	94	96
----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
85	L	-
90	BR	-
93	V	-
94	Y	-
96	P	- [With VR30 engine]
96	SB	- [With 2.0L turbo gasoline engine]

Connector No.	E195
Connector Name	WIRE TO WIRE
Connector Type	TK36FW-MS10



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
5	BR	-
8	GR	-
8	P	-
10	R	-
11	L	-
12	P	-
13	GR	-
14	Y	-
15	G	-
16	W	-
17	L	-
18	R	-
19	BR	-
20	SHIELD	-

21	BR	-
22	V	-
23	W	-
24	L	-
25	G	-
26	G	-
30	V	-
31	GR	-
32	SB	-
33	W	-
34	W	-
35	B	-
35	G	-
37	SHIELD	-
38	R	-
39	L	-
40	GR	-
41	W	-
42	B	-
43	BR	-
44	P	-
45	SB	-
46	Y	-

Connector No.	E220
Connector Name	JOINT CONNECTOR-E05
Connector Type	NH24FB-J



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
3	W	-
4	L	-
7	W	-
7	W	-
8	L	-
8	L	-
11	W	-
12	L	-
15	P	- [Without Gateway]
15	R	- [With Gateway]
16	L	-
19	P	- [Without Gateway]
19	R	- [With Gateway]

20	L	-
23	P	- [Without Gateway]
23	R	- [With Gateway]
24	L	-

Connector No.	IM1
Connector Name	INTEGRAL SWITCH
Connector Type	TH24FW-AH



2	3	4	7	8
13	14	15	16	18
19	20			

Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	ILLUMINATION SIGNAL
3	LG	AV COMM (L)
4	SB	AV COMM (H)
7	W/B	DISK EJECT SIGNAL
8	G	HAZARD SIGNAL
13	B	GND
14	SB	ACC [For 2.0L turbo gasoline engine]
15	B	ILLUMINATION CONTROL SIGNAL
16	BG	DISK EJECT SIGNAL GROUND
18	R	IGN [For VR30 engine]
18	W	IGN [For 2.0L turbo gasoline engine]
19	BR	CAMERA SWITCH SIGNAL
20	LG	AIR BAG INDICATOR OFF SIGNAL


A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

ILLUMINATION

< WIRING DIAGRAM >

ILLUMINATION

Connector No.	M17
Connector Name	A/T SHIFT SELECTOR
Connector Type	TH12FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	-
2	GR	-
3	BG	-
4	B	-
5	G	-
7	R	-
8	P	- [With VR30 engine]
9	B	- [With 2.0L turbo gasoline engine]
10	GR	-
11	R	-


Connector No.	M13
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FG-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	PUSH SW
2	Y	SENS PWR SPLY
3	Y	OPTICAL SENSOR
4	BG	-
5	LG	-
10	W	COMBI SW OUTPUT 5
11	SB	COMBI SW OUTPUT 4
12	L	COMBI SW OUTPUT 3
13	G	COMBI SW OUTPUT 2
14	P	COMBI SW OUTPUT 1

15	G	ONE TOUCH UNLK SENS (DR)
16	G	ONE TOUCH UNLK SENS (PASS)
17	P	RECEIVER/SENSOR GND
18	L	SECURITY IND LAMP CONT
20	R	DEFLECT SW
21	SB	STEP LAMP SW
25	R	STOP LAMP SW
26	R	EXTENDED STORAGE FUSE SW
27	P	STOP LAMP SW
30	W	DR DOOR UNLK SENS
32	V	TR ID OP CANCEL SW
36	G	HAZARD SW
39	BR	7/A POSITION

Connector No.	M14
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
48	R	PUSH BTN IGN SW ILL PWR
52	G	DOOR LOCK
54	V	COMM LINE
55	R	RAIN SENSOR
59	P	CANL
60	L	CANH
61	G	REAR WINDOW DEF RLY CONT
62	R	STARTER RLY CONT
64	V	LKEY WARN BUZZER
65	B	OUTS HD LAMP CONT
66	B	BLOWER FAN RLY CONT (With VR30 engine)
67	Y	BLOWER FAN REC CONT (With 2.0L turbo gasoline engine)
68	R	IGN RELAY (F/B) CONT
69	GR	DIMMER
70	B	A/T SHIFT SELECT PWR SPLY
71	G	IGN RLYAY (PDM/E/R) CONT
72	SB	DR DOOR REQ SW
75	BR	PASS DOOR REQ SW
76	BG	COMBI SW INPUT 5
77	V	COMBI SW INPUT 3

78	Y	COMBI SW INPUT 2
79	LG	COMBI SW INPUT 1
80	L	TR ID OPNR SW

Connector No.	M16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH24FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
105	V	TURN SIG RH OUTPUT (FRONT)
107	P	PUSH BTN IGN SW ILL GND
111	Y	ACC/ON IND
113	SB	ACC RELAY CONT
114	LG	PASSENGER DOOR ANT +
115	V	PASSENGER DOOR ANT -
116	BR	INSIDE KEY ANT (CONSOLE) +
117	W/B	INSIDE KEY ANT (CONSOLE) -
119	L	TURN SIG LH OUTPUT (FRONT)
121	SB	DRIVER DOOR ANT +
122	BG	DRIVER DOOR ANT -
123	R	INSIDE KEY ANT (INSTRUMENT LOWER) +
124	G	INSIDE KEY ANT (INSTRUMENT LOWER) -
126	B	NATS ANT AMP
127	W	NATS ANT AMP
128	GR	INSIDE KEY ANT (CONSOLE) -

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEAD9FW-FHAG-5A



Terminal No.	Color Of Wire	Signal Name [Specification]
129	LG	INT ROOM LAMP PWR SPLY
130	P	PASS DOOR UNLK OUTPUT
131	Y	BAT (FUSE)
132	V	RR, RL DOOR LK OUTPUT
133	BR	RR, RL DOOR UNLK OUTPUT
134	B	GND
135	V	FRONT DOOR, FL LID LK OUTPUT
136	V	INT ROOM LAMP CONT
137	LG	FRONT DOOR, FL LID UNLK OUTPUT
138	P	REAR DOORS ACT PWR SPLY (With VR30 engine)
139	R	REAR DOORS ACT PWR SPLY (With 2.0L turbo gasoline engine)
139	W	BAT (F/L)
140	BR	IGN ON
141	R	PWR SPLY (BAT)
142	R	FRONT DOORS, FL LID ACT PWR SPLY
143	B	GND

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-1M4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	SB	-
4	BR	-

ILLUMINATION


< WIRING DIAGRAM >

ILLUMINATION

5	Y	-	-	-	-
6	R	-	-	-	-
7	W	-	-	-	-
8	V	-	-	-	-
10	BG	-	-	-	-
11	BR	-	-	-	-
12	LG	-	-	-	-
13	GR	-	-	-	-
14	L	-	-	-	-
15	R	-	-	-	-
16	V	-	-	-	-
18	W	-	-	-	-
19	BR	-	-	-	-
20	W	-	-	-	-
22	S8	-	-	-	-
23	R	-	-	-	-
24	R	-	-	-	-
25	P	-	-	-	-
26	G	-	-	-	-
27	R	-	-	-	-
28	R	-	-	-	-
31	BR	-	-	-	-
32	B	-	-	-	-
33	B	-	-	-	-
34	V	-	-	-	-
35	P	-	-	-	-
36	W	-	-	-	-
37	S8	-	-	-	-
38	LG	-	-	-	-
40	P	-	-	-	-
41	G	-	-	-	-
42	BR	-	-	-	-
43	BR	-	-	-	-
44	BR	-	-	-	-
46	BG	-	-	-	-
50	W	-	-	-	-
51	V	-	-	-	-
52	V	-	-	-	-
53	LG	-	-	-	-
54	R	-	-	-	-
55	R	-	-	-	-
57	W	-	-	-	-
58	BG	-	-	-	-
59	BG	-	-	-	-
60	G	-	-	-	-
61	G	-	-	-	-
62	BG	-	-	-	-
63	BR	-	-	-	-

64	Y	-	-	-	-
66	R	-	-	-	-
70	LG	-	-	-	-
71	W	-	-	-	-
72	B	-	-	-	-
73	W	-	-	-	-
74	L	-	-	-	-
75	W	-	-	-	-
76	BR	-	-	-	-
77	B	-	-	-	-
78	S8	-	-	-	-
79	P	-	-	-	-
79	W	-	-	-	-
81	B	-	-	-	-
82	R	-	-	-	-
83	BG	-	-	-	-
84	L	-	-	-	-
85	W	-	-	-	-
86	B	-	-	-	-
88	G	-	-	-	-
89	V	-	-	-	-
89	W	-	-	-	-
91	GR	-	-	-	-
94	GR	-	-	-	-
96	W	-	-	-	-
97	V	-	-	-	-
98	BR	-	-	-	-
98	Y	-	-	-	-

Connector No. M27
Connector Name COMBINATION SWITCH
Connector Type TH16FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	FR WASH MOTOR
2	SB	OUTPUT 4
5	L	OUTPUT 3
6	B	GND
7	V	INPUT 3
8	W	OUTPUT 5

9	Y	INPUT 2
10	BG	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	IME3
Connector Name	WIRE TO WIRE
Connector Type	IM160MW-1S12



Terminal No.	Color Of Wire	Signal Name [Specification]
2	W	-
4	G	-
5	G	-
6	R	-
7	R	-
8	GR	-
9	GR	-
10	W	-
11	SHIELD	-
12	P	-
13	S8	-
14	LG	-
15	Y	-
16	Y	-
17	P	-
18	W/B	-
18	LG	- [With DRPO]
19	Y	- [Without DRPO]
20	V	-
21	B	-
22	BG	- [Without DRPO]
22	G	- [With DRPO]
23	L	-
24	Y	-
25	BG	- [Without DRPO]
25	L	- [With DRPO]
26	Y	-
27	GR	-

28	V	-	-
29	B	-	-
30	W	-	-
31	B	-	-
32	S8	-	-
33	L	-	-
34	BR	-	-
35	LG	-	-
36	W	-	-
37	B	-	-
40	P	-	-
41	S8	-	-
43	W	-	-
43	Y	-	-
44	BG	-	-
46	BR	-	-
47	G	-	-
49	V	-	-
50	B	-	-
52	BR	-	-
53	B	-	-
53	BG	-	-
56	LG	-	-
57	V	-	-
58	R	-	-
59	G	-	-
60	L	-	-
61	G	-	-
62	R	-	-
63	V	-	-
64	B	-	-
65	R	-	-
66	BR	-	-
68	P	-	-
69	V	-	-
70	W	-	-
71	LG	-	-
72	V	-	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

ILLUMINATION

< WIRING DIAGRAM >

ILLUMINATION

Connector No.	M35
Connector Name	DRIVE MODE SELECT SWITCH
Connector Type	TH08FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	W/B	-
3	SB	-
4	R	-
5	B	-

Connector No.	M38
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TH08FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
3	W	-
4	B	-
5	R	-
6	P	-
7	Y	-
8	BR	-

Connector No.	M39
Connector Name	WIRE TO WIRE
Connector Type	TH32FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W/B	-
2	SB	-
3	L	-
4	P	- [Without Gateway]
4	R	- [With Gateway]
5	BR	-
6	SB	-
7	L	-
8	W	-
9	P	- [Without BOSE system]
9	V	- [With BOSE system]
10	V	-
11	SB	-
12	G	-
13	G	-
15	R	-
16	SB	-
17	SHIELD	-
18	W	-
19	Y	-
20	L	-
21	G	-
22	R	-
23	BR	-
24	R	-
25	L	-
26	Y	-
27	LG	-
28	BR	-
29	W/B	-
30	Y	-
31	W	-
32	L	- [With Anti-theft diode]
32	LG	- [Without Anti-theft diode]

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BS	-
6	W/B	-
7	V	-
8	BS	- [With VR30 engine]
8	BR	- [Without VR30 engine]
9	LG	- [With VR30 engine]
9	P	- [Without VR30 engine]
10	W	-
11	W	- [With VR30 engine]
11	Y	- [Without VR30 engine]
12	B	- [With 2.0L turbo gasoline engine]
12	BR	- [With 2.0L turbo gasoline engine]
13	GR	- [With VR30 engine]
13	SHIELD	- [Without VR30 engine]
14	B	-
15	BS	- [With 2.0L turbo gasoline engine]
15	W/B	- [Without VR30 engine]
16	B	- [With VR30 engine]
16	BR	- [Without VR30 engine]
17	LG	-
18	B	- [With VR30 engine]
18	W/B	- [Without VR30 engine]
19	Y	-
21	W	-
22	G	- [With 2.0L turbo gasoline engine]
22	V	- [Without VR30 engine]
33	L	- [With VR30 engine]
33	Y	- [Without VR30 engine]
34	P	-
35	BS	-
36	G	-
37	B	- [With VR30 engine]
37	L	- [Without VR30 engine]
38	L	- [With 2.0L turbo gasoline engine and without gateway]
38	P	- [Without VR30 engine]
38	R	- [With 2.0L turbo gasoline engine and with gateway]

39	R	- [With 2.0L turbo gasoline engine]
39	Y	- [Without VR30 engine]
40	GR	-
41	L	-
44	BR	-
45	L	- [With 2.0L turbo gasoline engine]
45	W	- [Without VR30 engine]
46	G	- [With VR30 engine]
46	Y	- [Without VR30 engine]
47	BS	- [With 2.0L turbo gasoline engine]
47	R	- [Without VR30 engine]
48	SHIELD	-
49	B	- [With VR30 engine]
49	G	- [Without VR30 engine]
50	B	- [With 2.0L turbo gasoline engine]
50	BR	- [Without VR30 engine]
51	L	-
52	W	-
53	G	-
54	SB	- [With 2.0L turbo gasoline engine]
54	Y	- [Without VR30 engine]
55	B	- [With 2.0L turbo gasoline engine]
55	P	- [Without VR30 engine]
56	BG	- [With VR30 engine]
56	GR	- [Without VR30 engine]
57	GR	- [With VR30 engine]
57	P	- [Without VR30 engine]
58	B	-
59	SB	-
61	W/B	-
64	Y	-
65	R	-
66	P	- [Color of wire differs depending on production]
66	V	- [Color of wire differs depending on production]
67	LG	-
68	BG	-
69	L	-
70	R	-
71	V	- [With VR30 engine]
71	W	- [Without VR30 engine]
72	L	- [With 2.0L turbo gasoline engine]
72	LG	- [Without VR30 engine]
73	R	- [With VR30 engine]
73	W	- [Without VR30 engine]
74	BR	- [With 2.0L turbo gasoline engine]
74	L	- [Without VR30 engine]
75	B	- [With 2.0L turbo gasoline engine]
75	P	- [Without VR30 engine]
75	R	- [With 2.0L turbo gasoline engine and without gateway]
75	R	- [Without VR30 engine]
76	W/B	- [With 2.0L turbo gasoline engine and with gateway]

JRLWG0854GB

ILLUMINATION

< WIRING DIAGRAM >

ILLUMINATION

77	SB	-	-
78	G	- [With VR30 engine]	-
78	LG	- [With 2.0L turbo gasoline engine]	-
79	R	-	-
80	G	-	-
81	R	-	-
82	LG	-	-
83	BR	- [With 2.0L turbo gasoline engine]	-
83	R	- [With VR30 engine]	-
84	V	-	-
86	V	-	-
87	G	-	-
89	V	-	-
90	G	- [With VR30 engine]	-
90	V	- [With 2.0L turbo gasoline engine]	-
91	W	-	-
92	G	-	-
93	BR	-	-
94	GR	- [With VR30 engine]	-
94	L	- [With 2.0L turbo gasoline engine]	-
95	BR	- [With VR30 engine]	-
95	P	- [With 2.0L turbo gasoline engine and without gateway]	-
95	R	- [With 2.0L turbo gasoline engine and with gateway]	-
96	W	-	-
97	LG	-	-
98	Y	-	-
99	BR	- [With VR30 engine]	-
99	LG	- [With 2.0L turbo gasoline engine]	-
100	SHIELD	-	-

Connector No.	M45
Connector Name	GLOVE BOX LAMP
Connector Type	A02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	M50
Connector Name	DIODE
Connector Type	24335-C9900



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	B	-

Connector No.	M57
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
6	GR	STOP/START OFF SWITCH/INDICATOR SIGNAL
7	G	SECURITY SIGNAL
8	B	-
11	W	ALTERNATOR SIGNAL
12	G	LED HEADLAMP (RA) WARNING SIGNAL
13	BR	LED HEADLAMP (LB) WARNING SIGNAL
14	V	A/C POWER SUPPLY
16	V	AIR BAG SIGNAL
17	BR	METER CONTROL SWITCH GROUND
18	SB	TRIP/PRESET SIGNAL
21	B	STEERING SWITCH SIGNAL A
22	P	STEERING SWITCH SIGNAL B
23	W/B	WASHER LEVEL SWITCH SIGNAL
24	L	WASHER FLUID LEVEL SWITCH SIGNAL
25	LG	BRAKE FLUID LEVEL SWITCH SIGNAL
26	V	PARKING BRAKE SWITCH SIGNAL
27	G	PASSENGER SEAT BELT WARNING SIGNAL

28	W	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
30	G	MANUAL MODE SIGNAL [With 2.0L turbo gasoline engine]
30	SB	MANUAL MODE SIGNAL [With VR30 engine]
31	G	NON-MANUAL MODE SIGNAL [With VR30 engine]
31	L	NON-MANUAL MODE SIGNAL [With 2.0L turbo gasoline engine]
32	B/G	MANUAL MODE SHIFT UP SIGNAL
33	GR	MANUAL MODE SHIFT DOWN SIGNAL [With VR30 engine]
33	P	MANUAL MODE SHIFT DOWN SIGNAL [With 2.0L turbo gasoline engine]
34	B/G	PADDLE SHIFTER UP SWITCH SIGNAL
35	V	PADDLE SHIFTER DOWN SWITCH SIGNAL
36	V	ILLUMINATION CONTROL SWITCH SIGNAL (I)
37	GR	ILLUMINATION CONTROL SWITCH SIGNAL (I)
38	R	VEHICLE SPEED SIGNAL (R/PULSE)

Connector No.	M58
Connector Name	COMBINATION METER
Connector Type	TH12FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
41	L	CAN-H
42	P	CAN-L
43	B	ILLUMINATION CONTROL SIGNAL
44	Y	FUEL LEVEL SENSOR GROUND
45	W	BATTERY POWER SUPPLY
46	B/G	IGNITION SIGNAL [Event with VR30 engine and without SS]
46	R	IGNITION SIGNAL [With VR30 engine and without SS]
47	SB	AV COMMUNICATION SIGNAL (H)
48	LG	AV COMMUNICATION SIGNAL (L)
51	BR	FUEL LEVEL SENSOR SIGNAL
52	B	GROUND

Connector No.	M59
Connector Name	METER CONTROL SWITCH
Connector Type	TH48FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-
4	BR	-
5	SB	-
6	V	-
7	GR	-

Connector No.	M80
Connector Name	TRIPLE SWITCH
Connector Type	TH12FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	W	-
3	R	-
5	B	-
6	R	-
7	B	-
9	R	INDICATOR+
11	GR	INDICATOR-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

ILLUMINATION

Connector No.	M86
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TR06FY-EX-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
23	R	-
26	B	-
28	Y/R	-
29	Y	-
30	Y/B	-
34	LG	-

Connector No.	M91
Connector Name	OPTICAL SENSOR
Connector Type	TR03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	SENSOR POWER
2	BG	SENSOR OUTPUT
3	P	SENSOR_GND

Connector No.	M100
Connector Name	DISPLAY CONTROL UNIT
Connector Type	TH24FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
16	LG	AV COMM (L)
17	P	CAN-L
19	R	DIMMER SIGNAL
20	BR	REVERSE SIGNAL
22	B	GND
26	BR	CAMERA SWITCH SIGNAL
28	SB	AV COMM (H)
29	L	CAN-H
30	R	IGN [For VR30 engine]
30	W	IGN [For 2.0L turbo gasoline engine]
31	R	VEHICLE SPEED SIGNAL (8-PULSE)
33	SB	ACC [Except for VR30 engine and with IS]
33	V	ACC [For VR30 engine and with IS]
34	Y	BAT

Connector No.	M133
Connector Name	FUSE BLOCK (I/B)
Connector Type	TH40FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	V	-
13C	L	-
14C	Y	-
15C	R	-
16C	R	-

17C	L	-
18C	BG	- [Without DRPO]
18C	P	- [With DRPO]
19C	B	-
1C	R	-
20C	W	-
21C	L	-
22C	L	-
23C	L	-
24C	LG	-
25C	SB	-
26C	SB	-
27C	W	-
28C	W	-
29C	W	-
2C	R	-
30C	R	-
31C	W	-
32C	R	-
33C	B	- [With VR30 engine]
33C	R	- [With 2.0L turbo gasoline engine]
34C	W/B	-
35C	SB	-
36C	R	-
37C	W	-
38C	SB	-
39C	V	-
3C	P	-
40C	G	-
4C	P	-
5C	P	-
6C	G	-
7C	G	-
8C	G	-
9C	V	-

Connector No.	M135
Connector Name	JOINT CONNECTOR-M09
Connector Type	24342_4GA2A



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	B	-
4	B	-
5	B	-
6	B	-
9	LG	-
10	LG	-
11	LG	-
13	B	- [With VR30 engine]
13	SB	- [With 2.0L turbo gasoline engine]
14	B	- [With VR30 engine]
14	SB	- [With 2.0L turbo gasoline engine]
15	B	- [With VR30 engine]
15	SB	- [With 2.0L turbo gasoline engine]
16	Y	- [With VR30 engine]
17	Y	- [With 2.0L turbo gasoline engine]
18	SB	- [With VR30 engine]
18	Y	- [With 2.0L turbo gasoline engine]
19	SHIELD	-
20	R	-
21	R	-
22	SHIELD	-
23	L	-
24	L	-

ILLUMINATION

< WIRING DIAGRAM >

ILLUMINATION

Connector No.	M138
Connector Name	CONSOLE BOX LAMP
Connector Type	C02FBR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-

Connector No.	M139
Connector Name	DIODE2
Connector Type	ET02-2W



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	BG	-

Connector No.	M140
Connector Name	OPTICAL CONNECTOR (FRONT ILLUMINATION CONTROL UNIT (PASSenger SIDE))
Connector Type	TH12MW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	IGN
2	W	BAT
3	R	TAIL LAMP
4	V	ROOM LAMP OUTPUT
5	LG	BATTERY SAVER OUTPUT
6	GR	FR DOOR_SW RH
7	V	FR DOOR_SW LH
8	V	THRU_SIGNAL_1
9	G	RR DOOR_RH
10	W	RR DOOR_LH
11	SB	ACC [With 2.0L turbo gasoline engine]
12	B	ACC [With VR30 engine]
		GND

Connector No.	M141
Connector Name	OPTICAL CONNECTOR (FRONT ILLUMINATION CONTROL UNIT (DRIVER SIDE))
Connector Type	TH12MW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	IGN
2	W	BAT
3	R	TAIL LAMP
4	V	ROOM LAMP OUTPUT
5	LG	BATTERY SAVER OUTPUT
6	GR	FR DOOR_SW RH
7	V	FR DOOR_SW LH

8	V	THRU_SIGNAL_1
9	G	RR DOOR_RH
10	W	RR DOOR_LH
11	SB	ACC [With 2.0L turbo gasoline engine]
12	B	ACC [With VR30 engine]
		GND


Connector No.	M146
Connector Name	WIRE TO WIRE
Connector Type	TK35MW-NS10



Terminal No.	Color Of Wire	Signal Name [Specification]
5	R	-
8	GR	-
9	V	-
10	BG	-
11	L	-
12	P	-
13	SB	-
14	Y	-
15	G	-
16	BR	-
17	W	-
18	R	-
19	L	-
20	SHIELD	-
21	BR	-
22	B	-
23	G	-
24	L	-
25	R	-
26	G	-
30	Y	-
31	GR	-
32	SB	-
33	BG	-
34	V	-
35	G	-
36	R	-
37	SHIELD	-

38	B	-
39	W	-
40	B	-
41	GR	-
42	B	-
43	LG	-
44	B	-
45	SB	-
46	B	-

Connector No.	M159
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	BR	-
4	R	-
5	GR	-
6	R	- [With VR30 engine and with BS]
7	W	- [Except with VR30 engine and with BS]
9	SHIELD	-
10	W	-
11	R	-
12	L	-
13	G	-
14	Y	-
15	B	-
17	B	-
18	R	-
19	R	-
20	BG	- [Except with VR30 engine and with BOSE system]
21	R	- [With VR30 engine and with BOSE system]
22	G	-
24	B	-
25	W	-
26	R	-
27	P	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL


ILLUMINATION

< WIRING DIAGRAM >

ILLUMINATION

28	B	-	-
29	G	-	-
30	L	-	-
31	W	-	-
32	W	-	-
33	L	-	-
36	V	-	-
38	LG	-	-
40	W	-	-

Connector No.	M171
Connector Name	JOINT CONNECTOR-M01
Connector Type	24342_46A2A



Terminal No.	Color Of Wire	Signal Name (Specification)
1	B	-
2	B	-
3	B	-
4	B	-
5	B	-
6	B	-
7	B	-
8	B	-
9	B	-
10	G	-
11	G	-
14	B	-
15	B	-
16	SB	- [With VR20 engine]
16	Y	- [With 2.0L turbo gasoline engine]
17	SB	- [With VR30 engine]
17	V	- [With 2.0L turbo gasoline engine]
18	SB	- [With VR30 engine]
18	Y	- [With 2.0L turbo gasoline engine]
19	G	-
20	G	-
22	LG	- [With VR30 engine]
22	SB	- [With 2.0L turbo gasoline engine]
23	LG	- [With VR30 engine]
23	SB	- [With 2.0L turbo gasoline engine]

24	LG	-	[With VR30 engine]
24	SB	-	[With 2.0L turbo gasoline engine]

Connector No.	M175
Connector Name	JOINT CONNECTOR-M05
Connector Type	NH20EL-DC



Terminal No.	Color Of Wire	Signal Name (Specification)
1	L	-
2	L	-
3	L	-
4	L	-
5	L	-
6	L	-
7	L	-
8	L	-
10	P	-
11	P	-
12	P	-
13	P	-
14	P	-
15	P	-
16	R	- [With VR30 engine]
16	R	- [With 2.0L turbo gasoline engine]
17	R	- [With VR30 engine]
17	R	- [With 2.0L turbo gasoline engine]
19	W	- [With VR30 engine and with ISS]
19	W	- [Except with VR30 engine and with ISS]
20	R	- [With VR30 engine and with ISS]
20	W	- [Except with VR30 engine and with ISS]

Connector No.	M177
Connector Name	JOINT CONNECTOR-M07
Connector Type	24342_46A2A



Terminal No.	Color Of Wire	Signal Name (Specification)
1	L	-
2	L	-
3	L	-
4	L	-
5	L	-
6	L	-
7	P	-
8	P	-
9	P	-
10	P	-
11	P	-
12	P	-
13	L	-
14	L	-
15	L	-
16	L	-
17	L	-
18	L	-
19	W	-
20	W	-
21	W	-
22	P	-
23	P	-
24	P	-

Connector No.	M301
Connector Name	COMBINATION SWITCH (SPKAL CABLE)
Connector Type	TK08FGY



Terminal No.	Color Of Wire	Signal Name (Specification)
13	-	-
14	-	-
15	-	-
16	-	-
17	-	-
18	-	-
19	-	-
20	-	-

Connector No.	R4
Connector Name	MAP LAMP
Connector Type	TH08FW-1V-NH



Terminal No.	Color Of Wire	Signal Name (Specification)
1	R	-
2	L	-
3	BR	-
6	B	-
7	SB	-
8	BC	-


JRLWG0858GB

ILLUMINATION


< WIRING DIAGRAM >

ILLUMINATION


Connector No.	R6
Connector Name	WIRE TO WIRE
Connector Type	TH16FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	BR	-
3	B	-
4	V	-
5	SB	-
6	BG	- [With ANC]
7	W	-
8	BR	- [Without ANC]
9	R	-
10	LG	-
11	L	-
12	G	-
13	B	-
14	L	-



Connector No.	R14
Connector Name	WIRE TO WIRE
Connector Type	TH16FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	GR	-
4	V	-
6	SB	-
7	W	-
8	BR	-
9	R	-

11	LG	-
12	G	-
13	B	-
14	L	-

Connector No.	RLS
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	LG	-
3	BR	-
4	V	-
5	BG	-
6	GR	-
7	BR	-
9	SHIELD	-
10	GR	-
11	R	-
12	L	-
13	G	-
14	Y	-
15	B	-
17	SB	-
19	BG	-
20	BG	- [Without BOSE system]
20	BR	- [With BOSE system]
21	R	-
22	G	-
24	B	-
25	BG	- [Color of wire differs depending on production]
25	P	- [Color of wire differs depending on production]
26	BR	-
27	GR	-
28	B	-
29	R	-
30	L	-
31	V	-
32	W	-

33	L	-
36	BR	-
38	SB	-
40	W	-

Connector No.	R22
Connector Name	TELEMATICS SWITCH
Connector Type	TH08FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
3	G	-
5	SB	-
6	B	-
7	B	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000012789618

OVERALL SEQUENCE



JMKIA8652GB

DETAILED FLOW

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-45. "Intermittent Incident"](#).

6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-45. "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

Component Function Check

INFOID:0000000012789619

1. CHECK INTERIOR ROOM LAMP POWER SUPPLY FUNCTION

CONSULT ACTIVE TEST

- Turn ignition switch ON.
- Turn each interior room lamp ON.
 - Personal lamp
 - Map lamp
 - Trunk room lamp
 - Step lamp
 - Outside handle lamp
 - Vanity mirror lamp
 - Kicking plate lamp
- Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
- With operating the test items, check that each interior room lamp turns ON/OFF.

Off : Interior room lamp ON

On : Interior room lamp OFF

Does the interior room lamp turn ON/OFF?

YES >> Interior room lamp power supply circuit is normal.

NO >> Refer to [INL-61, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000012789620

1. CHECK INTERIOR ROOM LAMP POWER SUPPLY OUTPUT

CONSULT ACTIVE TEST

- Turn ignition switch OFF.
- Disconnect the following connectors.
 - Personal lamp
 - Map lamp
 - Trunk room lamp
 - Step lamp (ALL)
 - Outside handle lamp (both sides)
 - Vanity mirror lamp (both sides)
 - Kicking plate lamp (both sides)
- Turn ignition switch ON.
- Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
- With operating the test item, check voltage between BCM harness connector and ground.

BCM		(-)	Test item		Voltage
(+) Connector Terminal					
M17	129	Ground	BATTERY SAVER	Off	9 – 16 V
				On	0 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).

2. CHECK INTERIOR ROOM LAMP POWER SUPPLY OPEN CIRCUIT

- Turn ignition switch OFF.
- Disconnect the BCM connector.
- Check continuity between BCM harness connector and each interior room lamp harness connector.

INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BCM		Each interior room lamp			Continuity
Connector	Terminal	Connector		Terminal	
M17	129	Map lamp	R4	1	Existed
		Trunk room lamp	B67		
		Step lamp (driver side)	D16		
		Step lamp (passenger side)	D30		
		Outside handle lamp (driver side)	D5	3	
		Outside handle lamp (passenger side)	D19		
		Vanity mirror lamp (driver side)	R24	2	
		Vanity mirror lamp (passenger side)	R23		
		Personal lamp	R21		
		Kicking plate lamp LH	B165	2	
		Kicking plate lamp RH	B164		

Is the inspection result normal?

- YES >> Check intermittent incident. Refer to [GI-45. "Intermittent Incident"](#).
 NO >> Repair or replace harnesses.

INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL CIRCUIT

Component Function Check

INFOID:000000012789621

NOTE:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Personal lamp bulb

1. CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

CONSULT ACTIVE TEST

1. Switch the map lamp switch and personal lamp switch to DOOR.
2. Turn ignition switch ON.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. With operating the test items, check that each interior room lamp turns ON/OFF.

On : Interior room lamp gradual brightening

Off : Interior room lamp gradual dimming

Does the interior room lamp turns ON/OFF?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-63, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000012789622

1. CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch OFF.
2. Disconnect map lamp, personal lamp and kicking plate lamp (both sides) connector.
3. Turn ignition switch ON.
4. Select "INT LAMP" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and ground.

BCM		Ground	Test item		Continuity
Connector	Terminal		INT LAMP	On	Existed
M17	136			Off	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Continuity exists and remains unchanged: GO TO 3.

NO-2 >> Continuity does not exist and remains unchanged: Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).

2. CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and map lamp harness connector.

BCM		Map lamp		Continuity
Connector	Terminal	Connector	Terminal	
M17	136	R4	3	Existed

4. Check continuity between personal lamp harness connector and map lamp harness connector.

Personal lamp		Map lamp		Continuity
Connector	Terminal	Connector	Terminal	
R21	3	R4	2	Existed

INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace map lamp or personal lamp or kicking plate lamp (both sides). Refer to [INL-74, "MAP LAMP : Removal and Installation"](#) (map lamp) or [INL-84, "Removal and Installation"](#) (personal lamp) or [INL-91, "Replacement"](#) (kicking plate lamp).

NO >> Repair or replace harnesses.

3. CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M17	136		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).

NO >> Repair or replace harnesses.

TRUNK ROOM LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

TRUNK ROOM LAMP CIRCUIT

Component Function Check

INFOID:000000012789623

NOTE:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Trunk room lamp bulb

1.CHECK TRUNK ROOM LAMP OPERATION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "TRUNK/LUGGAGE LAMP TEST" of BCM (INTELLIGENT KEY) active test item.
3. With operating the test items, check that trunk room lamp turns ON/OFF.

On : Trunk room lamp ON

Off : Trunk room lamp OFF

Does the trunk room lamp turn ON/OFF?

- YES >> Trunk room lamp circuit is normal.
NO >> Refer to [INL-69, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000012789624

1.CHECK TRUNK ROOM LAMP OUTPUT

1. Turn ignition switch OFF.
2. Disconnect trunk room lamp connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Condition		Continuity
Connector	Terminal		Trunk lid	Open	Existed
M15	85			Closed	Not existed

Is the inspection result normal?

- YES >> GO TO 2.
NO-1 >> Continuity exists and remains unchanged: GO TO 3.
NO-2 >> Continuity does not exist and remains unchanged: Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).

2.CHECK TRUNK ROOM LAMP OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and trunk room lamp harness connector.

BCM		Trunk room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M15	85	B67	2	Existed

Is the inspection result normal?

- YES >> Replace trunk room lamp. Refer to [INL-87, "Removal and Installation"](#).
NO >> Repair or replace harnesses.

3.CHECK TRUNK ROOM LAMP SHORT CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and ground.

TRUNK ROOM LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BCM		Ground	Continuity
Connector	Terminal		
M15	85		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).
- NO >> Repair or replace harnesses.

STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

STEP LAMP CIRCUIT

Component Function Check

INFOID:0000000012789625

NOTE:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Step lamp bulb

1.CHECK STEP LAMP OPERATION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
3. With operating the test items, check that step lamp turns ON/OFF.

On : Step lamp ON

Off : Step lamp OFF

Does the step lamp turn ON/OFF?

YES >> Step lamp circuit is normal.

NO >> Refer to [INL-67, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000012789626

1.CHECK STEP LAMP OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch OFF.
2. Disconnect step lamp connector (ALL).
3. Turn ignition switch ON.
4. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and ground.

BCM		Ground	Test item		Continuity
Connector	Terminal		STEP LAMP TEST	On	Existed
M13	21			Off	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Continuity exists and remains unchanged: GO TO 3.

NO-2 >> Continuity does not exist and remains unchanged: Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).

2.CHECK STEP LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and step lamp harness connector.

BCM		Step lamp			Continuity
Connector	Terminal	Connector	Terminal		
M13	21	Driver side	D16	2	Existed
		Passenger side	D30		

Is the inspection result normal?

YES >> Replace step lamp. Refer to [INL-82, "Removal and Installation"](#).

NO >> Repair or replace harnesses.

3.CHECK STEP LAMP SHORT CIRCUIT

STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M13	21		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-99. "Removal and Installation"](#).
NO >> Repair or replace harnesses.

OUTSIDE HANDLE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

OUTSIDE HANDLE LAMP CIRCUIT

Component Function Check

INFOID:000000012789627

NOTE:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply

1.CHECK OUTSIDE HANDLE LAMP OPERATION

CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "DOOR HANDLE LAMP TEST" of BCM (INTELLIGENT KEY) active test item.
3. With operating the test items, check that outside handle lamp turns ON/OFF.

On : Outside handle lamp ON

Off : Outside handle lamp OFF

Does the outside handle lamp turn ON/OFF?

YES >> Outside handle lamp circuit is normal.

NO >> Refer to [INL-69, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000012789628

1.CHECK OUTSIDE HANDLE LAMP OUTPUT

CONSULT ACTIVE TEST

1. Turn ignition switch OFF.
2. Disconnect outside handle lamp connector (ALL).
3. Turn ignition switch ON.
4. Select "DOOR HANDLE LAMP TEST" of BCM (INTELLIGENT KEY) active test item.
5. With operating the test item, check continuity between BCM harness connector and ground.

BCM		Ground	Test item		Continuity
Connector	Terminal		DOOR HANDLE LAMP TEST	On	
M14	65		On	Existed	
			Off	Not existed	

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Continuity exists and remains unchanged: GO TO 3.

NO-2 >> Continuity does not exist and remains unchanged: Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).

2.CHECK OUTSIDE HANDLE LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and outside handle lamp harness connector.

BCM		Outside handle lamp			Continuity
Connector	Terminal	Connector	Terminal		
M14	65	Driver side	D5	4	Existed
		Passenger side	D19		

Is the inspection result normal?

YES >> Replace front outside handle assembly. Refer to [DLK-236, "OUTSIDE HANDLE : Removal and Installation"](#).

NO >> Repair or replace harnesses.

3.CHECK OUTSIDE HANDLE LAMP SHORT CIRCUIT

OUTSIDE HANDLE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M14	65		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-99. "Removal and Installation"](#).
NO >> Repair or replace harnesses.

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

Component Function Check

INFOID:000000012789629

1. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

CONSULT ACTIVE TEST

- Turn ignition switch ON.
- Select "ENGINE SW ILLUMI" of BCM (INTELLIGENT KEY) active test item.
- With operating the test items, check that the push-button ignition switch illumination turns ON/OFF.

On : Push-button ignition switch illumination ON

Off : Push-button ignition switch illumination OFF

Does the push-button ignition switch illumination turn ON/OFF?

YES >> Push-button ignition switch illumination circuit is normal.

NO >> Refer to [INL-71, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000012789630

1. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OUTPUT

CONSULT ACTIVE TEST

- Turn ignition switch ON.
- Select ENGINE SW ILLUMI of BCM (INTELLIGENT KEY) active test item.
- With operating the test item, check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage	
BCM					
Connector	Terminal				
M14	48	Ground	ENGINE SW ILLUMI	On	9 V
				Off	0 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).

2. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND

CONSULT ACTIVE TEST

With operating the test item, check continuity between BCM harness connector and ground.

BCM		Ground	Test item		Continuity
Connector	Terminal				
M16	107		ENGINE SW ILLUMI	On	Existed
				Off	Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO-1 >> Continuity exists and remains unchanged: GO TO 4.

NO-2 >> Continuity does not exist and remains unchanged: Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).

3. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM connector and push-button ignition switch connector.
- Check continuity between BCM harness connector and push-button ignition switch harness connector.

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M14	48	M38	5	Existed

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M16	107	M38	6	Existed

Is the inspection result normal?

- YES >> Replace push-button ignition switch.
- NO >> Repair or replace harnesses.

4. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and push-button ignition switch connector.
3. Check continuity between BCM harness connector and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M16	107		Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-99, "Removal and Installation"](#).
- NO >> Repair or replace harnesses.

INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

INTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:0000000012789631

NOTE:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All the following lamps do not turn ON. <ul style="list-style-type: none"> • Map lamp • Personal lamp • Vanity mirror lamp • Step lamp • Outside handle lamp • Trunk room lamp • Kicking plate lamp 	<ul style="list-style-type: none"> • Harness between BCM and each interior room lamp • BCM 	Interior room lamp power supply circuit Refer to INL-61, "Component Function Check" .
<ul style="list-style-type: none"> • Interior room lamp does not turn ON even though the door is open. (It turns ON when turning the interior room lamp ON.) • Interior room lamp does not turn OFF even though the door is closed. 	<ul style="list-style-type: none"> • Harness between BCM and each door switch • Harness between BCM and each interior room lamp • BCM 	Door switch circuit Refer to DLK-117, "Component Function Check" . Interior room lamp control circuit Refer to INL-63, "Component Function Check" .
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to INL-17, "INT LAMP : CONSULT Function (BCM - INT LAMP)" .
<ul style="list-style-type: none"> • Outside handle lamp does not turn ON even though the door is open. • Outside handle lamp does not turn OFF even though the door is closed. 	<ul style="list-style-type: none"> • Harness between BCM and each door switch • Harness between BCM and outside handle lamp • BCM 	Door switch circuit Refer to DLK-117, "Component Function Check" . Outside handle lamp circuit Refer to INL-69, "Component Function Check" .
<ul style="list-style-type: none"> • Trunk room lamp does not turn ON even though the trunk lid is open. • Trunk room lamp does not turn OFF even though the trunk lid is closed. 	<ul style="list-style-type: none"> • Harness between BCM and trunk room lamp switch • Harness between BCM and trunk room lamp • BCM 	Trunk room lamp switch circuit Refer to DLK-139, "Component Function Check" . Trunk room lamp circuit Refer to INL-65, "Component Function Check" .
<ul style="list-style-type: none"> • Step lamps (ALL) do not turn ON. • Step lamps (ALL) do not turn OFF. 	<ul style="list-style-type: none"> • Harness between BCM and each door switch • Harness between BCM and each step lamp • BCM 	Door switch circuit Refer to DLK-117, "Component Function Check" . Step lamp circuit Refer to INL-67, "Component Function Check" .
Push-button ignition switch illumination does not illuminate.	<ul style="list-style-type: none"> • Harness between BCM and push-button ignition switch • BCM 	Push-button ignition switch illumination circuit Refer to INL-71, "Component Function Check" .
Interior room lamp battery saver does not activate.	BCM	Replace BCM. Refer to BCS-99, "Removal and Installation" .

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

MAP LAMP


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

MAP LAMP

Exploded View

INFOID:000000012789632



① Map lamp bracket*¹

② Headlining assembly

③ Map lamp assembly

④ Map lamp bracket*²

△ : Pawl

□ : Metal clip

← : Vehicle front

*¹: With sunroof

*²: Without sunroof

MAP LAMP

MAP LAMP : Removal and Installation

INFOID:000000012789633

REMOVAL



MAP LAMP

< REMOVAL AND INSTALLATION >

CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage.

1. Disengage map lamp assembly fixing pawls and metal clips according to numerical order 1→2 indicated by arrows as shown in the figure.



2. Disconnect harness connectors, and then remove map lamp assembly.

INSTALLATION

Install in the reverse order of removal.

MAP LAMP : Replacement

INFOID:000000012789634

MAP LAMP BULB

CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace map lamp assembly as a set.



MAP LAMP BRACKET

MAP LAMP BRACKET : Removal and Installation

INFOID:000000012789635

REMOVAL

1. Remove all assist grips.
Disengage assist grip cap fixing pawl using a remover tool (A), and then slide assist grip cap and remove it according to numerical order 1→2 indicated by arrows as shown in the figure.




2. Remove center pillar upper garnish (LH and RH). Refer to [INT-33. "CENTER PILLAR UPPER GARNISH : Removal and Installation"](#).
3. Remove front pillar garnish (LH and RH). Refer to [INT-25. "FRONT PILLAR GARNISH : Removal and Installation"](#).


MAP LAMP

< REMOVAL AND INSTALLATION >


4. Disconnect inside mirror harness connector (A). (With auto anti-dazzling)




5. Remove inside mirror harness cover. (Without rain sensor)
- a. Slide part (A) of inside mirror harness cover (1) in the direction of the arrow in the figure.





- b. Disengage inside mirror harness cover fixing pawls, and then remove inside mirror harness cover.

 : Pawl






6. Disengage rain sensor cover fixing pawls, and then remove rain sensor cover. (With rain sensor)

 : Pawl



7. Disengage inside mirror cover fixing pawls and metal clips, and then remove inside mirror cover.


 : Pawl
 : Metal clip




MAP LAMP


< REMOVAL AND INSTALLATION >

8. Remove map lamp assembly. Refer to [INL-74, "MAP LAMP : Removal and Installation"](#).
9. Remove sun visor assembly (LH and RH).
 - a. Disengage sun visor cover fixing pawls using a remover tool (A), and then remove sun visor cover (LH and RH).


 : Pawl




- b. Remove sun visor assembly fixing screws, and then disconnect vanity mirror lamp harness connector.
 - c. Remove sun visor assembly (LH and RH).
10. Remove sun visor holder (LH and RH) using a remover tool according to numerical order 1→2 indicated by arrows as shown in the figure.



11. Peel off dual lock fasteners (A) between headlining assembly and roof panel. (With sunroof)
CAUTION:
Never bend headlining when removing.



12. Remove front portion of headlining as shown in the figure.
CAUTION:
To prevent damage of the headlining assembly, hold the headlining assembly using a rope or tape before removal operation.




A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

MAP LAMP

< REMOVAL AND INSTALLATION >


13. Disengage map lamp bracket fixing dual lock fastener (A).

← : Vehicle front




14. Disengage map lamp bracket fixing metal clips from between headlining assembly and roof panel.

□ : Metal clip



15. Remove harness connector fixing clips (A) and (B), and then remove map lamp bracket (1) from between headlining assembly and roof panel.



INSTALLATION

Install in the reverse order of removal.


VANITY MIRROR LAMP

< REMOVAL AND INSTALLATION >

VANITY MIRROR LAMP

Exploded View

INFOID:000000012789636



① Lens

② Bulb

△ : Pawl

Replacement


INFOID:000000012789637

VANITY MIRROR LAMP BULB

CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it for preventing damage to the bulb.
- The surface of the bulb is very hot just after the lamp is turned OFF. Never touch the glass surface of the bulb with bare hands for preventing burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (due to dirt or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

1. Apply protective tapes (A) to vanity mirror of surface for protecting it from damage.



A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P


VANITY MIRROR LAMP


< REMOVAL AND INSTALLATION >

2. Disengage lens fixing pawls using a remover tool (A) according to numerical order 1→4 indicated by arrows as shown in the figure, and then remove lens.

CAUTION:

Use a remover tool wrapped in tape.

 : Pawl



3. Remove bulb.


GLOVE BOX LAMP

< REMOVAL AND INSTALLATION >

GLOVE BOX LAMP

Exploded View

INFOID:000000012789638



① Bulb & socket assembly

② Lamp housing

③ Instrument lower panel RH

△ : Pawl

Replacement


INFOID:000000012789639

GLOVE BOX LAMP BULB

CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it for preventing damage to the bulb.
- The surface of the bulb is very hot just after the lamp is turned OFF. Never touch the glass surface of the bulb with bare hands for preventing burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (due to dirt or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

1. Remove instrument lower panel RH. Refer to [IP-13, "Removal and Installation"](#).
2. Remove bulb & socket assembly according to numerical order 1→2 indicated by arrows as shown in the figure.




STEP LAMP

< REMOVAL AND INSTALLATION >

STEP LAMP

Exploded View

INFOID:000000012789640



① Front door finisher

② Lens

③ Bulb

④ Step lamp base

△ : Pawl

□ : Metal clip

↶ : Vehicle front

Removal and Installation


INFOID:000000012789641

REMOVAL

CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it for preventing damage to the bulb.
- The surface of the bulb is very hot just after the lamp is turned OFF. Never touch the glass surface of the bulb with bare hands for preventing burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (due to dirt or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.


1. Apply protective tape (A) to front door finisher for protecting it from damage.




STEP LAMP

< REMOVAL AND INSTALLATION >

2. Disengage step lamp assembly fixing metal clips using a remover tool (A).

 : Metal clip



3. Disconnect step lamp harness connector, and then remove step lamp assembly.

INSTALLATION

Install in the reverse order of removal.

Replacement


INFOID:000000012789642


STEP LAMP BULB

CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it for preventing damage to the bulb.
- The surface of the bulb is very hot just after the lamp is turned OFF. Never touch the glass surface of the bulb with bare hands for preventing burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (due to dirt or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

1. Remove step lamp assembly. Refer to [INL-82, "Removal and Installation"](#).
2. Disengage lens fixing pawls using a remover tool (A), and then remove lens.

 : Pawl



3. Remove bulb.


PERSONAL LAMP

< REMOVAL AND INSTALLATION >

PERSONAL LAMP

Exploded View

INFOID:000000012789643



① Personal lamp base

② Personal lamp finisher

③ Bulb

④ Lens

△ : Pawl

↩ : Vehicle front

Removal and Installation

INFOID:000000012789644

REMOVAL

CAUTION:


- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it for preventing damage to the bulb.
- The surface of the bulb is very hot just after the lamp is turned OFF. Never touch the glass surface of the bulb with bare hands for preventing burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (due to dirt or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.
- Remove personal lamp base LH and RH as a set.


1. Remove headlining assembly. Refer to [INT-46, "Removal and Installation"](#).

PERSONAL LAMP


< REMOVAL AND INSTALLATION >


2. Disengage personal lamp finisher fixing pawls using a remover tool (A).

 : Pawl



3. Disengage personal lamp finisher fixing pawls according to numerical order 1→2 indicated by arrows as shown in the figure, and then remove personal lamp finisher.

 : Pawl



4. Remove personal lamp base from headlining assembly.

INSTALLATION

Install in the reverse order of removal.

Replacement


INFOID:000000012789645

PERSONAL LAMP BULB

CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it for preventing damage to the bulb.
- The surface of the bulb is very hot just after the lamp is turned OFF. Never touch the glass surface of the bulb with bare hands for preventing burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (due to dirt or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

1. Apply protective tapes (A) to personal lamp finisher for protecting it from damage.





A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

PERSONAL LAMP

< REMOVAL AND INSTALLATION >

2. Disengage lens fixing pawls using a remover tool (A), and then remove lens.

 : Pawl



3. Remove bulb.


TRUNK ROOM LAMP

< REMOVAL AND INSTALLATION >

TRUNK ROOM LAMP

Exploded View

INFOID:000000012789646



- ① Trunk room lamp housing ② Bulb

△ : Pawl

↔ : Vehicle front

Removal and Installation

INFOID:000000012789647


REMOVAL

CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it for preventing damage to the bulb.
- The surface of the bulb is very hot just after the lamp is turned OFF. Never touch the glass surface of the bulb with bare hands for preventing burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (due to dirt or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

1. Disengage trunk room lamp housing cover fixing pawl using a remover tool (A), and then open trunk room lamp housing cover.

△ : Pawl





2. Remove bulb.

TRUNK ROOM LAMP

< REMOVAL AND INSTALLATION >

3. Disengage trunk room lamp housing fixing pawl using a remover tool (A).

 : Pawl



4. Disconnect trunk room lamp harness connector, and then remove trunk room lamp housing.

INSTALLATION

Install in the reverse order of removal.

Replacement


INFOID:000000012789648


TRUNK ROOM LAMP BULB

CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it for preventing damage to the bulb.
- The surface of the bulb is very hot just after the lamp is turned OFF. Never touch the glass surface of the bulb with bare hands for preventing burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (due to dirt or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

1. Disengage trunk room lamp housing cover fixing pawl using a remover tool (A), and then open trunk room lamp housing cover.

 : Pawl



2. Remove bulb.

OUTSIDE HANDLE LAMP

< REMOVAL AND INSTALLATION >

OUTSIDE HANDLE LAMP

Exploded View

INFOID:000000012789649

Refer to [DLK-235, "Exploded View"](#).

Replacement

INFOID:000000012789650

Always replace outside handle lamp together with outside handle as a set, when replacing since outside handle lamp is integrated with outside handle. Refer to [DLK-236, "OUTSIDE HANDLE : Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

CONSOLE BOX LAMP

< REMOVAL AND INSTALLATION >

CONSOLE BOX LAMP

Exploded View

INFOID:000000013472533

Console box lamp is integrated into center console assembly. Refer to [IP-23, "Exploded View"](#).

Replacement

INFOID:000000013472534

Always replace console box lamp together with center console assembly as a set, because console box lamp is integrated into center console assembly. Refer to [IP-24, "Removal and Installation"](#).

KICKING PLATE LAMP

< REMOVAL AND INSTALLATION >

KICKING PLATE LAMP

Exploded View

INFOID:000000013526289

Kicking plate lamp is integrated into front kicking plate outer (with kicking plate lamp). Refer to [INT-24, "Exploded View"](#).

Replacement

INFOID:000000013526290

Always replace kicking plate lamp together with front kicking plate outer as a set, when replacing since kicking plate lamp is integrated with front kicking plate outer. Refer to [INT-26, "KICKING PLATE OUTER : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

INL

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Bulb Specifications

INFOID:0000000012789651

Item	Type	Wattage (W)
Push-button ignition switch illumination	LED	—
Map lamp	LED	—
Map lamp illumination (Integrated into map lamp assembly)	LED	—
Vanity mirror lamp	—	1.8
Glove box lamp	Wedge	1.4
Step lamp	Wedge	5.0
Personal lamp	Wedge	8.0
Trunk room lamp	Wedge	3.4
Outside handle lamp	LED	—
Console box lamp	Wedge	2.0
Kicking plate lamp*	LED	—

*: If equipped.