

ENGINE LUBRICATION SYSTEM

CONTENTS

| | | | |
|---|--|-----------|--|
| 2.0L TURBO GASOLINE ENGINE | Inspection | 17 | |
| PRECAUTION | SERVICE DATA AND SPECIFICATIONS (SDS) | 18 | |
| PRECAUTIONS | SERVICE DATA AND SPECIFICATIONS (SDS) | 18 | |
| Precautions For Engine Service | Periodical Maintenance Specification | 18 | |
| Liquid Gasket | Engine Oil Pressure | 18 | |
| Precautions for Removing Battery Terminal | VR30DDTT | | |
| PREPARATION | PRECAUTION | 19 | |
| PREPARATION | PRECAUTIONS | 19 | |
| Special Service Tools | Precautions For Engine Service | 19 | |
| Commercial Service Tools | Precautions for Removing Battery Terminal | 19 | |
| SYSTEM DESCRIPTION | Liquid Gasket | 20 | |
| DESCRIPTION | PREPARATION | 22 | |
| Engine Lubrication System Schematic | PREPARATION | 22 | |
| PERIODIC MAINTENANCE | Special Service Tools | 22 | |
| ENGINE OIL | Commercial Service Tools | 22 | |
| Inspection | SYSTEM DESCRIPTION | 24 | |
| Draining | DESCRIPTION | 24 | |
| Refilling | Engine Lubrication System | 24 | |
| OIL FILTER | Engine Lubrication System Schematic | 26 | |
| Removal and Installation | PERIODIC MAINTENANCE | 27 | |
| Inspection | ENGINE OIL | 27 | |
| REMOVAL AND INSTALLATION | Inspection | 27 | |
| OIL COOLER | Draining | 29 | |
| Exploded View | Refilling | 29 | |
| Removal and Installation | OIL FILTER | 30 | |
| Inspection | Removal and Installation | 30 | |
| UNIT DISASSEMBLY AND ASSEMBLY ... | Inspection | 31 | |
| OIL PUMP | REMOVAL AND INSTALLATION | 32 | |
| Exploded View | | | |
| Removal and Installation | | | |

| | | | |
|---|-----------|--|-----------|
| OIL COOLER | 32 | Removal and Installation | 39 |
| | | Inspection | 40 |
| AIR COOLING TYPE | 32 | SERVICE DATA AND SPECIFICATIONS | |
| AIR COOLING TYPE : Exploded View | 32 | (SDS) | 41 |
| AIR COOLING TYPE : Removal and Installation ... | 33 | SERVICE DATA AND SPECIFICATIONS | |
| AIR COOLING TYPE : Inspection | 34 | (SDS) | 41 |
| WATER COOLING TYPE | 34 | 2WD | 41 |
| WATER COOLING TYPE : Exploded View | 35 | 2WD : Periodical Maintenance Specification | 41 |
| WATER COOLING TYPE : Removal and Installation | 36 | 2WD : Engine Oil Pressure | 41 |
| WATER COOLING TYPE : Inspection | 37 | AWD | 41 |
| UNIT DISASSEMBLY AND ASSEMBLY ... | 39 | AWD : Periodical Maintenance Specification | 41 |
| OIL PUMP | 39 | AWD : Engine Oil Pressure | 41 |
| Exploded View | 39 | | |

PRECAUTION

PRECAUTIONS

Precautions For Engine Service

INFOID:000000012952582

LU

DISCONNECTING FUEL PIPING

- Before starting work, check no fire or spark producing items are in the work area.
- Release fuel pressure before disconnecting and disassembly.
- After disconnecting pipes, plug openings to stop fuel leakage.

C

DRAINING ENGINE COOLANT

Drain engine coolant and engine oil when the engine is cooled.

D

INSPECTION, REPAIR AND REPLACEMENT

Before repairing or replacing, thoroughly inspect parts. Inspect new replacement parts in the same way, and replace if necessary.

E

F

REMOVAL AND DISASSEMBLY

- When instructed to use SST, use specified tools. Always be careful to work safely, avoid forceful or uninstructed operations.
- Exercise maximum care to avoid damage to mating or sliding surfaces.
- Dowel pins are used for several parts alignment. When replacing and reassembling parts with dowel pins, check that dowel pins are installed in the original position.
- Must cover openings of engine system with a tape or equivalent, to seal out foreign materials.
- Mark and arrange disassembly parts in an organized way for easy troubleshooting and reassembly.
- When loosening nuts and bolts, as a basic rule, start with the one furthest outside, then the one diagonally opposite, and so on. If the order of loosening is specified, do exactly as specified. Power tools may be used in the step.

G

H

I

J

ASSEMBLY AND INSTALLATION

- Use torque wrench to tighten bolts or nuts to specification.
- When tightening nuts and bolts, as a basic rule, equally tighten in several different steps starting with the ones in center, then ones on inside and outside diagonally in this order. If the order of tightening is specified, do exactly as specified.
- Replace with new gasket, packing, oil seal or O-ring.
- Thoroughly wash, clean, and air-blow each part. Carefully check engine oil or engine coolant passages for any restriction and blockage.
- Avoid damaging sliding or mating surfaces. Completely remove foreign materials such as cloth lint or dust. Before assembly, oil sliding surfaces well.
- After disassembling, or exposing any internal engine parts, change engine oil and replace oil filter with a new one.
- Release air within route when refilling after draining engine coolant.
- After repairing, start the engine and increase engine speed to check engine coolant, fuel, engine oil, and exhaust gases for leakage.

K

L

M

N

Liquid Gasket

INFOID:000000012952583

O

REMOVAL OF LIQUID GASKET SEALING

P

PRECAUTIONS

< PRECAUTION >

[2.0L TURBO GASOLINE ENGINE]

- After removing mounting nuts and bolts, separate the mating surface using the seal cutter [SST: KV10111100] (A) and remove old liquid gasket sealing.


CAUTION:

Never damage the mating surfaces.

- Tap the seal cutter [SST: KV10111100] to insert it (B), and then slide it (C) by tapping on the side as shown in the figure.
- In areas where the seal cutter [SST: KV10111100] is difficult to use, lightly tap the parts using a plastic hammer to remove it.


CAUTION:

If for some unavoidable reason tool such as a screwdriver is used, be careful not to damage the mating surfaces.




LIQUID GASKET APPLICATION PROCEDURE

- Using a scraper (A), remove old liquid gasket adhering to the liquid gasket application surface and the mating surface.
 - Remove liquid gasket completely from the groove of the liquid gasket application surface, mounting bolts, and bolt holes.
- Wipe the liquid gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.



- Attach liquid gasket tube to the tube presser (commercial service tool).
Use Genuine Liquid Gasket or equivalent.
- Apply liquid gasket without gaps to the specified location according to the specified dimensions.
 - If there is a groove for liquid gasket application, apply liquid gasket to the groove.



- As for bolt holes (B), normally apply liquid gasket inside the holes. Occasionally, it should be applied outside the holes. Check to read the text of this manual.


(A) : Groove

⇐ : Inside

- Within five minutes of liquid gasket application, install the mating component.
- If liquid gasket protrudes, wipe it off immediately.
- Do not retighten mounting bolts or nuts after the installation.
- After 30 minutes or more have passed from the installation, fill engine oil and engine coolant.

CAUTION:

If there are specific instructions in this manual, observe them.



Precautions for Removing Battery Terminal

INFOID:000000013517285

When disconnecting the battery terminal, pay attention to the following.

- Always use a 12V battery as power source.
- Never disconnect battery terminal while engine is running.


PRECAUTIONS

< PRECAUTION >

[2.0L TURBO GASOLINE ENGINE]

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
- For vehicles with the engine listed below, remove the battery terminal after a lapse of the specified time:

| | | | |
|------------|--------------|------------|--------------|
| BR08DE | : 4 minutes | V9X engine | : 4 minutes |
| D4D engine | : 20 minutes | YD25DDTi | : 2 minutes |
| HR09DET | : 12 minutes | YS23DDT | : 4 minutes |
| HRA2DDT | : 12 minutes | YS23DDTT | : 4 minutes |
| K9K engine | : 4 minutes | ZD30DDTi | : 60 seconds |
| M9R engine | : 4 minutes | ZD30DDTT | : 60 seconds |
| R9M engine | : 4 minutes | | |



A
LU
C
D
E
F
G
H
I
J
K
L
M
N
O
P

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- After high-load driving, if the vehicle is equipped with the V9X engine, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery terminal.

NOTE:

- Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.
- Example of high-load driving
 - Driving for 30 minutes or more at 140 km/h (86 MPH) or more.
 - Driving for 30 minutes or more on a steep slope.
- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

PREPARATION

[2.0L TURBO GASOLINE ENGINE]



< PREPARATION >

PREPARATION

PREPARATION


Special Service Tools

INFOID:000000012952585

| Tool number (DAIMLER tool No.) Tool name | Description |
|---|--|
| KV115H0070 (DAIMLER tool No.103 589 00 21 00) Gauge oil press |  <p style="text-align: center;">JSBIA3891ZZ</p> 0-10 bar test equipment for gasoline and oil pressure measurements. |
| KV105H0050 (DAIMLER tool No.270 589 00 63 00) Oil pressure tester cap |  <p style="text-align: center;">JSBIA5233ZZ</p> Tester cap for checking oil pressure on oil filter insert. |

Commercial Service Tools

INFOID:000000012952586

| Tool name | Description |
|--------------|---|
| Tube presser |  <p style="text-align: center;">NT052</p> Pressing tube of liquid gasket |

SYSTEM DESCRIPTION


DESCRIPTION

Engine Lubrication System Schematic

INFOID:0000000012952587

A

LU



- | | | |
|--|---|--|
| ① Oil pan | ② Intake camshaft adjuster | ③ Exhaust camshaft adjuster |
| ④ Hydraulic valve clearance compensation | ⑤ Vacuum pump | ⑥ Oil spray nozzles |
| ⑦ Turbocharger | | |
| A Oil pump | B Engine oil / coolant heat exchanger with thermostatic valve | C Oil filter module with return stop and pressure differential valve |
| D Chain tensioner with oil spray nozzle | E Cylinder head | F Crankcase |

C

D

E

F

G

H

I

J

K

L

M

N

O

P

PERIODIC MAINTENANCE

ENGINE OIL

Inspection


INFOID:000000012952588

ENGINE OIL LEVEL

NOTE:

Before starting engine, put vehicle horizontally and check the engine oil level. If engine is already started, stop it and allow 10 minutes before checking.

1. Pull out oil level gauge and wipe it clean.
2. Insert oil level gauge and check the engine oil level is within the range (A) shown in the figure.
3. If it is out of range, adjust it.



JSBIA5244ZZ

ENGINE OIL APPEARANCE

- Check engine oil for white turbidity or heavy contamination.
- If engine oil becomes turbid and white, it is highly probable that it is contaminated with engine coolant. Repair or replace damaged parts.

ENGINE OIL LEAKAGE

Check for engine oil leakage around the following areas:

- Oil pan
- Oil pan drain plug
- Oil filter
- Oil cooler
- Chain case
- Mating surface between timing chain case and cylinder head
- Mating surface between timing chain case and cylinder block
- Mating surface between timing chain case and oil pan
- Mating surface between cylinder block and cylinder head
- Mating surface between cylinder head and cylinder head cover
- Crankshaft oil seals (front and rear)
- Vacuum pump
- Turbocharger
- Oil tube connecting parts from turbocharger
- Fuel pump

OIL PRESSURE CHECK

WARNING:

- **Never get burn yourself, as engine oil may be hot.**
 - **Oil pressure check should be done in "Parking position".**
1. Engine oil temperature until 100°C (212°F) by using the CONSULT, to warm up the engine.
 2. Stop the engine and wait for 10 minutes.
 3. Check the engine oil level.
 4. Remove engine cover. Refer to [EM-22. "Removal and Installation"](#).
 5. Remove oil filter screw cap.

CAUTION:

Never spill engine oil on drive belt.


6. Remove oil filter from oil filter screw cap.

ENGINE OIL


< PERIODIC MAINTENANCE >

[2.0L TURBO GASOLINE ENGINE]

7. Install the oil pressure tester cap [SST: KV105H0050 (270 589 00 63 00)] (A).



8. Install the gauge oil press [SST: KV115H0070 (103 589 00 21 00)] (A).



9. Check the engine oil pressure with engine running under no-load.

CAUTION:

When the engine oil temperature reached 90°C (194°F), check the oil pressure.

Engine oil pressure : Refer to [LU-18, "Engine Oil Pressure"](#).

10. Install in the reverse order of removal.

Draining


INFOID:0000000012952589

WARNING:

- Never get burn yourself, as engine oil may be hot.
- Prolonged and repeated contact with used engine oil may cause skin cancer. Try to avoid direct skin contact with used engine oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.

1. Warm up the engine, and check for engine oil leakage from engine components. Refer to [LU-8, "Inspection"](#).
2. Remove oil filter.
3. Loosen oil filler cap.
4. Remove drain plug ① and then drain engine oil and wait for 5 minutes.

← : Engine front



Refilling

INFOID:0000000012952590

1. Install drain plug with new seal ring. Refer to [EM-109, "2WD : Exploded View"](#) (2WD), [EM-79, "Exploded View"](#) (AWD).

ENGINE OIL

< PERIODIC MAINTENANCE >

[2.0L TURBO GASOLINE ENGINE]

CAUTION:

Be sure to clean drain plug and install with new seal ring.

Tightening torque : Refer to [EM-109, "2WD : Exploded View"](#) (2WD), [EM-79, "Exploded View"](#) (AWD).

2. Install engine oil filter. Refer to [LU-11, "Removal and Installation"](#).

3. Refill with new engine oil.

Engine oil specification and viscosity: Refer to [MA-20, "Recommended Fluids and Lubricants"](#).

Engine oil capacity : Refer to [LU-18, "Periodical Maintenance Specification"](#).

CAUTION:

- When filling engine oil, do not pull out oil level gauge.
- The refill capacity depends on the engine oil temperature and drain time. Use these specifications for reference only.
- Always use oil level gauge to determine the proper amount of engine oil in engine.

4. Warm up the engine and check area around drain plug and oil filter for engine oil leakage.

5. Stop the engine and wait for 10 minutes.

6. Check the engine oil level. Refer to [LU-8, "Inspection"](#).

OIL FILTER

Removal and Installation

INFOID:000000012952591

REMOVAL

CAUTION:

- **Never get burned when engine and engine oil may be hot.**
- **Completely wipe off any engine oil that adheres to engine and vehicle.**

1. Remove engine cover. Refer to [EM-22, "Removal and Installation"](#).
2. Remove engine oil level gauge. Refer to [EM-109, "2WD : Exploded View"](#) (2WD), [EM-79, "Exploded View"](#) (AWD).
3. Place a tray or an equivalent around the oil filter housing in case engine oil spills.
4. Remove oil filter screw cap.

CAUTION:**Never spill engine oil on drive belt.**

5. Remove oil filter from oil filter screw cap.

INSTALLATION

1. Remove foreign materials adhering to oil filter installation surface.
2. Apply engine oil to the oil ring contact surface of new oil filter.
CAUTION:
Do not reuse O-rings.
3. Screw oil filter screw cap manually until it touches the installation surface, then tighten to the specification.

Oil filter screw cap:
 **25.0 N·m (2.6 kg-m, 18 ft-lb)**

Inspection

INFOID:000000012952592

INSPECTION AFTER INSTALLATION


1. Check the engine oil level. Refer to [LU-8, "Inspection"](#).
2. Start the engine, and check there is no leak of engine oil.
3. Stop the engine and wait for 10 minutes.
4. Check the engine oil level, and adjust the level. Refer to [LU-8, "Inspection"](#).

REMOVAL AND INSTALLATION

OIL COOLER

Exploded View

INFOID:000000012952593



① Oil temperature regulator

② Gasket

③ Oil cooler

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

Removal and Installation

INFOID:000000012952594

REMOVAL

1. Drain engine coolant from radiator. Refer to [CO-7, "Draining"](#).
CAUTION:
 - Perform this step when the engine is cold.
 - Never spill engine coolant on drive belt.
2. Remove charge air manifold. Refer to [EM-29, "Removal and Installation"](#).
3. Remove alternator. Refer to [CHG-25, "2.0L TURBO GASOLINE ENGINE : Removal and Installation"](#).
4. Disconnect cooling hose from oil cooler.

OIL COOLER

< REMOVAL AND INSTALLATION >

[2.0L TURBO GASOLINE ENGINE]

5. Remove oil cooler.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

Do not reuse O-rings.

Inspection

INFOID:000000012952595

INSPECTION AFTER REMOVAL

Oil Cooler

Check oil cooler for cracks. Check oil cooler for clogging by blowing through engine coolant inlet. If necessary, replace oil cooler.

INSPECTION AFTER INSTALLATION

1. Check the engine oil level and the engine coolant level and add engine oil and engine coolant. Refer to [LU-8, "Inspection"](#) and [CO-7, "Inspection"](#).
2. Start the engine, and check there is no leakage of engine oil or engine coolant.
3. Stop the engine and wait for 10 minutes.
4. Check the engine oil level and the engine coolant level again. Refer to [LU-8, "Inspection"](#) and [CO-7, "Inspection"](#).

A

LU

C

D

E

F

G

H

I

J

K

L

M

N

O

P

OIL PUMP

< UNIT DISASSEMBLY AND ASSEMBLY >


[2.0L TURBO GASOLINE ENGINE]

UNIT DISASSEMBLY AND ASSEMBLY

OIL PUMP

Exploded View

INFOID:000000012952596



JSBIA9958GB

- | | | |
|---------------------------|--------------------|---------------------------|
| ① Oil level gauge | ② O-ring | ③ Oil level gauge guide |
| ④ O-ring | ⑤ Slide rail pin | ⑥ Timing chain guide |
| ⑦ Timing chain (oil pump) | ⑧ Crank sprocket | ⑨ O-ring |
| ⑩ Engine oil pump valve | ⑪ O-ring | ⑫ Oil drain screw |
| ⑬ Oil drain screw washer | ⑭ Oil pan | ⑮ Engine oil pump |
| ⑯ Oil suction pipe | ⑰ O-ring | ⑱ Engine oil level switch |
| ⑲ O-ring | ⑳ Rear plate cover | |

⊗ : Always replace after every disassembly.

OIL PUMP

< UNIT DISASSEMBLY AND ASSEMBLY >

[2.0L TURBO GASOLINE ENGINE]


: N·m (kg·m, in·lb)

: N·m (kg·m, ft·lb)

: Sealing point

: Should be lubricated with oil.

AWD



① Oil level gauge

② O-ring

③ Oil level gauge guide

④ O-ring

⑤ Slide rail pin

⑥ Timing chain guide

⑦ Timing chain (oil pump)

⑧ Crank sprocket

⑨ O-ring

OIL PUMP

< UNIT DISASSEMBLY AND ASSEMBLY >

[2.0L TURBO GASOLINE ENGINE]

- | | | |
|-----------------------------------|---------------------------|-------------------------|
| ⑩ Engine oil pump valve | ⑪ O-ring | ⑫ Engine oil pump |
| ⑬ O-ring | ⑭ Oil suction pipe | ⑮ Oil pan |
| ⑯ Engine oil level switch bracket | ⑰ Engine oil level switch | ⑱ O-ring |
| ⑲ Oil drain screw | ⑳ Oil drain screw washer | ㉑ Oil pan (lower front) |
| ㉒ Oil pan (lower rear) | ㉓ Rear plate cover | |

⊗ : Always replace after every disassembly.

🔧 : N·m (kg-m, in-lb)

🔧 : N·m (kg-m, ft-lb)

🔧 : Sealing point

🔧 : Should be lubricated with oil.


Removal and Installation

INFOID:000000012952597

REMOVAL


1. Remove oil pan. Refer to [EM-110, "2WD : Removal and Installation"](#) (2WD), [EM-112, "AWD : Removal and Installation"](#) (AWD).
2. Disconnect engine oil pump harness connector ①.

← : Engine front




3. Remove oil pump mounting bolts ②.

← : Engine front



4. Press and hold the oil pump chain tensioner, remove oil pump ③.

← : Engine front




OIL PUMP

< UNIT DISASSEMBLY AND ASSEMBLY >

[2.0L TURBO GASOLINE ENGINE]

5. Remove oil suction pipe ① from oil pump ②.



INSTALLATION

Note the following, and install in the reverse order of removal.

NOTE:

- If a sensor is replaced, carry out the reset of adaptation of sensors. Refer to [EC4-216. "Description"](#).

Inspection

INFOID:000000012952598

INSPECTION AFTER INSTALLATION

1. Check the engine oil level. Refer to [LU-8. "Inspection"](#).
2. Start the engine, and check there is no leakage of engine oil.
3. Stop the engine and wait for 10 minutes.
4. Check the engine oil level and adjust the level. Refer to [LU-8. "Inspection"](#).

A
LU
C
D
E
F
G
H
I
J
K
L
M
N
O
P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[2.0L TURBO GASOLINE ENGINE]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Periodical Maintenance Specification

INFOID:0000000012952599

ENGINE OIL CAPACITY (APPROXIMATE)

Unit: ℓ (US qt, Imp qt)

| | | | |
|------------------|-----|---------------------------|-----------------------|
| Drain and refill | 2WD | With oil filter change | 6.3 (6 -5/8, 5 -4/8) |
| | | Without oil filter change | 5.8 (6 -1/8, 5 -1/8) |
| | AWD | With oil filter change | 6.6 (7, 5 -6/8) |
| | | Without oil filter change | 6.1 (6 -4/8, 5 -3/8) |

Engine Oil Pressure

INFOID:0000000012952600

Unit: kPa (bar, kg/cm², psi)

| Engine speed | Approximate discharge pressure* |
|--------------|------------------------------------|
| 650 rpm | More than 50 (0.50, 0.51, 7.25) |
| 1,000 rpm | More than 90 (0.90, 0.918, 13.05) |
| 2,000 rpm | More than 170 (1.70, 1.734, 24.65) |
| 4,000 rpm | More than 350 (3.50, 3.57, 50.75) |

*: Engine oil temperature at 90°C (194°F)

PRECAUTION

PRECAUTIONS

Precautions For Engine Service

INFOID:000000013607973

A

LU

DISCONNECTING FUEL PIPING

- Before starting work, check no fire or spark producing items are in the work area.
- Release fuel pressure before disconnecting and disassembly.
- After disconnecting pipes, plug openings to stop fuel leakage.

C

DRAINING ENGINE COOLANT

Drain engine coolant and engine oil when the engine is cooled.

D

INSPECTION, REPAIR AND REPLACEMENT

Before repairing or replacing, thoroughly inspect parts. Inspect new replacement parts in the same way, and replace if necessary.

E

F

REMOVAL AND DISASSEMBLY

- When instructed to use SST, use specified tools. Always be careful to work safely, avoid forceful or uninstructed operations.
- Exercise maximum care to avoid damage to mating or sliding surfaces.
- Dowel pins are used for several parts alignment. When replacing and reassembling parts with dowel pins, check that dowel pins are installed in the original position.
- Must cover openings of engine system with a tape or equivalent, to seal out foreign materials.
- Mark and arrange disassembly parts in an organized way for easy troubleshooting and reassembly.
- When loosening nuts and bolts, as a basic rule, start with the one furthest outside, then the one diagonally opposite, and so on. If the order of loosening is specified, do exactly as specified. Power tools may be used in the step.

G

H

I

J

ASSEMBLY AND INSTALLATION

- Use torque wrench to tighten bolts or nuts to specification.
- When tightening nuts and bolts, as a basic rule, equally tighten in several different steps starting with the ones in center, then ones on inside and outside diagonally in this order. If the order of tightening is specified, do exactly as specified.
- Replace with new gasket, packing, oil seal or O-ring.
- Thoroughly wash, clean, and air-blow each part. Carefully check engine oil or engine coolant passages for any restriction and blockage.
- Avoid damaging sliding or mating surfaces. Completely remove foreign materials such as cloth lint or dust. Before assembly, oil sliding surfaces well.
- After disassembling, or exposing any internal engine parts, change engine oil and replace oil filter with a new one.
- Release air within route when refilling after draining engine coolant.
- After repairing, start the engine and increase engine speed to check engine coolant, fuel, engine oil, and exhaust gases for leakage.

K

L

M

N

Precautions for Removing Battery Terminal

INFOID:000000013607974

When disconnecting the battery terminal, pay attention to the following.

- Always use a 12V battery as power source.
- Never disconnect battery terminal while engine is running.

O

P


PRECAUTIONS

[VR30DDTT]

< PRECAUTION >

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
- For vehicles with the engine listed below, remove the battery terminal after a lapse of the specified time:

| | | | |
|------------|--------------|------------|--------------|
| BR08DE | : 4 minutes | V9X engine | : 4 minutes |
| D4D engine | : 20 minutes | YD25DDTi | : 2 minutes |
| HR09DET | : 12 minutes | YS23DDT | : 4 minutes |
| HRA2DDT | : 12 minutes | YS23DDTT | : 4 minutes |
| K9K engine | : 4 minutes | ZD30DDTi | : 60 seconds |
| M9R engine | : 4 minutes | ZD30DDTT | : 60 seconds |
| R9M engine | : 4 minutes | | |



NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- After high-load driving, if the vehicle is equipped with the V9X engine, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery terminal.

NOTE:

- Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.
- Example of high-load driving
 - Driving for 30 minutes or more at 140 km/h (86 MPH) or more.
 - Driving for 30 minutes or more on a steep slope.
- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.

Liquid Gasket

INFOID:000000013607975

REMOVAL OF LIQUID GASKET SEALING

- After removing mounting nuts and bolts, separate the mating surface using the seal cutter [SST: KV10111100] (A) and remove old liquid gasket sealing.


CAUTION:

Never damage the mating surfaces.

- Tap the seal cutter [SST: KV10111100] to insert it (B), and then slide it (C) by tapping on the side as shown in the figure.
- In areas where the seal cutter [SST: KV10111100] is difficult to use, lightly tap the parts using a plastic hammer to remove it.


CAUTION:

If for some unavoidable reason tool such as a screwdriver is used, be careful not to damage the mating surfaces.



LIQUID GASKET APPLICATION PROCEDURE

1. Using a scraper (A), remove old liquid gasket adhering to the liquid gasket application surface and the mating surface.
 - Remove liquid gasket completely from the groove of the liquid gasket application surface, mounting bolts, and bolt holes.
2. Wipe the liquid gasket application surface and the mating surface with white gasoline (lighting and heating use) to remove adhering moisture, grease and foreign materials.



PRECAUTIONS


[VR30DDTT]

< PRECAUTION >

3. Attach liquid gasket tube to the tube presser (commercial service tool).

Use Genuine Liquid Gasket or equivalent.

4. Apply liquid gasket without gaps to the specified location according to the specified dimensions.
 - If there is a groove for liquid gasket application, apply liquid gasket to the groove.




- As for bolt holes (B), normally apply liquid gasket inside the holes. Occasionally, it should be applied outside the holes. Check to read the text of this manual.

(A) : Groove

⇐ : Inside

- Within five minutes of liquid gasket application, install the mating component.
- If liquid gasket protrudes, wipe it off immediately.
- Do not retighten mounting bolts or nuts after the installation.
- After 30 minutes or more have passed from the installation, fill engine oil and engine coolant.



CAUTION:

If there are specific instructions in this manual, observe them.

A
LU
C
D
E
F
G
H
I
J
K
L
M
N
O
P

PREPARATION

< PREPARATION >

[VR30DDTT]




PREPARATION

PREPARATION

Special Service Tools


INFOID:000000013607976

The actual shapes of TechMate tools may differ from those of special service tools illustrated here.

| Tool number (TechMate No.) Tool name | Description |
|--|---|
| ST25051001 (J-25695-1) Oil pressure gauge  <p style="text-align: center;">NT050</p> | Measuring oil pressure Maximum measuring range: 2,452 kPa (25 kg/cm², 356 psi) |
| ST25052000 (J-25695-2) Hose  <p style="text-align: center;">S-NT559</p> | Adapting oil pressure gauge to oil pan (upper) |
| KV10115801 (J-38956) Oil filter wrench  <p style="text-align: center;">S-NT375</p> | Removing and installing oil filter a: 64.3 mm (2.531 in) |

Commercial Service Tools



INFOID:000000013607977

| Tool name | Description |
|--|--------------------------------|
| Tube presser  <p style="text-align: center;">NT052</p> | Pressing tube of liquid gasket |

PREPARATION

< PREPARATION >

[VR30DDTT]

| Tool name | Description |
|---|---|
| <p>Power tools</p>  <p>PBIC0190E</p> | <p>Loosening nuts and bolts</p> |
| <p>Deep socket</p>  <p>PBIC4066E</p> | <p>Removing and installing oil pressure switch 27 mm (1.06 in)</p> |

A

LU

C

D

E

F

G

H

I

J

K

L

M

N

O

P


SYSTEM DESCRIPTION

DESCRIPTION

Engine Lubrication System

INFOID:000000013607978

ENGINE OIL COOLER AIR COOLING TYPE



JSBIA9970ZZ


- | | | |
|--------------------------------------|--|--|
| ① Vacuum pump | ② Intake camshaft (bank 1) | ③ Exhaust camshaft (bank 1) |
| ④ Exhaust camshaft sprocket (bank 1) | ⑤ Exhaust valve timing control solenoid valve (bank 1) | ⑥ Turbocharger (bank 1) |
| ⑦ Oil filter | ⑧ Relief valve | ⑨ Oil cooler |
| ⑩ Timing chain tensioner (bank 1) | ⑪ Timing chain tensioner (bank 2) | ⑫ Oil gallery |
| ⑬ Oil jet | ⑭ Main bearing | ⑮ Timing chain oil jet |
| ⑯ Oil pump | ⑰ Turbocharger (bank 2) | ⑱ Exhaust valve timing control solenoid valve (bank 2) |
| ⑲ Exhaust camshaft sprocket (bank 2) | ⑳ High pressure fuel pump | ㉑ Exhaust camshaft (bank 2) |
| ㉒ Intake camshaft (bank 2) | | |

DESCRIPTION

< SYSTEM DESCRIPTION >

[VR30DDTT]

ENGINE OIL COOLER WATER COOLING TYPE



- | | | |
|--------------------------------------|--|--------------------------------------|
| ① Vacuum pump | ② Intake camshaft (bank 1) | ③ Exhaust camshaft (bank 1) |
| ④ Exhaust camshaft sprocket (bank 1) | ⑤ Exhaust valve timing control solenoid valve (bank 1) | ⑥ Turbocharger (bank 1) |
| ⑦ Oil filter | ⑧ Oil cooler | ⑨ Timing chain tensioner (bank 1) |
| ⑩ Timing chain tensioner (bank 2) | ⑪ Oil gallery | ⑫ Oil jet |
| ⑬ Main bearing | ⑭ Timing chain oil jet | ⑮ Oil pump |
| ⑯ Turbocharger (bank 2) | ⑰ Exhaust valve timing control solenoid valve (bank 2) | ⑱ Exhaust camshaft sprocket (bank 2) |
| ⑲ High pressure fuel pump | ⑳ Exhaust camshaft (bank 2) | ㉑ Intake camshaft (bank 2) |

A

LU

C

D

E

F

G

H

I

J

K

L

M

N

O

P

JSBIB0401ZZ

DESCRIPTION


< SYSTEM DESCRIPTION >

[VR30DDTT]


Engine Lubrication System Schematic

INFOID:000000013607979

ENGINE OIL COOLER AIR COOLING TYPE



ENGINE OIL COOLER WATER COOLING TYPE



PERIODIC MAINTENANCE

ENGINE OIL

Inspection

INFOID:000000013607980


LU

ENGINE OIL LEVEL

NOTE:

Before starting engine, put vehicle horizontally and check the engine oil level. If engine is already started, stop it and allow 10 minutes before checking.

1. Pull out oil level gauge and wipe it clean.
2. Insert oil level gauge and check the engine oil level is within the range **A** shown in the figure.
3. If it is out of range, adjust it.




NOTE:

When checking the engine oil level, insert oil level gauge ① with its tip aligned with oil level gauge guide.

② : Engine cover

↔ : Engine front



ENGINE OIL APPEARANCE

- Check engine oil for white turbidity or heavy contamination.
- If engine oil becomes turbid and white, it is highly probable that it is contaminated with engine coolant. Repair or replace damaged parts.

ENGINE OIL LEAKAGE

Check for engine oil leakage around the following areas:

- Oil pans (upper and lower)
- Oil pan drain plug
- Oil pressure sensor
- Oil temperature sensor
- Oil filter
- Oil cooler bracket
- Oil cooler
- Valve timing control cover
- Mating surface between cylinder head and rocker cover
- Mating surface between cylinder block and cylinder head
- Mating surface between lower cylinder block and cylinder block
- Crankshaft oil seals (front and rear)
- Camshaft position sensor and exhaust valve timing control solenoid valve

OIL PRESSURE CHECK

WARNING:

< PERIODIC MAINTENANCE >


- **Never get burn yourself, as engine oil may be hot.**
 - **Oil pressure check should be done in "Parking position".**
1. Check the engine oil level.
 2. Remove front under cover using a power tool (commercial service tool). Refer to [EXT-33, "FRONT UNDER COVER : Exploded View"](#).
 3. Disconnect harness connector at oil pressure sensor, and remove oil pressure sensor using deep socket (commercial service tool).

CAUTION:

Never drop or shock oil pressure sensor.


- 2WD models

- ① : Oil pressure sensor
- ↔ : Engine front




- AWD models

- ① : Oil pressure sensor
- ↔ : Engine front



4. Install the oil pressure gauge [SST: ST25051001 (J-25695-1)] (A) and hose [SST: ST25052000 (J-25695-2)] (B).



5. Start the engine and warm it up to normal operating temperature.
6. Check the engine oil pressure with engine running under no-load.

NOTE:

When the engine oil temperature is low, the engine oil pressure becomes high.

Engine oil pressure : Refer to [LU-41, "2WD : Engine Oil Pressure" \(2WD\)](#).
 : Refer to [LU-41, "AWD : Engine Oil Pressure" \(AWD\)](#).

If difference is extreme, check engine oil passage and oil pump for engine oil leakage.

7. After the inspections, install oil pressure sensor as follows:
 - a. Remove old liquid gasket adhering to oil pressure sensor and the mating surface.

ENGINE OIL

< PERIODIC MAINTENANCE >

[VR30DDTT]

- b. Apply liquid gasket and tighten oil pressure sensor to the specification.
Use Genuine Liquid Gasket (Three Bond 1386G or 1211) or equivalent.

Tightening torque : Refer to [EM-238, "Exploded View"](#)

- c. After warming up engine, check there is no leakage of engine oil with running engine.

Draining

INFOID:000000013607981

WARNING:

- Never get burn yourself, as engine oil may be hot.
- Prolonged and repeated contact with used engine oil may cause skin cancer. Try to avoid direct skin contact with used engine oil. If skin contact is made, wash thoroughly with soap or hand cleaner as soon as possible.

1. Warm up the engine, and check for engine oil leakage from engine components. Refer to [LU-27, "Inspection"](#).
2. Stop the engine and wait for 10 minutes.
3. Loosen oil filler cap.
4. Remove front under cover. Refer to [EXT-35, "FRONT UNDER COVER : Removal and Installation"](#).
5. Remove drain plug and then drain engine oil.

Refilling

INFOID:000000013607982

1. Install drain plug with new washer. Refer to [EM-189, "2WD : Exploded View"](#) (2WD) or [EM-190, "AWD : Exploded View"](#) (AWD).

CAUTION:

Be sure to clean drain plug and install with new washer.

2. Refill with new engine oil.
Engine oil specification and viscosity: Refer to [MA-20, "Recommended Fluids and Lubricants"](#).

Engine oil capacity : Refer to [LU-41, "2WD : Periodical Maintenance Specification"](#) (2WD).

: Refer to [LU-41, "AWD : Periodical Maintenance Specification"](#) (AWD).

CAUTION:

- When filling engine oil, do not pull out oil level gauge.
 - The refill capacity depends on the engine oil temperature and drain time. Use these specifications for reference only.
 - Always use oil level gauge to determine the proper amount of engine oil in engine.
3. Warm up the engine and check area around drain plug and oil filter for engine oil leakage.
 4. Stop the engine and wait for 10 minutes.
 5. Check the engine oil level. Refer to [LU-27, "Inspection"](#).
 6. Perform the "Engine Oil Data Reset". Refer to [EC6-278, "Description"](#) (FOR USA AND CANADA) or [EC6-1211, "Description"](#) (FOR MEXICO).

OIL FILTER

Removal and Installation

INFOID:000000013607983


REMOVAL

CAUTION:

- Oil filter is provided with relief valve. Use genuine NISSAN oil filter or equivalent.
- Never get burned when engine and engine oil may be hot.
- When removing, prepare a shop cloth to absorb any engine oil leakage or spillage.
- Never allow engine oil to adhere to drive belt.
- Completely wipe off any engine oil that adheres to engine and vehicle.


1. Remove front under cover, using a power tool. Refer to [EXT-35. "FRONT UNDER COVER : Removal and Installation"](#).
2. Using oil filter wrench [SST: KV10115801 (J-38956)] (A), remove oil filter.
 - 2WD models

↔ : Engine front




- AWD models

↔ : Engine front



INSTALLATION

1. Remove foreign materials adhering to oil filter installation surface.
2. Apply engine oil to the oil seal contact surface of new oil filter.



OIL FILTER


[VR30DDTT]

< PERIODIC MAINTENANCE >

3. Screw oil filter manually until it touches the installation surface, then tighten it by 2/3 turn **(A)**. Or tighten to the specification.

Oil filter:

: 17.7 N-m (1.8 kg-m, 13 ft-lb)



Inspection

INSPECTION AFTER INSTALLATION

1. Check the engine oil level. Refer to [LU-27. "Inspection"](#).
2. Start the engine, and check there is no leak of engine oil.
3. Stop the engine and wait for 10 minutes.
4. Check the engine oil level, and adjust the level. Refer to [LU-27. "Inspection"](#).

INFOID:000000013607984

A
LU
C
D
E
F
G
H
I
J
K
L
M
N
O
P

OIL COOLER

[VR30DDTT]

< REMOVAL AND INSTALLATION >


REMOVAL AND INSTALLATION

OIL COOLER

AIR COOLING TYPE

AIR COOLING TYPE : Exploded View

INFOID:000000013804358



- | | | |
|---------------------|----------------------|---------------------|
| ① Gasket | ② Oil cooler bracket | ③ Connector bolt |
| ④ Oil filter | ⑤ Clamp | ⑥ Oil cooler hose 1 |
| ⑦ Oil cooler hose 2 | ⑧ Gasket | ⑨ Relife valve |
| ⑩ Bracket | ⑪ Oil cooler pipe 1 | ⑫ Oil cooler hose 3 |
| ⑬ Oil cooler hose 4 | ⑭ Oil cooler pipe 2 | ⑮ Oil cooler hose 5 |
| ⑯ Oil cooler hose 6 | ⑰ Oil cooler | |

Ⓐ Comply with the installation procedure when tightening. Refer to [LU-30](#)

⇐ : Engine front

☞ : N·m (kg-m, ft-lb)

☞ : N·m (kg-m, in-lb)

⊗ : Always replace after every disassembly.


●, ▲ Indicates that the part is connected at points with same symbol in actual vehicle.

OIL COOLER

< REMOVAL AND INSTALLATION >

[VR30DDTT]

AWD



- | | | |
|---------------------|----------------------|---------------------|
| ① Gasket | ② Oil cooler bracket | ③ Connector bolt |
| ④ Oil filter | ⑤ Clamp | ⑥ Oil cooler hose 1 |
| ⑦ Oil cooler hose 2 | ⑧ Gasket | ⑨ Relife valve |
| ⑩ Oil cooler pipe 1 | ⑪ Oil cooler hose 3 | ⑫ Oil cooler hose 4 |
| ⑬ Oil cooler pipe 2 | ⑭ Oil cooler hose 5 | ⑮ Oil cooler hose 6 |
| ⑯ Oil cooler | | |

Ⓐ Comply with the installation procedure when tightening. Refer to [LU-30](#)

↔ : Engine front

Ⓜ : N·m (kg·m, ft·lb)

Ⓜ : N·m (kg·m, in·lb)

⊗ : Always replace after every disassembly.

●, ▲ Indicates that the part is connected at points with same symbol in actual vehicle.

AIR COOLING TYPE : Removal and Installation

INFOID:0000000013804359

REMOVAL

WARNING:

Never get burn yourself, as engine oil and engine coolant may be hot.

Oil cooler

1. Remove front under cover, using a power tool (commercial service tool). Refer to [EXT-35. "FRONT UNDER COVER : Removal and Installation"](#).
2. Drain engine oil. Refer to [LU-29. "Draining"](#).
3. Remove front bumper fascia. Refer to [EXT-15. "Removal and Installation"](#).
4. Disconnect oil cooler hose 5 and 6 from oil cooler.
5. Remove oil cooler mounting bolts and remove oil cooler.

OIL COOLER

< REMOVAL AND INSTALLATION >

[VR30DDTT]

Oil cooler bracket (2WD)

1. Remove front under cover, using a power tool (commercial service tool). Refer to [EXT-35, "FRONT UNDER COVER : Removal and Installation"](#).
2. Drain engine oil. Refer to [LU-29, "Draining"](#).
3. Remove oil filter. Refer to [LU-30, "Removal and Installation"](#).
4. Remove connector bolt.
5. Disconnect oil cooler hose 1 from oil cooler bracket.
6. Disconnect oil cooler hose 2 from relief valve.
7. Remove relief valve if necessary.
8. Remove oil cooler bracket.

Oil cooler bracket (AWD)

1. Remove front under cover, using a power tool (commercial service tool). Refer to [EXT-35, "FRONT UNDER COVER : Removal and Installation"](#).
2. Drain engine oil. Refer to [LU-29, "Draining"](#).
3. Disconnect oil cooler hose 1 from oil cooler bracket.
4. Disconnect oil cooler hose 2 from relief valve.
5. Remove relief valve if necessary.
6. Remove oil cooler bracket.

INSTALLATION

CAUTION:

Do not reuse gasket.

Install in the reverse order of removal.

AIR COOLING TYPE : Inspection

INFOID:000000013804360

INSPECTION AFTER REMOVAL

Oil Cooler

Check oil cooler for cracks. Check oil cooler for clogging by blowing through engine coolant inlet. If necessary, replace oil cooler.

Relief Valve

Check relief valve with the following procedure.

- Press steel ball of relief valve using a clean plastic stick. Check that valve moves smoothly and proper spring repulsion is felt.
- Replace relief valve, if necessary, with the following procedure.
- Remove the relief valve by prying using a screwdriver.

CAUTION:

Never damage the mounting hole.

- Press in the relief valve until it reaches a depth of 7 mm (0.28 in) from end surface of oil pan (upper) using approximately 10 mm (0.39 in) diameter drift.

CAUTION:

Carefully press in the relief valve by aligning its mounting hole side with the axle center so as not to cause deformation.

INSPECTION AFTER INSTALLATION

1. Check the engine oil level and the engine coolant level and add engine oil and engine coolant. Refer to [LU-27, "Inspection"](#) and [CO-33, "Inspection"](#).
2. Start the engine, and check there is no leakage of engine oil or engine coolant.
3. Stop the engine and wait for 10 minutes.
4. Check the engine oil level and the engine coolant level again. Refer to [LU-27, "Inspection"](#) and [CO-33, "Inspection"](#).

WATER COOLING TYPE


OIL COOLER

< REMOVAL AND INSTALLATION >

[VR30DDTT]

WATER COOLING TYPE : Exploded View

INFOID:000000013804361



① Oil cooler hose 1

④ Oil cooler

⑦ Hose clip

⑩ Clamp

Ⓐ To water pipe

Ⓓ To A/T fluid warmer

← : Engine front

: N·m (kg·m, ft·lb)

: N·m (kg·m, in·lb)

: Always replace after every disassembly.

●, Indicates that the part is connected at points with same symbol in actual vehicle.

② Clamp

⑤ Oil filter

⑧ Oil cooler hose 2

⑪ Oil cooler hose 3

Ⓑ Comply with the installation procedure when tightening. Refer to [LU-30](#)

Ⓒ Comply with the installation procedure when tightening. Refer to [LU-36](#)

③ O-ring

⑥ Clamp


⑨ Water pipe

OIL COOLER

< REMOVAL AND INSTALLATION >

[VR30DDTT]

AWD



- | | | |
|---|--|--|
| ① Oil cooler hose 1 | ② Clamp | ③ O-ring |
| ④ Oil cooler | ⑤ Clamp | ⑥ Hose clamp |
| ⑦ Oil cooler hose 2 | ⑧ Connector bolt | ⑨ Oil filter |
| ⑩ Water pipe | ⑪ Clamp | ⑫ Oil cooler hose 3 |
| A To water pipe | B Comply with the installation procedure when tightening. Refer to LU-36 | C Comply with the installation procedure when tightening. Refer to LU-30 |
| D To A/T fluid warmer | | |
| ← : Engine front | | |
| ⊖ : N·m (kg·m, ft·lb) | | |
| ⊖ : N·m (kg·m, in·lb) | | |
| ⊗ : Always replace after every disassembly. | | |

WATER COOLING TYPE : Removal and Installation

INFOID:0000000013804362

REMOVAL

WARNING:

Never get burn yourself, as engine oil and engine coolant may be hot.

Oil cooler

1. Remove front under cover, using a power tool. Refer to [EXT-35, "FRONT UNDER COVER : Removal and Installation"](#).
2. Drain engine coolant. Refer to [CO-33, "Draining"](#).
3. Drain engine oil. Refer to [LU-29, "Draining"](#).
4. Remove oil filter. Refer to [LU-30, "Removal and Installation"](#).
5. Remove oil cooler hose 1 and 2.
6. Loosen mounting bolts in the order from 4 to 1 as shown in the figure to remove.


OIL COOLER

[VR30DDTT]

< REMOVAL AND INSTALLATION >


- 2WD models

⇐ : Engine front



- AWD models

⇐ : Engine front



7. Remove oil cooler.

INSTALLATION

CAUTION:


Do not reuse gasket.

Note the followings, and install in the reverse order of removal.

Tighten mounting bolts in the order from 1 to 4 as shown in the figure.


- 2WD models

⇐ : Engine front



- AWD models

⇐ : Engine front



WATER COOLING TYPE : Inspection

INFOID:0000000013804363

INSPECTION AFTER REMOVAL

Oil Cooler

OIL COOLER

< REMOVAL AND INSTALLATION >

[VR30DDTT]

Check oil cooler for cracks. Check oil cooler for clogging by blowing through engine coolant inlet. If necessary, replace oil cooler.

INSPECTION AFTER INSTALLATION

1. Check the engine oil level and the engine coolant level and add engine oil and engine coolant. Refer to [LU-27. "Inspection"](#) and [CO-33. "Inspection"](#).
2. Start the engine, and check there is no leakage of engine oil or engine coolant.
3. Stop the engine and wait for 10 minutes.
4. Check the engine oil level and the engine coolant level again. Refer to [LU-27. "Inspection"](#) and [CO-33. "Inspection"](#).

UNIT DISASSEMBLY AND ASSEMBLY


OIL PUMP

Exploded View

INFOID:000000013607988

A

LU



C

D

E

F

G

H

I

J

K

L

M

N

O

P

- ① Oil pump drive chain tensioner
- ② Cover
- ③ Oil pump sprocket
- ④ Oil pump drive chain
- ⑤ Oil pump assembly
- ⑥ O-ring
- ⑦ Engine oil pressure control solenoid valve

↔ : Engine front

⊗ : Always replace after every disassembly.

⊙ : N-m (kg-m, ft-lb)

⊙ : N-m (kg-m, in-lb)

⊙ : Should be lubricated with oil.

Removal and Installation

INFOID:000000013607989

REMOVAL


1. Remove oil pan (lower). Refer to [EM-191, "Removal and Installation"](#).
2. Remove front timing chain case and timing chain. Refer to [EM-239, "Removal and Installation"](#).
3. Remove the crankshaft sprocket and the oil pump drive related parts with the following procedure.

OIL PUMP

< UNIT DISASSEMBLY AND ASSEMBLY >

[VR30DDTT]


- a. Remove chain tensioner ① (for oil pump drive chain).



- b. Remove cover.
c. Hold the top of the oil pump shaft using the TORX socket, and then loosen the oil pump sprocket nuts and remove them.

① : oil pan (upper)

⇐ : Engine front



- d. Remove the crankshaft sprocket, the oil pump drive chain, and the oil pump sprocket at the same time.
4. Remove oil pan (upper). Refer to [EM-218. "2WD : Disassembly and Assembly"](#) (2WD models) or [EM-222. "AWD : Disassembly and Assembly"](#) (AWD models).
5. Remove oil pump assembly.

INSTALLATION

Note the following, and install in the reverse order of removal.

CAUTION:

- Check that oil pump chain is correctly install on the oil pump sprocket.
- Before crank the engine, rotate crankshaft by hand to be sure that oil pump chain is correctly.
- Do not reuse O-ring.

Inspection

INFOID:000000013607990

INSPECTION AFTER INSTALLATION

1. Check the engine oil level. Refer to [LU-27. "Inspection"](#).
2. Start the engine, and check there is no leakage of engine oil.
3. Stop the engine and wait for 10 minutes.
4. Check the engine oil level and adjust the level. Refer to [LU-27. "Inspection"](#).

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[VR30DDTT]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

2WD

2WD : Periodical Maintenance Specification

INFOID:0000000013607991

ENGINE OIL CAPACITY (APPROXIMATE)

Unit: ℓ (US qt, Imp qt)

| | | |
|-----------------------|---------------------------|--------------------|
| Drain and refill | With oil filter change | 4.8 (5-1/8, 4-2/8) |
| | Without oil filter change | 4.6 (4-7/8, 4) |
| Dry engine (Overhaul) | | 6.1 (6-4/8, 5-3/8) |

2WD : Engine Oil Pressure

INFOID:0000000013607992

Unit: kPa (kg/cm², psi)

| | |
|--------------|---------------------------------|
| Engine speed | Approximate discharge pressure* |
| Idle speed | More than 40 (0.408, 5.8) |
| 2,000 rpm | More than 170 (1.734, 24.65) |

*: Engine oil temperature at 80°C (176°F)

AWD

AWD : Periodical Maintenance Specification

INFOID:0000000013607993

ENGINE OIL CAPACITY (APPROXIMATE)

Unit: ℓ (US qt, Imp qt)

| | | |
|-----------------------|---------------------------|--------------------|
| Drain and refill | With oil filter change | 5.4 (5-6/8, 4-6/8) |
| | Without oil filter change | 5.2 (5-4/8, 4-5/8) |
| Dry engine (Overhaul) | | 6.6 (7, 5-6/8) |

AWD : Engine Oil Pressure

INFOID:0000000013607994

Unit: kPa (kg/cm², psi)

| | |
|--------------|---------------------------------|
| Engine speed | Approximate discharge pressure* |
| Idle speed | More than 100 (1.02, 14.5) |
| 2,000 rpm | More than 170 (1.734, 24.65) |

*: Engine oil temperature at 80°C (176°F)