

SECTION **SE**  
SEAT

A  
B  
C

CONTENTS

D  
E

**PRECAUTION** ..... 4

**PRECAUTIONS** ..... 4

    Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....4

    Precautions for Removing Battery Terminal .....4

    Service Notice .....5

    Precaution for Work .....5

**PREPARATION** ..... 6

**PREPARATION** ..... 6

    Special Service Tool .....6

    Commercial Service Tool .....6

**CLIP LIST** ..... 7

    Clip List .....7

**SYSTEM DESCRIPTION** ..... 8

**COMPONENT PARTS** ..... 8

**POWER SEAT SYSTEM** .....8

    POWER SEAT SYSTEM : Component Parts Location .....8

**LUMBAR SUPPORT SYSTEM** .....9

    LUMBAR SUPPORT SYSTEM : Component Parts Location .....9

**SIDE SUPPORT SYSTEM** .....9

    SIDE SUPPORT SYSTEM : Component Parts Location ..... 10

**TILT & TELESCOPIC SYSTEM** ..... 10

    TILT & TELESCOPIC SYSTEM : Component Parts Location ..... 11

**HEATED SEAT SYSTEM** ..... 11

    HEATED SEAT SYSTEM : Component Parts Location ..... 12

    Power Seat Switch ..... 12

    Lumbar Support Switch .....13

    Side Support Switch .....13

**SYSTEM** ..... 14

**POWER SEAT SYSTEM** .....14

    POWER SEAT SYSTEM : System Description .....14

    POWER SEAT SYSTEM : Circuit Diagram .....15

**LUMBAR SUPPORT SYSTEM** .....15

    LUMBAR SUPPORT SYSTEM : System Description .....15

**SIDE SUPPORT SYSTEM** .....15

    SIDE SUPPORT SYSTEM : System Description ....15

**TILT & TELESCOPIC SYSTEM** .....16

    TILT & TELESCOPIC SYSTEM : System Description .....16

    TILT & TELESCOPIC SYSTEM : Circuit Diagram...17

**HEATED SEAT SYSTEM** .....17

    HEATED SEAT SYSTEM : System Description .....18

    HEATED SEAT SYSTEM : Circuit Diagram .....20

**ECU DIAGNOSIS INFORMATION** .....21

**DRIVER SEAT CONTROL UNIT, AUTOMATIC DRIVE POSITIONER CONTROL UNIT, A/C AUTO AMP.** .....21

    List of ECU Reference .....21

**WIRING DIAGRAM** .....22

**POWER SEAT CONTROL SYSTEM** .....22

    Wiring Diagram (Driver Side Without Automatic Drive Positioner) .....22

    Wiring Diagram (Passenger Side) .....27

**LUMBAR SUPPORT SYSTEM** .....33

    Wiring Diagram .....33

**SIDE SUPPORT SYSTEM** .....37

F  
G

H  
I

SE

K  
L

M

N

O

P

Wiring Diagram .....	37	<b>STEERING POSITION FUNCTION DOES NOT OPERATE</b> .....	73
<b>TILT &amp; TELESCOPIC SYSTEM</b> .....	41	Diagnosis Procedure .....	73
Wiring Diagram .....	41	<b>TILT FUNCTION DOES NOT OPERATE</b> .....	74
<b>HEATED SEAT SYSTEM</b> .....	46	Diagnosis Procedure .....	74
Wiring Diagram .....	46	<b>TELESCOPIC FUNCTION DOES NOT OPERATE</b> .....	75
<b>BASIC INSPECTION</b> .....	54	Diagnosis Procedure .....	75
<b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....	54	<b>SQUEAK AND RATTLE TROUBLE DIAGNOSES</b> .....	76
Work Flow .....	54	Work Flow .....	76
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	57	Inspection Procedure .....	78
<b>B277E HEAT SENSOR</b> .....	57	Diagnostic Worksheet .....	80
DTC Description .....	57	<b>REMOVAL AND INSTALLATION</b> .....	82
Diagnosis Procedure .....	57	<b>FRONT SEAT</b> .....	82
<b>B277F HEAT SENSOR</b> .....	59	Exploded View .....	82
DTC Description .....	59	Removal and Installation .....	83
Diagnosis Procedure .....	59	<b>SEATBACK</b> .....	85
<b>B27AF HEAT SENSOR</b> .....	61	SEATBACK : Disassembly and Assembly .....	85
DTC Description .....	61	<b>SEAT CUSHION</b> .....	90
Diagnosis Procedure .....	61	SEAT CUSHION : Disassembly and Assembly .....	90
<b>B27CF HEAT SENSOR</b> .....	63	<b>SEAT CUSHION FINISHER</b> .....	92
DTC Description .....	63	SEAT CUSHION FINISHER : Removal and Installation .....	92
Diagnosis Procedure .....	63	<b>REAR SEAT (BENCH SEAT)</b> .....	98
<b>HEATED SEAT RELAY</b> .....	65	Exploded View .....	98
Component Function Check .....	65	<b>ARMREST</b> .....	99
Diagnosis Procedure .....	65	ARMREST : Removal and Installation .....	99
Component Inspection .....	66	ARMREST : Disassembly and Assembly .....	99
<b>SEAT CUSHION HEATER</b> .....	67	<b>SEAT CUSHION</b> .....	101
<b>DRIVER SIDE</b> .....	67	SEAT CUSHION : Removal and Installation .....	101
DRIVER SIDE : Component Function Check .....	67	SEAT CUSHION : Disassembly and Assembly .....	101
DRIVER SIDE : Diagnosis Procedure .....	67	<b>SEATBACK</b> .....	101
<b>PASSENGER SIDE</b> .....	68	SEATBACK : Removal and Installation .....	101
PASSENGER SIDE :		SEATBACK : Disassembly and Assembly .....	102
Component Function Check .....	68	<b>REAR SEAT (6 : 4 SEPARATE SEAT)</b> .....	103
PASSENGER SIDE : Diagnosis Procedure .....	68	Exploded View .....	103
<b>SEATBACK HEATER</b> .....	70	<b>ARMREST</b> .....	104
<b>DRIVER SIDE</b> .....	70	ARMREST : Removal and Installation .....	104
DRIVER SIDE : Component Function Check .....	70	ARMREST : Disassembly and Assembly .....	106
DRIVER SIDE : Diagnosis Procedure .....	70	<b>SEATBACK</b> .....	107
<b>PASSENGER SIDE</b> .....	70	SEATBACK : Removal and Installation .....	107
PASSENGER SIDE :		SEATBACK : Disassembly and Assembly .....	109
Component Function Check .....	70	<b>SEAT CUSHION</b> .....	110
PASSENGER SIDE : Diagnosis Procedure .....	71	SEAT CUSHION : Removal and Installation .....	110
<b>SYMPTOM DIAGNOSIS</b> .....	72	SEAT CUSHION : Disassembly and Assembly .....	111
<b>HEATED SEAT DOES NOT OPERATE</b> .....	72		
Diagnosis Procedure .....	72		

<b>SEATBACK HINGE</b> .....	111	<b>ISO FIX BRACKET</b> .....	114	
SEATBACK HINGE : Removal and Installation ...	111	ISO FIX BRACKET : Removal and Installation ....	114	A
<b>SEAT LOCK</b> .....	111	<b>POWER SEAT SWITCH</b> .....	115	
SEAT LOCK : Removal and Installation .....	111	Removal and Installation .....	115	B
<b>CHILD SEAT ANCHOR</b> .....	113	<b>LUMBAR SUPPORT SWITCH</b> .....	116	
Exploded View .....	113	Removal and Installation .....	116	C
<b>TETHER ANCHOR PLATE</b> .....	113	<b>SIDE SUPPORT SWITCH</b> .....	117	
TETHER ANCHOR PLATE : Removal and Instal- lation .....	113	Removal and Installation .....	117	D

**SE**

- K
- L
- M
- N
- O
- P

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000012797174

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery or batteries, and wait at least 3 minutes before performing any service.


#### Precautions for Removing Battery Terminal

INFOID:000000013347362

When disconnecting the battery terminal, pay attention to the following.

- Always use a 12V battery as power source.
- Never disconnect battery terminal while engine is running.
- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
- For vehicles with the engine listed below, remove the battery terminal after a lapse of the specified time:

BR08DE	: 4 minutes	V9X engine	: 4 minutes
D4D engine	: 20 minutes	YD25DDTi	: 2 minutes
HR09DET	: 12 minutes	YS23DDT	: 4 minutes
HRA2DDT	: 12 minutes	YS23DDTT	: 4 minutes
K9K engine	: 4 minutes	ZD30DDTi	: 60 seconds
M9R engine	: 4 minutes	ZD30DDTT	: 60 seconds
R9M engine	: 4 minutes		



#### **NOTE:**

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- After high-load driving, if the vehicle is equipped with the V9X engine, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery terminal.

#### **NOTE:**

# PRECAUTIONS

## < PRECAUTION >

- Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.
- Example of high-load driving
  - Driving for 30 minutes or more at 140 km/h (86 MPH) or more.
  - Driving for 30 minutes or more on a steep slope.
- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

### NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

### NOTE:

The removal of 12V battery may cause a DTC detection error.

## Service Notice

INFOID:000000012797176

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to oil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

## Precaution for Work

INFOID:000000012797177

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and keep them.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After re-installation is completed, be sure to check that each part works normally.
- Follow the steps below to clean components.
  - Water soluble foul: Dip a soft cloth into lukewarm water, and wring the water out of the cloth to wipe the fouled area.  
Then rub with a soft and dry cloth.
  - Oily foul: Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%), and wipe the fouled area.  
Then dip a cloth into fresh water, and wring the water out of the cloth to wipe the detergent off. Then rub with a soft and dry cloth.
- Never use organic solvent such as thinner, benzene, alcohol, and gasoline.
- For genuine leather seats, use a genuine leather seat cleaner.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# PREPARATION

< PREPARATION >



## PREPARATION

### PREPARATION

#### Special Service Tool


INFOID:000000012797178

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
<p>(J-39570) Chassis ear</p>  <p style="text-align: right;">SIIA0993E</p>	<p>Locates the noise</p>
<p>(J-50397) NISSAN Squeak and Rattle Kit</p>  <p style="text-align: right;">SIIA0994E</p>	<p>Repairs the cause of noise</p>

#### Commercial Service Tool

INFOID:000000012797179

Tool name	Description
<p>Engine ear</p>  <p style="text-align: right;">SIIA0995E</p>	<p>Locates the noise</p>

# CLIP LIST

< PREPARATION >

## CLIP LIST

### Clip List

INFOID:000000012797180

Shapes	Removal & Installation	Shapes	Removal & Installation
	<p><b>Removal:</b> Remove by bending up with flat-bladed screwdrivers or clip remover.</p>		<p><b>Removal:</b></p>
	<p><b>Removal:</b> Remove with a clip remover.</p>		<p><b>Removal:</b></p>
	<p><b>Removal:</b> Push center pin to catching position. (Do not remove center pin by hitting it.)</p> <p><b>Installation:</b></p>		<p><b>Removal:</b> Holder portion of clip must be spread out to remove rod.</p>
	<p><b>Removal:</b> Remove by bending up with flat-bladed screwdrivers or clip remover.</p>		<p><b>Removal:</b></p> <ol style="list-style-type: none"> <li>Screw out with a Phillips screwdriver.</li> <li>Remove female portion with flat-bladed screwdriver.</li> </ol>
	<p><b>Removal:</b></p>		<p><b>Removal:</b></p> <p>Rotate 45° to remove.</p> <p><b>Installation:</b></p>
	<p><b>Removal:</b></p>		<p><b>Removal:</b></p>

JMJIA3734GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### POWER SEAT SYSTEM

#### POWER SEAT SYSTEM : Component Parts Location

INFOID:000000012797181



**A** Passenger side

**B** Driver side

No.	Component	Function
①	BCM	Supplies at all times the power received from battery to power seat switch.
②	Driver seat control unit	Operate the specific seat motor with the signal from power seat switch.
③	Lifting motor (rear) (passenger side)	<ul style="list-style-type: none"> <li>Lifting motor (rear) is installed to seat frame assembly.</li> <li>Lifting motor (rear) is moved upward/downward by changing the rotation direction of lifting motor (rear).</li> </ul>



# COMPONENT PARTS


## < SYSTEM DESCRIPTION >

No.	Component	Function
④	Lifting motor (front) (passenger side)	<ul style="list-style-type: none"> <li>Lifting motor (front) is installed to seat frame assembly.</li> <li>Lifting motor (front) is moved upward/downward by changing the rotation direction of lifting motor (front).</li> </ul>
⑤	Power seat switch (passenger side)	Refer to <a href="#">SE-12, "Power Seat Switch"</a> .
⑥	Sliding motor (passenger side)	<ul style="list-style-type: none"> <li>Sliding motor is installed to the seat frame assembly.</li> <li>Slides the seat forward/backward by changing the rotation direction of sliding motor.</li> </ul>
⑦	Reclining motor (passenger side)	<ul style="list-style-type: none"> <li>Reclining motor is installed to seat frame assembly.</li> <li>Seatback is reclined forward/backward by changing the rotation direction of reclining motor.</li> </ul>
⑧	Reclining motor (driver side)	<ul style="list-style-type: none"> <li>Reclining motor is installed to seat frame assembly.</li> <li>Reclining motor is activated with driver seat control unit.</li> <li>Seatback is reclined forward/backward by changing the rotation direction of reclining motor.</li> </ul>
⑨	Sliding motor (driver side)	<ul style="list-style-type: none"> <li>Sliding motor is installed to the seat frame assembly.</li> <li>Sliding motor is activated with driver seat control unit.</li> <li>Slides the seat forward/backward by changing the rotation direction of sliding motor.</li> </ul>
⑩	Power seat switch (driver side)	Refer to <a href="#">SE-12, "Power Seat Switch"</a> .
⑪	Lifting motor (front) (driver side)	<ul style="list-style-type: none"> <li>Lifting motor (front) is installed to seat frame assembly.</li> <li>Lifting motor (front) is activated with driver seat control unit.</li> <li>Lifting motor (front) is moved upward/downward by changing the rotation direction of lifting motor (front).</li> </ul>
⑫	Lifting motor (rear) (driver side)	<ul style="list-style-type: none"> <li>Lifting motor (rear) is installed to seat frame assembly.</li> <li>Lifting motor (rear) is activated with driver seat control unit.</li> <li>Lifting motor (rear) is moved upward/downward by changing the rotation direction of lifting motor (rear).</li> </ul>

## LUMBAR SUPPORT SYSTEM

### LUMBAR SUPPORT SYSTEM : Component Parts Location

INFOID:000000012797182



No.	Component	Function
①	Lumbar support motor	With the power supplied to lumbar support switch, operates the forward and backward movement of seatback support.
②	Lumbar support switch	Refer to <a href="#">SE-13, "Lumbar Support Switch"</a> .


## SIDE SUPPORT SYSTEM

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

## SIDE SUPPORT SYSTEM : Component Parts Location

INFOID:000000012797183



No.	Component	Function
①	Side support assembly	Built-in side support pump, side support valve and side support, and operates when pressing ON/OFF on side support switch.
②	Side support switch	Refer to <a href="#">SE-13. "Side Support Switch"</a> .


## TILT & TELESCOPIC SYSTEM

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

## TILT & TELESCOPIC SYSTEM : Component Parts Location

INFOID:000000012797184



**A** View with steering column cover lower

**B** View with steering column cover lower and instrument lower cover LH removed

No.	Component	Function
①	Automatic drive positioner control unit	<ul style="list-style-type: none"> <li>It communicates with driver seat control unit via UART communication.</li> <li>Perform the controls of tilt &amp; telescopic motor.</li> </ul>
②	Driver seat control unit	<ul style="list-style-type: none"> <li>It communicates with automatic drive positioner control unit via UART communication.</li> <li>Requests the operation of tilt &amp; telescopic motor to automatic drive positioner control unit.</li> </ul>
③	Tilt & telescopic switch	Tilt & telescopic switch, as a unit, transmits switch operation signal to automatic drive positioner control unit.
④	Tilt & telescopic motor	Operates by power supply from automatic drive positioner control unit.

## HEATED SEAT SYSTEM


A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

## HEATED SEAT SYSTEM : Component Parts Location

INFOID:000000012797185



**A** View with AV control unit or NAVI control unit removed

No.	Component	Function
①	Integral switch (heated seat switch LH)	Adjusts heated seat temperature and activates heated seat system. Refer to <a href="#">AV-14, "Component Parts Location"</a> for detailed installation location.
②	Integral switch (heated seat switch RH)	
③	Seatback heater	<ul style="list-style-type: none"> <li>• Warms seatback.</li> <li>• Contains heat sensor that outputs seatback heater temperature to A/C auto amp.</li> </ul>
④	Seat cushion heater	<ul style="list-style-type: none"> <li>• Warms seat cushion.</li> <li>• Contains heat sensor that outputs seat cushion heater temperature to A/C auto amp.</li> <li>• Built-in heat sensor.</li> </ul>
⑤	Heated seat relay	Supplies power to the heated seat being controlled by ignition power supply.

### Power Seat Switch


INFOID:000000012797186

- Built-in reclining switch, sliding switch and lifting switch, controls the power supplied to each motor.

# COMPONENT PARTS

## < SYSTEM DESCRIPTION >


- Installed on seat cushion outer finisher.



INFOID:000000012797187

## Lumbar Support Switch


- Controls the power supplied to lumbar support motor.
- Installed on seat cushion outer finisher (driver side).



INFOID:000000012797188

## Side Support Switch

- Controls the power supplied to side support assembly.
- Installed on seat cushion outer finisher (driver side).



A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# SYSTEM

< SYSTEM DESCRIPTION >


## SYSTEM

### POWER SEAT SYSTEM

#### POWER SEAT SYSTEM : System Description

INFOID:000000012797189

#### SYSTEM DIAGRAM



#### DESCRIPTION

Power seat can be operated regardless of the ignition switch position, because power supply is always supplied to power seat switch.

##### Sliding Operation

While operating the sliding switch located in power seat switch, sliding motor operates and makes possible the seat front and back position adjustment.

##### Reclining Operation

While operating the reclining switch located in power seat switch, reclining motor operates and makes possible the seat back forward and backward position adjustment.

##### Lifting Operation


While operating the lifting switch located in power seat switch, lifting motor operates and makes possible the seat cushion up and down position adjustment.

# SYSTEM

< SYSTEM DESCRIPTION >

## POWER SEAT SYSTEM : Circuit Diagram

INFOID:000000012797190



A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

## LUMBAR SUPPORT SYSTEM

### LUMBAR SUPPORT SYSTEM : System Description

INFOID:000000012797191

#### DESCRIPTION

- Lumbar support can operate regardless of the ignition switch position because, power supply is always supplied to lumbar support switch.
- While operating the lumbar support switch, lumbar support motor operates which allows forward and backward operation of seatback support.

## SIDE SUPPORT SYSTEM

### SIDE SUPPORT SYSTEM : System Description

INFOID:000000012797192

#### DESCRIPTION

- The pump located inside side support assembly operates when side support switch is operated, and adjusts the air pressure in seatback side support.

# SYSTEM

## < SYSTEM DESCRIPTION >


- It is possible to soften the side support, by allowing some air to escape, by deflating the solenoid located inside side support.
- It is possible to adjust seatback differently while inflating or deflating solenoid located in side support assembly.

## TILT & TELESCOPIC SYSTEM

### TILT & TELESCOPIC SYSTEM : System Description

INFOID:000000012797193

#### SYSTEM DIAGRAM



#### DESCRIPTION

Automatic driver positioner control unit is always supplied power supply from battery, and tilt and telescopic system is operative regardless of the ignition switch position.

##### Tilt Operation

- Tilt motor operates when tilt & telescopic switch is operated, and allows up or down position adjustment of steering wheel.
- Tilt sensor detects the position of steering wheel during tilt motor operation, and automatically cuts the power when the operation limit is reached.

##### Telescopic Operation

- Telescopic motor operates when tilt & telescopic switch is operated, and allows forward and backward position regulation of steering wheel.
- Telescopic sensor detects the position of steering wheel during telescopic motor operation, and automatically cuts the power when the operation limit is reached.




# SYSTEM

< SYSTEM DESCRIPTION >

## TILT & TELESCOPIC SYSTEM : Circuit Diagram

INFOID:000000012797194



A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

## HEATED SEAT SYSTEM


# SYSTEM

< SYSTEM DESCRIPTION >

## HEATED SEAT SYSTEM : System Description

INFOID:000000012797195

### SYSTEM DIAGRAM



### DESCRIPTION

- Heated seat system is activated by heated seat switch while ignition switch is ON, and has the function to warm seat cushion and seatback.
- There are two methods for operating the heated seat system: operation with the heated seat switch of the integral switch, and operation with the icon located in the display.
- The heated seat system operates in two modes: AUTO and Manual, which operates for the driver seat and passenger seat independently.
- The temperature of heated seat system can be set in three levels: Lo, Mid, or Hi.
- The status of heated seat system for driver seat and passenger seat can be checked using the integral switch display. Also, touching the operation status indicator in the display can change the temperature setting.

### OPERATION DESCRIPTION

- When the heated seat switch of integral switch is operated, the display control unit receives a switch operation signal from integral switch.
- The display control unit transmits a heated seat switch operation signal to A/C auto amp. via CAN communication.
- When A/C auto amp. receives a heated seat switch operation signal, it operates the heated seat system.
- A/C auto amp operates the heated seat system and simultaneously sends the heated seat switch indicator signal to the display control unit via CAN communication.
- When the display control unit receives a heated seat switch indicator signal, it illuminates the indicator lamp on the heated seat switch of integral switch.


### Manual Control

- The seatback heater and seat cushion heater are integrated with the heat sensors that detect the seat temperature. The heat sensors transmit the seat temperature as the heated seat signal to A/C auto amp.

# SYSTEM

## < SYSTEM DESCRIPTION >


- The A/C auto amp. recognizes the seat temperature from heat sensor signal. It adjusts the seat temperature by stopping operation when the seat temperature reaches the operation stop temperature (A), and starting operation when the seat temperature reaches the operation start temperature (B).



Preset temperature	Temperature °C (°F)	
	Temperature at operation stop	Temperature at operation start
Lo	26.67 (80.0)	25.67 (78.2)
Mid	37.67 (99.8)	36.67 (98.0)
Hi	45 (113)	44 (111.2)

### AUTO Control

- The seatback heater and seat cushion heater are integrated with the heat sensors that detect the seat temperature. The heat sensors transmit the seat temperature as the heated seat signal to A/C auto amp.
- The A/C auto amp. recognizes the seat temperature from heat sensor signal. It adjusts the seat temperature by stopping operation when the seat temperature reaches the operation stop temperature (A), and starting operation when the seat temperature reaches the operation start temperature (B).



- The A/C auto amp. adjusts the seat temperature automatically based on the temperature felt by the customer, which is calculated from the in-vehicle temperature, ambient temperature, sunload, and seat temperature setting.

Preset temperature	Temperature °C (°F)		
	Heat sensor detection temperature	Temperature at operation stop	Temperature at operation start
AUTO	0 (0)	1 (33.8)	0 (0)
	36.67 (98.0)	1 (33.8)	0 (0)
	37 (98.6)	22 (71.6)	21.67 (71.0)
	38 (100.4)	26.67 (80.0)	26.34 (79.4)
	43 (109.4)	50 (122)	49.67 (121.4)


- Temperature setting during AUTO control can be performed by operating the integral switch display.

# SYSTEM

< SYSTEM DESCRIPTION >

## HEATED SEAT SYSTEM : Circuit Diagram

INFOID:000000012797196



# DRIVER SEAT CONTROL UNIT, AUTOMATIC DRIVE POSITIONER CONTROL UNIT, A/C AUTO AMP.

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

DRIVER SEAT CONTROL UNIT, AUTOMATIC DRIVE POSITIONER CONTROL UNIT, A/C AUTO AMP.

List of ECU Reference

INFOID:0000000012797197

ECU		Reference
Driver seat control unit	Reference Value	<a href="#">ADP-35, "Reference Value"</a>
	Fail-safe	<a href="#">ADP-41, "Fail-Safe"</a>
	DTC Index	<a href="#">ADP-42, "DTC Index"</a>
Automatic drive positioner control unit	Reference Value	<a href="#">ADP-43, "Reference Value"</a>
A/C auto amp.	Reference Value	<a href="#">HAC-44, "Reference Value"</a>
	Fail-safe	<a href="#">HAC-47, "Fail-safe"</a>
	DTC Index	<a href="#">HAC-48, "DTC Index"</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# POWER SEAT CONTROL SYSTEM


< WIRING DIAGRAM >

## WIRING DIAGRAM

### POWER SEAT CONTROL SYSTEM

Wiring Diagram (Driver Side Without Automatic Drive Positioner)

INFOID:000000012797198



# POWER SEAT CONTROL SYSTEM

< WIRING DIAGRAM >

## POWER SEAT FOR DRIVER SIDE WITHOUT AUTOMATIC DRIVE POSITIONER

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



17	1	43	1	17
28	2	15	2	15
23	7	83	22	45
6	47	48	48	48

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	LG	-
5	P	-
6	V	-
7	P	- [Without Gateway]
17	R	- [With Gateway]
21	BG	-
22	BR	-
23	BG	-
28	R	-
33	L	-
43	B	-
45	G	-
46	BG	-
47	R	-
48	GR	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	TH80PW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	L	-
4	LG	-
5	Y	-
6	R	-
7	V	-
8	LG	-
10	BG	-
11	BG	-
12	LG	-
13	GR	-
14	R	-
15	L	-
16	V	-
18	W	-
19	BR	-
20	W	-
22	R	-
23	V	-
24	R	- [With 2.0L turbo gasoline engine]
24	Y	- [With VR30 engine]
25	P	- [With 2.0L turbo gasoline engine and without gateway]
25	V	- [With 2.0L turbo gasoline engine and with gateway]
25	W	- [With VR30 engine]
26	G	-
27	R	-
28	R	-
31	B	- [With VR30 engine]
31	BR	- [With 2.0L turbo gasoline engine]
32	B	-
33	B	-
34	LG	-
35	P	-
36	W	-
37	SB	-
38	LG	-
40	P	-
41	SB	-
42	BR	-
43	BG	-
44	BG	-
46	R	-
50	W	-
51	SB	-
52	V	-
53	LG	-

Terminal No.	Color Of Wire	Signal Name [Specification]
54	R	-
55	R	-
57	W	-
58	V	-
59	GR	-
60	G	-
61	G	-
62	BG	-
63	BR	-
64	Y	-
66	R	-
70	R	-
71	W	-
72	B	-
73	W	-
74	L	-
75	R	- [Without paddle shift]
75	V	- [With paddle shift]
76	BR	-
77	B	-
78	SB	-
79	V	- [With VR30 engine]
79	W	- [With 2.0L turbo gasoline engine]
81	B	-
82	R	-
83	BG	-
84	L	-
85	R	- [Without paddle shift]
85	V	- [With paddle shift]
86	B	-
88	G	-
89	V	- [With 2.0L turbo gasoline engine]
89	W	- [With VR30 engine]
91	GR	-
94	GR	-
96	Y	-
97	V	-
98	BR	- [With VR30 engine and with BOSE system]
98	Y	- [Except with VR30 engine and with BOSE system]

Connector No.	B600
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



17	1	43	2	15	21	28
148	48	47	6	45	22	33
7	23					

Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
5	-	-
6	-	-
7	-	-
17	-	-
21	-	-
22	-	-
23	-	-
28	-	-
33	-	-
43	-	-
45	-	-
46	-	-
47	-	-
48	-	-

Connector No.	B601
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH32FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
2	BR	UART (TX/RX)
3	R	START SW

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# POWER SEAT CONTROL SYSTEM

< WIRING DIAGRAM >

## POWER SEAT FOR DRIVER SIDE WITHOUT AUTOMATIC DRIVE POSITIONER

4	P	PULSE (RECLINER)
5	V	PULSE (TELESCOPIC)
6	GY	ADDRESS 2
7	G	IND 2
8	V	SLIDE SW (BACKWARD)
9	W	RECLINER SW (BACKWARD)
10	O	TILT SW (DOWNWARD)
11	G	LIFTER SW (DOWNWARD)
12	SB	POWER SUPPLY (ENCODER)
17	P	CANL
18	LG	PULSE (GLIDE SENSOR)
19	W	PULSE (LIFTER - FRONT)
20	GY	PULSE (LIFTER - REAR)
21	SB	PULSE (TILT SENSOR)
22	O	ADDRESS 1
23	W	IND 1
24	P	SLIDE SW (FORWARD)
25	Y	RECLINER SW (FORWARD)
26	GY	TILT SW (UPWARD)
27	L	LIFTER SW (UPWARD)
28	Y	SET SW

Connector No.	B602
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	NS12FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
33	R	BAT (PTC)
34	V	SLIDE MOTOR (BACKWARD)
35	Y	RECLINER MOTOR (FORWARD)
36	O	TILT MOTOR (DOWNWARD)
38	P	SLIDE MOTOR (FORWARD)
39	W	RECLINER MOTOR (BACKWARD)
40	GY	TILT MOTOR (UPWARD)
41	L	REAR LIFTER MOTOR (UPWARD)
42	G	REAR LIFTER MOTOR (DOWNWARD)
43	B	GND

Connector No.	B603
Connector Name	POWER SEAT SWITCH
Connector Type	NS10FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
8	V	SLIDE SW (BACKWARD)
9	W	RECLINER SW (BACKWARD)
10	O	TILT SW (DOWNWARD)
11	G/B	LIFTER SW (DOWNWARD)
24	P	SLIDE SW (FORWARD)
25	Y	RECLINER SW (FORWARD)
26	GY	TILT SW (UPWARD)
27	L	LIFTER SW (UPWARD)
43	B	GND

Connector No.	B604
Connector Name	SLIDING MOTOR
Connector Type	YAZAKI_7123-1460



Terminal No.	Color Of Wire	Signal Name [Specification]
12	SB	-
13	SB	-
15	G	-
34	V	-
38	P	-
43	B	-

Connector No.	B605
Connector Name	RECLINING MOTOR
Connector Type	YAZAKI_7123-1460



Terminal No.	Color Of Wire	Signal Name [Specification]
4	P	-
12	SB	-
35	Y	-
39	W	-
43	B	-

Connector No.	B606
Connector Name	LIFTING MOTOR (REAR)
Connector Type	YAZAKI_7123-1460




Terminal No.	Color Of Wire	Signal Name [Specification]
12	SB	-
19	GY	-
20	GY	-
41	L	-
42	G	-
43	B	-

Connector No.	B607
Connector Name	LIFTING MOTOR (FRONT)
Connector Type	YAZAKI_7123-1460



Terminal No.	Color Of Wire	Signal Name [Specification]
12	SB	-
19	W	-
20	-	-
36	O	-
40	GY	-
43	B	-

Connector No.	E25
Connector Name	WIRE TO WIRE
Connector Type	TH8DFW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
6	V	-
7	L	-
8	BG	- [With VR30 engine]
8	BR	- [With 2.0L turbo gasoline engine]
9	B	- [With 2.0L turbo gasoline engine]
9	GR	- [With VR30 engine] (Color of wire differs depending on production)
9	LG	- [With VR30 engine] (Color of wire differs depending on production)
10	BR	-
11	L	-
12	GR	- [With VR30 engine]
12	P	- [With 2.0L turbo gasoline engine]
13	SHIELD	- [With 2.0L turbo gasoline engine]
13	W	- [With VR30 engine]



# POWER SEAT CONTROL SYSTEM

< WIRING DIAGRAM >

## POWER SEAT FOR DRIVER SIDE WITHOUT AUTOMATIC DRIVE POSITIONER

14	B	-	-	-	-
15	GR	-	[With 2.0L turbo gasoline engine]	-	-
16	BR	-	[With VR30 engine]	-	-
17	BR	-	[With VR30 engine]	-	-
18	G	-	[With 2.0L turbo gasoline engine]	-	-
19	Y	-	[With VR30 engine]	-	-
20	W	-	[With 2.0L turbo gasoline engine]	-	-
21	Y	-	[With VR30 engine]	-	-
22	GR	-	[With 2.0L turbo gasoline engine]	-	-
23	L	-	[With VR30 engine]	-	-
24	P	-	[With VR30 engine]	-	-
25	W	-	[With 2.0L turbo gasoline engine]	-	-
26	GR	-	[With VR30 engine]	-	-
27	W	-	[With 2.0L turbo gasoline engine]	-	-
28	B	-	[With VR30 engine]	-	-
29	Y	-	[With VR30 engine]	-	-
30	GR	-	[With 2.0L turbo gasoline engine]	-	-
31	L	-	[With VR30 engine]	-	-
32	W	-	[With 2.0L turbo gasoline engine]	-	-
33	Y	-	[With VR30 engine]	-	-
34	P	-	[With VR30 engine]	-	-
35	GR	-	[With 2.0L turbo gasoline engine]	-	-
36	R	-	[With VR30 engine]	-	-
37	L	-	[With VR30 engine]	-	-
38	L	-	[With VR30 engine]	-	-
39	BR	-	[With 2.0L turbo gasoline engine and without gateway]	-	-
40	SB	-	[With 2.0L turbo gasoline engine]	-	-
41	LG	-	[With VR30 engine]	-	-
42	Y	-	[With VR30 engine]	-	-
43	W	-	[With 2.0L turbo gasoline engine]	-	-
44	Y	-	[With VR30 engine]	-	-
45	W	-	[With VR30 engine]	-	-
46	B	-	[With VR30 engine]	-	-
47	G	-	[With 2.0L turbo gasoline engine]	-	-
48	SHIELD	-	-	-	-
49	R	-	-	-	-
50	GR	-	[With VR30 engine]	-	-
51	L	-	[With 2.0L turbo gasoline engine]	-	-
52	W	-	-	-	-
53	Y	-	-	-	-
54	W	-	[With VR30 engine]	-	-
55	B	-	[With 2.0L turbo gasoline engine]	-	-
56	BG	-	[With VR30 engine]	-	-
57	W	-	[With VR30 engine]	-	-
58	B	-	[With 2.0L turbo gasoline engine]	-	-

58	B/W	-	[Color of wire differs depending on production]	-	-
59	W	-	-	-	-
61	R	-	-	-	-
64	Y	-	[Color of wire differs depending on production]	-	-
65	BR	-	[Color of wire differs depending on production]	-	-
66	GR	-	[Color of wire differs depending on production]	-	-
67	LG	-	-	-	-
68	RG	-	-	-	-
69	L	-	-	-	-
70	R	-	-	-	-
71	G	-	[With 2.0L turbo gasoline engine]	-	-
72	L	-	[With VR30 engine]	-	-
73	V	-	[With 2.0L turbo gasoline engine]	-	-
74	W	-	[With VR30 engine]	-	-
75	P	-	[With 2.0L turbo gasoline engine and without gateway]	-	-
76	R	-	[With 2.0L turbo gasoline engine and with gateway]	-	-
77	Y	-	[With VR30 engine]	-	-
78	LG	-	[With 2.0L turbo gasoline engine and with ADAS]	-	-
79	P	-	[With VR30 engine]	-	-
80	V	-	[With 2.0L turbo gasoline engine and without ADAS]	-	-
81	R	-	-	-	-
82	V	-	[With 2.0L turbo gasoline engine]	-	-
83	BR	-	[With 2.0L turbo gasoline engine]	-	-
84	LG	-	[With VR30 engine]	-	-
86	RG	-	-	-	-
87	G	-	-	-	-
89	LG	-	[With VR30 engine]	-	-
90	GR	-	[With 2.0L turbo gasoline engine]	-	-
91	G	-	-	-	-
93	BG	-	-	-	-
94	GR	-	[With VR30 engine]	-	-
94	L	-	[With 2.0L turbo gasoline engine]	-	-
95	BG	-	[With VR30 engine]	-	-
95	R	-	[With 2.0L turbo gasoline engine and without gateway]	-	-
96	W	-	[With 2.0L turbo gasoline engine and with gateway]	-	-
97	LG	-	-	-	-
98	L	-	-	-	-
99	LG	-	[With 2.0L turbo gasoline engine]	-	-

99	P	-	[With VR30 engine]	-	-
100	SHIELD	-	-	-	-

Connector No.	MT19
Connector Name	WIRE TO WIRE
Connector Type	TH80MWC316-TM4



Terminal No.	Wire	Color Of	Signal Name [Specification]
1	Y	-	-
2	G	-	-
3	SB	-	-
4	BR	-	-
5	Y	-	-
6	R	-	-
7	W	-	-
8	V	-	-
10	BG	-	-
11	BR	-	-
12	LG	-	-
13	GR	-	-
14	R	-	-
15	L	-	-
16	V	-	-
18	W	-	-
19	BR	-	-
20	W	-	-
22	SB	-	-
23	R	-	-
24	Y	-	[With 2.0L turbo gasoline engine]
24	Y	-	[With VR30 engine]
25	P	-	[With 2.0L turbo gasoline engine]
25	W	-	[With VR30 engine]
26	G	-	-
27	R	-	-
28	R	-	-
31	BR	-	-
32	B	-	-
33	B	-	-
34	V	-	-
35	P	-	-

35	W	-	-	-	-
37	SR	-	-	-	-
38	LG	-	-	-	-
40	P	-	-	-	-
41	G	-	-	-	-
42	BR	-	-	-	-
43	BR	-	-	-	-
44	BR	-	-	-	-
46	BG	-	-	-	-
50	W	-	-	-	-
51	V	-	-	-	-
52	V	-	-	-	-
53	LG	-	-	-	-
54	R	-	-	-	-
55	R	-	-	-	-
57	W	-	-	-	-
58	V	-	-	-	-
59	BG	-	-	-	-
60	G	-	-	-	-
61	G	-	-	-	-
62	BG	-	-	-	-
63	BR	-	-	-	-
64	Y	-	-	-	-
66	R	-	-	-	-
70	LG	-	-	-	-
71	W	-	-	-	-
72	B	-	-	-	-
73	W	-	-	-	-
74	L	-	-	-	-
75	W	-	-	-	-
76	BR	-	-	-	-
77	B	-	-	-	-
78	SR	-	-	-	-
79	P	-	[With VR30 engine]	-	-
79	W	-	[With 2.0L turbo gasoline engine]	-	-
81	B	-	-	-	-
82	R	-	-	-	-
83	BG	-	-	-	-
84	L	-	-	-	-
85	W	-	-	-	-
86	B	-	-	-	-
88	G	-	-	-	-
89	V	-	[With 2.0L turbo gasoline engine]	-	-
91	GR	-	[With VR30 engine]	-	-
94	GR	-	-	-	-
96	W	-	-	-	-
97	V	-	-	-	-
98	BR	-	[With VR30 engine and with BOSE system]	-	-
98	Y	-	[Except with VR30 engine and with BOSE system]	-	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# POWER SEAT CONTROL SYSTEM

< WIRING DIAGRAM >

## POWER SEAT FOR DRIVER SIDE WITHOUT AUTOMATIC DRIVE POSITIONER

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Type	TH80MVF-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
6	W/B	-
7	V	-
8	BG	- [With VR30 engine]
8	BR	- [With 2.0L turbo gasoline engine]
9	LG	- [With VR30 engine]
9	P	- [With 2.0L turbo gasoline engine]
10	W	-
11	W	- [With VR30 engine]
11	Y	- [With 2.0L turbo gasoline engine]
12	B	- [With VR30 engine]
12	BR	- [With 2.0L turbo gasoline engine]
13	GR	- [With VR30 engine]
13	SHIELD	- [With 2.0L turbo gasoline engine]
14	B	-
15	BG	- [With 2.0L turbo gasoline engine]
15	S8	- [With VR30 engine]
16	B	-
16	BR	- [With 2.0L turbo gasoline engine]
17	LG	-
18	B	- [With VR30 engine]
18	W/B	- [With 2.0L turbo gasoline engine]
19	Y	-
31	W	-
32	G	- [With 2.0L turbo gasoline engine]
32	V	- [With VR30 engine]
33	L	- [With VR30 engine]
33	Y	- [With 2.0L turbo gasoline engine]
34	P	-
35	BG	-
36	G	-
37	B	- [With VR30 engine]
37	L	- [With 2.0L turbo gasoline engine]
38	L	- [With VR30 engine]
38	P	- [With 2.0L turbo gasoline engine and without gateway]
38	R	- [With 2.0L turbo gasoline engine and with gateway]

39	R	- [With 2.0L turbo gasoline engine]
39	Y	- [With VR30 engine]
40	GR	-
41	L	-
44	BR	-
45	L	- [With 2.0L turbo gasoline engine]
45	W	- [With VR30 engine]
46	G	- [With VR30 engine]
46	Y	- [With 2.0L turbo gasoline engine]
47	BG	- [With 2.0L turbo gasoline engine]
47	R	- [With VR30 engine]
48	SHIELD	-
49	B	- [With VR30 engine]
49	G	- [With 2.0L turbo gasoline engine]
50	B	- [With 2.0L turbo gasoline engine]
50	BR	- [With VR30 engine]
51	L	-
52	W	-
53	G	-
54	SB	- [With 2.0L turbo gasoline engine]
54	Y	- [With VR30 engine]
55	B	- [With 2.0L turbo gasoline engine]
55	P	- [With VR30 engine]
56	BG	- [With VR30 engine]
56	GR	- [With 2.0L turbo gasoline engine]
57	GR	- [With VR30 engine]
57	P	- [With 2.0L turbo gasoline engine]
58	B	-
59	SB	-
61	W/B	-
64	Y	-
65	R	- [Color of wire differs depending on production]
66	P	- [Color of wire differs depending on production]
66	V	- [Color of wire differs depending on production]
67	LG	-
68	BG	-
69	L	-
70	R	-
71	V	- [With VR30 engine]
71	W	- [With 2.0L turbo gasoline engine]
72	L	- [With 2.0L turbo gasoline engine]
72	LG	- [With VR30 engine]
73	R	- [With VR30 engine]
73	W	- [With 2.0L turbo gasoline engine]
74	BR	- [With VR30 engine]
74	L	- [With 2.0L turbo gasoline engine]
75	B	- [With VR30 engine]
75	P	- [With 2.0L turbo gasoline engine and without gateway]
75	R	- [With 2.0L turbo gasoline engine and with gateway]
76	W/B	-

Connector No.	M118
Connector Name	CIRCUIT BREAKER
Connector Type	MO2FM-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	S8	-

JR1JWD4863GB

# POWER SEAT CONTROL SYSTEM


< WIRING DIAGRAM >

## Wiring Diagram (Passenger Side)

INFOID:00000001279199

### POWER SEAT FOR PASSENGER SIDE

2L : 2.0L Turbo gasoline engine  
 VR : With VR engine



\*: This connector is not shown in "Harness Layout".

2015/11/27

JRJD4243GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# POWER SEAT CONTROL SYSTEM

< WIRING DIAGRAM >

## POWER SEAT FOR PASSENGER SIDE

Connector No.	B58
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-C5



33	47	43
46	48	45

Terminal No.	Color Of Wire	Signal Name (Specification)
33	R	-
43	B	-
45	G	-
46	R	-
47	BR	-
48	V	-

Connector No.	B62
Connector Name	WIRE TO WIRE
Connector Type	TH80PW-C516-TM4



41	42	43	44	45	46	47	48
49	50	51	52	53	54	55	56

Terminal No.	Color Of Wire	Signal Name (Specification)
1	BR	- [With 2.0L turbo gasoline engine and without BOSE system]
1	LG	- [With VR30 engine]
1	W	- [With 2.0L turbo gasoline engine and without BOSE system]
2	L	- [With VR30 engine]
2	SHIELD	- [With 2.0L turbo gasoline engine]
3	BR	- [With 2.0L turbo gasoline engine]
3	R	- [With VR30 engine and with BOSE system]
3	W	- [With VR30 engine and without BOSE system]
4	SHIELD	- [With VR30 engine]
4	Y	- [With 2.0L turbo gasoline engine]
5	G	- [With VR30 engine]
5	V	- [With 2.0L turbo gasoline engine]
6	BG	- [With VR30 engine]

81	B	- [With VR30 engine]
81	R	- [With 2.0L turbo gasoline engine]
82	G	- [With 2.0L turbo gasoline engine]
82	SHIELD	- [With VR30 engine]
83	R	- [With 2.0L turbo gasoline engine]
83	W	- [With VR30 engine]
84	BR	- [With VR30 engine]
84	SHIELD	- [With 2.0L turbo gasoline engine]
85	BG	- [With VR30 engine]
85	G	- [With 2.0L turbo gasoline engine]
86	R	- [With 2.0L turbo gasoline engine]
86	W	- [With VR30 engine]
87	LG	- [With VR30 engine]
87	SHIELD	- [With 2.0L turbo gasoline engine]
89	LG	-
90	P	- [With 2.0L turbo gasoline engine]
90	V	- [With VR30 engine]
92	L	- [With 2.0L turbo gasoline engine]
92	W	- [With VR30 engine]
93	R	- [With VR30 engine]
93	SHIELD	- [With 2.0L turbo gasoline engine]
94	R	-
95	L	- [With 2.0L turbo gasoline engine]
95	Y	- [With VR30 engine]
96	R	- [With 2.0L turbo gasoline engine]
96	W	- [With VR30 engine]
97	L	- [With VR30 engine]
97	R	- [With 2.0L turbo gasoline engine and with BOSE system]
97	W	- [With 2.0L turbo gasoline engine and without BOSE system]
98	LG	-
99	BR	- [With VR30 engine and with BOSE system]
99	P	- [With 2.0L turbo gasoline engine]
99	Y	- [With VR30 engine and without BOSE system]
100	BR	- [With VR30 engine]
100	W	- [With 2.0L turbo gasoline engine]

39	R	- [With 2.0L turbo gasoline engine]
39	W	- [With VR30 engine and with BOSE system]
40	G	-
41	L	-
42	R	-
43	SHIELD	-
44	P	-
45	B	- [With 2.0L turbo gasoline engine]
45	G	- [With VR30 engine]
46	SHIELD	-
47	G	-
48	BG	-
49	G	-
50	V	-
51	GR	-
52	W	- [With 2.0L turbo gasoline engine]
52	Y	- [With VR30 engine]
53	R	-
54	GR	-
55	L	-
56	V	-
57	R	-
58	LG	-
59	P	-
61	L	-
62	P	- [With VR30 engine]
62	V	- [With 2.0L turbo gasoline engine]
63	L	-
64	W	-
66	LG	-
68	L	-
69	P	-
71	GR	- [With 2.0L turbo gasoline engine]
71	R	- [With VR30 engine]
72	G	- [With 2.0L turbo gasoline engine]
72	Y	- [With VR30 engine]
73	R	- [With 2.0L turbo gasoline engine]
73	SHIELD	- [With VR30 engine]
74	BG	- [With 2.0L turbo gasoline engine]
74	V	- [With VR30 engine]
75	GR	- [With 2.0L turbo gasoline engine]
75	V	- [With VR30 engine]
76	GR	- [With VR30 engine]
76	V	- [With 2.0L turbo gasoline engine]
77	P	-
78	L	-
79	R	-
80	GR	- [With 2.0L turbo gasoline engine]
80	W	- [With VR30 engine]

6	BR	- [With 2.0L turbo gasoline engine]
7	B	- [With 2.0L turbo gasoline engine and with BOSE system]
7	BR	- [With VR30 engine and without BOSE system]
7	W	- [With VR30 engine and with BOSE system]
7	Y	- [With 2.0L turbo gasoline engine and without BOSE system]
8	G	- [With VR30 engine and with BOSE system]
8	B	- [With 2.0L turbo gasoline engine]
8	V	- [With VR30 engine and without BOSE system]
9	LG	- [With 2.0L turbo gasoline engine]
9	SHIELD	- [With VR30 engine]
10	V	-
11	GR	-
12	Y	-
13	R	-
14	BG	-
15	BG	- [With 2.0L turbo gasoline engine]
15	GR	- [With VR30 engine]
16	V	-
17	P	-
18	L	-
19	R	-
20	GR	-
21	R	-
22	V	-
23	W	-
24	BG	- [With 2.0L turbo gasoline engine]
24	V	- [With VR30 engine]
25	L	- [With 2.0L turbo gasoline engine]
25	SB	- [With VR30 engine]
26	G	- [With VR30 engine]
26	W	- [With 2.0L turbo gasoline engine]
27	R	-
29	LG	-
30	LG	- [With 2.0L turbo gasoline engine]
30	P	- [With VR30 engine]
31	SHIELD	-
32	L	-
33	B	- [With VR30 engine]
32	LG	- [With 2.0L turbo gasoline engine]
34	SHIELD	-
35	LG	- [With VR30 engine]
35	W	- [With 2.0L turbo gasoline engine]
36	R	- [With VR30 engine]
36	W	- [With 2.0L turbo gasoline engine]
37	P	- [With 2.0L turbo gasoline engine and without BOSE system]
37	R	- [With VR30 engine]
37	W	- [With 2.0L turbo gasoline engine and with BOSE system]
38	W	-
39	P	- [With VR30 engine and without BOSE system]


JR1JWD4864GB

# POWER SEAT CONTROL SYSTEM

< WIRING DIAGRAM >


## POWER SEAT FOR PASSENGER SIDE

Connector No.	B613
Connector Name	WIRE TO WIRE
Connector Type	NS16BMW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
33	-	-
43	-	-
45	-	-
46	-	-
47	-	-
48	-	-

Connector No.	B614
Connector Name	POWER SEAT SWITCH
Connector Type	NS10FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
33	-	-
34	-	-
35	-	-
36	-	-
38	-	-
39	-	-
40	-	-
41	-	-
42	-	-
43	-	-

Connector No.	B615
Connector Name	SLIDING MOTOR
Connector Type	YAZAKI_7123-1460



Terminal No.	Color Of Wire	Signal Name [Specification]
34	-	-
38	-	-

Connector No.	B616
Connector Name	RECLINING MOTOR
Connector Type	YAZAKI_7123-1460



Terminal No.	Color Of Wire	Signal Name [Specification]
35	-	-
39	-	-

Connector No.	B617
Connector Name	LIFTING MOTOR (REAR)
Connector Type	YAZAKI_7123-1460



Terminal No.	Color Of Wire	Signal Name [Specification]
41	-	-
42	-	-

Connector No.	B618
Connector Name	LIFTING MOTOR (FRONT)
Connector Type	YAZAKI_7123-1460



Terminal No.	Color Of Wire	Signal Name [Specification]
36	-	-
40	-	-

Connector No.	EZ5
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
6	V	-
7	L	-
8	BC	- [With VR30 engine]
8	BR	- [With 2.0L turbo gasoline engine]
9	B	- [With 2.0L turbo gasoline engine]
9	GR	- [With VR30 engine] (Color of wire differs depending on production)
9	LG	- [With VR30 engine] (Color of wire differs depending on production)
10	BR	-
11	L	-
12	GR	- [With VR30 engine]
12	P	- [With 2.0L turbo gasoline engine]
13	SHIELD	- [With 2.0L turbo gasoline engine]
13	W	- [With VR30 engine]
14	B	-
15	GR	- [With 2.0L turbo gasoline engine]
15	SR	- [With VR30 engine]
16	BR	- [With 2.0L turbo gasoline engine]
16	Y	- [With VR30 engine]
17	BR	- [With VR30 engine]
17	GR	- [With 2.0L turbo gasoline engine]
18	G	- [With 2.0L turbo gasoline engine]
18	P	- [With VR30 engine]
19	Y	-
31	W	- [With 2.0L turbo gasoline engine]
31	T	- [With VR30 engine]
32	G	- [With 2.0L turbo gasoline engine]
32	GR	- [With VR30 engine]
33	L	- [With VR30 engine]
33	Y	- [With 2.0L turbo gasoline engine]
34	P	-
35	GR	-
36	R	-
37	L	- [With 2.0L turbo gasoline engine]
37	V	- [With VR30 engine]
38	L	- [With VR30 engine]

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# POWER SEAT CONTROL SYSTEM

< WIRING DIAGRAM >

## POWER SEAT FOR PASSENGER SIDE

38	P	- [With 2.0L turbo gasoline engine and without gateway] - [With 2.0L turbo gasoline engine and with gateway]
39	BR	- [With VR30 engine]
40	SB	- [With VR30 engine]
41	LG	-
44	Y	-
45	L	- [With 2.0L turbo gasoline engine]
46	B	- [With VR30 engine]
47	G	- [With VR30 engine]
48	SHIELD	-
49	R	-
50	GR	- [With VR30 engine]
51	L	- [With 2.0L turbo gasoline engine]
52	W	-
53	V	-
54	P	- [With VR30 engine]
55	B	- [With 2.0L turbo gasoline engine]
56	BG	- [With VR30 engine]
57	BG	- [With VR30 engine]
58	B	- [With 2.0L turbo gasoline engine]
59	W	- [Color of wire differs depending on production]
61	R	-
64	Y	- [Color of wire differs depending on production]
65	BR	- [Color of wire differs depending on production]
66	GR	- [Color of wire differs depending on production]
67	LG	-
68	BG	-
69	L	-
70	R	-
71	G	- [With 2.0L turbo gasoline engine]
72	L	- [With VR30 engine]
73	G	- [With VR30 engine]
74	BR	- [With VR30 engine]
75	P	- [With 2.0L turbo gasoline engine and without gateway] - [With 2.0L turbo gasoline engine and with gateway]
75	R	- [With VR30 engine]

76	G	-
77	Y	- [With 2.0L turbo gasoline engine and with ADAS] - [With VR30 engine]
78	V	- [With VR30 engine]
79	SB	-
80	G	-
81	R	-
82	BR	- [With 2.0L turbo gasoline engine]
83	BR	- [With VR30 engine]
84	LG	- [With VR30 engine]
86	BG	-
87	G	-
89	G	-
90	G	- [With VR30 engine]
91	GR	- [With 2.0L turbo gasoline engine]
93	BG	-
94	GR	- [With VR30 engine]
94	L	- [With 2.0L turbo gasoline engine]
95	BG	- [With VR30 engine]
95	P	- [With 2.0L turbo gasoline engine and without gateway]
95	R	- [With 2.0L turbo gasoline engine and with gateway]
96	W	-
97	LG	-
98	L	-
99	LG	- [With 2.0L turbo gasoline engine]
99	P	- [With VR30 engine]
100	SHIELD	-

Connector No.	M17
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEAD9FW-FH46-5A




137	138	139	140	141	142	143	144	145	146
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

Terminal No.	Color Of Wire	Signal Name [Specification]
129	LG	INT ROOM LAMP PWR SPLY
130	P	PASS DOOR UNLK OUTPUT
131	Y	BAT (FUSE)
132	V	RR, R, L DOOR LK OUTPUT

133	BR	RR, R, DOOR UNLK OUTPUT
134	B	GNL
135	V	FRONT DOOR, FL LID LK OUTPUT
136	V	INT ROOM LAMP CONT
137	LG	FRONT DOOR, FL LID UNLK OUTPUT
138	P	REAR DOORS ACT PWR SPLY [With VR30 engine]
138	R	REAR DOORS ACT PWR SPLY [With 2.0L turbo gasoline engine]
139	W	BAT (F/L)
140	BR	IGN ON
141	R	PWR SPLY (BAT)
142	R	FRONT DOORS, FL LID ACT PWR SPLY
143	B	GNL

Connector No.	M22
Connector Name	WIRE TO WIRE
Connector Type	TH8BMM-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	SHIELD	- [With VR30 engine]
3	BR	- [With 2.0L turbo gasoline engine]
3	R	- [With VR30 engine]
4	SHIELD	- [With VR30 engine]
4	Y	- [With 2.0L turbo gasoline engine]
5	G	- [With VR30 engine]
5	V	- [With 2.0L turbo gasoline engine]
6	BG	- [With VR30 engine]
6	BR	- [With 2.0L turbo gasoline engine]
7	LG	- [With VR30 engine]
7	P	- [With 2.0L turbo gasoline engine]
8	G	- [With 2.0L turbo gasoline engine]
8	P	- [With VR30 engine]
9	LG	- [With 2.0L turbo gasoline engine]
9	SHIELD	- [With VR30 engine]
10	V	-
11	GR	-
12	V	-
13	LG	-
14	LG	-

15	BR	- [With 2.0L turbo gasoline engine]
15	P	- [With VR30 engine]
16	SB	- [With DCM]
17	V	- [Without DCM]
17	Y	-
18	L	-
19	G	-
20	GR	-
21	R	-
22	V	-
23	LG	- [With 2.0L turbo gasoline engine]
24	V	- [With VR30 engine]
25	L	- [With 2.0L turbo gasoline engine]
25	SB	- [With VR30 engine]
26	G	- [With VR30 engine]
26	W	- [With 2.0L turbo gasoline engine]
27	R	-
29	LG	-
30	SB	- [With VR30 engine]
30	W	- [With 2.0L turbo gasoline engine]
31	SHIELD	-
32	L	-
33	B	- [With VR30 engine]
33	LG	- [With 2.0L turbo gasoline engine]
34	SHIELD	-
35	LG	- [With VR30 engine]
35	W	- [With 2.0L turbo gasoline engine]
36	R	- [With VR30 engine]
36	V	- [With 2.0L turbo gasoline engine]
37	R	- [With VR30 engine]
37	V	- [With 2.0L turbo gasoline engine]
38	W	-
39	P	- [With VR30 engine and without BOSE system]
39	R	- [With 2.0L turbo gasoline engine]
39	V	- [With VR30 engine and with BOSE system]
40	G	-
41	L	-
42	R	-
43	SHIELD	-
44	P	- [With 2.0L turbo gasoline engine]
45	B	- [With VR30 engine]
45	G	- [With VR30 engine]
46	SHIELD	-
47	G	-
48	BG	- [Except with VR30 engine and with BOSE system]
48	BR	- [With VR30 engine and with BOSE system]
49	G	-
50	V	-
51	V	-

JR9JWD4866GB

# POWER SEAT CONTROL SYSTEM


< WIRING DIAGRAM >

## POWER SEAT FOR PASSENGER SIDE

52	L	- [With 2.0L turbo gasoline engine]
52	Y	- [With VR30 engine]
53	R	- [With VR30 engine]
54	GR	- [With VR30 engine]
55	L	- [With 2.0L turbo gasoline engine]
56	P	- [With VR30 engine]
57	R	- [With 2.0L turbo gasoline engine]
58	LG	- [With VR30 engine]
59	SB	- [With VR30 engine]
61	L	- [With 2.0L turbo gasoline engine]
62	P	- [With VR30 engine]
63	V	- [With VR30 engine]
64	W	- [With VR30 engine]
66	R	- [With VR30 engine]
68	L	- [With VR30 engine]
69	P	- [With VR30 engine]
71	GR	- [With 2.0L turbo gasoline engine]
71	R	- [With VR30 engine]
72	G	- [With VR30 engine]
73	V	- [With 2.0L turbo gasoline engine]
73	LG	- [With VR30 engine]
74	L	- [With VR30 engine]
74	LG	- [With 2.0L turbo gasoline engine]
75	P	- [With VR30 engine]
76	V	- [With 2.0L turbo gasoline engine]
77	Y	- [With VR30 engine]
78	L	- [With VR30 engine]
79	G	- [With VR30 engine]
80	GR	- [With 2.0L turbo gasoline engine]
80	W	- [With VR30 engine]
81	B	- [With VR30 engine]
81	R	- [With 2.0L turbo gasoline engine]
82	G	- [With 2.0L turbo gasoline engine]
82	SHIELD	- [With VR30 engine]
83	R	- [With 2.0L turbo gasoline engine]
83	W	- [With VR30 engine]
84	BR	- [With VR30 engine]
84	SHIELD	- [With 2.0L turbo gasoline engine]
85	BR	- [With VR30 engine]
85	G	- [With 2.0L turbo gasoline engine]
86	R	- [With 2.0L turbo gasoline engine]
86	V	- [With VR30 engine]
87	LG	- [With VR30 engine]
87	SHIELD	- [With 2.0L turbo gasoline engine]
89	BR	- [With VR30 engine]
89	LG	- [With 2.0L turbo gasoline engine]
90	SB	- [With 2.0L turbo gasoline engine]

90	V	- [With VR30 engine]
92	L	- [With 2.0L turbo gasoline engine]
92	W	- [With VR30 engine]
93	R	- [With VR30 engine]
93	SHIELD	- [With 2.0L turbo gasoline engine]
94	R	- [With 2.0L turbo gasoline engine]
95	L	- [With 2.0L turbo gasoline engine]
95	Y	- [With VR30 engine]
96	R	- [With 2.0L turbo gasoline engine]
96	W	- [With VR30 engine]
97	L	- [With VR30 engine]
97	R	- [With 2.0L turbo gasoline engine]
98	BR	- [With VR30 engine]
99	P	- [With VR30 engine and with BOSE system]
99	Y	- [With VR30 engine and without BOSE system]
100	BR	- [With VR30 engine]
100	W	- [With 2.0L turbo gasoline engine]

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	RG	- [With VR30 engine]
6	W/B	- [With VR30 engine]
7	V	- [With VR30 engine]
8	RG	- [With VR30 engine]
8	BR	- [With 2.0L turbo gasoline engine]
9	LG	- [With VR30 engine]
9	P	- [With 2.0L turbo gasoline engine]
10	W	- [With VR30 engine]
11	W	- [With VR30 engine]
12	B	- [With VR30 engine]
12	BR	- [With 2.0L turbo gasoline engine]
13	GR	- [With VR30 engine]
13	SHIELD	- [With 2.0L turbo gasoline engine]
14	B	- [With VR30 engine]
15	BG	- [With 2.0L turbo gasoline engine]

64	Y	- [With VR30 engine]
65	R	- [With VR30 engine]
66	P	- [Color of wire differs depending on production]
67	V	- [Color of wire differs depending on production]
67	LG	- [With VR30 engine]
68	RG	- [With VR30 engine]
69	L	- [With VR30 engine]
70	R	- [With VR30 engine]
71	V	- [With 2.0L turbo gasoline engine]
71	W	- [With VR30 engine]
72	L	- [With 2.0L turbo gasoline engine]
72	LG	- [With VR30 engine]
73	R	- [With VR30 engine]
73	W	- [With 2.0L turbo gasoline engine]
74	BR	- [With VR30 engine]
74	L	- [With 2.0L turbo gasoline engine]
75	B	- [With VR30 engine]
75	P	- [With 2.0L turbo gasoline engine and without gateway]
76	R	- [With 2.0L turbo gasoline engine and with gateway]
76	W/B	- [With VR30 engine]
77	SB	- [With VR30 engine]
78	G	- [With VR30 engine]
78	LG	- [With 2.0L turbo gasoline engine]
79	R	- [With VR30 engine]
80	G	- [With VR30 engine]
81	R	- [With VR30 engine]
82	LG	- [With 2.0L turbo gasoline engine]
83	BR	- [With VR30 engine]
83	R	- [With 2.0L turbo gasoline engine]
84	V	- [With VR30 engine]
86	V	- [With VR30 engine]
87	G	- [With VR30 engine]
89	V	- [With VR30 engine]
90	G	- [With VR30 engine]
90	V	- [With 2.0L turbo gasoline engine]
91	W	- [With VR30 engine]
92	G	- [With VR30 engine]
93	BR	- [With VR30 engine]
94	GR	- [With VR30 engine]
94	L	- [With 2.0L turbo gasoline engine]
95	BR	- [With VR30 engine]
95	P	- [With 2.0L turbo gasoline engine and without gateway]
95	R	- [With 2.0L turbo gasoline engine and with gateway]
96	W	- [With VR30 engine]
97	LG	- [With VR30 engine]
98	Y	- [With VR30 engine]
99	BR	- [With VR30 engine]
99	LG	- [With 2.0L turbo gasoline engine]
100	SHIELD	- [With 2.0L turbo gasoline engine]

15	SB	- [With VR30 engine]
16	B	- [With VR30 engine]
16	BR	- [With 2.0L turbo gasoline engine]
17	LG	- [With VR30 engine]
18	B	- [With 2.0L turbo gasoline engine]
18	W/B	- [With VR30 engine]
19	V	- [With VR30 engine]
31	W	- [With VR30 engine]
32	G	- [With 2.0L turbo gasoline engine]
32	V	- [With VR30 engine]
33	L	- [With VR30 engine]
33	P	- [With 2.0L turbo gasoline engine]
34	P	- [With VR30 engine]
35	BG	- [With VR30 engine]
36	G	- [With VR30 engine]
37	B	- [With VR30 engine]
37	L	- [With 2.0L turbo gasoline engine]
38	L	- [With VR30 engine]
38	P	- [With 2.0L turbo gasoline engine and without gateway]
38	R	- [With 2.0L turbo gasoline engine and with gateway]
39	R	- [With 2.0L turbo gasoline engine]
39	Y	- [With VR30 engine]
40	GR	- [With VR30 engine]
41	L	- [With VR30 engine]
44	BR	- [With VR30 engine]
45	L	- [With 2.0L turbo gasoline engine]
46	G	- [With VR30 engine]
46	W	- [With 2.0L turbo gasoline engine]
47	BG	- [With 2.0L turbo gasoline engine]
47	R	- [With VR30 engine]
48	SHIELD	- [With VR30 engine]
49	B	- [With VR30 engine]
49	G	- [With 2.0L turbo gasoline engine]
50	B	- [With 2.0L turbo gasoline engine]
50	BR	- [With VR30 engine]
51	L	- [With VR30 engine]
52	W	- [With VR30 engine]
53	G	- [With VR30 engine]
54	SB	- [With 2.0L turbo gasoline engine]
54	Y	- [With VR30 engine]
55	B	- [With 2.0L turbo gasoline engine]
55	P	- [With VR30 engine]
56	BG	- [With VR30 engine]
56	GR	- [With 2.0L turbo gasoline engine]
57	GR	- [With VR30 engine]
57	P	- [With 2.0L turbo gasoline engine]
58	B	- [With VR30 engine]
59	SB	- [With 2.0L turbo gasoline engine]
61	W/B	- [With VR30 engine]

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# POWER SEAT CONTROL SYSTEM

< WIRING DIAGRAM >

## POWER SEAT FOR PASSENGER SIDE

Connector No.	M133
Connector Name	FUSE BLOCK (J/B)
Connector Type	TH40FW-NH



6C	G	-
7C	G	-
8C	G	-
9C	V	-

Terminal No.	Color Of Wire	Signal Name [Specification]
10C	V	-
12C	L	-
13C	L	-
14C	Y	-
15C	R	-
16C	R	-
17C	L	-
18C	BG	- [Without DRPO]
18C	P	- [With DRPO]
19C	B	-
1C	R	-
20C	W	-
21C	L	-
22C	L	-
23C	L	-
25C	LG	-
26C	SB	-
27C	P	-
28C	W	-
29C	W	-
2C	R	-
30C	R	-
31C	W	-
32C	R	-
32C	B	- [With UR20 engine]
32C	R	- [With 2.0L Turbo gasoline engine]
34C	W/B	-
35C	SB	-
36C	R	-
37C	W	-
38C	SB	-
39C	V	-
3C	P	-
40C	G	-
4C	P	-
5C	P	-

JRJWD4868GB



# LUMBAR SUPPORT SYSTEM


< WIRING DIAGRAM >

## LUMBAR SUPPORT SYSTEM

### Wiring Diagram

INFOID:000000012797200

2L : 2.0L Turbo gasoline engine  
 VR : With VR engine



\*: This connector is not shown in "Harness Layout".

LUMBAR SUPPORT

2015/11/27

JRJWD4249GB

A  
 B  
 C  
 D  
 E  
 F  
 G  
 H  
 I  
**SE**  
 K  
 L  
 M  
 N  
 O  
 P

# LUMBAR SUPPORT SYSTEM

< WIRING DIAGRAM >

## LUMBAR SUPPORT

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



17	1	43	1	17
48	48	48	48	48

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	LG	-
5	P	-
6	V	-
7	P	- [Without Gateway]
17	R	- [With Gateway]
21	BG	-
22	BR	-
23	BG	-
28	R	-
33	L	-
43	B	-
45	G	-
46	BG	-
47	R	-
48	GR	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	TH89FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	LG	-
4	Y	-
5	R	-
6	V	-
7	BR	-
8	LG	-
10	BG	-
11	BG	-
12	LG	-
13	GR	-
14	R	-
15	L	-
16	V	-
18	W	-
19	BR	-
20	W	-
22	R	-
23	V	-
24	R	- [With 2.0L Turbo Gasoline engine]
24	Y	- [With VR30 engine]
25	P	- [With 2.0L Turbo Gasoline engine and without gateway]
25	V	- [With 2.0L Turbo Gasoline engine and with gateway]
25	W	- [With VR30 engine]
26	G	-
27	R	-
28	R	-
31	B	- [With VR30 engine]
31	BR	- [With 2.0L Turbo Gasoline engine]
32	B	-
33	B	-
34	LG	-
35	P	-
36	W	-
37	SB	-
38	LG	-
40	D	-
41	SB	-
42	BR	-
43	BG	-
44	BG	-
46	R	-
50	W	-
51	SB	-
52	V	-
53	LG	-

54	R	-
55	R	-
57	W	-
58	V	-
59	GR	-
60	G	-
61	G	-
62	BG	-
63	BR	-
64	V	-
66	R	-
70	R	-
71	W	-
72	B	-
73	W	-
74	L	-
75	R	- [Without paddle shift]
75	V	- [With paddle shift]
76	BR	-
77	B	-
79	V	-
79	W	- [With VR30 engine]
79	W	- [With 2.0L Turbo Gasoline engine]
81	B	-
82	R	-
83	BG	-
84	L	-
85	R	- [Without paddle shift]
85	V	- [With paddle shift]
86	B	-
86	G	-
89	V	- [With 2.0L Turbo Gasoline engine]
89	W	- [With VR30 engine]
91	GR	-
94	GR	-
96	Y	-
97	V	-
98	BR	- [With VR30 engine and with BOSE system]
98	Y	- [Except with VR30 engine and with BOSE system]

Connector No.	B600
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



17	1	43	1	17
48	48	48	48	48

Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
5	-	-
6	-	-
7	-	-
17	-	-
21	-	-
22	-	-
23	-	-
28	-	-
33	-	-
43	-	-
45	-	-
46	-	-
47	-	-
48	-	-

Connector No.	B608
Connector Name	LUMBAR SUPPORT SWITCH
Connector Type	NS04FW-CS



69	69	43	69
----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
33	R	-
43	B	-
57	G	-

# LUMBAR SUPPORT SYSTEM

< WIRING DIAGRAM >

100	SHIELD	-
-----	--------	---

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name (Specification)
1	Y	-
2	G	-
3	SB	-
4	BR	-
5	Y	-
6	R	-
7	W	-
8	V	-
10	BG	-
11	BR	-
12	LG	-
13	GR	-
14	R	-
15	L	-
16	V	-
18	W	-
19	BR	-
20	W	-
22	SB	-
23	R	-
24	R	[With 2.0L turbo gasoline engine]
25	Y	[With VR30 engine]
25	P	[With 2.0L turbo gasoline engine]
26	G	-
27	R	-
28	R	-
31	BR	-
32	B	-
33	B	-
34	V	-
35	P	-
36	W	-

59	W	-
61	R	-
64	Y	- [Color of wire differs depending on production]
65	BR	- [Color of wire differs depending on production]
65	GR	- [Color of wire differs depending on production]
66	GR	-
67	LG	-
68	BG	-
69	B	-
70	R	- [With 2.0L turbo gasoline engine]
71	G	- [With VR30 engine]
71	LG	- [With VR30 engine]
72	L	- [With 2.0L turbo gasoline engine]
72	V	- [With VR30 engine]
73	G	- [With VR30 engine]
73	W	- [With 2.0L turbo gasoline engine]
74	BR	- [With VR30 engine]
74	L	- [With 2.0L turbo gasoline engine]
75	P	- [With 2.0L turbo gasoline engine and without gateway]
75	R	- [With 2.0L turbo gasoline engine and with gateway]
75	V	- [With VR30 engine]
76	G	-
77	Y	-
78	LG	- [With 2.0L turbo gasoline engine and with ADAS]
78	P	- [With VR30 engine]
78	V	- [With 2.0L turbo gasoline engine and without ADAS]
79	SB	-
80	G	-
81	R	-
82	V	- [With 2.0L turbo gasoline engine]
83	BR	- [With 2.0L turbo gasoline engine]
83	R	- [With VR30 engine]
84	LG	-
86	BG	-
87	G	-
89	LG	-
90	G	- [With VR30 engine]
90	GR	- [With 2.0L turbo gasoline engine]
91	G	-
93	BG	-
94	GR	- [With VR30 engine]
94	L	- [With 2.0L turbo gasoline engine]
95	BG	- [With VR30 engine]
95	P	- [With 2.0L turbo gasoline engine and without gateway]
95	R	- [With 2.0L turbo gasoline engine and with gateway]
96	W	-
97	LG	-
98	L	-
99	LG	- [With 2.0L turbo gasoline engine]
99	P	- [With VR30 engine]

15	GR	- [With 2.0L turbo gasoline engine]
15	SB	- [With VR30 engine]
16	BR	- [With 2.0L turbo gasoline engine]
16	Y	- [With VR30 engine]
17	BR	- [With VR30 engine]
17	GR	- [With 2.0L turbo gasoline engine]
18	G	- [With 2.0L turbo gasoline engine]
18	P	- [With VR30 engine]
19	V	- [With VR30 engine]
31	W	- [With 2.0L turbo gasoline engine]
31	Y	- [With VR30 engine]
32	G	- [With 2.0L turbo gasoline engine]
32	GR	- [With VR30 engine]
33	L	- [With VR30 engine]
33	Y	- [With 2.0L turbo gasoline engine]
34	P	-
35	GR	-
36	R	-
37	L	- [With 2.0L turbo gasoline engine]
37	V	- [With VR30 engine]
38	L	- [With VR30 engine]
38	P	- [With 2.0L turbo gasoline engine and without gateway]
38	R	- [With 2.0L turbo gasoline engine and with gateway]
39	BR	- [With 2.0L turbo gasoline engine]
39	Y	- [With VR30 engine]
40	SB	-
41	LG	-
44	Y	-
45	L	- [With 2.0L turbo gasoline engine]
45	W	- [With VR30 engine]
46	B	- [With VR30 engine]
46	Y	- [With 2.0L turbo gasoline engine]
47	G	-
48	SHIELD	-
49	R	-
50	BR	- [With VR30 engine]
50	GR	- [With 2.0L turbo gasoline engine]
51	L	-
52	W	-
53	V	-
54	P	- [With VR30 engine]
54	W	- [With 2.0L turbo gasoline engine]
55	B	- [With 2.0L turbo gasoline engine]
55	W	- [With VR30 engine]
56	BG	- [With 2.0L turbo gasoline engine]
56	SB	- [With VR30 engine]
57	BG	-
57	W	- [With 2.0L turbo gasoline engine]
58	B	- [Color of wire differs depending on production]
58	B/W	- [Color of wire differs depending on production]

### LUMBAR SUPPORT

58	Y	-
----	---	---


Connector No.	B609
Connector Name	LUMBAR SUPPORT MOTOR
Connector Type	IB02FW-1V



Terminal No.	Color Of Wire	Signal Name (Specification)
57	G	-
58	Y	-

Connector No.	E25
Connector Name	WIRE TO WIRE
Connector Type	TH80PW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name (Specification)
1	BG	-
6	V	-
7	L	-
8	BG	- [With VR30 engine]
8	BR	- [With 2.0L turbo gasoline engine]
9	B	- [With 2.0L turbo gasoline engine]
9	GR	- [With VR30 engine] [Color of wire differs depending on production]
9	LG	- [With VR30 engine] [Color of wire differs depending on production]
10	BR	-
11	L	-
12	GR	- [With VR30 engine]
12	P	- [With 2.0L turbo gasoline engine]
13	SHIELD	- [With 2.0L turbo gasoline engine]
13	W	- [With VR30 engine]
14	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# LUMBAR SUPPORT SYSTEM

< WIRING DIAGRAM >

## LUMBAR SUPPORT

37	SB	-	-
38	LG	-	-
40	P	-	-
41	G	-	-
42	BR	-	-
43	BR	-	-
44	BR	-	-
46	BG	-	-
50	W	-	-
51	Y	-	-
52	V	-	-
53	LG	-	-
54	R	-	-
55	R	-	-
57	W	-	-
58	V	-	-
59	BG	-	-
60	G	-	-
61	G	-	-
62	BG	-	-
63	BR	-	-
64	Y	-	-
66	R	-	-
70	LG	-	-
71	W	-	-
72	B	-	-
73	W	-	-
74	L	-	-
75	W	-	-
76	BR	-	-
77	B	-	-
78	SB	-	-
79	P	- [With VR30 engine]	-
79	W	- [With 2.0L turbo gasoline engine]	-
81	B	-	-
82	R	-	-
83	BG	-	-
84	L	-	-
85	W	-	-
86	B	-	-
88	G	-	-
89	V	- [With 2.0L turbo gasoline engine]	-
91	GR	- [With VR30 engine]	-
94	GR	-	-
96	W	-	-
97	V	-	-
98	BR	- [With VR30 engine and with BOSE system]	-
98	Y	- [Except with VR30 engine and with BOSE system]	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Type	THROMW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
6	W/B	-
7	V	-
8	BG	- [With VR30 engine]
8	BR	- [With 2.0L turbo gasoline engine]
9	LG	- [With VR30 engine]
9	P	- [With 2.0L turbo gasoline engine]
10	W	-
11	W	- [With VR30 engine]
11	Y	- [With 2.0L turbo gasoline engine]
12	B	- [With VR30 engine]
12	BR	- [With 2.0L turbo gasoline engine]
13	GR	- [With VR30 engine]
13	SHIELD	- [With 2.0L turbo gasoline engine]
14	B	-
15	BG	- [With 2.0L turbo gasoline engine]
15	SB	- [With VR30 engine]
16	B	- [With VR30 engine]
17	LG	- [With 2.0L turbo gasoline engine]
18	B	-
18	W/B	- [With VR30 engine]
19	Y	- [With 2.0L turbo gasoline engine]
31	W	-
32	G	- [With 2.0L turbo gasoline engine]
32	V	- [With VR30 engine]
33	L	- [With VR30 engine]
33	Y	- [With 2.0L turbo gasoline engine]
34	P	- [With 2.0L turbo gasoline engine]
35	BG	-
36	G	-
37	B	- [With VR30 engine]
37	L	- [With 2.0L turbo gasoline engine]
38	L	- [With 2.0L turbo gasoline engine and without gateway]
38	P	- [With VR30 engine]
38	R	- [With 2.0L turbo gasoline engine and with gateway]

39	R	- [With 2.0L turbo gasoline engine]
39	Y	- [With VR30 engine]
40	GR	-
41	L	-
44	BR	-
45	L	- [With 2.0L turbo gasoline engine]
45	W	- [With VR30 engine]
46	G	- [With VR30 engine]
46	Y	- [With 2.0L turbo gasoline engine]
47	BG	- [With 2.0L turbo gasoline engine]
47	R	- [With VR30 engine]
48	SHIELD	-
49	B	- [With VR30 engine]
49	G	- [With 2.0L turbo gasoline engine]
50	B	- [With 2.0L turbo gasoline engine]
50	BR	- [With VR30 engine]
51	L	-
52	W	-
53	G	-
54	SB	- [With 2.0L turbo gasoline engine]
54	Y	- [With VR30 engine]
55	B	- [With 2.0L turbo gasoline engine]
55	P	- [With VR30 engine]
56	BG	- [With VR30 engine]
56	GR	- [With 2.0L turbo gasoline engine]
57	GR	- [With VR30 engine]
57	P	- [With 2.0L turbo gasoline engine]
58	B	-
59	SB	-
61	W/B	-
64	Y	-
65	R	-
66	P	- [Color of wire differs depending on production]
66	V	- [Color of wire differs depending on production]
67	LG	-
68	BG	-
69	L	-
70	R	-
71	V	- [With VR30 engine]
71	W	- [With 2.0L turbo gasoline engine]
72	L	- [With 2.0L turbo gasoline engine]
72	LG	- [With VR30 engine]
73	R	- [With VR30 engine]
73	W	- [With 2.0L turbo gasoline engine]
74	BR	- [With VR30 engine]
74	L	- [With 2.0L turbo gasoline engine]
75	B	- [With VR30 engine]
75	P	- [With 2.0L turbo gasoline engine and without gateway]
75	R	- [With 2.0L turbo gasoline engine and with gateway]
76	W/B	-

77	SB	-	-
78	G	-	- [With VR30 engine]
78	LG	-	- [With 2.0L turbo gasoline engine]
79	R	-	-
80	G	-	-
81	R	-	-
82	LG	-	-
83	BR	-	- [With 2.0L turbo gasoline engine]
83	R	-	- [With VR30 engine]
84	V	-	-
86	V	-	-
87	G	-	-
89	V	-	-
90	G	-	- [With VR30 engine]
90	V	-	- [With 2.0L turbo gasoline engine]
91	W	-	-
92	G	-	-
93	BR	-	-
94	GR	-	- [With VR30 engine]
94	L	-	- [With 2.0L turbo gasoline engine]
95	BR	-	- [With VR30 engine]
95	P	-	- [With 2.0L turbo gasoline engine and without gateway]
95	R	-	- [With 2.0L turbo gasoline engine and with gateway]
96	W	-	-
97	LG	-	-
98	Y	-	-
99	BR	-	- [With VR30 engine]
99	LG	-	- [With 2.0L turbo gasoline engine]
100	SHIELD	-	-

Connector No.	M118
Connector Name	CIRCUIT BREAKER
Connector Type	M02FW-1C



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	SB	-

JR/JWD4871GB

# SIDE SUPPORT SYSTEM


< WIRING DIAGRAM >

## SIDE SUPPORT SYSTEM

### Wiring Diagram

INFOID:000000012797201

2L : 2.0L Turbo gasoline engine  
 VR : With VR engine



\*: This connector is not shown in "Harness Layout".

SIDE SUPPORT

2015/11/27

JRJWD4253GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# SIDE SUPPORT SYSTEM

< WIRING DIAGRAM >

## SIDE SUPPORT

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



23	7	13	22	45	6	47	48	46
28	21	15	2	43	1	17		

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	LG	-
5	P	-
6	V	-
7	P	- [Without Gateway]
17	R	- [With Gateway]
21	BG	-
22	BR	-
23	BG	-
28	R	-
33	L	-
43	B	-
45	G	-
46	BG	-
47	R	-
48	GR	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	TH89FW-CS16-1M4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	LG	-
4	Y	-
5	R	-
6	V	-
7	BR	-
8	LG	-
10	BG	-
11	BG	-
12	LG	-
13	GR	-
14	R	-
15	L	-
16	V	-
18	W	-
19	BR	-
20	W	-
22	R	-
23	V	-
24	R	- [With 2.0L Turbo gasoline engine]
24	Y	- [With VR30 engine]
25	P	- [With 2.0L Turbo gasoline engine and without gateway]
25	V	- [With 2.0L Turbo gasoline engine and with gateway]
25	W	- [With VR30 engine]
26	G	-
27	R	-
28	R	-
31	BR	- [With VR30 engine]
31	BR	- [With 2.0L Turbo gasoline engine]
32	B	-
33	B	-
34	LG	-
35	P	-
36	W	-
37	SB	-
38	LG	-
40	D	-
41	SB	-
42	BR	-
43	BG	-
44	BG	-
46	R	-
50	W	-
51	SB	-
52	V	-
53	LG	-

54	R	-
55	R	-
57	W	-
58	V	-
59	GR	-
60	G	-
61	G	-
62	BG	-
63	BR	-
64	V	-
66	R	-
70	R	-
71	W	-
72	B	-
73	W	-
74	L	-
75	R	- [Without paddle shift]
75	V	- [With paddle shift]
76	BR	-
77	B	-
78	S9	-
79	V	- [With VR30 engine]
79	W	- [With 2.0L Turbo gasoline engine]
81	B	-
82	R	-
83	BG	-
84	L	-
85	R	- [Without paddle shift]
85	V	- [With paddle shift]
86	B	-
86	G	-
89	V	- [With 2.0L Turbo gasoline engine]
89	W	- [With VR30 engine]
91	GR	-
94	GR	-
96	Y	-
97	V	-
98	BR	- [With VR30 engine and with BOSE system]
98	Y	- [Except with VR30 engine and with BOSE system]

Connector No.	B600
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



17	1	43	2	15	21	28		
46	48	47	6	45	22	33	7	23

Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
5	-	-
6	-	-
7	-	-
17	-	-
21	-	-
22	-	-
23	-	-
28	-	-
33	-	-
43	-	-
45	-	-
46	-	-
47	-	-
48	-	-

Connector No.	B610
Connector Name	BACK SIDE SUPPORT ASSEMBLY
Connector Type	NS06FW-CS



65	64
83	43

Terminal No.	Color Of Wire	Signal Name [Specification]
33	-	-
43	-	-
54	-	-



# SIDE SUPPORT SYSTEM

< WIRING DIAGRAM >

## SIDE SUPPORT

36	W	-	-	-	-
37	SB	-	-	-	-
38	LG	-	-	-	-
40	P	-	-	-	-
41	G	-	-	-	-
42	BR	-	-	-	-
43	RR	-	-	-	-
44	RR	-	-	-	-
46	BG	-	-	-	-
50	W	-	-	-	-
51	Y	-	-	-	-
52	V	-	-	-	-
53	LG	-	-	-	-
54	R	-	-	-	-
55	R	-	-	-	-
57	W	-	-	-	-
58	V	-	-	-	-
59	BG	-	-	-	-
60	G	-	-	-	-
61	G	-	-	-	-
62	BG	-	-	-	-
63	BR	-	-	-	-
64	Y	-	-	-	-
66	R	-	-	-	-
70	LG	-	-	-	-
71	W	-	-	-	-
72	B	-	-	-	-
73	W	-	-	-	-
74	L	-	-	-	-
75	W	-	-	-	-
76	BR	-	-	-	-
77	B	-	-	-	-
78	SB	-	-	-	-
79	P	-	-	-	- [With VR30 engine]
79	W	-	-	-	- [With 2.0L turbo gasoline engine]
81	B	-	-	-	-
82	R	-	-	-	-
83	BG	-	-	-	-
84	L	-	-	-	-
85	W	-	-	-	-
86	B	-	-	-	-
88	G	-	-	-	-
89	V	-	-	-	- [With 2.0L turbo gasoline engine]
91	GR	-	-	-	- [With VR30 engine]
94	GR	-	-	-	-
96	W	-	-	-	-
97	V	-	-	-	-
98	BR	-	-	-	- [With VR30 engine and with BOSE system]
98	Y	-	-	-	- [Except with VR30 engine and with BOSE system]

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Type	THROMW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BG	-
6	W/B	-
7	V	-
8	BG	- [With VR30 engine]
8	BR	- [With 2.0L turbo gasoline engine]
9	LG	- [With VR30 engine]
9	P	- [With 2.0L turbo gasoline engine]
10	W	-
11	W	- [With VR30 engine]
11	Y	- [With 2.0L turbo gasoline engine]
12	B	- [With VR30 engine]
12	BR	- [With 2.0L turbo gasoline engine]
13	GR	- [With VR30 engine]
13	SHIELD	- [With 2.0L turbo gasoline engine]
14	B	-
15	BG	- [With 2.0L turbo gasoline engine]
15	SB	- [With VR30 engine]
16	B	- [With VR30 engine]
16	BR	- [With 2.0L turbo gasoline engine]
17	LG	-
18	B	- [With VR30 engine]
18	W/B	- [With 2.0L turbo gasoline engine]
19	Y	-
31	W	-
32	G	- [With 2.0L turbo gasoline engine]
32	V	- [With VR30 engine]
33	L	- [With VR30 engine]
33	Y	- [With 2.0L turbo gasoline engine]
34	P	-
35	BG	-
36	G	-
37	B	- [With VR30 engine]
38	L	- [With 2.0L turbo gasoline engine]
38	P	- [With 2.0L turbo gasoline engine and without gateway]
38	R	- [With 2.0L turbo gasoline engine and with gateway]

39	R	-	- [With 2.0L turbo gasoline engine]
39	Y	-	- [With VR30 engine]
40	GR	-	-
41	L	-	-
44	BR	-	- [With 2.0L turbo gasoline engine]
45	L	-	- [With VR30 engine]
45	W	-	- [With 2.0L turbo gasoline engine]
46	G	-	- [With VR30 engine]
46	Y	-	- [With 2.0L turbo gasoline engine]
47	BG	-	- [With 2.0L turbo gasoline engine]
47	R	-	- [With VR30 engine]
48	SHIELD	-	-
49	B	-	- [With VR30 engine]
49	G	-	- [With 2.0L turbo gasoline engine]
50	B	-	- [With 2.0L turbo gasoline engine]
50	BR	-	- [With VR30 engine]
51	L	-	-
52	W	-	-
53	G	-	-
54	SB	-	- [With 2.0L turbo gasoline engine]
54	Y	-	- [With VR30 engine]
55	B	-	- [With 2.0L turbo gasoline engine]
55	P	-	- [With VR30 engine]
56	BG	-	- [With VR30 engine]
56	GR	-	- [With 2.0L turbo gasoline engine]
57	GR	-	- [With VR30 engine]
57	P	-	- [With 2.0L turbo gasoline engine]
58	B	-	-
59	SB	-	-
61	W/B	-	-
64	Y	-	-
65	R	-	- [Color of wire differs depending on production]
66	P	-	- [Color of wire differs depending on production]
66	V	-	-
67	LG	-	-
68	BG	-	-
69	L	-	-
70	R	-	-
71	V	-	- [With VR30 engine]
71	W	-	- [With 2.0L turbo gasoline engine]
72	L	-	- [With 2.0L turbo gasoline engine]
72	LG	-	- [With VR30 engine]
73	R	-	- [With VR30 engine]
73	W	-	- [With 2.0L turbo gasoline engine]
74	BR	-	- [With VR30 engine]
74	L	-	- [With 2.0L turbo gasoline engine]
75	B	-	- [With VR30 engine]
75	P	-	- [With 2.0L turbo gasoline engine and without gateway]
75	R	-	- [With 2.0L turbo gasoline engine and with gateway]
76	W/B	-	-

77	SB	-	-
78	G	-	- [With VR30 engine]
78	LG	-	- [With 2.0L turbo gasoline engine]
79	R	-	-
80	G	-	-
81	R	-	-
82	LG	-	-
83	BR	-	- [With 2.0L turbo gasoline engine]
83	R	-	- [With VR30 engine]
84	V	-	-
86	V	-	-
87	G	-	-
89	V	-	-
90	G	-	- [With VR30 engine]
90	V	-	- [With 2.0L turbo gasoline engine]
91	W	-	-
92	G	-	-
93	BR	-	-
94	GR	-	- [With VR30 engine]
94	L	-	- [With 2.0L turbo gasoline engine]
95	BR	-	- [With VR30 engine]
95	P	-	- [With 2.0L turbo gasoline engine and without gateway]
95	R	-	- [With 2.0L turbo gasoline engine and with gateway]
96	R	-	-
96	W	-	-
97	LG	-	-
98	Y	-	-
99	BR	-	- [With VR30 engine]
99	LG	-	- [With 2.0L turbo gasoline engine]
100	SHIELD	-	-

Connector No.	M118
Connector Name	CIRCUIT BREAKER
Connector Type	MQ2FW-1C



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	SB	-

JR1JWD4874GB





# TILT & TELESCOPIC SYSTEM

< WIRING DIAGRAM >

## TILT AND TELESCOPIC SYSTEM

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



17	1	43	1	17
18	2	44	2	18
19	3	45	3	19
20	4	46	4	20
21	5	47	5	21
22	6	48	6	22

Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	LG	-
5	P	-
6	V	-
7	P	-
17	P	- [Without Gateway]
17	R	- [With Gateway]
21	BG	-
22	BR	-
23	BG	-
28	R	-
33	L	-
43	B	-
45	G	-
46	BG	-
47	R	-
48	GR	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	TH89FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	LG	-
4	Y	-
5	R	-
6	V	-
7	BR	-
8	LG	-
10	BG	-
11	BG	-
12	LG	-
13	GR	-
14	R	-
15	L	-
16	V	-
18	W	-
19	BR	-
20	W	-
22	R	-
23	V	-
24	Y	- [With 2.0L Turbo gasoline engine]
24	Y	- [With VR30 engine]
25	P	- [With 2.0L Turbo gasoline engine and without gateway]
25	V	- [With 2.0L Turbo gasoline engine and with gateway]
25	W	- [With VR30 engine]
26	G	-
27	R	-
28	R	-
31	BR	- [With VR30 engine]
31	BR	- [With 2.0L Turbo gasoline engine]
32	B	-
33	B	-
34	LG	-
35	P	-
36	W	-
37	SB	-
38	LG	-
40	D	-
41	SB	-
42	BR	-
43	BG	-
44	BG	-
46	R	-
50	W	-
51	SB	-
52	V	-
53	LG	-

54	R	-
55	R	-
57	W	-
58	V	-
59	GR	-
60	G	-
61	G	-
62	BG	-
63	BR	-
64	V	-
66	R	-
70	R	-
71	W	-
72	B	-
73	W	-
74	L	-
75	R	- [Without paddle shift]
75	V	- [With paddle shift]
76	BR	-
77	B	-
78	S9	-
79	V	- [With VR30 engine]
79	W	- [With 2.0L Turbo gasoline engine]
81	B	-
82	R	-
83	BG	-
84	L	-
85	R	- [Without paddle shift]
85	V	- [With paddle shift]
86	B	-
86	G	-
89	V	- [With 2.0L Turbo gasoline engine]
89	W	- [With VR30 engine]
91	GR	-
94	GR	-
96	Y	-
97	V	-
98	BR	- [With VR30 engine and with BOSE system]
98	Y	- [Except with VR30 engine and with BOSE system]

Connector No.	B600
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



17	1	43	1	17
18	2	44	2	18
19	3	45	3	19
20	4	46	4	20
21	5	47	5	21
22	6	48	6	22

Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
5	-	-
6	-	-
7	-	-
17	-	-
21	-	-
22	-	-
23	-	-
28	-	-
33	-	-
43	-	-
45	-	-
46	-	-
47	-	-
48	-	-

Connector No.	B601
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	TH32FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
2	BR	UART (TX/RX)
3	R	START SW

# TILT & TELESCOPIC SYSTEM

< WIRING DIAGRAM >

## TILT AND TELESCOPIC SYSTEM

4	P	PULSE (RECLINER)
5	V	PULSE (TELESCOPIC)
6	GY	ADDRESS 2
7	G	IND 2
8	V	SLIDE SW (BACKWARD)
9	W	RECLINER SW (BACKWARD)
10	O	TILT SW (DOWNWARD)
11	G	LIFTER SW (DOWNWARD)
12	SB	POWER SUPPLY (ENCODER)
17	P	CABL
18	LG	PULSE (SLIDE SENSOR)
19	W	PULSE (LIFTER - FRONT)
20	GY	PULSE (LIFTER - REAR)
21	SB	ADDRESS 1
22	O	IND 1
23	W	SLIDE SW (FORWARD)
24	P	RECLINER SW (FORWARD)
25	Y	TILT SW (UPWARD)
26	GY	LIFTER SW (UPWARD)
27	L	SET SW
28	Y	

Connector No.	B602
Connector Name	DRIVER SEAT CONTROL UNIT
Connector Type	NS12FW-CS



33	34	35	36
38	39	40	41
42	43		

Terminal No.	Color Of Wire	Signal Name (Specification)
32	R	BAT (PTC)
33	V	SLIDE MOTOR (BACKWARD)
34	Y	RECLINER MOTOR (FORWARD)
35	O	TILT MOTOR (DOWNWARD)
36	P	SLIDE MOTOR (FORWARD)
38	W	RECLINER MOTOR (BACKWARD)
39	GY	TILT MOTOR (UPWARD)
40	L	REAR LIFTER MOTOR (UPWARD)
41	L	REAR LIFTER MOTOR (DOWNWARD)
42	G	GND
43	B	

Connector No.	E25
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



33	34	35	36
38	39	40	41
42	43		

Terminal No.	Color Of Wire	Signal Name (Specification)
1	BG	
6	V	
7	L	
8	BG	- [With VR30 engine]
8	BR	- [With 2.0L turbo gasoline engine]
9	B	- [With 2.0L turbo gasoline engine]
9	GR	- [With VR30 engine] (Color of wire differs depending on production)
9	LG	- [With VR30 engine] (Color of wire differs depending on production)
10	BR	
11	L	
12	GR	- [With VR30 engine]
12	P	- [With 2.0L turbo gasoline engine]
13	SHIELD	- [With 2.0L turbo gasoline engine]
13	W	- [With VR30 engine]
14	B	
15	GR	- [With 2.0L turbo gasoline engine]
16	SB	- [With VR30 engine]
16	BR	- [With 2.0L turbo gasoline engine]
16	Y	- [With VR30 engine]
17	BR	- [With 2.0L turbo gasoline engine]
18	G	- [With 2.0L turbo gasoline engine]
18	P	- [With VR30 engine]
19	V	
31	W	- [With 2.0L turbo gasoline engine]
31	Y	- [With VR30 engine]
32	G	- [With 2.0L turbo gasoline engine]
32	GR	- [With VR30 engine]
33	L	- [With VR30 engine]
33	Y	- [With 2.0L turbo gasoline engine]
34	P	
35	GR	
36	R	
37	L	- [With 2.0L turbo gasoline engine]
37	V	- [With VR30 engine]
38	L	- [With VR30 engine]

38	R	P	- [With 2.0L turbo gasoline engine and without gateway]
38	BR	BR	- [With 2.0L turbo gasoline engine and with gateway]
39	Y	Y	- [With VR30 engine]
40	SB	SB	- [With VR30 engine]
41	LG	LG	
44	V	V	
45	L	L	- [With 2.0L turbo gasoline engine]
45	W	W	- [With VR30 engine]
46	B	B	- [With VR30 engine]
46	Y	Y	- [With 2.0L turbo gasoline engine]
47	G	G	
48	SHIELD	SHIELD	
49	R	R	
50	BR	BR	- [With VR30 engine]
50	GR	GR	- [With 2.0L turbo gasoline engine]
51	L	L	
52	W	W	
53	V	V	
54	P	P	- [With VR30 engine]
54	W	W	- [With 2.0L turbo gasoline engine]
55	B	B	- [With 2.0L turbo gasoline engine]
55	W	W	- [With VR30 engine]
56	BG	BG	- [With 2.0L turbo gasoline engine]
56	SB	SB	- [With VR30 engine]
57	BG	BG	- [With VR30 engine]
57	W	W	- [With 2.0L turbo gasoline engine]
58	B	B	- [Color of wire differs depending on production]
58	B/W	B/W	- [Color of wire differs depending on production]
59	W	W	
61	R	R	
64	Y	Y	
65	BR	BR	- [Color of wire differs depending on production]
65	GR	GR	- [Color of wire differs depending on production]
66	GR	GR	
67	LG	LG	
68	BG	BG	
69	L	L	
70	R	R	
71	G	G	- [With 2.0L turbo gasoline engine]
71	LG	LG	- [With VR30 engine]
72	L	L	- [With 2.0L turbo gasoline engine]
72	V	V	- [With VR30 engine]
73	G	G	- [With VR30 engine]
73	W	W	- [With 2.0L turbo gasoline engine]
74	BR	BR	- [With VR30 engine]
74	L	L	- [With 2.0L turbo gasoline engine]
75	P	P	- [With 2.0L turbo gasoline engine and without gateway]
75	R	R	- [With 2.0L turbo gasoline engine and with gateway]
75	V	V	- [With VR30 engine]

76	G	G	
77	Y	Y	
78	LG	LG	- [With 2.0L turbo gasoline engine and with ADAS]
78	P	P	- [With VR30 engine]
78	V	V	- [With 2.0L turbo gasoline engine and without ADAS]
79	SB	SB	
80	LG	LG	
81	R	R	
82	V	V	
83	BR	BR	- [With 2.0L turbo gasoline engine]
83	R	R	- [With VR30 engine]
84	LG	LG	
86	BG	BG	
87	G	G	
89	LG	LG	
90	G	G	- [With VR30 engine]
90	GR	GR	- [With 2.0L turbo gasoline engine]
91	G	G	
93	BG	BG	
94	GR	GR	- [With VR30 engine]
94	L	L	- [With 2.0L turbo gasoline engine]
95	BG	BG	- [With VR30 engine]
95	P	P	- [With 2.0L turbo gasoline engine and without gateway]
95	R	R	- [With 2.0L turbo gasoline engine and with gateway]
96	W	W	
97	LG	LG	
98	L	L	
99	LG	LG	- [With 2.0L turbo gasoline engine]
99	P	P	- [With VR30 engine]
100	SHIELD	SHIELD	

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



33	34	35	36
38	39	40	41
42	43		

Terminal No.	Color Of Wire	Signal Name (Specification)
1	Y	
2	G	
3	SB	
4	BR	

JR3WD4877GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P



# TILT & TELESCOPIC SYSTEM

< WIRING DIAGRAM >

## TILT AND TELESCOPIC SYSTEM

74	BR	- [With VR30 engine]
74	L	- [With 2.0L turbo gasoline engine]
75	B	- [With VR30 engine]
75	P	- [With 2.0L turbo gasoline engine and without gateway]
75	R	- [With 2.0L turbo gasoline engine and with gateway]
76	W/B	-
77	SB	-
78	G	- [With VR30 engine]
78	LG	- [With 2.0L turbo gasoline engine]
79	R	-
80	G	-
81	R	-
82	LG	-
83	BR	- [With 2.0L turbo gasoline engine]
83	R	- [With VR30 engine]
84	V	-
86	V	-
87	G	-
89	V	-
90	G	- [With VR30 engine]
90	V	- [With 2.0L turbo gasoline engine]
91	W	-
92	G	-
93	BR	-
94	GR	- [With VR30 engine]
94	L	- [With 2.0L turbo gasoline engine]
95	BR	- [With VR30 engine]
95	P	- [With 2.0L turbo gasoline engine and without gateway]
95	R	- [With 2.0L turbo gasoline engine and with gateway]
96	W	-
97	LG	-
98	Y	-
99	BR	- [With VR30 engine]
99	LG	- [With 2.0L turbo gasoline engine]
100	SHIELD	-

Connector No.	M43
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	TH24FW-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	UPWARD
2	LG	MIRROR_SELECT_SW_RH
3	G	UPWARD
4	Y	LEFTWARD
5	R	MIRROR_SENSOR
6	GR	MIRROR_SENSOR
7	GR	FRONTWARD
8	V	RX/TX
10	W/B	MIRROR_MOTOR
11	BR	MIRROR_MOTOR
12	Y	MIRROR_MOTOR
13	LG	DOWNWARD
14	W	MIRROR_SELECT_SW_LH
15	SB	DOWNWARD
16	L	RIGHTWARD
17	L	MIRROR_SENSOR
18	B	MIRROR_SENSOR
19	G	BACKWARD
20	Y	SENS_GND
21	W	POWER_SUPPLY
22	SB	MIRROR_MOTOR
23	P	MIRROR_MOTOR
24	W/B	MIRROR_MOTOR

Connector No.	M44
Connector Name	AUTOMATIC DRIVE POSITIONER CONTROL UNIT
Connector Type	NSR6FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
25	SB	BAT
26	G	BACKWARD
27	W	POWER_SUPPLYSENSOR_for_16V
28	BR	DOWNWARD
29	L	UPWARD/FORWARD
30	B	GND(POWER SYSTEM)

Connector No.	M118
Connector Name	CIRCUIT BREAKER
Connector Type	MD2FW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	SB	-

Connector No.	M123
Connector Name	TILT & TELESCOPIC SWITCH
Connector Type	TK06FY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GND
2	GR	TELESCOPIC FR
3	G	TELESCOPIC RR
4	Y	TILT UP
5	LG	TILT_DOWN

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# HEATED SEAT SYSTEM


< WIRING DIAGRAM >

## HEATED SEAT SYSTEM

### Wiring Diagram

INFOID:000000012797203

### HEATED SEAT SYSTEM



- \*1 : 5 : <VR> \*3 : <VR> \*5 : <VR>
- 8 : <2L> 10 : <2L> 11 : <2L>
- \*2 : 84 : <VR> \*4 : <VR> \*6 : <VR>
- 60 : <2L> 91 : <VR> 93 : <2L>
- <TA> : With 2.0L turbo gasoline engine with automatic drive positioner
- <XT> : Except for 2.0L turbo gasoline engine with automatic drive positioner
- <GD> : Without CAN gateway for 2.0L turbo gasoline engine
- <2L> : 2.0L turbo gasoline engine
- <VR> : With VR engine

\* : This connector is not shown in "Harness Layout".

# HEATED SEAT SYSTEM

< WIRING DIAGRAM >

## HEATED SEAT SYSTEM

Connector No.	B12
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



28	21	15	12	43	1	17
23	7	33	22	45	6	47
						48

Terminal No.	Color Of Wire	Signal Name (Specification)
1	L	-
2	LG	-
5	P	-
6	V	-
7	P	- [Without Gateway]
17	R	- [With Gateway]
21	BG	-
22	BR	-
23	BG	-
28	R	-
33	L	-
43	B	-
45	G	-
46	BG	-
47	R	-
48	GR	-

Connector No.	B18
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name (Specification)
1	Y	-
2	G	-
3	L	-
4	LG	-
5	Y	-
6	R	-
7	V	-
8	LG	-
10	BG	-
11	BG	-
12	LG	-
13	GR	-
14	R	-
15	L	-
16	V	-
18	W	-
19	BR	-
20	W	-
22	R	-
23	V	-
24	R	- [With 2.0L turbo gasoline engine]
24	Y	- [With VR30 engine]
25	P	- [With 2.0L turbo gasoline engine and without gateway]
25	V	- [With 2.0L turbo gasoline engine and with gateway]
25	W	- [With VR30 engine]
26	G	-
27	R	-
28	R	-
31	BR	- [With VR30 engine]
32	B	- [With 2.0L turbo gasoline engine]
33	B	-
34	LG	-
35	P	-
36	W	-
37	SB	-
38	LG	-
40	P	-
41	SB	-
42	BR	-
43	BG	-
44	BG	-
46	R	-
50	W	-
51	SB	-
52	V	-
53	LG	-

54	R	-
55	R	-
57	W	-
58	V	-
59	GR	-
60	G	-
61	G	-
62	BG	-
63	BR	-
64	V	-
66	R	-
70	R	-
71	W	-
72	B	-
73	W	-
74	L	-
75	R	- [Without paddle shift]
75	V	- [With paddle shift]
76	BR	-
77	B	-
78	SB	-
79	V	- [With VR30 engine]
79	W	- [With 2.0L turbo gasoline engine]
81	B	-
82	R	-
83	BG	-
84	L	-
85	R	- [Without paddle shift]
85	V	- [With paddle shift]
86	B	-
88	G	-
89	V	- [With 2.0L turbo gasoline engine]
89	W	- [With VR30 engine]
91	GR	-
94	GR	-
96	V	-
97	V	-
98	BR	- [With VR30 engine and with BOSE system]
98	Y	- [Except with VR30 engine and with BOSE system]

Connector No.	B58
Connector Name	WIRE TO WIRE
Connector Type	NS16FW-CS



33	47	43
48	48	45

Terminal No.	Color Of Wire	Signal Name (Specification)
33	R	-
43	B	-
45	G	-
46	R	-
47	BR	-
48	V	-

Connector No.	B62
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name (Specification)
1	BR	- [With 2.0L turbo gasoline engine and without BOSE system]
1	LG	- [With VR30 engine]
1	V	- [With 2.0L turbo gasoline engine and with BOSE system]
2	L	- [With VR30 engine]
2	SHIELD	- [With 2.0L turbo gasoline engine]
3	BR	- [With VR30 engine and with BOSE system]
3	R	- [With 2.0L turbo gasoline engine]
3	W	- [With VR30 engine and without BOSE system]
4	SHIELD	- [With VR30 engine]
4	Y	- [With 2.0L turbo gasoline engine]
5	G	- [With VR30 engine]
5	V	- [With 2.0L turbo gasoline engine]
6	BG	- [With VR30 engine]

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# HEATED SEAT SYSTEM

< WIRING DIAGRAM >

## HEATED SEAT SYSTEM

6	BR	- [With 2.0L turbo gasoline engine]
7	B	- [With 2.0L turbo gasoline engine and with BOSE system]
7	BR	- [With VR30 engine and without BOSE system]
7	W	- [With VR30 engine and with BOSE system]
7	Y	- [With 2.0L turbo gasoline engine and without BOSE system]
8	B	- [With VR30 engine and with BOSE system]
8	G	- [With 2.0L turbo gasoline engine]
8	Y	- [With VR30 engine and without BOSE system]
9	LG	- [With 2.0L turbo gasoline engine]
9	SHIELD	- [With VR30 engine]
10	V	-
11	GR	-
12	Y	-
13	R	-
14	BG	-
15	BG	- [With 2.0L turbo gasoline engine]
15	GR	- [With VR30 engine]
16	V	-
17	P	-
18	L	-
19	R	-
20	GR	-
21	R	-
22	V	-
23	W	-
24	BG	- [With 2.0L turbo gasoline engine]
24	V	- [With VR30 engine]
25	L	- [With 2.0L turbo gasoline engine]
25	SB	- [With VR30 engine]
26	G	- [With VR30 engine]
26	W	- [With 2.0L turbo gasoline engine]
27	R	-
29	LG	-
30	LG	- [With 2.0L turbo gasoline engine]
30	P	- [With VR30 engine]
31	SHIELD	-
32	L	-
33	B	- [With VR30 engine]
33	LG	- [With 2.0L turbo gasoline engine]
34	SHIELD	-
35	LG	- [With VR30 engine]
35	W	- [With 2.0L turbo gasoline engine]
36	R	- [With VR30 engine]
36	W	- [With 2.0L turbo gasoline engine]
37	P	- [With 2.0L turbo gasoline engine and without BOSE system]
37	R	- [With VR30 engine]
37	W	- [With 2.0L turbo gasoline engine and with BOSE system]
38	W	-
39	P	- [With VR30 engine and without BOSE system]
39	R	- [With 2.0L turbo gasoline engine]

39	W	- [With VR30 engine and with BOSE system]
40	G	-
41	L	-
42	R	-
43	SHIELD	-
44	P	-
45	B	- [With 2.0L turbo gasoline engine]
45	G	- [With VR30 engine]
46	SHIELD	-
47	G	-
48	BG	-
49	G	-
50	V	-
51	GR	-
52	W	- [With 2.0L turbo gasoline engine]
53	R	- [With VR30 engine]
54	GR	-
55	L	-
56	V	-
57	R	-
58	LG	-
59	P	-
61	L	-
62	P	- [With VR30 engine]
62	V	- [With 2.0L turbo gasoline engine]
63	L	-
64	W	-
66	LG	-
68	L	-
69	P	- [With 2.0L turbo gasoline engine]
71	GR	- [With VR30 engine]
72	R	- [With VR30 engine]
72	G	- [With 2.0L turbo gasoline engine]
73	R	- [With 2.0L turbo gasoline engine]
73	SHIELD	-
74	BG	- [With VR30 engine]
74	L	- [With 2.0L turbo gasoline engine]
75	GR	- [With 2.0L turbo gasoline engine]
75	V	- [With VR30 engine]
76	GR	- [With VR30 engine]
76	V	- [With 2.0L turbo gasoline engine]
77	P	- [With 2.0L turbo gasoline engine]
78	L	-
79	R	-
80	GR	- [With 2.0L turbo gasoline engine]
80	W	- [With VR30 engine]
81	B	- [With VR30 engine]
81	R	- [With 2.0L turbo gasoline engine]

82	G	- [With 2.0L turbo gasoline engine]
83	SHIELD	- [With VR30 engine]
83	R	- [With 2.0L turbo gasoline engine]
83	W	- [With VR30 engine]
84	BR	- [With VR30 engine]
84	SHIELD	- [With 2.0L turbo gasoline engine]
85	BG	- [With VR30 engine]
85	G	- [With 2.0L turbo gasoline engine]
86	R	- [With 2.0L turbo gasoline engine]
86	W	- [With VR30 engine]
87	LG	- [With VR30 engine]
87	SHIELD	- [With 2.0L turbo gasoline engine]
89	LG	-
90	P	- [With 2.0L turbo gasoline engine]
90	V	- [With VR30 engine]
92	L	- [With 2.0L turbo gasoline engine]
92	W	- [With VR30 engine]
93	R	- [With VR30 engine]
93	SHIELD	- [With 2.0L turbo gasoline engine]
94	R	-
95	L	- [With 2.0L turbo gasoline engine]
95	Y	- [With VR30 engine]
96	R	- [With 2.0L turbo gasoline engine]
96	W	- [With VR30 engine]
97	L	- [With VR30 engine]
97	R	- [With 2.0L turbo gasoline engine and with BOSE system]
97	W	- [With 2.0L turbo gasoline engine and without BOSE system]
98	LG	-
99	BR	- [With VR30 engine and with BOSE system]
99	P	- [With 2.0L turbo gasoline engine]
99	Y	- [With VR30 engine and without BOSE system]
100	BR	- [With VR30 engine]
100	W	- [With 2.0L turbo gasoline engine]

Connector No.	B600
Connector Name	WIRE TO WIRE
Connector Type	NS16AM/CS



17	1	43	2	15	21	28		
46	48	47	6	45	22	33	7	23

Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-
5	-	-
6	-	-
7	-	-
17	-	-
21	-	-
32	-	-
38	-	-
33	-	-
43	-	-
45	-	-
46	-	-
47	-	-
48	-	-

Connector No.	B612
Connector Name	SEAT CUSHION HEATER
Connector Type	NS04MM/CS



45	46	47	48
----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
45	B	-
46	BR	-
47	W	-
48	P	-

JR1JWD4882GB





# HEATED SEAT SYSTEM

< WIRING DIAGRAM >

## HEATED SEAT SYSTEM

Connector No.	B613
Connector Name	WIRE TO WIRE
Connector Type	MS16MW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
33	-	-
43	-	-
45	-	-
46	-	-
47	-	-
48	-	-

Connector No.	B619
Connector Name	SEAT CUSHION HEATER
Connector Type	NS04MW-CS






Terminal No.	Color Of Wire	Signal Name [Specification]
45	B	-
46	BR	-
47	W	-
48	P	-

Connector No.	B630
Connector Name	WIRE TO WIRE
Connector Type	MD2FW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B631
Connector Name	WIRE TO WIRE
Connector Type	MD2MW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B632
Connector Name	WIRE TO WIRE
Connector Type	MD2FW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	B633
Connector Name	WIRE TO WIRE
Connector Type	MD2MW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	-
2	-	-

Connector No.	M1
Connector Name	INTEGRAL SWITCH
Connector Type	TH24FW-NH

Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	ILLUMINATION SIGNAL
3	LG	AV COMM [L]
4	SB	AV COMM [H]
7	W/B	DISK EJECT SIGNAL
8	G	HAZARD SIGNAL
13	B	IGN
14	SB	ACC. [for 2.0L turbo gasoline engine]
14	V	ACC. [for VRS0 engine]
15	B	ILLUMINATION CONTROL SIGNAL
16	BG	DISK EJECT SIGNAL GROUND
18	R	IGN [for VRS0 engine]
18	W	IGN [for 2.0L turbo gasoline engine]
19	BR	CAMERA SWITCH SIGNAL
20	LG	AIR BAG INDICATOR OFF SIGNAL

Connector No.	M19
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-IM4

Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	SB	-
4	BR	-
5	Y	-
6	R	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

JRJWD4883GB



# HEATED SEAT SYSTEM

< WIRING DIAGRAM >

## HEATED SEAT SYSTEM

Terminal No.	Color Of Wire	Signal Name [Specification]
82	SHIELD	- [With VR30 engine]
83	R	- [With 2.0L turbo gasoline engine]
84	W	- [With VR30 engine]
85	BR	- [With VR30 engine]
86	SHIELD	- [With 2.0L turbo gasoline engine]
87	BR	- [With VR30 engine]
88	G	- [With VR30 engine]
89	R	- [With 2.0L turbo gasoline engine]
90	V	- [With VR30 engine]
91	L	- [With 2.0L turbo gasoline engine]
92	W	- [With VR30 engine]
93	SHIELD	- [With 2.0L turbo gasoline engine]
94	R	- [With 2.0L turbo gasoline engine]
95	L	- [With 2.0L turbo gasoline engine]
96	R	- [With VR30 engine]
97	W	- [With VR30 engine]
98	BR	- [With VR30 engine]
99	BR	- [With VR30 engine and with BOSE system]
99	P	- [With 2.0L turbo gasoline engine]
99	Y	- [With VR30 engine and without BOSE system]
100	BR	- [With VR30 engine]
100	W	- [With 2.0L turbo gasoline engine]

Connector No.	Connector Name	Connector Type
M46	HEATED SEAT RELAY	MS02FL-M2 LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	- [With VR30 engine and without BS5]
2	R	- [Except with VR30 engine and without BS5]
3	W	- [With VR30 engine and without BS5]
4	G	- [With VR30 engine]
5	LG	- [With VR30 engine]

Connector No.	Connector Name	Connector Type
M88	A/C AUTO AMP.	TH40FV-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	CAN-H
2	B	GROUND
3	W	BATTERY POWER SUPPLY
7	G	AMBIENT SENSOR SIGNAL
9	R	SUNLOAD SENSOR SIGNAL
13	SB	ACC POWER SUPPLY [With 2.0L turbo gasoline engine]
13	V	ACC POWER SUPPLY [With VR30 engine]
16	P	LIN SIGNAL
17	R	DOOR MOTOR POWER SUPPLY
18	P	BLOWER MOTOR CONTROL SIGNAL
20	L	HEATED STEERING WHEEL RELAY CONTROL SIGNAL
21	P	CAN-L
22	B	GROUND
23	R	IGNITION POWER SUPPLY [With VR30 engine and with BS5]
23	W	IGNITION POWER SUPPLY [Except with VR30 engine and with BS5]
26	B	SENSOR GROUND
27	LG	IN-VEHICLE SENSOR SIGNAL
28	BR	INTAKE SENSOR SIGNAL
30	BG	EXHAUST GAS / OUTSIDE COORDETETING SENSOR SIGNAL
37	B	GROUND
38	BG	IONIZER [ON/OFF] CONTROL SIGNAL
40	BG	ECU CONTROL SIGNAL

Connector No.	Connector Name	Connector Type
M89	A/C AUTO AMP.	TH12FV-AH




Terminal No.	Color Of Wire	Signal Name [Specification]
43	BG	HEAT SENSOR GROUND LH
44	R	HEAT SENSOR SIGNAL RH
45	BR	HEAT SENSOR SIGNAL LH
46	R	HEAT SENSOR SIGNAL LH

Connector No.	Connector Name	Connector Type
M90	A/C AUTO AMP.	NS04FV-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
53	V	HEATED SEAT CONTROL SIGNAL RH
54	B	HEATED SEAT GROUND RH
55	GR	HEATED SEAT CONTROL SIGNAL LH
56	B	HEATED SEAT GROUND LH

Connector No.	Connector Name	Connector Type
M100	DISPLAY CONTROL UNIT	TH24FV-AH



Terminal No.	Color Of Wire	Signal Name [Specification]
16	LG	AV COMM (L)
17	P	CAN-L
19	R	DIMMER SIGNAL
20	BR	REVERSE SIGNAL
22	B	GROUND
26	BR	CAMERA SWITCH SIGNAL
28	SB	AV COMM (H)
29	L	CAN-H
30	R	IGN [For VR30 engine]
30	W	IGN [For 2.0L turbo gasoline engine]
31	R	VEHICLE SPEED SIGNAL (B-PULSE)
33	SB	ACC [Except for VR30 engine and with BS5]
33	V	ACC [For VR30 engine and with BS5]
34	Y	BAT

Connector No.	Connector Name	Connector Type
M132	FUSE BLOCK (1/8)	NS16FV-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
11B	LG	-
13B	P	-
14B	G	-
15B	Y	-
16B	Y	-
28	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# HEATED SEAT SYSTEM

< WIRING DIAGRAM >

## HEATED SEAT SYSTEM

4B	W	-	-	-
5B	R	-	-	-
9B	Y	-	-	-

Connector No.	M133
Connector Name	FUSE BLOCK (J/B)
Connector Type	T140FW/NH



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	V	-
12C	L	-
13C	L	-
14C	Y	-
15C	R	-
16C	R	-
17C	L	-
18C	BG	- [Without DRPO]
18C	P	- [With DRPO]
19C	B	-
1C	R	-
20C	W	-
21C	L	-
22C	L	-
23C	L	-
25C	LG	-
26C	SB	-
27C	P	-
28C	W	-
29C	W	-
30C	R	-
31C	W	-
32C	R	-
33C	B	- [With VR30 engine]
33C	R	- [With 2.0L turbo gasoline engine]
34C	W/B	-
35C	SB	-
36C	R	-
37C	W	-
38C	SB	-

39C	V	-	-	-
40C	P	-	-	-
40C	G	-	-	-
4C	P	-	-	-
5C	P	-	-	-
6C	G	-	-	-
7C	G	-	-	-
8C	G	-	-	-
9C	V	-	-	-

Connector No.	M171
Connector Name	JOINT CONNECTOR-M01
Connector Type	24342_4G42A



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	B	-
4	B	-
5	B	-
6	B	-
7	B	-
8	B	-
9	B	-
10	G	-
11	G	-
14	B	-
15	B	-
16	SB	- [With VR30 engine]
16	V	- [With 2.0L turbo gasoline engine]
17	SB	- [With VR30 engine]
17	Y	- [With VR30 engine]
18	SB	- [With VR30 engine]
18	Y	- [With 2.0L turbo gasoline engine]
19	G	-
20	G	-
22	LG	- [With VR30 engine]
22	SB	- [With 2.0L turbo gasoline engine]
23	LG	- [With VR30 engine]
23	SB	- [With 2.0L turbo gasoline engine]


24	LG	-	-	-	- [With VR30 engine]
24	SB	-	-	-	- [With 2.0L turbo gasoline engine]

Connector No.	M174
Connector Name	JOINT CONNECTOR-M04
Connector Type	24342_4G42A



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	L	-
3	L	-
4	L	-
5	L	-
6	L	-
7	Y	-
8	Y	-
9	Y	-
10	Y	-
11	Y	-
12	Y	-
13	SB	-
14	SB	-
15	SB	-
16	SB	-
17	SB	-
18	SB	-
19	SB	-
20	LG	-
21	LG	-
22	LG	-
23	LG	-
24	LG	-

Connector No.	M175
Connector Name	JOINT CONNECTOR-M05
Connector Type	NH20FI-DC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	L	-
3	L	-
4	L	-
5	L	-
6	L	-
7	L	-
8	L	-
10	P	-
11	P	-
12	P	-
13	P	-
14	P	-
15	P	-
16	P	- [With VR30 engine]
16	R	- [With 2.0L turbo gasoline engine]
17	P	- [With VR30 engine]
17	R	- [With 2.0L turbo gasoline engine]
19	R	- [With VR30 engine and with BSJ]
19	W	- [Except with VR30 engine and with BSJ]
20	R	- [With VR30 engine and with BSJ]
20	R	- [Except with VR30 engine and with BSJ]
20	W	- [Except with VR30 engine and with BSJ]

# HEATED SEAT SYSTEM

< WIRING DIAGRAM >

## HEATED SEAT SYSTEM

Connector No.	M177
Connector Name	JOINT CONNECTOR-M07
Connector Type	24342_4GAZA



6	5	4	3	2	1
12	11	10	9	8	7
18	17	16	15	14	13
24	23	22	21	20	19

Terminal No.	Color Of Wire	Signal Name (Specification)
1	L	-
2	L	-
3	L	-
4	L	-
5	L	-
6	L	-
7	P	-
8	P	-
9	P	-
10	P	-
11	P	-
12	P	-
13	L	-
14	L	-
15	L	-
16	L	-
17	L	-
18	L	-
19	W	-
20	W	-
21	W	-
22	P	-
23	P	-
24	P	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

JRJWD4887GB

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000012797204

OVERALL SEQUENCE



JMKIA8652GB

DETAILED FLOW

# DIAGNOSIS AND REPAIR WORK FLOW

## < BASIC INSPECTION >

### 1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

### 2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

#### Are any symptoms described and any DTC detected?

- Symptom is described, DTC is detected>>GO TO 3.
- Symptom is described, DTC is not detected>>GO TO 4.
- Symptom is not described, DTC is detected>>GO TO 5.

### 3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.  
Also study the normal operation and fail-safe related to the symptom.  
Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

### 4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.  
Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

### 5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to [HAC-48. "DTC Index"](#) and determine trouble diagnosis order.

#### **NOTE:**

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

#### Is DTC detected?

- YES >> GO TO 7.
- NO >> Check according to [GI-45. "Intermittent Incident"](#).

### 6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

#### Is the symptom described?

- YES >> GO TO 7.
- NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

### 7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

Inspect according to Diagnosis Procedure of the system.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

## DIAGNOSIS AND REPAIR WORK FLOW

### < BASIC INSPECTION >

---

#### Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-45. "Intermittent Incident"](#).

### 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

---

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

### 9. FINAL CHECK

---

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

#### Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.



# B277E HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### B277E HEAT SENSOR

#### DTC Description

INFOID:0000000012797205

#### DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)	DTC detecting condition
B277E	HEAT SENSOR (DRIVER SIDE) [Heat sensor (driver side)]	Heat sensor (driver side) signal voltage is too high.

#### POSSIBLE CAUSE

- Harness or connectors  
(Heat sensor signal circuit is short.)
- Seat cushion trim
- A/C auto amp.

#### FAIL-SAFE

—

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn heated seat switch ON.
3. Check DTC in "Self Diagnostic Result" mode of "A/C auto amp" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [SE-57. "Diagnosis Procedure"](#).  
 NO-1 >> To check malfunction symptom before repair: Refer to [GI-45. "Intermittent Incident"](#).  
 NO-2 >> Confirmation after repair: INSPECTION END

#### Diagnosis Procedure

INFOID:0000000012797206

##### 1.CHECK HEAT SENSOR SIGNAL

Check voltage between A/C auto amp. harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
A/C auto amp.					
Connector	Terminal				
M89	46	Ground	Ignition switch	OFF	0 V
				ON	5 V

##### Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-137. "Removal and Installation"](#).  
 NO >> GO TO 2.

##### 2.CHECK HEAT SENSOR SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector and seat cushion heater connector.
3. Check continuity between A/C auto amp. harness connector and seat cushion heater harness connector.

A/C auto amp.		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
M89	46	B612	46	Existed

4. Check continuity between A/C auto amp. harness connector and ground.

## B277E HEAT SENSOR

### < DTC/CIRCUIT DIAGNOSIS >

A/C auto amp.		Ground	Continuity
Connector	Terminal		
M89	46		Not existed

#### Is the inspection result normal?

- YES >> Replace seat cushion trim. Refer to [SE-90, "SEAT CUSHION : Disassembly and Assembly"](#).  
NO >> Repair or replace harness.

# B277F HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## B277F HEAT SENSOR

### DTC Description

INFOID:000000012797207

### DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)	DTC detecting condition
B277F	HEAT SENSOR (DRIVER SIDE) [Heat sensor (driver side)]	Heat sensor (driver side) signal voltage is too low.

### POSSIBLE CAUSE

- Harness or connectors  
(Heat sensor signal circuit is open.)
- Seat cushion trim
- A/C auto amp.

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn heated seat switch ON.
3. Check DTC in "Self Diagnostic Result" mode of "A/C auto amp" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SE-59, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-45, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012797208

#### 1. CHECK HEAT SENSOR SIGNAL

Check voltage between A/C auto amp. harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
A/C auto amp.					
Connector	Terminal				
M89	46	Ground	Ignition switch	OFF	0 V
				ON	5 V

#### Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-137, "Removal and Installation"](#).
- NO >> GO TO 2.

#### 2. CHECK HEAT SENSOR SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector and seat cushion heater connector.
3. Check continuity between A/C auto amp. harness connector and seat cushion heater harness connector.

A/C auto amp.		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
M89	46	B612	46	Existed

4. Check continuity between A/C auto amp. harness connector and ground.

## B277F HEAT SENSOR

### < DTC/CIRCUIT DIAGNOSIS >

A/C auto amp.		Ground	Continuity
Connector	Terminal		
M89	46		Not existed

#### Is the inspection result normal?

- YES >> Replace seat cushion trim. Refer to [SE-90, "SEAT CUSHION : Disassembly and Assembly"](#).  
NO >> Repair or replace harness.

# B27AF HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## B27AF HEAT SENSOR

### DTC Description

INFOID:000000012797209

### DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)	DTC detecting condition
B27AF	HEAT SENSOR (PASSENGER SIDE) [Heat sensor (passenger side)]	Heat sensor (passenger side) signal voltage is too high.

### POSSIBLE CAUSE

- Harness or connectors  
(Heat sensor signal circuit is short.)
- Seat heater cushion trim
- A/C auto amp.

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn heated seat switch ON.
3. Check DTC in "Self Diagnostic Result" mode of "A/C auto amp" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SE-61, "Diagnosis Procedure"](#).  
 NO-1 >> To check malfunction symptom before repair: Refer to [GI-45, "Intermittent Incident"](#).  
 NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012797210

#### 1.CHECK HEAT SENSOR SIGNAL

Check voltage between A/C auto amp. harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
A/C auto amp.					
Connector	Terminal				
M89	45	Ground	Ignition switch	OFF	0 V
				ON	5 V

#### Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-137, "Removal and Installation"](#).  
 NO >> GO TO 2.

#### 2.CHECK HEAT SENSOR SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector and seat cushion heater connector.
3. Check continuity between A/C auto amp. harness connector and seat cushion heater harness connector.

A/C auto amp.		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
M89	45	B619	46	Existed

4. Check continuity between A/C auto amp. harness connector and ground.

## B27AF HEAT SENSOR

### < DTC/CIRCUIT DIAGNOSIS >

A/C auto amp.		Ground	Continuity
Connector	Terminal		
M89	45		Not existed

#### Is the inspection result normal?

- YES >> Replace seat cushion trim. Refer to [SE-90, "SEAT CUSHION : Disassembly and Assembly"](#).  
NO >> Repair or replace harness.

# B27CF HEAT SENSOR

< DTC/CIRCUIT DIAGNOSIS >

## B27CF HEAT SENSOR

### DTC Description

INFOID:000000012797211

### DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)	DTC detecting condition
B27CF	HEAT SENSOR (PASSENGER SIDE) [Heat sensor (passenger side)]	Heat sensor (passenger side) signal voltage is too low.

### POSSIBLE CAUSE

- Harness or connectors  
(Heat sensor signal circuit is open.)
- Seat cushion trim
- A/C auto amp.

### FAIL-SAFE

—

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn heated seat switch ON.
3. Check DTC in "Self Diagnostic Result" mode of "A/C auto amp" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SE-63, "Diagnosis Procedure"](#).  
 NO-1 >> To check malfunction symptom before repair: Refer to [GI-45, "Intermittent Incident"](#).  
 NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012797212

#### 1. CHECK HEAT SENSOR SIGNAL

Check voltage between A/C auto amp. harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
A/C auto amp.					
Connector	Terminal				
M89	45	Ground	Ignition switch	OFF	0 V
				ON	5 V

#### Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-137, "Removal and Installation"](#).  
 NO >> GO TO 2.

#### 2. CHECK HEAT SENSOR SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect A/C auto amp. connector and seat cushion heater connector.
3. Check continuity between A/C auto amp. harness connector and seat cushion heater harness connector.

A/C auto amp.		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
M89	45	B619	46	Existed

4. Check continuity between A/C auto amp. harness connector and ground.

## B27CF HEAT SENSOR

### < DTC/CIRCUIT DIAGNOSIS >

A/C auto amp.		Ground	Continuity
Connector	Terminal		
M89	45		Not existed

#### Is the inspection result normal?

- YES >> Replace seat cushion trim. Refer to [SE-90, "SEAT CUSHION : Disassembly and Assembly"](#).  
NO >> Repair or replace harness.



# HEATED SEAT RELAY

< DTC/CIRCUIT DIAGNOSIS >

## HEATED SEAT RELAY

### Component Function Check

INFOID:000000012797213

#### 1.CHECK HEATED SEAT RELAY FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Refer to [SE-65. "Diagnosis Procedure"](#)

#### Diagnosis Procedure

INFOID:000000012797214

#### 1.CHECK HEATED SEAT RELAY POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect heated seat relay.
3. Turn ignition switch ON.
4. Check voltage between heated seat relay terminal connector and ground.

(+)		(-)	Voltage
Heated seat relay			
Connector	Terminal		
M46	2	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 2.

#### 2.CHECK FUSE

Check that the following fuse is not blown (open).

2.0L turbo gasoline engine models

Signal name	Fuse and fusible link No.
Ignition power supply	12 (10 A)

VR engine models

Signal name	Fuse and fusible link No.
Ignition power supply	14 (5 A)

Is the fuse blown (open)?

- YES >> Replace the blown (open) fuse after repairing the affected circuit if a fuse is blown (open).  
NO >> GO TO 3.

#### 3.CHECK HEATED SEAT RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect fuse block (J/B) connector.
3. Check continuity between heated seat relay terminal connector and fuse block (J/B) harness connector.

Heated seat relay		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M46	2	M133	30C	Existed

4. Check continuity between heated seat relay terminal connector and ground.

Heated seat relay		Ground	Continuity
Connector	Terminal		
M46	2		Not existed

Is the inspection result normal?

# HEATED SEAT RELAY

## < DTC/CIRCUIT DIAGNOSIS >

- YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).  
 NO >> Repair or replace harness.

### 4. CHECK HEATED SEAT RELAY GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between heated seat relay terminal connector and ground.

Heated seat relay		Ground	Continuity
Connector	Terminal		
M46	1		Existed

Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> Repair or replace harness.

### 5. CHECK HEATED SEAT RELAY

Check heated seat relay.  
 Refer to [SE-66, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.  
 NO >> Replace heated seat relay.

### 6. CHECK INTERMITTENT INCIDENT

Check intermittent incident.  
 Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:000000012797215


### 1. CHECK HEATED SEAT RELAY

1. Turn ignition switch OFF.
2. Disconnect heated seat relay.
3. Check continuity between heated seat relay terminals.

Terminal	Condition	Continuity
③	12 V direct current supply between terminals ① and ②.	Existed
⑤	No current supply	Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
 NO >> Replace heated seat relay.



# SEAT CUSHION HEATER

< DTC/CIRCUIT DIAGNOSIS >

## SEAT CUSHION HEATER DRIVER SIDE

### DRIVER SIDE : Component Function Check

INFOID:000000012797216

#### 1.CHECK FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

- YES >> Seat cushion heater function is OK.  
NO >> Refer to [SE-67, "DRIVER SIDE : Diagnosis Procedure"](#).

### DRIVER SIDE : Diagnosis Procedure

INFOID:000000012797217

#### 1.CHECK SEAT CUSHION HEATER POWER SUPPLY

Check voltage between seat cushion heater harness connector and ground.

(+)		(-)	Condition		Voltage (Approx.)
Seat cushion heater					
Connector	Terminal				
B612	45	Ground	Ignition switch	ON	Battery voltage
				Other than above	0 V

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK SEAT CUSHION HEATER CIRCUIT

- Turn ignition switch OFF.
- Disconnect seat cushion heater connector and heated seat relay connector.
- Check continuity between seat cushion heater harness connector and heated seat relay harness connector.

Seat cushion heater		Heated seat relay		Continuity
Connector	Terminal	Connector	Terminal	
B612	45	M46	3	Existed

- Check continuity between seat cushion heater harness connector and ground.

Seat cushion heater		Ground	Continuity
Connector	Terminal		
B612	45		Not existed

Is the inspection result normal?

- YES >> Replace heated seat relay.  
NO >> Repair or replace harness.

#### 3.CHECK SEAT CUSHION HEATER CONTROL SIGNAL

Check voltage between seat cushion heater harness connector and ground.

(+)		(-)	Condition		Voltage (Approx.)
Seat cushion heater					
Connector	Terminal				
B612	48	Ground	Heated seat system	Operated	0 V
				Not operated	Battery voltage

# SEAT CUSHION HEATER

## < DTC/CIRCUIT DIAGNOSIS >

### Is the inspection result normal?

- YES >> Replace seat cushion trim. Refer to [SE-90, "SEAT CUSHION : Disassembly and Assembly"](#)  
 NO >> GO TO 4.

### 4.CHECK SEAT CUSHION HEATER CONTROL SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector and A/C auto amp. connector.
3. Check continuity between seat cushion heater harness connector and A/C auto amp. harness connector.

Seat cushion heater		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
B612	48	M90	55	Existed

4. Check continuity between seat cushion heater harness connector and ground.

Seat cushion heater		Ground	Continuity
Connector	Terminal		
B612	48		Not existed

### Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-137, "Removal and Installation"](#).  
 NO >> Repair or replace harness.

## PASSENGER SIDE

### PASSENGER SIDE : Component Function Check

INFOID:000000012797218

### 1.CHECK FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

### Is the inspection result normal?

- YES >> Seat cushion heater function is OK.  
 NO >> Refer to [SE-68, "PASSENGER SIDE : Diagnosis Procedure"](#).

### PASSENGER SIDE : Diagnosis Procedure

INFOID:000000012797219

### 1.CHECK SEAT CUSHION HEATER POWER SUPPLY

Check voltage between seat cushion heater harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Seat cushion heater				
Connector	Terminal			
B619	45	Ground	Ignition switch	ON Battery voltage
			Other than above	0 V

### Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 2.

### 2.CHECK SEAT CUSHION HEATER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect seat cushion heater connector and heated seat relay connector.
3. Check continuity between seat cushion heater harness connector and heated seat relay harness connector.

# SEAT CUSHION HEATER

## < DTC/CIRCUIT DIAGNOSIS >

Seat cushion heater		Heated seat relay		Continuity
Connector	Terminal	Connector	Terminal	
B619	45	M46	3	Existed

4. Check continuity between seat cushion heater harness connector and ground.

Seat cushion heater		Ground	Continuity
Connector	Terminal		
B619	45		Not existed

Is the inspection result normal?

- YES >> Replace heated seat relay.  
 NO >> Repair or replace harness.

### 3. CHECK SEAT CUSHION HEATER CONTROL SIGNAL

Check voltage between seat cushion heater harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
Seat cushion heater					
Connector	Terminal				
B619	48	Ground	Heated seat system	Operated	0 V
				Not operated	Battery voltage

Is the inspection result normal?

- YES >> Replace seat cushion trim. Refer to [SE-90. "SEAT CUSHION : Disassembly and Assembly"](#)  
 NO >> GO TO 4.

### 4. CHECK SEAT CUSHION HEATER CONTROL SIGNAL CIRCUIT

- Turn ignition switch OFF.
- Disconnect seat cushion heater connector and A/C auto amp. connector.
- Check continuity between seat cushion heater harness connector and A/C auto amp. harness connector.

Seat cushion heater		A/C auto amp.		Continuity
Connector	Terminal	Connector	Terminal	
B619	48	M90	53	Existed

4. Check continuity between seat cushion heater harness connector and ground.

Seat cushion heater		Ground	Continuity
Connector	Terminal		
B619	48		Not existed

Is the inspection result normal?

- YES >> Replace A/C auto amp. Refer to [HAC-137. "Removal and Installation"](#).  
 NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# SEATBACK HEATER

< DTC/CIRCUIT DIAGNOSIS >

## SEATBACK HEATER DRIVER SIDE

DRIVER SIDE : Component Function Check

INFOID:000000012797220

### 1.CHECK SEATBACK HEATER FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Refer to [SE-70, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000012797221

### 1.CHECK SEATBACK HEATER POWER SUPPLY

Check voltage between seatback heater harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
B630	2	Ground	Ignition switch	ON Battery voltage
				Other than above 0 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace seat cushion trim. Refer to [SE-90, "SEAT CUSHION : Disassembly and Assembly"](#).

### 2.CHECK SEATBACK HEATER CONTROL SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect seatback heater connector and seat cushion heater connector.
3. Check continuity between seatback heater harness connector and seat cushion heater harness connector.

Seatback heater		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
B630	1	B612	48	Existed

4. Check continuity between seatback heater harness connector and ground.

Seatback heater		Ground	Continuity
Connector	Terminal		
B630	1		Not existed

Is the inspection result normal?

YES >> Replace seatback trim. Refer to [SE-85, "SEATBACK : Disassembly and Assembly"](#).

NO >> Replace seat cushion trim. Refer to [SE-90, "SEAT CUSHION : Disassembly and Assembly"](#).

## PASSENGER SIDE

PASSENGER SIDE : Component Function Check

INFOID:000000012797222

### 1.CHECK SEATBACK HEATER FUNCTION

Check that heated seat warms to preset temperature when operating heated seat switch to the optimal position.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Refer to [SE-71, "PASSENGER SIDE : Diagnosis Procedure"](#).

# SEATBACK HEATER

< DTC/CIRCUIT DIAGNOSIS >

## PASSENGER SIDE : Diagnosis Procedure

INFOID:000000012797223

### 1. CHECK SEATBACK HEATER POWER SUPPLY

Check voltage between seatback heater harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)	
Seatback heater					
Connector	Terminal				
B632	2	Ground	Ignition switch	ON	Battery voltage
				Other than above	0 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace seat cushion trim. Refer to [SE-90, "SEAT CUSHION : Disassembly and Assembly"](#).

### 2. CHECK SEATBACK HEATER CONTROL SIGNAL CIRCUIT

- Turn ignition switch OFF.
- Disconnect seatback heater connector and seat cushion heater connector.
- Check continuity between seatback heater harness connector and seat cushion heater harness connector.

Seatback heater		Seat cushion heater		Continuity
Connector	Terminal	Connector	Terminal	
B632	1	B619	48	Existed

- Check continuity between seatback heater harness connector and ground.

Seatback heater		Ground	Continuity
Connector	Terminal		
B632	1		Not existed

Is the inspection result normal?

YES >> Replace seatback trim. Refer to [SE-85, "SEATBACK : Disassembly and Assembly"](#).

NO >> Replace seat cushion trim. Refer to [SE-90, "SEAT CUSHION : Disassembly and Assembly"](#).

# HEATED SEAT DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### HEATED SEAT DOES NOT OPERATE

#### Diagnosis Procedure

INFOID:000000012797224

#### 1. CHECK HEATED SEAT RELAY

Check heated seat relay.

Refer to [SE-65, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK SEAT CUSHION HEATER

Check seat cushion heater.

Refer to [SE-67, "DRIVER SIDE : Component Function Check"](#) (driver side) or [SE-68, "PASSENGER SIDE : Component Function Check"](#) (passenger side).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK SEATBACK HEATER

Check seatback heater.

Refer to [SE-70, "DRIVER SIDE : Component Function Check"](#) (driver side) or [SE-70, "PASSENGER SIDE : Component Function Check"](#) (passenger side).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. REPLACE A/C AUTO AMP.

Replace A/C auto amp. Refer to [HAC-137, "Removal and Installation"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).



# STEERING POSITION FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## STEERING POSITION FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000012797225

#### 1. CHECK AUTOMATIC DRIVE POSITIONER CONTROL UNIT POWER SUPPLY AND GROUND CIRCUIT

Check automatic drive positioner control unit power supply and ground circuit.

Refer to [ADP-82, "AUTOMATIC DRIVE POSITIONER CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CHECK TILT SWITCH

Check tilt switch.

Refer to [ADP-92, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3. CHECK TELESCOPIC SWITCH

Check telescopic switch.

Refer to [ADP-94, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4. CHECK TILT SENSOR

Check tilt sensor.

Refer to [ADP-112, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

#### 5. CHECK TELESCOPIC SENSOR

Check telescopic sensor.

Refer to [ADP-115, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

#### 6. REPLACE AUTOMATIC DRIVE POSITIONER CONTROL UNIT

Replace automatic drive positioner control unit. Refer to [ADP-153, "Removal and Installation"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 7.

#### 7. REPLACE DRIVER SEAT CONTROL UNIT

Replace driver seat control unit. Refer to [ADP-152, "Removal and Installation"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# TILT FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

---

## TILT FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000012797226

#### 1.CHECK TILT SWITCH

---

Check tilt switch.

Refer to [ADP-92, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2.CHECK TILT MOTOR

---

Check tilt motor.

Refer to [ADP-130, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.CHECK TILT SENSOR

---

Check tilt sensor.

Refer to [ADP-112, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4.CONFIRM THE OPERATION

---

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

# TELESCOPIC FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

## TELESCOPIC FUNCTION DOES NOT OPERATE

### Diagnosis Procedure

INFOID:000000012797227

#### 1.CHECK TELESCOPIC SWITCH

Check telescopic switch.

Refer to [ADP-94, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2.CHECK TELESCOPIC MOTOR

Check telescopic motor.

Refer to [ADP-132, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.CHECK TELESCOPIC SENSOR

Check telescopic sensor.

Refer to [ADP-115, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE


# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK AND RATTLE TROUBLE DIAGNOSES

### Work Flow

INFOID:000000012797228



### CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [SE-80, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)  
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)  
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)  
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)  
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)  
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)  
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumblebee)  
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that a technician may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

### DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when the repair is reconfirmed.

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
  - 2) Tap or push/pull around the area where the noise appears to be coming from.
  - 3) Rev the engine.
  - 4) Use a floor jack to recreate vehicle "twist".
  - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
  - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
  - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

## CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

## LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis ear: J-39570, Engine ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
  - Removing the components in the area that is are suspected to be the cause of the noise.  
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
  - Tapping or pushing/pulling the component that is are suspected to be the cause of the noise.  
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
  - Feeling for a vibration by hand by touching the component(s) that is are suspected to be the cause of the noise.
  - Placing a piece of paper between components that are suspected to be the cause of the noise.
  - Looking for loose components and contact marks.  
Refer to [SE-78. "Inspection Procedure"](#).

## REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
  - Separate components by repositioning or loosening and retightening the component, if possible.
  - Insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-50397) is available through the authorized Nissan Parts Department.

### **CAUTION:**

**Never use excessive force as many components are constructed of plastic and may be damaged.**

### **NOTE:**

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-50397). are listed on the inside cover of the kit, and can each be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97in)

FELT CLOTHTAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

---

Insulates where slight movement is present. Ideal for instrument panel applications.

### SILICONE GREASE

Used in place of UHMW tape that is be visible or does not fit. Will only last a few months.

### SILICONE SPRAY

Used when grease cannot be applied.

### DUCT TAPE

Used to eliminate movement.

## CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

## Inspection Procedure

INFOID:000000012797229

Refer to Table of Contents for specific component removal and installation information.

## INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

### **CAUTION:**

**Never use silicone spray to isolate a squeak or rattle. If the area is saturated with silicone, the recheck of repair becomes impossible.**

## CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

## DOORS

Pay attention to the following:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. The areas can usually be insulated with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-50397) to repair the noise.

## TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the customer.

In addition look for the following:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

## < SYMPTOM DIAGNOSIS >

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

### SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

### SEATS

When isolating seat noise it's important to note the position the seats in and the load placed on the seat when the noise occurs. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

### UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## Diagnostic Worksheet

INFOID:000000012797230







### SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Infiniti Customer:

We are concerned about your satisfaction with your Infiniti vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Infiniti right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service consultant or technician to ensure we confirm the noise you are hearing.

#### I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8741E



# SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

## SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

---

---

### II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- |   |  |
|---|--|
| <input type="checkbox"/> anytime                      | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning      | <input type="checkbox"/> when it is raining or wet     |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions       |
| <input type="checkbox"/> only when it is hot outside  | <input type="checkbox"/> other:                        |

### III. WHEN DRIVING:

- through driveways
- over rough roads
- over speed bumps
- only about \_\_\_\_ mph
- on acceleration
- coming to a stop
- on turns: left, right or either (circle)
- with passengers or cargo
- other: \_\_\_\_\_
- after driving \_\_\_\_ miles or \_\_\_\_ minutes

### IV. WHAT TYPE OF NOISE

- squeak (like tennis shoes on a clean floor)
- creak (like walking on an old wooden floor)
- rattle (like shaking a baby rattle)
- knock (like a knock at the door)
- tick (like a clock second hand)
- thump (heavy, muffled knock noise)
- buzz (like a bumble bee)

### TO BE COMPLETED BY DEALERSHIP PERSONNEL

#### Test Drive Notes:

---

---

---

	YES	NO	Initials of person performing
Vehicle test driven with customer	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise verified on test drive	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Noise source located and repaired	<input type="checkbox"/>	<input type="checkbox"/>	_____
- Follow up test drive performed to confirm repair	<input type="checkbox"/>	<input type="checkbox"/>	_____

VIN: \_\_\_\_\_ Customer Name: \_\_\_\_\_  
W.O.# \_\_\_\_\_ Date: \_\_\_\_\_

This form must be attached to Work Order

PIIB8742E

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT


< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### FRONT SEAT

Exploded View

INFOID:000000012797231



# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- |   |  |   |   |
|---|--|---|---|
| ① Seatback trim                                 | ② Seatback pad                                   | ③ Seat cushion trim                             | A |
| ④ Seat cushion pad                              | ⑤ Forward pad                                    | ⑥ Seat belt buckle *                            |   |
| ⑦ Seat cushion outside finisher inner side      | ⑧ Seat cushion inside finisher inner side front  | ⑨ Seat cushion inside finisher inner side rear  | B |
| ⑩ Seat cushion lowside finisher inner side      | ⑪ Seat cushion forward finisher                  | ⑫ Front leg cover inner side                    |   |
| ⑬ Front leg cover outer side                    | ⑭ Occupant detection system control unit         | ⑮ ODS harness connector                         | C |
| ⑯ Driver seat control unit                      | ⑰ Harness assembly                               | ⑱ Power seat switch                             |   |
| ⑲ Side support switch                           | ⑳ Seat cushion outside finisher outer side       | ㉑ Slide knob                                    | D |
| ㉒ Reclining knob                                | ㉓ Lumber support switch                          | ㉔ Seat cushion inside finisher outer side rear  |   |
| ㉕ Seat cushion inside finisher outer side front | ㉖ Seat cushion outside finisher outer side lower | ㉗ Seat cushion inside finisher outer side lower | E |
| ㉘ Seat frame                                    | ㉙ Rear leg cover outer side                      | ㉚ Rear leg cover inner side                     | F |
| ㉛ side support assembly                         | ㉜ M-clip   | ㉝ Seatback board                                |   |
| ㉞ Side air bag assembly                         | ㉟ Headrest                                       | ㊱ Headrest holder (lock)                        | G |
| ㊲ Headrest holder (free)                        | ㊳ Lumber lever                                   | ㊴ Snap ring                                     |   |

⊗ : Always replace after every disassembly.

⊙ : N·m (kg-m, in-lb)

⊕ : N·m (kg-m, ft-lb)

\*: Tighten together with seat belt buckle and tongue. Refer to [SB-8, "Exploded View"](#).

## Removal and Installation

INFOID:000000012797232

### DANGER:

- Before disconnect, push ignition switch OFF, disconnect battery negative terminal and then wait for at least 3 minutes (discharges electricity held in the additional power supply circuit of the air bag diagnosis sensor unit).
- Never use air tools or electric tools for servicing (prevents the air bag diagnosis sensor unit from activating unexpectedly due to vibration).
- Always work from the side of air bag module. Never work in front of it.
- To prevent accidental explosion, never insert any objects (screwdriver) into the side air bag module harness connector (for prevention of accidental activation of the inflator due to static electricity).


### CAUTION:

When removing and installing, use shop cloths to protect parts from damage.

### REMOVAL

1. Remove headrest.
2. Slide seat to the frontmost position.
3. Remove rear leg cover.
  - Disengage rear leg cover fixing pawls, and then remove rear leg cover.
  - Outer side


△ : Pawl




# FRONT SEAT

## < REMOVAL AND INSTALLATION >


- Inner side


 : Pawl




4. Remove front seat rear fixing bolts.
5. Slide seat to the rearmost position.
6. Remove front leg cover.  
Disengage front leg cover fixing pawl, and then remove front leg cover.


- Outer side

 : Pawl



- Inner side

 : Pawl



7. Remove front seat front fixing bolts.
8. Disconnect seat cushion lower harness connector, and harness fixing clips.

### **WARNING:**

Before disconnect, turn ignition switch OFF, disconnect battery negative terminal and then wait for at least 3 minutes (discharges electricity held in the additional power supply circuit of the air bag diagnosis sensor unit).

### **CAUTION:**

Before performing removal operation, check the installation position of harness connectors and harness fixing clamps.

### **NOTE:**

When removing the seat cushion or seat cushion finisher, move the seat lifter to the highest level.

9. Remove front seat from the vehicle.

## INSTALLATION


Note the following item, and then install in the reverse order of removal.

### **CAUTION:**

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- When installing, tighten fixing bolts according to the numerical order 1 → 4 indicated by arrows as shown in the figure, starting from front inner fixing bolt.



## SEATBACK

### SEATBACK : Disassembly and Assembly


INFOID:000000012797233

#### CAUTION:


When removing, always use a remover tool that is made of plastic to prevent damage to the parts.


#### DISASSEMBLY

1. Disengage seatback board fixing rubber band (A).





2. Disengage side air bag harness connector fixing clips (A), harness clips (B) and cut cable tie (C).

 : Clip



3. Remove seat cushion outside finisher outer side. Refer to [SE-92. "SEAT CUSHION FINISHER : Removal and Installation"](#).
4. Disengage side air bag harness clip (A).

 : Clip





5. Remove seatback board.

# FRONT SEAT


## < REMOVAL AND INSTALLATION >


a. Disengage seatback board fixing M-clips.

 : Clip




b. Disengage seatback board fixing pawls using a remover tool (A).


 : Pawl




c. Remove seatback board to pull down.



6. Disengage seatback retainer (A).




7. Disconnect seat heater harness connector (A).



# FRONT SEAT

## < REMOVAL AND INSTALLATION >

8. Disengage seatback retainer (A) and hook-and-loop fastener (B).




9. Remove headrest holder.


**CAUTION:**

**Before installing headrest holder check its orientation (front / rear and right / left).**

Remove the headrest holder by raising it while pinching the pawls from the bottom of the headrest holder.




10. Remove side air bag fixing nuts (A).



11. Remove lumbar lever (manual only).

Remove snap ring (A), and then remove lumbar lever (B).




A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT


## < REMOVAL AND INSTALLATION >

12. Remove seatback trim and seatback pad as a set.




13. Remove side support assembly (if equipped).


a. Disconnect side support assembly harness connector (A).




b. Remove side support pad.



c. Disengage lumber support pad fixing pawls, and then remove lumber support pad.

 : Pawl






# FRONT SEAT

## < REMOVAL AND INSTALLATION >

- d. Remove side support assembly.




14. Separate seatback trim and seatback pad.

- a. Remove side air bag assembly.

**CAUTION:**

- Note how the part is installed for reference during assembly.
- To prevent accidental explosion, always place the driver air bag module with deploying direction facing upward.

← : Deploying direction



- To prevent damage to the parts, never impact the side air bag module.
- Replace the side air bag module if it is dropped or sustains an impact.



- To prevent accidental explosion, never insert any foreign objects (screwdriver, etc.) into the side air bag module.
- To prevent accidental explosion, never disassemble the side air bag module.
- To prevent accidental explosion, never expose the side air bag module to temperature of more than 90°C (194°F).
- To prevent damage to the parts, never allow oil, grease, detergent, or water to come in contact with the side air bag module.

- b. Remove hog rings, and then separate seatback trim and seatback pad.

**CAUTION:**

Before performing separating operation, check the installation position of hog rings.

## ASSEMBLY

Note the following items, and then assemble in the reverse order of disassembly.

**CAUTION:**

- For hog ring that is removed or crimped unsuccessfully, fix it by using a new hog ring. (Never reuse hog ring.)
- Always install the hog rings in position.
- When installing the side air bag, check that the inner cloth (reinforcement cloth) is not caught in bolt hole.

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT

< REMOVAL AND INSTALLATION >

## SEAT CUSHION

### SEAT CUSHION : Disassembly and Assembly


INFOID:000000012797234

#### CAUTION:


When removing, always use a remover tool that is made of plastic to prevent damage to the parts.

#### DISASSEMBLY

1. Disengage seatback board fixing rubber band (A).




2. Disengage seat cushion trim fixing rubber band (A).




3. Remove seat cushion outside finisher outer side. Refer to [SE-92. "SEAT CUSHION FINISHER : Removal and Installation"](#)

4. Disengage seat cushion trim fixing hook-and-loop fastener (A).



5. Disconnect seat heater harness connector (A).




6. Disengage seat cushion retainer (A) and rubber band (B).


# FRONT SEAT

## < REMOVAL AND INSTALLATION >


- With thigh extension



- Without thigh extension



- Remove seat cushion retainer of thigh extension portion (with thigh extension only).
  - Extend thigh extension.
  - Remove seat cushion retainer **A**, and then roll up seat cushion trim and thigh extension pad as a set.




A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


# FRONT SEAT

## < REMOVAL AND INSTALLATION >


c. Disengage seat cushion trim fixing portion (A).




d. Disengage seat cushion trim fixing portion (A).



e. Remove seat cushion retainer (A).



8. Remove seat cushion trim and seat cushion pad as a set.



9. Remove hog rings, and then separate seat cushion trim and seat cushion pad.

**CAUTION:**

**Before performing separating operation, check the installation position of hog rings.**

### ASSEMBLY

Assemble in the reverse order of disassembly.

### SEAT CUSHION FINISHER

### SEAT CUSHION FINISHER : Removal and Installation

INFOID:000000012797235

### SEAT CUSHION FORWARD FINISHER

# FRONT SEAT


## < REMOVAL AND INSTALLATION >

Removal


### CAUTION:


When removing, always use a remover tool that is made of plastic to prevent damage to the parts.

1. Remove seat cushion forward finisher fixing screws (A).



2. Slide the seat cushion forward finisher, disengage seat cushion forward finisher fixing pawls, and then remove seat cushion forward finisher.



 : Pawl

Installation

Install in the reverse order of removal.

## SEAT CUSHION INSIDE FINISHER


Removal

### CAUTION:

When removing, always use a remover tool that is made of plastic to prevent damage to the parts.

SEAT CUSHION INSIDE FINISHER (OUTER SIDE / INNER SIDE) REAR

1. Apply protective tape (A) on the parts to protect it from damage.





A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# FRONT SEAT

## < REMOVAL AND INSTALLATION >


2. Disengage seat cushion inside finisher (outer side / inner side) rear fixing pawls using a remover tool (A), and then remove seat cushion inside finisher (outer side / inner side) rear.



 : Pawl

## SEAT CUSHION INSIDE FINISHER (OUTER SIDE / INNER SIDE) FRONT

1. Remove seat cushion. Refer to [SE-90. "SEAT CUSHION : Disassembly and Assembly"](#).
2. Remove seat cushion outside finisher inner side (seat cushion inside finisher inner side front only).
3. Pull seat cushion inside finisher (outer side / inner side) front, and then remove seat cushion inside finisher (outer side / inner side) front.



## Installation

Install in the reverse order of removal.

## SEAT CUSHION OUTSIDE FINISHER


### Removal

#### **CAUTION:**

**When removing, always use a remover tool that is made of plastic to prevent damage to the parts.**

## SEAT CUSHION OUTSIDE FINISHER OUTER SIDE


1. Remove seat cushion forward finisher.
2. Disconnect side support harness connector (A) (with side support only).




# FRONT SEAT



## < REMOVAL AND INSTALLATION >

- Remove seat cushion trim fixing rubber band (A), and then remove seat cushion outside finisher outer side fixing screw (B).




- Remove seat cushion inside finisher outer side rear.
- Disengage seat cushion outside finisher outer side fixing clips and pawls.




-  : Clip
-  : Pawl



- Disconnect harness connector (A), (B) (if equipped), and then remove seat cushion outside finisher outer side.



### SEAT CUSHION OUTSIDE FINISHER INNER SIDE

- Remove seat cushion inside finisher inner side rear.
- Disengage seat cushion outside finisher inner side fixing clip and pawls, and then remove seat cushion outside finisher inner side.



-  : Clip
-  : Pawl

# FRONT SEAT

## < REMOVAL AND INSTALLATION >

### Installation

Install in the reverse order of removal.

### LOWER FINISHER



#### Removal

#### **CAUTION:**


**When removing, always use a remover tool that is made of plastic to prevent damage to the parts.**

#### SEAT CUSHION OUTSIDE FINISHER OUTER SIDE LOWER

1. Disengage seat cushion outside finisher outer side lower fixing pawls and clips.





2. Slide the fixing portion ① of seat cushion outside finisher outer side lower, and then remove seat cushion outside finisher outer side lower.



#### SEAT CUSHION INSIDE FINISHER OUTER SIDE LOWER

1. Disengage seat cushion inside finisher outer side lower fixing clip and pawls, and then remove seat cushion inside finisher outer side lower.




#### SEAT CUSHION LOWSIDE FINISHER INNER SIDE




# FRONT SEAT

## < REMOVAL AND INSTALLATION >

1. Disengage seat cushion lowside finisher inner side fixing pawls by pull, and then remove seat cushion lowside finisher inner side.

 : Pawl



### Installation

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE


# REAR SEAT (BENCH SEAT)

< REMOVAL AND INSTALLATION >

## REAR SEAT (BENCH SEAT)

Exploded View

INFOID:000000012797236




- |                     |                     |                     |
|---------------------|---------------------|---------------------|
| ① Headrest LH       | ② Headrest center   | ③ Headrest RH       |
| ④ Seat belt hook RH | ⑤ Seatback trim     | ⑥ Seatback pad      |
| ⑦ Seat cushion hook | ⑧ Hook cover        | ⑨ Seat cushion pad  |
| ⑩ Seat cushion trim | ⑪ Armrest pad       | ⑫ Armrest trim      |
| ⑬ Cup holder        | ⑭ Cup holder spacer | ⑮ Hinge cover LH    |
| ⑯ Hinge bracket     | ⑰ Hinge cover RH    | ⑱ Seat belt hook LH |

# REAR SEAT (BENCH SEAT)

## < REMOVAL AND INSTALLATION >

⑲ Headrest holder (lock)

⑳ Headrest holder (free)

 : N·m (kg·m, ft·lb)

## ARMREST

### ARMREST : Removal and Installation

INFOID:000000012797237

#### CAUTION:

When removing and installing, use shop cloths to protect parts from damage.


#### REMOVAL

1. Remove seatback. Refer to [SE-101. "SEATBACK : Removal and Installation"](#).
2. Remove armrest trim fixing hog rings.


#### CAUTION:

Before performing separating operation, check the installation position of hog rings.

3. Remove armrest fixing nuts (A), and then remove armrest.



4. Remove hinge cover fixing clips (A), and then remove hinge covers.



#### INSTALLATION

Note the following items, and then install in the reverse order of removal.

#### CAUTION:

- For hog ring that is removed or crimped unsuccessfully, fix it by using a new hog ring. (Never reuse hog ring.)
- Always install the hog rings in position.

### ARMREST : Disassembly and Assembly

INFOID:000000012797238


#### DISASSEMBLY

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P


## REAR SEAT (BENCH SEAT)


### < REMOVAL AND INSTALLATION >

1. Remove hinge bracket fixing bolts (A), and then remove hinge bracket.





2. Remove cup holder.
  - a. Disengage cup holder spacer fixing pawls by pull up while push cup holder spacer fixing pawl using a pic tool (A).

 : Pawl




- b. Disengage cup holder spacer fixing pawls, and then remove cup holder spacer.


 : Pawl



- c. Remove cup holder fixing screw (A).




- d. Pull up cup holder of vehicle rear side, and then remove cup holder.



## REAR SEAT (BENCH SEAT)

### < REMOVAL AND INSTALLATION >

3. Disengage armrest trim fixing retainer (A), and then separate armrest trim and armrest pad.



### ASSEMBLY

Assemble in the reverse order of disassembly.

### SEAT CUSHION

#### SEAT CUSHION : Removal and Installation


INFOID:0000000012797239

#### **CAUTION:**

**When removing and installing, use shop cloths to protect parts from damage.**

#### REMOVAL

1. Lift up seat cushion while pulling a seat cushion hook levers, and then disengage seat cushion hook.



2. Remove seat cushion from vehicle.

#### INSTALLATION

Install in the reverse order of removal.

#### SEAT CUSHION : Disassembly and Assembly

INFOID:0000000012797240

#### DISASSEMBLY

Remove hog rings, and then separate seat cushion trim and seat cushion pad.

#### **CAUTION:**

**Before performing separating operation, check the installation position of hog rings.**

#### ASSEMBLY

Note the following items, and then assemble in the reverse order of disassembly.

#### **CAUTION:**

- For hog ring that is removed or crimped unsuccessfully, fix it by using a new hog ring. (Never reuse hog ring.)
- Always install the hog rings in position.

### SEATBACK

#### SEATBACK : Removal and Installation

INFOID:0000000012797241

#### **CAUTION:**


**When removing and installing, use shop cloths to protect parts from damage.**

#### REMOVAL


## REAR SEAT (BENCH SEAT)

### < REMOVAL AND INSTALLATION >

1. Remove seat cushion. Refer to [SE-101, "SEAT CUSHION : Removal and Installation"](#).
2. Remove seat belt from seat belt hook.
3. Remove seatback fixing nuts (A).



4. Lift up seatback, disengage seatback frame (B) from engaging portion (C), and then remove seatback.



### INSTALLATION

Note the following item, and then install in the reverse order of removal.

#### **CAUTION:**

**When installing, temporarily tighten all fixing bolts, and then tighten bolts to specified torque.**

### SEATBACK : Disassembly and Assembly

INFOID:000000012797242


### DISASSEMBLY

1. Remove armrest. Refer to [SE-99, "ARMREST : Removal and Installation"](#).
2. Remove headrest holder.

#### **CAUTION:**

**Before installing headrest holder check its orientation (front/ rear and right/ left).**

Use pincers, etc., to press up pawls as shown by the arrows in the figure, and remove headrest holder from seatback.



3. Remove hog rings, and then separate seatback trim and seatback pad.

#### **CAUTION:**

**Before performing separating operation, check the installation position of hog rings.**

### ASSEMBLY

Note the following items, and then assemble in the reverse order of disassembly.

#### **CAUTION:**

- For hog ring that is removed or crimped unsuccessfully, fix it by using a new hog ring. (Never reuse hog ring.)
- Always install the hog rings in position.


# REAR SEAT (6 : 4 SEPARATE SEAT)

< REMOVAL AND INSTALLATION >

## REAR SEAT (6 : 4 SEPARATE SEAT)

Exploded View

INFOID:000000012797243




- |                        |                          |                          |
|------------------------|--------------------------|--------------------------|
| ① Cable bracket RH     | ② Seat lock RH           | ③ Seat belt hook RH      |
| ④ Headrest RH          | ⑤ Headrest center        | ⑥ Seatback hinge RH      |
| ⑦ Seatback lid         | ⑧ Headrest holder (lock) | ⑨ Headrest holder (free) |
| ⑩ Seatback trim RH     | ⑪ Seatback pad RH        | ⑫ Seatback side trim RH  |
| ⑬ Seatback side pad RH | ⑭ Hinge cover RH         | ⑮ Hinge bracket          |
| ⑯ Armrest trim         | ⑰ Armrest pad            | ⑱ Seat cushion trim      |

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# REAR SEAT (6 : 4 SEPARATE SEAT)

## < REMOVAL AND INSTALLATION >

- |                          |                          |                      |
|--------------------------|--------------------------|----------------------|
| ①9 Seat cushion pad      | ②0 Seat cushion hook     | ②1 Hook cover        |
| ②2 Seatback side pad LH  | ②3 Seatback side trim LH | ②4 Seat belt hook LH |
| ②5 Seat lock LH          | ②6 Cable bracket LH      | ②7 Seatback hinge LH |
| ②8 Seatback board LH     | ②9 Striker cover         | ③0 Seatback board RH |
| ③1 Seatback hinge center | ③2 Headrest LH           | ③3 Seatback trim LH  |
| ③4 Seatback pad LH       | ③5 Armrest escutcheon    | ③6 Cup holder spacer |
| ③7 Cup holder            |                          |                      |

 : N·m (kg-m, ft-lb)

## ARMREST

### ARMREST : Removal and Installation


INFOID:000000012797244

#### CAUTION:


When removing and installing, use shop cloths to protect parts from damage.


#### REMOVAL

1. Remove seatback board.
  - a. Remove striker cover fixing screws (A), and then remove striker cover.




- b. Disengage seatback board fixing clips, and then remove seatback board.

 : Clip



2. Remove seatback lid.
  - a. Disengage seatback trim (A) and retainer (B).







# REAR SEAT (6 : 4 SEPARATE SEAT)


## < REMOVAL AND INSTALLATION >

b. Remove seatback lid fixing screws (A).




c. Disengage seatback trim fixing pawls, and then remove seatback lid.


 : Pawl




3. Remove armrest trim fixing retainer (A) and armrest fixing nuts (B).



4. Pull armrest, and then remove armrest and armrest escutcheon as a set.



5. Remove armrest escutcheon.




A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

## REAR SEAT (6 : 4 SEPARATE SEAT)

### < REMOVAL AND INSTALLATION >

6. Remove hinge cover.  
Remove hinge cover fixing clip (A), and then remove hinge cover.



### INSTALLATION


Install in the reverse order of removal.

### ARMREST : Disassembly and Assembly


INFOID:000000012797245


### DISASSEMBLY

1. Remove hinge bracket fixing bolts (A), and then remove hinge bracket.





2. Remove cup holder.
  - a. Disengage cup holder spacer fixing pawls by pull up while push cup holder spacer fixing pawl using a pic tool (A).

 : Pawl



- b. Disengage cup holder spacer fixing pawls, and then remove cup holder spacer.


 : Pawl




## REAR SEAT (6 : 4 SEPARATE SEAT)

### < REMOVAL AND INSTALLATION >


- c. Remove cup holder fixing screw (A).



- d. Pull up cup holder of vehicle rear side, and then remove cup holder.



3. Disengage armrest trim fixing retainer (A), and then separate armrest trim and armrest pad.



### ASSEMBLY

Assemble in the reverse order of disassembly.

### SEATBACK

#### SEATBACK : Removal and Installation

INFOID:000000012797246

#### **CAUTION:**

**When removing and installing, use shop cloths to protect parts from damage.**

#### REMOVAL

Seatback

#### **CAUTION:**

**Never remove seat cushion during seatback removal and installation to prevent dirt on the seatback.**


1. Pull the strap to fold seatback down.

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

## REAR SEAT (6 : 4 SEPARATE SEAT)

### < REMOVAL AND INSTALLATION >

2. Disengage hook-and-loop fastener (A) for trunk floor carpet.



3. Roll up trim for seatback board.

- a. Remove clips


- RH side

Remove seatback board trim fixing clips (A), and then disengage hook-and-loop fastener (D).


- LH side

Remove seatback board trim fixing clips (B), and then disengage hook-and-loop fastener (D), clip (C).

- b. Further roll up the trim, and disengage hook-and-loop fastener, to expose seatback fixing bolts.




4. Remove seatback fixing bolts (A), and then remove seatback.



#### Seatback side

1. Remove seat cushion. Refer to [SE-110, "SEAT CUSHION : Removal and Installation"](#).
2. Remove seat belt from seat belt hook.
3. Remove seatback side fixing nut (A), and then lift up seatback side, disengage seatback side frame (C) from engaging point (D), remove seatback side.



#### INSTALLATION

Note the following item, and then install in the reverse order of removal.

#### **CAUTION:**

**When installing, temporarily tighten all fixing bolts, and then tighten bolts to specified torque.**

# REAR SEAT ( 6 : 4 SEPARATE SEAT )

< REMOVAL AND INSTALLATION >

## SEATBACK : Disassembly and Assembly

INFOID:000000012797247

### DISASSEMBLY

#### Seatback RH

1. Remove armrest. Refer to [SE-104, "ARMREST : Removal and Installation"](#).
2. Remove hog rings.

**CAUTION:**


**Before performing separating operation, check the installation position of hog rings.**

3. Remove headrest holder.

**CAUTION:**

**Before installing headrest holder check its orientation (Front/rear and right/left).**


Remove the headrest holder by raising it while pinching the pawls from the bottom of the headrest holder.




4. Separate seatback trim and seatback pad.


#### Seatback LH

1. Remove seatback board.
  - a. Remove striker cover fixing screws (A), and then remove striker cover.



- b. Disengage seatback board fixing clips, and then remove seatback board.

 : Clip



2. Remove headrest holder.


**CAUTION:**

**Before installing headrest holder check its orientation (Front/rear and right/left).**

## REAR SEAT (6 : 4 SEPARATE SEAT)

### < REMOVAL AND INSTALLATION >

Remove the headrest holder by raising it while pinching the pawls from the bottom of the headrest holder.




3. Remove hog rings, and then separate seatback trim and seatback pad.

**CAUTION:**


**Before performing separating operation, check the installation position of hog rings.**

Seatback side

1. Remove seat belt hook fixing screws (A), and then remove seat belt hook.



2. Disengage seatback side trim fixing retainer (A).



3. Remove hog rings, and then separate seatback side trim and seatback side pad.

**CAUTION:**

**Before performing separating operation, check the installation position of hog rings.**

### ASSEMBLY

Note the following items, and then assemble in the reverse order of disassembly.

**CAUTION:**

- For hog ring that is removed or crimped unsuccessfully, fix it by using a new hog ring. (Never reuse hog ring.)
- Always install the hog rings in position.

### SEAT CUSHION

#### SEAT CUSHION : Removal and Installation

INFOID:000000012797248

**CAUTION:**


**When removing and installing, use shop cloths to protect parts from damage.**

### REMOVAL

## REAR SEAT (6 : 4 SEPARATE SEAT)

### < REMOVAL AND INSTALLATION >

1. Lift up seat cushion while pulling a seat cushion hook levers, and then disengage seat cushion hook.



2. Remove seat cushion from vehicle.

### INSTALLATION

Install in the reverse order of removal.

### SEAT CUSHION : Disassembly and Assembly

INFOID:0000000012797249

#### DISASSEMBLY

Remove hog rings, and then separate seat cushion trim and seat cushion pad.

#### **CAUTION:**

**Before performing separating operation, check the installation position of hog rings.**

#### ASSEMBLY

Note the following items, and then assemble in the reverse order of disassembly.

#### **CAUTION:**

- For hog ring that is removed or crimped unsuccessfully, fix it by using a new hog ring. (Never reuse hog ring.)
- Always install the hog rings in position.

### SEATBACK HINGE

### SEATBACK HINGE : Removal and Installation

INFOID:0000000012797250

#### REMOVAL

1. Remove seatback Refer to [SE-101. "SEATBACK : Removal and Installation"](#).
2. Remove seatback hinge fixing bolts, and then remove seatback hinge.

#### INSTALLATION

Note the following item, and then install in the reverse order of removal.

#### **CAUTION:**

**When installing, temporarily tighten all fixing bolts, and then tighten bolts to specified torque.**


### SEAT LOCK

### SEAT LOCK : Removal and Installation

INFOID:0000000012797251

#### REMOVAL

1. Remove trunk upper finisher. Refer to [INT-54. "TRUNK UPPER FINISHER : Removal and Installation"](#).
2. Pull down cable, and then remove cable.




## REAR SEAT (6 : 4 SEPARATE SEAT)

### < REMOVAL AND INSTALLATION >

---

3. Remove rear parcel shelf finisher. Refer to [INT-37, "Removal and Installation"](#).
4. Remove center seat belt retractor (RH side only). Refer to [SB-14, "SEAT BELT RETRACTOR : Removal and Installation"](#).
5. Remove seat lock fixing bolts (A), and then remove seat lock.



### INSTALLATION

Note the following item, and then install in the reverse order of removal.

**CAUTION:**

**When installing, temporarily tighten all fixing bolts, and then tighten bolts to specified torque.**




# CHILD SEAT ANCHOR

< REMOVAL AND INSTALLATION >


## CHILD SEAT ANCHOR

Exploded View

INFOID:000000012797252



- ① Tether anchorage plate
- ② Tether anchorage spacer
- ③ Lock washer
- ④ ISO FIX bracket RH outside
- ⑤ ISO FIX bracket RH inside
- ⑥ ISO FIX bracket LH inside
- ⑦ ISO FIX bracket LH outside

 : N·m (kg·m, ft·lb)

## TETHER ANCHOR PLATE

### TETHER ANCHOR PLATE : Removal and Installation

INFOID:000000012797253

#### REMOVAL

1. Remove rear parcel shelf finisher. Refer to [INT-37, "Removal and Installation"](#).
2. Remove tether anchorage plate fixing bolt, and then remove tether anchorage plate.

#### INSTALLATION

Note the following item, and then install in the reverse order of removal.

#### CAUTION:

**When installing, temporarily tighten all fixing bolts, and then tighten fixing bolts to specified torque.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
SE  
K  
L  
M  
N  
O  
P

# CHILD SEAT ANCHOR

< REMOVAL AND INSTALLATION >

---

## ISO FIX BRACKET

### ISO FIX BRACKET : Removal and Installation

INFOID:000000012797254

#### REMOVAL

1. Remove seat back.  
Bench seat: Refer to [SE-101, "SEATBACK : Removal and Installation"](#).  
Separate seat: Refer to [SE-107, "SEATBACK : Removal and Installation"](#).
2. Remove seatback hinge LH/RH (separate seat only). Refer to [SE-111, "SEATBACK HINGE : Removal and Installation"](#).
3. Remove ISO FIX bracket fixing bolt and then remove ISO FIX bracket.

#### INSTALLATION

Install in the reverse order of removal.

# POWER SEAT SWITCH

< REMOVAL AND INSTALLATION >

## POWER SEAT SWITCH

### Removal and Installation

INFOID:000000012797255

#### REMOVAL


**CAUTION:**

When removing and installing, use shop cloths to protect parts from damage.

1. Remove front seat. Refer to [SE-83. "Removal and Installation"](#).
2. Remove seat cushion outside finisher outer side. Refer to [SE-92. "SEAT CUSHION FINISHER : Removal and Installation"](#).
3. Disconnect power seat switch connector.
4. Remove power seat switch mounting screws (A).
5. Remove power seat switch (1) from seat cushion outer finisher (2).

**NOTE:**

The same procedure is also performed for passenger side.



#### INSTALLATION

Install in the reverse order of removal.

**CAUTION:**

Always clamp the harness to the right place.

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE

# LUMBAR SUPPORT SWITCH

< REMOVAL AND INSTALLATION >

## LUMBAR SUPPORT SWITCH

### Removal and Installation


INFOID:000000012797256


#### REMOVAL

##### **CAUTION:**

**When removing and installing, use shop cloths to protect parts from damage.**

1. Remove front seat. Refer to [SE-83. "Removal and Installation"](#).
2. Remove seat cushion outside finisher outer side. Refer to [SE-92. "SEAT CUSHION FINISHER : Removal and Installation"](#).
3. Disconnect the lumbar support switch connector.
4. Disengage the fixing pawls, and then remove lumbar support switch ① from seat cushion outer finisher ②.

 : Pawl



#### INSTALLATION

Install in the reverse order of removal.

##### **CAUTION:**

**Always clamp the harness to the right place.**

# SIDE SUPPORT SWITCH

< REMOVAL AND INSTALLATION >

## SIDE SUPPORT SWITCH

### Removal and Installation


INFOID:000000012797257

#### REMOVAL

**CAUTION:**

**When removing and installing, use shop cloths to protect parts from damage.**

1. Remove front seat. Refer to [SE-83. "Removal and Installation"](#).
2. Remove seat cushion outside finisher outer side. Refer to [SE-92. "SEAT CUSHION FINISHER : Removal and Installation"](#).
3. Disconnect the side support switch connector.
4. Remove the side support switch mounting screws (A).
5. Remove side support switch (1) from the seat cushion outer finisher (2).



#### INSTALLATION

Install in the reverse order of removal.

**CAUTION:**

**Always clamp the harness to the right place.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
K  
L  
M  
N  
O  
P

SE