

SECTION **EXL**

EXTERIOR LIGHTING SYSTEM

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

CONTENTS

<p style="text-align: center;">LED HEADLAMP</p> <p>PRECAUTION 5</p> <p>PRECAUTIONS 5</p> <p style="padding-left: 20px;">Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"5</p> <p style="padding-left: 20px;">Precaution for Procedure without Cowl Top Cover.....5</p> <p style="padding-left: 20px;">Precautions for Removing Battery Terminal6</p> <p>SYSTEM DESCRIPTION 7</p> <p>COMPONENT PARTS 7</p> <p style="padding-left: 20px;">Component Parts Location7</p> <p>FRONT COMBINATION LAMP9</p> <p style="padding-left: 20px;">FRONT COMBINATION LAMP : LED Headlamp.....9</p> <p style="padding-left: 20px;">FRONT COMBINATION LAMP : LED Headlamp Control Module 10</p> <p style="padding-left: 20px;">FRONT COMBINATION LAMP : Swivel Actuator... 10</p> <p style="padding-left: 20px;">FRONT COMBINATION LAMP : Headlamp Aiming Motor 11</p> <p style="padding-left: 20px;">AFS Control Unit 11</p> <p style="padding-left: 20px;">Height Sensor 12</p> <p style="padding-left: 20px;">Optical Sensor 12</p> <p style="padding-left: 20px;">Hazard Switch 12</p> <p style="padding-left: 20px;">AFS Switch 13</p> <p>SYSTEM 14</p> <p>HEADLAMP SYSTEM 14</p> <p style="padding-left: 20px;">HEADLAMP SYSTEM : System Description 14</p> <p style="padding-left: 20px;">HEADLAMP SYSTEM : Fail-safe 15</p> <p>AUTO LIGHT SYSTEM 15</p> <p style="padding-left: 20px;">AUTO LIGHT SYSTEM : System Description 15</p> <p>DAYTIME RUNNING LIGHT SYSTEM 17</p> <p style="padding-left: 20px;">DAYTIME RUNNING LIGHT SYSTEM : System Description 17</p> <p style="padding-left: 20px;">DAYTIME RUNNING LIGHT SYSTEM : Fail-safe... 17</p>	<p>ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM.....17</p> <p style="padding-left: 20px;">ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM : System Description18</p> <p style="padding-left: 20px;">ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM : Fail-safe20</p> <p>TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM20</p> <p style="padding-left: 20px;">TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description21</p> <p>PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM21</p> <p style="padding-left: 20px;">PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description....21</p> <p style="padding-left: 20px;">PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-safe23</p> <p>FRONT FOG LAMP SYSTEM23</p> <p style="padding-left: 20px;">FRONT FOG LAMP SYSTEM : System Description23</p> <p style="padding-left: 20px;">FRONT FOG LAMP SYSTEM : Fail-safe24</p> <p>EXTERIOR LAMP BATTERY SAVER SYSTEM24</p> <p style="padding-left: 20px;">EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description24</p> <p>DIAGNOSIS SYSTEM (BCM) 25</p> <p>COMMON ITEM25</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)25</p> <p>HEADLAMP26</p> <p style="padding-left: 20px;">HEADLAMP : CONSULT Function (BCM - HEAD LAMP)26</p> <p>FLASHER29</p> <p style="padding-left: 20px;">FLASHER : CONSULT Function (BCM - FLASHER)29</p> <p>DIAGNOSIS SYSTEM (IPDM E/R)31</p> <p style="padding-left: 20px;">Diagnosis Description31</p>
---	---

CONSULT Function (IPDM E/R)	33	DTC Description	84
DIAGNOSIS SYSTEM (AFS CONTROL UNIT)	...	Diagnosis Procedure	84
CONSULT Function (ADAPTIVE LIGHT)	36	B2516 SHIFT POSITION SIGNAL [R, P]	87
ECU DIAGNOSIS INFORMATION	38	DTC Description	87
BCM, IPDM E/R	38	Diagnosis Procedure	87
List of ECU Reference	38	B2517 VEHICLE SPEED SIGNAL	88
AFS CONTROL UNIT	39	DTC Description	88
Reference Value	39	Diagnosis Procedure	88
Fail-safe	41	B2519 LEVELIZER CALIBRATION	89
DTC Inspection Priority Chart	42	DTC Description	89
DTC Index	42	Diagnosis Procedure	89
WIRING DIAGRAM	43	B2521 ECU CIRCUIT	90
EXTERIOR LIGHTING SYSTEM	43	DTC Description	90
Wiring Diagram	43	Diagnosis Procedure	90
ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM	63	U0126 STEERING ANGLE SENSOR SIGNAL..	91
Wiring Diagram	63	DTC Description	91
BASIC INSPECTION	71	Diagnosis Procedure	91
DIAGNOSIS AND REPAIR WORK FLOW	71	U0428 STEERING ANGLE SENSOR CALI-	92
Work Flow	71	BRATION	92
LED HEADLAMP OPERATION INSPECTION..	74	DTC Description	92
Work Procedure	74	Diagnosis Procedure	92
ADDITIONAL SERVICE WHEN REPLACING		U1000 CAN COMM CIRCUIT	93
AFS CONTROL UNIT	75	DTC Description	93
Description	75	Diagnosis Procedure	93
Work Procedure	75	U1010 CONTROL UNIT (CAN)	94
CONFIGURATION (AFS CONTROL UNIT)	76	DTC Description	94
Description	76	Diagnosis Procedure	94
Work Procedure	76	POWER SUPPLY AND GROUND CIRCUIT	95
Configuration list	77	AFS CONTROL UNIT	95
SENSOR INITIALIZE	78	AFS CONTROL UNIT : Diagnosis Procedure	95
Description	78	HEADLAMP (HI) CIRCUIT	96
Work Procedure	78	Component Function Check	96
DTC/CIRCUIT DIAGNOSIS	79	Diagnosis Procedure	96
B2008 PARA NOT PROG	79	HEADLAMP (LO) CIRCUIT	98
DTC Description	79	Component Function Check	98
Diagnosis Procedure	79	Diagnosis Procedure	98
B2503 SWIVEL ACTUATOR [RH]	80	LED HEADLAMP	100
DTC Description	80	Diagnosis Procedure	100
Diagnosis Procedure	80	HEADLAMP WARNING	101
B2504 SWIVEL ACTUATOR [LH]	82	Component Function Check	101
DTC Description	82	Diagnosis Procedure	101
Diagnosis Procedure	82	HEADLAMP LEVELIZER CIRCUIT	102
B2514 HEIGHT SENSOR UNUSUAL [RR]	84	Component Function Check	102
		Diagnosis Procedure	102
		PARKING LAMP CIRCUIT	104
		Component Function Check	104
		Diagnosis Procedure	104

TAIL LAMP CIRCUIT	106	FRONT FOG LAMP AIMING ADJUSTMENT .	135	
Component Function Check	106	Description	135	A
Diagnosis Procedure	106	Aiming Adjustment Procedure	135	
LICENSE PLATE LAMP CIRCUIT	109	REMOVAL AND INSTALLATION	137	B
Component Function Check	109	FRONT COMBINATION LAMP	137	
Diagnosis Procedure	109	Exploded View	137	C
DAYTIME RUNNING LIGHT CIRCUIT	111	Removal and Installation	137	
Component Function Check	111	Replacement	138	D
Diagnosis Procedure	111	Disassembly and Assembly	138	
Component Inspection	113	FRONT TURN SIGNAL LAMP ASSEMBLY ...	139	D
FRONT FOG LAMP CIRCUIT	115	Exploded View	139	E
Component Function Check	115	Removal and Installation	139	
Diagnosis Procedure	115	Replacement	139	E
TURN SIGNAL LAMP CIRCUIT	117	FRONT FOG LAMP	141	F
Component Function Check	117	Exploded View	141	
Diagnosis Procedure	117	Removal and Installation	141	F
OPTICAL SENSOR	120	Replacement	141	
Component Function Check	120	SIDE TURN SIGNAL LAMP	143	G
Diagnosis Procedure	120	Exploded View	143	
HAZARD SWITCH	123	Removal and Installation	143	H
Component Function Check	123	Replacement	143	
Diagnosis Procedure	123	OPTICAL SENSOR	144	I
SYMPTOM DIAGNOSIS	125	Exploded View	144	
EXTERIOR LIGHTING SYSTEM SYMPTOMS.	125	Removal and Installation	144	I
Symptom Table	125	LIGHTING AND TURN SIGNAL SWITCH	145	J
NORMAL OPERATING CONDITION	128	Exploded View	145	
Description	128	HAZARD SWITCH	146	K
BOTH SIDE HEADLAMPS (HI) ARE NOT		Exploded View	146	
TURNED ON	129	AFS SWITCH	147	K
Description	129	Exploded View	147	
Diagnosis Procedure	129	Removal and Installation	147	
BOTH SIDE HEADLAMPS (LO) ARE NOT		AFS CONTROL UNIT	148	M
TURNED ON	130	Exploded View	148	
Description	130	Removal and Installation	148	
Diagnosis Procedure	130	STEERING ANGLE SENSOR	149	N
PARKING, LICENSE PLATE, SIDE MARKER		Removal and Installation	149	
AND TAIL LAMPS ARE NOT TURNED ON ...	131	HEIGHT SENSOR	150	O
Description	131	Exploded View	150	
Diagnosis Procedure	131	Removal and Installation	150	
BOTH SIDE FRONT FOG LAMPS ARE NOT		REAR COMBINATION LAMP	151	P
TURNED ON	132	Exploded View	151	
Description	132	REAR COMBINATION LAMP (BODY SIDE)	152	
Diagnosis Procedure	132	REAR COMBINATION LAMP (BODY SIDE) : Re-		
PERIODIC MAINTENANCE	133	removal and Installation	153	
HEADLAMP AIMING ADJUSTMENT	133	REAR COMBINATION LAMP (BODY SIDE) : Re-		
Description	133	placement	153	
Aiming Adjustment Procedure	133	REAR COMBINATION LAMP (TRUNK LID SIDE)..	153	

EXL

REAR COMBINATION LAMP (TRUNK LID SIDE)	Removal and Installation	156
: Removal and Installation	Replacement	156
REAR COMBINATION LAMP (TRUNK LID SIDE)		
: Replacement		154
HIGH-MOUNTED STOP LAMP		155
Exploded View		155
Removal and Installation		155
LICENSE PLATE LAMP		156
Exploded View		156
	SERVICE DATA AND SPECIFICATIONS	
	(SDS)	157
	SERVICE DATA AND SPECIFICATIONS	
	(SDS)	157
	Bulb Specifications	157

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000011256217

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000011517942

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

PRECAUTIONS

[LED HEADLAMP]

< PRECAUTION >

Precautions for Removing Battery Terminal

INFOID:000000011256219

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.




SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000011460128



- A** Front combination lamp (Back)
- B** Engine room (LH)
- C** Rear suspension member (LH)
- D** Behind the instrument driver lower panel
- E** Cluster lid A

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

No.	Component	Function	
①	Optical sensor	Refer to EXL-12, "Optical Sensor" .	
②	IPDM E/R	<ul style="list-style-type: none"> Controls the integrated relay and daytime running light relay, and supplies voltage to the load according to the request from BCM via CAN communication. IPDM E/R transmits low beam status signal to AFS control unit via CAN communication. Refer to PCS-5, "IPDM E/R : Component Parts Location" for detailed installation location. 	
③	Front combination lamp	Headlamp (HI) (LED headlamp)	Refer to EXL-157, "Bulb Specifications" and EXL-9, "FRONT COMBINATION LAMP : LED Headlamp" .
		Headlamp (LO) (LED headlamp)	
		Parking lamp (Upper side) / Daytime running light (Upper side)	Refer to EXL-157, "Bulb Specifications" .
		Parking lamp (Lower side) / Daytime running light (Lower side)	
		Front side marker lamp	
④	Front turn signal lamp	Refer to EXL-157, "Bulb Specifications" .	
⑤	Front fog lamp	Refer to EXL-157, "Bulb Specifications" .	
⑥	BCM	<ul style="list-style-type: none"> Detects each switch condition by the combination switch reading function. Exterior lamp ON/OFF is judged from each signal, and then a request is transmitted to IPDM E/R (via CAN communication) to turn each relay ON/OFF. It also transmits a request to the combination meter (via CAN communication) to turn indicator lamp and warning (buzzer) ON/OFF. Blinks the turn signal lamp and hazard warning lamp according to the each switch condition. Requests the turn signal indicator lamp blink to the combination meter via CAN communication. Requests the turn signal operating sound ON to the combination meter via CAN communication. Refer to BCS-4, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location. 	
⑦	Combination meter	<ul style="list-style-type: none"> Turns the indicator lamp and warning (buzzer) ON/OFF according to the request from BCM via CAN communication. Inputs headlamp warning signal from LED headlamp control module and turns headlamp warning ON. Turns the AFS OFF indicator lamp ON/OFF/Blinking according to the request from AFS control unit via CAN communication. Blinks the turn signal indicator lamp and outputs the turn signal operating sound with integrated buzzer according to the request from BCM via CAN communication. Combination meter transmits vehicle speed signal to BCM, high beam assist control module and AFS control unit via CAN communication. Combination meter transmits parking brake switch signal to BCM via CAN communication. 	
⑧	Combination switch	Refer to BCS-7, "COMBINATION SWITCH READING SYSTEM : System Description" .	
⑨	Steering angle sensor*	<ul style="list-style-type: none"> Steering angle sensor transmits steering angle signal to AFS control unit via CAN communication. Refer to BRC-10, "Component Parts Location" for detailed installation location. 	
⑩	Side turn signal lamp	Refer to EXL-157, "Bulb Specifications" .	
⑪	Door switch	Refer to DLK-12, "DOOR LOCK SYSTEM : Component Description" .	

COMPONENT PARTS

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

No.	Component	Function
⑫	Door request switch	Refer to DLK-12, "DOOR LOCK SYSTEM : Component Description" .
⑬	License plate lamp	Refer to EXL-157, "Bulb Specifications" .
⑭	Rear combination lamp (Trunk lid side)	Tail lamp Refer to EXL-157, "Bulb Specifications" .
⑮	Rear combination lamp (Body side)	Tail lamp
		Rear side marker lamp
		Rear turn signal lamp
⑯	Air bag diagnosis sensor unit	<ul style="list-style-type: none"> Air bag diagnosis sensor unit transmits air bag signal to BCM. Refer to SRC-7, "Component Parts Location" for detailed installation location.
⑰	Transmission assembly*	Transmission range switch Refer to TM-13, "A/T CONTROL SYSTEM : Transmission Range Switch" .
		TCM <ul style="list-style-type: none"> TCM transmits shift position signal to AFS control unit via CAN communication. Refer to TM-11, "A/T CONTROL SYSTEM : Component Parts Location" for detailed installation location.
⑱	Multifunction switch (Hazard switch)	Refer to EXL-12, "Hazard Switch" .
⑲	ECM	<ul style="list-style-type: none"> ECM transmits engine status signal to BCM via CAN communication. ECM transmits engine speed signal to AFS control unit via CAN communication. Refer to EC-24, "ENGINE CONTROL SYSTEM : Component Parts Location" (VQ37VHR engine models) or EC-553, "ENGINE CONTROL SYSTEM : Component Parts Location" (VK56VD engine models).
⑳	Remote keyless entry receiver	Refer to DLK-12, "DOOR LOCK SYSTEM : Component Description" .
㉑	Front combination lamp	Headlamp aiming motor* Refer to EXL-11, "FRONT COMBINATION LAMP : Headlamp Aiming Motor" .
㉒		Swivel actuator* Refer to EXL-10, "FRONT COMBINATION LAMP : Swivel Actuator" .
㉓		LED headlamp control module Refer to EXL-10, "FRONT COMBINATION LAMP : LED Headlamp Control Module" .
㉔	Daytime running light relay	Daytime running light relay is controlled by IPDM E/R and supplies the voltage to daytime running light.
㉕	Height sensor*	Refer to EXL-12, "Height Sensor" .
㉖	AFS control unit*	Refer to EXL-11, "AFS Control Unit" .
㉗	Meter control switch (AFS switch)*	Refer to EXL-13, "AFS Switch" .

*: With active AFS

FRONT COMBINATION LAMP

FRONT COMBINATION LAMP : LED Headlamp

INFOID:000000011460129

OUTLINE

- Semiconductor device (Light emitting diode: LED), which is illuminated when forward bias electric voltage is applied, is adopted as the source of light instead of halogen bulb or xenon bulb.
- Comparing to halogen headlamp or xenon headlamp, LED headlamp is electrically power saving, durable, and is illuminated in the similar color to the sunlight. Bright, natural, and eye-friendly visibility can be obtained.

PRECAUTIONS FOR TROUBLE DIAGNOSIS

Representative malfunction examples are; "Light does not turn ON", "Light blinks", and "Brightness is inadequate." Such malfunctions, however, occasionally occur by LED control module malfunction or lamp case malfunction. Specify the malfunctioning part with diagnosis procedure.

CAUTION:

COMPONENT PARTS

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

- Never touch the harness, LED headlamp control module, the inside and metal part of lamp when turning the headlamp ON or operating the lighting switch, for preventing electrical shock.
- Never work with wet hands, for preventing electrical shock.
- Never perform LED headlamp control module circuit diagnosis with a circuit tester or an equivalent.
- Temporarily install the headlamps on the vehicle. Always connect power supply to the connector (vehicle side) when checking ON/OFF status.
- Disconnect the battery negative terminal before disconnecting the lamp socket connector or the harness connector.
- Check for fusing of the fusible link(s), open around connector, short, disconnection if the symptom is caused by electric error.
- Always check for deformation or hole of headlamp housing and engagement of bulb cover. Otherwise, water may enter into headlamp because of damage of headlamp housing and contact to LED headlamp control module connector. The normal operation may be inhibited when short circuit to power supply is detected.


NOTE:

Turn the switch OFF once before turning ON, if the ON/OFF is inoperative.

FRONT COMBINATION LAMP : LED Headlamp Control Module

INFOID:000000011460130

- LED headlamp control module is integrated in the front combination lamp and turns the LED headlamp ON according to the request from IPDM E/R.
- Outputs the headlamp warning signal to the combination meter.




FRONT COMBINATION LAMP : Swivel Actuator

INFOID:000000011460131

DESCRIPTION

- The swivel actuator is installed in the front combination lamp.
- Swivel actuator consists of the swivel motor for headlamp swivel operation, the swivel position sensor which detects the headlamp swivel angle, and LCU (Local Control Unit) which communicates with AFS control unit via LIN (Local Interconnect Network).



STRICTURE AND OPERATION

Swivel Motor

- The swivel motor is the DC motor.
- The swivel motor drives headlamp according to the drive signal from LCU.

Swivel Position Sensor

The swivel position sensor detects the headlamp swivel angle to transmit the swivel position sensor signal to LCU.

LCU (Local Control Unit)


- The LCU is integrated in left and right swivel actuators so as to perform the multiplex communication control (LIN) between left and right swivel actuators in one communication line.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[LED HEADLAMP]


- When each LCU receives a drive signal from AFS control unit, it drives the swivel motor and allows headlamp swivel operation. Also, it sends the swivel position signal of headlight to AFS control unit, which is detected by the swivel position sensor.



FRONT COMBINATION LAMP : Headlamp Aiming Motor

INFOID:000000011460132

- Headlamp aiming motor is integrated in the front combination lamp.
- Headlamp aiming motor adjusts the headlamp light axis upward and downward according to input drive signal from AFS control unit.




JMLIA4309ZZ

AFS Control Unit

INFOID:000000011460134

- AFS control unit judges the vehicle condition from each signal. AFS control unit controls AFS control (swivel control) and the headlamp aiming control.
- Self-diagnosis function is integrated in AFS control unit. Diagnosis of AFS can be performed quickly. Also, if AFS control unit detects a specific DTC, the AFS control unit requests the combination meter to blink the AFS OFF indicator lamp (via CAN communication).



JMLIA4311ZZ

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

COMPONENT PARTS


< SYSTEM DESCRIPTION >

[LED HEADLAMP]

Height Sensor

INFOID:000000011460136



- Height sensor is installed in rear suspension member (LH).
- Height sensor detects the vehicle rear height deviation with sensor lever, and transmits the detected value as a height sensor signal to AFS control unit.



Optical Sensor

INFOID:000000011460137


Optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.



Hazard Switch

INFOID:000000011460138

Hazard switch ① is built in to the multifunction switch. Inputs the hazard switch ON/OFF signal to BCM.



COMPONENT PARTS


< SYSTEM DESCRIPTION >

[LED HEADLAMP]

AFS Switch

INFOID:000000011540840

AFS switch ① is built in to the meter control switch. Inputs the AFS switch signal to AFS control unit.



A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


SYSTEM

HEADLAMP SYSTEM

HEADLAMP SYSTEM : System Description

INFOID:000000011460139

SYSTEM DIAGRAM



OUTLINE

Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and relay control function of IPDM E/R.

HEADLAMP (LO) OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R with CAN communication according to the headlamp (LO) ON condition.

Headlamp (LO) ON condition

- Lighting switch 2ND
- Lighting switch AUTO (Only when the illumination judgment by auto light system is ON. For details, refer to [EXL-15. "AUTO LIGHT SYSTEM : System Description".](#))
- Lighting switch PASS
- IPDM E/R turns the integrated headlamp low relay ON according to low beam request signal and supplies power supply to LED headlamp control module.
- LED headlamp control module turns the headlamp (LO) ON according to the power supply from IPDM E/R.

HEADLAMP (HI) OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter with CAN communication according to the headlamp (HI) ON condition.

Headlamp (HI) ON condition

- Lighting switch HI with the lighting switch 2ND
- Lighting switch HI with the lighting switch AUTO (Only when the illumination judgment by auto light system is ON. For details, refer to [EXL-15. "AUTO LIGHT SYSTEM : System Description".](#))
- Lighting switch PASS
- IPDM E/R turns the integrated headlamp high relay ON according to high beam request signal and supplies power supply to LED headlamp control module.

SYSTEM

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

- LED headlamp control module turns the headlamp (HI) ON according to the power supply from IPDM E/R.
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.

HEADLAMP WARNING OPERATION

- BCM transmits the low beam request signal to combination meter with CAN communication when headlamp (LO) ON judgment.
- When LED headlamp control module detects a malfunction of headlamp (LO) circuit, headlamp warning signal is output to combination meter.
- When the ignition switch is ON and the low beam request signal is received, if the headlamp warning signal is input, the headlamp warning is displayed on the information display.

NOTE:

When the headlamp warning signal is received, the most likely cause is a malfunction of the following.

- Headlamp (LO) power supply/ground circuit
- Headlamp warning signal circuit
- Front combination lamp
 - LED [Headlamp (LO)]
 - LED headlamp control module
 - Harness

HEADLAMP SYSTEM : Fail-safe

INFOID:000000011460141

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM


Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> • Turns ON the headlamp low relay when the ignition switch is turned ON • Turns OFF the headlamp low relay when the ignition switch is turned OFF • Headlamp high relay OFF

AUTO LIGHT SYSTEM

AUTO LIGHT SYSTEM : System Description

INFOID:000000011460142

SYSTEM DIAGRAM



OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Auto light function [Standard / twilight lighting function (Except for Canada)]

< SYSTEM DESCRIPTION >

- Wiper linked auto lighting function (Except for Canada)
- Fog override function (Factory setting is OFF)
- Delay timer function

Control by IPDM E/R

- Relay control function
- Auto light system has the auto light function [Standard / twilight lighting function (Except for Canada)], wiper linked auto lighting function (Except for Canada), fog override function and delay timer function.
- Auto light function automatically turns ON/OFF the exterior lamps*, depending on the outside brightness.
- Wiper linked auto lighting function automatically turns ON/OFF the exterior lamps* when the lighting switch is in the AUTO position, according to a front wiper operation.
- Fog override function turns ON the exterior lamps regardless of outside brightness, when front fog lamp switch is turned from OFF to ON while ignition switch is in ON position and lighting switch is in AUTO position.

*: Headlamp (LO/HI), front fog lamp, parking lamp, license plate lamp, side marker lamp and tail lamp.

NOTE:

- Headlamp (HI) depend on the combination switch condition.
- Front fog lamp depend on the front fog lamp switch condition (Only when the fog override function setting is OFF).
- Front fog lamp does not turn ON when the headlamp (HI) ON condition.

AUTO LIGHT FUNCTION

For Canada, twilight lighting function is not applicable.

- BCM detects the combination switch condition with the combination switch reading function.
- BCM supplies voltage to the optical sensor when the ignition switch is turned ON.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- When ignition switch is turned ON, BCM detects outside brightness from the optical sensor signal and judges ON/OFF condition of each exterior lamp, depending on the outside brightness condition [standard or twilight (Except for Canada)].
- BCM transmits each request signal to IPDM E/R and combination meter via CAN communication, according to ON/OFF condition by the auto light function.

NOTE:

- ON/OFF of twilight lighting function can be changed using CONSULT. Refer to [EXL-26. "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).
- As to ON/OFF timing, the sensitivity depends on settings. The settings can be changed using CONSULT. Refer to [EXL-26. "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

WIPER LINKED AUTO LIGHTING FUNCTION (EXCEPT FOR CANADA)

BCM turns each exterior lamp ON when detecting 4 operations of the front wiper while the light switch is in AUTO position.

NOTE:

- BCM turns OFF the headlamps 3 seconds after the front wiper switch is turned OFF.
- The setting of the wiper linked auto lighting function can be changed using CONSULT. Refer to [EXL-26. "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

FOG OVERRIDE FUNCTION (FACTORY SETTING IS OFF)

When front fog lamp switch is turned to ON while ignition switch is in ON position and lighting switch is in AUTO position, BCM turns ON exterior lamps* regardless of outside brightness.

*: Headlamp (LO/HI), front fog lamp, parking lamp, license plate lamp, side marker lamp and tail lamp.

NOTE:

- Headlamp (HI) depend on the combination switch condition.
- Front fog lamp does not turn ON when the headlamp (HI) ON condition.
- ON/OFF of fog override function can be changed using CONSULT. Refer to [INL-15. "INT LAMP : CONSULT Function \(BCM - INT LAMP\)"](#).

DELAY TIMER FUNCTION

- BCM turns the headlamp (LO) OFF depending on the vehicle condition with the auto light function when the ignition switch is turned OFF.
- Turns the headlamp (LO) OFF 5 minutes after the ignition switch is turned OFF.
- Turns the headlamp (LO) OFF 5 minutes after detecting that any door opens. (Door switch ON).
- Turns the headlamp (LO) OFF a certain period of time* after closing all doors. (Door switch ON → OFF).
- Delay timer function turns OFF, when the ignition switch is other than OFF or the lighting switch is other than AUTO.

SYSTEM

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

*: The preset time is 45 seconds. The timer operating time can be set by CONSULT. Refer to [EXL-26. "HEAD-LAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

NOTE:


When any position other than the lighting switch AUTO is set, the auto light system switches to the exterior lamp battery saver function.

DAYTIME RUNNING LIGHT SYSTEM

DAYTIME RUNNING LIGHT SYSTEM : System Description

INFOID:000000011460147

SYSTEM DIAGRAM



OUTLINE

Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and relay control function of IPDM E/R.

DAYTIME RUNNING LIGHT OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects vehicle condition depending on the following signals.
 - Engine status signal (received from ECM via CAN communication)
 - Parking brake switch signal (received from combination meter via CAN communication)
- BCM transmits the daytime running light request signal to IPDM E/R via CAN communication according to the daytime running light ON condition.

Daytime running light ON condition

- Engine running with the parking brake released, and any following conditions are satisfied.
 - Lighting switch OFF
 - Lighting switch AUTO (Only when the illumination judgment by auto light system is OFF. For details, refer to [EXL-15. "AUTO LIGHT SYSTEM : System Description"](#).)
- IPDM E/R turns the daytime running light relay ON, and turns the daytime running light ON according to the daytime running light request signal.

DAYTIME RUNNING LIGHT SYSTEM : Fail-safe

INFOID:000000011460149

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM


Control part	Fail-safe operation
Daytime running light	Daytime running light relay OFF

ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM

ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM : System Description

INFOID:000000011460150

SYSTEM DIAGRAM



OUTLINE

- AFS (ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM) is controlled by AFS control unit.
- AFS has AFS control (swivel control) and the headlamp auto aiming control.
 - AFS control swivels the headlamp to the steering direction.
 - Headlamp auto aiming control moves the headlamp light axis up/down according to the vehicle height.

AFS (ADAPTIVE FRONT-LIGHTING SYSTEM)

AFS Control Description

- AFS control unit controls the headlamp when the steering wheel is turned rightward or leftward.
- AFS control unit detects the vehicle condition necessary for AFS control with the following signals.
 - AFS switch signal
 - Engine speed signal (received from ECM via CAN communication)
 - Low beam status signal (received from IPDM E/R via CAN communication)
 - Shift position signal (received from TCM via CAN communication)
 - Vehicle speed signal (received from combination meter via CAN communication)
 - Steering angle sensor signal (received from steering angle sensor via CAN communication)
- When the operation conditions are satisfied, AFS control unit controls the swivel angle depending on the steering angle and the vehicle speed.

AFS operation condition

- AFS ON (AFS OFF indicator lamp OFF)
- Engine running
- Swivel actuator initialization completed
- Headlamp ON
- Selector lever position other than P or R
- Vehicle speed approximately 5 km/h (3.11 MPH) or more
(Left swivel only: Right swivel activates regardless of the vehicle speed.)

NOTE:

Swivel does not operate when the vehicle speed is 200 km/h (124.3 MPH) or more.

Swivel Actuator Initialization

- AFS control unit performs the swivel actuator initialization when detecting that the engine starts.

SYSTEM

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

- Swivels the headlamp to the vehicle-center side until it hits the stopper.
- Returns the swivel angle from the stopper. Completes the initialization with regarding the returned position as the swivel angle 0° (straight-forward position).

Swivel Operation

- AFS control unit transmits the swivel motor drive signal via LIN communication to the swivel actuator when activation conditions are satisfied. And swivels the headlamp.
- The swivel starts after steering angle approximately 5° or more (depending on the vehicle speed) from straight-forward position.
- The swivel angle becomes the maximum angle toward the driving direction if the steering angle is approximately 45.2° or more (depending on the vehicle speed). The swivel angle is maintained by shutting off the swivel motor drive signal.
- The swivel starts, and returns to the swivel angle 0° (straight-forward position) when the steering is returned to the straight-forward position.
- AFS control unit returns the swivel angle to the straight-forward position, and stops the swivel regardless of the steering angle if the operation condition is not satisfied while the swivel angle is not 0°.

AFS OFF indicator Lamp

- AFS control unit transmits AFS OFF indicator lamp signal to the combination meter.
- Combination meter turns AFS OFF indicator lamp ON/OFF/blinking according to AFS OFF indicator lamp signal.
- AFS OFF indicator lamp turns ON when AFS switched to OFF by operating AFS switch.
- AFS OFF indicator blinks (approximately 1 second each) if AFS control unit detects a specific DTC.

NOTE:

- AFS OFF indicator lamp is turned ON for 1 second for the AFS OFF indicator lamp bulb check when the ignition switch is turned ON. AFS OFF indicator lamp is turned OFF within 1 second when the ignition switch ON.
- Combination meter blinks AFS OFF indicator lamp (approximately 1 second each) if AFS OFF indicator lamp signal is not received from AFS control unit.

HEADLAMP AUTO AIMING

Headlamp Auto Aiming Control Description

- AFS control unit controls the headlamp light axis height appropriately according to the vehicle height.
- AFS control unit detects the vehicle condition necessary for headlamp auto aiming control with the following signals.
 - Height sensor signal
 - Engine speed signal (received from ECM via CAN communication)
 - Low beam status signal (received from IPDM E/R via CAN communication)
 - Vehicle speed signal (received from combination meter via CAN communication)
- When the operation conditions are satisfied, AFS control unit transmits the aiming motor drive signal for adjusting the headlamp axis height.

Headlamp auto aiming operation condition

- While the engine running
- Headlamp ON
- Vehicle speed (Control mode is switched according to the driving condition.)

Headlamp Auto Aiming Operation

- AFS control unit calculates the vehicle pitch angle from the height sensor signal. AFS control unit judges the angle for adjusting the axis gap from the preset position.
- AFS control unit controls the headlamp axis by changing the aiming motor drive signal output according to the vehicle-rearward height when detecting the following vehicle condition. Output is maintained if other condition than following is detected.
 - Engine starts
 - Headlamp is turned ON
 - Vehicle posture becomes stable after changing the vehicle posture change is detected with the headlamp ON and the vehicle stopped
 - Vehicle speed is maintained with the headlamp ON and the vehicle driven

NOTE:

Adjusted axis position may differ from the preset position although the headlamp auto aiming activates properly if the suspension is replaced or worn.

SYSTEM

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM : Fail-safe

INFOID:000000011460152


DTC No.	CONSULT screen terms	Fail-safe	
		Swivel operation	Aiming operation
B2008	PARA NOT PROG	Right and left swivel motors stop at the position when DTC is detected	Right and left headlamp aiming motors stop at the position when DTC is detected
B2503	SWIVEL ACTUATOR [RH]	<ul style="list-style-type: none"> Right swivel motor stop at the position when DTC is detected Left swivel motor swivel angle returns to 0° and fixed 	The signal, approximately 2 V decreased from the aiming motor drive signal when DTC detected, is output
	SWIVEL ACTUATOR [RH] COMM ERROR	<ul style="list-style-type: none"> Right swivel motor stop at the position when DTC is detected or right swivel motor swivel angle returns to 0° and fixed Left swivel motor swivel angle returns to 0° and fixed 	
B2504	SWIVEL ACTUATOR [LH]	<ul style="list-style-type: none"> Left swivel motor stop at the position when DTC is detected Right swivel motor swivel angle returns to 0° and fixed 	The signal, approximately 2 V decreased from the aiming motor drive signal when DTC detected, is output
	SWIVEL ACTUATOR [LH] COMM ERROR	<ul style="list-style-type: none"> Left swivel motor stop at the position when DTC is detected or left swivel motor swivel angle returns to 0° and fixed Right swivel motor swivel angle returns to 0° and fixed 	
B2514	HI SEN UNUSUAL [RR]	Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected
B2516	SHIFT POS SIG[R,P]	Right and left swivel motor swivel angle returns to 0° and fixed	—
B2517	VEHICEL SPEED SIG	Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected
B2519	LEVELIZER CALIB	Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors fix at the initial aiming position
B2521	ECU CIRC	Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected
U0126	ST ANG SEN SIG	Right and left swivel motor swivel angle returns to 0° and fixed	—
U0428	ST ANG SEN CALIB	Right and left swivel motor swivel angle returns to 0° and fixed	—
U1000	CAN COMM CIRCUIT	Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected NOTE: Only when the vehicle speed signal or the low beam status signal cannot be received
U1010	CONTROL UNIT(CAN)	Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description

INFOID:000000011460156

SYSTEM DIAGRAM



OUTLINE

Turn signal lamp and hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the ignition switch is ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuits when the hazard switch is ON. BCM blinks the hazard warning lamp.

TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL SOUND OPERATION

- BCM transmits the turn indicator signal to the combination meter via CAN communication while the turn signal lamp and the hazard warning lamp are operating.
- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn indicator signal.

3-TIME FLASHER FUNCTION

- By a short touch of the turn signal lever, BCM blinks the turn signal lamps 3 times in the selected direction.
- Cancels the operation when short touch of the turn signal lever in the reverse direction during the 3-time flasher function operation.

HIGH FLASHER OPERATION

- BCM detects the turn signal lamp circuit status from the current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

NOTE:

The blinking speed is normal while operating the hazard warning lamp.

AUTO HAZARD FUNCTION

- Air bag diagnosis sensor unit transmits air bag signal to BCM, when air bag diagnosis sensor unit detects strong impact to the vehicle body while ignition switch is ON.
- When air bag signal received from air bag diagnosis sensor unit is detected, BCM supplies voltage to each turn signal lamp system and hazard lamp blinks.

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM


PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System De-

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

scription

INFOID:000000011460158

SYSTEM DIAGRAM



OUTLINE

Parking, license plate, side marker and tail lamps are controlled by combination switch reading function and parking, license plate, side marker and tail lamps control function of BCM, and relay control function of IPDM E/R.

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter via CAN communication according to the parking, license plate, side marker and tail lamps ON condition.

Parking, license plate, side marker and tail lamps ON condition (When any of the following conditions are satisfied)

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO (Only when the illumination judgment by auto light system is ON. For details, refer to [EXL-15. "AUTO LIGHT SYSTEM : System Description"](#).)
- IPDM E/R turns the integrated tail lamp relay ON and turns the parking, license plate, side marker and tail lamps ON according to the position light request signal.
- Combination meter turns the position lamp indicator lamp ON according to the position light request signal.

NOTE:

Parking lamp (Upper side / Lower side) and daytime running light (Upper side / Lower side) use a common light source. When the parking, license plate, side marker and tail lamps are turned ON while daytime running light is ON, the parking lamp (Lower side) / daytime running light (Lower side) is dimmed.

SIGNATURE LIGHT FUNCTION

Description

The signature light function is a function that turns ON the parking lamp, license plate lamp, side marker lamp and tail lamp for a set period of time when the doors are locked or unlocked from outside the vehicle.

Operation Description

BCM transmits the position light request signal to IPDM E/R and the combination meter via CAN communication according to the signature light function ON condition.

Signature light function operating condition (Operation when doors are unlocked)

- When all of the following conditions are satisfied, the signature light function operates when door unlock operation is performed from outside the vehicle (Intelligent Key or door request switch).
 - Ignition switch: OFF
 - Door open/close status: All door close
 - Door lock status: All door lock
- When any of the following conditions is satisfied while the signature light function is operating, the signature light function stops.

SYSTEM

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

- Ignition switch: ON
- Since signature light function ON, approx. 30 seconds are passed.
- When door lock operation is performed from outside the vehicle (Intelligent Key or door request switch) while the signature light function is operating, the system changes to operation when doors are locked.

Signature light function operating condition (Operation when doors are locked)

- When all of the following conditions are satisfied, the signature light function operates when door lock operation is performed from outside the vehicle (Intelligent Key or door request switch).
- Ignition switch: OFF
- Door open/close status: All door close
- Door lock status: All door unlock
- When any of the following conditions is satisfied while the signature light function is operating, the signature light function stops.
- Ignition switch: ON
- Since signature light function ON, approx. 10 seconds are passed.
- When door unlock operation is performed from outside the vehicle (Intelligent Key or door request switch) while the signature light function is operating, the system changes to operation when doors are unlocked.

NOTE:

ON/OFF of signature light function can be changed using CONSULT. Refer to [DLK-36, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-safe

INFOID:000000011460160

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM


Control part	Fail-safe operation
<ul style="list-style-type: none"> • Parking lamp • License plate lamp • Side marker lamp • Tail lamp 	<ul style="list-style-type: none"> • Turns ON the tail lamp relay when the ignition switch is turned ON • Turns OFF the tail lamp relay when the ignition switch is turned OFF

FRONT FOG LAMP SYSTEM

FRONT FOG LAMP SYSTEM : System Description

INFOID:000000011460165

SYSTEM DIAGRAM



OUTLINE

Front fog lamp is controlled by combination switch reading function and front fog lamp control function of BCM, and relay control function of IPDM E/R.

FRONT FOG LAMP OPERATION

SYSTEM

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front fog light request signal to IPDM E/R and the combination meter via CAN communication according to the front fog lamp ON condition.

Front fog lamp ON condition

- Front fog lamp switch ON, and any of the following conditions are satisfied. [Except headlamp (HI) ON condition]
- Lighting switch 2ND
- Lighting switch AUTO (Only when the illumination judgment by auto light system is ON. For details, refer to [EXL-15, "AUTO LIGHT SYSTEM : System Description"](#).)
- IPDM E/R turns the integrated front fog lamp relay ON, and turns the front fog lamp ON according to the front fog light request signal.
- Combination meter turns the front fog lamp indicator lamp ON according to the front fog light request signal.

FRONT FOG LAMP SYSTEM : Fail-safe

INFOID:000000011460167

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With BCM


Control part	Fail-safe operation
Front fog lamp	Front fog lamp relay OFF

EXTERIOR LAMP BATTERY SAVER SYSTEM

EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000011460170

SYSTEM DIAGRAM



OUTLINE

- Exterior lamp battery saver system is controlled by combination switch reading function and exterior lamp battery saver function of BCM, and relay control function of IPDM E/R.
- BCM turns the exterior lamp* OFF, according to the vehicle status when ignition switch is turned OFF while exterior lamp is ON, for preventing battery discharge.

*: Headlamp (LO/HI), front fog lamp, parking lamp, license plate lamp, side marker lamp and tail lamp

EXTERIOR LAMP BATTERY SAVER ACTIVATION

- BCM activates the timer and turns the exterior lamp OFF 45 seconds after the ignition switch is turned from ON→OFF with the exterior lamps ON.
- When in any of following conditions (after the exterior lamp battery saver is activated), exterior lamps can be turned ON.
 - Ignition switch is turned from OFF→ON
 - Lighting switch is changed
 - Front fog lamp switch is changed

DIAGNOSIS SYSTEM (BCM)

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000011460362

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM.

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
—	AIR CONDITONER*		×	×
<ul style="list-style-type: none"> Intelligent Key system Engine start system 	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
IVIS - NATS	IMMU	×	×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Trunk lid open	TRUNK		×	
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
—	AIR PRESSURE MONITOR*	×	×	×

*: This item is not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

DIAGNOSIS SYSTEM (BCM)

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description	
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected	
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected	
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected*	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*)
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC		While turning power supply position from "LOCK" *to "ACC"
	ACC>ON		While turning power supply position from "ACC" to "IGN"
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF		While turning power supply position from "ACC" to "OFF"
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"*
	OFF>ACC		While turning power supply position from "OFF" to "ACC"
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK"*.) to low power consumption mode
	LOCK		Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)*
	OFF		Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
	ACC		Power supply position is "ACC" (Ignition switch ACC)
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)
ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)		
CRANKING	Power supply position is "CRANKING" (At engine cranking)		
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. 	

NOTE:

*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)

INFOID:0000000011460179

WORK SUPPORT

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

Service item	Setting item	Setting
CUSTOM A/LIGHT SETTING	MODE1* ²	Normal
	MODE2	More sensitive setting than normal setting (Turns ON earlier than normal operation)
	MODE3	More sensitive setting than MODE2 (Turns ON earlier than MODE2)
	MODE4	Less sensitive setting than normal setting (Turns ON later than normal operation)
BATTERY SAVER SET	On* ²	With the exterior lamp battery saver function
	Off	Without the exterior lamp battery saver function
ILL DELAY SET	MODE1* ²	45 sec.
	MODE2	Without the function
	MODE3	30 sec.
	MODE4	60 sec.
	MODE5	90 sec.
	MODE6	120 sec.
	MODE7	150 sec.
	MODE8	180 sec.
		Sets delay timer function timer operation time. (All doors closed)
AUTO LIGHT LOGIC SET* ¹	MODE1* ²	With twilight ON custom & with wiper INT, LO and HI
	MODE2	With twilight ON custom & with wiper LO and HI
	MODE3	With twilight ON custom & without
	MODE4	Without twilight ON custom & with wiper INT, LO and HI
	MODE5	Without twilight ON custom & with wiper LO and HI
	MODE6	Without twilight ON custom & without

*¹: For models for Canada, this item cannot be used.

*²: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
ENGINE STATE [STOP/STALL/CRANK/RUN]	Indicates [STOP/STALL/CRANK/RUN] condition of engine states
VEH SPEED 1 [km/h]	Display the vehicle speed signal received from combination meter by numerical value [km/h]

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

DIAGNOSIS SYSTEM (BCM)

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

Monitor item [Unit]	Description
TURN SIGNAL R [On/Off]	Each switch status that BCM judges from the combination switch reading function
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW 1 [On/Off]	
HEAD LAMP SW 2 [On/Off]	
PASSING SW [On/Off]	
AUTO LIGHT SW [On/Off]	
FR FOG SW [On/Off]	
RR FOG SW [On/Off]	NOTE: This item cannot be monitored
DOOR SW-DR [On/Off]	Indicated [On/Off] condition of front door switch (driver side)
DOOR SW-AS [On/Off]	Indicated [On/Off] condition of front door switch (passenger side)
DOOR SW-RR [On/Off]	Indicated [On/Off] condition of rear door switch RH
DOOR SW-RL [On/Off]	Indicated [On/Off] condition of rear door switch LH
DOOR SW-BK [On/Off]	NOTE: This item cannot be monitored
OPTI SEN (DTCT) [V]	The value of outside brightness voltage input from the optical sensor
OPTI SEN (FILT)* [V]	The value of outside brightness voltage filtered by BCM
OPTICAL SENSOR [On/Off/NG]	NOTE: This item cannot be monitored

*: For models for Canada, this item cannot be monitored.

ACTIVE TEST

Test item	Operation	Description
TAIL LAMP	On	<ul style="list-style-type: none"> • Transmits the position light request signal to IPDM E/R via CAN communication to turn the parking, license plate, side marker and tail lamps ON • Transmits the position light request signal to combination meter via CAN communication to turn the position lamp indicator lamp ON
	Off	Stops the position light request signal transmission
HEAD LAMP	HI	<ul style="list-style-type: none"> • Transmits the high beam request signal to IPDM E/R via CAN communication to turn the headlamp (HI) ON • Transmits the high beam request signal to combination meter via CAN communication to turn the high beam indicator lamp ON
	Low	Transmits the low beam request signal to IPDM E/R via CAN communication to turn the headlamp (LO) ON
	Off	Stops the high beam request signal and low beam request signal transmission

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

Test item	Operation	Description
FR FOG LAMP	On	<ul style="list-style-type: none"> Transmits the front fog light request signal to IPDM E/R via CAN communication to turn the front fog lamp ON Transmits the front fog light request signal to combination meter via CAN communication to turn the front fog lamp indicator lamp ON
	Off	Stops the front fog light request signal transmission
RR FOG LAMP	On	NOTE: This item cannot be tested
	Off	
DAYTIME RUNNING LIGHT	On	Transmits the daytime running light request signal via CAN communication to turn the daytime running light ON
	Off	Stops the daytime running light request signal transmission
ILL DIM SIGNAL	On	<ul style="list-style-type: none"> Transmits the dimmer signal to combination meter via CAN communication and dims combination meter Transmits the dimmer signal to AV control unit and dims display
	Off	Stops the dimmer signal transmission

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000011460180

WORK SUPPORT

Service item	Setting item	Setting	
HAZARD ANSWER BACK	Lock Only	With locking only	Sets the hazard warning lamp answer back function when the door is lock/unlock with the door request switch and Intelligent Key
	Unlock Only	With unlocking only	
	Lock/Unlock*	With locking/unlocking	
	Off	Without the function	

*: Factory setting

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Unit]	Description
REQ SW -DR [On/Off]	Indicates [On/Off] condition of door request switch (driver side)
REQ SW -AS [On/Off]	Indicates [On/Off] condition of door request switch (passenger side)
PUSH SW [On/Off]	Indicates [On/Off] condition of push-button ignition switch
TURN SIGNAL R [On/Off]	Each switch status that BCM detects from the combination switch reading function
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	The switch status input from the hazard switch
RKE-LOCK [On/Off]	Indicates [On/Off] condition of LOCK signal from Intelligent Key

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

Monitor item [Unit]	Description
RKE-UNLOCK [On/Off]	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-PANIC [On/Off]	Indicates [On/Off] condition of PANIC button of Intelligent Key

ACTIVE TEST

Test item	Operation	Description
FLASHER	RH	<ul style="list-style-type: none">• Outputs voltage to turn the right side turn signal lamps ON• Transmits the turn indicator signal to combination meter via CAN communication to turn the turn signal indicator lamp (RH) ON
	LH	<ul style="list-style-type: none">• Outputs voltage to turn the left side turn signal lamps ON• Transmits the turn indicator signal to combination meter via CAN communication to turn the turn signal indicator lamp (LH) ON
	Off	<ul style="list-style-type: none">• Stops the voltage to turn the turn signal lamps OFF• Stops the turn indicator signal transmission

DIAGNOSIS SYSTEM (IPDM E/R)

Diagnosis Description

INFOID:000000011460363

AUTO ACTIVE TEST

Description

In auto active test, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp (only for models with VQ37VHR engine)
- Front wiper (LO, HI)
- Parking lamp
- License plate lamp
- Tail lamp
- Side marker lamp
- Front fog lamp
- Headlamp (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan (cooling fan control module)

Operation Procedure

CAUTION:

Wiper arm interferes with hood when wiper is operated while wiper arm is in the raised position. Always perform auto active test without setting wiper arm in the raised position. Always pour water on front windshield glass in advance to auto active test so that damage on front windshield glass surface is prevented.

NOTE:

Never perform auto active test in the following condition.

- Engine is running
 - CONSULT is connected
1. Turn the ignition switch OFF.
 2. Turn the ignition switch ON, and within 20 seconds, press the front door switch (driver side) 10 times. Then turn the ignition switch OFF.

NOTE:

- Close passenger door.
- Within 5 seconds after ignition switch is turned to the ON position and when driver door switch is pressed 6 times or more within 4 seconds, self-diagnosis function for BOSE amp. activates and speaker sounds. After waiting for 5 seconds or more after ignition switch is turned to the ON position and when driver door switch is operated, self-diagnosis function for BOSE amp. does not activate.

3. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.

NOTE:

Engine starts when ignition switch is turned ON while brake pedal is depressed.

4. The oil pressure warning lamp starts blinking when the auto active test starts.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

NOTE:

- When auto active test has to be cancelled halfway through test, turn the ignition switch OFF.
- When auto active test is not activated, door switch may be the cause. Check door switch. Refer to [DLK-87, "Component Function Check"](#).

Inspection in Auto Active Test

When auto active test is actuated, the following 6 steps are repeated 3 times.

Operation sequence	Inspection location	Operation
1	Oil pressure warning lamp (only for models with VQ37VHR engine)	Blinks continuously during operation of auto active test
2	Front wiper motor	LO for 5 seconds → HI for 5 seconds

DIAGNOSIS SYSTEM (IPDM E/R)


[LED HEADLAMP]

< SYSTEM DESCRIPTION >

Operation sequence	Inspection location	Operation
3	<ul style="list-style-type: none"> • Parking lamp • License plate lamp • Tail lamp • Side marker lamp • Front fog lamp 	10 seconds
4	Headlamp	<ul style="list-style-type: none"> • LO 10 seconds • HI ON ⇔ OFF 5 times
5	A/C compressor (magnet clutch)	ON ⇔ OFF 5 times
6	Cooling fan	MID for 5 seconds → HI for 5 seconds

*: Outputs duty ratio of 50% for 5 seconds → duty ratio of 100% for 5 seconds on the cooling fan control module.

Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

Diagnosis chart in auto active test

Symptom	Inspection contents	Possible cause
Any of the following components do not operate <ul style="list-style-type: none"> • Parking lamp • License plate lamp • Tail lamp • Side marker lamp • Front fog lamp • Headlamp (HI, LO) • Front wiper motor 	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> • Lamp or motor • Lamp or motor ground circuit • Harness or connector between IPDM E/R and applicable system • IPDM E/R
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES <ul style="list-style-type: none"> • Combination meter signal input circuit • CAN communication signal between Combination meter and ECM • CAN communication signal between ECM and IPDM E/R
		NO <ul style="list-style-type: none"> • Magnet clutch • Harness or connector between IPDM E/R and magnet clutch • IPDM E/R

DIAGNOSIS SYSTEM (IPDM E/R)

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

Symptom	Inspection contents	Possible cause
Oil pressure warning lamp does not operate (only for models with VQ37VHR engine)	Perform auto active test. Does the oil pressure warning lamp blink?	YES <ul style="list-style-type: none"> • Harness or connector between IPDM E/R and oil pressure switch • Oil pressure switch • IPDM E/R
		NO <ul style="list-style-type: none"> • CAN communication signal between IPDM E/R and BCM • CAN communication signal between BCM and Combination meter • Combination meter
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES <ul style="list-style-type: none"> • ECM signal input circuit • CAN communication signal between ECM and IPDM E/R
		NO <ul style="list-style-type: none"> • Cooling fan • Harness or connector between cooling fan and cooling fan control module • Cooling fan control module • Harness or connector between IPDM E/R and cooling fan control module • Cooling fan relay • Harness or connector between IPDM E/R and cooling fan relay • IPDM E/R

CONSULT Function (IPDM E/R)

INFOID:000000011460364

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

SELF DIAGNOSTIC RESULT

Refer to [PCS-24, "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item [Unit]	MAIN SIGNALS	Description
RAD FAN REQ [%]	×	Displays the value of the cooling fan speed signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.

DIAGNOSIS SYSTEM (IPDM E/R)

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	MAIN SIG- NALS	Description
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper stop position signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the shift position judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INHI RLY [Off/ ST /INHI/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the A/T shift selector (detention switch) judged by IPDM E/R.
S/L RLY -REQ [Off/On]		NOTE: This item is indicated, but not monitored.
S/L STATE [LOCK/UNLOCK/UNKWN]		NOTE: This item is indicated, but not monitored.
DTRL REQ [Off/On]		Displays the status of the daytime running light request signal received from BCM via CAN communication. NOTE: This item is monitored only on the vehicle with daytime running light system.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
HOOD SW [Off/On]		Displays the status of the hood switch judged by IPDM E/R.
HL WASHER REQ [Off/On]		NOTE: This item is indicated, but not monitored.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn reminder signal received from BCM via CAN communication.
CRNRNG LMP REQ [Off/On]		NOTE: This item is indicated, but not monitored.

ACTIVE TEST

Test item

Test item	Operation	Description
CORNERING LAMP	Off	NOTE: This item is indicated, but cannot be tested.
	LH	
	RH	

DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

Test item	Operation	Description
HORN	On	Operates horn relay for 20 ms.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.
MOTOR FAN	1	OFF
	2	Transmits 50% pulse duty signal (PWM signal) to the cooling fan control module.
	3	Transmits 75% pulse duty signal (PWM signal) to the cooling fan control module.
	4	Transmits 100% pulse duty signal (PWM signal) to the cooling fan control module.
HEAD LAMP WASHER	On	NOTE: This item is indicated, but cannot be tested.
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay and the daytime running light relay.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	Operates the front fog lamp relay.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

DIAGNOSIS SYSTEM (AFS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

DIAGNOSIS SYSTEM (AFS CONTROL UNIT)

CONSULT Function (ADAPTIVE LIGHT)

INFOID:000000011460187

APPLICATION ITEMS

Diagnosis mode	Description
ECU Identification	Allows confirmation of AFS control unit part number
Self Diagnostic Result	Displays the diagnosis results judged by AFS control unit
Work Support	Performs settings on sensors.
Data Monitor	Displays input/output data for AFS control unit in real time
Active Test	Transmits a drive signal to the load to check their operation
Configuration	Writes the vehicle specification when replacing AFS control unit

ECU IDENTIFICATION

Part number of AFS control unit can be checked.

SELF DIAGNOSTIC RESULT

Self Diagnostic Item

Self diagnostic result that is judged by AFS control unit can be checked. Refer to [EXL-42, "DTC Index"](#).

- When "CRNT" is displayed on self diagnostic result, the system is presently malfunctioning.
- When "PAST" is displayed on self diagnostic result, system malfunction in the past is detected, but the system is presently normal.

FFD (Freeze Frame Data)

The AFS control unit records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

Monitor item [Unit]	Description
ODO/TRIP METER [km]	Total mileage (Odometer value) of the moment a particular DTC is detected

WORK SUPPORT

Work item	Description
ST ANG SEN ADJUSTMENT*	—
LEVELIZER ADJUSTMENT	Adjusts the height sensor signal output value (AFS control unit recognized) in the unloaded vehicle condition

*: This function is not necessary in the usual service procedure.

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item [Value/Unit]	Description
STR ANGLE SIG [°]	The steering angle value judged by the steering angle sensor signal received from the steering angle sensor via CAN communication
VHCL SPD [km/h]	The vehicle speed signal value from the combination meter via CAN communication
SLCT LVR POSI [P/R/N/D/M]	The selector lever status judged by the shift position signal received from TCM via CAN communication
HEAD LAMP [On/Off]	The headlamp ON/OFF status judged by the low beam status signal received from IPDM E/R via CAN communication

DIAGNOSIS SYSTEM (AFS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

Monitor item [Value/Unit]	Description
AFS SW [On/Off]	The AFS ON/OFF status by AFS switch operation
REVERSE SW [On/Off]	NOTE: This item is displayed, but cannot be monitored
HI SEN OTP RR [V]	The height sensor signal voltage value input from the height sensor
HI SEN OTP FR [V]	NOTE: This item is displayed, but cannot be monitored
LEV ACTR VLTG [%]	The ratio value to the battery voltage generated by the aiming motor signal control value judged by AFS control unit
SWVL SEN LH [°]	The headlamp swivel angle value judged by AFS control unit according to the swivel position sensor signal received from the swivel actuator via LIN communication
SWVL SEN RH [°]	
SWVL ANGLE LH [°]	The swivel angle command value to the swivel motor judged by AFS control unit
SWVL ANGLE RH [°]	
HI SEN INI RR [V]	Height sensor signal voltage value at height sensor initialization
HI SEN INI FR [V]	NOTE: This item is displayed, but cannot be monitored
PINION ANGLE [°]	NOTE: This item is displayed, but cannot be monitored

ACTIVE TEST

Test item	Operation	Description
LOW BEAM TEST RIGHT	Stop	Swivels the right headlamp to the swivel angle 0°
	Peak	Swivels the right headlamp to the swivel angle approximately 15°
	Origin	Swivels the right headlamp to the swivel angle 0°
LOW BEAM TEST LEFT	Stop	Swivels the left headlamp to the swivel angle 0°
	Peak	Swivels the left headlamp to the swivel angle approximately 15°
	Origin	Swivels the left headlamp to the swivel angle 0°
LEVELIZER TEST	Stop	Moves the headlamp axis to the initial position
	Peak	Moves the headlamp axis to the lowest position
	Origin	Moves the headlamp axis to the initial position

CONFIGURATION

The vehicle specification can be written when AFS control unit is replaced. Refer to [EXL-76. "Description"](#).

ECU DIAGNOSIS INFORMATION

BCM, IPDM E/R

List of ECU Reference

INFOID:000000011460189

ECU	Reference
BCM	BCS-33, "Reference Value"
	BCS-53, "Fail-safe"
	BCS-54, "DTC Inspection Priority Chart"
	BCS-55, "DTC Index"
IPDM E/R	PCS-16, "Reference Value"
	PCS-23, "Fail-safe"
	PCS-24, "DTC Index"

AFS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LED HEADLAMP]

AFS CONTROL UNIT

Reference Value

INFOID:0000000011460194

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT MONITOR ITEM

Monitor Item	Condition		Value/Status
STR ANGLE SIG	Steering	Straight-forward	Approx. 0°
		Steering	(-756°) - (756°)
VHCL SPD	Driving at 40 km/h (25 MPH)		40 km/h
SLCT LVR POSI	Selector lever operation	P/R/N/D	P/R/N/D
		Manual shift gate side	M
HEAD LAMP	Headlamp	ON	On
		OFF	Off
AFS SW	AFS switch	ON	On
		OFF	Off
REVERSE SW	NOTE: This item is displayed, but cannot be monitored		
HI SEN OTP RR	Vehicle rear height	Unloaded vehicle condition	Approx. 2.94 V
		Low	Voltage decreases from the unladen status
HI SEN OTP FR	NOTE: This item is displayed, but cannot be monitored		
LEV ACTR VLTG	Headlamp leveling	Unloaded vehicle condition	Approx. 20.0%
		Low	Value increases from the unladen status
SWVL SEN LH	Left headlamp swivel activation	Standard position	Approx. 0°
		Activation	Positive degree (+°)
SWVL SEN RH	Right headlamp swivel activation	Standard position	Approx. 0°
		Activation	Positive degree (+°)
SWVL ANGLE LH	Left headlamp swivel activation	Standard position	Approx. 0°
		Activation	Positive degree (+°)
SWVL ANGLE RH	Right headlamp swivel activation	Standard position	Approx. 0°
		Activation	Positive degree (+°)
HI SEN INI RR	Ignition switch ON		Approx. 2.94 V
HI SEN INI FR	NOTE: This item is displayed, but cannot be monitored		
PINION ANGLE	NOTE: This item is displayed, but cannot be monitored		


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

AFS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LED HEADLAMP]

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ output			
1 (L)	Ground	CAN-H	Input/ output	—		—
3 (GR)	Ground	AFS switch signal	Input	Ignition switch ON	AFS switch ON	9 – 16 V
					AFS switch OFF	0 V
6 (Y)	Ground	Height sensor signal	Input	Vehicle rear height	Unloaded vehicle condition	2.94 V
					Low	Voltage decreases from the un- laden status
8 (Y)	Ground	Swivel actuator LIN signal	Input/ output	Ignition switch ON		<p style="text-align: right; font-size: x-small;">JMLIA4324GB</p>
11 (B)	Ground	Ground	—	Ignition switch ON		0 V
12 (G)	Ground	Ignition power supply	Input	Ignition switch ON		9 – 16 V
13 (P)	Ground	CAN-L	Input/ output	—		—
19 (BR)	Ground	Swivel actuator ground	Input	Ignition switch ON		0 V
21 (V)	Ground	Height sensor power supply	Output	Ignition switch ON		4.45 – 6.25 V
22 (SB)	Ground	Aiming motor drive signal	Output	Headlamp lev- eling	Unloaded vehicle condition	2.5 V
					Low	Voltage increases from the un- laden status
23 (LG)	Ground	Height sensor ground	Input	Ignition switch ON		0 V
24 (B)	Ground	Aiming motor ground	Input	Ignition switch ON		0 V

AFS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LED HEADLAMP]

Fail-safe

INFOID:000000011460195

DTC No.	CONSULT screen terms	Fail-safe	
		Swivel operation	Aiming operation
B2008	PARA NOT PROG	Right and left swivel motors stop at the position when DTC is detected	Right and left headlamp aiming motors stop at the position when DTC is detected
B2503	SWIVEL ACTUATOR [RH]	<ul style="list-style-type: none"> Right swivel motor stop at the position when DTC is detected Left swivel motor swivel angle returns to 0° and fixed 	The signal, approximately 2 V decreased from the aiming motor drive signal when DTC detected, is output
	SWIVEL ACTUATOR [RH] COMM ERROR	<ul style="list-style-type: none"> Right swivel motor stop at the position when DTC is detected or right swivel motor swivel angle returns to 0° and fixed Left swivel motor swivel angle returns to 0° and fixed 	
B2504	SWIVEL ACTUATOR [LH]	<ul style="list-style-type: none"> Left swivel motor stop at the position when DTC is detected Right swivel motor swivel angle returns to 0° and fixed 	The signal, approximately 2 V decreased from the aiming motor drive signal when DTC detected, is output
	SWIVEL ACTUATOR [LH] COMM ERROR	<ul style="list-style-type: none"> Left swivel motor stop at the position when DTC is detected or left swivel motor swivel angle returns to 0° and fixed Right swivel motor swivel angle returns to 0° and fixed 	
B2514	HI SEN UNUSUAL [RR]	Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected
B2516	SHIFT POS SIG[R,P]	Right and left swivel motor swivel angle returns to 0° and fixed	—
B2517	VEHICEL SPEED SIG	Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected
B2519	LEVELIZER CALIB	Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors fix at the initial aiming position
B2521	ECU CIRC	Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected
U0126	ST ANG SEN SIG	Right and left swivel motor swivel angle returns to 0° and fixed	—
U0428	ST ANG SEN CALIB	Right and left swivel motor swivel angle returns to 0° and fixed	—
U1000	CAN COMM CIRCUIT	Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected NOTE: Only when the vehicle speed signal or the low beam status signal cannot be received
U1010	CONTROL UNIT(CAN)	Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

AFS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[LED HEADLAMP]

DTC Inspection Priority Chart

INFOID:000000011460196

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	DTC No.	CONSULT screen terms
1	U1000	CAN COMM CIRCUIT
	U1010	CONTROL UNIT(CAN)
2	B2008	PARA NOT PROG
	B2519	LEVELIZER CALIB
	B2521	ECU CIRC
	U0428	ST ANG SEN CALIB
3	B2503	SWIVEL ACTUATOR [RH]
		SWIVEL ACTUATOR [RH] COMM ERROR
	B2504	SWIVEL ACTUATOR [LH]
		SWIVEL ACTUATOR [LH] COMM ERROR
	B2514	HI SEN UNUSUAL [RR]
	B2516	SHIFT POS SIG[R,P]
	B2517	VEHICEL SPEED SIG
	U0126	ST ANG SEN SIG

DTC Index

INFOID:000000011460197

×: Applicable

DTC No.	CONSULT screen terms	Fail-safe	AFS OFF indicator lamp	Reference
B2008	PARA NOT PROG	×	×	EXL-79, "DTC Description"
B2503	SWIVEL ACTUATOR [RH]	×	×	EXL-80, "DTC Description"
	SWIVEL ACTUATOR [RH] COMM ERROR	×	×	
B2504	SWIVEL ACTUATOR [LH]	×	×	EXL-82, "DTC Description"
	SWIVEL ACTUATOR [LH] COMM ERROR	×	×	
B2514	HI SEN UNUSUAL [RR]	×	—	EXL-84, "DTC Description"
B2516	SHIFT POS SIG[R,P]	×	—	EXL-87, "DTC Description"
B2517	VEHICEL SPEED SIG	×	—	EXL-88, "DTC Description"
B2519	LEVELIZER CALIB	×	—	EXL-89, "DTC Description"
B2521	ECU CIRC	×	—	EXL-90, "DTC Description"
U0126	ST ANG SEN SIG	×	—	EXL-91, "DTC Description"
U0428	ST AND SEN CALIB	×	—	EXL-92, "DTC Description"
U1000	CAN COMM CIRCUIT	×	—	EXL-93, "DTC Description"
U1010	CONTROL UNIT(CAN)	×	—	EXL-94, "DTC Description"

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

WIRING DIAGRAM

EXTERIOR LIGHTING SYSTEM

Wiring Diagram

INFOID:000000011460202



2014/07/11

JRLWE0277GB


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM

[LED HEADLAMP]

< WIRING DIAGRAM >




A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]



A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P


EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4




Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	W	-
4	LG	-
5	P	-
7	GR	-
8	Y	-
9	LG	-
10	V	-
11	GR	- [With climate controlled seat]
11	L	- [With heated seat]
12	GR	- [With climate controlled seat]
12	P	- [With climate controlled seat]
13	BR	-
14	R	-
15	O	-
16	V	-
17	B	-
18	R	-
19	W	-
20	L	-
21	B	-
22	LG	-
23	V	-
24	Y	-
25	G	-
26	GR	-
27	SB	-
28	L/O	-
29	W/L	-
30	SHIELD	-
32	L	-
33	R	-
34	C	-
35	SHIELD	-
36	G	-

37	SB	-
40	SHIELD	-
41	GR/V	-
42	W/L	-
43	L	-
44	B	-
45	V	-
46	P	-
47	O	-
48	Y	-
49	BR	-
50	SB	-
51	V	-
52	LG	-
53	G	-
55	G	-
56	P	-
57	BR	-
58	LG	-
59	Y	-
60	W	-
61	B	-
62	LG	-
63	V	-
65	O	-
66	BR	-
67	V	-
68	LG	-
69	GR	-
70	R	-
72	L	-
73	P	-
74	L	-
75	P	-
76	Y	-
77	R	-
78	W	-
79	G	-
81	LG	-
82	BR	-
83	SB	-
84	Y	-
85	W	-
86	R	-
87	G	-
88	GR	-
91	SB	-
92	G	-
96	Y	-

97	O	-
98	SB	-
99	LG	-


Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	GR	-
3	B	-
4	L	-
5	BRW	-
6	L	-
7	R	-
8	B	-
9	W	-
10	LG	-
11	P	-
12	GR	-
13	BRW	-
14	SB	-
15	O	-
16	G	-
17	Y	-
18	BR	-
19	GR	-
20	O	-
21	LG	-
22	L	-
23	SB	-
24	V	-
25	W/L	-
26	L/O	-
27	V	-
28	W	-
29	SB	-
30	L	-

31	LG	-
32	O	-
33	V	-
34	BR	-
35	BR	-
36	P	-
37	BR	-
38	W	-
39	O	-
40	L	-
41	W	-
42	B	-
43	R	-
44	G	-
45	Y	-
46	V	-
47	SB	-
48	GR	-
49	LG	-
50	B	-
51	G	-
52	R	-
53	B	-
54	V	-
55	SHIELD	-

Connector No.	B6
Connector Name	FUSE BLOCK (JIB)
Connector Type	INS12FBRCS



Terminal No.	Color Of Wire	Signal Name [Specification]
10G	W	-
11G	W	-
12G	GR	-
1G	GR	-
2G	GR	-
4G	L	-
6G	PL	-
6G	G	-

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM

Connector No.	B8
Connector Name	WIPE TO WIRE
Connector Type	NS12FW-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
3	O	-
4	Y	-
5	Y	-
8	LG	-
10	W	-
11	G	-
12	SB	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH LH
Connector Type	A03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
2	LG	-

Connector No.	B23
Connector Name	REAR DOOR SWITCH LH
Connector Type	A03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
2	BR	-

Connector No.	B26
Connector Name	REAR COMBINATION LAMP LH (BODY SIDE)
Connector Type	NS2AMW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	P	-
3	GR	-
4	B/R	-

Connector No.	B33
Connector Name	WIPE TO WIRE
Connector Type	NS18FGY-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	O	-
3	O	-
6	G	-
8	GR	-
9	O	-
10	P	-
11	R/L	-
12	P/L	-
13	L	-
14	Y	-
15	SHIELD	-

Connector No.	B45
Connector Name	HIGH-MOUNTED STOP LAMP
Connector Type	TK02MBR-P



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	B/R	-

Connector No.	B201
Connector Name	WIPE TO WIRE
Connector Type	TF-80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	R	-
6	R	-
7	W	-
8	V	-
11	R	-
12	G	-
13	Y	-
14	L	-
15	R	- [Without ADAS]
15	Y	- [With ADAS]
17	GR	-
18	P	-
19	BR	-
20	GR	-
21	Y	-
22	GR	-
23	R	-
24	V	-
25	B	-
26	W	-
28	V	-
29	P	-
30	O	-
31	B/R	-
32	Y	-
40	SHIELD	-
41	W/R	-
42	V	-
45	SB	-
46	R	- [With climate controlled seat]
46	Y	- [With heated seat]
47	G	- [With climate controlled seat]
47	GR	- [With heated seat]
48	V	-
49	O	-

JRLWE0499GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM

50	R	-
51	GR	-
52	LG	-
53	P	-
56	W	-
57	W	-
58	O	-
59	Y	-
61	SB	-
62	L	-
63	W	-
64	SB	-
65	LG	-
66	L	-
67	Y	-
68	SB	-
69	B	-
71	L	-
72	L	-
73	R	-
74	B	-
75	L	-
76	SHIELD	-
77	G	-
78	R	-
79	P	-
80	G	-
81	O	-
82	BR	-
83	GR	-
84	V	-
85	LG	-
86	W	-
87	O	-
88	Y	-
89	BR	-
90	L	-
91	BR	-
93	O	- [With heated seat]
93	Y	- [With climate controlled seat]
94	GR	-
96	W	-
97	P	-
98	LG	-
99	LG	-
100	Y	-

Connector No.	B204
Connector Name	WIPE TO WIRE
Connector Type	TH40MW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
2	BMW	-
3	BMW	-
5	Y	-
8	B	-
10	V	-
11	V	-
12	Y	-
13	BR	-
14	LG	-
15	GR	-
16	G	-
17	O	-
18	BR	-
19	GR	-
20	V	-
21	LG	-
22	W	-
23	O	-
24	Y	-
25	BR	-
26	L	-
27	W	-
28	B	-
29	R	-
30	SHIELD	-
31	G	-
32	G	-
33	R	-
35	P	-
36	B/R	-
37	BR	-
38	SB	-
39	P	-
44	SB	-
46	B	-
53	L	-

54	B	-
55	V	-

Connector No.	B216
Connector Name	FRONT DOOR SWITCH RH
Connector Type	A03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
2	GR	-

Connector No.	B223
Connector Name	REAR DOOR SWITCH RH
Connector Type	A03FW




Terminal No.	Color Of Wire	Signal Name [Specification]
2	BR	-

Connector No.	B245
Connector Name	WIPE TO WIRE
Connector Type	NS16MGY-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	O	-
3	Y	-
6	G	-
8	G	-
9	V	-
10	P	-
11	R/L	-
12	P/L	-
13	L	-
14	Y	-
15	SHIELD	-

Connector No.	B260
Connector Name	REAR COMBINATION LAMP RH (BODY SIDE)
Connector Type	NS04MW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	O	-
2	P	-
3	V	-
4	BR	-

JRLWE0500GB


EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


EXTERIOR LIGHTING SYSTEM

Connector No.	B276
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	GR	-
3	V	-
4	W	-
5	W	-
6	R	-
7	B	-
8	B	-
9	O	-
10	BR	-
11	L	- [Without around view monitor]
12	W	- [With around view monitor]
13	LW	- [Without around view monitor]
14	R	- [With around view monitor]
15	B	- [Without around view monitor]
16	L	- [With around view monitor]

Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	G	-
3	B	-

4	L	-
5	B	-
6	L	-
7	R	-
8	GR	-
9	G	-
10	LG	-
12	LG	-
13	BW	-
14	Y	-
15	O	-
16	R	-
17	Y	-
18	BR	-
19	W	-
20	G	-
21	GR	-
22	G	-
23	LG	-
24	B	-
25	L	-
26	P	-
27	V	-
28	W	-
29	GR	-
30	G	-
31	Y	-
32	O	-
33	BR	-
34	L	-
35	P	-
36	V	-
37	GR	-
38	O	-
39	W	-
40	R	-
41	W	-
42	B	-
43	R	-
44	G	-
45	LG	-
46	BR	-
47	Y	-
48	Y	-
49	P	-
50	BW	-
51	G	-
52	Y	-
53	BW	-

54	W	-
55	SHIELD	-



Connector No.	D3
Connector Name	DOOR MIRROR (DRIVER SIDE)
Connector Type	TH24MW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	G	-
3	G	-
4	R	-
5	R	-
6	W	-
7	P	-
8	R	-
9	V	-
10	G	-
11	GR	-
12	O	-
13	B	-
17	SHIELD	-
18	B	-
19	B	-
21	BR	-
22	R	-
23	W	-
24	Y	-

Connector No.	D17
Connector Name	FRONT OUTSIDE HANDLE ASSEMBLY LH
Connector Type	SAZ06FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	BR	-
4	BW	-

Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
2	B	-
3	BW	-
5	GR	-
9	V	-
10	R	-
11	L	-
12	Y	-
13	BR	-
14	G	-
15	SB	-
16	G	-
17	B	-
18	BR	-
19	GR	-
20	V	-
21	LG	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM

22	SB	-
23	G	-
24	Y	-
25	BR	-
26	L	-
27	W	-
28	B	-
29	R	-
30	SHIELD	-
31	G	-
32	P	-
33	L	-
35	W	-
36	L	-
37	P	-
38	SB	-
39	O	-
44	SB	-
46	BR	-
53	L	-
54	B	-
55	V	-


Connector No.	D33
Connector Name	DOOR MIRROR (PASSENGER SIDE)
Connector Type	TH24MV-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	V	-
3	G	-
5	R	-
6	W	-
7	W	-
8	SB	-
9	O	-
10	Y	-
11	L	-
12	BR	-
13	B	-


17	SHIELD	-
18	B	-
19	B	-
21	BR	-
22	G	-
23	GR	-
24	P	-

Connector No.	D47
Connector Name	FRONT OUTSIDE HANDLE ASSEMBLY RH
Connector Type	SAZ706FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	-
2	B	-
3	G	-
4	BW	-

Connector No.	E5
Connector Name	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH20FW-CS12-M4-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
4	W	ENG SOL
5	P	IGN COIL
6	R	ECM_VB [With VK engine]
8	SB	ECM_VB [With VK engine]
7	R	ETC [With VK engine]
7	Y	ETC [With VK engine]
8	LY	A/C_COMP [With VK engine]

8	P	A/C_COMP [With VK engine]
10	V	ECM_BAT
11	B	P-GND
12	G	ABS_ECU
13	GR	FUEL_PUMP [With VK engine]
13	W	FUEL_PUMP [With VK engine]
16	V	WIPER_AUTOSTOP
18	Y	IGN_SIGNAL
22	BR	ALT-C
23	P	DTL_RLY
24	O	HOOD_SW
25	LG	SUB_ECU
30	BR	PUSH_START_SW
31	BR	NP_SW [With VK engine]
31	W	NP_SW [With VK engine]
36	GR	FILIGN_SW

Connector No.	E6
Connector Name	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH08FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
39	P	CAN-L
40	L	CAN-H
41	B	S-GND
42	V	MOTOR_FAN_RLY_CONT [With VK engine]
42	Y	MOTOR_FAN_RLY_CONT [With VK engine]
43	SB	DETENT_SW
44	GR	HORN_RLY [With VK engine]
44	LG	HORN_RLY [With VK engine]
45	G	HORN_SW
46	BR	START_CONT

Connector No.	E7
Connector Name	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH20FW-CS12-M4



Terminal No.	Color Of Wire	Signal Name [Specification]
48	P	DTL_DEICER
51	O	WASH_MTR
52	G	INJECTOR_#1
53	L	FR_WIPER_H
54	P	FR_WIPER_LO
55	R	DAZILLUMI
56	GR	O2_SENS_#1
57	V	O2_SENS_#2
58	BR	AT_ECU
70	LG	SSOFF
71	O	MOTRLY
73	G	START_IG-ER
74	R	START_IG-EG
75	Y	OIL_PRESSURE_SW
77	B	FPR
80	W	STARTER_MOTOR

Connector No.	E8
Connector Name	FROM INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	NS08FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
83	R	HEAD_LAMP_LO_RH
84	W	HEAD_LAMP_LO_LH
86	G	FR_POG_LAMP_RH
87	L	FR_POG_LAMP_LH

EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM

88	O	FR WIPER B
89	BR	HEAD LAMP HI RH
90	P	HEAD LAMP HI LH

Connector No.	E9
Connector Name	PRIMER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH18FWM-NH



Terminal No.	Wire	Signal Name [Specification]
94	P	CLEARANCE RH
96	R	WIPER REV RLY
97	V	MOTOR FAN PWM
102	R	CLEARANCE LH (With UK engine)
	R/L	CLEARANCE LH (With VQ engine)

Connector No.	E34
Connector Name	FRONT FOG LAMP RH
Connector Type	FH202FB



Terminal No.	Wire	Signal Name [Specification]
1	G	-
2	B/W	-

Connector No.	E48
Connector Name	FRONT COMBINATION LAMP LH
Connector Type	RS08FB-PR



Terminal No.	Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	B/Y	-
4	B/Y	-
5	V	-
7	P	-
8	P	-

Connector No.	E49
Connector Name	FRONT COMBINATION LAMP RH
Connector Type	RS08FB-PR



Terminal No.	Wire	Signal Name [Specification]
1	GR	-
2	V	-
3	B/W	-
4	B/W	-
5	R	-
7	BR	-
8	P	-

Connector No.	E50
Connector Name	DAYTIME RUNNING LIGHT RELAY
Connector Type	MO6FBR-R-LC



Terminal No.	Wire	Signal Name [Specification]
1	L	-
2	Y	-
3	Y	-
4	P	-
6	GR	-
7	P	-

Connector No.	E64
Connector Name	FRONT FOG LAMP LH
Connector Type	FH202FB



Terminal No.	Wire	Signal Name [Specification]
1	L	-
2	B/Y	-

Connector No.	E65
Connector Name	FRONT TURN SIGNAL LAMP LH
Connector Type	FH202FB



Terminal No.	Wire	Signal Name [Specification]
1	V	-
2	B/Y	-

Connector No.	E66
Connector Name	FRONT TURN SIGNAL LAMP RH
Connector Type	FH202FB



Terminal No.	Wire	Signal Name [Specification]
1	L	-
2	B/W	-

JRLWE0503GB

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL


EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	
2	W	
3	SB	
4	LG	
5	O	
6	W	
7	GR	
8	G	
9	Y	
10	BR	
11	SB	
12	L	
13	GR	
14	GR	
15	V	
16	Y	
17	GR	
18	V	
20	BR	
21	P	
22	L	
23	P	
27	SHIELD	
28	L/O	
29	W/L	
31	BR	
32	G	
33	O	
34	Y	
36	G	
37	V	
41	BR	
44	W	
45	L	
46	GR	
47	V	

Connector No.	E103
Connector Name	FUSE BLOCK (JIB)
Connector Type	NS16FW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
10F	GR	
12F	Y	
14F	W	
15F	V	
1F	SB	
2F	LG	
4F	G	
6F	O	
8F	BR	
9F	R	

48	G	
49	O	
50	LG	
54	R	
55	B	
60	W	
61	G	
62	Y	
63	BR	
64	B	
65	Y	
66	R	
67	SB	
68	G	
69	SHIELD	
70	W	
71	W	
72	R	
73	G	
74	Y	
75	B	
76	SHIELD	
77	O	
78	SB	
80	V	
82	SB	
83	GR	
84	Y	
85	Y	
86	L	
87	V	
88	BR	
89	LG	
90	W	
91	W	
92	P	
93	LG	
94	BR	
95	W	
96	W	
97	R	
98	Y	
99	V	
100	V	

Connector No.	E110
Connector Name	STOP LAMP SWITCH
Connector Type	MD4FW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	V	
3	G	- [Without ICC]
3	W	- [With ICC]
4	SB	

Connector No.	E115
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
3	R	
4	R	
5	LG	
8	GR	
10	P	- [With V/O engine]
10	W	- [With V/K engine]
11	V	
12	Y	

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM


Connector No.	F61
Connector Name	A/T ASSEMBLY
Connector Type	RK10FG-DGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	POWER SUPPLY (BACK-UP)
2	R	POWER SUPPLY (BACK-UP)
3	V	CAN-H
4	V	K-LINE
5	B	GND
6	G	POWER SUPPLY (IGN)
7	SB	BACK-UP LAMP RELAY
8	P	CAN-L
9	BR	PIN SIGNAL
10	B	GROUND



Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	TK38FW-NS10



Terminal No.	Color Of Wire	Signal Name [Specification]
2	L	-
3	G	-
4	B	- [With VK engine]
4	R	- [With VG engine]
5	B	- [With VG engine]
5	GR	- [With VK engine]
7	LG	-
8	Y	-
9	SB	- [With VG engine]
9	W	- [With VK engine]


Terminal No.	Color Of Wire	Signal Name [Specification]
10	BR	- [With VK engine]
10	V	- [With VG engine]
11	L	-
12	P	-
13	V	-
14	SB	-
15	R	-
16	W	-
17	GR	-
18	LG	-
21	LG	-
22	B	-
23	G	-
24	BR	-
25	O	-

Connector No.	F301
Connector Name	TCM
Connector Type	SP10FG




Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	V/GN
2	-	BATT
3	-	CAN-H
4	-	K-LINE
5	-	GND
6	-	V/GN
7	-	REV LAMP RLY
8	-	CAN-L
9	-	START RLY
10	-	GND

Connector No.	M1
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS08FM-AZ




Terminal No.	Color Of Wire	Signal Name [Specification]
1A	R	-
2A	W	-
3A	Y	-
4A	W	-
5A	V	-
6A	Y	-
8A	Y	-

Connector No.	M2
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS10FM-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
1B	R	-
3B	P	-
4B	G	-
5B	SB	-
6B	W	- [With VG engine]
6B	Y	- [With VK engine]
7B	Y	-
8B	R	-
9B	R	-

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Type	NS12FM-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	LG	-
11C	LG	-
12C	O	-
6C	R	-
7C	B	-
8C	B	-
9C	L	-

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MM-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	W	-
3	SB	-
4	LG	-
5	W	-
6	W	-
7	BG	-
8	O	-
9	Y	-
10	W	-
11	R	-
12	V	-
13	LG	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM

14	L	-	-	-	-
15	V	-	-	-	-
16	B	-	-	-	-
17	GR	-	-	-	-
18	V	-	-	-	-
20	SB	-	-	-	-
21	BR	-	-	-	-
22	L	-	-	-	-
23	P	-	-	-	-
27	SHIELD	-	-	-	-
28	V	-	-	-	-
29	SB	-	-	-	-
31	EG	-	-	-	-
32	P	-	-	-	-
33	R	-	-	-	-
34	EG	-	-	-	-
36	V	-	-	-	-
37	G	-	-	-	-
41	BR	-	-	-	-
44	BR	-	-	-	-
45	Y	-	-	-	-
46	EG	-	-	-	-
47	V	-	-	-	-
48	G	-	-	-	-
49	EG	-	-	-	-
50	W	-	-	-	-
54	W	-	-	-	-
55	G	-	-	-	-
60	GR	-	-	-	-
61	B	-	-	-	-
62	LG	-	-	-	-
63	BR	-	-	-	-
64	L	- [With ICC]	-	-	-
64	SB	- [Without ICC]	-	-	-
65	R	- [With ICC]	-	-	-
65	Y	- [Without ICC]	-	-	-
66	P	-	-	-	-
67	L	-	-	-	-
68	R	-	-	-	-
69	SHIELD	-	-	-	-
70	B	-	-	-	-
71	W	-	-	-	-
72	R	-	-	-	-
73	G	-	-	-	-
74	Y	-	-	-	-
75	B	-	-	-	-
76	SHIELD	-	-	-	-
77	B	-	-	-	-
78	V	-	-	-	-
80	G	-	-	-	-

82	B	-	-	-	-
83	EG	-	-	-	-
84	SB	-	-	-	-
85	Y	-	-	-	-
86	L	-	-	-	-
87	V	-	-	-	-
88	V	-	-	-	-
89	LG	-	-	-	-
90	EG	-	-	-	-
91	W	-	-	-	-
92	EG	-	-	-	-
93	G	-	-	-	-
94	Y	-	-	-	-
95	W	-	-	-	-
97	SB	-	-	-	-
98	R	-	-	-	-
99	W	-	-	-	-
100	L	-	-	-	-

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal Color Of Wire	Signal Name [Specification]
1 G	-
2 Y	-
4 BR	-
5 P	-
7 G	-
8 Y	-
9 G	-
10 V	-
11 L	-
11 V	- [With heater seat]
12 GR	- [With climate control seat]
12 P	- [With heater seat]
13 BR	- [With climate control seat]
14 GR	-
15 BG	-
16 V	-

17	BG	-	-	-	-
18	L	-	- [Without CAN gateway]	-	-
18	Y	-	- [With CAN gateway]	-	-
19	W	-	-	-	-
20	L	-	-	-	-
21	B	-	-	-	-
22	LG	-	-	-	-
23	W	-	-	-	-
24	V	-	-	-	-
25	G	-	-	-	-
26	BR	-	-	-	-
27	SB	-	-	-	-
28	P	-	-	-	-
29	L	-	-	-	-
30	SHIELD	-	-	-	-
32	P	-	-	-	-
33	P	-	-	-	-
34	W	-	-	-	-
35	SHIELD	-	-	-	-
36	EG	-	-	-	-
37	SB	-	-	-	-
41	SB	-	-	-	-
42	V	-	-	-	-
43	L	-	-	-	-
44	B	-	-	-	-
45	BG	-	-	-	-
46	P	-	-	-	-
47	L	-	-	-	-
48	LG	-	-	-	-
49	BR	-	-	-	-
50	V	-	-	-	-
51	V	-	-	-	-
52	P	-	-	-	-
53	BG	-	-	-	-
55	G	-	-	-	-
56	SB	-	-	-	-
57	P	-	-	-	-
58	LG	-	-	-	-
59	Y	-	-	-	-
60	GR	-	-	-	-
61	B	-	-	-	-
62	LG	-	-	-	-
63	BR	-	-	-	-
65	W	-	-	-	-
66	R	-	-	-	-
67	V	-	-	-	-
68	LG	-	-	-	-
69	SB	-	-	-	-
70	V	-	-	-	-
72	L	-	-	-	-

73	P	-	-	-	-
74	L	-	-	-	-
75	P	-	-	-	-
76	G	-	-	-	-
77	Y	-	-	-	-
78	SB	-	-	-	-
79	W	-	-	-	-
81	LG	-	-	-	-
82	BR	-	-	-	-
83	BG	-	-	-	-
84	B	-	-	-	-
85	W	-	-	-	-
86	G	-	-	-	-
87	R	-	-	-	-
88	G	-	-	-	-
91	W	-	-	-	-
92	G	-	-	-	-
96	W	-	-	-	-
97	EG	-	-	-	-
98	Y	-	-	-	-
99	LG	-	-	-	-

Connector No.	M20
Connector Name	PCB HARNESS
Connector Type	TH40FB-NH



Terminal Color Of Wire	Signal Name [Specification]
1 B	-
2 B	-
3 Y	-
4 G	-
5 R	-
6 W	-
11 BR	-
12 R	-
15 B	-
16 SHIELD	-
17 R	-
18 P	-
19 W	-

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM

21	B	-
22	R	- [With ICC]
22	Y	- [Without ICC]
23	L	- [With ICC]
23	SB	- [Without ICC]
24	L	-
27	P	-
31	V	-
33	V	-
35	L	-
36	P	-
38	L	-
40	Y	-

Connector No. M22
 Connector Name FCB HARNESS
 Connector Type TH40FB-NH



103	B	-
104	BR	-
105	R	-
107	Y	- [Without CAN gateway]
107	Y	- [With CAN gateway]
109	BR	-
110	Y	-
112	B	-
113	P	-
114	L	-
116	B	-
117	BR	- [With VK engine]
117	BG	- [With VO engine]
118	B	-
119	LG	-
120	V	-

Connector No. M24
 Connector Name FCB HARNESS
 Connector Type TH40FW-NH



184	V	-
185	P	-
186	R	-
187	L	- [Without CAN gateway]
187	Y	- [With CAN gateway]
188	L	-
189	B	-
190	V	-
191	LG	-
192	B	-
193	SB	-
194	BR	-
195	SB	-
198	R	-
199	B	-
200	SB	-

Connector No. M26
 Connector Name FCB HARNESS
 Connector Type TH40FW-NH



260	BG	-
261	P	-
262	P	-
267	P	-
268	Y	-
269	G	-
270	Y	-
271	Y	-
272	BR	-
273	G	-
273	R	-
274	Y	-
275	Y	-
276	B	-
277	G	-
278	R	-
279	R	-
280	Y	-

Connector No. M27
 Connector Name FCB HARNESS
 Connector Type TH40FB-NH



Terminal No.	Color Of Wire	Signal Name (Specification)
81	L	-
82	P	-
83	B	-
84	B	-
85	B	-
86	B	-
87	B	-
88	B	-
89	Y	-
91	V	-
92	V	-
93	B	-
94	B	-
95	LG	-
96	BR	-
97	G	-
98	G	-
99	G	-
100	G	-
101	L	-
102	P	-

Terminal No.	Color Of Wire	Signal Name (Specification)
161	BG	-
162	BG	-
164	V	-
165	V	-
166	R	-
167	LG	-
169	R	-
171	BG	-
172	B	-
174	W	-
176	L	-
177	P	-
178	Y	-
179	Y	-
180	LG	-
182	BR	- [With VO engine or with VK engine without ICC]
182	R	- [With VK engine with ICC]
183	G	-

Terminal No.	Color Of Wire	Signal Name (Specification)
241	L	-
242	L	-
243	R	- [With ICC]
243	Y	- [Without ICC]
244	L	- [With ICC]
244	SB	- [Without ICC]
245	B	-
246	B	-
247	B	-
248	SHIELD	-
251	SHIELD	-
252	B	-
253	B	-
254	B	-
254	W	- [With heated seat]
254	W	- [With climate controlled seat]
255	B	-
258	R	-
259	L	-

Terminal No.	Color Of Wire	Signal Name (Specification)
281	O	-
282	BG	-
283	BG	-
284	BG	-
286	W	-
287	Y	-
289	SHIELD	-
290	B	-
291	SHIELD	-
292	B	-
293	B	-
294	B	-
295	B	-
295	GR	-
297	B	-
298	B	-
299	L	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM

300	W	-	-
301	R	-	-
302	R	-	-
303	R	-	-
304	SHIELD	-	-
305	P	-	-
306	V	-	-
309	G	-	-
310	R	-	-
311	W	-	-
312	B	-	-
313	B	-	-
314	Y	-	-
315	G	-	-
316	R	-	-
317	W	-	-
318	SHIELD	-	-
319	W	-	-
320	W	-	-


Connector No.	M30
Connector Name	PCB HARNESS
Connector Type	TH40FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
402	R	-
403	R	-
405	B	-
407	V	-
408	B	-
409	B	-
410	B	-
411	B	-
413	Y	-
414	BR	-
416	LG	-
417	B	-
419	SB	-
420	SHIELD	-
422	V	-

427	P	-	-
428	V	-	-
429	P	-	-
430	LG	-	-
431	B	-	-
432	Y	-	-
435	V	-	-
436	BG	-	-
437	B	-	-
438	P	-	-
439	L	-	-
440	B	-	-

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH16FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	FR WASHER (-)
2	SB	OUTPUT 4
5	L	OUTPUT 3
6	B	GND
7	V	INPUT 3
8	BG	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	BATTERY POWER SUPPLY
2	BG	IGNITION SIGNAL
3	GR	VEHICLE SPEED SIGNAL (2-PULSE)
4	R	VEHICLE SPEED SIGNAL (8-PULSE)
5	B	ILLUMINATION CONTROL SIGNAL
6	B	METER CONTROL SWITCH GROUND
7	SB	ENTER SWITCH SIGNAL
8	LG	SELECT SWITCH SIGNAL
9	G	ILLUMINATION CONTROL SWITCH SIGNAL (+)
10	GR	ILLUMINATION CONTROL SWITCH SIGNAL (-)
11	L	TRIP RESET SWITCH SIGNAL
12	B	GND
14	L	CANH
15	P	CANL
16	R	AIR BAG SIGNAL
17	G	LED HEADLAMP (RH) WARNING SIGNAL
18	V	LED HEADLAMP (LH) WARNING SIGNAL
23	B	GND
24	B	FUEL LEVEL SENSOR GROUND
25	W	ALTERNATOR SIGNAL
26	V	PARKING BRAKE SWITCH SIGNAL
27	V	BRAKE FLUID LEVEL SWITCH SIGNAL
28	G	SECURITY SIGNAL
29	L	WASHER LEVEL SWITCH SIGNAL
32	G	PADDLE SHIFTER SHIFT DOWN SIGNAL
33	BG	PADDLE SHIFTER SHIFT UP SIGNAL
34	G	FUEL LEVEL SENSOR SIGNAL
35	W	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SEAT)
36	G	PASSENGER SEAT BELT WARNING SIGNAL
37	G	NON-MANUAL MODE SIGNAL
38	Y	MANUAL MODE SHIFT DOWN SIGNAL
39	L	MANUAL MODE SHIFT UP SIGNAL
40	W	MANUAL MODE SIGNAL

Connector No.	M69
Connector Name	BACK-UP LAMP RELAY
Connector Type	MS02FL-M2-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	R	-
3	BR	-
5	BG	-

Connector No.	M72
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH16FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GND
3	V	ACC
4	R	ILL
5	B	ILL CONT
6	SB	AV COMM (H)
8	LG	AV COMM (L)
9	BR	SW GND
14	SB	DISK EJECT SIGNAL
15	R	AIR BAGS CUT OFF
16	G	HAZARD ON

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM

Connector No.	M154
Connector Name	OPTICAL SENSOR
Connector Type	TK03FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	POWER
2	W	OUTPUT
3	B	GND

Connector No.	M104
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	TH04FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GND
2	BR	SIGNAL OUTPUT
3	GR	RSSI
4	R	BATTERY

Connector No.	M107
Connector Name	ECM
Connector Type	RH24FGY-RZ8-RH-Z




Terminal No.	Color Of Wire	Signal Name [Specification]
97	R	ACCELERATOR PEDAL POSITION SENSOR 1
98	Y	ACCELERATOR PEDAL POSITION SENSOR 2
99	G	SENSOR SW (ACCELERATOR PEDAL POSITION SENSOR 1)
100	W	SENSOR SW (ACCELERATOR PEDAL POSITION SENSOR 2)
101	SB	ASCD STEERING SWITCH
102	P	FUEL TANK PRESSURE SENSOR
103	L	SENSOR SW (FUEL TANK PRESSURE SENSOR)
104	B	SENSOR GROUND (Without ICC)
105	LG	REFRIGERANT PRESSURE SENSOR
106	P	FUEL TANK TEMPERATURE SENSOR
107	BG	AVOC2 PDPRES1FPRES
108	Y	GND ASCD SW
109	BR	TRANSMISSION RANGE SWITCH
110	V	ENGINE SPEED SIGNAL OUTPUT
112	V	GND PDPRES1FPRES
113	P	CAN COMMUNICATION LINE
114	L	CAN COMMUNICATION LINE
117	V	DATA LINK CONNECTOR
121	G	EVAP CANISTER VENT CONTROL VALVE
122	P	STOP LAMP SWITCH
123	B	ECM GROUND
124	B	ECM GROUND
125	SB	POWER SUPPLY FOR ECM
126	BR	ASGD BRAKE SWITCH
127	B	ECM GROUND
128	B	ECM GROUND

Connector No.	M116
Connector Name	WIPE TO WIRE
Connector Type	TK36MW-NS10



Terminal No.	Color Of Wire	Signal Name [Specification]
2	SB	-
3	Y	-
4	B	- [With VK engine]
4	SB	- [With VK engine]
5	B	-
7	W	-
8	Y	-
9	SB	- [With VG engine]
9	W	- [With VK engine]
10	SB	-
11	L	-
12	P	-
13	V	-
14	R	-
15	Y	-
16	SB	-
17	BR	-
18	LG	-
21	Y	-
22	LG	-
23	R	-
24	BG	-
25	BG	-
26	W	-
28	V	-
29	P	-
30	B	-
31	G	-
32	Y	-
40	SHIELD	-
41	R	-
42	V	-
45	SB	-
46	BG	-
46	L	- [With heated seat]
47	G	- [With climate controlled seat]
47	GR	- [With climate controlled seat]
48	V	-
49	BG	-

Connector No.	M117
Connector Name	WIPE TO WIRE
Connector Type	TH80FM-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
3	Y	-
6	R	-
7	W	-
8	V	-
11	R	-
12	G	-
13	W	-
14	L	-
15	R	- [Without ADAS]
15	Y	- [With ADAS]
17	GR	-
18	P	-
19	BR	-
20	GR	-
21	Y	-
22	LG	-
23	R	-
24	BG	-
25	BG	-
26	W	-
28	V	-
29	P	-
30	B	-
31	G	-
32	Y	-
40	SHIELD	-
41	R	-
42	V	-
45	SB	-
46	BG	-
46	L	- [With heated seat]
47	G	- [With climate controlled seat]
47	GR	- [With climate controlled seat]
48	V	-
49	BG	-

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM

50	LG	-	-
51	SB	-	-
52	Y	-	-
53	W	-	-
56	B	-	-
57	G	-	-
58	R	-	-
59	W	-	-
61	LG	-	-
62	V	-	-
63	R	-	-
64	SB	-	-
65	LG	-	-
66	L	-	-
67	Y	-	-
68	SB	-	-
69	B	-	-
71	L	-	-
72	L	-	-
73	P	-	-
74	B	-	-
75	L	-	-
76	SHIELD	-	-
77	G	-	-
78	R	-	-
79	L	-	-
80	G	-	-
81	EG	-	-
82	BR	-	-
83	GR	-	-
84	V	-	-
85	LG	-	-
86	V	-	-
87	R	-	-
88	Y	-	-
89	BR	-	-
90	L	-	-
91	Y	-	-
93	G	- [With heated seat]	-
93	W	- [With climate controlled seat]	-
94	V	-	-
96	W	-	-
97	Y	-	-
98	BR	-	-
99	G	-	-
100	Y	-	-


Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



41	W	TR KEY CYLINDER SW
42	R	TRUNK LID OPEN/CLOSE STATUS
44	V	TR LID OPEN/CANCEL SW
45	GR	PASSENGER DOOR SW
46	BR	REAR RH DOOR SW
47	LG	DRIVER DOOR SW
48	P	REAR LH DOOR SW
49	SB	TR ROOM LAMP CONT
51	BG	TR LID OPEN/REG SW
53	LG	TRUNK LID OPEN REQUEST
55	BR	RR DOOR UNLK OUTPUT

Terminal No.	Color	Wire	Signal Name [Specification]
1	G	RR WINDOW DEFGR/LY CONT	
2	BG	COMBI SW INPUT 5	
3	SB	COMBI SW INPUT 4	
4	L	COMBI SW INPUT 3	
5	G	COMBI SW INPUT 2	
6	P	COMBI SW INPUT 1	
8	V	POWER WINDOW SW COMM	
9	P	STOP LAMP SW 1	
11	R	RAIN SENSOR SERIAL LINK	
14	W	OPTICAL SENSOR	
16	SB	DIMMER SIGNAL	
17	Y	SENSOR PWR SPLY	
18	B	RECEIVER / SENSOR GND	
19	V	TURN SIG RH OUTPUT (FRONT)	
20	G	TURN SIG LH OUTPUT (FRONT)	
21	P	NATS ANT AMP	
22	GR	KYLS ENT RECEIVER RSSI	
23	G	SECURITY IND CONT	
24	L	DONGLE LINK	
25	G	NATS ANT AMP	
26	G	I-KEY IDENTIFICATION	
29	G	HAZARD SW	
30	O	TR LID OPNR SW	
31	W	DR DOOR UNLK SENSOR	
32	BR	COMBI SW OUTPUT 5	
33	R	COMBI SW OUTPUT 4	
34	V	COMBI SW OUTPUT 3	
35	Y	COMBI SW OUTPUT 2	
36	LG	COMBI SW OUTPUT 1	
37	R	P POSITION	
39	L	CANRH	
40	P	CANL	


Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FHAG-SA



41	42	44	45	46	47	48	49	51	53	55
----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color	Wire	Signal Name [Specification]
41	W	TR KEY CYLINDER SW	
42	R	TRUNK LID OPEN/CLOSE STATUS	
44	V	TR LID OPEN/CANCEL SW	
45	GR	PASSENGER DOOR SW	
46	BR	REAR RH DOOR SW	
47	LG	DRIVER DOOR SW	
48	P	REAR LH DOOR SW	
49	SB	TR ROOM LAMP CONT	
51	BG	TR LID OPEN/REG SW	
53	LG	TRUNK LID OPEN REQUEST	
55	BR	RR DOOR UNLK OUTPUT	

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FHAG-SA



56	57	58	59	60	61	62	63	65	66	67	68	69	70
----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color	Wire	Signal Name [Specification]
56	R	INT ROOM LAMP PWR SPLY	
57	R	BAT (FUSE)	
58	L	SENS CANCEL SW	
59	G	PASS DOOR UNLK OUTPUT	
60	G	TURN SIG LH OUTPUT (SIDE, REAR)	
61	V	TURN SIG RH OUTPUT (SIDE, REAR)	
62	V	STEP LAMP CONT	
63	L	ROOM LAMP TIMER CONT	
65	V	ALL DOOR FL LID LOCK OUTPUT	

66	LG	DR DOOR FL LID UNLK OUTPUT
67	B	GND
68	O	PWR PWR SPLY (IGN)
69	Y	PWR PWR SPLY (BAT)
70	W	BAT (FL)

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW-NH



71	72	73	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	96	97	98	99	100	102	104	105
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----	-----	-----	-----

Terminal No.	Color	Wire	Signal Name [Specification]
71	BR	KYLS ENT RECEIVER COMM	
72	B	OUTS HD LAMP OUTPUT	
73	V	ON IND	
75	G	DR DOOR REQ SW	
76	BR	PUSH SW	
78	BR	DRIVER DOOR ANT+	
79	SB	DRIVER DOOR ANT-	
80	LG	PASSENGER DOOR ANT+	
81	V	PASSENGER DOOR ANT-	
82	V	REAR BMPR ANT+	
83	SB	REAR BMPR ANT-	
84	BR	ROOM ANT1+	
85	Y	ROOM ANT1-	
86	R	ROOM ANT2+	
87	G	ROOM ANT2-	
88	V	TRUNK ROOM ANT+	
89	SB	TRUNK ROOM ANT-	
90	R	PUSH BTN IGN SW ILL PWR	
91	GR	LOCK IND	
92	B	PUSH BTN IGN SW ILL GND	
93	V	I-KEY WARM BUZZER	
96	SB	ACC RELAY CONT	
97	SB	STARTER RELAY CONT	
98	B	IGN RELAY (PDM E/R) CONT	
99	R	IGN RELAY (E/R) CONT	
100	SB	PASS DOOR REQ SW	
102	BR	PIN POSITION	
104	GR	AT SHIFT SELECT PWR SPLY	
105	R	STOP LAMP SW 2	

EXTERIOR LIGHTING SYSTEM


< WIRING DIAGRAM >

[LED HEADLAMP]

EXTERIOR LIGHTING SYSTEM


106	B	BLWR RELAY CONT
109	Y	ACC IND
110	R	RECEIVER PWR SPLY

Connector No.	M147
Connector Name	AIR BAG DIAGNOSIS SENSOR UNIT
Connector Type	NH28FX-EX



Terminal No.	Color Of Wire	Signal Name (Specification)
1	LG	IGN
2	B	GND
3	Y	DR1 (+)
4	Y	DR1 (-) DR2 (-)
5	Y	DR2 (+)
6	Y	AST (+)
7	Y	AST (-)
8	Y	AS2 (+)
9	Y	AS2 (-)
18	SB	ECZS (+)
19	V	ECZS (-)
22	SHIELD	GND
23	R	AIR BAG W/L
24	G	SEAT BELT
25	R	CUTOFF TELLTALE
51	G	SATELLITE RH2 (+)
52	R	SATELLITE RH2 (-)
54	L	IVCS
57	L	SATELLITE RH2 (-)
59	L	CANH
60	P	CANH


Connector No.	M160
Connector Name	ECM
Connector Type	MAB55FB-MEB10-LH-Z



Terminal No.	Color Of Wire	Signal Name (Specification)
111	W	FUEL INJECTOR DRIVER POWER SUPPLY
112	W	FUEL INJECTOR DRIVER POWER SUPPLY
114	B	ECM GROUND
115	B	ECM GROUND
120	G	EVAP CANISTER VENT CONTROL VALVE
122	V	VEHICLE SPEED SENSOR (VSS) (SIGNAL) (VEHICLE SPEED CONTROL MODULE)
123	BG	THROTTLE CONTROL MOTOR RELAY
125	P	FUEL PUMP CONTROL MODULE (FPOM)
126	Y	ACCELERATOR PEDAL POSITION SENSOR 2
128	SB	ASC/D STEERING SWITCH
129	B	SENSOR GROUND (WithIn ICC)
129	BR	SENSOR GROUND (WithIn ICC)
130	Y	SENSOR GROUND
131	L	SENSOR POWER SUPPLY
133	BG	SENSOR POWER SUPPLY
134	P	FUEL TANK TEMPERATURE SENSOR
136	R	ACCELERATOR PEDAL POSITION SENSOR 1
137	G	SENSOR POWER SUPPLY
138	P	BATTERY CURRENT SENSOR
139	BG	BATTERY TEMPERATURE SENSOR
140	W	SENSOR GROUND
141	G	IGNITION SWITCH
142	GR	FUEL PUMP CONTROL MODULE (FPOM) CHECK
143	P	FUEL TANK PRESSURE SENSOR
144	LG	REFRIGERANT PRESSURE SENSOR
146	L	CAN COMMUNICATION LINE
147	BR	ASC/D BRAKE SWITCH
150	V	SENSOR GROUND
151	P	CAN COMMUNICATION LINE
156	W	POWER SUPPLY FOR ECM (BACK-UP)
158	P	STOP LAMP SWITCH
161	Y	ENG COMMUNICATION LINE
163	W	ECM RELAY (SELF SHUT-OFF)
166	BG	ENG COMMUNICATION LINE
169	V	ENGINE SPEED SIGNAL OUTPUT
171	SB	POWER SUPPLY FOR ECM


172	SB	POWER SUPPLY FOR ECM
173	R	THROTTLE CONTROL MOTOR POWER SUPPLY
174	B	ECM GROUND
175	B	ECM GROUND

Connector No.	M182
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW




Terminal No.	Color Of Wire	Signal Name (Specification)
3	LG	M-CAN L
4	B	EARTH
5	B	EARTH
6	L	CANH
7	V	KLINE
8	LG	IGN SW
11	SB	M-CAN H
12	P	CANH
13	L	CANH
14	P	CANH
16	W	POWER

Connector No.	M221
Connector Name	WIRE TO WIRE
Connector Type	M03FW-LC




Terminal No.	Color Of Wire	Signal Name (Specification)
1	W	-
2	R	-
3	W	-

Connector No.	M222
Connector Name	WIRE TO WIRE
Connector Type	M03MM-LC



Terminal No.	Color Of Wire	Signal Name (Specification)
1	W	-
2	R	-
3	Y	-

Connector No.	T8
Connector Name	LICENSE PLATE LAMP RH
Connector Type	G02FW



Terminal No.	Color Of Wire	Signal Name (Specification)
1	V	-
2	L	-

JRLWE0511GB

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

EXTERIOR LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


EXTERIOR LIGHTING SYSTEM

Connector No.	T19
Connector Name	LICENSE PLATE LAMP LH
Connector Type	C02FW



Terminal Color Of No.	Wire	Signal Name [Specification]
1	V	-
2	L	-

Connector No.	T13
Connector Name	WIRE TO WIRE
Connector Type	MS16FW-CS



Terminal Color Of No.	Wire	Signal Name [Specification]
1	Y	-
2	G	-
3	P	-
5	W	-
6	R	-
7	G	-
8	O	-
9	V	-
10	L	-
11	W	-
12	B	-
13	R	-
14	L	-
15	P	-

Connector No.	T15
Connector Name	REAR COMBINATION LAMP RH (TRUNK LID USE)
Connector Type	TH04FW-NH



Terminal Color Of No.	Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	V	-
4	L	-

Connector No.	T16
Connector Name	REAR COMBINATION LAMP LH (TRUNK LID USE)
Connector Type	TH04FW-NH




Terminal Color Of No.	Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	V	-
4	L	-

JRLWE0512GB

ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]



ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

ACTIVE AFS

Connector No.	B8
Connector Name	WIRE TO WIRE
Connector Type	NS12FW-GS



Connector No.	E5
Connector Name	FROM ER INTELLIGENT POWER OS THERMION MODULE (ENGINE ROOM)
Connector Type	TH20FW-GS12-M4-1V



Connector No.	E6
Connector Name	FROM ER INTELLIGENT POWER OS THERMION MODULE (ENGINE ROOM)
Connector Type	TH8FW-NH



Connector No.	E58
Connector Name	HEADLAMP AIMING MOTOR LH
Connector Type	HS03FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
3	O	-
4	-	-
5	Y	-
8	LG	-
10	W	-
11	G	-
12	SB	-

Connector No.	B32
Connector Name	HEIGHT SENSOR
Connector Type	AAZ06FB1



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	-
2	G	-
4	Y	-

Terminal No.	Color Of Wire	Signal Name [Specification]
4	W	ENG SOL
5	P	IGN SOL
6	E	ECM_VB [With VG engine]
7	SB	ECM_VB [With VK engine]
8	R	ETC [With VK engine]
9	Y	ETC [With VG engine]
10	L/Y	A/C COMP [With VK engine]
11	P	A/C COMP [With VG engine]
12	V	ECM BAT
13	B	P-GND
14	G	ABS ECU
15	GR	FUEL PUMP [With VG engine]
16	W	FUEL PUMP [With VK engine]
17	V	WIPER AUTOSTOP
18	Y	IGN SIGNAL
19	BR	ALT-C
20	P	DTL RLY
21	O	HOOD SW
22	LG	SUB ECU
23	BR	PUSH START SW
24	W	NP SW [With VK engine]
25	W	NP SW [With VG engine]
26	GR	FIL IGN SW

Terminal No.	Color Of Wire	Signal Name [Specification]
39	P	CANL
40	L	CANLH
41	B	S-GND
42	V	MOTOR FAN RLY CONT [With VK engine]
43	SB	DETENT SW
44	GR	HORN RLY [With VK engine]
45	LG	HORN RLY [With VG engine]
46	BR	START CONT

Connector No.	E26
Connector Name	HEADLAMP AIMING MOTOR RH
Connector Type	HS03FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	AIMER_VCC
2	B	AIMER_GND
3	SB	AIMER_SIG

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	AIMER_VCC
2	B	AIMER_GND
3	SB	AIMER_SIG

Connector No.	E68
Connector Name	HEADLAMP SWIVEL ACTUATOR LH
Connector Type	HS03FGY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	SENS_VCC
2	Y	SENS_SIG
3	BR	SENS_GND

JRLWE0513GB

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


ACTIVE AFS

Connector No.	E69
Connector Name	HEADLAMP SWIVEL ACTUATOR RH
Connector Type	RS03FGY




Terminal No.	Wire	Signal Name [Specification]
1	G	SENS_VCC
2	Y	SENS_SIG
3	BR	SENS_GND

Connector No.	E70
Connector Name	AFS CONTROL UNIT
Connector Type	TH24FW-NH




Terminal No.	Wire	Signal Name [Specification]
1	L	CAN-H
3	GR	AFS SWITCH SIGNAL
6	Y	HEIGHT SENSOR SIGNAL
8	Y	SWIVEL ACTUATOR LIN SIGNAL
11	B	GROUND
12	G	IGNITION POWER SUPPLY
13	P	CAN-L
19	BR	SWIVEL ACTUATOR GROUND
21	V	HEIGHT SENSOR POWER SUPPLY
22	SB	AIMING MOTOR DRIVE SIGNAL
23	LG	HEIGHT SENSOR GROUND
24	B	AIMING MOTOR GROUND

Connector No.	E103
Connector Name	FUSE BLOCK (UB)
Connector Type	NS16FW-CS



Terminal No.	Wire	Signal Name [Specification]
10F	GR	
12F	Y	
14F	W	
15F	V	
1F	SB	
2F	LG	
4F	G	
8F	O	
9F	R	

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Wire	Signal Name [Specification]
1	P	
2	W	
3	SB	
4	LG	
5	O	
7	W	
8	GR	
9	Y	
10	BR	

11	SB	
12	L	
13	GR	
14	GR	
15	V	
16	Y	
17	GR	
18	V	
20	BR	
21	P	
22	L	
23	P	
27	SHIELD	
28	L/O	
29	W/L	
31	BR	
32	G	
33	O	
34	Y	
36	G	
37	V	
41	BR	
44	W	
45	L	
46	GR	
47	V	
48	G	
49	O	
50	LG	
54	R	
55	B	
60	W	
61	G	
62	Y	
63	BR	
64	B	
65	Y	
66	R	
67	SB	
68	G	
69	SHIELD	
70	W	
71	W	
72	R	
73	G	
74	Y	
75	B	
76	SHIELD	
77	O	
78	SB	

80	V	
82	SB	
83	GR	
84	Y	
85	Y	
86	L	
87	V	
88	BR	
89	LG	
90	W	
91	W	
92	P	
93	LG	
94	BR	
95	W	
97	R	
98	Y	
99	V	
100	V	

Connector No.	E115
Connector Name	WIRE TO WIRE
Connector Type	NS12MW-CS



Terminal No.	Wire	Signal Name [Specification]
3	R	
4	R	
5	LG	
8	GR	
10	P	- [With V6 engine]
11	V	- [With V6 engine]
12	Y	

ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

ACTIVE AFS


Connector No.	F61
Connector Name	A/T ASSEMBLY
Connector Type	RK10FG-DG1



Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	POWER SUPPLY (BACK UP)
2	R	POWER SUPPLY (BACK UP)
3	V	CANLH
4	V	KLINE
5	B	GND
6	G	POWER SUPPLY (IGN)
7	SB	BACK-UP LAMP RELAY
8	P	CANL
9	BR	PIN SIGNAL
10	B	GROUND




Connector No.	F301
Connector Name	TCM
Connector Type	SP10FG




Connector No.	M3
Connector Name	FUSE BLOCK (UB)
Connector Type	NS12FM-CS

Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	VIGN
2	-	BATT
3	-	CANLH
4	-	KLINE
5	-	GND
6	-	VIGN
7	-	REV LAMP RELY
8	-	CANL
9	-	START RELY
10	-	GND


Connector No.	M2
Connector Name	FUSE BLOCK (UB)
Connector Type	NS10FM-CS



Terminal No.	Color Of Wire	Signal Name [Specification]
1B	R	-
3B	P	-
4B	G	-
5B	SB	-
6B	W	- [With V/G engine]
7B	Y	- [With V/A engine]
8B	R	-
9B	R	-



Connector No.	M6
Connector Name	WIPE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	W	-
3	SB	-
4	LG	-
5	W	-
6	W	-
7	BG	-
8	G	-
9	Y	-
10	W	-
11	R	-
12	V	-
13	LG	-
14	L	-
15	V	-
16	B	-
17	GR	-
18	V	-
20	SB	-
21	BR	-
22	L	-
23	P	-
27	SHIELD	-
28	V	-
29	SB	-
31	BG	-
32	P	-
33	R	-
34	BG	-
36	V	-
37	G	-
41	BR	-
44	BR	-
45	Y	-
46	BG	-
47	V	-

48	G	-
49	BG	-
50	W	-
54	W	-
55	G	-
60	GR	-
61	B	-
62	LG	-
63	BR	-
64	L	- [With ICG]
64	SB	- [Without ICG]
65	R	- [With ICG]
65	Y	- [Without ICG]
66	P	- [With ICG]
67	L	- [Without ICG]
68	R	-
69	SHIELD	-
70	B	-
71	W	-
72	R	-
73	G	-
74	Y	-
75	B	-
76	SHIELD	-
77	B	-
78	V	-
80	G	-
82	B	-
83	BG	-
84	SB	-
85	Y	-
86	L	-
87	V	-
88	V	-
89	LG	-
90	BG	-
91	W	-
92	BG	-
93	G	-
94	Y	-
95	W	-
97	SB	-
98	R	-
99	W	-
100	L	-

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

ACTIVE AFS

Connector No.	M20
Connector Name	PCB HARNESS
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	Y	-
4	G	-
5	R	-
6	W	-
11	BR	-
12	R	-
15	B	-
16	SHIELD	-
17	R	-
18	P	-
19	W	-
21	B	-
22	R	- [With ICC]
22	Y	- [Without ICC]
23	L	- [With ICC]
23	SB	- [Without ICC]
24	L	-
27	P	-
31	V	-
33	V	-
35	L	-
36	P	-
38	L	-
40	Y	-

Connector No.	M22
Connector Name	PCB HARNESS
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
81	L	-
82	P	-
83	B	-
84	B	-
85	B	-
86	B	-
87	B	-
88	B	-
89	Y	-
91	V	-
92	V	-
93	B	-
94	B	-
95	LG	-
96	BR	-
97	G	-
98	G	-
99	G	-
100	G	-
101	L	-
102	P	-
103	B	-
104	BR	-
105	R	-
107	Y	-
108	Y	-
109	BR	-
110	Y	-
112	B	-
113	P	-
114	L	-
116	B	-
117	B	-
117	BS	- [With VK engine]
118	B	- [With VK engine]
119	LG	-

Connector No.	M24
Connector Name	PCB HARNESS
Connector Type	TH40FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
161	EG	-
162	EG	-
164	V	-
165	R	-
165	R	-
167	LG	-
169	R	-
171	BG	-
172	B	-
174	W	-
176	L	-
177	P	-
178	Y	-
179	L	-
180	LG	-
182	BR	- [With VK engine or with VK engine without ICC]
182	R	- [With VK engine with ICC]
183	G	-
184	V	-
185	P	-
186	R	-
187	L	- [Without CAN gateway]
187	Y	- [With CAN gateway]
188	L	-
189	B	-
190	V	-
191	LG	-
192	B	-
193	SB	-
194	BR	-
195	SB	-
196	R	-
199	B	-

Connector No.	M27
Connector Name	PCB HARNESS
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
281	O	-
282	EG	-
283	EG	-
284	BG	-
285	W	-
287	Y	-
289	SHIELD	-
290	B	-
291	SHIELD	-
292	B	-
293	B	-
294	B	-
295	B	-
296	GR	-
297	B	-
298	B	-
299	L	-
300	W	-
301	R	-
302	R	-
303	R	-
304	SHIELD	-
305	P	-
306	V	-
309	G	-
310	R	-
311	W	-
312	B	-
313	B	-
314	V	-
315	G	-
316	R	-
317	W	-

JRLWE0516GB

ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

ACTIVE AFS


318	SHIELD	-	-	GROUND
319	V	-	CAN-H	
320	W	-	CAN-L	

Connector No.	M37
Connector Name	STEERING ANGLE SENSOR
Connector Type	TH88FW-NH



Terminal No.	Color Of Wire	Signal Name (Specification)
1	L	CAN-H
2	P	CAN-L
7	B	GND
8	G	IGN

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



Terminal No.	Color Of Wire	Signal Name (Specification)
1	W	BATTERY POWER SUPPLY
2	BG	IGNITION SIGNAL
3	GR	VEHICLE SPEED SIGNAL (2-PULSE)
4	R	VEHICLE SPEED SIGNAL (8-PULSE)
5	B	ILLUMINATION CONTROL SIGNAL
6	B	METER CONTROL SWITCH GROUND
7	SB	ENTER SWITCH SIGNAL
8	LG	SELECT SWITCH SIGNAL
9	G	ILLUMINATION CONTROL SWITCH SIGNAL (+)
10	GR	ILLUMINATION CONTROL SWITCH SIGNAL (-)
11	L	TRIP RESET SWITCH SIGNAL

12	B	GROUND
14	L	CAN-H
15	P	CAN-L
16	R	AIR BAG SIGNAL
17	G	LED HEADLAMP (RH) WARNING SIGNAL
18	V	LED HEADLAMP (LH) WARNING SIGNAL
23	B	GROUND
24	B	FUEL LEVEL SENSOR GROUND
25	W	ALTERNATOR SIGNAL
26	V	PARKING BRAKE SWITCH SIGNAL
27	V	BRAKE FLUID LEVEL SWITCH SIGNAL
28	G	SECURITY SIGNAL
29	L	WASHER LEVEL SWITCH SIGNAL
32	G	PADDLE SHIFTER SHIFT DOWN SIGNAL
33	BG	PADDLE SHIFTER SHIFT UP SIGNAL
34	G	FUEL LEVEL SENSOR SIGNAL
35	W	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SEAT)
36	G	PASSENGER SEAT BELT WARNING SIGNAL
37	G	NON-MANUAL MODE SIGNAL
38	V	MANUAL MODE SHIFT DOWN SIGNAL
39	L	MANUAL MODE SHIFT UP SIGNAL
40	W	MANUAL MODE SIGNAL

Connector No.	M54
Connector Name	METER CONTROL SWITCH
Connector Type	TH2MIV-NH




Terminal No.	Color Of Wire	Signal Name (Specification)
1	SB	-
2	B	-
3	GR	-
4	R	-
5	W	-
6	G	-
9	BG	-
10	GR	-
11	LG	-
12	L	-

Connector No.	M107
Connector Name	ECM
Connector Type	RH24FY-RZ8-RH-Z



Terminal No.	Color Of Wire	Signal Name (Specification)
97	R	ACCELERATOR PEDAL POSITION SENSOR 1
98	Y	ACCELERATOR PEDAL POSITION SENSOR 2
99	G	SENSOR DATA (ACCELERATOR PEDAL POSITION SENSOR 1)
100	W	SENSOR DATA (ACCELERATOR PEDAL POSITION SENSOR 2)
101	SB	ASC2 STEERING SWITCH
102	P	FUEL TANK PRESSURE SENSOR
103	L	SENSOR DATA (FUEL TANK PRESSURE SENSOR 1)
104	B	SENSOR GROUND (WITHOUT ICC)
104	BR	SENSOR GROUND (WITH ICC)
105	LG	REFRIGERANT PRESSURE SENSOR
106	P	FUEL TANK TEMPERATURE SENSOR
107	BG	AVOCC2 PDPRES/PTPRES
108	Y	GND ASCD SW
109	BR	TRANSMISSION RANGE SWITCH
110	V	ENGINE SPEED SIGNAL OUTPUT
111	V	GND4 PDPRES/PTPRES
112	P	CAN COMMUNICATION LINE
113	P	CAN COMMUNICATION LINE
114	L	CAN COMMUNICATION LINE
117	V	DATA LINK CONNECTOR
121	G	EVAP CANISTER VENT CONTROL VALVE
122	P	STOP LAMP SWITCH
123	B	ECM GROUND
124	B	ECM GROUND
125	SB	POWER SUPPLY FOR ECM
126	BR	ASC2 BRAKE SWITCH
127	B	ECM GROUND
128	B	ECM GROUND

Connector No.	M160
Connector Name	ECM
Connector Type	MA855FB-MEB10-LH-Z



Terminal No.	Color Of Wire	Signal Name (Specification)
111	W	FUEL INJECTOR DRIVER POWER SUPPLY
112	W	FUEL INJECTOR DRIVER POWER SUPPLY
114	B	ECM GROUND
115	B	ECM GROUND
120	G	EVAP CANISTER VENT CONTROL VALVE
122	V	VEHICLE SPEED SIGNAL (VEHICLE SPEED SENSOR 1)
123	BG	THROTTLE CONTROL MOTOR RELAY
125	P	FUEL PUMP CONTROL MODULE (FPCM)
126	Y	ACCELERATOR PEDAL POSITION SENSOR 2
128	SB	ASC2 STEERING SWITCH
129	B	SENSOR GROUND (WITHOUT ICC)
129	BR	SENSOR GROUND (WITH ICC)
130	Y	SENSOR GROUND
131	L	SENSOR POWER SUPPLY
133	BG	SENSOR POWER SUPPLY
134	P	FUEL TANK TEMPERATURE SENSOR 1
136	R	ACCELERATOR PEDAL POSITION SENSOR 1
137	G	SENSOR POWER SUPPLY
138	P	BATTERY CURRENT SENSOR
139	BG	BATTERY TEMPERATURE SENSOR
140	W	SENSOR GROUND
141	G	IGNITION SWITCH
142	GR	FUEL PUMP CONTROL MODULE (FPCM) CHECK
143	P	FUEL TANK PRESSURE SENSOR
144	LG	REFRIGERANT PRESSURE SENSOR
146	L	CAN COMMUNICATION LINE
147	BR	ASC2 BRAKE SWITCH
150	V	SENSOR GROUND
151	P	CAN COMMUNICATION LINE
156	W	POWER SUPPLY FOR ECM (BACK-UP)
158	B	STOP LAMP SWITCH
161	V	ECM COMMUNICATION LINE
163	W	ECM RELAY (SELF SHUT-OFF)
166	BG	ECM COMMUNICATION LINE
169	V	ENGINE SPEED SIGNAL OUTPUT
171	SB	POWER SUPPLY FOR ECM

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

ACTIVE ADAPTIVE FRONT-LIGHTING SYSTEM


< WIRING DIAGRAM >

[LED HEADLAMP]

ACTIVE AFS

Terminal No.	Color Of Wire	Signal Name [Specification]
172	SB	POWER SUPPLY FOR ECM
173	R	THROTTLE CONTROL MOTOR POWER SUPPLY
174	B	ECM GROUND
175	B	ECM GROUND

Connector No.	M182
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color Of Wire	Signal Name [Specification]
3	LG	M-CAN L
4	B	EARTH
5	B	EARTH
6	L	CANH
7	V	KLIN
8	LG	IGN SW
11	SB	M-CAN H
12	P	CANL
13	L	CANH
14	P	CAN-L
16	W	POWER

Connector No.	M221
Connector Name	WIRE TO WIRE
Connector Type	M03FW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	R	-
3	W	-

Connector No.	M222
Connector Name	WIRE TO WIRE
Connector Type	M03MW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	R	-
3	Y	-

JRLWE0518GB

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[LED HEADLAMP]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000011460203

OVERALL SEQUENCE



DETAILED FLOW

JMKIA8652GB

DIAGNOSIS AND REPAIR WORK FLOW

[LED HEADLAMP]

< BASIC INSPECTION >

1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-44. "Intermittent Incident"](#).

6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

DIAGNOSIS AND REPAIR WORK FLOW

[LED HEADLAMP]

< BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-44. "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

LED HEADLAMP OPERATION INSPECTION

< BASIC INSPECTION >

[LED HEADLAMP]

LED HEADLAMP OPERATION INSPECTION

Work Procedure

INFOID:000000011460204

1. CHECK START

1. In the cool LED status (wait for more than 10 minutes after turning headlamp OFF), turn ON and turn OFF headlamp for the several times. Check that headlamp operates normally each time.
2. In the cool LED status, turn headlamp ON, wait until headlamp enters to the stable status (approximately 5 minutes after turning headlamp ON), and then check that headlamp operates normally without blinking or flickering.
3. In the warm LED status (turn headlamp ON for more than 15 minutes and wait for 1 minute after turning OFF), turn ON and turn OFF headlamp for the several times. Check that headlamp operates normally each time.
4. Turn headlamp ON for approximately 30 minutes, and then check that headlamp operates normally without difference in brightness between LH and RH, blinking or flickering.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Refer to [EXL-125, "Symptom Table"](#).

ADDITIONAL SERVICE WHEN REPLACING AFS CONTROL UNIT

< BASIC INSPECTION >

[LED HEADLAMP]

ADDITIONAL SERVICE WHEN REPLACING AFS CONTROL UNIT

Description

INFOID:000000011460207

BEFORE REPLACEMENT

When replacing AFS control unit, save or print current vehicle specification with CONSULT "Configuration" before replacement.

NOTE:

If "READ CONFIGURATION" can not be used, use the "WRITE CONFIGURATION - Manual selection" after replacing AFS control unit.

AFTER REPLACEMENT

CAUTION:

- When replacing AFS control unit, always perform "WRITE CONFIGURATION" with CONSULT. Or not doing so, AFS control unit control function does not operate normally.
- Complete the procedure of "WRITE CONFIGURATION" in order.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- If you set incorrect "WRITE CONFIGURATION", incidents might occur.
- Perform "SENSOR INITIALIZE" with CONSULT when replacing the AFS control unit.

Work Procedure

INFOID:000000011460208

1.SAVING VEHICLE SPECIFICATION

CONSULT Configuration

Perform "READ CONFIGURATION" to save or print current vehicle specification. Refer to [EXL-76. "Description"](#).

NOTE:

If "READ CONFIGURATION" can not be used, use the "WRITE CONFIGURATION - Manual selection" after replacing AFS control unit.

>> GO TO 2.

2.REPLACE AFS CONTROL UNIT

Replace AFS control unit. Refer to [EXL-148. "Removal and Installation"](#).

>> GO TO 3.

3.WRITING VEHICLE SPECIFICATION

CONSULT Configuration

Perform "WRITE CONFIGURATION - Config file" or "WRITE CONFIGURATION - Manual selection" to write vehicle specification. Refer to [EXL-76. "Work Procedure"](#).

>> GO TO 4.

4.SENSOR INITIALIZE

CONSULT Work Support

Perform "SENSOR INITIALIZE". Refer to [EXL-78. "Work Procedure"](#).

>> WORK END

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

CONFIGURATION (AFS CONTROL UNIT)

Description

INFOID:000000011460213

Vehicle specification needs to be written with CONSULT because it is not written after replacing AFS control unit.

Configuration has three functions as follows.

Function	Description
READ CONFIGURATION	<ul style="list-style-type: none"> • Reads the vehicle configuration of current AFS control unit. • Saves the read vehicle configuration.
WRITE CONFIGURATION - Manual selection	Writes the vehicle configuration with manual selection.
WRITE CONFIGURATION - Config file	Writes the vehicle configuration with saved data.

CAUTION:

- **When replacing AFS control unit, always perform “WRITE CONFIGURATION” with CONSULT. Or not doing so, AFS control unit control function does not operate normally.**
- **Complete the procedure of “WRITE CONFIGURATION” in order.**
- **Configuration is different for each vehicle model. Confirm configuration of each vehicle model.**
- **If you set incorrect “WRITE CONFIGURATION”, incidents might occur.**

Work Procedure

INFOID:000000011460214

1. WRITING MODE SELECTION

ⓅCONSULT Configuration

1. Turn ignition switch ON.
2. Select “Configuration” mode of “ADAPTIVE LIGHT” using CONSULT.

When writing saved data>>GO TO 2.

When writing manually>>GO TO 3.

2. PERFORM “WRITE CONFIGURATION - CONFIG FILE”

ⓅCONSULT Configuration

Perform “WRITE CONFIGURATION - Config file”.

>> WORK END

3. PERFORM “WRITE CONFIGURATION - MANUAL SELECTION”

ⓅCONSULT Configuration

1. Select "WRITE CONFIGURATION - Manual selection".
2. Identify the correct model and configuration list. Refer to [EXL-77. "Configuration list"](#).
3. Confirm and/or change setting value for each item.

CAUTION:

Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.

NOTE:

If items are not displayed, touch “SETTING”. Refer to [EXL-77. "Configuration list"](#) for written items and setting value.

4. Select "SETTING".

CAUTION:

Make sure to select “SETTING” even if the indicated configuration of brand new AFS control unit is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model can not be memorized.

5. When "COMMAND FINISHED", touch "End".

>> WORK END

CONFIGURATION (AFS CONTROL UNIT)

< BASIC INSPECTION >

[LED HEADLAMP]

Configuration list

INFOID:000000011460215

CAUTION:

Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.

SETTING ITEM		NOTE
Items	Setting value	
ENGINE TYPE	TYPE 2	—
HANDLE	LHD	—
SUSPENSION	TYPE 1	—

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

EXL

SENSOR INITIALIZE

Description

INFOID:000000011460219

Perform the sensor initialize when the following operation is performed.

- Replacing AFS control unit
- Removing, installing or replacing height sensor
- Adjusting, removing, installing or replacing suspension components

Work Procedure

INFOID:000000011460220

1. VEHICLE CONDITION CHECK

1. Park the vehicle in the straight-forward position.
2. Unload the vehicle (no passenger aboard).

>> GO TO 2.

2. SENSOR INITIALIZE

④ With CONSULT

1. Turn ignition switch ON.
2. Select "LEVELIZER ADJUSTMENT" in "Work Support" mode of "ADAPTIVE LIGHT" using CONSULT.
3. Touch "Start".
4. When "INITIALISE COMPLETE", touch "End".

NOTE:

If "INITIALISE NOT DONE" is indicated, AFS control unit detects that the height sensor signal changes. The sensor initialize is cancelled. In this case, turn the ignition switch OFF to prevent the vehicle from the height change. Perform the sensor initialize again.

Is the sensor initialize completed?

- YES >> GO TO 3.
 NO >> Perform the sensor initialize again.

3. SELF DIAGNOSTIC RESULT CHECK

④ With CONSULT

1. Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
2. Check DTC.

Is DTC detected?

- YES >> GO TO 2.
 NO >> WORK END

DTC/CIRCUIT DIAGNOSIS

B2008 PARA NOT PROG

DTC Description

INFOID:000000011460223

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition
B2008	PARA NOT PROG (Parameter not programmed)	Vehicle specification is not written in AFS control unit when the ignition switch is turned ON

POSSIBLE CAUSE

Configuration is not completed

FAIL-SAFE

Fail-safe	
Swivel operation	Aiming operation
Right and left swivel motors stop at the position when DTC is detected	Right and left headlamp aiming motors stop at the position when DTC is detected

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

ⓂWith CONSULT

1. Turn ignition switch ON.
2. Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
3. Check DTC.

Is DTC detected?

- YES >> Refer to [EXL-79. "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-44. "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011460224

1.PERFORM CONFIGURATION

Perform configuration. Refer to [EXL-76. "Work Procedure"](#).

>> INSPECTION END

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

B2503 SWIVEL ACTUATOR [RH]

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

B2503 SWIVEL ACTUATOR [RH]

DTC Description

INFOID:000000011460261

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition
B2503	SWIVEL ACTUATOR [RH] (Swivel actuator [Right hand])	<ul style="list-style-type: none"> Power supply voltage supplied to the swivel actuator RH is 17.5 V or more or 7.7 V or less and this condition continues for 5 seconds or more when the ignition switch is turned ON Initialization incomplete status of the swivel actuator (RH) continues for 5 seconds or more when the swivel actuator is initialized Swivel actuator (RH) does not complete swivel actuator initialization when the vehicle is driven
	SWIVEL ACTUATOR [RH] COMM ERROR (Swivel actuator [Right hand] Communication error)	LIN communication signal malfunction status between AFS control unit and the swivel actuator (RH) continues for 5 seconds or more when the ignition switch is turned ON

POSSIBLE CAUSE

- Harness or connectors
- Swivel actuator RH

FAIL-SAFE

CONSULT screen terms	Fail-safe	
	Swivel operation	Aiming operation
SWIVEL ACTUATOR [RH]	<ul style="list-style-type: none"> Right swivel motor stop at the position when DTC is detected Left swivel motor swivel angle returns to 0° and fixed 	The signal, approximately 2 V decreased from the aiming motor drive signal when DTC detected, is output
SWIVEL ACTUATOR [RH] COMM ERROR	<ul style="list-style-type: none"> Right swivel motor stop at the position when DTC is detected or right swivel motor swivel angle returns to 0° and fixed Left swivel motor swivel angle returns to 0° and fixed 	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓢ With CONSULT

- Start engine and wait at least 5 seconds.
- Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
- Check DTC.

Is DTC detected?

YES >> Refer to [EXL-80, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011460262

1. CHECK DTC

Perform each inspection according to the displayed DTC.

Which DTC is displayed?

SWIVEL ACTUATOR [RH] >> GO TO 2.

SWIVEL ACTUATOR [RH] COMM ERROR >> GO TO 4.

2. CHECK SWIVEL ACTUATOR RH POWER SUPPLY

B2503 SWIVEL ACTUATOR [RH]

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect headlamp swivel actuator RH connector.
3. Turn ignition switch ON.
4. Check voltage between headlamp swivel actuator RH harness connector and ground.

+		-	Voltage
Headlamp swivel actuator RH	Terminal		
Connector	Terminal	Ground	Battery voltage
E69	1		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK SWIVEL ACTUATOR RH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect AFS control unit connector.
3. Check continuity between headlamp swivel actuator RH harness connector and AFS control unit harness connector.

Headlamp swivel actuator RH		AFS control unit		Continuity
Connector	Terminal	Connector	Terminal	
E69	3	E70	19	Existed

Is the inspection result normal?

YES >> Replace front combination lamp RH. Refer to [EXL-137. "Removal and Installation"](#).

NO >> Repair or replace harness.

4.CHECK SWIVEL ACTUATOR RH LIN COMMUNICATION SIGNAL CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect headlamp swivel actuator RH connector and AFS control unit connector.
3. Check continuity between headlamp swivel actuator RH harness connector and AFS control unit harness connector.

Headlamp swivel actuator RH		AFS control unit		Continuity
Connector	Terminal	Connector	Terminal	
E69	2	E70	8	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK SWIVEL ACTUATOR RH LIN COMMUNICATION SIGNAL CIRCUIT (SHORT)

Check continuity between headlamp swivel actuator RH harness connector and ground.

Headlamp swivel actuator RH		—	Continuity
Connector	Terminal		
E69	2	Ground	Not existed

Is the inspection result normal?

YES >> Replace front combination lamp RH. Refer to [EXL-137. "Removal and Installation"](#).

NO >> Repair or replace harness.

B2504 SWIVEL ACTUATOR [LH]

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

B2504 SWIVEL ACTUATOR [LH]

DTC Description

INFOID:000000011460263

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition
B2504	SWIVEL ACTUATOR [LH] (Swivel actuator [Left hand])	<ul style="list-style-type: none"> Power supply voltage supplied to the swivel actuator LH is 17.5 V or more or 7.7 V or less and this condition continues for 5 seconds or more when the ignition switch is turned ON Initialization incomplete status of the swivel actuator (LH) continues for 5 seconds or more when the swivel actuator is initialized Swivel actuator (LH) does not complete swivel actuator initialization when the vehicle is driven
	SWIVEL ACTUATOR [LH] COMM ERROR (Swivel actuator [Left hand] Communication error)	LIN communication signal malfunction status between AFS control unit and the swivel actuator (LH) continues for 5 seconds or more when the ignition switch is turned ON

POSSIBLE CAUSE

- Harness or connectors
- Swivel actuator LH

FAIL-SAFE

CONSULT screen terms	Fail-safe	
	Swivel operation	Aiming operation
SWIVEL ACTUATOR [LH]	<ul style="list-style-type: none"> Left swivel motor stop at the position when DTC is detected Right swivel motor swivel angle returns to 0° and fixed 	The signal, approximately 2 V decreased from the aiming motor drive signal when DTC detected, is output
SWIVEL ACTUATOR [LH] COMM ERROR	<ul style="list-style-type: none"> Left swivel motor stop at the position when DTC is detected or left swivel motor swivel angle returns to 0° and fixed Right swivel motor swivel angle returns to 0° and fixed 	

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓢ With CONSULT

1. Start engine and wait at least 5 seconds.
2. Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
3. Check DTC.

Is DTC detected?

YES >> Refer to [EXL-82, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011460264

1. CHECK DTC

Perform each inspection according to the displayed DTC.

Which DTC is displayed?

SWIVEL ACTUATOR [LH] >> GO TO 2.

SWIVEL ACTUATOR [LH] COMM ERROR >> GO TO 4.

2. CHECK SWIVEL ACTUATOR LH POWER SUPPLY

B2504 SWIVEL ACTUATOR [LH]

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect headlamp swivel actuator LH connector.
3. Turn ignition switch ON.
4. Check voltage between headlamp swivel actuator LH harness connector and ground.

+		-	Voltage
Headlamp swivel actuator LH	Terminal		
Connector	Terminal	Ground	Battery voltage
E68	1		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK SWIVEL ACTUATOR LH GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect AFS control unit connector.
3. Check continuity between headlamp swivel actuator LH harness connector and AFS control unit harness connector.

Headlamp swivel actuator LH		AFS control unit		Continuity
Connector	Terminal	Connector	Terminal	
E68	3	E70	19	Existed

Is the inspection result normal?

YES >> Replace front combination lamp LH. Refer to [EXL-137. "Removal and Installation"](#).

NO >> Repair or replace harness.

4.CHECK SWIVEL ACTUATOR LH LIN COMMUNICATION SIGNAL CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect headlamp swivel actuator LH connector and AFS control unit connector.
3. Check continuity between headlamp swivel actuator LH harness connector and AFS control unit harness connector.

Headlamp swivel actuator LH		AFS control unit		Continuity
Connector	Terminal	Connector	Terminal	
E68	2	E70	8	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK SWIVEL ACTUATOR LH LIN COMMUNICATION SIGNAL CIRCUIT (SHORT)

Check continuity between headlamp swivel actuator LH harness connector and ground.

Headlamp swivel actuator LH		—	Continuity
Connector	Terminal		
E68	2	Ground	Not existed

Is the inspection result normal?

YES >> Replace front combination lamp LH. Refer to [EXL-137. "Removal and Installation"](#).

NO >> Repair or replace harness.

B2514 HEIGHT SENSOR UNUSUAL [RR]

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

B2514 HEIGHT SENSOR UNUSUAL [RR]

DTC Description

INFOID:000000011460267

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition
B2514	HI SEN UNUSUAL [RR] (Height sensor unusual [Rear])	<ul style="list-style-type: none"> Power supply voltage supplied to the height sensor is 6.25 V or more or 4.45 V or less and this condition continues for 10 seconds or more when the ignition switch is turned ON Signal voltage from the height sensor is 4.0 V or more or 1.0 V or less and this condition continues for 10 seconds or more when the ignition switch is turned ON

POSSIBLE CAUSE

- Harness or connectors
- Height sensor installation condition
- Height sensor
- AFS control unit

FAIL-SAFE

Fail-safe	
Swivel operation	Aiming operation
Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

④ With CONSULT

1. Turn ignition switch ON and wait at least 10 seconds.
2. Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
3. Check DTC.

Is DTC detected?

- YES >> Refer to [EXL-84, "Diagnosis Procedure"](#).
 NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).
 NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011460268

1. CHECK INSTALLATION OF HEIGHT SENSOR

Check height sensor is properly installed. Refer to [EXL-150, "Exploded View"](#).

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace malfunctioning parts and perform sensor initialize. Refer to [EXL-78, "Work Procedure"](#).

2. CHECK HEIGHT SENSOR SIGNAL

1. Turn ignition switch ON.
2. Check voltage between AFS control unit harness connector and ground.

+		-	Voltage
AFS control unit			
Connector	Terminal		
E70	6	Ground	1.0 – 4.0 V

Is the measurement value within the standard value?

B2514 HEIGHT SENSOR UNUSUAL [RR]

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace AFS control unit. Refer to [EXL-148. "Removal and Installation"](#).
NO-1 >> Less than the standard value: GO TO 3.
NO-2 >> Higher than the standard value: GO TO 8.

3.CHECK HEIGHT SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect height sensor connector.
3. Turn ignition switch ON.
4. Check voltage between height sensor harness connector and ground.

+		-	Voltage
Height sensor			
Connector	Terminal	Ground	4.45 – 6.25 V
B32	2		

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 6.

4.CHECK HEIGHT SENSOR SIGNAL CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect AFS control unit connector.
3. Check continuity between AFS control unit harness connector and height sensor harness connector.

AFS control unit		Height sensor		Continuity
Connector	Terminal	Connector	Terminal	
E70	6	B32	1	Existed

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace harness.

5.CHECK HEIGHT SENSOR SIGNAL CIRCUIT (SHORT)

Check continuity between AFS control unit harness connector and ground.

AFS control unit		—	Continuity
Connector	Terminal		
E70	6	Ground	Not existed

Is the inspection result normal?

- YES >> Replace height sensor. Refer to [EXL-150. "Removal and Installation"](#).
NO >> Repair or replace harness.

6.CHECK HEIGHT SENSOR POWER SUPPLY CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect AFS control unit connector.
3. Check continuity between AFS control unit harness connector and height sensor harness connector.

AFS control unit		Height sensor		Continuity
Connector	Terminal	Connector	Terminal	
E70	21	B32	2	Existed

Is the inspection result normal?

- YES >> GO TO 7.
NO >> Repair or replace harness.

7.CHECK HEIGHT SENSOR POWER SUPPLY CIRCUIT (SHORT)

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

B2514 HEIGHT SENSOR UNUSUAL [RR]

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

Check continuity between AFS control unit harness connector and ground.

AFS control unit		—	Continuity
Connector	Terminal		
E70	21	Ground	Not existed

Is the inspection result normal?

YES >> Replace AFS control unit. Refer to [EXL-148, "Removal and Installation"](#)

NO >> Repair or replace harness.

8. CHECK HEIGHT SENSOR GROUND

Check voltage between AFS control unit harness connector and ground.

+		-	Voltage (Approx.)
AFS control unit			
Connector	Terminal		
E70	23	Ground	0 V

Is the inspection result normal?

YES >> GO TO 9.

NO >> Replace AFS control unit. Refer to [EXL-148, "Removal and Installation"](#)

9. CHECK HEIGHT SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect AFS control unit connector and height sensor connector.
3. Check continuity between AFS control unit harness connector and height sensor harness connector.

AFS control unit		Height sensor		Continuity
Connector	Terminal	Connector	Terminal	
E70	23	B32	4	Existed

Is the inspection result normal?

YES >> Replace height sensor. Refer to [EXL-150, "Removal and Installation"](#).

NO >> Repair or replace harness.

B2516 SHIFT POSITION SIGNAL [R, P]

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

B2516 SHIFT POSITION SIGNAL [R, P]

DTC Description

INFOID:000000011460269

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition
B2516	SHIFT POS SIG[R,P] (Shift position signal)	Malfunction status of the shift position signal received from TCM continues for 2 seconds or more when the ignition switch is turned ON

POSSIBLE CAUSE

A/T control system

FAIL-SAFE

Fail-safe	
Swivel operation	Aiming operation
Right and left swivel motor swivel angle returns to 0° and fixed	—

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

④ With CONSULT

- Turn ignition switch ON and wait at least 2 seconds.
- Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
- Check DTC.

Is DTC detected?

YES >> Refer to [EXL-87, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011460270

1. TCM SELF-DIAGNOSIS

④ With CONSULT

- Turn ignition switch ON.
- Select "Self Diagnostic Result" mode of "TRANSMISSION" using CONSULT, and repair or replace malfunctioning parts.
- Check DTC, and repair or replace malfunctioning parts. Refer to [TM-78, "DTC Index"](#).

>> INSPECTION END

B2517 VEHICLE SPEED SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

B2517 VEHICLE SPEED SIGNAL

DTC Description

INFOID:000000011460273

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition
B2517	VEHICLE SPEED SIG (Speed signal)	Malfunction status of the vehicle speed signal received from the combination meter continues for 2 seconds or more when the ignition switch is turned ON

POSSIBLE CAUSE

Vehicle speed signal

FAIL-SAFE

Fail-safe	
Swivel operation	Aiming operation
Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

④ With CONSULT

1. Turn ignition switch ON and wait at least 2 seconds.
2. Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
3. Check DTC.

Is DTC detected?

- YES >> Refer to [EXL-88, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011460274

1. COMBINATION METER SELF-DIAGNOSIS

④ With CONSULT

1. Turn ignition switch ON.
2. Select "Self Diagnostic Result" mode of "METER/M&A" using CONSULT, and repair or replace malfunctioning parts.
3. Check DTC, and repair or replace malfunctioning parts. Refer to [MWI-45, "DTC Index"](#).

>> INSPECTION END

B2519 LEVELIZER CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

B2519 LEVELIZER CALIBRATION

DTC Description

INFOID:000000011460275

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition
B2519	LEVELIZER CALIB (Levelizer calibration)	Initialization incomplete status of the height sensor is detected when the ignition switch is turned ON

POSSIBLE CAUSE

Sensor initialize is not completed

FAIL-SAFE

Fail-safe	
Swivel operation	Aiming operation
Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors fix at the initial aiming position

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
3. Check DTC.

Is DTC detected?

YES >> Refer to [EXL-89, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011460276

1.SENSOR INITIALIZE

Perform sensor initialize. Refer to [EXL-78, "Work Procedure"](#).

>> INSPECTION END

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

B2521 ECU CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

B2521 ECU CIRCUIT

DTC Description

INFOID:000000011460277

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition
B2521	ECU CIRC (ECU)	Internal malfunction of AFS control unit continues for 10 seconds or more when the ignition switch is turned ON

POSSIBLE CAUSE

AFS C/U

FAIL-SAFE

Fail-safe	
Swivel operation	Aiming operation
Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

④ With CONSULT

1. Turn ignition switch ON and wait at least 10 seconds.
2. Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
3. Check DTC.

Is DTC detected?

- YES >> Refer to [EXL-90, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011460278

1.REPLACE AFS CONTROL UNIT

Replace AFS control unit. Refer to [EXL-148, "Removal and Installation"](#).

>> INSPECTION END

U0126 STEERING ANGLE SENSOR SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

U0126 STEERING ANGLE SENSOR SIGNAL

DTC Description

INFOID:000000011460279

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition
U0126	ST ANG SEN SIG [Lost communication with steering angle sensor module]	<ul style="list-style-type: none">Malfunction status of the steering angle signal received from the steering angle sensor continues for 2 seconds or more when the ignition switch is turned ONSteering angle sensor malfunction signal is received from the steering angle sensor for 2 seconds or more continuously when the ignition switch is turned ON

POSSIBLE CAUSE

Steering angle sensor

FAIL-SAFE

Fail-safe	
Swivel operation	Aiming operation
Right and left swivel motor swivel angle returns to 0° and fixed	—

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓜ With CONSULT

- Turn ignition switch ON and wait at least 2 seconds.
- Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
- Check DTC.

Is DTC detected?

- YES >> Refer to [EXL-91, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011460280

1. ABS ACTUATOR AND ELECTRICAL UNIT (CONTROL UNIT) SELF-DIAGNOSIS

Ⓜ With CONSULT

- Turn ignition switch ON.
- Select "Self Diagnostic Result" mode of "ABS" using CONSULT, and repair or replace malfunctioning parts.
- Check DTC, and repair or replace malfunctioning parts. Refer to [BRC-50, "DTC Index"](#).

>> INSPECTION END

U0428 STEERING ANGLE SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

U0428 STEERING ANGLE SENSOR CALIBRATION

DTC Description

INFOID:000000011460281

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition
U0428	ST ANG SEN CALIB [Invalid data received from steering angle sensor module]	Steering calibration signal (incomplete status) is received from the steering angle sensor for 2 seconds or more continuously when the ignition switch is turned ON

POSSIBLE CAUSE

Adjustment of steering angle sensor neutral position is not completed

FAIL-SAFE

Fail-safe	
Swivel operation	Aiming operation
Right and left swivel motor swivel angle returns to 0° and fixed	—

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

④ With CONSULT

1. Turn ignition switch ON and wait at least 2 seconds.
2. Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
3. Check DTC.

Is DTC detected?

- YES >> Refer to [EXL-92, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011460282

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Perform adjustment of steering angle sensor neutral position. Refer to [BRC-67, "Work Procedure"](#).

NOTE:

Perform adjustment of steering angle sensor neutral position on VDC side. VDC may activate incorrectly.

>> INSPECTION END

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

U1000 CAN COMM CIRCUIT

DTC Description

INFOID:000000011460283

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition
U1000	CAN COMM CIRCUIT (CAN communication)	When AFS control unit does not transmit/receive CAN communication signal continuously for 2 seconds or more

POSSIBLE CAUSE

CAN communication system

FAIL-SAFE

Fail-safe	
Swivel operation	Aiming operation
Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected NOTE: Only when the vehicle speed signal or the low beam status signal cannot be received

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

④ With CONSULT

1. Turn ignition switch ON and wait at least 2 seconds.
2. Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
3. Check DTC.

Is DTC detected?

YES >> Refer to [EXL-93, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011460284

1. CHECK CAN COMMUNICATION SYSTEM

Perform trouble diagnosis for CAN communication system. Refer to [LAN-25, "Trouble Diagnosis Flow Chart"](#).

>> INSPECTION END

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

U1010 CONTROL UNIT (CAN)

DTC Description

INFOID:000000011460287

DTC DETECTION LOGIC

DTC No.	CONSULT screen terms (Trouble diagnosis content)	DTC detection condition
U1010	CONTROL UNIT(CAN) (CAN initial diagnosis abnormal)	AFS control unit detected internal CAN communication circuit malfunction

POSSIBLE CAUSE

AFS control unit

FAIL-SAFE

Fail-safe	
Swivel operation	Aiming operation
Right and left swivel motor swivel angle returns to 0° and fixed	Right and left headlamp aiming motors stop at the position when DTC is detected

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

Ⓔ With CONSULT

1. Turn ignition switch ON.
2. Select "Self Diagnostic Result" mode of "ADAPTIVE LIGHT" using CONSULT.
3. Check DTC.

Is DTC detected?

- YES >> Refer to [EXL-94, "Diagnosis Procedure"](#).
NO-1 >> To check malfunction symptom before repair: Refer to [GI-44, "Intermittent Incident"](#).
NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000011460288

1. REPLACE AFS CONTROL UNIT

Replace AFS control unit. Refer to [EXL-148, "Removal and Installation"](#).

>> INSPECTION END

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

POWER SUPPLY AND GROUND CIRCUIT

AFS CONTROL UNIT

AFS CONTROL UNIT : Diagnosis Procedure

INFOID:000000011460292

1. CHECK FUSE

1. Turn ignition switch OFF.
2. Check that any of the following fuse is fusing

Unit	Location	Fuse No.	Capacity
AFS control unit	Fuse block (J/B)	3	10 A

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2. CHECK AFS CONTROL UNIT POWER SUPPLY

1. Disconnect AFS control unit connector.
2. Turn ignition switch ON.
3. Check voltage between AFS control unit harness connector and ground.

+		-	Voltage
AFS control unit			
Connector	Terminal	Ground	9 – 16 V
E70	12		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK AFS CONTROL UNIT GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between AFS control unit harness connector and ground.

AFS control unit		—	Continuity
Connector	Terminal		
E70	11	Ground	Existed

Is the inspection result normal?

YES >> Power supply and ground circuit are normal.

NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

HEADLAMP (HI) CIRCUIT

Component Function Check

INFOID:0000000011460294

1. CHECK HEADLAMP (HI) OPERATION

④ With CONSULT

- Turn ignition switch ON.
- Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
- With operating the test items, check that the headlamp (HI) blinks.

Hi : Headlamp (HI) blinks (ON/OFF is repeated 1 second each.)

Off : Headlamp (HI) OFF

⊗ Without CONSULT

- Start IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
- Check that the headlamp (HI) blinks.

Is the inspection result normal?

YES >> Headlamp (HI) circuit is normal.

NO >> Refer to [EXL-96, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011460295

1. CHECK HEADLAMP (HI) FUSE

- Turn ignition switch OFF.
- Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp (HI) RH	IPDM E/R	#55	10 A
Headlamp (HI) LH		#54	

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2. CHECK HEADLAMP (HI) POWER SUPPLY

④ With CONSULT

- Turn ignition switch ON.
- Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
- With operating the test items, check voltage between IPDM E/R harness connector and ground.

+			-	Test item	Voltage	
IPDM E/R						
Connector	Terminal					
RH	E8	89	Ground	EXTERNAL LAMPS	Hi	9 – 16 V (Repeated 1 second)
		90			Off	0 – 1 V
LH					90	Hi
		Off				0 – 1 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).

HEADLAMP (HI) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

3. CHECK HEADLAMP (HI) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front combination lamp connector.
3. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E8	89	E49	Existed
LH		90	E48	

Is the inspection result normal?

- YES >> Perform the LED headlamp diagnosis. Refer to [EXL-100, "Diagnosis Procedure"](#).
NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

HEADLAMP (LO) CIRCUIT

Component Function Check

INFOID:000000011460296

1. CHECK HEADLAMP (LO) OPERATION

④ With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the headlamp (LO) is turned ON.

Lo : Headlamp (LO) ON

Off : Headlamp (LO) OFF

⊗ Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the headlamp (LO) is turned ON.

Is the inspection result normal?

- YES >> Headlamp (LO) circuit is normal.
NO >> Refer to [EXL-98, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011460297

1. CHECK HEADLAMP (LO) FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Headlamp (LO) RH	IPDM E/R	#57	15 A
Headlamp (LO) LH		#56	

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2. CHECK HEADLAMP (LO) POWER SUPPLY

④ With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check voltage between IPDM E/R harness connector and ground.

+			-	Test item	Voltage		
IPDM E/R							
Connector	Terminal						
RH	E8	83	Ground	EXTERNAL LAMPS	Lo	9 – 16 V	
						Off	0 – 1 V
LH		84				Lo	9 – 16 V
						Off	0 – 1 V

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).

3. CHECK HEADLAMP (LO) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front combination lamp connector.
3. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

HEADLAMP (LO) CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E8	83	E49	Existed
LH		84	E48	

Is the inspection result normal?

- YES >> Perform the LED headlamp diagnosis. Refer to [EXL-100, "Diagnosis Procedure"](#).
- NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

LED HEADLAMP

Diagnosis Procedure

INFOID:000000011460298

1.CHECK HEADLAMP GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front combination lamp connector.
3. Check continuity between front combination lamp harness connector and ground.

Front combination lamp		Terminal	—	Continuity
Connector				
RH	E49	3	Ground	Existed
LH	E48			

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Repair or replace harness.

2.CHECK LED HEADLAMP

Install the normal front combination lamp to the applicable headlamp. Check that the headlamp is turned ON. Refer to [EXL-74, "Work Procedure"](#).

Is the headlamp turned ON?

- YES >> Replace the corresponding front combination lamp. Refer to [EXL-137, "Removal and Installation"](#).
 NO >> LED headlamp is normal.

HEADLAMP WARNING

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

HEADLAMP WARNING

Component Function Check

INFOID:000000011460299

1.CHECK HEADLAMP WARNING OPERATION

1. Turn ignition switch ON.
2. Check that headlamp warning on combination meter is not displayed when lighting switch is turned 2ND.

Is the inspection result normal?

- YES >> Headlamp warning is normal.
 NO >> Refer to [EXL-101, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011460300

1.CHECK HEADLAMP WARNING SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front combination lamp connector.
3. Turn ignition switch ON.
4. Check voltage between front combination lamp harness connector and ground.

+		Terminal	-	Voltage (Approx.)
Front combination lamp				
Connector		2	Ground	12 V
RH	E49			
LH	E48			

Is the inspection result normal?

- YES >> Replace front combination lamp. Refer to [EXL-137, "Removal and Installation"](#).
 NO >> GO TO 2.

2.CHECK HEADLAMP WARNING SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between front combination lamp harness connector and combination meter harness connector.

Front combination lamp		Terminal	Combination meter		Continuity
Connector			Connector	Terminal	
RH	E49	2	M53	17	Existed
LH	E48			18	

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-94, "Removal and Installation"](#).
 NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

HEADLAMP LEVELIZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

HEADLAMP LEVELIZER CIRCUIT

Component Function Check

INFOID:000000011460301

1.CHECK HEADLAMP LEVELIZER OPERATION

④ With CONSULT

1. Turn ignition switch ON.
2. Turn lighting switch 2ND.
3. Select "LEVELIZER TEST" in "Active Test" mode of "ADAPTIVE LIGHT" using CONSULT.
4. With operating the test item, check light axis operation.

Test item		Light axis operation
LEVELIZER TEST	Peak	Moves the light axis to the lowest position.
	Origin	Moves the light axis to the initial position.

Is the inspection result normal?

- YES >> Headlamp levelizer circuit is normal.
NO >> Refer to [EXL-102, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011460302

1.CHECK HEADLAMP AIMING MOTOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect headlamp aiming motor connector.
3. Turn ignition switch ON.
4. Check voltage between headlamp aiming motor harness connector and ground.

+		Terminal	-	Voltage
Headlamp aiming motor				
Connector		1	Ground	Battery voltage
RH	E26			
LH	E56			

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair harness or connector between headlamp aiming motor and fuse.

2.CHECK HEADLAMP AIMING MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between headlamp aiming motor harness connector and ground.

Headlamp aiming motor		Terminal	—	Continuity
Connector				
RH	E26	2	Ground	Existed
LH	E56			

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3.CHECK AIMING MOTOR DRIVE SIGNAL

④ With CONSULT

1. Reconnect headlamp aiming motor connector.
2. Turn ignition switch ON.
3. Turn lighting switch 2ND.
4. Select "LEVELIZER TEST" in "Active Test" mode of "ADAPTIVE LIGHT" using CONSULT.

HEADLAMP LEVELIZER CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

5. With operating the test items, check voltage between AFS control unit harness connector and ground.

+		-	Test item	Voltage (Approx.)	
AFS control unit					
Connector	Terminal				
E70	22	Ground	LEVELIZER TEST	Peak	8.75 V
				Origin	3.75 V

Is the inspection result normal?

- YES >> GO TO 4.
 NO-1 >> Fixed at 0 V: GO TO 5.
 NO-2 >> Fixed at battery voltage: GO TO 6.

4.CHECK AIMING MOTOR DRIVE SIGNAL CIRCUIT (OPEN)

- Turn ignition switch OFF.
- Disconnect AFS control unit connector and headlamp aiming motor connector.
- Check continuity between AFS control unit harness connector and headlamp aiming motor harness connector.

AFS control unit			Headlamp aiming motor		Continuity
Connector	Terminal	Terminal	Connector	Terminal	
RH	E70	22	E26	3	Existed
LH			E56		

Is the inspection result normal?

- YES >> Replace front combination lamp. Refer to [EXL-137. "Removal and Installation"](#).
 NO >> Repair or replace harness.

5.CHECK AIMING MOTOR DRIVE SIGNAL CIRCUIT (SHORT TO GROUND)

- Turn ignition switch OFF.
- Disconnect AFS control unit connector and headlamp aiming motor connector.
- Check continuity between AFS control unit harness connector and ground.

AFS control unit		—	Continuity
Connector	Terminal		
E70	22	Ground	Not existed

Is the inspection result normal?

- YES >> Replace AFS control unit. Refer to [EXL-148. "Removal and Installation"](#).
 NO >> Repair or replace harness.

6.CHECK AIMING MOTOR DRIVE SIGNAL CIRCUIT (SHORT TO BATTERY)

- Turn ignition switch OFF.
- Disconnect AFS control unit connector and headlamp aiming motor connector.
- Check voltage between AFS control unit harness connector and ground.

+		-	Voltage (Approx.)
AFS control unit			
Connector	Terminal		
E70	22	Ground	0 V

Is the inspection result normal?

- YES >> Replace AFS control unit. Refer to [EXL-148. "Removal and Installation"](#).
 NO >> Repair or replace harness.

PARKING LAMP CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

PARKING LAMP CIRCUIT

Component Function Check

INFOID:000000011460305

1. CHECK TAIL LAMP OPERATION

Check that the tail lamp is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check tail lamp circuit. Refer to [EXL-106, "Component Function Check"](#).

2. CHECK PARKING LAMP OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the parking lamp is turned ON.

TAIL : Parking lamp ON
Off : Parking lamp OFF

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the parking lamp is turned ON.

Is the inspection result normal?

YES >> Parking lamp circuit is normal.

NO >> Refer to [EXL-104, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011460306

1. CHECK PARKING LAMP POWER SUPPLY

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check voltage between IPDM E/R harness connector and ground.

+		-	Test item	Voltage	
IPDM E/R					
Connector	Terminal				
E9	94	Ground	EXTERNAL LAMPS	TAIL	9 – 16 V
				Off	0 – 1 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).

2. CHECK PARKING LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front combination lamp connector.
3. Check continuity between IPDM E/R harness connector and front combination lamp harness connector.

IPDM E/R		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E9	94	E49	Existed
LH			E48	

Is the inspection result normal?

YES >> GO TO 3.

PARKING LAMP CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

3.CHECK PARKING LAMP GROUND CIRCUIT

Check continuity between front combination lamp harness connector and ground.

Front combination lamp		Terminal	—	Continuity
Connector				
RH	E49	4	Ground	Existed
LH	E48			

Is the inspection result normal?

YES >> Replace the corresponding front combination lamp. Refer to [EXL-137. "Removal and Installation"](#).

NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

TAIL LAMP CIRCUIT

Component Function Check

INFOID:0000000011460307

1. CHECK TAIL LAMP OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the tail lamp is turned ON.

TAIL : Tail lamp ON
Off : Tail lamp OFF

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the tail lamp is turned ON.

Is the inspection result normal?

- YES >> Tail lamp circuit is normal.
 NO >> Refer to [EXL-106, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011460308

1. CHECK FUSE

1. Turn ignition switch OFF.
2. Check that the following fuse is not fusing.

Unit	Location	Fuse No.	Capacity
Parking lamp RH	IPDM E/R	#52	10 A
Parking lamp LH			
Front side marker lamp RH			
Front side marker lamp LH			
Tail lamp RH (Body side)			
Rear side marker lamp RH			
Tail lamp RH (Trunk lid side)			
Tail lamp LH (Trunk lid side)			
License plate lamp RH			
License plate lamp LH			
Tail lamp LH (Body side)		#53	
Rear side marker lamp LH			

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2. CHECK TAIL LAMP POWER SUPPLY

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check voltage between IPDM E/R harness connector and ground.

TAIL LAMP CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

Tail lamp (Body side)

+			-	Test item	Voltage	
IPDM E/R						
Connector	Terminal					
RH	E9	102	Ground	EXTERNAL LAMPS	TAIL	9 – 16 V
					Off	0 – 1 V
LH	E7	55			TAIL	9 – 16 V
					Off	0 – 1 V

Tail lamp (Trunk lid side)

+		-	Test item	Voltage	
IPDM E/R					
Connector	Terminal				
E9	102	Ground	EXTERNAL LAMPS	TAIL	9 – 16 V
				Off	0 – 1 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).

3. CHECK TAIL LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and rear combination lamp connector.
3. Check continuity between IPDM E/R harness connector and rear combination lamp harness connector.

Tail lamp (Body side)

IPDM E/R		Rear combination lamp (Body side)		Continuity
Connector	Terminal	Connector	Terminal	
RH	E9	B260	1	Existed
LH	E7	B26		

Tail lamp (Trunk lid side)

IPDM E/R		Rear combination lamp (Trunk lid side)		Continuity	
Connector	Terminal	Connector	Terminal		
RH	E9	102	T15	3	Existed
LH			T16		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK TAIL LAMP GROUND CIRCUIT

Check continuity between rear combination lamp harness connector and ground.

Tail lamp (Body side)

Rear combination lamp (Body side)		—	Continuity
Connector	Terminal		
RH	B260	4	Existed
LH	B26		

TAIL LAMP CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

Tail lamp (Trunk lid side)

Rear combination lamp (Trunk lid side)		Terminal	—	Continuity
Connector				
RH	T15	4	Ground	Existed
LH	T16			

Is the inspection result normal?

- YES >> Replace the corresponding rear combination lamp. Refer to [EXL-153, "REAR COMBINATION LAMP \(BODY SIDE\) : Removal and Installation"](#) (body side) or [EXL-153, "REAR COMBINATION LAMP \(TRUNK LID SIDE\) : Removal and Installation"](#) (trunk lid side).
- NO >> Repair or replace harness.

LICENSE PLATE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

LICENSE PLATE LAMP CIRCUIT

Component Function Check

INFOID:000000011460309

1. CHECK TAIL LAMP OPERATION

Check that the tail lamp is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check tail lamp circuit. Refer to [EXL-106, "Component Function Check"](#).

2. CHECK LICENSE PLATE LAMP OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the license plate lamp is turned ON.

TAIL : License plate lamp ON

Off : License plate lamp OFF

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the license plate lamp is turned ON.

Is the inspection result normal?

YES >> License plate lamp circuit is normal.

NO >> Refer to [EXL-109, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011460310

1. CHECK LICENSE PLATE LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and license plate lamp connector.
3. Check continuity between IPDM E/R harness connector and license plate lamp harness connector.

IPDM E/R		License plate lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E9	T8	1	Existed
LH		T9		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

2. CHECK LICENSE PLATE LAMP GROUND CIRCUIT

Check continuity between license plate lamp harness connector and ground.

License plate lamp		—	Continuity
Connector	Terminal		
RH	T8	Ground	Existed
LH	T9		

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK LICENSE PLATE LAMP BULB

Check the applicable license plate lamp bulb.

LICENSE PLATE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

Is the inspection result normal?

- YES >> Replace the corresponding license plate lamp. Refer to [EXL-156, "Removal and Installation"](#).
- NO >> Replace the corresponding license plate lamp bulb. Refer to [EXL-156, "Replacement"](#).

DAYTIME RUNNING LIGHT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

DAYTIME RUNNING LIGHT CIRCUIT

Component Function Check

INFOID:000000011460311

1.CHECK DAYTIME RUNNING LIGHT OPERATION

Ⓜ With CONSULT

1. Select "HEAD LAMP" of "BCM" using CONSULT.
2. Select "DAYTIME RUNNING LIGHT" in "Active Test" mode.
3. With operating the test items, check that the daytime running light is turned ON.

On : Daytime running light ON

Off : Daytime running light OFF

Is the inspection result normal?

- YES >> Daytime running light circuit is normal.
 NO >> Refer to [EXL-111, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011460312

1.CHECK DAYTIME RUNNING LIGHT RELAY FUSES

1. Turn ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Daytime running light relay [Switch side (Daytime running light RH)]	IPDM E/R	#58	10 A
Daytime running light relay [Switch side (Daytime running light LH)]			
Daytime running light relay (Coil side)	Fuse block (J/B)	#11	

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK DAYTIME RUNNING LIGHT RELAY POWER SUPPLY

1. Remove daytime running light relay.
2. Check voltage between daytime running light relay harness connector and ground.

+		Terminal	-	Voltage
Daytime running light relay				
Connector				
Switch side (Daytime running light RH)	E50	7	Ground	Battery voltage
Switch side (Daytime running light LH)		5		
Coil side		2		

Is the inspection result normal?

- YES >> GO TO 4.
 NO-1 >> Switch side: GO TO 3.
 NO-2 >> Coil side: Check battery power supply circuit. Refer to [PG-12, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).

3.CHECK DAYTIME RUNNING LIGHT RELAY (SWITCH SIDE) POWER SUPPLY CIRCUIT

1. Disconnect IPDM E/R connector.

DAYTIME RUNNING LIGHT CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between daytime running light relay harness connector and IPDM E/R harness connector.

Daytime running light relay		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
Switch side (Daytime running light RH)	E50	E7	48	Existed
Switch side (Daytime running light LH)				

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).
 NO >> Repair or replace harness.

4. CHECK DAYTIME RUNNING LIGHT RELAY

Check daytime running light relay. Refer to [EXL-113, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace daytime running light relay.

5. CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL

Ⓟ With CONSULT

1. Install daytime running light relay.
2. Turn ignition switch ON.
3. Select "HEAD LAMP" of "BCM" using CONSULT.
4. Select "DAYTIME RUNNING LIGHT" in "Active Test" mode.
5. With operating the test item, check voltage between IPDM E/R harness connector and ground.

+		-	Test item	Voltage	
IPDM E/R					
Connector	Terminal				
E5	23	Ground	DAYTIME RUNNING LIGHT	On	0 – 1 V
				Off	9 – 16 V

Is the inspection result normal?

- YES >> GO TO 8.
 NO-1 >> Fixed at 0 – 1 V: GO TO 7.
 NO-2 >> Fixed at 9 – 16 V: GO TO 6.

6. CHECK DAYTIME RUNNING LIGHT REQUEST SIGNAL

Ⓟ With CONSULT

1. Select "DTRL REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
2. With operating the daytime running light ON condition, check the monitor status.

Monitor item	Condition	Monitor status	
DTRL REQ	Daytime running light	ON condition	On
		OFF condition	Off

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).
 NO >> Replace BCM. Refer to [BCS-91, "Removal and Installation"](#).

7. CHECK DAYTIME RUNNING LIGHT RELAY CONTROL SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Remove daytime running light relay.
3. Disconnect IPDM E/R connector.

DAYTIME RUNNING LIGHT CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between daytime running light relay harness connector and IPDM E/R harness connector.

Daytime running light relay		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
E50	1	E5	23	Existed

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-34. "Removal and Installation"](#).
 NO >> Repair or replace harness.

8.CHECK DAYTIME RUNNING LIGHT POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Remove daytime running light relay.
3. Disconnect front combination lamp connector.
4. Check continuity between daytime running light relay harness connector and front combination lamp harness connector.

Daytime running light relay		Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E50	6	E49	Existed
LH		3	E48	

Is the inspection result normal?

- YES >> GO TO 9.
 NO >> Repair or replace harness.

9.CHECK DAYTIME RUNNING LIGHT GROUND CIRCUIT

Check continuity between front combination lamp harness connector and ground.

Front combination lamp		—	Continuity
Connector	Terminal		
RH	E49	Ground	Existed
LH	E48		

Is the inspection result normal?

- YES >> Replace the corresponding front combination lamp. Refer to [EXL-137. "Removal and Installation"](#).
 NO >> Repair or replace harness.

Component Inspection

INFOID:000000011460313

1.CHECK DAYTIME RUNNING LIGHT RELAY

1. Turn ignition switch OFF.
2. Remove daytime running light relay.
3. Apply battery voltage to daytime running light relay between terminals 2 and 1.
4. Check continuity of daytime running light relay terminals.

Daytime running light relay		Condition	Continuity
Terminal			
7	6	Apply	Existed
		Not apply	Not existed
5	3	Apply	Existed
		Not apply	Not existed

Is the inspection result normal?

DAYTIME RUNNING LIGHT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

YES >> INSPECTION END
NO >> Replace daytime running light relay.

FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

FRONT FOG LAMP CIRCUIT

Component Function Check

INFOID:000000011460320

1. CHECK FRONT FOG LAMP OPERATION

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check that the front fog lamp is turned ON.

Fog : Front fog lamp ON

Off : Front fog lamp OFF

Without CONSULT

1. Start IPDM E/R auto active test. Refer to [PCS-11, "Diagnosis Description"](#).
2. Check that the front fog lamp is turned ON.

Is the measurement normal?

YES >> Front fog lamp circuit is normal.

NO >> Refer to [EXL-115, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011460321

1. CHECK FRONT FOG LAMP FUSE

1. Turn ignition switch OFF.
2. Check that the following fuses are not fusing.

Unit	Location	Fuse No.	Capacity
Front fog lamp	IPDM E/R	#59	15 A

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2. CHECK FRONT FOG LAMP POWER SUPPLY

With CONSULT

1. Turn ignition switch ON.
2. Select "EXTERNAL LAMPS" in "Active Test" mode of "IPDM E/R" using CONSULT.
3. With operating the test items, check the voltage between IPDM E/R harness connector and ground.

+		Terminal	-	Test item	Voltage	
IPDM E/R						
Connector		Terminal				
RH	E8	86	Ground	EXTERNAL LAMPS	Fog	9 – 16 V
				Off	0 – 1 V	
LH		87		Fog	9 – 16 V	
				Off	0 – 1 V	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).

3. CHECK FRONT FOG LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and front fog lamp connector.
3. Check continuity between IPDM E/R harness connector and front fog lamp harness connector.

FRONT FOG LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

IPDM E/R		Front fog lamp		Continuity
Connector	Terminal	Connector	Terminal	
RH	E8	86	E34	Existed
LH		87	E64	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK FRONT FOG LAMP GROUND CIRCUIT

Check continuity between front fog lamp harness connector and ground.

Front fog lamp		Terminal	—	Continuity
Connector	Terminal			
RH	E34	2	Ground	Existed
LH	E64			

Is the inspection result normal?

YES >> Replace the corresponding front fog lamp. Refer to [EXL-141. "Removal and Installation"](#).

NO >> Repair or replace harness.

TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

TURN SIGNAL LAMP CIRCUIT

Component Function Check

INFOID:0000000011460325

1. CHECK TURN SIGNAL LAMP OPERATION

④ With CONSULT

1. Turn ignition switch ON.
2. Select "FLASHER" of "BCM" using CONSULT.
3. Select "FLASHER" in "Active Test" mode.
4. With operating the test items, check that the turn signal lamps is turned ON.

RH : Turn signal lamps (RH) ON

LH : Turn signal lamps (LH) ON

Off : Turn signal lamps OFF

Is the inspection result normal?

- YES >> Turn signal lamp circuit is normal.
 NO >> Refer to [EXL-117, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000011460326

1. CHECK TURN SIGNAL LAMP POWER SUPPLY

④ With CONSULT

1. Turn ignition switch OFF.
2. Disconnect the following connectors.
 - Front turn signal lamp
 - Door mirror
 - Rear combination lamp
3. Turn ignition switch ON.
4. Select "FLASHER" of "BCM" using CONSULT.
5. Select "FLASHER" in "Active Test" mode.
6. With operating the test items, check voltage between BCM harness connector and ground.

Front turn signal lamp

+			-	Test item	Voltage	
BCM						
Connector	Terminal					
RH	M120	19	Ground	FLASHER	RH	9 – 16 V
					Off	0 V
LH		20			LH	9 – 16 V
					Off	0 V

Side turn signal lamp / Rear turn signal lamp

+			-	Test item	Voltage	
BCM						
Connector	Terminal					
RH	M122	61	Ground	FLASHER	RH	9 – 16 V
					Off	0 V
LH		60			LH	9 – 16 V
					Off	0 V

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK TURN SIGNAL LAMP POWER SUPPLY CIRCUIT (SHORT)

TURN SIGNAL LAMP CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and ground.

Front turn signal lamp

BCM			—	Continuity
Connector		Terminal		
RH	M120	19	Ground	Not existed
LH		20		

Side turn signal lamp / Rear turn signal lamp

BCM			—	Continuity
Connector		Terminal		
RH	M122	61	Ground	Not existed
LH		60		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-91, "Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK TURN SIGNAL LAMP POWER SUPPLY CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and each turn signal lamp harness connector.

Front turn signal lamp

BCM			Front turn signal lamp		Continuity
Connector		Terminal	Connector	Terminal	
RH	M120	19	E66	1	Existed
LH		20	E65		

Side turn signal lamp

BCM			Door mirror		Continuity
Connector		Terminal	Connector	Terminal	
RH	M122	61	D33	2	Existed
LH		60	D3		

Rear turn signal lamp

BCM			Rear combination lamp (Body side)		Continuity
Connector		Terminal	Connector	Terminal	
RH	M122	61	B260	3	Existed
LH		60	B26		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK TURN SIGNAL LAMP GROUND CIRCUIT

Check continuity between each turn signal lamp harness connector and ground.

Front turn signal lamp

Front turn signal lamp			—	Continuity
Connector		Terminal		
RH	E66	2	Ground	Existed
LH	E65			

TURN SIGNAL LAMP CIRCUIT

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

Side turn signal lamp

Door mirror		Terminal	—	Continuity
Connector				
RH	D33	19	Ground	Existed
LH	D3			

Rear turn signal lamp

Rear combination lamp		Terminal	—	Continuity
Connector				
RH	B260	4	Ground	Existed
LH	B26			

Is the inspection result normal?

- YES-1 >> Front turn signal lamp: Replace the corresponding front turn signal lamp. Refer to [EXL-139, "Removal and Installation"](#).
- YES-2 >> Side turn signal lamp: Replace the corresponding side turn signal lamp. Refer to [MIR-42, "DOOR MIRROR : Disassembly and Assembly"](#).
- YES-3 >> Rear turn signal lamp: GO TO 5.
- NO >> Repair or replace harness.

5. CHECK REAR TURN SIGNAL LAMP BULB

Check the applicable rear turn signal lamp bulb.

Is the inspection result normal?

- YES >> Check the corresponding rear turn signal lamp bulb socket and harness. Repair or replace if necessary.
- NO >> Replace the corresponding rear turn signal lamp bulb.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL

OPTICAL SENSOR

Component Function Check

INFOID:000000011460327

1.CHECK OPTICAL SENSOR SIGNAL

④ With CONSULT

1. Turn ignition switch ON.
2. Select "HEAD LAMP" of "BCM" using CONSULT.
3. Select "OPTI SEN (DTCT)" in "Data Monitor" mode.
4. Turn lighting switch AUTO.
5. With the optical sensor illuminating, check the monitor status.

Monitor item	Condition		Voltage (Approx.)
OPTI SEN (DTCT)	Optical sensor	When illuminating	3.1 V or more *
		When shutting off light	0.6 V or less

*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

Is the inspection result normal?

YES >> Optical sensor is normal.

NO >> Refer to [EXL-120, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011460328

1.CHECK OPTICAL SENSOR POWER SUPPLY

1. Turn ignition switch ON.
2. Turn lighting switch AUTO.
3. Check voltage between optical sensor harness connector and ground.

+		-	Voltage
Optical sensor			
Connector	Terminal		
M94	1	Ground	4.65 – 5.5 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2.CHECK OPTICAL SENSOR GROUND

Check voltage between optical sensor harness connector and ground.

+		-	Voltage
Optical sensor			
Connector	Terminal		
M94	3	Ground	0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 6.

3.CHECK OPTICAL SENSOR SIGNAL

With illuminating the optical sensor, check voltage between optical sensor harness connector and ground.

OPTICAL SENSOR

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

+		-	Condition	Voltage (Approx.)
Optical sensor				
Connector	Terminal			
M94	2	Ground	Optical sensor	When illuminating 3.1 V or more*
				When shutting off light 0.6 V or less

*: Illuminate the optical sensor. The value may be less than the standard if brightness is weak.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace optical sensor. Refer to [EXL-144, "Removal and Installation"](#).

4. CHECK OPTICAL SENSOR POWER SUPPLY CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M94	1	M120	17	Existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5. CHECK OPTICAL SENSOR POWER SUPPLY CIRCUIT (SHORT)

Check continuity between optical sensor harness connector and ground.

Optical sensor		—	Continuity
Connector	Terminal		
M94	1	Ground	Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-91, "Removal and Installation"](#).

NO >> Repair or replace harness.

6. CHECK OPTICAL SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M94	3	M120	18	Existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-91, "Removal and Installation"](#).

NO >> Repair or replace harness.

7. CHECK OPTICAL SENSOR SIGNAL CIRCUIT (OPEN)

1. Turn ignition switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

OPTICAL SENSOR

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M94	2	M120	14	Existed

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

8. CHECK OPTICAL SENSOR SIGNAL CIRCUIT (SHORT)

Check continuity between optical sensor harness connector and ground.

Optical sensor		—	Continuity
Connector	Terminal		
M94	2	Ground	Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-91, "Removal and Installation"](#).

NO >> Repair or replace harness.

HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

HAZARD SWITCH

Component Function Check

INFOID:000000011460329

1.CHECK HAZARD SWITCH SIGNAL

Ⓜ With CONSULT

1. Turn ignition switch ON.
2. Select "FLASHER" of "BCM" using CONSULT.
3. Select "HAZARD SW" in "Data Monitor" mode.
4. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the inspection result normal?

- YES >> Hazard switch circuit is normal.
 NO >> Refer to [EXL-123, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000011460330

1.CHECK HAZARD SWITCH SIGNAL

1. Turn ignition switch OFF.
2. Disconnect multifunction switch connector.
3. Check voltage between multifunction switch connector and ground.

+		-	Voltage
Multifunction switch			
Connector	Terminal	Ground	9 – 16 V
M72	16		

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> GO TO 2.

2.CHECK HAZARD SWITCH SIGNAL CIRCUIT (OPEN)

1. Disconnect BCM connector.
2. Check continuity between multifunction switch harness connector and BCM harness connector.

Multifunction switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M72	16	M120	29	Existed

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK HAZARD SWITCH SIGNAL CIRCUIT (SHORT)

Check continuity between multifunction switch harness connector and ground.

Multifunction switch		—	Continuity
Connector	Terminal		
M72	16	Ground	Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-91, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
M
N
O
P

EXL

HAZARD SWITCH

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

4. CHECK HAZARD SWITCH GROUND CIRCUIT

Check continuity between multifunction switch harness connector and ground.

Multifunction switch		—	Continuity
Connector	Terminal		
M72	1	Ground	Existed

Is the inspection result normal?

YES >> Replace multifunction switch. Refer to [AV-137, "Removal and Installation"](#) (without navigation) or [AV-420, "Removal and Installation"](#) (with navigation).

NO >> Repair or replace harness.

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

SYMPTOM DIAGNOSIS

EXTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:0000000011460331

NOTE:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp (HI) is not turned ON	One side	<ul style="list-style-type: none"> • Fuse • Headlamp (HI) power supply circuit • Front combination lamp <ul style="list-style-type: none"> - LED [Headlamp (HI)] - LED headlamp control module - Harness • IPDM E/R 	Headlamp (HI) circuit Refer to EXL-96, "Component Function Check" .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to EXL-129, "Diagnosis Procedure" .	
High beam indicator lamp is not turned ON [Headlamp (HI) is turned ON]		Combination meter	<ul style="list-style-type: none"> • Combination meter Data monitor "HI-BEAM IND" • BCM (HEAD LAMP) Active test "HEAD LAMP"
Headlamp (LO) is not turned ON	One side	<ul style="list-style-type: none"> • Fuse • Headlamp (LO) power supply circuit • Front combination lamp <ul style="list-style-type: none"> - LED [Headlamp (LO)] - LED headlamp control module - Harness • IPDM E/R 	Headlamp (LO) circuit Refer to EXL-98, "Component Function Check" .
	Both sides	Symptom diagnosis "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to EXL-130, "Diagnosis Procedure" .	
Headlamp (HI) and (LO) is not turned ON		<ul style="list-style-type: none"> • Headlamp ground circuit • Front combination lamp - LED headlamp control module - Harness 	LED headlamp Refer to EXL-100, "Diagnosis Procedure" .
Headlamp warning remains ON [Headlamp (LO) is turned ON]		<ul style="list-style-type: none"> • Headlamp warning signal circuit • Front combination lamp - LED headlamp control module - Harness • Combination meter 	Headlamp warning Refer to EXL-101, "Component Function Check" .
Each lamp is not turned ON/OFF with lighting switch AUTO		<ul style="list-style-type: none"> • Combination switch input/output signal circuit • Combination switch • BCM 	Combination switch Refer to BCS-89, "Symptom Table" .
		<ul style="list-style-type: none"> • Optical sensor power supply/ground/signal circuit • Optical sensor • BCM 	Optical sensor Refer to EXL-120, "Component Function Check" .
Parking lamp is not turned ON		<ul style="list-style-type: none"> • Parking lamp power supply/ground circuit • Front combination lamp <ul style="list-style-type: none"> - LED (Parking lamp) - Control circuit - Harness • IPDM E/R 	Parking lamp circuit Refer to EXL-104, "Component Function Check" .

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

Symptom	Possible cause	Inspection item
Front side marker lamp is not turned ON (Parking lamp is turned ON)	<ul style="list-style-type: none"> • Front combination lamp - LED (Side marker lamp) - Control circuit - Harness 	Replace front combination lamp Refer to EXL-137, "Removal and Installation" .
Rear side marker lamp is not turned ON [Tail lamp (body side) is turned ON]	<ul style="list-style-type: none"> • Rear combination lamp (Body side) - LED (Side marker lamp) - Harness 	Replace rear combination lamp (Body side) Refer to EXL-153, "REAR COMBINATION LAMP (BODY SIDE) : Removal and Installation" .
Tail lamp is not turned ON	<ul style="list-style-type: none"> • Fuse • Tail lamp power supply/ground circuit • Rear combination lamp (Body side / Trunk lid side) - LED (Tail lamp) • IPDM E/R 	Tail lamp circuit Refer to EXL-106, "Component Function Check" .
License plate lamp is not turned ON	<ul style="list-style-type: none"> • License plate lamp power supply/ground circuit • License plate lamp bulb • License plate lamp 	License plate lamp circuit Refer to EXL-109, "Component Function Check" .
Parking lamp, license plate lamp, side marker lamp and tail lamp are not turned ON	<p>Symptom diagnosis "PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON" Refer to EXL-131, "Diagnosis Procedure".</p>	
Position lamp indicator lamp is not turned ON (Parking lamp, license plate lamp, side marker lamp and tail lamp are turned ON)	Combination meter	<ul style="list-style-type: none"> • Combination meter Data monitor "LIGHT IND" • BCM (HEAD LAMP) Active test "TAIL LAMP"
Daytime running light is not turned ON	<ul style="list-style-type: none"> • Fuse • Daytime running light relay power supply/control signal circuit • Daytime running light relay • Daytime running light power supply/ground circuit • Front combination lamp - LED (Daytime running light) - Control circuit - Harness • IPDM E/R • BCM • ECM • Combination meter 	<ul style="list-style-type: none"> • Daytime running light circuit Refer to EXL-111, "Component Function Check". • BCM (HEAD LAMP) Data monitor "ENGINE STATE" • Combination meter Data monitor "PKB SW"
Front fog lamp is not turned ON	One side	<ul style="list-style-type: none"> • Front fog lamp power supply/ground circuit • Front fog lamp • IPDM E/R
	Both sides	<p>Symptom diagnosis "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to EXL-115, "Diagnosis Procedure".</p>
Front fog lamp indicator lamp is not turned ON (Front fog lamp is turned ON)	Combination meter	<ul style="list-style-type: none"> • Combination meter Data monitor "FR FOG IND" • BCM (HEAD LAMP) Active test "FR FOG LAMP"

EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

Symptom	Possible cause	Inspection item	
Turn signal lamp does not blink	<ul style="list-style-type: none"> • Front turn signal lamp - Front turn signal lamp power supply/ground circuit - Front turn signal lamp - BCM • Side turn signal lamp - Side turn signal lamp power supply/ground circuit - Side turn signal lamp - BCM • Rear turn signal lamp - Rear turn signal lamp power supply/ground circuit - Rear turn signal lamp bulb - Rear turn signal lamp bulb socket/harness - BCM 	Turn signal lamp circuit Refer to EXL-117, "Component Function Check" .	
	Indicator lamp is included	<ul style="list-style-type: none"> • Combination switch input/output signal circuit • Combination switch • BCM 	Combination switch Refer to BCS-89, "Symptom Table" .
Turn signal indicator lamp does not blink (Turn signal lamp is normal)	One side	Combination meter —	
	Both sides (Always)	<ul style="list-style-type: none"> • Turn indicator signal • BCM • Combination meter 	<ul style="list-style-type: none"> • Combination meter Data monitor "TURN IND" • BCM (FLASHER) Active test "FLASHER"
	Both sides (Only when activating hazard warning lamp with ignition switch OFF)	<ul style="list-style-type: none"> • Combination meter power supply/ground circuit • Combination meter 	Combination meter Power supply and ground circuit Refer to MWI-74, "COMBINATION METER : Diagnosis Procedure" .
<ul style="list-style-type: none"> • Hazard warning lamp does not activate (Turn signal is normal) • Hazard warning lamp continues activating 	<ul style="list-style-type: none"> • Hazard switch signal/ground circuit • Multifunction switch (Hazard switch) • BCM 	Hazard switch Refer to EXL-123, "Component Function Check" .	
Headlamp auto aiming does not activate (AFS is normal)	<ul style="list-style-type: none"> • Headlamp aiming motor power supply/ground/drive signal circuit • Front combination lamp (Headlamp aiming motor) • AFS control unit 	Headlamp levelizer circuit Refer to EXL-102, "Component Function Check" .	
AFS OFF indicator lamp is not turned ON	<ul style="list-style-type: none"> • AFS OFF indicator lamp signal • AFS control unit • Combination meter 	Combination meter Data monitor "AFS OFF IND"	

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

NORMAL OPERATING CONDITION

Description

INFOID:000000011460332

LED HEADLAMP

- LED brightness and color may slightly change until the temperature becomes stable. This is not malfunction.
- Illumination time lag may occur between right and left. This is not malfunction.
- Brightness may be reduced due to aged deterioration of LED.

AUTO LIGHT SYSTEM

The headlamp may not be turned ON/OFF immediately after passing dark area or bright area (short tunnel, sky bridge, shadowed area etc.) while using the auto light system. This causes for the control difference. This is normal.

BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

Description

INFOID:000000011460333

Both side headlamps (HI) are not turned ON when setting to the lighting switch HI or PASS.

Diagnosis Procedure

INFOID:000000011460334

1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-89, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK HIGH BEAM REQUEST SIGNAL

 With CONSULT

1. Turn ignition switch ON.
2. Select "HL HI REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
3. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL HI REQ	Lighting switch (2ND)	HI or PASS	On
		LO	Off

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-91, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

Description

INFOID:000000011460335

Both side headlamps (LO) are not turned ON in any condition.

Diagnosis Procedure

INFOID:000000011460336

1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-89, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK LOW BEAM REQUEST SIGNAL

ⓅWith CONSULT

1. Turn ignition switch ON.
2. Select "HL LO REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
3. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HL LO REQ	Lighting switch	2ND	On
		OFF	Off

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-91, "Removal and Installation"](#).

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

Description

INFOID:000000011460337

The parking, license plate and tail lamps are not turned ON in any condition.

Diagnosis Procedure

INFOID:000000011460338

1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-89, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK POSITION LIGHT REQUEST SIGNAL

 With CONSULT

1. Select "TAIL & CLR REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.

2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status
TAIL & CLR REQ	Lighting switch	1ST
		OFF
		On
		Off

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-91, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

Description

INFOID:000000011460339

Both side front fog lamps are not turned ON in any condition.

Diagnosis Procedure

INFOID:000000011460340

1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-89, "Symptom Table"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

2.CHECK FRONT FOG LIGHT REQUEST SIGNAL

ⓅWith CONSULT

1. Turn power switch ON.
2. Select "FR FOG REQ" in "Data Monitor" mode of "IPDM E/R" using CONSULT.
3. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition	Monitor status	
FR FOG REQ	Front fog lamp switch (With lighting switch 1ST)	ON	On
		OFF	Off

Is the inspection result normal?

YES >> Perform the front fog lamp diagnosis. Refer to [EXL-115, "Component Function Check"](#).

NO >> Replace BCM. Refer to [BCS-91, "Removal and Installation"](#).

HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[LED HEADLAMP]

PERIODIC MAINTENANCE

HEADLAMP AIMING ADJUSTMENT

Description

INFOID:0000000011516233

PREPARATION BEFORE ADJUSTING

NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the luggage room.)

NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.


- Wipe out dirt on the headlamp.

CAUTION:

Never use organic solvent (thinner, gasoline etc.)

- Ride alone on the driver seat.

AIMING ADJUSTMENT SCREW



A. Headlamp LH (UP/DOWN) adjustment screw

B. Headlamp RH (UP/DOWN) adjustment screw

← : Vehicle front

NOTE:

The figure is the vehicle without AFS. Each adjustment screw is applied to the vehicle with AFS.

Adjustment screw		Screw driver rotation	Facing direction
A	Headlamp LH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP
B	Headlamp RH (UP/DOWN)	Clockwise	DOWN
		Counterclockwise	UP

Aiming Adjustment Procedure

INFOID:0000000011516234

1. Place the screen.

NOTE:

HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[LED HEADLAMP]

- Stop the vehicle facing the wall.
 - Place the board on a plain road vertically.
2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the headlamp center and the screen.
 3. Turn ignition switch ON. Turn the headlamp (LO) ON.

CAUTION:

Never cover lens surface with a tape etc. The lens is made of resin.


NOTE:

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.

4. Measure the distance (X) between the horizontal center line of headlamp (H) and the cut off line (A) within the light axis measurement range (R) from the vertical center line ahead of headlamp (V).

Light axis measurement range (R) : 350 – 175 mm (13.78 – 6.89 in)

Low beam distribution on the screen




5. Adjust the cutoff line height (X) with the aiming adjustment screw so as to enter in the adjustment range (M–N) according to the horizontal center line of headlamp (H).

unit: mm (in)

Horizontal center line of headlamp (H)	Highest cutoff line height (M)	Lowest cutoff line height (N)
700 (27.56) or less	4 (0.16)	30 (1.18)
701(27.60) – 800 (31.50)	4 (0.16)	30 (1.18)
801 (31.54) or more	17 (0.67)	44 (1.73)

Side view



Distance between the headlamp center and the screen (L) : 10 m (32.8 ft)

FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[LED HEADLAMP]

FRONT FOG LAMP AIMING ADJUSTMENT

Description

INFOID:000000011516235

PREPARATION BEFORE ADJUSTING

NOTE:

- For details, refer to the regulations in your own country.
- Perform aiming if the vehicle front body has been repaired and/or the headlamp assembly has been replaced.

Before performing aiming adjustment, check the following.

- Adjust the tire pressure to the specification.
- Fill with fuel, engine coolant and each oil.
- Maintain the unloaded vehicle condition. (Remove luggage from the passenger compartment and the trunk room.)

NOTE:

Do not remove the temporary tire, jack and on-vehicle tool.

- Wipe out dirt on the headlamp.

CAUTION:

Never use organic solvent (thinner, gasoline etc.)

- Ride alone on the driver seat.

AIMING ADJUSTMENT SCREW

- Turn the aiming adjusting screw for adjustment.


A: DOWN

B: UP

- For the position and direction of the adjusting screw, refer to the figure.

NOTE:

A screwdriver or hexagonal wrench [6 mm (0.24 in)] can be used for adjustment.



Aiming Adjustment Procedure

INFOID:000000011516236

1. Place the screen.

NOTE:

- Stop the vehicle facing the wall.
- Place the board on a plain road vertically.

2. Face the vehicle with the screen. Maintain 10 m (32.8 ft) between the front fog lamp center and the screen.

3. Start the engine. Turn the front fog lamp ON.

NOTE:

Shut off the headlamp light with the board to prevent from illuminating the adjustment screen.

CAUTION:

Never cover the lens surface with a tape etc. The lens is made of resin.

4. Adjust the cutoff line height (A) with the aiming adjustment screw so that the distance (X) between the horizontal center line of front fog lamp (H) and (A) becomes 100 mm (3.94 in).


A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[LED HEADLAMP]

Front fog lamp light distribution on the screen



- A : Cutoff line
- B : High illuminance area
- H : Horizontal center line of front fog lamp
- V : Vertical center line of front fog lamp
- X : Cutoff line height

FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]


REMOVAL AND INSTALLATION

FRONT COMBINATION LAMP

Exploded View


INFOID:0000000011515978

REMOVAL



1. Front combination lamp

DISASSEMBLY



1. Front combination lamp housing
2. Bumper bracket

Removal and Installation

INFOID:0000000011515979

REMOVAL

CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-6, "Precautions for Removing Battery Terminal"](#).

1. Remove front bumper fascia. Refer to [EXT-16, "Removal and Installation"](#).
2. Remove the washer inlet tube (RH side only).
3. Remove front combination lamp assembly mounting bolts.
4. Remove the harness clip.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

FRONT COMBINATION LAMP

[LED HEADLAMP]

< REMOVAL AND INSTALLATION >

5. Pull out the front combination lamp assembly forward the vehicle, and then disconnect the connector before removing the front combination lamp assembly.

INSTALLATION

Note the following item, and then install in the reverse order of removal.

NOTE:

After installation, perform aiming adjustment. Refer to [EXL-133, "Aiming Adjustment Procedure"](#).

Replacement

INFOID:000000011515980

CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-6, "Precautions for Removing Battery Terminal"](#).

HEADLAMP (HI/LO)

CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace front combination lamp as a set. Refer to [EXL-137, "Removal and Installation"](#).

DAYTIME RUNNING LIGHT/ PARKING LAMP

CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace front combination lamp as a set. Refer to [EXL-137, "Removal and Installation"](#).

FRONT SIDE MARKER LAMP

CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace front combination lamp as a set. Refer to [EXL-137, "Removal and Installation"](#).

Disassembly and Assembly

INFOID:000000011515981

DISASSEMBLY

Remove bumper bracket mounting screws, and then remove bumper bracket from front combination lamp housing.

ASSEMBLY

Note the following item, and then install in the reverse order of removal.

CAUTION:

After installation, perform aiming adjustment. Refer to [EXL-133, "Aiming Adjustment Procedure"](#).

FRONT TURN SIGNAL LAMP ASSEMBLY


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

FRONT TURN SIGNAL LAMP ASSEMBLY

Exploded View

INFOID:000000011515970



- 1. Front bumper fascia
- 2. Front turn signal lamp
- 3. Front fog lamp
- 4. U nut

 : N·m (kg-m, in-lb)

Removal and Installation

INFOID:000000011515971

REMOVAL

CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-6, "Precautions for Removing Battery Terminal"](#).

1. Remove front fender protector to make work space. Refer to [EXT-26, "FENDER PROTECTOR : Removal and Installation"](#).
2. Remove front fog lamp. Refer to [EXL-141, "Removal and Installation"](#).
3. Disconnect front turn signal lamp harness connector.
4. Remove front turn signal lamp fixing clip and then remove front turn signal lamp.

INSTALLATION

Install in the reverse order of removal.

Replacement

INFOID:000000011515972

CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-6, "Precautions for Removing Battery Terminal"](#).

FRONT TURN SIGNAL LAMP

CAUTION:

FRONT TURN SIGNAL LAMP ASSEMBLY

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

Replacement of a single part is not possible due to the adoption of LED bulb. For replacement, replace front turn signal lamp assembly as a set. Refer to [EXL-139, "Removal and Installation"](#).

FRONT FOG LAMP


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

FRONT FOG LAMP

Exploded View

INFOID:000000011515983



- 1. Front bumper fascia
- 2. Front turn signal lamp
- 3. Front fog lamp
- 4. U nut

 : N·m (kg-m, in-lb)

Removal and Installation

INFOID:000000011515984

CAUTION:
Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-6, "Precautions for Removing Battery Terminal"](#).

REMOVAL

1. Remove front fender protector to make work space. Refer to [EXT-26, "FENDER PROTECTOR : Removal and Installation"](#).
2. Disconnect front fog lamp connector.
3. Remove front fog lamp fixing screws and then remove front fog lamp.

INSTALLATION

Note the following item, and then install in the reverse order of removal.

NOTE:

After installation, perform aiming adjustment. Refer to [EXL-135, "Aiming Adjustment Procedure"](#).

Replacement

INFOID:000000011515985

CAUTION:
Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-6, "Precautions for Removing Battery Terminal"](#).

FRONT FOG LAMP

CAUTION:

FRONT FOG LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

Replacement of a single part is not possible due to the adoption of LED bulb. For replacement, replace front fog lamp assembly as a set. Refer to [EXL-141, "Removal and Installation"](#).

SIDE TURN SIGNAL LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

SIDE TURN SIGNAL LAMP

Exploded View

INFOID:0000000011890806

Refer to [MIR-41, "Exploded View"](#).

Removal and Installation

INFOID:0000000011890804

Refer to [MIR-42, "DOOR MIRROR : Disassembly and Assembly"](#).

Replacement

INFOID:0000000011890805

CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-6, "Precautions for Removing Battery Terminal"](#).

SIDE TURN SIGNAL LAMP

CAUTION:


Replacement of a single part is not possible due to the adoption of LED. For replacement, replace side turn signal lamp as a set. Refer to [EXL-143, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

OPTICAL SENSOR

Exploded View

INFOID:000000011256336



1. Optical sensor

Removal and Installation

INFOID:000000011256337

REMOVAL

1. Insert an appropriate tool between the optical sensor and the instrument upper panel. Pull out the optical sensor upward.
2. Disconnect the optical sensor connector. And then remove the optical sensor.

INSTALLATION

Install in the reverse order of removal.

LIGHTING AND TURN SIGNAL SWITCH

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

LIGHTING AND TURN SIGNAL SWITCH

Exploded View

INFOID:000000011256338

Lighting and turn signal switch is integrated in the combination switch. [BCS-92. "Removal and Installation"](#).

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- EXL
- M
- N
- O
- P

HAZARD SWITCH

Exploded View

INFOID:000000011256339

The hazard warning switch is integrated in the multifunction switch. Refer to [AV-137. "Removal and Installation"](#).

AFS SWITCH

Exploded View

INFOID:000000011890815

Refer to [MWI-95. "Exploded View"](#).

Removal and Installation

INFOID:000000011890814


Refer to [MWI-95. "Removal and Installation"](#).

- A
- B
- C
- D
- E
- F
- G
- H
- I
- J
- K
- EXL
- M
- N
- O
- P

AFS CONTROL UNIT

Exploded View

INFOID:000000011256340



1. Dash side panel

2. AFS control unit

Removal and Installation

INFOID:000000011256341

REMOVAL

CAUTION:

- Before replacing AFS control unit, perform “READ CONFIGURATION” to save or print current vehicle specification. Refer to [EXL-76, "Description"](#).
- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-6, "Precautions for Removing Battery Terminal"](#).

1. Remove the instrument lower panel LH. Refer to [JP-13, "Removal and Installation"](#).
2. Remove the AFS control unit mounting nuts.
3. Disconnect the AFS control unit connector.
4. Remove the AFS control unit.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

- Be sure to perform “WRITE CONFIGURATION” when replacing AFS control unit. Or not doing so, AFS control function does not operate normally. Refer to [EXL-76, "Work Procedure"](#).
- Be sure to perform “SENSOR INITIALIZE” when replacing AFS control unit. Refer to [EXL-78, "Description"](#).

STEERING ANGLE SENSOR

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

STEERING ANGLE SENSOR

Removal and Installation

INFOID:000000011256342

Refer to [SR-14. "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

HEIGHT SENSOR


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

HEIGHT SENSOR

Exploded View

INFOID:000000011256343



- 1. Height sensor
- A Height sensor mounting nut
- B. Height sensor lever link bracket mounting bolt

Removal and Installation

INFOID:000000011256344

REMOVAL

1. Remove the height sensor mounting nut.
2. Remove the height sensor lever link bracket mounting bolt.
3. Disconnect the height sensor connector.
4. Remove the height sensor.

INSTALLATION

Install in the reverse order of removal.

CAUTION:

Be sure to perform "SENSOR INITIALIZE" when removing the height sensor. Refer to [EXL-78](#), "[Description](#)".

REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]


REAR COMBINATION LAMP

Exploded View

INFOID:000000011256345

REMOVAL

Rear Combination Lamp (body side)



1. Grommet

2. Clip

3. Rear combination lamp (body side)

4. Rear combination lamp finisher

○ : Clip

△ : Pawl


Rear Combination Lamp (trunk lid side)

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

REAR COMBINATION LAMP


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]



- 1. Trunk lid assembly
- 2. Rear combination lamp (trunk lid side)

DISASSEMBLY



- 1. Rear combination lamp (trunk lid side)
- 2. Seal packing
- 3. Seal packing
- 4. Seal packing
- 5. Rear turn signal lamp
- 6. Rear combination lamp (body side)

⊗ : Always replace after every disassembly

REAR COMBINATION LAMP (BODY SIDE)

REAR COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

REAR COMBINATION LAMP (BODY SIDE) : Removal and Installation

INFOID:000000011891145

CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-6, "Precautions for Removing Battery Terminal"](#).

REMOVAL

1. Fully open trunk lid.
2. Remove the trunk side finisher. Refer to [INT-64, "TRUNK SIDE FINISHER : Removal and Installation"](#).
3. Disconnect the rear combination lamp harness connector.
4. Remove the rear combination lamp mounting nuts.
5. Pull the rear combination lamp toward vehicle rear, and then remove the rear combination lamp.
6. Remove the seal packing.
7. Remove the rear combination lamp finisher after removing rear combination lamp.

INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

Seal packing can not be reused.

REAR COMBINATION LAMP (BODY SIDE) : Replacement

INFOID:000000011891146

CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-6, "Precautions for Removing Battery Terminal"](#).
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it.
- Never touch bulb by hand while it is lit or right after being turned OFF.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

TAIL LAMP

CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace rear combination lamp assembly (body side) as a set. Refer to [EXL-153, "REAR COMBINATION LAMP \(BODY SIDE\) : Removal and Installation"](#).

STOP LAMP

CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace rear combination lamp assembly (body side) as a set. Refer to [EXL-153, "REAR COMBINATION LAMP \(BODY SIDE\) : Removal and Installation"](#).

REAR TURN SIGNAL LAMP

1. Remove the rear combination lamp (body side). Refer to [EXL-153, "REAR COMBINATION LAMP \(BODY SIDE\) : Removal and Installation"](#).
2. Rotate the rear turn signal lamp bulb socket counterclockwise and unlock it.
3. Remove the rear turn signal lamp bulb from rear turn signal lamp bulb socket.

REAR SIDE MARKER LAMP

CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace rear combination lamp assembly (body side) as a set. Refer to [EXL-153, "REAR COMBINATION LAMP \(BODY SIDE\) : Removal and Installation"](#).

REAR COMBINATION LAMP (TRUNK LID SIDE)

REAR COMBINATION LAMP (TRUNK LID SIDE) : Removal and Installation

INFOID:000000011891147

CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-6, "Precautions for Removing Battery Terminal"](#).

REAR COMBINATION LAMP

[LED HEADLAMP]

< REMOVAL AND INSTALLATION >

REMOVAL

1. Remove the trunk lid finisher. Refer to [INT-64, "TRUNK SIDE FINISHER : Removal and Installation"](#).
2. Disconnect the rear combination lamp harness connector.
3. Remove the rear combination lamp mounting nuts.
4. Pull the rear combination lamp toward vehicle rear, and then remove the rear combination lamp.
5. Remove the seal packing.

INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

Seal packing cannot be reused.

REAR COMBINATION LAMP (TRUNK LID SIDE) : Replacement

INFOID:000000011891148

CAUTION:

Disconnect the battery negative terminal or remove power circuit fuse when performing the operation for preventing electric leakage. Refer to [EXL-6, "Precautions for Removing Battery Terminal"](#).

TAIL LAMP

CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace rear combination lamp assembly (trunk lid side) as a set. Refer to [EXL-153, "REAR COMBINATION LAMP \(TRUNK LID SIDE\) : Removal and Installation"](#).

BACK-UP LAMP

CAUTION:

Replacement of a single part is not possible due to the adoption of LED. For replacement, replace rear combination lamp assembly (trunk lid side) as a set. Refer to [EXL-153, "REAR COMBINATION LAMP \(TRUNK LID SIDE\) : Removal and Installation"](#).

HIGH-MOUNTED STOP LAMP


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

HIGH-MOUNTED STOP LAMP

Exploded View

INFOID:000000011256347



1. Rear parcel shelf finisher

2. High-mounted stop lamp

3. High-mounted stop lamp cover

← : Vehicle front

△ : Pawl

Removal and Installation

INFOID:000000011256348

REMOVAL

1. Remove the rear parcel shelf finisher. Refer to [INT-53. "Removal and Installation"](#).
2. Remove the high-mounted stop lamp cover fixing screws.
3. Remove the high-mounted stop lamp.

INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
K
EXL
M
N
O
P

LICENSE PLATE LAMP


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

LICENSE PLATE LAMP

Exploded View

INFOID:000000011256352



1. License plate lamp

2. License plate lamp bulb

3. License plate lamp lens

 : Pawl

Removal and Installation

INFOID:000000011256353

CAUTION:

Disconnect the battery negative terminal or remove the fuse.

REMOVAL

1. Remove the screw, and then remove the license plate lamp.
2. Disconnect the license plate lamp connector.

INSTALLATION

Install in the reverse order of removal.

Replacement


INFOID:000000011256354

CAUTION:

- Disconnect the battery negative terminal or remove the fuse to prevent electric leakage.
- Never touch the glass of bulb directly by hand. Keep grease and other oily matters away from it to prevent damage to the bulb.
- Never touch bulb by hand while it is lit or right after being turned off to prevent burns.
- Never leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

LICENSE PLATE LAMP BULB

1. Remove the license lamp. Refer to [EXL-156. "Removal and Installation"](#).
2. Disengage license lamp lens (1) fixing pawls, with a flat-bladed screwdriver (A).
3. Remove the bulb.



SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[LED HEADLAMP]

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Bulb Specifications

INFOID:0000000011256355

Item		Type	Wattage (W)
Front combination lamp	Headlamp (HI/LO)	LED	—
	Parking lamp/ daytime running light		
	Parking lamp (upper side)/ daytime running light (upper side)		
	Front side marker lamp		
Front turn signal lamp		LED	—
Front fog lamp		LED	—
Side turn signal lamp (built in door mirror)		LED	—
Rear combination lamp (body side)	Stop lamp	LED	—
	Tail lamp	LED	—
	Rear side marker lamp	LED	—
	Rear turn signal lamp	W21W	21
Rear combination lamp (trunk lid side)	Tail lamp	LED	—
	Back-up lamp		
License plate lamp		W5W	5
High-mounted stop lamp		LED	—

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

EXL