

# SECTION **INL**

## INTERIOR LIGHTING SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

### CONTENTS

<p><b>PRECAUTION</b> ..... 3</p> <p><b>PRECAUTIONS</b> ..... 3</p> <p style="padding-left: 20px;">Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....3</p> <p style="padding-left: 20px;">Precautions for Removing of Battery Terminal .....3</p> <p><b>SYSTEM DESCRIPTION</b> ..... 4</p> <p><b>COMPONENT PARTS</b> ..... 4</p> <p><b>INTERIOR LIGHTING SYSTEM</b> .....4</p> <p style="padding-left: 20px;">INTERIOR LIGHTING SYSTEM : Component Parts Location .....4</p> <p style="padding-left: 20px;">INTERIOR LIGHTING SYSTEM : Component Description .....4</p> <p><b>SYSTEM</b> ..... 6</p> <p><b>INTERIOR ROOM LAMP CONTROL SYSTEM</b> .....6</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP CONTROL SYSTEM : System Diagram .....6</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP CONTROL SYSTEM : System Description .....6</p> <p><b>INTERIOR ROOM LAMP BATTERY SAVER SYSTEM</b> .....8</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Diagram .....9</p> <p style="padding-left: 20px;">INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description .....9</p> <p><b>ILLUMINATION CONTROL SYSTEM</b> .....10</p> <p style="padding-left: 20px;">ILLUMINATION CONTROL SYSTEM : System Diagram .....10</p> <p style="padding-left: 20px;">ILLUMINATION CONTROL SYSTEM : System Description .....10</p> <p><b>AUTO LIGHT ADJUSTMENT SYSTEM</b> .....10</p> <p style="padding-left: 20px;">AUTO LIGHT ADJUSTMENT SYSTEM : System Diagram .....11</p>	<p style="padding-left: 20px;">AUTO LIGHT ADJUSTMENT SYSTEM : System Description .....11</p> <p><b>DIAGNOSIS SYSTEM (BCM)</b> .....12</p> <p><b>COMMON ITEM</b> .....12</p> <p style="padding-left: 20px;">COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) .....12</p> <p><b>INT LAMP</b> .....13</p> <p style="padding-left: 20px;">INT LAMP : CONSULT Function (BCM - INT LAMP) .....14</p> <p><b>BATTERY SAVER</b> .....15</p> <p style="padding-left: 20px;">BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER) .....15</p> <p><b>ECU DIAGNOSIS INFORMATION</b> .....18</p> <p><b>BCM</b> .....18</p> <p style="padding-left: 20px;">List of ECU Reference .....18</p> <p><b>WIRING DIAGRAM</b> .....19</p> <p><b>INTERIOR ROOM LAMP CONTROL SYSTEM</b> .....19</p> <p style="padding-left: 20px;">Wiring Diagram .....19</p> <p><b>ILLUMINATION</b> .....35</p> <p style="padding-left: 20px;">Wiring Diagram .....35</p> <p><b>BASIC INSPECTION</b> .....54</p> <p><b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....54</p> <p style="padding-left: 20px;">Work Flow .....54</p> <p><b>DTC/CIRCUIT DIAGNOSIS</b> .....57</p> <p><b>INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT</b> .....57</p> <p style="padding-left: 20px;">Description .....57</p> <p style="padding-left: 20px;">Component Function Check .....57</p> <p style="padding-left: 20px;">Diagnosis Procedure .....57</p>
---	--



<b>INTERIOR ROOM LAMP CONTROL CIRCUIT</b>	<b>59</b>	<b>REAR DOOR ASHTRAY ILLUMINATION</b>	<b>72</b>
Description	59	Exploded View	72
Component Function Check	59	Removal and Installation	72
Diagnosis Procedure	59	Replacement	72
<b>TRUNK ROOM LAMP CIRCUIT</b>	<b>61</b>	<b>GLOVE BOX LAMP</b>	<b>73</b>
Description	61	Exploded View	73
Diagnosis Procedure	61	Removal and Installation	73
<b>STEP LAMP CIRCUIT</b>	<b>62</b>	Replacement	73
Description	62	<b>FOOT LAMP</b>	<b>74</b>
Component Function Check	62	<b>DRIVER SIDE</b>	<b>74</b>
Diagnosis Procedure	62	DRIVER SIDE : Exploded View	74
<b>OUTSIDE HANDLE LAMP CIRCUIT</b>	<b>64</b>	DRIVER SIDE : Removal and Installation	74
Description	64	DRIVER SIDE : Replacement	74
Diagnosis Procedure	64	<b>PASSENGER SIDE</b>	<b>75</b>
<b>PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT</b>	<b>65</b>	PASSENGER SIDE : Exploded View	75
Description	65	PASSENGER SIDE : Removal and Installation	75
Component Function Check	65	PASSENGER SIDE : Replacement	76
Diagnosis Procedure	65	<b>STEP LAMP</b>	<b>77</b>
<b>SYMPTOM DIAGNOSIS</b>	<b>67</b>	Exploded View	77
<b>INTERIOR LIGHTING SYSTEM SYMPTOMS</b>	<b>67</b>	Removal and Installation	77
Symptom Table	67	Replacement	77
<b>REMOVAL AND INSTALLATION</b>	<b>68</b>	<b>PERSONAL LAMP</b>	<b>78</b>
<b>MAP LAMP</b>	<b>68</b>	Exploded View	78
Exploded View	68	Removal and Installation	78
Removal and Installation	68	Replacement	79
Replacement	69	<b>OUTSIDE HANDLE LAMP</b>	<b>80</b>
<b>VANITY MIRROR LAMP</b>	<b>70</b>	Exploded View	80
Exploded View	70	<b>TRUNK ROOM LAMP</b>	<b>81</b>
Replacement	70	Exploded View	81
<b>CIGARETTE LIGHTER ILLUMINATION</b>	<b>71</b>	Removal and Installation	81
Exploded View	71	Replacement	82
Removal and Installation	71	<b>SERVICE DATA AND SPECIFICATIONS</b>	<b>83</b>
Replacement	71	<b>(SDS)</b>	<b>83</b>
		<b>SERVICE DATA AND SPECIFICATIONS</b>	<b>83</b>
		<b>(SDS)</b>	<b>83</b>
		bulb specifications	

# PRECAUTIONS

< PRECAUTION >

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010098499

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precautions for Removing of Battery Terminal

INFOID:000000010281873

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

#### **NOTE:**

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


#### **NOTE:**

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

#### **NOTE:**

The removal of 12V battery may cause a DTC detection error.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### INTERIOR LIGHTING SYSTEM

#### INTERIOR LIGHTING SYSTEM : Component Parts Location

INFOID:000000010098500



- |  |   |                                 |
|--|---|---------------------------------|
| 1. Personal lamp   | 2. Remote keyless entry receiver<br>Refer to <a href="#">DLK-9, "DOOR LOCK SYSTEM : Component Parts Location"</a> . | 3. Optical sensor               |
| 4. IPDM E/R<br>Refer to <a href="#">PCS-5, "IPDM E/R : Component Parts Location"</a> .   | 5. BCM<br>Refer to <a href="#">BCS-4, "BODY CONTROL SYSTEM : Component Parts Location"</a> .                        | 6. Door lock and unlock switch  |
| 7. Outside handle lamp   | 8. Front door request switch (driver side)  | 9. Step lamp                    |
| 10. Door switch  | 11. Front door lock assembly (driver side) (door key cylinder switch, unlock sensor)                                | 12. Trunk closure assembly      |
| 13. Trunk room lamp  | 14. Vanity mirror lamp  | 15. Combination meter           |
| 16. Combination switch   | 17. Foot lamp   | 18. Push-button ignition switch |
| 19. AV control unit <ul style="list-style-type: none"> <li>• Base audio without navigation:<br/>Refer to <a href="#">AV-11, "Component Parts Location"</a>.</li> <li>• BOSE audio with navigation: Refer to <a href="#">AV-148, "Component Parts Location"</a>.</li> </ul> | 20. Map lamp  |                                 |

#### INTERIOR LIGHTING SYSTEM : Component Description

INFOID:000000010098501

Part	Description
BCM	Controls the interior lighting system.
IPDM E/R	Controls the integrated relay according to the request signal from BCM (via CAN communication).
Remote keyless entry receiver	Receives the lock/unlock signal from Intelligent Key.
Combination switch (Lighting & turn signal switch)	Refer to <a href="#">BCS-7, "COMBINATION SWITCH READING SYSTEM : System Description"</a> .

# COMPONENT PARTS

## < SYSTEM DESCRIPTION >

Part	Description
<ul style="list-style-type: none"><li>• Door lock and unlock switch</li><li>• Door request switch</li><li>• Door key cylinder switch</li></ul>	Inputs the lock/unlock signal to BCM.
Door switch	Inputs the door switch signal to BCM.
Trunk closure assembly	Inputs the trunk lid open/close status signal to BCM.
Unlock sensor	Detects door lock condition of driver side door.
Optical sensor	Refer to <a href="#">EXL-9, "EXTERIOR LIGHTING SYSTEM : Component Description"</a> .

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

# SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM

### INTERIOR ROOM LAMP CONTROL SYSTEM

#### INTERIOR ROOM LAMP CONTROL SYSTEM : System Diagram

INFOID:000000010098502



#### INTERIOR ROOM LAMP CONTROL SYSTEM : System Description

INFOID:000000010098503

##### OUTLINE


- Interior room lamps\* are controlled by interior room lamp timer control function of BCM.  
\*: Map lamp, foot lamp and personal lamp (when map lamp switch and personal lamp switch are in DOOR position).
- Step lamp is controlled by step lamp control function of BCM.
- Trunk room lamp is controlled by trunk room lamp control function of BCM.
- Outside handle lamp is controlled by outside handle lamp timer control function of BCM.
- Push-button ignition switch illumination is controlled by the push-button ignition switch illumination control function of BCM.
- Interior room lamps and outside handle lamp are illuminated by welcome light function of Intelligent Key system. Refer to [DLK-23. "WELCOME LIGHT FUNCTION : System Description"](#).

##### INTERIOR ROOM LAMP TIMER CONTROL

# SYSTEM

## < SYSTEM DESCRIPTION >

### Interior Room Lamp Timer Basic Operation



#### NOTE:

A: Sets the interior room lamp gradual brightening and dimming time.

B: Gradually dims from 100% to 0% and gradually brightens 0% to 100% in 1 second.

- The interior room lamp turns ON and OFF (gradual brightening and dimming) by the interior room lamp timer.
- BCM judges the vehicle condition with the following items. It activates the interior room timer.
  - Ignition switch status
  - Door switch signal
  - Door lock/unlock signal (Remote keyless entry receiver, each door request switch, door key cylinder switch, door lock/unlock switch)

#### NOTE:

Each function of interior room lamp timer can be set by CONSULT. Refer to [INL-14, "INT LAMP : CONSULT Function \(BCM - INT LAMP\)"](#).

#### Interior Room Lamp ON Operation

- BCM always turns the interior room lamp ON when any door opens.
- When all doors are closed, and any all door unlock operation is performed or ignition switch is turned OFF, BCM brightens interior room lamp to 30% brightness and maintains 30% brightness until any door opens.
- BCM activates the interior room timer in any of the following conditions to turn the interior room lamp ON for a period of time.
  - Any door opens before all doors close.
  - Ignition switch is turned ON → OFF.
  - Any door unlock signal is detected when all doors close with ignition switch OFF.

#### NOTE:

The timer is restarted if new condition is input during the timer operating time.

#### Interior Room Lamp OFF Operation

BCM stops the timer in any of the following conditions to turns the interior room lamp OFF.

- The interior room lamp timer operating time is expired with all doors closed.
- Ignition switch position is other than OFF with all doors close.
- Any door lock operation is detected with all doors close.

#### TRUNK ROOM LAMP CONTROL

BCM controls the trunk room lamp (ground-side) to turn ON when trunk lid is open.

#### STEP LAMP CONTROL

BCM controls the step lamp (ground-side) to turn ON with any door switch ON.

#### OUTSIDE HANDLE LAMP TIMER CONTROL

#### Outside Handle Lamp Timer Basic Operation

- BCM controls the ground to turn the outside handle lamp ON.
- The outside handle lamp turns ON and OFF by the outside handle lamp timer.
- BCM judges the vehicle condition with the following items. It activates the outside handle lamp timer.
  - Ignition switch status
  - Door switch signal
  - Door lock/unlock signal (remote keyless entry receiver, each door request switch)

# SYSTEM

## < SYSTEM DESCRIPTION >

---

- Driver side door lock status

### Outside Handle Lamp ON Operation

BCM activates the outside handle lamp timer in any of the following conditions to turn the outside handle lamp ON for a period of time.

- Any door opens.
- Any door opens before all doors close.
- Ignition switch is turned ON → OFF.
- Door unlock signal by remote keyless entry receiver or each door request switch is detected.
- Driver side door is locked

### **NOTE:**

The timer is restarted if new condition is input during the timer operating time.

### Outside Handle Lamp OFF Operation

BCM stops the timer in any of the following conditions to turns the outside handle lamp OFF.

- The outside handle lamp timer operating time is expired.
- The interior room lamp OFF conditions.
- The interior room lamp timer operating time is expired.

## PUSH-BUTTON IGNITION SWITCH ILLUMINATION CONTROL

### Push-button Ignition Switch Illumination Basic Operation

BCM controls the ON/OFF status of push-button ignition switch illumination according to vehicle status.

### Heart Beat Operation

BCM repeats brightening and dimming operation of push-button ignition switch illumination when any of the following conditions are satisfied.

- Welcome light function operates.
- When ignition switch is OFF and any of the following conditions are satisfied.
  - Driver door changes from closed to open
  - Intelligent Key ID comparison is OK and driver side door changes from open to closed
  - ID comparison by Intelligent Key transponder is OK
  - Driver door is unlocked

### Illumination ON Operation

When ignition switch is change from OFF to ON, push-button ignition switch illumination turns ON.

### Dimming Operation

When ignition switch is change from ON to OFF, driver side is open and driver side door unlocked, push-button ignition switch illumination dims to 50% brightness.

### Illumination OFF Operation

Push-button ignition switch illumination turns OFF when ignition switch turns OFF, while push-button ignition switch illumination is in ON status.

When push-button ignition switch illumination is at 50% brightness or, when in heartbeat status any of the following conditions are satisfied, push-button ignition switch illumination turns OFF.

- Driver side door from unlock to lock.
- 15 seconds after start of heartbeat operation.
- When welcome light function is not operating and any on the following conditions is satisfied.
  - Driver side door is closed
  - Intelligent Key ID comparison is NG
  - Comparison of Intelligent Key ID by transponder is NG

## INTERIOR ROOM LAMP BATTERY SAVER SYSTEM




# SYSTEM

< SYSTEM DESCRIPTION >

## INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Diagram

INFOID:000000010098504



## INTERIOR ROOM LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000010098505

### OUTLINE

- Interior room lamp battery saver is controlled by BCM.
- BCM turns applicable lamps OFF depending on the vehicle condition. This function prevents the battery from over-discharging if the driver neglect turning OFF the any lamps.

### Applicable lamps

- Map lamp
- Personal lamp
- Foot lamp
- Trunk room lamp
- Step lamp
- Outside handle lamp
- Vanity mirror lamp

### INTERIOR ROOM LAMP BATTERY SAVER FUNCTION

- When the ignition switch is turned is other position than ON, BCM operates the timer for a period of time to cut the interior room lamp power supply.
- BCM restart the timer when any of the following signals changes while operating the timer.
  - Ignition switch status
  - Door switch signal (ALL)
  - Trunk lid open/close status signal
  - Door lock/unlock signal (remote keyless entry receiver, each door request switch, door lock and unlock switch, door key cylinder switch)
- BCM provides the interior room lamp power supply continuously when the ignition switch position is ON.
- When welcome light function operates.

### NOTE:


# SYSTEM

## < SYSTEM DESCRIPTION >

Each function of interior room lamp battery saver can be set by CONSULT. Refer to [INL-15. "BATTERY SAVER : CONSULT Function \(BCM - BATTERY SAVER\)"](#).

## ILLUMINATION CONTROL SYSTEM

### ILLUMINATION CONTROL SYSTEM : System Diagram



### ILLUMINATION CONTROL SYSTEM : System Description

INFOID:000000010098507

#### OUTLINE

Each illumination lamp is controlled by each function of BCM and IPDM E/R.

Control by BCM

- Combination switch reading function
- Headlamp control function

Control by IPDM E/R

- Relay control function

Control by combination meter

- Meter illumination control function (Refer to [MWI-16. "METER ILLUMINATION CONTROL : System Description"](#).)

#### ILLUMINATION CONTROL

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits position light request signal to IPDM E/R and combination meter according to tail lamp ON condition.

Tail lamp ON condition

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment (With auto light system)
- IPDM E/R turns the integrated tail lamp relay ON according to position light request signal. It provides the power supply to each illumination lamp.
- Combination meter enters in the nighttime mode according to position light request signal. Under the nighttime mode the combination meter controls the illuminance by controlling the each illumination lamp (ground side).


## AUTO LIGHT ADJUSTMENT SYSTEM

# SYSTEM

< SYSTEM DESCRIPTION >

## AUTO LIGHT ADJUSTMENT SYSTEM : System Diagram

INFOID:0000000110098508



## AUTO LIGHT ADJUSTMENT SYSTEM : System Description

INFOID:0000000110098509

### OUTLINE

Auto light adjustment system is controlled by each function of BCM, combination meter and AV control unit

Control by BCM

- Auto light system
- Auto light adjustment system

### AUTO LIGHT ADJUSTMENT SYSTEM

Description

- BCM supplies voltage to the optical sensor when the ignition switch is turned ON or ACC.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM judges dims/brightness of combination meter and display according to brightness outside the vehicle, when ignition switch is ON.
- BCM transmits dimmer signal to combination meter via CAN communication, according to auto light adjustment conditions. Dimmer signal is also transmitted to AV control unit.

#### NOTE:

As to dims/brightness timing, the sensitivity depends on settings. The settings can be changed with CONSULT. Refer to [EXL-27. "HEADLAMP : CONSULT Function \(BCM - HEAD LAMP\)"](#).

Auto Light Adjustment Timing Table

When the ignition switch is ON, the combination meter and display turns dims/brightness in the following condition.

Combination meter and display	Dims/brightness timing
Dims	Outside brightness is 1250 lx or less for 3 seconds or more.
Brightness	Outside brightness is 2500 lx or more for 5 seconds or more.

BCM turns combination meter and display dims when outside brightness obtained from the optical sensor signal is 1250 lx or less for 3 seconds or more. And BCM turns combination meter and display brightness when outside brightness from the optical sensor signal is 2500 lx or more for 5 seconds or more.

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

#### COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000010281921

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>

#### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
—	AIR CONDITONER*		×	×
<ul style="list-style-type: none"> <li>Intelligent Key system</li> <li>Engine start system</li> </ul>	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
IVIS - NATS	IMMU	×	×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Trunk lid open	TRUNK		×	
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
—	AIR PRESSURE MONITOR*	×	×	×

\*: This item is not used.

#### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

CONSULT screen item	Indication/Unit	Description		
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected		A
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected		
Vehicle Condition	SLEEP>LOCK	Power position status of the moment a particular DTC is detected*	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*)	B
	SLEEP>OFF		While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)	C
	LOCK>ACC		While turning power supply position from "LOCK" *to "ACC"	
	ACC>ON		While turning power supply position from "ACC" to "IGN"	D
	RUN>ACC		While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)	
	CRANK>RUN		While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)	E
	RUN>URGENT		While turning power supply position from "RUN" to "ACC" (Emergency stop operation)	
	ACC>OFF		While turning power supply position from "ACC" to "OFF"	F
	OFF>LOCK		While turning power supply position from "OFF" to "LOCK"*	
	OFF>ACC		While turning power supply position from "OFF" to "ACC"	G
	ON>CRANK		While turning power supply position from "IGN" to "CRANKING"	
	OFF>SLEEP		While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode	H
	LOCK>SLEEP		While turning BCM status from normal mode (Power supply position is "LOCK"*. ) to low power consumption mode	
	LOCK		Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)*	I
	OFF		Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)	J
	ACC		Power supply position is "ACC" (Ignition switch ACC)	
	ON		Power supply position is "IGN" (Ignition switch ON with engine stopped)	K
ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)			
CRANKING	Power supply position is "CRANKING" (At engine cranking)	INL		
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>		M

### NOTE:

\*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

### INT LAMP


# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

## INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:000000010098511

### WORK SUPPORT



Service item	Setting item	Setting
SET I/L D-UNLCK INTCON	On*	With the interior room lamp timer function
	Off	Without the interior room lamp timer function
ROOM LAMP TIMER SET	MODE 2	7.5 sec.
	MODE 3*	15 sec.
	MODE 4	30 sec.
ROOM LAMP ON TIME SET	MODE 1	0.5 sec.
	MODE 2	1 sec.
	MODE 3	2 sec.
	MODE 4	3 sec.
	MODE 5	0 sec.
	MODE 6*	Gradually brightens from 0% to 100% brightness in 1 second.
ROOM LAMP OFF TIME SET	MODE 1	0.5 sec.
	MODE 2	1 sec.
	MODE 3	2 sec.
	MODE 4	3 sec.
	MODE 5	0 sec.
	MODE 6*	Gradually dims from 100% to 0% in 1 second.
R LAMP TIMER LOGIC SET	MODE 1*	Interior room lamp timer activates with synchronizing all doors.
	MODE 2	Interior room lamp timer activates with synchronizing the driver door only.

\*: Factory setting

### DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from request switch (passenger side)

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Monitor item [Unit]	Description	
REQ SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.	A
REQ SW-RL [On/Off]		B
PUSH SW [On/Off]	Push switch status input from push-button ignition switch	C
UNLK SEN -DR [On/Off]	Driver door unlock status input from unlock sensor	
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)	D
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)	E
DOOR SW-RR [On/Off]	The switch status input from rear door switch RH	
DOOR SW- RL [On/Off]	The switch status input from rear door switch LH	F
DOOR SW- BK [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.	G
CDL LOCK SW [On/Off]	Lock switch status input from door lock and unlock switch	
CDL UNLOCK SW [On/Off]	Unlock switch status input from door lock and unlock switch	H
KEY CYL LK-SW [On/Off]	Lock switch status received from key cylinder lock/unlock switch	I
KEY CYL UN-SW [On/Off]	Unlock switch status received from key cylinder lock/unlock switch	
TRNK/HAT MNTR [On/Off]	Trunk lid open/close status received from trunk closure assembly	J
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver	K
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver	

## ACTIVE TEST

INL

Test item	Operation	Description	
INT LAMP	On	Outputs the interior room lamp control signal to turn the interior room lamps ON. [Map lamp, personal lamp, foot lamp (when applicable lamps switch is in DOOR position.)]	M
	Off	Stops the interior room lamp control signal to turn the interior room lamps OFF.	N
STEP LAMP TEST	On	Outputs the step lamp control signal to turn the step lamps ON.	
	Off	Stops the step lamp control signal to turn the step lamps ON.	O

## BATTERY SAVER

### BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:0000000010098512

P

## WORK SUPPORT

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Service item	Setting item	Setting	
ROOM LAMP TIMER SET	MODE 1*	30 min.	Sets the interior room lamp battery saver timer operating time.
	MODE 2	60 min.	
	MODE 3	15 min.	
BATTERY SAVER SET	On*	With the exterior lamp battery saver function	
	Off	Without the exterior lamp battery saver function	

\*:Factory setting

## DATA MONITOR

Monitor item [Unit]	Description
REQ SW-DR [On/Off]	The switch status input from request switch (driver side)
REQ SW-AS [On/Off]	The switch status input from request switch (passenger side)
REQ SW-RR [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
REQ SW-RL [On/Off]	
PUSH SW [On/Off]	Push switch status input from push-button ignition switch
UNLK SEN-DR [On/Off]	Driver door unlock status input from unlock sensor
DOOR SW-DR [On/Off]	The switch status input from front door switch (driver side)
DOOR SW-AS [On/Off]	The switch status input from front door switch (passenger side)
DOOR SW-RR [On/Off]	The switch status input from rear door switch RH
DOOR SW- RL [On/Off]	The switch status input from rear door switch LH
DOOR SW- BK [On/Off]	<b>NOTE:</b> The item is indicated, but not monitored.
CDL LOCK SW [On/Off]	Lock switch status input from door lock and unlock switch
CDL UNLOCK SW [On/Off]	Unlock switch status input from door lock and unlock switch
KEY CYL LK-SW [On/Off]	Lock switch status received from key cylinder lock/unlock switch
KEY CYL UN-SW [On/Off]	Unlock switch status received from key cylinder lock/unlock switch
TRNK/HAT MNTR [On/Off]	Trunk lid open/close status received from trunk closure assembly
RKE-LOCK [On/Off]	Lock signal status received from remote keyless entry receiver
RKE-UNLOCK [On/Off]	Unlock signal status received from remote keyless entry receiver

## ACTIVE TEST



# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

Test item	Operation	Description
BATTERY SAVER	Off	Cuts the interior room lamp power supply to turn interior room lamps OFF.
	On	Outputs the interior room lamp power supply to turn interior room lamps ON.*

\*: Each lamp switch is in ON position.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P

# BCM

< ECU DIAGNOSIS INFORMATION >

## ECU DIAGNOSIS INFORMATION

### BCM

#### List of ECU Reference

INFOID:0000000010098513

ECU	Reference
BCM	<a href="#">BCS-33, "Reference Value"</a>
	<a href="#">BCS-53, "Fail-safe"</a>
	<a href="#">BCS-54, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-54, "DTC Index"</a>

# INTERIOR ROOM LAMP CONTROL SYSTEM


< WIRING DIAGRAM >

## WIRING DIAGRAM

### INTERIOR ROOM LAMP CONTROL SYSTEM

Wiring Diagram

INFOID:0000000010098514



2013/10/22

JRLWD1135GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >


\* : This connector is not shown in "Harness Layout".



JRLWD1136GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >



JRLWD1138GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

## INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH80PW-CS16-TM4




Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	LG	-
4	BR	-
5	P	-
6	V	-
7	GR	-
8	Y	-
9	LG	-
10	V	-
11	GR	- [With climate controlled seat]
11	L	- [With heated seat]
12	GR	- [With heated seat]
12	P	- [With climate controlled seat]
13	BR	-
14	R	-
15	O	-
16	V	-
17	B	-
18	R	-
19	W	-
20	R	-
21	B	-
22	LG	-
23	V	-
24	Y	-
25	G	-
26	GR	-
27	SB	-
28	W	-
29	W	-
30	SHIELD	-
32	R	-
33	R	-
34	L	-
35	R	-

36	G	-
37	SB	-
38	SHIELD	-
39	CS	-
40	SEV	-
41	W/L	-
42	L	-
44	B	-
45	W	-
47	O	-
48	Y	-
49	BR	-
50	SB	-
51	V	-
52	LG	-
53	G	-
54	BR	-
55	LG	-
56	Y	-
60	W	-
61	B	-
62	LG	-
63	V	-
65	O	-
66	BR	-
67	V	-
68	LG	-
69	GR	-
70	R	-
72	P	-
74	L	-
75	P	-
76	Y	-
77	R	-
78	W	-
79	G	-
80	L	-
81	LG	-
82	BR	-
83	SB	-
84	Y	-
85	R	-
86	R	-
87	G	-
88	GR	-
81	SB	-
92	G	-
96	Y	-

37	O	-
38	CS	-
39	CS	-

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Type	TH4DMW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	L	-
5	B/W	-
6	L	-
7	R	-
8	B	-
9	W	-
10	LG	-
11	P	-
12	GR	-
13	BR	-
14	SB	-
15	G	-
16	G	-
17	Y	-
18	BR	-
19	GR	-
20	O	-
21	LG	-
22	L	-
23	SB	-
24	V	-
27	Y	-
28	SB	-
29	SB	-
30	LG	-
31	LG	-
32	O	-
33	V	-
34	BR	-

35	B/R	-
36	G	-
37	BR	-
38	W	-
39	O	-
40	L	-
41	SHIELD	-
42	W/L	-
43	L/O	-
44	R	-
45	Y	-
46	V	-
47	SB	-
48	GR	-
49	LG	-
50	B	-
51	G	-
52	R	-
53	B	-
54	V	-
55	W	-

Connector No.	B18
Connector Name	FRONT DOOR SWITCH LH
Connector Type	AQ3FW



Terminal No.	Color Of Wire	Signal Name [Specification]
2	LG	-


JRLWD1139GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >



JRLWD1140GB



# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

## INTERIOR ROOM LAMP CONTROL SYSTEM


44	SB	-
45	R	-
46	B	-
53	L	-
54	B	-

Connector No.	B21B
Connector Name	FRONT DOOR SWITCH RH
Connector Type	A03FW



Terminal No.	2
Color Of Wire	GR
Signal Name [Specification]	-

Connector No.	B21B
Connector Name	WIRE TO WIRE
Connector Type	IN11PW-CSD



Terminal No.	1	
Color Of Wire	LG	
Signal Name [Specification]	-	
2	GR	-
3	O	-
4	P	-
7	B	-
8	C	-
10	W	-
11	O	-
12	Y	-
13	B	-

Connector No.	B223
Connector Name	REAR DOOR SWITCH RH
Connector Type	A03FW




Terminal No.	2
Color Of Wire	BR
Signal Name [Specification]	-

Connector No.	B276
Connector Name	WIRE TO WIRE
Connector Type	NS16MW-CS



Terminal No.	1	
Color Of Wire	R	
Signal Name [Specification]	-	
2	GR	-
3	V	-
5	W	-
6	R	-
8	B	-
9	O	-
10	B/R	-
11	L	-
12	L/W	-
13	L/R	-
14	B/R	-
15	Y	-


Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-CS15



Terminal No.	1	
Color Of Wire	B	
Signal Name [Specification]	-	
2	B	-
5	B	-
6	L	-
7	R	-
8	GR	-
9	G	-
10	LG	-
11	P	-
12	LG	-
13	B/W	-
14	Y	-
15	O	-
16	R	-
17	BR	-
18	W	-
19	W	-
20	O	-
21	GR	-
22	G	-
23	LG	-
24	B	-
27	V	-
28	W	-
29	GR	-
30	G	-
31	Y	-
32	O	-
33	BR	-
34	P	-
36	V	-
37	GR	-
38	O	-
39	W	-
40	R	-

41	SHIELD	-
42	B	-
43	P	-
44	V	-
45	LG	-
46	BR	-
47	L	-
48	Y	-
49	P	-
50	B/W	-
51	G	-
52	Y	-
53	B/W	-
54	W	-
55	W	-

Connector No.	D8
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH




Terminal No.	4	
Color Of Wire	P	
Signal Name [Specification]	-	
7	Y	-
8	V	-
9	GR	-
10	G	-
11	W	-
12	O	-
13	O	-
14	W	-
15	R	-
16	G	-
19	GR	-
20	SB	-
21	SB	-
23	R	-
24	SB	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >



JRLWD1142GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

## INTERIOR ROOM LAMP CONTROL SYSTEM


9	V	-
10	R	-
11	L	-
12	Y	-
13	BR	-
14	G	-
15	SB	-
16	G	-
17	P	-
18	BR	-
19	GR	-
20	V	-
21	LG	-
22	SB	-
23	G	-
24	S	-
25	BR	-
26	L	-
32	L/O	-
33	W/L	-
34	SHIELD	-
35	W	-
36	L	-
37	P	-
38	SB	-
39	O	-
44	SB	-
45	R	-
46	B/W	-
53	L	-
54	B	-

Connector No.	D47
Connector Name	FRONT OUTSIDE HANDLE ASSEMBLY RH
Connector Type	SAZ08FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	-
2	B	-
3	B	-
4	B/W	-

Connector No.	D51
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	V	-
3	R	-
4	L	-
7	B	-
8	P	-
9	W	-
10	V	-
11	L	-
12	LG	-
13	B	-

Connector No.	D57
Connector Name	STEP LAMP (REAR LH)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	V	-

Connector No.	D71
Connector Name	WIRE TO WIRE
Connector Type	NH10MW-CS10



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	V	-
3	R	-
4	L	-
7	B	-
8	P	-
9	W	-
10	V	-
11	L	-
12	LG	-
13	B	-

Connector No.	D77
Connector Name	STEP LAMP (REAR RH)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	V	-

Connector No.	F108
Connector Name	WIRE TO WIRE
Connector Type	TH88FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	W	-
3	SB	-
4	LG	-
5	O	-
7	GR	-
8	G	-
9	Y	-
10	BR	-
11	SB	-
12	V	-
13	GR	-
14	G	-
15	V	-
16	Y	-
17	GR	-
18	V	-
20	BR	-

Connector No.	D42
Connector Name	STEP LAMP (PASSENGER SIDE)
Connector Type	TB02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	SB	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL



# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

## INTERIOR ROOM LAMP CONTROL SYSTEM

32	L	-	-	-	-
33	P	-	-	-	-
34	B	-	-	-	-
35	P	-	-	-	-
36	BG	-	-	-	-
37	SB	-	-	-	-
41	SB	-	-	-	-
42	V	-	-	-	-
43	L	-	-	-	-
44	B	-	-	-	-
45	W	-	-	-	-
47	L	-	-	-	-
48	LG	-	-	-	-
49	BR	-	-	-	-
50	V	-	-	-	-
51	V	-	-	-	-
52	B	-	-	-	-
53	BG	-	-	-	-
56	SB	-	-	-	-
57	P	-	-	-	-
58	LG	-	-	-	-
59	Y	-	-	-	-
60	GR	-	-	-	-
61	B	-	-	-	-
62	LG	-	-	-	-
63	BR	-	-	-	-
65	W	-	-	-	-
66	R	-	-	-	-
67	V	-	-	-	-
68	LG	-	-	-	-
69	SB	-	-	-	-
70	V	-	-	-	-
72	L	-	-	-	-
73	P	-	-	-	-
74	L	-	-	-	-
75	P	-	-	-	-
76	G	-	-	-	-
77	Y	-	-	-	-
78	SB	-	-	-	-
79	W	-	-	-	-
80	BR	-	-	-	-
81	LG	-	-	-	-
82	BR	-	-	-	-
83	BG	-	-	-	-
84	W	-	-	-	-
85	W	-	-	-	-
86	G	-	-	-	-
87	R	-	-	-	-
88	G	-	-	-	-
91	W	-	-	-	-

32	G	-	-	-	-
33	BG	-	-	-	-
34	Y	-	-	-	-
36	LG	-	-	-	-

Connector No.	M20
Connector Name	PCB HARNESS
Connector Type	TH40FB-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
11	BR	-
12	R	-
14	L	-
15	B	-
17	R	-
18	W	-
20	R	-
21	L	-
22	R	-
23	L	-
24	L	-
27	P	-
31	V	-
33	V	-
35	L	-
36	P	-
38	L	-
40	Y	-

Connector No.	M22
Connector Name	PCB HARNESS
Connector Type	TH40FB-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

Terminal No.	Color Of Wire	Signal Name [Specification]
81	L	-
82	B	-
84	G	-
85	B	-
86	B	-
87	B	-
88	B	-
89	Y	-
91	V	-
92	V	-
93	B	-
94	B	-
95	LG	-
96	BR	-
97	G	-
98	G	-
100	G	-
101	L	-
102	P	-
103	B	-
104	BR	-
105	R	-
107	Y	-
108	Y	-
109	BR	-
110	Y	-
112	B	-
113	P	-
114	P	-
116	B	-
117	BG	- [With V6 engine]
118	B	- [With V6 engine]
119	G	-
120	V	-

Connector No.	M23
Connector Name	PCB HARNESS
Connector Type	TH40FW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----

Terminal No.	Color Of Wire	Signal Name [Specification]
121	R	-
122	BG	-
124	BG	-
128	BR	-
130	B	-
131	SB	-
132	LG	-
133	L	-
135	P	-
137	Y	-
138	L	-
139	P	-
140	L	-
141	W	-
142	W	-
144	B	-
145	B	-
146	B	-
147	B	-
148	L	-
149	B	-
150	P	-
151	L	-
152	B	-
153	W	-
154	W	-
155	W	-
157	W	-
158	R	-
159	R	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P


INL

# INTERIOR ROOM LAMP CONTROL SYSTEM


< WIRING DIAGRAM >

## INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	M29
Connector Name	PCB HARNESS
Connector Type	TH40PW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
402	R	-
403	R	-
407	V	-
408	B	-
409	B	-
411	B	-
413	Y	-
414	BR	-
416	LG	-
417	B	-
419	SB	-
420	SHIELD	-
422	V	-
423	P	-
425	V	-
426	P	-
428	P	-
430	LG	-
431	B	-
432	Y	-
435	V	-
436	BG	-
437	B	-
439	P	-
439	L	-



Terminal No.	Color Of Wire	Signal Name [Specification]
352	W	-
353	W	-
357	B	-
368	G	-
373	BR	-
374	BG	-
375	BG	-
376	V	-
377	V	-
378	B	-
379	R	-
380	R	-
381	G	-
382	G	-
383	GR	-
385	P	-
386	L	-
400	V	-

Terminal No.	Color Of Wire	Signal Name [Specification]
2	BR	GNP
3	GR	SIGNAL OUTPUT
4	R	BATTERY

Connector No.	M105
Connector Name	WIRE TO WIRE
Connector Type	TH40PW-NH

Connector No.	M59
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK08FBR


Connector No.	M106
Connector Name	WIRE TO WIRE
Connector Type	NSDBMW-CS

Connector No.	M30
Connector Name	PCB HARNESS
Connector Type	TH40PW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	-
3	B	-
5	LG	-
6	P	-
7	L	-
8	P	-
9	B	-
10	W	-
11	W	-
12	SB	-
14	SB	-
15	BR	-
16	V	-
18	G	-
19	B	-
20	V	-

Connector No.	M104
Connector Name	REMOTE KEYLESS ENTRY RECEIVER
Connector Type	TH40PW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
3	R	-
4	BG	-
5	Y	-
6	R	-
7	B	-
8	L	-

Terminal No.	Color Of Wire	Signal Name [Specification]
22	BG	-
23	B	-
25	W	-
27	SB	-
29	B	-
30	R	-
31	BR	-
32	L	-
33	P	-
34	LG	-
35	W	-
36	LG	-
37	L	-
38	R	-

Connector No.	M106
Connector Name	WIRE TO WIRE
Connector Type	NSDBMW-CS



JRLWD1146GB

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >


## INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	M114
Connector Name	FOOT LAMP (PASSENGER SIDE)
Connector Type	G22FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	BR	-

Connector No.	M117
Connector Name	WIRE TO WIRE
Connector Type	TH86FW-C816-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
3	Y	-
6	R	-
13	W	-
17	GR	-
18	P	-
19	BR	-
20	GR	-
21	Y	-
22	LG	-
23	R	-
24	EG	-
26	EG	-
27	R	-
28	V	-
29	P	-
30	B	-
31	G	-

Terminal No.	Color Of Wire	Signal Name [Specification]
32	Y	-
42	SHIELD	-
43	R	-
44	W	-
45	SB	- [With heated seat]
46	BC	- [With climate controlled seat]
47	G	- [With climate controlled seat]
48	GR	- [With heated seat]
49	BG	-
50	LG	-
51	SB	-
52	Y	-
53	W	-
54	B	-
55	G	-
56	R	-
59	W	-
61	LG	-
62	V	-
63	R	-
66	L	-
67	Y	-
68	SB	-
69	B	-
70	R	-
71	BR	-
72	E	-
75	SHIELD	-
77	G	-
78	R	-
79	L	-
80	G	-
81	BG	-
82	BR	-
83	GR	-
84	V	-
85	LG	-
86	V	-
87	X	-
88	BR	-
89	BR	-
90	BR	-
91	Y	-
92	G	-
93	W	- [With climate controlled seat]
94	V	-

Terminal No.	86	W	-
Terminal No.	88	BR	-
Terminal No.	89	CG	-
Terminal No.	100	Y	-

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	RR WINDOW DEFG RLY CONT
2	BC	COMBI SW INPUT 5
3	SB	COMBI SW INPUT 4
4	L	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	P	COMBI SW INPUT 1
8	V	POWER WINDOW SW COMM
9	P	STOP LAMP SW 1
10	W	RAMBL SW 1 LINK
14	W	OPTICAL SENSOR
16	SB	DIMMER SIGNAL
17	Y	SENSOR PWR SPLY
18	B	RECEIVER / SENSOR GND
19	R	RECEIVER PWR SPLY
20	BR	KYLS ENT RECEIVER COMM
21	P	NATS ANT AMP
22	GR	KYLS ENT RECEIVER RSSI
23	G	SECURITY IND CONT
24	L	DONGLE LINK
25	G	NATS ANT AMP
26	G	F-KEY IDENTIFICATION
28	G	HAZARD SW
29	W	TRUNK LID SW
31	W	DR DOOR UNLK SENSOR
32	BR	COMBI SW OUTPUT 5
33	R	COMBI SW OUTPUT 4
34	V	COMBI SW OUTPUT 3
35	Y	COMBI SW OUTPUT 2
36	LG	COMBI SW OUTPUT 1

Terminal No.	37	R	P POSITION
Terminal No.	39	I	WASH
Terminal No.	40	P	CAT'L

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FB-FH40-SA



Terminal No.	Color Of Wire	Signal Name [Specification]
41	W	TR KEY CYLINDER SW
42	R	TRUNK LID OPEN/CLOSE STATUS
44	V	TR LID OP/CANCEL SW
45	GR	PASSENGER DOOR SW
46	BR	REAR RH DOOR SW
47	LG	DRIVER DOOR SW
48	P	REAR LH DOOR SW
49	SB	TR ROOM LAMP CONT
51	EG	TR LID OPEN/RED SW
53	LG	TRUNK LID OPEN REQUEST
55	BR	RR DOOR UNLK OUTPUT

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA09FW-FH40-SA



Terminal No.	Color Of Wire	Signal Name [Specification]
56	R	INT ROOM LAMP PWR SPLY
57	R	BAT (FUSE)
58	L	SENS CANCEL SW
59	G	PASS DOOR UNLK OUTPUT

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

INL





# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >


## INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	RT
Connector Name	WIRE TO WIRE
Connector Type	NSDBFW-CS




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	BG	-
3	Y	-
4	GR	-
5	BR	-
6	BR	-
7	BR	-
8	BR	-

Connector No.	R2
Connector Name	WIRE TO WIRE
Connector Type	TH24MW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	G	-
5	SHIELD	-
6	R	-
7	G	-
8	B	-
9	B	-
10	R	-
11	BR	-
12	BR	-
13	BR	-
14	V	-
17	LG	-
18	L	-

Connector No.	RT1
Connector Name	WIRE TO WIRE
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	G	-
5	SHIELD	-
6	R	-
7	G	-
8	B	-
9	B	-
10	R	-
11	BR	-
12	BR	-
13	BR	-
14	V	-
17	L	-
18	LG	-
19	R	-
20	G	-
21	R	-
22	B	-
23	GR	-
24	P	-

Connector No.	R12
Connector Name	VANITY MIRROR LAMP (DRIVER SIDE)
Connector Type	MCADDFW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	V	-

Connector No.	R13
Connector Name	VANITY MIRROR LAMP (PASSENGER SIDE)
Connector Type	MCADDFW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	V	-

Connector No.	R14
Connector Name	PERSONAL LAMP
Connector Type	TH04FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	B	-
3	Y	-

Connector No.	R15
Connector Name	MAP LAMP
Connector Type	TK06FCY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	SB	-
3	B	-
4	Y	-
5	B/Y	-
6	G	-

JRLWD1149GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

## INTERIOR ROOM LAMP CONTROL SYSTEM

Connector No.	T13
Connector Name	WIRE TO WIRE
Connector Type	NSIBFW-CS



6	5	3	2	1
15	14	13	12	11
10	9	8		

Terminal No.	Color Of Wire	Signal Name [Specification]
1	—	—
2	—	—
3	G	—
4	P	—
5	W	—
6	R	—
8	O	—
9	V	—
10	L	—
11	W	—
12	B	—
13	R	—
14	L	—
15	P	—

Connector No.	T14
Connector Name	TRUNK CLOSURE CONTROL UNIT
Connector Type	NSIBFW-CS



2	1
6	5
4	3

Terminal No.	Color Of Wire	Signal Name [Specification]
1	—	—
2	G	—
3	L	—
4	P	—
5	Y	—
6	R	—

JRLWD1150GB


# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION

### Wiring Diagram

INFOID:000000010098515



2013/10/22

JRLWD1151GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


INL





# ILLUMINATION

< WIRING DIAGRAM >




# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH89FT-C516-TM4




Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	W	-
4	LG	-
5	P	-
6	V	-
7	GR	-
8	Y	-
9	LG	-
10	V	-
11	GR	- [With climate controlled seat]
11	L	- [With heated seat]
12	GR	- [With heated seat]
12	P	- [With climate controlled seat]
13	BR	-
14	R	-
15	O	-
16	V	-
17	B	-
18	R	-
19	W	-
20	B	-
21	B	-
22	LG	-
23	V	-
24	Y	-
25	G	-
26	GR	-
27	SB	-
28	L/O	-
29	W/L	-
30	SHIELD	-
32	L	-
33	R	-
34	L	-
35	R	-

36	G	-
37	SB	-
40	SHIELD	-
40	GR/V	-
42	W/L	-
43	L	-
44	B	-
45	W	-
47	O	-
48	Y	-
48	BR	-
49	SB	-
50	SB	-
52	LG	-
53	G	-
56	P	-
57	BR	-
58	LG	-
59	Y	-
60	W	-
61	B	-
62	LG	-
63	V	-
65	O	-
66	BR	-
67	V	-
68	LG	-
69	GR	-
70	R	-
72	L	-
73	P	-
74	R	-
75	P	-
76	Y	-
77	R	-
78	W	-
78	G	-
80	L	-
81	LG	-
82	BR	-
83	SB	-
84	Y	-
85	W	-
86	R	-
87	G	-
88	GR	-
91	SB	-
92	G	-
96	Y	-

97	O	-
98	SB	-
99	LG	-

Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Type	TH40MW-GS15



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	L	-
5	B/W	-
6	L	-
7	R	-
8	B	-
9	W	-
10	LG	-
11	P	-
12	GR	-
13	B/W	-
14	SB	-
15	O	-
17	Y	-
18	BR	-
19	GR	-
20	O	-
21	LG	-
22	L	-
23	SB	-
24	V	-
27	V	-
28	W	-
29	SB	-
30	L	-
31	LG	-
32	O	-
33	V	-
34	BR	-

35	B/R	-
36	P	-
37	BR	-
38	W	-
39	O	-
40	L	-
41	SHIELD	-
42	W/L	-
43	L/O	-
44	R	-
45	Y	-
46	V	-
47	SB	-
48	GR	-
49	LG	-
50	B	-
51	G	-
52	R	-
53	B	-
54	V	-
55	W	-

Connector No.	B16
Connector Name	FRONT DOOR SWITCH LH
Connector Type	A03FW



Terminal No.	Color Of Wire	Signal Name [Specification]
2	LG	-

JRLWD1155GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P


INL

# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION

Connector No.	B218
Connector Name	WIRE TO WIRE
Connector Type	NH10FP-CSSD



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	P	-
3	R	-
4	G	-
7	B	-
8	W	-
9	V	-
10	Y	-
11	L	-
12	Y	-
13	B	-

Connector No.	B201
Connector Name	WIRE TO WIRE
Connector Type	T188MH-CSE-TM




Terminal No.	Color Of Wire	Signal Name [Specification]
3	R	-
6	R	-
13	Y	-
17	GR	-
18	P	-
19	BR	-
20	GR	-
21	Y	-
22	GR	-

23	R	-
24	Y	-
25	W	-
26	O	-
27	P	-
28	P	-
29	O	-
30	O	-
31	B/R	-
32	Y	-
40	SHIELD	-
41	W/R	-
42	V	-
44	P	-
45	SB	-
46	R	- [With climate controlled seat]
47	G	- [With climate controlled seat]
48	Y	- [With climate controlled seat]
49	O	-
50	R	-
51	GR	-
52	LG	-
53	P	-
56	P	-
57	W	-
58	O	-
59	SB	-
61	L	-
62	W	-
63	Y	-
64	L	-
65	Y	-
66	SB	-
68	R	-
70	R	-
71	L	-
74	B	-
75	L	-
76	SHIELD	-
77	G	-
78	R	-
79	P	-
80	G	-
81	O	-
82	BR	-
83	GR	-
84	V	-
85	LG	-

86	W	-
87	O	-
88	BR	-
89	BR	-
90	O	-
91	BR	-
93	O	- [With heated seat]
93	Y	- [With climate controlled seat]
94	GR	-
96	W	-
97	P	-
98	LG	-
99	LG	-
100	Y	-


Connector No.	B204
Connector Name	WIRE TO WIRE
Connector Type	T188MH-CSE15



Terminal No.	Color Of Wire	Signal Name [Specification]
2	B/W	-
5	R	-
9	R	-
10	P	-
11	Y	-
12	Y	-
13	BR	-
14	LG	-
15	GR	-
16	G	-
17	O	-
18	BR	-
19	GR	-
20	V	-
22	W	-
23	O	-
24	Y	-
25	BR	-

26	L	-
32	G	-
33	P	-
34	SHIELD	-
35	L	-
36	B/R	-
37	BR	-
38	SB	-
39	P	-
44	SB	-
45	R	-
46	B	-
53	L	-
54	B	-

Connector No.	B218
Connector Name	WIRE TO WIRE
Connector Type	NH10FP-CSSD



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	P	-
3	R	-
4	G	-
7	B	-
8	W	-
9	V	-
10	Y	-
11	L	-
12	Y	-
13	B	-




# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION


Connector No.	D1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	L	-
5	B	-
6	L	-
7	R	-
8	GR	-
9	G	-
10	LG	-
11	P	-
12	LG	-
13	B/W	-
14	Y	-
15	O	-
16	R	-
17	Y	-
18	BR	-
19	W	-
20	O	-
21	GR	-
22	LG	-
23	B	-
24	B	-
27	V	-
28	W	-
29	GR	-
30	G	-
31	Y	-
32	O	-
33	BR	-
34	L	-
35	P	-
36	V	-
37	GR	-
38	O	-
39	W	-
40	R	-


41	SHIELD	-
42	L	-
43	V	-
44	Y	-
45	G	-
46	BR	-
47	Y	-
48	P	-
50	B/W	-
51	G	-
52	Y	-
53	B/W	-
54	W	-
55	W	-

Connector No.	D5
Connector Name	SEAT MEMORY SWITCH
Connector Type	TH10FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	-
2	W	-
4	B	-
5	LG	-
6	GR	-
7	O	-
8	Y	-
9	B/W	-

Connector No.	D17
Connector Name	FRONT OUTSIDE HANDLE ASSEMBLY LH
Connector Type	SAZ20FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	V	-
4	B/W	-


Connector No.	D31
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS15



Terminal No.	Color Of Wire	Signal Name [Specification]
2	B	-
3	B/W	-
5	GR	-
9	V	-
10	R	-
11	L	-
12	Y	-
13	BR	-
14	G	-
15	S5	-
16	G	-
17	P	-
18	BR	-
19	GR	-
20	V	-
21	LG	-

22	SB	-
23	G	-
24	V	-
25	BR	-
29	L/O	-
32	W/L	-
34	SHIELD	-
35	W	-
36	L	-
37	P	-
38	SB	-
39	O	-
44	SB	-
45	R	-
46	B/W	-
53	L	-
54	B	-

Connector No.	DA7
Connector Name	FRONT OUTSIDE HANDLE ASSEMBLY RH
Connector Type	SAZ20FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	-
2	B	-
3	R	-
4	B/W	-

JRLWD1157GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


INL

# ILLUMINATION

< WIRING DIAGRAM >


## ILLUMINATION

Connector No.	D51
Connector Name	WIRE TO WIRE
Connector Type	NH10MH-CS10




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	V	-
3	R	-
4	L	-
7	B	-
8	P	-
9	W	-
10	V	-
11	L	-
12	LG	-
13	B	-

Connector No.	D58
Connector Name	ASHTRAY ILLUMINATION (REAR LH)
Connector Type	A03PW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B	-

Connector No.	D71
Connector Name	WIRE TO WIRE
Connector Type	NH10MH-CS10




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	V	-
3	R	-
4	L	-
7	B	-
8	P	-
9	W	-
10	V	-
11	L	-
12	LG	-
13	B	-

Connector No.	D78
Connector Name	ASHTRAY ILLUMINATION (REAR RH)
Connector Type	A03PW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	B	-

Connector No.	E5
Connector Name	INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH08FH-SS12-M4-1V




Terminal No.	Color Of Wire	Signal Name [Specification]
4	W	ENG SOL
5	P	IGN COIL
6	R	ECM VB [With VG engine]
7	SB	ECM VB [With VK engine]
7	R	ETC [With VK engine]
7	Y	A/C COMP [With VK engine]
8	L/Y	A/C COMP [With VG engine]
8	P	ECM BAT
10	V	P-GND
11	B	ABS ECU
12	G	FUEL PUMP [With VG engine]
13	GR	FUEL PUMP [With VK engine]
13	W	WIPER/AUTO STOP
15	V	IGN SIGNAL
16	BR	ALL-O
22	BR	DTRL RLY [With VG engine]
22	SB	DTRL RLY [With VK engine]
24	GO	HOOD SW
24	LG	SUB ECU
26	BR	PUSH START SW
30	BR	NP SW [With VK engine]
31	W	NP SW [With VG engine]
36	GR	F/L IGN SW

Connector No.	E6
Connector Name	INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH08FH-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
39	P	CAN-L
40	L	CAN-H
41	B	S-GND
42	V	MOTOR FAN RLY CONT [With VK engine]
43	SB	DETENT SW
44	GR	HORN RLY [With VK engine]
44	LG	HORN RLY [With VG engine]
45	G	HORN SW
46	BR	START COUNT

Connector No.	E7
Connector Name	INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH08FH-SS12-M4



Terminal No.	Color Of Wire	Signal Name [Specification]
48	W	DTRL DEICER
51	O	WASH MTR
52	G	INJECTOR #1
53	L	FR WIPER HI
54	P	FR WIPER LO
55	R	TAIL ILLUMI
56	GR	O2 SENS #1
57	V	O2 SENS #2
58	BR	AT ECU
70	LG	SSOFF

JRLWD1158GB


# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION

71	O	MOTRLY
73	G	START JG-E/R
74	R	START JG-EG
75	Y	OIL PRESSURE SW
77	B	
80	W	STARTER MOTOR


Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-C516-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	
2	W	
3	SB	
4	LG	
5	O	
7	GR	
8	G	
9	Y	
10	BR	
11	L	
12	SP	
14	GR	
15	V	
16	Y	
17	GR	
18	V	
20	BR	
21	P	
22	L	
23	P	
27	SHIELD	
28	L/O	
29	W/L	
31	BR	
32	G	
33	O	
34	Y	

41	BR	
44	W	
46	GR	
47	O	
48	G	
49	O	
50	LG	
61	W	
62	Y	
63	BR	
64	B	
65	Y	
66	R	
67	SB	
77	O	
78	SB	
80	G	
81	R	
82	SB	
83	GR	
84	Y	
85	L	
86	L	
87	V	
88	BR	
89	LG	
90	W	
91	W	
92	L	
93	G	
94	W	
95	W	
97	R	
98	Y	
99	V	
100	V	

Connector No.	M6
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-C516-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	W	
3	SB	
4	LG	
5	W	
7	BC	
8	G	
9	Y	
10	W	
11	R	
12	V	
13	LG	
14	L	
15	V	
16	B	
17	GR	
18	S	
20	SP	
21	P	
23	P	
27	SHIELD	
28	V	
29	SB	
31	EG	
32	P	
33	R	
34	EG	
41	BR	
44	BR	
45	Y	
46	EG	
47	V	
48	G	
49	EG	
50	W	

80	GR	
81	B	
82	LG	
83	BR	
84	L	
85	P	
86	L	
87	L	
88	V	
89	LG	
90	EG	
91	W	
92	EG	
93	G	
94	Y	
95	W	
97	SB	
98	R	
99	W	
100	L	

Connector No.	M7
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-C516-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	
2	Y	
4	BR	
5	P	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION

5	W	--	--	B	--
6	G	--	--	LG	--
7	Y	--	--	BR	--
8	G	--	--	W	--
9	G	--	--	R	--
10	Y	--	--	V	--
11	V	--	--	LG	--
12	GR	--	--	SB	--
13	P	--	--	V	--
14	BR	--	--	L	--
15	BG	--	--	P	--
16	V	--	--	L	--
17	BG	--	--	G	--
18	L	--	--	Y	--
19	W	--	--	SB	--
20	R	--	--	W	--
21	B	--	--	BR	--
22	LG	--	--	LG	--
23	W	--	--	BR	--
24	V	--	--	BG	--
25	G	--	--	B	--
26	BR	--	--	W	--
27	SB	--	--	G	--
28	P	--	--	R	--
29	L	--	--	G	--
30	SHIELD	--	--	W	--
32	L	--	--	G	--
33	P	--	--	W	--
34	L	--	--	BG	--
35	P	--	--	LG	--
37	SB	--	--	L	--
41	SB	--	--	V	--
42	V	--	--	V	--
43	L	--	--	L	--
44	B	--	--	P	--
45	W	--	--	L	--
47	L	--	--	Y	--
48	LG	--	--	L	--
49	BR	--	--	Y	--
50	V	--	--	B	--
51	V	--	--	P	--
52	P	--	--	L	--
53	BG	--	--	B	--
56	SB	--	--	B	--
57	P	--	--	BG	--
58	LG	--	--	B	--
59	Y	--	--	G	--
60	GR	--	--	V	--

61	B	--	--
62	LG	--	--
63	BR	--	--
64	W	--	--
65	R	--	--
66	V	--	--
68	LG	--	--
69	SB	--	--
70	V	--	--
72	L	--	--
73	P	--	--
74	L	--	--
75	P	--	--
76	G	--	--
77	Y	--	--
78	SB	--	--
79	W	--	--
80	BR	--	--
81	LG	--	--
82	BR	--	--
83	BG	--	--
84	B	--	--
85	W	--	--
86	G	--	--
87	R	--	--
88	G	--	--
91	W	--	--
92	G	--	--
96	W	--	--
97	BG	--	--
98	L	--	--
99	LG	--	--

Connector No.	M10
Connector Name	DIODE
Connector Type	24332, C3902



Terminal No.	Color Of Wire	Signal Name [Specification]
2	B	--

Connector No.	M20
Connector Name	PCB HARNESS
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	--
11	BR	--
12	R	--
14	L	--
15	B	--
17	R	--
19	W	--
20	R	--
21	B	--
22	R	--
24	L	--
27	P	--
31	V	--
33	V	--
35	L	--
36	P	--
38	L	--
40	Y	--

Connector No.	M22
Connector Name	PCB HARNESS
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
81	L	--
82	P	--
84	B	--
85	B	--
86	B	--
87	B	--
88	B	--
89	Y	--
91	V	--
92	V	--
93	B	--
94	B	--
95	LG	--
96	BR	--
97	G	--
98	G	--
99	G	--
100	G	--
102	P	--
103	B	--
104	BR	--
105	R	--
107	Y	--
108	Y	--
109	BR	--
110	Y	--
112	B	--
113	P	--
114	L	--
116	B	--
117	B	--
118	BG	--
119	G	--
120	V	--


JRLWD1160GB

# ILLUMINATION

< WIRING DIAGRAM >

## ILLUMINATION

Connector No.	M23
Connector Name	PCB HARNESS
Connector Type	TH40FPV-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
121	R	-
122	V	-
123	BG	-
124	BG	-
128	BR	-
130	B	-
131	SB	-
132	LG	-
133	L	-
135	P	-
137	Y	-
138	L	-
139	P	-
140	L	-
141	W	-
142	W	-
144	B	-
145	B	-
147	B	-
148	L	-
149	B	-
150	P	-
151	L	-
152	B	-
153	W	-
154	W	-
155	W	-
157	W	-
158	R	-
159	R	-

Connector No.	M24
Connector Name	PCB HARNESS
Connector Type	TH40FPV-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
161	BG	-
162	BG	-
163	G	-
164	V	-
165	V	-
166	R	-
167	LG	-
168	R	-
169	R	-
170	B	-
172	B	-
174	W	-
175	B	-
176	L	-
177	P	-
178	Y	-
179	L	-
180	G	-
182	BR	- [With V6 engines or with V6 engines without DCS]
183	R	- [With V6 engines with DCS]
184	C	-
185	V	-
185	P	- [With BOSE system]
186	R	- [Without BOSE system]
187	L	-
188	Y	-
189	B	-
190	V	-
191	G	-
192	B	-
193	SB	-
194	BR	-
195	SB	-
198	R	-
199	B	-

Connector No.	SB
Connector Name	PCB HARNESS
Connector Type	TH40FPV-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
241	L	-
242	L	-
243	R	-
244	L	-
245	B	-
246	B	-
247	B	-
252	B	-
253	B	-
254	B	- [With heated seat]
254	W	- [With climate controlled seat]
255	B	-
256	R	-
258	R	-
259	EG	-
260	W	-
302	R	-
303	R	-
303	V	-
306	V	-
307	LG	-
308	SB	-
309	G	-
310	R	-
311	W	-
312	B	-
313	B	-
319	V	-
320	W	-

Connector No.	M27
Connector Name	PCB HARNESS
Connector Type	TH40FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
281	O	-
282	BG	-
283	BG	-
284	BG	-
285	W	-
287	Y	-
288	W	-
289	SHIELD	-
290	B	-
291	SHIELD	-
292	B	-
293	B	-
294	B	-
295	B	-
297	B	-
298	B	-
299	L	-
300	W	-
302	R	-
303	R	-
306	V	-
307	LG	-
308	SB	-
309	G	-
310	R	-
311	W	-
312	B	-
313	B	-
319	V	-
320	W	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P


INL

# ILLUMINATION

< WIRING DIAGRAM >


## ILLUMINATION

Connector No.	M30
Connector Name	PCB HARNESS
Connector Type	TH40FT-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
402	R	-
403	R	-
407	V	-
408	B	-
409	B	-
411	B	-
413	Y	-
414	BR	-
416	LG	-
417	B	-
419	SB	-
420	SHIELD	-
422	V	-
427	P	-
428	V	-
429	C	-
430	LG	-
431	B	-
432	V	-
435	V	-
436	BG	-
437	B	-
438	P	-
439	L	-

Connector No.	M33
Connector Name	COMBINATION SWITCH
Connector Type	TH18FTW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	FR WASHER (-)
2	SB	OUTPUT 4
5	L	OUTPUT 3
6	B	GND
7	V	INPUT 3
8	BG	OUTPUT 5
9	Y	INPUT 2
10	R	INPUT 4
11	LG	INPUT 1
12	P	OUTPUT 1
13	BR	INPUT 5
14	G	OUTPUT 2

Connector No.	M35
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK08FT-EX-1V




Terminal No.	Color Of Wire	Signal Name [Specification]
23	R	-
28	Y	-
29	Y	-
30	Y	-

Connector No.	M36
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Type	TK08FTY-1V




Terminal No.	Color Of Wire	Signal Name [Specification]
24	P	-
25	SB	-
26	B	-
31	L	-
32	Y	-
33	B	-
34	LG	-

Connector No.	M50
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK08FBR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	R	-
3	R	-
4	BR	-
5	GR	-
6	Y	-
7	V	-
8	W	-

Connector No.	M53
Connector Name	COMBINATION METER
Connector Type	TH40FT-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	BATTERY POWER SUPPLY
2	BG	IGNITION SIGNAL
3	GR	VEHICLE SPEED SIGNAL (2-PULSE)
4	R	VEHICLE SPEED SIGNAL (8-PULSE)
5	B	ILLUMINATION CONTROL SIGNAL
6	B	METER CONTROL SWITCH GROUND
7	SB	ENTER SWITCH SIGNAL
8	LG	SELECT SWITCH SIGNAL
9	G	ILLUMINATION CONTROL SWITCH SIGNAL (-)
10	GR	ILLUMINATION CONTROL SWITCH SIGNAL (-)
11	L	TRIP RESET SWITCH SIGNAL
12	B	GROUND
14	L	GAN-H
15	P	GAN-L
16	R	AIR BAG SIGNAL
23	B	GROUND
24	B	FUEL LEVEL SENSOR GROUND
25	W	ALTER SIGNAL
26	W	PARKING BRAKE SWITCH SIGNAL
27	V	BRAKE FLUID LEVEL SWITCH SIGNAL
28	G	SECURITY SIGNAL
29	L	WASHER LEVEL SWITCH SIGNAL
32	G	PADDLE SHIFTER SHIFT DOWN SIGNAL
33	BG	PADDLE SHIFTER SHIFT UP SIGNAL
34	G	FUEL LEVEL SENSOR SIGNAL
35	W	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
36	G	PASSENGER SEAT BELT WARNING SIGNAL
37	G	NON-MANUAL MODE SIGNAL
38	V	MANUAL MODE SHIFT DOWN SIGNAL
39	L	MANUAL MODE SHIFT UP SIGNAL
40	W	MANUAL MODE SIGNAL


JRLWD1162GB

# ILLUMINATION

< WIRING DIAGRAM >


## ILLUMINATION

Connector No.	M64
Connector Name	METER CONTROL SWITCH
Connector Type	TH12MH-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	-
2	B	-
3	GR	-
4	R	-
5	W	-
6	G	-
9	BG	-
10	GR	-
11	LG	-
12	L	-

Connector No.	M72
Connector Name	MULTIFUNCTION SWITCH
Connector Type	TH18FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GND
3	V	ACC
4	R	ILL
5	B	ILL CONT
6	SB	AV COMM (H)
8	LG	AV COMM (L)
9	BR	SW GND
14	SB	DISK EJECT SIGNAL
15	R	AIR BAG CUT OFF
16	G	HAZARD ON

Connector No.	M74
Connector Name	CLOCK
Connector Type	TH6FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	BATTERY POWER SUPPLY
2	B	GROUND
3	R	ILLUMINATION (+)
4	B	ILLUMINATION (-)

Connector No.	M81
Connector Name	AV CONTROL UNIT
Connector Type	TH18FW-CS2



Terminal No.	Color Of Wire	Signal Name [Specification]
2	G	SOUND SIGNAL FRONT LH (+)
3	L	SOUND SIGNAL FRONT LH (-)
4	GR	SOUND SIGNAL REAR LH (+)
5	G	SOUND SIGNAL REAR LH (-)
6	P	STRG SW A
7	V	ACC
9	SB	ILLUMINATION
11	BR	SOUND SIGNAL FRONT RH (+)
12	R	SOUND SIGNAL FRONT RH (-)
13	P	SOUND SIGNAL REAR RH (+)
14	V	SOUND SIGNAL REAR RH (-)
15	B	STRG SW GND
16	L	STRG SW B
19	Y	BATTERY
20	B	GND

Connector No.	M82
Connector Name	AV CONTROL UNIT
Connector Type	TH24FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
36	BG	SIGNAL VCC
37	B	SIGNAL GND
38	G	HP
39	Y	COMM (DSP->CONT)
40	R	RGB AREA (Y'S) SIGNAL
41	R	SHIELD
42	W	RGB SYNC
43	R	RGB (RED) SIGNAL
44	B	RGB (GREEN) SIGNAL
45	W	RGB (BLUE) SIGNAL
46	V	COMPOSITE IMAGE GND
47	SB	COMPOSITE IMAGE SIGNAL
48	L	INVERTER VCC
49	LG	INVERTER GND
50	B	VP
51	BR	COMM (CONT->DISP)
52	R	SHIELD
57	R	SHIELD
58	R	SHIELD

Connector No.	M81
Connector Name	WIRE TO WIRE
Connector Type	TK02FBR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	R	-

Connector No.	M82
Connector Name	WIRE TO WIRE
Connector Type	TK02MBR-P



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	R	-

Connector No.	M83
Connector Name	GLOVE BOX LAMP
Connector Type	A02FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL


JRLWD1163GB

# ILLUMINATION

< WIRING DIAGRAM >

**ILLUMINATION**


Connector No.	M104
Connector Name	OPTICAL SENSOR
Connector Type	TH03PW



Terminal No.	1	2	3
Color	Y	W	B
Wire	POWER	OUTPUT	GND

Signal Name [Specification]

Connector No.	M105
Connector Name	WIRE TO WIRE
Connector Type	TH40PW-NH




Terminal No.	1	2	3	4	5	6	7	8	9	10	11	12
Color	BR	LG	P	L	B	BR	R	B	V	BR	W	BR
Wire												

Signal Name [Specification]

Terminal No.	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38
Color	B	SB	SB	B	BR	L	P	LG	W	LG	L	R				
Wire																

Connector No. M110  
Connector Name WIRE TO WIRE  
Connector Type TH24MW-NH




Terminal No.	1	2	3	4	5	6	7	8	9	10	11	12
Color	G	W	R	L	L	B	BR	R	B	V	BR	W
Wire												

Signal Name [Specification]

Terminal No.	21	22	23	24	25	26	27	28	29	30	31	32	40	41	42	44	45	46	47	48	49	50	
Color	Y	LG	R	EG	EG	R	BR	V	P	B	G	Y	SHIELD	R	R	W	SB	EG	L	G	BR	V	LG
Wire																							

Connector No. M117  
Connector Name WIRE TO WIRE  
Connector Type TH80PW-GS1P-TM4



Terminal No.	3	6	13	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	40	41	42	44	45	46	47	48	49	50	
Color	Y	R	W	GR	P	BR	GR	Y	LG	R	EG	EG	R	BR	V	P	B	G	Y	SHIELD	R	R	W	SB	EG	L	G	BR	V	LG
Wire																														

Signal Name [Specification]

JRLWD1164GB



# ILLUMINATION

## < WIRING DIAGRAM >

### ILLUMINATION

Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40PW-NH



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40
---	---	---	---	---	---	---	---	---	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	RR WINDOW DEFG RLY CONT
2	BG	COMBI SW INPUT 5
3	SB	COMBI SW INPUT 4
4	L	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	P	COMBI SW INPUT 1
8	V	POWER WINDOW SW COMM
9	P	STOP LAMP SW 1
11	R	RAIN SENSOR SERIAL LINK
14	W	OPTICAL SENSOR
16	SB	DIMMER SIGNAL
17	Y	SENSOR PWR SPLY
18	B	RECEIVER / SENSOR GND
19	R	RECEIVER PWR SPLY
20	BR	KYLS ENT RECEIVER COMM
21	P	KYLS ANT AMP
22	GR	KYLS ENT RECEIVER RSSI
23	G	SECURITY ID CONT
24	L	MS CAN AMP
25	G	MS CAN AMP
26	G	I-KEY IDENTIFICATION
29	G	HAZARD SW
30	O	TR LID OPEN SW
31	W	DR DOOR UNLK SENSOR
32	BR	COMBI SW OUTPUT 5
33	R	COMBI SW OUTPUT 4
34	V	COMBI SW OUTPUT 3
35	Y	COMBI SW OUTPUT 2
36	LG	COMBI SW OUTPUT 1
37	R	P POSITION
39	L	CAN-H
40	P	CAN-L

Connector No.	M121
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA08PB-FH46-SA



41	42	44	45	46	47	48	49	50	51	53	55
----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
41	W	TR KEY CYLINDER SW
42	R	TRUNK LID OPEN/CLOSE STATUS
44	V	TR LID OP-CANCEL SW
45	GR	PASSENGER DOOR SW
46	BR	REAR RH DOOR SW
47	LG	DRIVER DOOR SW
48	P	REAR LH DOOR SW
49	SB	TR ROOM LAMP CONT
51	BG	TR LID OPEN REQ SW
53	LG	TRUNK LID OPEN REQUEST
55	BR	RR DOOR UNLK OUTPUT

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FEA08PB-FH46-SA



56	57	58	59	60	61	62	63	65	66	67	68	69	70
----	----	----	----	----	----	----	----	----	----	----	----	----	----

Terminal No.	Color Of Wire	Signal Name [Specification]
56	R	INT ROOM LAMP PWR SPLY
57	R	BAT (FUSE)
58	L	SENS CANCEL SW
59	G	PASS DOOR UNLK OUTPUT
60	G	TURN SIG RH OUTPUT
61	V	TURN SIG LH OUTPUT
62	V	STEP LAMP CONT
63	L	ROOM LAMP TIMER CONT
65	V	ALL DOOR FL LID LOCK OUTPUT

66	67	68	69	70
----	----	----	----	----

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40PW-NH



72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	95	96	97	98	99	100	102	104	105	106
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----	-----	-----	-----	-----

Terminal No.	Color Of Wire	Signal Name [Specification]
72	B	OUTS HD LAMP OUTPUT
73	V	GN IND
75	G	DR DOOR REQ SW
76	BR	PUSH SW
78	BR	DRIVER DOOR ANT+
79	SB	DRIVER DOOR ANT-
80	LG	PASSENGER DOOR ANT+
81	V	PASSENGER DOOR ANT-
82	V	REAR EMPR ANT+
83	SB	REAR EMPR ANT-
84	BR	ROOM ANT+
85	R	ROOM ANT-
86	R	ROOM ANT+
87	G	ROOM ANT-
88	V	TRUNK ROOM ANT+
89	SR	TRUNK ROOM ANT-
90	R	PUSH-BTN IGN SW LLL LWR
91	GR	LOCK IND
92	B	PUSH-BTN IGN SW LLL GND
93	V	I-KEY WARN BUZZER
95	SR	ACC RELAY CONT
96	P	STARTER RELAY CONT
97	SB	IGN RELAY (J/PM) E/R1 CONT
98	B	IGN RELAY (F/B) CONT
99	R	IGN RELAY (F/B) CONT
100	SR	PASS DOOR REQ SW
102	BR	P/N POSITION
104	GR	A-T SHIFT SELECT PWR SPLY
105	R	STOP LAMP SW 2
106	B	BLWR RELAY CONT

109	Y	ACC IND
-----	---	---------

Connector No.	M132
Connector Name	CIGARETTE LIGHTER SOCKET
Connector Type	NS02PW-GS



3	2	1
---	---	---

Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	
2	R	
3	Y	

Connector No.	M135
Connector Name	WIRE TO WIRE
Connector Type	TH52PW-NH



18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191	192	193	194	195	196	197	198	199	200
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	
2	BG	
5	L	
5	V	- [With heated seat]
6	GR	- [With heated seat]
6	P	- [With climate controlled seat]
7	SB	
10	G	- [With climate controlled seat]
10	GR	- [With heated seat]
11	BG	- [With heated seat]
11	L	- [With climate controlled seat]
12	Y	
13	W	
14	L	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

INL

JRLWD1165GB

**ILLUMINATION**

15	G	-
16	V	-
17	G	-
18	G	-
19	BR	- [With heated seat]
20	W	- [With climate controlled seat]
21	GR	-
22	GR	-
23	GR	-
24	GR	-
25	GR	-
26	GR	-
27	GR	-
28	GR	-
29	GR	-
30	GR	-
31	GR	-
32	L	-


Connector No.	M181
Connector Name	WIRE TO WIRE
Connector Type	TH40MP-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	R	-
3	B	-
5	R	-
6	BR	-
7	L	-
8	P	-
9	B	-
10	W	-
11	LG	-
12	SB	-
14	SB	-
15	BR	-

16	V	-
18	G	-
20	V	-
22	BG	-
23	W	-
24	W	-
25	SB	-
26	B	-
27	R	-
28	R	-
29	R	-
30	R	-
31	BR	-
32	L	-
33	P	-
34	LG	-
35	W	-
36	LG	-
37	L	-
38	R	-

Connector No.	M183
Connector Name	TRIPLE SWITCH
Connector Type	TH12FB-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LG	-
2	SB	-
3	BR	-
5	B	-
6	R	-
7	B	-
9	W	-
11	B	-
12	L	-

Connector No.	M184
Connector Name	IBA OFF SWITCH
Connector Type	TH8BFGY-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	B	-
3	R	-
4	B	-

Connector No.	M187
Connector Name	TRUNK LID OPENER SWITCH
Connector Type	TH8BFB-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	EG	-
2	B	-
3	R	-
4	B	-

Connector No.	M188
Connector Name	TWIN SWITCH
Connector Type	TH12FCY-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	SB	-
3	B	-
5	BG	-
6	B	-
8	W	-
10	B	-

Connector No.	M198
Connector Name	HEATED SEAT SWITCH (DRIVER SIDE)
Connector Type	TK10EW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	V	-
3	R	-
4	B	-
5	W	-
6	B	-

JRLWD1166GB

# ILLUMINATION

< WIRING DIAGRAM >


## ILLUMINATION

Connector No.	M199
Connector Name	HEATED SEAT SWITCH (PASSENGER SIDE)
Connector Type	TK02FBR




Terminal No.	Color	Wire	Signal Name [Specification]
19	GR		
20	B		
21	R		
22	OG		
23	Y		
24	B		
25	B		
26	R		
27	R		
28	B		
29	B		
30	B		
32	R		

Connector No.	M202
Connector Name	A/T SHIFT SELECTOR ILLUMINATION
Connector Type	TK02FBR-B



Terminal No.	Color	Wire	Signal Name [Specification]
1	R		
2	B		


Connector No.	M201
Connector Name	WIRE TO WIRE
Connector Type	TH32MW-NH



Terminal No.	Color	Wire	Signal Name [Specification]
1	Y		
2	BG		
5	V		
6	P		
7	SB		
10	G		
11	L		
12	R		
13	W		
14	L		
15	G		
16	Y		
17	W		
18	BR		


Terminal No.	Color	Wire	Signal Name [Specification]
1	W		
2	L		
3	Y		
6	B		
7	B		
9	R		

Connector No.	M204
Connector Name	CLIMATE CONTROLLED SEAT SWITCH (DRIVER SIDE)
Connector Type	TK10FW




Terminal No.	Color	Wire	Signal Name [Specification]
1	BG		
2	V		
3	P		
4	BR		
5	GR		
6	B		
8	B		

Connector No.	M205
Connector Name	CLIMATE CONTROLLED SEAT SWITCH (PASSENGER SIDE)
Connector Type	TK08FBR



Terminal No.	Color	Wire	Signal Name [Specification]
1	SB		
2	G		
3	L		
4	BG		
5	V		
6	B		
7	R		
8	B		

Connector No.	M206
Connector Name	WIRE TO WIRE
Connector Type	NS08MW-GS



Terminal No.	Color	Wire	Signal Name [Specification]
1	Y		
2	BG		
3	V		
4	SB		
5	B		
6	G		
7	L		
8	SHIELD		

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



# ILLUMINATION

< WIRING DIAGRAM >

**ILLUMINATION**

Connector No. M207

Connector Name WIRE TO WIRE

Connector Type NSDBFT-OS

18	L	--
19	G	--
20	R	--
21	B	--
22	S	--
23	GP	--
24	P	--

Connector No. M221

Connector Name WIRE TO WIRE

Connector Type M03FW-LC

Terminal No.	Color Of Wire	Signal Name [Specification]
13	--	--
14	--	--
15	--	--
16	--	--
17	--	--
18	--	--
19	--	--
20	--	--

Connector No. M222

Connector Name WIRE TO WIRE

Connector Type M03MW-LC

Terminal No.	Color Of Wire	Signal Name [Specification]
2	G	--
5	SHIELD	--
6	R	--
7	G	--
8	B	--
9	B	--
10	P	--
11	BR	--
12	R	--
13	BR	--
14	V	--
17	LG	--

Connector No. M210

Connector Name AV CONTROL UNIT

Connector Type TH32FW-NH

Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	--
2	BG	--
3	V	--
4	SB	--
5	B	--
6	G	--
7	R	--
8	SHIELD	--

Connector No. M220

Connector Name AV CONTROL UNIT

Connector Type TH32FW-NH

Terminal No.	Color Of Wire	Signal Name [Specification]
13	--	--
14	--	--
15	--	--
16	--	--
17	--	--
18	--	--
19	--	--
20	--	--

Connector No. M203

Connector Name COMBINATION SWITCH (SPIRAL CABLE)

Connector Type TK0BEFY

Terminal No.	Color Of Wire	Signal Name [Specification]
13	--	--
14	--	--
15	--	--
16	--	--
17	--	--
18	--	--
19	--	--
20	--	--

Connector No. R7

Connector Name WIRE TO WIRE

Connector Type TH24FW-NH

Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	--
2	Y	--
3	W	--
4	R	--
5	L	--
6	B	--
7	R	--
8	B	--
9	V	--
10	V	--
11	BR	--
12	G	--
13	L	--
14	L	--
15	LG	--
16	Y	--
17	W	--
18	R	--
19	B	--
20	R	--
21	R	--
22	G	--
23	L	--
24	LG	--

JRLWD1168GB

# ILLUMINATION

< WIRING DIAGRAM >

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P

## ILLUMINATION

Connector No.	R11
Connector Name	WIRE TO WIRE
Connector Type	TK02RFP-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
2	G	-
5	SHIELD	-
6	R	-
7	G	-
8	B	-
9	B	-
10	R	-
11	BR	-
12	R	-
13	BR	-
14	V	-
17	L	-
18	LG	-
19	R	-
20	G	-
21	R	-
22	B	-
23	GR	-
24	P	-

Connector No.	R15
Connector Name	MAP LAMP
Connector Type	TK08FCY



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	SB	-
3	Y	-
4	Y	-
5	B/Y	-
6	G	-

Connector No.	R22
Connector Name	TELEMATICS SWITCH
Connector Type	TK08FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	-
2	BR	-
3	G	-
5	SB	-
6	B	-
7	B	-

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000010098516

OVERALL SEQUENCE



JMKIA8652GB

DETAILED FLOW

# DIAGNOSIS AND REPAIR WORK FLOW

## < BASIC INSPECTION >

---

### 1. GET INFORMATION FOR SYMPTOM

---

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

### 2. CHECK DTC

---

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

#### Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

### 3. CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

### 4. CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

### 5. PERFORM DTC CONFIRMATION PROCEDURE

---

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to DTC INSPECTION PRIORITY CHART, and determine trouble diagnosis order.

#### **NOTE:**

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

#### Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-47. "Intermittent Incident"](#).

### 6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

---

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

#### Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

### 7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

---

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P

## DIAGNOSIS AND REPAIR WORK FLOW

### < BASIC INSPECTION >

---

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-47. "Intermittent Incident"](#).

### 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

---

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

### 9. FINAL CHECK

---

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.



# INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

#### Description

INFOID:0000000010098517

Provides the interior room lamp power supply. Also cuts the power supply when the interior room lamp battery saver activating.

#### Component Function Check

INFOID:0000000010098518

#### 1. CHECK INTERIOR ROOM LAMP POWER SUPPLY FUNCTION

##### CONSULT ACTIVE TEST

- Turn ignition switch ON.
- Turn each interior room lamp ON.
  - Personal lamp
  - Map lamp
  - Foot lamp
  - Trunk room lamp
  - Step lamp
  - Outside handle lamp
  - Vanity mirror lamp
- Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
- With operating the test items, check that each interior room lamp turns ON/OFF.

**Off** : Interior room lamp OFF

**On** : Interior room lamp ON

Does the interior room lamp turn ON/OFF?

- YES >> Interior room lamp power supply circuit is normal.  
NO >> Refer to [INL-57, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:0000000010098519

#### 1. CHECK INTERIOR ROOM LAMP POWER SUPPLY OUTPUT

##### CONSULT ACTIVE TEST

- Turn ignition switch OFF.
- Disconnect the following connectors.
  - Personal lamp
  - Map lamp
  - Foot lamp (both sides)
  - Trunk room lamp
  - Step lamp (ALL)
  - Outside handle lamp (both sides)
  - Vanity mirror lamp (both sides)
- Turn ignition switch ON.
- Select "BATTERY SAVER" of BCM (BATTERY SAVER) active test item.
- With operating the test item, check voltage between BCM harness connector and ground.

BCM		(-)	Test item	Voltage (Approx.)	
(+) Connector Terminal					
M122	56	Ground	BATTERY SAVER	Off	0 V
			On	12 V	

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> GO TO 3.

# INTERIOR ROOM LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## 2. CHECK INTERIOR ROOM LAMP POWER SUPPLY OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the BCM connector.
3. Check continuity between BCM harness connector and each interior room lamp harness connector.

BCM		Each interior room lamp		Continuity	
Connector	Terminal	Connector	Terminal		
M122	56	Personal lamp	R14	1	Existed
		Map lamp	R15		
		Foot lamp (driver side)	M186		
		Foot lamp (passenger side)	M114		
		Trunk room lamp	B47		
		Step lamp (driver side)	D12		
		Step lamp (passenger side)	D42		
		Step lamp (Rear LH)	D57		
		Step lamp (Rear RH)	D77		
		Outside handle lamp (driver side)	D17	3	
		Outside handle lamp (passenger side)	D47		
		Vanity mirror lamp (driver side)	R12	2	
		Vanity mirror lamp (passenger side)	R13		

**Is the inspection result normal?**

- YES >> Check for internal short circuit of each interior room lamp.  
 NO >> Repair or replace harnesses.

## 3. CHECK INTERIOR ROOM LAMP POWER SUPPLY SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the BCM connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M122	56		Not existed

**Is the inspection result normal?**

- YES >> Replace BCM. Refer to [BCS-90. "Removal and Installation"](#).  
 NO >> Repair or replace harnesses.

# INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## INTERIOR ROOM LAMP CONTROL CIRCUIT

### Description

INFOID:0000000010098520

Controls each interior room lamp (ground side) by PWM signal.

#### NOTE:

PWM signal control period is approximately 250 Hz (in the gradual brightening/dimming).

### Component Function Check

INFOID:0000000010098521

#### NOTE:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Map lamp bulb
- Personal lamp bulb
- Foot lamp bulb

### 1.CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

#### ⓐCONSULT ACTIVE TEST

1. Switch the map lamp switch to DOOR.
2. Turn ignition switch ON.
3. Select "INT LAMP" of BCM (INT LAMP) active test item.
4. With operating the test items, check that each interior room lamp turns ON/OFF (gradual brightening/dimming).

**On** : Interior room lamp gradual brightening

**Off** : Interior room lamp gradual dimming

Does the interior room lamp turns ON/OFF (gradual brightening/dimming)?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-59, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000010098522

### 1.CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

#### ⓐCONSULT ACTIVE TEST

1. Turn ignition switch OFF.
2. Remove all the bulbs of map lamp, foot lamp and personal lamp.
3. Turn ignition switch ON.
4. Select "INT LAMP" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and ground.

BCM		Ground	Test item		Continuity
Connector	Terminal		INT LAMP	On	Existed
M122	63			Off	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Continuity exists and remains unchanged: GO TO 3.

NO-2 >> Continuity does not exist and remains unchanged: Replace BCM. Refer to [BCS-90, "Removal and Installation"](#).

### 2.CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector, map lamp connector, personal lamp connector and foot lamp connector.
3. Check continuity between BCM harness connector and foot lamp harness connector.

# INTERIOR ROOM LAMP CONTROL CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

BCM		Foot lamp			Continuity
Connector	Terminal	Connector		Terminal	
M122	63	Driver side	M186	2	Existed
		Passenger side	M114		

4. Check continuity between BCM harness connector and map lamp harness connector.

BCM		Map lamp		Continuity
Connector	Terminal	Connector	Terminal	
M122	63	R15	2	Existed

5. Check continuity between personal lamp harness connector and map lamp harness connector.

Personal lamp		Map lamp		Continuity
Connector	Terminal	Connector	Terminal	
R14	3	R15	4	Existed

Is the inspection result normal?

YES >> Replace map lamp, personal lamp or foot lamp.

NO >> Repair or replace harnesses.

### 3. CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

- Turn ignition switch OFF.
- Disconnect BCM connector, map lamp connector, personal lamp connector and foot lamp connector.
- Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M122	63		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-90, "Removal and Installation"](#).

NO >> Repair or replace harnesses.

# TRUNK ROOM LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## TRUNK ROOM LAMP CIRCUIT

### Description

INFOID:000000010098523

Controls the trunk room lamp (ground side) to turn the trunk room lamp ON and OFF.

### Diagnosis Procedure

INFOID:000000010098524

#### NOTE:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Trunk room lamp bulb

### 1. CHECK TRUNK ROOM LAMP OUTPUT

1. Turn ignition switch OFF.
2. Remove the trunk room lamp bulb.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Condition		Continuity
Connector	Terminal		Trunk lid	Open	Existed
M121	49			Closed	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Continuity exists and remains unchanged: GO TO 3.

NO-2 >> Continuity does not exist and remains unchanged: Replace BCM. Refer to [BCS-90. "Removal and Installation"](#).

### 2. CHECK TRUNK ROOM LAMP OPEN CIRCUIT

1. Disconnect BCM connector and trunk room lamp connector.
2. Check continuity between BCM harness connector and trunk room lamp harness connector.

BCM		Trunk room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M121	49	B47	2	Existed

Is the inspection result normal?

YES >> Replace trunk room lamp.

NO >> Repair or replace harnesses.

### 3. CHECK TRUNK ROOM LAMP SHORT CIRCUIT

1. Disconnect BCM connector and trunk room lamp connector.
2. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		Not existed
M121	49		

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-90. "Removal and Installation"](#).

NO >> Repair or replace harnesses.

# STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## STEP LAMP CIRCUIT

### Description

INFOID:000000010098525

Controls the step lamp (ground side) to turn the step lamp ON and OFF.

### Component Function Check

INFOID:000000010098526

#### NOTE:

Before performing the diagnosis, check that the following is normal.

- Interior room lamp power supply
- Step lamp bulb

### 1.CHECK STEP LAMP OPERATION

#### CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
3. With operating the test items, check that step lamp turns ON/OFF.

**On** : Step lamp ON

**Off** : Step lamp OFF

#### Does the step lamp turn ON/OFF?

- YES >> Step lamp circuit is normal.  
NO >> Refer to [INL-62, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010098527

### 1.CHECK STEP LAMP OUTPUT

#### CONSULT ACTIVE TEST

1. Turn ignition switch OFF.
2. Remove the step lamp bulbs (ALL).
3. Turn ignition switch ON.
4. Select "STEP LAMP TEST" of BCM (INT LAMP) active test item.
5. With operating the test item, check continuity between BCM harness connector and ground.

BCM		Ground	Test item		Continuity
Connector	Terminal		STEP LAMP TEST	On	Existed
M122	62			On	Existed
			Off	Not existed	

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO-1 >> Continuity exists and remains unchanged: GO TO 3.  
NO-2 >> Continuity does not exist and remains unchanged: Replace BCM. Refer to [BCS-90, "Removal and Installation"](#).

### 2.CHECK STEP LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector, and step lamp connector.
3. Check continuity between BCM harness connector and step lamp harness connector.

BCM		Step lamp		Continuity
Connector	Terminal	Connector	Terminal	
M122	62	Driver side	D12	Existed
		Passenger side	D42	
		Rear LH	D57	
		Rear RH	D77	

# STEP LAMP CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace step lamp.

NO >> Repair or replace harnesses.

### 3. CHECK STEP LAMP SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and step lamp connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M122	62		Not existed

Is the inspection result normal?

YES >> Repair or replace harnesses.

NO >> Replace BCM. Refer to [BCS-90, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

INL

# OUTSIDE HANDLE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## OUTSIDE HANDLE LAMP CIRCUIT

### Description

INFOID:000000010098528

Controls the outside handle lamp (ground side) to turn the outside handle lamp ON and OFF.

### Diagnosis Procedure

INFOID:000000010098529

#### NOTE:

Before performing the diagnosis, check that the interior room lamp power supply is normal.

### 1. CHECK OUTSIDE HANDLE LAMP OUTPUT

1. Turn ignition switch OFF.
2. Disconnect outside handle lamp connector.
3. Check continuity between BCM harness connector and ground.

BCM		Ground	Condition		Continuity
Connector	Terminal		Any door	Open	Existed
M123	72			Closed	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Continuity exists and remains unchanged: GO TO 3.

NO-2 >> Continuity does not exist and remains unchanged: Replace BCM. Refer to [BCS-90, "Removal and Installation"](#).

### 2. CHECK OUTSIDE HANDLE LAMP OPEN CIRCUIT

Check continuity between BCM harness connector and outside handle lamp harness connector.

BCM		Outside Handle lamp		Continuity
Connector	Terminal	Connector	Terminal	
M123	72	Driver side	D17	Existed
		Passenger side	D47	

Is the inspection result normal?

YES >> Replace outside handle lamp.

NO >> Repair or replace harnesses.

### 3. CHECK OUTSIDE HANDLE LAMP SHORT CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	72		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-90, "Removal and Installation"](#).

NO >> Repair or replace harnesses.



# PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

### Description

INFOID:0000000010098530

Provides the power supply and the ground to control the push-button ignition switch illumination.

### Component Function Check

INFOID:0000000010098531

### 1. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

#### CONSULT ACTIVE TEST

1. Turn ignition switch ON.
2. Select "ENGINE SW ILLUMI" of BCM (INTELLIGENT KEY) active test item.
3. With operating the test items, check that the push-button ignition switch illumination turns ON/OFF.

**On** : Push-button ignition switch illumination ON

**Off** : Push-button ignition switch illumination OFF

#### Does the push-button ignition switch illumination turn ON/OFF?

- YES >> Push-button ignition switch illumination circuit is normal.  
NO >> Refer to [INL-65, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000010098532

### 1. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OUTPUT

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check voltage between push-button ignition switch harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
Connector	Terminal			
M50	3	Ground	Push-button ignition switch illumination ON	12 V
			Push-button ignition switch illumination OFF	0 V

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 2.

### 2. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and the push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M123	90	M50	3	Existed

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harnesses.

### 3. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	90		Not existed

# PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-90, "Removal and Installation"](#).

NO >> Repair or replace harnesses.

## 4. CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between push-button ignition switch harness connector and BCM harness connector.

Push-button ignition switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M50	2	M123	92	Existed

3. Check continuity between push-button ignition switch harness connector and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M50	2		Not existed

Is the inspection result normal?

YES >> Replace push-button ignition switch.

NO >> Repair or replace harnesses.

# INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### INTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:0000000010098533

**NOTE:**

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All the following lamps do not turn ON. <ul style="list-style-type: none"> <li>• Map lamp</li> <li>• Personal lamp</li> <li>• Vanity mirror lamp</li> <li>• Foot lamp</li> <li>• Step lamp</li> <li>• Outside handle lamp</li> <li>• Trunk room lamp</li> </ul>	<ul style="list-style-type: none"> <li>• Harness between BCM and each interior room lamp</li> <li>• BCM</li> </ul>	Interior room lamp power supply circuit Refer to <a href="#">INL-57</a> .
<ul style="list-style-type: none"> <li>• Interior room lamp does not turn ON even though the door is open. (It turns ON when turning the interior room lamp ON.)</li> <li>• Interior room lamp does not turn OFF even though the door is closed.</li> </ul>	<ul style="list-style-type: none"> <li>• Harness between BCM and each door switch</li> <li>• Harness between BCM and each interior room lamp</li> <li>• BCM</li> </ul>	Door switch circuit Refer to <a href="#">DLK-77</a> . <hr/> Interior room lamp control circuit Refer to <a href="#">INL-59</a> .
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to <a href="#">INL-14</a> .
<ul style="list-style-type: none"> <li>• Outside handle lamp does not turn ON even though the door is open.</li> <li>• Outside handle lamp does not turn OFF even though the door is closed.</li> </ul>	<ul style="list-style-type: none"> <li>• Harness between BCM and each door switch</li> <li>• Harness between BCM and outside handle lamp</li> <li>• BCM</li> </ul>	Door switch circuit Refer to <a href="#">DLK-77</a> . <hr/> Outside handle lamp circuit Refer to <a href="#">INL-64</a> .
<ul style="list-style-type: none"> <li>• Trunk room lamp does not turn ON even though the trunk lid is open. (It turns ON when turning the trunk room lamp ON.)</li> <li>• Trunk room lamp or does not turn OFF even though the trunk lid is closed.</li> </ul>	<ul style="list-style-type: none"> <li>• Harness between BCM and trunk closure assembly</li> <li>• Harness between BCM and trunk room lamp</li> <li>• BCM</li> </ul>	Trunk lid open signal circuit Refer to <a href="#">DLK-90</a> . <hr/> Trunk room lamp circuit Refer to <a href="#">INL-61</a> .
<ul style="list-style-type: none"> <li>• Step lamps (ALL) do not turn ON.</li> <li>• Step lamps (ALL) do not turn OFF.</li> </ul>	<ul style="list-style-type: none"> <li>• Harness between BCM and each step lamp</li> <li>• BCM</li> </ul>	Door switch circuit Refer to <a href="#">DLK-77</a> . <hr/> Step lamp circuit Refer to <a href="#">INL-62</a> .
Push-button ignition switch illumination does not illuminate.	<ul style="list-style-type: none"> <li>• Harness between BCM and push-button ignition switch</li> <li>• BCM</li> </ul>	Push-button ignition switch illumination circuit Refer to <a href="#">INL-65</a> .
Interior room lamp battery saver does not activate.	BCM	Replace BCM. Refer to <a href="#">BCS-90</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**INL**

# MAP LAMP


< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION

### MAP LAMP

#### Exploded View


INFOID:000000010098534



1. Map lamp assembly

2. Bulb

3. Lens

 : Pawl

#### Removal and Installation

INFOID:000000010098535

##### CAUTION:


- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to prevent electric leakage.


##### Removal

1. Remove front and rear assist grips (LH and RH). Refer to [INT-52, "Removal and Installation"](#).
2. Remove center pillar upper garnish (LH and RH). Refer to [INT-42, "CENTER PILLAR UPPER GARNISH : Removal and Installation"](#).
3. Remove partially front body side welt (headlining side).
4. Remove front pillar garnish. Refer to [INT-36, "FRONT PILLAR GARNISH : Removal and Installation"](#).
5. Remove front camera finisher. Refer to [INT-52, "Removal and Installation"](#).
6. Remove sun visor assembly (LH and RH). Refer to [INT-52, "Removal and Installation"](#).
7. Remove front roof finisher. Refer to [INT-52, "Removal and Installation"](#).
8. Remove sun visor holders (LH and RH). Refer to [INT-52, "Removal and Installation"](#).
9. Open sunroof glass.
10. Insert a remover tool between the headlining and roof panel, and disengage metal clips (B). Pull down map lamp assembly to disengage joint dual-lock fastener (A).

##### CAUTION:

- When removing, always use a remover tool that is made of plastic.
- Map lamp is crimped from back of headlining.
- To prevent damage of the sunroof, hold the sunroof with a rope or tape before removal operation.

 : Metal clip



11. Remove map lamp assembly.

# MAP LAMP

## < REMOVAL AND INSTALLATION >


### NOTE:

Operate from the opening part of sunroof to ease the work.

- Remove harness connector (A).
- Remove screws (B), and then remove map lamp bracket (1).
- Remove map lamp back plate (3) from headlining while pressing engagement of each pawls in the direction as shown in the figure.

### CAUTION:

When removing, support map lamp assembly (2) by hand so that it does not drop during the operation.



### Installation

Install in the reverse order of removal.

### Replacement


INFOID:0000000010098536


### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to prevent electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.


### MAP LAMP BULB

- Insert a remover tool (A) into the gap between the lens to disengage fixing pawls as shown by the arrow in the figure, and then remove the lens.

 : Pawl



- Rotate the bulb clockwise or counterclockwise by 90° and remove the bulb as shown in the figure.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P


# VANITY MIRROR LAMP

< REMOVAL AND INSTALLATION >

## VANITY MIRROR LAMP


Exploded View

INFOID:000000010098537



1. Lens

2. Bulb

 : Pawl

## Replacement


INFOID:000000010098538

### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.


### VANITY MIRROR LAMP BULB

1. Insert a remover tool (A) into the gap between the lens to disengage fixing pawls as shown by the arrow in the figure, and then remove the lens.

 : Pawl

### CAUTION:

- Use a remover tool wrapped in tape.
- Apply protective tape (B) around the vanity mirror to protect the surface from damage.



2. Remove the bulb.


# CIGARETTE LIGHTER ILLUMINATION

< REMOVAL AND INSTALLATION >

## CIGARETTE LIGHTER ILLUMINATION

### Exploded View

INFOID:000000010098539



1. Bulb

2. Bulb socket

↔ : Vehicle front

### Removal and Installation

INFOID:000000010098540

- Remove console finisher assembly. Refer to [IP-24, "Removal and Installation"](#).
- Remove ashtray assembly. Refer to [IP-23, "Exploded View"](#).

### Replacement

INFOID:000000010098541

#### **CAUTION:**

- **Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.**
- **Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.**
- **Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.**
- **Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.**

### CIGARETTE LIGHTER ILLUMINATION BULB

1. Remove console finisher assembly, and then remove ashtray assembly. Refer to [IP-24, "Removal and Installation"](#).
2. Rotate bulb socket counterclockwise to unlock it.
3. Remove the bulb.


# REAR DOOR ASHTRAY ILLUMINATION

< REMOVAL AND INSTALLATION >

## REAR DOOR ASHTRAY ILLUMINATION

Exploded View

INFOID:000000010098542



1. Ashtray lamp assembly
2. Rear door finisher

### Removal and Installation

INFOID:000000010098543

Refer to [INT-33, "Exploded View"](#) for the rear door finisher installation or removal.

### Replacement


INFOID:000000010098544

#### **CAUTION:**

- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

### ASHTRAY ILLUMINATION BULB

1. Remove rear door finisher. Refer to [INT-33, "REAR DOOR FINISHER : Removal and Installation"](#).
2. Rotate bulb socket (1) counterclockwise to unlock it.
3. Remove the bulb (2) from bulb socket.






# GLOVE BOX LAMP

< REMOVAL AND INSTALLATION >

## GLOVE BOX LAMP

### Exploded View

INFOID:000000010098545



1. Bulb socket

2. Bulb

3. Instrument lower panel RH

### Removal and Installation

INFOID:000000010098546

Refer to [IP-12, "Exploded View"](#) for the instrument lower panel RH installation or removal.

### Replacement

INFOID:000000010098547

#### **CAUTION:**

- **Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.**
- **Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.**
- **Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.**
- **Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.**

### GLOVE BOX LAMP BULB

1. Remove instrument lower cover. Refer to [IP-13, "Removal and Installation"](#).
2. Remove glove box assembly, and then remove instrument lower panel RH. Refer to [IP-13, "Removal and Installation"](#).
3. Rotate the bulb socket counterclockwise to unlock it.
4. Remove the bulb.


# FOOT LAMP

< REMOVAL AND INSTALLATION >

## FOOT LAMP DRIVER SIDE

### DRIVER SIDE : Exploded View


INFOID:000000010098548



1. Foot lamp case

2. Bulb

3. Lens

 : Pawl

 : Metal clip

### DRIVER SIDE : Removal and Installation


INFOID:000000010098549

#### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.

#### REMOVAL

1. Remove instrument lower panel (1). Refer to [IP-24. "Removal and Installation"](#)
2. Disconnect foot lamp harness connector.
3. Remove foot lamp case (2) downward while pressing metal clips (A), in the directions indicated by arrows as shown in the figure.



#### INSTALLATION

Install in the reverse order of removal.

### DRIVER SIDE : Replacement

INFOID:000000010098550

#### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.

# FOOT LAMP

## < REMOVAL AND INSTALLATION >


- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

### FOOT LAMP BULB


1. Remove the foot lamp assembly. Refer to [INL-74, "DRIVER SIDE : Removal and Installation"](#).
2. Remove the lens (1).
  - a. Insert a remover tool (A) into the gap between the lens and foot lamp case (2).
  - b. Disengage the lens fixing pawls, and then remove the lens.

**CAUTION:**

Use a remover tool wrapped in tape.

 : Pawl


3. Remove the bulb.



### PASSENGER SIDE

#### PASSENGER SIDE : Exploded View


INFOID:000000010098551



1. Foot lamp case

2. Bulb

3. Lens

 : Pawl

 : Metal clip

#### PASSENGER SIDE : Removal and Installation

INFOID:000000010098552

**CAUTION:**

- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.


### REMOVAL

1. Remove instrument lower cover (1). Refer to [IP-24, "Removal and Installation"](#)

# FOOT LAMP

## < REMOVAL AND INSTALLATION >

2. Disconnect foot lamp harness connector.
3. Remove foot lamp case (2) downward while pressing metal clips (A), in the directions indicated by arrows as shown in the figure.



## INSTALLATION

Install in the reverse order of removal.

## PASSENGER SIDE : Replacement

INFOID:000000010098553

### CAUTION:


- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

## FOOT LAMP BULB


1. Remove the foot lamp assembly. Refer to [INL-75. "PASSENGER SIDE : Removal and Installation"](#).
2. Remove the lens (1).
  - a. Insert a remover tool (A) into the gap between the lens and foot lamp case (2).
  - b. Disengage the lens fixing pawls, and then remove the lens.

### CAUTION:

Use a remover tool wrapped in tape.

 : Pawl

3. Remove the bulb.




# STEP LAMP

< REMOVAL AND INSTALLATION >

## STEP LAMP

### Exploded View


INFOID:000000010098554



1. Step lamp case

2. Bulb

3. Lens

 : Pawl

 : Metal clip

### Removal and Installation

INFOID:000000010098555

#### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.

#### REMOVAL

1. Insert any appropriate tool into the gap between the step lamp case and door finisher to remove step lamp case.
2. Disconnect step lamp harness connector.

#### INSTALLATION

Install in the reverse order of removal.

### Replacement

INFOID:000000010098556

#### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

#### STEP LAMP BULB

1. Insert any appropriate tool into the gap between the lens to remove the lens.
2. Remove the bulb.


# PERSONAL LAMP

< REMOVAL AND INSTALLATION >


## PERSONAL LAMP

### Exploded View

INFOID:000000010098557



1. Personal lamp case
2. Personal lamp finisher
3. Lens
4. Bulb

 : Pawl

### Removal and Installation


INFOID:000000010098558

#### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.
- Replace the personal lamp case as a set (right and left). After removing the headlining assembly, remove the personal lamp case. Refer to [INT-51, "Exploded View"](#).

#### REMOVAL

1. Remove headlining assembly. Refer to [INT-52, "Removal and Installation"](#).
2. Insert any appropriate tool into the gap between the lens to remove the lens.
3. Press the pawls (A) on both sides in the direction shown by the arrow in the figure using appropriate tool, and then pull out the personal lamp finisher.




4. Remove personal lamp case from headlining assembly.

#### INSTALLATION

# PERSONAL LAMP

## < REMOVAL AND INSTALLATION >

Press the personal lamp finisher to the headlining. Pull the personal lamp case pawls in the direction shown by the arrow in the figure using appropriate tool.



## Replacement

INFOID:000000010098559

### **CAUTION:**

- **Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.**
- **Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.**
- **Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.**
- **Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.**

## PERSONAL LAMP BLUB

1. Insert any appropriate tool into the gap between the lens to remove the lens.
2. Remove the bulb.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

INL

## OUTSIDE HANDLE LAMP

< REMOVAL AND INSTALLATION >

---

### OUTSIDE HANDLE LAMP

#### Exploded View

INFOID:000000010098560

Always replace outside handle lamp together with outside handle as a set, when replacing since outside handle lamp is integrated with outside handle. Refer to [DLK-185. "OUTSIDE HANDLE : Removal and Installation"](#).




# TRUNK ROOM LAMP

< REMOVAL AND INSTALLATION >

## TRUNK ROOM LAMP

Exploded View


INFOID:000000010098561



1. Trunk room lamp case

2. Bulb

3. Lens

 : Pawl

 : Metal clip

## Removal and Installation


INFOID:000000010098562


### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

### REMOVAL

1. Insert a remover tool (A) into the gap between the lens to disengage fixing pawls as shown by the arrow in the figure, and then remove the lens.

 : Pawl




# TRUNK ROOM LAMP

## < REMOVAL AND INSTALLATION >

2. Insert a remover tool (A) into the gap between the trunk room lamp case to disengage fixing metal clips as shown by the arrow in the figure, and then remove the trunk room lamp case.

 : Metal clip



3. Disconnect trunk room lamp harness connector.

## INSTALLATION

Install in the reverse order of removal.

## Replacement


INFOID:0000000010098563


### CAUTION:

- Disconnect the battery negative terminal or remove power circuit fuse while performing the operation to electric leakage.
- Never touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Never touch the glass surface of the bulb with bare hands because the surface is very hot just after the lamp is turned OFF to prevent a burns.
- Leaving the bulb removed from housing for a long period of time can deteriorate performance of the lens and reflector (causing dirty or clouding). Always prepare a new bulb and have it on hand when replacing the bulb.

## TRUNK ROOM LAMP BULB

1. Insert a remover tool (A) into the gap between the lens to disengage fixing pawls as shown by the arrow in the figure, and then remove the lens.

 : Pawl



2. Remove the bulb.

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### bulb specifications

INFOID:0000000010098564

Item	Type	Wattage (W)
Push-button ignition switch illumination	LED	—
Map lamp	—	8
Console lamp (integrated into the map lamp assembly)	LED	—
Vanity mirror lamp	—	2
Cigarette lighter illumination (common use with ashtray illumination)	Wedge	1.1
Rear door ashtray illumination	Wedge	2
Glove box lamp	Wedge	2
Foot lamp	Wedge	3.4
Step lamp	Wedge	5
Personal lamp	Wedge	8
Outside handle lamp	LED	—
Trunk room lamp	Wedge	5

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
INL  
M  
N  
O  
P