

# SECTION PCS

## POWER CONTROL SYSTEM

### CONTENTS

<b>IPDM E/R</b>	CONSULT Function (IPDM E/R) .....	13
<b>PRECAUTION</b> .....	<b>ECU DIAGNOSIS INFORMATION</b> .....	16
<b>PRECAUTIONS</b> .....	<b>IPDM E/R</b> .....	16
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	Reference Value .....	16
Precaution for Procedure without Cowl Top Cover.....	Fail-safe .....	23
Precautions for Removing Battery Terminal .....	DTC Index .....	24
<b>SYSTEM DESCRIPTION</b> .....	<b>WIRING DIAGRAM</b> .....	25
<b>COMPONENT PARTS</b> .....	<b>IPDM E/R</b> .....	25
<b>IPDM E/R</b> .....	Wiring Diagram .....	25
IPDM E/R : Component Parts Location .....	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	28
<b>SYSTEM</b> .....	<b>U1000 CAN COMM CIRCUIT</b> .....	28
<b>RELAY CONTROL SYSTEM</b> .....	Description .....	28
RELAY CONTROL SYSTEM : System Diagram .....	DTC Logic .....	28
RELAY CONTROL SYSTEM : System Description .....	Diagnosis Procedure .....	28
RELAY CONTROL SYSTEM : Fail-safe .....	<b>B2098 IGNITION RELAY ON STUCK</b> .....	29
<b>POWER CONTROL SYSTEM</b> .....	Description .....	29
POWER CONTROL SYSTEM : System Diagram.....	DTC Logic .....	29
POWER CONTROL SYSTEM : System Description .....	Diagnosis Procedure .....	29
<b>SIGNAL BUFFER SYSTEM</b> .....	<b>B2099 IGNITION RELAY OFF STUCK</b> .....	31
SIGNAL BUFFER SYSTEM : System Diagram .....	Description .....	31
SIGNAL BUFFER SYSTEM : System Description.....	DTC Logic .....	31
<b>POWER CONSUMPTION CONTROL SYSTEM</b> .....	Diagnosis Procedure .....	31
POWER CONSUMPTION CONTROL SYSTEM : System Diagram .....	<b>POWER SUPPLY AND GROUND CIRCUIT</b> ....	33
POWER CONSUMPTION CONTROL SYSTEM : System Description .....	Diagnosis Procedure .....	33
<b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....	<b>REMOVAL AND INSTALLATION</b> .....	34
Diagnosis Description .....	<b>IPDM E/R</b> .....	34
	Exploded View .....	34
	Removal and Installation .....	34
	<b>POWER DISTRIBUTION SYSTEM</b>	
	<b>PRECAUTION</b> .....	36

<b>PRECAUTIONS</b> .....	36	Component Inspection .....	62
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	36	<b>B2615 BLOWER RELAY CIRCUIT</b> .....	64
Precautions for Removing Battery Terminal .....	36	DTC Logic .....	64
<b>SYSTEM DESCRIPTION</b> .....	37	Diagnosis Procedure .....	64
<b>COMPONENT PARTS</b> .....	37	Component Inspection .....	65
Component Parts Location .....	37	<b>B2616 IGNITION RELAY CIRCUIT</b> .....	66
Component Description .....	37	DTC Logic .....	66
BCM .....	37	Diagnosis Procedure .....	66
Ignition Relay .....	37	Component Inspection .....	67
Accessory Relay .....	38	<b>B2618 BCM</b> .....	68
Blower Relay .....	38	DTC Logic .....	68
Push-Button Ignition Switch .....	38	Diagnosis Procedure .....	68
<b>SYSTEM</b> .....	39	<b>B261A PUSH-BUTTON IGNITION SWITCH</b> ....	69
<b>POWER DISTRIBUTION SYSTEM</b> .....	39	DTC Logic .....	69
POWER DISTRIBUTION SYSTEM : System Diagram .....	39	Diagnosis Procedure .....	69
POWER DISTRIBUTION SYSTEM : System Description .....	39	<b>B26F1 IGNITION RELAY</b> .....	71
Fail-safe .....	40	DTC Logic .....	71
<b>DIAGNOSIS SYSTEM (BCM)</b> .....	42	Diagnosis Procedure .....	71
<b>COMMON ITEM</b> .....	42	<b>B26F2 IGNITION RELAY</b> .....	73
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) .....	42	DTC Logic .....	73
<b>INTELLIGENT KEY</b> .....	43	Diagnosis Procedure .....	73
INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) .....	43	<b>B26F6 BCM</b> .....	75
<b>ECU DIAGNOSIS INFORMATION</b> .....	48	DTC Logic .....	75
<b>BCM</b> .....	48	Diagnosis Procedure .....	75
List of ECU Reference .....	48	<b>PUSH-BUTTON IGNITION SWITCH</b> .....	76
<b>WIRING DIAGRAM</b> .....	49	Component Function Check .....	76
<b>POWER DISTRIBUTION SYSTEM</b> .....	49	Diagnosis Procedure .....	76
Wiring Diagram .....	49	Component Inspection .....	77
<b>BASIC INSPECTION</b> .....	57	<b>PUSH-BUTTON IGNITION SWITCH POSITION INDICATOR</b> .....	79
<b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....	57	Description .....	79
Work Flow .....	57	Component Function Check .....	79
<b>PROCEDURE FOR TEMPORARILY DISABLING THE IGNITION BATTERY SAVER SYSTEM</b> .....	60	Diagnosis Procedure .....	79
Description .....	60	<b>SYMPTOM DIAGNOSIS</b> .....	81
Work Procedure .....	60	<b>PUSH-BUTTON IGNITION SWITCH DOES NOT OPERATE</b> .....	81
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	61	Description .....	81
<b>B2614 ACC RELAY CIRCUIT</b> .....	61	Diagnosis Procedure .....	81
DTC Logic .....	61	<b>PUSH-BUTTON IGNITION SWITCH POSITION INDICATOR DOES NOT ILLUMINATE ...</b> ..	82
Diagnosis Procedure .....	61	Description .....	82
		Diagnosis Procedure .....	82
		<b>REMOVAL AND INSTALLATION</b> .....	83
		<b>PUSH-BUTTON IGNITION SWITCH</b> .....	83
		Exploded View .....	83
		Removal and Installation .....	83

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000012352366

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precaution for Procedure without Cowl Top Cover

INFOID:000000012352367

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



## PRECAUTIONS

< PRECAUTION >

[IPDM E/R]

### Precautions for Removing Battery Terminal

INFOID:0000000012352368

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

**NOTE:**

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


**NOTE:**

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

**NOTE:**

The removal of 12V battery may cause a DTC detection error.



SEF289H


## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### IPDM E/R

#### IPDM E/R : Component Parts Location

INFOID:0000000012352369



- 1. IPDM E/R
- A. Engine room dash panel (RH)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P


PCS

## SYSTEM

## RELAY CONTROL SYSTEM

## RELAY CONTROL SYSTEM : System Diagram

INFOID:0000000012352370



## RELAY CONTROL SYSTEM : System Description

INFOID:0000000012352371

IPDM E/R activates the internal control circuit to perform the relay ON-OFF control according to the input signals from various sensors and the request signals received from control units via CAN communication.

**CAUTION:**

To prevent damage to the parts, IPDM E/R integrated relays cannot be removed.

# SYSTEM

## < SYSTEM DESCRIPTION >

[IPDM E/R]

Control relay	Input/output	Transmit unit	Control part	Reference page
Headlamp low relay	<ul style="list-style-type: none"> <li>Low beam request signal</li> <li>Daytime running light request signal</li> </ul>	BCM (CAN)	Headlamp (LO)	<a href="#">EXL-14</a>
Headlamp high relay	High beam request signal	BCM (CAN)	Headlamp (HI)	
Front fog lamp relay	Front fog light request signal	BCM (CAN)	Front fog lamp	<a href="#">EXL-23</a>
Tail lamp relay	Position light request signal	BCM (CAN)	<ul style="list-style-type: none"> <li>Parking lamp</li> <li>License plate lamp</li> <li>Tail lamp</li> <li>Side marker lamp</li> </ul>	<a href="#">EXL-21</a>
			Illumination	<a href="#">INL-9</a>
<ul style="list-style-type: none"> <li>Front wiper main relay</li> <li>Front wiper HI/LO relay</li> </ul>	Front wiper request signal	BCM (CAN)	Front wiper motor	<a href="#">WW-8</a>
	Front wiper position signal	Front wiper motor		
<ul style="list-style-type: none"> <li>Horn relay</li> <li>Vehicle security horn relay</li> </ul>	<ul style="list-style-type: none"> <li>Theft warning horn request signal</li> <li>Horn reminder signal</li> </ul>	BCM (CAN)	<ul style="list-style-type: none"> <li>Horn (high)</li> <li>Vehicle security horn</li> </ul>	<a href="#">SEC-16</a>
<ul style="list-style-type: none"> <li>Starter relay<sup>NOTE</sup></li> <li>Starter control relay</li> </ul>	Starter control relay signal	BCM (CAN)	Starter motor	<ul style="list-style-type: none"> <li><a href="#">SEC-9</a></li> <li><a href="#">SEC-9</a></li> </ul>
	Steering lock unit condition signal	Steering lock unit		
	Starter relay control signal	TCM		
A/C relay	A/C compressor request signal	ECM (CAN)	A/C compressor (magnet clutch)	<a href="#">HAC-14</a>
Ignition relay	Ignition switch ON signal	BCM (CAN)	Each control unit, sensor, actuator and relay (ignition power supply)	<a href="#">PCS-37</a>
	Vehicle speed signal	Combination meter (CAN)		
	Push-button ignition switch signal	Push-button ignition switch		
Daytime running light relay	<ul style="list-style-type: none"> <li>Daytime running light request signal</li> <li>Position light request signal</li> </ul>	BCM (CAN)	<ul style="list-style-type: none"> <li>Headlamp (LO)</li> <li>Parking lamp</li> <li>License plate lamp</li> <li>Tail lamp</li> <li>Side marker lamp</li> </ul>	<a href="#">EXL-17</a>

### NOTE:

BCM controls the starter relay.

## RELAY CONTROL SYSTEM : Fail-safe

INFOID:0000000012352372

### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> <li>Outputs the pulse duty signal (PWM signal) 100% when the ignition switch is turned ON</li> <li>Outputs the pulse duty signal (PWM signal) 0% when the ignition switch is turned OFF</li> </ul>
A/C compressor	A/C relay OFF
Alternator	Outputs the power generation command signal (PWM signal) 0%

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>• Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>• Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>• Headlamp high relay OFF</li> </ul>
<ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Illumination</li> <li>• Tail lamp</li> <li>• Side marker lamp</li> </ul>	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp relay and daytime running light relay when the ignition switch is turned ON</li> <li>• Turns OFF the tail lamp relay and daytime running light relay when the ignition switch is turned OFF</li> </ul>
Front wiper motor	<ul style="list-style-type: none"> <li>• The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>• The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the AUTO mode and the front wiper motor is operating.</li> <li>• Returns automatically wiper to stop position when ignition switch is turned ON if fail-safe control is activated while front wiper motor is operated and wiper stop in the other than stop position.</li> </ul>
Front fog lamp	Front fog lamp relay OFF
Horn	Horn OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF

### IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay and daytime running light relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay excitation coil side		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—
ON	OFF	Ignition relay ON stuck	<ul style="list-style-type: none"> <li>• Detects DTC “B2098: IGN RELAY ON CIRC”</li> <li>• Turns ON the tail lamp relay and daytime running light relay for 10 minutes</li> </ul>
OFF	ON	Ignition relay OFF stuck	Detects DTC “B2099: IGN RELAY OFF CIRC”

### FRONT WIPER PROTECTION FUNCTION

IPDM E/R detects front wiper stop position by a front wiper stop position signal.

When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

Ignition switch	Front wiper switch	Front wiper stop position signal
ON	OFF	The front wiper stop position signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper stop position signal does not change for 10 seconds.

#### NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

### STARTER MOTOR PROTECTION FUNCTION




IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

## POWER CONTROL SYSTEM

### POWER CONTROL SYSTEM : System Diagram

INFOID:000000012352373



### POWER CONTROL SYSTEM : System Description

INFOID:000000012352374

#### COOLING FAN CONTROL

IPDM E/R outputs pulse duty signal (PWM signal) to the cooling fan control module according to the status of the cooling fan speed request signal received from ECM via CAN communication. Refer to [EC-63, "COOLING FAN CONTROL : System Diagram"](#) (VQ37VHR) or [EC-1013, "COOLING FAN CONTROL : System Diagram"](#) (VK56VD).


#### ALTERNATOR CONTROL

IPDM E/R outputs power generation command signal (PWM signal) to the alternator according to the status of the power generation command value signal received from ECM via CAN communication. Refer to [CHG-8, "POWER GENERATION VOLTAGE VARIABLE CONTROL SYSTEM : System Diagram"](#).

## SIGNAL BUFFER SYSTEM

### SIGNAL BUFFER SYSTEM : System Diagram

INFOID:000000012352375



### SIGNAL BUFFER SYSTEM : System Description


INFOID:000000012352376

- IPDM E/R reads the status of the oil pressure switch and transmits the oil pressure switch signal to BCM via CAN communication (only for models with VQ37VHR engine). Refer to [MWI-16, "OIL PRESSURE WARNING LAMP : System Diagram"](#).
- IPDM E/R reads the status of the hood switch and transmits the hood switch signal to BCM via CAN communication. Refer to [SEC-9, "Hood Switch"](#).
- IPDM E/R receives the rear window defogger control signal from BCM via CAN communication and transmits it to ECM and AV control unit via CAN communication. Refer to [DEF-6, "System Diagram"](#).

## POWER CONSUMPTION CONTROL SYSTEM

## POWER CONSUMPTION CONTROL SYSTEM : System Diagram

INFOID:000000012352377



## POWER CONSUMPTION CONTROL SYSTEM : System Description

INFOID:000000012352378

### OUTLINE

- IPDM E/R incorporates a power consumption control function that reduces the power consumption according to the vehicle status.
- IPDM E/R changes its status (control mode) with the sleep wake up signal received from BCM via CAN communication.

#### Normal mode (wake-up)

- CAN communication is normally performed with other control units.
- Individual unit control by IPDM E/R is normally performed.

#### Low power consumption mode (sleep)

- Low power consumption control is active.
- CAN transmission is stopped.

### SLEEP MODE ACTIVATION

- IPDM E/R judges that the sleep-ready conditions are fulfilled when the ignition switch is OFF and none of the conditions below are present. Then it transmits a sleep-ready signal (ready) to BCM via CAN communication.
  - Outputting signals to actuators
  - Switches or relays operating
  - Hood switch status is kept 50 ms or less.
  - Output requests are being received from control units via CAN communication.
- IPDM E/R stops CAN communication and enters the low power consumption mode when it receives a sleep wake up signal (sleep) from BCM and the sleep-ready conditions are fulfilled.

### WAKE-UP OPERATION

- IPDM E/R changes from the low power consumption mode to the normal mode when it receives a sleep wake-up signal (wake up) from BCM or any of the following conditions is fulfilled. In addition, it transmits a sleep-ready signal (not-ready) to BCM via CAN communication to report the CAN communication start.
  - Ignition switch ON
  - The hood switch status changes.
  - An output request is received from a control unit via CAN communication.

## DIAGNOSIS SYSTEM (IPDM E/R)

## Diagnosis Description

INFOID:000000012352379

## AUTO ACTIVE TEST

## Description

In auto active test, the IPDM E/R sends a drive signal to the following systems to check their operation.

- Oil pressure warning lamp (only for models with VQ37VHR engine)
- Front wiper (LO, HI)
- Parking lamp
- License plate lamp
- Tail lamp
- Side marker lamp
- Front fog lamp
- Headlamp (LO, HI)
- A/C compressor (magnet clutch)
- Cooling fan (cooling fan control module)

## Operation Procedure

**CAUTION:**

**Wiper arm interferes with hood when wiper is operated while wiper arm is in the raised position. Always perform auto active test without setting wiper arm in the raised position. Always pour water on front windshield glass in advance to auto active test so that damage on front windshield glass surface is prevented.**

**NOTE:**

Never perform auto active test in the following condition.

- Engine is running
  - CONSULT is connected
1. Turn the ignition switch OFF.
  2. Turn the ignition switch ON, and within 20 seconds, press the front door switch (driver side) 10 times. Then turn the ignition switch OFF.

**NOTE:**

- Close passenger door.
- Within 5 seconds after ignition switch is turned to the ON position and when driver door switch is pressed 6 times or more within 4 seconds, self-diagnosis function for BOSE amp. activates and speaker sounds. After waiting for 5 seconds or more after ignition switch is turned to the ON position and when driver door switch is operated, self-diagnosis function for BOSE amp. does not activate.

3. Turn the ignition switch ON within 10 seconds. After that the horn sounds once and the auto active test starts.

**NOTE:**

Engine starts when ignition switch is turned ON while brake pedal is depressed.

4. The oil pressure warning lamp starts blinking when the auto active test starts.
5. After a series of the following operations is repeated 3 times, auto active test is completed.

**NOTE:**

- When auto active test has to be cancelled halfway through test, turn the ignition switch OFF.
- When auto active test is not activated, door switch may be the cause. Check door switch. Refer to [DLK-87, "Component Function Check"](#).

## Inspection in Auto Active Test

When auto active test is actuated, the following 6 steps are repeated 3 times.

Operation sequence	Inspection location	Operation
1	Oil pressure warning lamp (only for models with VQ37VHR engine)	Blinks continuously during operation of auto active test
2	Front wiper motor	LO for 5 seconds → HI for 5 seconds

# DIAGNOSIS SYSTEM (IPDM E/R)


## < SYSTEM DESCRIPTION >

[IPDM E/R]

Operation sequence	Inspection location	Operation
3	<ul style="list-style-type: none"> <li>Parking lamp</li> <li>License plate lamp</li> <li>Tail lamp</li> <li>Side marker lamp</li> <li>Front fog lamp</li> </ul>	10 seconds
4	Headlamp	<ul style="list-style-type: none"> <li>LO 10 seconds</li> <li>HI ON ⇔ OFF 5 times</li> </ul>
5	A/C compressor (magnet clutch)	ON ⇔ OFF 5 times
6	Cooling fan	MID for 5 seconds → HI for 5 seconds

\*: Outputs duty ratio of 50% for 5 seconds → duty ratio of 100% for 5 seconds on the cooling fan control module.

### Concept of auto active test



- IPDM E/R starts the auto active test with the door switch signals transmitted by BCM via CAN communication. Therefore, the CAN communication line between IPDM E/R and BCM is considered normal if the auto active test starts successfully.
- The auto active test facilitates troubleshooting if any systems controlled by IPDM E/R cannot be operated.

### Diagnosis chart in auto active test

Symptom	Inspection contents	Possible cause
Any of the following components do not operate <ul style="list-style-type: none"> <li>Parking lamp</li> <li>License plate lamp</li> <li>Tail lamp</li> <li>Side marker lamp</li> <li>Front fog lamp</li> <li>Headlamp (HI, LO)</li> <li>Front wiper motor</li> </ul>	Perform auto active test. Does the applicable system operate?	YES BCM signal input circuit
		NO <ul style="list-style-type: none"> <li>Lamp or motor</li> <li>Lamp or motor ground circuit</li> <li>Harness or connector between IPDM E/R and applicable system</li> <li>IPDM E/R</li> </ul>
A/C compressor does not operate	Perform auto active test. Does the magnet clutch operate?	YES <ul style="list-style-type: none"> <li>Combination meter signal input circuit</li> <li>CAN communication signal between Combination meter and ECM</li> <li>CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO <ul style="list-style-type: none"> <li>Magnet clutch</li> <li>Harness or connector between IPDM E/R and magnet clutch</li> <li>IPDM E/R</li> </ul>

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[IPDM E/R]

Symptom	Inspection contents		Possible cause
Oil pressure warning lamp does not operate (only for models with VQ37VHR engine)	Perform auto active test. Does the oil pressure warning lamp blink?	YES	<ul style="list-style-type: none"> <li>• Harness or connector between IPDM E/R and oil pressure switch</li> <li>• Oil pressure switch</li> <li>• IPDM E/R</li> </ul>
		NO	<ul style="list-style-type: none"> <li>• CAN communication signal between IPDM E/R and BCM</li> <li>• CAN communication signal between BCM and Combination meter</li> <li>• Combination meter</li> </ul>
Cooling fan does not operate	Perform auto active test. Does the cooling fan operate?	YES	<ul style="list-style-type: none"> <li>• ECM signal input circuit</li> <li>• CAN communication signal between ECM and IPDM E/R</li> </ul>
		NO	<ul style="list-style-type: none"> <li>• Cooling fan</li> <li>• Harness or connector between cooling fan and cooling fan control module</li> <li>• Cooling fan control module</li> <li>• Harness or connector between IPDM E/R and cooling fan control module</li> <li>• Cooling fan relay</li> <li>• Harness or connector between IPDM E/R and cooling fan relay</li> <li>• IPDM E/R</li> </ul>

## CONSULT Function (IPDM E/R)

INFOID:0000000012352380

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Diagnosis mode	Description
Ecu Identification	Allows confirmation of IPDM E/R part number.
Self Diagnostic Result	Displays the diagnosis results judged by IPDM E/R.
Data Monitor	Displays the real-time input/output data from IPDM E/R input/output data.
Active Test	IPDM E/R can provide a drive signal to electronic components to check their operations.
CAN Diag Support Monitor	The results of transmit/receive diagnosis of CAN communication can be read.

### SELF DIAGNOSTIC RESULT

Refer to [PCS-24, "DTC Index"](#).

### DATA MONITOR

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item [Unit]	MAIN SIGNALS	Description
RAD FAN REQ [%]	×	Displays the value of the cooling fan speed signal received from ECM via CAN communication.
AC COMP REQ [Off/On]	×	Displays the status of the A/C compressor request signal received from ECM via CAN communication.
TAIL&CLR REQ [Off/On]	×	Displays the status of the position light request signal received from BCM via CAN communication.
HL LO REQ [Off/On]	×	Displays the status of the low beam request signal received from BCM via CAN communication.
HL HI REQ [Off/On]	×	Displays the status of the high beam request signal received from BCM via CAN communication.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L

PCS

N  
O  
P

# DIAGNOSIS SYSTEM (IPDM E/R)

## < SYSTEM DESCRIPTION >

[IPDM E/R]

Monitor Item [Unit]	MAIN SIG- NALS	Description
FR FOG REQ [Off/On]	×	Displays the status of the front fog light request signal received from BCM via CAN communication.
FR WIP REQ [Stop/1LOW/Low/Hi]	×	Displays the status of the front wiper request signal received from BCM via CAN communication.
WIP AUTO STOP [STOP P/ACT P]	×	Displays the status of the front wiper stop position signal judged by IPDM E/R.
WIP PROT [Off/BLOCK]	×	Displays the status of the front wiper fail-safe operation judged by IPDM E/R.
IGN RLY1 -REQ [Off/On]		Displays the status of the ignition switch ON signal received from BCM via CAN communication.
IGN RLY [Off/On]	×	Displays the status of the ignition relay judged by IPDM E/R.
PUSH SW [Off/On]		Displays the status of the push-button ignition switch judged by IPDM E/R.
INTER/NP SW [Off/On]		Displays the status of the shift position judged by IPDM E/R.
ST RLY CONT [Off/On]		Displays the status of the starter relay status signal received from BCM via CAN communication.
IHBT RLY -REQ [Off/On]		Displays the status of the starter control relay signal received from BCM via CAN communication.
ST/INHI RLY [Off/ ST /INHI/UNKWN]		Displays the status of the starter relay and starter control relay judged by IPDM E/R.
DETENT SW [Off/On]		Displays the status of the A/T shift selector (detention switch) judged by IPDM E/R.
S/L RLY -REQ [Off/On]		<b>NOTE:</b> This item is indicated, but not monitored.
S/L STATE [LOCK/UNLOCK/UNKWN]		<b>NOTE:</b> This item is indicated, but not monitored.
DTRL REQ [Off/On]		Displays the status of the daytime running light request signal received from BCM via CAN communication. <b>NOTE:</b> This item is monitored only on the vehicle with daytime running light system.
OIL P SW [Open/Close]		Displays the status of the oil pressure switch judged by IPDM E/R.
HOOD SW [Off/On]		Displays the status of the hood switch judged by IPDM E/R.
HL WASHER REQ [Off/On]		<b>NOTE:</b> This item is indicated, but not monitored.
THFT HRN REQ [Off/On]		Displays the status of the theft warning horn request signal received from BCM via CAN communication.
HORN CHIRP [Off/On]		Displays the status of the horn reminder signal received from BCM via CAN communication.
CRNRNG LMP REQ [Off/On]		<b>NOTE:</b> This item is indicated, but not monitored.

## ACTIVE TEST

Test item

Test item	Operation	Description
CORNERING LAMP	Off	<b>NOTE:</b> This item is indicated, but cannot be tested.
	LH	
	RH	

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[IPDM E/R]

Test item	Operation	Description
HORN	On	Operates horn relay for 20 ms.
FRONT WIPER	Off	OFF
	Lo	Operates the front wiper relay.
	Hi	Operates the front wiper relay and front wiper high relay.
MOTOR FAN	1	OFF
	2	Transmits 50% pulse duty signal (PWM signal) to the cooling fan control module.
	3	Transmits 75% pulse duty signal (PWM signal) to the cooling fan control module.
	4	Transmits 100% pulse duty signal (PWM signal) to the cooling fan control module.
HEAD LAMP WASHER	On	<b>NOTE:</b> This item is indicated, but cannot be tested.
EXTERNAL LAMPS	Off	OFF
	TAIL	Operates the tail lamp relay and the daytime running light relay.
	Lo	Operates the headlamp low relay.
	Hi	Operates the headlamp low relay and ON/OFF the headlamp high relay at 1 second intervals.
	Fog	Operates the front fog lamp relay.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

# ECU DIAGNOSIS INFORMATION

## IPDM E/R

### Reference Value

INFOID:0000000012352381

### VALUES ON THE DIAGNOSIS TOOL

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition		Value/Status
RAD FAN REQ	Engine idle speed	Changes depending on engine coolant temperature, air conditioner operation status, vehicle speed, etc.	0 – 100 %
AC COMP REQ	Engine running	A/C switch OFF	Off
		A/C switch ON (compressor is operating)	On
TAIL&CLR REQ	Lighting switch OFF		Off
	• Lighting switch 1ST, 2ND or AUTO (light is illuminated) • Daytime running light system is operated		On
HL LO REQ	Lighting switch OFF		Off
	Lighting switch 2ND or AUTO (light is illuminated)		On
	Daytime running light system is operated		
HL HI REQ	Lighting switch 2ND or AUTO (light is illuminated)	Lighting switch other than HI and PASS	Off
		Lighting switch HI or PASS	On
FR FOG REQ	Lighting switch 2ND or AUTO (light is illuminated)	Front fog lamp switch OFF	Off
		Lighting switch HI or PASS	
		Front fog lamp switch ON	On
FR WIP REQ	Ignition switch ON	Front wiper switch OFF	Stop
		Front wiper switch AUTO	1LOW
		Front wiper switch LO	Low
		Front wiper switch HI	Hi
WIP AUTO STOP	Ignition switch ON	Front wiper stop position	STOP P
		Any position other than front wiper stop position	ACT P
WIP PROT	Ignition switch ON	Front wiper operates normally	Off
		Front wiper stops at fail-safe operation	BLOCK
IGN RLY1 -REQ	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
IGN RLY	Ignition switch OFF or ACC		Off
	Ignition switch ON		On
PUSH SW	Release the push-button ignition switch		Off
	Press the push-button ignition switch		On
INTER/NP SW	Ignition switch ON	Selector lever in any position other than P or N	Off
		Selector lever in P or N position	On
ST RLY CONT	Ignition switch ON		Off
	At engine cranking		On



# IPDM E/R

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Monitor Item	Condition		Value/Status
IHBT RLY -REQ	Ignition switch ON		Off
	At engine cranking		On
ST/INHI RLY	Ignition switch ON		Off
	At engine cranking		INHI → ST
	The status of starter relay or starter control relay cannot be recognized by the battery voltage malfunction, etc. when the starter relay is ON and the starter control relay is OFF		UNKWN
DETENT SW	Ignition switch ON	<ul style="list-style-type: none"><li>Press the selector button with selector lever in P position</li><li>Selector lever in any position other than P</li></ul>	Off
	Release the selector button with selector lever in P position		On
S/L RLY -REQ	<b>NOTE:</b> This item is indicated, but not monitored.		Off
S/L STATE	<b>NOTE:</b> This item is indicated, but not monitored.		UNLOCK
DTRL REQ	Daytime running light system is not operated		Off
	Any of the condition below <ul style="list-style-type: none"><li>Daytime running light system is operated</li><li>Light switch 1ST, 2ND or AUTO (light is illuminated)</li></ul>		On
OIL P SW	Ignition switch OFF or ACC		Open
	Ignition switch ON (engine running)		
	Ignition switch ON (engine stopped)		Close
HOOD SW	Close the hood		Off
	Open the hood		On
HL WASHER REQ	<b>NOTE:</b> This item is indicated, but not monitored.		Off
THFT HRN REQ	Not operation		Off
	<ul style="list-style-type: none"><li>Panic alarm is activated</li><li>Theft warning alarm is activated</li></ul>		On
HORN CHIRP	Not operation		Off
	Door locking with Intelligent Key (horn chirp mode)		On
CRNRNG LMP REQ	<b>NOTE:</b> This item is indicated, but not monitored.		Off

A

B

C

D

E

F

G

H

I

J

K

L


PCS

N

O

P

TERMINAL LAYOUT



PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (W)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
2 (L)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage
4 (W)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)	Battery voltage
5 (P)	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)	0 V
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)	Battery voltage

# IPDM E/R




< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	-	Signal name	Input/ Output			
6 (SB)*1 (R)*2	Ground	ECM relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>		Battery voltage
7 (R)*1 (Y)*2	Ground	Throttle control motor relay power supply	Output	Ignition switch OFF (More than a few seconds after turning ignition switch OFF)		0 V
				<ul style="list-style-type: none"> <li>Ignition switch ON</li> <li>Ignition switch OFF (For a few seconds after turning ignition switch OFF)</li> </ul>		Battery voltage
8 (L/Y)*1 (P)*2	Ground	A/C relay power supply	Output	Engine running	A/C switch OFF	0 V
					A/C switch ON (A/C compressor is operating)	Battery voltage
10 (V)	Ground	ECM power supply	Output	Ignition switch OFF		Battery voltage
11 (B)	Ground	Ground	—	Ignition switch ON		0 V
12 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC		0 V
				Ignition switch ON		Battery voltage
13 (W)*1 (GR)*2	Ground	Fuel pump relay power supply	Output	Approximately 1 second or more after turning the ignition switch ON		0 V
				<ul style="list-style-type: none"> <li>Approximately 1 second after turning the ignition switch ON</li> <li>Engine running</li> </ul>		Battery voltage
16 (V)	Ground	Front wiper stop position	Input	Ignition switch ON	Front wiper stop position	0 V
					Any position other than front wiper stop position	12 V
18 (Y)	Ground	Ignition relay monitor	Input	Ignition switch OFF or ACC		Battery voltage
				Ignition switch ON		0 V

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	—	Signal name	Input/ Output			
22 (BR)	Ground	Power generation command signal	Output	Ignition switch ON	 JPMIA0001GB 6.3 V	
				40% is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"	 JPMIA0002GB 3.8 V	
				80% is set on "ACTIVE TEST", "ALTERNATOR DUTY" of "ENGINE"	 JPMIA0003GB 1.4 V	
23 (P)	Ground	Daytime running light relay control	Output	<ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Tail lamp</li> </ul> Turned OFF	Battery voltage	
				Turned ON	0 V	
24 (O)	Ground	Hood switch	Input	Close the hood	12 V	
				Open the hood	0 V	
25 (LG)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	Battery voltage	
30 (BR)	Ground	Push-button ignition switch	Input	Press the push-button ignition switch	0 V	
				Release the push-button ignition switch	12 V	
31 (BR)*1 (W)*2	Ground	Starter relay control	Input	Ignition switch ON	0 V	
				Selector lever P or N	12 V	
36 (GR)	Ground	Battery power supply	Input	Ignition switch OFF	Battery voltage	
39 (P)	—	CAN-L	Input/ Output	—	—	
40 (L)	—	CAN-H	Input/ Output	—	—	
41 (B)	Ground	Ground	—	Ignition switch ON	0 V	
42 (V)*1 (Y)*2	Ground	Cooling fan relay 1 control	Input	Ignition switch OFF or ACC	0 V	
				Ignition switch ON	0.7 V	

# IPDM E/R

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)	
+	-	Signal name	Input/ Output				
43 (SB)	Ground	A/T shift selector (Detention switch)	Input	Ignition switch ON	• Press the selector but- ton (selector lever P) • Selector lever in any po- sition other than P	12 V	A
					Release the selector but- ton (selector lever P)	0 V	B
44 (GR)*1 (LG)*2	Ground	Horn relay control	Input	The horn is deactivated		Battery voltage	C
				The horn is activated		0 V	D
45 (G)	Ground	Vehicle security horn relay control	Input	The horn is deactivated		Battery voltage	E
				The horn is activated		0 V	F
46 (BR)	Ground	Starter relay control	Input	Ignition switch ON	Selector lever in any posi- tion other than P or N	0 V	G
					Selector lever P or N	12 V	H
48 (P)	Ground	Daytime running light relay power supply	Output	Ignition switch OFF		Battery voltage	I
51 (O)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC		0 V	J
				Ignition switch ON		Battery voltage	K
52 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC		0 V	L
				Ignition switch ON		Battery voltage	M
53 (L)	Ground	Front wiper HI (ground)	Output	Ignition switch ON	Front wiper switch OFF or HI	0 V	N
54 (P)	Ground	Front wiper LO	Output	Ignition switch ON	Front wiper switch OFF	0 V	O
					Front wiper switch LO	Battery voltage	P
55 (R)	Ground	Illumination	Output	Lighting switch OFF		0 V	
				Lighting switch 1ST		Battery voltage	
56 (GR)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC		0 V	
				Ignition switch ON		Battery voltage	
57 (V)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC		0 V	
				Ignition switch ON		Battery voltage	
58 (BR)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC		0 V	
				Ignition switch ON		Battery voltage	
70 (LG)	Ground	ECM relay control	Output	Ignition switch OFF (More than a few seconds after turning igni- tion switch OFF)		Battery voltage	
				• Ignition switch ON • Ignition switch OFF (For a few seconds after turning ignition switch OFF)		0 – 1.5 V	
71 (O)	Ground	Throttle control motor relay control	Output	Ignition switch ON → OFF		0 – 1.0 V ↓ Battery voltage ↓ 0 V	
				Ignition switch ON		0 – 1.0 V	
73 (G)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC		0 V	
				Ignition switch ON		Battery voltage	

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

# IPDM E/R

< ECU DIAGNOSIS INFORMATION >

[IPDM E/R]

Terminal No. (Wire color)		Description		Condition		Value (Approx.)
+	–	Signal name	Input/ Output			
74 (R)	Ground	Ignition relay power supply	Output	Ignition switch OFF or ACC		0 V
				Ignition switch ON		Battery voltage
75 (Y)	Ground	Oil pressure switch	Input	Ignition switch ON	Engine stopped	0 V
					Engine running	12 V
77 (B)	Ground	Fuel pump relay control	Output	• Approximately 1 second after turning the ignition switch ON • Engine running		0 – 1.0 V
				Approximately 1 second or more after turning the ignition switch ON		Battery voltage
80 (W)	Ground	Starter motor	Output	At engine cranking		Battery voltage
83 (R)	Ground	Headlamp LO (RH)	Output	Lighting switch OFF		0 V
				Lighting switch 2ND or AUTO (light is illuminated)		Battery voltage
				Daytime running light operated		
84 (W)	Ground	Headlamp LO (LH)	Output	Lighting switch OFF		0 V
				Lighting switch 2ND or AUTO (light is illuminated)		Battery voltage
				Daytime running light operated		
86 (G)	Ground	Front fog lamp (RH)	Output	Lighting switch 2ND or AUTO (light is illuminated)	Front fog lamp switch ON	Battery voltage
					Lighting switch HI or PASS	0 V
					Front fog lamp switch OFF	
87 (L)	Ground	Front fog lamp (LH)	Output	Lighting switch 2ND or AUTO (light is illuminated)	Front fog lamp switch ON	Battery voltage
					Lighting switch HI or PASS	0 V
					Front fog lamp switch OFF	
88 (O)	Ground	Front wiper motor power supply	Output	Ignition switch ON		Battery voltage
89 (BR)	Ground	Headlamp HI (RH)	Output	Lighting switch 2ND or AUTO (light is illuminated)	Lighting switch HI or PASS	Battery voltage
					Lighting switch other than HI and PASS	0 V
90 (P)	Ground	Headlamp HI (LH)	Output	Lighting switch 2ND or AUTO (light is illuminated)	Lighting switch HI or PASS	Battery voltage
					Lighting switch other than HI and PASS	0 V
94 (P)	Ground	Front combination lamp	Output	Lighting switch OFF		0 V
				Lighting switch 1ST		Battery voltage
96 (R)	Ground	Wiper reverse relay	Input	Ignition switch OFF or ACC		0 V
				Ignition switch ON		Battery voltage
				Front wiper operates at LO		Battery voltage
				Front wiper operates at HI		0 V
97 (V)	Ground	Cooling fan control	Output	Engine idling		0 – 5 V
102 (R) <sup>*1</sup> (R/L) <sup>*2</sup>	Ground	Rear combination lamp RH and license plate lamp	Output	Lighting switch OFF		0 V
				Lighting switch 1ST		Battery voltage

\*1: For models with VK56VD engine

\*2: For models with VQ37VHR engine

## Fail-safe

INFOID:0000000012352382

### CAN COMMUNICATION CONTROL

When CAN communication with ECM and BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If No CAN Communication Is Available With ECM

Control part	Fail-safe operation
Cooling fan	<ul style="list-style-type: none"> <li>Outputs the pulse duty signal (PWM signal) 100% when the ignition switch is turned ON</li> <li>Outputs the pulse duty signal (PWM signal) 0% when the ignition switch is turned OFF</li> </ul>
A/C compressor	A/C relay OFF
Alternator	Outputs the power generation command signal (PWM signal) 0%

If No CAN Communication Is Available With BCM

Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>Turns ON the headlamp low relay when the ignition switch is turned ON</li> <li>Turns OFF the headlamp low relay when the ignition switch is turned OFF</li> <li>Headlamp high relay OFF</li> </ul>
<ul style="list-style-type: none"> <li>Parking lamp</li> <li>License plate lamp</li> <li>Illumination</li> <li>Tail lamp</li> <li>Side marker lamp</li> </ul>	<ul style="list-style-type: none"> <li>Turns ON the tail lamp relay and daytime running light relay when the ignition switch is turned ON</li> <li>Turns OFF the tail lamp relay and daytime running light relay when the ignition switch is turned OFF</li> </ul>
Front wiper motor	<ul style="list-style-type: none"> <li>The status just before activation of fail-safe control is maintained until the ignition switch is turned OFF while the front wiper is operating at LO or HI speed.</li> <li>The wiper is operated at LO speed until the ignition switch is turned OFF if the fail-safe control is activated while the front wiper is set in the AUTO mode and the front wiper motor is operating.</li> <li>Returns automatically wiper to stop position when ignition switch is turned ON if fail-safe control is activated while front wiper motor is operated and wiper stop in the other than stop position.</li> </ul>
Front fog lamp	Front fog lamp relay OFF
Horn	Horn OFF
Ignition relay	The status just before activation of fail-safe is maintained.
Starter motor	Starter control relay OFF

### IGNITION RELAY MALFUNCTION DETECTION FUNCTION

- IPDM E/R monitors the voltage at the contact circuit and excitation coil circuit of the ignition relay inside it.
- IPDM E/R judges the ignition relay error if the voltage differs between the contact circuit and the excitation coil circuit.
- If the ignition relay cannot turn OFF due to contact seizure, it activates the tail lamp relay and daytime running light relay for 10 minutes to alert the user to the ignition relay malfunction when the ignition switch is turned OFF.

Voltage judgment		IPDM E/R judgment	Operation
Ignition relay contact side	Ignition relay excitation coil side		
ON	ON	Ignition relay ON normal	—
OFF	OFF	Ignition relay OFF normal	—

ON	OFF	Ignition relay ON stuck	<ul style="list-style-type: none"> <li>• Detects DTC “B2098: IGN RELAY ON CIRC”</li> <li>• Turns ON the tail lamp relay and daytime running light relay for 10 minutes</li> </ul>
OFF	ON	Ignition relay OFF stuck	Detects DTC “B2099: IGN RELAY OFF CIRC”

#### FRONT WIPER PROTECTION FUNCTION

IPDM E/R detects front wiper stop position by a front wiper stop position signal.

When a front wiper stop position signal is in the conditions listed below, IPDM E/R stops power supply to wiper after repeating a front wiper 10 seconds activation and 20 seconds stop five times.

Ignition switch	Front wiper switch	Front wiper stop position signal
ON	OFF	The front wiper stop position signal (stop position) cannot be input for 10 seconds.
	ON	The front wiper stop position signal does not change for 10 seconds.

#### NOTE:

This operation status can be confirmed on the IPDM E/R “Data Monitor” that displays “BLOCK” for the item “WIP PROT” while the wiper is stopped.

#### STARTER MOTOR PROTECTION FUNCTION

IPDM E/R turns OFF the starter control relay to protect the starter motor when the starter control relay remains active for 90 seconds.

#### DTC Index

INFOID:0000000012352383

#### NOTE:

- The details of time display are as follows.
  - CRNT: A malfunction is detected now.
  - PAST: A malfunction was detected in the past.
- IGN counter is displayed on FFD (Freeze Frame Data).
  - The number is 0 when is detected now.
  - The number increases like 1 → 2 ... 38 → 39 after returning to the normal condition whenever IGN OFF → ON.
  - The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.

×: Applicable

CONSULT display	Fail-safe	Reference
No DTC is detected. further testing may be required.	—	—
U1000: CAN COMM CIRCUIT	×	<a href="#">PCS-28</a>
B2098: IGN RELAY ON CIRC	×	<a href="#">PCS-29</a>
B2099: IGN RELAY OFF CIRC	—	<a href="#">PCS-31</a>
B210B: STR CONT RLY ON CIRC	—	<a href="#">SEC-98</a>
B210C: STR CONT RLY OFF CIRC	—	<a href="#">SEC-99</a>
B210D: STARTER RLY ON CIRC	—	<a href="#">SEC-100</a>
B210E: STARTER RLY OFF CIRC	—	<a href="#">SEC-101</a>
B210F: INTRLCK/PNP SW ON	—	<a href="#">SEC-103</a>
B2110: INTRLCK/PNP SW OFF	—	<a href="#">SEC-105</a>




## WIRING DIAGRAM

IPDM E/R


Wiring Diagram

INFOID:0000000012352384



JRMW16293GB


2015/09/02



JRMW16294GB

## IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)

Connector No.	Color Of Wire	Signal Name [Specification]
E4		
1	W	F/L MAIN
2	L	F/L USM




Terminal No.	Color Of Wire	Signal Name [Specification]
24	O	HDD SW
25	LG	SUB ECU
26	BR	RUGA START SW
27	GR	RP SW (With VQ37 engine)
28	W	RP SW (With VQ37 engine)
29	W	F/L IGN SW

Connector No.	Color Of Wire	Signal Name [Specification]
E6		
1	W	F/L MAIN
2	L	F/L USM




Terminal No.	Color Of Wire	Signal Name [Specification]
E5		
1	W	F/L MAIN
2	L	F/L USM




Terminal No.	Color Of Wire	Signal Name [Specification]
39	P	CAN-L
40	L	CAN-H
41	B	S-GND
42	V	MOTOR_FAN_RLY_CONT (With VK56 engine)
43	SB	DETECT SW
44	GR	HORN_RL (With VK55 engine)
45	LG	HORN_RL (With VQ37 engine)
46	BR	START_CONT

Connector No.	Color Of Wire	Signal Name [Specification]
E7		
1	W	F/L MAIN
2	L	F/L USM



Terminal No.	Color Of Wire	Signal Name [Specification]
48	P	DTL ECU
49	G	WIPER_LO
50	L	WIPER_HI
51	P	FR WIPER_LO
52	R	FR WIPER_HI
53	GR	TAIL/ILLUM
54	GR	CO2 SENS #1
55	GR	CO2 SENS #2
56	BR	AT ECU
57	LG	SSOFF
58	O	MOTRLY
59	G	START_IG/E/R
60	R	START_IG/E/R
61	Y	OIL_PRESSURE_SW
62	B	FR
63	W	STARTER MOTOR

Connector No.	Color Of Wire	Signal Name [Specification]
E8		
1	W	F/L MAIN
2	L	F/L USM



Terminal No.	Color Of Wire	Signal Name [Specification]
83	R	HEAD_LAMP_LO_RH
84	W	HEAD_LAMP_LO_LH
85	G	FR_FOG_LAMP_RH
86	L	FR_FOG_LAMP_LH
87	O	FR WIPER_B
88	BR	HEAD_LAMP_HI_RH
89	P	HEAD_LAMP_HI_LH

Connector No.	Color Of Wire	Signal Name [Specification]
E9		
1	W	F/L MAIN
2	L	F/L USM



Terminal No.	Color Of Wire	Signal Name [Specification]
94	P	CLEARANCE_RH
95	R	WIPER_REV_RV
96	V	MOTOR_FAN_PWM
97	R	CLEARANCE_LH (With VQ37 engine)
98	R/L	CLEARANCE_LH (With VQ37 engine)

JRMW16295GB

## DTC/CIRCUIT DIAGNOSIS

### U1000 CAN COMM CIRCUIT

#### Description

INFOID:0000000012352385

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-37, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

#### DTC Logic

INFOID:0000000012352386

#### DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition	Possible cause
U1000	CAN COMM CIRCUIT	When IPDM E/R cannot communicate CAN communication signal continuously for 2 seconds or more	CAN communication system

#### Diagnosis Procedure

INFOID:0000000012352387

#### 1.PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait 2 seconds or more.
2. Check "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

Is DTC "U1000" displayed?

- YES >> Refer to [LAN-27, "Trouble Diagnosis Flow Chart"](#).  
 NO >> Refer to [GI-45, "Intermittent Incident"](#).

# B2098 IGNITION RELAY ON STUCK

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

## B2098 IGNITION RELAY ON STUCK

### Description

INFOID:0000000012352388

- IPDM E/R operates the ignition relay when it receives an ignition switch ON signal from BCM via CAN communication.
- Turn the ignition relay OFF by pressing the push-button ignition switch once when the vehicle speed is 4 km/h (2.5 MPH) or less.
- Turn the ignition relay OFF with the following operation when the vehicle speed is more than 4 km/h (2.5 MPH) or when an abnormal condition occurs in CAN communication from the unified meter and A/C amp.(Emergency OFF)
  - Press and hold the push-button ignition switch for 2 seconds or more.
  - Press the push-button ignition switch 3 times within 1.5 seconds.

#### NOTE:

The ignition relay does not turn ON for 3 seconds after emergency OFF even if the push-button ignition switch is pressed.

### DTC Logic

INFOID:0000000012352389

### DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition	Possible causes
B2098	IGN RELAY ON CIRC	The ignition relay ON is detected for 1 second at ignition switch OFF (CPU monitors the status at the contact and excitation coil circuits of the ignition relay inside it)	Ignition relay malfunction

### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn ignition switch OFF and wait 1 second or more.
3. Check DTC in "Self Diagnostic Result" mode of "IPDM E/R" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [PCS-29. "Diagnosis Procedure"](#).  
NO >> INSPECTION END.

### Diagnosis Procedure

INFOID:0000000012352390

### 1.CHECK SELF DIAGNOSTIC RESULT

Check DTC using CONSULT.

#### What is the display history of DTC "B2098"?

- "CRNT">> GO TO 2.  
"PAST">> GO TO 5.

### 2.CHECK IGNITION RELAY CONTROL CIRCUIT VOLTAGE 1

1. Turn ignition switch ON
2. Check voltage between IPDM E/R harness connector and ground.

(+)		(-)	Voltage (Approx.)
IPDM E/R			
Connector	Terminal		
E5	18	Ground	0 V

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 3.

### 3.CHECK IGNITION RELAY CONTROL CIRCUIT VOLTAGE 2

1. Disconnect IPDM E/R connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

## B2098 IGNITION RELAY ON STUCK

### < DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

2. Turn ignition switch ON
3. Check voltage between IPDM E/R harness connector and ground.

(+)		(-)	Voltage (Approx.)
IPDM E/R			
Connector	Terminal		
E5	18	Ground	0 V

Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).  
NO >> Check the harness of the ignition relay control circuit for a short to power.

### 4.CHECK IGNITION RELAY CONTROL CIRCUIT

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	18		Not existed

Is the inspection result normal?

- YES >> Perform the diagnosis procedure for DTC B26F2. Refer to [PCS-73, "DTC Logic"](#).  
NO >> Repair or replace harness.

### 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

# B2099 IGNITION RELAY OFF STUCK

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

## B2099 IGNITION RELAY OFF STUCK

### Description

INFOID:0000000012352391

- IPDM E/R operates the ignition relay when it receives an ignition switch ON signal from BCM via CAN communication.
- Turn the ignition relay OFF by pressing the push-button ignition switch once when the vehicle speed is 4 km/h (2.5 MPH) or less.
- Turn the ignition relay OFF with the following operation when the vehicle speed is more than 4 km/h (2.5 MPH) or when an abnormal condition occurs in CAN communication from the unified meter and A/C amp.(Emergency OFF)
  - Press and hold the push-button ignition switch for 2 seconds or more.
  - Press the push-button ignition switch 3 times within 1.5 seconds.

#### NOTE:

The ignition relay does not turn ON for 3 seconds after emergency OFF even if the push-button ignition switch is pressed.

### DTC Logic

INFOID:0000000012352392

#### DTC DETECTION LOGIC

DTC	CONSULT display description	DTC Detection Condition	Possible causes
B2099	IGN RELAY OFF CIRC	The ignition relay OFF is detected for 1 second at ignition switch ON (CPU monitors the status at the contact and excitation coil circuits of the ignition relay inside it)	Ignition relay malfunction

#### NOTE:

When IPDM E/R power supply voltage is low (Approx. 7 - 8 V for about 1 second), the "DTC: B2099" may be detected.

### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn ignition switch OFF and wait 1 second or more.
3. Check DTC in "Self Diagnostic Result" mode of "IPDM E/R" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [PCS-31, "Diagnosis Procedure"](#).  
NO >> INSPECTION END.

### Diagnosis Procedure

INFOID:0000000012352393

### 1.CHECK FUSE

Check that all of the fuses installed on the downstream of the contact point side circuit of the ignition relay in IPDM E/R are not blown.

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Replace the blown fuse after replacing the affected circuit if a fuse is blown.

### 2.CHECK IGNITION RELAY CONTROL CIRCUIT VOLTAGE

1. Turn ignition switch ON
2. Check voltage between IPDM E/R harness connector and ground.

(+)		(-)	Voltage (Approx)
IPDM E/R			
Connector	Terminal		
E5	18	Ground	0 V

#### Is the inspection result normal?

- YES >> Replace IPDM E/R. Refer to [PCS-34, "Removal and Installation"](#).  
NO >> GO TO 3.

## B2099 IGNITION RELAY OFF STUCK

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

---

### 3.CHECK BATTERY VOLTAGE

---

Check battery voltage.

Which is the measurement result?

More than 12.4 V>>GO TO 4.

Less than 12.4 V>>Perform battery inspection. Refer to [PG-157. "How to Handle Battery"](#).

---

### 4.CHECK INTERMITTENT INCIDENT

---

Refer to [GI-45. "Intermittent Incident"](#).

>> INSPECTION END



# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[IPDM E/R]

## POWER SUPPLY AND GROUND CIRCUIT

### Diagnosis Procedure

INFOID:0000000012352394

#### 1.CHECK FUSES AND FUSIBLE LINK

Check that the following IPDM E/R fuses or fusible links are not blown.

Signal name	Fuses and fusible link No.
Battery power supply	D (80 A)
	F (60 A)
	H (30 A)
	50 (15 A)
	51 (15 A)

Is the fuse blown (open)?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

#### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check voltage between IPDM E/R harness connector and the ground.

(+) IPDM E/R		(-)	Voltage (Approx.)
Connector	Terminal		
E4	1	Ground	Battery voltage
	2		
E5	36		

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair the harness or connector.

#### 3.CHECK GROUND CIRCUIT

Check continuity between IPDM E/R harness connectors and the ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	11		Existed
E6	41		

Does continuity exist?

YES >> INSPECTION END


NO >> Repair the harness or connector.

# REMOVAL AND INSTALLATION

## IPDM E/R

### Exploded View

INFOID:000000012352395



1. IPDM E/R cover A

2. IPDM E/R

3. IPDM E/R cover B

## Removal and Installation


INFOID:000000012352396

### CAUTION:


To prevent damage to the parts, IPDM E/R integrated relays cannot be removed.

### REMOVAL

1. Disconnect the battery cable from the negative terminal.
2. Remove the cowl top cover (RH). Refer to [EXT-23, "Removal and Installation"](#).
3. Pull up the IPDM E/R assembly while pressing the pawls (A) on the back of the IPDM E/R cover B (1).



4. Remove the IPDM E/R cover A while pressing the pawls (A) at the lower end of the IPDM E/R cover A (1).
5. Disconnect the harness connector and remove the IPDM E/R (2).



## INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000012352397

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precautions for Removing Battery Terminal

INFOID:0000000012352398

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

#### **NOTE:**

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


#### **NOTE:**

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

#### **NOTE:**

The removal of 12V battery may cause a DTC detection error.




SEF289H

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:0000000012352399



- |  |   |  |
|--|---|--|
| 1. Push-button ignition switch   | 2. IPDM E/R<br>Refer to <a href="#">PCS-5, "IPDM E/R : Component Parts Location"</a>      | 3. Stop lamp switch<br>Refer to <a href="#">BRC-10, "Component Parts Location"</a> |
| 4. BCM<br>Refer to <a href="#">BCS-5, "BODY CONTROL SYSTEM : Component Parts Location"</a> | 5. TCM<br>Refer to <a href="#">TM-11, "A/T CONTROL SYSTEM : Component Parts Location"</a> |  |

#### Component Description

INFOID:0000000012352400

BCM	Reference
BCM	<a href="#">PCS-37</a>
Ignition relay	<a href="#">PCS-37</a>
Accessory relay	<a href="#">PCS-38</a>
Blower relay	<a href="#">PCS-38</a>
Push-button ignition switch	<a href="#">PCS-38</a>
TCM	<a href="#">SEC-8</a>
Stop lamp switch	<a href="#">SEC-9</a>

#### BCM

INFOID:0000000012352401

BCM controls the various electrical components and simultaneously supplies power according to the power supply position.  
BCM checks the power supply position internally.

#### Ignition Relay

INFOID:0000000012352402

BCM turns ON the following relays to supply ignition power supply or ignition switch ON signal to each ECU when the ignition switch is turned ON.

- Ignition relay (fuse block)
- Ignition relay (IPDM E/R)
- Blower relay

BCM compares following status comparing.

- Ignition relay (fuse block) control signal, and power supply position judged by BCM

## COMPONENT PARTS

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

- Ignition relay (IPDM E/R) control request, and Ignition relay (IPDM E/R) status

### Accessory Relay

INFOID:0000000012352403

BCM turns ON the accessory relays to supply accessory power supply or ignition switch ACC signal to each ECU when the ignition switch is turned ACC or ON.

BCM compares status of accessory relay control signal, and power supply position judged by BCM.

### Blower Relay

INFOID:0000000012352404

BCM turns ON the following relays to supply ignition power supply or ignition switch ON signal to each ECU when the ignition switch is turned ON.

- Ignition relay (fuse block)
- Ignition relay (IPDM E/R)
- Blower relay

BCM compares status of blower relay control signal, and power supply position judged by BCM.

### Push-Button Ignition Switch

INFOID:0000000012352405


BCM transmits the change in the power supply position with the push-button ignition switch to IPDM E/R via CAN communication line. IPDM E/R transmits the power supply position status via CAN communication line to BCM.

## SYSTEM

## POWER DISTRIBUTION SYSTEM

### POWER DISTRIBUTION SYSTEM : System Diagram

INFOID:0000000012352406



### POWER DISTRIBUTION SYSTEM : System Description

INFOID:0000000012352407

#### SYSTEM DESCRIPTION

- PDS (POWER DISTRIBUTION SYSTEM) is the system that BCM controls with the operation of the push-button ignition switch and performs the power distribution to each power circuit. This system is used instead of the mechanical power supply changing mechanism with the operation of the conventional key cylinder.
- The push-button ignition switch can be operated when Intelligent Key is in the following condition.
  - Intelligent Key is in the detection area of the inside key antenna.
  - Intelligent Key backside is contacted to push-button ignition switch.
- The push-button ignition switch operation is input to BCM as a signal. BCM changes the power supply position according to the status and operates the following relays to supply power to each power circuit.
  - Ignition relay (IPDM E/R)
  - Ignition relay (fuse block)
  - ACC relay
  - Blower fan relay
- The power supply position changes due to the conditions of push-button ignition switch operation, brake pedal, clutch pedal, selector lever and vehicle speed.

#### NOTE:

- The power supply position can be confirmed with the lighting of the indicators near the push-button ignition switch.
- For models without steering lock unit, power supply position changes from "OFF" to "LOCK" when steering lock conditions are satisfied.

#### IGNITION BATTERY SAVER SYSTEM

##### Ignition Position [ON]

When all the following conditions are met for 10 minutes, the battery saver system will cut off the power supply (ignition switch position ON → OFF) to prevent battery discharge.

##### Ignition Position [ACC]

When all the following conditions are met for 30 minutes, the battery saver system will cut off the power supply (ignition switch position ACC → OFF) to prevent battery discharge.

- Ignition switch is in the ACC position
- Turn signal lamp is not in operation
- Selector lever is in the P position

##### Reset Condition of Ignition Battery Saver System

If any of the following conditions are met the battery saver system is released.

# SYSTEM

## < SYSTEM DESCRIPTION >

## [POWER DISTRIBUTION SYSTEM]

- Ignition switch is not in the ACC/ON position.
- Turn signal lamp is operation.
- Selector lever is not in the P position.

### NOTE:

The ignition battery saver system can be temporarily disabled, without using CONSULT, to prevent it from functioning when performing trouble diagnosis. Refer to [PCS-60, "Work Procedure"](#).

## POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION

The power supply position changing operation can be performed with the following operations.

### NOTE:

- When an Intelligent Key is within the detection area of inside key antenna and when Intelligent Key backside is contacted to push-button ignition switch, it is equivalent to the operations below.
- When starting the engine, the BCM monitors under the engine start conditions,
  - Brake pedal operating condition
  - Selector lever position
  - Vehicle speed

Vehicle speed: less than 4 km/h (2.5 MPH)

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever position	Brake pedal operation condition	
LOCK → ACC	—	Not depressed	1
LOCK → ACC → ON	—	Not depressed	2
LOCK → ACC → ON → OFF	—	Not depressed	3
LOCK → START ACC → START ON → START	P or N position	Depressed	1
Engine is running → OFF	—	—	1

Vehicle speed: 4 km/h (2.5 MPH) or more

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever position	Brake pedal operation condition	
Engine is running → ACC	—	—	Emergency stop operation
Engine stall return operation while driving	N position	Not depressed	1

Emergency stop operation

- Press and hold the push-button ignition switch for 2 seconds or more.
- Press the push-button ignition switch 3 times or more within 1.5 seconds.

## Fail-safe

INFOID:0000000012352408

## FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

Display contents of CONSULT	Fail-safe	Cancellation
B2192: ID DISCORD BCM-ECM	Inhibit engine cranking	Erase DTC
B2193: CHAIN OF BCM-ECM	Inhibit engine cranking	Erase DTC
B2195: ANTI-SCANNING	Inhibit engine cranking	Ignition switch ON → OFF
B2196: DONGLE NG	Inhibit engine cranking	Erase DTC
B2198: NATS ANTENNA AMP	Inhibit engine cranking	Erase DTC



# SYSTEM

## < SYSTEM DESCRIPTION >

## [POWER DISTRIBUTION SYSTEM]

Display contents of CONSULT	Fail-safe	Cancellation
B2608: STARTER RELAY	Inhibit engine cranking	500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> <li>• Starter motor relay control signal</li> <li>• Starter relay status signal (CAN)</li> </ul>
B260F: ENG STATE SIG LOST	Inhibit engine cranking	When any of the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Power position changes to ACC</li> <li>• Receives engine status signal (CAN)</li> </ul>
B2619: BCM	Inhibit engine cranking	1 second after the steering lock unit power supply output control inside BCM becomes normal
B26F1: IGN RELAY OFF	Inhibit engine cranking	When the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch ON signal (CAN: Transmitted from BCM): ON</li> <li>• Ignition switch ON signal (CAN: Transmitted from IPDM E/R): ON</li> </ul>
B26F2: IGN RELAY ON	Inhibit engine cranking	When the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Ignition switch ON signal (CAN: Transmitted from BCM): OFF</li> <li>• Ignition switch ON signal (CAN: Transmitted from IPDM E/R): OFF</li> </ul>
B26F3: START CONT RLY ON	Inhibit engine cranking	When the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Starter control relay signal (CAN: Transmitted from BCM): OFF</li> <li>• Starter control relay signal (CAN: Transmitted from IPDM E/R): OFF</li> </ul>
B26F4: START CONT RLY OFF	Inhibit engine cranking	When the following conditions are fulfilled <ul style="list-style-type: none"> <li>• Starter control relay signal (CAN: Transmitted from BCM): ON</li> <li>• Starter control relay signal (CAN: Transmitted from IPDM E/R): ON</li> </ul>
B26F7: BCM	Inhibit engine cranking by Intelligent Key system	When room antenna and luggage room antenna functions normally

### FAIL-SAFE CONTROL BY RAIN SENSOR MALFUNCTION

BCM detects the light and rain sensor serial link error and the rain sensor malfunction.

BCM controls the following fail-safe when rain sensor has a malfunction.

- Front wiper switch AUTO and sensing rain drop: The condition just before the activation of fail-safe is maintained until the front wiper switch is turned OFF.
- Front wiper switch AUTO and not sensing rain drop: Front wiper is LO operation until the front wiper switch is turned off.

### FAIL-SAFE CONTROL OF COMBINATION SWITCH READING FUNCTION CAUSED BY LOW POWER SUPPLY VOLTAGE

If voltage of battery power supply lower, BCM maintains combination switch reading to the status when input voltage is less than approximately 9 V.

#### NOTE:

When voltage of battery power supply is approximately 9 V or more, combination switch reading function returns to normal operation.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

### COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000012999109

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Diagnosis mode	Function Description
Work Support	Changes the setting for each system function.
Self Diagnostic Result	Displays the diagnosis results judged by BCM.
CAN Diag Support Monitor	Monitors the reception status of CAN communication viewed from BCM.
Data Monitor	The BCM input/output signals are displayed.
Active Test	The signals used to activate each device are forcibly supplied from BCM.
Ecu Identification	The BCM part number is displayed.
Configuration	<ul style="list-style-type: none"> <li>Read and save the vehicle specification.</li> <li>Write the vehicle specification when replacing BCM.</li> </ul>

### SYSTEM APPLICATION

BCM can perform the following functions for each system.

#### NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

System	Sub system selection item	Diagnosis mode		
		Work Support	Data Monitor	Active Test
Door lock	DOOR LOCK	×	×	×
Rear window defogger	REAR DEFOGGER		×	×
Warning chime	BUZZER		×	×
Interior room lamp timer	INT LAMP	×	×	×
Exterior lamp	HEAD LAMP	×	×	×
Wiper and washer	WIPER	×	×	×
Turn signal and hazard warning lamps	FLASHER	×	×	×
—	AIR CONDITONER*		×	×
<ul style="list-style-type: none"> <li>Intelligent Key system</li> <li>Engine start system</li> </ul>	INTELLIGENT KEY	×	×	×
Combination switch	COMB SW		×	
Body control system	BCM	×		
IVIS - NATS	IMMU	×	×	×
Interior room lamp battery saver	BATTERY SAVER	×	×	×
Trunk lid open	TRUNK		×	
Vehicle security system	THEFT ALM	×	×	×
RAP system	RETAINED PWR		×	
Signal buffer system	SIGNAL BUFFER		×	×
—	AIR PRESSURE MONITOR*	×	×	×

\*: This item is not used.

### FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

CONSULT screen item	Indication/Unit	Description
Vehicle Speed	km/h	Vehicle speed of the moment a particular DTC is detected
Odo/Trip Meter	km	Total mileage (Odometer value) of the moment a particular DTC is detected
Vehicle Condition	SLEEP>LOCK	While turning BCM status from low power consumption mode to normal mode (Power supply position is "LOCK"*)
	SLEEP>OFF	While turning BCM status from low power consumption mode to normal mode (Power supply position is "OFF".)
	LOCK>ACC	While turning power supply position from "LOCK" *to "ACC"
	ACC>ON	While turning power supply position from "ACC" to "IGN"
	RUN>ACC	While turning power supply position from "RUN" to "ACC" (Vehicle is stopping and selector lever is except P position.)
	CRANK>RUN	While turning power supply position from "CRANKING" to "RUN" (From cranking up the engine to run it)
	RUN>URGENT	While turning power supply position from "RUN" to "ACC" (Emergency stop operation)
	ACC>OFF	While turning power supply position from "ACC" to "OFF"
	OFF>LOCK	While turning power supply position from "OFF" to "LOCK"*
	OFF>ACC	While turning power supply position from "OFF" to "ACC"
	ON>CRANK	While turning power supply position from "IGN" to "CRANKING"
	OFF>SLEEP	While turning BCM status from normal mode (Power supply position is "OFF".) to low power consumption mode
	LOCK>SLEEP	While turning BCM status from normal mode (Power supply position is "LOCK"*. ) to low power consumption mode
	LOCK	Power supply position is "LOCK" (Ignition switch OFF with steering is locked.)*
	OFF	Power supply position is "OFF" (Ignition switch OFF with steering is unlocked.)
	ACC	Power supply position is "ACC" (Ignition switch ACC)
	ON	Power supply position is "IGN" (Ignition switch ON with engine stopped)
	ENGINE RUN	Power supply position is "RUN" (Ignition switch ON with engine running)
	CRANKING	Power supply position is "CRANKING" (At engine cranking)
IGN Counter	0 - 39	The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> <li>• The number is 0 when a malfunction is detected now.</li> <li>• The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON.</li> <li>• The number is fixed to 39 until the self-diagnosis results are erased if it is over 39.</li> </ul>

## NOTE:

\*: Power supply position shifts to "LOCK" from "OFF", when ignition switch is in the OFF position, selector lever is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "LOCK".

## INTELLIGENT KEY

## INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:0000000012999110

## WORK SUPPORT

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

## [POWER DISTRIBUTION SYSTEM]

Monitor item	Description
INSIDE ANT DIAGNOSIS	This function allows inside key antenna self-diagnosis
LOCK/UNLOCK BY I-KEY	Door lock/unlock function by door request switch mode can be changed to operation in this mode <ul style="list-style-type: none"><li>• On: Operate</li><li>• Off: Non-operation</li></ul>
ENGINE START BY I-KEY	Engine start function mode can be changed to operation with this mode <ul style="list-style-type: none"><li>• On: Operate</li><li>• Off: Non-operation</li></ul>
TRUNK/GLASS HATCH OPEN	Buzzer reminder function mode by trunk lid opener request switch and Intelligent Key can be changed to operation with this mode <ul style="list-style-type: none"><li>• On: Operate</li><li>• Off: Non-operation</li></ul>
PANIC ALARM SET	Panic alarm button pressing time on Intelligent Key remote control button can be selected from the following with this mode <ul style="list-style-type: none"><li>• MODE 1: 0.5 sec</li><li>• MODE 2: Non-operation</li><li>• MODE 3: 1.5 sec</li></ul>
TRUNK OPEN DELAY	Trunk button pressing on Intelligent Key can be selected as per the following in this mode. <ul style="list-style-type: none"><li>• MODE 1: Press and hold</li><li>• MODE 2: Press twice</li><li>• MODE 3: Press and hold, or press twice</li></ul>
LO- BATT OF KEY FOB WARN	Intelligent Key low battery warning mode can be changed to operation with this mode <ul style="list-style-type: none"><li>• On: Operate</li><li>• Off: Non-operation</li></ul>
ANTI KEY LOCK IN FUNCTI	Key reminder function mode can be changed to operation with this mode <ul style="list-style-type: none"><li>• On: Operate</li><li>• Off: Non-operation</li></ul>
HAZARD ANSWER BACK	Hazard reminder function mode by door request switch and Intelligent Key button can be selected from the following with this mode <ul style="list-style-type: none"><li>• Lock Only: Door lock operation only</li><li>• Unlock Only: Door unlock operation only</li><li>• Lock/Unlock: Lock and unlock operation</li><li>• Off: Non-operation</li></ul>
ANS BACK I-KEY LOCK	Buzzer reminder function (lock operation) mode by door request switch can be selected from the following with this mode <ul style="list-style-type: none"><li>• Horn Chirp: Sound horn</li><li>• Buzzer: Sound Intelligent Key warning buzzer</li><li>• Off: Non-operation</li></ul>
ANS BACK I-KEY UNLOCK	Buzzer reminder function (unlock operation) mode by door request switch can be changed to operation with this mode <ul style="list-style-type: none"><li>• On: Operate</li><li>• Off: Non-operation</li></ul>
SHORT CRANKING OUTPUT	Starter motor can operate during the times below <ul style="list-style-type: none"><li>• 70 msec</li><li>• 100 msec</li><li>• 200 msec</li></ul>
CONFIRM KEY FOB ID	It can be checked whether Intelligent Key ID code is registered or not in this mode
AUTO LOCK SET	Auto door lock operation time can be changed in this mode <ul style="list-style-type: none"><li>• MODE 1: OFF</li><li>• MODE 2: 30 sec</li><li>• MODE 3: 1 minute</li><li>• MODE 4: 2 minutes</li><li>• MODE 5: 3 minutes</li><li>• MODE 6: 4 minutes</li><li>• MODE 7: 5 minutes</li></ul>

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[POWER DISTRIBUTION SYSTEM]

Monitor item	Description
HORN WITH KEYLESS LOCK	Horn reminder function mode by Intelligent Key button can be selected from the following with this mode <ul style="list-style-type: none"> <li>On: Operate</li> <li>Off: Non-operation</li> </ul>
PW DOWN SET	Unlock button pressing time on Intelligent Key button can be selected from the following with this mode <ul style="list-style-type: none"> <li>MODE 1: 3 sec</li> <li>MODE 2: Non-operation</li> <li>MODE 3: 5 sec</li> </ul>
WELCOME LIGHT SELECT	Welcome light function mode can be selected from the following with this mode <ul style="list-style-type: none"> <li>Puddle/Outside Handle</li> <li>Room lamp</li> <li>Head &amp; Tail Lamps (this item is displayed, but cannot be used)</li> <li>Heart Beat</li> </ul>
WELCOME LIGHT OP SET	Welcome light function mode can be changed to operation with this mode <ul style="list-style-type: none"> <li>On: Operate</li> <li>Off: Non-operation</li> </ul>
INTELLIGENT KEY SETUP	Intelligent Key interlock function mode can be changed to operation with this mode <ul style="list-style-type: none"> <li>On: Operate</li> <li>Off: Non-operation</li> </ul>

## SELF-DIAG RESULT

Refer to [BCS-59, "DTC Index"](#).

## DATA MONITOR

### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor Item	Condition
REQ SW -DR	Indicates [On/Off] condition of door request switch (driver side)
REQ SW -AS	Indicates [On/Off] condition of door request switch (passenger side)
REQ SW -BD/TR	Indicates [On/Off] condition of trunk lid opener request switch
PUSH SW	Indicates [On/Off] condition of push-button ignition switch
CLUTCH SW	<b>NOTE:</b> This item is displayed, but cannot be monitored
BRAKE SW 1	Indicates [On/Off]* condition of stop lamp switch power supply
BRAKE SW 2	Indicates [On/Off] condition of stop lamp switch
DETE/CANCL SW	Indicates [On/Off] condition of P position
SFT PN/N SW	Indicates [On/Off] condition of P or N position
S/L -LOCK	<b>NOTE:</b> This item is displayed, but cannot be monitored
S/L -UNLOCK	<b>NOTE:</b> This item is displayed, but cannot be monitored
S/L RELAY -F/B	<b>NOTE:</b> This item is displayed, but cannot be monitored
UNLK SEN -DR	Indicates [On/Off] condition of driver door UNLOCK status
PUSH SW -IPDM	Indicates [On/Off] condition of push-button ignition switch
IGN RLY1 -F/B	Indicates [On/Off] condition of ignition relay 1
DETE SW -IPDM	Indicates [On/Off] condition of P position
SFT PN -IPDM	Indicates [On/Off] condition of P or N position
SFT P -MET	Indicates [On/Off] condition of P position
SFT N -MET	Indicates [On/Off] condition of N position

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

## [POWER DISTRIBUTION SYSTEM]

Monitor Item	Condition
ENGINE STATE	Indicates [Stop/Stall/Crank/Run] condition of engine states
S/L LOCK-IPDM	<b>NOTE:</b> This item is displayed, but cannot be monitored
S/L UNLK-IPDM	<b>NOTE:</b> This item is displayed, but cannot be monitored
S/L RELAY-REQ	<b>NOTE:</b> This item is displayed, but cannot be monitored
VEH SPEED 1	Display the vehicle speed signal received from combination meter by numerical value [Km/h]
VEH SPEED 2	Display the vehicle speed signal received from ABS or VDC or TCM by numerical value [Km/h]
DOOR STAT-DR	Indicates [LOCK/READY/UNLK] condition of driver side door status
DOOR STAT-AS	Indicates [LOCK/READY/UNLK] condition of passenger side door status
ID OK FLAG	Indicates [Set/Reset] condition of key ID
PRMT ENG STRT	Indicates [Set/Reset] condition of engine start possibility
PRMT RKE STRT	<b>NOTE:</b> This item is displayed, but cannot be monitored
TRNK/HAT MNTR	Indicates [On/Off] condition of trunk room lamp switch
RKE-LOCK	Indicates [On/Off] condition of LOCK signal from Intelligent Key
RKE-UNLOCK	Indicates [On/Off] condition of UNLOCK signal from Intelligent Key
RKE-TR/BD	Indicates [On/Off] condition of trunk open signal from Intelligent Key
RKE-PANIC	Indicates [On/Off] condition of panic alarm button of Intelligent Key
RKE-MODE CHG	Indicates [On/Off] condition of MODE CHANGE signal from Intelligent Key
RKE OPE COUN1	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing
RKE OPE COUN2	<b>NOTE:</b> This item is displayed, but cannot be monitored

\*: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

## ACTIVE TEST

Test item	Description
BATTERY SAVER	This test is able to check interior room lamp operation <ul style="list-style-type: none"> <li>On: Operate</li> <li>Off: Non-operation</li> </ul>
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation <ul style="list-style-type: none"> <li>On: Operate</li> <li>Off: Non-operation</li> </ul>
INSIDE BUZZER	This test is able to check warning chime in combination meter operation <ul style="list-style-type: none"> <li>Take Out: Take away warning chime sounds when CONSULT screen is touched</li> <li>Key: Key warning chime sounds when CONSULT screen is touched</li> <li>Knob: OFF position warning chime sounds when CONSULT screen is touched</li> <li>Off: Non-operation</li> </ul>
INDICATOR	This test is able to check warning lamp operation <ul style="list-style-type: none"> <li>KEY ON: "KEY" Warning lamp illuminates when CONSULT screen is touched</li> <li>KEY IND: "KEY" Warning lamp blinks when CONSULT screen is touched</li> <li>Off: Non-operation</li> </ul>
INT LAMP	This test is able to check interior room lamp operation <ul style="list-style-type: none"> <li>On: Operate</li> <li>Off: Non-operation</li> </ul>

# DIAGNOSIS SYSTEM (BCM)

## < SYSTEM DESCRIPTION >

## [POWER DISTRIBUTION SYSTEM]

Test item	Description
LCD	<p>This test is able to check meter display information</p> <ul style="list-style-type: none"> <li>• Engine start information displays when "BP N" on CONSULT screen is touched</li> <li>• Engine start information displays when "BP I" on CONSULT screen is touched</li> <li>• Key ID warning displays when "ID NG" on CONSULT screen is touched</li> <li>• Steering lock information displays when "ROTAT" on CONSULT screen is touched</li> </ul> <p><b>NOTE:</b> For models without steering lock unit, "ROTAT" is displayed, but cannot be tested.</p> <ul style="list-style-type: none"> <li>• P position warning displays when "SFT P" on CONSULT screen is touched</li> <li>• INSRT: This item is displayed, but cannot be monitored</li> <li>• BATT: This item is displayed, but cannot be monitored</li> <li>• Take away through window warning displays when "NO KY" on CONSULT screen is touched</li> <li>• Take away warning display when "OUTKEY" on CONSULT screen is touched</li> <li>• OFF position warning display when "LK WN" on CONSULT screen is touched</li> </ul>
FLASHER	<p>This test is able to check hazard warning lamp operation</p> <p>The hazard warning lamps are activated after "LH/RH/Off" on CONSULT screen is touched</p>
P RANGE	<p>This test is able to check AT shift selector power supply</p> <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
ENGINE SW ILLUMI	<p>This test is able to check push-ignition switch illumination operation</p> <p>Push-ignition switch illumination illuminates when "ON" on CONSULT screen is touched</p>
LOCK INDICATOR	<p>This test is able to check LOCK indicator (push-button ignition switch) operation</p> <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
ACC INDICATOR	<p>This test is able to check ACC indicator (push-button ignition switch) operation</p> <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
IGNITION ON IND	<p>This test is able to check ON indicator (push-button ignition switch) operation</p> <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
HORN	<p>This test is able to check horn operation</p> <ul style="list-style-type: none"> <li>• On: Operate</li> <li>• Off: Non-operation</li> </ul>
TRUNK/BACK DOOR	<p>This test is able to check trunk lid open operation</p> <ul style="list-style-type: none"> <li>• Open: Operate</li> </ul>
INTELLIGENT KEY LINK	<p>This test is able to check Intelligent Key interlock function</p> <ul style="list-style-type: none"> <li>• ID No1: BCM transmits Intelligent Key ID No1 to each control unit</li> <li>• ID No2: BCM transmits Intelligent Key ID No2 to each control unit</li> </ul>
INTELLIGENT KEY LINK (CAN)	<p>This test is able to check Intelligent Key interlock function</p> <ul style="list-style-type: none"> <li>• Off: Non-operation</li> <li>• ID No1: BCM transmits Intelligent Key ID No1 to each control unit via CAN communication line</li> <li>• ID No2: BCM transmits Intelligent Key ID No2 to each control unit via CAN communication line</li> <li>• ID No3: BCM transmits Intelligent Key ID No3 to each control unit via CAN communication line</li> <li>• ID No4: BCM transmits Intelligent Key ID No4 to each control unit via CAN communication line</li> <li>• ID No5: This item is displayed, but cannot be used</li> </ul>

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

ECU DIAGNOSIS INFORMATION

BCM

List of ECU Reference

INFOID:0000000012352411

ECU	Reference
BCM	<a href="#">BCS-37. "Reference Value"</a>
	<a href="#">BCS-57. "Fail-safe"</a>
	<a href="#">BCS-58. "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-59. "DTC Index"</a>




**[POWER DISTRIBUTION SYSTEM]**

## WIRING DIAGRAM

## Wiring Diagram

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
PC  
N  
O  
P




2014/07/11

JRMWG1242GB

**[POWER DISTRIBUTION SYSTEM]**

**[POWER DISTRIBUTION SYSTEM]**



# POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]


## PDS (POWER DISTRIBUTION SYSTEM)

Connector No.	E5
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH05PW-44-1V




Terminal No.	Color Of Wire	Signal Name [Specification]
4	W	ENG_SOL
5	P	IGN_COIL
6	R	ECM_VB [With VQ37 engine]
6	SB	ETC [With V56 engine]
7	R	ETC [With VQ37 engine]
7	Y	A/C_COMP [With V56 engine]
8	L/Y	A/C_COMP [With VQ37 engine]
8	P	ECM_BAT
10	V	P_GND
11	B	AUS_ECU
12	G	FUEL_PUMP [With VQ37 engine]
13	GR	FUEL_PUMP [With V56 engine]
13	W	WIPER_AUTOSTOP
15	V	IGN_SIGNAL
18	R	ALT_F
22	BR	DRIVE_SW
23	O	DRIVE_SW
24	R	SUB_ECU
25	LG	PUSH_START_SW
30	BR	NP_SW [With V56 engine]
31	W	NP_SW [With VQ37 engine]
31	W	F/L_IGN_SW
36	GR	

Connector No.	E6
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH05PW-44



Terminal No.	Color Of Wire	Signal Name [Specification]
39	P	CAN-L
40	L	CAN-H
41	B	S_GND
42	V	MOTOR_FAN_RLY_CONT [With V56 engine]
42	Y	MOTOR_FAN_RLY_CONT [With VQ37 engine]
43	SB	DETENT_SW
44	GR	HORN_RLY [With V56 engine]
44	LG	HORN_RLY [With VQ37 engine]
45	G	HORN_SW
46	BR	START_CONT


Connector No.	E7
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH05PW-45-2M4




Terminal No.	Color Of Wire	Signal Name [Specification]
48	P	DTL_DECER
51	O	WASH_MTR
52	G	INJECTOR_#1
53	L	FR_WIPER_HI
54	P	FR_WIPER_LO
55	R	TAIL/LLUMI
56	GR	O2_SENS_#1
57	V	O2_SENS_#2
58	BR	AT_ECU

70	LG	SSOIF
71	O	MOT_RLY
72	G	START_IG/F
72	Y	START_IG/F
75	X	OUT_PSSD_SW
77	B	IGN
77	B	STARTER_MOTOR
80	W	

Connector No.	E10
Connector Name	WIRE TO WHITE
Connector Type	SAA38MB-RCS-S4Z8



Connector No.	E12
Connector Name	ICC BRAKE HOLD RELAY
Connector Type	W502FL-M2-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	V	
2	LG	
3	V	
5	W	


# POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]


## PDS (POWER DISTRIBUTION SYSTEM)

Connector No.	FE03
Connector Name	FUSE BLOCK (J/B)
Connector Type	HS16FW-C5



Terminal No.	Color Of Wire	Signal Name [Specification]
10F	GR	-
12F	Y	-
14F	W	-
15F	V	-
1F	S8	-
2F	LG	-
4F	G	-
6F	O	-
8F	BR	-
9F	R	-

Connector No.	FE06
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-C515-TM44



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	W	-
3	S8	-
4	LG	-
5	O	-
6	W	-
7	GR	-
8	G	-
9	Y	-
10	BR	-


11	S8	-
12	GR	-
13	GR	-
14	GR	-
15	V	-
16	Y	-
17	GR	-
18	V	-
20	BR	-
21	P	-
22	L	-
23	P	-
27	SHIELD	-
28	L/O	-
29	W/L	-
31	BR	-
32	G	-
33	O	-
34	Y	-
36	G	-
37	V	-
41	BR	-
44	W	-
45	L	-
46	GR	-
47	V	-
48	G	-
49	O	-
50	LG	-
51	S	-
55	S	-
60	W	-
61	G	-
62	Y	-
63	BR	-
64	B	-
65	Y	-
66	R	-
67	S8	-
68	G	-
69	SHIELD	-
70	W	-
71	W	-
72	R	-
73	G	-
74	Y	-
75	B	-
76	SHIELD	-
77	O	-
78	S8	-

Connector No.	FE10
Connector Name	STOP LAMP SWITCH
Connector Type	HS4FW-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	V	-
3	G	- [Without ICC]
3	W	- [With ICC]
4	S8	-

Connector No.	FE40
Connector Name	WIRE TO WIRE
Connector Type	SAA365B-RS8-5429



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L/W	-
2	SHIELD	-
3	L/B	-
4	SHIELD	-
5	L/W	-
6	R	- [With V556 engine]
7	W	- [With VQ37 engine]
9	W	-
10	G	-
11	G	- [With V556 engine]
12	W	- [With VQ37 engine]
13	P	-
14	Y	-
15	R	-
16	O	- [With V556 engine]
16	Y	- [With VQ37 engine]
19	L	-
20	GR	-
21	G	-
22	W	-
23	L	-
24	Y	-
25	LG	-
28	R	-
29	W	-
30	B	-
31	V	-
32	BR	- [With VQ37 engine]
32	LG	- [With V556 engine]
33	P	- [With VQ37 engine]
33	Y	- [With V556 engine]
34	O	-
37	SHIELD	-
38	U/G	- [With V556 engine]

JRMW16297GB

# POWER DISTRIBUTION SYSTEM


< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

PDS (POWER DISTRIBUTION SYSTEM)

Connector No.	Signal Name [Specification]
38	O/L
39	L/Y
40	W/L
41	O/L
42	W/L
43	O/L
44	W/L
45	O/L
46	W/L
47	W/L
48	W/L
49	W/L
50	W/L
51	O/L
52	O/L
53	W/L

Connector No.	Signal Name [Specification]
FE1	A/T ASSEMBLY
PR105G-DG1	




Terminal No.	Color Of Wire	Signal Name [Specification]
1	Y	POWER SUPPLY (BACK UP)
2	R	POWER SUPPLY (BACK UP)
3	L	CAN-H
4	V	K-LINE
5	B	GND
6	G	POWER SUPPLY (IGN)
7	SB	BACK-UP LAMP RELAY
8	P	CAN-L
9	BR	P/N SIGNAL
10	B	GROUND

Connector No.	Signal Name [Specification]
301	TCM
SP10FG	




Terminal No.	Color Of Wire	Signal Name [Specification]
1	-	VIGN
2	-	BATT
3	-	CAN-H
4	-	K-LINE
5	-	GND
6	-	VIGN
7	-	REV LAMP RLY
8	-	CAN-L
9	-	START RLY
10	-	GND

Connector No.	Signal Name [Specification]
M1	FUSE BLOCK (I/B)
NS05FW-A02	




Terminal No.	Color Of Wire	Signal Name [Specification]
1A	R	-
2A	W	-
3A	Y	-
4A	W	-
5A	V	-
6A	Y	-
7A	Y	-
8A	Y	-

Connector No.	Signal Name [Specification]
M2	FUSE BLOCK (I/B)
NS10FW-CS	




Terminal No.	Color Of Wire	Signal Name [Specification]
1B	R	-
2B	P	-
3B	G	-
4B	SB	-
5B	W	-
6B	Y	-
7B	Y	-
8B	R	-
9B	R	-

Connector No.	Signal Name [Specification]
M3	FUSE BLOCK (I/B)
NS12FW-CS	



Terminal No.	Color Of Wire	Signal Name [Specification]
10C	LG	-
11C	LG	-
12C	O	-
6C	R	-
7C	B	-
8C	B	-
9C	L	-

Connector No.	Signal Name [Specification]
M6	WIRE TO WIRE
TH80MW-CS17-TM4	



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	-
2	W	-
3	SB	-
4	LG	-
5	W	-
6	W	-
7	BG	-
8	G	-
9	Y	-
10	W	-
11	R	-
12	V	-
13	LG	-
14	L	-
15	V	-
16	B	-
17	GN	-
18	SB	-
19	SB	-
20	SB	-
21	BR	-
22	L	-
23	P	-
24	SHIELD	-
25	V	-
26	SB	-
27	BG	-
28	P	-
29	R	-
30	SB	-
31	LG	-
32	P	-
33	R	-
34	BG	-
35	V	-
36	V	-
37	G	-
38	BR	-
39	Y	-
40	Y	-
41	Y	-
42	Y	-
43	Y	-
44	Y	-
45	Y	-
46	Y	-
47	V	-

# POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

PDS (POWER DISTRIBUTION SYSTEM)

48	G	-
49	B	-
50	W	-
51	W	-
52	G	-
53	G	-
54	W	-
55	G	-
56	GB	-
57	W	-
58	B	-
59	LG	-
60	BR	-
61	BR	-
62	L	-
63	Y	-
64	R	-
65	P	-
66	L	-
67	SHIELD	-
68	W	-
69	W	-
70	W	-
71	R	-
72	G	-
73	Y	-
74	B	-
75	SHIELD	-
76	B	-
77	V	-
78	G	-
79	B	-
80	B	-
81	Y	-
82	Y	-
83	Y	-
84	L	-
85	L	-
86	L	-
87	V	-
88	V	-
89	LG	-
90	BG	-
91	W	-
92	BG	-
93	G	-
94	Y	-
95	W	-
96	W	-
97	SH	-
98	R	-
99	W	-
100	L	-

Connector No.	M20
Connector Name	PCB HARNESS
Connector Type	TH40P8-NH



Connector No.	M22
Connector Name	PCB HARNESS
Connector Type	TH40P8-NH



Connector No.	M27
Connector Name	PCB HARNESS
Connector Type	TH40P8-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	Y	-
4	G	-
5	R	-
6	W	-
11	BR	-
12	R	-
15	B	-
16	SHIELD	-
17	R	-
18	P	-
19	W	-
21	B	-
22	R	-
23	L	-
24	S9	-
25	L	-
26	L	-
27	P	-
31	V	-
33	V	-
35	L	-
36	P	-
38	L	-
40	Y	-

Terminal No.	Color Of Wire	Signal Name [Specification]
81	L	-
82	P	-
83	B	-
84	B	-
85	B	-
86	B	-
87	B	-
88	B	-
89	Y	-
91	V	-
92	V	-
93	B	-
94	B	-
95	LG	-
96	BR	-
97	G	-
98	G	-
100	G	-
101	L	-
102	P	-
103	B	-
104	BR	-
105	R	-
107	Y	-
108	Y	-
109	BR	-
110	Y	-
112	P	-
113	P	-
114	L	-
116	B	-
117	B	-
118	BG	-
119	LG	-

Terminal No.	Color Of Wire	Signal Name [Specification]
281	O	-
282	BG	-
283	BG	-
284	BG	-
286	W	-
287	Y	-
288	W	-
289	SHIELD	-
290	B	-
291	SHIELD	-
292	B	-
293	B	-
294	B	-
295	B	-
296	GB	-
297	B	-
298	B	-
299	L	-
300	W	-
301	R	-
302	R	-
303	R	-
304	SHIELD	-
305	P	-
306	V	-
309	G	-
310	R	-
311	W	-
312	B	-
313	B	-
314	Y	-
315	G	-
316	R	-

JRMW16299GB

# POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]

## PDS (POWER DISTRIBUTION SYSTEM)

Terminal No.	Wire	Signal Name [Specification]
317	W	-
318	SHIELD	-
319	W	-
320	W	-

Connector No.	MS9
Connector Name	PUSH-BUTTON IGNITION SWITCH
Connector Type	TK08FBR



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	-
2	B	-
3	R	-
4	BR	-
5	GR	-
6	Y	-
7	V	-
8	W	-

Connector No.	ME3
Connector Name	COMBINATION METER
Connector Type	TH40FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	W	BATTERY POWER SUPPLY
2	BG	IGNITION SIGNAL
3	GR	VEHICLE SPEED SIGNAL (2-PULSE)
4	R	ILLUMINATION CONTROL SIGNAL
5	B	METER CONTROL SWITCH GROUND

Terminal No.	Wire	Signal Name [Specification]
7	SB	ENTER SWITCH SIGNAL
8	LG	SELECT SWITCH SIGNAL
9	G	ILLUMINATION CONTROL SWITCH SIGNAL (+)
10	GR	ILLUMINATION CONTROL SWITCH SIGNAL (-)
11	SB	TRIP RESET SWITCH SIGNAL
12	B	GROUND
13	L	CAN-L
14	P	AIR BAG SIGNAL
15	R	LED HEADLAMP (RH) WARNING SIGNAL
16	G	LED HEADLAMP (LH) WARNING SIGNAL
17	V	GROUND
18	B	FUEL LEVEL SENSOR GROUND
19	B	ALTERNATOR SIGNAL
20	W	PARKING BRAKE SWITCH SIGNAL
21	V	BRAKE FLUID LEVEL SWITCH SIGNAL
22	G	SECURITY SIGNAL
23	L	WASHER LEVEL SWITCH SIGNAL
24	G	PADDLE SHIFTER SHIFT DOWN SIGNAL
25	BG	PADDLE SHIFTER SHIFT UP SIGNAL
26	W	FUEL LEVEL SENSOR SIGNAL
27	G	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
28	G	PASSENGER SEAT BELT WARNING SIGNAL
29	G	NON-MANUAL MODE SIGNAL
30	V	MANUAL MODE SHIFT DOWN SIGNAL
31	L	MANUAL MODE SHIFT UP SIGNAL
32	W	MANUAL MODE SIGNAL


Connector No.	M120
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40F8-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	RR WINDOW DEFROG RLY CONT
2	BG	COMBI SW INPUT 5
3	SB	COMBI SW INPUT 4
4	L	COMBI SW INPUT 3
5	G	COMBI SW INPUT 2
6	P	COMBI SW INPUT 1
7	V	POWER WINDOW SW COMM

Terminal No.	Wire	Signal Name [Specification]
9	P	STOP LAMP SW L
10	R	RAIN SENSOR SERIAL LINK
11	R	RAIN SENSOR SERIAL LINK
12	SB	REAR WIPER MOTOR
13	Y	SENSOR PWR SUPPLY
14	B	RECEIVER/SENSOR GND
15	V	TURN SIG RH OUTPUT (FRONT)
16	G	TURN SIG LH OUTPUT (FRONT)
17	P	NATS ANT AMP
18	GR	KYLS ENT RECEIVER RSSI
19	G	SECURITY IND CONT
20	L	DONGLE LINK
21	G	NATS ANT AMP
22	G	I-KEY IDENTIFICATION
23	G	HAZARD SW
24	O	TR LID OPEN SW
25	W	DR DOOR UNLK SENSOR
26	BR	COMBI SW OUTPUT 5
27	R	COMBI SW OUTPUT 4
28	Y	COMBI SW OUTPUT 3
29	LG	COMBI SW OUTPUT 2
30	R	COMBI SW OUTPUT 1
31	L	P POSITION
32	L	CAN-H
33	P	CAN-L

Connector No.	M122
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	FE40SPW-FH46-SA



Terminal No.	Color Of Wire	Signal Name [Specification]
56	R	INT ROOM LAMP PWR SPLY
57	R	BAT (FUSE)
58	L	AIR BAG SIGNAL
59	G	PASS DOOR UNLK OUTPUT
60	G	TURN SIG LH OUTPUT (SIDE, REAR)
61	V	TURN SIG RH OUTPUT (SIDE, REAR)
62	L	STEP LAMP CONT
63	L	ROOM LAMP TIMER CONT
64	V	ALL DOOR, FL LID LOCK OUTPUT

Terminal No.	Wire	Signal Name [Specification]
66	LG	DR DOOR, FL LID UNLK OUTPUT
67	B	GND
68	O	PWR PWR SW L (IGN)
69	O	PWR PWR SW R (BAT)
70	W	BAT (FL)

Connector No.	M123
Connector Name	BCM (BODY CONTROL MODULE)
Connector Type	TH40FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
71	BR	KYLS ENT RECEIVER COMMA
72	B	OUTS HD LAMP OUTPUT
73	V	ON IND
74	G	DR DOOR REQ SW
75	BR	PUSH SW
76	BR	DRIVER DOOR ANT+
77	SB	PASSENGER DOOR ANT+
78	LG	PASSENGER DOOR ANT-
79	V	REAR BUMP ANT+
80	SB	REAR BUMP ANT-
81	BR	ROOM ANT1+
82	Y	ROOM ANT1-
83	R	ROOM ANT2+
84	G	ROOM ANT2-
85	V	TRUNK ROOM ANT+
86	R	PUSH-BTN IGN SW ILL PWR
87	GR	LOCK IND
88	B	PUSH-BTN IGN SW ILL GND
89	V	I-KEY WARN BUZZER
90	SB	ACC RELAY CONT
91	SB	STARTER RELAY CONT
92	B	IGN RELAY (PDM E/R) CONT
93	R	IGN RELAY (F/R) CONT
94	R	PASS DOOR REQ SW
95	BR	P/N POSITION
96	GR	A/T SHIFT SELECT PWR SPLY
97	R	STOP LAMP SW 2

POWER DISTRIBUTION SYSTEM

< WIRING DIAGRAM >

[POWER DISTRIBUTION SYSTEM]





# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:0000000012352413

OVERALL SEQUENCE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
PCS  
N  
O  
P

JMKIA8652GB

DETAILED FLOW

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]

---

## 1.GET INFORMATION FOR SYMPTOM

---

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

## 2.CHECK DTC

---

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

## 3.CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

## 4.CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

## 5.PERFORM DTC CONFIRMATION PROCEDURE

---

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-58. "DTC Inspection Priority Chart"](#), and determine trouble diagnosis order.

### NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.  
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-45. "Intermittent Incident"](#).

## 6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

---

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

## 7.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

---

## DIAGNOSIS AND REPAIR WORK FLOW

### < BASIC INSPECTION >

### [POWER DISTRIBUTION SYSTEM]

Inspect according to Diagnostic Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-45. "Intermittent Incident"](#).

### 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

### 9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# PROCEDURE FOR TEMPORARILY DISABLING THE IGNITION BATTERY SAVER SYSTEM

< BASIC INSPECTION >

[POWER DISTRIBUTION SYSTEM]

## PROCEDURE FOR TEMPORARILY DISABLING THE IGNITION BATTERY SAVER SYSTEM

### Description

INFOID:0000000012352414

The ignition battery saver system can be temporarily disabled, without using CONSULT, to prevent it from functioning when performing trouble diagnosis.

### Work Procedure

INFOID:0000000012352415

1. Enter the vehicle carrying a registered Intelligent Key.
2. Place the ignition switch in the ACC position by operating the push-button ignition switch without depressing the brake pedal.
3. Press and hold the push button ignition switch continuously for ten seconds.
4. Check that the buzzer in the combination meter sounds for two seconds.
5. Operation is completed.

**NOTE:**

When the ignition switch is placed in any position other than ON, the ignition battery saver system is activated again.

# B2614 ACC RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## DTC/CIRCUIT DIAGNOSIS

### B2614 ACC RELAY CIRCUIT

#### DTC Logic

INFOID:0000000012352416

#### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2614	BCM	An immediate operation of accessory relay is requested by BCM, but there is no response for more than 2 second.	<ul style="list-style-type: none"><li>• Harness or connectors (Accessory relay circuit is open or shorted)</li><li>• BCM</li><li>• Accessory relay</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the power supply position to ACC under the following conditions, and wait for 2 second or more.
  - Selector lever is in the P position
  - Do not depress brake pedal
2. Check "Self-diagnosis result" of BCM with CONSULT.

##### Is DTC detected?

- YES >> Go to [PCS-61, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

#### Diagnosis Procedure

INFOID:0000000012352417

##### 1.CHECK ACCESSORY RELAY POWER SUPPLY-1

1. Turn ignition switch OFF.
2. Disconnect accessory relay.
3. Check voltage between accessory relay harness connector and ground.

(+)	(-)	Condition		Voltage (V) (Approx.)
Accessory relay				
Terminal				
1	Ground	Ignition switch	OFF	0
			ACC or ON	12

##### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

##### 2.CHECK ACCESSORY RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between accessory relay harness connector and BCM harness connector.

Accessory relay	BCM		Continuity
	Connector	Terminal	
1	M123	96	Existed

4. Check continuity between accessory relay harness connector and ground.

## B2614 ACC RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

Accessory relay	Ground	Continuity
Terminal		
1		Not existed

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-95, "Removal and Installation"](#).

NO >> Repair or replace harness.

### 3.CHECK ACCESSORY RELAY GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between accessory relay harness connector and ground.

Accessory relay	Ground	Continuity
Terminal		
2		Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair accessory relay ground circuit.

### 4.CHECK ACCESSORY RELAY POWER SUPPLY CIRCUIT-2

1. Turn ignition switch ACC.
2. Check voltage between accessory relay harness connector and ground.

(+)	(-)	Voltage (V) (Approx.)
Accessory relay		
Terminal		
5	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> Check continuity open or short between accessory relay and battery.

### 5.CHECK ACCESSORY RELAY

Refer to [PCS-62, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace accessory relay.

### 6.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:0000000012352418

### 1.CHECK ACCESSORY RELAY

1. Turn ignition switch OFF.
2. Remove accessory relay.

B2614 ACC RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >


[POWER DISTRIBUTION SYSTEM]

3. Check the continuity between accessory relay terminals.

Terminals	Condition	Continuity
3 and 5	12 V direct current supply between terminals 1 and 2	Existed
	No current supply	Not existed

Is the inspection result normal?

YES >> INSPECTION END  
NO >> Replace accessory relay



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# B2615 BLOWER RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## B2615 BLOWER RELAY CIRCUIT

### DTC Logic

INFOID:0000000012352419

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2615	BCM	BCM detects a difference of signal for 1 second or more between the following items. <ul style="list-style-type: none"><li>• Blower relay ON/OFF request</li><li>• Blower relay feedback</li></ul>	<ul style="list-style-type: none"><li>• Harness or connectors (Blower relay circuit is open or shorted)</li><li>• BCM</li><li>• Blower relay</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions, and wait for 1 second or more.
  - Selector lever is in the P position
  - Do not depress brake pedal
2. Check "Self-diagnosis result" of BCM with CONSULT.

#### Is DTC detected?

- YES >> Go to [PCS-64. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:0000000012352420

#### 1.CHECK BLOWER RELAY POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect blower relay.
3. Check voltage between blower relay harness connector and ground.

(+)	(-)	Condition		Voltage (V) (Approx.)
Blower relay				
Terminal				
1	Ground	Ignition switch	OFF or ACC	0
			ON	Battery voltage

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK BLOWER RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between blower relay harness connector and BCM harness connector.

Blower relay Terminal	BCM		Continuity
	Connector	Terminal	
1	M123	106	Existed

4. Check continuity between blower relay harness connector and ground.

Blower relay Terminal	Ground	Continuity
		Not existed
1		

#### Is the inspection result normal?



## B2615 BLOWER RELAY CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

### [POWER DISTRIBUTION SYSTEM]

- YES >> GO TO 6.  
NO >> Repair or replace harness.

### 3.CHECK BLOWER RELAY GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between blower relay harness connector and ground.

Blower relay	Ground	Continuity
Terminal		
2		Existed

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair blower relay ground circuit.

### 4.CHECK BLOWER RELAY POWER SUPPLY CIRCUIT-2

1. Turn ignition switch ON.
2. Check voltage between blower relay harness connector and ground.

(+)	(-)	Voltage (V) (Approx.)
Blower relay		
Terminal		
5	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Check continuity open or short between blower relay and battery.

### 5.CHECK BLOWER RELAY

Refer to [PCS-65, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Replace blower relay.

### 6.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:0000000012352421

PCS


### 1.CHECK BLOWER RELAY

1. Turn ignition switch OFF.
2. Remove blower relay.
3. Check the continuity between blower relay terminals.

Terminals	Condition	Continuity
3 and 5	12 V direct current supply between terminals 1 and 2	Existed
	No current supply	Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace blower relay



PBIB0098E

# B2616 IGNITION RELAY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## B2616 IGNITION RELAY CIRCUIT

### DTC Logic

INFOID:0000000012352422

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2616	BCM	An immediate operation of ignition relay is requested by BCM, but there is no response for more than 1 second	<ul style="list-style-type: none"><li>• Harness or connectors (Ignition relay circuit is open or shorted)</li><li>• BCM</li><li>• Ignition relay</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions, and wait for 1 second or more.
  - Selector lever is in the P position
  - Do not depress brake pedal
2. Check "Self-diagnosis result" with CONSULT.

#### Is DTC detected?

- YES >> Go to [PCS-66, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:0000000012352423

#### 1.CHECK IGNITION RELAY POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect ignition relay.
3. Check voltage between ignition relay harness connector and ground.

(+)	(-)	Condition		Voltage (V) (Approx.)
Ignition relay Terminal				
2	Ground	Ignition switch	OFF or ACC	0
			ON	Battery voltage

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK IGNITION RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between ignition relay harness connector and BCM harness connector.

Ignition relay Terminal	BCM		Continuity
	Connector	Terminal	
2	M123	99	Existed

4. Check continuity between ignition relay harness connector and ground.

Ignition relay Terminal	Ground	Continuity
		Not existed
2		

#### Is the inspection result normal?

## B2616 IGNITION RELAY CIRCUIT

### < DTC/CIRCUIT DIAGNOSIS >

### [POWER DISTRIBUTION SYSTEM]

- YES >> Replace BCM. Refer to [BCS-95. "Removal and Installation"](#).  
NO >> Repair or replace harness.

### 3.CHECK IGNITION RELAY GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between ignition relay harness connector and ground.

Ignition relay	Ground	Continuity
Terminal		
1		Existed

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair ignition relay ground circuit.

### 4.CHECK IGNITION RELAY POWER SUPPLY CIRCUIT-2

1. Turn ignition switch ON.
2. Check voltage between ignition relay harness connector and ground.

(+)	(-)	Voltage (V) (Approx.)
Ignition relay		
Terminal		
5	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Check continuity open or short between ignition relay and battery.

### 5.CHECK IGNITION RELAY

Refer to [PCS-67. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Replace ignition relay.

### 6.CHECK INTERMITTENT INCIDENT

Refer to [GI-45. "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:0000000012352424

PCS


### 1.CHECK IGNITION RELAY

1. Turn ignition switch OFF.
2. Remove ignition relay.
3. Check the continuity between ignition relay terminals.

Terminals	Condition	Continuity
3 and 5	12 V direct current supply between terminals 1 and 2	Existed
	No current supply	Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace Ignition relay



**B2618 BCM****DTC Logic**

INFOID:0000000012352425

**DTC DETECTION LOGIC****NOTE:**

- If DTC B2618 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-83, "DTC Logic"](#).
- If DTC B2618 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-84, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2618	BCM	An immediate operation of ignition relay (IPDM E/R) is requested by BCM, but there is no response for more than 1 second	BCM

**DTC CONFIRMATION PROCEDURE****1.PERFORM DTC CONFIRMATION PROCEDURE**

1. Turn ignition switch ON under the following conditions, and wait for 1 second or more.
  - Selector lever is in the P or N position
  - Do not depress brake pedal
2. Check "Self-diagnosis result" of BCM with CONSULT.

**Is DTC detected?**YES >> Go to [PCS-68, "Diagnosis Procedure"](#).

NO &gt;&gt; INSPECTION END

**Diagnosis Procedure**

INFOID:0000000012352426

**1.INSPECTION START**

1. Turn ignition switch ON.
2. Select "Self-diagnosis result" of BCM with CONSULT.
3. Touch "ERASE".
4. Perform DTC Confirmation Procedure.  
See [PCS-68, "DTC Logic"](#).

**Is the 1st trip DTC B2618 displayed again?**YES >> Replace BCM. Refer to [BCS-95, "Removal and Installation"](#)

NO &gt;&gt; INSPECTION END

# B261A PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## B261A PUSH-BUTTON IGNITION SWITCH

### DTC Logic

INFOID:0000000012352427

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B261A is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-83, "DTC Logic"](#).
- If DTC B261A is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-84, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B261A	PUSH-BTN IGN SW	BCM detects a difference of signal for 1 second or more between the following items. <ul style="list-style-type: none"><li>• Push-button ignition switch signal</li><li>• Push-button ignition switch status signal (CAN)</li></ul>	<ul style="list-style-type: none"><li>• Harness or connectors (Push-button ignition switch circuit is open or shorted.)</li><li>• BCM</li><li>• IPDM E/R</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Press the push-button ignition switch under the following conditions, and wait for 1 second or more.
  - Selector lever is in the P or N position
  - Do not depress brake pedal
2. Check "Self-diagnosis result" of BCM with CONSULT.

#### Is DTC detected?

- YES >> Go to [PCS-69, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:0000000012352428

#### 1.CHECK IGNITION SWITCH OUTPUT SIGNAL (PUSH-BUTTON IGNITION SWITCH)

1. Disconnect push-button ignition switch connector and IPDM E/R connector.
2. Check voltage between push-button ignition switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Push-button ignition switch			
Connector	Terminal		
M50	4	Ground	12

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (BCM)

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M123	100	M50	4	Existed

3. Check continuity between push-button ignition switch harness connector and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M50	4		Not existed

## B261A PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-95, "Removal and Installation"](#).

NO >> Repair or replace harness.

### 3. CHECK IGNITION SWITCH OUTPUT SIGNAL (IPDM E/R)

Check voltage between IPDM E/R harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
IPDM E/R			
Connector	Terminal		
E5	30	Ground	12

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> GO TO 4.

### 4. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT (IPDM E/R)

1. Disconnect IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and push-button ignition switch harness connector.

IPDM E/R		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
E5	30	M50	4	Existed

3. Check continuity between push-button ignition switch harness connector and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M50	4		Not existed

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

### 5. CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

# B26F1 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## B26F1 IGNITION RELAY

### DTC Logic

INFOID:0000000012352429

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B26F1	IGN RELAY OFF	BCM transmits the ignition relay control signal (ON: 0 V) or ignition switch ON signal (ON) (CAN), but does not receives ignition switch ON signal (ON) (CAN) from IPDM E/R.	<ul style="list-style-type: none"><li>• Harness or connectors (ignition relay circuit is open)</li><li>• BCM</li><li>• IPDM E/R</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions, and wait for 2 seconds or more.
  - Selector lever is in the P or N position
  - Do not depress brake pedal
2. Check "Self-diagnosis result" with CONSULT.

#### Is DTC detected?

- YES >> Go to [PCS-71, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:0000000012352430

#### 1.CHECK IPDM E/R SELF-DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Erase the DTC of IPDM E/R.
3. Turn ignition switch OFF.
4. Turn ignition switch ON and check the DTC again.

#### Is DTC detected?

- YES >> Repair or replace the malfunctioning part. Refer to [PCS-24, "DTC Index"](#).  
NO >> GO TO 2.

#### 2.CHECK IGNITION RELAY (IPDM E/R) CONTROL SIGNAL

Check voltage between BCM harness connector and ground.

(+) BCM		(-)	Condition		Voltage (V) (Approx.)
Connector	Terminal				
M123	98	Ground	Ignition switch	ON	0

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace BCM. Refer to [BCS-95, "Removal and Installation"](#).

#### 3.CHECK IGNITION RELAY (IPDM E/R) CONTROL SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM and IPDM connectors.
3. Check continuity between BCM harness connector and IPDM E/R harness connector.

BCM		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
M123	98	E5	18	Existed

#### Is the inspection result normal?

- YES >> Replace IPDM E/R.

## **B26F1 IGNITION RELAY**

< DTC/CIRCUIT DIAGNOSIS >

**[POWER DISTRIBUTION SYSTEM]**

---

NO    >> Repair or replace harness.



## B26F2 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

### B26F2 IGNITION RELAY

#### DTC Logic

INFOID:0000000012352431

#### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B26F2	IGN RELAY ON	BCM transmits the ignition relay control signal (OFF: 12 V) or ignition switch ON signal (OFF) (CAN), but does not receives ignition switch ON signal (OFF) (CAN) from IPDM E/R.	<ul style="list-style-type: none"><li>• Harness or connectors (ignition relay circuit is short)</li><li>• BCM</li><li>• IPDM E/R</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions, and wait for 2 seconds or more.
  - Selector lever is in the P or N position
  - Do not depress brake pedal
2. Check "Self-diagnosis result" with CONSULT.

##### Is DTC detected?

- YES >> Go to [PCS-73, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

#### Diagnosis Procedure

INFOID:0000000012352432

##### 1.CHECK IPDM E/R SELF-DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Erase the DTC of IPDM E/R.
3. Turn ignition switch OFF.
4. Turn ignition switch ON and check the DTC again.

##### Is DTC detected?

- YES >> Repair or replace the malfunctioning part. Refer to [PCS-24, "DTC Index"](#).  
NO >> GO TO 2.

##### 2.CHECK IGNITION RELAY (IPDM E/R) CONTROL SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between IPDM E/R harness connector and ground.

(+) IPDM E/R		(-)	Condition		Voltage (V) (Approx.)
Connector	Terminal				
E5	18	Ground	Ignition switch	OFF or ACC	12

##### Is the inspection result normal?

- YES >> Replace IPDM E/R.  
NO >> GO TO 3.

##### 3.CHECK IGNITION RELAY (IPDM E/R) CONTROL SIGNAL CIRCUIT - 1

1. Disconnect BCM and IPDM E/R connectors.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	18		Not existed

##### Is the inspection result normal?

- YES >> GO TO 4.

## B26F2 IGNITION RELAY

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

NO >> Repair or replace harness.

### 4.CHECK IGNITION RELAY (IPDM E/R) CONTROL SIGNAL CIRCUIT - 2

1. Connect IPDM E/R connectors.
2. Check voltage between IPDM E/R harness connector and ground.

(+) IPDM E/R		(-)	Condition		Voltage (V) (Approx.)
Connector	Terminal				
E5	18	Ground	Ignition switch	OFF or ACC	12

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-95. "Removal and Installation"](#).  
NO >> Replace IPDM E/R.

## B26F6 BCM

## DTC Logic

INFOID:0000000012352433

## DTC DETECTION LOGIC

**NOTE:**

- If DTC B26F6 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-83, "DTC Logic"](#).
- If DTC B26F6 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-84, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B26F6	BCM	Ignition relay ON signal is not transmitted from IPDM E/R when BCM turns ignition relay ON.	BCM

## DTC CONFIRMATION PROCEDURE

**1. PERFORM DTC CONFIRMATION PROCEDURE**

1. Turn ignition switch ON under the following conditions, and wait for 1 second or more.
  - Selector lever is in the P or N position
  - Do not depress brake pedal
2. Check "Self-diagnosis result" of BCM with CONSULT.

Is DTC detected?

- YES >> Go to [PCS-75, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

## Diagnosis Procedure

INFOID:0000000012352434

**1. INSPECTION START**

1. Turn ignition switch ON.
2. Select "Self-diagnosis result" of BCM with CONSULT.
3. Touch "ERASE".
4. Perform DTC Confirmation Procedure.  
See [PCS-75, "DTC Logic"](#).

Is DTC detected?

- YES >> Replace BCM. Refer to [BCS-95, "Removal and Installation"](#)
- NO >> INSPECTION END

PCS

# PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## PUSH-BUTTON IGNITION SWITCH

### Component Function Check

INFOID:0000000012352435

#### 1.CHECK FUNCTION

1. Select "PUSH SW" in "Data Monitor" mode with CONSULT.
2. Check the push-button ignition switch signal under the following conditions.

Test item	Condition	Status
PUSH SW	Push-button ignition switch is pressed	ON
	Push-button ignition switch is not pressed	OFF

Is the indication normal?

- YES >> INSPECTION END.  
NO >> Go to [PCS-76, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012352436

#### 1.CHECK PUSH-BUTTON IGNITION SWITCH OUTPUT SIGNAL 1

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector and IPDM E/R connector.
3. Check voltage between push-button ignition switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Push-button ignition switch			
Connector	Terminal		
M50	4	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2.CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT 1

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and push-button ignition switch harness connector.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M123	76	M50	4	Existed

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M123	76	Ground	Not existed

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-95, "Removal and Installation"](#).  
NO >> Repair or replace harness.

#### 3.CHECK PUSH-BUTTON IGNITION SWITCH OUTPUT SIGNAL 2

Check voltage between IPDM E/R harness connector and ground.

# PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

(+) IPDM E/R		(-)	Voltage (V) (Approx.)
Connector	Terminal		
E5	30	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

## 4.CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT 2

1. Disconnect BCM connector.
2. Check continuity between IPDM E/R harness connector and push-button ignition switch harness connector.

IPDM E/R		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
E5	30	M50	4	Existed

3. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E5	30		Not existed

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Repair or replace harness.

## 5.CHECK PUSH-BUTTON IGNITION SWITCH GROUND CIRCUIT

Check continuity between push-button ignition switch harness connector and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M50	1		Existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

## 6.CHECK PUSH-BUTTON IGNITION SWITCH

Refer to [PCS-77, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace push-button ignition switch.

## 7.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

## Component Inspection

INFOID:0000000012352437

## 1.CHECK PUSH-BUTTON IGNITION SWITCH

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check continuity between push-button ignition switch terminals.

## PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

Push-button ignition switch		Condition	Continuity
Terminal			
4	1	Pressed	Existed
		Not pressed	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace push-button ignition switch.

# PUSH-BUTTON IGNITION SWITCH POSITION INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## PUSH-BUTTON IGNITION SWITCH POSITION INDICATOR

### Description

INFOID:0000000012352438

Push-button ignition switch changes the power supply position.

BCM maintains the power supply position status.

BCM changes the power supply position with the operation of the push-button ignition switch.

### Component Function Check

INFOID:0000000012352439

#### 1.CHECK FUNCTION

Check push-button ignition switch ("LOCK INDICATOR", "ACC INDICATOR" and "IGNITION ON IND") in Active Test Mode with CONSULT.

Test item		Description	
LOCK INDICATOR ACC INDICATOR IGNITION ON IND	ON	Position indicator	Illuminates
	OFF		Does not illuminate

Is the inspection result normal?

YES >> INSPECTION END.

NO >> Refer to [PCS-79, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012352440

#### 1.CHECK PUSH-BUTTON IGNITION SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check voltage between push-button ignition switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Push-button ignition switch			
Connector	Terminal		
M50	8	Ground	Battery voltage

Is the inspection normal?

YES >> GO TO 2.

NO-1 >> Check 10 A fuse [No.9, located in fuse block (J/B)].

NO-2 >> Check harness for open or short between push-button ignition switch and fuse.

#### 2.CHECK BCM INPUT

1. Connect push-button ignition switch connector.
2. Disconnect BCM connector.
3. Check voltage between BCM connector and ground.

(+)		(-)	Voltage (V) (Approx.)
BCM			
Connector	Terminal		
M123	73	Ground	Battery voltage
	91		
	109		

Is the inspection normal?

YES >> Replace BCM. Refer to [BCS-95, "Removal and Installation"](#).

NO >> GO TO 3.

#### 3.CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT

1. Disconnect push-button ignition switch connector.

A

B

C

D

E

F

G

H

I

J

K

L

PCS

N

O

P

## PUSH-BUTTON IGNITION SWITCH POSITION INDICATOR

< DTC/CIRCUIT DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

2. Check continuity between BCM harness connector and push-button ignition switch harness connector.

Indicator	BCM		Push-button ignition switch		Continuity
	Connector	Terminal	Connector	Terminal	
LOCK	M123	91	M50	5	Existed
ACC		109		6	
ON		73		7	

3. Check continuity between BCM harness connector and ground.

Indicator	BCM		Ground	Continuity
	Connector	Terminal		
LOCK	M123	91	Ground	Not existed
ACC		109		
ON		73		

Is the inspection normal?

- YES >> Replace push-button ignition switch.  
NO >> Repair or replace harness.



# PUSH-BUTTON IGNITION SWITCH DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## SYMPTOM DIAGNOSIS

### PUSH-BUTTON IGNITION SWITCH DOES NOT OPERATE

#### Description

INFOID:0000000012352441

Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.

#### NOTE:

The engine start function, door lock function, power distribution system, and NATS-IVIS/NVIS in the Intelligent Key system are closely related to each other regarding control. The vehicle security function can operate only when the door lock and power distribution system are operating normally.

#### Conditions of Vehicle (Operating Conditions)

- “ENGINE START BY I-KEY” in “WORK SUPPORT” is ON when setting on CONSULT.
- One or more of Intelligent Keys with registered Intelligent Key ID is in the vehicle.

#### Diagnosis Procedure

INFOID:0000000012352442

#### 1.PERFORM WORK SUPPORT

Perform “INSIDE ANT DIAGNOSIS” on Work Support of “INTELLIGENT KEY”.  
Refer to [DLK-36, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

>> GO TO 2.

#### 2.PERFORM SELF-DIAGNOSIS RESULT

Perform Self-Diagnosis Result of “BCM”.

##### Is DTC detected?

- YES >> Refer to [BCS-59, "DTC Index"](#).  
NO >> GO TO 3.

#### 3.CHECK PUSH-BUTTON IGNITION SWITCH

Check push-button ignition switch.

Refer to [PCS-76, "Component Function Check"](#).

##### Is the operation normal?

- YES >> GO TO 4.  
NO >> Repair or replace malfunctioning parts.

#### 4.CONFIRM THE OPERATION

Confirm the operation again.

##### Is the inspection normal?

- YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).  
NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
N  
O  
P

PCS

# PUSH-BUTTON IGNITION SWITCH POSITION INDICATOR DOES NOT ILLUMINATE

< SYMPTOM DIAGNOSIS >

[POWER DISTRIBUTION SYSTEM]

## PUSH-BUTTON IGNITION SWITCH POSITION INDICATOR DOES NOT ILLUMINATE

### Description

INFOID:0000000012352443

- Before performing the diagnosis in the following table, check “Work Flow”. Refer to [PCS-57, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.

#### Conditions of Vehicle (Operating Conditions)

- “ENGINE START BY I-KEY” in “WORK SUPPORT” is ON when setting on CONSULT.
- One or more of Intelligent Keys with registered Intelligent Key ID is in the vehicle.

### Diagnosis Procedure

INFOID:0000000012352444

#### 1. CHECK PUSH-BUTTON IGNITION SWITCH INDICATOR

Check push-button ignition switch indicator.

Refer to [PCS-79, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

# PUSH-BUTTON IGNITION SWITCH

< REMOVAL AND INSTALLATION >

[POWER DISTRIBUTION SYSTEM]

## REMOVAL AND INSTALLATION

### PUSH-BUTTON IGNITION SWITCH

#### Exploded View

INFOID:0000000012352445


Refer to [IP-12, "Exploded View"](#).


#### Removal and Installation

INFOID:0000000012352446


#### REMOVAL


1. Remove front body side welt. Refer to [INT-45, "BODY SIDE WELT : Removal and Installation"](#).
2. Remove instrument side finisher LH. Refer to [IP-13, "Removal and Installation"](#).
3. Remove instrument lower panel LH. Refer to [IP-13, "Removal and Installation"](#).
4. Disconnect NATS antenna amp. connector and push-button ignition switch connector.
5. Disengage the NATS antenna amp. fixing pawls while pushing NATS antenna amp. from its back side, so that NATS antenna amp. and push-button ignition switch are lifted up from instrument panel assembly.

 : Pawl



6. While pushing the push-button ignition switch from its back side, disengage the push-button ignition switch fixing pawls using a minus driver etc., and then remove push-button ignition switch.

 : Pawl



#### INSTALLATION

Install in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
PCS  
N  
O  
P