

SECTION **BT**

CONTENTS

PRECAUTIONS	2	FRONT SEAT	29	GI
Service Notice.....	2	Removal and Installation	29	MA
Supplemental Restraint System (SRS) "AIR BAG"	2	POWER SEAT.....	29	EM
CLIP AND FASTENER	3	MANUAL SEAT.....	30	LC
Description	3	HEATED SEAT.....	31	EC
BODY FRONT END	5	REAR SEAT	32	FE
Removal and Installation	5	Removal and Installation	32	AT
FRONT BUMPER ASSEMBLY	5	SUNROOF	33	TF
BODY REAR END AND OPENER	8	Adjustment.....	33	PD
Removal and Installation	8	Removal and Installation	34	AX
REAR BUMPER ASSEMBLY	8	Trouble Diagnoses.....	37	SU
FRONT DOOR	11	DIAGNOSTIC TABLE.....	37	BR
Overhaul	11	WIND DEFLECTOR	37	ST
REAR DOOR	12	ADJUSTMENT.....	38	RS
Overhaul	12	DRAIN HOSES	39	BT
INSTRUMENT PANEL ASSEMBLY	13	WEATHERSTRIP.....	39	HA
Removal and Installation	13	LINK AND WIRE ASSEMBLY.....	40	SC
SIDE AND FLOOR TRIM	17	WINDSHIELD AND WINDOWS	41	EL
Removal and Installation	17	Removal and Installation	41	IDX
DOOR TRIM	19	REMOVAL.....	41	
Removal and Installation	19	INSTALLATION.....	41	
ROOF TRIM	20	WINDSHIELD	42	
Removal and Installation	20	REAR SIDE WINDOW.....	43	
BACK DOOR TRIM	21	DOOR MIRROR	44	
Removal and Installation	21	Removal and Installation	44	
EXTERIOR	22	BODY (ALIGNMENT)	45	
Removal and Installation	22	Alignment	45	
		ENGINE COMPARTMENT.....	46	
		UNDERBODY.....	48	

PRECAUTIONS

Service Notice

Service Notice

NBBT0001

- When removing or installing various parts, place a cloth or padding onto the vehicle body to prevent scratches.
- Handle trim, molding, instruments, grille, etc. carefully during removing or installing. Be careful not to soil or damage them.
- Apply sealing compound where necessary when installing parts.
- When applying sealing compound, be careful that the sealing compound does not protrude from parts.
- When replacing any metal parts (for example body outer panel, members, etc.), be sure to take rust prevention measures.

Supplemental Restraint System (SRS) "AIR BAG"

NBBT0002

The Supplemental Restraint System "AIR BAG", used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger in a frontal collision. The Supplemental Restraint System consists of air bag modules (located in the center of the steering wheel and on the instrument panel on the passenger side), a diagnosis sensor unit, warning lamp, wiring harness and spiral cable. Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:
















- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system.**
- **Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses are covered with yellow insulation either just before the harness connectors or for the complete harness, for easy identification.**

CLIP AND FASTENER

Description

NBB10003

- Clips and fasteners in BT section correspond to the following numbers and symbols.
- Replace any clips and/or fasteners which are damaged during removal or installation.

Symbol No.	Shapes	Removal & Installation
<p>C101</p> 	 <p>SBF302H</p>	<p>Removal: Remove by bending up with flat-bladed screwdrivers or clip remover.</p>  <p>SBF367BA</p>
<p>C103</p> 	 <p>SBT095</p>	 <p>Removal: Remove with a clip remover.</p> <p>SBF423H</p>
<p>C203</p> 	 <p>SBF258G</p>	<p>Push center pin to catching position. (Do not remove center pin by hitting it.)</p>  <p>Installation:</p> <p>SBF708E</p>
<p>C205</p> 	 <p>MBT080A</p>	<p>Removal:</p>  <p>SBF638C</p>
<p>CE103</p> 	 <p>SBF104B</p>	<p>Removal:</p>  <p>SBF147B</p>

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

















SC

EL

IDX

CLIP AND FASTENER

Description (Cont'd)

Symbol No.	Shapes	Removal & Installation
<p>CE117</p> 	 <p style="text-align: right;">SBF174D</p>	<p>Removal: Remove with a flat-bladed screwdriver or pliers.</p>  <p style="text-align: right;">SBF175D</p>
<p>CF109</p> 	 <p style="text-align: right;">SBF651B</p>	<p>Removal:</p>  <p style="text-align: right;">SBF652B</p>
<p>CG101</p> 	 <p style="text-align: right;">SBF145B</p>	<p>Removal:</p>  <p>Rotate 45° to remove.</p> <hr/> <p>Installation:</p>  <p style="text-align: right;">SBF085B</p>
<p>CR103</p> 	 <p style="text-align: right;">SBF768B</p>	<p>Removal: Holder portion of clip must be spread out to remove rod.</p>  <p style="text-align: right;">SBF770B</p>
<p>CS101</p> 	 <p style="text-align: right;">SBF078B</p>	<p>Removal:</p> <ol style="list-style-type: none"> 1. Screw out with a Phillips screwdriver. 2. Remove female portion with flat-bladed screwdriver.  <p style="text-align: right;">SBF992G</p>

Removal and Installation








NBBT0004

- When removing or installing hood, place a cloth or other padding on front fender panel and cowl top. This prevents vehicle body from being scratched.
- Bumper fascia is made of plastic. Do not use excessive force and be sure to keep oil away from it.
- Hood adjustment: Adjust at hinge portion.
- Hood lock adjustment: After adjusting, check hood lock control operation. Apply a coat of grease to hood locks engaging mechanism.
- Hood opener: Do not attempt to bend cable forcibly. Doing so increases effort required to unlock hood.

FRONT BUMPER ASSEMBLY

NBBT0004S01

1. Remove screws and clips securing left and right sides of front fender protector. **B**
2. Remove clips securing bumper fascia to radiator core support lower. **C**
3. Remove bolts securing left and right clearance lamps and remove the lamps. **D**
4. Remove clips securing radiator grille and remove the radiator grille.
5. Remove bolts securing left and right turn signal lamps and remove the lamps. **E**
6. Remove bolts securing left and right fog lamps and remove the lamps. **F**
7. Remove bolts securing left and right radiator grille and remove the radiator grilles. **G**
8. Remove bolts securing license plate bracket and remove the license plate bracket. **H**
9. Remove clips securing bumper fascia to bumper reinforcement. **I**
10. Remove bolts securing front fender to bumper fascia. **J**
11. Extract bumper fascia assembly. **K**
12. Remove bolts and nuts securing bumper reinforcement. **L**
13. Extract bumper reinforcement.



★ : Bumper assembly mounting clips.

G : N·m (kg·m, ft·lb)

SBT346

BODY FRONT END

Removal and Installation (Cont'd)


SEC. 260•261•262•263•620•623•630•650

Hood lock adjustment

- Adjust hood so that hood primary lock meshes at a position 1 to 1.5 mm (0.039 to 0.059 in) lower than fender.
- After hood lock adjustment, adjust bumper rubber.
- When securing hood lock, ensure it does not tilt. Striker must be positioned at the center of hood primary lock.
- After adjustment, ensure that hood primary and secondary lock operate properly.

Hood lock secondary latch hooking length


More than 5.0 mm (0.197 in)



Bumper rubber adjustment

- Adjust so that hood is aligned with fender. At that time deflection is approx. 2 mm (0.08 in).








[Bumper rubber free height is approx. 13 mm (0.51 in)]



SBT347

BODY FRONT END

Removal and Installation (Cont'd)



★ : Bumper assembly mounting clips, bolts and nuts.

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SBT486

BODY REAR END AND OPENER

Removal and Installation

Removal and Installation

NBBT0005

- Bumper fascia is made of plastic. Do not use excessive force and be sure to keep oil away from it.
- Back door lock system adjustment: Adjust lock & striker so that they are in the center. After adjustment, check back door lock operation.
- Back door hatch lock system adjustment: Adjust lock & striker so that they are in the center. After adjustment, check back door hatch lock operation.
- Opener cable: Do not attempt to bend cable using excessive force.
- After installation, make sure that back door and fuel filler lid open smoothly.








WARNING:

- Be careful not to scratch back door stay and/or back door hatch stay when installing back door and/or back door hatch. A scratched stay may cause gas leakage.
- The contents of the back door stay and back door hatch stay are under pressure. Do not take apart, puncture, apply heat or allow fire near them.

REAR BUMPER ASSEMBLY

NBBT0005S01

1. Remove bolts and screws securing left and right mudguards and remove the mudguards. **K**
2. Remove clips and screws securing left and right sides of wheel protector. **L**
3. Remove clips and bolts securing left and right rear fenders to bumper fascia. **M**
4. Remove bolts securing bumper reinforcement to bumper fascia. **N**
5. Remove clips securing bumper fascia. **O**
6. Extract bumper fascia assembly. **P**
7. Remove bolts and nuts securing bumper reinforcement. **Q**
8. Extract bumper reinforcement.



K : N·m (kg-m, in-lb)
L : N·m (kg-m, ft-lb)

SBT349

BODY REAR END AND OPENER

Removal and Installation (Cont'd)

SEC. 570•767•850•900•905

GI

MA

EM

IC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS


BT

HA

SC

EL











IDX



SBT350

BODY REAR END AND OPENER

Removal and Installation (Cont'd)




- ★ : Bumper assembly mounting bolts, nuts and clips.
- : N·m (kg-m, in-lb)
- : N·m (kg-m, ft-lb)

SBT351

Overhaul

- For removal of door trim, refer to "DOOR TRIM" (BT-19).
- After adjusting door or door lock, check door lock operation.

SEC. 800•803•805•998



A Bell crank adjustment

Bell crank

Lock knob

Lock door after setting door lock assembly and inside handle in position. Move bell crank in direction of arrow (shown in figure at left) to take up knob free play, and secure with bolts.

B Door-hinge adjustment

30 - 41 (3.1 - 4.2, 22 - 30)

Striker adjustment

13 - 16 (1.3 - 1.6, 9 - 12)

⊗ : N•m (kg•m, in•lb)
⊕ : N•m (kg•m, ft•lb)

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


REAR DOOR

Overhaul

Overhaul



NBBT0007

SEC. 820•823•825




A Outside handle adjustment


Turn holder until the clearance between holder & rod is the specified value.



B Door-hinge adjustment



Striker adjustment



: N·m (kg-m, in-lb)

: N·m (kg-m, ft-lb)

SBT203

Removal and Installation

NBBT0008

CAUTION:

- Disconnect both battery cables in advance.
- Disconnect air bag system line in advance.
- Never tamper with or force air bag lid open, as this may adversely affect air bag performance.
- Be careful not to scratch pad and other parts.

Instrument panel assembly	Combination meter	Audio & A/C control	Console box
Remove air bag module (driver) and steering wheel. Refer to "SUPPLEMENTAL RESTRAINT SYSTEM" in RS section for details.			
1 Steering column cover and combination switch • Remove screws.			
2 Dash side lower finisher • Refer to "SIDE AND FLOOR TRIM" for details, *1.			
3 Instrument lower panel on driver side • Remove screws then disconnect harness connectors.			
4 Cluster lid A • Remove screws.			
5 Combination meter • Remove screws then disconnect harness connectors.			
6 Cluster lid C • Remove screws then disconnect harness connectors.			
7 Audio assembly • Remove screws.			
8 A/C control unit • Remove screws then disconnect harness connectors and cable.			
9 Ashtray • Pull the ashtray up.			
10 A/T shifter or M/T shift lever boots • Remove screw then disconnect harness connector.			
11 Console box • Remove screw then disconnect harness connector.			
12 Glove box • Remove clips. • Then disconnect passenger air bag module connector.			



*1 BT-17

SBT513

GI
 MA
 EM
 LC
 EC
 FE
 AT
 TF
 PD
 AX
 SU
 BR
 ST
 RS
BT
 HA
 SC
 EL
 IDX

INSTRUMENT PANEL ASSEMBLY

Removal and Installation (Cont'd)

Ⓐ

13 Instrument lower panel on passenger side

- Remove screws then disconnect harness connector.
- Then remove passenger air bag module bracket. Refer to "SUPPLEMENTAL RESTRAINT SYSTEM" in RS section for details.

14 Instrument lower center panel

- Remove screws.

15 Defroster grille

16 Front pillar garnish

- Refer to "SIDE AND FLOOR TRIM" for details, *1.

17 Instrument panel and pads

- Remove bolts and nuts.

18 Passenger air bag module

- Remove air duct.
- Refer to "SUPPLEMENTAL RESTRAINT SYSTEM" in RS section for details.


SBT514

*1 BT-17

INSTRUMENT PANEL ASSEMBLY

Removal and Installation (Cont'd)

SEC. 248•272•280•487•680•685•969




★ : Instrument panel assembly mounting bolts & nuts

GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SBT204-A

INSTRUMENT PANEL ASSEMBLY

Removal and Installation (Cont'd)



SBT205

Removal and Installation


NBBT0009

CAUTION:

Wrap the tip of flat-bladed screwdriver with a cloth when removing metal clips from garnishes.

1. Remove front and rear seats. Refer to "FRONT SEAT" and "REAR SEAT" for details, BT-29, BT-32.
2. Remove front and rear kicking plates.
3. Remove dash side lower finishers.
4. Remove front and rear body side welts.
5. Remove front pillar garnishes.
6. Remove center assist grips.
7. Remove center pillar lower garnishes.
8. Remove center pillar upper garnishes.
9. Remove rear gate kicking plate.
10. Remove rear parcel shelf hook assembly and hook.
11. Remove tonneau cover assembly and rear parcel holder.
12. Remove rear side lower garnishes.
13. Remove rear side upper garnishes.

SEC. 678•738•769•799•849








SBT206

CI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SIDE AND FLOOR TRIM

Removal and Installation (Cont'd)





SBT222

Removal and Installation

NBBT0010

1. Remove inside handle escutcheon.
2. Remove door armrest. (Front door only)
3. Remove power window switches, then disconnect the connectors.
4. Remove door finisher cover. (Rear door only)
5. Remove bolts securing door finisher.
6. Remove clips securing door finisher.
7. Lift out door finisher.

SEC. 251•809•828



SBT353

CI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

ROOF TRIM




Removal and Installation

Removal and Installation

NBB70011

1. Remove front and rear seats. Refer to "FRONT SEAT" and "REAR SEAT" for details, BT-29, BT-32.
2. Remove front and rear seat belts. Refer to "SEAT BELTS" in RS section for details.
3. Remove body side trim. Refer to "SIDE AND FLOOR TRIM" for details, BT-17.
4. Remove roof console assembly.
5. Remove inside mirror assembly.
6. Remove sun visors.
7. Remove interior lamp assembly and luggage room lamp assembly.
8. Remove assist grips.
9. Remove clips securing headlining.
10. Remove rear roof garnish.
11. Remove headlining from vehicle through either back door.

SEC. 264•738•963•964•970




SBT487

Removal and Installation

NBBT0012

1. Remove back door grip.
2. Remove back door finisher assembly.
3. Remove high-mounted stop lamp.
4. Remove back door upper finisher assembly.

SEC. 268•909



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX


SBT223

Removal and Installation


NBBT0013



① ② Hood front seal



③ ④ Cowl top seal and cowl top grille



⑤ Windshield side molding



Mounted with screws.

SBT494

⑥ Windshield upper molding

SEC. 720


1. Cut off urethane adhesive at glass end.
2. Remove old urethane adhesive from panel surface.
3. Set molding fastener and apply primer to body panel, and apply urethane adhesive to body.



4. Install molding by aligning the molding mark located on center with vehicle center. Be sure to install tightly so that there is no gap around the corner.


⑦ Sunroof lid weatherstrip

SEC. 736




⑧ Drip weatherstrip

SEC. 767




⑨ Body side welt

SEC. 769



⑩ Door weatherstrip

SEC. 800-820




GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SBT489


EXTERIOR

Removal and Installation (Cont'd)


⑪ Door outside molding



⑬ Side guard molding




⑫ Back door weatherstrip




- With a vehicle coated with Hard Clear Coat, use double-faced 3M adhesive tape Product No. 4210 or equivalent, after priming with 3M primer Product No. N-200 or C-100 or equivalent.

⑭ Back door window weatherstrip




SBT495

15 Air outlet grille




16 High-mounted stop lamp



17 Back door deflector

- When installing, make sure that there are not gaps or waves at ends of deflector.
- Before installing deflector, clean and remove oil from surface where deflector will be mounted.



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


SBT491

EXTERIOR

Removal and Installation (Cont'd)


18 Roof rack

SEC. 730



19 Side step

SEC. 767



SBT496


20 2nd side window molding

Refer to the applicable sections on the preceding pages.


21 Rear combination lamp

Rear combination lamps are installed with nuts.

22 Over fender



23 License plate finisher



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

SBT497

④ Back door molding



- With a vehicle coated with Hard Clear Coat, use double-faced 3M adhesive tape Product No. 4210 or equivalent, after priming with 3M primer Product No. N-200 or C-100 or equivalent.

FRONT SEAT

Removal and Installation

Removal and Installation

- When removing or installing the seat trim, carefully handle it to keep dirt out and avoid damage.
- ★ For Wiring Diagram, refer to "POWER SEAT" in EL section.

NBBT0014

POWER SEAT

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

SEC. 870

NBBT0014S01



\square : N•m (kg-m, ft-lb)

SBT188


FRONT SEAT

Removal and Installation (Cont'd)

MANUAL SEAT

NBBT0014S02

SEC. 870



: N•m (kg-m, ft-lb)

SBT189

BT-30


FRONT SEAT

Removal and Installation (Cont'd)

HEATED SEAT

-NBB70014503

- When handling seat, be extremely careful not to scratch heating unit.
- To replace heating unit, seat trim and pad should be separated.
- Do not use any organic solvent, such as thinner, benzene, alcohol, gasoline, etc. to clean trims.



SBF424H

★ For Wiring Diagram, refer to "HEATED SEAT" in EL section.

CI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX




REAR SEAT

Removal and Installation

Removal and Installation

NBBT0015

SEC. 870



- : N·m (kg-m, in-lb)
- : N·m (kg-m, ft-lb)

SBT190


BT-32

Adjustment

NBBT0016

Install motor & limit SW assembly and sunroof rail assembly in the following sequence:

1. Arrange equal lengths of link and wire assemblies on both sides of sunroof opening.
2. Connect sunroof connector to sunroof switch and positive (+) power supply.
3. Set lid assembly to fully closed position **A** by operating OPEN switch and TILT switch.
4. Fit outer side of lid assembly to the surface of roof on body outer panel.
5. Remove motor, and keep OPEN switch pressed until motor pinion gear reaches the end of its rotating range.
6. Install motor.
7. Check that motor drive gear fits properly in wires.
8. Press TILT-UP switch to check lid assembly for normal tilting.
9. Check sunroof lid assembly for normal operations (tilt-up, tilt-down, open, and close).



SBF920F

GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SUNROOF

Removal and Installation


Removal and Installation

=NBT0017

- After any adjustment, check sunroof operation and lid alignment.
- Handle finisher plate and glass lid with care so not to cause damage.
- It is desirable for easy installation to mark each point before removal.

CAUTION:

Always work with a helper.



★ For Wiring Diagram, refer to "POWER SUNROOF" in EL section.


SBT515

*1 BT-20

SUNROOF

Removal and Installation (Cont'd)

SEC. 736




GI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


MBF462BG

SUNROOF


Removal and Installation (Cont'd)




A Using flat-bladed screwdriver, pry shade assembly holder off rail. Then pull shade assembly forward to remove it from rail.



B1 Disengage pawls from rail, then remove wind deflector holder.



B2 Using flat-bladed screwdriver, pry stopper spring off rail groove. Then slide rear guide backward to remove it from rail.



B3 Remove wire and link assembly from rail while pushing link back with flat-bladed screwdriver.

Trouble Diagnoses DIAGNOSTIC TABLE

=NBBT0018


NBBT0018S01

NOTE:

For diagnosing electric problem, refer to "POWER SUNROOF" in EL section.

	Reference page	Check items (Components)				
		Wind deflector	Adjustment	Drain hoses	Weatherstrip	Link and wire assembly
		BT-37	BT-38	BT-39	BT-39	BT-40
Symptom	Excessive wind noise	1	2		3	
	Water leaks		1	2	3	
	Sunroof rattles		1	4	2	3
	Excessive operation noise		1		2	3


The numbers in this table mean checking order.



WIND DEFLECTOR

NBBT0018S02

1. Open lid.
2. Check visually for proper installation.
3. Check to ensure a proper amount of petroleum jelly has been applied to wind deflector connection points; apply if necessary.
4. Check that wind deflector is properly retracted by hand. If it is not, remove and visually check condition. (Refer to removal procedures, BT-34.) If wind deflector is damaged, replace with new one. If wind deflector is not damaged, re-install properly.



CI
MA
EM
LC
EC
FE
AT
TF
PD
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



SUNROOF

Trouble Diagnoses (Cont'd)

ADJUSTMENT

NBBT0018S03

SEC. 736



If any gap or height difference between glass lid and roof is found, check glass lid fit and adjust as follows:

Gap Adjustment

NBBT0018S0301

1. Open shade assembly.
2. Tilt glass lid up then remove side trim.
3. Loosen glass lid securing nuts (3 each on left and right sides), then tilt glass lid down.
4. Adjust glass lid from outside of vehicle so it resembles "A-A" as shown in the figure above.
5. Tilt glass lid up and down until it is adjusted to "B-B" as shown in the figure above.
6. After adjusting glass lid, tilt glass lid up and tighten nuts.
7. Tilt glass lid up and down several times to check that it moves smoothly.

Height Difference Adjustment

NBBT0018S0302


1. Tilt glass lid up and down.
2. Check height difference between roof panel and glass lid to see if it is as "A-A" as shown in the figure above.
3. If necessary, adjust it by using one of following procedures.
 - Adjust by adding or removing adjustment shim(s) between glass lid and link assembly.
 - If glass lid protrudes above roof panel, add shim(s) or plain washer(s) at sunroof mounting bracket or stud bolt locations to adjust sunroof installation as required.

SUNROOF

Trouble Diagnoses (Cont'd)

DRAIN HOSES

NBBT0018S04



GI

MA

EM


LC

EC

FE

AT

TF




PD

AX

SU

BR



ST

RS

BT

HA

1. Remove headlining to access drain hose connections. (Refer to "Removal and Installation" in "ROOF TRIM", BT-20, for detail.)

2. Check visually for proper connections, damage or deterioration. **A** (The figure shows only the front side.)

3. If leakage occurs around luggage room, remove luggage room side trim and check connecting area. Check for proper connection, damage or tear. **B**

4. Remove drain hoses and check visually for any damage, cracks, or deterioration.

5. Pour water into drain hoses and find damaged portion.

- If any damaged portion is found at each step, replace the damaged part.

SC

EL

IDX

WEATHERSTRIP

NBBT0018S05

- In the case of leakage around glass lid, close glass lid and pour water over glass lid to find damaged or gap portion.

1. Remove glass lid assembly. (Refer to removal procedures, BT-34, for details.)

2. Visually check weatherstrip for proper installation. If a gap exists between glass lid and weatherstrip, check for sufficient amount of butyl seal. If required, remove weatherstrip and apply butyl seal.

Refer to "EXTERIOR" (BT-22), for details.

SUNROOF

Trouble Diagnoses (Cont'd)

3. Check weatherstrip visually for any damage, deterioration, or flattening.
 - If any damage is found, replace weatherstrip.

CAUTION:

Do not remove weatherstrip except when replacing, or filling up butyl seal.




LINK AND WIRE ASSEMBLY

NBBT0018S06

NOTE:

Before replacing a suspect part, carefully ensure it is the source of noise being experienced.

1. Check link to determine if coating film has peeled off to such an extent that substrate is visible. Check also to determine if link is the source of noise. If it is, replace it.
2. Visually check to determine if a sufficient amount of petroleum jelly has been applied to wire or rail groove. If not, add petroleum jelly as required.
3. Check wire for any damage or deterioration. If any damage is found, remove rear guide (refer to removal procedures, BT-34 for details), then replace wire.



Removal and Installation

REMOVAL

After removing moldings, remove glass using piano wire or power cutting tool and an inflatable pump bag.

WARNING:

When cutting the glass from the vehicle, always wear safety glasses and heavy gloves to help prevent glass splinters from entering your eyes or cutting your hands.

CAUTION:

- Be careful not to scratch the glass when removing.
- Do not set or stand the glass on its edge. Small chips may develop into cracks.

INSTALLATION

- Use a genuine Nissan Urethane Adhesive Kit or equivalent and follow the instructions furnished with it.
- While the urethane adhesive is curing, open a door window. This will prevent the glass from being forced out by passenger compartment air pressure when a door is closed.
- The molding must be installed securely so that it is in position and leaves no gap.
- Inform the customer that the vehicle should remain stationary until the urethane adhesive has completely cured (preferably 24 hours). Curing time varies with temperature and humidity.

WARNING:

- Keep heat and open flames away as primers and adhesive are flammable.
- The materials contained in the kit are harmful if swallowed, and may irritate skin and eyes. Avoid contact with the skin and eyes.
- Use in an open, well ventilated location. Avoid breathing the vapors. They can be harmful if inhaled. If affected by vapor inhalation, immediately move to an area with fresh air.
- Driving the vehicle before the urethane adhesive has completely cured may affect the performance of the windshield in case of an accident.

CAUTION:

- Do not use an adhesive which is past its usable term. Shelf life of this product is limited to six months after the date of manufacture. Carefully adhere to the expiration or manufacture date printed on the box.
- Keep primers and adhesive in a cool, dry place. Ideally, they should be stored in a refrigerator.
- Do not leave primers or adhesive cartridge unattended with their caps open or off.
- The vehicle should not be driven for at least 24 hours or until the urethane adhesive has completely cured. Curing time varies depending on temperature and humidities. The curing time will increase under higher temperatures and lower humidities.

NBBT0019

NBBT0019S01

NBBT0019S02

GI

VA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL





IDX

WINDSHIELD AND WINDOWS

Removal and Installation (Cont'd)

WINDSHIELD

NBBT0019S03

<p>Body side Install spacer to panel.</p> 	<p>Glass side Install open cell foam dam.</p> 
<p>Install molding fastener. When installing it, heat body panel and fastener to approx. 30 to 40°C (86 to 104°F).</p> 	<p>Apply urethane adhesive evenly. Windshield</p>  <p>Unit: mm (in)</p>

SBT191-A

Repairing Water Leaks for Windshield

NBBT0019S0301

Leaks can be repaired without removing and reinstalling glass. **If water is leaking between the urethane adhesive material and body or glass, determine the extent of leakage. This can be done by applying water to the windshield area while pushing glass outward.**

To stop the leak, apply primer (if necessary) and then urethane adhesive to the leak point.





WINDSHIELD AND WINDOWS

Removal and Installation (Cont'd)

REAR SIDE WINDOW

NBBT0019S04

SEC. 830



CI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SBT359-A

BT-43

DOOR MIRROR

Removal and Installation

Removal and Installation

NBBT0020


CAUTION:

Be careful not to scratch door rearview mirror body.

★ For Wiring Diagram, refer to "POWER DOOR MIRROR" in EL section.

1. Remove door trim. Refer to "DOOR TRIM" for details, BT-19.
2. Remove clip securing inner cover from front corner of door.
3. Disconnect door mirror harness connector and clip.
4. Remove bolts securing door mirror, then remove door mirror assembly.

SEC. 963



SBT193


BODY ALIGNMENT

Alignment

Alignment

NBBT0021

- All dimensions indicated in figures are actual ones.
- When using a tracking gauge, adjust both pointers to equal length. Then check the pointers and gauge itself to make sure there is no free play.
- When a measuring tape is used, check to be sure there is no elongation, twisting or bending.
- Measurements should be taken at the center of the mounting holes.
- An asterisk (★) following the value at the measuring point indicates that the measuring point on the other side is symmetrically the same value.
- The coordinates of the measurement points are the distances measured from the standard line of "X", "Y" and "Z".



Gi

MA

EM

LC

EC

FE

AT

TF

PD

AX

SBF874GD

SU

BR

ST

RS

BT

HA

SC

EL

IDX

BODY (ALIGNMENT)


Alignment (Cont'd)

ENGINE COMPARTMENT

Measurement

NBBT0021S01

NBBT0021S0101



SBT194









BODY (ALIGNMENT)

Alignment (Cont'd)

Measurement Points

NBBT0021S0102

Unit: mm



GI

MA

EM

LC

EC

FE

AT

TF

PD

AX

SU

BR

ST

RS

BT

HA

SC

EL

DX

SBT195


BODY (ALIGNMENT)

Alignment (Cont'd)

UNDERBODY Measurement

NBBT0021S02

NBBT0021S0201




SBT360

BODY (ALIGNMENT)

Alignment (Cont'd)

NBB70021S0202

Measurement Points



Front coordinates:

(A, a)
X: 266
Y: -580.4
Z: 191.4

(B, b)
X: 403
Y: -500
Z: 297.7

(C, c)
X: 396
Y: -201
Z: 279.7

(D, d)
X: 396
Y: 228
Z: 156.7

(E, e)
X: 524
Y: 568
Z: 112.7

(F, f)
X: 489
Y: 637
Z: 114.1

Rear coordinates:

(G, g)
X: 565
Y: 1,630
Z: 115

(H, h)
X: 476.9
Y: 2,392.6
Z: 321.9

(K, k)
X: 513.3
Y: 2,434.5
Z: 301.4

(M)
X: 446.1
Y: 2,960.2
Z: 190

(m)
X: 350
Y: 2,878
Z: 424.8

(N, n)
X: 430
Y: 3,100
Z: 426.2

(P)
X: 290
Y: 3,230
Z: 394.1


(Q, q)
X: 142
Y: 3,230
Z: 383.6

(R, r)
X: 277
Y: 3,570
Z: 435.6

Unit: mm

Front strut tower center coordinates:

(S, s)
X: 499.9
Y: 41.2
Z: 748.9



- GI
- MA
- EM
- LC
- EC
- FE
- AT
- TF
- PD
- AX
- SU
- BR
- ST
- RS
- BT**
- HA
- SC
- EL
- IDX

SBT361