

SECTION **DLN**  
DRIVELINE

A  
B  
C

DLN

CONTENTS

E

<b>TRANSFER: ETX13C</b>		<b>AWD CONTROL UNIT</b> .....	<b>19</b>	F
<b>PRECAUTION</b> .....	<b>6</b>	Reference Value .....	19	
<b>PRECAUTIONS</b> .....	<b>6</b>	Fail-safe .....	20	G
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	6	Protection Function .....	21	
Service Notice or Precautions for Transfer .....	6	DTC Inspection Priority Chart .....	21	
<b>PREPARATION</b> .....	<b>7</b>	DTC Index .....	21	H
<b>PREPARATION</b> .....	<b>7</b>	<b>WIRING DIAGRAM</b> .....	<b>22</b>	
Special Service Tools .....	7	<b>AWD SYSTEM</b> .....	<b>22</b>	I
Commercial Service Tools .....	8	Wiring Diagram .....	22	
<b>SYSTEM DESCRIPTION</b> .....	<b>10</b>	<b>BASIC INSPECTION</b> .....	<b>27</b>	J
<b>COMPONENT PARTS</b> .....	<b>10</b>	<b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....	<b>27</b>	
Component Parts Location .....	10	Work Flow .....	27	K
Component Description .....	10	Diagnostic Work Sheet .....	28	
AWD Control Unit .....	11	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	<b>30</b>	L
AWD Solenoid .....	11	<b>C1201 AWD CONTROL UNIT</b> .....	<b>30</b>	
Transfer Fluid Temperature Sensor .....	11	DTC Logic .....	30	M
Electric Controlled Coupling .....	11	Diagnosis Procedure .....	30	
<b>STRUCTURE AND OPERATION</b> .....	<b>12</b>	<b>C1203 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)</b> .....	<b>31</b>	N
Sectional View .....	12	DTC Logic .....	31	
Operation Description .....	12	Diagnosis Procedure .....	31	O
<b>SYSTEM</b> .....	<b>14</b>	<b>C1204 AWD SOLENOID</b> .....	<b>32</b>	
<b>AWD SYSTEM</b> .....	<b>14</b>	DTC Logic .....	32	P
AWD SYSTEM : System Description .....	14	Diagnosis Procedure .....	32	
AWD SYSTEM : Fail-safe .....	15	Component Inspection .....	34	
AWD SYSTEM : Protection Function .....	15	<b>C1205 AWD ACTUATOR RELAY</b> .....	<b>35</b>	
<b>DIAGNOSIS SYSTEM (AWD CONTROL UNIT)</b> .....	<b>17</b>	DTC Logic .....	35	
CONSULT Function .....	17	Diagnosis Procedure .....	35	
<b>ECU DIAGNOSIS INFORMATION</b> .....	<b>19</b>	<b>C1210 ECM</b> .....	<b>37</b>	
		DTC Logic .....	37	
		Diagnosis Procedure .....	37	
		<b>P1804 TRANSFER CONTROL UNIT</b> .....	<b>38</b>	

DTC Logic .....	38	<b>TRANSFER FLUID .....</b>	<b>56</b>
Diagnosis Procedure .....	38	Inspection .....	56
<b>P1809 TRANSFER CONTROL UNIT .....</b>	<b>39</b>	Draining .....	56
DTC Logic .....	39	Refilling .....	56
Diagnosis Procedure .....	39	<b>REMOVAL AND INSTALLATION .....</b>	<b>57</b>
<b>P1826 TRANSFER FLUID TEMPERATURE ...</b>	<b>40</b>	<b>AWD CONTROL UNIT .....</b>	<b>57</b>
DTC Logic .....	40	Removal and Installation .....	57
Diagnosis Procedure .....	40	<b>FRONT OIL SEAL .....</b>	<b>58</b>
Component Inspection .....	41	Exploded View .....	58
<b>U1000 CAN COMM CIRCUIT .....</b>	<b>43</b>	Removal and Installation .....	58
Description .....	43	<b>REAR OIL SEAL .....</b>	<b>59</b>
DTC Logic .....	43	Exploded View .....	59
Diagnosis Procedure .....	43	Removal and Installation .....	59
<b>U1010 CONTROL UNIT (CAN) .....</b>	<b>44</b>	<b>UNIT REMOVAL AND INSTALLATION ....</b>	<b>62</b>
Description .....	44	<b>TRANSFER ASSEMBLY .....</b>	<b>62</b>
DTC Logic .....	44	Exploded View .....	62
Diagnosis Procedure .....	44	Removal and Installation .....	62
<b>POWER SUPPLY AND GROUND CIRCUIT ....</b>	<b>45</b>	<b>UNIT DISASSEMBLY AND ASSEMBLY ...</b>	<b>64</b>
Diagnosis Procedure .....	45	<b>FRONT CASE AND REAR CASE .....</b>	<b>64</b>
<b>AWD WARNING LAMP .....</b>	<b>48</b>	Exploded View .....	64
Component Function Check .....	48	Disassembly .....	65
Diagnosis Procedure .....	48	Assembly .....	68
<b>SYMPTOM DIAGNOSIS .....</b>	<b>49</b>	Inspection .....	72
<b>AWD WARNING LAMP DOES NOT TURN ON</b>	<b>... 49</b>	<b>MAIN SHAFT .....</b>	<b>74</b>
Description .....	49	Exploded View .....	74
Diagnosis Procedure .....	49	Disassembly .....	75
<b>AWD WARNING LAMP DOES NOT TURN</b>	<b>OFF .....</b>	Assembly .....	76
Description .....	50	Inspection .....	77
Description .....	50	<b>FRONT DRIVE SHAFT AND DRIVE CHAIN ....</b>	<b>79</b>
<b>HEAVY TIGHT-CORNER BRAKING SYMP-</b>	<b>TOM OCCURS .....</b>	Exploded View .....	79
Description .....	51	Disassembly .....	80
Diagnosis Procedure .....	51	Assembly .....	80
<b>VEHICLE DOES NOT ENTER AWD MODE ....</b>	<b>52</b>	Inspection .....	81
Description .....	52	<b>SERVICE DATA AND SPECIFICATIONS</b>	<b>(SDS) .....</b>
Diagnosis Procedure .....	52	<b>SERVICE DATA AND SPECIFICATIONS</b>	<b>(SDS) .....</b>
<b>AWD WARNING LAMP BLINKS QUICKLY ....</b>	<b>53</b>	General Specifications .....	83
Description .....	53	<b>FRONT PROPELLER SHAFT: 2S56A</b>	
<b>AWD WARNING LAMP BLINKS SLOWLY ....</b>	<b>54</b>	<b>SYMPTOM DIAGNOSIS .....</b>	<b>84</b>
Description .....	54	<b>NOISE, VIBRATION AND HARSHNESS</b>	<b>(NVH) TROUBLESHOOTING .....</b>
Diagnosis Procedure .....	54	NVH Troubleshooting Chart .....	84
<b>NOISE, VIBRATION AND HARSHNESS</b>	<b>(NVH) TROUBLESHOOTING .....</b>	<b>PREPARATION .....</b>	<b>85</b>
NVH Troubleshooting Chart .....	55	<b>PREPARATION .....</b>	<b>85</b>
<b>PERIODIC MAINTENANCE .....</b>	<b>56</b>	Commercial Service Tools .....	85

<b>PERIODIC MAINTENANCE</b> .....	86	<b>PREPARATION</b> .....	101	A
<b>FRONT PROPELLER SHAFT</b> .....	86	<b>PREPARATION</b> .....	101	
Inspection .....	86	Commercial Service Tools .....	101	B
<b>REMOVAL AND INSTALLATION</b> .....	87	<b>PERIODIC MAINTENANCE</b> .....	102	
<b>FRONT PROPELLER SHAFT</b> .....	87	<b>REAR PROPELLER SHAFT</b> .....	102	C
Exploded View .....	87	Inspection .....	102	
Removal and Installation .....	87	<b>REMOVAL AND INSTALLATION</b> .....	103	
Inspection .....	88	<b>REAR PROPELLER SHAFT</b> .....	103	DLN
<b>SERVICE DATA AND SPECIFICATIONS</b>		Exploded View .....	103	
<b>(SDS)</b> .....	90	Removal and Installation .....	103	E
<b>SERVICE DATA AND SPECIFICATIONS</b>		Inspection .....	106	
<b>(SDS)</b> .....	90	<b>SERVICE DATA AND SPECIFICATIONS</b>		F
General Specifications .....	90	<b>(SDS)</b> .....	108	
Propeller Shaft Runout .....	90	<b>SERVICE DATA AND SPECIFICATIONS</b>		G
Journal Axial Play .....	90	<b>(SDS)</b> .....	108	
<b>REAR PROPELLER SHAFT: 3S80A-R</b>		General Specifications .....	108	
<b>SYMPTOM DIAGNOSIS</b> .....	91	Propeller Shaft Runout .....	108	H
<b>NOISE, VIBRATION AND HARSHNESS</b>		Journal Axial Play .....	108	
<b>(NVH) TROUBLESHOOTING</b> .....	91	<b>FRONT FINAL DRIVE: F160A</b>		
NVH Troubleshooting Chart .....	91	<b>SYSTEM DESCRIPTION</b> .....	109	I
<b>PREPARATION</b> .....	92	<b>FRONT FINAL DRIVE ASSEMBLY</b> .....	109	
<b>PREPARATION</b> .....	92	System Diagram .....	109	J
Commercial Service Tools .....	92	<b>SYMPTOM DIAGNOSIS</b> .....	110	
<b>PERIODIC MAINTENANCE</b> .....	93	<b>NOISE, VIBRATION AND HARSHNESS</b>		K
<b>REAR PROPELLER SHAFT</b> .....	93	<b>(NVH) TROUBLESHOOTING</b> .....	110	
Inspection .....	93	NVH Troubleshooting Chart .....	110	L
<b>REMOVAL AND INSTALLATION</b> .....	94	<b>PRECAUTION</b> .....	111	
<b>REAR PROPELLER SHAFT</b> .....	94	<b>PRECAUTIONS</b> .....	111	M
Exploded View .....	94	Service Notice or Precautions for Front Final Drive	..111	
Removal and Installation .....	94	<b>PREPARATION</b> .....	112	N
Inspection .....	97	<b>PREPARATION</b> .....	112	
<b>SERVICE DATA AND SPECIFICATIONS</b>		Special Service Tools .....	112	O
<b>(SDS)</b> .....	99	Commercial Service Tools .....	114	
<b>SERVICE DATA AND SPECIFICATIONS</b>		<b>PERIODIC MAINTENANCE</b> .....	115	P
<b>(SDS)</b> .....	99	<b>FRONT DIFFERENTIAL GEAR OIL</b> .....	115	
General Specifications .....	99	Inspection .....	115	
Propeller Shaft Runout .....	99	Draining .....	115	
Journal Axial Play .....	99	Refilling .....	115	
<b>REAR PROPELLER SHAFT: 3F80A-1VL107</b>		<b>REMOVAL AND INSTALLATION</b> .....	116	
<b>SYMPTOM DIAGNOSIS</b> .....	100	<b>SIDE OIL SEAL</b> .....	116	
<b>NOISE, VIBRATION AND HARSHNESS</b>		<b>RIGHT SIDE</b> .....	116	
<b>(NVH) TROUBLESHOOTING</b> .....	100			
NVH Troubleshooting Chart .....	100			

RIGHT SIDE : Exploded View .....	116	Service Notice or Precautions for Rear Final Drive.	151
RIGHT SIDE : Removal and Installation .....	116		
<b>LEFT SIDE .....</b>	<b>117</b>	<b>PREPARATION .....</b>	<b>152</b>
LEFT SIDE : Exploded View .....	117	<b>PREPARATION .....</b>	<b>152</b>
LEFT SIDE : Removal and Installation .....	117	Special Service Tools .....	152
		Commercial Service Tools .....	154
<b>UNIT REMOVAL AND INSTALLATION ...</b>	<b>119</b>	<b>PERIODIC MAINTENANCE .....</b>	<b>156</b>
<b>FRONT FINAL DRIVE ASSEMBLY .....</b>	<b>119</b>	<b>REAR DIFFERENTIAL GEAR OIL .....</b>	<b>156</b>
Exploded View .....	119	Inspection .....	156
Removal and Installation .....	119	Draining .....	156
		Refilling .....	156
<b>UNIT DISASSEMBLY AND ASSEMBLY ..</b>	<b>121</b>	<b>REMOVAL AND INSTALLATION .....</b>	<b>157</b>
<b>SIDE SHAFT .....</b>	<b>121</b>	<b>FRONT OIL SEAL .....</b>	<b>157</b>
Exploded View .....	121	<b>2WD .....</b>	<b>157</b>
Disassembly .....	122	2WD : Exploded View .....	157
Assembly .....	122	2WD : Removal and Installation .....	157
Inspection After Disassembly .....	123		
<b>DIFFERENTIAL ASSEMBLY .....</b>	<b>124</b>	<b>AWD .....</b>	<b>161</b>
Exploded View .....	124	AWD : Exploded View .....	162
Disassembly .....	125	AWD : Removal and Installation .....	162
Assembly .....	128		
Adjustment .....	132	<b>SIDE OIL SEAL .....</b>	<b>167</b>
Inspection After Disassembly .....	137	<b>2WD .....</b>	<b>167</b>
<b>DRIVE PINION .....</b>	<b>138</b>	2WD : Exploded View .....	167
Exploded View .....	138	2WD : Removal and Installation .....	167
Disassembly .....	139		
Assembly .....	140	<b>AWD .....</b>	<b>168</b>
Adjustment .....	142	AWD : Exploded View .....	169
Inspection After Disassembly .....	145	AWD : Removal and Installation .....	169
<b>SERVICE DATA AND SPECIFICATIONS</b>		<b>UNIT REMOVAL AND INSTALLATION ...</b>	<b>171</b>
<b>(SDS) .....</b>	<b>146</b>	<b>REAR FINAL DRIVE ASSEMBLY .....</b>	<b>171</b>
<b>SERVICE DATA AND SPECIFICATIONS</b>		<b>2WD .....</b>	<b>171</b>
<b>(SDS) .....</b>	<b>146</b>	2WD : Exploded View .....	171
General Specifications .....	146	2WD : Removal and Installation .....	171
Drive Gear Runout .....	146		
Differential Side Gear Clearance .....	146	<b>AWD .....</b>	<b>172</b>
Preload Torque .....	146	AWD : Exploded View .....	173
Backlash .....	146	AWD : Removal and Installation .....	173
Companion Flange Runout .....	146		
<b>REAR FINAL DRIVE: R200</b>		<b>UNIT DISASSEMBLY AND ASSEMBLY ..</b>	<b>175</b>
<b>SYSTEM DESCRIPTION .....</b>	<b>147</b>	<b>DIFFERENTIAL ASSEMBLY .....</b>	<b>175</b>
<b>REAR FINAL DRIVE ASSEMBLY .....</b>	<b>147</b>	<b>2WD .....</b>	<b>175</b>
System Diagram .....	147	2WD : Exploded View .....	175
		2WD : Disassembly .....	176
<b>SYMPTOM DIAGNOSIS .....</b>	<b>149</b>	2WD : Assembly .....	178
<b>NOISE, VIBRATION AND HARSHNESS</b>		2WD : Adjustment .....	182
<b>(NVH) TROUBLESHOOTING .....</b>	<b>149</b>	2WD : Inspection After Disassembly .....	186
NVH Troubleshooting Chart .....	149		
		<b>AWD .....</b>	<b>187</b>
<b>PRECAUTION .....</b>	<b>151</b>	AWD : Exploded View .....	187
<b>PRECAUTIONS .....</b>	<b>151</b>	AWD : Disassembly .....	188
		AWD : Assembly .....	191

AWD : Adjustment .....	194	AWD : Adjustment .....	213	
AWD : Inspection After Disassembly .....	199	AWD : Inspection After Disassembly .....	214	A
<b>DRIVE PINION .....</b>	<b>200</b>	<b>SERVICE DATA AND SPECIFICATIONS</b>		
<b>2WD .....</b>	<b>200</b>	<b>(SDS) .....</b>	<b>216</b>	B
2WD : Exploded View .....	200	<b>SERVICE DATA AND SPECIFICATIONS</b>		
2WD : Disassembly .....	201	<b>(SDS) .....</b>	<b>216</b>	C
2WD : Assembly .....	202	General Specification .....	216	
2WD : Adjustment .....	206	Drive Gear Runout .....	216	
2WD : Inspection After Disassembly .....	206	Differential Side Gear Clearance .....	216	
<b>AWD .....</b>	<b>207</b>	Preload Torque .....	216	<b>DLN</b>
AWD : Exploded View .....	207	Backlash .....	216	
AWD : Disassembly .....	208	Drive Pinion Runout (2WD) .....	216	
AWD : Assembly .....	210	Companion Flange Runout (AWD) .....	217	E
				F
				G
				H
				I
				J
				K
				L
				M
				N
				O
				P

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009062024

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Service Notice or Precautions for Transfer

INFOID:000000009062025

- Never reuse transfer fluid, once it has been drained.
- Check the fluid level or replace the fluid only with the vehicle parked on level ground.
- During removal or installation, keep inside of transfer clear of dust or dirt.
- Replace all tires at the same time. Always use tires of the proper size and the same brand and pattern. Fitting improper size and unusually worn tires applies excessive force to vehicle mechanism and can cause longitudinal vibration.
- Disassembly should be done in a clean work area, it is preferable to work in dustproof area.
- Before proceeding with disassembly, thoroughly clean the transfer. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they do not interfere with the function of the parts when applied.
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with a new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time the transfer is disassembled.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, use it.
- Observe the specified torque when assembling.
- Clean and flush the parts sufficiently and blow-dry them.
- Be careful not to damage sliding surfaces and mating surfaces.
- Clean inner parts with lint-free cloth or towels. Do not use cotton work gloves and rags to prevent adhering fibers.

# PREPARATION

< PREPARATION >

[TRANSFER: ETX13C]

## PREPARATION

### PREPARATION

#### Special Service Tools

INFOID:000000009062026

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.




Tool number (Kent-Moore No.) Tool name	Description
ST27862000 ( — ) Drift a: 62.5 mm (2.461 in) dia. b: 42 mm (1.65 in) dia.	Installing front oil seal
KV381054S0 (J-34286) Puller	Removing rear oil seal
ST30720000 (J-25405) Drift a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.	<ul style="list-style-type: none"> <li>Installing rear oil seal</li> <li>Installing main shaft oil seal</li> </ul>
KV40104830 ( — ) Drift a: 70 mm (2.76 in) dia. b: 63.5 mm (2.500 in) dia.	Installing rear oil seal
ST33052000 ( — ) Drift a: 28 mm (1.10 in) dia. b: 22 mm (0.87 in) dia.	Removing main shaft assembly
ST35321000 ( — ) Drift a: 49 mm (1.93 in) dia. b: 41 mm (1.61 in) dia.	Installing main shaft assembly

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# PREPARATION



< PREPARATION >

[TRANSFER: ETX13C]

Tool number (Kent-Moore No.) Tool name	Description
<p>ST31214000 (J-25269-B) Drift a: 34 mm (1.34 in) dia. b: 25.5 mm (1.004 in) dia.</p> <div style="text-align: center;">  <p style="font-size: small;">ZZA0534D</p> </div>	<ul style="list-style-type: none"> <li>Removing front drive shaft front bearing</li> <li>Removing front drive shaft rear bearing</li> </ul>
<p>ST33200000 (J-26082) Drift a: 60 mm (2.36 in) dia. b: 44.5 mm (1.752 in) dia.</p> <div style="text-align: center;">  <p style="font-size: small;">ZZA1002D</p> </div>	<p>Installing front drive shaft front bearing</p>
<p>KV38104010 ( — ) Drift a: 67 mm (2.64 in) dia. b: 49 mm (1.93 in) dia.</p> <div style="text-align: center;">  <p style="font-size: small;">ZZA1000D</p> </div>	<p>Installing front drive shaft rear bearing</p>

## Commercial Service Tools

INFOID:000000009062027



Tool name	Description
<p>Flange wrench</p> <div style="text-align: center;">  <p style="font-size: small;">NT771</p> </div>	<p>Removing and installing self-lock nut</p>
<p>Puller</p> <div style="text-align: center;">  <p style="font-size: small;">NT077</p> </div>	<p>Removing companion flange</p>



# PREPARATION

< PREPARATION >

[TRANSFER: ETX13C]

Tool name	Description
<p>Replacer</p> <div style="text-align: center;">  <p>ZZB0823D</p> </div>	<ul style="list-style-type: none"> <li>• Removing front drive shaft front bearing</li> <li>• Removing front drive shaft rear bearing</li> </ul>
<p>Power tool</p> <div style="text-align: center;">  <p>PBIC0190E</p> </div>	<p>Loosening bolts and nuts</p>


A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009062028



- 1. AWD control unit
- 2. AWD solenoid (inside transfer)
- 3. Transfer fluid temperature sensor (inside transfer)
- 4. Electric controlled coupling (inside transfer)
- A. AWD warning lamp (in combination meter)
- B. Glove box assembly removed
- C. Transfer assembly

Component Description

INFOID:000000009062029

Component parts	Reference/Function
AWD control unit	<a href="#">DLN-11, "AWD Control Unit"</a>
Wheel sensor	<a href="#">BRC-37, "Description"</a>
AWD solenoid	<a href="#">DLN-11, "AWD Solenoid"</a>
Transfer fluid temperature sensor	<a href="#">DLN-11, "Transfer Fluid Temperature Sensor"</a>
Electric controlled coupling	<a href="#">DLN-11, "Electric Controlled Coupling"</a>
AWD warning lamp	<a href="#">DLN-14, "AWD SYSTEM : System Description"</a>
ABS actuator and electric unit (control unit)	Transmits the following signals to AWD control unit via CAN communication. <ul style="list-style-type: none"> <li>• Vehicle speed signal</li> <li>• Stop lamp switch signal (brake signal)</li> </ul>
ECM	Transmits the following signals to AWD control unit via CAN communication. <ul style="list-style-type: none"> <li>• Accelerator pedal position signal</li> <li>• Engine speed signal</li> </ul>
Unified meter and A/C amp.	Transmits conditions of parking brake switch to AWD control unit via CAN communication. Receive AWD warning lamp signal from AWD control unit via CAN communication.

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[TRANSFER: ETX13C]

## AWD Control Unit

INFOID:000000009062030

- AWD control unit controls driving force distribution by signals from each sensor from rear wheel driving mode (0:100) to 4-wheel driving mode (50:50).
- Rear wheel driving conditions is available by fail-safe function if malfunction is detected in AWD system.

## AWD ACTUATOR RELAY

AWD actuator relay is integrated with AWD control unit, and supplies AWD solenoid with voltage.

## AWD Solenoid


INFOID:000000009062031

AWD solenoid is integrated with electric controlled coupling, and controls electric controlled coupling by command current from AWD control unit.


## Transfer Fluid Temperature Sensor

INFOID:000000009062032

- Transfer fluid temperature sensor is integrated with electric controlled coupling.
- Transfer fluid temperature sensor detects the transfer fluid temperature and transmits a signal to AWD control unit.



- The electrical resistance of the sensor decreases as temperature increases.



## Electric Controlled Coupling

INFOID:000000009062033

Electric controlled coupling is integrated with transfer and transmits driving force to rear final drive. For operation, refer to [DLN-12. "Operation Description"](#).

# STRUCTURE AND OPERATION


< SYSTEM DESCRIPTION >

[TRANSFER: ETX13C]

## STRUCTURE AND OPERATION

### Sectional View

INFOID:000000009062034




JSDIA0803ZZ

- |                      |                   |               |
|----------------------|-------------------|---------------|
| 1. Electromagnet     | 2. Control clutch | 3. Cam        |
| 4. Drive chain       | 5. Front case     | 6. Main shaft |
| 7. Front drive shaft | 8. Main clutch    | 9. Rear case  |

### Operation Description

INFOID:000000009062035

### POWER TRANSFER DIAGRAM



JPDIE0253GB


### OPERATION PRINCIPLE

### ELECTRIC CONTROLLED COUPLING

# STRUCTURE AND OPERATION


< SYSTEM DESCRIPTION >

[TRANSFER: ETX13C]



- |                             |                                            |                      |
|-----------------------------|--------------------------------------------|----------------------|
| 1. Main clutch              | 2. Control clutch                          | 3. Cam               |
| 4. Electromagnet            |                                            |                      |
| A. Torque flow              | B. Current commanded from AWD control unit | C. From transmission |
| D. To front propeller shaft |                                            |                      |

1. AWD control unit supplies command current to electric controlled coupling (AWD solenoid).
2. Control clutch is engaged by electromagnet and torque is detected in control clutch.
3. The cam operates in response to control clutch torque and applies pressure to main clutch.
4. Main clutch transmits torque to front wheels according to pressing power.
  - Transmission torque to front wheels is determined according to command current.



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


## SYSTEM AWD SYSTEM

### AWD SYSTEM : System Description

INFOID:000000009062036

- Pressing force of multiple disc clutch is controlled by electric control. Driving torque distribution of front and rear wheels changes automatically between approximately 0 : 100 (Rear wheel drive) and 50 : 50 (AWD) to have an optimized torque distribution adapted to road condition change.
- In accordance with fail-safe function, when system is malfunctioning, AWD control stops, and the system becomes rear wheel drive. Refer to [DLN-15, "AWD SYSTEM : Fail-safe"](#).
- When a high load status continues for electric controlled coupling, AWD control temporarily becomes rear wheel drive, according to protection function. Refer to [DLN-15, "AWD SYSTEM : Protection Function"](#).

### SYSTEM DIAGRAM



### INPUT/OUTPUT SIGNAL

It transmits/receives each signal from the following control unit via CAN communication line.

Component parts	Signal item
ABS actuator and electric unit (control unit)	Transmits the following signals to AWD control unit via CAN communication. <ul style="list-style-type: none"> <li>• Vehicle speed signal</li> <li>• Stop lamp switch signal (brake signal)</li> </ul>
ECM	Transmits the following signals to AWD control unit via CAN communication. <ul style="list-style-type: none"> <li>• Accelerator pedal position signal</li> <li>• Engine speed signal</li> </ul>
Unified meter and A/C amp.	Transmits conditions of parking brake switch to AWD control unit via CAN communication.
	Receive AWD warning lamp signal from AWD control unit via CAN communication.

### OPERATION CHARACTERISTIC


# SYSTEM

## < SYSTEM DESCRIPTION >

[TRANSFER: ETX13C]

### VEHICLE STARTS CONTROL

- At the start, torque distribution for front and rear wheels is fixed by electric control and stable start is achieved.
- Makes possible stable driving, with no wheel spin, on snowy roads or other slippery surfaces.



### NORMAL CONTROL

- On roads which do not require AWD, it contributes to improved fuel economy by driving in conditions close to rear-wheel drive and it results in better fuel efficiency and provides FR-like steering characteristics.
- When spin occurs on rear wheel, distribute optimum torque to front wheel and keep stable driving.
- The vehicle cornering status is judged according to information from each sensor, and the optimum torque is distributed to front wheels for preventing tight cornering/braking symptom.

### AWD WARNING LAMP INDICATION CONDITION

- Turns ON when there is a malfunction in AWD system. AWD warning lamp indicates the vehicle is in fail-safe mode.
- Also turns ON when ignition switch is turned ON, for the purpose of lamp check. Turns OFF approximately for 1 second after the engine starts if system is normal.

### AWD WARNING LAMP INDICATION

Condition	AWD warning lamp
Lamp check	Turns ON when ignition switch is turned ON. (Turns OFF approx. 1 second after the engine start.)
AWD system malfunction	ON
Protection function is activated due to heavy load to electric controlled coupling. (AWD system is not malfunctioning and AWD system changes to rear wheel drive.)	Quick blinking: 2 times/second (Blinking in approx. 1 minute and then turning OFF)
Large difference in diameter of front/rear tires	Slow blinking: 1 time/2 seconds (Continuing to blink until turning ignition switch OFF)
Other than above (system normal)	OFF

### CAUTION:

**AWD warning lamp also turns ON due to data reception error, CAN communication error etc.**

### AWD SYSTEM : Fail-safe

INFOID:000000009062037

- If any malfunction occurs in AWD electrical system, and control unit detects the malfunction, AWD warning lamp on combination meter turns ON to indicate system malfunction.
- When AWD warning lamp is ON, vehicle changes to rear-wheel drive or shifts to 4-wheel drive (front-wheels still have some driving torque)

### AWD SYSTEM : Protection Function

INFOID:000000009062038

AWD system activates its protection function (shuts down AWD system temporarily) if AWD system detects high load continuously or the front wheel tire size differs from the rear tire size. (AWD system is automatically restored if AWD system no longer detects any overload or the tire size difference is eliminated.)

DTC	Warning lamp	Error area and root cause	Contents of protection function
—	Blinking <sup>*1</sup>	Transfer assembly in protection mode. It is not malfunction. (Internal temperature rise of electronic controlled coupling)	Shuts down AWD system temporarily
—	Blinking <sup>*2</sup>	Malfunction in each tire or different tire diameter	

## SYSTEM

< SYSTEM DESCRIPTION >

[TRANSFER: ETX13C]

---

\*1: Quick blinking: 2 times/second (blinking for approximately 1 minute and then turned OFF)

\*2: Slow blinking: 1 time/2 seconds (continuing to blink until ignition switch is turned OFF)

**NOTE:**

- If the warning lamp blinks slowly during driving but remains OFF after the engine is restarted, the system is normal. If it again blinks slowly after driving for some time, vehicle must be inspected.
- When there is a difference of revolution speed between the front and rear wheel the shift occasionally changes to direct 4-wheel driving conditions automatically. This is not a malfunction.



# DIAGNOSIS SYSTEM (AWD CONTROL UNIT)

< SYSTEM DESCRIPTION >

[TRANSFER: ETX13C]

## DIAGNOSIS SYSTEM (AWD CONTROL UNIT)

### CONSULT Function

INFOID:000000009062039

### APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes as follows.

Diagnostic test mode	Function
ECU Identification	AWD control unit part number can be read.
Self Diagnostic Result	Self-diagnostic results and freeze frame data can be read and erased quickly.*
Data Monitor	Input/Output data in the AWD control unit can be read.
Active Test	Diagnostic Test Mode in which CONSULT drives some actuators apart from the AWD control unit and also shifts some parameters in a specified range.

\* : The following diagnosis information is erased by erasing.

- DTC
- Freeze frame data (FFD)

### ECU IDENTIFICATION

AWD control unit part number can be read.

### SELF DIAGNOSTIC RESULT

Refer to [DLN-21, "DTC Index"](#).

When "PRNT" is displayed on self-diagnosis result.

- The system is presently malfunctioning.

When "PAST" is displayed on self-diagnosis result.

- System malfunction in the past is detected, but the system is presently normal.

### FREEZE FRAME DATA (FFD)

The following vehicle status is recorded when DTC is detected and is displayed on CONSULT.

Item name	Display item
IGN COUNTER (0 – 39)	<p>The number of times that ignition switch is turned ON after the DTC is detected is displayed.</p> <ul style="list-style-type: none"> <li>• When "0" is displayed : It indicates that the system is presently malfunctioning.</li> <li>• When except "0" is displayed : It indicates that system malfunction in the past is detected, but the system is presently normal.</li> </ul> <p><b>NOTE:</b> Each time when ignition switch is turned OFF to ON, numerical number increases in 1→2→3...38→39. When the operation number of times exceeds 39, the number do not increase and "39" is displayed until self-diagnosis is erased.</p>

### DATA MONITOR

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item (Unit)	Remarks
STOP LAMP SW [On/Off]	Stop lamp switch signal status via CAN communication line is displayed.
ENG SPEED SIG [Run/Stop]	Engine status is displayed.
ETS ACTUATOR [On/Off]	Operating condition of AWD actuator relay (integrated in AWD control unit) is displayed.
4WD WARN LAMP [On/Off]	Control status of AWD warning lamp is displayed.
4WD MODE SW [##] <sup>*1</sup>	Mode switch is not equipped, but displayed.
4WD MODE MON [AUTO]	Control status of AWD is displayed.
DIS-TIRE MONI [mm]	Improper size tire installed condition is displayed.
P BRAKE SW [On/Off]	Parking brake switch signal status via CAN communication line is displayed.
BATTERY VOLT [V]	Power supply voltage for AWD control unit

# DIAGNOSIS SYSTEM (AWD CONTROL UNIT)

< SYSTEM DESCRIPTION >

[TRANSFER: ETX13C]

Monitor item (Unit)	Remarks
THRTL POS SEN [%]	Throttle opening status is displayed.
ETS SOLENOID [A]	Monitored value of current at AWD solenoid
FR RH SENSOR [km/h] or [mph]	Wheel speed calculated by front RH wheel sensor signal is displayed.
FR LH SENSOR [km/h] or [mph]	Wheel speed calculated by front LH wheel sensor signal is displayed.
RR RH SENSOR [km/h] or [mph]	Wheel speed calculated by rear RH wheel sensor signal is displayed.
RR LH SENSOR [km/h] or [mph]	Wheel speed calculated by rear LH wheel sensor signal is displayed.

\*1: It is not setting, but it is displayed.

## ACTIVE TEST

Use this mode to determine and identify the details of a malfunction based on self-diagnostic results or data monitor. AWD control unit gives drive signal to actuator with receiving command from CONSULT to check operation of actuator.

Test item	Condition	Description
ETS S/V (Detects AWD solenoid)	<ul style="list-style-type: none"><li>Vehicle stopped</li><li>Engine running</li><li>No DTC detected</li></ul>	<p>Change command current value to AWD solenoid, and then change driving mode. (Monitor value is normal if it is within approx. <math>\pm 10\%</math> of command value.)</p> <ul style="list-style-type: none"><li>Qu: Increase current value in increments of 0.2 A</li><li>Qd: Decrease current value in increments of 0.2 A</li><li>UP: Increase current value in increments of 0.02 A</li><li>DOWN: Decrease current value in increments of 0.02 A</li></ul>

### CAUTION:

Never energize continuously for a long time.

# AWD CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[TRANSFER: ETX13C]

## ECU DIAGNOSIS INFORMATION

### AWD CONTROL UNIT

#### Reference Value

INFOID:000000009062040

#### VALUES ON THE DIAGNOSIS TOOL

**NOTE:**

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item	Condition	Value/Status
STOP LAMP SW	Brake pedal: Depressed	On
	Brake pedal: Released	Off
ENG SPEED SIG	Engine stopped (Engine speed: Less than 400 rpm)	Stop
	Engine running (Engine speed: 400 rpm or more)	Run
ETS ACTUATOR	Engine stopped (Ignition switch: ON)	Off
	Engine running	On
4WD WARN LAMP	AWD warning lamp: ON	On
	AWD warning lamp: OFF	Off
4WD MODE SW*1	Always	##
4WD MODE MON	Engine running	AUTO
DIS-TIRE MONI	Vehicle running with normal size tire installed	0 – 4 mm
	Vehicle running with improper size tire installed (Front/rear tire size difference, wear condition)	4 – 8 mm, 8 – mm
P BRAKE SW	Parking brake operated	On
	Parking brake not operated	Off
BATTERY VOLT	Always	Battery voltage
THRTL POS SEN	When depressing accelerator pedal (Value rises gradually in response to throttle position.)	0 – 100%
ETS SOLENOID	Engine running • At idle speed	Approx. 0.000 A
	Engine running • 3,000 rpm or more constant	Approx. 0.000 – 0.500 A <sup>2</sup>
FR RH SENSOR	Vehicle stopped	0.00 km/h (0.00 mph)
	Vehicle running <b>CAUTION:</b> <b>Check air pressure of tire under standard condition.</b>	Approx. equal to the indication on speedometer (Inside of ±10%)
FR LH SENSOR	Vehicle stopped	0.00 km/h (0.00 mph)
	Vehicle running <b>CAUTION:</b> <b>Check air pressure of tire under standard condition.</b>	Approx. equal to the indication on speedometer (Inside of ±10%)
RR RH SENSOR	Vehicle stopped	0.00 km/h (0.00 mph)
	Vehicle running <b>CAUTION:</b> <b>Check air pressure of tire under standard condition.</b>	Approx. equal to the indication on speedometer (Inside of ±10%)
RR LH SENSOR	Vehicle stopped	0.00 km/h (0.00 mph)
	Vehicle running <b>CAUTION:</b> <b>Check air pressure of tire under standard condition.</b>	Approx. equal to the indication on speedometer (Inside of ±10%)

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# AWD CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

[TRANSFER: ETX13C]

\*1: It is not setting, but it is displayed.

\*2: The values are changed by throttle opening and engine speed.

## TERMINAL LAYOUT



## PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (BR)	Ground	AWD solenoid power supply	Output	Engine speed: At idle	0 V
				Engine speed: 3,000 rpm or more constant	2.5 V*
2 (Y)	Ground	AWD solenoid ground	Input	Engine speed: At idle	0 V
				Engine speed: 3,000 rpm or more constant	0 V
3 (W)	Ground	Transfer fluid temperature sensor ground	Input	Always	0 V
7 (G)	Ground	Ignition switch	Input	Ignition switch: ON	Battery voltage
				Ignition switch: OFF	0 V
8 (L)	—	CAN-H	Input/ Output	—	—
9 (O)	Ground	Power supply (AWD solenoid)	Input	Always	Battery voltage
10 (B)	Ground	Ground	—	Always	0 V
11 (GR)	Ground	Ground	—	Always	0 V
13 (LG)	Ground	Transfer fluid temperature sensor power supply	Output	Transfer temperature: 20°C (68°F)	1.56 V
				Transfer temperature: 80°C (176°F)	0.44 V
15 (Y)	Ground	Power supply (AWD control unit)	Input	Always	Battery voltage
16 (P)	—	CAN-L	Input/ Output	—	—

\*: The values are changed by throttle opening and engine speed.

### CAUTION:

**When using circuit tester to measure voltage for inspection, be sure not to extend forcibly any connector terminals.**

### Fail-safe

INFOID:000000009062041

- If any malfunction occurs in AWD electrical system, and control unit detects the malfunction, AWD warning lamp on combination meter turns ON to indicate system malfunction.
- When AWD warning lamp is ON, vehicle changes to rear-wheel drive or shifts to 4-wheel drive (front-wheels still have some driving torque)

# AWD CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[TRANSFER: ETX13C]

## Protection Function

INFOID:000000009062042

AWD system activates its protection function (shuts down AWD system temporarily) if AWD system detects high load continuously or the front wheel tire size differs from the rear tire size. (AWD system is automatically restored if AWD system no longer detects any overload or the tire size difference is eliminated.)

DTC	Warning lamp	Error area and root cause	Contents of protection function
—	Blinking*1	Transfer assembly in protection mode. It is not malfunction. (Internal temperature rise of electronic controlled coupling)	Shuts down AWD system temporarily
—	Blinking*2	Malfunction in each tire or different tire diameter	

\*1: Quick blinking: 2 times/second (blinking for approximately 1 minute and then turned OFF)

\*2: Slow blinking: 1 time/2 seconds (continuing to blink until ignition switch is turned OFF)

**NOTE:**

- If the warning lamp blinks slowly during driving but remains OFF after the engine is restarted, the system is normal. If it again blinks slowly after driving for some time, vehicle must be inspected.
- When there is a difference of revolution speed between the front and rear wheel the shift occasionally changes to direct 4-wheel driving conditions automatically. This is not a malfunction.

## DTC Inspection Priority Chart

INFOID:000000009062043

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> <li>• U1000 CAN COMM CIRCUIT</li> <li>• U1010 CONTROL UNIT (CAN)</li> </ul>
2	<ul style="list-style-type: none"> <li>• C1201 CONTROLLER FAILURE</li> <li>• C1205 4WD ACTUATOR RLY</li> <li>• P1804 CONTROL UNIT 3</li> <li>• P1809 CONTROL UNIT 4</li> </ul>
3	<ul style="list-style-type: none"> <li>• C1203 ABS SYSTEM</li> <li>• C1210 ENGINE SIGNAL 1</li> </ul>
4	<ul style="list-style-type: none"> <li>• C1204 4WD SOLENOID</li> <li>• P1826 OIL TEMP SEN</li> </ul>

## DTC Index

INFOID:000000009062044

DTC	Display Items	Reference
C1201	CONTROLLER FAILURE	<a href="#">DLN-30, "DTC Logic"</a>
C1203	ABS SYSTEM	<a href="#">DLN-31, "DTC Logic"</a>
C1204	4WD SOLENOID	<a href="#">DLN-32, "DTC Logic"</a>
C1205	4WD ACTUATOR RLY	<a href="#">DLN-35, "DTC Logic"</a>
C1210	ENGINE SIGNAL 1	<a href="#">DLN-37, "DTC Logic"</a>
P1804	CONTROL UNIT 3	<a href="#">DLN-38, "DTC Logic"</a>
P1809	CONTROL UNIT 4	<a href="#">DLN-39, "DTC Logic"</a>
P1826	OIL TEMP SEN	<a href="#">DLN-40, "DTC Logic"</a>
U1000	CAN COMM CIRCUIT	<a href="#">DLN-43, "DTC Logic"</a>
U1010	CONTROL UNIT (CAN)	<a href="#">DLN-44, "DTC Logic"</a>

**NOTE:**

If some DTCs are displayed at the same time, refer to [DLN-21, "DTC Inspection Priority Chart"](#).

< WIRING DIAGRAM >


# WIRING DIAGRAM

## AWD SYSTEM

### Wiring Diagram

INFOID:000000009062045

AWD SYSTEM



# AWD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: ETX13C]


## AWD SYSTEM

Connector No.	E5
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	TH20FW-CS12-AM4-1V



Terminal No.	Color Of Wire	Signal Name [Specification]
4	V	-
5	L	-
7	R	-
12	B/W	-
13	V	-
16	LG	-
19	W	-
23	G	-
27	B/G	-
28	L	-
30	GR	-
36	G	-


Connector No.	E13
Connector Name	WIRE TO WIRE
Connector Type	SAA36MB-RSS-SHZ8



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L/Y	-
2	SHIELD	-
3	L/B	-
4	SHIELD	-
5	BR	-
7	G	-

8	W	-
9	W	-
10	Y	-
11	P	-
12	SB	-
13	L	-
14	G	-
15	R	-
16	LG	-
18	Y	-
19	B/G	-
20	B	-
21	SB	-
22	W	-
23	L	-
24	G	-
25	LG	-
27	GR	-
28	V	-
29	P	-
30	R	-
31	BR	-
32	Y	-
33	G	-
34	B/G	-
37	SHIELD	-
38	L	-
39	P	-
40	R	-
41	W	-
42	LG	-
43	G	-
45	B/G	-
46	SHIELD	-
47	W	-
48	BR	-
49	G	-
50	B	-
51	SB	-
52	R	-

Connector No.	E41
Connector Name	HAS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	BAA42FB-AHZ4-LH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	B	GROUND
2	G	UBWR
3	R	UBVR
4	B	GROUND
5	V	BS FL
6	B/G	DP RL
7	BR	DP RL
9	B	DP RL
10	W	DSTR
12	L	VAC
14	P	CANL
15	SHIELD	GROUND
19	P	UST
25	Y	BUS-L
26	LG	DP FL
27	GR	DS RL
28	G	UZ
29	LG	DS RRR
30	SB	BLS
31	R	VDC OFF SW
35	L	CANH
45	B	BUS-H

Connector No.	E106
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color Of Wire	Signal Name [Specification]
1	R	-
2	W	-
3	B	-
4	GR	-
5	GR	-
8	V	-
9	BR	-
10	B/G	-
11	SB	-
12	B/G	-
13	L	-
14	R	-
15	P	-
16	V	-
17	SB	-
18	V	-
20	B/G	-
21	L	-
22	V	-
23	G	-
24	P	-
25	Y	-
26	V	-
27	W	-
28	G	-
31	B/G	-
32	W	-
33	B	-
34	R	-
35	G	-
36	SHIELD	-
37	V	-
38	BR	-
39	B/G	-
41	W	-


A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AWD SYSTEM

42	G	-	-
43	BR	-	-
44	W	-	-
45	W	-	-
46	L	-	-
47	L	-	-
48	P	-	-
49	L	-	-
50	P	-	-
51	L	-	-
52	BG	-	-
53	BR	-	-
54	W	-	-
55	W	-	-
56	LG	-	-
57	G	-	-
58	S9	-	-
59	W	-	-
60	B	-	-
61	G	-	-
62	B	-	-
63	G	-	-
64	R	-	-
65	SHIELD	-	-
66	Y	-	-
67	LG	-	-
68	W	-	-
69	W	-	-
70	R	-	-
71	Y	-	-
72	B	-	-
73	BR	- [With ICC]	-
74	L	- [Without ICC]	-
75	G	- [With ICC]	-
76	W	- [Without ICC]	-
77	P	- [With ICC]	-
78	R	- [Without ICC]	-
79	L	- [With ICC]	-
80	Y	- [Without ICC]	-
81	R	-	-
82	S9	-	-
83	BG	-	-
84	G	-	-
85	L	-	-
86	P	-	-
87	V	-	-
88	GR	-	-
89	SHIELD	-	-
90	W	-	-
91	Y	-	-
92	Y	-	-
93	V	-	-
94	LG	-	-
95	BG	-	-

96	P	-	-
97	R	-	-
98	SHIELD	-	-
99	L	-	-
100	P	-	-

Connector No.	F40
Connector Name	WIRE TO WIRE
Connector Type	SAA36FB-RS9-SH28



Terminal No.	Color Of Wire	Signal Name [Specification]
1	LY	-
2	SHIELD	-
3	UB	-
4	SHIELD	-
5	BR	-
7	G	-
8	W	-
9	W	-
10	G	-
11	R	-
12	P	-
13	L	-
14	LG	-
15	BR	-
16	Y	-
18	LG	-
19	P	-
20	O	-
21	Y	-
22	G	-
23	Y	-
24	LG	-
25	V	-
27	GR	-
28	BR	-
29	L	-
30	R	-
31	P	-
32	W	-


33	SB	-	-
34	O	-	-
37	SHIELD	-	-
38	W	-	-
39	Y	-	-
40	G	-	-
41	B	-	-
42	GR	-	-
43	R	-	-
45	O	-	-
46	SHIELD	-	-
47	WL	-	-
48	LG	-	-
49	O/L	-	-
50	LY	-	-
51	W	-	-
52	L/G	-	-

Connector No.	F57
Connector Name	AWD SOLENOID
Connector Type	RK08FB



Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	Y	-
6	LG	-
7	W	-

Connector No.	F103
Connector Name	WIRE TO WIRE
Connector Type	TK96FW-NS10




Terminal No.	Color Of Wire	Signal Name [Specification]
2	G	-
3	W	-
4	R	-
5	B	-
9	Y	-
10	GR	-
19	BG	- [Without ICC]
20	Y	- [With ICC]
28	B	-
29	LG	-
31	R	-
33	GR	-
34	B	-
35	L	-
36	P	-
37	Y	-
38	G	-
43	LG	-
44	O	-
45	Y	-
46	V	-



# AWD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: ETX13C]



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

AWD SYSTEM

10	G	SECURITY SIGNAL
15	B	GROUND
16	B	METER CONTROL SWITCH/GROUND
19	B	ILL GND
20	R	ILL
21	BG	IGNITION SIGNAL
22	A	GROUND
24	BR	COMMUNICATION SIGNAL (LCD-AMP.)
25	Y	COMMUNICATION SIGNAL (AMP-LLCD)
26	R	VEHICLE SPEED SIGNAL (8-PUL/SE)
27	V	PARKING BRAKE SWITCH SIGNAL
28	W	BRAKE FLUID LEVEL SWITCH SIGNAL
29	S8	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
30	G	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)
31	L	WASHER LEVEL SWITCH SIGNAL
33	B	ILLUMINATION CONTROL SIGNAL
36	LG	SELECT SWITCH SIGNAL
37	S8	ENTER SWITCH SIGNAL
38	L	TRIP AIR RESET SWITCH SIGNAL
39	P	ILLUMINATION CONTROL SWITCH SIGNAL (1)
40	BG	ILLUMINATION CONTROL SWITCH SIGNAL (2)


Connector No.	IM66
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH40FV-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
5	L	MANUAL MODE SHIFT UP SIGNAL
7	GR	COMMUNICATION SIGNAL (AMP-METER)
8	L	VEHICLE SPEED SIGNAL (2-PUL/SE)
9	S8	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
10	W	MANUAL MODE SIGNAL
11	G	NON-MANUAL MODE SIGNAL
14	BR	COMMUNICATION SIGNAL (LCD-AMP.)
20	L	IGN ON/OFF SIGNAL
23	Y	AT SNOW SWITCH SIGNAL
25	V	MANUAL MODE SHIFT DOWN SIGNAL
27	LG	COMMUNICATION SIGNAL (METER-AMP.)
28	R	VEHICLE SPEED SIGNAL (8-PUL/SE)
30	V	PARKING BRAKE SWITCH SIGNAL

34	Y	COMMUNICATION SIGNAL (AMP-LLCD)
38	P	BLOWER MOTOR CONTROL SIGNAL

Connector No.	MB7
Connector Name	UNIFIED METER AND A/C AMP.
Connector Type	TH2FV-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
41	V	ACC POWER SUPPLY
42	Y	FUEL LEVEL SENSOR SIGNAL
43	R	INTAKE SENSOR SIGNAL
44	LG	IN-VEHICLE SENSOR SIGNAL
45	TP	AMBIENT SENSOR SIGNAL
46	BG	SUNLOAD SENSOR SIGNAL
47	G	IGNITION POWER SUPPLY
54	Y	BATTERY POWER SUPPLY
55	B	GROUND
56	L	CANH
57	W	BRAKE FLUID LEVEL SWITCH SIGNAL
58	BR	FUEL LEVEL SENSOR SIGNAL
59	GR	INTAKE SENSOR SIGNAL
60	L	IN-VEHICLE SENSOR SIGNAL
61	BR	AMBIENT SENSOR SIGNAL
62	S8	SUNLOAD SENSOR SIGNAL
63	R	GROUND
65	BG	ECV SIGNAL
69	L	A/C LAN SIGNAL
70	R	EACH DOOR MOTOR POWER SUPPLY
71	B	GROUND
72	P	CANL

Connector No.	MT07
Connector Name	ECM
Connector Type	RI24FGY-RZ8-R-LH-Z



Terminal No.	Color Of Wire	Signal Name [Specification]
97	R	ACCELERATOR PEDAL POSITION SENSOR 1
98	P	ACCELERATOR PEDAL POSITION SENSOR 2 (WITHOUT ICC)
98	Y	ACCELERATOR PEDAL POSITION SENSOR 2 (WITH ICC)
99	G	SENSOR POWER SUPPLY (WITH ICC)
99	L	SENSOR POWER SUPPLY (WITHOUT ICC)
100	W	SENSOR GROUND
101	S8	ASCD/CC STEERING SWITCH
102	LG	E/MP CONTROL SYSTEM PRESS SENSOR
103	G	SENSOR POWER SUPPLY (WITHOUT ICC)
103	L	SENSOR POWER SUPPLY (WITH ICC)
104	BR	SENSOR GROUND (WITH ICC)
104	GR	SENSOR GROUND (WITHOUT ICC)
105	L	REFRIGERANT PRESS SENSOR
106	W	FUEL TANK TEMPERATURE SENSOR
107	BG	SENSOR POWER SUPPLY
108	Y	SENSOR GROUND
109	G	PNP SIGNAL
110	R	ENGINE SPEED OUTPUT SIGNAL
112	V	SENSOR GROUND
113	P	CAN COMMUNICATION LINE
114	L	CAN COMMUNICATION LINE
117	V	DATA LINK CONNECTOR
121	LG	EVAP CANISTER VENT CONTROL VALVE
122	P	STOP LAMP SWITCH
124	B	ECM GROUND
124	R	ECM GROUND
125	R	POWER SUPPLY FOR ECM
126	BR	ASCD/CC BRAKE SWITCH
127	B	ECM GROUND
128	B	ECM GROUND

Connector No.	MT16
Connector Name	WIRE TO WIRE
Connector Type	TK36MV-N510



Terminal No.	Color Of Wire	Signal Name [Specification]
2	P	-
3	L	-
4	R	-
5	B	-
9	R	-
10	R	-
19	BG	-
20	Y	-
28	B	-
29	LG	-
31	W	-
33	B	-
34	B	-
35	L	-
36	P	-
37	Y	-
38	G	-
43	P	-
44	L	-
45	BR	-
46	BG	-

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[TRANSFER: ETX13C]

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

#### Work Flow

INFOID:000000009062046

#### DETAILED FLOW

#### 1. INTERVIEW FROM THE CUSTOMER

Clarify customer complaints before inspection. First of all, perform an interview utilizing [DLN-28, "Diagnostic Work Sheet"](#) and reproduce symptoms as well as fully understand it. Ask customer about his/her complaints carefully. Check symptoms by driving vehicle with customer, if necessary.

**CAUTION:**

**Customers are not professional. Never guess easily like "maybe the customer means that..." or "maybe the customer mentions this symptom".**

>> GO TO 2.

#### 2. CHECK SYMPTOM

Reproduce the symptom that is indicated by the customer, based on the information from the customer obtained by interview. Also check that the symptom is not caused by protection function. Refer to [DLN-21, "Protection Function"](#).

**CAUTION:**

**When the symptom is caused by normal operation, fully inspect each portion and obtain the understanding of customer that the symptom is not caused by a malfunction.**

>> GO TO 3.

#### 3. PERFORM SELF-DIAGNOSIS

 **With CONSULT**

Perform self-diagnosis for "ALL MODE AWD/4WD".

Is any DTC detected?

YES >> Record or print self-diagnosis results. GO TO 4.

NO >> GO TO 6.

#### 4. RECHECK SYMPTOM

 **With CONSULT**

1. Erase self-diagnostic results for "ALL MODE AWD/4WD".

2. Perform DTC confirmation procedures for the error detected system.

**NOTE:**

If some DTCs are detected at the same time, determine the order for performing the diagnosis based on [DLN-21, "DTC Inspection Priority Chart"](#).

Is any DTC detected?

YES >> GO TO 5.

NO >> Check harness and connectors based on the information obtained by interview. Refer to [GI-42, "Intermittent Incident"](#).

#### 5. REPAIR OR REPLACE ERROR-DETECTED PARTS

- Repair or replace error-detected parts.
- Reconnect part or connector after repairing or replacing.
- When DTC is detected, erase self-diagnostic results for "ALL MODE AWD/4WD".

>> GO TO 7.

#### 6. IDENTIFY ERROR-DETECTED SYSTEM BY SYMPTOM DIAGNOSIS

Estimate error-detected system based on symptom diagnosis and perform inspection.

Can the error-detected system be identified?

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[TRANSFER: ETX13C]

YES >> GO TO 7.

NO >> Check harness and connectors based on the information obtained by interview. Refer to [GI-42](#), "[Intermittent Incident](#)".

## 7. FINAL CHECK

### With CONSULT

1. Check the reference value for AWD control unit.
2. Recheck the symptom and check that symptom is not reproduced on the same conditions.

Is the symptom reproduced?

YES >> GO TO 3.

NO >> INSPECTION END

## Diagnostic Work Sheet

INFOID:000000009062047

### Description

- In general, customers have their own criteria for a problem. Therefore, it is important to understand the symptom and status well enough by asking the customer about his/her concerns carefully. To systemize all the information for the diagnosis, prepare the interview sheet referring to the interview points.
- In some cases, multiple conditions that appear simultaneously may cause a DTC to be detected.

### Interview sheet sample

Interview sheet					
Customer name	MR/MS	Registration number		Initial year registration	
		Vehicle type		VIN	
Storage date		Engine		Mileage	km (Mile)
Symptom		<input type="checkbox"/> Vehicle does not enter AWD mode.			
		<input type="checkbox"/> AWD warning lamp turns on.			
		<input type="checkbox"/> Heavy tight-corner braking symptom occurs			
		<input type="checkbox"/> Noise <input type="checkbox"/> Vibration			
		<input type="checkbox"/> Others ( _____ )			
First occurrence		<input type="checkbox"/> Recently <input type="checkbox"/> Others ( _____ )			
Frequency of occurrence		<input type="checkbox"/> Always <input type="checkbox"/> Under a certain conditions of _____ <input type="checkbox"/> Sometimes (time(s)/day)			
Climate conditions	<input type="checkbox"/> Irrelevant				
	Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloud <input type="checkbox"/> Rain <input type="checkbox"/> Snow <input type="checkbox"/> Others ( _____ )			
	Temperature	<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold <input type="checkbox"/> Temperature (Approx. _____ °C)			
Relative humidity		<input type="checkbox"/> High <input type="checkbox"/> Moderate <input type="checkbox"/> Low			
Road conditions		<input type="checkbox"/> Urban area <input type="checkbox"/> Suburb area <input type="checkbox"/> High way <input type="checkbox"/> Mounting road (uphill or down hill) <input type="checkbox"/> Rough road			
Operation conditions, etc.		<input type="checkbox"/> Irrelevant <input type="checkbox"/> When engine starts <input type="checkbox"/> During idling <input type="checkbox"/> During driving <input type="checkbox"/> During acceleration <input type="checkbox"/> At constant speed driving <input type="checkbox"/> During deceleration <input type="checkbox"/> During cornering (right curve or left curve)			

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[TRANSFER: ETX13C]

## Interview sheet

Customer name	MR/MS	Registration number		Initial year registration	
		Vehicle type		VIN	
Storage date		Engine		Mileage	km (Mile)
Other conditions					

Memo

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

DLN

# DTC/CIRCUIT DIAGNOSIS

## C1201 AWD CONTROL UNIT

### DTC Logic

INFOID:000000009062048

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1201	CONTROLLER FAILURE	Malfunction has occurred inside AWD control unit.	Internal malfunction of AWD control unit

#### DTC CONFIRMATION PROCEDURE

##### 1. DTC REPRODUCTION PROCEDURE

 **With CONSULT**

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "C1201" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-30, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

#### Diagnosis Procedure

INFOID:000000009062049

##### 1. PERFORM SELF-DIAGNOSIS

 **With CONSULT**

1. Erase self-diagnostic results for "ALL MODE AWD/4WD".
2. Turn the ignition switch OFF, and then wait 10 seconds or more.
3. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "C1201" detected?

- YES >> Replace AWD control unit. Refer to [DLN-57, "Removal and Installation"](#).  
 NO >> Check AWD control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace error-detected parts.

# C1203 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

## C1203 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### DTC Logic

INFOID:000000009062050

### DTC DETECTION LOGIC

DTC	Display items	Malfunction detected condition	Possible cause
C1203	ABS SYSTEM	Malfunction related to wheel sensor has been detected by ABS actuator and electric unit (control unit).	ABS malfunction <ul style="list-style-type: none"><li>Vehicle speed signal error</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

##### With CONSULT

- Start the engine and drive at 30 km/h (19 MPH) or more for approximately 1 minute.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

##### Is DTC "C1203" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-31, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000009062051

#### 1. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

##### With CONSULT

Perform self-diagnosis for "ABS".

##### Is any DTC detected?

- YES >> Check the DTC. Refer to [BRC-117, "DTC No. Index"](#).  
NO >> GO TO 2.

#### 2. ERASE SELF-DIAGNOSTIC RESULT

##### With CONSULT

- Erase self-diagnostic results for "ALL MODE AWD/4WD".
- Start the engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.
- Check that ABS warning lamp turns OFF.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

##### Does ABS warning lamp turn OFF?

- YES >> GO TO 3.  
NO >> Perform trouble diagnosis for ABS warning lamp system. Refer to [BRC-102, "Component Function Check"](#).

#### 3. CHECK TERMINALS AND HARNESS CONNECTORS

Check AWD control unit pin terminals for damage or loose connection with harness connector.

##### Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "C1203" is detected, Replace AWD control unit. Refer to [DLN-57, "Removal and Installation"](#).  
NO >> Repair or replace error-detected parts.

# C1204 AWD SOLENOID

[TRANSFER: ETX13C]

< DTC/CIRCUIT DIAGNOSIS >

## C1204 AWD SOLENOID

### DTC Logic

INFOID:000000009062052

### DTC DETECTION LOGIC

DTC	Display items	Malfunction detected condition	Possible cause
C1204	4WD SOLENOID	Malfunction related to AWD solenoid has been detected.	<ul style="list-style-type: none"><li>Internal malfunction of electronic controlled coupling</li><li>Malfunction of AWD solenoid power supply circuit (open or short)</li><li>Malfunction of AWD solenoid command current</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

##### With CONSULT

- Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

##### Is DTC "C1204" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-32, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000009062053

#### 1. CHECK AWD SOLENOID POWER SUPPLY (1)

- Turn the ignition switch OFF.
- Disconnect AWD control unit harness connector.
- Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
F108	9	Ground	Battery voltage

- Turn the ignition switch OFF.  
**CAUTION:**  
**Never start the engine.**
- Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
F108	9	Ground	Battery voltage

##### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2. CHECK AWD SOLENOID POWER SUPPLY (2)

- Turn the ignition switch OFF.
- Check the 10A fuse (#33)
- Check the harness for open or short between AWD control unit harness connector No.9 terminal and 10A (#33).

##### Is the inspection result normal?

- YES >> Perform the trouble diagnosis for power supply circuit. Refer to [PG-6, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).  
NO >> Repair or replace error-detected parts.



# C1204 AWD SOLENOID

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

## 3. CHECK AWD CONTROL UNIT GROUND

Check the continuity between AWD control unit harness connector and ground.

AWD control unit		—	Continuity
Connector	Terminal		
F108	10	Ground	Existed
	11		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

## 4. CHECK AWD SOLENOID CIRCUIT (1)

Check the resistance between AWD control unit terminals.

AWD control unit			Resistance (Approx.)
Terminal	Terminal		
F108	1	2	2.45 Ω

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 5.

## 5. CHECK AWD SOLENOID CIRCUIT (2)

1. Disconnect AWD solenoid harness connector.
2. Check the continuity between AWD control unit harness connector and AWD solenoid harness connector.

AWD control unit		AWD solenoid		Continuity
Connector	Terminal	Connector	Terminal	
F108	1	F57	1	Existed
	2		2	

3. Check the continuity between AWD control unit harness connector and the ground.

AWD control unit		—	Continuity
Connector	Terminal		
F108	1	Ground	Not existed
	2		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace error-detected parts.

## 6. CHECK AWD SOLENOID

Check AWD solenoid. Refer to [DLN-34, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> AWD solenoid is malfunctioning. Replace electric controlled coupling. Refer to [DLN-74, "Exploded View"](#).

## 7. CHECK TERMINALS AND HARNESS CONNECTORS

- Check AWD control unit pin terminals for damage or loose connection with harness connector.
- Check AWD solenoid pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace AWD control unit. Refer to [DLN-57, "Removal and Installation"](#).

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# C1204 AWD SOLENOID

[TRANSFER: ETX13C]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:000000009062054

### 1. CHECK AWD SOLENOID

1. Turn the ignition switch OFF.
2. Disconnect AWD solenoid harness connector.
3. Check the resistance between AWD solenoid connector terminals.

AWD solenoid		Resistance (Approx.)
Terminal		
1	2	2.45 Ω

Is the inspection result normal?

YES >> INSPECTION END

NO >> AWD solenoid is malfunctioning. Replace electric controlled coupling. Refer to [DLN-74, "Exploded View"](#).

# C1205 AWD ACTUATOR RELAY

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

## C1205 AWD ACTUATOR RELAY

### DTC Logic

INFOID:000000009062055

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1205	4WD ACTUATOR RLY	Malfunction has been detected from AWD actuator relay integrated with AWD control unit, or malfunction related to AWD solenoid has been detected.	<ul style="list-style-type: none"> <li>Internal malfunction of AWD control unit</li> <li>Malfunction of AWD solenoid power supply circuit (open or short)</li> </ul>

A  
B  
C  
DLN

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

##### With CONSULT

- Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

##### Is DTC "C1205" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-35, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

E  
F  
G

### Diagnosis Procedure

INFOID:000000009062056

#### 1. CHECK AWD SOLENOID CIRCUIT (1)

- Turn the ignition switch OFF.
- Disconnect AWD control unit harness connector.
- Check the continuity between AWD control unit harness connector and the ground.

AWD control unit		—	Continuity
Connector	Terminal		
F108	1	Ground	Not existed
	2		

H  
I  
J  
K

##### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> GO TO 3.

#### 2. CHECK TERMINALS AND HARNESS CONNECTORS

- Check AWD control unit pin terminals for damage or loose connection with harness connector.
- Check AWD solenoid pin terminals for damage or loose connection with harness connector.

##### Is the inspection result normal?

- YES >> After connecting each harness connector, perform DTC confirmation procedure again. When DTC "C1205" is detected, replace AWD control unit. Refer to [DLN-57, "Removal and Installation"](#).  
 NO >> Repair or replace damaged parts.

L  
M  
N  
O

#### 3. CHECK AWD SOLENOID

- Disconnect AWD solenoid harness connector.
- Check the continuity between AWD solenoid harness connector and the ground.

AWD solenoid		—	Continuity
Terminal			
1	Ground	Not existed	
2			

P

##### Is the inspection result normal?

# C1205 AWD ACTUATOR RELAY

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

YES >> GO TO 4.

NO >> Replace electric controlled coupling. Refer to [DLN-74, "Exploded View"](#).

## 4. CHECK AWD SOLENOID CIRCUIT

Check the continuity between AWD control unit harness connector and the ground.

AWD control unit		—	Continuity
Connector	Terminal		
F108	1	Ground	Not existed
	2		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace damaged parts.

## 5. CHECK TERMINALS AND HARNESS CONNECTORS

1. Check AWD control unit pin terminals for damage or loose connection with harness connector.

2. Check AWD solenoid pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> After connecting each harness connector, perform DTC confirmation procedure again. When DTC "C1205" is detected, GO TO 1.

NO >> Repair or replace damaged parts.

C1210 ECM

DTC Logic

INFOID:000000009062057

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1210	ENGINE SIGNAL 1	Malfunction related to engine signal has been detected.	Malfunction of engine control system

DTC CONFIRMATION PROCEDURE

1. DTC REPRODUCTION PROCEDURE

 With CONSULT

1. Start the engine. Drive the vehicle for a while.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "C1210" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-37, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009062058

1. PERFORM ECM SELF-DIAGNOSIS

 With CONSULT

Perform self-diagnosis for "ENGINE".

Is any DTC detected?

- YES >> Check the DTC. Refer to [EC-579, "DTC Index"](#).
- NO >> GO TO 2.

2. CHECK TERMINALS AND HARNESS CONNECTORS

Check AWD control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. When DTC "C1210" is detected, Replace AWD control unit. Refer to [DLN-57, "Removal and Installation"](#).
- NO >> Repair or replace error-detected parts.

# P1804 TRANSFER CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

## P1804 TRANSFER CONTROL UNIT

### DTC Logic

INFOID:000000009062059

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1804	CONTROL UNIT 3	Malfunction has occurred inside AWD control unit.	Malfunction is detected in the memory (EEPROM) system of transfer control unit.

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

##### With CONSULT

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

##### Is DTC "P1804" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-38, "Diagnosis Procedure"](#).  
NO >> INSPECTION END.

### Diagnosis Procedure

INFOID:000000009062060

#### 1. REPLACE AWD CONTROL UNIT

##### **CAUTION:**

Replace AWD control unit when DTC "P1804" is detected simultaneously with other items.

>> Replace AWD control unit. Refer [DLN-57, "Removal and Installation"](#).

# P1809 TRANSFER CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

## P1809 TRANSFER CONTROL UNIT

### DTC Logic

INFOID:000000009062061

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1809	CONTROL UNIT 4	Malfunction has occurred inside AWD control unit.	AD converter system of transfer control unit is malfunctioning.

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

##### With CONSULT

1. Turn the ignition switch ON.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

##### Is DTC "P1809" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-39, "Diagnosis Procedure"](#).  
NO >> INSPECTION END.

### Diagnosis Procedure

INFOID:000000009062062

#### 1. REPLACE AWD CONTROL UNIT

##### **CAUTION:**

Replace AWD control unit when DTC "P1809" is detected simultaneously with other items.

>> Replace AWD control unit. Refer [DLN-57, "Removal and Installation"](#).

# P1826 TRANSFER FLUID TEMPERATURE

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

## P1826 TRANSFER FLUID TEMPERATURE

### DTC Logic

INFOID:000000009062063

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1826	OIL TEMP SEN	Transfer fluid temperature sensor voltage condition is continued 0 V or more than 2.45 V for several seconds.	<ul style="list-style-type: none"><li>Malfunction of transfer fluid temperature sensor or transfer fluid temperature sensor circuit.</li><li>Malfunction of AWD control unit.</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

##### With CONSULT

- Turn the ignition switch ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

##### Is DTC "P1826" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-40. "Diagnosis Procedure"](#).  
NO >> INSPECTION END.

### Diagnosis Procedure

INFOID:000000009062064

#### 1. CHECK TRANSFER FLUID TEMPERATURE SENSOR SIGNAL (1)

- Turn the ignition switch OFF.
- Disconnect AWD solenoid harness connector.
- Turn the ignition switch ON.
- Check the voltage between AWD solenoid harness connector terminals.

AWD solenoid			Voltage (Approx.)
Connector	Terminal		
F57	6	7	2.5 V

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> GO TO 3.

#### 2. CHECK TRANSFER FLUID TEMPERATURE SENSOR

Check transfer fluid temperature sensor. Refer to [DLN-41. "Component Inspection"](#).

##### Is the inspection result normal?

- YES >> GO TO 6.  
NO >> AWD solenoid is malfunctioning. Replace electric controlled coupling. Refer to [DLN-74. "Exploded View"](#).

#### 3. CHECK TRANSFER FLUID TEMPERATURE SENSOR SIGNAL (2)

Check the voltage between AWD solenoid harness connector and ground.

AWD solenoid		—	Voltage (Approx.)
Connector	Terminal		
F57	6	Ground	2.5 V

##### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 5.

#### 4. CHECK AWD CONTROL UNIT GROUND



# P1826 TRANSFER FLUID TEMPERATURE

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

1. Turn the ignition switch OFF.
2. Disconnect AWD control unit harness connector.
3. Check the continuity between AWD control unit harness connector and ground.

AWD control unit		—	Continuity
Connector	Terminal		
F108	10	Ground	Existed
	11		

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace error-detected parts.

## 5.CHECK TRANSFER FLUID TEMPERATURE SENSOR CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect AWD control unit harness connector.
3. Check the continuity between AWD control unit harness connector and AWD solenoid harness connector.

AWD control unit		AWD solenoid		Continuity
Connector	Terminal	Connector	Terminal	
F108	13	F57	6	Existed
	3		7	

4. Check the continuity between AWD control unit harness connector and the ground.

AWD control unit		—	Continuity
Connector	Terminal		
F108	13	Ground	Not existed
	3		

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

## 6.CHECK TERMINALS AND HARNESS CONNECTORS

- Check AWD control unit pin terminals for damage or loose connection with harness connector.
- Check transfer fluid temperature sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace AWD control unit. Refer to [DLN-57, "Removal and Installation"](#).

NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:000000009062065

### 1.CHECK TRANSFER FLUID TEMPERATURE SENSOR

1. Turn ignition switch OFF.
2. Disconnect AWD solenoid harness connector.
3. Check resistance between AWD solenoid connector terminals.

AWD solenoid		Condition	Resistance (Approx.)
Terminal			
6	7	20°C (68°F)	2.5 kΩ
		80°C (176°F)	0.3 kΩ

Is inspection result normal?

YES >> INSPECTION END

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## P1826 TRANSFER FLUID TEMPERATURE

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

---

NO >> Transfer fluid temperature sensor is malfunctioning. Replace electric controlled coupling. Refer to [DLN-74, "Exploded View"](#).

# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

## U1000 CAN COMM CIRCUIT

### Description

INFOID:000000009062066

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit communicate data but selectively reads required data only.

### DTC Logic

INFOID:000000009062067

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	AWD control unit is not transmitting/receiving CAN communication signal for 2 seconds or more.	CAN communication error

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

##### With CONSULT

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

##### Is DTC "U1000" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-43, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000009062068

Proceed to [LAN-16, "Trouble Diagnosis Flow Chart"](#).

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

## U1010 CONTROL UNIT (CAN)

### Description

INFOID:000000009062069

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit communicate data but selectively reads required data only.

### DTC Logic

INFOID:000000009062070

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1010	CONTROL UNIT (CAN)	Detecting error during the initial diagnosis of CAN controller of AWD control unit.	Internal malfunction of AWD control unit

### DTC CONFIRMATION PROCEDURE

#### 1. DTC REPRODUCTION PROCEDURE

##### Ⓔ With CONSULT

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "U1010" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-44, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000009062071

#### 1. CHECK AWD CONTROL UNIT

Check AWD control unit harness connector for disconnection and deformation.

Is the inspection result normal?

- YES >> Replace AWD control unit. Refer to [DLN-57, "Removal and Installation"](#).  
NO >> Repair or replace error-detected parts.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

## POWER SUPPLY AND GROUND CIRCUIT

### Diagnosis Procedure

INFOID:000000009062072

#### 1. CHECK AWD CONTROL UNIT POWER SUPPLY (1)

1. Turn the ignition switch OFF.
2. Disconnect AWD control unit harness connector.
3. Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage (Approx.)
Connector	Terminal		
F108	7	Ground	0 V

4. Turn the ignition switch ON.  
**CAUTION:**  
**Never start the engine.**
5. Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
F108	7	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2. CHECK AWD CONTROL UNIT POWER SUPPLY (2)

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#45).
3. Disconnect IPDM E/R harness connector.
4. Check the continuity between AWD control unit harness connector and IPDM E/R harness connector.

AWD control unit		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F108	7	E5	25	Existed

5. Check the continuity between AWD control unit harness connector and the ground.

AWD control unit		—	Continuity
Connector	Terminal		
F108	7	Ground	Not existed

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for ignition power supply circuit. Refer to [PG-44, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- NO >> Repair or replace error-detected parts.

#### 3. CHECK AWD CONTROL UNIT POWER SUPPLY (3)

1. Turn the ignition switch OFF.
2. Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage (Approx.)
Connector	Terminal		
F108	15	Ground	Battery voltage

3. Turn the ignition switch ON.  
**CAUTION:**

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

**Never start the engine.**

4. Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
F108	15	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

## 4.CHECK AWD CONTROL UNIT POWER SUPPLY (4)

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#11).
3. Disconnect fuse block (J/B) harness connector.
4. Check the continuity between AWD control unit harness connector and fuse block (J/B).

AWD control unit		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
F108	15	M1	1A	Existed

5. Check the continuity between AWD control unit harness connector and the ground.

AWD control unit		—	Continuity
Connector	Terminal		
F108	15	Ground	Not existed

Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit. Refer to [PG-6. "Wiring Diagram - BATTERY POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

## 5.CHECK AWD SOLENOID POWER SUPPLY (1)

1. Turn the ignition switch OFF.
2. Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
F108	9	Ground	Battery voltage

3. Turn the ignition switch ON.

**CAUTION:**

**Never start the engine.**

4. Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
F108	9	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

## 6.CHECK AWD SOLENOID POWER SUPPLY (2)

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#33).

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: ETX13C]

3. Check the harness for open or short between AWD control unit harness connector No.9 terminal and fuse box.

Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit. Refer to [PG-6. "Wiring Diagram - BATTERY POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

## 7. CHECK AWD CONTROL UNIT GROUND

1. Turn the ignition switch OFF.  
2. Check the continuity between AWD control unit harness connector and ground.

AWD control unit		—	Continuity
Connector	Terminal		
F108	10	Ground	Existed
	11		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

## AWD WARNING LAMP

## Component Function Check

INFOID:000000009062073

**1.**CHECK AWD WARNING LAMP FUNCTION

1. Turn the ignition switch ON.
2. Check that AWD warning lamp lights up.

Is the inspection result normal?

YES &gt;&gt; INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [DLN-48, "Diagnosis Procedure"](#).

## Diagnosis Procedure

INFOID:000000009062074

**1.**CHECK POWER SUPPLY AND GROUND CIRCUITPerform the trouble diagnosis for power supply and ground circuit. Refer to [DLN-45, "Diagnosis Procedure"](#).Is the inspection result normal?

YES &gt;&gt; GO TO 2.

NO &gt;&gt; Repair or replace the error-detected parts.

**2.**PERFORM SELF-DIAGNOSIS**Ⓢ**With CONSULT

Perform self-diagnosis for "ALL MODE AWD/4WD".

Is any DTC detected?YES >> Check the DTC. Refer to [DLN-21, "DTC Index"](#).

NO &gt;&gt; GO TO 3.

**3.**CHECK AWD WARNING LAMP SIGNAL**Ⓢ**With CONSULT

1. Turn the ignition switch ON.

**CAUTION:****Never start the engine.**

2. Check "4WD WARN LAMP" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".

Does the item on "DATA MONITOR" indicate "On"?YES >> Perform the trouble diagnosis for combination meter power supply circuit. Refer to [MWI-55, "COMBINATION METER : Diagnosis Procedure"](#).NO >> Replace AWD control unit. Refer to [DLN-57, "Removal and Installation"](#).



# AWD WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

[TRANSFER: ETX13C]

## SYMPTOM DIAGNOSIS

### AWD WARNING LAMP DOES NOT TURN ON

#### Description

INFOID:0000000009062075

AWD warning lamp does not turn ON when the ignition switch is turned to ON.

#### Diagnosis Procedure

INFOID:0000000009062076

#### 1. CHECK AWD WARNING LAMP

Perform the trouble diagnosis for AWD warning lamp. Refer to [DLN-48. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Check each harness connector pin terminal for malfunction or disconnection.
- NO >> Repair or replace the error-detected parts.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# AWD WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

[TRANSFER: ETX13C]

## AWD WARNING LAMP DOES NOT TURN OFF

### Description

INFOID:000000009062077

AWD warning lamp does not turn OFF several seconds after the engine started.

### Description

INFOID:000000009062078

## 1.PERFORM SELF-DIAGNOSIS

### With CONSULT

Perform self-diagnosis for "ALL MODE AWD/4WD".

#### Is any DTC detected?

YES >> Check the DTC. Refer to [DLN-21, "DTC Index"](#).

NO >> GO TO 2.

## 2.CHECK AWD WARNING LAMP

Perform the trouble diagnosis of the AWD warning lamp. Refer to [DLN-48, "Diagnosis Procedure"](#).

#### Is the inspection result normal?

YES >> Check each harness connector pin terminal for malfunction or disconnection.

NO >> Repair or replace the error-detected parts.

# HEAVY TIGHT-CORNER BRAKING SYMPTOM OCCURS

< SYMPTOM DIAGNOSIS >

[TRANSFER: ETX13C]

## HEAVY TIGHT-CORNER BRAKING SYMPTOM OCCURS

### Description

INFOID:000000009062079

Heavy tight-corner braking symptom occurs when the vehicle is driven and the steering wheel is turned fully to either side after the engine is started.

#### NOTE:

Light tight-corner braking symptom may occur depending on driving conditions. This is not malfunction.

### Diagnosis Procedure

INFOID:000000009062080

#### 1. PERFORM ECM SELF-DIAGNOSIS

##### With CONSULT

Perform self-diagnosis for "ENGINE".

##### Is any DTC detected?

- YES >> Check the DTC.
- NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

##### With CONSULT

Perform self-diagnosis for "ALL MODE AWD/4WD".

##### Is DTC "U1000" detected?

- YES >> Proceed to [LAN-16, "Trouble Diagnosis Flow Chart"](#).
- NO >> GO TO 3.

#### 3. CHECK TRANSFER FLUID TEMPERATURE SENSOR

Perform the trouble diagnosis of the transfer fluid temperature sensor. Refer to [DLN-40, "Diagnosis Procedure"](#).

##### Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the error-detected parts.

#### 4. CHECK AWD SOLENOID

Perform the trouble diagnosis of the AWD solenoid. Refer to [DLN-32, "Diagnosis Procedure"](#).

##### Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the error-detected parts.

#### 5. CHECK ELECTRIC CONTROLLED COUPLING

1. Turn the ignition switch OFF.
2. Set the transmission to neutral. Release the parking brake.
3. Lift up the vehicle.
4. Rotate the rear propeller shaft.
5. Hold the front propeller shaft lightly.

##### Does the front propeller shaft rotate?

- YES >> Replace electric controlled coupling for mechanical malfunction (clutch sticking etc.). Refer to [DLN-74, "Exploded View"](#).
- NO >> Check each harness connector pin terminal for disconnection.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# VEHICLE DOES NOT ENTER AWD MODE

< SYMPTOM DIAGNOSIS >

[TRANSFER: ETX13C]

---

## VEHICLE DOES NOT ENTER AWD MODE

### Description

INFOID:000000009062081

Vehicle does not enter 4-wheel drive mode even though AWD warning lamp turned to OFF.

### Diagnosis Procedure

INFOID:000000009062082

#### 1. CHECK AWD WARNING LAMP

---

Turn the ignition switch ON.

Does AWD warning lamp turn ON?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [DLN-49, "Diagnosis Procedure"](#).

#### 2. CRUISE TEST

---

Drive the vehicle for a period of time.

Does any symptom occur?

YES >> Replace electric controlled coupling for mechanical malfunction (mechanical engagement of clutch is not possible). Refer to [DLN-74, "Exploded View"](#).

NO >> Check each harness connector pin terminal for disconnection.

# AWD WARNING LAMP BLINKS QUICKLY

< SYMPTOM DIAGNOSIS >

[TRANSFER: ETX13C]

## AWD WARNING LAMP BLINKS QUICKLY

### Description

INFOID:000000009062083

While driving, AWD warning lamp blinks 2 times in 1 second and it turns OFF after 1 minute.

#### NOTE:

- This symptom protects drivetrain parts when a heavy load is applied to the electric controlled coupling and multiple disc clutch temperature increases. Also, optional distribution of torque sometimes becomes rigid before lamp blinks quickly. Both cases are not malfunction. Refer to [DLN-21, "Protection Function"](#).
- When this symptom occurs, stop vehicle and allow it to idle for some times. Blinking will stop and system will be restored.

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# AWD WARNING LAMP BLINKS SLOWLY

< SYMPTOM DIAGNOSIS >

[TRANSFER: ETX13C]

## AWD WARNING LAMP BLINKS SLOWLY

### Description

INFOID:000000009062084

AWD warning lamp blinks at approximately 2 seconds intervals while driving.

### Diagnosis Procedure

INFOID:000000009062085

#### 1.CHECK TIRE

Check the following.

- Tire pressure
- Wear condition
- Front and rear tire size (There is no difference between front and rear tires.)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts. And then, drive the vehicle at speed of 20 km/h (12 MPH) or more for 5 seconds or more. Improper size information is initialized accordingly.

#### 2.CHECK INPUT SIGNAL OF TIRE DIAMETER

 **With CONSULT**

1. Start the engine.
2. Drive at 20 km/h (12 MPH) or more for approximately 4 minutes.
3. Check "DIS-TIRE MONI" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".

Does the item on "DATA MONITOR" indicate "0 - 4 mm"?

YES >> INSPECTION END

NO >> GO TO 3.

#### 3.TERMINAL INSPECTION

Check AWD control unit harness connector for disconnection.

Is the inspection result normal?

YES >> Replace AWD control unit. Refer to [DLN-57, "Removal and Installation"](#).

NO >> Repair or replace the error-detected parts.

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[TRANSFER: ETX13C]

## NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

### NVH Troubleshooting Chart

INFOID:000000009062086

Use the chart below to find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

Reference		DLN-56. "Inspection"			DLN-64. "Exploded View"		DLN-77. "Inspection"		DLN-77. "Inspection"		DLN-72. "Inspection"						
		TRANSFER FLUID (Level low)			TRANSFER FLUID (Wrong)		TRANSFER FLUID (Level too high)		LIQUID GASKET (Damaged)		OIL SEAL (Worn or damaged)		GEAR (Worn or damaged)		BEARING (Worn or damaged)		TRANSFER CASE (Damaged)
Symptom		Noise	1	2				3	3	3							
		Transfer fluid leakage		4	1	2	2										

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# PERIODIC MAINTENANCE

## TRANSFER FLUID

### Inspection

INFOID:000000009062087

### FLUID LEAKAGE

Check transfer surrounding area (oil seal, drain plug, and filler plug etc.) for fluid leakage.

### FLUID LEVEL

1. Remove filler plug (1) and gasket. Then check that fluid is filled up from mounting hole for the filler plug.


**CAUTION:**

**Never start engine while checking fluid level.**

2. Set a new gasket onto filler plug, and install it on transfer and tighten to the specified torque. Refer to [DLN-64, "Exploded View"](#).

**CAUTION:**

**Never reuse gasket.**




### Draining

INFOID:000000009062088

1. Run the vehicle to warm up the transfer unit sufficiently.
2. Stop the engine, and remove the drain plug (1) to drain the transfer fluid.
3. Set a new gasket onto the drain plug, and install it on the transfer and tighten to the specified torque. Refer to [DLN-64, "Exploded View"](#).

**CAUTION:**

**Never reuse gasket.**



### Refilling

INFOID:000000009062089

1. Remove filler plug (1) and gasket. Then fill fluid up to mounting hole for the filler plug.

**Fluid and viscosity**

: Refer to [MA-10, "Fluids and Lubricants"](#).

**Fluid capacity**

: Refer to [DLN-83, "General Specifications"](#).


**CAUTION:**

**Carefully fill the fluid. (Fill up for approximately 3 minutes.)**

2. Leave the vehicle for 3 minutes, and check the fluid level again.
3. Set a new gasket onto filler plug, and install it on transfer and tighten to the specified torque. Refer to [DLN-64, "Exploded View"](#).

**CAUTION:**

**Never reuse gasket.**





# AWD CONTROL UNIT

< REMOVAL AND INSTALLATION >

[TRANSFER: ETX13C]

## REMOVAL AND INSTALLATION


### AWD CONTROL UNIT

#### Removal and Installation

INFOID:000000009062090

#### REMOVAL

1. Remove the glove box assembly. Refer to [IP-13. "Removal and Installation"](#).
2. Disconnect AWD control unit harness connector.
3. Remove AWD control unit (1) mounting nuts.
4. Remove AWD control unit.



#### INSTALLATION

Install in the reverse order of removal.

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# FRONT OIL SEAL


< REMOVAL AND INSTALLATION >

[TRANSFER: ETX13C]

## FRONT OIL SEAL

Exploded View


INFOID:000000009062091



1. Transfer assembly                      2. Front oil seal

A. Oil seal lip

↔: Vehicle front

: Apply transfer fluid. Refer to [MA-10, "Fluids and Lubricants"](#).

: Apply petroleum jelly.

Refer to [GI-4, "Components"](#) for symbols not described above.

## Removal and Installation

INFOID:000000009062092

### REMOVAL

1. Remove the drain plug to drain the transfer fluid. Refer to [DLN-56, "Draining"](#).
2. Remove the front propeller shaft. Refer to [DLN-87, "Removal and Installation"](#).
3. Remove front oil seal.

#### **CAUTION:**

**Never damage the front case and front drive shaft.**


### INSTALLATION

1. Apply transfer fluid to outside of front oil seal, install it with a drift (A) [SST: ST27862000 ( — )] until the end face of front case.

#### **CAUTION:**

- **Never reuse front oil seal.**
- **Apply petroleum jelly to oil seal lip.**
- **When installing, never incline front oil seal.**

2. Install front propeller shaft. Refer to [DLN-87, "Removal and Installation"](#).
3. Fill with new transfer fluid, check fluid level and for fluid leakage. Refer to [DLN-56, "Inspection"](#).



# REAR OIL SEAL


< REMOVAL AND INSTALLATION >

[TRANSFER: ETX13C]

## REAR OIL SEAL

### Exploded View

INFOID:000000009062093



1. Transfer assembly
2. Rear oil seal
3. Companion flange
4. Self-lock nut
- A. Oil seal lip

⇐: Vehicle front

: Apply transfer fluid. Refer to [MA-10. "Fluids and Lubricants"](#).

: Apply petroleum jelly.

Refer to [GI-4. "Components"](#) for symbols not described above.

## Removal and Installation


INFOID:000000009062094

### REMOVAL

1. Remove the rear propeller shaft. Refer to [DLN-103. "Removal and Installation"](#).
2. Remove self-lock nut of companion flange with a flange wrench (commercial service tool).
3. Put matching mark (A) on the end of the main shaft. The mark should be in line with the mark (B) on the companion flange.

#### **CAUTION:**

**For matching mark, use paint. Never damage main shaft.**




# REAR OIL SEAL

## < REMOVAL AND INSTALLATION >

[TRANSFER: ETX13C]


4. Remove the companion flange with a puller (A) (commercial service tool).

**CAUTION:**  
Never damage the companion flange.



5. Remove the rear oil seal with the puller (A) [SST: KV381054S0 (J-34286)].

**CAUTION:**  
Never damage the rear case.



## INSTALLATION

1. Apply transfer fluid to rear oil seal, install it with the drifts (A and B) within the dimension (L) shown as follows.


A : Drift [SST: ST30720000 (J-25405)]

B : Drift [SST: KV40104830 ( — )]


**L : 6.7 – 7.3 mm (0.264 – 0.287 in)**

**CAUTION:**

- Never reuse rear oil seal.
- Apply petroleum jelly to oil seal lip.
- When installing, never incline rear oil seal.



2. Align the matching mark (A) of main shaft with the mark (B) of companion flange, then install the companion flange.



## REAR OIL SEAL

### < REMOVAL AND INSTALLATION >


[TRANSFER: ETX13C]

- Using a flange wrench (A) (commercial service tool), install the self-lock nut of companion flange and tighten to the specified torque. Refer to [DLN-59, "Exploded View"](#).

**CAUTION:**

**Never reuse self-lock nut.**

- Install the rear propeller shaft. Refer to [DLN-103, "Removal and Installation"](#).
- Check fluid level. Refer to [DLN-56, "Inspection"](#).



A  
B  
C

DLN


E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# UNIT REMOVAL AND INSTALLATION

## TRANSFER ASSEMBLY

### Exploded View

INFOID:000000009062095



1. Transfer assembly

↔: Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000009062096

### REMOVAL

1. Remove rear propeller shaft. Refer to [DLN-103, "Removal and Installation"](#).
2. Remove front propeller shaft. Refer to [DLN-87, "Removal and Installation"](#).
3. Disconnect AWD solenoid harness connector and separate harness from transfer assembly.
4. Remove transfer breather hose.
5. Remove control rod. Refer to [TM-185, "Removal and Installation"](#).
6. Support transfer assembly and transmission assembly with a jack.  
**CAUTION:**  
**Secure transfer assembly and transmission assembly to a jack.**
7. Remove rear engine mounting member and engine mounting insulator with power tool. Refer to [EM-73, "AWD : Removal and Installation"](#).
8. Lower jack to the position where the top transfer mounting bolts can be removed.
9. Remove transfer mounting bolts with power tool and separate transfer from transmission.

### INSTALLATION

Note the following, and install in the reverse order of removal.

# TRANSFER ASSEMBLY

## < UNIT REMOVAL AND INSTALLATION >


[TRANSFER: ETX13C]

- When installing the transfer to the transmission, install the mounting bolts following the standard below, tighten bolts to the specified torque.

Bolt No.	A	B	C	D
Quantity	4	3	4	2
Bolt length " L " mm (in)	75 (2.95)	45 (1.77)	40 (1.57)	30 (1.18)

●:Transfer to transmission.


○:Transmission to transfer.



- When installing transfer air breather hose, make sure there are no pinched or restricted areas on the transfer air breather hose caused by bending or winding.
- Be sure to insert until front side end (A) of air breather hose (1) reaches the end and rear side end (B) reaches the tube bent R.

← : Vehicle front

- After the installation, check the fluid level, fluid leakage and the A/T positions. Refer to [DLN-56, "Inspection"](#).



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# FRONT CASE AND REAR CASE

< UNIT DISASSEMBLY AND ASSEMBLY >


[TRANSFER: ETX13C]

## UNIT DISASSEMBLY AND ASSEMBLY

### FRONT CASE AND REAR CASE

Exploded View

INFOID:000000009062097



- |                                   |                                       |                       |
|-----------------------------------|---------------------------------------|-----------------------|
| 1. Front oil seal                 | 2. Main shaft oil seal                | 3. Breather tube      |
| 4. Front case                     | 5. Front drive shaft front bearing    | 6. Front drive shaft  |
| 7. Front drive shaft rear bearing | 8. Plug                               | 9. Main shaft bearing |
| 10. Snap ring                     | 11. Snap ring                         | 12. Spacer            |
| 13. Steel ball                    | 14. Oil pump                          | 15. Main shaft        |
| 16. Needle bearing                | 17. Sprocket                          | 18. Drive chain       |
| 19. Spacer                        | 20. Snap ring                         | 21. Circlip           |
| 22. Electric controlled coupling  | 23. Oil cover                         | 24. O-ring            |
| 25. Retainer                      | 26. Transfer fluid temperature sensor | 27. Spacer            |
| 28. Baffle plate                  | 29. Dowel pin                         | 30. Snap ring         |
| 31. Rear case                     | 32. Harness bracket                   | 33. Breather tube     |
| 34. Gasket                        | 35. Filler plug                       | 36. Drain plug        |
| 37. Rear bearing                  | 38. Snap ring                         | 39. Spacer            |
| 40. Rear oil seal                 | 41. Companion flange                  | 42. Self-lock nut     |
| A. Oil seal lip                   | B. Matching surface                   |                       |




# FRONT CASE AND REAR CASE

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

: Apply Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).

: Apply petroleum jelly.


: Apply transfer fluid. Refer to [MA-10. "Fluids and Lubricants"](#).

Refer to [GI-4. "Components"](#) for symbols not described above.


## Disassembly

INFOID:000000009062098


1. Remove drain plug and filler plug.
2. Remove harness brackets.
3. Remove main shaft oil seal from front case.  
**CAUTION:**  
**Never damage the front case and main shaft.**
4. Remove front oil seal from front case.  
**CAUTION:**  
**Never damage the front case and front drive shaft.**
5. Remove self-lock nut.
6. Put a matching mark (A) on the end of main shaft. The mark should be in line with the mark (B) on the companion flange.  
**CAUTION:**  
**For the matching mark, use paint. Never damage main shaft.**



7. Remove companion flange with a puller (A) (commercial service tool).  
**CAUTION:**  
**Never damage the companion flange.**



8. Remove rear oil seal from rear case with the puller (A) [SST: KV381054S0 (J-34286)].  
**CAUTION:**  
**Never damage the rear case.**
9. Remove spacer from main shaft.



A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# FRONT CASE AND REAR CASE


< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

10. Remove front case and rear case fixing bolts, then remove harness bracket.


Bolts symbol	Quantity
A	14
T (TORX bolt)	1

\*: With harness bracket.



11. Remove front case (1) from rear case by levering it up with a suitable tool.

**CAUTION:**  
Never damage the mating surface.




12. Remove snap ring (1) from front case.

**CAUTION:**  
Never damage front case.


13. Remove main shaft bearing from front case.

**CAUTION:**  
Never use tools. Always remove by hand.



14. Remove snap ring (1) from main shaft.

**CAUTION:**  
Never damage main shaft.



# FRONT CASE AND REAR CASE

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

15. Remove spacer (1) and steel ball (2) from main shaft.


**CAUTION:**

**Be careful not to drop the steel ball.**


16. Remove Oil pump from main shaft.  
17. Remove drive chain and front drive shaft.

**CAUTION:**


**Never use tools. Always remove by hand.**




18. Remove transfer fluid temperature sensor bolt from rear case. And then, remove transfer fluid temperature sensor (1).




19. Remove oil cover bolts from rear case. And then, remove oil cover (1).  
20. Remove retainer from AWD solenoid harness connector.  
21. Remove AWD solenoid harness connector from rear case.  
22. Remove O-ring from AWD solenoid harness connector.



23. Remove main shaft assembly from rear case with the drift (A) [SST: ST33052000 ( — )].



24. Remove snap ring (1) from rear case.  
25. Remove rear bearing from rear case.  
**CAUTION:**  
**Never use tools. Always remove by hand.**




A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# FRONT CASE AND REAR CASE

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

26. Remove baffle plate (1) from rear case.
27. Remove breather tube from rear case.
28. Remove breather tube from front case.
29. Perform inspection after disassembly. Refer to [DLN-72. "Inspection"](#).



## Assembly



INFOID:000000009062099

1. Install breather tube to front case.  
**CAUTION:**  
**Never reuse breather tube.**
2. Install breather tube to rear case within the angle (A) shown as follows.


**Angle (A) : 80 – 100°**

**CAUTION:**  
**Never reuse breather tube.**

3. Install baffle plate to rear case.
4. Install rear bearing to rear case.  
**CAUTION:**  
**Never use tools. Always install by hand.**
5. Install snap ring (1) to rear case.  
**CAUTION:**  
**Never reuse snap ring.**



6. Install main shaft assembly to rear case with the drift (A) [SST: ST35321000 ( — )].  
**CAUTION:**  
**Apply transfer fluid to the sliding surface of main shaft and needle bearing.**
7. Install O-ring to AWD solenoid harness connector.  
**CAUTION:**
  - **Never reuse O-ring.**
  - **Apply transfer fluid to O-ring.**
8. Install AWD solenoid harness connector into rear case.
9. Install retainer to AWD solenoid harness connector.




# FRONT CASE AND REAR CASE


< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

10. Hold electric controlled coupling harness (1) with oil cover hold plate (2), install oil cover (3) to rear case (4).



11. Install transfer fluid temperature sensor (1) to rear case.



12. Set drive chain to front drive shaft.

**CAUTION:**


Identification mark (A) of drive chain should be in the side of front bearing (1) of front drive shaft.

13. Install drive chain to main shaft, and then install front drive shaft.

**CAUTION:**

Never use tools. Always install by hand.

14. Install oil pump to main shaft.




A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## FRONT CASE AND REAR CASE

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

15. Install spacer (1) and steel ball (2) to main shaft.



16. Install snap ring (1) to main shaft.


**CAUTION:**

- Never reuse snap ring.
- Never damage main shaft.

17. Install main shaft bearing to front case.

**CAUTION:**


Never use tools. Always install by hand.



18. Install snap ring (1) to front case.

**CAUTION:**

- Never reuse snap ring.
- Never damage front case.



19. Apply liquid gasket (1) to mating surface of rear case. Use Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).


**CAUTION:**

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.

20. Set front case to rear case.

**CAUTION:**

Never damage the mating surface transmission side.



# FRONT CASE AND REAR CASE

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

21. Tighten front case and rear case fixing bolts.


Bolts symbol	Quantity
A	14
T (TORX bolt)	1

\*: With harness bracket.

22. Install spacer to main shaft.

**CAUTION:**

**Apply transfer fluid to spacer.**



23. Apply transfer fluid to outside of rear oil seal, and install rear oil seal to rear case with the drifts (A and B) within the dimension (L) shown as follows.


A : Drift [SST: ST30720000 (J-25405)]

B : Drift [SST: KV40104830 ( — )]


**L : 6.7 – 7.3 mm (0.264 – 0.287 in)**

**CAUTION:**

- Never reuse rear oil seal.
- Apply petroleum jelly to oil seal lip.
- When installing, never incline rear oil seal.



24. Install companion flange while aligning the matching mark (A) of main shaft with the mark (B) of companion flange.



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# FRONT CASE AND REAR CASE


< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

25. Tighten self-lock nut to the specified torque with flange wrench (A) (commercial service tool).

**CAUTION:**


**Never reuse self-lock nut.**



26. Apply transfer fluid to outside of main shaft oil seal, and install main shaft oil seal until it is flush with the end face of front case with the drift (A) [SST: ST30720000 (J-25405)].

**CAUTION:**


- **Never reuse main shaft oil seal.**
- **Apply petroleum jelly to oil seal lip.**
- **When installing, never incline main shaft oil seal.**



27. Apply transfer fluid to outside of front oil seal, and install front oil seal until it is flush with the end face of front case with the drift (A) [SST: ST27862000 ( — )].

**CAUTION:**

- **Never reuse front oil seal.**
- **Apply petroleum jelly to oil seal lip.**
- **When installing, never incline front oil seal.**



28. Set gasket to drain plug. Install it to rear case.

**CAUTION:**

**Never reuse gasket.**

29. Set gasket to filler plug. Install it to rear case.

**CAUTION:**

- **Never reuse gasket.**
- **After oil is filled, tighten filler plug to specified torque.**

## Inspection


INFOID:000000009062100

### INSPECTION AFTER DISASSEMBLY

Check items below. If necessary, replace them with new ones.

#### Cases

- Contact surfaces of bearing for wear, damage, etc.
- Damage and cracks of case.



#### Bearing




# FRONT CASE AND REAR CASE

< UNIT DISASSEMBLY AND ASSEMBLY >


[TRANSFER: ETX13C]

Damage and rough rotation of bearing.




Shaft

Damage, peeling, dent, uneven wear, bending, etc. of shaft.



Gears and Chain

- Excessive wear, damage, peeling, etc. of gear and chain.
- Cracks, damage, wear, etc of drive chain.



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# MAIN SHAFT


< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

## MAIN SHAFT

### Exploded View

INFOID:00000009363919




- |                                   |                                       |                       |
|-----------------------------------|---------------------------------------|-----------------------|
| 1. Front oil seal                 | 2. Main shaft oil seal                | 3. Breather tube      |
| 4. Front case                     | 5. Front drive shaft front bearing    | 6. Front drive shaft  |
| 7. Front drive shaft rear bearing | 8. Plug                               | 9. Main shaft bearing |
| 10. Snap ring                     | 11. Snap ring                         | 12. Spacer            |
| 13. Steel ball                    | 14. Oil pump                          | 15. Main shaft        |
| 16. Needle bearing                | 17. Sprocket                          | 18. Drive chain       |
| 19. Spacer                        | 20. Snap ring                         | 21. Circlip           |
| 22. Electric controlled coupling  | 23. Oil cover                         | 24. O-ring            |
| 25. Retainer                      | 26. Transfer fluid temperature sensor | 27. Spacer            |
| 28. Baffle plate                  | 29. Dowel pin                         | 30. Snap ring         |
| 31. Rear case                     | 32. Harness bracket                   | 33. Breather tube     |
| 34. Gasket                        | 35. Filler plug                       | 36. Drain plug        |
| 37. Rear bearing                  | 38. Snap ring                         | 39. Spacer            |
| 40. Rear oil seal                 | 41. Companion flange                  | 42. Self-lock nut     |
| A. Oil seal lip                   | B. Matching surface                   |                       |


: Apply Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

# MAIN SHAFT

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

: Apply petroleum jelly.


: Apply transfer fluid. Refer to [MA-10. "Fluids and Lubricants"](#).

Refer to [GI-4. "Components"](#) for symbols not described above.


## Disassembly

INFOID:000000009062102


1. Separate front case and rear case, then remove main shaft assembly. Refer to [DLN-65. "Disassembly"](#).
2. Remove snap ring (1) from main shaft.



3. Remove spacer (1) and steel ball (2) from main shaft.  
**CAUTION:**  
Be careful not to drop the steel ball.



4. Using a press, remove electric controlled coupling from main shaft.




5. Remove circlip (1) from notch (A) of electric controlled coupling.

: Front side

### CAUTION:

- Never remove the circlip from the electric controlled coupling rear side.
- Never damage electric control coupling spline, bush, etc.

6. Remove snap ring from main shaft.




A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# MAIN SHAFT

## < UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]


- Remove spacer (1) and steel ball (2) from main shaft.  
**CAUTION:**  
**Be careful not to drop the steel ball.**
- Remove sprocket from main shaft.
- Remove needle bearing from main shaft.
- Perform inspection after disassembly. Refer to [DLN-77, "Inspection"](#).



INFOID:000000009062103

## Assembly


- Install needle bearing to main shaft.  
**CAUTION:**  
**Apply transfer fluid to the periphery of needle bearing.**
- Install sprocket to main shaft.
- Install spacer (1) and steel ball (2) to main shaft.  
**CAUTION:**  
**Be careful not to drop the steel ball.**
- Install snap ring to main shaft.  
**CAUTION:**  
**Never reuse snap ring.**
- Install circlip (1) to notch (A) of the electric controlled coupling.




⇐:Front side

### **CAUTION:**

- Never install the circlip to the notches other than notch (A).
- Never install the circlip from the electric controlled coupling rear side.
- Never reduce the outer diameter of circlip to less than 43.2 mm (1.701 in).
- Never damage electric control coupling spline, bush, etc.
- Never reuse circlip.



- Install electric controlled coupling to main shaft.  
**CAUTION:**  
**Securely insert it until locked.**
- Install spacer (1) and steel ball (2) to main shaft.  
**CAUTION:**  
**Be careful not to drop the steel ball.**




# MAIN SHAFT

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

8. Install snap ring (1) to main shaft.  
**CAUTION:**  
**Never reuse snap ring.**
9. Install main shaft assembly to rear case, then install front case and rear case. Refer to [DLN-68, "Assembly"](#).



INFOID:000000009062104


## Inspection

### INSPECTION AFTER DISASSEMBLY

Check items below. If necessary, replace them with new ones.


#### Cases

- Contact surfaces of bearing for wear, damage, etc.
- Damage and cracks of case.




#### Bearing

Damage and rough rotation of bearing.



#### Shaft

Damage, peeling, dent, uneven wear, bending, etc. of shaft.




#### Gears and Chain

## MAIN SHAFT

### < UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

- Excessive wear, damage, peeling, etc. of gear and chain.
- Cracks, damage, wear, etc of drive chain.



# FRONT DRIVE SHAFT AND DRIVE CHAIN


< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

## FRONT DRIVE SHAFT AND DRIVE CHAIN

Exploded View

INFOID:000000009363922




- |                                   |                                       |                       |
|-----------------------------------|---------------------------------------|-----------------------|
| 1. Front oil seal                 | 2. Main shaft oil seal                | 3. Breather tube      |
| 4. Front case                     | 5. Front drive shaft front bearing    | 6. Front drive shaft  |
| 7. Front drive shaft rear bearing | 8. Plug                               | 9. Main shaft bearing |
| 10. Snap ring                     | 11. Snap ring                         | 12. Spacer            |
| 13. Steel ball                    | 14. Oil pump                          | 15. Main shaft        |
| 16. Needle bearing                | 17. Sprocket                          | 18. Drive chain       |
| 19. Spacer                        | 20. Snap ring                         | 21. Circlip           |
| 22. Electric controlled coupling  | 23. Oil cover                         | 24. O-ring            |
| 25. Retainer                      | 26. Transfer fluid temperature sensor | 27. Spacer            |
| 28. Baffle plate                  | 29. Dowel pin                         | 30. Snap ring         |
| 31. Rear case                     | 32. Harness bracket                   | 33. Breather tube     |
| 34. Gasket                        | 35. Filler plug                       | 36. Drain plug        |
| 37. Rear bearing                  | 38. Snap ring                         | 39. Spacer            |
| 40. Rear oil seal                 | 41. Companion flange                  | 42. Self-lock nut     |
- A. Oil seal lip  
B. Matching surface


Apply Genuine Anaerobic Liquid Gasket or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

# FRONT DRIVE SHAFT AND DRIVE CHAIN

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

: Apply petroleum jelly.

: Apply transfer fluid. Refer to [MA-10, "Fluids and Lubricants"](#).

Refer to [GI-4, "Components"](#) for symbols not described above.

## Disassembly

INFOID:000000009062106

1. Separate front case and rear case. Refer to [DLN-65, "Disassembly"](#).
2. Remove drive chain and front drive shaft.


### CAUTION:

**Never use tools. Always remove by hand.**

3. Remove front drive shaft front bearing with the drift (A) and replacer (B).

A: Drift [SST: ST31214000 (J-25269-B)]


B: Replacer (commercial service tool)



4. Remove front drive shaft rear bearing with the drift (A) and replacer (B).

A: Drift [SST: ST31214000 (J-25269-B)]

B: Replacer (commercial service tool)



5. Remove plug from front drive shaft.

6. Perform inspection after disassembly. Refer to [DLN-81, "Inspection"](#).

## Assembly


INFOID:000000009062107

1. Install plug to front drive shaft.

### CAUTION:

**Never reuse plug.**

2. Install front drive shaft front bearing with the drift (A) [SST: ST33200000 (J-26082)].






# FRONT DRIVE SHAFT AND DRIVE CHAIN

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: ETX13C]

3. Install front drive shaft rear bearing with the drift (A) [SST: KV38104010 ( — )].



4. Set drive chain to front drive shaft.

**CAUTION:**


Identification mark (A) of drive chain should be in the side of front bearing (1) of front drive shaft.

5. Install drive chain to main shaft, and then install front drive shaft.

**CAUTION:**

Never use tools. Always install by hand.

6. Install front case to rear case. Refer to [DLN-68, "Assembly"](#).



INFOID:000000009062108


## Inspection

### INSPECTION AFTER DISASSEMBLY

Check items below. If necessary, replace them with new ones.


#### Cases

- Contact surfaces of bearing for wear, damage, etc.
- Damage and cracks of case.



#### Bearing

Damage and rough rotation of bearing.




#### Shaft

## FRONT DRIVE SHAFT AND DRIVE CHAIN

< UNIT DISASSEMBLY AND ASSEMBLY >


[TRANSFER: ETX13C]

Damage, peeling, dent, uneven wear, bending, etc. of shaft.



Gears and Chain

- Excessive wear, damage, peeling, etc. of gear and chain.
- Cracks, damage, wear, etc of drive chain.



# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[TRANSFER: ETX13C]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### General Specifications

INFOID:0000000009062109

Applied model	AWD
	VQ37VHR
	A/T
Transfer model	ETX13C
Fluid capacity (Approx.)	<i>ℓ</i> (US pt, Imp pt) 1.0 (2-1/8, 1-3/4)

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[FRONT PROPELLER SHAFT: 2S56A]

## SYMPTOM DIAGNOSIS

### NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

#### NVH Troubleshooting Chart

INFOID:000000009062110

Use the chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Reference		DLN-86, "Inspection"	—	—	—	—	DLN-88, "Inspection"	DLN-88, "Inspection"	NVH of FRONT and REAR FINAL DRIVE in this section.	NVH in FAX, RAX, FSU and RSU section.	NVH in WT section.	NVH in WT section.	NVH in FAX and RAX section.	NVH in BR section.	NVH in ST section.
Possible cause and SUSPECTED PARTS		Uneven rotating torque	Center bearing improper installation	Excessive center bearing axial end play	Center bearing mounting (insulator) cracks, damage or deterioration	Excessive joint angle	Rotation imbalance	Excessive runout	DIFFERENTIAL	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING
Symptom	Noise	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	Shake		x			x				x	x	x	x	x	x
	Vibration	x	x	x	x	x	x	x	x	x	x	x	x		x

x: Applicable

# PREPARATION

< PREPARATION >


[FRONT PROPELLER SHAFT: 2S56A]

## PREPARATION

### PREPARATION

#### Commercial Service Tools

INFOID:000000009062111

Tool name	Description
<p data-bbox="164 411 272 436">Power tool</p>  <p data-bbox="829 632 901 646">PBIC0190E</p>	<p data-bbox="1011 411 1263 436">Loosening bolts and nuts</p>

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# FRONT PROPELLER SHAFT

< PERIODIC MAINTENANCE >

[FRONT PROPELLER SHAFT: 2S56A]

## PERIODIC MAINTENANCE

### FRONT PROPELLER SHAFT

#### Inspection

INFOID:000000009062112

#### APPEARANCE AND NOISE

- Check the propeller shaft tube surface for dents or cracks. If damaged, replace propeller shaft assembly.
- If center bearing is noisy or damaged, replace propeller shaft assembly.


#### VIBRATION

If vibration is present at high speed, inspect propeller shaft runout first.

1. With a dial indicator, measure propeller shaft runout at runout measuring points by rotating final drive companion flange with hands.

↔ : Vehicle Front


**Propeller shaft runout** : Refer to [DLN-90, "Propeller Shaft Runout"](#).



- Propeller shaft runout measuring point (Point "△")

**Dimension** A: 381.5 mm (15.02 in)

2. If runout still exceeds specifications, separate propeller shaft at final drive companion flange; then change the phase between companion flange and propeller shaft by the one bolt hole at a time and install propeller shaft.
3. Check runout again. If runout still exceeds specifications, replace propeller shaft assembly.
4. Check the vibration by driving vehicle.



# FRONT PROPELLER SHAFT

< REMOVAL AND INSTALLATION >


[FRONT PROPELLER SHAFT: 2S56A]

## REMOVAL AND INSTALLATION

### FRONT PROPELLER SHAFT

Exploded View

INFOID:000000009062113



1. O-ring
2. Propeller shaft assembly

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000009062114

#### REMOVAL

1. Shift the transmission to the neutral position, and then release the parking brake.
2. Remove engine undercover with a power tool.
3. Remove front cross bar.
4. Remove the three-way catalyst (right bank) with a power tool. Refer to [EX-5, "Exploded View"](#).
5. Put matching mark onto propeller shaft flange yoke and final drive companion flange.

#### **CAUTION:**


**For matching mark, use paint. Never damage propeller shaft flange and final drive companion flange.**

6. Remove the propeller shaft assembly fixing bolts.
7. Remove propeller shaft assembly from the front final drive and transfer.

#### **CAUTION:**

**Never damage the transfer front oil seal.**

8. Hang steering hydraulic line not to interfere with work. Refer to [ST-52, "AWD : Exploded View"](#).
9. Remove propeller shaft assembly from O-ring.



#### INSTALLATION

Note the following, and install in the reverse order of removal.

# FRONT PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[FRONT PROPELLER SHAFT: 2S56A]

- Align matching mark to install propeller shaft assembly to final drive companion flange.
- Perform inspection after installation. Refer to [DLN-88, "Inspection"](#).

## CAUTION:

- Never damage the transfer front oil seal.
- Never reuse O-ring.
- Apply multi-purpose grease onto O-ring.



INFOID:000000009062115

## Inspection

### INSPECTION AFTER REMOVAL


#### Appearance

Check propeller shaft for bend and damage. If damage is detected, replace propeller shaft assembly.

#### Propeller Shaft Runout


Check propeller shaft runout at measuring point with a dial indicator. If runout exceeds specifications, replace propeller shaft assembly.

**Propeller shaft runout** : Refer to [DLN-90, "Propeller Shaft Runout"](#).



- Propeller shaft runout measuring point (Point "Δ")

**Dimension** **A: 381.5 mm (15.02 in)**




#### Journal Axial Play

As shown in the figure, while fixing yoke on one side, check axial play of joint. If it is outside the standard, replace propeller shaft assembly.

**Journal axial play** : Refer to [DLN-90, "Journal Axial Play"](#).

## CAUTION:

Never disassemble joints.



### INSPECTION AFTER INSTALLATION

After assembly, perform a driving test to check propeller shaft vibration. If vibration occurred, separate propeller shaft from final drive. Reinstall companion flange by changing the phase between companion flange and



# FRONT PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[FRONT PROPELLER SHAFT: 2S56A]

propeller shaft by the one bolt hole at a time. Then perform driving test and check propeller shaft vibration again at each point.

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[FRONT PROPELLER SHAFT: 2S56A]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### General Specifications

INFOID:000000009062116

Applied model	AWD
	VQ37VHR
	A/T
Propeller shaft model	2S56A
Number of joints	2
Type of journal bearings (Non-disassembly type)	Shell type
Coupling method with transfer	Sleeve type
Coupling method with front final drive	Flange type
Shaft length (Spider to spider)	763 mm (30.04 in)
Shaft outer diameter	42.7 mm (1.681 in)

#### Propeller Shaft Runout

INFOID:000000009062117

Unit: mm (in)

Item	Limit
Propeller shaft runout	0.8 (0.031)

#### Journal Axial Play

INFOID:000000009062118

Unit: mm (in)

Item	Standard
Journal axial play	0 (0)

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[REAR PROPELLER SHAFT: 3S80A-R]

## SYMPTOM DIAGNOSIS

### NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

#### NVH Troubleshooting Chart

INFOID:000000009062119

Use the chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Symptom		Possible cause and SUSPECTED PARTS													
		Uneven rotating torque	Center bearing improper installation	Excessive center bearing axial end play	Center bearing mounting (insulator) cracks, damage or deterioration	Excessive joint angle	Rotation imbalance	Excessive runout	DIFFERENTIAL	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING
Noise	Noise	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	Shake		x			x				x	x	x	x	x	x
	Vibration	x	x	x	x	x	x	x		x	x	x			x
Reference		DLN-93, "Inspection"	DLN-97, "Inspection"	—	DLN-97, "Inspection"	—	DLN-97, "Inspection"	DLN-97, "Inspection"	NVH of REAR FINAL DRIVE in this section.	NVH in FAX, RAX, FSU and RSU section.	NVH in WT section.	NVH in WT section.	NVH in RAX section.	NVH in BR section.	NVH in ST section.

x: Applicable

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# PREPARATION

< PREPARATION >


[REAR PROPELLER SHAFT: 3S80A-R]

## PREPARATION

### PREPARATION

#### Commercial Service Tools

INFOID:000000009062120

Tool name	Description
<p data-bbox="162 415 272 441">Power tool</p>  <p data-bbox="828 630 901 646">PBIC0190E</p>	<p data-bbox="1011 415 1263 441">Loosening bolts and nuts</p>

# REAR PROPELLER SHAFT

< PERIODIC MAINTENANCE >

[REAR PROPELLER SHAFT: 3S80A-R]

## PERIODIC MAINTENANCE

### REAR PROPELLER SHAFT

#### Inspection

INFOID:000000009062121

#### APPEARANCE AND NOISE


- Check the propeller shaft tube surface for dents or cracks. If damaged, replace propeller shaft assembly.
- If center bearing is noisy or damaged, replace propeller shaft assembly.

#### VIBRATION

If vibration is present at high speed, inspect propeller shaft runout first.

1. With a dial indicator, measure propeller shaft runout at runout measuring points by rotating final drive companion flange with hands.


**Propeller shaft runout** : Refer to [DLN-99, "Propeller Shaft Runout"](#).



- Propeller shaft runout measuring point (Point "△")

↔ : Vehicle Front

**Dimension**  
**A: 192 mm (7.56 in)**  
**B: 172 mm (6.77 in)**  
**C: 172 mm (6.77 in)**



2. If runout still exceeds specifications, separate propeller shaft at final drive companion flange; then change the phase between companion flange and propeller shaft by the one bolt hole at a time and install propeller shaft.
3. Check runout again. If runout still exceeds specifications, replace propeller shaft assembly.
4. Check the vibration by driving vehicle.

# REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >


[REAR PROPELLER SHAFT: 3S80A-R]

## REMOVAL AND INSTALLATION

### REAR PROPELLER SHAFT

Exploded View

INFOID:000000009062122



1. Clip
2. Center bearing mounting bracket (upper)
3. Propeller shaft assembly
4. Center bearing mounting bracket (lower)

←: Vehicle front


Refer to [GI-4, "Components"](#) for symbols in the figure.

## Removal and Installation

INFOID:000000009062123

### REMOVAL

1. Shift the transmission to the neutral position, and then release the parking brake.
2. Remove the floor reinforcement.
3. Remove the center muffler with power tool. Refer to [EX-5, "Exploded View"](#).
4. Remove the heat insulator (1).



# REAR PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 3S80A-R]

5. Put matching marks (↔) onto propeller shaft rubber coupling and final drive companion flange.

**CAUTION:**

For matching marks, use paint. Never damage propeller shaft rubber coupling and final drive companion flange.




6. Loosen mounting nuts (1) of center bearing mounting brackets (upper/lower).

↔ : Vehicle front

**CAUTION:**


Tighten mounting nuts temporarily.



7. Remove propeller shaft assembly fixing bolts and nuts (↔).

**CAUTION:**


Never remove the rubber coupling from the propeller shaft assembly.



8. Slightly separate the rubber coupling (1) from the final drive companion flange (2).

**CAUTION:**

Never damage the final drive companion flange and rubber coupling.




9. Remove center bearing mounting bracket fixing nuts.

**CAUTION:**

- The angle (A), which the third axis rubber coupling (1) forms with the final drive companion flange (2), must be 5° or less.
- Never damage the grease seal (3).
- Never damage the rubber coupling.

10. Slide the propeller shaft in the vehicle forward direction slightly. Separate the propeller shaft from the final drive companion flange.

**CAUTION:**



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 3S80A-R]

- The angle, which the third axis rubber coupling forms with the final drive companion flange, must be 5° or less.
- Never damage the grease seal.
- Never damage the rubber coupling.

11. Remove the propeller shaft assembly from the vehicle.

**CAUTION:**


**Never damage the rear oil seal of transmission.**

12. Remove clip and center bearing mounting bracket (upper/lower).


## INSTALLATION

Note the following, and install in the reverse order of removal.


- Install center bearing mounting bracket (upper) (1) with its arrow mark (A) facing forward.
- Adjust position of center bearing mounting bracket (upper), center bearing mounting bracket (lower) (2) sliding back and forth to prevent play in thrust direction of center bearing insulator (3). Install center bearing mounting bracket (upper/lower) to vehicle.



- Align matching marks to install propeller shaft rubber coupling to final drive companion flange.
- Perform inspection after installation. Refer to [DLN-97, "Inspection"](#).



- If propeller shaft or final drive has been replaced, connect them as follows:
  - Install the propeller shaft (1) while aligning its matching mark (A) with the matching mark (B) on the joint as close as possible.






# REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 3S80A-R]

**CAUTION:**

- The angle (A), which the third axis rubber coupling (1) forms with the final drive companion flange (2), must be 5° or less.
- Never damage the grease seal (3).
- Never damage the rubber coupling.
- Never damage the rear oil seal of transmission.
- Never damage the rubber coupling, protect it with a shop towel or equivalent.



## Inspection

INFOID:000000009062124

### INSPECTION AFTER REMOVAL


#### Appearance

Check propeller shaft for bend and damage. If damage is detected, replace propeller shaft assembly.

#### Propeller Shaft Runout

Check propeller shaft runout at measuring points with a dial indicator. If runout exceeds specifications, replace propeller shaft assembly.


**Propeller shaft runout** : Refer to [DLN-99, "Propeller Shaft Runout"](#).



- Propeller shaft runout measuring point (Point "△")

← : Vehicle Front

**Dimension**  
**A: 192 mm (7.56 in)**  
**B: 172 mm (6.77 in)**  
**C: 172 mm (6.77 in)**




#### Journal Axial Play

As shown in the figure, while fixing yoke on one side, check axial play of joint. If it is outside the standard, replace propeller shaft assembly.

**Journal axial play** : Refer to [DLN-99, "Journal Axial Play"](#).

**CAUTION:**  
**Never disassemble joints.**



#### Center Bearing

Check center bearing for noise and damage. If noise or damage is detected, replace propeller shaft assembly.

**CAUTION:**

## REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 3S80A-R]

---

**Never disassemble center bearing.**

### INSPECTION AFTER INSTALLATION

After assembly, perform a driving test to check propeller shaft vibration. If vibration occurred, separate propeller shaft from final drive. Reinstall companion flange by changing the phase between companion flange and propeller shaft by the one bolt hole at a time. Then perform driving test and check propeller shaft vibration again at each point.

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REAR PROPELLER SHAFT: 3S80A-R]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### General Specifications

INFOID:0000000009062125

Applied model		2WD
		VQ37VHR
		A/T
Propeller shaft model		3S80A-R
Number of joints		3
Type of journal bearings (Non-disassembly type)	1st joint	Shell type
	2nd joint	Shell type
	3rd joint	Rubber coupling type
Coupling method with transmission		Sleeve type
Coupling method with rear final drive		Rubber coupling type
Shaft length	1st (Spider to spider)	697 mm (27.44 in)
	2nd (Spider to rubber coupling center)	722 mm (28.43 in)
Shaft outer diameter	1st	82.6 mm (3.252 in)
	2nd	75.0 mm (2.953 in)

#### Propeller Shaft Runout

INFOID:0000000009062126

Unit: mm (in)

Item	Limit
Propeller shaft runout	0.8 (0.031)

#### Journal Axial Play

INFOID:0000000009062127

Unit: mm (in)

Item	Standard
Journal axial play	0 (0)

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[REAR PROPELLER SHAFT: 3F80A-1VL107]

## SYMPTOM DIAGNOSIS

### NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

#### NVH Troubleshooting Chart

INFOID:000000009062128

Use the chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Reference		DLN-102. "Inspection"	DLN-106. "Inspection"	—	DLN-106. "Inspection"	—	DLN-106. "Inspection"	DLN-106. "Inspection"	NVH of FRONT and REAR FINAL DRIVE in this section.	NVH in FAX, RAX, FSU and RSU section.	NVH in WT section.	NVH in WT section.	NVH in FAX and RAX section.	NVH in BR section.	NVH in ST section.
Possible cause and SUSPECTED PARTS		Uneven rotating torque	Center bearing improper installation	Excessive center bearing axial end play	Center bearing mounting (insulator) cracks, damage or deterioration	Excessive joint angle	Rotation imbalance	Excessive runout	DIFFERENTIAL	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING
Symptom	Noise	x	x	x	x	x	x	x	x	x	x	x	x	x	x
	Shake		x			x				x	x	x	x	x	x
	Vibration	x	x	x	x	x	x	x		x	x		x		x

x: Applicable

# PREPARATION

[REAR PROPELLER SHAFT: 3F80A-1VL107]


< PREPARATION >

## PREPARATION

### PREPARATION

#### Commercial Service Tools

INFOID:000000009062129

Tool name	Description
<p data-bbox="164 413 272 438">Power tool</p>  <p data-bbox="829 632 901 646">PBIC0190E</p>	<p data-bbox="1011 413 1263 441">Loosening bolts and nuts</p>

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# REAR PROPELLER SHAFT

< PERIODIC MAINTENANCE >

[REAR PROPELLER SHAFT: 3F80A-1VL107]

## PERIODIC MAINTENANCE

### REAR PROPELLER SHAFT

#### Inspection

INFOID:000000009062130

#### APPEARANCE AND NOISE


- Check the propeller shaft tube surface for dents or cracks. If damaged, replace propeller shaft assembly.
- If center bearing is noisy or damaged, replace propeller shaft assembly.

#### VIBRATION

If vibration is present at high speed, inspect propeller shaft runout first.

1. With a dial indicator, measure propeller shaft runout at runout measuring points by rotating final drive companion flange with hands.

**Propeller shaft runout** : Refer to [DLN-108, "Propeller Shaft Runout"](#).




- Propeller shaft runout measuring point (Point "△")

↔ : Vehicle Front

**Dimension**

**A: 162 mm (6.38 in)**  
**B: 245 mm (9.65 in)**  
**C: 185 mm (7.28 in)**



2. If runout still exceeds specifications, separate propeller shaft at final drive companion flange or transfer companion flange; then change the phase between companion flange and propeller shaft by the one bolt hole at a time and install propeller shaft.
3. Check runout again. If runout still exceeds specifications, replace propeller shaft assembly.
4. Check the vibration by driving vehicle.

# REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >


[REAR PROPELLER SHAFT: 3F80A-1VL107]

## REMOVAL AND INSTALLATION

### REAR PROPELLER SHAFT

#### Exploded View

INFOID:000000009062131



1. Propeller shaft assembly
2. Clip
3. Center bearing mounting bracket (upper)
4. Center bearing mounting bracket (lower)

←: Vehicle front


Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000009062132

#### REMOVAL

1. Shift the transmission to the neutral position, and release the parking brake.
2. Remove the floor reinforcement.
3. Remove the center muffler with power tool. Refer to [EX-5, "Exploded View"](#).
4. Remove the heat insulator (1).



## REAR PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 3F80A-1VL107]

5. Put matching marks (A) on propeller shaft flange yoke and transfer companion flange.

**CAUTION:**


**For matching marks, use paint. Never damage propeller shaft flange yoke and transfer companion flange.**



6. Put matching marks (A) on propeller shaft rebro joint and final drive companion flange.

**CAUTION:**

**For matching marks, use paint. Never damage propeller shaft rebro joint and final drive companion flange.**



7. Loosen mounting nuts (1) of center bearing mounting brackets (upper/lower).

**CAUTION:**


**Tighten mounting nuts temporarily.**

⇐ : Vehicle front

8. Remove propeller shaft assembly fixing bolts and nuts.  
9. Remove center bearing mounting bracket fixing nuts.  
10. Remove propeller shaft assembly.

**CAUTION:**

**If constant velocity joint was bent during propeller shaft assembly removal, installation, or transportation, its boot may be damaged. Wrap boot interference area to metal part with shop cloth or rubber to protect boot from breakage.**



### INSTALLATION

Note the following, and install in the reverse order of removal.




# REAR PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 3F80A-1VL107]


- Install center bearing mounting bracket (upper) (1) with its arrow mark (A) facing forward.
- Adjust position of center bearing mounting bracket (upper), center bearing mounting bracket (lower) (2) sliding back and forth to prevent play in thrust direction of center bearing insulator (3). Install center bearing mounting bracket (upper/lower) to vehicle.



- Align matching marks (A) to install propeller shaft flange yoke and transfer companion flange.



- Align matching marks (A) to install propeller shaft rebro joint and final drive companion flange.



**CAUTION:**

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 3F80A-1VL107]

Tighten mounting bolt and nut in the order shown in the figure.


- Perform inspection after removal. Refer to [DLN-106, "Inspection"](#).



- If propeller shaft or final drive has been replaced, connect them as follows:
- Install the propeller shaft while aligning its matching mark (A) with the matching mark (B) on the joint as close as possible.

**CAUTION:**

Avoid damaging the rebro joint boot, protect it with a shop towel or equivalent.



## Inspection

INFOID:000000009062133

### INSPECTION AFTER REMOVAL


#### Appearance

Check propeller shaft for bend and damage. If damage is detected, replace propeller shaft assembly.

#### Propeller Shaft Runout

Check propeller shaft runout at measuring points with a dial indicator. If runout exceeds specifications, replace propeller shaft assembly.

**Propeller shaft runout** : Refer to [DLN-108, "Propeller Shaft Runout"](#).




- Propeller shaft runout measuring point (Point "Δ")

↔ : Vehicle Front

**Dimension**

**A: 162 mm (6.38 in)**  
**B: 245 mm (9.65 in)**  
**C: 185 mm (7.28 in)**



#### Journal Axial Play

## REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 3F80A-1VL107]


As shown in the figure, while fixing yoke on one side, check axial play of joint. If it is outside the standard, replace propeller shaft assembly.

**Journal axial play**

: Refer to [DLN-108, "Journal Axial Play"](#).

**CAUTION:**

**Never disassemble joints.**



Center Bearing

Check center bearing for noise and damage. If noise or damage is detected, replace propeller shaft assembly.

**CAUTION:**

**Never disassemble center bearing.**

### INSPECTION AFTER INSTALLATION

After assembly, perform a driving test to check propeller shaft vibration. If vibration occurred, separate propeller shaft from final drive or transfer. Reinstall companion flange by changing the phase between companion flange and propeller shaft by the one bolt hole at a time. Then perform driving test and check propeller shaft vibration again at each point.

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REAR PROPELLER SHAFT: 3F80A-1VL107]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### General Specifications

INFOID:000000009062134

Applied model		AWD
		VQ37VHR
		A/T
Propeller shaft model		3F80A-1VL107
Number of joints		3
Type of journal bearings (Non-disassembly type)	1st joint	Shell type
	2nd joint	Shell type
	3rd joint	Rebro joint type
Coupling method with transmission		Flange type
Coupling method with rear final drive		Rebro joint type
Shaft length	1st (Spider to spider)	435 mm (17.12 in)
	2nd (Spider to spider)	706 mm (27.80 in)
Shaft outer diameter	1st	82.6 mm (3.252 in)
	2nd	75.0 mm (2.953 in)

#### Propeller Shaft Runout

INFOID:000000009062135

Unit: mm (in)

Item	Limit
Propeller shaft runout	0.8 (0.031)

#### Journal Axial Play

INFOID:000000009062136

Unit: mm (in)

Item	Standard
Journal axial play	0 (0)

# FRONT FINAL DRIVE ASSEMBLY

< SYSTEM DESCRIPTION >

[FRONT FINAL DRIVE: F160A]


## SYSTEM DESCRIPTION

### FRONT FINAL DRIVE ASSEMBLY

#### System Diagram

INFOID:000000009062137

#### CROSS-SECTIONAL VIEW



- |                         |                             |                          |
|-------------------------|-----------------------------|--------------------------|
| 1. Side retainer        | 2. Side bearing             | 3. Differential case     |
| 4. Drive gear           | 5. Pinion mate shaft        | 6. Pinion mate gear      |
| 7. Side gear            | 8. Side shaft               | 9. Gear carrier          |
| 10. Drive pinion        | 11. Companion flange        | 12. Pinion front bearing |
| 13. Pinion rear bearing | 14. Extension tube retainer | 15. Engine assembly      |

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[FRONT FINAL DRIVE: F160A]

## SYMPTOM DIAGNOSIS

### NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

#### NVH Troubleshooting Chart

INFOID:000000009062138

Use the chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Symptom	Noise													
Reference														
Possible cause and SUSPECTED PARTS														
		Gear tooth rough	Gear contact improper	Tooth surfaces worn	Backlash incorrect	Companion flange excessive runout	Gear oil improper	PROPELLER SHAFT	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING
		DLN-137, "Inspection After Disassembly"	DLN-132, "Adjustment"	DLN-137, "Inspection After Disassembly"	DLN-132, "Adjustment"	DLN-132, "Adjustment"	DLN-115, "Inspection"	NVH of FRONT and REAR PROPELLER SHAFT in this section.	NVH in FAX, RAX, FSU and RSU sections.	NVH in WT section.	NVH in WT section.	NVH in FAX and RAX section.	NVH in BR section.	NVH in ST section.
	×	×	×	×	×	×	×	×	×	×	×	×	×	×

×: Applicable

PRECAUTION

PRECAUTIONS

Service Notice or Precautions for Front Final Drive

INFOID:000000009062139

- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they never interfere with the function of the parts when applied.
- Overhaul should be done in a clean work area, it is preferable to work in dustproof area.
- Before disassembly, using steam or white gasoline, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with new ones if necessary.
- Gaskets, seals and O-rings should be replaced any time when the unit is disassembled.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, observe it.
- Clean and flush the parts sufficiently and blow-dry them.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mounting surface; then remove any moisture, oil, and foreign materials from the application and mounting surfaces.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or shop rags to prevent entering of lint.
- During assembly, observe the specified tightening torque, and apply new gear oil, petroleum jelly, or multi-purpose grease as specified for each vehicle, if necessary.

**NOTE:**

Front oil seal cannot be replaced on vehicle, because there is not enough room.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



# PREPARATION

< PREPARATION >

[FRONT FINAL DRIVE: F160A]







## PREPARATION

### PREPARATION

#### Special Service Tools

INFOID:000000009062140

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.







Tool number (Kent-Moore No.) Tool name	Description
KV381054S0 (J-34286) Puller  ZZA0601D	<ul style="list-style-type: none"> <li>• Removing side oil seal (right side)</li> <li>• Removing side bearing outer race</li> </ul>
ST33400001 (J-26082) Drift a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia.  ZZA0702D	<ul style="list-style-type: none"> <li>• Installing side oil seal (right side)</li> <li>• Installing front oil seal</li> </ul>
KV38102100 (J-25803-01) Drift a: 44 mm (1.73 in) dia. b: 36 mm (1.42 in) dia. c: 24.5 mm (0.965 in) dia.  ZZA1046D	Installing side oil seal (left side)
KV38100200 ( — ) Drift a: 65 mm (2.56 in) dia. b: 49 mm (1.93 in) dia.  ZZA1143D	Installing side shaft oil seal
ST30032000 (J-26010-01) Drift a: 80 mm (3.15 in) dia. b: 38 mm (1.50 in) dia. c: 31 mm (1.22 in) dia.  S-NT107	<ul style="list-style-type: none"> <li>• Installing side shaft</li> <li>• Installing pinion rear bearing inner race</li> </ul>
KV10111100 (J-37228) Seal cutter  S-NT046	Removing carrier cover



# PREPARATION

< PREPARATION >

[FRONT FINAL DRIVE: F160A]


Tool number (Kent-Moore No.) Tool name	Description	
ST3306S001 (J-22888-D) Differential side bearing puller set 1: ST33051001 (J-22888-20) Puller 2: ST33061000 (J-8107-2) Base a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia.	 <p style="text-align: center;">NT072</p>	A B C <b>DLN</b>
ST33230000 (J-25805-01) Drift a: 51 mm (2.01 in) dia. b: 41 mm (1.61 in) dia. c: 28.5 mm (1.122 in) dia.	 <p style="text-align: center;">ZZA1046D</p>	E F
ST30611000 (J-25742-1) Drift bar	 <p style="text-align: center;">S-NT090</p>	G H I
KV31103000 (J-38982) Drift a: 49 mm (1.93 in) dia. b: 70 mm (2.76 in) dia.	 <p style="text-align: center;">ZZA1113D</p>	J K
ST3127S000 (J-25765-A) Preload gauge	 <p style="text-align: center;">ZZA0806D</p>	L M
(J-8129) Spring gauge	 <p style="text-align: center;">NT127</p>	N O P

# PREPARATION


< PREPARATION >

[FRONT FINAL DRIVE: F160A]

Tool number (Kent-Moore No.) Tool name	Description
ST37820000 ( — ) Drift a: 39 mm (1.54 in) dia. b: 72 mm (2.83 in) dia.	Installing pinion front and rear bearing outer race
KV38102510 ( — ) Drift a: 71 mm (2.80 in) dia. b: 65 mm (2.56 in) dia.	Installing front oil seal



ZZA0836D




ZZA0838D


## Commercial Service Tools

INFOID:000000009062141


Tool name	Description
Flange wrench	Removing and installing drive pinion lock nut
Replacer	Removing pinion rear bearing inner race
Spacer a: 60 mm (2.36 in) dia. b: 36 mm (1.42 in) dia. c: 30 mm (1.18 in)	Installing pinion front bearing inner race
Power tool	Loosening bolts and nuts




NT035



ZZA0700D



ZZA1133D



PBIC0190E

PERIODIC MAINTENANCE

FRONT DIFFERENTIAL GEAR OIL

Inspection

INFOID:000000009062142

OIL LEAKAGE

Make sure that oil is not leaking from final drive assembly or around it.

OIL LEVEL

- Remove filler plug (1) and check oil level from filler plug mounting hole as shown in the figure.


**CAUTION:**

**Never start engine while checking oil level.**

- Set a gasket on filler plug and install it on final drive assembly. Refer to [DLN-121, "Exploded View"](#).

**CAUTION:**

**Never reuse gasket.**




INFOID:000000009062143

Draining

- Stop engine.
- Remove drain plug (1) and drain gear oil.
- Set a gasket on drain plug and install it to final drive assembly and tighten to the specified torque. Refer to [DLN-121, "Exploded View"](#).

**CAUTION:**

**Never reuse gasket.**



INFOID:000000009062144

Refilling

- Remove filler plug (1). Fill with new gear oil until oil level reaches the specified level near filler plug mounting hole.


**Oil grade and Viscosity** : Refer to [MA-10, "Fluids and Lubricants"](#).

**Oil capacity** : Refer to [DLN-146, "General Specifications"](#).

- After refilling oil, check oil level. Set a gasket to filler plug, then install it to final drive assembly. Refer to [DLN-121, "Exploded View"](#).

**CAUTION:**

**Never reuse gasket.**



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# SIDE OIL SEAL

< REMOVAL AND INSTALLATION >

[FRONT FINAL DRIVE: F160A]


## REMOVAL AND INSTALLATION

### SIDE OIL SEAL

#### RIGHT SIDE

#### RIGHT SIDE : Exploded View

INFOID:000000009062145



1. Front final drive assembly
2. Side oil seal (right side)

A: Oil seal lip

⇐: Vehicle front

⊠: Apply gear oil.

⊠: Apply multi-purpose grease.

Refer to [GI-4. "Components"](#) for symbols not described above.

#### RIGHT SIDE : Removal and Installation


INFOID:000000009062146

##### REMOVAL

1. Remove the front drive shaft. Refer to [FAX-23. "Exploded View"](#).
2. Remove the side oil seal using a puller (A) [SST: KV381054S0 (J-34286)].

##### **CAUTION:**

**Never damage gear carrier.**



##### INSTALLATION

# SIDE OIL SEAL

## < REMOVAL AND INSTALLATION >


[FRONT FINAL DRIVE: F160A]

1. Using the drift (A) [SST: ST33400001 (J-26082)], press-fit side oil seal so that its surface comes face-to-face with the end surface of the side retainer.

**CAUTION:**

- Apply multi-purpose grease to sealing lips of side oil seal.
- Never reuse oil seal.
- When installing, never incline oil seal.


2. Install the front drive shaft. Refer to [FAX-23, "Exploded View"](#).
3. When oil leaks while removing, check oil level after the installation. Refer to [DLN-115, "Inspection"](#).



## LEFT SIDE

### LEFT SIDE : Exploded View

INFOID:000000009062147



1. Front final drive assembly
2. Side oil seal (left side)

A: Oil seal lip

↶: Vehicle front

: Apply gear oil.

: Apply multi-purpose grease.

Refer to [GI-4, "Components"](#) for symbols not described above.

## LEFT SIDE : Removal and Installation

INFOID:000000009062148

### REMOVAL

1. Remove the front final drive assembly from vehicle with power tool. Refer to [DLN-119, "Exploded View"](#).  
**NOTE:**  
Left side oil seal is attached to engine assembly. Replace it after removing front final drive assembly from vehicle.
2. Remove the side oil seal using a flat-bladed screwdriver.  
**CAUTION:**  
Never damage gear carrier.

### INSTALLATION

1. Apply multi-purpose grease to sealing lips of side oil seal.

## SIDE OIL SEAL


### < REMOVAL AND INSTALLATION >

[FRONT FINAL DRIVE: F160A]

- Using the drift (A) [SST: KV38102100 (J-25803-01)], press-fit side oil seal so that its surface comes face-to-face with the end surface of the gear carrier.

**CAUTION:**

- Never reuse oil seal.
  - When installing, never incline oil seal.
- Install the front final drive assembly on vehicle. Refer to [DLN-119, "Exploded View"](#).
  - Install the front drive shaft. Refer to [FAX-23, "Exploded View"](#).
  - When oil leaks while removing, check oil level after the installation. Refer to [DLN-115, "Inspection"](#).



# FRONT FINAL DRIVE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >


[FRONT FINAL DRIVE: F160A]

## UNIT REMOVAL AND INSTALLATION

### FRONT FINAL DRIVE ASSEMBLY

#### Exploded View

INFOID:000000009062149



1. Breather tube
2. Breather hose
3. Front final drive assembly
4. Side shaft

←: Vehicle front

Refer to [GI-4, "Components"](#) for symbols in the figure.

### Removal and Installation

INFOID:000000009062150

#### REMOVAL

1. Remove both front drive shaft. Refer to [FAX-23, "Exploded View"](#).
2. Remove front crossbar with power tool.
3. Separate steering outer socket and steering knuckle. Refer to [ST-34, "AWD : Exploded View"](#).
4. Remove side shaft.
5. Remove three way catalyst (right bank) with power tool. Refer to [EX-5, "Exploded View"](#).
6. Remove front propeller shaft. Refer to [DLN-87, "Exploded View"](#).
7. Separate power steering solenoid valve connector.
8. Separate power steering hydraulic line. Refer to [ST-52, "AWD : Exploded View"](#).
9. Remove stabilizer assembly with power tool. Refer to [FSU-36, "Exploded View"](#).
10. Separate steering lower joint and steering gear assembly. Refer to [ST-34, "AWD : Exploded View"](#).
11. Set a suitable jack to engine.
12. Remove front suspension member with power tool. Refer to [FSU-37, "Exploded View"](#).
13. Remove breather hose and tube.
14. Remove engine mounting bracket (RH) (Lower) and engine mounting insulator (RH) with power tool. Refer to [EM-72, "AWD : Exploded View"](#).
15. Remove final drive assembly mounting bolts with power tool and separate front final drive assembly from engine.

#### INSTALLATION

Note the following, install in the reverse order of removal.

## FRONT FINAL DRIVE ASSEMBLY


### < UNIT REMOVAL AND INSTALLATION >

[FRONT FINAL DRIVE: F160A]

- When installing the side shaft, apply multi-purpose grease to contact surface of side shaft and side shaft oil seal.
- Tighten mounting bolts in the order described below when installing front final drive assembly: side of gear carrier (1), upper side of gear carrier (2), part of carrier cover (3).

**CAUTION:**

Align the mating faces of gear carrier and oil pan for installation.




- When installing breather hose (1) and tube (2), refer to the figure.

**CAUTION:**

Make sure there are no pinched or restricted areas on the breather hose caused by bending or winding when installing it.

- Make sure the paint mark facing up (←).
- Securely install the hose until it seats the rounded portion of the tube. (←) (front final drive side).
- Securely install the hose until it to paint mark of the tube. (←) (vehicle rear side).
- Face the bend of the breather hose (↔) to the engine.
- When oil leaks while removing final drive assembly, check oil level after the installation. Refer to [DLN-115. "Inspection"](#).





# SIDE SHAFT

< UNIT DISASSEMBLY AND ASSEMBLY >


[FRONT FINAL DRIVE: F160A]

## UNIT DISASSEMBLY AND ASSEMBLY

### SIDE SHAFT

#### Exploded View

INFOID:000000009062151



- |                               |                                          |                                   |
|-------------------------------|------------------------------------------|-----------------------------------|
| 1. Drive pinion lock nut      | 2. Companion flange                      | 3. Front oil seal                 |
| 4. Pinion front bearing       | 5. Drive pinion bearing adjusting washer | 6. Drive pinion adjusting washer  |
| 7. Gear carrier               | 8. Pinion rear bearing                   | 9. Pinion height adjusting washer |
| 10. Drive pinion              | 11. Drive gear                           | 12. Side oil seal (right side)    |
| 13. Side retainer             | 14. O-ring                               | 15. Side bearing adjusting shim   |
| 16. Side bearing              | 17. Differential case                    | 18. Breather connector            |
| 19. Dowel pin                 | 20. Filler plug                          | 21. Drain plug                    |
| 22. Gasket                    | 23. Carrier cover                        | 24. Gear oil defense              |
| 25. Side gear thrust washer   | 26. Side gear                            | 27. Circular clip                 |
| 28. Pinion mate thrust washer | 29. Pinion mate gear                     | 30. Pinion mate shaft             |

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# SIDE SHAFT

## < UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

- |                        |                                   |                               |
|------------------------|-----------------------------------|-------------------------------|
| 31. Lock pin           | 32. Side bearing adjusting washer | 33. Side oil seal (left side) |
| 34. Side shaft bearing | 35. Extension tube retainer       | 36. Side shaft oil seal       |
| 37. Dust seal          | 38. Side shaft                    |                               |
| A: Oil seal lip        | B: Screw hole                     |                               |



Apply gear oil.



Apply anti-corrosion oil.



Apply Genuine Silicone RTV or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).




Apply Genuine Medium Strength Thread Locking Sealant or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#)

Refer to [GI-4. "Components"](#) for symbols not described above.

## Disassembly

INFOID:000000009062152

1. Hold extension tube retainer with puller, then press out side shaft using a press.




2. Remove side shaft oil seal (1) from extension tube retainer with a suitable tool.

**CAUTION:**

**Never damage extension tube retainer.**

3. Remove side shaft bearing from extension tube retainer.
4. Remove O-ring from extension tube retainer.
5. Remove dust seal from side shaft.



## Assembly


INFOID:000000009062153

1. Using the drift (A) [SST: KV38100200 ( — )], install side shaft oil seal.

**CAUTION:**

- **Never reuse oil seal.**
- **When installing, never incline oil seal.**
- **Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.**

2. Install dust seal.



## SIDE SHAFT


### < UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

- Support side shaft bearing with the drift (A) [SST: ST30032000 (J-26010-01)], then press side shaft (1) into the side shaft bearing using a press.
- Apply multi-purpose grease to O-ring, and install it to extension tube retainer.

**CAUTION:**

**Never reuse O-ring.**



### Inspection After Disassembly

#### DRIVE GEAR AND DRIVE PINION

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

#### BEARING

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

#### SIDE GEAR AND PINION MATE GEAR

- Clean up the disassembled parts.
- If any cracks or damage on the surface of the tooth is found, replace.
- If any worn or chipped mark on the contact sides of the thrust washer is found, replace.

#### SIDE GEAR THRUST WASHER AND PINION MATE THRUST WASHER

- Clean up the disassembled parts.
- If it is chipped (by friction), damaged, or unusually worn, replace.

#### OIL SEAL

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

#### DIFFERENTIAL CASE

- Clean up the disassembled parts.
- If any wear or crack on the contact sides of the differential case is found, replace.

#### COMPANION FLANGE

- Clean up the disassembled parts.
- If any chipped mark [about 0.1 mm, (0.004 in)] or other damage on the contact sides of the lips of the companion flange is found, replace.

INFOID:000000009062154

A  
B  
C

DLN

E  
F

G

H

I

J

K

L

M

N

O

P

# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

## DIFFERENTIAL ASSEMBLY

Exploded View

INFOID:000000009062155



- |                               |                                          |                                   |
|-------------------------------|------------------------------------------|-----------------------------------|
| 1. Drive pinion lock nut      | 2. Companion flange                      | 3. Front oil seal                 |
| 4. Pinion front bearing       | 5. Drive pinion bearing adjusting washer | 6. Drive pinion adjusting washer  |
| 7. Gear carrier               | 8. Pinion rear bearing                   | 9. Pinion height adjusting washer |
| 10. Drive pinion              | 11. Drive gear                           | 12. Side oil seal (right side)    |
| 13. Side retainer             | 14. O-ring                               | 15. Side bearing adjusting shim   |
| 16. Side bearing              | 17. Differential case                    | 18. Breather connector            |
| 19. Dowel pin                 | 20. Filler plug                          | 21. Drain plug                    |
| 22. Gasket                    | 23. Carrier cover                        | 24. Gear oil defense              |
| 25. Side gear thrust washer   | 26. Side gear                            | 27. Circular clip                 |
| 28. Pinion mate thrust washer | 29. Pinion mate gear                     | 30. Pinion mate shaft             |
| 31. Lock pin                  | 32. Side bearing adjusting washer        | 33. Side oil seal (left side)     |


# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >


[FRONT FINAL DRIVE: F160A]

- |                        |                             |                         |
|------------------------|-----------------------------|-------------------------|
| 34. Side shaft bearing | 35. Extension tube retainer | 36. Side shaft oil seal |
| 37. Dust seal          | 38. Side shaft              |                         |
| A: Oil seal lip        | B: Screw hole               |                         |

 Apply gear oil.

 Apply anti-corrosion oil.

 Apply Genuine Silicone RTV or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).

 Apply Genuine Medium Strength Thread Locking Sealant or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).

Refer to [GI-4. "Components"](#) for symbols not described above.


## Disassembly

INFOID:000000009062156


1. Drain gear oil, if necessary.
2. Remove carrier cover mounting bolts.
3. Remove carrier cover to insert the seal cutter (A) [SST: KV10111100 (J-37228)] between gear carrier and carrier cover.

### CAUTION:


- Never damage the mating surface.
- Never insert flat-bladed screwdriver, this may damage the mating surface.



4. Remove side retainer.
5. Remove side bearing adjusting shim.
6. Remove O-ring from side retainer.



7. Remove differential case assembly from gear carrier.




A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]


8. Remove side oil seal (right side) from side retainer.




9. Remove side bearing outer race with puller (A) [SST: KV381054S0 (J-34286)].

10. Remove O-ring from gear carrier.

11. Remove side oil seal (left side) from gear carrier.



12. Remove side bearing outer race with puller (A) [SST: KV381054S0 (J-34286)].




13. Remove side bearing inner race with puller (A) and base (B).  
To prevent damage to bearing, engage puller jaws in groove (←).

A: Puller [SST: ST33051001 (J-22888-20)]

B: Base [SST: ST33061000 (J-8107-2)]

### CAUTION:

- To prevent damage to the side bearing and drive gear, place copper plates between these parts and vise.
- It is not necessary to remove side bearing inner race except if it is replaced.



# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

14. For proper reinstallation, paint matching marks on one differential case assembly.


**CAUTION:**

**For matching marks, use paint. Never damage differential case and drive gear.**


15. Remove drive gear mounting bolts.  
16. Tap drive gear off differential case assembly with a soft hammer.

**CAUTION:**


**Tap evenly all around to keep drive gear from bending.**




17. Remove lock pin of pinion mate shaft with a punch from drive gear side.



18. Remove pinion mate shaft.



19. Turn pinion mate gear, then remove pinion mate gears, pinion mate thrust washers, side gears and side gear thrust washers from differential case.



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]


INFOID:00000009062157

## Assembly


1. Install side gear thrust washers with the same thickness as the ones installed prior to disassembly or reinstall the old ones on the side gears.




2. Install side gears and thrust washers into differential case.  
**CAUTION:**
  - Never reuse circular clip.
  - Make sure that the circular clip is installed to side gear (side retainer side).
3. Align 2 pinion mate gears in diagonally opposite positions, then rotate and install them into differential case after installing thrust washer to pinion mate gear.



4. Align the lock pin holes on differential case with shaft, and install pinion mate shaft.



5. Measure side gear end play. If necessary, select the appropriate side gear thrust washers.
  - a. Place differential case straight up so that side gear to be measured comes upward.





# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

- b. Using feeler gauge, measure the clearance between side gear back and differential case at 3 different points, while rotating side gear. Average the 3 readings, and then measure the clearance of the other side as well.

**Side gear back clearance** : Refer to [DLN-146, "Differential Side Gear Clearance"](#).

**CAUTION:**

To prevent side gear from tilting, insert feeler gauges with the same thickness from both sides.

- c. If the back clearance is outside the specification, use a thicker/thinner side gear thrust washer to adjust. For selecting thrust washer, refer to the latest parts information.

**When the back clearance is large:** Use a thicker thrust washer.

**When the back clearance is small:** Use a thinner thrust washer.

**CAUTION:**

Select a side gear thrust washer for right and left individually.

6. Drive a lock pin into pinion mate shaft, using a punch. Make sure lock pin is flush with differential case.

**CAUTION:**





Never reuse lock pin.

7. Align the matching mark of drive gear with the mark of differential case, then place drive gear.

8. Apply thread locking sealant into the thread hole of drive gear.  
• Use **Genuine Medium Strength Thread Locking Sealant or equivalent**. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

**CAUTION:**

Drive gear back and threaded holes must be cleaned and degreased sufficiently.



A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

9. Install drive gear on the mounting bolts.

**CAUTION:**

**Tighten bolts in a crisscross fashion.**




10. Press side bearing inner races to differential case, using the drift (A) and the base (B).

A: Drift [SST: ST33230000 (J-25805-01)]

B: Base [SST: ST33061000 (J-8107-2)]

**CAUTION:**

**Never reuse side bearing inner race.**




11. Press-fit side bearing outer race into side retainer with the drift bar (A) and the drift (B).

A: Drift bar [SST: ST30611000 (J-25742-1)]

B: Drift [SST: KV31103000 (J-38982)]

**CAUTION:**

- At first, using a hammer, tap bearing outer race until it becomes flat to side retainer.
- Never reuse side bearing outer race.




12. Press-fit side bearing outer race into gear carrier with the drift bar (A) and the drift (B).

A: Drift bar [SST: ST30611000 (J-25742-1)]

B: Drift [SST: KV31103000 (J-38982)]


**CAUTION:**

- At first, using a hammer, tap bearing outer race until it becomes flat to gear carrier.
- Never reuse side bearing outer race.



13. Place the differential case assembly into gear carrier.

14. Measure side bearing preload. If necessary, select the appropriate side bearing adjusting shim. Refer to [DLN-132, "Adjustment"](#).



# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

15. Install selected side bearing adjusting shim (1). Refer to [DLN-132, "Adjustment"](#).


2: O-ring

16. Apply multi-purpose grease to O-ring, and install it to side retainer.


**CAUTION:**

**Never reuse O-ring.**

17. Install side retainer assembly to gear carrier.




18. Install side retainer mounting bolts.



19. Using the drift (A) [SST: ST33400001 (J-26082)], press-fit side oil seal so that its surface comes face-to-face with the end surface of the side retainer.

**CAUTION:**


- Never reuse oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.



20. Using the drift (A) [SST: KV38102100 (J-25803-01)], press-fit side oil seal so that its surface comes face-to-face with the end surface of gear carrier.

**CAUTION:**

- Never reuse oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.



21. Apply multi-purpose grease to O-ring, and install it to gear carrier.

**CAUTION:**

**Never reuse O-ring.**

22. Check and adjust drive gear runout, tooth contact, drive gear to drive pinion backlash, and total preload torque. Refer to [DLN-132, "Adjustment"](#).  
Recheck above items. Readjust as described above, if necessary.


A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

23. Apply sealant to mating surface of carrier cover.
- Use Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).
- CAUTION:**  
Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.




24. Install carrier cover on gear carrier and tighten mounting bolts.



25. Set breather connector angle (A) as shown in the figure.

←: Vehicle front

**A** : 0 – 30°



## Adjustment

INFOID:000000009062158

### TOTAL PRELOAD TORQUE


- Before inspection and adjustment, drain gear oil.
1. Rotate drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
  2. Rotate drive pinion at least 20 times to check for smooth operation of the bearing.
  3. Measure total preload with preload gauge (A) [SST: ST3127S000 (J-25765-A)].

**Total preload torque** : Refer to [DLN-146, "Pre-load Torque"](#).

#### NOTE:

**Total preload torque = Pinion bearing preload torque + Side bearing preload torque**

- If measured value is out of the specification, disassemble it to check and adjust each part. Adjust the pinion bearing preload and side bearing preload.  
Adjust the pinion bearing preload first, then adjust the side bearing preload.



# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

## When the preload torque is large

**On pinion bearings:** Decrease the drive pinion bearing adjusting washer and drive pinion adjusting washer thickness. For selecting adjusting washer, refer to the latest parts information.

**On side bearings:** Increase the side bearing adjusting shim thickness. For select parts refer to parts information. For selecting adjusting washer, refer to the latest parts information.


## When the preload torque is small

**On pinion bearings:** Increase the drive pinion bearing adjusting washer and drive pinion adjusting washer thickness. For selecting adjusting washer, refer to the latest parts information.

**On side bearings:** Decrease the side bearing adjusting shim thickness. For select parts refer to parts information. For selecting adjusting washer, refer to the latest parts information.


## SIDE BEARING PRELOAD

- Before inspection and adjustment, drain gear oil.
1. Remove carrier cover and side retainer. Refer to [DLN-125, "Disassembly"](#).
  2. Make sure all parts are clean. Also, make sure the bearings are well lubricated with gear oil.
  3. Place the differential case assembly into gear carrier.




4. Install side bearing adjusting shim before disassembling or shim which thickness is the same as the one before disassembling.
5. Install side retainer assembly to gear carrier.

**CAUTION:**  
Never install O-ring.



6. Install side retainer mounting bolts to the specified torque.



A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P


# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]


7. Measure the turning torque of the gear carrier at the drive gear mounting bolts with a spring gauge [SST: — (J-8129)].

**Specification** : 34.2 – 39.2 N (3.5 – 4.0 kg, 7.7 – 8.8 lb) of pulling force at the drive gear bolt



8. If the turning torque is outside the specification, use a thicker/thinner side bearing adjusting shim to adjust. For selecting adjusting shim, refer to the latest parts information.

**If the turning torque is less than the specified range:**  
Decrease the side bearing adjusting shim thickness.  
**If the turning torque is greater than the specification:**  
Increase the side bearing adjusting shim thickness.



9. Record the total amount of shim thickness required for the correct carrier side bearing preload.

## DRIVE GEAR RUNOUT


1. Remove carrier cover. Refer to [DLN-125, "Disassembly"](#).
2. Fit a dial indicator to the drive gear back face.
3. Rotate the drive gear to measure runout.

**Drive gear runout** : Refer to [DLN-146, "Drive Gear Runout"](#).

- If the runout is outside of the repair limit, check drive gear assembly condition; foreign material may be caught between drive gear and differential case, or differential case or drive gear may be deformed, etc.

### CAUTION:

Replace drive gear and drive pinion gear as a set.




## TOOTH CONTACT

Before inspection and adjustment, drain gear oil.

1. Remove carrier cover. Refer to [DLN-125, "Disassembly"](#).
2. Apply red lead to drive gear.

### CAUTION:

Apply red lead to both the faces of 3 to 4 gears at 4 locations evenly spaced on drive gear.



# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

3. Rotate drive gear back and forth several times, check drive pinion gear to drive gear tooth contact.

**CAUTION:**

**Check tooth contact on drive side and reverse side.**



A  
B  
C

DLN

Tooth contact pattern				Pinion height adjusting washer selection value [mm (in)]	Adjustment requirement (Yes/No)
Back side		Drive side			
Heel side	Toe side	Toe side	Heel side		
				+0.15 (+0.0059)	Yes
				+0.12 (+0.0047)	
				+0.09 (+0.0035)	
				+0.06 (+0.0024)	No
				+0.03 (+0.0012)	
				0	
				-0.03 (-0.0012)	
				-0.06 (-0.0024)	Yes
				-0.09 (-0.0035)	
				-0.12 (-0.0047)	
				-0.15 (-0.0059)	

E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


PDIA0667E

# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]


4. If tooth contact is improperly adjusted, follow the procedure below to adjust the pinion height [dimension (X)].



- If the tooth contact is near the face (face contact), or near the heel (heel contact), thicken pinion height adjusting washers to move drive pinion closer to drive gear. For selecting adjusting washer, refer to the latest parts information.



- If the tooth contact is near the flank (flank contact), or near the toe (toe contact), thin pinion height adjusting washers to move drive pinion farther from drive gear. For selecting adjusting washer, refer to the latest parts information.



## BACKLASH

Before inspection and adjustment, drain gear oil.

1. Remove carrier cover. Refer to [DLN-125, "Disassembly"](#).
2. Fit a dial indicator to the drive gear face to measure the backlash.

**Backlash** : Refer to [DLN-146, "Backlash"](#).


- If the backlash is outside of the specified value, change the thickness of side bearing adjusting washer.

**When the backlash is large:**

**Decrease side bearing adjusting washer thickness. For selecting adjusting washer, refer to the latest parts information.**

**When the backlash is small:**

**Increase side bearing adjusting washer thickness. For selecting adjusting washer, refer to the latest parts information.**





# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

## Inspection After Disassembly

INFOID:000000009062159

### DRIVE GEAR AND DRIVE PINION

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

### BEARING

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

### SIDE GEAR AND PINION MATE GEAR

- Clean up the disassembled parts.
- If any cracks or damage on the surface of the tooth is found, replace.
- If any worn or chipped mark on the contact sides of the thrust washer is found, replace.

### SIDE GEAR THRUST WASHER AND PINION MATE THRUST WASHER

- Clean up the disassembled parts.
- If it is chipped (by friction), damaged, or unusually worn, replace.

### OIL SEAL

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

### DIFFERENTIAL CASE

- Clean up the disassembled parts.
- If any wear or crack on the contact sides of the differential case is found, replace.

### COMPANION FLANGE

- Clean up the disassembled parts.
- If any chipped mark [about 0.1 mm, (0.004 in)] or other damage on the contact sides of the lips of the companion flange is found, replace.

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# DRIVE PINION


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

## DRIVE PINION

Exploded View

INFOID:000000009062160






- |                               |                                          |                                   |
|-------------------------------|------------------------------------------|-----------------------------------|
| 1. Drive pinion lock nut      | 2. Companion flange                      | 3. Front oil seal                 |
| 4. Pinion front bearing       | 5. Drive pinion bearing adjusting washer | 6. Drive pinion adjusting washer  |
| 7. Gear carrier               | 8. Pinion rear bearing                   | 9. Pinion height adjusting washer |
| 10. Drive pinion              | 11. Drive gear                           | 12. Side oil seal (right side)    |
| 13. Side retainer             | 14. O-ring                               | 15. Side bearing adjusting shim   |
| 16. Side bearing              | 17. Differential case                    | 18. Breather connector            |
| 19. Dowel pin                 | 20. Filler plug                          | 21. Drain plug                    |
| 22. Gasket                    | 23. Carrier cover                        | 24. Gear oil defense              |
| 25. Side gear thrust washer   | 26. Side gear                            | 27. Circular clip                 |
| 28. Pinion mate thrust washer | 29. Pinion mate gear                     | 30. Pinion mate shaft             |
| 31. Lock pin                  | 32. Side bearing adjusting washer        | 33. Side oil seal (left side)     |


# DRIVE PINION

## < UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

- |                        |                             |                         |
|------------------------|-----------------------------|-------------------------|
| 34. Side shaft bearing | 35. Extension tube retainer | 36. Side shaft oil seal |
| 37. Dust seal          | 38. Side shaft              |                         |
| A: Oil seal lip        | B: Screw hole               |                         |

-  Apply gear oil.
-  Apply anti-corrosion oil.
-  Apply Genuine Silicone RTV or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).


 Apply Genuine Medium Strength Thread Locking Sealant or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#)

Refer to [GI-4. "Components"](#) for symbols not described above.

## Disassembly

INFOID:000000009062161

1. Remove differential case assembly. Refer to [DLN-125. "Disassembly"](#).
2. Remove drive pinion lock nut with a flange wrench (commercial service tool).



3. Put matching mark (B) on the end of drive pinion. The matching mark should be in line with the matching mark (A) on companion flange (1).


### CAUTION:

**For matching mark, use paint. Never damage companion flange and drive pinion.**


### NOTE:

The matching mark on the final drive companion flange indicates the maximum vertical runout position.

When replacing companion flange, matching mark is not necessary.



4. Remove companion flange using the suitable puller (commercial service tool).




A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DRIVE PINION


## < UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]


5. Press drive pinion assembly out of gear carrier.  
**CAUTION:**  
**Never drop drive pinion assembly.**
6. Remove front oil seal.
7. Remove pinion front bearing inner race.
8. Remove drive pinion bearing adjusting washer and drive pinion adjusting washer.



9. Remove pinion rear bearing inner race and pinion height adjusting washer with replacer (A) (commercial service tool).



10. Tap pinion front/rear bearing outer races uniformly a brass rod or equivalent to removed.  
**CAUTION:**  
**Never damage gear carrier.**




## Assembly

1. Install pinion front and rear bearing outer races using drift (A) [SST: ST37820000 ( — )].

### **CAUTION:**

- At first, using a hammer, tap bearing outer race until it becomes flat to gear carrier.
- Never reuse pinion front and rear bearing outer race.



INFOID:000000009062162

# DRIVE PINION

## < UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]


- Temporarily install pinion height adjusting washer (1).

**When hypoid gear set has been replaced**

- Select pinion height adjusting washer. Refer to [DLN-142, "Adjustment"](#).

**When hypoid gear set has been reused**


- Temporarily install the removed pinion height adjusting washer or same thickness washer to drive pinion.



- Install selected pinion height adjusting washer (2) to drive pinion. Press pinion rear bearing inner race (1) to it, using drift (A) [SST: ST30032000 (J-26010-01)].

**CAUTION:**


- Pay attention to the direction of pinion height adjusting washer. (Assemble as shown in the figure.)
- Never reuse pinion rear bearing inner race.




- Temporarily assemble removed drive pinion adjusting washer and drive pinion bearing adjusting washer or same thickness of them to drive pinion.
- Apply gear oil to pinion rear bearing, and assemble drive pinion into gear carrier.
- Apply gear oil to pinion front bearing, and assemble pinion front bearing inner race to drive pinion assembly.

**CAUTION:**

**Never reuse pinion front bearing inner race.**



- Using suitable spacer (A) (commercial service tool), press the pinion front bearing inner race to drive pinion as far as drive pinion nut can be tightened.
- Adjust pinion bearing preload. If necessary, select the appropriate drive pinion adjusting washer and drive pinion bearing adjusting washer. Refer to [DLN-142, "Adjustment"](#).




- Using the drifts (A and B), install front oil seal as shown in figure.

A: Drift [SST: ST33400001 (J-26082)]

B: Drift [SST: KV38102510 ( — )]

**CAUTION:**

- Never reuse oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.



# DRIVE PINION


< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

10. Install companion flange.

**NOTE:**

When reusing drive pinion, align the matching mark (B) of drive pinion with the matching mark (A) of companion flange, and then install companion flange (1).



11. Apply anti-corrosion oil to the thread and seat of new drive pinion lock nut, and temporarily tighten drive pinion lock nut to drive pinion, using flange wrench (commercial service tool).

A: Preload gauge [SST: ST3127S000 (J-25765-A)]

**CAUTION:**

**Never reuse drive pinion lock nut.**

12. Tighten to drive pinion lock nut, while adjusting pinion bearing preload torque, using preload gauge [SST: ST3127S000 (J-25765-A)].

**Pinion bearing preload** : Refer to [DLN-146, "Pre-load Torque"](#).

**CAUTION:**

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.

13. Install differential case assembly. Refer to [DLN-128, "Assembly"](#).


**CAUTION:**

**Never install carrier cover yet.**

14. Check and adjust drive gear runout, tooth contact, drive gear to drive pinion backlash, and companion flange runout. Refer to [DLN-132, "Adjustment"](#) and [DLN-142, "Adjustment"](#).  
Recheck above items. Readjust the above description, if necessary.

15. Check total preload torque. Refer to [DLN-132, "Adjustment"](#).

16. Install carrier cover. Refer to [DLN-128, "Assembly"](#).



## Adjustment

INFOID:000000009062163

### PINION GEAR HEIGHT

If the hypoid gear set has been replaced, select the pinion height adjusting washer.

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

1. Use the formula below to calculate pinion height adjusting washer thickness.

**Washer selection equation:**


$$T = T_0 + (t_1 - t_2)$$

**T:** Correct washer thickness

**T<sub>0</sub>:** Removed washer thickness

**t<sub>1</sub>:** Old drive pinion head letter "H × 0.01"  
("H": machined tolerance 1/100 mm × 100)

**t<sub>2</sub>:** New drive pinion head letter "H × 0.01"  
("H": machined tolerance 1/100 mm × 100)



A

B

C

DLN

**Example:**

$$T = 3.21 + [(2 \times 0.01) - (-1 \times 0.01)] = 3.24$$

**T<sub>0</sub>:** 3.21

**t<sub>1</sub>:** +2

**t<sub>2</sub>:** -1

E

F

2. Select the proper pinion height adjusting washer. For selecting adjusting washer, refer to the latest parts information.

If unable to find a washer of desired thickness, use a washer with thickness closest to the calculated value.

G

H

**Example:**

**Calculated value... T = 3.22 mm**

**Used washer... T = 3.21 mm**

I


## PINION BEARING PRELOAD

Assemble the drive pinion parts if they are disassembled. Refer to [DLN-140. "Assembly"](#).

1. Make sure all parts are clean. Also, make sure the bearings are well lubricated with gear oil.
2. Install companion flange.

**NOTE:**

When reusing drive pinion, align the matching mark (B) of drive pinion with the matching mark (A) of companion flange, and then install companion flange (1).



J

K

L

M

N

O

P

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

3. Temporarily tighten removed drive pinion lock nut to drive pinion, using flange wrench (commercial service tool).

A: Preload gauge [SST: ST3127S000 (J-25765-A)]

### NOTE:


Use removed drive pinion lock nut only for the preload measurement.

4. Rotate drive pinion at least 20 times to check for smooth operation of the bearing.
5. Tighten to drive pinion lock nut, while adjust pinion bearing preload torque, using preload gauge [SST: ST3127S000 (J-25765-A)].

**Pinion bearing preload** : Refer to [DLN-146, "Pre-load Torque"](#).

### CAUTION:

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
  - After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.
6. If the pinion bearing preload torque is outside the specification, use a thicker/thinner drive pinion bearing adjusting washer and drive pinion adjusting washer to adjust.



### When the preload torque is large:

Decrease the drive pinion bearing adjusting washer and drive pinion adjusting washer thickness. For selecting adjusting washer, refer to the latest parts information.

### When the preload is small:

Increase the drive pinion bearing adjusting washer and drive pinion adjusting washer thickness. For selecting adjusting washer, refer to the latest parts information.


7. Remove companion flange, after adjustment.

## COMPANION FLANGE RUNOUT

1. Fit a dial indicator onto the companion flange face (inner side of the propeller shaft mounting bolt holes).
2. Rotate companion flange to check for runout.

**Companion flange runout** : Refer to [DLN-146, "Companion Flange Runout"](#).

3. Fit a test indicator to the inner side of companion flange (socket diameter).
4. Rotate companion flange to check for runout.



**Companion flange runout** : Refer to [DLN-146, "Companion Flange Runout"](#).

5. If the runout value is outside the runout limit, follow the procedure below to adjust.
  - a. Check for runout while changing the phase between companion flange and drive pinion by 90° step, and search for the position where the runout is the minimum.
  - b. If the runout value is still outside of the limit after the phase has been changed, possible cause will be an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.
  - c. If the runout value is still outside of the limit after the check and repair, replace companion flange.



# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[FRONT FINAL DRIVE: F160A]

## Inspection After Disassembly

INFOID:000000009062164

### DRIVE GEAR AND DRIVE PINION

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

### BEARING

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

### SIDE GEAR AND PINION MATE GEAR

- Clean up the disassembled parts.
- If any cracks or damage on the surface of the tooth is found, replace.
- If any worn or chipped mark on the contact sides of the thrust washer is found, replace.

### SIDE GEAR THRUST WASHER AND PINION MATE THRUST WASHER

- Clean up the disassembled parts.
- If it is chipped (by friction), damaged, or unusually worn, replace.

### OIL SEAL

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

### DIFFERENTIAL CASE

- Clean up the disassembled parts.
- If any wear or crack on the contact sides of the differential case is found, replace.

### COMPANION FLANGE

- Clean up the disassembled parts.
- If any chipped mark [about 0.1 mm, (0.004 in)] or other damage on the contact sides of the lips of the companion flange is found, replace.

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[FRONT FINAL DRIVE: F160A]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### General Specifications

INFOID:000000009062165

Applied model	AWD
	VQ37VHR
	A/T
Final drive model	F160A
Gear ratio	3.133
Number of teeth (Drive gear/Drive pinion)	47/15
Oil capacity (Approx.) $\ell$ (US pt, Imp pt)	0.65 (1-3/8, 1-1/8)
Number of pinion gears	2
Drive pinion adjustment spacer type	Solid

#### Drive Gear Runout

INFOID:000000009062166

Unit: mm (in)

Item	Limit
Drive gear back face runout	0.05 (0.0020)

#### Differential Side Gear Clearance

INFOID:000000009062167

Unit: mm (in)

Item	Standard
Side gear backlash (Clearance between side gear and differential case)	0.2 (0.008) or less (Each gear should rotate smoothly without excessive resistance during differential motion.)

#### Preload Torque

INFOID:000000009062168

Unit: N·m (kg·m, in·lb)

Item	Standard
Pinion bearing (P1)	0.78 – 1.57 (0.08 – 0.16, 7 – 13)
Side bearing (P2)	0.78 – 1.08 (0.08 – 0.11, 7 – 9)
Side bearing to pinion bearing (Total preload) (Total preload = P1 + P2)	1.56 – 2.65 (0.16 – 0.27, 14 – 23)

#### Backlash

INFOID:000000009062169

Unit: mm (in)

Item	Standard
Drive gear to drive pinion gear	0.10 – 0.15 (0.0039 – 0.0059)

#### Companion Flange Runout

INFOID:000000009062170

Unit: mm (in)

Item	Limit
Companion flange face runout	0.18 (0.0071)
Inner side of the companion flange runout	0.13 (0.0051)

# REAR FINAL DRIVE ASSEMBLY

< SYSTEM DESCRIPTION >

[REAR FINAL DRIVE: R200]

## SYSTEM DESCRIPTION


### REAR FINAL DRIVE ASSEMBLY

System Diagram

INFOID:000000009062171

#### CROSS-SECTIONAL VIEW

2WD



- |                        |                         |                     |
|------------------------|-------------------------|---------------------|
| 1. Side flange         | 2. Pinion mate gear     | 3. Drive gear       |
| 4. Pinion mate shaft   | 5. Differential case    | 6. Side bearing     |
| 7. Drive pinion        | 8. Pinion front bearing | 9. Companion flange |
| 10. Collapsible spacer | 11. Pinion rear bearing | 12. Side gear       |

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O


P

# REAR FINAL DRIVE ASSEMBLY

< SYSTEM DESCRIPTION >

[REAR FINAL DRIVE: R200]

AWD



- |                        |                         |                     |
|------------------------|-------------------------|---------------------|
| 1. Side flange         | 2. Pinion mate gear     | 3. Drive gear       |
| 4. Pinion mate shaft   | 5. Differential case    | 6. Side bearing     |
| 7. Drive pinion        | 8. Pinion front bearing | 9. Companion flange |
| 10. Collapsible spacer | 11. Pinion rear bearing | 12. Side gear       |

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[REAR FINAL DRIVE: R200]

## SYMPTOM DIAGNOSIS

### NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

#### NVH Troubleshooting Chart

INFOID:000000009062172

2WD

Use the chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Symptom	Noise														
Reference															
Possible cause and SUSPECTED PARTS		Gear tooth rough	Gear contact improper	Tooth surfaces worn	Backlash incorrect	Companion flange excessive runout	Gear oil improper	PROPELLER SHAFT	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING	
	x	x	x	x	x	x	x	x	x	x	x	x	x	x	
		<a href="#">DLN-186, "2WD : Inspection After Disassembly"</a>	<a href="#">DLN-182, "2WD : Adjustment"</a>	<a href="#">DLN-186, "2WD : Inspection After Disassembly"</a>	<a href="#">DLN-182, "2WD : Adjustment"</a>	<a href="#">DLN-182, "2WD : Adjustment"</a>	<a href="#">DLN-156, "Inspection"</a>	NVH of REAR PROPELLER SHAFT in this section.	NVH in FAX, RAX, FSU and RSU sections.	NVH in WT section.	NVH in WT section.	NVH in RAX section.	NVH in BR section.	NVH in ST section.	

x: Applicable

AWD

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[REAR FINAL DRIVE: R200]

Use the chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Symptom	Noise	Gear tooth rough	Gear contact improper	Tooth surfaces worn	Backlash incorrect	Companion flange excessive runout	Gear oil improper	PROPELLER SHAFT	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING	
Reference			<a href="#">DLN-199, "AWD : Inspection After Disassembly"</a>	<a href="#">DLN-194, "AWD : Adjustment"</a>	<a href="#">DLN-199, "AWD : Inspection After Disassembly"</a>	<a href="#">DLN-194, "AWD : Adjustment"</a>	<a href="#">DLN-194, "AWD : Adjustment"</a>	<a href="#">DLN-156, "Inspection"</a>	NVH of FRONT and REAR PROPELLER SHAFT in this section.	NVH in FAX, RAX, FSU and RSU sections.	NVH in WT section.	NVH in WT section.	NVH in FAX and RAX section.	NVH in BR section.	NVH in ST section.
Possible cause and SUSPECTED PARTS		×	×	×	×	×	×	×	×	×	×	×	×	×	

×: Applicable

# PRECAUTION

## PRECAUTIONS

### Service Notice or Precautions for Rear Final Drive

INFOID:000000009062173

- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they never interfere with the function of the parts when applied.
- Overhaul should be done in a clean work area, it is preferable to work in dustproof area.
- Before disassembly, using steam or white gasoline, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with new ones, if necessary.
- Gaskets, seals and O-rings should be replaced any time when the unit is disassembled.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, observe it.
- Clean and flush the parts sufficiently and blow-dry them.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mounting surface; then remove any moisture, oil, and foreign materials from the application and mounting surfaces.
- Always use shop paper for cleaning the inside of components.
- Never use cotton gloves or shop rags to prevent entering of lint.
- During assembly, observe the specified tightening torque, and apply new gear oil, petroleum jelly, or multi-purpose grease as specified for each vehicle, if necessary.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



# PREPARATION

< PREPARATION >

[REAR FINAL DRIVE: R200]







## PREPARATION

### PREPARATION

#### Special Service Tools

INFOID:000000009062174

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
KV40104100 ( — ) Attachment	Removing side flange   ZZA0804D
ST36230000 (J-25840-A) Sliding hammer	Removing side flange   ZZA0803D
ST3127S000 (J-25765-A) Preload gauge	Measuring pinion bearing preload and total preload   ZZA0806D
KV381054S0 (J-34286) Puller	Removing front oil seal   ZZA0601D
ST30720000 (J-25405) Drift a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia.	<ul style="list-style-type: none"> <li>• Installing front oil seal</li> <li>• Installing pinion rear bearing outer race</li> </ul>  ZZA0811D
KV38107900 (J-39352) Protector	Installing side flange   S-NT129



# PREPARATION

< PREPARATION >






[REAR FINAL DRIVE: R200]

Tool number (Kent-Moore No.) Tool name	Description	
KV38100200 (J-26233) Drift a: 65 mm (2.56 in) dia. b: 49 mm (1.93 in) dia.	Installing side oil seal	A B C
KV10111100 (J-37228) Seal cutter	Removing rear cover	DLN E F
KV38100800 (J-25604-01) Attachment A: 541 mm (21.30 in) B: 200 mm (7.87 in)	Fixing unit assembly	G H
ST3306S001 (J-22888-D) Differential side bearing puller set 1: ST33051001 (J-22888-20) Puller 2: ST33061000 (J-8107-2) Base a: 28.5 mm (1.122 in) dia. b: 38 mm (1.50 in) dia.	Removing and installing side bearing inner race	I J K
KV10112100 (BT-8653-A) Angle wrench	Tightening the drive gear mounting bolt	L M
KV38100300 (J-25523) Drift a: 54 mm (2.13 in) dia. b: 46 mm (1.81 in) dia. c: 32 mm (1.26 in) dia.	Installing side bearing inner race	N O P

# PREPARATION

< PREPARATION >

[REAR FINAL DRIVE: R200]

Tool number (Kent-Moore No.) Tool name	Description
(J-8129) Spring gauge	Measuring turning torque
 NT127	Installing pinion rear bearing outer race
KV40105230 ( — ) Drift a: 92 mm (3.62 in) dia. b: 86 mm (3.39 in) dia. c: 45 mm (1.77 in) dia.	 PDIA0591E
ST30611000 (J-25742-1) Drift bar	Installing pinion front bearing outer race (Use with ST30613000)
 S-NT090	Installing pinion front bearing outer race
ST30613000 (J-25742-3) Drift a: 72 mm (2.83 in) dia. b: 48 mm (1.89 in) dia.	 ZZA1000D
ST30901000 (J-26010-01) Drift a: 79 mm (3.11 in) dia. b: 45 mm (1.77 in) dia. c: 35.2 mm (1.386 in) dia.	Installing pinion rear bearing inner race
 ZZA0978D	







Commercial Service Tools

INFOID:000000009062175

# PREPARATION

< PREPARATION >

[REAR FINAL DRIVE: R200]

Tool name	Description	
Flange wrench   NT035	Removing and installing drive pinion lock nut	A B C
Puller   ZZA0119D	Removing companion flange	DLN E
Sliding hammer   NT125	Removing differential case assembly	F G
Replacer   ZZA0700D	Removing pinion rear bearing inner race	H I J
Spacer a: 60 mm (2.36 in) dia. b: 36 mm (1.42 in) dia. c: 30 mm (1.18 in)   ZZA1133D	Installing pinion front bearing inner race	K L
Power tool   PBIC0190E	Loosening bolts and nuts	M N O

P

## PERIODIC MAINTENANCE

### REAR DIFFERENTIAL GEAR OIL

#### Inspection

INFOID:000000009062176

#### OIL LEAKAGE

- Make sure that oil is not leaking from final drive assembly or around it.

#### OIL LEVEL

- Remove filler plug (1) and check oil level from filler plug mounting hole as shown in the figure.


**CAUTION:**

**Never start engine while checking oil level.**

- Set a gasket on filler plug and install it on final drive assembly. Refer to [DLN-175, "2WD : Exploded View"](#) (2WD), [DLN-187, "AWD : Exploded View"](#) (AWD).

**CAUTION:**

**Never reuse gasket.**




#### Draining

INFOID:000000009062177

1. Stop engine.
2. Remove drain plug (1) and drain gear oil.
3. Set a gasket on drain plug and install it to final drive assembly and tighten to the specified torque. Refer to [DLN-175, "2WD : Exploded View"](#) (2WD), [DLN-187, "AWD : Exploded View"](#) (AWD).

**CAUTION:**

**Never reuse gasket.**



#### Refilling

INFOID:000000009062178

1. Remove filler plug (1). Fill with new gear oil until oil level reaches the specified level near filler plug mounting hole.


**Oil grade and viscosity** : Refer to [MA-10, "Fluids and Lubricants"](#).

**Oil capacity** : Refer to [DLN-216, "General Specification"](#).

2. After refilling oil, check oil level. Set a gasket to filler plug, then install it to final drive assembly. Refer to [DLN-175, "2WD : Exploded View"](#) (2WD), [DLN-187, "AWD : Exploded View"](#) (AWD).

**CAUTION:**

**Never reuse gasket.**



# FRONT OIL SEAL

< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]


## REMOVAL AND INSTALLATION

### FRONT OIL SEAL

2WD

2WD : Exploded View

INFOID:000000009062179



1. Final drive assembly
  2. Front oil seal
  3. Companion flange
  4. Drive pinion lock nut
- A. Oil seal lip

←: Vehicle front

: Apply gear oil.

\*: Apply anti-corrosion oil.

Refer to [GI-4, "Components"](#) for symbols not described above.

### 2WD : Removal and Installation

INFOID:000000009062180

#### REMOVAL

##### CAUTION:

Verify identification stamp of replacement frequency put in the lower part of gear carrier to determine replacement for collapsible spacer when replacing front oil seal. Refer to "Identification stamp of replacement frequency of front oil seal". If collapsible spacer replacement is necessary, remove final drive assembly and disassemble it to replace front oil seal and collapsible spacer. Refer to [DLN-171, "2WD : Removal and Installation"](#) and [DLN-176, "2WD : Disassembly"](#).

##### NOTE:

The reuse of collapsible spacer is prohibited in principle. However, it is reusable on a one-time basis only in cases when replacing front oil seal.


Identification stamp of replacement frequency of front oil seal

# FRONT OIL SEAL

[REAR FINAL DRIVE: R200]

## < REMOVAL AND INSTALLATION >

- The diagonally shaded area in the figure shows stamping point for replacement frequency of front oil seal.
- The following table shows if collapsible spacer replacement is needed before replacing front oil seal.  
When collapsible spacer replacement is required, disassemble final drive assembly to replace collapsible spacer and front oil seal. Refer to [DLN-176. "2WD : Disassembly"](#).



Stamp	collapsible spacer replacement
No stamp	Not required
"0" or "0" on the far right of stamp	Required
"01" or "1" on the far right of stamp	Not required

### CAUTION:

**Make a stamping after replacing front oil seal.**

- After replacing front oil seal, make a stamping on the stamping point in accordance with the table below in order to identify replacement frequency.

### CAUTION:

**Make a stamping from left to right.**

Stamp before stamping	Stamping on the far right	Stamping
No stamp	0	0
"0" (Front oil seal was replaced once.)	1	01
"01" (Collapsible spacer and front oil seal were replaced last time.)	0	010
"0" is on the far right. (Only front oil seal was replaced last time.)	1	...01
"1" is on the far right. (Collapsible spacer and front oil seal were replaced last time.)	0	...010


1. Drain gear oil. Refer to [DLN-156. "Draining"](#).
2. Make a judgment if a collapsible spacer replacement is required.
3. Remove center muffler with a power tool. Refer to [EX-5. "Exploded View"](#).
4. Remove rear wheel sensor. Refer to [BRC-130. "REAR WHEEL SENSOR : Exploded View"](#).
5. Remove drive shaft from final drive. Then suspend it by wire, etc. Refer to [RAX-10. "Exploded View"](#).
6. Install attachment (A) to side flange, and then pull out the side flange with the sliding hammer (B).

- A : Attachment [SST: KV40104100 ( — )]  
B : Sliding hammer [SST: ST36230000 (J-25840-A)]

### NOTE:

**Circular clip installation position: Final drive side**

7. Remove rear propeller shaft. Refer to [DLN-94. "Exploded View"](#).



# FRONT OIL SEAL


## < REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]

8. Measure the total preload with the preload gauge (A) [SST: ST3127S000 (J-25765-A)].

**NOTE:**

Record the preload measurement.




9. Put matching mark (B) on the end of the drive pinion. The matching mark should be in line with the matching mark (A) on companion flange (1).

**CAUTION:**


For matching mark, use paint. Never damage companion flange and drive pinion.

**NOTE:**


The matching mark on the final drive companion flange indicates the maximum vertical runout position.




10. Remove drive pinion lock nut, using the flange wrench (commercial service tool).



11. Remove companion flange using puller (commercial service tool).



12. Remove front oil seal using the puller (A) [SST: KV381054S0 (J-34286)].



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# FRONT OIL SEAL

< REMOVAL AND INSTALLATION >


[REAR FINAL DRIVE: R200]

## INSTALLATION


1. Apply multi-purpose grease to front oil seal lips.
2. Install front oil seal using the drift (A) [SST: ST30720000 (J-25405)] as shown in figure.

**CAUTION:**

- Never reuse oil seal.
- Never incline oil seal when installing.



3. Align the matching mark (B) of drive pinion with the matching mark (A) of companion flange (1), and then install the companion flange.



4. Apply anti-corrosion oil to the thread and seat of new drive pinion lock nut, and temporarily tighten drive pinion lock nut to drive pinion, using flange wrench (commercial service tool).

A : Preload gauge [SST: ST3127S000 (J-25765-A)]

**CAUTION:**

**Never reuse drive pinion lock nut.**


5. Tighten drive pinion lock nut within the limits of specified torque so as to keep the pinion bearing preload within a standard values, using preload gauge [SST: ST3127S000 (J-25765-A)].

**Standard**

**Total preload torque : A value that add 0.1 – 0.4 N·m (0.01 – 0.04 kg·m) to the measured value when removing.**

**CAUTION:**

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- If the preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Never loosen drive pinion lock nut to adjust the preload torque.





# FRONT OIL SEAL

## < REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]

- Set a dial indicator (A) vertically to the tip of the drive pinion.
- Rotate drive pinion to check for runout.

**Drive pinion runout** : Refer to [DLN-216, "Drive Pinion Runout \(2WD\)"](#).

- If the runout value is still outside of the limit after the phase has been changed, possible causes are an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.

- Make a stamping for identification of front oil seal replacement frequency. Refer to "Identification stamp of replacement frequency of front oil seal".

**CAUTION:**

**Make a stamping after replacing front oil seal.**

- Install rear propeller shaft. Refer to [DLN-94, "Exploded View"](#).
- Install side flange with the following procedure.
  - Attach the protector [SST: KV38107900 (J-39352)] to side oil seal.
  - After the side flange is inserted and the serrated part of side gear has engaged the serrated part of flange, remove the protector.
  - Put a suitable drift on the center of side flange, then drive it until sound changes.

**NOTE:**

When installation is completed, driving sound of the side flange turns into a sound that seems to affect the whole final drive.




- Confirm that the dimension of the side flange (1) installation measurement (A) in the figure comes into the following.

**Standard**

**A** : 326 – 328 mm (12.83 – 12.91 in)

- Install drive shaft. Refer to [RAX-10, "Exploded View"](#).
- Install rear wheel sensor. Refer to [BRC-130, "REAR WHEEL SENSOR : Exploded View"](#).
- Install center muffler. Refer to [EX-5, "Exploded View"](#).
- Refill gear oil to the final drive and check oil level. Refer to [DLN-156, "Refilling"](#).
- Check the final drive for oil leakage. Refer to [DLN-156, "Inspection"](#).

AWD



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# FRONT OIL SEAL

< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]

AWD : Exploded View

INFOID:000000009062181



- 1. Final drive assembly
  - 2. Front oil seal
  - 3. Companion flange
  - 4. Drive pinion lock nut
  - A. Oil seal lip
- ←: Vehicle front

: Apply gear oil.

\*: Apply anti-corrosion oil.

Refer to [GI-4, "Components"](#) for symbols not described above.

AWD : Removal and Installation

INFOID:000000009062182

## REMOVAL

### CAUTION:

Verify identification stamp of replacement frequency put in the lower part of gear carrier to determine replacement for collapsible spacer when replacing front oil seal. Refer to "Identification stamp of replacement frequency of front oil seal". If collapsible spacer replacement is necessary, remove final drive assembly and disassemble it to replace front oil seal and collapsible spacer. Refer to [DLN-173, "AWD : Removal and Installation"](#) and [DLN-188, "AWD : Disassembly"](#).


### NOTE:

The reuse of collapsible spacer is prohibited in principle. However, it is reusable on a one-time basis only in cases when replacing front oil seal.

Identification stamp of replacement frequency of front oil seal

- The diagonally shaded area in the figure shows stamping point for replacement frequency of front oil seal.
- The following table shows if collapsible spacer replacement is needed before replacing front oil seal. When collapsible spacer replacement is required, disassemble final drive assembly to replace collapsible spacer and front oil seal. Refer to [DLN-188, "AWD : Disassembly"](#).

Stamp	collapsible spacer replacement
No stamp	Not required
"0" or "0" on the far right of stamp	Required
"01" or "1" on the far right of stamp	Not required



### CAUTION:

Make a stamping after replacing front oil seal.

# FRONT OIL SEAL

## < REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]

- After replacing front oil seal, make a stamping on the stamping point in accordance with the table below in order to identify replacement frequency.

**CAUTION:**

Make a stamping from left to right.

Stamp before stamping	Stamping on the far right	Stamping
No stamp	0	0
"0" (Front oil seal was replaced once.)	1	01
"01" (Collapsible spacer and front oil seal were replaced last time.)	0	010
"0" is on the far right. (Only front oil seal was replaced last time.)	1	...01
"1" is on the far right. (Collapsible spacer and front oil seal were replaced last time.)	0	...010

- Drain gear oil. Refer to [DLN-156, "Draining"](#).
- Make a judgment if a collapsible spacer replacement is required.
- Remove center muffler with a power tool. Refer to [EX-5, "Exploded View"](#).
- Remove rear wheel sensor. Refer to [BRC-130, "REAR WHEEL SENSOR : Exploded View"](#).
- Remove drive shaft from final drive. Then suspend it by wire, etc. Refer to [RAX-10, "Exploded View"](#).
- Install attachment (A) to side flange, and then pull out the side flange with the sliding hammer (B).


A : Attachment [SST: KV40104100 ( — )]

B : Sliding hammer [SST: ST36230000 (J-25840-A)]

**NOTE:**

**Circular clip installation position: Final drive side**


- Remove rear propeller shaft. Refer to [DLN-103, "Exploded View"](#).



- Measure the total preload with the preload gauge (A) [SST: ST3127S000 (J-25765-A)].

**NOTE:**

**Record the preload measurement.**




- Put matching mark (B) on the end of the drive pinion. The matching mark should be in line with the matching mark (A) on companion flange (1).

**CAUTION:**

**For matching mark, use paint. Never damage companion flange and drive pinion.**

**NOTE:**

The matching mark on the final drive companion flange indicates the maximum vertical runout position.




# FRONT OIL SEAL


## < REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]


10. Remove drive pinion lock nut using the flange wrench (commercial service tool).



11. Remove companion flange using puller (commercial service tool).



12. Remove front oil seal using the puller (A) [SST: KV381054S0 (J-34286)].




## INSTALLATION

1. Apply multi-purpose grease to front oil seal lips.
2. Install front oil seal using the drift (A) [SST: ST30720000 (J-25405)] as shown in figure.

### CAUTION:

- Never reuse oil seal.
- Never incline oil seal when installing.




# FRONT OIL SEAL

## < REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]

3. Align the matching mark (B) of drive pinion with the matching mark (A) of companion flange (1), and then install the companion flange.



4. Apply anti-corrosion oil to the thread and seat of new drive pinion lock nut, and temporarily tighten drive pinion lock nut to drive pinion, using flange wrench (commercial service tool).

A : Preload gauge [SST: ST3127S000 (J-25765-A)]

### CAUTION:

**Never reuse drive pinion lock nut.**


5. Tighten drive pinion lock nut within the limits of specified torque so as to keep the pinion bearing preload within a standard values, using preload gauge [SST: ST3127S000 (J-25765-A)].

### Standard

**Total preload torque** : A value that add 0.1 – 0.4 N·m (0.01 – 0.04 kg·m) to the measured value when removing.

### CAUTION:

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- If the preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Never loosen drive pinion lock nut to adjust the preload torque.



6. Fit a test indicator to the inner side of companion flange (socket diameter).  
7. Rotate companion flange to check for runout.

**Companion flange runout** : Refer to [DLN-217, "Companion Flange Runout \(AWD\)"](#).


- If the runout value is outside the runout limit, follow the procedure below to adjust.
  - Check for runout while changing the phase between companion flange and drive pinion by 90° step, and search for the position where the runout is the minimum.
  - If the runout value is still outside of the limit after the phase has been changed, possible cause will be an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.
  - If the runout value is still outside of the limit after the check and repair, replace companion flange.

8. Make a stamping for identification of front oil seal replacement frequency. Refer to "Identification stamp of replacement frequency of front oil seal".

### CAUTION:

**Make a stamping after replacing front oil seal.**

9. Install rear propeller shaft. Refer to [DLN-103, "Exploded View"](#).



A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# FRONT OIL SEAL

## < REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]

10. Install side flange with the following procedure.
  - a. Attach the protector [SST: KV38107900 (J-39352)] to side oil seal.
  - b. After the side flange is inserted and the serrated part of side gear has engaged the serrated part of flange, remove the protector.
  - c. Put a suitable drift on the center of side flange, then drive it until sound changes.

**NOTE:**



When installation is completed, driving sound of the side flange turns into a sound that seems to affect the whole final drive.

- d. Confirm that the dimension of the side flange installation measurement (A) in the figure comes into the following.

**Standard**

**A : 326 – 328 mm (12.83 – 12.91 in)**

11. Install drive shaft. Refer to [RAX-10, "Exploded View"](#).
12. Install rear wheel sensor. Refer to [BRC-130, "REAR WHEEL SENSOR : Exploded View"](#).
13. Install center muffler. Refer to [EX-5, "Exploded View"](#).
14. Refill gear oil to the final drive and check oil level. Refer to [DLN-156, "Refilling"](#).
15. Check the final drive for oil leakage. Refer to [DLN-156, "Inspection"](#).



# SIDE OIL SEAL

< REMOVAL AND INSTALLATION >


[REAR FINAL DRIVE: R200]

## SIDE OIL SEAL

2WD

2WD : Exploded View

INFOID:000000009062183



1. Final drive assembly

2. Side oil seal

3. Side flange

A. Oil seal lip

↔: Vehicle front

: Apply gear oil.

Refer to [GI-4, "Components"](#) for symbols not described above.

## 2WD : Removal and Installation

INFOID:000000009062184

### REMOVAL


1. Remove center muffler with a power tool. Refer to [EX-5, "Exploded View"](#).
2. Remove rear wheel sensor. Refer to [BRC-130, "REAR WHEEL SENSOR : Exploded View"](#).
3. Remove drive shaft from final drive with a power tool. Then suspend it by wire, etc. Refer to [RAX-10, "Exploded View"](#).
4. Install attachment (A) to side flange, and then pull out the side flange with the sliding hammer (B).

A : Attachment [SST: KV40104100 ( — )]

B : Sliding hammer [SST: ST36230000 (J-25840-A)]

### NOTE:

**Circular clip installation position: Final drive side**



# SIDE OIL SEAL


## < REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]

5. Remove side oil seal, using a suitable tool.

**CAUTION:**

Never damage gear carrier.




## INSTALLATION


1. Apply multi-purpose grease to side oil seal lips.
2. Install side oil seal until it becomes flush with the case end, using the drift [SST: KV38100200 (J-26233)].

**CAUTION:**

- Never reuse oil seal.
- When installing, never incline oil seal.



3. Install side flange with the following procedure.
  - a. Attach the protector [SST: KV38107900 (J-39352)] to side oil seal.
  - b. After the side flange is inserted and the serrated part of side gear has engaged the serrated part of flange, remove the protector.



- c. Put a suitable drift on the center of side flange, then drive it until sound changes.

**NOTE:**


When installation is completed, driving sound of the side flange turns into a sound that seems to affect the whole final drive.

- d. Confirm that the dimension of the side flange (1) installation measurement (A) in the figure comes into the following.

**Standard**

**A** : 326 – 328 mm (12.83 – 12.91 in)

4. Install drive shaft. Refer to [RAX-10, "Exploded View"](#).
5. Install rear wheel sensor. Refer to [BRC-130, "REAR WHEEL SENSOR : Exploded View"](#).
6. Install center muffler. Refer to [EX-5, "Exploded View"](#).
7. When oil leaks while removing, check oil level after the installation. Refer to [DLN-156, "Inspection"](#).



## AWD





# SIDE OIL SEAL

< REMOVAL AND INSTALLATION >


[REAR FINAL DRIVE: R200]

## INSTALLATION


1. Apply multi-purpose grease to side oil seal lips.
2. Install side oil seal until it becomes flush with the case end, using the drift [SST: KV38100200 (J-26233)].

**CAUTION:**

- Never reuse oil seal.
- When installing, never incline oil seal.



3. Install side flange with the following procedure.
  - a. Attach the protector [SST: KV38107900 (J-39352)] to side oil seal.
  - b. After the side flange is inserted and the serrated part of side gear has engaged the serrated part of flange, remove the protector.



- c. Put a suitable drift on the center of side flange, then drive it until sound changes.

**NOTE:**


When installation is completed, driving sound of the side flange turns into a sound that seems to affect the whole final drive.

- d. Confirm that the dimension of the side flange installation measurement (A) in the figure comes into the following.

**Standard**

**A** : 326 – 328 mm (12.83 – 12.91 in)

4. Install drive shaft. Refer to [RAX-10, "Exploded View"](#).
5. Install rear wheel sensor. Refer to [BRC-130, "REAR WHEEL SENSOR : Exploded View"](#).
6. Install center muffler. Refer to [EX-5, "Exploded View"](#).
7. When oil leaks while removing, check oil level after the installation. Refer to [DLN-156, "Inspection"](#).



# REAR FINAL DRIVE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]


## UNIT REMOVAL AND INSTALLATION

### REAR FINAL DRIVE ASSEMBLY

2WD

2WD : Exploded View

INFOID:000000009062187



- 1. Rear final drive assembly
- 2. Upper stopper
- 3. Lower stopper
- 4. Washer

↶: Vehicle front


Refer to [GI-4, "Components"](#) for symbols in the figure.

### 2WD : Removal and Installation

INFOID:000000009062188

#### REMOVAL

1. Remove center muffler with a power tool. Refer to [EX-5, "Exploded View"](#).
2. Remove stabilizer bar with a power tool. Refer to [RSU-16, "Exploded View"](#).
3. Remove rear propeller shaft from the final drive. Refer to [DLN-94, "Exploded View"](#).
4. Remove drive shaft from final drive with a power tool. Then suspend it by wire, etc. Refer to [RAX-10, "Exploded View"](#).
5. Remove breather hose from the final drive.
6. Remove rear wheel sensor. Refer to [BRC-130, "REAR WHEEL SENSOR : Exploded View"](#).



# REAR FINAL DRIVE ASSEMBLY

## < UNIT REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]

7. Set a suitable jack to rear final drive assembly.


**CAUTION:**

**Never place a jack on the rear cover (aluminum case).**

8. Remove the mounting bolts and nuts connecting to the suspension member, and remove rear final drive assembly with a power tool.

**CAUTION:**

**Secure rear final drive assembly to a suitable jack while removing it.**



## INSTALLATION

Note the following, and installation is in the reverse order of removal.

**CAUTION:**


**Check that there are no pinched or restricted areas on the breather hose caused by bending or winding when installing it.**

- Install the breather hose (1) to breather connector until dimension (A) shown as follows.

A:

Final drive side : 20 mm (0.79 in)

Suspension member side : 20.5 mm (0.807 in)



**CAUTION:**

- **Never reuse hose clamp.**
- **Install the hose clamp at the final drive side, with the tab facing downward.**
- **Install the hose clamp at the suspension member side, with the tab facing downward.**
- If remove breather connector, install breather hose (1) as shown in the figure.

2 : Suspension member

3 : Metal connector


⇐: Vehicle front

- For installation, insert the resin connector into rear suspension member. Install the metal connector in rear cover so that a paint mark becomes forward of the vehicle as shown in the figure. Arrange the breather hose then to pass by over wheel sensor harness.

**CAUTION:**

**Never reuse breather connector.**

- When oil leaks while removing final drive assembly, check oil level after the installation. Refer to [DLN-156](#), "[Inspection](#)".



AWD


# REAR FINAL DRIVE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]

AWD : Exploded View

INFOID:000000009062189



1. Rear final drive assembly
2. Upper stopper
3. Lower stopper
4. Washer

←: Vehicle front


Refer to [GI-4, "Components"](#) for symbols in the figure.

AWD : Removal and Installation


INFOID:000000009062190

## REMOVAL

1. Remove center muffler with a power tool. Refer to [EX-5, "Exploded View"](#).
2. Remove stabilizer bar with a power tool. Refer to [RSU-16, "Exploded View"](#).
3. Remove rear propeller shaft from the final drive. Refer to [DLN-103, "Exploded View"](#).
4. Remove drive shaft from final drive with a power tool. Then suspend it by wire, etc. Refer to [RAX-10, "Exploded View"](#).
5. Remove breather hose from the final drive.
6. Remove rear wheel sensor. Refer to [BRC-130, "REAR WHEEL SENSOR : Exploded View"](#).



7. Set a suitable jack to rear final drive assembly.  
**CAUTION:**  
**Never place a jack on the rear cover (aluminum case).**
8. Remove the mounting bolts and nuts connecting to the suspension member, and remove rear final drive assembly with a power tool.  
**CAUTION:**  
**Secure rear final drive assembly to a suitable jack while removing it.**



## INSTALLATION

Revision: 2013 March

DLN-173

2014 QX50

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## REAR FINAL DRIVE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R200]

Note the following, and installation is in the reverse order of removal.

### CAUTION:

**Check that there are no pinched or restricted areas on the breather hose caused by bending or winding when installing it.**

- Install the breather hose (1) to breather connector until dimension (A) shown as follows.

A:

Final drive side : 20 mm (0.79 in)

Suspension member side : 20.5 mm (0.807 in)

### CAUTION:

- Never reuse hose clamp.
- Install the hose clamp at the final drive side, with the tab facing downward.
- Install the hose clamp at the suspension member side, with the tab facing downward.
- If remove breather connector, install breather hose (1) as shown in the figure.

2 : Suspension member

3 : Metal connector



⇐: Vehicle front

- For installation, insert the resin connector into rear suspension member. Install the metal connector in rear cover so that a paint mark becomes forward of the vehicle as shown in the figure. Arrange the breather hose then to pass by over wheel sensor harness.

### CAUTION:

**Never reuse breather connector.**

- When oil leaks while removing final drive assembly, check oil level after the installation. Refer to [DLN-156](#), "[Inspection](#)".



# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]


## UNIT DISASSEMBLY AND ASSEMBLY

### DIFFERENTIAL ASSEMBLY

2WD

2WD : Exploded View

INFOID:000000009062191



- |                                    |                             |                                   |
|------------------------------------|-----------------------------|-----------------------------------|
| 1. Drive pinion lock nut           | 2. Companion flange         | 3. Front oil seal                 |
| 4. Pinion front bearing            | 5. Gear carrier             | 6. Side oil seal                  |
| 7. Side flange                     | 8. Collapsible spacer       | 9. Pinion rear bearing            |
| 10. Pinion height adjusting washer | 11. Drive pinion            | 12. Side bearing adjusting washer |
| 13. Side bearing                   | 14. Side gear thrust washer | 15. Circular clip                 |
| 16. Side gear                      | 17. Lock pin                | 18. Pinion mate gear              |
| 19. Pinion mate thrust washer      | 20. Pinion mate shaft       | 21. Drive gear                    |
| 22. Differential case              | 23. Bearing cap             | 24. Filler plug                   |
| 25. Gasket                         | 26. Rear cover              | 27. Drain plug                    |
- A. Oil seal lip  
 B. Screw hole  
 C. Comply with the assembly procedure when tightening. Refer to [DLN-178, "2WD : Assembly"](#).

: Apply gear oil.


: Apply anti-corrosion oil.

: Apply Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

 L: Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).

Refer to [GI-4. "Components"](#) for symbols not described above.


## 2WD : Disassembly

INFOID:00000009062192


1. Drain gear oil, if necessary.
2. Remove side flange.
3. Remove rear cover mounting bolts.
4. Remove rear cover to insert the seal cutter (A) [SST: KV10111100 (J-37228)] between gear carrier and rear cover.

### CAUTION:

- Never damage the mating surface.
- Never insert flat-bladed screwdriver, this may damage the mating surface.




5. Using two 45 mm (1.77 in) spacers, mount carrier on the attachment (A) [SST: KV38100800 (J-25604-01)].




6. For proper reinstallation, paint matching marks on one side of the bearing cap.

### CAUTION:

- For matching marks, use paint. Never damage bearing caps and gear carrier.
- Bearing caps are manufactured as integral molding. Use the matching marks to them in their original positions.



7. Remove bearing caps.






# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

- Lift differential case assembly out with a sliding hammer (commercial service tool).



- Keep side bearing outer races together with inner race. Never mix them up. Also, keep side bearing adjusting washers together with bearings.




- Remove side bearing inner race with puller (A) and base (B). To prevent damage to bearing, engage puller jaws in groove (←).

A : Puller [SST: ST33051001 (J-22888-20)]

B : Base [SST: ST33061000 (J-8107-2)]

**CAUTION:**

- To prevent damage to the side bearing and drive gear, place copper plates between these parts and vise.
- It is not necessary to remove side bearing inner race except when it is replaced.



- For proper reinstallation, paint matching marks on one differential case assembly.


**CAUTION:**

For matching marks, use paint. Never damage differential case and drive gear.

- Remove drive gear mounting bolts.
- Tap drive gear off differential case assembly with a soft hammer.

**CAUTION:**

Tap evenly all around to keep drive gear from bending.




A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

13. Remove lock pin of pinion mate shaft with a punch from drive gear side.



14. Remove pinion mate shaft.




15. Turn pinion mate gear, then remove pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from differential case.

16. Remove circular clip from side gear.

**CAUTION:**

**Never damage side gear.**



## 2WD : Assembly


INFOID:000000009062193

1. Install circular clip to side gear.

**CAUTION:**

**Never damage side gear.**

2. Install side gear thrust washers with the same thickness as the ones installed prior to disassembly or reinstall the old ones on the side gears.




# DIFFERENTIAL ASSEMBLY


## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]


3. Install side gears and thrust washers into differential case.  
**CAUTION:**  
**Make sure that the circular clip is installed to side gears.**
4. Align 2 pinion mate gears in diagonally opposite positions, then rotate and install them into differential case after installing thrust washer to pinion mate gear.



5. Align the lock pin holes on differential case with shaft, and install pinion mate shaft.



6. Measure side gear end play. If necessary, select the appropriate side gear thrust washers.
  - a. Place differential case straight up so that side gear to be measured comes upward.



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

- b. Using feeler gauge, measure the clearance between side gear back and differential case at 3 different points, while rotating side gear. Average the 3 readings, and then measure the clearance of the other side as well.

**Side gear back clearance** : Refer to [DLN-216, "Differential Side Gear Clearance"](#).

**CAUTION:**

To prevent side gear from tilting, insert feeler gauges with the same thickness from both sides.

- c. If the back clearance is outside the specification, use a thicker/thinner side gear thrust washer to adjust. For selecting thrust washer, refer to the latest parts information.

**When the back clearance is large:** Use a thicker thrust washer.

**When the back clearance is small:** Use a thinner thrust washer.

**CAUTION:**

Select a side gear thrust washer for right and left individually.

7. Drive a lock pin into pinion mate shaft, using a punch. Make sure lock pin is flush with differential case.

**CAUTION:**

Never reuse lock pin.

8. Apply thread locking sealant into the thread hole of drive gear. Use Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

**CAUTION:**

Clean and degrease drive gear back and threaded holes sufficiently.

9. Install the drive gear to differential case.

**CAUTION:**

Align the matching marks of differential case and drive gear.

10. Tighten the mounting bolts with the following procedure.





**CAUTION:**

Apply anti-corrosion oil to the thread and seat of mounting bolts.

- a. Tighten the bolts in a crisscross fashion to the specified torque.

**Drive gear mounting bolts tightening torque** : 78.5 N•m (8.0 kg•m, 58 ft•lb)

- b. Tighten the bolts additionally to the specified angle.



# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

**Drive gear mounting bolts tightening angle : 31 to 36 degree**

**CAUTION:**

Check the tightening angle using the angle wrench [SST: KV10112100 (BT-8653-A)]. Never make judgment by visual inspection.


11. Press side bearing inner races to differential case, using the drift (A) and the base (B).

A : Drift [SST: KV38100300 (J-25523)]

B : Base [SST: ST33061000 (J-8107-2)]

**CAUTION:**

Never reuse side bearing inner race.




12. Set bearing outer races to differential case assembly, and install it with removed side bearing adjusting washer or same thickness washer into gear carrier.


**CAUTION:**

- Apply differential gear oil to the side bearings.
- Install side bearing and side bearing adjusting washer in correct location. (drive gear tooth side or drive gear back side)

13. Measure side bearing preload. If necessary, select the appropriate side bearing adjusting washers. Refer to [DLN-182, "2WD : Adjustment"](#).



14. Align matching marks on bearing cap with that on gear carrier.  
15. Install bearing caps and tighten bearing cap mounting bolts.




16. Using the drift [SST: KV38100200 (J-26233)], drive side oil seals until it becomes flush with the case end.

**CAUTION:**

- Never reuse oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.

17. Check and adjust drive gear runout, tooth contact, drive gear to drive pinion backlash, and total preload torque. Refer to [DLN-182, "2WD : Adjustment"](#).  
Recheck above items. Readjust the above description, if necessary.



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]


18. Apply sealant to mating surface of rear cover.

- Use Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

**CAUTION:**

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.

19. Install rear cover on gear carrier and tighten mounting bolts.




20. Install side flange with the following procedure.

- Attach the protector [SST: KV38107900 (J-39352)] to side oil seal.
- After the side flange is inserted and the serrated part of side gear has engaged the serrated part of flange, remove the protector.
- Put a suitable drift on the center of side flange, then drive it until sound changes.

**NOTE:**


When installation is completed, driving sound of the side flange turns into a sound that seems to affect the whole final drive.



- Confirm that the dimension of the side flange (1) installation measurement (A) in the figure comes into the following.

**Standard**

**A : 326 – 328 mm (12.83 – 12.91 in)**



## 2WD : Adjustment

INFOID:000000009062194

### TOTAL PRELOAD TORQUE

Before inspection and adjustment, drain gear oil.

- Secure final drive assembly onto an attachment [SST: KV38100800 (J-25604-01)].
- Remove side flanges.
- Rotate drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
- Rotate drive pinion at least 20 times to check for smooth operation of the bearing.
- Measure total preload with the preload gauge (A) [SST: ST3127S000 (J-25765-A)].


**Total preload torque : Refer to [DLN-216, "Pre-load Torque"](#).**

**NOTE:**

**Total preload torque = Pinion bearing preload torque + Side bearing preload torque**

- If measured value is out of the specification, disassemble it to check and adjust each part. Adjust the pinion bearing preload and side bearing preload.

Adjust the pinion bearing preload first, then adjust the side bearing preload.



# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

## When the preload torque is large

**On pinion bearings:** Replace the collapsible spacer.

**On side bearings:** Use thinner side bearing adjusting washers by the same amount to each side. For selecting adjusting washer, refer to the latest parts information.

## When the preload is small


**On pinion bearings:** Tighten the drive pinion lock nut.

**On side bearings:** Use thicker side bearing adjusting washers by the same amount to each side. For selecting adjusting washer, refer to the latest parts information.


## SIDE BEARING PRELOAD

Before inspection and adjustment, drain gear oil.


1. Remove rear cover. Refer to [DLN-176, "2WD : Disassembly"](#).
2. Make sure all parts are clean. Also, make sure the bearings are well lubricated with gear oil.
3. Place the differential case, with side bearings and bearing races installed, into gear carrier.



4. Insert left and right original side bearing adjusting washers in place between side bearings and gear carrier.



5. Install bearing caps in their correct locations and tighten bearing cap mounting bolts.
6. Turn the carrier several times to seat the bearings.



# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: R200]

7. Measure the turning torque of the carrier at the drive gear mounting bolts with a spring gauge [SST: — (J-8129)].

## Standard

## Specification

: 34.2 – 39.2 N (3.5 – 4.0 kg, 7.7 – 8.8 lb) of pulling force at the drive gear bolt




8. If the turning torque is outside the specification, use a thicker/thinner side bearing adjusting washer to adjust. For selecting adjusting washer, refer to the latest parts information.

If the turning torque is less than the specified range: Use a thicker adjusting washer.

If the turning torque is greater than the specification: Use a thinner adjusting washer.

## CAUTION:

Select a side bearing adjusting washer for right and left individually.



9. Record the total amount of washer thickness required for the correct carrier side bearing preload.

## DRIVE GEAR RUNOUT

1. Remove rear cover. Refer to [DLN-176. "2WD : Disassembly"](#).
2. Fit a dial indicator to the drive gear back face.
3. Rotate the drive gear to measure runout.


## Drive gear runout

: Refer to [DLN-216, "Drive Gear Runout"](#).

- If the runout is outside of the repair limit, check drive gear assembly condition; foreign material may be caught between drive gear and differential case, or differential case or drive gear may be deformed, etc.

## CAUTION:

Replace drive gear and drive pinion gear as a set.




## TOOTH CONTACT

Before inspection and adjustment, drain gear oil.

1. Remove rear cover. Refer to [DLN-176. "2WD : Disassembly"](#).
2. Apply red lead to drive gear.

## CAUTION:

Apply red lead to both the faces of 3 to 4 gears at 4 locations evenly spaced on drive gear.





# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

3. Rotate drive gear back and forth several times, check drive pinion gear to drive gear tooth contact.

**CAUTION:**

**Check tooth contact on drive side and reverse side.**




A  
B  
C

DLN

Tooth contact condition				Pinion height adjusting washer selection valve [ mm (in) ]	Adjustment (Yes/No)	Possible cause	
Drive side		Back side					
Heel side	Toe side	Toe side	Heel side				
				↑ Thicker	+0.09 (+0.0035)	Yes	Occurrence of noise and scoring sound in all speed ranges.
					+0.06 (+0.0024)		Occurrence of noise when accelerating.
					+0.03 (+0.0012)	No	—
				0			
				-0.03 (-0.0012)			
				↓ Thinner	-0.06 (-0.0024)	Yes	Occurrence of noise at constant speed and decreasing speed.
					-0.09 (-0.0035)		Occurrence of noise and scoring sound in all speed ranges.

S DIA0207E

4. If tooth contact is improperly adjusted, follow the procedure below to adjust the pinion height [dimension (X)].




E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIFFERENTIAL ASSEMBLY


## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

- If the tooth contact is near the face (face contact), or near the heel (heel contact), thicken pinion height adjusting washers to move drive pinion closer to drive gear.  
For selecting adjusting washer, refer to the latest parts information.



- If the tooth contact is near the flank (flank contact), or near the toe (toe contact), thin pinion height adjusting washers to move drive pinion farther from drive gear.  
For selecting adjusting washer, refer to the latest parts information.



## BACKLASH

Before inspection and adjustment, drain gear oil.

1. Remove rear cover. Refer to [DLN-176, "2WD : Disassembly"](#).
2. Fit a dial indicator to the drive gear face to measure the backlash.

**Backlash** : Refer to [DLN-216, "Backlash"](#).

- If the backlash is outside of the specified value, change the thickness of side bearing adjusting washer.

**When the backlash is large:**

**Make drive gear back side adjusting washer thicker, and drive gear tooth side adjusting washer thinner by the same amount. For selecting adjusting washer, refer to the latest parts information.**

**When the backlash is small:**

**Make drive gear back side adjusting washer thinner, and drive gear tooth side adjusting washer thicker by the same amount. For selecting adjusting washer, refer to the latest parts information.**

### **CAUTION:**

**Never change the total amount of washers as it changes the bearing preload.**


## 2WD : Inspection After Disassembly

INFOID:000000009062195

### DRIVE GEAR AND DRIVE PINION

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

### BEARING



# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

## SIDE GEAR AND PINION MATE GEAR

- Clean up the disassembled parts.
- If any cracks or damage on the surface of the tooth is found, replace.
- If any worn or chipped mark on the contact sides of the thrust washer is found, replace.

## SIDE GEAR THRUST WASHER AND PINION MATE THRUST WASHER

- Clean up the disassembled parts.
- If it is chipped (by friction), damaged, or unusually worn, replace.

## OIL SEAL

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

## DIFFERENTIAL CASE

- Clean up the disassembled parts.
- If any wear or crack on the contact sides of the differential case is found, replace.


## COMPANION FLANGE

- Clean up the disassembled parts.
- If any chipped mark [about 0.1 mm, (0.004 in)] or other damage on the contact sides of the lips of the companion flange is found, replace.

## AWD

### AWD : Exploded View

INFOID:000000009062196




- |                          |                     |                   |
|--------------------------|---------------------|-------------------|
| 1. Drive pinion lock nut | 2. Companion flange | 3. Front oil seal |
| 4. Pinion front bearing  | 5. Gear carrier     | 6. Side oil seal  |


# DIFFERENTIAL ASSEMBLY

## < UNIT DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: R200]

- |                                    |                             |                                                                                                             |
|------------------------------------|-----------------------------|-------------------------------------------------------------------------------------------------------------|
| 7. Side flange                     | 8. Collapsible spacer       | 9. Pinion rear bearing                                                                                      |
| 10. Pinion height adjusting washer | 11. Drive pinion            | 12. Side bearing adjusting washer                                                                           |
| 13. Side bearing                   | 14. Side gear thrust washer | 15. Circular clip                                                                                           |
| 16. Side gear                      | 17. Lock pin                | 18. Pinion mate gear                                                                                        |
| 19. Pinion mate thrust washer      | 20. Pinion mate shaft       | 21. Drive gear                                                                                              |
| 22. Differential case              | 23. Bearing cap             | 24. Filler plug                                                                                             |
| 25. Gasket                         | 26. Rear cover              | 27. Drain plug                                                                                              |
| A. Oil seal lip                    | B. Screw hole               | C. Comply with the assembly procedure when tightening. Refer to <a href="#">DLN-191</a> , "AWD : Assembly". |

: Apply gear oil.

\*: Apply anti-corrosion oil.

: Apply Genuine Silicone RTV or equivalent. Refer to [GI-22](#), "Recommended Chemical Products and Sealants".

L: Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22](#), "Recommended Chemical Products and Sealants".

Refer to [GI-4](#), "Components" for symbols not described above.


## AWD : Disassembly

INFOID:000000009062197


1. Drain gear oil, if necessary.
2. Remove side flange.
3. Remove rear cover mounting bolts.
4. Remove rear cover to insert the seal cutter (A) [SST: KV10111100 (J-37228)] between gear carrier and rear cover.

### CAUTION:

- Never damage the mating surface.
- Never insert flat-bladed screwdriver, this may damage the mating surface.



5. Using two 45 mm (1.77 in) spacers, mount carrier on the attachment (A) [SST: KV38100800 (J-25604-01)].



# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]


6. For proper reinstallation, paint matching marks on one side of the bearing cap.

**CAUTION:**


- For matching marks, use paint. Never damage bearing caps and gear carrier.
- Bearing caps are manufactured as integral molding. Use the matching marks to them in their original positions.




7. Remove bearing caps.



8. Lift differential case assembly out with a sliding hammer (commercial service tool).



- Keep side bearing outer races together with inner race. Never mix them up. Also, keep side bearing adjusting washers together with bearings.



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIFFERENTIAL ASSEMBLY

## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]


9. Remove side bearing inner race with puller (A) and base (B). To prevent damage to bearing, engage puller jaws in groove (←).

A : Puller [SST: ST33051001 (J-22888-20)]

B : Base [SST: ST33061000 (J-8107-2)]

**CAUTION:**

- To prevent damage to the side bearing and drive gear, place copper plates between these parts and vise.
- It is not necessary to remove side bearing inner race except when it is replaced.



10. For proper reinstallation, paint matching marks on one differential case assembly.


**CAUTION:**

**For matching marks, use paint. Never damage differential case and drive gear.**


11. Remove drive gear mounting bolts.  
12. Tap drive gear off differential case assembly with a soft hammer.

**CAUTION:**


**Tap evenly all around to keep drive gear from bending.**



13. Remove lock pin of pinion mate shaft with a punch from drive gear side.



14. Remove pinion mate shaft.




# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]


15. Turn pinion mate gear, then remove pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from differential case.
16. Remove circular clip from side gear.  
**CAUTION:**  
**Never damage side gear.**




## AWD : Assembly

INFOID:000000009062198


1. Install circular clip to side gear.  
**CAUTION:**  
**Never damage side gear.**
2. Install side gear thrust washers with the same thickness as the ones installed prior to disassembly or reinstall the old ones on the side gears.



3. Install side gears and thrust washers into differential case.  
**CAUTION:**  
**Make sure that the circular clip is installed to side gears.**
4. Align 2 pinion mate gears in diagonally opposite positions, then rotate and install them into differential case after installing thrust washer to pinion mate gear.



5. Align the lock pin holes on differential case with shaft, and install pinion mate shaft.



6. Measure side gear end play. If necessary, select the appropriate side gear thrust washers.


A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

- a. Place differential case straight up so that side gear to be measured comes upward.



- b. Using feeler gauge, measure the clearance between side gear back and differential case at 3 different points, while rotating side gear. Average the 3 readings, and then measure the clearance of the other side as well.

**Side gear back clearance** : Refer to [DLN-216, "Differential Side Gear Clearance"](#).

**CAUTION:**

To prevent side gear from tilting, insert feeler gauges with the same thickness from both sides.


- c. If the back clearance is outside the specification, use a thicker/thinner side gear thrust washer to adjust. For selecting thrust washer, refer to the latest parts information.

**When the back clearance is large:** Use a thicker thrust washer.

**When the back clearance is small:** Use a thinner thrust washer.

**CAUTION:**


Select a side gear thrust washer for right and left individually.



7. Drive a lock pin into pinion mate shaft, using a punch. Make sure lock pin is flush with differential case.

**CAUTION:**

Never reuse lock pin.



8. Apply thread locking sealant into the thread hole of drive gear. Use Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).


**CAUTION:**

Clean and degrease drive gear back and threaded holes sufficiently.

9. Install the drive gear to differential case.

**CAUTION:**

Align the matching marks of differential case and drive gear.





# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

10. Tighten the mounting bolts with the following procedure.

**CAUTION:**


**Apply anti-corrosion oil to the thread and seat of mounting bolts.**

a. Tighten the bolts in a crisscross fashion to the specified torque.

**Drive gear mounting bolts tightening torque : 78.5 N•m (8.0 kg-m, 58 ft-lb)**

b. Tighten the bolts additionally to the specified angle.

**Drive gear mounting bolts tightening angle : 31 to 36 degree**



**CAUTION:**

**Check the tightening angle using the angle wrench [SST: KV10112100 (BT-8653-A)]. Never make judgment by visual inspection.**


11. Press side bearing inner races to differential case, using the drift (A) and the base (B).

A : Drift [SST: KV38100300 (J-25523)]

B : Base [SST: ST33061000 (J-8107-2)]

**CAUTION:**

**Never reuse side bearing inner race.**




12. Set bearing outer races to differential case assembly, and install it with removed side bearing adjusting washer or same thickness washer into gear carrier.

**CAUTION:**


- Apply differential gear oil to the side bearings.
- Install side bearing and side bearing adjusting washer in correct location. (drive gear tooth side or drive gear back side)

13. Measure side bearing preload. If necessary, select the appropriate side bearing adjusting washers. Refer to [DLN-194, "AWD : Adjustment"](#).



14. Align matching marks on bearing cap with that on gear carrier.

15. Install bearing caps and tighten bearing cap mounting bolts.



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

16. Using the drift (A) [SST: KV38100200 (J-26233)], drive side oil seals until it becomes flush with the case end.

**CAUTION:**

- Never reuse oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.

17. Check and adjust drive gear runout, tooth contact, drive gear to drive pinion backlash, and total preload torque. Refer to [DLN-194](#), "AWD : Adjustment".  
Recheck above items. Readjust the above description, if necessary.



18. Apply sealant to mating surface of rear cover.

- Use Genuine Silicone RTV or equivalent. Refer to [GI-22](#), "Recommended Chemical Products and Sealants".

**CAUTION:**

Remove old sealant adhering to mounting surfaces. Also remove any moisture, oil, or foreign material adhering to application and mounting surfaces.

19. Install rear cover on gear carrier and tighten mounting bolts.




20. Install side flange with the following procedure.

- a. Attach the protector [SST: KV38107900 (J-39352)] to side oil seal.
- b. After the side flange is inserted and the serrated part of side gear has engaged the serrated part of flange, remove the protector.

- c. Put a suitable drift on the center of side flange, then drive it until sound changes.

**NOTE:**


When installation is completed, driving sound of the side flange turns into a sound that seems to affect the whole final drive.



- d. Confirm that the dimension of the side flange installation measurement (A) in the figure comes into the following.

**Standard**

**A** : 326 – 328 mm (12.83 – 12.91 in)



## AWD : Adjustment

INFOID:000000009062199

### TOTAL PRELOAD TORQUE

Before inspection and adjustment, drain gear oil.

1. Secure final drive assembly onto an attachment [SST: KV38100800 (J-25604-01)].
2. Remove side flanges.
3. Rotate drive pinion back and forth 2 to 3 times to check for unusual noise and rotation malfunction.
4. Rotate drive pinion at least 20 times to check for smooth operation of the bearing.

# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]


5. Measure total preload with the preload gauge (A) [SST: ST3127S000 (J-25765-A)].

**Total preload torque** : Refer to [DLN-216, "Preload Torque"](#).

**NOTE:**

**Total preload torque = Pinion bearing preload torque + Side bearing preload torque**

- If measured value is out of the specification, disassemble it to check and adjust each part. Adjust the pinion bearing preload and side bearing preload.  
Adjust the pinion bearing preload first, then adjust the side bearing preload.



PDA0766J

**When the preload torque is large**

**On pinion bearings:** Replace the collapsible spacer.

**On side bearings:** Use thinner side bearing adjusting washers by the same amount to each side. For selecting adjusting washer, refer to the latest parts information.

**When the preload is small**


**On pinion bearings:** Tighten the drive pinion lock nut.

**On side bearings:** Use thicker side bearing adjusting washers by the same amount to each side. For selecting adjusting washer, refer to the latest parts information.

## SIDE BEARING PRELOAD


Before inspection and adjustment, drain gear oil.

1. Remove rear cover. Refer to [DLN-188, "AWD : Disassembly"](#).
2. Make sure all parts are clean. Also, make sure the bearings are well lubricated with gear oil.
3. Place the differential case, with side bearings and bearing races installed, into gear carrier.



SPD527

4. Insert left and right original side bearing adjusting washers in place between side bearings and gear carrier.




SPD558

# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

5. Install bearing caps in their correct locations and tighten bearing cap mounting bolts.
6. Turn the carrier several times to seat the bearings.




7. Measure the turning torque of the carrier at the drive gear mounting bolts with a spring gauge [SST: — (J-8129)].

### Standard

### Specification

: 34.2 – 39.2 N (3.5 – 4.0 kg, 7.7 – 8.8 lb) of pulling force at the drive gear bolt




8. If the turning torque is outside the specification, use a thicker/thinner side bearing adjusting washer to adjust. For selecting adjusting washer, refer to the latest parts information.

If the turning torque is less than the specified range:

Use a thicker adjusting washer.

If the turning torque is greater than the specification:

Use a thinner adjusting washer.



### CAUTION:

Select a side bearing adjusting washer for right and left individually.

9. Record the total amount of washer thickness required for the correct carrier side bearing preload.

## DRIVE GEAR RUNOUT

1. Remove rear cover. Refer to [DLN-188, "AWD : Disassembly"](#).
2. Fit a dial indicator to the drive gear back face.
3. Rotate the drive gear to measure runout.


### Drive gear runout

: Refer to [DLN-216, "Drive Gear Runout"](#).

- If the runout is outside of the repair limit, check drive gear assembly condition; foreign material may be caught between drive gear and differential case, or differential case or drive gear may be deformed, etc.

### CAUTION:

Replace drive gear and drive pinion gear as a set.



## TOOTH CONTACT

Before inspection and adjustment, drain gear oil.

1. Remove rear cover. Refer to [DLN-188, "AWD : Disassembly"](#).

# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

2. Apply red lead to drive gear.

**CAUTION:**


Apply red lead to both the faces of 3 to 4 gears at 4 locations evenly spaced on drive gear.



3. Rotate drive gear back and forth several times, check drive pinion gear to drive gear tooth contact.

**CAUTION:**

Check tooth contact on drive side and reverse side.



Tooth contact condition		Pinion height adjusting washer selection valve [ mm (in) ]	Adjustment (Yes/No)	Possible cause
Drive side	Back side			
Heel side 	Toe side 	↑ Thicker	Yes	Occurrence of noise and scoring sound in all speed ranges.
				Occurrence of noise when accelerating.
				—
		0	No	—
		↓ Thinner	Yes	Occurrence of noise at constant speed and decreasing speed.
				Occurrence of noise and scoring sound in all speed ranges.
				—

SDIA0207E


A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DIFFERENTIAL ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]


4. If tooth contact is improperly adjusted, follow the procedure below to adjust the pinion height [dimension (X)].



- If the tooth contact is near the face (face contact), or near the heel (heel contact), thicken pinion height adjusting washers to move drive pinion closer to drive gear. For selecting adjusting washer, refer to the latest parts information.



- If the tooth contact is near the flank (flank contact), or near the toe (toe contact), thin pinion height adjusting washers to move drive pinion farther from drive gear. For selecting adjusting washer, refer to the latest parts information.



## BACKLASH

Before inspection and adjustment, drain gear oil.


1. Remove rear cover. Refer to [DLN-188, "AWD : Disassembly"](#).
2. Fit a dial indicator to the drive gear face to measure the backlash.

**Backlash** : Refer to [DLN-216, "Backlash"](#).

- If the backlash is outside of the specified value, change the thickness of side bearing adjusting washer.

**When the backlash is large:**

**Make drive gear back side adjusting washer thicker, and drive gear tooth side adjusting washer thinner by the same amount. For selecting adjusting washer, refer to the latest parts information.**



# DIFFERENTIAL ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

## When the backlash is small:

**Make drive gear back side adjusting washer thinner, and drive gear tooth side adjusting washer thicker by the same amount. For selecting adjusting washer, refer to the latest parts information.**

### **CAUTION:**

**Never change the total amount of washers as it changes the bearing preload.**

## AWD : Inspection After Disassembly

INFOID:000000009062200

### DRIVE GEAR AND DRIVE PINION

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

### BEARING

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

### SIDE GEAR AND PINION MATE GEAR

- Clean up the disassembled parts.
- If any cracks or damage on the surface of the tooth is found, replace.
- If any worn or chipped mark on the contact sides of the thrust washer is found, replace.

### SIDE GEAR THRUST WASHER AND PINION MATE THRUST WASHER

- Clean up the disassembled parts.
- If it is chipped (by friction), damaged, or unusually worn, replace.

### OIL SEAL

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

### DIFFERENTIAL CASE

- Clean up the disassembled parts.
- If any wear or crack on the contact sides of the differential case is found, replace.

### COMPANION FLANGE

- Clean up the disassembled parts.
- If any chipped mark [about 0.1 mm, (0.004 in)] or other damage on the contact sides of the lips of the companion flange is found, replace.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: R200]

## DRIVE PINION

2WD

2WD : Exploded View

INFOID:000000009062201



- |                                    |                             |                                                                                                             |
|------------------------------------|-----------------------------|-------------------------------------------------------------------------------------------------------------|
| 1. Drive pinion lock nut           | 2. Companion flange         | 3. Front oil seal                                                                                           |
| 4. Pinion front bearing            | 5. Gear carrier             | 6. Side oil seal                                                                                            |
| 7. Side flange                     | 8. Collapsible spacer       | 9. Pinion rear bearing                                                                                      |
| 10. Pinion height adjusting washer | 11. Drive pinion            | 12. Side bearing adjusting washer                                                                           |
| 13. Side bearing                   | 14. Side gear thrust washer | 15. Circular clip                                                                                           |
| 16. Side gear                      | 17. Lock pin                | 18. Pinion mate gear                                                                                        |
| 19. Pinion mate thrust washer      | 20. Pinion mate shaft       | 21. Drive gear                                                                                              |
| 22. Differential case              | 23. Bearing cap             | 24. Filler plug                                                                                             |
| 25. Gasket                         | 26. Rear cover              | 27. Drain plug                                                                                              |
| A. Oil seal lip                    | B. Screw hole               | C. Comply with the assembly procedure when tightening. Refer to <a href="#">DLN-178, "2WD : Assembly"</a> . |

: Apply gear oil.

: Apply anti-corrosion oil.

: Apply Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

: Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

Refer to [GI-4, "Components"](#) for symbols not described above.



# DRIVE PINION


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

INFOID:000000009062202

## 2WD : Disassembly

1. Remove differential case assembly. Refer to [DLN-176. "2WD : Disassembly"](#).
2. Remove drive pinion lock nut with the flange wrench (commercial service tool).



3. Put matching mark (B) on the end of drive pinion. The matching mark should be in line with the matching mark (A) on companion flange (1).


**CAUTION:**

**For matching mark, use paint. Never damage companion flange and drive pinion.**


**NOTE:**

The matching mark on the final drive companion flange indicates the maximum vertical runout position.

When replacing companion flange, matching mark is not necessary.



4. Remove companion flange using the suitable puller (commercial service tool).




5. Press drive pinion assembly out of gear carrier.

**CAUTION:**

**Never drop drive pinion assembly.**

6. Remove front oil seal.
7. Remove side oil seal.
8. Remove pinion front bearing inner race.
9. Remove collapsible spacer.




A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DRIVE PINION

## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]


10. Remove pinion rear bearing inner race and pinion height adjusting washer with the replacer (A) (commercial service tool).



11. Tap pinion front/rear bearing outer races uniformly using a brass rod or equivalent to remove them.

**CAUTION:**

**Never damage gear carrier.**




## 2WD : Assembly

1. Install front bearing outer race (1) and rear bearing outer race (2) using drifts (A, B and D) and drift bar (C).

- A : Drift [SST: ST30720000 (J-25405)]  
B : Drift [SST: KV40105230 ( — )]  
C : Drift bar [SST: ST30611000 (J-25742-1)]  
D : Drift [SST: ST30613000 (J-25742-3)]

**CAUTION:**

- At first, using a hammer, tap bearing outer race until it becomes flat to gear carrier.
- Never reuse pinion front and rear bearing outer race.



INFOID:000000009062203

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

2. Temporarily install pinion height adjusting washer (1).

**When hypoid gear set has been replaced**


- Select pinion height adjusting washer. Refer to [DLN-206](#), "[2WD : Adjustment](#)".

**When hypoid gear set has been reused**

- Temporarily install the removed pinion height adjusting washer or same thickness washer to drive pinion.

**CAUTION:**

Pay attention to the direction of pinion height adjusting washer. (Assemble as shown in the figure.)



3. Install pinion rear bearing inner race (1) to drive pinion with the drift (A) [SST: ST30901000 (J-26010-01)].

**CAUTION:**

**Never reuse pinion rear bearing inner race.**

4. Check and adjust the tooth contact and back lash of drive gear and drive pinion following the procedure below.

- a. Assemble drive pinion into gear carrier.

**CAUTION:**



- **Never assemble collapsible spacer at this time.**
- **Apply gear oil to pinion rear bearing.**

- b. Assemble pinion front bearing inner race to drive pinion assembly.

**CAUTION:**

- **Never reuse pinion front bearing inner race.**
- **Apply gear oil to pinion front bearing.**

- c. Using suitable spacer (A) (commercial service tool), press the pinion front bearing inner race to drive pinion as far as drive pinion nut can be tightened.




- d. Install companion flange.

**CAUTION:**

**Never install front oil seal at this time.**

**NOTE:**

When reusing drive pinion, align the matching mark (B) of drive pinion with the matching mark (A) of companion flange, and then install companion flange (1).



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

- e. Temporarily tighten removed drive pinion nut to drive pinion, using flange wrench (commercial service tool).

A : Preload gauge [SST: ST3127S000 (J-25765-A)]

**NOTE:**

Use removed drive pinion nut only for the preload measurement.

- f. Rotate drive pinion more than 20 times to adjust bearing.  
g. Tighten to drive pinion lock nut using flange wrench (commercial service tool), while adjusting pinion bearing preload torque using preload gauge [SST: ST3127S000 (J-25765-A)].

**Pinion bearing preload (without oil seal) : 1.0 - 1.3 N·m (0.11 – 0.13 kg-m, 9 – 11 in-lb)**

**CAUTION:**

Drive pinion nut is tightened with no collapsible spacer. Be careful not to overtighten it. While measuring the preload, tighten drive pinion nut in 5° to 10° increments.

- h. Assemble removed drive side bearing adjusting washer or same thickness of it and install differential case assembly. Refer to [DLN-178. "2WD : Assembly"](#).

**CAUTION:**

- Apply differential gear oil to the side bearings.
- Install side bearing and side bearing adjusting washer in correct location. (drive gear tooth side or drive gear back side)

- i. Install bearing caps.  
j. Check and adjust tooth contact and drive gear to drive pinion backlash. Refer to [DLN-182. "2WD : Adjustment"](#).

- k. Remove bearing caps and differential case assembly.  
l. Remove companion flange.

- m. Remove drive pinion assembly from gear carrier.

**CAUTION:**

Never drop the drive pinion assembly.

- n. Remove pinion front bearing inner race.  
5. Assemble collapsible spacer.

**CAUTION:**

Never reuse collapsible spacer.

6. Assemble drive pinion into gear carrier.

**CAUTION:**




Apply gear oil to pinion rear bearing.

7. Assemble pinion front bearing inner race to drive pinion assembly.

**CAUTION:**

- Never reuse pinion front bearing inner race.
- Apply gear oil to pinion front bearing.

8. Using suitable spacer (A) (commercial service tool), press the pinion front bearing inner race to drive pinion as far as drive pinion nut can be tightened.



# DRIVE PINION


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

9. Using the drift (A) [SST: ST30720000 (J-25405)], install front oil seal as shown in figure.

**CAUTION:**


- Never reuse oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.



10. Install companion flange.

**NOTE:**

When reusing drive pinion, align the matching mark (B) of drive pinion with the matching mark (A) of companion flange, and then install companion flange (1).



11. Apply anti-corrosion oil to the thread and seat of drive pinion lock nut, and temporarily tighten drive pinion lock nut to drive pinion, using flange wrench (commercial service tool).

A : Preload gauge [SST: ST3127S000 (J-25765-A)]

**CAUTION:**


**Never reuse drive pinion lock nut.**

12. Adjust to the drive pinion lock nut tightening torque and pinion bearing preload torque, using preload gauge [SST: ST3127S000 (J-25765-A)].

**Pinion bearing preload** : Refer to [DLN-216, "Pre-load Torque"](#).

**CAUTION:**

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- If the preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Never loosen drive pinion lock nut to adjust the preload torque.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.



13. Install differential case assembly. Refer to [DLN-178, "2WD : Assembly"](#).

**CAUTION:**

**Never install rear cover at this timing.**

14. Check and adjust drive gear runout, tooth contact, drive gear to drive pinion backlash, and companion flange runout. Refer to [DLN-182, "2WD : Adjustment"](#) and [DLN-206, "2WD : Adjustment"](#). Recheck above items. Readjust the above description, if necessary.
15. Check total preload torque. Refer to [DLN-182, "2WD : Adjustment"](#).
16. Install rear cover. Refer to [DLN-178, "2WD : Assembly"](#).

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

INFOID:00000009062204

## 2WD : Adjustment

### PINION GEAR HEIGHT


If the hypoid gear set has been replaced, select the pinion height adjusting washer.

1. Use the formula below to calculate pinion height adjusting washer thickness.

#### Washer selection equation:

$$T = T_0 + (t_1 - t_2)$$

- T: Correct washer thickness
- T<sub>0</sub>: Removed washer thickness
- t<sub>1</sub>: Old drive pinion head letter "H × 0.01"  
("H": machined tolerance 1/100 mm × 100)
- t<sub>2</sub>: New drive pinion head letter "H × 0.01"  
("H": machined tolerance 1/100 mm × 100)



#### Example:

$$T = 3.21 + [(2 \times 0.01) - (-1 \times 0.01)] = 3.24$$

- T<sub>0</sub>: 3.21
- t<sub>1</sub>: +2
- t<sub>2</sub>: -1

2. Select the proper pinion height adjusting washer. For selecting adjusting washer, refer to the latest parts information.

#### CAUTION:

If unable to find a washer of desired thickness, use a washer with thickness closest to the calculated value.

#### Example:

Calculated value... T = 3.22 mm


Used washer... T = 3.21 mm

### DRIVE PINION RUNOUT

1. Set a dial indicator (A) vertically to the tip of the drive pinion.
2. Rotate drive pinion to check for runout.

Drive pinion runout : Refer to [DLN-216, "Drive Pinion Runout \(2WD\)"](#).

3. If the runout value is outside of the limit, possible causes are an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.



## 2WD : Inspection After Disassembly

INFOID:00000009062205

### DRIVE GEAR AND DRIVE PINION

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

### BEARING

- Clean up the disassembled parts.

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

## SIDE GEAR AND PINION MATE GEAR

- Clean up the disassembled parts.
- If any cracks or damage on the surface of the tooth is found, replace.
- If any worn or chipped mark on the contact sides of the thrust washer is found, replace.

## SIDE GEAR THRUST WASHER AND PINION MATE THRUST WASHER

- Clean up the disassembled parts.
- If it is chipped (by friction), damaged, or unusually worn, replace.

## OIL SEAL

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

## DIFFERENTIAL CASE

- Clean up the disassembled parts.
- If any wear or crack on the contact sides of the differential case is found, replace.


## COMPANION FLANGE

- Clean up the disassembled parts.
- If any chipped mark [about 0.1 mm, (0.004 in)] or other damage on the contact sides of the lips of the companion flange is found, replace.

## AWD

## AWD : Exploded View

INFOID:000000009062206




- |                          |                       |                        |
|--------------------------|-----------------------|------------------------|
| 1. Drive pinion lock nut | 2. Companion flange   | 3. Front oil seal      |
| 4. Pinion front bearing  | 5. Gear carrier       | 6. Side oil seal       |
| 7. Side flange           | 8. Collapsible spacer | 9. Pinion rear bearing |


# DRIVE PINION

## < UNIT DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: R200]

- |                                    |                             |                                                                                                             |
|------------------------------------|-----------------------------|-------------------------------------------------------------------------------------------------------------|
| 10. Pinion height adjusting washer | 11. Drive pinion            | 12. Side bearing adjusting washer                                                                           |
| 13. Side bearing                   | 14. Side gear thrust washer | 15. Circular clip                                                                                           |
| 16. Side gear                      | 17. Lock pin                | 18. Pinion mate gear                                                                                        |
| 19. Pinion mate thrust washer      | 20. Pinion mate shaft       | 21. Drive gear                                                                                              |
| 22. Differential case              | 23. Bearing cap             | 24. Filler plug                                                                                             |
| 25. Gasket                         | 26. Rear cover              | 27. Drain plug                                                                                              |
| A. Oil seal lip                    | B. Screw hole               | C. Comply with the assembly procedure when tightening. Refer to <a href="#">DLN-191</a> , "AWD : Assembly". |

: Apply gear oil.

\*: Apply anti-corrosion oil.

: Apply Genuine Silicone RTV or equivalent. Refer to [GI-22](#), "Recommended Chemical Products and Sealants".


Ⓛ: Apply Genuine High Strength Thread Locking Sealant or equivalent. Refer to [GI-22](#), "Recommended Chemical Products and Sealants".

Refer to [GI-4](#), "Components" for symbols not described above.

## AWD : Disassembly

INFOID:000000009062207

1. Remove differential case assembly. Refer to [DLN-188](#), "AWD : Disassembly".
2. Remove drive pinion lock nut with the flange wrench (commercial service tool).



3. Put matching mark (B) on the end of drive pinion. The matching mark should be in line with the matching mark (A) on companion flange (1).


### CAUTION:

**For matching mark, use paint. Never damage companion flange and drive pinion.**


### NOTE:

The matching mark on the final drive companion flange indicates the maximum vertical runout position.

When replacing companion flange, matching mark is not necessary.



4. Remove companion flange using the suitable puller (commercial service tool).





# DRIVE PINION

## < UNIT DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: R200]

5. Press drive pinion assembly out of gear carrier.


**CAUTION:**

**Never drop drive pinion assembly.**

6. Remove front oil seal.  
7. Remove side oil seal.  
8. Remove pinion front bearing inner race.  
9. Remove collapsible spacer.




10. Remove pinion rear bearing inner race and pinion height adjusting washer with the replacer (A) (commercial service tool).



11. Tap pinion front/rear bearing outer races uniformly using a brass rod or equivalent to remove them.

**CAUTION:**

**Never damage gear carrier.**



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

AWD : Assembly


INFOID:00000009062208

1. Install front bearing outer race (1) and rear bearing outer race (2) using drifts (A, B and D) and drift bar (C).

- A : Drift [SST: ST30720000 (J-25405)]
- B : Drift [SST: KV40105230 ( — )]
- C : Drift bar [SST: ST30611000 (J-25742-1)]
- D : Drift [SST: ST30613000 (J-25742-3)]

**CAUTION:**

- At first, using a hammer, tap bearing outer race until it becomes flat to gear carrier.
- Never reuse pinion front and rear bearing outer race.



2. Temporarily install pinion height adjusting washer (1).

**When hypoid gear set has been replaced**


- Select pinion height adjusting washer. Refer to [DLN-213](#), "[AWD : Adjustment](#)".

**When hypoid gear set has been reused**

- Temporarily install the removed pinion height adjusting washer or same thickness washer to drive pinion.

**CAUTION:**

**Pay attention to the direction of pinion height adjusting washer. (Assemble as shown in the figure.)**



3. Install pinion rear bearing inner race (1) to drive pinion with the drift (A) [SST: ST30901000 (J-26010-01)].

**CAUTION:**

**Never reuse pinion rear bearing inner race.**

4. Check and adjust the tooth contact and back lash of drive gear and drive pinion following the procedure below.

- a. Assemble drive pinion into gear carrier.


**CAUTION:**

- Never install collapsible spacer at this time.
- Apply gear oil to pinion rear bearing.

- b. Assemble pinion front bearing inner race to drive pinion assembly.

**CAUTION:**

- Never reuse pinion front bearing inner race.
- Apply gear oil to pinion front bearing.




# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

- c. Using suitable spacer (A) (commercial service tool), press the pinion front bearing inner race to drive pinion as far as drive pinion nut can be tightened.




- d. Install companion flange.

**CAUTION:**

**Never install front oil seal at this time.**

**NOTE:**

When reusing drive pinion, align the matching mark (B) of drive pinion with the matching mark (A) of companion flange, and then install companion flange (1).




- e. Temporarily tighten removed drive pinion nut to drive pinion, using flange wrench (commercial service tool).

A : Preload gauge [SST: ST3127S000 (J-25765-A)]

**NOTE:**

Use removed drive pinion nut only for the preload measurement.

- f. Rotate drive pinion more than 20 times to adjust bearing.  
g. Tighten to drive pinion lock nut using flange wrench (commercial service tool), while adjusting pinion bearing preload torque using preload gauge [SST: ST3127S000 (J-25765-A)].



**Pinion bearing preload (without oil seal) : 1.0 - 1.3 N·m (0.11 – 0.13 kg·m, 9 – 11 in·lb)**

**CAUTION:**

**Drive pinion nut is tightened with no collapsible spacer. Be careful not to overtighten it. While measuring the preload, tighten drive pinion nut in 5° to 10° increments.**

- h. Assemble removed drive side bearing adjusting washer or same thickness of it and install differential case assembly. Refer to [DLN-191. "AWD : Assembly"](#).

**CAUTION:**

- Apply differential gear oil to the side bearings.
- Install side bearing and side bearing adjusting washer in correct location. (drive gear tooth side or drive gear back side)

- i. Install bearing caps.  
j. Check and adjust tooth contact and drive gear to drive pinion backlash. Refer to [DLN-194. "AWD : Adjustment"](#).  
k. Remove bearing caps and differential case assembly.  
l. Remove companion flange.

A  
B  
C  
DLN

E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DRIVE PINION

## < UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

- m. Remove drive pinion assembly from gear carrier.

**CAUTION:**

**Never drop the drive pinion assembly.**

- n. Remove pinion front bearing inner race.

5. Assemble collapsible spacer.

**CAUTION:**

**Never reuse collapsible spacer.**

6. Assemble drive pinion into gear carrier.

**CAUTION:**



**Apply gear oil to pinion rear bearing.**

7. Assemble pinion front bearing inner race to drive pinion assembly.

**CAUTION:**

- **Never reuse pinion front bearing inner race.**
- **Apply gear oil to pinion front bearing.**


8. Using suitable spacer (A) (commercial service tool), press the pinion front bearing inner race to drive pinion as far as drive pinion nut can be tightened.



9. Using the drift (A) [SST: ST30720000 (J-25405)], install front oil seal as shown in figure.

**CAUTION:**


- **Never reuse oil seal.**
- **When installing, never incline oil seal.**
- **Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of oil seal.**



10. Install companion flange.

**NOTE:**

When reusing drive pinion, align the matching mark (B) of drive pinion with the matching mark (A) of companion flange, and then install companion flange (1).



# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

11. Apply anti-corrosion oil to the thread and seat of drive pinion lock nut, and temporarily tighten drive pinion lock nut to drive pinion, using flange wrench (commercial service tool).

A : Preload gauge [SST: ST3127S000 (J-25765-A)]

**CAUTION:**

**Never reuse drive pinion lock nut.**

12. Adjust to the drive pinion lock nut tightening torque and pinion bearing preload torque, using preload gauge [SST: ST3127S000 (J-25765-A)].

**Pinion bearing preload** : Refer to [DLN-216, "Pre-load Torque"](#).

**CAUTION:**

- Adjust to the lower limit of the drive pinion lock nut tightening torque first.
- If the preload torque exceeds the specified value, replace collapsible spacer and tighten it again to adjust. Never loosen drive pinion lock nut to adjust the preload torque.
- After adjustment, rotate drive pinion back and forth 2 to 3 times to check for unusual noise, rotation malfunction, and other malfunctions.

13. Install differential case assembly. Refer to [DLN-191, "AWD : Assembly"](#).

**CAUTION:**

**Never install rear cover at this timing.**

14. Check and adjust drive gear runout, tooth contact, drive gear to drive pinion backlash, and companion flange runout. Refer to [DLN-194, "AWD : Adjustment"](#) and [DLN-213, "AWD : Adjustment"](#). Recheck above items. Readjust the above description, if necessary.
15. Check total preload torque. Refer to [DLN-194, "AWD : Adjustment"](#).
16. Install rear cover. Refer to [DLN-191, "AWD : Assembly"](#).

## AWD : Adjustment

INFOID:000000009062209

## PINION GEAR HEIGHT

If the hypoid gear set has been replaced, select the pinion height adjusting washer.

1. Use the formula below to calculate pinion height adjusting washer thickness.

**Washer selection equation:**



$$T = T_0 + (t_1 - t_2)$$

- T:** Correct washer thickness
- T<sub>0</sub>:** Removed washer thickness
- t<sub>1</sub>:** Old drive pinion head letter "H × 0.01" ("H": machined tolerance 1/100 mm × 100)
- t<sub>2</sub>:** New drive pinion head letter "H × 0.01" ("H": machined tolerance 1/100 mm × 100)

**Example:**

$$T = 3.21 + [(2 \times 0.01) - (-1 \times 0.01)] = 3.24$$

- T<sub>0</sub>:** 3.21
- t<sub>1</sub>:** +2
- t<sub>2</sub>:** -1



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

2. Select the proper pinion height adjusting washer. For selecting adjusting washer, refer to the latest parts information.

**CAUTION:**

**If unable to find a washer of desired thickness, use a washer with thickness closest to the calculated value.**

**Example:**

**Calculated value... T = 3.22 mm**


**Used washer... T = 3.21 mm**

## COMPANION FLANGE RUNOUT

1. Fit a test indicator to the inner side of companion flange (socket diameter).
2. Rotate companion flange to check for runout.

**Companion flange runout : Refer to [DLN-217, "Companion Flange Runout \(AWD\)"](#).**

3. If the runout value is outside the runout limit, follow the procedure below to adjust.
  - a. Check for runout while changing the phase between companion flange and drive pinion by 90° step, and search for the position where the runout is the minimum.
  - b. If the runout value is still outside of the limit after the phase has been changed, possible cause will be an assembly malfunction of drive pinion and pinion bearing and malfunction of pinion bearing. Check for these items and repair if necessary.
  - c. If the runout value is still outside of the limit after the check and repair, replace companion flange.



## AWD : Inspection After Disassembly

INFOID:000000009062210

### DRIVE GEAR AND DRIVE PINION

- Clean up the disassembled parts.
- If the gear teeth never mesh or line-up correctly, determine the cause and adjust or replace as necessary.
- If the gears are worn, cracked, damaged, pitted or chipped (by friction) noticeably, replace with new drive gear and drive pinion as a set.

### BEARING

- Clean up the disassembled parts.
- If any chipped (by friction), pitted, worn, rusted or scratched marks, or unusual noise from the bearing is observed, replace as a bearing assembly (as a new set).

### SIDE GEAR AND PINION MATE GEAR

- Clean up the disassembled parts.
- If any cracks or damage on the surface of the tooth is found, replace.
- If any worn or chipped mark on the contact sides of the thrust washer is found, replace.

### SIDE GEAR THRUST WASHER AND PINION MATE THRUST WASHER

- Clean up the disassembled parts.
- If it is chipped (by friction), damaged, or unusually worn, replace.

### OIL SEAL

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

### DIFFERENTIAL CASE

- Clean up the disassembled parts.
- If any wear or crack on the contact sides of the differential case is found, replace.

### COMPANION FLANGE

- Clean up the disassembled parts.

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R200]

- If any chipped mark [about 0.1 mm, (0.004 in)] or other damage on the contact sides of the lips of the companion flange is found, replace.

A

B

C

**DLN**

E

F

G

H

I

J

K

L

M

N

O

P

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REAR FINAL DRIVE: R200]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### General Specification

INFOID:000000009062211

	2WD	AWD
Applied model	VQ37VHR	
	A/T	
Final drive model	R200	
Gear ratio	3.133	
Number of teeth (Drive gear/Drive pinion)	47/15	
Oil capacity (Approx.) ℓ (US pt, Imp pt)	1.4 (3, 2-1/2)	
Number of pinion gears	2	
Drive pinion adjustment spacer type	Collapsible	

#### Drive Gear Runout

INFOID:000000009062212

Unit: mm (in)

Item	Limit
Drive gear back face runout	0.05 (0.0020)

#### Differential Side Gear Clearance

INFOID:000000009062213

Unit: mm (in)

Item	Standard
Side gear backlash (Clearance between side gear and differential case)	0.2 (0.008) or less (Each gear should rotate smoothly without excessive resistance during differential motion.)

#### Preload Torque

INFOID:000000009062214

Unit: N·m (kg-m, in-lb)

Item	Standard
Pinion bearing (P1)	2.65 – 3.23 (0.27 – 0.32, 24 – 28)
Side bearing (P2)	0.20 – 0.52 (0.02 – 0.05, 2 – 4)
Side bearing to pinion bearing (Total preload) (Total preload = P1 + P2)	2.85 – 3.75 (0.29 – 0.38, 26 – 33)

#### Backlash

INFOID:000000009062215

Unit: mm (in)

Item	Standard
Drive gear to drive pinion gear	0.10 – 0.15 (0.0039 – 0.0059)

#### Drive Pinion Runout (2WD)

INFOID:000000009062216

Unit: mm (in)

Item	Limit
Tip of drive pinion runout	0.8 (0.031)



# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REAR FINAL DRIVE: R200]

## Companion Flange Runout (AWD)

INFOID:000000009062217

Unit: mm (in)

Item	Limit
Inner side of the companion flange runout	0.08 (0.0031)

A

B

C

**DLN**

E

F

G

H

I

J

K

L

M

N

O

P