

SECTION **LAN**
LAN SYSTEM

A
B
C

CONTENTS

D
E

CAN FUNDAMENTAL

SERVICE INFORMATION 3

PRECAUTIONS 3

 Precaution When Using CONSULT-II 3

 Precaution for Trouble Diagnosis 3

 Precaution for Harness Repair 3

SYSTEM DESCRIPTION 4

 CAN Communication System 4

 Diag on CAN 5

TROUBLE DIAGNOSIS 7

 Condition of Error Detection 7

 Symptom When Error Occurs in CAN Communication System 7

 Self-Diagnosis 10

 CAN Diagnostic Support Monitor 10

TROUBLE DIAGNOSES WORK FLOW 13

 Information Needed for Trouble Diagnosis 13

 How to Use CAN Communication Signal Chart 13

 Trouble Diagnosis Flow Chart 14

 Trouble Diagnosis Procedure 14

CAN

SERVICE INFORMATION 36

INDEX FOR DTC 36

 DTC No. Index 36

HOW TO USE THIS SECTION 37

 Caution 37

 Abbreviation List 37

PRECAUTIONS 38

 Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" 38

 Precaution When Using CONSULT-II 38

 Precaution for Trouble Diagnosis 38

 Precaution for Harness Repair 38

TROUBLE DIAGNOSIS 40

 CAN Diagnostic Support Monitor 40

 CAN System Specification Chart 44

 CAN Communication Signal Chart 44

 Schematic 49

 Wiring Diagram - CAN - 50

 Interview Sheet 53

 Data Sheet 54

 CAN System (Type 1) 57

 CAN System (Type 2) 58

 CAN System (Type 3) 59

 CAN System (Type 4) 60

 Component Parts Location 61

 Harness Layout 61

 Malfunction Area Chart 61

 Main Line Between TCM and Driver Seat Control Unit 62

 Main Line Between TCM and ICC Sensor 63

 Main Line Between ICC Sensor and ICC Unit 64

 Main Line Between ICC Unit and Driver Seat Control Unit 65

 Main Line Between Driver Seat Control Unit and Data Link Connector 65

 Main Line Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) 66

 ECM Branch Line Circuit 67

 TCM Branch Line Circuit 67

 ICC Sensor Branch Line Circuit 68

 ICC Unit Branch Line Circuit 69

 Driver Seat Control Unit Branch Line Circuit 69

 BCM Branch Line Circuit 70

 Display Control Unit Branch Line Circuit 70

 Data Link Connector Branch Line Circuit 71

 Front Air Control Branch Line Circuit 71

 Combination Meter Branch Line Circuit 72

 Steering Angle Sensor Branch Line Circuit 72

 Transfer Control Unit Branch Line Circuit 73

 ABS Actuator and Electric Unit (Control Unit) Branch Line Circuit 74

F
G
H
I
J

LAN

L
M
N
O
P

SERVICE INFORMATION

PRECAUTIONS

Precaution When Using CONSULT-II

INFOID:000000003533606

Use CONSULT-II CONVERTER when connecting CONSULT-II to data link connector.

CAUTION:

CAN communication does not function properly if CONSULT-II is used without connecting CONSULT-II CONVERTER.

Precaution for Trouble Diagnosis

INFOID:000000003533607

CAUTION:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.
- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.


Precaution for Harness Repair

INFOID:000000003533608

- Solder the repaired area and wrap tape around the soldered area.

NOTE:


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

A
B
C
D
E
F
G
H
I
J
LAN
L
M
N
O
P


SYSTEM DESCRIPTION

CAN Communication System

INFOID:000000003533609

- CAN communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with two communication lines (CAN-H and CAN-L).
- Control units on the CAN network transmit signals using the CAN communication control circuit. They receive only necessary signals from other control units to operate various functions.
- CAN communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

SYSTEM DIAGRAM



Each control unit passes an electric current to the termination circuits when transmitting CAN communication signal. The termination circuits produce an electrical potential difference between CAN-H and CAN-L. CAN communication system transmits and receives CAN communication signals by the potential difference.


Component	Description
Main line	CAN communication line between splices
Branch line	CAN communication line between splice and a control unit
Splice	A point connecting a branch line with a main line
Termination circuit	Refer to "CAN COMMUNICATION CONTROL CIRCUIT".

SYSTEM DESCRIPTION

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

CAN COMMUNICATION CONTROL CIRCUIT



Component	System description
CAN controller	It controls CAN communication signal transmission and reception, error detection, etc.
Transceiver IC	It converts digital signal into CAN communication signal, and CAN communication signal into digital signal.
Noise filter	It eliminates noise of CAN communication signal.
Termination circuit* (Resistance of approx. 120 Ω)	It produces potential difference.

*: These are the only control units wired with both ends of CAN communication system.

Diag on CAN

INFOID:000000003533610

DESCRIPTION

“Diag on CAN” is a diagnosis using CAN communication instead of previous DDL1 and DDL2 communication line, between control unit and diagnosis unit.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


LAN

SYSTEM DESCRIPTION

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

System Diagram



Name	Harness	Description
DDL1	Tx Rx	It is used for trouble diagnosis. (CAN-H and CAN-L are used for controlling)
DDL2	K-LINE	It is used for trouble diagnosis. (CAN-H and CAN-L are used for controlling)
Diag on CAN	CAN-H CAN-L	It is used for trouble diagnosis and control.

TROUBLE DIAGNOSIS

Condition of Error Detection

INFOID:000000003533611

“U1000” or “U1001” is indicated on SELF-DIAG RESULTS on CONSULT-II if CAN communication signal is not transmitted or received between units for 2 seconds or more.

CAN COMMUNICATION SYSTEM ERROR

- CAN communication line open (CAN-H, CAN-L, or both)
- CAN communication line short (ground, between CAN communication lines, other harnesses)
- Error of CAN communication control circuit of the unit connected to CAN communication line

WHEN INDICATED “U1000” OR “U1001” IS INDICATED EVEN THOUGH CAN COMMUNICATION SYSTEM IS NORMAL

- CONSULT-II CONVERTER not connected: Error may be detected by the self-diagnosis when not using CONSULT-II CONVERTER (Depending on the control unit which carries out CAN communication).
- Removal/installation of parts: Error may be detected when removing and installing CAN communication unit and related parts while turning the ignition switch ON. (A DTC except for CAN communication may be detected.)
- Fuse blown out (removed): CAN communication of the unit may cease.
- Voltage drop: Error may be detected if voltage drops due to discharged battery when turning the ignition switch ON (Depending on the control unit which carries out CAN communication).
- Error may be detected if the power supply circuit of the control unit, which carries out CAN communication, malfunctions (Depending on the control unit which carries out CAN communication).
- Error may be detected if reprogramming is not completed normally.

NOTE:

CAN communication system is normal if “U1000” or “U1001” is indicated on SELF-DIAG RESULTS of CONSULT-II under the above conditions. Erase the memory of the self-diagnosis of each unit.

Symptom When Error Occurs in CAN Communication System

INFOID:000000003533612


In CAN communication system, multiple units mutually transmit and receive signals. Each unit cannot transmit and receive signals if any error occurs on CAN communication line. Under this condition, multiple control units related to the root cause malfunction or go into fail-safe mode.

ERROR EXAMPLE

NOTE:

- Each vehicle differs in symptom of each unit under fail-safe mode and CAN communication line wiring.
- Refer to [LAN-37, "Abbreviation List"](#) for the unit abbreviation.

Example: TCM branch line open circuit




TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

Unit name	Symptom
ECM	Engine torque limiting is affected, and shift harshness increases.
BCM	Reverse warning chime does not sound.
EPS control unit	Normal operation.
Combination meter	<ul style="list-style-type: none"> • Shift position indicator and OD OFF indicator turn OFF. • Warning lamps turn ON.
ABS actuator and electric unit (control unit)	Normal operation.
TCM	No impact on operation.
IPDM E/R	Normal operation.

Example: Data link connector branch line open circuit



Unit name	Symptom
ECM	Normal operation.
BCM	
EPS control unit	
Combination meter	
ABS actuator and electric unit (control unit)	
TCM	
IPDM E/R	

NOTE:

- When data link connector branch line is open, transmission and reception of CAN communication signals is not affected. Therefore, no symptoms occur. However, be sure to repair malfunctioning circuit.
- When data link connector branch line is open, the screen-display of the CONSULT-II “SELECT SYSTEM” screen may be the same as when the CAN communication line has short-circuit. However, symptoms differ depending on the case. See below chart for the differences.


	SELECT SYSTEM (CONSULT-II)	Difference of symptom
Data link connector branch line open circuit		Normal operation.
CAN-H, CAN-L harness short-circuit	All Diag on CAN units are not indicated.	Most the units which are connected to the CAN communication system enter fail-safe mode or are deactivated.

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >


[CAN FUNDAMENTAL]

Example: Main Line Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit) Open Circuit



Unit name	Symptom
ECM	Engine torque limiting is affected, and shift harshness increases.
BCM	<ul style="list-style-type: none"> • Reverse warning chime does not sound. • The front wiper moves under continuous operation mode even though the front wiper switch being in the intermittent position.
EPS control unit	The steering effort increases.
Combination meter	<ul style="list-style-type: none"> • The shift position indicator and OD OFF indicator turn OFF. • The speedometer is inoperative. • The odo/trip meter stops.
ABS actuator and electric unit (control unit)	Normal operation.
TCM	No impact on operation.
IPDM E/R	When the ignition switch is ON, <ul style="list-style-type: none"> • The headlamps (Lo) turn ON. • The cooling fan continues to rotate.

Example: CAN-H, CAN-L Harness Short Circuit



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

LAN

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

Unit name	Symptom
ECM	<ul style="list-style-type: none"> Engine torque limiting is affected, and shift harshness increases. Engine speed drops.
BCM	<ul style="list-style-type: none"> Reverse warning chime does not sound. The front wiper moves under continuous operation mode even though the front wiper switch being in the intermittent position. The room lamp does not turn ON. The engine does not start (if an error or malfunction occurs while turning the ignition switch is OFF.) The steering lock does not release (if an error or malfunction occurs while turning the ignition switch is OFF.)
EPS control unit	The steering effort increases.
Combination meter	<ul style="list-style-type: none"> The tachometer and the speedometer do not move. Warning lamps turn ON. Indicator lamps do not turn ON.
ABS actuator and electric unit (control unit)	Normal operation.
TCM	No impact on operation.
IPDM E/R	When the ignition switch is ON, <ul style="list-style-type: none"> The headlamps (Lo) turn ON. The cooling fan continues to rotate.

Self-Diagnosis

INFOID:000000003533613

DTC	Self-diagnosis item (CONSULT-II indication)	DTC detection condition	Inspection/Action
U1000	CAN COMM CIRCUIT	When ECM is not transmitting or receiving CAN communication signal of OBD (emission-related diagnosis) for 2 seconds or more.	Refer to LAN-13 .
		When a control unit (except for ECM) is not transmitting or receiving CAN communication signal for 2 seconds or more.	
U1001	CAN COMM CIRCUIT	When ECM is not transmitting or receiving CAN communication signal other than OBD (emission-related diagnosis) for 2 seconds or more.	
U1002	SYSTEM COMM	When a control unit is not transmitting or receiving CAN communication signal for 2 seconds or less.	Start the inspection. Refer to the applicable section of the indicated control unit.
U1010	CONTROL UNIT [CAN]	When an error is detected during the initial diagnosis for CAN controller of each control unit.	Replace the control unit indicating "U1010".

CAN Diagnostic Support Monitor

INFOID:000000003533614

CONSULT-II and CAN diagnostic support monitor (on-board diagnosis function) are used for detecting root cause.

MONITOR ITEM (CONSULT-II)

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

Example: CAN DIAG SUPPORT MNTR indication

Without PAST			With PAST		
SYSTEM DATE P/#	ENGINE		SYSTEM DATE P/#	ENGINE	
		PRSNT			PRSNT PAST
INITIAL DIAG		OK	TRANSMIT DIAG		OK OK
TRANSMIT DIAG		OK	VDC/TCS/ABS		- -
TCM		OK	METER/M&A		OK OK
VDC/TCS/ABS		UNKWN	BCM/SEC		OK OK
METER/M&A		OK	ICC		- -
ICC		UNKWN	HVAC		- -
BCM/SEC		OK	TCM		OK OK
IPDM E/R		OK	EPS		- -
			IPDM E/R		OK OK
			e4WD		- -
			AWD/4WD		OK OK

SKIB8742E

Without PAST

Item	PRSNT	Description
Initial diagnosis	OK	Normal at present
	NG	Control unit error (Except for some control units)
Transmission diagnosis	OK	Normal at present
	UNKWN	Unable to transmit signals for 2 seconds or more. Diagnosis not performed
Control unit name (Reception diagnosis)	OK	Normal at present
	UNKWN	Unable to receive signals for 2 seconds or more. Diagnosis not performed
	UNKWN	No control unit for receiving signals. (No applicable optional parts)

With PAST

Item	PRSNT	PAST	Description
Transmission diagnosis	OK	OK	Normal at present and in the past
		1 – 39	Normal at present, but unable to transmit signals for 2 seconds or more in the past. (The number indicates the number of ignition switch cycles from OFF to ON.)
	UNKWN	0	Unable to transmit signals for 2 seconds or more at present.
Control unit name (Reception diagnosis)	OK	OK	Normal at present and in the past
		1 – 39	Normal at present, but unable to receive signals for 2 seconds or more in the past. (The number indicates the number of ignition switch cycles from OFF to ON.)
	UNKWN	0	Unable to receive signals for 2 seconds or more at present
	-	-	Diagnosis not performed. No control unit for receiving signals. (No applicable optional parts)

MONITOR ITEM (ON-BOARD DIAGNOSIS)

NOTE:

- For some models, CAN communication diagnosis result is received from the vehicle monitor. (CONSULT-II is not available.)
- Refer to [LAN-40. "CAN Diagnostic Support Monitor"](#) for the details.

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

Example: Vehicle Display

Item	Result indicated	Error counter	Description
CAN_COMM (Initial diagnosis)	OK	0	Normal at present
	NG	1 – 50	Control unit error (The number indicates how many times diagnosis has been run.)
CAN_CIRC_1 (Transmission diagnosis)	OK	0	Normal at present
	UNKWN	1 – 50	Unable to transmit for 2 seconds or more at present. (The number indicates how many times diagnosis has been run.)
CAN_CIRC_2 – 9 (Reception diagnosis of each unit)	OK	0	Normal at present
	UNKWN	1 – 50	Unable to transmit for 2 seconds or more at present. (The number indicates how many times diagnosis has been run.)
			Diagnosis not performed.
			No control unit for receiving signals. (No applicable optional parts)

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

TROUBLE DIAGNOSES WORK FLOW

Information Needed for Trouble Diagnosis

INFOID:000000003533615

CAN communication system performs trouble diagnosis with the following tools.

Tool	Usage
Interview sheet	For filling in vehicle information and interview with customer.
Data sheet	For attaching CONSULT-II data or on-board diagnosis data.
Diagnosis sheet	For detecting the root cause. (Diagnosis sheet includes system diagram for every CAN system type)
SELECT SYSTEM (CONSULT-II)	For checking the condition of control units and the status of CAN communication.
SELF-DIAG RESULTS (CONSULT-II)	
CAN DIAG SUPPORT MNTR (CONSULT-II)	
CAN communication signal chart	For converting information received from a customer into CAN communication signal transmission and reception. This information can be used to judge whether a circuit between control units is normal or abnormal.
Abbreviation list	For checking abbreviations in CAN communication signal chart and diagnosis sheet.

How to Use CAN Communication Signal Chart

INFOID:000000003533616

The CAN communication signal chart lists the signals needed for trouble diagnosis. It is useful for detecting the root cause by finding a signal related to the symptom, and by checking transmission and reception unit.

Example: Tachometer does not move even though the engine rotates.

T: Transmit R: Receive

Signal name/Connecting unit	ECM	BCM	M&A	STRG	ABS	IPDM-E
A/C compressor feedback signal	T		R			
A/C compressor request signal	T					R
Accelerator pedal position signal	T				R	
Cooling fan motor operation signal	T					R
Engine coolant temperature signal	T		R			
Engine speed signal	T		R		R	
Fuel consumption monitor signal	T		R			
Malfunction indicator lamp signal	T		R			
A/C switch signal	R	T				
Ignition switch signal		T				R
Sleep/wake up signal		T	R			R

No communication between ECM and M&A.

It indicates that an error occurs between ECM and M&A (Shaded area).

SKIB8715E


TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

Trouble Diagnosis Flow Chart

INFOID:000000003533617



Trouble Diagnosis Procedure

INFOID:000000003533618

INTERVIEW WITH CUSTOMER

Interview with the customer is important to detect the root cause of CAN communication system errors and to understand vehicle condition and symptoms for proper trouble diagnosis.

Points in interview

- What: Parts name, system name
- When: Date, Frequency
- Where: Road condition, Place
- In what condition: Driving condition/environment

TROUBLE DIAGNOSES WORK FLOW


< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

- Result: Symptom

NOTE:

- Check normal units as well as error symptoms.
- Example: Circuit between ECM and the combination meter is judged normal if the customer indicates tachometer functions normally.
- When a CAN communication system error is present, multiple control units may malfunction or go into fail-safe mode.
- Indication of the combination meter is important to detect the root cause because it is the most obvious from the customer, and it performs CAN communication with many units.



INSPECTION OF VEHICLE CONDITION

- Check whether or not “U1000” or “U1001” is indicated on “SELF-DIAG RESULTS” by CONSULT-II.

NOTE:

Root cause cannot be detected using the procedure in this section if “U1000” or “U1001” is not indicated.

- Check whether the symptom is reproduced or not.

NOTE:

- Never turn the ignition switch OFF or disconnect the battery cable while the reproducing the error. The error may temporarily correct itself, making it difficult to determine the root cause.
- The procedures for present errors differ from the procedures for past errors. Refer to "DETECT THE ROOT CAUSE".

CHECK OF CAN SYSTEM TYPE (HOW TO USE CAN SYSTEM TYPE SPECIFICATION CHART)

Determine CAN system type based on vehicle equipment. Then choose the correct diagnosis sheet.

NOTE:

There are two styles for CAN system type specification charts. Depending on the number of available system types, either style A or style B may be used.

CAN System Type Specification Chart (Style A)

NOTE:

A
B
C
D
E
F
G
H
I
J
LAN
L
M
N
O
P

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

CAN system type is easily checked with the vehicle equipment identification information shown in the chart.

Example:
Vehicle is equipped as follows: Wagon, AWD, VQ35DE, CVT, VDC, and Intelligent Key system. (○ shows an example of CAN system type.)


CAN System Specification Chart
Determine CAN system type from the following specification chart. Then choose the correct diagnosis sheet.

Body type	Wagon					
Axle	2WD			AWD		
Engine	QR25DE		VQ35DE			
Transmission	A/T		CVT			
Brake control	ABS			VDC		
Intelligent Key system		X		X		X
CAN system type	1	2	3	4	5	6
Diagnosis sheet	(XX-XX)	(XX-XX)	(XX-XX)	(XX-XX)	(XX-XX)	(XX-XX)
CAN communication signal chart	XX-XX. "TYPE 1/TYPE 2"		XX-XX. "TYPE 3/TYPE 4"		XX-XX. "TYPE 5/TYPE 6"	

X : Applicable


VEHICLE EQUIPMENT IDENTIFICATION INFORMATION
NOTE:
Check CAN system type from the vehicle shape and equipment.

With VDC



VDC OFF switch

With Intelligent Key system



Ignition knob

In the above example,
• Checking VDC OFF switch leads to judge whether or not VDC is equipped.
• Checking the ignition knob leads to judge whether or not Intelligent Key system is equipped.

[For the above case, CAN system type is "6".]

SKIB8688E

CAN System Type Specification Chart (Style B)

NOTE:

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

CAN system type is easily checked with the vehicle equipment identification information shown in the chart.

Example:

Vehicle is equipped as follows: Sedan, 2WD, MR20DE, CVT, ABS, Active AFS, Intelligent Key system, Navigation system and Automatic drive positioner. (○ shows an example of CAN system type.)

CAN System Specification Chart

Refer to the specification as shown in the chart.

Body type	Sedan		
Axle	2WD		AWD
Engine	HR15DE	MR20DE	HR15DE
Transmission	A/T	CVT	A/T
Brake control		ABS	
Specification chart	XX.XX SPECIFICATION CHART A	YY.YY SPECIFICATION CHART B	ZZ.ZZ SPECIFICATION CHART C

Check the vehicle equipment with the vehicle identification number plate.

Check the vehicle equipment.

Select the applicable vehicle equipment. Refer to the specification chart.

x: Applicable

SPECIFICATION CHART B

Determine CAN system type from the following specification chart. Then choose the correct diagnosis sheet.

Body type	Sedan											
Axle	2WD											
Engine	MR20DE											
Transmission	CVT											
Brake control	ABS											
Active AFS		x			x		x		x	x		x
Intelligent Key system			x		x		x	x	x	x		x
Navigation system				x		x	x		x		x	x
Automatic drive positioner								x		x	x	x
CAN system type	9	10	11	12	13	14	15	16	17	18	19	20
Diagnosis sheet	AA: XX	AA: XX	AA: XX	AA: XX	AA: XX	AA: XX	AA: XX	AA: XX	AA: XX	AA: XX	AA: XX	AA: XX
CAN communication signal chart	XX.XX TYPE 8TYPE 10TYPE 12TYPE 14TYPE 16TYPE 18TYPE 20TYPE 1TYPE 2TYPE 3TYPE 4TYPE 5TYPE 6TYPE 7TYPE 9TYPE 11TYPE 13TYPE 15TYPE 17TYPE 19											

Check the vehicle equipment.


The number indicates the CAN system type of the vehicle.

x: Applicable

VEHICLE EQUIPMENT IDENTIFICATION INFORMATION

NOTE:

Check CAN system type from the vehicle shape and equipment.



In the above example,

- Checking Xenon bulb and bending lamp lead to judge whether or not Active AFS is equipped.
- Checking the ignition knob leads to judge whether or not Intelligent Key system is equipped.
- Checking display and multifunction switch lead to judge whether or not Navigation system is equipped.
- Checking seat memory switch leads to judge whether or not Automatic drive positioner is equipped.

For the above case, CAN system type is "20".

SKIB8889E

CREATE INTERVIEW SHEET

Fill out the symptom described by the customer, vehicle condition, and CAN system type on the interview sheet.

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

Interview Sheet (Example)

CAN Communication System Diagnosis Interview Sheet	
Date received:	3, Feb. 2005
Type: DBA-KG11	VIN No.: KG11-005040
Model: BDRARGZ397EDA-E-J-	
First registration: 10, Jan. 2005	Mileage: 952 km
CAN system type: Type 19	
Symptom (Results from interview with customer)	
<ul style="list-style-type: none">• Headlamps suddenly turn ON while driving the vehicle.• The engine does not restart after stopping the vehicle and turning the ignition switch OFF.• The cooling fan continues rotating while turning the ignition switch ON.	
Condition at inspection	
Error Symptom: Present / Past	
<p>The engine does not start. While turning the ignition switch ON,</p> <ul style="list-style-type: none">• The headlamps (Lo) turn ON, and the cooling fan continues rotating.• The interior lamp does not turn ON. <p>On CONSULT-II screen,</p> <ul style="list-style-type: none">• IPDM E/R is not indicated on SELECT SYSTEM.• ENGINE: U1001• BCM, ADAPTIVE LIGHT: U1000	

SKIB8890E

CREATE DATA SHEET

Create CONSULT-II Data Attachment Sheet

Print out the following CONSULT-II screens, and attach them to the CONSULT-II data attachment sheet.

- SELECT SYSTEM
- SELF-DIAG RESULTS
- CAN DIAG SUPPORT MNTR


NOTE:

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

Some items may not be needed depending on CAN system type of vehicle.



Create On-board Diagnosis Copy Sheet

Display the trouble diagnosis result of CAN communication with the on-board diagnosis function on the vehicle monitor, etc. Copy them on the on-board diagnosis copy sheet.

NOTE:

- For some models, CAN communication diagnosis result is received from the vehicle monitor. (CONSULT-II is not available.)

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >


[CAN FUNDAMENTAL]

- For the details, refer to [LAN-54. "Data Sheet"](#).

Example: Copy the diagnosis result of CAN communication from the vehicle monitor.

Vehicle monitor indication

CAN DIAG SUPPORT MONITOR			
CAN_COMM	OK	0	Delete
CAN_CIRC_1	OK	0	
CAN_CIRC_2	UNKWN	12	
CAN_CIRC_3	UNKWN	12	
CAN_CIRC_4	UNKWN	0	
CAN_CIRC_5	OK	0	
CAN_CIRC_6	UNKWN	0	
CAN_CIRC_7	OK	0	
CAN_CIRC_8	UNKWN	0	
CAN_CIRC_9	UNKWN	50	



Vehicle monitor (Display control unit) CAN DIAG SUPPORT MONITOR copy sheet

Indication item (Diagnosis item)	Vehicle monitor		Indication item (Diagnosis item)	Vehicle monitor	
	Result indicated	Error counter		Result indicated	Error counter
CAN_COMM (Initial diagnosis)	OK	0	CAN_CIRC_5 (Receive diagnosis of Unified meter and A/C amp.)	OK	0
CAN_CIRC_1 (Transmit diagnosis)	OK	0	CAN_CIRC_6	Not available	
CAN_CIRC_2 (Receive diagnosis of BCM)	UNKWN	12	CAN_CIRC_7 (Receive diagnosis of IPDM E/R)	OK	0
CAN_CIRC_3 (Receive diagnosis of ECM)	UNKWN	12	CAN_CIRC_8	Not available	
CAN_CIRC_4	Not available		CAN_CIRC_9	Not available	

Result indicated: Fill in the indication (OK, NG or UNKWN).
Error counter: Fill in the indicated number.

SKIB8722E

CREATE DIAGNOSIS SHEET

NOTE:

Be sure to use the diagnosis sheet for the correct CAN system type.

Print Diagnosis Sheet

Print the diagnosis sheet for the applicable CAN system type.

Check of Received Data


Check the created data sheet for missing information.

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

- For abbreviations, refer to [LAN-37, "Abbreviation List"](#).



DETECT THE ROOT CAUSE

Identify the root cause using the created diagnosis sheet.

Identifying the root cause

- Draw a line on the diagnosis sheet to indicate the possible cause. Narrow the search.

NOTE:

- Color-code when drawing lines.
- Do not draw a line onto a existing line.
- Drawing a line is not necessary if the circuit is shorted. Refer to "Present Error — Short Circuit —", "Past Error — Short Circuit —".

Refer to the following for details of the trouble diagnosis procedure.

- "Present Error — Open Circuit —"
- "Present Error — Short Circuit —"
- "Past Error — Open Circuit —"
- "Past Error — Short Circuit —"

NOTE:

When the root cause appears to be a branch line or short circuit, be sure to check the control unit as well as the communication line.

Present Error — Open Circuit —

Identify the error circuit using information from the "SELECT SYSTEM" and "CAN DIAG SUPPORT MNTR" screens.

- SELECT SYSTEM: Check the items indicated in "SELECT SYSTEM". Draw a line on the diagnosis sheet to indicate the error circuit.

NOTE:

CAN communication line has no error if units other than Diag on CAN units are indicated. An error may be on the power supply of the control unit, DDL1 line or DDL2 line.

- "TRANSMISSION" which is Diag on CAN unit, is not indicated on "SELECT SYSTEM" screen. This indicates that DLC is not receiving a signal from TCM. Draw a line to indicate an error between DLC and TCM (line 1-a in the figure).

NOTE:


- Diag on CAN units are not indicated on the "SELECT SYSTEM" screen when the CAN line between Diag on CAN unit and the data link connector is open.

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

- For a description of Diag on CAN, refer to [LAN-5. "Diag on CAN"](#).



2. CAN DIAG SUPPORT MNTR: Check each item on “CAN DIAG SUPPORT MNTR”. Draw a line on the diagnosis sheet to indicate the error circuit.

- a. Reception item of “ENGINE”: On “TCM”, “UNKWN” is indicated. This means ECM cannot receive the signal from TCM. Draw a line to indicate an error between ECM and TCM (line 2-a in the figure).

NOTE:

If “UNKWN” is indicated on “TRANSMIT DIAG”, then the control unit cannot transmit CAN communication signal to each unit. Draw a line between the control unit and the splice.


- b. Reception item of “ADAPTIVE LIGHT”: On “TCM”, “UNKWN” is indicated. This means AFS cannot receive the signal from TCM. Draw a line to indicate an error between AFS and TCM (line 2-b in the figure).

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

- c. Reception item of "MULTI AV": "UNKWN" is not indicated. This indicates normal communication between AV and its receiving units. Do not draw any line.



- d. Reception item of "BCM": On "TCM", "UNKWN" is indicated. This means BCM cannot receive the signal from TCM. Draw a line to indicate an error between BCM and TCM (line 2-d in the figure).
- e. Reception item of "EPS" and "INTELLIGENT KEY": "UNKWN" is not indicated. This indicates normal communication between EPS and I-KEY and their receiving units. Do not draw any line.

NOTE:

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


LAN

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

On CAN DIAG SUPPORT MNTR (without PAST), “UNKWN” is indicated even though the item is not used in the trouble diagnosis. For the details of each item on CAN diagnostic support monitor, refer to [LAN-40, "CAN Diagnostic Support Monitor"](#).




- f. Reception item of “METER”: On “TCM”, “UNKWN” is indicated. This means M&A cannot receive the signal from TCM. Draw a line to indicate an error between M&A and TCM (line 2-f in the figure).
- g. Reception item of “AUTO DRIVE POS.”: On “TCM”, “UNKWN” is indicated. This means ADP cannot receive the signal from TCM. Draw a line to indicate an error between ADP and TCM (line 2-g in the figure).

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

- h. Reception item of "ABS": "UNKWN" is not indicated. This indicates normal communication between ABS and its receiving units. Do not draw any line.




- i. Reception item of "IPDM E/R": "UNKWN" is not indicated. This indicates normal communication between IPDM-E and its receiving units. Do not draw any line.
3. Based on information received from "CAN DIAG SUPPORT MNTR", place a check mark on the known good CAN communication line between ECM and IPDM-E.
- a. Through the previous procedure, the circuit between ADP splice and TCM has the most amount of lines (shade 3-a in the figure).
- b. Place a check mark on the known good lines to establish the error circuit.

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

Reception item of "IPDM E/R": On "ECM", "OK" is indicated. IPDM-E communicates normally with ECM. Put a check mark on the normal circuit between ECM and IPDM-E (check mark 3-b in the figure).



4. Through the above procedure, the error is detected in the TCM branch line (shaded in the figure).

NOTE:


For abbreviations, refer to [LAN-37, "Abbreviation List"](#).

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

5. Perform the inspection for the detected error circuit. For the inspection procedure, refer to [LAN-61. "Mal-function Area Chart"](#).



Present Error — Short Circuit —

When the symptoms listed below exist, a short circuit of the CAN communication line is a possible cause.

Received data

Item (CONSULT-II)	Indication
SELECT SYSTEM	All Diag on CAN units are not indicated.
CAN DIAG SUPPORT MNTR	"UNKWN" is indicated under "TRANSMIT DIAG" and most reception items.

Error symptom

- Most the units connected to the CAN communication system go into fail-safe mode or are deactivated.

Inspection procedure

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

- Refer to [LAN-61, "Malfunction Area Chart"](#).

(Example)

SELECT SYSTEM
ENGINE
ABS
AIR BAG
HEAD LAMP LEVELIZER
BACKLIGHT COPY

All Diag on CAN units are not indicated.

SYSTEM ENGINE			SYSTEM ABS		
DATE			DATE		
P/#	PRSNT	PAST	P/#	PRSNT	
TRANSMIT DIAG	UNKWN	0	INITIAL DIAG	NG	
VDC/TCS/ABS	UNKWN	0	TRANSMIT DIAG	UNKWN	
METER/M&A	-	-	ECM	UNKWN	
BCM/SEC	UNKWN	0			
ICC	-	-			
HVAC	-	-			
TCM	UNKWN	0			
EPS	UNKWN	0			
IPDM E/R	UNKWN	0			
e4WD	-	-			
AWD/4WD	-	-			

"UNKWN" is indicated under most reception items of CAN DIAG SUPPORT MNTR.

SKIB8894E

Past Error — Open Circuit —
Review CAN communication signal chart based on information received from the interview with the customer and on past error information from SELF-DIAG RESULTS and CAN DIAG SUPPORT MNTR.

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

1. SELF-DIAG RESULTS: Inspect the control units indicating “U1000” or “U1001” on SELF-DIAG RESULTS.

(Example)

SYSTEM ENGINE DATE P/# SELF-DIAG RESULTS DTC RESULTS TIME CAN COMM CIRCUIT 1t [U1001]	SYSTEM ADAPTIVE LIGHT DATE P/# SELF-DIAG RESULTS DTC RESULTS TIME NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	SYSTEM MULTI AV DATE P/# SELF-DIAG RESULTS DTC RESULTS TIME NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	SYSTEM BCM DATE P/# SELF-DIAG RESULTS DTC RESULTS TIME NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.
SYSTEM EPS DATE P/# SELF-DIAG RESULTS DTC RESULTS TIME CAN COMM CIRCUIT PAST [U1000]	SYSTEM INTELLIGENT KEY DATE P/# SELF-DIAG RESULTS DTC RESULTS TIME NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	SYSTEM METER DATE P/# SELF-DIAG RESULTS DTC RESULTS TIME CAN COMM CIRCUIT 3 [U1000]	SYSTEM AUTO DRIVE POS. DATE P/# SELF-DIAG RESULTS DTC RESULTS TIME NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.
SYSTEM ABS DATE P/# SELF-DIAG RESULTS DTC RESULTS TIME CAN COMM CIRCUIT 3 [U1000]	SYSTEM TRANSMISSION DATE P/# SELF-DIAG RESULTS DTC RESULTS TIME CAN COMM CIRCUIT 3 [U1000]	SYSTEM IPDM E/R DATE P/# SELF-DIAG RESULTS DTC RESULTS TIME NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED.	

SKIB8731E

A
B
C
D
E
F
G
H
I
J
LAN
L
M
N
O
P

2. CAN DIAG SUPPORT MNTR (with PAST): Check the CAN DIAG SUPPORT MNTR (with PAST) of units indicating “U1000” or “U1001” on SELF-DIAG RESULTS. Draw a line on the diagnosis sheet to indicate the possible error circuit.

NOTE:
For the details of each indication on CAN DIAG SUPPORT MNTR, refer to [LAN-40, "CAN Diagnostic Support Monitor"](#).


- a. Reception item of “ENGINE”: “VDC/TCS/ABS”, “3” is indicated in the “PAST”. This means ECM could not receive the signal from ABS in the past. Draw a line between ECM and ABS (line 2-a in the figure).

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

- b. Reception item of "METER": "VDC/TCS/ABS", "3" is indicated in the "PAST". This means M&A could not receive the signal from ABS in the past. Draw a line between M&A and ABS (line 2-b in the figure).
- c. Reception item of "TRANSMISSION": "VDC/TCS/ABS", "3" is indicated in the "PAST". This means TCM could not receive the signal from ABS in the past. Draw a line between TCM and ABS (line 2-c in the figure).



3. CAN DIAG SUPPORT MNTR (without PAST): Check the CAN DIAG SUPPORT MNTR (without PAST) of units indicating "U1000" or "U1001" on SELF-DIAG RESULTS. Draw a line on the diagnosis sheet to indicate the possible error circuit.

NOTE:

- While an error occurred in the past according to SELF-DIAG RESULTS, it is unclear which signal is not received. Assume that errors were detected from all reception items.
- Draw a single line among the unit and all reception items. (Work flow differs from CAN DIAG SUPPORT MNTR (with PAST).)


- a. Reception item of "EPS": Assume that the unit could not receive the signals from ECM, ABS, and M&A. Draw a line among EPS, ECM, ABS, and M&A (line 3-a in the figure).

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

- b. Reception item of "ABS": Assume that the unit could not receive the signal from ECM. Draw a line between ABS and ECM (line 3-b in the figure).



4. Search for the possible cause using CAN communication signal chart using information from the interview with the customer.

NOTE:

For the details of CAN communication signal, refer to [LAN-44. "CAN Communication Signal Chart"](#).

- a. ABS warning lamp turned ON and speedometer did not move: This means that "ABS warning lamp signal" and "Vehicle speed signal" could not communicate between M&A and ABS (4-a in the figure).

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

- b. The tachometer moved normally: This means that “Engine speed signal” could communicate normally between ECM and M&A (4-b in the figure).

(Example)

First registration:

CAN system type:

Symptom (Results from interview with customer)

While driving,

- ABS warning lamp turned ON.
- Speedometer did not move.
- Tachometer moved normally.

CAN Communication Signal Chart

Signal name/Connecting unit	T: Transmit R: Receive												
	ECM	AFS ¹	AV ²	BCM	EPS	I-KEY ³	M&A	STRG ¹	ADP ⁴	ABS	TCM	IPDM/E	
A/C compressor request signal	T											R	
Accelerator pedal position signal	T										R		
Closed throttle position signal	T										R		
Cooling fan speed request signal	T											R	
Engine and CVT integrated control signal	T R										R T		
Engine coolant temperature signal	T						R				R		
4-b Engine speed signal	T						R				R		
Engine status signal	T		R		R								
Fuel consumption monitor signal	T		R				R						
MI signal	T						R						
Wide open throttle position signal	T										R		
4-a ABS warning lamp signal							R			T			
Brake warning lamp signal							R			T			
Steering angle sensor signal		R						T					
4-a Vehicle speed signal	R	R		R	R	R	T		R	T	R		
Input shaft revolution signal	R											T	
Output shaft revolution signal	R											T	
Shift position indicator signal	R	R	R	R ⁵			R		R ⁶			T	
Second position indicator signal							R					T	
Front wiper stop position signal				R								T	
High beam status signal	R	R										T	
Low beam status signal	R	R										T	

SKIB8895E


5. Fill out the diagnosis sheet based on information from step 4.
- a. The ABS warning lamp turned ON and speedometer did not move: Assume that a possible cause is no communication between M&A and ABS. Draw a line between M&A and ABS. (Line 5-a in the figure).

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

- b. The tachometer moved normally: Put check marks between ECM and M&A. The circuit between ECM and M&A is functioning properly (check marks 5-b in the figure).



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

LAN

6. The circuit which has the most amount of lines are the possible cause. Error is detected from ABS actuator and electric unit (control unit) branch line (shaded in the figure).

NOTE:

For abbreviations, refer to [LAN-37, "Abbreviation List"](#).

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

7. Perform the inspection procedure for the possible cause. Refer to [LAN-61, "Malfunction Area Chart"](#).

(Example)

▲ :Diag on CAN unit

< CONSULT-II printout checklist >

Item	Check box
1 SELECT SYSTEM	<input checked="" type="checkbox"/>
2 ENGINE	<input checked="" type="checkbox"/>
3 ADAPTIVE LIGHT [▲]	<input checked="" type="checkbox"/>
4 MULTI AV [▲]	<input checked="" type="checkbox"/>
5 BCM [▲]	<input checked="" type="checkbox"/>
6 EPS [▲]	<input checked="" type="checkbox"/>
7 INTELLIGENT KEY [▲]	<input checked="" type="checkbox"/>
8 METER [▲]	<input checked="" type="checkbox"/>
9 AUTO DRIVE POS. [▲]	<input checked="" type="checkbox"/>
10 ABS	<input checked="" type="checkbox"/>
11 TRANSMISSION [▲]	<input checked="" type="checkbox"/>
12 IPDM E/R [▲]	<input checked="" type="checkbox"/>

Possible root cause

- Error between ABS actuator and electric unit (control unit) and splice.
- Error in ABS actuator and electric unit (control unit).

Inspection result

SKIB8896E

Past Error — Short Circuit —

When the symptoms listed below exist, a short circuit of the CAN communication line is a possible cause.

Item (CONSULT-II)	Indication	Inspection procedure
SELF-DIAG RESULTS	“U1000” and “U1001” is indicated in the past for most units.	Refer to LAN-61, "Malfunction Area Chart" .
CAN DIAG SUPPORT MNTR	Only on CAN DIAG SUPPORT MNTR (with PAST), “1 - 39” is indicated on “PAST” of “TRANSMIT DIAG” and the reception item.	

TROUBLE DIAGNOSES WORK FLOW

< SERVICE INFORMATION >

[CAN FUNDAMENTAL]

(Example)

SYSTEM DATE P/#	ENGINE	SYSTEM DATE P/#	ADAPTIVE LIGHT	SYSTEM DATE P/#	MULTI AV	SYSTEM DATE P/#	BCM
SELF-DIAG RESULTS		SELF-DIAG RESULTS		SELF-DIAG RESULTS		SELF-DIAG RESULTS	

DTC RESULTS	TIME	DTC RESULTS	TIME	DTC RESULTS	TIME	DTC RESULTS	TIME
CAN COMM CIRCUIT [U1000]	1t	CAN COMM CIRCUIT [U1000]	5	CAN COMM CIRCUIT [U1000]	5	CAN COMM CIRCUIT [U1000]	5
CAN COMM CIRCUIT [U1001]	1t						

SYSTEM DATE P/#	EPS	SYSTEM DATE P/#	INTELLIGENT KEY	SYSTEM DATE P/#	METER	SYSTEM DATE P/#	AUTO DRIVE POS.
SELF-DIAG RESULTS		SELF-DIAG RESULTS		SELF-DIAG RESULTS		SELF-DIAG RESULTS	

DTC RESULTS	TIME	DTC RESULTS	TIME	DTC RESULTS	TIME	DTC RESULTS	TIME
CAN COMM CIRCUIT [U1000]			5	CAN COMM CIRCUIT [U1000]	5	CAN COMM CIRCUIT [U1000]	PAST

"U1000" and "U1001" is indicated in the past for most units.

SYSTEM DATE P/#	ENGINE	PRSENT	PAST	SYSTEM DATE P/#	ADAPTIVE LIGHT	PRSENT	PAST	SYSTEM DATE P/#	MULTI AV	PRSENT	PAST	SYSTEM DATE P/#	BCM	PRSENT	PAST
TRANSMIT DIAG		OK	5	TRANSMIT DIAG		-	-	TRANSMIT DIAG		-	-	TRANSMIT DIAG		OK	5
VDC/TCS/ABS		OK	5	ECM		OK	5	ECM		OK	5	ECM		OK	5
METER/M&A		-	-	METER/M&A		OK	5	METER/M&A		OK	5	METER/M&A		OK	5
BCM/SEC		OK	5	TCM		OK	5	BCM/SEC		-	-	TCM		OK	5
ICC		-	-	STRG		OK	5	HVAC		-	-	MULTI AV		-	-
HVAC		-	-	EPS		-	-	IPDM E/R		-	-	IPDM E/R		OK	5
TCM		OK	5	IPDM E/R		OK	5	TIRE-P		-	-	I-KEY		OK	5
EPS		OK	5												
IPDM E/R		OK	5												
e4WD		-	-												
AWD/4WD		-	-												

Only on CAN DIAG SUPPORT MNTR (with PAST), "1-39" is indicated on "PAST" of "TRANSMIT DIAG" and the reception item.

SYSTEM DATE P/#	ENGINE	PRSENT	PAST	SYSTEM DATE P/#	INTELLIGENT KEY	PRSENT	PAST	SYSTEM DATE P/#	METER	PRSENT	PAST	SYSTEM DATE P/#	AUTO DRIVE POS.	PRSENT	PAST
TRANSMIT DIAG		OK	5	TRANSMIT DIAG		OK	5	TRANSMIT DIAG		OK	5	TRANSMIT DIAG		-	-
ECM		OK	5	ECM		OK	5	ECM		OK	5	ECM		OK	5
VDC/TCS/ABS		OK	5	METER/M&A		OK	5	TCM		OK	5	BCM/SEC		OK	5
METER/M&A		-	-	METER/M&A		OK	5	BCM/SEC		OK	5	TCM		OK	5
								VDC/TCS/ABS		OK	5				
								IPDM E/R		-	-				
										OK	5				

SKIB8897E

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



SERVICE INFORMATION

INDEX FOR DTC

DTC No. Index

INFOID:000000003533619

DTC	Self-diagnosis item (CONSULT-II indication)	DTC detection condition	Inspection
U1000	CAN COMM CIRCUIT	When ECM is not transmitting or receiving CAN communication signal of OBD (emission-related diagnosis) for 2 seconds or more.	Refer to LAN-37 .
		When a control unit (except for ECM) is not transmitting or receiving CAN communication signal for 2 seconds or more.	
U1001	CAN COMM CIRCUIT	When ECM is not transmitting or receiving CAN communication signal other than OBD (emission-related diagnosis) for 2 seconds or more.	
U1002	SYSTEM COMM	When a control unit is not transmitting or receiving CAN communication signal for 2 seconds or less.	Start the inspection. Refer to the applicable section of the indicated control unit.
U1010	CONTROL UNIT [CAN]	When an error is detected during the initial diagnosis for CAN controller of each control unit.	Replace the control unit indicating "U1010".

HOW TO USE THIS SECTION

< SERVICE INFORMATION >

[CAN]

HOW TO USE THIS SECTION

Caution

INFOID:000000003533620

- This section describes information peculiar to a vehicle, sheets for trouble diagnosis, and inspection procedures.
- For trouble diagnosis procedure, refer to [LAN-14, "Trouble Diagnosis Procedure"](#).

Abbreviation List

INFOID:000000003533621

Abbreviations in CAN communication signal chart, and the diagnosis sheet are as per the following list.

Abbreviation	Unit name	SELECT SYSTEM (CONSULT-II)	CAN DIAG SUPPORT MNTR (CONSULT-II)
4WD	Transfer control unit	ALL MODE AWD/4WD	AWD/4WD
A-BAG	Air bag diagnosis sensor unit	AIR BAG	-
ABS	ABS actuator and electric unit (control unit)	ABS	VDC/TCS/ABS
ADP	Driver seat control unit	AUTO DRIVE POS.	-
BCM	BCM	BCM	BCM/SEC
DISP	Display control unit	-	DISPLAY
DLC	Data link connector	-	-
ECM	ECM	ENGINE	ECM
HVAC	Front air control	HVAC	-
ICC	ICC unit	ICC	ICC
			ICC/e4WD
IPDM-E	IPDM E/R	IPDM E/R	IPDM E/R
LASER	ICC sensor	-	ICC SENSOR
M&A	Combination meter	-	METER/M&A
STRG	Steering angle sensor	-	STRG
TCM	A/T assembly	A/T	TCM

LAN

PRECAUTIONS

< SERVICE INFORMATION >

[CAN]

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000003533622

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

Precaution When Using CONSULT-II

INFOID:000000003533623

Use CONSULT-II CONVERTER when connecting CONSULT-II to data link connector.

CAUTION:

CAN communication does not function properly if CONSULT-II is used without connecting CONSULT-II CONVERTER.

Precaution for Trouble Diagnosis

INFOID:000000003533624

CAUTION:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.
- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.


Precaution for Harness Repair

INFOID:000000003533625

- Solder the repaired area and wrap tape around the soldered area.

NOTE:

A fray of twisted lines must be within 110 mm (4.33 in).



PRECAUTIONS


< SERVICE INFORMATION >

[CAN]

- Bypass connection is never allowed at the repaired area.

NOTE:

Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

LAN

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

TROUBLE DIAGNOSIS

CAN Diagnostic Support Monitor

INFOID:000000003533626

Use "CAN DIAG SUPPORT MNTR" for detecting the root cause.

MONITOR ITEM LIST (CONSULT-II)

ECM

0: Error at present, 1 – 39: Error in the past (Number means the number of times the ignition switch is turned OFF→ON)

SELECT SYSTEM	CAN DIAG SUPPORT MNTR	Description	Normal		Error	
			PRSNT	PAST	PRSNT	PAST
ENGINE	TRANSMIT DIAG	Signal transmission status	OK	OK or 1 – 39*	UNKWEN	0
	VDC/TCS/ABS	Signal receiving status from the ABS actuator and electric unit (control unit)				
	METER/M&A	Signal receiving status from the combination meter				
	BCM/SEC	Signal receiving status from the BCM				
	ICC	Signal receiving status from the ICC unit				
	HVAC	Not used even though indicated				
	TCM	Signal receiving status from the TCM	OK	OK or 1 – 39*	UNKWEN	0
	EPS	Not used even though indicated				
	IPDM E/R	Signal receiving status from the IPDM E/R	OK	OK or 1 – 39*	UNKWEN	0
	e4WD	Not used even though indicated				
AWD/4WD	Signal receiving status from the transfer control unit	OK	OK or 1 – 39*	UNKWEN	0	

*: 39 or higher number is fixed at 39 until the self-diagnosis result is erased.

TCM

NOTE:

Replace the unit when "NG" is indicated on the "INITIAL DIAG".

SELECT SYSTEM	CAN DIAG SUPPORT MNTR	Description	Normal	Error
			PRSNT	
A/T	INITIAL DIAG	Status of CAN controller	OK	NG
	TRANSMIT DIAG	Signal transmission status		UNKWEN
	ECM	Signal receiving status from the ECM		
	VDC/TCS/ABS	Signal receiving status from the ABS actuator and electric unit (control unit)		
	METER/M&A	Signal receiving status from the combination meter		
	ICC/e4WD	Signal receiving status from the ICC unit		
	AWD/4WD	Signal receiving status from the transfer control unit		

ICC Unit

NOTE:

Replace the unit when "NG" is indicated on the "INITIAL DIAG".

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

SELECT SYSTEM	CAN DIAG SUPPORT MNTR	Description	Normal	Error		
			PRSNT			
ICC	INITIAL DIAG	Status of CAN controller	OK	NG		
	TRANSMIT DIAG	Signal transmission status		OK	UNKWN	
	ECM	Signal receiving status from the ECM				
	VDC/TCS/ABS	Signal receiving status from the ABS actuator and electric unit (control unit)				
	TCM	Signal receiving status from the TCM				
	METER/M&A	Not used even though indicated				
	LANE KEEP					
	ECM(I)					
	ICC SENSOR	Signal receiving status from the ICC sensor			OK	UNKWN
	STRG	Not used even though indicated				
	METER/M&A(I)					
	ERROR(I)					
	LANE DETECTOR					
	TCM(I)					
	BCM/SEC	Signal receiving status from the BCM			OK	UNKWN

Driver Seat Control Unit

0: Error at present, 1 – 39: Error in the past (Number means the number of times the ignition switch is turned OFF→ON)

SELECT SYSTEM	CAN DIAG SUPPORT MNTR	Description	Normal		Error	
			PRSNT	PAST	PRSNT	PAST
AUTO DRIVE POS.	TRANSMIT DIAG	Not used even though indicated				
	METER/M&A	Signal receiving status from the combination meter	OK	OK or 1 – 39*	UNKWN	0
	BCM/SEC	Signal receiving status from the BCM				
	TCM	Signal receiving status from the TCM				

*: 39 or higher number is fixed at 39 until the self-diagnosis result is erased.

BCM

NOTE:

Replace the unit when “NG” is indicated on the “INITIAL DIAG”.

SELECT SYSTEM	CAN DIAG SUPPORT MNTR	Description	Normal	Error
			PRSNT	
BCM	INITIAL DIAG	Status of CAN controller	OK	NG
	TRANSMIT DIAG	Signal transmission status		UNKWN
	ECM	Signal receiving status from the ECM		
	IPDM E/R	Signal receiving status from the IPDM E/R		
	METER/M&A	Signal receiving status from the combination meter		
	I-KEY	Not used even though indicated		

Front Air Control

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

0: Error at present, 1 – 39: Error in the past (Number means the number of times the ignition switch is turned OFF→ON)

SELECT SYSTEM	CAN DIAG SUPPORT MNTR	Description	Normal		Error	
			PRSNT	PAST	PRSNT	PAST
HVAC	TRANSMIT DIAG	Signal transmission status	OK	OK or 1 – 39*	UNKWN	0
	ECM	Signal receiving status from the ECM				
	TCM	Not used even though indicated				
	BCM/SEC	Signal receiving status from the BCM	OK	OK or 1 – 39*	UNKWN	0
	VDC/TCS/ABS	Signal receiving status from the ABS actuator and electric unit (control unit)				
	IPDM E/R	Not used even though indicated				
	DISPLAY	Signal receiving status from the display control unit	OK	OK or 1 – 39*	UNKWN	0
	I-KEY	Not used even though indicated				
	EPS					
	AWD/4WD					
	e4WD					
	ICC					
LANE KEEP						
TIRE-P						

*: 39 or higher number is fixed at 39 until the self-diagnosis result is erased.

Transfer Control Unit

0: Error at present, 1 – 39: Error in the past (Number means the number of times the ignition switch is turned OFF→ON)

SELECT SYSTEM	CAN DIAG SUPPORT MNTR	Description	Normal		Error	
			PRSNT	PAST	PRSNT	PAST
ALL MODE AWD/4WD	TRANSMIT DIAG	Signal transmission status	OK	OK or 1 – 39*	UNKWN	0
	ECM	Signal receiving status from the ECM				
	VDC/TCS/ABS	Signal receiving status from the ABS actuator and electric unit (control unit)				
	TCM	Signal receiving status from the TCM				
	STRG	Signal receiving status from the steering angle sensor				

*: 39 or higher number is fixed at 39 until the self-diagnosis result is erased.

ABS Actuator and Electric Unit (Control Unit)

SELECT SYSTEM	CAN DIAG SUPPORT MNTR	Description	Normal	Error
			PRSNT	
ABS	INITIAL DIAG	Status of CAN controller	OK	NG ^{Caution}
	TRANSMIT DIAG	Signal transmission status		
	ECM	Signal receiving status from the ECM		
	TCM	Signal receiving status from the TCM		
	METER/M&A	Not used even though indicated		
	STRG	Signal receiving status from the steering angle sensor	OK	UNKWN
	ICC	Signal receiving status from the ICC unit		
AWD/4WD	Signal receiving status from the transfer control unit			

CAUTION:

TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

Never replace the unit even when "NG" is indicated on the "INITIAL DIAG" at this stage. Follow the trouble diagnosis procedures.

IPDM E/R

0: Error at present, 1 – 39: Error in the past (Number means the number of times the ignition switch is turned OFF→ON)

SELECT SYSTEM	CAN DIAG SUPPORT MNTR	Description	Normal		Error	
			PRSNT	PAST	PRSNT	PAST
IPDM E/R	TRANSMIT DIAG	Signal transmission status	OK	OK or 1 – 39*	UNKWN	0
	ECM	Signal receiving status from the ECM				
	BCM/SEC	Signal receiving status from the BCM				

*: 39 or higher number is fixed at 39 until the self-diagnosis result is erased.

MONITOR ITEM LIST (ON-BOARD DIAGNOSIS)

Display Control Unit

NOTE:

CAN diagnostic support monitor of the display control unit is indicated on the vehicle display. Refer to [AV-123](#), "[CAN Communication Line Check](#)".

(Example)

CAN DIAG SUPPORT MONITOR				Delete
CAN_COMM	OK	0		
CAN_CIRC_1	OK	0		
CAN_CIRC_2	OK	0		
CAN_CIRC_3	OK	0		
CAN_CIRC_4	OK	0		
CAN_CIRC_5	OK	0		
CAN_CIRC_6	OK	0		
CAN_CIRC_7	OK	0		
CAN_CIRC_8	OK	0		
CAN_CIRC_9	UNKWN	0		

PKIB6080E

Unit name	Diagnosis item	Description	Indicated items on CAN DIAG SUPPORT MONITOR					
			Normal		Error			
			Result indicated	Error counter (Reference)	Result indicated	Error counter (Reference)		
Display control unit	CAN_COMM	Status of CAN controller	OK	0 or 1 – 50*	NG	1 – 50*		
	CAN_CIRC_1	Signal transmission status						
	CAN_CIRC_2	Signal receiving status from the BCM						
	CAN_CIRC_3	Signal receiving status from the ECM						
	CAN_CIRC_4	Signal receiving status from the front air control						
	CAN_CIRC_5	Signal receiving status from the combination meter						
	CAN_CIRC_6	Not used even though indicated						
	CAN_CIRC_7	Signal receiving status from the IPDM E/R			UNKWN			
	CAN_CIRC_8	Not used even though indicated						
	CAN_CIRC_9	Not used even though indicated						

*: The error counter stops counting when it reaches "50" and holds "50" until it is deleted.

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

CAN System Specification Chart

INFOID:000000003533627

Determine CAN system type from the following specification chart. Then choose the correct diagnosis sheet.

NOTE:

Refer to [LAN-14, "Trouble Diagnosis Procedure"](#) for how to use CAN system specification chart.


Body type	Wagon			
Axle	2WD		AWD	
Engine	VK56DE			
Transmission	A/T			
Brake control	VDC			
ICC system		X		X
CAN system type	1	2	3	4
Diagnosis sheet	LAN-57	LAN-58	LAN-59	LAN-60
CAN communication signal chart	LAN-44, "CAN Communication Signal Chart"		LAN-44, "CAN Communication Signal Chart"	

X: Applicable

VEHICLE EQUIPMENT IDENTIFICATION INFORMATION

NOTE:

Check CAN system type from the vehicle shape and equipment.



CAN Communication Signal Chart

INFOID:000000003533628

Refer to [LAN-13, "How to Use CAN Communication Signal Chart"](#) for how to use CAN communication signal chart.

TYPE 1/TYPE 2

NOTE:

Refer to [LAN-37, "Abbreviation List"](#) for the abbreviations of the connecting units.

T: Transmit R: Receive

Signal name/Connecting unit	ECM	TCM	LASER	ICC	ADP	BCM	DISP	HVAC	M&A	STRG	ABS	IPDM-E
A/C compressor request signal	T											R
Accelerator pedal position signal	T	R		R							R	
ASCD CRUISE lamp signal	T								R			
ASCD OD cancel request signal	T	R										
ASCD operation signal	T	R										
ASCD SET lamp signal	T								R			
Battery voltage signal	T	R										
Closed throttle position signal	T	R		R								
Cooling fan speed request signal	T											R
Engine coolant temperature signal	T							R	R			

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

Signal name/Connecting unit	ECM	TCM	LASER	ICC	ADP	BCM	DISP	HVAC	M&A	STRG	ABS	IPDM-E
Engine speed signal	T	R		R			R	R	R		R	
Engine status signal	T					R						
Fuel consumption monitor signal	T								R			
							R		T			
ICC steering switch signal	T			R								
Malfunction indicator lamp signal	T								R			
Wide open throttle position signal	T	R										
A/T CHECK indicator lamp signal		T							R			
A/T fluid temperature sensor signal		T							R			
A/T position indicator lamp signal		T		R					R			
A/T self-diagnosis signal	R	T										
Current gear position signal		T		R							R	
Output shaft revolution signal	R	T		R								
P range signal		T		R	R				R		R	
Turbine revolution signal	R	T		R								
ICC sensor signal			T	R								
Buzzer output signal				T					R			
						T			R			
ICC OD cancel request signal	R	R		T								
ICC operation signal	R	R		T								
ICC system display signal				T					R			
System setting signal					T		R					
					R		T					
A/C switch signal	R					T		R				
Blower fan motor switch signal	R					T						
Day time running light request signal						T			R			R
Door switch signal					R	T	R		R			R
Front fog light request signal						T						R
Front wiper request signal				R		T						R
High beam request signal						T			R			R
Horn chirp signal						T						R
Ignition switch signal					R	T						R
Key fob door unlock signal					R	T						
Key fob ID signal					R	T						
Key switch signal					R	T						
Low beam request signal						T						R
Position light request signal						T			R			R
Rear window defogger switch signal						T		R				R
Sleep wake up signal					R	T			R			R
Theft warning horn request signal						T						R
Tire pressure data signal						T	R					
Tire pressure signal						T	R		R			
Turn indicator signal						T			R			

A
B
C
D
E
F
G
H
I
J
LAN
L
M
N
O
P

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

Signal name/Connecting unit	ECM	TCM	LASER	ICC	ADP	BCM	DISP	HVAC	M&A	STRG	ABS	IPDM-E
A/C switch/indicator signal							T R	R T				
1st position switch signal		R							T			
4th position switch signal		R							T			
Distance to empty signal							R		T			
Fuel level low warning signal							R		T			
Fuel level sensor signal	R								T			
Parking brake switch signal						R			T			
Stop lamp switch signal		R							T			
Tow mode switch signal		R							T			
Vehicle speed signal								R	R		T	
	R	R	R		R	R	R		T			
Steering angle sensor signal										T	R	
ABS malfunction signal				R							T	
ABS warning lamp signal									R		T	
Brake pressure sensor signal				R							T	
Brake warning lamp signal									R		T	
SLIP indicator lamp signal									R		T	
TCS malfunction signal				R							T	
VDC malfunction signal				R							T	
VDC OFF indicator lamp signal				R					R		T	
VDC operation signal				R							T	
Front wiper stop position signal						R						T
High beam status signal	R											T
Hood switch signal						R						T
Low beam status signal	R											T
Rear window defogger control signal	R						R					T

NOTE:

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.

TYPE 3/TYPE 4

NOTE:

Refer to [LAN-37. "Abbreviation List"](#) for the abbreviations of the connecting units.

T: Transmit R: Receive

Signal name/Connecting unit	ECM	TCM	LASER	ICC	ADP	BCM	DISP	HVAC	M&A	STRG	4WD	ABS	IPDM-E
A/C compressor request signal	T												R
Accelerator pedal position signal	T	R		R							R	R	
ASCD CRUISE lamp signal	T								R				
ASCD OD cancel request signal	T	R											
ASCD operation signal	T	R											
ASCD SET lamp signal	T								R				
Battery voltage signal	T	R											
Closed throttle position signal	T	R		R									

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

Signal name/Connecting unit	ECM	TCM	LASER	ICC	ADP	BCM	DISP	HVAC	M&A	STRG	4WD	ABS	IPDM-E	
Cooling fan speed request signal	T												R	A
Engine coolant temperature signal	T							R	R					B
Engine speed signal	T	R		R			R	R	R		R	R		
Engine status signal	T					R								C
Fuel consumption monitor signal	T								R					
							R		T					
ICC steering switch signal	T			R										D
Malfunction indicator lamp signal	T								R					
Wide open throttle position signal	T	R												E
A/T CHECK indicator lamp signal		T							R					
A/T fluid temperature sensor signal		T							R					
A/T position indicator lamp signal		T		R					R		R			F
A/T self-diagnosis signal	R	T												
Current gear position signal		T		R								R		
Output shaft revolution signal	R	T		R							R			G
P range signal		T		R	R				R			R		
Turbine revolution signal	R	T		R										H
ICC sensor signal			T	R										
Buzzer output signal				T					R					
						T			R					I
ICC OD cancel request signal	R	R		T										
ICC operation signal	R	R		T										J
ICC system display signal				T					R					
System setting signal					T		R							
					R		T							LAN
A/C switch signal	R					T		R						
Blower fan motor switch signal	R					T								L
Day time running light request signal						T			R				R	
Door switch signal					R	T	R		R				R	
Front fog light request signal						T							R	M
Front wiper request signal				R		T							R	
High beam request signal						T			R				R	
Horn chirp signal						T							R	N
Ignition switch signal					R	T							R	
Key fob door unlock signal					R	T								O
Key fob ID signal					R	T								
Key switch signal					R	T								
Low beam request signal						T							R	P
Position light request signal						T			R				R	
Rear window defogger switch signal						T		R					R	
Sleep wake up signal					R	T			R				R	
Theft warning horn request signal						T							R	
Tire pressure data signal						T	R							

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

Signal name/Connecting unit	ECM	TCM	LASER	ICC	ADP	BCM	DISP	HVAC	M&A	STRG	4WD	ABS	IPDM-E
Tire pressure signal						T	R		R				
Turn indicator signal						T			R				
A/C switch/indicator signal							T R	R T					
1st position switch signal		R							T				
4th position switch signal		R							T				
Distance to empty signal							R		T				
Fuel level low warning signal							R		T				
Fuel level sensor signal	R								T				
Parking brake switch signal						R			T				
Stop lamp switch signal		R							T				
Tow mode switch signal		R							T				
Vehicle speed signal								R	R		R	T	
	R	R	R		R	R	R		T				
Steering angle sensor signal										T		R	
ABS malfunction signal				R								T	
ABS warning lamp signal									R			T	
Brake pressure sensor signal				R								T	
Brake warning lamp signal									R			T	
SLIP indicator lamp signal									R			T	
TCS malfunction signal				R								T	
VDC malfunction signal				R								T	
VDC OFF indicator lamp signal				R					R			T	
VDC operation signal				R								T	
Front wiper stop position signal						R							T
High beam status signal	R												T
Hood switch signal						R							T
Low beam status signal	R												T
Rear window defogger control signal	R						R						T

NOTE:

CAN data of the air bag diagnosis sensor unit is not used by usual service work, thus it is omitted.


TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

Schematic

INFOID:000000003533629



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

LAN

BKWA0730E

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >


[CAN]

Wiring Diagram - CAN -


INFOID:000000003533630

LAN-CAN-01

▬ : DATA LINE
 ◊ (IC) : WITH ICC



NEXT PAGE



REFER TO THE FOLLOWING.
 (M40) - SUPER MULTIPLE JUNCTION (SMJ)

*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.





BKWA0731E

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

LAN-CAN-02





BKWA0732E

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

LAN-CAN-03



REFER TO THE FOLLOWING.
 (M31) - SUPER MULTIPLE JUNCTION (SMJ)

BKWA0733E

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

Interview Sheet

INFOID:000000003533631

CAN Communication System Diagnosis Interview Sheet

Date received:

Type:

VIN No.:

Model:

First registration:

Mileage:

CAN system type:

Symptom (Results from interview with customer)

Condition at inspection

Error symptom : Present / Past

SKIB8898E

A
B
C
D
E
F
G
H
I
J
LAN
L
M
N
O
P

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

Data Sheet

INFOID:000000003533632

CONSULT-II DATA ATTACHMENT SHEET

Attach printout of ICC SELF-DIAG RESULTS and CAN DIAG SUPPORT MNTR
Attach printout of A/T SELF-DIAG RESULTS and CAN DIAG SUPPORT MNTR
Attach printout of ENGINE SELF-DIAG RESULTS and CAN DIAG SUPPORT MNTR
Attach printout of SELECT SYSTEM

PKID0654E

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

<p>Attach printout of ALL MODE AWD/4WD SELF-DIAG RESULTS and CAN DIAG SUPPORT MNTR</p>
<p>Attach printout of HVAC SELF-DIAG RESULTS and CAN DIAG SUPPORT MNTR</p>
<p>Attach printout of BCM SELF-DIAG RESULTS and CAN DIAG SUPPORT MNTR</p>
<p>Attach printout of AUTO DRIVE POS. SELF-DIAG RESULTS and CAN DIAG SUPPORT MNTR</p>

PKID0651E

A
B
C
D
E
F
G
H
I
J
LAN
L
M
N
O
P

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

Attach printout of
IPDM E/R
SELF-DIAG RESULTS
and
CAN DIAG SUPPORT MNTR

Attach printout of
ABS
SELF-DIAG RESULTS
and
CAN DIAG SUPPORT MNTR

PKID0390E

ON-BOARD DIAGNOSIS COPY SHEET

NOTE:

CAN diagnostic support monitor of the display control unit is indicated on the vehicle display. Refer to [AV-109](#), "[CAN Diagnostic Support Monitor](#)".

Vehicle monitor (Display control unit) CAN DIAG SUPPORT MONITOR copy sheet

Indication item (Diagnosis item)	Vehicle monitor		Indication item (Diagnosis item)	Vehicle monitor	
	Result indicated	Error counter		Result indicated	Error counter
CAN_COMM (Initial diagnosis)			CAN_CIRC_5 (Receive diagnosis of Combination meter)		
CAN_CIRC_1 (Transmit diagnosis)			CAN_CIRC_6	Not available	
CAN_CIRC_2 (Receive diagnosis of BCM)			CAN_CIRC_7 (Receive diagnosis of IPDM E/R)		
CAN_CIRC_3 (Receive diagnosis of ECM)			CAN_CIRC_8	Not available	
CAN_CIRC_4 (Receive diagnosis of Front air control)			CAN_CIRC_9	Not available	

SKIB8771E

TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

CAN System (Type 1)

INFOID:000000003533633

DIAGNOSIS SHEET

▲ : Diag on CAN unit

Possible root cause

Inspection result

< CONSULT-II printout checklist >

Item	Check box
1 SELECT SYSTEM	<input type="checkbox"/>
2 ENGINE	<input type="checkbox"/>
3 A/T	<input type="checkbox"/>
4 AUTO DRIVE POS.▲	<input type="checkbox"/>
5 BCM▲	<input type="checkbox"/>
6 HVAC▲	<input type="checkbox"/>
7 ABS	<input type="checkbox"/>
8 IPDME/R▲	<input type="checkbox"/>

< On-board diagnosis copy checklist >

Item	Check box
1 Display control unit	<input type="checkbox"/>

PKID0632E

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

LAN

TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

CAN System (Type 2)

INFOID:000000003533634

DIAGNOSIS SHEET

The diagram shows a central CAN bus line with several nodes. From left to right, the nodes are: ECM, TCM, LASER, ICC, ADP, A-BAG, BCM, DISP, DLC, HVAC, M&A, STRG, ABS, and IPDME. Solid lines connect the bus to ECM, TCM, LASER, ICC, ADP, and ABS. Dashed lines connect the bus to A-BAG, BCM, DISP, DLC, HVAC, M&A, STRG, and IPDME. Small triangles point to the bus line at the nodes for ADP, BCM, and IPDME. A legend indicates that a triangle symbol means ': Diag on CAN unit'.

< CONSULT-II printout checklist >

Item	Item	Check box
1	SELECT SYSTEM	<input type="checkbox"/>
2	ENGINE	<input type="checkbox"/>
3	A/T	<input type="checkbox"/>
4	ICC	<input type="checkbox"/>
5	AUTO DRIVE POS.*	<input type="checkbox"/>
6	BCM*	<input type="checkbox"/>
7	HVAC*	<input type="checkbox"/>
8	ABS	<input type="checkbox"/>
9	IPDM E/R*	<input type="checkbox"/>

< On-board diagnosis copy checklist >

Item	Item	Check box
1	Display control unit	<input type="checkbox"/>

Possible root cause

Inspection result

PKID0652E

LAN-58

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

CAN System (Type 3)

INFOID:000000003533635

DIAGNOSIS SHEET

▲ : Diag on CAN unit

< CONSULT-II printout checklist >

Item	Check box
1	SELECT SYSTEM
2	ENGINE
3	A/T
4	AUTO DRIVE POS.▲
5	BCM▲
6	HVAC▲
7	ALL MODE AWD/4WD▲
8	ABS
9	IPDME/R▲

< On-board diagnosis copy checklist >

Item	Check box
1	Display control unit

Possible root cause

Inspection result

A
B
C
D
E
F
G
H
I
J
LAN
L
M
N
O
P

PKID0670E

TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

CAN System (Type 4)

INFOID:000000003533636

DIAGNOSIS SHEET

▲ : Diag on CAN unit

Possible root cause

Inspection result

< CONSULT-II printout checklist >

Item	Check box
1	SELECT SYSTEM
2	ENGINE
3	A/T
4	ICC
5	AUTO DRIVE POS.▲
6	BCM▲
7	HVAC▲
8	ALL MODE AWD/4WD▲
9	ABS
10	IPDME/R▲

< On-board diagnosis copy checklist >

Item	Check box
1	Display control unit

PKID0653E


TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

Component Parts Location

INFOID:000000003533637



BKIA0189E

- | | | |
|---------------------------------|----------------------------|---|
| 1. ECM E16 | 2. IPDM E/R E122 | 3. ICC sensor E42 |
| 4. Display control unit M95 | 5. Combination meter M24 | 6. ABS actuator and electric unit (control unit) E125 |
| 7. BCM M18 | 8. Data link connector M22 | 9. Steering angle sensor M47 |
| 10. Driver seat control unit P2 | 11. ICC unit B13 | 12. Air bag diagnosis sensor unit M35 |
| 13. A/T assembly F9 | 14. Front air control M50 | 15. Transfer control unit E142 |

Harness Layout

INFOID:000000003533638

Refer to [PG-39, "Harness Layout"](#).

Malfunction Area Chart

INFOID:000000003533639

MAIN LINE

Malfunction Area	Reference
Main line between TCM and driver seat control unit	LAN-62, "Main Line Between TCM and Driver Seat Control Unit"
Main line between TCM and ICC sensor	LAN-63, "Main Line Between TCM and ICC Sensor"
Main line between ICC sensor and ICC unit	LAN-64, "Main Line Between ICC Sensor and ICC Unit"
Main line between ICC unit and driver seat control unit	LAN-65, "Main Line Between ICC Unit and Driver Seat Control Unit"
Main line between driver seat control unit and data link connector	LAN-65, "Main Line Between Driver Seat Control Unit and Data Link Connector"
Main line between data link connector and ABS actuator and electric unit (control unit)	LAN-66, "Main Line Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)"

BRANCH LINE

Malfunction Area	Reference
ECM branch line circuit	LAN-67, "ECM Branch Line Circuit"
TCM branch line circuit	LAN-67, "TCM Branch Line Circuit"
ICC sensor branch line circuit	LAN-68, "ICC Sensor Branch Line Circuit"
ICC unit branch line circuit	LAN-69, "ICC Unit Branch Line Circuit"
Driver seat control unit branch line circuit	LAN-69, "Driver Seat Control Unit Branch Line Circuit"

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

Malfunction Area	Reference
BCM branch line circuit	LAN-70. "BCM Branch Line Circuit"
Display control unit branch line circuit	LAN-70. "Display Control Unit Branch Line Circuit"
Data link connector branch line circuit	LAN-71. "Data Link Connector Branch Line Circuit"
Front air control branch line circuit	LAN-71. "Front Air Control Branch Line Circuit"
Combination meter branch line circuit	LAN-72. "Combination Meter Branch Line Circuit"
Steering angle sensor branch line circuit	LAN-72. "Steering Angle Sensor Branch Line Circuit"
Transfer control unit branch line circuit	LAN-73. "Transfer Control Unit Branch Line Circuit"
ABS actuator and electric unit (control unit) branch line circuit	LAN-74. "ABS Actuator and Electric Unit (Control Unit) Branch Line Circuit"
IPDM E/R branch line circuit	LAN-74. "IPDM E/R Branch Line Circuit"

SHORT CIRCUIT

Malfunction Area	Reference
CAN communication circuit	LAN-75. "CAN Communication Circuit"

Main Line Between TCM and Driver Seat Control Unit

INFOID:000000003533640

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5
 - Harness connector E34
 - Harness connector B40

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/T assembly and the harness connectors F14 and E5.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
F9	3	F14	5	Yes
	8		15	Yes

OK or NG

- OK >> GO TO 3.
 NG >> Repair the main line between the A/T assembly and the harness connector F14.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors E34 and B40.
2. Check the continuity between harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

E5	5	E34	24	Yes
	15		23	Yes

OK or NG

- OK >> GO TO 4.
 NG >> Repair the main line between the harness connectors E5 and E34.

4.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors B37 and P1.
2. Check the continuity between harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B40	24	B37	15	Yes
	23		14	Yes

OK or NG

- OK >> • Present error: Check the following items again.
 - Decision of CAN system type.
 - Not received CONSULT-II data (SELECT SYSTEM, SELF-DIAG RESULTS, CAN DIAG SUPPORT MNTR).
 - Not copied from on-board diagnosis.
 - Procedure for detecting root cause.
 • Past error: Error was detected in the main line between the TCM and the driver seat control unit.
- NG >> Repair the main line between the harness connectors B40 and B37.

Main Line Between TCM and ICC Sensor

INFOID:000000003533641

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector F14
 - Harness connector E5

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of A/T assembly and the harness connectors F14 and E5.
2. Check the continuity between the A/T assembly harness connector and the harness connector.

A/T assembly harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
F9	3	F14	5	Yes
	8		15	Yes

OK or NG

- OK >> GO TO 3.
 NG >> Repair the main line between the A/T assembly and the harness connector F14.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ICC sensor.
2. Check the continuity between the harness connector and the ICC sensor harness connector.

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

Harness connector		ICC sensor harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E5	5	E42	2	Yes
	15		3	Yes

OK or NG

- OK >> • Present error: Check the following items again.
- Decision of CAN system type.
 - Not received CONSULT-II data (SELECT SYSTEM, SELF-DIAG RESULTS, CAN DIAG SUPPORT MNTR).
 - Not copied from on-board diagnosis.
 - Procedure for detecting root cause.
 - Past error: Error was detected in the main line between the TCM and the ICC sensor.
- NG >> Repair the main line between the harness connector E5 and the ICC sensor.

Main Line Between ICC Sensor and ICC Unit

INFOID:000000003533642

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector E34
 - Harness connector B40

OK or NG

- OK >> GO TO 2.
 NG >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ICC sensor and the harness connectors E34 and B40.
2. Check the continuity between the ICC sensor harness connector and the harness connector.

ICC sensor harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E42	2	E34	24	Yes
	3		23	Yes

OK or NG

- OK >> GO TO 3.
 NG >> Repair the main line between the ICC sensor and the harness connector E34.

3. CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ICC unit.
2. Check the continuity between the harness connector and the ICC unit harness connector.

Harness connector		ICC unit harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B40	24	B13	14	Yes
	23		5	Yes

OK or NG

- OK >> • Present error: Check the following items again.
- Decision of CAN system type.
 - Not received CONSULT-II data (SELECT SYSTEM, SELF-DIAG RESULTS, CAN DIAG SUPPORT MNTR).

TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

- Not copied from on-board diagnosis.
- Procedure for detecting root cause.
- Past error: Error was detected in the main line between the ICC sensor and the ICC unit.

NG >> Repair the main line between the harness connector B40 and the ICC unit.

Main Line Between ICC Unit and Driver Seat Control Unit

INFOID:000000003533643

INSPECTION PROCEDURE

1.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Disconnect the following harness connectors.
 - ECM harness connector
 - ICC unit harness connector
 - Harness connectors B37 and P1
4. Check continuity between the ICC unit harness connector and the harness connector.

ICC unit harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
B13	14	B37	15	Yes
	5		14	Yes

OK or NG

- OK >> • Present error: Check the following items again.
- Decision of CAN system type.
 - Not received CONSULT-II data (SELECT SYSTEM, SELF-DIAG RESULTS, CAN DIAG SUPPORT MNTR).
 - Not copied from on-board diagnosis.
 - Procedure for detecting root cause.
 - Past error: Error was detected in the main line between the ICC unit and the driver seat control unit.

NG >> Repair the main line between the ICC unit and the harness connector B37.

Main Line Between Driver Seat Control Unit and Data Link Connector

INFOID:000000003533644

LAN

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector B69
 - Harness connector M40

OK or NG

- OK >> GO TO 2.
NG >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the following harness connectors.
 - Harness connectors P1 and B37
 - Harness connectors B69 and M40
2. Check the continuity between harness connectors.

Harness connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

B37	15	B69	51J	Yes
	14		52J	Yes

OK or NG

OK >> GO TO 3.

NG >> Repair the main line between the harness connectors B37 and B69.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

Check the continuity between the harness connector and the data link connector.

Harness connector		Data link connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M40	51J	M22	6	Yes
	52J		14	Yes

OK or NG

OK >> • Present error: Check the following items again.

- Decision of CAN system type.
- Not received CONSULT-II data (SELECT SYSTEM, SELF-DIAG RESULTS, CAN DIAG SUPPORT MNTR).
- Not copied from on-board diagnosis.
- Procedure for detecting root cause.
- Past error: Error was detected in the main line between the driver seat control unit and the data link connector.

NG >> Repair the main line between the harness connector M40 and the data link connector.

Main Line Between Data Link Connector and ABS Actuator and Electric Unit (Control Unit)

INFOID:000000003533645

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (connector side and harness side).
 - Harness connector M31
 - Harness connector E152

OK or NG

OK >> GO TO 2.

NG >> Repair the terminal and connector.

2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the harness connectors M31 and E152.
2. Check the continuity between the data link connector and the harness connector.

Data link connector		Harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
M22	6	M31	31G	Yes
	14		42G	Yes

OK or NG

OK >> GO TO 3.

NG >> Repair the main line between the data link connector and the harness connector M31.

3.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect the connector of ABS actuator and electric unit (control unit).

TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

2. Check the continuity between the harness connector and the ABS actuator and electric unit (control unit) harness connector.

Harness connector		ABS actuator and electric unit (control unit) harness connector		Continuity
Connector No.	Terminal No.	Connector No.	Terminal No.	
E152	31G	E125	11	Yes
	42G		15	Yes

OK or NG

- OK >> • Present error: Check the following items again.
- Decision of CAN system type.
 - Not received CONSULT-II data (SELECT SYSTEM, SELF-DIAG RESULTS, CAN DIAG SUPPORT MNTR).
 - Not copied from on-board diagnosis.
 - Procedure for detecting root cause.
 - Past error: Error was detected in the main line between the data link connector and the ABS actuator and electric unit (control unit).
- NG >> Repair the main line between the harness connector E152 and the ABS actuator and electric unit (control unit).

ECM Branch Line Circuit

INFOID:000000003533646

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - ECM connector
 - Harness connector E5
 - Harness connector F14

OK or NG

- OK >> GO TO 2.
NG >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ECM.
2. Check the resistance between the ECM harness connector terminals.

ECM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E16	94	86	Approx. 108 – 132

OK or NG

- OK >> GO TO 3.
NG >> Repair the ECM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ECM. Refer to [EC-101, "Circuit Diagram"](#).

OK or NG

- OK >> • Present error: Replace the ECM. Refer to [EC-77, "Procedure After Replacing ECM"](#).
• Past error: Error was detected in the ECM branch line.
- NG >> Repair the power supply and the ground circuit.

TCM Branch Line Circuit

INFOID:000000003533647

INSPECTION PROCEDURE

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

LAN

TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the A/T assembly for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
NG >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of A/T assembly.
2. Check the resistance between the A/T assembly harness connector terminals.

A/T assembly harness connector			Resistance (Ω)
Connector No.	Terminal No.		
F9	3	8	Approx. 54 – 66

OK or NG

- OK >> GO TO 3.
NG >> Repair the TCM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the TCM. Refer to [AT-51. "Circuit Diagram"](#).

OK or NG

- OK >> • Present error: Replace the TCM.
• Past error: Error was detected in the TCM branch line.
NG >> Repair the power supply and the ground circuit.

ICC Sensor Branch Line Circuit

INFOID:000000003533648

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ICC sensor for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
NG >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ICC sensor.
2. Check the resistance between the ICC sensor harness connector terminals.

ICC sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E42	2	3	Approx. 54 – 66

OK or NG

- OK >> GO TO 3.
NG >> Repair the ICC sensor branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ICC sensor. Refer to [ACS-19. "Schematic"](#).

OK or NG

- OK >> • Present error: Replace the ICC sensor. Refer to [ACS-55. "ICC Sensor"](#).

TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

- Past error: Error was detected in the ICC sensor branch line.

NG >> Repair the power supply and the ground circuit.

ICC Unit Branch Line Circuit

INFOID:000000003533649

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ICC unit for damage, bend and loose connection (unit side and connector side).

OK or NG

OK >> GO TO 2.

NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ICC unit.
2. Check the resistance between the ICC unit harness connector terminals.

ICC unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
B13	14	5	Approx. 54 – 66

OK or NG

OK >> GO TO 3.

NG >> Repair the ICC unit branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ICC unit. Refer to [ACS-19, "Schematic"](#).

OK or NG

OK >> • Present error: Replace the ICC unit. Refer to [ACS-55, "ICC Unit"](#).

- Past error: Error was detected in the ICC unit branch line.

NG >> Repair the power supply and the ground circuit.

Driver Seat Control Unit Branch Line Circuit

INFOID:000000003533650

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the following terminals and connectors for damage, bend and loose connection (unit side and connector side).
 - Driver seat control unit connector
 - Harness connector P1
 - Harness connector B37

OK or NG

OK >> GO TO 2.

NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of driver seat control unit.
2. Check the resistance between the driver seat control unit harness connector terminals.

Driver seat control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
P2	3	19	Approx. 54 – 66

A

B

C

D

E

F

G

H

I

J

LAN

L

M

N

O

P

TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

OK or NG

- OK >> GO TO 3.
- NG >> Repair the driver seat control unit branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the driver seat control unit. Refer to [SE-13. "Schematic"](#).

OK or NG

- OK >> • Present error: Replace the driver seat control unit. Refer to [SE-74. "Removal and Installation"](#).
- Past error: Error was detected in the driver seat control unit branch line.
- NG >> Repair the power supply and the ground circuit.

BCM Branch Line Circuit

INFOID:000000003533651

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the BCM for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of BCM.
2. Check the resistance between the BCM harness connector terminals.

BCM harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M18	39	40	Approx. 54 – 66

OK or NG

- OK >> GO TO 3.
- NG >> Repair the BCM branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the BCM. Refer to [BCS-8. "Schematic"](#).

OK or NG

- OK >> • Present error: Replace the BCM. Refer to [BCS-24. "BCM"](#).
- Past error: Error was detected in the BCM branch line.
- NG >> Repair the power supply and the ground circuit.

Display Control Unit Branch Line Circuit

INFOID:000000003533652

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the display control unit for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of display control unit.

TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

2. Check the resistance between the display control unit harness connector terminals.

Display control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M95	25	26	Approx. 54 – 66

OK or NG

OK >> GO TO 3.

NG >> Repair the display control unit branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the display control unit. Refer to [AV-85. "Schematic"](#).

OK or NG

OK >> • Present error: Replace the display control unit. Refer to [AV-145. "Removal and Installation"](#).
• Past error: Error was detected in the display control unit branch line.

NG >> Repair the power supply and the ground circuit.

Data Link Connector Branch Line Circuit

INFOID:000000003533653

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the data link connector for damage, bend and loose connection (connector side and harness side).

OK or NG

OK >> GO TO 2.

NG >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

Check the resistance between the data link connector terminals.

Data link connector			Resistance (Ω)
Connector No.	Terminal No.		
M22	6	14	Approx. 54 – 66

OK or NG

OK >> • Present error: Check the following items again.

- Decision of CAN system type.
- Not received CONSULT-II data (SELECT SYSTEM, SELF-DIAG RESULTS, CAN DIAG SUPPORT MNTR).
- Not copied from on-board diagnosis.
- Procedure for detecting root cause.
- Past error: Error was detected in the data link connector branch line circuit.

NG >> Repair the data link connector branch line.

Front Air Control Branch Line Circuit

INFOID:000000003533654

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the front air control for damage, bend and loose connection (unit side and connector side).

OK or NG

OK >> GO TO 2.

NG >> Repair the terminal and connector.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

LAN

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of front air control.
2. Check the resistance between the front air control harness connector terminals.

Front air control harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M50	34	35	Approx. 54 – 66

OK or NG

- OK >> GO TO 3.
- NG >> Repair the front air control branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the front air control. Refer to [ATC-36, "Schematic"](#).

OK or NG

- OK >> • Present error: Replace the front air control. Refer to [ATC-123, "Removal and Installation"](#).
- Past error: Error was detected in the front air control branch line.
- NG >> Repair the power supply and the ground circuit.

Combination Meter Branch Line Circuit

INFOID:000000003533655

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the combination meter for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
- NG >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of combination meter.
2. Check the resistance between the combination meter harness connector terminals.

Combination meter harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M24	11	12	Approx. 54 – 66

OK or NG

- OK >> GO TO 3.
- NG >> Repair the combination meter branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the combination meter. Refer to [DI-9, "Wiring Diagram - METER -"](#).

OK or NG

- OK >> • Present error: Replace the combination meter. Refer to [IP-10, "Removal and Installation"](#).
- Past error: Error was detected in the combination meter branch line.
- NG >> Repair the power supply and the ground circuit.

Steering Angle Sensor Branch Line Circuit

INFOID:000000003533656

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.

TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the steering angle sensor for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
NG >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of steering angle sensor.
2. Check the resistance between the steering angle sensor harness connector terminals.

Steering angle sensor harness connector			Resistance (Ω)
Connector No.	Terminal No.		
M47	3	4	Approx. 54 – 66

OK or NG

- OK >> GO TO 3.
NG >> Repair the steering angle sensor branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the steering angle sensor. Refer to [BRC-15. "Schematic"](#).

OK or NG

- OK >> • Present error: Replace the steering angle sensor. Refer to [BRC-60. "Removal and Installation"](#).
• Past error: Error was detected in the steering angle sensor branch line.
NG >> Repair the power supply and the ground circuit.

Transfer Control Unit Branch Line Circuit

INFOID:000000003533657

INSPECTION PROCEDURE

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the transfer control unit for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
NG >> Repair the terminal and connector.

2.CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of transfer control unit.
2. Check the resistance between the transfer control unit harness connector terminals.

Transfer control unit harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E142	7	8	Approx. 54 – 66

OK or NG

- OK >> GO TO 3.
NG >> Repair the transfer control unit branch line.

3.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the transfer control unit. Refer to [TF-23. "Circuit Diagram"](#).

OK or NG

- OK >> • Present error: Replace the transfer control unit. Refer to [TF-115. "Removal and Installation"](#).
• Past error: Error was detected in the transfer control unit branch line.
NG >> Repair the power supply and the ground circuit.

TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

ABS Actuator and Electric Unit (Control Unit) Branch Line Circuit

INFOID:000000003533658

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the ABS actuator and electric unit (control unit) for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of ABS actuator and electric unit (control unit).
2. Check the resistance between the ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit) harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E125	11	15	Approx. 54 – 66

OK or NG

- OK >> GO TO 3.
NG >> Repair the ABS actuator and electric unit (control unit) branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the ABS actuator and electric unit (control unit). Refer to [BRC-15, "Schematic"](#).

OK or NG

- OK >> • Present error: Replace the ABS actuator and electric unit (control unit). Refer to [BRC-58, "Removal and Installation"](#).
• Past error: Error was detected in the ABS actuator and electric unit (control unit) branch line.
NG >> Repair the power supply and the ground circuit.

IPDM E/R Branch Line Circuit

INFOID:000000003533659

INSPECTION PROCEDURE

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect the battery cable from the negative terminal.
3. Check the terminals and connectors of the IPDM E/R for damage, bend and loose connection (unit side and connector side).

OK or NG

- OK >> GO TO 2.
NG >> Repair the terminal and connector.

2. CHECK HARNESS FOR OPEN CIRCUIT

1. Disconnect the connector of IPDM E/R.
2. Check the resistance between the IPDM E/R harness connector terminals.

IPDM E/R harness connector			Resistance (Ω)
Connector No.	Terminal No.		
E122	39	40	Approx. 108 – 132

OK or NG

- OK >> GO TO 3.

TROUBLE DIAGNOSIS

[CAN]

< SERVICE INFORMATION >

NG >> Repair the IPDM E/R branch line.

3. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check the power supply and the ground circuit of the IPDM E/R. Refer to [PG-3, "Schematic"](#).

OK or NG

OK >> • Present error: Replace the IPDM E/R. Refer to [PG-28, "Removal and Installation of IPDM E/R"](#).
 • Past error: Error was detected in the IPDM E/R branch line.

NG >> Repair the power supply and the ground circuit.

CAN Communication Circuit

INFOID:0000000003533660

INSPECTION PROCEDURE

1. CONNECTOR INSPECTION

1. Turn the ignition switch OFF
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.
4. Check terminals and connectors for damage, bend and loose connection.

OK or NG

OK >> GO TO 2.

NG >> Repair the terminal and connector.

2. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector terminals.

Data link connector			Continuity
Connector No.	Terminal No.		
M22	6	14	No

OK or NG

OK >> GO TO 3.

NG >> Check the harness and repair the root cause.

3. CHECK HARNESS CONTINUITY (SHORT CIRCUIT)

Check the continuity between the data link connector and the ground.

Data link connector		Ground	Continuity
Connector No.	Terminal No.		
M22	6	Ground	No
	14		No

OK or NG

OK >> GO TO 4.


NG >> Check the harness and repair the root cause.

4. CHECK ECM AND IPDM E/R TERMINATION CIRCUIT

1. Remove the ECM and the IPDM E/R.
2. Check the resistance between the ECM terminals.

ECM		Resistance (Ω)
Terminal No.		
94	86	Approx. 108 – 132

3. Check the resistance between the IPDM E/R terminals.



TROUBLE DIAGNOSIS

< SERVICE INFORMATION >

[CAN]

IPDM E/R		Resistance (Ω)
Terminal No.		
39	40	Approx. 108 – 132

OK or NG

OK >> GO TO 5.

NG >> Replace the ECM and/or the IPDM E/R.

5.CHECK SYMPTOM

Connect all the connectors. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

Inspection result

Reproduced>>GO TO 6.

Non-reproduced>>Start the diagnosis again. Follow the trouble diagnosis procedure when past error is detected.

6.CHECK UNIT REPRODUCTION

Perform the reproduction test as per the following procedure for each unit.

1. Turn the ignition switch OFF
2. Disconnect the battery cable from the negative terminal.
3. Disconnect all the unit connectors on CAN communication system.

NOTE:

ECM and IPDM E/R have a termination circuit. Check other units first.

4. Connect the battery cable to the negative terminal. Check if the symptoms described in the “Symptom (Results from interview with customer)” are reproduced.

NOTE:

Although unit-related error symptoms occur, do not confuse them with other symptoms.

Inspection result

Reproduced>>Connect the connector. Check other units as per the above procedure.

Non-reproduced>>Replace unit whose connector was disconnected.