

A
B
C
D
E

SECTION **BRC**

BRAKE CONTROL SYSTEM

CONTENTS

		BRC
WITH VDC		
PRECAUTION	TCS FUNCTION	
PRECAUTIONS	TCS FUNCTION : System Diagram	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"	TCS FUNCTION : System Description	
Precaution for Brake System	ABS FUNCTION	
Precaution for Brake Control System	ABS FUNCTION : System Diagram	
Precaution for Harness Repair	ABS FUNCTION : System Description	
PREPARATION	EBD FUNCTION	
PREPARATION	EBD FUNCTION : System Diagram	
Special Service Tool	EBD FUNCTION : System Description	
Commercial Service Tools	HILL START ASSIST FUNCTION	
SYSTEM DESCRIPTION	Hill start assist FUNCTION : System Diagram	
COMPONENT PARTS	Hill start assist FUNCTION : System Description	
Component Parts Location	ACTIVE STABILITY ASSIST	
Component Description	ACTIVE STABILITY ASSIST : System Diagram	
ABS Actuator and Electric Unit (Control Unit)	ACTIVE STABILITY ASSIST : System Description	
Wheel Sensor and Sensor Rotor	
Stop Lamp Switch	ACTIVE STABILITY ASSIST : Active Trace Control Function	
Steering Angle Sensor	ACTIVE STABILITY ASSIST : Brake Force Distribution Function	
Yaw Rate/Side/Decel G Sensor	DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]	
Brake Fluid Level Switch	CONSULT Function	
Vacuum Sensor	ECU DIAGNOSIS INFORMATION	
Parking Brake Switch	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)	
ADAS Control Unit	Reference Value	
VDC OFF Switch	Fail-Safe	
SYSTEM	DTC Inspection Priority Chart	
System Diagram	DTC Index	
System Description	ADAS CONTROL UNIT	
Fail-Safe	List of ECU Reference	
VDC FUNCTION	WIRING DIAGRAM	
VDC FUNCTION : System Diagram		
VDC FUNCTION : System Description		

BRAKE CONTROL SYSTEM	49	Diagnosis Procedure	81
Wiring Diagram	49		
BASIC INSPECTION	57	C1130 ENGINE SIGNAL	83
DIAGNOSIS AND REPAIR WORKFLOW	57	DTC Logic	83
Work Flow	57	Diagnosis Procedure	83
Diagnostic Work Sheet	58	C1140 ACTUATOR RELAY SYSTEM	84
ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)	59	DTC Logic	84
Description	59	Diagnosis Procedure	84
Work Procedure	59	C1142 PRESS SENSOR	86
ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION	60	DTC Logic	86
Description	60	Diagnosis Procedure	86
Work Procedure	60	C1143 STEERING ANGLE SENSOR	88
CALIBRATION OF DECEL G SENSOR	62	DTC Logic	88
Description	62	Diagnosis Procedure	88
Work Procedure	62	C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT	90
DTC/CIRCUIT DIAGNOSIS	64	DTC Logic	90
C1101, C1102, C1103, C1104 WHEEL SENSOR	64	Diagnosis Procedure	90
DTC Logic	64	C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR	91
Diagnosis Procedure	64	DTC Logic	91
C1105, C1106, C1107, C1108 WHEEL SENSOR	68	Diagnosis Procedure	91
DTC Logic	68	C1155 BRAKE FLUID LEVEL SWITCH	94
Diagnosis Procedure	68	DTC Logic	94
C1109 POWER AND GROUND SYSTEM	70	Diagnosis Procedure	94
DTC Logic	70	Component Inspection	95
Diagnosis Procedure	70	C1160 DECEL G SEN SET	96
C1111 PUMP MOTOR	72	DTC Logic	96
DTC Logic	72	Diagnosis Procedure	96
Diagnosis Procedure	72	C1164, C1165 CV SYSTEM	97
C1115 ABS SENSOR [ABNORMAL SIGNAL] ..	74	DTC Logic	97
DTC Logic	74	Diagnosis Procedure	97
Diagnosis Procedure	74	C1170 VARIANT CODING	99
C1116 STOP LAMP SWITCH	76	DTC Logic	99
DTC Logic	76	Diagnosis Procedure	99
Diagnosis Procedure	76	C1197 VACUUM SENSOR	100
Component Inspection	78	DTC Logic	100
C1120, C1122, C1124, C1126 ABS IN VALVE SYSTEM	79	Diagnosis Procedure	100
DTC Logic	79	C1198 VACUUM SENSOR	102
Diagnosis Procedure	79	DTC Logic	102
C1121, C1123, C1125, C1127 ABS OUT VALVE SYSTEM	81	Diagnosis Procedure	102
DTC Logic	81	C1199 BRAKE BOOSTER	104
		DTC Logic	104
		Diagnosis Procedure	104
		C119A VACUUM SENSOR	106
		DTC Logic	106
		Diagnosis Procedure	106
		U1000 CAN COMM CIRCUIT	108

Description	108	VEHICLE JERKS DURING VDC/TCS/ABS CONTROL	123	A
DTC Logic	108	Description	123	
Diagnosis Procedure	108	Diagnosis Procedure	123	
U0424 HVAC CAN CIRCUIT 1	109	NORMAL OPERATING CONDITION	124	B
Description	109	Description	124	
DTC Logic	109	UNIT REMOVAL AND INSTALLATION ...	125	C
Diagnosis Procedure	109	WHEEL SENSOR	125	
PARKING BRAKE SWITCH	110	Exploded View - Front Wheel Sensor	125	D
Component Function Check	110	Removal and Installation - Front Wheel Sensor ...	125	
Diagnosis Procedure	110	Exploded View - Rear Wheel Sensor	126	E
Component Inspection	110	Removal and Installation - Rear Wheel Sensor	127	
VDC OFF SWITCH	111	SENSOR ROTOR	129	
Component Function Check	111	Removal and Installation - Front Sensor Rotor	129	
Diagnosis Procedure	111	Removal and Installation - Rear Sensor Rotor	129	
Component Inspection	112	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)	130	BRC
ABS WARNING LAMP	113	Exploded View	130	G
Component Function Check	113	Removal and Installation	130	
Diagnosis Procedure	113	YAW RATE/SIDE/DECEL G SENSOR	132	H
BRAKE WARNING LAMP	114	Exploded View	132	
Component Function Check	114	Removal and Installation	132	
Diagnosis Procedure	114	STEERING ANGLE SENSOR	133	I
VDC OFF INDICATOR LAMP	115	Removal and Installation	133	
Component Function Check	115	BRAKE ASSIST (WITH PREVIEW FUNCTION)		J
Diagnosis Procedure	115	PRECAUTION	134	
SLIP INDICATOR LAMP	116	PRECAUTIONS	134	K
Component Function Check	116	Precautions for Preview Function Service	134	
Diagnosis Procedure	116	SYSTEM DESCRIPTION	135	L
SYMPTOM DIAGNOSIS	117	COMPONENT PARTS	135	
VDC/TCS/ABS	117	Component Parts Location	135	M
Symptom Table	117	Component Description	136	
EXCESSIVE OPERATION FREQUENCY	118	SYSTEM	138	N
Description	118	BRAKE ASSIST (WITH PREVIEW FUNCTION)	138	
Diagnosis Procedure	118	BRAKE ASSIST (WITH PREVIEW FUNCTION) :		O
UNEXPECTED BRAKE PEDAL REACTION ..	119	System Description	138	
Description	119	DTC/CIRCUIT DIAGNOSIS	139	
Diagnosis Procedure	119	BRAKE ASSIST (WITH PREVIEW FUNCTION)	139	P
THE BRAKING DISTANCE IS LONG	120	Diagnosis Procedure	139	
Description	120	SYMPTOM DIAGNOSIS	140	
Diagnosis Procedure	120	NORMAL OPERATING CONDITION	140	
ABS FUNCTION DOES NOT OPERATE	121	Description	140	
Description	121	INTELLIGENT BRAKE ASSIST		
Diagnosis Procedure	121			
BRAKE PEDAL VIBRATION OR OPERATION SOUND OCCURS	122			
Description	122			
Diagnosis Procedure	122			

PRECAUTION	141	DTC/CIRCUIT DIAGNOSIS	146
PRECAUTIONS	141	INTELLIGENT BRAKE ASSIST	146
Precautions for IBA System Service	141	Diagnosis Procedure	146
SYSTEM DESCRIPTION	142	SYMPTOM DIAGNOSIS	147
COMPONENT PARTS	142	SWITCH DOES NOT TURN ON / SWITCH	
Component Parts Location	142	DOES NOT TURN OFF	147
Component Description	143	Symptom Table	147
SYSTEM	145	Description	147
INTELLIGENT BRAKE ASSIST	145	Diagnosis Procedure	147
INTELLIGENT BRAKE ASSIST : System Description	145	NORMAL OPERATING CONDITION	149
		Description	149

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009729280

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes dual stage front air bag modules. The SRS system may only deploy one front air bag, depending on the severity of a collision and whether the front passenger seat is occupied. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.


Precaution for Brake System

INFOID:000000009134624

WARNING:

Clean any dust from the front brake and rear brake using a vacuum dust collector. Do not blow by compressed air.

- Brake fluid use refer to [MA-15. "FOR USA AND CANADA : Fluids and Lubricants"](#) (United States and Canada) or [MA-16. "FOR MEXICO : Fluids and Lubricants"](#) (Mexico).
- Do not reuse drained brake fluid.
- Do not spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Always confirm the specified tightening torque when installing the brake pipes.
- After pressing the brake pedal more deeply or harder than normal driving, such as air bleeding, check each item of brake pedal. Adjust brake pedal if it is outside the standard value.
- Do not use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with a crow-foot (A) and torque wrench (B).
- Always connect the battery terminal when moving the vehicle.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



PRECAUTIONS

< PRECAUTION >

[WITH VDC]

Precaution for Brake Control System


INFOID:000000009134625

- Just after starting vehicle after ignition switch is ON, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is a normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for simple causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level and oil leaks.
- If tire size and type are used in an improper combination or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.
- VDC system may not operate normally or a VDC OFF indicator lamp or SLIP indicator lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.


Precaution for Harness Repair

INFOID:000000009134626

- Solder the repair part, and wrap it with tape. [Twisted wire fray must be 110 mm (4.33 in) or less.]



- Do not bypass the repair point with wire. (If it is bypassed, the turn-out point cannot be separated and the twisted wire characteristics are lost.)



PREPARATION

< PREPARATION >

[WITH VDC]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000009134627

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.



Tool number (Kent-Moore No.) Tool name	Description
KV991J0080 (J-45741) ABS active wheel sensor tester	Checking operation of ABS active wheel sensors



Commercial Service Tools

INFOID:000000009134628

Tool name	Description
1. Flare nut crowfoot 2. Torque wrench	Removing and installing brake piping a: 10 mm (0.39 in)/12 mm (0.47 in)
Power tool	Loosening nuts, screws and bolts



A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

COMPONENT PARTS

[WITH VDC]


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009134629



AWFIA1027GB

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[WITH VDC]

- | | | | |
|--|--|--|---|
| 1. IPDM E/R | 2. ABS actuator and electric unit (control unit) | 3. Brake fluid level switch (part of brake fluid reservoir) | A |
| 4. Vacuum sensor (attached to lower side of brake booster) | 5. Front wheel sensor LH (RH similar) | 6. Rear wheel sensor LH (RH similar) | B |
| 7. VDC OFF switch | 8. Steering angle sensor (view with steering wheel and steering column covers removed) | 9. Yaw rate/side/decel G sensor (view with the center console removed) | B |
| 10. Stop lamp switch | 11. Combination meter | 12. Parking brake switch | C |
| 13. ADAS control unit (view of rear luggage room area) | | | C |

Component Description

INFOID:000000009134630

Component		Reference/Function	
ABS actuator and electric unit (control unit)	Pump/motor	BRC-9. "ABS Actuator and Electric Unit (Control Unit)"	G
	Motor relay		
	Actuator relay (main relay)		
	ABS IN valve		
	ABS OUT valve		
	Cut valve 1		
	Cut valve 2		
	Pressure sensor		
Wheel sensor	BRC-10. "Wheel Sensor and Sensor Rotor"		
Stop lamp switch	BRC-10. "Stop Lamp Switch"	I	
Steering angle sensor	BRC-10. "Steering Angle Sensor"		
Yaw rate/side/decel G sensor	BRC-10. "Yaw Rate/Side/Decel G Sensor"	J	
Vacuum sensor	BRC-11. "Vacuum Sensor"		
Brake fluid level switch	BRC-11. "Brake Fluid Level Switch"		
Parking brake switch	BRC-11. "Parking Brake Switch"	K	
VDC OFF switch	BRC-11. "VDC OFF Switch"		
ECM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> Accelerator pedal position signal Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> Target throttle position signal 	L	
TCM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> Shift position signal Current gear position signal 	M	
ABS warning lamp	BRC-12. "System Description"	O	
Brake warning lamp			
VDC OFF indicator lamp			
SLIP indicator lamp			
ADAS control unit (if equipped)			BRC-11. "ADAS Control Unit"

ABS Actuator and Electric Unit (Control Unit)

INFOID:000000009134631

Electric unit (control unit) is integrated with actuator and motor/accumulator assembly and comprehensively controls VDC function, TCS function, ABS function and EBD function.

COMPONENT PARTS

[WITH VDC]

< SYSTEM DESCRIPTION >

ELECTRIC UNIT (CONTROL UNIT)

- Brake fluid pressure, engine and transmission are controlled according to signals from each sensor.
- If malfunction is detected, the system enters fail-safe mode.

ACTUATOR

The following components are integrated with ABS actuator.

Pump

Returns the brake fluid reserved in reservoir to master cylinder by reducing pressure.

Motor

Activates the pump according to signals from ABS actuator and electric unit (control unit).

Motor Relay

Operates the motor ON/OFF according to signals from ABS actuator and electric unit (control unit).

Actuator Relay

Operates each valve ON/OFF according to signals from ABS actuator and electric unit (control unit).

ABS IN Valve and ABS OUT Valve

Increases, holds or decreases the fluid pressure of each caliper according to signals from ABS actuator and electric unit (control unit).

Pressure Sensor

Detects the brake fluid pressure and transmits signal to ABS actuator and electric unit (control unit).

Cut Valve 1 (Primary Line), Cut Valve 2 (Secondary Line)


Shuts off the ordinary brake line from master cylinder when VDC function, TCS function, hill start assist function and brake force distribution function are activated.

Wheel Sensor and Sensor Rotor

INFOID:000000009134632

NOTE:

- Wheel sensor and sensor rotor is integrated in wheel hub assembly.
- Never measure resistance and voltage value using a tester because sensor is active sensor.
- Downsize and weight reduction is aimed. IC for detection portion and magnet for sensor rotor are adopted.
- Power supply is supplied to detection portion so that magnetic field line is read. Magnetic field that is detected is converted to current signal.
- When sensor rotor rotates, magnetic field changes. Magnetic field change is converted to current signals (rectangular wave) and is transmitted to ABS actuator and electric unit (control unit). Change of magnetic field is proportional to wheel speed.



Stop Lamp Switch

INFOID:000000009134633

Detects the operation status of brake pedal and transmits converted electric signal to ABS actuator and electric unit (control unit).

Steering Angle Sensor

INFOID:000000009134634

Detects the following information and transmits steering angle signal to ABS actuator and electric unit (control unit) via CAN communication:

- Steering wheel rotation amount
- Steering wheel rotation angular velocity
- Steering wheel rotation direction

Yaw Rate/Side/Decel G Sensor

INFOID:000000009134635

Calculates the following information that affects the vehicle and transmits a signal to ABS actuator and electric unit (control unit) via communication lines:

- Vehicle rotation angular velocity (yaw rate signal)

COMPONENT PARTS

[WITH VDC]

< SYSTEM DESCRIPTION >

- Vehicle lateral acceleration (side G signal) / longitudinal acceleration (decel G signal)

Brake Fluid Level Switch

INFOID:000000009134636

Detects the brake fluid level in reservoir tank and transmits converted electric signal from ABS actuator and electric unit (control unit) when brake fluid level is the specified level or less.

Vacuum Sensor

INFOID:000000009134637

Detects the vacuum in brake booster and transmits converted electric signal to ABS actuator and electric unit (control unit).

Parking Brake Switch

INFOID:000000009134638

Detects the operation status of parking brake switch and transmits converted electric signal from combination meter to ABS actuator and electric unit (control unit).

ADAS Control Unit

INFOID:000000009134639

Controls Active trace control function in ADAS control unit and transmits Active trace control signal to ABS actuator and electric unit (control unit) via CAN communication.

NOTE:

Models with ICC system

VDC OFF Switch

INFOID:000000009134640


- This is an integrated switch with switches for other functions.
- Non-operational status or standby status of the following functions can be selected using VDC OFF switch. VDC OFF indicator lamp indicates the operation status of function. (ON: Non-operational status, OFF: Standby status)
 - VDC function
- **NOTE:**
 - Brake limited slip differential (BLSD) control operates.
 - TCS function
 - Active trace control function
- VDC OFF indicator lamp turns OFF (standby status) when the engine is started again after it is stopped once while VDC OFF indicator lamp is ON (non-operational status).

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

SYSTEM

System Diagram

INFOID:000000009134641



AWFIA1028GB

System Description

INFOID:000000009134642

- The system switches fluid pressure of each brake caliper to increase, to hold or to decrease according to signals from control unit in ABS actuator and electric unit (control unit). This control system is applied to VDC function, TCS function, ABS function, EBD function, hill start assist function, Brake force distribution function and Active trace control function.
- Fail-safe function is available for each function and is activated by each function when system malfunction occurs.

INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

VDC function, TCS function, ABS function, EBD function and Brake force distribution function

Component	Signal description
Yaw rate/side/decel G sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via communication line*1: <ul style="list-style-type: none"> • Yaw rate signal • Side G sensor signal • Decel G sensor signal
ECM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Accelerator pedal position signal • Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> • Target throttle position signal
TCM	Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Shift position signal

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

Component	Signal description
Steering angle sensor	Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> • Steering angle sensor signal
Combination meter	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Brake fluid level switch signal • Parking brake switch signal Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • ABS warning lamp signal • Brake warning lamp signal • VDC warning lamp signal • VDC OFF indicator lamp

A
B
C
D
E

*1: Communication line between yaw rate/side/decel G sensor and ABS actuator and electric unit (control unit)

Active trace control function

Component	Signal description
ADAS control unit	Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Active trace control signal
ECM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Accelerator pedal position signal • Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Target throttle position signal
ABS actuator and electric unit (control unit)	Mainly transmits the following signals to ADAS control unit via CAN communication: <ul style="list-style-type: none"> • Vehicle speed signal (ABS) • Stop lamp switch signal (brake signal) • VDC OFF switch signal • Yaw rate signal • Side G sensor signal • Decel G sensor signal
Yaw rate/side/decel G sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via communication line *: <ul style="list-style-type: none"> • Yaw rate signal • Side G sensor signal • Decel G sensor signal
Drive mode select switch	Outputs ON/OFF status of STANDARD, SPORT, ECO, SNOW mode to A/C auto AMP.
A/C auto AMP.	Mainly transmits the following signal to ADAS control unit via CAN communication: <ul style="list-style-type: none"> • Drive mode select switch signal
Steering angle sensor	Mainly transmits the following signal to ADAS control unit via CAN communication: <ul style="list-style-type: none"> • Steering angle sensor signal
Combination meter	Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • VDC OFF indicator lamp signal • VDC warning lamp signal Mainly receives the following signal from ADAS control unit via CAN communication: <ul style="list-style-type: none"> • IBA warning lamp signal

BRC
G
H
I
J
K
L
M
N
O
P

*: Communication line between yaw rate/side/decel G sensor and ABS actuator and electric unit (control unit)

VALVE OPERATION (ABS AND EBD)


Each valve is operated and fluid pressure of brake caliper is controlled.

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

When ordinary brake is applied and ABS is in operation (when pressure increases).



Name	Not activated	When Pressure Increases
Cut valve 1	Power supply is not supplied (open)	Power supply is not supplied (open)
Cut valve 2	Power supply is not supplied (open)	Power supply is not supplied (open)
ABS IN valve	Power supply is not supplied (open)	Power supply is not supplied (open)
ABS OUT valve	Power supply is not supplied (close)	Power supply is not supplied (close)
Each caliper (fluid pressure)	—	Pressure increases

When front RH wheel caliper pressure increases

- Motor is activated. Brake fluid is pressurized by pump and is sent to secondary line through cut valve 2. At the same time, pressurized brake fluid is supplied to front RH caliper through ABS IN valve.

When front LH wheel caliper pressure increases

- Motor is activated. Brake fluid is pressurized by pump and is sent to primary line through cut valve 1. At the same time, pressurized brake fluid is supplied to front LH wheel caliper through ABS IN valve.

When rear RH wheel caliper pressure increases

- Motor is activated. Brake fluid is pressurized by pump and is sent to primary line through cut valve 1. At the same time, pressurized brake fluid is supplied to rear RH wheel caliper through ABS IN valve.

When rear LH wheel caliper pressure increases


- Motor is activated. Brake fluid is pressurized by pump and is sent to secondary line through cut valve 2. At the same time, pressurized brake fluid is supplied to rear LH wheel caliper through ABS IN valve.

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

When ABS operation starts (when pressure holds)



Name	Not activated	When pressure holds
Cut valve 1	Power supply is not supplied (open)	Power supply is not supplied (open)
Cut valve 2	Power supply is not supplied (open)	Power supply is not supplied (open)
ABS IN valve	Power supply is not supplied (open)	Power supply is supplied (close)
ABS OUT valve	Power supply is not supplied (close)	Power supply is not supplied (close)
Each caliper (fluid pressure)	—	Pressure holds

When front RH wheel caliper pressure holds

- Motor is activated. Brake fluid is pressurized by pump and is sent to secondary line through cut valve 2. At the same time, because ABS IN valve and ABS OUT valve are closed, fluid pressure holds.

When front LH wheel caliper pressure holds

- Motor is activated. Brake fluid is pressurized by pump and is sent to primary line through cut valve 1. At the same time, because ABS IN valve and ABS OUT valve are closed, fluid pressure holds.

When rear RH wheel caliper pressure holds

- Motor is activated. Brake fluid is pressurized by pump and is sent to primary line through cut valve 1. At the same time, because ABS IN valve and ABS OUT valve are closed, fluid pressure holds.

When rear LH wheel caliper pressure holds


- Motor is activated. Brake fluid is pressurized by pump and is sent to secondary line through cut valve 2. At the same time, because ABS IN valve and ABS OUT valve are closed, fluid pressure holds.

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

ABS is in operation (when pressure decreases)



Name	Not activated	When pressure decreases
Cut valve 1	Power supply is not supplied (open)	Power supply is not supplied (open)
Cut valve 2	Power supply is not supplied (open)	Power supply is not supplied (open)
ABS IN valve	Power supply is not supplied (open)	Power supply is supplied (close)
ABS OUT valve	Power supply is not supplied (close)	Power supply is supplied (open)
Each caliper (fluid pressure)	—	Pressure decreases

When front RH wheel caliper pressure decreases

- Being supplied to reservoir through ABS OUT valve, the fluid pressure of brake caliper is decreased.

When front LH wheel caliper pressure decreases

- Being supplied to reservoir through ABS OUT valve, the fluid pressure of brake caliper is decreased.

When rear RH wheel caliper pressure decreases

- Being supplied to reservoir through ABS OUT valve, the fluid pressure of brake caliper is decreased.

When rear LH wheel caliper pressure decreases

- Being supplied to reservoir through ABS OUT valve, the fluid pressure of brake caliper is decreased.

Component Parts and Function

Component	FUNCTION
Reservoir	Temporarily reserves the brake fluid drained from brake caliper, so that pressure efficiently decreases when decreasing pressure of brake caliper.
Pump	Returns the brake fluid reserved in reservoir to master cylinder by reducing pressure.
Motor	Drives the pump according to signals from control unit.
ABS IN valve	Switches the fluid pressure line to increase or hold according to signals from control unit.

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

Component	FUNCTION
ABS OUT valve	Switches the fluid pressure line to increase, hold or decrease according to signals from control unit.
Return check valve	Returns the brake fluid from brake caliper to master cylinder by bypassing orifice of each valve when brake is released.
Cut valve 1 Cut valve 2	Performs the duty control of fluid pressure increased by pump according to signals from control unit.
Pressure Sensor	Detects the brake pedal operation amount.


VALVE OPERATION (OTHER THAN ABS AND EBD)

Each valve is operated and fluid pressure of brake caliper is controlled.

NOTE:

There is no operation to hold and increase pressure for functions other than ABS and EBD.

When Pressure Increases



Name	Not activated	When Pressure Increases
Cut valve 1	Power supply is not supplied (open)	Wheel other than the one that the pressure is to be increased: Power supply is not supplied (open) Only wheel that the pressure is to be increased: Power supply is supplied (close)
Cut valve 2	Power supply is not supplied (open)	Wheel other than the one that the pressure is to be increased: Power supply is not supplied (open) Only wheel that the pressure is to be increased: Power supply is supplied (close)

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

Name	Not activated	When Pressure Increases
ABS IN valve	Power supply is not supplied (open)	Only wheel that the pressure is to be increased: Power supply is not supplied (open) Wheel other than the one that the pressure is to be increased: Power supply is supplied (close)
ABS OUT valve	Power supply is not supplied (close)	Power supply is not supplied (close)
Each caliper (fluid pressure)	—	Pressure increases

When front RH wheel caliper pressure increases

- Motor is activated. Brake fluid from pump is supplied to front RH wheel caliper through ABS IN valve. For other wheel, ABS IN valve is closed and brakes fluid is not supplied to caliper.

When front LH wheel caliper pressure increases

- Motor is activated. Brake fluid from pump is supplied to front LH wheel caliper through ABS IN valve. For other wheel, ABS IN valve is closed and brakes fluid is not supplied to caliper.


When rear RH wheel caliper pressure increases

- Motor is activated. Brake fluid from pump is supplied to front RH wheel caliper through ABS IN valve. For other wheel, ABS IN valve is closed and brakes fluid is not supplied to caliper.

When rear LH wheel caliper pressure increases

- Motor is activated. Brake fluid from pump is supplied to front LH wheel caliper through ABS IN valve. For other wheel, ABS IN valve is closed and brakes fluid is not supplied to caliper.

Released



SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

Name	Not activated	When pressure decreases
Cut valve 1	Power supply is not supplied (open)	Power supply is not supplied (open)
Cut valve 2	Power supply is not supplied (open)	Power supply is not supplied (open)
ABS IN valve	Power supply is not supplied (open)	Power supply is not supplied (open)
ABS OUT valve	Power supply is not supplied (close)	Power supply is supplied (open)
Each caliper (fluid pressure)	—	Pressure decreases

When front RH wheel caliper pressure decreases

- Being returned to master cylinder through ABS IN valve, fluid pressure of brake caliper is decreased.

When front LH wheel caliper pressure decreases

- Being returned to master cylinder through ABS IN valve, fluid pressure of brake caliper is decreased.

When rear RH wheel caliper pressure decreases

- Being returned to master cylinder through ABS IN valve, fluid pressure of brake caliper is decreased.

When rear LH wheel caliper pressure decreases

- Being returned to master cylinder through ABS IN valve, fluid pressure of brake caliper is decreased.

Component Parts and Function

Component	Function
Reservoir	Temporarily reserves the brake fluid drained from brake caliper so that pressure efficiently decreases when decreasing pressure of brake caliper.
Pump	Returns the brake fluid reserved in reservoir to master cylinder by reducing pressure.
Motor	Drives the pump according to signals from control unit.
ABS IN valve	Switches the fluid pressure line to increase or hold according to signals from control unit.
ABS OUT valve	Switches the fluid pressure line to increase, hold or decrease according to signals from control unit.
Return check valve	Returns the brake fluid from brake caliper to master cylinder by bypassing orifice of each valve when brake is released.
Cut valve 1 Cut valve 2	Performs the duty control of fluid pressure increased by pump according to signals from control unit.
Pressure Sensor	Detects the brake pedal operation amount.

CONDITION FOR TURN ON THE WARNING LAMP

ABS Warning Lamp

- Turns ON at the same time as VDC warning lamp when either ABS function or EBD function is malfunctioning.
- Turns ON when ignition switch turns ON and turns OFF when the system is normal, for bulb check purposes.

Condition (status)	ABS warning lamp
Ignition switch OFF	OFF
For approx. 1 second after the ignition switch is turned ON	ON
Approx. 1 second after ignition switch is turned ON (when the system is in normal operation)	OFF
ABS function is malfunctioning	ON
EBD function is malfunctioning	ON

Brake Warning Lamp

- Turns ON at the same time as ABS warning lamp and VDC warning lamp when EBD function is malfunctioning.
- Turns ON when ignition switch turns ON and turns OFF when the system is normal for bulb check purposes.

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

Condition (status)	Brake warning lamp
Ignition switch OFF	OFF
For approx. 1 seconds after the ignition switch is turned ON	ON
Approx. 1 second after ignition switch is turned ON (when the system is in normal operation)	OFF
After engine starts	OFF
When parking brake operates (parking brake switch ON)	ON
When brake booster vacuum decreases	ON
When vacuum sensor is malfunctioning	ON
When brake fluid is less than the specified level (brake fluid level switch ON)	ON
ABS function is malfunctioning	OFF
EBD function is malfunctioning	ON

VDC Warning Lamp

- Turns ON when either VDC function, TCS function, ABS function or EBD function is malfunctioning.
- Turns ON when ignition switch turns ON and turns OFF when the system is normal for bulb check purposes.

Condition (status)	VDC warning lamp
Ignition switch OFF	OFF
For approx. 1 second after the ignition switch is turned ON	ON
Approx. 1 second after ignition switch is turned ON (when the system is in normal operation)	OFF
VDC function is malfunctioning	ON
TCS function is malfunctioning	ON
ABS function is malfunctioning	ON
EBD function is malfunctioning	ON
VDC function is operating	Blinking
TCS function is operating	Blinking

IBA OFF indicator lamp

- Turns ON when Active trace control function is malfunctioning.

NOTE:

Lamp ON condition of intelligent brake assistance OFF indicator lamp is that intelligent brake assistance OFF switch is in the pressed and not turned ON status.

CONDITIONS FOR TURNING ON THE INDICATOR LAMP

VDC OFF indicator lamp

- Turns ON when VDC function and TCS function are switched to non-operational status (OFF) by VDC OFF switch.
- Turns ON when ignition switch turns ON and turns OFF when the system is normal for bulb check purposes.

Condition (status)	VDC OFF indicator lamp
Ignition switch OFF	OFF
For approx. 1 second after the ignition switch is turned ON	ON
Approx. 1 second after ignition switch is turned ON (when the system is in normal operation)	OFF
When VDC OFF switch is ON (VDC function, TCS function and Active trace control function are OFF)	ON

Fail-Safe

INFOID:000000009134643

VDC FUNCTION, TCS FUNCTION, hill start assist FUNCTION AND BRAKE FORCE DISTRIBUTION

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

FUNCTION FUNCTION

VDC warning lamp in combination meter turns ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, hill start assist function and Brake force distribution function. The vehicle status becomes the same as models without VDC function, TCS function, hill start assist function and Brake force distribution function. However, ABS function and EBD function are operated normally.

ABS FUNCTION

ABS warning lamp and VDC warning lamp in combination meter turn ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, ABS function, hill start assist function and Brake force distribution function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, hill start assist function and Brake force distribution function. However, EBD function is operated normally.

NOTE:

ABS self-diagnosis sound may be heard the same as in the normal condition because self-diagnosis is performed when ignition switch turns ON and when vehicle initially starts.

EBD FUNCTION

ABS warning lamp, brake warning lamp and VDC warning lamp in combination meter turn ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, ABS function, EBD function, hill start assist function and Brake force distribution function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, EBD function, hill start assist function and Brake force distribution function.

ACTIVE TRACE CONTROL FUNCTION

Intelligent brake assistance OFF indicator lamp turns ON when a malfunction occurs in the system [ABS actuator and electric unit (control unit)]. The control is suspended for Active trace control function. The vehicle becomes the same as models without Active trace control function.

CAUTION:

Lamp ON condition of intelligent brake assistance OFF indicator lamp is that intelligent brake assistance OFF switch is in the pressed and not turned ON status.

Mode is fixed to the mode when a malfunction occurs if CAN communication malfunction (DTC "U1000", DTC "U1010" "U0424") occurs between ADAS control unit and A/C auto AMP. The mode is fixed to STANDARD mode after ignition switch turns OFF to ON.

DTC	Malfunction detected condition	Fail-safe condition
C1101	When an open circuit is detected in rear RH wheel sensor circuit.	The following functions are suspended: • VDC function • TCS function • ABS function • EBD function (only when both 2 rear wheels are malfunctioning) • hill start assist function • Brake force distribution function
C1102	When an open circuit is detected in rear LH wheel sensor circuit.	
C1103	When an open circuit is detected in front RH wheel sensor circuit.	
C1104	When an open circuit is detected in front LH wheel sensor circuit.	
C1105	<ul style="list-style-type: none"> When power supply voltage of rear RH wheel sensor is low. When distance between rear RH wheel sensor and rear RH wheel sensor rotor is large. When installation of rear RH wheel sensor or rear RH wheel sensor rotor is not normal. 	
C1106	<ul style="list-style-type: none"> When power supply voltage of rear LH wheel sensor is low. When distance between rear LH wheel sensor and rear LH wheel sensor rotor is large. When installation of rear LH wheel sensor or rear LH wheel sensor rotor is not normal. 	
C1107	<ul style="list-style-type: none"> When power supply voltage of front RH wheel sensor is low. When distance between front RH wheel sensor and front RH wheel sensor rotor is large. When installation of front RH wheel sensor or front RH wheel sensor rotor is not normal. 	
C1108	<ul style="list-style-type: none"> When power supply voltage of front LH wheel sensor is low. When distance between front LH wheel sensor and front LH wheel sensor rotor is large. When installation of front LH wheel sensor or front LH wheel sensor rotor is not normal. 	

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

DTC	Malfunction detected condition	Fail-safe condition
C1109	<ul style="list-style-type: none"> • When ignition voltage is 10 V or less. • When ignition voltage is 16 V or more. 	The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function
C1111	When a malfunction is detected in motor or motor relay.	
C1115	When difference in wheel speed between any wheel and others is detected during the vehicle is driven, because of installation of other tires than specified.	The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • hill start assist function • Brake force distribution function
C1116	When stop lamp switch signal is not input when brake pedal operates.	
C1120	When a malfunction is detected in front LH ABS IN valve.	The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function
C1121	When a malfunction is detected in front LH ABS OUT valve.	
C1122	When a malfunction is detected in front RH ABS IN valve.	
C1123	When a malfunction is detected in front RH ABS OUT valve.	
C1124	When a malfunction is detected in rear LH ABS IN valve.	
C1125	When a malfunction is detected in rear LH ABS OUT valve.	
C1126	When a malfunction is detected in rear RH ABS IN valve.	
C1127	When a malfunction is detected in rear RH ABS OUT valve.	
C1130	When a malfunction is detected in ECM system.	The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • hill start assist function • Brake force distribution function
C1140	When a malfunction is detected in actuator relay.	The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function
C1142	When a malfunction is detected in pressure sensor.	The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • hill start assist function • Brake force distribution function
C1143	When a malfunction is detected in steering angle sensor.	
C1144	When neutral position adjustment of steering angle sensor is not complete.	
C1145	When a malfunction is detected in yaw rate signal.	
C1146	When a malfunction is detected in side/decel G signal.	The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • hill start assist function • Brake force distribution function
C1155	When brake fluid level low signal is detected.	
C1160	When calibration of yaw rate/side/decel G sensor is not complete.	The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • hill start assist function • Brake force distribution function

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]


DTC	Malfunction detected condition	Fail-safe condition
C1164	When a malfunction is detected in cut valve 1.	The following functions are suspended: • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function
C1165	When a malfunction is detected in cut valve 2.	
C1170	When the information in ABS actuator and electric unit (control unit) is not the same.	
C1197	When a malfunction is detected in vacuum sensor.	Electrical vacuum assistance of brake booster is suspended.
C1198	<ul style="list-style-type: none"> • When an open circuit is detected in vacuum sensor circuit. • When a short circuit is detected in vacuum sensor circuit. • When a malfunction is detected in vacuum sensor noise. 	
C1199	When brake booster vacuum is approx. 0 kPa (0 mmHg) during engine running.	
C119A	When a malfunction is detected in supply power voltage of vacuum sensor.	Electrical vacuum assistance of brake booster is suspended.
U1000	When CAN communication signal is not continuously received for 2 seconds or more.	The following functions are suspended: • VDC function • TCS function • hill start assist function • Brake force distribution function
U0424*	When signal that is transmitted from A/C auto AMP. is not the latest information.	Mode is fixed to the mode when a malfunction of drive mode selector occurs. The mode is fixed to STAN-DARD mode after ignition switch turns OFF to ON.

*: This is DTC that is detected in ADAS control unit side.

VDC FUNCTION

VDC FUNCTION : System Diagram


INFOID:000000009134644



VDC FUNCTION : System Description

INFOID:000000009134645

- Side slip or tail slip may occur while driving on a slippery road or during intended urgent evasive driving. VDC function detects side slip status using each sensor when side slip or tail slip is about to occur and improves vehicle stability by brake control and engine output control during driving.
- In addition to ABS function, EBD function and TCS function, target side slip amount is calculated according to steering operation amount from steering angle sensor and brake operation amount from brake pressure sensor. By comparing this information with vehicle side slip amount that is calculated from information from yaw rate/side/decel G sensor and wheel sensor, vehicle driving conditions (conditions of understeer or oversteer) are judged and vehicle stability is improved by brake force control on all 4 wheels and engine output control.



- VDC function can be switched to non-operational status (OFF) by operating VDC OFF switch. In this case, VDC OFF indicator lamp turns ON.
- Control unit portion automatically improves driving stability by performing brake force control as well as engine output control by transmitting drive signal to actuator portion according to difference between target side slip amount and vehicle side slip amount
- VDC warning lamp blinks while VDC function is in operation and indicates to the driver that the function is in operation.
- VDC function has brake limited slip differential (BLSD) function. LH and RH driving wheel spin is always monitored. If necessary, appropriate brake force is independently applied to LH or RH driving wheel so that one-sided wheel spin is avoided and traction is maintained. Mainly starting ability is improved. [Brake limited slip differential (BLSD) function operates while VDC function is in non-operational status (OFF) by VDC OFF switch.] VDC warning lamp turns ON when Brake limited slip differential (BLSD) function is in operation. Noises and vibration may be generated due to brake operation. This is not a malfunction.
- CONSULT can be used to diagnose the system.
- Fail-safe function is adopted. When a malfunction occurs in VDC function, the control is suspended for VDC function, TCS function, hill start assist function, Brake force distribution function and Active trace control function. The vehicle status becomes the same as models without VDC function, TCS function, hill start assist function, Brake force distribution function and Active trace control function. However, ABS function and EBD function are operated normally. Refer to [BRC-20. "Fail-Safe"](#).

NOTE:

VDC has the characteristic as described here. This is not a device that helps reckless driving.

INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

Component	Signal description
Yaw rate/side/decel G sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via communication line*1: <ul style="list-style-type: none"> • Yaw rate signal • Side G sensor signal • Decel G sensor signal
ECM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Acceleration pedal position signal • Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Target throttle position signal

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]


Component	Signal description
TCM	Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Shift position signal
Steering angle sensor	Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Steering angle sensor signal
Combination meter	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Brake fluid level switch signal • Parking brake switch signal Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • VDC warning lamp signal • VDC OFF indicator lamp signal

*1: Communication line between yaw rate/side/decel G sensor and ABS actuator and electric unit (control unit)


OPERATION CHARACTERISTICS

VDC Function That Prevents Oversteer Tendency

- During a cornering, brake force (brake fluid pressure) is applied on front wheel and rear wheel on the outer side of turn. Momentum directing towards the outer side of turn is generated. Oversteer is prevented.




- Changing driving lane on a slippery road, when oversteer tendency is judged large, engine output is controlled as well as brake force (brake fluid pressure) of 4 wheels. Oversteer tendency decreases.



VDC Function That Prevents Understeer Tendency

- During a cornering, brake force (brake fluid pressure) is applied on front wheel and rear wheel on the inner side of turn. Momentum directing towards the inner side of turn is generated. Understeer is prevented.




A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

SYSTEM

[WITH VDC]

< SYSTEM DESCRIPTION >


- Applying braking during cornering on a slippery road, when understeer tendency is judged large, engine output is controlled as well as brake force (brake fluid pressure) of four wheels. Understeer tendency decreases.



TCS FUNCTION

TCS FUNCTION : System Diagram


INFOID:000000009134646



TCS FUNCTION : System Description

INFOID:00000009134647

- Wheel spin status of drive wheel is detected by wheel sensor of 4 wheels. Engine output and transmission shift status is controlled so that slip rate of drive wheels is at an appropriate level. When wheel spin occurs on drive wheel, ABS actuator and electric unit (control unit) perform brake force control of LH and RH drive wheels (apply brake force by increasing brake fluid pressure of drive wheel) and decrease engine torque by engine torque control. Wheel spin amount decreases. Engine torque is controlled to appropriate level.
- TCS function can be switched to non-operational status (OFF) by operating VDC OFF switch. In this case, VDC OFF indicator lamp turns ON.
- VDC warning lamp blinks while TCS function is in operation and indicates to the driver that the function is in operation.
- CONSULT can be used to diagnose the system.
- Fail-safe function is adopted. When a malfunction occurs in TCS function, the control is suspended for VDC function, TCS function, hill start assist function, Brake force distribution function and Active trace control function. The vehicle status becomes the same as models without VDC function, TCS function, hill start assist function, Brake force distribution function and Active trace control function. However, ABS function and EBD function are operated normally. Refer to [BRC-20, "Fail-Safe"](#).



INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.


Component	Signal description
Yaw rate/side/decel G sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via communication line*1: • Yaw rate signal • Side G sensor signal • Decel G sensor signal
ECM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: • Accelerator pedal position signal • Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication: • Target throttle position signal
TCM	Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: • Shift position signal
Steering angle sensor	Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: • Steering angle sensor signal
Combination meter	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: • Brake fluid level switch signal • Parking brake switch signal Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: • VDC warning lamp signal • VDC OFF indicator lamp signal

*1: Communication line between yaw rate/side/decel G sensor and ABS actuator and electric unit (control unit)

ABS FUNCTION

ABS FUNCTION : System Diagram

INFOID:000000009134648




ABS FUNCTION : System Description

INFOID:000000009134649

- By preventing wheel lock through brake force (brake fluid pressure) control that is electronically controlled by detecting wheel speed during braking, stability during emergency braking is improved so that obstacles can be avoided by steering operation.
- During braking, control units calculate wheel speed and pseudo-vehicle speed, and transmits pressure increase, hold or decrease signals to actuator portion according to wheel slip status.
- The following effects are obtained by preventing wheel lock during braking.
 - Vehicle tail slip is prevented during braking when driving straight.
 - Understeer and oversteer tendencies are moderated during braking driving on a corner.
 - Obstacles may be easily bypassed by steering operation during braking.
- CONSULT can be used to diagnose the system diagnosis.
- Fail-safe function is adopted. When a malfunction occurs in ABS function, the control is suspended for VDC function, TCS function, ABS function, hill start assist function, Brake force distribution function and Active trace control function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, hill start assist function, Brake force distribution function and Active trace control function. However, EBD function is operated normally. Refer to [BRC-20. "Fail-Safe"](#).

NOTE:

- ABS has the characteristic as described here. This is not the device that helps reckless driving.
- To stop vehicle efficiently, ABS does not operate and ordinary brake operates at low speed [approx. 10 km/h (6 MPH) or less but differs subject to road conditions].
- Self-diagnosis is performed immediately after when engine starts and when vehicle initially is driven [by vehicle speed approx. 15 km/h (9 MPH)]. Motor sounds are generated during self-diagnosis. In addition, brake pedal may be feel heavy when depressing brake pedal lightly. These symptoms are not malfunctions.



SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

INPUT SIGNAL AND OUTPUT SIGNAL


Major signal transmission between each unit via communication lines is shown in the following table.

Component	Signal description
Steering angle sensor	Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> Steering angle sensor signal
Combination meter	Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> ABS warning lamp signal VDC warning lamp signal

EBD FUNCTION

EBD FUNCTION : System Diagram


INFOID:000000009134650



EBD FUNCTION : System Description

INFOID:000000009134651

- By preventing rear wheel slip increase through rear wheel brake force (brake fluid pressure) control that is electronically controlled when slight skip on front and rear wheels are detected during braking, stability during braking is improved.
- EBD function is expanded and developed from conventional ABS function and corrects rear wheel brake force to appropriate level by electronic control according to load weight (number of passengers).




SYSTEM

[WITH VDC]

< SYSTEM DESCRIPTION >

- During braking, control unit portion compares slight slip on front and rear wheels by wheel speed sensor signal, transmits drive signal to actuator portion when rear wheel slip exceeds front wheel slip for the specified value or more, and controls rear wheel brake force (brake fluid pressure) so that increase of rear wheel slip is prevented and slips on front wheel and rear wheel are nearly equalized. ABS control is applied when slip on each wheel increases and wheel speed is the threshold value of ABS control or less.
- CONSULT can be used to diagnose the system.
- Fail-safe function is adopted. When a malfunction occurs in EBD function, the control is suspended for VDC function, TCS function, ABS function, EBD function, hill start assist function, Brake force distribution function and Active trace control function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, EBD function, hill start assist function, Brake force distribution function and Active trace control function. Refer to [BRC-20, "Fail-Safe"](#).



INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

Component	Signal description
Combination meter	Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Brake warning lamp signal • ABS warning lamp signal • VDC warning lamp signal

Hill start assist FUNCTION


SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

Hill start assist FUNCTION : System Diagram

INFOID:000000009134652



A
B
C
D
E
G
H

BRC

Hill start assist FUNCTION : System Description

INFOID:000000009134653

- This function maintains brake fluid pressure so that the vehicle does not move backwards even if brake pedal is released to depress accelerator pedal to start the vehicle while it is stopped on an uphill slope by depressing brake pedal.
- This function operates when the vehicle is in stop status on an uphill slope of slope ratio 10% or more and selector lever is in any position other than P (Park) or N (Neutral).
- Hill start assist function is only for the start aid. It maintains the brake fluid pressure for approx. 2 seconds after releasing the brake pedal, and then decreases the pressure gradually. If the vehicle starts by accelerator operation, the brake is released automatically and a smooth start can be performed.
- Fail-safe function is adopted. When a malfunction occurs in hill start assist function, the control is suspended for VDC function, TCS function, hill start assist function, Brake force distribution function and Active trace control function. The vehicle status becomes the same as models without VDC function, TCS function, hill start assist function, Brake force distribution function and Active trace control function. However, ABS function and EBD function are operated normally. Refer to [BRC-20, "Fail-Safe"](#).

I
J
K
L
M
N

INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

Component	Signal description
Yaw rate/side/decel G sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via communication line *: <ul style="list-style-type: none"> • Yaw rate signal • Side G sensor signal • Decel G sensor signal
ECM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Accelerator pedal position signal • Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Target throttle position signal

O
P

SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]


Component	Signal description
TCM	Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Shift position signal
Combination meter	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Brake fluid level switch signal • Parking brake switch signal Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • VDC warning lamp signal • VDC OFF indicator lamp signal

*: Communication line between yaw rate/side/decel G sensor and ABS actuator and electric unit (control unit)

ACTIVE STABILITY ASSIST

ACTIVE STABILITY ASSIST : System Diagram

INFOID:000000009134654



ACTIVE STABILITY ASSIST : System Description

INFOID:000000009134655

- Combination of Active trace control function and Brake force distribution function is named to as Active stability assist. Active trace control function is available for models with ICC system.
- Active stability assist system is aimed to smooth the vehicle movement utilizing VDC function for enjoyable driving with reliable feeling of the driver.
- Active trace control function
- Active Trace Control helps enhance the transition from braking into and then accelerating out of corners. Active Trace Control utilizes the vehicle's VDC system to help improve cornering feel by automatically applying brakes, or smoothing engine torque characteristics while accelerating. Furthermore, Active Trace Control will apply selective braking to help create increased steering response in S-turns. For example, if driving through an S-turn that starts with steering to the right, the right-side brakes are engaged to create a yaw momentum and help turn the vehicle. When steering back to the left, left-side brakes are engaged. Refer to [BRC-33. "ACTIVE STABILITY ASSIST : Active Trace Control Function"](#).
- Brake Force Distribution function

SYSTEM

[WITH VDC]

< SYSTEM DESCRIPTION >

- During braking, Brake force Distribution optimizes the distribution of brake force to each of the four wheels depending on the state of the turn detected by driver's steering and some sensors. Brake force Distribution helps provide a more stable and secure feeling. Refer to [BRC-12. "System Diagram"](#).
- Active trace control can be switched to operational status or non-operational status by operating VDC OFF switch to ON/OFF.

INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

Component	Signal description
ADAS control unit	Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Active trace control signal
ECM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Accelerator pedal position signal • Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Target throttle position signal
ABS actuator and electric unit (control unit)	Mainly transmits the following signals to ADAS control unit via CAN communication: <ul style="list-style-type: none"> • Vehicle speed signal (ABS) • Stop lamp switch signal (brake signal) • VDC OFF switch signal • Yaw rate signal • Side G sensor signal • Decel G sensor signal
Yaw rate/side/decel G sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via communication line *: <ul style="list-style-type: none"> • Yaw rate signal • Side G sensor signal • Decel G sensor signal
Drive mode select switch	Outputs ON/OFF status of STANDARD, SPORT, ECO, SNOW mode to A/C auto AMP.
A/C auto AMP	Mainly transmits the following signal to ADAS control unit via CAN communication: <ul style="list-style-type: none"> • Drive mode select switch signal
Steering angle sensor	Mainly transmits the following signal to ADAS control unit via CAN communication: <ul style="list-style-type: none"> • Steering angle sensor signal
Combination meter	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Brake fluid level switch signal • Parking brake switch signal Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • VDC OFF indicator lamp signal • VDC warning lamp signal Mainly receives the following signal from ADAS control unit via CAN communication: <ul style="list-style-type: none"> • IBA warning lamp signal

*: Communication line between yaw rate/side/decel G sensor and ABS actuator and electric unit (control unit)

ACTIVE STABILITY ASSIST : Active Trace Control Function

INFOID:000000009134656


- Active trace control function is calculated by ADAS control unit and transmits command to ABS actuator and electric unit (control unit).
- This system senses driving based on the driver's steering and acceleration/braking patterns, and individually controls the braking and application of engine torque to each of the four wheels to help smooth vehicle response.
- When the drive mode selector switch is set to the "SPORT" mode, the amount of brake control provided by Active trace control function is reduced.
- When the VDC OFF switch is turn OFF the VDC function, the Active trace control function is also turned OFF.
- Active trace control function is malfunctioning properly, the IBA OFF indicator lamp turns ON.

NOTE:


Effect to decrease delay of vehicle yaw rate in response to steering operation may not always be obtained in all driving conditions (example: when road surface resistance is low).

OPERATION CHARACTERISTICS

Active Trace Control helps enhance the transition from braking into and then accelerating out of corners. Active Trace Control utilizes the vehicle's VDC system to help improve cornering feel by automatically applying brakes, or smoothing engine torque characteristics while accelerating. Furthermore, Active Trace Control will apply selective braking to help create increased steering response in S-turns. For example, if driving through an S-turn that starts with steering to the right, the right-side brakes are engaged to create a yaw momentum and help turn the vehicle.



- Brake control amount and engine output are controlled according to steering operation status by the driver and vehicle cornering status.




SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]


- By preventing a sudden torque change, vehicle behavior moderates. As a result, accelerator pedal operation by the driver is improved.



ACTIVE STABILITY ASSIST : Brake Force Distribution Function

INFOID:000000009134657


- Brake force distribution function is controlled by ABS actuator and electric unit (control unit).
- Brake force distribution function helps provide a more stable and secure feeling.



- During cornering, when brake operation is performed, brake fluid pressure of each wheel is controlled based on steering operation amount by the driver and vehicle cornering status amount detected by each sensor.
- VDC warning lamp turns ON when Brake force distribution function is malfunctioning.

NOTE:

Brake force distribution function may not always operate in all driving conditions.



DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

CONSULT Function

INFOID:000000009134658

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes as follows.

Mode	Function description
ECU identification	Parts number of ABS actuator and electric unit (control unit) can be read.
Self Diagnostic Result	Self-diagnostic results and freeze frame data can be read and erased quickly.*
DATA MONITOR	Input/Output data in the ABS actuator and electric unit (control unit) can be read.
ACTIVE TEST	Diagnostic Test Mode in which CONSULT drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range.
WORK SUPPORT	Components can be quickly and accurately adjusted.

*: The following diagnosis information is erased by erasing.

- DTC
- Freeze frame data (FFD)

ECU IDENTIFICATION

ABS actuator and electric unit (control unit) part number can be read.

SELF DIAGNOSTIC RESULT

Refer to [BRC-46, "DTC Index"](#).

When "CRNT" is displayed on self-diagnosis result,

- The system is presently malfunctioning.

When "PAST" is displayed on self-diagnosis result,

- System malfunction in the past is detected, but the system is presently normal.

Freeze frame data (FFD)

The following vehicle status is recorded when DTC is detected and is displayed on CONSULT.

Item name	Display item
IGN counter (0 – 39)	<p>The number of times that ignition switch is turned ON after the DTC is detected is displayed.</p> <ul style="list-style-type: none">• When "0" is displayed: It indicates that the system is presently malfunctioning.• When except "0" is displayed: It indicates that system malfunction in the past is detected, but the system is presently normal. <p>NOTE: Each time when ignition switch is turned OFF to ON, numerical number increases in 1 → 2 → 3...38 → 39. When the operation number of times exceeds 39, the number do not increase and "39" is displayed until self-diagnosis is erased.</p>

ACTIVE TEST

The active test is used to determine and identify details of a malfunction, based on self-diagnosis test results and data obtained in the DATA MONITOR. In response to instructions from CONSULT, instead of those from ABS actuator and electric unit (control unit) on the vehicle, a drive signal is sent to the actuator to check its operation.

CAUTION:

- Never perform ACTIVE TEST while driving the vehicle.
- Always bleed air from brake system before active test.
- Never perform active test when system is malfunctioning.

NOTE:

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

- When active test is performed while depressing the pedal, the pedal depressing stroke may change. This is not a malfunction.
- “TEST IS STOPPED” is displayed approx. 10 seconds after operation start.
- When performing active test again after “TEST IS STOPPED” is displayed, select “BACK”.
- ABS warning lamp, brake warning lamp and VDC warning lamp may turn ON during active test. This is not a malfunction.

ABS IN Valve and ABS OUT Valve

When “Up”, “Keep” or “Down” is selected on display screen, the following items are displayed when system is normal.

Test item	Display Item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On*	On*
	FR RH OUT SOL	Off	Off	On*
FR LH SOL	FR LH IN SOL	Off	On*	On*
	FR LH OUT SOL	Off	Off	On*
RR RH SOL	RR RH IN SOL	Off	On*	On*
	RR RH OUT SOL	Off	Off	On*
RR LH SOL	RR LH IN SOL	Off	On*	On*
	RR LH OUT SOL	Off	Off	On*

*: Immediately after being selected, status is “On”. Status changes to “Off” after approx. 2 seconds.

ABS IN Valve (ACT) and ABS OUT Valve (ACT)

When “Up”, “ACT UP” or “ACT KEEP” is selected on display screen, the following items are displayed when system is normal.

Test item	Display Item	Display		
		Up	ACT UP	ACT KEEP
FR RH SOLENOID (ACT)	FR RH IN SOL	Off	Off	Off
	FR RH OUT SOL	Off	Off	Off
	CV1	Off	Off	Off
	CV2	Off	On*	On*
FR LH SOLENOID (ACT)	FR LH IN SOL	Off	Off	Off
	FR LH OUT SOL	Off	Off	Off
	CV1	Off	On*	On*
	CV2	Off	Off	Off
RR RH SOLENOID (ACT)	RR RH IN SOL	Off	Off	Off
	RR RH OUT SOL	Off	Off	Off
	CV1	Off	On*	On*
	CV2	Off	Off	Off
RR LH SOLENOID (ACT)	RR LH IN SOL	Off	On*	Off
	RR LH OUT SOL	Off	Off	Off
	CV1	Off	Off	Off
	CV2	Off	On*	On*

*: Immediately after being selected, status is “On”. Status changes to “Off” after approx. 10 seconds.

ABS MOTOR

When “On” or “Off” is selected on display screen, the following items are displayed when system is normal.

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

Test item	Display Item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY ^(Note)	On	On

NOTE:

Display occasionally changes On/Off for a moment after ignition switch is turned ON. This is an operation for checking purposes and is not a malfunction.

DATA MONITOR

×: Applicable

Item (Unit)	Monitor item selection		Note
	ECU INPUT SIGNALS	MAIN SIGNALS	
FR LH SENSOR [km/h (MPH)]	×	×	Wheel speed calculated by front LH wheel sensor is displayed.
FR RH SENSOR [km/h (MPH)]	×	×	Wheel speed calculated by front RH wheel sensor is displayed.
RR LH SENSOR [km/h (MPH)]	×	×	Wheel speed calculated by rear LH wheel sensor is displayed.
RR RH SENSOR [km/h (MPH)]	×	×	Wheel speed calculated by rear RH wheel sensor is displayed.
DECEL G-SEN (m/s ²)	×	×	Decel G detected by decel G sensor is displayed.
FR RH IN SOL (On/Off)		×	Operation status of front RH wheel ABS IN valve is displayed.
FR RH OUT SOL (On/Off)		×	Operation status of front RH wheel ABS OUT valve is displayed.
FR LH IN SOL (On/Off)		×	Operation status of front LH wheel ABS IN valve is displayed.
FR LH OUT SOL (On/Off)		×	Operation status of front LH wheel ABS OUT valve is displayed.
RR RH IN SOL (On/Off)		×	Operation status of rear RH wheel ABS IN valve is displayed.
RR RH OUT SOL (On/Off)		×	Operation status of rear RH wheel ABS OUT valve is displayed.
RR LH IN SOL (On/Off)		×	Operation status of rear LH wheel ABS IN valve is displayed.
RR LH OUT SOL (On/Off)		×	Operation status of rear LH wheel ABS OUT valve is displayed.
EBD WARN LAMP (On/Off)			Brake warning lamp ON/OFF status is displayed. ^(Note 1)
STOP LAMP SW (On/Off)	×	×	Stop lamp switch signal input status is displayed.
MOTOR RELAY (On/Off)		×	ABS motor and motor relay status is displayed.
ACTUATOR RLY (On/Off)		×	ABS actuator relay status is displayed.
ABS WARN LAMP (On/Off)		×	ABS warning lamp ON/OFF status is displayed. ^(Note 1)
OFF LAMP (On/Off)		×	VDC OFF indicator lamp ON/OFF status is displayed. ^(Note 1)
OFF SW (On/Off)	×	×	VDC OFF switch ON/OFF status is displayed. ^(Note 1)

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

Item (Unit)	Monitor item selection		Note	
	ECU INPUT SIGNALS	MAIN SIGNALS		
SLIP/VDC LAMP (On/Off)		×	VDC warning lamp ON/OFF status is displayed. ^(Note 1)	A
BATTERY VOLT (V)	×	×	Voltage supplied to ABS actuator and electric unit (control unit) is displayed.	B
GEAR	×	×	Current gear position judged from current gear position signal is displayed.	C
SLCT LVR POSI	×	×	Current gear position judged from current gear position signal is displayed.	D
ENGINE SPEED (tr/min)	×	×	Engine speed status is displayed.	E
YAW RATE SEN (d/s)	×	×	Yaw rate detected by yaw rate sensor is displayed.	E
R POSI SIG (On/Off)			R range signal input status judged from R range signal is displayed.	BRC
N POSI SIG (On/Off)			N range signal input status judged from N range signal is displayed.	
CV1 (On/Off)			Cut valve 1 operation status is displayed.	G
CV2 (On/Off)			Cut valve 2 operation status is displayed.	H
ACCEL POS SIG (%)	×		Displays the Accelerator pedal position.	
SIDE G -SENSOR (m/s ²)	×		Side G detected by side G sensor is displayed.	I
STR ANGLE SIG (°)	×		Steering angle detected by steering angle sensor is displayed.	J
PRESS SENSOR (bar)	×		Brake fluid pressure detected by pressure sensor is displayed.	
EBD SIGNAL (On/Off)			EBD operation status is displayed.	K
ABS SIGNAL (On/Off)			ABS operation status is displayed.	L
TCS SIGNAL (On/Off)			TCS operation status is displayed.	
VDC SIGNAL (On/Off)			VDC operation status is displayed.	M
EBD FAIL SIG (On/Off)			EBD fail-safe signal status is displayed.	N
ABS FAIL SIG (On/Off)			ABS fail-safe signal status is displayed.	
TCS FAIL SIG (On/Off)			TCS fail-safe signal status is displayed.	O
VDC FAIL SIG (On/Off)			VDC fail-safe signal status is displayed.	P
CRANKING SIG (On/Off)			Cranking status is displayed.	
FLUID LEV SW (On/Off)	×		Brake fluid level signal input status via CAN communication is displayed.	

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

Item (Unit)	Monitor item selection		Note
	ECU INPUT SIGNALS	MAIN SIGNALS	
PARK BRAKE SW (On/Off)	×		Parking brake switch signal input status via CAN communication is displayed.
USS SIG ^(Note 2) (On/Off)			Hill start assist operation status is displayed.

Note 1: Refer to [BRC-12. "System Description"](#) for ON/OFF conditions of each warning lamp and indicator lamp.

Note 2: USS means "hill start assist."

WORK SUPPORT

Conditions	Description
ST ANGLE SENSOR ADJUSTMENT	Perform neutral position adjustment of steering angle sensor.
DECEL G SEN CALIBRATION	Perform decel G sensor calibration.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

ECU DIAGNOSIS INFORMATION

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Reference Value

INFOID:000000009134659

CONSULT DATA MONITOR STANDARD VALUE

Monitor item	Condition	Reference values in normal operation
FR LH SENSOR	Vehicle stopped	0.00 km/h (MPH)
	When driving ^(Note 1)	Nearly matches the speedometer display (within ±10%)
FR RH SENSOR	Vehicle stopped	0.00 km/h (MPH)
	When driving ^(Note 1)	Nearly matches the speedometer display (within ±10%)
RR LH SENSOR	Vehicle stopped	0.00 km/h (MPH)
	When driving ^(Note 1)	Nearly matches the speedometer display (within ±10%)
RR RH SENSOR	Vehicle stopped	0.00 km/h (MPH)
	When driving ^(Note 1)	Nearly matches the speedometer display (within ±10%)
DECEL G-SEN	When stopped	Approx. 0 m/s ²
	During acceleration	Positive value
	During deceleration	Negative value
FR RH IN SOL	Active	On
	Not activated	Off
FR RH OUT SOL	Active	On
	Not activated	Off
FR LH IN SOL	Active	On
	Not activated	Off
FR LH OUT SOL	Active	On
	Not activated	Off
RR RH IN SOL	Active	On
	Not activated	Off
RR RH OUT SOL	Active	On
	Not activated	Off
RR LH IN SOL	Active	On
	Not activated	Off
RR LH OUT SOL	Active	On
	Not activated	Off
EBD WARN LAMP	When brake warning lamp is ON ^(Note 2)	On
	When brake warning lamp is OFF ^(Note 2)	Off
STOP LAMP SW	Brake pedal depressed	On
	Brake pedal not depressed	Off
MOTOR RELAY	Active	On
	Not activated	Off
ACTUATOR RLY	Active	On
	When not operating (in fail-safe mode)	Off

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

Monitor item	Condition	Reference values in normal operation
ABS WARN LAMP	When ABS warning lamp is ON ^(Note 2)	On
	When ABS warning lamp is OFF ^(Note 2)	Off
OFF LAMP	When VDC OFF indicator lamp is ON ^(Note 2)	On
	When VDC OFF indicator lamp is OFF ^(Note 2)	Off
OFF SW	VDC OFF switch ON (When VDC OFF switch is ON ^(Note 2))	On
	VDC OFF switch OFF (When VDC OFF switch is OFF ^(Note 2))	Off
SLIP/VDC LAMP	When VDC warning lamp is ON ^(Note 2)	On
	When VDC warning lamp is OFF ^(Note 2)	Off
BATTERY VOLT	Ignition switch ON	10 – 16 V
GEAR	Driving	1 – 7 Depending on shift status
SLCT LVR POSI	Vehicle stopped	N/P Depending on shift status
ENGINE SPEED	Engine stopped	0 tr/min
	Engine running	Almost same reading as tachometer
YAW RATE SEN	Vehicle stopped	Approx. 0 d/s
	Turning right	Negative value
	Turning left	Positive value
R POSI SIG	When selector lever is in the R position	On
	When selector lever is in the other position than R	Off
N POSI SIG	When selector lever is in the N position	On
	When selector lever is in the other position than N	Off
CV1	Active	On
	Not activated	Off
CV2	Active	On
	Not activated	Off
ACCEL POS SIG	Never depress accelerator pedal (with ignition switch ON)	0%
	Depress accelerator pedal (with ignition switch ON)	0 – 100%
SIDE G-SENSOR	Vehicle stopped	Approx. 0 m/s ²
	Right turn	Negative value
	Left turn	Positive value
STR ANGLE SIG	When driving straight	0±2.5°
	When steering wheel is steered to LH by 90°	Approx. +90°
	When steering wheel is steered to RH by 90°	Approx. –90°
PRESS SENSOR	Brake pedal not depressed	Approx. 0 bar
	Brake pedal depressed	(–40) – (+300 bar)
EBD SIGNAL	EBD activated	On
	EBD not activated	Off
ABS SIGNAL	ABS is activated	On
	ABS is not activated	Off

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

Monitor item	Condition	Reference values in normal operation
TCS SIGNAL	TCS activated	On
	TCS not activated	Off
VDC SIGNAL	VDC activated	On
	VDC not activated	Off
EBD FAIL SIG	In EBD fail-safe	On
	EBD is normal	Off
ABS FAIL SIG	In ABS fail-safe	On
	ABS is normal	Off
TCS FAIL SIG	In TCS fail-safe	On
	TCS is normal	Off
VDC FAIL SIG	In VDC fail-safe	On
	VDC is normal	Off
CRANKING SIG	At cranking	On
	Other than at cranking	Off
FLUID LEV SW	When brake fluid level switch is ON (brake fluid level is less than the specified level)	On
	When brake fluid level switch is OFF	Off
PARK BRAKE SW	When parking brake is active	On
	Parking brake is released	Off
USS SIG ^(Note 3)	hill start assist is active	On
	hill start assist is inactive	Off

Note 1: Confirm tire pressure is standard value.

Note 2: Refer to [BRC-12. "System Description"](#) for ON/OFF conditions of each warning lamp and indicator lamp.

Note 3: USS means "hill start assist."

Fail-Safe

INFOID:000000009134660

VDC FUNCTION, TCS FUNCTION, hill start assist FUNCTION AND BRAKE FORCE DISTRIBUTION FUNCTION

VDC warning lamp in combination meter turns ON when a malfunction occurs in the system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, hill start assist function and Brake force distribution function. The vehicle status becomes the same as models without VDC function, TCS function, hill start assist function and Brake force distribution function. However, ABS function and EBD function are operated normally.

ABS FUNCTION

ABS warning lamp and VDC warning lamp in combination meter turn ON when a malfunction occurs in the system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, ABS function, hill start assist function and Brake force distribution function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, hill start assist function and Brake force distribution function. However, EBD function is operated normally.

NOTE:

ABS self-diagnosis sound may be heard the same as in the normal condition because self-diagnosis is performed when ignition switch turns ON and when vehicle initially starts.

EBD FUNCTION

ABS warning lamp, brake warning lamp and VDC warning lamp in combination meter turn ON when a malfunction occurs in the system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, ABS function, EBD function, hill start assist function and Brake force distribution function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, EBD function, hill start assist function and Brake force distribution function.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

DTC	Malfunction detected condition	Fail-safe condition
C1101	When an open circuit is detected in rear RH wheel sensor circuit.	The following functions are suspended: • VDC function • TCS function • ABS function • EBD function (only when both 2 rear wheels are malfunctioning) • hill start assist function • Brake force distribution function
C1102	When an open circuit is detected in rear LH wheel sensor circuit.	
C1103	When an open circuit is detected in front RH wheel sensor circuit.	
C1104	When an open circuit is detected in front LH wheel sensor circuit.	
C1105	<ul style="list-style-type: none"> • When power supply voltage of rear RH wheel sensor is low. • When distance between rear RH wheel sensor and rear RH wheel sensor rotor is large. • When installation of rear RH wheel sensor or rear RH wheel sensor rotor is not normal. 	
C1106	<ul style="list-style-type: none"> • When power supply voltage of rear LH wheel sensor is low. • When distance between rear LH wheel sensor and rear LH wheel sensor rotor is large. • When installation of rear LH wheel sensor or rear LH wheel sensor rotor is not normal. 	
C1107	<ul style="list-style-type: none"> • When power supply voltage of front RH wheel sensor is low. • When distance between front RH wheel sensor and front RH wheel sensor rotor is large. • When installation of front RH wheel sensor or front RH wheel sensor rotor is not normal. 	
C1108	<ul style="list-style-type: none"> • When power supply voltage of front LH wheel sensor is low. • When distance between front LH wheel sensor and front LH wheel sensor rotor is large. • When installation of front LH wheel sensor or front LH wheel sensor rotor is not normal. 	
C1109	<ul style="list-style-type: none"> • When ignition voltage is 10 V or less. • When ignition voltage is 16 V or more. 	The following functions are suspended: • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function
C1111	When a malfunction is detected in motor or motor relay.	The following functions are suspended: • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function
C1115	When difference in wheel speed between any wheel and others is detected during the vehicle is driven because of installation of other tires than specified.	The following functions are suspended: • VDC function • TCS function • ABS function • hill start assist function • Brake force distribution function
C1116	When stop lamp switch signal is not input when brake pedal operates.	The following functions are suspended: • VDC function • TCS function • ABS function • hill start assist function • Brake force distribution function
C1120	When a malfunction is detected in front LH ABS IN valve.	The following functions are suspended: • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function
C1121	When a malfunction is detected in front LH ABS OUT valve.	
C1122	When a malfunction is detected in front RH ABS IN valve.	
C1123	When a malfunction is detected in front RH ABS OUT valve.	
C1124	When a malfunction is detected in rear LH ABS IN valve.	
C1125	When a malfunction is detected in rear LH ABS OUT valve.	
C1126	When a malfunction is detected in rear RH ABS IN valve.	
C1127	When a malfunction is detected in rear RH ABS OUT valve.	
C1130	When a malfunction is detected in ECM system.	The following functions are suspended: • VDC function • TCS function • hill start assist function • Brake force distribution function

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

DTC	Malfunction detected condition	Fail-safe condition	
C1140	When a malfunction is detected in actuator relay.	The following functions are suspended: • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function	A B C
C1142	When a malfunction is detected in pressure sensor.	The following functions are suspended: • VDC function • TCS function • hill start assist function • Brake force distribution function	D E
C1143	When a malfunction is detected in steering angle sensor.		
C1144	When neutral position adjustment of steering angle sensor is not complete.		
C1145	When a malfunction is detected in yaw rate signal.		
C1146	When a malfunction is detected in side/decel G signal.	The following functions are suspended: • VDC function • TCS function • ABS function • hill start assist function • Brake force distribution function	E
C1155	When brake fluid level low signal is detected.	The following functions are suspended: • VDC function • TCS function • ABS function • hill start assist function • Brake force distribution function	G H
C1160	When calibration of yaw rate/side/decel G sensor is not complete.	The following functions are suspended: • VDC function • TCS function • hill start assist function • Brake force distribution function	H
C1164	When a malfunction is detected in cut valve 1.	The following functions are suspended: • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function	I J
C1165	When a malfunction is detected in cut valve 2.		
C1170	When the information in ABS actuator and electric unit (control unit) is not the same.	The following functions are suspended: • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function	J
C1197	When a malfunction is detected in vacuum sensor.	Electrical vacuum assistance of brake booster is suspended.	K L
C1198	• When an open circuit is detected in vacuum sensor circuit. • When a short circuit is detected in vacuum sensor circuit. • When a malfunction is detected in vacuum sensor noise.		
C1199	When brake booster vacuum is approx. 0 kPa (0 mmHg) during engine running.		
C119A	When a malfunction is detected in supply power voltage of vacuum sensor.	Electrical vacuum assistance of brake booster is suspended.	M
U1000	When CAN communication signal is not continuously received for 2 seconds or more.	The following functions are suspended: • VDC function • TCS function • hill start assist function • Brake force distribution function	N
U0424*	When signal that is transmitted from A/C auto AMP. is not the latest information.	Mode is fixed to the mode when a malfunction of drive mode selector occurs. The mode is fixed to STANDARD mode after ignition switch turns OFF to ON.	O P

*: This is DTC that is detected in ADAS control unit side.

DTC Inspection Priority Chart

INFOID:000000009134661

When multiple DTCs are displayed simultaneously, check one by one depending on the following priority list.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

Priority	Detected item (DTC)
1	<ul style="list-style-type: none"> • U1000 CAN COMM CIRCUIT • U0424 HVAC CAN CIR 1*
2	<ul style="list-style-type: none"> • C1170 VARIANT CODING
3	<ul style="list-style-type: none"> • C1130 ENGINE SIGNAL 1 • C1144 ST ANG SEN SIGNAL
4	<ul style="list-style-type: none"> • C1109 BATTERY VOLTAGE [ABNOMAL] • C1111 PUMP MOTOR • C1140 ACTUATOR RLY
5	<ul style="list-style-type: none"> • C1101 RR RH SENSOR-1 • C1102 RR LH SENSOR-1 • C1103 FR RH SENSOR-1 • C1104 FR LH SENSOR-1 • C1105 RR RH SENSOR-2 • C1106 RR LH SENSOR-2 • C1107 FR RH SENSOR-2 • C1108 FR LH SENSOR-2 • C1115 ABS SENSOR [ABNORMAL SIGNAL] • C1116 STOP LAMP SW • C1120 FR LH IN ABS SOL • C1121 FR LH OUT ABS SOL • C1122 FR RH IN ABS SOL • C1123 FR RH OUT ABS SOL • C1124 RR LH IN ABS SOL • C1125 RR LH OUT ABS SOL • C1126 RR RH IN ABS SOL • C1127 RR RH OUT ABS SOL • C1142 PRESS SEN CIRCUIT • C1143 ST ANG SEN CIRCUIT • C1145 YAW RATE SENSOR • C1146 SIDE G SEN CIRCUIT • C1160 DECEL G SEN SET • C1164 CV 1 • C1165 CV 2 • C1197 VACUUM SENSOR • C1198 VACUUM SEN CIR • C1199 BRAKE BOOSTER • C119A VACUUM SEN VOLT
6	<ul style="list-style-type: none"> • C1155 BR FLUID LEVEL LOW

*: This is DTC that is detected in ADAS control unit side.

DTC Index

INFOID:000000009134662

DTC	Display Item	Refer to
C1101	RR RH SENSOR-1	BRC-64. "DTC Logic"
C1102	RR LH SENSOR-1	
C1103	FR RH SENSOR-1	
C1104	FR LH SENSOR-1	
C1105	RR RH SENSOR-2	BRC-68. "DTC Logic"
C1106	RR LH SENSOR-2	
C1107	FR RH SENSOR-2	
C1108	FR LH SENSOR-2	
C1109	BATTERY VOLTAGE [ABNOMAL]	BRC-70. "DTC Logic"
C1111	PUMP MOTOR	BRC-72. "DTC Logic"
C1115	ABS SENSOR [ABNORMAL SIGNAL]	BRC-74. "DTC Logic"

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

DTC	Display Item	Refer to	
C1116	STOP LAMP SW	BRC-76, "DTC Logic"	A
C1120	FR LH IN ABS SOL	BRC-79, "DTC Logic"	
C1121	FR LH OUT ABS SOL	BRC-81, "DTC Logic"	B
C1122	FR RH IN ABS SOL	BRC-79, "DTC Logic"	
C1123	FR RH OUT ABS SOL	BRC-81, "DTC Logic"	
C1124	RR LH IN ABS SOL	BRC-79, "DTC Logic"	C
C1125	RR LH OUT ABS SOL	BRC-81, "DTC Logic"	
C1126	RR RH IN ABS SOL	BRC-79, "DTC Logic"	D
C1127	RR RH OUT ABS SOL	BRC-81, "DTC Logic"	
C1130	ENGINE SIGNAL 1	BRC-83, "DTC Logic"	
C1140	ACTUATOR RLY	BRC-84, "DTC Logic"	E
C1142	PRESS SEN CIRCUIT	BRC-86, "DTC Logic"	
C1143	ST ANG SEN CIRCUIT	BRC-88, "DTC Logic"	BRC
C1144	ST ANG SEN SIGNAL	BRC-90, "DTC Logic"	
C1145	YAW RATE SENSOR	BRC-91, "DTC Logic"	
C1146	SIDE G SEN CIRCUIT		G
C1155	BR FLUID LEVEL LOW	BRC-94, "DTC Logic"	
C1160	DECEL G SEN SET	BRC-96, "DTC Logic"	
C1164	CV 1	BRC-97, "DTC Logic"	H
C1165	CV 2		
C1170	VARIANT CODING	BRC-99, "DTC Logic"	I
C1197	VACUUM SENSOR	BRC-100, "DTC Logic"	
C1198	VACUUM SEN CIR	BRC-102, "DTC Logic"	
C1199	BRAKE BOOSTER	BRC-104, "DTC Logic"	J
C119A	VACUUM SEN VOLT	BRC-106, "DTC Logic"	
U1000	CAN COMM CIRCUIT	BRC-108, "DTC Logic"	K
U0424*	HVAC CAN CIR 1	BRC-109, "DTC Logic"	

*: This DTC is detected in ADAS control unit.

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

ADAS CONTROL UNIT

List of ECU Reference

INFOID:000000009134663

ECU name	Refer to
ADAS control unit	DAS-39. "Reference Value"
	DAS-44. "Fail-safe"
	DAS-45. "DTC Inspection Priority Chart"
	DAS-47. "DTC Index"

ACTIVE TRACE CONTROL FUNCTION

Intelligent brake assist OFF indicator lamp turns ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for Active trace control function. The vehicle becomes the same as models without Active trace control function. Refer to [DAS-19. "System Function"](#) for ON/OFF conditions of each warning lamp and indicator lamp.

CAUTION:

Lamp ON condition of intelligent brake assist OFF indicator lamp is that intelligent brake assist OFF switch is in the pressed and not turned ON status.

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[WITH VDC]


WIRING DIAGRAM

BRAKE CONTROL SYSTEM

Wiring Diagram

INFOID:000000009134664

BRAKE CONTROL SYSTEM




ABFWA0277GB

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[WITH VDC]



ABFWA0359GB

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[WITH VDC]


BRAKE CONTROL SYSTEM CONNECTORS

Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8P	BG	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND1
2	B	GND2
12	G	PKB
21	BG	IGN
25	G	BRAKE OIL SW
38	P	CAN-L
39	L	CAN-H

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
33G	G	-
34G	G	-
35G	P	-
36G	L	-
55G	G	-
56G	P	-
57G	P	-
58G	L	-

ABFIA0718GB


A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >


[WITH VDC]

Connector No.	M160
Connector Name	YAW RATE/SIDE/DECEL G SENSOR
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	P	-
3	L	-
4	G	-
5	-	-
6	-	-

Connector No.	M71
Connector Name	VDC OFF SWITCH
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
1	P	-
2	GR	-

Connector No.	M54
Connector Name	STEERING ANGLE SENSOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	STEERING ANGLE SENS GND
2	P	CAN-L
3	-	-
4	G	STEERING ANGLE SENS POWER
5	L	CAN-H
6	-	-
7	-	-
8	-	-

Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5M	Y	-

Connector No.	E21
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

Connector No.	E18
Connector Name	FRONT WHEEL SENSOR LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-

ABFIA0719GB

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[WITH VDC]

Connector No.	E43
Connector Name	FRONT WHEEL SENSOR RH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	G	-
2	W	-

Connector No.	E38
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	Y	-
2	P	-
3	Y	-(WITH ICC)
4	G	-(WITH ICC)

Connector No.	E34
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	BG	-
14	P	-
15	R	-
16	G	-

Connector No.	E56
Connector Name	VDC RESISTOR
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	G	-
2	GR	-

Connector No.	E52
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	LG	-

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	P	-
14	P	-
19	Y	-
20	Y	-
22	Y	-

ABFIA0720GB



A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >



[WITH VDC]

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
35	BR	ABS ECU

Connector No.	E71
Connector Name	JOINT CONNECTOR-E15
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
1	L	-
3	L	-

Connector No.	E70
Connector Name	JOINT CONNECTOR-E14
Connector Color	BLACK






Terminal No.	Color of Wire	Signal Name
1	P	-
3	P	-

Terminal No.	Color of Wire	Signal Name
26	-	-
27	-	-
28	B	VAC SEN (POWER)
29	-	-
30	R	VDC OFF SW
31	-	-
32	SHIELD	VAC SEN (GND)
33	-	-
34	BR	IGN (POWER)

Terminal No.	Color of Wire	Signal Name
9	W	FR RH SEN (SIGNAL)
10	G	FR RH SEN (POWER)
11	-	-
12	-	-
13	W	VAC SEN (SIGNAL)
14	-	-
15	P	CAN-L
16	BG	CANM2 (+)
17	P	RR RH SEN (SIGNAL)
18	BG	RR RH SEN (POWER)
19	W	FR LH SEN (SIGNAL)
20	G	FR LH SEN (POWER)
21	-	-
22	-	-
23	-	-
24	-	-
25	L	CAN-H

Connector No.	E125
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK

Terminal No.	Color of Wire	Signal Name
1	B	ECU (GND)
2	B/W	MOTOR (GND)
3	R	SOLENOID (POWER)
4	W	MOTOR (POWER)
5	G	STOP LAMP SW (WITH ICC)
5	P	STOP LAMP SW (WITHOUT ICC)
6	P	CANM2 (-)
7	G	RR LH SEN (SIGNAL)
8	R	RR LH SEN (POWER)

ABFIA0721GB

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[WITH VDC]


Connector No.	E167
Connector Name	VACUUM SENSOR
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W	-
2	SHIELD	-
3	B	-

Terminal No.	Color of Wire	Signal Name
33G	LG	-
34G	W	-
35G	P	-
36G	L	-
55G	BR	-
56G	R	-
57G	P	-
58G	BG	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	C13
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
9	W	-
10	B	-
11	P	-
12	V	-

Connector No.	C11
Connector Name	REAR WHEEL SENSOR RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	V	-
2	P	-

Connector No.	C10
Connector Name	REAR WHEEL SENSOR LH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	B	-
2	W	-

ABFIA0722GB


A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >


[WITH VDC]

Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	L	-
14	P	-
15	BR	-
16	Y	-

Connector No.	B13
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
9	Y	-
10	BR	-
11	P	-
12	L	-

ABFIA0560GB


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009134665

OVERALL SEQUENCE



DETAILED FLOW

1. COLLECT INFORMATION FROM THE CUSTOMER

Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnostic worksheet. Refer to [BRC-58, "Diagnostic Work Sheet"](#).

>> GO TO 2.

2. PERFORM SELF-DIAGNOSTIC RESULT

Perform self-diagnostic result. Refer to [BRC-36, "CONSULT Function"](#).

Are any DTCs displayed?

YES >> Refer to [BRC-46, "DTC Index"](#).

NO >> GO TO 3.

3. CHECK SYMPTOM OPERATING CONDITION

Check that the symptom is a normal operating condition. Refer to [BRC-124, "Description"](#).

Is the symptom a normal operating condition?

YES >> Inspection End.

NO >> GO TO 4.

4. CHECK WARNING AND INDICATOR LAMPS OPERATION

DIAGNOSIS AND REPAIR WORKFLOW

[WITH VDC]

< BASIC INSPECTION >

Check ABS and brake warning lamps, VDC OFF and SLIP indicator lamps operation. Refer to [BRC-12. "System Description"](#).

Is ON/OFF timing normal?

YES >> GO TO 5.

NO >> Perform warning lamp diagnosis. Refer to [BRC-113. "Component Function Check"](#) (ABS warning lamp), [BRC-114. "Component Function Check"](#) (brake warning lamp), [BRC-115. "Component Function Check"](#) (VDC OFF indicator lamp) or [BRC-116. "Component Function Check"](#) (SLIP indicator lamp).

5. PERFORM DIAGNOSIS APPLICABLE TO THE SYMPTOM

Perform diagnosis applicable to the symptom. Refer to [BRC-117. "Symptom Table"](#).

>> GO TO 6.

6. FINAL CHECK

Perform self-diagnostic result again, and check that the malfunction is repaired. After checking, erase the self-diagnosis memory. Refer to [BRC-36. "CONSULT Function"](#).

>> Inspection End.

Diagnostic Work Sheet

INFOID:000000009134666

Customer name MR/MS	Model & Year	VIN	
Engine #	Trans.	Mileage	
Incident Date	Manuf. Date	In Service Date	
Symptoms	<input type="checkbox"/> Noise and vibration (from engine compartment)	<input type="checkbox"/> Warning/Indicator activate	<input type="checkbox"/> Firm pedal operation Large stroke pedal operation
	<input type="checkbox"/> Noise and vibration (from axle)	<input type="checkbox"/> TCS dose not work (Drive wheels slip when accelerating)	<input type="checkbox"/> ABS dose not work (Wheels lock when braking)
Engine conditions	<input type="checkbox"/> When starting <input type="checkbox"/> After starting		
Road conditions	<input type="checkbox"/> Low friction road (<input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other) <input type="checkbox"/> Bumps / potholes		
Driving conditions	<input type="checkbox"/> Full-acceleration <input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped		
Applying brake conditions	<input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually		
Other conditions	<input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Shift change <input type="checkbox"/> Other descriptions		

AWFIA1029GB

ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< BASIC INSPECTION >

[WITH VDC]

ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Description

INFOID:000000009134667

After replacing the ABS actuator and electric unit (control unit), perform the following procedures:

- Neutral position adjustment for the steering angle sensor
- Calibration of the decel G sensor

Work Procedure

INFOID:000000009134668

1. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

Perform the neutral position adjustment for the steering angle sensor.

>> Refer to [BRC-60. "Work Procedure"](#), GO TO 2.

2. PERFORM CALIBRATION OF THE DECEL G SENSOR

Perform calibration of the decel G sensor.

>> Refer to [BRC-62. "Work Procedure"](#).

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

< BASIC INSPECTION >

[WITH VDC]

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Description

INFOID:000000009134669

Refer to the table below to determine if adjustment of steering angle sensor neutral position is required.

×: Required –: Not required

Situation	Adjustment of steering angle sensor neutral position
Removing/Installing ABS actuator and electric unit (control unit)	—
Replacing ABS actuator and electric unit (control unit)	×
Removing/Installing steering angle sensor	×
Replacing steering angle sensor	×
Removing/Installing steering components	×
Replacing steering components	×
Removing/Installing suspension components	×
Replacing suspension components	×
Change tires to new ones	—
Tire rotation	—
Adjusting wheel alignment	×
Battery disconnection	×

Work Procedure

INFOID:000000009134670

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

CAUTION:

To adjust neutral position of steering angle sensor, make sure to use CONSULT.
(Adjustment cannot be done without CONSULT).

1. ALIGN THE VEHICLE STATUS

Stop vehicle with front wheels in straight-ahead position.

>> GO TO 2.

2. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

1. On the CONSULT screen, touch "WORK SUPPORT" and "ST ANG SEN ADJUSTMENT" in order.
2. Touch "START".

CAUTION:

Do not touch steering wheel while adjusting steering angle sensor.

3. After approximately 10 seconds, touch "END".

NOTE:

After approximately 60 seconds, it ends automatically.

4. Turn ignition switch OFF, then turn it ON again.

CAUTION:

Be sure to perform above operation.

>> GO TO 3.

3. CHECK DATA MONITOR

1. Run vehicle with front wheels in straight-ahead position, then stop.
2. Select "DATA MONITOR". Then make sure "STR ANGLE SIG" is within $0 \pm 2.5^\circ$.

Is the steering angle within the specified range?

YES >> GO TO 4.

NO >> Perform the neutral position adjustment for the steering angle sensor again, GO TO 1.

4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memory of the ABS actuator and electric unit (control unit) and ECM.

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

< BASIC INSPECTION >

[WITH VDC]

- ABS actuator and electric unit (control unit): Refer to [BRC-36. "CONSULT Function"](#).
- ECM: Refer to [EC-67. "CONSULT Function"](#).

Are the memories erased?

YES >> Inspection End.

NO >> Check the items indicated by the self-diagnosis.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

CALIBRATION OF DECEL G SENSOR

< BASIC INSPECTION >

[WITH VDC]

CALIBRATION OF DECEL G SENSOR

Description

INFOID:000000009134671

Refer to the table below to determine if calibration of the decel G sensor is required.

×: Required —: Not required

Situation	Calibration of decel G sensor
Removing/Installing ABS actuator and electric unit (control unit)	—
Replacing ABS actuator and electric unit (control unit)	×
Removing/Installing steering components	—
Replacing steering components	—
Removing/Installing suspension components	—
Replacing suspension components	—
Removing/Installing tire	—
Replacing tire	—
Tire rotation	—
Adjusting wheel alignment	—
Removing/Installing yaw rate/side/decel G sensor	×
Replacing yaw rate/side/decel G sensor	×

Work Procedure

INFOID:000000009134672

CALIBRATION OF DECEL G SENSOR

CAUTION:

To calibrate the decel G sensor, make sure to use CONSULT.
(Calibration cannot be done without CONSULT).

1. ALIGN THE VEHICLE STATUS

Stop vehicle with front wheels in straight-ahead position.

>> GO TO 2.

2. PERFORM CALIBRATION OF DECEL G SENSOR

1. On the CONSULT screen, touch "WORK SUPPORT" and "DECEL G SEN CALIBRATION" in order.
2. Touch "START".
3. After approximately 10 seconds, touch "END".

NOTE:

After approximately 60 seconds, it ends automatically.

4. Turn ignition switch OFF, then turn it ON again.

CAUTION:

Be sure to perform above operation.

>> GO TO 3.

3. CHECK DATA MONITOR

1. Run vehicle with front wheels in straight-ahead position, then stop.
2. Select "DATA MONITOR". Then make sure "DECEL G SEN" is within $\pm 0.08G$.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Perform calibration of decel G sensor again, GO TO 1.

4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memory of the ABS actuator and electric unit (control unit) and ECM.

- ABS actuator and electric unit (control unit): Refer to [BRC-36, "CONSULT Function"](#).
- ECM: Refer to [EC-67, "CONSULT Function"](#).

CALIBRATION OF DECEL G SENSOR

[WITH VDC]

< BASIC INSPECTION >

Are the memories erased?

YES >> Inspection End.

NO >> Check the items indicated by the self-diagnosis.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

DTC/CIRCUIT DIAGNOSIS

C1101, C1102, C1103, C1104 WHEEL SENSOR

DTC Logic

INFOID:000000009773689

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1101	RR RH SENSOR-1	<ul style="list-style-type: none">When power supply voltage of rear wheel sensor RH is low.When an open or shorted circuit is detected in rear wheel sensor RH circuit.	<ul style="list-style-type: none">Harness or connectorWheel sensorABS actuator and electric unit (control unit)
C1102	RR LH SENSOR-1	<ul style="list-style-type: none">When power supply voltage of rear wheel sensor LH is low.When an open or shorted circuit is detected in rear wheel sensor LH circuit.	
C1103	FR RH SENSOR-1	<ul style="list-style-type: none">When power supply voltage of front wheel sensor RH is low.When an open or shorted circuit is detected in front wheel sensor RH circuit.	
C1104	FR LH SENSOR-1	<ul style="list-style-type: none">When power supply voltage of front wheel sensor LH is low.When an open or shorted circuit is detected in front wheel sensor LH circuit.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

- Start engine and drive vehicle at approximately 21 km/h (13 MPH) or more for approximately 5 minutes.
- Perform self-diagnostic result.

Is DTC C1101, C1102, C1103 or C1104 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-64, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009773690

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1. CONFIRM DTC

Ⓜ With CONSULT

- Perform self-diagnostic result of ABS and record all active DTCs.
- Clear all DTCs.
- Perform DTC confirmation procedure. Refer to [BRC-64, "DTC Logic"](#).

Does DTC C1101, C1102, C1103 or C1104 reset?

- YES >> GO TO 2.
NO >> Refer to [GI-53, "Intermittent Incident"](#).

2. INSPECT WHEEL SENSOR

Inspect the suspect wheel sensor for damage or deformation.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace as necessary.

3. HARNESS AND CONNECTOR INSPECTION

C1101, C1102, C1103, C1104 WHEEL SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect ABS actuator and electric unit (control unit) connector E125 and wheel sensor connector of suspect wheel.
2. Check harness, connectors and terminals for corrosion, deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace as necessary.

4. CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Connect ABS active wheel sensor tester (J-45741) to wheel sensor using appropriate adapter.
2. Turn on the ABS active wheel sensor tester power switch.

NOTE:

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

3. Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash ON and OFF to indicate an output signal.

NOTE:

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

- YES >> GO TO 5.
 NO >> Replace the wheel sensor. Refer to [BRC-125, "Removal and Installation - Front Wheel Sensor"](#) or [BRC-127, "Removal and Installation - Rear Wheel Sensor"](#).

5. CHECK WIRING HARNESS FOR SHORT TO VOLTAGE

1. Turn ignition switch ON.
2. Check voltage between wheel sensor harness connector terminals of suspect wheel and ground.

Wheel Sensor			Ground	Voltage
Wheel	Connector	Terminal		
Front LH	E18	1	—	0V
		2		
Front RH	E43	1		
		2		
Rear LH	C10	1		
		2		
Rear RH	C11	1		
		2		

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Repair the circuit.

6. CHECK WIRING HARNESS FOR SHORT TO GROUND

1. Turn ignition switch OFF.
2. Check continuity between wheel sensor harness connector terminals of suspect wheel and ground.

Wheel Sensor			Ground	Continuity
Wheel	Connector	Terminal		

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

Wheel	Connector	Terminal	Continuity	Result
Front LH	E18	1	—	No
		2		
Front RH	E43	1		
		2		
Rear LH	C10	1		
		2		
Rear RH	C11	1		
		2		

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair the circuit.

7. CHECK WIRING HARNESS FOR SHORT BETWEEN CIRCUITS

Check continuity between wheel sensor harness connector terminals of suspect wheel.

Wheel Sensor		(+)	(-)	Continuity
Wheel	Connector	Terminal	Terminal	
Front LH	E18	1	2	No
Front RH	E43			
Rear LH	C10			
Rear RH	C11			

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair the circuit.

8. CHECK WIRING HARNESS FOR OPEN CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector E125 and harness connector of suspect wheel sensor.

Wheel sensor	ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
	Connector	Terminal	Connector	Terminal	
Front LH	E125	20	E18	1	Yes
		19		2	
Front RH		10	E43	1	
		9		2	
Rear LH		8	C10	1	
		7		2	
Rear RH		18	C11	1	
		17		2	

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair the circuit.

9. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between ABS actuator and electric unit (control unit) harness connector E125 terminal and ground.

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

ABS actuator and electric unit (control unit)		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E125	34	—	Ignition switch ON	Battery voltage
			Ignition switch OFF	0V

Is the inspection result normal?

YES >> GO TO 10.

NO >> Check the following:

- 10A fuse No. 49 located in the IPDM E/R
- Harness between ABS actuator and electric unit (control unit) and IPDM E/R

10. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between ABS actuator and electric unit (control unit) connector E125 terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E125	1	Ground	Yes
	2		

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair or replace malfunctioning components.

11. CHECK WHEEL SENSOR INPUT VOLTAGE

1. Connect ABS actuator and electric unit (control unit) connector E125.
2. Turn ignition switch ON.
3. Check voltage between suspect wheel sensor harness connector terminals.

Wheel Sensor		(+)	(-)	Voltage (Approx.)
Wheel	Connector	Terminal	Terminal	
Front LH	E18	1	2	Battery voltage
Front RH	E43			
Rear LH	C10			
Rear RH	C11			

Is the inspection result normal?

YES >> Replace wheel sensor. Refer to [BRC-125, "Removal and Installation - Front Wheel Sensor"](#) or [BRC-127, "Removal and Installation - Rear Wheel Sensor"](#). Then, GO TO 12.

NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

12. CONFIRM REPAIR

Ⓜ With CONSULT

1. Clear all DTCs.
2. Perform DTC confirmation procedure. Refer to [BRC-64, "DTC Logic"](#).

Does DTC C1105, C1106, C1107 or C1108 reset?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Inspection End.

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1105, C1106, C1107, C1108 WHEEL SENSOR

DTC Logic

INFOID:000000009773691

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1105	RR RH SENSOR-2	<ul style="list-style-type: none">When distance between rear wheel sensor RH and rear wheel sensor RH rotor is large.When installation of rear wheel sensor RH or rear wheel sensor RH rotor is not normal.	<ul style="list-style-type: none">Wheel sensorABS actuator and electric unit (control unit)Sensor rotor
C1106	RR LH SENSOR-2	<ul style="list-style-type: none">When distance between rear wheel sensor LH and rear wheel sensor LH rotor is large.When installation of rear wheel sensor LH or rear wheel sensor LH rotor is not normal.	
C1107	FR RH SENSOR-2	<ul style="list-style-type: none">When distance between front wheel sensor RH and front wheel sensor RH rotor is large.When installation of front wheel sensor RH or front wheel sensor RH rotor is not normal.	
C1108	FR LH SENSOR-2	<ul style="list-style-type: none">When distance between front wheel sensor LH and front wheel sensor LH rotor is large.When installation of front wheel sensor LH or front wheel sensor LH rotor is not normal.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓟ With CONSULT.

- Start engine and drive vehicle at approximately 21 km/h (13 MPH) or more for approximately 5 minutes.
- Perform self-diagnostic result.

Is DTC C1105, C1106, C1107 or C1108 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-68, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009773692

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1. CONFIRM DTC

Ⓟ With CONSULT

- Perform self-diagnostic result of ABS and record all active DTCs.
- Clear all DTCs.
- Perform DTC confirmation procedure. Refer to [BRC-64, "DTC Logic"](#).

Does DTC C1105, C1106, C1107 or C1108 reset?

- YES >> GO TO 2.
NO >> Refer to GI-XX, "Intermittent Incident".

2. CHECK TIRE PRESSURE AND TIRE WEAR

Check tires for excessive wear and proper inflation. Refer to [BRC-49, "Wiring Diagram"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace as necessary.

3. CHECK WHEEL SENSOR

Check wheel sensor for the following:

- Proper installation

C1105, C1106, C1107, C1108 WHEEL SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

- Physical damage
- Contamination

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace as necessary.

4.CHECK SENSOR ROTOR

Check sensor rotor for the following:

- Contamination
- Physical damage (missing teeth, cracks, etc.)
- Foreign material
- Looseness

Is the inspection result normal?

YES >> Replace the wheel sensor. Refer to [BRC-125. "Removal and Installation - Front Wheel Sensor"](#) or [BRC-127. "Removal and Installation - Rear Wheel Sensor"](#). Then, GO TO 5.

NO >> Repair or replace as necessary.

5.CONFIRM REPAIR

Ⓜ With CONSULT

1. Clear all DTCs.
2. Perform DTC confirmation procedure. Refer to [BRC-64. "DTC Logic"](#).

Does DTC C1105, C1106, C1107 or C1108 reset?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130. "Removal and Installation"](#).

NO >> Inspection End.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1109 POWER AND GROUND SYSTEM

DTC Logic

INFOID:000000009134677

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1109	BATTERY VOLTAGE [ABNORMAL]	<ul style="list-style-type: none">• When ignition voltage is 10 V or less.• When ignition voltage is 16 V or more.	<ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• Fuse• Ignition power supply system• Battery

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnostic result.

Is DTC C1109 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-70, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134678

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connectors.
3. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace as necessary.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) IGNITION POWER SUPPLY CIRCUIT

Check voltage between ABS actuator and electric unit (control unit) connector E125 terminal 34 and ground.

ABS actuator and electric unit (control unit)		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E125	34	—	Ignition switch ON	Battery voltage
			Ignition switch OFF	0V

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) BATTERY POWER SUPPLY CIRCUIT

Check voltage between ABS actuator and electric unit (control unit) connector E125 terminals 3, 4 and ground.

ABS actuator and electric unit (control unit)		Ground	Voltage (Approx.)
Connector	Terminal		

C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

E125	3	—	Battery voltage
	4		

A

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

B

4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between ABS actuator and electric unit (control unit) connector E125 terminals 1, 2 and ground.

C

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E125	1	Ground	Yes
	2		

D

E

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130. "Removal and Installation"](#).

NO >> Repair or replace malfunctioning components.

BRC

G

H

I

J

K

L

M

N

O

P

C1111 PUMP MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1111 PUMP MOTOR

DTC Logic

INFOID:000000009134679

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1111	PUMP MOTOR	When a malfunction is detected in motor or motor relay.	<ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• Fusible link• Battery power supply system

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch OFF.
2. Depress brake pedal 20 times or more.
3. Start the engine and wait for 3 minutes or more.
4. Perform self-diagnostic result.

Is DTC C1111 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-72. "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134680

Regarding Wiring Diagram information, refer to [BRC-49. "Wiring Diagram"](#).

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connectors.
3. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace as necessary.

2. CHECK ABS MOTOR AND MOTOR RELAY BATTERY POWER SUPPLY

Check voltage between ABS actuator and electric unit (control unit) connector E125 terminal 4 and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E125	4	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector E125 terminals 1, 2 and ground.

C1111 PUMP MOTOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E125	1	Ground	Yes
	2		

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#)
- NO >> Repair or replace harness.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1115 ABS SENSOR [ABNORMAL SIGNAL]

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1115 ABS SENSOR [ABNORMAL SIGNAL]

DTC Logic

INFOID:000000009134681

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1115	ABS SENSOR [ABNORMAL SIGNAL]	When difference in wheel speed between any wheel and others is detected while the vehicle is driven because of installation of tires other than specified.	<ul style="list-style-type: none">• Harness or connector• Wheel sensor• Sensor rotor• ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Start engine and drive vehicle at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnostic result.

Is DTC C1115 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-74, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134682

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

CAUTION:

Do not check between wheel sensor terminals.

1. CONNECTOR INSPECTION

1. Disconnect ABS actuator and electric unit (control unit) connector E125 and wheel sensor connector of wheel with DTC.
2. Check terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace as necessary.

2. CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Connect ABS active wheel sensor tester (J-45741) to wheel sensor using appropriate adapter.
2. Turn on the ABS active wheel sensor tester power switch.

NOTE:

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

3. Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash on and off to indicate an output signal.

NOTE:

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

- YES >> GO TO 3.
NO >> Replace the wheel sensor. Refer to [BRC-125, "Removal and Installation - Front Wheel Sensor"](#) or [BRC-127, "Removal and Installation - Rear Wheel Sensor"](#).

3. CHECK TIRES

Check the inflation pressure, wear and size of each tire.

Is the inspection result normal?

C1115 ABS SENSOR [ABNORMAL SIGNAL]

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

- YES >> GO TO 4.
- NO >> Adjust tire pressure, or replace tire(s).

4. CHECK WIRING HARNESS FOR SHORT CIRCUIT

Check continuity between wheel sensor connector terminals and ground of wheel with DTC.

Wheel Sensor			Ground	Continuity
Wheel	Connector	Terminal		
Front LH	E18	1	—	No
		2		
Front RH	E43	1		
		2		
Rear LH	C10	1		
		2		
Rear RH	C11	1		
		2		

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair the circuit.

5. CHECK WIRING HARNESS FOR OPEN CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector E125 and wheel sensor connector of wheel with DTC.

Wheel sensor	ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
	Connector	Terminal	Connector	Terminal	
Front LH	E125	20	E18	1	Yes
		19		2	
Front RH		10	E43	1	
		9		2	
Rear LH		8	C10	1	
		7		2	
Rear RH		18	C11	1	
		17		2	

Is the inspection result normal?

- YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).
- NO >> Repair the circuit.

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1116 STOP LAMP SWITCH

DTC Logic

INFOID:000000009134683

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1116	STOP LAMP SW	When stop lamp switch signal is not input when brake pedal operates.	<ul style="list-style-type: none">• Harness or connector• Stop lamp switch• ABS actuator and electric unit (control unit)• Resistor (models without ICC system)• Battery power supply system

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULT

Ⓜ With CONSULT

1. Erase self-diagnosis result for "ABS".
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.
CAUTION:
Never start the vehicle.
4. Depress the brake pedal several times.
5. Perform self-diagnosis for "ABS".

Is DTC "C1116" detected?

- YES >> Refer to [BRC-76. "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134684

Regarding Wiring Diagram information, refer to [BRC-49. "Wiring Diagram"](#).

NOTE:

DTC "C1116" may be detected when the brake pedal and the accelerator pedal are simultaneously depressed for 1 minute or more while driving the vehicle. This is not a malfunction.

1. CHECK STOP LAMP ILLUMINATION

1. Turn ignition switch ON.
2. Depress brake pedal and check that stop lamps turn ON.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Check stop lamp system. Refer to [EXL-81. "Wiring Diagram"](#).

2. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector E125 and stop lamp switch connector E38.
3. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace as necessary.

3. CHECK DATA MONITOR (1)

Ⓜ With CONSULT

1. Erase self-diagnosis result for "ABS".
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.

C1116 STOP LAMP SWITCH

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

CAUTION:

Never start the vehicle.

4. Select "ABS", "DATA MONITOR" and "STOP LAMP SW". Check that data monitor displays "On" or "Off" when brake pedal is depressed or released.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 4.

4.CHECK STOP LAMP SWITCH CLEARANCE


1. Turn the ignition switch OFF.
2. Check stop lamp switch clearance. Refer to [BR-7. "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Adjust stop lamp switch clearance. Refer to [BR-15. "Adjustment"](#). GO TO 5.

5.CHECK DATA MONITOR (2)

 With CONSULT

1. Erase self-diagnosis result for "ABS".
2. Turn the ignition switch OFF, and wait 10 seconds or more.
3. Start the engine.

CAUTION:

Never start the vehicle.

4. Select "ABS", "DATA MONITOR" and "STOP LAMP SW". Check that data monitor displays "On" or "Off" when brake pedal is depressed or released.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 6.

6.CHECK STOP LAMP SWITCH

Check stop lamp switch. Refer to [BRC-78. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace stop lamp switch. Refer to [BR-20. "Removal and Installation"](#).

7.CHECK STOP LAMP SWITCH CIRCUIT (1)

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage (Approx.)
Connector	Terminal			
E125	5	Ground	Brake pedal depressed	Battery voltage
			Brake pedal not depressed	0 V

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130. "Removal and Installation"](#).

NO >> GO TO 8.

8.CHECK STOP LAMP SWITCH CIRCUIT (2)

1. Turn the ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector and stop lamp switch harness connector.

C1116 STOP LAMP SWITCH

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

ABS actuator and electric unit (control unit)		Stop lamp switch		Continuity
Connector	Terminal	Connector	Terminal	
E125	5	E38	4 ^{*1}	Yes
			2 ^{*2}	

*1: With ICC

*2: Without ICC

4. Check continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E125	5	Ground	No

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000009134685

1. CHECK STOP LAMP SWITCH

1. Turn the ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check continuity when stop lamp switch is operated.

Stop lamp switch Terminal	Condition	Continuity
1 – 2 ^{*1} 3 – 4 ^{*2}	When stop lamp switch is released (When brake pedal is depressed)	Yes
	When stop lamp switch is pressed (When brake pedal is released)	No

*1: Without ICC system

*2: With ICC system

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace stop lamp switch. Refer to [BR-20, "Removal and Installation"](#).

C1120, C1122, C1124, C1126 ABS IN VALVE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1120, C1122, C1124, C1126 ABS IN VALVE SYSTEM

DTC Logic

INFOID:000000009134686

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1120	FR LH IN ABS SOL	When a malfunction is detected in front LH ABS IN valve.	<ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• Fusible link• Battery power supply system
C1122	FR RH IN ABS SOL	When a malfunction is detected in front RH ABS IN valve.	
C1124	RR LH IN ABS SOL	When a malfunction is detected in rear LH ABS IN valve.	
C1126	RR RH IN ABS SOL	When a malfunction is detected in rear RH ABS IN valve.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

④ With CONSULT.

1. Turn ignition switch OFF to ON.
2. Perform self-diagnostic result.

Is DTC C1120, C1122, C1124 or C1126 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-79, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134687

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connectors.
3. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace as necessary.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) BATTERY POWER SUPPLY

Check voltage between ABS actuator and electric unit (control unit) connector E125 terminal 3 and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E125	3	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector E125 terminals 1, 2 and ground.

C1120, C1122, C1124, C1126 ABS IN VALVE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E125	1	Ground	Yes
	2		

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning components.

C1121, C1123, C1125, C1127 ABS OUT VALVE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1121, C1123, C1125, C1127 ABS OUT VALVE SYSTEM

DTC Logic

INFOID:000000009134688

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1121	FR LH OUT ABS SOL	When a malfunction is detected in front LH ABS OUT valve.	<ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• Fusible link• Battery power supply system
C1123	FR RH OUT ABS SOL	When a malfunction is detected in front RH ABS OUT valve.	
C1125	RR LH OUT ABS SOL	When a malfunction is detected in rear LH ABS OUT valve.	
C1127	RR RH OUT ABS SOL	When a malfunction is detected in rear RH ABS OUT valve.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch OFF to ON.
2. Perform self-diagnostic result.

Is DTC C1121, C1123, C1125 or C1127 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-81, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134689

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connectors.
3. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace as necessary.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) BATTERY POWER SUPPLY

Check voltage between ABS actuator and electric unit (control unit) connector E125 terminal 3 and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E125	3	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector E125 terminals 1, 2 and ground.

C1121, C1123, C1125, C1127 ABS OUT VALVE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E125	1	Ground	Yes
	2		

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning components.

C1130 ENGINE SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1130 ENGINE SIGNAL

DTC Logic

INFOID:000000009134690

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1130	ENGINE SIGNAL 1	When a malfunction is detected in ECM system.	<ul style="list-style-type: none">• ECM• ABS actuator and electric unit (control unit)• CAN communication line

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch OFF to ON.
2. Perform self-diagnostic result.

Is DTC C1130 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-83, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134691

1. CHECK SELF-DIAGNOSTIC RESULT FOR ENGINE SYSTEM

Ⓜ With CONSULT.

Perform self-diagnostic result. Refer to [EC-67, "CONSULT Function"](#).

Are any ECM DTCs detected?

- YES >> Refer to [EC-97, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK SELF-DIAGNOSTIC RESULT FOR ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Ⓜ With CONSULT.

1. Perform self-diagnostic result and erase DTCs.
2. Turn ignition switch OFF.
3. Start engine and drive vehicle for a short period of time.
4. Check that malfunction indicator lamp (MIL) turns OFF.
5. Stop vehicle and perform self-diagnostic result.

Is DTC C1130 detected?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).
NO >> Check pin terminals and connection of connectors for abnormal conditions. Repair or replace malfunctioning components.

C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1140 ACTUATOR RELAY SYSTEM

DTC Logic

INFOID:000000009134692

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1140	ACTUATOR RLY	When a malfunction is detected in actuator relay.	<ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• Fusible link• Battery power supply system

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch OFF to ON.
2. Perform self-diagnostic result.

Is DTC C1140 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-84, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134693

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connectors.
3. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace as necessary.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) BATTERY POWER SUPPLY

Check voltage between ABS actuator and electric unit (control unit) connector E125 terminals 3, 4 and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E125	3	Ground	Battery voltage
	4		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector E125 terminals 1, 2 and ground.

C1140 ACTUATOR RELAY SYSTEM

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E125	1	Ground	Yes
	2		

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning components.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1142 PRESS SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1142 PRESS SENSOR

DTC Logic

INFOID:000000009134694

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1142	PRESS SEN CIRCUIT	When a malfunction is detected in master cylinder pressure sensor.	<ul style="list-style-type: none">• Stop lamp switch system• ABS actuator and electric unit (control unit)• Brake system

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch OFF to ON.
2. Perform self-diagnostic result.

Is DTC C1142 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-86, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134695

1. CHECK STOP LAMP SWITCH SYSTEM

Check stop lamp switch system. Refer to [BRC-76, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace malfunctioning components.

2. CHECK BRAKE FLUID LEAKAGE

Check brake fluid leakage. Refer to [BR-8, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3. CHECK BRAKE PEDAL

Check brake pedal. Refer to [BR-7, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace malfunctioning components.

4. CHECK HYDRAULIC BOOSTER ASSEMBLY

Check hydraulic booster assembly. Refer to [BR-10, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace malfunctioning components.

5. CHECK SELF DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch OFF to ON.
2. Perform self-diagnostic result.
3. Erase DTCs.
4. Start engine and drive vehicle for a short period of time.
5. Turn ignition switch OFF to ON.

C1142 PRESS SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

6. Perform self-diagnostic result.

Is DTC C1142 detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130. "Removal and Installation"](#)

NO >> Inspection End.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1143 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1143 STEERING ANGLE SENSOR

DTC Logic

INFOID:000000009134696

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1143	ST ANG SEN CIRCUIT	When a malfunction is detected in steering angle sensor.	<ul style="list-style-type: none">• Harness or connector• Steering angle sensor• ABS actuator and electric unit (control unit)• Fuse• Ignition power supply system• CAN communication line

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSTIC RESULT

④With CONSULT.

1. Turn ignition switch OFF to ON.
2. Perform self-diagnostic result.

Is DTC C1143 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-88, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134697

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1.CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) and steering angle sensor connectors.
3. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace as necessary.

2.CHECK STEERING ANGLE SENSOR MOUNTING CONDITION

Check steering angle sensor mounting condition.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3.CHECK STEERING ANGLE SENSOR POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect steering angle sensor connector.
3. Turn ignition switch ON.
4. Check voltage between steering angle sensor connector M54 terminal 4 and ground.

Steering angle sensor		—	Voltage (Approx.)
Connector	Terminal		
M54	4	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 5.

C1143 STEERING ANGLE SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

NO >> GO TO 4.

4. CHECK STEERING ANGLE SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector E119.
3. Check continuity between steering angle sensor connector M54 terminal 4 and IPDM E/R connector E119 terminal 35.

Steering angle sensor		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
M54	4	E119	35	Yes

4. Check continuity between steering angle sensor connector M54 terminal 4 and ground.

Steering angle sensor		—	Continuity
Connector	Terminal		
M54	4	Ground	No

Is the inspection result normal?

- YES >> Perform trouble diagnosis for ignition power supply.
NO >> Repair or replace malfunctioning components.

5. CHECK STEERING ANGLE SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between steering angle sensor connector M54 terminal 1 and ground.

Steering angle sensor		—	Continuity
Connector	Terminal		
M54	1	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair or replace malfunctioning components.

6. CHECK CAN COMMUNICATION LINE

Check "STRG BRANCH LINE CIRCUIT". Refer to [LAN-168, "Diagnosis Procedure"](#) (Type 1) or [LAN-190, "Diagnosis Procedure"](#) (Type 2).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning components.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

DTC Logic

INFOID:000000009134698

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1144	ST ANG SEN SIGNAL	When neutral position adjustment of steering angle sensor is not complete.	<ul style="list-style-type: none">• Harness or connector• Steering angle sensor• ABS actuator and electric unit (control unit)• Incomplete neutral position adjustment of steering angle sensor

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓢ With CONSULT.

1. Turn ignition switch OFF to ON.
2. Perform self-diagnostic result.

Is DTC C1144 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-90, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134699

1. ADJUST THE NEUTRAL POSITION OF STEERING ANGLE SENSOR

Perform neutral position adjustment of steering angle sensor. Refer to [BRC-60, "Work Procedure"](#).

>> GO TO 2.

2. CHECK SELF-DIAGNOSTIC RESULT

Ⓢ With CONSULT.

Perform self-diagnostic result.

Is DTC C1144 detected?

- YES >> GO TO 3.
NO >> Inspection End.

3. CHECK STEERING ANGLE SENSOR SYSTEM

Check steering angle sensor system. Refer to [BRC-88, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning components.

C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

DTC Logic

INFOID:000000009134700

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1145	YAW RATE SENSOR	<ul style="list-style-type: none">When a malfunction is detected in yaw rate signal.When yaw rate signal is not continuously received for 2 seconds or more.When side G signal is not continuously received for 2 seconds or more.When decel G signal is not continuously received for 2 seconds or more.	<ul style="list-style-type: none">Harness or connectorYaw rate/side/decel G sensorABS actuator and electric unit (control unit)Ignition power supply systemFuse
C1146	SIDE G-SEN CIRCUIT	When a malfunction is detected in side/decel G signal.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

- Turn ignition switch OFF to ON.
- Perform self-diagnostic result.

Is DTC C1145 or C1146 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-91. "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134701

Regarding Wiring Diagram information, refer to [BRC-49. "Wiring Diagram"](#).

CAUTION:

- A malfunction in yaw rate/side/decel G sensor system may be detected when the vehicle sharply turns during a spin turn, acceleration turn or drift driving while VDC function is OFF (VDC OFF indicator lamp is in ON status). This is not a malfunction if the status returns to normal after engine is started again. In that case, erase self-diagnosis result memory using CONSULT.
- When the engine is in running status and the vehicle is on a turntable at the entrance of parking lot or on a moving unit, SLIP indicator lamp may turn ON and "ABS" self-diagnosis may display "YAW RATE SENSOR". In this case, yaw rate sensor is not malfunctioning. The status returns to normal when the vehicle leaves the turntable or moving unit and the engine is started again. In that case, erase self-diagnosis result memory using CONSULT.

1. CONNECTOR INSPECTION

- Turn ignition switch OFF.
- Disconnect ABS actuator and electric unit (control unit) and yaw rate/side/decel G sensor connectors.
- Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace as necessary.

2. CHECK YAW RATE/SIDE/DECEL G SENSOR MOUNTING CONDITION

Check yaw rate/side/decel G sensor mounting condition. Refer to [BRC-132. "Exploded View"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3. CHECK YAW RATE/SIDE/DECEL G SENSOR POWER SUPPLY

C1145, C1146 YAW RATE/SIDE/DECCEL G SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect yaw rate/side/decel G sensor connector.
3. Turn the ignition switch ON.
4. Check voltage between yaw rate/side/decel G sensor connector M160 terminal 4 and ground.

Yaw rate/side/decel G sensor		—	Voltage (Approx.)
Connector	Terminal		
M160	4	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair circuit between splice and yaw rate/side/decel G sensor terminal 4.

4.CHECK YAW RATE/SIDE/DECCEL G SENSOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between yaw rate/side/decel G sensor connector M160 terminal 1 and ground.

Yaw rate/side/decel G sensor		—	Continuity
Connector	Terminal		
M160	1	Ground	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5.CHECK COMMUNICATION LINES

1. Disconnect ABS actuator and electric unit (control unit) connector E125.
2. Check continuity between yaw rate/side/decel G sensor connector M160 terminals 2, 3 and ABS actuator and electric unit (control unit) connector E125 terminals 6, 16.

Yaw rate/side/decel G sensor		ABS actuator and electric unit (control unit)		Continuity
Connector	Terminal	Connector	Terminal	
M160	2	E125	6	Yes
	3		16	

3. Check continuity between yaw rate/side/decel G sensor connector M160 terminals 2, 3 and ground.

Yaw rate/side/decel G sensor		Ground	Continuity
Connector	Terminal		
M160	2	—	No
	3		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace malfunctioning components.

6.CHECK COMMUNICATION LINES RESISTANCE

1. Connect ABS actuator and electric unit (control unit) connector E125.
2. Check resistance between yaw rate/side/decel G sensor connector M160 terminals 2, 3.

Yaw rate/side/decel G sensor		Resistance
Connector	Terminal	
M160	2	100 – 140 Ω
	3	

Is the inspection result normal?

C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

YES >> Replace yaw rate/side/decel G sensor. Refer to [BRC-132, "Removal and Installation"](#).
NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1155 BRAKE FLUID LEVEL SWITCH

DTC Logic

INFOID:000000009134702

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1155	BR FLUID LEVEL LOW	When brake fluid level low signal is detected.	<ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• Brake fluid level switch• Combination meter

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓟ With CONSULT.

1. Turn ignition switch OFF to ON and wait 1 minute or more.
2. Perform self-diagnostic result.

Is DTC C1155 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-94, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134703

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1. CHECK BRAKE FLUID LEVEL

1. Turn the ignition switch OFF.
2. Check brake fluid level. Refer to [BR-8, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Refill brake fluid. Refer to [BR-16, "Drain and Refill"](#).

2. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect combination meter connector M24 and brake fluid level switch connector E21.
3. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace as necessary.

3. CHECK BRAKE FLUID LEVEL SWITCH

Check brake fluid level switch. Refer to [BRC-95, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace reservoir tank. Refer to [BR-29, "Disassembly and Assembly"](#).

4. CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Disconnect combination meter harness connector.
4. Check continuity between brake fluid level switch harness connector and combination meter harness connector.

C1155 BRAKE FLUID LEVEL SWITCH

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

Brake fluid level switch		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
E21	1	M24	25	Yes

5. Check continuity between brake fluid level switch harness connector and ground.

Brake fluid level switch		—	Continuity
Connector	Terminal		
E21	1	Ground	No

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5.CHECK BRAKE FLUID LEVEL SWITCH GROUND CIRCUIT

Check continuity between brake fluid level switch harness connector and ground.

Brake fluid level switch		—	Continuity
Connector	Terminal		
E21	2	Ground	Yes

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace malfunctioning components.

6.CHECK COMBINATION METER

Check if indication and operation of combination meter are normal. Refer to [MWI-9, "METER SYSTEM : System Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Replace combination meter. Refer to [MWI-95, "Removal and Installation"](#).

Component Inspection

INFOID:000000009134704

1.CHECK BRAKE FLUID LEVEL SWITCH

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Check continuity between terminals of brake fluid level switch.

Brake fluid level switch	Condition	Continuity
Terminal		
1 – 2	When brake fluid level in reservoir tank is within the specified level.	No
	When brake fluid level in reservoir tank is less than the specified level.	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace reservoir tank. Refer to [BR-29, "Disassembly and Assembly"](#).

C1160 DECEL G SEN SET

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1160 DECEL G SEN SET

DTC Logic

INFOID:000000009134705

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1160	DECEL G SEN SET	When calibration of yaw rate/side/decel G sensor is not complete.	<ul style="list-style-type: none">• Yaw rate/side/decel G sensor• Harness or connector• ABS actuator and electric unit (control unit)• Decel G sensor calibration is not performed

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSTIC RESULT

ⓂWith CONSULT.

1. Turn ignition switch OFF to ON.
2. Perform self-diagnostic result.

Is DTC C1160 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-96, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134706

1.DECEL G SENSOR CALIBRATION

Perform decel G sensor calibration. Refer to [BRC-62, "Work Procedure"](#).

>> GO TO 2.

2.CHECK SELF-DIAGNOSTIC RESULT

ⓂWith CONSULT.

Perform self-diagnostic result.

Is DTC C1160 detected?

- YES >> GO TO 3.
NO >> Inspection End.

3.CHECK YAW RATE/SIDE/DECEL G SENSOR SYSTEM

Check yaw rate/side/decel G sensor system. Refer to [BRC-91, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).
NO >> Repair or replace malfunctioning components.

C1164, C1165 CV SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1164, C1165 CV SYSTEM

DTC Logic

INFOID:000000009134707

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1164	CV 1	When a malfunction is detected in cut valve 1.	<ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• Fusible link• Battery power supply system
C1165	CV 2	When a malfunction is detected in cut valve 2.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓟ With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

Is DTC "C1164" or "C1165" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-97, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134708

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connectors.
3. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace as necessary.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) BATTERY POWER SUPPLY

Check voltage between ABS actuator and electric unit (control unit) connector E125 terminals 3, 4 and ground.

ABS actuator and electric unit (control unit)		—	Voltage (Approx.)
Connector	Terminal		
E125	3	Ground	Battery voltage
	4		

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) connector E125 terminals 1, 2 and ground.

C1164, C1165 CV SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E125	1	Ground	Yes
	2		

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning components.

C1170 VARIANT CODING

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

C1170 VARIANT CODING

DTC Logic

INFOID:000000009134709

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1170	VARIANT CODING	When the information in ABS actuator and electric unit (control unit) is not the same.	ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

 With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

Is DTC C1170 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-99, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134710

1. REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Replace ABS actuator and electric unit (control unit) even if other DTCs are displayed with "VARIANT CODING" in self diagnostic result.

- >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

C1197 VACUUM SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

C1197 VACUUM SENSOR

DTC Logic

INFOID:000000009134711

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1197	VACUUM SENSOR	When a malfunction is detected in vacuum sensor.	<ul style="list-style-type: none">• Harness or connector• Vacuum sensor (brake booster)• Vacuum piping• ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn the ignition switch ON.
2. Perform self-diagnostic result.

Is DTC C1197 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-100, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134712

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1. CHECK BRAKE BOOSTER

1. Turn the ignition switch OFF.
2. Check brake booster. Refer to [BR-10, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace brake booster. Refer to [BR-31, "Removal and Installation"](#).

2. CHECK VACUUM PIPING

Check vacuum piping. Refer to [BR-33, "Exploded View"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace vacuum piping. Refer to [BR-33, "Removal and Installation"](#).

3. CHECK VACUUM SENSOR CIRCUIT

1. Disconnect vacuum sensor harness connector.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check continuity between vacuum sensor harness connector and ABS actuator and electric unit (control unit) harness connector.

Vacuum sensor		ABS actuator and electric unit (control unit)		Continuity
Connector	Terminal	Connector	Terminal	
E167	1	E125	13	Yes
	2		32	
	3		28	

4. Check continuity between vacuum sensor harness connector and ground.

C1197 VACUUM SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

Vacuum sensor		—	Continuity
Connector	Terminal		
E167	1	Ground	No
	2		
	3		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

4.CHECK TERMINAL

- Check vacuum sensor pin terminals for damage or loose connection with harness connector.
- Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5.REPLACE VACUUM SENSOR

④ With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Replace vacuum sensor. Refer to [BR-31, "Removal and Installation"](#).

CAUTION:

Always replace brake booster because vacuum sensor cannot be disassembled.

3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF.
5. Start engine.
6. Perform self-diagnosis for "ABS".

Is DTC "C1197" detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Inspection End.

C1198 VACUUM SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C1198 VACUUM SENSOR

DTC Logic

INFOID:000000009134713

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1198	VACUUM SEN CIR	<ul style="list-style-type: none">When an open circuit is detected in vacuum sensor circuit.When a short circuit is detected in vacuum sensor circuit.When a malfunction is detected in vacuum sensor noise.	<ul style="list-style-type: none">Harness or connectorVacuum sensor (brake booster)ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

- Turn the ignition switch ON.
- Perform self-diagnostic result.

Is DTC C1198 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-102, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134714

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1. CHECK VACUUM SENSOR CIRCUIT

- Turn the ignition switch OFF.
- Disconnect vacuum sensor harness connector.
- Disconnect ABS actuator and electric unit (control unit) harness connector.
- Check continuity between vacuum sensor harness connector and ABS actuator and electric unit (control unit) harness connector.

Vacuum sensor		ABS actuator and electric unit (control unit)		Continuity
Connector	Terminal	Connector	Terminal	
E167	1	E125	13	Yes
	2		32	
	3		28	

- Check continuity between vacuum sensor harness connector and ground.

Vacuum sensor		—	Continuity
Connector	Terminal		
E167	1	Ground	No
	2		
	3		

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace malfunctioning components.

2. CHECK TERMINAL

C1198 VACUUM SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

- Check vacuum sensor pin terminals for damage or loose connection with harness connector.
- Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3.REPLACE VACUUM SENSOR

ⓂWith CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Replace vacuum sensor. Refer to [BR-31, "Removal and Installation"](#).

CAUTION:

Always replace brake booster because vacuum sensor cannot be disassembled.

3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF.
5. Start engine.
6. Perform self-diagnosis for "ABS".

Is DTC "C1198" detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Inspection End.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

C1199 BRAKE BOOSTER

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

C1199 BRAKE BOOSTER

DTC Logic

INFOID:000000009134715

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C1199	BRAKE BOOSTER	When brake booster vacuum is approx. 0 kPa (0 mm-Hg) during engine running.	<ul style="list-style-type: none">• Harness or connector• Vacuum sensor (brake booster)• Vacuum piping• ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn the ignition switch ON.
2. Perform self-diagnostic result.

Is DTC C1199 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-104, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134716

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1. CHECK BRAKE BOOSTER

1. Turn the ignition switch OFF.
2. Check brake booster. Refer to [BR-10, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace brake booster. Refer to [BR-31, "Removal and Installation"](#).

2. CHECK VACUUM PIPING

Check vacuum piping. Refer to [BR-33, "Exploded View"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace vacuum piping. Refer to [BR-33, "Removal and Installation"](#).

3. CHECK VACUUM SENSOR CIRCUIT

1. Disconnect vacuum sensor harness connector.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check continuity between vacuum sensor harness connector and ABS actuator and electric unit (control unit) harness connector.

Vacuum sensor		ABS actuator and electric unit (control unit)		Continuity
Connector	Terminal	Connector	Terminal	
E167	1	E125	13	Yes
	2		32	
	3		28	

4. Check continuity between vacuum sensor harness connector and ground.

C1199 BRAKE BOOSTER

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

Vacuum sensor		—	Continuity
Connector	Terminal		
E167	1	Ground	No
	2		
	3		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

4. CHECK TERMINAL

- Check vacuum sensor pin terminals for damage or loose connection with harness connector.
- Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5. REPLACE VACUUM SENSOR

Ⓜ With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Replace vacuum sensor. Refer to [BR-31, "Removal and Installation"](#).

CAUTION:

Always replace brake booster because vacuum sensor cannot be disassembled.

3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF.
5. Start engine.
6. Perform self-diagnosis for "ABS".

Is DTC "C1199" detected?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Inspection End.

C119A VACUUM SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

C119A VACUUM SENSOR

DTC Logic

INFOID:000000009134717

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
C119A	VACUUM SEN VOLT	When a malfunction is detected in supply power voltage of vacuum sensor.	<ul style="list-style-type: none">• Harness or connector• Vacuum sensor (brake booster)• ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn the ignition switch ON.
2. Perform self-diagnostic result.

Is DTC C119A detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-106. "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134718

Regarding Wiring Diagram information, refer to [BRC-49. "Wiring Diagram"](#).

1. CHECK VACUUM SENSOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect vacuum sensor harness connector.
3. Check voltage between vacuum sensor harness connector and ground.

Vacuum sensor		—	Voltage (Approx.)
Connector	Terminal		
E167	3	Ground	0 V

4. Turn the ignition switch ON.
CAUTION:
Never start engine.
5. Check voltage between vacuum sensor harness connector and ground.

Vacuum sensor		—	Voltage (Approx.)
Connector	Terminal		
E167	3	Ground	4.75 V – 5.25 V

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK VACUUM SENSOR POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check continuity between vacuum sensor harness connector and ABS actuator and electric unit (control unit) harness connector.

C119A VACUUM SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

Vacuum sensor		ABS actuator and electric unit (control unit)		Continuity
Connector	Terminal	Connector	Terminal	
E167	3	E125	28	Yes

4. Check continuity between vacuum sensor harness connector and ground.

Vacuum sensor		—	Continuity
Connector	Terminal		
E167	3	Ground	No

Is the inspection result normal?

YES >> Perform diagnosis of ABS actuator and electric unit (control unit) power supply and ground circuit.

Refer to [BRC-70, "Diagnosis Procedure"](#).

NO >> Repair or replace malfunctioning components.

3. CHECK VACUUM SENSOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check continuity between vacuum sensor harness connector and ground.

Vacuum sensor		—	Continuity
Connector	Terminal		
E167	2	Ground	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

4. CHECK TERMINAL

- Check vacuum sensor pin terminals for damage or loose connection with harness connector.
- Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning components.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

U1000 CAN COMM CIRCUIT

Description

INFOID:000000009134719

CAN communication allows a high rate of information transmission through the two communication lines (CAN-H line and CAN-L line) connecting various control units in the system. Each control unit transmits/ receives data but selectively reads required data only.

DTC Logic

INFOID:000000009134720

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
U1000	CAN COMM CIRCUIT	When CAN communication signal is not continuously received for 2 seconds or more	CAN communication system malfunction

Diagnosis Procedure

INFOID:000000009134721

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓔ With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

Is DTC U1000 detected?

- YES >> Proceed to diagnosis procedure. Refer to [LAN-26, "Trouble Diagnosis Flow Chart"](#).
NO >> Refer to [GI-53, "Intermittent Incident"](#).

U0424 HVAC CAN CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

U0424 HVAC CAN CIRCUIT 1

Description

INFOID:000000009134722

ADAS control unit reads status of signal that is transmitted from A/C auto AMP. to ADAS control unit.

DTC Logic

INFOID:000000009134723

DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
U0424	HVAC CAN CIR 1	When signal that is transmitted from A/C auto AMP. is not the latest information	A/C auto AMP.

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓟ With CONSULT.

1. Turn the ignition switch ON.
2. Perform self-diagnostic result for "ICC/ADAS".

Is DTC U0424 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-109. "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009134724

1. PERFORM ADAS CONTROL UNIT SELF-DIAGNOSIS

Ⓟ With CONSULT

Perform self-diagnosis for "ICC/ADAS".

Are DTC "U1010" and "U0424" simultaneously detected?

- YES >> Refer to [DAS-76. "Diagnosis Procedure"](#).
NO >> Replace A/C auto AMP. Refer to [HAC-163. "Removal and Installation"](#).

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

PARKING BRAKE SWITCH

Component Function Check

INFOID:000000009134725

1.COMBINATION METER INPUT SIGNAL

1. Start engine.
2. Check PKB SW in DATA MONITOR while applying and releasing the parking brake.

Condition **CONSULT**
Parking brake applied : **ON**
Parking brake released : **OFF**

>> Inspection End.

Diagnosis Procedure

INFOID:000000009134726

Regarding Wiring Diagram information, refer to [MWI-29, "Wiring Diagram - With Automatic Drive Positioner"](#) or [MWI-48, "Wiring Diagram - Without Automatic Drive Positioner"](#).

1.CHECK PARKING BRAKE SWITCH CIRCUIT

1. Disconnect combination meter harness connector M24 and parking brake switch harness connector E52.
2. Check continuity between combination meter harness connector M24 terminal 12 and parking brake switch harness connector E52 terminal 1.

12 - 1 : **Continuity should exist.**

3. Check continuity between combination meter harness connector M24 terminal 12 and ground.

12 - Ground : **Continuity should not exist.**

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace harness or connectors.

Component Inspection

INFOID:000000009134727

1.CHECK PARKING BRAKE SWITCH

Check continuity between parking brake switch terminal 1 and switch case ground.

Component	Terminal	Condition	Continuity
Parking brake switch	1	Parking brake applied	Yes
		Parking brake released	No

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace parking brake switch. Refer to [PB-7, "Exploded View"](#).

VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

VDC OFF SWITCH

Component Function Check

INFOID:000000009134728

1.CHECK VDC OFF SWITCH OPERATION

Check that VDC OFF indicator lamp in combination meter turns ON/OFF when VDC OFF switch is operated.

Is the inspection result normal?

YES >> Inspection End.

NO >> Proceed to diagnosis procedure. Refer to [BRC-111, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009134729

Regarding Wiring Diagram information, refer to [BRC-49, "Wiring Diagram"](#).

1.CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector E125 and VDC OFF switch connector M71.
3. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace as necessary.

2.CHECK VDC OFF SWITCH

Check VDC OFF switch. Refer to [BRC-112, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace VDC OFF switch.

3.CHECK VDC OFF SWITCH SIGNAL

ⓂWith CONSULT.

1. Connect ABS actuator and electric unit (control unit) connector E125 and VDC OFF switch connector M71.
2. Turn ignition switch ON.
3. In "DATA MONITOR" select "OFF SW" and check VDC OFF switch signal.

Condition	DATA MONITOR
VDC OFF switch is pressed and released	On
VDC OFF switch is pressed and released again	Off

Is the inspection result normal?

YES >> Refer to [BRC-57, "Work Flow"](#).

NO >> GO TO 4.

4.CHECK VDC OFF SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector E125 and VDC OFF switch connector M71.
3. Check continuity between ABS actuator and electric unit (control unit) connector E125 terminal 30 and VDC OFF switch connector M71 terminal 1.

ABS actuator and electric unit (control unit)		VDC OFF switch		Continuity
Connector	Terminal	Connector	Terminal	
E125	30	M71	1	Yes

A
B
C
D
E

BRC

G
H
I
J
K
L

M
N
O

P

VDC OFF SWITCH

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

4. Check continuity between ABS actuator and electric unit (control unit) connector terminal E125 terminal 30 and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E125	30	Ground	No

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5.CHECK VDC OFF SWITCH GROUND CIRCUIT

Check continuity between VDC OFF switch connector M71 terminal 2 and ground.

VDC OFF switch		—	Continuity
Connector	Terminal		
M71	2	Ground	Yes

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000009134730

1.CHECK VDC OFF SWITCH

1. Turn ignition switch OFF.
2. Disconnect VDC OFF switch connector.
3. Check continuity between terminals of VDC OFF switch connector.

VDC OFF switch terminals	Condition	Continuity
1 – 2	VDC OFF switch pressed	Yes
	VDC OFF switch released	No

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace VDC OFF switch.

ABS WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

ABS WARNING LAMP

Component Function Check

INFOID:000000009134731

1.CHECK ABS WARNING LAMP FUNCTION

Check that ABS warning lamp in combination meter turns ON for approximately 2 seconds after ignition switch is turned ON.

Is the inspection result normal?

YES >> Inspection End.

NO >> Proceed to diagnosis procedure. Refer to [BRC-113, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009134732

1.PERFORM THE SELF-DIAGNOSIS

 With CONSULT.

Perform self-diagnostic result.

Are any DTCs detected?

YES >> Refer to [BRC-46, "DTC Index"](#).

NO >> GO TO 2.

2.CHECK COMBINATION METER

Check if indication and operation of combination meter are normal. Refer to [MWI-9, "METER SYSTEM : System Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Replace combination meter. Refer to [MWI-95, "Removal and Installation"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

BRAKE WARNING LAMP

Component Function Check

INFOID:000000009134733

1. CHECK BRAKE WARNING LAMP FUNCTION (1)

Check that brake warning lamp in combination meter turns ON for approximately 2 seconds after ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-114, "Diagnosis Procedure"](#).

2. CHECK BRAKE WARNING LAMP FUNCTION (2)

Check that brake warning lamp in combination meter turns ON/OFF when parking brake is operated.

Is the inspection result normal?

YES >> Inspection End.

NO >> Check parking brake switch system. Refer to [MWI-83, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009134734

1. PERFORM THE SELF-DIAGNOSIS

Ⓟ With CONSULT.

Perform self-diagnostic result.

Are any DTCs detected?

YES >> Refer to [BRC-46, "DTC Index"](#).

NO >> GO TO 2.

2. CHECK COMBINATION METER

Check if indication and operation of combination meter are normal. Refer to [MWI-9, "METER SYSTEM : System Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Replace combination meter. Refer to [MWI-95, "Removal and Installation"](#).

VDC OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

VDC OFF INDICATOR LAMP

Component Function Check

INFOID:000000009134735

1.CHECK VDC OFF INDICATOR LAMP FUNCTION (1)

Check that VDC OFF indicator lamp in combination meter turns ON for approximately 2 seconds after ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-115, "Diagnosis Procedure"](#)

2.CHECK VDC OFF INDICATOR LAMP FUNCTION (2)

Check that VDC OFF indicator lamp in combination meter turns ON/OFF when VDC OFF switch is operated.

Is the inspection result normal?

YES >> Inspection End.

NO >> Check VDC OFF switch. Refer to [BRC-111, "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:000000009134736

BRC

1.PERFORM THE SELF-DIAGNOSIS

Ⓜ With CONSULT.

Perform self diagnostic result.

Are any DTCs detected?

YES >> Refer to [BRC-46, "DTC Index"](#).

NO >> GO TO 2.

2.CHECK COMBINATION METER

Check if indication and operation of combination meter are normal. Refer to [MWI-9, "METER SYSTEM : System Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Replace combination meter. Refer to [MWI-95, "Removal and Installation"](#).

SLIP INDICATOR LAMP

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

SLIP INDICATOR LAMP

Component Function Check

INFOID:000000009134737

1.CHECK SLIP INDICATOR LAMP FUNCTION

Check that slip indicator lamp in combination meter turns ON for approximately 2 seconds after ignition switch is turned ON.

Is the inspection result normal?

YES >> Inspection End.

NO >> Proceed to diagnosis procedure. Refer to [BRC-116, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009134738

1.PERFORM THE SELF-DIAGNOSIS

With CONSULT.

Perform self diagnostic result.

Are any DTCs detected?

YES >> Refer to [BRC-46, "DTC Index"](#).

NO >> GO TO 2.

2.CHECK COMBINATION METER

Check if indication and operation of combination meter are normal. Refer to [MWI-9, "METER SYSTEM : System Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130, "Removal and Installation"](#).

NO >> Replace combination meter. Refer to [MWI-95, "Removal and Installation"](#).

SYMPTOM DIAGNOSIS

VDC/TCS/ABS

Symptom Table

INFOID:000000009134739

If ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp turn ON, perform self-diagnosis.

Symptom	Check item	Reference
Excessive ABS function operation frequency	Brake force distribution	BRC-118. "Diagnosis Procedure"
	Looseness of front and rear axle	
	Wheel sensor and rotor system	
Unexpected pedal reaction	Brake pedal stroke	BRC-119. "Diagnosis Procedure"
	Make sure the braking force is sufficient when the ABS is not operating.	
The braking distance is long	Check stopping distance when the ABS is not operating.	BRC-120. "Diagnosis Procedure"
ABS function does not operate (Note 1)	ABS actuator and electric unit (control unit)	BRC-121. "Diagnosis Procedure"
Pedal vibration or ABS operation sound occurs (Note 2)	Brake pedal	BRC-122. "Diagnosis Procedure"
	ABS actuator and electric unit (control unit)	
Vehicle jerks during VDC/TCS/ABS control	ABS actuator and electric unit (control unit)	BRC-123. "Diagnosis Procedure"
	TCM	
	ECM	

NOTE:

- 1: The ABS does not operate when the speed is 10 km/h (6 MPH) or less.
- 2: Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.
 - When shifting gears
 - When driving on slippery road
 - During cornering at high speed
 - When passing over bumps or grooves [approximately 50 mm (1.97 in) or more]
 - When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

EXCESSIVE OPERATION FREQUENCY

[WITH VDC]

< SYMPTOM DIAGNOSIS >

EXCESSIVE OPERATION FREQUENCY

Description

INFOID:000000009134740

VDC function, TCS function, ABS function, EBD function, hill start assist function or Brake force distribution function operates in excessive operation frequency.

Diagnosis Procedure

INFOID:000000009134741

1. CHECK BRAKING FORCE

Check brake force using a brake tester.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

2. CHECK FRONT AND REAR AXLE

Check that there is no excessive looseness in front and rear axle.

- Front axle
- FWD: Refer to [FAX-7, "Inspection"](#).
- AWD: Refer to [FAX-7, "Inspection"](#).
- Rear axle: Refer to [RAX-6, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3. CHECK WHEEL SENSOR

Check wheel sensor.

- Check installation and damage of wheel sensor.
- Check connection of wheel sensor harness connector.
- Check terminal of wheel sensor harness connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair installation or replace wheel sensor.

- Front wheel sensor: Refer to [BRC-125, "Removal and Installation - Front Wheel Sensor"](#).
- Rear wheel sensor: Refer to [BRC-127, "Removal and Installation - Rear Wheel Sensor"](#).

4. CHECK SENSOR ROTOR

Check that there is no looseness, damage or foreign material on sensor rotor.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair installation or replace sensor rotor.

- Front sensor rotor: Refer to [BRC-129, "Removal and Installation - Front Sensor Rotor"](#).
- Rear sensor rotor: Refer to [BRC-129, "Removal and Installation - Rear Sensor Rotor"](#).

5. CHECK WARNING LAMP TURNS OFF

Check that ABS warning lamp, brake warning lamp and VDC warning lamp turn OFF approx. 1 second after key switch is turned ON and stay in OFF status during driving.

CAUTION:

Brake warning lamp turns ON when parking brake is operated (parking brake switch is ON) or brake fluid is less than the specified level (brake fluid level switch is ON).

Is the inspection result normal?

YES >> Inspection End.

NO >> Perform self-diagnosis result. Refer to [BRC-36, "CONSULT Function"](#).

UNEXPECTED BRAKE PEDAL REACTION

[WITH VDC]

< SYMPTOM DIAGNOSIS >

UNEXPECTED BRAKE PEDAL REACTION

Description

INFOID:000000009134742

A malfunction of brake pedal feel (height or others) is detected when brake pedal is depressed.

Diagnosis Procedure

INFOID:000000009134743

1.CHECK FRONT AND REAR AXLE

Check that there is no excessive looseness in front and rear axle.

- Front axle
- FWD: Refer to [FAX-7. "Inspection"](#).
- AWD: Refer to [FAX-7. "Inspection"](#).
- Rear axle: Refer to [RAX-6. "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace malfunctioning components.

2.CHECK DISC ROTOR

Check disc rotor runout.

- Front: Refer to [BR-11. "DISC ROTOR : Inspection"](#).
- Rear: Refer to [BR-13. "DISC ROTOR : Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Refinish the disc rotor.

3.CHECK BRAKE FLUID LEAKAGE

Check fluid leakage. Refer to [BR-8. "Inspection"](#)

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace malfunctioning components.

4.CHECK BRAKE PEDAL

Check brake pedal. Refer to [BR-7. "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Adjust brake pedal. Refer to [BR-15. "Adjustment"](#).

5.CHECK BRAKING FORCE

Check brake force using a brake tester.

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Check brake system.

6.CHECK BRAKE PERFORMANCE

Disconnect ABS actuator and electric unit (control unit) connector so that ABS does not operate. Check that brake force is normal in this condition. Connect harness connectors after checking.

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Check brake system.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

THE BRAKING DISTANCE IS LONG

[WITH VDC]

< SYMPTOM DIAGNOSIS >

THE BRAKING DISTANCE IS LONG

Description

INFOID:000000009134744

Brake stopping distance is long when ABS function is operated.

Diagnosis Procedure

INFOID:000000009134745

CAUTION:

Brake stopping distance on slippery roads like a rough road, gravel road or snowy road may become longer when ABS is operated than when ABS is not operated.

1.CHECK BRAKING FORCE

Check brake force using a brake tester.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

2.CHECK BRAKE PERFORMANCE

Disconnect ABS actuator and electric unit (control unit) connector so that ABS does not operate. Check brake stopping distance in this condition. Connect harness connectors after checking.

Is the inspection result normal?

YES >> Inspection End.

NO >> Check brake system.

ABS FUNCTION DOES NOT OPERATE

[WITH VDC]

< SYMPTOM DIAGNOSIS >

ABS FUNCTION DOES NOT OPERATE

Description

INFOID:000000009134746

VDC function, TCS function, ABS function, EBD function, hill start assist function or Brake force distribution function does not operate.

Diagnosis Procedure

INFOID:000000009134747

CAUTION:

- VDC function, TCS function, ABS function, EBD function, hill start assist function and Brake force distribution function never operate when the vehicle speed is 10 km/h (6.2 MPH) or less. However, hill start assist function operates when the vehicle speed is 0 km/h (0 MPH) (the vehicle is in stop status).
- VDC function and TCS function never operate when VDC OFF switch is operated (when VDC OFF indicator lamp turns ON).

1. CHECK ABS WARNING LAMP

Check that ABS warning lamp, brake warning lamp and VDC warning lamp turn ON and turn OFF approx. 1 second after key switch is turned ON. Check that ABS warning lamp, brake warning lamp and VDC warning lamp and stay in OFF status during driving.

CAUTION:

Brake warning lamp turns ON when parking brake is operated (parking brake switch is ON) or brake fluid is less than the specified level (brake fluid level switch is ON).

Is the inspection result normal?

YES >> Inspection End.

NO >> Perform self-diagnosis result"". Refer to [BRC-36. "CONSULT Function"](#).

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

BRAKE PEDAL VIBRATION OR OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[WITH VDC]

BRAKE PEDAL VIBRATION OR OPERATION SOUND OCCURS

Description

INFOID:000000009134748

- Brake pedal vibrates and motor sound from ABS actuator and electric unit (control unit) occurs when the engine starts.
- Brake pedal vibrates during braking.

CAUTION:

Vibration may be felt during brake pedal is lightly depressed (just placing a foot on it) in the following conditions. This is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [Approx. 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approx. 10 km/h (6.2 MPH) or higher]

Diagnosis Procedure

INFOID:000000009134749

1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Check brake pedal. Refer to [BR-7, "Inspection"](#).

2. SYMPTOM CHECK 2

Check that motor sound from ABS actuator occurs when the engine starts.

Does the operation sound occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis result. Refer to [BRC-36, "CONSULT Function"](#).

3. SYMPTOM CHECK 3

Check symptoms when electrical component (head lamps, etc.) switches are operated.

Does the symptom occur?

YES >> Check that radio (including wiring), antenna and antenna lead-in wires are not located near ABS actuator and electric unit (control unit). Move them if they are located near ABS actuator and electric unit (control unit).

NO >> Inspection End.

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

< SYMPTOM DIAGNOSIS >

[WITH VDC]

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

Description

INFOID:000000009134750

The vehicle jerks when VDC function, TCS function, ABS function, EBD function, hill start assist function or Brake force distribution function operates.

Diagnosis Procedure

INFOID:000000009134751

1. CHECK SYMPTOM

Check that the vehicle jerks when VDC function, TCS function, ABS function, EBD function, hill start assist function or Brake force distribution function operates.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 2.

2. PERFORM THE SELF-DIAGNOSIS

Ⓜ With CONSULT

Perform self-diagnosis result. Refer to [BRC-36. "CONSULT Function"](#).

Is any DTC detected?

YES >> Check the DTC. Refer to [BRC-46. "DTC Index"](#).

NO >> GO TO 3.

3. CHECK CONNECTOR

Ⓜ With CONSULT

1. Turn the ignition switch OFF.

2. Disconnect ABS actuator and electric unit (control unit) harness connector.

3. Check connector terminal for deformation, disconnection and looseness.

4. Connect harness connector and perform self-diagnosis result. Refer to [BRC-36. "CONSULT Function"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace connector terminal.

4. CHECK ECM AND TCM SELF-DIAGNOSIS RESULTS

Ⓜ With CONSULT

Perform self-diagnosis result for "ENGINE" and "TRANSMISSION".

Is any DTC detected?

YES >> Check the DTC.

NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-130. "Removal and Installation"](#).

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[WITH VDC]

NORMAL OPERATING CONDITION

Description

INFOID:000000009134752

Symptom	Result
Brake pedal slightly vibrates and operation sound (motor sound and sound from suspension) occurs when VDC function, TCS function, ABS function, EBD function, hill start assist function, Brake force distribution function or Active trace control function operates.	This is not a malfunction, because it is caused by VDC function, TCS function, ABS function, EBD function, hill start assist function, Brake force distribution function and Active trace control function that are normally operated.
Brake stopping distance may become longer than models without ABS function depending on the road conditions, when ABS function is operated on slippery road like rough road, gravel road or snowy road.	
Brake pedal vibrates and operation sound occurs during sudden acceleration and cornering, when VDC function, TCS function, Brake force distribution function or Active trace control function is operated.	
Brake pedal vibrates and motor sound from the engine room occurs when the engine starts or the vehicle starts just after starting the engine.	This is not a malfunction because it is caused by operation check of ABS actuator and electric unit (control unit).
Acceleration may be felt insufficient depending on the road conditions.	This is not a malfunction because it is caused by TCS function that puts the highest priority to obtain the optimum traction (stability).
TCS function may operate momentarily while driving on a road where friction coefficient varies or when downshifting or fully depressing accelerator pedal.	
ABS warning lamp and VDC warning lamp may turn ON when the vehicle is on a rotating turntable or is given a strong shaking or large vibrations on a ship while the engine is running.	In this case, restart the engine on a normal road. If the normal condition is restored, there is no malfunction. In that case, erase "ABS" self-diagnosis result memory with CONSULT.
VDC warning lamp may turn ON and VDC function, TCS function, Brake force distribution function and Active trace control function may not normally operate, when driving on a special road the is extremely slanted (bank in a circuit course).	
A malfunction in yaw rate/side/decel G sensor system may be detected when the vehicle sharply turns during a spin turn, acceleration turn or drift driving while VDC function, TCS function, Brake force distribution function and Active trace control function are OFF (VDC OFF switch is pressed and VDC OFF indicator lamp is in ON status).	
The vehicle speed does not increase when the accelerator pedal is depressed while the vehicle is on a 2-wheel chassis dynamometer for speedometer check.	This is normal. (When checking the vehicle on a chassis dynamometer, operate VDC OFF switch so that TCS function is OFF.)

WHEEL SENSOR

< UNIT REMOVAL AND INSTALLATION >


[WITH VDC]

UNIT REMOVAL AND INSTALLATION

WHEEL SENSOR

Exploded View - Front Wheel Sensor

INFOID:000000009134753



1. Front wheel sensor

A. Color line (slant line)

B. Front wheel sensor connector

⇐ Front

Removal and Installation - Front Wheel Sensor

INFOID:000000009134754

CAUTION:

- Be careful not to damage front wheel sensor edge and sensor rotor teeth.
- When removing the front wheel hub and bearing, first remove the front wheel sensor from the steering knuckle. Failure to do so may result in damage to the front wheel sensor wires making the front wheel sensor inoperative.
- Pull out the front wheel sensor, being careful to turn it as little as possible. Do not pull on the front wheel sensor harness.
- Before installation, check if foreign objects such as iron fragments are adhered to the pick-up part of the front wheel sensor or to the inside of the hole in the steering knuckle for the front wheel sensor, or if a foreign object is caught in the surface of the mating surface for the sensor rotor. Fix as necessary and then install the front wheel sensor.

REMOVAL

1. Remove the front wheel and tire using power tool. Refer to [WT-53, "Adjustment"](#).
2. Partially remove the fender protector to gain access to the wheel sensor connector.
3. Disconnect the harness connector from the front wheel sensor.
4. Remove the front wheel sensor bolt.
5. Remove the front wheel sensor from the strut bracket and body brackets.
6. Remove the front wheel sensor from the steering knuckle.

INSTALLATION

WHEEL SENSOR


< UNIT REMOVAL AND INSTALLATION >

[WITH VDC]

Installation is in the reverse order of the removal.

CAUTION:


- When installing, make sure there is no foreign material such as iron chips on and in the hole in the steering knuckle for the front wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- Do not twist front wheel sensor harness when installing front wheel sensor. Check that grommet (2) is fully inserted to bracket (1). Check that front wheel sensor harness is not twisted after installation.



Exploded View - Rear Wheel Sensor

INFOID:000000009134755

RH Side



1. Rear wheel sensor

A. Rear wheel sensor bracket

B. Clip

C. Rear wheel sensor connector


↶ Front

WHEEL SENSOR

< UNIT REMOVAL AND INSTALLATION >

[WITH VDC]

LH Side



- | | | |
|------------------------------|--------------------------------|---------|
| 1. Rear wheel sensor | A. Rear wheel sensor connector | B. Clip |
| C. Rear wheel sensor bracket | ⇐ Front | |

Removal and Installation - Rear Wheel Sensor

INFOID:000000009134756

CAUTION:

- Be careful not to damage rear wheel sensor edge and sensor rotor teeth.
- When removing the rear wheel hub and bearing, first remove the rear wheel sensor from the rear knuckle. Failure to do so may result in damage to the rear wheel sensor wires making the rear wheel sensor inoperative.
- Pull out the rear wheel sensor, being careful to turn it as little as possible. Do not pull on the rear wheel sensor harness.
- Before installation, check if foreign objects such as iron fragments are adhered to the pick-up part of the rear wheel sensor or to the inside of the hole in the rear knuckle for the wheel sensor, or if a foreign object is caught in the surface of the mating surface for the sensor rotor. Fix as necessary and then install the rear wheel sensor.

REMOVAL

1. Remove the rear wheel and tire using power tool. Refer to [WT-53. "Adjustment"](#).
2. Remove the rear wheel sensor bolt.
3. Disconnect the harness connector from the rear wheel sensor.
4. Remove the rear wheel sensor from the sensor brackets.
5. Remove the rear wheel sensor from the rear knuckle.

INSTALLATION

Installation is in the reverse order of the removal.

CAUTION:


A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

WHEEL SENSOR

< UNIT REMOVAL AND INSTALLATION >

[WITH VDC]

- When installing, make sure there is no foreign material such as iron chips on and in the hole in the rear knuckle for the rear wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- Do not twist rear wheel sensor harness when installing rear wheel sensor. Check that grommet (2) is fully inserted to bracket (1). Check that rear wheel sensor harness is not twisted after installation.



SENSOR ROTOR

< UNIT REMOVAL AND INSTALLATION >

[WITH VDC]

SENSOR ROTOR

Removal and Installation - Front Sensor Rotor

INFOID:000000009134757

The front wheel sensor rotor is an integral part of the wheel hub and bearing and cannot be disassembled. Refer to [FAX-8, "Removal and Installation"](#).

Removal and Installation - Rear Sensor Rotor

INFOID:000000009134758

The rear wheel sensor rotor is an integral part of the wheel hub and bearing and cannot be disassembled. Refer to [RAX-7, "Removal and Installation"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< UNIT REMOVAL AND INSTALLATION >

[WITH VDC]

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000009134759



- | | | |
|--|--------------------------------------|--|
| 1. ABS actuator and electric unit (control unit) | 2. Bracket | A. From master cylinder secondary side |
| B. To front RH brake caliper | C. To rear LH brake caliper | D. To rear RH brake caliper |
| E. To front LH brake caliper | F. From master cylinder primary side | ← Front |

Removal and Installation

INFOID:000000009134760

REMOVAL

CAUTION:

- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged.
- Do not remove actuator by holding harness.

NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

1. Disconnect the negative battery terminal. Refer to [PG-93, "Exploded View"](#).
2. Remove cowl top. Refer to [EXT-25, "Removal and Installation"](#).
3. Disconnect the harness connector from the ABS actuator and electric unit (control unit).
4. Separate brake tubes from ABS actuator and electric unit (control unit). Refer to [BR-22, "FRONT : Exploded View"](#).
5. Remove ABS actuator and electric unit (control unit) bracket bolt.
6. Remove ABS actuator and electric unit (control unit) from vehicle.

INSTALLATION

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[WITH VDC]

< UNIT REMOVAL AND INSTALLATION >

Installation is in the reverse order of removal.

- After work is completed, bleed air from brake tube. Refer to [BR-16, "Bleeding Brake System"](#).
- Adjust the neutral position of steering angle sensor. Refer to [BRC-60, "Work Procedure"](#).
- Perform calibration of yaw rate/side/decel G sensor. Refer to [BRC-62, "Work Procedure"](#).

CAUTION:

- **To install, use flare nut crowfoot and torque wrench.**
- **Do not apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.**
- **Do not install actuator by holding harness.**
- **After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.**

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

YAW RATE/SIDE/DECEL G SENSOR


< UNIT REMOVAL AND INSTALLATION >

[WITH VDC]

YAW RATE/SIDE/DECEL G SENSOR

Exploded View

INFOID:000000009134761



1. Yaw rate/side/decel G sensor

A. Harness connector

← Front

Removal and Installation

INFOID:000000009134762

REMOVAL

1. Remove the side stay cover from the center console assembly. Refer to [IP-27, "Exploded View"](#).
2. Disconnect the harness connector from the yaw rate/side/decel G sensor.
3. Remove the yaw rate/side/decel G sensor nuts.
4. Remove yaw rate/side/decel G sensor.

INSTALLATION

Installation is in the reverse order of removal.

- Perform calibration of the yaw rate/side/decel G sensor. Refer to [BRC-62, "Work Procedure"](#).

CAUTION:

- Do not use power tools on the yaw rate/side/decel G sensor because it is sensitive to the impact.
- Replace the yaw rate/side/decel G sensor if it has been dropped or sustained an impact.

STEERING ANGLE SENSOR

[WITH VDC]

< UNIT REMOVAL AND INSTALLATION >

STEERING ANGLE SENSOR

Removal and Installation

INFOID:000000009134764

To remove and install the steering angle sensor, remove and install spiral cable. Refer to [SR-15. "Removal and Installation"](#).

- A
- B
- C
- D
- E
- BRC**
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P

PRECAUTIONS

< PRECAUTION >

[BRAKE ASSIST (WITH PREVIEW FUNCTION)]

PRECAUTION

PRECAUTIONS

Precautions for Preview Function Service

INFOID:000000009134765

CAUTION:

- Never look straight into the laser beam discharger when adjusting laser beam aiming.
- Never use the ICC sensor removed from vehicle. Never disassemble or remodel.
- Erase DTC when replacing parts of ICC system. Then check the operation of ICC system after adjusting laser beam aiming if necessary.

COMPONENT PARTS

[BRAKE ASSIST (WITH PREVIEW FUNCTION)]


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009134766



- | | | |
|---|---|--|
| 1. ICC steering switch | 2. Vehicle information display, ICC system warning lamp, IBA OFF indicator lamp, buzzer
(On the combination meter) | 3. ICC brake hold relay
(view with relay cover removed) |
| 4. ABS actuator and electric unit
(control unit) | 5. ICC sensor
(view with front fascia removed) | 6. TCM |
| 7. ECM | 8. Stop lamp switch
(view with instrument panel LH removed) | 9. ICC brake switch
(view with instrument panel LH removed) |
| 10. Steering angle sensor | 11. ADAS control unit | |
| A. Back side of engine room (RH) | B. Front bumper | C. Upper side of brake pedal |

COMPONENT PARTS

[BRAKE ASSIST (WITH PREVIEW FUNCTION)]

< SYSTEM DESCRIPTION >

Component Description

INFOID:000000009134767

No.	Component	Function				Description
		Vehicle-to-vehicle distance control mode	Conventional (fixed speed) cruise control mode	Intelligent Brake Assist (IBA)	Brake Assist (with preview function)	
1	ICC steering switch	×	×			<ul style="list-style-type: none"> • ICC steering switch allows the ON/OFF of the intelligent cruise control and the settings of a vehicle speed and distance between vehicles. • ICC steering switch signal is transmitted to ECM. ECM transmits the signal to the ADAS control unit via CAN communication.
2	Combination meter (Information display, IBA OFF indicator lamp, buzzer)	×	×	×	×	<p>Performs the following operations using the signals received from the ADAS control unit via the CAN communication:</p> <ul style="list-style-type: none"> • Displays the ICC system operation status using the meter display signal. • Illuminates the ICC system warning lamp using the ICC warning lamp signal. • Illuminates the IBA OFF indicator lamp using the IBA OFF indicator lamp signal. • Operates the buzzer (ICC warning chime) using the buzzer output signal.
3	ICC brake hold relay	×		×		ICC brake hold relay activates the stop lamp by ICC brake hold relay drive signal (stop lamp drive signal) outputted by the ADAS control unit
4	ABS actuator and electric unit (control unit)	×	×	×	×	<ul style="list-style-type: none"> • ABS actuator and electric unit (control unit) transmits the vehicle speed signal (wheel speed), stop lamp signal and VDC/TCS/ABS system operation condition to ADAS control unit via CAN communication. • ABS actuator and electric unit (control unit) controls the brake based on a brake fluid pressure control signal received from the ADAS control unit via CAN communication.
5	ICC sensor	×	×	×	×	<ul style="list-style-type: none"> • ICC sensor detects light reflected from a vehicle ahead by irradiating laser forward and calculates a distance from the vehicle ahead and a relative speed, based on the detected signal. • ICC sensor transmits the presence/absence of vehicle ahead and the distance from the vehicle to ADAS control unit via ITS communication.
6	TCM	×	×			TCM transmits the signal related to CVT control to ADAS control unit via CAN communication.
7	ECM	×	×	×	×	<ul style="list-style-type: none"> • ECM transmits the accelerator pedal position signal, ICC brake switch signal, stop lamp switch signal, ICC steering switch signal, etc. to ADAS control unit via CAN communication. • ECM controls the electric throttle control actuator based on the engine torque demand received from the ADAS control unit via CAN communication.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[BRAKE ASSIST (WITH PREVIEW FUNCTION)]

No.	Component	Function				Description
		Vehicle-to-vehicle distance control mode	Conventional (fixed speed) cruise control mode	Intelligent Brake Assist (IBA)	Brake Assist (with preview function)	
8	Stop lamp switch	×	×	×	×	<ul style="list-style-type: none"> • ICC brake switch is turned OFF and stop lamp switch is turned ON, when depressing the brake pedal. • ICC brake switch signal is input to ECM. These signals are transmitted from ECM to ADAS control unit via CAN communication. • Stop lamp switch signal is input to ECM and ABS actuator and electric unit (control unit). These signals are transmitted from ECM and ABS actuator and electric unit (control unit) to ADAS control unit via CAN communication.
9	ICC brake switch	×	×	×	×	
10	Steering angle sensor	×				Measures the rotation amount, rotation speed, and rotation direction of steering wheel, and then transmits them to ADAS control unit via CAN communication.
11	ADAS control unit	×	×	×	×	<ul style="list-style-type: none"> • ADAS control unit calculates a target distance between vehicles and a target speed based on signals received from each sensor and switch to transmit an engine torque command value to ECM and a brake fluid pressure control signal to ABS actuator and electric unit (control unit) via CAN communication. • ADAS control unit transmits buzzer output signal to combination meter via CAN communication.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

SYSTEM

< SYSTEM DESCRIPTION >

[BRAKE ASSIST (WITH PREVIEW FUNCTION)]

SYSTEM

BRAKE ASSIST (WITH PREVIEW FUNCTION)

BRAKE ASSIST (WITH PREVIEW FUNCTION) : System Description

INFOID:000000009134768

FUNCTION DESCRIPTION

When the Preview Function identifies the need to apply emergency braking by sensing a vehicle ahead in the same lane and the distance and relative speed from it, it applies the brake pre-pressure before the driver depresses the brake pedal and helps improve brake response by reducing pedal free play.

The Preview Function shares component parts and diagnosis with the Intelligent Cruise Control (ICC) system.

CAUTION:

This system is only an aid to assist braking operation and is not a collision warning or avoidance device. It is the driver's responsibility to stay alert, drive safely and be in control of the vehicle at all times.

OPERATION DESCRIPTION

- The system detects the distance to the vehicle in front with the ICC sensor of ICC and judges the necessity of emergency braking.
- The system detects the accelerator pedal release operation of the driver by the accelerator pedal position sensor and estimates the driver's brake operation intention.
- If the system judges that the emergency braking is necessary and that the driver has the intention to operate the brake, the ABS actuator and electric unit (control unit) applies pre-pressure to reduce brake pedal play.

NOTE:

This system will not operate when the vehicle is moving at approximately 32 km/h (20 MPH) or less.

END OF OPERATION

The pre-pressure function ceases when the following conditions are met:

1. When the driver depresses the accelerator pedal or the brake pedal.
2. If the driver does not operate the accelerator pedal or brake pedal within approximately 1 second.

BRAKE ASSIST (WITH PREVIEW FUNCTION)

< DTC/CIRCUIT DIAGNOSIS >

[BRAKE ASSIST (WITH PREVIEW FUNCTION)]

DTC/CIRCUIT DIAGNOSIS

BRAKE ASSIST (WITH PREVIEW FUNCTION)

Diagnosis Procedure

INFOID:000000009134769

1. PREVIEW FUNCTION DIAGNOSIS

When the preview function is not operating properly, the buzzer sounds and the preview function warning lamp will come on.

NOTE:

The preview function warning lamp shares the ICC system warning lamp.

>> Go to ICC. Refer to [CCS-81, "Work Flow"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[BRAKE ASSIST (WITH PREVIEW FUNCTION)]

SYMPTOM DIAGNOSIS


NORMAL OPERATING CONDITION

Description

INFOID:000000009134770

PRECAUTIONS FOR PREVIEW FUNCTION

- This system is only an aid to assist braking operation and is not a collision warning or avoidance device. It is the driver's responsibility to stay alert, drive safely and be in control of the vehicle at all times.
- As there is a performance limit to the Preview Function, never rely solely on this system. This system does not correct careless inattentive or absent-minded driving or overcome poor visibility in rain, fog or other bad weather. Reduce vehicle speed by depressing the brake pedal in order to maintain a safe distance between vehicles.
- The system may not detect a vehicle ahead, depending on road or weather conditions. While the vehicle still travels and the Brake Assist System operates under normal conditions, the Preview Function may operate improperly under the following conditions:
 - When rain, snow or dirt adhere to the system sensor.
 - When strong light (for example, at sunrise or sunset) is directly shining on the front of the vehicle.
 - Winding or hilly roads may cause the sensor to temporarily not detect a vehicle in the same lane or may detect objects or vehicles in other lanes.
 - Vehicle position in the lane may cause the sensor to temporarily not detect a vehicle in the same lane or may detect objects or vehicles in other lanes.
- The system will not detect:
 - Pedestrians or objects in the roadway.
 - Oncoming vehicles in the same lane.
 - Motorcycles traveling offset in the travel lane as illustrated.
- When the Preview Function operates, the brake pedal may move slightly and may make a small noise. This is not a system malfunction.



PRECAUTION

PRECAUTIONS

Precautions for IBA System Service

INFOID:000000009134771

CAUTION:

- Never look straight into the laser beam discharger when adjusting laser beam aiming.
- Never use the ICC sensor removed from vehicle. Never disassemble or remodel.
- Erase DTC when replacing parts of ICC system. Then check the operation of ICC system after adjusting laser beam aiming if necessary.
- Never change IBA system state ON/OFF without the consent of the customer.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

COMPONENT PARTS

< SYSTEM DESCRIPTION >


[INTELLIGENT BRAKE ASSIST]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000009134772



- | | | |
|---|---|--|
| 1. ICC steering switch | 2. Vehicle information display, ICC system warning lamp, IBA OFF indicator lamp, buzzer
(On the combination meter) | 3. ICC brake hold relay
(view with relay cover removed) |
| 4. ABS actuator and electric unit
(control unit) | 5. ICC sensor
(view with front fascia removed) | 6. TCM |
| 7. ECM | 8. Stop lamp switch
(view with instrument panel LH removed) | 9. ICC brake switch
(view with instrument panel LH removed) |
| 10. Steering angle sensor | 11. ADAS control unit | |
| A. Back side of engine room (RH) | B. Front bumper | C. Upper side of brake pedal |

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[INTELLIGENT BRAKE ASSIST]

Component Description

INFOID:000000009134773

No.	Component	Function				Description
		Vehicle-to-vehicle distance control mode	Conventional (fixed speed) cruise control mode	Intelligent Brake Assist (IBA)	Brake Assist (with preview function)	
1	ICC steering switch	x	x			<ul style="list-style-type: none"> ICC steering switch allows the ON/OFF of the intelligent cruise control and the settings of a vehicle speed and distance between vehicles. ICC steering switch signal is transmitted to ECM. ECM transmits the signal to the ADAS control unit via CAN communication.
2	Combination meter (Information display, IBA OFF indicator lamp, buzzer)	x	x	x	x	<p>Performs the following operations using the signals received from the ADAS control unit via the CAN communication:</p> <ul style="list-style-type: none"> Displays the ICC system operation status using the meter display signal. Illuminates the ICC system warning lamp using the ICC warning lamp signal. Illuminates the IBA OFF indicator lamp using the IBA OFF indicator lamp signal. Operates the buzzer (ICC warning chime) using the buzzer output signal.
3	ICC brake hold relay	x		x		ICC brake hold relay activates the stop lamp by ICC brake hold relay drive signal (stop lamp drive signal) outputted by the ADAS control unit
4	ABS actuator and electric unit (control unit)	x	x	x	x	<ul style="list-style-type: none"> ABS actuator and electric unit (control unit) transmits the vehicle speed signal (wheel speed), stop lamp signal and VDC/TCS/ABS system operation condition to ADAS control unit via CAN communication. ABS actuator and electric unit (control unit) controls the brake based on a brake fluid pressure control signal received from the ADAS control unit via CAN communication.
5	ICC sensor	x	x	x	x	<ul style="list-style-type: none"> ICC sensor detects light reflected from a vehicle ahead by irradiating laser forward and calculates a distance from the vehicle ahead and a relative speed, based on the detected signal. ICC sensor transmits the presence/absence of vehicle ahead and the distance from the vehicle to ADAS control unit via ITS communication.
6	TCM	x	x			TCM transmits the signal related to CVT control to ADAS control unit via CAN communication.
7	ECM	x	x	x	x	<ul style="list-style-type: none"> ECM transmits the accelerator pedal position signal, ICC brake switch signal, stop lamp switch signal, ICC steering switch signal, etc. to ADAS control unit via CAN communication. ECM controls the electric throttle control actuator based on the engine torque demand received from the ADAS control unit via CAN communication.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[INTELLIGENT BRAKE ASSIST]

No.	Component	Function				Description
		Vehicle-to-vehicle distance control mode	Conventional (fixed speed) cruise control mode	Intelligent Brake Assist (IBA)	Brake Assist (with preview function)	
8	Stop lamp switch	×	×	×	×	<ul style="list-style-type: none"> • ICC brake switch is turned OFF and stop lamp switch is turned ON, when depressing the brake pedal. • ICC brake switch signal is input to ECM. These signals are transmitted from ECM to ADAS control unit via CAN communication. • Stop lamp switch signal is input to ECM and ABS actuator and electric unit (control unit). These signals are transmitted from ECM and ABS actuator and electric unit (control unit) to ADAS control unit via CAN communication.
9	ICC brake switch	×	×	×	×	
10	Steering angle sensor	×				Measures the rotation amount, rotation speed, and rotation direction of steering wheel, and then transmits them to ADAS control unit via CAN communication.
11	ADAS control unit	×	×	×	×	<ul style="list-style-type: none"> • ADAS control unit calculates a target distance between vehicles and a target speed based on signals received from each sensor and switch to transmit an engine torque command value to ECM and a brake fluid pressure control signal to ABS actuator and electric unit (control unit) via CAN communication. • ADAS control unit transmits buzzer output signal to combination meter via CAN communication.

SYSTEM
INTELLIGENT BRAKE ASSIST

INTELLIGENT BRAKE ASSIST : System Description

INFOID:000000009134774

FUNCTION DESCRIPTION

Intelligent Brake Assist (IBA) system warns the driver by a vehicle ahead detection indicator and chime when there is a risk of a collision with the vehicle ahead in the traveling lane and the driver must take avoidance action immediately. The system helps reduce the rear-end collision speed by applying the brakes when it judges a collision can not be avoided.

CAUTION:

The IBA system is a not collision avoidance system. It is the driver's responsibility to stay alert, drive safely and be in control of the vehicle at all times. As there is a performance limit, it may not provide a warning or brake in certain conditions.

NOTE:

- The IBA system shares component parts and diagnosis with the Intelligent Cruise Control (ICC) system.
- The IBA system will operate even when the ICC system is turned to OFF.

OPERATION DESCRIPTION


The IBA system uses a ICC sensor located below the front bumper to measure the distance to a vehicle ahead. When the system judges that the distance gets shorter, the vehicle ahead detection indicator on the combination meter blinks and the warning chime sounds.

To turn the system OFF/ON, select the Drivers Assistance menu on the Combination meter, then select the Intelligent Brake Assist option. Toggle between on and off in this menu.

NOTE:

- The system ON/OFF condition will be memorized even if the ignition switch turns OFF.
- The IBA system operates under the following conditions.
- The IBA system will function when the vehicle is driven at speeds of approximately 15 km/h (10 MPH) and above, and when the vehicle's speed is approximately 15 km/h (10 MPH) faster than that of the vehicle ahead.

Fail-safe Indication

Condition	Description	Indication on the combination meter
<ul style="list-style-type: none"> • When the sensor window is dirty • When the system malfunction 	The system will be cancelled automatically with a beep sound.	 <p>IBA OFF</p>
When driving into a strong light (i.e. sunlight)	The system is temporary unavailable. (Without the warning chime)	

JSFIA0392ZZ

NOTE:

When the IBA turns OFF, the IBA OFF indicator lamp will illuminate.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DTC/CIRCUIT DIAGNOSIS

INTELLIGENT BRAKE ASSIST

Diagnosis Procedure

INFOID:000000009134775

1. INTELLIGENT BRAKE ASSIST DIAGNOSIS

- The system will be cancelled automatically with a beep sound and IBA OFF indicator lamp on the combination meter will illuminate when the system will not operate properly.
- When the IBA OFF indicator lamp continues to illuminate even if the IBA system is turned on after the engine restarts, perform the trouble-diagnosis.

NOTE:

IBA system automatically returns to ON when erasing self-diagnosis result of "ICC/ADAS" with CONSULT.

>> Go to ICC. Refer to [CCS-81, "Work Flow"](#).

SWITCH DOES NOT TURN ON / SWITCH DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

[INTELLIGENT BRAKE ASSIST]

SYMPTOM DIAGNOSIS

SWITCH DOES NOT TURN ON / SWITCH DOES NOT TURN OFF

Symptom Table

INFOID:000000009134776

CAUTION:

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Inspection item/Reference page
IBA system does not turn on/off	IBA OFF indicator lamp is not turned ON⇔OFF when selecting it on the Combination meter.	BRC-147, "Diagnosis Procedure"

Description

INFOID:000000009134777

IBA system does not turn on/off.

- IBA OFF indicator lamp does not illuminate even if Intelligent Brake Assist OFF has been selected on the Combination meter even when the IBA OFF indicator is not illuminated.
- IBA OFF indicator lamp does not turn OFF even if Intelligent Brake Assist ON has been selected on the Combination meter when the IBA OFF indicator is illuminated.

NOTE:

- To turn the system OFF⇔ON, select the Drivers Assistance menu on the Combination meter display, then select the Intelligent Brake Assist. Toggle the system on and off from this screen. The IBA OFF light will illuminate.
- The system ON/OFF condition will be memorized even if the ignition switch turns OFF.

Diagnosis Procedure

INFOID:000000009134778

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnostic result.

Is DTC detected?

- YES >> Refer to [CCS-58, "DTC Index"](#) (ADAS) or [CCS-64, "DTC Index"](#) (ICC).
NO >> GO TO 2.

2. IBA OFF SWITCH INSPECTION

1. Start the engine.
2. Check that "IBA SW" operates normally in "DATA MONITOR" for "ICC/ADAS" with CONSULT.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning parts.

3. CHECK IBA OFF INDICATOR CIRCUIT

1. Start the engine.
2. Select the ACTIVE TEST item "METER LAMP" for "ICC/ADAS" with CONSULT.
3. Check if the IBA OFF indicator lamp illuminates when the test is performed.

Is the inspection result normal?

- YES >> Inspection End.
NO >> GO TO 4.

4. CHECK DATA MONITOR OF COMBINATION METER

Check that "BA W/L" operates normally in "DATA MONITOR" for "METER/M&A" with CONSULT when the IBA OFF switch is pushed and held for more than 1 second.

Is the inspection result normal?

- YES >> Replace the combination meter. Refer to [MWI-95, "Removal and Installation"](#).

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

SWITCH DOES NOT TURN ON / SWITCH DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

[INTELLIGENT BRAKE ASSIST]

NO >> Replace the ADAS control unit. Refer to [DAS-79. "Removal and Installation"](#).

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[INTELLIGENT BRAKE ASSIST]

NORMAL OPERATING CONDITION

Description

INFOID:000000009134779

PRECAUTIONS FOR INTELLIGENT BRAKE ASSIST

- The IBA system is not a collision avoidance system. It is the driver's responsibility to stay alert, drive safely and be in control of the vehicle at all times.
- As there is a performance limit, it may not provide a warning or brake in certain conditions.
- The system will not detect the following objects:
 - Pedestrians, animals or obstacles in the roadway.
 - Oncoming vehicles in the same lane.
- The system will not detect under the following conditions:
 - When the sensor gets dirty and it is impossible to detect the distance from the vehicle ahead.
 - When driving into a strong light (i.e. sunlight).
- The sensor generally detects the signals returned from the reflectors on a vehicle ahead. Therefore, the system may not function properly under the following conditions:
 - When the reflectors of the vehicle ahead are positioned high or close each other (including small vehicles such as motorcycles).
 - When the sensor gets dirty or it is impossible to detect the distance from the vehicle ahead.
 - When the reflectors on the vehicle ahead are missing, damaged or covered.
 - When the reflector of the vehicle ahead is covered with dirt, snow and road spray.
 - When visibility is low (such as rain, fog, snow, etc.).
 - When snow or road spray from traveling vehicles are raised up.
 - When dense exhaust or other smoke (black smoke) from vehicles reduces the sensor visibility.
 - When excessively heavy baggage is loaded in the rear seat or the luggage room of vehicle.
 - When abruptly accelerating or decelerating.
 - On steep downhill or roads with sharp curves.
 - When there is a highly reflective object near the vehicle ahead (i.e. very close to other vehicle, signboard, etc.).
 - While towing a trailer or other vehicle.
- Depending on certain road conditions (curved, beginning of a curve), vehicle conditions (steering position, vehicle position), or preceding vehicle's conditions (position in lane, etc.), the system may not function properly.
- The system may not function in offset conditions.
- The system may not function when the distance to the vehicle ahead is extremely close.
- The system detect highly reflective objects such as reflectors, signs, white markers, and other stationary objects on the road or near the traveling lane, and when in extreme conditions, detection of these objects may cause the system to function.
- The system is designed to automatically check the sensor's functionality. If the sensor is covered with ice, a transparent or translucent plastic bag, etc., the system may not detect them. In these instances the system may not be able to warn properly. Be sure to check and clean the sensor regularly.
- Excessive noise will interfere with the warning chime sound and the chime may not be heard.
- Never step in under the brake pedal to avoid an accident when IBA system turns ON.
- Sudden appearance of the vehicle in front (i.e. it abruptly cuts in) may not be detected and the system may not warn soon enough.
- The system will be cancelled automatically with a beep sound and the IBA OFF indicator lamp will illuminate under the following conditions:
 - When the sensor window is dirty.
 - When the system malfunctions.

