

SECTION **DLN**  
DRIVELINE

A  
B  
C

DLN

CONTENTS

E

<b>TRANSFER: TY21C</b>	<b>ECU DIAGNOSIS INFORMATION</b> .....	19	F
<b>PRECAUTION</b> .....	<b>AWD CONTROL UNIT</b> .....	19	G
<b>PRECAUTIONS</b> .....	Reference Value .....	19	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	Fail-Safe .....	20	H
Precaution for Procedure without Cowl Top Cover.....	Protection Function .....	21	
Precaution for Battery Service .....	DTC Inspection Priority Chart .....	21	I
Service Notice or Precautions for Transfer .....	DTC Index .....	22	
<b>PREPARATION</b> .....	<b>WIRING DIAGRAM</b> .....	23	J
<b>PREPARATION</b> .....	<b>AWD SYSTEM</b> .....	23	K
Special Service Tool .....	Wiring Diagram .....	23	
Commercial Service Tool .....	<b>BASIC INSPECTION</b> .....	38	L
<b>SYSTEM DESCRIPTION</b> .....	<b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....	38	M
<b>COMPONENT PARTS</b> .....	Work Flow .....	38	
Component Parts Location .....	Diagnostic Work Sheet .....	39	N
AWD Control Unit .....	<b>ADDITIONAL SERVICE WHEN REPLACING AWD CONTROL UNIT</b> .....	41	O
AWD Solenoid .....	Description .....	41	
Electric Controlled Coupling .....	Work Procedure .....	41	P
AWD Warning Icon/Display .....	<b>UNIT CHARACTERISTICS WRITING</b> .....	42	
<b>STRUCTURE AND OPERATION</b> .....	Description .....	42	
Sectional View .....	Work Procedure .....	42	
Operation Description .....	<b>DTC/CIRCUIT DIAGNOSIS</b> .....	43	
<b>SYSTEM</b> .....	<b>C1201 AWD CONTROL UNIT</b> .....	43	
<b>AWD SYSTEM</b> .....	DTC Logic .....	43	
AWD SYSTEM : System Description .....	Diagnosis Procedure .....	43	
AWD SYSTEM : Circuit Diagram .....	<b>C1203 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)</b> .....	44	
AWD SYSTEM : Fail-Safe .....	DTC Logic .....	44	
AWD SYSTEM : Protection Function .....	Diagnosis Procedure .....	44	
<b>DIAGNOSIS SYSTEM (AWD CONTROL UNIT)</b> .....	<b>C1204 AWD SOLENOID</b> .....	45	
CONSULT Function .....	DTC Logic .....	45	
	Diagnosis Procedure .....	45	

Component Inspection .....	47	<b>PERIODIC MAINTENANCE .....</b>	<b>65</b>
<b>C1205 AWD ACTUATOR RELAY .....</b>	<b>48</b>	<b>TRANSFER OIL .....</b>	<b>65</b>
DTC Logic .....	48	Inspection .....	65
Diagnosis Procedure .....	48	Draining .....	65
<b>C1210 ECM .....</b>	<b>50</b>	Refilling .....	65
DTC Logic .....	50	<b>REMOVAL AND INSTALLATION .....</b>	<b>67</b>
Diagnosis Procedure .....	50	<b>AWD CONTROL UNIT .....</b>	<b>67</b>
<b>P1804 AWD CONTROL UNIT .....</b>	<b>51</b>	Removal and Installation .....	67
DTC Logic .....	51	<b>TRANSFER COVER .....</b>	<b>68</b>
Diagnosis Procedure .....	51	Removal and Installation .....	68
<b>P181F INCOMPLETE CALIBRATION .....</b>	<b>52</b>	<b>UNIT REMOVAL AND INSTALLATION ....</b>	<b>69</b>
DTC Logic .....	52	<b>TRANSFER ASSEMBLY .....</b>	<b>69</b>
Diagnosis Procedure .....	52	Exploded View .....	69
<b>U1000 CAN COMM CIRCUIT .....</b>	<b>53</b>	Removal and Installation .....	69
Description .....	53	<b>UNIT DISASSEMBLY AND ASSEMBLY ...</b>	<b>71</b>
DTC Logic .....	53	<b>TRANSFER COVER .....</b>	<b>71</b>
Diagnosis Procedure .....	53	Exploded View .....	71
<b>U1010 CONTROL UNIT (CAN) .....</b>	<b>54</b>	Disassembly .....	72
Description .....	54	Assembly .....	73
DTC Logic .....	54	Inspection .....	74
Diagnosis Procedure .....	54	<b>RING GEAR SHAFT .....</b>	<b>75</b>
<b>POWER SUPPLY AND GROUND CIRCUIT ....</b>	<b>55</b>	Exploded View .....	75
Diagnosis Procedure .....	55	Disassembly .....	76
<b>AWD WARNING ICON/DISPLAY .....</b>	<b>58</b>	Assembly .....	77
Diagnosis Procedure .....	58	Inspection .....	78
<b>SYMPTOM DIAGNOSIS .....</b>	<b>59</b>	<b>DRIVE PINION .....</b>	<b>80</b>
<b>AWD ERROR IS DISPLAYED ON INFORMA-</b>		Exploded View .....	80
<b>TION DISPLAY .....</b>	<b>59</b>	Disassembly .....	81
Description .....	59	Assembly .....	82
Diagnosis Procedure .....	59	Adjustment .....	83
<b>HEAVY TIGHT-CORNER BRAKING SYMP-</b>		Inspection .....	87
<b>TOM OCCURS .....</b>	<b>60</b>	<b>TRANSFER CASE .....</b>	<b>88</b>
Description .....	60	Exploded View .....	88
Diagnosis Procedure .....	60	Disassembly .....	89
<b>VEHICLE DOES NOT ENTER AWD MODE ....</b>	<b>61</b>	Assembly .....	90
Description .....	61	Inspection .....	91
Diagnosis Procedure .....	61	<b>SERVICE DATA AND SPECIFICATIONS</b>	
<b>AWD HIGH TEMP IS DISPLAYED ON INFOR-</b>		<b>(SDS) .....</b>	<b>92</b>
<b>MATION DISPLAY .....</b>	<b>62</b>	<b>SERVICE DATA AND SPECIFICATIONS</b>	
Description .....	62	<b>(SDS) .....</b>	<b>92</b>
<b>TIRE SIZE INCORRECT IS DISPLAYED ON</b>		General Specifications .....	92
<b>INFORMATION DISPLAY .....</b>	<b>63</b>	Preload Torque .....	92
Description .....	63	Backlash .....	92
Diagnosis Procedure .....	63	Companion Flange Runout .....	92
<b>NOISE, VIBRATION AND HARSHNESS</b>		<b>REAR PROPELLER SHAFT: 3FCJ-CVJ</b>	
<b>(NVH) TROUBLESHOOTING .....</b>	<b>64</b>	<b>PRECAUTION .....</b>	<b>93</b>
NVH Troubleshooting Chart .....	64		

<b>PRECAUTIONS</b> .....	93	Description .....	106	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	93	Work Procedure .....	106	A
<b>PREPARATION</b> .....	94	<b>ADDITIONAL SERVICE WHEN REPLACING ELECTRIC CONTROLLED COUPLING</b> .....	107	B
<b>PREPARATION</b> .....	94	Description .....	107	
Commercial Service Tool .....	94	Work Procedure .....	107	
<b>SYMPTOM DIAGNOSIS</b> .....	95	<b>SYMPTOM DIAGNOSIS</b> .....	108	C
<b>NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING</b> .....	95	<b>NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING</b> .....	108	DLN
NVH Troubleshooting Chart .....	95	NVH Troubleshooting Chart .....	108	
<b>BASIC INSPECTION</b> .....	96	<b>PERIODIC MAINTENANCE</b> .....	109	E
<b>PROPELLER SHAFT ASSEMBLY</b> .....	96	<b>REAR DIFFERENTIAL GEAR OIL</b> .....	109	F
Inspection .....	96	Inspection .....	109	
<b>REMOVAL AND INSTALLATION</b> .....	97	Draining .....	109	
<b>REAR PROPELLER SHAFT</b> .....	97	Refilling .....	109	G
Exploded View .....	97	<b>REMOVAL AND INSTALLATION</b> .....	111	
Removal and Installation .....	97	<b>TORSIONAL DAMPER</b> .....	111	H
Inspection .....	99	Exploded View .....	111	
<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	101	Removal and Installation .....	111	I
<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	101	<b>SIDE OIL SEAL</b> .....	113	J
General Specifications .....	101	Exploded View .....	113	
Propeller Shaft Runout .....	101	Removal and Installation .....	113	K
Journal Axial Play .....	101	<b>ELECTRIC CONTROLLED COUPLING</b> .....	115	
<b>REAR FINAL DRIVE: R145K1</b>		Exploded View .....	115	L
<b>PRECAUTION</b> .....	102	Removal and Installation .....	115	
<b>PRECAUTIONS</b> .....	102	<b>FRONT OIL SEAL</b> .....	118	M
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	102	Exploded View .....	118	
Service Notice or Precautions for Rear Final Drive. ....	102	Removal and Installation .....	118	N
<b>PREPARATION</b> .....	103	<b>UNIT REMOVAL AND INSTALLATION</b> ...	122	O
<b>PREPARATION</b> .....	103	<b>REAR FINAL DRIVE ASSEMBLY</b> .....	122	
Special Service Tools .....	103	Exploded View .....	122	P
Commercial Service Tools .....	103	Removal and Installation .....	122	
<b>SYSTEM DESCRIPTION</b> .....	105	<b>UNIT DISASSEMBLY AND ASSEMBLY</b> .	125	
<b>STRUCTURE AND OPERATION</b> .....	105	<b>REAR FINAL DRIVE ASSEMBLY</b> .....	125	
Sectional View .....	105	Exploded View .....	125	
Electric Controlled Coupling .....	105	Disassembly .....	125	
<b>BASIC INSPECTION</b> .....	106	Assembly .....	126	
<b>ADDITIONAL SERVICE WHEN REPLACING REAR FINAL DRIVE ASSEMBLY</b> .....	106	Adjustment .....	128	
		Inspection .....	129	
		<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	130	
		<b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> .....	130	
		General Specification .....	130	
		Companion Flange Runout .....	130	

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009760279

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes dual stage front air bag modules. The SRS system may only deploy one front air bag, depending on the severity of a collision and whether the front passenger seat is occupied. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

#### Precaution for Procedure without Cowl Top Cover

INFOID:000000009694258

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



#### Precaution for Battery Service

INFOID:000000009694259

Before disconnecting the battery, lower both the driver and passenger windows. This will prevent any interference between the window edge and the vehicle when the door is opened/closed. During normal operation, the window slightly raises and lowers automatically to prevent any window to vehicle interference. The automatic window function will not work with the battery disconnected.

#### Service Notice or Precautions for Transfer

INFOID:000000009694260

- After overhaul refill the transfer with new transfer oil.
- Check the oil level or replace the oil only with the vehicle parked on level surface.
- During removal or installation, keep inside of transfer clear of dust or dirt.

# PRECAUTIONS

< PRECAUTION >

[TRANSFER: TY21C]

- Replace all tires at the same time. Always use tires of the proper size and the same brand and pattern. Fitting improper size and unusual wear tires applies excessive force to vehicle mechanism and can cause longitudinal vibration. A
- Disassembly should be done in a clean work area.
- Before proceeding with disassembly, thoroughly clean the transfer. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter. B
- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they do not interfere with the function of the parts when applied.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly. C
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with a new one if necessary. DLN
- Gaskets, seals, O-rings and lock nuts should be replaced any time when the transfer is disassembled.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, use it.
- Observe the specified torque when assembling. E
- Clean and flush the parts sufficiently and blow-dry them.
- Be careful not to damage sliding surfaces and mating surfaces.
- Use lint-free cloth or towels for wiping parts clean. Common shop rags can leave fibers that could interfere with the operation of the transfer. F

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# PREPARATION

< PREPARATION >

[TRANSFER: TY21C]




## PREPARATION

### PREPARATION

#### Special Service Tool



*INFOID:000000009694261*

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
ST33061000 (J-8107-2) Drift a: 38 mm (1.50 in) dia. b: 28.5 mm (1.122 in) dia.	Removing ring gear bearing (left) inner race (transfer case side)
 <p style="text-align: center;">ZZA0810D</p>	
KV381054S0 (J-34286) Puller	Removing ring gear shaft oil seal
 <p style="text-align: center;">ZZA0601D</p>	
ST3127S000 (J-25765-A) Preload gauge	Measuring preload torque
 <p style="text-align: center;">ZZA0503D</p>	

#### Commercial Service Tool

*INFOID:000000009694262*

Tool name	Description
Power tool	Loosening nuts and bolts and nuts
 <p style="text-align: center;">PBIC0190E</p>	
Drift a: 52 mm (2.05 in) dia. b: 44 mm (1.73 in) dia.	Removing gear ring bearing inner race (adapter case side)
 <p style="text-align: center;">ZZA1002D</p>	

# PREPARATION

< PREPARATION >

[TRANSFER: TY21C]

Tool name	Description
Drift a: 56.5 mm (2.224 in) dia. b: 48 mm (1.89 in) dia.	Installing side oil seal (installing transfer case oil seal)
Drift a: 44 mm (1.73 in) dia. b: 33 mm (1.3 in) dia.	Installing ring gear shaft oil seal
Puller	Removing ring gear bearing (left) inner race (transfer case side)
Drift a: 70 mm (2.76 in) dia. b: 60 mm (2.36 in) dia.	Installing oil seal (installing pinion bearing seal)
Drift a: 78 mm (3.07 in) dia. b: 68 mm (2.68 in) dia.	Installing side oil seal (installing transfer cover oil seal)
Replacer	<ul style="list-style-type: none"> <li>• Removing drive pinion</li> <li>• Removing ring gear bearing (left) inner race (transfer cover side)</li> </ul>
Drift a: 58 mm (2.28 in) dia. b: 55 mm (2.17 in) dia.	Installing ring gear bearing (left) inner race (transfer case side)

A  
B  
C

DLN

E  
F  
G  
H

I  
J

K  
L







M  
N

O  
P

# PREPARATION

< PREPARATION >

[TRANSFER: TY21C]

Tool name	Description
Drift a: 62 mm (2.44 in) dia. b: 58 mm (2.28 in) dia.	Installing ring gear bearing (right) inner race (transfer cover side)
 <p>NT115</p>	
Drift a: 73.5 mm (2.894 in) dia.	Installing ring gear bearing (left) outer race (transfer case side)
 <p>SCIA5338E</p>	
Drift a: 87 mm (3.43 in) dia.	Installing ring gear bearing (right) outer race (transfer cover side)
 <p>SCIA5338E</p>	
Drift a: 20 mm (0.79 in) dia.	Removing drive pinion
 <p>SCIA5338E</p>	
Drift a: 50 mm (1.97 in) dia. b: 41 mm (1.61 in) dia.	Installing pinion bearing
 <p>NT115</p>	
Drift a: 40 mm (1.57 in) dia. b: 25 mm (0.98 in) dia.	Installing companion flange
 <p>NT115</p>	



# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[TRANSFER: TY21C]

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000009694263



A. Rear final drive assembly

B. Inside storage room

No.	Component parts	Reference/Function
1	Combination meter (AWD warning icon/display)	Transmits/receives the signals for control of AWD system via CAN communication line to/from AWD control unit. For transmitting/receiving mainly signals, refer to <a href="#">DLN-14, "AWD SYSTEM : System Description"</a> Refer to <a href="#">MWI-6, "METER SYSTEM : Component Parts Location"</a> for detailed installation location.
2	Steering angle sensor	Transmits/receives the signals for control of AWD system via CAN communication line to/from AWD control unit. For transmitting/receiving mainly signals, refer to <a href="#">DLN-14, "AWD SYSTEM : System Description"</a> Refer to <a href="#">BRC-8, "Component Parts Location"</a> for detailed installation location.
3	ABS actuator and electric unit (control unit)	Transmits/receives the signals for control of AWD system via CAN communication line to/from AWD control unit. For transmitting/receiving mainly signals, refer to <a href="#">DLN-14, "AWD SYSTEM : System Description"</a> Refer to <a href="#">BRC-8, "Component Parts Location"</a> for detailed installation location.
4	TCM	Transmits/receives the signals for control of AWD system via CAN communication line to/from AWD control unit. For transmitting/receiving mainly signals, refer to <a href="#">DLN-14, "AWD SYSTEM : System Description"</a> Refer to <a href="#">TM-11, "CVT CONTROL SYSTEM : Component Parts Location"</a> for detailed installation location.

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[TRANSFER: TY21C]

No.	Component parts	Reference/Function
5	ECM	Transmits/receives the signals for control of AWD system via CAN communication line to/from AWD control unit. For transmitting/receiving mainly signals, refer to <a href="#">DLN-14. "AWD SYSTEM : System Description"</a> Refer to <a href="#">EC-15. "ENGINE CONTROL SYSTEM : Component Parts Location"</a> for detailed installation location.
6	Front wheel sensor	<a href="#">BRC-10. "Wheel Sensor and Sensor Rotor"</a>
7	Rear wheel sensor	
8	AWD solenoid	<a href="#">DLN-10. "AWD Solenoid"</a>
9	Electric controlled coupling	<a href="#">DLN-10. "Electric Controlled Coupling"</a>
10	AWD control unit	<a href="#">DLN-10. "AWD Control Unit"</a>

## AWD Control Unit

INFOID:000000009694264

- Controls driving force distribution by signals from each sensor from front wheel driving mode (100:0) to 4-wheel driving mode (50:50).
- Front wheel driving conditions is available by fail-safe function if malfunction is detected in AWD system.
- AWD actuator relay is integrated with AWD control unit, and supplies AWD solenoid with voltage.

## AWD Solenoid

INFOID:000000009694265

Controls electric controlled coupling by command current from AWD control unit.

## Electric Controlled Coupling

INFOID:000000009694266



Electric controlled coupling is integrated with rear final drive and transmits driving force to rear final drive. For operation, refer to [DLN-12. "Operation Description"](#).

## AWD Warning Icon/Display

INFOID:000000009694267

AWD warning icon/display is displayed when there is a malfunction in AWD system. AWD warning icon/display indicates the vehicle is in fail-safe mode and shifting to front-wheel drive or 4-wheel drive (rear-wheels still have some driving torque).


### AWD WARNING ICON/DISPLAY INDICATION

Condition	AWD warning icon/display
AWD system malfunction	 <p style="text-align: right;"><small>JSDIA3103GB</small></p>
Protection function is activated due to heavy load to electric controlled coupling. (AWD system is not malfunctioning and AWD system changes to front wheel drive.) When this message is displayed, refer to <a href="#">DLN-62. "Description"</a> .	 <p style="text-align: right;"><small>JSDIA3104GB</small></p> <p>(Displaying for approximately 1 minute and then turned OFF)</p>

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[TRANSFER: TY21C]

Condition	AWD warning icon/display
Large difference in diameter of front/rear tires When this message is displayed, refer to <a href="#">DLN-63. "Diagnosis Procedure"</a> .	 <p style="font-size: small; margin-top: 10px;">JSDIA3105GB (Continuing to display until ignition switch is turned OFF)</p>
Other than above (system normal)	OFF

A  
B  
C  
**DLN**

**CAUTION:**

- AWD warning icon/display is displayed due to data reception error, CAN communication error etc.

E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# STRUCTURE AND OPERATION


< SYSTEM DESCRIPTION >

[TRANSFER: TY21C]

## STRUCTURE AND OPERATION

### Sectional View

INFOID:000000009694268




JSDIA3966ZZ

- |                     |                   |  |
|---------------------|-------------------|--|
| 1. Transfer cover   | 2. Transfer case  | 3. Ring gear bearing (transfer case side)  |
| 4. Ring gear shaft  | 5. Pinion bearing | 6. Drive pinion                            |
| 7. Companion flange | 8. Ring gear      | 9. Ring gear bearing (transfer cover side) |

### Operation Description

INFOID:000000009694269

### POWER TRANSFER DIAGRAM



SDIA1607E


# STRUCTURE AND OPERATION

< SYSTEM DESCRIPTION >


[TRANSFER: TY21C]

## ELECTRIC CONTROLLED COUPLING

1. The AWD control unit supplies command current to electric controlled coupling (AWD solenoid).
2. The control clutch is engaged by electromagnet and torque is detected in control clutch.
3. The cam operates in response to control clutch torque and applies pressure to main clutch.
4. The main clutch transmits torque to front wheels according to pressing power.



- Transmission torque to the rear wheels is determined according to command current.



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


SYSTEM

AWD SYSTEM

AWD SYSTEM : System Description

INFOID:000000009694270

SYSTEM DIAGRAM



INPUT/OUTPUT SIGNAL

It transmits/receives each signal from the following AWD control unit via CAN communication line.

Component parts	Function
ABS actuator and electric unit (control unit)	Transmits the following signals via CAN communication to AWD control unit. <ul style="list-style-type: none"> <li>• Vehicle speed signal</li> <li>• Stop lamp switch signal (brake signal)</li> <li>• Yaw rate sensor signal</li> <li>• Side G sensor signal</li> <li>• Decel G sensor signal</li> </ul>
ECM	Transmits the following signals via CAN communication to AWD control unit. <ul style="list-style-type: none"> <li>• Accelerator pedal position signal</li> <li>• Engine speed signal</li> </ul>
TCM	Transmits the following signals via CAN communication to AWD control unit. <ul style="list-style-type: none"> <li>• Input shaft revolutionary signal</li> <li>• CVT ratio signal</li> </ul>
Combination meter	Transmits conditions of parking brake switch signal via CAN communication to AWD control unit. Receives the following signal via CAN communication from AWD control unit. <ul style="list-style-type: none"> <li>• AWD warning icon/display signal</li> </ul>
Steering angle sensor	Transmits conditions of steering angle sensor signal via CAN communication to AWD control unit.

# SYSTEM

< SYSTEM DESCRIPTION >

[TRANSFER: TY21C]

## DESCRIPTION

- AWD controls distribution of drive power between front-wheel drive (100:0) and 4-wheel drive (50:50) conditions according to signals from sensors.
- By receiving the steering angle sensor signal, yaw rate sensor signal, side G sensor signal and decel G sensor signal, vehicle with VDC corrects a torque distribution for front and rear wheels according to a driving operation and a behavior of the vehicle during cornering and improves drivability and safety on a slippery road surface.
- Electronic control allows optimal distribution of torque to front/rear wheels to match road conditions.
- AWD mode makes possible stable driving possible with no wheel spin, on snowy roads or other slippery surfaces.
- On roads which do not require 4-wheel drive, it contributes to improved fuel economy by driving in conditions close to front-wheel drive.
- Sensor inputs determine the vehicle's turning condition, and tight cornering/braking are controlled by distributing optimum torque to rear wheels.


A  
B  
C  
DLN

### NOTE:

Light tight-corner braking symptom may occur depending on driving condition. This is not malfunction.

## AWD SYSTEM : Circuit Diagram

INFOID:000000009694271



F  
G  
H  
I  
J  
K  
L  
M  
N  
O

## AWD SYSTEM : Fail-Safe

INFOID:000000009694272

- If any malfunction occurs in AWD electrical system, and control unit detects the malfunction, AWD warning icon/display on information display is displayed to indicate system malfunction.
- When AWD warning icon/display is displayed, vehicle changes to front-wheel drive or shifts to 4-wheel drive (rear-wheels still have some driving torque).

P

# SYSTEM

< SYSTEM DESCRIPTION >

[TRANSFER: TY21C]

DTC	AWD warning icon/display	Possible cause	Vehicle condition	
C1201	<div style="border: 1px solid black; padding: 5px; display: inline-block;"> <b>AWD Error:</b> See Owner's Manual                 </div>	Internal malfunction of AWD control unit	Front-wheel drive or shifts to 4-wheel drive (Rear-wheels still have some driving torque)	
C1203		ABS malfunction <ul style="list-style-type: none"> <li>Vehicle speed signal error</li> </ul>		
C1204		<ul style="list-style-type: none"> <li>Internal malfunction of electronic controlled coupling</li> <li>Malfunction of AWD solenoid power supply circuit (open or short)</li> <li>Malfunction of AWD solenoid command current</li> </ul>		
C1205		<ul style="list-style-type: none"> <li>Internal malfunction of AWD control unit</li> <li>Malfunction of AWD solenoid power supply circuit (ground short)</li> </ul>		
C1210		Malfunction of engine control system		
P1804		JSDIA3103GB		Internal malfunction of AWD control unit
P181F				Writing unit characteristics is incomplete.
U1000				<ul style="list-style-type: none"> <li>CAN communication error</li> <li>Malfunction of AWD control unit</li> </ul>
U1010				Malfunction of AWD control unit

## AWD SYSTEM : Protection Function

INFOID:000000009694273

AWD system activates its protection function (shuts down AWD system temporarily) if AWD system detects high load continuously or the front wheel tire size differs from the rear tire size. (AWD system is automatically restored if AWD system no longer detects any overload or the tire size difference is eliminated.)

AWD warning icon/display	Possible cause	Vehicle condition
<div style="border: 1px solid black; padding: 5px; display: inline-block;"> <b>AWD High Temp. Stop Vehicle</b> </div> <p style="text-align: center; font-size: small;">JSDIA3104GB (Displaying for approximately 1 minute and then turned OFF)</p>	Drive train parts in protection mode. It is not malfunction. (Internal temperature rise of electronic controlled coupling) When this message is displayed, refer to <a href="#">DLN-62, "Description"</a> .	Shuts down AWD system temporarily (Front wheel drive)
<div style="border: 1px solid black; padding: 5px; display: inline-block;"> <b>AWD Tire Size Incorrect: See Owner's Manual</b> </div> <p style="text-align: center; font-size: small;">JSDIA3105GB (Continuing to display until ignition switch is turned OFF)</p>	Malfunction in each tire or different tire diameter When this message is displayed, refer to <a href="#">DLN-63, "Diagnosis Procedure"</a> .	



# DIAGNOSIS SYSTEM (AWD CONTROL UNIT)

< SYSTEM DESCRIPTION >

[TRANSFER: TY21C]

## DIAGNOSIS SYSTEM (AWD CONTROL UNIT)

### CONSULT Function

INFOID:000000009694274

#### CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

### APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes as follows.

Diagnostic test mode	Function
ECU Identification	AWD control unit part number can be read.
Self Diagnostic Result	Self-diagnostic results and freeze frame data can be read and erased quickly.*
Data Monitor	Input/Output data in the AWD control unit can be read.
Active Test	Diagnostic Test Mode in which CONSULT drives some actuators apart from the AWD control unit and also shifts some parameters in a specified range.
Work support	This mode enable a technician to adjust some devices faster and more accurately by following the indication on the CONSULT.

\*: The following diagnosis information is erased by erasing.

- DTC
- Freeze frame data (FFD)

### ECU IDENTIFICATION

AWD control unit part number can be read.

### SELF DIAGNOSTIC RESULT

Refer to [DLN-22, "DTC Index"](#).

When "PRSNT" is displayed on self-diagnosis result.

- The system is presently malfunctioning.

When "PAST" is displayed on self-diagnosis result.

- System malfunction in the past is detected, but the system is presently normal.

### FREEZE FRAME DATA (FFD)

The following vehicle status is recorded when DTC is detected and is displayed.

Freeze Frame Data Item	Description
IGN COUNTER [0 - 39]	<p>The number of times that ignition switch is turned ON after the DTC is detected is displayed.</p> <ul style="list-style-type: none"><li>• When "0" is displayed: It indicates that the system is presently malfunctioning.</li><li>• When except "0" is displayed: It indicates that system malfunction in the past is detected, but the system is presently normal.</li></ul> <p><b>NOTE:</b> Each time when ignition switch is turned OFF to ON, numerical number increases in 1→2→3...38→39. When the operation number of times exceeds 39, the number do not increase and "39" is displayed until self-diagnosis is erased.</p>

### DATA MONITOR

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item (Unit)	Remarks
STOP LAMP SW [On/Off]	Stop lamp switch signal status via CAN communication line is displayed.
ENG SPEED SIG [Run/Stop]	Engine status is displayed.
ETS ACTUATOR [On/Off]	Operating condition of AWD actuator relay (integrated in AWD control unit) is displayed.

# DIAGNOSIS SYSTEM (AWD CONTROL UNIT)

< SYSTEM DESCRIPTION >

[TRANSFER: TY21C]

Monitor item (Unit)	Remarks
4WD WARN LAMP [On/Off]	Control status of AWD warning icon/display is displayed.
4WD MODE SW [AUTO/LOCK]	Mode switch is not equipped, but displayed.
4WD MODE MON [AUTO/LOCK]	Control status of AWD is displayed.
DIS-TIRE MONI [mm]	Improper size tire installed condition is displayed.
P BRAKE SW [On/Off]	Parking switch signal status via CAN communication line is displayed.
BATTERY VOLT [V]	Power supply voltage for AWD control unit
THRTL POS SEN [%]	Throttle opening status is displayed.
ETS SOLENOID [A]	Monitored value of current at AWD solenoid
FR RH SENSOR [km/h] or [mph]	Wheel speed calculated by front RH wheel sensor signal is displayed.
FR LH SENSOR [km/h] or [mph]	Wheel speed calculated by front LH wheel sensor signal is displayed.
RR RH SENSOR [km/h] or [mph]	Wheel speed calculated by rear RH wheel sensor signal is displayed.
RR LH SENSOR [km/h] or [mph]	Wheel speed calculated by rear LH wheel sensor signal is displayed.

## ACTIVE TEST

Use this mode to determine and identify the details of a malfunction based on self-diagnostic results or data monitor. AWD control unit gives drive signal to actuator with receiving command from CONSULT to check operation of actuator.

Test item	Condition	Description
ETS S/V (Detects AWD solenoid)	<ul style="list-style-type: none"> <li>• Vehicle stopped</li> <li>• Engine running</li> <li>• No DTC detected</li> </ul>	Change command current value to AWD solenoid, and then change driving mode. (Monitor value is normal if it is within approx. $\pm 10\%$ of command value.) <ul style="list-style-type: none"> <li>• Qu: Increase current value in increments of 0.2 A</li> <li>• Qd: Decrease current value in increments of 0.2 A</li> <li>• UP: Increase current value in increments of 0.02 A</li> <li>• DOWN: Decrease current value in increments of 0.02 A</li> </ul>

### CAUTION:

**Never energize continuously for a long time.**

## WORK SUPPORT

Item	Usage
UNIT CHARACTERISTICS DATA	Display the unit characteristics of electric controlled coupling written to AWD control unit.
UNIT CHARACTERISTICS WRITE	Writes the unit characteristics of electric controlled coupling to AWD control unit.

# AWD CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[TRANSFER: TY21C]

## ECU DIAGNOSIS INFORMATION

### AWD CONTROL UNIT

#### Reference Value

INFOID:000000009694275

#### VALUES ON THE DIAGNOSIS TOOL

**NOTE:**

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item	Condition	Value/Status
STOP LAMP SW	Brake pedal: Depressed	On
	Brake pedal: Released	Off
ENG SPEED SIG	Engine stopped (Engine speed: Less than 400 rpm)	Stop
	Engine running (Engine speed: 400 rpm or more)	Run
ETS ACTUATOR	Engine stopped (Ignition switch: ON)	Off
	Engine running	On
4WD WARN LAMP	AWD warning icon/display: ON	On
	AWD warning icon/display: OFF	Off
4WD MODE SW	Always	AUTO
4WD MODE MON	Always	AUTO
DIS-TIRE MONI	Vehicle running with normal size tire installed	0 – 4 mm
	Vehicle running with improper size tire installed (Front/rear tire size difference, wear condition)	4 – 8 mm, 8 – mm
P BRAKE SW	Parking brake operated	On
	Parking brake not operated	Off
BATTERY VOLT	Always	Battery voltage
THRTL POS SEN	When depressing accelerator pedal (Value rises gradually in response to throttle position.)	0 – 100%
ETS SOLENOID	Engine running • At idle speed	Approx. 0.000 A
	Engine running • 3,000 rpm or more constant	Approx. 0.000 – 1.800 A*
FR RH SENSOR	Vehicle stopped	0.00 km/h (0.00 mph)
	Vehicle running <b>CAUTION:</b> <b>Check air pressure of tire under standard condition.</b>	Nearly matches the speed meter display (±10% or less)
FR LH SENSOR	Vehicle stopped	0.00 km/h (0.00 mph)
	Vehicle running <b>CAUTION:</b> <b>Check air pressure of tire under standard condition.</b>	Nearly matches the speed meter display (±10% or less)
RR RH SENSOR	Vehicle stopped	0.00 km/h (0.00 mph)
	Vehicle running <b>CAUTION:</b> <b>Check air pressure of tire under standard condition.</b>	Nearly matches the speed meter display (±10% or less)
RR LH SENSOR	Vehicle stopped	0.00 km/h (0.00 mph)
	Vehicle running <b>CAUTION:</b> <b>Check air pressure of tire under standard condition.</b>	Nearly matches the speed meter display (±10%)


# AWD CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[TRANSFER: TY21C]

\*: The values are changed by throttle opening and engine speed.

## TERMINAL LAYOUT



## PHYSICAL VALUES

Terminal No. (Wire color)		Description	Input/ Output	Condition	Value (Approx.)
+	-				
1 (LG)	Ground	AWD solenoid power supply	Output	Engine speed: At idle	0 V
				Engine speed: 3,000 rpm or more constant	2.5 V*
2 (V)	Ground	AWD solenoid ground	—	Always	0 V
7 (W)	Ground	Ignition switch	Input	Ignition switch: ON	Battery voltage
				Ignition switch: OFF	0 V
8 (L)	—	CAN-H	Input/ Output	—	—
9 (SB)	Ground	Power supply (AWD solenoid)	Input	Always	Battery voltage
10 (GR)	Ground	Ground	—	Always	0 V
11 (GR)	Ground	Ground	—	Always	0 V
15 (Y)	Ground	Power supply (AWD control unit)	Input	Always	Battery voltage
16 (P)	—	CAN-L	Input/ Output	—	—

\*: The values are changed by throttle opening and engine speed.

### **CAUTION:**

**When using circuit tester to measure voltage for inspection, be sure not to extend forcibly any connector terminals.**

## Fail-Safe

INFOID:000000009694276

- If any malfunction occurs in AWD electrical system, and control unit detects the malfunction, AWD warning icon/display on information display is displayed to indicate system malfunction.
- When AWD warning icon/display is displayed, vehicle changes to front-wheel drive or shifts to 4-wheel drive (rear-wheels still have some driving torque).

# AWD CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[TRANSFER: TY21C]

DTC	AWD warning icon/display	Possible cause	Vehicle condition	
C1201	<div style="border: 1px solid black; padding: 5px; display: inline-block;"> <b>AWD Error:</b> See Owner's Manual                 </div>	Internal malfunction of AWD control unit	Front-wheel drive or shifts to 4-wheel drive (Rear-wheels still have some driving torque)	
C1203		ABS malfunction <ul style="list-style-type: none"> <li>• Vehicle speed signal error</li> </ul>		
C1204		<ul style="list-style-type: none"> <li>• Internal malfunction of electronic controlled coupling</li> <li>• Malfunction of AWD solenoid power supply circuit (open or short)</li> <li>• Malfunction of AWD solenoid command current</li> </ul>		
C1205		<ul style="list-style-type: none"> <li>• Internal malfunction of AWD control unit</li> <li>• Malfunction of AWD solenoid power supply circuit (ground short)</li> </ul>		
C1210		Malfunction of engine control system		
P1804		JSDIA3103GB		Internal malfunction of AWD control unit
P181F				Writing unit characteristics is incomplete.
U1000				<ul style="list-style-type: none"> <li>• CAN communication error</li> <li>• Malfunction of AWD control unit</li> </ul>
U1010				Malfunction of AWD control unit

## Protection Function

INFOID:000000009694277

AWD system activates its protection function (shuts down AWD system temporarily) if AWD system detects high load continuously or the front wheel tire size differs from the rear tire size. (AWD system is automatically restored if AWD system no longer detects any overload or the tire size difference is eliminated.)

AWD warning icon/display	Possible cause	Vehicle condition
<div style="border: 1px solid black; padding: 5px; display: inline-block;"> <b>AWD High Temp. Stop Vehicle</b> </div> <p style="text-align: center; font-size: small;">JSDIA3104GB (Displaying for approximately 1 minute and then turned OFF)</p>	Drive train parts in protection mode. It is not malfunction. (Internal temperature rise of electronic controlled coupling) When this message is displayed, refer to <a href="#">DLN-62, "Description"</a> .	Shuts down AWD system temporarily (Front wheel drive)
<div style="border: 1px solid black; padding: 5px; display: inline-block;"> <b>AWD Tire Size Incorrect: See Owner's Manual</b> </div> <p style="text-align: center; font-size: small;">JSDIA3105GB (Continuing to display until ignition switch is turned OFF)</p>	Malfunction in each tire or different tire diameter When this message is displayed, refer to <a href="#">DLN-63, "Diagnosis Procedure"</a> .	

## DTC Inspection Priority Chart

INFOID:000000009694278

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> <li>• U1000 CAN COMM CIRCUIT</li> <li>• U1010 CONTROL UNIT (CAN)</li> </ul>
2	<ul style="list-style-type: none"> <li>• C1201 CONTROLLER FAILURE</li> <li>• C1205 4WD ACTUATOR RLY</li> </ul>

# AWD CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[TRANSFER: TY21C]

Priority	Detected items (DTC)
3	• C1204 4WD SOLENOID
4	• C1203 ABS SYSTEM • C1210 ENGINE SIGNAL 1
5	• P1804 CONTROL UNIT 3
6	• P181F INCOMP CALIBRATION

## DTC Index

INFOID:000000009694279

DTC	Display Item	Reference
C1201	CONTROLLER FAILURE	<a href="#">DLN-43, "DTC Logic"</a>
C1203	ABS SYSTEM	<a href="#">DLN-44, "DTC Logic"</a>
C1204	4WD SOLENOID	<a href="#">DLN-45, "DTC Logic"</a>
C1205	4WD ACTUATOR RLY	<a href="#">DLN-48, "DTC Logic"</a>
C1210	ENGINE SIGNAL 1	<a href="#">DLN-50, "DTC Logic"</a>
P1804	CONTROL UNIT 3	<a href="#">DLN-51, "DTC Logic"</a>
P181F	INCOMP CALIBRATION	<a href="#">DLN-52, "DTC Logic"</a>
U1000	CAN COMM CIRCUIT	<a href="#">DLN-53, "DTC Logic"</a>
U1010	CONTROL UNIT (CAN)	<a href="#">DLN-54, "DTC Logic"</a>

< WIRING DIAGRAM >

# WIRING DIAGRAM


## AWD SYSTEM

### Wiring Diagram

#### WITH AUTOMATIC DRIVE POSITIONER

INFOID:000000009694280

### AWD SYSTEM - WITH AUTOMATIC DRIVE POSITIONER




ABDWA0686GB

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


AWD SYSTEM CONNECTORS - WITH AUTOMATIC DRIVE POSITIONER

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2N	BG	-


Connector No.	M5
Connector Name	CAN GATEWAY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	CAN-H
4	L	CAN-H
5	B	GND


Terminal No.	Color of Wire	Signal Name
6	L	CAN-H
7	P	CAN-L
10	P	CAN-L
11	B	GND
12	P	CAN-L

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
38	P	CAN-L
39	L	CAN-H

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
35G	P	-
36G	L	-

ABDIA1072GB




Connector No.	M41
Connector Name	JOINT CONNECTOR-M18
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
3	P	-

Terminal No.	Color of Wire	Signal Name
73A	BG	-
89A	L	-
90A	P	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Connector No.	E16
Connector Name	ECM
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
113	P	CAN-L
114	L	CAN-H

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-

Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
3	L	-

ABDIA1083GB

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# AWD SYSTEM

< WIRING DIAGRAM >


[TRANSFER: TY21C]

Connector No.	E70
Connector Name	JOINT CONNECTOR-E14
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
3	P	-

Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
7	P	-
8	P	-

Connector No.	E34
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
20	LG	-
21	SB	-

Connector No.	E125
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
15	P	CAN-L
25	L	CAN-H

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
19	SB	SUB ECU

Connector No.	E71
Connector Name	JOINT CONNECTOR-E15
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	L	-

AADIA0312GB

# AWD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: TY21C]


Connector No.	C12
Connector Name	AWD SOLENOID
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	Y	-

Terminal No.	Color of Wire	Signal Name
35G	P	-
36G	L	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B12
Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	B11
Connector Name	JOINT CONNECTOR-B09
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	C13
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
13	SB	-
14	Y	-

AADIA0313GB

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# AWD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: TY21C]

Connector No.	B17
Connector Name	JOINT CONNECTOR-B12
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	L	-

Connector No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
3	P	-

Connector No.	B13
Connector Name	WIRE TO WIRE
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
13	LG	-
14	V	-

Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20	SB	-
21	W	-

Connector No.	B32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-


ABDIA1084GB

# AWD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: TY21C]


Connector No.	B67
Connector Name	AWD CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	AWD SOLENOID (+)
2	V	AWD SOLENOID (-)
3	-	-
4	-	-
5	-	-


Terminal No.	Color of Wire	Signal Name
6	-	-
7	W	IGNITION SWITCH
8	L	CAN-H
9	SB	BATTERY (AWD SOLENOID)
10	GR	GROUND
11	GR	GROUND
12	-	-
13	-	-
14	-	-
15	Y	BATTERY (CONTROL UNIT)
16	P	CAN-L

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	GRAY



ABDIA1085GB

Connector No.	B101
Connector Name	WIRE TO WIRE
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-

Terminal No.	Color of Wire	Signal Name
73A	Y	-
89A	L	-
90A	P	-

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

Connector No.	B124
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-

Connector No.	B103
Connector Name	JOINT CONNECTOR-B15
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	B102
Connector Name	JOINT CONNECTOR-B14
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

ABDIA1086GB


# AWD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: TY21C]

## WITHOUT AUTOMATIC DRIVE POSITIONER

### AWD SYSTEM - WITHOUT AUTOMATIC DRIVE POSITIONER




ABDWA0685GB

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


AWD SYSTEM CONNECTORS - WITHOUT AUTOMATIC DRIVE POSITIONER

Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2N	BG	-

Connector No.	M24
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
38	P	CAN-L
39	L	CAN-H

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
35G	P	-
36G	L	-

ABDIA1087GB



# AWD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: TY21C]


Connector No.	M41
Connector Name	JOINT CONNECTOR-M18
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Terminal No.	Color of Wire	Signal Name
73A	BG	-
89A	L	-
90A	P	-

Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Connector No.	E34
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20	LG	-
21	SB	-

Connector No.	E16
Connector Name	ECM
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
113	P	CAN-L
114	L	CAN-H

Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

ABDIA1088GB

A  
B  
C  
**DLN**  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# AWD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: TY21C]

Connector No.	E71
Connector Name	JOINT CONNECTOR-E15
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	L	-

Connector No.	E70
Connector Name	JOINT CONNECTOR-E14
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-
3	P	-

Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
7	P	-
8	P	-

Connector No.	E125
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
15	P	CAN-L
25	L	CAN-H

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
19	SB	SUB ECU

AADIA0319GB

# AWD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: TY21C]


Connector No.	C12
Connector Name	AWD SOLENOID
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	SB	-
2	Y	-

Terminal No.	Color of Wire	Signal Name
35G	P	-
36G	L	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	B12
Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

Connector No.	B11
Connector Name	JOINT CONNECTOR-B09
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-

Connector No.	C13
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
13	SB	-
14	Y	-

AADIA0320GB


A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# AWD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: TY21C]

Connector No.	B17
Connector Name	JOINT CONNECTOR-B12
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	L	-
3	L	-

Connector No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	P	-
3	P	-


Connector No.	B13
Connector Name	WIRE TO WIRE
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
13	LG	-
14	V	-

Terminal No.	Color of Wire	Signal Name
6	-	-
7	W	IGNITION SWITCH
8	L	CAN-H
9	SB	BATTERY (AWD SOLENOID)
10	GR	GROUND
11	GR	GROUND
12	-	-
13	-	-
14	-	-
15	Y	BATTERY (CONTROL UNIT)
16	P	CAN-L

Connector No.	B67
Connector Name	AWD CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	AWD SOLENOID (+)
2	V	AWD SOLENOID (-)
3	-	-
4	-	-
5	-	-

Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20	SB	-
21	W	-

AADIA0321GB


# AWD SYSTEM

< WIRING DIAGRAM >

[TRANSFER: TY21C]

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
73A	Y	-
89A	L	-
90A	P	-

ABDIA1089GB

# BASIC INSPECTION

## DIAGNOSIS AND REPAIR WORK FLOW

### Work Flow

INFOID:000000009694281

#### DETAILED FLOW

### 1. INTERVIEW FROM THE CUSTOMER

Clarify customer complaints before inspection. First of all, perform an interview utilizing [DLN-39, "Diagnostic Work Sheet"](#) and reproduce symptoms as well as fully understand it. Ask customer about his/her complaints carefully. Check symptoms by driving vehicle with customer, if necessary.

**CAUTION:**

**Customers are not professional. Never guess easily like "maybe the customer means that..." or "maybe the customer mentions this symptom".**

&gt;&gt; GO TO 2.

### 2. CHECK SYMPTOM

Reproduce the symptom that is indicated by the customer, based on the information from the customer obtained by interview. Also check that the symptom is not caused by protection function. Refer to [DLN-21, "Protection Function"](#).

**CAUTION:**

**When the symptom is caused by normal operation, fully inspect each portion and obtain the understanding of customer that the symptom is not caused by a malfunction.**

&gt;&gt; GO TO 3.

### 3. PERFORM SELF-DIAGNOSIS

**With CONSULT**

Perform self-diagnosis for "ALL MODE AWD/4WD".

Is any DTC detected?

YES >> Record or print self-diagnosis results. GO TO 4.

NO >> GO TO 6.

### 4. RECHECK SYMPTOM

**With CONSULT**

1. Erase self-diagnostic results for "ALL MODE AWD/4WD".

2. Perform DTC confirmation procedures for the error detected system.

**NOTE:**

If some DTCs are detected at the same time, determine the order for performing the diagnosis based on [LAN-26, "Trouble Diagnosis Flow Chart"](#).

Is any DTC detected?

YES >> GO TO 5.

NO >> Check harness and connectors based on the information obtained by interview. Refer to [GI-53, "Intermittent Incident"](#).

### 5. REPAIR OR REPLACE ERROR-DETECTED PARTS

- Repair or replace error-detected parts.
- Reconnect part or connector after repairing or replacing.
- When DTC is detected, erase self-diagnostic results for "ALL MODE AWD/4WD".

&gt;&gt; GO TO 7.

### 6. IDENTIFY ERROR-DETECTED SYSTEM BY SYMPTOM DIAGNOSIS

Estimate error-detected system based on symptom diagnosis and perform inspection.

Can the error-detected system be identified?

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[TRANSFER: TY21C]

YES >> GO TO 7.

NO >> Check harness and connectors based on the information obtained by interview. Refer to [GI-53](#), "Intermittent Incident".

## 7. FINAL CHECK

### With CONSULT

1. Check the reference value for AWD control module.
2. Recheck the symptom and check that symptom is not reproduced on the same conditions.

Is the symptom reproduced?

YES >> GO TO 3.

NO >> INSPECTION END

## Diagnostic Work Sheet

INFOID:000000009694282

### Description

- In general, customers have their own criteria for a problem. Therefore, it is important to understand the symptom and status well enough by asking the customer about his/her concerns carefully. To systemize all the information for the diagnosis, prepare the interview sheet referring to the interview points.
- In some cases, multiple conditions that appear simultaneously may cause a DTC to be detected.

### Interview sheet sample

Interview sheet					
Customer name	MR/MS	Registration number		Initial year registration	
		Vehicle type		VIN	
Storage date		Engine		Mileage	km (Mile)
Symptom		<input type="checkbox"/> Vehicle does not enter AWD mode.			
		<input type="checkbox"/> AWD warning icon/display is displayed.			
		<input type="checkbox"/> Heavy tight-corner braking symptom occurs			
		<input type="checkbox"/> Noise <input type="checkbox"/> Vibration			
		<input type="checkbox"/> Others ( _____ )			
First occurrence		<input type="checkbox"/> Recently <input type="checkbox"/> Others ( _____ )			
Frequency of occurrence		<input type="checkbox"/> Always <input type="checkbox"/> Under a certain conditions of _____ <input type="checkbox"/> Sometimes (time(s)/day)			
Climate conditions	<input type="checkbox"/> Irrelevant				
	Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloud <input type="checkbox"/> Rain <input type="checkbox"/> Snow <input type="checkbox"/> Others ( _____ )			
	Temperature	<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold <input type="checkbox"/> Temperature (Approx. _____ °C)			
	Relative humidity	<input type="checkbox"/> High <input type="checkbox"/> Moderate <input type="checkbox"/> Low			
Road conditions		<input type="checkbox"/> Urban area <input type="checkbox"/> Suburb area <input type="checkbox"/> High way <input type="checkbox"/> Mounting road (uphill or down hill) <input type="checkbox"/> Rough road			
Operation conditions, etc.		<input type="checkbox"/> Irrelevant <input type="checkbox"/> When engine starts <input type="checkbox"/> During idling <input type="checkbox"/> During driving <input type="checkbox"/> During acceleration <input type="checkbox"/> At constant speed driving <input type="checkbox"/> During deceleration <input type="checkbox"/> During cornering (right curve or left curve)			

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[TRANSFER: TY21C]

## Interview sheet

Customer name	MR/MS	Registration number		Initial year registration	
		Vehicle type		VIN	
Storage date		Engine		Mileage	km (Mile)
Other conditions					

Memo



# ADDITIONAL SERVICE WHEN REPLACING AWD CONTROL UNIT

< BASIC INSPECTION >

[TRANSFER: TY21C]

## ADDITIONAL SERVICE WHEN REPLACING AWD CONTROL UNIT

### Description

INFOID:000000009694283

When replacing AWD control unit, unit characteristics writing is required.

### Work Procedure

INFOID:000000009694284

#### 1.PERFORM WRITING UNIT CHARACTERISTICS

Perform writing unit characteristics of electric controlled coupling.

>> Refer to [DLN-42. "Work Procedure"](#).

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# UNIT CHARACTERISTICS WRITING

< BASIC INSPECTION >

[TRANSFER: TY21C]

## UNIT CHARACTERISTICS WRITING

### Description

INFOID:000000009694285

When replacing AWD control unit, rear final drive assembly and/or electric controlled coupling, unit characteristics of electric controlled coupling writing is required.

### Work Procedure

INFOID:000000009694286

## 1. UNIT CHARACTERISTICS WRITING


### ④ With CONSULT

1. Confirm the unit characteristics (A) of electric controlled coupling.

#### NOTE:

Unit characteristics is 12-digit alphanumeric.

2. Turn the ignition switch OFF to ON.
3. Select "UNIT CHARACTERISTICS WRITE" in "WORK SUPPORT" for "ALL MODE AWD/4WD".
4. Input unit characteristics.
5. Select "Start".
6. Check that "UNIT CHARACTERISTICS WRITE COMPLETED" is displayed.



>> WORK END

# DTC/CIRCUIT DIAGNOSIS

## C1201 AWD CONTROL UNIT

### DTC Logic

INFOID:000000009694287

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1201	CONTROLLER FAILURE	Malfunction has occurred inside AWD control unit.	Internal malfunction of AWD control unit

A  
B  
C  
DLN

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION

##### Ⓜ With CONSULT

- Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "C1201" detected?

- YES >> Proceed to [DLN-43, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000009694288

#### 1. PERFORM SELF-DIAGNOSIS

##### Ⓜ With CONSULT

- Erase self-diagnostic results for "ALL MODE AWD/4WD".
- Turn the ignition switch OFF, and then wait 10 seconds or more.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "C1201" detected?

- YES >> Replace AWD control unit. Refer to [DLN-67, "Removal and Installation"](#).
- NO >> Check AWD control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace error-detected parts.

E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# C1203 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: TY21C]

## C1203 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### DTC Logic

INFOID:000000009694289

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1203	ABS SYSTEM	Malfunction related to wheel sensor has been detected by ABS actuator and electric unit (control unit).	ABS malfunction <ul style="list-style-type: none"><li>Vehicle speed signal error</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

##### 2. PERFORM DTC CONFIRMATION

###### Ⓟ With CONSULT

- Start the engine and drive at 30 km/h (19 MPH) or more for approximately 1 minute.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "C1203" detected?

- YES >> Proceed to [DLN-44, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

#### Diagnosis Procedure

INFOID:000000009694290

##### 1. PERFORM ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF-DIAGNOSIS

###### Ⓟ With CONSULT

Perform self-diagnosis for "ABS".

Is any DTC detected?

- YES >> Check the DTC. Refer to [TM-61, "DTC Index"](#).  
NO >> GO TO 2.

##### 2. CHECK TERMINALS AND HARNESS CONNECTORS

Check AWD control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. If DTC "C1203" is detected, Replace AWD control unit. Refer to [DLN-67, "Removal and Installation"](#).  
NO >> Repair or replace error-detected parts.

# C1204 AWD SOLENOID

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: TY21C]

## C1204 AWD SOLENOID

### DTC Logic

INFOID:000000009694291

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1204	4WD SOLENOID	Malfunction related to AWD solenoid has been detected.	<ul style="list-style-type: none"> <li>Internal malfunction of electronic controlled coupling</li> <li>Malfunction of AWD solenoid power supply circuit (open or short)</li> <li>Malfunction of AWD solenoid command current</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION

##### With CONSULT

- Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "C1204" detected?

- YES >> Proceed to [DLN-45, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000009694292

#### 1. CHECK AWD SOLENOID POWER SUPPLY (1)

- Turn the ignition switch OFF.
- Disconnect AWD control unit harness connector.
- Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
B67	9	Ground	Battery voltage

- Turn the ignition switch ON.  
**CAUTION:**  
**Never start the engine.**
- Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
B67	9	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 2.

#### 2. CHECK AWD SOLENOID POWER SUPPLY (2)

- Turn the ignition switch OFF.
- Check the 10A fuse (#62)

# C1204 AWD SOLENOID

[TRANSFER: TY21C]

< DTC/CIRCUIT DIAGNOSIS >

3. Check the harness for open or short between AWD control unit harness connector No.9 terminal and 10A fuse (#62).

Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit. Refer to [PG-11. "Wiring Diagram - BATTERY POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

## 3.CHECK AWD SOLENOID GROUND

Check the continuity between AWD control unit harness connector and ground.

AWD control unit		—	Continuity
Connector	Terminal		
B67	10	Ground	Existed
	11		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

## 4.CHECK AWD SOLENOID CIRCUIT (1)

Check the resistance between AWD control unit harness connector.

AWD control unit			Resistance (Approx.)
Connector	Terminal		
B67	1	2	2.45 Ω

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 5.

## 5.CHECK AWD SOLENOID CIRCUIT (2)

1. Remove AWD solenoid harness connector.
2. Check the continuity between AWD control unit harness connector and AWD solenoid harness connector.

AWD control unit		AWD solenoid		Continuity
Connector	Terminal	Connector	Terminal	
B67	1	C12	1	Existed
	2		2	

3. Check the continuity between AWD control unit harness connector and the ground.

AWD control unit		—	Continuity
Connector	Terminal		
B67	1	Ground	Not existed
	2		

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace error-detected parts.

## 6.CHECK AWD SOLENOID

Check AWD solenoid. Refer to [DLN-47. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> AWD solenoid is malfunctioning. Replace electric controlled coupling. Refer to [DLN-115. "Removal and Installation"](#).

# C1204 AWD SOLENOID

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: TY21C]

## 7. CHECK TERMINALS AND HARNESS CONNECTORS

- Check AWD control unit pin terminals for damage or loose connection with harness connector.
- Check AWD solenoid pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> Replace AWD control unit. Refer to [DLN-67, "Removal and Installation"](#).  
NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:000000009694293

## 1. CHECK AWD SOLENOID

1. Turn the ignition switch OFF.
2. Disconnect AWD solenoid harness connector.
3. Check the resistance between AWD solenoid harness connector terminals.

AWD solenoid		Resistance (Approx.)
Terminal		
1	2	2.45 Ω

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> AWD solenoid is malfunctioning. Replace electric controlled coupling. Refer to [DLN-115, "Removal and Installation"](#).

# C1205 AWD ACTUATOR RELAY

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: TY21C]

## C1205 AWD ACTUATOR RELAY

### DTC Logic

INFOID:000000009694294

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1205	4WD ACTUATOR RLY	Malfunction has been detected from AWD actuator relay integrated with AWD control unit, or malfunction related to AWD solenoid has been detected.	<ul style="list-style-type: none"> <li>Internal malfunction of AWD control unit</li> <li>Malfunction of AWD solenoid power supply circuit (ground short)</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION

##### With CONSULT

- Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "C1205" detected?

- YES >> Proceed to [DLN-48, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000009694295

#### 1. CHECK AWD SOLENOID CIRCUIT (1)

- Turn the ignition switch OFF.
- Disconnect AWD control unit harness connector.
- Check the continuity between AWD control unit harness connector and the ground.

AWD control unit		—	Continuity
Connector	Terminal		
B67	1	Ground	Not existed
	2		

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> GO TO 2.

#### 2. CHECK AWD SOLENOID

- Disconnect AWD solenoid harness connector.
- Check the continuity between AWD solenoid connector and the ground.

AWD solenoid		—	Continuity
Terminal			
1		Ground	Not existed
2			

Is the inspection result normal?

- YES >> GO TO 3.



# C1205 AWD ACTUATOR RELAY

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: TY21C]

NO >> AWD solenoid is malfunctioning. Replace electric controlled coupling. Refer to [DLN-115](#).  
["Removal and Installation"](#).

## 3.CHECK AWD SOLENOID CIRCUIT

Check the continuity between AWD control unit harness connector and the ground.

AWD control unit		—	Continuity
Connector	Terminal		
B67	1	Ground	Not existed
	2		

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace damaged parts.

## 4.CHECK TERMINALS AND HARNESS CONNECTORS

1. Check AWD control unit pin terminals for damage or loose connection with harness connector.
2. Check AWD solenoid pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> After connecting each harness connector, perform DTC confirmation procedure again. When DTC "C1205" is detected, replace AWD control unit. Refer to [DLN-67](#). ["Removal and Installation"](#).

NO >> Repair or replace damaged parts.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**C1210 ECM**

**DTC Logic**

INFOID:000000009694296

**DTC DETECTION LOGIC**

DTC	Display item	Malfunction detected condition	Possible cause
C1210	ENGINE SIGNAL 1	Malfunction related to engine signal has been detected.	Malfunction of engine control system

**DTC CONFIRMATION PROCEDURE**

**1. PRECONDITIONING**

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

**2. PERFORM DTC CONFIRMATION**

**Ⓜ With CONSULT**

1. Start the engine and drive at 30 km/h (19 MPH) or more for approximately 1 minute.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "C1210" detected?

- YES >> Proceed to diagnosis procedure. Refer to [DLN-50, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

**Diagnosis Procedure**

INFOID:000000009694297

**1. PERFORM ECM SELF-DIAGNOSIS**

**Ⓜ With CONSULT**

Perform self-diagnosis for "ENGINE".

Is any DTC detected?

- YES >> Check the DTC. Refer to [DLN-22, "DTC Index"](#).
- NO >> GO TO 2.

**2. CHECK TERMINALS AND HARNESS CONNECTORS**

Check AWD control unit pin terminals for damage or loose connection with harness connector.

Is inspection result normal?

- YES >> After turning the ignition switch OFF, perform DTC confirmation procedure again. If DTC "C1210" is detected, Replace AWD control unit. Refer to [DLN-67, "Removal and Installation"](#).
- NO >> Repair or replace error-detected parts.

# P1804 AWD CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: TY21C]

## P1804 AWD CONTROL UNIT

### DTC Logic

INFOID:000000009694298

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P1804	CONTROL UNIT 3	Malfunction is detected in the memory (EEPROM) system of AWD control unit.	Internal malfunction of AWD control module.

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION

##### With CONSULT

- Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P1804" detected?

- YES >> Proceed to [DLN-51, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000009694299

#### 1. PERFORM SELF-DIAGNOSIS AGAIN

##### With CONSULT

Perform "DTC CONFIRMATION PROCEDURE" (self-diagnosis) again. Refer to [DLN-51, "DTC Logic"](#).

Is DTC "P1804" detected?

- YES >> Replace AWD control unit. Refer to [DLN-67, "Removal and Installation"](#).  
NO >> Check AWD control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace error-detected parts.

# P181F INCOMPLETE CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: TY21C]

## P181F INCOMPLETE CALIBRATION

### DTC Logic

INFOID:000000009694300

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
P181F	INCOMP CALIBRATION	When incomplete writing unit characteristics of rear final drive is detected.	Writing unit characteristics is incomplete.

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION

##### With CONSULT

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "P181F" detected?

- YES >> Proceed to [DLN-52, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000009694301

#### 1. PERFORM WRITING UNIT CHARACTERISTICS

1. Erase self-diagnostic result for "ALL MODE AWD/4WD".
2. Perform writing unit characteristics. Refer to [DLN-42, "Work Procedure"](#).
3. Turn the ignition switch OFF to ON.
4. Perform self-diagnosis for "ALL MODE AWD/4WD".

Is any DTC except "P181F" detected?

- YES >> Perform trouble diagnosis for detected DTC. Refer to [DLN-22, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS AGAIN

##### With CONSULT

Perform "DTC CONFIRMATION PROCEDURE" (self-diagnosis) again. Refer to [DLN-22, "DTC Index"](#).

Is DTC "P181F" detected?

- YES >> Replace AWD control unit. Refer to [DLN-67, "Removal and Installation"](#).  
NO >> Check AWD control unit pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace error-detected parts.

# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: TY21C]

## U1000 CAN COMM CIRCUIT

### Description

INFOID:000000009694302

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit communicate data but selectively reads required data only.

### DTC Logic

INFOID:000000009694303

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	AWD control unit is not transmitting/receiving CAN communication signal for 2 seconds or more.	<ul style="list-style-type: none"><li>CAN communication error</li><li>Malfunction of AWD control unit</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION

##### With CONSULT

- Turn the ignition switch OFF to ON.
- Perform self-diagnosis for "ALL MODE AWD/4WD".

Is DTC "U1000" detected?

YES >> Proceed to [DLN-53, "Diagnosis Procedure"](#).

NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000009694304

Proceed to [LAN-26, "Trouble Diagnosis Flow Chart"](#).

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: TY21C]

## U1010 CONTROL UNIT (CAN)

### Description

INFOID:000000009694305

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit communicate data but selectively reads required data only.

### DTC Logic

INFOID:000000009694306

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1010	CONTROL UNIT (CAN)	Detecting error during the initial diagnosis of CAN controller of AWD control unit.	Malfunction of AWD control unit

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION

##### With CONSULT

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ALL MODE AWD/4WD".

##### Is DTC "U1010" detected?

YES >> Proceed to [DLN-54, "Diagnosis Procedure"](#).

NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000009694307

#### 1. CHECK AWD CONTROL UNIT

Check AWD control unit harness connector for disconnection and deformation.

##### Is the inspection result normal?

YES >> Replace AWD control unit. Refer to [DLN-67, "Removal and Installation"](#).

NO >> Repair or replace error-detected parts.

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: TY21C]

## POWER SUPPLY AND GROUND CIRCUIT

### Diagnosis Procedure

INFOID:000000009694308

#### 1. CHECK AWD CONTROL UNIT POWER SUPPLY (1)

1. Turn the ignition switch OFF.
2. Disconnect AWD control unit harness connector.
3. Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage (Approx.)
Connector	Terminal		
B67	7	Ground	0 V

4. Turn the ignition switch ON.  
**CAUTION:**  
**Never start the engine.**
5. Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
B67	7	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2. CHECK AWD CONTROL UNIT POWER SUPPLY (2)

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#49).
3. Disconnect IPDM E/R harness connector.
4. Check the continuity between AWD control unit harness connector and IPDM E/R harness connector.

AWD control unit		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
B67	7	E119	19	Existed

5. Check the continuity between AWD control unit harness connector and the ground.

AWD control unit		—	Continuity
Connector	Terminal		
B67	7	Ground	Not existed

Is the inspection result normal?

- YES >> Perform the trouble diagnosis for ignition power supply circuit. Refer to [PG-23, "Wiring Diagram - IGNITION POWER SUPPLY -"](#).
- NO >> Repair or replace error-detected parts.

#### 3. CHECK AWD CONTROL UNIT POWER SUPPLY (3)

1. Turn the ignition switch OFF.
2. Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
B67	15	Ground	Battery voltage

3. Turn the ignition switch ON.

**CAUTION:**

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: TY21C]

**Never start the engine.**

4. Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
B67	15	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

## 4.CHECK AWD CONTROL UNIT POWER SUPPLY (4)

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#25).
3. Disconnect fuse block (J/B) harness connector.
4. Check the continuity between AWD control unit harness connector and fuse block (J/B) harness connector.

AWD control unit		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
B67	15	M3	2N	Existed

5. Check the continuity between AWD control unit harness connector and the ground.

AWD control unit		—	Continuity
Connector	Terminal		
B67	15	Ground	Not existed

Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit. Refer to [PG-11, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

## 5.CHECK AWD SOLENOID POWER SUPPLY (1)

1. Turn the ignition switch OFF.
2. Disconnect AWD solenoid harness connector.
3. Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
B67	9	Ground	Battery voltage

4. Turn the ignition switch ON.

**CAUTION:**

**Never start the engine.**

5. Check the voltage between AWD control unit harness connector and ground.

AWD control unit		—	Voltage
Connector	Terminal		
B67	9	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

## 6.CHECK AWD SOLENOID POWER SUPPLY (2)

1. Turn the ignition switch OFF.



# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[TRANSFER: TY21C]

2. Check the 10A fuse (#62)
3. Check the harness for open or short between AWD control unit harness connector No.9 terminal and 10A fuse (#62).

Is the inspection result normal?

YES >> Perform the trouble diagnosis for power supply circuit. Refer to [PG-11, "Wiring Diagram - BATTERY POWER SUPPLY -"](#).

NO >> Repair or replace error-detected parts.

## 7. CHECK AWD CONTROL UNIT GROUND

1. Turn the ignition switch OFF.
2. Check the continuity between AWD control unit harness connector and ground.

AWD control unit		—	Continuity
Connector	Terminal		
B67	10	Ground	Existed
	11		

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace error-detected parts.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## AWD WARNING ICON/DISPLAY

### Diagnosis Procedure

INFOID:000000009694309

#### 1. CHECK POWER SUPPLY AND GROUND CIRCUIT

Perform the trouble diagnosis for power supply and ground circuit. Refer to [DLN-55, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the error-detected parts.

#### 2. PERFORM SELF-DIAGNOSIS (AWD CONTROL UNIT)

##### With CONSULT

Perform self-diagnosis for "ALL MODE AWD/4WD".

Is any detected?

YES >> Check the DTC. Refer to [DLN-22, "DTC Index"](#).

NO >> GO TO 3.

#### 3. PERFORM SELF-DIAGNOSIS (COMBINATION METER)

##### With CONSULT

Perform self-diagnosis for "METER/M&A".

Is any detected?

YES >> Check the DTC. Refer to [MWI-26, "DTC Index"](#).

NO >> Perform the trouble diagnosis for combination meter power supply circuit. Refer to [MWI-75, "COMBINATION METER : Diagnosis Procedure"](#).

# AWD ERROR IS DISPLAYED ON INFORMATION DISPLAY

< SYMPTOM DIAGNOSIS >

[TRANSFER: TY21C]

## SYMPTOM DIAGNOSIS

### AWD ERROR IS DISPLAYED ON INFORMATION DISPLAY

#### Description

INFOID:000000009694310

AWD warning icon/display (AWD Error: See Owner's Manual) is displayed on information display after the engine started.

#### Diagnosis Procedure

INFOID:000000009694311

#### 1. PERFORM SELF-DIAGNOSIS

##### With CONSULT

Perform self-diagnosis for "ALL MODE AWD/4WD".

##### Is any DTC detected?

- YES >> Check the DTC. Refer to [DLN-22, "DTC Index"](#).
- NO >> GO TO 2.

#### 2. CHECK AWD WARNING ICON/DISPLAY

Perform the trouble diagnosis of the AWD warning icon/display. Refer to [DLN-58, "Diagnosis Procedure"](#).

##### Is the inspection result normal?

- YES >> Check each harness connector pin terminal for malfunction or disconnection.
- NO >> Repair or replace the error-detected parts.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# HEAVY TIGHT-CORNER BRAKING SYMPTOM OCCURS

< SYMPTOM DIAGNOSIS >

[TRANSFER: TY21C]

## HEAVY TIGHT-CORNER BRAKING SYMPTOM OCCURS

### Description

INFOID:000000009694312

Heavy tight-corner braking symptom occurs when the vehicle is driven and the steering wheel is turned fully to either side after the engine is started.

#### NOTE:

Light tight-corner braking symptom may occur depending on driving conditions. This is not malfunction.

### Diagnosis Procedure

INFOID:000000009694313

#### 1. PERFORM ECM SELF-DIAGNOSIS

##### With CONSULT

Perform self-diagnosis for "ENGINE".

##### Is any DTC detected?

YES >> Check the DTC. Refer to [EC-97, "DTC Index"](#).

NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

##### With CONSULT

Perform self-diagnosis for "ALL MODE AWD/4WD".

##### Is DTC "U1000" detected?

YES >> Proceed to [LAN-26, "Trouble Diagnosis Flow Chart"](#).

NO >> GO TO 3.

#### 3. CHECK AWD SOLENOID

Perform the trouble diagnosis of the AWD solenoid. Refer to [DLN-45, "Diagnosis Procedure"](#).

##### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the error-detected parts.

#### 4. CHECK ELECTRIC CONTROLLED COUPLING

1. Turn the ignition switch OFF.
2. Set the transaxle to neutral. Release the parking brake.
3. Lift up the vehicle.
4. Rotate the propeller shaft by hand.
5. Hold rear wheel of right and left lightly.

##### Does rear wheel rotate?

YES >> Replace electric controlled coupling for mechanical malfunction (clutch sticking etc.). Refer to [DLN-115, "Removal and Installation"](#).

NO >> Check each harness connector pin terminal for disconnection.

# VEHICLE DOES NOT ENTER AWD MODE

< SYMPTOM DIAGNOSIS >

[TRANSFER: TY21C]

## VEHICLE DOES NOT ENTER AWD MODE

### Description

INFOID:000000009694314

Vehicle does not enter 4-wheel drive mode even though AWD warning icon/display is not displayed.

### Diagnosis Procedure

INFOID:000000009694315

#### 1. CHECK AWD WARNING ICON/DISPLAY

Perform the trouble diagnosis of the AWD warning icon/display. Refer to [DLN-58, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the error-detected parts.

#### 2. CHECK PARKING BRAKE SWITCH SIGNAL

##### With CONSULT

Check "P BRAKE SW" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".

Monitor Item	Condition	Status
P BRAKE SW	When the parking brake pedal is operation.	On
	When the parking brake pedal is not operation.	Off

Is the inspection result normal?

YES >> GO TO 3.

NO >> Proceed to [BRC-110, "Diagnosis Procedure"](#).

#### 3. CRUISE TEST

Drive the vehicle for a period of time.

Does any symptom occur?

YES >> Replace electric controlled coupling for mechanical malfunction (mechanical engagement of clutch is not possible). Refer to [DLN-115, "Removal and Installation"](#).

NO >> Check each harness connector pin terminal for disconnection.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## AWD HIGH TEMP IS DISPLAYED ON INFORMATION DISPLAY

< SYMPTOM DIAGNOSIS >

[TRANSFER: TY21C]

---

## AWD HIGH TEMP IS DISPLAYED ON INFORMATION DISPLAY

### Description

INFOID:000000009694316

While driving, AWD warning icon/display (AWD High Temp. Stop vehicle) is displayed on information display and it turns OFF after 1 minute.

- This symptom protects drivetrain parts when a heavy load is applied to the electric controlled coupling and multiple disc clutch temperature increases. Also, optional distribution of torque sometimes becomes rigid before icon/display is displayed. Both cases are not malfunction. Refer to [DLN-21. "Protection Function"](#).
- When this symptom occurs, stop vehicle and allow it to idle for some times. Displays will stop and system will be restored.

# TIRE SIZE INCORRECT IS DISPLAYED ON INFORMATION DISPLAY

< SYMPTOM DIAGNOSIS >

[TRANSFER: TY21C]

## TIRE SIZE INCORRECT IS DISPLAYED ON INFORMATION DISPLAY

### Description

INFOID:000000009694317

While driving, AWD warning icon/display (Tire Size Incorrect: See Owner's Manual) is displayed on information display.

### Diagnosis Procedure

INFOID:000000009694318

#### 1. CHECK TIRE

Check the following.

- Tire pressure
- Wear condition
- Front and rear tire size (There is no difference between front and rear tires.)

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts. And then, drive the vehicle at speed of 20 km/h (12 MPH) or more for 5 seconds or more. Improper size information is initialized accordingly.

#### 2. CHECK INPUT SIGNAL OF TIRE DIAMETER

##### With CONSULT

1. Start the engine.
2. Drive at 20 km/h (12 MPH) or more for approximately 4 minutes continually.
3. Check "DIS-TIRE MONI" of CONSULT "DATA MONITOR" for "ALL MODE AWD/4WD".

Does the item on "DATA MONITOR" indicate "0 - 4 mm"?

YES >> INSPECTION END

NO >> GO TO 3.

#### 3. TERMINAL INSPECTION

Check AWD control unit harness connector for disconnection.

Is the inspection result normal?

YES >> Replace AWD control unit. Refer to [DLN-67, "Removal and Installation"](#).

NO >> Repair or replace the error-detected parts.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[TRANSFER: TY21C]

## NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

### NVH Troubleshooting Chart

INFOID:000000009694319

Use the chart below to find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.

Reference		<a href="#">DLN-65, "Inspection"</a>			—	<a href="#">DLN-71, "Exploded View"</a>		<a href="#">DLN-71, "Exploded View"</a>		<a href="#">DLN-78, "Inspection", DLN-87, "Inspection"</a>		<a href="#">DLN-78, "Inspection", DLN-87, "Inspection"</a>	
SUSPECTED PARTS (Possible cause)		TRANSFER OIL (Level low)	TRANSFER OIL (Wrong)	TRANSFER OIL (Level too high)	LIQUID GASKET (Damaged)	O-RING (Worn or damaged)	OIL SEAL (Worn or damaged)	GEAR (Worn or damaged)	BEARING (Worn or damaged)				
Symptom	Noise	1	2				3	3	3				
	Transfer oil leakage		3	1	2	2	2						



## PERIODIC MAINTENANCE

### TRANSFER OIL

#### Inspection

INFOID:000000009694320

#### TRANSFER OIL LEAKS

Check that transfer oil is not leaking from transfer assembly or around it.

#### TRANSFER OIL LEVEL

**CAUTION:**

**Do not start engine while checking transfer oil level.**

1. Remove filler plug (1) and gasket.


↩ : Front

2. Transfer oil level (A) should be level with bottom of filler plug hole. Add transfer oil if necessary. Refer to [MA-15. "FOR USA AND CANADA : Fluids and Lubricants"](#) (USA and CANADA) or [MA-16. "FOR MEXICO : Fluids and Lubricants"](#) (MEXICO).

3. Set a new gasket onto filler plug, and install it in the transfer and tighten to specified torque. Refer to [DLN-88. "Exploded View"](#).

**CAUTION:**

**Do not reuse gasket.**



ALDIA0383ZZ

#### Draining

INFOID:000000009694321

**CAUTION:**

**Do not start engine while working.**


1. Run the vehicle to warm up the transfer unit sufficiently.
2. Stop the engine and remove drain plug (1) and gasket and drain the transfer oil.

↩ : Front

3. Set a new gasket onto filler plug, and install it in the transfer and tighten to specified torque. Refer to [DLN-88. "Exploded View"](#).

**CAUTION:**

**Do not reuse gasket.**



ALDIA0382ZZ

#### Refilling


INFOID:000000009694322

**CAUTION:**

**Do not start engine while checking transfer oil level.**

1. Remove filler plug (1).
2. Fill with new transfer oil to the specified level near the filler plug hole.

↩ : Front



ALDIA0383ZZ

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## TRANSFER OIL

< PERIODIC MAINTENANCE >

[TRANSFER: TY21C]

Transfer oil grade and viscosity : Refer to [MA-15, "FOR USA AND CANADA : Fluids and Lubricants"](#) (USA and CANADA) or [MA-16, "FOR MEXICO : Fluids and Lubricants"](#) (MEXICO).

Transfer oil capacity : Refer to [DLN-92, "General Specifications"](#).

3. Set a new gasket onto filler plug, and install it in the transfer and tighten to specified torque. Refer to [DLN-88, "Exploded View"](#).

**CAUTION:**

**Do not reuse gasket.**

# AWD CONTROL UNIT

< REMOVAL AND INSTALLATION >

[TRANSFER: TY21C]

## REMOVAL AND INSTALLATION

### AWD CONTROL UNIT

#### Removal and Installation


INFOID:000000009694323

#### REMOVAL

1. Disconnect the negative battery terminal. Refer to [PG-93. "Exploded View"](#).
2. Remove storage box. Refer to [INT-33. "STORAGE BOX : Removal and Installation"](#).

↩ : Front

3. Remove AWD control unit bolts (↔).
4. Disconnect AWD control unit harness connector.
5. Remove AWD control unit (1).



#### INSTALLATION

- Installation is in the reverse order of removal.
- Tighten AWD control unit bolts to specified torque.

**AWD control unit bolts : 10.1 N·m (1.0 kg-m, 7 ft-lb)**

#### **CAUTION:**

**Do not drop or shock AWD control unit.**

A

B

C

DLN

E

F

G

H

I

J

K

L

M

N

O

P

## TRANSFER COVER

< REMOVAL AND INSTALLATION >

[TRANSFER: TY21C]

---

### TRANSFER COVER

#### Removal and Installation

INFOID:000000009694324

**NOTE:**

- Replacement on vehicle may cause damage to transfer cover, and may cause a transfer oil leak.
- If transfer cover oil seal requires replacement, remove the transfer assembly from the vehicle before replacing transfer cover oil seal. Refer to [DLN-89, "Disassembly"](#).

# TRANSFER ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >


[TRANSFER: TY21C]

## UNIT REMOVAL AND INSTALLATION

### TRANSFER ASSEMBLY

Exploded View

INFOID:000000009694325



1. Transfer assembly

2. Transfer gusset

3. Rear gusset

⇐: Vehicle front

⊗: N·m (kg·m, ft·lb)

### Removal and Installation

INFOID:000000009694326

#### NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

#### REMOVAL

1. Drain the transfer oil. Refer to [DLN-65, "Draining"](#).
2. Remove exhaust manifold (RH). Refer to [EM-33, "Removal and Installation \(RH\)"](#).  
**CAUTION:**  
**Handle carefully to avoid any shock to three way catalyst.**
3. Support transaxle with a suitable jack.
4. Remove the steering gear. Refer to [ST-50, "Removal and Installation - FWD"](#) (FWD) or [ST-51, "Removal and Installation - AWD"](#) (AWD).
5. Remove rear gusset and transfer gusset.
6. Remove transaxle assembly to transfer assembly bolts.

#### CAUTION:


**Be careful not to damage gear ring oil seal inside of CVT.**

Bolt No.	(A)	(B)
Quantity	4	2
Bolt length "ℓ" mm (in)	40 (1.57)	40 (1.57)

7. Remove transfer assembly from the vehicle.

#### CAUTION:

- Do not damage air breather hose.



# TRANSFER ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[TRANSFER: TY21C]

- After removing transfer from transaxle, always replace differential side oil seal of the transaxle side with new one. Refer to [TM-203, "Removal and Installation"](#).

## INSTALLATION


Installation is in the reverse order of removal.

- When installing the transfer to the transaxle, install the bolts following the standard below.

Bolt No.	(A)	(B)
Quantity	4	2
Bolt length "ℓ" mm (in)	40 (1.57)	40 (1.57)

### CAUTION:

- When installing transfer to transaxle, be careful not to damage oil seal of transaxle.
- Do not reuse differential side oil seal.
- Check transfer oil level and check for transfer oil leaks after installation. Refer to [DLN-65, "Refilling"](#).



# TRANSFER COVER

< UNIT DISASSEMBLY AND ASSEMBLY >


[TRANSFER: TY21C]

## UNIT DISASSEMBLY AND ASSEMBLY

### TRANSFER COVER

Exploded View

INFOID:000000009694327



SEC.331-332

JSDIA4191GB


A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# TRANSFER COVER


< UNIT DISASSEMBLY AND ASSEMBLY >


[TRANSFER: TY21C]


- |   |  |  |
|---|--|--|
| 1. Oil seal   | 2. Transfer cover  | 3. Filler plug                             |
| 4. Gasket   | 5. Drain plug  | 6. Oil seal                                |
| 7. O-ring   | 8. Ring gear bearing adjusting shim (transfer cover side)  | 9. Ring gear bearing (transfer cover side) |
| 10. Drive shaft oil seal                                  | 11. Ring gear shaft  | 12. Ring gear bearing (transfer case side) |
| 13. Ring gear bearing adjusting shim (transfer case side) | 14. Ring gear  | 15. Baffle plate                           |
| 16. Transfer case   | 17. Plug   | 18. O-ring                                 |
| 19. Oil seal  | 20. Dowel pin  | 21. Drive pinion                           |
| 22. Drive pinion adjusting shim                           | 23. O-ring   | 24. Pinion bearing assembly                |
| 25. Oil seal  | 26. Dust cover   | 27. Companion flange                       |
| 28. Pinion lock nut                                       |  |  |
| A. Oil seal lip   | B. Comply with the assembly procedure when tightening. Refer to <a href="#">DLN-82. "Assembly"</a> . |  |


: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

: Always replace after every disassembly.

: Apply gear oil.

: Apply anti-corrosive oil.


: Apply multi-purpose grease.

★: Select with proper thickness.


## Disassembly

INFOID:000000009694328

1. Remove transfer cover mounting bolts (←).



2. Lightly tap transfer cover (1) with a plastic hammer to remove transfer cover.
3. Remove O-ring from transfer cover.
  - CAUTION:**
  - Never use a tool.
  - Never damage transfer cover.





# TRANSFER COVER


< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]


4. Lightly tap the metal part of oil seals (1) with punch from back side of transfer cover to remove oil seals.

**CAUTION:**

**When removing, never damage the transfer cover by scooping it out with a tool.**



5. Remove the ring gear bearing adjusting shim (transfer cover side) (1) and ring gear bearing outer race (transfer cover side) (2) using drift (commercial service tool).
6. Remove drain plug and gasket.
7. Remove filler plug and gasket.
8. Perform inspection after disassembly. Refer to [DLN-74, "Inspection"](#).



## Assembly

INFOID:000000009694329

1. Select the ring gear bearing adjusting shim (transfer cover side). Refer to [DLN-83, "Adjustment"](#).
2. Install the selected ring gear bearing adjusting shim (transfer cover side) (1) and ring gear bearing outer race (transfer cover side) (2) using drift (commercial service tool).


**CAUTION:**

- Never reuse ring gear bearing.
- Apply gear oil to the ring gear bearing.

3. Install gasket onto drain plug and install them to transfer cover.

**CAUTION:**

**Never reuse gasket.**



4. Install the transfer cover to the transfer case, and apply anti-corrosive oil onto thread and seats on the mounting bolts. Then tighten mounting bolts to the specified torque.

- A : M10 bolt
- B : M8 bolt

**NOTE:**

At this timing, O-ring installing to transfer cover is not necessary. Install O-ring after tooth contact is checked.

5. Check backlash, tooth contact, total preload and companion flange runout. Refer to [DLN-83, "Adjustment"](#).


**CAUTION:**

**Measure the total preload without oil seals of transfer cover and transfer case.**

6. Remove transfer cover to install O-ring.
7. Apply multi-purpose grease lightly and evenly onto an O-ring, and install it to the transfer cover.

**CAUTION:**

- Never reuse O-ring.
- When installing O-ring, never use a tool.
- Never damage O-ring.




# TRANSFER COVER

## < UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

8. Install the transfer cover to the transfer case, and apply anti-corrosive oil onto thread and seats on the mounting bolts. Then tighten mounting bolts to the specified torque.

- A : M10 bolt  
B : M8 bolt




9. Using drift (commercial service tool), drive the transfer cover oil seals.

- A : 10.3 +0.6/-0 mm (0.406 +0.024/-0 in)  
B : 0 +0.6/-0 mm (0 +0.024/-0 in)

**CAUTION:**

- When checking the total preload torque, measure it without the oil seal, then install the oil seal.
- Never reuse the oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of the oil seal.



10. Install gasket onto filler plug and install them to transfer cover.

**CAUTION:**

- Never reuse gasket.
- Install filler plug after oil is filled.

## Inspection

INFOID:000000009694330

### INSPECTION AFTER DISASSEMBLY

Check items below. If necessary, replace them with new ones.

Transfer cover

Check the bearing mounting surface for wear, cracks and damages.

# RING GEAR SHAFT


< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

## RING GEAR SHAFT

Exploded View

INFOID:000000009694331



- |             |                   |                |
|-------------|-------------------|----------------|
| 1. Oil seal | 2. Transfer cover | 3. Filler plug |
| 4. Gasket   | 5. Drain plug     | 6. Oil seal    |

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# RING GEAR SHAFT

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

- |   |  |  |
|---|--|--|
| 7. O-ring   | 8. Ring gear bearing adjusting shim (transfer cover side)  | 9. Ring gear bearing (transfer cover side) |
| 10. Drive shaft oil seal                                  | 11. Ring gear shaft  | 12. Ring gear bearing (transfer case side) |
| 13. Ring gear bearing adjusting shim (transfer case side) | 14. Ring gear  | 15. Baffle plate                           |
| 16. Transfer case   | 17. Plug   | 18. O-ring                                 |
| 19. Oil seal  | 20. Dowel pin  | 21. Drive pinion                           |
| 22. Drive pinion adjusting shim                           | 23. O-ring   | 24. Pinion bearing assembly                |
| 25. Oil seal  | 26. Dust cover   | 27. Companion flange                       |
| 28. Pinion lock nut                                       |  |  |
| A. Oil seal lip   | B. Comply with the assembly procedure when tightening. Refer to <a href="#">DLN-82, "Assembly"</a> . |  |



N·m (kg-m, ft-lb)



N·m (kg-m, in-lb)



Always replace after every disassembly.



Apply gear oil.



Apply anti-corrosive oil.




Apply multi-purpose grease.

★: Select with proper thickness.


## Disassembly

INFOID:000000009694332

1. Remove transfer cover assembly. Refer to [DLN-72, "Disassembly"](#).
2. Remove ring gear bearing outer race (transfer cover side) and ring gear bearing adjusting shim (transfer cover side) from the transfer cover. Refer to [DLN-72, "Disassembly"](#).
3. Remove ring gear shaft assembly from the transfer case.
4. Remove ring gear bearing outer race (transfer case side) and ring gear bearing adjusting shim (transfer case side) from the transfer case. Refer to [DLN-89, "Disassembly"](#).
5. Remove ring gear bearing inner race (transfer cover side) from ring gear shaft with drift (A) (commercial service tool) and replacer (commercial service tool).



6. Remove ring gear bearing inner race (transfer case side) from ring gear shaft with the drift (A) [SST: ST33061000 (J-8107-2)] and puller (commercial service tool).
7. Remove the ring gear mounting bolts.




# RING GEAR SHAFT


< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

8. Lightly tap ring gear with a plastic hammer to remove ring gear from the ring gear shaft.



9. Remove drive shaft oil seal from the ring gear shaft with the puller (A) [SST: KV381054S0 (J-34286)].
10. Perform inspection after disassembly. Refer to [DLN-78. "Inspection"](#).



INFOID:000000009694333

## Assembly


1. Using drift (A) (commercial service tool), install drive shaft oil seal (1) within the dimension (L) shown as follows.

**L** : 2.0 +0.6/-0 mm (0.079 +0.024/-0 in)

### CAUTION:

- Never reuse the oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of the oil seal.

2. Select ring gear bearing adjusting shim (transfer case side) and ring gear bearing adjusting shim (transfer cover side). Refer to [DLN-83. "Adjustment"](#).



3. Assemble the selected ring gear bearing adjusting shim (transfer case side) and ring gear bearing outer race (transfer case side) to transfer case. Refer to [DLN-90. "Assembly"](#).

### CAUTION:

- Never reuse ring gear bearing.
- Apply gear oil to the ring gear bearing.

4. Assemble the selected ring gear bearing adjusting shim (transfer cover side) and ring gear bearing outer race (transfer cover side) to transfer cover. Refer to [DLN-73. "Assembly"](#).

### CAUTION:

- Never reuse ring gear bearing.
- Apply gear oil to the ring gear bearing.

5. Install the ring gear to ring gear shaft, and tighten mounting bolts to the specified torque.

# RING GEAR SHAFT


< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

6. Install ring gear bearing inner race (transfer cover side) with drift (A) (commercial service tool).

**CAUTION:**

- Never reuse ring gear bearing.
- Apply gear oil to the ring gear bearing.



7. Install the ring gear bearing inner race (transfer case side) to ring gear shaft with drift (A) (commercial service tool).


**CAUTION:**

- Never reuse ring gear bearing.
- Apply gear oil to the ring gear bearing.


8. Install the ring gear shaft assembly to the transfer case.

**CAUTION:**

Protect transfer case oil seals beforehand from being damaged by the spline of ring gear shaft below method following.



- a. Apply multi-purpose grease to spline part indicated in the figure.



- b. Wrap piece of vinyl to spline part only indicated in the figure. [(A): limit line]

**CAUTION:**

Never wrap sliding surfaces on oil seal.

9. Install transfer cover to check and adjust each part. Refer to [DLN-73, "Assembly"](#).

**NOTE:**

At this timing, O-ring installing to transfer cover is not necessary. Install O-ring after backlash and tooth contact are checked.


10. Check backlash, tooth contact, total preload and companion flange runout. Refer to [DLN-83, "Adjustment"](#).

**CAUTION:**

Measure the total preload without oil seals of transfer cover and transfer case.

11. Reinstall transfer cover for installing O-ring. Refer to [DLN-73, "Assembly"](#).

12. After installing transfer case oil seals, remove wrapped vinyl from the spline of ring gear shaft.



## Inspection

INFOID:000000009694334

### INSPECTION AFTER DISASSEMBLY

Check items below. If necessary, replace them with new ones.

#### Gear and Shaft

Check gear face and shaft for wear, cracks, damage, and seizure.

# RING GEAR SHAFT

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

**CAUTION:**

If malfunction is detected on the ring gear or drive pinion, replace the ring gear and drive pinion as a set.

A

Bearing

Check for seizure, peeling, wear, corrosion, sticking, unusual noise, roughness in hand turning, and other damage.

B

**CAUTION:**

When replacing the bearing, always replace the inner race and outer race as a pair.

C

Shim

Check for seizure, damage, and unusual wear.

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# DRIVE PINION


< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

## DRIVE PINION

Exploded View

INFOID:000000009694335



- |             |                   |                |
|-------------|-------------------|----------------|
| 1. Oil seal | 2. Transfer cover | 3. Filler plug |
| 4. Gasket   | 5. Drain plug     | 6. Oil seal    |



# DRIVE PINION

## < UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

- |   |  |  |   |
|---|--|--|---|
| 7. O-ring   | 8. Ring gear bearing adjusting shim (transfer cover side)  | 9. Ring gear bearing (transfer cover side) | A |
| 10. Drive shaft oil seal                                  | 11. Ring gear shaft  | 12. Ring gear bearing (transfer case side) | B |
| 13. Ring gear bearing adjusting shim (transfer case side) | 14. Ring gear  | 15. Baffle plate                           | B |
| 16. Transfer case   | 17. Plug   | 18. O-ring                                 | C |
| 19. Oil seal  | 20. Dowel pin  | 21. Drive pinion                           | C |
| 22. Drive pinion adjusting shim                           | 23. O-ring   | 24. Pinion bearing assembly                |   |
| 25. Oil seal  | 26. Dust cover   | 27. Companion flange                       |   |
| 28. Pinion lock nut                                       |  |  |   |
| A. Oil seal lip   | B. Comply with the assembly procedure when tightening. Refer to <a href="#">DLN-82. "Assembly"</a> . |  |   |

DLN



N·m (kg-m, ft-lb)



N·m (kg-m, in-lb)



Always replace after every disassembly.



Apply gear oil.



Apply anti-corrosive oil.



Apply multi-purpose grease.



Select with proper thickness.

E

F


G

H

## Disassembly

INFOID:000000009694336

1. Remove pinion bearing assembly mounting bolts.




I

J

K

L

2. Lightly tap companion flange with a plastic hammer to remove drive pinion assembly (1).
3. Remove the O-ring from pinion bearing.
4. Remove the pinion lock nut.



M

N

O


P

# DRIVE PINION

## < UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

5. Remove drive pinion from pinion bearing assembly with drift (A) (commercial service tool) and replacer (B) (commercial service tool).
6. Remove adjusting shim.
7. Remove companion flange.
8. Remove the dust cover.
9. Remove the oil seal.
10. Perform inspection after disassembly. Refer to [DLN-87, "Inspection"](#).



INFOID:000000009694337

## Assembly

1. Select drive pinion adjusting shim. Refer to [DLN-83, "Adjustment"](#).
2. Assemble the selected drive pinion adjusting shim to drive pinion.
3. Install the drive pinion to pinion bearing assembly with drift (commercial service tool).

### CAUTION:

- Never reuse pinion bearing assembly.
- Apply gear oil to pinion bearing part.

4. Install oil seal to pinion bearing assembly with drift (A) (commercial service tool).


### CAUTION:

- Never reuse the oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of the oil seal.

5. Install dust cover.

### NOTE:

Tighten dust cover together with pinion bearing assembly.



6. Install companion flange (1) to pinion bearing with drift (A) (commercial service tool).
7. Apply anti-corrosive oil to the thread and seat of the lock nut, and adjust the pinion lock nut tightening torque and pinion bearing preload torque, using a preload gauge.
- a. Install pinion lock nut, and then tighten to the specified torque.

**Pinion lock nut tightening torque** :  $90 \pm 9$  N·m ( $9.2 \pm 0.92$  kg·m,  $66 \pm 7$  ft·lb)

### CAUTION:

- Never reuse pinion lock nut.
- Check that pinion lock nut is seated on the companion flange.


- b. After tightening pinion lock nut to the specified torque, retighten the pinion lock nut by 25 degrees.
- c. Measure the pinion bearing preload.

**Pinion bearing preload** : Refer to [DLN-92, "Preload Torque"](#).

8. Apply multi-purpose grease lightly and evenly onto an O-ring, and install it to the pinion bearing assembly.

### CAUTION:

- Never reuse O-ring.
- When installing O-ring, never use a tool.
- Never damage O-ring.



# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

- Install drive pinion assembly, and apply anti-corrosive oil onto thread and seats on the mounting bolts. Tighten to the specified torque.


**NOTE:**

Tighten dust cover together with pinion bearing assembly.

- Check backlash, tooth contact, total preload and companion flange runout. Refer to [DLN-83. "Adjustment"](#).

**CAUTION:**

Measure the total preload without oil seals of transfer cover and transfer case.



JSDIA3951ZZ

## Adjustment


INFOID:000000009694338

A  
B  
C

DLN

## ADJUSTING SHIM SELECTION

Measurement point



JSDIA4034ZZ

E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

Select adjusting shim of T1, T2, and T3, respectively, by using the following equation.

T1 [Ring gear bearing adjusting shim (transfer case side)]

$$\bullet T1 = A - (B + X/2) + C + W - V - F - (M/100) + 0.071 \text{ mm (0.0028 in)}$$

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

T2 [Ring gear bearing adjusting shim (transfer cover side)]


- $T2 = -Y + Z + (B + X/2) - C - D - H + (M/100) + 0.071$  mm (0.0028 in)

T3 (Drive pinion adjusting shim)

- $T3 = -Q + (R + S/2) - K + (O/100)$
- Check dimension (M) on the ring gear side face.

## NOTE:


Dimension "M" indicates the difference between the optimum engagement and standard dimensions in increments of 0.01 mm (0.0004 in) written on the ring gear side face.



- Check dimension (O) on the gear end of drive pinion.

## NOTE:

Dimension "O" indicates the difference between the optimum engagement and the standard dimensions in increments of 0.01 mm (0.0004 in) written on the gear end of drive pinion.



## PINION BEARING PRELOAD

### CAUTION:

When measuring preload, the rotating speed must be set to 30 rpm.


1. Remove ring gear shaft assembly from the transfer case. Refer to [DLN-76, "Disassembly"](#).
2. Rotate the companion flange back and forth from 2 to 3 times to check for unusual noise, binding, sticking, and so on.
3. Rotate the companion flange at least 20 times to check for smooth operation of the bearing.
4. Measure the pinion bearing preload with the preload gauge (A) [SST: ST3127S000 (J-25765-A)].

Pinion bearing preload : Refer to [DLN-92, "Preload Torque"](#).

### CAUTION:

Each rotational part should rotate smoothly with the specified gear oil.

- If outside the standard, disassemble the drive pinion assembly to check and adjust each part.



## TOTAL PRELOAD

### CAUTION:

When measuring preload, the rotating speed must be set to 30 rpm.

1. Measure pinion bearing preload.

### CAUTION:

Check that the pinion bearing preload is within the standard.

2. Assemble the ring gear shaft assembly to the transfer case. Refer to [DLN-77, "Assembly"](#)
3. Install transfer cover to check and adjust each part. Refer to [DLN-73, "Assembly"](#).
4. Rotate the companion flange at least 20 times to check for smooth operation of the bearing.

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]


5. Measure the total preload with the preload gauge (A) [SST: ST3127S000 (J-25765-A)].

**Total preload** : Refer to [DLN-92, "Preload Torque"](#).

**CAUTION:**

Each rotational part should rotate smoothly with the specified gear oil.

- If outside the standard, disassemble the transfer assembly to check and adjust each part. Measure it with the transfer case oil seal and transfer cover oil seal removed when measuring total preload after disassembly. Then install transfer case oil seals and transfer cover oil seal.



A  
B  
C


DLN

## BACKLASH

1. Install the bolt to the companion flange.
2. Fit a dial indicator onto the bolt (A).
3. Measure the circumference backlash of the companion flange.

**Backlash** : Refer to [DLN-92, "Backlash"](#).

- If outside the standard, disassemble the transfer assembly to check and adjust each part.



E  
F  
G  
H

## TOOTH CONTACT

1. Remove transfer cover. Refer to [DLN-72, "Disassembly"](#).
2. Remove ring gear shaft assembly from transfer case. Refer to [DLN-76, "Disassembly"](#).
3. Apply red lead onto the ring gear.

**CAUTION:**


Apply red lead to both faces of 3 to 4 gears at 4 locations evenly spaced on the ring gear.

4. Assemble the ring gear shaft assembly to the transfer case. Refer to [DLN-77, "Assembly"](#).
5. Install transfer cover to check and adjust each part. Refer to [DLN-73, "Assembly"](#).

**NOTE:**

At this timing, O-ring installing to transfer cover is not necessary. Install O-ring after backlash and tooth contact are checked.

6. Remove the plug from the transfer case.
7. Rotate the companion flange back and forth several times, and check the drive pinion gear to ring gear tooth contact by viewing from the plug hole.



I  
J  
K  
L  
M  
N  
O  
P

# DRIVE PINION

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

## Tooth Contact Judgment Guide


Drive pinion adjusting shim selection value mm(in)		Tooth contact condition				Need for adjustment
		Drive side		Back side		
↑ Thinner	-0.09 (-0.0035)	Heel side 	Toe side 	Toe side 	Heel side 	YES
	-0.06 (-0.0024)					
	-0.03 (-0.0012)					NO
	0					
↓ Thicker	+0.03 (+0.0012)					YES
	+0.06 (+0.0024)					
	+0.09 (+0.0035)					

JSDIA4035GB

8. Follow the procedure below to adjust pinion height (dimension X) if tooth contact is improper. For selecting adjusting shim, refer to the latest parts information.

**CAUTION:**

If no adjusting shim with the calculated value is available, select the thicker and closest one.




JSDIA1221ZZ

- Thicken the drive pinion adjusting shim to move the drive pinion closer to the ring gear in case of face contact or heel contact.

**CAUTION:**

Only one adjusting shim can be selected.



PDIA0440E

# DRIVE PINION


< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

- Thin the drive pinion adjusting shim to move the drive pinion farther from the ring gear in case of flank contact or toe contact.

**CAUTION:**

**Only one adjusting shim can be selected.**



## COMPANION FLANGE RUNOUT


- Fit a dial indicator onto the companion flange face (inner side of the propeller shaft mounting bolt holes).
- Rotate the companion flange to check for runout.

**Companion flange runout** : Refer to [DLN-92, "Companion Flange Runout"](#).

- Fit a test indicator to the inner side of the companion flange (socket diameter).
- Rotate the companion flange to check for runout.

**Companion flange runout** : Refer to [DLN-92, "Companion Flange Runout"](#).

- Follow the procedure below to adjust if runout value is outside the repair limit.
  - Check for runout while changing the phase between companion flange and drive pinion in 90° steps. Then search for the minimum point.
  - Replace companion flange if runout value is still outside the limit after the phase has been changed.
  - Adjust assembly status of the pinion bearing and drive pinion, or replace pinion bearing assembly if runout is outside the standard after the companion flange is replaced.



## Inspection

INFOID:000000009694339

### INSPECTION AFTER DISASSEMBLY

Check items below. If necessary, replace them with new ones.

#### Gear and Shaft

Check gear face and shaft for wear, cracks, damage, and seizure.

**CAUTION:**

**Replace ring gear and drive pinion as a set (hypoid gear set) if any malfunction is detected on the ring gear or drive pinion.**

#### Bearing

Check for seizure, peeling, wear, corrosion, sticking, unusual noise, roughness in hand turning, and other damage.

#### Shim

Check for seizure, damage, and unusual wear.

# TRANSFER CASE


< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

## TRANSFER CASE

Exploded View

INFOID:000000009694340



SEC.331-332

JSDIA4191GB

- |             |                   |                |
|-------------|-------------------|----------------|
| 1. Oil seal | 2. Transfer cover | 3. Filler plug |
| 4. Gasket   | 5. Drain plug     | 6. Oil seal    |



# TRANSFER CASE

## < UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

- |   |  |  |     |
|---|--|--|-----|
| 7. O-ring   | 8. Ring gear bearing adjusting shim (transfer cover side)  | 9. Ring gear bearing (transfer cover side) | A   |
| 10. Drive shaft oil seal                                  | 11. Ring gear shaft  | 12. Ring gear bearing (transfer case side) |     |
| 13. Ring gear bearing adjusting shim (transfer case side) | 14. Ring gear  | 15. Baffle plate                           | B   |
| 16. Transfer case   | 17. Plug   | 18. O-ring                                 |     |
| 19. Oil seal  | 20. Dowel pin  | 21. Drive pinion                           | C   |
| 22. Drive pinion adjusting shim                           | 23. O-ring   | 24. Pinion bearing assembly                |     |
| 25. Oil seal  | 26. Dust cover   | 27. Companion flange                       |     |
| 28. Pinion lock nut                                       |  |  |     |
| A. Oil seal lip   | B. Comply with the assembly procedure when tightening. Refer to <a href="#">DLN-82</a> , "Assembly". |  | DLN |



N·m (kg-m, ft-lb)



N·m (kg-m, in-lb)



Always replace after every disassembly.



Apply gear oil.



Apply anti-corrosive oil.



Apply multi-purpose grease.

★: Select with proper thickness.

## Disassembly

INFOID:000000009694341


- Remove transfer cover. Refer to [DLN-72](#), "Disassembly".
- Remove ring gear shaft assembly. Refer to [DLN-76](#), "Disassembly".
- Remove drive pinion assembly. Refer to [DLN-81](#), "Disassembly".
- Remove O-ring from transfer case.
 

**CAUTION:**


  - Never use a tool.
  - Never damage transfer case.
- Remove oil seals (1).
 

**CAUTION:**

Never damage transfer case.



- Remove baffle plate (1).



# TRANSFER CASE

< UNIT DISASSEMBLY AND ASSEMBLY >


[TRANSFER: TY21C]

- Remove the ring gear bearing adjusting shim (transfer case side) (1) and ring gear bearing outer race (transfer case side) (2) by tapping from the 2 cutouts (◀) on the transfer case.

**CAUTION:**

**Never damage transfer case.**

- Remove plug and gasket.
- Perform inspection after disassembly. Refer to [DLN-91, "Inspection"](#).




INFOID:000000009694342

## Assembly

- Select the ring gear bearing adjusting shim (transfer case side). Refer to [DLN-83, "Adjustment"](#).
- Install the selected ring gear bearing adjusting shim (transfer case side) and ring gear bearing outer race (transfer case side) using drift (A) (commercial service tool).

**CAUTION:**

- Never reuse ring gear bearing.
- Apply gear oil to the ring gear bearing.



- Install baffle plate (1).
- Install ring gear shaft assembly. Refer to [DLN-77, "Assembly"](#).

**CAUTION:**

**Protect transfer case oil seals beforehand from being damaged by the spline of ring gear shaft.**

- Install drive pinion assembly. Refer to [DLN-82, "Assembly"](#).
- Install transfer cover to check and adjust each part. Refer to [DLN-73, "Assembly"](#).

**NOTE:**

At this timing, O-ring installing to transfer cover is not necessary. Install O-ring after backlash and tooth contact are checked.

- Check backlash, tooth contact, total preload and companion flange runout. Refer to [DLN-83, "Adjustment"](#).

**CAUTION:**

**Measure the total preload without oil seals of transfer cover and transfer case.**



- Reinstall transfer cover for installing O-ring. Refer to [DLN-73, "Assembly"](#).
- Install oil seals with drift (commercial service tool).

**A : 24.8 mm (0.976 in)**

**B : 10.3 mm (0.406 in)**

**CAUTION:**

- When checking the total preload torque, measure it without the oil seal, then install the oil seal.
- Never reuse the oil seal.
- When installing, never incline oil seal.
- Apply multi-purpose grease onto oil seal lips, and gear oil onto the circumference of the oil seal.
- Never damage oil seals by spline of ring gear shaft.



- After installing oil seals to transfer case, remove wrapped vinyl from the spline of ring gear shaft.
- Apply multi-purpose grease lightly and evenly onto an O-ring, and install it to the transfer case.

# TRANSFER CASE

< UNIT DISASSEMBLY AND ASSEMBLY >

[TRANSFER: TY21C]

**CAUTION:**

- Never reuse O-ring.
- When installing O-ring, never use a tool.
- Never damage O-ring.

A

## Inspection

INFOID:000000009694343

B

## INSPECTION AFTER DISASSEMBLY

Check items below. If necessary, replace them with new ones.

C

## Case

Check the bearing mounting surface for wear, cracks and damages.

DLN

E

F

G

H

I

J

K

L

M

N

O

P

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[TRANSFER: TY21C]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### General Specifications

INFOID:000000009694344

ℓ (US pt, Imp pt)

Applied model	VQ35DE	
	CVT	
Transfer model	TY21C	
Oil Type	MA-15 (United States and Canada) or MA-16 (Mexico)	
Oil capacity (Approx.)	0.31(5/8 pt, 1/2 pt)	
Gear ratio	0.404	
Number of teeth	Ring gear	42
	Drive pinion	17

#### Preload Torque

INFOID:000000009694345

Unit: N·m (kg-m, in-lb)

Item		Standard
Pinion bearing preload		0.25 – 1.15 (0.03 – 0.11, 3.0 – 10.0)
Total preload	With all oil seals	P1 + 0.7 – 1.0 (0.08 – 0.1, 7.0 – 8.0)
	Without oil seals (for transfer cover and transfer case)	P1 + 0.5 – 0.8 (0.06 – 0.08, 5.0 – 7.0)

#### Backlash

INFOID:000000009694346

Unit: mm (in)

Item	Standard
Ring gear to drive pinion	0.16 – 0.21 (0.0063 – 0.0083)

#### Companion Flange Runout

INFOID:000000009694347

Unit: mm (in)

Item	Limit
Companion flange face (inner side of the propeller shaft mounting bolt holes)	0.15 (0.0059)
Inside of companion flange (socket diameter)	0.1 (0.004)

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009710300

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes dual stage front air bag modules. The SRS system may only deploy one front air bag, depending on the severity of a collision and whether the front passenger seat is occupied. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# PREPARATION

< PREPARATION >


[REAR PROPELLER SHAFT: 3FCJ-CVJ]

## PREPARATION

### PREPARATION

#### Commercial Service Tool

INFOID:000000009694350

Tool name	Description
<p data-bbox="162 415 272 441">Power tool</p>  <p data-bbox="867 632 938 646">PBIC0190E</p>	<p data-bbox="1065 415 1318 441">Loosening bolts and nuts</p>

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[REAR PROPELLER SHAFT: 3FCJ-CVJ]

## SYMPTOM DIAGNOSIS

### NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

#### NVH Troubleshooting Chart

INFOID:000000009694351

Use the chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Symptom	Possible cause and SUSPECTED PARTS													
	Reference													
	Uneven rotating torque	Center bearing improper installation	Excessive center bearing axial end play	Center bearing mounting (insulator) cracks, damage or deterioration	Excessive joint angle	Rotation imbalance	Excessive runout	DIFFERENTIAL	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING
	DLN-96, "Inspection"	DLN-99, "Inspection"	—	DLN-99, "Inspection"	—	DLN-99, "Inspection"	DLN-96, "Inspection"	NVH of REAR FINAL DRIVE in this section	NVH in FAX, RAX, FSU and RSU section	NVH in WT section	NVH in WT section	NVH in FAX and RAX section	NVH in BR section	NVH in ST section
Noise	x	x	x	x	x	x	x	x	x	x	x	x	x	x
Shake		x			x			x	x	x	x	x	x	x
Vibration	x	x	x	x	x	x	x	x	x		x			x

x: Applicable

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

### BASIC INSPECTION

#### PROPELLER SHAFT ASSEMBLY

##### Inspection

INFOID:000000009694352

##### APPEARANCE AND NOISE INSPECTION

- Inspect the propeller shaft tube for dents or cracks. If damaged, replace the propeller shaft assembly.
- Check bearings for noise or damage. If damaged, replace as necessary.


##### PROPELLER SHAFT VIBRATION

###### NOTE:

If vibration is present at high speed, check propeller shaft runout first, then check mounting between propeller shaft and companion flange.

1. Measure the runout of the propeller shaft tube at several points by rotating the final drive companion flange with your hands.

**Propeller shaft runout** : Refer to [DLN-101, "Propeller Shaft Runout"](#).




- Propeller shaft runout measuring point (Point "Δ").

**Dimension (A)** : 612.0 mm (24.09 in)

**Dimension (B)** : 474.5 mm (18.68 in)

← : Front



2. If the runout still exceeds specifications, disconnect the propeller shaft at the final drive companion flange; then rotate the companion flange 90°, 180°, 270° and reconnect propeller shaft.
3. Check the runout again. If the runout still exceeds specifications, replace the propeller shaft assembly.
4. After installation, check for vibration by driving the vehicle.



# REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >


[REAR PROPELLER SHAFT: 3FCJ-CVJ]

## REMOVAL AND INSTALLATION

### REAR PROPELLER SHAFT

Exploded View

INFOID:000000009694353



1. Propeller shaft assembly
2. Center bearing mounting bracket (upper)
3. Clip
4. Center bearing mounting bracket (lower)

←: Vehicle front

⊗: Always replace after every disassembly.

Ⓜ: N·m (kg-m, ft-lb)

### Removal and Installation


INFOID:000000009694354

#### REMOVAL

1. Move the shift selector to the neutral position, and then release the parking brake.
2. Put matching marks onto propeller shaft flange yokes, final drive torsional damper, and transfer companion flange.

#### CAUTION:

**For matching marks, use paint. Do not damage propeller shaft flange yokes, final drive torsional damper or transfer companion flange.**



3. Remove front heat insulator.

# REAR PROPELLER SHAFT


< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 3FCJ-CVJ]

4. Loosen nuts of center bearing mounting brackets (upper/lower).

⇐ : Front

**CAUTION:**  
Tighten nuts temporarily.



5. Remove propeller shaft assembly nuts and bolts. Refer to [DLN-97. "Exploded View"](#).

6. Remove center bearing mounting bracket nuts.

7. Remove propeller shaft assembly.

**CAUTION:**

If constant velocity joint was bent during propeller shaft assembly removal, installation, or transportation, its boot may be damaged. Wrap boot with shop cloth or rubber to protect boot from damage.


8. Remove clips in center bearing mounting bracket (upper/lower).

9. Perform inspection after removal. Refer to [DLN-99. "Inspection"](#).


## INSTALLATION

Installation is in the reverse order of removal.

- Install center bearing mounting bracket [upper (1)] with its arrow mark (A) facing forward.
- Adjust position of center bearing mounting bracket (upper), center bearing mounting bracket [lower (2)] sliding back and forth to prevent play in thrust direction of center bearing insulator (3). Install center bearing mounting bracket (upper/lower) to vehicle.
- Align matching marks to install propeller shaft assembly to final drive and transfer companion flanges.
- Perform inspection after installation. Refer to [DLN-99. "Inspection"](#).



- After tightening the bolts and nuts to the specified torque, check that the bolts (3) on the flange side are tightened as shown.
- Final drive assembly (1)
- Propeller shaft assembly (2)




# REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 3FCJ-CVJ]

- If propeller shaft assembly or final drive assembly has been replaced, connect them as follows:
  - Install propeller shaft (1) while aligning its matching mark (A) with the matching mark (B) of the final drive (2) on the joint as close as possible.
  - Tighten bolts and nuts of propeller shaft and final drive to the specified torque.



## Inspection

### INSPECTION AFTER REMOVAL


#### Appearance

Check propeller shaft for bend and damage. If damage is detected, replace propeller shaft assembly.

#### Propeller Shaft Runout

Check propeller shaft runout at measuring points with a dial indicator. If runout exceeds specifications, replace propeller shaft assembly.


**Propeller shaft runout** : Refer to [DLN-101, "Propeller Shaft Runout"](#).



- Propeller shaft runout measuring point (Point "Δ").

← : Front

**Dimension (A)** : 612.0 mm (24.09 in)  
**Dimension (B)** : 474.5 mm (18.68 in)




#### Journal Axial Play

As shown, while fixing yoke on one side, check axial play of joint. If it is outside the standard, replace propeller shaft assembly.

**Journal axial play** : Refer to [DLN-101, "Journal Axial Play"](#).

**CAUTION:**  
Do not disassemble joints.



#### Center Bearing

Check center bearing for noise and damage. If noise or damage is detected, replace propeller shaft assembly.

## REAR PROPELLER SHAFT

< REMOVAL AND INSTALLATION >

[REAR PROPELLER SHAFT: 3FCJ-CVJ]

---

**CAUTION:**

**Do not disassemble center bearing.**

INSPECTION AFTER INSTALLATION

After assembly, perform a driving test to check propeller shaft vibration. If vibration occurs refer to [DLN-96](#).  
["Inspection"](#).

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REAR PROPELLER SHAFT: 3FCJ-CVJ]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### General Specifications

INFOID:000000009694356

Applied model		AWD
		VQ35DE
		CVT
Propeller shaft model		3FCJ-CVJ
Number of joints		3
Type of journal bearings (Non-disassembly type)	1st joint	Shell type
	2nd joint	CVJ type
	3rd joint	Shell type
Coupling method with transfer		Flange type
Coupling method with rear final drive		Flange type
Shaft length	1st (Spider to EDJ joint center)	1,332 mm (52.44 in)
	2nd (EDJ joint center to spider)	946 mm (37.24 in)
Shaft outer diameter	1st	80 mm (3.15 in)
	2nd	70 mm (2.76 in)

#### Propeller Shaft Runout

INFOID:000000009694357

Unit: mm (in)

Item	Limit
Propeller shaft runout	0.8 (0.031)

#### Journal Axial Play

INFOID:000000009694358

Unit: mm (in)

Item	Standard
Journal axial play	0 (0)

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009760282

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes dual stage front air bag modules. The SRS system may only deploy one front air bag, depending on the severity of a collision and whether the front passenger seat is occupied. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

#### Service Notice or Precautions for Rear Final Drive

INFOID:000000009694363

- Check for the correct installation status prior to removal or disassembly. If matching marks are required, be certain they never interfere with the function of the parts when applied.
- Overhaul should be done in a clean work area, it is preferable to work in dustproof area.
- Before disassembly, using steam or white gasoline, completely remove sand and mud from the exterior of the unit, preventing them from entering into the unit during disassembly or assembly.
- Check appearance of the disassembled parts for damage, deformation, and unusual wear. Replace them with a new one if necessary.
- Seals should be replaced any time when the unit is disassembled.
- In principle, tighten bolts or nuts gradually in several steps working diagonally from inside to outside. If tightening sequence is specified, observe it.
- Clean and flush the parts sufficiently and blow-dry them.
- Be careful not to damage sliding surfaces and mating surfaces.
- When applying sealant, remove the old sealant from the mounting surface; then remove any moisture, oil, and foreign materials from the application and mounting surfaces.
- Always use shop paper for cleaning the inside of components.
- Avoid using cotton gloves or shop rags to prevent entering of lint.
- During assembly, observe the specified tightening torque, and apply new gear oil, petroleum jelly, or multi-purpose grease as specified for each vehicle, if necessary.

# PREPARATION

< PREPARATION >

[REAR FINAL DRIVE: R145K1]

## PREPARATION


### PREPARATION

#### Special Service Tools

INFOID:000000009694364

The actual shapes of Kent-More tools may differ from those of special service tools illustrated here.


Tool number (Kent-More No.) Tool name	Description
ST30720000 (J-25405) Drift a: 77 mm (3.03 in) dia. b: 55 mm (2.185 in) dia.	Installing front oil seal
KV40105740 ( — ) Drift a: 57 mm (2.24 in) dia. b: 48 mm (1.89 in) dia.	Installing side oil seal (cover side)
KV31103000 (J-38982) Drift a: 70 mm (2.76 in) dia. b: 59 mm (2.32 in) dia. c: 49 mm (1.93 in) dia.	Installing side oil seal (carrier side)
ST35325000 ( — ) Drift bar	Installing side oil seal (carrier side)




ZZA0811D



ZZA0832D



S-NT107



S-NT090

#### Commercial Service Tools



INFOID:000000009694365

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# PREPARATION

< PREPARATION >

[REAR FINAL DRIVE: R145K1]

Tool name	Description
<p data-bbox="159 197 315 224">Flange wrench</p>  <p data-bbox="824 415 870 432">NT771</p>	<p data-bbox="1008 197 1425 254">Removing and installing torsional damper mounting nut</p>
<p data-bbox="159 449 272 476">Power tool</p>  <p data-bbox="824 667 899 684">PBIC0190E</p>	<p data-bbox="1008 449 1260 476">Loosening bolts and nuts</p>




SYSTEM DESCRIPTION

STRUCTURE AND OPERATION

Sectional View

INFOID:000000009694366



- |                     |                                 |                      |
|---------------------|---------------------------------|----------------------|
| 1. Torsional damper | 2. Electric controlled coupling | 3. Wave washer       |
| 4. Front oil seal   | 5. Drive pinion                 | 6. Differential case |
| 7. Side oil seal    |                                 |                      |

Electric Controlled Coupling

INFOID:000000009694367

The electric controlled coupling operates as the AWD system. For the operation, refer to [DLN-12. "Operation Description"](#).

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## ADDITIONAL SERVICE WHEN REPLACING REAR FINAL DRIVE ASSEMBLY

< BASIC INSPECTION >

[REAR FINAL DRIVE: R145K1]

---

### BASIC INSPECTION

#### ADDITIONAL SERVICE WHEN REPLACING REAR FINAL DRIVE ASSEMBLY

##### Description

INFOID:000000009694368

When replacing rear final drive assembly, unit characteristics writing is required.

##### Work Procedure

INFOID:000000009694369

##### 1. PERFORM WRITING UNIT CHARACTERISTICS

---

Perform writing unit characteristics of electric controlled coupling.

>> Refer to [DLN-42. "Work Procedure"](#).

# ADDITIONAL SERVICE WHEN REPLACING ELECTRIC CONTROLLED COUPLING

< BASIC INSPECTION >

[REAR FINAL DRIVE: R145K1]

## ADDITIONAL SERVICE WHEN REPLACING ELECTRIC CONTROLLED COUPLING

### Description

INFOID:000000009694370

When replacing electric controlled coupling, unit characteristics writing is required.

### Work Procedure

INFOID:000000009694371

#### 1.PERFORM WRITING UNIT CHARACTERISTICS

Perform writing unit characteristics of electric controlled coupling.

>> Refer to [DLN-42. "Work Procedure"](#).

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

< SYMPTOM DIAGNOSIS >

[REAR FINAL DRIVE: R145K1]

## SYMPTOM DIAGNOSIS

### NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

#### NVH Troubleshooting Chart

INFOID:000000009694372

Use the chart below to find the cause of the symptom. If necessary, repair or replace these parts.

Symptom	Noise	Gear tooth rough	Gear contact improper	Tooth surfaces worn	Backlash incorrect	Companion flange excessive runout	Gear oil improper	PROPELLER SHAFT	AXLE AND SUSPENSION	TIRE	ROAD WHEEL	DRIVE SHAFT	BRAKE	STEERING
Reference		—	—	—	—	<a href="#">DLN-128. "Adjustment"</a>	<a href="#">DLN-109. "Inspection"</a>	NVH of REAR PROPELLER SHAFT in this section	NVH in FAX, RAX, FSU and RSU sections	NVH in WT section	NVH in WT section	NVH in FAX and RAX section	NVH in BR section	NVH in ST section
Possible cause and SUSPECTED PARTS														
		x	x	x	x	x	x	x	x	x	x	x	x	x

x: Applicable

# REAR DIFFERENTIAL GEAR OIL

< PERIODIC MAINTENANCE >

[REAR FINAL DRIVE: R145K1]

## PERIODIC MAINTENANCE

### REAR DIFFERENTIAL GEAR OIL

#### Inspection

INFOID:000000009694373

#### REAR DIFFERENTIAL GEAR OIL LEAKS

Check that rear differential gear oil is not leaking from final drive assembly or around it.

#### REAR DIFFERENTIAL GEAR OIL LEVEL

##### CAUTION:

**Do not start engine while checking rear differential gear oil level.**


1. Remove and discard filler plug (1).

##### CAUTION:

**Do not reuse filler plug.**

⇐ : Front

2. Rear differential gear oil level should be level with the bottom of filler plug hole. Add rear differential gear oil if necessary. Refer to [MA-15, "FOR USA AND CANADA : Fluids and Lubricants"](#) (USA and CANADA) or [MA-16, "FOR MEXICO : Fluids and Lubricants"](#) (MEXICO).
3. Install filler plug (1) and tighten to specified torque. Refer to [DLN-125, "Exploded View"](#).



#### Draining

INFOID:000000009694374

##### CAUTION:

**Do not start engine while checking rear differential gear oil level.**


1. Remove and discard drain plug (1), and drain rear differential gear oil.

##### CAUTION:

**Do not reuse drain plug.**

⇐ : Front

2. Install drain plug (1) and tighten to specified torque. Refer to [DLN-125, "Exploded View"](#).



#### Refilling

INFOID:000000009694375

##### CAUTION:

**Do not start engine while checking rear differential gear oil level.**


1. Remove and discard filler plug (1).

##### CAUTION:

**Do not reuse filler plug.**

⇐ : Front

2. Fill with new rear differential gear oil to the specified level near the filler plug hole.



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## REAR DIFFERENTIAL GEAR OIL

< PERIODIC MAINTENANCE >

[REAR FINAL DRIVE: R145K1]

---

Rear differential gear oil grade and viscosity : Refer to [MA-15. "FOR USA AND CANADA : Fluids and Lubricants"](#) (USA and CANADA) or [MA-16. "FOR MEXICO : Fluids and Lubricants"](#) (MEXICO).

Rear differential gear oil capacity : Refer to [DLN-130. "General Specification"](#).

3. Install filler plug (1) and tighten to specified torque. Refer to [DLN-125. "Exploded View"](#).

# TORSIONAL DAMPER

< REMOVAL AND INSTALLATION >


[REAR FINAL DRIVE: R145K1]

## REMOVAL AND INSTALLATION

### TORSIONAL DAMPER

#### Exploded View

INFOID:000000009694376



1. Final drive assembly
2. Torsional damper

←: Vehicle front

⊗: Always replace after every disassembly.

Ⓜ: N·m (kg·m, ft·lb)


### Removal and Installation

INFOID:000000009694377

#### REMOVAL

1. Remove rear propeller shaft from the torsional damper, and support the end of the propeller shaft. Refer to [DLN-97. "Exploded View"](#).
2. Remove torsional damper lock nuts (←), using suitable tool.

← : Front



3. Remove torsional damper.

#### INSTALLATION

1. Install torsional damper. (When torsional damper has been reused.)

**CAUTION:**  
Clean the mounting surface.

2. Install torsional damper. (When torsional damper has been replaced.)  
Degrease the mounting surface of electric controlled coupling, according to the following instruction.

# TORSIONAL DAMPER


## < REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R145K1]

1. Spray alcohol on a cotton cloth four times per part.

**CAUTION:**


**Always use a new cotton cloth.**



2. Wipe the mounting surface of electric controlled coupling five times.

**CAUTION:**


**Complete the work within 180 seconds to prevent alcohol from evaporating.**



3. Install torsional damper lock nuts, using suitable tool, and tighten to the specified torque.

**CAUTION:**

**Do not reuse torsional damper lock nuts.**




4. Check torsional damper runout as follows:

- Rotate torsional damper and check for runout on the torsional damper face (inner side of the bolt holes) using a suitable tool (1). Also check for runout on the inner side of the torsional damper using a suitable tool (2).

**Torsional damper runout** : Refer to [DLN-130, "Companion Flange Runout"](#).

- If the runout value is outside the runout limit, follow the procedure below to adjust.
- Check for runout while changing the phase between the torsional damper and electric controlled coupling by 90° step, and search for the position where the runout value is the minimum.
- If the runout value is still outside of the runout limit after the phase has been changed, replace the torsional damper.
- If the runout value is still outside of the runout limit after torsional damper has been replaced, possible cause will be a damaged electric controlled coupling. Repair as necessary. Refer to [DLN-111, "Removal and Installation"](#).



5. Install rear propeller shaft. Refer to [DLN-97, "Exploded View"](#).



# SIDE OIL SEAL


< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R145K1]

## SIDE OIL SEAL

Exploded View

INFOID:000000009694378



- 1. Final drive assembly
- 2. Side oil seal
- A. Oil seal lip

⇐: Vehicle front

⊗: Always replace after every disassembly.

🔧: Apply gear oil.

## Removal and Installation


INFOID:000000009694379

### REMOVAL

1. Remove rear drive shaft (LH) or (RH) as necessary. Refer to [RAX-9, "Removal and Installation"](#).
2. Remove side oil seal (1), using suitable tool.

**CAUTION:**  
Be careful not to damage gear carrier and side cover.

⇐ : Front



### INSTALLATION

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## SIDE OIL SEAL

### < REMOVAL AND INSTALLATION >


[REAR FINAL DRIVE: R145K1]

1. Install side oil seal (cover side) until it becomes flush with the carrier end, using Tool (A).

Tool number (A) : KV40105740 ( — )

**CAUTION:**

- Do not reuse side oil seal.
- When installing, do not incline side oil seals.
- Apply rear differential gear oil onto side oil seal lip.




2. Install side oil seal (carrier side) until it becomes flush with the carrier end, using Tool (A) and Tool (B).

Tool number (A) : ST35325000 ( — )

Tool number (B) : KV31103000 (J-38982)

**CAUTION:**

- Do not reuse side oil seal.
- When installing, do not incline side oil seals.
- Apply rear differential gear oil onto side oil seal lip.



3. Install rear drive shaft (LH) or (RH) as necessary. Refer to [RAX-9, "Removal and Installation"](#).
4. Check rear differential gear oil level and check for rear differential gear oil leaks. Refer to [DLN-109, "Inspection"](#).

# ELECTRIC CONTROLLED COUPLING


< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R145K1]

## ELECTRIC CONTROLLED COUPLING

Exploded View

INFOID:000000009694380



- |                                 |                     |                  |
|---------------------------------|---------------------|------------------|
| 1. Stud bolt                    | 2. Filler plug      | 3. Side oil seal |
| 4. Final drive assembly         | 5. Front oil seal   | 6. Wave washer   |
| 7. Electric controlled coupling | 8. Torsional damper | 9. Reamer bolt   |
| 10. Harness bracket             | 11. Drain plug      | A. Oil seal lip  |
| B. Final drive mounting face    |                     |                  |

## Removal and Installation

INFOID:000000009694381

### NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

### CAUTION:


When replacing rear final drive assembly, perform writing unit characteristics. Refer to [DLN-42, "Work Procedure"](#).

### REMOVAL

1. Move the shift selector to the neutral position, and then release the parking brake.
2. Drain rear differential gear oil. Refer to [DLN-109, "Draining"](#).
3. Remove rear propeller shaft from the torsional damper, and support the end of the propeller shaft. Refer to [DLN-97, "Exploded View"](#).

### CAUTION:

For matching marks, use paint. Do not damage propeller shaft flange yokes, final drive torsional damper or transfer companion flange.




ALDIA0282ZZ

# ELECTRIC CONTROLLED COUPLING

< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R145K1]

4. Remove the electric controlled coupling breather hose (1).



5. Disconnect the electric controlled coupling harness connector and unclip harness from harness bracket.  
6. Remove the 6 bolts from the electric controlled coupling.

7. Remove the electric controlled coupling.

**CAUTION:**

Be careful that the wave washer does not fall out or get damaged when removing the electric controlled coupling.

## INSTALLATION


Installation is in the reverse order of removal.

**CAUTION:**

- Do not reuse hose clamp and breather connector.
  - Make sure there are no pinched or restricted areas on the breather hose caused by bending or winding when installing it.
  - Install the hose clamp at the final drive side, with the tab facing to the vehicle front.
  - Install the hose clamp at the suspension member side, with the tab facing downward.
  - Use Genuine Silicone RTV or an equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).
- Apply liquid gasket (1) to mating surface of coupling cover.  
Use Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

**CAUTION:**


- The width of sealant bend is approximately 3 mm (0.012 in).



- Install electric controlled coupling to spline of drive pinion inside final drive assembly.

**CAUTION:**

- Align the pin (A) on electric controlled coupling with the groove (B) of final drive assembly.
- Be careful not to damage center oil seal.



# ELECTRIC CONTROLLED COUPLING


## < REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R145K1]

- Press the electric controlled coupling pin to check that it is positioned in the groove of the final drive assembly as shown.

**NOTE:**


If the pin is properly positioned in the groove, then the electric controlled coupling can be pressed into position by the same amount of flexion of the wave washer.



- Temporarily tighten reamer bolts (1) to the positions shown.

**CAUTION:**

- Do not use tools. Always tighten by hand.
- If reamer bolts cannot be tightened all the way by hand, the electric controlled coupling pin may not be positioned in the groove of the final drive assembly. In this case, remove electric controlled coupling and reinstall it.




- Install the electric controlled coupling breather hose (1) as shown.
- Install electric controlled coupling breather hose at the coupling side to the metal connector (3) of the coupling (2) all the way to the point shown by the solid arrow (←).

← : Front

- Install electric controlled coupling breather hose at the suspension member side until dimension (A) as shown.


(A) : 15 mm (0.59 in)



- If resin connector of the electric controlled coupling (1) and metal connector (2) are removed, install them as shown.
- Install the resin connector at the insertion side to the suspension member, facing to the vehicle front.
- Install the metal connector to the coupling cover, facing to the vehicle front.

**CAUTION:**

Do not reuse breather connector and hose clip.



- Remove the old sealant from mating surfaces using a suitable tool before installing.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# FRONT OIL SEAL


< REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R145K1]

## FRONT OIL SEAL

Exploded View

INFOID:000000009694382




- |                                 |                     |                  |
|---------------------------------|---------------------|------------------|
| 1. Stud bolt                    | 2. Filler plug      | 3. Side oil seal |
| 4. Final drive assembly         | 5. Front oil seal   | 6. Wave washer   |
| 7. Electric controlled coupling | 8. Torsional damper | 9. Reamer bolt   |
| 10. Harness bracket             | 11. Drain plug      | A. Oil seal lip  |
| B. Final drive mounting face    |                     |                  |

## Removal and Installation

INFOID:000000009694383

### REMOVAL

1. Drain rear differential gear oil. Refer to [DLN-109. "Draining"](#).
2. Remove the rear propeller shaft from the rear final drive and support the rear propeller shaft with suitable wire. Refer to [DLN-97. "Removal and Installation"](#).
3. Remove torsional damper nuts using suitable tool (A) and remove torsional damper (if necessary).



4. Remove the electric controlled coupling. Refer to [DLN-115. "Removal and Installation"](#).
5. Remove wave washer.

# FRONT OIL SEAL


## < REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R145K1]

6. Remove front oil seal (1) from final drive assembly, using a suitable tool.

**CAUTION:**

Do not damage final drive assembly.



## INSTALLATION

1. Install drain plug.

**CAUTION:**

Do not reuse drain plug.


2. Using a Tool (A) install front oil seal (1) as shown.

Tool number : ST30720000 (J-25405)

**CAUTION:**

- Do not reuse front oil seal.
- When installing, do not incline front oil seal.
- Apply rear differential gear oil onto front oil seal lip.

3. Install wave washer to electric controlled coupling.




4. Apply liquid gasket (1) to mating surface of coupling cover.

Use Genuine Silicone RTV or equivalent. Refer to [GI-22, "Recommended Chemical Products and Sealants"](#).

**CAUTION:**


- Remove old gasket adhering to the surfaces. Also remove any moisture, rear differential gear oil, or foreign material adhering to the surfaces.
- The width of sealant bend is approximately 3 mm (0.012 in).



5. Install electric controlled coupling to spline of drive pinion inside final drive assembly.

**CAUTION:**

- Align the pin (A) on electric controlled coupling with the groove (B) of final drive assembly.
- Be careful not to damage front oil seal.



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# FRONT OIL SEAL


## < REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R145K1]

6. Press the electric controlled coupling pin to check that it is positioned in the groove of the final drive assembly as shown.

**NOTE:**

If the pin is properly positioned in the groove, then the electric controlled coupling can be pressed into position by the same amount of flexion of the wave washer.




7. Temporarily tighten reamer bolts (1) to the positions shown.

**CAUTION:**

- Do not use tools. Always tighten by hand.
- If reamer bolts cannot be tightened all the way by hand, the electric controlled coupling pin may not be positioned in the groove of the final drive assembly. In this case, remove electric controlled coupling and reinstall it.

8. Tighten reamer bolts and coupling cover bolts to the specified torque.
9. Install harness bracket, and tighten bolts to the specified torque.
10. Install torsional damper. (When torsional damper has been replaced.)




Degrease the surface of electric controlled coupling, according to the following instruction.

1. Spray alcohol on a cotton cloth four times per part.

**CAUTION:**


Always use a new cotton cloth.



2. Wipe the surface of electric controlled coupling five times.

**CAUTION:**

Complete the work within 180 seconds to prevent alcohol from evaporating.





## FRONT OIL SEAL

### < REMOVAL AND INSTALLATION >


[REAR FINAL DRIVE: R145K1]

3. Install torsional damper nut, using suitable tool (1) and tighten to the specified torque.

**CAUTION:**

**Do not reuse torsional damper nut.**

11. Check companion flange runout. Refer to [DLN-130, "Companion Flange Runout"](#).
12. When replacing electric controlled coupling, perform writing unit characteristics after installing final drive assembly to the vehicle. Refer to [DLN-107, "Work Procedure"](#).



A  
B  
C

DLN

E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# REAR FINAL DRIVE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >


[REAR FINAL DRIVE: R145K1]

## UNIT REMOVAL AND INSTALLATION

### REAR FINAL DRIVE ASSEMBLY

#### Exploded View

INFOID:000000009694384



- |                                 |                  |                         |
|---------------------------------|------------------|-------------------------|
| 1. Final drive mounting bracket | 2. Washer        | 3. Breather             |
| 4. Breather hose                | 5. Breather tube | 6. Final drive assembly |
| 7. Breather tube                | 8. Hose clamp    | 9. Breather hose        |
| 10. Breather                    |                  |                         |

↔: Vehicle front

⊗: Always replace after every disassembly.

🔧: N·m (kg-m, ft-lb)

#### Removal and Installation

INFOID:000000009694385

##### NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

##### REMOVAL


1. Drain rear differential gear oil. Refer to [DLN-109, "Draining"](#).
2. Remove the rear propeller shaft from the final drive assembly and support the rear propeller shaft with suitable wire. Refer to [DLN-97, "Removal and Installation"](#).
3. Remove the vehicle spare tire.
4. Remove the rear drive shafts. Refer to [RAX-9, "Removal and Installation"](#).
5. Remove rear stabilizer bar. Refer to [RSU-15, "Removal and Installation"](#).
6. Remove AWD harness bracket.
7. Disconnect AWD harness connector and unclip harness from the final drive mounting bracket.
8. Remove breather hose and electric controlled coupling breather hose.
9. Support final drive assembly with a suitable jack.

# REAR FINAL DRIVE ASSEMBLY

< UNIT REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R145K1]

10. Remove final drive bolts (←).




11. Remove rear final drive nut (←) at rear suspension member, and remove final drive from vehicle.

**NOTE:**

If it is necessary to remove the final drive mounting bracket, the fuel tank must be removed first. Refer to [FL-13. "Removal and Installation"](#).

**CAUTION:**

Secure final drive assembly to a suitable jack while removing it.



## INSTALLATION


Installation is in the reverse order of removal.

- Install the breather hose (1) to breather connector until dimension (A) shown as follows.


- (A) : 20 mm (0.79 in) Final drive side
- : 20.7 mm (0.815 in) Suspension member side

**CAUTION:**

- Do not reuse hose clamp and breather connector.
- Make sure there are no pinched or restricted areas on the breather hose caused by bending or winding when installing it.
- Install the hose clamp at the final drive side, with the tab facing to the vehicle front.
- Install the hose clamp at the suspension member side, with the tab facing downward.
- If remove resin connector (2) and metal connector (3), install breather hose (1), resin connector and metal connector as shown.
- For installation, insert resin connector into the square hole of rear suspension. Install metal connector to rear cover with aiming painted mark (A) to the front of vehicle.



← : Front



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# REAR FINAL DRIVE ASSEMBLY

## < UNIT REMOVAL AND INSTALLATION >

[REAR FINAL DRIVE: R145K1]

- Install the electric controlled coupling breather hose (1) as shown in the figure.
- Install electric controlled coupling breather hose at the coupling side to the metal connector (3) of the coupling (2) all the way to the point shown by the solid arrow (←).

← : Front

- Install electric controlled coupling breather hose at the suspension member side until dimension (A) shown as follows.

(A) : 15 mm (0.59 in)

- If remove resin connector of the electric controlled coupling (1) and metal connector (2), install them as shown.
- Install the resin connector at the insertion side to the suspension member, facing to the vehicle front.
- Install the metal connector to the coupling cover, facing to the vehicle front.

**CAUTION:**

**Do not reuse breather connector and hose clip.**




- If remove plug (1) and (2), install them as shown.

← : Front

**CAUTION:**

**Do not reuse breather connector and hose clip.**

- When oil leaks while removing final drive assembly, check oil level after the installation. Refer to [DLN-109. "Inspection"](#).
- When replacing rear final drive assembly, perform writing unit characteristics. Refer to [DLN-106. "Work Procedure"](#).



# REAR FINAL DRIVE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: R145K1]

## UNIT DISASSEMBLY AND ASSEMBLY

### REAR FINAL DRIVE ASSEMBLY

Exploded View

INFOID:000000009694386



- |                                 |                              |                  |
|---------------------------------|------------------------------|------------------|
| 1. Stud bolt                    | 2. Filler plug               | 3. Side oil seal |
| 4. Final drive assembly         | 5. Front oil seal            | 6. Wave washer   |
| 7. Electric controlled coupling | 8. Torsional damper          | 9. Reamer bolt   |
| 10. Harness bracket             | 11. Drain plug               |                  |
| A. Oil seal lip                 | B. Final drive mounting face |                  |

⊗: Always replace after every disassembly.

⊕: N·m (kg-m, ft-lb)

⊖: N·m (kg-m, in-lb)


⊚: Apply gear oil.

⊔: Apply Genuine Silicone RTV or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).

### Disassembly

INFOID:000000009694387

1. Remove torsional damper mounting nut, using a flange wrench (1) (commercial service tool).
2. Remove torsional damper.
3. Remove harness bracket.
4. Remove electric controlled coupling.
5. Remove wave washer.




# REAR FINAL DRIVE ASSEMBLY


< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R145K1]

6. Remove front oil seal (1) from final drive assembly, using a oil seal remover.  
**CAUTION:**  
**Never damage final drive assembly.**
7. Remove drain plug and filler plug, if necessary.




8. Remove side oil seal (1), using a oil seal remover.  
**CAUTION:**  
**Never damage final drive assembly and side cover.**
9. Remove stud bolt from side cover, if necessary.



INFOID:000000009694388

## Assembly

1. Install stud bolt to side cover.  
**CAUTION:**  
**Never reuse stud bolt.**
2. Install side oil seal (cover side) until it becomes flush with the carrier end, using the drift (A) [SST: KV40105740 ( — )].  
**CAUTION:**
  - Never reuse oil seal.
  - When installing, do not incline oil seals.
  - Apply gear oil onto side oil seal lip.




3. Install side oil seal (carrier side) until it becomes flush with the carrier end, using the drift (A) and drift bar (B).

A : Drift [SST: KV31103000 (J-38982)]

B : Drift bar [SST: ST35325000 ( — )]

- CAUTION:**
- Never reuse oil seal.
  - When installing, do not incline oil seals.
  - Apply gear oil onto side oil seal lip.

4. Install drain plug.  
**CAUTION:**  
**Never reuse drain plug.**
5. Install filler plug.  
**CAUTION:**  
**Never reuse filler plug.**



# REAR FINAL DRIVE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R145K1]


6. Using the drift (A) [SST: ST30720000 (J-25405)], install front oil seal (1) as shown in the figure.

**B** : 0.5 – 1.2 mm (0.020 – 0.047 in)

**CAUTION:**

- Never reuse oil seal.
- When installing, never incline oil seal.
- Apply gear oil onto side oil seal lip.


7. Install wave washer to electric controlled coupling.



8. Apply liquid gasket (1) to mating surface of coupling cover. Use Genuine Silicone RTV or equivalent. Refer to [GI-22. "Recommended Chemical Products and Sealants"](#).

**CAUTION:**


- Remove old gasket adhering to the mounting surfaces. Also remove any moisture, oil, or foreign material adhering to the mounting surfaces.
- The width of sealant bend is approximately 3 mm (0.012 in).



9. Install electric controlled coupling to spline of drive pinion inside final drive assembly.

**CAUTION:**


- Align the pin (A) on electric controlled coupling with the groove (B) of final drive assembly.
- Be careful not to damage center oil seal.



10. Press the electric controlled coupling pin to check that it is positioned in the groove of the final drive assembly as shown in the figure.

**NOTE:**

If the pin is properly positioned in the groove, then the electric controlled coupling can be pressed by the same amount of flexion of the wave washer.



A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## REAR FINAL DRIVE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >

[REAR FINAL DRIVE: R145K1]

11. Temporarily tighten reamer bolts (1) to the positions shown in the figure.

**CAUTION:**

- Never use tools. Always tighten by hand.
- If reamer bolts cannot be tightened all the way by hand, the electric controlled coupling pin may not be positioned in the groove of the final drive assembly. In this case, remove electric controlled coupling and reinstall it.

12. Tighten reamer bolts and coupling cover mounting bolts to the specified torque.

13. Install harness bracket, and tighten bolts to the specified torque.

14. Install torsional damper. (When torsional damper has been reused.)

**CAUTION:**

**Clean the mounting surface.**



15. Install torsional damper. (When torsional damper has been replaced.)

Degrease the mounting surface of electric controlled coupling, according to the following instruction.

1. Spray alcohol on a cotton cloth four times per part.

**CAUTION:**


**Always use a new cotton cloth.**



2. Wipe the mounting surface of electric controlled coupling five times.

**CAUTION:**

**Complete the work within 180 seconds to prevent alcohol from evaporating.**



16. Install torsional damper mounting nut, using flange wrench (1) (commercial service tool) and tighten to the specified torque.


**CAUTION:**

**Never reuse torsional damper mounting nut.**

17. Check companion flange runout. Refer to [DLN-128. "Adjustment"](#).

18. When oil leaks while removing, check oil level after installation. Refer to [DLN-109. "Inspection"](#).

19. When replacing electric controlled coupling, perform writing unit characteristics after installing final drive assembly to the vehicle. Refer to [DLN-107. "Work Procedure"](#).



### Adjustment

INFOID:000000009694389

### COMPANION FLANGE RUNOUT



# REAR FINAL DRIVE ASSEMBLY

< UNIT DISASSEMBLY AND ASSEMBLY >


[REAR FINAL DRIVE: R145K1]

Check for companion flange runout as follows:

- For companion flange face, fit a dial indicator (1) onto the companion flange face (inner side of the propeller shaft mounting bolt holes). For inner side of the companion flange, fit a test indicator (2) to the inner side of companion flange (socket diameter).
- Rotate companion flange to check for runout.

**Companion flange runout** : Refer to [DLN-130, "Companion Flange Runout"](#).

- If the runout value is outside the runout limit, follow the procedure below to adjust.
- Check for runout while changing the phase between companion flange and drive pinion by 90° step, and search for the position where the runout is the minimum.
- If the runout value is still outside of the limit after the phase has been changed, replace companion flange.
- If the runout value is still outside of the limit after companion flange has been replaced, possible cause will be an electric controlled coupling.



## Inspection

INFOID:000000009694390

### OIL SEAL

- Whenever disassembled, replace.
- If wear, deterioration of adherence (sealing force lips), or damage is detected on the lips, replace them.

### COMPANION FLANGE

- Clean up the disassembled parts.
- If any chipped mark [about 0.1 mm, (0.004 in)] or other damage on the contact sides of the lips of the companion flange is found, replace.

A  
B  
C  
DLN  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[REAR FINAL DRIVE: R145K1]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### General Specification

INFOID:000000009694391

Applied model	AWD
	VQ35DE
	CVT
Final drive model	R145K1
Gear ratio	2.466
Number of teeth (Drive gear/Drive pinion)	37/15
Oil capacity (Approx.) $\ell$ (US pt, Imp pt)	0.5 (1, 7/8)
Number of pinion gears	2

#### Companion Flange Runout

INFOID:000000009694392

Unit: mm (in)

Item	Limit
Companion flange face	0.12 (0.0047)
Inner side of the companion flange	0.27 (0.0106)