

SECTION **INL**

INTERIOR LIGHTING SYSTEM

A
B
C
D
E

F
G
H
I
J
K
L
M
N
O
P

INL

CONTENTS

PRECAUTION	3	BATTERY SAVER	12
PRECAUTIONS	3	BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)	12
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER"	3		
Precaution for Work	3		
PREPARATION	4	ECU DIAGNOSIS INFORMATION	13
PREPARATION	4	BCM	13
Special Service Tool	4	List of ECU Reference	13
SYSTEM DESCRIPTION	5	WIRING DIAGRAM	14
COMPONENT PARTS	5	INTERIOR ROOM LAMP CONTROL SYSTEM	14
Component Parts Location	5	Wiring Diagram	14
Component Description	5	ILLUMINATION	28
SYSTEM	7	Wiring Diagram	28
INTERIOR ROOM LAMP CONTROL SYSTEM	7	BASIC INSPECTION	45
INTERIOR ROOM LAMP CONTROL SYSTEM : System Diagram	7	DIAGNOSIS AND REPAIR WORKFLOW	45
INTERIOR ROOM LAMP CONTROL SYSTEM : System Description	7	Work Flow	45
ILLUMINATION CONTROL SYSTEM	8	DTC/CIRCUIT DIAGNOSIS	48
ILLUMINATION CONTROL SYSTEM : System Diagram	8	POWER SUPPLY AND GROUND CIRCUIT	48
ILLUMINATION CONTROL SYSTEM : System Description	8	Diagnosis Procedure	48
DIAGNOSIS SYSTEM (BCM)	10	BATTERY SAVER OUTPUT/POWER SUP- PLY CIRCUIT	49
COMMON ITEM	10	Description	49
COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)	10	Component Function Check	49
INT LAMP	11	Diagnosis Procedure	49
INT LAMP : CONSULT Function (BCM - INT LAMP)	11	INTERIOR ROOM LAMP CONTROL CIRCUIT	51
		Description	51
		Component Function Check	51
		Diagnosis Procedure	51
		STEP LAMP CIRCUIT	53
		Description	53
		Component Function Check	53

Diagnosis Procedure	53	DRIVER SIDE	64
OUTSIDE HANDLE LAMP CIRCUIT	55	DRIVER SIDE : Exploded View	64
Description	55	DRIVER SIDE : Removal and Installation	64
Component Function Check	55	DRIVER SIDE : Bulb Replacement	64
Diagnosis Procedure	55		
PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT	57	PASSENGER SIDE	64
Description	57	PASSENGER SIDE : Exploded View	65
Component Function Check	57	PASSENGER SIDE : Bulb Replacement	65
Diagnosis Procedure	57		
SYMPTOM DIAGNOSIS	59	STEP LAMP	66
INTERIOR LIGHTING SYSTEM SYMPTOMS...	59	Exploded View	66
Symptom Table	59	Removal and Installation	66
REMOVAL AND INSTALLATION	60	Bulb or Lens Replacement	66
FRONT ROOM/MAP LAMP	60		
Exploded View	60	PERSONAL LAMP	67
Removal and Installation	60	Exploded View	67
Bulb or Lens Replacement	61	Removal and Installation	67
VANITY LAMP	62	Bulb or Lens Replacement	67
Exploded View	62		
Removal and Installation	62	CARGO LAMP	68
Bulb or Lens Replacement	62	Exploded View	68
GLOVE BOX LAMP	63	Removal and Installation	68
Exploded View	63	Bulb or Lens Replacement	68
Bulb Replacement	63		
FOOT LAMP	64	ILLUMINATION CONTROL SWITCH	69
		Removal and Installation	69
		SERVICE DATA AND SPECIFICATIONS (SDS)	70
		Exploded View	70
		Removal and Installation	70
		Bulb Specifications	70

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000009131986

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes dual stage front air bag modules. The SRS system may only deploy one front air bag, depending on the severity of a collision and whether the front passenger seat is occupied. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:0000000009712192

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
 - Water soluble dirt:
 - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
 - Then rub with a soft, dry cloth.
 - Oily dirt:
 - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
 - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
 - Then rub with a soft, dry cloth.
 - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
 - For genuine leather seats, use a genuine leather seat cleaner.

PREPARATION

< PREPARATION >

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000009131988

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:0000000009131989



AWLIA195ZZ

1. BCM (view with combination meter removed)
2. Front door switch LH (RH similar)
3. Rear door switch LH (RH similar)
4. Main power window and door lock/unlock switch
5. Power window and door lock/unlock switch RH
6. Back door lock assembly (back door switch)
7. Front door lock assembly LH
8. Combination switch (lighting and turn signal switch)
9. Meter control switch (illumination control switch)
10. Push-button ignition switch
11. IPDM E/R

Component Description

INFOID:0000000009131990

Part name	Description
BCM	The BCM monitors the combination switch (lighting and turn signal switch) position. The BCM requests via CAN communication that the IPDM E/R activate the tail lamp relay.

A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

IPDM E/R	The IPDM E/R activates the tail lamp relay based on inputs received from the BCM via the CAN communication.
Push button ignition switch	Provides ignition status to the BCM.
Door switches	Provides door OPEN/CLOSED status to the BCM.
Combination switch (lighting and turn signal switch)	The combination switch (lighting and turn signal switch) provides input to the BCM about the combination switch (lighting and turn signal switch) position.
Back door lock assembly (door ajar switch)	Provides back door OPEN/CLOSED status to the BCM.
Power window and door lock/unlock switch RH	Provides door lock/unlock position switch RH status to the BCM.
Main power window and door lock/unlock switch [front door lock assembly LH (key cylinder switch)].	Provides door lock/unlock position switch LH status to the BCM.
Meter control switch (illumination control switch)	Adjusts the illumination system and combination meter illumination brightness.

SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM

INTERIOR ROOM LAMP CONTROL SYSTEM

INTERIOR ROOM LAMP CONTROL SYSTEM : System Diagram

INFOID:0000000009131991



AWLIA1948GB

INTERIOR ROOM LAMP CONTROL SYSTEM : System Description

INFOID:0000000009131992

OUTLINE

- Front room/map lamp, personal lamp 2nd row and cargo lamp are controlled by the interior room lamp timer control function of the BCM when the lamp switch is in the DOOR position.
- Front outside handle assembly lamps are controlled by door handle lamp control function of BCM.
- Step lamp and foot lamp are controlled by the step lamp control function of the BCM.
- Push-button ignition switch illumination is controlled by the push-button ignition switch illumination control function of BCM.
- Interior room lamps and outside handle lamp are illuminated by welcome light function of Intelligent Key system. Refer to [DLK-33, "WELCOME LIGHT FUNCTION : System Description"](#).

INL

ROOM LAMP TIMER OPERATION

When the interior room lamp switch is in the DOOR position and when all conditions below are met, the BCM begins timer control (maximum 30 seconds) for interior room lamp ON/OFF.

- When the front door LH is unlocked [with Intelligent Key, main power window and door lock/unlock switch or front door lock assembly LH (key cylinder switch)].
- When a door opens → closes.

M

Timer control is cancelled under the following conditions:

- When the front door LH is locked [with Intelligent Key, main power window and door lock/unlock switch or front door lock assembly LH (key cylinder switch)].
- A door is opened (door switch turns ON).
- Ignition switch is turned ON.

N

INTERIOR LAMP BATTERY SAVER CONTROL

O

P

SYSTEM

< SYSTEM DESCRIPTION >

If an interior lamp is left ON and does not turn OFF even when the doors are closed, the BCM turns off power to the interior lamps automatically to save the battery 15 minutes after the ignition switch is turned OFF. The BCM controls power and ground to all interior lamps.

After the battery saver system turns the lamps OFF, the lamps will illuminate again when:

- A signal is received from an Intelligent Key or main power window and door lock/unlock switch or when the front door lock assembly LH (key cylinder switch) is locked or unlocked.
- A door is opened or closed.

OUTSIDE HANDLE LAMP TIMER CONTROL

Outside Handle Lamp Timer Basic Operation

- BCM controls the ground to turn the outside handle lamp ON.
- The outside handle lamp turns ON and OFF by the outside handle lamp timer.
- BCM judges the vehicle condition with the following items: It activates the outside handle lamp timer.
 - Ignition switch status
 - Door switch signal
 - Door lock/unlock signal (remote keyless entry receiver, each door request switch)
 - Driver side door lock status

Outside Handle Lamp ON Operation

BCM activates the outside handle lamp timer in any of the following conditions to turn the outside handle lamp ON for a period of time

- Any door opens
- Any door opens before all doors close
- Ignition switch is turned ON → OFF
- Door unlock signal by remote keyless entry receiver or each door request switch is detected
- Driver side door is locked

NOTE:

The timer is restarted if new condition is input during the timer operating time.

Front Outside Handle Lamp OFF Operation


BCM stops the timer in any of the following conditions to turn the front outside handle assembly lamp OFF.

- The front outside handle assembly lamp timer operating time is expired
- The interior room lamp OFF conditions
- The interior room lamp timer operating time is expired

ILLUMINATION CONTROL SYSTEM

ILLUMINATION CONTROL SYSTEM : System Diagram

INFOID:0000000009131993



ILLUMINATION CONTROL SYSTEM : System Description

INFOID:0000000009131994

The illumination lamps operation is dependent upon the position of the combination switch (lighting and turn signal switch). When the combination switch (lighting and turn signal switch) is placed in the 1st or 2nd position (or if the auto light system is activated) the BCM (body control module) receives input requesting the parking lamps to illuminate. This input is communicated to the IPDM E/R (intelligent power distribution module engine room) via the CAN communication lines. The CPU (central processing unit) of the IPDM E/R controls

SYSTEM

< SYSTEM DESCRIPTION >

the tail lamp relay coil. When energized, this relay directs power to the parking and illumination lamps, which then illuminate. The illumination brightness can be controlled by the illumination control switch.

BATTERY SAVER CONTROL

When the combination switch (lighting and turn signal switch) is in the 1st or 2nd position and the ignition switch is turned from ON or ACC to OFF, the battery saver control feature is activated. Under this condition, the illumination lamps remain illuminated for 15 minutes unless the combination switch (lighting and turn signal switch) position is changed. If the combination switch (lighting and turn signal switch) position is changed, then the illumination lamps are turned off after a 30 second delay. When the combination switch (lighting and turn signal switch) is turned from OFF to 1st or 2nd position (or if auto light system is activated) after illumination lamps have been turned off by the battery saver control, the illumination lamps illuminate again.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009724088

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> • The vehicle specification can be read and saved. • The vehicle specification can be written when replacing BCM.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		x	x	x	x		
Rear window defogger	REAR DEFOGGER			x	x	x		
Warning chime	BUZZER			x	x			
Interior room lamp timer	INT LAMP			x	x	x		
Exterior lamp	HEADLAMP			x	x	x		
Wiper and washer	WIPER			x	x	x		
Turn signal and hazard warning lamps	FLASHER			x	x			
Air conditioner	AIR CONDITIONER			x				
Intelligent Key system	INTELLIGENT KEY		x	x	x	x		
Combination switch	COMB SW			x				
BCM	BCM	x	x			x	x	x
Immobilizer	IMMU		x	x	x			
Interior room lamp battery saver	BATTERY SAVER			x	x			
Back door open	TRUNK			x				
Vehicle security system	THEFT ALM			x	x	x		
RAP system	RETAINED PWR			x				

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

System	Sub System	Direct Diagnostic Mode					
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration
Signal buffer system	SIGNAL BUFFER			x			
TPMS	AIR PRESSURE MONITOR		x	x	x	x	

INT LAMP

INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:0000000009724089

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

DATA MONITOR

Monitor Item [Unit]	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of back door switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
TRNK/HAT MNTR [On/Off]	Indicates condition of trunk room lamp switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.

ACTIVE TEST

Test Item	Description
INT LAMP	This test is able to check interior room lamp operation [On/Off].
STEP LAMP TEST	This test is able to check step lamp operation [On/Off].

WORK SUPPORT

NOTE:

The items listed below are the only applicable Work Support items for this vehicle. If other items are displayed on CONSULT, do not use or change the setting for these other items.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

Support Item	Setting	Description
SCENARIO LIGHTING SETTING	On	NOTE: Do not use this function since interior room lamp control is changed.
	Off*	
SET I/L D-UNLCK INTCON	On	Interior room lamp timer function ON.
	Off*	Interior room lamp timer function OFF.
Fog Lamp Override	On*	Fog lamp override function ON.
	Off	Fog lamp override function OFF.

* : Initial setting

BATTERY SAVER

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:000000009724090

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

DATA MONITOR

Monitor Item [Unit]	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH SW [On/Off]	Indicates condition push-button ignition switch.
UNLK SEN -DR [On/Off]	Indicates condition of door unlock sensor.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of back door switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
TRNK/HAT MNTR [On/Off]	Indicates condition of trunk room lamp switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.

ACTIVE TEST

Test item	Description
BATTERY SAVER	This test is able to check battery saver operation [On/Off].

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM

List of ECU Reference

INFOID:000000009131998

ECU	Reference
BCM	<u>BCS-29, "Reference Value"</u>
	<u>BCS-49, "Fail_Safe"</u>
	<u>BCS-49, "DTC Inspection Priority Chart"</u>
	<u>BCS-51, "DTC Index"</u>

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >


WIRING DIAGRAM

INTERIOR ROOM LAMP CONTROL SYSTEM

Wiring Diagram

INFOID:0000000009131999


INTERIOR ROOM LAMP



ABLWA2186GB

INTERIOR ROOM LAMP CONTROL SYSTEM


< WIRING DIAGRAM >



ABLWA2187GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >




ABLWA2094GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

INTERIOR ROOM LAMP CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	LG	-
5	GR	-



Terminal No.	Color of Wire	Signal Name
6N	W	-

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
21	W	STEP LAMP CONT


Terminal No.	Color of Wire	Signal Name
82	W	RL DOOR SW

Terminal No.	Color of Wire	Signal Name
54	W	PW LIN/COM
59	P	CAN-L
60	L	CAN-H
65	P	DOOR HANDLE LAMP

ABLIA3529GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >




ABLIA4932GB


INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE




Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	G	-
22	R	-

Terminal No.	Color of Wire	Signal Name
1	2	3
2	3	4
3	4	5
4	5	6
5	6	7
6	7	8
7	8	9
8	9	10
9	10	11
10	11	12
11	12	13
12	13	14
13	14	15
14	15	16
15	16	1
16	1	2
17	2	3
18	3	4
19	4	5
20	5	6
21	6	7
22	7	8
23	8	9
24	9	10
25	10	11
26	11	12
27	12	13
28	13	14
29	14	15
30	15	16
31	16	1

Terminal No.	Color of Wire	Signal Name
22	SB	-
23	P	-
29	W	-
30	SB	-
31	W	-



Terminal No.	Color of Wire	Signal Name
1	2	3
5	6	7
6	7	8
9	9	10



Terminal No.	Color of Wire	Signal Name
1	1	FOOT LAMP RH
2	2	BLACK
3	3	-



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	W	-




ABLIA4933GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

Connector No.	M167
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M167
Connector Name	JOINT CONNECTOR M36
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	B	-
19	W	-
20	SB	-
21	P	-
39	W	-

Terminal No.	Color of Wire	Signal Name
28	W	-
29	W	-
30	W	-

Terminal No.	Color of Wire	Signal Name
10G	P	-





Terminal No.	Color of Wire	Signal Name
5G	4G	3G
10G	9G	8G



ABLIA4934GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

<table border="1"> <tr><td>Connector No.</td><td>B8</td></tr> <tr><td>Connector Name</td><td>FRONT DOOR SWITCH LH</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	B8	Connector Name	FRONT DOOR SWITCH LH	Connector Color	WHITE	<table border="1"> <tr><td>Connector No.</td><td>B18</td></tr> <tr><td>Connector Name</td><td>REAR DOOR SWITCH LH</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	B18	Connector Name	REAR DOOR SWITCH LH	Connector Color	WHITE	<table border="1"> <tr><td>Connector No.</td><td>B41</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	B41	Connector Name	WIRE TO WIRE	Connector Color	WHITE																																																																																																																																													
Connector No.	B8																																																																																																																																																																
Connector Name	FRONT DOOR SWITCH LH																																																																																																																																																																
Connector Color	WHITE																																																																																																																																																																
Connector No.	B18																																																																																																																																																																
Connector Name	REAR DOOR SWITCH LH																																																																																																																																																																
Connector Color	WHITE																																																																																																																																																																
Connector No.	B41																																																																																																																																																																
Connector Name	WIRE TO WIRE																																																																																																																																																																
Connector Color	WHITE																																																																																																																																																																
<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>3</td><td>L</td><td>-</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	3	L	-	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>3</td><td>SB</td><td>-</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	3	SB	-	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>9</td><td>V</td><td>-</td></tr> <tr><td>12</td><td>G</td><td>-</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	9	V	-	12	G	-																																																																																																																																										
Terminal No.	Color of Wire	Signal Name																																																																																																																																																															
3	L	-																																																																																																																																																															
Terminal No.	Color of Wire	Signal Name																																																																																																																																																															
3	SB	-																																																																																																																																																															
Terminal No.	Color of Wire	Signal Name																																																																																																																																																															
9	V	-																																																																																																																																																															
12	G	-																																																																																																																																																															
<table border="1"> <tr><td>Connector No.</td><td>B46</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	B46	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1"> <tr><td>Connector No.</td><td>B69</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>GRAY</td></tr> </table> 	Connector No.	B69	Connector Name	WIRE TO WIRE	Connector Color	GRAY	<table border="1"> <tr><td>Connector No.</td><td>B101</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	B101	Connector Name	WIRE TO WIRE	Connector Color	WHITE																																																																																																																																													
Connector No.	B46																																																																																																																																																																
Connector Name	WIRE TO WIRE																																																																																																																																																																
Connector Color	WHITE																																																																																																																																																																
Connector No.	B69																																																																																																																																																																
Connector Name	WIRE TO WIRE																																																																																																																																																																
Connector Color	GRAY																																																																																																																																																																
Connector No.	B101																																																																																																																																																																
Connector Name	WIRE TO WIRE																																																																																																																																																																
Connector Color	WHITE																																																																																																																																																																
<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>2</td><td>3</td></tr> <tr><td>2</td><td>3</td><td>4</td></tr> <tr><td>3</td><td>4</td><td>5</td></tr> <tr><td>4</td><td>5</td><td>6</td></tr> <tr><td>5</td><td>6</td><td>7</td></tr> <tr><td>6</td><td>7</td><td>8</td></tr> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>8</td><td>9</td><td>10</td></tr> <tr><td>9</td><td>10</td><td>11</td></tr> <tr><td>10</td><td>11</td><td>12</td></tr> <tr><td>11</td><td>12</td><td>13</td></tr> <tr><td>12</td><td>13</td><td>14</td></tr> <tr><td>13</td><td>14</td><td>15</td></tr> <tr><td>14</td><td>15</td><td>16</td></tr> <tr><td>15</td><td>16</td><td>17</td></tr> <tr><td>16</td><td>17</td><td>18</td></tr> <tr><td>17</td><td>18</td><td>19</td></tr> <tr><td>18</td><td>19</td><td>20</td></tr> <tr><td>19</td><td>20</td><td>21</td></tr> <tr><td>20</td><td>21</td><td>22</td></tr> <tr><td>21</td><td>22</td><td>23</td></tr> <tr><td>22</td><td>23</td><td>24</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	2	3	2	3	4	3	4	5	4	5	6	5	6	7	6	7	8	7	8	9	8	9	10	9	10	11	10	11	12	11	12	13	12	13	14	13	14	15	14	15	16	15	16	17	16	17	18	17	18	19	18	19	20	19	20	21	20	21	22	21	22	23	22	23	24	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>5A</td><td>4A</td><td>3A</td></tr> <tr><td>4A</td><td>3A</td><td>2A</td></tr> <tr><td>3A</td><td>2A</td><td>1A</td></tr> <tr><td>10A</td><td>9A</td><td>8A</td></tr> <tr><td>9A</td><td>8A</td><td>7A</td></tr> <tr><td>8A</td><td>7A</td><td>6A</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	5A	4A	3A	4A	3A	2A	3A	2A	1A	10A	9A	8A	9A	8A	7A	8A	7A	6A	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>2</td><td>3</td></tr> <tr><td>2</td><td>3</td><td>4</td></tr> <tr><td>3</td><td>4</td><td>5</td></tr> <tr><td>4</td><td>5</td><td>6</td></tr> <tr><td>5</td><td>6</td><td>7</td></tr> <tr><td>6</td><td>7</td><td>8</td></tr> <tr><td>7</td><td>8</td><td>9</td></tr> <tr><td>8</td><td>9</td><td>10</td></tr> <tr><td>9</td><td>10</td><td>11</td></tr> <tr><td>10</td><td>11</td><td>12</td></tr> <tr><td>11</td><td>12</td><td>13</td></tr> <tr><td>12</td><td>13</td><td>14</td></tr> <tr><td>13</td><td>14</td><td>15</td></tr> <tr><td>14</td><td>15</td><td>16</td></tr> <tr><td>15</td><td>16</td><td>17</td></tr> <tr><td>16</td><td>17</td><td>18</td></tr> <tr><td>17</td><td>18</td><td>19</td></tr> <tr><td>18</td><td>19</td><td>20</td></tr> <tr><td>19</td><td>20</td><td>21</td></tr> <tr><td>20</td><td>21</td><td>22</td></tr> <tr><td>21</td><td>22</td><td>23</td></tr> <tr><td>22</td><td>23</td><td>24</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	1	2	3	2	3	4	3	4	5	4	5	6	5	6	7	6	7	8	7	8	9	8	9	10	9	10	11	10	11	12	11	12	13	12	13	14	13	14	15	14	15	16	15	16	17	16	17	18	17	18	19	18	19	20	19	20	21	20	21	22	21	22	23	22	23	24
Terminal No.	Color of Wire	Signal Name																																																																																																																																																															
1	2	3																																																																																																																																																															
2	3	4																																																																																																																																																															
3	4	5																																																																																																																																																															
4	5	6																																																																																																																																																															
5	6	7																																																																																																																																																															
6	7	8																																																																																																																																																															
7	8	9																																																																																																																																																															
8	9	10																																																																																																																																																															
9	10	11																																																																																																																																																															
10	11	12																																																																																																																																																															
11	12	13																																																																																																																																																															
12	13	14																																																																																																																																																															
13	14	15																																																																																																																																																															
14	15	16																																																																																																																																																															
15	16	17																																																																																																																																																															
16	17	18																																																																																																																																																															
17	18	19																																																																																																																																																															
18	19	20																																																																																																																																																															
19	20	21																																																																																																																																																															
20	21	22																																																																																																																																																															
21	22	23																																																																																																																																																															
22	23	24																																																																																																																																																															
Terminal No.	Color of Wire	Signal Name																																																																																																																																																															
5A	4A	3A																																																																																																																																																															
4A	3A	2A																																																																																																																																																															
3A	2A	1A																																																																																																																																																															
10A	9A	8A																																																																																																																																																															
9A	8A	7A																																																																																																																																																															
8A	7A	6A																																																																																																																																																															
Terminal No.	Color of Wire	Signal Name																																																																																																																																																															
1	2	3																																																																																																																																																															
2	3	4																																																																																																																																																															
3	4	5																																																																																																																																																															
4	5	6																																																																																																																																																															
5	6	7																																																																																																																																																															
6	7	8																																																																																																																																																															
7	8	9																																																																																																																																																															
8	9	10																																																																																																																																																															
9	10	11																																																																																																																																																															
10	11	12																																																																																																																																																															
11	12	13																																																																																																																																																															
12	13	14																																																																																																																																																															
13	14	15																																																																																																																																																															
14	15	16																																																																																																																																																															
15	16	17																																																																																																																																																															
16	17	18																																																																																																																																																															
17	18	19																																																																																																																																																															
18	19	20																																																																																																																																																															
19	20	21																																																																																																																																																															
20	21	22																																																																																																																																																															
21	22	23																																																																																																																																																															
22	23	24																																																																																																																																																															
<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>V</td><td>-</td></tr> <tr><td>11</td><td>G</td><td>-</td></tr> <tr><td>23</td><td>GR</td><td>-</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	1	V	-	11	G	-	23	GR	-	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>21</td><td>LG</td><td>-</td></tr> <tr><td>22</td><td>LG</td><td>-</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	21	LG	-	22	LG	-	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>65A</td><td>SB</td><td>-</td></tr> <tr><td>66A</td><td>L</td><td>-</td></tr> </table> 	Terminal No.	Color of Wire	Signal Name	65A	SB	-	66A	L	-																																																																																																																																	
Terminal No.	Color of Wire	Signal Name																																																																																																																																																															
1	V	-																																																																																																																																																															
11	G	-																																																																																																																																																															
23	GR	-																																																																																																																																																															
Terminal No.	Color of Wire	Signal Name																																																																																																																																																															
21	LG	-																																																																																																																																																															
22	LG	-																																																																																																																																																															
Terminal No.	Color of Wire	Signal Name																																																																																																																																																															
65A	SB	-																																																																																																																																																															
66A	L	-																																																																																																																																																															


ABLIA4935GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

Connector No.	B116
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE




Connector No.	B108
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	LG	-

Terminal No.	Color of Wire	Signal Name
12	11	9
11	10	8
10	9	7
9	8	6
8	7	5
7	6	4
6	5	3
5	4	2
4	3	1
13	24	12
12	23	11
11	22	20
20	21	19
19	18	18
18	17	17
17	16	16
16	15	15
15	14	14
14	13	13

Terminal No.	Color of Wire	Signal Name
1	G	-
2	R	-
5	B	-



Connector No.	R101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	2	1
2	3	2
3	4	3
4	5	4
5	6	5
6	7	6
7	8	7
8	9	8
9	10	9
10	11	10
11	12	11
12	13	12
13	14	13
14	15	14
15	16	15
16	17	16
17	18	17
18	19	18
19	20	19
20	21	20
21	22	21
22	23	22
23	24	23



Terminal No.	Color of Wire	Signal Name
1	G	-
2	B	-



Terminal No.	Color of Wire	Signal Name
8	B	-
11	R	-
12	G	-

ABLIA3534GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

Connector No.	R104
Connector Name	CARGO LAMP
Connector Color	WHITE



Connector No.	R103
Connector Name	VANITY LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
2	B	-
3	R	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-

Terminal No.	Color of Wire	Signal Name
2	G	-
3	L	-
4	B	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-

20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1
40	39	38	37	36	35	34	33	32	31	30	29	28	27	26	25	24	23	22	21

Terminal No.	Color of Wire	Signal Name
1	Y	-
19	Y	-
20	LG	-
21	LG	-
39	Y	-

Terminal No.	Color of Wire	Signal Name
7	6	-
16	5	-
15	4	-
14	3	-
13	2	-
12	1	-
11	10	-
10	9	-
9	8	-
8	7	-
7	6	-
6	5	-
5	4	-
4	3	-
3	2	-
2	1	-

Terminal No.	Color of Wire	Signal Name
1	B	-
2	G	-
3	R	-
4	Y	-
5	LG	-


INL M Z P O K M Z P O INL

ABIA4936GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

Connector No.	D11
Connector Name	FRONT STEP LAMP LH
Connector Color	WHITE



Connector No.	D14
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY




Connector No.	D17
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	Y	-
3	B	-
4	SB	-
5	BR	-
6	BR	-

Terminal No.	Color of Wire	Signal Name
4	B	-
5	SB	-
6	BR	-


Terminal No.	Color of Wire	Signal Name
3	Y	-
4	LG	-



Connector No.	D18
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D19
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	Y	-
14	BR	-
15	SB	-

Terminal No.	Color of Wire	Signal Name
12	11	9
13	10	8
14	11	7
15	12	6
16	13	5
17	14	4
18	15	3
19	16	2
20	17	1


ABLIA4937GB

INTERIOR ROOM LAMP CONTROL SYSTEM


< WIRING DIAGRAM >

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL


Connector No.	D51
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D52
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D53
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10	Y	-
11	BR	-
12	SB	-

Terminal No.	Color of Wire	Signal Name
13	Y	-
14	W	-
15	SB	-

Terminal No.	Color of Wire	Signal Name
6	B	-
		-
		-

Connector No.	D56
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE



Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
22	Y	-
23	LG	-
29	Y	-
30	LG	-
31	BR	-

Terminal No.	Color of Wire	Signal Name
8	B	-
		-
		-


P
O
Z
M
K
L
INL

ABLIA4938GB


INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

Connector No.	D110
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	D109
Connector Name	FRONT STEP LAMP RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	B	-
4	BR	-

Terminal No.	Color of Wire	Signal Name
1	LG	-
2	Y	-

Terminal No.	Color of Wire	Signal Name
3	Y	-
4	LG	-



Connector No.	D157
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	BR	-
11	B	GND
16	BR	COM

Terminal No.	Color of Wire	Signal Name
3	B	-
4	BR	-

Terminal No.	Color of Wire	Signal Name
11	B	GND
16	BR	COM


ABLIA4939GB

INTERIOR ROOM LAMP CONTROL SYSTEM

< WIRING DIAGRAM >

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
INL


Connector No.	D507
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D552
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D557
Connector Name	BACK DOOR LOCK ASSEMBLY
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	B	-
10	BR	-
12	P	-

Terminal No.	Color of Wire	Signal Name
6	B	-
10	P	-
12	G	-

Terminal No.	Color of Wire	Signal Name
7	G	-
8	B	-


Hazard Symbol (HS) is present below the terminal table.

Connector No.	D558
Connector Name	DIODE-2
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
3	P	-
4	BR	-

Hazard Symbol (HS) is present below the terminal table.



Terminal No.	Color of Wire	Signal Name
1	G	-
2	BR	-

ABLIA4940GB


ILLUMINATION

< WIRING DIAGRAM >

ILLUMINATION

Wiring Diagram


INFOID:0000000009132000



ABLWA2188GB

ILLUMINATION

< WIRING DIAGRAM >




* : THE CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

ABLWA2189GB

ILLUMINATION

< WIRING DIAGRAM >




ABLWA2190GB

ILLUMINATION

< WIRING DIAGRAM >

ILLUMINATION CONNECTORS

Connector No.	M1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R	—
5	GR	—
24	B	—

Connector No.	M17
Connector Name	PUSH-BUTTON IGNITION
Connector Color	WHITE




Connector No.	M3
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6N	W	—
13N	—	—
8N	—	—


Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Connector No.	M4
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	BG	—
13P	W	—




Terminal No.	Color of Wire	Signal Name
48	R	HIGH SIDE START SW LED
59	P	CAN-L
60	L	CAN-H
75	BG	COMBI SW OUT 5
76	P	COMBI SW OUT 4
77	P	COMBI SW OUT 3
78	W	COMBI SW OUT 2
79	W	COMBI SW OUT 1

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

ILLUMINATION

< WIRING DIAGRAM >



ABLIA4942GB

ILLUMINATION

< WIRING DIAGRAM >

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

Terminal No.	Color of Wire	Signal Name
8SA	L	-
9DA	P	-


Connector No.	M40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-

11A	12A	13A	14A	15A	16A	17A	18A	19A	20A	21A
22A	23A	24A	25A	26A	27A	28A	29A	30A		
31A	32A	33A	34A	35A	36A	37A	38A	39A	40A	41A
42A	43A	44A	45A	46A	47A	48A	49A	50A		
51A	52A	53A	54A	55A	56A	57A	58A	59A	60A	61A
62A	63A	64A	65A	66A	67A	68A	69A	70A		
71A	72A	73A	74A	75A	76A	77A	78A	79A	80A	81A
82A	83A	84A	85A	86A	87A	88A	89A	90A		
91A	92A	93A	94A	95A						
96A	97A	98A	99A	100A						



Terminal No.	Color of Wire	Signal Name
41	R	ILL

Connector No.	M43
Connector Name	JOINT CONNECTOR-M17
Connector Color	WHITE



Connector No.	M41
Connector Name	JOINT CONNECTOR-M18
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

ABIA4943GB

ILLUMINATION

< WIRING DIAGRAM >

Connector No.	M48
Connector Name	HEATED STEERING WHEEL SWITCH
Connector Color	BLUE



Connector No.	M53
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)
Connector Color	YELLOW




Terminal No.	Color of Wire	Signal Name
23	R	-
26	B	-

Terminal No.	Color of Wire	Signal Name
3	R	-
4	B	-

Terminal No.	Color of Wire	Signal Name
1	R	-
2	GR	-

Terminal No.	Color of Wire	Signal Name
1	R	-
2	GR	-




Connector No.	M65
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1R	R	-
23	R	-

Terminal No.	Color of Wire	Signal Name
3	R	-
4	B	-



ABLIA4944GB

ILLUMINATION

< WIRING DIAGRAM >

Connector No.	M84
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M81
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
131	W	BAT BCM FUSE
134	B	GND 2
139	W	BAT POWER F/L
143	B	GND 1

Terminal No.	Color of Wire	Signal Name
107	W	LOW SIDE START SW LED

Connector No.	M80
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
17	L	-
18	P	-



Terminal No.	Color of Wire	Signal Name
3	R	-
4	B	-


Terminal No.	Color of Wire	Signal Name
131	W	A/C AND AV SWITCH ASSEMBLY
134	B	WHITE



Terminal No.	Color of Wire	Signal Name
2	4	HEADLAMP AIMING SWITCH
4	3	WHITE



Connector No.	M88
Connector Name	A/C 120V OUTLET MAIN SWITCH
Connector Color	BLACK



ABLIA4945GB

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

Y

Z

ILLUMINATION

< WIRING DIAGRAM >


<table border="1"> <tr><td>Connector No.</td><td>M126</td></tr> <tr><td>Connector Name</td><td>TWIN SWITCH (WARNING SYSTEM SWITCH)</td></tr> <tr><td>Connector Color</td><td>BLACK</td></tr> </table> 	Connector No.	M126	Connector Name	TWIN SWITCH (WARNING SYSTEM SWITCH)	Connector Color	BLACK	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>R</td><td>-</td></tr> <tr><td>4</td><td>B</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	R	-	4	B	-	<table border="1"> <tr><td>Connector No.</td><td>M149</td></tr> <tr><td>Connector Name</td><td>COMBINATION SWITCH (SPIRAL CABLE)</td></tr> <tr><td>Connector Color</td><td>GRAY</td></tr> </table> 	Connector No.	M149	Connector Name	COMBINATION SWITCH (SPIRAL CABLE)	Connector Color	GRAY	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>19</td><td>Y</td><td>-</td></tr> <tr><td>20</td><td>W</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	19	Y	-	20	W	-
Connector No.	M126																																
Connector Name	TWIN SWITCH (WARNING SYSTEM SWITCH)																																
Connector Color	BLACK																																
Terminal No.	Color of Wire	Signal Name																															
1	R	-																															
4	B	-																															
Connector No.	M149																																
Connector Name	COMBINATION SWITCH (SPIRAL CABLE)																																
Connector Color	GRAY																																
Terminal No.	Color of Wire	Signal Name																															
19	Y	-																															
20	W	-																															
<table border="1"> <tr><td>Connector No.</td><td>M168</td></tr> <tr><td>Connector Name</td><td>WIRE TO WIRE</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	M168	Connector Name	WIRE TO WIRE	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>25</td><td>R</td><td>-</td></tr> <tr><td>26</td><td>B</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	25	R	-	26	B	-	<table border="1"> <tr><td>Connector No.</td><td>M185</td></tr> <tr><td>Connector Name</td><td>AUTOMATIC BACK DOOR MAIN SWITCH</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	M185	Connector Name	AUTOMATIC BACK DOOR MAIN SWITCH	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>25</td><td>R</td><td>-</td></tr> <tr><td>26</td><td>B</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	25	R	-	26	B	-
Connector No.	M168																																
Connector Name	WIRE TO WIRE																																
Connector Color	WHITE																																
Terminal No.	Color of Wire	Signal Name																															
25	R	-																															
26	B	-																															
Connector No.	M185																																
Connector Name	AUTOMATIC BACK DOOR MAIN SWITCH																																
Connector Color	WHITE																																
Terminal No.	Color of Wire	Signal Name																															
25	R	-																															
26	B	-																															
<table border="1"> <tr><td>Connector No.</td><td>M175</td></tr> <tr><td>Connector Name</td><td>JOINT CONNECTOR-M22</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	M175	Connector Name	JOINT CONNECTOR-M22	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>W</td><td>-</td></tr> <tr><td>2</td><td>W</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	W	-	2	W	-	<table border="1"> <tr><td>Connector No.</td><td>M181</td></tr> <tr><td>Connector Name</td><td>JOINT CONNECTOR-M36</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	M181	Connector Name	JOINT CONNECTOR-M36	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>4</td><td>R</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	2	B	-	4	R	-
Connector No.	M175																																
Connector Name	JOINT CONNECTOR-M22																																
Connector Color	WHITE																																
Terminal No.	Color of Wire	Signal Name																															
1	W	-																															
2	W	-																															
Connector No.	M181																																
Connector Name	JOINT CONNECTOR-M36																																
Connector Color	WHITE																																
Terminal No.	Color of Wire	Signal Name																															
2	B	-																															
4	R	-																															
<table border="1"> <tr><td>Connector No.</td><td>M22</td></tr> <tr><td>Connector Name</td><td>JOINT CONNECTOR-M22</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	M22	Connector Name	JOINT CONNECTOR-M22	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>1</td><td>W</td><td>-</td></tr> <tr><td>2</td><td>W</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	1	W	-	2	W	-	<table border="1"> <tr><td>Connector No.</td><td>M36</td></tr> <tr><td>Connector Name</td><td>JOINT CONNECTOR-M36</td></tr> <tr><td>Connector Color</td><td>WHITE</td></tr> </table> 	Connector No.	M36	Connector Name	JOINT CONNECTOR-M36	Connector Color	WHITE	<table border="1"> <tr><td>Terminal No.</td><td>Color of Wire</td><td>Signal Name</td></tr> <tr><td>2</td><td>B</td><td>-</td></tr> <tr><td>4</td><td>R</td><td>-</td></tr> </table>	Terminal No.	Color of Wire	Signal Name	2	B	-	4	R	-
Connector No.	M22																																
Connector Name	JOINT CONNECTOR-M22																																
Connector Color	WHITE																																
Terminal No.	Color of Wire	Signal Name																															
1	W	-																															
2	W	-																															
Connector No.	M36																																
Connector Name	JOINT CONNECTOR-M36																																
Connector Color	WHITE																																
Terminal No.	Color of Wire	Signal Name																															
2	B	-																															
4	R	-																															

ABLIA4946GB


ILLUMINATION

< WIRING DIAGRAM >

Connector No.	M188
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M186
Connector Name	AUTOMATIC BACK DOOR SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
11	B	-
12	R	-
17	B	-
18	R	-
23	B	-
24	R	-

Terminal No.	Color of Wire	Signal Name
11	B	-
12	R	-
17	B	-
18	R	-
23	B	-
24	R	-

Terminal No.	Color of Wire	Signal Name
11	B	-
12	R	-
17	B	-
18	R	-
23	B	-
24	R	-

Connector No.	M193
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM WITHOUT NAVI)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
22	R	-
23	B	-

Terminal No.	Color of Wire	Signal Name
22	R	-
23	B	-


ABLIA4947GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z
INL
NL
M
Z
O
P

ILLUMINATION

< WIRING DIAGRAM >


Connector No.	M203
Connector Name	CLIMATE CONTROLLED SEAT SWITCH (DRIVER SEAT)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	R	-
8	B	-

Terminal No.	Color of Wire	Signal Name
2	R	-
3	B	-


Connector No.	M204
Connector Name	CVT SHIFT SELECTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	R	-
8	B	-

Terminal No.	Color of Wire	Signal Name
2	R	-
3	B	-


Connector No.	M206
Connector Name	CLIMATE CONTROLLED SEAT SWITCH (PASSENGER SEAT)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3	R	-
4	B	-


Terminal No.	Color of Wire	Signal Name
23	R	-
24	B	-

Connector No.	M220
Connector Name	FRONT HEATED SEAT SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-

Terminal No.	Color of Wire	Signal Name
1	R	-
2	B	-




ABLIA4948GB

ILLUMINATION


< WIRING DIAGRAM >

Connector No.	M221
Connector Name	FRONT HEATED SEAT SWITCH RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
3	R	-
4	B	-

Connector No.	M251
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M253
Connector Name	2ND ROW HEATED SEAT SWITCH RH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
5	R	-
6	B	-

Terminal No.	Color of Wire	Signal Name
5	R	-
6	B	-



Terminal No.	Color of Wire	Signal Name
5	R	ILL(+)
6	B	ILL(-)

Connector No.	M257
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
22	R	-
23	B	-

INL M Z O P K M Z O P A B C D E F G H I J


ILLUMINATION

< WIRING DIAGRAM >

Connector No.	E45
Connector Name	JOINT CONNECTOR-E12
Connector Color	BLUE




Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
4	L	-
7	P	-
10	P	-

Terminal No.	Color of Wire	Signal Name
6M	L	-
12	2M	1M
10M	9M	8M
7M	6M	5M


Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-




Terminal No.	Color of Wire	Signal Name
1	L	-
4	L	-
7	P	-



Connector No.	E71
Connector Name	JOINT CONNECTOR-E15
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	P	CAN-L



Terminal No.	Color of Wire	Signal Name
7	B	GND (POWER)
10	L	TAIL LH

Terminal No.	Color of Wire	Signal Name
28	P	CAN-H
29	L	GND (SIGNAL)
41	B	-

ABLIA4950GB

ILLUMINATION

< WIRING DIAGRAM >

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
10G	P	-
35G	P	-
36G	L	-



Terminal No.	Color of Wire	Signal Name
1	P	-
2	P	-



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-



Connector No.	B17
Connector Name	JOINT CONNECTOR-B12
Connector Color	WHITE



Terminal No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE



Terminal No.	B12
Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE



Terminal No.	B16
Connector Name	JOINT CONNECTOR-B11
Connector Color	WHITE



Terminal No.	B12
Connector Name	JOINT CONNECTOR-B10
Connector Color	WHITE



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z


INL

ILLUMINATION


< WIRING DIAGRAM >

Terminal No.	Color of Wire	Signal Name
89A	L	-
90A	P	-

Connector No.	B69
Connector Name	WIRE TO WIRE
Connector Color	GRAY





Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-



Terminal No.	Color of Wire	Signal Name
89A	L	-
90A	P	-



Connector No.	B102
Connector Name	JOINT CONNECTOR-B14
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-

ILLUMINATION

< WIRING DIAGRAM >


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
Q
R
S
T
U
V
W
X
Y
Z

Connector No.	R11
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	W	-
9	B	-
10	B	-

Connector No.	R1
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	W	-
5	B	-
24	B	-

Connector No.	R124
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
18	L	-
19	P	-


Terminal No.	Color of Wire	Signal Name
8	B	-
9	B	-
10	W	-



Connector No.	R106
Connector Name	PERSONAL LAMPS 2ND ROW
Connector Color	WHITE



Connector No.	R105
Connector Name	TELEMATICS SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	B	-
6	B	-
7	W	-

Terminal No.	Color of Wire	Signal Name
12	W	-
13	B	-
14	B	-



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-
3	B	-



Terminal No.	Color of Wire	Signal Name
2	SB	-
4	L	-
5	W	-


Terminal No.	Color of Wire	Signal Name
5	W	ILL
6	B	ILL CONT (GND)
7	W	-

IN


ILLUMINATION

< WIRING DIAGRAM >


Connector No.	D19
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	D3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	R107
Connector Name	FRONT ROOM/MAP LAMP ASSEMBLY
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
22	BR	-
23	B	-

Terminal No.	Color of Wire	Signal Name
25	BR	-
26	B	-

Terminal No.	Color of Wire	Signal Name
22	BR	-
23	B	-

Terminal No.	Color of Wire	Signal Name
22	BR	-
23	B	-



Terminal No.	Color of Wire	Signal Name
8	BR	-
9	B	-

ABLIA4954GB

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000009132001

OVERALL SEQUENCE



A
B
C
D
E
F
G
H
I
J
K
INL
M
N
O
P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

Find out what the customer's concerns are.

>> GO TO 2.

2. SYMPTOM CHECK

Verify the symptom from the customer's information.

>> GO TO 3.

3. BASIC INSPECTION

Check the operation of each part. Check that any concerns occur other than those mentioned in the customer interview.

>> GO TO 4.

4. SELF-DIAGNOSIS WITH CONSULT

Perform the self-diagnosis with CONSULT. Check that any DTC is detected.

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

Perform the trouble diagnosis for the detected DTC. Specify the malfunctioning part.

>> GO TO 9.

6. FAIL-SAFE ACTIVATION CHECK

Determine if the customer's concern is related to fail-safe activation.

Does the fail-safe activate?

YES >> GO TO 7.

NO >> GO TO 8.

7. SYSTEM DIAGNOSIS

Perform the system diagnosis for the system in which the fail-safe activates. Specify the malfunctioning part.

>> GO TO 9.

8. SYMPTOM DIAGNOSIS

Perform the symptom diagnosis, refer to [INL-59, "Symptom Table"](#). Specify the malfunctioning part.

>> GO TO 9.

9. MALFUNCTION PART REPAIR

Repair or replace the malfunctioning part.

>> GO TO 10.

10. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

Perform the self-diagnosis with CONSULT. Verify that no DTCs are detected. Erase all DTCs detected prior to the repair. Verify that DTC is not detected again.

Is any DTC detected?

YES >> GO TO 5.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

NO >> GO TO 11.

11. REPAIR CHECK (OPERATION CHECK)

Check the operation of each part.

Does it operate normally?

YES >> Inspection End.

NO >> GO TO 3.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000009726248

Regarding Wiring Diagram information, refer to [BCS-54, "Wiring Diagram".](#)

1. CHECK FUSE AND FUSIBLE LINK

Check that the following fuse and fusible link are not blown.

Terminal No.	Signal name	Fuse and fusible link No.
139	Fusible link battery power	O (40A)
131	BCM battery fuse	1 (10A)

Is the fuse or fusible link blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M81.
2. Check voltage between BCM connector M81 terminals 131, 139 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M81	131	—	Battery voltage
	139		

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M81 terminals 134, 143 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M81	134	—	Yes
	143		

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

Description

INFOID:0000000009132003

Provides the battery saver output/power supply. Also cuts the power supply when the interior room lamp battery saver is activating.

Component Function Check

INFOID:0000000009132004

1.CHECK BATTERY SAVER OUTPUT/POWER SUPPLY FUNCTION

CONSULT

1. Turn ignition switch ON.
2. Turn each interior room lamp ON:
 - Front room/map lamp assembly
 - Vanity lamps
 - Personal lamp 2nd row
 - Cargo lamp
3. Open the driver door to turn ON the following lamps:
 - Front step lamps
 - Foot lamps
 - Front outside handle assembly lamps
4. Select BATTERY SAVER of BCM (BATTERY SAVER) active test item.
5. While operating the test item, check that each interior room lamp turns ON/OFF.

OFF : Interior room lamp OFF

ON : Interior room lamp ON

Is the inspection result normal?

YES >> Battery saver output/power supply circuit is normal.

NO >> Refer to [INL-49, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000009132005

Regarding Wiring Diagram information, refer to [INL-14, "Wiring Diagram"](#).

1.CHECK BATTERY SAVER OUTPUT/POWER SUPPLY OUTPUT

CONSULT

1. Turn ignition switch ON.
2. Select BATTERY SAVER of BCM (BATTERY SAVER) active test item.
3. While operating the test item, check voltage between BCM connector M81 terminal 129 and ground.

Connector	(+) Terminal	(-)	Test item	Voltage (Approx.)
			BATTERY SAVER	
M81	129	Ground	OFF	0V
			ON	Battery voltage

Is the inspection result normal?

YES >> GO TO 2

NO >> Replace BCM after making sure battery saver output/power supply circuit is not shorted to voltage. Refer to [BCS-79, "Removal and Installation"](#).

2.CHECK BATTERY SAVER OUTPUT/POWER SUPPLY OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the following connectors:
 - BCM M81
 - Front step lamp LH D11

A

B

C

D

E

F

G

H

I

J

K

L

M

N

O

P

BATTERY SAVER OUTPUT/POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

- Front step lamp RH D109
 - Front outside handle assembly LH D15
 - Front outside handle assembly RH D115
 - Foot lamp LH M99
 - Foot lamp RH M100
 - Front room/map lamp assembly R107
 - Vanity lamp LH R103
 - Vanity lamp RH R102
 - Cargo lamp R104
 - Personal lamp 2nd row R106
3. Check continuity between BCM connector M81 terminal 129 and interior room lamp connector terminal in question.

BCM		Each interior room lamp		Continuity
Connector	Terminal	Connector	Terminal	
M81	129	Front step lamp LH	D11	1
		Front step lamp RH	D109	1
		Front outside handle assembly LH	D15	3
		Front outside handle assembly RH	D115	3
		Foot lamp LH	M99	1
		Foot lamp RH	M100	1
		Front room/map lamp assembly	R107	8
		Vanity lamp LH	R103	1
		Vanity lamp RH	R102	1
		Cargo lamp	R104	2
		Personal lamp 2nd row	R106	2

Is the inspection result normal?

YES >> GO TO 3

NO >> Repair or replace harness or connectors.

3.CHECK BATTERY SAVER OUTPUT/POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM connector M81 terminal 129 and ground.

Connector	Terminal	—	Continuity
M81	129	Ground	No

Is the inspection result normal?

YES >> Check that each interior room lamp has no internal short circuit.

NO >> Repair or replace harness or connectors.

INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

INTERIOR ROOM LAMP CONTROL CIRCUIT

Description

INFOID:0000000009132006

Controls the room lamp control circuit (ground side) to turn the room lamps ON and OFF.

Component Function Check

INFOID:0000000009132007

CAUTION:

Before performing the diagnosis, check that the following are normal.

- Battery saver output/power supply
- Front room/map lamp bulb
- Personal lamp bulb
- Cargo lamp bulb

1.CHECK INTERIOR ROOM LAMP CONTROL FUNCTION

①CONSULT

1. Set the front room/map lamp switch, personal lamp switch and cargo lamp switch to DOOR.
2. Turn ignition switch ON.
3. Select INT LAMP of BCM (INT LAMP) active test item.
4. While operating the test item, check that each interior room lamp turn ON/OFF.

On : Interior room lamp On

Off : Interior room lamp Off

Does the interior room lamp turn ON/OFF?

YES >> Interior room lamp control circuit is normal.

NO >> Refer to [INL-51, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000009132008

Regarding Wiring Diagram information, refer to [INL-14, "Wiring Diagram"](#).

1.CHECK INTERIOR ROOM LAMP CONTROL OUTPUT

②CONSULT

1. Turn ignition switch ON.
2. Select INT LAMP of BCM (INT LAMP) active test item.
3. While operating the test item, check voltage between BCM harness connector M81 terminal 136 and ground.

INL

BCM		Ground	Test item		Voltage (Approx.)
Connector	Terminal		INT LAMP	On	
M81	136			Off	
					Battery voltage

Is the inspection result normal?

YES >> Interior room lamp control circuit is operating normally.

Fixed ON>>GO TO 3.

Fixed OFF>>GO TO 2.

2.CHECK INTERIOR ROOM LAMP CONTROL OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector M81, front room/map lamp harness connector R107 and cargo lamp harness connector R104.
3. Check continuity between BCM harness connector M81 terminal 136 and front room/map lamp assembly harness connector R107 terminal 7 and cargo lamp harness connector R104 terminal 3.

INTERIOR ROOM LAMP CONTROL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BCM		Foot lamp			Continuity
Connector	Terminal	Connector	Terminal		
M81	136	Front room/map lamp	R107	7	Yes
		Cargo lamp	R104	3	

4. Reconnect the front room/map lamp assembly harness connector.
5. Check continuity between BCM harness connector M81 terminal 136 and personal lamps 2nd row harness connector R106 terminal 3.

BCM		Personal lamp		Continuity
Connector	Terminal	Connector	Terminal	
M81	136	R106	3	Yes

Is the inspection result normal?

YES >> Check interior room lamps for an open. If NG, replace lamp in question. Refer to [INL-60, "Removal and Installation"](#) or [INL-68, "Removal and Installation"](#) or [INL-67, "Removal and Installation"](#). If OK, replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

3.CHECK INTERIOR ROOM LAMP CONTROL SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM harness connector M81 and front room/map lamp harness connector R107 and cargo lamp harness connector R104.
3. Check continuity between BCM harness connector M81 terminal 136 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M81	136		No

Is the inspection result normal?

YES >> Check interior room lamps for a short circuit. If NG, replace lamp in question. Refer to [INL-60, "Removal and Installation"](#) or [INL-68, "Removal and Installation"](#) or [INL-67, "Removal and Installation"](#). If OK, replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

STEP LAMP CIRCUIT

Description

INFOID:0000000009132009

Controls the step lamp control circuit (ground side) to turn the step lamps and foot lamps ON and OFF.

Component Function Check

INFOID:0000000009132010

CAUTION:

Before performing the diagnosis, check that the following is normal.

- Battery saver output/power supply
- Front step lamp bulb
- Foot lamp bulb

1.CHECK STEP LAMP OPERATION

(B)CONSULT

1. Turn ignition switch ON.
2. Select STEP LAMP TEST of BCM (INT LAMP) active test item.
3. While operating the test items, check that front step lamp and foot lamp turns ON/OFF.

On : Step lamp and foot lamp ON

Off : Step lamp and foot lamp OFF

Is the inspection result normal?

YES >> Step lamp circuit is normal.

NO >> Refer to [INL-53, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000009132011

Regarding Wiring Diagram information, refer to [INL-14, "Wiring Diagram"](#).

1.CHECK STEP LAMP OUTPUT

(B)CONSULT

1. Turn ignition switch ON.
2. Select STEP LAMP TEST of BCM (INT LAMP) active test item.
3. While operating the test item, check voltage between BCM harness connector M18 terminal 21 and ground.

BCM		Ground	STEP LAMP TEST	Voltage (Approx.)
Connector	Terminal			
M18	21		On	0V
			Off	Battery voltage

Is the inspection result normal?

YES >> Step lamp control circuit is operating normally.

Fixed ON>>GO TO 3

Fixed OFF>>GO TO 2

2.CHECK STEP LAMP OPEN CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the following harness connectors:
 - BCM M18
 - Front step lamp LH D11
 - Front step lamp RH D109
 - Foot lamp LH M99
 - Foot lamp RH M100
3. Check continuity between BCM harness connector M18 terminal 21 and the following lamp harness connector terminal.

STEP LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BCM		Step lamp			Continuity
Connector	Terminal	Connector		Terminal	
M18	21	Front step lamp LH	D11	2	Yes
		Front step lamp RH	D109		
		Foot lamp LH	M99		
		Foot lamp RH	M100		

Is the inspection result normal?

YES >> Check front step lamp or foot lamp for an open. If NG, replace lamp in question. Refer to [INL-64, "DRIVER SIDE : Removal and Installation"](#) or [INL-65, "PASSENGER SIDE : Bulb Replacement"](#) or [INL-66, "Removal and Installation"](#). If OK, replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

3.CHECK STEP LAMP SHORT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect the following harness connectors:
 - BCM M18
 - Front step lamp LH D11
 - Front step lamp RH D109
 - Foot lamp LH M99
 - Foot lamp RH M100
3. Check continuity between BCM harness connector M18 terminal 21 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M18	21		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

OUTSIDE HANDLE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

OUTSIDE HANDLE LAMP CIRCUIT

Description

INFOID:0000000009132012

Controls the outside door handle lamp circuit (ground side) to turn the outside door handle lamps ON and OFF.

Component Function Check

INFOID:0000000009132013

1.CHECK OUTSIDE DOOR HANDLE LAMP OPERATION

①CONSULT

1. Turn the ignition switch ON.
2. Select DOOR HANDLE LAMP TEST of BCM (INTELLIGENT KEY) active test item.
3. While operating the test item, check that the outside door handle lamp turn ON/OFF.

On : Outside door handle lamp ON

Off : Outside door handle lamp OFF

Is the inspection results normal?

YES >> Outside door handle lamp circuit is normal.

NO >> Refer to [INL-55. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000009132014

Regarding Wiring Diagram information, refer to [INL-14. "Wiring Diagram"](#).

CAUTION:

Before performing the diagnosis, check that the following is normal:

- Battery saver output/power supply

1.CHECK OUTSIDE HANDLE LAMP OUTPUT

1. Turn ignition switch OFF.
2. Open driver's door.
3. Check voltage between BCM harness connector M19 terminal 65 and ground.

BCM		Ground	Condition		Voltage (Approx.)
Connector	Terminal		Any door	Open	
M19	65			Closed	
					Battery voltage

Is the inspection result normal?

YES >> Front outside handle assembly control circuit is operating normally.

Fixed ON>>GO TO 3

Fixed OFF>>GO TO 2

2.CHECK OUTSIDE HANDLE LAMP OPEN CIRCUIT

1. Disconnect BCM harness connector and front outside handle assembly LH/RH harness connectors.
2. Check continuity between BCM harness connector and front outside handle assembly harness connector.

BCM		Front Outside Handle Assembly			Continuity
Connector	Terminal	Connector		Terminal	
M19	65	LH	D15	4	
		RH	D115	Yes	

Is the inspection result normal?

YES >> Replace front outside handle lamp. Refer to [DLK-296. "OUTSIDE HANDLE : Removal and Installation"](#).

NO >> Repair or replace harness or connector.

OUTSIDE HANDLE LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK OUTSIDE HANDLE LAMP SHORT CIRCUIT

1. Disconnect BCM harness connector and front outside handle assembly LH/RH harness connectors.
2. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M19	65		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation".](#)

NO >> Repair or replace harness or connector.

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

Description

INFOID:0000000009132015

Provides the power supply and the ground to control the push-button ignition switch illumination.

Component Function Check

INFOID:0000000009132016

1.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

CONSULT

1. Turn the ignition switch ON.
2. Select ENGINE SW ILLUMI of BCM (INTELLIGENT KEY) active test item.
3. With operating the test items, check that the push-button ignition switch illumination turns ON/OFF.

On : Push-button ignition switch illumination ON

Off : Push-button ignition switch illumination OFF

Does the push-button ignition switch illumination turn ON/OFF?

YES >> Push-button ignition switch illumination circuit is normal.

NO >> Refer to [INL-57, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:0000000009132017

Regarding Wiring Diagram information, refer to [INL-28, "Wiring Diagram"](#).

1.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION OPERATION

CONSULT

1. Turn the ignition switch ON.
2. Select ENGINE SW ILLUMI of BCM (INTELLIGENT KEY) active test item.
3. While operating the test item, check voltage between push-button ignition switch connector M17 terminal 5 and ground.

Terminals		Test item	Voltage (Approx.)
(+)	(-)		
Push-button ignition switch		ENGINE SW ILLUMI	INL
Connector	Terminal		
M17	5		
		ON	5 V
		OFF	0 V

Is the inspection result normal?

YES >> GO TO 4

NO >> GO TO 2

2.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY OPEN CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector M19 and the push-button ignition switch harness connector M17.
3. Check continuity between BCM harness connector M19 terminal 48 and the push-button ignition switch harness connector M17 terminal 5.

BCM		Push-button ignition switch		Continuity
Connector	Terminal	Connector	Terminal	
M19	48	M17	5	Yes

Is the inspection result normal?

YES >> GO TO 3

PUSH-BUTTON IGNITION SWITCH ILLUMINATION CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness or connectors.

3.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION POWER SUPPLY SHORT CIRCUIT

Check continuity between BCM harness connector M19 terminal 48 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M19	48		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

4.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect push-button ignition switch harness connector M17.
3. Check continuity between push-button ignition switch harness connector M17 terminal 6 and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M17	6		Yes

Is the inspection result normal?

YES >> Replace push-button ignition switch. Refer to [SEC-153, "Removal and Installation"](#).

NO >> GO TO 5

5.CHECK PUSH-BUTTON IGNITION SWITCH ILLUMINATION GROUND OPEN CIRCUIT

1. Disconnect BCM harness connector M80 and push-button ignition switch harness connector M17.
2. Check continuity between BCM harness connector M80 terminal 107 and push-button ignition switch harness connector M17 terminal 6.

Push-button ignition switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M17	6	M80	107	Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-79, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

INTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

INTERIOR LIGHTING SYSTEM SYMPTOMS

Symptom Table

INFOID:000000009132018

CAUTION:
Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom	Possible cause	Inspection item
All the following lamps do not turn ON: <ul style="list-style-type: none">• Front room/map lamp• Personal lamp 2nd row• Foot lamp LH/RH• Step lamp LH/RH• Cargo lamp• Vanity lamp LH/RH• Front outside handle assembly LH/RH	<ul style="list-style-type: none">• Harness between BCM and each interior room lamp• BCM	Battery saver output/power supply circuit Refer to INL-49 .
<ul style="list-style-type: none">• Interior room lamp does not turn ON even though the door is open. (It turns ON when turning the interior room lamp ON.)• Interior room lamp does not turn OFF even though the door is closed.	<ul style="list-style-type: none">• Harness between BCM and each door switch• Harness between BCM and each interior room lamp• BCM	Door switch circuit Refer to DLK-170 . Interior room lamp control circuit Refer to INL-51 .
Interior room lamp timer does not activate. (It turns ON/ OFF when the door opens/closes.)	—	Check the interior room lamp setting. Refer to INL-11 .
<ul style="list-style-type: none">• Front outside handle assembly lamp does not turn ON even though the door is open.• Front outside handle assembly lamp does not turn OFF even though the door is closed.	<ul style="list-style-type: none">• Harness between BCM and each door switch• Harness between BCM and Front outside handle assembly lamp.• BCM	Door switch circuit Refer to DLK-170 . Front outside handle assembly lamp circuit Refer to INL-55 .
<ul style="list-style-type: none">• Step lamps (ALL) do not turn ON.• Step lamps (ALL) do not turn OFF.	<ul style="list-style-type: none">• Harness between BCM and each step lamp• BCM	Door switch circuit Refer to DLK-170 . Step lamp circuit Refer to INL-53 .
Push-button ignition switch illumination does not illuminate.	<ul style="list-style-type: none">• Harness between BCM and push-button ignition switch• BCM	Push-button ignition switch illumination circuit Refer to INL-57 .
Interior room lamp battery saver does not activate.	BCM	Replace BCM. Refer to BCS-79 .

FRONT ROOM/MAP LAMP


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

FRONT ROOM/MAP LAMP

Exploded View

INFOID:0000000009132019



1. Front room/map lamp assembly

2. Bulb

3. Lens

(○) Pawl

Removal and Installation

INFOID:0000000009132020

CAUTION:

Do not attempt to separate the front room/map lamp assembly from the headlining prior to removing headlining, or damage to the components may occur.

REMOVAL


1. Remove the headlining. Refer to [INT-27, "Removal and Installation"](#).
2. Remove the two bracket screws, then remove the front room/map lamp assembly bracket (1) from front room/map assembly (3) and position aside.
3. Disconnect the harness connectors from front room/map lamp assembly (3).
4. Release the nine back plate pawls (A) using a suitable tool and remove the front room/map lamp assembly (3).

(○) Pawl

CAUTION:

When removing, support front room/map lamp assembly (3) by hand so it does not fall out and get damaged during the removal.

5. Remove the front room/map lamp back plate (2) from the headlining.



INSTALLATION

FRONT ROOM/MAP LAMP

< REMOVAL AND INSTALLATION >

Installation is in the reverse order of removal.

Bulb or Lens Replacement

INFOID:000000009132021

WARNING:

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.

1. Insert a suitable tool into the gap between the lens and the front room/map lamp assembly, then gently release the lens pawls and remove the lens.
2. Push the bulb inward slightly and twist it counterclockwise to remove from the front room/map lamp assembly.
3. Push the bulb in and twist clockwise to install.
4. Install the front room/map lamp lens.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P


VANITY LAMP

< REMOVAL AND INSTALLATION >

VANITY LAMP

Exploded View

INFOID:0000000009132022



1. Lens

2. Bulb

Pawl

ALLIA1083ZZ

Removal and Installation

INFOID:0000000009132023

CAUTION:

Do not attempt to separate the vanity lamp from the sun visor or damage to the components may occur.

The vanity lamp is replaced as part of the sun visor. Refer to [INT-27, "Removal and Installation"](#).

Bulb or Lens Replacement

INFOID:0000000009132024

WARNING:

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.
- Do not attempt to separate the vanity lamp from the sun visor or damage to the components may occur.

1. Insert a suitable tool into the gap between the lens and vanity lamp, then gently release the lens pawls and remove the lens.
2. Grasp the bulb and pull straight out of the vanity lamp to remove.
3. Install vanity lamp bulb to vanity lamp.
4. Install the vanity lamp lens.


GLOVE BOX LAMP

< REMOVAL AND INSTALLATION >

GLOVE BOX LAMP

Exploded View

INFOID:0000000009132025



ALLIA1084ZZ

1. Glove box assembly

2. Bulb

3. Bulb socket

Bulb Replacement

INFOID:0000000009132026

WARNING:

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

CAUTION:

- **Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.**
- **Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.**

1. Remove glove box assembly. Refer to [IP-26, "Removal and Installation"](#).
2. Rotate the bulb socket counterclockwise and remove from glove box assembly.
3. Grasp the bulb and pull straight out of the bulb socket to remove.
4. Install glove box lamp bulb to bulb socket.
5. Insert bulb socket into glove box assembly and rotate clockwise to lock in position.
6. Install glove box assembly. Refer to [IP-26, "Removal and Installation"](#).

INL

M

N

O

P

FOOT LAMP


< REMOVAL AND INSTALLATION >

FOOT LAMP

DRIVER SIDE

DRIVER SIDE : Exploded View

INFOID:000000009132027



AWLIA1975ZZ

- 1. Bulb socket
- 2. Instrument lower panel LH
- 3. Foot lamp housing
- 4. Bulb

DRIVER SIDE : Removal and Installation

INFOID:000000009132028

The foot lamp housing is replaced as part of the instrument lower panel LH. Refer to [IP-25, "Removal and Installation"](#).

DRIVER SIDE : Bulb Replacement

INFOID:000000009132029

WARNING:

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.

1. Remove instrument lower panel LH. Refer to [IP-25, "Removal and Installation"](#).
2. Rotate the bulb socket counterclockwise and remove from foot lamp housing.
3. Grasp the bulb and pull straight out of the bulb socket to remove.
4. Install foot lamp bulb to bulb socket.
5. Insert bulb socket into foot lamp housing and rotate clockwise to lock in position.
6. Install the instrument lower panel LH. Refer to [IP-25, "Removal and Installation"](#).


PASSENGER SIDE

FOOT LAMP

< REMOVAL AND INSTALLATION >

PASSENGER SIDE : Exploded View

INFOID:000000009132030



1. Bulb
Front
2. Bulb socket
3. Instrument panel substrate

PASSENGER SIDE : Bulb Replacement

INFOID:000000009132031

WARNING:

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.

1. Reach under instrument panel on RH side, locate foot lamp socket, rotate the bulb socket and remove from instrument panel substrate.
2. Grasp the bulb and pull straight out of the bulb socket to remove.
3. Install foot lamp bulb to bulb socket.
4. Insert bulb socket into instrument panel substrate and rotate to lock in position.

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P


STEP LAMP

< REMOVAL AND INSTALLATION >

STEP LAMP

Exploded View

INFOID:0000000009132032



ALLIA1087ZZ

1. Step lamp harness connector
2. Step lamp

3. Bulb

Removal and Installation

INFOID:0000000009132033

REMOVAL

1. Insert a suitable tool into the gap between the step lamp and front door finisher and gently release the pawls and step lamp.
2. Disconnect the harness connector from the step lamp and remove.

INSTALLATION

Installation is in the reverse order of removal.

Bulb or Lens Replacement

INFOID:0000000009132034

WARNING:

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.

1. Remove the step lamp. Refer to [INL-66, "Removal and Installation"](#).
2. Grasp the bulb and pull straight out from the step lamp to remove.
3. Install the step lamp bulb to step lamp.
4. Install the step lamp. Refer to [INL-66, "Removal and Installation"](#)


PERSONAL LAMP

< REMOVAL AND INSTALLATION >

PERSONAL LAMP

Exploded View

INFOID:0000000009132035



1. Personal lamp

2. Bulb

3. Lens

Pawl


A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

Removal and Installation

INFOID:0000000009132036

REMOVAL

1. Remove the headlining. Refer to [INT-27, "Removal and Installation"](#)
2. Insert a suitable tool into the gap between the headlining and personal lamp (1), release personal lamp pawls and remove.
 Pawl



INL

INSTALLATION

Installation is in the reverse order of removal.

Bulb or Lens Replacement

INFOID:0000000009132037

WARNING:

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
 - Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.
 - Do not attempt to separate the personal lamp from the headlining or damage may occur.
1. Insert a suitable tool into the gap between the lens and personal lamp, then gently release the lens pawls and remove the lens.
 2. Grasp the bulb and pull straight out from its socket to remove.
 3. Install personal lamp bulb to personal lamp.
 4. Install the personal lamp lens.

M
N
O
P


CARGO LAMP

< REMOVAL AND INSTALLATION >

CARGO LAMP

Exploded View

INFOID:0000000009132038



- | | | |
|---|---|----------|
| 1. Cargo lamp | 2. Bulb | 3. Lens |
| A. Pawls to release first for lens re-
moval | B. Pawl to install first for lens in-
stallation | (○) Pawl |
| [] Metal clip | | |

Removal and Installation

INFOID:0000000009132039

REMOVAL

1. Insert a suitable tool into the gap between the headlining and cargo lamp and gently release the metal clips and the cargo lamp.
2. Disconnect the harness connector from cargo lamp and remove.

INSTALLATION

Installation is in the reverse order of removal.

Bulb or Lens Replacement

INFOID:0000000009132040

WARNING:

Do not touch the glass surface of a bulb while it is lit or right after being turned OFF to prevent burns.

CAUTION:

- Do not touch the glass of bulb directly by hand. Keep grease and other oily substances away from bulb surface.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture, smoke, etc. may affect the performance of lamp.
- Release and insert pawl as indicated in exploded view or damage may occur.

1. Beginning at the switch end, insert a suitable tool into the gap between the lens and cargo lamp, then gently release the lens pawls and remove the lens.
2. Push the tab to release one bulb end, then grasp the bulb and pull out the second end from its socket to remove.
3. Install cargo lamp bulb to cargo lamp.
4. Insert pawl at the end opposite the switch first, then insert the remaining two pawls to lock the lens in position.

ILLUMINATION CONTROL SWITCH

< REMOVAL AND INSTALLATION >

ILLUMINATION CONTROL SWITCH

Removal and Installation

INFOID:0000000009132041

The illumination control switch is serviced as part of the meter control switch. Refer to [MWI-96, "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

INL

M

N

O

P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

Bulb Specifications

INFOID:000000009132042

Item	Wattage (W)*
Front room/map lamp	8
Push-button ignition switch illumination	—
Vanity lamp	2
Glove box lamp	8
Foot lamp	3.4
Step lamp	3.4
Personal lamp	8
Cargo lamp	8

*: Always check with the Parts Department for the latest parts information.