

SECTION **BRC**

BRAKE CONTROL SYSTEM

CONTENTS

| | | | |
|--|-----------|---|-----------|
| VDC/TCS/ABS | | | |
| PRECAUTION | 6 | TCS FUNCTION | 27 |
| PRECAUTIONS | 6 | TCS FUNCTION : System Diagram | 27 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" | 6 | TCS FUNCTION : System Description | 28 |
| Precaution for Brake System | 6 | ABS FUNCTION | 28 |
| Precaution for Brake Control System | 7 | ABS FUNCTION : System Diagram | 29 |
| Precaution for Harness Repair | 7 | ABS FUNCTION : System Description | 29 |
| PREPARATION | 8 | EBD FUNCTION | 30 |
| PREPARATION | 8 | EBD FUNCTION : System Diagram | 30 |
| Special Service Tool | 8 | EBD FUNCTION : System Description | 30 |
| Commercial Service Tools | 8 | HILL START ASSIST FUNCTION | 31 |
| SYSTEM DESCRIPTION | 9 | Hill start assist FUNCTION : System Diagram | 32 |
| COMPONENT PARTS | 9 | Hill start assist FUNCTION : System Description | 32 |
| Component Parts Location | 9 | ACTIVE STABILITY ASSIST | 33 |
| Component Description | 10 | ACTIVE STABILITY ASSIST : System Diagram | 33 |
| ABS Actuator and Electric Unit (Control Unit) | 11 | ACTIVE STABILITY ASSIST : System Description | 33 |
| Wheel Sensor and Sensor Rotor | 11 |33 | |
| Stop Lamp Switch | 12 | ACTIVE STABILITY ASSIST : Active Trace Con- trol Function | 34 |
| Steering Angle Sensor | 12 | ACTIVE STABILITY ASSIST : Brake Force Distri- bution Function | 36 |
| Brake Fluid Level Switch | 12 | DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)] | 37 |
| Vacuum Sensor | 12 | CONSULT Function | 37 |
| Parking Brake Switch | 12 | ECU DIAGNOSIS INFORMATION | 42 |
| ADAS Control Unit | 12 | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) | 42 |
| VDC OFF Switch | 12 | Reference Value | 42 |
| SYSTEM | 13 | Fail-Safe | 44 |
| System Diagram | 13 | DTC Inspection Priority Chart | 46 |
| System Description | 13 | DTC Index | 47 |
| Fail-Safe | 21 | ADAS CONTROL UNIT | 49 |
| VDC FUNCTION | 24 | Reference Value | 49 |
| VDC FUNCTION : System Diagram | 24 | Fail-safe (ADAS Control Unit) | 55 |
| VDC FUNCTION : System Description | 25 | DTC Inspection Priority Chart | 56 |

| | | | |
|--|------------|--|------------|
| DTC Index | 57 | C1120, C1122, C1124, C1126 ABS IN VALVE SYSTEM | 118 |
| WIRING DIAGRAM | 60 | DTC Description | 118 |
| BRAKE CONTROL SYSTEM | 60 | Diagnosis Procedure | 118 |
| Wiring Diagram | 60 | C1121, C1123, C1125, C1127 ABS OUT VALVE SYSTEM | 120 |
| BASIC INSPECTION | 78 | DTC Description | 120 |
| DIAGNOSIS AND REPAIR WORK FLOW | 78 | Diagnosis Procedure | 120 |
| Work Flow | 78 | C1130 ENGINE SIGNAL | 122 |
| Diagnostic Work Sheet | 79 | DTC Description | 122 |
| ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) | 81 | Diagnosis Procedure | 122 |
| Description | 81 | C1140 ACTUATOR RELAY SYSTEM | 124 |
| Work Procedure | 81 | DTC Description | 124 |
| ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION | 82 | Diagnosis Procedure | 124 |
| Description | 82 | C1142 PRESS SENSOR | 126 |
| Work Procedure | 82 | DTC Description | 126 |
| CALIBRATION OF DECEL G SENSOR | 84 | Diagnosis Procedure | 126 |
| Description | 84 | C1143 STEERING ANGLE SENSOR | 129 |
| Work Procedure | 84 | DTC Description | 129 |
| DTC/CIRCUIT DIAGNOSIS | 86 | Diagnosis Procedure | 129 |
| C1101, C1102, C1103, C1104 WHEEL SENSOR | 86 | C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT | 133 |
| DTC Description | 86 | DTC Description | 133 |
| Diagnosis Procedure | 87 | Diagnosis Procedure | 133 |
| C1105, C1106, C1107, C1108 WHEEL SENSOR | 91 | C1155 BRAKE FLUID LEVEL SWITCH | 135 |
| DTC Description | 91 | DTC Description | 135 |
| Diagnosis Procedure | 92 | Diagnosis Procedure | 135 |
| C1109 POWER AND GROUND SYSTEM | 98 | Component Inspection | 138 |
| DTC Description | 98 | C1160 INCOMPLETE DECEL G SENSOR CALIBRATION | 139 |
| Diagnosis Procedure | 98 | DTC Description | 139 |
| C1111 ABS MOTOR, MOTOR RELAY SYSTEM | 100 | Diagnosis Procedure | 139 |
| DTC Description | 100 | C1164, C1165 CV SYSTEM | 141 |
| Diagnosis Procedure | 100 | DTC Description | 141 |
| C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR | 103 | Diagnosis Procedure | 141 |
| DTC Description | 103 | C1170 VARIANT CODING | 143 |
| Diagnosis Procedure | 104 | DTC Description | 143 |
| C1115 WHEEL SENSOR | 105 | Diagnosis Procedure | 143 |
| DTC Description | 105 | C1197 VACUUM SENSOR | 144 |
| Diagnosis Procedure | 105 | DTC Description | 144 |
| C1116 STOP LAMP SWITCH | 112 | Diagnosis Procedure | 144 |
| DTC Description | 112 | C1198 VACUUM SENSOR | 147 |
| Diagnosis Procedure | 113 | DTC Description | 147 |
| Component Inspection | 117 | Diagnosis Procedure | 147 |
| | | C1199 BRAKE BOOSTER | 149 |
| | | DTC Description | 149 |
| | | Diagnosis Procedure | 149 |
| | | C119A VACUUM SENSOR | 152 |

| | | | | |
|--|------------|--|------------|---|
| DTC Description | 152 | BRAKE PEDAL VIBRATION OR OPERATION SOUND OCCURS | 172 | A |
| Diagnosis Procedure | 152 | Description | 172 | |
| U1000 CAN COMM CIRCUIT | 155 | Diagnosis Procedure | 172 | B |
| DTC Description | 155 | VEHICLE JERKS DURING VDC/TCS/ABS CONTROL | 173 | C |
| Diagnosis Procedure | 155 | Description | 173 | |
| U0424 HVAC CAN CIRCUIT 1 | 156 | Diagnosis Procedure | 173 | D |
| Description | 156 | NORMAL OPERATING CONDITION | 174 | |
| DTC Logic | 156 | Description | 174 | D |
| Diagnosis Procedure | 156 | UNIT REMOVAL AND INSTALLATION ... | 175 | E |
| POWER SUPPLY AND GROUND CIRCUIT ... | 157 | WHEEL SENSOR | 175 | |
| Diagnosis Procedure | 157 | Exploded View - Front Wheel Sensor | 175 | |
| PARKING BRAKE SWITCH | 160 | Removal and Installation - Front Wheel Sensor ... | 175 | |
| Component Function Check | 160 | Exploded View - Rear Wheel Sensor | 176 | |
| Diagnosis Procedure | 160 | Removal and Installation - Rear Wheel Sensor | 177 | |
| Component Inspection | 160 | SENSOR ROTOR | 179 | |
| VDC OFF SWITCH | 161 | Removal and Installation - Front Sensor Rotor | 179 | G |
| Component Function Check | 161 | Removal and Installation - Rear Sensor Rotor | 179 | |
| Diagnosis Procedure | 161 | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) | 180 | H |
| Component Inspection | 162 | Exploded View | 180 | |
| ABS WARNING LAMP | 163 | Removal and Installation | 180 | I |
| Component Function Check | 163 | VDC OFF SWITCH | 182 | |
| Diagnosis Procedure | 163 | Removal and Installation | 182 | J |
| BRAKE WARNING LAMP | 164 | STEERING ANGLE SENSOR | 183 | |
| Component Function Check | 164 | Removal and Installation | 183 | K |
| Diagnosis Procedure | 164 | FORWARD EMERGENCY BRAKING PRECAUTION | 184 | L |
| VDC OFF INDICATOR LAMP | 165 | PRECAUTIONS | 184 | |
| Component Function Check | 165 | Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 184 | M |
| Diagnosis Procedure | 165 | Precaution for FEB System Service | 184 | |
| SLIP INDICATOR LAMP | 166 | Precaution for Harness Repair | 185 | N |
| Component Function Check | 166 | SYSTEM DESCRIPTION | 186 | |
| Diagnosis Procedure | 166 | COMPONENT PARTS | 186 | O |
| SYMPTOM DIAGNOSIS | 167 | Component Parts Location | 186 | |
| VDC/TCS/ABS | 167 | Component Description | 187 | P |
| Symptom Table | 167 | ADAS Control Unit | 187 | |
| EXCESSIVE OPERATION FREQUENCY | 168 | ICC Sensor | 188 | |
| Description | 168 | Lane Camera Unit | 188 | |
| Diagnosis Procedure | 168 | Brake Pedal Position Switch / Stop Lamp Switch.. | 188 | |
| UNEXPECTED BRAKE PEDAL REACTION .. | 169 | ICC Brake Hold Relay | 189 | |
| Description | 169 | Accelerator Pedal Actuator | 189 | |
| Diagnosis Procedure | 169 | Driver Assistance Buzzer Control Module | 189 | |
| THE BRAKING DISTANCE IS LONG | 170 | Driver Assistance Buzzer | 189 | |
| Description | 170 | SYSTEM | 190 | |
| Diagnosis Procedure | 170 | | | |
| ABS FUNCTION DOES NOT OPERATE | 171 | | | |
| Description | 171 | | | |
| Diagnosis Procedure | 171 | | | |

| | | | |
|--|------------|---|------------|
| System Description | 190 | Description | 262 |
| Fail-safe (ADAS Control Unit) | 193 | Work Procedure | 262 |
| WARNING/INDICATOR/CHIME LIST | 194 | ADDITIONAL SERVICE WHEN REPLACING | |
| WARNING/INDICATOR/CHIME LIST : Warning | | LANE CAMERA UNIT | 263 |
| Lamp/Indicator Lamp | 194 | Description | 263 |
| OPERATION | 195 | Work Procedure | 263 |
| Switch Name and Function | 195 | PRE-INSPECTION FOR DIAGNOSIS | 264 |
| Menu Displayed by Pressing Each Switch | 195 | LANE CAMERA UNIT | 264 |
| HANDLING PRECAUTION | 198 | LANE CAMERA UNIT : Inspection Procedure | 264 |
| Description | 198 | CAMERA AIMING ADJUSTMENT | 265 |
| DIAGNOSIS SYSTEM (ADAS CONTROL | | Description | 265 |
| UNIT) | 199 | Work Procedure (Preparation) | 265 |
| On Board Diagnosis Function | 199 | Work Procedure (Target Setting) | 266 |
| CONSULT Function (ICC/ADAS) | 200 | Work Procedure (Camera Aiming Adjustment) | 267 |
| DIAGNOSIS SYSTEM (ICC SENSOR) | 213 | Work Procedure (Target Mark Sample) | 268 |
| CONSULT Function (LASER/RADAR) | 213 | DTC/CIRCUIT DIAGNOSIS | 270 |
| DIAGNOSIS SYSTEM (LANE CAMERA | | C1B00 CAMERA UNIT MALF | 270 |
| UNIT) | 215 | LANE CAMERA UNIT | 270 |
| CONSULT Function (LANE CAMERA) | 215 | LANE CAMERA UNIT : DTC Logic | 270 |
| DIAGNOSIS SYSTEM (ACCELERATOR | | LANE CAMERA UNIT : Diagnosis Procedure | 270 |
| PEDAL ACTUATOR) | 217 | C1B01 CAM AIMING INCOMP | 271 |
| CONSULT Function (ACCELERATOR PEDAL | | LANE CAMERA UNIT | 271 |
| ACT) | 217 | LANE CAMERA UNIT : DTC Logic | 271 |
| ECU DIAGNOSIS INFORMATION | 219 | LANE CAMERA UNIT : Diagnosis Procedure | 271 |
| ADAS CONTROL UNIT | 219 | C1B03 ABNRML TEMP DETECT | 272 |
| Reference Value | 219 | LANE CAMERA UNIT | 272 |
| Fail-safe (ADAS Control Unit) | 225 | LANE CAMERA UNIT : DTC Logic | 272 |
| DTC Inspection Priority Chart | 226 | LANE CAMERA UNIT : Diagnosis Procedure | 272 |
| DTC Index | 227 | C1B09 POWER SUPPLY CIRCUIT | 273 |
| ICC SENSOR | 230 | DTC Logic | 273 |
| Reference Value | 230 | Diagnosis Procedure | 273 |
| Fail-safe (ICC Sensor) | 231 | U1000 CAN COMM CIRCUIT | 274 |
| DTC Inspection Priority Chart | 231 | ACCELERATOR PEDAL ACTUATOR | 274 |
| DTC Index | 232 | ACCELERATOR PEDAL ACTUATOR : Descrip- | |
| WIRING DIAGRAM | 236 | tion | 274 |
| DRIVER ASSISTANCE SYSTEMS | 236 | ACCELERATOR PEDAL ACTUATOR : DTC Log- | |
| Wiring Diagram | 236 | ic | 274 |
| BASIC INSPECTION | 258 | ACCELERATOR PEDAL ACTUATOR : Diagnosis | |
| DIAGNOSIS AND REPAIR WORK FLOW | 258 | Procedure | 274 |
| Work Flow | 258 | LANE CAMERA UNIT | 274 |
| ADDITIONAL SERVICE WHEN REPLACING | | LANE CAMERA UNIT : Description | 274 |
| ICC SENSOR | 261 | LANE CAMERA UNIT : DTC Logic | 275 |
| Description | 261 | LANE CAMERA UNIT : Diagnosis Procedure | 275 |
| Work Procedure | 261 | SIDE RADAR LH | 275 |
| ADDITIONAL SERVICE WHEN REPLACING | | SIDE RADAR LH : Description | 275 |
| ACCELERATOR PEDAL ASSEMBLY | 262 | SIDE RADAR LH : DTC Logic | 276 |
| | | SIDE RADAR LH : Diagnosis Procedure | 276 |

| | | | | |
|--|------------|---|------------|------------|
| SIDE RADAR RH | 276 | U0104 ADAS CAN 1 | 283 | A |
| SIDE RADAR RH : Description | 276 | SIDE RADAR | 283 | B |
| SIDE RADAR RH : DTC Logic | 277 | SIDE RADAR : DTC Logic | 283 | |
| SIDE RADAR RH : Diagnosis Procedure | 277 | SIDE RADAR : Diagnosis Procedure | 283 | |
| DRIVER ASSISTANCE BUZZER CONTROL MOD- MODULE | 277 | DRIVER ASSISTANCE BUZZER CONTROL MOD- MODULE | 283 | C |
| DRIVER ASSISTANCE BUZZER CONTROL MODULE : Description | 277 | DRIVER ASSISTANCE BUZZER CONTROL MODULE : DTC Logic | 284 | |
| DRIVER ASSISTANCE BUZZER CONTROL MODULE : DTC Logic | 277 | DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure | 284 | D |
| DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure | 278 | U0126 STRG SEN CAN 1 | 285 | E |
| U1010 CONTROL UNIT (CAN) | 279 | LANE CAMERA UNIT | 285 | |
| ACCELERATOR PEDAL ACTUATOR | 279 | LANE CAMERA UNIT : DTC Logic | 285 | |
| ACCELERATOR PEDAL ACTUATOR : Descrip- tion | 279 | LANE CAMERA UNIT : Diagnosis Procedure | 285 | |
| ACCELERATOR PEDAL ACTUATOR : DTC Log- ic | 279 | U0405 ADAS CAN 2 | 286 | BRC |
| ACCELERATOR PEDAL ACTUATOR : Diagnosis Procedure | 279 | SIDE RADAR | 286 | G |
| LANE CAMERA UNIT | 279 | SIDE RADAR : DTC Logic | 286 | |
| LANE CAMERA UNIT : Description | 279 | SIDE RADAR : Diagnosis Procedure | 286 | |
| LANE CAMERA UNIT : DTC Logic | 279 | U0428 STRG SEN CAN 2 | 287 | H |
| LANE CAMERA UNIT : Diagnosis Procedure | 280 | LANE CAMERA UNIT | 287 | |
| SIDE RADAR LH | 280 | LANE CAMERA UNIT : DTC Logic | 287 | |
| SIDE RADAR LH : Description | 280 | LANE CAMERA UNIT : Diagnosis Procedure | 287 | I |
| SIDE RADAR LH : DTC Logic | 280 | POWER SUPPLY AND GROUND CIRCUIT .. | 288 | J |
| SIDE RADAR LH : Diagnosis Procedure | 281 | Diagnosis Procedure | 288 | |
| SIDE RADAR RH | 281 | FORWARD EMERGENCY BRAKING | 289 | K |
| SIDE RADAR RH : Description | 281 | Diagnosis Procedure | 289 | |
| SIDE RADAR RH : DTC Logic | 281 | SYMPTOM DIAGNOSIS | 290 | L |
| SIDE RADAR RH : Diagnosis Procedure | 282 | SYSTEM SETTINGS CANNOT BE TURNED ON/OFF ON THE INTEGRAL SWITCH | 290 | |
| DRIVER ASSISTANCE BUZZER CONTROL MOD- MODULE | 282 | Symptom Table | 290 | |
| DRIVER ASSISTANCE BUZZER CONTROL MODULE : Description | 282 | Description | 290 | |
| DRIVER ASSISTANCE BUZZER CONTROL MODULE : DTC Logic | 282 | Diagnosis Procedure | 290 | M |
| DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure | 282 | NORMAL OPERATING CONDITION | 293 | |
| | | Description | 293 | N |
| | | | | O |
| | | | | P |

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000012853586

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes dual stage front air bag modules. The SRS system may only deploy one front air bag, depending on the severity of a collision and whether the front passenger seat is occupied. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.


Precaution for Brake System

INFOID:000000012853587

WARNING:

Clean any dust from the front brake and rear brake using a vacuum dust collector. Do not blow by compressed air.

- Brake fluid use refer to [MA-16, "FOR USA AND CANADA : Fluids and Lubricants"](#) (United States and Canada) or [MA-17, "FOR MEXICO : Fluids and Lubricants"](#) (Mexico).
- Do not reuse drained brake fluid.
- Do not spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Always confirm the specified tightening torque when installing the brake pipes.
- After pressing the brake pedal more deeply or harder than normal driving, such as air bleeding, check each item of brake pedal. Adjust brake pedal if it is outside the standard value.
- Do not use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with a crow-foot (A) and torque wrench (B).
- Always connect the battery terminal when moving the vehicle.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



PRECAUTIONS

< PRECAUTION >

[VDC/TCS/ABS]

Precaution for Brake Control System


INFOID:000000012853588

- Just after starting vehicle after ignition switch is ON, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is a normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for simple causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level and oil leaks.
- If tire size and type are used in an improper combination or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.
- VDC system may not operate normally or a VDC OFF indicator lamp or SLIP indicator lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.


Precaution for Harness Repair

INFOID:000000012853589

- Solder the repair part, and wrap it with tape. [Twisted wire fray must be 110 mm (4.33 in) or less.]



- Do not bypass the repair point with wire. (If it is bypassed, the turn-out point cannot be separated and the twisted wire characteristics are lost.)



A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

PREPARATION

< PREPARATION >

[VDC/TCS/ABS]

PREPARATION


PREPARATION

Special Service Tool

INFOID:000000012853590

The actual shape of the tools may differ from those illustrated here.



| Tool number (TechMate No.) Tool name | Description |
|---|--|
| KV991J0080 (J-45741) ABS active wheel sensor tester | Checking operation of ABS active wheel sensors |



Commercial Service Tools

INFOID:000000012853591

| Tool name | Description |
|---|--|
| 1. Flare nut crowfoot 2. Torque wrench | Tightening brake tube flare nuts a: 10 mm (0.39 in)/12 mm (0.47 in) |
| Power tool | Loosening nuts, screws and bolts |



COMPONENT PARTS

< SYSTEM DESCRIPTION >


[VDC/TCS/ABS]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000013635593




A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]



- A. Steering column area (view with steering wheel removed)
- B. Instrument panel (LH side)
- C. Engine compartment (RH rear)
- D. Engine compartment (LH rear)
- E. Left front wheel area (RH similar)
- F. Engine compartment (LH rear)
- G. Left front wheel area (RH similar)
- H. Brake pedal area
- I. LH drivers kick panel area
- J. Instrument panel (LH side)
- K. Front center console area (View with center console removed)
- L. Left rear wheel area (RH similar)
- M. Center of back door kicking plate area (view with storage box removed)

Component Description

INFOID:0000000013635591

| No. | Component | Function |
|-----|---|--|
| 1. | ECM | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> • Accelerator pedal position signal • Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> • Target throttle position signal |
| 2. | TCM | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> • Shift position signal • Current gear position signal |
| 3. | Steering angle sensor | BRC-12. "Steering Angle Sensor" |
| 4. | Combination meter | MWI-6. "METER SYSTEM : Component Parts Location" |
| 5. | ABS actuator and electric unit (control unit) | BRC-11. "ABS Actuator and Electric Unit (Control Unit)" |
| | Pump/motor | |
| | Motor relay | |
| | Actuator relay (main relay) | |
| | ABS IN valve | |
| | ABS OUT valve | |
| | Pressure sensor | |
| 6. | Brake fluid level switch | BRC-12. "Brake Fluid Level Switch" |
| 7. | Vacuum sensor | BRC-12. "Vacuum Sensor" |
| 8. | IPDM E/R | Supplies power to the following components: <ul style="list-style-type: none"> • ABS actuator and electric unit (control unit) • Steering angle sensor • Yaw rate/side/decel G sensor |

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| No. | Component | Function |
|-----|----------------------|---|
| 9. | Wheel sensor | BRC-11, "Wheel Sensor and Sensor Rotor" |
| 10. | Stop lamp switch | BRC-12, "Stop Lamp Switch" |
| 11. | Parking brake switch | BRC-12, "Parking Brake Switch" |
| 12. | VDC OFF switch | BRC-12, "VDC OFF Switch" |
| 13. | Wheel sensor | BRC-11, "Wheel Sensor and Sensor Rotor" |
| 14. | ADAS control unit | BRC-12, "ADAS Control Unit" |

ABS Actuator and Electric Unit (Control Unit)

INFOID:000000012853594

Electric unit (control unit) is integrated with actuator and motor/accumulator assembly and comprehensively controls VDC function, TCS function, ABS function and EBD function.

ELECTRIC UNIT (CONTROL UNIT)

- Brake fluid pressure, engine and transmission are controlled according to signals from each sensor.
- If malfunction is detected, the system enters fail-safe mode.

ACTUATOR

The following components are integrated with ABS actuator.

Pump

Returns the brake fluid reserved in reservoir to master cylinder by reducing pressure.

Motor

Activates the pump according to signals from ABS actuator and electric unit (control unit).

Motor Relay

Operates the motor ON/OFF according to signals from ABS actuator and electric unit (control unit).

Actuator Relay

Operates each valve ON/OFF according to signals from ABS actuator and electric unit (control unit).

ABS IN Valve and ABS OUT Valve

Increases, holds or decreases the fluid pressure of each caliper according to signals from ABS actuator and electric unit (control unit).

Pressure Sensor

Detects the brake fluid pressure and transmits signal to ABS actuator and electric unit (control unit).

Cut Valve 1 (Primary Line), Cut Valve 2 (Secondary Line)

Shuts off the ordinary brake line from master cylinder when VDC function, TCS function, hill start assist function and brake force distribution function are activated.

Yaw Rate/Side/Decel G Sensor

Calculates the following information that affects the vehicle and transmits a signal to ABS actuator and electric unit (control unit). [Yaw rate/side/decel G sensor is integrated into the ABS actuator and electric unit (control unit)].

- Vehicle rotation angular velocity (yaw rate signal)
- Vehicle lateral acceleration (side G signal)
- Vehicle longitudinal acceleration (decel G signal)

Wheel Sensor and Sensor Rotor

INFOID:000000012853595

NOTE:


- Wheel sensor and sensor rotor is integrated in wheel hub assembly.
- Never measure resistance and voltage value using a tester because sensor is active sensor.

COMPONENT PARTS

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- Downsize and weight reduction is aimed. IC for detection portion and magnet for sensor rotor are adopted.
- Power supply is supplied to detection portion so that magnetic field line is read. Magnetic field that is detected is converted to current signal.
- When sensor rotor rotates, magnetic field changes. Magnetic field change is converted to current signals (rectangular wave) and is transmitted to ABS actuator and electric unit (control unit). Change of magnetic field is proportional to wheel speed.



Stop Lamp Switch

INFOID:0000000012853596

Detects the operation status of brake pedal and transmits converted electric signal to ABS actuator and electric unit (control unit).

Steering Angle Sensor

INFOID:0000000012853597

Detects the following information and transmits steering angle signal to ABS actuator and electric unit (control unit) via CAN communication:

- Steering wheel rotation amount
- Steering wheel rotation angular velocity
- Steering wheel rotation direction

Brake Fluid Level Switch

INFOID:0000000012853599

Detects the brake fluid level in reservoir tank and transmits converted electric signal from ABS actuator and electric unit (control unit) when brake fluid level is the specified level or less.

Vacuum Sensor

INFOID:0000000012853600

Detects the vacuum in brake booster and transmits converted electric signal to ABS actuator and electric unit (control unit).

Parking Brake Switch

INFOID:0000000012853601

Detects the operation status of parking brake switch and transmits converted electric signal from combination meter to ABS actuator and electric unit (control unit).

ADAS Control Unit

INFOID:0000000012853602

Controls Active trace control function in ADAS control unit and transmits Active trace control signal to ABS actuator and electric unit (control unit) via CAN communication.

NOTE:

Models with ICC system

VDC OFF Switch

INFOID:0000000012853603

- This is an integrated switch with switches for other functions.
- Non-operational status or standby status of the following functions can be selected using VDC OFF switch. VDC OFF indicator lamp indicates the operation status of function. (ON: Non-operational status, OFF: Standby status)

- VDC function

NOTE:

Brake limited slip differential (BLSD) control operates.

- TCS function


- Active trace control function

- VDC OFF indicator lamp turns OFF (standby status) when the engine is started again after it is stopped once while VDC OFF indicator lamp is ON (non-operational status).

SYSTEM

System Diagram

INFOID:000000012853604



A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

System Description

INFOID:000000012853605

- The system switches fluid pressure of each brake caliper to increase, to hold or to decrease according to signals from control unit in ABS actuator and electric unit (control unit). This control system is applied to VDC function, TCS function, ABS function, EBD function, hill start assist function, Brake force distribution function and Active trace control function.
- Fail-safe function is available for each function and is activated by each function when system malfunction occurs.

INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

VDC function, TCS function, ABS function, EBD function and Brake force distribution function

| Component | Signal description |
|-----------|--|
| ECM | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Accelerator pedal position signal • Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> • Target throttle position signal |
| TCM | Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Shift position signal |

SYSTEM

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Component | Signal description |
|-----------------------|---|
| Steering angle sensor | Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> • Steering angle sensor signal |
| Combination meter | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Brake fluid level switch signal • Parking brake switch signal Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • ABS warning lamp signal • Brake warning lamp signal • VDC warning lamp signal • VDC OFF indicator lamp |

Active trace control function

| Component | Signal description |
|---|--|
| ADAS control unit | Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Active trace control signal |
| ECM | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Accelerator pedal position signal • Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Target throttle position signal |
| ABS actuator and electric unit (control unit) | Mainly transmits the following signals to ADAS control unit via CAN communication: <ul style="list-style-type: none"> • Vehicle speed signal (ABS) • Stop lamp switch signal (brake signal) • VDC OFF switch signal • Yaw rate signal • Side G sensor signal • Decel G sensor signal |
| Drive mode select switch | Outputs ON/OFF status of STANDARD, SPORT, ECO, SNOW mode to A/C auto AMP. |
| A/C auto AMP. | Mainly transmits the following signal to ADAS control unit via CAN communication: <ul style="list-style-type: none"> • Drive mode select switch signal |
| Steering angle sensor | Mainly transmits the following signal to ADAS control unit via CAN communication: <ul style="list-style-type: none"> • Steering angle sensor signal |
| Combination meter | Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • VDC OFF indicator lamp signal • VDC warning lamp signal Mainly receives the following signal from ADAS control unit via CAN communication: <ul style="list-style-type: none"> • FEB warning lamp signal |

VALVE OPERATION (ABS AND EBD)


Each valve is operated and fluid pressure of brake caliper is controlled.

SYSTEM

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

When ordinary brake is applied and ABS is in operation (when pressure increases).



| Name | Not activated | When Pressure Increases |
|-------------------------------|--------------------------------------|--------------------------------------|
| Cut valve 1 | Power supply is not supplied (open) | Power supply is not supplied (open) |
| Cut valve 2 | Power supply is not supplied (open) | Power supply is not supplied (open) |
| ABS IN valve | Power supply is not supplied (open) | Power supply is not supplied (open) |
| ABS OUT valve | Power supply is not supplied (close) | Power supply is not supplied (close) |
| Each caliper (fluid pressure) | — | Pressure increases |

When front RH wheel caliper pressure increases

- Motor is activated. Brake fluid is pressurized by pump and is sent to secondary line through cut valve 2. At the same time, pressurized brake fluid is supplied to front RH caliper through ABS IN valve.

When front LH wheel caliper pressure increases

- Motor is activated. Brake fluid is pressurized by pump and is sent to primary line through cut valve 1. At the same time, pressurized brake fluid is supplied to front LH wheel caliper through ABS IN valve.

When rear RH wheel caliper pressure increases

- Motor is activated. Brake fluid is pressurized by pump and is sent to primary line through cut valve 1. At the same time, pressurized brake fluid is supplied to rear RH wheel caliper through ABS IN valve.

When rear LH wheel caliper pressure increases


- Motor is activated. Brake fluid is pressurized by pump and is sent to secondary line through cut valve 2. At the same time, pressurized brake fluid is supplied to rear LH wheel caliper through ABS IN valve.

SYSTEM

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

When ABS operation starts (when pressure holds)



| Name | Not activated | When pressure holds |
|-------------------------------|--------------------------------------|--------------------------------------|
| Cut valve 1 | Power supply is not supplied (open) | Power supply is not supplied (open) |
| Cut valve 2 | Power supply is not supplied (open) | Power supply is not supplied (open) |
| ABS IN valve | Power supply is not supplied (open) | Power supply is supplied (close) |
| ABS OUT valve | Power supply is not supplied (close) | Power supply is not supplied (close) |
| Each caliper (fluid pressure) | — | Pressure holds |

When front RH wheel caliper pressure holds

- Motor is activated. Brake fluid is pressurized by pump and is sent to secondary line through cut valve 2. At the same time, because ABS IN valve and ABS OUT valve are closed, fluid pressure holds.

When front LH wheel caliper pressure holds

- Motor is activated. Brake fluid is pressurized by pump and is sent to primary line through cut valve 1. At the same time, because ABS IN valve and ABS OUT valve are closed, fluid pressure holds.

When rear RH wheel caliper pressure holds

- Motor is activated. Brake fluid is pressurized by pump and is sent to primary line through cut valve 1. At the same time, because ABS IN valve and ABS OUT valve are closed, fluid pressure holds.

When rear LH wheel caliper pressure holds


- Motor is activated. Brake fluid is pressurized by pump and is sent to secondary line through cut valve 2. At the same time, because ABS IN valve and ABS OUT valve are closed, fluid pressure holds.

SYSTEM

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

ABS is in operation (when pressure decreases)



| Name | Not activated | When pressure decreases |
|-------------------------------|--------------------------------------|-------------------------------------|
| Cut valve 1 | Power supply is not supplied (open) | Power supply is not supplied (open) |
| Cut valve 2 | Power supply is not supplied (open) | Power supply is not supplied (open) |
| ABS IN valve | Power supply is not supplied (open) | Power supply is supplied (close) |
| ABS OUT valve | Power supply is not supplied (close) | Power supply is supplied (open) |
| Each caliper (fluid pressure) | — | Pressure decreases |

When front RH wheel caliper pressure decreases

- Being supplied to reservoir through ABS OUT valve, the fluid pressure of brake caliper is decreased.

When front LH wheel caliper pressure decreases

- Being supplied to reservoir through ABS OUT valve, the fluid pressure of brake caliper is decreased.

When rear RH wheel caliper pressure decreases

- Being supplied to reservoir through ABS OUT valve, the fluid pressure of brake caliper is decreased.

When rear LH wheel caliper pressure decreases

- Being supplied to reservoir through ABS OUT valve, the fluid pressure of brake caliper is decreased.

Component Parts and Function

| Component | FUNCTION |
|--------------|--|
| Reservoir | Temporarily reserves the brake fluid drained from brake caliper, so that pressure efficiently decreases when decreasing pressure of brake caliper. |
| Pump | Returns the brake fluid reserved in reservoir to master cylinder by reducing pressure. |
| Motor | Drives the pump according to signals from control unit. |
| ABS IN valve | Switches the fluid pressure line to increase or hold according to signals from control unit. |

SYSTEM

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

| Component | FUNCTION |
|----------------------------|--|
| ABS OUT valve | Switches the fluid pressure line to increase, hold or decrease according to signals from control unit. |
| Return check valve | Returns the brake fluid from brake caliper to master cylinder by bypassing orifice of each valve when brake is released. |
| Cut valve 1 Cut valve 2 | Performs the duty control of fluid pressure increased by pump according to signals from control unit. |
| Pressure Sensor | Detects the brake pedal operation amount. |


VALVE OPERATION (OTHER THAN ABS AND EBD)

Each valve is operated and fluid pressure of brake caliper is controlled.

NOTE:

There is no operation to hold and increase pressure for functions other than ABS and EBD.

When Pressure Increases



| Name | Not activated | When Pressure Increases |
|-------------|-------------------------------------|---|
| Cut valve 1 | Power supply is not supplied (open) | Wheel other than the one that the pressure is to be increased: Power supply is not supplied (open) Only wheel that the pressure is to be increased: Power supply is supplied (close) |
| Cut valve 2 | Power supply is not supplied (open) | Wheel other than the one that the pressure is to be increased: Power supply is not supplied (open) Only wheel that the pressure is to be increased: Power supply is supplied (close) |

SYSTEM

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Name | Not activated | When Pressure Increases |
|-------------------------------|--------------------------------------|---|
| ABS IN valve | Power supply is not supplied (open) | Only wheel that the pressure is to be increased: Power supply is not supplied (open) Wheel other than the one that the pressure is to be increased: Power supply is supplied (close) |
| ABS OUT valve | Power supply is not supplied (close) | Power supply is not supplied (close) |
| Each caliper (fluid pressure) | — | Pressure increases |

When front RH wheel caliper pressure increases

- Motor is activated. Brake fluid from pump is supplied to front RH wheel caliper through ABS IN valve. For other wheel, ABS IN valve is closed and brakes fluid is not supplied to caliper.

When front LH wheel caliper pressure increases

- Motor is activated. Brake fluid from pump is supplied to front LH wheel caliper through ABS IN valve. For other wheel, ABS IN valve is closed and brakes fluid is not supplied to caliper.


When rear RH wheel caliper pressure increases

- Motor is activated. Brake fluid from pump is supplied to front RH wheel caliper through ABS IN valve. For other wheel, ABS IN valve is closed and brakes fluid is not supplied to caliper.

When rear LH wheel caliper pressure increases

- Motor is activated. Brake fluid from pump is supplied to front LH wheel caliper through ABS IN valve. For other wheel, ABS IN valve is closed and brakes fluid is not supplied to caliper.

Released



SYSTEM

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Name | Not activated | When pressure decreases |
|-------------------------------|--------------------------------------|-------------------------------------|
| Cut valve 1 | Power supply is not supplied (open) | Power supply is not supplied (open) |
| Cut valve 2 | Power supply is not supplied (open) | Power supply is not supplied (open) |
| ABS IN valve | Power supply is not supplied (open) | Power supply is not supplied (open) |
| ABS OUT valve | Power supply is not supplied (close) | Power supply is supplied (open) |
| Each caliper (fluid pressure) | — | Pressure decreases |

When front RH wheel caliper pressure decreases

- Being returned to master cylinder through ABS IN valve, fluid pressure of brake caliper is decreased.

When front LH wheel caliper pressure decreases

- Being returned to master cylinder through ABS IN valve, fluid pressure of brake caliper is decreased.

When rear RH wheel caliper pressure decreases

- Being returned to master cylinder through ABS IN valve, fluid pressure of brake caliper is decreased.

When rear LH wheel caliper pressure decreases

- Being returned to master cylinder through ABS IN valve, fluid pressure of brake caliper is decreased.

Component Parts and Function

| Component | Function |
|----------------------------|---|
| Reservoir | Temporarily reserves the brake fluid drained from brake caliper so that pressure efficiently decreases when decreasing pressure of brake caliper. |
| Pump | Returns the brake fluid reserved in reservoir to master cylinder by reducing pressure. |
| Motor | Drives the pump according to signals from control unit. |
| ABS IN valve | Switches the fluid pressure line to increase or hold according to signals from control unit. |
| ABS OUT valve | Switches the fluid pressure line to increase, hold or decrease according to signals from control unit. |
| Return check valve | Returns the brake fluid from brake caliper to master cylinder by bypassing orifice of each valve when brake is released. |
| Cut valve 1 Cut valve 2 | Performs the duty control of fluid pressure increased by pump according to signals from control unit. |
| Pressure Sensor | Detects the brake pedal operation amount. |

CONDITION FOR TURN ON THE WARNING LAMP

ABS Warning Lamp

- Turns ON at the same time as VDC warning lamp when either ABS function or EBD function is malfunctioning.
- Turns ON when ignition switch turns ON and turns OFF when the system is normal, for bulb check purposes.

| Condition (status) | ABS warning lamp |
|--|------------------|
| Ignition switch OFF | OFF |
| For approx. 1 second after the ignition switch is turned ON | ON |
| Approx. 1 second after ignition switch is turned ON (when the system is in normal operation) | OFF |
| ABS function is malfunctioning | ON |
| EBD function is malfunctioning | ON |

Brake Warning Lamp

- Turns ON at the same time as ABS warning lamp and VDC warning lamp when EBD function is malfunctioning.
- Turns ON when ignition switch turns ON and turns OFF when the system is normal for bulb check purposes.

SYSTEM

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Condition (status) | Brake warning lamp |
|--|--------------------|
| Ignition switch OFF | OFF |
| For approx. 1 seconds after the ignition switch is turned ON | ON |
| Approx. 1 second after ignition switch is turned ON (when the system is in normal operation) | OFF |
| After engine starts | OFF |
| When parking brake operates (parking brake switch ON) | ON |
| When brake booster vacuum decreases | ON |
| When vacuum sensor is malfunctioning | ON |
| When brake fluid is less than the specified level (brake fluid level switch ON) | ON |
| ABS function is malfunctioning | OFF |
| EBD function is malfunctioning | ON |

A
B
C
D
E

VDC Warning Lamp

- Turns ON when either VDC function, TCS function, ABS function or EBD function is malfunctioning.
- Turns ON when ignition switch turns ON and turns OFF when the system is normal for bulb check purposes.

BRC

| Condition (status) | VDC warning lamp |
|--|------------------|
| Ignition switch OFF | OFF |
| For approx. 1 second after the ignition switch is turned ON | ON |
| Approx. 1 second after ignition switch is turned ON (when the system is in normal operation) | OFF |
| VDC function is malfunctioning | ON |
| TCS function is malfunctioning | ON |
| ABS function is malfunctioning | ON |
| EBD function is malfunctioning | ON |
| VDC function is operating | Blinking |
| TCS function is operating | Blinking |

G
H
I
J
K

FEB OFF indicator lamp

- Turns ON when Active trace control function is malfunctioning.

CONDITIONS FOR TURNING ON THE INDICATOR LAMP

VDC OFF indicator lamp

- Turns ON when VDC function and TCS function are switched to non-operational status (OFF) by VDC OFF switch.
- Turns ON when ignition switch turns ON and turns OFF when the system is normal for bulb check purposes.

| Condition (status) | VDC OFF indicator lamp |
|--|------------------------|
| Ignition switch OFF | OFF |
| For approx. 1 second after the ignition switch is turned ON | ON |
| Approx. 1 second after ignition switch is turned ON (when the system is in normal operation) | OFF |
| When VDC OFF switch is ON (VDC function, TCS function and Active trace control function are OFF) | ON |

L
M
N
O
P

Fail-Safe

INFOID:0000000012853606

VDC FUNCTION, TCS FUNCTION, hill start assist FUNCTION AND BRAKE FORCE DISTRIBUTION FUNCTION

VDC warning lamp in combination meter turns ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, hill start assist function

SYSTEM

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

and Brake force distribution function. The vehicle status becomes the same as models without VDC function, TCS function, hill start assist function and Brake force distribution function. However, ABS function and EBD function are operated normally.

ABS FUNCTION

ABS warning lamp and VDC warning lamp in combination meter turn ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, ABS function, hill start assist function and Brake force distribution function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, hill start assist function and Brake force distribution function. However, EBD function is operated normally.

NOTE:

ABS self-diagnosis sound may be heard the same as in the normal condition because self-diagnosis is performed when ignition switch turns ON and when vehicle initially starts.

EBD FUNCTION

ABS warning lamp, brake warning lamp and VDC warning lamp in combination meter turn ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, ABS function, EBD function, hill start assist function and Brake force distribution function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, EBD function, hill start assist function and Brake force distribution function.

ACTIVE TRACE CONTROL FUNCTION

• FEB OFF indicator lamp turns ON when a malfunction occurs in the system [ABS actuator and electric unit (control unit)]. The control is suspended for Active trace control function. The vehicle becomes the same as models without Active trace control function.

CAUTION:

Lamp ON condition of intelligent brake assistance OFF indicator lamp is that intelligent brake assistance OFF switch is in the pressed and not turned ON status.

• Mode is fixed to the mode when a malfunction occurs if CAN communication malfunction (DTC “U1000”, DTC “U1010”“U0424”) occurs between ADAS control unit and A/C auto AMP. The mode is fixed to STAN-DARD mode after ignition switch turns OFF to ON.

| DTC | Malfunction detected condition | Fail-safe condition |
|-------|---|---|
| C1101 | When an open circuit is detected in rear RH wheel sensor circuit. | The following functions are suspended: • VDC function • TCS function • ABS function • EBD function (only when both 2 rear wheels are malfunctioning) • hill start assist function • Brake force distribution function |
| C1102 | When an open circuit is detected in rear LH wheel sensor circuit. | |
| C1103 | When an open circuit is detected in front RH wheel sensor circuit. | |
| C1104 | When an open circuit is detected in front LH wheel sensor circuit. | |
| C1105 | <ul style="list-style-type: none"> • When power supply voltage of rear RH wheel sensor is low. • When distance between rear RH wheel sensor and rear RH wheel sensor rotor is large. • When installation of rear RH wheel sensor or rear RH wheel sensor rotor is not normal. | |
| C1106 | <ul style="list-style-type: none"> • When power supply voltage of rear LH wheel sensor is low. • When distance between rear LH wheel sensor and rear LH wheel sensor rotor is large. • When installation of rear LH wheel sensor or rear LH wheel sensor rotor is not normal. | |
| C1107 | <ul style="list-style-type: none"> • When power supply voltage of front RH wheel sensor is low. • When distance between front RH wheel sensor and front RH wheel sensor rotor is large. • When installation of front RH wheel sensor or front RH wheel sensor rotor is not normal. | |
| C1108 | <ul style="list-style-type: none"> • When power supply voltage of front LH wheel sensor is low. • When distance between front LH wheel sensor and front LH wheel sensor rotor is large. • When installation of front LH wheel sensor or front LH wheel sensor rotor is not normal. | |

SYSTEM

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| DTC | Malfunction detected condition | Fail-safe condition | |
|-------|--|--|-----|
| C1109 | <ul style="list-style-type: none"> • When ignition voltage is 10 V or less. • When ignition voltage is 16 V or more. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function | A |
| C1111 | When a malfunction is detected in motor or motor relay. | | B |
| C1115 | When difference in wheel speed between any wheel and others is detected during the vehicle is driven, because of installation of other tires than specified. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • hill start assist function • Brake force distribution function | C |
| C1116 | When stop lamp switch signal is not input when brake pedal operates. | | D |
| C1120 | When a malfunction is detected in front LH ABS IN valve. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function | E |
| C1121 | When a malfunction is detected in front LH ABS OUT valve. | | BRC |
| C1122 | When a malfunction is detected in front RH ABS IN valve. | | G |
| C1123 | When a malfunction is detected in front RH ABS OUT valve. | | H |
| C1124 | When a malfunction is detected in rear LH ABS IN valve. | | I |
| C1125 | When a malfunction is detected in rear LH ABS OUT valve. | | J |
| C1126 | When a malfunction is detected in rear RH ABS IN valve. | | K |
| C1127 | When a malfunction is detected in rear RH ABS OUT valve. | | L |
| C1130 | When a malfunction is detected in ECM system. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • hill start assist function • Brake force distribution function | M |
| C1140 | When a malfunction is detected in actuator relay. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function | N |
| C1142 | When a malfunction is detected in pressure sensor. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • hill start assist function • Brake force distribution function | O |
| C1143 | When a malfunction is detected in steering angle sensor. | | P |
| C1144 | When neutral position adjustment of steering angle sensor is not complete. | | O |
| C1145 | When a malfunction is detected in yaw rate signal. | | P |
| C1146 | When a malfunction is detected in side/decel G signal. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • hill start assist function • Brake force distribution function | O |
| C1155 | When brake fluid level low signal is detected. | | P |
| C1160 | When calibration of yaw rate/side/decel G sensor is not complete. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • hill start assist function • Brake force distribution function | P |

SYSTEM

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]


| DTC | Malfunction detected condition | Fail-safe condition |
|--------|--|---|
| C1164 | When a malfunction is detected in cut valve 1. | The following functions are suspended: • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function |
| C1165 | When a malfunction is detected in cut valve 2. | |
| C1170 | When the information in ABS actuator and electric unit (control unit) is not the same. | |
| C1197 | When a malfunction is detected in vacuum sensor. | Electrical vacuum assistance of brake booster is suspended. |
| C1198 | • When an open circuit is detected in vacuum sensor circuit. • When a short circuit is detected in vacuum sensor circuit. • When a malfunction is detected in vacuum sensor noise. | |
| C1199 | When brake booster vacuum is approx. 0 kPa (0 mmHg) during engine running. | |
| C119A | When a malfunction is detected in supply power voltage of vacuum sensor. | Electrical vacuum assistance of brake booster is suspended. |
| U1000 | When CAN communication signal is not continuously received for 2 seconds or more. | The following functions are suspended: • VDC function • TCS function • hill start assist function • Brake force distribution function |
| U0424* | When signal that is transmitted from A/C auto AMP. is not the latest information. | Mode is fixed to the mode when a malfunction of drive mode selector occurs. The mode is fixed to STAN-DARD mode after ignition switch turns OFF to ON. |

*: This is DTC that is detected in ADAS control unit side.

VDC FUNCTION

VDC FUNCTION : System Diagram

INFOID:000000012853607




ALFIA0518GB

VDC FUNCTION : System Description

INFOID:000000012853608

- Side slip or tail slip may occur while driving on a slippery road or during intended urgent evasive driving. VDC function detects side slip status using each sensor when side slip or tail slip is about to occur and improves vehicle stability by brake control and engine output control during driving.
- In addition to ABS function, EBD function and TCS function, target side slip amount is calculated according to steering operation amount from steering angle sensor and brake operation amount from brake pressure sensor. By comparing this information with vehicle side slip amount that is calculated from information from yaw rate/side/decel G sensor and wheel sensor, vehicle driving conditions (conditions of understeer or oversteer) are judged and vehicle stability is improved by brake force control on all 4 wheels and engine output control.



- VDC function can be switched to non-operational status (OFF) by operating VDC OFF switch. In this case, VDC OFF indicator lamp turns ON.
- Control unit portion automatically improves driving stability by performing brake force control as well as engine output control by transmitting drive signal to actuator portion according to difference between target side slip amount and vehicle side slip amount
- VDC warning lamp blinks while VDC function is in operation and indicates to the driver that the function is in operation.
- VDC function has brake limited slip differential (BLSD) function. LH and RH driving wheel spin is always monitored. If necessary, appropriate brake force is independently applied to LH or RH driving wheel so that one-sided wheel spin is avoided and traction is maintained. Mainly starting ability is improved. [Brake limited slip differential (BLSD) function operates while VDC function is in non-operational status (OFF) by VDC OFF switch.] VDC warning lamp turns ON when Brake limited slip differential (BLSD) function is in operation. Noises and vibration may be generated due to brake operation. This is not a malfunction.
- CONSULT can be used to diagnose the system.
- Fail-safe function is adopted. When a malfunction occurs in VDC function, the control is suspended for VDC function, TCS function, hill start assist function, Brake force distribution function and Active trace control function. The vehicle status becomes the same as models without VDC function, TCS function, hill start assist function, Brake force distribution function and Active trace control function. However, ABS function and EBD function are operated normally. Refer to [BRC-21. "Fail-Safe"](#).

NOTE:

VDC has the characteristic as described here. This is not a device that helps reckless driving.

INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

| Component | Signal description |
|-----------|---|
| ECM | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Acceleration pedal position signal • Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Target throttle position signal |
| TCM | Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Shift position signal |

SYSTEM

< SYSTEM DESCRIPTION >


[VDC/TCS/ABS]

| Component | Signal description |
|-----------------------|--|
| Steering angle sensor | Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Steering angle sensor signal |
| Combination meter | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Brake fluid level switch signal • Parking brake switch signal Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • VDC warning lamp signal • VDC OFF indicator lamp signal |


OPERATION CHARACTERISTICS

VDC Function That Prevents Oversteer Tendency

- During a cornering, brake force (brake fluid pressure) is applied on front wheel and rear wheel on the outer side of turn. Momentum directing towards the outer side of turn is generated. Oversteer is prevented.




- Changing driving lane on a slippery road, when oversteer tendency is judged large, engine output is controlled as well as brake force (brake fluid pressure) of 4 wheels. Oversteer tendency decreases.



VDC Function That Prevents Understeer Tendency

- During a cornering, brake force (brake fluid pressure) is applied on front wheel and rear wheel on the inner side of turn. Momentum directing towards the inner side of turn is generated. Understeer is prevented.




SYSTEM

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]


- Applying braking during cornering on a slippery road, when understeer tendency is judged large, engine output is controlled as well as brake force (brake fluid pressure) of four wheels. Understeer tendency decreases.



TCS FUNCTION

TCS FUNCTION : System Diagram

INFOID:000000012853609




A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

TCS FUNCTION : System Description

INFOID:000000012853610

- Wheel spin status of drive wheel is detected by wheel sensor of 4 wheels. Engine output and transmission shift status is controlled so that slip rate of drive wheels is at an appropriate level. When wheel spin occurs on drive wheel, ABS actuator and electric unit (control unit) perform brake force control of LH and RH drive wheels (apply brake force by increasing brake fluid pressure of drive wheel) and decrease engine torque by engine torque control. Wheel spin amount decreases. Engine torque is controlled to appropriate level.
- TCS function can be switched to non-operational status (OFF) by operating VDC OFF switch. In this case, VDC OFF indicator lamp turns ON.
- VDC warning lamp blinks while TCS function is in operation and indicates to the driver that the function is in operation.
- CONSULT can be used to diagnose the system.
- Fail-safe function is adopted. When a malfunction occurs in TCS function, the control is suspended for VDC function, TCS function, hill start assist function, Brake force distribution function and Active trace control function. The vehicle status becomes the same as models without VDC function, TCS function, hill start assist function, Brake force distribution function and Active trace control function. However, ABS function and EBD function are operated normally. Refer to [BRC-21. "Fail-Safe"](#).



INPUT SIGNAL AND OUTPUT SIGNAL


Major signal transmission between each unit via communication lines is shown in the following table.

| Component | Signal description |
|-----------------------|--|
| ECM | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Accelerator pedal position signal • Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Target throttle position signal |
| TCM | Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Shift position signal |
| Steering angle sensor | Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Steering angle sensor signal |
| Combination meter | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Brake fluid level switch signal • Parking brake switch signal Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • VDC warning lamp signal • VDC OFF indicator lamp signal |

ABS FUNCTION

ABS FUNCTION : System Diagram

INFOID:000000012853611



A
B
C
D
E
BRC
G
H


ABS FUNCTION : System Description

INFOID:000000012853612

- By preventing wheel lock through brake force (brake fluid pressure) control that is electronically controlled by detecting wheel speed during braking, stability during emergency braking is improved so that obstacles can be avoided by steering operation.
- During braking, control units calculate wheel speed and pseudo-vehicle speed, and transmits pressure increase, hold or decrease signals to actuator portion according to wheel slip status.
- The following effects are obtained by preventing wheel lock during braking.
 - Vehicle tail slip is prevented during braking when driving straight.
 - Understeer and oversteer tendencies are moderated during braking driving on a corner.
 - Obstacles may be easily bypassed by steering operation during braking.
- CONSULT can be used to diagnose the system diagnosis.
- Fail-safe function is adopted. When a malfunction occurs in ABS function, the control is suspended for VDC function, TCS function, ABS function, hill start assist function, Brake force distribution function and Active trace control function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, hill start assist function, Brake force distribution function and Active trace control function. However, EBD function is operated normally. Refer to [BRC-21, "Fail-Safe"](#).

NOTE:

- ABS has the characteristic as described here. This is not the device that helps reckless driving.
- To stop vehicle efficiently, ABS does not operate and ordinary brake operates at low speed [approx. 10 km/h (6 MPH) or less but differs subject to road conditions].
- Self-diagnosis is performed immediately after when engine starts and when vehicle initially is driven [by vehicle speed approx. 15 km/h (9 MPH)]. Motor sounds are generated during self-diagnosis. In addition, brake pedal may be feel heavy when depressing brake pedal lightly. These symptoms are not malfunctions.



I
J
K
L
M
N
O
P

SYSTEM

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

INPUT SIGNAL AND OUTPUT SIGNAL


Major signal transmission between each unit via communication lines is shown in the following table.

| Component | Signal description |
|-----------------------|--|
| Steering angle sensor | Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> Steering angle sensor signal |
| Combination meter | Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> ABS warning lamp signal VDC warning lamp signal |

EBD FUNCTION

EBD FUNCTION : System Diagram

INFOID:000000012853613




ALFIA0519GB

EBD FUNCTION : System Description

INFOID:000000012853614

- By preventing rear wheel slip increase through rear wheel brake force (brake fluid pressure) control that is electronically controlled when slight skip on front and rear wheels are detected during braking, stability during braking is improved.
- EBD function is expanded and developed from conventional ABS function and corrects rear wheel brake force to appropriate level by electronic control according to load weight (number of passengers).




JPFIC0142GB

SYSTEM

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- During braking, control unit portion compares slight slip on front and rear wheels by wheel speed sensor signal, transmits drive signal to actuator portion when rear wheel slip exceeds front wheel slip for the specified value or more, and controls rear wheel brake force (brake fluid pressure) so that increase of rear wheel slip is prevented and slips on front wheel and rear wheel are nearly equalized. ABS control is applied when slip on each wheel increases and wheel speed is the threshold value of ABS control or less.
- CONSULT can be used to diagnose the system.
- Fail-safe function is adopted. When a malfunction occurs in EBD function, the control is suspended for VDC function, TCS function, ABS function, EBD function, hill start assist function, Brake force distribution function and Active trace control function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, EBD function, hill start assist function, Brake force distribution function and Active trace control function. Refer to [BRC-21, "Fail-Safe"](#).



A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

INPUT SIGNAL AND OUTPUT SIGNAL


Major signal transmission between each unit via communication lines is shown in the following table.

| Component | Signal description |
|-------------------|---|
| Combination meter | Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Brake warning lamp signal • ABS warning lamp signal • VDC warning lamp signal |

Hill start assist FUNCTION

Hill start assist FUNCTION : System Diagram

INFOID:000000012853615



Hill start assist FUNCTION : System Description

INFOID:000000012853616

- This function maintains brake fluid pressure so that the vehicle does not move backwards even if brake pedal is released to depress accelerator pedal to start the vehicle while it is stopped on an uphill slope by depressing brake pedal.
- This function operates when the vehicle is in stop status on an uphill slope of slope ratio 10% or more and selector lever is in any position other than P (Park) or N (Neutral).
- Hill start assist function is only for the start aid. It maintains the brake fluid pressure for approx. 2 seconds after releasing the brake pedal, and then decreases the pressure gradually. If the vehicle starts by accelerator operation, the brake is released automatically and a smooth start can be performed.
- Fail-safe function is adopted. When a malfunction occurs in hill start assist function, the control is suspended for VDC function, TCS function, hill start assist function, Brake force distribution function and Active trace control function. The vehicle status becomes the same as models without VDC function, TCS function, hill start assist function, Brake force distribution function and Active trace control function. However, ABS function and EBD function are operated normally. Refer to [BRC-21, "Fail-Safe"](#).

INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

| Component | Signal description |
|-----------|--|
| ECM | <p>Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication:</p> <ul style="list-style-type: none"> • Accelerator pedal position signal • Engine speed signal <p>Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication:</p> <ul style="list-style-type: none"> • Target throttle position signal |

SYSTEM

< SYSTEM DESCRIPTION >


[VDC/TCS/ABS]

| Component | Signal description |
|-------------------|--|
| TCM | Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Shift position signal |
| Combination meter | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • Brake fluid level switch signal • Parking brake switch signal Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> • VDC warning lamp signal • VDC OFF indicator lamp signal |

ACTIVE STABILITY ASSIST

ACTIVE STABILITY ASSIST : System Diagram

INFOID:0000000012853617



ACTIVE STABILITY ASSIST : System Description

INFOID:0000000012853618

- Combination of Active trace control function and Brake force distribution function is named to as Active stability assist. Active trace control function is available for models with ICC system.
- Active stability assist system is aimed to smooth the vehicle movement utilizing VDC function for enjoyable driving with reliable feeling of the driver.
- Active trace control function
- Active Trace Control helps enhance the transition from braking into and then accelerating out of corners. Active Trace Control utilizes the vehicle's VDC system to help improve cornering feel by automatically applying brakes, or smoothing engine torque characteristics while accelerating. Furthermore, Active Trace Control will apply selective braking to help create increased steering response in S-turns. For example, if driving through an S-turn that starts with steering to the right, the right-side brakes are engaged to create a yaw momentum and help turn the vehicle. When steering back to the left, left-side brakes are engaged. Refer to [BRC-34. "ACTIVE STABILITY ASSIST : Active Trace Control Function"](#).
- Brake Force Distribution function
- During braking, Brake force Distribution optimizes the distribution of brake force to each of the four wheels depending on the state of the turn detected by driver's steering and some sensors. Brake force Distribution helps provide a more stable and secure feeling. Refer to [BRC-13. "System Diagram"](#).

SYSTEM

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- Active trace control can be switched to operational status or non-operational status by operating VDC OFF switch to ON/OFF.

INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

| Component | Signal description |
|---|---|
| ADAS control unit | Mainly transmits the following signal to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> Active trace control signal |
| ECM | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> Accelerator pedal position signal Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> Target throttle position signal |
| ABS actuator and electric unit (control unit) | Mainly transmits the following signals to ADAS control unit via CAN communication: <ul style="list-style-type: none"> Vehicle speed signal (ABS) Stop lamp switch signal (brake signal) VDC OFF switch signal Yaw rate signal Side G sensor signal Decel G sensor signal |
| Drive mode select switch | Outputs ON/OFF status of STANDARD, SPORT, ECO, SNOW mode to A/C auto AMP. |
| A/C auto AMP | Mainly transmits the following signal to ADAS control unit via CAN communication: <ul style="list-style-type: none"> Drive mode select switch signal |
| Steering angle sensor | Mainly transmits the following signal to ADAS control unit via CAN communication: <ul style="list-style-type: none"> Steering angle sensor signal |
| Combination meter | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> Brake fluid level switch signal Parking brake switch signal Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication: <ul style="list-style-type: none"> VDC OFF indicator lamp signal VDC warning lamp signal Mainly receives the following signal from ADAS control unit via CAN communication: <ul style="list-style-type: none"> FEB warning lamp signal |

ACTIVE STABILITY ASSIST : Active Trace Control Function

INFOID:0000000012853619

- Active trace control function is calculated by ADAS control unit and transmits command to ABS actuator and electric unit (control unit).
- This system senses driving based on the driver's steering and acceleration/braking patterns, and individually controls the braking and application of engine torque to each of the four wheels to help smooth vehicle response.
- When the drive mode selector switch is set to the "SPORT" mode, the amount of brake control provided by Active trace control function is reduced.
- When the VDC OFF switch is turn OFF the VDC function, the Active trace control function is also turned OFF.
- Active trace control function is malfunctioning properly, the IBA OFF indicator lamp turns ON.

NOTE:

Effect to decrease delay of vehicle yaw rate in response to steering operation may not always be obtained in all driving conditions (example: when road surface resistance is low).


OPERATION CHARACTERISTICS

SYSTEM

< SYSTEM DESCRIPTION >


[VDC/TCS/ABS]

Active Trace Control helps enhance the transition from braking into and then accelerating out of corners. Active Trace Control utilizes the vehicle's VDC system to help improve cornering feel by automatically applying brakes, or smoothing engine torque characteristics while accelerating. Furthermore, Active Trace Control will apply selective braking to help create increased steering response in S-turns. For example, if driving through an S-turn that starts with steering to the right, the right-side brakes are engaged to create a yaw momentum and help turn the vehicle.



A
B
C
D
E
BRC

- Brake control amount and engine output are controlled according to steering operation status by the driver and vehicle cornering status.




G
H
I
J
K
L
M
N
O
P

SYSTEM

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]


- By preventing a sudden torque change, vehicle behavior moderates. As a result, accelerator pedal operation by the driver is improved.



ACTIVE STABILITY ASSIST : Brake Force Distribution Function

INFOID:000000012853620


- Brake force distribution function is controlled by ABS actuator and electric unit (control unit).
- Brake force distribution function helps provide a more stable and secure feeling.



- During cornering, when brake operation is performed, brake fluid pressure of each wheel is controlled based on steering operation amount by the driver and vehicle cornering status amount detected by each sensor.
- VDC warning lamp turns ON when Brake force distribution function is malfunctioning.

NOTE:

Brake force distribution function may not always operate in all driving conditions.



DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

CONSULT Function

INFOID:000000012853621

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and no-start condition.

APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes as follows.

| Mode | Function description |
|------------------------|--|
| ECU identification | Parts number of ABS actuator and electric unit (control unit) can be read. |
| Self Diagnostic Result | Self-diagnostic results and freeze frame data can be read and erased quickly.* |
| DATA MONITOR | Input/Output data in the ABS actuator and electric unit (control unit) can be read. |
| ACTIVE TEST | Diagnostic Test Mode in which CONSULT drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range. |
| WORK SUPPORT | Components can be quickly and accurately adjusted. |

*: The following diagnosis information is erased by erasing.

- DTC
- Freeze frame data (FFD)

ECU IDENTIFICATION

ABS actuator and electric unit (control unit) part number can be read.

SELF DIAGNOSTIC RESULT

Refer to [BRC-47, "DTC Index"](#).

When "CRNT" is displayed on self-diagnosis result,

- The system is presently malfunctioning.

When "PAST" is displayed on self-diagnosis result,

- System malfunction in the past is detected, but the system is presently normal.

Freeze frame data (FFD)

The following vehicle status is recorded when DTC is detected and is displayed on CONSULT.

| Item name | Display item |
|-------------------------|--|
| IGN counter (0 – 39) | <p>The number of times that ignition switch is turned ON after the DTC is detected is displayed.</p> <ul style="list-style-type: none">• When "0" is displayed: It indicates that the system is presently malfunctioning.• When except "0" is displayed: It indicates that system malfunction in the past is detected, but the system is presently normal. <p>NOTE: Each time when ignition switch is turned OFF to ON, numerical number increases in 1 → 2 → 3...38 → 39. When the operation number of times exceeds 39, the number do not increase and "39" is displayed until self-diagnosis is erased.</p> |

ACTIVE TEST

The active test is used to determine and identify details of a malfunction, based on self-diagnosis test results and data obtained in the DATA MONITOR. In response to instructions from CONSULT, instead of those from ABS actuator and electric unit (control unit) on the vehicle, a drive signal is sent to the actuator to check its operation.

CAUTION:

- Never perform ACTIVE TEST while driving the vehicle.
- Always bleed air from brake system before active test.
- Never perform active test when system is malfunctioning.

NOTE:

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- When active test is performed while depressing the pedal, the pedal depressing stroke may change. This is not a malfunction.
- “TEST IS STOPPED” is displayed approx. 10 seconds after operation start.
- When performing active test again after “TEST IS STOPPED” is displayed, select “BACK”.
- ABS warning lamp, brake warning lamp and VDC warning lamp may turn ON during active test. This is not a malfunction.

ABS IN Valve and ABS OUT Valve

When “Up”, “Keep” or “Down” is selected on display screen, the following items are displayed when system is normal.

| Test item | Display Item | Display | | |
|-----------|---------------|---------|------|------|
| | | Up | Keep | Down |
| FR RH SOL | FR RH IN SOL | Off | On* | On* |
| | FR RH OUT SOL | Off | Off | On* |
| FR LH SOL | FR LH IN SOL | Off | On* | On* |
| | FR LH OUT SOL | Off | Off | On* |
| RR RH SOL | RR RH IN SOL | Off | On* | On* |
| | RR RH OUT SOL | Off | Off | On* |
| RR LH SOL | RR LH IN SOL | Off | On* | On* |
| | RR LH OUT SOL | Off | Off | On* |

*: Immediately after being selected, status is “On”. Status changes to “Off” after approx. 2 seconds.

ABS IN Valve (ACT) and ABS OUT Valve (ACT)

When “Up”, “ACT UP” or “ACT KEEP” is selected on display screen, the following items are displayed when system is normal.

| Test item | Display Item | Display | | |
|---------------------------|---------------|---------|--------|----------|
| | | Up | ACT UP | ACT KEEP |
| FR RH ABS SOLE-NOID (ACT) | FR RH IN SOL | Off | Off | Off |
| | FR RH OUT SOL | Off | Off | Off |
| | CV1 | Off | Off | Off |
| | CV2 | Off | On* | On* |
| FR LH ABS SOLE-NOID (ACT) | FR LH IN SOL | Off | Off | Off |
| | FR LH OUT SOL | Off | Off | Off |
| | CV1 | Off | On* | On* |
| | CV2 | Off | Off | Off |
| RR RH ABS SOLE-NOID (ACT) | RR RH IN SOL | Off | Off | Off |
| | RR RH OUT SOL | Off | Off | Off |
| | CV1 | Off | On* | On* |
| | CV2 | Off | Off | Off |
| RR LH ABS SOLE-NOID (ACT) | RR LH IN SOL | Off | On* | Off |
| | RR LH OUT SOL | Off | Off | Off |
| | CV1 | Off | Off | Off |
| | CV2 | Off | On* | On* |

*: Immediately after being selected, status is “On”. Status changes to “Off” after approx. 10 seconds.

ABS MOTOR

When “On” or “Off” is selected on display screen, the following items are displayed when system is normal.

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Test item | Display Item | Display | |
|-----------|--------------------------------|---------|-----|
| | | On | Off |
| ABS MOTOR | MOTOR RELAY | On | Off |
| | ACTUATOR RLY ^(Note) | On | On |

NOTE:

Display occasionally changes On/Off for a moment after ignition switch is turned ON. This is an operation for checking purposes and is not a malfunction.

DATA MONITOR

×: Applicable

| Item (Unit) | Monitor item selection | | Note |
|---------------------------------|------------------------|--------------|--|
| | ECU INPUT SIGNALS | MAIN SIGNALS | |
| FR LH SENSOR [km/h (MPH)] | × | × | Wheel speed calculated by front LH wheel sensor is displayed. |
| FR RH SENSOR [km/h (MPH)] | × | × | Wheel speed calculated by front RH wheel sensor is displayed. |
| RR LH SENSOR [km/h (MPH)] | × | × | Wheel speed calculated by rear LH wheel sensor is displayed. |
| RR RH SENSOR [km/h (MPH)] | × | × | Wheel speed calculated by rear RH wheel sensor is displayed. |
| DECEL G-SEN (m/s ²) | × | × | Decel G detected by decel G sensor is displayed. |
| FR RH IN SOL (On/Off) | | × | Operation status of front RH wheel ABS IN valve is displayed. |
| FR RH OUT SOL (On/Off) | | × | Operation status of front RH wheel ABS OUT valve is displayed. |
| FR LH IN SOL (On/Off) | | × | Operation status of front LH wheel ABS IN valve is displayed. |
| FR LH OUT SOL (On/Off) | | × | Operation status of front LH wheel ABS OUT valve is displayed. |
| RR RH IN SOL (On/Off) | | × | Operation status of rear RH wheel ABS IN valve is displayed. |
| RR RH OUT SOL (On/Off) | | × | Operation status of rear RH wheel ABS OUT valve is displayed. |
| RR LH IN SOL (On/Off) | | × | Operation status of rear LH wheel ABS IN valve is displayed. |
| RR LH OUT SOL (On/Off) | | × | Operation status of rear LH wheel ABS OUT valve is displayed. |
| EBD WARN LAMP (On/Off) | | | Brake warning lamp ON/OFF status is displayed. ^(Note 1) |
| STOP LAMP SW (On/Off) | × | × | Stop lamp switch signal input status is displayed. |
| MOTOR RELAY (On/Off) | | × | ABS motor and motor relay status is displayed. |
| ACTUATOR RLY (On/Off) | | × | ABS actuator relay status is displayed. |
| ABS WARN LAMP (On/Off) | | × | ABS warning lamp ON/OFF status is displayed. ^(Note 1) |
| OFF LAMP (On/Off) | | × | VDC OFF indicator lamp ON/OFF status is displayed. ^(Note 1) |
| OFF SW (On/Off) | × | × | VDC OFF switch ON/OFF status is displayed. ^(Note 1) |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Item (Unit) | Monitor item selection | | Note |
|------------------------------------|------------------------|--------------|---|
| | ECU INPUT SIGNALS | MAIN SIGNALS | |
| SLIP/VDC LAMP (On/Off) | | × | VDC warning lamp ON/OFF status is displayed. ^(Note 1) |
| BATTERY VOLT (V) | × | × | Voltage supplied to ABS actuator and electric unit (control unit) is displayed. |
| GEAR | × | × | Current gear position judged from current gear position signal is displayed. |
| SLCT LVR POSI | × | × | Current gear position judged from current gear position signal is displayed. |
| ENGINE SPEED (tr/min) | × | × | Engine speed status is displayed. |
| YAW RATE SEN (d/s) | × | × | Yaw rate detected by yaw rate sensor is displayed. |
| R POSI SIG (On/Off) | | | R range signal input status judged from R range signal is displayed. |
| N POSI SIG (On/Off) | | | N range signal input status judged from N range signal is displayed. |
| CV1 (On/Off) | | | Cut valve 1 operation status is displayed. |
| CV2 (On/Off) | | | Cut valve 2 operation status is displayed. |
| ACCEL POS SIG (%) | × | | Displays the Accelerator pedal position. |
| SIDE G -SENSOR (m/s ²) | × | | Side G detected by side G sensor is displayed. |
| STR ANGLE SIG (°) | × | | Steering angle detected by steering angle sensor is displayed. |
| PRESS SENSOR (bar) | × | | Brake fluid pressure detected by pressure sensor is displayed. |
| EBD SIGNAL (On/Off) | | | EBD operation status is displayed. |
| ABS SIGNAL (On/Off) | | | ABS operation status is displayed. |
| TCS SIGNAL (On/Off) | | | TCS operation status is displayed. |
| VDC SIGNAL (On/Off) | | | VDC operation status is displayed. |
| EBD FAIL SIG (On/Off) | | | EBD fail-safe signal status is displayed. |
| ABS FAIL SIG (On/Off) | | | ABS fail-safe signal status is displayed. |
| TCS FAIL SIG (On/Off) | | | TCS fail-safe signal status is displayed. |
| VDC FAIL SIG (On/Off) | | | VDC fail-safe signal status is displayed. |
| CRANKING SIG (On/Off) | | | Cranking status is displayed. |
| FLUID LEV SW (On/Off) | × | | Brake fluid level signal input status via CAN communication is displayed. |

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

| Item (Unit) | Monitor item selection | | Note |
|--------------------------------------|------------------------|--------------|--|
| | ECU INPUT SIGNALS | MAIN SIGNALS | |
| PARK BRAKE SW (On/Off) | × | | Parking brake switch signal input status via CAN communication is displayed. |
| USS SIG ^(Note 2) (On/Off) | | | Hill start assist operation status is displayed. |

Note 1: Refer to [BRC-13. "System Description"](#) for ON/OFF conditions of each warning lamp and indicator lamp.

Note 2: USS means "hill start assist."

WORK SUPPORT

| Conditions | Description |
|----------------------------|---|
| ST ANGLE SENSOR ADJUSTMENT | Perform neutral position adjustment of steering angle sensor. |
| DECEL G SEN CALIBRATION | Perform decel G sensor calibration. |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

ECU DIAGNOSIS INFORMATION

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Reference Value

INFOID:000000012853622

CONSULT DATA MONITOR STANDARD VALUE

| Monitor item | Condition | Reference values in normal operation |
|---------------|--|--|
| FR LH SENSOR | Vehicle stopped | 0.00 km/h (MPH) |
| | When driving ^(Note 1) | Nearly matches the speedometer display (within ±10%) |
| FR RH SENSOR | Vehicle stopped | 0.00 km/h (MPH) |
| | When driving ^(Note 1) | Nearly matches the speedometer display (within ±10%) |
| RR LH SENSOR | Vehicle stopped | 0.00 km/h (MPH) |
| | When driving ^(Note 1) | Nearly matches the speedometer display (within ±10%) |
| RR RH SENSOR | Vehicle stopped | 0.00 km/h (MPH) |
| | When driving ^(Note 1) | Nearly matches the speedometer display (within ±10%) |
| DECEL G-SEN | When stopped | Approx. 0 m/s ² |
| | During acceleration | Positive value |
| | During deceleration | Negative value |
| FR RH IN SOL | Active | On |
| | Not activated | Off |
| FR RH OUT SOL | Active | On |
| | Not activated | Off |
| FR LH IN SOL | Active | On |
| | Not activated | Off |
| FR LH OUT SOL | Active | On |
| | Not activated | Off |
| RR RH IN SOL | Active | On |
| | Not activated | Off |
| RR RH OUT SOL | Active | On |
| | Not activated | Off |
| RR LH IN SOL | Active | On |
| | Not activated | Off |
| RR LH OUT SOL | Active | On |
| | Not activated | Off |
| EBD WARN LAMP | When brake warning lamp is ON ^(Note 2) | On |
| | When brake warning lamp is OFF ^(Note 2) | Off |
| STOP LAMP SW | Brake pedal depressed | On |
| | Brake pedal not depressed | Off |
| MOTOR RELAY | Active | On |
| | Not activated | Off |
| ACTUATOR RLY | Active | On |
| | When not operating (in fail-safe mode) | Off |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Condition | Reference values in normal operation |
|---------------|---|---|
| ABS WARN LAMP | When ABS warning lamp is ON ^(Note 2) | On |
| | When ABS warning lamp is OFF ^(Note 2) | Off |
| OFF LAMP | When VDC OFF indicator lamp is ON ^(Note 2) | On |
| | When VDC OFF indicator lamp is OFF ^(Note 2) | Off |
| OFF SW | VDC OFF switch ON (When VDC OFF switch is ON ^(Note 2)) | On |
| | VDC OFF switch OFF (When VDC OFF switch is OFF ^(Note 2)) | Off |
| SLIP/VDC LAMP | When VDC warning lamp is ON ^(Note 2) | On |
| | When VDC warning lamp is OFF ^(Note 2) | Off |
| BATTERY VOLT | Ignition switch ON | 10 – 16 V |
| GEAR | Driving | 1 – 7 Depending on shift status |
| SLCT LVR POSI | Vehicle stopped | N/P Depending on shift status |
| ENGINE SPEED | Engine stopped | 0 tr/min |
| | Engine running | Almost same reading as tachometer |
| YAW RATE SEN | Vehicle stopped | Approx. 0 d/s |
| | Turning right | Negative value |
| | Turning left | Positive value |
| R POSI SIG | When selector lever is in the R position | On |
| | When selector lever is in the other position than R | Off |
| N POSI SIG | When selector lever is in the N position | On |
| | When selector lever is in the other position than N | Off |
| CV1 | Active | On |
| | Not activated | Off |
| CV2 | Active | On |
| | Not activated | Off |
| ACCEL POS SIG | Never depress accelerator pedal (with ignition switch ON) | 0% |
| | Depress accelerator pedal (with ignition switch ON) | 0 – 100% |
| SIDE G-SENSOR | Vehicle stopped | Approx. 0 m/s ² |
| | Right turn | Negative value |
| | Left turn | Positive value |
| STR ANGLE SIG | When driving straight | 0±2.5° |
| | When steering wheel is steered to LH by 90° | Approx. +90° |
| | When steering wheel is steered to RH by 90° | Approx. -90° |
| PRESS SENSOR | Brake pedal not depressed | 0 - 255 bar |
| | Brake pedal depressed | (Pressure increases according to pedal effort.) |
| EBD SIGNAL | EBD activated | On |
| | EBD not activated | Off |
| ABS SIGNAL | ABS is activated | On |
| | ABS is not activated | Off |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Condition | Reference values in normal operation |
|-----------------------------|--|--------------------------------------|
| TCS SIGNAL | TCS activated | On |
| | TCS not activated | Off |
| VDC SIGNAL | VDC activated | On |
| | VDC not activated | Off |
| EBD FAIL SIG | In EBD fail-safe | On |
| | EBD is normal | Off |
| ABS FAIL SIG | In ABS fail-safe | On |
| | ABS is normal | Off |
| TCS FAIL SIG | In TCS fail-safe | On |
| | TCS is normal | Off |
| VDC FAIL SIG | In VDC fail-safe | On |
| | VDC is normal | Off |
| CRANKING SIG | At cranking | On |
| | Other than at cranking | Off |
| FLUID LEV SW | When brake fluid level switch is ON (brake fluid level is less than the specified level) | On |
| | When brake fluid level switch is OFF | Off |
| PARK BRAKE SW | When parking brake is active | On |
| | Parking brake is released | Off |
| USS SIG ^(Note 3) | hill start assist is active | On |
| | hill start assist is inactive | Off |

Note 1: Confirm tire pressure is standard value.

Note 2: Refer to [BRC-13. "System Description"](#) for ON/OFF conditions of each warning lamp and indicator lamp.

Note 3: USS means "hill start assist."

Fail-Safe

INFOID:000000012853623

VDC FUNCTION, TCS FUNCTION, hill start assist FUNCTION AND BRAKE FORCE DISTRIBUTION FUNCTION

VDC warning lamp in combination meter turns ON when a malfunction occurs in the system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, hill start assist function and Brake force distribution function. The vehicle status becomes the same as models without VDC function, TCS function, hill start assist function and Brake force distribution function. However, ABS function and EBD function are operated normally.

ABS FUNCTION

ABS warning lamp and VDC warning lamp in combination meter turn ON when a malfunction occurs in the system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, ABS function, hill start assist function and Brake force distribution function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, hill start assist function and Brake force distribution function. However, EBD function is operated normally.

NOTE:

ABS self-diagnosis sound may be heard the same as in the normal condition because self-diagnosis is performed when ignition switch turns ON and when vehicle initially starts.

EBD FUNCTION

ABS warning lamp, brake warning lamp and VDC warning lamp in combination meter turn ON when a malfunction occurs in the system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, ABS function, EBD function, hill start assist function and Brake force distribution function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, EBD function, hill start assist function and Brake force distribution function.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| DTC | Malfunction detected condition | Fail-safe condition | A | |
|-------|---|---|---|---|
| C1101 | When an open circuit is detected in rear RH wheel sensor circuit. | The following functions are suspended: • VDC function • TCS function • ABS function • EBD function (only when both 2 rear wheels are malfunctioning) • hill start assist function • Brake force distribution function | A | |
| C1102 | When an open circuit is detected in rear LH wheel sensor circuit. | | B | |
| C1103 | When an open circuit is detected in front RH wheel sensor circuit. | | C | |
| C1104 | When an open circuit is detected in front LH wheel sensor circuit. | | D | |
| C1105 | <ul style="list-style-type: none"> • When power supply voltage of rear RH wheel sensor is low. • When distance between rear RH wheel sensor and rear RH wheel sensor rotor is large. • When installation of rear RH wheel sensor or rear RH wheel sensor rotor is not normal. | | E | |
| C1106 | <ul style="list-style-type: none"> • When power supply voltage of rear LH wheel sensor is low. • When distance between rear LH wheel sensor and rear LH wheel sensor rotor is large. • When installation of rear LH wheel sensor or rear LH wheel sensor rotor is not normal. | | BRC | |
| C1107 | <ul style="list-style-type: none"> • When power supply voltage of front RH wheel sensor is low. • When distance between front RH wheel sensor and front RH wheel sensor rotor is large. • When installation of front RH wheel sensor or front RH wheel sensor rotor is not normal. | | G | |
| C1108 | <ul style="list-style-type: none"> • When power supply voltage of front LH wheel sensor is low. • When distance between front LH wheel sensor and front LH wheel sensor rotor is large. • When installation of front LH wheel sensor or front LH wheel sensor rotor is not normal. | | H | |
| C1109 | <ul style="list-style-type: none"> • When ignition voltage is 10 V or less. • When ignition voltage is 16 V or more. | | I | |
| C1111 | When a malfunction is detected in motor or motor relay. | | J | |
| C1113 | When a malfunction is detected in G signal. | | K | |
| C1115 | When difference in wheel speed between any wheel and others is detected during the vehicle is driven because of installation of other tires than specified. | | L | |
| C1116 | When stop lamp switch signal is not input when brake pedal operates. | | M | |
| C1120 | When a malfunction is detected in front LH ABS IN valve. | | The following functions are suspended: • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function | N |
| C1121 | When a malfunction is detected in front LH ABS OUT valve. | | | O |
| C1122 | When a malfunction is detected in front RH ABS IN valve. | | | P |
| C1123 | When a malfunction is detected in front RH ABS OUT valve. | A | | |
| C1124 | When a malfunction is detected in rear LH ABS IN valve. | B | | |
| C1125 | When a malfunction is detected in rear LH ABS OUT valve. | C | | |
| C1126 | When a malfunction is detected in rear RH ABS IN valve. | D | | |
| C1127 | When a malfunction is detected in rear RH ABS OUT valve. | E | | |
| C1130 | When a malfunction is detected in ECM system. | The following functions are suspended: • VDC function • TCS function • hill start assist function • Brake force distribution function | A | |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| DTC | Malfunction detected condition | Fail-safe condition |
|--------|--|---|
| C1140 | When a malfunction is detected in actuator relay. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function |
| C1142 | When a malfunction is detected in pressure sensor. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • hill start assist function • Brake force distribution function |
| C1143 | When a malfunction is detected in steering angle sensor. | |
| C1144 | When neutral position adjustment of steering angle sensor is not complete. | |
| C1145 | When a malfunction is detected in yaw rate signal. | |
| C1146 | When a malfunction is detected in side/decel G signal. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • hill start assist function • Brake force distribution function |
| C1155 | When brake fluid level low signal is detected. | |
| C1160 | When calibration of yaw rate/side/decel G sensor is not complete. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • hill start assist function • Brake force distribution function |
| C1164 | When a malfunction is detected in cut valve 1. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function |
| C1165 | When a malfunction is detected in cut valve 2. | |
| C1170 | When the information in ABS actuator and electric unit (control unit) is not the same. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • ABS function • EBD function • hill start assist function • Brake force distribution function |
| C1197 | When a malfunction is detected in vacuum sensor. | Electrical vacuum assistance of brake booster is suspended. |
| C1198 | <ul style="list-style-type: none"> • When an open circuit is detected in vacuum sensor circuit. • When a short circuit is detected in vacuum sensor circuit. • When a malfunction is detected in vacuum sensor noise. | |
| C1199 | When brake booster vacuum is approx. 0 kPa (0 mmHg) during engine running. | |
| C119A | When a malfunction is detected in supply power voltage of vacuum sensor. | Electrical vacuum assistance of brake booster is suspended. |
| U1000 | When CAN communication signal is not continuously received for 2 seconds or more. | The following functions are suspended: <ul style="list-style-type: none"> • VDC function • TCS function • hill start assist function • Brake force distribution function |
| U0424* | When signal that is transmitted from A/C auto AMP. is not the latest information. | Mode is fixed to the mode when a malfunction of drive mode selector occurs. The mode is fixed to STANDARD mode after ignition switch turns OFF to ON. |

*: This is DTC that is detected in ADAS control unit side.

DTC Inspection Priority Chart

INFOID:000000012853624

When multiple DTCs are displayed simultaneously, check one by one depending on the following priority list.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Priority | Detected item (DTC) | |
|----------|--|---|
| 1 | <ul style="list-style-type: none"> • U1000 CAN COMM CIRCUIT • U0424 HVAC CAN CIR 1* | A |
| 2 | <ul style="list-style-type: none"> • C1170 VARIANT CODING | B |
| 3 | <ul style="list-style-type: none"> • C1130 ENGINE SIGNAL 1 • C1144 ST ANG SEN SIGNAL | |
| 4 | <ul style="list-style-type: none"> • C1109 BATTERY VOLTAGE [ABNOMAL] • C1111 PUMP MOTOR • C1140 ACTUATOR RLY | C |
| 5 | <ul style="list-style-type: none"> • C1101 RR RH SENSOR-1 • C1102 RR LH SENSOR-1 • C1103 FR RH SENSOR-1 • C1104 FR LH SENSOR-1 • C1105 RR RH SENSOR-2 • C1106 RR LH SENSOR-2 • C1107 FR RH SENSOR-2 • C1108 FR LH SENSOR-2 • C1113 G SENSOR • C1115 ABS SENSOR [ABNORMAL SIGNAL] • C1116 STOP LAMP SW • C1120 FR LH IN ABS SOL • C1121 FR LH OUT ABS SOL • C1122 FR RH IN ABS SOL • C1123 FR RH OUT ABS SOL • C1124 RR LH IN ABS SOL • C1125 RR LH OUT ABS SOL • C1126 RR RH IN ABS SOL • C1127 RR RH OUT ABS SOL • C1142 PRESS SEN CIRCUIT • C1143 ST ANG SEN CIRCUIT • C1145 YAW RATE SENSOR • C1146 SIDE G SEN CIRCUIT • C1160 DECEL G SEN SET • C1164 CV 1 • C1165 CV 2 • C1197 VACUUM SENSOR • C1198 VACUUM SEN CIR • C1199 BRAKE BOOSTER • C119A VACUUM SEN VOLT | D E BRC G H I J K |
| 6 | <ul style="list-style-type: none"> • C1155 BR FLUID LEVEL LOW | L |

*: This is DTC that is detected in ADAS control unit side.

DTC Index

INFOID:000000012853625

| DTC | Display Item | Refer to |
|-------|---------------------------|--|
| C1101 | RR RH SENSOR-1 | BRC-86. "DTC Description" |
| C1102 | RR LH SENSOR-1 | |
| C1103 | FR RH SENSOR-1 | |
| C1104 | FR LH SENSOR-1 | |
| C1105 | RR RH SENSOR-2 | BRC-91. "DTC Description" |
| C1106 | RR LH SENSOR-2 | |
| C1107 | FR RH SENSOR-2 | |
| C1108 | FR LH SENSOR-2 | |
| C1109 | BATTERY VOLTAGE [ABNOMAL] | BRC-98. "DTC Description" |
| C1111 | PUMP MOTOR | BRC-100. "DTC Description" |
| C1113 | G SENSOR | BRC-103. "DTC Description" |

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| DTC | Display Item | Refer to |
|--------|------------------------------|--|
| C1115 | ABS SENSOR [ABNORMAL SIGNAL] | BRC-105, "DTC Description" |
| C1116 | STOP LAMP SW | BRC-112, "DTC Description" |
| C1120 | FR LH IN ABS SOL | BRC-118, "DTC Description" |
| C1121 | FR LH OUT ABS SOL | BRC-120, "DTC Description" |
| C1122 | FR RH IN ABS SOL | BRC-118, "DTC Description" |
| C1123 | FR RH OUT ABS SOL | BRC-120, "DTC Description" |
| C1124 | RR LH IN ABS SOL | BRC-118, "DTC Description" |
| C1125 | RR LH OUT ABS SOL | BRC-120, "DTC Description" |
| C1126 | RR RH IN ABS SOL | BRC-118, "DTC Description" |
| C1127 | RR RH OUT ABS SOL | BRC-120, "DTC Description" |
| C1130 | ENGINE SIGNAL 1 | BRC-122, "DTC Description" |
| C1140 | ACTUATOR RLY | BRC-124, "DTC Description" |
| C1142 | PRESS SEN CIRCUIT | BRC-126, "DTC Description" |
| C1143 | ST ANG SEN CIRCUIT | BRC-129, "DTC Description" |
| C1144 | ST ANG SEN SIGNAL | BRC-133, "DTC Description" |
| C1145 | YAW RATE SENSOR | BRC-103, "DTC Description" |
| C1146 | SIDE G SEN CIRCUIT | |
| C1155 | BR FLUID LEVEL LOW | BRC-135, "DTC Description" |
| C1160 | DECEL G SEN SET | BRC-139, "DTC Description" |
| C1164 | CV 1 | BRC-141, "DTC Description" |
| C1165 | CV 2 | |
| C1170 | VARIANT CODING | BRC-143, "DTC Description" |
| C1197 | VACUUM SENSOR | BRC-144, "DTC Description" |
| C1198 | VACUUM SEN CIR | BRC-147, "DTC Description" |
| C1199 | BRAKE BOOSTER | BRC-149, "DTC Description" |
| C119A | VACUUM SEN VOLT | BRC-152, "DTC Description" |
| U1000 | CAN COMM CIRCUIT | BRC-155, "DTC Description" |
| U0424* | HVAC CAN CIR 1 | BRC-156, "DTC Logic" |

*: This DTC is detected in ADAS control unit.

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

ADAS CONTROL UNIT

Reference Value

INFOID:000000014223922

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor item | Condition | | Value/Status |
|---------------|--|--|--------------|
| MAIN SW | Ignition switch ON | When MAIN switch is pressed | On |
| | | When MAIN switch is not pressed | Off |
| SET/COAST SW | Ignition switch ON | When SET/COAST switch is pressed | On |
| | | When SET/COAST switch is not pressed | Off |
| CANCEL SW | Ignition switch ON | When CANCEL switch is pressed | On |
| | | When CANCEL switch is not pressed | Off |
| RESUME/ACC SW | Ignition switch ON | When RESUME/ACCELERATE switch is pressed | On |
| | | When RESUME/ACCELERATE switch is not pressed | Off |
| DISTANCE SW | Ignition switch ON | When DISTANCE switch is pressed | On |
| | | When DISTANCE switch is not pressed | Off |
| CRUISE OPE | Drive the vehicle and activate the vehicle-to-vehicle distance control mode | When ICC system is controlling | On |
| | | When ICC system is not controlling | Off |
| BRAKE SW | Ignition switch ON | When brake or clutch pedal is depressed | Off |
| | | When brake or clutch pedal is not depressed | On |
| STOP LAMP SW | Ignition switch ON | When brake pedal is depressed | On |
| | | When brake pedal is not depressed | Off |
| IDLE SW | Engine running | Idling | On |
| | | Except idling (depress accelerator pedal) | Off |
| SET DISTANCE | <ul style="list-style-type: none"> • Start the engine and turn the ICC system ON • Press the DISTANCE switch to change the vehicle-to-vehicle distance setting | When set to "long" | Long |
| | | When set to "middle" | Mid |
| | | When set to "short" | Short |
| CRUISE LAMP | Start the engine and press MAIN switch | ICC system ON (MAIN switch indicator ON) | On |
| | | ICC system OFF (MAIN switch indicator OFF) | Off |
| OWN VHCL | NOTE: The item is indicated, but not monitored | | Off |
| VHCL AHEAD | Drive the vehicle and activate the vehicle-to-vehicle distance control mode | When a vehicle ahead is detected (vehicle ahead detection indicator ON) | On |
| | | When a vehicle ahead is not detected (vehicle ahead detection indicator OFF) | Off |
| ICC WARNING | Start the engine and press MAIN switch | When ICC system is malfunctioning (ICC system malfunction ON) | On |
| | | When ICC system is normal (ICC system malfunction OFF) | Off |

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Condition | | Value/Status |
|---------------|---|---|--|
| VHCL SPEED SE | While driving | | Displays the vehicle speed calculated by ADAS control unit |
| SET VHCL SPD | While driving | When vehicle speed is set | Displays the set vehicle speed |
| BUZZER O/P | Engine running | When the buzzer of the following system operates <ul style="list-style-type: none"> • Vehicle-to-vehicle distance control mode • DCA system • PFCW system • FEB system | On |
| | | When the buzzer of the following system not operates <ul style="list-style-type: none"> • Vehicle-to-vehicle distance control mode • DCA system • PFCW system • FEB system | Off |
| THRTL SENSOR | NOTE: The item is indicated, but not monitored | | 0.0 |
| ENGINE RPM | Engine running | | Equivalent to tachometer reading |
| WIPER SW | Ignition switch ON | Wiper not operating | Off |
| | | Wiper LO operation | Low |
| | | Wiper HI operation | High |
| YAW RATE | NOTE: The item is indicated, but not monitored | | 0.0 |
| BA WARNING | Engine running | FEB OFF indicator lamp ON <ul style="list-style-type: none"> • When FEB system is malfunctioning • When FEB system is turned to OFF | On |
| | | FEB OFF indicator lamp OFF <ul style="list-style-type: none"> • When FEB system is normal • When FEB system is turned to ON | Off |
| STP LMP DRIVE | Drive the vehicle and activate the vehicle-to-vehicle distance control mode | When ICC brake hold relay is activated | On |
| | | When ICC brake hold relay is not activated | Off |
| D RANGE SW | Engine running | When the selector lever is in "D" position or manual mode | On |
| | | When the selector lever is in any position other than "D" or manual mode | Off |
| NP RANGE SW | Engine running | When the selector lever is in "N", "P" position | On |
| | | When the selector lever is in any position other than "N", "P" | Off |
| PKB SW | Ignition switch ON | When the parking brake is applied | On |
| | | When the parking brake is released | Off |
| PWR SUP MONI | Engine running | | Power supply voltage value of ADAS control unit |
| VHCL SPD AT | While driving | | Value of A/T vehicle speed sensor signal |
| THRTL OPENING | Engine running | Depress accelerator pedal | Displays the throttle position |

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Condition | | Value/Status |
|---------------|---|--|---|
| GEAR | While driving | | Displays the gear position |
| MODE SIG | Start the engine and press MAIN switch | When ICC system is deactivated | Off |
| | | When vehicle-to-vehicle distance control mode is activated | ICC |
| | | When conventional (fixed speed) cruise control mode is activated | ASCD |
| SET DISP IND | <ul style="list-style-type: none"> • Drive the vehicle and activate the conventional (fixed speed) cruise control mode • Press SET/COAST switch | SET switch indicator ON | On |
| | | SET switch indicator OFF | Off |
| DISTANCE | Drive the vehicle and activate the vehicle-to-vehicle distance control mode | When a vehicle ahead is detected | Displays the distance from the preceding vehicle |
| | | When a vehicle ahead is not detected | 0.0 |
| RELATIVE SPD | Drive the vehicle and activate the vehicle-to-vehicle distance control mode | When a vehicle ahead is detected | Displays the relative speed. |
| | | When a vehicle ahead is not detected | 0.0 |
| DYNA ASIST SW | Ignition switch ON | When dynamic driver assistance switch is pressed | On |
| | | When dynamic driver assistance switch is not pressed | Off |
| DCA ON IND | Start the engine and press dynamic driver assistance switch (When DCA setting is ON) | DCA system OFF | Off |
| | | DCA system ON | On |
| DCA VHL AHED | Drive the vehicle and activate the DCA system | When a vehicle ahead is not detected (vehicle ahead detection indicator OFF) | Off |
| | | When a vehicle ahead is detected (vehicle ahead detection indicator ON) | On |
| FCW SYSTEM ON | Ignition switch ON | When the PFCW system is ON | On |
| | | When the PFCW system is OFF | Off |
| APA TEMP | Engine running | | Display the accelerator pedal actuator integrated motor temperature |
| APA PWR | Ignition switch ON | | Power supply voltage value of accelerator pedal actuator |
| LDW SYSTEM ON | Ignition switch ON | When the LDW system is ON | On |
| | | When the LDW system is OFF | Off |
| LDW ON LAMP | Ignition switch ON | When the LDW system is ON | On |
| | | When the LDW system is OFF | Off |
| LDP ON IND | Start the engine and press dynamic driver assistance switch (When LDP system setting is ON) | LDP ON indicator lamp ON | On |
| | | LDP ON indicator lamp OFF | Off |
| LANE DPRT W/L | Drive the vehicle and activate the LDW system or LDP system | Lane departure warning lamp ON | On |
| | | Lane departure warning lamp OFF | Off |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Condition | | Value/Status |
|------------------|--|---|-----------------------------|
| LDW BUZER OUTPUT | Drive the vehicle and activate the LDW/LDP system or Blind Spot Warning/Blind Spot Intervention system | When the buzzer of the following system operates • LDW/LDP system • Blind Spot Warning/Blind Spot Intervention system | On |
| | | When the buzzer of the following system does not operate • LDW/LDP system • Blind Spot Warning/Blind Spot Intervention system | Off |
| LDP SYSTEM ON | Start the engine and press dynamic driver assistance switch (When LDP system setting is ON) | When the LDP system is ON | On |
| | | When the LDP system is OFF | Off |
| WARN REQ | Drive the vehicle and activate the LDP system | Lane departure warning is operating | On |
| | | Lane departure warning is not operating | Off |
| READY signal | Start the engine and press dynamic driver assistance switch (When LDP system setting is ON) | When the LDP system is ON | On |
| | | When the LDP system is OFF | Off |
| Camera lost | Drive the vehicle and activate the LDW system, LDP system or Blind Spot Intervention system | Both side lane markers are detected | Detect |
| | | Deviate side lane marker is lost | Deviate |
| | | Both side lane markers are lost | Both |
| Lane unclear | While driving | Lane marker is unclear | On |
| | | Lane marker is clear | Off |
| STATUS signal | Drive the vehicle and activate the LDP system | When the LDP system is ON | Stnby |
| | | When the LDP system is operating | Warn |
| | | When the LDP system is canceled | Cancl |
| | | When the LDP system is OFF | Off |
| Shift position | <ul style="list-style-type: none"> • Engine running • While driving | | Displays the shift position |
| Turn signal | Turn signal lamps OFF | | Off |
| | Turn signal lamp LH blinking | | LH |
| | Turn signal lamp RH blinking | | RH |
| | Turn signal lamp LH and RH blinking | | LH&RH |
| SIDE G | While driving | Vehicle turning right | Negative value |
| | | Vehicle turning left | Positive value |
| FUNC ITEM | Ignition switch ON | | FUNC3 |
| FUNC ITEM (FCW) | Engine running | | On |
| FUNC ITEM (LDW) | Engine running | | On |
| FUNC ITEM (BSW) | Engine running | | On |
| DCA SELECT | Ignition switch ON | "Distance Control Assist" set with the integral switch is ON | On |
| | | "Distance Control Assist" set with the integral switch is OFF | Off |
| LDP SELECT | Ignition switch ON | "Lane Departure Intervention" set with the integral switch is ON | On |
| | | "Lane Departure Intervention" set with the integral switch is OFF | Off |
| BSI SELECT | Ignition switch ON | "Blind Spot Intervention" set with the integral switch is ON | On |
| | | "Blind Spot Intervention" set with the integral switch is OFF | Off |

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Condition | | Value/Status |
|-----------------------|---|---|--------------|
| FCW SELECT | Ignition switch ON | "Forward Emergency Braking" set with the integral switch is ON | On |
| | | "Forward Emergency Braking" set with the integral switch is OFF | Off |
| LDW SELECT | Ignition switch ON | "Lane Departure Warning" set with the integral switch is ON | On |
| | | "Lane Departure Warning" set with the integral switch is OFF | Off |
| BSW SELECT | Ignition switch ON | "Blind Spot Warning" set with the integral switch is ON | On |
| | | "Blind Spot Warning" set with the integral switch is OFF | Off |
| DRIVE MODE STATS | Ignition switch ON | When drive mode select switch position is STANDARD | STD |
| | | When drive mode select switch position is in SPORT | SPORT |
| | | When drive mode select switch position is in ECO | ECO |
| | | When drive mode select switch position is in SNOW | SNOW |
| | | When drive mode select switch position is in PERSONAL | STD |
| | | A signal other than those above is input | ERROR |
| WARN SYS SW | Ignition switch ON | When warning systems switch is pressed | On |
| | | When warning systems switch is not pressed | Off |
| BSW/BSI WARN LMP | Engine running | When the BSW system is malfunctioning | On |
| | | When the BSW system is normal | Off |
| BSI ON IND | Engine running | Blind Spot Intervention warning ON | On |
| | | Blind Spot Intervention warning OFF | Off |
| BSW SYSTEM ON | Ignition switch ON | When the BSW system is ON | On |
| | | When the BSW system is OFF | Off |
| BSI SYSTEM ON | Start the engine and press dynamic driver assistance switch (When Blind Spot Intervention system setting is ON) | When the Blind Spot Intervention system is ON | On |
| | | When the Blind Spot Intervention system is OFF | Off |
| FCW SYSTEM ON | Engine running | When the FEB/PFCW system is ON | On |
| | | When the FEB/PFCW system is OFF | Off |
| BCI SYSTEM ON | Engine running | When the BCI system is ON | On |
| | | When the BCI system is OFF | Off |
| BCI SWITCH | NOTE: The item is indicated, but not monitored | | Off |
| BATTERY CIRCUIT OFF | NOTE: The item is indicated, but not used | | Off |
| LDP WARNING INDICATOR | Engine running | When the LDP system is malfunctioning | On |
| | | When the LDP system is normal | Off |
| LDW ON INDICATOR | Engine running | LDW system display ON | On |
| | | LDW system display OFF | Off |
| LDW WARNING INDICATOR | Engine running | When the LDW system is malfunctioning | On |
| | | When the LDW system is normal | Off |
| SYSTEM CANCEL MESSAGE | Engine running | When the vehicle is normal | NOREQ |
| | | When the wheel is slipping | SLIP |
| | | When the drive mode selector is SNOW mode | SNOW |
| | | When the VDC is OFF | VDC OFF |

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P


ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Monitor item | Condition | | Value/Status |
|--------------------------|--------------------|--|--------------|
| CAMERA HI TEMP MSG | Engine running | Lane camera unit high temperature warning display ON | On |
| | | Lane camera unit high temperature warning display OFF | Off |
| ITS SETTING ITEM(DCA) | Ignition switch ON | | On |
| ITS SETTING ITEM(LDP) | Ignition switch ON | | On |
| ITS SETTING ITEM(BSI) | Ignition switch ON | | On |
| BSI WARNING INDICATOR | Engine running | When the Blind Spot Intervention is malfunctioning | On |
| | | When the Blind Spot Intervention is normal | Off |
| BSW ON INDICATOR | Engine running | BSW system display ON | On |
| | | BSW system display OFF | Off |
| SIDE RADAR BLOCK COND | Engine running | Front bumper or side radar is dirty | On |
| | | Front bumper and side radar is clean | Off |
| LDW WARNING ALERT TIMING | Ignition switch ON | LDW system OFF | Nothing |
| | | Lane departure warning timing is early setting | Early |
| | | Lane departure warning timing is late setting | Late |
| BSW IND BRIGHTNESS | Ignition switch ON | BSW system OFF | Nothing |
| | | Blind Spot Warning/Blind Spot Intervention indicator brightness bright | Bright |
| | | Blind Spot Warning/Blind Spot Intervention indicator brightness normal | Normal |
| | | Blind Spot Warning/Blind Spot Intervention indicator brightness dark | Dark |

TERMINAL LAYOUT
PHYSICAL VALUES



ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------------------------------|-----------------------------------|------------------|--------------------------|--|------------------------|
| + | - | Signal name | Input/ Output | | | |
| 1 (B) | Ground | CAN high | — | — | — | — |
| 2 (W) | | CAN low | — | — | — | — |
| 5 (B) | | Ground | — | Ignition switch ON | — | 0 V |
| 6 (L) | | ITS communication high | — | — | — | — |
| 7 (Y) | | ITS communication low | — | — | — | — |
| 8 (L) | | Chassis communication high | — | — | — | — |
| 9 (Y) | | Chassis communication low | — | — | — | — |
| 12 (R) | | Ignition power supply | Input | Ignition switch ON | | Battery voltage |
| 17 (G) | | ICC brake hold relay drive signal | Output | Ignition switch ON | — At "STOP LAMP" test of "Active test" | Battery voltage 0 V |
| 18 (BR) | | Warning systems switch | Input | Ignition switch ON | When warning systems switch is not pressed | Battery voltage |
| | | | | | When warning systems switch is pressed | 0 V |
| 19 (W) | | Warning systems ON indicator | Output | Ignition switch ON | Warning systems ON indicator ON | 0 V |
| | | | | | Warning systems ON indicator OFF | Battery voltage |
| 22 (BG) | | BCI OFF switch | Input | Ignition switch ON | When BCI OFF switch is not pressed | Battery voltage |
| | When BCI OFF switch is pressed | | | | 0 V | |

A
B
C
D
E
BRC
G
H
I
J
K

Fail-safe (ADAS Control Unit)

INFOID:000000014223923

If a malfunction occurs in each system, ADAS control unit cancels each control, sounds a beep, and turns ON the warning or indicator lamp.

| System | Buzzer | Warning lamp/Warning display | Description |
|--|-------------------|------------------------------|-------------|
| Vehicle-to-vehicle distance control mode | High-pitched tone | ICC system warning | Cancel |
| Conventional (fixed speed) cruise control mode | High-pitched tone | ICC system warning | Cancel |
| Forward Emergency Braking (FEB) | High-pitched tone | FEB warning | Cancel |
| Predictive Forward Collision Warning (PFCW) | High-pitched tone | Warning message | Cancel |
| Distance Control Assist (DCA) | High-pitched tone | DCA system warning | Cancel |
| Lane Departure Warning (LDW) | — | Lane departure warning lamp | Cancel |

L
M
N
O
P

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| System | Buzzer | Warning lamp/Warning display | Description |
|-------------------------------------|-------------------|---|-------------|
| Lane Departure Prevention (LDP) | Low-pitched tone | Lane departure warning lamp | Cancel |
| Blind Spot Warning (BSW) | — | Blind Spot Warning warning lamp | Cancel |
| Blind Spot Intervention | Low-pitched tone | Blind Spot Intervention warning lamp | Cancel |
| Backup Collision Intervention (BCI) | High-pitched tone | Backup Collision Intervention warning indicator | Cancel |
| Rear Cross Traffic Alert (RCTA) | — | Rear Cross Traffic Alert warning | Cancel |

DTC Inspection Priority Chart

INFOID:0000000014223924

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

| Priority | Detected items (DTC) | |
|----------|---|--|
| 1 | <ul style="list-style-type: none"> • U1507: LOST COMM (SIDE RDR R) • U1508: LOST COMM (SIDE RDR L) | |
| 2 | <ul style="list-style-type: none"> • 1CA0A: CONFIG UNFINISHED • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN) | |
| 3 | <ul style="list-style-type: none"> • C1B00: CAMERA UNIT MALF • C1F02: APA C/U MALF • C1B53: SIDE RDR R MALF • C1B54: SIDE RDR L MALF • C1B84: DIST SEN MALFUNCTION | |
| 4 | <ul style="list-style-type: none"> • C1A01: POWER SUPPLY CIR • C1A02: POWER SUPPLY CIR 2 • C1A04: ABS/TCS/VDC CIRC • C1A05: BRAKE SW/STOP L SW • C1A06: OPERATION SW CIRC • C1A13: STOP LAMP RLY FIX • C1A14: ECM CIRCUIT • C1A24: NP RANGE • C1A26: ECD MODE MALF • C1A27: ECD PWR SUPPLY CIR • C1A33: CAN TRANSMISSION ERR • C1A34: COMMAND ERROR • C1A35: APA CIR • C1A36: APA CAN COMM CIR • C1A37: APA CAN CIR 2 • C1A38: APA CAN CIR 1 • C1A39: STRG SEN CIR • C1A40: SYSTEM SW CIR • C1B01: CAM AIMING INCOMP • C1B03: CAM ABNORMAL TMP DETCT • C1B56: SONAR CIRCUIT • C1B57: AVM CIRCUIT • C1B58: DR ASSIST BUZZER CIRCUIT • C1B82: DIST SEN OFF-CENTER • C1B85: DIST SEN ABNORMAL TEMP • C1B86: DIST SEN PWR SUP CIR • C1F01: APA MOTOR MALF • C1F05: APA PWR SUPPLY CIR | <ul style="list-style-type: none"> • U0121: VDC CAN CIR 2 • U0126: STRG SEN CAN CIR 1 • U0235: ICC SENSOR CAN CIRC 1 • U0401: ECM CAN CIR 1 • U0402: TCM CAN CIR 1 • U0415: VDC CAN CIR 1 • U0424: HVAC CAN CIR 1 • U0428: STRG SEN CAN CIR 2 • U1500: CAM CAN CIR 2 • U1501: CAM CAN CIR 1 • U1502: ICC SEN CAN COMM CIR • U1503: SIDE RDR L CAN CIR 2 • U1504: SIDE RDR L CAN CIR 1 • U1505: SIDE RDR R CAN CIR 2 • U1506: SIDE RDR R CAN CIR 1 • U150B: ECM CAN CIRC 3 • U150C: VDC CAN CIRC 3 • U150D: TCM CAN CIRC 3 • U150E: BCM CAN CIRC 3 • U1512: HVAC CAN CIRC3 • U1513: METER CAN CIRC 3 • U1514: STRG SEN CAN CIRC 3 • U1515: ICC SENSOR CAN CIRC 3 • U1516: CAM CAN CIR 3 • U1517: APA CAN CIRC 3 • U1518: SIDE RDR L CAN CIRC 3 • U1519: SIDE RDR R CAN CIRC 3 • U1521: SONAR CAN COMMUNICATION 2 • U1522: SONAR CAN COMMUNICATION 1 • U1523: SONAR CAN COMMUNICATION 3 • U1524: AVM CAN COMMUNICATION 1 • U1525: AVM CAN COMMUNICATION 3 • U1530: DR ASSIST BUZZER CAN CIR 1 |

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

| Priority | Detected items (DTC) |
|----------|-----------------------------|
| 5 | • C1A03: VHCL SPEED SE CIRC |
| 6 | • C1A15: GEAR POSITION |
| 7 | • C1A00: CONTROL UNIT |

DTC Index

INFOID:0000000014223925

Systems for fail-safe

- A: Vehicle-to-vehicle distance control mode
- B: Conventional (fixed speed) cruise control mode
- C: Distance Control Assist (DCA)
- D: Forward Emergency Braking (FEB)
- E: Predictive Forward Collision Warning (PFCW)
- F: Blind Spot Warning (BSW)/Blind Spot Intervention (BSI)/Rear Cross Traffic Alert (RCTA)
- G: Back-up Collision Intervention (BCI)
- H: Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)

| DTC | | CONSULT display | Fail-safe | Reference |
|---|------------------|---|------------------------|-------------------------|
| CONSULT | On board display | | System | |
| NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED | 55 | NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED | — | — |
| C1A0A | 41 | CONFIG UNFINISHED | A, B, C, D, E, F, G, H | DAS-68 |
| C1A00 | 0 | CONTROL UNIT | A, B, C, D, E, F, G, H | DAS-69 |
| C1A01 | 1 | POWER SUPPLY CIR | A, B, C, D, E, F, G, H | DAS-70 |
| C1A02 | 2 | POWER SUPPLY CIR 2 | A, B, C, D, E, F, G, H | DAS-70 |
| C1A03 | 3 | VHCL SPEED SE CIRC | A, B, C, D, E, F, G, H | DAS-71 |
| C1A04 | 4 | ABS/TCS/VDC CIRC | A, B, C, D, E, F, G, H | DAS-73 |
| C1A05 | 5 | BRAKE SW/STOP L SW | A, B, C, D, G, H | DAS-75 |
| C1A06 | 6 | OPERATION SW CIRC | A, B, C, D, E, H | DAS-80 |
| C1A13 | 13 | STOP LAMP RLY FIX | A, B, C, D, E, G | DAS-82 |
| C1A14 | 14 | ECM CIRCUIT | A, B, C, D, E | DAS-89 |
| C1A15 | 15 | GEAR POSITION | A, B, C, D, E | DAS-91 |
| C1A24 | 24 | NP RANGE | A, B, C, D, E, F, G | DAS-93 |
| C1A26 | 26 | ECD MODE MALF | A, B, C, D, G | DAS-95 |
| C1A27 | 27 | ECD PWR SUPPLY CIR | A, B, C, D, G | DAS-97 |
| C1A33 | 33 | CAN TRANSMISSION ERR | A, B, C, D, E | DAS-99 |
| C1A34 | 34 | COMMAND ERROR | A, B, C, D, E | DAS-100 |
| C1A35 | 35 | APA CIR | A, C, D, E | DAS-101 |
| C1A36 | 36 | APA CAN COMM CIR | A, C, D, E | DAS-102 |
| C1A37 | 133 | APA CAN CIR 2 | A, C, D, E | DAS-103 |
| C1A38 | 132 | APA CAN CIR 1 | A, C, D, E | DAS-104 |
| C1A39 | 39 | STRG SEN CIR | A, B, C, D, E, F, G | DAS-105 |
| C1A40 | 40 | SYSTEM SW CIR | G | DAS-105 |
| C1B00 | 81 | CAMERA UNIT MALF | F, H | DAS-108 |
| C1B01 | 82 | CAM AIMING INCOMP | F, H | DAS-109 |
| C1B03 | 83 | ABNRML TMP DETCT | F, H | DAS-110 |
| C1B53 | 84 | SIDE RDR R MALF | F, G | DAS-111 |

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Systems for fail-safe

- A: Vehicle-to-vehicle distance control mode
- B: Conventional (fixed speed) cruise control mode
- C: Distance Control Assist (DCA)
- D: Forward Emergency Braking (FEB)
- E: Predictive Forward Collision Warning (PFCW)
- F: Blind Spot Warning (BSW)/Blind Spot Intervention (BSI)/Rear Cross Traffic Alert (RCTA)
- G: Back-up Collision Intervention (BCI)
- H: Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)

| DTC | | CONSULT display | Fail-safe | Reference |
|-----------------------|------------------|--------------------------|------------------------|-------------------------|
| CONSULT | On board display | | System | |
| C1B54 | 85 | SIDE RDR L MALF | F, G | DAS-112 |
| C1B56 | 86 | SONAR CIRCUIT | G | DAS-113 |
| C1B57 | 87 | AVM CIRCUIT | G | DAS-114 |
| C1A58 | 182 | DR ASSIST BUZZER CIRCUIT | | DAS-115 |
| C1B82 | 12 | DIST SEN OFF-CENTER | A, C, D, E | DAS-116 |
| C1B83 | 16 | DIST SEN BLOCKED | A, C, D, E | DAS-117 |
| C1B84 | 17 | DIST SEN MALFUNCTION | A, C, D, E | DAS-118 |
| C1B85 | 21 | DIST SEN ABNORMAL TEMP | A, C, D, E | DAS-119 |
| C1B86 | 80 | DIST SEN PWR SUP CIR | A, C, D, E | DAS-120 |
| C1F01 | 91 | APA MOTOR MALF | A, C, D, E | DAS-122 |
| C1F02 | 92 | APA C/U MALF | A, C, D, E | DAS-123 |
| C1F05 | 95 | APA PWR SUPPLY CIR | A, C, D, E | DAS-124 |
| U0121 | 127 | VDC CAN CIR 2 | A, B, C, D, E, F, G, H | DAS-125 |
| U0126 | 130 | STRG SEN CAN CIR 1 | A, B, C, D, E, F, G | DAS-126 |
| U0235 | 144 | ICC SENSOR CAN CIRC 1 | A, C, D, E | DAS-127 |
| U0401 | 120 | ECM CAN CIR 1 | A, B, C, D, E, F, G | DAS-128 |
| U0402 | 122 | TCM CAN CIR 1 | A, B, C, D, E, F, G, H | DAS-129 |
| U0415 | 126 | VDC CAN CIR 1 | A, B, C, D, E, F, G, H | DAS-131 |
| U0424 | 156 | HVAC CAN CIR 1 | | DAS-133 |
| U0428 | 131 | STRG SEN CAN CIR 2 | A, B, C, D, E, F, G | DAS-134 |
| U1000 ^{NOTE} | 100 | CAN COMM CIRCUIT | A, B, C, D, E, F, G, H | DAS-135 |
| U1010 | 110 | CONTROL UNIT (CAN) | A, B, C, D, E, F, G, H | DAS-137 |
| U150B | 157 | ECM CAN CIRC 3 | A, B, C, D, E, F, G, H | DAS-138 |
| U150C | 158 | VDC CAN CIRC 3 | A, B, C, D, E, F, G, H | DAS-140 |
| U150D | 159 | TCM CAN CIRC 3 | A, B, C, D, E, F, G, H | DAS-142 |
| U150E | 160 | BCM CAN CIRC 3 | A, B, C, D, F, G, H | DAS-144 |
| U1500 | 145 | CAM CAN CIR2 | F, H | DAS-145 |
| U1501 | 146 | CAM CAN CIR 1 | F, H | DAS-146 |
| U1502 | 147 | ICC SEN CAN COMM CIR | A, C, D, E | DAS-147 |
| U1503 | 150 | SIDE RDR L CAN CIR 2 | F, G | DAS-148 |
| U1504 | 151 | SIDE RDR L CAN CIR 1 | F, G | DAS-149 |
| U1505 | 152 | SIDE RDR R CAN CIR 2 | F, G | DAS-150 |
| U1506 | 153 | SIDE RDR R CAN CIR 1 | F, G | DAS-151 |
| U1507 | 154 | LOST COMM (SIDE RDR R) | F, G | DAS-152 |
| U1508 | 155 | LOST COMM (SIDE RDR L) | F, G | DAS-153 |
| U1512 | 162 | HVAC CAN CIRC3 | | DAS-154 |

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Systems for fail-safe

- A: Vehicle-to-vehicle distance control mode
- B: Conventional (fixed speed) cruise control mode
- C: Distance Control Assist (DCA)
- D: Forward Emergency Braking (FEB)
- E: Predictive Forward Collision Warning (PFCW)
- F: Blind Spot Warning (BSW)/Blind Spot Intervention (BSI)/Rear Cross Traffic Alert (RCTA)
- G: Back-up Collision Intervention (BCI)
- H: Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)

| DTC | | CONSULT display | Fail-safe | Reference |
|---------|------------------|---------------------------|------------------------|-------------------------|
| CONSULT | On board display | | System | |
| U1513 | 163 | METER CAN CIRC 3 | A, B, C, D, E, F, G, H | DAS-155 |
| U1514 | 164 | STRG SEN CAN CIRC 3 | A, B, C, D, E, F, G | DAS-156 |
| U1515 | 165 | ICC SENSOR CAN CIRC 3 | A, C, D, E | DAS-157 |
| U1516 | 166 | CAM CAN CIRC 3 | F, H | DAS-158 |
| U1517 | 167 | APA CAN CIRC 3 | A, C, D, E | DAS-159 |
| U1518 | 168 | SIDE RDR L CAN CIRC 3 | F, G | DAS-160 |
| U1519 | 169 | SIDE RDR R CAN CIRC 3 | F, G | DAS-161 |
| U1521 | 177 | SONAR CAN COMMUNICATION 2 | G | DAS-163 |
| U1522 | 178 | SONAR CAN COMMUNICATION 1 | G | DAS-164 |
| U1523 | 179 | SONAR CAN COMMUNICATION 3 | G | DAS-165 |
| U1524 | 180 | AVM CAN COMMUNICATION 1 | G | DAS-166 |
| U1525 | 181 | AVM CAN COMMUNICATION 3 | G | DAS-167 |
| U1530 | 183 | DR ASSIST BUZZER CAN CIR1 | | DAS-168 |

NOTE:

With the detection of “U1000” some systems do not perform the fail-safe operation.

A system controlling based on a signal received from the control unit performs fail-safe operation when the communication with the ADAS control unit becomes inoperable.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >


[VDC/TCS/ABS]

WIRING DIAGRAM

BRAKE CONTROL SYSTEM

Wiring Diagram

INFOID:000000012853627




AAFWA0210GB

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]

(B) : WITHOUT INTELLIGENT CRUISE CONTROL
 (C) : WITH INTELLIGENT CRUISE CONTROL
 (NX) : EXCEPT FOR MEXICO
 (XX) : FOR MEXICO
 *1 : (NX) : 124 (XX) : 114
 *2 : (NX) : 123 (XX) : 113
 *3 : (NX) : 139 (XX) : 122



AAFWA0211GB


A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]

⬠ IC ⬠ : WITH INTELLIGENT CRUISE CONTROL



AAFWA0212GB



BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]



BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | B13 |
| Connector Name | WIRE TO WIRE |
| Connector Type | RH12FB-RS2 |
| Connector Color | BLACK |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------|
| 1 | L | TO CHASSIS HARNESS |
| 2 | W | TO CHASSIS HARNESS |
| 3 | V | TO CHASSIS HARNESS |
| 4 | SB | TO CHASSIS HARNESS |
| 5 | BR | TO CHASSIS HARNESS |
| 6 | Y | TO CHASSIS HARNESS |
| 7 | B | TO CHASSIS HARNESS |
| 8 | LG | TO CHASSIS HARNESS |
| 9 | Y | TO CHASSIS HARNESS |
| 10 | BR | TO CHASSIS HARNESS |
| 11 | P | TO CHASSIS HARNESS |
| 12 | L | TO CHASSIS HARNESS |
| 13 | LG | TO CHASSIS HARNESS |
| 14 | V | TO CHASSIS HARNESS |

| | |
|-----------------|--------------|
| Connector No. | B32 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32FW-NH |
| Connector Color | WHITE |






| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------|
| 1 | - | TO BODY HARNESS RH |
| 2 | - | TO BODY HARNESS RH |
| 3 | - | TO BODY HARNESS RH |
| 4 | - | TO BODY HARNESS RH |
| 5 | G | TO BODY HARNESS RH |
| 6 | R | TO BODY HARNESS RH |
| 7 | B | TO BODY HARNESS RH |
| 8 | R | TO BODY HARNESS RH |
| 9 | W | TO BODY HARNESS RH |

AAFIA0538GB



| | | |
|----|--------|--------------------|
| 10 | SHIELD | TO BODY HARNESS RH |
| 11 | B | TO BODY HARNESS RH |
| 12 | L | TO BODY HARNESS RH |
| 13 | B | TO BODY HARNESS RH |
| 14 | R | TO BODY HARNESS RH |
| 15 | W | TO BODY HARNESS RH |
| 16 | SHIELD | TO BODY HARNESS RH |
| 17 | L | TO BODY HARNESS RH |
| 18 | L | TO BODY HARNESS RH |
| 19 | P | TO BODY HARNESS RH |
| 20 | Y | TO BODY HARNESS RH |
| 21 | L | TO BODY HARNESS RH |
| 22 | B | TO BODY HARNESS RH |
| 23 | W | TO BODY HARNESS RH |
| 24 | SHIELD | TO BODY HARNESS RH |
| 25 | BR | TO BODY HARNESS RH |
| 26 | V | TO BODY HARNESS RH |
| 27 | - | TO BODY HARNESS RH |
| 28 | - | TO BODY HARNESS RH |
| 29 | - | TO BODY HARNESS RH |
| 30 | - | TO BODY HARNESS RH |
| 31 | - | TO BODY HARNESS RH |
| 32 | - | TO BODY HARNESS RH |

| | |
|-----------------|-------------------------------------|
| Connector No. | B36 |
| Connector Name | EVAP CONTROL SYSTEM PRESSURE SENSOR |
| Connector Type | E03FGY-RS |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | GND |
| 2 | W | OUTPUT |
| 3 | R | POWER |

| | |
|-----------------|--------------|
| Connector No. | B40 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24MW-NH |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------------|
| 1 | LG | TO ENGINE ROOM HARNESS |
| 2 | Y | TO ENGINE ROOM HARNESS |
| 3 | R | TO ENGINE ROOM HARNESS |
| 4 | G | TO ENGINE ROOM HARNESS |
| 5 | W | TO ENGINE ROOM HARNESS |
| 6 | SHIELD | TO ENGINE ROOM HARNESS |
| 7 | R | TO ENGINE ROOM HARNESS |
| 8 | G | TO ENGINE ROOM HARNESS |
| 9 | B | TO ENGINE ROOM HARNESS |
| 10 | W | TO ENGINE ROOM HARNESS |
| 11 | - | TO ENGINE ROOM HARNESS |
| 12 | - | TO ENGINE ROOM HARNESS |
| 13 | L | TO ENGINE ROOM HARNESS |
| 14 | P | TO ENGINE ROOM HARNESS |
| 15 | BR | TO ENGINE ROOM HARNESS |
| 16 | Y | TO ENGINE ROOM HARNESS |
| 17 | BR | TO ENGINE ROOM HARNESS |
| 18 | Y | TO ENGINE ROOM HARNESS |
| 19 | LG | TO ENGINE ROOM HARNESS |
| 20 | SB | TO ENGINE ROOM HARNESS |
| 21 | W | TO ENGINE ROOM HARNESS |
| 22 | W | TO ENGINE ROOM HARNESS |
| 23 | W | TO ENGINE ROOM HARNESS |
| 24 | - | TO ENGINE ROOM HARNESS |

| | |
|-----------------|---------------------|
| Connector No. | B63 |
| Connector Name | JOINT CONNECTOR-B01 |
| Connector Type | BJ30FW |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | L | ITS CAN-H |
| 2 | L | ITS CAN-H |
| 3 | L | ITS CAN-H |
| 4 | Y | ITS CAN-L |
| 5 | Y | ITS CAN-L |
| 6 | Y | ITS CAN-L |
| 7 | - | - |
| 8 | SHIELD | GND |
| 9 | B | GND |
| 10 | B | GND |
| 11 | B | GND |
| 12 | LG | ILLUMI CONT OUT |
| 13 | LG | ILLUMI CONT OUT |
| 14 | LG | ILLUMI CONT OUT |
| 15 | - | - |
| 16 | W | ALERT SIGNAL |
| 17 | W | ALERT SIGNAL |
| 18 | - | - |
| 19 | B | GND |
| 20 | B | GND |
| 21 | SHIELD | SHIELD |
| 22 | B | GND |
| 23 | - | - |
| 24 | - | - |
| 25 | SHIELD | SHIELD |
| 26 | B | GND |
| 27 | B | GND |
| 28 | B | GND |
| 29 | W | TAIL |
| 30 | W | TAIL |
| 31 | W | TAIL |
| 32 | W | TAIL |
| 33 | W | TAIL |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC


BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|-------------------|
| Connector No. | B69 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MDGY-CS16-TM4 |
| Connector Color | GRAY |



| | | |
|-----|--------|---|
| 25A | SHIELD | TO MAIN HARNESS |
| 26A | B | TO MAIN HARNESS |
| 27A | B | TO MAIN HARNESS |
| 28A | SHIELD | TO MAIN HARNESS |
| 29A | R | TO MAIN HARNESS |
| 30A | B | TO MAIN HARNESS |
| 31A | BR | TO MAIN HARNESS |
| 32A | - | TO MAIN HARNESS |
| 33A | W | TO MAIN HARNESS |
| 34A | B | TO MAIN HARNESS |
| 35A | SHIELD | TO MAIN HARNESS |
| 36A | - | TO MAIN HARNESS |
| 37A | LG | TO MAIN HARNESS |
| 38A | V | TO MAIN HARNESS |
| 39A | SB | TO MAIN HARNESS |
| 40A | BR | TO MAIN HARNESS |
| 41A | Y | TO MAIN HARNESS |
| 42A | - | TO MAIN HARNESS |
| 43A | - | TO MAIN HARNESS |
| 44A | V | TO MAIN HARNESS |
| 45A | G | TO MAIN HARNESS |
| 46A | V | TO MAIN HARNESS |
| 47A | L | TO MAIN HARNESS |
| 48A | SB | TO MAIN HARNESS |
| 49A | G | TO MAIN HARNESS |
| 50A | W | TO MAIN HARNESS |
| 51A | - | TO MAIN HARNESS |
| 52A | - | TO MAIN HARNESS |
| 53A | R | TO MAIN HARNESS |
| 54A | SB | TO MAIN HARNESS |
| 55A | LG | TO MAIN HARNESS |
| 56A | Y | TO MAIN HARNESS |
| 57A | SB | TO MAIN HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 57A | V | TO MAIN HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 58A | BR | TO MAIN HARNESS |
| 59A | BR | TO MAIN HARNESS |
| 60A | L | TO MAIN HARNESS |
| 61A | Y | TO MAIN HARNESS |
| 62A | - | TO MAIN HARNESS |
| 63A | P | TO MAIN HARNESS |
| 64A | R | TO MAIN HARNESS |
| 65A | SB | TO MAIN HARNESS |
| 66A | L | TO MAIN HARNESS |
| 67A | LG | TO MAIN HARNESS |
| 68A | P | TO MAIN HARNESS |
| 69A | W | TO MAIN HARNESS |
| 70A | G | TO MAIN HARNESS |
| 71A | BR | TO MAIN HARNESS |
| 72A | - | TO MAIN HARNESS |
| 73A | Y | TO MAIN HARNESS |
| 74A | P | TO MAIN HARNESS |
| 75A | V | TO MAIN HARNESS |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 1A | - | TO MAIN HARNESS |
| 2A | Y | TO MAIN HARNESS |
| 3A | Y | TO MAIN HARNESS |
| 4A | G | TO MAIN HARNESS |
| 5A | - | TO MAIN HARNESS |
| 6A | LG | TO MAIN HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 6A | R | TO MAIN HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 7A | BR | TO MAIN HARNESS |
| 8A | G | TO MAIN HARNESS |
| 9A | P | TO MAIN HARNESS |
| 10A | - | TO MAIN HARNESS |
| 11A | W | TO MAIN HARNESS |
| 12A | G | TO MAIN HARNESS |
| 13A | - | TO MAIN HARNESS |
| 14A | R | TO MAIN HARNESS |
| 15A | G | TO MAIN HARNESS |
| 16A | W | TO MAIN HARNESS |
| 17A | B | TO MAIN HARNESS |
| 18A | B | TO MAIN HARNESS |
| 19A | SHIELD | TO MAIN HARNESS |
| 20A | W | TO MAIN HARNESS |
| 21A | SHIELD | TO MAIN HARNESS |
| 22A | - | TO MAIN HARNESS |
| 23A | W | TO MAIN HARNESS |
| 24A | B | TO MAIN HARNESS |

AAFI00539GB


| | | |
|------|--------|-----------------|
| 76A | R | TO MAIN HARNESS |
| 77A | Y | TO MAIN HARNESS |
| 78A | LG | TO MAIN HARNESS |
| 79A | BR | TO MAIN HARNESS |
| 80A | Y | TO MAIN HARNESS |
| 81A | L | TO MAIN HARNESS |
| 82A | BG | TO MAIN HARNESS |
| 83A | Y | TO MAIN HARNESS |
| 84A | LG | TO MAIN HARNESS |
| 85A | SHIELD | TO MAIN HARNESS |
| 86A | LG | TO MAIN HARNESS |
| 87A | SB | TO MAIN HARNESS |
| 88A | BG | TO MAIN HARNESS |
| 89A | L | TO MAIN HARNESS |
| 90A | P | TO MAIN HARNESS |
| 91A | L | TO MAIN HARNESS |
| 92A | LG | TO MAIN HARNESS |
| 93A | B | TO MAIN HARNESS |
| 94A | - | TO MAIN HARNESS |
| 95A | - | TO MAIN HARNESS |
| 96A | - | TO MAIN HARNESS |
| 97A | BR | TO MAIN HARNESS |
| 98A | L | TO MAIN HARNESS |
| 99A | - | TO MAIN HARNESS |
| 100A | - | TO MAIN HARNESS |

| | |
|-----------------|--------------|
| Connector No. | B101 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32MW-NH |
| Connector Color | WHITE |



| | | |
|----|--------|---|
| 7 | W | TO MAIN HARNESS - (WITH REAR ENTERTAINMENT SYSTEM) |
| 8 | B | TO MAIN HARNESS - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 8 | R | TO MAIN HARNESS - (WITH REAR ENTERTAINMENT SYSTEM) |
| 9 | SHIELD | TO MAIN HARNESS |
| 10 | G | TO MAIN HARNESS |
| 11 | SB | TO MAIN HARNESS |
| 12 | P | TO MAIN HARNESS |
| 13 | W | TO MAIN HARNESS |
| 14 | - | TO MAIN HARNESS |
| 15 | - | TO MAIN HARNESS |
| 16 | - | TO MAIN HARNESS |
| 17 | L | TO MAIN HARNESS |
| 18 | P | TO MAIN HARNESS |
| 19 | LG | TO MAIN HARNESS |
| 20 | BR | TO MAIN HARNESS |
| 21 | LG | TO MAIN HARNESS |
| 22 | LG | TO MAIN HARNESS |
| 23 | W | TO MAIN HARNESS |
| 24 | V | TO MAIN HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 24 | BR | TO MAIN HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 25 | SB | TO MAIN HARNESS |
| 26 | LG | TO MAIN HARNESS |
| 27 | Y | TO MAIN HARNESS |
| 28 | Y | TO MAIN HARNESS |
| 29 | SB | TO MAIN HARNESS |
| 30 | LG | TO MAIN HARNESS |
| 31 | G | TO MAIN HARNESS |
| 32 | - | TO MAIN HARNESS |

| | |
|-----------------|---------------------|
| Connector No. | B102 |
| Connector Name | JOINT CONNECTOR-B14 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 2 | L | CAN-H |
| 3 | B | CAN-H |
| 4 | - | - |


BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]


BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|---------------------|
| Connector No. | B103 |
| Connector Name | JOINT CONNECTOR-B15 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | CAN-L |
| 2 | P | CAN-L |
| 3 | W | CAN-L |
| 4 | - | - |

| | |
|-----------------|-------------------|
| Connector No. | B104 |
| Connector Name | ADAS CONTROL UNIT |
| Connector Type | TH24FW-NH |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------|
| 1 | B | CAN-H |
| 2 | W | CAN-L |
| 3 | - | - |
| 4 | - | - |
| 5 | B | GND |
| 6 | L | ITS CAN-H |
| 7 | Y | ITS CAN-L |
| 8 | L | IC CAN-H |
| 9 | Y | IC CAN-L |
| 10 | - | - |
| 11 | - | - |
| 12 | R | IGN |
| 13 | - | - |
| 14 | - | - |
| 15 | - | - |
| 16 | - | - |
| 17 | G | BRK-RLY |
| 18 | BR | ITS ALERT SW |
| 19 | W | ITS ALERT SW LED |

AAFIA0540GB

| | |
|----|---|
| 20 | - |
| 21 | - |
| 22 | - |
| 23 | - |
| 24 | - |

| | |
|-----------------|---------------------|
| Connector No. | B115 |
| Connector Name | JOINT CONNECTOR-B08 |
| Connector Type | BJ30FW |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 1 | - | - |
| 2 | - | - |
| 3 | - | - |
| 4 | - | - |
| 5 | - | - |
| 6 | - | - |
| 7 | - | - |
| 8 | - | - |
| 9 | B | GND |
| 10 | GR | GND |
| 11 | SHIELD | SHIELD |
| 12 | - | - |
| 13 | - | - |
| 14 | - | - |
| 15 | - | - |
| 16 | - | - |
| 17 | - | - |
| 18 | - | - |
| 19 | R | IGNITION |
| 20 | R | IGNITION |
| 21 | R | IGNITION |
| 22 | - | - |
| 23 | - | - |
| 24 | - | - |
| 25 | - | - |
| 26 | - | - |
| 27 | W | ALERT SIGNAL |
| 28 | W | ALERT SIGNAL |
| 29 | B | ADDRESS |
| 30 | B | GND |
| 31 | GR | GND |
| 32 | SHIELD | SHIELD |

| | | |
|----|---|-----|
| 33 | B | GND |
|----|---|-----|

| | |
|-----------------|--------------|
| Connector No. | B124 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32MW-NH |
| Connector Color | WHITE |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | - | TO BODY HARNESS |
| 2 | - | TO BODY HARNESS |
| 3 | - | TO BODY HARNESS |
| 4 | - | TO BODY HARNESS |
| 5 | G | TO BODY HARNESS |
| 6 | R | TO BODY HARNESS |
| 7 | G | TO BODY HARNESS |
| 8 | R | TO BODY HARNESS |
| 9 | W | TO BODY HARNESS |
| 10 | SHIELD | TO BODY HARNESS |
| 11 | B | TO BODY HARNESS |
| 12 | L | TO BODY HARNESS |
| 13 | G | TO BODY HARNESS |
| 14 | R | TO BODY HARNESS |
| 15 | W | TO BODY HARNESS |
| 16 | SHIELD | TO BODY HARNESS |
| 17 | Y | TO BODY HARNESS |
| 18 | L | TO BODY HARNESS |
| 19 | P | TO BODY HARNESS |
| 20 | Y | TO BODY HARNESS |
| 21 | L | TO BODY HARNESS |
| 22 | B | TO BODY HARNESS |
| 23 | W | TO BODY HARNESS |
| 24 | SHIELD | TO BODY HARNESS |
| 25 | BR | TO BODY HARNESS |
| 26 | V | TO BODY HARNESS |
| 27 | - | TO BODY HARNESS |
| 28 | - | TO BODY HARNESS |
| 29 | - | TO BODY HARNESS |
| 30 | - | TO BODY HARNESS |
| 31 | - | TO BODY HARNESS |
| 32 | - | TO BODY HARNESS |

| | |
|-----------------|---------------------|
| Connector No. | B146 |
| Connector Name | JOINT CONNECTOR-B12 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | ITS CAN-H |
| 2 | L | ITS CAN-H |
| 3 | L | ITS CAN-H |
| 4 | - | - |

| | |
|-----------------|---------------------|
| Connector No. | B147 |
| Connector Name | JOINT CONNECTOR-B13 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | ITS CAN-L |
| 2 | Y | ITS CAN-L |
| 3 | Y | ITS CAN-L |
| 4 | - | - |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|----------------------|
| Connector No. | C10 |
| Connector Name | REAR WHEEL SENSOR LH |
| Connector Type | RH02MB |
| Connector Color | BLACK |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | B | POWER |
| 2 | W | SIGNAL |


| | |
|-----------------|----------------------|
| Connector No. | C11 |
| Connector Name | REAR WHEEL SENSOR RH |
| Connector Type | RH02FGY |
| Connector Color | GRAY |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | V | POWER |
| 2 | P | SIGNAL |

| | |
|-----------------|--------------|
| Connector No. | C13 |
| Connector Name | WIRE TO WIRE |
| Connector Type | RH12MB-RS2 |
| Connector Color | BLACK |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | L | TO BODY HARNESS |
| 2 | G | TO BODY HARNESS |
| 3 | BG | TO BODY HARNESS |

AAFIA0541GB

| | | |
|----|----|-----------------|
| 4 | BR | TO BODY HARNESS |
| 5 | W | TO BODY HARNESS |
| 6 | Y | TO BODY HARNESS |
| 7 | B | TO BODY HARNESS |
| 8 | LG | TO BODY HARNESS |
| 9 | W | TO BODY HARNESS |
| 10 | B | TO BODY HARNESS |
| 11 | P | TO BODY HARNESS |
| 12 | V | TO BODY HARNESS |
| 13 | SB | TO BODY HARNESS |
| 14 | Y | TO BODY HARNESS |

| | |
|-----------------|--------------|
| Connector No. | E2 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16MW-NH |
| Connector Color | WHITE |




H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 1 | R | TO ENGINE CONTROL HARNESS - (EXCEPT FOR MEXICO) |
| 1 | G | TO ENGINE CONTROL HARNESS - (FOR MEXICO) |
| 2 | W | TO ENGINE CONTROL HARNESS |
| 3 | W | TO ENGINE CONTROL HARNESS - (EXCEPT FOR MEXICO) |
| 3 | L | TO ENGINE CONTROL HARNESS - (FOR MEXICO) |
| 4 | L | TO ENGINE CONTROL HARNESS - (EXCEPT FOR MEXICO) |
| 4 | SB | TO ENGINE CONTROL HARNESS - (FOR MEXICO) |
| 5 | GR | TO ENGINE CONTROL HARNESS |
| 6 | L | TO ENGINE CONTROL HARNESS |
| 7 | P | TO ENGINE CONTROL HARNESS |
| 8 | LG | TO ENGINE CONTROL HARNESS |
| 9 | P | TO ENGINE CONTROL HARNESS |
| 10 | L | TO ENGINE CONTROL HARNESS |
| 11 | LG | TO ENGINE CONTROL HARNESS |
| 12 | Y | TO ENGINE CONTROL HARNESS |
| 13 | LG | TO ENGINE CONTROL HARNESS |
| 14 | V | TO ENGINE CONTROL HARNESS |
| 15 | GR | TO ENGINE CONTROL HARNESS - (EXCEPT FOR MEXICO) |
| 15 | R | TO ENGINE CONTROL HARNESS - (FOR MEXICO) |
| 16 | P | TO ENGINE CONTROL HARNESS - (FOR MEXICO) |

| | | |
|----|---|---|
| 16 | B | TO ENGINE CONTROL HARNESS - (EXCEPT FOR MEXICO) |
|----|---|---|

| | |
|-----------------|------------------|
| Connector No. | E16 |
| Connector Name | ECM (FOR MEXICO) |
| Connector Type | RH24FGY-RZ8-RH |
| Connector Color | GRAY |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 97 | W | ACCELERATOR PEDAL POSITION SENSOR 1 (WITHOUT ICC SYSTEM) |
| 97 | R | ACCELERATOR PEDAL POSITION SENSOR 1 (WITH ICC SYSTEM) |
| 98 | P | ACCELERATOR PEDAL POSITION SENSOR 2 (WITHOUT ICC SYSTEM) |
| 98 | B | ACCELERATOR PEDAL POSITION SENSOR 2 (WITH ICC SYSTEM) |
| 99 | R | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 1) (WITHOUT ICC SYSTEM) |
| 99 | G | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 1) (WITH ICC SYSTEM) |
| 100 | R | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 1) (WITHOUT ICC SYSTEM) |
| 100 | W | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 1) (WITH ICC SYSTEM) |
| 101 | G | ASCD STEERING SWITCH/ICC STEERING SWITCH |
| 102 | O | EVAP CONTROL SYSTEM PRESSURE SENSOR |
| 103 | W | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 2) (WITHOUT ICC SYSTEM) |
| 103 | Y | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 2) (WITH ICC SYSTEM) |
| 104 | P | DATA LINK CONNECTOR |
| 105 | - | - |
| 106 | Y | EVAP CANISTER VENT CONTROL VALVE |
| 107 | W | SENSOR POWER SUPPLY (EVAP CONTROL SYSTEM PRESSURE SENSOR) (WITHOUT ICC SYSTEM) |
| 108 | R | SENSOR GROUND (ASCD STEERING SWITCH) |

| | | |
|-----|----|---|
| 109 | SB | IGNITION SWITCH |
| 110 | - | - |
| 111 | BR | FUEL TANK TEMPERATURE SENSOR |
| 112 | G | SENSOR GROUND (EVAP CONTROL SYSTEM PRESSURE SENSOR, ENGINE OIL PRESSURE SENSOR) |
| 113 | P | CAN-L |
| 114 | L | CAN-H |
| 115 | - | - |
| 116 | G | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 2) (WITHOUT ICC SYSTEM) |
| 116 | L | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 2) (WITH ICC SYSTEM) |
| 117 | - | - |
| 118 | W | PNP SIGNAL |
| 119 | - | - |
| 120 | LG | SENSOR GROUND (FUEL TANK TEMPERATURE SENSOR) |
| 121 | LG | POWER SUPPLY FOR ECM |
| 122 | R | STOP LAMP SWITCH |
| 123 | B | ECM GND |
| 124 | B | ECM GND |
| 125 | - | - |
| 126 | LG | BRAKE PEDAL POSITION SWITCH |
| 127 | B | ECM GND |
| 128 | B | ECM GND |

| | |
|-----------------|-----------------------|
| Connector No. | E18 |
| Connector Name | FRONT WHEEL SENSOR LH |
| Connector Type | RH02MB |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | POWER |
| 2 | W | SIGNAL |

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|--------------------------|
| Connector No. | E21 |
| Connector Name | BRAKE FLUID LEVEL SWITCH |
| Connector Type | YV02FGY |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 1 | W | BRAKE OIL SW |
| 2 | B | GROUND |

| | |
|-----------------|--------------|
| Connector No. | E26 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24MW-NH |
| Connector Color | WHITE |



| | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 |
| 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------|
| 1 | R | TO FRONT END MODULE HARNESS |
| 2 | W | TO FRONT END MODULE HARNESS |
| 3 | B | TO FRONT END MODULE HARNESS |
| 4 | SHIELD | TO FRONT END MODULE HARNESS |
| 5 | B | TO FRONT END MODULE HARNESS |
| 6 | R | TO FRONT END MODULE HARNESS |
| 7 | W | TO FRONT END MODULE HARNESS |
| 8 | SHIELD | TO FRONT END MODULE HARNESS |
| 9 | Y | TO FRONT END MODULE HARNESS |
| 10 | BG | TO FRONT END MODULE HARNESS |
| 11 | G | TO FRONT END MODULE HARNESS |
| 12 | W | TO FRONT END MODULE HARNESS |

AAFIA0542GB

| | | |
|----|--------|-----------------------------|
| 13 | R | TO FRONT END MODULE HARNESS |
| 14 | B | TO FRONT END MODULE HARNESS |
| 15 | G | TO FRONT END MODULE HARNESS |
| 16 | SHIELD | TO FRONT END MODULE HARNESS |
| 17 | W | TO FRONT END MODULE HARNESS |
| 18 | P | TO FRONT END MODULE HARNESS |
| 19 | W | TO FRONT END MODULE HARNESS |
| 20 | R | TO FRONT END MODULE HARNESS |
| 21 | W | TO FRONT END MODULE HARNESS |
| 22 | BR | TO FRONT END MODULE HARNESS |
| 23 | V | TO FRONT END MODULE HARNESS |
| 24 | SB | TO FRONT END MODULE HARNESS |


| | |
|-----------------|------------------|
| Connector No. | E28 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS10FW-CS |
| Connector Color | WHITE |



| | | | |
|-----|----|----|----|
| 4M | 3M | 2M | 1M |
| 10M | 9M | 8M | 7M |
| 6M | 5M | | |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------|
| 1M | R | IGNITION |
| 2M | - | - |
| 3M | - | - |
| 4M | - | - |
| 5M | Y | BATTERY |
| 6M | L | TAIL LH |
| 7M | P | BRAKE PEDAL POSITION SWITCH |
| 8M | R | BRAKE PEDAL POSITION SWITCH |
| 9M | - | - |
| 10M | - | - |

| | |
|-----------------|-------------------------|
| Connector No. | E32 |
| Connector Name | ECM (EXCEPT FOR MEXICO) |
| Connector Type | RH24FB-RZ8-L-LH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 121 | W | EVAP CONTROL SYSTEM PRESSURE SENSOR |
| 122 | - | - |
| 123 | P | CAN-L |
| 124 | L | CAN-H |
| 125 | R | POWER SUPPLY (EVAP CONTROL SYSTEM PRESSURE SENSOR) |
| 126 | - | - |
| 127 | - | - |
| 128 | BR | FUEL TANK TEMPERATURE SENSOR |
| 129 | - | - |
| 130 | - | - |
| 131 | - | - |
| 132 | - | - |
| 133 | SB | POWER SUPPLY STEERING SWITCH |
| 134 | G | ASC/D STEERING SWITCH/ICC |
| 135 | R | SENSOR GROUND |
| 136 | - | - |
| 137 | - | - |
| 138 | - | - |
| 139 | R | STOP LAMP SWITCH |
| 140 | LG | BRAKE PEDAL POSITION SWITCH |
| 141 | Y | EVAP CANISTER VENT CONTROL VALVE |
| 142 | Y | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 2) (WITH ICC SYSTEM) |
| 142 | W | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 2) (WITHOUT ICC SYSTEM) |
| 143 | B | ACCELE PEDAL POSITION SENSOR 2 (WITH ICC SYSTEM) |
| 143 | P | ACCELE PEDAL POSITION SENSOR 2 (WITHOUT ICC SYSTEM) |
| 144 | L | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 2) (WITH ICC SYSTEM) |

| | | |
|-----|----|--|
| 144 | G | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 2) (WITHOUT ICC SYSTEM) |
| 145 | LG | POWER SUPPLY FOR ECM |
| 146 | G | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 1) (WITH ICC SYSTEM) |
| 146 | R | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 1) (WITHOUT ICC SYSTEM) |
| 147 | B | SENSOR GROUND |
| 148 | LG | SENSOR GROUND |
| 149 | B | SENSOR GROUND |
| 150 | R | ACCELE PEDAL POSITION SENSOR 1 (WITH ICC SYSTEM) |
| 150 | W | ACCELE PEDAL POSITION SENSOR 1 (WITHOUT ICC SYSTEM) |
| 151 | W | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 1) (WITH ICC SYSTEM) |
| 151 | R | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 1) (WITHOUT ICC SYSTEM) |
| 152 | B | SENSOR GROUND |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC



BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >



[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | E34 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24FW-NH |
| Connector Color | WHITE |

| | |
|-----------------|------------------|
| Connector No. | E38 |
| Connector Name | STOP LAMP SWITCH |
| Connector Type | M04FW-LC |
| Connector Color | WHITE |






| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------------------------|
| 1 | Y | TO BODY HARNESS |
| 2 | L | TO BODY HARNESS |
| 3 | R | TO BODY HARNESS - (EXCEPT FOR MEXICO) |
| 3 | W | TO BODY HARNESS - (FOR MEXICO) |
| 4 | LG | TO BODY HARNESS - (EXCEPT FOR MEXICO) |
| 4 | G | TO BODY HARNESS - (FOR MEXICO) |
| 5 | W | TO BODY HARNESS - (EXCEPT FOR MEXICO) |
| 5 | BG | TO BODY HARNESS - (FOR MEXICO) |
| 6 | SHIELD | TO BODY HARNESS |
| 7 | W | TO BODY HARNESS |
| 8 | G | TO BODY HARNESS |
| 9 | R | TO BODY HARNESS |
| 10 | B | TO BODY HARNESS |
| 11 | R/G | TO BODY HARNESS |
| 12 | R/L | TO BODY HARNESS |
| 13 | BG | TO BODY HARNESS |
| 14 | P | TO BODY HARNESS |
| 15 | R | TO BODY HARNESS |
| 16 | G | TO BODY HARNESS |
| 17 | Y | TO BODY HARNESS |
| 18 | L | TO BODY HARNESS |
| 19 | R | TO BODY HARNESS |
| 20 | LG | TO BODY HARNESS |
| 21 | SB | TO BODY HARNESS |
| 22 | G | TO BODY HARNESS |
| 23 | LG | TO BODY HARNESS |
| 24 | LG | TO BODY HARNESS |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------|
| 1 | Y | BATT |
| 2 | P | BRAKE PEDAL POSITION SWITCH |
| 3 | Y | BATT |
| 4 | G | STP |






| | |
|-----------------|-----------------------|
| Connector No. | E43 |
| Connector Name | FRONT WHEEL SENSOR RH |
| Connector Type | RH02MB |
| Connector Color | BLACK |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | POWER |
| 2 | W | SIGNAL |






| | |
|-----------------|---------------------|
| Connector No. | E44 |
| Connector Name | JOINT CONNECTOR-E01 |
| Connector Type | BJ30FW |
| Connector Color | WHITE |






| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------|
| 1 | W | SENSOR POWER SUPPLY |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------------------------|
| 2 | W | SENSOR POWER SUPPLY |
| 3 | W | SENSOR POWER SUPPLY |
| 4 | R | BATTERY |
| 5 | R | BATTERY |
| 6 | R | BATTERY |
| 7 | - | - |
| 8 | LG | BATTERY |
| 9 | LG | BATTERY |
| 10 | LG | BATTERY |
| 11 | LG | BATTERY |
| 12 | P | BATTERY |
| 13 | P | BATTERY |
| 14 | P | BATTERY |
| 15 | GR | GND |
| 16 | B | GND |
| 17 | B | GND |
| 18 | - | - |
| 19 | Y | BATTERY |
| 20 | Y | BATTERY |
| 21 | Y | BATTERY |
| 22 | Y | BATTERY |
| 23 | BG | EVAP CONTROL SYSTEM PRESSURE SENSOR |
| 24 | O | EVAP CONTROL SYSTEM PRESSURE SENSOR |
| 25 | - | - |
| 26 | G | GND |
| 27 | G | GND |
| 28 | G | GND |
| 29 | - | - |
| 30 | V | BATTERY |
| 31 | LG | BATTERY |
| 32 | V | BATTERY |
| 33 | V | BATTERY |






| | |
|-----------------|---------------------|
| Connector No. | E45 |
| Connector Name | JOINT CONNECTOR-E12 |
| Connector Type | A12FL |
| Connector Color | BLUE |






| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 2 | L | CAN-H |
| 3 | L | CAN-H |
| 4 | L | CAN-H |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 5 | - | - |
| 6 | - | - |
| 7 | P | CAN-L |
| 8 | P | CAN-L |
| 9 | P | CAN-L |
| 10 | P | CAN-L |
| 11 | - | - |
| 12 | - | - |






| | |
|-----------------|----------------------|
| Connector No. | E52 |
| Connector Name | PARKING BRAKE SWITCH |
| Connector Type | P01FB-A |
| Connector Color | BLACK |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | LG | PKB |

| | |
|-----------------|--------------|
| Connector No. | E56 |
| Connector Name | VDC RESISTOR |
| Connector Type | M02FBR-LC |
| Connector Color | BROWN |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | CSW |
| 2 | GR | GND |



BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]


BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|---------------------|
| Connector No. | E70 |
| Connector Name | JOINT CONNECTOR-E14 |
| Connector Type | RH06FB |
| Connector Color | BLACK |






| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | CAN-L |
| 2 | P | CAN-L |
| 3 | P | CAN-L |
| 4 | P | CAN-L |
| 5 | - | - |
| 6 | - | - |

| | |
|-----------------|---------------------|
| Connector No. | E71 |
| Connector Name | JOINT CONNECTOR-E15 |
| Connector Type | RH06FB |
| Connector Color | BLACK |






| | |
|-----------------|----------------------|
| Connector No. | E75 |
| Connector Name | ICC BRAKE HOLD RELAY |
| Connector Type | MS02FL-M2-LC |
| Connector Color | BLUE |






| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------|
| 1 | W | BRAKE HOLD RLY DRIVE SIGNAL |
| 2 | R | IGN |
| 3 | P | BRAKE PEDAL POSITION SWITCH |
| 5 | Y | BATT |

| | |
|-----------------|---------------------|
| Connector No. | E106 |
| Connector Name | JOINT CONNECTOR-E06 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |






| | |
|-----------------|---------------------|
| Connector No. | E108 |
| Connector Name | JOINT CONNECTOR-E07 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | CAN-L |
| 2 | Y | CAN-L |
| 3 | Y | CAN-L |
| 4 | - | - |

| | |
|-----------------|--|
| Connector No. | E119 |
| Connector Name | IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM) |
| Connector Type | TH32FW-NH |
| Connector Color | WHITE |

| | | |
|----|----|-----------------|
| 36 | W | START (G-E/R) |
| 37 | W | CLUTCH/L SW |
| 38 | P | PUSH START SW |
| 39 | - | - |
| 40 | - | - |
| 41 | B | GND (SIGNAL) |
| 42 | - | - |
| 43 | L | IGN SIGNAL |
| 44 | - | - |
| 45 | LG | PD SENS SIG-E/R |
| 46 | - | - |
| 47 | Y | PD SENS PWR-E/R |
| 48 | V | PD SENS GND-E/R |
| 49 | - | - |
| 50 | - | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | BG | CAN-H |
| 2 | BG | CAN-H |
| 3 | BG | CAN-H |
| 4 | - | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------|
| 19 | SB | SUB ECU |
| 20 | - | - |
| 21 | SB | BCM IGNSW |
| 22 | W | HORN RLY |
| 23 | LG | HORN SW |
| 24 | - | - |
| 25 | - | - |
| 26 | - | - |
| 27 | B | MOTOR FAN RLY MID |
| 28 | P | CAN-L |
| 29 | L | CAN-H |
| 30 | - | - |
| 31 | BG | DETENT SW |
| 32 | - | - |
| 33 | R | START CONT |
| 34 | GR | WIPER AUTOSTOP |
| 35 | BR | ABS ECU |

AAFIA0544GB

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >


[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|---|
| Connector No. | E125 |
| Connector Name | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) |
| Connector Type | SAZ34FB-HS2-SJSZ2-UH |
| Connector Color | BLACK |




| | |
|-----------------|-----------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |
| Connector Color | WHITE |



| | | |
|-----|--------|-----------------|
| 23G | SHIELD | TO MAIN HARNESS |
| 24G | R | TO MAIN HARNESS |
| 25G | W | TO MAIN HARNESS |
| 26G | SHIELD | TO MAIN HARNESS |
| 27G | W | TO MAIN HARNESS |
| 28G | R | TO MAIN HARNESS |
| 29G | B | TO MAIN HARNESS |
| 30G | G | TO MAIN HARNESS |
| 31G | L | TO MAIN HARNESS |
| 32G | LG | TO MAIN HARNESS |
| 33G | LG | TO MAIN HARNESS |
| 34G | W | TO MAIN HARNESS |
| 35G | P | TO MAIN HARNESS |
| 36G | L | TO MAIN HARNESS |
| 37G | BG | TO MAIN HARNESS |
| 38G | W | TO MAIN HARNESS |
| 39G | W | TO MAIN HARNESS |
| 40G | Y | TO MAIN HARNESS |
| 41G | BG | TO MAIN HARNESS |
| 42G | P | TO MAIN HARNESS |
| 43G | R | TO MAIN HARNESS |
| 44G | W | TO MAIN HARNESS |
| 45G | Y | TO MAIN HARNESS |
| 46G | SB | TO MAIN HARNESS |
| 47G | V | TO MAIN HARNESS |
| 48G | BR | TO MAIN HARNESS |
| 49G | W | TO MAIN HARNESS |
| 50G | G | TO MAIN HARNESS |
| 51G | B/W | TO MAIN HARNESS |
| 52G | BR | TO MAIN HARNESS |
| 53G | L | TO MAIN HARNESS |
| 54G | P | TO MAIN HARNESS |
| 55G | BR | TO MAIN HARNESS |
| 56G | R | TO MAIN HARNESS |
| 57G | P | TO MAIN HARNESS |
| 58G | BG | TO MAIN HARNESS |
| 59G | W | TO MAIN HARNESS |
| 60G | B | TO MAIN HARNESS |
| 61G | SHIELD | TO MAIN HARNESS |
| 62G | P | TO MAIN HARNESS |
| 63G | L | TO MAIN HARNESS |
| 64G | R | TO MAIN HARNESS |
| 65G | G/R | TO MAIN HARNESS |
| 66G | R | TO MAIN HARNESS |
| 67G | BG | TO MAIN HARNESS |
| 68G | LG/R | TO MAIN HARNESS |
| 69G | W | TO MAIN HARNESS |
| 70G | G | TO MAIN HARNESS |
| 71G | GR | TO MAIN HARNESS |
| 72G | GR | TO MAIN HARNESS |
| 73G | W | TO MAIN HARNESS |
| 74G | W | TO MAIN HARNESS |
| 75G | G | TO MAIN HARNESS |

| | | |
|------|--------|-----------------|
| 76G | Y | TO MAIN HARNESS |
| 77G | BR | TO MAIN HARNESS |
| 78G | - | TO MAIN HARNESS |
| 79G | P | TO MAIN HARNESS |
| 80G | G | TO MAIN HARNESS |
| 81G | R | TO MAIN HARNESS |
| 82G | - | TO MAIN HARNESS |
| 83G | - | TO MAIN HARNESS |
| 84G | - | TO MAIN HARNESS |
| 85G | - | TO MAIN HARNESS |
| 86G | - | TO MAIN HARNESS |
| 87G | - | TO MAIN HARNESS |
| 88G | - | TO MAIN HARNESS |
| 89G | R | TO MAIN HARNESS |
| 90G | L | TO MAIN HARNESS |
| 91G | L | TO MAIN HARNESS |
| 92G | - | TO MAIN HARNESS |
| 93G | - | TO MAIN HARNESS |
| 94G | Y | TO MAIN HARNESS |
| 95G | W | TO MAIN HARNESS |
| 96G | - | TO MAIN HARNESS |
| 97G | - | TO MAIN HARNESS |
| 98G | - | TO MAIN HARNESS |
| 99G | - | TO MAIN HARNESS |
| 100G | SHIELD | TO MAIN HARNESS |

| | |
|-----------------|---------------|
| Connector No. | E167 |
| Connector Name | VACUUM SENSOR |
| Connector Type | RH03FB |
| Connector Color | BLACK |



| | | |
|--------------|---------------|-----------------|
| Terminal No. | Color of Wire | Signal Name |
| 1G | G | TO MAIN HARNESS |
| 2G | W | TO MAIN HARNESS |
| 3G | P | TO MAIN HARNESS |
| 4G | R | TO MAIN HARNESS |
| 5G | P | TO MAIN HARNESS |
| 6G | W | TO MAIN HARNESS |
| 7G | SHIELD | TO MAIN HARNESS |
| 8G | G | TO MAIN HARNESS |
| 9G | LG | TO MAIN HARNESS |
| 10G | P | TO MAIN HARNESS |
| 11G | G | TO MAIN HARNESS |
| 12G | P | TO MAIN HARNESS |
| 13G | W | TO MAIN HARNESS |
| 14G | BG | TO MAIN HARNESS |
| 15G | W | TO MAIN HARNESS |
| 16G | R | TO MAIN HARNESS |
| 17G | B | TO MAIN HARNESS |
| 18G | SHIELD | TO MAIN HARNESS |
| 19G | W | TO MAIN HARNESS |
| 20G | G | TO MAIN HARNESS |
| 21G | P | TO MAIN HARNESS |
| 22G | B | TO MAIN HARNESS |

| | | |
|--------------|---------------|--|
| Terminal No. | Color of Wire | Signal Name |
| 1 | R | SOLENOID (POWER) |
| 2 | B | ECU (GND) |
| 3 | W | MOTOR (POWER) |
| 4 | B/W | MOTOR (GND) |
| 5 | - | - |
| 6 | - | - |
| 7 | P | STOP LAMP SW (WITHOUT CC) |
| 8 | G | STOP LAMP SW (WITH INTELLIGENT CRUISE CONTROL) |
| 9 | - | - |
| 10 | R | VDC-OFF SW |
| 11 | - | - |
| 12 | G | FR RH SEN (POWER) |
| 13 | W | FR RH SEN (SIGNAL) |
| 14 | R | FR LH SEN (POWER) |
| 15 | G | FR LH SEN (SIGNAL) |
| 16 | - | - |
| 17 | - | - |
| 18 | - | - |
| 19 | L | CAN-H |
| 20 | SHIELD | VAC SEN (GND) |
| 21 | B | VAC SEN (POWER) |
| 22 | W | WAC SEN (SIGNAL) |
| 23 | G | FR LH SEN (POWER) |
| 24 | W | FR LH SEN (SIGNAL) |
| 25 | BG | RR RH SEN (POWER) |
| 26 | P | RR RH SEN (SIGNAL) |
| 27 | - | - |
| 28 | BR | IGN (POWER) |
| 29 | - | - |
| 30 | P | CAN-L |
| 31 | - | - |
| 32 | - | - |
| 33 | - | - |
| 34 | - | - |
| 35 | - | - |

AAFIA0545GB



BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >



[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | E209 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24FW-NH |
| Connector Color | WHITE |



| | |
|-----------------|------------|
| Connector No. | E219 |
| Connector Name | ICC SENSOR |
| Connector Type | AA208FB |
| Connector Color | BLACK |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------------|
| 1 | Y | TO ENGINE ROOM HARNESS |
| 2 | L | TO ENGINE ROOM HARNESS |
| 3 | B | TO ENGINE ROOM HARNESS |
| 4 | SHIELD | TO ENGINE ROOM HARNESS |
| 5 | B | TO ENGINE ROOM HARNESS |
| 6 | R | TO ENGINE ROOM HARNESS |
| 7 | W | TO ENGINE ROOM HARNESS |
| 8 | SHIELD | TO ENGINE ROOM HARNESS |
| 9 | Y | TO ENGINE ROOM HARNESS |
| 10 | L | TO ENGINE ROOM HARNESS |
| 11 | SB | TO ENGINE ROOM HARNESS |
| 12 | Y | TO ENGINE ROOM HARNESS |
| 13 | R | TO ENGINE ROOM HARNESS |
| 14 | B | TO ENGINE ROOM HARNESS |
| 15 | G | TO ENGINE ROOM HARNESS |
| 16 | SHIELD | TO ENGINE ROOM HARNESS |
| 17 | W | TO ENGINE ROOM HARNESS |
| 18 | L | TO ENGINE ROOM HARNESS |
| 19 | Y | TO ENGINE ROOM HARNESS |
| 20 | V | TO ENGINE ROOM HARNESS |
| 21 | G | TO ENGINE ROOM HARNESS |
| 22 | L | TO ENGINE ROOM HARNESS |
| 23 | G | TO ENGINE ROOM HARNESS |
| 24 | R | TO ENGINE ROOM HARNESS |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | UBAT |
| 2 | - | - |
| 3 | L | CAN 1 H |
| 4 | - | - |
| 5 | - | - |
| 6 | Y | CAN 1 L |
| 7 | - | - |
| 8 | B | GND |



| | |
|-----------------|--|
| Connector No. | F25 |
| Connector Name | TCM (TRANSMISSION CONTROL MODULE) (FOR MEXICO) |
| Connector Type | RH40FB-RZ8-L-RH |
| Connector Color | BLACK |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------|
| 1 | - | - |
| 2 | SB | L RANGE SW |
| 3 | - | - |
| 4 | Y | D RANGE SW |
| 5 | L | N RANGE SW |
| 6 | BR | R RANGE SW |
| 7 | V | P RANGE SW |
| 8 | - | - |
| 9 | - | - |
| 10 | - | - |
| 11 | Y | SENSOR GND |
| 12 | LG | CVT FLUID TEMP SENS |
| 13 | - | - |

| | | | |
|----|----|----------------------|---|
| 14 | - | - | - |
| 15 | - | - | - |
| 16 | Y | SEC PRESS SENS | - |
| 17 | LG | PRI PRESS SENS | - |
| 18 | - | - | - |
| 19 | - | - | - |
| 20 | - | - | - |
| 21 | - | - | - |
| 22 | - | - | - |
| 23 | P | CAN-L | - |
| 24 | LG | INPUT SPEED SENS | - |
| 25 | - | - | - |
| 26 | LG | SENS PWR SUPPLY | - |
| 27 | - | - | - |
| 28 | - | - | - |
| 29 | - | - | - |
| 30 | SB | LINE PRESS SOL VALVE | - |
| 31 | - | - | - |
| 32 | - | - | - |
| 33 | L | CAN-H | - |
| 34 | BR | OUTPUT SPEED SENS | - |
| 35 | LG | PRI SPEED SENS | - |
| 36 | - | - | - |
| 37 | BR | SELECT SOL VALVE | - |
| 38 | Y | TCC SOLE VALVE | - |
| 39 | L | SEC PRESS SOLE VALVE | - |
| 40 | V | PRI PRESS SOLE VALVE | - |
| 41 | B | GND | - |
| 42 | B | GND | - |
| 43 | - | - | - |
| 44 | - | - | - |
| 45 | LG | BATT | - |
| 46 | LG | BATT | - |
| 47 | Y | VIGN | - |
| 48 | Y | VIGN | - |

| | |
|-----------------|--------------|
| Connector No. | F32 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16FW-NH |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 1 | L | TO ENGINE ROOM HARNESS - (EXCEPT FOR MEXICO) |

| | | |
|----|----|--|
| 1 | BR | TO ENGINE ROOM HARNESS - (FOR MEXICO) |
| 2 | Y | TO ENGINE ROOM HARNESS |
| 3 | R | TO ENGINE ROOM HARNESS - (EXCEPT FOR MEXICO) |
| 3 | L | TO ENGINE ROOM HARNESS - (FOR MEXICO) |
| 4 | L | TO ENGINE ROOM HARNESS - (EXCEPT FOR MEXICO) |
| 4 | W | TO ENGINE ROOM HARNESS - (FOR MEXICO) |
| 5 | B | TO ENGINE ROOM HARNESS |
| 6 | L | TO ENGINE ROOM HARNESS |
| 7 | GR | TO ENGINE ROOM HARNESS |
| 8 | Y | TO ENGINE ROOM HARNESS |
| 9 | P | TO ENGINE ROOM HARNESS |
| 10 | L | TO ENGINE ROOM HARNESS |
| 11 | Y | TO ENGINE ROOM HARNESS - (EXCEPT FOR MEXICO) |
| 12 | Y | TO ENGINE ROOM HARNESS - (FOR MEXICO) |
| 12 | P | TO ENGINE ROOM HARNESS - (FOR MEXICO) |
| 13 | SB | TO ENGINE ROOM HARNESS |
| 14 | V | TO ENGINE ROOM HARNESS |
| 15 | B | TO ENGINE ROOM HARNESS - (EXCEPT FOR MEXICO) |
| 15 | L | TO ENGINE ROOM HARNESS - (FOR MEXICO) |
| 16 | GR | TO ENGINE ROOM HARNESS - (FOR MEXICO) |
| 16 | B | TO ENGINE ROOM HARNESS - (EXCEPT FOR MEXICO) |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|---|
| Connector No. | F89 |
| Connector Name | TCM (TRANSMISSION CONTROL MODULE) (EXCEPT FOR MEXICO) |
| Connector Type | RH40FB-RZ8-L-RH |
| Connector Color | BLACK |

| | | |
|----|----|----------------------|
| 38 | Y | TCC SOLE VALVE |
| 39 | L | SEC PRESS SOLE VALVE |
| 40 | V | PRI PRESS SOLE VALVE |
| 41 | B | GND |
| 42 | B | GND |
| 43 | - | - |
| 44 | - | - |
| 45 | LG | BATT |
| 46 | LG | BATT |
| 47 | Y | VIGN |
| 48 | Y | VIGN |

| | |
|-----------------|------------------|
| Connector No. | M4 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS16FW-CS |
| Connector Color | WHITE |

| | |
|-----------------|-------------|
| Connector No. | M5 |
| Connector Name | CAN GATEWAY |
| Connector Type | TH12FW-NH |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 2 | - | - |
| 3 | BG | BAT |
| 4 | L | CAN-H |
| 5 | B | GND |
| 6 | L | CAN-H |
| 7 | P | CAN-L |
| 8 | - | - |
| 9 | BG | IGN |
| 10 | P | CAN-L |
| 11 | B | GND |
| 12 | P | CAN-L |

| | |
|-----------------|---------------------|
| Connector No. | M11 |
| Connector Name | JOINT CONNECTOR-M03 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------------|
| 1P | R | IGNITION |
| 2P | LG | IGNITION |
| 3P | G | IGN ELEC RELAY OUT 2 |
| 4P | - | - |
| 5P | P | IGNITION |
| 6P | BG | REAR DEFOGGER RELAY OUT |
| 7P | LG | IGNITION |
| 8P | BG | IGNITION |
| 9P | L | BATTERY |
| 10P | BR | IGNITION |
| 11P | - | - |
| 12P | - | - |
| 13P | W | BATTERY |
| 14P | Y | BATTERY |
| 15P | L | BATT |
| 16P | W | BLOWER FAN RELAY OUT |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------------|
| 1 | - | - |
| 2 | SB | L RANGE SW |
| 3 | - | - |
| 4 | Y | D RANGE SW |
| 5 | L | N RANGE SW |
| 6 | BR | R RANGE SW |
| 7 | V | P RANGE SW |
| 8 | - | - |
| 9 | - | - |
| 10 | - | - |
| 11 | Y | SENSOR GND |
| 12 | LG | CVT FLUID TEMP SENS |
| 13 | - | - |
| 14 | - | - |
| 15 | - | - |
| 16 | Y | SEC PRESS SENS |
| 17 | LG | PRI PRESS SENS |
| 18 | - | - |
| 19 | - | - |
| 20 | - | - |
| 21 | - | - |
| 22 | - | - |
| 23 | P | CAN-L |
| 24 | LG | INPUT SPEED SENS |
| 25 | - | - |
| 26 | LG | SENS PWR SUPPLY |
| 27 | G | VDP SOL VALVE |
| 28 | - | - |
| 29 | - | - |
| 30 | SB | LINE PRESS SOL VALVE |
| 31 | - | - |
| 32 | - | - |
| 33 | L | CAN-H |
| 34 | BR | OUTPUT SPEED SENS |
| 35 | LG | PRI SPEED SENS |
| 36 | - | - |
| 37 | BR | SELECT SOL VALVE |

AAFI0547GB


BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]


BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|-------------------|
| Connector No. | M24 |
| Connector Name | COMBINATION METER |
| Connector Type | TH40FW-NH |
| Connector Color | WHITE |



| | | |
|----|---|-------|
| 39 | L | CAN-H |
| 40 | - | - |

| | |
|-----------------|-----------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CS16-TM4 |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------|
| 1 | B | GND1 |
| 2 | B | GND2 |
| 3 | P | STRG SW INPUT 1 |
| 4 | BG | STRG SW INPUT 2 |
| 5 | P | ACC |
| 6 | V | SECURITY |
| 7 | R | AIR BAG |
| 8 | G | AS BELT |
| 9 | Y | DR BUCKLE SW |
| 10 | - | - |
| 11 | BG | ALTERNATOR (CHARGE) |
| 12 | G | PKB |
| 13 | - | - |
| 14 | G | STRG SW OUTPUT 1 |
| 15 | W | STRG SW OUTPUT 2 |
| 16 | B | STRG SW OUTPUT GND |
| 17 | - | - |
| 18 | - | - |
| 19 | - | - |
| 20 | - | - |
| 21 | BG | IGN |
| 22 | W | BAT |
| 23 | B | ILLUMI CONT OUT |
| 24 | R | STRG SW GND |
| 25 | G | BRAKE OIL SW |
| 26 | R | FUEL SENSOR GND |
| 27 | W | FUEL SENSOR |
| 28 | - | - |
| 29 | - | - |
| 30 | - | - |
| 31 | - | - |
| 32 | - | - |
| 33 | BR | SPEED 2 P/R |
| 34 | BG | SPEED 8 P/R |
| 35 | - | - |
| 36 | - | - |
| 37 | - | - |
| 38 | P | CAN-L |

AAFIA0548GB

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------------|
| 17G | B | TO ENGINE ROOM HARNESS |
| 18G | SHIELD | TO ENGINE ROOM HARNESS |
| 19G | SB | TO ENGINE ROOM HARNESS |
| 20G | LG | TO ENGINE ROOM HARNESS |
| 21G | R | TO ENGINE ROOM HARNESS |
| 22G | B | TO ENGINE ROOM HARNESS |
| 23G | SHIELD | TO ENGINE ROOM HARNESS |
| 24G | W | TO ENGINE ROOM HARNESS |
| 25G | R | TO ENGINE ROOM HARNESS |
| 26G | SHIELD | TO ENGINE ROOM HARNESS |
| 27G | B | TO ENGINE ROOM HARNESS |
| 28G | W | TO ENGINE ROOM HARNESS |
| 29G | G | TO ENGINE ROOM HARNESS |
| 30G | R | TO ENGINE ROOM HARNESS |
| 31G | L | TO ENGINE ROOM HARNESS |
| 32G | G | TO ENGINE ROOM HARNESS |
| 33G | G | TO ENGINE ROOM HARNESS |
| 34G | G | TO ENGINE ROOM HARNESS |
| 35G | P | TO ENGINE ROOM HARNESS |
| 36G | L | TO ENGINE ROOM HARNESS |
| 37G | L | TO ENGINE ROOM HARNESS |
| 38G | W | TO ENGINE ROOM HARNESS |
| 39G | R | TO ENGINE ROOM HARNESS |
| 40G | Y | TO ENGINE ROOM HARNESS |
| 41G | L | TO ENGINE ROOM HARNESS |
| 42G | P | TO ENGINE ROOM HARNESS |
| 43G | W | TO ENGINE ROOM HARNESS |
| 44G | G | TO ENGINE ROOM HARNESS |
| 45G | R | TO ENGINE ROOM HARNESS |
| 46G | Y | TO ENGINE ROOM HARNESS |
| 47G | Y | TO ENGINE ROOM HARNESS |
| 48G | LG | TO ENGINE ROOM HARNESS |
| 49G | P | TO ENGINE ROOM HARNESS |
| 50G | L | TO ENGINE ROOM HARNESS |
| 51G | B/W | TO ENGINE ROOM HARNESS |
| 52G | BR | TO ENGINE ROOM HARNESS |
| 53G | L | TO ENGINE ROOM HARNESS |
| 54G | BG | TO ENGINE ROOM HARNESS |
| 55G | G | TO ENGINE ROOM HARNESS |
| 56G | P | TO ENGINE ROOM HARNESS |
| 57G | P | TO ENGINE ROOM HARNESS |
| 58G | L | TO ENGINE ROOM HARNESS |
| 59G | B | TO ENGINE ROOM HARNESS |
| 60G | W | TO ENGINE ROOM HARNESS |
| 61G | SHIELD | TO ENGINE ROOM HARNESS |
| 62G | G | TO ENGINE ROOM HARNESS |
| 63G | P | TO ENGINE ROOM HARNESS |
| 64G | W | TO ENGINE ROOM HARNESS |
| 65G | G/R | TO ENGINE ROOM HARNESS |
| 66G | R | TO ENGINE ROOM HARNESS |
| 67G | W | TO ENGINE ROOM HARNESS |
| 68G | LG/R | TO ENGINE ROOM HARNESS |
| 69G | P | TO ENGINE ROOM HARNESS |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------------|
| 70G | BG | TO ENGINE ROOM HARNESS |
| 71G | GR | TO ENGINE ROOM HARNESS |
| 72G | - | TO ENGINE ROOM HARNESS |
| 73G | - | TO ENGINE ROOM HARNESS |
| 74G | - | TO ENGINE ROOM HARNESS |
| 75G | G | TO ENGINE ROOM HARNESS |
| 76G | Y | TO ENGINE ROOM HARNESS |
| 77G | BR | TO ENGINE ROOM HARNESS |
| 78G | - | TO ENGINE ROOM HARNESS |
| 79G | R | TO ENGINE ROOM HARNESS |
| 80G | W | TO ENGINE ROOM HARNESS |
| 81G | G | TO ENGINE ROOM HARNESS |
| 82G | P | TO ENGINE ROOM HARNESS |
| 83G | P | TO ENGINE ROOM HARNESS |
| 84G | P | TO ENGINE ROOM HARNESS |
| 85G | P | TO ENGINE ROOM HARNESS |
| 86G | P | TO ENGINE ROOM HARNESS |
| 87G | P | TO ENGINE ROOM HARNESS |
| 88G | P | TO ENGINE ROOM HARNESS |
| 89G | R | TO ENGINE ROOM HARNESS |
| 90G | P | TO ENGINE ROOM HARNESS |
| 91G | L | TO ENGINE ROOM HARNESS |
| 92G | P | TO ENGINE ROOM HARNESS |
| 93G | P | TO ENGINE ROOM HARNESS |
| 94G | O | TO ENGINE ROOM HARNESS |
| 95G | B | TO ENGINE ROOM HARNESS |
| 96G | P | TO ENGINE ROOM HARNESS |
| 97G | P | TO ENGINE ROOM HARNESS |
| 98G | P | TO ENGINE ROOM HARNESS |
| 99G | P | TO ENGINE ROOM HARNESS |
| 100G | SHIELD | TO ENGINE ROOM HARNESS |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC


BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]


BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | M36 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40FW-NH |
| Connector Color | WHITE |



| | | |
|----|---|--------------------|
| 39 | - | TO BODY HARNESS RH |
| 40 | - | TO BODY HARNESS RH |

| | |
|-----------------|---------------------|
| Connector No. | M37 |
| Connector Name | JOINT CONNECTOR-M28 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------|
| 1 | V | TO BODY HARNESS RH |
| 2 | G | TO BODY HARNESS RH |
| 3 | Y | TO BODY HARNESS RH |
| 4 | R | TO BODY HARNESS RH |
| 5 | BG | TO BODY HARNESS RH |
| 6 | LG | TO BODY HARNESS RH |
| 7 | SB | TO BODY HARNESS RH |
| 8 | G | TO BODY HARNESS RH |
| 9 | B | TO BODY HARNESS RH |
| 10 | W | TO BODY HARNESS RH |
| 11 | SHIELD | TO BODY HARNESS RH |
| 12 | W | TO BODY HARNESS RH |
| 13 | B | TO BODY HARNESS RH |
| 14 | SHIELD | TO BODY HARNESS RH |
| 15 | B | TO BODY HARNESS RH |
| 16 | W | TO BODY HARNESS RH |
| 17 | SHIELD | TO BODY HARNESS RH |
| 18 | SB | TO BODY HARNESS RH |
| 19 | LG | TO BODY HARNESS RH |
| 20 | SB | TO BODY HARNESS RH |
| 21 | B | TO BODY HARNESS RH |
| 22 | W | TO BODY HARNESS RH |
| 23 | SHIELD | TO BODY HARNESS RH |
| 24 | W | TO BODY HARNESS RH |
| 25 | B | TO BODY HARNESS RH |
| 26 | SHIELD | TO BODY HARNESS RH |
| 27 | B | TO BODY HARNESS RH |
| 28 | W | TO BODY HARNESS RH |
| 29 | SHIELD | TO BODY HARNESS RH |
| 30 | B | TO BODY HARNESS RH |
| 31 | W | TO BODY HARNESS RH |
| 32 | L | TO BODY HARNESS RH |
| 33 | Y | TO BODY HARNESS RH |
| 34 | - | TO BODY HARNESS RH |
| 35 | - | TO BODY HARNESS RH |
| 36 | - | TO BODY HARNESS RH |
| 37 | BR | TO BODY HARNESS RH |
| 38 | - | TO BODY HARNESS RH |

AAFI0549GB

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 2 | L | CAN-H |
| 3 | B | CAN-H |
| 4 | - | - |

| | |
|-----------------|---------------------|
| Connector No. | M38 |
| Connector Name | JOINT CONNECTOR-M29 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | CAN-L |
| 2 | Y | CAN-L |
| 3 | W | CAN-L |
| 4 | - | - |


BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]


BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|-------------------|
| Connector No. | M40 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FDGY-CST6-TM4 |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 75A | LG | TO BODY HARNESS |
| 76A | W | TO BODY HARNESS |
| 77A | L | TO BODY HARNESS |
| 78A | V | TO BODY HARNESS |
| 79A | LG | TO BODY HARNESS |
| 80A | Y | TO BODY HARNESS |
| 81A | L | TO BODY HARNESS |
| 82A | BG | TO BODY HARNESS |
| 83A | Y | TO BODY HARNESS |
| 84A | LG | TO BODY HARNESS |
| 85A | SHIELD | TO BODY HARNESS |
| 86A | Y | TO BODY HARNESS |
| 87A | LG | TO BODY HARNESS |
| 88A | BR | TO BODY HARNESS |
| 89A | L | TO BODY HARNESS |
| 90A | P | TO BODY HARNESS |
| 91A | L | TO BODY HARNESS |
| 92A | L | TO BODY HARNESS |
| 93A | B | TO BODY HARNESS |
| 94A | W | TO BODY HARNESS |
| 95A | W | TO BODY HARNESS |
| 96A | - | TO BODY HARNESS |
| 97A | SB | TO BODY HARNESS |
| 98A | Y | TO BODY HARNESS - (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| 99A | L | TO BODY HARNESS - (WITH AUTOMATIC DRIVE POSITIONER) |
| 100A | - | TO BODY HARNESS |

| | |
|-----------------|---------------------|
| Connector No. | M41 |
| Connector Name | JOINT CONNECTOR-M18 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | CAN-L |
| 2 | P | CAN-L |
| 3 | P | CAN-L |
| 4 | - | - |

| | | |
|-----|--------|---|
| 24A | B | TO BODY HARNESS |
| 25A | SHIELD | TO BODY HARNESS |
| 26A | B | TO BODY HARNESS |
| 27A | B | TO BODY HARNESS |
| 28A | SHIELD | TO BODY HARNESS |
| 29A | R | TO BODY HARNESS |
| 30A | B | TO BODY HARNESS |
| 31A | R | TO BODY HARNESS |
| 32A | Y/R | TO BODY HARNESS |
| 33A | W | TO BODY HARNESS |
| 34A | B | TO BODY HARNESS |
| 35A | SHIELD | TO BODY HARNESS |
| 36A | LY | TO BODY HARNESS |
| 37A | LG | TO BODY HARNESS |
| 38A | V | TO BODY HARNESS |
| 39A | SB | TO BODY HARNESS |
| 40A | BR | TO BODY HARNESS |
| 41A | Y | TO BODY HARNESS |
| 42A | G | TO BODY HARNESS |
| 43A | - | TO BODY HARNESS |
| 44A | W | TO BODY HARNESS |
| 45A | R | TO BODY HARNESS |
| 46A | BG | TO BODY HARNESS |
| 47A | LG | TO BODY HARNESS |
| 48A | R | TO BODY HARNESS |
| 49A | P | TO BODY HARNESS |
| 50A | W | TO BODY HARNESS |
| 51A | L | TO BODY HARNESS |
| 52A | P | TO BODY HARNESS |
| 53A | G | TO BODY HARNESS |
| 54A | W | TO BODY HARNESS |
| 55A | BG | TO BODY HARNESS |
| 56A | BR | TO BODY HARNESS |
| 57A | P | TO BODY HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 57A | L | TO BODY HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 58A | G | TO BODY HARNESS |
| 59A | SB | TO BODY HARNESS |
| 60A | L | TO BODY HARNESS |
| 61A | G | TO BODY HARNESS |
| 62A | BR | TO BODY HARNESS |
| 63A | BR | TO BODY HARNESS |
| 64A | Y | TO BODY HARNESS |
| 65A | W | TO BODY HARNESS |
| 66A | BG | TO BODY HARNESS |
| 67A | Y | TO BODY HARNESS |
| 68A | LG | TO BODY HARNESS |
| 69A | R | TO BODY HARNESS |
| 70A | P | TO BODY HARNESS |
| 71A | BR | TO BODY HARNESS |
| 72A | SB | TO BODY HARNESS |
| 73A | BG | TO BODY HARNESS |
| 74A | BR | TO BODY HARNESS |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 1A | GR | TO BODY HARNESS |
| 2A | BR | TO BODY HARNESS |
| 3A | Y | TO BODY HARNESS |
| 4A | V | TO BODY HARNESS |
| 5A | L/B | TO BODY HARNESS |
| 6A | L | TO BODY HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 6A | G | TO BODY HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 7A | Y | TO BODY HARNESS |
| 8A | W | TO BODY HARNESS |
| 9A | L | TO BODY HARNESS |
| 10A | R | TO BODY HARNESS |
| 11A | R | TO BODY HARNESS |
| 12A | BG | TO BODY HARNESS |
| 13A | O | TO BODY HARNESS |
| 14A | LG | TO BODY HARNESS |
| 15A | R | TO BODY HARNESS |
| 16A | G | TO BODY HARNESS |
| 17A | B | TO BODY HARNESS |
| 18A | B | TO BODY HARNESS |
| 19A | SHIELD | TO BODY HARNESS |
| 20A | B | TO BODY HARNESS |
| 21A | SHIELD | TO BODY HARNESS |
| 22A | - | TO BODY HARNESS |
| 23A | W | TO BODY HARNESS |

AAFIA0550GB

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM CONNECTORS


| | |
|-----------------|---------------|
| Connector No. | M50 |
| Connector Name | A/C AUTO AMP. |
| Connector Type | TH40FW-NH |
| Connector Color | WHITE |



H.S.

| | | | |
|----|---|---|---------------------|
| 39 | L | Y | PTC 2 |
| 40 | Y | | WATER VALVE CLOSE A |

| | |
|-----------------|-----------------------|
| Connector No. | M54 |
| Connector Name | STEERING ANGLE SENSOR |
| Connector Type | TH08FW-NH |
| Connector Color | WHITE |




H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------|
| 1 | L | CAN-H |
| 2 | GR | GND |
| 3 | G | BATT |
| 4 | - | - |
| 5 | G | TX RR |
| 6 | - | - |
| 7 | G | AMB SENS |
| 8 | G | STRG HTR SW |
| 9 | W | SUN SENS |
| 10 | SB | MODE 1 |
| 11 | G | MODE 3 |
| 12 | G | FAN OUT (COOLER) |
| 13 | W | IGN 2 |
| 14 | W | FAN OUT (BOOSTER) |
| 15 | - | - |
| 16 | Y | ACTR (LIN) |
| 17 | LG | VACTR |
| 18 | W | FR FAN PWM |
| 19 | W | PTC 1 |
| 20 | BR | STRG HTR RLY |
| 21 | P | CAN-L |
| 22 | GR | GND (POWER) |
| 23 | LG | IGN |
| 24 | - | - |
| 25 | W | RX RR |
| 26 | G | SENS GND |
| 27 | W | INC SENS |
| 28 | W | INT SENS |
| 29 | P | MODE 2 |
| 30 | R | GAS SENS |
| 31 | BG | MODE 4 |
| 32 | L | FAN F/B (COOLER) |
| 33 | - | - |
| 34 | L | FAN F/B (BOOSTER) |
| 35 | - | - |
| 36 | BR | WATER VALVE OPEN B |
| 37 | BR | ACTR GND |
| 38 | P | ION ON/OFF |

AAFI0551GB

| | | |
|----|----|------------------------|
| 13 | Y | TO CONSOLE SUB HARNESS |
| 14 | SB | TO CONSOLE SUB HARNESS |
| 15 | L | TO CONSOLE SUB HARNESS |
| 16 | LG | TO CONSOLE SUB HARNESS |

| | |
|-----------------|--------------|
| Connector No. | M65 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32FW-NH |
| Connector Color | WHITE |




H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 1 | W | TO CONSOLE SUB HARNESS |
| 2 | G | TO CONSOLE SUB HARNESS |
| 3 | BR | TO CONSOLE SUB HARNESS |
| 4 | BG | TO CONSOLE SUB HARNESS |
| 5 | W | TO CONSOLE SUB HARNESS |
| 6 | P | TO CONSOLE SUB HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 7 | W | TO CONSOLE SUB HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 7 | LG | TO CONSOLE SUB HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 8 | R | TO CONSOLE SUB HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 8 | L | TO CONSOLE SUB HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 9 | V | TO CONSOLE SUB HARNESS |
| 10 | BG | TO CONSOLE SUB HARNESS |
| 11 | P | TO CONSOLE SUB HARNESS |
| 12 | G | TO CONSOLE SUB HARNESS |
| 13 | SHIELD | TO CONSOLE SUB HARNESS |
| 14 | B | TO CONSOLE SUB HARNESS |
| 15 | R | TO CONSOLE SUB HARNESS |
| 16 | W | TO CONSOLE SUB HARNESS |
| 17 | SB | TO CONSOLE SUB HARNESS |
| 18 | P | TO CONSOLE SUB HARNESS |
| 19 | G | TO CONSOLE SUB HARNESS |
| 20 | BG | TO CONSOLE SUB HARNESS |
| 21 | R | TO CONSOLE SUB HARNESS |
| 22 | W | TO CONSOLE SUB HARNESS |
| 23 | R | TO CONSOLE SUB HARNESS |
| 24 | B | TO CONSOLE SUB HARNESS |
| 25 | G | TO CONSOLE SUB HARNESS |
| 26 | W | TO CONSOLE SUB HARNESS |

| | | |
|----|--------|------------------------|
| 27 | LG | TO CONSOLE SUB HARNESS |
| 28 | B | TO CONSOLE SUB HARNESS |
| 29 | BR | TO CONSOLE SUB HARNESS |
| 30 | SHIELD | TO CONSOLE SUB HARNESS |
| 31 | B | TO CONSOLE SUB HARNESS |
| 32 | W | TO CONSOLE SUB HARNESS |


| | |
|-----------------|---------------------|
| Connector No. | M67 |
| Connector Name | JOINT CONNECTOR-M04 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 2 | L | CAN-H |
| 3 | B | CAN-H |
| 4 | L | CAN-H |

| | |
|-----------------|----------------|
| Connector No. | M71 |
| Connector Name | VDC OFF SWITCH |
| Connector Type | TH08FG-NH |
| Connector Color | GREEN |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | PWR |
| 2 | GR | GND |
| 3 | R | ILL+ |
| 4 | B | ILL- |



BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | M84 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32FW-NH |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 1 | B | TO BODY HARNESS RH |
| 2 | W | TO BODY HARNESS RH |
| 3 | SHIELD | TO BODY HARNESS RH |
| 4 | LG | TO BODY HARNESS RH |
| 5 | P | TO BODY HARNESS RH - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 5 | Y | TO BODY HARNESS RH - (WITH REAR ENTERTAINMENT SYSTEM) |
| 6 | W | TO BODY HARNESS RH - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 6 | B | TO BODY HARNESS RH - (WITH REAR ENTERTAINMENT SYSTEM) |
| 7 | R | TO BODY HARNESS RH - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 7 | W | TO BODY HARNESS RH - (WITH REAR ENTERTAINMENT SYSTEM) |
| 8 | B | TO BODY HARNESS RH - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 8 | R | TO BODY HARNESS RH - (WITH REAR ENTERTAINMENT SYSTEM) |
| 9 | SHIELD | TO BODY HARNESS RH |
| 10 | G | TO BODY HARNESS RH |
| 11 | L | TO BODY HARNESS RH |
| 12 | G | TO BODY HARNESS RH |
| 13 | G | TO BODY HARNESS RH |
| 14 | P | TO BODY HARNESS RH |
| 15 | O | TO BODY HARNESS RH |
| 16 | SB | TO BODY HARNESS RH |
| 17 | L | TO BODY HARNESS RH |
| 18 | P | TO BODY HARNESS RH |
| 19 | R | TO BODY HARNESS RH |
| 20 | - | TO BODY HARNESS RH |
| 21 | G | TO BODY HARNESS RH |
| 22 | R | TO BODY HARNESS RH |
| 23 | G | TO BODY HARNESS RH |
| 24 | R | TO BODY HARNESS RH - (WITH CLIMATE CONTROLLED SEAT) |
| 24 | V | TO BODY HARNESS RH - (WITHOUT CLIMATE CONTROLLED SEAT) |

AAFIA0552GB



| | | |
|----|----|--------------------|
| 25 | W | TO BODY HARNESS RH |
| 26 | W | TO BODY HARNESS RH |
| 27 | BG | TO BODY HARNESS RH |
| 28 | V | TO BODY HARNESS RH |
| 29 | SB | TO BODY HARNESS RH |
| 30 | L | TO BODY HARNESS RH |
| 31 | W | TO BODY HARNESS RH |
| 32 | - | TO BODY HARNESS RH |

| | |
|-----------------|--------------------------|
| Connector No. | M211 |
| Connector Name | DRIVE MODE SELECT SWITCH |
| Connector Type | TH10FB-NH |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W | DATA1 |
| 2 | L | DATA2 |
| 3 | G | DATA3 |
| 4 | Y | DATA4 |
| 5 | - | - |
| 6 | B | GND |
| 7 | B | ILL CONT |
| 8 | - | - |
| 9 | R | ILL+ |
| 10 | - | - |



| | |
|-----------------|--------------|
| Connector No. | M216 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16MW-CS |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | BG | TO MAIN HARNESS |
| 2 | B | TO MAIN HARNESS |
| 3 | B | TO MAIN HARNESS |

| | | |
|----|--------|-----------------|
| 4 | R | TO MAIN HARNESS |
| 5 | SHIELD | TO MAIN HARNESS |
| 6 | W | TO MAIN HARNESS |
| 7 | B | TO MAIN HARNESS |
| 8 | BG | TO MAIN HARNESS |
| 9 | B | TO MAIN HARNESS |
| 10 | - | TO MAIN HARNESS |
| 11 | - | TO MAIN HARNESS |
| 12 | BR | TO MAIN HARNESS |
| 13 | LG | TO MAIN HARNESS |
| 14 | L | TO MAIN HARNESS |
| 15 | LG | TO MAIN HARNESS |
| 16 | Y | TO MAIN HARNESS |

| | |
|-----------------|--------------|
| Connector No. | M217 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32MW-NH |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 1 | BG | TO MAIN HARNESS |
| 2 | BG | TO MAIN HARNESS |
| 3 | Y | TO MAIN HARNESS |
| 4 | BR | TO MAIN HARNESS |
| 5 | SB | TO MAIN HARNESS |
| 6 | P | TO MAIN HARNESS |
| 7 | V | TO MAIN HARNESS (WITH CLIMATE CONTROLLED SEAT) |
| 7 | W | TO MAIN HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 8 | L | TO MAIN HARNESS |
| 9 | G | TO MAIN HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 9 | LG | TO MAIN HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 10 | V | TO MAIN HARNESS |
| 11 | P | TO MAIN HARNESS |
| 12 | G | TO MAIN HARNESS |
| 13 | SHIELD | TO MAIN HARNESS |
| 14 | B | TO MAIN HARNESS |
| 15 | W | TO MAIN HARNESS |
| 16 | R | TO MAIN HARNESS |
| 17 | W | TO MAIN HARNESS |
| 18 | L | TO MAIN HARNESS |
| 19 | G | TO MAIN HARNESS |
| 20 | Y | TO MAIN HARNESS |

| | | |
|----|--------|-----------------|
| 21 | B | TO MAIN HARNESS |
| 22 | W | TO MAIN HARNESS |
| 23 | R | TO MAIN HARNESS |
| 24 | B | TO MAIN HARNESS |
| 25 | G | TO MAIN HARNESS |
| 26 | W | TO MAIN HARNESS |
| 27 | LG | TO MAIN HARNESS |
| 28 | B | TO MAIN HARNESS |
| 29 | BR | TO MAIN HARNESS |
| 30 | SHIELD | TO MAIN HARNESS |
| 31 | B | TO MAIN HARNESS |
| 32 | W | TO MAIN HARNESS |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000012853628

DETAILED FLOW

1. INTERVIEW THE CUSTOMER

Clarify customer concerns before inspection. First of all, perform an interview utilizing [BRC-79, "Diagnostic Work Sheet"](#) and reproduce the symptom as well as fully understand it. Ask customer about his/her concerns carefully. Check symptoms by driving vehicle with customer, if necessary.

CAUTION:

Customers are not professional. Never guess easily like "maybe the customer means that..." or "maybe the customer mentions this symptom".

>> GO TO 2.

2. CHECK SYMPTOM

Reproduce the symptom that is indicated by the customer, based on the information from the customer obtained in the interview. Also check that the symptom is not caused by fail-safe mode. Refer to [BRC-44, "Fail-Safe"](#).

CAUTION:

When the symptom is caused by normal operation, fully inspect each portion and obtain the understanding of customer that the symptom is not caused by a malfunction.

>> GO TO 3.

3. PERFORM THE SELF-DIAGNOSIS

CONSULT

1. Turn the ignition switch OFF → ON.

CAUTION:

Be sure to wait of 10 seconds after turning ignition switch OFF or ON.

2. Select "Self Diagnostic Result" mode of "ABS".

Is DTC detected?

YES >> Record or print Self Diagnostic Results and Freeze Frame Data (FFD). GO TO 4.

NO >> GO TO 6.

4. RECHECK THE SYMPTOM

CONSULT

1. Erase "Self Diagnostic Result" of "ABS".
2. Turn the ignition switch OFF → ON → OFF.

CAUTION:

Be sure to wait of 10 seconds after turning ignition switch OFF or ON.

3. Perform DTC confirmation procedures for the malfunctioning system.

NOTE:

If some DTCs are detected at the same time, determine the order for performing the diagnosis based on [BRC-46, "DTC Inspection Priority Chart"](#).

Is DTC detected?

YES >> GO TO 5.

NO >> Check harness and connectors based on the information obtained in the interview. Refer to [GI-50, "Intermittent Incident"](#).

5. REPAIR OR REPLACE MALFUNCTIONING COMPONENT

1. Repair or replace malfunctioning components.
2. Reconnect component or connector after repairing or replacing.
3. When DTC is detected, erase "Self Diagnostic Result" of "ABS".

CAUTION:

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

- Turn the ignition switch OFF → ON → OFF after erasing Self Diagnostic Result.
- Be sure to wait of 10 seconds after turning ignition switch OFF or ON.

>> GO TO 7.

6. IDENTIFY MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Identify malfunctioning system based on symptom diagnosis and perform inspection.

Can the malfunctioning system be identified?

YES >> GO TO 7.

NO >> Check harness and connectors based on the information obtained in the interview. Refer to [GI-50](#), "[Intermittent Incident](#)".

7. FINAL CHECK

CONSULT

1. Select "Data Monitor" mode of "ABS"
2. Check the reference values. Refer to [BRC-42](#), "[Reference Value](#)".
3. Recheck the symptom and check that the symptom is not reproduced on the same conditions.

Is the symptom reproduced?

YES >> GO TO 3.

NO >> Inspection End.

Diagnostic Work Sheet

INFOID:0000000012853629

DESCRIPTION

- In general, customers have their own criteria for a problem. Therefore, it is important to understand the symptom and status well enough by asking the customer about his/her concerns carefully. To systemize all the information for the diagnosis, prepare the interview sheet referring to the interview points.
- In some cases, multiple conditions that appear simultaneously may cause a DTC to be detected.

INTERVIEW SHEET SAMPLE

| Interview sheet | | | | | |
|------------------------------------|-------------------------------------|---|--|---|-----------|
| Customer name | MR/MS | Registration number | | Initial year registration | |
| | | Vehicle type | | VIN | |
| Storage date | | Engine/traction Motor | | Mileage | km (Mile) |
| Symptom | | <input type="checkbox"/> Does not operate () function | | | |
| | | <input type="checkbox"/> Warning lamp turns ON. | | | |
| | | ABS or BRAKE or <input type="checkbox"/> <input type="checkbox"/> OFF | | | |
| | | <input type="checkbox"/> Other () | | | |
| | | <input type="checkbox"/> Noise (Location:) | | <input type="checkbox"/> Vibration (Location:) | |
| <input type="checkbox"/> Other () | | | | | |
| First occurrence | | <input type="checkbox"/> Recently <input type="checkbox"/> Other () | | | |
| Frequency of occurrence | | <input type="checkbox"/> Always <input type="checkbox"/> Under a certain conditions of <input type="checkbox"/> Sometimes (time(s)/day) | | | |
| Climate conditions | <input type="checkbox"/> Irrelevant | | | | |
| | Weather | <input type="checkbox"/> Fine <input type="checkbox"/> Cloud <input type="checkbox"/> Rain <input type="checkbox"/> Snow <input type="checkbox"/> Others () | | | |
| | Temperature | <input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold <input type="checkbox"/> Temperature [Approx. °C (°F)] | | | |
| | Relative humidity | <input type="checkbox"/> High <input type="checkbox"/> Moderate <input type="checkbox"/> Low | | | |
| Road conditions | | <input type="checkbox"/> Ordinary road <input type="checkbox"/> Highway <input type="checkbox"/> Mountainous road (uphill or downhill) <input type="checkbox"/> Rough road | | | |

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

Interview sheet

| | | | | | |
|---------------------------|--|--|--|---------------------------|-----------|
| Customer name | MR/MS | Registration number | | Initial year registration | |
| | | Vehicle type | | VIN | |
| Storage date | | Engine/traction Motor | | Mileage | km (Mile) |
| Operating condition, etc. | | <input type="checkbox"/> Irrelevant <input type="checkbox"/> When engine/traction motor starts <input type="checkbox"/> During idling <input type="checkbox"/> During driving <input type="checkbox"/> During acceleration <input type="checkbox"/> At constant speed driving <input type="checkbox"/> During deceleration <input type="checkbox"/> Immediately before stop [Vehicle speed: Approx. km/h (MPH)] <input type="checkbox"/> During cornering (right curve or left curve) <input type="checkbox"/> When steering wheel is steered (to right or to left) | | | |
| Other conditions | VDC OFF switch operation | <input type="checkbox"/> Yes <input type="checkbox"/> No | | | |
| | Use of other functions (ex. ICC) | <input type="checkbox"/> Yes <input type="checkbox"/> No () | | | |
| | Presence of non-genuine parts installation | <input type="checkbox"/> Yes <input type="checkbox"/> No () | | | |

Memo

ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< BASIC INSPECTION >

[VDC/TCS/ABS]

ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Description

INFOID:000000012853630

After replacing the ABS actuator and electric unit (control unit), perform the following procedures:

- Neutral position adjustment for the steering angle sensor
- Calibration of the decel G sensor

Work Procedure

INFOID:000000012853631

1. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

Perform the neutral position adjustment for the steering angle sensor.

>> Refer to [BRC-82. "Work Procedure"](#), GO TO 2.

2. PERFORM CALIBRATION OF THE DECEL G SENSOR

Perform calibration of the decel G sensor.

>> Refer to [BRC-84. "Work Procedure"](#).

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

< BASIC INSPECTION >

[VDC/TCS/ABS]

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Description

INFOID:000000012853632

Refer to the table below to determine if adjustment of steering angle sensor neutral position is required.

×: Required —: Not required

| Situation | Adjustment of steering angle sensor neutral position |
|---|--|
| Removing/Installing ABS actuator and electric unit (control unit) | — |
| Replacing ABS actuator and electric unit (control unit) | × |
| Removing/Installing steering angle sensor | × |
| Replacing steering angle sensor | × |
| Removing/Installing steering components | × |
| Replacing steering components | × |
| Removing/Installing suspension components | × |
| Replacing suspension components | × |
| Change tires to new ones | — |
| Tire rotation | — |
| Adjusting wheel alignment | × |

Work Procedure

INFOID:000000012853633

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

CAUTION:

**To adjust neutral position of steering angle sensor, make sure to use CONSULT.
(Adjustment cannot be done without CONSULT).**

1. ALIGN THE VEHICLE STATUS

Stop vehicle with front wheels in straight-ahead position.

>> GO TO 2.

2. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

1. On the CONSULT screen, touch "Work support" and "ST ANG SEN ADJUSTMENT" in order.
2. Touch "START".

CAUTION:

Do not touch steering wheel while adjusting steering angle sensor.

3. After approximately 10 seconds, touch "END".

NOTE:

After approximately 60 seconds, it ends automatically.

4. Turn ignition switch OFF, then turn it ON again.

CAUTION:

Be sure to perform above operation.

>> GO TO 3.

3. CHECK DATA MONITOR

1. Run vehicle with front wheels in straight-ahead position, then stop.
2. Select "Data Monitor". Then make sure "STR ANGLE SIG" is within $0 \pm 2.5^\circ$.

Is the steering angle within the specified range?

YES >> GO TO 4.

NO >> Perform the neutral position adjustment for the steering angle sensor again, GO TO 1.

4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memory of the ABS actuator and electric unit (control unit) and ECM.

- ABS actuator and electric unit (control unit): Refer to [BRC-37, "CONSULT Function"](#).

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

< BASIC INSPECTION >

[VDC/TCS/ABS]

- ECM: Refer to [EC-79. "CONSULT Function"](#) (except for Mexico) or [EC-625. "CONSULT Function"](#) (for Mexico).

Are the memories erased?

YES >> Inspection End.

NO >> Check the items indicated by the self-diagnosis.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

CALIBRATION OF DECEL G SENSOR

< BASIC INSPECTION >

[VDC/TCS/ABS]

CALIBRATION OF DECEL G SENSOR

Description

INFOID:000000012853634

Refer to the table below to determine if calibration of the decel G sensor is required.

×: Required —: Not required

| Situation | Calibration of decel G sensor |
|---|-------------------------------|
| Removing/Installing ABS actuator and electric unit (control unit) | — |
| Replacing ABS actuator and electric unit (control unit) | × |
| Removing/Installing steering components | — |
| Replacing steering components | — |
| Removing/Installing suspension components | — |
| Replacing suspension components | — |
| Removing/Installing tire | — |
| Replacing tire | — |
| Tire rotation | — |
| Adjusting wheel alignment | — |
| Removing/Installing yaw rate/side/decel G sensor | × |
| Replacing yaw rate/side/decel G sensor | × |

Work Procedure

INFOID:000000012853635

CALIBRATION OF DECEL G SENSOR

CAUTION:

To calibrate the decel G sensor, make sure to use CONSULT.
(Calibration cannot be done without CONSULT).

1. ALIGN THE VEHICLE STATUS

Stop vehicle with front wheels in straight-ahead position.

>> GO TO 2.

2. PERFORM CALIBRATION OF DECEL G SENSOR

1. On the CONSULT screen, touch "Work support" and "DECEL G SEN CALIBRATION" in order.
2. Touch "START".
3. After approximately 10 seconds, touch "END".

NOTE:

After approximately 60 seconds, it ends automatically.

4. Turn ignition switch OFF, then turn it ON again.

CAUTION:

Be sure to perform above operation.

>> GO TO 3.

3. CHECK DATA MONITOR

1. Run vehicle with front wheels in straight-ahead position, then stop.
2. Select "Data Monitor". Then make sure "DECEL G SEN" is within $\pm 0.08G$.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Perform calibration of decel G sensor again, GO TO 1.

4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memory of the ABS actuator and electric unit (control unit) and ECM.

- ABS actuator and electric unit (control unit): Refer to [BRC-37. "CONSULT Function"](#).

CALIBRATION OF DECEL G SENSOR

[VDC/TCS/ABS]

< BASIC INSPECTION >

- ECM: Refer to [EC-79. "CONSULT Function"](#) (except for Mexico) or [EC-625. "CONSULT Function"](#) (for Mexico).

Are the memories erased?

YES >> Inspection End.

NO >> Check the items indicated by the self-diagnosis.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

DTC/CIRCUIT DIAGNOSIS

C1101, C1102, C1103, C1104 WHEEL SENSOR

DTC Description

INFOID:000000012853636

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|--|
| C1101 | RR RH SENSOR-1 (Rear RH wheel sensor-1) | When an open circuit is detected in rear RH wheel sensor circuit. |
| C1102 | RR LH SENSOR-1 (Rear LH wheel sensor-1) | When an open circuit is detected in rear LH wheel sensor circuit. |
| C1103 | FR RH SENSOR-1 (Front RH wheel sensor-1) | When an open circuit is detected in front RH wheel sensor circuit. |
| C1104 | FR LH SENSOR-1 (Front LH wheel sensor-1) | When an open circuit is detected in front LH wheel sensor circuit. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|--|
| <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery | <ul style="list-style-type: none">• Harness or connector• Wheel sensor• ABS actuator and electric unit (control unit)• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery• Vehicle was not driven after previous repair |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

CONSULT

1. Start the engine.
2. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
3. Stop the vehicle.
4. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

5. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

6. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES-1 >> "C1101", "C1102", "C1103" or "C1104" is displayed as "CRNT": Proceed to [BRC-87. "Diagnosis Procedure"](#).

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

YES-2 >> "C1101", "C1102", "C1103" or "C1104" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853637

CAUTION:

Never check between wheel sensor harness connector terminals.

1. CHECK WHEEL SENSOR

1. Turn the ignition switch OFF.
2. Check the wheel sensor for damage.

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. REPLACE WHEEL SENSOR (1)

CONSULT

1. Replace the wheel sensor.
 - Front: Refer to [BRC-175, "Removal and Installation - Front Wheel Sensor"](#).
 - Rear: Refer to [BRC-177, "Removal and Installation - Rear Wheel Sensor"](#).
2. Erase "Self Diagnostic Result" of "ABS".
3. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

4. Start the engine.
5. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

6. Stop the vehicle.
7. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

8. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

9. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 3.

NO >> Inspection End.

3. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check the wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 4.

4. PERFORM SELF-DIAGNOSIS (1)

CONSULT

1. Erase "Self Diagnostic Result" of "ABS".
2. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.
4. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

C1101, C1102, C1103, C1104 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

5. Stop the vehicle.
6. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
7. Start the engine.
NOTE:
Wait at least 10 seconds after starting the engine.
8. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

- YES >> GO TO 5.
NO >> Inspection End.

5.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157](#), "Diagnosis Procedure".

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair / replace harness, connector, fuse, or fusible link.

6.CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
3. Disconnect wheel sensor harness connector and check each wheel sensor pin terminal for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 8.
NO >> Repair / replace harness, connector, or terminal, and GO TO 7.

7.PERFORM SELF-DIAGNOSIS (2)

CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase "Self Diagnostic Result" of "ABS".
4. Turn the ignition switch OFF → ON → OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF or ON.
5. Start the engine.
6. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
NOTE:
Vehicle must be driven after repair or replacement to erase the previous DTCs.
7. Stop the vehicle.
8. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
9. Start the engine.
NOTE:
Wait at least 10 seconds after starting the engine.
10. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

- YES >> GO TO 8.
NO >> Inspection End.

8.CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect wheel sensor harness connector.

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Check the continuity while turning steering wheel left and right, or while moving center harness in wheel housing.)

Power Supply Circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|--------------|------------------|--------------|
| Connector | Terminal | Connector | Terminal | |
| E125 | 23 | E18 | (Front LH wheel) | 1 Yes |
| | 11 | E43 | (Front RH wheel) | |
| | 13 | C10 | (Rear LH wheel) | |
| | 25 | C11 | (Rear RH wheel) | |

Signal Circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|--------------|------------------|--------------|
| Connector | Terminal | Connector | Terminal | |
| E125 | 24 | E18 | (Front LH wheel) | 2 Yes |
| | 12 | E43 | (Front RH wheel) | |
| | 14 | C10 | (Rear LH wheel) | |
| | 26 | C11 | (Rear RH wheel) | |

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair / replace harness or connector, and GO TO 9.

9. PERFORM SELF-DIAGNOSIS (3)

CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase "Self Diagnostic Result" of "ABS".
4. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

5. Start the engine.
6. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

7. Stop the vehicle.
8. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

9. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

10. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 10.

NO >> Inspection End.

10. CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Disconnect ABS actuator and electric unit (control unit) harness connector.
2. Disconnect wheel sensor harness connector.
3. Connect ABS active wheel sensor tester (SST: J-45741-A) to wheel sensor using appropriate adapter.
4. Turn the ABS active wheel sensor tester power switch ON.

NOTE:

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

5. Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash ON and OFF to indicate an output signal.

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NOTE:

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> GO TO 11.

11. REPLACE WHEEL SENSOR

Ⓟ CONSULT

1. Replace the wheel sensor.
 - Front: Refer to [BRC-175, "Removal and Installation - Front Wheel Sensor"](#).
 - Rear: Refer to [BRC-177, "Removal and Installation - Rear Wheel Sensor"](#).
2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Erase "Self Diagnostic Result" of "ABS".
4. Turn the ignition switch OFF → ON → OFF.

NOTE:
Wait at least 10 seconds after turning ignition switch OFF or ON.
5. Start the engine.
6. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.

NOTE:
Vehicle must be driven after repair or replacement to erase the previous DTCs.
7. Stop the vehicle.
8. Turn the ignition switch OFF.

NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
9. Start the engine.

NOTE:
Wait at least 10 seconds after starting the engine.
10. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Inspection End.

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1105, C1106, C1107, C1108 WHEEL SENSOR

DTC Description

INFOID:000000012853638

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|--|
| C1105 | RR RH SENSOR-2 (Rear RH wheel sensor-2) | <ul style="list-style-type: none"> When power supply voltage of rear RH wheel sensor is low. When distance between rear RH wheel sensor and rear RH wheel sensor rotor is large. When installation of rear RH wheel sensor or rear RH wheel sensor rotor is not normal. When there is contamination on or damage to the rear RH wheel sensor or rear RH sensor rotor. |
| C1106 | RR LH SENSOR-2 (Rear LH wheel sensor-2) | <ul style="list-style-type: none"> When power supply voltage of rear LH wheel sensor is low. When distance between rear LH wheel sensor and rear LH wheel sensor rotor is large. When installation of rear LH wheel sensor or rear LH wheel sensor rotor is not normal. When there is contamination on or damage to the rear LH wheel sensor or rear LH sensor rotor. |
| C1107 | FR RH SENSOR-2 (Front RH wheel sensor-2) | <ul style="list-style-type: none"> When power supply voltage of front RH wheel sensor is low. When distance between front RH wheel sensor and front RH wheel sensor rotor is large. When installation of front RH wheel sensor or front RH wheel sensor rotor is not normal. When there is contamination on or damage to the front RH wheel sensor or front RH sensor rotor. |
| C1108 | FR LH SENSOR-2 (Front LH wheel sensor-2) | <ul style="list-style-type: none"> When power supply voltage of front LH wheel sensor is low. When distance between front LH wheel sensor and front LH wheel sensor rotor is large. When installation of front LH wheel sensor or front LH wheel sensor rotor is not normal. When there is contamination on or damage to the front LH wheel sensor or front LH sensor rotor. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|---|--|
| <ul style="list-style-type: none"> Harness or connector Wheel sensor Sensor rotor Tire size ABS actuator and electric unit (control unit) power supply system Fuse Fusible link Battery | <ul style="list-style-type: none"> Harness or connector Wheel sensor Sensor rotor ABS actuator and electric unit (control unit) Tire size ABS actuator and electric unit (control unit) power supply system Fuse Fusible link Battery Vehicle was not driven after previous repair |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

CONSULT

- Start the engine.
- Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
- Stop the vehicle.
- Turn the ignition switch OFF.

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

5. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

6. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES-1 >> "C1105", "C1106", "C1107" or "C1108" is displayed as "CRNT": Proceed to [BRC-92, "Diagnosis Procedure"](#).

YES-2 >> "C1105", "C1106", "C1107" or "C1108" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853639

CAUTION:

Never check between wheel sensor harness connector terminals.

1. CHECK WHEEL HUB ASSEMBLY

Check that there is no excessive looseness in wheel hub assembly.

- Front: Refer to [FAX-6, "Inspection"](#).
- Rear: Refer to [RAX-5, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

- NO >> Repair or replace the wheel hub assembly, and GO TO 2.
- Front: Refer to [FAX-8, "Removal and Installation"](#).
 - Rear: Refer to [RAX-7, "Removal and Installation"](#).

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

- NO >> Repair / replace harness, connector, fuse, or fusible link.

3. CHECK TIRE

1. Turn the ignition switch OFF.
2. Check the tire air pressure, wear and size. Refer to [WT-60, "Tire Air Pressure"](#).

Is the inspection result normal?

YES >> GO TO 6.

- NO >> Adjust air pressure or replace tire, and GO TO 4.

4. CHECK DATA MONITOR (1)

CONSULT

1. Erase "Self Diagnostic Result" mode of "ABS".
2. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.
4. Select "DATA MONITOR" mode of "ABS", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read the values (wheel speed) of both the normal wheel sensors and malfunctioning wheel sensor.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

C1105, C1106, C1107, C1108 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the malfunctioning wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%. respectively?

- YES >> GO TO 5.
NO >> GO TO 6.

5.PERFORM SELF-DIAGNOSIS (1)

CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
3. Start the engine.

NOTE:

Wait at least 10 seconds after start the engine.

4. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> GO TO 6.
NO >> Inspection End.

6.CHECK WHEEL SENSOR AND SENSOR ROTOR

1. Turn the ignition switch OFF.
2. Disconnect wheel sensor harness connector.
3. Remove dust and foreign matter adhered to the wheel sensor and sensor rotor with a vacuum dust collector through the wheel sensor mounting hole.

CAUTION:

Install wheel sensor with no backlash and float, and tighten the mounting bolt to the specified torque.

- **Front:** Refer to [BRC-175, "Exploded View - Front Wheel Sensor"](#).
- **Rear:** Refer to [BRC-176, "Exploded View - Rear Wheel Sensor"](#).

>> GO TO 7.

7.CHECK WHEEL SENSOR

Check the wheel sensor for damage.

Is the inspection result normal?

- YES >> GO TO 8.
NO >> GO TO 9.

8.CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Disconnect ABS actuator and electric unit (control unit) harness connector.
2. Connect ABS active wheel sensor tester (SST: J-45741-A) to wheel sensor using appropriate adapter.
3. Turn the ABS active wheel sensor tester power switch ON.
NOTE:
The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.
4. Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash ON and OFF to indicate an output signal.

NOTE:

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

- YES >> GO TO 12.
NO >> GO TO 9.

9.REPLACE WHEEL SENSOR (1)

CONSULT

1. Replace the wheel sensor.
- Front: Refer to [BRC-175, "Removal and Installation - Front Wheel Sensor"](#).

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

- Rear: Refer to [BRC-177, "Removal and Installation - Rear Wheel Sensor"](#).
2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Erase "Self Diagnostic Result" mode of "ABS".
4. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

5. Start the engine.
6. Select "DATA MONITOR" mode of "ABS", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read the values (wheel speed) of both the normal wheel sensors and malfunctioning wheel sensor.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the malfunctioning wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors. is the difference within 5%, respectively?

YES >> GO TO 10.

NO >> GO TO 20.

10.PERFORM SELF-DIAGNOSIS (2)

CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

3. Start the engine.

NOTE:

Wait at least 10 seconds after start the engine.

4. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 11.

NO >> Inspection End.

11.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check the wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 14.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 12.

12.CHECK DATA MONITOR (2)

CONSULT

1. Erase "Self Diagnostic Result" mode of "ABS".
2. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.
4. Select "DATA MONITOR" of "ABS", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read the values (wheel speed) of both the normal wheel sensors and malfunctioning wheel sensor.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the malfunctioning wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors. is the difference within 5%, respectively?

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

- YES >> GO TO 13.
- NO >> GO TO 14.

13.PERFORM SELF-DIAGNOSIS (3)

CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
3. Start the engine.
NOTE:
Wait at least 10 seconds after start the engine.
4. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> GO TO 14.
- NO >> Inspection End.

14.CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
3. Disconnect wheel sensor harness connector and check each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 17.
- NO >> Repair / replace harness, connector, or terminal, and GO TO 15.

15.CHECK DATA MONITOR (3)

CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase "Self Diagnostic Result" of "ABS".
4. Turn the ignition switch OFF → ON → OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF or ON.
5. Start the engine.
6. Select "DATA MONITOR" of "ABS", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".
NOTE:
Set the "DATA MONITOR" recording speed to "10 msec".
7. Read the values (wheel speed) of both the normal wheel sensors and malfunctioning wheel sensor.
NOTE:
Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the malfunctioning wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%. respectively?

- YES >> GO TO 16.
- NO >> GO TO 17.

16.PERFORM SELF-DIAGNOSIS (4)

CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
3. Start the engine.
NOTE:
Wait at least 10 seconds after start the engine.
4. Select "Self Diagnostic Result" mode of "ABS".

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

C1105, C1106, C1107, C1108 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> GO TO 17.
- NO >> Inspection End.

17. CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect wheel sensor harness connector.
4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

Power Supply Circuit

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E125 | 23 | Ground | No |
| | 11 | | |
| | 13 | | |
| | 25 | | |

Is the inspection result normal?

- YES >> GO TO 18.
- NO >> Repair / replace harness or connector, and GO TO 18.

18. CHECK DATA MONITOR (4)

ⓅCONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase "Self Diagnostic Result" of "ABS".
4. Turn the ignition switch OFF → ON → OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF or ON.
5. Start the engine.
6. Select "DATA MONITOR" mode of "ABS", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read the values (wheel speed) of both the normal wheel sensors and malfunctioning wheel sensor.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the malfunctioning wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

- YES >> GO TO 19.
- NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180. "Removal and Installation"](#).

19. PERFORM SELF-DIAGNOSIS (5)

ⓅCONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
3. Start the engine.
NOTE:
Wait at least 10 seconds after start the engine.
4. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180. "Removal and Installation"](#).

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NO >> Inspection End.

20. REPLACE SENSOR ROTOR

CONSULT

1. Replace the sensor rotor.
 - Front: Refer to [BRC-179. "Removal and Installation - Front Sensor Rotor"](#).
 - Rear: Refer to [BRC-179. "Removal and Installation - Rear Sensor Rotor"](#).
2. Erase "Self Diagnostic Result" of "ABS".
3. Turn the ignition switch OFF → ON → OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF or ON.
4. Start the engine.
5. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
NOTE:
Vehicle must be driven after repair or replacement to erase the previous DTCs.
6. Stop the vehicle.
7. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
8. Start the engine.
NOTE:
Wait at least 10 seconds after start the engine.
9. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180. "Removal and Installation"](#).

NO >> Inspection End.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1109 POWER AND GROUND SYSTEM

DTC Description

INFOID:000000012853640

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|--|---|
| C1109 | BATTERY VOLTAGE [ABNORMAL] (Battery voltage [abnormal]) | When ignition power supply voltage is in following state: <ul style="list-style-type: none">• Ignition power supply voltage: $10\text{ V} \geq$ ignition power supply voltage.• Ignition power supply voltage: $16\text{ V} \leq$ ignition power supply voltage. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|---|
| <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery• Charge system | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• IPDM E/R• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery• Charge system |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1109" detected?

YES-1 >> "C1109" is displayed as "CRNT": Proceed to [BRC-98, "Diagnosis Procedure"](#).

YES-2 >> "C1109" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853641

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.

2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.

C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

2.PERFORM SELF-DIAGNOSIS

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1109" detected?

YES >> GO TO 3.

NO >> Inspection End.

3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, fuse, or fusible link.

4.CHECK TERMINAL

1. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
2. Check the IPDM E/R pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Repair / replace harness, connector, or terminal.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

DTC Description

INFOID:000000012853642

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|---|
| C1111 | PUMP MOTOR (Pump motor and motor relay) | When a malfunction is detected in motor or motor relay. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|--|
| <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

CONSULT

1. Turn the ignition switch OFF → ON, and wait 30 seconds.
2. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
3. Stop the vehicle.
4. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

5. Start the engine.

NOTE:

Wait at least 10 seconds after start the engine.

6. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1111" detected?

YES-1 >> "C1111" is displayed as "CRNT": Proceed to [BRC-100, "Diagnosis Procedure"](#).

YES-2 >> "C1111" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853643

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

2. PERFORM SELF-DIAGNOSIS

ⓂCONSULT

1. Turn the ignition switch OFF → ON, and wait 30 seconds.
2. Start the engine.
3. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
NOTE:
Vehicle must be driven after repair or replacement to erase the previous DTCs.
4. Stop the vehicle.
5. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
6. Start the engine.
NOTE:
Wait at least 10 seconds after starting the engine.
7. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1111" detected?

- YES >> GO TO 3.
NO >> Inspection End.

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair / replace harness, connector, or fuse, and GO TO 4.

4. ERASE SELF-DIAGNOSIS RESULT (1)

ⓂCONSULT

1. Start the engine.
2. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
NOTE:
Vehicle must be driven after repair or replacement to erase the previous DTCs.
3. Stop the vehicle.
4. Erase "Self Diagnostic Result" of "ABS".
5. Turn the ignition switch OFF → ON → OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF or ON.

>> Inspection End.

5. CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).
NO >> Repair / replace harness or connector, and GO TO 6.

6. ERASE SELF-DIAGNOSIS RESULT (2)

ⓂCONSULT

1. Start the engine.
2. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
NOTE:
Vehicle must be driven after repair or replacement to erase the previous DTCs.
3. Stop the vehicle.
4. Erase "Self Diagnostic Result" of "ABS".

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

5. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

>> Inspection End.

C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

DTC Description

INFOID:000000013652080

DTC DETECTION LOGIC

| DTC | Display item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|--|
| C1113 | G-SENSOR (Decel G sensor circuit) | When a malfunction is detected in the longitudinal G sensor internal to the ABS actuator and electric unit (control unit). |
| C1145 | YAW RATE SENSOR (Yaw rate sensor circuit) | When a malfunction is detected in the yaw rate sensor internal to the ABS actuator and electric unit (control unit). |
| C1146 | SIDE G-SEN CIRCUIT (Side G sensor circuit) | When a malfunction is detected in side G sensor internal to the ABS actuator and electric unit (control unit). |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| DTC | PAST DTC | CRNT DTC |
|-------|---|--|
| C1113 | <ul style="list-style-type: none"> ABS actuator and electric unit (control unit) power supply system Fuse Fusible link Battery Change in vehicle posture (e.g. different tire sizes on front and rear, overload) | <ul style="list-style-type: none"> ABS actuator and electric unit (control unit) Change in vehicle posture (e.g. different tire sizes on front and rear, overload) |
| C1145 | <ul style="list-style-type: none"> ABS actuator and electric unit (control unit) power supply system Fuse Fusible link Battery | ABS actuator and electric unit (control unit) |
| C1146 | <ul style="list-style-type: none"> Fuse Fusible link Battery | |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

Ⓜ CONSULT

- Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

- Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

- Select "Self Diagnostic Result" of "ABS".

Is DTC "C1113", "C1145" or "C1146" detected?

YES-1 >> "C1113", "C1145", or "C1146" is displayed as "CRNT": Proceed to [BRC-104. "Diagnosis Procedure"](#).

YES-2 >> "C1113", "C1145", or "C1146" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Diagnosis Procedure

INFOID:000000013652081

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-98, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair / replace harness, connector, fuse, or fusible link.

2. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 3.

3. PERFORM SELF-DIAGNOSIS

Ⓟ CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after start the engine.

3. Select "Self Diagnostic Result" of "ABS".

Is DTC "C1113", "C1145" or "C1146" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Inspection End.

C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1115 WHEEL SENSOR

DTC Description

INFOID:000000012853644

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|--|--|
| C1115 | ABS SENSOR [ABNORMAL SIGNAL] (Wheel sensor [abnormal signal]) | When difference in wheel speed between any wheel and others is detected when the vehicle is driven, because of installation of other tires than specified. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|--|
| <ul style="list-style-type: none">• Harness or connector• Wheel sensor• Sensor rotor• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery | <ul style="list-style-type: none">• Harness or connector• Wheel sensor• Sensor rotor• ABS actuator and electric unit (control unit)• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery• Tire size |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

Ⓜ With CONSULT

1. Start the engine.
2. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
3. Stop the vehicle.
4. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

5. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

6. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1115" detected?

YES-1 >> "C1115" is displayed as "CRNT": Proceed to [BRC-105, "Diagnosis Procedure"](#).

YES-2 >> "C1115" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853645

CAUTION:

Never check between wheel sensor harness connector terminals.

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

1. CHECK TIRE

Check the tire air pressure, wear and size. Refer to [WT-60, "Tire Air Pressure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Adjust air pressure or replace tire and GO TO 2.

2. CHECK DATA MONITOR (1)

Ⓜ With CONSULT

1. Erase "Self Diagnostic Result" of "ABS"

2. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.

4. Select "DATA MONITOR" of "ABS", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read the values (wheel speed) of both the normal wheel sensors and malfunctioning wheel sensor.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the malfunctioning wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors. is the difference within 5%, respectively?

YES >> GO TO 3.

NO >> GO TO 4.

3. PERFORM SELF-DIAGNOSIS (1)

Ⓜ With CONSULT

1. Stop the vehicle.

2. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

3. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

4. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1115" detected?

YES >> GO TO 4.

NO >> Inspection End.

4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair / replace harness, connector, fuse, or fusible link.

5. CHECK WHEEL SENSOR AND SENSOR ROTOR

1. Turn the ignition switch OFF.

2. Disconnect wheel sensor harness connector.

3. Remove dust and foreign matter adhered to the wheel sensor and sensor rotor with a vacuum dust collector through the wheel sensor mounting hole.

CAUTION:

Install wheel sensor with no backlash and float, and tighten the mounting bolt to the specified torque.

• Front: Refer to [BRC-175, "Exploded View - Front Wheel Sensor"](#).

• Rear: Refer to [BRC-176, "Exploded View - Rear Wheel Sensor"](#).

>> GO TO 6.

6. CHECK WHEEL SENSOR

Check the wheel sensor for damage.

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 8.

7. CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Disconnect ABS actuator and electric unit (control unit) harness connector.
2. Connect ABS active wheel sensor tester (SST: J-45741-A) to wheel sensor using appropriate adapter.
3. Turn the ABS active wheel sensor tester power switch ON.

NOTE:

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

4. Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash ON and OFF to indicate an output signal.

NOTE:

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

YES >> GO TO 11.

NO >> GO TO 8.

8. REPLACE WHEEL SENSOR (1)

Ⓜ With CONSULT

1. Replace the wheel sensor.
 - Front: Refer to [BRC-175, "Removal and Installation - Front Wheel Sensor"](#).
 - Rear: Refer to [BRC-177, "Removal and Installation - Rear Wheel Sensor"](#).
2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Erase "Self Diagnostic Result" of "ABS"
4. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

5. Start the engine.
6. Select "DATA MONITOR" of "ABS", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read the values (wheel speed) of both the normal wheel sensors and malfunctioning wheel sensor.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the malfunctioning wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 9.

NO >> GO TO 19.

9. PERFORM SELF-DIAGNOSIS (2)

Ⓜ With CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

3. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

4. Perform "Self Diagnostic Result" of "ABS".

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is DTC "C1115" detected?

- YES >> GO TO 10.
- NO >> Inspection End.

10. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check the wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

- YES >> GO TO 12.
- NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 11.

11. CHECK DATA MONITOR (2)

Ⓜ With CONSULT

1. Erase "Self Diagnostic Result" of "ABS"
2. Turn the ignition switch OFF → ON → OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF or ON.
3. Start the engine.
4. Select "DATA MONITOR" of "ABS", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read the values (wheel speed) of both the normal wheel sensors and malfunctioning wheel sensor.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the malfunctioning wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

- YES >> GO TO 12.
- NO >> GO TO 13.

12. PERFORM SELF-DIAGNOSIS (3)

Ⓜ With CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
3. Start the engine.
NOTE:
Wait at least 10 seconds after starting the engine.
4. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1115" detected?

- YES >> GO TO 13.
- NO >> Inspection End.

13. CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
3. Disconnect wheel sensor harness connector and check each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 16.
- NO >> Repair / replace harness, connector, or terminal, and GO TO 14.

14. CHECK DATA MONITOR (3)

Ⓜ With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

2. Connect wheel sensor harness connector.
3. Erase "Self Diagnostic Result" of "ABS" A
4. Turn the ignition switch OFF → ON → OFF. B
NOTE:
 Wait at least 10 seconds after turning ignition switch OFF or ON.
5. Start the engine. C
6. Select "DATA MONITOR" of "ABS", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR". D
NOTE:
 Set the "DATA MONITOR" recording speed to "10 msec".
7. Read the values (wheel speed) of both the normal wheel sensors and malfunctioning wheel sensor. E
NOTE:
 Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the malfunctioning wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

- YES >> GO TO 15.
 NO >> GO TO 16.

15.PERFORM SELF-DIAGNOSIS (4)

ⓂWith CONSULT

1. Stop the vehicle. G
2. Turn the ignition switch OFF. H
NOTE:
 Wait at least 10 seconds after turning ignition switch OFF.
3. Start the engine. I
NOTE:
 Wait at least 10 seconds after starting the engine.
4. Perform "Self Diagnostic Result" of "ABS". J

Is DTC "C1115" detected?

- YES >> GO TO 16.
 NO >> Inspection End.

16.CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF. K
2. Disconnect ABS actuator and electric unit (control unit) harness connector. L
3. Disconnect wheel sensor harness connector. M
4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Check the continuity while turning steering wheel left and right, or while moving center harness in wheel housing.) N

Power Supply Circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|--------------|------------------|------------|
| Connector | Terminal | Connector | Terminal | |
| E125 | 23 | E18 | (Front LH wheel) | 1 Yes |
| | 11 | E43 | (Front RH wheel) | |
| | 13 | C10 | (Rear LH wheel) | |
| | 26 | C11 | (Rear RH wheel) | |

Signal Circuit

| ABS actuator and electric unit (control unit) | | Wheel sensor | | Continuity |
|---|----------|--------------|------------------|------------|
| Connector | Terminal | Connector | Terminal | |
| E125 | 24 | E18 | (Front LH wheel) | 2 Yes |
| | 12 | E43 | (Front RH wheel) | |
| | 14 | C10 | (Rear LH wheel) | |
| | 25 | C11 | (Rear RH wheel) | |

C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

5. Check the continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

Power Supply Circuit

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E125 | 23 | Ground | No |
| | 11 | | |
| | 13 | | |
| | 25 | | |

Is the inspection result normal?

YES >> GO TO 17.

NO >> Repair / replace harness or connector, and GO TO 17.

17. CHECK DATA MONITOR (4)

Ⓟ With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase "Self Diagnostic Result" of "ABS"
4. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

5. Start the engine.
6. Select "DATA MONITOR" of "ABS", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

NOTE:

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read the values (wheel speed) of both the normal wheel sensors and malfunctioning wheel sensor.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the malfunctioning wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 18.

NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

18. PERFORM SELF-DIAGNOSIS (5)

Ⓟ With CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
3. Start the engine.
NOTE:
Wait at least 10 seconds after starting the engine.
4. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1115" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Inspection End.

19. REPLACE SENSOR ROTOR

Ⓟ With CONSULT

1. Replace the sensor rotor.
 - Front: Refer to [BRC-179, "Removal and Installation - Front Sensor Rotor"](#).
 - Rear: Refer to [BRC-179, "Removal and Installation - Rear Sensor Rotor"](#).
2. Erase "Self Diagnostic Result" of "ABS"

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

3. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

4. Start the engine.

5. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

6. Stop the vehicle.

7. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

8. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

9. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1115" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Inspection End.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1116 STOP LAMP SWITCH

DTC Description

INFOID:000000013642353

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|--|
| C1116 | STOP LAMP SW (Stop lamp switch) | When stop lamp switch signal is not input when brake pedal operates. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|---|
| <ul style="list-style-type: none">• Harness or connector• Stop lamp switch signal circuit | <ul style="list-style-type: none">• Harness or connector• Stop lamp switch• ABS actuator and electric unit (control unit)• Resistor (models with ICC system)• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery• Stop lamp relay |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

CONSULT

1. Turn the ignition switch OFF, and wait 10 seconds or more.
2. Start the engine.
NOTE:
Stop the vehicle.
3. Wait 1 minute or more.
NOTE:
Never depress brake pedal.
4. Depress brake pedal by 100 mm (3.94 in) or more, and maintain at that position for a minimum of 1 minute or more.
5. Release brake pedal, and wait 1 minute or more.
6. Repeat step 4 to 5 ten or more times.
7. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
8. Start the engine.
NOTE:
Wait at least 10 seconds after starting the engine.
9. Select "Self Diagnostic Result" mode of "ABS".

Is DTC "C1116" detected?

- YES-1 >> "C1116" is displayed as "CRNT": Proceed to [BRC-113, "Diagnosis Procedure"](#).
YES-2 >> "C1116" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").
NO-1 >> To check malfunction symptom before repair: Refer to [GI-52, "Circuit Inspection"](#).

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000013642354

NOTE:

DTC "C1116" may be detected when the brake pedal and the accelerator pedal are simultaneously depressed for 1 minute or more while driving the vehicle. This is not a malfunction.

1. INTERVIEW FROM THE CUSTOMER

Check if the brake pedal and the accelerator pedal are simultaneously depressed for 1 minute or more while driving the vehicle.

Is there such a history?

YES >> GO TO 2.

NO >> GO TO 3.

2. PERFORM SELF-DIAGNOSIS

ⓂCONSULT

1. Erase "Self Diagnostic Result" of "ABS"
2. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.

NOTE:

Stop the vehicle.

4. Depress the brake pedal several times.

5. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

6. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

7. Select "Self Diagnostic Result" of "ABS".

Is DTC "C1116" detected?

YES >> GO TO 3.

NO >> Inspection End.

3. STOP LAMP FOR ILLUMINATION

Depress brake pedal and check that stop lamp turns ON.

Does stop lamp turn ON?

YES >> GO TO 5.

NO >> Check the stop lamp system. Refer to [BRC-113, "Diagnosis Procedure"](#). GO TO 4.

4. CHECK DATA MONITOR (1)

ⓂCONSULT

1. Erase "Self Diagnostic Result" of "ABS"
2. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.

NOTE:

Stop the vehicle.

4. Select "DATA MONITOR" of "ABS", check "STOP LAMP SW". Check that data monitor displays "On" or "Off" when brake pedal is depressed or released. Refer to [BRC-42, "Reference Value"](#).

5. Select "DATA MONITOR" of "ABS", check "PRESS SENSOR". Check that data monitor displays "5 bar" or less when brake pedal is depressed. Refer to [BRC-42, "Reference Value"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 5.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

C1116 STOP LAMP SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

5. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check the stop lamp switch harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair / replace harness or connector, and GO TO 6.

6. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-98. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair / replace harness, connector, fuse, or fusible link.

7. CHECK STOP LAMP SWITCH CLEARANCE

1. Turn the ignition switch OFF.
2. Check the stop lamp switch clearance. Refer to [BR-7. "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 9.

NO >> Adjust stop lamp switch clearance. Refer to [BR-13. "Adjustment"](#). GO TO 8.

8. CHECK DATA MONITOR (2)

ⓐCONSULT

1. Erase "Self Diagnostic Result" of "ABS"
2. Turn the ignition switch OFF → ON → OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF or ON.
3. Start the engine.
NOTE:
Stop the vehicle.
4. Select "DATA MONITOR" of "ABS", check "STOP LAMP SW". Check that data monitor displays "On" or "Off" when brake pedal is depressed or released. Refer to [BRC-42. "Reference Value"](#).
5. Select "DATA MONITOR" of "ABS", check "PRESS SENSOR". Check that data monitor displays "5 bar" or less when brake pedal is depressed. Refer to [BRC-42. "Reference Value"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 9.

9. CHECK STOP LAMP SWITCH

Check the stop lamp switch. Refer to [BRC-117. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 10.

NO >> Replace the stop lamp switch. Refer to [BR-20. "Exploded View"](#). GO TO 10.

10. CHECK DATA MONITOR (3)

ⓐCONSULT

1. Erase "Self Diagnostic Result" of "ABS"
2. Turn the ignition switch OFF → ON → OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF or ON.
3. Start the engine.
NOTE:
Start the vehicle.
4. Select "DATA MONITOR" of "ABS", check "STOP LAMP SW". Check that data monitor displays "On" or "Off" when brake pedal is depressed or released. Refer to [BRC-42. "Reference Value"](#).

C1116 STOP LAMP SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

- Select "DATA MONITOR" of "ABS", check "PRESS SENSOR". Check that data monitor displays "5 bar" or less when brake pedal is depressed. Refer to [BRC-42, "Reference Value"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 11.

11.CHECK CONNECTOR AND TERMINAL

- Turn the ignition switch OFF.
- Disconnect ABS actuator and electric unit (control unit) harness connector.
- Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
- Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
- Disconnect stop lamp switch harness connector.
- Check the stop lamp switch harness connector for disconnection or looseness.
- Check the stop lamp switch pin terminals for damage or loose connection with harness connector.
- Disconnect resistor harness connector. (Models with ICC)
- Check the resistor harness connector for disconnection or looseness. (Models with ICC)
- Check the resistor pin terminals for damage or loose connection with harness connector. (Models with ICC)

Is the inspection result normal?

YES >> GO TO 13.

NO >> Repair / replace harness, connector, or terminal, and GO TO 12.

12.CHECK DATA MONITOR (4)

 With CONSULT

- Connect ABS actuator and electric unit (control unit) harness connector.
- Connect stop lamp switch harness connector.
- Connect resistor harness connector. (Models with ICC)
- Erase "Self Diagnostic Result" of "ABS"
- Turn the ignition switch OFF → ON → OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF or ON.
- Start the engine.
NOTE:
Stop the vehicle.
- Select "DATA MONITOR" of "ABS", check "STOP LAMP SW". Check that data monitor displays "On" or "Off" when brake pedal is depressed or released. Refer to [BRC-42, "Reference Value"](#).
- Select "DATA MONITOR" of "ABS", check "PRESS SENSOR". Check that data monitor displays "5 bar" or less when brake pedal is depressed. Refer to [BRC-42, "Reference Value"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 13.

13.CHECK STOP LAMP SWITCH CIRCUIT (1)

- Turn the ignition switch OFF.
- Disconnect ABS actuator and electric unit (control unit) harness connector.
- Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Condition | Voltage |
|---|----------|--------|---------------------------|-------------|
| Connector | Terminal | | | |
| E125 | 7 | Ground | Brake pedal depressed | 10 – 16 V |
| | | | Brake pedal not depressed | Approx. 0 V |

- Turn the ignition switch ON.
- Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| ABS actuator and electric unit (control unit) | | — | Condition | Voltage |
|---|----------|--------|---------------------------|-------------|
| Connector | Terminal | | | |
| E125 | 7 | Ground | Brake pedal depressed | 10 – 16 V |
| | | | Brake pedal not depressed | Approx. 0 V |

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO (Models with ICC)>>Repair / replace harness or connector, and GO TO 14.

NO (Models without ICC)>>Repair / replace harness or connector, and GO TO 15.

14.CHECK STOP LAMP SWITCH CIRCUIT (2) (MODELS WITH ICC)

1. Turn the ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Disconnect resistor harness connector.
4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and stop lamp switch harness connector.

| ABS actuator and electric unit (control unit) | | Stop lamp switch | | Continuity |
|---|----------|------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E125 | 7 | E38 | 4 | Yes |

5. Check the continuity between ABS actuator and electric unit (control unit) harness connector and resistor harness connector.

| ABS actuator and electric unit (control unit) | | Resistor | | Continuity |
|---|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E125 | 7 | E56 | 1 | Yes |

6. Check the continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E125 | 7 | Ground | No |

7. Check the continuity between resistor and the ground.

| Resistor | | — | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| E56 | 1 | Ground | No |
| | 2 | | Yes |

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Repair / replace harness or connector, and GO TO 16.

15.CHECK STOP LAMP SWITCH CIRCUIT (2) (MODELS WITHOUT ICC)

1. Turn the ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check the continuity between ABS actuator and electric unit (control unit) harness connector and stop lamp switch harness connector.

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| ABS actuator and electric unit (control unit) | | Stop lamp switch | | Continuity |
|---|----------|------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E125 | 7 | E38 | 2 | Yes |

4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E125 | 7 | Ground | No |

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Repair / replace harness or connector, and GO TO 16.

16. CHECK DATA MONITOR (5)

 With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect stop lamp switch harness connector.
3. Connect resistor harness connector. (Models with ICC)
4. Erase "Self Diagnostic Result" of "ABS"
5. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

6. Start the engine.

NOTE:

Stop the vehicle.

7. Select "DATA MONITOR" of "ABS", check "STOP LAMP SW". Check that data monitor displays "On" or "Off" when brake pedal is depressed or released. Refer to [BRC-42, "Reference Value"](#).
8. Select "DATA MONITOR" of "ABS", check "PRESS SENSOR". Check that data monitor displays "5 bar" or less when brake pedal is depressed. Refer to [BRC-42, "Reference Value"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

Component Inspection

INFOID:000000013642355

1. CHECK STOP LAMP SWITCH

1. Turn the ignition switch OFF.
2. Disconnect stop lamp switch harness connector.
3. Check the continuity when stop lamp switch is operated.

| Stop lamp switch | Condition | Continuity |
|------------------|--|------------|
| Terminal | | |
| 2 – 1 | When stop lamp switch is released (When brake pedal is depressed) | Yes |
| 4 – 3 | When stop lamp switch is pressed (When brake pedal is released) | No |

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the stop lamp switch. Refer to [BR-20, "Exploded View"](#).

C1120, C1122, C1124, C1126 ABS IN VALVE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1120, C1122, C1124, C1126 ABS IN VALVE SYSTEM

DTC Description

INFOID:000000012853649

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|--|--|
| C1120 | FR LH IN ABS SOL (Front LH ABS IN solenoid valve) | When a malfunction is detected in front LH ABS IN valve. |
| C1122 | FR RH IN ABS SOL (Front RH ABS IN solenoid valve) | When a malfunction is detected in front RH ABS IN valve. |
| C1124 | RR LH IN ABS SOL (Rear LH ABS IN solenoid valve) | When a malfunction is detected in rear LH ABS IN valve. |
| C1126 | RR RH IN ABS SOL (Rear RH ABS IN solenoid valve) | When a malfunction is detected in rear RH ABS IN valve. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|--|
| <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

Ⓔ With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1120", "C1122", "C1124" or "C1126" detected?

YES-1 >> "C1120", "C1122", "C1124" or "C1126" is displayed as "CRNT": Proceed to [BRC-118, "Diagnosis Procedure"](#).

YES-2 >> "C1120", "C1122", "C1124" or "C1126" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853650

1. CHECK CONNECTOR

C1120, C1122, C1124, C1126 ABS IN VALVE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.

2.PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1120", "C1122", "C1124" or "C1126" detected?

YES >> GO TO 3.

NO >> Inspection End.

3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157](#), "[Diagnosis Procedure](#)".

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, fuse, or fusible link.

4.CHECK TERMINAL

Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180](#), "[Removal and Installation](#)".

NO >> Repair / replace harness, connector, or terminal.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1121, C1123, C1125, C1127 ABS OUT VALVE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1121, C1123, C1125, C1127 ABS OUT VALVE SYSTEM

DTC Description

INFOID:000000012853651

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|--|---|
| C1121 | FR LH OUT ABS SOL (Front LH ABS OUT solenoid valve) | When a malfunction is detected in front LH ABS OUT valve. |
| C1123 | FR RH OUT ABS SOL (Front RH ABS OUT solenoid valve) | When a malfunction is detected in front RH ABS OUT valve. |
| C1125 | RR LH OUT ABS SOL (Rear LH ABS OUT solenoid valve) | When a malfunction is detected in rear LH ABS OUT valve. |
| C1127 | RR RH OUT ABS SOL (Rear RH ABS OUT solenoid valve) | When a malfunction is detected in rear RH ABS OUT valve. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|--|
| <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

Ⓔ With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1121", "C1123", "C1125" or "C1127" detected?

YES-1 >> "C1121", "C1123", "C1125" or "C1127" is displayed as "CRNT": Proceed to [BRC-120, "Diagnosis Procedure"](#).

YES-2 >> "C1121", "C1123", "C1125" or "C1127" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853652

1. CHECK CONNECTOR

C1121, C1123, C1125, C1127 ABS OUT VALVE SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.

2.PERFORM SELF-DIAGNOSIS

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1121", "C1123", "C1125" or "C1127" detected?

YES >> GO TO 3.

NO >> Inspection End.

3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, fuse, or fusible link.

4.CHECK TERMINAL

Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Repair / replace harness, connector, or terminal.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

C1130 ENGINE SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1130 ENGINE SIGNAL

DTC Description

INFOID:000000012853653

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|---|
| C1130 | ENGINE SIGNAL 1 (Engine system signal) | When a malfunction is detected in ECM system. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|---|---|
| <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery• CAN communication line | <ul style="list-style-type: none">• Harness or connector• ECM• ABS actuator and electric unit (control unit)• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery• CAN communication line |


DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1130" detected?

YES-1 >> "C1130" is displayed as "CRNT": Proceed to [BRC-122, "Diagnosis Procedure"](#).

YES-2 >> "C1130" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").


NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853654

1. CHECK ENGINE SYSTEM

 With CONSULT

Perform "Self Diagnostic Result" of "ENGINE".

Is DTC detected?

YES >> Check the DTC. Refer to [EC-112, "DTC Index"](#) (VQ35DE FOR USA AND CANADA) or [EC-654, "DTC Index"](#) (VQ35DE FOR MEXICO).

NO >> GO TO 2.

C1130 ENGINE SIGNAL

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness, connector, fuse, or fusible link.

3. CHECK CONNECTOR AND TERMINAL


1. Turn the ignition switch OFF.
2. Disconnect ECM harness connector.
3. Disconnect ABS actuator and electric unit (control unit) harness connector.
4. Check the connector for disconnection or looseness.
5. Check the pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, or terminal, securely lock the connector, and GO TO 4.

4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

 With CONSULT

1. Connect ECM harness connector.
2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Erase "Self Diagnostic Result" of "ABS"
4. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

5. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

6. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1130" or "U1000" detected?

YES ("C1130")>>GO TO 1.

YES ("U1000")>>Refer to [LAN-28, "Trouble Diagnosis Flow Chart"](#).

NO >> Inspection End.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1140 ACTUATOR RELAY SYSTEM

DTC Description

INFOID:000000012853655

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|---|
| C1140 | ACTUATOR RLY (Actuator relay) | When a malfunction is detected in actuator relay. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|--|
| <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery | <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery |

DTC CONFIRMATION PROCEDURE

1.PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2.CHECK DTC DETECTION

Ⓟ With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1140" detected?

YES-1 >> "C1140" is displayed as "CRNT": Proceed to [BRC-124, "Diagnosis Procedure"](#).

YES-2 >> "C1140" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853656

1.CHECK CONNECTOR

1. Turn the ignition switch OFF.

2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 3.


NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.

2.PERFORM SELF-DIAGNOSIS

C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

 With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1140" detected?

YES >> GO TO 3.

NO >> Inspection End.

3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157](#), "[Diagnosis Procedure](#)".

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, fuse, or fusible link.

4. CHECK TERMINAL

Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180](#), "[Removal and Installation](#)".

NO >> Repair / replace harness, connector, or terminal.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

C1142 PRESS SENSOR

DTC Description

INFOID:000000012853657

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|--|--|
| C1142 | PRESS SEN CIRCUIT (Pressure sensor circuit) | When a malfunction is detected in pressure sensor. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|---|
| <ul style="list-style-type: none"> • Harness or connector • Air inclusion in the brake piping • Stop lamp switch system • ABS actuator and electric unit (control unit) power supply system • Fuse • Fusible link • Battery | <ul style="list-style-type: none"> • Stop lamp switch system • ABS actuator and electric unit (control unit) • Brake system • ABS actuator and electric unit (control unit) power supply system • Fuse • Fusible link • Battery • Air inclusion in the brake piping |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

With CONSULT

1. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
2. Start the engine.
NOTE:
Wait at least 10 seconds after starting the engine.
3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1142" detected?

- YES-1 >> "C1142" is displayed as "CRNT": Proceed to [BRC-126, "Diagnosis Procedure"](#).
- YES-2 >> "C1142" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853658

1. STOP LAMP SWITCH SYSTEM

Check the stop lamp switch system. Refer to [BRC-113, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace stop lamp switch system.

2. CHECK BRAKE FLUID LEAKAGE

C1142 PRESS SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Check the brake fluid leakage. Refer to [BR-8, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace brake fluid leakage part.

3.CHECK BRAKE PIPING

Check the brake piping. Refer to [BR-8, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace brake piping.

- Front: Refer to [BR-23, "FRONT : Removal and Installation"](#).

- Rear: Refer to [BR-26, "REAR : Removal and Installation"](#).

4.CHECK BRAKE PEDAL

Check the brake pedal.

- Brake pedal height: Refer to [BR-7, "Inspection"](#).

- Brake pedal assembly: Refer to [BR-20, "Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Adjust the brake pedal height or replace brake pedal assembly.

- Adjust the brake pedal: Refer to [BR-13, "Adjustment"](#).

- Replace the brake pedal: Refer to [BR-20, "Removal and Installation"](#).

5.CHECK BRAKE MASTER CYLINDER

Check the brake master cylinder. Refer to [BR-9, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace brake master cylinder. Refer to [BR-28, "Removal and Installation"](#).

6.CHECK BRAKE BOOSTER

Check the brake booster. Refer to [BR-10, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace brake booster. Refer to [BR-31, "Removal and Installation"](#).

7.CHECK VACUUM PIPING

Check the vacuum piping. Refer to [BR-34, "Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace vacuum piping. Refer to [BR-34, "Removal and Installation"](#).

8.CHECK FRONT DISC BRAKE

Check the front disc brake caliper. Refer to [BR-37, "BRAKE CALIPER ASSEMBLY : Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace front disc brake caliper. Refer to [BR-38, "BRAKE CALIPER ASSEMBLY : Removal and Installation"](#).

9.CHECK REAR DISC BRAKE

Check the rear disc brake. Refer to [BR-42, "BRAKE CALIPER ASSEMBLY : Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace rear disc brake. Refer to [BR-43, "BRAKE CALIPER ASSEMBLY : Removal and Installation"](#).

10.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

C1142 PRESS SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157](#), "[Diagnosis Procedure](#)".

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair / replace harness, connector, fuse, or fusible link.

11. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Ⓟ With CONSULT

1. Erase "Self Diagnostic Result" of "ABS".

2. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

3. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

4. Start the engine and drive the vehicle for a short period of time.

NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

5. Stop the vehicle.

6. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1142" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180](#), "[Removal and Installation](#)".

NO >> Check the ABS actuator and electric unit (control unit) harness connector and terminal for damage, looseness and disconnection. Repair / replace harness, connector, or terminal.

C1143 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1143 STEERING ANGLE SENSOR

DTC Description

INFOID:000000012853659

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|--|
| C1143 | ST ANG SEN CIRCUIT (Steering angle sensor circuit) | When a malfunction is detected in steering angle sensor. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|--|
| <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery• CAN communication line• Incomplete neutral position adjustment of steering angle sensor• Improper installation of steering angle sensor | <ul style="list-style-type: none">• Harness or connector• Steering angle sensor• ABS actuator and electric unit (control unit)• IPDM E/R• CAN communication line• Wheel alignment• Incomplete neutral position adjustment of steering angle sensor• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1143" detected?

YES-1 >> "C1143" is displayed as "CRNT": Proceed to [BRC-129, "Diagnosis Procedure"](#).

YES-2 >> "C1143" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").


NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853660

1. ADJUST THE NEUTRAL POSITION OF STEERING ANGLE SENSOR

 With CONSULT

Perform neutral position adjustment of steering angle sensor. Refer to [BRC-82, "Description"](#).


C1143 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

>> GO TO 2.

2.PERFORM SELF-DIAGNOSIS (1)

 With CONSULT

1. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
2. Start the engine.
NOTE:
Wait at least 10 seconds after starting the engine.
3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1143" detected?

- YES-1 >> "C1143" is displayed as "CRNT": GO TO 3.
YES-2 >> "C1143" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").
NO >> Inspection End.


3.CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check the steering angle sensor harness connector for disconnection or looseness.

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 4.

4.PERFORM SELF-DIAGNOSIS (2)

 With CONSULT

1. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
2. Start the engine.
NOTE:
Wait at least 10 seconds after starting the engine.
3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1143" detected?

- YES >> GO TO 5.
NO >> Inspection End.

5.CHECK STEERING ANGLE SENSOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect steering angle sensor harness connector.
3. Check the voltage between steering angle sensor harness connector and ground.

| Steering angle sensor | | — | Voltage (Approx.) |
|-----------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| M54 | 4 | Ground | 0 V |

4. Turn the ignition switch ON.
NOTE:
Start the engine.
5. Check the voltage between steering angle sensor harness connector and ground.

| Steering angle sensor | | — | Voltage (Approx.) |
|-----------------------|----------|--------|-------------------|
| Connector | Terminal | | |
| M54 | 4 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 7.
NO >> GO TO 6.

C1143 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

6. CHECK STEERING ANGLE SENSOR POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check fuse 49 (10A).
3. Disconnect IPDM E/R harness connector.
4. Check the continuity between steering angle sensor harness connector and IPDM E/R harness connector.

| Steering angle sensor | | IPDM E/R | | Continuity |
|-----------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M54 | 4 | E119 | 35 | Yes |

5. Check the continuity between steering angle sensor harness connector and ground.

| Steering angle sensor | | — | Continuity |
|-----------------------|----------|--------|------------|
| Connector | Terminal | | |
| M54 | 4 | Ground | No |

Is the inspection result normal?

- YES >> Perform trouble diagnosis for ignition power supply.
NO >> Repair / replace harness, connector, or fuse.

7. CHECK STEERING ANGLE SENSOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check the continuity between steering angle sensor harness connector and ground.

| Steering angle sensor | | — | Continuity |
|-----------------------|----------|--------|------------|
| Connector | Terminal | | |
| M54 | 1 | Ground | Yes |

Is the inspection result normal?

- YES >> GO TO 8.
NO >> Repair / replace harness or connector.

8. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 9.
NO >> Repair / replace harness, connector, fuse, or fusible link.

9. CHECK TERMINAL

1. Check the steering angle sensor pin terminals for damage or loose connection with harness connector.
2. Check the IPDM E/R pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 10.
NO >> Repair / replace harness, connector, or terminal.

10. CHECK CAN COMMUNICATION LINE

Check the CAN communication line. Refer to [LAN-28, "Trouble Diagnosis Flow Chart"](#).

Is the inspection result normal?

- YES >> GO TO 11.
NO >> Repair / replace harness or connector.

11. CHECK DATA MONITOR

 With CONSULT

1. Select "DATA MONITOR" of "ABS", check "STR ANGLE SIG".

C1143 STEERING ANGLE SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

2. Check that the indication changes with the steering angle when the steering wheel is turned left/right from the neutral position. Refer to [BRC-42, "Reference Value"](#).

Is the inspection result normal?

- YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).
- NO >> Replace the steering angle sensor. Refer to [BRC-183, "Removal and Installation"](#).

C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

DTC Description

INFOID:000000012853661

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|--|
| C1144 | ST ANG SEN SIGNAL (Steering angle sensor not complete) | When neutral position adjustment of steering angle sensor is not complete. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|---|--|
| Incomplete neutral position adjustment of steering angle sensor | <ul style="list-style-type: none">• Harness or connector• Steering angle sensor• ABS actuator and electric unit (control unit)• Incomplete neutral position adjustment of steering angle sensor |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

ⓑ With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1144" detected?

YES-1 >> "C1144" is displayed as "CRNT": Proceed to [BRC-133. "Diagnosis Procedure"](#).

YES-2 >> "C1144" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853662

1. ADJUST THE NEUTRAL POSITION OF STEERING ANGLE SENSOR

Perform neutral position adjustment of steering angle sensor. Refer to [BRC-82. "Description"](#).

>> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

ⓑ With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1144" detected?

YES >> GO TO 3.

NO >> Inspection End.

3.CHECK STEERING ANGLE SENSOR SYSTEM


1. Turn the ignition switch OFF.
2. Check the steering angle sensor system. Refer to [BRC-129. "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, or terminal.

4.CHECK DATA MONITOR

 With CONSULT

1. Select "DATA MONITOR" of "ABS", check "STR ANGLE SIG".
2. Check that the indication changes with the steering angle when the steering wheel is turned left/right from the neutral position. Refer to [BRC-42. "Reference Value"](#).

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180. "Removal and Installation"](#).

NO >> Replace the steering angle sensor. Refer to [BRC-183. "Removal and Installation"](#).

C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1155 BRAKE FLUID LEVEL SWITCH

DTC Description

INFOID:000000012853665

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|---|
| C1155 | BR FLUID LEVEL LOW (Brake fluid level low) | <ul style="list-style-type: none"> When brake fluid level low signal is detected. When an open circuit is detected in brake fluid level switch circuit. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|--|
| <ul style="list-style-type: none"> Harness or connector Brake fluid level is low | <ul style="list-style-type: none"> Harness or connector ABS actuator and electric unit (control unit) Brake fluid level switch Combination meter Brake fluid level is low |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

④ With CONSULT

- Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

- Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

- Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1155" detected?

YES-1 >> "C1155" is displayed as "CRNT": Proceed to [BRC-135. "Diagnosis Procedure"](#).

YES-2 >> "C1155" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853666

1. CHECK BRAKE FLUID LEVEL

- Turn the ignition switch OFF.
- Check the brake fluid level. Refer to [BR-8. "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Refill brake fluid. Refer to [BR-14. "Drain and Refill"](#). GO TO 2.

2. PERFORM SELF-DIAGNOSIS (1)

④ With CONSULT

- Erase "Self Diagnostic Result" of "ABS"

C1155 BRAKE FLUID LEVEL SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

2. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

4. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1155" detected?

YES >> GO TO 3.

NO >> Inspection End.

3. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the combination meter harness connector for disconnection or looseness.
3. Check the brake fluid level switch harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair / replace harness or connector, and GO TO 4.

4. PERFORM SELF-DIAGNOSIS (2)

Ⓟ With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1155" detected?

YES >> GO TO 5.

NO >> Inspection End.

5. CHECK BRAKE FLUID LEVEL SWITCH

Check the brake fluid level switch. Refer to [BR-28, "Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace the reservoir tank. Refer to [BR-28, "Exploded View"](#). GO TO 6.

6. PERFORM SELF-DIAGNOSIS (3)

Ⓟ With CONSULT

1. Erase "Self Diagnostic Result" of "ABS"
2. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

4. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1155" detected?

YES >> GO TO 7.

NO >> Inspection End.

7. CHECK CONNECTOR AND TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Check the brake fluid level switch harness connector for disconnection or looseness.
4. Check the brake fluid level switch pin terminals for damage or loose connection with harness connector.
5. Disconnect combination meter harness connector.

C1155 BRAKE FLUID LEVEL SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

6. Check the combination meter harness connector for disconnection or looseness.
7. Check the combination meter pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 9.
 NO >> Repair / replace harness, connector, or terminal, and GO TO 8.

8.PERFORM SELF-DIAGNOSIS (4)

ⓂWith CONSULT

1. Erase "Self Diagnostic Result" of "ABS"
2. Turn the ignition switch OFF → ON → OFF.
NOTE:
 Wait at least 10 seconds after turning ignition switch OFF or ON.
3. Start the engine.
NOTE:
 Wait at least 10 seconds after starting the engine.
4. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1155" detected?

- YES >> GO TO 9.
 NO >> Inspection End.

9.CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Disconnect combination meter harness connector.
4. Check the continuity between brake fluid level switch harness connector and combination meter harness connector.

| Brake fluid level switch | | Combination meter | | Continuity |
|--------------------------|----------|-------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E21 | 1 | M24 | 25 | Yes |

5. Check the continuity between brake fluid level switch harness connector and ground.

| Brake fluid level switch | | — | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| E21 | 1 | Ground | No |

Is the inspection result normal?

- YES >> GO TO 10.
 NO >> Repair / replace harness or connector, and GO TO 10.

10.CHECK BRAKE FLUID LEVEL SWITCH GROUND CIRCUIT

Check the continuity between brake fluid level switch harness connector and ground.

| Brake fluid level switch | | — | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| E21 | 2 | Ground | Yes |

Is the inspection result normal?

- YES >> GO TO 11.
 NO >> Repair / replace harness or connector, and GO TO 11.

11.CHECK COMBINATION METER

Check the combination meter. Refer to [MWI-17, "CONSULT Function \(METER/M&A\)"](#).

Is the inspection result normal?

- YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NO >> Repair or replace combination meter. Refer to [MWI-94. "Removal and Installation"](#).

Component Inspection

INFOID:0000000012853667

1. CHECK BRAKE FLUID LEVEL SWITCH

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Check the continuity between terminals of brake fluid level switch.

| Brake fluid level switch | Condition | Continuity |
|--------------------------|--|------------|
| Terminal | | |
| 1 – 2 | When brake fluid level in reservoir tank is within the specified level. | No |
| | When brake fluid level in reservoir tank is less than the specified level. | Yes |

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the reservoir tank. Refer to [BR-28. "Exploded View"](#).

C1160 INCOMPLETE DECEL G SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1160 INCOMPLETE DECEL G SENSOR CALIBRATION

DTC Description

INFOID:000000012853668

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|---|
| C1160 | DECEL G SEN SET (Decel G sensor set) | When calibration of yaw rate/side/decel G sensor is not complete. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|--|
| <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery | <ul style="list-style-type: none">• Incomplete calibration of decel G sensor• ABS actuator and electric unit (control unit)• Yaw rate/side/decel G sensor• Harness or connector |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

④ With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1160" detected?

YES-1 >> "C1160" is displayed as "CRNT": Proceed to [BRC-139. "Diagnosis Procedure"](#).

YES-2 >> "C1160" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853669

1. DECEL G SENSOR CALIBRATION

Perform decel G sensor calibration. Refer to [BRC-84. "Work Procedure"](#).

>> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

④ With CONSULT

Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1160" detected?

C1160 INCOMPLETE DECEL G SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

-
- YES >> GO TO 3.
NO >> Inspection End.

3.CHECK YAW RATE/SIDE/DECEL G SENSOR SYSTEM

1. Turn the ignition switch OFF.
2. Check the yaw rate/side/decel G sensor system. Refer to [BRC-84. "Work Procedure"](#).

Is the inspection result normal?

- YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180. "Removal and Installation"](#).
NO >> Inspection End.

C1164, C1165 CV SYSTEM

DTC Description

INFOID:0000000012853670

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|--|
| C1164 | CV 1 (Cut valve 1) | When a malfunction is detected in cut valve 1. |
| C1165 | CV 2 (Cut valve 2) | When a malfunction is detected in cut valve 2. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|---|
| <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) power supply system • Fuse • Fusible link • Battery | <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) • ABS actuator and electric unit (control unit) power supply system • Fuse • Fusible link • Battery |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION?

Ⓜ With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1164" or "C1165" detected?

YES-1 >> "C1164" or "C1165" is displayed as "CRNT": Proceed to [BRC-141, "Diagnosis Procedure"](#).

YES-2 >> "C1164" or "C1165" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:0000000012853671

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 3.

C1164, C1165 CV SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.

2.PERFORM SELF-DIAGNOSIS

Ⓜ With CONSULT

Perform "Self Diagnostic Result" of "ABS" again.

Is DTC "C1164" or "C1165" detected?

YES >> GO TO 3.

NO >> Inspection End.

3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, fuse, or fusible link.

4.CHECK TERMINAL

Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness.

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Repair / replace harness, connector, or terminal.

C1170 VARIANT CODING

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1170 VARIANT CODING

DTC Description

INFOID:0000000012853672

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|--|
| C1170 | VARIANT CODING (Variant coding) | When the information in ABS actuator and electric unit (control unit) is not the same. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|----------|---|
| — | ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

Ⓜ With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1170" detected?

YES-1 >> "C1170" is displayed as "CRNT": Proceed to [BRC-143, "Diagnosis Procedure"](#).

YES-2 >> "C1170" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:0000000012853673

1. CHECK SELF-DIAGNOSIS RESULTS

Ⓜ With CONSULT

Replace the ABS actuator and electric unit (control unit) even if other DTC are displayed along with "C1170" in "Self Diagnostic Result" of "ABS".

>> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

C1197 VACUUM SENSOR

DTC Description

INFOID:0000000012853674

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|--|
| C1197 | VACUUM SENSOR (Vacuum sensor) | When a malfunction is detected in vacuum sensor. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|---|
| <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) power supply system • Fuse • Fusible link • Battery | <ul style="list-style-type: none"> • Harness or connector • Vacuum sensor (brake booster) • Vacuum piping • ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

Ⓟ With CONSULT

1. Turn the ignition switch OFF.
NOTE:
Wait at least 10 seconds after turning ignition switch OFF.
2. Start the engine.
NOTE:
Wait at least 10 seconds after starting the engine.
3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1197" detected?

- YES-1 >> "C1197" is displayed as "CRNT": Proceed to [BRC-144, "Diagnosis Procedure"](#).
- YES-2 >> "C1197" is displayed as "PAST": Inspection End (Erase "Self Diagnostic Result" of "ABS").
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:0000000012853675

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the vacuum sensor harness connector for disconnection or looseness.
3. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair / replace harness or connector, and GO TO 2.

2. CHECK BRAKE BOOSTER

1. Turn the ignition switch OFF.

C1197 VACUUM SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

2. Check the brake booster. Refer to [BR-10, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace the brake booster. Refer to [BR-31, "Removal and Installation"](#).

3. CHECK VACUUM PIPING

Check the vacuum piping. Refer to [BR-34, "Exploded View"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace the vacuum piping. Refer to [BR-34, "Removal and Installation"](#).

4. CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect vacuum sensor harness connector.
3. Check the vacuum sensor pin terminals for damage or loose connection with harness connector.
4. Disconnect ABS actuator and electric unit (control unit) harness connector.
5. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair / replace harness, connector, or terminal.

5. CHECK VACUUM SENSOR CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect vacuum sensor harness connector.
3. Disconnect ABS actuator and electric unit (control unit) harness connector.
4. Check the continuity between vacuum sensor harness connector and ABS actuator and electric unit (control unit) harness connector.

| Vacuum sensor | | ABS actuator and electric unit (control unit) | | Continuity |
|---------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E167 | 1 | E125 | 22 | Yes |
| | 2 | | 20 | |
| | 3 | | 21 | |

5. Check the continuity between vacuum sensor harness connector and ground.

| Vacuum sensor | | — | Continuity |
|---------------|----------|--------|------------|
| Connector | Terminal | | |
| E167 | 1 | Ground | No |
| | 2 | | |
| | 3 | | |

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair / replace harness or connector.

6. REPLACE VACUUM SENSOR

Ⓜ With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Replace the vacuum sensor.

CAUTION:

Always replace brake booster because vacuum sensor cannot be disassembled. Refer to [BR-31, "Removal and Installation"](#).

3. Erase "Self Diagnostic Result" of "ABS".
4. Turn the ignition switch OFF → ON → OFF.

NOTE:

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1197 VACUUM SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Wait at least 10 seconds after turning ignition switch OFF or ON.

5. Start engine.

NOTE:

Wait at least 10 seconds after starting the engine.

6. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1197" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180. "Removal and Installation"](#).

NO >> Inspection End.

C1198 VACUUM SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1198 VACUUM SENSOR

DTC Description

INFOID:000000012853676

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|--|
| C1198 | VACUUM SEN CIR (Vacuum sensor circuit) | <ul style="list-style-type: none"> When an open circuit is detected in vacuum sensor circuit. When a short circuit is detected in vacuum sensor circuit. When a malfunction is detected in vacuum sensor noise. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|--|
| <ul style="list-style-type: none"> Harness or connector ABS actuator and electric unit (control unit) power supply system Fuse Fusible link Battery | <ul style="list-style-type: none"> Harness or connector Vacuum sensor (brake booster) ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

Ⓜ With CONSULT

- Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

- Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

- Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1198" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-147, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853677

1. CHECK CONNECTOR

- Turn the ignition switch OFF.
- Check the vacuum sensor harness connector for disconnection or looseness.
- Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair / replace harness or connector, and GO TO 2.

2. CHECK TERMINAL

C1198 VACUUM SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Disconnect vacuum sensor harness connector.
3. Check the vacuum sensor pin terminals for damage or loose connection with harness connector.
4. Disconnect ABS actuator and electric unit (control unit) harness connector.
5. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness, connector, or terminal.

3. CHECK VACUUM SENSOR CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect vacuum sensor harness connector.
3. Disconnect ABS actuator and electric unit (control unit) harness connector.
4. Check the continuity between vacuum sensor harness connector and ABS actuator and electric unit (control unit) harness connector.

| Vacuum sensor | | ABS actuator and electric unit (control unit) | | Continuity |
|---------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E167 | 1 | E125 | 22 | Yes |
| | 2 | | 20 | |
| | 3 | | 21 | |

5. Check the continuity between vacuum sensor harness connector and ground.

| Vacuum sensor | | — | Continuity |
|---------------|----------|--------|------------|
| Connector | Terminal | | |
| E167 | 1 | Ground | No |
| | 2 | | |
| | 3 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness or connector.

4. REPLACE VACUUM SENSOR

With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Replace the vacuum sensor.

CAUTION:

Always replace brake booster because vacuum sensor cannot be disassembled. Refer to [BR-31, "Removal and Installation"](#).

3. Erase "Self Diagnostic Result" of "ABS"
4. Turn the ignition switch OFF → ON → OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

5. Start engine.

NOTE:

Wait at least 10 seconds after starting the engine.

6. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1198" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Inspection End.

C1199 BRAKE BOOSTER

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1199 BRAKE BOOSTER

DTC Description

INFOID:0000000012853678

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|---|
| C1199 | BRAKE BOOSTER (Brake booster) | When brake booster vacuum is approx. 0 kPa (0 mm Hg) during engine running. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|---|
| <ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) power supply system • Fuse • Fusible link • Battery | <ul style="list-style-type: none"> • Harness or connector • Vacuum sensor (brake booster) • Vacuum piping • ABS actuator and electric unit (control unit) |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

④ With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1199" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-149. "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:0000000012853679

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the vacuum sensor harness connector for disconnection or looseness.
3. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair / replace harness or connector, and GO TO 2.

2. CHECK BRAKE BOOSTER

C1199 BRAKE BOOSTER

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Check the brake booster. Refer to [BR-10, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Replace the brake booster. Refer to [BR-31, "Removal and Installation"](#).

3.CHECK VACUUM PIPING

Check the vacuum piping. Refer to [BR-34, "Exploded View"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace the vacuum piping. Refer to [BR-34, "Removal and Installation"](#).

4.CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect vacuum sensor harness connector.
3. Check the vacuum sensor pin terminals for damage or loose connection with harness connector.
4. Disconnect ABS actuator and electric unit (control unit) harness connector.
5. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair / replace harness, connector, or terminal.

5.CHECK VACUUM SENSOR CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect vacuum sensor harness connector.
3. Disconnect ABS actuator and electric unit (control unit) harness connector.
4. Check the continuity between vacuum sensor harness connector and ABS actuator and electric unit (control unit) harness connector.

| Vacuum sensor | | ABS actuator and electric unit (control unit) | | Continuity |
|---------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E167 | 1 | E125 | 22 | Yes |
| | 2 | | 20 | |
| | 3 | | 21 | |

5. Check the continuity between vacuum sensor harness connector and ground.

| Vacuum sensor | | — | Continuity |
|---------------|----------|--------|------------|
| Connector | Terminal | | |
| E167 | 1 | Ground | No |
| | 2 | | |
| | 3 | | |

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair / replace harness or connector.

6.REPLACE VACUUM SENSOR

Ⓜ With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Replace the vacuum sensor.

CAUTION:

Always replace brake booster because vacuum sensor cannot be disassembled. Refer to [BR-31, "Removal and Installation"](#).

3. Erase "Self Diagnostic Result" of "ABS"
4. Turn the ignition switch OFF → ON → OFF.

C1199 BRAKE BOOSTER

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

5. Start engine.

NOTE:

Wait at least 10 seconds after starting the engine.

6. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C1199" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Inspection End.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C119A VACUUM SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C119A VACUUM SENSOR

DTC Description

INFOID:000000012853680

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|--|
| C119A | VACUUM SEN VOLT (Vacuum sensor voltage) | When a malfunction is detected in supply power voltage of vacuum sensor. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|--|--|
| <ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery | <ul style="list-style-type: none">• Harness or connector• Vacuum sensor (brake booster)• ABS actuator and electric unit (control unit)• ABS actuator and electric unit (control unit) power supply system• Fuse• Fusible link• Battery |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

Ⓟ With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "C119A" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-152, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#)

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853681

1. CHECK CONNECTOR

1. Turn the ignition switch OFF.

2. Check the vacuum sensor harness connector for disconnection or looseness.

3. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness or connector, and GO TO 2.

C119A VACUUM SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

2. CHECK VACUUM SENSOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect vacuum sensor harness connector.
3. Check the voltage between vacuum sensor harness connector and ground.

| Vacuum sensor | | — | Voltage (Approx.) |
|---------------|----------|--------|----------------------|
| Connector | Terminal | | |
| E167 | 3 | Ground | 0 V |

4. Turn the ignition switch ON.
NOTE:
Start the engine.
5. Check the voltage between vacuum sensor harness connector and ground.

| Vacuum sensor | | — | Voltage (Approx.) |
|---------------|----------|--------|----------------------|
| Connector | Terminal | | |
| E167 | 3 | Ground | 5 V |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

3. CHECK VACUUM SENSOR POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the continuity between vacuum sensor harness connector and ABS actuator and electric unit (control unit) harness connector.

| Vacuum sensor | | ABS actuator and electric unit (control unit) | | Continuity |
|---------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E167 | 3 | E125 | 21 | Yes |

4. Check the continuity between vacuum sensor harness connector and ground.

| Vacuum sensor | | — | Continuity |
|---------------|----------|--------|------------|
| Connector | Terminal | | |
| E167 | 3 | Ground | No |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair / replace harness or connector.

4. CHECK VACUUM SENSOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check the continuity between vacuum sensor harness connector and ground.

| Vacuum sensor | | — | Continuity |
|---------------|----------|--------|------------|
| Connector | Terminal | | |
| E167 | 2 | Ground | No |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair / replace harness or connector.

5. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

C119A VACUUM SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Check the ABS actuator and electric unit (control unit) power supply and ground circuits. Refer to [BRC-157](#), "[Diagnosis Procedure](#)".

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair / replace harness, connector, fuse, or fusible link.

6.CHECK TERMINAL

1. Check the vacuum sensor pin terminals for damage or loose connection with harness connector.
2. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180](#), "[Removal and Installation](#)".

NO >> Repair / replace harness, connector, or terminal.

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

U1000 CAN COMM CIRCUIT

DTC Description

INFOID:000000012853682

DTC DETECTION LOGIC

| DTC | Display Item (Trouble diagnosis content) | Malfunction detected condition |
|-------|---|--|
| U1000 | CAN COMM CIRCUIT (CAN communication circuit) | When CAN communication signal is not continuously transmitted or received for 2 seconds or more. |

POSSIBLE CAUSE

NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear the DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

| PAST DTC | CRNT DTC |
|---|--------------------------------------|
| <ul style="list-style-type: none">• Harness or connector• CAN communication line | CAN communication system malfunction |

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF.

NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

NOTE:

Wait at least 10 seconds after starting the engine.

3. Perform "Self Diagnostic Result" of "ABS".

Is DTC "U1000" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-155. "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: Inspection End (Erase "Self Diagnostic Result" of "ABS").

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

Diagnosis Procedure

INFOID:000000012853683

Proceed to [LAN-28. "Trouble Diagnosis Flow Chart"](#).

U0424 HVAC CAN CIRCUIT 1

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

U0424 HVAC CAN CIRCUIT 1

Description

INFOID:0000000012853684

ADAS control unit reads status of signal that is transmitted from A/C auto AMP. to ADAS control unit.

DTC Logic

INFOID:0000000012853685

DTC DETECTION LOGIC

| DTC | Display Item | Malfunction detected condition | Possible causes |
|-------|----------------|--|-----------------|
| U0424 | HVAC CAN CIR 1 | When signal that is transmitted from A/C auto AMP. is not the latest information | A/C auto AMP. |

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSTIC RESULT

Ⓟ With CONSULT.

1. Turn the ignition switch ON.
2. Perform self-diagnostic result for "ICC/ADAS".

Is DTC U0424 detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-156. "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:0000000012853686

1. PERFORM ADAS CONTROL UNIT SELF-DIAGNOSIS

Ⓟ With CONSULT

Perform self-diagnosis for "ICC/ADAS".

Are DTC "U1010" and "U0424" simultaneously detected?

- YES >> Refer to [BRC-155. "Diagnosis Procedure"](#).
NO >> Replace A/C auto AMP. Refer to [HAC-160. "Removal and Installation"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000012853687

1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) IGNITION POWER SUPPLY (1)

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E125 | 28 | Ground | 0 V |

4. Turn the ignition switch ON
NOTE:
Start the engine.
5. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E125 | 28 | Ground | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) IGNITION POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 10A fuse (49).
3. Disconnect IPDM E/R harness connector.
4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R.

| ABS actuator and electric unit (control unit) | | IPDM E/R | | Continuity |
|---|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E125 | 28 | E119 | 35 | Yes |

5. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E125 | 28 | Ground | No |

Is the inspection result normal?

- YES >> Perform trouble diagnosis for ignition power supply.
NO >> Repair / replace harness, connector, or fuse.

3. CHECK MOTOR AND MOTOR RELAY POWER SUPPLY

1. Turn the ignition switch OFF.
2. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E125 | 3 | Ground | Battery voltage |

3. Turn the ignition switch ON.
NOTE:

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Start the engine.

4. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E125 | 3 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

4.CHECK MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 50A fusible link (I).
3. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal 4 and 50A fusible link (I).

Is the inspection result normal?

YES >> Perform trouble diagnosis for battery power supply.

NO >> Repair / replace harness, connector, or fusible link.

5.CHECK ACTUATOR RELAY, ABS IN VALVE, ABS OUT VALVE POWER SUPPLY

1. Turn the ignition switch OFF.
2. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E125 | 1 | Ground | Battery voltage |

3. Turn the ignition switch ON

NOTE:

Start the engine.

4. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

| ABS actuator and electric unit (control unit) | | — | Voltage (Approx.) |
|---|----------|--------|-------------------|
| Connector | Terminal | | |
| E125 | 1 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

6.CHECK ACTUATOR RELAY, ABS IN VALVE, ABS OUT VALVE POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 30A fusible link (J).
3. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal 3 and 30A fusible link (J).

Is the inspection result normal?

YES >> Perform trouble diagnosis for battery power supply.

NO >> Repair / replace harness, connector, or fusible link.

7.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E125 | 4 | Ground | Yes |
| | 2 | | |

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair / replace harness, connector, or terminal.

8. CHECK TERMINAL

1. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
2. Check the IPDM E/R pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Repair / replace harness, connector, or terminal.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

PARKING BRAKE SWITCH

Component Function Check

INFOID:000000012853688

1.COMBINATION METER INPUT SIGNAL

1. Start engine.
2. Check PKB SW in DATA MONITOR while applying and releasing the parking brake.

Condition **CONSULT**
Parking brake applied : **ON**
Parking brake released : **OFF**

>> Inspection End.

Diagnosis Procedure

INFOID:000000012853689

Regarding Wiring Diagram information, refer to [MWI-29, "Wiring Diagram - With Automatic Drive Positioner"](#) or [MWI-48, "Wiring Diagram - Without Automatic Drive Positioner"](#).

1.CHECK PARKING BRAKE SWITCH CIRCUIT

1. Disconnect combination meter harness connector M24 and parking brake switch harness connector E52.
2. Check continuity between combination meter harness connector M24 terminal 12 and parking brake switch harness connector E52 terminal 1.

12 - 1 : **Continuity should exist.**

3. Check continuity between combination meter harness connector M24 terminal 12 and ground.

12 - Ground : **Continuity should not exist.**

Is the inspection result normal?

- YES >> Inspection End.
NO >> Repair or replace harness or connectors.

Component Inspection

INFOID:000000012853690

1.CHECK PARKING BRAKE SWITCH

Check continuity between parking brake switch terminal 1 and switch case ground.

| Component | Terminal | Condition | Continuity |
|----------------------|----------|------------------------|------------|
| Parking brake switch | 1 | Parking brake applied | Yes |
| | | Parking brake released | No |

Is the inspection result normal?

- YES >> Inspection End.
NO >> Replace parking brake switch. Refer to [PB-7, "Exploded View"](#).

VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

VDC OFF SWITCH

Component Function Check

INFOID:000000012853691

1.CHECK VDC OFF SWITCH OPERATION

Check that VDC OFF indicator lamp in combination meter turns ON/OFF when VDC OFF switch is operated.

Is the inspection result normal?

YES >> Inspection End.

NO >> Proceed to diagnosis procedure. Refer to [BRC-161, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000012853692

Regarding Wiring Diagram information, refer to [BRC-60, "Wiring Diagram"](#).

1.CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector E125 and VDC OFF switch connector M71.
3. Check connectors and terminals for deformation, disconnection, looseness or damage.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace as necessary.

2.CHECK VDC OFF SWITCH

Check VDC OFF switch. Refer to [BRC-162, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace VDC OFF switch.

3.CHECK VDC OFF SWITCH SIGNAL

ⓂWith CONSULT.

1. Connect ABS actuator and electric unit (control unit) connector E125 and VDC OFF switch connector M71.
2. Turn ignition switch ON.
3. In "DATA MONITOR" select "OFF SW" and check VDC OFF switch signal.

| Condition | DATA MONITOR |
|--|--------------|
| VDC OFF switch is pressed and released | On |
| VDC OFF switch is pressed and released again | Off |

Is the inspection result normal?

YES >> Refer to [BRC-78, "Work Flow"](#).

NO >> GO TO 4.

4.CHECK VDC OFF SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector E125 and VDC OFF switch connector M71.
3. Check continuity between ABS actuator and electric unit (control unit) connector E125 terminal 30 and VDC OFF switch connector M71 terminal 1.

| ABS actuator and electric unit (control unit) | | VDC OFF switch | | Continuity |
|---|----------|----------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| E125 | 9 | M71 | 1 | Yes |

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

4. Check continuity between ABS actuator and electric unit (control unit) connector terminal E125 terminal 30 and ground.

| ABS actuator and electric unit (control unit) | | — | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| E125 | 9 | Ground | No |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5.CHECK VDC OFF SWITCH GROUND CIRCUIT

Check continuity between VDC OFF switch connector M71 terminal 2 and ground.

| VDC OFF switch | | — | Continuity |
|----------------|----------|--------|------------|
| Connector | Terminal | | |
| M71 | 2 | Ground | Yes |

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:0000000012853693

1.CHECK VDC OFF SWITCH

1. Turn ignition switch OFF.
2. Disconnect VDC OFF switch connector.
3. Check continuity between terminals of VDC OFF switch connector.

| VDC OFF switch terminals | Condition | Continuity |
|--------------------------|-------------------------|------------|
| 1 – 2 | VDC OFF switch pressed | Yes |
| | VDC OFF switch released | No |

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace VDC OFF switch.

ABS WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS WARNING LAMP

Component Function Check

INFOID:000000012853694

1. CHECK ABS WARNING LAMP FUNCTION

Check that ABS warning lamp in combination meter turns ON for approximately 2 seconds after ignition switch is turned ON.

Is the inspection result normal?

YES >> Inspection End.

NO >> Proceed to diagnosis procedure. Refer to [BRC-163, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000012853695

1. PERFORM THE SELF-DIAGNOSIS

 With CONSULT.

Perform self-diagnostic result.

Are any DTCs detected?

YES >> Refer to [BRC-47, "DTC Index"](#).

NO >> GO TO 2.

2. CHECK COMBINATION METER

Check if indication and operation of combination meter are normal. Refer to [MWI-9, "METER SYSTEM : System Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Replace combination meter. Refer to [MWI-94, "Removal and Installation"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

BRAKE WARNING LAMP

Component Function Check

INFOID:000000012853696

1. CHECK BRAKE WARNING LAMP FUNCTION (1)

Check that brake warning lamp in combination meter turns ON for approximately 2 seconds after ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-164, "Diagnosis Procedure"](#).

2. CHECK BRAKE WARNING LAMP FUNCTION (2)

Check that brake warning lamp in combination meter turns ON/OFF when parking brake is operated.

Is the inspection result normal?

YES >> Inspection End.

NO >> Check parking brake switch system. Refer to [MWI-82, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000012853697

1. PERFORM THE SELF-DIAGNOSIS

Ⓟ With CONSULT.

Perform self-diagnostic result.

Are any DTCs detected?

YES >> Refer to [BRC-47, "DTC Index"](#).

NO >> GO TO 2.

2. CHECK COMBINATION METER

Check if indication and operation of combination meter are normal. Refer to [MWI-9, "METER SYSTEM : System Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Replace combination meter. Refer to [MWI-94, "Removal and Installation"](#).

VDC OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

VDC OFF INDICATOR LAMP

Component Function Check

INFOID:000000012853698

1.CHECK VDC OFF INDICATOR LAMP FUNCTION (1)

Check that VDC OFF indicator lamp in combination meter turns ON for approximately 2 seconds after ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-165, "Diagnosis Procedure"](#)

2.CHECK VDC OFF INDICATOR LAMP FUNCTION (2)

Check that VDC OFF indicator lamp in combination meter turns ON/OFF when VDC OFF switch is operated.

Is the inspection result normal?

YES >> Inspection End.

NO >> Check VDC OFF switch. Refer to [BRC-161, "Diagnosis Procedure"](#)

Diagnosis Procedure

INFOID:000000012853699

BRC

1.PERFORM THE SELF-DIAGNOSIS

Ⓜ With CONSULT.

Perform self diagnostic result.

Are any DTCs detected?

YES >> Refer to [BRC-47, "DTC Index"](#).

NO >> GO TO 2.

2.CHECK COMBINATION METER

Check if indication and operation of combination meter are normal. Refer to [MWI-9, "METER SYSTEM : System Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Replace combination meter. Refer to [MWI-94, "Removal and Installation"](#).

SLIP INDICATOR LAMP

Component Function Check

INFOID:000000012853700

1. CHECK SLIP INDICATOR LAMP FUNCTION

Check that slip indicator lamp in combination meter turns ON for approximately 2 seconds after ignition switch is turned ON.

Is the inspection result normal?

YES >> Inspection End.

NO >> Proceed to diagnosis procedure. Refer to [BRC-166, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000012853701

1. PERFORM THE SELF-DIAGNOSIS

With CONSULT.

Perform self diagnostic result.

Are any DTCs detected?

YES >> Refer to [BRC-47, "DTC Index"](#).

NO >> GO TO 2.

2. CHECK COMBINATION METER

Check if indication and operation of combination meter are normal. Refer to [MWI-9, "METER SYSTEM : System Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-180, "Removal and Installation"](#).

NO >> Replace combination meter. Refer to [MWI-94, "Removal and Installation"](#).

SYMPTOM DIAGNOSIS

VDC/TCS/ABS

Symptom Table

INFOID:0000000012853702

If ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp turn ON, perform self-diagnosis.

| Symptom | Check item | Reference |
|--|--|--|
| Excessive ABS function operation frequency | Brake force distribution | BRC-168. "Diagnosis Procedure" |
| | Looseness of front and rear axle | |
| | Wheel sensor and rotor system | |
| Unexpected pedal reaction | Brake pedal stroke | BRC-169. "Diagnosis Procedure" |
| | Make sure the braking force is sufficient when the ABS is not operating. | |
| The braking distance is long | Check stopping distance when the ABS is not operating. | BRC-170. "Diagnosis Procedure" |
| ABS function does not operate (Note 1) | ABS actuator and electric unit (control unit) | BRC-171. "Diagnosis Procedure" |
| Pedal vibration or ABS operation sound occurs (Note 2) | Brake pedal | BRC-172. "Diagnosis Procedure" |
| | ABS actuator and electric unit (control unit) | |
| Vehicle jerks during VDC/TCS/ABS control | ABS actuator and electric unit (control unit) | BRC-173. "Diagnosis Procedure" |
| | TCM | |
| | ECM | |

NOTE:

- 1: The ABS does not operate when the speed is 10 km/h (6 MPH) or less.
- 2: Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.
 - When shifting gears
 - When driving on slippery road
 - During cornering at high speed
 - When passing over bumps or grooves [approximately 50 mm (1.97 in) or more]
 - When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

EXCESSIVE OPERATION FREQUENCY

[VDC/TCS/ABS]

< SYMPTOM DIAGNOSIS >

EXCESSIVE OPERATION FREQUENCY

Description

INFOID:000000012853703

VDC function, TCS function, ABS function, EBD function, hill start assist function or Brake force distribution function operates in excessive operation frequency.

Diagnosis Procedure

INFOID:000000012853704

1. CHECK BRAKING FORCE

Check brake force using a brake tester.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

2. CHECK FRONT AND REAR AXLE

Check that there is no excessive looseness in front and rear axle.

- Front axle: Refer to [FAX-7, "Inspection"](#).
- Rear axle: Refer to [RAX-6, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3. CHECK WHEEL SENSOR

Check wheel sensor.

- Check installation and damage of wheel sensor.
- Check connection of wheel sensor harness connector.
- Check terminal of wheel sensor harness connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair installation or replace wheel sensor.

- Front wheel sensor: Refer to [BRC-175, "Removal and Installation - Front Wheel Sensor"](#).
- Rear wheel sensor: Refer to [BRC-177, "Removal and Installation - Rear Wheel Sensor"](#).

4. CHECK SENSOR ROTOR

Check that there is no looseness, damage or foreign material on sensor rotor.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair installation or replace sensor rotor.

- Front sensor rotor: Refer to [BRC-179, "Removal and Installation - Front Sensor Rotor"](#).
- Rear sensor rotor: Refer to [BRC-179, "Removal and Installation - Rear Sensor Rotor"](#).

5. CHECK WARNING LAMP TURNS OFF

Check that ABS warning lamp, brake warning lamp and VDC warning lamp turn OFF approx. 1 second after key switch is turned ON and stay in OFF status during driving.

CAUTION:

Brake warning lamp turns ON when parking brake is operated (parking brake switch is ON) or brake fluid is less than the specified level (brake fluid level switch is ON).

Is the inspection result normal?

YES >> Inspection End.

NO >> Perform self-diagnosis result. Refer to [BRC-37, "CONSULT Function"](#).

UNEXPECTED BRAKE PEDAL REACTION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

UNEXPECTED BRAKE PEDAL REACTION

Description

INFOID:000000012853705

A malfunction of brake pedal feel (height or others) is detected when brake pedal is depressed.

Diagnosis Procedure

INFOID:000000012853706

1.CHECK FRONT AND REAR AXLE

Check that there is no excessive looseness in front and rear axle.

- Front axle: Refer to [FAX-7. "Inspection"](#).
- Rear axle: Refer to [RAX-6. "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace malfunctioning components.

2.CHECK DISC ROTOR

Check disc rotor runout.

- Front: Refer to [BR-11. "DISC ROTOR : Inspection"](#).
- Rear: Refer to [BR-12. "DISC ROTOR : Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Refinish the disc rotor.

3.CHECK BRAKE FLUID LEAKAGE

Check fluid leakage. Refer to [BR-8. "Inspection"](#)

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace malfunctioning components.

4.CHECK BRAKE PEDAL

Check brake pedal. Refer to [BR-7. "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Adjust brake pedal. Refer to [BR-13. "Adjustment"](#).

5.CHECK BRAKING FORCE

Check brake force using a brake tester.

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Check brake system.

6.CHECK BRAKE PERFORMANCE

Disconnect ABS actuator and electric unit (control unit) connector so that ABS does not operate. Check that brake force is normal in this condition. Connect harness connectors after checking.

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Check brake system.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

THE BRAKING DISTANCE IS LONG

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

THE BRAKING DISTANCE IS LONG

Description

INFOID:000000012853707

Brake stopping distance is long when ABS function is operated.

Diagnosis Procedure

INFOID:000000012853708

CAUTION:

Brake stopping distance on slippery roads like a rough road, gravel road or snowy road may become longer when ABS is operated than when ABS is not operated.

1.CHECK BRAKING FORCE

Check brake force using a brake tester.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

2.CHECK BRAKE PERFORMANCE

Disconnect ABS actuator and electric unit (control unit) connector so that ABS does not operate. Check brake stopping distance in this condition. Connect harness connectors after checking.

Is the inspection result normal?

YES >> Inspection End.

NO >> Check brake system.

ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

ABS FUNCTION DOES NOT OPERATE

Description

INFOID:000000012853709

VDC function, TCS function, ABS function, EBD function, hill start assist function or Brake force distribution function does not operate.

Diagnosis Procedure

INFOID:000000012853710

CAUTION:

- VDC function, TCS function, ABS function, EBD function, hill start assist function and Brake force distribution function never operate when the vehicle speed is 10 km/h (6.2 MPH) or less. However, hill start assist function operates when the vehicle speed is 0 km/h (0 MPH) (the vehicle is in stop status).
- VDC function and TCS function never operate when VDC OFF switch is operated (when VDC OFF indicator lamp turns ON).

1.CHECK ABS WARNING LAMP

Check that ABS warning lamp, brake warning lamp and VDC warning lamp turn ON and turn OFF approx. 1 second after key switch is turned ON. Check that ABS warning lamp, brake warning lamp and VDC warning lamp and stay in OFF status during driving.

CAUTION:

Brake warning lamp turns ON when parking brake is operated (parking brake switch is ON) or brake fluid is less than the specified level (brake fluid level switch is ON).

Is the inspection result normal?

YES >> Inspection End.

NO >> Perform self-diagnosis result. Refer to [BRC-37. "CONSULT Function"](#).

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

BRAKE PEDAL VIBRATION OR OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

BRAKE PEDAL VIBRATION OR OPERATION SOUND OCCURS

Description

INFOID:000000012853711

- Brake pedal vibrates and motor sound from ABS actuator and electric unit (control unit) occurs when the engine starts.
- Brake pedal vibrates during braking.

CAUTION:

Vibration may be felt during brake pedal is lightly depressed (just placing a foot on it) in the following conditions. This is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [Approx. 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approx. 10 km/h (6.2 MPH) or higher]

Diagnosis Procedure

INFOID:000000012853712

1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Check brake pedal. Refer to [BR-7, "Inspection"](#).

2. SYMPTOM CHECK 2

Check that motor sound from ABS actuator occurs when the engine starts.

Does the operation sound occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis result. Refer to [BRC-37, "CONSULT Function"](#).

3. SYMPTOM CHECK 3

Check symptoms when electrical component (head lamps, etc.) switches are operated.

Does the symptom occur?

YES >> Check that radio (including wiring), antenna and antenna lead-in wires are not located near ABS actuator and electric unit (control unit). Move them if they are located near ABS actuator and electric unit (control unit).

NO >> Inspection End.

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

Description

INFOID:000000012853713

The vehicle jerks when VDC function, TCS function, ABS function, EBD function, hill start assist function or Brake force distribution function operates.

Diagnosis Procedure

INFOID:000000012853714

1. CHECK SYMPTOM


Check that the vehicle jerks when VDC function, TCS function, ABS function, EBD function, hill start assist function or Brake force distribution function operates.

Is the inspection result normal?

YES >> Inspection End.

NO >> GO TO 2.

2. PERFORM THE SELF-DIAGNOSIS

 With CONSULT


Perform self-diagnosis result. Refer to [BRC-37. "CONSULT Function"](#).

Is any DTC detected?

YES >> Check the DTC. Refer to [BRC-47. "DTC Index"](#).

NO >> GO TO 3.

3. CHECK CONNECTOR

 With CONSULT

1. Turn the ignition switch OFF.

2. Disconnect ABS actuator and electric unit (control unit) harness connector.

3. Check connector terminal for deformation, disconnection and looseness.


4. Connect harness connector and perform self-diagnosis result. Refer to [BRC-37. "CONSULT Function"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace connector terminal.

4. CHECK ECM AND TCM SELF-DIAGNOSIS RESULTS

 With CONSULT

Perform self-diagnosis result for "ENGINE" and "TRANSMISSION".

Is any DTC detected?

YES >> Check the DTC.

NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-180. "Removal and Installation"](#).

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

NORMAL OPERATING CONDITION

Description

INFOID:000000012853715

| Symptom | Result |
|--|--|
| Brake pedal slightly vibrates and operation sound (motor sound and sound from suspension) occurs when VDC function, TCS function, ABS function, EBD function, hill start assist function, Brake force distribution function or Active trace control function operates. | This is not a malfunction, because it is caused by VDC function, TCS function, ABS function, EBD function, hill start assist function, Brake force distribution function and Active trace control function that are normally operated. |
| Brake stopping distance may become longer than models without ABS function depending on the road conditions, when ABS function is operated on slippery road like rough road, gravel road or snowy road. | |
| Brake pedal vibrates and operation sound occurs during sudden acceleration and cornering, when VDC function, TCS function, Brake force distribution function or Active trace control function is operated. | |
| Brake pedal vibrates and motor sound from the engine room occurs when the engine starts or the vehicle starts just after starting the engine. | This is not a malfunction because it is caused by operation check of ABS actuator and electric unit (control unit). |
| Acceleration may be felt insufficient depending on the road conditions. | This is not a malfunction because it is caused by TCS function that puts the highest priority to obtain the optimum traction (stability). |
| TCS function may operate momentarily while driving on a road where friction coefficient varies or when downshifting or fully depressing accelerator pedal. | |
| ABS warning lamp and VDC warning lamp may turn ON when the vehicle is on a rotating turntable or is given a strong shaking or large vibrations on a ship while the engine is running. | In this case, restart the engine on a normal road. If the normal condition is restored, there is no malfunction. In that case, erase "ABS" self-diagnosis result memory with CONSULT. |
| VDC warning lamp may turn ON and VDC function, TCS function, Brake force distribution function and Active trace control function may not normally operate, when driving on a special road the is extremely slanted (bank in a circuit course). | |
| A malfunction in yaw rate/side/decel G sensor system may be detected when the vehicle sharply turns during a spin turn, acceleration turn or drift driving while VDC function, TCS function, Brake force distribution function and Active trace control function are OFF (VDC OFF switch is pressed and VDC OFF indicator lamp is in ON status). | |
| The vehicle speed does not increase when the accelerator pedal is depressed while the vehicle is on a 2-wheel chassis dynamometer for speedometer check. | This is normal. (When checking the vehicle on a chassis dynamometer, operate VDC OFF switch so that TCS function is OFF.) |

WHEEL SENSOR

< UNIT REMOVAL AND INSTALLATION >


[VDC/TCS/ABS]

UNIT REMOVAL AND INSTALLATION

WHEEL SENSOR

Exploded View - Front Wheel Sensor

INFOID:0000000012853716



1. Front wheel sensor

A. Color line (slant line)

B. Front wheel sensor connector

⇐ Front

Removal and Installation - Front Wheel Sensor

INFOID:0000000012853717

CAUTION:

- Be careful not to damage front wheel sensor edge and sensor rotor teeth.
- When removing the front wheel hub and bearing, first remove the front wheel sensor from the steering knuckle. Failure to do so may result in damage to the front wheel sensor wires making the front wheel sensor inoperative.
- Pull out the front wheel sensor, being careful to turn it as little as possible. Do not pull on the front wheel sensor harness.
- Before installation, check if foreign objects such as iron fragments are adhered to the pick-up part of the front wheel sensor or to the inside of the hole in the steering knuckle for the front wheel sensor, or if a foreign object is caught in the surface of the mating surface for the sensor rotor. Fix as necessary and then install the front wheel sensor.

REMOVAL

1. Remove the front wheel and tire using power tool. Refer to [WT-52, "Adjustment"](#).
2. Partially remove the fender protector to gain access to the wheel sensor connector.
3. Disconnect the front wheel sensor harness connector.
4. Remove the front wheel sensor bolt.
5. Remove the front wheel sensor from the strut bracket and body brackets.
6. Remove the front wheel sensor from the steering knuckle.

INSTALLATION

WHEEL SENSOR


< UNIT REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

Installation is in the reverse order of the removal.

CAUTION:


- When installing, make sure there is no foreign material such as iron chips on and in the hole in the steering knuckle for the front wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- Do not twist front wheel sensor harness when installing front wheel sensor. Check that grommet (2) is fully inserted to bracket (1). Check that front wheel sensor harness is not twisted after installation.



Exploded View - Rear Wheel Sensor

INFOID:000000012853718

RH Side




- | | | |
|--------------------------------|------------------------------|---------|
| 1. Rear wheel sensor | A. Rear wheel sensor bracket | B. Clip |
| C. Rear wheel sensor connector | ↶ Front | |

WHEEL SENSOR

< UNIT REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

LH Side



- | | | |
|------------------------------|--------------------------------|---------|
| 1. Rear wheel sensor | A. Rear wheel sensor connector | B. Clip |
| C. Rear wheel sensor bracket | ← Front | |

Removal and Installation - Rear Wheel Sensor

INFOID:000000012853719

CAUTION:

- Be careful not to damage rear wheel sensor edge and sensor rotor teeth.
- When removing the rear wheel hub and bearing, first remove the rear wheel sensor from the rear knuckle. Failure to do so may result in damage to the rear wheel sensor wires making the rear wheel sensor inoperative.
- Pull out the rear wheel sensor, being careful to turn it as little as possible. Do not pull on the rear wheel sensor harness.
- Before installation, check if foreign objects such as iron fragments are adhered to the pick-up part of the rear wheel sensor or to the inside of the hole in the rear knuckle for the wheel sensor, or if a foreign object is caught in the surface of the mating surface for the sensor rotor. Fix as necessary and then install the rear wheel sensor.

REMOVAL

1. Remove the rear wheel and tire using power tool. Refer to [WT-52. "Adjustment"](#).
2. Remove the rear wheel sensor bolt.
3. Disconnect the rear wheel sensor harness connector.
4. Remove the rear wheel sensor from the sensor brackets.
5. Remove the rear wheel sensor from the rear knuckle.

INSTALLATION

Installation is in the reverse order of the removal.

CAUTION:


A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

WHEEL SENSOR

< UNIT REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

- When installing, make sure there is no foreign material such as iron chips on and in the hole in the rear knuckle for the rear wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- Do not twist rear wheel sensor harness when installing rear wheel sensor. Check that grommet (2) is fully inserted to bracket (1). Check that rear wheel sensor harness is not twisted after installation.



SENSOR ROTOR

< UNIT REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

SENSOR ROTOR

Removal and Installation - Front Sensor Rotor

INFOID:000000012853720

The front wheel sensor rotor is an integral part of the wheel hub and bearing and cannot be disassembled. Refer to [FAX-8, "Removal and Installation"](#).

Removal and Installation - Rear Sensor Rotor

INFOID:000000012853721

The rear wheel sensor rotor is an integral part of the wheel hub and bearing and cannot be disassembled. Refer to [RAX-7, "Removal and Installation"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< UNIT REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000012853722



- | | | |
|--|--------------------------------------|--|
| 1. ABS actuator and electric unit (control unit) | 2. Bracket | A. From master cylinder secondary side |
| B. To front RH brake caliper | C. To rear LH brake caliper | D. To rear RH brake caliper |
| E. To front LH brake caliper | F. From master cylinder primary side | ⇐ Front |

Removal and Installation

INFOID:000000012853723

REMOVAL

CAUTION:

- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged.
- Do not remove actuator by holding harness.

NOTE:

When removing components such as hoses, tubes/lines, etc., cap or plug openings to prevent fluid from spilling.

1. Disconnect the negative battery terminal. Refer to [PG-147, "Exploded View"](#).
2. Remove cowl top and cowl top extension. Refer to [EXT-25, "Removal and Installation"](#).
3. Disconnect the harness connector from the ABS actuator and electric unit (control unit).
4. Separate brake tubes from ABS actuator and electric unit (control unit). Refer to [BR-22, "FRONT : Exploded View"](#).
5. Remove ABS actuator and electric unit (control unit) bracket bolt.
6. Remove ABS actuator and electric unit (control unit) from vehicle.

INSTALLATION

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< UNIT REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

Installation is in the reverse order of removal.

- After work is completed, bleed air from brake tube. Refer to [BR-14, "Bleeding Brake System"](#).
- Adjust the neutral position of steering angle sensor. Refer to [BRC-82, "Work Procedure"](#).
- Perform calibration of yaw rate/side/decel G sensor. Refer to [BRC-84, "Work Procedure"](#).

CAUTION:

- **To install, use flare nut crowfoot and torque wrench.**
- **Do not apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.**
- **Do not install actuator by holding harness.**
- **After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.**

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

VDC OFF SWITCH

< UNIT REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]


VDC OFF SWITCH

Removal and Installation

INFOID:000000013480168


REMOVAL

1. Remove instrument lower panel LH. Refer to [IP-25. "Removal and Installation"](#).
2. Remove screws (A) and (B) and remove the lower switch carrier assembly (2).
3. Remove the screws (C) from the upper switch carrier assembly (1) and remove upper switch carrier.



4. Release pawls using suitable tool and remove the VDC OFF switch from the upper switch carrier.

○: Pawl



INSTALLATION

Installation is in the reverse order of removal.

STEERING ANGLE SENSOR

< UNIT REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

STEERING ANGLE SENSOR

Removal and Installation

INFOID:000000012853726

To remove and install the steering angle sensor, remove and install spiral cable. Refer to [SR-15. "Removal and Installation"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000014224280

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes dual stage front air bag modules. The SRS system may only deploy one front air bag, depending on the severity of a collision and whether the front passenger seat is occupied. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, it is recommended that all maintenance and repair be performed by an authorized NISSAN/INFINITI dealer.
- Improper repair, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery or batteries, and wait at least three minutes before performing any service.

Precaution for FEB System Service

INFOID:000000014224335

WARNING:

- Failure to follow the warnings and instructions for proper use of the FEB with pedestrian detection system could result in serious injury or death.
- The FEB with pedestrian detection system is a supplemental aid to the driver. It is not a replacement for the driver's attention to traffic conditions or responsibility to drive safely. It cannot prevent accidents due to carelessness or dangerous driving techniques.
- The FEB with pedestrian detection system does not function in all driving, traffic, weather, and road conditions.
- Listed below are the system limitations for the FEB with pedestrian detection system. Failure to operate the vehicle in accordance with these system limitations could result in serious injury or death.
 - The FEB with pedestrian detection system cannot detect all vehicles or pedestrians under all conditions.
 - The FEB with pedestrian detection system does not detect the following objects:
 - Small pedestrians (including small children), animals and cyclists.
 - Pedestrians in wheel chairs or using mobile transport such as scooters, child-operated toys, or skateboards.
 - Pedestrians who are seated or otherwise not in a full upright standing or walking position.
 - Oncoming vehicles
 - Crossing vehicles
 - Obstacles on the roadside.

CAUTION:

- The FEB with pedestrian detection system has some performance limitations, for example:
 - If a stationary vehicle is in the vehicle's path, the FEB with pedestrian detection system will not function when the vehicle is driven at speeds over approximately 50 MPH (80 km/h).

PRECAUTIONS

< PRECAUTION >


[FORWARD EMERGENCY BRAKING]

- For pedestrian detection, the FEB with pedestrian detection system will not function when the vehicle is driven at speeds over approximately 37 MPH (60 km/h) or below approximately 6 MPH (10 km/h).
 - The FEB with pedestrian detection system will not function for pedestrians in darkness or in tunnels, even if there is street lighting in the areas.
 - For pedestrians, the FEB with pedestrian detection system will not issue the first warning and will not push the accelerator pedal up
-
- The vehicles brake lights come on when any braking is performed by the FEB with pedestrian detection system. Depending on vehicle speed and distance to the vehicle or pedestrian ahead, as well as driving and roadway conditions, the system may help the driver avoid a forward collision or may help mitigate the consequences if a collision should be unavoidable. If the driver is handling the steering wheel, accelerating or braking, the FEB with pedestrian detection system will function later or not function.
 - The automatic braking will cease under the following conditions:
 - When the steering wheel is turned to avoid a collision.
 - When the accelerator pedal is depressed.
 - When there is no longer a vehicle or pedestrian detected ahead.
 - If the FEB with pedestrian detection system has stopped the vehicle, the vehicle will remain at a standstill for approximately 2 seconds before the brakes are released.
 - The FEB with pedestrian detection system will be automatically turned on when the engine is started.
 - The PFCW system (if equipped) is integrated into the FEB with pedestrian detection system. There is not a separate selection in the vehicle information display for the PFCW system. When the FEB with pedestrian detection is turned off, the PFCW system is also turned off.


Precaution for Harness Repair

INFOID:000000014224336

- Solder the repair part, and wrap it with tape. [Twisted wire fray must be 110 mm (4.33 in) or less.]



- Do not bypass the repair point with wire. (If it is bypassed, the turn-out point cannot be separated and the twisted wire characteristics are lost.)



COMPONENT PARTS

< SYSTEM DESCRIPTION >


[FORWARD EMERGENCY BRAKING]

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000014170316



- A. Rear view mirror area
- B. Back side of engine room (RH) (view with relay cover removed)
- C. Radiator core support assembly (RH)
- C. Upper side of brake pedal (view with instrument panel LH removed)

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

Component Description


INFOID:000000014170317

| No. | Component | Function | |
|-----|---|--|--|
| 1. | ICC steering switch | Refer to CCS-11, "ICC Steering Switch" | |
| 2. | Combination meter | Refer to MWI-6, "METER SYSTEM : Component Parts Location" | |
| 3. | Lane camera unit | Refer to BRC-188, "Lane Camera Unit" | |
| 4. | ICC brake hold relay | Refer to BRC-189, "ICC Brake Hold Relay" | |
| 5. | ABS actuator and electric unit (control unit) | Pump/motor | Refer to BRC-11, "ABS Actuator and Electric Unit (Control Unit)" |
| | | Motor relay | |
| | | Actuator relay (main relay) | |
| | | ABS IN valve | |
| | | ABS OUT valve | |
| | | Cut valve 1 | |
| | | Cut valve 2 | |
| 6. | ICC sensor | Refer to BRC-188, "ICC Sensor" | |
| 7. | TCM | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> • Shift position signal • Current gear position signal | |
| 8. | ECM | Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> • Accelerator pedal position signal • Engine speed signal Mainly receives the following signal from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> • Target throttle position signal | |
| 9. | Warning buzzer | Refer to BRC-189, "Driver Assistance Buzzer" | |
| 10. | Driver assistance buzzer control module | Refer to BRC-189, "Driver Assistance Buzzer Control Module" | |
| 11. | Stop lamp switch | Refer to BRC-188, "Brake Pedal Position Switch / Stop Lamp Switch" | |
| 12. | Brake pedal position switch | | |
| 13. | ADAS control unit | Refer to BRC-187, "ADAS Control Unit" | |

ADAS Control Unit

INFOID:000000014170318

- ADAS control unit is installed at trunk side of the parcel shelf.
- Communicates with each control unit via CAN communication/ITS communication/Chassis communication.
- ADAS control unit included gateway function, and necessary for system control signals are transmitted to each control unit between CAN communication and ITS communication by the ADAS control unit.
- ADAS control unit controls the each system, based on ITS communication signal, CAN communication signal, and chassis communication signal from each control unit.



COMPONENT PARTS


< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

ICC Sensor

INFOID:000000014170319


- ICC sensor is installed on the back of the front bumper and detects a vehicle ahead by using millimeter waves.
- ICC sensor detects radar reflected from a vehicle ahead by irradiating radar forward and calculates a distance from the vehicle ahead and relative speed, based on the detected signal.
- ICC sensor transmits the presence/absence of vehicle ahead and the distance from the vehicle to ADAS control unit via ITS communication.



Lane Camera Unit

INFOID:000000014203040


- Lane camera unit is installed to windshield, and detects the lane marker in travel lane and pedestrian ahead.
- Transmits the signal to ADAS control unit and ADAS control unit 2 via chassis communication.




Brake Pedal Position Switch / Stop Lamp Switch

INFOID:000000014170320

- Brake pedal position switch is installed at the upper part of the brake pedal and detects a brake operation performed by the driver.




- Brake pedal position switch is turned OFF when depressing the brake pedal.
- Brake pedal position switch signal is input to ECM. Brake pedal position switch signal is transmitted from ECM to ADAS control unit via CAN communication. (VQ35DE)
- Stop lamp switch is installed at the upper part of the brake pedal and detects a brake operation performed by the driver.
- Stop lamp switch is turned ON, when depressing the brake pedal.
- Stop lamp switch signal is input to ECM and ABS actuator and electric unit (control unit). Stop lamp switch signals are transmitted from ECM and ABS actuator and electric unit (control unit) to ADAS control unit via CAN communication. (VQ35DE)



ICC Brake Hold Relay

INFOID:000000014170321


- ICC brake hold relay is installed in the engine room (right side).
- When the brake is activated by the system, the ICC brake hold relay turns ON the stop lamp by bypassing the circuit of the stop lamp, according to a signal transmitted from the ADAS control unit.



Accelerator Pedal Actuator

INFOID:000000014170322


- Installed to the upper portion of the accelerator pedal, this consists of the accelerator pedal actuator together with the accelerator pedal position sensor, and is linked with the accelerator pedal.
- If accelerator pedal feedback force control signal is received from ADAS control unit via ITS communication, it operates the integrated motor for applying control to move the accelerator pedal upward.



Driver Assistance Buzzer Control Module

INFOID:000000014170323


- Driver assistance buzzer control module is installed at the behind of glove box.
- When driver assistance buzzer signal is received from the ADAS control unit, the driver assistance buzzer control module transmits the warning buzzer signal to driver assistance buzzer.



Driver Assistance Buzzer

INFOID:000000014170324

- Driver assistance buzzer is installed at the behind the display control unit.
- When a warning buzzer signal is received from the driver assistance buzzer control module, the driver assistance buzzer sounds a buzzer.




A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

SYSTEM

System Description

INFOID:000000014170325

SYSTEM DIAGRAM



ADAS CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Input Signal Item

| Transmit unit | | Signal name | Description |
|---------------|-------------------|------------------------------------|--|
| ECM | CAN communication | Closed throttle position signal | Receives idle position state (ON/OFF) |
| | | Accelerator pedal position signal | Receives accelerator pedal position (angle) |
| | | Engine speed signal | Receives engine speed |
| | | Stop lamp switch signal | Receives an operational state of the brake pedal |
| | | Brake pedal position switch signal | Receives an operational state of the brake pedal |
| TCM | CAN communication | Input speed signal | Receives the number of revolutions of input shaft |
| | | Current gear position signal | Receives a current gear position |
| | | Shift position signal | Receives a selector lever position |
| | | Output shaft revolution signal | Receives the number of revolutions of output shaft |

SYSTEM

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Transmit unit | Signal name | | Description |
|---|-------------------|--|--|
| ABS actuator and electric unit (control unit) | CAN communication | ABS malfunction signal | Receives a malfunction state of ABS |
| | | ABS operation signal | Receives an operational state of ABS |
| | | ABS warning lamp signal | Receives an ON/OFF state of ABS warning lamp |
| | | TCS malfunction signal | Receives a malfunction state of TCS |
| | | TCS operation signal | Receives an operational state of TCS |
| | | VDC OFF switch signal | Receives an ON/OFF state of VDC |
| | | VDC malfunction signal | Receives a malfunction state of VDC |
| | | VDC operation signal | Receives an operational state of VDC |
| | | Vehicle speed signal (ABS) | Receives wheel speeds of four wheels |
| | | Yaw rate signal | Receives yaw rate acting on the vehicle |
| | | Stop lamp switch signal | Receives an operational state of the brake pedal |
| Steering angle sensor | CAN communication | Steering angle sensor malfunction signal | Receives a malfunction state of steering angle sensor |
| | | Steering angle sensor signal | Receives the number of revolutions, turning direction of the steering wheel |
| | | Steering angle speed signal | Receives the turning angle speed of the steering wheel |
| Display control unit | CAN communication | System selection signal | Receives a selection state of each item in "Driver Aids" selected with the integral switch |
| ICC sensor | ITS communication | ICC sensor signal | Receives detection results, such as the presence or absence of a leading vehicle and distance from the vehicle |
| Accelerator pedal actuator | ITS communication | Accelerator pedal actuator operation status signal | Receives an operational state of accelerator pedal actuator |
| Lane camera unit | ITS communication | Pedestrian ahead signal | Receives detection results of pedestrian ahead of vehicle |

Output Signal Item

| Reception unit | Signal name | | Description |
|--|-----------------------------------|---|--|
| Electrically-driven intelligent brake unit | CAN communication | Brake fluid pressure control signal | Transmits a brake fluid pressure control signal to activates the brake |
| Combination meter | CAN communication | Meter display signal | Vehicle ahead detection indicator signal |
| | | | FEB/PFCW system display signal |
| | | | FEB warning signal |
| ICC sensor | ITS communication | Vehicle speed signal | Transmits a vehicle speed calculated by the ADAS control unit |
| | | Steering angle sensor signal | Transmits a steering angle sensor signal received from the steering angle sensor |
| Accelerator pedal actuator | ITS communication | Accelerator pedal position signal | Transmits an accelerator pedal angle calculated by the ADAS control unit |
| | | Accelerator pedal feedback force control signal | Transmits a target actuation force value calculated by the ADAS control unit |
| Driver assistance buzzer control module | ITS communication | Driver assistance buzzer signal | Transmits a driver assistance buzzer signal to active the buzzer |
| ICC brake hold relay | ICC brake hold relay drive signal | | Activates the brake hold relay and turns ON the stop lamp |


SYSTEM

[FORWARD EMERGENCY BRAKING]

< SYSTEM DESCRIPTION >

FUNCTION DESCRIPTION

- The FEB system measures the distance from a vehicle ahead using the ICC sensor installed in the front bumper.
- When the system judges that a vehicle is being approached, “approach warning” is displayed in the combination meter and at the same time a warning buzzer sounds, the accelerator pedal is moved upward, and the brake is operated.
- When it is further judged that the vehicle may collide with the vehicle ahead, the system operates the brake strongly to avoid collision while it displays FEB warning on the combination meter and rings a warning chime.



- ① Start of warning and partial brake ② Start of harder brake
 [A] Applies partial braking and moves the accelerator pedal to upward direction [B] Harder brake

| Situation | | Brake | Accelerator pedal actuator | Warning |
|------------------------|------------------------------------|---|---|--|
| No obstacle approached | | No operation | No operation | — |
| ① | Start of warning and partial brake | Partial brake <small>JSOIA0222ZZ</small> | Operation <small>JSOIA0094ZZ</small> | <ul style="list-style-type: none"> • Sounds the buzzer • Blinks vehicle ahead indicator |
| ② | Start of harder brake | Harder brake <small>JSOIA0222ZZ</small> | Operation <small>JSOIA0094ZZ</small> | <ul style="list-style-type: none"> • Sounds the buzzer (Higher pitched buzzer) • Indicates FEB warning |

CAUTION:

It is the driver's responsibility to stay alert, drive safely and be in control of the vehicle at all times. As there is a performance limit, it may not provide a warning or brake in certain conditions.

NOTE:

The FEB system shares component parts and diagnosis with the ICC/DCA system.

OPERATION DESCRIPTION

- The ICC sensor measures the distance from the obstacle ahead and transmits the ICC sensor signal to the ADAS control unit.

SYSTEM

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

- The lane camera measures the distance from a pedestrian and transmits the pedestrian ahead signal to the ADAS control unit.
- The ADAS control unit judges the possibility of a collision from the ICC sensor signal and the vehicle speed.
- The ADAS control unit judges the possibility of a collision from the ICC sensor signal, the pedestrian ahead signal and the vehicle speed.
- The ADAS control unit performs the following operations according to the degree of possibility of a collision.
 - Transmits the driver assistance buzzer signal to the driver assistance buzzer control module and sounds the buzzer.
 - Transmits the meter display signal to the combination meter and displays the vehicle ahead indicator/FEB warning.
 - Transmits the accelerator pedal feedback force signal to the accelerator pedal actuator and moves the accelerator pedal upward to assist the driver to release the accelerator pedal.
 - Transmits the brake fluid pressure control signal to the electrically-driven intelligent brake unit and performs the brake control.
 - Transmits the ICC brake hold relay drive signal to the ICC brake hold relay and turns ON the stop lamp.

NOTE:

- ON/OFF of FEB/PFCW system is performed with the integral switch.
- The system ON/OFF condition will be memorized even if the ignition switch turns OFF.
- The FEB system operates under the following conditions.
 - The FEB system will function when the vehicle is driven at speeds of approximately 5 km/h (3 MPH) and above, and when the vehicle's speed is approximately 5 km/h (3 MPH) faster than that of the vehicle ahead.
 - Setting of FEB is performed in synchronization with the log-in function of on-board personal assistant. For details of the log-in function, refer to [BRC-190, "System Description"](#).

Operation Condition

ADAS control unit performs the control when the following conditions are satisfied.

- When the FEB/PFCW system setting on the integral switch is ON.
- When the vehicle speed is above approximately 5 km/h (3 MPH).
- There is a possibility of a collision with the vehicle ahead.

No Operation Condition

The ADAS control unit is not operate when the system is under the conditions of the no operation condition.

- When the FEB system setting on the integral switch is OFF.
- When the vehicle ahead is not detected.
- When the vehicle speed is below approximately 5 km/h (3 MPH).

Operation Cancellation Condition

The ADAS control unit cancels the operation when the system is under any conditions of the operation cancellation condition.

- When the system judges that the vehicle comes to a standstill by the system control.
- When the system malfunction occurs.
- When the ICC sensor area of the front bumper is dirty and the measurement of the distance between the vehicles becomes difficult.

Fail-safe (ADAS Control Unit)

INFOID:000000014237591

If a malfunction occurs in each system, ADAS control unit cancels each control, sounds a beep, and turns ON the warning or indicator lamp.

| System | Buzzer | Warning lamp/Warning display | Description |
|--|-------------------|------------------------------|-------------|
| Vehicle-to-vehicle distance control mode | High-pitched tone | ICC system warning | Cancel |
| Conventional (fixed speed) cruise control mode | High-pitched tone | ICC system warning | Cancel |
| Forward Emergency Braking (FEB) | High-pitched tone | FEB warning | Cancel |
| Predictive Forward Collision Warning (PFCW) | High-pitched tone | Warning message | Cancel |

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

SYSTEM

< SYSTEM DESCRIPTION >


[FORWARD EMERGENCY BRAKING]

| System | Buzzer | Warning lamp/Warning display | Description |
|-------------------------------------|-------------------|---|-------------|
| Distance Control Assist (DCA) | High-pitched tone | DCA system warning | Cancel |
| Lane Departure Warning (LDW) | — | Lane departure warning lamp | Cancel |
| Lane Departure Prevention (LDP) | Low-pitched tone | Lane departure warning lamp | Cancel |
| Blind Spot Warning (BSW) | — | Blind Spot Warning warning lamp | Cancel |
| Blind Spot Intervention | Low-pitched tone | Blind Spot Intervention warning lamp | Cancel |
| Backup Collision Intervention (BCI) | High-pitched tone | Backup Collision Intervention warning indicator | Cancel |
| Rear Cross Traffic Alert (RCTA) | — | Rear Cross Traffic Alert warning | Cancel |

WARNING/INDICATOR/CHIME LIST

WARNING/INDICATOR/CHIME LIST : Warning Lamp/Indicator Lamp

INFOID:000000014170327

| Name | Design | Function |
|------------------|--|---|
| FEB warning lamp |  | <ul style="list-style-type: none"> For layout, refer to MWI-10, "METER SYSTEM : Arrangement of Combination Meter". |

OPERATION


< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

OPERATION

Switch Name and Function

INFOID:000000014170328




| No. | Switch name | Description |
|-----|--|---|
| ① | FEB system setting screen (Integral switch settings screen) | The setting of FEB/PFCW system can be switched between ON and OFF |

BRC

Menu Displayed by Pressing Each Switch

INFOID:000000014170329

SYSTEM DISPLAY



| No. | Switch name | Description |
|-----|-------------------------|--|
| ① | FEB warning lamp | <ul style="list-style-type: none"> FEB warning lamp indicates that an abnormal condition is present in FEB system When the FEB system turns OFF, the FEB warning lamp will illuminate. |
| ② | Vehicle ahead indicator | <ul style="list-style-type: none"> Indicates whether it detects a vehicle ahead. Blinks when there is a possibility of a collision with the vehicle ahead. |
| ③ | FEB warning | Displays immediately before the harder brake operates |

DISPLAY AND WARNING




Setting Display

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P







OPERATION

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| System status | Condition | Display on combination meter | | FEB warning lamp | Buzzer |
|---------------|-----------|------------------------------|---|---|--------|
| | | Upper part | Middle part | | |
| FEB OFF | — | — | Driving Aids  <small>JSOIA1624ZZ</small> |  | — |
| FEB ON | System ON | — | White Driving Aids  <small>JSOIA1625ZZ</small> | OFF | — |

Warning Operation









| System status | Action | Display on combination meter | | FEB warning lamp | Buzzer |
|--|---------------|---|--|---|------------------------|
| | | Upper part | Middle part | | |
| There is a possibility of a collision with the vehicle ahead | Partial brake | Yellow (Blink)  <small>ALFIA0531ZZ</small> | Driving Aids  <small>JSOIA1625ZZ</small> |  | Short continuous beeps |
| An obstacle ahead is avoided due to the system applying braking. | Harder brake | Red↔White  <small>JSOIA1477ZZ</small> | Driving Aids  <small>JSOIA1625ZZ</small> |  | Continuous beeps |

Warning Display

OPERATION

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| System status | Condition | Display on combination meter | | FEB warning lamp | Master warning lamp | Buzzer |
|------------------------|--|---|--|---|---|--------|
| | | Upper part | Middle part | | | |
| FEB system malfunction | The FEB system is automatically canceled.* | Yellow (Blink)  <small>ALFIA0532ZZ</small> | Driving Aids  <small>JSOIA1625ZZ</small> |  <small>ALFIA0508ZZ</small> | Yellow  | Beep |
| | | Yellow (Blink)  <small>ALFIA0532ZZ</small> | Driving Aids  <small>JSOIA1625ZZ</small> |  <small>ALFIA0508ZZ</small> | Yellow  | Beep |

NOTE:

*: The system operates if the ignition switch is turned OFF⇒ON after the condition improves

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

HANDLING PRECAUTION

Description

INFOID:000000014170330

PRECAUTIONS FOR FORWARD EMERGENCY BRAKING

- The forward emergency braking system is a supplemental aid to the driver. It is not a replacement for the driver's attention to traffic conditions or responsibility to drive safely. It cannot prevent accidents due to carelessness or dangerous driving techniques.
- The forward emergency braking system does not function in all driving, traffic, weather and road conditions.
- The automatic braking will cease under the following conditions:
 - When the steering wheel is turned as far as necessary to avoid a collision.
 - When the accelerator pedal is depressed.
 - When there is no longer a vehicle detected ahead.
- If the forward emergency braking system has stopped the vehicle, the vehicle will remain at a standstill for approximately 2 seconds before the brakes are released.
- The system will not detect the following objects:
 - Pedestrians, animals, or obstacles in the roadway
 - Oncoming vehicles in the same lane
 - Crossing vehicles
- The radar sensor has some performance limitations. For stationary vehicles, the forward emergency braking system can function at speeds up to approximately 70 km/h (45 MPH).
- The radar sensor may not detect a vehicle ahead in the following conditions:
 - Dirt, ice, snow or other material covering the radar sensor.
 - Interference by other radar sources.
 - Snow or road spray from traveling vehicles.
 - If the vehicle ahead is narrow (e.g. motorcycle)
 - When driving on a steep downhill slope or roads with sharp curves.
- In some road or traffic conditions, the forward emergency braking system may unexpectedly push the accelerator pedal up or apply partial braking. When acceleration is necessary, continue to depress the accelerator pedal to override the system.
- Braking distances increase on slippery surfaces.
- Excessive noise will interfere with the warning chime sound, and the chime may not be heard.

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)


On Board Diagnosis Function

INFOID:000000014224816

DESCRIPTION

The DTC is displayed on the information display by operating the ICC steering switch.

On Board Self-diagnosis System Diagram



METHOD OF STARTING

CAUTION:


Start condition of on board self-diagnosis

- ICC system OFF
- DCA system OFF
- Vehicle speed 0 km/h (0 MPH)


1. Turn the ignition switch OFF.
2. Start the engine.
3. Wait for 5 seconds after starting the engine. Push up the RESUME/ACCELERATE switch 5 times and push down the SET/COAST switch 5 times within 10 seconds.

NOTE:

If the above operation cannot be performed within 10 seconds after waiting for 5 seconds after starting the engine, repeat the procedure from step 1.



4. The DTC is displayed on the set vehicle speed indicator (1) on the ICC system display on the information display when the on board self-diagnosis starts. Refer to [DAS-40, "DTC Index"](#).



NOTE:

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

[FORWARD EMERGENCY BRAKING]

< SYSTEM DESCRIPTION >

- It displays for up to 5 minutes and then stops.
- If multiple malfunctions exist, up to 6 DTCs can be stored in memory at the most, and the most recent one is displayed first.

WHEN THE ON BOARD SELF-DIAGNOSIS DOES NOT START

If the on board self-diagnosis does not start, check the following items.

| Assumed abnormal part | | Inspection item |
|---|-------------------------------|--|
| Information display | Combination meter malfunction | Check that the self-diagnosis function of the combination meter operates. Refer to MWI-17, "Description" . |
| ICC steering switch malfunction | | Perform the inspection for DTC "C1A06". Refer to DAS-80, "DTC Logic" . |
| Harness malfunction between ICC steering switch and ECM | | |
| ECM malfunction | | |
| ADAS control unit malfunction | | <ul style="list-style-type: none"> • Check power supply and ground circuit of ADAS control unit. Refer to DAS-169, "Diagnosis Procedure". • Perform SELF-DIAGNOSIS for "ICC/ADAS" with CONSULT, and then check the malfunctioning parts. Refer to DAS-40, "DTC Index". |

HOW TO ERASE ON BOARD SELF-DIAGNOSIS

1. Turn the ignition switch OFF.
2. Start the engine, and then start the on board self-diagnosis.
3. Press the CANCEL switch 5 times, and then press the DISTANCE switch 5 times under the condition that the on board self-diagnosis starts.

NOTE:


- Complete the operation within 10 seconds after pressing the CANCEL switch first.
- If the operation is not completed within 10 seconds, repeat the procedure from step 1.

4. DTC 55 is displayed after erasing.

NOTE:

DTCs for existing malfunction can not be erased.

5. Turn ignition switch OFF, and finish the diagnosis.



CONSULT Function (ICC/ADAS)

INFOID:0000000014224817

APPLICATION ITEMS

CONSULT performs the following functions via CAN communication using ADAS control unit.

| Diagnosis mode | Description |
|--------------------------|--|
| Configuration | <ul style="list-style-type: none"> • The vehicle specification that is written in ADAS control unit can be displayed or stored • The vehicle specification can be written when ADAS control unit is replaced |
| Work support | Displays causes of automatic system cancellation occurred during system control |
| Self Diagnostic Result | Displays the name of a malfunctioning system stored in the ADAS control unit |
| Data Monitor | Displays ADAS control unit input/output data in real time |
| Active Test | Enables an operational check of a load by transmitting a driving signal from the ADAS control unit to the load |
| ECU Identification | Displays ADAS control unit part number |
| CAN Diag Support Monitor | Displays a reception/transmission state of CAN communication and ITS communication |

CONFIGURATION

Configuration includes functions as follows.

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Function | | Description |
|--------------------------|--------------------|---|
| Read/Write Configuration | Before Replace ECU | Allows the reading of vehicle specification written in ADAS control unit to store the specification in CONSULT. |
| | After Replace ECU | Allows the writing of the vehicle information stored in CONSULT into the ADAS control unit. |
| Manual Configuration | | Allows the writing of the vehicle specification into the ADAS control unit by hand. |

WORK SUPPORT

| Work support items | Description |
|------------------------|--|
| CAUSE OF AUTO-CANCEL 1 | Displays causes of automatic system cancellation occurred during control of the following systems <ul style="list-style-type: none"> • Vehicle-to-vehicle control mode • Conventional (fixed speed) control mode • Distance Control Assist (DCA) • Forward Emergency Braking (FEB) |
| CAUSE OF AUTO-CANCEL 2 | Displays causes of automatic system cancellation occurred during control of the following systems <ul style="list-style-type: none"> • Lane Departure Prevention (LDP) • Blind Spot Intervention |
| CAUSE OF AUTO-CANCEL 3 | Displays causes of automatic system cancellation occurred during control of the Back-up Collision Intervention (BCI) |

NOTE:

- Causes of the maximum five cancellations (system cancel) are displayed.
- The displayed cancellation causes display the number of the ignition switch ON/OFF up to 254. It is fixed to 254 if it is over 254. It returns to 0 when the same cancellation cause is detected again.

Display Items for The Cause of Automatic Cancellation 1

| Cause of cancellation | | | | | Description |
|-----------------------|--|--|-------------------------|---------------------------|--|
| | Vehicle-to-vehicle distance control mode | Conventional (fixed speed) cruise control mode | Distance Control Assist | Forward Emergency Braking | |
| OPERATING ABS | × | | × | × | ABS function was operated |
| OPERATING TCS | × | × | × | | TCS function was operated |
| OPERATING VDC | × | × | × | × | VDC function was operated |
| ECM CIRCUIT | × | × | | | ECM did not permit ICC operation |
| OPE SW VOLT CIRC | × | × | × | | The ICC steering switch input voltage is not within standard range |
| SNOW MODE SW | × | | × | | Shifting of the drive mode selector to SNOW position |
| OP SW DOUBLE TOUCH | × | × | | | ICC steering switches were pressed at the same time |

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| | | | | | |
|-------------------------|---|---|---|---|---|
| VHCL SPD DOWN | × | × | × | | Vehicle speed lower than the speed as follows <ul style="list-style-type: none"> • Vehicle-to-vehicle distance control mode is 24 km/h (15 MPH) • Conventional (fixed speed) cruise control mode is 32 km/h (20 MPH) |
| WHL SPD ELEC NOISE | × | × | × | | Wheel speed sensor signal caught electromagnetic noise |
| VDC/TCS OFF SW | × | | × | × | VDC OFF switch was pressed |
| VHCL SPD UNMATCH | × | × | × | | Wheel speed became different from A/T vehicle speed |
| TIRE SLIP | × | × | | | Wheel slipped |
| IGN LOW VOLT | × | × | × | × | Decrease in ADAS control unit ignition voltage |
| PARKING BRAKE ON | × | × | | | The parking brake is operating |
| WHEEL SPD UNMATCH | × | × | × | | The wheel speeds of 4 wheels are out of the specified values |
| INCHING LOST | × | | | | A vehicle ahead is not detected during the following driving when the vehicle speed is approximately 24 km/h (15 MPH) or less |
| CAN COMM ERROR | × | × | × | × | ADAS control unit received an abnormal signal with CAN communication |
| ABS/TCS/VDC CIRC | × | × | × | × | An abnormal condition occurs in VDC/TCS/ABS system |
| ECD CIRCUIT | × | × | × | × | An abnormal condition occurs in ECD system |
| ENG SPEED DOWN | × | × | | | Engine speed became extremely low while controlling ICC system |
| ASCD VHCL SPD DTAC | | × | | | Vehicle speed is detached from set vehicle speed |
| ASCD DOUBLE COMD | | × | | | Cancel switch and operation switch are detected simultaneously |
| APA HI TEMP | | | × | | The accelerator pedal actuator integrated motor temperature is high |
| ICC SENSOR CAN COMM ERR | × | | × | × | Communication error between ADAS control unit and the ICC sensor |
| ABS WARNING LAMP | × | | × | | ABS warning lamp ON |
| FR RADAR BLOCKED | × | | × | × | Inclusion of dirt or stains on the ICC sensor area of the front bumper |
| FEB) CURVATURE | | | | × | Road curve was more than the specified value |
| FEB) YAW RATE | | | | × | Detected yawing speed was more than the specified value |
| FEB) LTRL ACCELERATION | | | | × | Detected lateral speed is the specified value or more |
| RADAR INTERFERENCE | × | | × | × | ICC sensor receives electromagnetic interference |
| NO RECORD | × | × | × | | — |

Display Items for The Cause of Automatic Cancellation 3

| Cause of cancellation | Back-up Collision Intervention | Description |
|-----------------------|--------------------------------|--|
| CAN COMM ERROR (CAN) | × | ADAS control unit received an abnormal signal with CAN communication |
| CAN COMM ERROR (ECD) | × | ADAS control unit received an abnormal signal with CAN communication |
| IGN LOW VOLT | × | Decrease in ADAS control unit ignition voltage |
| VEHICLE SPEED UP | × | Vehicle speed higher than 8 km/h (5 MPH) |
| ACCEL IS OPERATED | × | Accelerator pedal was depressed |

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Cause of cancellation | Back-up Collision Intervention | Description |
|-----------------------|--------------------------------|---|
| BRAKE IS OPERATED | × | Brake pedal was operated |
| APA HI TEMP | × | The accelerator pedal actuator integrated motor temperature is high |
| APA POWER | × | Decrease in accelerator pedal actuator ignition or battery voltage |
| NO RECORD | × | — |

SELF DIAGNOSTIC RESULT

Refer to [DAS-40, "DTC Index"](#).

NOTE:

- The details of time display are as per the following.
- CRNT: A malfunction is detected now
- PAST: A malfunction was detected in the past
- IGN counter is displayed on FFD (Freeze Frame Data).
- 0: The malfunctions that are detected now
 - CAN communication system (U1000, U1010)
 - 1 - 39: It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
 - If it is over 39, it is fixed to 39 until the self-diagnosis results are erased.
 - Other than CAN communication system (Other than U1000, U1010)
 - 1 - 49: It increases like 0 → 1 → 2 ... 38 → 49 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
 - If it is over 49, it is fixed to 49 until the self-diagnosis results are erased.

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitored item [Unit] | ALL SIG (ICC) | MAIN SIG (ICC) | MAIN SIG (LDW/LDP) | MAIN SIG (BSW/BSI) | MAIN SIG (BCI) | Description |
|---------------------------|------------------|-------------------|-----------------------|-----------------------|-------------------|--|
| MAIN SW [On/Off] | × | × | × | × | | Indicates [On/Off] status as judged from ICC steering switch |
| SET/COAST SW [On/Off] | × | × | | | | Indicates [On/Off] status as judged from ICC steering switch |
| CANCEL SW [On/Off] | × | × | | | | Indicates [On/Off] status as judged from ICC steering switch |
| RESUME/ACC SW [On/Off] | × | × | | | | Indicates [On/Off] status as judged from ICC steering switch |
| DISTANCE SW [On/Off] | × | | | | | Indicates [On/Off] status as judged from ICC steering switch |
| CRUISE OPE [On/Off] | × | × | | | | Indicates whether controlling or not (ON means "controlling") |
| BRAKE SW [On/Off] | × | × | × | × | × | Indicates [On/Off] status as judged from ICC brake switch signal (ECM transmits ICC brake switch signal through CAN communication) |
| STOP LAMP SW [On/Off] | × | × | × | × | × | Indicates [On/Off] status as judged from stop lamp switch signal (ECM transmits stop lamp switch signal through CAN communication) |

A
B
C
D
E

BRC

G
H
I
J

K

L

M

N

O

P

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Monitored item [Unit] | ALL SIG (ICC) | MAIN SIG (ICC) | MAIN SIG (LDW/LDP) | MAIN SIG (BSW/BSI) | MAIN SIG (BCI) | Description |
|----------------------------------|------------------|-------------------|-----------------------|-----------------------|-------------------|--|
| IDLE SW [On/Off] | × | | | | × | Indicates [On/Off] status of idle switch read from ADAS control unit through CAN communication (ECM transmits On/Off status through CAN communication) |
| SET DISTANCE [Short/Mid/Long] | × | × | | | | Indicates set distance memorized in ADAS control unit |
| CRUISE LAMP [On/Off] | × | × | | | | Indicates [On/Off] status of MAIN switch indicator output |
| OWN VHCL [On/Off] | × | | | | | Indicates [On/Off] status of own vehicle indicator output |
| VHCL AHEAD [On/Off] | × | | | | | Indicates [On/Off] status of vehicle ahead detection indicator output |
| ICC WARNING [On/Off] | × | | | | | Indicates [On/Off] status of ICC system warning lamp output |
| VHCL SPEED SE [km/h] or [mph] | × | × | × | × | × | Indicates vehicle speed calculated from ADAS control unit through CAN communication [ABS actuator and electric unit (control unit) transmits vehicle speed signal (wheel speed) through CAN communication] |
| SET VHCL SPD [km/h] or [mph] | × | × | | | | Indicates set vehicle speed memorized in ADAS control unit |
| BUZZER O/P [On/Off] | × | | | | × | Indicates [On/Off] status of ICC warning chime output |
| THRTL SENSOR [deg] | × | × | | | | NOTE: The item is displayed, but it is not monitored |
| ENGINE RPM [rpm] | × | | | | | Indicates engine speed read from ADAS control unit through CAN communication (ECM transmits engine speed signal through CAN communication) |
| WIPER SW [OFF/LOW/HIGH] | × | | | | | Indicates wiper [OFF/LOW/HIGH] status (BCM transmits front wiper request signal through CAN communication) |
| YAW RATE [deg/s] | × | | | | | NOTE: The item is displayed, but it is not monitored |
| BA WARNING [On/Off] | × | | | | | Indicates [On/Off] status of FEB indicator lamp output |
| STP LMP DRIVE [On/Off] | × | × | | | × | Indicates [On/Off] status of ICC brake hold relay drive output |
| D RANGE SW [On/Off] | × | | | | | Indicates [On/Off] status of "D" or "M" positions read from ADAS control unit through CAN communication; ON when position "D" or "M" (TCM transmits shift position signal through CAN communication). |
| NP RANGE SW [On/Off] | × | | | | | Indicates shift position signal read from ADAS control unit through CAN communication (TCM transmits shift position signal through CAN communication) |
| PKB SW [On/Off] | × | | | | | Parking brake switch status [On/Off] judged from the parking brake switch signal that ADAS control unit readout via CAN communication is displayed (combination meter transmits the parking brake switch signal via CAN communication) |
| PWR SUP MONI [V] | × | × | | | | Indicates IGN voltage input by ADAS control unit |
| VHCL SPD AT [km/h] or [mph] | × | | | | | Indicates vehicle speed calculated from A/T vehicle speed sensor read from ADAS control unit through CAN communication (TCM transmits A/T vehicle speed sensor signal through CAN communication) |
| THRTL OPENING [%] | × | × | | | × | Indicates throttle position read from ADAS control unit through CAN communication (ECM transmits accelerator pedal position signal through CAN communication). |

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Monitored item [Unit] | ALL SIG (ICC) | MAIN SIG (ICC) | MAIN SIG (LDW/LDP) | MAIN SIG (BSW/BSI) | MAIN SIG (BCI) | Description |
|--------------------------------------|------------------|-------------------|-----------------------|-----------------------|-------------------|--|
| GEAR [1, 2, 3, 4, 5, 6, 7] | × | | | | | Indicates A/T gear position read from ADAS control unit through CAN communication (TCM transmits current gear position signal through CAN communication) |
| MODE SIG [OFF, ICC, ASCD] | × | | | | | Indicates the active mode from ICC or ASCD [conventional (fixed speed) cruise control mode] |
| SET DISP IND [On/Off] | × | | | | | Indicates [On/Off] status of SET switch indicator output |
| DISTANCE [m] | × | | | | | Indicates the distance from the vehicle ahead |
| RELATIVE SPD [m/s] | × | | | | | Indicates the relative speed of the vehicle ahead |
| DYNA ASSIST SW [On/Off] | × | × | | × | | Indicates [On/Off] status as judged from ICC steering switch signal (ECM transmits ICC steering switch signal through CAN communication) |
| DCA ON IND [On/Off] | × | | | | | The status [ON/OFF] of DCA system switch indicator output is displayed |
| DCA VHL AHED [On/Off] | × | | | | | The status [ON/OFF] of vehicle ahead detection indicator output in DCA system is displayed |
| APA TEMP [°C] | × | | | | × | Accelerator pedal actuator integrated motor temperature that the ADAS control unit readout via ITS communication is displayed (Accelerator pedal actuator transmits the integrated motor temperature via ITS communication) |
| APA PWR [V] | × | | | | × | Accelerator pedal actuator power supply voltage that the ADAS control unit readout via ITS communication is displayed (Accelerator pedal actuator transmits the power supply voltage via ITS communication) |
| NAVI ICC DISP [On/Off] | | | | | | NOTE: The item is displayed, but it is not monitored |
| LDW SYSTEM ON [On/Off] | | | × | | | Indicates [On/Off] status of LDW system |
| LDW ON LAMP [On/Off] | | | × | | | Indicates [On/Off] status of LDW system display output |
| LDP ON IND [On/Off] | | | × | | | Indicates [On/Off] status of LDP system display output |
| LANE DPRT W/L [On/Off] | | | × | | | Indicates [On/Off] status of LDW/LDP warning display (Yellow) output |
| LDW BUZER OUT- PUT [On/Off] | | | × | | | Indicates [On/Off] status of warning buzzer output |
| LDP SYSTEM ON [On/Off] | | | × | | | Indicates [On/Off] status of LDP system |
| WARN REQ [On/Off] | | | × | | | Indicates an ADAS control unit judged warning state (ON/OFF) of LDP system |
| READY signal [On/Off] | | | × | | | Indicates LDP system settings |
| Camera lost [Detect/Deviate/Both] | | | × | × | | Indicates a lane marker detection state judged from a lane marker detection signal read by the ADAS control unit via Chassis communication (Lane camera unit transmits a lane marker signal via Chassis communication) |
| Lane unclear [On/Off] | | | × | × | | Indicates an ON/OFF state of the lane marker. The ON/OFF state is judged from a detected lane condition signal read by the ADAS control unit via Chassis communication (The lane camera unit transmits a detected lane condition signal via Chassis communication) |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Monitored item [Unit] | ALL SIG (ICC) | MAIN SIG (ICC) | MAIN SIG (LDW/LDP) | MAIN SIG (BSW/BSI) | MAIN SIG (BCI) | Description |
|--|------------------|-------------------|-----------------------|-----------------------|-------------------|--|
| STATUS signal [Stnby/Warn/Cancl/ Off] | | | × | | | Indicates a control state of LDP system |
| Shift position [Off, P, R, N, D, M/T1 - 7] | | | × | × | × | Indicates shift position read from ADAS control unit through CAN communication (TCM transmits shift position signal through CAN communication) |
| Turn signal [OFF/LH/RH/LH&RH] | | | × | × | | Indicates turn signal operation status read from ADAS control unit through CAN communication (BCM transmits turn indicator signal through CAN communication) |
| SIDE G [G] | | | × | × | | Indicates lateral G acting on the vehicle. This lateral G is judged from a side G sensor signal read by ADAS control unit via CAN communication (The ABS actuator and electric unit (control unit) transmits a side G sensor signal via CAN communication) |
| FUNC ITEM (FCW) [On/Off] | × | × | × | × | | Indicates systems which can be set to ON/OFF by selecting "Driver Aids" ⇒ "Emergency Assist" of the integral switch Forward Emergency Braking |
| FUNC ITEM (LDW) [On/Off] | × | × | × | × | | Indicates systems which can be set to ON/OFF by selecting "Driver Aids" ⇒ "Lane" of the integral switch Lane Departure Warning |
| FUNC ITEM (BSW) [On/Off] | × | × | × | × | | Indicates systems which can be set to ON/OFF by selecting "Driver Aids" ⇒ "Blind spot" of the integral switch Blind Spot Warning |
| DCA SELECT [On/Off] | × | × | × | × | | Indicates an ON/OFF state of the DCA system. The DCA system can be set to ON/OFF by selecting "Driving Aids" ⇒ "Front assist" of the integral switch |
| LDP SELECT [On/Off] | × | × | × | × | | Indicates an ON/OFF state of LDP system. LDP system can be set to ON/OFF by selecting "Driving Aids" ⇒ "Lane" of the integral switch |
| BSI SELECT [On/Off] | × | × | × | × | | Indicates an ON/OFF state of Blind Spot Intervention system. Blind Spot Intervention system can be set to ON/OFF by selecting "Driving Aids" ⇒ "Blind Spot" of the integral switch |
| FCW SELECT [On/Off] | × | × | × | × | | Indicates an ON/OFF state of the PFCW system. The PFCW system can be set to ON/OFF by selecting "Driving Aids" ⇒ "Emergency Assist" of the integral switch |
| LDW SELECT [On/Off] | × | × | × | × | | Indicates an ON/OFF state of the LDW system. The LDW system can be set to ON/OFF by selecting "Driving Aids" ⇒ "Lane" of the integral switch |
| BSW SELECT [On/Off] | × | × | × | × | | Indicates an ON/OFF state of the BSW system. The BSW system can be set to ON/OFF by selecting "Driving Aids" ⇒ "Blind spot" of the integral switch |
| DRIVE MODE STATS [STD/SPT/ECO/SNO] | × | × | × | × | | Indicates a drive mode selector select position judged from a drive mode select switch position signal read by the ADAS control unit via CAN communication |
| WARN SYS SW [On/Off] | × | × | × | × | | Indicates [On/Off] status of warning systems switch |
| BSW/BSI WARN LMP [On/Off] | | | | × | | Indicates [On/Off] status of Blind Spot warning malfunction |
| BSI ON IND [On/Off] | | | | × | | Indicates [On/Off] status of Blind Spot Intervention system display |
| BSW SYSTEM ON [On/Off] | | | | × | | Indicates [On/Off] status of BSW system |
| BSI SYSTEM ON [On/Off] | | | | × | | Indicates [On/Off] status of Blind Spot Intervention system |
| FCW SYSTEM ON [On/Off] | × | × | | | | Indicates [On/Off] status of PFCW system |

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Monitored item [Unit] | ALL SIG (ICC) | MAIN SIG (ICC) | MAIN SIG (LDW/LDP) | MAIN SIG (BSW/BSI) | MAIN SIG (BCI) | Description |
|--|------------------|-------------------|-----------------------|-----------------------|-------------------|--|
| BCI SYSTEM ON [On/Off] | | | | | × | Indicates [On/Off] status of BCI system |
| BCI SWITCH [On/Off] | | | | | × | Indicates [On/Off] status of Backup Collision Intervention system switch |
| BATTERY CIRCUIT OFF [On/Off] | × | | | | | NOTE: The item is displayed, but it is not used |
| LDP WARNING INDI- CATOR [On/Off] | | | × | | | Indicates [On/Off] status of LDP warning display (Yellow) output |
| LDW ON INDICATOR [On/Off] | | | × | | | Indicates [On/Off] status of LDW system ON display output |
| LDW WARNING INDI- CATOR [On/Off] | | | × | | | Indicates [On/Off] status of LDW system warning display output |
| SYSTEM CANCEL MESSAGE [NOREQ/SLIP/ SNOW/VDC OFF] | × | × | × | × | | Indicates status of system cancel display output |
| CAMERA HI TEMP MSG [On/Off] | | | × | × | | Indicates [On/Off] status of lane camera unit high temperature warning display output |
| ITS SETTING ITEM(DCA) [On/Off] | × | × | × | × | | Indicates the presence or absence of DCA system. |
| ITS SETTING ITEM(LDP) [On/Off] | × | × | × | × | | Indicates the presence or absence of LDP system. |
| ITS SETTING ITEM(BSI) [On/Off] | × | × | × | × | | Indicates the presence or absence of Blind Spot Intervention system. |
| BSI WARNING INDI- CATOR [On/Off] | | | | × | | Indicates [On/Off] status of Blind Spot Intervention warning display output |
| BSW ON INDICATOR [On/Off] | | | | × | | Indicates [On/Off] status of BSW system ON display output |
| SIDE RADAR BLOCK COND [On/Off] | | | | × | | Indicates [On/Off] status of side radar with dirt or foreign materials |
| LDW WARNING ALERT TIMING [Nothing/Early/Late] | | | × | | | NOTE: The item is displayed, but it is not monitored |
| BSW IND BRIGHT- NESS [Nothing/Bright/Nor- mal/Dark] | | | | × | | Indicates status of brightness of Blind Spot Warning/Blind Spot Intervention indicator |

ACTIVE TEST

CAUTION:

- Never perform “Active Test” while driving the vehicle.
- The “Active Test” cannot be performed when the following systems malfunction is displayed.
- ICC system
- DCA
- LDW

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

- LDP
- Blind Spot Warning
- Blind Spot Intervention
- BCI
- The “Active Test” cannot be performed when the FEB warning lamp is illuminated.
- Shift the selector lever to “P” position, and then perform the test.

| Test item | Description |
|-----------------------|--|
| METER LAMP | The MAIN switch indicator and FEB warning lamp can be illuminated by ON/OFF operations as necessary |
| STOP LAMP | The ICC brake hold relay can be operated by ON/OFF operations as necessary, and the stop lamp can be illuminated |
| ICC BUZZER | Sounds a buzzer used for following systems by arbitrarily operating ON/OFF <ul style="list-style-type: none"> • Intelligent Cruise Control (ICC) • Distance Control Assist (DCA) • Predictive Forward Collision Warning (PFCW) • Forward Emergency Brake (FEB) |
| BRAKE ACTUATOR | Activates the brake by an arbitrary operation |
| ACTIVE PEDAL | The accelerator pedal actuator can be operated as necessary |
| DCA INDICATOR | The DCA system display can be illuminated by ON/OFF operations as necessary |
| LDP BUZZER | Sounds a buzzer used for following systems by arbitrarily operating ON/OFF <ul style="list-style-type: none"> • Lane Departure Warning (LDW) • Lane Departure Prevention (LDP) • Blind Spot Warning (BSW) • Blind Spot Intervention |
| WARNING SYSTEM IND | Warning systems ON indicator (on warning systems switch) can be illuminated by ON/OFF operations as necessary |
| LDP ON IND | The LDP system display can be illuminated by ON/OFF operations as necessary |
| LANE DEPARTURE W/L | The LDW/LDP warning can be illuminated by ON/OFF operations as necessary |
| BSW/BSI WARNING LAMP | The Blind Spot Warning/Blind Spot Intervention warning lamp can be illuminated by ON/OFF operations as necessary |
| BSW ON INDICATOR | The Blind Spot Warning system display can be illuminated by ON/OFF operations as necessary |
| BSI ON INDICATOR | The Blind Spot Intervention system display can be illuminated by ON/OFF operations as necessary |
| LDW ON INDICATOR | The LDW system display can be illuminated by ON/OFF operations as necessary |
| LDP WARNING INDICATOR | The LDP malfunction can be illuminated by ON/OFF operations as necessary |
| LDW WARNING INDICATOR | The LDW malfunction can be illuminated by ON/OFF operations as necessary |
| BSW WARNING INDICATOR | The BSW malfunction can be illuminated by ON/OFF operations as necessary |
| BSI WARNING INDICATOR | The Blind Spot Intervention malfunction can be illuminated by ON/OFF operations as necessary |

METER LAMP

NOTE:

The test can be performed only when the engine is running.

| Test item | Operation | Description | Signal |
|------------|-----------|--|--------|
| METER LAMP | Off | Stops sending the following signals to exit from the test <ul style="list-style-type: none"> • Meter display signal • FEB warning lamp signal | OFF |
| | On | Transmits the following signals to the combination meter via CAN communication <ul style="list-style-type: none"> • Meter display signal • FEB warning lamp signal | ON |

STOP LAMP

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Test item | Operation | Description | Stop lamp |
|-----------|-----------|--|-----------|
| STOP LAMP | Off | Stops transmitting the ICC brake hold relay drive signal below to end the test | OFF |
| | On | Transmits the ICC brake hold relay drive signal | ON |

ICC BUZZER

| Test item | Operation | Description | Operation sound |
|------------|------------|--|-------------------------|
| ICC BUZZER | MODE1 | Transmits the buzzer output signals to the driver assistance buzzer control module via ITS communication | Intermittent beep sound |
| | Test start | Starts the tests of "MODE1" | — |
| | Reset | Stops transmitting the buzzer output signal below to end the test | — |
| | End | Returns to the "SELECT TEST ITEM" screen | — |

BRAKE ACTUATOR


NOTE:

The test can be performed only when the engine is running.

| Test item | Operation | Description | "PRESS SENS" value |
|----------------|------------|--|--------------------|
| BRAKE ACTUATOR | MODE1 | Transmits the brake fluid pressure control signal to the ABS actuator and electric unit (control unit) via CAN communication | 10 bar |
| | MODE2 | | 20 bar |
| | MODE3 | | 30 bar |
| | Test start | Starts the tests of "MODE1", "MODE2" and "MODE3" | — |
| | Reset | Stops transmitting the brake fluid pressure control signal below to end the test | — |
| | End | Returns to the "SELECT TEST ITEM" screen | — |

NOTE:

The test is finished in 10 seconds after starting



Active Pedal

CAUTION:

- Shift the selector lever to "P" position, and then perform the test.
- Never depress the accelerator pedal excessively. (The engine speed may rise unexpectedly when finishing the test.)

NOTE:

- Depress the accelerator pedal to check when performing the test.
- The test can be performed only when the engine is running.

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)


< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Test item | Operation | Description | Accelerator pedal operation |
|--------------|------------|---|---|
| ACTIVE PEDAL | MODE1 | Transmit the accelerator pedal feedback force control signal to the accelerator pedal actuator via ITS communication. | Constant with a force of 25 N for 8 seconds |
| | MODE2 | | Constant with a force of 15 N for 8 seconds |
| | MODE3 | | Change up to a force of 25 N for 8 seconds |
| | MODE4 | | Change up to a force of 15 N for 8 seconds |
| | Test start | Starts the tests of "MODE1", "MODE2", "MODE3" and "MODE4" | — |
| | Reset | Stops transmitting the accelerator pedal feedback force control signal below to end the test. | — |
| | End | Returns to the "SELECT TEST ITEM" screen | — |

NOTE:

The test is finished in 10 seconds after starting



DCA INDICATOR

NOTE:

The test can be performed only when the engine is running.

| Test item | Operation | Description | DCA system display |
|---------------|-----------|---|--------------------|
| DCA INDICATOR | Off | Stops transmitting the meter display signal below to end the test | — |
| | On | Transmits the meter display signal to the combination meter via CAN communication | ON |

LDP BUZZER

| Test item | Operation | Description | Warning buzzer |
|------------|-----------|--|----------------|
| LDP BUZZER | Off | Stops transmitting the warning buzzer signal below to end the test | — |
| | On | Transmits the warning buzzer signal to the warning buzzer | ON |

WARNING SYSTEM IND

| Test item | Operation | Description | Warning systems ON indicator |
|--------------------|-----------|---|------------------------------|
| WARNING SYSTEM IND | Off | Stops transmitting the warning systems ON indicator signal below to end the test | — |
| | On | Transmits the warning systems ON indicator signal to the warning systems ON indicator | ON |

LDP ON IND

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Test item | Operation | Description | LDP system display (Green) |
|------------|-----------|---|----------------------------|
| LDP ON IND | Off | Stops transmitting the meter display signal below to end the test | — |
| | On | Transmits the meter display signal to the combination meter via CAN communication | ON |

A

B

LANE DEPARTURE W/L

C

| Test item | Operation | Description | Lane departure system display (Yellow) |
|--------------------|-----------|---|--|
| LANE DEPARTURE W/L | Off | Stops transmitting the meter display signal below to end the test | — |
| | On | Transmits the meter display signal to the combination meter via CAN communication | ON |

D

E

BSW/BSI WARNING LAMP

| Test item | Operation | Description | Blind Spot Warning/Blind Spot Intervention warning lamp (Yellow) |
|----------------------|-----------|---|--|
| BSW/BSI WARNING LAMP | Off | Stops transmitting the Blind Spot Warning/Blind Spot Intervention warning lamp signal below to end the test | — |
| | On | Transmits the Blind Spot Warning/Blind Spot Intervention warning lamp signal to the combination meter via CAN communication | ON |

BRC

G

H

BSW ON INDICATOR

| Test item | Operation | Description | Blind Spot Warning system display (Yellow) |
|------------------|-----------|---|--|
| BSW ON INDICATOR | Off | Stops transmitting the meter display signal below to end the test | — |
| | On | Transmits the meter display signal to the combination meter via CAN communication | ON |

I

J

K

BSI ON INDICATOR

| Test item | Operation | Description | Blind Spot Intervention system display (Green) |
|------------------|-----------|---|--|
| BSI ON INDICATOR | Off | Stops transmitting the meter display signal below to end the test | — |
| | On | Transmits the meter display signal to the combination meter via CAN communication | ON |

L

M

LDW ON INDICATOR

| Test item | Operation | Description | LDW system display (White) |
|------------------|-----------|---|----------------------------|
| LDW ON INDICATOR | Off | Stops transmitting the meter display signal below to end the test | — |
| | On | Transmits the meter display signal to the combination meter via CAN communication | ON |

N

O

P

LDP WARNING INDICATOR

DIAGNOSIS SYSTEM (ADAS CONTROL UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Test item | Operation | Description | LDP malfunction (Yellow) |
|-----------------------|-----------|---|--------------------------|
| LDP WARNING INDICATOR | Off | Stops transmitting the meter display signal below to end the test | — |
| | On | Transmits the meter display signal to the combination meter via CAN communication | ON |

LDW WARNING INDICATOR

| Test item | Operation | Description | LDW malfunction (Yellow) |
|-----------------------|-----------|---|--------------------------|
| LDW WARNING INDICATOR | Off | Stops transmitting the meter display signal below to end the test | — |
| | On | Transmits the meter display signal to the combination meter via CAN communication | ON |

BSW WARNING INDICATOR

| Test item | Operation | Description | BSW malfunction (Yellow) |
|-----------------------|-----------|---|--------------------------|
| BSW WARNING INDICATOR | Off | Stops transmitting the meter display signal below to end the test | — |
| | On | Transmits the meter display signal to the combination meter via CAN communication | ON |

BSI WARNING INDICATOR

| Test item | Operation | Description | Blind Spot Intervention malfunction (Yellow) |
|-----------------------|-----------|---|--|
| BSI WARNING INDICATOR | Off | Stops transmitting the meter display signal below to end the test | — |
| | On | Transmits the meter display signal to the combination meter via CAN communication | ON |

ECU IDENTIFICATION

Displays ADAS control unit parts number.

DIAGNOSIS SYSTEM (ICC SENSOR)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

DIAGNOSIS SYSTEM (ICC SENSOR)

CONSULT Function (LASER/RADAR)

INFOID:000000014203343

CAUTION:

After disconnecting the CONSULT vehicle interface (VI) from the data link connector, the ignition must be cycled OFF → ON (for at least 5 seconds) → OFF. If this step is not performed, the BCM may not go to "sleep mode", potentially causing a discharged battery and a no-start condition.

APPLICATION ITEMS

CONSULT performs the following functions via CAN communication with ADAS control unit and the communication with ICC sensor.

| Diagnosis mode | Description |
|--------------------------|--|
| Self Diagnostic Result | Displays malfunctioning system memorized in ICC sensor |
| Data Monitor | Displays real-time input/output data of ICC sensor |
| Work support | It can monitor the adjustment direction indication in order to perform the radar adjustment operation smoothly |
| ECU identification | Displays ICC sensor part number |
| CAN Diag Support Monitor | The results of transmit/receive diagnosis of ITS communication can be read |

SELF DIAGNOSTIC RESULT

Refer to [CCS-60. "DTC Index"](#).

DATA MONITOR

| Monitored item [Unit] | Description |
|-------------------------------|---|
| VHCL SPEED SE [km/h] or [mph] | Vehicle speed judged from a vehicle speed signal read by the ICC sensor via ITS communication is displayed [ADAS control unit receives a vehicle speed signal from ABS actuator and electric unit (control unit) via CAN communication and transmits the calculated vehicle speed to ICC sensor via ITS communication] |
| YAW RATE [deg/s] | Indicates yaw rate read from ADAS control unit through ITS communication (ADAS control unit receives yaw rate signal from ABS actuator and electric unit (control unit) via CAN communication and transmits yaw rate calculated by the ADAS control unit) Yaw rate judged from a yaw rate signal read by ICC sensor via ITS communication is displayed [ADAS control unit receives a yaw rate signal from ABS actuator and electric unit (control unit) via CAN communication and transmits the calculated yaw rate to ICC sensor via ITS communication] |
| PWR SUP MONI [V] | Indicates IGN voltage input by ICC sensor |
| DISTANCE [m] | Indicates the distance from the vehicle ahead |
| RELATIVE SPD [m/s] | Indicates the relative speed of the vehicle ahead |
| RADAR OFFSET [m] | NOTE: The item is indicated, but not used |
| RADAR HEIGHT [m] | NOTE: The item is indicated, but not used |
| STEERING ANGLE [deg] | The steering angle is displayed |
| STRG ANGLE SPEED [deg/s] | The steering angle speed is displayed |
| L/R ADJUST [deg] | Indicates a horizontal correction value of the radar |
| U/D ADJUST [deg] | Indicates a vertical correction value of the radar |

DIAGNOSIS SYSTEM (ICC SENSOR)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

WORK SUPPORT

| Work support items | Description |
|------------------------|---|
| MILLIWAVE RADAR ADJUST | Outputs millimeter waves, calculates the displacement in radar direction, and indicates an adjustment direction |

ICC sensor Adjust

ECU IDENTIFICATION

ICC sensor part number is displayed.

DIAGNOSIS SYSTEM (LANE CAMERA UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

DIAGNOSIS SYSTEM (LANE CAMERA UNIT)

CONSULT Function (LANE CAMERA)

INFOID:000000014224818

APPLICATION ITEMS

CONSULT performs the following functions by communicating with the lane camera unit.

| Diagnosis mode | Description |
|--------------------------|---|
| Work Support | Performs the camera aiming. |
| Self Diagnostic Result | Displays the name of a malfunctioning system stored in the lane camera unit |
| Data Monitor | Displays lane camera unit input/output data in real time |
| Ecu Identification | Displays lane camera unit part number |
| CAN Diag Support Monitor | Displays a reception/transmission state of chassis communication |

WORK SUPPORT

| Work support items | Description |
|--------------------|---|
| AUTO AIM | Outputs camera unit, calculates dislocation of the camera, and displays adjustment direction. |
| AIM CHECK | NOTE: The item is displayed, but it is not used. |

SELF DIAGNOSTIC RESULT

Refer to [DAS-283, "DTC Index"](#).

FREEZE FRAME DATA (FFD)

Lane camera unit records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

| CONSULT screen item (Indication/Unit) | Description |
|--|---|
| ODO/TRIP METER (km/h) | Vehicle speed of the moment a particular DTC is detected. |

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitored item (Unit) | Description |
|--|---|
| CAMERA HIGH TEMP (NORMAL/HIGH) | Displays status of lane camera unit high temperature judgment. |
| WIPER (Off/Lo/Hi) | Displays the wiper operating status. |
| TURN SIGNAL (Off/LH/ RH/LH&RH) | Displays status of "Turn signal" received from BCM via CAN communication. |
| VEHICLE SPEED (km/h) | Displays vehicle speed received from ABS actuator and electric unit (control unit) via CAN communication. |
| DRIVER ASSIST SYSTEM SET (NO REQ) | NOTE: The item is indicated, but not monitored. |
| BRAKE OPERATION STATUS (Off/On/CNFRM/UNKWN) | Displays the brake operating status. |
| AIMING DONE (not finished/finished) | Displays status that camera aiming is done. |
| AIMING RESULT (NOK/OK) | Displays result of camera aiming. |

DIAGNOSIS SYSTEM (LANE CAMERA UNIT)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Monitored item (Unit) | Description |
|---|---|
| STEERING ANGLE (deg) | Displays the steering angle sent from the steering angle sensor. |
| YAW RATE (deg/s) | Displays the yaw rate. |
| FCTRY AIM YAW (deg) | Displays the yaw angle result of camera aiming. |
| FCTRY AIM ROL (deg) | Displays the roll angle result of camera aiming. |
| FCTRY AIM PIT (deg) | Displays the pitch angle result of camera aiming. |
| LDW FUNCTION (NORMAL/MALF) | Displays LDW function status. |
| LDW SETTING DISPLAY (NTHNG) | NOTE: The item is indicated, but not monitored. |
| DRIVER ASSIST SYSTEM BZZR (NO REQ) | NOTE: The item is indicated, but not monitored. |
| LDW LEFT (Off/On) | Displays the deviating status on the LH side lane. |
| LDW RIGHT (Off/On) | Displays the deviating status on the RH side lane. |
| LDW STATUS DISPLAY (Off/ON/TMP MF/ MF) | NOTE: The item is indicated, but not monitored. |
| HBA FUNCTION | NOTE: The item is indicated, but not monitored. |
| DISTANCE (m) | Displays the distance between the vehicle and an object detected by the lane camera unit. |
| RELATIVE SPEED (m/s) | Displays the relative velocity to an object detected by the lane camera unit. |
| HBA REQUEST (NO REQ) | NOTE: The item is indicated, but not monitored. |
| LOW BEAM STATUS (Off) | NOTE: The item is indicated, but not monitored. |
| HIGH BEAM STATUS (Off) | NOTE: The item is indicated, but not monitored. |
| NO-ENTRY SIGN DISPLAY | NOTE: The item is indicated, but not monitored. |

DIAGNOSIS SYSTEM (ACCELERATOR PEDAL ACTUATOR)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

DIAGNOSIS SYSTEM (ACCELERATOR PEDAL ACTUATOR)

CONSULT Function (ACCELERATOR PEDAL ACT)

INFOID:000000014224819

DESCRIPTION

CONSULT performs the following functions via CAN communication with ADAS control unit and the communication with accelerator pedal actuator.

| Test mode | Function |
|--------------------------|--|
| Self Diagnostic Result | <ul style="list-style-type: none">• Displays malfunctioning system memorized in accelerator pedal actuator• Displays the Freeze Frame Data when the malfunction is detected |
| DATA MONITOR | Displays real-time input/output data of accelerator pedal actuator |
| ACTIVE TEST | Enables operation check of electrical loads by sending driving signal to them |
| ECU Identification | Displays accelerator pedal actuator parts number |
| CAN Diag Support Monitor | The results of transmit/receive diagnosis of ITS communication can be read |

SELF DIAGNOSTIC RESULT

Self Diagnostic Result

Refer to [DAS-271, "DTC Index"](#).

FFD (Freeze Frame Data)

The accelerator pedal actuator records the following data when the malfunction is detected.

| Freeze Frame Data item [Unit] | Description |
|------------------------------------|--|
| TGT FBK FRC [N] | It displays the target accelerator pedal actuation force that the accelerator pedal actuator read out from the accelerator pedal feedback force control signal received via ITS communication at the time when the malfunction is detected |
| TGT MOT POSI [%] | It displays the target motor position that the accelerator pedal actuator read out from the accelerator pedal feedback force control signal received via ITS communication at the time when the malfunction is detected |
| ACT MOT POSI [%] | It displays the integrated motor position that the accelerator pedal actuator read out at the time when the malfunction is detected |
| AP OPEN [%] | It displays the accelerator pedal position signal that the accelerator pedal actuator read out via ITS communication at the time when the malfunction is detected |
| APA TEMP [°C] | It displays the integrated motor temperature that the accelerator pedal actuator read out at the time when the malfunction is detected |
| APA CURRENT [A] | It displays the integrated motor consumption current that the accelerator pedal actuator read out at the time when the malfunction is detected |
| APA PWR [V] | It displays the power supply voltage that the accelerator pedal actuator read out at the time when the malfunction is detected |
| APA OPE STATS [On/Off] | It displays the activation permission status of accelerator pedal actuator at the time when the malfunction is detected |
| APA STATS [READY/NG/TP NG/INIT] | It displays the condition of accelerator pedal actuator at the time when the malfunction is detected |
| ODO/TRIP METER | Total mileage (Odometer value) of the moment a particular. |

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

DIAGNOSIS SYSTEM (ACCELERATOR PEDAL ACTUATOR)

< SYSTEM DESCRIPTION >

[FORWARD EMERGENCY BRAKING]

| Monitor item [Unit] | FUNCTION DESCRIPTION |
|------------------------------------|--|
| TGT FBK FRC [N] | It displays the target accelerator pedal actuation force that the accelerator pedal actuator read out from the accelerator pedal feedback force control signal received via ITS communication (The ADAS control unit transmits the accelerator pedal feedback force control signal via ITS communication) |
| TGT MOT POSI [%] | It displays the target motor position that the accelerator pedal actuator read out from the accelerator pedal feedback force control signal received via ITS communication (The ADAS control unit transmits the accelerator pedal feedback force control signal via ITS communication) |
| ACT MOT POSI [%] | It displays the integrated motor position that the accelerator pedal actuator read out |
| AP OPEN [%] | It displays the accelerator pedal position signal that the accelerator pedal actuator read out via ITS communication (The ADAS control unit transmits with ITS communication the accelerator pedal position signal that is received from ECM via CAN communication) |
| APA TEMP [°C] | It displays the accelerator pedal actuator integrated motor temperature |
| APA CURRENT [A] | It displays the accelerator pedal actuator integrated motor consumption current |
| APA PWR [V] | It displays the power supply voltage that the accelerator pedal actuator read out |
| APA OPE STATS [On/Off] | It displays the activation permission status of accelerator pedal actuator |
| APA STATS [READY/NG/TP NG/INIT] | It displays the condition of accelerator pedal actuator |

ACTIVE TEST

CAUTION:

Never perform ACTIVE TEST while driving the vehicle.

NOTE:

The active test cannot be performed when the ICC system warning lamp is illuminated.

Item list

| Active test item | Description |
|----------------------------------|--|
| ACCELERATOR PEDAL ACTUATOR TEST1 | Drive the accelerator pedal actuator and generate the constant accelerator pedal actuation force |
| ACCELERATOR PEDAL ACTUATOR TEST2 | Drive the accelerator pedal actuator and generate the vibration |

ACCELERATOR PEDAL ACTUATOR TEST 1

NOTE:

Check the accelerator pedal by depressing when performing the test.

| Active test item | Operation | Description |
|-----------------------------------|-----------|---|
| ACCELERATOR PEDAL AC-TUATOR TEST1 | STOP | Finish the test |
| | START | Generate the constant accelerator pedal actuation force for accelerator pedal |

ACCELERATOR PEDAL ACTUATOR TEST 2

NOTE:

Check the accelerator pedal by depressing when performing the test.

| Active test item | Operation | Description |
|------------------------------------|-----------|--|
| ACCELERATOR PEDAL AC-TUATOR TEST 2 | STOP | Finish the test |
| | START | Generate the vibration for accelerator pedal |

ECU IDENTIFICATION

Displays accelerator pedal assembly parts number.

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

ECU DIAGNOSIS INFORMATION

ADAS CONTROL UNIT

Reference Value

INFOID:0000000014224821

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor item | Condition | | Value/Status |
|---------------|--|--|--------------|
| MAIN SW | Ignition switch ON | When MAIN switch is pressed | On |
| | | When MAIN switch is not pressed | Off |
| SET/COAST SW | Ignition switch ON | When SET/COAST switch is pressed | On |
| | | When SET/COAST switch is not pressed | Off |
| CANCEL SW | Ignition switch ON | When CANCEL switch is pressed | On |
| | | When CANCEL switch is not pressed | Off |
| RESUME/ACC SW | Ignition switch ON | When RESUME/ACCELERATE switch is pressed | On |
| | | When RESUME/ACCELERATE switch is not pressed | Off |
| DISTANCE SW | Ignition switch ON | When DISTANCE switch is pressed | On |
| | | When DISTANCE switch is not pressed | Off |
| CRUISE OPE | Drive the vehicle and activate the vehicle-to-vehicle distance control mode | When ICC system is controlling | On |
| | | When ICC system is not controlling | Off |
| BRAKE SW | Ignition switch ON | When brake or clutch pedal is depressed | Off |
| | | When brake or clutch pedal is not depressed | On |
| STOP LAMP SW | Ignition switch ON | When brake pedal is depressed | On |
| | | When brake pedal is not depressed | Off |
| IDLE SW | Engine running | Idling | On |
| | | Except idling (depress accelerator pedal) | Off |
| SET DISTANCE | <ul style="list-style-type: none"> • Start the engine and turn the ICC system ON • Press the DISTANCE switch to change the vehicle-to-vehicle distance setting | When set to "long" | Long |
| | | When set to "middle" | Mid |
| | | When set to "short" | Short |
| CRUISE LAMP | Start the engine and press MAIN switch | ICC system ON (MAIN switch indicator ON) | On |
| | | ICC system OFF (MAIN switch indicator OFF) | Off |
| OWN VHCL | NOTE: The item is indicated, but not monitored | | Off |
| VHCL AHEAD | Drive the vehicle and activate the vehicle-to-vehicle distance control mode | When a vehicle ahead is detected (vehicle ahead detection indicator ON) | On |
| | | When a vehicle ahead is not detected (vehicle ahead detection indicator OFF) | Off |
| ICC WARNING | Start the engine and press MAIN switch | When ICC system is malfunctioning (ICC system malfunction ON) | On |
| | | When ICC system is normal (ICC system malfunction OFF) | Off |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

| Monitor item | Condition | | Value/Status |
|---------------|---|--|--|
| VHCL SPEED SE | While driving | | Displays the vehicle speed calculated by ADAS control unit |
| SET VHCL SPD | While driving | When vehicle speed is set | Displays the set vehicle speed |
| BUZZER O/P | Engine running | When the buzzer of the following system operates <ul style="list-style-type: none"> • Vehicle-to-vehicle distance control mode • DCA system • PFCW system • FEB system | On |
| | | When the buzzer of the following system not operates <ul style="list-style-type: none"> • Vehicle-to-vehicle distance control mode • DCA system • PFCW system • FEB system | Off |
| THRTL SENSOR | NOTE: The item is indicated, but not monitored | | 0.0 |
| ENGINE RPM | Engine running | | Equivalent to tachometer reading |
| WIPER SW | Ignition switch ON | Wiper not operating | Off |
| | | Wiper LO operation | Low |
| | | Wiper HI operation | High |
| YAW RATE | NOTE: The item is indicated, but not monitored | | 0.0 |
| BA WARNING | Engine running | FEB OFF indicator lamp ON <ul style="list-style-type: none"> • When FEB system is malfunctioning • When FEB system is turned to OFF | On |
| | | FEB OFF indicator lamp OFF <ul style="list-style-type: none"> • When FEB system is normal • When FEB system is turned to ON | Off |
| STP LMP DRIVE | Drive the vehicle and activate the vehicle-to-vehicle distance control mode | When ICC brake hold relay is activated | On |
| | | When ICC brake hold relay is not activated | Off |
| D RANGE SW | Engine running | When the selector lever is in "D" position or manual mode | On |
| | | When the selector lever is in any position other than "D" or manual mode | Off |
| NP RANGE SW | Engine running | When the selector lever is in "N", "P" position | On |
| | | When the selector lever is in any position other than "N", "P" | Off |
| PKB SW | Ignition switch ON | When the parking brake is applied | On |
| | | When the parking brake is released | Off |
| PWR SUP MONI | Engine running | | Power supply voltage value of ADAS control unit |
| VHCL SPD AT | While driving | | Value of A/T vehicle speed sensor signal |
| THRTL OPENING | Engine running | Depress accelerator pedal | Displays the throttle position |

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

| Monitor item | Condition | | Value/Status |
|---------------|---|--|---|
| GEAR | While driving | | Displays the gear position |
| MODE SIG | Start the engine and press MAIN switch | When ICC system is deactivated | Off |
| | | When vehicle-to-vehicle distance control mode is activated | ICC |
| | | When conventional (fixed speed) cruise control mode is activated | ASCD |
| SET DISP IND | <ul style="list-style-type: none"> • Drive the vehicle and activate the conventional (fixed speed) cruise control mode • Press SET/COAST switch | SET switch indicator ON | On |
| | | SET switch indicator OFF | Off |
| DISTANCE | Drive the vehicle and activate the vehicle-to-vehicle distance control mode | When a vehicle ahead is detected | Displays the distance from the preceding vehicle |
| | | When a vehicle ahead is not detected | 0.0 |
| RELATIVE SPD | Drive the vehicle and activate the vehicle-to-vehicle distance control mode | When a vehicle ahead is detected | Displays the relative speed. |
| | | When a vehicle ahead is not detected | 0.0 |
| DYNA ASIST SW | Ignition switch ON | When dynamic driver assistance switch is pressed | On |
| | | When dynamic driver assistance switch is not pressed | Off |
| DCA ON IND | Start the engine and press dynamic driver assistance switch (When DCA setting is ON) | DCA system OFF | Off |
| | | DCA system ON | On |
| DCA VHL AHED | Drive the vehicle and activate the DCA system | When a vehicle ahead is not detected (vehicle ahead detection indicator OFF) | Off |
| | | When a vehicle ahead is detected (vehicle ahead detection indicator ON) | On |
| FCW SYSTEM ON | Ignition switch ON | When the PFCW system is ON | On |
| | | When the PFCW system is OFF | Off |
| APA TEMP | Engine running | | Display the accelerator pedal actuator integrated motor temperature |
| APA PWR | Ignition switch ON | | Power supply voltage value of accelerator pedal actuator |
| LDW SYSTEM ON | Ignition switch ON | When the LDW system is ON | On |
| | | When the LDW system is OFF | Off |
| LDW ON LAMP | Ignition switch ON | When the LDW system is ON | On |
| | | When the LDW system is OFF | Off |
| LDP ON IND | Start the engine and press dynamic driver assistance switch (When LDP system setting is ON) | LDP ON indicator lamp ON | On |
| | | LDP ON indicator lamp OFF | Off |
| LANE DPRT W/L | Drive the vehicle and activate the LDW system or LDP system | Lane departure warning lamp ON | On |
| | | Lane departure warning lamp OFF | Off |

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

| Monitor item | Condition | | Value/Status |
|------------------|--|---|-----------------------------|
| LDW BUZER OUTPUT | Drive the vehicle and activate the LDW/LDP system or Blind Spot Warning/Blind Spot Intervention system | When the buzzer of the following system operates • LDW/LDP system • Blind Spot Warning/Blind Spot Intervention system | On |
| | | When the buzzer of the following system does not operate • LDW/LDP system • Blind Spot Warning/Blind Spot Intervention system | Off |
| LDP SYSTEM ON | Start the engine and press dynamic driver assistance switch (When LDP system setting is ON) | When the LDP system is ON | On |
| | | When the LDP system is OFF | Off |
| WARN REQ | Drive the vehicle and activate the LDP system | Lane departure warning is operating | On |
| | | Lane departure warning is not operating | Off |
| READY signal | Start the engine and press dynamic driver assistance switch (When LDP system setting is ON) | When the LDP system is ON | On |
| | | When the LDP system is OFF | Off |
| Camera lost | Drive the vehicle and activate the LDW system, LDP system or Blind Spot Intervention system | Both side lane markers are detected | Detect |
| | | Deviate side lane marker is lost | Deviate |
| | | Both side lane markers are lost | Both |
| Lane unclear | While driving | Lane marker is unclear | On |
| | | Lane marker is clear | Off |
| STATUS signal | Drive the vehicle and activate the LDP system | When the LDP system is ON | Stnby |
| | | When the LDP system is operating | Warn |
| | | When the LDP system is canceled | Cancl |
| | | When the LDP system is OFF | Off |
| Shift position | <ul style="list-style-type: none"> • Engine running • While driving | | Displays the shift position |
| Turn signal | Turn signal lamps OFF | | Off |
| | Turn signal lamp LH blinking | | LH |
| | Turn signal lamp RH blinking | | RH |
| | Turn signal lamp LH and RH blinking | | LH&RH |
| SIDE G | While driving | Vehicle turning right | Negative value |
| | | Vehicle turning left | Positive value |
| FUNC ITEM | Ignition switch ON | | FUNC3 |
| FUNC ITEM (FCW) | Engine running | | On |
| FUNC ITEM (LDW) | Engine running | | On |
| FUNC ITEM (BSW) | Engine running | | On |
| DCA SELECT | Ignition switch ON | "Distance Control Assist" set with the integral switch is ON | On |
| | | "Distance Control Assist" set with the integral switch is OFF | Off |
| LDP SELECT | Ignition switch ON | "Lane Departure Intervention" set with the integral switch is ON | On |
| | | "Lane Departure Intervention" set with the integral switch is OFF | Off |
| BSI SELECT | Ignition switch ON | "Blind Spot Intervention" set with the integral switch is ON | On |
| | | "Blind Spot Intervention" set with the integral switch is OFF | Off |

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

| Monitor item | Condition | | Value/Status |
|-----------------------|---|---|--------------|
| FCW SELECT | Ignition switch ON | "Forward Emergency Braking" set with the integral switch is ON | On |
| | | "Forward Emergency Braking" set with the integral switch is OFF | Off |
| LDW SELECT | Ignition switch ON | "Lane Departure Warning" set with the integral switch is ON | On |
| | | "Lane Departure Warning" set with the integral switch is OFF | Off |
| BSW SELECT | Ignition switch ON | "Blind Spot Warning" set with the integral switch is ON | On |
| | | "Blind Spot Warning" set with the integral switch is OFF | Off |
| DRIVE MODE STATS | Ignition switch ON | When drive mode select switch position is STANDARD | STD |
| | | When drive mode select switch position is in SPORT | SPORT |
| | | When drive mode select switch position is in ECO | ECO |
| | | When drive mode select switch position is in SNOW | SNOW |
| | | When drive mode select switch position is in PERSONAL | STD |
| | | A signal other than those above is input | ERROR |
| WARN SYS SW | Ignition switch ON | When warning systems switch is pressed | On |
| | | When warning systems switch is not pressed | Off |
| BSW/BSI WARN LMP | Engine running | When the BSW system is malfunctioning | On |
| | | When the BSW system is normal | Off |
| BSI ON IND | Engine running | Blind Spot Intervention warning ON | On |
| | | Blind Spot Intervention warning OFF | Off |
| BSW SYSTEM ON | Ignition switch ON | When the BSW system is ON | On |
| | | When the BSW system is OFF | Off |
| BSI SYSTEM ON | Start the engine and press dynamic driver assistance switch (When Blind Spot Intervention system setting is ON) | When the Blind Spot Intervention system is ON | On |
| | | When the Blind Spot Intervention system is OFF | Off |
| FCW SYSTEM ON | Engine running | When the FEB/PFCW system is ON | On |
| | | When the FEB/PFCW system is OFF | Off |
| BCI SYSTEM ON | Engine running | When the BCI system is ON | On |
| | | When the BCI system is OFF | Off |
| BCI SWITCH | NOTE: The item is indicated, but not monitored | | Off |
| BATTERY CIRCUIT OFF | NOTE: The item is indicated, but not used | | Off |
| LDP WARNING INDICATOR | Engine running | When the LDP system is malfunctioning | On |
| | | When the LDP system is normal | Off |
| LDW ON INDICATOR | Engine running | LDW system display ON | On |
| | | LDW system display OFF | Off |
| LDW WARNING INDICATOR | Engine running | When the LDW system is malfunctioning | On |
| | | When the LDW system is normal | Off |
| SYSTEM CANCEL MESSAGE | Engine running | When the vehicle is normal | NOREQ |
| | | When the wheel is slipping | SLIP |
| | | When the drive mode selector is SNOW mode | SNOW |
| | | When the VDC is OFF | VDC OFF |

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P


ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

| Monitor item | Condition | | Value/Status |
|--------------------------|--------------------|--|--------------|
| CAMERA HI TEMP MSG | Engine running | Lane camera unit high temperature warning display ON | On |
| | | Lane camera unit high temperature warning display OFF | Off |
| ITS SETTING ITEM(DCA) | Ignition switch ON | | On |
| ITS SETTING ITEM(LDP) | Ignition switch ON | | On |
| ITS SETTING ITEM(BSI) | Ignition switch ON | | On |
| BSI WARNING INDICATOR | Engine running | When the Blind Spot Intervention is malfunctioning | On |
| | | When the Blind Spot Intervention is normal | Off |
| BSW ON INDICATOR | Engine running | BSW system display ON | On |
| | | BSW system display OFF | Off |
| SIDE RADAR BLOCK COND | Engine running | Front bumper or side radar is dirty | On |
| | | Front bumper and side radar is clean | Off |
| LDW WARNING ALERT TIMING | Ignition switch ON | LDW system OFF | Nothing |
| | | Lane departure warning timing is early setting | Early |
| | | Lane departure warning timing is late setting | Late |
| BSW IND BRIGHTNESS | Ignition switch ON | BSW system OFF | Nothing |
| | | Blind Spot Warning/Blind Spot Intervention indicator brightness bright | Bright |
| | | Blind Spot Warning/Blind Spot Intervention indicator brightness normal | Normal |
| | | Blind Spot Warning/Blind Spot Intervention indicator brightness dark | Dark |

TERMINAL LAYOUT
PHYSICAL VALUES



ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------------------------------|-----------------------------------|------------------|--------------------------|--|------------------------|
| + | - | Signal name | Input/ Output | | | |
| 1 (B) | Ground | CAN high | — | — | — | — |
| 2 (W) | | CAN low | — | — | — | — |
| 5 (B) | | Ground | — | Ignition switch ON | — | 0 V |
| 6 (L) | | ITS communication high | — | — | — | — |
| 7 (Y) | | ITS communication low | — | — | — | — |
| 8 (L) | | Chassis communication high | — | — | — | — |
| 9 (Y) | | Chassis communication low | — | — | — | — |
| 12 (R) | | Ignition power supply | Input | Ignition switch ON | | Battery voltage |
| 17 (G) | | ICC brake hold relay drive signal | Output | Ignition switch ON | — At "STOP LAMP" test of "Active test" | Battery voltage 0 V |
| 18 (BR) | | Warning systems switch | Input | Ignition switch ON | When warning systems switch is not pressed | Battery voltage |
| | | | | | When warning systems switch is pressed | 0 V |
| 19 (W) | | Warning systems ON indicator | Output | Ignition switch ON | Warning systems ON indicator ON | 0 V |
| | | | | | Warning systems ON indicator OFF | Battery voltage |
| 22 (BG) | | BCI OFF switch | Input | Ignition switch ON | When BCI OFF switch is not pressed | Battery voltage |
| | When BCI OFF switch is pressed | | | | 0 V | |

Fail-safe (ADAS Control Unit)

INFOID:000000014224822

If a malfunction occurs in each system, ADAS control unit cancels each control, sounds a beep, and turns ON the warning or indicator lamp.

| System | Buzzer | Warning lamp/Warning display | Description |
|--|-------------------|------------------------------|-------------|
| Vehicle-to-vehicle distance control mode | High-pitched tone | ICC system warning | Cancel |
| Conventional (fixed speed) cruise control mode | High-pitched tone | ICC system warning | Cancel |
| Forward Emergency Braking (FEB) | High-pitched tone | FEB warning | Cancel |
| Predictive Forward Collision Warning (PFCW) | High-pitched tone | Warning message | Cancel |
| Distance Control Assist (DCA) | High-pitched tone | DCA system warning | Cancel |
| Lane Departure Warning (LDW) | — | Lane departure warning lamp | Cancel |

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

| System | Buzzer | Warning lamp/Warning display | Description |
|-------------------------------------|-------------------|---|-------------|
| Lane Departure Prevention (LDP) | Low-pitched tone | Lane departure warning lamp | Cancel |
| Blind Spot Warning (BSW) | — | Blind Spot Warning warning lamp | Cancel |
| Blind Spot Intervention | Low-pitched tone | Blind Spot Intervention warning lamp | Cancel |
| Backup Collision Intervention (BCI) | High-pitched tone | Backup Collision Intervention warning indicator | Cancel |
| Rear Cross Traffic Alert (RCTA) | — | Rear Cross Traffic Alert warning | Cancel |

DTC Inspection Priority Chart

INFOID:0000000014224823

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

| Priority | Detected items (DTC) | |
|----------|---|--|
| 1 | <ul style="list-style-type: none"> • U1507: LOST COMM (SIDE RDR R) • U1508: LOST COMM (SIDE RDR L) | |
| 2 | <ul style="list-style-type: none"> • 1CA0A: CONFIG UNFINISHED • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN) | |
| 3 | <ul style="list-style-type: none"> • C1B00: CAMERA UNIT MALF • C1F02: APA C/U MALF • C1B53: SIDE RDR R MALF • C1B54: SIDE RDR L MALF • C1B84: DIST SEN MALFUNCTION | |
| 4 | <ul style="list-style-type: none"> • C1A01: POWER SUPPLY CIR • C1A02: POWER SUPPLY CIR 2 • C1A04: ABS/TCS/VDC CIRC • C1A05: BRAKE SW/STOP L SW • C1A06: OPERATION SW CIRC • C1A13: STOP LAMP RLY FIX • C1A14: ECM CIRCUIT • C1A24: NP RANGE • C1A26: ECD MODE MALF • C1A27: ECD PWR SUPPLY CIR • C1A33: CAN TRANSMISSION ERR • C1A34: COMMAND ERROR • C1A35: APA CIR • C1A36: APA CAN COMM CIR • C1A37: APA CAN CIR 2 • C1A38: APA CAN CIR 1 • C1A39: STRG SEN CIR • C1A40: SYSTEM SW CIR • C1B01: CAM AIMING INCOMP • C1B03: CAM ABNORMAL TMP DETCT • C1B56: SONAR CIRCUIT • C1B57: AVM CIRCUIT • C1B58: DR ASSIST BUZZER CIRCUIT • C1B82: DIST SEN OFF-CENTER • C1B85: DIST SEN ABNORMAL TEMP • C1B86: DIST SEN PWR SUP CIR • C1F01: APA MOTOR MALF • C1F05: APA PWR SUPPLY CIR | <ul style="list-style-type: none"> • U0121: VDC CAN CIR 2 • U0126: STRG SEN CAN CIR 1 • U0235: ICC SENSOR CAN CIRC 1 • U0401: ECM CAN CIR 1 • U0402: TCM CAN CIR 1 • U0415: VDC CAN CIR 1 • U0424: HVAC CAN CIR 1 • U0428: STRG SEN CAN CIR 2 • U1500: CAM CAN CIR 2 • U1501: CAM CAN CIR 1 • U1502: ICC SEN CAN COMM CIR • U1503: SIDE RDR L CAN CIR 2 • U1504: SIDE RDR L CAN CIR 1 • U1505: SIDE RDR R CAN CIR 2 • U1506: SIDE RDR R CAN CIR 1 • U150B: ECM CAN CIRC 3 • U150C: VDC CAN CIRC 3 • U150D: TCM CAN CIRC 3 • U150E: BCM CAN CIRC 3 • U1512: HVAC CAN CIRC3 • U1513: METER CAN CIRC 3 • U1514: STRG SEN CAN CIRC 3 • U1515: ICC SENSOR CAN CIRC 3 • U1516: CAM CAN CIR 3 • U1517: APA CAN CIRC 3 • U1518: SIDE RDR L CAN CIRC 3 • U1519: SIDE RDR R CAN CIRC 3 • U1521: SONAR CAN COMMUNICATION 2 • U1522: SONAR CAN COMMUNICATION 1 • U1523: SONAR CAN COMMUNICATION 3 • U1524: AVM CAN COMMUNICATION 1 • U1525: AVM CAN COMMUNICATION 3 • U1530: DR ASSIST BUZZER CAN CIR 1 |

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

| Priority | Detected items (DTC) |
|----------|-----------------------------|
| 5 | • C1A03: VHCL SPEED SE CIRC |
| 6 | • C1A15: GEAR POSITION |
| 7 | • C1A00: CONTROL UNIT |

DTC Index

INFOID:0000000014224824

Systems for fail-safe

- A: Vehicle-to-vehicle distance control mode
- B: Conventional (fixed speed) cruise control mode
- C: Distance Control Assist (DCA)
- D: Forward Emergency Braking (FEB)
- E: Predictive Forward Collision Warning (PFCW)
- F: Blind Spot Warning (BSW)/Blind Spot Intervention (BSI)/Rear Cross Traffic Alert (RCTA)
- G: Back-up Collision Intervention (BCI)
- H: Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)

| DTC | | CONSULT display | Fail-safe | Reference |
|---|------------------|---|------------------------|-------------------------|
| CONSULT | On board display | | System | |
| NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED | 55 | NO DTC IS DETECTED. FURTHER TESTING MAY BE REQUIRED | — | — |
| C1A0A | 41 | CONFIG UNFINISHED | A, B, C, D, E, F, G, H | DAS-68 |
| C1A00 | 0 | CONTROL UNIT | A, B, C, D, E, F, G, H | DAS-69 |
| C1A01 | 1 | POWER SUPPLY CIR | A, B, C, D, E, F, G, H | DAS-70 |
| C1A02 | 2 | POWER SUPPLY CIR 2 | A, B, C, D, E, F, G, H | DAS-70 |
| C1A03 | 3 | VHCL SPEED SE CIRC | A, B, C, D, E, F, G, H | DAS-71 |
| C1A04 | 4 | ABS/TCS/VDC CIRC | A, B, C, D, E, F, G, H | DAS-73 |
| C1A05 | 5 | BRAKE SW/STOP L SW | A, B, C, D, G, H | DAS-75 |
| C1A06 | 6 | OPERATION SW CIRC | A, B, C, D, E, H | DAS-80 |
| C1A13 | 13 | STOP LAMP RLY FIX | A, B, C, D, E, G | DAS-82 |
| C1A14 | 14 | ECM CIRCUIT | A, B, C, D, E | DAS-89 |
| C1A15 | 15 | GEAR POSITION | A, B, C, D, E | DAS-91 |
| C1A24 | 24 | NP RANGE | A, B, C, D, E, F, G | DAS-93 |
| C1A26 | 26 | ECD MODE MALF | A, B, C, D, G | DAS-95 |
| C1A27 | 27 | ECD PWR SUPPLY CIR | A, B, C, D, G | DAS-97 |
| C1A33 | 33 | CAN TRANSMISSION ERR | A, B, C, D, E | DAS-99 |
| C1A34 | 34 | COMMAND ERROR | A, B, C, D, E | DAS-100 |
| C1A35 | 35 | APA CIR | A, C, D, E | DAS-101 |
| C1A36 | 36 | APA CAN COMM CIR | A, C, D, E | DAS-102 |
| C1A37 | 133 | APA CAN CIR 2 | A, C, D, E | DAS-103 |
| C1A38 | 132 | APA CAN CIR 1 | A, C, D, E | DAS-104 |
| C1A39 | 39 | STRG SEN CIR | A, B, C, D, E, F, G | DAS-105 |
| C1A40 | 40 | SYSTEM SW CIR | G | DAS-105 |
| C1B00 | 81 | CAMERA UNIT MALF | F, H | DAS-108 |
| C1B01 | 82 | CAM AIMING INCMP | F, H | DAS-109 |
| C1B03 | 83 | ABNRML TMP DETCT | F, H | DAS-110 |
| C1B53 | 84 | SIDE RDR R MALF | F, G | DAS-111 |

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

Systems for fail-safe

- A: Vehicle-to-vehicle distance control mode
- B: Conventional (fixed speed) cruise control mode
- C: Distance Control Assist (DCA)
- D: Forward Emergency Braking (FEB)
- E: Predictive Forward Collision Warning (PFCW)
- F: Blind Spot Warning (BSW)/Blind Spot Intervention (BSI)/Rear Cross Traffic Alert (RCTA)
- G: Back-up Collision Intervention (BCI)
- H: Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)

| DTC | | CONSULT display | Fail-safe | Reference |
|-----------------------|------------------|--------------------------|------------------------|-------------------------|
| CONSULT | On board display | | System | |
| C1B54 | 85 | SIDE RDR L MALF | F, G | DAS-112 |
| C1B56 | 86 | SONAR CIRCUIT | G | DAS-113 |
| C1B57 | 87 | AVM CIRCUIT | G | DAS-114 |
| C1A58 | 182 | DR ASSIST BUZZER CIRCUIT | | DAS-115 |
| C1B82 | 12 | DIST SEN OFF-CENTER | A, C, D, E | DAS-116 |
| C1B83 | 16 | DIST SEN BLOCKED | A, C, D, E | DAS-117 |
| C1B84 | 17 | DIST SEN MALFUNCTION | A, C, D, E | DAS-118 |
| C1B85 | 21 | DIST SEN ABNORMAL TEMP | A, C, D, E | DAS-119 |
| C1B86 | 80 | DIST SEN PWR SUP CIR | A, C, D, E | DAS-120 |
| C1F01 | 91 | APA MOTOR MALF | A, C, D, E | DAS-122 |
| C1F02 | 92 | APA C/U MALF | A, C, D, E | DAS-123 |
| C1F05 | 95 | APA PWR SUPPLY CIR | A, C, D, E | DAS-124 |
| U0121 | 127 | VDC CAN CIR 2 | A, B, C, D, E, F, G, H | DAS-125 |
| U0126 | 130 | STRG SEN CAN CIR 1 | A, B, C, D, E, F, G | DAS-126 |
| U0235 | 144 | ICC SENSOR CAN CIRC 1 | A, C, D, E | DAS-127 |
| U0401 | 120 | ECM CAN CIR 1 | A, B, C, D, E, F, G | DAS-128 |
| U0402 | 122 | TCM CAN CIR 1 | A, B, C, D, E, F, G, H | DAS-129 |
| U0415 | 126 | VDC CAN CIR 1 | A, B, C, D, E, F, G, H | DAS-131 |
| U0424 | 156 | HVAC CAN CIR 1 | | DAS-133 |
| U0428 | 131 | STRG SEN CAN CIR 2 | A, B, C, D, E, F, G | DAS-134 |
| U1000 ^{NOTE} | 100 | CAN COMM CIRCUIT | A, B, C, D, E, F, G, H | DAS-135 |
| U1010 | 110 | CONTROL UNIT (CAN) | A, B, C, D, E, F, G, H | DAS-137 |
| U150B | 157 | ECM CAN CIRC 3 | A, B, C, D, E, F, G, H | DAS-138 |
| U150C | 158 | VDC CAN CIRC 3 | A, B, C, D, E, F, G, H | DAS-140 |
| U150D | 159 | TCM CAN CIRC 3 | A, B, C, D, E, F, G, H | DAS-142 |
| U150E | 160 | BCM CAN CIRC 3 | A, B, C, D, F, G, H | DAS-144 |
| U1500 | 145 | CAM CAN CIR2 | F, H | DAS-145 |
| U1501 | 146 | CAM CAN CIR 1 | F, H | DAS-146 |
| U1502 | 147 | ICC SEN CAN COMM CIR | A, C, D, E | DAS-147 |
| U1503 | 150 | SIDE RDR L CAN CIR 2 | F, G | DAS-148 |
| U1504 | 151 | SIDE RDR L CAN CIR 1 | F, G | DAS-149 |
| U1505 | 152 | SIDE RDR R CAN CIR 2 | F, G | DAS-150 |
| U1506 | 153 | SIDE RDR R CAN CIR 1 | F, G | DAS-151 |
| U1507 | 154 | LOST COMM (SIDE RDR R) | F, G | DAS-152 |
| U1508 | 155 | LOST COMM (SIDE RDR L) | F, G | DAS-153 |
| U1512 | 162 | HVAC CAN CIRC3 | | DAS-154 |

ADAS CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

Systems for fail-safe

- A: Vehicle-to-vehicle distance control mode
- B: Conventional (fixed speed) cruise control mode
- C: Distance Control Assist (DCA)
- D: Forward Emergency Braking (FEB)
- E: Predictive Forward Collision Warning (PFCW)
- F: Blind Spot Warning (BSW)/Blind Spot Intervention (BSI)/Rear Cross Traffic Alert (RCTA)
- G: Back-up Collision Intervention (BCI)
- H: Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)

| DTC | | CONSULT display | Fail-safe | Reference |
|---------|------------------|---------------------------|------------------------|-------------------------|
| CONSULT | On board display | | System | |
| U1513 | 163 | METER CAN CIRC 3 | A, B, C, D, E, F, G, H | DAS-155 |
| U1514 | 164 | STRG SEN CAN CIRC 3 | A, B, C, D, E, F, G | DAS-156 |
| U1515 | 165 | ICC SENSOR CAN CIRC 3 | A, C, D, E | DAS-157 |
| U1516 | 166 | CAM CAN CIRC 3 | F, H | DAS-158 |
| U1517 | 167 | APA CAN CIRC 3 | A, C, D, E | DAS-159 |
| U1518 | 168 | SIDE RDR L CAN CIRC 3 | F, G | DAS-160 |
| U1519 | 169 | SIDE RDR R CAN CIRC 3 | F, G | DAS-161 |
| U1521 | 177 | SONAR CAN COMMUNICATION 2 | G | DAS-163 |
| U1522 | 178 | SONAR CAN COMMUNICATION 1 | G | DAS-164 |
| U1523 | 179 | SONAR CAN COMMUNICATION 3 | G | DAS-165 |
| U1524 | 180 | AVM CAN COMMUNICATION 1 | G | DAS-166 |
| U1525 | 181 | AVM CAN COMMUNICATION 3 | G | DAS-167 |
| U1530 | 183 | DR ASSIST BUZZER CAN CIR1 | | DAS-168 |

NOTE:

With the detection of “U1000” some systems do not perform the fail-safe operation.

A system controlling based on a signal received from the control unit performs fail-safe operation when the communication with the ADAS control unit becomes inoperable.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ICC SENSOR

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

ICC SENSOR


Reference Value

INFOID:000000014222590

VALUES ON THE DIAGNOSIS TOOL

| Monitor item | Condition | | Value/Status |
|------------------|---|--|--|
| VHCL SPEED SE | While driving | | Value of vehicle speed signal (wheel speed) |
| YAW RATE | While driving | Vehicle stopped | 0.0 |
| | | Vehicle turning right | Positive value |
| | | Vehicle turning left | Negative value |
| PWR SUP MONI | Ignition switch ON | | Power supply voltage value of ICC sensor |
| DISTANCE | Drive the vehicle and activate the vehicle-to-vehicle distance control mode | When a vehicle ahead is detected | Displays the distance from the preceding vehicle |
| | | When a vehicle ahead is not detected | 0.0 |
| RELATIVE SPD | Drive the vehicle and activate the vehicle-to-vehicle distance control mode | When a vehicle ahead is detected | Displays the relative speed |
| | | When a vehicle ahead is not detected | 0.0 |
| RADAR OFFSET | NOTE: The item is indicated, but not used | | — |
| RADAR HEIGHT | NOTE: The item is indicated, but not used | | — |
| STEERING ANGLE | Ignition switch ON | When setting the steering wheel in straight-ahead position | 0.0 |
| | | When turning the steering wheel 90° rightward | +90 |
| | | When turning the steering wheel 90° leftward | -90 |
| STRG ANGLE SPEED | Ignition switch ON | At the time of turning the steering wheel | Steering wheel turning speed is displayed |
| L/R ADJUST | Ignition switch ON | At the completion of radar alignment adjustment | Horizontal correction value is displayed |
| U/D ADJUST | Ignition switch ON | At the completion of radar alignment adjustment | Vertical correction value is displayed |

TERMINAL LAYOUT



PHYSICAL VALUES

ICC SENSOR

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

| Terminal No. (Wire color) | | Description | | Condition | Standard value | Reference value (Approx.) |
|------------------------------|----------|-----------------------|------------------|--------------------|----------------|------------------------------|
| + | - | Signal name | Input/ Output | | | |
| 1 (P) | 8 (B) | Ignition power supply | Input | Ignition switch ON | 9.5 - 16 V | Battery voltage |
| 3 (L) | — | ITS communication-L | — | — | — | — |
| 6 (Y) | | ITS communication-H | — | — | — | — |
| 8 (B) | Ground | Ground | — | Ignition switch ON | 0 - 0.1 V | 0 V |

Fail-safe (ICC Sensor)

INFOID:000000014222591

If a malfunction occurs in the ICC sensor, ADAS control unit cancels control, sounds a beep, and turns ON the ICC system warning lamp in the combination meter.

DTC Inspection Priority Chart

INFOID:000000014222592

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

| Priority | Detected items (DTC) |
|----------|--|
| 1 | <ul style="list-style-type: none"> U1000: CAN COMM CIRCUIT U1010: CONTROL UNIT (CAN) |
| 2 | <ul style="list-style-type: none"> C1A50: ADAS MALFUNCTION |

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ICC SENSOR

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

| Priority | Detected items (DTC) |
|----------|--|
| 3 | <ul style="list-style-type: none"> • C1A01: POWER SUPPLY CIR • C1A02: POWER SUPPLY CIR 2 • C1A03: VHCL SPEED CIRC • C1A04: ABS/TCS/VDC CIRC • C1A05: BRAKE SW/STOP L SW • C1A06: OPERATION SW • C1A13: STOP LSMP RLY FIX • C1A14: ECM CIRCUIT • C1A15: GEAR POSITION • C1A23: UNIT LOW TEMP • C1A24: NP RANGE • C1A26: ECD MODE MALF • C1A27: ECD PWR SUPPLY CIR • C1A33: CAN TRANSMISSION ERR • C1A34: COMMAND ERROR • C1A35: APA CIR • C1A36: APA CAN COMM CIR • C1A37: APA CAN CIR2 • C1A38: APA CAN CIR1 • C1A39: STRG SEN CIR • C1B58: DR ASSIST BUZZER CIRCUIT • C1B83: DIST SEN BLOCKED • C1F01: APA MOTOR MALF • C1F02: APA C/U MALF • C1F05: APA PWR SUPPLY CIR • U0104: ADAS CAN CIR1 • U0121: VDC CAN CIR2 • U0126: STRG SEN CAN CIR1 • U0235: ICC SENSOR CAN CIR1 • U0401: ECM CAN CIR2 • U0402: TCM CAN CIR2 • U0415: VDC CAN CIR1 • U150B: ECM CAN CIR3 • U150C: VDC CAN CIRC3 • U150D: TCM CAN CIRC3 • U150E: BCM CAN CIRC3 • U1513: METER CAN CIRC3 • U1514: STRG SEN CAN CIRC3 • U1515: ICC SENSOR CAN CIRC3 • U1517: APA CAN CIRC3 |
| 4 | <ul style="list-style-type: none"> • C1A00: CONTROL UNIT |

DTC Index

INFOID:000000014222593

NOTE:

- The details of time display are as per the following.
- 0: The malfunctions that are detected now
CAN communication system (U1000, U1010)
- 1 - 39: It increases like 0 → 1 → 2 ... 38 → 39 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
- If it is over 39, it is fixed to 39 until the self-diagnosis results are erased.
Other than CAN communication system (Other than U1000, U1010)
- 1 - 49: It increases like 0 → 1 → 2 ... 38 → 49 after returning to the normal condition whenever the ignition switch OFF → ON. It returns to 0 when a malfunction is detected again in the process.
- If it is over 49, it is fixed to 49 until the self-diagnosis results are erased.

ICC SENSOR

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

×: Applicable

| DTC | | Fail-safe function | Fail-safe function | | | | | Reference |
|---------|------------------------|-------------------------|--|--|-------------------------------|---------------------------------|---------------------------------|--|
| | | | Vehicle-to-vehicle distance control mode | Conventional (fixed speed) cruise control mode | Distance Control Assist (DCA) | Forward Collision Warning (FCW) | Forward Emergency Braking (FEB) | |
| CONSULT | CONSULT display | ICC system warning lamp | | | | | | |
| C1A00 | CONTROL UNIT | ON | × | × | × | × | × | CCS-96, "ICC SENSOR : DTC Logic" |
| C1A01 | POWER SUPPLY CIR | ON | × | × | × | × | × | CCS-98, "ICC SENSOR : DTC Logic" |
| C1A02 | POWER SUPPLY CIR2 | ON | × | × | × | × | × | CCS-98, "ICC SENSOR : DTC Logic" |
| C1A03 | VHCL_SPEED SE CIRC | ON | × | × | × | × | × | CCS-100, "DTC Logic" |
| C1A04 | ABS/TCS/VDC_CIRC | ON | × | × | × | × | × | CCS-102, "DTC Logic" |
| C1A05 | BRAKE_SW/STOP_L_SW | ON | × | × | × | × | × | CCS-104, "DTC Logic" |
| C1A06 | OPERATION_SW_CIRC | ON | × | × | × | × | × | CCS-109, "DTC Logic" |
| C1A13 | STOP_LAMP_RLY_FIX | ON | × | × | × | × | × | CCS-112, "DTC Logic" |
| C1A14 | ECM_CIRCUIT | ON | × | × | × | × | × | CCS-118, "DTC Logic" |
| C1A15 | GEAR_POSITION | ON | × | × | × | × | × | CCS-119, "DTC Logic" |
| C1A23 | UNIT HIGH TEMP | ON | × | × | × | × | × | CCS-121, "DTC Logic" |
| C1A24 | NP_RANGE | ON | × | × | × | × | × | CCS-122, "DTC Logic" |
| C1A26 | ECD_MODE_MALF | ON | × | × | × | × | × | CCS-124, "DTC Logic" |
| C1A27 | ECD_PWR_SUPLY_CIR | ON | × | × | × | × | × | CCS-126, "DTC Logic" |
| C1A33 | CAN TRANSMISSION ERROR | ON | × | × | × | × | × | CCS-128, "DTC Logic" |
| C1A34 | COMMAND ERROR | ON | × | × | × | × | × | CCS-129, "DTC Logic" |
| C1A35 | APA CIR | ON | × | × | × | × | × | CCS-130, "DTC Logic" |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ICC SENSOR

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

| DTC | CONSULT display | ICC system warning lamp | Fail-safe function | | | | | Reference |
|-------|--------------------------|-------------------------|--|--|-------------------------------|---------------------------------|---------------------------------|--|
| | | | Vehicle-to-vehicle distance control mode | Conventional (fixed speed) cruise control mode | Distance Control Assist (DCA) | Forward Collision Warning (FCW) | Forward Emergency Braking (FEB) | |
| C1A36 | APA CAN COMM CIR | ON | x | x | x | x | x | CCS-131. "DTC Logic" |
| C1A37 | APA CAN CIR2 | ON | x | x | x | x | x | CCS-132. "DTC Logic" |
| C1A38 | APA CAN CIR2 | ON | x | x | x | x | x | CCS-133. "DTC Logic" |
| C1A39 | STRG SEN CIR | ON | x | x | x | x | x | CCS-135. "ICC SEN- SOR : DTC Logic" |
| C1B58 | DR ASSIST BUZZER CIRCUIT | ON | x | x | x | x | x | CCS-169. "DTC Logic" |
| C1B83 | DIST SEN BLOCKED | ON | x | x | x | x | x | CCS-137. "DTC Logic" |
| C1F01 | APA MOTOR MALF | ON | x | x | x | x | x | CCS-138. "DTC Logic" |
| C1F02 | APA C/U MALF | ON | x | x | x | x | x | CCS-139. "DTC Logic" |
| C1F05 | APA PWR SUPPLY CIR | ON | x | x | x | x | x | CCS-140. "DTC Logic" |
| U0121 | VDC CAN CIR2 | ON | x | x | x | x | x | CCS-142. "ICC SEN- SOR : DTC Logic" |
| U0126 | STRG SEN CAN CIR1 | ON | x | x | x | x | x | CCS-144. "ICC SEN- SOR : DTC Logic" |
| U0235 | ICC SENSOR CAN CIR1 | ON | x | x | x | x | x | CCS-146. "DTC Logic" |
| U0401 | ECM CAN CIR1 | ON | x | x | x | x | x | CCS-147. "DTC Logic" |
| U0402 | TCM CAN CIRC1 | ON | x | x | x | x | x | CCS-148. "DTC Logic" |
| U0415 | VDC CAN CIR1 | ON | x | x | x | x | x | CCS-151. "ICC SEN- SOR : DTC Logic" |

ICC SENSOR

< ECU DIAGNOSIS INFORMATION >

[FORWARD EMERGENCY BRAKING]

| DTC | CONSULT display | ICC system warning lamp | Fail-safe function | | | | | Reference |
|-------|----------------------|-------------------------|--|--|-------------------------------|---------------------------------|---------------------------------|---|
| | | | Vehicle-to-vehicle distance control mode | Conventional (fixed speed) cruise control mode | Distance Control Assist (DCA) | Forward Collision Warning (FCW) | Forward Emergency Braking (FEB) | |
| U0428 | STRG SEN CAN CIR2 | ON | x | x | x | x | x | CCS-153. "ICC SEN-SOR : DTC Logic" |
| U1000 | CAN COMM CIRCUIT | ON | x | x | x | x | x | CCS-155. "ICC SEN-SOR : DTC Logic" |
| U1010 | CONTROL UNIT (CAN) | ON | x | x | x | x | x | CCS-157. "ICC SEN-SOR : DTC Logic" |
| U150B | ECM CAN CIRC3 | ON | x | x | x | x | x | CCS-158. "DTC Logic" |
| U150C | VDC CAN CIRC3 | ON | x | x | x | x | x | CCS-160. "DTC Logic" |
| U150D | TCM CAN CIRC3 | ON | x | x | x | x | x | CCS-162. "DTC Logic" |
| U150E | BCM CAN CIRC3 | ON | x | x | x | x | x | CCS-164. "DTC Logic" |
| U1513 | METER CAN CIRC# | ON | x | x | x | x | x | CCS-165. "DTC Logic" |
| U1514 | STRG SEN CAN CIRC3 | ON | x | x | x | x | x | CCS-166. "DTC Logic" |
| U1515 | ICC SENSOR CAN CIRC3 | ON | x | x | x | x | x | CCS-167. "DTC Logic" |
| U1517 | APA CAN CIRC3 | ON | x | x | x | x | x | CCS-168. "DTC Logic" |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]


< WIRING DIAGRAM >

WIRING DIAGRAM

DRIVER ASSISTANCE SYSTEMS

Wiring Diagram

INFOID:0000000014224838




AAOWA0150GB

DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >




AAOWA0151GB

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >




AAOWA0152GB

DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >



AAOWA0153GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC


DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >


DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|------------------|
| Connector No. | B30 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS08FW-CS |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------|
| 1Q | - | - |
| 2Q | - | - |
| 3Q | - | - |
| 4Q | - | - |
| 5Q | G | BRAKE PEDAL POSITION SWITCH |
| 6Q | P | BATTERY |
| 7Q | - | - |
| 8Q | - | - |


| | |
|-----------------|--------------|
| Connector No. | B32 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32FW-NH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------|
| 1 | - | TO BODY HARNESS RH |
| 2 | - | TO BODY HARNESS RH |
| 3 | - | TO BODY HARNESS RH |
| 4 | - | TO BODY HARNESS RH |
| 5 | G | TO BODY HARNESS RH |
| 6 | R | TO BODY HARNESS RH |
| 7 | B | TO BODY HARNESS RH |
| 8 | R | TO BODY HARNESS RH |
| 9 | W | TO BODY HARNESS RH |
| 10 | SHIELD | TO BODY HARNESS RH |
| 11 | B | TO BODY HARNESS RH |
| 12 | L | TO BODY HARNESS RH |
| 13 | B | TO BODY HARNESS RH |
| 14 | R | TO BODY HARNESS RH |
| 15 | W | TO BODY HARNESS RH |

| | | |
|----|--------|--------------------|
| 16 | SHIELD | TO BODY HARNESS RH |
| 17 | L | TO BODY HARNESS RH |
| 18 | L | TO BODY HARNESS RH |
| 19 | P | TO BODY HARNESS RH |
| 20 | Y | TO BODY HARNESS RH |
| 21 | L | TO BODY HARNESS RH |
| 22 | B | TO BODY HARNESS RH |
| 23 | W | TO BODY HARNESS RH |
| 24 | SHIELD | TO BODY HARNESS RH |
| 25 | BR | TO BODY HARNESS RH |
| 26 | V | TO BODY HARNESS RH |
| 27 | - | TO BODY HARNESS RH |
| 28 | - | TO BODY HARNESS RH |
| 29 | - | TO BODY HARNESS RH |
| 30 | - | TO BODY HARNESS RH |
| 31 | - | TO BODY HARNESS RH |
| 32 | - | TO BODY HARNESS RH |

| | |
|-----------------|---------------------|
| Connector No. | B63 |
| Connector Name | JOINT CONNECTOR-B01 |
| Connector Type | BJ30FW |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | L | ITS CAN-H |
| 2 | L | ITS CAN-H |
| 3 | L | ITS CAN-H |
| 4 | Y | ITS CAN-L |
| 5 | Y | ITS CAN-L |
| 6 | Y | ITS CAN-L |
| 7 | - | - |
| 8 | SHIELD | GND |
| 9 | B | GND |
| 10 | B | GND |
| 11 | B | GND |
| 12 | LG | ILLUMI CONT OUT |
| 13 | LG | ILLUMI CONT OUT |
| 14 | LG | ILLUMI CONT OUT |
| 15 | - | - |
| 16 | W | ALERT SIGNAL |
| 17 | W | ALERT SIGNAL |
| 18 | - | - |
| 19 | B | GND |
| 20 | B | GND |
| 21 | SHIELD | SHIELD |

| | | |
|----|--------|--------|
| 22 | B | GND |
| 23 | - | - |
| 24 | - | - |
| 25 | SHIELD | SHIELD |
| 26 | B | GND |
| 27 | B | GND |
| 28 | B | GND |
| 29 | W | TAIL |
| 30 | W | TAIL |
| 31 | W | TAIL |
| 32 | W | TAIL |
| 33 | W | TAIL |


DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >


DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|-------------------|
| Connector No. | B69 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MDGY-CS16-TM4 |
| Connector Color | GRAY |



| | | |
|------|--------|-----------------|
| 76A | R | TO MAIN HARNESS |
| 77A | Y | TO MAIN HARNESS |
| 78A | LG | TO MAIN HARNESS |
| 79A | BR | TO MAIN HARNESS |
| 80A | Y | TO MAIN HARNESS |
| 81A | L | TO MAIN HARNESS |
| 82A | BG | TO MAIN HARNESS |
| 83A | Y | TO MAIN HARNESS |
| 84A | LG | TO MAIN HARNESS |
| 85A | SHIELD | TO MAIN HARNESS |
| 86A | LG | TO MAIN HARNESS |
| 87A | SB | TO MAIN HARNESS |
| 88A | BG | TO MAIN HARNESS |
| 89A | L | TO MAIN HARNESS |
| 90A | P | TO MAIN HARNESS |
| 91A | L | TO MAIN HARNESS |
| 92A | LG | TO MAIN HARNESS |
| 93A | B | TO MAIN HARNESS |
| 94A | - | TO MAIN HARNESS |
| 95A | - | TO MAIN HARNESS |
| 96A | - | TO MAIN HARNESS |
| 97A | BR | TO MAIN HARNESS |
| 98A | L | TO MAIN HARNESS |
| 99A | - | TO MAIN HARNESS |
| 100A | - | TO MAIN HARNESS |

| | |
|-----------------|--------------|
| Connector No. | B77 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32MW-NH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------|
| 1 | - | TO BODY NO. 3 HARNESS |
| 2 | - | TO BODY NO. 3 HARNESS |
| 3 | - | TO BODY NO. 3 HARNESS |
| 4 | G | TO BODY NO. 3 HARNESS |
| 5 | W | TO BODY NO. 3 HARNESS |
| 6 | R | TO BODY NO. 3 HARNESS |
| 7 | W | TO BODY NO. 3 HARNESS |
| 8 | B | TO BODY NO. 3 HARNESS |
| 9 | W | TO BODY NO. 3 HARNESS |
| 10 | G | TO BODY NO. 3 HARNESS |
| 11 | - | TO BODY NO. 3 HARNESS |
| 12 | L | TO BODY NO. 3 HARNESS |
| 13 | Y | TO BODY NO. 3 HARNESS |

| | | |
|-----|--------|---|
| 25A | SHIELD | TO MAIN HARNESS |
| 26A | B | TO MAIN HARNESS |
| 27A | B | TO MAIN HARNESS |
| 28A | SHIELD | TO MAIN HARNESS |
| 29A | R | TO MAIN HARNESS |
| 30A | B | TO MAIN HARNESS |
| 31A | BR | TO MAIN HARNESS |
| 32A | - | TO MAIN HARNESS |
| 33A | W | TO MAIN HARNESS |
| 34A | SHIELD | TO MAIN HARNESS |
| 35A | B | TO MAIN HARNESS |
| 36A | - | TO MAIN HARNESS |
| 37A | LG | TO MAIN HARNESS |
| 38A | V | TO MAIN HARNESS |
| 39A | SB | TO MAIN HARNESS |
| 40A | BR | TO MAIN HARNESS |
| 41A | Y | TO MAIN HARNESS |
| 42A | - | TO MAIN HARNESS |
| 43A | - | TO MAIN HARNESS |
| 44A | V | TO MAIN HARNESS |
| 45A | G | TO MAIN HARNESS |
| 46A | V | TO MAIN HARNESS |
| 47A | L | TO MAIN HARNESS |
| 48A | SB | TO MAIN HARNESS |
| 49A | G | TO MAIN HARNESS |
| 50A | W | TO MAIN HARNESS |
| 51A | - | TO MAIN HARNESS |
| 52A | R | TO MAIN HARNESS |
| 53A | SB | TO MAIN HARNESS |
| 54A | LG | TO MAIN HARNESS |
| 55A | LG | TO MAIN HARNESS |
| 56A | Y | TO MAIN HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 57A | V | TO MAIN HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 58A | BR | TO MAIN HARNESS |
| 59A | BR | TO MAIN HARNESS |
| 60A | L | TO MAIN HARNESS |
| 61A | Y | TO MAIN HARNESS |
| 62A | - | TO MAIN HARNESS |
| 63A | P | TO MAIN HARNESS |
| 64A | R | TO MAIN HARNESS |
| 65A | SB | TO MAIN HARNESS |
| 66A | L | TO MAIN HARNESS |
| 67A | LG | TO MAIN HARNESS |
| 68A | P | TO MAIN HARNESS |
| 69A | W | TO MAIN HARNESS |
| 70A | G | TO MAIN HARNESS |
| 71A | BR | TO MAIN HARNESS |
| 72A | - | TO MAIN HARNESS |
| 73A | Y | TO MAIN HARNESS |
| 74A | P | TO MAIN HARNESS |
| 75A | V | TO MAIN HARNESS |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 1A | - | TO MAIN HARNESS |
| 2A | Y | TO MAIN HARNESS |
| 3A | Y | TO MAIN HARNESS |
| 4A | G | TO MAIN HARNESS |
| 5A | - | TO MAIN HARNESS |
| 6A | LG | TO MAIN HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 6A | R | TO MAIN HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 7A | BR | TO MAIN HARNESS |
| 8A | G | TO MAIN HARNESS |
| 9A | P | TO MAIN HARNESS |
| 10A | - | TO MAIN HARNESS |
| 11A | W | TO MAIN HARNESS |
| 12A | G | TO MAIN HARNESS |
| 13A | - | TO MAIN HARNESS |
| 14A | R | TO MAIN HARNESS |
| 15A | G | TO MAIN HARNESS |
| 16A | W | TO MAIN HARNESS |
| 17A | B | TO MAIN HARNESS |
| 18A | B | TO MAIN HARNESS |
| 19A | SHIELD | TO MAIN HARNESS |
| 20A | W | TO MAIN HARNESS |
| 21A | SHIELD | TO MAIN HARNESS |
| 22A | - | TO MAIN HARNESS |
| 23A | W | TO MAIN HARNESS |
| 24A | B | TO MAIN HARNESS |

AAOIA04763B

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC



DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >



DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | B101 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32MW-NH |
| Connector Color | WHITE |

| | | |
|----|----|-----------------|
| 28 | Y | TO MAIN HARNESS |
| 29 | SB | TO MAIN HARNESS |
| 30 | LG | TO MAIN HARNESS |
| 31 | G | TO MAIN HARNESS |
| 32 | - | TO MAIN HARNESS |

| | |
|-----------------|---------------------|
| Connector No. | B102 |
| Connector Name | JOINT CONNECTOR-B14 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 1 | B | TO MAIN HARNESS |
| 2 | W | TO MAIN HARNESS |
| 3 | SHIELD | TO MAIN HARNESS |
| 4 | R | TO MAIN HARNESS |
| 5 | V | TO MAIN HARNESS - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 5 | Y | TO MAIN HARNESS - (WITH REAR ENTERTAINMENT SYSTEM) |
| 6 | W | TO MAIN HARNESS - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 6 | B | TO MAIN HARNESS - (WITH REAR ENTERTAINMENT SYSTEM) |
| 7 | R | TO MAIN HARNESS - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 7 | W | TO MAIN HARNESS - (WITH REAR ENTERTAINMENT SYSTEM) |
| 8 | B | TO MAIN HARNESS - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 8 | R | TO MAIN HARNESS - (WITH REAR ENTERTAINMENT SYSTEM) |
| 9 | SHIELD | TO MAIN HARNESS |
| 10 | G | TO MAIN HARNESS |
| 11 | SB | TO MAIN HARNESS |
| 12 | P | TO MAIN HARNESS |
| 13 | W | TO MAIN HARNESS |
| 14 | - | TO MAIN HARNESS |
| 15 | - | TO MAIN HARNESS |
| 16 | - | TO MAIN HARNESS |
| 17 | L | TO MAIN HARNESS |
| 18 | P | TO MAIN HARNESS |
| 19 | LG | TO MAIN HARNESS |
| 20 | BR | TO MAIN HARNESS |
| 21 | LG | TO MAIN HARNESS |
| 22 | LG | TO MAIN HARNESS |
| 23 | W | TO MAIN HARNESS |
| 24 | V | TO MAIN HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 24 | BR | TO MAIN HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 25 | SB | TO MAIN HARNESS |
| 26 | LG | TO MAIN HARNESS |
| 27 | Y | TO MAIN HARNESS |

AAOIA0477GB

| | |
|-----------------|-------------------|
| Connector No. | B104 |
| Connector Name | ADAS CONTROL UNIT |
| Connector Type | TH24FW-NH |
| Connector Color | WHITE |




| | |
|-----------------|---------------|
| Connector No. | B109 |
| Connector Name | SIDE RADAR RH |
| Connector Type | AAC08FB-WP |
| Connector Color | BLACK |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------|
| 1 | B | CAN-H |
| 2 | W | CAN-L |
| 3 | - | - |
| 4 | - | - |
| 5 | B | GND |
| 6 | L | ITS CAN-H |
| 7 | Y | ITS CAN-L |
| 8 | L | IC CAN-H |
| 9 | Y | IC CAN-L |
| 10 | - | - |
| 11 | - | - |
| 12 | R | IGN |
| 13 | - | - |
| 14 | - | - |
| 15 | - | - |
| 16 | - | - |
| 17 | G | BRK-FLY |
| 18 | BR | ITS ALERT SW |
| 19 | W | ITS ALERT SW LED |
| 20 | - | - |
| 21 | - | - |
| 22 | - | - |
| 23 | - | - |
| 24 | - | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 1 | B | ADDRESS |
| 2 | B | GND |
| 3 | Y | ITS CAN-L |
| 4 | L | ITS CAN-H |
| 5 | R | POWER (IGN) |
| 6 | W | ALERT SIGNAL |

| | |
|-----------------|---------------------|
| Connector No. | B103 |
| Connector Name | JOINT CONNECTOR-B15 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 2 | L | CAN-H |
| 3 | B | CAN-H |
| 4 | - | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | CAN-L |
| 2 | P | CAN-L |
| 3 | W | CAN-L |
| 4 | - | - |

DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >

DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|---------------------|
| Connector No. | B115 |
| Connector Name | JOINT CONNECTOR-B08 |
| Connector Type | BJ30FW |
| Connector Color | WHITE |

| | |
|-----------------|--------------|
| Connector No. | B124 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32MW-NH |
| Connector Color | WHITE |

| | |
|-----------------|--------------|
| Connector No. | B136 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40MW-NH |
| Connector Color | WHITE |

| | | |
|----|----|-----------------|
| 35 | - | TO MAIN HARNESS |
| 36 | - | TO MAIN HARNESS |
| 37 | BR | TO MAIN HARNESS |
| 38 | - | TO MAIN HARNESS |
| 39 | - | TO MAIN HARNESS |
| 40 | - | TO MAIN HARNESS |

| | |
|-----------------|---------------------|
| Connector No. | B146 |
| Connector Name | JOINT CONNECTOR-B12 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------------|
| 1 | - | - |
| 2 | - | - |
| 3 | - | - |
| 4 | - | - |
| 5 | - | - |
| 6 | - | - |
| 7 | - | - |
| 8 | B | GND |
| 9 | B | GND |
| 10 | GR | GND |
| 11 | SHIELD | SHIELD |
| 12 | - | - |
| 13 | - | - |
| 14 | - | - |
| 15 | - | - |
| 16 | - | - |
| 17 | - | - |
| 18 | - | - |
| 19 | R | IGNITION |
| 20 | R | IGNITION |
| 21 | R | IGNITION |
| 22 | - | - |
| 23 | - | - |
| 24 | - | - |
| 25 | - | - |
| 26 | - | - |
| 27 | W | ALERT SIGNAL |
| 28 | W | ALERT SIGNAL ADDRESS |
| 29 | B | GND |
| 30 | B | GND |
| 31 | GR | GND |
| 32 | SHIELD | SHIELD |
| 33 | B | GND |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | - | TO BODY HARNESS |
| 2 | - | TO BODY HARNESS |
| 3 | - | TO BODY HARNESS |
| 4 | - | TO BODY HARNESS |
| 5 | G | TO BODY HARNESS |
| 6 | R | TO BODY HARNESS |
| 7 | G | TO BODY HARNESS |
| 8 | R | TO BODY HARNESS |
| 9 | W | TO BODY HARNESS |
| 10 | SHIELD | TO BODY HARNESS |
| 11 | B | TO BODY HARNESS |
| 12 | L | TO BODY HARNESS |
| 13 | G | TO BODY HARNESS |
| 14 | R | TO BODY HARNESS |
| 15 | W | TO BODY HARNESS |
| 16 | SHIELD | TO BODY HARNESS |
| 17 | Y | TO BODY HARNESS |
| 18 | L | TO BODY HARNESS |
| 19 | P | TO BODY HARNESS |
| 20 | Y | TO BODY HARNESS |
| 21 | L | TO BODY HARNESS |
| 22 | B | TO BODY HARNESS |
| 23 | W | TO BODY HARNESS |
| 24 | SHIELD | TO BODY HARNESS |
| 25 | BR | TO BODY HARNESS |
| 26 | V | TO BODY HARNESS |
| 27 | - | TO BODY HARNESS |
| 28 | - | TO BODY HARNESS |
| 29 | - | TO BODY HARNESS |
| 30 | - | TO BODY HARNESS |
| 31 | - | TO BODY HARNESS |
| 32 | - | TO BODY HARNESS |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 1 | G | TO MAIN HARNESS |
| 2 | W | TO MAIN HARNESS |
| 3 | BR | TO MAIN HARNESS |
| 4 | G | TO MAIN HARNESS |
| 5 | BG | TO MAIN HARNESS |
| 6 | B | TO MAIN HARNESS |
| 7 | W | TO MAIN HARNESS |
| 8 | W | TO MAIN HARNESS |
| 9 | B | TO MAIN HARNESS |
| 10 | W | TO MAIN HARNESS |
| 11 | SHIELD | TO MAIN HARNESS |
| 12 | B | TO MAIN HARNESS |
| 13 | W | TO MAIN HARNESS |
| 14 | SHIELD | TO MAIN HARNESS |
| 15 | B | TO MAIN HARNESS |
| 16 | W | TO MAIN HARNESS |
| 17 | SHIELD | TO MAIN HARNESS |
| 18 | W | TO MAIN HARNESS |
| 19 | LG | TO MAIN HARNESS - (WITHOUT SURROUND SOUND SYSTEM) |
| 19 | B | TO MAIN HARNESS - (WITH SURROUND SOUND SYSTEM) |
| 20 | SB | TO MAIN HARNESS - (WITHOUT SURROUND SOUND SYSTEM) |
| 20 | W | TO MAIN HARNESS - (WITH SURROUND SOUND SYSTEM) |
| 21 | B | TO MAIN HARNESS |
| 22 | W | TO MAIN HARNESS |
| 23 | SHIELD | TO MAIN HARNESS |
| 24 | B | TO MAIN HARNESS |
| 25 | W | TO MAIN HARNESS |
| 26 | SHIELD | TO MAIN HARNESS |
| 27 | B | TO MAIN HARNESS |
| 28 | W | TO MAIN HARNESS |
| 29 | SHIELD | TO MAIN HARNESS |
| 30 | B | TO MAIN HARNESS |
| 31 | W | TO MAIN HARNESS |
| 32 | L | TO MAIN HARNESS |
| 33 | Y | TO MAIN HARNESS |
| 34 | - | TO MAIN HARNESS |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | ITS CAN-H |
| 2 | L | ITS CAN-H |
| 3 | L | ITS CAN-H |
| 4 | - | - |

| | |
|-----------------|---------------------|
| Connector No. | B147 |
| Connector Name | JOINT CONNECTOR-B13 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | ITS CAN-L |
| 2 | Y | ITS CAN-L |
| 3 | Y | ITS CAN-L |
| 4 | - | - |

AAOIA0478GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC



DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]



< WIRING DIAGRAM >

DRIVER ASSISTANCE SYSTEM CONNECTORS



| | |
|-----------------|--------------|
| Connector No. | B400 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32FV-NH |
| Connector Color | WHITE |



| | |
|-----------------|---------------|
| Connector No. | B416 |
| Connector Name | SIDE RADAR LH |
| Connector Type | AA06FB-WP-5P |
| Connector Color | BLACK |

| | |
|-----------------|-----------------------|
| Connector No. | D21 |
| Connector Name | BLIND SPOT WARNING LH |
| Connector Type | TH04MW-NH |
| Connector Color | WHITE |



| | |
|-----------------|-----------------------|
| Connector No. | D111 |
| Connector Name | BLIND SPOT WARNING RH |
| Connector Type | TH04MW-NH |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | - | TO BODY HARNESS |
| 2 | - | TO BODY HARNESS |
| 3 | - | TO BODY HARNESS |
| 4 | G | TO BODY HARNESS |
| 5 | W | TO BODY HARNESS |
| 6 | R | TO BODY HARNESS |
| 7 | W | TO BODY HARNESS |
| 8 | B | TO BODY HARNESS |
| 9 | W | TO BODY HARNESS |
| 10 | G | TO BODY HARNESS |
| 11 | - | TO BODY HARNESS |
| 12 | L | TO BODY HARNESS |
| 13 | Y | TO BODY HARNESS |
| 14 | - | TO BODY HARNESS |
| 15 | G | TO BODY HARNESS |
| 16 | B | TO BODY HARNESS |
| 17 | B | TO BODY HARNESS |
| 18 | B | TO BODY HARNESS |
| 19 | SHIELD | TO BODY HARNESS |
| 20 | R | TO BODY HARNESS |
| 21 | B | TO BODY HARNESS |
| 22 | W | TO BODY HARNESS |
| 23 | SHIELD | TO BODY HARNESS |
| 24 | W | TO BODY HARNESS |
| 25 | B | TO BODY HARNESS |
| 26 | SHIELD | TO BODY HARNESS |
| 27 | B | TO BODY HARNESS |
| 28 | B | TO BODY HARNESS |
| 29 | SHIELD | TO BODY HARNESS |
| 30 | LG | TO BODY HARNESS |
| 31 | W | TO BODY HARNESS |
| 32 | - | TO BODY HARNESS |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------|
| 1 | - | - |
| 2 | B | GND |
| 3 | Y | ITS CAN-L |
| 4 | L | ITS CAN-H |
| 5 | R | POWER (GN) |
| 6 | W | ALERT SIGNAL |

| | |
|-----------------|--------------|
| Connector No. | D2 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FW-CS |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | W | SIGNAL |
| 2 | - | - |
| 3 | - | - |
| 4 | B | GND |

| | |
|-----------------|--------------|
| Connector No. | D102 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS10FW-CS |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | W | TO MAIN HARNESS |
| 2 | B | TO MAIN HARNESS |
| 3 | SHIELD | TO MAIN HARNESS |
| 4 | L | TO MAIN HARNESS |
| 5 | BR | TO MAIN HARNESS |
| 6 | Y | TO MAIN HARNESS |
| 7 | LG | TO MAIN HARNESS |
| 8 | B | TO MAIN HARNESS |
| 9 | G | TO MAIN HARNESS |
| 10 | W | TO MAIN HARNESS |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | B | TO MAIN HARNESS |
| 2 | Y | TO MAIN HARNESS |
| 3 | G/B | TO MAIN HARNESS |
| 4 | BR | TO MAIN HARNESS |
| 5 | SB | TO MAIN HARNESS |
| 6 | LG | TO MAIN HARNESS |
| 7 | Y | TO MAIN HARNESS |
| 8 | W | TO MAIN HARNESS |
| 9 | G | TO MAIN HARNESS |
| 10 | V | TO MAIN HARNESS |
| 11 | BR | TO MAIN HARNESS |
| 12 | LG | TO MAIN HARNESS |
| 13 | L | TO MAIN HARNESS |
| 14 | SHIELD | TO MAIN HARNESS |
| 15 | B | TO MAIN HARNESS |
| 16 | W | TO MAIN HARNESS |

AAOIA0479GB

DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >


DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | E5 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16MW-CS |
| Connector Color | WHITE |



| | | | | | | | | |
|---|---|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | | |
| 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |

| | |
|-----------------|------------------|
| Connector No. | E16 |
| Connector Name | ECM (FOR MEXICO) |
| Connector Type | RH24FGY-RZ8-R-RH |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------|
| 1 | Y | TO FRONT END MODULE HARNESS |
| 2 | SB | TO FRONT END MODULE HARNESS |
| 3 | BR | TO FRONT END MODULE HARNESS |
| 4 | B | TO FRONT END MODULE HARNESS |
| 5 | B | TO FRONT END MODULE HARNESS |
| 6 | P | TO FRONT END MODULE HARNESS |
| 7 | W/G | TO FRONT END MODULE HARNESS |
| 8 | G | TO FRONT END MODULE HARNESS |
| 9 | L | TO FRONT END MODULE HARNESS |
| 10 | G | TO FRONT END MODULE HARNESS |
| 11 | R | TO FRONT END MODULE HARNESS |
| 12 | P | TO FRONT END MODULE HARNESS |
| 13 | SHIELD | TO FRONT END MODULE HARNESS |
| 14 | SHIELD | TO FRONT END MODULE HARNESS |
| 15 | P | TO FRONT END MODULE HARNESS |
| 16 | B | TO FRONT END MODULE HARNESS |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 97 | W | ACCELERATOR PEDAL POSITION SENSOR 1 (WITHOUT ICC SYSTEM) |
| 97 | R | ACCELERATOR PEDAL POSITION SENSOR 1 (WITH ICC SYSTEM) |
| 98 | P | ACCELERATOR PEDAL POSITION SENSOR 2 (WITHOUT ICC SYSTEM) |
| 98 | B | ACCELERATOR PEDAL POSITION SENSOR 2 (WITH ICC SYSTEM) |
| 99 | R | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 1) (WITHOUT ICC SYSTEM) |
| 99 | G | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 1) (WITH ICC SYSTEM) |
| 100 | R | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 1) (WITHOUT ICC SYSTEM) |
| 100 | W | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 1) (WITH ICC SYSTEM) |
| 101 | G | ASC/D STEERING SWITCH/ICC STEERING SWITCH |
| 102 | O | EVAP CONTROL SYSTEM PRESSURE SENSOR |
| 103 | W | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 2) (WITHOUT ICC SYSTEM) |
| 103 | Y | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 2) (WITH ICC SYSTEM) |
| 104 | P | DATA LINK CONNECTOR |
| 105 | - | - |
| 106 | Y | EVAP CANISTER VENT CONTROL VALVE |
| 107 | W | SENSOR POWER SUPPLY (EVAP CONTROL SYSTEM PRESSURE SENSOR, ENGINE OIL PRESSURE SENSOR) |
| 108 | R | SENSOR GROUND (ASC/D STEERING SWITCH) |
| 109 | SB | IGNITION SWITCH |
| 110 | - | - |

| | | |
|----|--------|-----------------------------|
| 8 | SHIELD | TO FRONT END MODULE HARNESS |
| 9 | Y | TO FRONT END MODULE HARNESS |
| 10 | BG | TO FRONT END MODULE HARNESS |
| 11 | G | TO FRONT END MODULE HARNESS |
| 12 | W | TO FRONT END MODULE HARNESS |
| 13 | R | TO FRONT END MODULE HARNESS |
| 14 | B | TO FRONT END MODULE HARNESS |
| 15 | G | TO FRONT END MODULE HARNESS |
| 16 | SHIELD | TO FRONT END MODULE HARNESS |
| 17 | W | TO FRONT END MODULE HARNESS |
| 18 | P | TO FRONT END MODULE HARNESS |
| 19 | W | TO FRONT END MODULE HARNESS |
| 20 | R | TO FRONT END MODULE HARNESS |
| 21 | W | TO FRONT END MODULE HARNESS |
| 22 | BR | TO FRONT END MODULE HARNESS |
| 23 | V | TO FRONT END MODULE HARNESS |
| 24 | SB | TO FRONT END MODULE HARNESS |

| | | |
|-----|----|--|
| 111 | BR | FUEL TANK TEMPERATURE SENSOR |
| 112 | G | SENSOR GROUND (MAP CONTROL SYSTEM PRESSURE SENSOR, ENGINE OIL PRESSURE SENSOR) |
| 113 | P | CAN-L |
| 114 | L | CAN-H |
| 115 | - | - |
| 116 | G | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 2) (WITHOUT ICC SYSTEM) |
| 116 | L | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 2) (WITH ICC SYSTEM) |
| 117 | - | - |
| 118 | W | PNP SIGNAL |
| 119 | - | - |
| 120 | LG | SENSOR GROUND (FUEL TANK TEMPERATURE SENSOR) |
| 121 | LG | POWER SUPPLY FOR ECM |
| 122 | R | STOP LAMP SWITCH |
| 123 | B | ECM GND |
| 124 | B | ECM GND |
| 125 | - | - |
| 126 | LG | BBRAKE PEDAL POSITION SWITCH |
| 127 | B | ECM GND |
| 128 | B | ECM GND |

| | |
|-----------------|--------------|
| Connector No. | E26 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24MW-NH |
| Connector Color | WHITE |



| | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 |
| 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------|
| 1 | R | TO FRONT END MODULE HARNESS |
| 2 | W | TO FRONT END MODULE HARNESS |
| 3 | B | TO FRONT END MODULE HARNESS |
| 4 | SHIELD | TO FRONT END MODULE HARNESS |
| 5 | B | TO FRONT END MODULE HARNESS |
| 6 | R | TO FRONT END MODULE HARNESS |
| 7 | W | TO FRONT END MODULE HARNESS |

AAOIA0480GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC


DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >


DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|------------------|
| Connector No. | E28 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS10FW-CS |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------|
| 1M | R | IGNITION |
| 2M | - | - |
| 3M | - | - |
| 4M | - | - |
| 5M | Y | BATTERY |
| 6M | L | TAIL LH |
| 7M | P | BRAKE PEDAL POSITION SWITCH |
| 8M | R | BRAKE PEDAL POSITION SWITCH |
| 9M | - | - |
| 10M | - | - |


| | |
|-----------------|-------------------------|
| Connector No. | E32 |
| Connector Name | ECM (EXCEPT FOR MEXICO) |
| Connector Type | RH24FB-RZ8-L-LH |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 121 | W | EVAP CONTROL SYSTEM PRESSURE SENSOR |
| 122 | - | - |
| 123 | P | CAN-L |
| 124 | L | CAN-H |
| 125 | R | POWER SUPPLY (EVAP CONTROL SYSTEM PRESSURE SENSOR) |
| 126 | - | - |
| 127 | - | - |
| 128 | BR | FUEL TANK TEMPERATURE SENSOR |
| 129 | - | - |
| 130 | - | - |


| | | | |
|-----|----|---|--|
| 131 | - | - | - |
| 132 | - | - | POWER SUPPLY |
| 133 | SB | - | ASD STEERING SWITCH/ICC STEERING SWITCH |
| 134 | G | - | SENSOR GROUND |
| 135 | R | - | - |
| 136 | - | - | - |
| 137 | - | - | - |
| 138 | - | - | STOP LAMP SWITCH |
| 139 | R | - | - |
| 140 | LG | - | BRAKE PEDAL POSITION SWITCH |
| 141 | Y | - | EVAP CANISTER VENT CONTROL VALVE |
| 142 | Y | - | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 2) (WITH ICC SYSTEM) |
| 142 | W | - | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 2) (WITHOUT ICC SYSTEM) |
| 143 | B | - | ACCELE PEDAL POSITION SENSOR 2 (WITH ICC SYSTEM) |
| 143 | P | - | ACCELE PEDAL POSITION SENSOR 2 (WITHOUT ICC SYSTEM) |
| 144 | L | - | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 2) (WITH ICC SYSTEM) |
| 144 | G | - | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 2) (WITHOUT ICC SYSTEM) |
| 145 | LG | - | POWER SUPPLY FOR ECM |
| 146 | G | - | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 1) (WITH ICC SYSTEM) |
| 146 | R | - | SENSOR POWER SUPPLY (ACCELERATOR PEDAL POSITION SENSOR 1) (WITHOUT ICC SYSTEM) |
| 147 | B | - | SENSOR GROUND |
| 148 | LG | - | SENSOR GROUND |
| 149 | B | - | ACCELE PEDAL POSITION SENSOR 1 (WITH ICC SYSTEM) |
| 150 | R | - | ACCELE PEDAL POSITION SENSOR 1 (WITHOUT ICC SYSTEM) |
| 150 | W | - | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 1) (WITH ICC SYSTEM) |
| 151 | W | - | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 1) (WITHOUT ICC SYSTEM) |
| 151 | R | - | SENSOR GROUND (ACCELERATOR PEDAL POSITION SENSOR 1) (WITH ICC SYSTEM) |
| 152 | B | - | SENSOR GROUND |

| | |
|-----------------|------------------|
| Connector No. | E38 |
| Connector Name | STOP LAMP SWITCH |
| Connector Type | M04FW-LC |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------|
| 1 | Y | BATT |
| 2 | P | BRAKE PEDAL POSITION SWITCH |
| 3 | Y | BATT |
| 4 | G | STP |


| | |
|-----------------|---------------------|
| Connector No. | E44 |
| Connector Name | JOINT CONNECTOR-E01 |
| Connector Type | BJ30FW |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------|
| 1 | W | SENSOR POWER SUPPLY |
| 2 | W | SENSOR POWER SUPPLY |
| 3 | W | SENSOR POWER SUPPLY |
| 4 | R | BATTERY |
| 5 | R | BATTERY |
| 6 | R | BATTERY |
| 7 | - | - |
| 8 | LG | BATTERY |
| 9 | LG | BATTERY |
| 10 | LG | BATTERY |
| 11 | LG | BATTERY |
| 12 | P | BATTERY |
| 13 | P | BATTERY |
| 14 | P | BATTERY |
| 15 | GR | GND |
| 16 | B | GND |
| 17 | B | GND |
| 18 | - | - |
| 19 | Y | BATTERY |

| | | |
|----|----|-------------------------------------|
| 20 | Y | BATTERY |
| 21 | Y | BATTERY |
| 22 | Y | BATTERY |
| 23 | BG | EVAP CONTROL SYSTEM PRESSURE SENSOR |
| 24 | O | EVAP CONTROL SYSTEM PRESSURE SENSOR |
| 25 | - | - |
| 26 | G | GND |
| 27 | G | GND |
| 28 | G | GND |
| 29 | - | - |
| 30 | V | BATTERY |
| 31 | LG | BATTERY |
| 32 | V | BATTERY |
| 33 | V | BATTERY |

| | |
|-----------------|---------------------|
| Connector No. | E45 |
| Connector Name | JOINT CONNECTOR-E12 |
| Connector Type | A12FL |
| Connector Color | BLUE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 2 | L | CAN-H |
| 3 | L | CAN-H |
| 4 | L | CAN-H |
| 5 | - | - |
| 6 | - | - |
| 7 | P | CAN-L |
| 8 | P | CAN-L |
| 9 | P | CAN-L |
| 10 | P | CAN-L |
| 11 | - | - |
| 12 | - | - |


DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >

DRIVER ASSISTANCE SYSTEM CONNECTORS


| | |
|-----------------|---------------------|
| Connector No. | E70 |
| Connector Name | JOINT CONNECTOR-E14 |
| Connector Type | RH06FB |
| Connector Color | BLACK |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | CAN-L |
| 2 | P | CAN-L |
| 3 | P | CAN-L |
| 4 | P | CAN-L |
| 5 | - | - |
| 6 | - | - |


| | |
|-----------------|---------------------|
| Connector No. | E71 |
| Connector Name | JOINT CONNECTOR-E15 |
| Connector Type | RH06FB |
| Connector Color | BLACK |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 2 | L | CAN-H |
| 3 | L | CAN-H |
| 4 | L | CAN-H |
| 5 | - | - |
| 6 | - | - |


| | |
|-----------------|---|
| Connector No. | E72 |
| Connector Name | BRAKE PEDAL POSITION SWITCH (WITH INTELLIGENT CRUISE CONTROL) |
| Connector Type | M02FBR-LC |
| Connector Color | BROWN |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------|
| 1 | R | IGN |
| 2 | LG | BRAKE PEDAL POSITION SWITCH |


| | |
|-----------------|--|
| Connector No. | E74 |
| Connector Name | ACCELERATOR PEDAL ACTUATOR (WITH INTELLIGENT CRUISE CONTROL) |
| Connector Type | RH12FB |
| Connector Color | BLACK |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | BG | +VB |
| 2 | R | IGN SW |
| 3 | BG | CAN-H |
| 4 | L/G | AFS1 VDD |
| 5 | W | AFS1 GND |
| 6 | W/L | AFS1 OUT |
| 7 | GR | GND |
| 8 | - | - |
| 9 | Y | CAN-L |
| 10 | L/Y | AFS2 VDD |
| 11 | O | AFS2 GND |
| 12 | O/L | AFS2 OUT |


| | |
|-----------------|----------------------|
| Connector No. | E75 |
| Connector Name | ICC BRAKE HOLD RELAY |
| Connector Type | MS02FL-IM2-LC |
| Connector Color | BLUE |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------|
| 1 | W | BRAKE HOLD RLY DRIVE SIGNAL |
| 2 | R | IGN |
| 3 | P | BRAKE PEDAL POSITION SWITCH |
| 5 | Y | BATT |


| | |
|-----------------|---------------------|
| Connector No. | E106 |
| Connector Name | JOINT CONNECTOR-E06 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | BG | CAN-H |
| 2 | BG | CAN-H |
| 3 | BG | CAN-H |
| 4 | - | - |

| | |
|-----------------|---------------------|
| Connector No. | E108 |
| Connector Name | JOINT CONNECTOR-E07 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | CAN-L |
| 2 | Y | CAN-L |
| 3 | Y | CAN-L |
| 4 | - | - |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]


< WIRING DIAGRAM >

DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|---|
| Connector No. | E125 |
| Connector Name | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) |
| Connector Type | SAZ34FB-HS2-SJS22-UH |
| Connector Color | BLACK |



| | |
|-----------------|-----------------|
| Connector No. | E152 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS16-TM4 |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 1 | R | SOLENOID (POWER) |
| 2 | B | ECU (GND) |
| 3 | W | MOTOR (POWER) |
| 4 | B/W | MOTOR (GND) |
| 5 | - | - |
| 6 | - | - |
| 7 | P | STOP LAMP SW (WITHOUT CC) |
| 7 | G | STOP LAMP SW (WITH INTELLIGENT CRUISE CONTROL) |
| 8 | - | - |
| 9 | R | VDC-OFF SW |
| 10 | - | - |
| 11 | G | FR RH SEN (POWER) |
| 12 | W | FR RH SEN (SIGNAL) |
| 13 | R | FR LH SEN (POWER) |
| 14 | G | FR LH SEN (SIGNAL) |
| 15 | - | - |
| 16 | - | - |
| 17 | - | - |
| 18 | - | - |
| 19 | L | CAN-H |
| 20 | SHIELD | VAC SEN (GND) |
| 21 | B | VAC SEN (POWER) |
| 22 | W | WAC SEN (SIGNAL) |
| 23 | G | FR LH SEN (POWER) |
| 24 | W | FR LH SEN (SIGNAL) |
| 25 | BG | RR RH SEN (POWER) |
| 26 | P | RR RH SEN (SIGNAL) |
| 27 | - | - |
| 28 | BR | IGN (POWER) |
| 29 | - | - |
| 30 | P | CAN-L |
| 31 | - | - |
| 32 | - | - |
| 33 | - | - |
| 34 | - | - |
| 35 | - | - |

AAOIA0483GB

| | | |
|------|--------|-----------------|
| 76G | Y | TO MAIN HARNESS |
| 77G | BR | TO MAIN HARNESS |
| 78G | - | TO MAIN HARNESS |
| 79G | P | TO MAIN HARNESS |
| 80G | G | TO MAIN HARNESS |
| 81G | R | TO MAIN HARNESS |
| 82G | - | TO MAIN HARNESS |
| 83G | - | TO MAIN HARNESS |
| 84G | - | TO MAIN HARNESS |
| 85G | - | TO MAIN HARNESS |
| 86G | - | TO MAIN HARNESS |
| 87G | - | TO MAIN HARNESS |
| 88G | - | TO MAIN HARNESS |
| 89G | R | TO MAIN HARNESS |
| 90G | L | TO MAIN HARNESS |
| 91G | L | TO MAIN HARNESS |
| 92G | - | TO MAIN HARNESS |
| 93G | - | TO MAIN HARNESS |
| 94G | Y | TO MAIN HARNESS |
| 95G | W | TO MAIN HARNESS |
| 96G | - | TO MAIN HARNESS |
| 97G | - | TO MAIN HARNESS |
| 98G | - | TO MAIN HARNESS |
| 99G | - | TO MAIN HARNESS |
| 100G | SHIELD | TO MAIN HARNESS |

| | | |
|-----|--------|-----------------|
| 23G | SHIELD | TO MAIN HARNESS |
| 24G | R | TO MAIN HARNESS |
| 25G | W | TO MAIN HARNESS |
| 26G | SHIELD | TO MAIN HARNESS |
| 27G | W | TO MAIN HARNESS |
| 28G | R | TO MAIN HARNESS |
| 29G | B | TO MAIN HARNESS |
| 30G | G | TO MAIN HARNESS |
| 31G | L | TO MAIN HARNESS |
| 32G | LG | TO MAIN HARNESS |
| 33G | LG | TO MAIN HARNESS |
| 34G | W | TO MAIN HARNESS |
| 35G | P | TO MAIN HARNESS |
| 36G | L | TO MAIN HARNESS |
| 37G | BG | TO MAIN HARNESS |
| 38G | W | TO MAIN HARNESS |
| 39G | W | TO MAIN HARNESS |
| 40G | Y | TO MAIN HARNESS |
| 41G | BG | TO MAIN HARNESS |
| 42G | P | TO MAIN HARNESS |
| 43G | R | TO MAIN HARNESS |
| 44G | W | TO MAIN HARNESS |
| 45G | Y | TO MAIN HARNESS |
| 46G | SB | TO MAIN HARNESS |
| 47G | V | TO MAIN HARNESS |
| 48G | BR | TO MAIN HARNESS |
| 49G | W | TO MAIN HARNESS |
| 50G | G | TO MAIN HARNESS |
| 51G | B/W | TO MAIN HARNESS |
| 52G | BR | TO MAIN HARNESS |
| 53G | L | TO MAIN HARNESS |
| 54G | P | TO MAIN HARNESS |
| 55G | BR | TO MAIN HARNESS |
| 56G | R | TO MAIN HARNESS |
| 57G | P | TO MAIN HARNESS |
| 58G | BG | TO MAIN HARNESS |
| 59G | W | TO MAIN HARNESS |
| 60G | B | TO MAIN HARNESS |
| 61G | SHIELD | TO MAIN HARNESS |
| 62G | P | TO MAIN HARNESS |
| 63G | L | TO MAIN HARNESS |
| 64G | R | TO MAIN HARNESS |
| 65G | G/R | TO MAIN HARNESS |
| 66G | R | TO MAIN HARNESS |
| 67G | BG | TO MAIN HARNESS |
| 68G | LG/R | TO MAIN HARNESS |
| 69G | W | TO MAIN HARNESS |
| 70G | G | TO MAIN HARNESS |
| 71G | GR | TO MAIN HARNESS |
| 72G | - | TO MAIN HARNESS |
| 73G | - | TO MAIN HARNESS |
| 74G | - | TO MAIN HARNESS |
| 75G | G | TO MAIN HARNESS |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1G | G | TO MAIN HARNESS |
| 2G | W | TO MAIN HARNESS |
| 3G | P | TO MAIN HARNESS |
| 4G | R | TO MAIN HARNESS |
| 5G | P | TO MAIN HARNESS |
| 6G | W | TO MAIN HARNESS |
| 7G | SHIELD | TO MAIN HARNESS |
| 8G | G | TO MAIN HARNESS |
| 9G | LG | TO MAIN HARNESS |
| 10G | P | TO MAIN HARNESS |
| 11G | G | TO MAIN HARNESS |
| 12G | P | TO MAIN HARNESS |
| 13G | W | TO MAIN HARNESS |
| 14G | BG | TO MAIN HARNESS |
| 15G | W | TO MAIN HARNESS |
| 16G | R | TO MAIN HARNESS |
| 17G | B | TO MAIN HARNESS |
| 18G | SHIELD | TO MAIN HARNESS |
| 19G | W | TO MAIN HARNESS |
| 20G | G | TO MAIN HARNESS |
| 21G | P | TO MAIN HARNESS |
| 22G | B | TO MAIN HARNESS |



DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >



DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | E207 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FW-CS |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------------|
| 1 | P | TO ENGINE ROOM HARNESS |
| 2 | P | TO ENGINE ROOM HARNESS |
| 3 | R | TO ENGINE ROOM HARNESS |
| 4 | B | TO ENGINE ROOM HARNESS |
| 5 | G | TO ENGINE ROOM HARNESS |
| 6 | - | TO ENGINE ROOM HARNESS |
| 7 | - | TO ENGINE ROOM HARNESS |
| 8 | G | TO ENGINE ROOM HARNESS |
| 9 | R | TO ENGINE ROOM HARNESS |
| 10 | G | TO ENGINE ROOM HARNESS |
| 11 | P | TO ENGINE ROOM HARNESS |
| 12 | R | TO ENGINE ROOM HARNESS |
| 13 | SHIELD | TO ENGINE ROOM HARNESS |
| 14 | SHIELD | TO ENGINE ROOM HARNESS |
| 15 | - | TO ENGINE ROOM HARNESS |
| 16 | - | TO ENGINE ROOM HARNESS |

| | |
|-----------------|--------------|
| Connector No. | E209 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24FW-NH |
| Connector Color | WHITE |






| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------------|
| 1 | Y | TO ENGINE ROOM HARNESS |
| 2 | L | TO ENGINE ROOM HARNESS |
| 3 | B | TO ENGINE ROOM HARNESS |
| 4 | SHIELD | TO ENGINE ROOM HARNESS |
| 5 | B | TO ENGINE ROOM HARNESS |
| 6 | R | TO ENGINE ROOM HARNESS |
| 7 | W | TO ENGINE ROOM HARNESS |

AAOI0484GB



| | | |
|----|--------|------------------------|
| 8 | SHIELD | TO ENGINE ROOM HARNESS |
| 9 | Y | TO ENGINE ROOM HARNESS |
| 10 | L | TO ENGINE ROOM HARNESS |
| 11 | SB | TO ENGINE ROOM HARNESS |
| 12 | Y | TO ENGINE ROOM HARNESS |
| 13 | R | TO ENGINE ROOM HARNESS |
| 14 | B | TO ENGINE ROOM HARNESS |
| 15 | G | TO ENGINE ROOM HARNESS |
| 16 | SHIELD | TO ENGINE ROOM HARNESS |
| 17 | W | TO ENGINE ROOM HARNESS |
| 18 | L | TO ENGINE ROOM HARNESS |
| 19 | Y | TO ENGINE ROOM HARNESS |
| 20 | V | TO ENGINE ROOM HARNESS |
| 21 | G | TO ENGINE ROOM HARNESS |
| 22 | L | TO ENGINE ROOM HARNESS |
| 23 | G | TO ENGINE ROOM HARNESS |
| 24 | R | TO ENGINE ROOM HARNESS |

| | |
|-----------------|------------|
| Connector No. | E219 |
| Connector Name | ICC SENSOR |
| Connector Type | AAZ08FB |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | UBAT |
| 2 | - | - |
| 3 | L | CAN 1 H |
| 4 | - | - |
| 5 | - | - |
| 6 | Y | CAN 1 L |
| 7 | - | - |
| 8 | B | GND |

| | |
|-----------------|--------------|
| Connector No. | M1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24MW-NH |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|----------------------|
| 1 | SB | TO ROOM LAMP HARNESS |
| 2 | LG | TO ROOM LAMP HARNESS |
| 3 | R | TO ROOM LAMP HARNESS |
| 4 | - | TO ROOM LAMP HARNESS |
| 5 | GR | TO ROOM LAMP HARNESS |
| 6 | LG | TO ROOM LAMP HARNESS |
| 7 | L | TO ROOM LAMP HARNESS |
| 8 | Y | TO ROOM LAMP HARNESS |
| 9 | W | TO ROOM LAMP HARNESS |
| 10 | LG | TO ROOM LAMP HARNESS |
| 11 | BR | TO ROOM LAMP HARNESS |
| 12 | R/G | TO ROOM LAMP HARNESS |
| 13 | W | TO ROOM LAMP HARNESS |
| 14 | B | TO ROOM LAMP HARNESS |
| 15 | SHIELD | TO ROOM LAMP HARNESS |
| 16 | R | TO ROOM LAMP HARNESS |
| 17 | W | TO ROOM LAMP HARNESS |
| 18 | - | TO ROOM LAMP HARNESS |
| 19 | G | TO ROOM LAMP HARNESS |
| 20 | BR | TO ROOM LAMP HARNESS |
| 21 | LG | TO ROOM LAMP HARNESS |
| 22 | Y | TO ROOM LAMP HARNESS |
| 23 | P | TO ROOM LAMP HARNESS |
| 24 | B | TO ROOM LAMP HARNESS |

| | |
|-----------------|------------------|
| Connector No. | M3 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | CS06FW-M2 |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1N | LG | IGNITION |
| 2N | BG | BATTERY |
| 3N | L | IGNITION |
| 4N | V | BATTERY |
| 5N | Y | BATTERY |
| 6N | W | BATTERY |
| 7N | L | BATTERY |
| 8N | L | IGNITION |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >

DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|------------------|
| Connector No. | M4 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS16FW-CS |
| Connector Color | WHITE |



| | | | | | | |
|-----|-----|-----|-----|-----|-----|-----|
| 7P | 6P | 5P | 4P | 3P | 2P | 1P |
| 16P | 15P | 14P | 13P | 12P | 11P | 10P |
| 9P | 8P | | | | | |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------------|
| 1P | R | IGNITION |
| 2P | LG | IGNITION |
| 3P | G | IGN ELEC RELAY OUT 2 |
| 4P | - | - |
| 5P | P | IGNITION |
| 6P | BG | REAR DEFOGGER RELAY OUT |
| 7P | LG | IGNITION |
| 8P | BG | IGNITION |
| 9P | L | BATTERY |
| 10P | BR | IGNITION |
| 11P | - | - |
| 12P | - | - |
| 13P | W | BATTERY |
| 14P | Y | BATTERY |
| 15P | L | BATT |
| 16P | W | BLOWER FAN RELAY OUT |

| | | | | | |
|---|---|---|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 |
| 7 | 8 | 9 | 10 | 11 | 12 |



| | |
|-----------------|-------------|
| Connector No. | M5 |
| Connector Name | CAN GATEWAY |
| Connector Type | TH12FW-NH |
| Connector Color | WHITE |

| | | |
|----|----|-------|
| 8 | - | - |
| 9 | BG | IGN |
| 10 | P | CAN-L |
| 11 | B | GND |
| 12 | P | CAN-L |



| | |
|-----------------|---------------------|
| Connector No. | M11 |
| Connector Name | JOINT CONNECTOR-M03 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| | | | |
|---|---|---|---|
| 4 | 3 | 2 | 1 |
|---|---|---|---|

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | CAN-L |
| 2 | Y | CAN-L |
| 3 | W | CAN-L |
| 4 | Y | CAN-L |

| | |
|-----------------|---------------------------|
| Connector No. | M19 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH |
| Connector Color | BLACK |



| | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|
| 40 | 39 | 38 | 37 | 36 | 35 | 34 | 33 | 32 | 31 | 30 | 29 | 28 | 27 | 26 | 25 | 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|---|---|---|---|---|---|---|---|---|

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------------|
| 41 | - | - |
| 42 | - | - |
| 43 | - | - |
| 44 | - | - |
| 45 | - | - |
| 46 | - | - |
| 47 | - | - |
| 48 | R | HIGH SIDE START SW LED |
| 49 | - | - |
| 50 | - | - |
| 51 | - | - |
| 52 | W | AUDIO DONGLE |

| | | |
|----|----|-------------------------|
| 53 | - | - |
| 54 | W | PW LIN/COM |
| 55 | BR | R SENSOR K-LINE |
| 56 | - | - |
| 57 | - | - |
| 58 | - | - |
| 59 | P | CAN-L |
| 60 | L | CAN-H |
| 61 | BG | REAR DEFOGGER RELAY OUT |
| 62 | W | STARTER RELAY OUT |
| 63 | BG | I-KEY LINK SIGNAL |
| 64 | P | BUZZER OUT |
| 65 | P | DOOR HANDLE LAMP |
| 66 | W | BLOWER FAN RELAY OUT |
| 67 | G | IGN ELEC RELAY OUT 2 |
| 68 | P | MR OUTPUT |
| 69 | G | AT DEVICE OUT |
| 70 | P | IGN USM OUT 1 |
| 71 | R | DR REQUEST SW |
| 72 | G | AS REQUEST SW |
| 73 | - | - |
| 74 | - | - |
| 75 | BG | COMBI SW OUT 5 |
| 76 | P | COMBI SW OUT 4 |
| 77 | P | COMBI SW OUT 3 |
| 78 | W | COMBI SW OUT 2 |
| 79 | W | COMBI SW OUT 1 |
| 80 | R | BACK DOOR OPEN SW |

| | |
|-----------------|-------------------|
| Connector No. | M23 |
| Connector Name | COMBINATION METER |
| Connector Type | TH12FW-NH |
| Connector Color | WHITE |



| | | | | | |
|----|----|----|----|----|----|
| 46 | 45 | 44 | 43 | 42 | 41 |
| 52 | 51 | 50 | 49 | 48 | 47 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 41 | LG | TRIP/RESET |
| 42 | Y | ILLUMI DOWN SW |
| 43 | V | M RANGE SE |
| 44 | BG | AT SHIFT UP |
| 45 | W | AT SHIFT DOWN |
| 46 | P | NOT M RANGE SW |
| 47 | BR | ILLUMI UP SW |
| 48 | G | SW GND |
| 49 | P | WASHER LEVEL SW |
| 50 | - | - |

| | | |
|----|---|---|
| 51 | - | - |
| 52 | - | - |



DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >



DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|-------------------|
| Connector No. | M24 |
| Connector Name | COMBINATION METER |
| Connector Type | TH40FW-NH |
| Connector Color | WHITE |

| | | |
|----|---|-------|
| 39 | L | CAN-H |
| 40 | - | - |


| | |
|-----------------|----------------------|
| Connector No. | M27 |
| Connector Name | METER CONTROL SWITCH |
| Connector Type | TH12FW-NH |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------|
| 1 | B | GND1 |
| 2 | B | GND2 |
| 3 | P | STRG SW INPUT 1 |
| 4 | BG | STRG SW INPUT 2 |
| 5 | P | ACC |
| 6 | V | SECURITY |
| 7 | R | AIR BAG |
| 8 | G | AS BELT |
| 9 | Y | DR BUCKLE SW |
| 10 | - | - |
| 11 | BG | ALTERNATOR (CHARGE) |
| 12 | G | PKB |
| 13 | - | - |
| 14 | G | STRG SW OUTPUT 1 |
| 15 | W | STRG SW OUTPUT 2 |
| 16 | B | STRG SW OUTPUT GND |
| 17 | - | - |
| 18 | - | - |
| 19 | - | - |
| 20 | - | - |
| 21 | BG | IGN |
| 22 | W | BAT |
| 23 | B | ILLUMI CONT OUT |
| 24 | R | STRG SW GND |
| 25 | G | BRAKE OIL SW |
| 26 | R | FUEL SENSOR GND |
| 27 | W | FUEL SENSOR |
| 28 | - | - |
| 29 | - | - |
| 30 | - | - |
| 31 | - | - |
| 32 | - | - |
| 33 | BR | SPEED 2 P/R |
| 34 | BG | SPEED 8 P/R |
| 35 | - | - |
| 36 | - | - |
| 37 | - | - |
| 38 | P | CAN-L |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | Y | ILLUMI DOWN SW |
| 2 | G | SW GND |
| 3 | LG | TRIP/RESET |
| 4 | R | ILL PWR |
| 5 | B | ILLUMI CONT OUT |
| 6 | BG | BCI OFF SWITCH |
| 7 | - | - |
| 8 | - | - |
| 9 | - | - |
| 10 | - | - |
| 11 | - | - |
| 12 | BR | ILLUMI UP SW |

| | |
|-----------------|-----------------------------------|
| Connector No. | M30 |
| Connector Name | COMBINATION SWITCH (SPIRAL CABLE) |
| Connector Type | TK08FGY-1V |
| Connector Color | GRAY |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------------|
| 24 | P | AUDIO STRG SW REMOTE A |
| 25 | W | ASCD |
| 31 | BG | AUDIO STRG SW REMOTE B |
| 32 | G | ASCDG |
| 33 | R | AUDIO STRG SW GND |

AAOIA0486GB

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >

DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|-----------------|
| Connector No. | M31 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CST6-TM4 |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 1G | SB | TO ENGINE ROOM HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 1G | P | TO ENGINE ROOM HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 2G | W | TO ENGINE ROOM HARNESS |
| 3G | P | TO ENGINE ROOM HARNESS |
| 4G | G | TO ENGINE ROOM HARNESS |
| 5G | P | TO ENGINE ROOM HARNESS |
| 6G | SB | TO ENGINE ROOM HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 6G | R | TO ENGINE ROOM HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 7G | SHIELD | TO ENGINE ROOM HARNESS |
| 8G | G | TO ENGINE ROOM HARNESS |
| 9G | BG | TO ENGINE ROOM HARNESS |
| 10G | W | TO ENGINE ROOM HARNESS |
| 11G | R | TO ENGINE ROOM HARNESS |
| 12G | G | TO ENGINE ROOM HARNESS |
| 13G | G | TO ENGINE ROOM HARNESS |
| 14G | V | TO ENGINE ROOM HARNESS |
| 15G | W | TO ENGINE ROOM HARNESS |
| 16G | R | TO ENGINE ROOM HARNESS |
| 17G | B | TO ENGINE ROOM HARNESS |
| 18G | SHIELD | TO ENGINE ROOM HARNESS |
| 19G | SB | TO ENGINE ROOM HARNESS |

AAOIA0487GB

| | | |
|-----|--------|------------------------|
| 20G | LG | TO ENGINE ROOM HARNESS |
| 21G | R | TO ENGINE ROOM HARNESS |
| 22G | B | TO ENGINE ROOM HARNESS |
| 23G | SHIELD | TO ENGINE ROOM HARNESS |
| 24G | W | TO ENGINE ROOM HARNESS |
| 25G | R | TO ENGINE ROOM HARNESS |
| 26G | SHIELD | TO ENGINE ROOM HARNESS |
| 27G | B | TO ENGINE ROOM HARNESS |
| 28G | W | TO ENGINE ROOM HARNESS |
| 29G | G | TO ENGINE ROOM HARNESS |
| 30G | R | TO ENGINE ROOM HARNESS |
| 31G | L | TO ENGINE ROOM HARNESS |
| 32G | G | TO ENGINE ROOM HARNESS |
| 33G | G | TO ENGINE ROOM HARNESS |
| 34G | G | TO ENGINE ROOM HARNESS |
| 35G | P | TO ENGINE ROOM HARNESS |
| 36G | L | TO ENGINE ROOM HARNESS |
| 37G | L | TO ENGINE ROOM HARNESS |
| 38G | W | TO ENGINE ROOM HARNESS |
| 39G | R | TO ENGINE ROOM HARNESS |
| 40G | Y | TO ENGINE ROOM HARNESS |
| 41G | L | TO ENGINE ROOM HARNESS |
| 42G | P | TO ENGINE ROOM HARNESS |
| 43G | W | TO ENGINE ROOM HARNESS |
| 44G | G | TO ENGINE ROOM HARNESS |
| 45G | R | TO ENGINE ROOM HARNESS |
| 46G | Y | TO ENGINE ROOM HARNESS |
| 47G | Y | TO ENGINE ROOM HARNESS |
| 48G | LG | TO ENGINE ROOM HARNESS |
| 49G | P | TO ENGINE ROOM HARNESS |
| 50G | L | TO ENGINE ROOM HARNESS |
| 51G | B/W | TO ENGINE ROOM HARNESS |
| 52G | BR | TO ENGINE ROOM HARNESS |
| 53G | L | TO ENGINE ROOM HARNESS |
| 54G | BG | TO ENGINE ROOM HARNESS |
| 55G | G | TO ENGINE ROOM HARNESS |
| 56G | P | TO ENGINE ROOM HARNESS |
| 57G | P | TO ENGINE ROOM HARNESS |
| 58G | L | TO ENGINE ROOM HARNESS |
| 59G | B | TO ENGINE ROOM HARNESS |
| 60G | W | TO ENGINE ROOM HARNESS |
| 61G | SHIELD | TO ENGINE ROOM HARNESS |
| 62G | G | TO ENGINE ROOM HARNESS |
| 63G | P | TO ENGINE ROOM HARNESS |
| 64G | W | TO ENGINE ROOM HARNESS |
| 65G | G/R | TO ENGINE ROOM HARNESS |
| 66G | R | TO ENGINE ROOM HARNESS |
| 67G | W | TO ENGINE ROOM HARNESS |
| 68G | Lg/R | TO ENGINE ROOM HARNESS |
| 69G | P | TO ENGINE ROOM HARNESS |
| 70G | BG | TO ENGINE ROOM HARNESS |
| 71G | GR | TO ENGINE ROOM HARNESS |
| 72G | - | TO ENGINE ROOM HARNESS |


| | | |
|------|--------|------------------------|
| 73G | - | TO ENGINE ROOM HARNESS |
| 74G | - | TO ENGINE ROOM HARNESS |
| 75G | G | TO ENGINE ROOM HARNESS |
| 76G | Y | TO ENGINE ROOM HARNESS |
| 77G | BR | TO ENGINE ROOM HARNESS |
| 78G | - | TO ENGINE ROOM HARNESS |
| 79G | R | TO ENGINE ROOM HARNESS |
| 80G | W | TO ENGINE ROOM HARNESS |
| 81G | G | TO ENGINE ROOM HARNESS |
| 82G | P | TO ENGINE ROOM HARNESS |
| 83G | P | TO ENGINE ROOM HARNESS |
| 84G | P | TO ENGINE ROOM HARNESS |
| 85G | P | TO ENGINE ROOM HARNESS |
| 86G | P | TO ENGINE ROOM HARNESS |
| 87G | P | TO ENGINE ROOM HARNESS |
| 88G | P | TO ENGINE ROOM HARNESS |
| 89G | R | TO ENGINE ROOM HARNESS |
| 90G | P | TO ENGINE ROOM HARNESS |
| 91G | L | TO ENGINE ROOM HARNESS |
| 92G | P | TO ENGINE ROOM HARNESS |
| 93G | P | TO ENGINE ROOM HARNESS |
| 94G | O | TO ENGINE ROOM HARNESS |
| 95G | B | TO ENGINE ROOM HARNESS |
| 96G | P | TO ENGINE ROOM HARNESS |
| 97G | P | TO ENGINE ROOM HARNESS |
| 98G | P | TO ENGINE ROOM HARNESS |
| 99G | P | TO ENGINE ROOM HARNESS |
| 100G | SHIELD | TO ENGINE ROOM HARNESS |

| | |
|-----------------|--------------|
| Connector No. | M36 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40FW-NH |
| Connector Color | WHITE |



| | | |
|----|--------|--------------------|
| 11 | SHIELD | TO BODY HARNESS RH |
| 12 | W | TO BODY HARNESS RH |
| 13 | B | TO BODY HARNESS RH |
| 14 | SHIELD | TO BODY HARNESS RH |
| 15 | B | TO BODY HARNESS RH |
| 16 | W | TO BODY HARNESS RH |
| 17 | SHIELD | TO BODY HARNESS RH |
| 18 | SB | TO BODY HARNESS RH |
| 19 | Lg | TO BODY HARNESS RH |
| 20 | B | TO BODY HARNESS RH |
| 21 | B | TO BODY HARNESS RH |
| 22 | W | TO BODY HARNESS RH |
| 23 | SHIELD | TO BODY HARNESS RH |
| 24 | W | TO BODY HARNESS RH |
| 25 | B | TO BODY HARNESS RH |
| 26 | SHIELD | TO BODY HARNESS RH |
| 27 | B | TO BODY HARNESS RH |
| 28 | W | TO BODY HARNESS RH |
| 29 | SHIELD | TO BODY HARNESS RH |
| 30 | B | TO BODY HARNESS RH |
| 31 | W | TO BODY HARNESS RH |
| 32 | L | TO BODY HARNESS RH |
| 33 | Y | TO BODY HARNESS RH |
| 34 | - | TO BODY HARNESS RH |
| 35 | - | TO BODY HARNESS RH |
| 36 | - | TO BODY HARNESS RH |
| 37 | BR | TO BODY HARNESS RH |
| 38 | - | TO BODY HARNESS RH |
| 39 | - | TO BODY HARNESS RH |
| 40 | - | TO BODY HARNESS RH |

| | |
|-----------------|---------------------|
| Connector No. | M37 |
| Connector Name | JOINT CONNECTOR-M28 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 2 | L | CAN-H |
| 3 | B | CAN-H |
| 4 | - | - |


DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >



DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|---------------------|
| Connector No. | M38 |
| Connector Name | JOINT CONNECTOR-M29 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | CAN-L |
| 2 | Y | CAN-L |
| 3 | W | CAN-L |
| 4 | - | - |

| | |
|-----------------|-------------------|
| Connector No. | M40 |
| Connector Name | WIRE TO WIPE |
| Connector Type | TH80FDGY-CST6-TM4 |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1A | GR | TO BODY HARNESS |
| 2A | BR | TO BODY HARNESS |
| 3A | Y | TO BODY HARNESS |
| 4A | V | TO BODY HARNESS |
| 5A | L/B | TO BODY HARNESS |

AAOIA0500B

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 57A | P | TO BODY HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 57A | L | TO BODY HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 58A | G | TO BODY HARNESS |
| 59A | SB | TO BODY HARNESS |
| 60A | L | TO BODY HARNESS |
| 61A | G | TO BODY HARNESS |
| 62A | BR | TO BODY HARNESS |
| 63A | BR | TO BODY HARNESS |
| 64A | Y | TO BODY HARNESS |
| 65A | W | TO BODY HARNESS |
| 66A | BG | TO BODY HARNESS |
| 67A | Y | TO BODY HARNESS |
| 68A | LG | TO BODY HARNESS |
| 69A | R | TO BODY HARNESS |
| 70A | P | TO BODY HARNESS |
| 71A | BR | TO BODY HARNESS |
| 72A | SB | TO BODY HARNESS |
| 73A | BG | TO BODY HARNESS |
| 74A | BR | TO BODY HARNESS |
| 75A | LG | TO BODY HARNESS |
| 76A | W | TO BODY HARNESS |
| 77A | L | TO BODY HARNESS |
| 78A | V | TO BODY HARNESS |
| 79A | LG | TO BODY HARNESS |
| 80A | Y | TO BODY HARNESS |
| 81A | L | TO BODY HARNESS |
| 82A | BG | TO BODY HARNESS |
| 83A | Y | TO BODY HARNESS |
| 84A | LG | TO BODY HARNESS |
| 85A | SHIELD | TO BODY HARNESS |
| 86A | Y | TO BODY HARNESS |
| 87A | LG | TO BODY HARNESS |
| 88A | BR | TO BODY HARNESS |
| 89A | L | TO BODY HARNESS |
| 90A | P | TO BODY HARNESS |
| 91A | L | TO BODY HARNESS |
| 92A | L | TO BODY HARNESS |
| 93A | B | TO BODY HARNESS |
| 94A | W | TO BODY HARNESS |
| 95A | W | TO BODY HARNESS |
| 96A | - | TO BODY HARNESS |
| 97A | SB | TO BODY HARNESS |
| 98A | Y | TO BODY HARNESS - (WITHOUT AUTOMATIC DRIVE POSITIONER) |
| 98A | L | TO BODY HARNESS - (WITH AUTOMATIC DRIVE POSITIONER) |
| 99A | - | TO BODY HARNESS |
| 100A | - | TO BODY HARNESS |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 6A | L | TO BODY HARNESS - (WITHOUT CLIMATE CONTROLLED SEAT) |
| 6A | G | TO BODY HARNESS - (WITH CLIMATE CONTROLLED SEAT) |
| 7A | Y | TO BODY HARNESS |
| 8A | W | TO BODY HARNESS |
| 9A | L | TO BODY HARNESS |
| 10A | R | TO BODY HARNESS |
| 11A | R | TO BODY HARNESS |
| 12A | BG | TO BODY HARNESS |
| 13A | O | TO BODY HARNESS |
| 14A | LG | TO BODY HARNESS |
| 15A | R | TO BODY HARNESS |
| 16A | G | TO BODY HARNESS |
| 17A | B | TO BODY HARNESS |
| 18A | B | TO BODY HARNESS |
| 19A | SHIELD | TO BODY HARNESS |
| 20A | B | TO BODY HARNESS |
| 21A | SHIELD | TO BODY HARNESS |
| 22A | - | TO BODY HARNESS |
| 23A | W | TO BODY HARNESS |
| 24A | B | TO BODY HARNESS |
| 25A | SHIELD | TO BODY HARNESS |
| 26A | B | TO BODY HARNESS |
| 27A | B | TO BODY HARNESS |
| 28A | SHIELD | TO BODY HARNESS |
| 29A | R | TO BODY HARNESS |
| 30A | B | TO BODY HARNESS |
| 31A | R | TO BODY HARNESS |
| 32A | Y/R | TO BODY HARNESS |
| 33A | W | TO BODY HARNESS |
| 34A | B | TO BODY HARNESS |
| 35A | SHIELD | TO BODY HARNESS |
| 36A | L/Y | TO BODY HARNESS |
| 37A | LG | TO BODY HARNESS |
| 38A | V | TO BODY HARNESS |
| 39A | SB | TO BODY HARNESS |
| 40A | BR | TO BODY HARNESS |
| 41A | Y | TO BODY HARNESS |
| 42A | G | TO BODY HARNESS |
| 43A | - | TO BODY HARNESS |
| 44A | W | TO BODY HARNESS |
| 45A | R | TO BODY HARNESS |
| 46A | BG | TO BODY HARNESS |
| 47A | LG | TO BODY HARNESS |
| 48A | R | TO BODY HARNESS |
| 49A | P | TO BODY HARNESS |
| 50A | W | TO BODY HARNESS |
| 51A | L | TO BODY HARNESS |
| 52A | P | TO BODY HARNESS |
| 53A | G | TO BODY HARNESS |
| 54A | W | TO BODY HARNESS |
| 55A | BG | TO BODY HARNESS |
| 56A | BR | TO BODY HARNESS |

| | |
|-----------------|---------------------|
| Connector No. | M41 |
| Connector Name | JOINT CONNECTOR-M18 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | P | CAN-L |
| 2 | P | CAN-L |
| 3 | P | CAN-L |
| 4 | - | - |

| | |
|-----------------|---------------------|
| Connector No. | M43 |
| Connector Name | JOINT CONNECTOR-M17 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 2 | L | CAN-H |
| 3 | L | CAN-H |
| 4 | - | - |

A B C D E F G H I J K L M N O P

BRC



DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >



DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|---------------|
| Connector No. | M50 |
| Connector Name | A/C AUTO AMP. |
| Connector Type | TH40FW-NH |
| Connector Color | WHITE |






| | | |
|----|---|---------------------|
| 39 | L | PTC 2 |
| 40 | Y | WATER VALVE CLOSE A |

| | |
|-----------------|-----------------------|
| Connector No. | M54 |
| Connector Name | STEERING ANGLE SENSOR |
| Connector Type | TH08FW-NH |
| Connector Color | WHITE |



| | |
|-----------------|--------------------|
| Connector No. | M70 |
| Connector Name | SONAR CONTROL UNIT |
| Connector Type | TH24FW-NH |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------|
| 1 | L | CAN-H |
| 2 | GR | GND |
| 3 | G | BATT |
| 4 | - | - |
| 5 | G | TX RR |
| 6 | - | - |
| 7 | G | AMB SENS |
| 8 | G | STRG HTR SW |
| 9 | W | SUN SENS |
| 10 | SB | MODE 1 |
| 11 | G | MODE 3 |
| 12 | G | FAN OUT (COOLER) |
| 13 | W | IGN 2 |
| 14 | W | FAN OUT (BOOSTER) |
| 15 | - | - |
| 16 | Y | ACTR (LIN) |
| 17 | LG | VACTR |
| 18 | W | FR FAN PWM |
| 19 | W | PTC 1 |
| 20 | BR | STRG HTR RLY |
| 21 | P | CAN-L |
| 22 | GR | GND (POWER) |
| 23 | LG | IGN |
| 24 | - | - |
| 25 | W | RX RR |
| 26 | G | SENS GND |
| 27 | W | INC SENS |
| 28 | W | INT SENS |
| 29 | P | MODE 2 |
| 30 | R | GAS SENS |
| 31 | BG | MODE 4 |
| 32 | L | FAN F/B (COOLER) |
| 33 | - | - |
| 34 | L | FAN F/B (BOOSTER) |
| 35 | - | - |
| 36 | BR | WATER VALVE OPEN B |
| 37 | BR | ACTR GND |
| 38 | P | IGN ON/OFF |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | GR | GND |
| 2 | P | CAN-L |
| 3 | - | - |
| 4 | G | IGN |
| 5 | L | CAN-H |
| 6 | - | - |
| 7 | - | - |
| 8 | - | - |

| | |
|-----------------|---------------------|
| Connector No. | M67 |
| Connector Name | JOINT CONNECTOR-M04 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------|
| 1 | B | FR SENSOR SIGNAL |
| 2 | B | FL SENSOR SIGNAL |
| 3 | R | FOL SENSOR SIGNAL |
| 4 | R | FOR SENSOR SIGNAL |
| 5 | B | Y CAN-H |
| 6 | W | Y CAN-L |
| 7 | - | - |
| 8 | - | - |
| 9 | B | RR SENSOR SIGNAL |
| 10 | B | ROL SENSOR SIGNAL |
| 11 | - | - |
| 12 | LG | IGN |
| 13 | B | FR SENSOR GND |
| 14 | B | RR SENSOR GND |
| 15 | GR | GND |
| 16 | LG | DISABLE SW |
| 17 | GR | LED OUTPUT |
| 18 | - | - |
| 19 | BR | SPEAKER PWR |
| 20 | LG | SPEAKER RR SIGNAL |
| 21 | B | RL SENSOR SIGNAL |
| 22 | W | ROL SENSOR SIGNAL |
| 23 | - | - |
| 24 | - | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | CAN-H |
| 2 | L | CAN-H |
| 3 | B | CAN-H |
| 4 | L | CAN-H |

AAOIA0564GB


DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >

DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | M84 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH32FW-NH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 1 | B | TO BODY HARNESS RH |
| 2 | W | TO BODY HARNESS RH |
| 3 | SHIELD | TO BODY HARNESS RH |
| 4 | LG | TO BODY HARNESS RH |
| 5 | P | TO BODY HARNESS RH - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 5 | Y | TO BODY HARNESS RH - (WITH REAR ENTERTAINMENT SYSTEM) |
| 6 | W | TO BODY HARNESS RH - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 6 | B | TO BODY HARNESS RH - (WITH REAR ENTERTAINMENT SYSTEM) |
| 7 | R | TO BODY HARNESS RH - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 7 | W | TO BODY HARNESS RH - (WITH REAR ENTERTAINMENT SYSTEM) |
| 8 | B | TO BODY HARNESS RH - (WITHOUT REAR ENTERTAINMENT SYSTEM) |
| 8 | R | TO BODY HARNESS RH - (WITH REAR ENTERTAINMENT SYSTEM) |
| 9 | SHIELD | TO BODY HARNESS RH |
| 10 | G | TO BODY HARNESS RH |
| 11 | L | TO BODY HARNESS RH |
| 12 | G | TO BODY HARNESS RH |
| 13 | G | TO BODY HARNESS RH |
| 14 | P | TO BODY HARNESS RH |
| 15 | O | TO BODY HARNESS RH |
| 16 | SB | TO BODY HARNESS RH |
| 17 | L | TO BODY HARNESS RH |
| 18 | P | TO BODY HARNESS RH |
| 19 | R | TO BODY HARNESS RH |
| 20 | - | TO BODY HARNESS RH |
| 21 | G | TO BODY HARNESS RH |
| 22 | R | TO BODY HARNESS RH |
| 23 | G | TO BODY HARNESS RH |
| 24 | R | TO BODY HARNESS RH - (WITH CLIMATE CONTROLLED SEAT) |
| 24 | V | TO BODY HARNESS RH - (WITHOUT CLIMATE CONTROLLED SEAT) |

| | | |
|----|----|--------------------|
| 25 | W | TO BODY HARNESS RH |
| 26 | W | TO BODY HARNESS RH |
| 27 | BG | TO BODY HARNESS RH |
| 28 | V | TO BODY HARNESS RH |
| 29 | SB | TO BODY HARNESS RH |
| 30 | L | TO BODY HARNESS RH |
| 31 | W | TO BODY HARNESS RH |
| 32 | - | TO BODY HARNESS RH |

| | |
|-----------------|---|
| Connector No. | M124 |
| Connector Name | AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM- WITH NAVI WITHOUT SURROUND SOUND SYSTEM) |
| Connector Type | TH32FW-NH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------|
| 49 | - | - |
| 50 | - | - |
| 51 | - | - |
| 52 | - | - |
| 53 | G | PKE SIG |
| 54 | - | - |
| 55 | W | NAVI COMP 1- |
| 56 | B | NAVI COMP 1+ |
| 57 | BG | I-KEY MEMORY |
| 58 | G | AV-ACC (DCM) |
| 59 | SHIELD | PKE SIG/MIC GND |
| 60 | W | MIC VCC |
| 61 | W | IT DISP |
| 62 | P | CAN-L |
| 63 | LG | M CAN-L |
| 64 | LG | M CAN-L TRM |
| 65 | - | - |
| 66 | - | - |
| 67 | P | MFO OUTPUT |
| 68 | LG | IGN |
| 69 | R | REVERSE SIG |
| 70 | BG | SPEED |
| 71 | SHIELD | NAVI COMP 1 SHIELD |
| 72 | R | NAVI COMP 1 SYNC |
| 73 | - | - |
| 74 | - | - |


| | | |
|----|--------|-------------|
| 75 | B | IMC SIG |
| 76 | SHIELD | DISP SHIELD |
| 77 | B | DISP IT |
| 78 | L | CAN-H |
| 79 | SB | M CAN-H |
| 80 | SB | M CAN-H TRM |

| | |
|-----------------|-----------------------|
| Connector No. | M126 |
| Connector Name | WARNING SYSTEM SWITCH |
| Connector Type | TH08FB-NH |
| Connector Color | BLACK |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------|
| 1 | R | ILL |
| 2 | - | - |
| 3 | G | WARNING SYSTEM ON IND |
| 4 | B | ILL CONT |
| 5 | W | BATT |
| 6 | Y | WARNING SYSTEM SW |
| 7 | - | - |
| 8 | B | GND |

| | |
|-----------------|---------------------|
| Connector No. | M146 |
| Connector Name | JOINT CONNECTOR-M05 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | L | ITS CAN-H |
| 2 | L | ITS CAN-H |
| 3 | L | ITS CAN-H |
| 4 | L | ITS CAN-H |

| | |
|-----------------|---------------------|
| Connector No. | M147 |
| Connector Name | JOINT CONNECTOR-M07 |
| Connector Type | TK04FW-J |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | Y | ITS CAN-L |
| 2 | Y | ITS CAN-L |
| 3 | Y | ITS CAN-L |
| 4 | Y | ITS CAN-L |

| | |
|-----------------|-----------------------------------|
| Connector No. | M149 |
| Connector Name | COMBINATION SWITCH (SPIRAL CABLE) |
| Connector Type | TK08FGY |
| Connector Color | GRAY |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------------|
| 13 | R | ASCD |
| 14 | B | AUDIO STRG SW REMOTE A |
| 15 | GR | AUDIO STRG SW REMOTE B |
| 16 | L | ASCDG |
| 17 | BR | AUDIO STRG SW GND |
| 18 | G | HORN SWITCH |
| 19 | Y | ILL CONT |
| 20 | W | ILL |

A B C D E F G H I J K L M N O P

BRC

DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]

< WIRING DIAGRAM >

DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|--------------|
| Connector No. | M158 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS10MW-CS |
| Connector Color | WHITE |

| | | | |
|---|----|---|---|
| 1 | 2 | 3 | 4 |
| 5 | 6 | 7 | 8 |
| 9 | 10 | | |

H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 1 | W | TO FRONT DOOR RH HARNESS |
| 2 | B | TO FRONT DOOR RH HARNESS |
| 3 | SHIELD | TO FRONT DOOR RH HARNESS |
| 4 | BR | TO FRONT DOOR RH HARNESS |
| 5 | Y | TO FRONT DOOR RH HARNESS |
| 6 | L | TO FRONT DOOR RH HARNESS |
| 7 | LG | TO FRONT DOOR RH HARNESS |
| 8 | GR | TO FRONT DOOR RH HARNESS |
| 9 | BR | TO FRONT DOOR RH HARNESS - (WITH BOSE AUDIO SYSTEM) |
| 9 | G | TO FRONT DOOR RH HARNESS - (WITH BOSE AUDIO SYSTEM) |
| 10 | Y | TO FRONT DOOR RH HARNESS - (WITH BOSE AUDIO SYSTEM) |
| 10 | W | TO FRONT DOOR RH HARNESS - (WITH BOSE AUDIO SYSTEM) |

| | |
|-----------------|--|
| Connector No. | M163 |
| Connector Name | AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM - WITH NAVI AND SURROUND SOUND SYSTEM) |
| Connector Type | TH32FW-NH |
| Connector Color | WHITE |

| | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 48 | 49 | 50 | 51 | 52 | 53 | 54 | 55 | 56 | 57 | 58 | 59 | 60 | 61 | 62 | 63 | 64 |
| 65 | 66 | 67 | 68 | 69 | 70 | 71 | 72 | 73 | 74 | 75 | 76 | 77 | 78 | 79 | 80 | |

H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 49 | - | - |
| 50 | - | - |
| 51 | - | - |
| 52 | - | - |
| 53 | G | PKB SIG |

AAOIA0637GB

| | | |
|----|--------|--------------------|
| 54 | - | NAVI COMPT1- |
| 55 | W | NAVI COMPT1- |
| 56 | B | NAVI COMPT1+ |
| 57 | BG | RESERVE I1 |
| 58 | G | RESERVE I2 |
| 59 | SHIELD | MIC GND |
| 60 | W | MIC VCC |
| 61 | W | IF-DISP |
| 62 | P | CAN-L |
| 63 | LG | M-CAN L |
| 64 | LG | M-CAN L TRM |
| 65 | - | - |
| 66 | - | - |
| 67 | P | MFR OUTPUT |
| 68 | LG | IGN |
| 69 | R | REVERSE SIG |
| 70 | BG | SPEED |
| 71 | SHIELD | NAVI COMPT1 SHIELD |
| 72 | R | GND |
| 73 | - | - |
| 74 | - | - |
| 75 | B | MIC SIG |
| 76 | SHIELD | DISP SHIELD |
| 77 | B | DISP-IT |
| 78 | L | CAN-H |
| 79 | SB | M-CAN H |
| 80 | SB | M-CAN H TRM |

| | |
|-----------------|--------------|
| Connector No. | M167 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16MW-CS |
| Connector Color | WHITE |

| | | | | | | |
|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 8 | 9 | 10 | 11 | 12 | 13 | 14 |
| 15 | 16 | | | | | |

H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 1 | B | TO FRONT DOOR LH HARNESS |
| 2 | V | TO FRONT DOOR LH HARNESS |
| 3 | G/B | TO FRONT DOOR LH HARNESS |
| 4 | V | TO FRONT DOOR LH HARNESS |
| 5 | SB | TO FRONT DOOR LH HARNESS |
| 6 | BR | TO FRONT DOOR LH HARNESS |
| 7 | Y | TO FRONT DOOR LH HARNESS |
| 8 | W | TO FRONT DOOR LH HARNESS - (WITH BOSE AUDIO SYSTEM) |
| 8 | V | TO FRONT DOOR LH HARNESS - (WITH BOSE AUDIO SYSTEM) |

| | | |
|----|--------|---|
| 9 | P | TO FRONT DOOR LH HARNESS - (WITH BOSE AUDIO SYSTEM WITHOUT SURROUND SOUND SYSTEM) |
| 9 | G | TO FRONT DOOR LH HARNESS - (WITH BOSE AUDIO SYSTEM AND SURROUND SOUND SYSTEM) |
| 9 | SB | TO FRONT DOOR LH HARNESS - (WITH BASE AUDIO SYSTEM) |
| 10 | L | TO FRONT DOOR LH HARNESS |
| 11 | BR | TO FRONT DOOR LH HARNESS |
| 12 | Y | TO FRONT DOOR LH HARNESS |
| 13 | LG | TO FRONT DOOR LH HARNESS |
| 14 | SHIELD | TO FRONT DOOR LH HARNESS |
| 15 | B | TO FRONT DOOR LH HARNESS |
| 16 | W | TO FRONT DOOR LH HARNESS |

| | |
|-----------------|--------------|
| Connector No. | M188 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24MW-NH |
| Connector Color | WHITE |

| | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 |
| 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |

H.S.

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | - | TO MAIN HARNESS |
| 2 | - | TO MAIN HARNESS |
| 3 | - | TO MAIN HARNESS |
| 4 | - | TO MAIN HARNESS |
| 5 | - | TO MAIN HARNESS |
| 6 | - | TO MAIN HARNESS |
| 7 | B | TO MAIN HARNESS |
| 8 | W | TO MAIN HARNESS |
| 9 | LG | TO MAIN HARNESS |
| 10 | G | TO MAIN HARNESS |
| 11 | B | TO MAIN HARNESS |
| 12 | R | TO MAIN HARNESS |
| 13 | B | TO MAIN HARNESS |
| 14 | Y | TO MAIN HARNESS |
| 15 | GR | TO MAIN HARNESS |
| 16 | G | TO MAIN HARNESS |
| 17 | B | TO MAIN HARNESS |
| 18 | R | TO MAIN HARNESS |
| 19 | G | TO MAIN HARNESS |
| 20 | W | TO MAIN HARNESS |
| 21 | B | TO MAIN HARNESS |
| 22 | Y | TO MAIN HARNESS |
| 23 | B | TO MAIN HARNESS |

| | | |
|----|---|-----------------|
| 24 | R | TO MAIN HARNESS |
|----|---|-----------------|

| | |
|-----------------|--------------|
| Connector No. | M189 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24FW-NH |
| Connector Color | WHITE |

H.S.

| | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|
| 12 | 11 | 10 | 9 | 8 | 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| 24 | 23 | 22 | 21 | 20 | 19 | 18 | 17 | 16 | 15 | 14 | 13 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | - | TO MAIN HARNESS |
| 2 | - | TO MAIN HARNESS |
| 3 | - | TO MAIN HARNESS |
| 4 | - | TO MAIN HARNESS |
| 5 | - | TO MAIN HARNESS |
| 6 | - | TO MAIN HARNESS |
| 7 | B | TO MAIN HARNESS |
| 8 | W | TO MAIN HARNESS |
| 9 | LG | TO MAIN HARNESS |
| 10 | G | TO MAIN HARNESS |
| 11 | B | TO MAIN HARNESS |
| 12 | R | TO MAIN HARNESS |
| 13 | B | TO MAIN HARNESS |
| 14 | Y | TO MAIN HARNESS |
| 15 | GR | TO MAIN HARNESS |
| 16 | G | TO MAIN HARNESS |
| 17 | B | TO MAIN HARNESS |
| 18 | R | TO MAIN HARNESS |
| 19 | G | TO MAIN HARNESS |
| 20 | W | TO MAIN HARNESS |
| 21 | B | TO MAIN HARNESS |
| 22 | Y | TO MAIN HARNESS |
| 23 | B | TO MAIN HARNESS |
| 24 | R | TO MAIN HARNESS |



DRIVER ASSISTANCE SYSTEMS

[FORWARD EMERGENCY BRAKING]



< WIRING DIAGRAM >

DRIVER ASSISTANCE SYSTEM CONNECTORS

| | |
|-----------------|---|
| Connector No. | M198 |
| Connector Name | DRIVER ASSISTANCE BUZZER CONTROL MODULE |
| Connector Type | TH24FW-NH |
| Connector Color | WHITE |






| | |
|-----------------|-----------------------|
| Connector No. | M199 |
| Connector Name | WARNING SYSTEM BUZZER |
| Connector Type | NS02FW-CS |
| Connector Color | WHITE |

| | | |
|----|----|-----------------|
| 21 | SB | TO MAIN HARNESS |
| 22 | L | TO MAIN HARNESS |
| 23 | W | TO MAIN HARNESS |
| 24 | B | TO MAIN HARNESS |



| | |
|-----------------|------------------|
| Connector No. | R6 |
| Connector Name | LANE CAMERA UNIT |
| Connector Type | MUB12FB |
| Connector Color | BLACK |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | B | GND |
| 2 | L | ITS-CAN-H |
| 3 | LG | IGN |
| 4 | - | - |
| 5 | Y | ITS-CAN-L |
| 6 | Y | 3RD-CAN-L |
| 7 | - | - |
| 8 | - | - |
| 9 | L | V-CAN-H |
| 10 | Y | V-CAN-L |
| 11 | - | - |
| 12 | G | SPEAKER + |
| 13 | - | - |
| 14 | - | - |
| 15 | - | - |
| 16 | - | - |
| 17 | - | - |
| 18 | L | 3RD-CAN-H |
| 19 | - | - |
| 20 | - | - |
| 21 | - | - |
| 22 | - | - |
| 23 | - | - |
| 24 | W | SPEAKER - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------|
| 1 | G | SPEAKER DRIVE(+) |
| 2 | W | SPEAKER DRIVE(-) |

| | |
|-----------------|--------------|
| Connector No. | R1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24FW-NH |
| Connector Color | WHITE |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | B | GND |
| 2 | - | - |
| 3 | LG | IGN |
| 4 | - | - |
| 5 | BR | CAN-H |
| 6 | Y | CAN-L |
| 7 | - | - |
| 8 | - | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------|
| 1 | G | TO MAIN HARNESS |
| 2 | R | TO MAIN HARNESS |
| 3 | W | TO MAIN HARNESS |
| 4 | Y/R | TO MAIN HARNESS |
| 5 | B | TO MAIN HARNESS |
| 6 | LG | TO MAIN HARNESS |
| 7 | BR | TO MAIN HARNESS |
| 8 | Y | TO MAIN HARNESS |
| 9 | G | TO MAIN HARNESS |
| 10 | W | TO MAIN HARNESS |
| 11 | SB | TO MAIN HARNESS |
| 12 | R/G | TO MAIN HARNESS |
| 13 | W | TO MAIN HARNESS |
| 14 | B | TO MAIN HARNESS |
| 15 | SHIELD | TO MAIN HARNESS |
| 16 | P | TO MAIN HARNESS |
| 17 | BG | TO MAIN HARNESS |
| 18 | - | TO MAIN HARNESS |
| 19 | V | TO MAIN HARNESS |
| 20 | W | TO MAIN HARNESS |

AAOIA0638GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[FORWARD EMERGENCY BRAKING]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000014224839

OVERALL SEQUENCE



DETAILED FLOW

1. INTERVIEW FOR MALFUNCTION

It is also important to clarify the customer concerns before starting the inspection. Interview the customer about the concerns carefully and understand the symptoms fully.

DIAGNOSIS AND REPAIR WORK FLOW

[FORWARD EMERGENCY BRAKING]

< BASIC INSPECTION >

NOTE:

The customers are not professionals. Never assume that “maybe the customer means…” or “maybe the customer mentioned this symptom”.

>> GO TO 2.

2. SELF-DIAGNOSIS WITH CONSULT

1. Perform “All DTC Reading” with CONSULT.
2. Check if the DTC is detected on the self-diagnosis results of following.
 - “ICC/ADAS”
 - “LASER/RADAR”
 - “ACCELE PEDAL ACT”
 - “LANE CAMERA”
 - “SIDE RADAR LEFT”
 - “SIDE RADAR RIGHT”
 - “BSW/BUZZER”

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 3.

3. ACTION TEST

Perform Following system action test to check the operation status. Refer to [DAS-318, "DCA : Description"](#). Check if any other malfunctions occur.

>> GO TO 4.

4. SYMPTOM DIAGNOSIS

Perform the applicable diagnosis according to the diagnosis chart by symptom. Refer to [DAS-371, "Symptom Table"](#).

>> GO TO 6.

5. TROUBLE DIAGNOSIS BY DTC

1. Check the DTC in the self-diagnosis results.
2. Perform trouble diagnosis for the detected DTC following.
 - “ICC/ADAS”: Refer to [DAS-261, "DTC Index"](#)
 - “LASER/RADAR” Refer to [DAS-266, "DTC Index"](#)
 - “ACCELE PEDAL ACT”: Refer to [DAS-271, "DTC Index"](#)
 - “LANE CAMERA”: Refer to [DAS-283, "DTC Index"](#)
 - “SIDE RADAR LEFT”: Refer to [DAS-273, "DTC Index"](#)
 - “SIDE RADAR RIGHT”: Refer to [DAS-276, "DTC Index"](#)
 - “BSW/BUZZER”: Refer to [DAS-280, "DTC Index"](#)

NOTE:

If “DTC: U1000” is detected, first diagnose the CAN communication system or ITS communication system.

>> GO TO 6.

6. MALFUNCTIONING PART REPAIR

Repair or replace the identified malfunctioning parts.

>> GO TO 7.

7. REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

1. Erases self-diagnosis results.
2. Perform “All DTC Reading” again after repairing or replacing the specific items.
3. Check if any DTC is detected in self-diagnosis results of following.
 - “ICC/ADAS”
 - “LASER/RADAR”

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

DIAGNOSIS AND REPAIR WORK FLOW

[FORWARD EMERGENCY BRAKING]

< BASIC INSPECTION >

- "ACCELE PEDAL ACT"
- "LANE CAMERA"
- "SIDE RADAR LEFT"
- "SIDE RADAR RIGHT"
- "BSW/BUZZER"

Is any DTC detected?

YES >> GO TO 5.

NO >> GO TO 8.

8. REPAIR CHECK (ACTION TEST)

Perform the Following system action test. Check that the malfunction symptom is solved or no other symptoms occur.

- DCA
- LDW/LDP
- Blind Spot Warning/Blind Spot Intervention
- BCI

Is there a malfunction symptom?

YES >> GO TO 4.

NO >> INSPECTION END

ADDITIONAL SERVICE WHEN REPLACING ICC SENSOR

< BASIC INSPECTION >

[FORWARD EMERGENCY BRAKING]

ADDITIONAL SERVICE WHEN REPLACING ICC SENSOR

Description

INFOID:000000014224840

- Always perform the radar alignment after removing and installing or replacing the ICC sensor.

CAUTION:

The system does not operate normally unless the laser beam aiming adjustment is performed. Always perform it.

- Perform the DCA system action test check that the DCA system operates normally.

Work Procedure

INFOID:000000014224841

1. RADAR ALIGNMENT

Perform the radar alignment. Refer to [CCS-82. "Description"](#).

>> GO TO 2.

2. DCA SYSTEM ACTION TEST

1. Perform the DCA system action test. Refer to [DAS-318. "DCA : Description"](#).
2. Check that the DCA system operates normally.

>> INSPECTION END

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ADDITIONAL SERVICE WHEN REPLACING ACCELERATOR PEDAL ASSEMBLY

< BASIC INSPECTION >

[FORWARD EMERGENCY BRAKING]

ADDITIONAL SERVICE WHEN REPLACING ACCELERATOR PEDAL ASSEMBLY

Description

INFOID:000000014224842

- Always perform accelerator pedal released position learning when replacing the accelerator pedal assembly or disconnecting the accelerator pedal position sensor connector.
- Perform the DCA system action test check that the DCA system operates normally.

Work Procedure

INFOID:000000014224843

1.ACCELERATOR PEDAL RELEASED POSITION LEARNING

Perform accelerator pedal released position learning. Refer to [BRC-262. "Description"](#).

>> GO TO 2.

2.DCA SYSTEM ACTION TEST

1. Perform the DCA system action test. Refer to [DAS-318. "DCA : Description"](#).
2. Check that the DCA system operates normally.

>> INSPECTION END

ADDITIONAL SERVICE WHEN REPLACING LANE CAMERA UNIT

< BASIC INSPECTION >

[FORWARD EMERGENCY BRAKING]

ADDITIONAL SERVICE WHEN REPLACING LANE CAMERA UNIT

Description

INFOID:0000000014224844

Always adjust the camera aiming after removing and installing or replacing the lane camera unit.

CAUTION:

The system does not operate normally unless the camera aiming adjustment is performed. Always perform it.

Work Procedure

INFOID:0000000014224845

1. CAMERA AIMING ADJUSTMENT

Perform the camera aiming adjustment. Refer to [BRC-267, "Work Procedure \(Camera Aiming Adjustment\)"](#).

>> GO TO 2.

2. PERFORM SELF-DIAGNOSIS

Perform the self-diagnosis of lane camera unit with CONSULT. Check if any DTC is detected.

Is any DTC detected?

YES >> Perform the trouble diagnosis for the detected DTC. Refer to [DAS-283, "DTC Index"](#)

NO >> GO TO 3.

3. LDW/LDP SYSTEM ACTION TEST

1. Perform the LDW/LDP system action test. Refer to [DAS-319, "LDW/LDP : Description"](#).
2. Check that the LDW/LDP system operates normally.

>> GO TO 4.

4. BLIND SPOT WARNING/BLIND SPOT INTERVENTION SYSTEM ACTION TEST

1. Perform the Blind Spot Warning/Blind Spot Intervention system action test. Refer to [DAS-321, "BSW/RCTA : Description"](#).
2. Check that the Blind Spot Warning/Blind Spot Intervention system operates normally.

>> WORK END

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

PRE-INSPECTION FOR DIAGNOSIS

[FORWARD EMERGENCY BRAKING]

< BASIC INSPECTION >

PRE-INSPECTION FOR DIAGNOSIS

LANE CAMERA UNIT

LANE CAMERA UNIT : Inspection Procedure

INFOID:0000000014224846

1.CHECK CAMERA LENS AND WINDSHIELD

Are camera lens and windshield contaminated with foreign materials?

YES >> Clean camera lens and windshield.

NO >> GO TO 2.

2.CHECK LANE CAMERA UNIT INSTALLATION CONDITION

Check lane camera unit installation condition (installation position, properly tightened, a bent bracket).

Is it properly installed?

YES >> GO TO 3.

NO >> Install lane camera unit properly, and perform camera aiming. Refer to [BRC-265, "Description"](#).

3.CHECK VEHICLE HEIGHT

Check vehicle height. Refer to [FSU-23, "Wheelarch Height"](#).

Is vehicle height appropriate?

YES >> INSPECTION END

NO >> Repair vehicle to appropriate height.

CAMERA AIMING ADJUSTMENT

< BASIC INSPECTION >

[FORWARD EMERGENCY BRAKING]

CAMERA AIMING ADJUSTMENT

Description

INFOID:000000014224847

Always adjust the camera aiming after removing and installing or replacing the lane camera unit.

CAUTION:

- Place the vehicle on level ground when the camera aiming adjustment is operated.
- Follow the **CONSULT** when performing the camera aiming. (Camera aiming adjustment cannot be operated without **CONSULT**.)

Work Procedure (Preparation)

INFOID:000000014224848

1. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis of ADAS control unit and lane camera unit.

Is any DTC detected?

Except "C1B01">>Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-40, "DTC Index"](#) (ICC/ADAS) or [DAS-283, "DTC Index"](#) (LANE CAMERA).

"C1B01" or no DTC>>GO TO 2.

2. PREPARATION BEFORE CAMERA AIMING ADJUSTMENT

1. Perform pre-inspection for diagnosis. Refer to [BRC-264, "LANE CAMERA UNIT : Inspection Procedure"](#).
2. Adjust the tire pressure to the specified pressure value.
3. Maintain no-load in vehicle.
4. Check if coolant and engine oil are filled up to correct level and fuel tank is full.
5. Shift the selector lever to "P" position and release the parking brake.
6. Clean the windshield.
7. Completely clear off the instrument panel.

>> GO TO 3.


3. PREPARATION OF AIMING ADJUSTMENT JIG

Prepare the aiming adjustment jig according to the following procedure and the figure.

1. Print out the target mark attached in this service manual. Refer to [BRC-268, "Work Procedure \(Target Mark Sample\)"](#).
2. Stick a printed target mark on the board with a scotch tape or a piece of double-sided tape.

NOTE:

- Use the board that peripheral area of the target is monochrome such as a white-board.
- Notice that the cross of the target is horizontal and vertical.



CAMERA AIMING ADJUSTMENT

[FORWARD EMERGENCY BRAKING]

< BASIC INSPECTION >

- ① Board
- ② String
- ③ Cone
- : Target mark

Diameter of a target (D) : 200 mm (7.87 in)
Height of a target center (H) : 1,450 mm (57.09 in)
Width between a right target center from a left target center (W) : 600 mm (23.62 in)

>> Go to [BRC-266, "Work Procedure \(Target Setting\)"](#).


Work Procedure (Target Setting)

INFOID:000000014224849

CAUTION:

- Perform this operation in a horizontal position where there is a clear view for 5 m (16.4 ft) forward and 3 m (9.84 ft) wide.
- Place the target in a well-lighted location. (Poor lighting may make it hard to adjust.)
- The target may not be detected when there is a light source within 1.5 m (4.92 ft) from either side and within 1 m (3.28 ft) upward/downward from the target.
- Check the location of the sun. (Sunlight should not shine directly on the front of the vehicle.)
- The target may not be detected when there is the same pattern of black and white as the target when the pattern is within 1 m (3.28 ft) from either side and upward/downward position from the target. (It is desirable that the vehicle is positioned on the opposite side of a single-color wall.)

1. TARGET SETTING



"A"—"E" ("C"—"F") : 3,000 mm (118.11 in)

1. Mark points "A", "B", "C" and "D" at the center of the lateral surface of each wheels.


NOTE:

Hang a string with a cone from the fender so as to pass through the center of wheel, and then mark a point at the center of the lateral surface of the wheel.

2. Draw line "LH" passing through points "A" and "B" on the left side of vehicle.

NOTE:

Approximately 4 m (13.12 ft) or more from the front end of vehicle.




CAMERA AIMING ADJUSTMENT

[FORWARD EMERGENCY BRAKING]

< BASIC INSPECTION >

3. Mark point "E" on the line "LH" at the positions 3,000 mm (118.11 in) from point "A".
4. Draw line "RH" passing through points "C" and "D" on the right side of vehicle in the same way as step 2.
NOTE:
Approximately 4 m (13.12 ft) or more from the front end of vehicle.
5. Mark point "F" on the line "RH" at the positions 3,000 mm (118.11 in) from point "C".
6. Draw line "FW" passing through the points "E" and "F" on the front side of vehicle.
7. Mark point "X" at the center of point "E" and "F" on the line "FW".
CAUTION:
Make sure that "E" to "X" is equal to "F" to "X".
8. Place a target on either side of point "X". Each distance from point "X" must be equal each other.



Dt : 3,000 mm (118.11 in)

>> Go to [BRC-267, "Work Procedure \(Camera Aiming Adjustment\)"](#).

Work Procedure (Camera Aiming Adjustment)

INFOID:000000014224850

CAUTION:

Perform the adjustment under unloaded vehicle condition.

1. CHECK VEHICLE HEIGHT

Measure the wheelarch height. Calculate "Dh".

$$Dh [mm] = (Hfl + Hfr) \div 2 - 821 \text{ mm (32.32 in)}$$

where,

Hfl: Front left wheelarch height [mm]

Hfr: Front right wheelarch height [mm]

NOTE:

"Dh" may be calculated as a minus value.


>> GO TO 2.

2. CAMERA AIMING ADJUSTMENT

CAUTION:

Operate CONSULT outside the vehicle, and close all the doors. (To retain vehicle attitude appropriately)

1. Select "Work Support" on "LANE CAMERA" with CONSULT.
2. Select "AUTO AIM".
3. Confirm the following items;
 - The target should be accurately placed.
 - The vehicle should be stopped.
4. Select "Start" to perform camera aiming.



CAMERA AIMING ADJUSTMENT

< BASIC INSPECTION >

[FORWARD EMERGENCY BRAKING]

CAUTION:

- Never select “Start” when the target is not accurately placed.
- Wait 5 seconds or more after selecting “Start”.

5. Input “Dh”, and then select “Start”.

CAUTION:

Never change “Ht” and “Dt”.

6. Confirm the displayed item.

- “Normally Completed”: Select “Completion”.
- “SUSPENSION”, “X AIMING NG Y”, “ABNORMALLY COMPLETED”: Perform the following services.

| Displayed item | Possible cause | Service procedure |
|---------------------------------------|---|--|
| — | Temporary malfunction in internal processing of the lane camera unit. | Go back to Step 1 |
| SUSPENSION | 00H Routine not activated | Lane camera unit malfunction. |
| | 10H Writing error | <ul style="list-style-type: none"> • Temporary malfunction in internal processing of the lane camera unit. • Lane camera unit malfunction. |
| X AIMING NG Y (X: 0 - 7, Y: 1 - 8) | — | <ul style="list-style-type: none"> • A target is not-yet-placed. (The lane camera unit cannot detect a target.) • The position of the lane camera unit is not correct. |
| ABNORMALLY COMPLETED | — | <ul style="list-style-type: none"> • Inappropriate work environment. • Inappropriate vehicle condition. |

NOTE:

Replace camera unit if “00H Routine not activated” or “10H Writing error” are repeatedly indicated during the above two services are performed.

7. Confirm that “Normally Completed” is displayed and then select “End” to close the aiming adjustment procedure.

>> GO TO 3.

3. PERFORM SELF-DIAGNOSIS

Perform self-diagnosis of lane camera unit with CONSULT.

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-283. "DTC Index"](#).

NO >> GO TO 4.

4. ACTION TEST

Test the LDW/LDP system operation by action test. Refer to [DAS-319. "LDW/LDP : Description"](#).

>> WORK END

Work Procedure (Target Mark Sample)

INFOID:000000014224851


NOTE:

CAMERA AIMING ADJUSTMENT

< BASIC INSPECTION >

[FORWARD EMERGENCY BRAKING]

Print this illustration so that the diameter of the circle is 200 mm (7.87 in).



- A
- B
- C
- D
- E
- BRC**
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P

BRC

PGIA0105J

C1B00 CAMERA UNIT MALF

< DTC/CIRCUIT DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

DTC/CIRCUIT DIAGNOSIS

C1B00 CAMERA UNIT MALF

LANE CAMERA UNIT

LANE CAMERA UNIT : DTC Logic

INFOID:0000000014225010

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|---|---------------------------------------|
| C1B00 | CAMERA UNIT MALF (Camera unit malfunction) | If lane camera unit is malfunctioning |

POSSIBLE CAUSE

Lane camera unit

FAIL-SAFE

The following systems are canceled.

- Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)
- Blind Spot Warning (BSW)/Blind Spot Intervention

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1B00" is detected as the current malfunction in "Self Diagnostic Result" of "LANE CAMERA".

Is "C1B00" detected as the current malfunction?

- YES >> Refer to [BRC-270, "LANE CAMERA UNIT : Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

LANE CAMERA UNIT : Diagnosis Procedure

INFOID:0000000014225011

1. CHECK SELF-DIAGNOSIS RESULTS

Check if any DTC other than "C1B00" is detected in "Self Diagnostic Result" of "LANE CAMERA".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [DAS-283, "DTC Index"](#).
- NO >> Replace the lane camera unit. Refer to [DAS-409, "Removal and Installation"](#).

C1B01 CAM AIMING INCMP

[FORWARD EMERGENCY BRAKING]

< DTC/CIRCUIT DIAGNOSIS >

C1B01 CAM AIMING INCMP

LANE CAMERA UNIT

LANE CAMERA UNIT : DTC Logic

INFOID:0000000014225012

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|--|--------------------------------|
| C1B01 | CAM AIMING INCMP (Camera aiming incomplete) | Camera aiming is not completed |

POSSIBLE CAUSE

- Lane camera aiming is not adjusted
- Lane camera aiming adjustment has been interrupted

FAIL-SAFE

The following systems are canceled.

- Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)
- Blind Spot Warning (BSW)/Blind Spot Intervention

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1B01" is detected as the current malfunction in "Self Diagnostic Result" of "LANE CAMERA".

Is "C1B01" detected as the current malfunction?

- YES >> Refer to [BRC-271, "LANE CAMERA UNIT : Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

LANE CAMERA UNIT : Diagnosis Procedure

INFOID:0000000014225013

1. CAMERA AIMING ADJUSTMENT

1. Perform the camera aiming. Refer to [BRC-265, "Description"](#).
2. Erase all self-diagnosis results with CONSULT.
3. Perform "All DTC Reading".
4. Check if the "C1B01" is detected in "Self Diagnostic Result" of "LANE CAMERA".

Is "C1B01" detected?

- YES >> Replace the lane camera unit. Refer to [DAS-409, "Removal and Installation"](#).
- NO >> INSPECTION END

C1B03 ABNRML TEMP DETECT

< DTC/CIRCUIT DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

C1B03 ABNRML TEMP DETECT

LANE CAMERA UNIT

LANE CAMERA UNIT : DTC Logic

INFOID:0000000014225014

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|---|---|
| C1B03 | ABNRML TEMP DETECT (Abnormal temperature detect) | Temperature around lane camera unit is excessively high |

POSSIBLE CAUSE

Interior room temperature is excessively high

FAIL-SAFE

The following systems are canceled.

- Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)
- Blind Spot Warning (BSW)/Blind Spot Intervention

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "C1B03" is detected as the current malfunction in "Self Diagnostic Result" of "LANE CAMERA".

Is "C1B03" detected as the current malfunction?

YES >> Refer to [BRC-272, "LANE CAMERA UNIT : Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

LANE CAMERA UNIT : Diagnosis Procedure

INFOID:0000000014225015

1. COOLING LANE CAMERA UNIT

1. Wait for 10 minutes or more to cool the lane camera unit.
2. Erase all self-diagnosis results with CONSULT.
3. Perform "All DTC Reading".
4. Check if the "C1B03" is detected in "Self Diagnostic Result" of "LANE CAMERA".

Is "C1B03" detected?

YES >> Replace the lane camera unit. Refer to [DAS-409, "Removal and Installation"](#).

NO >> INSPECTION END

C1B09 POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

C1B09 POWER SUPPLY CIRCUIT

DTC Logic

INFOID:000000014225016

DTC DETECTION LOGIC

| DTC | CONSULT screen terms (Trouble diagnosis content) | DTC detecting condition |
|-------|---|--|
| C1B09 | POWER SUPPLY CIRCUIT (Power supply circuit) | Lane camera unit ignition voltage is greater than 16 V for 5 seconds |

POSSIBLE CAUSE

- Harness, connector, or fuse
- Lane camera unit
- Power supply circuit

FAIL-SAFE

The following functions are suspended.

- LDW

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the LDW system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "C1B09" is detected as the current malfunction on the self-diagnosis results of "LANE CAMERA".

Is "C1B09" detected as the current malfunction?

YES >> Refer to [BRC-273, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000014225017

1. CHECK LANE CAMERA UNIT SUPPLY AND GROUND CIRCUIT

Check power supply and ground circuit of lane camera unit. Refer to [DAS-360, "LANE CAMERA UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> Replace the lane camera unit. Refer to [DAS-409, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

U1000 CAN COMM CIRCUIT ACCELERATOR PEDAL ACTUATOR

ACCELERATOR PEDAL ACTUATOR : Description

INFOID:000000014225018

ITS COMMUNICATION

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with 2 communication lines.
- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

ACCELERATOR PEDAL ACTUATOR : DTC Logic

INFOID:000000014225019

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|---|---|
| U1000 | CAN COMM CIRCUIT (CAN communication circuit) | If accelerator pedal actuator is not transmitting or receiving ITS communication signal for 2 seconds or more |

POSSIBLE CAUSE

ITS communication system

FAIL-SAFE

The following systems are canceled.

- Vehicle-to-vehicle distance control mode
- Distance Control Assist (DCA)
- Forward Emergency Braking (FEB)
- Back-up Collision Intervention (BCI)

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the DCA system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [BRC-274. "ACCELERATOR PEDAL ACTUATOR : Diagnosis Procedure"](#).
NO-1 >> To check malfunction symptom before repair: Refer to [GI-50. "Intermittent Incident"](#).
NO-2 >> Confirmation after repair: INSPECTION END

ACCELERATOR PEDAL ACTUATOR : Diagnosis Procedure

INFOID:000000014225020

1. PERFORM THE SELF-DIAGNOSIS

1. Turn the ignition switch ON.
2. Turn the DCA system ON, and then wait for 2 seconds or more.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "ACCELERATOR PEDAL ACT".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [LAN-28. "Trouble Diagnosis Flow Chart"](#).
NO-1 >> To check malfunction symptom before repair: Refer to [GI-50. "Intermittent Incident"](#).
NO-2 >> Confirmation after repair: INSPECTION END

LANE CAMERA UNIT

LANE CAMERA UNIT : Description

INFOID:000000014225021

ITS COMMUNICATION

U1000 CAN COMM CIRCUIT

[FORWARD EMERGENCY BRAKING]

< DTC/CIRCUIT DIAGNOSIS >

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with 2 communication lines.
- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

LANE CAMERA UNIT : DTC Logic

INFOID:0000000014225022

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|--|---|
| U1000 | CAN COMM CIRCUIT (CAN communication circuit) | If lane camera unit is not transmitting or receiving ITS communication signal for 2 seconds or more |

POSSIBLE CAUSE

ITS communication system

FAIL-SAFE

The following systems are canceled.

- Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)
- Blind Spot Warning (BSW)/Blind Spot Intervention

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the LDP system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS".

Is "U1000" detected as the current malfunction?

YES >> Refer to [BRC-275, "LANE CAMERA UNIT : Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

LANE CAMERA UNIT : Diagnosis Procedure

INFOID:0000000014225023

1. PERFORM THE SELF-DIAGNOSIS

1. Turn the ignition switch ON.
2. Turn the LDP system ON, and then wait for 2 seconds or more.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "LANE CAMERA".

Is "U1000" detected as the current malfunction?

YES >> Refer to [LAN-28, "Trouble Diagnosis Flow Chart"](#).

NO >> Refer to [GI-50, "Intermittent Incident"](#).

SIDE RADAR LH

SIDE RADAR LH : Description

INFOID:0000000014225024

CAN COMMUNICATION

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads the required data only.

CAN communication signal chart. Refer to [LAN-49, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

ITS COMMUNICATION

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting plural units with 2 communication lines.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

SIDE RADAR LH : DTC Logic

INFOID:000000014225025

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|---|--|
| U1000 | CAN COMM CIRCUIT (CAN communication circuit) | If Side radar LH is not transmitting or receiving ITS communication signal for 2 seconds or more |

POSSIBLE CAUSE

ITS communication system

FAIL-SAFE

The following systems are canceled.

- Blind Spot Warning (BSW)
- Rear Cross Traffic Alert (RCTA)
- Blind Spot Intervention
- Back-up Collision Intervention (BCI)

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the Blind Spot Intervention system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS".

Is "U1000" detected as the current malfunction?

YES >> Refer to [BRC-276, "SIDE RADAR LH : Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

SIDE RADAR LH : Diagnosis Procedure

INFOID:000000014225026

1. PERFORM THE SELF-DIAGNOSIS

1. Start the engine.
2. Turn the Blind Spot Intervention system ON, and then wait for 30 seconds or more.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "SIDE RADAR LEFT".

Is "U1000" detected as the current malfunction?

YES >> Refer to [LAN-28, "Trouble Diagnosis Flow Chart"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

SIDE RADAR RH

SIDE RADAR RH : Description

INFOID:000000014225027

CAN COMMUNICATION

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control units, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H, CAN-L) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads the required data only.

CAN communication signal chart. Refer to [LAN-49, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

ITS COMMUNICATION

U1000 CAN COMM CIRCUIT

[FORWARD EMERGENCY BRAKING]

< DTC/CIRCUIT DIAGNOSIS >

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting plural units with 2 communication lines.
- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

SIDE RADAR RH : DTC Logic

INFOID:0000000014225028

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|---|--|
| U1000 | CAN COMM CIRCUIT (CAN communication circuit) | If Side radar RH is not transmitting or receiving ITS communication signal for 2 seconds or more |

POSSIBLE CAUSE

ITS communication system

FAIL-SAFE

The following systems are canceled.

- Blind Spot Warning (BSW)
- Rear Cross Traffic Alert (RCTA)
- Blind Spot Intervention
- Back-up Collision Intervention (BCI)

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the Blind Spot Intervention system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [BRC-277, "SIDE RADAR RH : Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

SIDE RADAR RH : Diagnosis Procedure

INFOID:0000000014225029

1. PERFORM THE SELF-DIAGNOSIS

1. Start the engine.
2. Turn the Blind Spot Intervention system ON, and then wait for 30 seconds or more.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "SIDE RADAR RIGHT".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [LAN-28, "Trouble Diagnosis Flow Chart"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

DRIVER ASSISTANCE BUZZER CONTROL MODULE

DRIVER ASSISTANCE BUZZER CONTROL MODULE : Description

INFOID:0000000014225030

ITS COMMUNICATION

- ITS communication is a multiplex communication system. This enables the system to transmit and receive large quantities of data at high speed by connecting control units with 2 communication lines.
- ITS communication lines adopt twisted-pair line style (two lines twisted) for noise immunity.

DRIVER ASSISTANCE BUZZER CONTROL MODULE : DTC Logic

INFOID:0000000014225031

DTC DETECTION LOGIC

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|---|--|
| U1000 | CAN COMM CIRCUIT (CAN communication circuit) | If driver assistance buzzer control module is not transmitting or receiving ITS communication signal for 2 seconds or more |

POSSIBLE CAUSE

ITS communication system

FAIL-SAFE

None

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the MAIN switch of ICC system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS".

Is "U1000" detected as the current malfunction?

YES >> Refer to [BRC-278, "DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure

INFOID:000000014225032

1. PERFORM THE SELF-DIAGNOSIS

1. Turn the ignition switch ON.
2. Turn the MAIN switch of ICC system ON, and then wait for 2 seconds or more.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "BSW/BUZZER".

Is "U1000" detected as the current malfunction?

YES >> Refer to [LAN-28, "Trouble Diagnosis Flow Chart"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

U1010 CONTROL UNIT (CAN)

[FORWARD EMERGENCY BRAKING]

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN) ACCELERATOR PEDAL ACTUATOR

ACCELERATOR PEDAL ACTUATOR : Description

INFOID:0000000014225033

CAN controller controls the communication of ITS communication signal and the error detection.

ACCELERATOR PEDAL ACTUATOR : DTC Logic

INFOID:0000000014225034

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|--|---|
| U1010 | CONTROL UNIT (CAN) [Control unit (CAN)] | If accelerator pedal actuator detects malfunction by CAN controller initial diagnosis |

POSSIBLE CAUSE

Accelerator pedal actuator

FAIL-SAFE

The following systems are canceled.

- Vehicle-to-vehicle distance control mode
- Distance Control Assist (DCA)
- Forward Emergency Braking (FEB)
- Back-up Collision Intervention (BCI)

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the DCA system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [BRC-279, "ACCELERATOR PEDAL ACTUATOR : Diagnosis Procedure"](#).
 NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
 NO-2 >> Confirmation after repair: INSPECTION END

ACCELERATOR PEDAL ACTUATOR : Diagnosis Procedure

INFOID:0000000014225035

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the DCA system ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "ACCELERATOR PEDAL ACT".

Is "U1010" detected as the current malfunction?

- YES >> Replace the accelerator pedal actuator. Refer to [DAS-400, "Removal and Installation"](#).
 NO >> INSPECTION END

LANE CAMERA UNIT

LANE CAMERA UNIT : Description

INFOID:0000000014225036

CAN controller controls the communication of ITS communication signal and the error detection.

LANE CAMERA UNIT : DTC Logic

INFOID:0000000014225037

DTC DETECTION LOGIC

U1010 CONTROL UNIT (CAN)

[FORWARD EMERGENCY BRAKING]

< DTC/CIRCUIT DIAGNOSIS >

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|--|---|
| U1010 | CONTROL UNIT (CAN) [Control unit (CAN)] | If lane camera unit detects malfunction by CAN controller initial diagnosis |

POSSIBLE CAUSE

Lane camera unit

FAIL-SAFE

The following systems are canceled.

- Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)
- Blind Spot Warning (BSW)/Blind Spot Intervention

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the LDP system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS".

Is "U1010" detected as the current malfunction?

YES >> Refer to [BRC-280. "LANE CAMERA UNIT : Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

LANE CAMERA UNIT : Diagnosis Procedure

INFOID:000000014225038

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the LDP system ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "LANE CAMERA".

Is "U1010" detected as the current malfunction?

YES >> Replace the lane camera unit. Refer to [DAS-409. "Removal and Installation"](#).

NO >> INSPECTION END

SIDE RADAR LH

SIDE RADAR LH : Description

INFOID:000000014225039

CAN controller controls the communication of ITS communication signal and the error detection.

SIDE RADAR LH : DTC Logic

INFOID:000000014225040

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|--|---|
| U1010 | CONTROL UNIT (CAN) [Control unit (CAN)] | If side radar LH detects malfunction by CAN controller initial diagnosis. |

POSSIBLE CAUSE

Side radar LH

FAIL-SAFE

The following systems are canceled.

- Blind Spot Warning (BSW)
- Rear Cross Traffic Alert (RCTA)
- Blind Spot Intervention
- Back-up Collision Intervention (BCI)

DTC CONFIRMATION PROCEDURE

U1010 CONTROL UNIT (CAN)

[FORWARD EMERGENCY BRAKING]

< DTC/CIRCUIT DIAGNOSIS >

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the Blind Spot Intervention system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [BRC-281, "SIDE RADAR LH : Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

SIDE RADAR LH : Diagnosis Procedure

INFOID:0000000014225041

1. CHECK SELF-DIAGNOSIS RESULT

1. Turn the Blind Spot Intervention system ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "SIDE RADAR LEFT".

Is "U1010" detected as the current malfunction?

- YES >> Replace the side radar LH. [DAS-402, "Removal and Installation"](#).
- NO >> INSPECTION END

SIDE RADAR RH

SIDE RADAR RH : Description

INFOID:0000000014225042

CAN controller controls the communication of ITS communication signal and the error detection.

SIDE RADAR RH : DTC Logic

INFOID:0000000014225043

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|--|---|
| U1010 | CONTROL UNIT (CAN) [Control unit (CAN)] | If Side radar RH detects malfunction by CAN controller initial diagnosis. |

POSSIBLE CAUSE

Side radar RH

FAIL-SAFE

The following systems are canceled.

- Blind Spot Warning (BSW)
- Rear Cross Traffic Alert (RCTA)
- Blind Spot Intervention
- Back-up Collision Intervention (BCI)

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the Blind Spot Intervention system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [BRC-282, "SIDE RADAR RH : Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

U1010 CONTROL UNIT (CAN)

[FORWARD EMERGENCY BRAKING]

< DTC/CIRCUIT DIAGNOSIS >

SIDE RADAR RH : Diagnosis Procedure

INFOID:0000000014225044

1. CHECK SELF-DIAGNOSIS RESULT

1. Turn the Blind Spot Intervention system ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "SIDE RADAR RIGHT".

Is "U1010" detected as the current malfunction?

- YES >> Replace the side radar RH. [DAS-402, "Removal and Installation"](#).
NO >> INSPECTION END

DRIVER ASSISTANCE BUZZER CONTROL MODULE

DRIVER ASSISTANCE BUZZER CONTROL MODULE : Description

INFOID:0000000014225045

CAN controller controls the communication of ITS communication signal and the error detection.

DRIVER ASSISTANCE BUZZER CONTROL MODULE : DTC Logic

INFOID:0000000014225046

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|--|--|
| U1010 | CONTROL UNIT (CAN) [Control unit (CAN)] | If driver assistance buzzer control module detects malfunction by CAN controller initial diagnosis |

POSSIBLE CAUSE

Driver assistance buzzer control module

FAIL-SAFE

None

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the MAIN switch of ICC system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U1000" is detected as the current malfunction in "Self Diagnostic Result" of "ICC/ADAS".

Is "U1000" detected as the current malfunction?

- YES >> Refer to [BRC-282, "DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure"](#).
NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
NO-2 >> Confirmation after repair: INSPECTION END

DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure

INFOID:0000000014225047

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn the MAIN switch of ICC system ON.
2. Perform "All DTC Reading" with CONSULT.
3. Check if the "U1010" is detected as the current malfunction in "Self Diagnostic Result" of "BSW/BUZZER".

Is "U1010" detected as the current malfunction?

- YES >> Replace the driver assistance buzzer control module. Refer to [DAS-404, "Removal and Installation"](#).
NO >> INSPECTION END

U0104 ADAS CAN 1

< DTC/CIRCUIT DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

U0104 ADAS CAN 1

SIDE RADAR

SIDE RADAR : DTC Logic

INFOID:000000014225048

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|--|--|
| U0104 | ADAS CAN CIR1 (ADAS control unit CAN circuit 1) | Side radar detected an error of ITS communication signal that was received from ADAS control unit. |

POSSIBLE CAUSE

ADAS control unit

FAIL-SAFE

The following systems are canceled.

- Blind Spot Warning (BSW)
- Blind Spot Intervention
- Back-up Collision Intervention (BCI)

DTC CONFIRMATION PROCEDURE

1.CHECK DTC PRIORITY

If DTC "U0104" is displayed with DTC "U1000", first diagnose the DTC "U1000".

Is applicable DTC detected?

YES >> Perform diagnosis of applicable. Refer to [BRC-276, "SIDE RADAR LH : DTC Logic"](#) (SIDE RADAR LH) or [BRC-277, "SIDE RADAR RH : DTC Logic"](#) (SIDE RADAR RH).

NO >> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the Blind Spot Intervention system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the U0104 is detected as the current malfunction in "Self Diagnostic Result" of "SIDE RADAR RIGHT/LEFT".

Is the DTC "U0104" detected?

YES >> Refer to [BRC-283, "SIDE RADAR : Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

SIDE RADAR : Diagnosis Procedure

INFOID:000000014225049

1.CHECK DTC PRIORITY

If DTC "U0104" is displayed with DTC "U1000", first diagnose the DTC "U1000".

Is applicable DTC detected?

YES >> Perform diagnosis of applicable. Refer to [BRC-276, "SIDE RADAR LH : DTC Logic"](#) (SIDE RADAR LH) or [BRC-277, "SIDE RADAR RH : DTC Logic"](#) (SIDE RADAR RH).

NO >> GO TO 2.

2.CHECK ADAS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ICC/ADAS".

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [DAS-261, "DTC Index"](#).

NO >> Replace side radar LH or RH. Refer to [DAS-402, "Removal and Installation"](#)

DRIVER ASSISTANCE BUZZER CONTROL MODULE

U0104 ADAS CAN 1

< DTC/CIRCUIT DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

DRIVER ASSISTANCE BUZZER CONTROL MODULE : DTC Logic

INFOID:000000014225050

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|---|--|
| U0104 | ADAS CAN CIR 1 (ADAS control unit CAN circuit 1) | If driver assistance buzzer control module detects an error signal that is received from ADAS control unit via ITS communication |

POSSIBLE CAUSE

ADAS control unit

FAIL-SAFE

None

DTC CONFIRMATION PROCEDURE

CHECK DTC PRIORITY

1.CHECK DTC PRIORITY

If DTC "U0104" is displayed with DTC "U1000", first diagnose the DTC "U1000".

Is applicable DTC detected?

YES >> Perform diagnosis of applicable. Refer to [BRC-277, "DRIVER ASSISTANCE BUZZER CONTROL MODULE : DTC Logic"](#).

NO >> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the MAIN switch of ICC system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U0104" is detected as the current malfunction in "Self Diagnostic Result" of "BSW/BUZZER".

Is "U0104" detected as the current malfunction?

YES >> Refer to [BRC-284, "DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

DRIVER ASSISTANCE BUZZER CONTROL MODULE : Diagnosis Procedure

INFOID:000000014225051

1.CHECK DTC PRIORITY

If DTC "U0104" is displayed with DTC "U1000", first diagnose the DTC "U1000".

Is applicable DTC detected?

YES >> Perform diagnosis of applicable. Refer to [BRC-277, "DRIVER ASSISTANCE BUZZER CONTROL MODULE : DTC Logic"](#).

NO >> GO TO 2.

2.CHECK ADAS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ICC/ADAS".

Is any DTC detected?

YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [DAS-280, "DTC Index"](#).

NO >> Replace the driver assistance buzzer control module. Refer to [DAS-404, "Removal and Installation"](#).

U0126 STRG SEN CAN 1

< DTC/CIRCUIT DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

U0126 STRG SEN CAN 1

LANE CAMERA UNIT

LANE CAMERA UNIT : DTC Logic

INFOID:000000014225052

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|---|---|
| U0126 | STRG SEN CAN CIR1 (Steering angle sensor CAN circuit1) | If lane camera unit detects an error signal that is received from steering angle sensor via ADAS control unit |

POSSIBLE CAUSE

Steering angle sensor

FAIL-SAFE

The following systems are canceled.

- Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)
- Blind Spot Warning (BSW)/Blind Spot Intervention

DTC CONFIRMATION PROCEDURE

1.CHECK DTC PRIORITY

If DTC "U0126" is displayed with DTC "U1000", first diagnose the DTC "U1000".

Is applicable DTC detected?

- YES >> Perform diagnosis of applicable. Refer to [BRC-275, "LANE CAMERA UNIT : DTC Logic"](#).
NO >> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the LDP system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U0126" is detected as the current malfunction in "Self Diagnostic Result" of "LANE CAMERA".

Is "U0126" detected as the current malfunction?

- YES >> Refer to [BRC-285, "LANE CAMERA UNIT : Diagnosis Procedure"](#).
NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
NO-2 >> Confirmation after repair: INSPECTION END

LANE CAMERA UNIT : Diagnosis Procedure

INFOID:000000014225053

1.CHECK DTC PRIORITY

If DTC "U0126" is displayed with DTC "U1000", first diagnose the DTC "U1000".

Is applicable DTC detected?

- YES >> Perform diagnosis of applicable. Refer to [BRC-275, "LANE CAMERA UNIT : DTC Logic"](#).
NO >> GO TO 2.

2.CHECK ADAS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ICC/ADAS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [DAS-261, "DTC Index"](#).
NO >> Replace the lane camera unit. Refer to [DAS-170, "Removal and Installation"](#).

U0405 ADAS CAN 2

SIDE RADAR

SIDE RADAR : DTC Logic

INFOID:000000014225054

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|--|--|
| U0405 | ADAS CAN CIR2 (ADAS control unit CAN circuit 2) | Side radar detected an error of ITS communication signal that was received from ADAS control unit. |

POSSIBLE CAUSE

ADAS control unit.

FAIL-SAFE

The following systems are canceled.

- Blind Spot Warning (BSW)
- Rear Cross Traffic Alert (RCTA)
- Blind Spot Intervention
- Back-up Collision Intervention (BCI)

DTC CONFIRMATION PROCEDURE

1.CHECK DTC PRIORITY

If DTC “U0405” is displayed with DTC “U1000”, first diagnose the DTC “U1000”.

Is applicable DTC detected?

- YES >> Perform diagnosis of applicable. Refer to [BRC-276, "SIDE RADAR LH : DTC Logic"](#) (SIDE RADAR LH) or [BRC-277, "SIDE RADAR RH : DTC Logic"](#) (SIDE RADAR RH).
- NO >> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the Blind Spot Intervention system ON.
3. Perform “All DTC Reading” with CONSULT.
4. Check if the U0405 is detected as the current malfunction in “Self Diagnostic Result” of “SIDE RADAR RIGHT/LEFT”.

Is the DTC “U0405” detected?

- YES >> Refer to [BRC-286, "SIDE RADAR : Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

SIDE RADAR : Diagnosis Procedure

INFOID:000000014225055

1.CHECK DTC PRIORITY

If DTC “U0405” is displayed with DTC “U1000”, first diagnose the DTC “U1000”.

Is applicable DTC detected?

- YES >> Perform diagnosis of applicable. Refer to [BRC-276, "SIDE RADAR LH : DTC Logic"](#) (SIDE RADAR LH) or [BRC-277, "SIDE RADAR RH : DTC Logic"](#) (SIDE RADAR RH).
- NO >> GO TO 2.

2.CHECK ADAS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in “Self Diagnostic Result” of “ICC/ADAS”.

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [BRC-274, "ACCELERATOR PEDAL ACTUATOR : DTC Logic"](#).
- NO >> Replace side radar LH or RH. Refer to [DAS-402, "Removal and Installation"](#).

U0428 STRG SEN CAN 2

< DTC/CIRCUIT DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

U0428 STRG SEN CAN 2

LANE CAMERA UNIT

LANE CAMERA UNIT : DTC Logic

INFOID:000000014225056

DTC DETECTION LOGIC

| DTC | Trouble diagnosis name | DTC detecting condition |
|-------|---|---|
| U0428 | STRG SEN CAN CIR2 (Steering angle sensor CAN circuit2) | If lane camera unit detects an error signal that is received from steering angle sensor via ADAS control unit |

POSSIBLE CAUSE

Steering angle sensor

FAIL-SAFE

The following systems are canceled.

- Lane Departure Warning (LDW)/Lane Departure Prevention (LDP)
- Blind Spot Warning (BSW)/Blind Spot Intervention

DTC CONFIRMATION PROCEDURE

1.CHECK DTC PRIORITY

If DTC "U0428" is displayed with DTC "U1000", first diagnose the DTC "U1000".

Is applicable DTC detected?

- YES >> Perform diagnosis of applicable. Refer to [BRC-275, "LANE CAMERA UNIT : DTC Logic"](#).
NO >> GO TO 2.

2.PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Turn the LDP system ON.
3. Perform "All DTC Reading" with CONSULT.
4. Check if the "U0428" is detected as the current malfunction in "Self Diagnostic Result" of "LANE CAMERA".

Is "U0428" detected as the current malfunction?

- YES >> Refer to [BRC-287, "LANE CAMERA UNIT : Diagnosis Procedure"](#).
NO-1 >> To check malfunction symptom before repair: Refer to [GI-50, "Intermittent Incident"](#).
NO-2 >> Confirmation after repair: INSPECTION END

LANE CAMERA UNIT : Diagnosis Procedure

INFOID:000000014225057

1.CHECK DTC PRIORITY

If DTC "U0428" is displayed with DTC "U1000", first diagnose the DTC "U1000".

Is applicable DTC detected?

- YES >> Perform diagnosis of applicable. Refer to [BRC-275, "LANE CAMERA UNIT : DTC Logic"](#).
NO >> GO TO 2.

2.CHECK ADAS CONTROL UNIT SELF-DIAGNOSIS RESULTS

Check if any DTC is detected in "Self Diagnostic Result" of "ICC/ADAS".

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the malfunctioning parts. Refer to [DAS-261, "DTC Index"](#).
NO >> Replace the lane camera unit. Refer to [DAS-170, "Removal and Installation"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000014204035

1.CHECK FUSES

Check if any of the following fuses are blown:

| Signal name | Fuse No. |
|-----------------------|----------|
| Ignition power supply | 30 |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK LANE CAMERA UNIT POWER SUPPLY CIRCUIT

Check voltage between lane camera unit harness connector and ground.

| Terminal | | Condition | Voltage (Approx.) |
|------------------|----------|-----------|-------------------|
| (+) | (-) | | |
| Lane camera unit | | Ground | Ignition switch |
| Connector | Terminal | | |
| R6 | 3 | | |
| | | OFF | 0 V |
| | | ON | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the lane camera unit power supply circuit.

3.CHECK LANE CAMERA UNIT GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect the lane camera unit connector.
3. Check for continuity between lane camera unit harness connector and ground.

| Lane camera unit | | Ground | Continuity |
|------------------|----------|--------|------------|
| Connector | Terminal | | |
| R6 | 1 | | Yes |

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair the lane camera unit ground circuit.

FORWARD EMERGENCY BRAKING

< DTC/CIRCUIT DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

FORWARD EMERGENCY BRAKING

Diagnosis Procedure

INFOID:000000014170335

1. FORWARD EMERGENCY BRAKE DIAGNOSIS

- The system will be cancelled automatically with a beep sound and FEB warning lamp on the combination meter will illuminate, when the system will not operate properly.
- When the FEB warning lamp continues to illuminate even if the FEB system is turned on after the engine restarts, perform the trouble-diagnosis.

>> Go to ICC. Refer to [CCS-79. "Work Flow"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BRC

SYSTEM SETTINGS CANNOT BE TURNED ON/OFF ON THE INTEGRAL SWITCH

< SYMPTOM DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

SYMPTOM DIAGNOSIS

SYSTEM SETTINGS CANNOT BE TURNED ON/OFF ON THE INTEGRAL SWITCH

Symptom Table

INFOID:0000000014237581

CAUTION:

Perform the "Self Diagnostic Result" with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

| Symptom | | Inspection item/Reference page |
|---------------------------------|--|--|
| FEB system does not turn ON/OFF | FEB warning lamp is not turned ON↔OFF when operating integral switch | BRC-290. "Diagnosis Procedure" |

Description

INFOID:0000000014237582

FEB system does not turn ON/OFF.

- FEB warning lamp does not illuminate even if the integral switch is operated when FEB warning lamp is not illuminated.
- FEB warning lamp does not turn off even if the integral switch is operated when FEB warning lamp is illuminated.

NOTE:

The system ON/OFF condition will be memorized even if the ignition switch turns OFF.

Diagnosis Procedure

INFOID:0000000014237583

1.PERFORM SELF DIAGNOSTIC RESULT (LASER/RADAR)

1. Select "Self Diagnostic Result" mode of "ICC/ADAS" with CONSULT.
2. Check if the DTC is detected in "Self Diagnostic Result" mode of "ICC/ADAS" with CONSULT. Refer to [CCS-60. "DTC Index"](#).

Is any DTC detected?

YES >> GO TO 9.

NO >> GO TO 2.

2.STEERING SWITCH INSPECTION

1. Start the engine.
2. Check that "FEB SELECT" operates normally in "Data Monitor" of "LASER/RADAR" with CONSULT.

Is inspection result normal?

YES >> GO TO 6.

NO >> GO TO 3.

3.CHECK STEERING SWITCH RESISTANCE

Check resistance between the following steering switch terminals:

| Steering switches | | Condition | Resistance (Ω) (Approx.) |
|-------------------|-------------|--------------------|-----------------------------|
| Terminal | Signal name | | |
| 14 | Display | Depress ▷ switch. | 2023 |
| | Back | Depress ◁ switch. | 723 |
| 15 | Enter | Depress OK switch. | 2023 |
| | Menu Up | Depress △ switch. | 121 |
| | Menu Down | Depress ▽ switch. | 321 |

Is the inspection result normal?

YES >> GO TO 4.

SYSTEM SETTINGS CANNOT BE TURNED ON/OFF ON THE INTEGRAL SWITCH

< SYMPTOM DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

NO >> Replace steering wheel switch. Refer to [CCS-190, "Removal and Installation"](#).

4. CHECK SPIRAL CABLE

Check continuity between the following spiral cable terminals:

| Spiral cable | | Continuity |
|--------------|----|------------|
| Terminal | | |
| 14 | 24 | Yes |
| 15 | 31 | |
| 17 | 33 | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace spiral cable. Refer to [SR-15, "Removal and Installation"](#).

5. CHECK STEERING SWITCH CIRCUIT

- Turn ignition switch OFF.
- Disconnect combination meter harness connector M24 and spiral cable harness connector M30.
- Check continuity between combination meter harness connector M24 and spiral cable harness connector M30.

| Combination meter | | Spiral cable | | Continuity |
|-------------------|----------|--------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M24 | 3 | M30 | 24 | Yes |
| | 4 | | 31 | |
| | 24 | | 33 | |

- Check continuity between combination meter harness connector M24 and ground.

| Combination meter | | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector | Terminal | | |
| M24 | 3 | Ground | No |
| | 4 | | |
| | 24 | | |

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness or connector.

6. PERFORM THE DIAGNOSTIC RESULT (METER/M&A)

- Select "Self Diagnostic Result" mode of "METER/M&A" with CONSULT.
- Check if the DTC is detected in "Self Diagnostic Result" mode of "METER/M&A" with CONSULT. Refer to [MWI-26, "DTC Index"](#).

Is any DTC detected?

YES >> GO TO 9.

NO >> GO TO 7.

7. FEB WARNING LAMP

- Select the active test item "METER LAMP" of "ICC/ADAS".
- Check if the FEB warning lamp illuminates when the test item is operated.

Is inspection result normal?

YES >> Refer to [CCS-79, "Work Flow"](#).

NO >> GO TO 8.

8. CHECK DATA MONITOR OF COMBINATION METER

Check that "BA W/L operates normally in "Data Monitor""METER/M&A".

SYSTEM SETTINGS CANNOT BE TURNED ON/OFF ON THE INTEGRAL SWITCH

< SYMPTOM DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

Is inspection result normal?

YES >> Replace the combination meter. Refer to [MWI-94, "Removal and Installation"](#).

NO >> Replace the ICC sensor. Refer to [CCS-188, "Removal and Installation"](#).

9.REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace malfunctioning parts.

>> GO TO 10.

10.CHECK FEB SYSTEM

Check that FEB warning lamp turned ON⇔OFF, when operating steering switch.

>> Inspection End.

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[FORWARD EMERGENCY BRAKING]

NORMAL OPERATING CONDITION

Description

INFOID:000000014204034

LANE CAMERA UNIT HANDLING

To maintain the proper operation of the FEB systems and prevent a system malfunction, be sure to observe the following:

- Always keep the windshield clean.
- Do not attach a sticker (including transparent material) or install an accessory near the lane camera unit.
- Do not place reflective materials, such as white paper or a mirror, on the instrument panel. The reflection of sunlight may adversely affect the lane camera unit's detection capability.
- Do not strike or damage the areas around the camera unit. Do not touch the camera lens or remove the screw located on the camera unit.

PRECAUTIONS FOR FORWARD EMERGENCY BRAKING

- The forward emergency braking system is a supplemental aid to the driver. It is not a replacement for the driver's attention to traffic conditions or responsibility to drive safely. It cannot prevent accidents due to carelessness or dangerous driving techniques.
- The forward emergency braking system does not function in all driving, traffic, weather and road conditions.
- The lane camera unit does not detect the following objects:
 - Children and other people who are of short stature, animals, and bicycles
 - Pedestrians walking at night or in dark areas such as tunnels
 - Oncoming vehicles
 - Crossing vehicles
 - Vehicles parked diagonally
- The lane camera unit may not detect a vehicle or pedestrian ahead in the following conditions:
 - Visibility is poor because of bad weather conditions such as rain, snow, fog, dust storms, sandstorms, and snowstorms.
 - Snow, sand or road spray from traveling vehicles.
 - The windshield in front of the camera is covered with dirt, water drops, ice, snow, etc.
 - The windshield in front of the camera is fogged up.
 - Strong light (for example, sunlight or high beams from oncoming vehicles) enters from the front.
 - The headlamps did not illuminate during the nighttime or in a tunnel, or the headlamp lenses are extremely dirty.
 - Both tail lamps of the vehicle ahead do not illuminate at night or inside a tunnel.
 - When a sudden change in brightness occurs. (For example, when the vehicle enters or exits a tunnel or a shaded area.)
 - On roads where there are sharp curves.
 - The vehicle drives on a slope where the gradient changes.
 - The vehicle drives on a bumpy road surface, such as an uneven dirt road.
 - The system cannot recognize the outline of a person because the pedestrian is carrying large luggage or is wearing clothes that are the same color as the background.
- Depending on the ambient noise, the audible warning may not be heard.
- In the following conditions, the system may not be able to function normally:
 - The vehicle is driven on a slippery road.
 - The vehicle drives on a slope.
 - When excessively heavy baggage is loaded in the rear seat or the luggage room of own vehicle.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P