

SECTION STC

STEERING CONTROL SYSTEM

CONTENTS

BASIC INSPECTION	2	Diagnosis Procedure	12
DIAGNOSIS AND REPAIR WORK FLOW	2	ECU DIAGNOSIS INFORMATION	14
Work Flow	2	POWER STEERING CONTROL UNIT	14
SYSTEM DESCRIPTION	3	Reference Value	14
EPS SYSTEM	3	Wiring Diagram - ELECTRONICALLY CON-	
System Diagram	3	TROLLED POWER STEERING SYSTEM -	16
System Description	3	Fail-Safe	20
Component Parts Location	5	SYMPTOM DIAGNOSIS	22
Component Description	5	UNBALANCE STEERING WHEEL TURNING	
DTC/CIRCUIT DIAGNOSIS	6	FORCE (TORQUE VARIATION)	22
POWER SUPPLY AND GROUND CIRCUIT	6	Description	22
Description	6	Diagnosis Procedure	22
Diagnosis Procedure	6	PRECAUTION	23
POWER STEERING SOLENOID VALVE	7	PRECAUTIONS	23
Description	7	Precaution for Supplemental Restraint System	
Diagnosis Procedure	7	(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-	
Component Inspection	8	SIONER"	23
ENGINE SPEED SIGNAL CIRCUIT	9	Precautions for Removing Battery Terminal	23
Description	9		
Diagnosis Procedure	9	REMOVAL AND INSTALLATION	24
VEHICLE SPEED SIGNAL CIRCUIT	12	POWER STEERING CONTROL UNIT	24
Description	12	Removal and Installation	24

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000010580110

DETAILED FLOW

1. COLLECT THE INFORMATION FROM THE CUSTOMER

It is also important to clarify customer complaints before inspection. First of all, reproduce symptoms and understand them fully. Ask customer about his/her complaints carefully. In some cases, it is necessary to check symptoms by driving vehicle with customer.

CAUTION:

Customers are not professional. It is dangerous to make an easy guess like “maybe the customer means that...,” or “maybe the customer mentions this symptom”.

>> GO TO 2.

2. CHECK THE STATUS

1. Power steering fluid leakage and check the power steering fluid level. Refer to [ST-12, "Inspection"](#).
2. Check the drive belt tension. Refer to [EM-15, "Checking"](#) (VQ37VHR), [EM-173, "Checking"](#) (VK50VE).
3. Check the power steering gear for damages, cracks and fluid leakage. Refer to [ST-34, "Inspection"](#).
4. Check the relief oil pressure. Refer to [ST-40, "VQ37VHR : Inspection"](#) (VQ37VHR), [ST-46, "VK50VE : Inspection"](#) (VK50VE).

>> GO TO 3.

3. DIAGNOSIS CHART BY SYMPTOM

Perform the diagnosis by symptom. Refer to [STC-22, "Diagnosis Procedure"](#).

>> GO TO 4.

4. FINAL CHECK

Check the input/output standard values for the power steering control unit.

Are the power steering control unit input/output values within standard ranges respectively?

YES >> INSPECTION END
NO >> GO TO 2.

EPS SYSTEM

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

EPS SYSTEM

System Diagram


INFOID:0000000010580111

CONTROL DIAGRAM



JSGIA0258GB

CROSS-SECTIONAL VIEW



JSGIA0376ZZ

1. Unified meter and A/C amp.
2. Power steering control unit
3. Power steering solenoid valve
4. Steering gear assembly
5. Gear housing assembly
6. Gear sub-assembly
7. Pinion
8. Power steering oil pump
9. Reservoir tank

System Description


INFOID:0000000010580112

- The EPS system controls the power steering solenoid valve through the power steering control unit.

EPS SYSTEM


< SYSTEM DESCRIPTION >

- The valve driving voltage to control the power steering solenoid valve varies according to the vehicle speed.




OPERATION PRINCIPLE

During Parking (When Turning The Steering Wheel To The Right.)



1. Power steering solenoid valve is closed while a vehicle is stopped.
2. Pinion "1R", "2R" and "3R" are closed depending on steering torque of steering wheel.
3. Oil pressure "P" in the gear housing assembly is the sum of oil pressures occurred in "2R" and "3R". This results in a light steering force because of high pressure.

During High-speed Operation




1. Power steering solenoid valve is opened during high-speed operation.
2. Pinion "1R", "2R" and "3R" are closed depending on steering torque of steering wheel.
3. Oil pressure "2R" does not occur because the power steering solenoid valve is on full throttle.
4. Oil pressure "P" in the gear housing assembly includes only oil pressure occurred in "3R" and results in a heavy steering force.

EPS SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000010580113



1. Power steering solenoid valve
 2. Power steering control unit
- A. Steering gear assembly B. Glove box assembly removed

◀: Vehicle front

Component Description

INFOID:000000010580114

Component parts	Reference/Function
Power steering control unit	<ul style="list-style-type: none">• Signals from various sensors control the driving voltage to the power steering solenoid valve.• The power steering control unit controls the driving voltage to the power steering solenoid valve for maintaining the power steering assist force when the fail-safe function is activated. (The engine speed signals control EPS system if any vehicle speed signal error is detected.)
Unified meter and A/C amp.	STC-12, "Description"
ECM	STC-9, "Description"
Power steering solenoid valve	STC-7, "Description"

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

Description

INFOID:0000000010580115

Power supply to EPS system

Diagnosis Procedure

INFOID:0000000010580116

1.CHECK POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect power steering control unit harness connector.
3. Check voltage between power steering control unit harness connector and ground.

Power steering control unit		—	Voltage
Connector	Terminal		
M108	3	Ground	0 V

4. Turn the ignition switch ON.

CAUTION:

Never start the engine.

5. Check voltage between power steering control unit harness connector and ground.

Power steering control unit		—	Voltage
Connector	Terminal		
M108	3	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check the following. If any items are damaged, repair or replace damaged parts.

- 10A fuses (#45) open
- Harness for short or open between ignition switch and power steering control unit harness connector No. 3 terminal.
- Ignition switch.

2.CHECK GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check continuity between power steering control unit harness connector and ground.

Power steering control unit		—	Continuity
Connector	Terminal		
M108	6	Ground	Existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair open circuit or short to power in harness or connectors.

3.CHECK TERMINALS AND HARNESS CONNECTORS

Check power steering control unit pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace damaged parts.

POWER STEERING SOLENOID VALVE

< DTC/CIRCUIT DIAGNOSIS >

POWER STEERING SOLENOID VALVE

Description

INFOID:0000000010580117

Power steering solenoid valve controls the power steering oil pressure in the gear housing assembly.

Diagnosis Procedure

INFOID:0000000010580118

1. CHECK POWER STEERING SOLENOID VALVE SIGNAL

Check voltage between power steering control unit harness connector and ground.

Power steering control unit		—	Condition	Voltage (Approx.)
Connector	Terminal			
M108	1	Ground	Vehicle speed: 0 km/h (0 MPH) (Engine is running)	4.4 – 6.6 V
			Vehicle speed: 100 km/h (62 MPH)	2.4 – 3.6 V

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 4.

2. CHECK HARNESS BETWEEN POWER STEERING SOLENOID VALVE AND POWER STEERING CONTROL UNIT

1. Turn the ignition switch OFF.
2. Disconnect power steering solenoid valve harness connector.
3. Disconnect power steering control unit harness connector.
4. Check the continuity between power steering solenoid valve harness connector and the power steering control unit harness connector.

Power steering solenoid valve		Power steering control unit		Continuity
Connector	Terminal	Connector	Terminal	
F45	1	M108	1	Existed
	2		5	Existed

5. Check continuity between power steering control unit harness connector and ground.

Power steering control unit		—	Continuity
Connector	Terminal		
M108	1	Ground	Existed
	5		Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace damaged parts.

3. CHECK POWER STEERING SOLENOID VALVE

Check power steering solenoid valve. Refer to [STC-8, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace gear-sub assembly. Refer to [ST-26, "Exploded View"](#).

4. CHECK TERMINALS AND HARNESS CONNECTORS

- Check power steering control unit pin terminals for damage or loose connection with harness connector.
- Check power steering solenoid valve pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> INSPECTION END

POWER STEERING SOLENOID VALVE

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace damaged parts.

Component Inspection

INFOID:0000000010580119

1. CHECK POWER STEERING SOLENOID VALVE

1. Turn the ignition switch OFF.
2. Disconnect power steering solenoid valve harness connector.
3. Check resistance between power steering solenoid valve connector terminals.

Power steering solenoid valve		Resistance (Approx.)
Terminal		
1	2	4 – 6 Ω

4. Check power steering solenoid valve by listening for its operation sound while applying battery voltage to power steering solenoid valve connector F45 terminals 1 (positive) and 2 (negative).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace gear-sub assembly. Refer to [ST-26, "Exploded View"](#).

ENGINE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

ENGINE SPEED SIGNAL CIRCUIT

Description

INFOID:0000000010580120

ECM sends engine speed signal to power steering control unit.

Diagnosis Procedure

INFOID:0000000010580121

1. PERFORM ECM SELF-DIAGNOSIS

With CONSULT

1. Turn the ignition switch ON.
2. Perform "ENGINE" self-diagnosis. Refer to [EC-157, "CONSULT Function"](#) (VQ37VHR FOR USA AND CANADA), [EC-750, "CONSULT Function"](#) (VQ37VHR FOR MEXICO), [EC-1264, "CONSULT Function"](#) (VK50VE).

Is any DTC detected?

YES >> Check the DTC.

NO >> GO TO 2.

2. CHECK HARNESS BETWEEN ECM AND POWER STEERING CONTROL UNIT

1. Turn the ignition switch OFF.
2. Disconnect ECM harness connectors.
3. Disconnect power steering control unit harness connector.
4. Check continuity between ECM harness connector and power steering control unit harness connector.

ECM		Power steering control unit		Continuity
Connector	Terminal	Connector	Terminal	
M164 (VQ37VHR)	110	M108	10	Existed
M160 (VK50VE)	97			

5. Check continuity between power steering control unit harness connector and ground.

Power steering control unit		—	Continuity
Connector	Terminal		
M108	10	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 3.



NO >> Repair or replace damaged parts.

3. CHECK ENGINE SPEED SIGNAL (1)

1. Connect ECM harness connectors.
2. Check signal between ECM harness connector and ground with oscilloscope.

ENGINE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

ECM		—	Condition	Voltage (Approx.)	
Connector	Terminal				
M164 (VQ37VHR) M160 (VK50VE)	110 (VQ37VHR) 97 (VK50VE)	Ground	Engine is running • Warm-up condition • Idle speed	 10mSec/div 2V/div	JMBIA0076GB
			Engine is running • Warm-up condition • Engine speed: Approx. 2,000 rpm	 10mSec/div 2V/div	JMBIA0077GB



Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace ECM. Refer to [EC-29, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(ECM\) : Description"](#) (VQ37VHR FOR USA AND CANADA), [EC-639, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(ECM\) : Description"](#) (VQ37VHR FOR MEXICO), [EC-1133, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(ECM\) : Description"](#) (VK50VE).

4.CHECK ENGINE SPEED SIGNAL (2)

1. Turn the ignition switch OFF.
2. Connect power steering control unit harness connector.
3. Check signal between power steering control unit harness connector and ground with oscilloscope.

Power steering control unit		—	Condition	Voltage (Approx.)	
Connector	Terminal				
M108	10	Ground	Engine is running • Warm-up condition • Idle speed	 10mSec/div 2V/div	JMBIA0076GB
			Engine is running • Warm-up condition • Engine speed: Approx. 2,000 rpm	 10mSec/div 2V/div	JMBIA0077GB

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace power steering control unit. Refer to [STC-24, "Removal and Installation"](#).

5.CHECK TERMINALS AND HARNESS CONNECTORS

- Check power steering control unit pin terminals for damage or loose connection with harness connector.
- Check ECM pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

ENGINE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

YES >> INSPECTION END

NO >> Repair or replace damaged parts.

A

B

C

D

E

F

STC

H

I

J

K

L

M

N

O

P

VEHICLE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

VEHICLE SPEED SIGNAL CIRCUIT

Description

INFOID:0000000010580122

Unified meter and A/C amp. sends vehicle speed signal to power steering control unit.

Diagnosis Procedure

INFOID:0000000010580123

1. PERFORM UNIFIED METER AND A/C AMP. SELF-DIAGNOSIS

With CONSULT

1. Turn the ignition switch ON.
2. Perform "METER/M&A" self-diagnosis. Refer to [MWI-45, "CONSULT Function \(METER/M&A\)".](#)

Is any DTC detected?

- YES >> Check the DTC.
NO >> GO TO 2.

2. CHECK HARNESS BETWEEN UNIFIED METER AND A/C AMP. AND POWER STEERING CONTROL UNIT

1. Turn the ignition switch OFF.
2. Disconnect unified meter and A/C amp. harness connector.
3. Disconnect power steering control unit harness connector.
4. Check continuity between unified meter and A/C amp. harness connector and power steering control unit harness connector.

Unified meter and A/C amp.		Power steering control unit		Continuity
Connector	Terminal	Connector	Terminal	
M66	8	M108	8	Existed

5. Check continuity between power steering control unit harness connector and ground.

Power steering control unit		—	Continuity
Connector	Terminal		
M108	8	Ground	Not existed

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace damaged parts.

3. CHECK VEHICLE SPEED SIGNAL (1)

1. Connect unified meter and A/C amp. harness connector.
2. Check unified meter and A/C amp. input/output standard values. Refer to [MWI-96, "Reference Value".](#)

Is the inspection result normal?


- YES >> GO TO 4.
NO >> Replace unified meter and A/C amp. Refer to [MWI-144, "Exploded View".](#)

4. CHECK VEHICLE SPEED SIGNAL (2)

1. Turn the ignition switch OFF.
2. Connect power steering control unit harness connector.
3. Check signal between power steering control unit harness connector and ground with oscilloscope.

VEHICLE SPEED SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Power steering control unit		—	Condition	Voltage (Approx.)
Connector	Terminal			
M108	8	Ground	<p>Vehicle speed: 40 km/h (25 MPH)</p> <p>CAUTION: Check air pressure of tire under standard condition.</p>	<p>NOTE: The maximum voltage varies depending on the specification (destination unit).</p>  <p>JSNIA0015GB</p>

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace power steering control unit. Refer to [STC-24, "Removal and Installation"](#).

5.CHECK TERMINALS AND HARNESS CONNECTORS

- Check power steering control unit pin terminals for damage or loose connection with harness connector.
- Check unified meter and A/C amp. pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace damaged parts.

A

B

C

D

E

F

STC

H

I

J

K

L

M

N

O

P

POWER STEERING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


ECU DIAGNOSIS INFORMATION

POWER STEERING CONTROL UNIT

Reference Value


INFOID:0000000010580124

TERMINAL LAYOUT





JSGIA0023ZZ

PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
1 (LG)	Ground	Power steering solenoid valve voltage	Output	Vehicle speed: 0 km/h (0 MPH) (Engine is running)	4.4 – 6.6 V
				Vehicle speed: 100 km/h (62 MPH)	2.4 – 3.6 V
3 (G)	Ground	Ignition switch power supply	Input	Ignition switch: ON	Battery voltage
				Ignition switch: OFF	0 V
5 (B)	Ground	Power steering solenoid valve ground	—	Always	0 V
6 (B)	Ground	Ground	—	Always	0 V
8 (L)	Ground	Vehicle speed signal	Input	Vehicle speed: 40 km/h (25 MPH) CAUTION: Check air pressure of tire under standard condition.	NOTE: The maximum voltage varies depending on the specification (destination unit).  <p>JSNIA0015GB</p>

POWER STEERING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
10 (R)	Ground	Engine speed signal	Input	Engine is running • Warm-up condition • Idle speed	 2V/div JMBIA0076GB
				Engine is running • Warm-up condition • Engine speed: Approx. 2,000 rpm	 2V/div JMBIA0077GB

CAUTION:

When using circuit tester or oscilloscope to measure voltage for inspection, be sure not to forcibly extend any connector terminals.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P
STC


POWER STEERING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM -

INFOID:0000000010580125

ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM



2014/03/18


JRGWC1257GB

POWER STEERING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM

Connector No.	B1
Connector Name	WIRE TO WIRE
Connector Type	TH40FW-CS16-TM4



Terminal Color Of Wire No.	Signal Name [Specification]
1 G	
2 L	
3 W	
6 G	
7 P	
8 BG	
10 SB	
11 SB	
12 B	
13 G	
14 R	
15 W	
16 SHIELD	
17 L	
18 P	
19 G	
20 W	
21 R	
22 Y	
23 G	
24 L	-[With CC]
25 G	-[Without CC]
26 R	-[Without CC]
27 Y	-[With CC]
28 BG	-
30 GR	-
36 G	-

Terminal Color Of Wire No.	Signal Name [Specification]
57 P	
58 L	
59 SHIELD	
60 L	
61 P	
62 GR	
63 G	
64 BG	
65 W	
66 V	
67 LG	
68 Y	
69 G	
70 GR	
71 G	
72 B	
73 W	
74 V	
75 BG	
76 LG	
77 L	
78 GR	
79 W	
80 L	
81 P	
82 L	
83 P	
84 SB	
85 R	
86 Y	
87 B	
88 GR	
91 R	
92 BG	
93 BR	
94 V	
96 BG	
97 W	
98 GR	
99 W	

Connector No.	E5
Connector Name	POWER INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	TH40FW-CS12-M4-IV
HS.	
6 W	-
7 G	-
8 V	-
9 R	-
10 BR	-
11 B	-
12 G	-
13 R	-
14 W	-
15 SHIELD	-
16 SB	-
17 L	-
18 P	-
19 G	-
20 W	-[With CC]
21 R	-[Without CC]
22 R	-[With CC]
23 V	-[Without CC]
24 L	-[With CC]
25 L	-[Without CC]
26 Y	-[With CC]
27 G	-
28 G	-
29 LG	-
30 BG	-
31 W	-
32 Y	-
33 BG	-
34 Y	-
35 R	-
36 SB	-
37 Y	-
38 GR	-
39 LG	-
40 P	-
41 LG	-
42 V	-
43 R	-
44 G	-
45 GR	-
46 W	-
47 L	-
48 P	-
49 SB	-
50 BR	-
51 B	-
52 BG	-
53 SB	-
54 BR	-
55 Y	-
56 SHIELD	-
57	-
58	-
59	-
60	-
61	-
62	-
63	-
64	-
65	-
66	-
67	-
68	-
69	-
70	-
71	-
72	-
73	-
74	-
75	-
76	-
77	-
78	-
79	-
80	-
81	-
82	-
83	-
84	-
85	-
86	-
87	-
88	-
89	-
90	-
91	-
92	-
93	-
94	-
95	-
96	-
97	-
98	-
99	-

Terminal Color Of Wire No.	Signal Name [Specification]
57 P	
58 L	
59 SHIELD	
60 L	
61 P	
62 GR	
63 G	
64 BG	
65 W	
66 V	
67 LG	
68 Y	
69 G	
70 GR	
71 G	
72 B	
73 W	
74 V	
75 BG	
76 LG	
77 L	
78 GR	
79 W	
80 L	
81 P	
82 L	
83 P	
84 SB	
85 R	
86 Y	
87 B	
88 GR	
91 R	
92 BG	
93 BR	
94 V	
96 BG	
97 W	
98 GR	
99 W	



JRGWC1258GB

POWER STEERING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM

Connector No.			Terminal Color Of Wire			Signal Name [Specification]			Terminal Color Of Wire			Signal Name [Specification]		
Connector No.	Terminal No.	Wire Color	1	2	3	1	2	3	4	5	6	7	8	9
F45	59	P	-	-	-	35	BR	-	-	-	-	23	G	-
	60	SB	-	-	-	36	W	-	-	-	-	24	L	- [With ICC]
	61	V	-	-	-	37	Y	-	-	-	-	24	P	- [Without ICC]
	62	P	-	-	-	38	Y	-	-	-	-	25	W	- [Without ICC]
	63	LG	-	-	-	43	P	-	-	-	-	25	Y	- [With ICC]
	64	L	-	-	-	44	L	-	-	-	-	26	SHIELD	-
	65	BG	-	-	-	45	Y	-	-	-	-	28	GR	-
	66	SHIELD	-	-	-	46	V	-	-	-	-	29	V	-
	69	L	-	-	-	-	-	-	-	-	-	30	BG	-
	71	G	-	-	-	-	-	-	-	-	-	32	W	-
	72	G	-	-	-	-	-	-	-	-	-	33	Y	-
	73	R	-	-	-	-	-	-	-	-	-	34	L	-
	74	BR	-	-	-	-	-	-	-	-	-	37	G	-
	76	L	-	-	-	-	-	-	-	-	-	38	R	-
	77	W	-	-	-	-	-	-	-	-	-	39	G	-
	78	Y	-	-	-	-	-	-	-	-	-	41	L	-
	80	SB	-	-	-	-	-	-	-	-	-	42	W	-
	81	L	-	-	-	-	-	-	-	-	-	43	R	-
	82	W	-	-	-	-	-	-	-	-	-	44	LG	-
	83	LG	-	-	-	-	-	-	-	-	-	45	GR	-
	84	GR	-	-	-	-	-	-	-	-	-	46	W	-
	85	G	-	-	-	-	-	-	-	-	-	47	L	-
	86	P	-	-	-	-	-	-	-	-	-	48	P	-
	87	W	-	-	-	-	-	-	-	-	-	49	BG	-
	88	BG	-	-	-	-	-	-	-	-	-	50	LG	-
	89	LG	-	-	-	-	-	-	-	-	-	51	SB	-
	90	BR	-	-	-	-	-	-	-	-	-	52	Y	-
	91	GR	-	-	-	-	-	-	-	-	-	53	BG	-
	92	BR	-	-	-	-	-	-	-	-	-	54	BR	-
	93	SB	-	-	-	-	-	-	-	-	-	55	SB	-
	95	Y	-	-	-	-	-	-	-	-	-	59	SB	-
	96	W	-	-	-	-	-	-	-	-	-	60	SB	-
	97	W	-	-	-	-	-	-	-	-	-	61	V	-
	98	SHIELD	-	-	-	-	-	-	-	-	-	62	P	-
	100	Y	-	-	-	-	-	-	-	-	-	63	R	-
												64	L	-
												65	BG	-
												66	V	-
												70	SHIELD	-
												71	BG	-
												72	GR	-
												73	W	-
												74	SB	-
												76	V	-
												77	V	-
												78	Y	-
												80	BG	-
												81	L	-
												82	W	-
												83	Y	-
												83	Y	- [With ICC]

JRGWC1259GB

POWER STEERING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM

Terminal Color Of No.	Signal Name [Specification]	Wire No.	Signal Name [Specification]	Wire No.
1	G - (With Auto arcon seat)	BG	MANUAL MODE SIGNAL (METER>>METER)	7
2	B	-	COMMUNICATION SIGNAL (CD->METER)	8
3	W	-	SEAT BELTBUCKLE SWITCH SIGNAL (DRIVER SIDE)	9
6	P	-	MANUAL MODE SIGNAL	10
7	V	-	NONMANUAL MODE SIGNAL	11
8	BG	-	COMMUNICATION SIGNAL (LCD->AMP)	14
10	W	-	TON SENSOR SIGNAL	20
11	BG	-	Y - AS SNOW SWITCH SIGNAL	23
12	B	-	MANUAL MODE SHIFT DOWN SIGNAL	25
13	G	-	PADDLE SHIFTER DOWN SIGNAL	26
14	R	-	COMMUNICATION SIGNAL (METER->AMP)	27
15	W	-	VEHICLE SPEED SIGNAL (PULSE)	28
16	SHEILD	-	PARKING BRAKE SWITCH SIGNAL	30
17	L	-	COMMUNICATION SIGNAL (AMP->LCD)	34
18	P	-	BLOWER MOTOR CONTROL SIGNAL	38
19	G	-		
20	R	-		
21	LG	-		
23	V	-		
24	P	-		
25	BR	-		
26	GR	-		
27	BG	-		
28	W	-		
38	B	-		
39	B	-		
43	SB	-		
44	W	-		
45	B	-		
51	V	-		
52	LG	-		
53	SHEILD	-		
54	BR	-		
55	Y	-		
56	SHEILD	-		
57	P	-		
58	L	-		
59	SHEILD	-		
60	L	-		
61	BR	-		
62	R	-		
63	Y	-		
64	L	-		
65	W	-		
66	V	-		
67	LG	-		
68	Y	-		
69	G	-		
70	V	-		
71	W	-		
72	B	-		
73	W	-		
74	LG	-		
75	P	-		
76	LG	-		
77	SB	-		
78	GR	-		
79	R	-		
80	L	-		
81	P	-		
82	L	-		
83	P	-		
84	SB	-		
85	W	-		
86	Y	-		
87	B	-		
88	G	-		
89	BG	-		

JRGWC1260GB

POWER STEERING CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

ELECTRONICALLY CONTROLLED POWER STEERING SYSTEM

Connector No.	M108	Connector No.	M164
Connector Name	POWER STEERING CONTROL UNIT	Connector Name	ECM
Connector Type	TH12PWNH	Connector Type	RH24FGY-RZB-R-LH-Z
			

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
29	LG	-	97	R	ACCELERATOR PEDAL POSITION SENSOR 1
31	W	-	98	P	ACCELERATOR PEDAL POSITION SENSOR (With NAVI)
34	LG	-	98	Y	ACCELERATOR PEDAL POSITION SENSOR 2 (With NAVI)
35	BR	-	99	G	SENSOR POWER SUPPLY (With NAVI)
36	W	-	99	L	SENSOR POWER SUPPLY (Without NAVI)
37	Y	-	100	W	SENSOR GROUND
38	BG	-	101	SB	ASCD/CC-STEERING SWITCH
43	P	-	102	LG	EVAP CONTROL SYSTEM PRESSURE SENSOR
44	L	-	103	G	SENSOR POWER SUPPLY (Without NAVI)
45	G	-	104	BR	SENSOR GROUND (With NAVI)
46	Y	-	104	GR	SENSOR GROUND (Without NAVI)

Connector No.	M160	Connector No.	M160
Connector Name	ECM	Connector Name	ECM
Connector Type	RH24FGY-RZB-R-LH-Z	Connector Type	RH24FGY-RZB-R-LH-Z
			

Terminal No.	Color Of Wire	Signal Name [Specification]	Terminal No.	Color Of Wire	Signal Name [Specification]
97	R	ENGINE SPEED SIGNAL OUTPUT	97	R	ENGINE SPEED SIGNAL OUTPUT
99	G	SENSOR POWER SUPPLY	99	G	SENSOR POWER SUPPLY
100	L	CAN COMMUNICATION LINE	100	L	CAN COMMUNICATION LINE
101	P	-	101	P	-
102	SB	ASCD/CC-STEERING SWITCH	102	SB	ASCD/CC-STEERING SWITCH
104	R	ACCELERATOR PEDAL POSITION SENSOR 1	104	R	ACCELERATOR PEDAL POSITION SENSOR 1
105	L	CAN COMMUNICATION LINE	105	L	CAN COMMUNICATION LINE
106	L	IGNITION SWITCH	106	L	IGNITION SWITCH
108	P	ACCELERATOR PEDAL POSITION SENSOR 2	108	P	ACCELERATOR PEDAL POSITION SENSOR 2
110	P	STOP LAMP SWITCH	110	P	STOP LAMP SWITCH
111	V	SENSOR GROUND	111	V	SENSOR GROUND
112	LG	FUEL PUMP CONTROL MODULE FAULT CHECK	112	LG	FUEL PUMP CONTROL MODULE FAULT CHECK
114	GR	DATA LINK CONNECTOR	114	GR	DATA LINK CONNECTOR
115	GR	SENSOR GROUND	115	GR	SENSOR GROUND
116	G	TRANSMISSION RANGE SWITCH	116	G	TRANSMISSION RANGE SWITCH
117	BR	ASCD/CC BRAKE SWITCH	117	BR	ASCD/CC BRAKE SWITCH
118	R	POWER SUPPLY FOR ECM (BACK-UP)	118	R	POWER SUPPLY FOR ECM (BACK-UP)
119	W	SENSOR GROUND	119	W	SENSOR GROUND
120	W	FUEL TANK TEMPERATURE SENSOR	120	W	FUEL TANK TEMPERATURE SENSOR
121	GR	POWER SUPPLY FOR ECM	121	GR	POWER SUPPLY FOR ECM
123	B	ECM GROUND	123	B	ECM GROUND
125	BR	ASCD/CC BRAKE SWITCH	125	BR	ASCD/CC BRAKE SWITCH
127	B	ECM GROUND	127	B	ECM GROUND
128	B	ECM GROUND	128	B	ECM GROUND

JRGWC1261GB

INFOID:0000000010580126

Fail-Safe

EPS system

POWER STEERING CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

- EPS system enters the fail-safe mode (that allows the steering force to be controlled without impairing the drivability) if any of the input/output values to/from EPS system (power steering control unit) deviate from the standard range.

NOTE:

The system enters the fail-safe mode if the engine speed remains at 1,500 rpm or more for over 10 seconds while the vehicle is stopped. This is normal.

- The fail-safe function is canceled when a vehicle speed signal of 2 km/h (1.2 MPH) or more is inputted or the ignition switch is turned OFF→ON. EPS system restores the normal operation at that time.



Mode	Warning lamp	DTC	Detection point (malfunction part)	Error area and root cause
Fail-safe	—	—	Vehicle speed signal input	<ul style="list-style-type: none"> Engine speed is 1,500 rpm or more and there is no vehicle speed signal input for over 10 seconds during vehicle travel. Vehicle speed signal has abruptly dropped from 30 km/h (19 MPH) or more to 2 km/h (1.2 MPH) or less within 1.4 seconds.

A
B
C
D
E
F

STC

H
I
J
K
L
M
N
O
P

UNBALANCE STEERING WHEEL TURNING FORCE (TORQUE VARIATION)

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

UNBALANCE STEERING WHEEL TURNING FORCE (TORQUE VARIATION)

Description

INFOID:0000000010580127

- Hard steering when fully turning the steering wheel.
- Light steering when driving at a high speed.

Diagnosis Procedure

INFOID:0000000010580128

1. CHECK SYSTEM FOR POWER SUPPLY AND GROUND

Perform trouble diagnosis for power supply and ground. Refer to [STC-6, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace damaged parts.

2. CHECK SYSTEM FOR VEHICLE SPEED SIGNAL

Perform trouble diagnosis for vehicle speed signal. Refer to [STC-12, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace damaged parts.

3. CHECK SYSTEM FOR ENGINE SPEED SIGNAL

Perform trouble diagnosis for engine speed signal. Refer to [STC-9, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace damaged parts.

4. CHECK SYSTEM FOR POWER STEERING SOLENOID VALVE

Perform trouble diagnosis for power steering solenoid valve. Refer to [STC-7, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Perform the symptom diagnosis for the steering system. Refer to [ST-3, "NVH Troubleshooting Chart"](#).
NO >> Repair or replace damaged parts.

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000010580129

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions for Removing Battery Terminal

INFOID:0000000010715433

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



SEF289H

POWER STEERING CONTROL UNIT

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

POWER STEERING CONTROL UNIT

Removal and Installation

INFOID:0000000010580130

REMOVAL

1. Remove instrument lower cover RH. Refer to [IP-12, "Exploded View"](#).
2. Remove instrument lower panel RH. Refer to [IP-12, "Exploded View"](#).
3. Remove power steering control unit.
4. Disconnect power steering control unit connector.

INSTALLATION

Install in the reverse order of removal.