

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

SECTION **VTL**

VENTILATION SYSTEM

CONTENTS

<p>PRECAUTION 3</p> <p>PRECAUTIONS 3</p> <p style="padding-left: 20px;">Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"3</p> <p style="padding-left: 20px;">Precautions for Removing of Battery Terminal3</p> <p style="padding-left: 20px;">Precaution for Procedure without Cowl Top Cover.....4</p> <p>PREPARATION 5</p> <p>PREPARATION 5</p> <p style="padding-left: 20px;">Commercial Service Tool5</p> <p>SYSTEM DESCRIPTION 6</p> <p>VENTILATION SYSTEM 6</p> <p>VENTILATION SYSTEM (FRONT AIR CONDITIONING)6</p> <p style="padding-left: 20px;">VENTILATION SYSTEM (FRONT AIR CONDITIONING) : System Description6</p> <p>VENTILATION SYSTEM (REAR AIR CONDITIONING)7</p> <p style="padding-left: 20px;">VENTILATION SYSTEM (REAR AIR CONDITIONING) : System Description7</p> <p>REMOVAL AND INSTALLATION 8</p> <p>DUCT AND GRILLE 8</p> <p style="padding-left: 20px;">Exploded View8</p> <p>CENTER VENTILATOR GRILLE 10</p> <p style="padding-left: 20px;">CENTER VENTILATOR GRILLE : Removal and Installation 10</p> <p>SIDE VENTILATOR GRILLE 10</p> <p style="padding-left: 20px;">SIDE VENTILATOR GRILLE : Removal and Installation 10</p> <p>FRONT DEFROSTER GRILLE 10</p>	<p style="padding-left: 20px;">FRONT DEFROSTER GRILLE : Removal and Installation10</p> <p>UPPER VENTILATOR GRILLE10</p> <p style="padding-left: 20px;">UPPER VENTILATOR GRILLE : Removal and Installation 10</p> <p>SIDE VENTILATOR DUCT10</p> <p style="padding-left: 20px;">SIDE VENTILATOR DUCT : Removal and Installation 10</p> <p>UPPER VENTILATOR DUCT10</p> <p style="padding-left: 20px;">UPPER VENTILATOR DUCT : Removal and Installation 10</p> <p>FRONT DEFROSTER NOZZLE11</p> <p style="padding-left: 20px;">FRONT DEFROSTER NOZZLE : Removal and Installation 11</p> <p>SIDE DEFROSTER NOZZLE11</p> <p style="padding-left: 20px;">SIDE DEFROSTER NOZZLE : Removal and Installation 11</p> <p>FLOOR DUCT 111</p> <p style="padding-left: 20px;">FLOOR DUCT 1 : Removal and Installation11</p> <p>FLOOR DUCT 211</p> <p style="padding-left: 20px;">FLOOR DUCT 2 : Removal and Installation 11</p> <p>FLOOR DUCT 311</p> <p style="padding-left: 20px;">FLOOR DUCT 3 : Removal and Installation11</p> <p>REAR FLOOR GRILLE12</p> <p style="padding-left: 20px;">REAR FLOOR GRILLE : Removal and Installation12</p> <p>FOOT DUCT12</p> <p style="padding-left: 20px;">FOOT DUCT : Removal and Installation 12</p> <p>FOOT GRILLE12</p> <p style="padding-left: 20px;">FOOT GRILLE : Removal and Installation 12</p> <p>REAR VENTILATOR DUCT LOWER12</p>
--	---

VTL

REAR VENTILATOR DUCT LOWER : Removal and Installation	12	FRONT A/C UNIT : Exploded View	16
REAR VENTILATOR DUCT LOWER : Removal and Installation	12	FRONT A/C UNIT : Removal and Installation	16
REAR VENTILATOR DUCT UPPER	12	REAR A/C UNIT ASSEMBLY	16
REAR VENTILATOR DUCT UPPER : Removal and Installation	12	REAR A/C UNIT ASSEMBLY : Exploded View	16
ROOF DUCT	13	REAR A/C UNIT ASSEMBLY : Removal and Installation	16
ROOF DUCT : Removal and Installation	13	IN-CABIN MICROFILTER	17
REAR VENTILATOR GRILLE	13	Exploded View	17
REAR VENTILATOR GRILLE : Removal and Installation	13	Removal and Installation	17
BLOWER UNIT	14	Replacement	17
Exploded View	14	SERVICE DATA AND SPECIFICATIONS (SDS)	18
Removal and Installation	15	SERVICE DATA AND SPECIFICATIONS (SDS)	18
BLOWER MOTOR	16	In-cabin microfilter	18
FRONT A/C UNIT	16		

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009012031

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precautions for Removing of Battery Terminal

INFOID:000000009864398

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.




PRECAUTIONS

< PRECAUTION >

Precaution for Procedure without Cowl Top Cover

INFOID:00000009338443

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



PREPARATION


< PREPARATION >

PREPARATION

PREPARATION

Commercial Service Tool

INFOID:000000009012033

Tool name	Description
Remover tool  JMKIA3050ZZ	Removes clips, pawls and metal clips

A
B
C
D
E
F
G
H
VTL
J
K
L
M
N
O
P

VTL

VENTILATION SYSTEM

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

VENTILATION SYSTEM

VENTILATION SYSTEM (FRONT AIR CONDITIONING)

VENTILATION SYSTEM (FRONT AIR CONDITIONING) : System Description


INFOID:000000009012034

OUTLINE


Ventilation system is controlled by A/C control. For details of air conditioner system, refer to [HAC-15. "FRONT AUTOMATIC AIR CONDITIONING SYSTEM : System Description"](#).

AIR FLOW

Front



Rear



AIR DISTRIBUTION

Front A/C Unit

Discharge air flow							
Mode position	Condition	Air outlet/distribution					
		VENT			FOOT		DEF (4)
		Center (1)	Side (2)	Upper (3)	Front (5)	Rear (6)	
	DUAL and Upper ventilator switch: ON	×	×	×	—	—	—
		×	×	×	×	×	—
		—	×	×	×	×	×
		—	×	×	×	×	×
		—	×	—	—	—	—

VENTILATION SYSTEM

< SYSTEM DESCRIPTION >

VENTILATION SYSTEM (REAR AIR CONDITIONING)


VENTILATION SYSTEM (REAR AIR CONDITIONING) : System Description

INFOID:000000009012035

OUTLINE

Rear cooling system is controlled by rear blower switch. Refer to [HAC-24, "REAR AUTOMATIC AIR CONDITIONING SYSTEM : System Description"](#).

AIR FLOW



AIR DISTRIBUTION

Rear A/C Unit

VTL

Discharge air flow		
Mode position	Air outlet/distribution	
	VENT (1)	FOOT (2)
	x	—
	x	x
	—	x

DUCT AND GRILLE

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION


DUCT AND GRILLE

Exploded View

INFOID:000000009012036

FRONT

SEC. 270•273•680•685



JM1IA0644ZZ

DUCT AND GRILLE

< REMOVAL AND INSTALLATION >

- 16. Rear ventilator outlet grille B LH
- 17. Roof duct LH
- 18. Roof duct center
- 19. Rear ventilator duct upper

CENTER VENTILATOR GRILLE

CENTER VENTILATOR GRILLE : Removal and Installation

INFOID:000000009012037

REMOVAL

1. Remove cluster lid D. Refer to [IP-14, "Removal and Installation"](#).
2. Remove center ventilator grille from cluster lid D.

INSTALLATION

Install in the reverse order of removal.

SIDE VENTILATOR GRILLE

SIDE VENTILATOR GRILLE : Removal and Installation

INFOID:000000009012038

REMOVAL

1. Remove instrument panel assembly. Refer to [IP-14, "Removal and Installation"](#).
2. Remove fixing screw, and then remove side ventilator grille from instrument panel.

INSTALLATION

Install in the reverse order of removal.

FRONT DEFROSTER GRILLE

FRONT DEFROSTER GRILLE : Removal and Installation

INFOID:000000009012039

REMOVAL

Remove front defroster grilles, using remover tools.

INSTALLATION

Install in the reverse order of removal.

UPPER VENTILATOR GRILLE

UPPER VENTILATOR GRILLE : Removal and Installation

INFOID:000000009012040

REMOVAL

Remove upper ventilator grille, using remover tools.

INSTALLATION

Install in the reverse order of removal.

SIDE VENTILATOR DUCT

SIDE VENTILATOR DUCT : Removal and Installation

INFOID:000000009012041

REMOVAL

1. Remove instrument panel assembly. Refer to [IP-14, "Removal and Installation"](#).
2. Remove fixing screws, and then remove side ventilator duct from instrument panel.

INSTALLATION

Install in the reverse order of removal.

UPPER VENTILATOR DUCT

UPPER VENTILATOR DUCT : Removal and Installation

INFOID:000000009012042

REMOVAL

1. Remove instrument panel assembly. Refer to [IP-14, "Removal and Installation"](#).

DUCT AND GRILLE

< REMOVAL AND INSTALLATION >

2. Remove front defroster nozzle. Refer to [VTL-11, "FRONT DEFROSTER NOZZLE : Removal and Installation"](#).
3. Remove fixing screws, and then remove upper ventilator duct.

INSTALLATION

Install in the reverse order of removal.

FRONT DEFROSTER NOZZLE

FRONT DEFROSTER NOZZLE : Removal and Installation

INFOID:000000009012043

REMOVAL

1. Remove instrument panel assembly. Refer to [VTL-8, "Exploded View"](#).
2. Remove fixing screws, and then remove front defroster nozzle.

INSTALLATION

Install in the reverse order of removal.

SIDE DEFROSTER NOZZLE

SIDE DEFROSTER NOZZLE : Removal and Installation

INFOID:000000009012044

REMOVAL

1. Remove instrument panel assembly. Refer to [IP-14, "Removal and Installation"](#).
2. Remove fixing screw, and then remove side defroster nozzle.

INSTALLATION

Install in the reverse order of removal.

FLOOR DUCT 1

FLOOR DUCT 1 : Removal and Installation

INFOID:000000009012045

REMOVAL

1. Remove center console assembly. Refer to [IP-25, "Removal and Installation"](#).
2. Remove floor duct 1.

INSTALLATION

Install in the reverse order of removal.

FLOOR DUCT 2

FLOOR DUCT 2 : Removal and Installation

INFOID:000000009012046

REMOVAL

1. Pull up front of front floor carpet of securing work space. Refer to [INT-25, "FRONT FLOOR CARPET : Removal and Installation"](#).
2. Remove fixing clip, and then remove floor duct 2.

INSTALLATION

Install in the reverse order of removal.

FLOOR DUCT 3

FLOOR DUCT 3 : Removal and Installation

INFOID:000000009012047

REMOVAL

1. Pull up front of front floor carpet of securing work space. Refer to [INT-25, "FRONT FLOOR CARPET : Removal and Installation"](#).
2. Remove mounting bolt, and then remove floor duct 1.

INSTALLATION

A
B
C
D
E
F
G
H
J
K
L
M
N
O
P

VTL

DUCT AND GRILLE

< REMOVAL AND INSTALLATION >

Install in the reverse order of removal.

REAR FLOOR GRILLE

REAR FLOOR GRILLE : Removal and Installation

INFOID:000000009012048

REMOVAL

Disengage fixing metal clips, and then remove rear floor grille.

INSTALLATION

Install in the reverse order of removal.

FOOT DUCT

FOOT DUCT : Removal and Installation

INFOID:000000009012049

REMOVAL

1. Remove steering member. Refer to [HA-44. "HEATER & COOLING UNIT ASSEMBLY : Removal and Installation"](#).
2. Remove fixing screws, and then remove foot duct.

INSTALLATION

Install in the reverse order of removal.

FOOT GRILLE

FOOT GRILLE : Removal and Installation

INFOID:000000009012050

REMOVAL

Driver side

1. Remove instrument lower panel RH. Refer to [IP-14. "Removal and Installation"](#).
2. Remove fixing screws, and then remove foot grille.

Passenger side

1. Remove instrument lower cover. Refer to [IP-14. "Removal and Installation"](#).
2. Remove fixing screws and clip, and then remove foot grille.

INSTALLATION

Install in the reverse order of removal.

REAR VENTILATOR DUCT LOWER

REAR VENTILATOR DUCT LOWER : Removal and Installation

INFOID:000000009012051

REMOVAL

1. Remove luggage side lower finisher RH. Refer to [INT-36. "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
2. Remove mounting bolts, and then remove rear ventilator duct lower.

INSTALLATION

Install in the reverse order of removal.

REAR VENTILATOR DUCT UPPER

REAR VENTILATOR DUCT UPPER : Removal and Installation

INFOID:000000009012052

REMOVAL

1. Remove back pillar garnish RH. Refer to [INT-37. "BACK PILLAR GARNISH : Removal and Installation"](#).
2. Remove mounting bolt, and then remove rear ventilator grille upper.

INSTALLATION

Install in the reverse order of removal.

DUCT AND GRILLE

< REMOVAL AND INSTALLATION >

ROOF DUCT

ROOF DUCT : Removal and Installation

INFOID:000000009012053

REMOVAL

1. Remove headlining. Refer to [INT-29, "Removal and Installation"](#).
2. Remove mounting bolts and clip, and then remove roof duct (LH/RH).
3. Remove rear ventilator duct upper.
4. Remove roof duct (center).

INSTALLATION

Install in the reverse order of removal.

REAR VENTILATOR GRILLE

REAR VENTILATOR GRILLE : Removal and Installation

INFOID:000000009012054

REMOVAL

1. Remove headlining. Refer to [INT-29, "Removal and Installation"](#).
2. Remove fixing screws, and then remove rear ventilator grille A and B from headlining.

INSTALLATION

Install in reverse order of removal.

A

B

C

D

E

F

G

H

VTL

J

K

L

M

N

O

P

BLOWER UNIT


< REMOVAL AND INSTALLATION >

BLOWER UNIT


Exploded View


INFOID:000000009012055

REMOVAL



- | | | |
|-----------------------------------|-------------------------|-----------------------|
| 1. Heater & cooling unit assembly | 2. Steering member | 3. Instrument stay LH |
| 4. Instrument stay RH | 5. Blower unit assembly | |


 : N·m (kg-m, ft-lb)

 : N·m (kg-m, in-lb)

DISASSEMBLY

BLOWER UNIT

< REMOVAL AND INSTALLATION >



- | | | |
|--------------------------|---------------------------|----------------------|
| 1. Shutter box case RH | 2. Shutter box upper case | 3. Packing |
| 4. Bellmouth ring | 5. Blower unit bracket | 6. Intake upper case |
| 7. Intake lower case | 8. Blower motor assembly | 9. Packing |
| 10. Shutter box case LH | 11. Intake door motor | 12. Intake door |
| 13. In-cabin microfilter | 14. Filter cover | |

Removal and Installation

INFOID:000000009012056

REMOVAL

1. Remove A/C unit assembly. Refer to [HA-44, "HEATER & COOLING UNIT ASSEMBLY : Removal and Installation"](#).
2. Remove mounting bolts, and then disconnect heater & cooling unit assembly and blower unit assembly.

INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
VTL
J
K
L
M
N
O
P

BLOWER MOTOR

< REMOVAL AND INSTALLATION >

BLOWER MOTOR

FRONT A/C UNIT

FRONT A/C UNIT : Exploded View

INFOID:000000009012057

Refer to [VTL-14, "Exploded View"](#).

FRONT A/C UNIT : Removal and Installation

INFOID:000000009012058

REMOVAL

1. Remove instrument lower cover. Refer to [IP-14, "Removal and Installation"](#).
2. Disconnect blower motor connector.
3. Remove fixing screws, and then remove blower motor.

INSTALLATION

Install in the reverse order of removal.

REAR A/C UNIT ASSEMBLY

REAR A/C UNIT ASSEMBLY : Exploded View

INFOID:000000009012059

Refer to [HA-47, "Exploded View"](#).

REAR A/C UNIT ASSEMBLY : Removal and Installation

INFOID:000000009012060

REMOVAL

1. Removal rear A/C unit assembly. Refer to [HA-48, "REAR A/C UNIT ASSEMBLY : Removal and Installation"](#).
2. Disconnect blower motor connector.
3. Remove fixing screws, and then remove blower motor.

IN-CABIN MICROFILTER

< REMOVAL AND INSTALLATION >

IN-CABIN MICROFILTER

Exploded View

INFOID:000000009012061

Refer to [VTL-14. "Exploded View"](#).

Removal and Installation

INFOID:000000009012062

REMOVAL

1. Remove glove box assembly. Refer to [IP-14. "Removal and Installation"](#).
2. Remove filter cover, and then remove air conditioner filter.

CAUTION:

If the filter is deformed/damaged when removing, replace it with a new one. Deformed/damaged filter may deteriorate the dust collecting performance.

INSTALLATION

Note the following item, and install in the reverse order of removal.

CAUTION:

When installing, handle the filter with extreme care to avoid deforming/damaging.

Replacement

INFOID:000000009012063

Replace in-cabin microfilter.

Refer to [MA-8. "FOR NORTH AMERICA : Introduction of Periodic Maintenance"](#).

Affix a caution label inside the glove box when replacing filter.

A

B

C

D

E

F

G

H

VTL

J

K

L

M

N

O

P

SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

SERVICE DATA AND SPECIFICATIONS (SDS)

In-cabin microfilter

INFOID:000000009012064

Replacement interval	MA-8. "FOR NORTH AMERICA : Introduction of Periodic Maintenance"
----------------------	--