

A
B
C

DLK

SECTION DOOR & LOCK

CONTENTS

| | | |
|--|-----------|-----|
| PRECAUTION | | D |
| PRECAUTIONS | | E |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 14 | |
| Precaution for Procedure without Cowl Top Cover... .. | 14 | |
| Precautions For Xenon Headlamp Service | 14 | |
| Precautions for Removing Battery Terminal Work | 15 | |
| PREPARATION | 16 | |
| PREPARATION | 16 | |
| Special Service Tools | 16 | |
| Commercial Service Tools | 16 | |
| SYSTEM DESCRIPTION | 18 | |
| COMPONENT PARTS | 18 | |
| DOOR LOCK SYSTEM | 18 | |
| DOOR LOCK SYSTEM : Component Parts Location | 18 | |
| AUTOMATIC BACK DOOR SYSTEM | 22 | |
| AUTOMATIC BACK DOOR SYSTEM : Component Parts Location | 22 | |
| AUTOMATIC SLIDING DOOR SYSTEM | 23 | |
| AUTOMATIC SLIDING DOOR SYSTEM : Component Parts Location | 23 | |
| Inside Key Antenna | 27 | |
| Front Door Outside Handle Assembly (Outside Key Antenna) | 27 | |
| Outside Key Antenna (Rear Bumper) | 27 | |
| Remote Keyless Entry Receiver | 27 | |
| Intelligent Key Warning Buzzer | 28 | |
| Door Lock and Unlock Switch (Driver Side) | 28 | |
| Door Lock and Unlock Switch (Passenger Side) | 28 | |
| Front Door Request Switch | 28 | |
| Front Door Switch | 28 | |
| Front Door Lock Assembly (Driver Side) | 28 | F |
| Back Door Opener Switch | 29 | |
| Back Door Request Switch | 29 | |
| Back Door Lock Assembly (Without Automatic Back Door System) | 29 | G |
| Back Door Control Unit (Without Automatic Back Door System) | 29 | H |
| Selective Unlock Relay | 29 | |
| Back Door Touch Sensor | 30 | |
| Automatic Back Door Control Module | 30 | |
| Automatic Back Door Switch | 30 | I |
| Automatic Door Main Switch | 30 | |
| Automatic Back Door Warning Buzzer | 30 | |
| Automatic Back Door Close Switch | 30 | J |
| Back Door Lock Assembly (With Automatic Back Door System) | 30 | |
| Automatic Back Door Opener Switch | 30 | DLK |
| Automatic Sliding Door Open/Close Switch | 30 | |
| Automatic Sliding Door Unit | 30 | |
| Sliding Door Control Unit | 31 | L |
| Automatic Sliding Door Warning Buzzer | 31 | |
| Automatic Sliding Door One-Touch Open/Close Switch | 31 | |
| Remote Control Assembly | 31 | M |
| Sliding Door Switch | 31 | |
| Sliding Door Lock Actuator | 31 | |
| Sliding Door Lock Release Actuator | 31 | N |
| Sliding Door Lock Assembly | 31 | |
| Sliding Door Touch Sensor | 31 | |
| Fuel Filler Lid Sliding Door Unit | 32 | O |
| SYSTEM (POWER DOOR LOCK SYSTEM) | 33 | |
| System Description | 33 | |
| Circuit Diagram | 35 | P |
| SYSTEM (INTELLIGENT KEY SYSTEM) | 36 | |
| INTELLIGENT KEY SYSTEM | 36 | |
| INTELLIGENT KEY SYSTEM : System Description | 36 | |
| INTELLIGENT KEY SYSTEM : Circuit Diagram | 38 | |

| | | | |
|---|-----------|--|------------|
| DOOR LOCK FUNCTION | 39 | POWER ASSIST FUNCTION : System Description | 79 |
| DOOR LOCK FUNCTION : System Description | 40 | POWER ASSIST FUNCTION : Fail-safe | 79 |
| BACK DOOR OPEN FUNCTION | 42 | SLIDING DOOR AUTO CLOSURE FUNCTION | 80 |
| BACK DOOR OPEN FUNCTION : System Description | 42 | SLIDING DOOR AUTO CLOSURE FUNCTION : System Description | 81 |
| REMOTE KEYLESS ENTRY FUNCTION | 44 | SLIDING DOOR AUTO CLOSURE FUNCTION : Fail-safe | 81 |
| REMOTE KEYLESS ENTRY FUNCTION : System Description | 44 | HOLD FUNCTION | 82 |
| KEY REMINDER FUNCTION | 46 | HOLD FUNCTION : System Description | 83 |
| KEY REMINDER FUNCTION : System Description | 47 | HOLD FUNCTION : Fail-safe | 83 |
| WARNING FUNCTION | 47 | ANTI-PINCH FUNCTION | 84 |
| WARNING FUNCTION : System Description | 47 | ANTI-PINCH FUNCTION : System Description | 85 |
| SYSTEM (AUTOMATIC BACK DOOR SYSTEM) | 52 | ANTI-PINCH FUNCTION : Fail-safe | 85 |
| System Description | 52 | INTERMITTENT CLUTCH FUNCTION | 86 |
| Circuit Diagram | 58 | INTERMITTENT CLUTCH FUNCTION : System Description | 87 |
| Fail Safe | 59 | INTERMITTENT CLUTCH FUNCTION : Fail-safe... .. | 87 |
| SYSTEM (BACK DOOR AUTO CLOSURE SYSTEM) | 60 | BUZZER REMINDER FUNCTION | 88 |
| CLOSURE FUNCTION | 60 | BUZZER REMINDER FUNCTION : System Description | 88 |
| CLOSURE FUNCTION : System Description | 60 | BUZZER REMINDER FUNCTION : Fail-safe | 89 |
| OPEN FUNCTION | 60 | SYSTEM (INTEGRATED HOMELINK TRANSMITTER) | 91 |
| OPEN FUNCTION : System Description | 61 | System Description | 91 |
| Circuit Diagram | 63 | DIAGNOSIS SYSTEM (BCM) | 92 |
| SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM) | 64 | COMMON ITEM | 92 |
| AUTOMATIC SLIDING DOOR SYSTEM | 64 | COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) | 92 |
| AUTOMATIC SLIDING DOOR SYSTEM : System Description | 64 | DOOR LOCK | 93 |
| AUTOMATIC SLIDING DOOR SYSTEM : Circuit Diagram | 66 | DOOR LOCK : CONSULT Function (BCM - DOOR LOCK) | 94 |
| AUTOMATIC SLIDING DOOR SYSTEM : Fail-safe | 68 | INTELLIGENT KEY | 95 |
| AUTO OPEN/CLOSE FUNCTION | 69 | INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) | 95 |
| AUTO OPEN/CLOSE FUNCTION : System Description | 70 | TRUNK | 98 |
| AUTO OPEN/CLOSE FUNCTION : Fail-safe | 73 | TRUNK : CONSULT Function (BCM - TRUNK) | 98 |
| ONE-TOUCH UNLOCK FUNCTION | 74 | DIAGNOSIS SYSTEM (AUTOMATIC BACK DOOR CONTROL UNIT) | 100 |
| ONE-TOUCH UNLOCK FUNCTION : System Description | 75 | CONSULT Function (AUTOMATIC BACK DOOR CONTROL UNIT) | 100 |
| ONE-TOUCH UNLOCK FUNCTION : Fail-safe | 76 | DIAGNOSIS SYSTEM (SLIDING DOOR CONTROL UNIT LH) | 101 |
| UNLOCK-LINKED OPENING FUNCTION | 76 | CONSULT Function | 101 |
| UNLOCK-LINKED OPENING FUNCTION : System Description | 77 | DIAGNOSIS SYSTEM (SLIDING DOOR CONTROL UNIT RH) | 103 |
| UNLOCK-LINKED OPENING FUNCTION : Fail-safe | 78 | CONSULT Function | 103 |
| POWER ASSIST FUNCTION | 78 | ECU DIAGNOSIS INFORMATION | 105 |

| | | | | |
|---|------------|---|------------|-----|
| BCM | 105 | ADDITIONAL SERVICE WHEN REPLACING AUTOMATIC BACK DOOR CONTROL MOD- ULE | 169 | A |
| List of ECU Reference | 105 | Description | 169 | B |
| AUTOMATIC BACK DOOR CONTROL MOD- ULE | 106 | Work Procedure | 169 | |
| Reference Value | 106 | ADDITIONAL SERVICE WHEN REPLACING SLIDING DOOR CONTROL UNIT | 170 | C |
| Fail Safe | 108 | Description | 170 | |
| DTC Inspection Priority Chart | 108 | Work Procedure | 170 | |
| DTC Index | 109 | DTC/CIRCUIT DIAGNOSIS | 171 | D |
| BACK DOOR CONTROL UNIT | 110 | U1000 CAN COMM CIRCUIT | 171 | |
| Reference Value | 110 | AUTOMATIC BACK DOOR CONTROL MODULE.. 171 | | E |
| SLIDING DOOR CONTROL UNIT | 111 | AUTOMATIC BACK DOOR CONTROL MODULE | | F |
| LH | 111 | : Description | 171 | |
| LH : Reference Value | 111 | AUTOMATIC BACK DOOR CONTROL MODULE | | G |
| LH : Fail-safe | 114 | : DTC Logic | 171 | |
| LH : DTC Inspection Priority Chart | 115 | AUTOMATIC BACK DOOR CONTROL MODULE | | |
| LH : DTC Index | 115 | : Diagnosis Procedure | 171 | |
| RH | 116 | SLIDING DOOR LH | 171 | H |
| RH : Reference Value | 116 | SLIDING DOOR LH : Description | 171 | |
| RH : Fail-safe | 120 | SLIDING DOOR LH : DTC Logic | 171 | |
| RH : DTC Inspection Priority Chart | 121 | SLIDING DOOR LH : Diagnosis Procedure | 172 | |
| RH : DTC Index | 121 | SLIDING DOOR RH | 172 | I |
| WIRING DIAGRAM | 122 | SLIDING DOOR RH : Description | 172 | |
| DOOR & LOCK SYSTEM | 122 | SLIDING DOOR RH : DTC Logic | 172 | J |
| Wiring Diagram | 122 | SLIDING DOOR RH : Diagnosis Procedure | 172 | |
| AUTOMATIC BACK DOOR SYSTEM | 141 | U1010 CONTROL UNIT (CAN) | 173 | |
| Wiring Diagram | 141 | AUTOMATIC BACK DOOR CONTROL MODULE.. 173 | | DLK |
| INTEGRATED HOMELINK TRANSMITTER SYSTEM | 149 | AUTOMATIC BACK DOOR CONTROL MODULE | | L |
| Wiring Diagram | 149 | : DTC Logic | 173 | |
| AUTOMATIC SLIDING DOOR SYSTEM | 151 | AUTOMATIC BACK DOOR CONTROL MODULE | | M |
| Wiring Diagram | 151 | : Diagnosis Procedure | 173 | |
| BASIC INSPECTION | 165 | SLIDING DOOR LH | 173 | N |
| DIAGNOSIS AND REPAIR WORK FLOW | 165 | SLIDING DOOR LH : DTC Logic | 173 | |
| Work Flow | 165 | SLIDING DOOR LH : Diagnosis Procedure | 173 | |
| ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL | 168 | SLIDING DOOR RH | 173 | O |
| AUTOMATIC BACK DOOR SYSTEM | 168 | SLIDING DOOR RH : DTC Logic | 173 | |
| AUTOMATIC BACK DOOR SYSTEM : Descrip- tion | 168 | SLIDING DOOR RH : Diagnosis Procedure | 173 | P |
| AUTOMATIC BACK DOOR SYSTEM : Work Pro- cedure | 168 | B2401 IGNITION POWER SUPPLY CIRCUIT. 174 | | |
| AUTOMATIC SLIDING DOOR SYSTEM | 168 | AUTOMATIC BACK DOOR CONTROL MODULE.. 174 | | |
| AUTOMATIC SLIDING DOOR SYSTEM : De- scription | 168 | AUTOMATIC BACK DOOR CONTROL MODULE | | |
| AUTOMATIC SLIDING DOOR SYSTEM : Work Procedure | 168 | : DTC Logic | 174 | |
| | | AUTOMATIC BACK DOOR CONTROL MODULE | | |
| | | : Diagnosis Procedure | 174 | |
| | | SLIDING DOOR LH | 174 | |
| | | SLIDING DOOR LH : DTC Logic | 174 | |
| | | SLIDING DOOR LH : Diagnosis Procedure | 175 | |
| | | SLIDING DOOR RH | 175 | |
| | | SLIDING DOOR RH : DTC Logic | 175 | |

| | | | |
|--|------------|---|------------|
| SLIDING DOOR RH : Diagnosis Procedure | 176 | SLIDING DOOR LH : Diagnosis Procedure | 194 |
| B2402 TOUCH SENSOR | 177 | SLIDING DOOR RH | 195 |
| SLIDING DOOR LH | 177 | SLIDING DOOR RH : DTC Logic | 195 |
| SLIDING DOOR LH : DTC Logic | 177 | SLIDING DOOR RH : Diagnosis Procedure | 195 |
| SLIDING DOOR LH : Diagnosis Procedure | 177 | B2412 AUTOMATIC SLIDING DOOR MO- | |
| SLIDING DOOR LH : Component Inspection | 178 | TOR/ENCODER | 197 |
| SLIDING DOOR RH | 179 | SLIDING DOOR LH | 197 |
| SLIDING DOOR RH : DTC Logic | 179 | SLIDING DOOR LH : DTC Logic | 197 |
| SLIDING DOOR RH : Diagnosis Procedure | 179 | SLIDING DOOR LH : Diagnosis Procedure | 197 |
| SLIDING DOOR RH : Component Inspection | 180 | SLIDING DOOR RH | 199 |
| B2403 ENCODER | 182 | SLIDING DOOR RH : DTC Logic | 199 |
| AUTOMATIC BACK DOOR CONTROL MODULE.. | 182 | SLIDING DOOR RH : Diagnosis Procedure | 199 |
| AUTOMATIC BACK DOOR CONTROL MODULE | | B2413 AUTOMATIC SLIDING DOOR MO- | |
| : DTC Logic | 182 | TOR/ENCODER | 203 |
| AUTOMATIC BACK DOOR CONTROL MODULE | | SLIDING DOOR LH | 203 |
| : Diagnosis Procedure | 182 | SLIDING DOOR LH : DTC Logic | 203 |
| SLIDING DOOR LH | 182 | SLIDING DOOR LH : Diagnosis Procedure | 203 |
| SLIDING DOOR LH : DTC Logic | 182 | SLIDING DOOR RH | 204 |
| SLIDING DOOR LH : Diagnosis Procedure | 182 | SLIDING DOOR RH : DTC Logic | 204 |
| SLIDING DOOR RH | 184 | SLIDING DOOR RH : Diagnosis Procedure | 204 |
| SLIDING DOOR RH : DTC Logic | 184 | B2414 AUTOMATIC SLIDING DOOR MOTOR | |
| SLIDING DOOR RH : Diagnosis Procedure | 184 | ..206 | |
| B2405 SLIDING DOOR CONTROL UNIT | 187 | SLIDING DOOR LH | 206 |
| SLIDING DOOR LH | 187 | SLIDING DOOR LH : DTC Logic | 206 |
| SLIDING DOOR LH : DTC Logic | 187 | SLIDING DOOR LH : Diagnosis Procedure | 206 |
| SLIDING DOOR LH : Diagnosis Procedure | 187 | SLIDING DOOR RH | 207 |
| SLIDING DOOR RH | 187 | SLIDING DOOR RH : DTC Logic | 207 |
| SLIDING DOOR RH : DTC Logic | 187 | SLIDING DOOR RH : Diagnosis Procedure | 208 |
| SLIDING DOOR RH : Diagnosis Procedure | 187 | B2416 TOUCH SENSOR RH | 210 |
| B2409 HALF LATCH SWITCH | 188 | DTC Logic | 210 |
| AUTOMATIC BACK DOOR CONTROL MODULE.. | 188 | Diagnosis Procedure | 210 |
| AUTOMATIC BACK DOOR CONTROL MODULE | | Component Inspection | 211 |
| : DTC Logic | 188 | B2417 TOUCH SENSOR LH | 213 |
| AUTOMATIC BACK DOOR CONTROL MODULE | | DTC Logic | 213 |
| : Diagnosis Procedure | 188 | Diagnosis Procedure | 213 |
| AUTOMATIC BACK DOOR CONTROL MODULE | | Component Inspection | 214 |
| : Component Inspection | 189 | B2419 OPEN SWITCH | 216 |
| SLIDING DOOR LH | 189 | DTC Logic | 216 |
| SLIDING DOOR LH : DTC Logic | 189 | Diagnosis Procedure | 216 |
| SLIDING DOOR LH : Diagnosis Procedure | 190 | Component Inspection | 217 |
| SLIDING DOOR LH : Component Inspection | 191 | B2420 CLOSE SWITCH | 218 |
| SLIDING DOOR RH | 191 | DTC Logic | 218 |
| SLIDING DOOR RH : DTC Logic | 192 | Diagnosis Procedure | 218 |
| SLIDING DOOR RH : Diagnosis Procedure | 192 | Component Inspection | 219 |
| SLIDING DOOR RH : Component Inspection | 193 | B2421 CLUTCH OPERATION TIME | 220 |
| B241A ENCODER | 194 | DTC Logic | 220 |
| SLIDING DOOR LH | 194 | Diagnosis Procedure | 220 |
| SLIDING DOOR LH : DTC Logic | 194 | | |

| | | | | |
|--|------------|---|------------|-----|
| B2422 BACK DOOR STATE | 221 | BACK DOOR SWITCH | 243 | |
| DTC Logic | 221 | Component Function Check | 243 | A |
| Diagnosis Procedure | 221 | Diagnosis Procedure | 243 | |
| B2423 AUTOMATIC BACK DOOR MOTOR OPERATION TIME | 222 | Component Inspection | 244 | B |
| DTC Logic | 222 | DOOR LOCK AND UNLOCK SWITCH | 245 | |
| Diagnosis Procedure | 222 | WITH AUTOMATIC SLIDING DOOR | 245 | C |
| B2424 CLOSURE CONDITION | 223 | WITH AUTOMATIC SLIDING DOOR : | | |
| DTC Logic | 223 | Component Function Check | 245 | |
| Diagnosis Procedure | 223 | WITH AUTOMATIC SLIDING DOOR : Diagnosis Procedure | 245 | D |
| Component Inspection | 224 | WITHOUT AUTOMATIC SLIDING DOOR | 245 | |
| B2425 AUTOMATIC BACK DOOR CONTROL UNIT | 225 | WITHOUT AUTOMATIC SLIDING DOOR : | | |
| DTC Logic | 225 | Component Function Check | 245 | E |
| Diagnosis Procedure | 225 | WITHOUT AUTOMATIC SLIDING DOOR : Diagnosis Procedure | 245 | |
| B2621 INSIDE ANTENNA | 226 | WITHOUT AUTOMATIC SLIDING DOOR : Component Inspection | 248 | F |
| DTC Logic | 226 | DOOR LOCK ACTUATOR | 249 | |
| Diagnosis Procedure | 226 | DRIVER SIDE | 249 | G |
| B2622 INSIDE ANTENNA | 228 | DRIVER SIDE : Component Function Check | 249 | |
| DTC Logic | 228 | DRIVER SIDE : Diagnosis Procedure | 249 | H |
| Diagnosis Procedure | 228 | PASSENGER SIDE | 250 | |
| B2623 INSIDE ANTENNA | 230 | PASSENGER SIDE : | | |
| DTC Logic | 230 | Component Function Check | 250 | I |
| Diagnosis Procedure | 230 | PASSENGER SIDE : Diagnosis Procedure | 250 | |
| B2626 OUTSIDE ANTENNA | 232 | SLIDING DOOR LOCK ACTUATOR | 252 | J |
| DTC Logic | 232 | WITH AUTOMATIC SLIDING DOOR | 252 | |
| Diagnosis Procedure | 232 | WITH AUTOMATIC SLIDING DOOR : | | |
| B2627 OUTSIDE ANTENNA | 234 | Component Function Check | 252 | DLK |
| DTC Logic | 234 | WITH AUTOMATIC SLIDING DOOR : Diagnosis Procedure | 252 | |
| Diagnosis Procedure | 234 | WITH AUTOMATIC SLIDING DOOR : Component Inspection | 254 | L |
| B2628 OUTSIDE ANTENNA | 236 | WITHOUT AUTOMATIC SLIDING DOOR | 255 | |
| DTC Logic | 236 | WITHOUT AUTOMATIC SLIDING DOOR : | | |
| Diagnosis Procedure | 236 | Component Function Check | 255 | M |
| POWER SUPPLY AND GROUND CIRCUIT ... | 238 | WITHOUT AUTOMATIC SLIDING DOOR : Diagnosis Procedure | 255 | |
| AUTOMATIC BACK DOOR CONTROL MODULE | 238 | SELECT UNLOCK RELAY | 257 | N |
| AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure | 238 | Component Function Check | 257 | |
| BACK DOOR CONTROL UNIT | 238 | Diagnosis Procedure | 257 | O |
| BACK DOOR CONTROL UNIT : Diagnosis Procedure | 238 | Component Inspection | 258 | |
| SLIDING DOOR CONTROL UNIT | 239 | UNLOCK SENSOR | 259 | P |
| SLIDING DOOR CONTROL UNIT : Diagnosis Procedure | 239 | Component Function Check | 259 | |
| Diagnosis Procedure | 239 | Diagnosis Procedure | 259 | |
| DOOR SWITCH | 241 | Component Inspection | 260 | |
| Component Function Check | 241 | DOOR KEY CYLINDER SWITCH | 261 | |
| Diagnosis Procedure | 241 | WITH AUTOMATIC SLIDING DOOR | 261 | |
| Component Inspection | 242 | | | |

WITH AUTOMATIC SLIDING DOOR : Component Function Check261
WITH AUTOMATIC SLIDING DOOR : Diagnosis Procedure261
WITH AUTOMATIC SLIDING DOOR : Component Inspection262

WITHOUT AUTOMATIC SLIDING DOOR262
WITHOUT AUTOMATIC SLIDING DOOR : Component Function Check262
WITHOUT AUTOMATIC SLIDING DOOR : Diagnosis Procedure263
WITHOUT AUTOMATIC SLIDING DOOR : Component Inspection264

REMOTE KEYLESS ENTRY RECEIVER 265
Component Function Check265
Diagnosis Procedure265

DOOR REQUEST SWITCH 267
Component Function Check267
Diagnosis Procedure267
Component Inspection268

BACK DOOR REQUEST SWITCH 269
Component Function Check269
Diagnosis Procedure269
Component Inspection270

BACK DOOR OPENER SWITCH 271
Component Function Check271
Diagnosis Procedure271
Component Inspection272

INTELLIGENT KEY WARNING BUZZER 273
Component Function Check273
Diagnosis Procedure273
Component Inspection274

INTELLIGENT KEY 275
Component Function Check275
Component Inspection275

COMBINATION METER BUZZER 276
Component Function Check276
Diagnosis Procedure276

INFORMATION DISPLAY 277
Component Function Check277
Diagnosis Procedure277

KEY WARNING LAMP 278
Component Function Check278
Diagnosis Procedure278

HAZARD FUNCTION 279
Component Function Check279
Diagnosis Procedure279

BACK DOOR OPEN REQUEST SIGNAL CIRCUIT 280
Diagnosis Procedure280

AUTOMATIC BACK DOOR CLOSE SWITCH.281
Component Function Check 281
Diagnosis Procedure 281
Component Inspection 282

AUTOMATIC DOOR MAIN SWITCH283

AUTOMATIC BACK DOOR CONTROL MODULE . 283
AUTOMATIC BACK DOOR CONTROL MODULE : Component Function Check 283
AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure 283
AUTOMATIC BACK DOOR CONTROL MODULE : Component Inspection 284

SLIDING DOOR CONTROL UNIT 284
SLIDING DOOR CONTROL UNIT : Component Function Check 284
SLIDING DOOR CONTROL UNIT : Diagnosis Procedure 284
SLIDING DOOR CONTROL UNIT : Component Inspection 286

AUTOMATIC BACK DOOR SWITCH287
Component Function Check 287
Diagnosis Procedure 287
Component Inspection 288

OPEN SWITCH289
Diagnosis Procedure 289
Component Inspection 290

CLOSE SWITCH291
Diagnosis Procedure 291
Component Inspection 292

HALF LATCH SWITCH293

WITH AUTOMATIC BACK DOOR 293
WITH AUTOMATIC BACK DOOR : Component Function Check 293
WITH AUTOMATIC BACK DOOR : Diagnosis Procedure 293
WITH AUTOMATIC BACK DOOR : Component Inspection 294

WITHOUT AUTOMATIC BACK DOOR 294
WITHOUT AUTOMATIC BACK DOOR : Diagnosis Procedure 294
WITHOUT AUTOMATIC BACK DOOR : Component Inspection 295

SLIDING DOOR CONTROL UNIT 295
SLIDING DOOR CONTROL UNIT : Component Function Check 296
SLIDING DOOR CONTROL UNIT : Diagnosis Procedure 296
SLIDING DOOR CONTROL UNIT : Component Inspection 298

BACK DOOR TOUCH SENSOR299

| | | | | |
|---|------------|--|------------|-----|
| LH | 299 | SLIDING DOOR RH | 319 | |
| LH : Component Function Check | 299 | SLIDING DOOR RH : Component Function Check | .. 320 | A |
| LH : Diagnosis Procedure | 299 | SLIDING DOOR RH : Diagnosis Procedure | 320 | |
| LH : Component Inspection | 300 | SLIDING DOOR RH : Component Inspection | 321 | B |
| RH | 301 | NEUTRAL SWITCH | 322 | |
| RH : Component Function Check | 301 | SLIDING DOOR LH | 322 | C |
| RH : Diagnosis Procedure | 301 | SLIDING DOOR LH : Component Function Check | 322 | |
| RH : Component Inspection | 302 | SLIDING DOOR LH : Diagnosis Procedure | 322 | |
| BACK DOOR CLOSURE MOTOR | 304 | SLIDING DOOR LH : Component Inspection | 323 | D |
| WITH AUTOMATIC BACK DOOR | 304 | SLIDING DOOR RH | 323 | |
| WITH AUTOMATIC BACK DOOR : Diagnosis Procedure | 304 | SLIDING DOOR RH : Component Function Check | .. 324 | E |
| WITHOUT AUTOMATIC BACK DOOR | 304 | SLIDING DOOR RH : Diagnosis Procedure | 324 | |
| WITHOUT AUTOMATIC BACK DOOR : Diagnosis Procedure | 304 | SLIDING DOOR RH : Component Inspection | 325 | |
| AUTOMATIC BACK DOOR WARNING BUZZER | 306 | SLIDING DOOR HANDLE SWITCH | 326 | F |
| Diagnosis Procedure | 306 | SLIDING DOOR LH | 326 | |
| Component Inspection | 306 | SLIDING DOOR LH : Component Function Check | 326 | G |
| GROUND CIRCUIT | 308 | SLIDING DOOR LH : Diagnosis Procedure | 326 | |
| Component Function Check | 308 | SLIDING DOOR LH : Component Inspection | 327 | |
| Diagnosis Procedure | 308 | SLIDING DOOR RH | 327 | H |
| INTEGRATED HOMELINK TRANSMITTER ... | 309 | SLIDING DOOR RH : Component Function Check | .. 328 | |
| Component Function Check | 309 | SLIDING DOOR RH : Diagnosis Procedure | 328 | I |
| Diagnosis Procedure | 309 | SLIDING DOOR RH : Component Inspection | 329 | |
| ENCODER | 311 | CHILD LOCK STATUS SWITCH | 330 | J |
| SLIDING DOOR LH | 311 | SLIDING DOOR LH | 330 | |
| SLIDING DOOR LH : Component Function Check | 311 | SLIDING DOOR LH : Component Function Check | 330 | |
| SLIDING DOOR LH : Diagnosis Procedure | 311 | SLIDING DOOR LH : Diagnosis Procedure | 330 | DLK |
| SLIDING DOOR RH | 312 | SLIDING DOOR LH : Component Inspection | 331 | |
| SLIDING DOOR RH : Component Function Check | .. 312 | SLIDING DOOR RH | 331 | |
| SLIDING DOOR RH : Diagnosis Procedure | 313 | SLIDING DOOR RH : Component Function Check | .. 332 | L |
| SLIDING DOOR SWITCH | 315 | SLIDING DOOR RH : Diagnosis Procedure | 332 | |
| SLIDING DOOR LH | 315 | SLIDING DOOR RH : Component Inspection | 333 | M |
| SLIDING DOOR LH : Component Function Check | 315 | SLIDING DOOR LOCK STATUS SWITCH | 334 | |
| SLIDING DOOR LH : Diagnosis Procedure | 315 | SLIDING DOOR LH | 334 | |
| SLIDING DOOR LH : Component Inspection | 316 | SLIDING DOOR LH : Component Function Check | 334 | N |
| SLIDING DOOR RH | 316 | SLIDING DOOR LH : Diagnosis Procedure | 334 | |
| SLIDING DOOR RH : Component Function Check | .. 316 | SLIDING DOOR LH : Component Inspection | 335 | O |
| SLIDING DOOR RH : Diagnosis Procedure | 316 | SLIDING DOOR RH | 335 | |
| SLIDING DOOR RH : Component Inspection | 317 | SLIDING DOOR RH : Component Function Check | .. 336 | P |
| FULL LATCH SWITCH | 318 | SLIDING DOOR RH : Diagnosis Procedure | 336 | |
| SLIDING DOOR LH | 318 | SLIDING DOOR RH : Component Inspection | 337 | |
| SLIDING DOOR LH : Component Function Check | 318 | FUEL LID STATUS SWITCH | 338 | |
| SLIDING DOOR LH : Diagnosis Procedure | 318 | Component Function Check | 338 | |
| SLIDING DOOR LH : Component Inspection | 319 | Diagnosis Procedure | 338 | |
| | | Component Inspection | 339 | |

| | | | |
|--|------------|--|------------|
| SLIDING DOOR OPEN/CLOSE SWITCH | 340 | SLIDING DOOR LH : Diagnosis Procedure | 358 |
| FRONT LH | 340 | SLIDING DOOR RH | 358 |
| FRONT LH : Component Function Check | 340 | SLIDING DOOR RH : Diagnosis Procedure | 358 |
| FRONT LH : Diagnosis Procedure | 340 | SLIDING DOOR LOCK RELEASE ACTUA- | |
| FRONT LH : Component Inspection | 341 | TOR | 360 |
| FRONT RH | 341 | SLIDING DOOR LH | 360 |
| FRONT RH : Component Function Check | 341 | SLIDING DOOR LH : Diagnosis Procedure | 360 |
| FRONT RH : Diagnosis Procedure | 341 | SLIDING DOOR RH | 361 |
| FRONT RH : Component Inspection | 342 | SLIDING DOOR RH : Diagnosis Procedure | 361 |
| REAR LH | 343 | SLIDING DOOR CLOSURE MOTOR | 363 |
| REAR LH : Component Function Check | 343 | SLIDING DOOR LH | 363 |
| REAR LH : Diagnosis Procedure | 343 | SLIDING DOOR LH : Diagnosis Procedure | 363 |
| REAR LH : Component Inspection | 344 | SLIDING DOOR RH | 363 |
| REAR RH | 344 | SLIDING DOOR RH : Diagnosis Procedure | 363 |
| REAR RH : Component Function Check | 344 | AUTOMATIC SLIDING DOOR WARNING | |
| REAR RH : Diagnosis Procedure | 345 | BUZZER | 365 |
| REAR RH : Component Inspection | 346 | SLIDING DOOR LH | 365 |
| SLIDING DOOR ONE-TOUCH OPEN/CLOSE | | SLIDING DOOR LH : Diagnosis Procedure | 365 |
| SWITCH | 347 | SLIDING DOOR LH : Component Inspection | 365 |
| SLIDING DOOR LH | 347 | SLIDING DOOR RH | 366 |
| SLIDING DOOR LH : Component Function Check | 347 | SLIDING DOOR RH : Diagnosis Procedure | 366 |
| SLIDING DOOR LH : Diagnosis Procedure | 347 | SLIDING DOOR RH : Component Inspection | 367 |
| SLIDING DOOR LH : Component Inspection | 348 | SYMPTOM DIAGNOSIS | 368 |
| SLIDING DOOR RH | 348 | DOOR DOES NOT LOCK/UNLOCK WITH | |
| SLIDING DOOR RH : Component Function Check | | DOOR LOCK AND UNLOCK SWITCH | 368 |
|349 | | ALL DOOR | 368 |
| SLIDING DOOR RH : Diagnosis Procedure | 349 | ALL DOOR : Description | 368 |
| SLIDING DOOR RH : Component Inspection | 350 | ALL DOOR : Diagnosis Procedure | 368 |
| SLIDING DOOR TOUCH SENSOR | 351 | DRIVER SIDE | 368 |
| SLIDING DOOR LH | 351 | DRIVER SIDE : Description | 368 |
| SLIDING DOOR LH : Component Function Check | 351 | DRIVER SIDE : Diagnosis Procedure | 368 |
| SLIDING DOOR LH : Diagnosis Procedure | 351 | PASSENGER SIDE | 369 |
| SLIDING DOOR LH : Component Inspection | 352 | PASSENGER SIDE : Description | 369 |
| SLIDING DOOR RH | 352 | PASSENGER SIDE : Diagnosis Procedure | 369 |
| SLIDING DOOR RH : Component Function Check | | SLIDING DOOR LH | 369 |
|353 | | SLIDING DOOR LH : Description | 369 |
| SLIDING DOOR RH : Diagnosis Procedure | 353 | SLIDING DOOR LH : Diagnosis Procedure | 369 |
| SLIDING DOOR RH : Component Inspection | 354 | SLIDING DOOR RH | 369 |
| CLUTCH | 355 | SLIDING DOOR RH : Description | 369 |
| SLIDING DOOR LH | 355 | SLIDING DOOR RH : Diagnosis Procedure | 370 |
| SLIDING DOOR LH : Component Function Check | 355 | DOOR DOES NOT LOCK/UNLOCK WITH | |
| SLIDING DOOR LH : Diagnosis Procedure | 355 | DOOR KEY CYLINDER OPERATION | 371 |
| SLIDING DOOR RH | 356 | Diagnosis Procedure | 371 |
| SLIDING DOOR RH : Component Function Check | | DOOR DOES NOT LOCK/UNLOCK WITH | |
|356 | | DOOR REQUEST SWITCH | 372 |
| SLIDING DOOR RH : Diagnosis Procedure | 356 | | |
| AUTOMATIC SLIDING DOOR MOTOR | 358 | | |
| SLIDING DOOR LH | 358 | | |

| | | | | |
|--|------------|---|------------|------------|
| ALL DOOR REQUEST SWITCHES | 372 | OFF POSITION WARNING DOES NOT OPERATE | 386 | A |
| ALL DOOR REQUEST SWITCHES : Description | 372 | Diagnosis Procedure | 386 | |
| ALL DOOR REQUEST SWITCHES : Diagnosis Procedure | 372 | P POSITION WARNING DOES NOT OPERATE | 387 | B |
| DRIVER SIDE DOOR REQUEST SWITCH | 372 | Diagnosis Procedure | 387 | |
| DRIVER SIDE DOOR REQUEST SWITCH : Description | 372 | ACC WARNING DOES NOT OPERATE | 388 | C |
| DRIVER SIDE DOOR REQUEST SWITCH : Diagnosis Procedure | 372 | Diagnosis Procedure | 388 | |
| PASSENGER SIDE DOOR REQUEST SWITCH ... | 373 | TAKE AWAY WARNING DOES NOT OPERATE | 389 | D |
| PASSENGER SIDE DOOR REQUEST SWITCH : Description | 373 | Diagnosis Procedure | 389 | |
| PASSENGER SIDE DOOR REQUEST SWITCH : Diagnosis Procedure | 373 | KEY ID WARNING DOES NOT OPERATE | 390 | E |
| BACK DOOR REQUEST SWITCH | 373 | Diagnosis Procedure | 390 | |
| BACK DOOR REQUEST SWITCH : Description .. | 373 | INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE | 391 | F |
| BACK DOOR REQUEST SWITCH : Diagnosis Procedure | 373 | Diagnosis Procedure | 391 | |
| DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY | 375 | DOOR LOCK OPERATION WARNING DOES NOT OPERATE | 392 | G |
| Diagnosis Procedure | 375 | Diagnosis Procedure | 392 | |
| IGNITION POSITION WARNING FUNCTION DOES NOT OPERATE | 377 | BACK DOOR AUTO CLOSURE FUNCTION DOES NOT OPERATE | 393 | H |
| Diagnosis Procedure | 377 | OPEN/CLOSURE FUNCTION | 393 | I |
| SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE | 378 | OPEN/CLOSURE FUNCTION : Description | 393 | |
| Diagnosis Procedure | 378 | OPEN/CLOSURE FUNCTION : Diagnosis Procedure | 393 | J |
| AUTO DOOR LOCK OPERATION DOES NOT OPERATE | 379 | OPEN FUNCTION | 393 | |
| Diagnosis Procedure | 379 | OPEN FUNCTION : Description | 393 | |
| VEHICLE SPEED SENSING AUTO LOCK OPERATION DOES NOT OPERATE | 380 | OPEN FUNCTION : Diagnosis Procedure | 393 | DLK |
| Diagnosis Procedure | 380 | CLOSURE FUNCTION | 394 | |
| IGN OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE | 381 | CLOSURE FUNCTION : Description | 394 | L |
| Diagnosis Procedure | 381 | CLOSURE FUNCTION : Diagnosis Procedure | 394 | |
| P RANGE INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE | 382 | AUTOMATIC BACK DOOR OPERATION DOES NOT OPERATE | 395 | M |
| Diagnosis Procedure | 382 | ALL SWITCHES | 395 | |
| HAZARD AND HORN REMINDER DOES NOT OPERATE | 383 | ALL SWITCHES : Description | 395 | N |
| Diagnosis Procedure | 383 | ALL SWITCHES : Diagnosis Procedure | 395 | |
| HAZARD AND BUZZER REMINDER DOES NOT OPERATE | 384 | AUTOMATIC BACK DOOR SWITCH | 395 | O |
| Diagnosis Procedure | 384 | AUTOMATIC BACK DOOR SWITCH : Description | 395 | |
| KEY REMINDER FUNCTION DOES NOT OPERATE | 385 | AUTOMATIC BACK DOOR SWITCH : Diagnosis Procedure | 396 | P |
| Diagnosis Procedure | 385 | AUTOMATIC BACK DOOR CLOSE SWITCH | 396 | |
| | | AUTOMATIC BACK DOOR CLOSE SWITCH : Description | 396 | |
| | | AUTOMATIC BACK DOOR CLOSE SWITCH : Diagnosis Procedure | 396 | |
| | | INTELLIGENT KEY | 396 | |

| | | | |
|---|------------|--|------------|
| INTELLIGENT KEY : Description | 397 | UNLOCK-LINKED OPENING FUNCTION : De- scription | 406 |
| INTELLIGENT KEY : Diagnosis Procedure | 397 | UNLOCK-LINKED OPENING FUNCTION : Diag- nosis Procedure | 406 |
| BACK DOOR OPENER SWITCH | 397 | HOLD FUNCTION | 407 |
| BACK DOOR OPENER SWITCH : Description | 397 | HOLD FUNCTION : Description | 407 |
| BACK DOOR OPENER SWITCH : Diagnosis Pro- cedure | 397 | HOLD FUNCTION : Diagnosis Procedure | 407 |
| OPEN/CLOSURE FUNCTION | 398 | ANTI-PINCH FUNCTION | 408 |
| OPEN/CLOSURE FUNCTION : Description | 398 | ANTI-PINCH FUNCTION : Description | 408 |
| OPEN/CLOSURE FUNCTION : Diagnosis Proce- dure | 398 | ANTI-PINCH FUNCTION : Diagnosis Procedure . | 408 |
| OPEN FUNCTION | 398 | INTERMITTENT CLUTCH FUNCTION | 409 |
| OPEN FUNCTION : Description | 398 | INTERMITTENT CLUTCH FUNCTION : Descrip- tion | 409 |
| OPEN FUNCTION : Diagnosis Procedure | 398 | INTERMITTENT CLUTCH FUNCTION : Diagno- sis Procedure | 409 |
| CLOSURE FUNCTION | 399 | HAZARD AND BUZZER REMINDER FUNCTION . | 409 |
| CLOSURE FUNCTION : Description | 399 | HAZARD AND BUZZER REMINDER FUNCTION : Description | 409 |
| CLOSURE FUNCTION : Diagnosis Procedure | 399 | HAZARD AND BUZZER REMINDER FUNCTION : Diagnosis Procedure | 409 |
| AUTOMATIC BACK DOOR WARNING DOES NOT OPERATE | 400 | SLIDING DOOR AUTO CLOSURE FUNCTION | 410 |
| BUZZER | 400 | SLIDING DOOR AUTO CLOSURE FUNCTION : Description | 410 |
| BUZZER : Description | 400 | SLIDING DOOR AUTO CLOSURE FUNCTION : Diagnosis Procedure | 410 |
| BUZZER : Diagnosis Procedure | 400 | AUTOMATIC SLIDING DOOR OPEN/CLOSE FUNCTION DOES NOT OPERATE | 412 |
| HAZARD WARNING LAMP | 400 | ALL SWITCHES | 412 |
| HAZARD WARNING LAMP : Description | 400 | ALL SWITCHES : Description | 412 |
| HAZARD WARNING LAMP : Diagnosis Proce- dure | 400 | ALL SWITCHES : Diagnosis Procedure | 412 |
| AUTOMATIC BACK DOOR FUNCTIONS DO NOT CANCEL | 402 | OUTSIDE HANDLE | 413 |
| Diagnosis Procedure | 402 | OUTSIDE HANDLE : Description | 413 |
| AUTOMATIC BACK DOOR ANTI-PINCH FUNCTION DOES NOT OPERATE | 403 | OUTSIDE HANDLE : Diagnosis Procedure | 413 |
| Diagnosis Procedure | 403 | INSIDE HANDLE | 414 |
| INTEGRATED HOMELINK TRANSMITTER DOES NOT OPERATE | 404 | INSIDE HANDLE : Description | 414 |
| Diagnosis Procedure | 404 | INSIDE HANDLE : Diagnosis Procedure | 414 |
| AUTOMATIC SLIDING DOOR SYSTEM DOES NOT OPERATE | 405 | INTELLIGENT KEY | 414 |
| ALL FUNCTIONS | 405 | INTELLIGENT KEY : Description | 414 |
| ALL FUNCTIONS : Description | 405 | INTELLIGENT KEY : Diagnosis Procedure | 415 |
| ALL FUNCTIONS : Diagnosis Procedure | 405 | SLIDING DOOR OPEN/CLOSE SWITCH | 415 |
| ONE-TOUCH UNLOCK FUNCTION | 405 | SLIDING DOOR OPEN/CLOSE SWITCH : De- scription | 415 |
| ONE-TOUCH UNLOCK FUNCTION : Description. | 405 | SLIDING DOOR OPEN/CLOSE SWITCH : Diag- nosis Procedure | 415 |
| ONE-TOUCH UNLOCK FUNCTION : Diagnosis Procedure | 405 | SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH | 416 |
| POWER ASSIST FUNCTION | 406 | SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH : Description | 416 |
| POWER ASSIST FUNCTION : Description | 406 | SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH : Diagnosis Procedure | 416 |
| POWER ASSIST FUNCTION : Diagnosis Proce- dure | 406 | | |
| UNLOCK-LINKED OPENING FUNCTION | 406 | | |

| | | |
|--|-----|-----|
| AUTOMATIC SLIDING DOOR FUNCTIONS | | |
| DO NOT CANCEL | 417 | |
| Diagnosis Procedure | 417 | |
| SQUEAK AND RATTLE TROUBLE DIAG- NOSES | 418 | |
| Work Flow | 418 | |
| Inspection Procedure | 420 | |
| Diagnostic Worksheet | 422 | |
| REMOVAL AND INSTALLATION | 424 | |
| HOOD | 424 | |
| Exploded View | 424 | |
| HOOD ASSEMBLY | 424 | |
| HOOD ASSEMBLY : Removal and Installation | 424 | |
| HOOD ASSEMBLY : Adjustment | 425 | |
| HOOD HINGE | 426 | |
| HOOD HINGE : Removal and Installation | 426 | |
| HOOD SUPPORT ROD | 427 | |
| HOOD SUPPORT ROD : Removal and Installa- tion | 427 | |
| RADIATOR CORE SUPPORT | 428 | |
| Exploded View | 428 | |
| Removal and Installation | 428 | |
| FRONT FENDER | 430 | |
| Exploded View | 430 | |
| FRONT FENDER | 430 | |
| FRONT FENDER : Removal and Installation | 430 | |
| HOOD SIDE COVER | 431 | |
| HOOD SIDE COVER : Removal and Installation .. | 431 | |
| FRONT DOOR | 432 | |
| Exploded View | 432 | |
| DOOR ASSEMBLY | 432 | |
| DOOR ASSEMBLY : Removal and Installation | 432 | |
| DOOR ASSEMBLY : Adjustment | 434 | |
| DOOR STRIKER | 435 | |
| DOOR STRIKER : Removal and Installation | 435 | |
| DOOR HINGE | 435 | |
| DOOR HINGE : Removal and Installation | 435 | |
| DOOR CHECK LINK | 436 | |
| DOOR CHECK LINK : Removal and Installation .. | 436 | |
| SLIDE DOOR | 437 | |
| Exploded View | 437 | |
| DOOR ASSEMBLY | 438 | |
| DOOR ASSEMBLY : Removal and Installation | 438 | |
| DOOR ASSEMBLY : Adjustment | 440 | |
| DOOR STRIKER | 441 | |
| DOOR STRIKER : Removal and Installation | 441 | |
| UPPER ROLLER | 441 | |
| UPPER ROLLER : Removal and Installation | 441 | A |
| REAR ROLLER | 442 | |
| REAR ROLLER : Removal and Installation | 442 | B |
| LOWER ROLLER | 442 | |
| LOWER ROLLER : Removal and Installation | 442 | |
| LOWER LATCH | 443 | |
| LOWER LATCH : Removal and Installation | 443 | C |
| DOVETAIL | 443 | |
| DOVETAIL : Removal and Installation | 443 | D |
| BUMPER RUBBER | 444 | |
| BUMPER RUBBER : Removal and Installation | 444 | E |
| SLIDE DOOR LOWER WEATHER-STRIP | 445 | |
| SLIDE DOOR LOWER WEATHER-STRIP : Re- moval and Installation | 445 | F |
| SLIDE DOOR OUTSIDE PROTECTOR | 445 | |
| SLIDE DOOR OUTSIDE PROTECTOR : Remov- al and Installation | 445 | G |
| SLIDE DOOR LOWER STRIKER | 446 | |
| SLIDE DOOR LOWER STRIKER : Removal and Installation | 446 | H |
| SLIDE DOOR LOWER STOPPER | 446 | |
| SLIDE DOOR LOWER STOPPER : Removal and Installation | 446 | I |
| SLIDE DOOR UPPER STOPPER | 447 | |
| SLIDE DOOR UPPER STOPPER : Removal and Installation | 447 | J |
| TOUCH SENSOR | 447 | |
| TOUCH SENSOR : Removal and Installation | 447 | DLK |
| SLIDE DOOR GUIDE RAIL | 449 | |
| Exploded View | 449 | L |
| SLIDE DOOR UPPER GUIDE RAIL | 449 | |
| SLIDE DOOR UPPER GUIDE RAIL : Removal and Installation | 449 | M |
| SLIDE DOOR REAR GUIDE RAIL | 450 | |
| SLIDE DOOR REAR GUIDE RAIL : Removal and Installation | 450 | N |
| SLIDE DOOR LOWER GUIDE RAIL | 450 | |
| SLIDE DOOR LOWER GUIDE RAIL : Removal and Installation | 450 | O |
| BACK DOOR | 451 | |
| Exploded View | 451 | P |
| BACK DOOR ASSEMBLY | 451 | |
| BACK DOOR ASSEMBLY : Removal and Installa- tion | 451 | |
| BACK DOOR ASSEMBLY : Adjustment | 454 | |
| BACK DOOR STRIKER | 455 | |

| | | | |
|---|------------|--|------------|
| BACK DOOR STRIKER : Removal and Installation | 455 | AUTOMATIC SLIDING DOOR UNIT : Removal and Installation | 474 |
| BACK DOOR HINGE | 456 | BACK DOOR LOCK | 476 |
| BACK DOOR HINGE : Removal and Installation .. | 456 | Exploded View | 476 |
| BACK DOOR STAY | 456 | DOOR LOCK | 476 |
| BACK DOOR STAY : Removal and Installation ... | 456 | DOOR LOCK : Removal and Installation | 476 |
| BACK DOOR STAY : Disposal | 457 | BACK DOOR SUPPORT ROD | 477 |
| BACK DOOR WEATHER-STRIP | 457 | BACK DOOR SUPPORT ROD : Removal and Installation | 477 |
| BACK DOOR WEATHER-STRIP : Removal and Installation | 457 | TOUCH SENSOR | 477 |
| HOOD LOCK | 459 | TOUCH SENSOR : Removal and Installation | 477 |
| Exploded View | 459 | EMERGENCY LEVER | 478 |
| HOOD LOCK | 459 | EMERGENCY LEVER : Unlock procedures | 478 |
| HOOD LOCK : Removal and Installation | 459 | FUEL FILLER LID OPENER | 479 |
| HOOD LOCK CONTROL CABLE | 460 | Exploded View | 479 |
| HOOD LOCK CONTROL CABLE : Removal and Installation | 460 | FUEL FILLER LID | 479 |
| HOOD LOCK CONTROL HANDLE | 460 | FUEL FILLER LID : Removal and Installation | 479 |
| HOOD LOCK CONTROL HANDLE : Removal and Installation | 461 | FUEL FILLER OPENER CABLE | 480 |
| Inspection | 461 | FUEL FILLER OPENER CABLE : Removal and Installation | 480 |
| FRONT DOOR LOCK | 463 | FUEL FILLER LID LOCK | 480 |
| Exploded View | 463 | FUEL FILLER LID LOCK : Removal and Installation | 480 |
| DOOR LOCK | 463 | INTERLOCK | 482 |
| DOOR LOCK : Removal and Installation | 463 | Exploded View | 482 |
| INSIDE HANDLE | 464 | SLIDE DOOR INTERLOCK | 482 |
| INSIDE HANDLE : Removal and Installation | 464 | SLIDE DOOR INTERLOCK : Removal and Installation | 482 |
| OUTSIDE HANDLE | 464 | FUEL FILLER INTERLOCK | 482 |
| OUTSIDE HANDLE : Removal and Installation ... | 464 | FUEL FILLER INTERLOCK : Removal and Installation | 482 |
| SLIDE DOOR LOCK | 466 | KEY CYLINDER | 484 |
| Exploded View | 466 | GLOVE BOX LID KEY CYLINDER | 484 |
| DOOR LOCK | 467 | GLOVE BOX LID KEY CYLINDER : Exploded View | 484 |
| DOOR LOCK : Removal and Installation | 467 | GLOVE BOX LID KEY CYLINDER : Removal and Installation | 484 |
| DOOR LOCK : Inspection and Adjustment | 469 | DOOR SWITCH | 486 |
| INSIDE HANDLE | 471 | Removal and Installation | 486 |
| INSIDE HANDLE : Removal and Installation | 471 | DOOR REQUEST SWITCH | 487 |
| OUTSIDE HANDLE | 471 | DRIVER SIDE | 487 |
| OUTSIDE HANDLE : Removal and Installation ... | 471 | DRIVER SIDE : Removal and Installation | 487 |
| REMOTE CONTROL ASSEMBLY | 472 | PASSENGER SIDE | 487 |
| REMOTE CONTROL ASSEMBLY : Removal and Installation | 473 | PASSENGER SIDE : Removal and Installation ... | 487 |
| LOCK RELEASE ACTUATOR | 473 | BACK DOOR | 487 |
| LOCK RELEASE ACTUATOR : Removal and Installation | 474 | BACK DOOR : Removal and Installation | 487 |
| AUTOMATIC SLIDING DOOR UNIT | 474 | | |

| | | | | |
|--|------------|---|------------|------------|
| INSIDE KEY ANTENNA | 488 | Removal and Installation | 496 | |
| INSTRUMENT CENTER | 488 | AUTOMATIC DOOR MAIN SWITCH | 497 | A |
| INSTRUMENT CENTER : Removal and Installation | 488 | Exploded View | 497 | |
| CONSOLE | 488 | Removal and Installation | 497 | B |
| CONSOLE : Removal and Installation | 488 | AUTOMATIC BACK DOOR CLOSE SWITCH. | 498 | |
| LUGGAGE ROOM | 488 | Removal and Installation | 498 | C |
| LUGGAGE ROOM : Removal and Installation | 488 | AUTOMATIC BACK DOOR SWITCH | 499 | |
| OUTSIDE KEY ANTENNA | 490 | Exploded View | 499 | D |
| DRIVER SIDE | 490 | Removal and Installation | 499 | |
| DRIVER SIDE : Removal and Installation | 490 | SLIDING DOOR CONTROL UNIT | 500 | E |
| PASSENGER SIDE | 490 | RH | 500 | |
| PASSENGER SIDE : Removal and Installation ... | 490 | RH : Removal and Installation | 500 | F |
| REAR BUMPER | 490 | LH | 500 | |
| REAR BUMPER : Removal and Installation | 490 | LH : Removal and Installation | 500 | G |
| INTELLIGENT KEY WARNING BUZZER | 491 | SLIDING DOOR OPEN/CLOSE SWITCH | 501 | |
| Removal and Installation | 491 | FRONT | 501 | H |
| REMOTE KEYLESS ENTRY RECEIVER | 492 | FRONT : Removal and Installation | 501 | |
| Removal and Installation | 492 | REAR | 501 | I |
| INTELLIGENT KEY BATTERY | 493 | REAR : Removal and Installation | 501 | |
| Removal and Installation | 493 | SLIDING DOOR LOCK ACTUATOR | 502 | J |
| BACK DOOR CONTROL UNIT | 494 | Removal and Installation | 502 | |
| Removal and Installation | 494 | AUTOMATIC SLIDING DOOR WARNING | | |
| AUTOMATIC BACK DOOR CONTROL MODULE | 495 | BUZZER | 503 | |
| Removal and Installation | 495 | Removal and Installation | 503 | DLK |
| AUTOMATIC BACK DOOR WARNING BUZZER | 496 | SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH | 504 | |
| | | Removal and Installation | 504 | L |

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010014965

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

Precaution for Procedure without Cowl Top Cover

INFOID:000000009648931

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



Precautions For Xenon Headlamp Service

INFOID:000000009648932

WARNING:

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector.

PRECAUTIONS

< PRECAUTION >

(Turning it ON outside the lamp case may cause fire or visual impairments.)

- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

CAUTION:

Comply with the following cautions to prevent any error and malfunction.

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

Precautions for Removing Battery Terminal

INFOID:000000009978844

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.


NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

NOTE:

The removal of 12V battery may cause a DTC detection error.



Work

INFOID:000000009648933

- After removing and installing the opening/closing parts, be sure to carry out fitting adjustments to check their operational.
- Check the lubrication level, damage, and wear of each part. If necessary, grease or replace it.

DLK

PREPARATION

< PREPARATION >



PREPARATION

PREPARATION

Special Service Tools



INFOID:000000009648934

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description |
|--|-----------------------------------|
| <p>(J-39570) Chassis ear</p>  <p>SIIA0993E</p> | <p>Locates the noise</p> |
| <p>(J-50397) NISSAN Squeak and Rattle Kit</p>  <p>SIIA0994E</p> | <p>Repairs the cause of noise</p> |



Commercial Service Tools

INFOID:000000009648935

| Tool name | Description |
|--|--|
| <p>Engine ear</p>  <p>SIIA0995E</p> | <p>Locates the noise</p> |
| <p>Remover tool</p>  <p>JMKIA3050ZZ</p> | <p>Removes the clips, pawls, and metal clips</p> |

PREPARATION

< PREPARATION >

| Tool name | Description |
|--|------------------------------|
| <p>Power tool</p>  <p>PIB1407E</p> | |
| <p>Hook and pick tool</p>  <p>JMJIA0490ZZ</p> | <p>Press tumbler stopper</p> |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

COMPONENT PARTS

< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

DOOR LOCK SYSTEM


DOOR LOCK SYSTEM : Component Parts Location

INFOID:000000009648936

Front View

COMPONENT PARTS

< SYSTEM DESCRIPTION >



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

- A. View with luggage room finisher removed
- B. View with roof finisher removed
- C. View with center console assembly removed
- D. View with cluster lid C removed
- E. Engine room LH

JMKIA8155GB

COMPONENT PARTS


< SYSTEM DESCRIPTION >

| No. | Component | Function |
|-----|---|---|
| 1. | Inside key antenna (luggage room) | DLK-27, "Inside Key Antenna" |
| 2. | Remote keyless entry receiver | DLK-27, "Remote Keyless Entry Receiver" |
| 3. | Inside key antenna (console) | DLK-27, "Inside Key Antenna" |
| 4. | Inside key antenna (instrument center) | DLK-27, "Inside Key Antenna" |
| 5. | TCM | Transmits shift position signal to BCM via CAN communication line Refer to TM-10, "CVT CONTROL SYSTEM : Component Parts Location" for detailed installation location |
| 6. | Push-button ignition switch | <ul style="list-style-type: none"> Inputs push-button ignition switch ON/OFF condition to BCM Inputs power switch ON/OFF condition to BCM Refer to SEC-6, "Component Parts Location" for detailed installation location |
| 7. | IPDM E/R | Sounds horn via CAN communication between BCM Refer to PCS-4, "IPDM E/R : Component Parts Location" for detailed installation location |
| 8. | BCM | <ul style="list-style-type: none"> BCM detects the vehicle status according to signals from each door switch, each outside/inside key antenna, and unlock sensor. BCM transmits drive signal to door lock actuator when BCM receives operation signal from remote keyless entry receiver and each switch Inputs back door open request signal to back door control unit Refer to BCS-4, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location |
| 9. | Combination meter | <ul style="list-style-type: none"> Displays each operation method guide and warning for system malfunction Performs operation method guide and warning with buzzer Transmits vehicle speed signal to CAN communication line Refer to MWI-6, "METER SYSTEM : Component Parts Location" for detailed installation location |
| 10. | Intelligent Key warning buzzer | DLK-28, "Intelligent Key Warning Buzzer" |
| 11. | Door lock and unlock switch (driver side) | DLK-28, "Door Lock and Unlock Switch (Driver Side)" |
| 12. | Front door outside handle assembly LH (outside key antenna) | DLK-27, "Front Door Outside Handle Assembly (Outside Key Antenna)" |
| 13. | Front door request switch (driver side) | DLK-28, "Front Door Request Switch" |
| 14. | Front door switch (driver side) | DLK-28, "Front Door Switch" |
| 15. | Front door lock assembly (driver side) | DLK-28, "Front Door Lock Assembly (Driver Side)" |
| 16. | Sliding door switch LH | DLK-31, "Sliding Door Switch" |
| 17. | Sliding door lock assembly LH | DLK-31, "Sliding Door Lock Assembly" |

Rear View

COMPONENT PARTS

< SYSTEM DESCRIPTION >



A. View with rear bumper removed

B. View with back door lower finisher removed

C. View with instrument lower panel RH removed

| No. | Component | Function |
|-----|---|--|
| 1. | Back door opener switch | DLK-29, "Back Door Opener Switch" |
| 2. | Back door request switch | DLK-29, "Back Door Request Switch" |
| 3. | Back door lock assembly | DLK-29, "Back Door Lock Assembly (Without Automatic Back Door System)" |
| 4. | Outside antenna (rear bumper) | DLK-27, "Outside Key Antenna (Rear Bumper)" |
| 5. | Back door control unit | DLK-29, "Back Door Control Unit (Without Automatic Back Door System)" |
| 6. | Sliding door switch RH | DLK-31, "Sliding Door Switch" |
| 7. | Front door switch (passenger side) | DLK-28, "Front Door Switch" |
| 8. | Front door outside handle assembly RH (outside key antenna) | DLK-27, "Front Door Outside Handle Assembly (Outside Key Antenna)" |
| 9. | Front door request switch (passenger side) | DLK-28, "Front Door Request Switch" |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

JMKIA8156GB

COMPONENT PARTS


< SYSTEM DESCRIPTION >

| No. | Component | Function |
|-----|--|--|
| 10. | Door lock and unlock switch (passenger side) | DLK-28, "Door Lock and Unlock Switch (Passenger Side)" |
| 11. | Selective unlock relay | DLK-29, "Selective Unlock Relay" |

AUTOMATIC BACK DOOR SYSTEM

AUTOMATIC BACK DOOR SYSTEM : Component Parts Location

INFOID:00000009648937



- A. View with luggage side upper finisher removed B. View with rear bumper removed

| No. | Component | Function |
|-----|-------------------------------|--|
| 1. | Remote keyless entry receiver | Receives Intelligent Key operation and transmits to BCM Refer to DLK-18, "DOOR LOCK SYSTEM : Component Parts Location" for detailed installation location |
| 2. | Combination meter | Transmits vehicle speed signal to CAN communication line Refer to MWI-6, "METER SYSTEM : Component Parts Location" for detailed installation location |
| 3. | BCM | Transmits and receives signal to the automatic back door control module Refer to BCS-4, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location |

COMPONENT PARTS

< SYSTEM DESCRIPTION >

| No. | Component | Function |
|-----|------------------------------------|---|
| 4. | TCM | Transmits shift position signal to BCM via CAN communication line Refer to TM-10, "CVT CONTROL SYSTEM : Component Parts Location" for detailed installation location |
| 5. | ABS actuator and electric unit | Transmits vehicle speed signal to CAN communication line Refer to BRC-9, "Component Parts Location" for detailed installation location |
| 6. | Back door touch sensor LH/RH | DLK-30, "Back Door Touch Sensor" |
| 7. | Automatic back door control module | DLK-30, "Automatic Back Door Control Module" |
| 8. | Automatic back door switch | DLK-30, "Automatic Back Door Switch" |
| 9. | Automatic door main switch | DLK-30, "Automatic Door Main Switch" |
| 10. | Automatic back door warning buzzer | DLK-30, "Automatic Back Door Warning Buzzer" |
| 11. | Automatic back door close switch | DLK-30, "Automatic Back Door Close Switch" |
| 12. | Back door lock assembly | DLK-30, "Back Door Lock Assembly (With Automatic Back Door System)" |
| 13. | Automatic back door opener switch | DLK-30, "Automatic Back Door Opener Switch" |

AUTOMATIC SLIDING DOOR SYSTEM

AUTOMATIC SLIDING DOOR SYSTEM : Component Parts Location

INFOID:000000009648938


RH

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

COMPONENT PARTS

< SYSTEM DESCRIPTION >



A. View with luggage side lower finisher RH removed B. View with sliding door finisher RH removed

| No. | Component | Function |
|-----|--------------------------------|--|
| 1. | ABS actuator and electric unit | Transmits vehicle speed signal to sliding door control unit via CAN communication line Refer to BRC-9, "Component Parts Location" for detailed installation location |
| 2. | TCM | Transmits shift position signal to sliding door control unit via CAN communication line Refer to TM-10, "CVT CONTROL SYSTEM : Component Parts Location" for detailed installation location |
| 3. | BCM | Transmits ignition switch ON signal, automatic sliding door operate request signal and sleep wake up signal to sliding door control unit via CAN communication line Refer to BCS-4, "BODY CONTROL SYSTEM : Component Parts Location" for detailed installation location |
| 4. | Combination meter | Transmits vehicle speed signal to sliding door control unit via CAN communication line Refer to MWI-6, "METER SYSTEM : Component Parts Location" for detailed installation location |

COMPONENT PARTS

< SYSTEM DESCRIPTION >

| No. | Component | | Function |
|-----|--|---------------------------------|--|
| 5. | Automatic sliding door open/close switch (driver side) | | DLK-30, "Automatic Sliding Door Open/Close Switch" |
| 6. | Remote keyless entry receiver | | Receives Intelligent Key operation and transmits to BCM Refer to DLK-18, "DOOR LOCK SYSTEM : Component Parts Location" for detailed installation location |
| 7. | Automatic sliding door unit RH | Encoder | DLK-30, "Automatic Sliding Door Unit" |
| | | Clutch | |
| | | Automatic sliding door motor | |
| 8. | Sliding door control unit RH | | DLK-31, "Sliding Door Control Unit" |
| 9. | Automatic sliding door warning buzzer RH | | DLK-31, "Automatic Sliding Door Warning Buzzer" |
| 10. | Sliding door switch RH | | DLK-31, "Sliding Door Switch" |
| 11. | Automatic sliding door one-touch open/close switch RH | | DLK-31, "Automatic Sliding Door One-Touch Open/Close Switch" |
| 12. | Remote control assembly RH | Child lock status switch | DLK-31, "Remote Control Assembly" |
| | | Sliding door handle switch | |
| 13. | Sliding door lock actuator RH | Sliding door lock actuator | DLK-31, "Sliding Door Lock Actuator" |
| | | Sliding door lock status switch | |
| 14. | Sliding door lock release actuator RH | | DLK-31, "Sliding Door Lock Release Actuator" |
| 15. | Sliding door lock assembly RH | Neutral switch | DLK-31, "Sliding Door Lock Assembly" |
| | | Full latch switch | |
| | | Half latch switch | |
| | | Sliding door closure motor | |
| 16. | Sliding door touch sensor RH | | DLK-31, "Sliding Door Touch Sensor" |
| 17. | Automatic sliding door open/close switch (rear RH) | | DLK-30, "Automatic Sliding Door Open/Close Switch" |


LH

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

COMPONENT PARTS

< SYSTEM DESCRIPTION >



- A. View with sliding door finisher LH re-moved
 B. View with luggage side lower finisher LH removed

| No. | Component | | Function |
|-----|--|---------------------------------|--|
| 1. | Automatic sliding door open/close switch (rear LH) | | DLK-30, "Automatic Sliding Door Open/Close Switch" |
| 2. | Sliding door touch sensor LH | | DLK-31, "Sliding Door Touch Sensor" |
| 3. | Remote control assembly LH | Child lock status switch | DLK-31, "Remote Control Assembly" |
| | | Sliding door handle switch | |
| 4. | Sliding door lock actuator LH | Sliding door lock actuator | DLK-31, "Sliding Door Lock Actuator" |
| | | Sliding door lock status switch | |
| 5. | Sliding door lock release actuator LH | | DLK-31, "Sliding Door Lock Release Actuator" |
| 6. | Sliding door lock assembly LH | Neutral switch | DLK-31, "Sliding Door Lock Assembly" |
| | | Full latch switch | |
| | | Half latch switch | |
| | | Sliding door closure motor | |
| 7. | Sliding door switch LH | | DLK-31, "Sliding Door Switch" |

COMPONENT PARTS


< SYSTEM DESCRIPTION >

| No. | Component | Function |
|-----|--|---|
| 8. | Sliding door control unit LH | DLK-31, "Sliding Door Control Unit" |
| 9. | Automatic sliding door warning buzzer LH | DLK-31, "Automatic Sliding Door Warning Buzzer" |
| 10. | Fuel filler lid status switch | DLK-32, "Fuel Filler Lid Sliding Door Unit" |
| 11. | Automatic sliding door unit LH | Encoder |
| | | Clutch |
| | | Automatic sliding door motor |
| 12. | Automatic door main switch | DLK-30, "Automatic Door Main Switch" |

Inside Key Antenna

INFOID:000000009648939

Inside key antenna detects that Intelligent Key is within the inside detection area, and then transmits detection status to BCM.



Front Door Outside Handle Assembly (Outside Key Antenna)


INFOID:000000009648940

- Outside key antenna detects that Intelligent Key is within the outside detection area, and then transmits detection status to BCM. Request signal is transmitted simultaneously to Intelligent Key.
- Outside key antenna is installed in side outside handle assembly.

Outside Key Antenna (Rear Bumper)

INFOID:000000009648941

- Outside key antenna (rear bumper) detects that Intelligent Key is within the outside detection area, and then transmits detection status to BCM. Request signal is transmitted simultaneously to Intelligent Key.
- Outside key antenna (rear bumper) is installed in the rear of rear bumper.




DLK

Remote Keyless Entry Receiver

INFOID:000000009648942

Remote keyless entry receiver receives button operation signal and key ID signal of Intelligent Key, and then transmits them to BCM.




COMPONENT PARTS

< SYSTEM DESCRIPTION >

Intelligent Key Warning Buzzer

INFOID:000000009648943

Intelligent Key warning buzzer warns the user, who is outside vehicle, of operation confirmation according to Intelligent Key operation and door request switch operation, or of an inappropriate operation.



Door Lock and Unlock Switch (Driver Side)

INFOID:000000009648944

- Door lock and unlock switch transmits door lock/unlock signal operation to BCM.
- Door lock and unlock switch is Integrated in the power window main switch.

Door Lock and Unlock Switch (Passenger Side)


INFOID:000000009648945

- Door lock and unlock switch transmits door lock/unlock signal operation to BCM.
- Door lock and unlock switch is Integrated in the front power window switch (passenger side).

Front Door Request Switch

INFOID:000000009648946


- Front door request switch (1) transmits door request switch signal to BCM.
- Front door request switch (1) integrated in outside handle assembly.



Front Door Switch

INFOID:000000009648947

Door switch detects open/close status of door and transmits door switch signal to BCM.



Front Door Lock Assembly (Driver Side)


INFOID:000000009648948

- Door lock actuator and unlock sensor are Integrated in driver door lock assembly.
- Door lock actuator receives lock/unlock signal from BCM, and then locks/unlocks driver door.

COMPONENT PARTS

< SYSTEM DESCRIPTION >


- Only front door lock assembly (driver side) integrates unlock sensor. Unlock sensor transmits lock/unlock status of driver seat to BCM.



Back Door Opener Switch

INFOID:000000009648949


- Back door opener switch (1) transmits back door opener switch signal to BCM.
- Back door opener switch (1) is integrated in outside handle (back door).



Back Door Request Switch

INFOID:000000009648950

- Back door request switch (1) transmits back door request switch signal to BCM.
- Back door request switch (1) is integrated in outside handle (back door).



Back Door Lock Assembly (Without Automatic Back Door System)

INFOID:000000009648951

Back door closure motor, half latch switch, open switch, close switch and back door switch are installed

- Closure motor: Inputs open/close signal from back door control unit and activates the back door auto closure operation.
- Half latch switch: Starts the closure motor close operation.
- Open switch: Stops the closure motor open operation.
- Close switch: Stops the closure motor close operation.
- Back door switch: Detects open/close status of back door and transmits signal to BCM.

Back Door Control Unit (Without Automatic Back Door System)

INFOID:000000009648952

Controls the back door auto closure system.

Selective Unlock Relay

INFOID:000000009648953

Detects open/close status of front door (passenger side) and transmits signal to BCM.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

Back Door Touch Sensor

INFOID:000000009648954

During back door close operation, the touch sensor detects any trapped foreign material.

Automatic Back Door Control Module

INFOID:000000009648955

Automatic back door control unit, encoder, automatic back door motor and clutch are installed.

- Automatic back door control unit: Controls the automatic back door system.
- Encoder: Automatic back door control unit receives the pulse signals from encoders A and B that occurred due to synchronization with the back door operation. The automatic back door control unit calculates the back door position, operation direction, and operation speed according to the received pulse signals.
- Automatic back door motor: Inputs open/close signal from automatic back door control unit and activates the automatic back door open/close operation.
- Clutch: Performs the duty control of the power supply to control the operation speed of the back door.

Automatic Back Door Switch

INFOID:000000009648956

Detects open/close operation of automatic back door

Automatic Door Main Switch

INFOID:000000009648957

- Controls automatic open/close operation of each switches.
- Transmits automatic door main switch signal to sliding door control unit and automatic back door control module.

Automatic Back Door Warning Buzzer

INFOID:000000009648958

Warns the user of the automatic back door condition and inappropriate operations with the buzzer sounds

Automatic Back Door Close Switch

INFOID:000000009648959

- Detects close operation of automatic back door.
- Transmits automatic back door close switch signal to automatic back door control module.

Back Door Lock Assembly (With Automatic Back Door System)

INFOID:000000009648960

Back door closure motor, half latch switch, open switch, close switch and back door switch are installed.

- Closure motor: Inputs open/close signal from automatic back door control module and activates the back door auto closure operation.
- Half latch switch: Starts the closure motor close operation.
- Open switch: Stops the closure motor open operation.
- Close switch: Stops the closure motor close operation.
- Back door switch: Inputs back door open/ close condition to BCM.

Automatic Back Door Opener Switch

INFOID:000000009648961

Door switch detects open/close status of door and transmits door switch signal to BCM.

- Detects open operation of automatic back door.
- Transmits automatic back door opener switch signal to automatic back door control module.

Automatic Sliding Door Open/Close Switch

INFOID:000000009648962

Transmits automatic sliding door open/close switch signal to sliding door control unit.

Automatic Sliding Door Unit

INFOID:000000009648963

Encoder, clutch and automatic sliding door motor are installed.

- Encoder: Sliding door control unit receives the pulse signals from encoders A and B that occurred due to synchronization with the sliding door operation. The sliding door control unit calculates the sliding door position, operation direction, and operation speed according to the received pulse signals.
- Clutch: Performs the duty control of the power supply to control the operation speed of the sliding door.
- Automatic sliding door motor: Inputs open/close signal from sliding door control unit and activates the automatic sliding door auto open/close operation.

COMPONENT PARTS

< SYSTEM DESCRIPTION >

Sliding Door Control Unit

INFOID:000000009648964

Controls the automatic sliding door system

Automatic Sliding Door Warning Buzzer

INFOID:000000009648965

Warns the user of the automatic sliding door condition and inappropriate operations with the buzzer sounds.

Automatic Sliding Door One-Touch Open/Close Switch

INFOID:000000009648966

Transmits automatic sliding door one-touch open/close switch signal to sliding door control unit.

Remote Control Assembly

INFOID:000000009648967


Child lock status switch and sliding door handle switch are installed.

- Child lock status switch: Detects lock/unlock status of sliding door child lock and transmits signal to sliding door control unit.
- Sliding door handle switch: Detects operation/non-operation status of sliding door handle and transmits signal to sliding door control unit.

Sliding Door Switch

INFOID:000000009648968

Door switch detects open/close status of door and transmits door switch signal to BCM.



Sliding Door Lock Actuator

INFOID:000000009648969

SLIDING DOOR LOCK ACTUATOR

Child lock status switch and sliding door handle switch are installed.

SLIDING DOOR LOCK STATUS SWITCH

- Child lock status switch: Detects lock/unlock status of sliding door child lock and transmits signal to sliding door control unit.
- Sliding door handle switch: Detects operation/non-operation status of sliding door handle and transmits signal to sliding door control unit.

Sliding Door Lock Release Actuator

INFOID:000000009648970

Inputs release signal from sliding door control unit and releases sliding door latch

Sliding Door Lock Assembly

INFOID:000000009648971

- Door lock actuator is Integrated in driver door lock assembly.
- Door lock actuator receives lock/unlock signal from BCM, and then locks/unlocks sliding door.
- Neutral switch, full latch switch, half latch switch and sliding door closure motor are installed.
 - Neutral switch: Detects neutral position of sliding door closure motor.
 - Full latch switch: Detects fully closed status of sliding door.
 - Half latch switch: Detects half latch status of sliding door.
 - Sliding door closure motor: Inputs close signal from sliding door control unit and activates the sliding door auto closure operation.

Sliding Door Touch Sensor

INFOID:000000009648972

During sliding door close operation, the touch sensor detects any trapped foreign material.

A
B
C
D
E
F
G
H
I
J

DLK

L
M
N
O
P

COMPONENT PARTS

< SYSTEM DESCRIPTION >

Fuel Filler Lid Sliding Door Unit

INFOID:000000009648973

- Detects open/close status of fuel filler lid and transmits signal to sliding door control unit.
- Integrated in fuel filler interlock assembly.

SYSTEM (POWER DOOR LOCK SYSTEM)


< SYSTEM DESCRIPTION >

SYSTEM (POWER DOOR LOCK SYSTEM)

System Description

INFOID:000000009648974

SYSTEM DIAGRAM



*1:With driver side window anti-pinch

*2:With front window anti-pinch

DOOR LOCK FUNCTION

Door Lock and Unlock Switch

- The door lock and unlock switch (driver side) is build into power window main switch.
- The door lock and unlock switch (passenger side) is build into front power window switch (passenger side).
- Interlocked with the locking operation of door lock and unlock switch, door lock actuators of all doors are locked.
- Interlocked with the unlocking operation of door lock and unlock switch, door lock actuators of all doors actuator are unlocked.

Door Key Cylinder Switch

- With the mechanical key inserted in the door key cylinder on driver side, turning it to lock position, locks door lock actuator of all doors .
- With the mechanical key inserted in the door key cylinder on driver side, turning it to unlock position once unlocks the driver side door, turning it to unlock position again within 60 seconds after the first unlock operation unlocks all of the other doors actuator . (SELECTIVE UNLOCK OPERATION)

Selective unlock operation mode can be changed using CONSULT.

Refer to [DLK-94. "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

DOOR KEY CYLINDER SWITCH POWER WINDOW FUNCTION

Driver side door key cylinder LOCK/UNLOCK operation can activate power window. Refer to [PWC-9. "System Description"](#) (with front window anti-pinch), [PWC-73. "System Description"](#) (driver side window anti-pinch).

IGNITION POSITION WARNING FUNCTION

When door lock and unlock switch are operated while driver side door is open and ignition position is ACC or ON, door locks once but immediately unlocks.

INTERIOR ROOM LAMP CONTROL FUNCTION

Interior room lamp is controlled according to door lock/unlock state, refer to [INL-6. "INTERIOR ROOM LAMP CONTROL SYSTEM : System Description"](#).

AUTOMATIC DOOR LOCK/UNLOCK FUNCTION (LOCK OPERATION)

The interlock door lock function is the function that locks all doors linked with the vehicle speed or shift position. It has 2 types as per the following items.

Vehicle Speed Sensing Auto Door Lock

All doors are locked when the vehicle speed reaches 24 km/h (15 MPH) or more.

SYSTEM (POWER DOOR LOCK SYSTEM)

< SYSTEM DESCRIPTION >

BCM outputs the lock signal to all door lock actuators when it detects that the ignition switch is turned ON, all doors are closed and the vehicle speed received from the combination meter via CAN communication becomes 24 km/h (15 MPH) or more.

P Range Interlock Door Lock

All doors are locked when shifting the selector lever from the P position to any position other than P. BCM outputs the lock signal to all door lock actuators when it detects that the ignition switch is in the ON position, all doors are closed and the shift signal received from the TCM via CAN communication shifted from the P position to any position other than P.

Setting change of Automatic Door Lock/Unlock Function

The lock operation setting of the automatic door lock/unlock function can be changed.

With CONSULT

The ON/OFF switching of the automatic door lock function and the type selection of the automatic door lock/unlock function can be performed at the WORK SUPPORT setting of CONSULT.

Without CONSULT

The automatic door lock function ON/OFF can be switched by performing the following operation.

1. Close all doors (door switch OFF)
2. Ignition switch: OFF→ON
3. Press and hold the door lock and unlock switch for 5 seconds or more in the lock direction within 20 seconds after turning the ignition switch ON.
4. The switching complete when the hazard lamp blinks.

OFF → ON : 2 blinks

ON → OFF : 1 blink

AUTOMATIC DOOR LOCK/UNLOCK FUNCTION (UNLOCK OPERATION)

The automatic door lock/unlock function is the function that unlocks all doors linked with the key position or shift position. It has 2 types as per the following items.

IGN OFF Interlock Door Unlock

All doors are unlocked when the power supply position is changed from ON to OFF. BCM outputs the unlock signal to all door lock actuators when it detects that the power supply position is changed from ignition switch ON to OFF.

P Range Interlock Door Unlock

All doors are unlocked when shifting the selector lever from any position other than the P to P position. BCM outputs the unlock signal to all door lock actuators when it detects that the ignition switch is in the ON position and the shift signal received from TCM via CAN communication is shifted from any position other than the P to P position.

Setting change of Automatic Door Lock/Unlock Function

The unlock operation setting of the automatic door lock/unlock function can be changed.

With CONSULT

The ON/OFF switching of the automatic door lock/unlock function and the type selection of the automatic door lock/unlock function can be performed at the WORK SUPPORT setting of CONSULT.

Without CONSULT

The automatic door lock/unlock function ON/OFF can be switched by performing the following operation.

1. Close all doors (door switch OFF)
2. Ignition switch: OFF→ON
3. Press and hold the door lock and unlock switch for 5 seconds or more in the unlock direction within 20 seconds after turning the power supply position ON.
4. The switching is complete when the hazard lamp blinks.

OFF → ON : 2 blinks


ON → OFF : 1 blink

SYSTEM (POWER DOOR LOCK SYSTEM)

< SYSTEM DESCRIPTION >

Circuit Diagram

INFOID:000000009648975



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SYSTEM (INTELLIGENT KEY SYSTEM)


< SYSTEM DESCRIPTION >

SYSTEM (INTELLIGENT KEY SYSTEM) INTELLIGENT KEY SYSTEM

INTELLIGENT KEY SYSTEM : System Description

INFOID:000000009648976

SYSTEM DIAGRAM



*1:With back door auto closure system

*2:With automatic back door system

*:With automatic sliding door system

- The Intelligent Key system is a system that makes it possible to lock and unlock the door locks (door lock/unlock function) by carrying the Intelligent Key, which operates based on the results of electronic ID verification using two-way communication between the Intelligent Key and the vehicle (BCM).

NOTE:

The driver should always carry the Intelligent Key

- The settings for each function can be changed with CONSULT.
- If an Intelligent Key is lost, a new Intelligent Key can be registered. A maximum of 4 Intelligent Keys can be registered.
- It is possible to perform a diagnosis on the system and register an Intelligent Key with CONSULT.

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

| Function | Description | Refer |
|----------------------------|--|------------------------|
| Door lock | Lock/unlock can be performed by pressing the request switch | DLK-40 |
| Back door opener | The back door can be opened by carrying the Intelligent Key and pressing the back door opener switch | DLK-42 |
| Remote keyless entry | Lock/unlock can be performed by pressing the remote controller button of the Intelligent Key | DLK-44 |
| Key reminder | The key reminder buzzer sounds a warning if the door is locked with the key left inside the vehicle | DLK-47 |
| Warning | If an action that does not meet the operating condition of the Intelligent Key system is taken, the buzzer sounds to inform the driver | DLK-47 |
| Engine start | The engine can be turned on while carrying the Intelligent Key | SEC-10 |
| Interior room lamp control | Interior room lamp is controlled according to door lock/unlock state | INL-6 |
| Power window | Power window can be operated by Intelligent Key button operation | PWC-9 |
| Automatic drive positioner | Automatic drive positioner system can be operated by door unlock operation | ADP-9 |
| Panic alarm | When Intelligent Key panic alarm button is pressed, horn sounds | SEC-21 |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >


INTELLIGENT KEY SYSTEM : Circuit Diagram

INFOID:00000009648977



SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >



DOOR LOCK FUNCTION


SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

DOOR LOCK FUNCTION : System Description

INFOID:00000009648978

SYSTEM DIAGRAM



DOOR REQUEST SWITCH OPERATION

Only when pressing the door request switch, it is possible to lock and unlock the door by carrying the Intelligent Key.

OPERATION DESCRIPTION

- When the BCM detects that each door request switch is pressed, it activates the outside key antenna and inside key antenna corresponding to the pressed door request switch and transmits the request signal to the Intelligent Key. And then, check that the Intelligent Key is near the door.
- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- BCM locks/unlocks each doors.
- BCM sounds Intelligent Key warning buzzer (lock: 2 times, unlock: 1 time) and blinks hazard warning lamps (lock: 2 times, unlock: 1 time) at the same time as a reminder.

OPERATION CONDITION

If the following conditions are satisfied, door lock/unlock operation is performed if the door request switch is operated.

| Each door request switch operation | Operation condition |
|------------------------------------|--|
| Lock | <ul style="list-style-type: none"> • All doors are closed • Panic alarm is not activated • P position warning is not activated • Intelligent Key is outside the vehicle • Intelligent Key is within outside key antenna detection area* |
| Unlock | <ul style="list-style-type: none"> • Panic alarm is not activated • Intelligent Key is outside the vehicle • Intelligent Key is within outside key antenna detection area* |


*: Even with a registered Intelligent Key remaining inside the vehicle, door locks can be locked/unlocked from outside of the vehicle with a spare Intelligent Key as long as key IDs are different.

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

OUTSIDE KEY ANTENNA DETECTION AREA

The outside key antenna detection area of door lock/unlock function is in the range of approximately 80 cm (31.50 in) surrounding the driver, passenger door handles (1) and back door handle (2). However, this operating range depends on the ambient conditions.



SELECTIVE UNLOCK FUNCTION

Lock Operation

When an LOCK signal is sent from door request switch (driver side, passenger side, back door), all doors and fuel filler lid are locked.

Unlock Operation

- When an UNLOCK signal from driver side door request switch is transmitted, driver side door are unlocked. When another UNLOCK signal is transmitted within 60 seconds, all other doors are unlocked, back door open permission is set.
- When an UNLOCK signal from passenger side door request switch is transmitted, passenger side door is unlocked. When another UNLOCK signal is transmitted within 60 seconds, all other doors are unlocked, back door open permission is set.
- When an UNLOCK signal from back door request switch is transmitted, back door open permission is set. When another UNLOCK signal is transmitted within 60 seconds, all doors are unlocked.
- Only the door, of which one touch switch is pressed, unlock and starts automatic open operation when one-touch switch of sliding door is pressed.

How To Change Selective Unlock Operation Mode

Selective unlock operation mode can be changed using CONSULT.

Refer to [DLK-95. "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)".](#)

HAZARD AND BUZZER REMINDER FUNCTION

During lock or unlock operation by each door request switch, the hazard warning lamps and Intelligent Key warning buzzer blinks or honks as a reminder.

Operating Function Of Hazard And buzzer Reminder

| Operation | Hazard warning lamp blinks | Intelligent Key warning buzzer honks |
|-----------|----------------------------|--------------------------------------|
| Unlock | Once | Once |
| Lock | Twice | Twice |

Hazard and buzzer reminder does not operate in the following conditions.

- Ignition switch position is ON
- Door is open (only lock operation)

How To Change Hazard And Buzzer Reminder Mode

Hazard and buzzer reminder mode can be changed using CONSULT.

Refer to [DLK-95. "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)".](#)

AUTO DOOR LOCK FUNCTION

After door is unlocked by door request switch operation and if 60 seconds or more passes without performing the following operation, all doors are automatically locked. However, operation check function does not activate.

| | |
|---------------------|--|
| Operating condition | <ul style="list-style-type: none"> • Door switch is ON (door is open) • Door is locked • Push switch is pressed |
|---------------------|--|

How To Change Auto Door Lock Operation Mode

Auto door lock operation mode can be changed using CONSULT.

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

Refer to [DLK-95. "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)".](#)

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.


| Function | Intelligent Key | Remote keyless entry receiver | Door switch | Door request switch | Door lock actuator | Inside key antenna | Outside key antenna | CAN communication system | BCM | Hazard warning lamp | Intelligent Key warning buzzer | Push-button ignition switch |
|---------------------------|-----------------|-------------------------------|-------------|---------------------|--------------------|--------------------|---------------------|--------------------------|-----|---------------------|--------------------------------|-----------------------------|
| Door lock/unlock function | × | × | × | × | × | × | × | | × | | | |
| Hazard reminder function | | | | | | | | × | × | × | × | |
| Selective unlock function | × | | | × | × | × | × | | × | | | |
| Auto door lock function | × | | | | × | | | | × | | | × |

BACK DOOR OPEN FUNCTION

BACK DOOR OPEN FUNCTION : System Description

INFOID:000000009648979

BACK DOOR OPEN OPERATION



*1:With back door auto closure system

*2:With automatic back door system

BACK DOOR OPEN OPERATION

This section describes the operation of the back door opener switch.

- The back door open function can open the back door by pressing the back door opener switch while carrying the Intelligent Key and all doors are locked.
- The back door open function enables the back door to be opened by pressing back door opener switch after BCM transmits UNLOCK signal to each door. Refer to [DLK-52. "System Description".](#)

BACK DOOR OPEN (WITH BACK DOOR AUTO CLOSURE SYSTEM MODELS)

- When the BCM detects that back door opener switch is pressed, it activates the outside key antenna (rear bumper) and inside key antenna and transmits the request signal to the Intelligent Key. And then, check that the Intelligent Key is near the back door.
- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- If the verification result is OK, BCM transmits the back door open request signal to back door control unit.

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

- Back door control unit transmits back door open request signal to back door lock assembly and back door is open.
- When back door is open, back door auto closure system performs waiting operation for next back door close operation.
The operation of then back door open is the same as the back door auto closure system, refer to [DLK-52, "System Description"](#).

BACK DOOR OPEN (WITH AUTOMATIC BACK DOOR SYSTEM MODELS)

- When the BCM detects that back door opener switch is pressed, it activates the outside key antenna (rear bumper) and inside key antenna and transmits the request signal to the Intelligent Key. And then, check that the Intelligent Key is near the back door.
- If the Intelligent Key is within the outside key antenna detection area, it receives the request signal and transmits the key ID signal to the BCM via remote keyless entry receiver.
- BCM receives the key ID signal and compares it with the registered key ID.
- If the verification result is OK, BCM transmits the back door open request signal to automatic back door control module via CAN communication.
- Automatic back door control module transmits back door open request signal to back door lock assembly and back door is open.
- When the back door is open, automatic back door system performs waiting operation for next back door close operation.
The operation of then back door open is the same as the automatic back door system, refer to [DLK-61, "OPEN FUNCTION : System Description"](#).


OPERATION CONDITION

If the following conditions are not satisfied, back door open operation is not performed even if the back door opener switch is operated.

| Back door opener switch operation | Operation condition |
|-----------------------------------|--|
| Back door open | <ul style="list-style-type: none"> • Vehicle speed is less than 5 km/h (3 MPH) • Intelligent Key is within outside key antenna (back door) detection area • Back door is closed • Panic alarm is not activated |

OUTSIDE KEY ANTENNA DETECTION AREA

The outside key antenna detection area of back door open function is in the range of approximately 80 cm (31.50 in) surrounding the outside key antenna (rear bumper) (1). However, this operating range depends on the ambient conditions.



DLK

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

| Function | Intelligent Key | Remote keyless entry receiver | Back door opener switch | Back door lock assembly | Inside key antenna | Outside key antenna (rear bumper) | CAN communication system | BCM | Back door control unit*1 | Automatic back door control module*2 |
|-------------------------|-----------------|-------------------------------|-------------------------|-------------------------|--------------------|-----------------------------------|--------------------------|-----|--------------------------|--------------------------------------|
| Back door open function | × | × | × | × | × | × | × | × | × | × |

*1:With back door auto closure system


*2:With automatic back door system

REMOTE KEYLESS ENTRY FUNCTION

REMOTE KEYLESS ENTRY FUNCTION : System Description

INFOID:000000009648980

SYSTEM DIAGRAM



*1:With automatic back door system

*2:With automatic sliding door system

BASIC OPERATION

The Intelligent Key has the same functions as the remote control entry system. Therefore, it can be used in the same manner as the remote controller by operating the door lock/unlock button.

OPERATION

Remote keyless entry system controls operation of the following items.

- Door lock/unlock function
- Selective unlock function
- Auto door lock function
- Hazard and horn reminder function
- Automatic back door open/close function
- Automatic sliding door open/close function

OPERATION AREA

To check that the Intelligent Key works normally, use within 1 m (3 ft) range of each doors, however the operable range may differ according to surroundings.

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

DOOR LOCK/UNLOCK FUNCTION

- When door lock/unlock button of the Intelligent Key is pressed, lock signal or unlock signal transmitted from Intelligent Key to BCM via remote keyless entry receiver.
- BCM receives the signal and compares it with the registered key ID to the vehicle.
- When BCM receives the door lock/unlock signal, it operates all door lock actuators, blinks the hazard lamp (lock: 2 time, unlock: 1 times) and horn chirp signal to IPDM E/R at the same time as a reminder.
- IPDM E/R honks horn (lock: 1 time) as a reminder.

OPERATION CONDITION

If the following condition are satisfied, remote keyless entry operation is performed when the Intelligent Key is operated.

| Remote controller operation | Operation condition |
|-----------------------------|---|
| Lock | <ul style="list-style-type: none"> • Panic alarm is not activated • P position warning is not activated |
| Unlock | Panic alarm is not activated |

SELECTIVE UNLOCK FUNCTION

- When an LOCK signal is transmitted from Intelligent Key, all doors are locked.
- When an UNLOCK signal is transmitted from Intelligent Key once, driver side door is unlocked.
- Then, if an UNLOCK signal is transmitted from Intelligent Key again within 60 seconds, all other doors are unlocked. back door open permission is set.
- Only the door, of which back door button of Intelligent Key is pressed, unlock and starts automatic open operation when back door button of Intelligent Key of sliding door is pressed.

How to change selective unlock operation mode.

Selective unlock operation mode can be changed using CONSULT.

Refer to [DLK-94, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

AUTO DOOR LOCK FUNCTION

After door is unlocked by Intelligent Key button operation and if 60 seconds or more passes without performing the following operation, all doors are locked. However, operation check function does not activate.

| Operating condition | |
|---------------------|--|
| | <ul style="list-style-type: none"> • Door switch is ON (door is open) • Door is locked • Push switch is pressed |

How to change auto door lock operation mode.

Auto door lock mode can be changed using CONSULT.

Refer to [DLK-95, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

HAZARD AND HORN REMINDER FUNCTION

When doors are locked or unlocked by Intelligent Key, BCM blinks hazard warning lamps as a reminder and transmits horn chirp signal to IPDM E/R. IPDM E/R sounds horn as a reminder.

The hazard and horn reminder has a horn chirp mode (C mode) and a non-horn chirp mode (S mode).

Operating Function of Hazard and Horn Reminder

| | C mode | | S mode | |
|----------------------------|--------|--------|--------|--------|
| | Lock | Unlock | Lock | Unlock |
| Intelligent Key operation | Lock | Unlock | Lock | Unlock |
| Hazard warning lamp blinks | Twice | Once | Twice | — |
| Horn sound | Once | — | — | — |

Hazard and horn reminder does not operate in the following conditions.

- Ignition switch position is ON.
- Door is open (only lock operation)

How to Change Hazard and Horn Reminder Mode

With CONSULT

Hazard and horn reminder operation mode can be changed using CONSULT.


Refer to [DLK-95, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Without CONSULT

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

When LOCK and UNLOCK signals are sent from the Intelligent Key for more than 2 seconds at the same time, the hazard and horn reminder mode is changed and hazard warning lamp blinks and horn sounds as per the following items:



AUTOMATIC BACK DOOR OPEN/CLOSE FUNCTION

When back door button of Intelligent Key is pressed, back door open automatically for detailed description, refer to [DLK-52. "System Description"](#).

AUTOMATIC SLIDING DOOR OPEN/CLOSE FUNCTION

When sliding door button of Intelligent Key is pressed, sliding door open automatically for detailed description, refer to [DLK-64. "AUTOMATIC SLIDING DOOR SYSTEM : System Description"](#).

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

| Function | Intelligent Key | Door switch | Door lock actuator | Push-button ignition switch | CAN communication system | BCM | IPDM E/R | Horn | Combination meter | Hazard warning lamp | Intelligent Key warning buzzer | Automatic back door control module*1 | Sliding door control unit*2 |
|--|-----------------|-------------|--------------------|-----------------------------|--------------------------|-----|----------|------|-------------------|---------------------|--------------------------------|--------------------------------------|-----------------------------|
| Door lock/unlock function | × | × | × | | | × | | | | | | | |
| Selective unlock function | × | × | × | | | × | | | | | | | |
| Auto door lock function | × | × | × | × | | × | | | | | | | |
| Hazard and horn reminder function | | | | | × | × | × | × | × | × | × | | |
| Automatic back door open/close function | × | | | | × | × | | | | | | × | × |
| Automatic sliding door open/close function | × | | | | × | × | | | | | | | × |

*1:With automatic back door system

*2:With automatic sliding door system

KEY REMINDER FUNCTION


SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

KEY REMINDER FUNCTION : System Description

INFOID:000000009648981

SYSTEM DIAGRAM



*1:With back door auto closure system

*2:With automatic back door system

BASIC OPERATION

Key reminder is the function that prevents the key from being left in the vehicle. Key reminder has the following 3 functions.

| Key remainder function | Operation condition | Operation |
|------------------------|--|--|
| Driver door closed* | Right after driver side door is closed under the following conditions <ul style="list-style-type: none"> • Door lock operation is performed • Driver side door is open • Driver side door is in unlock state | All doors unlock |
| Door is open or closed | Right after all doors are closed under the following conditions <ul style="list-style-type: none"> • Intelligent Key is inside the vehicle • Any door is open • All doors are locked by door lock and unlock switch or door lock knob | <ul style="list-style-type: none"> • All doors unlock • Honk Intelligent Key warning buzzer |
| Back door is closed | Right after back door is closed under the following conditions <ul style="list-style-type: none"> • Intelligent Key is inside vehicle • All doors (except for back door) are closed • All doors (except for back door) are locked | <ul style="list-style-type: none"> • All doors unlock • Back door can open with back door opener switch • Honk Intelligent Key warning buzzer |

*: If the door closing impact shocks the door lock knob, or contacts against baggage with the door lock knob might activate the door locks accidentally but unlock operation is perform in these cases.

NOTE:

- The above function operates when the Intelligent Key is inside the vehicle. However, there may be times when the Intelligent Key cannot be detected, and this function does not operate when the Intelligent Key is on the instrument panel, rear parcel shelf, or in the glove box. Also, this system sometimes does not operate if the Intelligent Key is in the door pocket for the open door.

WARNING FUNCTION

WARNING FUNCTION : System Description

INFOID:000000009648982

OPERATION DESCRIPTION

The warning function are as per the following items and are given to the user as warning information and warnings using combinations of Intelligent Key warning buzzer, combination meter buzzer, KEY warning lamp and information display in combination meter.

- Intelligent Key system malfunction
- OFF position warning
- P position warning

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

- ACC warning
- Take away warning
- Door lock operation warning
- Engine start information
- Intelligent Key low battery warning
- Key ID warning
- Key ID verification information

OPERATION CONDITION

Once the following condition from below is established, alert or warning is executed.

| Warning/Information functions | | Operation procedure |
|------------------------------------|---------------------------------------|---|
| Intelligent Key system malfunction | | When a malfunction is detected on BCM, "KEY" warning lamp illuminates |
| OFF position warning | For internal | When condition A, B or condition C is satisfied <ul style="list-style-type: none"> • Condition A <ul style="list-style-type: none"> - Ignition switch: ACC position - Door switch (driver side): ON (Door is open) • Condition B <ul style="list-style-type: none"> - Turn ignition switch from ON to OFF while door is open • Condition C <ul style="list-style-type: none"> - Intelligent Key backside is contacted to ignition switch while brake pedal is depressed and ignition switch is LOCK or OFF (When the Intelligent Key battery is discharged) - Door switch (driver side): ON (Door is open) |
| | For external | OFF position warning (For internal) is in active mode, driver side door is closed NOTE: OFF position (For external) active only when each of the sequence occurs as below: P position warning → ACC warning → OFF position warning (For internal) → OFF position warning (For internal) |
| P position warning | For internal | <ul style="list-style-type: none"> • Shift position: Except P position • Engine is running to stopped (Ignition switch is ON to OFF) |
| | For external | Warning is activated when driver door is closed from the open position while the P position warning (for inside vehicle) is ON |
| ACC warning | | <ul style="list-style-type: none"> • When P position warning is in active mode, shift position changes P position • Ignition switch: ACC position |
| Take away warning | Door is open to close | <ul style="list-style-type: none"> • Ignition switch: Except LOCK position • Door switch: ON to OFF (Door is open to close) • Intelligent Key cannot be detected inside the vehicle |
| | Door is open | <ul style="list-style-type: none"> • Ignition switch: Except LOCK position • Door switch: ON (Door is open) • Key ID verification every 5 seconds when registered Intelligent Key cannot be detected inside the vehicle |
| | Push-button ignition switch operation | <ul style="list-style-type: none"> • Ignition switch: Except LOCK position • Press push-button ignition switch • Intelligent Key cannot be detected inside the vehicle |
| Door lock operation warning | | When door lock operation is requested while door lock operating condition of door request switch or Intelligent Key are not satisfied |




SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

| Warning/Information functions | | Operation procedure |
|-------------------------------------|--|---|
| Engine start information | Ignition switch is ON position | <ul style="list-style-type: none"> Ignition switch: ON position Shift position: P position Engine is stopped |
| | Ignition switch is except ON position | <ul style="list-style-type: none"> Ignition switch: Except ON position Shift position: P position Intelligent Key is in the passenger room after driver door is opened and closed. |
| | Ignition switch is ON position to OFF position | <ul style="list-style-type: none"> Ignition switch: ON position to OFF position Shift position: P position <p>NOTE: Engine start information turns ON for several seconds and then turns OFF, when ignition switch is turned to the ON position from the OFF position. Engine start information does not turn ON until opening and closing of driver door is detected again.</p> |
| Intelligent Key low battery warning | | When Intelligent Key is low battery, BCM is detected after ignition switch is turned ON |
| Key ID warning | | When registered Intelligent Key cannot be detected inside the vehicle after ignition switch is turned ON |
| Key ID verification information | | <ul style="list-style-type: none"> When registered Intelligent Key cannot be detected inside the vehicle Intelligent Key battery is discharged When NATS antenna amp cannot be detected NATS ID |





WARNING METHOD

The following table shows the alarm or warning methods with chime.

| Warning/Information functions | | "KEY" warning lamp | Information display (combination meter) | Warning chime | |
|------------------------------------|---------------------------------------|--------------------|---|--------------------------|--------------------------------|
| | | | | Combination meter buzzer | Intelligent Key warning buzzer |
| Intelligent Key system malfunction | | Indicate | — | — | — |
| OFF position warning | For internal | — | — | Activate | — |
| | For external | — | — | — | Activate |
| P position warning | For internal | — |  <p style="text-align: center; font-size: small;">JMKIA0037GB</p> | Activate | — |
| | For external | — | | — | Active |
| ACC warning | | — |  <p style="text-align: center; font-size: small;">JMKIA0047GB</p> | Activate | — |
| Take away warning | Door is open to close | — |  <p style="text-align: center; font-size: small;">JMKIA0036GB</p> | Activate | Activate |
| | Door is open | | | — | — |
| | Push button-ignition switch operation | | | Activate | — |

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

| Warning/Information functions | | "KEY" warning lamp | Information display (combination meter) | Warning chime | |
|-------------------------------------|--------------------------|--------------------|--|--------------------------|--------------------------------|
| | | | | Combination meter buzzer | Intelligent Key warning buzzer |
| Door lock operation warning | Request switch operation | — | — | — | Activate |
| | Intelligent Key | — | — | — | Activate |
| Key ID warning | | — |  <small>JMKIA0036GB</small> | — | — |
| Engine start information | | — |  <small>JMKIA0032GB</small> | — | — |
| Intelligent Key low battery warning | | — |  <small>JMKIA3049ZZ</small> | — | — |
| Key ID verification information | | — |  <small>JMKIA4907ZZ</small> | — | — |

LIST OF OPERATION RELATED PARTS

Parts marked with × are the parts related to operation.

| Warning function | Intelligent Key | Push-button Ignition switch | Door switch | Door request switch | Inside key antenna | Outside key antenna | Intelligent Key warning buzzer | Combination meter buzzer | CAN communication system | BCM | Information display | "KEY" warning lamp |
|----------------------|------------------------------------|-----------------------------|-------------|---------------------|--------------------|---------------------|--------------------------------|--------------------------|--------------------------|-----|---------------------|--------------------|
| | Intelligent Key system malfunction | | | | | | | | | × | × | |
| OFF position warning | For internal | | × | | | | | × | × | × | | |
| | For external | | × | | | | × | | | × | | |
| P position warning | | × | | | | | × | × | × | × | × | × |
| ACC warning | | × | | | | | × | × | × | × | × | |

SYSTEM (INTELLIGENT KEY SYSTEM)

< SYSTEM DESCRIPTION >

| Warning function | | Intelligent Key | Push-button Ignition switch | Door switch | Door request switch | Inside key antenna | Outside key antenna | Intelligent Key warning buzzer | Combination meter buzzer | CAN communication system | BCM | Information display | "KEY" warning lamp |
|-------------------------------------|---------------------------------------|-----------------|-----------------------------|-------------|---------------------|--------------------|---------------------|--------------------------------|--------------------------|--------------------------|-----|---------------------|--------------------|
| Take away warning | Door is open or close | × | | × | | × | | × | × | × | × | × | × |
| | Door is open | × | | × | | × | | | | × | × | × | × |
| | Push-button ignition switch operation | × | × | | | × | | | × | × | × | × | × |
| Door lock operation warning | | × | | × | × | × | × | × | | | × | | |
| Key ID warning | | | × | | | × | | | | × | × | × | × |
| Engine start information | Ignition switch is ON position | × | × | | | × | | | | × | × | × | |
| | Ignition switch is except ON position | × | × | | | × | | | | × | × | × | |
| Intelligent Key low battery warning | | × | | | | × | | | | × | × | × | × |
| Key ID verification information | | × | | | | × | | | | × | × | × | |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SYSTEM (AUTOMATIC BACK DOOR SYSTEM)


< SYSTEM DESCRIPTION >

SYSTEM (AUTOMATIC BACK DOOR SYSTEM)

System Description

INFOID:000000009648983

SYSTEM DIAGRAM



BASIC OPERATION

The automatic back door system performs the automatic open/close operation of the back door by operating the automatic back door switch, the automatic back door close switch, the back door opener switch, and Intelligent Key.

AUTOMATIC BACK DOOR OPEN/CLOSE FUNCTION

- In the case of the back door fully closed, operate the automatic back door switch, Intelligent Key or back door opener switch with the back door unlock. The back door closure motor releases the latch, then the automatic back door motor opens the back door to the fully open position. Reverse the closure motor to the neutral position simultaneously.
- In the case of the back door fully open, operate the automatic back door switch, Intelligent Key or automatic back door close switch. The automatic back door motor closes the back door to the half-latch position, then the back door closure motor to the full latch position. Then, reverse the closure motor to the neutral position.

SYSTEM (AUTOMATIC BACK DOOR SYSTEM)

< SYSTEM DESCRIPTION >

BACK DOOR AUTO CLOSURE FUNCTION

Open Function

When back door opener switch is pressed and automatic door main switch in the OFF position, BCM transmits the back door open request signal to automatic back door control module via CAN communication, and automatic back door control module opens back door lock assembly.

Closure Function

When the back door is closed to the half-latch position, the motor drives to rotate the latch lever and pulls it in from half latched to fully latched and automatically closes the door. Then, reverse the closure motor to the neutral position.

WARNING FUNCTION

The warning function is as follows and gives the user warning information and warnings using automatic back door buzzer and hazard.

Buzzer Operation Condition

| | Pattern | Time | Description |
|---|--------------|--|---|
| A | | 0.75 sec. | Operation start announcement |
| | | | Anti-pinch operation start announcement |
| B | Pi--- | 2.0 sec. | During the closure operation, the touch sensor detects any trapped foreign material and stops halfway |
| C | Pi-----●●●●● | Back door fully closed or vehicle is stopped | The conditions are not satisfied in the fully open position or during the operation, and then the operation continues |
| D | | During open/close operation | During operation announcement |
| | | | |

ANTI-PINCH FUNCTION

During auto operation, if an object is detected by encoder pulse in the door's path, a warning chime sounds and the back door operates in the reverse direction to prevent pinching.

During auto close operation, if an object is detected by the touch sensors in the door's path, a warning chime sounds and the back door operates in the open direction until it is fully open.

Operation Condition

| Detection method | | Encoder pulse | Touch sensor |
|---|---------------------|---|---|
| Applicable operation | | Open/close operation | Close operation |
| Operation when any trapped foreign material is detected | Stop the vehicle | Buzzer sounds (pattern A) and reverse operation | <ul style="list-style-type: none"> Buzzer sounds (pattern A) and the back door stops in the fully-open position after reverse operation During closure (close) operation (at main switch OFF): Closure [open (neutral position return)] operation |
| | Running the vehicle | No reverse operation (buzzer sounds, pattern C) | <ul style="list-style-type: none"> The back door reverses a certain amount, and then it reverses automatically to perform the auto close operation During closure (close) operation (at main switch ON): Closure (open) operation |

SYSTEM (AUTOMATIC BACK DOOR SYSTEM)

< SYSTEM DESCRIPTION >

| Detection method | Encoder pulse | Touch sensor |
|---|---|---|
| Non-reverse area | <ul style="list-style-type: none"> Just after starting the motor operation Full range of closure operation Driving | <ul style="list-style-type: none"> Back door open operation Closure [open (return the latch to the neutral position)] |
| Switch operation during reverse operation | Receive | |
| Number of allowable reverse operations | Perform the intermittent clutch function after 2 reverse operations regardless of the operation direction | |

INTERMITTENT CLUTCH FUNCTION

If the main switch is turned to OFF during auto operation, the back door may be closed suddenly because the operation is interrupted immediately when the operation cannot be continued because of the detection of a system malfunction. Therefore, operate the clutch intermittently to stabilize the back door behavior and ensure safety.

AUTOMATIC BACK DOOR OPEN/CLOSE OPERATION CONDITION

| | Automatic back door switch | | Intelligent Key | | Automatic back door close switch | Back door opener switch | |
|---|----------------------------|---------------------|---------------------|---------------------|----------------------------------|-------------------------|----------|
| | Fully closed → Open | Fully open → Closed | Fully closed → Open | Fully open → Closed | Fully open → Closed | Fully closed → Open | |
| Operating direction | Fully closed → Open | Fully open → Closed | Fully closed → Open | Fully open → Closed | Fully open → Closed | Fully closed → Open | |
| Main switch | — | — | — | — | ON | ON | |
| Ignition position | ON | ACC/LOCK | — | — | — | ON | ACC/LOCK |
| Shift selector lever | P position | — | — | — | — | P position | — |
| Vehicle speed | 0 km/h | | | | | | |
| Back door lock condition | — | — | — | — | — | Unlock* | |
| Touch sensor | Normal | | | | | | |
| Power supply (Automatic power back door control unit) | Approx. 11 V or more | | | | | | |

*: If the registered Intelligent Key is used, the operation can be performed even if the back door is in the LOCK position

CONTROL IF NOT WITHIN THE OPERATION CONDITIONS DURING THE OPERATION

If the back door is not within the operation conditions during the operation, the automatic back door control unit performs the control as follows.

| Item (Condition) | Back door condition |
|--|--|
| Main Switch (ON → OFF) | <ul style="list-style-type: none"> Motor: OFF Clutch: OFF (Intermittent clutch function) |
| Vehicle stop condition (open operation) <ul style="list-style-type: none"> IGN ON and shift P position → IGN ON and other than P position IGN OFF and shift N position → IGN ON and N position | The operation is continued |
| Operation condition release during the operation start announcement condition | Automatic back door function does not operate |

SYSTEM (AUTOMATIC BACK DOOR SYSTEM)

< SYSTEM DESCRIPTION >

| Item (Condition) | Back door condition | | |
|--|---|---|---|
| Vehicle speed (0 km/h → More than 0 km/h) | Open operation | Operation stop and intermittent clutch function [Back door fully closed or buzzer sounds until the vehicle stops (pattern C)] | A |
| | Close operation | The operation is continued [buzzer sounds (pattern C) until back door fully closed] | B |
| Touch sensor (Normal → Open) | Open operation | The operation is continued (If the pinch is detected after that, the system switches to the intermittent clutch function) | C |
| | Close operation | Intermittent clutch function | D |
| | Closure (close) operation | Closure (open) operation and buzzer sounds (pattern B) | E |
| | Closure [open (return the latch to the neutral position)] operation | The operation is continued | E |
| Operation time (More than approx. 30 sec.) | Intermittent clutch function | | F |
| Back door opener switch (OFF → ON) | Open/close operation | The operation is continued | G |
| | Closure (close) operation | Closure (open) operation and back door open | G |
| | Closure [open (return the latch to the neutral position)] operation | Back door open | H |
| Malfunction detected (IGN circuit, half latch switch and back door state) | Intermittent clutch function | | I |

TIME CHART FOR AUTOMATIC POWER BACK DOOR SYSTEM

Fully Closed to Fully Open Operation

When operating the automatic back door switch, automatic back door opener switch and Intelligent Key in the fully closed position, the system operates as follows.

DLK

L

M


N

O

P

SYSTEM (AUTOMATIC BACK DOOR SYSTEM)

< SYSTEM DESCRIPTION >



NOTE:

Output sequence for half latch switch, open switch, and close switch may vary depending on reaction force difference of back door weather-strip. When reaction force of back door weather-strip is strong, refer to a broken line in the chart.

When reaction force of back door weather-strip is not strong

1. Buzzer and hazard lamp operate after condition are satisfied.
2. After buzzer operation (pattern A), back door closure motor starts the open operation.
3. When the latch is released and reaction force of weather-strip is not strong, half latch switch does not turn ON, and back door closure motor stops the open operation when open switch turns ON. After this operation, automatic back door motor and magnet clutch operate, and then back door starts the open operation.
4. When door is lifted up, half latch switch turns ON, and then back door closure motor operates the reverse operation and starts returning to the neutral position.
5. When close switch turns OFF, back door closure motor stops the reverse operation and then completes returning to the neutral position.

When reaction force of back door weather-strip is strong


1. Buzzer and hazard lamp operate after condition are satisfied.
2. After buzzer operation (pattern A), back door closure motor starts the open operation.
3. When the latch is released, half latch switch turns ON, and then back door closure motor stops the open operation.
4. When automatic back door motor and clutch operate and back door starts the open operation, back door closure motor operates the reverse operation and starts returning to the neutral operation.
5. When close switch turns OFF, back door closure motor stops the reverse operation and then completes returning to the neutral position.

SYSTEM (AUTOMATIC BACK DOOR SYSTEM)

< SYSTEM DESCRIPTION >

Fully Open to Fully Closed Operation

When operating the automatic back door switch, automatic back door close switch and Intelligent Key, the automatic back door system operates as follows.



1. Operates the buzzer and hazard after the operation enable conditions are established
2. After the buzzer (pattern A) stops sounding, operates the automatic back door motor and clutch to perform the back door close operation
3. The back door closure motor performs the close operation after 300 msec. or more from turning the half latch switch to OFF
4. The back door closure motor performs the open operation after turning the close switch to ON
5. Stop the back door closure motor open operation and return the latch to the neutral position after turning the close switch to OFF


DLK

SYSTEM (AUTOMATIC BACK DOOR SYSTEM)

< SYSTEM DESCRIPTION >

Circuit Diagram

INFOID:00000009648984



JMKIA8115GB

SYSTEM (AUTOMATIC BACK DOOR SYSTEM)

< SYSTEM DESCRIPTION >

Fail Safe

INFOID:000000009648985

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|--|--|
| B2401 IGN OPEN | Intermittent clutch function | All following condition are satisfied <ul style="list-style-type: none"> Power supply condition of automatic back door control unit: OFF BCM receive ignition position signal (OFF) via CAN |
| B2403 PULSE ENCODER | Inhibit automatic back door operation | When receiving the pulse from encoders A and B normally (5 pulses) |
| B2409 HALF LATCH SW | Intermittent clutch function | Half latch switch is ON from OFF |
| B2416 TOUCH SEN R OPEN | During close operation: Intermittent clutch function | Normal return |
| B2417 TOUCH SEN L OPEN | During close operation: Intermittent clutch function | Normal return |
| B2419 OPEN SW | Inhibit automatic back door operation | Erase DTC, reconnect battery |
| B2420 CLOSE SW | Inhibit automatic back door operation | Erase DTC, reconnect battery |
| B2421 CLUTCH TIME OUT | Intermittent clutch function | Reception of next operation request |
| B2422 BACK DOOR STATE | Intermittent clutch function | Detect back door fully closed position |
| B2423 ABD MTR TIME OUT | Intermittent clutch function | Reception of next operation request |
| B2424 CLSR CONDITION | Inhibit automatic back door operation | Normal return or reconnect battery |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SYSTEM (BACK DOOR AUTO CLOSURE SYSTEM)


< SYSTEM DESCRIPTION >

SYSTEM (BACK DOOR AUTO CLOSURE SYSTEM) CLOSURE FUNCTION

CLOSURE FUNCTION : System Description

INFOID:000000009648986

SYSTEM DIAGRAM




AUTO CLOSURE OPERATION

When back door is closed to the half-latch position, closure motor operates to rotate the latch lever from the half latched to fully latched position and automatically closes back door. Then, closure motor reverses to the neutral position.

From fully Open to Fully Closed Operation

The back door closure system operates as per the following.



1. Back door is fully open.
2. Back door closure motor starts the close operation after turning half latch switch OFF.
3. Back door closure motor stops the close operation and starts the neutral operation after turning close switch ON.
4. Back door closure motor stops the open operation and returns the latch to the neutral position after turning open switch OFF.

OPEN FUNCTION


SYSTEM (BACK DOOR AUTO CLOSURE SYSTEM)

< SYSTEM DESCRIPTION >

OPEN FUNCTION : System Description

INFOID:000000009648987

SYSTEM DIAGRAM



OPEN OPERATION

- When the back door opener switch operation signal is input into back door control unit from BCM, back door is opened by the closure motor open operation.
- When back door opener switch is pressed, BCM transmits the back door open request signal to back door control unit and back door control unit opens back door.
- The operation to open back door with Intelligent Key is the same as the Intelligent Key system. Refer to [DLK-42. "BACK DOOR OPEN FUNCTION : System Description"](#)

Operation Condition

If the following conditions are satisfied, the back door opener operation is performed.

| Back door opener switch operation | Operation condition |
|-----------------------------------|--|
| Back door open | <ul style="list-style-type: none"> • When back door is unlocked using back door request switch (selective unlock mode), or after BCM outputs all doors unlock signal • Vehicle speed is less than 5 km/h (3 MPH) |

NOTE:

- When battery terminal is disconnected and reconnected during all doors unlock state, back door may not open.
- Regardless of door lock actuator state, BCM resets recognition of all doors unlock state approximately 30 seconds after battery terminal is disconnected and BCM recognizes that all doors are in lock state.
- When battery terminal is reconnected and back door does not open, have BCM recognize that all doors are in unlock state.

From Fully Closed To Fully Open Operation


A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SYSTEM (BACK DOOR AUTO CLOSURE SYSTEM)

< SYSTEM DESCRIPTION >

The back door open system operates as per the following.




1. Back door is fully closed.
2. Back door closure motor starts the open operation after turning back door opener switch ON.
3. Back door closure motor stops the open operation after turning open switch ON.
4. Back door closure motor starts the close operation after turning half latch switch ON.
5. Back door closure motor stops the close operation and returns the latch to the neutral position after turning close switch OFF.

SYSTEM (BACK DOOR AUTO CLOSURE SYSTEM)

< SYSTEM DESCRIPTION >

Circuit Diagram

INFOID:000000009648988



A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)


< SYSTEM DESCRIPTION >

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM) AUTOMATIC SLIDING DOOR SYSTEM

AUTOMATIC SLIDING DOOR SYSTEM : System Description

INFOID:000000009648989

SYSTEM DIAGRAM



* : For automatic sliding door LH

- Automatic sliding door system controls auto open/close operation of sliding door LH and sliding door RH.

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

- Sliding door control unit controls each function of automatic sliding door system.

| Function | Description | Refer |
|---------------------------|---|------------------------|
| Auto open/close | Sliding door is automatically opened or closed according to operation of sliding door handle, sliding door open/close switch, sliding door one-touch open/close switch, and Intelligent Key | DLK-70 |
| One-touch unlock | By carrying Intelligent Key, sliding door is unlocked and automatically opened according to operation of sliding door one-touch open/close switch, even when sliding door is in fully closed and locked status | DLK-75 |
| Unlock-linked opening | Sliding door is unlocked and automatically opened according to operation of sliding door open/close switch (front side) or Intelligent Key button, even when sliding door is in fully closed and locked status | DLK-77 |
| Power assist | Sliding door is automatically opened or closed according to direction of sliding door movement, when sliding door is manually opened or closed | DLK-79 |
| Sliding door auto closure | Sliding door closure motor operates and sliding door is automatically retracted and closed to fully closed status, when sliding door is in half latch status | DLK-81 |
| Hold | During vehicle driving, if sliding door is in open status because of incorrect operation or any other cause, sliding door control unit continuously keeps clutch to the ON position and holds the position of sliding door so that it does not open further | DLK-83 |
| Anti-pinch | During sliding door auto open/close operation, if pinching of foreign materials is detected, sliding door control unit operates sliding door in the reverse direction | DLK-85 |
| Intermittent clutch | During sliding door auto open/close operation, if system malfunction is detected, sliding door control unit operates clutch intermittently to the ON/OFF position and prevents sliding door from opening or closing suddenly, so that safety can be ensured | DLK-87 |
| Buzzer reminder | Automatic sliding door warning buzzer sounds so that user is informed of operation start when sliding door auto open/close operation starts to operate | DLK-88 |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

AUTOMATIC SLIDING DOOR SYSTEM : Circuit Diagram


INFOID:000000009648990



JMKIA8191GB

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >



AUTOMATIC SLIDING DOOR SYSTEM : Fail-safe

INFOID:000000009648991

FAIL-SAFE CONTROL BT DTC

Sliding door control unit performs fail-safe control when any DTC is detected.

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

| Display contents of CONSULT | Fail-safe | Reference page ^{*1} | A |
|-----------------------------|-------------------------------|---|-----|
| U1010: CAN COMM CIRCUIT | Intermittent clutch operation | Return to normal status ^{*2} | B |
| B2401: IGN OPEN | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Sliding door control unit detects that ignition switch is in the OFF position • Sliding door control unit detects that ignition switch is not in the ON position via CAN communication | C |
| B2402: TOUCH SENSOR OPEN | | Return to normal status | D |
| B2403: PULSE ENCODER | | Sliding door control unit detects that sliding door is in the fully closed position | E |
| B2405: ECU FAIL | | Erase DTC ^{*2} | F |
| B2409: HALF LATCH SW | | Sliding door control unit detects that sliding door is in the fully closed position | G |
| B2412: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position | H |
| B2413: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position | I |
| B2414: ASD MTR TIME OUT | | Sliding door control unit detects that sliding door is in the fully closed position | J |
| B241A: ENCDR PWR SUPPLY | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Return to normal status • Sliding door control unit detects that sliding door is in the fully closed position | DLK |

*1: When battery is reconnected, cancellation conditions are unconditionally fulfilled.

*2: After returning to normal status, auto open/close function does not operate unless sliding door auto closure function is operated.

AUTO OPEN/CLOSE FUNCTION

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

AUTO OPEN/CLOSE FUNCTION : System Description

INFOID:000000009648992

SYSTEM DIAGRAM



*: For automatic sliding door LH

Auto open/close function operates auto open/close of sliding door according to operation of sliding door handle, sliding door open/close switch, sliding door one-touch open/close switch, and Intelligent Key.

AUTO OPEN/CLOSE FUNCTION (OPEN OPERATION)

Sliding Door Handle Operation

- When sliding door handle is operated, sliding door handle switch, half latch switch, and full latch switch turn ON. Sliding door control unit sounds automatic sliding door warning buzzer as a reminder.

NOTE:

The function may not be operated unless sliding door handle is pulled continuously.

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

- Sliding door control unit operates sliding door lock release actuator, and then operates automatic sliding door motor to move sliding door to the fully open position. A
- When sliding door handle is operated again during auto open operation, sliding door control unit stops auto open operation and operates sliding door in reverse direction to the fully closed position.
- When child lock is in the lock status, auto open function does not operate even when sliding door inside handle is operated. B

Sliding Door Open/close Switch and Sliding Door One-touch Open/close Switch Operation

- When sliding door open/close switch or sliding door one-touch open/close switch is operated, sliding door control unit sounds automatic sliding door warning buzzer as a reminder. C
- Sliding door control unit operates clutch and sliding door lock release actuator, and it releases sliding door latch (only when sliding door is fully closed).
- Sliding door control unit detects half latch switch signal and full latch switch signal. When judging that sliding door latch is released, sliding door control unit operates automatic sliding door motor and it moves sliding door to the fully open position. D
- When switch is operated again during auto open operation, sliding door control unit stops auto open operation and operates sliding door in reverse direction to the fully closed position. E

Intelligent Key Button Operation

- When sliding door open button of Intelligent Key is operated, BCM transmits automatic sliding door operate request signal to sliding door control unit via CAN communication. F
- When automatic sliding door operate request signal is received from BCM, sliding door control unit sounds automatic sliding door warning buzzer as a reminder.
- Sliding door control unit operates clutch and sliding door lock release actuator, and it releases sliding door latch. (Only when sliding door is fully closed.) G
- Sliding door control unit detects half latch switch signal and full latch switch signal. When judging that sliding door latch is released, sliding door control unit operates automatic sliding door motor and it moves sliding door to the fully open position. H
- When Intelligent Key button is operated again during auto open operation, sliding door control unit stops auto open operation and operates sliding door in reverse direction to the fully closed position. I

OPERATION CONDITION

The auto open operation is performed, when the following conditions are satisfied. J

| Operation | Operation condition |
|---|--|
| Sliding door open/close switch (front side) | Vehicle speed: 0 km/h |
| | Battery voltage: 11 V or more |
| | Fuel filler lid: Closed status (Operation condition for sliding door LH) |
| | Shift position: P position* |
| | Sliding door: Not fully opened |
| | Sliding door: Unlocked while fully closed |
| | Vehicle security system: Not set |
| Intelligent Key | Vehicle speed: 0 km/h |
| | Battery voltage: 11 V or more |
| | Fuel filler lid: Closed status (Operation condition for sliding door LH) |
| | Shift position: P position* |
| | Sliding door: Not fully opened |
| | Sliding door: Unlocked while fully closed |

DLK

L

M

N

O

P

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

| Operation | Operation condition |
|--|--|
| Sliding door open/close switch (rear side) | Automatic door main switch: ON |
| | Vehicle speed: 0 km/h |
| | Battery voltage: 11 V or more |
| | Fuel filler lid: Closed status (Operation condition for sliding door LH) |
| | Shift position: P position* |
| | Sliding door: Not fully opened |
| | Sliding door: Unlocked while fully closed |
| | Child lock: Unlocked status while sliding door is fully closed |
| Sliding door handle | Automatic door main switch: ON |
| | Vehicle speed: 0 km/h |
| | Battery voltage: 11 V or more |
| | Fuel filler lid: Closed status (Operation condition for sliding door LH) |
| | Shift position: P position* |
| | Sliding door: Not fully opened |
| | Sliding door: Unlocked while fully closed |
| | Child lock: Unlocked (Sliding door inside handle only) |
| Sliding door one-touch open/close switch | Automatic door main switch: ON |
| | Vehicle speed: 0 km/h |
| | Battery voltage: 11 V or more |
| | Fuel filler lid: Closed status (Operation condition for sliding door LH) |
| | Shift position: P position* |
| | Sliding door: Unlocked while fully closed |

*: Only when ignition switch is in the ON position.

AUTO OPEN/CLOSE FUNCTION (CLOSE OPERATION)

- Sliding door control unit sounds automatic sliding door warning buzzer as a reminder, when operation of sliding door handle, sliding door open/close switch, sliding door one-touch open/close switch, or Intelligent Key button is detected while sliding door is in the fully open status.

NOTE:

- The function may not be operated unless sliding door handle is pulled continuously.
- Sliding door control unit operates clutch and sliding door lock release actuator and it performs latch release operation, so that sliding door control unit can judge whether sliding door latch is in released status.
- Sliding door control unit operates automatic sliding door motor and moves sliding door to half latch status, when sliding door control unit judges sliding door handle switch ON status and latch release status according to operation of sliding door release actuator.
- Sliding door control unit detects half latch status according to half latch switch. Sliding door control unit operates sliding door auto closure function and closes sliding door to the fully closed position.
- When sliding door handle, each switch, or Intelligent Key button is operated again during auto close operation, sliding door control unit stops auto close operation and operates sliding door in reverse direction to the fully open position.

OPERATION CONDITION

The auto close operation is performed, when the following conditions are satisfied.

- Automatic door main switch: ON^{*1}
- Battery voltage: 11 V or more
- Fuel filler lid: Closed status^{*2}
- Sliding door: Fully open

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

*1: Except operation of sliding door open/close switch (front side) and Intelligent Key button.

*2: When sliding door LH is operated.

CONTROL WHEN OPERATION CONDITION IS NOT SATISFIED

Sliding door is controlled as described in the following table, when operation condition becomes invalid during automatic operation.

| Condition | Operation |
|--|--|
| Automatic door main switch: Turned to the OFF position | One-way operation is continued |
| Shift position: P position → Other than P position | One-way operation is continued |
| Vehicle speed: 0 km/h more during auto open operation | <ul style="list-style-type: none"> Automatic sliding door warning buzzer sounds continuously and hold function is activated When the vehicle stops, automatic sliding door warning buzzer operation stops, intermittent clutch function operates, and sliding door enters into manual mode |
| Low battery voltage: 11 – 9 V | One-way operation is continued |
| Low battery voltage: 9 – 5 V for 2.1 seconds or more (Traction force lower limit – clutch force assurance) | Automatic sliding door motor stops, and then intermittent clutch function operate |
| Low battery voltage: 5 – 4 V (Control unit reset voltage – clutch hold voltage) | <ul style="list-style-type: none"> Automatic sliding door motor stops (Clutch ON) → sliding door stops continuously and stays restricted (Clutch ON in circuit) Control is impossible because control unit is reset |
| Low battery voltage: 4 – 0 V | <ul style="list-style-type: none"> Sliding door stops continuously and stays restricted (Clutch ON in circuit) Sliding door position cannot be held when the vehicle is on a slope, because clutch force is not sufficient |
| Fuel filler lid: Open | Intermittent clutch function operates. Sliding door enters into manual mode (Sliding door returns to electric mode when fuel filler lid is closed) |

AUTO OPEN/CLOSE FUNCTION : Fail-safe

INFOID:000000009648993

FAIL-SAFE CONTROL BT DTC

Sliding door control unit performs fail-safe control when any DTC is detected.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

| Display contents of CONSULT | Fail-safe | Reference page ^{*1} |
|-----------------------------|-------------------------------|---|
| U1010: CAN COMM CIRCUIT | Intermittent clutch operation | Return to normal status ^{*2} |
| B2401: IGN OPEN | | When the following conditions are fulfilled <ul style="list-style-type: none"> Sliding door control unit detects that ignition switch is in the OFF position Sliding door control unit detects that ignition switch is not in the ON position via CAN communication |
| B2402: TOUCH SENSOR OPEN | | Return to normal status |
| B2403: PULSE ENCODER | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2405: ECU FAIL | | Erase DTC ^{*2} |
| B2409: HALF LATCH SW | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2412: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2413: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2414: ASD MTR TIME OUT | | Sliding door control unit detects that sliding door is in the fully closed position |
| B241A: ENCDR PWR SUPPLY | | When the following conditions are fulfilled <ul style="list-style-type: none"> Return to normal status Sliding door control unit detects that sliding door is in the fully closed position |

*1: When battery is reconnected, cancellation conditions are unconditionally fulfilled.

*2: After returning to normal status, auto open/close function does not operate unless sliding door auto closure function is operated.

ONE-TOUCH UNLOCK FUNCTION


SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

ONE-TOUCH UNLOCK FUNCTION : System Description

INFOID:000000009648994

SYSTEM DIAGRAM



One-touch unlock function enables sliding door unlock operation and auto open operation simultaneously when sliding door one-touch open/close switch is operated while carrying Intelligent Key, even when sliding door is in fully closed and locked status.

OPERATION DESCRIPTION

- Sliding door control unit checks sliding door lock status according to sliding door lock status switch, when sliding door one-touch open/ close switch operation is detected.
- Sliding door control unit transmits sliding door unlock request signal to BCM via CAN communication, when sliding door is locked.
- When sliding door unlock request signal is received, BCM activates outside key antenna, transmits request signal to Intelligent Key, and then checks that Intelligent Key is located near the door.
- Intelligent Key, when it is within outside key antenna detection area (within activation range), transmits key ID signal to BCM via remote keyless entry receiver.
- BCM receives key ID signal and verifies the received key ID with the registered key ID to the vehicle.
- When selective unlock function is in ON status and key ID verification is successful, BCM operates sliding door lock actuator and unlocks sliding door.
- When selective unlock function is in OFF status and key ID verification is successful, BCM operates each door lock actuator and unlocks all doors.
- Sliding door control unit starts auto open operation when sliding door unlocked status is detected according to sliding door lock status switch.

OPERATION CONDITION

If the following conditions are satisfied, the one-touch unlock function is performed.

- Automatic door main switch: ON
- Vehicle speed: 0 km/h
- Battery voltage: 11V or more
- Fuel filler lid: Closed status^{*1}
- Sliding door: Fully closed status
- Sliding door lock status switch: OFF (Sliding door locked status)
- Shift position: P position^{*2}

^{*1}:When sliding door LH is operated

^{*2}:Only when ignition switch is in the ON position

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

ONE-TOUCH UNLOCK FUNCTION : Fail-safe

INFOID:00000009648995

FAIL-SAFE CONTROL BT DTC

Sliding door control unit performs fail-safe control when any DTC is detected.

| Display contents of CONSULT | Fail-safe | Reference page ^{*1} |
|-----------------------------|-------------------------------|---|
| U1010: CAN COMM CIRCUIT | Intermittent clutch operation | Return to normal status ^{*2} |
| B2401: IGN OPEN | | When the following conditions are fulfilled <ul style="list-style-type: none"> Sliding door control unit detects that ignition switch is in the OFF position Sliding door control unit detects that ignition switch is not in the ON position via CAN communication |
| B2402: TOUCH SENSOR OPEN | | Return to normal status |
| B2403: PULSE ENCODER | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2405: ECU FAIL | | Erase DTC ^{*2} |
| B2409: HALF LATCH SW | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2412: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2413: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2414: ASD MTR TIME OUT | | Sliding door control unit detects that sliding door is in the fully closed position |
| B241A: ENCDR PWR SUPPLY | | When the following conditions are fulfilled <ul style="list-style-type: none"> Return to normal status Sliding door control unit detects that sliding door is in the fully closed position |

*1: When battery is reconnected, cancellation conditions are unconditionally fulfilled.

*2: After returning to normal status, auto open/close function does not operate unless sliding door auto closure function is operated.

UNLOCK-LINKED OPENING FUNCTION


SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

UNLOCK-LINKED OPENING FUNCTION : System Description

INFOID:000000009648996

SYSTEM DIAGRAM



Unlock-linked opening function enables sliding door unlock operation and auto open operation simultaneously when sliding door open/close switch (front side) or Intelligent Key button is operated, even when sliding door is in fully closed and locked status.

OPERATION DESCRIPTION

Sliding Door Open/close Switch (Front Side) Operation

- Sliding door control unit checks sliding door lock status according to sliding door lock status switch, when sliding door open/close switch (front side) operation is detected.
- Sliding door control unit transmits sliding door unlock request signal to BCM via CAN communication, when sliding door is unlocked.
- BCM operates sliding door lock actuator and unlocks sliding door, when sliding door unlock request signal is received.
- Sliding door control unit starts auto open operation when sliding door lock status is detected according to sliding door lock status switch.

Intelligent Key Operation

- BCM transmits automatic sliding door operate request signal to sliding door control unit via CAN communication, when operation of Intelligent Key button id detected.
- Sliding door control unit checks sliding door lock status according to sliding door lock status switch, when automatic sliding door operate request signal is detected.
- Sliding door control unit transmits sliding door unlock request signal to BCM via CAN communication, when sliding door is locked.
- When selective unlock function is in ON status and sliding door unlock request signal is received, BCM operates sliding door lock actuator and unlocks sliding door.
- When selective unlock function is in OFF status and sliding door unlock request signal is received, BCM operates each door lock actuator and unlocks all doors.
- Sliding door control unit starts auto open operation when sliding door unlocked status is detected according to sliding door lock status switch.

OPERATION CONDITION

If the following conditions are satisfied, the unlock-linked opening function is performed.

- Vehicle speed: 0 km/h

A
B
C
D
E
F
G
H
I
J

DLK

L

M

N

O

P

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

- Battery voltage: 11 V or more
- Fuel filler lid: Closed status^{*1}
- Sliding door: Fully closed status
- Sliding door lock status switch: OFF (Sliding door locked status)
- Shift position: P position^{*2}

^{*1}: When sliding door LH is operated

^{*2}: Only when ignition switch is in the ON position

UNLOCK-LINKED OPENING FUNCTION : Fail-safe

INFOID:000000009648997

FAIL-SAFE CONTROL BT DTC

Sliding door control unit performs fail-safe control when any DTC is detected.

| Display contents of CONSULT | Fail-safe | Reference page ^{*1} |
|-----------------------------|-------------------------------|---|
| U1010: CAN COMM CIRCUIT | Intermittent clutch operation | Return to normal status ^{*2} |
| B2401: IGN OPEN | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Sliding door control unit detects that ignition switch is in the OFF position • Sliding door control unit detects that ignition switch is not in the ON position via CAN communication |
| B2402: TOUCH SENSOR OPEN | | Return to normal status |
| B2403: PULSE ENCODER | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2405: ECU FAIL | | Erase DTC ^{*2} |
| B2409: HALF LATCH SW | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2412: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2413: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2414: ASD MTR TIME OUT | | Sliding door control unit detects that sliding door is in the fully closed position |
| B241A: ENCDR PWR SUPPLY | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Return to normal status • Sliding door control unit detects that sliding door is in the fully closed position |

^{*1}: When battery is reconnected, cancellation conditions are unconditionally fulfilled.

^{*2}: After returning to normal status, auto open/close function does not operate unless sliding door auto closure function is operated.

POWER ASSIST FUNCTION


SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

POWER ASSIST FUNCTION : System Description

INFOID:000000009648998

SYSTEM DIAGRAM



*: For automatic sliding door LH

Power assist function automatically opens or closes sliding door to fully open/closed position, when sliding door is pressed manually without operating each switch or sliding door handle, while sliding door is in half open stop status or fully open stop status.

OPERATION DESCRIPTION

Sliding door control unit sounds automatic sliding door warning buzzer, activates automatic sliding door motor, and automatically opens or closes to the fully open/close position, when encoder pulse signal is detected from encoder.

OPERATION CONDITION

If the following conditions are satisfied, the power assist function is performed.

- Automatic door main switch: ON
- Vehicle speed: 0 km/h (auto close operation only)
- Fuel filler lid: Closed status^{*1}
- Shift position: P position^{*2}
- Sliding door position: Halfway position
- Sliding door status: Stop status

*1: When sliding door LH is operated.

*2: Only when ignition switch is in the ON position.

POWER ASSIST FUNCTION : Fail-safe

INFOID:000000009648999

FAIL-SAFE CONTROL BT DTC

Sliding door control unit performs fail-safe control when any DTC is detected.

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

| Display contents of CONSULT | Fail-safe | Reference page ^{*1} |
|-----------------------------|-------------------------------|---|
| U1010: CAN COMM CIRCUIT | Intermittent clutch operation | Return to normal status ^{*2} |
| B2401: IGN OPEN | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Sliding door control unit detects that ignition switch is in the OFF position • Sliding door control unit detects that ignition switch is not in the ON position via CAN communication |
| B2402: TOUCH SENSOR OPEN | | Return to normal status |
| B2403: PULSE ENCODER | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2405: ECU FAIL | | Erase DTC ^{*2} |
| B2409: HALF LATCH SW | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2412: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2413: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2414: ASD MTR TIME OUT | | Sliding door control unit detects that sliding door is in the fully closed position |
| B241A: ENCDR PWR SUPPLY | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Return to normal status • Sliding door control unit detects that sliding door is in the fully closed position |

*1: When battery is reconnected, cancellation conditions are unconditionally fulfilled.

*2: After returning to normal status, auto open/close function does not operate unless sliding door auto closure function is operated.

SLIDING DOOR AUTO CLOSURE FUNCTION


SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

SLIDING DOOR AUTO CLOSURE FUNCTION : System Description

INFOID:000000009649000

SYSTEM DIAGRAM



Sliding door auto closure function closes automatically sliding door to the fully closed position when sliding door is in half latch status (lock and striker are in engage status). Sliding door auto closure function is operative, even when automatic door main switch is in the OFF position.

OPERATION DESCRIPTION

- When sliding door control unit judges that sliding door handle is in non-operated status and sliding door is in half latch status according to half latch switch signal and full latch switch signal, sliding door control unit judges that sliding door is in retractable position according to sliding door handle switch and neutral switch signal. Sliding door control unit operates sliding door closure motor, and starts retract operation.
- When sliding door control unit judges that sliding door is in fully closed status according to half latch switch signal and full latch switch signal, sliding door control unit stops sliding door closure motor operation once, and then operates sliding door closure motor in reverse direction to the neutral position of sliding door closure motor.
- Sliding door auto closure function does not operate when any of the following conditions is satisfied.
 - Sliding door: When manually closed swiftly
 - Sliding door handle: When operated immediately after detection of half latch status
 - Battery voltage: 9 V or less

SLIDING DOOR AUTO CLOSURE FUNCTION : Fail-safe

INFOID:000000009649001

FAIL-SAFE CONTROL BT DTC

Sliding door control unit performs fail-safe control when any DTC is detected.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

| Display contents of CONSULT | Fail-safe | Reference page ^{*1} |
|-----------------------------|-------------------------------|---|
| U1010: CAN COMM CIRCUIT | Intermittent clutch operation | Return to normal status ^{*2} |
| B2401: IGN OPEN | | When the following conditions are fulfilled <ul style="list-style-type: none"> Sliding door control unit detects that ignition switch is in the OFF position Sliding door control unit detects that ignition switch is not in the ON position via CAN communication |
| B2402: TOUCH SENSOR OPEN | | Return to normal status |
| B2403: PULSE ENCODER | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2405: ECU FAIL | | Erase DTC ^{*2} |
| B2409: HALF LATCH SW | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2412: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2413: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2414: ASD MTR TIME OUT | | Sliding door control unit detects that sliding door is in the fully closed position |
| B241A: ENCDR PWR SUPPLY | | When the following conditions are fulfilled <ul style="list-style-type: none"> Return to normal status Sliding door control unit detects that sliding door is in the fully closed position |

*1: When battery is reconnected, cancellation conditions are unconditionally fulfilled.

*2: After returning to normal status, auto open/close function does not operate unless sliding door auto closure function is operated.

HOLD FUNCTION


SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

HOLD FUNCTION : System Description

INFOID:000000009649002

SYSTEM DIAGRAM



- When sliding door control unit detects the vehicle speed during auto open operation or detects that sliding door is open during vehicle driving, sliding door control unit sounds automatic sliding door warning buzzer warning the driver, simultaneously stops automatic sliding door motor operation, operates clutch, and then holds sliding door.
- During hold function operation, when sliding door control unit detects half latch status, sliding door control unit stops hold function and operates sliding door auto closure function.
- During hold function operation, when sliding door control unit detects sliding door handle operation, sliding door control unit stops clutch operation. Sliding door can be closed manually.
- When hold function is stopped according to sliding door handle operation and sliding door is manually moved to open direction, sliding door control unit judges sliding door moving direction according to encoder pulse signal, operates clutch again, and holds sliding door.

HOLD FUNCTION : Fail-safe

INFOID:000000009649003

FAIL-SAFE CONTROL BT DTC

Sliding door control unit performs fail-safe control when any DTC is detected.

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

| Display contents of CONSULT | Fail-safe | Reference page ^{*1} |
|-----------------------------|-------------------------------|---|
| U1010: CAN COMM CIRCUIT | Intermittent clutch operation | Return to normal status ^{*2} |
| B2401: IGN OPEN | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Sliding door control unit detects that ignition switch is in the OFF position • Sliding door control unit detects that ignition switch is not in the ON position via CAN communication |
| B2402: TOUCH SENSOR OPEN | | Return to normal status |
| B2403: PULSE ENCODER | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2405: ECU FAIL | | Erase DTC ^{*2} |
| B2409: HALF LATCH SW | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2412: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2413: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2414: ASD MTR TIME OUT | | Sliding door control unit detects that sliding door is in the fully closed position |
| B241A: ENCDR PWR SUPPLY | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Return to normal status • Sliding door control unit detects that sliding door is in the fully closed position |

*1: When battery is reconnected, cancellation conditions are unconditionally fulfilled.

*2: After returning to normal status, auto open/close function does not operate unless sliding door auto closure function is operated.

ANTI-PINCH FUNCTION


SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

ANTI-PINCH FUNCTION : System Description

INFOID:000000009649004

SYSTEM DIAGRAM



Reverse operation is performed when pinching of foreign materials is detected during automatic sliding door auto open/close operation. Sliding door control unit stops automatic operation and enters into intermittent clutch, when pinching during auto close operation is continuously detected for 3 times or more.

DETECTION ACCORDING TO ENCODER

- During automatic operation when operation speed is reduced or sliding door motor operation load is increased due to pinching of foreign materials, sliding door control unit judges the pinching according to change in encoder pulse signal detected from encoder. Sliding door control unit stops automatic operation, and then automatically operates sliding door in reverse direction. Sliding door control unit stops automatic sliding door motor at the sliding door fully open or fully closed position.
- During auto close operation when the vehicle starts driving, auto close operation does not stop and continues to operate, although operation speed may be reduced or sliding door motor operation load may be increased due to pinching of foreign materials.

DETECTION ACCORDING TO SLIDING DOOR TOUCH SENSOR

- When the vehicle is in stop status and sliding door front end pinches foreign materials during auto close operation, sliding door control unit judges the pinching according to sliding door touch sensor signal, operates sliding door in reverse direction, and operates auto open operation to the fully open position.
- When sliding door is in lock status and sliding door front end pinches foreign materials during sliding door auto closure operation, sliding door control unit judges the pinching according to sliding door touch sensor signal, and stops sliding door auto closure operation.
- When sliding door is in unlock status and sliding door front end pinches foreign materials during sliding door auto closure operation, sliding door control unit judges the pinching according to sliding door touch sensor signal, stops sliding door auto closure operation, and operates sliding door auto open operation to the fully open position.

CAUTION:

Be careful that sliding door may not operate in reverse direction because load may not be detected when thin or soft foreign materials are pinched.

ANTI-PINCH FUNCTION : Fail-safe

INFOID:000000009649005

FAIL-SAFE CONTROL BT DTC

Sliding door control unit performs fail-safe control when any DTC is detected.

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

| Display contents of CONSULT | Fail-safe | Reference page ^{*1} |
|-----------------------------|-------------------------------|---|
| U1010: CAN COMM CIRCUIT | Intermittent clutch operation | Return to normal status ^{*2} |
| B2401: IGN OPEN | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Sliding door control unit detects that ignition switch is in the OFF position • Sliding door control unit detects that ignition switch is not in the ON position via CAN communication |
| B2402: TOUCH SENSOR OPEN | | Return to normal status |
| B2403: PULSE ENCODER | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2405: ECU FAIL | | Erase DTC ^{*2} |
| B2409: HALF LATCH SW | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2412: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2413: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2414: ASD MTR TIME OUT | | Sliding door control unit detects that sliding door is in the fully closed position |
| B241A: ENCDR PWR SUPPLY | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Return to normal status • Sliding door control unit detects that sliding door is in the fully closed position |

*1: When battery is reconnected, cancellation conditions are unconditionally fulfilled.

*2: After returning to normal status, auto open/close function does not operate unless sliding door auto closure function is operated.

INTERMITTENT CLUTCH FUNCTION


SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

INTERMITTENT CLUTCH FUNCTION : System Description

INFOID:000000009649006

SYSTEM DIAGRAM



*: For automatic sliding door LH

- During automatic operation of sliding door, when the vehicle is on a slope, it may become impossible to continue automatic operation of sliding door and its operation may stop suddenly, or door may open or close suddenly. This is due to automatic door main switch being turned the OFF position or any other cause. For prevention purposes, sliding door control unit stops automatic sliding door motor, and simultaneously operates clutch intermittently and prevents sliding door from opening or closing suddenly, so that safety can be secured.
- Intermittent clutch function operates when any of the following conditions is satisfied.

| Operation | Operation condition |
|---------------------------------------|--|
| auto open/close function in operation | Fuel filler lid status: Closed → Open |
| | Automatic sliding door system malfunction |
| | Battery voltage: Continuous detection of 9 V or less for 2 seconds or more |
| Hold function in operation | Vehicle speed: 0 km/h |
| | Fuel filler lid status: Closed → Open |
| Anti-pinch function | Automatic sliding door system malfunction |
| | Continuous detection of pinching for 3 times during auto close operation |

INTERMITTENT CLUTCH FUNCTION : Fail-safe

INFOID:000000009649007

FAIL-SAFE CONTROL BT DTC

Sliding door control unit performs fail-safe control when any DTC is detected.

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

| Display contents of CONSULT | Fail-safe | Reference page ^{*1} |
|-----------------------------|-------------------------------|---|
| U1010: CAN COMM CIRCUIT | Intermittent clutch operation | Return to normal status ^{*2} |
| B2401: IGN OPEN | | When the following conditions are fulfilled <ul style="list-style-type: none"> Sliding door control unit detects that ignition switch is in the OFF position Sliding door control unit detects that ignition switch is not in the ON position via CAN communication |
| B2402: TOUCH SENSOR OPEN | | Return to normal status |
| B2403: PULSE ENCODER | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2405: ECU FAIL | | Erase DTC ^{*2} |
| B2409: HALF LATCH SW | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2412: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2413: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2414: ASD MTR TIME OUT | | Sliding door control unit detects that sliding door is in the fully closed position |
| B241A: ENCDR PWR SUPPLY | | When the following conditions are fulfilled <ul style="list-style-type: none"> Return to normal status Sliding door control unit detects that sliding door is in the fully closed position |

*1: When battery is reconnected, cancellation conditions are unconditionally fulfilled.

*2: After returning to normal status, auto open/close function does not operate unless sliding door auto closure function is operated.

BUZZER REMINDER FUNCTION

BUZZER REMINDER FUNCTION : System Description

INFOID:000000009649008

- Automatic sliding door warning buzzer sounds when sliding door automatic function is operated as a reminder.

| Operation | Automatic sliding door warning buzzer |
|-------------------------------|--|
| Auto open | 2 times for start operation |
| Auto close | From sliding door halfway position until operation start of sliding door auto closure function |
| Power assist function (open) | 2 times for start operation |
| Power assist function (close) | |
| Reverse | 2 times for reverse operation |

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

| Operation | Function | Automatic sliding door warning buzzer operation pattern |
|----------------------------|--|---|
| Automatic operation start | Sliding door open/close switch | Sound twice (2 times) |
| | Intelligent Key button operation | |
| | Power assist function | |
| Reverse operation start | Reverse operation detection | |
| Hold function in operation | Vehicle speed 0km/h or more, and sliding door open | Sound continuously (until sliding door is fully closed or the vehicle stops) |
| Auto close in operation | Auto close in operation | Continuously sounds intermittently (until sliding door is in half latch position) |

- When all of the following conditions are satisfied, automatic sliding door warning buzzer sounds, alerting the driver to stop the vehicle.
 - Sliding door: Open status (Sliding door switch ON or full latch switch ON)
 - Vehicle speed: 0 km/h or more

BUZZER REMINDER FUNCTION : Fail-safe

INFOID:000000009649009

FAIL-SAFE CONTROL BT DTC

Sliding door control unit performs fail-safe control when any DTC is detected.

| Display contents of CONSULT | Fail-safe | Reference page ^{*1} |
|-----------------------------|-------------------------------|---|
| U1010: CAN COMM CIRCUIT | Intermittent clutch operation | Return to normal status ^{*2} |
| B2401: IGN OPEN | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Sliding door control unit detects that ignition switch is in the OFF position • Sliding door control unit detects that ignition switch is not in the ON position via CAN communication |
| B2402: TOUCH SENSOR OPEN | | Return to normal status |
| B2403: PULSE ENCODER | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2405: ECU FAIL | | Erase DTC ^{*2} |
| B2409: HALF LATCH SW | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2412: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2413: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2414: ASD MTR TIME OUT | | Sliding door control unit detects that sliding door is in the fully closed position |
| B241A: ENCDR PWR SUPPLY | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Return to normal status • Sliding door control unit detects that sliding door is in the fully closed position |

^{*1}: When battery is reconnected, cancellation conditions are unconditionally fulfilled.

SYSTEM (AUTOMATIC SLIDING DOOR SYSTEM)

< SYSTEM DESCRIPTION >

*2: After returning to normal status, auto open/close function does not operate unless sliding door auto closure function is operated.

SYSTEM (INTEGRATED HOMELINK TRANSMITTER)

< SYSTEM DESCRIPTION >

SYSTEM (INTEGRATED HOMELINK TRANSMITTER)

System Description

INFOID:000000009649010

| Item | Function |
|---------------------------------|---|
| Integrated homelink transmitter | A maximum of 3 radio signals can be stored and transmitted to operate the garage door, etc. |

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009986191

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

| Diagnosis mode | Function Description |
|--------------------------|---|
| Work Support | Changes the setting for each system function. |
| Self Diagnostic Result | Displays the diagnosis results judged by BCM. |
| CAN Diag Support Monitor | Monitors the reception status of CAN communication viewed from BCM. |
| Data Monitor | The BCM input/output signals are displayed. |
| Active Test | The signals used to activate each device are forcibly supplied from BCM. |
| Ecu Identification | The BCM part number is displayed. |
| Configuration | <ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM. |

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

| System | Sub system selection item | Diagnosis mode | | |
|---|---------------------------|----------------|--------------|-------------|
| | | Work Support | Data Monitor | Active Test |
| Door lock | DOOR LOCK | × | × | × |
| Rear window defogger | REAR DEFOGGER | | × | × |
| Warning chime | BUZZER | | × | × |
| Interior room lamp control system | INT LAMP | × | × | × |
| Exterior lamp | HEAD LAMP | × | × | × |
| Wiper and washer | WIPER | × | × | × |
| Turn signal and hazard warning lamps | FLASHER | × | × | × |
| Air conditioning control system | AIR CONDITONER | | × | ×* |
| <ul style="list-style-type: none"> Intelligent Key system Engine start system | INTELLIGENT KEY | × | × | × |
| Combination switch | COMB SW | | × | |
| Body control system | BCM | × | | |
| NVIS | IMMU | × | × | × |
| Interior room lamp battery saver | BATTERY SAVER | × | × | × |
| Back door open | TRUNK | | × | |
| Vehicle security system | THEFT ALM | × | × | × |
| RAP system | RETAINED PWR | | × | |
| Signal buffer system | SIGNAL BUFFER | | × | × |
| TPMS | AIR PRESSURE MONITOR | × | × | × |

NOTE:

*: For models with automatic air conditioning control system, this diagnosis mode is not used.

FREEZE FRAME DATA (FFD)

The BCM records the following vehicle condition at the time a particular DTC is detected, and displays on CONSULT.

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| CONSULT screen item | Indication/Unit | Description | | |
|---------------------|--------------------------------|--|---|---|
| Vehicle Speed | km/h | Vehicle speed of the moment a particular DTC is detected | | A |
| Odo/Trip Meter | km | Total mileage (Odometer value) of the moment a particular DTC is detected | | |
| Vehicle Condition | SLEEP>LOCK | Power position status of the moment a particular DTC is detected* | While turning BCM status from low power consumption mode to normal mode [Power supply position is OFF (LOCK)] | B |
| | SLEEP>OFF | | While turning BCM status from low power consumption mode to normal mode [Power supply position is OFF (OFF)] | C |
| | LOCK>ACC | | While turning power supply position from OFF (LOCK) to ACC | |
| | ACC>ON | | While turning power supply position from ACC to ON | D |
| | RUN>ACC | | While turning power supply position from RUN to ACC (Except emergency stop operation) | |
| | CRANK>RUN | | While turning power supply position from CRANK to RUN | E |
| | RUN>URGENT | | While turning power supply position from RUN to ACC (Emergency stop operation) | |
| | ACC>OFF | | While turning power supply position from ACC to OFF (OFF) | F |
| | OFF>LOCK | | While turning power supply position from OFF (OFF) to OFF (LOCK) | |
| | OFF>ACC | | While turning power supply position from OFF (OFF) to ACC | G |
| | ON>CRANK | | While turning power supply position from ON to CRANK | |
| | OFF>SLEEP | | While turning BCM status from normal mode [Power supply position is OFF (OFF)] to low power consumption mode | H |
| | LOCK>SLEEP | | While turning BCM status from normal mode [Power supply position is OFF (LOCK)] to low power consumption mode | |
| | LOCK | | Power supply position is OFF (LOCK) | I |
| | OFF | | Power supply position is OFF (OFF) | |
| | ACC | | Power supply position is ACC | J |
| | ON | | Power supply position is ON | |
| ENGINE RUN | Power supply position is RUN | | | |
| CRANKING | Power supply position is CRANK | DLK | | |
| IGN Counter | 0 - 39 | The number of times that ignition switch is turned ON after DTC is detected <ul style="list-style-type: none"> • The number is 0 when a malfunction is detected now. • The number increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. • The number is fixed to 39 until the self-diagnosis results are erased if it is over 39. | | L |

NOTE:

*: Refer to the following for details of the power supply position.

- OFF (OFF, LOCK): Ignition switch OFF
- ACC: Ignition switch ACC
- IGN: Ignition switch ON with engine stopped
- RUN: Ignition switch ON with engine running
- CRANK: At engine cranking

Power supply position shifts to "OFF (LOCK)" from "OFF (OFF)", when ignition switch is in the OFF position, shift position is in the P position, and any of the following conditions are met.

- Closing door
- Opening door
- Door is locked using door request switch
- Door is locked using Intelligent Key

The power supply position shifts to "ACC" when the push-button ignition switch (push switch) is pushed at "OFF (LOCK)".

DOOR LOCK

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK)

INFOID:000000009649012

BCM CONSULT FUNCTION

CONSULT performs the following functions via CAN communication with BCM.

WORK SUPPORT

| Monitor item | Description |
|------------------------------|--|
| DOOR LOCK-UNLOCK SET | Selective unlock function mode can be changed to operation with this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| AUTOMATIC DOOR LOCK SELECT | Automatic door lock function mode can be selected from the following in this mode <ul style="list-style-type: none"> • VH SPD: All doors are locked when vehicle speed more than 24 km/h (15 MPH) • P RANGE: All doors are locked when shifting the selector lever from P position to other than the P position |
| AUTOMATIC DOOR UNLOCK SELECT | Automatic door unlock function mode can be selected from the following in this mode <ul style="list-style-type: none"> • MODE 1: All doors are unlocked when the power supply position is changed from ON to OFF • MODE 2: All doors are unlocked when shifting the selector lever from any position other than the P to P position • MODE 3: Driver side door is unlocked when the power supply position is changed from ON to OFF • MODE 4: Driver side door is unlocked when shifting the selector lever from any position other than the P to P position • MODE 5: This item is displayed, but cannot be used • MODE 6: This item is displayed, but cannot be used |
| AUTOMATIC LOCK/UNLOCK SET | Automatic door lock/unlock function mode can be selected from the following in this mode <ul style="list-style-type: none"> • Off: Non-operation • Unlock Only: Door unlock operation only • Lock Only: Door lock operation only • Lock/Unlock: Lock and unlock operation |

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor Item | Contents |
|---------------|---|
| REQ SW-DR | Indicated [On/Off] condition of door request switch (driver side) |
| REQ SW-AS | Indicated [On/Off] condition of door request switch (passenger side) |
| REQ SW-BD/TR | Indicated [On/Off] condition of back door request switch |
| DOOR SW-DR | Indicated [On/Off] condition of front door switch (driver side) |
| DOOR SW-AS | Indicated [On/Off] condition of front door switch (passenger side) |
| DOOR SW-RR | Indicated [On/Off] condition of sliding door switch RH |
| DOOR SW-RL | Indicated [On/Off] condition of sliding door switch LH |
| DOOR SW-BK | Indicated [On/Off] condition of back door switch |
| CDL LOCK SW | Indicated [On/Off] condition of lock signal from door lock unlock switch |
| CDL UNLOCK SW | Indicated [On/Off] condition of unlock signal from door lock unlock switch |
| KEY CYL LK-SW | Indicated [On/Off] condition of lock signal from door key cylinder switch |
| KEY CYL UN-SW | Indicated [On/Off] condition of unlock signal from door key cylinder switch |

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| Test item | Description |
|-----------|--|
| DOOR LOCK | <p>This test is able to check door lock/unlock operation</p> <ul style="list-style-type: none"> • The all door lock actuators are locked when "ALL LOCK" on CONSULT screen is touched • The all door lock actuators are unlocked when "ALL UNLK" on CONSULT screen is touched • The front door lock actuator (driver side) is unlocked when "DR UNLK" on CONSULT screen is touched • The front door lock actuator (passenger side) is unlocked when "AS UNLK" on CONSULT screen is touched • The door lock actuator (other) is unlocked when "OTR ULK" on CONSULT screen is touched |

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000009649013

WORK SUPPORT

| Monitor item | Description |
|--------------------------|---|
| INSIDE ANT DIAGNOSIS | This function allows inside key antenna self-diagnosis |
| LOCK/UNLOCK BY I-KEY | <p>Door lock/unlock function by door request switch mode can be changed to operation in this mode</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| ENGINE START BY I-KEY | <p>Engine start function mode can be changed to operation with this mode</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| TRUNK/GLASS HATCH OPEN | <p>NOTE: This item is displayed, but cannot be used</p> |
| PANIC ALARM SET | <p>Panic alarm button pressing time on Intelligent Key button can be selected from the following with this mode</p> <ul style="list-style-type: none"> • MODE 1: 0.5 sec • MODE 2: Non-operation • MODE 3: 1.5 sec |
| TRUNK OPEN DELAY | <p>NOTE: This item is displayed, but cannot be used</p> |
| LO- BATT OF KEY FOB WARN | <p>Intelligent Key low battery warning mode can be changed to operation with this mode</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| ANTI KEY LOCK IN FUNCTI | <p>Key reminder function mode can be changed to operation with this mode</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| HAZARD ANSWER BACK | <p>Hazard reminder function mode by door request switch and Intelligent Key button can be selected from the following with this mode</p> <ul style="list-style-type: none"> • Lock Only: Door lock operation only • Unlock Only: Door unlock operation only • Lock/Unlock: Lock and unlock operation • Off: Non-operation |
| ANS BACK I-KEY LOCK | <p>Buzzer reminder function (lock operation) mode by door request switch can be selected from the following with this mode</p> <ul style="list-style-type: none"> • Horn Chirp: Sound horn • Buzzer: Sound Intelligent Key warning buzzer • Off: Non-operation |
| ANS BACK I-KEY UNLOCK | <p>Buzzer reminder function (unlock operation) mode by door request switch can be changed to operation with this mode</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| SHORT CRANKING OUTPUT | <p>Starter motor can operate during the times below</p> <ul style="list-style-type: none"> • 70 msec • 100 msec • 200 msec |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| Monitor item | Description |
|------------------------|---|
| CONFIRM KEY FOB ID | It can be checked whether Intelligent Key ID code is registered or not in this mode |
| AUTO LOCK SET | Auto door lock operation time can be changed in this mode <ul style="list-style-type: none"> • MODE 1: OFF • MODE 2: 30 sec • MODE 3: 1 minute • MODE 4: 2 minutes • MODE 5: 3 minutes • MODE 6: 4 minutes • MODE 7: 5 minutes |
| HORN WITH KEYLESS LOCK | Horn reminder function mode by Intelligent Key button can be selected from the following with this mode <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| PW DOWN SET | Unlock button pressing time on Intelligent Key button can be selected from the following with this mode <ul style="list-style-type: none"> • MODE 1: 3 sec • MODE 2: Non-operation • MODE 3: 5 sec |

SELF-DIAG RESULT

Refer to [BCS-63. "DTC Index"](#).

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor Item | Condition |
|----------------|--|
| REQ SW -DR | Indicates [On/Off] condition of door request switch (driver side) |
| REQ SW -AS | Indicates [On/Off] condition of door request switch (passenger side) |
| REQ SW -BD/TR | Indicates [On/Off] condition of back door request switch |
| PUSH SW | Indicates [On/Off] condition of push-button ignition switch |
| CLUTCH SW | NOTE: This item is displayed, but cannot be monitored |
| BRAKE SW 1 | Indicates [On/Off]* condition of stop lamp switch power supply |
| BRAKE SW 2 | Indicates [On/Off] condition of stop lamp switch |
| DETE/CANCL SW | Indicates [On/Off] condition of P position |
| SFT PN/N SW | Indicates [On/Off] condition of P or N position |
| S/L -LOCK | NOTE: This item is displayed, but cannot be monitored |
| S/L -UNLOCK | NOTE: This item is displayed, but cannot be monitored |
| S/L RELAY -F/B | NOTE: This item is displayed, but cannot be monitored |
| UNLK SEN -DR | Indicates [On/Off] condition of driver door UNLOCK status |
| PUSH SW -IPDM | Indicates [On/Off] condition of push-button ignition switch |
| IGN RLY1 -F/B | Indicates [On/Off] condition of ignition relay 1 |
| DETE SW -IPDM | Indicates [On/Off] condition of P position |
| SFT PN -IPDM | Indicates [On/Off] condition of P or N position |
| SFT P -MET | Indicates [On/Off] condition of P position |
| SFT N -MET | Indicates [On/Off] condition of N position |
| ENGINE STATE | Indicates [Stop/Stall/Crank/Run] condition of engine states |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| Monitor Item | Condition |
|---------------|---|
| S/L LOCK-IPDM | NOTE: This item is displayed, but cannot be monitored |
| S/L UNLK-IPDM | NOTE: This item is displayed, but cannot be monitored |
| S/L RELAY-REQ | NOTE: This item is displayed, but cannot be monitored |
| VEH SPEED 1 | Display the vehicle speed signal received from combination meter by numerical value [km/h] |
| VEH SPEED 2 | Display the vehicle speed signal received from ABS or VDC or TCM by numerical value [km/h] |
| DOOR STAT-DR | Indicates [LOCK/READY/UNLK] condition of unlock sensor |
| DOOR STAT-AS | Indicates [LOCK/READY/UNLK] condition of passenger side door status |
| ID OK FLAG | Indicates [Set/Reset] condition of key ID |
| PRMT ENG STRT | Indicates [Set/Reset] condition of engine start possibility |
| PRMT RKE STRT | NOTE: This item is displayed, but cannot be monitored |
| TRNK/HAT MNTR | NOTE: This item is displayed, but cannot be monitored |
| RKE-LOCK | Indicates [On/Off] condition of LOCK signal from Intelligent Key |
| RKE-UNLOCK | Indicates [On/Off] condition of UNLOCK signal from Intelligent Key |
| RKE-TR/BD | NOTE: This item is displayed, but cannot be monitored |
| RKE-PANIC | Indicates [On/Off] condition of PANIC button of Intelligent Key |
| RKE-MODE CHG | Indicates [On/Off] condition of MODE CHANGE signal from Intelligent Key |
| RKE OPE COUN1 | When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing |
| RKE OPE COUN2 | NOTE: This item is displayed, but cannot be monitored |

*: OFF is displayed when brake pedal is depressed while brake switch power supply is OFF.

ACTIVE TEST

| Test item | Description |
|----------------|---|
| BATTERY SAVER | This test is able to check interior room lamp operation <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| OUTSIDE BUZZER | This test is able to check Intelligent Key warning buzzer operation <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| INSIDE BUZZER | This test is able to check warning chime in combination meter operation <ul style="list-style-type: none"> • Take Out: Take away warning chime sounds when CONSULT screen is touched • Key: Key warning chime sounds when CONSULT screen is touched • Knob: OFF position warning chime sounds when CONSULT screen is touched • Off: Non-operation |
| INDICATOR | This test is able to check warning lamp operation <ul style="list-style-type: none"> • KEY ON: "KEY" Warning lamp illuminates when CONSULT screen is touched • KEY IND: "KEY" Warning lamp blinks when CONSULT screen is touched • Off: Non-operation |
| INT LAMP | This test is able to check interior room lamp operation <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |

A
B
C
D
E
F
G
H
I
J

DLK

L
M
N
O
P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| Test item | Description |
|------------------|---|
| LCD | <p>This test is able to check meter display information</p> <ul style="list-style-type: none"> • Engine start information displays when "BP N" on CONSULT screen is touched • Engine start information displays when "BP I" on CONSULT screen is touched • Key ID warning displays when "ID NG" on CONSULT screen is touched • ROTAT: This item is displayed, but cannot be used. • P position warning displays when "SFT P" on CONSULT screen is touched • INSR: This item is displayed, but cannot be monitored • BATT: This item is displayed, but cannot be monitored • Take away through window warning displays when "NO KY" on CONSULT screen is touched • Take away warning display when "OUTKEY" on CONSULT screen is touched • OFF position warning display when "LK WN" on CONSULT screen is touched |
| FLASHER | <p>This test is able to check hazard warning lamp operation</p> <ul style="list-style-type: none"> • LH: LH side hazard warning lamps operate • RH: RH side hazard warning lamps operate • Off: Non-operation |
| P RANGE | <p>This test is able to check CVT shift selector power supply</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| ENGINE SW ILLUMI | <p>This test is able to check push-button ignition switch illumination operation</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| LOCK INDICATOR | <p>This test is able to check LOCK indicator (push-button ignition switch) operation</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| ACC INDICATOR | <p>This test is able to check ACC indicator (push-button ignition switch) operation</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| IGNITION ON IND | <p>This test is able to check ON indicator (push-button ignition switch) operation</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| HORN | <p>This test is able to check horn operation</p> <ul style="list-style-type: none"> • On: Operate • Off: Non-operation |
| TRUNK/BACK DOOR | <p>NOTE: This item is displayed, but cannot be used</p> |
| POWER SLIDE DOOR | <p>This test is able to check automatic sliding door operation</p> <ul style="list-style-type: none"> • RR PSD ON: Auto open/close operate • RL PSD ON: Auto open/close operate |

TRUNK

TRUNK : CONSULT Function (BCM - TRUNK)

INFOID:000000009649014

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor Item | Contents |
|---------------|---|
| PUSH SW | Indicates [On/Off] condition of push switch |
| UNLK SEN -DR | Indicates [On/Off] condition of unlock sensor |
| VEH SPEED 1 | Indicates [km/h] condition of vehicle speed signal from combination meter |
| TR/BD OPEN SW | Indicates [On/Off] condition of back door opener switch |

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

| Monitor Item | Contents | |
|---------------|---|---|
| TRNK/HAT MNTR | NOTE: This item is displayed, but cannot be monitored | A |
| RKE-TR/BD | NOTE: This item is displayed, but cannot be monitored | B |

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

DIAGNOSIS SYSTEM (AUTOMATIC BACK DOOR CONTROL UNIT)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (AUTOMATIC BACK DOOR CONTROL UNIT)

CONSULT Function (AUTOMATIC BACK DOOR CONTROL UNIT)

INFOID:000000009649015

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with automatic back door control unit.

| Diagnosis mode | Function Description |
|--------------------------|---|
| Self Diagnostic Result | Displays the diagnosis results judged by automatic back door control unit |
| CAN Diag Support Monitor | Monitors the reception status of CAN communication viewed from automatic back door control unit |
| Data Monitor | The automatic back door control unit input/output signals are displayed |
| Ecu Identification | The automatic back door control unit part number is displayed |

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor Item | Unit | Description |
|----------------|----------------|--|
| VHCL SPEED MTR | [km/h] | Display the vehicle speed signal received from combination meter by numerical value |
| VHCL SPEED ABS | [km/h] | Display the vehicle speed signal received from ABS actuator and electrical unit by numerical value |
| VHCL SPEED SIG | [NORMAL/ERROR] | Indicates condition of vehicle speed from automatic back door control unit |
| MAIN SW | [ON/OFF] | Indicates condition of automatic door main switch |
| AUTO BD SW | [ON/OFF] | Indicates condition of automatic back door switch |
| BK DOOR CL SW | [ON/OFF] | Indicates condition of automatic back door close switch |
| UNLOCK SEN DR | [ON/OFF] | NOTE: This item is displayed, but cannot be monitored |
| OPEN SW | [ON/OFF] | Indicates condition of open switch |
| CLOSE SW | [ON/OFF] | Indicates condition of close switch |
| HALF LATCH SW | [ON/OFF] | Indicates condition of half latch switch |
| TOUCH SEN RH | [ON/OFF/OPEN] | Indicates condition of touch sensor RH |
| TOUCH SEN LH | [ON/OFF/OPEN] | Indicates condition of touch sensor LH |
| P RANGE IND | [ON/OFF] | Indicates condition of P range signal from TCM |
| RKE REQ | [OFF/MOVE/REV] | Indicates condition of remote keyless entry signal from BCM |
| IGN SW | [ON/OFF] | Indicates condition of IGN power supply |
| ENCODER A | [LO/HI] | Indicates condition of encoder signal from encoder A |
| ENCODER B | [LO/HI] | Indicates condition of encoder signal from encoder B |
| BD OPENER SW | [ON/OFF] | Indicates condition of back door opener switch |
| UNLOCK SEN BD | [LOCK/UNLOCK] | NOTE: This item is displayed, but cannot be monitored |
| DESTINATION | [JPN/NAM] | Indicates specification of destination of the automatic back door system |
| HAZARD | [ON/OFF] | Indicates specification of hazard warning |

SELF-DIAG RESULT

Refer to [DLK-109, "DTC Index"](#).

DIAGNOSIS SYSTEM (SLIDING DOOR CONTROL UNIT LH)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (SLIDING DOOR CONTROL UNIT LH)

CONSULT Function

INFOID:000000009649016

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with sliding door control unit LH.

| Diagnosis mode | Function description |
|--------------------------|---|
| Self Diagnostic Result | Displays the diagnosis results judged by sliding door control unit LH |
| CAN Diag Support Monitor | Monitors the reception status of CAN communication viewed from sliding door control unit LH |
| Data Monitor | The sliding door control unit LH input/output signals are displayed |
| Active Test | The signal used to activate each device are forcibly supplied from sliding door control unit LH |
| Ecu Identification | The sliding door control unit LH part number is displayed |

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor item | Description |
|---------------|--|
| SPEED METER | Vehicle speed signal from combination meter is displayed |
| ABS SPEED | Vehicle speed signal from ABS actuator and electric unit (control unit) is displayed |
| MAIN SW | [ON/OFF] status of automatic door main switch, which is judged from automatic door main switch signal, is displayed |
| KNOB LCK SW L | [Lock (OFF)/unlock (ON)] status of sliding door LH, which is judged from sliding door lock/unlock status signal, is displayed |
| ONE-TOUCH SW | [Operation (ON)/non-operation (OFF)] status of sliding door one-touch open/close switch LH, which is judged from sliding door one-touch open/close switch signal, is displayed |
| F LID SW | [ON/OFF] status of fuel filler lid status switch, which is judged from fuel filler lid open/close status signal, is displayed |
| B PILLER SW | [Operation (ON)/non-operation (OFF)] status of sliding door open/close switch (rear LH), which is judged from sliding door open/close switch (rear LH) signal, is displayed |
| DRIVER SW | [Operation (ON)/non-operation (OFF)] status of sliding door open/close switch (front LH), which is judged from sliding door open/close switch (front LH) signal, is displayed |
| ACC On SW | [ON, ACC status (ON)/other than ON, ACC (OFF)] status of ignition switch, which is judged from ACC signal, is displayed |
| DOR HAND SW L | [Operation (ON)/non-operation (OFF)] status of sliding door handle LH, which is judged from sliding door handle switch signal, is displayed |
| TOUCH SEN LH | [Pinching detection (ON)/non-detection (OFF)] status of sliding door touch sensor LH, which is judged from sliding door touch sensor signal, is displayed |
| RR-LH DOOR SW | [Open (ON)/close (OFF)] status of sliding door LH, which is judged from sliding door switch signal, is displayed |
| HAF LATC SW L | [Half latch, fully close (OFF)/open (ON)] status of half latch switch, which is judged from half latch switch signal, is displayed |
| P RANGE SW | [P position (ON)/other than P position (OFF)] status of selector lever, which is judged from shift position signal, is displayed |
| BRAKE SW | [Depressed (ON)/non-depressed (OFF)] status of brake pedal, which is judged from stop lamp switch signal, is displayed |
| P BRAKE SW | [Operation (ON)/non-operation (OFF)] status of parking brake, which is judged from park brake switch signal, is displayed |

DIAGNOSIS SYSTEM (SLIDING DOOR CONTROL UNIT LH)

< SYSTEM DESCRIPTION >

| Monitor item | Description |
|----------------|--|
| KEYLESS SIG | [REV→MOVE→OFF] status of auto open/close operation is displayed according to Intelligent Key button operation <ul style="list-style-type: none">• REV: When Intelligent Key signal is received (button short press)• MOVE: When Intelligent Key signal is received (button long press)• OFF: When Intelligent Key button is not operated |
| IGN SW | [ON position (ON)/other than ON position (OFF)] of ignition switch, which is judged from ignition switch ON signal, is displayed |
| ENCODER A LH | Encoder status, which is judged from encoder pulse signal, is displayed |
| ENCODER B LH | Encoder status, which is judged from encoder pulse signal, is displayed |
| CHILD LOCK SW | [Lock (OFF)/unlock (ON)] status of child lock, which is judged from child lock status signal, is displayed |
| FULL LATC SW L | [Full close (OFF)/other than full close (ON)] status of sliding door LH, which is judged from full latch switch signal, is displayed |
| NEUTRAL SW | [Neutral position (OFF)/other than neutral position (ON)] status of sliding door closure motor, which is judged from neutral switch signal, is displayed |

ACTIVE TEST

| Test Item | Description |
|-----------|---|
| CLUTCH | Clutch operation of sliding door LH can be checked according to screen operation of CONSULT <ul style="list-style-type: none">• HOLD: Clutch ON (sliding door LH cannot be operated manually)• RELEASE: Clutch OFF (sliding door LH can be operated manually) NOTE: Be careful to perform active test after turning automatic door main switch to the OFF position and setting sliding door to the halfway stop position |

SELF-DIAG RESULT

Refer to [DLK-115, "LH : DTC Index"](#).

DIAGNOSIS SYSTEM (SLIDING DOOR CONTROL UNIT RH)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (SLIDING DOOR CONTROL UNIT RH)

CONSULT Function

INFOID:000000009649017

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with sliding door control unit RH.

| Diagnosis mode | Function description |
|--------------------------|---|
| Self Diagnostic Result | Displays the diagnosis results judged by sliding door control unit RH |
| CAN Diag Support Monitor | Monitors the reception status of CAN communication viewed from sliding door control unit RH |
| Data Monitor | The sliding door control unit RH input/output signals are displayed |
| Active Test | The signal used to activate each device are forcibly supplied from sliding door control unit RH |
| Ecu Identification | The sliding door control unit RH part number is displayed |

DATA MONITOR

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor item | Description |
|---------------|--|
| SPEED METER | Vehicle speed signal from combination meter is displayed |
| ABS SPEED | Vehicle speed signal from ABS actuator and electric unit (control unit) is displayed |
| MAIN SW | [ON/OFF] status of automatic door main switch, which is judged from automatic door main switch signal, is displayed |
| KNOB LCK SW R | [Lock (OFF)/unlock (ON)] status of sliding door RH, which is judged from sliding door lock/unlock status signal, is displayed |
| ONE-TOUCH SW | [Operation (ON)/non-operation (OFF)] status of sliding door one-touch open/close switch RH, which is judged from sliding door one-touch open/close switch signal, is displayed |
| F LID SW | [ON/OFF] status of fuel filler lid status switch, which is judged from fuel filler lid open/close status signal, is displayed |
| B PILLER SW | [Operation (ON)/non-operation (OFF)] status of sliding door open/close switch (rear RH), which is judged from sliding door open/close switch (rear RH) signal, is displayed |
| DRIVER SW | [Operation (ON)/non-operation (OFF)] status of sliding door open/close switch (front RH), which is judged from sliding door open/close switch (front RH) signal, is displayed |
| ACC On SW | [ON, ACC status (ON)/other than ON, ACC (OFF)] status of ignition switch, which is judged from ACC signal, is displayed |
| DOR HAND SW R | [Operation (ON)/non-operation (OFF)] status of sliding door handle RH, which is judged from sliding door handle switch signal, is displayed |
| TOUCH SEN RH | [Pinching detection (ON)/non-detection (OFF)] status of sliding door touch sensor RH, which is judged from sliding door touch sensor signal, is displayed |
| RR-RH DOOR SW | [Open (ON)/close (OFF)] status of sliding door RH, which is judged from sliding door switch signal, is displayed |
| HAF LATC SW R | [Half latch, fully close (OFF)/open (ON)] status of half latch switch, which is judged from half latch switch signal, is displayed |
| P RANGE SW | [P position (ON)/other than P position (OFF)] status of selector lever, which is judged from shift position signal, is displayed |
| BRAKE SW | [Depressed (ON)/non-depressed (OFF)] status of brake pedal, which is judged from stop lamp switch signal, is displayed |
| P BRAKE SW | [Operation (ON)/non-operation (OFF)] status of parking brake, which is judged from park brake switch signal, is displayed |

DIAGNOSIS SYSTEM (SLIDING DOOR CONTROL UNIT RH)

< SYSTEM DESCRIPTION >

| Monitor item | Description |
|---------------|--|
| KEYLESS SIG | [REV→MOVE→OFF] status of auto open/close operation is displayed according to Intelligent Key button operation <ul style="list-style-type: none">• REV: When Intelligent Key signal is received (button short press)• MOVE: When Intelligent Key signal is received (button long press)• OFF: When Intelligent Key button is not operated |
| IGN SW | [ON position (ON)/other than ON position (OFF)] of ignition switch, which is judged from ignition switch ON signal, is displayed |
| ENCODER A RH | Encoder status, which is judged from encoder pulse signal, is displayed |
| ENCODER B RH | Encoder status, which is judged from encoder pulse signal, is displayed |
| CHILD LOCK SW | [Lock (OFF)/unlock (ON)] status of child lock, which is judged from child lock status signal, is displayed |
| FUL LATC SW R | [Full close (OFF)/other than full close (ON)] status of sliding door RH, which is judged from full latch switch signal, is displayed |
| NEUTRAL SW | [Neutral position (OFF)/other than neutral position (ON)] status of sliding door closure motor, which is judged from neutral switch signal, is displayed |

ACTIVE TEST

| Test Item | Description |
|-----------|---|
| CLUTCH | Clutch operation of sliding door RH can be checked according to screen operation of CONSULT <ul style="list-style-type: none">• HOLD: Clutch ON (sliding door RH cannot be operated manually)• RELEASE: Clutch OFF (sliding door RH can be operated manually) NOTE: Be careful to perform active test after turning automatic door main switch to the OFF position and setting sliding door to the halfway stop position |

SELF-DIAG RESULT

Refer to [DLK-121, "RH : DTC Index"](#).

BCM

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM

List of ECU Reference

INFOID:000000009649018

| ECU | Reference |
|-----|---|
| BCM | BCS-40, "Reference Value" |
| | BCS-62, "Fail-safe" |
| | BCS-62, "DTC Inspection Priority Chart" |
| | BCS-63, "DTC Index" |

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DLK

AUTOMATIC BACK DOOR CONTROL MODULE

< ECU DIAGNOSIS INFORMATION >

AUTOMATIC BACK DOOR CONTROL MODULE

Reference Value

INFOID:000000009649019

VALUES ON THE DIAGNOSIS TOOL

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

CONSULT MONITOR ITEM


| Monitor Item | Condition | | Value/Status |
|----------------|---|------------------------------|-----------------------------------|
| VHCL SPEED MTR | While driving | | Equivalent to speedometer reading |
| VHCL SPEED ABS | While driving | | Equivalent to speedometer reading |
| VHCL SPEED SIG | Vehicle speed from automatic back door control unit | Normal | NORMAL |
| | | Error | ERROR |
| MAIN SW | Automatic door main switch | OFF | OFF |
| | | ON | ON |
| AUTO BD SW | Automatic back door switch | Release | OFF |
| | | Press | ON |
| BK DOOR CL SW | Automatic back door close switch | Release | OFF |
| | | Press | ON |
| UNLOCK SEN DR | NOTE: This item is displayed, but cannot be monitored | | OFF |
| | | | ON |
| OPEN SW | Back door | Half latch/fully closed | OFF |
| | | Open | ON |
| CLOSE SW | Back door | Open/half latch | OFF |
| | | Fully closed | ON |
| HALF LATCH SW | Back door | Half latch/fully closed | OFF |
| | | Open | ON |
| TOUCH SEN RH | Back door touch sensor RH | Other than bellow | OFF |
| | | Detect obstruction | ON |
| TOUCH SEN LH | Back door touch sensor LH | Other than bellow | OFF |
| | | Detect obstruction | ON |
| P RANGE IND | Selector lever | Other than P position | OFF |
| | | P position | ON |
| RKE REQ | Intelligent Key button (back door) | Release | OFF |
| | | Press (more than 0.5 second) | MOVE |
| | | Press (just after) | REV |
| IGN SW | Ignition switch | Other than ON position | OFF |
| | | ON position | ON |
| ENCODER A | Automatic back door | Not operate | No change HI or LO |
| | | Operate | Change HI or LO |
| ENCODER B | Automatic back door | Not operate | No change HI or LO |
| | | Operate | Change HI or LO |
| BD OPENER SW | Back door opener switch | Release | UNLK |
| | | Press | LOCK |

AUTOMATIC BACK DOOR CONTROL MODULE

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|---------------|--|-------------------------|
| UNLOCK SEN BD | NOTE: This item is displayed, but cannot be monitored | OFF |
| | | ON |
| DESTINATION | Circuit between automatic back door control module terminal 6 and ground | Normal Open or short |
| | | NAM JPN |
| HAZARD | Circuit between automatic back door control module terminal 8 and ground | Normal Open or short |
| | | ON OFF |

TERMINAL LAYOUT



PHYSICAL VALUES

| Terminal No. (Wire color) | | Description | | Condition | | Voltage |
|------------------------------|--------|------------------------------------|------------------|------------------------------------|--------------------|-----------|
| (+) | (-) | Signal name | Input/ Output | | | |
| 1 (SB) | Ground | Power supply (BAT) | Input | — | | 9 - 16 V |
| 2 (R) | Ground | Back door closure motor (close) | Output | Back door | Close operation | 9 - 16 V |
| | | | | | Other than above | 0 - 1.5 V |
| 3 (G) | Ground | Back door closure motor (open) | Output | Back door | Open operation | 9 - 16 V |
| | | | | | Other than above | 0 - 1.5 V |
| 4 (O) | Ground | Automatic back door close switch | Input | Automatic back door close switch | Pressed | 0 - 1.5 V |
| | | | | | Released | 9 - 16 V |
| 5 (GR) | Ground | Automatic back door warning buzzer | Output | Automatic back door warning buzzer | Sounding | 0 - 1.5 V |
| | | | | | Not sounding | 9 - 16 V |
| 6 (B/R) | Ground | Ground (destination) | — | — | | 0 - 1.5 V |
| 7 (W) | Ground | Power supply (IGN) | Input | Ignition switch ON | | 9 - 16 V |
| 8 (B/R) | Ground | Ground (Hazard reminder) | — | — | | 0 - 1.5 V |
| 9 (LG) | Ground | Power supply (BAT) | Input | — | | 9 - 16 V |
| 11 (B/R) | Ground | Ground | — | — | | 0 - 1.0 V |
| 13 (LG) | Ground | Touch sensor RH signal | Input | Back door touch sensor RH | Detect obstruction | 0 - 1.5 V |
| | | | | | Other than above | 5 - 6.7 V |
| 14 (P) | Ground | Touch sensor ground | Input | — | | 0 - 1.5 V |

AUTOMATIC BACK DOOR CONTROL MODULE

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Voltage |
|------------------------------|--------|----------------------------|------------------|----------------------------|---------------------------------|
| (+) | (-) | Signal name | Input/ Output | | |
| 15 (BR) | Ground | Touch sensor LH signal | Input | Back door touch sensor LH | Detect obstruction 0 - 1.5 V |
| | | | | Other than above | 5 - 6.7 V |
| 16 (L) | Ground | Automatic back door switch | Input | Automatic back door switch | Pressed 0 - 1.5 V |
| | | | | Released | 9 - 16 V |
| 17 (Y) | Ground | Automatic door main switch | Input | Automatic door main switch | ON 9 - 16 V |
| | | | | OFF | 0 - 1.5 V |
| 20 (R) | Ground | Close switch signal | Input | Back door | Fully closed 0 - 1.5 V |
| | | | | Open/half latch | 9 - 16 V |
| 22 (W) | Ground | Half latch switch signal | Input | Back door | Open 0 - 1.5 V |
| | | | | Fully closed/half latch | 9 - 16 V |
| 24 (G) | Ground | Open switch signal | Input | Back door | Open 0 - 1.5 V |
| | | | | Half latch/fully closed | 9 - 16 V |
| 25 (P) | Ground | CAN - L | Input/ Output | — | — |
| 26 (L) | Ground | CAN - H | Input/ Output | — | — |

Fail Safe

INFOID:000000009649020

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|--|--|
| B2401 IGN OPEN | Intermittent clutch function | All following condition are satisfied <ul style="list-style-type: none"> Power supply condition of automatic back door control unit: OFF BCM receive ignition position signal (OFF) via CAN |
| B2403 PULSE ENCODER | Inhibit automatic back door operation | When receiving the pulse from encoders A and B normally (5 pulses) |
| B2409 HALF LATCH SW | Intermittent clutch function | Half latch switch is ON from OFF |
| B2416 TOUCH SEN R OPEN | During close operation: Intermittent clutch function | Normal return |
| B2417 TOUCH SEN L OPEN | During close operation: Intermittent clutch function | Normal return |
| B2419 OPEN SW | Inhibit automatic back door operation | Erase DTC, reconnect battery |
| B2420 CLOSE SW | Inhibit automatic back door operation | Erase DTC, reconnect battery |
| B2421 CLUTCH TIME OUT | Intermittent clutch function | Reception of next operation request |
| B2422 BACK DOOR STATE | Intermittent clutch function | Detect back door fully closed position |
| B2423 ABD MTR TIME OUT | Intermittent clutch function | Reception of next operation request |
| B2424 CLSR CONDITION | Inhibit automatic back door operation | Normal return or reconnect battery |

DTC Inspection Priority Chart

INFOID:000000009649021

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

AUTOMATIC BACK DOOR CONTROL MODULE

< ECU DIAGNOSIS INFORMATION >

| Priority | DTC |
|----------|---|
| 1 | <ul style="list-style-type: none"> • B2425 AUTO BK DR CNT UNIT • U1000: CAN COMM • U1010: CONTROL UNIT (CAN) • B2401 IGN OPEN |
| 2 | <ul style="list-style-type: none"> • B2403 PULSE ENCODER • B2409 HALF LATCH SW • B2416 TOUCH SEN R OPEN • B2417 TOUCH SEN L OPEN • B2419 OPEN SW • B2420 CLOSE SW • B2421 CLUTCH TIME OUT • B2422 BACK DOOR STATE • B2423 ABD MTR TIME OUT • B2424 CLSR CONDITION |

DTC Index

INFOID:000000009649022

NOTE:

Details of time display

- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

| CONSULT display | Fail-safe | Reference page |
|-----------------------------|-----------|-------------------------|
| U1000: CAN COMM | — | DLK-171 |
| U1010: CONTROL UNIT(CAN) | — | DLK-173 |
| B2401: IGN OPEN | × | DLK-174 |
| B2403: PULSE ENCODER | × | DLK-182 |
| B2409: HALF LATCH SW | × | DLK-188 |
| B2416: TOUCH SEN R OPEN | × | DLK-210 |
| B2417: TOUCH SEN L OPEN | × | DLK-213 |
| B2419: OPEN SW | × | DLK-216 |
| B2420: CLOSE SW | × | DLK-218 |
| B2421: CLUTCH TIME OUT | × | DLK-220 |
| B2422: BACK DOOR STATE | × | DLK-221 |
| B2423: ABD MTR TIME OUT | × | DLK-222 |
| B2424: CLSR CONDITION | × | DLK-223 |
| B2425: AUTO BCK DR CNT UNIT | — | DLK-225 |

DLK

BACK DOOR CONTROL UNIT


< ECU DIAGNOSIS INFORMATION >

BACK DOOR CONTROL UNIT

Reference Value

INFOID:000000009649023

TERMINAL LAYOUT



PHYSICAL VALUES

| Terminal No. (Wire color) | | Description | | Condition | | Voltage |
|------------------------------|--------|---------------------------------|------------------|-------------------------|-------------------------|-------------|
| (+) | (-) | Signal name | Input/ Output | | | |
| 1 (L) | Ground | Close switch signal | Input | Closure motor | Stop | 8 - 16 V |
| | | | | | Close operation | 8 - 16 V |
| | | | | | Open operation | 0 - 1.5 V |
| 2 (GR) | Ground | Half-latch switch signal | Input | Back door | Open | 0 - 1.5 V |
| | | | | | Fully closed/half latch | 3.5 - 5.5 V |
| 3 (G) | Ground | Battery power supply | Input | — | | 8 - 16 V |
| 4 (V) | Ground | Back door closure motor (close) | Output | Back door | Close operation | 5 - 16 V |
| | | | | | Other than above | 0 - 1.5 V |
| 5 (O) | Ground | Open switch signal | Input | Closure motor | Stop | 8 - 16 V |
| | | | | | Close operation | 0 - 1.5 V |
| | | | | | Open operation | 8 - 16 V |
| 6 (BR) | Ground | Back door open request signal | Input | Back door opener switch | Pressed | 0 - 1.5 V |
| | | | | | Released | 8 - 16 V |
| 7 (B) | Ground | Ground | — | — | — | 0 - 1.5 V |
| 8 (B/W) | Ground | Ground | — | — | — | 0 - 1.5 V |
| 10 (G) | Ground | Back door closure motor (open) | Output | Back door | Open operation | 5 - 16 V |
| | | | | | Other than above | 0 - 1.5 V |

SLIDING DOOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

SLIDING DOOR CONTROL UNIT

LH

LH : Reference Value

INFOID:000000009649024

CONSULT MONITOR ITEM

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor Item | Condition | | Value/Status |
|---------------|---|----------------------------------|-----------------------------------|
| SPEED METER | While driving | | Equivalent to speedometer reading |
| ABS SPEED | While driving | | Equivalent to speedometer reading |
| MAIN SW | Automatic door main switch | OFF | OFF |
| | | ON | ON |
| KNOB LCK SW L | Sliding door lock knob LH | Lock | OFF |
| | | Unlock | ON |
| ONE-TOUCH SW | Sliding door one-touch open/close switch LH | Release | OFF |
| | | Press | ON |
| F LID SW | Fuel filler lid status switch | OFF | OFF |
| | | ON | ON |
| B PILLER SW | Sliding door open/close switch (rear LH) | Release | OFF |
| | | Press | ON |
| DRIVER SW | Sliding door open/close switch (front LH) | Release | OFF |
| | | Press | ON |
| ACC On SW | Ignition position | Other than below | OFF |
| | | ON, ACC position | ON |
| DOR HAND SW L | Sliding door handle LH | Release | OFF |
| | | Pull | ON |
| TOUCH SEN LH | Sliding door touch sensor LH | Other than below | OFF |
| | | Pinching detection | ON |
| RR-LH DOOR SW | Sliding door LH | Close | OFF |
| | | Open | ON |
| HAF LATC SW L | Sliding door LH | Half latch/fully closed | OFF |
| | | Open | ON |
| P RANGE SW | Selector lever | Other than P position | OFF |
| | | P position | ON |
| BRAKE SW | Brake pedal | Not depressed | OFF |
| | | Depressed | ON |
| P BRAKE SW | Parking brake | Not operate | OFF |
| | | Operate | ON |
| KEYLESS SIG | Intelligent Key button (sliding door LH) | Pressed for short period of time | REV |
| | | Pressed for long period of time | MOVE |
| | | No operation | OFF |

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O


P

SLIDING DOOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | | Value/Status |
|----------------|-------------------------------|-------------------------|--------------|
| IGN SW | Ignition position | Other than below | OFF |
| | | ON position | ON |
| ENCODER A LH | Sliding door LH | Moving (auto or manual) | HI ⇔ LO |
| | | When stopped | HI or LO |
| ENCODER B LH | Sliding door LH | Moving (auto or manual) | HI ⇔ LO |
| | | When stopped | HI or LO |
| CHILD LOCK SW | Child lock | Lock | OFF |
| | | Unlock | ON |
| FULL LATC SW L | Sliding door LH | Full closed | OFF |
| | | Other than below | ON |
| NEUTRAL SW | Sliding door closure motor LH | Neutral position | OFF |
| | | Other than below | ON |

TERMINAL LAYOUT




PHYSICAL VALUES

| Terminal No. (Wire color) | | Description | | Condition | Voltage | | | | |
|------------------------------|------------------|--|------------------|--|---|-------------------------|---|--------------|------------------|
| (+) | (-) | Signal name | Input/ Output | | | | | | |
| 1 (Y) | Ground | Automatic door main switch | Input | Automatic door main switch | <table border="1"> <tr> <td>OFF</td> <td>8 – 16 V</td> </tr> <tr> <td>ON</td> <td>0 – 1.5 V</td> </tr> </table> | OFF | 8 – 16 V | ON | 0 – 1.5 V |
| OFF | 8 – 16 V | | | | | | | | |
| ON | 0 – 1.5 V | | | | | | | | |
| 2 (R) | Ground | Sliding door open/ close switch (rear LH) | Input | Sliding door open/close switch (rear LH) | <table border="1"> <tr> <td>Released</td> <td>8 – 16 V</td> </tr> <tr> <td>Pressed</td> <td>0 – 1.5 V</td> </tr> </table> | Released | 8 – 16 V | Pressed | 0 – 1.5 V |
| Released | 8 – 16 V | | | | | | | | |
| Pressed | 0 – 1.5 V | | | | | | | | |
| 3 (SB) | Ground | Sliding door lock status switch | Input | Sliding door lock knob | <table border="1"> <tr> <td>Unlock</td> <td>0 – 1.5 V</td> </tr> <tr> <td>Lock</td> <td>8 – 16 V</td> </tr> </table> | Unlock | 0 – 1.5 V | Lock | 8 – 16 V |
| Unlock | 0 – 1.5 V | | | | | | | | |
| Lock | 8 – 16 V | | | | | | | | |
| 4 (GR) | Ground | Encoder A signal | Input | Sliding door LH | <table border="1"> <tr> <td>Moving (auto or manual)</td> <td> <p style="text-align: right; font-size: small;">JMKIA6157ZZ</p> </td> </tr> <tr> <td>When stopped</td> <td>4 V or 0 – 0.5 V</td> </tr> </table> <p>NOTE: Waveform width changes according to sliding door open/close speed</p> | Moving (auto or manual) | <p style="text-align: right; font-size: small;">JMKIA6157ZZ</p> | When stopped | 4 V or 0 – 0.5 V |
| | | | | Moving (auto or manual) | <p style="text-align: right; font-size: small;">JMKIA6157ZZ</p> | | | | |
| When stopped | 4 V or 0 – 0.5 V | | | | | | | | |

SLIDING DOOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Voltage |
|------------------------------|--------|---|------------------|---|-------------------------|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 5 (LG) | Ground | Half latch switch | Input | Sliding door LH | Open | 0 – 1.5 V |
| | | | | | Full closed/half latch | 8 – 16 V |
| 6 (W) | Ground | Power supply (IGN) | Input | Ignition switch ON | | 9 – 16 V |
| 8 (W) | Ground | Automatic sliding door warning buzzer | Output | Automatic sliding door warning buzzer LH | Sounding | 0 – 1.5 V |
| | | | | | Not sounding | 8 – 16 V |
| 9 (P) | Ground | CAN - L | Input/ Output | — | | — |
| 10 (L) | Ground | CAN - H | Input/ Output | — | | — |
| 11 (O) | Ground | Encoder power supply | Output | Ignition switch OFF | | 8 – 16 V |
| 12 (LG) | Ground | Power supply (BAT) | Input | Ignition switch OFF | | 8 – 16 V |
| 14 (GR) | Ground | Sliding door one-touch open/close switch | Output | Sliding door one-touch open/close switch LH | Released | 8 – 16 V |
| | | | | | Pressed | 0 – 1.5 V |
| 15 (R) | Ground | Neutral switch | Input | Sliding door closure motor | Neutral position | 8 – 16 V |
| | | | | | Other than above | 0 – 1.5 V |
| 17 (G) | Ground | Fuel filler lid status switch | Input | Fuel filler lid status switch | OFF | 8 – 16 V |
| | | | | | ON | 0 – 1.5 V |
| 18 (L) | Ground | Full latch switch | Input | Sliding door LH | Full closed | 8 – 16 V |
| | | | | | Other than above | 0 – 1.5 V |
| 19 (P) | Ground | Sliding door open/close switch (front side) | Input | Sliding door open/close switch (front LH) | Released | 8 – 16 V |
| | | | | | Pressed | 0 – 1.5 V |
| 20 (R) | Ground | Child lock status switch | Input | Child lock | Unlock | 0 – 1.5 V |
| | | | | | Lock | 8 – 16 V |
| 21 (BR) | Ground | Encoder B signal | Input | Sliding door LH | Moving (auto or manual) |  <p style="text-align: right; font-size: small;">JMkia6157ZZ</p> |
| | | | | | When stopped | 4 V or 0 – 0.5 V |
| 22 (O) | Ground | Sliding door handle switch | Input | Sliding door handle LH | Released | 8 – 16 V |
| | | | | | Pulled | 0 – 1.5 V |
| 23 (B) | Ground | Ground | — | — | | 0 V |

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

SLIDING DOOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Voltage |
|------------------------------|--------|--|------------------|---------------------------------------|----------------------|-----------|
| (+) | (-) | Signal name | Input/ Output | | | |
| 24 (G) | Ground | Sliding door touch sensor | Input | Sliding door touch sensor LH | Pinching detection | 0 – 1.5 V |
| | | | | | Other than above | 4 – 8 V |
| 26 (SB) | Ground | Ground (encoder) | — | — | — | 0 V |
| 27 (B/Y) | Ground | Ground | — | — | — | 0 V |
| 28 (V) | Ground | Sliding door switch | Input | Sliding door switch LH | Close | 8 – 16 V |
| | | | | | Open | 0 – 1.5 V |
| 33 (B/Y) | Ground | Ground | — | — | — | 0 V |
| 34 (GR) | Ground | Sliding door closure motor (close) | Output | Sliding door closure motor LH | Close operation | 9 – 16 V |
| | | | | | Other than above | 0 – 1.5 V |
| 35 (SB) | Ground | Sliding door closure motor (return) | Output | Sliding door closure motor LH | Return operation | 9 – 16 V |
| | | | | | Other than above | 0 – 1.5 V |
| 36 (V) | Ground | Power supply (BAT) | Input | Ignition switch OFF | — | 9 – 16 V |
| 37 (B/Y) | Ground | Ground | — | — | — | 0 V |
| 39 (G) | Ground | Sliding door lock release actuator (-) | Output | Sliding door lock release actuator LH | Operate | 0 – 1.5 V |
| | | | | | Other than above | 0 V |
| 40 (Y) | Ground | Sliding door lock release actuator (+) | Output | Sliding door lock release actuator LH | Operate | 9 – 16 V |
| | | | | | Other than above | 0 V |
| 42 (V) | Ground | Power supply (sliding door auto closure) | Input | Ignition switch OFF | — | 9 – 16 V |
| 43 (R) | Ground | Sliding door motor (open) | Output | Sliding door LH | Auto open operation | 9 – 16 V |
| | | | | | Other than above | 0 – 1.5 V |
| 44 (P) | Ground | Clutch (-) | Output | Clutch LH | ON | 0 – 1.5 V |
| | | | | | OFF | 0 V |
| 46 (W) | Ground | Sliding door motor (close) | Output | Sliding door LH | Auto close operation | 9 – 16 V |
| | | | | | Other than above | 0 – 1.5 V |
| 47 (SB) | Ground | Clutch (+) | Output | Clutch LH | ON | 9 – 16 V |
| | | | | | OFF | 0 V |

LH : Fail-safe

INFOID:000000009649025

FAIL-SAFE CONTROL BT DTC

Sliding door control unit performs fail-safe control when any DTC is detected.

SLIDING DOOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

| Display contents of CONSULT | Fail-safe | Reference page ^{*1} |
|-----------------------------|-------------------------------|---|
| U1010: CAN COMM CIRCUIT | Intermittent clutch operation | Return to normal status ^{*2} |
| B2401: IGN OPEN | | When the following conditions are fulfilled <ul style="list-style-type: none"> Sliding door control unit detects that ignition switch is in the OFF position Sliding door control unit detects that ignition switch is not in the ON position via CAN communication |
| B2402: TOUCH SENSOR OPEN | | Return to normal status |
| B2403: PULSE ENCODER | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2405: ECU FAIL | | Erase DTC ^{*2} |
| B2409: HALF LATCH SW | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2412: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2413: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2414: ASD MTR TIME OUT | | Sliding door control unit detects that sliding door is in the fully closed position |
| B241A: ENCDR PWR SUPPLY | | When the following conditions are fulfilled <ul style="list-style-type: none"> Return to normal status Sliding door control unit detects that sliding door is in the fully closed position |

A
B
C
D
E
F
G
H
I
J

DLK

*1: When battery is reconnected, cancellation conditions are unconditionally fulfilled.

*2: After returning to normal status, auto open/close function does not operate unless sliding door auto closure function is operated.

LH : DTC Inspection Priority Chart

INFOID:000000009649026

| Priority | DTC |
|----------|---|
| 1 | <ul style="list-style-type: none"> U1000: CAN COMM CIRCUIT U1010: CONTROL UNIT (CAN) B2401: IGN OPEN B2405: ECU FAIL |
| 2 | <ul style="list-style-type: none"> B2402: TOUCH SENSOR OPEN B2403: PULSE ENCODER B2409: HALF LATCH SW B241A: ENCDR PWR SUPPLY |
| 3 | <ul style="list-style-type: none"> B2412: ASD MTR/ENCDR B2413: ASD MTR/ENCDR B2414: ASD MTR TIME OUT |

M
N
O
P

LH : DTC Index

INFOID:000000009649027

NOTE:

SLIDING DOOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

| CONSULT display | Fail-safe | Reference page |
|---------------------------|-----------|-------------------------|
| U1000: CAN COMM CIRCUIT | — | DLK-171 |
| U1010: CONTROL UNIT (CAN) | × | DLK-173 |
| B2401: IGN OPEN | × | DLK-174 |
| B2402: TOUCH SENSOR OPEN | × | DLK-177 |
| B2403: PULSE ENCODER | × | DLK-182 |
| B2405: ECU FAIL | × | DLK-187 |
| B2409: HALF LATCH SW | × | DLK-189 |
| B2412: ASD MTR/ENCDR | × | DLK-197 |
| B2413: ASD MTR/ENCDR | × | DLK-203 |
| B2414: ASD MTR TIME OUT | × | DLK-206 |
| B241A: ENCDR PWR SUPPLY | × | DLK-194 |

RH

RH : Reference Value

INFOID:000000009649028

CONSULT MONITOR ITEM

NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

| Monitor Item | Condition | | Value/Status |
|---------------|---|--------------------|-----------------------------------|
| SPEED METER | While driving | | Equivalent to speedometer reading |
| ABS SPEED | While driving | | Equivalent to speedometer reading |
| MAIN SW | Automatic door main switch | OFF | OFF |
| | | ON | ON |
| KNOB LCK SW R | Sliding door lock knob RH | Lock | OFF |
| | | Unlock | ON |
| ONE-TOUCH SW | Sliding door one-touch open/close switch RH | Release | OFF |
| | | Press | ON |
| F LID SW | NOTE: This item is displayed, but cannot be monitored | | OFF |
| B PILLER SW | Sliding door open/close switch (rear RH) | Release | OFF |
| | | Press | ON |
| DRIVER SW | Sliding door open/close switch (front RH) | Release | OFF |
| | | Press | ON |
| ACC On SW | Ignition position | Other than bellow | OFF |
| | | ON, ACC position | ON |
| DOR HAND SW R | Sliding door handle RH | Release | OFF |
| | | Pull | ON |
| TOUCH SEN RH | Sliding door touch sensor RH | Other than bellow | OFF |
| | | Pinching detection | ON |


SLIDING DOOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | | Value/Status |
|---------------|--|----------------------------------|--------------|
| RR-RH DOOR SW | Sliding door RH | Close | OFF |
| | | Open | ON |
| HAF LATC SW R | Sliding door RH | Half latch/fully closed | OFF |
| | | Open | ON |
| P RANGE SW | Selector lever | Other than P position | OFF |
| | | P position | ON |
| BRAKE SW | Brake pedal | Not depressed | OFF |
| | | Depressed | ON |
| P BRAKE SW | Parking brake | Not operate | OFF |
| | | Operate | ON |
| KEYLESS SIG | Intelligent Key button (sliding door RH) | Pressed for short period of time | REV |
| | | Pressed for long period of time | MOVE |
| | | No operation | OFF |
| IGN SW | Ignition position | Other than bellow | OFF |
| | | ON position | ON |
| ENCODER A RH | Sliding door RH | Moving (auto or manual) | HI ⇔ LO |
| | | When stopped | HI or LO |
| ENCODER B RH | Sliding door RH | Moving (auto or manual) | HI ⇔ LO |
| | | When stopped | HI or LO |
| CHILD LOCK SW | Child lock | Lock | OFF |
| | | Unlock | ON |
| FUL LATC SW R | Sliding door RH | Full closed | OFF |
| | | Other than bellow | ON |
| NEUTRAL SW | Sliding door closure motor RH | Neutral position | OFF |
| | | Other than bellow | ON |

A
B
C
D
E
F
G
H
I
J
DLK

TERMINAL LAYOUT



L
M
N
O


PHYSICAL VALUES

| Terminal No. (Wire color) | | Description | | Condition | | Voltage |
|------------------------------|--------|----------------------------|------------------|----------------------------|-----|-----------|
| (+) | (-) | Signal name | Input/ Output | | | |
| 1 (Y) | Ground | Automatic door main switch | Input | Automatic door main switch | OFF | 8 – 16 V |
| | | | | | ON | 0 – 1.5 V |

P


SLIDING DOOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Voltage |
|------------------------------|--------|--|------------------|---|----------------------------|---|
| (+) | (-) | Signal name | Input/ Output | | | |
| 2 (BR) | Ground | Sliding door open/ close switch (rear RH) | Input | Sliding door open/close switch (rear RH) | Released | 8 – 16 V |
| | | | | | Pressed | 0 – 1.5 V |
| 3 (L) | Ground | Sliding door lock sta- tus switch | Input | Sliding door lock knob RH | Unlock | 0 – 1.5 V |
| | | | | | Lock | 8 – 16 V |
| 4 (R) | Ground | Encoder A signal | Input | Sliding door RH | Moving (auto or manual) |  <p style="text-align: right; font-size: small;">JMKIA6157ZZ</p> |
| | | | | | When stopped | 4 V or 0 – 0.5 V |
| 5 (GR) | Ground | Half latch switch | Input | Sliding door RH | Open | 0 – 1.5 V |
| | | | | | Full closed/half latch | 8 – 16 V |
| 6 (LG) | Ground | Power supply (IGN) | Input | Ignition switch ON | | 9 – 16 V |
| 8 (BR) | Ground | Automatic sliding door warning buzzer | Output | Automatic slid- ing door warning buzzer RH | Sounding | 0 – 1.5 V |
| | | | | | Not sounding | 8 – 16 V |
| 9 (P) | Ground | CAN - L | Input/ Output | — | | — |
| 10 (L) | Ground | CAN - H | Input/ Output | — | | — |
| 11 (G) | Ground | Encoder power sup- ply | Output | Ignition switch OFF | | 8 – 16 V |
| 12 (O) | Ground | Power supply (BAT) | Input | Ignition switch OFF | | 8 – 16 V |
| 14 (SB) | Ground | Sliding door one- touch open/close switch | Output | Sliding door one- touch open/ close switch RH | Released | 8 – 16 V |
| | | | | | Pressed | 0 – 1.5 V |
| 15 (V) | Ground | Neutral switch | Input | Sliding door clo- sure motor | Neutral position | 8 – 16 V |
| | | | | | Other than above | 0 – 1.5 V |
| 18 (W) | Ground | Half latch switch | Input | Sliding door RH | Full closed | 8 – 16 V |
| | | | | | Other than above | 0 – 1.5 V |
| 19 (GR) | Ground | Sliding door open/ close switch (front side) | Input | Sliding door open/close switch (front RH) | Released | 8 – 16 V |
| | | | | | Pressed | 0 – 1.5 V |
| 20 (LG) | Ground | Child lock status switch | Input | Child lock | Unlock | 0 – 1.5 V |
| | | | | | Lock | 8 – 16 V |

SLIDING DOOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Voltage |
|------------------------------|--------|--|------------------|---------------------------------------|---|
| (+) | (-) | Signal name | Input/ Output | | |
| 21 (V) | Ground | Encoder B signal | Input | Sliding door RH |  <p>NOTE: Waveform width changes according to sliding door open/close speed</p> |
| | | | | When stopped | 4 V or 0 – 0.5 V |
| 22 (Y) | Ground | Sliding door handle switch | Input | Sliding door handle RH | Released 8 – 16 V Pulled 0 – 1.5 V |
| | | | | | |
| 23 (B) | Ground | Ground | — | — | 0 V |
| 24 (G) | Ground | Sliding door touch sensor | Input | Sliding door touch sensor RH | Pinching detection 0 – 1.5 V Other than above 4 – 8 V |
| | | | | | |
| 26 (GR) | Ground | Ground (encoder) | — | — | 0 V |
| 27 (B/Y) | Ground | Ground | — | — | 0 V |
| 28 (W) | Ground | Sliding door switch | Input | Sliding door switch RH | Close 8 – 16 V Open 0 – 1.5 V |
| | | | | | |
| 33 (B/R) | Ground | Ground | — | — | 0 V |
| 34 (R) | Ground | Sliding door closure motor (close) | Output | Sliding door closure motor RH | Close operation 9 – 16 V Other than above 0 – 1.5 V |
| | | | | | |
| 35 (G) | Ground | Sliding door closure motor (return) | Output | Sliding door closure motor RH | Return operation 9 – 16 V Other than above 0 – 1.5 V |
| | | | | | |
| 36 (Y) | Ground | Power supply (BAT) | Input | Ignition switch OFF | 9 – 16 V |
| 37 (B/R) | Ground | Ground | — | — | 0 V |
| 39 (L) | Ground | Sliding door lock release actuator (-) | Output | Sliding door lock release actuator RH | Operate 0 – 1.5 V Other than above 0 V |
| | | | | | |
| 40 (O) | Ground | Sliding door lock release actuator (+) | Output | Sliding door lock release actuator RH | Operate 9 – 16 V Other than above 0 V |
| | | | | | |
| 42 (Y) | Ground | Power supply (sliding door auto closure) | Input | Ignition switch OFF | 9 – 16 V |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SLIDING DOOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Voltage |
|------------------------------|--------|-------------------------------|------------------|-----------------|----------------------|-----------|
| (+) | (-) | Signal name | Input/ Output | | | |
| 43 (B) | Ground | Sliding door motor (open) | Output | Sliding door RH | Auto open operation | 9 – 16 V |
| | | | | | Other than above | 0 – 1.5 V |
| 44 (L) | Ground | Clutch (-) | Output | Clutch RH | ON | 0 – 1.5 V |
| | | | | | OFF | 0 V |
| 46 (W) | Ground | Sliding door motor (close) | Output | Sliding door RH | Auto close operation | 9 – 16 V |
| | | | | | Other than above | 0 – 1.5 V |
| 47 (BR) | Ground | Clutch (+) | Output | Clutch RH | ON | 9 – 16 V |
| | | | | | OFF | 0 V |

RH : Fail-safe

INFOID:000000009649029

FAIL-SAFE CONTROL BT DTC

Sliding door control unit performs fail-safe control when any DTC is detected.

| Display contents of CONSULT | Fail-safe | Reference page ^{*1} |
|-----------------------------|-------------------------------|---|
| U1010: CAN COMM CIRCUIT | Intermittent clutch operation | Return to normal status ^{*2} |
| B2401: IGN OPEN | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Sliding door control unit detects that ignition switch is in the OFF position • Sliding door control unit detects that ignition switch is not in the ON position via CAN communication |
| B2402: TOUCH SENSOR OPEN | | Return to normal status |
| B2403: PULSE ENCODER | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2405: ECU FAIL | | Erase DTC ^{*2} |
| B2409: HALF LATCH SW | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2412: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2413: ASD MTR/ENCDR | | Sliding door control unit detects that sliding door is in the fully closed position |
| B2414: ASD MTR TIME OUT | | Sliding door control unit detects that sliding door is in the fully closed position |
| B241A: ENCDR PWR SUPPLY | | When the following conditions are fulfilled <ul style="list-style-type: none"> • Return to normal status • Sliding door control unit detects that sliding door is in the fully closed position |

SLIDING DOOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

*1: When battery is reconnected, cancellation conditions are unconditionally fulfilled.

*2: After returning to normal status, auto open/close function does not operate unless sliding door auto closure function is operated.

RH : DTC Inspection Priority Chart

INFOID:000000009649030

| Priority | DTC |
|----------|---|
| 1 | <ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN) • B2401: IGN OPEN • B2405: ECU FAIL |
| 2 | <ul style="list-style-type: none"> • B2402: TOUCH SENSOR OPEN • B2403: PULSE ENCODER • B2409: HALF LATCH SW • B241A: ENCDR PWR SUPPLY |
| 3 | <ul style="list-style-type: none"> • B2412: ASD MTR/ENCDR • B2413: ASD MTR/ENCDR • B2414: ASD MTR TIME OUT |

RH : DTC Index

INFOID:000000009649031

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
- PAST: A malfunction was detected in the past.

| CONSULT display | Fail-safe | Reference page |
|---------------------------|-----------|-------------------------|
| U1000: CAN COMM CIRCUIT | — | DLK-172 |
| U1010: CONTROL UNIT (CAN) | × | DLK-173 |
| B2401: IGN OPEN | × | DLK-175 |
| B2402: TOUCH SENSOR OPEN | × | DLK-179 |
| B2403: PULSE ENCODER | × | DLK-184 |
| B2405: ECU FAIL | × | DLK-187 |
| B2409: HALF LATCH SW | × | DLK-192 |
| B2412: ASD MTR/ENCDR | × | DLK-199 |
| B2413: ASD MTR/ENCDR | × | DLK-203 |
| B2414: ASD MTR TIME OUT | × | DLK-207 |
| B241A: ENCDR PWR SUPPLY | × | DLK-195 |

DLK

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

WIRING DIAGRAM

DOOR & LOCK SYSTEM

Wiring Diagram

INFOID:000000009649032




2013/07/10

JRKCW6495GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >




JRKWC6496GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >



JRKWC6497GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >




JRKWC6498GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >



JRKWC6499GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >


DOOR LOCK SYSTEM

| | |
|----------------|------------------------------------|
| Connector No. | B8 |
| Connector Name | AUTOMATIC BACK DOOR CONTROL MODULE |
| Connector Type | TH20PW-TB8 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SB | +B |
| 2 | R | LATCH MTR CLOSE |
| 3 | G | LATCH MTR OPEN |
| 4 | O | INSIDE CLOSE SW |
| 5 | GR | BULZER |
| 6 | B/R | NAM-FUNC-FLG |
| 7 | W | +GN |
| 8 | B/R | GROUND |
| 9 | LG | GROUND |
| 10 | B/R | GROUND |
| 11 | B/R | GROUND |
| 12 | B/R | GROUND |
| 13 | LG | TOUCH SENS RH |
| 14 | P | TOUCH SENS GND |
| 15 | BR | TOUCH SENS LH |
| 16 | L | DRIVER SW |
| 17 | Y | MAIN SW |
| 18 | R | CLOSE SW |
| 19 | W | HALF LATCH SW |
| 20 | G | OPEN SW |
| 21 | P | GN-L |
| 22 | L | GN+H |

| | |
|----------------|--------------|
| Connector No. | B11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80MW-CS19 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10 | LG | - |
| 12 | Y | - |
| 13 | P | - |
| 15 | L | - |
| 29 | GR | - |
| 30 | W | - |
| 31 | BR | - |
| 37 | SHIELD | - |
| 38 | R/L | - |
| 39 | B | - |
| 40 | R/W | - |
| 51 | O | - |
| 52 | B/P | - |
| 53 | V | - |
| 54 | P | - |
| 55 | L | - |
| 57 | Y | - |
| 58 | Y | - |
| 60 | O | - |
| 61 | B | - |
| 62 | W | - |
| 63 | Y | - |
| 64 | W | - |
| 65 | R | - |
| 66 | SHIELD | - |
| 67 | B | - |
| 68 | W | - |
| 69 | SHIELD | - |
| 70 | W/R | - |
| 71 | B/R | - |
| 72 | P | - |
| 74 | BR | - |
| 75 | SB | - |
| 77 | V | - |

| | | |
|----|----|--|
| 78 | LG | - |
| 79 | W | - |
| 80 | R | - |
| 81 | SP | - |
| 82 | BR | - |
| 83 | P | - |
| 84 | BR | - |
| 85 | BR | - |
| 86 | LG | - [Without automatic drive positioner] |
| 87 | P | - [With automatic drive positioner] |
| 89 | O | - |
| 90 | G | - |
| 91 | O | - |
| 92 | G | - |

| | |
|----------------|--------------|
| Connector No. | B20 |
| Connector Name | WIRE TO WIRE |
| Connector Type | M06MW-LC |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | G | - [With automatic back door] |
| 1 | V | - [Without automatic back door] |
| 2 | B | - |
| 3 | B | - [Without automatic back door] |
| 3 | Y | - [With automatic back door] |
| 5 | P | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | B21 |
| Connector Name | WIRE TO WIRE |
| Connector Type | N516MW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | B | - |
| 5 | Y | - |
| 6 | BR | - |
| 7 | LG | - |
| 8 | GR | - |
| 9 | SB | - |
| 10 | Y | - |
| 11 | G | - |
| 14 | O | - |
| 15 | W | - |
| 16 | B | - |

| | |
|----------------|--------------|
| Connector No. | B28 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16PW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 2 | W/R | - |
| 3 | B/R | - |
| 4 | SHIELD | - |
| 5 | B/W | - |
| 6 | L | - |
| 7 | Y | - |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

JRKWC6500GB


DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

DOOR LOCK SYSTEM

| | | |
|----|-----|---|
| 8 | B/W | - |
| 9 | R | - |
| 10 | GR | - |
| 11 | GR | - |
| 12 | LG | - |

| | |
|----------------|--------------|
| Connector No. | B32 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24MW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | BR | - |
| 2 | B | - |
| 3 | SB | - |
| 4 | L | - |
| 5 | O | - |
| 6 | SB | - |
| 9 | SHIELD | - |
| 10 | RYL | - |
| 11 | B | - |
| 12 | SW | - |
| 13 | GR | - |
| 14 | O | - |
| 15 | W | - |
| 16 | G | - |
| 17 | R | - |
| 18 | W | - |
| 19 | BR | - |
| 20 | P | - |
| 21 | LG | - |
| 22 | BR | - |
| 23 | V | - |
| 24 | P | - |

| | |
|----------------|---------------------------------|
| Connector No. | B35 |
| Connector Name | FRONT DOOR SWITCH (DRIVER SIDE) |
| Connector Type | TH24FW-NH |



| | | | |
|-----------------------------|---|---|---|
| Terminal No. | 3 | O | - |
| Color Of Wire | | | |
| Signal Name [Specification] | | | |

| | |
|----------------|--------------|
| Connector No. | B42 |
| Connector Name | WIRE TO WIRE |
| Connector Type | HS18MW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | MAIN SW |
| 2 | R | B-FLR SW |
| 3 | SB | KNOB LOCK |
| 4 | GR | A-SIGN |
| 5 | LG | HALF LATCH |
| 6 | W | IGN |
| 8 | W | BUIZZER |
| 9 | P | GAN-L |
| 10 | L | GAN-H |
| 11 | O | ENCODER POWER |
| 12 | LG | ELEG B |
| 14 | GR | ONETOUCH OPEN SW |
| 15 | R | NEUTRAL SW |
| 17 | G | FUEL LD SW |
| 18 | L | FUEL SW |
| 19 | R | DRIVER SW |
| 20 | B | LOCK |
| 21 | BR | LOCK |
| 22 | GO | HANDLE |
| 23 | B | SW GND |
| 24 | G | TOUCH SENS |
| 26 | SB | ENCODER GND |
| 27 | B/Y | GD LOGIC |
| 28 | V | RR DOOR SW |

| | |
|----------------|------------------------------|
| Connector No. | B45 |
| Connector Name | SLIDING DOOR CONTROL UNIT LH |
| Connector Type | TH27FH-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | MAIN SW |
| 2 | R | B-FLR SW |
| 3 | SB | KNOB LOCK |
| 4 | GR | A-SIGN |
| 5 | LG | HALF LATCH |
| 6 | W | IGN |
| 8 | W | BUIZZER |
| 9 | P | GAN-L |
| 10 | L | GAN-H |
| 11 | O | ENCODER POWER |
| 12 | LG | ELEG B |
| 14 | GR | ONETOUCH OPEN SW |
| 15 | R | NEUTRAL SW |
| 17 | G | FUEL LD SW |
| 18 | L | FUEL SW |
| 19 | R | DRIVER SW |
| 20 | B | LOCK |
| 21 | BR | LOCK |
| 22 | GO | HANDLE |
| 23 | B | SW GND |
| 24 | G | TOUCH SENS |
| 26 | SB | ENCODER GND |
| 27 | B/Y | GD LOGIC |
| 28 | V | RR DOOR SW |

| | |
|----------------|------------------------|
| Connector No. | B71 |
| Connector Name | SLIDING DOOR SWITCH LH |
| Connector Type | TH24FW-NH |



| | | | |
|-----------------------------|---|---|---|
| Terminal No. | 3 | V | - |
| Color Of Wire | | | |
| Signal Name [Specification] | | | |

| | |
|----------------|------------------------|
| Connector No. | B21 |
| Connector Name | SLIDING DOOR SWITCH RH |
| Connector Type | TH24FW-NH |



| | | | |
|-----------------------------|---|---|---|
| Terminal No. | 3 | W | - |
| Color Of Wire | | | |
| Signal Name [Specification] | | | |

| | |
|----------------|--------------|
| Connector No. | B25 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16MW-NH |



JRKWC6501GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

DOOR LOCK SYSTEM


| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | W | - |
| 3 | G | - |
| 4 | GR | - |
| 5 | BR | - |
| 6 | V | - |
| 7 | P | - |
| 8 | R | - |
| 9 | G | - |
| 10 | L | - |
| 11 | SB | - |
| 12 | W | - |
| 13 | Y | - |
| 14 | GR | - |
| 15 | LG | - |
| 16 | O | - |

| | |
|----------------|------------------------------------|
| Connector No. | BZ35 |
| Connector Name | FRONT DOOR SWITCH (PASSENGER SIDE) |
| Connector Type | TRH4FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SB | - |
| 2 | Y | - |
| 3 | SB | - |

| | |
|----------------|--------------|
| Connector No. | BZ27 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16MGY-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | Y | - |
| 3 | SB | - |

| | | |
|----|----|---|
| 4 | BR | - |
| 5 | LG | - |
| 6 | G | - |
| 7 | GR | - |
| 8 | GR | - |
| 9 | SB | - |
| 10 | V | - |
| 11 | V | - |
| 12 | P | - |
| 13 | W | - |
| 14 | R | - |
| 15 | L | - |
| 16 | G | - |

| | |
|----------------|--------------|
| Connector No. | BZ39 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16BMW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | BR | - [Without BOSE system] |
| 1 | L | - [With BOSE system] |
| 2 | P | - [Without BOSE system] |
| 2 | B | - [With BOSE system] |
| 3 | SB | - |
| 4 | GR | - |
| 5 | O | - |
| 6 | R | - |
| 7 | SB | - |
| 8 | R | - |
| 9 | G | - |
| 10 | O | - |
| 11 | L | - |
| 14 | P | - |
| 15 | V | - |
| 16 | B/R | - |

| | |
|----------------|-----------------------------------|
| Connector No. | BZ41 |
| Connector Name | INSIDE KEY ANTENNA (LUGGAGE ROOM) |
| Connector Type | RK02FL |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | B | - |

| | |
|----------------|------------------------------|
| Connector No. | BZ4Z |
| Connector Name | INSIDE KEY ANTENNA (CONSOLE) |
| Connector Type | RK02FL |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | R | - |

| | |
|----------------|------------------------------|
| Connector No. | BZ47 |
| Connector Name | SLIDING DOOR CONTROL UNIT RH |
| Connector Type | TR432FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | MAIN SW |
| 2 | BR | B-PLP SW |
| 3 | L | KNOB LOCK |
| 4 | R | A-SIGN |
| 5 | GR | HALF LATCH |
| 6 | LG | IGN |
| 8 | BR | BUZZER |
| 9 | P | CAN-L |
| 10 | L | CAN-H |
| 11 | G | ENCODER POWER |
| 12 | O | ELEC B |
| 14 | SB | ONETOUCH OPEN SW |
| 15 | V | NEUTRAL SW |
| 18 | W | FULL SW |
| 19 | GR | DRIVER SW |
| 20 | LG | CHILD LOCK |
| 21 | V | B-SIGN |
| 22 | Y | HANDLE |
| 23 | B | TOYOTA SEALS |
| 24 | G | TOYOTA SEALS |
| 26 | GR | ENCODER CRD |
| 27 | B/Y | GO LOCK |
| 28 | W | RR DOOR SW |

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

JRKWC6502GB

DOOR & LOCK SYSTEM


< WIRING DIAGRAM >

DOOR LOCK SYSTEM

| | |
|----------------|-----------------------------------|
| Connector No. | B203 |
| Connector Name | OUTSIDE KEY ANTENNA (REAR BUMPER) |
| Connector Type | FR02FL |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | W | - |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | B | - |
| 3 | W | - |
| 4 | SHIELD | - |
| 5 | L | - |
| 6 | Y | - |
| 7 | R | - |
| 8 | B | - |
| 9 | R | - |
| 10 | W | - |
| 11 | P | - |
| 12 | LG | - |

| | |
|----------------|--------------------------|
| Connector No. | D5 |
| Connector Name | POWER WINDOW MAIN SWITCH |
| Connector Type | NS18FW-CS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 1 | O | - |
| 2 | W | - |
| 3 | BR | - |
| 4 | P | - |
| 5 | SB | - |
| 6 | BR | - [Without passenger power window anti-pinch system] |
| 7 | P | - [With front power window anti-pinch system] |
| 8 | BR | - [Without passenger power window anti-pinch system] |
| 9 | L | - [With front power window anti-pinch system] |
| 10 | V | - |
| 11 | GR | - [Without passenger power window anti-pinch system] |
| 12 | LG | - [With front power window anti-pinch system] |
| 13 | BR | - |
| 14 | R | - |
| 15 | R | - |
| 16 | L | - |

| | |
|----------------|--------------------------|
| Connector No. | D6 |
| Connector Name | POWER WINDOW MAIN SWITCH |
| Connector Type | NS03FW-CS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 17 | Y | - |
| 18 | R | - |
| 19 | W | - |
| 20 | R | - |
| 21 | B | - |
| 22 | W | - |
| 23 | LG | - |

| | |
|----------------|---|
| Connector No. | D9 |
| Connector Name | FRONT DOOR LOCK ASSEMBLY (PASSENGER SIDE) |
| Connector Type | ED06FY-RS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | R | - |
| 6 | LG | - |

| | |
|----------------|--------------|
| Connector No. | D21 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH06FY-CS16 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 7 | W | - |
| 8 | P | - [Without passenger power window anti-pinch system] |
| 9 | V | - [With front power window anti-pinch system] |
| 10 | BR | - [Without passenger power window anti-pinch system] |
| 11 | L | - [With front power window anti-pinch system] |
| 12 | LG | - |
| 13 | R | - |
| 14 | B | - |
| 15 | W | - |
| 16 | P | - |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 17 | Y | - |
| 18 | R | - |
| 19 | W | - |
| 20 | R | - |
| 21 | B | - |
| 22 | W | - |
| 23 | LG | - |
| 24 | SHIELD | - |
| 25 | G | - |
| 26 | L | - |
| 27 | LG | - |
| 28 | Y | - |
| 29 | L | - |
| 30 | O | - |
| 40 | B | - |
| 41 | W | - |
| 42 | R | - |
| 43 | P | - |
| 44 | G | - |
| 45 | GR | - |
| 46 | GR | - |
| 50 | BR | - |
| 51 | V | - |
| 52 | SB | - |
| 53 | SHIELD | - |
| 54 | G | - |
| 55 | R | - |

| | |
|----------------|---------------------------------------|
| Connector No. | D31 |
| Connector Name | FRONT DOOR OUTSIDE HANDLE ASSEMBLY RH |
| Connector Type | FR04MB |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | R | - |
| 3 | P | - |
| 4 | B | - |

JRKWC6503GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


DOOR LOCK SYSTEM

| | |
|----------------|---------------------------------------|
| Connector No. | D32 |
| Connector Name | FRONT DOOR OUTSIDE HANDLE ASSEMBLY LH |
| Connector Type | FR04MB |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P | - |
| 2 | V | - |
| 3 | Y | - |
| 4 | B | - |

| | |
|----------------|--------------|
| Connector No. | D41 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40FW-CS15 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 1 | B | - |
| 2 | P | - |
| 3 | SB | - |
| 4 | O | - |
| 5 | BR | - |
| 6 | BR | - |
| 7 | GR | - |
| 8 | V | - |
| 9 | BR | - [With front power window anti-pinch system] |
| 10 | LG | - [Without passenger power window anti-pinch system] |
| 11 | V | - |
| 12 | G | - |
| 13 | O | - |
| 14 | B | - |
| 15 | W | - |


| | | |
|----|--------|--|
| 16 | P | - |
| 17 | R | - |
| 18 | L | - |
| 19 | LG | - |
| 20 | YL | - |
| 21 | YL | - |
| 22 | BR | - |
| 23 | P | - |
| 24 | B | - |
| 25 | W | - |
| 26 | SHIELD | - |
| 27 | SB | - |
| 28 | G | - |
| 29 | V | - |
| 30 | W | - |
| 31 | O | - |
| 32 | LG | - |
| 33 | V | - |
| 34 | BR | - |
| 35 | P | - |
| 36 | SB | - |
| 37 | GR | - |
| 38 | L | - |
| 39 | V | - |
| 40 | BR | - |
| 41 | P | - |
| 42 | V | - |
| 43 | Y | - |
| 44 | B | - |
| 45 | B | - [Without automatic drive positioner] |
| 46 | P | - [With automatic drive positioner] |
| 47 | GR | - [Without automatic drive positioner] |
| 48 | P | - [With automatic drive positioner] |
| 49 | LG | - |
| 50 | W | - |
| 51 | R | - |
| 52 | LG | - |
| 53 | SHIELD | - |
| 54 | G | - |
| 55 | R | - |

| | |
|----------------|--|
| Connector No. | D48 |
| Connector Name | FRONT DOOR LOCK ASSEMBLY (DRIVER SIDE) |
| Connector Type | E0673Y-RS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 2 | G | - |
| 3 | O | - |
| 4 | B | - |
| 5 | GR | - |
| 6 | P | - |

| | |
|----------------|--|
| Connector No. | D55 |
| Connector Name | FRONT POWER WINDOW SWITCH (PASSENGER SIDE) |
| Connector Type | NS10FY-CS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | BR | - |
| 4 | SB | - |
| 8 | Y | - |
| 9 | G | - |
| 10 | V | - |
| 11 | W | - |
| 12 | O | - |
| 15 | R | - |
| 16 | L | - |

| | |
|----------------|--|
| Connector No. | D56 |
| Connector Name | FRONT POWER WINDOW SWITCH (PASSENGER SIDE) |
| Connector Type | NS12FY-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | GR | - |
| 2 | G | - |
| 3 | B | - |
| 6 | V | - |
| 7 | Y | - |
| 8 | P | - |
| 11 | LG | - |
| 12 | BR | - |

| | |
|----------------|--------------|
| Connector No. | D61 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS15FY-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | B | - |
| 4 | B | - |
| 5 | R | - |
| 6 | P | - |
| 7 | SB | - |
| 8 | W | - |
| 9 | W | - |
| 10 | O | - |
| 11 | G | - |
| 14 | L | - |
| 15 | Y | - |

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

DOOR LOCK SYSTEM

| | |
|----------------|--------------|
| Connector No. | DB2 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FW-CS |



| | | | | | | |
|----|----|----|----|----|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| 18 | 15 | 14 | 11 | 10 | 9 | 8 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | B | - |
| 5 | R | - |
| 6 | P | - |
| 7 | SB | - |
| 8 | BR | - |
| 9 | W | - |
| 10 | O | - |
| 11 | G | - |
| 14 | L | - |
| 15 | Y | - |
| 16 | BR | - |

| | |
|----------------|-------------------------------|
| Connector No. | DB5 |
| Connector Name | SLIDING DOOR LOCK ASSEMBLY LH |
| Connector Type | SDY02FGY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | L | - |

| | |
|----------------|--------------|
| Connector No. | DB1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | IM06FH-LC |



| | | |
|---|---|---|
| 3 | 2 | 1 |
| 6 | 5 | 4 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | G | - [Without automatic back door] |
| 2 | B | - [Without automatic back door] |
| 3 | B/W | - [Without automatic back door] |
| 4 | Y | - [Without automatic back door] |
| 5 | R | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | DB2 |
| Connector Name | WIRE TO WIRE |
| Connector Type | IM06FY-LC |



| | | |
|---|---|---|
| 3 | 2 | 1 |
| 6 | 5 | 4 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | B/W | - [Without automatic back door] |
| 2 | B | - [Without automatic back door] |
| 3 | G | - [Without automatic back door] |
| 5 | R | - |
| 6 | B | - |

| | |
|----------------|-------------------------------|
| Connector No. | D105 |
| Connector Name | SLIDING DOOR LOCK ASSEMBLY RH |
| Connector Type | SDY02FGY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | L | - |

| | |
|----------------|--------------|
| Connector No. | D111 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FY-CS |



| | | | | | | |
|----|----|----|----|----|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| 16 | 15 | 14 | 11 | 10 | 9 | 8 |

| | |
|----------------|--------------|
| Connector No. | D113 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FY-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | W | - |
| 5 | BR | - |
| 6 | BR | - |
| 7 | G | - |
| 8 | R | - |
| 9 | R | - |
| 10 | Y | - |
| 11 | Y | - |
| 14 | GR | - |
| 15 | GR | - |
| 16 | P | - |

| | |
|----------------|--------------|
| Connector No. | D112 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16MF-CS |



| | | | | | | |
|---|---|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 |
| 8 | 9 | 10 | 11 | 14 | 15 | 16 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | W | - |
| 5 | BR | - |
| 6 | BR | - |
| 7 | G | - |
| 8 | R | - |
| 9 | R | - |
| 10 | Y | - |
| 11 | Y | - |
| 14 | GR | - |
| 15 | GR | - |
| 16 | P | - |

| | |
|----------------|--------------|
| Connector No. | D113 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FY-CS |



| | | | | | | |
|----|----|----|----|----|---|---|
| 7 | 6 | 5 | 4 | 3 | 2 | 1 |
| 16 | 15 | 14 | 11 | 10 | 9 | 8 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | W | - |
| 4 | B | - |
| 5 | BR | - |
| 6 | BR | - |
| 7 | G | - |
| 8 | R | - |
| 9 | R | - |

JRKWC6505GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

DOOR LOCK SYSTEM

| | | |
|----|----|---|
| 10 | Y | - |
| 11 | L | - |
| 14 | GR | - |
| 15 | GR | - |
| 16 | P | - |

| | |
|----------------|--------------|
| Connector No. | D114 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16AW-CS |



| | | | | | | |
|---|---|----|----|----|----|----|
| 1 | 2 | 4 | 5 | 6 | 7 | |
| 8 | 9 | 10 | 11 | 14 | 15 | 16 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | W | - |
| 4 | B | - |
| 5 | BR | - |
| 6 | BR | - |
| 7 | G | - |
| 8 | R | - |
| 9 | R | - |
| 10 | Y | - |
| 11 | Y | - |
| 14 | GR | - |
| 15 | GR | - |
| 16 | P | - |

| | |
|----------------|--------------|
| Connector No. | D152 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24FW-NH |



| | | | | | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SB | - |
| 2 | B | - |
| 3 | P | - |
| 4 | V | - |
| 5 | Y | - |
| 6 | LG | - |
| 9 | SHIELD | - |
| 10 | W | - |
| 11 | R | - |
| 12 | B | - |
| 13 | R | - |
| 14 | G | - |
| 15 | P | - |
| 16 | O | - |
| 17 | L | - |
| 18 | GR | - |
| 19 | BR | - |
| 20 | O | - |
| 21 | Y | - |
| 22 | W | - |
| 23 | W | - |
| 24 | Y | - |

| | |
|----------------|--------------|
| Connector No. | D158 |
| Connector Name | WIRE TO WIRE |
| Connector Type | M66MW-LC |



| | | |
|---|---|---|
| 1 | 2 | 3 |
| 4 | 5 | 6 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | B/W | - [Without automatic back door] |
| 2 | V | - [With automatic back door] |
| 3 | B | - |
| 4 | V | - |
| 5 | R | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | D159 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16FW-NH |



| | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SB | - |
| 2 | B | - |
| 3 | P | - |
| 4 | V | - |
| 5 | Y | - |
| 9 | R | - |
| 10 | P | - |
| 11 | O | - |
| 12 | L | - |
| 13 | GR | - |
| 14 | O | - |
| 15 | LG | - |
| 16 | V | - |

| | |
|----------------|------------------------|
| Connector No. | D181 |
| Connector Name | BACK DOOR CONTROL UNIT |
| Connector Type | NS16PW-CS |



| | | | | | |
|---|---|---|---|---|----|
| 1 | 2 | 3 | 4 | | |
| 5 | 6 | 7 | 8 | 9 | 10 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L | CLOSE |
| 2 | GR | HARF |
| 3 | G | 4B |
| 4 | V | CLOSE |
| 5 | O | OPEN |
| 6 | BR | OPEN SW |
| 7 | B | DR LOCK STATUS |
| 8 | B/W | EARTH |
| 10 | G | OPEN |

| | |
|----------------|----------------------------------|
| Connector No. | D188 |
| Connector Name | BACK DOOR OPENER SWITCH ASSEMBLY |
| Connector Type | TH6MMF-NH |



| | | | |
|---|---|---|---|
| 1 | 2 | 3 | 4 |
|---|---|---|---|

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | B | - |
| 3 | B | - |
| 4 | V | - |

JRKWC6506GB


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

DOOR LOCK SYSTEM

| | |
|----------------|--------------|
| Connector No. | D188 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH188MP-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SB | - |
| 2 | B | - |
| 3 | Y | - |
| 4 | BR | - |
| 5 | BR | - |
| 9 | R | - |
| 10 | P | - |
| 11 | O | - |
| 12 | L | - |
| 13 | GR | - |
| 14 | P | - |
| 15 | LG | - |
| 16 | V | - |

| | |
|----------------|-------------------------|
| Connector No. | D180 |
| Connector Name | BACK DOOR LOCK ASSEMBLY |
| Connector Type | NS08PW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | V | - |
| 4 | O | - |
| 5 | L | - |
| 6 | GR | - |
| 7 | P | - |
| 8 | B | - |

| | |
|----------------|------------------|
| Connector No. | E5 |
| Connector Name | HORN RELAY |
| Connector Type | Relay 24381795DA |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | SB | - |
| 3 | P | - |

| | |
|----------------|--------------|
| Connector No. | E5 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS12MBR-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P | - |
| 2 | W | - |
| 3 | V | - |
| 4 | BR | - |
| 5 | LG | - |
| 6 | O | - |
| 7 | G | - |
| 8 | Y | - |
| 9 | SB | - |
| 10 | GR | - |
| 11 | L | - |
| 12 | R | - |

| | |
|----------------|---|
| Connector No. | E11 |
| Connector Name | INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM |
| Connector Type | TH08FH-NH |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 39 | P | - |
| 40 | L | - |
| 41 | B | - |
| 42 | SB | - |
| 43 | LG | - |
| 44 | W | - |
| 45 | Y | - |
| 46 | O | - |

| | |
|----------------|--------------------------------|
| Connector No. | E28 |
| Connector Name | INTELLIGENT KEY WARNING BUZZER |
| Connector Type | PK03FBR |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 3 | GR | - |

| | |
|----------------|------------------|
| Connector No. | E103 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS18PW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 11F | G | - |
| 12F | V | - |
| 1F | SB | - |
| 2F | R | - |
| 4F | L | - |
| 6F | LG | - |
| 8F | P | - |
| 9F | BR | - |

| | |
|----------------|-------------------|
| Connector No. | E105 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH120MW-CS (P-M3) |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SHIELD | - |
| 2 | W | - |
| 3 | B | - |
| 4 | R | - |
| 6 | LG | - |
| 7 | R | - |
| 8 | GR | - |
| 9 | SB | - |
| 10 | BR | - |
| 11 | Y | - |
| 12 | O | - |
| 13 | W | - |

JRKWC6507GB


DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

DOOR LOCK SYSTEM

| | | | |
|----|--------|----|--|
| 14 | L | -- | |
| 15 | P | -- | |
| 31 | GR | -- | |
| 32 | R | -- | |
| 33 | BR | -- | |
| 34 | G | -- | |
| 38 | P | -- | |
| 40 | P | -- | |
| 41 | L | -- | |
| 42 | LG | -- | |
| 43 | O | -- | |
| 45 | GR | -- | |
| 46 | SB | -- | |
| 47 | V | -- | |
| 49 | L | -- | |
| 51 | BR | -- | |
| 52 | G | -- | |
| 53 | B | -- | |
| 54 | O | -- | |
| 55 | Y | -- | |
| 56 | SHIELD | -- | |
| 61 | P | -- | |
| 62 | G | -- | |
| 63 | W/L | -- | |
| 64 | W/R | -- | |
| 66 | W | -- | |
| 67 | Y | -- | |
| 68 | SB | -- | |
| 70 | LG | -- | |
| 71 | R | -- | |
| 72 | GR | -- | |
| 74 | Y | -- | |
| 75 | SB | -- | |
| 76 | G | -- | |
| 77 | O | -- | |
| 78 | O | -- | |
| 80 | R | -- | |
| 81 | L | -- | |
| 82 | LG | -- | |
| 83 | R | -- | |

| | |
|----------------|--------------|
| Connector No. | E539 |
| Connector Name | WIRE TO WIRE |
| Connector Type | HS1ZFBR-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | -- |
| 2 | O | -- |
| 3 | V | -- |
| 4 | R | -- |
| 5 | L | -- |
| 6 | BR | -- |
| 7 | P | -- |
| 8 | Y | -- |
| 9 | SB | -- |
| 10 | GR | -- |
| 11 | Y | -- |
| 12 | G | -- |

| | |
|----------------|-------------|
| Connector No. | E541 |
| Connector Name | HORN (HIGH) |
| Connector Type | P01FE-A |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | -- |

| | |
|----------------|------------|
| Connector No. | E543 |
| Connector Name | HORN (LOW) |
| Connector Type | P01FE-A |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | -- |

| | |
|----------------|-----------------------------------|
| Connector No. | F23 |
| Connector Name | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Type | RH40FB-FZ8-L-RH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------------|
| 1 | P/B | TRANSMISSION RANGE SWITCH 2 |
| 2 | R/B | TRANSMISSION RANGE SWITCH 2 |
| 3 | G/O | TRANSMISSION RANGE SWITCH 2 |
| 4 | GR | TRANSMISSION RANGE SWITCH 3 (MONITOR) |
| 5 | B | GROUND |
| 7 | W | SENSOR GROUND |
| 8 | G/W | ROM ASSY (SEL 2) |
| 9 | L/R | ROM ASSY (SEL 1) |
| 10 | BR/R | ROM ASSY (SEL 3) |
| 11 | BR/W | TRANSMISSION RANGE SWITCH 1 |
| 13 | V | CVT FLUID TEMPERATURE SENSOR |
| 14 | R/W | PRIMARY PRESSURE SENSOR |
| 15 | V/W | SECONDARY PRESSURE SENSOR |
| 19 | G/B | BACK-UP LAMP RELAY |
| 20 | R/B | STARTER RELAY |
| 25 | W/R | SENSOR GROUND |
| 26 | L/O | SENSOR POWER |
| 27 | R/G | STEP MOTOR D |
| 28 | R | STEP MOTOR C |

| | | |
|----|-----|--|
| 29 | O/B | STEP MOTOR B |
| 30 | G/R | STEP MOTOR A |
| 31 | P | CAN-L |
| 32 | L/G | CAN-H |
| 33 | L/G | PRIMARY SENSOR |
| 37 | L/R | SECONDARY SENSOR |
| 38 | L/W | LOCK-UP SELECT SOLENOID VALVE |
| 39 | L/W | TORQUE CONVERTER CLUTCH SOLENOID VALVE |
| 40 | R/W | SECONDARY PRESSURE SOLENOID VALVE |
| 42 | B | GROUND |
| 46 | Y | IGNITION POWER SUPPLY |
| 47 | L/R | BATTERY POWER SUPPLY (MEMORY BACK-UP) |
| 48 | Y | IGNITION POWER SUPPLY |

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS06FW-M2 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 7A | P | -- |
| 8A | G | -- |
| 2A | -- | -- |
| 4A | GR | -- |
| 5A | Y | -- |
| 6A | R | -- |
| 7A | GR | -- |
| 8A | L | -- |

JRKWC6508GB


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >


DOOR LOCK SYSTEM

| | |
|----------------|------------------|
| Connector No. | M2 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS12PW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10B | R | - |
| 3B | V | - |
| 4B | W | - |
| 5B | BR | - |
| 6B | O | - |
| 8B | R/L | - |
| 9B | GR | - |

| | |
|----------------|------------------|
| Connector No. | M3 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS12PW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10C | LG | - |
| 11C | V | - |
| 12C | Y | - |
| 8C | GR | - |
| 7C | B/R | - |
| 8C | G | - |
| 9C | Y | - |

| | |
|----------------|---------------------|
| Connector No. | M4 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD18PW |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | LG | - |
| 4 | B/R | - |
| 5 | B/R | - |
| 6 | L | SB |
| 7 | R | - |
| 8 | G | - |
| 11 | SB | - |
| 14 | P | - |
| 15 | O | - |

| | |
|----------------|----------------|
| Connector No. | M11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH10PW-CS10-M3 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SHIELD | - |
| 2 | W | - |
| 3 | B | - |
| 4 | R | - |
| 6 | O | - |
| 7 | G | - |
| 8 | G | - |
| 9 | B | - |
| 10 | R | - |
| 11 | W | - |
| 12 | LG | - |

| | |
|----------------|--------------|
| Connector No. | M18 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH14GMW-CS15 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B/W | - |
| 2 | R | - |
| 3 | W | - |
| 4 | Y | - |
| 5 | SB | - |
| 6 | BR | - |
| 7 | LG | - |
| 8 | L | - |
| 9 | GR | - |
| 10 | P | - |
| 11 | V | - |
| 12 | G | - |
| 13 | O | - |
| 14 | BR | - |
| 15 | G | - |
| 16 | R | - |
| 17 | SB | - |
| 18 | P | - |
| 19 | Y | - |
| 20 | Y | - |
| 21 | W | - |
| 22 | G | - |
| 23 | R | - |
| 24 | B | - |
| 25 | W | - |
| 26 | SHIELD | - |
| 27 | GR | - |
| 28 | G | - |
| 29 | O | - |
| 30 | LG | - |
| 31 | R | - |
| 32 | G | - |
| 33 | Y | - |
| 34 | R/W | - |
| 35 | GR | - |

| | | |
|----|--------|----|
| 13 | Y | - |
| 14 | L | - |
| 15 | R | - |
| 16 | V | - |
| 17 | Y | - |
| 18 | BR | - |
| 19 | BR | - |
| 20 | Y | - |
| 21 | P | - |
| 22 | L | - |
| 23 | G | - |
| 24 | W | - |
| 25 | LG | - |
| 26 | W/R | - |
| 27 | O | - |
| 28 | SB | - |
| 29 | R | - |
| 30 | L | - |
| 31 | T | - |
| 32 | R | - |
| 33 | Y | - |
| 34 | Y | - |
| 35 | G | - |
| 36 | V | - |
| 37 | P | - |
| 38 | W | - |
| 39 | Y | - |
| 40 | W | - |
| 41 | L | - |
| 42 | G | - |
| 43 | W | - |
| 44 | LG | - |
| 45 | LG | - |
| 46 | V | - |
| 47 | LG | - |
| 48 | G | - |
| 49 | G | - |
| 50 | L | SB |
| 51 | SB | - |
| 52 | GR | - |
| 53 | B | - |
| 54 | R | - |
| 55 | L | - |
| 56 | SHIELD | - |
| 61 | BR | - |
| 62 | LG | - |
| 63 | W/L | - |
| 64 | W/R | - |
| 65 | O | - |
| 66 | SB | - |
| 67 | SB | - |
| 68 | R | - |
| 69 | L | - |
| 70 | R | - |
| 71 | T | - |
| 72 | R | - |
| 73 | R | - |
| 74 | Y | - |
| 75 | G | - |
| 76 | V | - |
| 77 | P | - |
| 78 | W | - |
| 79 | Y | - |
| 80 | Y | - |
| 81 | W | - |
| 82 | L | - |
| 83 | R | - |

JRKWC6509GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

DOOR LOCK SYSTEM

| | | |
|----|--------|---|
| 36 | LG | -- |
| 37 | W | -- |
| 38 | P | -- |
| 39 | Y | -- |
| 40 | BR | -- |
| 41 | W | -- |
| 42 | V | -- |
| 43 | SB | -- |
| 44 | B | -- |
| 45 | W/L | -- (With automatic drive positioner) |
| 46 | GR/V | -- (Without automatic drive positioner) |
| 47 | W | -- (With automatic drive positioner) |
| 48 | B/P | -- |
| 49 | R/W | -- (With automatic drive positioner) |
| 50 | V | -- (Without automatic drive positioner) |
| 51 | LG | -- |
| 52 | W | -- |
| 53 | SHIELD | -- (With automatic drive positioner) |
| 54 | L/R | -- |
| 55 | L/G | -- |

| | |
|----------------|--------------|
| Connector No. | M20 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH40MM-C515 |



| | | | | | | | | |
|----|----|----|----|----|----|----|----|----|
| 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 |
| 16 | 17 | 18 | 19 | 20 | 21 | 22 | 23 | 24 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---|
| 7 | B/W | -- |
| 8 | L | -- (Without passenger power window anti-pinch system) |
| 9 | BR | -- (With front power window anti-pinch system) |
| 10 | GR | -- (Without passenger power window anti-pinch system) |
| 11 | SB | -- (With front power window anti-pinch system) |
| 12 | V | -- |
| 14 | B | -- |
| 15 | W | -- |
| 16 | BR | -- |

| | | |
|----|--------|----|
| 17 | P | -- |
| 18 | R | -- |
| 19 | Y | -- |
| 20 | BR | -- |
| 21 | W | -- |
| 22 | W | -- |
| 23 | W | -- |
| 24 | SHIELD | -- |
| 25 | W/L | -- |
| 26 | W/R | -- |
| 27 | LG | -- |
| 28 | W | -- |
| 29 | P | -- |
| 30 | G | -- |
| 31 | R | -- |
| 32 | L | -- |
| 33 | GR | -- |
| 34 | BR | -- |
| 35 | GR | -- |
| 36 | V | -- |
| 37 | BR | -- |
| 38 | LG | -- |
| 39 | W | -- |
| 40 | B | -- |
| 41 | R | -- |
| 42 | L | -- |
| 43 | GR | -- |
| 44 | GR | -- |
| 45 | GR | -- |
| 46 | GR | -- |
| 47 | V | -- |
| 48 | BR | -- |
| 49 | LG | -- |
| 50 | W | -- |
| 51 | LG | -- |
| 52 | W | -- |
| 53 | SHIELD | -- |
| 54 | B/Y | -- |
| 55 | LG | -- |

| | |
|----------------|--------------|
| Connector No. | M22 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16FN-NH |



| | | | | | | | |
|----|----|----|----|----|----|----|---|
| 8 | 7 | 6 | 4 | 3 | 2 | 1 | |
| 16 | 15 | 14 | 13 | 12 | 11 | 10 | 9 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | BR | -- |
| 2 | SB | -- |
| 3 | G/W | -- |
| 4 | O | -- |
| 6 | R | -- |
| 7 | SB | -- |
| 8 | GR | -- |
| 9 | P | -- |

| | | |
|----|--------|----|
| 10 | R | -- |
| 11 | B/W | -- |
| 12 | B | -- |
| 13 | R | -- |
| 14 | W | -- |
| 15 | SHIELD | -- |
| 16 | BR | -- |
| 17 | W/R | -- |

| | |
|----------------|--------------|
| Connector No. | M28 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FY-C5 |



| | | | | | | | |
|----|----|----|----|----|----|---|---|
| 7 | 5 | 4 | 3 | 2 | 1 | | |
| 16 | 15 | 14 | 12 | 11 | 10 | 9 | 8 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P | -- |
| 2 | Y | -- |
| 3 | BR | -- |
| 4 | SB | -- |
| 5 | R | -- |
| 6 | BR | -- |
| 7 | BR | -- |
| 8 | L | -- |
| 9 | B | -- |
| 10 | W | -- |
| 11 | G | -- |
| 12 | V | -- |
| 14 | V | -- |
| 15 | LG | -- |
| 16 | Y | -- |

| | |
|----------------|-------------------|
| Connector No. | M34 |
| Connector Name | COMBINATION METER |
| Connector Type | TH46FN-NH |



| | | | | | | | | | | | | | | | | | | | |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
|---|---|---|---|---|---|---|---|---|----|----|----|----|----|----|----|----|----|----|----|

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---|
| 1 | O | BATTERY POWER SUPPLY |
| 2 | Y | IGNITION SIGNAL |
| 3 | B | GROUND |
| 4 | B | GROUND |
| 5 | B/P | ILLUMINATION CONTROL SIGNAL |
| 8 | SB | TRIP RESET SWITCH SIGNAL |
| 10 | P | METER CONTROL SWITCH GROUND |
| 11 | G | ENTER SWITCH SIGNAL |
| 12 | BR | SELECT SWITCH SIGNAL |
| 13 | Y | ILLUMINATION CONTROL SWITCH SIGNAL (+) |
| 14 | V | ILLUMINATION CONTROL SWITCH SIGNAL (-) |
| 15 | BR | AIR BAG SIGNAL |
| 16 | L | ENGINE COOLANT TEMPERATURE SIGNAL |
| 18 | LG | AMBIENT SENSOR SIGNAL |
| 19 | R | A/G AUTO AMP CONNECTION REGULATION SIGNAL |
| 20 | Y | AMBIENT SENSOR GROUND |
| 21 | L | CAN-H |
| 22 | P | GROUND |
| 23 | B | FUEL LEVEL SENSOR GROUND |
| 24 | BR | ALTERNATOR SIGNAL |
| 25 | BR | PARKING BRAKE SWITCH SIGNAL |
| 26 | BR | BRAKE FLUID LEVEL SWITCH SIGNAL |
| 27 | Y | SECURITY SIGNAL |
| 28 | V | WASHER LEVEL SWITCH SIGNAL |
| 29 | G | VEHICLE SPEED SIGNAL (8-PULSE) |
| 31 | SB | OVERDRIVE CONTROL SWITCH SIGNAL |
| 32 | P | FUEL LEVEL SENSOR SIGNAL |
| 34 | O | SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE) |
| 35 | P | SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE) |
| 36 | BR | PASSENGER SEAT BELT WARNING SIGNAL |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P


DLK

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >


DOOR LOCK SYSTEM

| | |
|----------------|--------------|
| Connector No. | M38 |
| Connector Name | WIRE TO WIRE |
| Connector Type | MS16PW-CS |





| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|----------------------------------|
| 8 | P | - |
| 9 | B | - |
| 10 | L | - |
| 11 | Y | - |
| 12 | SB | - |
| 13 | G | - [Without automatic slide door] |
| 14 | V | - [With automatic slide door] |
| 15 | P | - |

| | |
|----------------|-----------------|
| Connector No. | M39 |
| Connector Name | CIRCUIT BREAKER |
| Connector Type | M02PW-P-LC |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | W | - |

| | |
|----------------|--------------|
| Connector No. | M77 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80PW-CS19 |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 10 | GR | - |
| 12 | V | - |
| 13 | W | - |
| 15 | Y | - |
| 29 | L | - |
| 30 | P | - |
| 31 | BR | - |
| 37 | SHIELD | - |
| 38 | B | - [Without automatic drive positioner] |
| 38 | W | - [With automatic drive positioner] |
| 39 | B | - [Without automatic drive positioner] |
| 39 | W | - [With automatic drive positioner] |
| 40 | R | - |
| 51 | V | - |
| 52 | B | - |
| 53 | O | - |
| 54 | T | - |
| 55 | L | - |
| 57 | Y | - |
| 58 | L | - |
| 59 | O | - |
| 60 | G | - |
| 61 | LG | - |
| 62 | V | - |
| 63 | SB | - |
| 64 | R | - |
| 65 | G | - |
| 66 | SHIELD | - |
| 67 | W/L | - |
| 68 | GR/V | - |
| 69 | SHIELD | - |
| 70 | W/L | - |
| 71 | W/R | - |
| 72 | LG | - |
| 74 | GR | - |
| 75 | G | - |


| | | |
|----|----|--|
| 77 | O | - |
| 78 | LG | - |
| 79 | R | - |
| 81 | O | - |
| 82 | W | - |
| 87 | V | - |
| 88 | R | - |
| 89 | Y | - |
| 90 | P | - [Without automatic drive positioner] |
| 90 | R | - [With automatic drive positioner] |
| 91 | SB | - |
| 92 | P | - |

| | |
|----------------|--------------|
| Connector No. | M79 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16PW-NH |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | W | - |
| 3 | B | - |
| 5 | B | - |
| 5 | BR | - |
| 9 | BL | - |
| 10 | P | - |
| 11 | SB | - |
| 12 | R | - |
| 13 | V | - |
| 14 | L | - |
| 15 | G | - |
| 16 | GR | - |

| | |
|----------------|------------------------|
| Connector No. | M91 |
| Connector Name | SELECTIVE UNLOCK RELAY |
| Connector Type | MS02PW-ME-LC |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | - |
| 2 | V | - |
| 3 | W | - |
| 4 | B | - |
| 5 | O | - |

| | |
|----------------|-----------------------------|
| Connector No. | M101 |
| Connector Name | PUSH-BUTTON IGNITION SWITCH |
| Connector Type | TK08FBR |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B/W | - |
| 2 | G | - |
| 3 | P | - |
| 4 | V | - |
| 5 | SB | - |
| 6 | GR | - |
| 7 | Y | - |
| 8 | O | - |

JRKWC6511GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

DOOR LOCK SYSTEM

| | |
|----------------|--|
| Connector No. | RM05 |
| Connector Name | INSIDE KEY ANTENNA (INSTRUMENT CENTER) |
| Connector Type | FRK02FL |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | BR | - |

| | |
|----------------|---------------------------|
| Connector No. | M12L |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 1 | W | REAR WINDOW DEF RELAY CONT |
| 2 | LG | COMBI SW INPUT 2 |
| 3 | Y | COMBI SW INPUT 2 |
| 4 | O | COMBI SW INPUT 3 |
| 5 | G | COMBI SW INPUT 2 |
| 6 | L | COMBI SW INPUT 1 |
| 7 | W | KEY C/L UNLOCK SW |
| 8 | GR | PW SW COMM (With automatic sliding door) |
| 9 | Y | KEY C/L LOCK SW (Without automatic sliding door) |
| 12 | GR | STOP LAMP SW 1 |
| 13 | BR | DOOR LK & UNLK SW LOCK |
| 14 | L | DOOR LK & UNLK SW UNLOCK |
| 15 | W | OPTICAL SENS |
| 16 | Y | REAR WINDOW DEF SW DIMMER |
| 17 | O | SENS PWR SPLY |
| 18 | R | RECEIV/SENS GND |
| 21 | R | NATS ANT AMP |


| | | |
|----|----|-------------------|
| 23 | V | SECURITY IND CONT |
| 24 | B | DOUBLE LINK |
| 25 | W | NATS ANT AMP |
| 27 | GR | ECU ON ON |
| 28 | SP | BLUETOOTH SW |
| 29 | L | PK DOOR OPEN SW |
| 30 | Y | PK DOOR OPEN SW |
| 31 | O | DR DOOR UNLK SENS |
| 32 | Y | COMBI SW OUTPUT 5 |
| 33 | W | COMBI SW OUTPUT 4 |
| 34 | GR | COMBI SW OUTPUT 3 |
| 35 | SB | COMBI SW OUTPUT 2 |
| 36 | R | COMBI SW OUTPUT 1 |
| 37 | G | DETECT SW |
| 38 | SB | RECEIVER COMM |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|----------------|---------------------------|
| Connector No. | M122 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | FEA0FB-FHA6-SA |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 43 | P | BK DOOR SW |
| 44 | Y | REAR WIPER STOP POSITION |
| 45 | SB | PASS DOOR SW |
| 46 | R | SL DOOR RH SW |
| 47 | G | DR DOOR SW |
| 48 | O | SL DOOR LH SW |
| 49 | B | LUGGAGE LAMP CONT |
| 50 | V | SELECT UNLK RELAY CONT |
| 51 | LG | BACK DOOR REQ SW |
| 53 | BR | BK DOOR OPEN |
| 54 | R | REAR WIPER OUTPUT |
| 55 | G | SL DOOR LH UNLK CONT |

| | |
|----------------|---------------------------|
| Connector No. | M123 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | FEA0FW-FHA6-SA |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 56 | P | INT ROOM LAMP PWR SPLY |
| 57 | GR | BAT |
| 58 | O | AIR BAG |
| 59 | SB | PASS DOOR UNLK OUTPUT |
| 60 | V | TURN SIG LH OUTPUT |
| 61 | G | TURN SIG RH OUTPUT |
| 62 | W | STEP LAMP CONT |
| 63 | R | INT ROOM LAMP CONT |
| 64 | LG | CRANK REQ |
| 65 | V | ALL DOOR LOCK OUTPUT |
| 66 | G | DR DOOR UNLK OUTPUT |
| 67 | B | GROUND |
| 68 | L | PW PWR SPLY (IGN) |
| 69 | P | PW PWR SPLY (BAT) |
| 70 | L | BAT |


| | |
|----------------|---------------------------|
| Connector No. | M124 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 73 | Y | ON IND |
| 75 | SB | DR DOOR REQ SW |
| 76 | V | PUSH SW |
| 78 | P | DR DOOR ANT+ |
| 79 | V | DR DOOR ANT- |

| | | |
|-----|----|------------------------------|
| 80 | R | PASS DOOR ANT+ |
| 81 | L | PASS DOOR ANT- |
| 82 | G | REAR BMR ANT+ |
| 83 | R | REAR BMR ANT- |
| 84 | Y | ROOM ANT+ |
| 85 | BR | ROOM ANT- |
| 86 | LG | ROOM ANT2+ |
| 87 | Y | ROOM ANT2- |
| 88 | W | LUGGAGE ROOM ANT+ |
| 89 | B | LUGGAGE ROOM ANT- |
| 90 | P | PUSH-BTN IGN SW ILL PWR SPLY |
| 91 | SB | LOCK IND |
| 92 | G | PUSH-BTN IGN SW ILL GND |
| 93 | R | F-KEY WARM BUZZER |
| 96 | BR | ACC RELAY CONT OUTPUT |
| 97 | W | STARTER RELAY CONT |
| 98 | LG | IGN RELAY (FDM E/R) CONT |
| 99 | GR | IGN RELAY (F-B) CONT OUTPUT |
| 100 | GR | PASS DOOR REQ SW |
| 101 | BR | IGN PWR SPLY 2 |
| 102 | Y | P/N POSITION |
| 104 | L | CVT SHIFT SELECT PWR SPLY |
| 105 | GR | STOP LAMP SW 2 |
| 106 | O | BLWR RELAY CONT OUTPUT |
| 109 | GR | ACC IND |

| | |
|----------------|--------------|
| Connector No. | RM06 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16BMF-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | SB | - |
| 3 | P | - |
| 4 | LG | - |
| 6 | O | - |
| 7 | W | - |
| 8 | BR | - |
| 9 | L | - |
| 10 | LG | - |

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

JRKWC6512GB

DOOR & LOCK SYSTEM

< WIRING DIAGRAM >

DOOR LOCK SYSTEM

| | | |
|---|--------|---|
| 1 | B | - |
| 2 | Y | - |
| 3 | Y | - |
| 4 | Y | - |
| 5 | SHIELD | - |
| 6 | BR | - |

| | |
|----------------|-------------------------------|
| Connector No. | R1108 |
| Connector Name | REMOTE KEYLESS ENTRY RECEIVER |
| Connector Type | TH04FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | BR | BAT |
| 2 | W | SIGNAL |
| 4 | O | GROUND |

JRKWC6513GB


AUTOMATIC BACK DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC BACK DOOR SYSTEM

Wiring Diagram

INFOID:000000009649033



2013/07/10


JRWKC6524GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

AUTOMATIC BACK DOOR SYSTEM

< WIRING DIAGRAM >




JRKWC6525GB

AUTOMATIC BACK DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC BACK DOOR SYSTEM

| | |
|----------------|------------------|
| Connector No. | 56 |
| Connector Name | FUSE BLOCK (A/B) |
| Connector Type | MS12FER-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10 | Y | -- |
| 11 | Y | -- |
| 12 | W | -- |
| 13 | W | -- |
| 14 | W | -- |
| 15 | SB | -- |
| 16 | L | -- |


| | |
|----------------|------------------------------------|
| Connector No. | 88 |
| Connector Name | AUTOMATIC BACK DOOR CONTROL MODULE |
| Connector Type | TH20FW-TB8 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SB | 4B |
| 2 | R | LATCH MTR CLOSE |
| 3 | G | LATCH MTR OPEN |
| 4 | O | INSIDE CLOSE SW |
| 5 | GR | BUZZER |
| 6 | B/R | MAN-FUNC-FLG |
| 7 | W | IGN |
| 8 | B/R | GROUND |
| 9 | B/R | GROUND |
| 10 | B/R | GROUND |
| 11 | B/R | GROUND |
| 12 | B/R | GROUND |
| 13 | LG | TOUCH-SENS RH |
| 14 | P | TOUCH-SENS LH |
| 15 | BR | TOUCH-SENS LH |
| 16 | L | DRIVER SW |

| | | |
|----|---|---------------|
| 17 | Y | MAIN SW |
| 18 | G | RELAY SW |
| 19 | W | HALT LATCH SW |
| 20 | W | HALT LATCH SW |
| 21 | G | OPEN SW |
| 22 | G | OPEN SW |
| 23 | P | CAN-H |
| 24 | P | CAN-H |
| 25 | L | CAN-H |
| 26 | L | CAN-H |

| | |
|----------------|--------------|
| Connector No. | B11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH18MW-CS19 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10 | LG | -- |
| 12 | Y | -- |
| 13 | P | -- |
| 15 | L | -- |
| 29 | GR | -- |
| 30 | W | -- |
| 31 | BR | -- |
| 32 | SHIELD | -- |
| 33 | LG | -- |
| 34 | LG | -- |
| 35 | LG | -- |
| 36 | LG | -- |
| 37 | LG | -- |
| 38 | LG | -- |
| 39 | LG | -- |
| 40 | R/W | -- |
| 51 | O | -- |
| 52 | B/P | -- |
| 53 | V | -- |
| 54 | P | -- |
| 55 | L | -- |
| 57 | Y | -- |
| 58 | L | -- |
| 59 | V | -- |
| 60 | O | -- |
| 61 | W | -- |
| 62 | Y | -- |
| 63 | Y | -- |
| 64 | W | -- |
| 65 | R | -- |
| 66 | SHIELD | -- |
| 67 | B | -- |


| | | |
|----|--------|----|
| 58 | W | -- |
| 59 | SHIELD | -- |
| 60 | W | -- |
| 61 | B/R | -- |
| 62 | P | -- |
| 63 | P | -- |
| 64 | BR | -- |
| 65 | SB | -- |
| 66 | V | -- |
| 67 | V | -- |
| 68 | LG | -- |
| 69 | W | -- |
| 70 | R | -- |
| 81 | SB | -- |
| 82 | V | -- |
| 87 | BR | -- |
| 88 | P | -- |
| 89 | EG | -- |
| 90 | EG | -- |
| 91 | P | -- |
| 92 | O | -- |
| 93 | G | -- |

| | |
|----------------|--------------|
| Connector No. | B20 |
| Connector Name | WIRE TO WIRE |
| Connector Type | M08MW-LC |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | -- |
| 1 | V | -- |
| 2 | B | -- |
| 3 | B | -- |
| 3 | R | -- |
| 4 | Y | -- |
| 5 | P | -- |
| 6 | B | -- |

| | |
|----------------|--------------|
| Connector No. | B28 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | -- |
| 2 | W | -- |
| 3 | B/R | -- |
| 4 | SHIELD | -- |
| 5 | B/W | -- |
| 6 | L | -- |
| 7 | Y | -- |
| 8 | B/W | -- |
| 9 | R | -- |
| 10 | W | -- |
| 11 | GR | -- |
| 12 | LG | -- |

| | |
|----------------|--------------|
| Connector No. | B32 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH24MW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | BR | -- |
| 2 | BR | -- |
| 3 | SB | -- |
| 4 | L | -- |
| 5 | O | -- |
| 6 | SB | -- |
| 9 | SHIELD | -- |

A
B
C
D
E
F
G
H
I
J
DLK

L
M
N
O
P

JRKWC6526GB


AUTOMATIC BACK DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC BACK DOOR SYSTEM

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10 | B/L | - |
| 11 | B | - |
| 12 | B/W | - |
| 13 | GR | - |
| 14 | O | - |
| 15 | W | - |
| 16 | G | - |
| 17 | R | - |
| 18 | W | - |
| 19 | BR | - |
| 20 | P | - |
| 21 | LG | - |
| 22 | BR | - |
| 23 | Y | - |
| 24 | P | - |

| | |
|----------------|------------------------------------|
| Connector No. | B305 |
| Connector Name | AUTOMATIC BACK DOOR WARNING BUZZER |
| Connector Type | RK0ZFBR |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | - |
| 2 | P | - |

| | |
|----------------|--------------|
| Connector No. | B310 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16MW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | - |
| 2 | B | - |
| 3 | W | - |
| 4 | SHIELD | - |
| 5 | B | - |
| 6 | L | - |
| 7 | Y | - |
| 8 | B | - |
| 9 | R | - |
| 10 | W | - |
| 11 | P | - |
| 12 | LG | - |

| | |
|----------------|--------------|
| Connector No. | D81 |
| Connector Name | WIRE TO WIRE |
| Connector Type | M08FW-LC |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | G | - [With automatic back door] |
| 1 | W | - [Without automatic back door] |
| 2 | B | - [With automatic back door] |
| 2 | B/W | - [Without automatic back door] |
| 3 | V | - [With automatic back door] |
| 4 | Y | - [Without automatic back door] |
| 5 | R | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | D292 |
| Connector Name | WIRE TO WIRE |
| Connector Type | M08FW-LC |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | B/Y | - [With automatic back door] |
| 2 | B | - [Without automatic back door] |
| 3 | G | - [With automatic back door] |
| 3 | W | - [Without automatic back door] |
| 5 | R | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | D152 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH12EV-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SB | - |
| 2 | B | - |
| 3 | P | - |
| 4 | V | - |
| 5 | L | - |
| 9 | SHIELD | - |
| 10 | W | - |
| 11 | R | - |
| 12 | B | - |
| 13 | R | - |
| 14 | G | - |
| 15 | P | - |

| | | |
|----|----|---|
| 16 | O | - |
| 17 | L | - |
| 18 | GR | - |
| 19 | BR | - |
| 20 | O | - |
| 21 | LG | - |
| 22 | V | - |
| 23 | W | - |
| 24 | V | - |

| | |
|----------------|--------------|
| Connector No. | D159 |
| Connector Name | WIRE TO WIRE |
| Connector Type | M08FW-LC |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | B/W | - [Without automatic back door] |
| 1 | V | - [With automatic back door] |
| 2 | B | - |
| 3 | G | - |
| 5 | R | - |
| 6 | B | - |

| | |
|----------------|--------------|
| Connector No. | D159 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SB | - |
| 2 | B | - |
| 3 | P | - |

AUTOMATIC BACK DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC BACK DOOR SYSTEM

| | | |
|----------------|---------------------------|-----------------------------|
| Connector No. | D185 | |
| Connector Name | BACK DOOR TOUCH SENSOR LH | |
| Connector Type | T062MM | |
| Terminal No. | Wire | Signal Name [Specification] |
| 1 | BR | - |
| 2 | O | - |
| 3 | W | - |
| 4 | LG | - |

| | |
|----------------|---------------------------|
| Connector No. | D185 |
| Connector Name | BACK DOOR TOUCH SENSOR LH |
| Connector Type | T062MM |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color Of Wire | Signal Name [Specification] |
| 1 | BR | - |
| 2 | O | - |
| 3 | W | - |
| 4 | LG | - |

| | |
|----------------|--------------|
| Connector No. | D188 |
| Connector Name | WIRE TO WIRE |
| Connector Type | T181MW-NH |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color Of Wire | Signal Name [Specification] |
| 1 | SB | - |
| 2 | B | - |
| 3 | Y | - |
| 4 | BR | - |
| 5 | BR | - |
| 9 | R | - |
| 10 | P | - |
| 11 | O | - |
| 12 | GR | - |
| 14 | W | - |
| 15 | LG | - |
| 16 | V | - |

| | |
|----------------|----------------------------------|
| Connector No. | D186 |
| Connector Name | BACK DOOR OPENER SWITCH ASSEMBLY |
| Connector Type | T181MW-NH |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color Of Wire | Signal Name [Specification] |
| 1 | R | - |
| 2 | B | - |
| 3 | V | - |
| 4 | V | - |

| | |
|----------------|--------------|
| Connector No. | D188 |
| Connector Name | WIRE TO WIRE |
| Connector Type | T181MW-NH |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color Of Wire | Signal Name [Specification] |
| 1 | SB | - |
| 2 | B | - |
| 3 | Y | - |
| 4 | BR | - |
| 5 | BR | - |
| 9 | R | - |
| 10 | P | - |
| 11 | O | - |
| 12 | GR | - |
| 14 | W | - |
| 15 | LG | - |
| 16 | V | - |

| | |
|----------------|-------------------------|
| Connector No. | D180 |
| Connector Name | BACK DOOR LOCK ASSEMBLY |
| Connector Type | RS08PW-CS |




| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color Of Wire | Signal Name [Specification] |
| 1 | G | - |
| 2 | O | - |
| 3 | L | - |
| 4 | L | - |
| 5 | L | - |
| 6 | GR | - |
| 7 | P | - |
| 8 | B | - |

| | |
|----------------|---------------------------|
| Connector No. | D181 |
| Connector Name | BACK DOOR TOUCH SENSOR RH |
| Connector Type | T02MGY |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color Of Wire | Signal Name [Specification] |
| 1 | LG | - |
| 2 | P | - |

| | |
|----------------|---|
| Connector No. | E38 |
| Connector Name | ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) |
| Connector Type | A1E22EB-AJZ4-LH |



| | | |
|--------------|---------------|---------------------------------|
| Terminal No. | Color Of Wire | Signal Name [Specification] |
| 1 | R | VALVE BATTERY |
| 2 | R | RR LH WHEEL SENSOR SIGNAL |
| 3 | L | RR LH WHEEL SENSOR POWER SUPPLY |
| 4 | G | G SENSOR POWER SUPPLY |
| 5 | B | FR RH WHEEL SENSOR SIGNAL |
| 6 | W | FR RH WHEEL SENSOR SIGNAL |
| 7 | R | BRAKE FLUID LEVEL SWITCH SIGNAL |
| 8 | LG | FR LH WHEEL SENSORE SIGNAL |
| 9 | L | FR LH WHEEL SENSOR POWER SUPPLY |
| 10 | B | G SENSOR GND |
| 11 | V | RR RH WHEEL SENSOR POWER SUPPLY |
| 12 | P | RR RH WHEEL SENSORE SIGNAL |
| 13 | B | GROUND |
| 14 | G | MOT OR BATTERY |
| 15 | SB | STOP LAMP SWITCH SIGNAL |
| 16 | GR | G SENSOR SIGNAL (-) |
| 17 | GR | CANL |
| 18 | P | CANL |
| 22 | BR | VOC OFF SWITCH SIGNAL |
| 23 | L | CAN-H |
| 25 | O | G SENSOR SIGNAL (-) |
| 26 | B | GROUND |


A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

AUTOMATIC BACK DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC BACK DOOR SYSTEM


| | |
|----------------|-----------------|
| Connector No. | ET05 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH700MK-CS10-M3 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SHIELD | - |
| 2 | P | - |
| 3 | B | - |
| 4 | R | - |
| 6 | LG | - |
| 7 | R | - |
| 8 | P | - |
| 9 | SB | - |
| 10 | BR | - |
| 11 | Y | - |
| 12 | O | - |
| 13 | W | - |
| 14 | L | - |
| 15 | GR | - |
| 23 | N | - |
| 33 | W | - |
| 37 | BR | - |
| 38 | G | - |
| 39 | V | - |
| 40 | P | - |
| 41 | L | - |
| 42 | LG | - |
| 43 | O | - |
| 45 | GR | - |
| 46 | SB | - |
| 47 | V | - |
| 49 | L | - |
| 50 | BR | - |
| 52 | G | - |
| 53 | B | - |
| 54 | O | - |
| 55 | Y | - |
| 56 | SHIELD | - |
| 61 | P | - |
| 62 | G | - |

| Terminal No. | W/L | Color Of Wire | Signal Name [Specification] |
|--------------|-----|---------------|-----------------------------|
| 63 | W/L | - | - |
| 64 | W/R | - | - |
| 66 | W | - | - |
| 67 | Y | - | - |
| 69 | SB | - | - |
| 70 | LG | - | - |
| 71 | R | - | - |
| 72 | L | - | - |
| 73 | GR | - | - |
| 74 | Y | - | - |
| 75 | SB | - | - |
| 76 | Y | - | - |
| 77 | G | - | - |
| 78 | O | - | - |
| 81 | R | - | - |
| 82 | LG | - | - |
| 83 | R | - | - |


| | |
|----------------|----------------------------------|
| Connector No. | FZ3 |
| Connector Name | TM (TRANSMISSION CONTROL MODULE) |
| Connector Type | RH40FB-RZP-L-RH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------------|
| 1 | P/B | TRANSMISSION RANGE SWITCH 2 |
| 2 | P/L | TRANSMISSION RANGE SWITCH 3 |
| 3 | G/O | TRANSMISSION RANGE SWITCH 4 |
| 4 | GR | TRANSMISSION RANGE SWITCH 3 (MONITOR) |
| 5 | B | GROUND |
| 7 | W | SENSOR GROUND |
| 8 | G/W | RCM ASSY (SEL 2) |
| 9 | L/R | RCM ASSY (SEL 1) |
| 10 | BR | RCM ASSY (SEL 3) |
| 11 | BR/W | RCM ASSY (SEL 4) |
| 13 | V | CVT FLUID TEMPERATURE SENSOR |
| 14 | R/W | PRIMARY PRESSURE SENSOR |
| 15 | V/W | SECONDARY PRESSURE SENSOR |
| 19 | O/B | BACK-UP LAMP RELAY |
| 20 | R/B | STARTER RELAY |
| 23 | W/R | SENSOR GROUND |


| Terminal No. | L/O | Color Of Wire | Signal Name [Specification] |
|--------------|------|---------------|--|
| 26 | L/O | - | SENSOR POWER |
| 27 | R/G | - | STEP MOTOR C |
| 28 | R | - | STEP MOTOR B |
| 29 | O/B | - | STEP MOTOR A |
| 30 | G/R | - | STEP MOTOR A |
| 31 | P | - | CAN-L |
| 32 | L | - | CAN-H |
| 33 | LG | - | PRIMARY SPEED SENSOR |
| 34 | LG/R | - | SECONDARY SPEED SENSOR |
| 37 | V/R | - | LOCK-UP SELECT SOLENOID VALVE |
| 38 | L/W | - | TORQUE CONVERTER CLUTCH SOLENOID VALVE |
| 39 | W/B | - | SECONDARY PRESSURE SOLENOID VALVE |
| 40 | R/Y | - | LINE PRESSURE SOLENOID VALVE |
| 42 | B | - | GROUND |
| 43 | W | - | IGNITION SUPPLY |
| 44 | L/R | - | BATTERY POWER SUPPLY (ALTERNATOR) |
| 45 | L/R | - | BATTERY POWER SUPPLY (ALTERNATOR) |
| 46 | Y | - | IGNITION POWER SUPPLY |

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS56FM-M2 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1A | Y | - |
| 2A | G | - |
| 3A | L | - |
| 4A | GR | - |
| 5A | V | - |
| 6A | R | - |
| 7A | GR | - |
| 8A | L | - |

| | |
|----------------|---------------------|
| Connector No. | M4 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD16W |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SHIELD | - |
| 2 | B | - |
| 3 | O | - |
| 4 | B/R | - |
| 5 | B/R | - |
| 6 | L | - |
| 7 | R | - |
| 8 | G | - |
| 11 | SB | - |
| 14 | P | - |
| 16 | O | - |

| | |
|----------------|-----------------|
| Connector No. | MT1 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH700PW-CS10-M8 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SHIELD | - |
| 2 | L | - |
| 3 | B | - |
| 4 | R | - |
| 6 | O | - |
| 7 | G | - |
| 8 | G | - |
| 9 | B | - |
| 10 | R | - |
| 11 | W | - |
| 12 | LG | - |


AUTOMATIC BACK DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC BACK DOOR SYSTEM

| | | | |
|----|--------|----|--|
| 13 | Y | -- | |
| 14 | L | -- | |
| 15 | B | -- | |
| 31 | R | -- | |
| 32 | V | -- | |
| 33 | Y | -- | |
| 37 | BR | -- | |
| 38 | BR | -- | |
| 39 | Y | -- | |
| 40 | P | -- | |
| 41 | L | -- | |
| 42 | G | -- | |
| 43 | W | -- | |
| 45 | LG | -- | |
| 46 | Y | -- | |
| 47 | G | -- | |
| 48 | BR | -- | |
| 49 | B | -- | |
| 51 | SB | -- | |
| 52 | GR | -- | |
| 53 | B | -- | |
| 54 | R | -- | |
| 55 | L | -- | |
| 56 | SHIELD | -- | |
| 61 | BR | -- | |
| 62 | LG | -- | |
| 63 | W/L | -- | |
| 64 | W/R | -- | |
| 66 | G | -- | |
| 67 | SB | -- | |
| 68 | Y | -- | |
| 70 | R | -- | |
| 71 | R | -- | |
| 72 | L | -- | |
| 73 | R | -- | |
| 74 | Y | -- | |
| 75 | G | -- | |
| 76 | V | -- | |
| 77 | P | -- | |
| 78 | W | -- | |
| 80 | Y | -- | |
| 81 | W | -- | |
| 82 | L | -- | |
| 83 | R | -- | |

| | |
|----------------|----------------------------|
| Connector No. | M29 |
| Connector Name | AUTOMATIC DOOR MAIN SWITCH |
| Connector Type | TK08FW |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | BATTERY POWER SUPPLY |
| 2 | B | IGNITION SIGNAL |
| 3 | B | GROUND |
| 4 | B/L | GROUND |

| | |
|----------------|-----------------|
| Connector No. | M31 |
| Connector Name | CIRCUIT BREAKER |
| Connector Type | M021W-P-LC |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | |
| 2 | L | |

| | |
|----------------|-------------------|
| Connector No. | M34 |
| Connector Name | COMBINATION METER |
| Connector Type | TH40FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 1 | O | BATTERY POWER SUPPLY |
| 2 | B | IGNITION SIGNAL |
| 3 | B | GROUND |
| 4 | B | GROUND |
| 5 | B/P | ILLUMINATION CONTROL SIGNAL |
| 6 | SB | TRIP RESET SWITCH SIGNAL |
| 10 | P | METER CONTROL SWITCH GROUND |
| 11 | G | ENTER SWITCH SIGNAL |
| 12 | BR | SELECT SWITCH SIGNAL |
| 13 | Y | ILLUMINATION CONTROL SWITCH SIGNAL (+) |
| 14 | V | ILLUMINATION CONTROL SWITCH SIGNAL (-) |
| 15 | BR | AIR BAG SIGNAL |
| 16 | L | ENGINE COOLANT TEMPERATURE SIGNAL |
| 18 | LG | AMBIENT SENSOR SIGNAL |
| 19 | R | A/G AUTO AMB CONDITION REGISTRATION SIGNAL |
| 21 | L | AMBIENT SENSOR GROUND |
| 22 | L | GM-H |
| 23 | P | GM-H |
| 24 | B | GROUND |
| 25 | B | FUEL LEVEL SENSOR GROUND |
| 25 | BR | ALTERNATOR SIGNAL |
| 26 | BR | PARKING BRAKE SWITCH SIGNAL |
| 27 | Y | BRAKE FLUID LEVEL SWITCH SIGNAL |
| 28 | V | SECURITY SIGNAL |
| 29 | G | WASHER LEVEL SWITCH SIGNAL |
| 31 | SB | VEHICLE SPEED SIGNAL (θ-PULSE) |
| 32 | P | OVERDRIVE CONTROL SWITCH SIGNAL |
| 34 | O | FUEL LEVEL SENSOR SIGNAL |
| 35 | P | SEAT BELT BRAKE SWITCH SIGNAL (UNPRESS) |
| 36 | BR | PASSENGER SEAT BELT WARNING SIGNAL |

| | |
|----------------|--------------|
| Connector No. | M77 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CS19 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---|
| 10 | GR | -- |
| 12 | W | -- |
| 13 | W | -- |
| 15 | Y | -- |
| 29 | L | -- |
| 30 | P | -- |
| 31 | BR | -- |
| 37 | SHIELD | -- |
| 38 | B | -- [Without automatic drive positioner] |
| 38 | W | -- [With automatic drive positioner] |
| 39 | B | -- [Without automatic drive positioner] |
| 39 | W | -- [With automatic drive positioner] |
| 40 | R | -- |
| 51 | V | -- |
| 52 | B | -- |
| 52 | O | -- |
| 53 | R | -- |
| 55 | L | -- |
| 57 | Y | -- |
| 58 | L | -- |
| 59 | O | -- |
| 60 | G | -- |
| 61 | LG | -- |
| 62 | V | -- |
| 63 | SB | -- |
| 64 | R | -- |
| 65 | G | -- |
| 66 | SHIELD | -- |
| 67 | W/L | -- |
| 68 | SHIELD | -- |
| 70 | W/L | -- |
| 71 | W/R | -- |
| 72 | LG | -- |
| 74 | GR | -- |
| 75 | G | -- |

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

JRKWC6530GB

AUTOMATIC BACK DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC BACK DOOR SYSTEM

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---|
| 77 | G | - |
| 78 | R | - |
| 79 | L | - |
| 80 | G | - |
| 81 | L | - |
| 82 | W | - |
| 87 | V | - |
| 88 | R | - |
| 89 | Y | - |
| 90 | R | - [Without automatic drive positioner] - [With automatic drive positioner] |
| 91 | SB | - |
| 92 | P | - |

| | |
|----------------|----------------------------|
| Connector No. | ME3 |
| Connector Name | AUTOMATIC BACK DOOR SWITCH |
| Connector Type | TH08FGY-NH |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | - |
| 2 | B | - |
| 3 | R/L | - |
| 4 | B/R | - |

| | |
|----------------|---------------------------|
| Connector No. | M12L |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 1 | W | REAR WINDOW DEF RELAY CONT |
| 2 | LG | COMBI SW INPUT 5 |
| 3 | Y | COMBI SW INPUT 4 |
| 4 | O | COMBI SW INPUT 3 |
| 5 | G | COMBI SW INPUT 2 |
| 6 | L | COMBI SW INPUT 1 |
| 7 | W | KEY CYL UNLOCK SW |
| 8 | GR | PW SW COMM [With automatic sliding door] |
| 8 | Y | KEY CYL LOCK SW [Without automatic sliding door] |
| 9 | V | STOP LAMP SW 1 |
| 12 | GR | DOOR LK & UNLK SW LOCK |
| 13 | BR | DOOR LK & UNLK SW UNLOCK |
| 14 | L | REAR WINDOW DEF SW |
| 15 | W | REAR WINDOW DEF SW |
| 16 | Y | DRIVER |
| 17 | O | SENS PWR SPLY |
| 18 | R | REGEN/SENS GND |
| 21 | R | NATS ANT AMP |
| 23 | B | SECURITY IND CONT |
| 24 | B | DONGLE LINK |
| 25 | W | NATS ANT AMP |
| 27 | O | A/G ON |
| 28 | BR | BLOWER FAN ON |
| 29 | P | HAZARD SW |
| 30 | L | BR DOOR OPEN SW |
| 31 | O | DR DOOR UNLK SENS |
| 32 | W | COMBI SW OUTPUT 5 |
| 33 | W | COMBI SW OUTPUT 4 |
| 34 | GR | COMBI SW OUTPUT 3 |
| 35 | SB | COMBI SW OUTPUT 2 |
| 36 | R | COMBI SW OUTPUT 1 |
| 37 | G | DETENT SW |
| 38 | SB | RECEIVER COMM |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|----------------|---------------------------|
| Connector No. | M12Z |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | FEA08FB-FH46-SA |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 43 | Y | BK DOOR SW |
| 44 | Y | REAR WHEEL STOP POSITION |
| 45 | SB | PASS DOOR SW |
| 46 | R | SL DOOR RH SW |
| 47 | G | DR DOOR SW |
| 48 | O | SL DOOR LH SW |
| 49 | B | LUGGAGE LAMP CONT |
| 50 | V | SELECT UNLK RELAY CONT |
| 51 | LG | BACK DOOR REQ SW |
| 53 | BR | BK DOOR OPEN |
| 54 | R | REAR WIPER OUTPUT |
| 55 | G | SL DOOR LH UNLK CONT |

| | |
|----------------|---------------------------|
| Connector No. | M12Z |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | FEA08FB-FH46-SA |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 57 | GR | INT ROOM LAMP PWR SPLY |
| 58 | O | BAT |
| 58 | O | AIR SAS |
| 60 | V | PASS DOOR UNLK OUTPUT |
| 61 | G | TURN SIG LH OUTPUT |
| 62 | W | TURN SIG RH OUTPUT |
| 63 | R | STEP LAMP CONT |
| 63 | R | INT ROOM LAMP CONT |

| | | |
|----|----|----------------------|
| 64 | LG | CRANK REQ |
| 66 | Y | ALL DOOR LOCK OUTPUT |
| 68 | G | DR DOOR UNLK OUTPUT |
| 67 | B | GROUND |
| 68 | L | PW PWR SPLY (IGN) |
| 69 | P | PW PWR SPLY (BAT) |
| 70 | L | BAT |

INTEGRATED HOMELINK TRANSMITTER SYSTEM


< WIRING DIAGRAM >

INTEGRATED HOMELINK TRANSMITTER SYSTEM

Wiring Diagram

INFOID:000000009649034

INTEGRATED HOMELINK TRANSMITTER



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

2012/07/19


JRKWC2316GB

INTEGRATED HOMELINK TRANSMITTER SYSTEM


< WIRING DIAGRAM >

INTEGRATED HOMELINK TRANSMITTER

| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NSJ9FW-M2 |




| | |
|----------------|--------------|
| Connector No. | M2 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH12FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | |
| 2 | SB | |
| 3 | G | |
| 4 | L | |
| 5 | GR | |
| 6 | V | |
| 7 | R | |
| 8 | GR | |
| 9 | P | |
| 10 | R | |
| 11 | B/W | |
| 12 | B | |
| 13 | R | |
| 14 | W/L | [Without MAV] |
| 15 | SHIELD | [With MAV] |
| 16 | BR | [With MAV] |
| 17 | W/R | [Without MAV] |


| | |
|----------------|------------------|
| Connector No. | M2 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NSJ9FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10B | R | |
| 3B | V | |
| 4B | W | |
| 8B | BR | |
| 9B | O/L | |
| 8B | GR | |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | |
| 2 | BR | |
| 3 | BR/R | [With manual A/C] |
| 4 | V | [With auto A/C] |
| 5 | R | [With auto A/C] |
| 6 | R/L | [With manual A/C] |
| 7 | B | |
| 8 | O | |
| 9 | P | |
| 10 | V | |
| 11 | BR | |

| | |
|----------------|----------------------------------|
| Connector No. | R2B |
| Connector Name | AUTO ANTI-DAZZLING INSIDE MIRROR |
| Connector Type | TH18FR-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 8 | V | |
| 9 | G | |
| 10 | BR | |

| | |
|----------------|--------------|
| Connector No. | R10B |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH18MW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | G | |
| 2 | SB | |
| 3 | P | |
| 4 | LG | |
| 6 | O | |
| 7 | W | |
| 8 | BR | |
| 9 | L | |
| 10 | LG | |
| 11 | B | |
| 12 | V | |
| 13 | Y | |
| 14 | Y | |
| 15 | SHIELD | |
| 16 | BR | |

| | |
|----------------|--------------|
| Connector No. | R107 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH12MM-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P | |
| 2 | SB | |
| 3 | G | |
| 4 | Y | |
| 7 | B | |
| 8 | R | |
| 9 | L | |
| 10 | P | |
| 11 | LG | |

JRKWC6532GB


AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC SLIDING DOOR SYSTEM

Wiring Diagram

INFOID:000000009649035




A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

2012/07/19

JRKWC2312GB


AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >



AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >




AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >


AUTOMATIC SLIDING DOOR SYSTEM

| | |
|----------------|------------------|
| Connector No. | B8 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NSZFBR-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10G | Y | - |
| 12G | O | - |
| 2G | W | - |
| 4G | SB | - |
| 5G | L | - |


| | |
|----------------|--------------|
| Connector No. | B11 |
| Connector Name | WIPE TO WIPE |
| Connector Type | TR80MW-CS19 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10 | LG | - |
| 12 | Y | - |
| 13 | P | - |
| 15 | L | - |
| 29 | GR | - |
| 30 | W | - |
| 31 | BR | - |
| 37 | SHIELD | - |
| 38 | R/L | - |
| 39 | B | - |
| 40 | R/W | - |
| 51 | O | - |
| 52 | B/P | - |
| 53 | V | - |

| | | |
|----|--------|---|
| 54 | P | - |
| 55 | L | - |
| 57 | Y | - |
| 58 | V | - |
| 59 | O | - |
| 61 | B | - |
| 62 | W | - |
| 63 | Y | - |
| 64 | W | - |
| 65 | R | - |
| 66 | SHIELD | - |
| 67 | B | - |
| 68 | W | - |
| 69 | SHIELD | - |
| 70 | W/R | - |
| 71 | B/R | - |
| 72 | P | - |
| 74 | BR | - |
| 75 | SB | - |
| 77 | V | - |
| 78 | LG | - |
| 79 | W | - |
| 80 | R | - |
| 81 | SB | - |
| 82 | V | - |
| 87 | BR | - |
| 88 | P | - |
| 89 | BR | - |
| 90 | LG | - [Without automatic drive positioner] - [With automatic drive positioner] |
| 91 | O | - |
| 92 | G | - |

| | |
|----------------|--------------|
| Connector No. | B21 |
| Connector Name | WIPE TO WIPE |
| Connector Type | NS80MW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | B | - |
| 5 | Y | - |
| 6 | BR | - |
| 7 | LG | - |
| 8 | GR | - |
| 9 | SB | - |
| 10 | Y | - |
| 11 | G | - |
| 14 | O | - |
| 15 | W | - |
| 16 | B | - |

| | |
|----------------|-------------------------------|
| Connector No. | B24 |
| Connector Name | FUEL FILLER LID STATUS SWITCH |
| Connector Type | TK02FBR |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B/Y | - |
| 2 | G | - |

| | |
|----------------|--|
| Connector No. | B25 |
| Connector Name | SLIDING DOOR OPEN / CLOSE SWITCH (REAR LH) |
| Connector Type | TK02MW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | B | - |

| | |
|----------------|--|
| Connector No. | B27 |
| Connector Name | AUTOMATIC SLIDING DOOR WARNING BUZZER LH |
| Connector Type | RK02FBR |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | - |
| 2 | W | - |

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

JRKWC6514GB

AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >


AUTOMATIC SLIDING DOOR SYSTEM

| | |
|----------------|--------------------------------|
| Connector No. | B53 |
| Connector Name | AUTOMATIC SLIDING DOOR UNIT LH |
| Connector Type | NS08FW-GS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | P | GLUTCH(PWM-) |
| 2 | SB | GLUTCH(RET-) |
| 3 | R | MOTOR(GREEN) |
| 4 | W | MOTOR(RED) |


| | |
|----------------|------------------------------|
| Connector No. | B45 |
| Connector Name | SLIDING DOOR CONTROL UNIT LH |
| Connector Type | TH132FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | MAIN SW |
| 2 | R | B-PLR SW |
| 3 | SB | KNOB LOCK |
| 4 | GR | A-SIGN |
| 5 | LG | HALF LATCH |
| 6 | W | IGN |
| 8 | W | BUZZER |
| 9 | P | CAN-L |
| 10 | L | CAN-H |
| 11 | O | ENCODER POWER |
| 12 | LG | ELEC B |
| 14 | GR | ONETOUCH OPEN SW |
| 15 | R | NEUTRAL SW |
| 17 | G | FUEL LID SW |
| 18 | L | FULL SW |
| 19 | P | DRIVER SW |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 20 | R | CHILD LOCK |
| 21 | BR | B-SIGN |
| 22 | G | SWIDE |
| 24 | C | TOUCH SENS |
| 26 | SB | ENCODER GND |
| 27 | B/Y | GBL LOGIC |
| 28 | V | RR DOOR SW |

| | |
|----------------|------------------------------|
| Connector No. | B46 |
| Connector Name | SLIDING DOOR CONTROL UNIT LH |
| Connector Type | NS10FW-GS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 33 | B/Y | GND POWER |
| 34 | GR | CLOSURE-(CLOSE) |
| 35 | SB | CLOSURE(RET) |
| 36 | V | BAT |
| 37 | B/Y | GND POWER |
| 38 | G | RELEASE ACTR(-) |
| 40 | V | RELEASE ACTR(+) |
| 42 | V | BAT |

| | |
|----------------|------------------------------|
| Connector No. | B47 |
| Connector Name | SLIDING DOOR CONTROL UNIT LH |
| Connector Type | NS08FW-GS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 43 | R | OPEN |
| 44 | W | CLOSE |
| 46 | W | CLOSE |
| 47 | SB | GLUTCH(+) |

| | |
|----------------|--------------|
| Connector No. | B53 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH12MW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | |
| 5 | SB | |
| 6 | G | |
| 7 | B | |
| 8 | L | |
| 9 | R | |
| 10 | LG | |
| 11 | O | |
| 12 | GR | |

| | |
|----------------|--------------------------------|
| Connector No. | B55 |
| Connector Name | AUTOMATIC SLIDING DOOR UNIT LH |
| Connector Type | TH04FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | O | |
| 6 | GR | |
| 7 | BR | |


| | | | |
|--------------|---|----|--|
| Terminal No. | 8 | SB | |
|--------------|---|----|--|

| | |
|----------------|------------------------|
| Connector No. | B71 |
| Connector Name | SLIDING DOOR SWITCH LH |
| Connector Type | TH04FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | V | |

| | |
|----------------|--|
| Connector No. | B203 |
| Connector Name | AUTOMATIC SLIDING DOOR WARNING BUZZER RH |
| Connector Type | RK02FBR |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | |
| 2 | BR | |

JRKWC6515GB

AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC SLIDING DOOR SYSTEM

| | |
|----------------|--|
| Connector No. | B208 |
| Connector Name | SLIDING DOOR OPEN / CLOSE SWITCH (REAR RH) |
| Connector Type | TH02MW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | BR | - |
| 2 | B/W | - |

| | |
|----------------|--------------|
| Connector No. | B218 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16MR-CS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | O | - |
| 4 | BR | - |
| 5 | Y | - |
| 8 | V | - |
| 9 | P | - |
| 10 | L | - |
| 11 | LG | - |
| 13 | G | - |
| 14 | SB | - |
| 15 | Y | - |

| | |
|----------------|------------------------|
| Connector No. | B221 |
| Connector Name | SLIDING DOOR SWITCH RH |
| Connector Type | TH06FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 3 | W | - |

| | |
|----------------|--------------|
| Connector No. | B225 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH18MW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | W | - |
| 3 | P | - |
| 5 | BR | - |
| 9 | L | - |
| 10 | P | - |
| 11 | SB | - |
| 12 | W | - |
| 13 | Y | - |
| 14 | GR | - |
| 15 | LG | - |
| 16 | O | - |

| | |
|----------------|--------------|
| Connector No. | B232 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH12MW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | - |
| 5 | L | - |
| 6 | G | - |
| 7 | B | - |
| 8 | W | - |
| 9 | V | - |
| 10 | GR | - |
| 11 | Y | - |
| 12 | SB | - |

| | |
|----------------|--------------|
| Connector No. | B239 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS18MW-ZS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | BR | - [Without BOSE system] |
| 2 | P | - [With BOSE system] |
| 2 | Y | - [Without BOSE system] |
| 4 | B | - |
| 5 | GR | - |
| 6 | O | - |
| 7 | SB | - |
| 8 | R | - |
| 9 | G | - |
| 10 | O | - |

| | | |
|----|-----|---|
| 11 | L | - |
| 14 | P | - |
| 15 | V | - |
| 16 | B/R | - |



| | |
|----------------|--------------------------------|
| Connector No. | B244 |
| Connector Name | AUTOMATIC SLIDING DOOR UNIT RH |
| Connector Type | TH04FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 5 | G | - |
| 6 | V | - |
| 7 | R | - |
| 8 | GR | - |

| | |
|----------------|--------------------------------|
| Connector No. | B245 |
| Connector Name | AUTOMATIC SLIDING DOOR UNIT RH |
| Connector Type | NS04FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L | CLUTCH(PWM-) |
| 2 | BR | CLUTCH(RET-) |
| 3 | W | MOTOR(GREEN) |
| 4 | B | MOTOR(RED) |

JRKWC6516GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC SLIDING DOOR SYSTEM

| | |
|----------------|------------------------------|
| Connector No. | B247 |
| Connector Name | SLIDING DOOR CONTROL UNIT RH |
| Connector Type | TH22FW-NH |



| | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 8 | 9 | 10 | 11 | 12 | 14 | 15 |
| 18 | 19 | 20 | 21 | 22 | 23 | 24 | 26 | 27 | 28 | 29 | | |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | Y | MAIN SW |
| 2 | BR | B-PLR SW |
| 3 | L | KNOB LOCK |
| 4 | R | A-SIGN |
| 5 | GR | HALF LATCH |
| 6 | LG | IGN |
| 8 | BR | BUZZER |
| 9 | P | CAN-L |
| 10 | L | CAN-H |
| 11 | G | ENCODER POWER |
| 12 | O | ELEC B |
| 14 | SB | ONETOUCH OPEN SW |
| 15 | V | NEUTRAL SW |
| 18 | W | FULL SW |
| 19 | GR | DRIVER SW |
| 20 | LG | CHILE LOCK |
| 21 | Y | HAZARD |
| 22 | Y | SW GND |
| 24 | G | TOUCH SENS |
| 26 | GR | ENCODER GND |
| 27 | B/Y | GD LOGIC |
| 28 | W | RR DOOR SW |

| | |
|----------------|------------------------------|
| Connector No. | B248 |
| Connector Name | SLIDING DOOR CONTROL UNIT RH |
| Connector Type | HS10FW-CS |



| | | | |
|----|----|----|----|
| 33 | 34 | 35 | 36 |
| 37 | 39 | 40 | 42 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 33 | B/R | GND POWER |
| 34 | R | CLOSURE -(CLOSE) |
| 35 | G | CLOSURE +(CLOSE) |
| 36 | Y | BAT |
| 37 | B/R | GND POWER |
| 38 | L | RELEASE ACTR(-) |
| 40 | O | RELEASE ACTR(+) |
| 42 | Y | BAT |

| | |
|----------------|------------------------------|
| Connector No. | B249 |
| Connector Name | SLIDING DOOR CONTROL UNIT RH |
| Connector Type | HS06FW-CS |



| | |
|----|----|
| 43 | 44 |
| 46 | 47 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 43 | B | OPEN |
| 44 | L | CLUTCH(-) |
| 46 | W | CLOSE |
| 47 | BR | CLUTCH(+) |

| | |
|----------------|--------------|
| Connector No. | D22 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH12MW-NH |



| | | | | | |
|---|---|---|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 |
| 7 | 8 | 9 | 10 | 11 | 12 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 5 | LG | - |
| 6 | R | - |
| 7 | B | - |
| 8 | Y | - |
| 9 | P | - |
| 10 | L | - |
| 11 | O | - |
| 12 | W | - |

| | |
|----------------|--------------|
| Connector No. | D23 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH12MW-NH |



| | | | | | |
|---|---|---|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 |
| 7 | 8 | 9 | 10 | 11 | 12 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 5 | LG | - |
| 6 | R | - |
| 7 | B | - |
| 8 | Y | - |
| 9 | P | - |
| 10 | L | - |
| 11 | O | - |
| 12 | W | - |

| | |
|----------------|--------------|
| Connector No. | D61 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FW-CS |



| | | | | | | |
|----|----|----|----|----|---|---|
| 7 | 6 | 5 | 4 | 2 | 1 | |
| 18 | 15 | 14 | 11 | 10 | 9 | 8 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | B | - |
| 4 | B | - |
| 5 | R | - |
| 6 | P | - |
| 7 | SB | - |
| 8 | BR | - |
| 9 | W | - |
| 10 | O | - |
| 11 | G | - |
| 14 | L | - |
| 15 | Y | - |
| 16 | BR | - |

| | |
|----------------|--------------|
| Connector No. | D62 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FW-CS |



| | | | | | | |
|----|----|----|----|----|---|---|
| 7 | 6 | 5 | 4 | 2 | 1 | |
| 18 | 15 | 14 | 11 | 10 | 9 | 8 |

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | B | - |
| 5 | R | - |
| 6 | P | - |
| 7 | SB | - |
| 8 | BR | - |
| 9 | W | - |

JRKWC6517GB


AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC SLIDING DOOR SYSTEM

| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 10 | O | - |
| 11 | G | - |
| 14 | L | - |
| 15 | Y | - |
| 16 | BR | - |

| | |
|----------------|--------------|
| Connector No. | D111 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FW-CS |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | W | - |
| 5 | BR | - |
| 6 | BR | - |
| 7 | G | - |
| 8 | R | - |
| 9 | R | - |
| 10 | Y | - |
| 11 | G | - |
| 14 | GR | - |
| 15 | GR | - |
| 16 | P | - |

| | |
|----------------|--------------|
| Connector No. | D112 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16MW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | W | - |
| 3 | BR | - |
| 4 | BR | - |
| 7 | G | - |
| 8 | R | - |
| 9 | R | - |
| 10 | Y | - |
| 11 | Y | - |
| 14 | GR | - |
| 15 | GR | - |
| 16 | P | - |

| | |
|----------------|--------------|
| Connector No. | D113 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | W | - |
| 3 | BR | - |
| 4 | BR | - |
| 7 | G | - |
| 8 | R | - |
| 9 | R | - |
| 10 | Y | - |
| 11 | Y | - |
| 14 | GR | - |
| 15 | GR | - |
| 16 | P | - |

| | |
|----------------|--------------|
| Connector No. | D114 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16MW-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | W | - |
| 4 | B | - |
| 5 | BR | - |
| 6 | BR | - |
| 7 | G | - |
| 8 | R | - |
| 9 | R | - |
| 10 | Y | - |
| 11 | Y | - |
| 14 | GR | - |
| 15 | GR | - |
| 16 | P | - |

| | |
|----------------|----------------------------|
| Connector No. | D116 |
| Connector Name | REMOTE CONTROL ASSEMBLY LH |
| Connector Type | TH6AMW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | - |
| 2 | O | - |
| 4 | V | - |

| | |
|----------------|------------------------------------|
| Connector No. | D119 |
| Connector Name | SLIDING DOOR LOCK STATUS SWITCH LH |
| Connector Type | SGY0DFGY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | LG | - |
| 3 | B | - |

| | |
|----------------|------------------------------------|
| Connector No. | D120 |
| Connector Name | SLIDING DOOR LOCK STATUS SWITCH RH |
| Connector Type | SGY0DFGY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | - |
| 3 | LG | - |

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

JRKWC6518GB

AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC SLIDING DOOR SYSTEM

| | |
|----------------|---------------------------------------|
| Connector No. | D121 |
| Connector Name | SLIDING DOOR LOCK RELEASE ACTUATOR LH |
| Connector Type | SGY02FGY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | - |
| 2 | G | - |

| | |
|----------------|---------------------------------------|
| Connector No. | D122 |
| Connector Name | SLIDING DOOR LOCK RELEASE ACTUATOR RH |
| Connector Type | SGY02FGY |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | O | - |
| 2 | G | - |

| | |
|----------------|-------------------------------|
| Connector No. | D123 |
| Connector Name | SLIDING DOOR LOCK ASSEMBLY LH |
| Connector Type | RS06FGY-PR |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | B | - |
| 3 | L | - |
| 4 | BR | - |
| 5 | Y | - |
| 6 | P | - |

| | |
|----------------|-------------------------------|
| Connector No. | D124 |
| Connector Name | SLIDING DOOR LOCK ASSEMBLY RH |
| Connector Type | RS06FGY-PR |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | B | - |
| 3 | L | - |
| 4 | BR | - |
| 5 | Y | - |
| 6 | P | - |

| | |
|----------------|---|
| Connector No. | D125 |
| Connector Name | SLIDING DOOR ONE TOUCH OPEN / CLOSE SWITCH LH |
| Connector Type | RH02FB |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | - |
| 2 | B | - |

| | |
|----------------|---|
| Connector No. | D126 |
| Connector Name | SLIDING DOOR ONE TOUCH OPEN / CLOSE SWITCH RH |
| Connector Type | RH02FB |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | B | - |

| | |
|----------------|----------------------------|
| Connector No. | D127 |
| Connector Name | REMOTE CONTROL ASSEMBLY RH |
| Connector Type | TR02MP-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | B | - |
| 2 | O | - |
| 4 | V | - |

| | |
|----------------|------------------------------|
| Connector No. | D172 |
| Connector Name | SLIDING DOOR TOUCH SENSOR LH |
| Connector Type | PH02MB |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | F | - |
| 2 | B | - |

JRKWC6519GB

AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >


AUTOMATIC SLIDING DOOR SYSTEM

| | |
|----------------|------------------------------|
| Connector No. | D173 |
| Connector Name | SLIDING DOOR TOUCH SENSOR RH |
| Connector Type | FR02MB |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | B | - |

| | |
|----------------|--------------|
| Connector No. | D188 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH12FW-NH |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | BR | - |
| 5 | BR | - |
| 6 | BR | - |
| 7 | BR | - |
| 8 | R | - |
| 9 | Y | - |
| 10 | Y | - |
| 11 | GR | - |
| 12 | GR | - |

| | |
|----------------|--------------|
| Connector No. | D194 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH12FW-NH |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L | - |
| 5 | BR | - |
| 6 | BR | - |
| 7 | R | - |
| 8 | R | - |
| 9 | Y | - |
| 10 | Y | - |
| 11 | GR | - |
| 12 | GR | - |

| | |
|----------------|--------------|
| Connector No. | D195 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH12FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L | - |
| 5 | BR | - |
| 6 | BR | - |
| 7 | R | - |
| 8 | R | - |
| 9 | Y | - |
| 10 | Y | - |
| 11 | GR | - |
| 12 | GR | - |

| | |
|----------------|--------------|
| Connector No. | D196 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH12FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L | - |
| 5 | BR | - |
| 6 | BR | - |
| 7 | R | - |
| 8 | R | - |
| 9 | Y | - |
| 10 | Y | - |
| 11 | GR | - |
| 12 | GR | - |


| | |
|----------------|---|
| Connector No. | E36 |
| Connector Name | ABS ACTUATOR AND ELECTRIC UNIT CONTROL UNIT |
| Connector Type | AE22FB-AJ24-LH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|---------------------------------|
| 1 | R | VALVE BATTERY |
| 2 | Y | RR LH WHEEL SENSOR SIGNAL |
| 3 | L | RR LH WHEEL SENSOR POWER SUPPLY |
| 4 | G | G SENSOR POWER SUPPLY |
| 5 | B | FR RH WHEEL SENSOR POWER SUPPLY |
| 6 | W | FR RH WHEEL SENSOR SIGNAL |
| 7 | R | BRAKE FLUID LEVEL SWITCH SIGNAL |
| 8 | LG | FR LH WHEEL SENSOR SIGNAL |
| 9 | L | FR LH WHEEL SENSOR POWER SUPPLY |
| 10 | B | G SENSOR GND |
| 11 | V | RR RH WHEEL SENSOR POWER SUPPLY |

| | | |
|----|----|---------------------------|
| 12 | P | RR RH WHEEL SENSOR SIGNAL |
| 13 | B | GROUND |
| 14 | G | MOTOR BATTERY |
| 15 | B | STOP LAMP SWITCH SIGNAL |
| 16 | Y | G SENSOR SIGNAL (-) |
| 17 | GR | CAN-L |
| 18 | P | CAN-H |
| 19 | BR | VDC OFF SWITCH SIGNAL |
| 20 | L | CAN-H |
| 21 | L | CAN-H |
| 22 | O | G SENSOR SIGNAL (-) |
| 23 | B | GROUND |

| | |
|----------------|-----------------|
| Connector No. | E105 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH7MMY-CSD10-M3 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | SHIELDED | - |
| 2 | W | - |
| 3 | B | - |
| 4 | R | - |
| 5 | G | - |
| 6 | R | - |
| 7 | LG | - |
| 8 | GR | - |
| 9 | SS | - |
| 10 | BR | - |
| 11 | Y | - |
| 12 | O | - |
| 13 | W | - |
| 14 | L | - |
| 15 | P | - |
| 31 | GR | - |
| 32 | R | - |
| 33 | W | - |
| 37 | BR | - |
| 38 | G | - |
| 39 | V | - |
| 40 | P | - |
| 41 | L | - |
| 42 | LG | - |

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC SLIDING DOOR SYSTEM

| | | | |
|----|--------|----|--|
| 43 | O | -- | |
| 44 | GR | -- | |
| 45 | SB | -- | |
| 46 | Y | -- | |
| 47 | L | -- | |
| 48 | W | -- | |
| 49 | BR | -- | |
| 50 | GR | -- | |
| 51 | B | -- | |
| 52 | O | -- | |
| 53 | Y | -- | |
| 54 | W | -- | |
| 55 | V | -- | |
| 56 | SHIELD | -- | |
| 61 | P | -- | |
| 62 | G | -- | |
| 63 | W/L | -- | |
| 64 | W/R | -- | |
| 66 | W | -- | |
| 67 | Y | -- | |
| 69 | SB | -- | |
| 70 | LG | -- | |
| 71 | R | -- | |
| 72 | L | -- | |
| 73 | GR | -- | |
| 74 | Y | -- | |
| 75 | SB | -- | |
| 76 | Y | -- | |
| 77 | G | -- | |
| 78 | O | -- | |
| 80 | R | -- | |
| 81 | L | -- | |
| 82 | G | -- | |
| 83 | R | -- | |


| | |
|----------------|-----------------------------------|
| Connector No. | F23 |
| Connector Name | TCM (TRANSMISSION CONTROL MODULE) |
| Connector Type | RH40FB-R28-L-RH |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color Of Wire | Signal Name [Specification] |
| 1 | P/B | TRANSMISSION RANGE SWITCH 2 |
| 2 | P/L | TRANSMISSION RANGE SWITCH 3 |
| 3 | G/O | TRANSMISSION RANGE SWITCH 4 |

| | | |
|----|------|--|
| 4 | GR | TRANSMISSION RANGE SWITCH 3 (MONITOR) |
| 5 | B | GROUND |
| 6 | Y | SENSOR GROUND |
| 7 | O/W | ROM ASSY (SEL. 2) |
| 8 | L/W | ROM ASSY (SEL. 1) |
| 9 | BR/W | ROM ASSY (SEL. 3) |
| 10 | BR/W | TRANSMISSION RANGE SWITCH 1 |
| 11 | BR/W | CVT FLUID TEMPERATURE SENSOR |
| 13 | V | PRIMARY PRESSURE SENSOR |
| 14 | R/W | SECONDARY PRESSURE SENSOR |
| 15 | V/W | BACK-UP LAMP RELAY |
| 19 | O/B | STARTER RELAY |
| 20 | R/B | SENSOR GROUND |
| 25 | W/R | SENSOR POWER |
| 26 | L/O | STEP MOTOR D |
| 27 | R/G | STEP MOTOR C |
| 28 | R | STEP MOTOR B |
| 29 | O/B | STEP MOTOR A |
| 30 | G/R | CAN-L |
| 31 | P | CAN-H |
| 32 | L | PRIMARY SPEED SENSOR |
| 33 | LG | SECONDARY SPEED SENSOR |
| 34 | LG/R | LOCK-UP SELECT SOLENOID VALVE |
| 37 | V/R | TORQUE CONVERTER CLUTCH SOLENOID VALVE |
| 38 | L/W | SECONDARY PRESSURE SOLENOID VALVE |
| 39 | W/B | LINE PRESSURE SOLENOID VALVE |
| 40 | R/Y | GROUND |
| 42 | B | IGNITION POWER SUPPLY |
| 46 | Y | BATTERY POWER SUPPLY (MONITOR BACK-UP) |
| 47 | L/R | IGNITION POWER SUPPLY |
| 48 | Y | |


| | |
|----------------|------------------|
| Connector No. | M1 |
| Connector Name | FUSE BLOCK (J/B) |
| Connector Type | NS08FW-M2 |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color Of Wire | Signal Name [Specification] |
| 1A | Y | -- |
| 2A | G | -- |
| 3A | L | -- |
| 4A | GR | -- |

| | | |
|----|----|----|
| 5A | V | -- |
| 6A | R | -- |
| 7A | GR | -- |
| 8A | L | -- |

| | |
|----------------|---------------------|
| Connector No. | M4 |
| Connector Name | DATA LINK CONNECTOR |
| Connector Type | BD18FW |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color Of Wire | Signal Name [Specification] |
| 3 | LG | -- |
| 4 | B/R | -- |
| 5 | B/R | -- |
| 6 | L | -- |
| 7 | R | -- |
| 8 | G | -- |
| 11 | SB | -- |
| 14 | P | -- |
| 16 | O | -- |

| | |
|----------------|----------------|
| Connector No. | M11 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH70FW-CS10-M3 |



| | | |
|--------------|---------------|-----------------------------|
| Terminal No. | Color Of Wire | Signal Name [Specification] |
| 1 | SHIELD | -- |
| 2 | W | -- |
| 3 | B | -- |
| 4 | R | -- |
| 6 | O | -- |

| | | |
|----|--------|----|
| 7 | O | -- |
| 8 | G | -- |
| 9 | B | -- |
| 10 | W | -- |
| 11 | W | -- |
| 12 | LG | -- |
| 13 | Y | -- |
| 14 | L | -- |
| 15 | P | -- |
| 31 | R | -- |
| 32 | V | -- |
| 33 | Y | -- |
| 37 | BR | -- |
| 38 | BR | -- |
| 39 | Y | -- |
| 40 | P | -- |
| 41 | L | -- |
| 42 | G | -- |
| 43 | W | -- |
| 45 | LG | -- |
| 46 | V | -- |
| 47 | LG | -- |
| 49 | G | -- |
| 51 | SB | -- |
| 52 | GR | -- |
| 53 | B | -- |
| 54 | R | -- |
| 55 | R | -- |
| 56 | SHIELD | -- |
| 61 | BR | -- |
| 62 | G | -- |
| 64 | W/L | -- |
| 66 | O | -- |
| 67 | SB | -- |
| 68 | Y | -- |
| 70 | R | -- |
| 71 | R | -- |
| 72 | L | -- |
| 73 | R | -- |
| 74 | Y | -- |
| 75 | G | -- |
| 76 | V | -- |
| 77 | P | -- |
| 78 | W | -- |
| 80 | Y | -- |
| 81 | W | -- |
| 82 | L | -- |
| 83 | R | -- |

AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >


AUTOMATIC SLIDING DOOR SYSTEM

| | |
|----------------|----------------------------|
| Connector No. | M29 |
| Connector Name | AUTOMATIC DOOR MAIN SWITCH |
| Connector Type | TH08FW |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 2 | B/R | - |
| 3 | B | - |
| 4 | R/L | - |


| | |
|----------------|-------------------|
| Connector No. | M34 |
| Connector Name | COMBINATION METER |
| Connector Type | TH40FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 1 | O | BATTERY POWER SUPPLY |
| 2 | O | IGNITION SIGNAL |
| 3 | B | GROUND |
| 4 | B | ILLUMINATION CONTROL SIGNAL |
| 5 | B/P | TRIP RESET SWITCH SIGNAL |
| 6 | SB | METER CONTROL SWITCH SIGNAL |
| 10 | P | ENTER SWITCH SIGNAL |
| 11 | G | SELECT SWITCH SIGNAL |
| 12 | BR | ILLUMINATION CONTROL SWITCH SIGNAL (+) |
| 13 | Y | ILLUMINATION CONTROL SWITCH SIGNAL (-) |
| 14 | V | AIR BAG SIGNAL |
| 15 | BR | ENGINE COOLANT TEMPERATURE SIGNAL |
| 16 | LG | AMBIENT SENSOR SIGNAL |
| 18 | R | A/C AUTO AMP CONNECTION RECOGNITION SIGNAL |
| 19 | R | A/C AUTO AMP CONNECTION RECOGNITION SIGNAL |
| 20 | Y | AMBIENT SENSOR GROUND |


| | | |
|----|----|--|
| 21 | L | CAN-H |
| 22 | P | CAN-L |
| 23 | B | GROUND |
| 24 | B | FUEL LEVEL SENSOR GROUND |
| 25 | BR | PARKING BRAKE SWITCH SIGNAL |
| 26 | Y | BRAKE FLUID LEVEL SWITCH SIGNAL |
| 27 | V | SECURITY SIGNAL |
| 28 | V | WASHER LEVEL SWITCH SIGNAL |
| 29 | G | R/L |
| 31 | SB | VEHICLE SPEED SIGNAL (8-PULSE) |
| 32 | P | OVERDRIVE CONTROL SWITCH SIGNAL |
| 34 | O | FUEL LEVEL SENSOR SIGNAL |
| 35 | P | SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE) |
| 38 | BR | PASSENGER SEAT BELT WARNING SIGNAL |

| | |
|----------------|-----------------|
| Connector No. | M39 |
| Connector Name | CIRCUIT BREAKER |
| Connector Type | IM02FW-P-LC |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | R | - |
| 2 | W | - |

| | |
|----------------|--------------|
| Connector No. | M70 |
| Connector Name | WIRE TO WIRE |
| Connector Type | NS16FBR-CS |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | V | - |
| 2 | R | - |
| 3 | T | - |
| 4 | R | - |
| 5 | G | - |
| 6 | G | - |
| 7 | W/L | - |
| 8 | W/L | - |
| 9 | V | - |
| 10 | R/L | - |
| 11 | SB | - |
| 13 | Y | - |
| 14 | P | - |
| 15 | W | - |


| | |
|----------------|--------------|
| Connector No. | M77 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH80FW-CS18 |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|--|
| 10 | GR | - |
| 12 | V | - |
| 13 | W | - |
| 23 | T | - |
| 30 | P | - |
| 31 | BR | - |
| 37 | SHIELD | - |
| 38 | B | - [Without automatic drive positioner] |
| 38 | W | - [With automatic drive positioner] |
| 39 | B | - [Without automatic drive positioner] |
| 39 | W | - [With automatic drive positioner] |
| 40 | R | - |
| 51 | V | - |
| 52 | B | - |
| 53 | O | - |
| 54 | P | - |
| 55 | L | - |
| 57 | Y | - |
| 58 | L | - |
| 59 | O | - |

| | | |
|----|--------|--|
| 60 | G | - |
| 61 | LG | - |
| 62 | V | - |
| 63 | SB | - |
| 64 | R | - |
| 65 | R | - |
| 66 | SHIELD | - |
| 67 | W/L | - |
| 68 | GR/V | - |
| 69 | SHIELD | - |
| 70 | W/L | - |
| 71 | W/R | - |
| 72 | LG | - |
| 74 | GR | - |
| 75 | G | - |
| 77 | O | - |
| 78 | LG | - |
| 79 | R | - |
| 80 | G | - |
| 81 | L | - |
| 82 | W | - |
| 87 | V | - |
| 88 | R | - |
| 89 | Y | - |
| 90 | P | - [Without automatic drive positioner] |
| 90 | R | - [With automatic drive positioner] |
| 91 | SB | - |
| 92 | P | - |

| | |
|----------------|--------------|
| Connector No. | M79 |
| Connector Name | WIRE TO WIRE |
| Connector Type | TH16FW-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 2 | W | - |
| 3 | B | - |
| 4 | P | - |
| 5 | BR | - |
| 9 | L | - |
| 10 | P | - |

JRKWC6522GB

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


AUTOMATIC SLIDING DOOR SYSTEM

< WIRING DIAGRAM >

AUTOMATIC SLIDING DOOR SYSTEM

| | | |
|---|----|---|
| 1 | SB | - |
| 2 | R | - |
| 3 | Y | - |
| 4 | L | - |
| 5 | G | - |
| 6 | GR | - |

| | |
|----------------|--|
| Connector No. | M80 |
| Connector Name | SLIDING DOOR OPEN / CLOSE SWITCH (FRONT) (SBD) |
| Connector Type | TH11ZFGY-NH |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | L | - |
| 2 | W | - |
| 3 | B | - |
| 4 | R/L | - |
| 5 | G | - |
| 6 | B/R | - |

| | |
|----------------|---------------------------|
| Connector No. | M121 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | TH40FB-NH |




| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 1 | W | REAR WINDOW DEF RELAY CONT |
| 2 | LG | COMBI SW INPUT 5 |
| 3 | Y | COMBI SW INPUT 4 |
| 4 | O | COMBI SW INPUT 3 |
| 5 | G | COMBI SW INPUT 2 |
| 6 | L | COMBI SW INPUT 1 |
| 7 | W | KEY CYL UNLOCK SW |

| | | |
|----|----|----------------------|
| 62 | W | STEP LAMP CONT |
| 63 | R | INT ROOM LAMP CONT |
| 64 | LG | COMBI SW INPUT 3 |
| 65 | Y | ALL DOOR UNLK OUTPUT |
| 66 | G | DR DOOR UNLK OUTPUT |
| 67 | B | GROUND |
| 68 | L | PW PWR SPLY (IGN) |
| 69 | P | PW PWR SPLY (BAT) |
| 70 | L | BAT |

| | | |
|----|----|---|
| 8 | GR | PW SW COMM (With automatic sliding door) KEY CYL LOCK SW (With automatic sliding door) |
| 9 | Y | DOOR LK & UNLK SW LOCK |
| 10 | GR | DOOR LK & UNLK SW UNLOCK |
| 11 | BR | DOOR LK & UNLK SW UNLOCK |
| 12 | L | OPTICAL SENS |
| 13 | W | REAR WINDOW DEF SW |
| 14 | Y | DIMMER |
| 15 | O | SENS PWR SPLY |
| 16 | R | RECEIV/SENS GND |
| 17 | R | NATS ANT AMP |
| 18 | R | SECURITY IND CONT |
| 19 | V | DONGLE LINK |
| 20 | B | NATS ANT AMP |
| 21 | W | A/C ON |
| 22 | O | BLOWER FAN ON |
| 23 | BR | HAZARD SW |
| 24 | P | BK DOOR OPNR SW |
| 25 | L | DR DOOR UNLK SENS |
| 26 | O | COMBI SW OUTPUT 5 |
| 27 | Y | COMBI SW OUTPUT 4 |
| 28 | W | COMBI SW OUTPUT 3 |
| 29 | GR | COMBI SW OUTPUT 2 |
| 30 | SB | COMBI SW OUTPUT 1 |
| 31 | R | DEFENT SW |
| 32 | G | RECEIVER COMM |
| 33 | SB | CAN-H |
| 34 | L | CAN-L |

| | |
|----------------|---------------------------|
| Connector No. | M123 |
| Connector Name | BCM (BODY CONTROL MODULE) |
| Connector Type | FEA08FW-FHA6-SA |



| Terminal No. | Color Of Wire | Signal Name [Specification] |
|--------------|---------------|-----------------------------|
| 56 | P | INT ROOM LAMP PWR SPLY |
| 57 | GR | BAT |
| 58 | O | AIR BAG |
| 59 | SB | PASS DOOR UNLK OUTPUT |
| 60 | V | TURN SIG LH OUTPUT |
| 61 | G | TURN SIG RH OUTPUT |

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000009649036

OVERALL SEQUENCE



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DETAILED FLOW

JMKIA8652GB

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
 - Record DTC and freeze frame data (Print them out using CONSULT.)
 - Erase DTC.
 - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-62. "DTC Inspection Priority Chart"](#) (BCM), and determine trouble diagnosis order.

NOTE:

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-42. "Intermittent Incident"](#).

6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-42. "Intermittent Incident"](#).

8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

< BASIC INSPECTION >

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

AUTOMATIC BACK DOOR SYSTEM

AUTOMATIC BACK DOOR SYSTEM : Description

INFOID:000000009649037

When the battery is disconnected from the negative terminal, it is necessary to perform initial setting to operate automatic back door system normally.

CAUTION:

The following specified operations are not performed under the non-initialized condition.

- Automatic back door open/close function
- Anti-pinch function

AUTOMATIC BACK DOOR SYSTEM : Work Procedure

INFOID:000000009649038

1. INITIALIZATION

1. Fully close the back door manually. (when back door is already fully closed, this operation is not necessary)
2. Perform automatic back door open/close operation of back door.
3. Check for noise or malfunctioning during operation.
4. Check that hazard lamp blinks and that warning buzzer operates.

CAUTION:

Never touch back door, or allow foreign materials to be pinched in door, when performing automatic back door open/close operation of back door, until it is in the fully closed or fully open position.

>> WORK END

AUTOMATIC SLIDING DOOR SYSTEM

AUTOMATIC SLIDING DOOR SYSTEM : Description

INFOID:000000009649039

When the battery is disconnected from the negative terminal, it is necessary to perform initial setting to operate automatic sliding door system normally.

CAUTION:

Be careful of sliding door that does not operate smoothly in the non-initialized status because door speed is constant during automatic open/close operation. Also, be careful of high reverse load.

AUTOMATIC SLIDING DOOR SYSTEM : Work Procedure

INFOID:000000009649040

1. INITIALIZATION

1. Operate automatic sliding door open/close switch or automatic sliding door one-touch open/close switch, and the automatic open function operates. (Perform open operation first in the non-initialized status regardless of sliding door position)
2. After sliding door is stopped in the fully open position, operate automatic sliding door open/close switch or automatic sliding door one-touch open/close switch, and the automatic close function operates.
3. Check for noise or malfunctioning during operation.
4. Check that automatic sliding door warning buzzer operates.

CAUTION:

Never touch sliding door, or allow foreign materials to be pinched in door, when performing automatic open/close operation of sliding door, until it is in the fully closed or fully open position.

>> WORK END

ADDITIONAL SERVICE WHEN REPLACING AUTOMATIC BACK DOOR CONTROL MODULE

< BASIC INSPECTION >

ADDITIONAL SERVICE WHEN REPLACING AUTOMATIC BACK DOOR CONTROL MODULE

Description

INFOID:000000009649041

When replacing control module, or removing connector terminal, it is necessary to perform initial setting to operate automatic back door system normally.

CAUTION:

The following specified operations are not performed under the non-initialized condition.

- Automatic back door open/close function
- Anti-pinch function

Work Procedure

INFOID:000000009649042

1. INITIALIZATION

1. Fully close the back door manually. (when back door is already fully closed, this operation is not necessary)
2. Perform automatic back door open/close operation of back door.
3. Check for noise or malfunctioning during operation.
4. Check that hazard lamp blinks and that warning buzzer operates.

CAUTION:

Never touch back door, or allow foreign materials to be pinched in door, when performing automatic back door open/close operation of back door, until it is in the fully closed or fully open position.

>> WORK END

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

ADDITIONAL SERVICE WHEN REPLACING SLIDING DOOR CONTROL UNIT

< BASIC INSPECTION >

ADDITIONAL SERVICE WHEN REPLACING SLIDING DOOR CONTROL UNIT

Description

INFOID:000000009649043

When replacing control module, or removing connector terminal, it is necessary to perform initial setting to operate automatic sliding door system normally.

CAUTION:

Be careful of sliding door that does not operate smoothly in the non-initialized status because door speed is constant during automatic open/close operation. Also, be careful of high reverse load.

Work Procedure

INFOID:000000009649044

1. INITIALIZATION

1. Operate automatic sliding door open/close switch or automatic sliding door one-touch open/close switch, and the automatic open function operates. (Perform open operation first in the non-initialized status regardless of sliding door position)
2. After sliding door is stopped in the fully open position, operate automatic sliding door open/close switch or automatic sliding door one-touch open/close switch, and the automatic close function operates.
3. Check for noise or malfunctioning during operation.
4. Check that automatic sliding door warning buzzer operates.

CAUTION:

Never touch sliding door, or allow foreign materials to be pinched in door, when performing automatic open/close operation of sliding door, until it is in the fully closed or fully open position.

>> WORK END

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

AUTOMATIC BACK DOOR CONTROL MODULE

AUTOMATIC BACK DOOR CONTROL MODULE : Description

INFOID:000000009649045

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-32. "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

AUTOMATIC BACK DOOR CONTROL MODULE : DTC Logic

INFOID:000000009649046

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|---|--------------------------|
| U1000 | CAN COMM | When automatic back door control unit cannot communicate CAN communication signal continuously for 2 seconds or more. | CAN communication system |

AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure

INFOID:000000009649047

1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" of "AUTO BACK DOOR".

Is "CAN COMM CIRCUIT" displayed?

YES >> Refer to [LAN-17. "Trouble Diagnosis Flow Chart"](#).

NO >> Refer to [GI-42. "Intermittent Incident"](#).

SLIDING DOOR LH

SLIDING DOOR LH : Description

INFOID:000000009649048

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-32. "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

SLIDING DOOR LH : DTC Logic

INFOID:000000009649049

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--------------------------|
| U1000 | CAN COMM | When sliding door control unit cannot communicate CAN communication signal continuously for 2 seconds or more. | CAN communication system |

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649050

1.PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR" using CONSULT.

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).
NO >> Refer to [GI-42, "Intermittent Incident"](#).

SLIDING DOOR RH

SLIDING DOOR RH : Description

INFOID:000000009649051

CAN (Controller Area Network) is a serial communication line for real time applications. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Modern vehicle is equipped with many electronic control unit, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H-line, CAN L-line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

CAN Communication Signal Chart. Refer to [LAN-32, "CAN COMMUNICATION SYSTEM : CAN Communication Signal Chart"](#).

SLIDING DOOR RH : DTC Logic

INFOID:000000009649052

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--------------------------|
| U1000 | CAN COMM | When sliding door control unit cannot communicate CAN communication signal continuously for 2 seconds or more. | CAN communication system |

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649053

1.PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR RIGHT" using CONSULT.

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).
NO >> Refer to [GI-42, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

AUTOMATIC BACK DOOR CONTROL MODULE

AUTOMATIC BACK DOOR CONTROL MODULE : DTC Logic

INFOID:000000009649054

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|------------------------------------|
| U1010 | CONTROL UNIT (CAN) | Automatic back door control unit detected internal CAN communication circuit malfunction | Automatic back door control module |

AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure

INFOID:000000009649055

1. REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

When DTC [U1010] is detected, replace automatic back door control module.

>> Replace automatic back door control module. Refer to [DLK-495. "Removal and Installation"](#).

SLIDING DOOR LH

SLIDING DOOR LH : DTC Logic

INFOID:000000009649056

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|------------------------------|
| U1010 | CONTROL UNIT (CAN) | Sliding door control unit LH detected internal CAN communication circuit malfunction | Sliding door control unit LH |

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649057

1. REPLACE SLIDING DOOR CONTROL UNIT

When DTC [U1010] is detected, replace sliding door control unit LH.

>> Replace sliding door control unit LH. Refer to [DLK-500. "LH : Removal and Installation"](#).

SLIDING DOOR RH

SLIDING DOOR RH : DTC Logic

INFOID:000000009649058

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|------------------------------|
| U1010 | CONTROL UNIT (CAN) | Sliding door control unit RH detected internal CAN communication circuit malfunction | Sliding door control unit RH |

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649059

1. REPLACE SLIDING DOOR CONTROL UNIT

When DTC [U1010] is detected, replace sliding door control unit RH.

>> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

B2401 IGNITION POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

B2401 IGNITION POWER SUPPLY CIRCUIT AUTOMATIC BACK DOOR CONTROL MODULE

AUTOMATIC BACK DOOR CONTROL MODULE : DTC Logic

INFOID:000000009649060

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|---|---|
| B2401 | IGN OPEN | When the automatic back door control unit detects the following condition for 0.3 second or more • Power supply condition (OFF) of automatic back door control unit and Ignition position signal (ON) from BCM via CAN | <ul style="list-style-type: none">• Fuse• Harness or connectors (Ignition power supply condition circuit is open or shorted) |

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait for at least 1 second.
2. Check "Self Diagnostic Result" mode of "AUTO BACK DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-174, "AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure"](#).
NO >> INSPECTION END

AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure

INFOID:000000009649061

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10 A fuse, [No. 3, located in fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic back door control module connector.
3. Check voltage between automatic back door control module harness connector and ground.

| (+) | | (-) | Condition | | Voltage |
|--|----------|--------|-----------|--------------------|-----------------|
| Automatic back door control module Connector | Terminal | | Ground | Ignition switch ON | |
| B8 | 7 | Ground | | | Ignition switch |

Is the measurement value normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> Repair or replace harness.

SLIDING DOOR LH

SLIDING DOOR LH : DTC Logic

INFOID:000000009649062

DTC DETECTION LOGIC

B2401 IGNITION POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2401 | IGN OPEN | When the sliding door control unit detects the following condition for 0.3 second or more <ul style="list-style-type: none"> Power supply condition (OFF) of sliding door control unit and ignition position signal (ON) from BCM via CAN | <ul style="list-style-type: none"> Fuse Harness or connectors (Ignition power supply condition circuit is open or shorted) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-175. "SLIDING DOOR LH : Diagnosis Procedure"](#).
 NO >> INSPECTION END

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649063

1. CHECK FUSE

- Turn ignition switch OFF.
- Check 10A fuse, [No. 3, located in fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2. CHECK POWER SUPPLY CIRCUIT

- Turn ignition switch OFF.
- Disconnect sliding door control unit LH connector.
- Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Condition | | Voltage |
|--|----------|--------|-----------------|----|---------|
| Sliding door control unit LH Connector | Terminal | | Ignition switch | ON | |
| B45 | 6 | Ground | | | ON |

Is the measurement value normal?

- YES >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).
 NO >> Repair or replace harness.

SLIDING DOOR RH

SLIDING DOOR RH : DTC Logic

INFOID:000000009649064

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2401 | IGN OPEN | When the sliding door control unit detects the following condition for 0.3 second or more <ul style="list-style-type: none"> Power supply condition (OFF) of sliding door control unit and ignition position signal (ON) from BCM via CAN | <ul style="list-style-type: none"> Fuse Harness or connectors (Ignition power supply condition circuit is open or shorted) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR RIGHT" using CONSULT.

B2401 IGNITION POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Is DTC detected?

- YES >> Refer to [DLK-176, "SLIDING DOOR RH : Diagnosis Procedure"](#).
NO >> INSPECTION END

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649065

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10A fuse, [No. 3, located in fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sliding door control unit RH connector.
3. Check voltage between sliding door control unit RH harness connector and ground.

| (+) Sliding door control unit RH | | (-) | Condition | | Voltage |
|----------------------------------|----------|--------|-----------------|----|----------|
| Connector | Terminal | | | | |
| B247 | 6 | Ground | Ignition switch | ON | 9 – 16 V |

Is the measurement value normal?

- YES >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).
NO >> Repair or replace harness.

B2402 TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

B2402 TOUCH SENSOR SLIDING DOOR LH

SLIDING DOOR LH : DTC Logic

INFOID:000000009649066

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2402 | TOUCH SENSOR OPEN | When the sliding door control unit detects the open circuit of the sliding door touch sensor | <ul style="list-style-type: none"> Sliding door touch sensor Harness or connector (Sliding door touch sensor circuit is open) Sliding door control unit |

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-177. "SLIDING DOOR LH : Diagnosis Procedure"](#).
 NO >> INSPECTION END

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649067

1.CHECK SLIDING DOOR TOUCH SENSOR INPUT SIGNAL

- Turn ignition switch OFF.
- Check voltage between sliding door touch sensor LH harness connector and sliding door control unit LH harness connector.

| (+) | | (-) | | Condition | Voltage | |
|------------------------------|----------|------------------------------|----------|------------------------------|--------------------|-----------|
| Sliding door touch sensor LH | | Sliding door control unit LH | | | | |
| Connector | Terminal | Connector | Terminal | | | |
| D172 | 1 | B45 | 23 | Sliding door touch sensor LH | Pinching detection | 0 – 1.5 V |
| | | | | | Other than above | 4 – 8 V |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK SLIDING DOOR TOUCH SENSOR CIRCUIT

- Disconnect sliding door control unit LH connector and sliding door touch sensor LH connector.
- Check continuity between sliding door control unit LH harness connector and sliding door touch sensor LH harness connector.

| Sliding door control unit LH | | Sliding door touch sensor LH | | Continuity |
|------------------------------|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 24 | D172 | 1 | Existed |

- Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 24 | | Not existed |

Is the inspection result normal?

B2402 TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace sliding door control unit LH. Refer to [DLK-500. "LH : Removal and Installation"](#).
 NO >> Repair or replace harness.

3.CHECK SLIDING DOOR TOUCH SENSOR GROUND CIRCUIT

1. Disconnect sliding door control unit LH connector and sliding door touch sensor LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door touch sensor LH harness connector.

| Sliding door control unit LH | | Sliding door touch sensor LH | | Continuity |
|------------------------------|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 23 | D172 | 2 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK SLIDING DOOR TOUCH SENSOR CIRCUIT 2

1. Connect sliding door control unit LH connector and sliding door touch sensor LH connector.
2. Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B45 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace sliding door control unit LH. Refer to [DLK-500. "LH : Removal and Installation"](#).

5.CHECK SLIDING DOOR TOUCH SENSOR

Refer to [DLK-180. "SLIDING DOOR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Replace sliding door touch sensor LH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR LH : Component Inspection

INFOID:000000009649068

1.CHECK SLIDING DOOR TOUCH SENSOR LH

1. Turn ignition switch OFF.
2. Disconnect sliding door touch sensor LH connector.
3. Check resistance between sliding door touch sensor LH terminals.

| Sliding door touch sensor LH | | Condition | | Resistance (Approx.) |
|------------------------------|---|------------------------------|--------------------|----------------------|
| Terminal | | | | |
| 1 | 2 | Sliding door touch sensor LH | Pinching detection | 120 Ω or less |
| | | | Other than above | 1 kΩ ± 10% |

B2402 TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace sliding door touch sensor LH.

SLIDING DOOR RH

SLIDING DOOR RH : DTC Logic

INFOID:000000009649069

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2402 | TOUCH SENSOR OPEN | When the sliding door control unit detects the open circuit of the sliding door touch sensor | <ul style="list-style-type: none"> Sliding door touch sensor Harness or connector (Sliding door touch sensor circuit is open) Sliding door control unit |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON
- Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR RIGHT" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-179, "SLIDING DOOR RH : Diagnosis Procedure"](#).
 NO >> INSPECTION END

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649070

1. CHECK SLIDING DOOR TOUCH SENSOR INPUT SIGNAL

- Turn ignition switch OFF.
- Check voltage between sliding door touch sensor RH harness connector and sliding door control unit RH harness connector.

| (+) | | (-) | | Condition | Voltage | |
|------------------------------|----------|------------------------------|----------|------------------------------|--------------------|-----------|
| Sliding door touch sensor RH | | Sliding door control unit RH | | | | |
| Connector | Terminal | Connector | Terminal | | | |
| D173 | 1 | B247 | 23 | Sliding door touch sensor RH | Pinching detection | 0 – 1.5 V |
| | | | | Other than above | 4 – 8 V | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK SLIDING DOOR TOUCH SENSOR CIRCUIT

- Disconnect sliding door control unit RH connector and sliding door touch sensor RH connector.
- Check continuity between sliding door control unit RH harness connector and sliding door touch sensor RH harness connector.

| Sliding door control unit RH | | Sliding door touch sensor RH | | Continuity |
|------------------------------|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 24 | D173 | 1 | Existed |

- Check continuity between sliding door control unit RH harness connector and ground.

B2402 TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 24 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit RH. Refer to [DLK-500, "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK SLIDING DOOR TOUCH SENSOR GROUND CIRCUIT

1. Disconnect sliding door control unit RH connector and sliding door touch sensor RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door touch sensor RH harness connector.

| Sliding door control unit RH | | Sliding door touch sensor RH | | Continuity |
|------------------------------|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 23 | D173 | 2 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 23 | | Not existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK SLIDING DOOR TOUCH SENSOR CIRCUIT 2

1. Connect sliding door control unit RH connector and sliding door touch sensor RH connector.
2. Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | | |
| B247 | 23 | Ground | 0 V |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace sliding door control unit RH. Refer to [DLK-500, "LH : Removal and Installation"](#).

5. CHECK SLIDING DOOR TOUCH SENSOR

Refer to [DLK-180, "SLIDING DOOR RH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace sliding door touch sensor RH.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH : Component Inspection

INFOID:000000009649071

1. CHECK SLIDING DOOR TOUCH SENSOR RH

1. Turn ignition switch OFF.
2. Disconnect sliding door touch sensor RH connector.
3. Check resistance between sliding door touch sensor RH terminals.

B2402 TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door touch sensor RH | | Condition | | Resistance (Approx.) |
|------------------------------|---|------------------------------|--------------------|-------------------------|
| Terminal | | | | |
| 1 | 2 | Sliding door touch sensor RH | Pinching detection | 120 Ω or less |
| | | | Other than above | 1 kΩ ± 10% |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sliding door touch sensor RH.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2403 ENCODER

< DTC/CIRCUIT DIAGNOSIS >

B2403 ENCODER

AUTOMATIC BACK DOOR CONTROL MODULE

AUTOMATIC BACK DOOR CONTROL MODULE : DTC Logic

INFOID:000000009649072

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|---|--|
| B2403 | PULSE ENCODER | When the automatic back door control unit cannot receive the signal from the encoder just after starting the open/close operation | <ul style="list-style-type: none">Battery voltage (low battery)Automatic back door control module |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Operate automatic back door.
- Check "Self Diagnostic Result" mode of "AUTO BACK DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-182, "AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure"](#).
NO >> INSPECTION END

AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure

INFOID:000000009649073

1. CHECK AUTOMATIC BACK DOOR CONTROL MODULE POWER SUPPLY AND GROUND CIRCUIT

- Turn ignition switch OFF.
- Check automatic back door control module power supply and ground circuit.
Refer to [DLK-238, "AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
NO >> Repair or replace the malfunctioning parts.

SLIDING DOOR LH

SLIDING DOOR LH : DTC Logic

INFOID:000000009649074

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|---|
| B2403 | PULSE ENCODER | When sliding door control unit cannot receive the signal from the encoder just after starting the open/close operation | <ul style="list-style-type: none">EncoderBattery voltage (low battery)Sliding door control unit |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-182, "SLIDING DOOR LH : Diagnosis Procedure"](#).
NO >> INSPECTION END

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649075

1. CHECK ENCODER POWER SUPPLY

- Turn ignition switch OFF.

B2403 ENCODER

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect automatic sliding door unit LH connector.
3. Check voltage between automatic sliding door unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|--------------------------------|----------|--------|----------|
| Automatic sliding door unit LH | | | |
| Connector | Terminal | | |
| B65 | 5 | Ground | 8 – 16 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK ENCODER CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 11 | B65 | 5 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 11 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK ENCODER CIRCUIT 2

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 4 | B65 | 6 | Existed |
| | 21 | | 7 | |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|-------------|-------------|
| Connector | Terminal | | |
| B45 | 4 | | Not existed |
| | 21 | Not existed | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK ENCODER GROUND CIRCUIT

1. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

B2403 ENCODER

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 26 | B65 | 8 | Existed |

- Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 26 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace harness.

5.CHECK ENCODER CIRCUIT 3

- Connect sliding door control unit LH connector and automatic sliding door unit LH connector.
- Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B45 | 26 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH

SLIDING DOOR RH : DTC Logic

INFOID:000000009649076

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|---|
| B2403 | PULSE ENCODER | When sliding door control unit cannot receive the signal from the encoder just after starting the open/close operation | <ul style="list-style-type: none"> Encoder Battery voltage (low battery) Sliding door control unit |

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR RIGHT" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-184, "SLIDING DOOR RH : Diagnosis Procedure"](#).
 NO >> INSPECTION END

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649077

1.CHECK ENCODER POWER SUPPLY

- Turn ignition switch OFF.
- Disconnect automatic sliding door unit RH connector.

B2403 ENCODER

< DTC/CIRCUIT DIAGNOSIS >

3. Check voltage between automatic sliding door unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|--------------------------------|----------|--------|----------|
| Automatic sliding door unit RH | | | |
| Connector | Terminal | | |
| B244 | 5 | Ground | 8 – 16 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK ENCODER CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 11 | B244 | 5 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 11 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK ENCODER CIRCUIT 2

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 4 | B244 | 7 | Existed |
| | 21 | | 6 | |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 4 | | Not existed |
| | 21 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK ENCODER GROUND CIRCUIT

1. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

B2403 ENCODER

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 26 | B244 | 8 | Existed |

2. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 26 | | Not existed |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK ENCODER CIRCUIT 3

1. Connect sliding door control unit RH connector and automatic sliding door unit RH connector.
2. Check voltage between sliding door control unit RH harness connector and ground.

| (+) Sliding door control unit RH | | (-) | Voltage |
|----------------------------------|----------|--------|---------|
| Connector | Terminal | | |
| B247 | 26 | Ground | 0 V |

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

B2405 SLIDING DOOR CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

B2405 SLIDING DOOR CONTROL UNIT SLIDING DOOR LH

SLIDING DOOR LH : DTC Logic

INFOID:000000009649078

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|---------------------------|
| B2405 | ECU FAIL | Sliding door control unit detected CPU malfunction | Sliding door control unit |

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649079

1. REPLACE SLIDING DOOR CONTROL UNIT

When DTC [B2405] is detected, replace sliding door control unit LH.

>> Replace sliding door control unit. Refer to [DLK-500, "LH : Removal and Installation"](#).

SLIDING DOOR RH

SLIDING DOOR RH : DTC Logic

INFOID:000000009649080

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|---------------------------|
| B2405 | ECU FAIL | Sliding door control unit detected CPU malfunction | Sliding door control unit |

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649081

1. REPLACE SLIDING DOOR CONTROL UNIT

When DTC [B2405] is detected, replace sliding door control unit RH.

>> Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2409 HALF LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

B2409 HALF LATCH SWITCH

AUTOMATIC BACK DOOR CONTROL MODULE

AUTOMATIC BACK DOOR CONTROL MODULE : DTC Logic

INFOID:000000009649082

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|---|--|
| B2409 | HALF LATCH SW | When the automatic back door control unit can not detect the half latch switch ON condition even when the back door is in the open position | <ul style="list-style-type: none">• Half latch switch• Harness or connectors (Half latch switch circuit is open)• Automatic back door control module |

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Operate automatic back door function.
3. Check "Self Diagnostic Result" mode of "AUTO BACK DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-188. "AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure"](#).
NO >> INSPECTION END

AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure

INFOID:000000009649083

1.CHECK HALF LATCH SWITCH SIGNAL

1. Select "AUTO BACK DOOR" using CONSULT.
2. Select "HALF LATCH SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | Status | |
|---------------|-----------|-------------------------|-----|
| HALF LATCH SW | Back door | Fully closed/Half latch | OFF |
| | | Open | ON |

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 2.

2.CHECK HALF LATCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check voltage between back door lock assembly harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------|----------|--------|----------|
| Back door lock assembly | | | |
| Connector | Terminal | | |
| D190 | 6 | Ground | 9 - 16 V |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

3.CHECK HALF LATCH SWITCH CIRCUIT

1. Disconnect automatic back door control module connector.
2. Check continuity between automatic back door control module harness connector and back door lock assembly harness connector.

B2409 HALF LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Automatic back door control module | | Back door lock assembly | | Continuity |
|------------------------------------|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 22 | D190 | 6 | Existed |

3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 22 | | Not existed |

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
 NO >> Repair or replace harness.

4.CHECK HALF LATCH SWITCH GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

| Back door lock assembly | | Ground | Continuity |
|-------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D190 | 8 | | Existed |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace back door lock assembly ground circuit.

5.CHECK HALF LATCH SWITCH

Refer to [DLK-189, "AUTOMATIC BACK DOOR CONTROL MODULE : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Replace back door lock assembly.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

AUTOMATIC BACK DOOR CONTROL MODULE : Component Inspection INFOID:000000009649084

1.CHECK HALF LATCH SWITCH

- Turn ignition switch OFF.
- Disconnect back door lock assembly connector.
- Check continuity between back door lock assembly terminals.

| Back door lock assembly | | Condition | Continuity | |
|-------------------------|---|----------------|-------------------------|-------------|
| Terminal | | | | |
| 6 | 8 | Back door lock | Open | Existed |
| | | | Fully closed/Half latch | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace back door lock assembly.

SLIDING DOOR LH

SLIDING DOOR LH : DTC Logic

INFOID:000000009649085

DTC DETECTION LOGIC

B2409 HALF LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|---|
| B2409 | HALF LATCH SW | When the sliding door control unit cannot detects the half latch switch ON condition even when the sliding door release actuator operate | <ul style="list-style-type: none"> • Half latch switch • Harness or connectors (Half latch switch circuit is open) • Sliding door control unit |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-190, "SLIDING DOOR LH : Diagnosis Procedure"](#).
 NO >> INSPECTION END

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649086

1. CHECK HALF LATCH SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly LH connector.
3. Check voltage between sliding door lock assembly LH harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------------|----------|--------|----------|
| Sliding door lock assembly LH | | | |
| Connector | Terminal | | |
| D123 | 3 | Ground | 8 – 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK HALF LATCH SWITCH CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door lock assembly LH harness connector.

| Sliding door control unit LH | | Sliding door lock assembly LH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 5 | D123 | 3 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 5 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).
 NO >> Repair or replace harness.

3. CHECK HALF LATCH SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door lock assembly LH harness connector.

B2409 HALF LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit LH | | Sliding door lock assembly LH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 23 | D123 | 2 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK HALF LATCH SWITCH CIRCUIT 2

- Connect sliding door control unit LH connector and sliding door lock assembly LH connector.
- Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B45 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door control unit LH. Refer to [DLK-500. "LH : Removal and Installation"](#).

5.CHECK HALF LATCH SWITCH

Refer to [DLK-191. "SLIDING DOOR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace sliding door lock assembly LH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR LH : Component Inspection

INFOID:000000009649087

1.CHECK HALF LATCH SWITCH

- Turn ignition switch OFF.
- Disconnect sliding door lock assembly LH connector.
- Check continuity between sliding door lock assembly LH terminals.

| Sliding door lock assembly LH | | Condition | Continuity |
|-------------------------------|---|-----------------|-------------|
| Terminal | | | |
| 3 | 2 | Sliding door LH | Existed |
| | | | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace sliding door lock assembly LH.

SLIDING DOOR RH

B2409 HALF LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR RH : DTC Logic

INFOID:000000009649088

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|---|
| B2409 | HALF LATCH SW | When the sliding door control unit cannot detects the half latch switch ON condition even when the sliding door release actuator operate | <ul style="list-style-type: none">• Half latch switch• Harness or connectors (Half latch switch circuit is open)• Sliding door control unit |

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR RIGHT" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-192. "SLIDING DOOR RH : Diagnosis Procedure"](#).
NO >> INSPECTION END

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649089

1.CHECK HALF LATCH SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly RH connector.
3. Check voltage between sliding door lock assembly RH harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------------|----------|--------|----------|
| Sliding door lock assembly RH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| D124 | 3 | | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK HALF LATCH SWITCH CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door lock assembly RH harness connector.

| Sliding door control unit RH | | Sliding door lock assembly RH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 5 | D124 | 3 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 5 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK HALF LATCH SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit RH connector.

B2409 HALF LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between sliding door control unit RH harness connector and sliding door lock assembly RH harness connector.

| Sliding door control unit RH | | Sliding door lock assembly RH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 23 | D124 | 2 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK HALF LATCH SWITCH CIRCUIT 2

1. Connect sliding door control unit RH connector and sliding door lock assembly RH connector.
2. Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | | |
| B247 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace sliding door control unit RH. Refer to [DLK-500, "RH : Removal and Installation"](#).

5.CHECK HALF LATCH SWITCH

Refer to [DLK-193, "SLIDING DOOR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Replace sliding door lock assembly RH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH : Component Inspection

INFOID:000000009649090

1.CHECK HALF LATCH SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly RH connector.
3. Check continuity between sliding door lock assembly RH terminals.

| Sliding door lock assembly RH | | Condition | Continuity |
|-------------------------------|---|-----------------|---------------------------------------|
| Terminal | | | |
| 3 | 2 | Sliding door RH | Open Existed |
| | | | Half latch/full closed Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace sliding door lock assembly RH.

B241A ENCODER

< DTC/CIRCUIT DIAGNOSIS >

B241A ENCODER SLIDING DOOR LH

SLIDING DOOR LH : DTC Logic

INFOID:000000009649091

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|---|
| B241A | ENCDR PWR SUPPLY | When battery voltage to encoder is 4.5 V or less | <ul style="list-style-type: none">EncoderHarness or connectorsSliding door control unit |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR" using CONSULT.

Is DTC detected?

YES >> Refer to [DLK-194, "SLIDING DOOR LH : Diagnosis Procedure"](#).

NO >> INSPECTION END

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649092

1. CHECK ENCODER POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect automatic sliding door unit LH connector.
3. Check voltage between automatic sliding door unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| B65 | 5 | Ground | 8 – 16 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK ENCODER CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 11 | B65 | 5 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 11 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

B241A ENCODER

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH

SLIDING DOOR RH : DTC Logic

INFOID:000000009649093

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|---|
| B241A | ENCDR PWR SUPPLY | When battery voltage to encoder is 4.5 V or less | <ul style="list-style-type: none"> Encoder Harness or connectors Sliding door control unit |

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR RIGHT" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-195. "SLIDING DOOR RH : Diagnosis Procedure"](#).
 NO >> INSPECTION END

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649094

1.CHECK ENCODER POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect automatic sliding door unit RH connector.
3. Check voltage between automatic sliding door unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|--------------------------------|----------|--------|----------|
| Automatic sliding door unit RH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| B247 | 11 | | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK ENCODER CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 11 | B244 | 5 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 11 | | Not existed |

Is the inspection result normal?

B241A ENCODER

< DTC/CIRCUIT DIAGNOSIS >

YES >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

B2412 AUTOMATIC SLIDING DOOR MOTOR/ENCODER

< DTC/CIRCUIT DIAGNOSIS >

B2412 AUTOMATIC SLIDING DOOR MOTOR/ENCODER SLIDING DOOR LH

SLIDING DOOR LH : DTC Logic

INFOID:000000009649095

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2412 | ASD MTR/ENCDR | When sliding door control unit transmits signal to automatic sliding door motor but pulse signal from encoder is not detected for 1 second or more | <ul style="list-style-type: none">• Sliding door motor• Encoder• Harness or connectors |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR" using CONSULT.

Is DTC detected?

YES >> Refer to [DLK-197. "SLIDING DOOR LH : Diagnosis Procedure"](#).

NO >> INSPECTION END

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649096

1. CHECK ENCODER MONITOR ITEM

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "ENCODER A LH" and "ENCODER B LH" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | Status | |
|--------------|-----------------|-------------------------|----------|
| ENCODER A LH | Sliding door LH | Moving (auto or manual) | HI ↔ LO |
| | | When stopped | HI or LO |
| ENCODER B LH | Sliding door LH | Moving (auto or manual) | HI ↔ LO |
| | | When stopped | HI or LO |

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 2.

2. CHECK ENCODER POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect automatic sliding door unit LH connector.
3. Check voltage between automatic sliding door unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| B65 | 5 | Ground | 8 – 16 V |

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK ENCODER CIRCUIT 1

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

B2412 AUTOMATIC SLIDING DOOR MOTOR/ENCODER

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 11 | B65 | 5 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 11 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

4.CHECK ENCODER CIRCUIT 2

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 4 | B65 | 6 | Existed |
| | 21 | | 7 | |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 4 | | Not existed |
| | 21 | | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK ENCODER GROUND CIRCUIT

1. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 26 | B65 | 8 | Existed |

2. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 26 | | Not existed |

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6.CHECK ENCODER CIRCUIT 3

1. Connect sliding door control unit LH connector and automatic sliding door unit LH connector.
2. Check voltage between sliding door control unit LH harness connector and ground.

B2412 AUTOMATIC SLIDING DOOR MOTOR/ENCODER

< DTC/CIRCUIT DIAGNOSIS >

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | Ground | 0 V |
| B45 | 26 | | |

Is the inspection result normal?

YES >> Replace automatic sliding door unit LH.

NO >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

7. CHECK AUTOMATIC SLIDING DOOR MOTOR CIRCUIT

1. Disconnect sliding door control unit LH connector and automatic sliding door unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B47 | 43 | B33 | 3 | Existed |
| | 46 | | 4 | |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B47 | 43 | | Not existed |
| | 46 | | |

Is the inspection result normal?

YES >> Replace automatic sliding door unit LH.

NO >> Repair or replace harness.

SLIDING DOOR RH

SLIDING DOOR RH : DTC Logic

INFOID:000000009649097

DLK

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2412 | ASD MTR/ENCDR | When sliding door control unit transmits signal to automatic sliding door motor but pulse signal from encoder is not detected for 1 second or more | <ul style="list-style-type: none"> • Sliding door motor • Encoder • Harness or connectors |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR RIGHT" using CONSULT.

Is DTC detected?

YES >> Refer to [DLK-199, "SLIDING DOOR RH : Diagnosis Procedure"](#).

NO >> INSPECTION END

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649098

1. CHECK ENCODER MONITOR ITEM

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "ENCODER A RH" and "ENCODER B RH" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

B2412 AUTOMATIC SLIDING DOOR MOTOR/ENCODER

< DTC/CIRCUIT DIAGNOSIS >

| Monitor item | Condition | | Status |
|--------------|-----------------|-------------------------|----------|
| ENCODER A RH | Sliding door RH | Moving (auto or manual) | HI ⇔ LO |
| | | When stopped | HI or LO |
| ENCODER B RH | Sliding door RH | Moving (auto or manual) | HI ⇔ LO |
| | | When stopped | HI or LO |

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 2.

2. CHECK ENCODER POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect automatic sliding door unit RH connector.
3. Check voltage between automatic sliding door unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| B244 | 5 | Ground | 8 – 16 V |

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

3. CHECK ENCODER CIRCUIT 1

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 11 | B244 | 5 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 11 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit RH. Refer to [DLK-500, "RH : Removal and Installation"](#).

NO >> Repair or replace harness.

4. CHECK ENCODER CIRCUIT 2

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 4 | B244 | 7 | Existed |
| | 21 | | 6 | |

3. Check continuity between sliding door control unit RH harness connector and ground.

B2412 AUTOMATIC SLIDING DOOR MOTOR/ENCODER

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 4 | | |
| | 21 | | Not existed |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK ENCODER GROUND CIRCUIT

1. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 26 | B244 | 8 | Existed |

2. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B247 | 26 | | |

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace harness.

6.CHECK ENCODER CIRCUIT 3

1. Connect sliding door control unit RH connector and automatic sliding door unit RH connector.
2. Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | | |
| B247 | 26 | Ground | 0 V |

Is the inspection result normal?

YES >> Replace automatic sliding door unit RH.

NO >> Replace sliding door control unit RH. Refer to [DLK-500, "RH : Removal and Installation"](#).

7.CHECK AUTOMATIC SLIDING DOOR MOTOR CIRCUIT

1. Disconnect sliding door control unit RH connector and automatic sliding door unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B249 | 43 | B245 | 4 | Existed |
| | 46 | | 3 | |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B249 | 43 | | |
| | 46 | | Not existed |

B2412 AUTOMATIC SLIDING DOOR MOTOR/ENCODER

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace automatic sliding door unit RH.

NO >> Repair or replace harness.

B2413 AUTOMATIC SLIDING DOOR MOTOR/ENCODER

< DTC/CIRCUIT DIAGNOSIS >

B2413 AUTOMATIC SLIDING DOOR MOTOR/ENCODER SLIDING DOOR LH

SLIDING DOOR LH : DTC Logic

INFOID:000000009649099

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|---|
| B2413 | ASD MTR/ENCDR | When sliding door control unit detects pulse signal that is in the reverse direction of sliding door motor operation | <ul style="list-style-type: none"> Reverse connection of harness between encoder and sliding door control unit Reverse connection of harness between automatic sliding door motor and sliding door control unit Encoder Automatic sliding door motor Sliding door control unit |

DTC CONFIRMATION PROCEDURE

1.PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-203. "SLIDING DOOR LH : Diagnosis Procedure"](#).
NO >> INSPECTION END

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649100

1.CHECK ENCODER CIRCUIT

- Turn ignition switch OFF.
- Disconnect sliding door control unit LH connector and automatic sliding door unit LH connector.
- Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|-------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 4 | B65 | 6 | Existed |
| | 21 | | 7 | |
| | 4 | | 7 | Not existed |
| | 21 | | 6 | |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace harness.

2.CHECK AUTOMATIC SLIDING DOOR MOTOR CIRCUIT

Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

B2413 AUTOMATIC SLIDING DOOR MOTOR/ENCODER

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|-------------|
| Connector | Terminal | Connector | Terminal | |
| B47 | 43 | B33 | 3 | Existed |
| | 46 | | 4 | |
| | 43 | | 4 | Not existed |
| | 46 | | 3 | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK AUTOMATIC SLIDING DOOR UNIT LH

1. Replace automatic sliding door unit LH. (New unit or other unit)
2. Erase DTC.
3. Operate auto open/close function.

Is DTC detected?

YES >> Replace sliding door control unit LH. Refer to [DLK-500. "LH : Removal and Installation"](#).

NO >> INSPECTION END

SLIDING DOOR RH

SLIDING DOOR RH : DTC Logic

INFOID:000000009649101

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|---|
| B2413 | ASD MTR/ENCDR | When sliding door control unit detects pulse signal that is in the reverse direction of sliding door motor operation | <ul style="list-style-type: none"> • Reverse connection of harness between encoder and sliding door control unit • Reverse connection of harness between automatic sliding door motor and sliding door control unit • Encoder • Automatic sliding door motor • Sliding door control unit |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR RIGHT" using CONSULT.

Is DTC detected?

YES >> Refer to [DLK-204. "SLIDING DOOR RH : Diagnosis Procedure"](#).

NO >> INSPECTION END

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649102

1. CHECK ENCODER CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sliding door control unit RH connector and automatic sliding door unit RH connector.
3. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

B2413 AUTOMATIC SLIDING DOOR MOTOR/ENCODER

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|-------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 4 | B244 | 7 | Existed |
| | 21 | | 6 | |
| | 4 | | 6 | Not existed |
| | 21 | | 7 | |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

2.CHECK AUTOMATIC SLIDING DOOR MOTOR CIRCUIT

Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|-------------|
| Connector | Terminal | Connector | Terminal | |
| B249 | 43 | B245 | 4 | Existed |
| | 46 | | 3 | |
| | 43 | | 3 | Not existed |
| | 46 | | 4 | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK AUTOMATIC SLIDING DOOR UNIT RH

1. Replace automatic sliding door unit RH. (New unit or other unit)
2. Erase DTC.
3. Operate auto open/close function.

Is DTC detected?

YES >> Replace sliding door control unit RH. Refer to [DLK-500, "RH : Removal and Installation"](#).

NO >> INSPECTION END

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2414 AUTOMATIC SLIDING DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

B2414 AUTOMATIC SLIDING DOOR MOTOR SLIDING DOOR LH

SLIDING DOOR LH : DTC Logic

INFOID:000000009649103

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|---|--|
| B2414 | ASD MTR TIME OUT | When the sliding door control unit and sliding door motor operate in the same direction for 15 seconds or more continuously | <ul style="list-style-type: none"> Clutch Automatic sliding door motor Sliding door control unit Battery voltage (low battery) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-206, "SLIDING DOOR LH : Diagnosis Procedure"](#).
NO >> INSPECTION END

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649104

1. CHECK SLIDING DOOR CONTROL UNIT LH POWER SUPPLY

Check sliding door control unit LH power supply.

Refer to [DLK-239, "SLIDING DOOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace the malfunctioning parts.

2. CHECK CLUTCH

- Select "AUTO SLIDE DOOR" using CONSULT.
- Select "CLUTCH" in "ACTIVE TEST" mode.
- Touch "HOLD" or "RELEASE" to check that it works normally.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK AUTOMATIC SLIDING DOOR MOTOR OUTPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect automatic sliding door unit LH connector.
- Check voltage between automatic sliding door unit LH harness connector and ground.

| (+) | | (-) | Condition | Voltage |
|--|----------|--------|----------------------|-----------|
| Automatic sliding door unit LH Connector | Terminal | | | |
| B33 | 3 | Ground | Auto open operation | 9 – 16 V |
| | | | Other than above | 0 – 1.5 V |
| | 4 | | Auto close operation | 9 – 16 V |
| | | | Other than above | 0 – 1.5 V |

Is the inspection result normal?

B2414 AUTOMATIC SLIDING DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).
 NO >> GO TO 5.

4.CHECK CLUTCH CIRCUIT

- Turn ignition switch OFF.
- Disconnect sliding door control unit LH connector and automatic sliding door unit LH connector.
- Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B47 | 44 | B33 | 1 | Existed |
| | 47 | | 2 | |

- Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B47 | 44 | | Not existed |
| | 47 | | |

Is the inspection result normal?

- YES >> Replace automatic sliding door unit LH.
 NO >> Repair or replace harness.

5.CHECK AUTOMATIC SLIDING DOOR MOTOR CIRCUIT

- Disconnect sliding door control unit LH connector.
- Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B47 | 43 | B33 | 3 | Existed |
| | 46 | | 4 | |

- Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B47 | 43 | | Not existed |
| | 46 | | |

Is the inspection result normal?

- YES >> Replace automatic sliding door unit LH.
 NO >> Repair or replace harness.

SLIDING DOOR RH

SLIDING DOOR RH : DTC Logic

INFOID:000000009649105

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|---|--|
| B2414 | ASD MTR TIME OUT | When the sliding door control unit and sliding door motor operate in the same direction for 15 seconds or more continuously | <ul style="list-style-type: none"> Clutch Automatic sliding door motor Sliding door control unit Battery voltage (low battery) |

B2414 AUTOMATIC SLIDING DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "AUTO SLIDE DOOR RIGHT" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-208. "SLIDING DOOR RH : Diagnosis Procedure"](#).
NO >> INSPECTION END

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649106

1. CHECK SLIDING DOOR CONTROL UNIT RH POWER SUPPLY

Check sliding door control unit RH power supply.

Refer to [DLK-239. "SLIDING DOOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace the malfunctioning parts.

2. CHECK CLUTCH

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "CLUTCH" in "ACTIVE TEST" mode.
3. Touch "HOLD" or "RELEASE" to check that it works normally.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 4.

3. CHECK AUTOMATIC SLIDING DOOR MOTOR OUTPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect automatic sliding door unit RH connector.
3. Check voltage between automatic sliding door unit RH harness connector and ground.

| (+) | | (-) | Condition | Voltage | |
|--|----------|--------|---------------------|----------------------|-----------|
| Automatic sliding door unit RH Connector | Terminal | | | | |
| B245 | 3 | Ground | Sliding door RH | Auto close operation | 9 – 16 V |
| | | | | Other than above | 0 – 1.5 V |
| | 4 | | Auto open operation | 9 – 16 V | |
| | | | | Other than above | 0 – 1.5 V |

Is the inspection result normal?

- YES >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).
NO >> GO TO 5.

4. CHECK CLUTCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect sliding door control unit RH connector and automatic sliding door unit RH connector.
3. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B249 | 44 | B245 | 1 | Existed |
| | 47 | | 2 | |

4. Check continuity between sliding door control unit RH harness connector and ground.

B2414 AUTOMATIC SLIDING DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B249 | 44 | | |
| | 47 | | |

Is the inspection result normal?

YES >> Replace automatic sliding door unit RH.

NO >> Repair or replace harness.

5.CHECK AUTOMATIC SLIDING DOOR MOTOR CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B249 | 43 | B245 | 4 | Existed |
| | 46 | | 3 | |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B249 | 43 | | |
| | 46 | | |

Is the inspection result normal?

YES >> Replace automatic sliding door unit RH.

NO >> Repair or replace harness.

DLK

B2416 TOUCH SENSOR RH

< DTC/CIRCUIT DIAGNOSIS >

B2416 TOUCH SENSOR RH

DTC Logic

INFOID:000000009649107

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|---|--|
| B2416 | TOUCH SEN R OPEN | When the automatic back door control unit detects the open circuit of the back door touch sensor RH | <ul style="list-style-type: none"> Back door touch sensor RH Harness or connectors (Back door touch sensor RH circuit is open) Automatic back door control module |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" mode of "AUTO BACK DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-210. "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009649108

1. CHECK TOUCH SENSOR INPUT SIGNAL

- Turn ignition switch OFF.
- Check voltage between back door touch sensor RH harness connector and automatic back door control module harness connector.

| (+) | | (-) | | Condition | Voltage |
|-----------|----------|-----------|----------|---------------------------|------------------------|
| Connector | Terminal | Connector | Terminal | | |
| D191 | 1 | B8 | 14 | Back door touch sensor RH | Detect obstruction |
| | | | | Other than above | 0 – 1.5 V 5 – 6.7 V |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK BACK DOOR TOUCH SENSOR RH CIRCUIT

- Disconnect automatic back door control module connector and back door touch sensor RH connector.
- Check continuity between automatic back door control module harness connector and back door touch sensor RH harness connector.

| Automatic back door control module | | Back door touch sensor RH | | Continuity |
|------------------------------------|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 13 | D191 | 1 | Existed |

- Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 13 | | Not existed |

B2416 TOUCH SENSOR RH

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK BACK DOOR TOUCH SENSOR RH GROUND CIRCUIT

1. Disconnect automatic back door control module connector and back door touch sensor RH connector.
2. Check continuity between automatic back door control module harness connector and back door touch sensor RH harness connector.

| Automatic back door control module | | Back door touch sensor RH | | Continuity |
|------------------------------------|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 14 | D191 | 2 | Existed |

3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 14 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK BACK DOOR TOUCH SENSOR RH GROUND CIRCUIT 2

1. Connect automatic back door control module connector and back door touch sensor RH connector.
2. Check voltage between automatic back door control module harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------------|----------|--------|-----------|
| Automatic back door control module | | | |
| Connector | Terminal | | |
| B8 | 14 | Ground | 0 – 1.5 V |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).

5.CHECK BACK DOOR TOUCH SENSOR RH

Refer to [DLK-211, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace back door touch sensor RH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649109

1.CHECK TOUCH SENSOR RH

1. Turn ignition switch OFF.
2. Disconnect back door touch sensor RH connector.
3. Check resistance between back door touch sensor RH terminals.

B2416 TOUCH SENSOR RH

< DTC/CIRCUIT DIAGNOSIS >

| Back door touch sensor RH | | Condition | | Resistance |
|---------------------------|---|---------------------------|--------------------|----------------------|
| Terminal | | | | |
| 1 | 2 | Back door touch sensor RH | Detect obstruction | 360 - 440 Ω |
| | | | Other than above | 0.9 - 1.1 k Ω |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace back door touch sensor RH.

B2417 TOUCH SENSOR LH

< DTC/CIRCUIT DIAGNOSIS >

B2417 TOUCH SENSOR LH

DTC Logic

INFOID:000000009649110

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2417 | TOUCH SEN L OPEN | When the automatic back door control unit detects the open circuit of the back door touch sensor LH. | <ul style="list-style-type: none"> Back door touch sensor LH Harness or connectors (Back door touch sensor LH circuit is open) Automatic back door control module |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" mode of "AUTO BACK DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-213, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009649111

1. CHECK BACK DOOR TOUCH SENSOR INPUT SIGNAL

- Turn ignition switch OFF.
- Check voltage between back door touch sensor LH harness connector and automatic back door control module harness connector.

| (+) | | (-) | | Condition | Voltage | |
|---------------------------|----------|------------------------------------|----------|---------------------------|--------------------|-----------|
| Back door touch sensor LH | | Automatic back door control module | | | | |
| Connector | Terminal | Connector | Terminal | | | |
| D165 | 1 | B8 | 14 | Back door touch sensor LH | Detect obstruction | 0 – 1.5 V |
| | | | | | Other than above | 5 – 6.7 V |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK BACK DOOR TOUCH SENSOR LH CIRCUIT

- Disconnect automatic back door control module connector and back door touch sensor LH connector.
- Check continuity between automatic back door control module harness connector and back door touch sensor LH harness connector.

| Automatic back door control module | | Back door touch sensor LH | | Continuity |
|------------------------------------|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 15 | D165 | 1 | Existed |

- Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 15 | | Not existed |

B2417 TOUCH SENSOR LH

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK BACK DOOR TOUCH SENSOR LH GROUND CIRCUIT

1. Disconnect automatic back door control module connector and back door touch sensor LH connector.
2. Check continuity between automatic back door control module harness connector and back door touch sensor LH harness connector.

| Automatic back door control module | | Back door touch sensor LH | | Continuity |
|------------------------------------|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 14 | D165 | 2 | Existed |

3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 14 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4. CHECK BACK DOOR TOUCH SENSOR LH GROUND CIRCUIT 2

1. Connect automatic back door control module connector and back door touch sensor LH connector.
2. Check voltage between automatic back door control module harness connector and ground.

| (+) Automatic back door control module | | (-) | Voltage |
|--|----------|--------|-----------|
| Connector | Terminal | | |
| B8 | 14 | Ground | 0 – 1.5 V |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).

5. CHECK BACK DOOR TOUCH SENSOR LH

Refer to [DLK-214, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace back door touch sensor LH.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649112

1. CHECK BACK DOOR TOUCH SENSOR LH

1. Turn ignition switch OFF.
2. Disconnect back door touch sensor LH connector.
3. Check resistance between back door touch sensor LH terminals.

B2417 TOUCH SENSOR LH

< DTC/CIRCUIT DIAGNOSIS >

| Back door touch sensor LH | | Condition | | Resistance |
|---------------------------|---|---------------------------|--------------------|------------------|
| Terminal | | | | |
| 1 | 2 | Back door touch sensor LH | Detect obstruction | 360 - 440 Ω |
| | | | | Other than above |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace back door touch sensor LH.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2419 OPEN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

B2419 OPEN SWITCH

DTC Logic

INFOID:000000009649113

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|---|
| B2419 | OPEN SW | <p>When the automatic back door control unit detects any of the following conditions</p> <ul style="list-style-type: none"> The change of open switch cannot be detected for 1 second or more after starting the closure open output for the 3rd time in a row The change of open switch cannot be detected for 0.5 second or more after starting the closure close output for the 3rd time in a row The condition that the open switch is in the ON position and the close switch is in the OFF position is detected when starting the closure open/close output for the 3rd time in a row | <ul style="list-style-type: none"> Open switch Harness or connectors (Open switch circuit is open or shorted) Automatic back door control module |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Operate automatic back door.
- Check "Self Diagnostic Result" mode of "AUTO BACK DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-216, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009649114

1. CHECK AUTOMATIC BACK DOOR CONTROL MODULE OUTPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect back door lock assembly connector.
- Check voltage between back door lock assembly harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------|----------|--------|----------|
| Back door lock assembly | | | |
| Connector | Terminal | Ground | 9 - 16 V |
| D190 | 4 | | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK OPEN SWITCH CIRCUIT

- Disconnect automatic back door control module connector.
- Check continuity between automatic back door control module harness connector and back door lock assembly harness connector.

| Automatic back door control module | | Back door lock assembly | | Continuity |
|------------------------------------|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 24 | D190 | 4 | Existed |

- Check continuity between automatic back door control module harness connector and ground.

B2419 OPEN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 24 | | Not existed |

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
 NO >> Repair or replace harness.

3.CHECK OPEN SWITCH GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

| Back door lock assembly | | Ground | Continuity |
|-------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D190 | 8 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK OPEN SWITCH

Refer to [DLK-217, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace back door lock assembly.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649115

COMPONENT INSPECTION

1.CHECK OPEN SWITCH

- Turn ignition switch OFF.
- Disconnect back door lock assembly connector.
- Check continuity between back door lock assembly terminals.

| Back door lock assembly | | Condition | Continuity |
|-------------------------|---|-----------|-------------|
| Terminal | | | |
| 4 | 8 | | Back door |
| | | | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace back door lock assembly.

DLK

B2420 CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

B2420 CLOSE SWITCH

DTC Logic

INFOID:000000009649116

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|---|---|
| B2420 | CLOSE SW | When the automatic back door control unit detects any of the following condition <ul style="list-style-type: none"> The change of close switch cannot be detected for 3 second or more after starting the closure close output for the 3rd time in a row | <ul style="list-style-type: none"> Close switch Harness or connectors (Close switch circuit is open or shorted) Automatic back door control module |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Operate automatic back door.
- Check "Self Diagnostic Result" mode of "AUTO BACK DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-218, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009649117

1. CHECK AUTOMATIC BACK DOOR CONTROL MODULE OUTPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect back door lock assembly connector.
- Check voltage between back door lock assembly harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------|----------|--------|----------|
| Back door lock assembly | | | |
| Connector | Terminal | | |
| D190 | 5 | Ground | 9 - 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK CLOSE SWITCH CIRCUIT

- Disconnect automatic back door control module connector.
- Check continuity between automatic back door control module harness connector and back door lock assembly harness connector.

| Automatic back door control module | | Back door lock assembly | | Continuity |
|------------------------------------|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 20 | D190 | 5 | Existed |

- Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 20 | | Not existed |

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#)

B2420 CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

3.CHECK CLOSE SWITCH GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

| Back door lock assembly | | Ground | Continuity |
|-------------------------|----------|--------|------------|
| Connector | Terminal | | Existed |
| D190 | 8 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK CLOSE SWITCH

Refer to [DLK-219. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace back door lock assembly.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649118

1.CHECK CLOSE SWITCH

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly.
3. Check continuity between back door lock assembly terminals.

| Back door lock assembly | | Condition | Continuity |
|-------------------------|---|-----------|--------------------------------|
| Terminal | | | Existed |
| 5 | 8 | Back door | Fully closed Existed |
| | | | Open/Half latch Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace back door lock assembly.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2421 CLUTCH OPERATION TIME

< DTC/CIRCUIT DIAGNOSIS >

B2421 CLUTCH OPERATION TIME

DTC Logic

INFOID:000000009649119

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2421 | CLUTCH TIME OUT | When the automatic back door control unit detects the power distribution to the clutch for 2 minutes or more | <ul style="list-style-type: none">Automatic back door control moduleBattery voltage (low voltage) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "AUTO BACK DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-220, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009649120

1. CHECK AUTOMATIC BACK DOOR CONTROL MODULE POWER SUPPLY AND GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check automatic back door control module power supply and ground circuit.
Refer to [DLK-238, "AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
NO >> Repair or replace the malfunctioning parts.

B2422 BACK DOOR STATE

< DTC/CIRCUIT DIAGNOSIS >

B2422 BACK DOOR STATE

DTC Logic

INFOID:000000009649121

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2422 | BACK DOOR STATE | When the automatic back door control unit detects back door position malfunction according to the pulse signal | <ul style="list-style-type: none">• Back door mechanism• Automatic back door control module |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Operate automatic back door.
3. Check "Self Diagnostic Result" mode of "AUTO BACK DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-221, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009649122

1. REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

When DTC [B2422] is detected, replace automatic back door control module.

- >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2423 AUTOMATIC BACK DOOR MOTOR OPERATION TIME

< DTC/CIRCUIT DIAGNOSIS >

B2423 AUTOMATIC BACK DOOR MOTOR OPERATION TIME

DTC Logic

INFOID:000000009649123

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|---|--|
| B2423 | ABD MTR TIME OUT | When the automatic back door control unit and automatic back door motor operate in the same direction for 30 seconds or more continuously | <ul style="list-style-type: none">• Back door mechanism• Automatic back door control module• Battery voltage (low battery) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Operate automatic back door.
3. Check "Self Diagnostic Result" mode of "AUTO BACK DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-222, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009649124

1. CHECK AUTOMATIC BACK DOOR CONTROL MODULE POWER SUPPLY AND GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check automatic back door control module power supply and ground circuit.
Refer to [DLK-238, "AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
NO >> Repair or replace the malfunctioning parts.

B2424 CLOSURE CONDITION

< DTC/CIRCUIT DIAGNOSIS >

B2424 CLOSURE CONDITION

DTC Logic

INFOID:000000009649125

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2424 | CLSR CONDITION | When the following condition is detected after OPEN/CLOSE operation of the back door closure motor <ul style="list-style-type: none"> Open switch and close switch are ON | <ul style="list-style-type: none"> Harness or connector (Open switch or close switch circuit is open or shorted) Back door lock assembly |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Operate automatic back door.
- Check "Self Diagnostic Result" mode of "AUTO BACK DOOR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-223, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000009649126

1. CHECK AUTOMATIC BACK DOOR CONTROL MODULE OUTPUT

- Turn ignition switch OFF.
- Disconnect back door lock assembly connector.
- Check voltage between back door lock assembly harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------|----------|--------|----------|
| Back door lock assembly | | | |
| Connector | Terminal | Ground | 9 - 16 V |
| D190 | 4 | | |
| | 5 | | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK OPEN/CLOSE SWITCH CIRCUIT

- Disconnect automatic back door control module connector.
- Check continuity between automatic back door control module harness connector and back door lock assembly harness connector.

| Automatic back door control module | | Back door lock assembly | | Continuity |
|------------------------------------|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 20 | D190 | 5 | Existed |
| | 24 | | 4 | |

- Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 20 | | Not existed |
| | 24 | | |

B2424 CLOSURE CONDITION

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

| Back door lock assembly | | Ground | Continuity |
|-------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D190 | 8 | | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK OPEN/CLOSE SWITCH

Refer to [DLK-224, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace back door lock assembly.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649127

1.CHECK OPEN/CLOSE SWITCH

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly.
3. Check continuity between back door lock assembly terminals.

| Back door lock assembly | | Condition | Continuity |
|-------------------------|---|-------------------------|-------------|
| Terminal | | | |
| 5 | 8 | Fully closed | Existed |
| | | Open/half latch | Not existed |
| 4 | | Open | Existed |
| | | Fully closed/half latch | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace back door lock assembly.

B2425 AUTOMATIC BACK DOOR CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

B2425 AUTOMATIC BACK DOOR CONTROL UNIT

DTC Logic

INFOID:000000009649128

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC Detection Condition | Possible cause |
|-------|-----------------------------|---|------------------------------------|
| B2425 | AUTO BCK DR CNT UNIT | Automatic back door control unit detected CPU malfunction | Automatic back door control module |

Diagnosis Procedure

INFOID:000000009649129

1. REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

When DTC [B2425] is detected, replace automatic back door control module.

>> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2621 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2621 INSIDE ANTENNA

DTC Logic

INFOID:000000009649130

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|---|--|
| B2621 | INSIDE ANTENNA | An excessive high or low voltage from inside antenna (instrument center) is sent to BCM | <ul style="list-style-type: none"> Inside key antenna (instrument center) Harness or connector (Front inside key antenna (instrument center) circuit is open or shorted) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INSIDE ANT DIAGNOSIS" in "WORK SUPPORT" mode.
3. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") on "WORK SUPPORT" of "INTELLIGENT KEY".
4. Check BCM for DTC.

Is inside key antenna DTC detected?

- YES >> Refer to [DLK-226, "Diagnosis Procedure"](#).
 NO >> Inside key antenna (instrument center) is OK.

Diagnosis Procedure

INFOID:000000009649131

1. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

| (+) | | (-) | Condition | Signal (Reference value) |
|-----------|----------|--------|---|-----------------------------|
| BCM | | | | |
| Connector | Terminal | | | |
| M124 | 84, 85 | Ground | When Intelligent Key is in the antenna detection area | <p>JMKIA3839GB</p> |
| | | | When Intelligent Key is not in the antenna detection area | <p>JMKIA5951GB</p> |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK INSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and inside key antenna (instrument center) connector.

B2621 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between BCM harness connector and inside key antenna (instrument center) harness connector.

| BCM | | Inside key antenna (instrument center) | | Continuity |
|-----------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M124 | 84 | M105 | 1 | Existed |
| | 85 | | 2 | |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M124 | 84 | | Not existed |
| | 85 | | |



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (instrument center). (New antenna or other antenna)
2. Connect BCM connector and inside key antenna (instrument center) connector.
3. Check signal between BCM harness connector and ground using oscilloscope.

| (+) | | (-) | Condition | Signal (Reference value) |
|-----------|----------|--------|---|---|
| BCM | | | | |
| Connector | Terminal | | | |
| M124 | 84, 85 | Ground | When Intelligent Key is in the antenna detection area |  <p style="text-align: right; font-size: small;">JMKIA3839GB</p> |
| | | | When Intelligent Key is not in the antenna detection area |  <p style="text-align: right; font-size: small;">JMKIA5951GB</p> |

Is the inspection result normal?

YES >> Replace inside key antenna (instrument center).

NO >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).

B2622 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2622 INSIDE ANTENNA

DTC Logic

INFOID:000000009649132

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|---|--|
| B2622 | INSIDE ANTENNA | An excessive high or low voltage from inside antenna (console) is sent to BCM | <ul style="list-style-type: none"> Inside key antenna (console) Harness or connector (Front inside key antenna (console) circuit is open or shorted) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INSIDE ANT DIAGNOSIS" in "WORK SUPPORT" mode.
3. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") on "WORK SUPPORT" of "INTELLIGENT KEY".
4. Check BCM for DTC.

Is inside key antenna DTC detected?

- YES >> Refer to [DLK-228. "Diagnosis Procedure"](#).
 NO >> Inside key antenna (console) is OK.

Diagnosis Procedure

INFOID:000000009649133

1. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

| (+) | | (-) | Condition | Signal (Reference value) |
|-----------|----------|--------|---|--------------------------|
| BCM | | | | |
| Connector | Terminal | | | |
| M124 | 86, 87 | Ground | When Intelligent Key is in the antenna detection area | |
| | | | When Intelligent Key is not in the antenna detection area | |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK INSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and inside key antenna (console) connector.
2. Check continuity between BCM harness connector and inside key antenna (console) harness connector.

B2622 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

| BCM | | Inside key antenna (console) | | Continuity |
|-----------|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M124 | 86 | B242 | 1 | Existed |
| | 87 | | 2 | |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M124 | 86 | | Not existed |
| | 87 | | |



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (console). (New antenna or other antenna)
2. Connect BCM connector and inside key antenna (console) connector.
3. Check signal between BCM harness connector and ground using oscilloscope.

| (+) BCM | | (-) | Condition | Signal (Reference value) |
|-----------|----------|--------|---|---|
| Connector | Terminal | | | |
| M124 | 86, 87 | Ground | When Intelligent Key is in the antenna detection area |  |
| | | | When Intelligent Key is not in the antenna detection area |  |

Is the inspection result normal?

YES >> Replace inside key antenna (console).

NO >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).

B2623 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2623 INSIDE ANTENNA

DTC Logic

INFOID:000000009649134

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2623 | INSIDE ANTENNA | An excessive high or low voltage from inside antenna (luggage room) is sent to BCM | <ul style="list-style-type: none"> Inside key antenna (luggage room) Harness or connector (Front inside key antenna (luggage room) circuit is open or shorted) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INSIDE ANT DIAGNOSIS" in "WORK SUPPORT" mode.
3. Perform inside key antenna ("INSIDE ANT DIAGNOSIS") on "WORK SUPPORT" of "INTELLIGENT KEY".
4. Check BCM for DTC.

Is inside key antenna DTC detected?



- YES >> Refer to [DLK-230. "Diagnosis Procedure"](#).
 NO >> Inside key antenna (luggage room) is OK.

Diagnosis Procedure

INFOID:000000009649135

1. CHECK INSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

| (+) | | (-) | Condition | Signal (Reference value) |
|-----------|----------|--------|---|---|
| BCM | | | | |
| Connector | Terminal | | | |
| M124 | 88, 89 | Ground | When Intelligent Key is in the antenna detection area |  |
| | | | When Intelligent Key is not in the antenna detection area |  |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK INSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and inside key antenna (luggage room) connector.
2. Check continuity between BCM harness connector and inside key antenna (luggage room) harness connector.

B2623 INSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

| BCM | | Inside key antenna (luggage room) | | Continuity |
|-----------|----------|-----------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M124 | 88 | B241 | 1 | Existed |
| | 89 | | 2 | |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M124 | 88 | | Not existed |
| | 89 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK INSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace inside key antenna (luggage room). (New antenna or other antenna)
2. Connect BCM connector and inside key antenna (luggage room) connector.
3. Check signal between BCM harness connector and ground using oscilloscope.

| (+) BCM | | (-) | Condition | Signal (Reference value) |
|-----------|----------|--------|---|-----------------------------|
| Connector | Terminal | | | |
| M124 | 88, 89 | Ground | When Intelligent Key is in the antenna detection area | |
| | | | When Intelligent Key is not in the antenna detection area | |

Is the inspection result normal?

YES >> Replace inside key antenna (luggage room).

NO >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).

B2626 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2626 OUTSIDE ANTENNA

DTC Logic

INFOID:000000009649136

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|---|--|
| B2626 | OUTSIDE ANTENNA | An excessive high or low voltage from front door right outside key antenna is sent to BCM | <ul style="list-style-type: none"> Front door right outside key antenna Harness or connector (Front door right outside key antenna circuit is open or shorted) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" mode of "BCM" using CONSULT.

Is DTC detected?



- YES >> Refer to [DLK-232, "Diagnosis Procedure"](#).
 NO >> Outside key antenna (passenger side) is OK.

Diagnosis Procedure

INFOID:000000009649137

1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

- Turn ignition switch ON.
- Check signal between BCM harness connector and ground using oscilloscope.

| (+) | | (-) | Condition | Signal (Reference value) |
|-----------|----------|--------|---|--|
| BCM | | | | |
| Connector | Terminal | | | |
| M124 | 80, 81 | Ground | When the passenger door request switch is operated with power switch ON |  <p>JMKIA5955GB</p> |
| | | | When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less) |  <p>JMKIA5954GB</p> |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

- Disconnect BCM connector and front door outside handle assembly RH connector.
- Check continuity between BCM harness connector and front door outside handle assembly RH harness connector.

B2626 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

| BCM | | Front door outside handle assembly RH | | Continuity |
|-----------|----------|---------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M124 | 80 | D31 | 1 | Existed |
| | 81 | | 2 | |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M124 | 80 | | Not existed |
| | 81 | | |



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna (passenger side). (New antenna or other antenna)
2. Connect BCM connector and front door outside handle assembly RH connector.
3. Turn ignition switch ON.
4. Check signal between BCM harness connector and ground using oscilloscope.

| (+) | | (-) | Condition | Signal (Reference value) |
|-----------|----------|--------|---|---|
| BCM | | | | |
| Connector | Terminal | | | |
| M124 | 80, 81 | Ground | When the passenger door request switch is operated with power switch ON |  <p style="text-align: right; font-size: small;">JMKIA5955GB</p> |
| | | | When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less) |  <p style="text-align: right; font-size: small;">JMKIA5954GB</p> |

Is the inspection result normal?

YES >> Replace front door outside handle assembly RH (outside key antenna).

NO >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

B2627 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2627 OUTSIDE ANTENNA

DTC Logic

INFOID:000000009649138

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2627 | OUTSIDE ANTENNA | An excessive high or low voltage from front door left outside key antenna is sent to BCM | <ul style="list-style-type: none"> Front door left outside key antenna Harness or connector (Front door left outside key antenna circuit is open or shorted) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" mode of "BCM" using CONSULT.

Is DTC detected?

- YES >> Refer to [DLK-234, "Diagnosis Procedure"](#).
- NO >> Outside key antenna (driver side) is OK.

Diagnosis Procedure

INFOID:000000009649139

1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

- Turn ignition switch ON.
- Check signal between BCM harness connector and ground using oscilloscope.

| (+) | | (-) | Condition | Signal (Reference value) |
|-----------|----------|--------|---|-----------------------------|
| BCM | | | | |
| Connector | Terminal | | | |
| M124 | 78,79 | Ground | When the driver door request switch is operated with power switch ON | <p>JMKIA5955GB</p> |
| | | | When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less) | <p>JMKIA5954GB</p> |
| | | | When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m) | <p>JMKIA5954GB</p> |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
- NO >> GO TO 2.

2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

- Disconnect BCM connector and front door outside handle assembly LH connector.
- Check continuity between BCM harness connector and front door outside handle assembly LH harness connector.

B2627 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

| BCM | | Front door outside handle assembly LH | | Continuity |
|-----------|----------|---------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M124 | 78 | D32 | 1 | Existed |
| | 79 | | 2 | |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M124 | 78 | | Not existed |
| | 79 | | |



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna (driver side). (New antenna or other antenna)
2. Connect BCM connector and front door outside handle assembly LH connector.
3. Turn ignition switch ON.
4. Check signal between BCM harness connector and ground using oscilloscope.

| (+) | | (-) | Condition | Signal (Reference value) |
|-----------|----------|--------|---|--|
| BCM | | | | |
| Connector | Terminal | | | |
| M124 | 78,79 | Ground | When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less) |  <p>JMKIA5955GB</p> |
| | | | When the driver door request switch is operated with power switch ON |  <p>JMKIA5954GB</p> |
| | | | When Intelligent Key is not in the antenna detection area (The distance between Intelligent Key and antenna: Approx. 2 m) | <p>JMKIA5954GB</p> |

Is the inspection result normal?

YES >> Replace front door outside handle assembly LH (outside key antenna).

NO >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).

B2628 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

B2628 OUTSIDE ANTENNA

DTC Logic

INFOID:000000009649140

DTC DETECTION LOGIC

| DTC | CONSULT display description | DTC detecting condition | Possible cause |
|-------|-----------------------------|--|--|
| B2628 | OUTSIDE ANTENNA | An excessive high or low voltage from outside key antenna (rear bumper) is sent to BCM | <ul style="list-style-type: none"> • Outside key antenna (rear bumper) • Harness or connector (Outside key antenna (rear bumper) circuit is open or shorted) |

DTC CONFIRMATION PROCEDURE

1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" mode of "BCM" using CONSULT.

Is DTC detected?



- YES >> Refer to [DLK-230. "Diagnosis Procedure"](#).
 NO >> Outside key antenna (rear bumper) is OK.

Diagnosis Procedure

INFOID:000000009649141

1. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 1

1. Turn ignition switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

| (+) | | (-) | Condition | Signal (Reference value) |
|-----------|----------|--------|---|--|
| BCM | | | | |
| Connector | Terminal | | | |
| M124 | 82, 83 | Ground | When the back door request switch is operated with power switch ON |  <p>JMKIA5955GB</p> |
| | | | When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less) |  <p>JMKIA5954GB</p> |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).
 NO >> GO TO 2.

2. CHECK OUTSIDE KEY ANTENNA CIRCUIT

1. Disconnect BCM connector and outside key antenna (rear bumper) connector.
2. Check continuity between BCM harness connector and outside key antenna (rear bumper) harness connector.

B2628 OUTSIDE ANTENNA

< DTC/CIRCUIT DIAGNOSIS >

| BCM | | Outside key antenna (rear bumper) | | Continuity |
|-----------|----------|-----------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M124 | 82 | B303 | 1 | Existed |
| | 83 | | 2 | |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M124 | 82 | | Not existed |
| | 83 | | |



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK OUTSIDE KEY ANTENNA INPUT SIGNAL 2

1. Replace outside key antenna (rear bumper). (New antenna or other antenna)
2. Connect BCM and outside key antenna (rear bumper) connector.
3. Turn ignition switch ON.
4. Check signal between BCM harness connector and ground using oscilloscope.

| (+) | | (-) | Condition | Signal (Reference value) |
|-----------|----------|--------|---|--|
| BCM | | | | |
| Connector | Terminal | | | |
| M124 | 82, 83 | Ground | When the back door request switch is operated with power switch ON |  <p>JMKIA5955GB</p> |
| | | | When Intelligent Key is in the antenna detection area (The distance between Intelligent Key and antenna: 80 cm or less) |  <p>JMKIA5954GB</p> |

Is the inspection result normal?

YES >> Replace outside key antenna (rear bumper).

NO >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT AUTOMATIC BACK DOOR CONTROL MODULE

AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure

INFOID:000000009649142

1. CHECK FUSE, FUSIBLE LINK AND CIRCUIT BREAKER

Check that the following fuse, fusible link and circuit breaker are not fusing.

| Fuse and fusible link No. | Signal name |
|---------------------------|-----------------------|
| J (40A) | Battery power supply |
| 9 (10A) | |
| 3 (10A) | Ignition power supply |

Is the fuse fusing?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic back door control module connector.
3. Check voltage between automatic back door control module harness connector and ground.

| (+) | | (-) | Condition | Voltage |
|-----------|----------|--------|-----------------|---------|
| Connector | Terminal | | | |
| B8 | 1 | Ground | Ignition switch | OFF |
| | 7 | | | ON |
| | 9 | | | OFF |

Is the measurement value normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK GROUND CIRCUIT

Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B8 | 11 | | Existed |

Does continuity exist?

YES >> INSPECTION END

NO >> Repair or replace harness.

BACK DOOR CONTROL UNIT

BACK DOOR CONTROL UNIT : Diagnosis Procedure

INFOID:000000009649143

1. CHECK FUSE

Check that the following fusible link is not fusing.

| Fusible link | Signal name |
|--------------|----------------------|
| J (40A) | Battery power supply |

Is the inspection result normal?

YES >> GO TO 2.

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace the blown fusible link after repairing the affected circuit if a fuse is blown.

2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect back door control unit connector.
3. Check voltage between back door control unit harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------|----------|--------|----------|
| Back door control unit | | | |
| Connector | Terminal | Ground | 8 - 16 V |
| D181 | 3 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK GROUND CIRCUIT

Check continuity between back door control unit harness connector and ground.

| Back door control unit | | Ground | Continuity |
|------------------------|----------|--------|------------|
| Connector | Terminal | | Existed |
| D181 | 7 | | |
| | 8 | | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

SLIDING DOOR CONTROL UNIT

SLIDING DOOR CONTROL UNIT : Diagnosis Procedure

INFOID:000000009649144

1.CHECK FUSE, FUSIBLE LINK AND CIRCUIT BREAKER

1. Turn ignition switch OFF.
2. Check that the following fuse and fusible link are not blown.

| Fuse and fusible link No. | Signal name |
|---------------------------|-----------------------|
| 3 (10 A) | Ignition power supply |
| 9 (10 A) | Battery power supply |
| J(40 A) | |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse or fusible link after repairing the affected circuit if a fuse or fusible link is blown.

2.CHECK POWER SUPPLY CIRCUIT

1. Disconnect sliding door control unit connector.
2. Check voltage between sliding door control unit harness connector and ground.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

Sliding door LH

| (+) | | (-) | Condition | Voltage |
|------------------------------|----------|--------|-----------------|----------|
| Sliding door control unit LH | | | | |
| Connector | Terminal | | | |
| B45 | 6 | Ground | Ignition switch | ON |
| | 12 | | | 8 – 16 V |
| B46 | 36 | | OFF | 9 – 16 V |
| | 42 | | | |

Sliding door RH

| (+) | | (-) | Condition | Voltage |
|------------------------------|----------|--------|-----------------|----------|
| Sliding door control unit RH | | | | |
| Connector | Terminal | | | |
| B247 | 6 | Ground | Ignition switch | ON |
| | 12 | | | 8 – 16 V |
| B248 | 36 | | OFF | 9 – 16 V |
| | 42 | | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK GROUND CIRCUIT

Check continuity between sliding door control unit harness connector and ground.

Sliding door LH

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B45 | 27 | | Ground |
| | B46 | 33 | |
| | | 37 | |

Sliding door RH

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B247 | 27 | | Ground |
| | B248 | 33 | |
| | | 37 | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR SWITCH

Component Function Check

INFOID:000000009649145

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR SW-DR", "DOOR SW-AS", "DOOR SW-RL", "DOOR SW-RR", in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|---------------------|--------|--------|
| DOOR SW-DR | Driver side door | Open | On |
| | | Closed | Off |
| DOOR SW-AS | Passenger side door | Open | On |
| | | Closed | Off |
| DOOR SW-RL | Sliding door LH | Open | On |
| | | Closed | Off |
| DOOR SW-RR | Sliding door RH | Open | On |
| | | Closed | Off |

Is the inspection result normal?

YES >> Door switch is OK.

NO >> Refer to [DLK-241. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649146

1.CHECK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check signal between malfunctioning door switch harness connector and ground using oscilloscope.

| (+) Door switch | | Terminal | (-) | Signal (Reference value) |
|-----------------|------|----------|--------|-----------------------------|
| Connector | | | | |
| Driver side | B35 | 3 | Ground | |
| Passenger side | B235 | | | |
| Sliding door LH | B71 | | | |
| Sliding door RH | B221 | | | |

DLK

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between door switch harness connector and BCM harness connector.

DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Door switch | | BCM | | Continuity |
|----------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| Driver side | B35 | 3 | M122 | 47 |
| Passenger side | B235 | | | 45 |
| Sliding LH | B71 | | | 48 |
| Sliding RH | B221 | | | 46 |

3. Check continuity between door switch harness connector and ground.

| Door switch | | Terminal | Ground | Continuity |
|----------------|----------|----------|--------|-------------|
| Connector | Terminal | | | |
| Driver side | B35 | 3 | Ground | Not existed |
| Passenger side | B235 | | | |
| Sliding LH | B71 | | | |
| Sliding RH | B221 | | | |

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR SWITCH

Refer to [DLK-242, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace malfunctioning door switch.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649147

1.CHECK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect malfunctioning door switch connector.
3. Check continuity between door switch terminals.

| Door switch | | Condition | | Continuity |
|-------------|----------------------------|-------------|----------|-------------|
| Terminal | | | | |
| 3 | Ground part of door switch | Door switch | Pressed | Existed |
| | | | Released | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace malfunction door switch.

BACK DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BACK DOOR SWITCH

Component Function Check

INFOID:000000009649148

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR SW-BK" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|-----------|--------|--------|
| DOOR SW-BK | Back door | Open | On |
| | | Closed | Off |

Is the inspection result normal?

- YES >> Back door switch is OK.
 NO >> Refer to [DLK-243, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649149

1.CHECK BACK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check signal between back door lock assembly harness connector and ground using oscilloscope.

| (+) | | (-) | Signal (Reference value) |
|-----------|----------|--------|-----------------------------|
| Connector | Terminal | | |
| D190 | 7 | Ground | <p>9.0 - 10.0 V</p> |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK BACK DOOR SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between back door lock assembly harness connector and BCM harness connector.

| Back door lock assembly | | BCM | | Continuity |
|-------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D190 | 7 | M122 | 43 | Existed |

3. Check continuity between back door lock assembly harness connector and ground.

| Back door lock assembly | | Ground | Continuity |
|-------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D190 | 7 | | Not existed |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
 NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BACK DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK BACK DOOR SWITCH GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

| Back door lock assembly | | Ground | Continuity |
|-------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D190 | 8 | | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK BACK DOOR SWITCH

Refer to [DLK-244, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace back door lock assembly.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649150

1.CHECK BACK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check continuity between back door lock assembly terminals.

| Back door lock assembly | | Condition | | Continuity |
|-------------------------|---|----------------|--------|-------------|
| Terminal | | | | |
| 7 | 8 | Back door lock | Lock | Existed |
| | | | Unlock | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace back door lock assembly.

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR LOCK AND UNLOCK SWITCH WITH AUTOMATIC SLIDING DOOR

WITH AUTOMATIC SLIDING DOOR : Component Function Check

INFOID:000000009649151

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "CDL LOCK SW", "CDL UNLOCK SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | Status |
|---------------|-----------|--------|
| CDL LOCK SW | Lock | ON |
| | Unlock | OFF |
| CDL UNLOCK SW | Lock | OFF |
| | Unlock | ON |

Is the inspection result normal?

YES >> Door lock and unlock switch is OK.

NO >> Refer to [DLK-245, "WITH AUTOMATIC SLIDING DOOR : Diagnosis Procedure"](#).

WITH AUTOMATIC SLIDING DOOR : Diagnosis Procedure

INFOID:000000009649152

1.CHECK POWER WINDOW OPERATION

1. Turn ignition switch ON.
2. Check power window operation.

Does power window operate?

YES >> Replace the malfunctioning power window switch.

NO >> Refer to [PWC-52, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#) (power window main switch), [PWC-53, "FRONT POWER WINDOW SWITCH \(PASSENGER SIDE\) : Diagnosis Procedure"](#) [front power window switch (passenger side)].

WITHOUT AUTOMATIC SLIDING DOOR

WITHOUT AUTOMATIC SLIDING DOOR : Component Function Check

INFOID:000000009649153

DLK

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "CDL LOCK SW", "CDL UNLOCK SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | Status |
|---------------|-----------|--------|
| CDL LOCK SW | Lock | ON |
| | Unlock | OFF |
| CDL UNLOCK SW | Lock | OFF |
| | Unlock | ON |

Is the inspection result normal?

YES >> Door lock and unlock switch is OK.

NO >> Refer to [DLK-245, "WITHOUT AUTOMATIC SLIDING DOOR : Diagnosis Procedure"](#).

WITHOUT AUTOMATIC SLIDING DOOR : Diagnosis Procedure

INFOID:000000009649154

POWER WINDOW MAIN SWITCH


1.CHECK DOOR LOCK AND UNLOCK SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect power window main switch connector.
3. Check signal between power window main switch harness connector and ground using oscilloscope.

| (+) | | (-) | Signal (Reference value) |
|--------------------------|----------|--------|--|
| Power window main switch | | | |
| Connector | Terminal | | |
| D6 | 18 | Ground |  1.0 - 1.5 V |
| D5 | 6 | | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK DOOR LOCK AND UNLOCK SWITCH CIRCUIT

1. Disconnect BCM connector and power window main switch connector.
2. Check continuity between BCM harness connector and power window main switch harness connector.

| BCM | | Power window main switch | | Continuity |
|-----------|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M121 | 12 | D6 | 18 | Existed |
| | 13 | D5 | 6 | |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M121 | 12 | | Not existed |
| | 13 | | |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK DOOR LOCK AND UNLOCK SWITCH GROUND

Check continuity between power window main switch harness connector and ground.

| Power window main switch | | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D6 | 17 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK DOOR LOCK AND UNLOCK SWITCH

Refer to [DLK-248. "WITHOUT AUTOMATIC SLIDING DOOR : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace power window main switch. Refer to [PWC-123. "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >


Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

1. CHECK DOOR LOCK AND UNLOCK SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector.
3. Check signal between front power window switch (passenger side) harness connector and ground using oscilloscope.

| (+) | | (-) | Signal (Reference value) |
|--|----------|--------|---|
| front power window switch (passenger side) | | | |
| Connector | Terminal | | |
| D56 | 1 | Ground |  |
| | 2 | | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK DOOR LOCK AND UNLOCK SWITCH CIRCUIT

1. Disconnect BCM connector and front power window switch (passenger side) connector.
2. Check continuity between BCM harness connector and front power window switch (passenger side) harness connector.

| BCM | | front power window switch (passenger side) | | Continuity |
|-----------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M121 | 12 | D56 | 1 | Existed |
| | 13 | | 2 | |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M121 | 12 | Ground | Not existed |
| | 13 | | |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK DOOR LOCK AND UNLOCK SWITCH GROUND

Check continuity between front power window switch (passenger side) harness connector and ground.

| front power window switch (passenger side) | | Ground | Continuity |
|--|----------|--------|------------|
| Connector | Terminal | | |
| D56 | 3 | Ground | Existed |

Is the inspection result normal?

DOOR LOCK AND UNLOCK SWITCH

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK DOOR LOCK AND UNLOCK SWITCH

Refer to [DLK-248. "WITHOUT AUTOMATIC SLIDING DOOR : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace front power window switch (passenger side). Refer to [PWC-123. "Removal and Installation"](#).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

WITHOUT AUTOMATIC SLIDING DOOR : Component Inspection

INFOID:000000009649155

POWER WINDOW MAIN SWITCH

1.CHECK DOOR LOCK AND UNLOCK SWITCH

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch terminals.

| Power window main switch | | Condition | Continuity | |
|--------------------------|----|-----------------------------|------------|-------------|
| Terminal | | | | |
| 18 | 17 | Door lock and unlock switch | LOCK | Existed |
| | | | UNLOCK | Not existed |
| 6 | | | LOCK | Not existed |
| | | | UNLOCK | Existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace power window main switch.

FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

1.CHECK DOOR LOCK AND UNLOCK SWITCH

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector.
3. Check continuity between front power window switch (passenger side) terminals.

| Front power window switch (passenger side) | | Condition | Continuity | |
|--|---|-----------------------------|------------|-------------|
| Terminal | | | | |
| 1 | 3 | Door lock and unlock switch | LOCK | Existed |
| | | | UNLOCK | Not existed |
| 2 | | | LOCK | Not existed |
| | | | UNLOCK | Existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace front power window switch (passenger side).

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

DOOR LOCK ACTUATOR DRIVER SIDE

DRIVER SIDE : Component Function Check

INFOID:000000009649156

1. CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK" in "ACTIVE TEST" mode.
3. Touch "ALL LOCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-249. "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000009649157

1. CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check voltage between front door lock assembly (driver side) harness connector and ground.

| (+) | | (-) | Condition | Voltage |
|--|----------|--------|-----------------------------|----------|
| Front door lock assembly (driver side) | | | | |
| Connector | Terminal | Ground | Door lock and unlock switch | 9 - 16 V |
| D48 | 1 | | | |
| | 2 | Unlock | | |

Is the inspection result normal?

YES >> Replace front door lock assembly (driver side).

NO >> GO TO 2.

2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM, all door lock actuators connector.
2. Check continuity between BCM harness connector and front door lock assembly (driver side) harness connector.

| BCM | | Front door lock assembly (driver side) | | Continuity |
|-----------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 65 | D48 | 1 | Existed |
| | 66 | | 2 | |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 65 | Ground | Not existed |
| | 66 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

| (+) | | (-) | Condition | | Voltage |
|-----------|----------|--------|-----------------------------|--------|----------|
| BCM | | | | | |
| Connector | Terminal | | | | |
| M123 | 65 | Ground | Door lock and unlock switch | Lock | 9 - 16 V |
| | 66 | | | Unlock | |

Is the inspection result normal?

YES >> Check for internal short of door lock actuator.

NO >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Component Function Check

INFOID:000000009649158

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK" in "ACTIVE TEST" mode.
3. Touch "ALL LOCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-250, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000009649159

1.CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (passenger side) connector.
3. Check voltage between front door lock assembly (passenger side) harness connector and ground.

| (+) | | (-) | Condition | | Voltage |
|---|----------|--------|-----------------------------|--------|----------|
| Front door lock assembly (passenger side) | | | | | |
| Connector | Terminal | | | | |
| D9 | 5 | Ground | Door lock and unlock switch | Lock | 9 - 16 V |
| | 6 | | | Unlock | |

Is the inspection result normal?

YES >> Replace front door lock assembly (passenger side).

NO >> GO TO 2.

2.CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM, all door lock actuators connector.
2. Check continuity between BCM harness connector and front door lock assembly (passenger side) harness connector.

| BCM | | Front door lock assembly (passenger side) | | Continuity |
|-----------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 65 | D9 | 5 | Existed |
| | 59 | | 6 | |

3. Check continuity between BCM harness connector and ground.

DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 65 | | Not existed |
| | 59 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

| (+) | | (-) | Condition | Voltage |
|-----------|----------|--------|-----------------------------|----------|
| BCM | | | | |
| Connector | Terminal | Ground | Door lock and unlock switch | 9 - 16 V |
| M123 | 65 | | | |
| | 59 | Unlock | | |

Is the inspection result normal?

YES >> Check for internal short of door lock actuator.

NO >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SLIDING DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR LOCK ACTUATOR WITH AUTOMATIC SLIDING DOOR

WITH AUTOMATIC SLIDING DOOR : Component Function Check

INFOID:000000009649160

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK" in "ACTIVE TEST" mode.
3. Touch "ALL LOCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-255. "WITHOUT AUTOMATIC SLIDING DOOR : Diagnosis Procedure"](#).

WITH AUTOMATIC SLIDING DOOR : Diagnosis Procedure

INFOID:000000009649161

Sliding door lock assembly LH

1.CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly LH connector.
3. Check voltage between sliding door lock assembly LH harness connector and ground.

| (+) Sliding door lock assembly LH | | (-) | Condition | Voltage | |
|-----------------------------------|----------|--------|-----------------------------|---------|----------|
| Connector | Terminal | | | | |
| D85 | 2 | Ground | Door lock and unlock switch | Lock | 9 - 16 V |
| | 1 | | Unlock | | |

Is the inspection result normal?

YES >> Replace sliding door lock assembly.

NO >> GO TO 2.

2.CHECK DOOR LOCK ACTUATOR CIRCUIT 1

1. Disconnect BCM, all door lock actuators connector.
2. Check continuity between BCM harness connector and sliding door lock assembly LH harness connector.

| BCM | | Sliding door lock assembly LH | | Continuity |
|-----------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 65 | D85 | 2 | Existed |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 65 | | Not existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK DOOR LOCK ACTUATOR CIRCUIT 2

1. Disconnect selective unlock relay connector.
2. Check continuity between selective unlock relay harness connector and sliding door lock assembly LH harness connector.

SLIDING DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

| Selective unlock relay | | Sliding door lock assembly LH | | Continuity |
|------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M91 | 3 | D85 | 1 | Existed |

3. Check continuity between BCM harness connector and ground.

| Selective unlock relay | | Ground | Continuity |
|------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| M91 | 3 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK SELECTIVE UNLOCK RELAY GROUND CIRCUIT

1. Disconnect selective unlock relay connector.
2. Check continuity between selective unlock relay harness connector and ground.

| Selective unlock relay | | Ground | Continuity |
|------------------------|----------|--------|------------|
| Connector | Terminal | | |
| M91 | 4 | | Existed |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace harness.

5.CHECK SELECTIVE UNLOCK RELAY

Check selective unlock relay.
Refer to [DLK-258. "Component Inspection"](#)

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace selective unlock relay.

6.CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

| (+) | | (-) | Condition | Voltage | |
|-----------|----------|--------|-----------------------------|------------------|----------|
| BCM | | | | | |
| Connector | Terminal | | | | |
| M123 | 65 | Ground | Door lock and unlock switch | Lock | 9 - 16 V |
| M122 | 50 | | | Unlock | 0 V |
| | | | | Other than above | 9 - 16 V |

Is the inspection result normal?

- YES >> Check for internal short of door lock actuator.
NO >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).

Sliding door lock assembly RH

1.CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly RH connector.
3. Check voltage between sliding door lock assembly RH harness connector and ground.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SLIDING DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

| (+) | | (-) | Condition | Voltage |
|-------------------------------|----------|--------|-----------------------------|---------|
| Sliding door lock assembly RH | | | | |
| Connector | Terminal | | | |
| D105 | 1 | Ground | Door lock and unlock switch | Lock |
| | 2 | | | Unlock |
| 9 - 16 V | | | | |

Is the inspection result normal?

YES >> Replace sliding door lock assembly.

NO >> GO TO 2.

2. CHECK DOOR LOCK ACTUATOR CIRCUIT

1. Disconnect BCM, all door lock actuators connector.
2. Check continuity between BCM harness connector and sliding door lock assembly RH harness connector.

| BCM | | Sliding door lock assembly RH | | Continuity |
|-----------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M123 | 65 | D105 | 1 | Existed |
| M122 | 55 | | 2 | |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 65 | | Not existed |
| M122 | 55 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

| (+) | | (-) | Condition | Voltage |
|-----------|----------|--------|-----------------------------|---------|
| BCM | | | | |
| Connector | Terminal | | | |
| M123 | 65 | Ground | Door lock and unlock switch | Lock |
| M122 | 55 | | | Unlock |
| 9 - 16 V | | | | |

Is the inspection result normal?

YES >> Check for internal short of door lock actuator.

NO >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).

WITH AUTOMATIC SLIDING DOOR : Component Inspection

INFOID:000000009649162

1. CHECK SELECTIVE UNLOCK RELAY


1. Turn ignition switch OFF.
2. Remove selective unlock relay.

SLIDING DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

- Check the continuity between selective unlock relay terminals under the following conditions.

| Terminal | Condition | Continuity |
|----------|---|-------------|
| 4 | No current supply | Existed |
| | 12 V direct current supply between terminals 1 and 2. | Not existed |
| 5 | 12 V direct current supply between terminals 1 and 2. | Existed |
| | No current supply | Not existed |



Is the inspection result normal?

YES >> INSPECTION END.

NO >> Replace selective unlock relay.

WITHOUT AUTOMATIC SLIDING DOOR

WITHOUT AUTOMATIC SLIDING DOOR : Component Function Check

INFOID:000000009649163

1.CHECK FUNCTION

- Select "DOOR LOCK" of "BCM" using CONSULT.
- Select "DOOR LOCK" in "ACTIVE TEST" mode.
- Touch "ALL LOCK" or "ALL UNLK" to check that it works normally.

Is the inspection result normal?

YES >> Door lock actuator is OK.

NO >> Refer to [DLK-255. "WITHOUT AUTOMATIC SLIDING DOOR : Diagnosis Procedure"](#).

WITHOUT AUTOMATIC SLIDING DOOR : Diagnosis Procedure

INFOID:000000009649164

1.CHECK DOOR LOCK ACTUATOR INPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect sliding door lock assembly LH connector and sliding door lock assembly RH connector.
- Check voltage between sliding door lock assembly LH/RH harness connector and ground.

DLK

L

M

N

O

P

| (+) | | (-) | Condition | Voltage |
|----------------------------|----------|-----|-----------------------------|---------|
| Sliding door lock assembly | | | | |
| Connector | Terminal | | | |
| LH | D85 | 2 | Door lock and unlock switch | Lock |
| | | 1 | | Unlock |
| RH | D105 | 1 | | Lock |
| | | 2 | | Unlock |

Is the inspection result normal?

YES >> Replace sliding door lock assembly.

NO >> GO TO 2.

2.CHECK DOOR LOCK ACTUATOR CIRCUIT

- Disconnect BCM, all door lock actuators connector.
- Check continuity between BCM harness connector and sliding door lock assembly LH/RH harness connector.

SLIDING DOOR LOCK ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

| BCM | | | Sliding door lock assembly | | Continuity |
|-----------|------|----------|----------------------------|----------|------------|
| Connector | | Terminal | Connector | Terminal | |
| LH | M123 | 65 | D85 | 2 | Existed |
| | M122 | 55 | | 1 | |
| RH | M123 | 65 | D105 | 1 | |
| | M122 | 55 | | 2 | |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M123 | 65 | | Not existed |
| M122 | 55 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

| (+) | | (-) | Condition | Voltage | |
|-----------|----------|--------|-----------------------------|---------|----------|
| BCM | | | | | |
| Connector | Terminal | | | | |
| M123 | 65 | Ground | Door lock and unlock switch | Lock | 9 - 16 V |
| M122 | 55 | | | Unlock | |

Is the inspection result normal?

YES >> Check for internal short of each door lock actuator and fuel lid lock actuator.

NO >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).

SELECT UNLOCK RELAY

< DTC/CIRCUIT DIAGNOSIS >

SELECT UNLOCK RELAY

Component Function Check

INFOID:000000009649165

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK" in "ACTIVE TEST" mode.
3. Touch "ALL UNLK" to check that it works normally of sliding door LH.

Is the inspection result normal?

- YES >> Selective unlock relay is OK.
NO >> Refer to [DLK-257. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649166

1.CHECK SELECTIVE UNLOCK RELAY POWER SUPPLY 1

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

| (+) | | (-) | Voltage (V) |
|-----------|----------|--------|-------------|
| BCM | | | |
| Connector | Terminal | Ground | 9 - 16 V |
| M122 | 50 | | |

Is the inspection result normal?

- YES >> GO TO 6.
NO >> GO TO 2.

2.CHECK SELECTIVE UNLOCK RELAY POWER SUPPLY 2

1. Disconnect selective unlock relay connector.
2. Check voltage between selective unlock relay and ground.

| (+) | | (-) | Voltage (V) |
|------------------------|----------|--------|-------------|
| Selective unlock relay | | | |
| Connector | Terminal | Ground | 9 - 16 V |
| M91 | 1 | | |
| | 5 | | |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> GO TO 3.

3.DETECT MALFUNCTIONING PART

Check the following.

- 10 A fuse (#6)
- Harness for open or short between selective unlock relay harness connector and battery terminal.

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair or replace the malfunctioning parts.

4.CHECK SELECTIVE UNLOCK RELAY CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between selective unlock relay harness connector and BCM harness connector.

SELECT UNLOCK RELAY

< DTC/CIRCUIT DIAGNOSIS >

| Selective unlock relay | | BCM | | Continuity |
|------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M91 | 2 | M122 | 50 | Existed |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M122 | 50 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace harness.

5.CHECK SELECTIVE UNLOCK RELAY

Check selective unlock relay.

Refer to [DLK-258. "Component Inspection"](#)

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Replace selective unlock relay.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#)

>> INSPECTION END


Component Inspection

INFOID:000000009649167

1.CHECK SELECTIVE UNLOCK RELAY

1. Turn ignition switch OFF.
2. Remove selective unlock relay.
3. Check the continuity between selective unlock relay terminals under the following conditions.

| Terminal | Condition | Continuity |
|----------|---|-------------|
| 4 | No current supply | Existed |
| | 12 V direct current supply between terminals 1 and 2. | Not existed |
| 5 | 12 V direct current supply between terminals 1 and 2. | Existed |
| | No current supply | Not existed |



JMLIA0997ZZ

Is the inspection result normal?

- YES >> INSPECTION END.
- NO >> Replace selective unlock relay.

UNLOCK SENSOR

< DTC/CIRCUIT DIAGNOSIS >

UNLOCK SENSOR

Component Function Check

INFOID:000000009649168

1. CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "UNLK SEN-DR" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|------------------|--------|--------|
| UNLK SEN -DR | Driver side door | Lock | OFF |
| | | Unlock | ON |

Is the inspection result normal?

YES >> Unlock sensor is OK.

NO >> Refer to [DLK-259, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649169

1. CHECK UNLOCK SENSOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check signal between front door lock assembly (driver side) harness connector and ground with oscilloscope.

| (+) | | (-) | Signal (Reference value) |
|--|-----------|--------|----------------------------------|
| Front door lock assembly (driver side) | Connector | | |
| Terminal | Terminal | | |
| D48 | 3 | Ground | <p>PKIB4960J 7.0 - 8.0 V</p> |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK UNLOCK SENSOR CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and front door lock assembly (driver side) harness connector.

| BCM | | Front door lock assembly (driver side) | | Continuity |
|-----------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M121 | 31 | D48 | 3 | Existed |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M121 | 31 | | Not existed |

Is the inspection result normal?

UNLOCK SENSOR

< DTC/CIRCUIT DIAGNOSIS >

YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK UNLOCK SENSOR GROUND CIRCUIT

Check continuity between front door lock assembly (driver side) harness connector and ground.

| Front door lock assembly (driver side) | | Ground | Continuity |
|--|----------|--------|------------|
| Connector | Terminal | | |
| D48 | 4 | | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK UNLOCK SENSOR

Refer to [DLK-260, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front door lock assembly (driver side).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649170

1.CHECK UNLOCK SENSOR

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check continuity between front door lock assembly (driver side) terminals.

| Front door lock assembly (driver side) | | Condition | Continuity |
|--|---|------------------|---------------------|
| Terminal | | | |
| 3 | 4 | Driver side door | Unlock Existed |
| | | | Lock Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace front door lock assembly (driver side).

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR KEY CYLINDER SWITCH WITH AUTOMATIC SLIDING DOOR

WITH AUTOMATIC SLIDING DOOR : Component Function Check

INFOID:000000009649171

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "KEY CYL LK-SW", "KEY CYL UN-SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | Status |
|---------------|------------------|--------|
| KEY CYL LK-SW | Lock | ON |
| | Neutral / Unlock | OFF |
| KEY CYL UN-SW | Unlock | ON |
| | Neutral / Lock | OFF |

Is the inspection result normal?

YES >> Door key cylinder switch is OK.


NO >> Refer to [DLK-261. "WITH AUTOMATIC SLIDING DOOR : Diagnosis Procedure"](#).

WITH AUTOMATIC SLIDING DOOR : Diagnosis Procedure

INFOID:000000009649172

1.CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check voltage between front door lock assembly (driver side) harness connector and ground.

| (+) | | (-) | Signal (Reference value) |
|-----------|----------|--------|---|
| Connector | Terminal | | |
| D48 | 5 | Ground |  |
| | 6 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK DOOR KEY CYLINDER SWITCH SIGNAL CIRCUIT

1. Disconnect power window main switch connector.
2. Check continuity between power window main switch harness connector and front door lock assembly (driver side) harness connector.

| Power window main switch | | Front door lock assembly (driver side) | | Continuity |
|--------------------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D5 | 4 | D48 | 6 | Existed |
| | 6 | | 5 | |

3. Check continuity between power window main switch harness connector and ground.

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Power window main switch | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D5 | 4 | | |
| | 6 | | Not existed |

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-68, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly (driver side) harness connector and ground.

| Front door lock assembly (driver side) | | Ground | Continuity |
|--|----------|--------|------------|
| Connector | Terminal | | |
| D48 | 4 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK DOOR KEY CYLINDER SWITCH

Refer to [DLK-262, "WITH AUTOMATIC SLIDING DOOR : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace front door lock assembly (driver side).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

WITH AUTOMATIC SLIDING DOOR : Component Inspection

INFOID:000000009649173

1.CHECK DOOR KEY CYLINDER SWITCH

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check continuity between front door lock assembly (driver side) terminals.

| Front door lock assembly (driver side) | | Condition | Continuity | |
|--|---|-------------------------------|------------------|-------------|
| Terminal | | | | |
| 5 | 4 | Driver side door key cylinder | Unlock | Existed |
| | | | Neutral / Lock | Not existed |
| 6 | | | Lock | Existed |
| | | | Neutral / Unlock | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace front door lock assembly (driver side).

WITHOUT AUTOMATIC SLIDING DOOR

WITHOUT AUTOMATIC SLIDING DOOR : Component Function Check

INFOID:000000009649174

1.CHECK FUNCTION

1. Select "DOOR LOCK" of "BCM" using CONSULT.

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

- Select "KEY CYL LK-SW", "KEY CYL UN-SW" in "DATA MONITOR" mode.
- Check that the function operates normally according to the following conditions.

| Monitor item | Condition | Status |
|---------------|------------------|--------|
| KEY CYL LK-SW | Lock | ON |
| | Neutral / Unlock | OFF |
| KEY CYL UN-SW | Unlock | ON |
| | Neutral / Lock | OFF |

Is the inspection result normal?

YES >> Door key cylinder switch is OK.

NO >> Refer to [DLK-263, "WITHOUT AUTOMATIC SLIDING DOOR : Diagnosis Procedure"](#).

WITHOUT AUTOMATIC SLIDING DOOR : Diagnosis Procedure

INFOID:000000009649175

1. CHECK DOOR KEY CYLINDER SWITCH INPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect front door lock assembly (driver side) connector.
- Check voltage between front door lock assembly (driver side) harness connector and ground.

| (+) | | (-) | Signal (Reference value) |
|-----------|----------|--------|-----------------------------|
| Connector | Terminal | | |
| D48 | 5 | Ground | |
| | 6 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK DOOR KEY CYLINDER SWITCH SIGNAL CIRCUIT

- Disconnect BCM connector.
- Check continuity between BCM harness connector and front door lock assembly (driver side) harness connector.

| BCM | | Front door lock assembly (driver side) | | Continuity |
|-----------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M121 | 8 | D48 | 6 | Existed |
| | 7 | | 5 | |

- Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M121 | 8 | | Not existed |
| | 7 | | |

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

NO >> Repair or replace harness.

DOOR KEY CYLINDER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK DOOR KEY CYLINDER SWITCH GROUND CIRCUIT

Check continuity between front door lock assembly (driver side) harness connector and ground.

| Front door lock assembly (driver side) | | Ground | Continuity |
|--|----------|--------|------------|
| Connector | Terminal | | |
| D48 | 4 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4. CHECK DOOR KEY CYLINDER SWITCH

Refer to [DLK-264, "WITHOUT AUTOMATIC SLIDING DOOR : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace front door lock assembly (driver side).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

WITHOUT AUTOMATIC SLIDING DOOR : Component Inspection

INFOID:000000009649176

1. CHECK DOOR KEY CYLINDER SWITCH

1. Turn ignition switch OFF.
2. Disconnect front door lock assembly (driver side) connector.
3. Check continuity between front door lock assembly (driver side) terminals.

| Front door lock assembly (driver side) | | Condition | Continuity | |
|--|---|-------------------------------|------------------|-------------|
| Terminal | | | | |
| 5 | 4 | Driver side door key cylinder | Unlock | Existed |
| | | | Neutral / Lock | Not existed |
| 6 | | | Lock | Existed |
| | | | Neutral / Unlock | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace front door lock assembly (driver side).

REMOTE KEYLESS ENTRY RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

REMOTE KEYLESS ENTRY RECEIVER

Component Function Check

INFOID:000000009649177

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "RKE OPE COUN1" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition |
|---------------|---|
| RKE OPE COUN1 | Checks whether value changes when operating Intelligent Key |

Is the inspection result normal?

- YES >> Remote keyless entry receiver is OK.
NO >> Refer to [DLK-265. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649178

1.CHECK REMOTE KEYLESS ENTRY RECEIVER POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect remote keyless entry receiver connector.
3. Check voltage between remote keyless entry receiver harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| R108 | 1 | Ground | 9 - 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.DETECT MALFUNCTIONING PART

Check the following.

- 10 A fuse (#10)
- Harness for open or short between selective unlock relay harness connector and battery terminal.

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair or replace the malfunctioning parts.

3.CHECK REMOTE KEYLESS ENTRY RECEIVER GROUND CIRCUIT 1

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

| BCM | | Remote keyless entry receiver | | Continuity |
|-----------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M121 | 18 | R108 | 4 | Existed |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M121 | 18 | | Not existed |

Is the inspection result normal?


- YES >> GO TO 4.
NO >> Repair or replace harness.

REMOTE KEYLESS ENTRY RECEIVER

< DTC/CIRCUIT DIAGNOSIS >

4. CHECK REMOTE KEYLESS ENTRY RECEIVER OUTPUT SIGNAL

1. Connect remote keyless entry receiver connector and BCM connector.
2. Check signal between remote keyless entry receiver harness connector and ground using oscilloscope.

| (+) | | (-) | Condition | Signal (Reference value) |
|--|----------|--------|---|---|
| Remote keyless entry receiver Connector | Terminal | | | |
| R108 | 2 | Ground | Waiting | (Approx.) 12 V |
| | | | Press the Intelligent Key lock or unlock button |  <p style="text-align: right; font-size: small;">JMMIA0572GB</p> |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace remote keyless entry receiver.

5. CHECK REMOTE KEYLESS ENTRY RECEIVER CIRCUIT

1. Disconnect BCM and remote keyless entry receiver connector.
2. Check continuity between BCM harness connector and remote keyless entry receiver harness connector.

| BCM | | Remote keyless entry receiver | | Continuity |
|-----------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M121 | 38 | R108 | 2 | Existed |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M121 | 38 | | Not existed |

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).

NO >> Repair or replace harness.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

DOOR REQUEST SWITCH

Component Function Check

INFOID:000000009649179

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "REQ SW-DR", "REQ SW-AS" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|------------------------------------|----------|--------|
| REQ SW -DR | Driver side door request switch | Pressed | ON |
| | | Released | OFF |
| REQ SW -AS | Passenger side door request switch | Pressed | ON |
| | | Released | OFF |

Is the inspection result normal?

- YES >> Front door request switch is OK.
 NO >> Refer to [DLK-267, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649180

1.CHECK DOOR REQUEST SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect malfunctioning front door outside assembly connector.
3. Check voltage between malfunctioning front door outside handle assembly harness connector and ground.

| (+) | | Terminal | (-) | Voltage |
|------------------------------------|-----|----------|--------|----------|
| Front door outside handle assembly | | | | |
| Connector | | | | |
| LH | D32 | 3 | Ground | 9 - 16 V |
| RH | D31 | | | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK DOOR REQUEST SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between malfunctioning front door outside handle assembly harness connector and BCM harness connector.

| Front door outside handle assembly | | Terminal | BCM | | Continuity |
|------------------------------------|-----|----------|-----------|----------|------------|
| Connector | | | Connector | Terminal | |
| LH | D32 | 3 | M124 | 75 | Existed |
| RH | D31 | | | 100 | |

3. Check continuity between malfunctioning front door outside handle assembly harness connector and ground.

| Front door outside handle assembly | | Terminal | Ground | Continuity |
|------------------------------------|-----|----------|--------|-------------|
| Connector | | | | |
| LH | D32 | 3 | Ground | Not existed |
| RH | D31 | | | |

Is the inspection result normal?

DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK DOOR REQUEST SWITCH GROUND CIRCUIT

Check continuity between malfunctioning front door outside handle assembly harness connector and ground.

| Front door outside handle assembly | | Ground | Continuity |
|------------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| LH | D32 | 4 | Existed |
| RH | D31 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK DOOR REQUEST SWITCH

Refer to [DLK-268, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace malfunctioning front door outside handle assembly.

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649181

1. CHECK DOOR REQUEST SWITCH

1. Turn ignition switch OFF.
2. Disconnect malfunctioning front door request switch connector.
3. Check continuity between malfunctioning front door request switch terminals.

| Front door request switch | | Condition | | Continuity |
|---------------------------|---|---------------------|----------|-------------|
| Terminal | | | | |
| 3 | 4 | Door request switch | Pressed | Existed |
| | | | Released | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace malfunctioning front door outside handle assembly.

BACK DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BACK DOOR REQUEST SWITCH

Component Function Check

INFOID:000000009649182

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "REQ SW-BD/TR" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|--------------------------|----------|--------|
| REQ SW-BD/TR | Back door request switch | Pressed | On |
| | | Released | Off |

Is the inspection result normal?

YES >> Back door request switch is OK.

NO >> Refer to [DLK-269, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649183

1.CHECK BACK DOOR REQUEST SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect back door opener switch assembly connector.
3. Check voltage between back door opener switch assembly harness connector and ground.

| (+) | | (-) | Voltage |
|----------------------------------|----------|--------|----------|
| Back door opener switch assembly | | | |
| Connector | Terminal | Ground | 9 - 16 V |
| D186 | 4 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK BACK DOOR REQUEST SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and back door opener switch assembly harness connector.

| BCM | | Back door opener switch assembly | | Continuity |
|-----------|----------|----------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M122 | 51 | D186 | 4 | Existed |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M122 | 51 | | Not existed |

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK BACK DOOR REQUEST SWITCH GROUND CIRCUIT

Check continuity between back door opener switch assembly harness connector and ground.

BACK DOOR REQUEST SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Back door opener switch assembly | | Ground | Continuity |
|----------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D186 | 3 | | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK BACK DOOR REQUEST SWITCH

Refer to [DLK-270, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace back door opener switch assembly.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649184

1.CHECK BACK DOOR REQUEST SWITCH

1. Turn ignition switch OFF.
2. Disconnect back door opener switch assembly connector.
3. Check continuity between back door opener switch assembly terminals.

| Back door opener switch assembly | | Condition | Continuity |
|----------------------------------|---|--------------------------|-------------------------|
| Terminal | | | |
| 3 | 4 | Back door request switch | Pressed Existed |
| | | | Released Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace back door opener switch assembly.

BACK DOOR OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

BACK DOOR OPENER SWITCH

Component Function Check

INFOID:000000009649185

1.CHECK FUNCTION

1. Select "TRUNK" of "BCM" using CONSULT.
2. Select "TR/BD OPEN SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|---------------|-------------------------|----------|--------|
| TR/BD OPEN SW | Back door opener switch | Pressed | ON |
| | | Released | OFF |

Is the inspection result normal?


- YES >> Back door opener switch is OK.
 NO >> Refer to [DLK-271, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649186

1.CHECK BACK DOOR OPEN INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect back door opener switch assembly connector.
3. Check signal between back door opener switch assembly harness connector and ground.

| (+) | | (-) | Signal (Reference value) |
|-----------|----------|--------|--|
| Connector | Terminal | | |
| D186 | 1 | Ground |  <p>1.0 - 1.5 V</p> |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK BACK DOOR OPENER SWITCH CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and back door opener switch assembly harness connector.

| BCM | | Back door opener switch assembly | | Continuity |
|-----------|----------|----------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M121 | 30 | D186 | 1 | Existed |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M121 | 30 | | Not existed |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

BACK DOOR OPENER SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair or replace harness.

3.CHECK BACK DOOR OPENER SWITCH GROUND CIRCUIT

Check continuity between back door opener switch assembly harness connector and ground.

| Back door opener switch assembly | | Ground | Continuity |
|----------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D186 | 2 | | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK BACK DOOR OPENER SWITCH

Refer to [DLK-272, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace back door opener switch assembly.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649187

1.CHECK BACK DOOR OPENER SWITCH

1. Turn ignition switch OFF.
2. Disconnect back door opener switch assembly connector.
3. Check continuity between back door opener switch assembly terminals.

| Back door opener switch assembly | | Condition | Continuity |
|----------------------------------|---|------------------------------------|-------------|
| Terminal | | | |
| 1 | 2 | Back door opener switch Pressed | Existed |
| | | Released | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace back door opener switch assembly.

INTELLIGENT KEY WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

INTELLIGENT KEY WARNING BUZZER

Component Function Check

INFOID:000000009649188

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "OUTSIDE BUZZER" in "ACTIVE TEST" mode.
3. Touch "On" or "Off" to check that it works normally.

Is the inspection result normal?

- YES >> Intelligent Key warning buzzer is OK.
NO >> Refer to [DLK-273. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649189

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 15 A fuse, [No. 6, located in fuse block (J/B)].

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK INTELLIGENT KEY WARNING BUZZER POWER SUPPLY CIRCUIT

1. Disconnect Intelligent Key warning buzzer connector.
2. Check voltage between Intelligent Key warning buzzer harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| E26 | 1 | Ground | 9 - 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3.CHECK INTELLIGENT KEY WARNING BUZZER CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between BCM harness connector and Intelligent Key warning buzzer harness connector.

| BCM | | Intelligent Key warning buzzer | | Continuity |
|-----------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M124 | 93 | E26 | 3 | Existed |

3. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M124 | 93 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK INTELLIGENT KEY WARNING BUZZER

Refer to [DLK-274. "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).
NO >> Replace Intelligent Key warning buzzer.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTELLIGENT KEY WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

Component Inspection

INFOID:000000009649190

1. CHECK INTELLIGENT KEY WARNING BUZZER

1. Turn ignition switch OFF.
2. Disconnect Intelligent Key warning buzzer connector.
3. Connect battery power supply directly to Intelligent Key warning buzzer terminals and check the operation.

| Intelligent Key warning buzzer | | Operation |
|--------------------------------|-----|---------------|
| Terminal | | |
| (+) | (-) | |
| 1 | 3 | Buzzer sounds |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace Intelligent Key warning buzzer.

INTELLIGENT KEY

< DTC/CIRCUIT DIAGNOSIS >

INTELLIGENT KEY

Component Function Check

INFOID:000000009649191

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "RKE OPE COUN1" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition |
|---------------|--|
| RKE OPE COUN1 | Check that the numerical value is changing while operating on the Intelligent Key. |

Is the inspection result normal?

- YES >> Intelligent Key is OK.
NO >> Refer to [DLK-275. "Component Inspection"](#).

Component Inspection

INFOID:000000009649192


1.CHECK INTELLIGENT KEY BATTERY

Check by connecting a resistance (approximately 300Ω) so that the current value becomes about 10 mA. Refer to [DLK-493. "Removal and Installation"](#).

Standard : Approx. 2.5 - 3.0V

Is the measurement value within the specification?

- YES >> INSPECTION END
NO >> Replace Intelligent Key battery.



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

COMBINATION METER BUZZER

< DTC/CIRCUIT DIAGNOSIS >

COMBINATION METER BUZZER

Component Function Check

INFOID:000000009649193

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INSIDE BUZZER" in "ACTIVE TEST" mode.
3. Touch "Key", "Knob" or "Take Out" to check that it works normally.

Is the inspection result normal?

- Yes >> Combination meter buzzer is OK.
No >> Refer to [DLK-276, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649194

1.CHECK COMBINATION METER BUZZER CIRCUIT

Refer to [WCS-40, "Component Function Check"](#).

Is the inspection result normal?

- Yes >> GO TO 2.
No >> Repair or replace the malfunctioning parts.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

INFORMATION DISPLAY

< DTC/CIRCUIT DIAGNOSIS >

INFORMATION DISPLAY

Component Function Check

INFOID:000000009649195

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "LCD" in "ACTIVE TEST" mode.
3. Check each warning display on meter display.

Is the inspection result normal?

YES >> Information display is OK.

NO >> Refer to [DLK-277. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649196

1.CHECK COMBINATION METER

Refer to [MWI-34. "On Board Diagnosis Function"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

KEY WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

KEY WARNING LAMP

Component Function Check

INFOID:000000009649197

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "INDICATOR" in "ACTIVE TEST" mode.
3. Touch "KEY IND" or "KEY ON" to check that it works normally.

Is the inspection result normal?

- YES >> Key warning lamp is OK.
NO >> Refer to [DLK-278, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649198

1.CHECK KEY WARNING LAMP

Refer to [MWI-34, "On Board Diagnosis Function"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace the malfunctioning parts.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

HAZARD FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

HAZARD FUNCTION

Component Function Check

INFOID:000000009649199

1.CHECK FUNCTION

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "FLASHER" in "ACTIVE TEST" mode.
3. Touch "LH" or "RH" to check that it works normally.

Is the inspection result normal?

YES >> Hazard warning lamp circuit is OK.

NO >> Refer to [DLK-279. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649200

1.CHECK HAZARD SWITCH CIRCUIT

Refer to [EXL-86. "Component Function Check"](#) (xenon type), [EXL-196. "Component Function Check"](#) (halo-gen type) .

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

BACK DOOR OPEN REQUEST SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

BACK DOOR OPEN REQUEST SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:000000009649201

1. CHECK BACK DOOR CONTROL UNIT INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect back door control unit connector.
3. Check voltage between back door control unit harness connector and ground.

| (+) | | (-) | Condition | Voltage | |
|------------------------|----------|--------|-------------------------|----------|-----------|
| Back door control unit | | | | | |
| Connector | Terminal | | | | |
| D181 | 6 | Ground | Back door opener switch | Pressed | 0 - 1.5 V |
| | | | | Released | 8 - 16 V |

Is the inspection result normal?

YES >> Replace back door control unit. Refer to [DLK-494. "Removal and Installation"](#).

NO >> GO TO 2.

2. CHECK BACK DOOR CONTROL UNIT CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between back door control unit harness connector and BCM harness connector.

| Back door control unit | | BCM | | Continuity |
|------------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D181 | 6 | M122 | 53 | Existed |

3. Check continuity between BCM harness connector and ground.

| Back door control unit | | Ground | Continuity |
|------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D181 | 6 | | Not existed |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK BCM OUTPUT SIGNAL

1. Connect BCM connector.
2. Check voltage between BCM harness connector and ground.

| (+) | | (-) | Condition | Voltage | |
|-----------|----------|--------|-------------------------|----------|----------|
| BCM | | | | | |
| Connector | Terminal | | | | |
| M122 | 53 | Ground | Back door opener switch | Pressed | 0 V |
| | | | | Released | 9 - 16 V |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

AUTOMATIC BACK DOOR CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

AUTOMATIC BACK DOOR CLOSE SWITCH

Component Function Check

INFOID:000000009649202

1.CHECK FUNCTION

1. Select "AUTO BACK DOOR" using CONSULT.
2. Select "BK DOOR CL SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|---------------|----------------------------------|----------|--------|
| BK DOOR CL SW | Automatic back door close switch | Pressed | ON |
| | | Released | OFF |

Is the inspection result normal?

- YES >> Automatic back door close switch is OK.
NO >> Refer to [DLK-281, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649203

1.CHECK AUTOMATIC BACK DOOR CLOSE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect automatic back door close switch connector.
3. Check voltage between automatic back door close switch harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| D169 | 1 | Ground | 9 - 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK AUTOMATIC BACK DOOR CLOSE SWITCH CIRCUIT

1. Disconnect automatic back door control module connector.
2. Check continuity between automatic back door control module harness connector and automatic back door close switch harness connector.

| Automatic back door control module | | Automatic back door close switch | | Continuity |
|------------------------------------|----------|----------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 4 | D169 | 1 | Existed |

3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 4 | | Not existed |

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK AUTOMATIC BACK DOOR CLOSE SWITCH GROUND CIRCUIT

Check continuity between automatic back door close switch harness connector and ground.

AUTOMATIC BACK DOOR CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Automatic back door close switch | | Ground | Continuity |
|----------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D169 | 2 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK AUTOMATIC BACK DOOR CLOSE SWITCH

Refer to [DLK-282, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace automatic back door close switch.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649204

1.CHECK AUTOMATIC BACK DOOR CLOSE SWITCH

1. Turn ignition switch OFF.
2. Disconnect automatic back door close switch connector.
3. Check continuity between automatic back door close switch terminals.

| Automatic back door close switch | | Condition | | Continuity |
|----------------------------------|---|----------------------------------|----------|-------------|
| Terminal | | | | |
| 1 | 2 | Automatic back door close switch | Pressed | Existed |
| | | | Released | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace automatic back door close switch.

AUTOMATIC DOOR MAIN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

AUTOMATIC DOOR MAIN SWITCH

AUTOMATIC BACK DOOR CONTROL MODULE

AUTOMATIC BACK DOOR CONTROL MODULE : Component Function Check

INFOID:000000009649205

1. CHECK FUNCTION

1. Select "AUTO BACK DOOR" using CONSULT.
2. Select "MAIN SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | Status |
|--------------|--------------------------------|--------|
| MAIN SW | Automatic door main switch ON | ON |
| | Automatic door main switch OFF | OFF |

Is the inspection result normal?

YES >> Automatic door main switch is OK.

NO >> Refer to [DLK-283. "AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure"](#).

AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure

INFOID:000000009649206

1. CHECK AUTOMATIC DOOR MAIN SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect automatic door main switch connector.
3. Check voltage between automatic door main switch harness connector and ground.

| (+) Automatic door main switch | | (-) | Voltage |
|--------------------------------|----------|--------|----------|
| Connector | Terminal | | |
| M29 | 1 | Ground | 9 - 16 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK AUTOMATIC DOOR MAIN SWITCH CIRCUIT

1. Disconnect automatic back door control module connector.
2. Check continuity between automatic back door control module harness connector and automatic door main switch harness connector.

| Automatic back door control module | | Automatic door main switch | | Continuity |
|------------------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 17 | M29 | 1 | Existed |

3. Check continuity between automatic back door control module connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 17 | | Not existed |

Is the inspection result normal?

YES >> Replace automatic back door control module. Refer to [DLK-495. "Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK AUTOMATIC DOOR MAIN SWITCH GROUND CIRCUIT

Check continuity between automatic door main switch connector and ground.

AUTOMATIC DOOR MAIN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Automatic door main switch | | Ground | Continuity |
|----------------------------|----------|--------|------------|
| Connector | Terminal | | Existed |
| M29 | 3 | | |

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace harness.

4.CHECK AUTOMATIC DOOR MAIN SWITCH

Refer to [DLK-284, "AUTOMATIC BACK DOOR CONTROL MODULE : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Replace automatic door main switch.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

AUTOMATIC BACK DOOR CONTROL MODULE : Component Inspection INFOID:000000009649207

1.CHECK AUTOMATIC DOOR MAIN SWITCH

1. Turn ignition switch OFF.
2. Disconnect automatic door main switch connector.
3. Check continuity between automatic door main switch terminals.

| Automatic door main switch | | Condition | | Continuity |
|----------------------------|---|----------------------------|-----|-------------|
| Terminal | | | | |
| 1 | 3 | Automatic door main switch | ON | Existed |
| | | | OFF | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Replace automatic door main switch.

SLIDING DOOR CONTROL UNIT

SLIDING DOOR CONTROL UNIT : Component Function Check INFOID:000000009649208

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" (LH) or "AUTO SLIDE DOOR RIGHT" (RH) using CONSULT.
2. Select "MAIN SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|----------------------------|-----|--------|
| MAIN SW | Automatic door main switch | ON | ON |
| | | OFF | OFF |

Is the inspection result normal?

- YES >> Automatic door main switch is OK.
- NO >> Refer to [DLK-284, "SLIDING DOOR CONTROL UNIT : Diagnosis Procedure"](#).

SLIDING DOOR CONTROL UNIT : Diagnosis Procedure INFOID:000000009649209

1.CHECK AUTOMATIC DOOR MAIN SWITCH POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect automatic door main switch connector.

AUTOMATIC DOOR MAIN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3. Check voltage between automatic door main switch harness connector and ground.

| (+) | | (-) | Voltage (Approx.) |
|----------------------------|----------|--------|----------------------|
| Automatic door main switch | | | |
| Connector | Terminal | | |
| M29 | 1 | Ground | 8 – 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK AUTOMATIC DOOR MAIN SWITCH CIRCUIT

1. Disconnect sliding door control unit connector.
2. Check continuity between sliding door control unit harness connector and automatic door main switch harness connector.

Sliding door LH

| Sliding door control unit LH | | Automatic door main switch | | Continuity |
|------------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 1 | M29 | 1 | Existed |

Sliding door RH

| Sliding door control unit LH | | Automatic door main switch | | Continuity |
|------------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 1 | M29 | 1 | Existed |

3. Check continuity between sliding door control unit connector and ground.

Sliding door LH

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 1 | | Not existed |

Sliding door RH

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 1 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit.
 NO >> Repair or replace harness.

3. CHECK AUTOMATIC DOOR MAIN SWITCH GROUND CIRCUIT

Check continuity between automatic door main switch connector and ground.

| Automatic door main switch | | Ground | Continuity |
|----------------------------|----------|--------|------------|
| Connector | Terminal | | |
| M29 | 3 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4. CHECK AUTOMATIC DOOR MAIN SWITCH

Refer to [DLK-286, "SLIDING DOOR CONTROL UNIT : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace automatic door main switch.

AUTOMATIC DOOR MAIN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR CONTROL UNIT : Component Inspection

INFOID:000000009649210

1.CHECK AUTOMATIC DOOR MAIN SWITCH

1. Turn ignition switch OFF.
2. Disconnect automatic door main switch connector.
3. Check continuity between automatic door main switch terminals.

| Automatic door main switch | | Condition | | Continuity |
|----------------------------|---|----------------------------|-----|-------------|
| Terminal | | | | |
| 1 | 3 | Automatic door main switch | ON | Existed |
| | | | OFF | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace automatic door main switch.

AUTOMATIC BACK DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

AUTOMATIC BACK DOOR SWITCH

Component Function Check

INFOID:000000009649211

1.CHECK FUNCTION

1. Select "AUTO BACK DOOR" using CONSULT.
2. Select "AUTO BD SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|----------------------------|----------|--------|
| AUTO BD SW | Automatic back door switch | Pressed | ON |
| | | Released | OFF |

Is the inspection result normal?

- YES >> Automatic back door switch is OK.
NO >> Refer to [DLK-287, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649212

1.CHECK AUTOMATIC BACK DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect automatic back door switch connector.
3. Check voltage between automatic back door switch harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| M83 | 1 | Ground | 9 - 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK AUTOMATIC BACK DOOR SWITCH CIRCUIT

1. Disconnect automatic back door control module connector.
2. Check continuity between automatic back door control module harness connector and automatic back door switch harness connector.

| Automatic back door control module | | Automatic back door switch | | Continuity |
|------------------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 16 | M83 | 1 | Existed |

3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 16 | | Not existed |

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK AUTOMATIC BACK DOOR SWITCH GROUND CIRCUIT

Check continuity between automatic back door switch harness connector and ground.

AUTOMATIC BACK DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Automatic back door switch | | Ground | Continuity |
|----------------------------|----------|--------|------------|
| Connector | Terminal | | Existed |
| M83 | 2 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK AUTOMATIC BACK DOOR SWITCH

Refer to [DLK-288, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace automatic back door switch.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649213

1.CHECK AUTOMATIC BACK DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect automatic back door switch connector.
3. Check continuity between automatic back door switch terminals.

| Automatic back door switch | | Condition | Continuity |
|----------------------------|---|---------------------------------------|-------------|
| Terminal | | | Existed |
| 1 | 2 | Automatic back door switch Pressed | Existed |
| | | Released | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace automatic back door switch.

OPEN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

OPEN SWITCH

Diagnosis Procedure

INFOID:000000009649214

1.CHECK OPEN SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check voltage between back door lock assembly harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------|----------|--------|----------|
| Back door lock assembly | | | |
| Connector | Terminal | | |
| D190 | 4 | Ground | 8 - 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK OPEN SWITCH CIRCUIT

1. Disconnect back door control unit connector.
2. Check continuity between back door control unit harness connector and back door lock assembly harness connector.

| Back door control unit | | Back door lock assembly | | Continuity |
|------------------------|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D181 | 5 | D190 | 4 | Existed |

3. Check continuity between back door control unit harness connector and ground.

| Back door control unit | | Ground | Continuity |
|------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D181 | 5 | | Not existed |

Is the inspection result normal?

- YES >> Replace back door control unit. Refer to [DLK-494, "Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK OPEN SWITCH GROUND CIRCUIT

Check continuity between back door lock assembly connector and ground.

| Back door lock assembly | | Ground | Continuity |
|-------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D190 | 8 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK OPEN SWITCH

Refer to [DLK-290, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace back door lock assembly.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

OPEN SWITCH

< DTC/CIRCUIT DIAGNOSIS >

>> INSPECTION END

Component Inspection

INFOID:000000009649215

1. CHECK OPEN SWITCH

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check continuity between back door lock assembly terminals.

| Back door lock assembly | | Condition | | Continuity |
|-------------------------|---|-----------|-------------------------|-------------|
| Terminal | | | | |
| 4 | 8 | Back door | Open | Existed |
| | | | Fully closed/Half latch | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace back door lock assembly.

CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

CLOSE SWITCH

Diagnosis Procedure

INFOID:000000009649216

1.CHECK CLOSE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check voltage between back door lock assembly harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------|----------|--------|---------|
| Back door lock assembly | | | |
| Connector | Terminal | | |
| D190 | 5 | Ground | 8 - 16 |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK CLOSE SWITCH CIRCUIT

1. Disconnect back door control unit connector.
2. Check continuity between back door control unit harness connector and back door lock assembly harness connector.

| Back door control unit | | Back door lock assembly | | Continuity |
|------------------------|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D181 | 1 | D190 | 5 | Existed |

3. Check continuity between back door control unit harness connector and ground.

| Back door control unit | | Ground | Continuity |
|------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D181 | 1 | | Not existed |

Is the inspection result normal?

YES >> Replace back door control unit. Refer to [DLK-494, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK CLOSE SWITCH GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

| Back door lock assembly | | Ground | Continuity |
|-------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D190 | 8 | | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK CLOSE SWITCH

Refer to [DLK-292, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace back door lock assembly.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

>> INSPECTION END

Component Inspection

INFOID:000000009649217

1. CHECK CLOSE SWITCH

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check continuity between back door lock assembly terminals.

| Back door lock assembly | | Condition | Continuity |
|-------------------------|---|-----------|--------------------------------|
| Terminal | | | |
| 5 | 8 | Back door | Fully closed Existed |
| | | | Open/Half latch Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace back door lock assembly.

HALF LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

HALF LATCH SWITCH WITH AUTOMATIC BACK DOOR

WITH AUTOMATIC BACK DOOR : Component Function Check

INFOID:000000009649218

1. CHECK FUNCTION

1. Select "AUTO BACK DOOR" using CONSULT.
2. Select "HALF LATCH SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|---------------|-----------|-------------------------|--------|
| HALF LATCH SW | Back door | Fully closed/Half latch | OFF |
| | | Open | ON |

Is the inspection result normal?

YES >> Half latch switch is OK.

NO >> Refer to [DLK-293, "WITH AUTOMATIC BACK DOOR : Diagnosis Procedure"](#).

WITH AUTOMATIC BACK DOOR : Diagnosis Procedure

INFOID:000000009649219

1. CHECK HALF LATCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check voltage between back door lock assembly harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------|----------|--------|----------|
| Back door lock assembly | | | |
| Connector | Terminal | Ground | 9 - 16 V |
| D190 | 6 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HALF LATCH SWITCH CIRCUIT

1. Disconnect automatic back door control module connector.
2. Check continuity between automatic back door control module harness connector and back door lock assembly harness connector.

| Automatic back door control module | | Back door lock assembly | | Continuity |
|------------------------------------|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 22 | D190 | 6 | Existed |

3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | Not existed |
| B8 | 22 | | |

Is the inspection result normal?

YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK HALF LATCH SWITCH GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HALF LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Back door lock assembly | | Ground | Continuity |
|-------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D190 | 8 | | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace back door lock assembly ground circuit.

4.CHECK HALF LATCH SWITCH

Refer to [DLK-294, "WITH AUTOMATIC BACK DOOR : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace back door lock assembly.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

WITH AUTOMATIC BACK DOOR : Component Inspection

INFOID:000000009649220

1.CHECK HALF LATCH SWITCH

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check continuity between back door lock assembly terminals.

| Back door lock assembly | | Condition | Continuity |
|-------------------------|---|----------------|-------------|
| Terminal | | | |
| 6 | 8 | Back door lock | Existed |
| | | | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace back door lock assembly.

WITHOUT AUTOMATIC BACK DOOR

WITHOUT AUTOMATIC BACK DOOR : Diagnosis Procedure

INFOID:000000009649221

1.CHECK HALF LATCH SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check voltage between back door lock assembly harness connector and ground.

| (-) | | (-) | Voltage |
|-------------------------|----------|--------|------------|
| Back door lock assembly | | | |
| Connector | Terminal | | |
| D190 | 6 | Ground | 3.5 -5.5 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK HALF LATCH SWITCH CIRCUIT

1. Disconnect back door control unit connector.
2. Check continuity between back door control unit harness connector.

HALF LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Back door control unit | | Back door lock assembly | | Continuity |
|------------------------|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D181 | 2 | D190 | 6 | Existed |

3. Check continuity between back door control unit harness connector and ground.

| Back door control unit | | Ground | Continuity |
|------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D181 | 2 | | Not existed |

Is the inspection result normal?

YES >> Replace back door control unit. Refer to [DLK-494, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK HALF LATCH SWITCH GROUND CIRCUIT

Check continuity between back door lock assembly harness connector and ground.

| Back door lock assembly | | Ground | Continuity |
|-------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D190 | 8 | | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK HALF LATCH SWITCH

Refer to [DLK-295, "WITHOUT AUTOMATIC BACK DOOR : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace back door lock assembly.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

WITHOUT AUTOMATIC BACK DOOR : Component Inspection

INFOID:000000009649222

1.CHECK HALF LATCH SWITCH

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check continuity between back door lock assembly terminals.

| Back door lock assembly | | Condition | Continuity |
|-------------------------|---|-------------------------|-------------|
| Terminal | | | |
| 6 | 8 | Open | Existed |
| | | Fully closed/Half latch | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace back door lock assembly.

SLIDING DOOR CONTROL UNIT

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HALF LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR CONTROL UNIT : Component Function Check

INFOID:000000009649223

1. CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" (LH) or "AUTO SLIDE DOOR RIGHT" (RH) using CONSULT.
2. Select "HAF LATC SW L" (LH) or "HAF LATC SW R" (RH) in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|---------------|-----------------|-------------------------|--------|
| HAF LATC SW L | Sliding door LH | Open | ON |
| | | Half latch/fully closed | OFF |
| HAF LATC SW R | Sliding door RH | Open | ON |
| | | Half latch/fully closed | OFF |

Is the inspection result normal?

YES >> Half latch switch is OK.

NO >> Refer to [DLK-298, "SLIDING DOOR CONTROL UNIT : Component Inspection"](#).

SLIDING DOOR CONTROL UNIT : Diagnosis Procedure

INFOID:000000009649224

1. CHECK HALF LATCH SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly connector.
3. Check voltage between sliding door lock assembly harness connector and ground.

Sliding door LH

| (+) | | (-) | Voltage |
|-------------------------------|----------|--------|----------|
| Sliding door lock assembly LH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| D123 | 3 | | |

Sliding door RH

| (+) | | (-) | Voltage |
|-------------------------------|----------|--------|----------|
| Sliding door lock assembly RH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| D124 | 3 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK HALF LATCH SWITCH CIRCUIT

1. Disconnect sliding door control unit connector.
2. Check continuity between sliding door control unit harness connector and sliding door lock assembly harness connector.

Sliding door LH

| Sliding door control unit LH | | Sliding door lock assembly LH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 5 | D123 | 3 | Existed |

Sliding door RH

| Sliding door control unit RH | | Sliding door lock assembly RH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 5 | D124 | 3 | Existed |

3. Check continuity between sliding door control unit harness connector and ground.

HALF LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door LH | | | |
|------------------------------|----------|--------|-------------|
| Sliding door control unit LH | | Ground | Continuity |
| Connector | Terminal | | |
| B45 | 5 | | Not existed |

| Sliding door RH | | | |
|------------------------------|----------|--------|-------------|
| Sliding door control unit RH | | Ground | Continuity |
| Connector | Terminal | | |
| B247 | 5 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit.

NO >> Repair or replace harness.

3. CHECK HALF LATCH SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit connector.
2. Check continuity between sliding door control unit harness connector and sliding door lock assembly harness connector.

| Sliding door LH | | | | |
|------------------------------|----------|-------------------------------|----------|------------|
| Sliding door control unit LH | | Sliding door lock assembly LH | | Continuity |
| Connector | Terminal | Connector | Terminal | |
| B45 | 23 | D123 | 2 | |

| Sliding door RH | | | | |
|------------------------------|----------|-------------------------------|----------|------------|
| Sliding door control unit RH | | Sliding door lock assembly RH | | Continuity |
| Connector | Terminal | Connector | Terminal | |
| B247 | 23 | D124 | 2 | |

3. Check continuity between sliding door control unit harness connector and ground.

| Sliding door LH | | | |
|------------------------------|----------|--------|-------------|
| Sliding door control unit LH | | Ground | Continuity |
| Connector | Terminal | | |
| B45 | 23 | | Not existed |

| Sliding door RH | | | |
|------------------------------|----------|--------|-------------|
| Sliding door control unit RH | | Ground | Continuity |
| Connector | Terminal | | |
| B247 | 23 | | Not existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK HALF LATCH SWITCH CIRCUIT 2

1. Connect sliding door control unit connector and sliding door lock assembly connector.
2. Check voltage between sliding door control unit harness connector and ground.

| Sliding door LH | | | |
|------------------------------|----------|--------|---------|
| (+) | | (-) | Voltage |
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B45 | 23 | Ground | 0 V |

HALF LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Sliding door RH

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | Ground | 0 V |
| B247 | 23 | | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace sliding door control unit.

5.CHECK HALF LATCH SWITCH

Refer to [DLK-298, "SLIDING DOOR CONTROL UNIT : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace sliding door lock assembly

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR CONTROL UNIT : Component Inspection

INFOID:000000009649225

1.CHECK HALF LATCH SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly connector.
3. Check continuity between sliding door lock assembly terminals.

| Sliding door lock assembly | | Condition | Continuity |
|----------------------------|---|--------------|--|
| Terminal | | | |
| 3 | 2 | Sliding door | Open Existed |
| | | | Half latch/fully closed Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sliding door lock assembly.

BACK DOOR TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

BACK DOOR TOUCH SENSOR

LH

LH : Component Function Check

INFOID:000000009649226

1. CHECK FUNCTION

1. Select "AUTO BACK DOOR" using CONSULT.
2. Select "TOUCH SEN LH" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|---------------------------|--------------------|--------|
| TOUCH SEN LH | Back door touch sensor LH | Other than below | OFF |
| | | Detect obstruction | ON |

Is the inspection result normal?

- YES >> Back door touch sensor LH is OK.
 NO >> Refer to [DLK-299, "LH : Diagnosis Procedure"](#).

LH : Diagnosis Procedure

INFOID:000000009649227

1. CHECK BACK DOOR TOUCH SENSOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between back door touch sensor LH harness connector and automatic back door control module harness connector.

| (+) | | (-) | | Condition | Voltage | |
|---------------------------|----------|------------------------------------|----------|---------------------------|--------------------|-----------|
| Back door touch sensor LH | | Automatic back door control module | | | | |
| Connector | Terminal | Connector | Terminal | | | |
| D165 | 1 | B8 | 14 | Back door touch sensor LH | Detect obstruction | 0 – 1.5 V |
| | | | | | Other than above | 5 – 6.7 V |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK BACK DOOR TOUCH SENSOR LH CIRCUIT

1. Disconnect automatic back door control module connector and back door touch sensor LH connector.
2. Check continuity between automatic back door control module harness connector and back door touch sensor LH harness connector.

| Automatic back door control module | | Back door touch sensor LH | | Continuity |
|------------------------------------|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 15 | D165 | 1 | Existed |

3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 15 | | Not existed |

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
 NO >> Repair or replace harness.

BACK DOOR TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK BACK DOOR TOUCH SENSOR LH GROUND CIRCUIT

1. Disconnect automatic back door control module connector and back door touch sensor LH connector.
2. Check continuity between automatic back door control module harness connector and back door touch sensor LH harness connector.

| Automatic back door control module | | Back door touch sensor LH | | Continuity |
|------------------------------------|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 14 | D165 | 2 | Existed |

3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 14 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4. CHECK BACK DOOR TOUCH SENSOR LH GROUND CIRCUIT 2

1. Connect automatic back door control module connector and back door touch sensor LH connector.
2. Check voltage between automatic back door control module harness connector and ground.

| Automatic back door control module (+) | | (-) | Voltage |
|--|----------|--------|-----------|
| Connector | Terminal | | |
| B8 | 14 | Ground | 0 - 1.5 V |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).

5. CHECK BACK DOOR TOUCH SENSOR LH

Refer to [DLK-300, "LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Replace back door touch sensor LH.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

LH : Component Inspection

INFOID:000000009649228

1. CHECK BACK DOOR TOUCH SENSOR LH

1. Turn ignition switch OFF.
2. Disconnect back door touch sensor LH connector.
3. Check resistance between back door touch sensor LH terminals.

| Back door touch sensor LH | | Condition | | Resistance |
|---------------------------|---|---------------------------|--------------------|--------------|
| Terminal | | | | |
| 1 | 2 | Back door touch sensor LH | Detect obstruction | 360 - 440 Ω |
| | | | Other than above | 0.9 - 1.1 kΩ |

Is the inspection result normal?

BACK DOOR TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

- YES >> INSPECTION END
 NO >> Replace back door touch sensor LH.

RH

RH : Component Function Check

INFOID:000000009649229

1.CHECK FUNCTION

1. Select "AUTO BACK DOOR" using CONSULT.
2. Select "TOUCH SEN RH" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|---------------------------|--------------------|--------|
| TOUCH SEN RH | Back door touch sensor RH | Other than below | OFF |
| | | Detect obstruction | ON |

Is the inspection result normal?

- YES >> Back door touch sensor RH is OK.
 NO >> Refer to [DLK-301. "RH : Diagnosis Procedure"](#).

RH : Diagnosis Procedure

INFOID:000000009649230

1.CHECK TOUCH SENSOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between back door touch sensor RH harness connector and automatic back door control module harness connector.

| (+) | | (-) | | Condition | Voltage | |
|---------------------------|----------|------------------------------------|----------|---------------------------|--------------------|-----------|
| Back door touch sensor RH | | Automatic back door control module | | | | |
| Connector | Terminal | Connector | Terminal | | | |
| D191 | 1 | B8 | 14 | Back door touch sensor RH | Detect obstruction | 0 – 1.5 V |
| | | | | | Other than above | 5 – 6.7 V |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK BACK DOOR TOUCH SENSOR RH CIRCUIT

1. Disconnect automatic back door control module connector and back door touch sensor RH connector.
2. Check continuity between automatic back door control module harness connector and back door touch sensor RH harness connector.

| Automatic back door control module | | Back door touch sensor RH | | Continuity |
|------------------------------------|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 13 | D191 | 1 | Existed |

3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 13 | | Not existed |

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495. "Removal and Installation"](#).
 NO >> Repair or replace harness.

BACK DOOR TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK BACK DOOR TOUCH SENSOR RH GROUND CIRCUIT

1. Disconnect automatic back door control module connector and back door touch sensor RH connector.
2. Check continuity between automatic back door control module harness connector and back door touch sensor RH harness connector.

| Automatic back door control module | | Back door touch sensor RH | | Continuity |
|------------------------------------|----------|---------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 14 | D191 | 2 | Existed |

3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 14 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4. CHECK BACK DOOR TOUCH SENSOR RH GROUND CIRCUIT 2

1. Connect automatic back door control module connector and back door touch sensor RH connector.
2. Check voltage between automatic back door control module harness connector and ground.

| Automatic back door control module | | (-) | Voltage |
|------------------------------------|----------|--------|-----------|
| Connector | Terminal | | |
| B8 | 14 | Ground | 0 – 1.5 V |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).

5. CHECK BACK DOOR TOUCH SENSOR RH

Refer to [DLK-302, "RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Replace back door touch sensor RH.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

RH : Component Inspection

INFOID:000000009649231

1. CHECK TOUCH SENSOR RH

1. Turn ignition switch OFF.
2. Disconnect back door touch sensor RH connector.
3. Check resistance between back door touch sensor RH terminals.

| Back door touch sensor RH | | Condition | | Resistance |
|---------------------------|---|---------------------------|--------------------|--------------|
| Terminal | | | | |
| 1 | 2 | Back door touch sensor RH | Detect obstruction | 360 - 440 Ω |
| | | | Other than above | 0.9 - 1.1 kΩ |

Is the inspection result normal?

BACK DOOR TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

YES >> INSPECTION END
NO >> Replace back door touch sensor RH.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

BACK DOOR CLOSURE MOTOR

< DTC/CIRCUIT DIAGNOSIS >

BACK DOOR CLOSURE MOTOR WITH AUTOMATIC BACK DOOR

WITH AUTOMATIC BACK DOOR : Diagnosis Procedure

INFOID:000000009649232

1. CHECK BACK DOOR CLOSURE MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check voltage between back door lock assembly harness connector and ground.

| (+) | | (-) | Condition | Voltage | |
|-------------------------|----------|--------|-----------|------------------|-----------|
| Back door lock assembly | | | | | |
| Connector | Terminal | | | | |
| D190 | 1 | Ground | Back door | Open | 9 - 16 V |
| | | | | Other than above | 0 - 1.5 V |
| | 2 | | | Close | 9 - 16 V |
| | | | | Other than above | 0 - 1.5 V |

Is the inspection result normal?

- YES >> Replace back door lock assembly.
NO >> GO TO 2.

2. CHECK BACK DOOR CLOSURE MOTOR CIRCUIT

1. Disconnect automatic back door control module connector.
2. Check continuity between automatic back door control module harness connector and back door lock assembly harness connector.

| Automatic back door control module | | Back door lock assembly | | Continuity |
|------------------------------------|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 3 | D190 | 1 | Existed |
| | 2 | | 2 | |

3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 3 | | Not existed |
| | 2 | | |

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
NO >> Repair or replace harness.

WITHOUT AUTOMATIC BACK DOOR

WITHOUT AUTOMATIC BACK DOOR : Diagnosis Procedure

INFOID:000000009649233

1. CHECK BACK DOOR CLOSURE MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect back door lock assembly connector.
3. Check voltage between back door lock assembly harness connector and ground.

BACK DOOR CLOSURE MOTOR

< DTC/CIRCUIT DIAGNOSIS >

| (+) | | (-) | Condition | Voltage | |
|-------------------------|----------|--------|-----------|------------------|-----------|
| Back door lock assembly | | | | | |
| Connector | Terminal | | | | |
| D190 | 1 | Ground | Back door | Open | 5 - 16 V |
| | | | | Other than above | 0 - 1.5 V |
| | 2 | | | Close | 5 - 16 V |
| | | | | Other than above | 0 - 1.5 V |

Is the inspection result normal?

YES >> Replace back door lock assembly.

NO >> GO TO 2.

2. CHECK BACK DOOR CLOSURE MOTOR CIRCUIT

1. Disconnect back door control unit connector.
2. Check continuity between back door control unit harness connector and back door lock assembly harness connector.

| Back door control unit | | Back door lock assembly | | Continuity |
|------------------------|----------|-------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D181 | 10 | D190 | 1 | Existed |
| | 4 | | 2 | |

3. Check continuity between back door control unit harness connector and ground.

| Back door control unit | | Ground | Continuity |
|------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D181 | 10 | | Not existed |
| | 4 | | |

Is the inspection result normal?

YES >> Replace back door control unit.

NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

AUTOMATIC BACK DOOR WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

AUTOMATIC BACK DOOR WARNING BUZZER

Diagnosis Procedure

INFOID:000000009649234

1. CHECK AUTOMATIC BACK DOOR WARNING BUZZER POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic back door warning buzzer connector.
3. Check voltage between automatic back door warning buzzer harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| B305 | 1 | Ground | 9 - 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK FUSE

Check the following.

- 10 A fuse, [No.9, located in fuse block (J/B)].
- Harness for open or short between automatic back door warning buzzer harness connector and battery terminal.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace the malfunctioning parts.

3. CHECK AUTOMATIC BACK DOOR WARNING BUZZER OUTPUT SIGNAL CIRCUIT

1. Disconnect automatic back door control module connector.
2. Check continuity between automatic back door control module harness connector and automatic back door warning buzzer harness connector.

| Automatic back door control module | | Automatic back door warning buzzer | | Continuity |
|------------------------------------|----------|------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B8 | 5 | B305 | 2 | Existed |

3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B8 | 5 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4. CHECK AUTOMATIC BACK DOOR WARNING BUZZER

Refer to [DLK-306, "Component Inspection"](#)

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
NO >> Replace automatic back door warning buzzer.

Component Inspection

INFOID:000000009649235

1. CHECK AUTOMATIC BACK DOOR WARNING BUZZER

1. Turn ignition switch OFF.
2. Disconnect automatic back door warning buzzer connector.

AUTOMATIC BACK DOOR WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

3. Check battery power supply directly to automatic back door warning buzzer terminals and check the operation.

| Automatic back door warning buzzer | | Operation |
|------------------------------------|-----|---------------|
| Terminal | | |
| (+) | (-) | |
| 1 | 2 | Buzzer sounds |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace automatic back door warning buzzer.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

GROUND CIRCUIT

Component Function Check

INFOID:000000009649236

1.CHECK FUNCTION

1. Select "AUTO BACK DOOR" using CONSULT.
2. Select "DESTINATION" and "HAZARD" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|--|---------------|--------|
| DESTINATION | Circuit between automatic back door control module terminal 6 and ground | Normal | NAM |
| | | Open or short | JPN |
| HAZARD | Circuit between automatic back door control module terminal 8 and ground | Normal | ON |
| | | Open or short | OFF |

Is the inspection result normal?

- YES >> Automatic back door ground circuit is OK.
NO >> Refer to [DLK-308, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649237

1.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect automatic back door control module connector.
3. Check continuity between automatic back door control module harness connector and ground.

| Automatic back door control module | | Ground | Continuity |
|------------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B8 | 6 | | Existed |
| | 8 | | |

Is the inspection result normal?

- YES >> Replace automatic back door control module. Refer to [DLK-495, "Removal and Installation"](#).
NO >> Repair or replace harness.

INTEGRATED HOMELINK TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

INTEGRATED HOMELINK TRANSMITTER

Component Function Check

INFOID:000000009649238

1.CHECK FUNCTION

Check that system receiver (garage door opener, etc.) operates with original hand-held transmitter.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Receiver or hand-held transmitter is malfunctioning.

2.CHECK ILLUMINATE

1. Turn ignition switch OFF.
2. Does red light of transmitter illuminate when any transmitter button is pressed?

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Refer to [DLK-309. "Diagnosis Procedure"](#).

3.CHECK TRANSMITTER

Check transmitter with Tool*.

*:For details, refer to Technical Service Bulletin.

Is the inspection result normal?

- YES >> Receiver or hand-held transmitter malfunction, not vehicle related.
- NO >> Replace auto anti-dazzling inside mirror (integrated homelink transmitter).

Diagnosis Procedure

INFOID:000000009649239

1.CHECK POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect auto anti-dazzling inside mirror (integrated homelink transmitter) connector.
3. Check voltage between auto anti-dazzling inside mirror (integrated homelink transmitter) harness connector and ground.

| (+) | | (-) | Condition | | Voltage (Approx.) |
|--|----------|--------|-----------------|-----------------|-------------------|
| Auto anti-dazzling inside mirror (Integrated homelink transmitter) | | | Ground | Ignition switch | |
| Connector | Terminal | | | | |
| R25 | 6 | Ground | Ignition switch | ON | Battery voltage |
| | 10 | | | OFF | |

Is the inspection result normal?

- YES >> GO TO 2.
- NO-1 >> Check 10 A fuse [No. 6 and No 3 located in the fuse block (J/B)].
- NO-2 >> Harness for open or short between fuse and auto anti-dazzling inside mirror (integrated homelink transmitter).

2.CHECK GROUND CIRCUIT

Check continuity between auto anti-dazzling inside mirror (integrated homelink transmitter) harness connector and ground.

| Auto anti-dazzling inside mirror (Integrated homelink transmitter) | | Ground | Continuity |
|--|----------|--------|------------|
| Connector | Terminal | | |
| R25 | 8 | | Existed |

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTEGRATED HOMELINK TRANSMITTER

< DTC/CIRCUIT DIAGNOSIS >

3.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

ENCODER

SLIDING DOOR LH

SLIDING DOOR LH : Component Function Check

INFOID:000000009649240

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "ENCODER A LH" and "ENCODER B LH" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|-----------------|-------------------------|----------|
| ENCODER A LH | Sliding door LH | Moving (auto or manual) | HI ↔ LO |
| | | When stopped | HI or LO |
| ENCODER B LH | Sliding door LH | Moving (auto or manual) | HI ↔ LO |
| | | When stopped | HI or LO |

Is the inspection result normal?

YES >> Encoder is OK.

NO >> Refer to [DLK-311, "SLIDING DOOR LH : Diagnosis Procedure"](#).

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649241

1.CHECK ENCODER POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect automatic sliding door unit LH connector.
3. Check voltage between automatic sliding door unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| B65 | 5 | Ground | 8 – 16 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK ENCODER CIRCUIT 1

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 11 | B65 | 5 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 11 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK ENCODER CIRCUIT 2

1. Disconnect sliding door control unit LH connector.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 4 | B65 | 6 | Existed |
| | 21 | | 7 | |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 4 | | Not existed |
| | 21 | | |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK ENCODER GROUND CIRCUIT

1. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 26 | B65 | 8 | Existed |

2. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 26 | | Not existed |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK ENCODER CIRCUIT 3

1. Connect sliding door control unit LH connector and automatic sliding door unit LH connector.
2. Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B45 | 26 | Ground | 0 V |

Is the inspection result normal?

YES >> Replace automatic sliding door unit LH.

NO >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

SLIDING DOOR RH

SLIDING DOOR RH : Component Function Check

INFOID:000000009649242

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "ENCODER A RH" and "ENCODER B RH" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

| Monitor item | Condition | | Status |
|--------------|-----------------|-------------------------|----------|
| ENCODER A RH | Sliding door RH | Moving (auto or manual) | HI ⇔ LO |
| | | When stopped | HI or LO |
| ENCODER B RH | Sliding door RH | Moving (auto or manual) | HI ⇔ LO |
| | | When stopped | HI or LO |

Is the inspection result normal?

YES >> Encoder is OK.

NO >> Refer to [DLK-313. "SLIDING DOOR RH : Diagnosis Procedure"](#).

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649243

1.CHECK ENCODER POWER SUPPLY

1. Turn ignition switch OFF.
2. Disconnect automatic sliding door unit RH connector.
3. Check voltage between automatic sliding door unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|--------------------------------|----------|--------|----------|
| Automatic sliding door unit RH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| B244 | 5 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK ENCODER CIRCUIT 1

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 11 | B244 | 5 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 11 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK ENCODER CIRCUIT 2

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 4 | B244 | 7 | Existed |
| | 21 | | 6 | |

3. Check continuity between sliding door control unit RH harness connector and ground.

ENCODER

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 4 | | |
| | 21 | | Not existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK ENCODER GROUND CIRCUIT

1. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 26 | B244 | 8 | Existed |

2. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|------------|
| Connector | Terminal | | |
| B247 | 26 | | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

5.CHECK ENCODER CIRCUIT 3

1. Connect sliding door control unit RH connector and automatic sliding door unit RH connector.
2. Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | | |
| B247 | 26 | Ground | 0 V |

Is the inspection result normal?

YES >> Replace automatic sliding door unit RH.

NO >> Replace sliding door control unit RH. Refer to [DLK-500, "RH : Removal and Installation"](#).

SLIDING DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR SWITCH

SLIDING DOOR LH

SLIDING DOOR LH : Component Function Check

INFOID:000000009649244

1. CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "RR-LH DOOR SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | Status |
|---------------|-------------------------|--------|
| RR-LH DOOR SW | Sliding door LH Open | ON |
| | Closed | OFF |

Is the inspection result normal?

- YES >> Sliding door switch is OK
 NO >> Refer to [DLK-315, "SLIDING DOOR LH : Diagnosis Procedure"](#).

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649245

1. SLIDING DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door switch LH connector.
3. Check voltage between sliding door switch LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------|----------|--------|----------|
| Sliding door switch LH | | | |
| Connector | Terminal | | |
| B71 | 3 | Ground | 8 – 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK SLIDING DOOR SWITCH CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door switch LH harness connector.

| Sliding door control unit LH | | Sliding door switch LH | | Continuity |
|------------------------------|----------|------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 28 | B71 | 3 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 28 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).
 NO >> Repair or replace harness.

3. CHECK SLIDING DOOR SWITCH

Refer to [DLK-316, "SLIDING DOOR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.

SLIDING DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace sliding door switch LH.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR LH : Component Inspection

INFOID:000000009649246

1.CHECK SLIDING DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding door switch LH connector.
3. Check continuity between sliding door switch LH terminals.

| Sliding door switch LH | | Condition | | Continuity |
|------------------------|----------------------------|------------------------|----------|-------------|
| Terminal | | | | |
| 3 | Ground part of door switch | Sliding door switch LH | Pressed | Existed |
| | | | Released | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sliding door switch LH.

SLIDING DOOR RH

SLIDING DOOR RH : Component Function Check

INFOID:000000009649247

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "RR-RH DOOR SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|---------------|-----------------|--------|--------|
| RR-RH DOOR SW | Sliding door RH | Open | ON |
| | | Closed | OFF |

Is the inspection result normal?

YES >> Sliding door switch is OK

NO >> Refer to [DLK-316, "SLIDING DOOR RH : Diagnosis Procedure"](#).

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649248

1.SLIDING DOOR SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door switch RH connector.
3. Check voltage between sliding door switch RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------|----------|--------|----------|
| Sliding door switch RH | | | |
| Connector | Terminal | | |
| B221 | 3 | Ground | 8 – 16 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK SLIDING DOOR SWITCH CIRCUIT

1. Disconnect sliding door control unit RH connector.

SLIDING DOOR SWITCH

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between sliding door control unit RH harness connector and sliding door switch RH harness connector.

| Sliding door control unit RH | | Sliding door switch RH | | Continuity |
|------------------------------|----------|------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 28 | B221 | 3 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 28 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).
 NO >> Repair or replace harness.

3.CHECK SLIDING DOOR SWITCH

Refer to [DLK-317. "SLIDING DOOR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Replace sliding door switch RH.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH : Component Inspection

INFOID:000000009649249

1.CHECK SLIDING DOOR SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding door switch RH connector.
3. Check continuity between sliding door switch RH terminals.

| Sliding door switch RH | | Condition | Continuity |
|------------------------|----------------------------|------------------------|-------------------------|
| Terminal | | | |
| 3 | Ground part of door switch | Sliding door switch RH | Pressed Existed |
| | | | Released Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace sliding door switch RH.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

FULL LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

FULL LATCH SWITCH SLIDING DOOR LH

SLIDING DOOR LH : Component Function Check

INFOID:000000009649251

1. CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "FULL LATCH SW L" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|-----------------|-----------------|------------------|--------|
| FULL LATCH SW L | Sliding door LH | Full close | OFF |
| | | Other than above | ON |

Is the inspection result normal?

YES >> Full latch switch is OK.

NO >> Refer to [DLK-318, "SLIDING DOOR LH : Diagnosis Procedure"](#).

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649251

1. CHECK FULL LATCH SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly LH connector.
3. Check voltage between sliding door lock assembly LH harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------------|----------|--------|----------|
| Sliding door lock assembly LH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| D123 | 5 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK FULL LATCH SWITCH CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door lock assembly LH harness connector.

| Sliding door control unit LH | | Sliding door lock assembly LH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 18 | D123 | 5 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 18 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK FULL LATCH SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door lock assembly LH harness connector.

FULL LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit LH | | Sliding door lock assembly LH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 23 | D123 | 2 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK FULL LATCH SWITCH CIRCUIT 2

1. Connect sliding door control unit LH connector and sliding door lock assembly LH connector.
2. Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B45 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door control unit LH. Refer to [DLK-500. "LH : Removal and Installation"](#).

5.CHECK FULL LATCH SWITCH

Refer to [DLK-319. "SLIDING DOOR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace sliding door lock assembly LH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR LH : Component Inspection

INFOID:000000009649252

1.CHECK FULL LATCH SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly LH connector.
3. Check continuity between sliding door lock assembly LH terminals.

| Sliding door lock assembly LH | | Condition | Continuity | |
|-------------------------------|---|-----------------|------------------|-------------|
| Terminal | | | | |
| 5 | 2 | Sliding door LH | Full close | Not existed |
| | | | Other than above | Existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace sliding door lock assembly LH.

SLIDING DOOR RH

FULL LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR RH : Component Function Check

INFOID:000000009649253

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "FUL LATCH SW R" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|----------------|-----------------|------------------|--------|
| FUL LATCH SW R | Sliding door RH | Full close | OFF |
| | | Other than above | ON |

Is the inspection result normal?

YES >> Full latch switch is OK.

NO >> Refer to [DLK-320, "SLIDING DOOR RH : Diagnosis Procedure"](#).

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649254

1.CHECK FULL LATCH SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly RH connector.
3. Check voltage between sliding door lock assembly RH harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------------|----------|--------|----------|
| Sliding door lock assembly RH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| D124 | 5 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK FULL LATCH SWITCH CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door lock assembly RH harness connector.

| Sliding door control unit RH | | Sliding door lock assembly RH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 18 | D124 | 5 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 18 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit RH. Refer to [DLK-500, "RH : Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK FULL LATCH SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door lock assembly RH harness connector.

FULL LATCH SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Sliding door lock assembly RH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 23 | D124 | 2 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK FULL LATCH SWITCH CIRCUIT 2

1. Connect sliding door control unit RH connector and sliding door lock assembly RH connector.
2. Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | | |
| B247 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

5.CHECK FULL LATCH SWITCH

Refer to [DLK-321. "SLIDING DOOR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace sliding door lock assembly RH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH : Component Inspection

INFOID:000000009649255

1.CHECK FULL LATCH SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly RH connector.
3. Check continuity between sliding door lock assembly RH terminals.

| Sliding door lock assembly RH | | Condition | Continuity | |
|-------------------------------|---|-----------------|------------------|-------------|
| Terminal | | | | |
| 5 | 2 | Sliding door RH | Full close | Not existed |
| | | | Other than above | Existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace sliding door lock assembly RH.

NEUTRAL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

NEUTRAL SWITCH SLIDING DOOR LH

SLIDING DOOR LH : Component Function Check

INFOID:000000009649256

1. CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "NEUTRAL SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|-------------------------------|------------------|--------|
| NEUTRAL SW | Sliding door closure motor LH | Neutral position | OFF |
| | | Other than above | ON |

Is the inspection result normal?

- YES >> Neutral switch is OK.
NO >> Refer to [DLK-322, "SLIDING DOOR LH : Diagnosis Procedure"](#).

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649257

1. CHECK NEUTRAL SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly LH connector.
3. Check voltage between sliding door lock assembly LH harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------------|----------|--------|----------|
| Sliding door lock assembly LH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| D123 | 6 | | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK NEUTRAL SWITCH CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door lock assembly LH harness connector.

| Sliding door control unit LH | | Sliding door lock assembly LH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 15 | D123 | 6 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 15 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK NEUTRAL SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit LH connector.

NEUTRAL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

- Check continuity between sliding door control unit LH harness connector and sliding door lock assembly LH harness connector.

| Sliding door control unit LH | | Sliding door lock assembly LH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 23 | D123 | 2 | Existed |

- Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK NEUTRAL SWITCH CIRCUIT 2

- Connect sliding door control unit LH connector and sliding door lock assembly LH connector.
- Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B45 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

5.CHECK NEUTRAL SWITCH

Refer to [DLK-323, "SLIDING DOOR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Replace sliding door lock assembly LH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR LH : Component Inspection

INFOID:000000009649258

1.CHECK NEUTRAL SWITCH

- Turn ignition switch OFF.
- Disconnect sliding door lock assembly LH connector.
- Check continuity between sliding door lock assembly LH terminals.

| Sliding door lock assembly LH | | Condition | Continuity |
|-------------------------------|---|-------------------------------|---------------------------------|
| Terminal | | | |
| 6 | 2 | Sliding door closure motor LH | Neutral position Not existed |
| | | | Other than above Existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace sliding door lock assembly LH.

SLIDING DOOR RH

NEUTRAL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR RH : Component Function Check

INFOID:000000009649259

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "NEUTRAL SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|-------------------------------|------------------|--------|
| NEUTRAL SW | Sliding door closure motor RH | Neutral position | OFF |
| | | Other than above | ON |

Is the inspection result normal?

YES >> Neutral switch is OK.

NO >> Refer to [DLK-324, "SLIDING DOOR RH : Diagnosis Procedure"](#).

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649260

1.CHECK NEUTRAL SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly RH connector.
3. Check voltage between sliding door lock assembly RH harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------------|----------|--------|----------|
| Sliding door lock assembly RH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| D124 | 6 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK NEUTRAL SWITCH CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door lock assembly RH harness connector.

| Sliding door control unit RH | | Sliding door lock assembly RH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 15 | D124 | 6 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 15 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit RH. Refer to [DLK-500, "RH : Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK NEUTRAL SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door lock assembly RH harness connector.

NEUTRAL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Sliding door lock assembly RH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 23 | D124 | 2 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK NEUTRAL SWITCH CIRCUIT 2

1. Connect sliding door control unit RH connector and sliding door lock assembly RH connector.
2. Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | | |
| B247 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

5.CHECK NEUTRAL SWITCH

Refer to [DLK-325. "SLIDING DOOR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace sliding door lock assembly RH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH : Component Inspection

INFOID:000000009649261

1.CHECK NEUTRAL SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding door lock assembly RH connector.
3. Check continuity between sliding door lock assembly RH terminals.

| Sliding door lock assembly RH | | Condition | Continuity | |
|-------------------------------|---|-------------------------------|------------------|-------------|
| Terminal | | | | |
| 6 | 2 | Sliding door closure motor RH | Neutral position | Not existed |
| | | | Other than above | Existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace sliding door lock assembly RH.

SLIDING DOOR HANDLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR HANDLE SWITCH

SLIDING DOOR LH

SLIDING DOOR LH : Component Function Check

INFOID:000000009649263

1. CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "DOR HAND SW L" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|---------------|------------------------|---------|--------|
| DOR HAND SW L | Sliding door handle LH | Pull | ON |
| | | Release | OFF |

Is the inspection result normal?

YES >> Sliding door handle switch is OK.

NO >> Refer to [DLK-326, "SLIDING DOOR LH : Diagnosis Procedure"](#).

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649263

1. CHECK SLIDING DOOR HANDLE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect remote control assembly LH connector.
3. Check voltage between remote control assembly LH harness connector and ground.

| (+) | | (-) | Voltage |
|----------------------------|----------|--------|----------|
| Remote control assembly LH | | | |
| Connector | Terminal | | |
| D118 | 2 | Ground | 8 – 16 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK SLIDING DOOR HANDLE SWITCH CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and remote control assembly LH harness connector.

| Sliding door control unit LH | | Remote control assembly LH | | Continuity |
|------------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 22 | D118 | 2 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 22 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK SLIDING DOOR HANDLE SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and remote control assembly LH harness connector.

SLIDING DOOR HANDLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit LH | | Remote control assembly LH | | Continuity |
|------------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 23 | D118 | 1 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK SLIDING DOOR HANDLE SWITCH CIRCUIT 2

- Connect sliding door control unit LH connector and remote control assembly LH connector.
- Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B45 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door control unit LH. Refer to [DLK-500. "LH : Removal and Installation"](#).

5.CHECK SLIDING DOOR HANDLE SWITCH

Refer to [DLK-327. "SLIDING DOOR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace remote control assembly LH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR LH : Component Inspection

INFOID:000000009649264

1.CHECK SLIDING DOOR HANDLE SWITCH

- Turn ignition switch OFF.
- Disconnect remote control assembly LH connector.
- Check continuity between remote control assembly LH terminals.

| Remote control assembly LH | | Condition | | Continuity |
|----------------------------|---|------------------------|---------|-------------|
| Terminal | | | | |
| 2 | 1 | Sliding door handle LH | Pull | Existed |
| | | | Release | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace remote control assembly LH.

SLIDING DOOR RH

SLIDING DOOR HANDLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR RH : Component Function Check

INFOID:000000009649265

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "DOR HAND SW R" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|---------------|------------------------|---------|--------|
| DOR HAND SW R | Sliding door handle RH | Pull | ON |
| | | Release | OFF |

Is the inspection result normal?

- YES >> Sliding door handle switch is OK.
 NO >> Refer to [DLK-328. "SLIDING DOOR RH : Diagnosis Procedure"](#).

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649266

1.CHECK SLIDING DOOR HANDLE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect remote control assembly RH connector.
3. Check voltage between remote control assembly RH harness connector and ground.

| (+) | | (-) | Voltage |
|----------------------------|----------|--------|----------|
| Remote control assembly RH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| D127 | 2 | | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK SLIDING DOOR HANDLE SWITCH CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and remote control assembly RH harness connector.

| Sliding door control unit RH | | Remote control assembly RH | | Continuity |
|------------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 22 | D127 | 2 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 22 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).
 NO >> Repair or replace harness.

3.CHECK SLIDING DOOR HANDLE SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and remote control assembly RH harness connector.

SLIDING DOOR HANDLE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Remote control assembly RH | | Continuity |
|------------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 23 | D127 | 1 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK SLIDING DOOR HANDLE SWITCH CIRCUIT 2

- Connect sliding door control unit RH connector and remote control assembly RH connector.
- Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | | |
| B247 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

5.CHECK SLIDING DOOR HANDLE SWITCH

Refer to [DLK-329. "SLIDING DOOR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace remote control assembly RH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH : Component Inspection

INFOID:000000009649267

1.CHECK SLIDING DOOR HANDLE SWITCH

- Turn ignition switch OFF.
- Disconnect remote control assembly RH connector.
- Check continuity between remote control assembly RH terminals.

| Remote control assembly RH | | Condition | | Continuity |
|----------------------------|---|------------------------|---------|-------------|
| Terminal | | | | |
| 2 | 1 | Sliding door handle RH | Pull | Existed |
| | | | Release | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace remote control assembly RH.

CHILD LOCK STATUS SWITCH

< DTC/CIRCUIT DIAGNOSIS >

CHILD LOCK STATUS SWITCH SLIDING DOOR LH

SLIDING DOOR LH : Component Function Check

INFOID:000000009649269

1. CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "CHILD LOCK SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|---------------|---------------|--------|--------|
| CHILD LOCK SW | Child lock LH | LOCK | OFF |
| | | UNLOCK | ON |

Is the inspection result normal?

YES >> Child lock status switch is OK.

NO >> Refer to [DLK-330, "SLIDING DOOR LH : Diagnosis Procedure"](#).

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649269

1. CHECK CHILD LOCK STATUS SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect remote control assembly LH connector.
3. Check voltage between remote control assembly LH harness connector and ground.

| (+) | | (-) | Voltage |
|----------------------------|----------|--------|----------|
| Remote control assembly LH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| D118 | 4 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK CHILD LOCK STATUS SWITCH CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and remote control assembly LH harness connector.

| Sliding door control unit LH | | Remote control assembly LH | | Continuity |
|------------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 20 | D118 | 4 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 20 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK CHILD LOCK STATUS SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and remote control assembly LH harness connector.

CHILD LOCK STATUS SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit LH | | Remote control assembly LH | | Continuity |
|------------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 23 | D118 | 1 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK CHILD LOCK STATUS SWITCH CIRCUIT 2

1. Connect sliding door control unit LH connector and remote control assembly LH connector.
2. Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B45 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door control unit LH. Refer to [DLK-500. "LH : Removal and Installation"](#).

5.CHECK CHILD LOCK STATUS SWITCH

Refer to [DLK-331. "SLIDING DOOR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace remote control assembly LH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR LH : Component Inspection

INFOID:000000009649270

1.CHECK CHILD LOCK STATUS SWITCH

1. Turn ignition switch OFF.
2. Disconnect remote control assembly LH connector.
3. Check continuity between remote control assembly LH terminals.

| Remote control assembly LH | | Condition | Continuity |
|----------------------------|---|---------------|---------------------|
| Terminal | | | |
| 4 | 1 | Child lock LH | LOCK Not existed |
| | | | UNLOCK Existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace remote control assembly LH.

SLIDING DOOR RH

CHILD LOCK STATUS SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR RH : Component Function Check

INFOID:000000009649271

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "CHILD LOCK SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|---------------|---------------|--------|--------|
| CHILD LOCK SW | Child lock RH | LOCK | OFF |
| | | UNLOCK | ON |

Is the inspection result normal?

- YES >> Child lock status switch is OK.
NO >> Refer to [DLK-332. "SLIDING DOOR RH : Diagnosis Procedure"](#).

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649272

1.CHECK CHILD LOCK STATUS SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect remote control assembly RH connector.
3. Check voltage between remote control assembly RH harness connector and ground.

| (+) | | (-) | Voltage |
|----------------------------|----------|--------|----------|
| Remote control assembly RH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| D127 | 4 | | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK CHILD LOCK STATUS SWITCH CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and remote control assembly RH harness connector.

| Sliding door control unit RH | | Remote control assembly RH | | Continuity |
|------------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 20 | D127 | 4 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 20 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK CHILD LOCK STATUS SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and remote control assembly RH harness connector.

CHILD LOCK STATUS SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Remote control assembly RH | | Continuity |
|------------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 23 | D127 | 1 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK CHILD LOCK STATUS SWITCH CIRCUIT 2

1. Connect sliding door control unit RH connector and remote control assembly RH connector.
2. Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | | |
| B247 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

5.CHECK CHILD LOCK STATUS SWITCH

Refer to [DLK-333. "SLIDING DOOR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace remote control assembly RH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH : Component Inspection

INFOID:000000009649273

1.CHECK CHILD LOCK STATUS SWITCH

1. Turn ignition switch OFF.
2. Disconnect remote control assembly RH connector.
3. Check continuity between remote control assembly RH terminals.

| Remote control assembly RH | | Condition | Continuity |
|----------------------------|---|---------------|---------------------|
| Terminal | | | |
| 4 | 1 | Child lock RH | LOCK Not existed |
| | | | UNLOCK Existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace remote control assembly RH.

SLIDING DOOR LOCK STATUS SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR LOCK STATUS SWITCH

SLIDING DOOR LH

SLIDING DOOR LH : Component Function Check

INFOID:000000009649274

1. CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "KNOB LCK SW L" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | Status |
|---------------|-----------------|--------|
| KNOB LCK SW L | Sliding door LH | LOCK |
| | | UNLOCK |
| | | OFF |
| | | ON |

Is the inspection result normal?

YES >> Sliding door lock status switch is OK.

NO >> Refer to [DLK-334, "SLIDING DOOR LH : Diagnosis Procedure"](#).

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649275

1. CHECK SLIDING DOOR LOCK STATUS SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door lock status switch LH connector.
3. Check voltage between sliding door lock status switch LH harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| D119 | 1 | Ground | 8 – 16 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK SLIDING DOOR LOCK STATUS SWITCH CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door lock status switch LH harness connector.

| Sliding door control unit LH | | Sliding door lock status switch LH | | Continuity |
|------------------------------|----------|------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 3 | D119 | 1 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 3 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK SLIDING DOOR LOCK STATUS SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door lock status switch LH harness connector.

SLIDING DOOR LOCK STATUS SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit LH | | Sliding door lock status switch LH | | Continuity |
|------------------------------|----------|------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 23 | D119 | 3 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK SLIDING DOOR LOCK STATUS SWITCH CIRCUIT 2

1. Connect sliding door control unit LH connector and sliding door lock status switch LH connector.
2. Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B45 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door control unit LH. Refer to [DLK-500. "LH : Removal and Installation"](#).

5.CHECK SLIDING DOOR LOCK STATUS SWITCH

Refer to [DLK-331. "SLIDING DOOR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace sliding door lock actuator LH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR LH : Component Inspection

INFOID:000000009649276

1.CHECK SLIDING DOOR LOCK STATUS SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding door lock status switch LH connector.
3. Check continuity between sliding door lock status switch LH terminals.

| Sliding door lock status switch LH | | Condition | Continuity |
|------------------------------------|---|-----------------|---------------------|
| Terminal | | | |
| 3 | 1 | Sliding door LH | LOCK Not existed |
| | | | UNLOCK Existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace sliding door lock status switch LH.

SLIDING DOOR RH

SLIDING DOOR LOCK STATUS SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR RH : Component Function Check

INFOID:000000009649277

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "KNOB LCK SW R" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|---------------|-----------------|--------|--------|
| KNOB LCK SW R | Sliding door RH | LOCK | OFF |
| | | UNLOCK | ON |

Is the inspection result normal?

- YES >> Sliding door lock status switch is OK.
NO >> Refer to [DLK-332. "SLIDING DOOR RH : Diagnosis Procedure"](#).

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649278

1.CHECK SLIDING DOOR LOCK STATUS SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door lock status switch RH connector.
3. Check voltage between sliding door lock status switch RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------------|----------|--------|----------|
| Sliding door lock status switch RH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| D120 | 3 | | |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK SLIDING DOOR LOCK STATUS SWITCH CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door lock status switch RH harness connector.

| Sliding door control unit RH | | Sliding door lock status switch RH | | Continuity |
|------------------------------|----------|------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 3 | D120 | 3 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 3 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK SLIDING DOOR LOCK STATUS SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door lock status switch RH harness connector.

SLIDING DOOR LOCK STATUS SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Sliding door lock status switch RH | | Continuity |
|------------------------------|----------|------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 23 | D120 | 1 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK SLIDING DOOR LOCK STATUS SWITCH CIRCUIT 2

- Connect sliding door control unit RH connector and sliding door lock status switch RH connector.
- Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | | |
| B247 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

5.CHECK SLIDING DOOR LOCK STATUS SWITCH

Refer to [DLK-333. "SLIDING DOOR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Replace sliding door lock actuator RH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH : Component Inspection

INFOID:000000009649279

1.CHECK SLIDING DOOR LOCK STATUS SWITCH

- Turn ignition switch OFF.
- Disconnect sliding door lock status switch RH connector.
- Check continuity between sliding door lock status switch RH terminals.

| Sliding door lock status switch RH | | Condition | Continuity |
|------------------------------------|---|-----------------|---------------------|
| Terminal | | | |
| 3 | 1 | Sliding door RH | LOCK Not existed |
| | | | UNLOCK Existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace sliding door lock actuator RH.

FUEL LID STATUS SWITCH

< DTC/CIRCUIT DIAGNOSIS >

FUEL LID STATUS SWITCH

Component Function Check

INFOID:000000009649280

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "F LID SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|-------------------------------|-----|--------|
| F LID SW | Fuel filler lid status switch | ON | ON |
| | | OFF | OFF |

Is the inspection result normal?

- YES >> Fuel filler lid status switch is OK.
 NO >> Refer to [DLK-338, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000009649281

1.CHECK FUEL FILLER LID STATUS SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect fuel filler lid status switch connector.
3. Check voltage between fuel filler lid status switch harness connector and ground.

| (+) | | (-) | Voltage |
|-------------------------------|----------|--------|----------|
| Fuel filler lid status switch | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| B24 | 2 | | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK FUEL FILLER LID STATUS SWITCH CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and fuel filler lid status switch harness connector.

| Sliding door control unit LH | | Fuel filler lid status switch | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 17 | B24 | 2 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 17 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).
 NO >> Repair or replace harness.

3.CHECK FUEL FILLER LID STATUS SWITCH GROUND CIRCUIT

Check continuity between fuel filler lid status switch LH harness connector and ground.

FUEL LID STATUS SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Fuel filler lid status switch | | Ground | Continuity |
|-------------------------------|----------|--------|------------|
| Connector | Terminal | | Existed |
| B24 | 1 | | |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK FUEL FILLER LID STATUS SWITCH

Refer to [DLK-339. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace fuel filler interlock assembly.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000009649282

1.CHECK FUEL FILLER LID STATUS SWITCH

- Turn ignition switch OFF.
- Disconnect fuel filler lid status switch connector.
- Check continuity between fuel filler lid status switch terminals.

| Fuel filler lid status switch | | Condition | Continuity |
|-------------------------------|---|----------------------------------|-------------|
| Terminal | | | Existed |
| 2 | 1 | Fuel filler lid status switch ON | Existed |
| | | OFF | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace fuel filler lid interlock assembly.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SLIDING DOOR OPEN/CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR OPEN/CLOSE SWITCH FRONT LH

FRONT LH : Component Function Check

INFOID:000000009649283

1. CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "DRIVER SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|---|----------|--------|
| DRIVER SW | Sliding door open/close switch (front LH) | Pressed | ON |
| | | Released | OFF |

Is the inspection result normal?

YES >> Sliding door open/close switch (front LH) is OK.

NO >> Refer to [DLK-340, "FRONT LH : Diagnosis Procedure"](#).

FRONT LH : Diagnosis Procedure

INFOID:000000009649284

1. CHECK SLIDING DOOR OPEN/CLOSE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door open/close switch (front side) connector.
3. Check voltage between sliding door open/close switch (front side) harness connector and ground.

| (+) | | (-) | Voltage |
|---|----------|--------|----------|
| Sliding door open/close switch (front side) | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| M90 | 2 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2. CHECK SLIDING DOOR OPEN/CLOSE SWITCH CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door open/close switch (front side) harness connector.

| Sliding door control unit LH | | Sliding door open/close switch (front side) | | Continuity |
|------------------------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 19 | M90 | 2 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 19 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

3. CHECK SLIDING DOOR OPEN/CLOSE SWITCH GROUND CIRCUIT

Check continuity between sliding door open/close switch (front side) harness connector and ground.

SLIDING DOOR OPEN/CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door open/close switch (front side) | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | Existed |
| M90 | 3 | | |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK SLIDING DOOR OPEN/CLOSE SWITCH

Refer to [DLK-341, "FRONT LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace sliding door open/close switch (front side).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

FRONT LH : Component Inspection

INFOID:000000009649285

1.CHECK SLIDING DOOR OPEN/CLOSE SWITCH

- Turn ignition switch OFF.
- Disconnect sliding door open/close switch (front side) connector.
- Check continuity between sliding door open/close switch (front side) terminals.

| Sliding door open/close switch (front side) | | Condition | | Continuity |
|---|---|---|----------|-------------|
| Terminal | | | | |
| 2 | 3 | Sliding door open/close switch (front LH) | Pressed | Existed |
| | | | Released | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace sliding door open/close switch (front side).

FRONT RH

FRONT RH : Component Function Check

INFOID:000000009649286

1.CHECK FUNCTION

- Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
- Select "DRIVER SW" in "DATA MONITOR" mode.
- Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|---|----------|--------|
| DRIVER SW | Sliding door open/close switch (front RH) | Pressed | ON |
| | | Released | OFF |

Is the inspection result normal?

- YES >> Sliding door open/close switch (front RH) is OK.
 NO >> Refer to [DLK-341, "FRONT RH : Diagnosis Procedure"](#).

FRONT RH : Diagnosis Procedure

INFOID:000000009649287

1.CHECK SLIDING DOOR OPEN/CLOSE SWITCH INPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect sliding door open/close switch (front side) connector.

SLIDING DOOR OPEN/CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

3. Check voltage between sliding door open/close switch (front side) harness connector and ground.

| (+) | | (-) | Voltage |
|---|----------|--------|----------|
| Sliding door open/close switch (front side) | | | |
| Connector | Terminal | | |
| M90 | 1 | Ground | 8 – 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2.CHECK SLIDING DOOR OPEN/CLOSE SWITCH CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door open/close switch (front side) harness connector.

| Sliding door control unit RH | | Sliding door open/close switch (front side) | | Continuity |
|------------------------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 19 | M90 | 1 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 19 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit RH. Refer to [DLK-500, "RH : Removal and Installation"](#).
NO >> Repair or replace harness.

3.CHECK SLIDING DOOR OPEN/CLOSE SWITCH GROUND CIRCUIT

Check continuity between sliding door open/close switch (front side) harness connector and ground.

| Sliding door open/close switch (front side) | | Ground | Continuity |
|---|----------|--------|------------|
| Connector | Terminal | | |
| M90 | 3 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4.CHECK SLIDING DOOR OPEN/CLOSE SWITCH

Refer to [DLK-342, "FRONT RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door open/close switch (front side).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

FRONT RH : Component Inspection

INFOID:000000009649288

1.CHECK SLIDING DOOR OPEN/CLOSE SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding door open/close switch (front side) connector.
3. Check continuity between sliding door open/close switch (front side) terminals.

SLIDING DOOR OPEN/CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door open/close switch (front side) | | Condition | | Continuity |
|---|---|---|----------|-------------|
| Terminal | | | | |
| 1 | 3 | Sliding door open/close switch (front RH) | Pressed | Existed |
| | | | Released | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sliding door open/close switch (front side).

REAR LH

REAR LH : Component Function Check

INFOID:000000009649289

1.CHECK FUNCTION

1. Select "AUTO SLDE DOOR" using CONSULT.
2. Select "B PILLER SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|--|----------|--------|
| B PILLER SW | Sliding door open/close switch (rear LH) | Pressed | ON |
| | | Released | OFF |

Is the inspection result normal?

YES >> Sliding door open/close switch (rear LH) is OK.

NO >> Refer to [DLK-343. "REAR LH : Diagnosis Procedure"](#).

REAR LH : Diagnosis Procedure

INFOID:000000009649290

1.CHECK SLIDING DOOR OPEN/CLOSE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door open/close switch (rear LH) connector.
3. Check voltage between sliding door open/close switch (rear LH) harness connector and ground.

| (+) | | (-) | Voltage |
|--|----------|--------|----------|
| Sliding door open/close switch (rear LH) | | | |
| Connector | Terminal | | |
| B25 | 1 | Ground | 8 – 16 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK SLIDING DOOR OPEN/CLOSE SWITCH CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door open/close switch (rear LH) harness connector.

| Sliding door control unit LH | | Sliding door open/close switch (rear LH) | | Continuity |
|------------------------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 2 | B25 | 1 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 2 | | Not existed |

SLIDING DOOR OPEN/CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK SLIDING DOOR OPEN/CLOSE SWITCH GROUND CIRCUIT

Check continuity between sliding door open/close switch (rear LH) harness connector and ground.

| Sliding door open/close switch (rear LH) | | Ground | Continuity |
|--|----------|--------|------------|
| Connector | Terminal | | |
| B25 | 2 | | Existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK SLIDING DOOR OPEN/CLOSE SWITCH

Refer to [DLK-344, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace sliding door open/close switch (rear LH).

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

REAR LH : Component Inspection

INFOID:000000009649291

1.CHECK SLIDING DOOR OPEN/CLOSE SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding door open/close switch (rear LH) connector.
3. Check continuity between sliding door open/close switch (rear LH) terminals.

| Sliding door open/close switch (rear LH) | | Condition | | Continuity |
|--|---|--|----------|-------------|
| Terminal | | | | |
| 1 | 2 | Sliding door open/close switch (rear LH) | Pressed | Existed |
| | | | Released | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sliding door open/close switch (rear LH).

REAR RH

REAR RH : Component Function Check

INFOID:000000009649292

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "B PILLER SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|--|----------|--------|
| B PILLER SW | Sliding door open/close switch (rear RH) | Pressed | ON |
| | | Released | OFF |

Is the inspection result normal?

YES >> Sliding door open/close switch (rear RH) is OK.

NO >> Refer to [DLK-343, "REAR LH : Diagnosis Procedure"](#).

SLIDING DOOR OPEN/CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

REAR RH : Diagnosis Procedure

INFOID:000000009649293

1. CHECK SLIDING DOOR OPEN/CLOSE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door open/close switch (rear RH) connector.
3. Check voltage between sliding door open/close switch (rear RH) harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| B206 | 1 | Ground | 8 – 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK SLIDING DOOR OPEN/CLOSE SWITCH CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door open/close switch (rear RH) harness connector.

| Sliding door control unit RH | | Sliding door open/close switch (rear RH) | | Continuity |
|------------------------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 2 | B206 | 1 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 2 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit RH. Refer to [DLK-500, "RH : Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK SLIDING DOOR OPEN/CLOSE SWITCH GROUND CIRCUIT

Check continuity between sliding door open/close switch (rear RH) harness connector and ground.

| Sliding door open/close switch (rear RH) | | Ground | Continuity |
|--|----------|--------|------------|
| Connector | Terminal | | |
| B206 | 2 | | Existed |

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace harness.

4. CHECK SLIDING DOOR OPEN/CLOSE SWITCH

Refer to [DLK-346, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door open/close switch (rear RH).

5. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR OPEN/CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

REAR RH : Component Inspection

INFOID:000000009649294

1. CHECK SLIDING DOOR OPEN/CLOSE SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding door open/close switch (rear RH) connector.
3. Check continuity between sliding door open/close switch (rear RH) terminals.

| Sliding door open/close switch (rear RH) | | Condition | Continuity | |
|--|---|--|------------|-------------|
| Terminal | | | | |
| 1 | 2 | Sliding door open/close switch (rear RH) | Pressed | Existed |
| | | | Released | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace sliding door open/close switch (rear RH).

SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

SLIDING DOOR LH

SLIDING DOOR LH : Component Function Check

INFOID:000000009649295

1. CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "ONE-TOUCH SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | Status |
|--------------|---|----------|
| ONE-TOUCH SW | Sliding door one-touch open/ close switch LH | Pressed |
| | | Released |
| | | ON |
| | | OFF |

Is the inspection result normal?

- YES >> Sliding door one-touch open/close switch is OK.
NO >> Refer to [DLK-347, "SLIDING DOOR LH : Diagnosis Procedure"](#).

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649295

1. CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door one-touch open/close switch LH connector.
3. Check voltage between sliding door one-touch open/close switch LH harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| D125 | 1 | Ground | 8 – 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door one-touch open/close switch LH harness connector.

| Sliding door control unit LH | | Sliding door one-touch open/close switch LH | | Continuity |
|------------------------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 14 | D125 | 1 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 14 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door one-touch open/close switch LH harness connector.

SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit LH | | Sliding door one-touch open/close switch LH | | Continuity |
|------------------------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 23 | D125 | 2 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH CIRCUIT 2

1. Connect sliding door control unit LH connector and sliding door one-touch open/close switch LH connector.
 2. Check voltage between sliding door one-touch open/close switch LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B45 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

5.CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

Refer to [DLK-348, "SLIDING DOOR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Replace sliding door one-touch open/close switch LH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR LH : Component Inspection

INFOID:000000009649297

1.CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

1. Turn ignition switch OFF.
 2. Disconnect sliding door one-touch open/close switch LH connector.
 3. Check continuity between sliding door one-touch open/close switch LH terminals.

| Sliding door one-touch open/close switch LH | | Condition | Continuity |
|---|---|--|-------------|
| Terminal | | | |
| 1 | 2 | Sliding door one-touch open/close switch LH Pressed | Existed |
| | | Released | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace sliding door one-touch open/close switch LH.

SLIDING DOOR RH

SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR RH : Component Function Check

INFOID:000000009649298

1. CHECK FUNCTION

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "ONE-TOUCH SW" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | Status |
|--------------|---|-----------------|
| ONE-TOUCH SW | Sliding door one-touch open/ close switch RH | Pressed ON |
| | | Released OFF |

Is the inspection result normal?

- YES >> Sliding door one-touch open/close switch is OK.
NO >> Refer to [DLK-347, "SLIDING DOOR LH : Diagnosis Procedure"](#).

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649299

1. CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door one-touch open/close switch RH connector.
3. Check voltage between sliding door one-touch open/close switch RH harness connector and ground.

| (+) | | (-) | Voltage |
|--|----------|--------|----------|
| Sliding door one-touch open/close switch RH Connector | Terminal | | |
| D126 | 1 | Ground | 8 – 16 V |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door one-touch open/close switch RH harness connector.

| Sliding door control unit RH | | Sliding door one-touch open/close switch RH | | Continuity |
|------------------------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 14 | D126 | 1 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 14 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit RH. Refer to [DLK-500, "RH : Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH GROUND CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door one-touch open/close switch RH harness connector.

SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Sliding door one-touch open/close switch RH | | Continuity |
|------------------------------|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 23 | D126 | 2 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 23 | | Not existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH CIRCUIT 2

1. Connect sliding door control unit RH connector and sliding door one-touch open/close switch RH connector.
2. Check voltage between sliding door one-touch open/close switch RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | | |
| B247 | 23 | Ground | 0 V |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace sliding door control unit RH. Refer to [DLK-500, "RH : Removal and Installation"](#).

5. CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

Refer to [DLK-350, "SLIDING DOOR RH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace sliding door one-touch open/close switch RH.

6. CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH : Component Inspection

INFOID:000000009649300

1. CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

1. Turn ignition switch OFF.
2. Disconnect sliding door one-touch open/close switch RH connector.
3. Check continuity between sliding door one-touch open/close switch RH terminals.

| Sliding door one-touch open/close switch RH | | Condition | Continuity |
|---|---|--|-------------|
| Terminal | | | |
| 1 | 2 | Sliding door one-touch open/close switch RH Pressed | Existed |
| | | Released | Not existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sliding door one-touch open/close switch RH.

SLIDING DOOR TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR TOUCH SENSOR

SLIDING DOOR LH

SLIDING DOOR LH : Component Function Check

INFOID:000000009649301

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "TOUCH SEN LH" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | Status |
|--------------|------------------------------|--------------------|
| TOUCH SEN LH | Sliding door touch sensor LH | Other than below |
| | | Detect obstruction |
| | | OFF |
| | | ON |

Is the inspection result normal?

YES >> Sliding door touch sensor is OK.

NO >> Refer to [DLK-351, "SLIDING DOOR LH : Diagnosis Procedure"](#).

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649302

1.CHECK SLIDING DOOR TOUCH SENSOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between sliding door touch sensor LH harness connector and sliding door control unit LH harness connector.

| (+) | | (-) | | Condition | Voltage | |
|------------------------------|----------|------------------------------|----------|------------------------------|--------------------|-----------|
| Sliding door touch sensor LH | | Sliding door control unit LH | | | | |
| Connector | Terminal | Connector | Terminal | | | |
| D172 | 1 | B45 | 23 | Sliding door touch sensor LH | Detect obstruction | 0 – 1.5 V |
| | | | | | Other than above | 4 – 8 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK SLIDING DOOR TOUCH SENSOR CIRCUIT

1. Disconnect sliding door control unit LH and sliding door touch sensor LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door touch sensor LH harness connector.

| Sliding door control unit LH | | Sliding door touch sensor LH | | Continuity |
|------------------------------|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 24 | D172 | 1 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 24 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK SLIDING DOOR TOUCH SENSOR GROUND CIRCUIT

1. Disconnect sliding door control unit LH and sliding door touch sensor LH connectors.

SLIDING DOOR TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

- Check continuity between sliding door control unit LH harness connector and sliding door touch sensor LH harness connector.

| Sliding door control unit LH | | Sliding door touch sensor LH | | Continuity |
|------------------------------|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 23 | D172 | 2 | Existed |

- Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 23 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK SLIDING DOOR TOUCH SENSOR GROUND CIRCUIT 2

- Connect sliding door control unit LH connector and sliding door touch sensor LH connector.
- Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B45 | 23 | Ground | 0 V |

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

5.CHECK SLIDING DOOR TOUCH SENSOR

Refer to [DLK-352, "SLIDING DOOR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.
 NO >> Replace sliding door touch sensor LH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR LH : Component Inspection

INFOID:000000009649303

1.CHECK SLIDING DOOR TOUCH SENSOR LH

- Turn ignition switch OFF.
- Disconnect sliding door touch sensor LH connector.
- Check resistance between sliding door touch sensor LH terminals.

| Sliding door touch sensor LH | | Condition | | Resistance |
|------------------------------|---|------------------------------|--------------------|---------------|
| Terminal | | | | |
| 1 | 2 | Sliding door touch sensor RH | Detect obstruction | 120 Ω or less |
| | | | Other than above | 1 kΩ ± 10% |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace sliding door touch sensor LH.

SLIDING DOOR RH

SLIDING DOOR TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR RH : Component Function Check

INFOID:000000009649304

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "TOUCH SEN RH" in "DATA MONITOR" mode.
3. Check that the function operates normally according to the following conditions.

| Monitor item | Condition | | Status |
|--------------|------------------------------|--------------------|--------|
| TOUCH SEN RH | Sliding door touch sensor RH | Other than below | OFF |
| | | Detect obstruction | ON |

Is the inspection result normal?

- YES >> Sliding door touch sensor is OK.
 NO >> Refer to [DLK-353, "SLIDING DOOR RH : Diagnosis Procedure"](#).

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649305

1.CHECK SLIDING DOOR TOUCH SENSOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Check voltage between sliding door touch sensor RH harness connector and sliding door control unit RH harness connector.

| (+) | | (-) | | Condition | Voltage | |
|------------------------------|----------|------------------------------|----------|------------------------------|--------------------|-----------|
| Sliding door touch sensor RH | | Sliding door control unit RH | | | | |
| Connector | Terminal | Connector | Terminal | | | |
| D173 | 1 | B247 | 23 | Sliding door touch sensor RH | Detect obstruction | 0 – 1.5 V |
| | | | | Other than above | 4 – 8 V | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK SLIDING DOOR TOUCH SENSOR CIRCUIT

1. Disconnect sliding door control unit RH connector and sliding door touch sensor RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door touch sensor RH harness connector.

| Sliding door control unit RH | | Sliding door touch sensor RH | | Continuity |
|------------------------------|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 24 | D173 | 1 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 24 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit RH. Refer to [DLK-500, "LH : Removal and Installation"](#).
 NO >> Repair or replace harness.

3.CHECK SLIDING DOOR TOUCH SENSOR GROUND CIRCUIT

1. Disconnect sliding door control unit RH connector and sliding door touch sensor RH connectors.
2. Check continuity between sliding door control unit RH harness connector and sliding door touch sensor RH harness connector.

SLIDING DOOR TOUCH SENSOR

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit RH | | Sliding door touch sensor RH | | Continuity |
|------------------------------|----------|------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 23 | D173 | 2 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B247 | 23 | | Not existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK SLIDING DOOR TOUCH SENSOR GROUND CIRCUIT 2

1. Connect sliding door control unit RH connector and sliding door touch sensor RH connector.
2. Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | | |
| B247 | 23 | Ground | 0 V |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace sliding door control unit RH. Refer to [DLK-500. "LH : Removal and Installation"](#).

5.CHECK SLIDING DOOR TOUCH SENSOR

Refer to [DLK-354. "SLIDING DOOR RH : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace sliding door touch sensor RH.

6.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH : Component Inspection

INFOID:000000009649306

1.CHECK SLIDING DOOR TOUCH SENSOR RH

1. Turn ignition switch OFF.
2. Disconnect sliding door touch sensor RH connector.
3. Check resistance between sliding door touch sensor RH terminals.

| Sliding door touch sensor RH | | Condition | | Resistance |
|------------------------------|---|------------------------------|--------------------|---------------|
| Terminal | | | | |
| 1 | 2 | Sliding door touch sensor RH | Detect obstruction | 120 Ω or less |
| | | | Other than above | 1 kΩ ± 10% |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace sliding door touch sensor RH.

CLUTCH

< DTC/CIRCUIT DIAGNOSIS >

CLUTCH

SLIDING DOOR LH

SLIDING DOOR LH : Component Function Check

INFOID:000000009649307

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR" using CONSULT.
2. Select "CLUTCH" in "ACTIVE TEST" mode.
3. Touch "HOLD" and "RELEASE" to check that it works normally.

Is the inspection result normal?

YES >> Clutch is OK.

NO >> Refer to [DLK-355. "SLIDING DOOR LH : Diagnosis Procedure"](#).

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649308

1.CHECK CLUTCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect automatic sliding door unit LH connector.
3. Check voltage between automatic sliding door unit LH harness connector and ground.

| (+) | | (-) | Condition | Voltage |
|--|----------|--------|-----------|----------|
| Automatic sliding door unit LH Connector | Terminal | | | |
| B33 | 2 | Ground | Clutch ON | 9 – 16 V |
| | | | OFF | 0 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK CLUTCH CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B47 | 47 | B33 | 2 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B47 | 47 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500. "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK CLUTCH GROUND CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

CLUTCH

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B47 | 44 | B33 | 1 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B47 | 44 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK CLUTCH CIRCUIT 2

1. Connect sliding door control unit LH connector and automatic sliding door unit LH connector.
2. Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | | |
| B47 | 44 | Ground | 0 V |

Is the inspection result normal?

- YES >> Replace automatic sliding door unit LH.
 NO >> Replace sliding door control unit LH. Refer to [DLK-500. "LH : Removal and Installation"](#).

SLIDING DOOR RH

SLIDING DOOR RH : Component Function Check

INFOID:000000009649309

1.CHECK FUNCTION

1. Select "AUTO SLIDE DOOR RIGHT" using CONSULT.
2. Select "CLUTCH" in "ACTIVE TEST" mode.
3. Touch "HOLD" and "RELEASE" to check that it works normally.

Is the inspection result normal?

- YES >> Clutch is OK.
 NO >> Refer to [DLK-355. "SLIDING DOOR LH : Diagnosis Procedure"](#).

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649310

1.CHECK CLUTCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect automatic sliding door unit RH connector.
3. Check voltage between automatic sliding door unit RH harness connector and ground.

| (+) | | (-) | Condition | Voltage | |
|--------------------------------|----------|--------|-----------|---------|----------|
| Automatic sliding door unit RH | | | | | |
| Connector | Terminal | | | | |
| B245 | 2 | Ground | Clutch | ON | 9 – 16 V |
| | | | | OFF | 0 V |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2.CHECK CLUTCH CIRCUIT

CLUTCH

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B249 | 47 | B245 | 2 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B249 | 47 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK CLUTCH GROUND CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B249 | 44 | B245 | 1 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B249 | 44 | | Not existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4.CHECK CLUTCH CIRCUIT 2

1. Connect sliding door control unit RH connector and automatic sliding door unit RH connector.
2. Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | | |
| B249 | 44 | Ground | 0 V |

Is the inspection result normal?

YES >> Replace automatic sliding door unit RH.

NO >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

AUTOMATIC SLIDING DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

AUTOMATIC SLIDING DOOR MOTOR SLIDING DOOR LH

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649311

1. CHECK AUTOMATIC SLIDING DOOR MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door control unit LH connector.
3. Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Condition | | Voltage |
|------------------------------|----------|--------|-----------------|---------------|----------|
| Sliding door control unit LH | | | | | |
| Connector | Terminal | Ground | Sliding door LH | Open operate | 9 – 16 V |
| B47 | 43 | | | Close operate | |
| | 46 | | | | |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

2. CHECK AUTOMATIC SLIDING DOOR MOTOR CIRCUIT

1. Disconnect automatic sliding door unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and automatic sliding door unit LH harness connector.

| Sliding door control unit LH | | Automatic sliding door unit LH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B47 | 43 | B33 | 3 | Existed |
| | 46 | | 4 | |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B47 | 43 | | Not existed |
| | 46 | | |

Is the inspection result normal?

YES >> Replace automatic sliding door unit LH.

NO >> Repair or replace harness.

SLIDING DOOR RH

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649312

1. CHECK AUTOMATIC SLIDING DOOR MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door control unit RH connector.
3. Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Condition | | Voltage |
|------------------------------|----------|--------|-----------------|---------------|----------|
| Sliding door control unit RH | | | | | |
| Connector | Terminal | Ground | Sliding door RH | Open operate | 9 – 16 V |
| B249 | 43 | | | Close operate | |
| | 46 | | | | |

AUTOMATIC SLIDING DOOR MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace sliding door control unit RH. Refer to [DLK-500. "LH : Removal and Installation"](#).

2. CHECK AUTOMATIC SLIDING DOOR MOTOR CIRCUIT

1. Disconnect automatic sliding door unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door unit RH harness connector.

| Sliding door control unit RH | | Automatic sliding door unit RH | | Continuity |
|------------------------------|----------|--------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B249 | 43 | B245 | 4 | Existed |
| | 46 | | 3 | |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B249 | 43 | | Not existed |
| | 46 | | |

Is the inspection result normal?

YES >> Replace automatic sliding door unit RH.

NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



SLIDING DOOR LOCK RELEASE ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR LOCK RELEASE ACTUATOR

SLIDING DOOR LH

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649313

1. CHECK SLIDING DOOR LOCK RELEASE ACTUATOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door lock release actuator LH connector.
3. Check voltage between sliding door lock release actuator LH harness connector and ground.

| (+) | | (-) | Voltage |
|---------------------------------------|----------|--------|----------|
| Sliding door lock release actuator LH | | | |
| Connector | Terminal | Ground | 9 – 16 V |
| D121 | 1 | | |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> GO TO 4.

2. CHECK SLIDING DOOR LOCK RELEASE ACTUATOR CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door lock release actuator LH harness connector.

| Sliding door control unit LH | | Sliding door lock release actuator LH | | Continuity |
|------------------------------|----------|---------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B46 | 39 | D121 | 2 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B46 | 39 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness.

3. CHECK SLIDING DOOR LOCK RELEASE ACTUATOR CIRCUIT 2

1. Connect sliding door control unit LH connector and sliding door lock release actuator LH connector.
2. Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit LH | | | |
| Connector | Terminal | Ground | 0 V |
| B46 | 39 | | |

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

4. CHECK SLIDING DOOR LOCK RELEASE ACTUATOR GROUND CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door lock release actuator LH harness connector.

SLIDING DOOR LOCK RELEASE ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

| Sliding door control unit LH | | Sliding door lock release actuator LH | | Continuity |
|------------------------------|----------|---------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B46 | 40 | D121 | 1 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B46 | 40 | | Not existed |

Is the inspection result normal?

- YES >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).
 NO >> Repair or replace harness.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42, "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR RH

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649314

1.CHECK SLIDING DOOR LOCK RELEASE ACTUATOR INPUT SIGNAL

- Turn ignition switch OFF.
- Disconnect sliding door lock release actuator RH connector.
- Check voltage between sliding door lock release actuator RH harness connector and ground.

| (+) | | (-) | Voltage |
|---------------------------------------|----------|--------|----------|
| Sliding door lock release actuator RH | | | |
| Connector | Terminal | | |
| D122 | 1 | Ground | 9 – 16 V |

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> GO TO 4.

2.CHECK SLIDING DOOR LOCK RELEASE ACTUATOR CIRCUIT

- Disconnect sliding door control unit RH connector.
- Check continuity between sliding door control unit RH harness connector and sliding door lock release actuator RH harness connector.

| Sliding door control unit RH | | Sliding door lock release actuator RH | | Continuity |
|------------------------------|----------|---------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B248 | 39 | D122 | 2 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B248 | 39 | | Not existed |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK SLIDING DOOR LOCK RELEASE ACTUATOR CIRCUIT 2

- Connect sliding door control unit RH connector and sliding door lock release actuator RH connector.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SLIDING DOOR LOCK RELEASE ACTUATOR

< DTC/CIRCUIT DIAGNOSIS >

2. Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Voltage |
|------------------------------|----------|--------|---------|
| Sliding door control unit RH | | | |
| Connector | Terminal | Ground | 0 V |
| B248 | 39 | | |

Is the inspection result normal?

YES >> GO TO 5.

NO >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

4.CHECK SLIDING DOOR LOCK RELEASE ACTUATOR GROUND CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door lock release actuator RH harness connector.

| Sliding door control unit RH | | Sliding door lock release actuator RH | | Continuity |
|------------------------------|----------|---------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B248 | 40 | D122 | 1 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B248 | 40 | | Not existed |

Is the inspection result normal?

YES >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

NO >> Repair or replace harness.

5.CHECK INTERMITTENT INCIDENT

Refer to [GI-42. "Intermittent Incident"](#).

>> INSPECTION END

SLIDING DOOR CLOSURE MOTOR

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR CLOSURE MOTOR SLIDING DOOR LH

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649315

1. CHECK SLIDING DOOR CLOSURE MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door control unit LH connector.
3. Check voltage between sliding door control unit LH harness connector and ground.

| (+) | | (-) | Condition | | Voltage |
|------------------------------|----------|--------|-------------------------------|-------------------|----------|
| Sliding door control unit LH | | | | | |
| Connector | Terminal | Ground | Sliding door closure motor LH | Closure operation | 9 – 16 V |
| B46 | 34 | | | Return operation | |
| | 35 | | | | |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace sliding door control unit LH. Refer to [DLK-500, "LH : Removal and Installation"](#).

2. CHECK SLIDING DOOR CLOSURE MOTOR CIRCUIT

1. Disconnect sliding door lock assembly LH connector.
2. Check continuity between sliding door control unit LH harness connector and sliding door lock assembly LH harness connector.

| Sliding door control unit LH | | Sliding door lock assembly LH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B46 | 34 | D123 | 4 | Existed |
| | 35 | | 1 | |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B46 | 34 | | Not existed |
| | 35 | | |

Is the inspection result normal?

YES >> Replace sliding door lock assembly LH.

NO >> Repair or replace harness.

SLIDING DOOR RH

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649316

1. CHECK SLIDING DOOR CLOSURE MOTOR INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect sliding door control unit RH connector.
3. Check voltage between sliding door control unit RH harness connector and ground.

| (+) | | (-) | Condition | | Voltage |
|------------------------------|----------|--------|-------------------------------|-------------------|----------|
| Sliding door control unit RH | | | | | |
| Connector | Terminal | Ground | Sliding door closure motor RH | Closure operation | 9 – 16 V |
| B248 | 34 | | | Return operation | |
| | 35 | | | | |

SLIDING DOOR CLOSURE MOTOR

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).

2. CHECK SLIDING DOOR CLOSURE MOTOR CIRCUIT

1. Disconnect sliding door lock assembly RH connector.
2. Check continuity between sliding door control unit RH harness connector and sliding door lock assembly RH harness connector.

| Sliding door control unit RH | | Sliding door lock assembly RH | | Continuity |
|------------------------------|----------|-------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B248 | 34 | D124 | 4 | Existed |
| | 35 | | 1 | |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B248 | 34 | | Not existed |
| | 35 | | |

Is the inspection result normal?

YES >> Replace sliding door lock assembly RH.

NO >> Repair or replace harness.

AUTOMATIC SLIDING DOOR WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

AUTOMATIC SLIDING DOOR WARNING BUZZER SLIDING DOOR LH

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649317

1. CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10 A fuse, [No.9, located in fuse block (J/B)]

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2. CHECK AUTOMATIC SLIDING DOOR WARNING BUZZER INPUT SIGNAL

1. Disconnect automatic sliding door warning buzzer LH connector.
2. Check voltage between automatic sliding door warning buzzer LH harness connector and ground.

| (+) | | (-) | Voltage |
|-----------|----------|--------|----------|
| Connector | Terminal | | |
| B27 | 1 | Ground | 8 – 16 V |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3. CHECK AUTOMATIC SLIDING DOOR WARNING BUZZER CIRCUIT

1. Disconnect sliding door control unit LH connector.
2. Check continuity between sliding door control unit LH harness connector and automatic sliding door warning buzzer LH harness connector.

| Sliding door control unit LH | | Automatic sliding door warning buzzer LH | | Continuity |
|------------------------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B45 | 8 | B27 | 2 | Existed |

3. Check continuity between sliding door control unit LH harness connector and ground.

| Sliding door control unit LH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| B45 | 8 | | Not existed |

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

4. CHECK AUTOMATIC SLIDING DOOR WARNING BUZZER

Refer to [DLK-365. "SLIDING DOOR LH : Component Inspection"](#)

Is the inspection result normal?

YES >> Replace sliding door control unit LH. Refer to [DLK-500. "LH : Removal and Installation"](#).

NO >> Repair or replace harness.

SLIDING DOOR LH : Component Inspection

INFOID:000000009649318

1. CHECK AUTOMATIC SLIDING DOOR WARNING BUZZER

1. Turn ignition switch OFF.
2. Disconnect automatic sliding door warning buzzer LH connector.
3. Check battery power supply directly to automatic sliding door warning buzzer LH terminals and check the operation.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

AUTOMATIC SLIDING DOOR WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

| Automatic sliding door warning buzzer LH | | Operation |
|--|-----|---------------|
| Terminal | | |
| (+) | (-) | Buzzer sounds |
| 1 | 2 | |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace automatic sliding door warning buzzer LH.

SLIDING DOOR RH

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649319

1.CHECK FUSE

1. Turn ignition switch OFF.
2. Check 10 A fuse, [No.9, located in fuse block (J/B)]

Is the inspection result normal?

- YES >> GO TO 2.
 NO >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.

2.CHECK AUTOMATIC SLIDING DOOR WARNING BUZZER INPUT SIGNAL

1. Disconnect automatic sliding door warning buzzer RH connector.
2. Check voltage between automatic sliding door warning buzzer RH harness connector and ground.

| (+) | | (-) | Voltage |
|--|----------|--------|----------|
| Automatic sliding door warning buzzer RH | | | |
| Connector | Terminal | Ground | 8 – 16 V |
| B203 | 1 | | |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace harness.

3.CHECK AUTOMATIC SLIDING DOOR WARNING BUZZER CIRCUIT

1. Disconnect sliding door control unit RH connector.
2. Check continuity between sliding door control unit RH harness connector and automatic sliding door warning buzzer RH harness connector.

| Sliding door control unit RH | | Automatic sliding door warning buzzer RH | | Continuity |
|------------------------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| B247 | 8 | B203 | 2 | Existed |

3. Check continuity between sliding door control unit RH harness connector and ground.

| Sliding door control unit RH | | Ground | Continuity |
|------------------------------|----------|--------|-------------|
| Connector | Terminal | | Not existed |
| B247 | 8 | | |

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace harness.

4.CHECK AUTOMATIC SLIDING DOOR WARNING BUZZER

Refer to [DLK-367. "SLIDING DOOR RH : Component Inspection"](#)

Is the inspection result normal?

- YES >> Replace sliding door control unit RH. Refer to [DLK-500. "RH : Removal and Installation"](#).
 NO >> Repair or replace harness.

AUTOMATIC SLIDING DOOR WARNING BUZZER

< DTC/CIRCUIT DIAGNOSIS >

SLIDING DOOR RH : Component Inspection

INFOID:000000009649320

1. CHECK AUTOMATIC SLIDING DOOR WARNING BUZZER

1. Turn ignition switch OFF.
2. Disconnect automatic sliding door warning buzzer RH connector.
3. Check battery power supply directly to automatic sliding door warning buzzer RH terminals and check the operation.

| Automatic sliding door warning buzzer RH | | Operation |
|--|-----|---------------|
| Terminal | | |
| (+) | (-) | |
| 1 | 2 | Buzzer sounds |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace automatic sliding door warning buzzer RH.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

ALL DOOR

ALL DOOR : Description

INFOID:000000009649321

All doors do not lock/unlock using door lock and unlock switch.

ALL DOOR : Diagnosis Procedure

INFOID:000000009649322

1.CHECK DOOR LOCK AND UNLOCK SWITCH

Check door lock and unlock switch.

- With automatic sliding door system: Refer to [DLK-245, "WITH AUTOMATIC SLIDING DOOR : Component Function Check"](#).
- Without automatic sliding door system: Refer to [DLK-245, "WITHOUT AUTOMATIC SLIDING DOOR : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK DOOR LOCK ACTUATOR

Check front door lock assembly (driver side).

Refer to [DLK-249, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000009649323

Driver side door does not lock/unlock using door lock and unlock switch.

DRIVER SIDE : Diagnosis Procedure

INFOID:000000009649324

1.CHECK DOOR LOCK ACTUATOR

Check front door lock assembly (driver side).

Refer to [DLK-249, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000009649325

Passenger side door does not lock/unlock using door lock and unlock switch.

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000009649326

1.CHECK DOOR LOCK ACTUATOR

Check front door lock assembly (passenger side).

Refer to [DLK-250, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

SLIDING DOOR LH

SLIDING DOOR LH : Description

INFOID:000000009649327

Rear LH side door does not lock/unlock using door lock and unlock switch.

SLIDING DOOR LH : Diagnosis Procedure

INFOID:000000009649328

1.CHECK DOOR LOCK ACTUATOR

Check sliding door lock assembly LH.

Refer to [DLK-252, "WITH AUTOMATIC SLIDING DOOR : Component Function Check"](#) (with automatic sliding door system), [DLK-255, "WITHOUT AUTOMATIC SLIDING DOOR : Component Function Check"](#) (without automatic sliding door system).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK SELECTIVE UNLOCK RELAY

Check selective unlock relay.

Refer to [DLK-257, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

SLIDING DOOR RH

SLIDING DOOR RH : Description

INFOID:000000009649329

Rear RH side door does not lock/unlock using door lock and unlock switch.

DOOR DOES NOT LOCK/UNLOCK WITH DOOR LOCK AND UNLOCK SWITCH

< SYMPTOM DIAGNOSIS >

SLIDING DOOR RH : Diagnosis Procedure

INFOID:000000009649330

1. CHECK DOOR LOCK ACTUATOR

Check sliding door lock assembly RH.

Refer to [DLK-252. "WITH AUTOMATIC SLIDING DOOR : Component Function Check"](#) (with automatic sliding door system), [DLK-255. "WITHOUT AUTOMATIC SLIDING DOOR : Component Function Check"](#) (without automatic sliding door system).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. REPLACE BCM

1. Replace BCM. Refer to [BCS-98. "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).

DOOR DOES NOT LOCK/UNLOCK WITH DOOR KEY CYLINDER OPERATION

< SYMPTOM DIAGNOSIS >

DOOR DOES NOT LOCK/UNLOCK WITH DOOR KEY CYLINDER OPERATION

Diagnosis Procedure

INFOID:000000009649331

1. CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 2.

NO >> Refer to [DLK-368, "ALL DOOR : Diagnosis Procedure"](#).

2. CHECK DOOR KEY CYLINDER SWITCH

Check door key cylinder switch.

Refer to [DLK-261, "WITH AUTOMATIC SLIDING DOOR : Component Function Check"](#) (with automatic sliding door), [DLK-262, "WITHOUT AUTOMATIC SLIDING DOOR : Component Function Check"](#) (without automatic sliding door).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH ALL DOOR REQUEST SWITCHES

ALL DOOR REQUEST SWITCHES : Description

INFOID:000000009649332

All doors do not lock/unlock using all door request switches.

ALL DOOR REQUEST SWITCHES : Diagnosis Procedure

INFOID:000000009649333

1. CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent Key button?

YES >> GO TO 2.

NO >> Refer to [DLK-265, "Component Function Check"](#).

2. CHECK "LOCK/UNLOCK BY I-KEY" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.

2. Select "LOCK/UNLOCK BY I-KEY" in "WORK SUPPORT" mode.

3. Check "LOCK/UNLOCK BY I-KEY" setting in "WORK SUPPORT".

Refer to [DLK-95, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "ON" in "LOCK/UNLOCK BY I-KEY".

3. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

• Instrument center: Refer to [DLK-226, "DTC Logic"](#).

• Console: Refer to [DLK-228, "DTC Logic"](#).

• Luggage room: Refer to [DLK-230, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK OUTSIDE KEY ANTENNA

Check outside key antenna.

• Driver side: Refer to [DLK-234, "DTC Logic"](#).

• Passenger side: Refer to [DLK-232, "DTC Logic"](#).

• Rear bumper: Refer to [DLK-236, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

DRIVER SIDE DOOR REQUEST SWITCH

DRIVER SIDE DOOR REQUEST SWITCH : Description

INFOID:000000009649334

All doors do not lock/unlock using driver side door request switch.

DRIVER SIDE DOOR REQUEST SWITCH : Diagnosis Procedure

INFOID:000000009649335

1. CHECK DOOR REQUEST SWITCH

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

Check front door request switch (driver side).
Refer to [DLK-267, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning parts.

2.CHECK OUTSIDE KEY ANTENNA

Check outside key antenna (driver side).
Refer to [DLK-234, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3.REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
- NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

PASSENGER SIDE DOOR REQUEST SWITCH

PASSENGER SIDE DOOR REQUEST SWITCH : Description

INFOID:000000009649336

All doors do not lock/unlock using passenger side door request switch.

PASSENGER SIDE DOOR REQUEST SWITCH : Diagnosis Procedure

INFOID:000000009649337

1.CHECK DOOR REQUEST SWITCH

Check front door request switch (passenger side).
Refer to [DLK-267, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning parts.

2.CHECK OUTSIDE KEY ANTENNA

Check outside key antenna (passenger side).
Refer to [DLK-232, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3.REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
- NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

BACK DOOR REQUEST SWITCH

BACK DOOR REQUEST SWITCH : Description

INFOID:000000009649338

All doors do not lock/unlock using back door request switch.

BACK DOOR REQUEST SWITCH : Diagnosis Procedure

INFOID:000000009649339

1.CHECK BACK DOOR REQUEST SWITCH

Check back door request switch.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR DOES NOT LOCK/UNLOCK WITH DOOR REQUEST SWITCH

< SYMPTOM DIAGNOSIS >

Refer to [DLK-269, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK OUTSIDE KEY ANTENNA

Check outside key antenna (rear bumper).

Rear bumper: Refer to [DLK-236, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

< SYMPTOM DIAGNOSIS >

DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

Diagnosis Procedure

INFOID:000000009649340

1.CHECK INTELLIGENT KEY

For Intelligent Key that cannot be used for door lock and unlock, check that the Intelligent Key belongs to the vehicle to be checked.

Does the Intelligent Key belong to the vehicle to checked?

YES >> GO TO 2.

NO >> Check Intelligent Key button operation with registered Intelligent Key belonging to the vehicle.

2.CHECK INTELLIGENT KEY LOW BATTERY WARNING

Check that the Intelligent Key low battery warning is operated.

Is the Intelligent Key low battery warning operated?

YES >> GO TO 6.

NO-1 >> With another registered Intelligent Key: GO TO 3.

NO-2 >> Without another registered Intelligent Key: GO TO 4.

3.CHECK INTELLIGENT KEY BUTTON OPERATION

Check that door lock and unlock can be performed by operating the buttons of another registered Intelligent Key.

Can door lock and unlock be performed with another registered Intelligent Key?

YES >> GO TO 4.

NO >> GO TO 7.

4.CHECK ENGINE START

While depressing the brake pedal, contact the backside of the Intelligent Key that cannot be used to perform door lock and unlock operation to the push-button ignition switch. Operate the push-button ignition switch, and check that the vehicle is in START status.

Is the vehicle in START status?

YES >> GO TO 6.

NO >> GO TO 5.

5.CHECK INTELLIGENT KEY

Check the inside of the Intelligent Key for rust or corrosion by water. Simultaneously check the internal circuits for damage.

Is the vehicle in START status?

YES >> GO TO 6.

NO >> Replace Intelligent Key.

6.CHECK INTELLIGENT KEY BATTERY

Check the Intelligent Key battery.

Refer to [DLK-275, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace Intelligent Key battery.

7.CHECK POWER DOOR LOCK OPERATION

Check door lock/unlock using door lock and unlock switch.

Does door lock/unlock using door lock and unlock switch?

YES >> GO TO 8.

NO >> Refer to [DLK-368, "ALL DOOR : Diagnosis Procedure"](#).

8.CHECK REMOTE KEYLESS ENTRY RECEIVER

Check remote keyless entry receiver.

Refer to [DLK-265, "Component Function Check"](#).

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

DOOR DOES NOT LOCK/UNLOCK WITH INTELLIGENT KEY

< SYMPTOM DIAGNOSIS >

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace the malfunctioning parts.

9. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-241, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace the malfunctioning parts.

10. REPLACE INTELLIGENT KEY

1. Replace Intelligent Key.
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

IGNITION POSITION WARNING FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

IGNITION POSITION WARNING FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649341

1. CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-63, "DTC Index"](#).

2. CHECK POWER DOOR LOCK OPERATION

Check power door lock operation.

Does door lock/unlock with door lock and unlock switch?

YES >> GO TO 3.

NO >> Refer to [DLK-368, "ALL DOOR : Diagnosis Procedure"](#).

3. CHECK DOOR SWITCH

Check door switch

Refer to [DLK-241, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK BACK DOOR SWITCH

Check door switch

Refer to [DLK-243, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

SELECTIVE UNLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649342

1. CHECK "DOOR LOCK-UNLOCK SET" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "DOOR LOCK-UNLOCK SET" in "WORK SUPPORT" mode.
3. Check "DOOR LOCK-UNLOCK SET" setting in "WORK SUPPORT".
Refer to [DLK-94, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Set "On" in "DOOR LOCK-UNLOCK SET".

2. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

AUTO DOOR LOCK OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

AUTO DOOR LOCK OPERATION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649343

1. CHECK "AUTO LOCK SET" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "AUTO LOCK SET" in "WORK SUPPORT" mode.
3. Check "AUTO LOCK SET" setting in "WORK SUPPORT".
Refer to [DLK-95, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Set "MODE 2", "MODE 3", "MODE 4", "MODE 5", "MODE 6" or "MODE 7" in "AUTO LOCK SET".

2. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

VEHICLE SPEED SENSING AUTO LOCK OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

VEHICLE SPEED SENSING AUTO LOCK OPERATION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649344

1. CHECK "AUTOMATIC LOCK/UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC LOCK/UNLOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC LOCK/UNLOCK SELECT" setting in "WORK SUPPORT".
Refer to [DLK-94, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "Lock Only" or "Lock/Unlock" in "WORK SUPPORT".

2. CHECK "AUTOMATIC DOOR LOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC DOOR LOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC DOOR LOCK SELECT" setting in "WORK SUPPORT".
Refer to [DLK-94, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "VH SPD" in "AUTOMATIC DOOR LOCK SELECT".

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

IGN OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

IGN OFF INTERLOCK DOOR UNLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649345

1. CHECK "AUTOMATIC LOCK/UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC LOCK/UNLOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC LOCK/UNLOCK SELECT" setting in "WORK SUPPORT".
Refer to [DLK-94, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "Unlock Only" or "Lock/Unlock" in "AUTOMATIC LOCK/UNLOCK SELECT".

2. CHECK "AUTOMATIC DOOR UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC DOOR UNLOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC DOOR UNLOCK SELECT" setting in "WORK SUPPORT".
Refer to [DLK-94, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "MODE 1" or "MODE 3" in "AUTOMATIC DOOR UNLOCK SELECT".

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

P RANGE INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

P RANGE INTERLOCK DOOR LOCK/UNLOCK FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649346

1. CHECK "AUTOMATIC LOCK/UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC LOCK/UNLOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC LOCK/UNLOCK SELECT" setting in "WORK SUPPORT".
Refer to [DLK-94, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Set "Unlock Only", "Lock Only" or "Lock/Unlock" in "AUTOMATIC LOCK/UNLOCK SELECT".

2. CHECK "AUTOMATIC DOOR LOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC DOOR LOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC DOOR LOCK SELECT" setting in "WORK SUPPORT".
Refer to [DLK-94, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "P RANGE" in "AUTOMATIC DOOR LOCK SELECT".

3. CHECK "AUTOMATIC DOOR UNLOCK SELECT" SETTING IN "WORK SUPPORT"

1. Select "DOOR LOCK" of "BCM" using CONSULT.
2. Select "AUTOMATIC DOOR UNLOCK SELECT" in "WORK SUPPORT" mode.
3. Check "AUTOMATIC DOOR UNLOCK SELECT" setting in "WORK SUPPORT".
Refer to [DLK-94, "DOOR LOCK : CONSULT Function \(BCM - DOOR LOCK\)"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Set "MODE 2" or "MODE 4" in "AUTOMATIC DOOR UNLOCK SELECT".

4. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

HAZARD AND HORN REMINDER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

HAZARD AND HORN REMINDER DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649347

1. CHECK "HAZARD ANSWER BACK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "HAZARD ANSWER BACK" in "WORK SUPPORT" mode.
3. Check the "HAZARD ANSWER BACK" setting in "WORK SUPPORT".
Refer to [DLK-95, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Set the "Lock Only", "Unlock Only" or "Lock/Unlock" in "HAZARD ANSWER BACK".

2. CHECK "HORN WITH KEYLESS LOCK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "HORN WITH KEYLESS LOCK" in "WORK SUPPORT" mode.
3. Check the "HORN WITH KEYLESS LOCK" in "WORK SUPPORT".
Refer to [DLK-95, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Set the "On" in "HORN WITH KEYLESS LOCK".

3. CHECK HAZARD FUNCTION

Check hazard function.
Refer to [DLK-279, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning parts.

4. CHECK HORN FUNCTION

Check horn function.
Refer to [SEC-120, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HAZARD AND BUZZER REMINDER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

HAZARD AND BUZZER REMINDER DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649348

1. CHECK "HAZARD ANSWER BACK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "HAZARD ANSWER BACK" in "WORK SUPPORT" mode.
3. Check the "HAZARD ANSWER BACK" setting in "WORK SUPPORT".
Refer to [DLK-95, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)".](#)

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Set the "Lock Only", "Unlock Only" or "Lock/Unlock" in "HAZARD ANSWER BACK".

2. CHECK "ANS BACK I-KEY LOCK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "ANS BACK I-KEY LOCK" in "WORK SUPPORT" mode.
3. Check the "ANS BACK I-KEY LOCK" setting in "WORK SUPPORT".
Refer to [DLK-95, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)".](#)

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Set the "Horn Chirp" or "Buzzer" in "ANS BACK I-KEY LOCK".

3. CHECK "ANS BACK I-KEY UNLOCK" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.
2. Select "ANS BACK I-KEY UNLOCK" in "WORK SUPPORT" mode.
3. Check the "ANS BACK I-KEY UNLOCK" setting in "WORK SUPPORT".
Refer to [DLK-95, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)".](#)

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Set the "On" in "ANS BACK I-KEY UNLOCK".

4. CHECK HAZARD FUNCTION

Check hazard function.

Refer to [DLK-279, "Component Function Check".](#)

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace the malfunctioning parts.

5. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-273, "Component Function Check".](#)

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair or replace the malfunctioning parts.

6. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation".](#)
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident".](#)

KEY REMINDER FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

KEY REMINDER FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649349

1. CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-63, "DTC Index"](#).

2. CHECK "ANTI KEY LOCK IN FUNCTI" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM" using CONSULT.

2. Select "ANTI KEY LOCK IN FUNCTI" in "WORK SUPPORT" mode.

3. Check "ANTI KEY LOCK IN FUNCTI" setting in "WORK SUPPORT".

Refer to [DLK-95, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "On" in "ANTI KEY LOCK IN FUNCTI".

3. CHECK DOOR SWITCH

Check door switch

Refer to [DLK-241, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

• Instrument center: Refer to [DLK-226, "DTC Logic"](#).

• Console: Refer to [DLK-228, "DTC Logic"](#).

• Luggage room: Refer to [DLK-230, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CHECK UNLOCK SENSOR

Check unlock sensor.

Refer to [DLK-259, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

OFF POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

OFF POSITION WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649350

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Refer to [BCS-63, "DTC Index"](#) (BCM).

NO-2 >> Refer to [MWI-48, "DTC Index"](#) (combination meter).

2. CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-276, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-273, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK DOOR SWITCH

Check front door switch (driver side).

Refer to [DLK-241, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

P POSITION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

P POSITION WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649351

1. CHECK DTC WITH BCM, TCM AND COMBINATION METER

Check that DTC is not detected with BCM, TCM and combination meter.

Is the inspection result normal?

- YES >> GO TO 2.
- NO-1 >> Refer to [BCS-63, "DTC Index"](#) (BCM).
- NO-2 >> Refer to [TM-48, "DTC Index"](#) (TCM).
- NO-3 >> Refer to [MWI-48, "DTC Index"](#) (Combination meter).

2. CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-276, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-273, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

4. CHECK DOOR SWITCH

Check front door switch (driver side).

Refer to [DLK-241, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the malfunctioning parts.

5. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

- Instrument center: Refer to [DLK-226, "DTC Logic"](#).
- Console: Refer to [DLK-228, "DTC Logic"](#).
- Luggage room: Refer to [DLK-230, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair or replace the malfunctioning parts.

6. CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-277, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Repair or replace the malfunctioning parts.

7. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
- NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

ACC WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

ACC WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649352

1. CHECK P POSITION WARNING FUNCTION

Check P position warning function.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [DLK-387, "Diagnosis Procedure"](#).

2. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

TAKE AWAY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

TAKE AWAY WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649353

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Refer to [BCS-63, "DTC Index"](#) (BCM).

NO-2 >> Refer to [MWI-48, "DTC Index"](#) (Combination meter).

2. CHECK COMBINATION METER BUZZER

Check combination meter buzzer.

Refer to [DLK-276, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-277, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK DOOR SWITCH

Check front door switch (driver side).

Refer to [DLK-241, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-273, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

• Instrument center: Refer to [DLK-226, "DTC Logic"](#).

• Console: Refer to [DLK-228, "DTC Logic"](#).

• Luggage room: Refer to [DLK-230, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

7. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

KEY ID WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

KEY ID WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649354

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

- YES >> GO TO 2.
- NO-1 >> Refer to [BCS-63, "DTC Index"](#) (BCM).
- NO-2 >> Refer to [MWI-48, "DTC Index"](#) (Combination meter).

2. CHECK INTELLIGENT KEY BATTERY

Check Intelligent Key battery.

Refer to [DLK-275, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

- Instrument center: Refer to [DLK-226, "DTC Logic"](#).
- Console: Refer to [DLK-228, "DTC Logic"](#).
- Luggage room: Refer to [DLK-230, "DTC Logic"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

4. CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-277, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace the malfunctioning parts.

5. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
- NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

INTELLIGENT KEY LOW BATTERY WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649355

1. CHECK DTC WITH BCM AND COMBINATION METER

Check that DTC is not detected with BCM and combination meter.

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Refer to [BCS-63, "DTC Index"](#) (BCM).

NO-2 >> Refer to [MWI-48, "DTC Index"](#) (Combination meter).

2. CHECK "LO- BATT OF KEY FOB WARN" SETTING IN "WORK SUPPORT"

1. Select "INTELLIGENT KEY" of "BCM".

2. Select "LO- BATT OF KEY FOB WARN" in "WORK SUPPORT" mode.

3. Check "LO- BATT OF KEY FOB WARN" setting in "WORK SUPPORT".

Refer to [DLK-95, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Set "ON" in "LO- BATT OF KEY FOB WARN".

3. CHECK INTELLIGENT KEY BATTERY

Check Intelligent Key battery.

Refer to [DLK-275, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK INFORMATION DISPLAY

Check information display.

Refer to [DLK-277, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CHECK INSIDE KEY ANTENNA

Check inside key antenna.

• Instrument center: Refer to [DLK-226, "DTC Logic"](#).

• Console: Refer to [DLK-228, "DTC Logic"](#).

• Luggage room: Refer to [DLK-230, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

DOOR LOCK OPERATION WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

DOOR LOCK OPERATION WARNING DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649356

1. CHECK DOOR LOCK FUNCTION

Check door lock function.

Does door lock/unlock using door request switch?

YES >> GO TO 2.

NO >> Refer to [DLK-372, "ALL DOOR REQUEST SWITCHES : Diagnosis Procedure"](#).

2. CHECK INTELLIGENT KEY WARNING BUZZER

Check Intelligent Key warning buzzer.

Refer to [DLK-273, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. REPLACE BCM

1. Replace BCM. Refer to [BCS-98, "Removal and Installation"](#).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

BACK DOOR AUTO CLOSURE FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

BACK DOOR AUTO CLOSURE FUNCTION DOES NOT OPERATE OPEN/CLOSURE FUNCTION

OPEN/CLOSURE FUNCTION : Description

INFOID:000000009649357

Back door auto closure does not operate when back door opening and closing operations are performed.

OPEN/CLOSURE FUNCTION : Diagnosis Procedure

INFOID:000000009649358

1.CHECK DTC WITH BCM

Check that DTC is not detected with BCM.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refer to [BCS-63, "DTC Index"](#).

2.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check back door control unit power supply and ground circuit.

Refer to [DLK-238, "BACK DOOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK BACK DOOR CLOSURE MOTOR

Check back door closure motor.

Refer to [DLK-304, "WITHOUT AUTOMATIC BACK DOOR : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.REPLACE BACK DOOR CONTROL UNIT

1. Replace back door control unit.

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

OPEN FUNCTION

OPEN FUNCTION : Description

INFOID:000000009649359

Back door auto closure does not operate when back door opening operation is performed.

OPEN FUNCTION : Diagnosis Procedure

INFOID:000000009649360

1.CHECK BACK DOOR OPENER SWITCH

Check back door opener switch.

Refer to [DLK-271, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK BACK DOOR OPEN REQUEST SIGNAL CIRCUIT

Check back door open request signal circuit.

Refer to [DLK-280, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

BACK DOOR AUTO CLOSURE FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

3.REPLACE BACK DOOR CONTROL UNIT

1. Replace back door control unit.
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
NO >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).

CLOSURE FUNCTION

CLOSURE FUNCTION : Description

INFOID:000000009649361

Back door auto closure does not operate when back door closing operation is performed.

CLOSURE FUNCTION : Diagnosis Procedure

INFOID:000000009649362

1.CHECK HALF LATCH SWITCH

Check half latch switch.

Refer to [DLK-294. "WITHOUT AUTOMATIC BACK DOOR : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair or replace the malfunctioning parts.

2.CHECK OPEN SWITCH

Check open switch.

Refer to [DLK-289. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace the malfunctioning parts.

3.CHECK CLOSE SWITCH

Check close switch.

Refer to [DLK-291. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning parts.

4.REPLACE BACK DOOR CONTROL UNIT

1. Replace back door control unit.
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
NO >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).

AUTOMATIC BACK DOOR OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

AUTOMATIC BACK DOOR OPERATION DOES NOT OPERATE

ALL SWITCHES

ALL SWITCHES : Description

INFOID:000000009649363

Automatic back door open/close function does not operate using all switches.

NOTE:

Automatic back door open/close operation condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-52, "System Description"](#).

ALL SWITCHES : Diagnosis Procedure

INFOID:000000009649364

1. CHECK DTC WITH AUTOMATIC BACK DOOR CONTROL MODULE

Check that DTC is not detected with automatic back door control module.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

2. CHECK BACK DOOR AUTO CLOSURE FUNCTION

Check back door auto closure function.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Refer to [DLK-398, "OPEN/CLOSURE FUNCTION : Diagnosis Procedure"](#).

3. CHECK GROUND CIRCUIT

Check automatic back door control module ground circuit.

Refer to [DLK-308, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK TOUCH SENSOR LH

Check touch sensor LH.

Refer to [DLK-299, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CHECK TOUCH SENSOR RH

Check touch sensor RH.

Refer to [DLK-301, "RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

1. Replace automatic back door control module.

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

AUTOMATIC BACK DOOR SWITCH

AUTOMATIC BACK DOOR SWITCH : Description

INFOID:000000009649365

Automatic back door open/close function does not operate using automatic back door switch.

NOTE:

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

AUTOMATIC BACK DOOR OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

Automatic back door open/close operation condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-52, "System Description"](#).

AUTOMATIC BACK DOOR SWITCH : Diagnosis Procedure

INFOID:000000009649366

1. CHECK AUTOMATIC BACK DOOR SWITCH

Check automatic back door switch.

Refer to [DLK-287, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

1. Replace automatic back door control module.

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

AUTOMATIC BACK DOOR CLOSE SWITCH

AUTOMATIC BACK DOOR CLOSE SWITCH : Description

INFOID:000000009649367

Automatic back door open/close function does not operate using automatic back door close switch.

NOTE:

Automatic back door open/close operation condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-52, "System Description"](#).

AUTOMATIC BACK DOOR CLOSE SWITCH : Diagnosis Procedure

INFOID:000000009649368

1. CONFIRM THE OPERATION

1. Turn ON automatic door main switch.

2. Confirm the operation.

Is the result normal?

YES >> Automatic back door system is normal.

NO >> GO TO 2.

2. CHECK AUTOMATIC BACK DOOR CLOSE SWITCH

Check automatic back door close switch.

Refer to [DLK-281, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK AUTOMATIC DOOR MAIN SWITCH

Check automatic door main switch.

Refer to [DLK-283, "AUTOMATIC BACK DOOR CONTROL MODULE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

1. Replace automatic back door control module.

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

INTELLIGENT KEY

AUTOMATIC BACK DOOR OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

INTELLIGENT KEY : Description

INFOID:000000009649369

Automatic back door open/close function does not operate using Intelligent Key.

NOTE:

Automatic back door open/close operation condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-52, "System Description"](#).

INTELLIGENT KEY : Diagnosis Procedure

INFOID:000000009649370

1. CHECK DTC WITH BCM AND AUTOMATIC BACK DOOR CONTROL MODULE

Check that DTC is not detected with BCM, TCM and combination meter.

Is the inspection result normal?

YES >> GO TO 2.

NO-1 >> Refer to [BCS-63, "DTC Index"](#) (BCM).

NO-2 >> Refer to [DLK-109, "DTC Index"](#) (automatic back door control module).

2. CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent Key button?

YES >> GO TO 3.

NO >> Refer to [DLK-375, "Diagnosis Procedure"](#).

3. REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

1. Replace automatic back door control module.

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

BACK DOOR OPENER SWITCH

BACK DOOR OPENER SWITCH : Description

INFOID:000000009649371

Automatic back door open/close function does not operate using back door opener switch.

NOTE:

Automatic back door open/close operation condition is extremely complicated, during operating confirmations, reconfirm the list above twice in order to ensure proper operation. Refer to [DLK-52, "System Description"](#).

BACK DOOR OPENER SWITCH : Diagnosis Procedure

INFOID:000000009649372

1. CONFIRM THE OPERATION

1. Turn ON automatic door main switch.

2. Confirm the operation.

Is the result normal?

YES >> Automatic door system is normal.

NO >> GO TO 2.

2. CHECK BACK DOOR OPENER SWITCH

Check back door opener switch.

Refer to [DLK-271, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK AUTOMATIC DOOR MAIN SWITCH

Check automatic door main switch.

Refer to [DLK-283, "AUTOMATIC BACK DOOR CONTROL MODULE : Component Function Check"](#).

Is the inspection result normal?

AUTOMATIC BACK DOOR OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning parts.

4.REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

1. Replace automatic back door control module.
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

OPEN/CLOSURE FUNCTION

OPEN/CLOSURE FUNCTION : Description

INFOID:000000009649373

Back door auto closure function does not operate when back door opening and closing operations are performed.

OPEN/CLOSURE FUNCTION : Diagnosis Procedure

INFOID:000000009649374

1.CHECK DTC WITH AUTOMATIC BACK DOOR CONTROL MODULE

Check that DTC is not detected with automatic back door control module.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check automatic back door control module power supply and ground circuit.

Refer to [DLK-238, "AUTOMATIC BACK DOOR CONTROL MODULE : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace the malfunctioning parts.

3.CHECK BACK DOOR CLOSURE MOTOR

Check back door closure motor.

Refer to [DLK-304, "WITH AUTOMATIC BACK DOOR : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning parts.

4.REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

1. Replace automatic back door control module.
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

OPEN FUNCTION

OPEN FUNCTION : Description

INFOID:000000009649375

Back door auto closure function does not operate when back door opening operations are performed.

OPEN FUNCTION : Diagnosis Procedure

INFOID:000000009649376

1.CHECK BACK DOOR OPENER SWITCH

Check back door opener switch.

Refer to [DLK-271, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.

AUTOMATIC BACK DOOR OPERATION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

NO >> Repair or replace the malfunctioning parts.

2.REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

1. Replace automatic back door control module.
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).

CLOSURE FUNCTION

CLOSURE FUNCTION : Description

INFOID:000000009649377

Back door auto closure function does not operate when back door closing operations are performed.

CLOSURE FUNCTION : Diagnosis Procedure

INFOID:000000009649378

1.CHECK HALF LATCH SWITCH

Check half latch switch.

Refer to [DLK-293. "WITH AUTOMATIC BACK DOOR : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

1. Replace automatic back door control module.
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

AUTOMATIC BACK DOOR WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

AUTOMATIC BACK DOOR WARNING DOES NOT OPERATE BUZZER

BUZZER : Description

INFOID:000000009649379

Automatic back door warning buzzer does not operate when automatic back door warning function are performed.

BUZZER : Diagnosis Procedure

INFOID:000000009649380

1.CHECK DTC WITH AUTOMATIC BACK DOOR CONTROL MODULE

Check that DTC is not detected with automatic back door control module.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK AUTOMATIC BACK DOOR WARNING BUZZER

Check automatic back door warning buzzer.

Refer to [DLK-306, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3.REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

1. Replace automatic back door control module.
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
- NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

HAZARD WARNING LAMP

HAZARD WARNING LAMP : Description

INFOID:000000009649381

Hazard warning lamp does not operate when automatic back door warning function are performed.

HAZARD WARNING LAMP : Diagnosis Procedure

INFOID:000000009649382

1.CHECK DTC WITH BCM AND AUTOMATIC BACK DOOR CONTROL MODULE

Check that DTC is not detected with BCM, TCM and combination meter.

Is the inspection result normal?

- YES >> GO TO 2.
- NO-1 >> Refer to [BCS-63, "DTC Index"](#) (BCM).
- NO-2 >> Refer to [DLK-109, "DTC Index"](#) (automatic back door control module).

2.CHECK GROUND CIRCUIT

Check automatic back door control module ground circuit.

Refer to [DLK-308, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts

3.CHECK HAZARD AND HORN REMINDER FUNCTION

Check hazard and horn reminder function.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Refer to [DLK-383, "Diagnosis Procedure"](#).

AUTOMATIC BACK DOOR WARNING DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

4. REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

1. Replace automatic back door control module.
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

AUTOMATIC BACK DOOR FUNCTIONS DO NOT CANCEL

< SYMPTOM DIAGNOSIS >

AUTOMATIC BACK DOOR FUNCTIONS DO NOT CANCEL

Diagnosis Procedure

INFOID:000000009649383

1.CHECK THE OPERATION

Check automatic door main switch function.

NOTE:

When the main switch is OFF, the automatic back door operation is not available by back door opener switch and automatic back door close switch.

Is the inspection result normal?

- YES >> Automatic back door system is normal.
- NO >> GO TO 2.

2.CHECK AUTOMATIC DOOR MAIN SWITCH

Check automatic door main switch.

Refer to [DLK-283, "AUTOMATIC BACK DOOR CONTROL MODULE : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3.REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

1. Replace automatic back door control module.
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
- NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

AUTOMATIC BACK DOOR ANTI-PINCH FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

AUTOMATIC BACK DOOR ANTI-PINCH FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649384

1. CHECK TOUCH SENSOR LH

Check touch sensor LH.

Refer to [DLK-299, "LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK TOUCH SENSOR RH

Check touch sensor RH.

Refer to [DLK-301, "RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. REPLACE AUTOMATIC BACK DOOR CONTROL MODULE

1. Replace automatic back door control module.

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

INTEGRATED HOMELINK TRANSMITTER DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

INTEGRATED HOMELINK TRANSMITTER DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000009649385

1. CHECK INTEGRATED HOMELINK TRANSMITTER

Check integrated homelink transmitter.

Refer to [DLK-309, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. REPLACE AUTO ANTI-DAZZLING INSIDE MIRROR

Replace auto anti-dazzling inside mirror.

Refer to [MIR-29, "Removal and Installation"](#).

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

AUTOMATIC SLIDING DOOR SYSTEM DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

AUTOMATIC SLIDING DOOR SYSTEM DOES NOT OPERATE ALL FUNCTIONS

ALL FUNCTIONS : Description

INFOID:000000009649386

Automatic sliding door system all functions does not operate.

ALL FUNCTIONS : Diagnosis Procedure

INFOID:000000009649387

1.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check sliding door control unit power supply and ground circuit.

Refer to [DLK-239. "SLIDING DOOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500. "RH : Removal and Installation"](#) (RH) or [DLK-500. "LH : Removal and Installation"](#) (LH).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).

ONE-TOUCH UNLOCK FUNCTION

ONE-TOUCH UNLOCK FUNCTION : Description

INFOID:000000009649388

Automatic sliding door system one-touch unlock function does not operate.

ONE-TOUCH UNLOCK FUNCTION : Diagnosis Procedure

INFOID:000000009649389

1.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent Key button?

YES >> GO TO 3.

NO >> Refer to [DLK-375. "Diagnosis Procedure"](#).

3.CHECK AUTO OPEN/CLOSE FUNCTION

Check automatic sliding door system auto open/close function.

Does sliding door auto open/close with switches?

YES >> GO TO 4.

NO >> Refer to [DLK-412. "ALL SWITCHES : Diagnosis Procedure"](#).

4.CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

Check sliding door one-touch open/close switch.

AUTOMATIC SLIDING DOOR SYSTEM DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

- Sliding door LH: Refer to [DLK-347, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-349, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace the malfunctioning parts.

5.CHECK SLIDING DOOR LOCK STATUS SWITCH

Check sliding door lock status switch.

- Sliding door LH: Refer to [DLK-334, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-336, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 6.
NO >> Repair or replace the malfunctioning parts.

6.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

POWER ASSIST FUNCTION

POWER ASSIST FUNCTION : Description

INFOID:000000009649390

Automatic sliding door system power assist function does not operate.

POWER ASSIST FUNCTION : Diagnosis Procedure

INFOID:000000009649391

1.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK AUTO OPEN/CLOSE FUNCTION

Check automatic sliding door system auto open/close function.

Does sliding door auto open/close with switches?

- YES >> GO TO 3.
NO >> Refer to [DLK-412, "ALL SWITCHES : Diagnosis Procedure"](#).

3.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

UNLOCK-LINKED OPENING FUNCTION

UNLOCK-LINKED OPENING FUNCTION : Description

INFOID:000000009649392

Automatic sliding door unlock-linked opening function does not operate.

UNLOCK-LINKED OPENING FUNCTION : Diagnosis Procedure

INFOID:000000009649393

1.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

AUTOMATIC SLIDING DOOR SYSTEM DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK ONE-TOUCH UNLOCK FUNCTION

Check automatic sliding door one-touch unlock function.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Refer to [DLK-405, "ONE-TOUCH UNLOCK FUNCTION : Diagnosis Procedure"](#).

3.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

HOLD FUNCTION

HOLD FUNCTION : Description

INFOID:000000009649394

Automatic sliding door system hold function does not operate.

HOLD FUNCTION : Diagnosis Procedure

INFOID:000000009649395

1.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK SLIDING DOOR HANDLE SWITCH

Check sliding door handle switch.

- Sliding door LH: Refer to [DLK-326, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-328, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CHECK CLUTCH

Check clutch.

- Sliding door LH: Refer to [DLK-355, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-356, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK FULL LATCH SWITCH

Check full latch switch.

- Sliding door LH: Refer to [DLK-318, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-320, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CHECK HALF LATCH SWITCH

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

AUTOMATIC SLIDING DOOR SYSTEM DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

Check half latch switch.

Refer to [DLK-296, "SLIDING DOOR CONTROL UNIT : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6. REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

ANTI-PINCH FUNCTION

ANTI-PINCH FUNCTION : Description

INFOID:000000009649396

Automatic sliding door system anti-pinch function does not operate.

ANTI-PINCH FUNCTION : Diagnosis Procedure

INFOID:000000009649397

1. CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

2. CHECK SLIDING DOOR TOUCH SENSOR

Check sliding door touch sensor.

- Sliding door LH: Refer to [DLK-351, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-353, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CHECK ENCODER

Check encoder.

- Sliding door LH: Refer to [DLK-311, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-312, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4. CHECK FULL LATCH SWITCH

Check full latch switch.

- Sliding door LH: Refer to [DLK-318, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-320, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5. CHECK SLIDING DOOR LOCK STATUS SWITCH

Check sliding door lock status switch.

- Sliding door LH: Refer to [DLK-334, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-336, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6.

AUTOMATIC SLIDING DOOR SYSTEM DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

NO >> Repair or replace the malfunctioning parts.

6.CHECK SLIDING DOOR SWITCH

Check sliding door switch.

- Sliding door LH: Refer to [DLK-315, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-316, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

7.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

INTERMITTENT CLUTCH FUNCTION

INTERMITTENT CLUTCH FUNCTION : Description

INFOID:000000009649398

Automatic sliding door system intermittent clutch function does not operate.

INTERMITTENT CLUTCH FUNCTION : Diagnosis Procedure

INFOID:000000009649399

1.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK CLUTCH

Check clutch.

- Sliding door LH: Refer to [DLK-355, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-356, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

HAZARD AND BUZZER REMINDER FUNCTION

HAZARD AND BUZZER REMINDER FUNCTION : Description

INFOID:000000009649400

Automatic sliding door system hazard and buzzer reminder function does not operate.

HAZARD AND BUZZER REMINDER FUNCTION : Diagnosis Procedure

INFOID:000000009649401

1.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

AUTOMATIC SLIDING DOOR SYSTEM DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

- YES >> GO TO 2.
NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK AUTOMATIC SLIDING DOOR WARNING BUZZER

Check automatic sliding door warning buzzer.

- Sliding door LH: Refer to [DLK-365. "SLIDING DOOR LH : Diagnosis Procedure"](#).
- Sliding door RH: Refer to [DLK-366. "SLIDING DOOR RH : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or rereplace the malfunctioning parts.

3.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500. "RH : Removal and Installation"](#) (RH) or [DLK-500. "LH : Removal and Installation"](#) (LH).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
NO >> Check intermittent incident. Refer to [GI-42. "Intermittent Incident"](#).

SLIDING DOOR AUTO CLOSURE FUNCTION

SLIDING DOOR AUTO CLOSURE FUNCTION : Description

INFOID:000000009649402

Automatic sliding door system sliding door auto closure function does not operate.

SLIDING DOOR AUTO CLOSURE FUNCTION : Diagnosis Procedure

INFOID:000000009649403

1.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK SLIDING DOOR HANDLE SWITCH

Check sliding door handle switch.

- Sliding door LH: Refer to [DLK-326. "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-328. "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace the malfunctioning parts.

3.CHECK FULL LATCH SWITCH

Check full latch switch.

- Sliding door LH: Refer to [DLK-318. "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-320. "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace the malfunctioning parts.

4.CHECK NEUTRAL SWITCH

Check neutral switch.

- Sliding door LH: Refer to [DLK-322. "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-324. "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Repair or replace the malfunctioning parts.

5.CHECK HALF LATCH SWITCH

Check half latch switch.

AUTOMATIC SLIDING DOOR SYSTEM DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

Refer to [DLK-296, "SLIDING DOOR CONTROL UNIT : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 6

NO >> Repair or replace the malfunctioning parts.

6. CHECK SLIDING DOOR CLOSURE MOTOR

Check sliding door closure motor.

- Sliding door LH: Refer to [DLK-363, "SLIDING DOOR LH : Diagnosis Procedure"](#).
- Sliding door RH: Refer to [DLK-363, "SLIDING DOOR RH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

7. REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

AUTOMATIC SLIDING DOOR OPEN/CLOSE FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

AUTOMATIC SLIDING DOOR OPEN/CLOSE FUNCTION DOES NOT OPERATE

ALL SWITCHES

ALL SWITCHES : Description

INFOID:000000009649404

Automatic sliding door system auto open/close function does not operate using all switches.

ALL SWITCHES : Diagnosis Procedure

INFOID:000000009649405

1.CHECK AUTOMATIC DOOR MAIN SWITCH POSITION

Check automatic door main switch is in the ON position.

Is the inspection result normal?

YES >> GO TO 2

NO >> Press automatic door main switch to ON position.

2.CHECK DTC WITH SLIDING DOOR MAIN SWITCH

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Perform trouble diagnosis relevant to DTC indicated.

3.CHECK AUTOMATIC DOOR MAIN SWITCH

Check automatic door main switch.

Refer to [DLK-284, "SLIDING DOOR CONTROL UNIT : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.CHECK FUEL FILLER LID STATUS SWITCH

Check fuel filler lid status switch.

Refer to [DLK-338, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.CHECK POWER SUPPLY AND GROUND CIRCUIT

Check sliding door control unit power supply and ground circuit.

Refer to [DLK-239, "SLIDING DOOR CONTROL UNIT : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace the malfunctioning parts.

6.CHECK SLIDING DOOR LOCK RELEASE ACTUATOR

Check sliding door lock release actuator.

- Sliding door LH: Refer to [DLK-360, "SLIDING DOOR LH : Diagnosis Procedure"](#).
- Sliding door RH: Refer to [DLK-361, "SLIDING DOOR RH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace the malfunctioning parts.

7.CHECK CLUTCH

Check clutch.

- Sliding door LH: Refer to [DLK-355, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-356, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

AUTOMATIC SLIDING DOOR OPEN/CLOSE FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

- YES >> GO TO 8.
NO >> Repair or replace the malfunctioning parts.

8.CHECK AUTOMATIC SLIDING DOOR MOTOR

Check automatic sliding door motor.

- Sliding door LH: Refer to [DLK-358, "SLIDING DOOR LH : Diagnosis Procedure"](#).
- Sliding door RH: Refer to [DLK-358, "SLIDING DOOR RH : Diagnosis Procedure"](#)

Is the inspection result normal?

- YES >> GO TO 9.
NO >> Repair or replace the malfunctioning parts.

9.CHECK HALF LATCH SWITCH

Check half latch switch.

Refer to [DLK-296, "SLIDING DOOR CONTROL UNIT : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 10.
NO >> Repair or replace the malfunctioning parts.

10.CHECK FULL LATCH SWITCH

Check full latch switch.

- Sliding door LH: Refer to [DLK-318, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-320, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 11.
NO >> Repair or replace the malfunctioning parts.

11.CHECK SLIDING DOOR SWITCH

Check sliding door switch.

- Sliding door LH: Refer to [DLK-315, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-316, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 12.
NO >> Repair or replace the malfunctioning parts.

12.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).
2. Confirm the operation after replacement.

Is the result normal?

- YES >> INSPECTION END
NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

OUTSIDE HANDLE

OUTSIDE HANDLE : Description

INFOID:000000009649406

Automatic sliding door system auto open/close function does not operate using sliding door outside handle.

OUTSIDE HANDLE : Diagnosis Procedure

INFOID:000000009649407

1.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK AUTO OPEN/CLOSE FUNCTION

Check automatic sliding door system auto open/close function.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

AUTOMATIC SLIDING DOOR OPEN/CLOSE FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

Does sliding door auto open/close with switches?

YES >> GO TO 3.

NO >> Refer to [DLK-412, "ALL SWITCHES : Diagnosis Procedure"](#).

3.CHECK SLIDING DOOR HANDLE SWITCH

Check sliding door handle switch.

- Sliding door LH: Refer to [DLK-326, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-328, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

INSIDE HANDLE

INSIDE HANDLE : Description

INFOID:000000009649408

Automatic sliding door system auto open/close function does not operate using sliding door inside handle.

INSIDE HANDLE : Diagnosis Procedure

INFOID:000000009649409

1.CHECK CHILD LOCK STATUS

Check child lock is unlock.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Perform trouble diagnosis relevant to DTC indicated.

3.CHECK AUTO OPEN/CLOSE FUNCTION

Check automatic sliding door system auto open/close function.

Does sliding door auto open/close with switches?

YES >> GO TO 4.

NO >> Refer to [DLK-412, "ALL SWITCHES : Diagnosis Procedure"](#).

4.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

INTELLIGENT KEY

INTELLIGENT KEY : Description

INFOID:000000009649410

Automatic sliding door system auto open/close function does not operate using Intelligent Key.

AUTOMATIC SLIDING DOOR OPEN/CLOSE FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

INTELLIGENT KEY : Diagnosis Procedure

INFOID:000000009649411

1.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent Key button?

YES >> GO TO 3.

NO >> Refer to [DLK-375, "Diagnosis Procedure"](#).

3.CHECK AUTO OPEN/CLOSE FUNCTION

Check automatic sliding door system auto open/close function.

Does sliding door auto open/close with sliding door outside handle?

YES >> GO TO 4.

NO >> Refer to [DLK-413, "OUTSIDE HANDLE : Diagnosis Procedure"](#).

4.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

SLIDING DOOR OPEN/CLOSE SWITCH

SLIDING DOOR OPEN/CLOSE SWITCH : Description

INFOID:000000009649412

Automatic sliding door system auto open/close function does not operate using sliding door open/close switch.

SLIDING DOOR OPEN/CLOSE SWITCH : Diagnosis Procedure

INFOID:000000009649413

DLK

1.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK AUTO OPEN/CLOSE FUNCTION

Check automatic sliding door system auto open/close function.

Does sliding door auto open/close with switches?

YES >> GO TO 3.

NO >> Refer to [DLK-412, "ALL SWITCHES : Diagnosis Procedure"](#).

3.CHECK SLIDING DOOR OPEN/CLOSE SWITCH

Check sliding door open/close switch.

- Front LH: Refer to [DLK-340, "FRONT LH : Component Function Check"](#).
- Front RH: Refer to [DLK-341, "FRONT RH : Component Function Check"](#).
- Rear LH: Refer to [DLK-343, "REAR LH : Component Function Check"](#).
- Rear RH: Refer to [DLK-344, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

AUTOMATIC SLIDING DOOR OPEN/CLOSE FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

4.CHECK CHILD LOCK STATUS SWITCH

Check child lock status switch.

- Sliding door LH: Refer to [DLK-330, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-332, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace the malfunctioning parts.

5.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH : Description

INFOID:000000009649414

Automatic sliding door system auto open/close function does not operate using sliding door one-touch open close switch.

SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH : Diagnosis Procedure

INFOID:000000009649415

1.CHECK DTC WITH SLIDING DOOR CONTROL UNIT

Check that DTC is not detected with sliding door control unit.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Perform trouble diagnosis relevant to DTC indicated.

2.CHECK AUTO OPEN/CLOSE FUNCTION

Check automatic sliding door system auto open/close function.

Does sliding door auto open/close with switches?

YES >> GO TO 3.

NO >> Refer to [DLK-395, "ALL SWITCHES : Diagnosis Procedure"](#).

3.CHECK SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

Check sliding door one-touch open/close switch.

- Sliding door LH: Refer to [DLK-347, "SLIDING DOOR LH : Component Function Check"](#).
- Sliding door RH: Refer to [DLK-349, "SLIDING DOOR RH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

4.REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).
2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

AUTOMATIC SLIDING DOOR FUNCTIONS DO NOT CANCEL

< SYMPTOM DIAGNOSIS >

AUTOMATIC SLIDING DOOR FUNCTIONS DO NOT CANCEL

Diagnosis Procedure

INFOID:000000009649416

1. CHECK AUTOMATIC DOOR MAIN SWITCH

Check automatic door main switch.

Refer to [DLK-284, "SLIDING DOOR CONTROL UNIT : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. REPLACE SLIDING DOOR CONTROL UNIT

1. Replace sliding door control unit. Refer to [DLK-500, "RH : Removal and Installation"](#) (RH) or [DLK-500, "LH : Removal and Installation"](#) (LH).

2. Confirm the operation after replacement.

Is the result normal?

YES >> INSPECTION END

NO >> Check intermittent incident. Refer to [GI-42, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK AND RATTLE TROUBLE DIAGNOSES

Work Flow

INFOID:000000009649417



CUSTOMER INTERVIEW

Interview the customer if possible, to determine the conditions that exist when the noise occurs. Use the Diagnostic Worksheet during the interview to document the facts and conditions when the noise occurs and any of customer's comments; refer to [DLK-422, "Diagnostic Worksheet"](#). This information is necessary to duplicate the conditions that exist when the noise occurs.

- The customer may not be able to provide a detailed description or the location of the noise. Attempt to obtain all the facts and conditions that exist when the noise occurs (or does not occur).
- If there is more than one noise in the vehicle, perform a diagnosis and repair the noise that the customer is concerned about. This can be accomplished by performing a cruise test on the vehicle with the customer.
- After identifying the type of noise, isolate the noise in terms of its characteristics. The noise characteristics are provided so the customer, service adviser and technician are all speaking the same language when defining the noise.
- Squeak – (Like tennis shoes on a clean floor)
Squeak characteristics include the light contact/fast movement/brought on by road conditions/hard surfaces = higher pitch noise/softer surfaces = lower pitch noises/edge to surface = chirping
- Creak – (Like walking on an old wooden floor)
Creak characteristics include firm contact/slow movement/twisting with a rotational movement/pitch dependent on materials/often brought on by activity.
- Rattle – (Like shaking a baby rattle)
Rattle characteristics include the fast repeated contact/vibration or similar movement/loose parts/missing clip or fastener/incorrect clearance.
- Knock – (Like a knock on a door)
Knock characteristics include hollow sounding/sometimes repeating/often brought on by driver action.
- Tick – (Like a clock second hand)
Tick characteristics include gentle contacting of light materials/loose components/can be caused by driver action or road conditions.
- Thump – (Heavy, muffled knock noise)
Thump characteristics include softer knock/dead sound often brought on by activity.
- Buzz – (Like a bumblebee)
Buzz characteristics include high frequency rattle/firm contact.
- Often the degree of acceptable noise level will vary depending up on the person. A noise that a technician may judge as acceptable may be very irritating to the customer.
- Weather conditions, especially humidity and temperature, may have a great effect on noise level.

DUPLICATE THE NOISE AND TEST DRIVE

If possible, drive the vehicle with the customer until the noise is duplicated. Note any additional information on the Diagnostic Worksheet regarding the conditions or location of the noise. This information can be used to duplicate the same conditions when the repair is reconfirmed.

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

If the noise can be duplicated easily during the test drive, to help identify the source of the noise, try to duplicate the noise with the vehicle stopped by doing one or all of the following:

- 1) Close a door.
 - 2) Tap or push/pull around the area where the noise appears to be coming from.
 - 3) Rev the engine.
 - 4) Use a floor jack to recreate vehicle "twist".
 - 5) At idle, apply engine load (electrical load, half-clutch on M/T models, drive position on A/T models).
 - 6) Raise the vehicle on a hoist and hit a tire with a rubber hammer.
- Drive the vehicle and attempt to duplicate the conditions the customer states exist when the noise occurs.
 - If it is difficult to duplicate the noise, drive the vehicle slowly on an undulating or rough road to stress the vehicle body.

CHECK RELATED SERVICE BULLETINS

After verifying the customer concern or symptom, check ASIST for Technical Service Bulletins (TSBs) related to that concern or symptom.

If a TSB relates to the symptom, follow the procedure to repair the noise.

LOCATE THE NOISE AND IDENTIFY THE ROOT CAUSE

1. Narrow down the noise to a general area. To help pinpoint the source of the noise, use a listening tool (Chassis ear: J-39570, Engine ear and mechanics stethoscope).
2. Narrow down the noise to a more specific area and identify the cause of the noise by:
 - Removing the components in the area that is are suspected to be the cause of the noise.
Do not use too much force when removing clips and fasteners, otherwise clips and fastener can be broken or lost during the repair, resulting in the creation of new noise.
 - Tapping or pushing/pulling the component that is are suspected to be the cause of the noise.
Do not tap or push/pull the component with excessive force, otherwise the noise will be eliminated only temporarily.
 - Feeling for a vibration by hand by touching the component(s) that is are suspected to be the cause of the noise.
 - Placing a piece of paper between components that are suspected to be the cause of the noise.
 - Looking for loose components and contact marks.
Refer to [DLK-420. "Inspection Procedure"](#).

REPAIR THE CAUSE

- If the cause is a loose component, tighten the component securely.
- If the cause is insufficient clearance between components:
 - Separate components by repositioning or loosening and retightening the component, if possible.
 - Insulate components with a suitable insulator such as urethane pads, foam blocks, felt cloth tape or urethane tape. A Nissan Squeak and Rattle Kit (J-50397) is available through the authorized Nissan Parts Department.

CAUTION:

Never use excessive force as many components are constructed of plastic and may be damaged.

NOTE:

Always check with the Parts Department for the latest parts information.

The following materials are contained in the Nissan Squeak and Rattle Kit (J-50397) are listed on the inside cover of the kit; and can each be ordered separately as needed.

URETHANE PADS [1.5 mm (0.059 in) thick]

Insulates connectors, harness, etc.

76268-9E005: 100 × 135 mm (3.94 × 5.31 in)/76884-71L01: 60 × 85 mm (2.36 × 3.35 in)/76884-71L02: 15 × 25 mm (0.59 × 0.98 in)

INSULATOR (Foam blocks)

Insulates components from contact. Can be used to fill space behind a panel.

73982-9E000: 45 mm (1.77 in) thick, 50 × 50 mm (1.97 × 1.97 in)/73982-

50Y00: 10 mm (0.39 in) thick, 50 × 50 mm (1.97 × 1.97 in)

INSULATOR (Light foam block)

80845-71L00: 30 mm (1.18 in) thick, 30 × 50 mm (1.18 × 1.97 in)

FELT CLOTHTAPE

Used to insulate where movement does not occur. Ideal for instrument panel applications.

68370-4B000: 15 × 25 mm (0.59 × 0.98 in) pad/68239-13E00: 5 mm (0.20 in) wide tape roll

The following materials, not found in the kit, can also be used to repair squeaks and rattles.

UHMW (TEFLON) TAPE

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Insulates where slight movement is present. Ideal for instrument panel applications.

SILICONE GREASE

Used in place of UHMW tape that is be visible or does not fit. Will only last a few months.

SILICONE SPRAY

Used when grease cannot be applied.

DUCT TAPE

Used to eliminate movement.

CONFIRM THE REPAIR

Confirm that the cause of a noise is repaired by test driving the vehicle. Operate the vehicle under the same conditions as when the noise originally occurred. Refer to the notes on the Diagnostic Worksheet.

Inspection Procedure

INFOID:000000009649418

Refer to Table of Contents for specific component removal and installation information.

INSTRUMENT PANEL

Most incidents are caused by contact and movement between:

1. The cluster lid A and instrument panel
2. Acrylic lens and combination meter housing
3. Instrument panel to front pillar garnish
4. Instrument panel to windshield
5. Instrument panel mounting pins
6. Wiring harnesses behind the combination meter
7. A/C defroster duct and duct joint

These incidents can usually be located by tapping or moving the components to duplicate the noise or by pressing on the components while driving to stop the noise. Most of these incidents can be repaired by applying felt cloth tape or silicon spray (in hard to reach areas). Urethane pads can be used to insulate wiring harness.

CAUTION:

Never use silicone spray to isolate a squeak or rattle. If the area is saturated with silicone, the recheck of repair becomes impossible.

CENTER CONSOLE

Components to pay attention to include:

1. Shifter assembly cover to finisher
2. A/C control unit and cluster lid C
3. Wiring harnesses behind audio and A/C control unit

The instrument panel repair and isolation procedures also apply to the center console.

DOORS

Pay attention to the following:

1. Finisher and inner panel making a slapping noise
2. Inside handle escutcheon to door finisher
3. Wiring harnesses tapping
4. Door striker out of alignment causing a popping noise on starts and stops

Tapping or moving the components or pressing on them while driving to duplicate the conditions can isolate many of these incidents. The areas can usually be insulated with felt cloth tape or insulator foam blocks from the Nissan Squeak and Rattle Kit (J-50397) to repair the noise.

TRUNK

Trunk noises are often caused by a loose jack or loose items put into the trunk by the customer.

In addition look for the following:

1. Trunk lid dumpers out of adjustment
2. Trunk lid striker out of adjustment
3. The trunk lid torsion bars knocking together
4. A loose license plate or bracket

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Most of these incidents can be repaired by adjusting, securing or insulating the item(s) or component(s) causing the noise.

SUNROOF/HEADLINING

Noises in the sunroof/headlining area can often be traced to one of the following:

1. Sunroof lid, rail, linkage or seals making a rattle or light knocking noise
2. Sunvisor shaft shaking in the holder
3. Front or rear windshield touching headlining and squeaking

Again, pressing on the components to stop the noise while duplicating the conditions can isolate most of these incidents. Repairs usually consist of insulating with felt cloth tape.

SEATS

When isolating seat noise it's important to note the position the seats in and the load placed on the seat when the noise occurs. These conditions should be duplicated when verifying and isolating the cause of the noise.

Cause of seat noise include:

1. Headrest rods and holder
2. A squeak between the seat pad cushion and frame
3. The rear seatback lock and bracket

These noises can be isolated by moving or pressing on the suspected components while duplicating the conditions under which the noise occurs. Most of these incidents can be repaired by repositioning the component or applying urethane tape to the contact area.

UNDERHOOD

Some interior noise may be caused by components under the hood or on the engine wall. The noise is then transmitted into the passenger compartment.

Causes of transmitted underhood noise include:

1. Any component mounted to the engine wall
2. Components that pass through the engine wall
3. Engine wall mounts and connectors
4. Loose radiator mounting pins
5. Hood bumpers out of adjustment
6. Hood striker out of adjustment

These noises can be difficult to isolate since they cannot be reached from the interior of the vehicle. The best method is to secure, move or insulate one component at a time and test drive the vehicle. Also, engine RPM or load can be changed to isolate the noise. Repairs can usually be made by moving, adjusting, securing, or insulating the component causing the noise.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

Diagnostic Worksheet

INFOID:00000009649419







SQUEAK & RATTLE DIAGNOSTIC WORKSHEET

Dear Nissan Customer:

We are concerned about your satisfaction with your Nissan vehicle. Repairing a squeak or rattle sometimes can be very difficult. To help us fix your Nissan right the first time, please take a moment to note the area of the vehicle where the squeak or rattle occurs and under what conditions. You may be asked to take a test drive with a service advisor or technician to ensure we confirm the noise you are hearing.

I. WHERE DOES THE NOISE COME FROM? (circle the area of the vehicle)

The illustrations are for reference only, and may not reflect the actual configuration of your vehicle.



Continue to page 2 of the worksheet and briefly describe the location of the noise or rattle. In addition, please indicate the conditions which are present when the noise occurs.

PIIB8740E

SQUEAK AND RATTLE TROUBLE DIAGNOSES

< SYMPTOM DIAGNOSIS >

SQUEAK & RATTLE DIAGNOSTIC WORKSHEET - page 2

Briefly describe the location where the noise occurs:

II. WHEN DOES IT OCCUR? (please check the boxes that apply)

- | | |
|---|--|
| <input type="checkbox"/> anytime | <input type="checkbox"/> after sitting out in the rain |
| <input type="checkbox"/> 1st time in the morning | <input type="checkbox"/> when it is raining or wet |
| <input type="checkbox"/> only when it is cold outside | <input type="checkbox"/> dry or dusty conditions |
| <input type="checkbox"/> only when it is hot outside | <input type="checkbox"/> other: |

III. WHEN DRIVING:

- through driveways
- over rough roads
- over speed bumps
- only about ____ mph
- on acceleration
- coming to a stop
- on turns: left, right or either (circle)
- with passengers or cargo
- other: _____
- after driving ____ miles or ____ minutes

IV. WHAT TYPE OF NOISE

- squeak (like tennis shoes on a clean floor)
- creak (like walking on an old wooden floor)
- rattle (like shaking a baby rattle)
- knock (like a knock at the door)
- tick (like a clock second hand)
- thump (heavy, muffled knock noise)
- buzz (like a bumble bee)

TO BE COMPLETED BY DEALERSHIP PERSONNEL

Test Drive Notes:

| | YES | NO | Initials of person performing |
|--|--------------------------|--------------------------|-------------------------------|
| Vehicle test driven with customer | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise verified on test drive | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Noise source located and repaired | <input type="checkbox"/> | <input type="checkbox"/> | _____ |
| - Follow up test drive performed to confirm repair | <input type="checkbox"/> | <input type="checkbox"/> | _____ |

VIN: _____ Customer Name: _____
W.O.# _____ Date: _____

This form must be attached to Work Order

PIIB8742E

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

HOOD


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

HOOD

Exploded View

INFOID:000000009649420



- | | | |
|-------------------|-----------------------|---------------------|
| 1. Hood assembly | 2. Radiator core seal | 3. Hood seal |
| 4. Grommet | 5. Clamp | 6. Hood support rod |
| 7. Hood insulator | 8. Bumper rubber | 9. Hood hinge |

○ : Clip

▣ : Body grease

HOOD ASSEMBLY

HOOD ASSEMBLY : Removal and Installation

INFOID:000000009649421

CAUTION:

- Operate with two workers, because of its heavy weight.
- Use protective tape or shop cloth to protect from damage during removal and installation.

REMOVAL

1. Support hood assembly with the proper material to prevent it from falling.

WARNING:

Injury may occur if hood assembly is not supported with appropriate material when removing hood assembly.

2. Remove hood hinge mounting nuts on the hood to remove the hood assembly.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Before installing the hood hinge, apply anticorrosive agent onto the mounting surface of the vehicle body.


HOOD

< REMOVAL AND INSTALLATION >

- After installing, perform hood fitting adjustment. Refer to [DLK-425, "HOOD ASSEMBLY : Adjustment"](#).

HOOD ASSEMBLY : Adjustment

INFOID:000000009649422



- | | | |
|-----------------------|------------------|---------------------------|
| 1. Hood assembly | 2. Bumper rubber | 3. Hood hinge |
| 4. Hood lock assembly | 5. Front grille | 6. Front combination lamp |
| 7. Front fender | | |

: N-m (kg-m, ft-lb)

: Body grease

Check the clearance and the surface height between hood and each part by visually and touching. If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

HOOD

< REMOVAL AND INSTALLATION >

| Portion | | | | Standard | Difference (RH/LH, MAX) |
|-------------------------------|-------|---|----------------|---|-------------------------|
| Hood – Front grille | A – A | E | Clearance | 4.0 – 8.5 mm (0.157 – 0.335 in) | — |
| Hood – Front combination lamp | B – B | F | Clearance | 3.7 – 8.3 mm (0.146 – 0.327 in) | 3.0 mm (0.118 in) |
| | | G | Surface height | (–1.7) –(+3.7) mm [(–0.067) – (+0.146) in] | 3.0 mm (0.118 in) |
| Hood – Front fender | C – C | H | Surface height | (–1.0) – (+1.0) mm [(–0.039) – (+0.039) in] | 1.5 mm (0.059 in) |
| | | I | Clearance | 2.7 – 4.7 mm (0.106 – 0.185 in) | 1.5 mm (0.059 in) |
| Hood – Front fender | D – D | J | Clearance | 3.1 – 5.1 mm (0.122 – 0.201 in) | 1.5 mm (0.059 in) |
| | | K | Surface height | (–1.0) – (+1.0) mm [(–0.039) – (+0.039) in] | — |

FITTING ADJUSTMENT PROCEDURE

1. Remove front grille. Refer to [EXT-18, "Removal and Installation"](#).
2. Remove hood lock assembly.
3. Temporarily install front grille, and then adjust the surface height of hood assembly, front fender assembly, and front combination lamp according to the specified value, by rotating hood bumper rubber.
4. Remove front grille.
5. Position hood lock assembly and engage hood striker. Check hood lock assembly and hood striker for looseness.
6. Move hood lock assembly laterally until the center of hood striker and hood lock assembly are vertical when viewed from the front.
7. After adjustment, tighten lock bolts to the specified torque.
8. Check that secondary latch is securely engaged with secondary striker from the dead load of the hood assembly.
9. Check that primary latch is securely engaged with primary striker when hood assembly is closed [free-fall from approximately 200 mm (7.874 in) height].
CAUTION:
Never free-fall hood assembly from a height of 300 (11.811 in) mm or more.
10. Install front grille. Refer to [EXT-18, "Removal and Installation"](#).

HOOD HINGE

HOOD HINGE : Removal and Installation

INFOID:000000009649423

REMOVAL

1. Remove hood assembly. Refer to [DLK-424, "HOOD ASSEMBLY : Removal and Installation"](#).
2. Remove front fender. Refer to [DLK-430, "FRONT FENDER : Removal and Installation"](#).
3. Remove hood hinge mounting bolts, and then remove hood hinge.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:


- After installation, perform hood fitting adjustment. Refer to [DLK-425, "HOOD ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (the body color) onto the head of the hinge mounting bolts and nuts.

HOOD

< REMOVAL AND INSTALLATION >

- Check hood hinge rotating part for poor lubrication. If necessary, apply grease.

← : Grease up point



HOOD SUPPORT ROD

HOOD SUPPORT ROD : Removal and Installation

INFOID:000000009649424

REMOVAL

CAUTION:

Two workers are required to support the hood.

1. Support hood assembly with an appropriate material to prevent it from falling.

WARNING:

Injury may occur if hood assembly is not supported with appropriate material when removing hood assembly.

2. Pull hood support rod from grommet and remove.

INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >


RADIATOR CORE SUPPORT

Exploded View

INFOID:000000009649425



- 1. Radiator upper hose bracket
- 2. Air guide upper
- 3. Air guide side RH
- 4. Air guide side LH
- 5. Radiator core support

 : Pawl

Removal and Installation

INFOID:000000009649426


REMOVAL

1. Use a refrigerant collecting equipment to discharge the refrigerant. Refer to [HA-20, "Recycle Refrigerant"](#).
2. Remove engine under cover. Refer to [EXT-28, "Removal and Installation"](#).
3. Drain engine coolant from radiator. Refer to [CO-8, "Draining"](#).
4. Remove front grille. Refer to [EXT-18, "Removal and Installation"](#).
5. Remove front bumper fascia, energy absorber, bumper reinforcement. Refer to [EXT-12, "Removal and Installation"](#).
6. Remove front combination lamp LH and RH. Refer to [EXL-104, "Removal and Installation"](#) (XENON TYPE) or [EXL-214, "Removal and Installation"](#) (HALOGEN TYPE).
7. Remove air duct (inlet). Refer to [EM-26, "Removal and Installation"](#).
8. Remove air guide upper.
 - a. Remove exhaust gas/outside odor sensor. Refer to [HAC-149, "Removal and Installation"](#) (AUTOMATIC AIR CONDITIONING).

RADIATOR CORE SUPPORT

< REMOVAL AND INSTALLATION >

- b. Remove harness fixing clip (A).
- c. Remove fixing clips (B), and then remove air guide upper (1).



9. Remove hood lock assembly. Refer to [DLK-459. "HOOD LOCK : Removal and Installation"](#).
10. Disengage pawls, and then remove air guide side LH and RH.
11. Remove condenser. Refer to [HA-43. "CONDENSER : Removal and Installation"](#).
12. Remove ambient sensor. Refer to [HAC-145. "Removal and Installation"](#) (AUTOMATIC AIR CONDITIONING).
13. Remove reservoir tank, radiator hose (upper) and radiator pipe (upper). Refer to [CO-13. "Removal and Installation"](#).
14. Remove crash zone sensor. Refer to [SR-23. "Removal and Installation"](#).
15. Remove cooling fan assembly. Refer to [CO-17. "Removal and Installation"](#).
16. Remove radiator hose (lower), radiator pipe (lower) and radiator. Refer to [CO-13. "Removal and Installation"](#).
17. Remove all harness clips from radiator core support.
18. Remove mounting bolts, and then remove radiator core support.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

After installation, inspection and replenish the following.

- Refrigerant: Refer to [HA-20. "Charge Refrigerant"](#).
- Engine coolant: Refer to [CO-9. "Refilling"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


FRONT FENDER

< REMOVAL AND INSTALLATION >

FRONT FENDER

Exploded View

INFOID:000000009649427



- | | | |
|--------------------------|------------------------|---------------------------|
| 1. Hood side cover | 2. Front fender spacer | 3. Front fender stay |
| 4. Front fender assembly | 5. Front fender baffle | 6. Front fender stiffener |

○ : Clip

← : Vehicle front

FRONT FENDER

FRONT FENDER : Removal and Installation

INFOID:000000009649428


CAUTION:

Use a shop cloth to protect the body from being damaged during removal and installation.

REMOVAL

1. Remove front fender cover. Refer to [EXT-21, "Exploded View"](#).
2. Remove hood side cover. Refer to [DLK-431, "HOOD SIDE COVER : Removal and Installation"](#).
3. Remove front bumper fascia and bumper side bracket. Refer to [EXT-12, "Removal and Installation"](#).
4. Remove front combination lamp. Refer to [EXL-104, "Removal and Installation"](#) (XENON TYPE) or [EXL-214, "Removal and Installation"](#) (HALOGEN TYPE).
5. Remove fender protect molding. Refer to [EXT-24, "FENDER PROTECT MOLDING : Removal and Installation"](#).
6. Remove fender protector (front and rear). Refer to [EXT-23, "Removal and Installation"](#).
7. Remove front fender spacer and front fender baffle.
8. Remove mounting bolts of front fender assembly.
9. Remove front fender stiffener (2) from the vehicle body while carefully pulling upper portion of front fender (1) toward vehicle outside.

← : Vehicle front




FRONT FENDER


< REMOVAL AND INSTALLATION >

10. Move front fender (1) toward vehicle front, and then disengage clip (2).

CAUTION:

Apply protective tape (A) on the hood and front fender to protect the painted surface from damage.

 : Clip



11. Remove front fender assembly.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- After installation, apply the touch-up paint (the body color) onto the head of front fender mounting bolts.
- After installation, adjust the following part.
 - Hood assembly: Refer to [DLK-425, "HOOD ASSEMBLY : Adjustment"](#).
 - Front door: Refer to [DLK-434, "DOOR ASSEMBLY : Adjustment"](#).

HOOD SIDE COVER

HOOD SIDE COVER : Removal and Installation

INFOID:000000009649429

REMOVAL

1. Disconnect end of hood side cover from front combination lamp.
2. Remove fixing clips, and then remove hood side cover.

INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


FRONT DOOR

< REMOVAL AND INSTALLATION >

FRONT DOOR

Exploded View

INFOID:000000009649430



- | | | |
|--------------------------------|--------------------|-----------------------|
| 1. Front door panel | 2. TORX bolt | 3. Door striker |
| 4. Front door sash inner cover | 5. Grommet | 6. Bumper rubber |
| 7. Hole cover | 8. Door check link | 9. Door hinge (lower) |
| 10. Door hinge (upper) | | |

⊗ : Always replace after every disassembly.

⊙ : N·m (kg·m, in·lb)

⊙ : N·m (kg·m, ft·lb)

⊙ : Body grease

DOOR ASSEMBLY

DOOR ASSEMBLY : Removal and Installation

INFOID:000000009649431

WARNING:

Before servicing, turn ignition switch OFF, disconnect battery negative terminal and wait 3 minutes or more.

CAUTION:

- Perform work with 2 workers, because of its heavy weight.
- When removing and installing front door assembly, support door with a jack and shop cloth to protect door and body.


REMOVAL

1. Remove front door protect molding. Refer to [EXT-25, "FRONT DOOR PROTECT MOLDING : Removal and Installation"](#).

FRONT DOOR

< REMOVAL AND INSTALLATION >

2. Disconnect front door harness connector.



3. Remove mounting bolt of door check link on the vehicle.
4. Remove door hinge mounting nuts (door side), and then remove door assembly.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- Check front door open/close, lock/unlock operation after installation.
- After installation, perform the fitting adjustment. Refer to [DLK-434, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (the body color) onto the head of door hinge mounting nuts.
- Check door hinge rotating part for poor lubrication. If necessary, apply body grease.
- If malfunction is detected by the air bag warning lamp, after repair or replacement of the malfunctioning parts, reset the memory using self-diagnosis or CONSULT. Refer to [SRC-15, "On Board Diagnosis Function"](#) or [SRC-19, "CONSULT Function"](#).
- After the work is completed, check that no system malfunction is detected by air bag warning lamp.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

FRONT DOOR

< REMOVAL AND INSTALLATION >

DOOR ASSEMBLY : Adjustment

INFOID:000000009649432



- 1. Front fender
- 2. Front door
- 3. Slide door
- 4. Front door hinge (upper)
- 5. Front door hinge (lower)
- 6. Door striker
- 7. TORX bolt

⊗ : Always replace after every disassembly.

Ⓜ : N-m (kg-m, ft-lb)

🛠 : Body grease

Check the clearance and the surface height between front door and each part by visually and touching. If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

| Portion | | Standard |
|---------------------------|-------|---|
| Front fender – Front door | A – A | Clearance 3.5 – 5.5 mm (0.138 – 0.217 in) |
| | | Surface height (-1.0) – (+1.0) mm [(-0.039) – (+0.039) in] |

FRONT DOOR

< REMOVAL AND INSTALLATION >

| Portion | | Standard |
|-------------------------|-------|---|
| Front door – Slide door | B – B | Clearance 3.5 – 5.5 mm (0.138 – 0.217 in) |
| | | Surface height (-1.0) – (+1.0) mm [(-0.039) – (+0.039) in] |

FITTING ADJUSTMENT PROCEDURE

1. Remove front fender. Refer to [DLK-430, "FRONT FENDER : Removal and Installation"](#).
2. Loosen door hinge mounting nuts on door side.
3. Adjust the surface height of front door according to the fitting standard dimension.
4. Temporarily tighten door hinge mounting nuts on door side.
5. Loosen door hinge mounting bolts on body side.
6. Raise front door at rear end to adjust clearance of the front door according to the fitting standard dimension.
7. After adjustment tighten bolts and nuts to the specified torque.
CAUTION:
 - After installation, apply touch-up paint (the body color) onto the head of hinge mounting bolts and nuts.
 - Check door hinge rotating part for poor lubrication. If necessary, apply body grease.
8. Install front fender. Refer to refer to [DLK-430, "FRONT FENDER : Removal and Installation"](#).

DOOR STRIKER ADJUSTMENT

Adjust door striker so that it becomes parallel with door lock insertion direction.

DOOR STRIKER

DOOR STRIKER : Removal and Installation

INFOID:000000009649433

REMOVAL

Remove TORX bolts, and then remove door striker.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Check front door open/close, operation after installation.
- After installation, be sure to perform the fitting adjustment. Refer to [DLK-434, "DOOR ASSEMBLY : Adjustment"](#).

DOOR HINGE

DOOR HINGE : Removal and Installation

INFOID:000000009649434

REMOVAL

WARNING:

Before servicing, turn ignition switch OFF, disconnect battery negative terminal and wait 3 minutes or more.

CAUTION:

- Perform work with 2 workers, because of its heavy weight.
- When removing and installing front door assembly, support door with a jack and shop cloth to protect door and body.

1. Remove front fender. Refer to [DLK-430, "FRONT FENDER : Removal and Installation"](#).
2. Remove front door assembly. Refer to [DLK-432, "DOOR ASSEMBLY : Removal and Installation"](#).
3. Remove front door hinge mounting bolts (body side), and then remove front door hinge.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:


- Apply anticorrosive agent onto the mounting surface.
- Check front door open/close, lock/unlock operation after installation.

FRONT DOOR

< REMOVAL AND INSTALLATION >

- After installation, perform the fitting adjustment. Refer to [DLK-434, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (the body color) onto the head of door hinge mounting nuts.
- Check door hinge rotating part for poor lubrication. If necessary, apply body grease.

← : Grease up point



- If malfunction is detected by the air bag warning lamp, after repair or replacement of the malfunctioning parts, reset the memory using self-diagnosis or CONSULT. Refer to [SRC-15, "On Board Diagnosis Function"](#) or [SRC-19, "CONSULT Function"](#).
- After the work is completed, check that no system malfunction is detected by air bag warning lamp.


DOOR CHECK LINK

DOOR CHECK LINK : Removal and Installation

INFOID:000000009649435

REMOVAL

1. Fully close the front door window.
2. Remove front door finisher. Refer to [INT-14, "Removal and Installation"](#).
3. Remove bracket mounting bolts of front door speaker.
4. Remove front door speaker and bracket as a set, and move them aside.
5. Remove mounting bolt of door check link on the vehicle.
6. Remove mounting nuts of door check link on door panel.
7. Take door check link (1) out from the hole of door panel (2).




INSTALLATION

Note the following items, and install in the reverse order of removal.

CAUTION:

- Check front door open/close operation after installation.
- Check door check link rotating part for poor lubrication. If necessary, apply grease.

← : Grease up point




SLIDE DOOR

< REMOVAL AND INSTALLATION >

SLIDE DOOR

Exploded View

INFOID:000000009649436



- | | | |
|------------------------------------|------------------------------|---|
| 1. Slide door panel | 2. Bumper rubber | 3. Grommet |
| 4. TORX bolt | 5. Door striker (front) | 6. Touch sensor (automatic sliding door models) |
| 7. Dovetail (female) | 8. Dovetail (male) | 9. Lower latch |
| 10. Lower roller | 11. Slide door lower stopper | 12. Slide door lower striker |
| 13. Slide door lower weather-strip | 14. Screw grommet | 15. Rear roller |
| 16. Roller | 17. TORX bolt | 18. Slide door outside protector |
| 19. Door striker (rear) | 20. Stopper rubber | 21. Upper roller assembly |
| 22. Sub roller | 23. Slide door upper stopper | |

A : To slide door lower rail

B : To body outer panel

C : Slide door upper rail

A

B

C

D

E

F

G

H

I

J

DLK

L

M


N


O


P

SLIDE DOOR

< REMOVAL AND INSTALLATION >

 : Clip

 : Always replace after every disassembly.

 : N·m (kg-m, in-lb)

DOOR ASSEMBLY

DOOR ASSEMBLY : Removal and Installation

INFOID:000000009649437


CAUTION:

- Perform work with 2 workers, because of its heavy weight.
- When removing and installing slide door assembly, support door with a jack and shop cloth to protect door and body.

REMOVAL


1. Remove slide door protect molding. Refer to [EXT-26. "SLIDE DOOR PROTECT MOLDING : Removal and Installation"](#).
2. Remove slide door finisher. Refer to [INT-17. "Removal and Installation"](#).
3. Remove lower latch. Refer to [DLK-443. "LOWER LATCH : Removal and Installation"](#).
4. Disconnect uninterruptible power supply harness from slide door panel.
- a. Disconnect harness connector (1).

 : Vehicle front




- b. Remove harness connectors (1) from harness connector bracket (2).

 : Vehicle front



- c. Remove mounting bolts (A), and then remove uninterruptible power supply harness (1) from slide door panel (2).

 : Vehicle front



5. Remove upper roller assembly mounting bolts. Refer to [DLK-441. "UPPER ROLLER : Removal and Installation"](#).
6. Remove rear roller mounting bolts. Refer to [DLK-442. "REAR ROLLER : Removal and Installation"](#).

SLIDE DOOR

< REMOVAL AND INSTALLATION >

7. Remove lower roller mounting bolts. Refer to [DLK-442. "LOWER ROLLER : Removal and Installation"](#).
8. Remove slide door assembly.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- Check slide door open/close, lock/unlock operation after installation.
- After installation, perform the fitting adjustment. Refer to [DLK-440. "DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (the body color) onto the head of slide door roller mounting bolts.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

SLIDE DOOR


< REMOVAL AND INSTALLATION >

DOOR ASSEMBLY : Adjustment

INFOID:000000009649438



- | | | |
|------------------------|--------------------------|-----------------|
| 1. Slide door | 2. Upper roller assembly | 3. Lower roller |
| 4. Rear roller | 5. Door striker (front) | 6. TORX bolt |
| 7. Door striker (rear) | 8. Body side outer | 9. Front door |
| 10. Body side outer | | |

 : N·m (kg·m, ft·lb)

Check the clearance and the surface height between slide door each part by visually and touching.
If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

SLIDE DOOR

< REMOVAL AND INSTALLATION >

| Portion | | | Standard |
|------------------------------|-------|---|---|
| Slide door – Body side outer | F – F | I | Clearance 5.1 – 7.1 mm (0.201 – 0.280 in) |
| | | J | Surface height (-1.0) – (+1.0) mm [(-0.039) – (+0.039) in] |
| Front door – Slide door | G – G | K | Surface height (-1.0) – (+1.0) mm [(-0.039) – (+0.039) in] |
| | | L | Clearance 3.5 – 6.5 mm (0.138 – 0.256 in) |
| Slide door – Body side outer | H – H | M | Surface height (-1.0) – (+1.0) mm [(-0.039) – (+0.039) in] |
| | | N | Clearance 3.3 – 6.3 mm (0.130 – 0.248 in) |

FITTING ADJUSTMENT PROCEDURE

Loosen the upper roller assembly, lower roller and rear roller mounting bolts, adjust the surface of slide door according to the fitting standard dimension.

DOOR STRIKER ADJUSTMENT

Adjust door striker so that it becomes parallel with door lock insertion direction.

CAUTION:

After installation, apply touch-up paint (the body color) onto the head of slide door roller mounting bolts.

DOOR STRIKER

DOOR STRIKER : Removal and Installation

INFOID:000000009649439

REMOVAL

Door striker (front)

Remove mounting TORX bolts, and then remove door striker (front).

Door striker (rear)


Remove mounting bolts, and then remove door striker (rear).

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- After installation, be sure to perform the fitting adjustment. Refer to [DLK-440, "DOOR ASSEMBLY : Adjustment"](#).
- After installation, check that the direction of arrows (A), as shown in the figure, faces toward passenger room.



Door striker (front)

Door striker (rear)

UPPER ROLLER

UPPER ROLLER : Removal and Installation

INFOID:000000009649440

CAUTION:

SLIDE DOOR

< REMOVAL AND INSTALLATION >

- Perform work with 2 workers, because of its heavy weight.
- When removing and installing slide door assembly, support door with a jack and shop cloth to protect door and body.

REMOVAL

1. Remove slide door upper stopper. Refer to [DLK-447. "SLIDE DOOR UPPER STOPPER : Removal and Installation"](#).

2. Support the front of slide door with the proper material to prevent it from falling.

WARNING:

Bodily injury may occur if no supporting jack is holding slide door open when removing upper roller assembly.

3. Remove upper roller assembly mounting bolts.
4. Remove upper roller assembly and sub roller as a set.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- Check slide door open/close operation after installation.
- When removing and installing slide door assembly, perform the fitting adjustment. Refer to [DLK-440. "DOOR ASSEMBLY : Adjustment"](#).
- After installing, apply the touch-up paint (the body color) onto the head of upper roller mounting bolts.

REAR ROLLER

REAR ROLLER : Removal and Installation

INFOID:000000009649441

CAUTION:

- Perform work with 2 workers, because of its heavy weight.
- When removing and installing slide door assembly, support door with a jack and shop cloth to protect door and body.

REMOVAL

1. Remove slide door rail cover. Refer to [EXT-43. "Removal and Installation"](#).

2. Support the end of slide door with the proper material to prevent it from falling.

WARNING:

Bodily injury may occur if no supporting jack is holding slide door open when removing rear roller.

3. Remove rear roller mounting bolts.
4. Disconnect cable holder of automatic sliding door unit (automatic sliding door models). Refer to [DLK-474. "AUTOMATIC SLIDING DOOR UNIT : Removal and Installation"](#).
5. Remove rear roller.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- Check slide door open/close operation after installation.
- When removing and installing slide door assembly, perform the fitting adjustment. Refer to [DLK-440. "DOOR ASSEMBLY : Adjustment"](#).
- After installing, apply the touch-up paint (the body color) onto the head of rear roller mounting bolts.

LOWER ROLLER

LOWER ROLLER : Removal and Installation

INFOID:000000009649442

CAUTION:

- Perform work with 2 workers, because of its heavy weight.
- When removing and installing slide door assembly, support door with a jack and shop cloth to protect door and body.

SLIDE DOOR

< REMOVAL AND INSTALLATION >

REMOVAL

1. Remove slide door finisher. Refer to [INT-17, "Removal and Installation"](#).
2. Remove lower latch. Refer to [DLK-443, "LOWER LATCH : Removal and Installation"](#).
3. Remove slide door lower striker. Refer to [DLK-446, "SLIDE DOOR LOWER STRIKER : Removal and Installation"](#).
4. Support the front of slide door with the proper material to prevent it from falling.

WARNING:

Bodily injury may occur if no supporting jack is holding slide door open when removing lower roller.

5. Remove the mounting bolts, and then remove the lower roller.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- Check slide door open/close operation after installation.
- When removing and installing slide door assembly, perform the fitting adjustment. Refer to [DLK-440, "DOOR ASSEMBLY : Adjustment"](#).
- After installing, apply the touch-up paint (the body color) onto the head of lower roller mounting bolts.

LOWER LATCH


LOWER LATCH : Removal and Installation

INFOID:000000009649443

REMOVAL

1. Remove rear kicking plate. Refer to [INT-22, "KICKING PLATE : Removal and Installation"](#).
2. Remove lower latch mounting bolts.
3. Disconnect remote control door lock cable (2) from lower latch (1).

← : Vehicle front



INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

After installation, check door open/close, lock/unlock operation.

DOVETAIL

DOVETAIL : Removal and Installation

INFOID:000000009649444

REMOVAL

Remove the mounting bolts, and then remove the dovetail (male/female).

INSTALLATION

Install in the reverse order of removal.


1. Install dovetail (male).
2. Temporarily tighten dovetail (female) mounting bolts.
3. Perform the fitting adjustment.
 - a. Open and close two or three times slide doors.
 - b. Open the slide door, and then tighten the dovetail (female) mounting bolts.

SLIDE DOOR

< REMOVAL AND INSTALLATION >

CAUTION:

After installation, check that the direction of arrows (A), as shown in the figure, faces toward passenger room.



Dovetail (female)

Dovetail (male)

BUMPER RUBBER


BUMPER RUBBER : Removal and Installation

INFOID:000000009649445

BUMPER RUBBER

Removal

Pull out bumper rubber forward while rotating it counterclockwise to remove.





Installation


Install in the reverse order of removal.

STOPPER RUBBER

Removal

Disengage pawl of stopper rubber to remove.

-  : Pawl
-  : Vehicle front



Installation

Install in the reverse order of removal.


BUMPER RUBBER (BODY UPPER PORTION AND SLIDE DOOR REAR LOWER PORTION)

Removal

SLIDE DOOR

< REMOVAL AND INSTALLATION >

Pull out and disengage bumper rubber to remove.



← : Vehicle front

CAUTION:

When installing, check that \triangle mark (C) on bumper rubber of body upper portion (A) and slide door rear lower portion (B) are visible to vehicle upper side.

Installation

Install in the reverse order of removal.

SLIDE DOOR LOWER WEATHER-STRIP

SLIDE DOOR LOWER WEATHER-STRIP : Removal and Installation

INFOID:000000009649446

REMOVAL


Remove fixing screws and clips, and then remove slide door lower weather-strip.

INSTALLATION


Note the following items, and then install in the reverse order of removal.

CAUTION:

- When installing, check that lip portion (A) of slide door lower weather-strip overlaps end of slide door panel (1).



- When installing, install mounting clips (A) and mounting screws (B) in numerical order as shown in the figure.



SLIDE DOOR OUTSIDE PROTECTOR

SLIDE DOOR OUTSIDE PROTECTOR : Removal and Installation

INFOID:000000009649447

REMOVAL

Remove slide door outside protector while peeling double-sided adhesive tape.

SLIDE DOOR

< REMOVAL AND INSTALLATION >


INSTALLATION

Install slide door panel (2) while checking the installation position of slide door outside protector (1).

- Align to vehicle vertical position mark (A).
- Align to vehicle longitudinal position mark (B).
- Align lower end of slide door outside protector to be parallel to lock opening portion.

NOTE:

When reusing slide door outside protector, remove double-sided adhesive tape from protector and slide door panel sides, clean the applied area of double-sided adhesive tape, and then install slide door outside protector to slide door panel using new double-sided adhesive tape.



Double-sided tape t: 1.2 mm (0.047 in)

SLIDE DOOR LOWER STRIKER


SLIDE DOOR LOWER STRIKER : Removal and Installation

INFOID:000000009649448

REMOVAL

1. Remove rear kicking plate and rear floor step assembly. Refer to [INT-22, "KICKING PLATE : Removal and Installation"](#) and [INT-20, "Exploded View"](#).
2. Disconnect uninterruptible power supply harness from slide door lower striker.
 - a. Disconnect harness connector (A).
 - b. Remove uninterruptible power supply harness mounting nut (B).

⇐ : Vehicle front



3. Remove mounting nuts, and then remove slide door lower striker.


INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

Fix rear end of slide door lower striker (1) to rear portion of slide door lower stopper (2).

⇐ : Vehicle front



SLIDE DOOR LOWER STOPPER

SLIDE DOOR LOWER STOPPER : Removal and Installation

INFOID:000000009649449

REMOVAL


1. Remove slide door lower striker. Refer to [DLK-446, "SLIDE DOOR LOWER STRIKER : Removal and Installation"](#).

SLIDE DOOR

< REMOVAL AND INSTALLATION >

2. Remove slide door lower stopper.

← : Vehicle front



INSTALLATION

Install in the reverse order of removal.

SLIDE DOOR UPPER STOPPER


SLIDE DOOR UPPER STOPPER : Removal and Installation

INFOID:000000009649450

REMOVAL

1. Slide the slide door upper stopper toward vehicle front.
2. Use a remover tool (A), and then remove slide door upper stopper.

← : Vehicle front



INSTALLATION

Install in the reverse order of removal.

TOUCH SENSOR


TOUCH SENSOR : Removal and Installation

INFOID:000000009649451

REMOVAL

1. Remove remote control assembly. Refer to [DLK-473. "REMOTE CONTROL ASSEMBLY : Removal and Installation"](#).
2. Remove front side of sealing screen.
NOTE:
Cut the butyl-tape so that some parts of the butyl-tape do not remain on the sealing screen, if the sealing screen is reused.
3. Disconnect touch sensor harness connector (1).

← : Vehicle front




SLIDE DOOR

< REMOVAL AND INSTALLATION >

4. Remove grommet (A), and then pull out harness from slide door panel (1).

← : Vehicle front



5. Remove mounting screws and mounting clips, and then pull touch sensor toward vehicle front to remove.

CAUTION:

Never hit or bend touch sensor strongly.

INSTALLATION

Note the following item, and install in the reverse order of removal.

CAUTION:

After installation, check that slide door is reversed normally.


SLIDE DOOR GUIDE RAIL

< REMOVAL AND INSTALLATION >


SLIDE DOOR GUIDE RAIL

Exploded View

INFOID:000000009649452



- | | | |
|--------------------------------|--------------------------------|-------------------------------|
| 1. Slide door upper guide rail | 2. Slide door lower guide rail | 3. Slide door lower striker |
| 4. Rear floor step assembly | 5. TORX bolt | 6. Slide door rear guide rail |
| 7. Slide door rail cover | | |

 : N-m (kg-m, in-lb)

SLIDE DOOR UPPER GUIDE RAIL

SLIDE DOOR UPPER GUIDE RAIL : Removal and Installation

INFOID:000000009649453

CAUTION:

- Perform work with 2 workers, because of its heavy weight.
- When removing and installing slide door assembly, support door with a jack and shop cloth to protect door and body.
- Perform the following procedures after replacing guide rail.
 - Paint rail the same color as the vehicle body.
 - Apply grease to the roller rotating portion.
 - Apply anti-corrosion treatment to installation surface between body panel and rail.
 - Adjust fitting of slide door after installation. Refer to [DLK-440, "DOOR ASSEMBLY : Adjustment"](#).

REMOVAL

1. Remove headlining. Refer to [INT-35, "Removal and Installation"](#).
2. Remove slide door assembly. Refer to [DLK-438, "DOOR ASSEMBLY : Removal and Installation"](#).
3. Remove slide door upper stopper. Refer to [DLK-447, "SLIDE DOOR UPPER STOPPER : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J

DLK

L
M
N
O
P

SLIDE DOOR GUIDE RAIL

< REMOVAL AND INSTALLATION >

4. Remove upper roller assembly and sub roller as a set. Refer to [DLK-441, "UPPER ROLLER : Removal and Installation"](#).
5. Remove mounting nuts, and then remove slide door upper guide rail.

INSTALLATION

Install in the reverse order of removal.

SLIDE DOOR REAR GUIDE RAIL

SLIDE DOOR REAR GUIDE RAIL : Removal and Installation

INFOID:000000009649454

CAUTION:

- Perform work with 2 workers, because of its heavy weight.
- When removing and installing slide door assembly, support door with a jack and shop cloth to protect door and body.
- Perform the following procedures after replacing guide rail.
 - Paint rail the same color as the vehicle body.
 - Apply anti-corrosion treatment to installation surface between body panel and rail.
 - Adjust fitting of slide door after installation. Refer to [DLK-440, "DOOR ASSEMBLY : Adjustment"](#).

REMOVAL

1. Remove slide door assembly. Refer to [DLK-438, "DOOR ASSEMBLY : Removal and Installation"](#).
2. Remove slide door rail cover. Refer to [EXT-43, "Removal and Installation"](#).
3. Remove rear roller. Refer to [DLK-442, "REAR ROLLER : Removal and Installation"](#).
4. Remove luggage side lower finisher. Refer to [INT-43, "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
5. Remove mounting TORX bolts and nuts, and then remove slide door rear guide rail.

INSTALLATION

Install in the reverse order of removal.

SLIDE DOOR LOWER GUIDE RAIL

SLIDE DOOR LOWER GUIDE RAIL : Removal and Installation

INFOID:000000009649455

CAUTION:

- Perform work with 2 workers, because of its heavy weight.
- When removing and installing slide door assembly, support door with a jack and shop cloth to protect door and body.
- Perform the following procedures after replacing guide rail.
 - Paint rail the same color as the vehicle body.
 - Apply anti-corrosion treatment to installation surface between body panel and rail.
 - Apply anti-corrosion treatment to each end of mounting nuts and stud bolts of rail.
 - Adjust fitting of slide door after installation. Refer to [DLK-440, "DOOR ASSEMBLY : Adjustment"](#).

REMOVAL

1. Remove slide door assembly. Refer to [DLK-438, "DOOR ASSEMBLY : Removal and Installation"](#).
2. Remove rear kicking plate. Refer to [INT-22, "KICKING PLATE : Removal and Installation"](#).
3. Remove mounting bolts, and then remove rear floor step assembly.
4. Remove slide door lower striker. Refer to [DLK-446, "SLIDE DOOR LOWER STRIKER : Removal and Installation"](#).
5. Remove slide door lower stopper. Refer to [DLK-446, "SLIDE DOOR LOWER STOPPER : Removal and Installation"](#).
6. Remove lower roller. Refer to [DLK-442, "LOWER ROLLER : Removal and Installation"](#).
7. Remove mounting nuts, and then remove slide door lower guide rail.

INSTALLATION

Install in the reverse order of removal.


BACK DOOR

< REMOVAL AND INSTALLATION >

BACK DOOR


Exploded View


INFOID:000000009649456



- | | | |
|----------------------------|--------------------|---------------------------|
| 1. Back door weather-strip | 2. Back door hinge | 3. Stud ball |
| 4. Bumper rubber | 5. Back door stay | 6. Back door stay bracket |
| 7. Back door striker | 8. Back door panel | 9. Back door damper |

- A. Center mark
B. Seam

 : N·m (kg·m, ft·lb)

 : Body grease

BACK DOOR ASSEMBLY

BACK DOOR ASSEMBLY : Removal and Installation

INFOID:000000009649457

CAUTION:

- Operate with two workers, because of its heavy weight.
- Use protective tape or cloth to protect from damage during remove and installation.

REMOVAL


1. Remove back door support rod (back door side). Refer to [DLK-477. "BACK DOOR SUPPORT ROD : Removal and Installation"](#) (automatic back door models).
2. Remove back pillar garnish LH and RH. Refer to [INT-27. "BACK PILLAR GARNISH : Removal and Installation"](#).

BACK DOOR

< REMOVAL AND INSTALLATION >


3. Disconnect harness connectors (1) and remove harness fixing clip (A).

⇐ : Vehicle front




4. Remove grommet (1), and then pull out harness from back main pillar (2).

⇐ : Vehicle front




5. Lower rear portion of headlining and secure work space.

- a. Remove rear pillar garnish LH and RH. Refer to [INT-27, "REAR PILLAR GARNISH : Removal and Installation"](#).
- b. Remove roof side garnish LH and RH. Refer to [INT-28, "ROOF SIDE GARNISH : Removal and Installation"](#).
- c. Remove upper side of back door weather-strip. Refer to [DLK-457, "BACK DOOR WEATHER-STRIP : Removal and Installation"](#).
- d. Remove second assist grips LH and RH, third assist grips LH and RH and third seat belt finisher LH and RH, and then remove rear portion of headlining. Refer to [INT-35, "Removal and Installation"](#).



6. Remove fixing clip (A), and then disconnect rear washer tube (1).

⇐ : Vehicle front




BACK DOOR

< REMOVAL AND INSTALLATION >

7. Remove grommet (1), and then pull out washer tube from roof panel (2).

⇐ : Vehicle front



8. Support back door lock with the proper material to prevent it from falling.

WARNING:

Body injury may occur if no supporting rod is holding the back door open when removing the back door stay.

9. Remove back door stay (back door side). Refer to [DLK-456, "BACK DOOR STAY : Removal and Installation"](#).
10. Remove back door hinge mounting nuts on back door and remove back door assembly.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- Check back door open/close, lock/unlock operation after installation.
- After installation, perform fitting adjustment. Refer to [DLK-454, "BACK DOOR ASSEMBLY : Adjustment"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

BACK DOOR

< REMOVAL AND INSTALLATION >

BACK DOOR ASSEMBLY : Adjustment

INFOID:00000009649458



- | | | |
|----------------------|------------------------|--------------------------|
| 1. Back door | 2. Back door hinge | 3. Back door striker |
| 4. TORX bolt | 5. Bumper rubber | 6. Roof panel |
| 7. Side window glass | 8. Back door glass | 9. Slide door rail cover |
| 10. Sight shield | 11. Rear bumper fascia | |

: Always replace after every disassembly.

: N·m (kg·m, ft·lb)

: Body grease

Check the clearance and the surface height between back door and each part by seeing and touching. If the clearance and the surface height are out of specification, adjust them according to the procedures shown below.

| Portion | | Standard | | Difference (RH/LH) |
|------------------------|-------|----------|----------------|---------------------------------|
| Back door – Roof panel | A – A | F | Clearance | 5.5 – 8.5 mm (0.217 – 0.335 in) |
| | | G | Surface height | 0.0 – 2.0 mm (0.000 – 0.079 in) |


BACK DOOR

< REMOVAL AND INSTALLATION >

| Portion | | | Standard | Difference (RH/LH) | |
|-------------------------------------|-------|---|----------------|---|-------------------|
| Back door glass – Side window glass | B – B | H | Surface height | (-1.6) – (+2.4) mm [(-0.063) – (+0.094) in] | 1.5 mm (0.059 in) |
| | | I | Clearance | 3.0 – 7.0 mm (0.118 – 0.276 in) | — |
| Back door – Slide door rail cover | C – C | J | Clearance | 4.0 – 8.0 mm (0.157 – 0.315 in) | — |
| | | K | Surface height | (-1.5) – (+1.5) mm [(-0.059) – (+0.059) in] | — |
| Back door – Sight shield | D – D | L | Clearance | 3.3 – 6.7 mm (0.130 – 0.264 in) | — |
| | | M | Surface height | (-1.7) – (+1.7) mm [(-0.067) – (+0.067) in] | — |
| Back door – Rear bumper fascia | E – E | N | Clearance | 6.0 – 10.0 mm (0.236 – 0.394 in) | — |

FITTING ADJUSTMENT PROCEDURE

- Loosen back door striker mounting bolts.
- Loosen back door hinge mounting nuts (back door side).
- Adjust back door using back door striker and back door hinge to the specified value, as shown in the following table.
- After adjustment tighten back door striker mounting bolts and back door hinge mounting nuts (back door side) to the specified torque.
- Viewing from vehicle upper, insert bumper rubber (1) into bumper rubber bracket (2) to the position of alignment mark (B).



CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- After installation, apply touch-up paint (the body color) onto the head of back door hinge mounting nuts.
- Adjust the following parts.
 - Rear view camera.
 - DISPLAY AUDIO: Refer to [AV-116. "Adjustment"](#).
 - BASE AUDIO WITH SEPARATE DISPLAY: Refer to [AV-267. "Adjustment"](#).
 - BOSE AUDIO WITHOUT NAVIGATION: Refer to [AV-426. "Adjustment"](#).
 - BOSE AUDIO WITH NAVIGATION: Refer to [AV-528. "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Work Procedure"](#).

BACK DOOR STRIKER ADJUSTMENT

Adjust back door striker so that it becomes parallel with back door lock insertion direction.

BACK DOOR STRIKER

BACK DOOR STRIKER : Removal and Installation

INFOID:000000009649459

REMOVAL

- Remove tailgate kicking plate. Refer to [INT-40. "TAILGATE KICKING PLATE : Removal and Installation"](#).
- Remove mounting TORX bolts, and then remove back door striker.

BACK DOOR

< REMOVAL AND INSTALLATION >

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Check back door open/close operation after installation.
- When removing and installing back door striker, check to perform the fitting adjustment. Refer to [DLK-454, "BACK DOOR ASSEMBLY : Adjustment"](#).

BACK DOOR HINGE

BACK DOOR HINGE : Removal and Installation

INFOID:000000009649460

CAUTION:

- Operate with two workers, because of its heavy weight.
- Use protective tape or cloth to protect from damage during remove and installation.

REMOVAL

1. Remove back door assembly. Refer to [DLK-451, "BACK DOOR ASSEMBLY : Removal and Installation"](#).
2. Remove back door hinge mounting nuts (body side), and then remove back door hinge.


INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Apply anticorrosive agent onto the mounting surface.
- Check back door open/close operation after installation.
- When removing and installing back door assembly, perform the fitting adjustment. Refer to [DLK-454, "BACK DOOR ASSEMBLY : Adjustment"](#).
- After installation, apply touch-up paint (the body color) onto the head of back door hinge mounting nuts.
- Check back door hinge rotating part for poor lubrication. If necessary, apply body grease.

← : Grease up point



BACK DOOR STAY

BACK DOOR STAY : Removal and Installation

INFOID:000000009649461

REMOVAL

1. Support back door lock with the proper material to prevent it from falling.

WARNING:

Body injury may occur if no supporting rod is holding the back door open when removing the back door stay.

2. Remove back door stay mounting bolts.

CAUTION:

Be careful not to damage painted surface.


BACK DOOR

< REMOVAL AND INSTALLATION >

- Remove the metal clip (3) located on the connection between the back door stay (1) and the stud ball (2) (body side) by using a flat-bladed screwdriver (A).

CAUTION:

Be careful not to damage painted surface.



- Remove back door stay.

INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

Check back door open/close operation after installation.


BACK DOOR STAY : Disposal

INFOID:000000009649462

- Fix back door stay (1) using a vise (C).
- Using hacksaw (A) slowly make 2 holes in the back door stay, in numerical order as shown in the figure.


CAUTION:

- When cutting a hole on back door stay, always cover a hacksaw using a shop cloth (B) to avoid scattering metal fragments or oil.
- Wear eye protection (safety glasses).
- Wear gloves.



A: 20 mm (0.787 in)

B: Cut at the groove.



BACK DOOR WEATHER-STRIP

BACK DOOR WEATHER-STRIP : Removal and Installation

INFOID:000000009649463

REMOVAL

- Remove back door support rod (back door side). Refer to [DLK-477, "BACK DOOR SUPPORT ROD : Removal and Installation"](#).
- Pull up and remove engagement with body from weather-strip joint.

CAUTION:

Never pull strongly on weather-strip.


INSTALLATION

- Working from the upper section, align weather-strip center mark with vehicle center position mark and install weather-strip onto the vehicle.

BACK DOOR

< REMOVAL AND INSTALLATION >

2. Align the connecting point (B) of weather-strip (2) to the center (A) of striker (1), and then install as shown in the figure.



3. Pull weather-strip gently to ensure that there is no loose section.

NOTE:

Check that weather-strip is fit tightly at each corner and tailgate kicking plate.

4. Install back door support rod (back door side). Refer to [DLK-477. "BACK DOOR SUPPORT ROD : Removal and Installation"](#).


HOOD LOCK

< REMOVAL AND INSTALLATION >

HOOD LOCK

Exploded View

INFOID:000000009649464



1. Hood lock assembly

2. Hood lock control cable

3. Hood lock control handle

○ : Clip

⊙ : N-m (kg-m, in-lb)

⊙ : N-m (kg-m, ft-lb)

⊙ : Body grease

HOOD LOCK

HOOD LOCK : Removal and Installation

INFOID:000000009649465

REMOVAL


1. Remove front grille. Refer to [EXT-18, "Removal and Installation"](#).
2. Remove mounting bolts, and then remove hood lock assembly (1).

NOTE:

Press the lever downward to avoid pin (A), then pull out hood lock assembly upward.

CAUTION:


Never bend hood lock control cable (2) strongly.



HOOD LOCK

< REMOVAL AND INSTALLATION >

3. Disconnect hood lock control cable (2) from hood lock assembly (1).



INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- After installation, perform hood fitting adjustment. Refer to [DLK-425, "HOOD ASSEMBLY : Adjustment"](#).
- After installation, perform hood lock control inspection. Refer to [DLK-461, "Inspection"](#).

HOOD LOCK CONTROL CABLE

HOOD LOCK CONTROL CABLE : Removal and Installation

INFOID:000000009649466

REMOVAL

1. Disconnect hood lock control cable from hood lock assembly. Refer to [DLK-459, "HOOD LOCK : Removal and Installation"](#).
2. Remove fender protector LH (front and rear). Refer to [EXT-23, "Removal and Installation"](#).
3. Remove hood lock cable fixing clips.
4. Disconnect hood lock control cable from hood lock control handle. Refer to [DLK-461, "HOOD LOCK CONTROL HANDLE : Removal and Installation"](#).
5. Remove grommet on the lower dash, and pull the hood lock control cable toward the passenger compartment.

CAUTION:


While pulling, never to damage (peeling) the outside of hood lock control cable.

INSTALLATION

Note the following items, and install in the reverse order of removal.

CAUTION:

- Never to bend cable too much, keeping the radius 100 mm (3.937 in) or more.
- Check that cable is not offset from the positioning grommet, and apply the sealant to the grommet (at * mark) properly.



- Check that hood lock control cable is properly engaged with hood lock.
- After installation, perform hood fitting adjustment. Refer to [DLK-425, "HOOD ASSEMBLY : Adjustment"](#).
- After installation, perform hood lock control inspection. Refer to [DLK-461, "Inspection"](#).

HOOD LOCK CONTROL HANDLE

HOOD LOCK


< REMOVAL AND INSTALLATION >

HOOD LOCK CONTROL HANDLE : Removal and Installation

INFOID:000000009649467

REMOVAL

1. Remove mounting bolts, and then hood lock control handle.
2. Remove fuel filler lid opener cable. Refer to [DLK-480, "FUEL FILLER OPENER CABLE : Removal and Installation"](#).
3. Remove hood lock control cable (2) from hood lock opener lever (1).



INSTALLATION

Note the following item, and install in the reverse order of removal.

CAUTION:


After installation, perform hood lock control inspection. Refer to [DLK-461, "Inspection"](#).

Inspection

INFOID:000000009649468

NOTE:

If the hood lock cable is bent or deformed, replace it.



1. Primary striker
2. Primary latch
3. Secondary latch
4. Secondary striker

1. Check that secondary latch (3) is securely engaged with secondary striker (4) from the dead load of the hood assembly.
2. Check that primary latch (2) is securely engaged with primary striker (1) when hood assembly is closed [free-fall from approximately 200 mm (7.874 in) height].

CAUTION:

Never free-fall hood assembly from a height of 300 (11.811 in) mm or more.


3. While operating the hood opener carefully, check that the front end of the hood is lifted by approximately 20 mm (0.787 in) (A). Also, check that the hood opener returns to the original position.
4. Check that secondary latch is properly engaged with secondary striker [6.8 mm (0.268 in)] (B).

HOOD LOCK

< REMOVAL AND INSTALLATION >

5. Check the hood lock lubrication condition. If necessary, apply body grease to hood lock.

← : Grease up point




FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >

FRONT DOOR LOCK

Exploded View

INFOID:000000009649469



- | | | |
|---|-----------------------|----------------------|
| 1. Door key cylinder assembly (driver side) | 2. Rear gasket | 3. TORX bolt |
| Outside handle escutcheon (passenger side) | | |
| 4. Key rod (driver side) | 5. Door lock assembly | 6. Inside handle cap |
| 7. Inside handle | 8. Front gasket | 9. Outside handle |
| 10. Outside handle bracket | | |

← : Vehicle front

⊗ : Always replace after every disassembly.

⊕ : N·m (kg·m, in·lb)

🔧 : Body grease

DOOR LOCK

DOOR LOCK : Removal and Installation

INFOID:000000009649470

REMOVAL

1. Remove outside handle and outside handle bracket. Refer to [DLK-464, "OUTSIDE HANDLE : Removal and Installation"](#).
2. Disconnect door lock actuator connector.
3. Remove door lock assembly TORX bolts, and then remove door lock assembly.

INSTALLATION

Note the following items, and install in the reverse order of removal.

CAUTION:

- Never reuse TORX bolt. Always replace it with a new one when it is removed.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P


DLK

FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >

- Check door open/close, lock/unlock operation after installation.
- Check door lock cable is properly engaged with outside handle bracket.
- Check door lock assembly for poor lubrication. Apply body grease to door lock if necessary.

← : Grease up point



INSIDE HANDLE

INSIDE HANDLE : Removal and Installation

INFOID:000000009649471

REMOVAL

1. Remove front door finisher. Refer to [INT-14, "Removal and Installation"](#).
2. Remove inside handle mounting screws, and then remove the inside handle.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Check door lock cables are properly engaged with inside handle.
- After installation, check door open/close, lock/unlock operation.

OUTSIDE HANDLE


OUTSIDE HANDLE : Removal and Installation

INFOID:000000009649472


REMOVAL

1. Remove module base. Refer to [GW-29, "Removal and Installation"](#).
2. Disconnect key rod from door lock assembly (driver side).
3. Remove door antenna harness connector fixing clip (1), and then disconnect harness connector (2).

⇐ : Vehicle front




4. Remove grommet (1) of door side. Loosen, through grommet hole, TORX bolt (2) that fixes door lock cylinder. (For passenger side, TORX bolt fixes outside handle escutcheon.)




FRONT DOOR LOCK

< REMOVAL AND INSTALLATION >

5. While pulling outside handle, remove door key cylinder assembly (driver side) or outside handle escutcheon (passenger side).




6. While pulling outside handle (1), slide toward rear of vehicle to remove outside handle.




7. Remove front gasket and rear gasket.
8. Peel hole cover (1) carefully, and then remove TORX bolt (2), which is fixing outside handle bracket, through hole.

CAUTION:

When affixing hole cover, if affixing force is insufficient, replace hole cover.



9. Slide outside handle bracket toward front of vehicle to remove.
10. Disconnect outside handle cable from outside handle bracket.



INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- When installing key rod, rotate key rod holder until a click is felt.
- Check door lock cable is properly engaged with outside handle bracket.
- After installation, check door open/close, lock/unlock operation.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


SLIDE DOOR LOCK

< REMOVAL AND INSTALLATION >

SLIDE DOOR LOCK

Exploded View

INFOID:00000009649473



- | | | |
|-------------------------------------|-------------------------------------|-------------------------------------|
| 1. Outside handle assembly | 2. Outside handle escutcheon | 3. TORX bolt |
| 4. Snap pin | 5. Inside handle | 6. Remote control door lock cable |
| 7. Slide door lock assembly (front) | 8. Slide door lock cover (front) | 9. Slide door lock release actuator |
| 10. Cable clip | 11. Slide door lock assembly (rear) | 12. Slide door lock cover (rear) |
| 13. Slide door lock cable (rear) | 14. Outside handle bracket | 15. Rear gasket |
| 16. Front gasket | 17. Slide door lock actuator | 18. Clip |
| 19. Remote control assembly | 20. Lock knob | 21. Outside handle cable |
| 22. Slide door lock cable (front) | 23. Slide door closure motor | 24. Automatic sliding door unit |

A : To lower latch

○ : Clip

← : Vehicle front

⊙ : N·m (kg-m, in-lb)

▭ : Body grease

CAUTION:

- Apply anticorrosive agent onto the mounting surface.

SLIDE DOOR LOCK

< REMOVAL AND INSTALLATION >

- During removal and installation, work so as not to bend the ends of the cable.
- After installation, check door open/close, lock/unlock operation.
- Check door lock assembly for poor lubrication. Apply body grease to door lock if necessary.

DOOR LOCK

DOOR LOCK : Removal and Installation


INFOID:000000009649474

SLIDE DOOR LOCK ASSEMBLY (FRONT)

Removal


1. Fully close the slide door glass.
2. Remove remote control assembly. Refer to [DLK-473. "REMOTE CONTROL ASSEMBLY : Removal and Installation"](#).
3. Remove lock release actuator. Refer to [DLK-474. "LOCK RELEASE ACTUATOR : Removal and Installation"](#).
4. Remove sealing screen.
NOTE:
Cut the butyl-tape so that some parts of the butyl-tape do not remain on the sealing screen, if the sealing screen is reused.
5. Remove cable fixing clip (A) of slide door lock cable (1).

← : Vehicle front



6. Remove mounting bolt, and then remove slide door lock assembly (front) and slide door lock cable (front) as a set.
7. Disconnect slide door lock cable (front) from slide door lock assembly (front).
 - a. Remove fixing screw, and then remove slide door lock cover (front)
 - b. Open cable mounting clip (A) of slide door lock assembly (front) (1).
 - c. Disconnect slide door lock cable (front) (2).

← : Vehicle front



Installation

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Always adjust cable when assembling slide door lock cable (front) to slide door lock assembly (front). Refer to [DLK-469. "DOOR LOCK : Inspection and Adjustment"](#).
- After installation, check door open/close, lock/unlock operation.

SLIDE DOOR LOCK ASSEMBLY (REAR)

Removal

1. Fully close the slide door glass.

SLIDE DOOR LOCK

< REMOVAL AND INSTALLATION >

2. Remove remote control assembly. Refer to [DLK-473. "REMOTE CONTROL ASSEMBLY : Removal and Installation"](#).
3. Remove lock release actuator. Refer to [DLK-474. "LOCK RELEASE ACTUATOR : Removal and Installation"](#).


4. Remove sealing screen.

NOTE:

Cut the butyl-tape so that some parts of the butyl-tape do not remain on the sealing screen, if the sealing screen is reused.


5. Remove harness connector fixing clip (A), and then disconnect slide door lock assembly harness connector (1).

⇐ : Vehicle front




6. Remove cable fixing clip (A)
7. Disengage slide door lock cable (rear) (1) from cable clip (B).

⇐ : Vehicle front



8. Remove door lower sash (rear) of slide door glass. Refer to [GW-32. "Exploded View"](#).
9. Remove mounting bolt, and then remove slide door lock assembly (rear) and slide door lock cable (rear) as a set.
 - a. Remove slide door lock (rear) mounting bolts.
 - b. Remove slide door lock (rear) (2) from reinforcement (1) of slide door panel



⇐ : Vehicle front


10. Disconnect slide door lock cable (rear) from slide door lock assembly (rear).
 - a. Remove fixing screw, and then remove slide door lock cover (rear)

SLIDE DOOR LOCK

< REMOVAL AND INSTALLATION >

- b. Open cable mounting clip (A) of slide door lock assembly (rear) (1).
- c. Disconnect slide door lock cable (rear) (2).

← : Vehicle front



11. Remove slide door closure motor from slide door lock assembly (rear).
 - a. Disconnect harness connector of slide door closure motor.
 - b. Remove mounting molts, and then slide door closure motor.

Installation

Note the following items, and then install in the reverse order of removal.

CAUTION:


- Always adjust cable when assembling slide door lock cable (rear) to slide door lock assembly (rear). Refer to [DLK-469, "DOOR LOCK : Inspection and Adjustment"](#).
- After installation, check door open/close, lock/unlock operation.

DOOR LOCK : Inspection and Adjustment


INFOID:000000009649475

ADJUSTMENT OF SLIDE DOOR LOCK CABLE (FRONT)

1. Temporarily install slide door lock cable (front) to slide door lock assembly (front).
2. Set claw (1) of slide door lock assembly (front) to full latch status. (Press until it clicks.)



3. Pull lightly inner cable (1) of remote control assembly side in the direction indicated by arrow as shown in the figure so that play is eliminated. With play eliminated, adjust projection (A) by moving inner cable (2) of slide door lock assembly (front) side.




A : 45.8 – 47.2 mm (1.803 – 1.852 in)

SLIDE DOOR LOCK

< REMOVAL AND INSTALLATION >

- After the adjustment, close cable mounting clip (A) of slide door lock assembly (front) (1) and fix inner cable (2).




CAUTION:

Check the following items after assembling slide door lock assembly (front) to slide door panel.


- Check that there is no slack in remote control assembly and inner cable.
- Check that no pulling tension by inner cable is applied to lever of remote control assembly.

ADJUSTMENT OF SLIDE DOOR LOCK CABLE (REAR)

- Temporarily install slide door lock cable (rear) to slide door lock assembly (rear).
- Set claw (1) of slide door lock assembly (front) to full latch status. (Press until it clicks.)




- Pull lightly inner cable (1) of remote control assembly side in the direction indicated by arrow as shown in the figure so that play is eliminated. With play eliminated, adjust projection (A) by moving inner cable (2) of slide door lock assembly (rear) side.



A : 49.5 – 50.9 mm (1.949 – 2.004 in)

- After the adjustment, close cable mounting clip (A) of slide door lock assembly (front) (2) and fix inner cable (1).



CAUTION:

SLIDE DOOR LOCK

< REMOVAL AND INSTALLATION >

Check the following items after assembling slide door lock assembly (rear) to slide door panel.

- Check that there is no slack in remote control assembly and inner cable.
- Check that no pulling tension by inner cable is applied to lever of remote control assembly.


INSIDE HANDLE

INSIDE HANDLE : Removal and Installation

INFOID:000000009649476

REMOVAL

1. Hang snap pin (1) on hook and pick tool (A) and pull it up to remove.
2. Remove inside handle (2)



INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

After installation, check door open/close, lock/unlock operation.

OUTSIDE HANDLE

OUTSIDE HANDLE : Removal and Installation

INFOID:000000009649477


REMOVAL

1. Fully close slide door glass.
2. Remove remote control assembly. Refer to [DLK-473. "REMOTE CONTROL ASSEMBLY : Removal and Installation"](#).
3. Remove upper side of sealing screen.

NOTE:

Cut the butyl-tape so that some parts of the butyl-tape do not remain on the sealing screen, if the sealing screen is reused.

4. Remove fixing clip of sliding door one-touch open/close switch harness connector, and then disconnect sliding door one-touch open/close switch harness connector.
5. Remove grommet (1) door side. Loosen, through grommet hole, TORX bolt (2) that fixes outside handle escutcheon.




6. Remove outside handle escutcheon.

SLIDE DOOR LOCK


< REMOVAL AND INSTALLATION >

- a. Disconnect sliding door one-touch open/close switch harness connector (2) from outside handle bracket (1).


⇐ : Vehicle front




- b. While pulling outside handle (1), remove outside handle escutcheon (2).



7. While pulling outside handle (1), slide toward front of vehicle to remove outside handle.



8. Remove front gasket and rear gasket.
9. Through the hole, remove TORX bolt that is fixing outside handle bracket.
10. Slide outside handle bracket toward rear of vehicle to remove.
11. Disconnect outside handle cable from outside handle bracket.



INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

After installation, check door open/close, lock/unlock operation.

REMOTE CONTROL ASSEMBLY

SLIDE DOOR LOCK

< REMOVAL AND INSTALLATION >

REMOTE CONTROL ASSEMBLY : Removal and Installation


INFOID:000000009649478

REMOVAL

1. Remove slide door finisher. Refer to [INT-17. "Removal and Installation"](#).
2. Pull lock knob toward passenger room side and remove.
3. Disengage cable holder (A), and then separate lock release actuator cable (2), outside handle cable (3), slide door lock cable (rear) (4), slide door lock cable (front) (5) and lower latch cable (6) from remote control assembly (1).

CAUTION:

Be careful not to bend cable end.



⇐ : Vehicle front

4. Disconnect harness connector (8) and (9) (automatic sliding door models) of slide door lock actuator (7).
5. Disconnect remote control assembly harness connector (10) (automatic sliding door models).
6. Remove mounting bolts and mounting clips. Remove remote control assembly and slide door lock actuator as a set.

INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

After installation, check door open/close, lock/unlock operation.

LOCK RELEASE ACTUATOR

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

DLK

SLIDE DOOR LOCK

< REMOVAL AND INSTALLATION >


LOCK RELEASE ACTUATOR : Removal and Installation

INFOID:000000009649479


REMOVAL

1. Remove slide door finisher. Refer to [INT-17, "Removal and Installation"](#).
2. Disconnect cable of lock release actuator from remote control assembly. Refer to [DLK-473, "REMOTE CONTROL ASSEMBLY : Removal and Installation"](#).
3. Disengage lock release actuator cable (1) from cable clip (A).

↶ : Vehicle front



4. Disconnect harness connector (A) from lock release actuator (1).
5. Remove mounting bolts (B), and then remove lock release actuator



INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

After installation, check door open/close, lock/unlock operation.


AUTOMATIC SLIDING DOOR UNIT

AUTOMATIC SLIDING DOOR UNIT : Removal and Installation

INFOID:000000009649480

REMOVAL


1. Remove luggage side lower finisher. Refer to [INT-43, "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
2. Remove rear ventilator pillar duct. Refer to [VTL-8, "Exploded View"](#). (automatic sliding door unit RH only)
3. Separate rear roller from slide door assembly. Refer to [DLK-442, "REAR ROLLER : Removal and Installation"](#).
4. Disconnect cable holder of automatic sliding door unit from rear roller.
 - a. Disengage pawl (A) of cable holder (1), and then remove cable holder from rear roller (2).



SLIDE DOOR LOCK

< REMOVAL AND INSTALLATION >

- b. Remove cable holder (2) from cable (1) of automatic sliding door unit




5. Remove mounting nut (A) of front pulley (1), and then pull front side cable of automatic sliding door unit into the vehicle.

CAUTION:

Be careful not to damage body paint surface when pulling cable into the vehicle.

← : Vehicle front




6. Remove mounting nut (A) of rear pulley (1), and then pull front side cable of automatic sliding door unit into the vehicle.

CAUTION:

Be careful not to damage body paint surface when pulling cable into the vehicle.


← : Vehicle front



7. Disconnect harness connector (1) from automatic sliding door unit (2).

8. Remove mounting nuts (A), and then remove automatic sliding door unit.

← : Vehicle front



INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

After installation, check door open/close, lock/unlock operation.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P


BACK DOOR LOCK

< REMOVAL AND INSTALLATION >

BACK DOOR LOCK

Exploded View

INFOID:000000009649481



- | | | |
|------------------|----------------------------|---------------------------------------|
| 1. Stud ball | 2. Back door support rod | 3. Automatic back door control module |
| 4. Touch sensor | 5. Back door lock assembly | 6. Back door assembly |
| 7. Screw grommet | | |

: N·m (kg·m, in·lb)

: N·m (kg·m, ft·lb)

: Body grease

DOOR LOCK


DOOR LOCK : Removal and Installation

INFOID:000000009649482

REMOVAL

1. Remove back door lower finisher. Refer to [INT-48. "BACK DOOR LOWER FINISHER : Removal and Installation"](#).
2. Disconnect harness connector (1), and then remove harness fixing clip (A) and harness connector fixing clip.

: Vehicle front



BACK DOOR LOCK

< REMOVAL AND INSTALLATION >


3. Remove back door lock mounting bolts and nut, and then remove back door lock assembly.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- Check back door open/close, lock/unlock operation after installation.
- Check door lock assembly for poor lubrication. Apply body grease to door lock if necessary.



BACK DOOR SUPPORT ROD

BACK DOOR SUPPORT ROD : Removal and Installation

INFOID:000000009649483


REMOVAL

1. Remove stud ball (3) of back door support rod (2) from back door assembly (1).

CAUTION:

Apply protective tape (A) on the door panel to protect the painted surface from damage.

← : Vehicle front



2. Remove automatic back door control module. Refer to [DLK-495. "Removal and Installation"](#).

NOTE:

When replacing back door support rod, replace stud ball and automatic back door control module as a set, since back door support rod is engaged and connected to stud ball and automatic back door control module.

INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- When reusing stud ball, always apply locking sealant before installing stud ball to back door.
- Check back door open/close operation after installation.

TOUCH SENSOR

TOUCH SENSOR : Removal and Installation

INFOID:000000009649484

CAUTION:

Take care not to bend touch sensor.


REMOVAL

1. Remove back door lower finisher. Refer to [INT-48. "BACK DOOR LOWER FINISHER : Removal and Installation"](#).
2. Disconnect touch sensor harness connector.

BACK DOOR LOCK

< REMOVAL AND INSTALLATION >

↔ : Vehicle front



3. Remove fixing clips and screws of touch sensor.
4. Pull harness of touch sensor out of back door and remove touch sensor.


INSTALLATION

Note the following items, and then install in the reverse order of removal.

CAUTION:

- After installing touch sensor using fixing clips (A), tighten fixing screws in numerical order as shown in the figure.

↔ : Vehicle front



- Check back door open/close operation after installation.

EMERGENCY LEVER

EMERGENCY LEVER : Unlock procedures


INFOID:000000009649485

UNLOCK PROCEDURES

NOTE:

If back door lock cannot be unlocked due to a malfunction or battery discharge, follow the procedures to unlock back door.

1. Remove the emergency lid. Refer to [INT-50. "EMERGENCY LID : Removal and Installation"](#).
2. From inside the vehicle, rotate emergency lever toward lower direction and unlock.




FUEL FILLER LID OPENER

< REMOVAL AND INSTALLATION >

FUEL FILLER LID OPENER

Exploded View

INFOID:000000009649486



- 1. Fuel filler lid opener cable
- 2. TORX bolt
- 3. Fuel filler lid assembly
- 4. Bumper rubber
- 5. Fuel filler lid lock assembly

⊖ : Clip

△ : Pawl

⊖ : N·m (kg·m, in·lb)

CAUTION:

After installation, check fuel filler lid assembly open/close, lock/unlock operation.


FUEL FILLER LID

FUEL FILLER LID : Removal and Installation

INFOID:000000009649487

REMOVAL

1. Fully open fuel filler lid.
2. Remove fuel mounting pin (1).



A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

FUEL FILLER LID OPENER

< REMOVAL AND INSTALLATION >

3. Remove mounting screws, and then remove fuel filler lid.

INSTALLATION

Note the following item, and install in the reverse order of removal.

CAUTION:

After installation, check fuel filler lid assembly open/close, lock/unlock operation.

NOTE:

- The following table shows the specified values for checking normal installation status.
- Fitting adjustment cannot be performed.

| | Clearance | Evenness |
|-----------------------------------|---------------------------------|---|
| Fuel filler lid – Body side outer | 2.0 – 4.0 mm (0.079 – 0.157 in) | (-1.0) – (+1.0) mm [(-0.039) – (+0.039) in] |


FUEL FILLER OPENER CABLE

FUEL FILLER OPENER CABLE : Removal and Installation

INFOID:000000009649488

REMOVAL

1. Remove hood lock control handle from instrument lower panel LH. Refer to [DLK-461, "HOOD LOCK CONTROL HANDLE : Removal and Installation"](#).
2. Remove fuel filler lid opener cable (2) from fuel filler lid opener lever (1).



3. Remove front kicking plate LH and rear kicking plate LH. Refer to [INT-22, "KICKING PLATE : Removal and Installation"](#).
4. Remove dash side finisher LH. Refer to [INT-24, "DASH SIDE FINISHER : Removal and Installation"](#).
5. Remove center pillar lower garnish LH. Refer to [INT-25, "CENTER PILLAR LOWER GARNISH : Removal and Installation"](#).
6. Remove luggage side lower finisher LH. Refer to [INT-43, "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
7. Remove fuel filler lid opener cable from fuel filler lid lock assembly. Refer to [DLK-480, "FUEL FILLER LID LOCK : Removal and Installation"](#).
8. Remove fuel filler lid opener cable from each harness clamp of body harness.
9. Remove fuel filler lid opener cable fixing clips, and then remove fuel filler lid opener cable.

INSTALLATION

Note the following item, and install in the reverse order of removal.

CAUTION:

After installation, check fuel filler lid assembly open/close, lock/unlock operation.

FUEL FILLER LID LOCK

FUEL FILLER LID LOCK : Removal and Installation

INFOID:000000009649489

REMOVAL

1. Fully open fuel filler lid.
2. Remove luggage side lower finisher LH. Refer to [INT-43, "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).


FUEL FILLER LID OPENER

< REMOVAL AND INSTALLATION >


3. Rotate and disengage fuel filler lid lock assembly, and then remove fuel filler lid lock assembly.

NOTE:

Operation is performed easily when rotating fuel filler lid lock from passenger room side.



4. Disengage fuel filler lid opener cable (1). Remove fuel filler lid opener cable while pressing stopper pin (2).



INSTALLATION

Note the following item, and install in the reverse order of removal.

CAUTION:

After installation, check fuel filler lid assembly open/close, lock/unlock operation.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK


INTERLOCK

< REMOVAL AND INSTALLATION >

INTERLOCK

Exploded View

INFOID:000000009649490



1. Fuel filler inter lock assembly 2. Slide door inter lock

○ : Clip

⊙ : N·m (kg·m, ft·lb)

SLIDE DOOR INTERLOCK


SLIDE DOOR INTERLOCK : Removal and Installation

INFOID:000000009649491

REMOVAL

1. Remove rear floor step assembly. Refer to [INT-20, "Exploded View"](#).
2. Remove slide door interlock mounting nuts.
3. Disconnect cable (2) of fuel filler interlock assembly from slide door interlock (1).

⇐ : Vehicle front



INSTALLATION

Note the following items, and install in the reverse order of removal.

CAUTION:

- After installation, check slide door open/close operation.
- After installation, check fuel filler lid lock/unlock operation.

FUEL FILLER INTERLOCK

FUEL FILLER INTERLOCK : Removal and Installation

INFOID:000000009649492

REMOVAL


1. Remove slide door interlock. Refer to [DLK-482, "SLIDE DOOR INTERLOCK : Removal and Installation"](#).

INTERLOCK

< REMOVAL AND INSTALLATION >

2. Remove luggage side lower finisher. Refer to [INT-43, "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
3. Disconnect fuel filler lid status switch connector (1), and then remove harness connector fixing clip.

↶ : Vehicle front



4. Fully open fuel filler lid.
CAUTION:
Check in advance that fuel filler lid does not interfere with slide door.
5. Remove fuel filler interlock assembly mounting nut.
6. Remove cable fixing clips of fuel filler inter lock, and then remove fuel filler inter lock assembly.

INSTALLATION

Note the following items, and install in the reverse order of removal.

CAUTION:

- After installation, check slide door open/close operation.
- After installation, check fuel filler lid lock/unlock operation.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

KEY CYLINDER


< REMOVAL AND INSTALLATION >

KEY CYLINDER

GLOVE BOX LID KEY CYLINDER

GLOVE BOX LID KEY CYLINDER : Exploded View

INFOID:000000009649493



1. Glove box assembly

2. Sleeve

3. Glove box lid lock cylinder

CAUTION:


After installation, check glove box assembly open/close, lock/unlock operation.

GLOVE BOX LID KEY CYLINDER : Removal and Installation

INFOID:000000009649494

REMOVAL


1. Remove glove box assembly. Refer to [IP-14, "Removal and Installation"](#).
2. Insert mechanical key (1) into glove box lid lock cylinder (2).
3. Set glove box lid release handle (3) to the pulled-up status.
4. Rotate mechanical key and turn glove box lid key cylinder to the lock position.



5. Press tumbler stopper (1) into glove box lid lock cylinder (2) using a hook and pick tool (A), and then remove mechanical key (3) and glove box lid lock cylinder together from glove box lid release handle (4).

NOTE:

When removing glove box lid lock cylinder, write a short note describing its position against glove box lid release handle.



KEY CYLINDER

< REMOVAL AND INSTALLATION >


- Remove sleeve (3) from glove box lid release handle, and then install sleeve to glove box lid lock cylinder.

NOTE:

When removing sleeve, write a short note describing its position against glove box lid release handle.

CAUTION:

Never pull out mechanical key (1) from glove box lid lock cylinder (2) while sleeve is uninstalled. Otherwise, tumbler (4) pops out of glove box lid lock cylinder.



INSTALLATION

Note the following item, and then install in the reverse order of removal.

CAUTION:

After installation, check glove box assembly open/close, lock/unlock operation.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

DOOR SWITCH

< REMOVAL AND INSTALLATION >


DOOR SWITCH

Removal and Installation

INFOID:000000009649495

REMOVAL

Remove the TORX bolt (A), and then remove door switch (1).



INSTALLATION

Install in the reverse order of removal.

DOOR REQUEST SWITCH

< REMOVAL AND INSTALLATION >

DOOR REQUEST SWITCH

DRIVER SIDE

DRIVER SIDE : Removal and Installation

INFOID:000000009649496

REMOVAL

Remove the driver side outside handle. Refer to [DLK-464, "OUTSIDE HANDLE : Removal and Installation"](#).

INSTALLATION

Install in the reverse order of removal.

PASSENGER SIDE

PASSENGER SIDE : Removal and Installation

INFOID:000000009649497

REMOVAL

Remove the passenger side outside handle. Refer to [DLK-464, "OUTSIDE HANDLE : Removal and Installation"](#).

INSTALLATION

Install in the reverse order of removal.

BACK DOOR

BACK DOOR : Removal and Installation

INFOID:000000009649498

REMOVAL

Remove the back door finisher. Refer to [EXT-47, "Removal and Installation"](#).

INSTALLATION

Install in the reverse order of removal.

A

B

C

D

E

F

G

H

I

J

DLK

L

M

N

O

P

INSIDE KEY ANTENNA

< REMOVAL AND INSTALLATION >

INSIDE KEY ANTENNA INSTRUMENT CENTER

INSTRUMENT CENTER : Removal and Installation


INFOID:000000009649499

REMOVAL

1. Remove the instrument lower center panel. Refer to [JP-14, "Removal and Installation"](#).
2. Remove the inside key antenna (instrument center) mounting screw (A), and then remove inside key antenna (instrument center) (1).

CAUTION:

Be careful not to drop mounting screw (A) into instrument panel.



INSTALLATION

Install in the reverse order of removal.


CONSOLE

CONSOLE : Removal and Installation

INFOID:000000009649500

REMOVAL

1. Remove the console body assembly. Refer to [JP-28, "Removal and Installation"](#).
2. Remove the inside key antenna (console) mounting screw (A), and then remove inside key antenna (console) (1).



INSTALLATION

Install in the reverse order of removal.

LUGGAGE ROOM

LUGGAGE ROOM : Removal and Installation

INFOID:000000009649501


REMOVAL

1. Remove the rear floor carpet. Refer to [INT-31, "REAR FLOOR CARPET : Removal and Installation"](#).

INSIDE KEY ANTENNA

< REMOVAL AND INSTALLATION >

2. Remove the inside key antenna (luggage room) mounting screw (A), and then remove inside key antenna (luggage room) (1).



INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

OUTSIDE KEY ANTENNA

< REMOVAL AND INSTALLATION >

OUTSIDE KEY ANTENNA

DRIVER SIDE

DRIVER SIDE : Removal and Installation

INFOID:000000009649502

REMOVAL

Remove the driver side outside handle. Refer to [DLK-464, "OUTSIDE HANDLE : Removal and Installation"](#).

INSTALLATION

Install in the reverse order of removal.

PASSENGER SIDE

PASSENGER SIDE : Removal and Installation

INFOID:000000009649503

REMOVAL

Remove the passenger side outside handle. Refer to [DLK-464, "OUTSIDE HANDLE : Removal and Installation"](#).

INSTALLATION

Install in the reverse order of removal.


REAR BUMPER

REAR BUMPER : Removal and Installation

INFOID:000000009649504

REMOVAL

1. Remove the rear bumper fascia. Refer to [EXT-16, "REAR BUMPER : Removal and Installation"](#).
2. Remove the outside key antenna (rear bumper) mounting clip (A), then remove outside key antenna (rear bumper) (1).



INSTALLATION

Install in the reverse order of removal.

INTELLIGENT KEY WARNING BUZZER

< REMOVAL AND INSTALLATION >


INTELLIGENT KEY WARNING BUZZER

Removal and Installation

INFOID:000000009649505

REMOVAL

1. Remove the front bumper fascia. Refer to [EXT-12. "Removal and Installation"](#).
2. Remove the Intelligent Key warning buzzer mounting bolt (A), and then remove the Intelligent Key warning buzzer (1).



INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

REMOTE KEYLESS ENTRY RECEIVER

< REMOVAL AND INSTALLATION >


REMOTE KEYLESS ENTRY RECEIVER

Removal and Installation

INFOID:000000009649506

REMOVAL

1. Remove the glove box lid. Refer to [IP-14. "Removal and Installation"](#)
2. Remove the remote keyless entry receiver mounting bolt (A), and then remote keyless entry receiver (1).



INSTALLATION

Install in the reverse order of removal.

INTELLIGENT KEY BATTERY

< REMOVAL AND INSTALLATION >

INTELLIGENT KEY BATTERY

Removal and Installation


INFOID:000000009649507

1. Release the lock knob at the back of the Intelligent Key and remove the mechanical key.

2. Insert a remover tool (A) wrapped with a cloth into the slit of the corner and twist it to separate the upper part from the lower part.

CAUTION:

- Do not touch the circuit board or battery terminal.
- The key fob is water-resistant. However, if it does get wet, immediately wipe it dry.



3. Replace the battery with new one.


Battery replacement

**:Coin-type lithium battery
(CR2025)**

4. Align the tips of the upper and lower parts, and then push them together until it is securely closed.

CAUTION:

- When replacing battery, keep dirt, grease, and other foreign materials off the electrode contact area.
- After replacing the battery, check that all Intelligent Key functions work normally.



A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

BACK DOOR CONTROL UNIT

< REMOVAL AND INSTALLATION >


BACK DOOR CONTROL UNIT

Removal and Installation

INFOID:000000009649508

REMOVAL

1. Remove the back door lower finisher. Refer to [INT-48. "BACK DOOR LOWER FINISHER : Removal and Installation"](#).
2. Remove the back door control unit mounting bolt (A), and then remove the back door control unit (1).



INSTALLATION

Install in the reverse order of removal.

AUTOMATIC BACK DOOR CONTROL MODULE

< REMOVAL AND INSTALLATION >


AUTOMATIC BACK DOOR CONTROL MODULE

Removal and Installation

INFOID:000000009649509

REMOVAL

1. Remove the back pillar garnish LH. Refer to [INT-27. "BACK PILLAR GARNISH : Removal and Installation"](#).
2. Remove the back door support rod. Refer to [DLK-477. "BACK DOOR SUPPORT ROD : Removal and Installation"](#).
3. Remove the automatic back door control module mounting bolt (A), and then remove the automatic back door control module (1).



INSTALLATION

Install in the reverse order of removal.

NOTE:

After installing automatic back door control module, perform additional service when replace control unit. Refer to [DLK-169. "Work Procedure"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

AUTOMATIC BACK DOOR WARNING BUZZER

< REMOVAL AND INSTALLATION >


AUTOMATIC BACK DOOR WARNING BUZZER

Removal and Installation

INFOID:000000009649510

REMOVAL

1. Remove the rear bumper fascia. Refer to [EXT-16. "REAR BUMPER : Removal and Installation"](#).
2. Remove the automatic back door warning buzzer mounting bolt (A), and then remove the automatic back door warning buzzer (1).



JMKIA6046ZZ

INSTALLATION


Install in the reverse order of removal.

AUTOMATIC DOOR MAIN SWITCH

< REMOVAL AND INSTALLATION >

AUTOMATIC DOOR MAIN SWITCH

Exploded View



1. Instrument lower panel LH
2. Switch bracket lower
3. Automatic door main switch


Removal and Installation

INFOID:000000009649512

REMOVAL

1. Remove the instrument lower panel LH. Refer to [IP-14, "Removal and Installation"](#).
2. Removed automatic door main switch (1) from switch bracket lower (2) using remover tool (A).

 : Pawl



INSTALLATION

Install in the reverse order of removal.

AUTOMATIC BACK DOOR CLOSE SWITCH

< REMOVAL AND INSTALLATION >

AUTOMATIC BACK DOOR CLOSE SWITCH


Removal and Installation

INFOID:000000009649513

REMOVAL

1. Remove the automatic back door close switch finisher. Refer to [INT-48. "BACK DOOR LOWER FINISHER : Removal and Installation"](#).
2. Remove automatic back door close switch (1) from automatic back door close switch finisher (2) using remover tool (A).

 **Pawl**



INSTALLATION

Install in the reverse order of removal.


AUTOMATIC BACK DOOR SWITCH

< REMOVAL AND INSTALLATION >

AUTOMATIC BACK DOOR SWITCH

Exploded View

INFOID:000000009649514



1. Instrument lower panel LH
2. Switch bracket upper
3. Automatic door switch


Removal and Installation

INFOID:000000009649515

REMOVAL

1. Remove the instrument driver lower panel. Refer to [IP-14, "Removal and Installation"](#).
2. Remove automatic back door switch (1) from switch bracket (2) using remover tool (A).

 : Pawl



INSTALLATION

Install in the reverse order of removal.

SLIDING DOOR CONTROL UNIT

< REMOVAL AND INSTALLATION >

SLIDING DOOR CONTROL UNIT


RH

RH : Removal and Installation

INFOID:000000009649516

REMOVAL

1. Remove the luggage side lower finisher RH. Refer to [INT-43. "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
2. Remove the rear foot duct. Refer to [VTL-13. "REAR FOOT DUCT : Removal and Installation"](#).
3. Remove the sliding door control unit RH mounting bolt and nuts (A), and then remove the sliding door control unit RH (1).



INSTALLATION

Install in the reverse order of removal

NOTE:

After installing sliding door control unit, perform additional service when replace control unit. Refer to [DLK-170. "Work Procedure"](#).


LH

LH : Removal and Installation

INFOID:000000009649517

REMOVAL

1. Remove the luggage side lower finisher LH. Refer to [INT-43. "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
2. Remove the sliding door control unit LH mounting bolt and nuts (A), and then remove the sliding door control unit LH (1).



INSTALLATION

Install in the reverse order of removal

NOTE:

After installing sliding door control unit, perform additional service when replace control unit. Refer to [DLK-170. "Work Procedure"](#).

SLIDING DOOR OPEN/CLOSE SWITCH

< REMOVAL AND INSTALLATION >

SLIDING DOOR OPEN/CLOSE SWITCH


FRONT

FRONT : Removal and Installation

INFOID:000000009649518


REMOVAL

1. Remove the instrument finisher B. Refer to [JP-14. "Removal and Installation"](#).
2. Remove the switch bracket lower mounting screw (A), and then remove the switch bracket lower from instrument finisher B.



3. Remove the sliding door open/close switch (front side) (2) from switch bracket lower (1) using flat-head screw driver (A).

 : Pawl



INSTALLATION

Install in the reverse order of removal.


REAR

REAR : Removal and Installation

INFOID:000000009649519

REMOVAL

1. Remove the center pillar lower. Refer to [INT-25. "CENTER PILLAR LOWER GARNISH : Removal and Installation"](#).
2. Remove the sliding door open/close switch (rear side) mounting screw (A), and then remove the sliding door open/close switch (rear side).



INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
DLK
L
M
N
O
P

SLIDING DOOR LOCK ACTUATOR

< REMOVAL AND INSTALLATION >


SLIDING DOOR LOCK ACTUATOR

Removal and Installation

INFOID:000000009649520

REMOVAL

1. Remove the remote control assembly. Refer to [DLK-473, "REMOTE CONTROL ASSEMBLY : Removal and Installation"](#).
2. Remove the sliding door lock actuator mounting screw (A), and then remove the sliding door lock actuator (1) from remote control assembly (2).



INSTALLATION

Install in the reverse order of removal.

AUTOMATIC SLIDING DOOR WARNING BUZZER

< REMOVAL AND INSTALLATION >


AUTOMATIC SLIDING DOOR WARNING BUZZER

Removal and Installation

INFOID:000000009649521

REMOVAL

1. Remove the luggage side lower finisher. Refer to [INT-43. "LUGGAGE SIDE LOWER FINISHER : Removal and Installation"](#).
2. Remove automatic sliding door warning buzzer (1) from sliding door control unit (2).



INSTALLATION

Install in the reverse order of removal.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

DLK

SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

< REMOVAL AND INSTALLATION >

SLIDING DOOR ONE-TOUCH OPEN/CLOSE SWITCH

Removal and Installation

INFOID:000000009649522

REMOVAL

Remove outside handle escutcheon. Refer to [DLK-471, "OUTSIDE HANDLE : Removal and Installation"](#).

INSTALLATION

Install in the reverse order of removal.