

# STR

SECTION STR  
STARTING SYSTEM

## CONTENTS

|  |    |  |    |
|--|----|--|----|
| <b>PRECAUTION</b>  | 2  | <b>DIAGNOSIS AND REPAIR WORK FLOW</b>        | 10 |
| <b>PRECAUTIONS</b>   | 2  | Work Flow (With GR8-1200 NI)                 | 10 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 2  | Work Flow (Without GR8-1200 NI)              | 13 |
| Precaution for Procedure without Cowl Top Cover  | 2  |  |    |
| Precautions For Xenon Headlamp Service   | 2  |  |    |
| Precautions for Removing Battery Terminal  | 3  |  |    |
| Precautions When Battery Is Discharged   | 3  |  |    |
| <b>PREPARATION</b>   | 4  |  |    |
| <b>PREPARATION</b>   | 4  | <b>DTC/CIRCUIT DIAGNOSIS</b>                 | 15 |
| Special Service Tools  | 4  | <b>B TERMINAL CIRCUIT</b>                    | 15 |
| Commercial Service Tools   | 4  | Description                                  | 15 |
| <b>SYSTEM DESCRIPTION</b>  | 5  | Diagnosis Procedure                          | 15 |
| <b>COMPONENT PARTS</b>   | 5  | <b>S CONNECTOR CIRCUIT</b>                   | 16 |
| Component Parts Location   | 5  | Description                                  | 16 |
| <b>SYSTEM</b>  | 6  | Diagnosis Procedure                          | 16 |
| System Description   | 6  | <b>SYMPTOM DIAGNOSIS</b>                     | 17 |
| <b>WIRING DIAGRAM</b>  | 7  | <b>STARTING SYSTEM</b>                       | 17 |
| <b>STARTING SYSTEM</b>   | 7  | Symptom Table                                | 17 |
| Wiring Diagram   | 7  | <b>REMOVAL AND INSTALLATION</b>              | 18 |
| <b>BASIC INSPECTION</b>  | 10 | <b>STARTER MOTOR</b>                         | 18 |
|  |    | Exploded View                                | 18 |
|  |    | Removal and Installation                     | 18 |
|  |    | <b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> | 20 |
|  |    | <b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> | 20 |
|  |    | Starter Motor                                | 20 |

## PRECAUTIONS

< PRECAUTION >

# PRECAUTION

## PRECAUTIONS

### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:0000000011326155

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

### Precaution for Procedure without Cowl Top Cover

INFOID:0000000011552704

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



### Precautions For Xenon Headlamp Service

INFOID:0000000011552705

#### **WARNING:**

Comply with the following warnings to prevent any serious accident.

- Disconnect the battery cable (negative terminal) or the power supply fuse before installing, removing, or touching the xenon headlamp (bulb included). The xenon headlamp contains high-voltage generated parts.
- Never work with wet hands.
- Check the xenon headlamp ON-OFF status after assembling it to the vehicle. Never turn the xenon headlamp ON in other conditions. Connect the power supply to the vehicle-side connector.

# PRECAUTIONS

## < PRECAUTION >

A

(Turning it ON outside the lamp case may cause fire or visual impairments.)

- Never touch the bulb glass immediately after turning it OFF. It is extremely hot.

STR

### CAUTION:

C

Comply with the following cautions to prevent any error and malfunction.

D

- Install the xenon bulb securely. (Insufficient bulb socket installation may melt the bulb, the connector, the housing, etc. by high-voltage leakage or corona discharge.)
- Never perform HID circuit inspection with a tester.
- Never touch the xenon bulb glass with hands. Never put oil and grease on it.
- Dispose of the used xenon bulb after packing it in thick vinyl without breaking it.
- Never wipe out dirt and contamination with organic solvent (thinner, gasoline, etc.).

E

## Precautions for Removing Battery Terminal

F

INFOID:0000000011326156

G

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.

H

I

J

K

L

M

N

O

P

A

STR

C

D

E

F

G

H

I

J

K


L

M

N

O

P



SEF289H

### NOTE:

I

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

J

K

L

M

N

O

P

A

STR

C

D

E

F

G

H

I

J

K

L

M

N

O

P

### NOTE:

A

STR

C

D

E

F

G

H

I

J

K

L

M

N

O

P

## Precautions When Battery Is Discharged

A

INFOID:0000000011552717

When battery is discharged, disconnect the negative terminal of the battery and wait for 1 minute before connecting jumper cables to restart the engine. (This is necessary for resetting information in ECM.)

## PREPARATION


< PREPARATION >

# PREPARATION

## PREPARATION

### Special Service Tools

INFOID:0000000011326157

| Tool number<br>(TechMate No.)<br>Tool name   | Description  |
|--|--|
| —<br>— Model GR8-1200 NI<br>Multitasking battery and electrical diagnostic station | <br>AWIIA1239ZZ<br>Tests batteries, starting and charging systems and charges batteries.<br>For operating instructions, refer to diagnostic station instruction manual. |

### Commercial Service Tools

INFOID:0000000011326158

| Tool name  | Description   |
|------------|---|
| Power tool | <br>PIIB1407E<br>Loosening bolts, nuts and screws |

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:0000000011326159

STR



A. Engine room LH

| No. | Component part            | Description  |
|-----|---------------------------|--|
| 1.  | BCM                       | BCM controls the starter relay.<br>Refer to <a href="#">BCS-4. "BODY CONTROL SYSTEM : Component Parts Location".</a>   |
| 2.  | IPDM E/R                  | CPU inside IPDM E/R controls the starter control relay.<br>Refer to <a href="#">PCS-4. "IPDM E/R : Component Parts Location".</a>                                      |
| 3.  | Transmission range switch | When the selector lever is shifted to the "P" or "N" position, power is supplied to BCM and IPDM E/R (CPU) by transmission range switch.                               |
| 4.  | Starter motor             | The starter motor plunger closes and the motor is supplied with battery power, which in turn cranks the engine, when the "S" terminal is supplied with electric power. |

A

C

D

E

F

G

H

I

J

K

L

M

N

O

P

# SYSTEM


< SYSTEM DESCRIPTION >

## SYSTEM

### System Description

INFOID:0000000011326160

### SYSTEM DIAGRAM



JSBIA5905GB

### OUTLINE

- When selector lever is “P” or “N”, power is supplied to BCM and IPDM E/R (CPU) by transmission range switch. BCM and IPDM E/R (CPU) detect selector lever P/N condition by the inputted signal.
- When starter operating condition is satisfied, IPDM E/R turns starter control relay ON by starter control relay control signal.
- When engine cranking condition is satisfied, BCM turns starter relay ON by starter relay control signal.
- Then battery power is supplied to starter motor (“S” terminal) through starter control relay and starter relay.

# STARTING SYSTEM

< WIRING DIAGRAM >


## WIRING DIAGRAM STARTING SYSTEM

### Wiring Diagram

INFOID:0000000011326161

STR

### STARTING SYSTEM



2014/07/25


JRBWD0410GB

# STARTING SYSTEM

< WIRING DIAGRAM >

## STARTING SYSTEM

| Connector No.  | E10   |
|----------------|---|
| Connector Name | FORM-F INTELLIGENT POWER DISTRIBUTION MODULE ENGINE |
| Connector No.  | 15  |
| Connector Type | TH20FV-CS12-M4-1V                                   |



| Terminal No. | Signal Name [Specification] |
|--------------|-----------------------------|
| 4            | I.G                         |
| 5            | Y                           |
| 6            | G                           |
| 7            | B.R                         |
| 10           | P                           |
| 12           | B                           |
| 13           | O                           |
| 15           | L                           |
| 16           | R                           |
| 18           | P                           |
| 19           | V                           |
| 20           | W                           |
| 21           | O                           |
| 22           | S.B                         |
| 23           | G.R                         |
| 24           | G                           |
| 25           | G.R                         |
| 27           | B.R                         |
| 28           | G                           |
| 30           | L.G                         |
| 34           | O                           |
| 35           | P                           |
| 36           | G                           |
| 38           | G.R                         |



| Terminal No. | Signal Name [Specification] |
|--------------|-----------------------------|
| 1            | SHIELD                      |
| 2            | W                           |
| 3            | B                           |
| 4            | R                           |
| 6            | L.G                         |
| 7            | R                           |
| 8            | G.R                         |
| 9            | V                           |
| 10           | B.R                         |
| 11           | Y                           |
| 12           | O                           |



| Terminal No. | Signal Name [Specification] |
|--------------|-----------------------------|
| 13           | W                           |
| 14           | L                           |
| 15           | P                           |
| 32           | V                           |
| 37           | B.R                         |
| 38           | G                           |
| 39           | V                           |
| 40           | P                           |
| 41           | L                           |
| 42           | L.G                         |
| 43           | O                           |
| 45           | P                           |
| 46           | SB                          |
| 47           | Y                           |
| 48           | L                           |
| 51           | B.R                         |
| 52           | G                           |
| 53           | B                           |
| 54           | O                           |
| 55           | Y                           |
| 56           | SHIELD                      |
| 61           | P                           |
| 62           | G                           |
| 63           | W/L                         |
| 64           | W.R                         |
| 66           | W                           |
| 67           | Y                           |
| 69           | R                           |
| 71           | R                           |
| 72           | L                           |
| 74           | Y                           |
| 75           | SB                          |
| 76           | Y                           |
| 77           | G                           |
| 78           | O                           |
| 80           | R                           |
| 81           | L                           |
| 82           | L.G                         |
| 83           | R                           |



| Terminal No. | Signal Name [Specification] |
|--------------|-----------------------------|
| 13           | W                           |
| 14           | L                           |
| 15           | P                           |
| 32           | V                           |
| 37           | B.R                         |
| 38           | G                           |
| 39           | V                           |
| 40           | P                           |
| 41           | L                           |
| 42           | L.G                         |
| 43           | O                           |
| 45           | P                           |
| 46           | SB                          |
| 47           | Y                           |
| 48           | L                           |
| 51           | B.R                         |
| 52           | G                           |
| 53           | B                           |
| 54           | O                           |
| 55           | Y                           |
| 56           | SHIELD                      |
| 61           | P                           |
| 62           | G                           |
| 63           | W/L                         |
| 64           | W.R                         |
| 66           | W                           |
| 67           | Y                           |
| 69           | R                           |
| 71           | R                           |
| 72           | L                           |
| 74           | Y                           |
| 75           | SB                          |
| 76           | Y                           |
| 77           | G                           |
| 78           | O                           |
| 80           | R                           |
| 81           | L                           |
| 82           | L.G                         |
| 83           | R                           |



| Terminal No. | Signal Name [Specification] |
|--------------|-----------------------------|
| 13           | W                           |
| 14           | L                           |
| 15           | P                           |
| 32           | V                           |
| 37           | B.R                         |
| 38           | G                           |
| 39           | V                           |
| 40           | P                           |
| 41           | L                           |
| 42           | L.G                         |
| 43           | O                           |
| 45           | P                           |
| 46           | SB                          |
| 47           | Y                           |
| 48           | L                           |
| 51           | B.R                         |
| 52           | G                           |
| 53           | B                           |
| 54           | O                           |
| 55           | Y                           |
| 56           | SHIELD                      |
| 61           | P                           |
| 62           | G                           |
| 63           | W/L                         |
| 64           | W.R                         |
| 66           | W                           |
| 67           | Y                           |
| 69           | R                           |
| 71           | R                           |
| 72           | L                           |
| 74           | Y                           |
| 75           | SB                          |
| 76           | Y                           |
| 77           | G                           |
| 78           | O                           |
| 80           | R                           |
| 81           | L                           |
| 82           | L.G                         |
| 83           | R                           |



| Terminal No. | Signal Name [Specification] |
|--------------|-----------------------------|
| 13           | W                           |
| 14           | L                           |
| 15           | P                           |
| 32           | V                           |
| 37           | B.R                         |
| 38           | G                           |
| 39           | V                           |
| 40           | P                           |
| 41           | L                           |
| 42           | L.G                         |
| 43           | O                           |
| 45           | P                           |
| 46           | SB                          |
| 47           | Y                           |
| 48           | L                           |
| 51           | B.R                         |
| 52           | G                           |
| 53           | B                           |
| 54           | O                           |
| 55           | Y                           |
| 56           | SHIELD                      |
| 61           | P                           |
| 62           | G                           |
| 63           | W/L                         |
| 64           | W.R                         |
| 66           | W                           |
| 67           | Y                           |
| 69           | R                           |
| 71           | R                           |
| 72           | L                           |
| 74           | Y                           |
| 75           | SB                          |
| 76           | Y                           |
| 77           | G                           |
| 78           | O                           |
| 80           | R                           |
| 81           | L                           |
| 82           | L.G                         |
| 83           | R                           |



| Terminal No. | Signal Name [Specification] |
|--------------|-----------------------------|
| 13           | W                           |
| 14           | L                           |
| 15           | P                           |
| 32           | V                           |
| 37           | B.R                         |
| 38           | G                           |
| 39           | V                           |
| 40           | P                           |
| 41           | L                           |
| 42           | L.G                         |
| 43           | O                           |
| 45           | P                           |
| 46           | SB                          |
| 47           | Y                           |
| 48           | L                           |
| 51           | B.R                         |
| 52           | G                           |
| 53           | B                           |
| 54           | O                           |
| 55           | Y                           |
| 56           | SHIELD                      |
| 61           | P                           |
| 62           | G                           |
| 63           | W/L                         |
| 64           | W.R                         |
| 66           | W                           |
| 67           | Y                           |
| 69           | R                           |
| 71           | R                           |
| 72           | L                           |
| 74           | Y                           |
| 75           | SB                          |
| 76           | Y                           |
| 77           | G                           |
| 78           | O                           |
| 80           | R                           |
| 81           | L                           |
| 82           | L.G                         |
| 83           | R                           |



| Terminal No. | Signal Name [Specification] |
|--------------|-----------------------------|
| 13           | W                           |
| 14           | L                           |
| 15           | P                           |
| 32           | V                           |
| 37           | B.R                         |
| 38           | G                           |
| 39           | V                           |
| 40           | P                           |
| 41           | L                           |
| 42           | L.G                         |
| 43           | O                           |
| 45           | P                           |
| 46           | SB                          |
| 47           | Y                           |
| 48           | L                           |
| 51           | B.R                         |
| 52           | G                           |
| 53           | B                           |
| 54           | O                           |
| 55           | Y                           |
| 56           | SHIELD                      |
| 61           | P                           |
| 62           | G                           |
| 63           | W/L                         |
| 64           | W.R                         |
| 66           | W                           |
| 67           | Y                           |
| 69           | R                           |
| 71           | R                           |
| 72           | L                           |
| 74           | Y                           |
| 75           | SB                          |
| 76           | Y                           |
| 77           | G                           |
| 78           | O                           |
| 80           | R                           |
| 81           | L                           |
| 82           | L.G                         |
| 83           | R                           |



| Terminal No. | Signal Name [Specification] |
|--------------|-----------------------------|
| 13           | W                           |
| 14           | L                           |
| 15           | P                           |
| 32           | V                           |
| 37           | B.R                         |
| 38           | G                           |
| 39           | V                           |
| 40           | P                           |
| 41           | L                           |
| 42           | L.G                         |
| 43           | O                           |
| 45           | P                           |
| 46           | SB                          |
| 47           | Y                           |
| 48           | L                           |
| 51           | B.R                         |
| 52           | G                           |
| 53           | B                           |
| 54           | O                           |
| 55           | Y                           |
| 56           | SHIELD                      |
| 61           | P                           |
| 62           | G                           |
| 63           | W/L                         |
| 64           | W.R                         |
| 66           | W                           |
| 67           | Y                           |
| 69           | R                           |
| 71           | R                           |
| 72           | L                           |
| 74           | Y                           |
| 75           | SB                          |
| 76           | Y                           |
| 77           | G                           |
| 78           | O                           |
| 80           | R                           |
| 81           | L                           |
| 82           | L.G                         |
| 83           | R                           |



| Terminal No. | Signal Name [Specification] |
|--------------|-----------------------------|
| 13           | W                           |
| 14           | L                           |
| 15           | P                           |
| 32           | V                           |
| 37           | B.R                         |
| 38           | G                           |
| 39           | V                           |
| 40           | P                           |
| 41           | L                           |
| 42           | L.G                         |
| 43           | O                           |
| 45           | P                           |
| 46           | SB                          |
| 47           | Y                           |
| 48           | L                           |
| 51           | B.R                         |
| 52           | G                           |
| 53           | B                           |
| 54           | O                           |
| 55           | Y                           |
| 56           | SHIELD                      |
| 61           | P                           |
| 62           | G                           |
| 63           | W/L                         |
| 64           | W.R                         |
| 66           | W                           |
| 67           | Y                           |
| 69           | R                           |
| 71           | R                           |
| 72           | L                           |
| 74           | Y                           |
| 75           | SB                          |
| 76           | Y                           |
| 77           | G                           |
| 78           | O                           |
| 80           | R                           |
| 81           | L                           |
| 82           | L.G                         |
| 83           | R                           |



| Terminal No. | Signal Name [Specification] |
|--------------|-----------------------------|
| 13           | W                           |
| 14           | L                           |
| 15           | P                           |
| 32           | V                           |
| 37           | B.R                         |
| 38           | G                           |
| 39           | V                           |
| 40           | P                           |
| 41           | L                           |
| 42           | L.G                         |
| 43           | O                           |
| 45           | P                           |
| 46           | SB                          |
| 47           | Y                           |
| 48           | L                           |
| 51           | B.R                         |
| 52           | G                           |
| 53           | B                           |
| 54           | O                           |
| 55           | Y                           |
| 56           | SHIELD                      |
| 61           | P                           |
| 62           | G                           |
| 63           | W/L                         |
| 64           | W.R                         |
| 66           | W                           |
| 67           | Y                           |
| 69           | R                           |
| 71           | R                           |
| 72           | L                           |
| 74           | Y                           |
| 75           | SB                          |
| 76           | Y                           |
|              |                             |

# STARTING SYSTEM

< WIRING DIAGRAM >

| STARTING SYSTEM |                           |   |  |
|-----------------|---------------------------|---|--|
| 80              | B                         |   |  |
| Connector No.   | M11                       |   |  |
| Connector Name  | WIRE TO WIRE              |   |  |
| Connector Type  | T17/0FW-CS17-H3           |   |  |
| HS.             |                           |   |  |
| Terminal No.    | Color Of Wire             | Signal Name [Specification]   |  |
| 1               | SHEILD                    |   |  |
| 2               | W                         |   |  |
| 3               | B                         |   |  |
| 4               | R                         |   |  |
| 6               | G                         |   |  |
| 7               | R                         |   |  |
| 8               | G                         |   |  |
| 9               | B                         |   |  |
| 10              | R                         |   |  |
| 11              | W                         | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 12              | L                         | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 13              | G                         | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 14              | L                         |   |  |
| 15              | P                         |   |  |
| 31              | R                         |   |  |
| 32              | LG                        |   |  |
| 37              | BR                        | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 38              | R                         | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 39              | Y                         | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 40              | P                         |   |  |
| 41              | L                         |   |  |
| 42              | G                         |   |  |
| 43              | W                         |   |  |
| 45              | P                         |   |  |
| 46              | V                         |   |  |
| 47              | R                         |   |  |
| 49              | G                         |   |  |
| 51              | G                         |   |  |
| 52              | W                         |   |  |
| 53              | B                         |   |  |
| 54              | LG                        |   |  |
| 55              | L                         |   |  |
| 56              | SHEILD                    |   |  |
| 61              | R                         |   |  |
| 62              | W                         |   |  |
| 63              | B                         |   |  |
| 64              | W                         |   |  |
| 66              | W                         |   |  |
| 67              | BR                        |   |  |
| 69              | P                         |   |  |
| 71              | R                         |   |  |
| 72              | L                         |   |  |
| 73              | LG                        |   |  |
| 74              | Y                         |   |  |
| 75              | Y                         |   |  |
| 76              | Y                         |   |  |
| 77              | B                         |   |  |
| 78              | BR                        |   |  |
| 80              | Y                         |   |  |
| 81              | W                         |   |  |
| 82              | L                         |   |  |
| 83              | R                         |   |  |
| HS.             |                           |   |  |
| Connector No.   | M124                      |   |  |
| Connector Name  | BCM (BODY CONTROL MODULE) |   |  |
| Connector Type  | TH40FW-NH                 |   |  |
| HS.             |                           |   |  |
| Terminal No.    | Color Of Wire             | Signal Name [Specification]   |  |
| 1               | Y                         | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 2               | LG                        | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 3               | LG                        | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 4               | LG                        | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 5               | LG                        | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 6               | LG                        | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 7               | LG                        | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| 8               | GR                        | - [Without automatic drive positioner]<br>- [With automatic drive positioner] |  |
| HS.             |                           |   |  |
| Connector No.   | F47                       |   |  |
| Connector Name  | STARTER MOTOR             |   |  |
| Connector Type  | X01FGY                    |   |  |
| HS.             |                           |   |  |
| Terminal No.    | Color Of Wire             | Signal Name [Specification]   | Terminal No. Color Of Wire Signal Name [Specification] |
| 1               | B                         | -   | 73 G ON/LND  |
| 1               | B                         | -   | 73 G DR DOOR REG SW                                    |
| 41              | L                         | -   | 76 V PUSH SW   |
| 42              | G                         | -   | 78 B DR DOOR ANT+                                      |
| 43              | W                         | -   | 79 W DR DOOR ANT-                                      |
| 45              | P                         | -   | 80 GR PASS DOOR ANT+                                   |
| 46              | V                         | -   | 81 BE PASS DOOR ANT-                                   |
| 47              | R                         | -   | 82 G REAR EMPR ANT-                                    |
| 49              | G                         | -   | 83 R REAR EMPR ANT-                                    |
| 51              | G                         | -   | 84 GR ROOM ANT1+                                       |
| 52              | W                         | -   | 85 B ROOM ANT1-  |
| 53              | B                         | -   | 86 W ROOM ANT2+  |
| 54              | LG                        | -   | 87 BE ROOM ANT2-                                       |
| 55              | L                         | -   | 88 GR LUGGAGE ROOM ANT+                                |

JRBWD0412GB

## DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

# BASIC INSPECTION

## DIAGNOSIS AND REPAIR WORK FLOW

### Work Flow (With GR8-1200 NI)

INFOID:000000011326162

#### STARTING SYSTEM DIAGNOSIS WITH GR8-1200 NI

To test the starting system, use the following special service tool:

- GR8-1200 NI Multitasking battery and electrical diagnostic station


**NOTE:**

Refer to the diagnostic station Instruction Manual for proper starting system diagnosis procedures.

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

OVERALL SEQUENCE



JMBIA4453GB

DETAILED FLOW

**NOTE:**

To ensure a complete and thorough diagnosis, the battery, starter motor and alternator test segments must be done as a set from start to finish.

## 1. DIAGNOSIS WITH MULTITASKING BATTERY AND ELECTRICAL DIAGNOSTIC STATION GR8-1200 NI

# DIAGNOSIS AND REPAIR WORK FLOW

## < BASIC INSPECTION >

Perform the starting system test with Multitasking battery and electrical diagnostic station GR8-1200 NI. For details and operating instructions, refer to diagnostic station Instruction Manual.

### Test result

CRANKING NORMAL>>GO TO 2.

LOW VOLTAGE>>GO TO 5.

CHARGE BATTERY>>Perform the slow battery charging procedure. (Initial rate of charge is 10A for 12 hours.) Perform battery test again. Refer to diagnostic station instruction manual.

REPLACE BATTERY>>Before replacing battery, clean the battery cable clamps and battery posts. Perform battery test again. Refer to diagnostic station instruction manual. If second test result is "REPLACE BATTERY", then do so. Perform battery test again to confirm repair.

## 2.CRANKING CHECK

Check that the starter motor operates correctly.

### Does the engine crank normally?

YES >> GO TO 3.

NO >> GO TO 4.

## 3.ENGINE START CHECK

Check that the engine starts.

### Does the engine start?

YES >> Starter motor is OK. INSPECTION END

NO >> Perform further diagnosis of engine mechanical or engine control system. Refer EM and EC sections. Once resolved, perform battery test again.

## 4.STARTER MOTOR ACTIVATION

Check that the starter motor operates.

### Does the starter motor turn?

YES >> Check ring gear and starter motor drive pinion. Once resolved, perform battery test again.

NO >> GO TO 7.

## 5.COMPARISON BETWEEN ENGINE COOLANT AND CRANKING VOLTAGE

Compare the engine coolant temperature and the cranking voltage with the specifications.

Minimum Specification of Cranking Voltage Referencing Coolant Temperature

| Engine coolant temperature [°C (°F)] | Voltage [V] |
|--------------------------------------|-------------|
| -30 to -20 (-22 to -4)               | 8.6         |
| -19 to -10 (-2 to 14)                | 9.1         |
| -9 to 0 (16 to 32)                   | 9.5         |
| More than 1 (More than 34)           | 9.9         |

### Is the voltage less than the specified value?

YES >> GO TO 7.

NO >> GO TO 6.

## 6.STARTER OPERATION

Check the starter operation status.

### Does the starter motor turn smoothly?

YES >> Starter motor is OK. INSPECTION END

NO >> GO TO 7.

## 7.“B” TERMINAL CIRCUIT INSPECTION

Check “B” terminal circuit. Refer to [STR-15, "Diagnosis Procedure"](#).

### Is “B” terminal circuit normal?

YES >> GO TO 8.

NO >> Repair as needed.

## 8.“S” CONNECTOR CIRCUIT INSPECTION

Check “S” connector circuit. Refer to [STR-16, "Diagnosis Procedure"](#).

# DIAGNOSIS AND REPAIR WORK FLOW

## < BASIC INSPECTION >

Is "S" connector circuit normal?

YES >> GO TO 9.

NO >> Repair as needed.

## 9.ENGINE ROTATION STATUS

Check that the engine can be rotated by hand.

Does the engine turn freely by hand?


YES >> Replace starter motor. Refer to [STR-18, "Removal and Installation".](#)

NO >> Perform further diagnosis of engine mechanical or powertrain mechanism. Once resolved, perform battery test again using Multitasking battery and electrical diagnostic station GR8-1200 NI. Refer to the diagnostic station Instruction Manual for proper testing procedures.

## Work Flow (Without GR8-1200 NI)

INFOID:000000011326163

### OVERALL SEQUENCE



JMBIA4454GB

### DETAILED FLOW

#### NOTE:

If any malfunction is found, immediately disconnect the battery cable from the negative terminal.

#### 1.CHECK ENGINE START

Crank the engine and check that the engine starts.

Does the engine start?

YES >> GO TO 2.

A

STR

C

D

E

F

G

H

I

J

K

L

M

N

O

P

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

NO >> GO TO 3.

## 2.CHECK THAT THE STARTER MOTOR STOPS

Check that the starter motor stops after starting the engine.

Does the starter motor stop?

YES >> INSPECTION END

NO >> Replace starter motor. Refer to [STR-18, "Removal and Installation"](#).

## 3.CHECK THAT THE ENGINE TURNS WHEN CRANKING

Check that the engine turns when cranking.

Does engine turn when cranking?

YES >> GO TO 4.

NO >> GO TO 5.

## 4.CHECK THE ENGINE SPEED WHEN CRANKING

Check that the engine speed is not low when cranking.

Does engine turn normally?

YES >> Check ignition/fuel system.

NO >> Check charge condition, corrosion and connection condition of the battery. Refer to [PG-110, "Work Flow"](#).

## 5.CHECK STARTER MOTOR ACTIVATION

Check that the starter motor runs at cranking.

Does starter motor turn?

YES >> Replace starter motor. Refer to [STR-18, "Removal and Installation"](#).

NO >> GO TO 6.

## 6.CHECK POWER SUPPLY CIRCUIT

Check the following conditions.

- Fuse and fusible link
- Charge condition, corrosion and connection condition of the battery. Refer to [PG-110, "Work Flow"](#).

Are these inspection results normal?

YES >> GO TO 7.

NO >> Repair as needed.

## 7.CHECK STARTING SYSTEM WIRING

Check the following.

- "B" terminal circuit. Refer to [STR-15, "Diagnosis Procedure"](#).
- "S" connector circuit. Refer to [STR-16, "Diagnosis Procedure"](#).

Are these inspection results normal?

YES >> Replace starter motor. Refer to [STR-18, "Removal and Installation"](#).

NO >> Repair as needed.

## B TERMINAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

# DTC/CIRCUIT DIAGNOSIS

## B TERMINAL CIRCUIT

### Description

INFOID:0000000011326164

A  
STR

The "B" terminal is constantly supplied with battery power.

### Diagnosis Procedure

INFOID:0000000011326165

C

#### **CAUTION:**

Perform diagnosis under the condition that engine cannot start by the following procedure.

1. Remove fuel pump fuse.
2. Crank or start the engine (where possible) until the fuel pressure is released.

#### 1.CHECK "B" TERMINAL CIRCUIT

1. Turn ignition switch OFF.
2. Check that starter motor "B" terminal connection is clean and tight.
3. Check voltage between starter motor "B" terminal and ground.

| Terminals                  |          | (-)    | Voltage (Approx.) |
|----------------------------|----------|--------|-------------------|
| (+)                        | Terminal |        |                   |
| Starter motor "B" terminal | F10      | Ground | Battery voltage   |
|                            | 2        |        |                   |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check harness between battery and starter motor for open circuit.

#### 2.CHECK BATTERY CABLE CONNECTION STATUS (VOLTAGE DROP TEST)

1. Shift selector lever to "P" or "N" position.
2. Check voltage between battery positive terminal and starter motor "B" terminal.

| Terminals                  |          | Condition                                     | Voltage (Approx.) |
|----------------------------|----------|---|-------------------|
| (+)                        | (-)      |   |                   |
| Starter motor "B" terminal | Terminal | When the ignition switch is in START position | Less than 0.5 V   |
| Battery positive terminal  | F10      | 2   |                   |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between the battery and the starter motor for poor continuity.

#### 3.CHECK GROUND CIRCUIT STATUS (VOLTAGE DROP TEST)

1. Shift selector lever to "P" or "N" position.
2. Check voltage between starter motor case and battery negative terminal.

| Terminals          |                           | Condition                                     | Voltage (Approx.) |
|--------------------|---------------------------|---|-------------------|
| (+)                | (-)                       |   |                   |
| Starter motor case | Battery negative terminal | When the ignition switch is in START position | Less than 0.2 V   |

Is the inspection result normal?

YES >> "B" terminal circuit is OK. Further inspection is necessary. Refer to [STR-10, "Work Flow \(With GR8-1200 NI\)"](#) or [STR-13, "Work Flow \(Without GR8-1200 NI\)"](#).

NO >> Check the starter motor case and ground for poor continuity.

# S CONNECTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

## S CONNECTOR CIRCUIT

### Description

INFOID:0000000011326166

The starter motor magnetic switch is supplied with power when the ignition switch is turned to the START position while the selector lever is in the P or N position.

### Diagnosis Procedure

INFOID:0000000011326167

#### CAUTION:

Perform diagnosis under the condition that engine cannot start by the following procedure.

1. Remove fuel pump fuse.
2. Crank or start the engine (where possible) until the fuel pressure is released.

#### 1.CHECK "S" CONNECTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect starter motor connector.
3. Shift selector lever to "P" or "N" position.
4. Check voltage between starter motor harness connector and ground.

| terminals                       |          | Condition | Voltage (Approx.)  |
|---------------------------------|----------|-----------|--|
| (+)                             | (-)      |           |  |
| Starter motor harness connector | Terminal |           |  |
| F47                             | 1        | Ground    | When the ignition switch is in START position<br>Battery voltage |

#### Is the inspection result normal?

YES >> "S" connector circuit is OK. Further inspection is necessary. Refer to [STR-10, "Work Flow \(With GR8-1200 NI\)"](#) or [STR-13, "Work Flow \(Without GR8-1200 NI\)"](#).

NO >> GO TO 2.

#### 2.CHECK HARNESS CONTINUITY (OPEN CIRCUIT)

1. Disconnect IPDM E/R connector.
2. Check continuity between starter motor harness connector and IPDM E/R harness connector.

| Starter motor harness connector |              | IPDM E/R harness connector |              | Continuity |
|---------------------------------|--------------|----------------------------|--------------|------------|
| Connector No.                   | Terminal No. | Connector No.              | Terminal No. |            |
| F47                             | 1            | F12                        | 80           | Existed    |

#### Is the inspection result normal?

YES >> Further inspection is necessary. Refer to [STR-10, "Work Flow \(With GR8-1200 NI\)"](#) or [STR-13, "Work Flow \(Without GR8-1200 NI\)"](#).

NO >> Repair the harness.

## STARTING SYSTEM

< SYMPTOM DIAGNOSIS >

# SYMPTOM DIAGNOSIS

## STARTING SYSTEM

### Symptom Table

INFOID:000000011326168

STR

| Symptom                       | Reference   |
|-------------------------------|---|
| No normal cranking            | Refer to <a href="#">STR-10. "Work Flow (With GR8-1200 NI)"</a> or <a href="#">STR-13. "Work Flow (Without GR8-1200 NI)".</a> |
| Starter motor does not rotate |   |

A

C

D

E

F

G

H

I

J

K

L

M

N

O

P

# STARTER MOTOR


< REMOVAL AND INSTALLATION >

## REMOVAL AND INSTALLATION STARTER MOTOR

### Exploded View

INFOID:0000000011326169

### REMOVAL



- 1. Cylinder block
- 2. Shim
- 3. Starter motor
- 4. "B" terminal harness
- 5. "S" connector

: N·m (kg-m, in-lb)

: N·m (kg-m, ft-lb)


### Removal and Installation

INFOID:0000000011326170

### REMOVAL

1. Remove battery. Refer to [PG-118, "Removal and Installation"](#).
2. Remove air duct (inlet) and air cleaner assembly. Refer to [EM-27, "Removal and Installation"](#).
3. Disconnect TCM harness connector (1) and ECM harness connectors (2).

: Vehicle front




# STARTER MOTOR

## < REMOVAL AND INSTALLATION >


4. Remove harness fixing clips (A) and harness mounting bolt (B).

◀ : Vehicle front




5. Remove ECM bracket mounting bolts (A), and then remove ECM bracket (1).

◀ : Vehicle front



6. Remove battery tray mounting bolts (A), and then remove battery tray (1).

◀ : Vehicle front



7. Disconnect "S" terminal harness connector.
8. Remove "B" terminal harness nut, and then disconnect "B" terminal harness.
9. Remove splash guard LH. Refer to [EXT-23, "Removal and Installation"](#).
10. Remove starter motor mounting bolts from the left side of the vehicle and the engine room.
11. Remove starter motor from the vehicle.

## INSTALLATION

Note the following items, and install in the reverse order of removal.

### CAUTION:

- Be careful to tighten "B" terminal nut to the specified torque.
- To prevent damage to the parts, connect the battery cable to the positive terminal first.
- To prevent damage to the vehicle, after connecting battery cables, ensure that they are tightly clamped to battery terminals for good contact.
- To prevent damage to the parts, check battery terminal for poor connection caused by corrosion.

### NOTE:

Reset electronic systems as necessary. Refer to [GI-58, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Required Procedure After Battery Disconnection"](#).

A  
STR  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# SERVICE DATA AND SPECIFICATIONS (SDS)

<SERVICE DATA AND SPECIFICATIONS (SDS)

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

Starter Motor

INFOID:0000000011326171

|                |                      |                     |
|----------------|----------------------|---------------------|
| Type           |                      | M000TB0271          |
|                |                      | IMITSUBISHI make    |
|                |                      | Reduction gear type |
| System voltage | [V]                  | 12                  |
| No-load        | Terminal voltage [V] | 11                  |
|                | Current [A]          | Less than 90        |
|                | Revolution [rpm]     | More than 2,370     |