

SECTION **LAN**  
LAN SYSTEM

A  
B  
C

CONTENTS

D  
E

<b>CAN</b>		
<b>PRECAUTIONS</b> .....	<b>3</b>	
Precautions for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	3	
Precautions When Using CONSULT-II .....	3	
CHECK POINTS FOR USING CONSULT-II .....	3	
Precautions for CAN System .....	3	
<b>CAN COMMUNICATION</b> .....	<b>5</b>	
System Description .....	5	
CAN Communication Unit .....	5	
TYPE 1 .....	7	
TYPE 2/TYPE 3 .....	9	
TYPE 4/TYPE 5 .....	12	
<b>CAN SYSTEM (TYPE 1)</b> .....	<b>15</b>	
System Description .....	15	
Component Parts and Harness Connector Location .....	15	
Schematic .....	16	
Wiring Diagram — CAN — .....	17	
Work Flow .....	20	
CHECK SHEET .....	22	
CHECK SHEET RESULTS .....	24	
Circuit Check Between TCM and Data Link Connector .....	35	
ECM Circuit Check .....	35	
TCM Circuit Check .....	36	
ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	36	
Front Air Control Circuit Check .....	37	
Display Unit Circuit Check .....	37	
Data Link Connector Circuit Check .....	38	
BCM Circuit Check .....	38	
Combination Meter Circuit Check .....	39	
IPDM E/R Circuit Check .....	39	
CAN Communication Circuit Check .....	40	
IPDM E/R Ignition Relay Circuit Check .....	40	
Component Inspection .....	41	
ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION .....	41	
<b>CAN SYSTEM (TYPE 2)</b> .....	<b>42</b>	
System Description .....	42	
Component Parts and Harness Connector Location .....	42	
Schematic .....	43	
Wiring Diagram — CAN — .....	44	
Work Flow .....	47	
CHECK SHEET .....	49	
CHECK SHEET RESULTS .....	51	
Circuit Check Between TCM and Data Link Connector .....	62	
ECM Circuit Check .....	62	
TCM Circuit Check .....	63	
ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	63	
Front Air Control Circuit Check .....	64	
Display Unit Circuit Check .....	64	
Data Link Connector Circuit Check .....	65	
BCM Circuit Check .....	65	
Combination Meter Circuit Check .....	66	
IPDM E/R Circuit Check .....	66	
CAN Communication Circuit Check .....	67	
IPDM E/R Ignition Relay Circuit Check .....	67	
Component Inspection .....	68	
ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION .....	68	
<b>CAN SYSTEM (TYPE 3)</b> .....	<b>69</b>	
System Description .....	69	
Component Parts and Harness Connector Location .....	69	
Schematic .....	70	
Wiring Diagram — CAN — .....	71	
Work Flow .....	74	
CHECK SHEET .....	76	
CHECK SHEET RESULTS .....	78	
Circuit Check Between TCM and Data Link Connector .....	89	
ECM Circuit Check .....	89	
TCM Circuit Check .....	90	
ABS Actuator and Electric Unit (Control Unit) Circuit Check .....	90	
Front Air Control Circuit Check .....	91	

F  
G  
H  
I  
J  
L  
M

LAN

Display Control Unit Circuit Check .....	91	CAN Communication Circuit Check .....	124
Data Link Connector Circuit Check .....	92	IPDM E/R Ignition Relay Circuit Check .....	124
BCM Circuit Check .....	92	Component Inspection .....	125
Combination Meter Circuit Check .....	93	ECM AND IPDM E/R INTERNAL CIRCUIT	
IPDM E/R Circuit Check .....	93	INSPECTION .....	125
CAN Communication Circuit Check .....	94	<b>CAN SYSTEM (TYPE 5) .....</b>	<b>126</b>
IPDM E/R Ignition Relay Circuit Check .....	94	System Description .....	126
Component Inspection .....	95	Component Parts and Harness Connector Location .....	126
ECM AND IPDM E/R INTERNAL CIRCUIT		Schematic .....	127
INSPECTION .....	95	Wiring Diagram — CAN — .....	128
<b>CAN SYSTEM (TYPE 4) .....</b>	<b>96</b>	Work Flow .....	131
System Description .....	96	CHECK SHEET .....	133
Component Parts and Harness Connector Location .....	96	CHECK SHEET RESULTS .....	135
Schematic .....	97	Circuit Check Between TCM and Data Link Con-	
Wiring Diagram — CAN — .....	98	nector .....	148
Work Flow .....	101	ECM Circuit Check .....	148
CHECK SHEET .....	103	TCM Circuit Check .....	149
CHECK SHEET RESULTS .....	105	ABS Actuator and Electric Unit (Control Unit) Circuit	
Circuit Check Between TCM and Data Link Con-		Check .....	149
nector .....	118	Front Air Control Circuit Check .....	150
ECM Circuit Check .....	118	Display Control Unit Circuit Check .....	150
TCM Circuit Check .....	119	Data Link Connector Circuit Check .....	151
ABS Actuator and Electric Unit (Control Unit) Circuit		BCM Circuit Check .....	151
Check .....	119	Combination Meter Circuit Check .....	152
Front Air Control Circuit Check .....	120	Steering Angle Sensor Circuit Check .....	152
Display Unit Circuit Check .....	120	Driver Seat Control Unit Circuit Check .....	153
Data Link Connector Circuit Check .....	121	IPDM E/R Circuit Check .....	153
BCM Circuit Check .....	121	CAN Communication Circuit Check .....	154
Combination Meter Circuit Check .....	122	IPDM E/R Ignition Relay Circuit Check .....	154
Steering Angle Sensor Circuit Check .....	122	Component Inspection .....	155
Driver Seat Control Unit Circuit Check .....	123	ECM AND IPDM E/R INTERNAL CIRCUIT	
IPDM E/R Circuit Check .....	123	INSPECTION .....	155

**PRECAUTIONS**

**Precautions for Supplemental Restraint System (SRS) “AIR BAG” and “SEAT BELT PRE-TENSIONER”**

UKS002EC

The Supplemental Restraint System such as “AIR BAG” and “SEAT BELT PRE-TENSIONER”, used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the SRS and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SRS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

**Precautions When Using CONSULT-II**

UKS002EE

When connecting CONSULT-II to data link connector, connect them through CONSULT-II CONVERTER.

**CAUTION:**

If CONSULT-II is used with no connection of CONSULT-II CONVERTER, malfunctions might be detected in self-diagnosis depending on control unit which carry out CAN communication.


**CHECK POINTS FOR USING CONSULT-II**

1. Has CONSULT-II been used without connecting CONSULT-II CONVERTER on this vehicle?
  - If YES, GO TO 2.
  - If NO, GO TO 5.
2. Is there any indication other than indications relating to CAN communication system in the self-diagnosis results?
  - If YES, GO TO 3.
  - If NO, GO TO 4.
3. Based on self-diagnosis results unrelated to CAN communication, carry out the inspection.
4. Malfunctions may be detected in self-diagnosis depending on control units carrying out CAN communication. Therefore, erase the self-diagnosis results.
5. Diagnose CAN communication system. Refer to [LAN-5, "CAN COMMUNICATION"](#) .

**Precautions for CAN System**

UKS002ED

- Do not apply voltage of 7.0 V or higher to terminal to be measured.
- Maximum open terminal voltage of tester in use must be less than 7.0 V.
- Before checking harnesses, turn ignition switch OFF and disconnect negative battery terminal.
- Area to be repaired must be soldered and wrapped with tape. Make sure that fraying of twisted wire is within 110 mm (4.33 in).




PKIA0306E

## PRECAUTIONS

[CAN]

- Do not make a bypass connection to repaired area. (If the circuit is bypassed, characteristics of twisted wire will be lost.)



## CAN COMMUNICATION

PFP:23710

### System Description

UKS002EG

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### CAN Communication Unit

UKS002EH

Refer to the following table to determine CAN system type.


Axle	2WD				
Engine	VQ35DE				
Transmission	4 A/T	5 A/T			
Brake control	TCS	TCS		VDC	
Navigation system			X		X
Automatic drive positioner				X	X
CAN system type	1	2	3	4	5
CAN system trouble diagnosis	<a href="#">LAN-15</a>	<a href="#">LAN-42</a>	<a href="#">LAN-69</a>	<a href="#">LAN-96</a>	<a href="#">LAN-126</a>

X: Applicable


**NOTE:**

Confirming the presence of the following items helps to identify CAN system type.

- Models with TCS



- Models with VDC




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN


# CAN COMMUNICATION

[CAN]

- Models with navigation system



- Models with automatic drive positioner




# CAN COMMUNICATION

[CAN]

## TYPE 1

### System diagram

- Type 1



### Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Front air control	Display unit	BCM	Combination meter	IPDM E/R
Engine speed signal	T		R	R	R		R	
Engine coolant temperature signal	T			R			R	
Ignition switch signal						T		R
Ignition power supply confirmation signal						R		T
Fuel consumption monitor signal	T						R	
					R		T	
A/C switch signal	R			R		T		
A/C compressor request signal	T							R
Blower fan motor switch signal	R					T		
A/C switch/indicator signal				R	T			
				T	R			
Cooling fan speed request signal	T							R
Cooling fan speed signal	R							T
Position light request signal						T	R	R
Low beam request signal						T		R
Low beam status signal	R							T
High beam request signal						T	R	R
High beam status signal	R							T
Front fog light request signal						T		R
Vehicle speed signal			T	R			R	
	R				R	R	T	
Sleep wake up signal						T	R	R

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Front air control	Display unit	BCM	Combination meter	IPDM E/R
IPDM E/R wake up sleep request signal						R		T
IPDM E/R refuse to sleep signal						R		T
BCM wake up request signal						R		T
Door switch signal					R	T	R	R
Turn indicator signal						T	R	
Cornering lamp request signal						T		R
Oil pressure switch signal							R	T
Buzzer output signal						T	R	
Fuel level sensor signal	R						T	
ASCD SET indicator signal	T						R	
ASCD CRUISE indicator signal	T						R	
Malfunction indicator lamp signal	T						R	
Front wiper request signal						T		R
Front wiper stop position signal						R		T
Rear window defogger switch signal				R	R	T		R
Rear window defogger control signal	R							T
Horn chirp signal						T		R
ABS warning lamp signal			T				R	
Brake warning lamp signal			T				R	
System setting signal					T	R		
					R	T		
Distance to empty signal					R		T	
A/T self-diagnosis signal	R	T						
Engine and A/T integrated control signal	T	R						
	R	T						
Accelerator pedal position signal	T		R					
Closed throttle position signal	T	R						
Wide open throttle position signal	T	R						
P range signal		T	R					
Stop lamp switch signal		R					T	
Input shaft revolution signal	R	T						
Output shaft revolution signal	R	T						
ASCD operation signal	T	R						
ASCD OD cancel request signal	T	R						
SLIP indicator lamp signal			T				R	
O/D OFF indicator lamp signal		T					R	
A/T position indicator lamp signal		T					R	
A/T shift schedule change demand signal		R	T					
Overdrive control switch signal		R					T	
Tire pressure signal						T	R	




# CAN COMMUNICATION

[CAN]


Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Front air control	Display unit	BCM	Combination meter	IPDM E/R
Tire pressure data signal					R	T		
Seat belt buckle switch signal						R	T	

## TYPE 2/TYPE 3 System diagram

- Type 2



- Type 3



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN COMMUNICATION

[CAN]

## Input/output signal chart

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Front air control	Display control unit	Display unit	BCM	Combination meter	IPDM E/R
Engine speed signal	T	R	R	R	R	R		R	
Engine coolant temperature signal	T	R		R				R	
Ignition switch signal							T		R
Ignition power supply confirmation signal							R		T
ABS operation signal		R	T						
Fuel consumption monitor signal	T				R	R		R	
A/C switch signal	R			R			T		
A/C compressor request signal	T								R
Blower fan motor switch signal	R						T		
A/C switch/indicator signal				R	T	T			
				T	R	R			
Cooling fan speed request signal	T								R
Cooling fan speed signal	R								T
Position light request signal							T	R	R
Low beam request signal							T		R
Low beam status signal	R								T
High beam request signal							T	R	R
High beam status signal	R								T
Front fog light request signal							T		R
Vehicle speed signal			T	R				R	
	R	R			R	R	R	T	
Sleep wake up signal							T	R	R
IPDM E/R wake up sleep request signal							R		T
IPDM E/R refuse to sleep signal							R		T
BCM wake up request signal							R		T
Door switch signal					R	R	T	R	R
Turn indicator signal							T	R	
Cornering lamp request signal							T		R
Oil pressure switch signal								R	T
Buzzer output signal							T	R	
Fuel level sensor signal	R							T	
ASCD SET indicator signal	T							R	
ASCD CRUISE indicator signal	T							R	
Malfunction indicator lamp signal	T							R	
Front wiper request signal							T		R
Front wiper stop position signal							R		T


# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Front air control	Display control unit	Display unit	BCM	Combination meter	IPDM E/R	A B C D E F G H I J L M
Rear window defogger switch signal				R	R	R	T		R	
Rear window defogger control signal	R								T	
Horn chirp signal							T		R	
ABS warning lamp signal			T					R		
Brake warning lamp signal			T					R		
System setting signal					T	T	R			
					R	R	T			
Distance to empty signal					R	R		T		
A/T self-diagnosis signal	R	T								
Engine and A/T integrated control signal	T	R								
	R	T								
Accelerator pedal position signal	T	R	R							
P range signal		T	R							
Stop lamp switch signal		R						T		
TCS operation signal		R	T							
Input shaft revolution signal	R	T								
Output shaft revolution signal	R	T								
ASCD operation signal	T	R								
ASCD OD cancel request signal	T	R								
SLIP indicator lamp signal			T					R		LAN
O/D OFF indicator lamp signal		T						R		
A/T position indicator lamp signal		T						R		
A/T shift schedule change demand signal		R	T							
Tire pressure signal							T	R		
Tire pressure data signal					R	R	T			
Seat belt buckle switch signal							R	T		


**TYPE 4/TYPE 5**  
**System diagram**

- Type 4



SKIB1740E

- Type 5



SKIB1741E

**Input/output signal chart**

T: Transmit R: Receive

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Front air control	Display control unit	Display unit	BCM	Combination meter	Steering angle sensor	Driver seat control unit	IPDM E/R
Engine speed signal	T	R	R	R	R	R		R			
Engine coolant temperature signal	T	R		R				R			
Key switch signal							T			R	
Ignition switch signal							T			R	R
Ignition power supply confirmation signal							R				T

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Front air control	Display control unit	Display unit	BCM	Combination meter	Steering angle sensor	Driver seat control unit	IPDM E/R
ABS operation signal		R	T								
Fuel consumption monitor signal	T				R	R		R			
A/C switch signal	R			R			T				
A/C compressor request signal	T										R
Blower fan motor switch signal	R						T				
A/C switch/indicator signal				R	T	T					
Cooling fan speed request signal	T			T	R	R					R
Cooling fan speed signal	R										T
Position light request signal							T	R			R
Low beam request signal							T				R
Low beam status signal	R										T
High beam request signal							T	R			R
High beam status signal	R										T
Front fog light request signal							T				R
Vehicle speed signal			T	R				R			
	R	R			R	R	R	T		R	
Sleep wake up signal							T	R			R
IPDM E/R wake up sleep request signal							R				T
IPDM E/R refuse to sleep signal							R				T
BCM wake up request signal							R				T
Door switch signal					R	R	T	R		R	R
Turn indicator signal							T	R			
Cornering lamp request signal							T				R
Key fob ID signal							T			R	
Key fob door unlock signal							T			R	
Oil pressure switch signal								R			T
Buzzer output signal							T	R			
Fuel level sensor signal	R							T			
ASCD SET indicator signal	T							R			
ASCD CRUISE indicator signal	T							R			
Malfunction indicator lamp signal	T							R			
Front wiper request signal							T				R
Front wiper stop position signal							R				T
Rear window defogger switch signal				R	R	R	T				R

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

# CAN COMMUNICATION

[CAN]

Signals	ECM	TCM	ABS actuator and electric unit (control unit)	Front air control	Display control unit	Display unit	BCM	Combination meter	Steering angle sensor	Driver seat control unit	IPDM E/R
Rear window defogger control signal	R										T
Horn chirp signal							T				R
ABS warning lamp signal			T					R			
Brake warning lamp signal			T					R			
System setting signal					T	T	R			R	
					R	R	T			T	
Distance to empty signal					R	R		T			
A/T self-diagnosis signal	R	T									
Engine and A/T integrated control signal	T	R									
	R	T									
Accelerator pedal position signal	T	R	R								
P range signal		T	R							R	
R range signal		T								R	
Stop lamp switch signal		R						T			
VDC operation signal		R	T								
Input shaft revolution signal	R	T									
Output shaft revolution signal	R	T									
ASCD operation signal	T	R									
ASCD OD cancel request signal	T	R									
Steering angle sensor signal			R						T		
SLIP indicator lamp signal			T					R			
O/D OFF indicator lamp signal		T						R			
A/T position indicator lamp signal		T						R			
A/T shift schedule change demand signal		R	T								
Tire pressure signal							T	R			
Tire pressure data signal					R	R	T				
Seat belt buckle switch signal							R	T			

## CAN SYSTEM (TYPE 1)

PFP:23710


### System Description

UKS002EI

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS002EJ



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

# CAN SYSTEM (TYPE 1)

[CAN]

## Schematic

UKS002EK



WKWA0599E



# CAN SYSTEM (TYPE 1)



[CAN]

## Wiring Diagram — CAN —



UKS002EL

LAN-CAN-01

▬ : DATA LINE




BKWA0332E




M22  
W



M23  
W



M50  
W



M93  
W

REFER TO THE FOLLOWING.


M18 - ELECTRICAL UNITS

# CAN SYSTEM (TYPE 1)


[CAN]

LAN-CAN-03

▬ : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



BKWA0334E

# CAN SYSTEM (TYPE 1)

[CAN]

UKS002PL

## Work Flow

- When there are no indications of “BCM” or “IPDM E/R” on “SELECT SYSTEM” display of CONSULT-II, print the “SELECT SYSTEM”.

(Example)

NISSAN			
CONSULT-II			
ENGINE			
START (NISSAN BASED VHCL)			
START (RENAULT BASED VHCL)			
SUB MODE			
		LIGHT	COPY

➔

SELECT SYSTEM			
ENGINE			
A/T			
ABS			
AIR BAG			
BCM			
METER A/C AMP			
		BACK	LIGHT COPY

PKIA2093E

- Print all the data of “SELF-DIAG RESULTS” for “ENGINE”, “A/T”, “ABS”, “BCM” and “IPDM E/R” displayed on CONSULT-II.

(Example)

SELECT DIAG MODE		SELF-DIAG RESULTS	
WORK SUPPORT		DTC RESULTS	
SELF-DIAG RESULTS		TIME	
DATA MONITOR		CAN COMM CIRCUIT (U1000)	
DATA MONITOR (SPEC)		0	
CAN DIAG SUPPORT MNTR			
ACTIVE TEST			
		F.F.DATA	
Scroll Down		ERASE PRINT	
		MODE	BACK LIGHT COPY

➔

CAN DIAG SUPPORT MNTR			
ENGINE			
INITIAL DIAG		PRSN	
TRANSMIT DIAG		OK	
TCM		OK	
VDC/TCS/ABS		OK	
METER/M&A		OK	
ICC		UNKWN	
BCM/SEC		OK	
IPDM E/R		OK	
AWD/4WD/e4WD		UNKWN	
PRINT		Scroll Down	
MODE	BACK	LIGHT	COPY

PKIA8260E

- Print all the data of “CAN DIAG SUPPORT MNTR” for “ENGINE”, “A/T”, “ABS”, “BCM” and “IPDM E/R” displayed on CONSULT-II.

(Example)

SELECT DIAG MODE		CAN DIAG SUPPORT MNTR	
WORK SUPPORT		ENGINE	
SELF-DIAG RESULTS		PRSN	
DATA MONITOR		INITIAL DIAG	
DATA MONITOR (SPEC)		OK	
CAN DIAG SUPPORT MNTR		TRANSMIT DIAG	
ACTIVE TEST		OK	
		TCM	
Scroll Down		OK	
		VDC/TCS/ABS	
		OK	
		METER/M&A	
		OK	
		ICC	
		UNKWN	
		BCM/SEC	
		OK	
		IPDM E/R	
		OK	
		AWD/4WD/e4WD	
		UNKWN	
		PRINT	
		Scroll Down	
		MODE	BACK LIGHT COPY

➔

CAN DIAG SUPPORT MNTR											
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis		Transmit diagnosis		ECM		TCM		Receive diagnosis	
										Front air control	
										BCM/SEC	
										METER/M&A	
										IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

PKIA8343E

- Attach the printed sheet of “SELECT SYSTEM”, “SELF-DIAG RESULTS” and “CAN DIAG SUPPORT MNTR” onto the check sheet. Refer to [LAN-22, "CHECK SHEET"](#).
- Based on the indications of “SELECT SYSTEM” and the results of “CAN DIAG SUPPORT MNTR”, put marks onto the items with “No indication”, “NG” or “UNKWN” in the check sheet table.

CAN DIAG SUPPORT MNTR											
SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis		Transmit diagnosis		ECM		TCM		Receive diagnosis	
										Front air control	
										BCM/SEC	
										METER/M&A	
										IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2559E

# CAN SYSTEM (TYPE 1)

[CAN]

**NOTE:**

- If “NG” is displayed on “INITIAL DIAG (Initial diagnosis)” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.  
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.

6. Check CAN communication line of the integrated display system. Refer to [AV-109, "AV Communication Line Check"](#) .
7. Attach the CAN DIAG MONITOR check sheet onto the check sheet. Refer to [LAN-22, "CHECK SHEET"](#) .
8. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG MONITOR check sheet.

**NOTE:**

If “NG” is displayed on “CAN COMM” as “CAN DIAG MNTR” for the diagnosed control unit, replace the control unit.

9. According to the Check Sheet Results, start inspection.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 1)

[CAN]

## CHECK SHEET

### NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						METER/M&A	IPDM E/R
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SEC			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7	
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	

Symptoms:

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display unit  
CAN DIAG MONITOR  
check sheet

SKIB2092E

# CAN SYSTEM (TYPE 1)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of A/T SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS
Attach copy of BCM SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS	
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of A/T CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR
Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

SKIB2093E


## CHECK SHEET RESULTS

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-35, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VID/TCS/ABS	Front air control	BCM/SEC	METER/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	✓	✓	-	CAN 4	CAN 2	CAN 5	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2576E



SKIB2082E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-35, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIC/ICS/ABS	Front air control	BCM/SEC	MI-IE/R M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	UNKWN	-	-	CAN 4	CAN 2	CAN 5	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2577E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 3

Check TCM circuit. Refer to [LAN-36, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R																
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						MFI-IFR/ M&A	IPDM E/R							
				ECM	TCM	VIDOTCS/ ABS	Front air control	BCM/SEC	CAN 1			CAN 2	CAN 3	CAN 4	CAN 5	CAN 6	CAN 7	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
A/T	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	-	-	CAN 4	CAN 2	-	CAN 5	-	CAN 6	-	CAN 7	-	UNKWN
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	-	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN

WKIA2579E



SKIB2084E

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 4

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-36, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SEC	MF-IFR/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2935E




## Case 5

Check front air control circuit. Refer to [LAN-37, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						MF-TE/R/ M&A	IPDM E/R
				ECM	TCM	VIDOTCS/ ABS	Front air control	BCM/SEC			
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	UNKWN	
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	✓4	CAN 2	CAN 5	CAN 7	
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	

WKIA2584E



SKIB2086E

# CAN SYSTEM (TYPE 1)


[CAN]

## Case 6

Check display unit circuit. Refer to [LAN-37, "Display Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VDC/TCSS/ABS	Front air control	BCM/SEC	MI-IE/R M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display unit	-	CAN COMM	✓1	✓3	-	-	✓4	✓2	✓5	✓7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2580E




## Case 7

Check data link connector circuit. Refer to [LAN-38, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDOTCS/ABS	Front air control	BCM/SEC	MF-TE/R/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
BCM	No illumination	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No illumination	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-

WKIA2581E

////// : Malfunctioning part




SKIB2088E

## Case 8

Check BCM circuit. Refer to [LAN-38, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIC/ICS/ABS	Front air control	BCM/SEC	MI-IE/R M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	UNKWN	CAN 5	CAN 7
BCM	No indication ✓	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2582E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

LAN


## Case 9

Check combination meter circuit. Refer to [LAN-39, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						MFI-TE/R/ M/A	IPDM E/R
				ECM	TCM	VIDOTCS/ ABS	Front air control	BCM/SEC			
ENGINE	-	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	UNKWN	
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7	
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	

WKIA2583E

////// : Malfunctioning part



SKIB2090E



# CAN SYSTEM (TYPE 1)


[CAN]

## Case 10

Check IPDM E/R circuit. Refer to [LAN-39, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	VDC/TCSS/ABS	Front air control	BCM/SEC	MH-ER/M&A	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	✓17
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	✓No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2585E



## Case 11

Check CAN communication circuit. Refer to [LAN-40, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						IPDM E/R
				ECM	TCM	VDC/TCSS/ABS	Front air control	BCM/SEC	MH-ER/M&A	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	✓3	-	-	✓4	✓2	✓5	✓17
BCM	✓No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	✓No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2138E

# CAN SYSTEM (TYPE 1)

[CAN]

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-40, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDC/TCSI/ABS	Front air control	BCM/SEC	M-TEF/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN ✓	UNKWN ✓	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2587E

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-40, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDC/TCSI/ABS	Front air control	BCM/SEC	M-TEF/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
A/T	-	NG	UNKWN	UNKWN ✓	-	UNKWN	-	-	UNKWN ✓	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

WKIA2588E

## Circuit Check Between TCM and Data Link Connector

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector E142 and ECM connector E16.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector E142 terminals 5 (L), 6 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 5 (L) - 6 (L) : Continuity should exist.**  
**6 (P) - 14 (P) : Continuity should exist.**

#### OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-20, "Work Flow"](#).  
NG >> Repair harness.



## ECM Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector E16.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector E16 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

#### OK or NG

- OK >> Replace ECM.  
NG >> Repair harness between ECM connector E16 and TCM connector E142.



**TCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector E142.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between TCM connector E142 terminal 5 (L) and terminal 6 (P).

**5 (L) - 6 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace TCM.  
 NG >> Repair harness between TCM connector E142 and ECM connector E16.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

**20 (L) - 23 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and ECM connector E16.



**Front Air Control Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect front air control connector M50.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between front air control connector M50 terminal 34 (L) and terminal 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace front air control.  
 NG >> Repair harness between front air control connector M50 and data link connector M22.

**Display Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display unit connector M93.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between display unit connector M93 terminal 14 (L) and terminal 16 (P).

**14 (L) - 16 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace display unit.  
 NG >> Repair harness between display unit connector M93 and data link connector M22.



## Data Link Connector Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Diagnose again. Refer to [LAN-20, "Work Flow"](#) .  
 NG >> Repair harness between data link connector M22 and BCM connector M18.



## BCM Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace BCM.  
 NG >> Repair harness between BCM connector M18 and data link connector M22.



**Combination Meter Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect combination meter connector M23.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between combination meter connector M23 terminal 27 (L) and terminal 28 (P).

**27 (L) - 28 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter connector M23 and data link connector M22.

**IPDM E/R Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132  $\Omega$**

**OK or NG**

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R connector E121 and data link connector M22.



## CAN Communication Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - TCM (Transmission control module)
  - ABS actuator and electric unit (control unit)
  - Front air control
  - Display unit
  - BCM (Body control module)
  - Combination meter
  - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

OK >> GO TO 2.

NG >> Repair or replace as necessary.

### 2. CHECK HARNESS FOR SHORTED CIRCUITS


With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair the harness.



SKIA6868E

### 3. CHECK HARNESS FOR SHORT TO GROUND

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-41, "Component Inspection"](#).

NG >> Repair the harness.



SKIA6874E

### IPDM E/R Ignition Relay Circuit Check


Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).



**Component Inspection****ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Disconnect ECM and IPDM E/R harness connectors.
- Check resistance between ECM terminals 94 and 86.  
**94 - 86 : Approx. 108 - 132  $\Omega$**
- Check resistance between IPDM E/R terminals 48 and 49.  
**48 - 49 : Approx. 108 - 132  $\Omega$**



A

B

C

D

E

F

G

H

I

J

LAN

L

M

## CAN SYSTEM (TYPE 2)

PFP:23710


## System Description

UKS002P2

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## Component Parts and Harness Connector Location

UKS002P3




# CAN SYSTEM (TYPE 2)

[CAN]

## Schematic

UKS002P4



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

BKWA0349E

# CAN SYSTEM (TYPE 2)



[CAN]

UKS002P5

## Wiring Diagram — CAN —

LAN-CAN-04

▬ : DATA LINE




BKWA0350E

# CAN SYSTEM (TYPE 2)


[CAN]

LAN-CAN-05



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M



LAN



REFER TO THE FOLLOWING.  
M18 - ELECTRICAL UNITS

BKWA0351E

▬ : DATA LINE




# CAN SYSTEM (TYPE 2)

[CAN]


UKS002P7

## Work Flow


- When there are no indications of "TRANSMISSION", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "ABS", "BCM" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "ABS", "BCM" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-49. "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG" or "UNKWVN" in the check sheet table.

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR								
	Initial diagnosis	Transmit diagnosis	ECM	TCM	VDC/TCS/ABS	Receive diagnosis Front air control	BCM/SEC	METER/M&A	IPDM E/R
ENGINE	-	NG	UNKWVN	-	UNKWVN	UNKWVN	-	UNKWVN	UNKWVN
TRANSMISSION	No indication	NG	UNKWVN	UNKWVN	-	UNKWVN	-	-	UNKWVN
ABS	-	NG	UNKWVN	UNKWVN	UNKWVN	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5
BCM	No indication	NG	UNKWVN	UNKWVN	-	-	-	-	UNKWVN
IPDM E/R	No indication	-	UNKWVN	UNKWVN	-	-	-	UNKWVN	-

SKIB2081E

---

**NOTE:**

- If “NG” is displayed on “INITIAL DIAG (Initial diagnosis)” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
  - The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.  
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
6. Check CAN communication line of the integrated display system. Refer to [AV-109, "AV Communication Line Check"](#) .
  7. Attach the CAN DIAG MONITOR check sheet onto the check sheet. Refer to [LAN-49, "CHECK SHEET"](#) .
  8. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG MONITOR check sheet.

**NOTE:**

If “NG” is displayed on “CAN COMM” as “CAN DIAG MNTR” for the diagnosed control unit, replace the control unit.

9. According to the Check Sheet Results, start inspection.



# CAN SYSTEM (TYPE 2)

[CAN]

## CHECK SHEET

### NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SEC	METER/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

Symptoms:

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display unit  
CAN DIAG MONITOR  
check sheet

SKIB2067E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 2)

[CAN]

Attach copy of  
ENGINE  
SELF-DIAG RESULTS

Attach copy of  
TRANSMISSION  
SELF-DIAG RESULTS

Attach copy of  
ABS  
SELF-DIAG RESULTS

Attach copy of  
BCM  
SELF-DIAG RESULTS

Attach copy of  
IPDM E/R  
SELF-DIAG RESULTS

Attach copy of  
ENGINE  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
TRANSMISSION  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
ABS  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
BCM  
CAN DIAG SUPPORT  
MNTR

Attach copy of  
IPDM E/R  
CAN DIAG SUPPORT  
MNTR

SKIB2041E


## CHECK SHEET RESULTS

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-62, "Circuit Check Between TCM and Data Link Connector"](#).

SH-ECI SYSTEM screen		CAN DIAG SUPPORT MONTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDC/CS/ABS	Front air control	BCM/SEC	M-IER/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	✓ 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2068E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 2

Check ECM circuit. Refer to [LAN-62, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDOTCS/ABS	Front air control	BCM/SEC	MF-TE/R/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
ECM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2069E




SKIB2083E

## Case 3

Check TCM circuit. Refer to [LAN-63, "TCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIC/ICS/ABS	Front air control	BCM/SEC	MI-IE/R M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2070E




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

## Case 4

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-63, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDC/TCM/ABS	Front air control	BCM/SEC	MI-IFR/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2071E




SKIB2085E

## Case 5

Check front air control circuit. Refer to [LAN-64, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIC/ICS/ABS	Front air control	BCM/SEC	MI-IE/R M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	✓4	CAN 2	CAN 5	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2072E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 6

Check display unit circuit. Refer to [LAN-64, "Display Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDOTCS/ABS	Front air control	BCM/SEC	MF-TE/R/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display unit	-	CAN COMM	✓ <sup>1</sup>	✓ <sup>3</sup>	-	-	✓ <sup>4</sup>	✓ <sup>2</sup>	✓ <sup>5</sup>	✓ <sup>7</sup>
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2073E



SKIB2087E




## Case 7

Check data link connector circuit. Refer to [LAN-65, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIC/ICS/ABS	Front air control	BCM/SEC	MI-IE/R M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No location ✓	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
BCM	No location ✓	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No location ✓	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2074E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 8

Check BCM circuit. Refer to [LAN-65, "BCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						MF-TE/R/ M&A	IPDM E/R
				ECM	TCM	VIDOTCS/ ABS	Front air control	BCM/SEC			
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	✓2	CAN 5	CAN 7	
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN	
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	

SKIB2075E




SKIB2089E

## Case 9

Check combination meter circuit. Refer to [LAN-66, "Combination Meter Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIC/ICSI/ABS	Front air control	BCM/SEC	MI-IE/R M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2076E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 2)


[CAN]

## Case 10

Check IPDM E/R circuit. Refer to [LAN-66, "IPDM E/R Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDOTCS/ABS	Front air control	BCM/SEC	MF-TE/R/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	✓7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	✓	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2077E



## Case 11

Check CAN communication circuit. Refer to [LAN-67, "CAN Communication Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDOTCS/ABS	Front air control	BCM/SEC	MF-TE/R/M&A	IPDM E/R
ENGINE	-	NG	✓UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	✓UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	✓CAN 3	-	-	✓4	✓2	✓5	✓7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	✓	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2078E

# CAN SYSTEM (TYPE 2)

[CAN]

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-67, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR						
				Receive diagnosis						
				ECM	TCM	VDC/TCSP/ABS	Front air control	BCM/SEC	MHFR/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
HCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2079E

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-67, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR						
				Receive diagnosis						
				ECM	TCM	VDC/TCSP/ABS	Front air control	BCM/SEC	MHFR/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	CAN 7
HCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2080E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## Circuit Check Between TCM and Data Link Connector

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector E143 and ECM connector E16.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector E143 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**  
**4 (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-47, "Work Flow"](#).  
 NG >> Repair harness.



## ECM Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector E16.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector E16 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM connector E16 and TCM connector E143.



**TCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector E143.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between TCM connector E143 terminal 3 (L) and terminal 4 (P).

**3 (L) - 4 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace TCM.  
 NG >> Repair harness between TCM connector E143 and ECM connector E16.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

**20 (L) - 23 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and ECM connector E16.



## Front Air Control Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect front air control connector M50.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between front air control connector M50 terminal 34 (L) and terminal 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control connector M50 and data link connector M22.



## Display Unit Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display unit connector M93.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display unit connector M93 terminal 14 (L) and terminal 16 (P).

**14 (L) - 16 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace display unit.  
 NG >> Repair harness between display unit connector M93 and data link connector M22.





**Data Link Connector Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66 Ω**

**OK or NG**

- OK >> Diagnose again. Refer to [LAN-47, "Work Flow"](#) .  
 NG >> Repair harness between data link connector M22 and BCM connector M18.

**BCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66 Ω**

**OK or NG**

- OK >> Replace BCM.  
 NG >> Repair harness between BCM connector M18 and data link connector M22.



**Combination Meter Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect combination meter connector M23.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between combination meter connector M23 terminal 27 (L) and terminal 28 (P).

**27 (L) - 28 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter connector M23 and data link connector M22.

**IPDM E/R Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132  $\Omega$**

OK or NG

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R connector E121 and data link connector M22.



**CAN Communication Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - TCM (Transmission control module)
  - ABS actuator and electric unit (control unit)
  - Front air control
  - Display unit
  - BCM (Body control module)
  - Combination meter
  - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

OK &gt;&gt; GO TO 2.

NG &gt;&gt; Repair or replace as necessary.

**2. CHECK HARNESS FOR SHORTED CIRCUITS**


With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

OK or NG

OK &gt;&gt; GO TO 3.

NG &gt;&gt; Repair the harness.

**3. CHECK HARNESS FOR SHORT TO GROUND**

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-68, "Component Inspection"](#).

NG &gt;&gt; Repair the harness.


**IPDM E/R Ignition Relay Circuit Check**

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

**Component Inspection****ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Disconnect ECM and IPDM E/R harness connectors.
- Check resistance between ECM terminals 94 and 86.  
**94 - 86 : Approx. 108 - 132  $\Omega$**
- Check resistance between IPDM E/R terminals 48 and 49.  
**48 - 49 : Approx. 108 - 132  $\Omega$**



## CAN SYSTEM (TYPE 3)


### System Description

UKS0020X

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS0020Y



BKIA0096E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

# CAN SYSTEM (TYPE 3)

[CAN]

## Schematic

UKS0020Z



BKWA0348E

# CAN SYSTEM (TYPE 3)


[CAN]

## Wiring Diagram — CAN —


UKS002P0

LAN-CAN-07

■ ■ ■ : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M








BKWA0335E

# CAN SYSTEM (TYPE 3)

[CAN]

LAN-CAN-08



REFER TO THE FOLLOWING.  
**M18** - ELECTRICAL UNITS

BKWA0336E




# CAN SYSTEM (TYPE 3)


[CAN]

LAN-CAN-09

▬ : DATA LINE



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M



BKWA0337E


# CAN SYSTEM (TYPE 3)

[CAN]


UKS00201

## Work Flow


- When there are no indications of "TRANSMISSION", "BCM" or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "ABS", "BCM" and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "ABS", "BCM" and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-76, "CHECK SHEET"](#) .
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG" or "UNKWN" in the check sheet table.

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MNTR							
			ECM	TCM	VDC/TCS/ABS	Receive diagnosis		METER/M&A	IPDM E/R	
						Front air control	BCM/SEC			
ENGINE	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2056E

## CAN SYSTEM (TYPE 3)

[CAN]

---

**NOTE:**

- If “NG” is displayed on “INITIAL DIAG (Initial diagnosis)” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.  
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.

6. Check CAN communication line of the navigation system.
7. Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-133](#), "[CHECK SHEET](#)".
8. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.

**NOTE:**

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.

9. According to the Check Sheet Results, start inspection.

A

B

C

D

E

F

G

H

I

J

LAN

L

M

# CAN SYSTEM (TYPE 3)

[CAN]

## CHECK SHEET

### NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

#### Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VDC/TCS/ ABS	Front air control	BCM/SEC	METER/ M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

Symptoms:

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR  
check sheet

SKIB2040E

# CAN SYSTEM (TYPE 3)

[CAN]

<p>Attach copy of ENGINE SELF-DIAG RESULTS</p>	<p>Attach copy of TRANSMISSION SELF-DIAG RESULTS</p>	<p>Attach copy of ABS SELF-DIAG RESULTS</p>
<p>Attach copy of BCM SELF-DIAG RESULTS</p>	<p>Attach copy of IPDM E/R SELF-DIAG RESULTS</p>	
<p>Attach copy of ENGINE CAN DIAG SUPPORT MNTR</p>	<p>Attach copy of TRANSMISSION CAN DIAG SUPPORT MNTR</p>	<p>Attach copy of ABS CAN DIAG SUPPORT MNTR</p>
<p>Attach copy of BCM CAN DIAG SUPPORT MNTR</p>	<p>Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR</p>	

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

SKIB2041E


## CHECK SHEET RESULTS

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-89, "Circuit Check Between TCM and Data Link Connector"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDZ/TCS/ABS	Front air control	BCM/SEC	ME-TE/R/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3 ✓	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN ✓	-	-	-	UNKWN	-	-

SKIB2042E



SKIB2057E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 2

Check ECM circuit. Refer to [LAN-89, "ECM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIC/ICS/ABS	Front air control	BCM/SEC	MI-TER/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
ECM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2043E



SKIB2058E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 3

Check TCM circuit. Refer to [LAN-90, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDOTCS/ABS	Front air control	BCM/SEC	MF-TE/R/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
ECM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2044E



SKIB2059E



# CAN SYSTEM (TYPE 3)


[CAN]

## Case 4

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-90, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SEC	MF-IFR/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2045E



# CAN SYSTEM (TYPE 3)

[CAN]


## Case 5

Check front air control circuit. Refer to [LAN-91, "Front Air Control Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDOTCS/ABS	Front air control	BCM/SEC	MF-TE/R/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2046E

//// : Malfunctioning part




SKIB2061E

## Case 6

Check display control unit circuit. Refer to [LAN-91, "Display Control Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIC/ICS/ABS	Front air control	BCM/SEC	MH-ER/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN
Display control unit	-	CAN COMM	CAN RRC 1	CAN RRC 3	-	-	CAN RRC 4	CAN RRC 2	CAN RRC 5	CAN RRC 7
ECM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2047E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN


## Case 7

Check data link connector circuit. Refer to [LAN-92, "Data Link Connector Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDOTCS/ABS	Front air control	BCM/SEC	MF-TE/R/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	Not operation ✓	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
BCM	Not operation ✓	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	Not operation ✓	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2048E

//// : Malfunctioning part



SKIB2063E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 8

Check BCM circuit. Refer to [LAN-92, "BCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIC/ICS/ABS	Front air control	BCM/SEC	MI-IE/R M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	✓	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2049E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN


## Case 9

Check combination meter circuit. Refer to [LAN-93, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VIDOTCS/ABS	Front air control	BCM/SEC	MF-TE/R/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2050E

//// : Malfunctioning part



SKIB2065E

# CAN SYSTEM (TYPE 3)


[CAN]

## Case 10

Check IPDM E/R circuit. Refer to [LAN-93, "IPDM E/R Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VID/LCS/ABS	Front air control	BCM/SEC	MH-ER/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2051E



## Case 11

Check CAN communication circuit. Refer to [LAN-94, "CAN Communication Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				ECM	TCM	VID/LCS/ABS	Front air control	BCM/SEC	MH-ER/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2052E

# CAN SYSTEM (TYPE 3)

[CAN]

## Case 12

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-94, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				E-CM	TCM	VIDC/TCSP/ABS	Front air control	BCM/SEC	M-TEP/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2053E

## Case 13

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-94, "IPDM E/R Ignition Relay Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN								
		Initial diagnosis	Transmit diagnosis	Receive diagnosis						
				E-CM	TCM	VIDC/TCSP/ABS	Front air control	BCM/SEC	M-TEP/M&A	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-

SKIB2054E



**Circuit Check Between TCM and Data Link Connector****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector E143 and ECM connector E16.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check continuity between TCM connector E143 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**  
**4 (P) - 14 (P) : Continuity should exist.**

**OK or NG**

- OK >> Connect all connectors and diagnose again. Refer to [LAN-74, "Work Flow"](#).  
 NG >> Repair harness.

**ECM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector E16.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between ECM connector E16 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

**OK or NG**

- OK >> Replace ECM.  
 NG >> Repair harness between ECM connector E16 and TCM connector E143.



**TCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector E143.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between TCM connector E143 terminal 3 (L) and terminal 4 (P).

**3 (L) - 4 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace TCM.  
 NG >> Repair harness between TCM connector E143 and ECM connector E16.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 20 (L) and terminal 23 (P).

**20 (L) - 23 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and ECM connector E16.



**Front Air Control Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect front air control connector M50.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between front air control connector M50 terminal 34 (L) and terminal 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace front air control.  
 NG >> Repair harness between front air control connector M50 and data link connector M22.

**Display Control Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display control unit connector M95.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between display control unit connector M95 terminal 25 (L) and terminal 26 (P).

**25 (L) - 26 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace display control unit.  
 NG >> Repair harness between display control unit connector M95 and data link connector M22.



**Data Link Connector Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Diagnose again. Refer to [LAN-74, "Work Flow"](#) .  
 NG >> Repair harness between data link connector M22 and BCM connector M18.



UKS0020Q

**BCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66  $\Omega$**

OK or NG

- OK >> Replace BCM.  
 NG >> Repair harness between BCM connector M18 and data link connector M22.



WKIA0955E

**Combination Meter Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect combination meter connector M23.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between combination meter connector M23 terminal 27 (L) and terminal 28 (P).

**27 (L) - 28 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter connector M23 and data link connector M22.

**IPDM E/R Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132  $\Omega$**

**OK or NG**

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R connector E121 and data link connector M22.



## CAN Communication Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - TCM (Transmission control module)
  - ABS actuator and electric unit (control unit)
  - Front air control
  - Display control unit
  - BCM (Body control module)
  - Combination meter
  - IPDM E/R (Intelligent power distribution module engine room)

OK or NG

OK >> GO TO 2.

NG >> Repair or replace as necessary.

### 2. CHECK HARNESS FOR SHORTED CIRCUITS


With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

OK or NG

OK >> GO TO 3.

NG >> Repair the harness.



### 3. CHECK HARNESS FOR SHORT TO GROUND

Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.


**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

OK or NG

OK >> Check ECM and IPDM E/R. Refer to [LAN-95, "Component Inspection"](#).

NG >> Repair the harness.




### IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#).
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#).

**Component Inspection****ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Disconnect ECM and IPDM E/R harness connectors.
- Check resistance between ECM terminals 94 and 86.  
**94 - 86 : Approx. 108 - 132  $\Omega$**
- Check resistance between IPDM E/R terminals 48 and 49.  
**48 - 49 : Approx. 108 - 132  $\Omega$**



A

B

C

D

E

F

G

H

I

J

LAN

L

M

## CAN SYSTEM (TYPE 4)

PFP:23710


### System Description

UKS002NY

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS002NZ






# CAN SYSTEM (TYPE 4)

[CAN]

## Schematic

UKS00200



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

BKWA0347E

# CAN SYSTEM (TYPE 4)



[CAN]

UKS00201

## Wiring Diagram — CAN —

### LAN-CAN-10

▬▬▬ : DATA LINE












BKWA0339E

# CAN SYSTEM (TYPE 4)

[CAN]

## LAN-CAN-11





REFER TO THE FOLLOWING.  
(M18) - ELECTRICAL UNITS

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

BKWA0340E

LAN-CAN-12

▬ : DATA LINE




# CAN SYSTEM (TYPE 4)

[CAN]


UKS00202

## Work Flow


- When there are no indications of "TRANSMISSION", "BCM", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "ABS", "BCM", "AUTO DRIVE POS." and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "ABS", "BCM", "AUTO DRIVE POS." and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-103. "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG" or "UNKWN" in the check sheet table.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	ECM	TCM	VDC/TCS/ABS	Receive diagnosis Front air control	BCM/SEC	METER/M&A	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	-	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2561E

---

**NOTE:**

- If “NG” is displayed on “INITIAL DIAG (Initial diagnosis)” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
  - The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.  
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.
6. Check CAN communication line of the integrated display system. Refer to [AV-109, "AV Communication Line Check"](#) .
  7. Attach the CAN DIAG MONITOR check sheet onto the check sheet. Refer to [LAN-103, "CHECK SHEET"](#) .
  8. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG MONITOR check sheet.

**NOTE:**

If “NG” is displayed on “CAN COMM” as “CAN DIAG MNTR” for the diagnosed control unit, replace the control unit.

9. According to the Check Sheet Results, start inspection.

# CAN SYSTEM (TYPE 4)

[CAN]

## CHECK SHEET

### NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" as "CAN DIAG MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
ECM	TCM			VDC/TCS/ABS	Front air control	BCM/SEC	METER/M&A	STRG	IPDM E/R		
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	-	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

Symptoms:

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display unit  
CAN DIAG MONITOR  
check sheet

SKIB2006E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 4)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of TRANSMISSION SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS
Attach copy of BCM SELF-DIAG RESULTS	Attach copy of AUTO DRIVE POS. SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of TRANSMISSION CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR
Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of AUTO DRIVE POS. CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

SKIB1971E



## CHECK SHEET RESULTS

### NOTE:


If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" as "CAN DIAG MNTR" for the diagnosed control unit, replace the control unit.

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-118, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	VDC/TCU/ABS	Front air control	BCM/SH-C	METER/M&A	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	✓ CAN 3	-	-	CAN 4	CAN 2	CAN 5	-	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2630E




## Case 2

Check ECM circuit. Refer to [LAN-118, "ECM Circuit Check"](#) .

SEI HCT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	ICM	VDC/TCS/ AHS	Front air control	BCM/SF-C	METER/ MSA	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
AHS	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
Display unit	-	CAN COMM	CAN 1	CAN 3			CAN 4	CAN 2	CAN 5		CAN 7
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
IPDM E/R	No indication	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN

WKIA2631E




SKIB2020E

## Case 3

Check TCM circuit. Refer to [LAN-119, "TCM Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SF-C	ME-TR/M&A	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	-	CAN 7	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-

WKIA2633E



SKIB2021E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 4

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-119, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MONTR									
			Receive diagnosis									
			ECM	ICM	VDC/CS/ABS	Front air control	BCM/SF-C	METER/MRA	STRG	IPDM E/R		
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN	-	-
AHS	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 7	CAN 5	-	-	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-

SKIB2936E




SKIB2022E

## Case 5

Check front air control circuit. Refer to [LAN-120, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SH-C	METER/M&A	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	✓14	CAN 2	CAN 5	-	CAN 7	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-

WKIA2640E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 6

Check display unit circuit. Refer to [LAN-120, "Display Unit Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	VDC/TCS/AHS	Front air control	BCM/SF-C	METER/MKA	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
AHS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	UNKWN
Display unit	-	CAN COMM	✓ <sup>1</sup>	✓ <sup>3</sup>	-	-	✓ <sup>4</sup>	✓ <sup>2</sup>	✓ <sup>5</sup>	-	✓ <sup>7</sup>
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2634E



SKIB2024E

# CAN SYSTEM (TYPE 4)


[CAN]

## Case 7

Check data link connector circuit. Refer to [LAN-121, "Data Link Connector Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SF-C	ME-TR/M&A	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
TRANSMISSION	Not applicable	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3			CAN 4	CAN 2	CAN 5	-	CAN 7
BCM	Not applicable	NG	UNKWN	UNKWN			-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	Not applicable	NG	UNKWN	UNKWN	UNKWN		-	UNKWN	UNKWN	-	-
IPDM E/R	Not applicable	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2635E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 8

Check BCM circuit. Refer to [LAN-121, "BCM Circuit Check"](#).

SELECTION SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	VDC/TCS/AHS	Front air control	BCM/SI-C	METER/ MKA	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-
AHS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	UNKWN	CAN 5	-	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	UNKWN	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2636E



SKIB2026E




## Case 9

Check combination meter circuit. Refer to [LAN-122, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SF-C	METER/M&A	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	-	UNKWN	-	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-

WKIA2637E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 10

Check steering angle sensor circuit. Refer to [LAN-122, "Steering Angle Sensor Circuit Check"](#) .

SELECTION SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	VDC/TCS/AHS	Front air control	BCM/SF-C	METER/MKA	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-	-
AHS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	-	CAN 7	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-

WKIA2638E




SKIB2028E

## Case 11

Check driver seat control unit circuit. Refer to [LAN-123, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SF-C	METER/M&A	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	-	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2639E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 12

Check IPDM E/R circuit. Refer to [LAN-123, "IPDM E/R Circuit Check"](#) .

SELF-DIAGNOSTIC SYSTEM screen		CAN DIAG SUPPORT MNTNR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
				ECM	ICM	VDC/TCS/ABS	Front air control	BCM/IS-C	METER/MXA	STRG	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	-	✓
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2641E



## Case 13

Check CAN communication circuit. Refer to [LAN-124, "CAN Communication Circuit Check"](#) .

SELF-DIAGNOSTIC SYSTEM screen		CAN DIAG SUPPORT MNTNR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							IPDM E/R
				ECM	ICM	VDC/TCS/ABS	Front air control	BCM/IS-C	METER/MXA	STRG	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-
Display unit	-	CAN COMM	CAN 1	✓3	-	-	✓4	✓2	✓5	-	✓1
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

SKIB2140E

# CAN SYSTEM (TYPE 4)

[CAN]

## Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-124, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	ICM	VDC/TCS/ABS	Front air control	BCM/SF-C	ME-TR/M&A	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN ✓	UNKWN ✓	-	-	UNKWN	-	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	-	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN ✓	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2643E

## Case 14

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-124, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	ICM	VDC/TCS/ABS	Front air control	BCM/SF-C	ME-TR/M&A	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN ✓	-	UNKWN	-	-	UNKWN ✓	-	-
ABS	-	NG	UNKWN	UNKWN ✓	UNKWN	-	-	-	-	UNKWN ✓	-
Display unit	-	CAN COMM	CAN 1	CAN 3	-	-	CAN 4	CAN 2	CAN 5	-	CAN 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2644E

## Circuit Check Between TCM and Data Link Connector

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector E143 and ECM connector E16.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector E143 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**  
**4 (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-101, "Work Flow"](#).  
 NG >> Repair harness.



## ECM Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector E16.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector E16 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM connector E16 and TCM connector E143.



**TCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector E143.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between TCM connector E143 terminal 3 (L) and terminal 4 (P).

**3 (L) - 4 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace TCM.  
 NG >> Repair harness between TCM connector E143 and ECM connector E16.

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 7 (L) and terminal 9 (P).

**7 (L) - 9 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and ECM connector E16.



## Front Air Control Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect front air control connector M50.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between front air control connector M50 terminal 34 (L) and terminal 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control connector M50 and data link connector M22.



## Display Unit Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display unit connector M93.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display unit connector M93 terminal 14 (L) and terminal 16 (P).

**14 (L) - 16 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace display unit.  
 NG >> Repair harness between display unit connector M93 and data link connector M22.





**Data Link Connector Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Diagnose again. Refer to [LAN-101, "Work Flow"](#) .  
 NG >> Repair harness between data link connector M22 and BCM connector M18.

**BCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace BCM.  
 NG >> Repair harness between BCM connector M18 and data link connector M22.



## Combination Meter Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect combination meter connector M23.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between combination meter connector M23 terminal 27 (L) and terminal 28 (P).

**27 (L) - 28 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace combination meter.  
 NG >> Repair harness between combination meter connector M23 and data link connector M22.



## Steering Angle Sensor Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect steering angle sensor connector M47.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between steering angle sensor connector M47 terminal 4 (L) and terminal 5 (P).

**4 (L) - 5 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace steering angle sensor.  
 NG >> Repair harness between steering angle sensor connector M47 and data link connector M22.



**Driver Seat Control Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between driver seat control unit connector P2 terminal 3 (L) and terminal 19 (P).

**3 (L) - 19 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace driver seat control unit.  
 NG >> Repair harness between driver seat control unit connector P2 and data link connector M22.

**IPDM E/R Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132  $\Omega$**

**OK or NG**

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R connector E121 and data link connector M22.



## CAN Communication Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - TCM (Transmission control module)
  - ABS actuator and electric unit (control unit)
  - Front air control
  - Display unit
  - BCM (Body control module)
  - Combination meter
  - Steering angle sensor
  - Driver seat control unit
  - IPDM E/R (Intelligent power distribution module engine room)

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair the harness.



SKIA6868E

### 3. CHECK HARNESS FOR SHORT TO GROUND


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

#### OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-125, "Component Inspection"](#) .  
 NG >> Repair the harness.



SKIA6874E


### IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

**Component Inspection****ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Disconnect ECM and IPDM E/R harness connectors.
- Check resistance between ECM terminals 94 and 86.  
**94 - 86 : Approx. 108 - 132  $\Omega$**
- Check resistance between IPDM E/R terminals 48 and 49.  
**48 - 49 : Approx. 108 - 132  $\Omega$**



A

B

C

D

E

F

G

H

I

J

LAN

L

M

## CAN SYSTEM (TYPE 5)


### System Description

UKS002NE

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### Component Parts and Harness Connector Location

UKS002NF




WKIA1100E

# CAN SYSTEM (TYPE 5)

[CAN]

## Schematic

UKS002NG



A

B

C

D

E

F

G

H

I

J

LAN

L

M

WKWA0587E

# CAN SYSTEM (TYPE 5)



[CAN]

## Wiring Diagram — CAN —

UKS002NH

### LAN-CAN-13

▬▬▬ : DATA LINE




BKWA0343E



# CAN SYSTEM (TYPE 5)


[CAN]

## LAN-CAN-14



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN





REFER TO THE FOLLOWING.  
M18 - ELECTRICAL UNITS

\*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF PG SECTION.

BKWA0346E

LAN-CAN-15

▬ : DATA LINE




# CAN SYSTEM (TYPE 5)

[CAN]


UKS002NI

## Work Flow


- When there are no indications of "TRANSMISSION", "BCM", "AUTO DRIVE POS." or "IPDM E/R" on "SELECT SYSTEM" display of CONSULT-II, print the "SELECT SYSTEM".



- Print all the data of "SELF-DIAG RESULTS" for "ENGINE", "TRANSMISSION", "ABS", "BCM", "AUTO DRIVE POS." and "IPDM E/R" displayed on CONSULT-II.



- Print all the data of "CAN DIAG SUPPORT MNTR" for "ENGINE", "TRANSMISSION", "ABS", "BCM", "AUTO DRIVE POS.", and "IPDM E/R" displayed on CONSULT-II.



- Attach the printed sheet of "SELECT SYSTEM", "SELF-DIAG RESULTS" and "CAN DIAG SUPPORT MNTR" onto the check sheet. Refer to [LAN-133, "CHECK SHEET"](#).
- Based on the indications of "SELECT SYSTEM" and the results of "CAN DIAG SUPPORT MNTR", put marks onto the items with "No indication", "NG" or "UNKWN" in the check sheet table.

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	ECM	TCM	VDC/TCS/ABS	Receive diagnosis Front air control	BCM/SEC	METER/M&A	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2562E

---

**NOTE:**

- If “NG” is displayed on “INITIAL DIAG (Initial diagnosis)” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.
- The “CAN DIAG SUPPORT MNTR” items which are not in check sheet table are not related to diagnostic procedure on service manual.  
Therefore, it is not necessary to check the status of the “CAN DIAG SUPPORT MNTR” items not in check sheet table.

6. Check CAN communication line of the navigation system.
7. Attach the CAN DIAG SUPPORT MONITOR check sheet onto the check sheet. Refer to [LAN-133, "CHECK SHEET"](#).
8. Mark the “NG” or “UNKWN” item of the check sheet table from the result of CAN DIAG SUPPORT MONITOR check sheet.

**NOTE:**

If “NG” is displayed on “CAN COMM” as “CAN DIAG SUPPORT MNTR” for the diagnosed control unit, replace the control unit.

9. According to the Check Sheet Results, start inspection.

# CAN SYSTEM (TYPE 5)

[CAN]

## CHECK SHEET

### NOTE:

If "NG" is displayed on "INITIAL DIAG (Initial diagnosis)" or "CAN COMM" as "CAN DIAG SUPPORT MNTR" for the diagnosed control unit, replace the control unit.

Check sheet table

SELECT SYSTEM screen	CAN DIAG SUPPORT MNTR									
	Initial diagnosis	Transmit diagnosis	ECM	TCM	VDC/TCS/ABS	Receive diagnosis Front air control	BCM/SEC	METER/M&A	STRG	IPDM E/R
ENGINE	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
ABS	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-
Display control unit	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7
BCM No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS No indication	NG	UNKWN	-	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

Symptoms:

Attach copy of  
SELECT SYSTEM

Attach copy of  
SELECT SYSTEM

Attach copy of  
display control unit  
CAN DIAG SUPPORT MONITOR  
check sheet

SKIB1970E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 5)

[CAN]

Attach copy of ENGINE SELF-DIAG RESULTS	Attach copy of TRANSMISSION SELF-DIAG RESULTS	Attach copy of ABS SELF-DIAG RESULTS
Attach copy of BCM SELF-DIAG RESULTS	Attach copy of AUTO DRIVE POS. SELF-DIAG RESULTS	Attach copy of IPDM E/R SELF-DIAG RESULTS
Attach copy of ENGINE CAN DIAG SUPPORT MNTR	Attach copy of TRANSMISSION CAN DIAG SUPPORT MNTR	Attach copy of ABS CAN DIAG SUPPORT MNTR
Attach copy of BCM CAN DIAG SUPPORT MNTR	Attach copy of AUTO DRIVE POS. CAN DIAG SUPPORT MNTR	Attach copy of IPDM E/R CAN DIAG SUPPORT MNTR

SKIB1971E


## CHECK SHEET RESULTS

### Case 1

Check harness between TCM and data link connector. Refer to [LAN-148, "Circuit Check Between TCM and Data Link Connector"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNT'R										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SF-C	METER/MSA	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	UNKWN	UNKWN	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN	-	-	UNKWN
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-	-

WKIA2660E




SKIB2007E

## Case 2

Check ECM circuit. Refer to [LAN-148, "ECM Circuit Check"](#) .

SEI HCT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	ICM	VDC/TCS/ABS	Front air control	BCM/SE-C	METER/MSA	STRG	IPDM E/R
ENGINE	-	NG	UNKWN ✓	-	UNKWN ✓	UNKWN ✓	-	UNKWN ✓	-	UNKWN ✓	UNKWN ✓
TRANSMISSION	No indication	NG	UNKWN	UNKWN ✓	-	UNKWN	-	UNKWN	-	UNKWN	-
AHS	-	NG	UNKWN	UNKWN ✓	UNKWN	-	-	-	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN ✓	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN ✓	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN ✓	-	-	-	UNKWN	-	-	-

WKIA2661E



SKIB2008E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 3

Check TCM circuit. Refer to [LAN-149, "TCM Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SF-C	METER/M&A	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
TRANSMISSION	No indication ✓	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	UNKWN	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-

WKIA2663E



SKIB2009E


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
LAN  
L  
M

## Case 4

Check ABS actuator and electric unit (control unit) circuit. Refer to [LAN-149, "ABS Actuator and Electric Unit \(Control Unit\) Circuit Check"](#) .

SELECT SYSTEM screen	Initial diagnosis	Transmit diagnosis	CAN DIAG SUPPORT MONTR								
			Receive diagnosis								
			ECM	ICM	VDC/CS/ABS	Front air control	BCM/SF-C	METER/MRA	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
AHS	-	NG	UNKWN	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

SKIB2937E




SKIB2010E

## Case 5

Check front air control circuit. Refer to [LAN-150, "Front Air Control Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SF-C	METER/M&A	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-

WKIA2670E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 6

Check display control unit circuit. Refer to [LAN-150, "Display Control Unit Circuit Check"](#) .

SEI HCT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	VDC/TCS/AHS	Front air control	BCM/SF-C	METER/MKA	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
AHS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-
Display control unit	-	CAN COMM	CAN RC 1 ✓	CAN RC 3 ✓	-	-	CAN RC 4 ✓	CAN RC 2 ✓	CAN RC 5 ✓	-	CAN RC 7 ✓
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	UNKWN	-	-	UNKWN	-	-	-

WKIA264E



SKIB2012E

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 7

Check data link connector circuit. Refer to [LAN-151, "Data Link Connector Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SF-C	METER/M&A	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
TRANSMISSION	No illumination ✓	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7	-
BCM	No illumination ✓	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN	-
AUTO DRIVE POS.	No illumination ✓	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	-
IPDM E/R	No illumination ✓	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-

WKIA2665E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 8

Check BCM circuit. Refer to [LAN-151, "BCM Circuit Check"](#).

SEI HCT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	VDC/TCS/AHS	Front air control	BCM/SE-C	METER/ MKA	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	✓	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN	-	-
AHS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	✓	CAN CIRC 5	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	✓	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	✓	-	-	-

WKIA266E




SKIB2014E

## Case 9

Check combination meter circuit. Refer to [LAN-152, "Combination Meter Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR										
		Initial diagnosis	Transmit diagnosis	Receive diagnosis								
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SH-C	METER/M&A	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7	-
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN	-
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-	-

WKIA2667E



SKIB2015E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M


LAN

## Case 10

Check steering angle sensor circuit. Refer to [LAN-152, "Steering Angle Sensor Circuit Check"](#) .

SEI HCT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	VDC/TCS/ AHS	Front air control	BCM/SE-C	METER/ MKA	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
AHS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA268E



SKIB2016E



# CAN SYSTEM (TYPE 5)


[CAN]

## Case 11

Check driver seat control unit circuit. Refer to [LAN-153, "Driver Seat Control Unit Circuit Check"](#) .

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTR									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	TCM	VDC/TCS/ABS	Front air control	BCM/SF-C	METER/M&A	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2669E



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

# CAN SYSTEM (TYPE 5)


[CAN]

## Case 12

Check IPDM E/R circuit. Refer to [LAN-153, "IPDM E/R Circuit Check"](#) .

SELECTION SYSTEM screen	CAN DIAG SUPPORT MNTNR										
	Initial diagnosis	Transmit diagnosis	Receive diagnosis								
			ECM	ICM	VDC/TCS/ABS	Front air control	BCM/SH-C	METER/MSA	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	-	UNKWN	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
AHS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2671E



SKIB2018E

## Case 13

Check CAN communication circuit. Refer to [LAN-154, "CAN Communication Circuit Check"](#) .

SELECTION SYSTEM screen	CAN DIAG SUPPORT MNTNR										
	Initial diagnosis	Transmit diagnosis	Receive diagnosis								
			ECM	ICM	VDC/TCS/ABS	Front air control	BCM/SH-C	METER/MSA	STRG	IPDM E/R	
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	UNKWN	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
AHS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	UNKWN	-	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

SKIB2141E

# CAN SYSTEM (TYPE 5)

[CAN]

## Case 14

Check IPDM E/R ignition relay circuit continuously sticks "OFF". Refer to [LAN-154, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	ICM	VDC/TCS/ABS	Front air control	BCM/SF-C	ME-TR/M&A	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	-	-	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	-	UNKWN	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2673E

## Case 15

Check IPDM E/R ignition relay circuit continuously sticks "ON". Refer to [LAN-154, "IPDM E/R Ignition Relay Circuit Check"](#).

SELECT SYSTEM screen		CAN DIAG SUPPORT MNTN									
		Initial diagnosis	Transmit diagnosis	Receive diagnosis							
				ECM	ICM	VDC/TCS/ABS	Front air control	BCM/SF-C	ME-TR/M&A	STRG	IPDM E/R
ENGINE	-	NG	UNKWN	-	UNKWN	UNKWN	-	-	UNKWN	-	UNKWN
TRANSMISSION	No indication	NG	UNKWN	UNKWN	-	UNKWN	-	-	UNKWN	-	-
ABS	-	NG	UNKWN	UNKWN	UNKWN	-	-	-	-	UNKWN	-
Display control unit	-	CAN COMM	CAN CIRC 1	CAN CIRC 3	-	-	CAN CIRC 4	CAN CIRC 2	CAN CIRC 5	-	CAN CIRC 7
BCM	No indication	NG	UNKWN	UNKWN	-	-	-	-	UNKWN	-	UNKWN
AUTO DRIVE POS.	No indication	NG	UNKWN	UNKWN	UNKWN	-	-	UNKWN	UNKWN	-	-
IPDM E/R	No indication	-	UNKWN	UNKWN	-	-	-	UNKWN	-	-	-

WKIA2674E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M

LAN

## Circuit Check Between TCM and Data Link Connector

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector E143 and ECM connector E16.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check continuity between TCM connector E143 terminals 3 (L), 4 (P) and data link connector M22 terminals 6 (L), 14 (P).

- 3 (L) - 6 (L) : Continuity should exist.**  
**4 (P) - 14 (P) : Continuity should exist.**

OK or NG

- OK >> Connect all connectors and diagnose again. Refer to [LAN-131, "Work Flow"](#).  
 NG >> Repair harness.



## ECM Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ECM connector E16.
4. Check the terminals for deformation, disconnection, looseness or damage.

OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between ECM connector E16 terminal 94 (L) and terminal 86 (P).

- 94 (L) - 86 (P) : Approx. 108 - 132 Ω**

OK or NG

- OK >> Replace ECM.  
 NG >> Repair harness between ECM connector E16 and TCM connector E143.



**TCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect TCM connector E143.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between TCM connector E143 terminal 3 (L) and terminal 4 (P).

**3 (L) - 4 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace TCM.  
 NG >> Repair harness between TCM connector E143 and ECM connector E16.



SKIB1816E

**ABS Actuator and Electric Unit (Control Unit) Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect ABS actuator and electric unit (control unit) connector E125.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between ABS actuator and electric unit (control unit) connector E125 terminal 7 (L) and terminal 9 (P).

**7 (L) - 9 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace ABS actuator and electric unit (control unit).  
 NG >> Repair harness between ABS actuator and electric unit (control unit) connector E125 and ECM connector E16.



SKIB1820E

## Front Air Control Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect front air control connector M50.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between front air control connector M50 terminal 34 (L) and terminal 35 (P).

**34 (L) - 35 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace front air control.  
 NG >> Repair harness between front air control connector M50 and data link connector M22.



## Display Control Unit Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect display control unit connector M95.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between display control unit connector M95 terminal 25 (L) and terminal 26 (P).

**25 (L) - 26 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace display control unit.  
 NG >> Repair harness between display control unit connector M95 and data link connector M22.



**Data Link Connector Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Check data link connector M22 terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between data link connector M22 terminal 6 (L) and terminal 14 (P).

**6 (L) - 14 (P) : Approx. 54 - 66 Ω**

**OK or NG**

- OK >> Diagnose again. Refer to [LAN-131, "Work Flow"](#) .  
 NG >> Repair harness between data link connector M22 and BCM connector M18.

**BCM Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect BCM connector M18.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between BCM connector M18 terminal 39 (L) and terminal 40 (P).

**39 (L) - 40 (P) : Approx. 54 - 66 Ω**

**OK or NG**

- OK >> Replace BCM.  
 NG >> Repair harness between BCM connector M18 and data link connector M22.



## Combination Meter Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect combination meter connector M23.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between combination meter connector M23 terminal 27 (L) and terminal 28 (P).

**27 (L) - 28 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace combination meter.  
NG >> Repair harness between combination meter connector M23 and data link connector M22.



## Steering Angle Sensor Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect steering angle sensor connector M47.
4. Check the terminals for deformation, disconnection, looseness or damage.

#### OK or NG

- OK >> GO TO 2.  
NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR OPEN CIRCUIT

Check resistance between steering angle sensor connector M47 terminal 4 (L) and terminal 5 (P).

**4 (L) - 5 (P) : Approx. 54 - 66  $\Omega$**

#### OK or NG

- OK >> Replace steering angle sensor.  
NG >> Repair harness between steering angle sensor connector M47 and data link connector M22.





**Driver Seat Control Unit Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect driver seat control unit connector P2.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between driver seat control unit connector P2 terminal 3 (L) and terminal 19 (P).

**3 (L) - 19 (P) : Approx. 54 - 66  $\Omega$**

**OK or NG**

- OK >> Replace driver seat control unit.  
 NG >> Repair harness between driver seat control unit connector P2 and data link connector M22.

**IPDM E/R Circuit Check****1. CONNECTOR INSPECTION**

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect IPDM E/R connector E121.
4. Check the terminals for deformation, disconnection, looseness or damage.

**OK or NG**

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


**2. CHECK HARNESS FOR OPEN CIRCUIT**

Check resistance between IPDM E/R connector E121 terminal 48 (L) and terminal 49 (P).

**48 (L) - 49 (P) : Approx. 108 - 132  $\Omega$**

**OK or NG**

- OK >> Replace IPDM E/R.  
 NG >> Repair harness between IPDM E/R connector E121 and data link connector M22.



## CAN Communication Circuit Check

### 1. CONNECTOR INSPECTION

1. Turn ignition switch OFF.
2. Disconnect the negative battery terminal.
3. Disconnect the following module and control unit connectors and check terminals for deformation, disconnection, looseness or damage.
  - ECM
  - TCM (Transmission control module)
  - ABS actuator and electric unit (control unit)
  - Front air control
  - Display control unit
  - BCM (Body control module)
  - Combination meter
  - Steering angle sensor
  - Driver seat control unit
  - IPDM E/R (Intelligent power distribution module engine room)

#### OK or NG

- OK >> GO TO 2.  
 NG >> Repair or replace as necessary.


### 2. CHECK HARNESS FOR SHORTED CIRCUITS

With all module and control unit connectors disconnected, check continuity between data link connector M22 terminals 6 (L) and 14 (P).

**6 (L) - 14 (P) : Continuity should not exist.**

#### OK or NG

- OK >> GO TO 3.  
 NG >> Repair the harness.



SKIA6868E

### 3. CHECK HARNESS FOR SHORT TO GROUND


Check continuity between data link connector M22 terminals 6 (L), 14 (P) and ground.

**6 (L) - Ground : Continuity should not exist.**

**14 (P) - Ground : Continuity should not exist.**

#### OK or NG

- OK >> Check ECM and IPDM E/R. Refer to [LAN-155, "Component Inspection"](#) .  
 NG >> Repair the harness.



SKIA6874E


### IPDM E/R Ignition Relay Circuit Check

Check the following. If no malfunction is found, replace the IPDM E/R.

- IPDM E/R power supply circuit. Refer to [PG-27, "IPDM E/R Power/Ground Circuit Inspection"](#) .
- Ignition power supply circuit. Refer to [PG-12, "IGNITION POWER SUPPLY — IGNITION SW. IN ON AND/OR START"](#) .

**Component Inspection****ECM AND IPDM E/R INTERNAL CIRCUIT INSPECTION**

- Disconnect ECM and IPDM E/R harness connectors.
- Check resistance between ECM terminals 94 and 86.  
**94 - 86 : Approx. 108 - 132  $\Omega$**
- Check resistance between IPDM E/R terminals 48 and 49.  
**48 - 49 : Approx. 108 - 132  $\Omega$**



A

B

C

D

E

F

G

H

I

J

LAN

L

M

