

# SECTION **BRC**

## BRAKE CONTROL SYSTEM

A  
B  
C  
D  
E

### CONTENTS

<b>WITH VDC</b>		<b>BRC</b>
<b>PRECAUTION</b> .....	<b>ABS FUNCTION</b> .....	<b>25</b>
	ABS FUNCTION : System Description .....	25
<b>PRECAUTIONS</b> .....	<b>EBD FUNCTION</b> .....	<b>27</b>
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	EBD FUNCTION : System Description .....	27
Precaution for Procedure without Cowl Top Cover.....	<b>BRAKE LIMITED SLIP DIFFERENTIAL (BLSD) FUNCTION</b> .....	<b>28</b>
Precautions for Removing Battery Terminal .....	BRAKE LIMITED SLIP DIFFERENTIAL (BLSD) FUNCTION : System Description .....	28
Precaution for Brake System .....	<b>DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]</b> .....	<b>30</b>
Precaution for Brake Control System .....	CONSULT Function .....	30
Precaution for Harness Repair .....	<b>ECU DIAGNOSIS INFORMATION</b> .....	<b>35</b>
<b>PREPARATION</b> .....	<b>ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)</b> .....	<b>35</b>
<b>PREPARATION</b> .....	Reference Value .....	35
Special Service Tool .....	Fail-safe .....	37
Commercial Service Tool .....	DTC Inspection Priority Chart .....	37
<b>SYSTEM DESCRIPTION</b> .....	DTC Index .....	38
<b>COMPONENT PARTS</b> .....	<b>WIRING DIAGRAM</b> .....	<b>40</b>
Component Parts Location .....	<b>BRAKE CONTROL SYSTEM</b> .....	<b>40</b>
ABS Actuator and Electric Unit (Control Unit) .....	Wiring Diagram .....	40
Wheel Sensor and Sensor Rotor .....	<b>BASIC INSPECTION</b> .....	<b>46</b>
Stop Lamp Switch .....	<b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....	<b>46</b>
Steering Angle Sensor .....	Work Flow .....	46
Yaw Rate/Side G Sensor .....	Diagnostic Work Sheet .....	47
Brake Fluid Level Switch .....	<b>ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)</b> .....	<b>49</b>
VDC OFF Switch .....	Description .....	49
<b>SYSTEM</b> .....	<b>ADJUSTMENT OF STEERING ANGLE SEN- SOR NEUTRAL POSITION</b> .....	<b>50</b>
System Description .....	Description .....	50
Circuit Diagram .....		
Fail-safe .....		
<b>VDC FUNCTION</b> .....		
VDC FUNCTION : System Description .....		
<b>TCS FUNCTION</b> .....		
TCS FUNCTION : System Description .....		

G  
H  
I  
J  
K  
L  
M  
N  
O  
P

Work Procedure .....	50	<b>C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT .....</b>	<b>98</b>
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>52</b>	DTC Logic .....	98
<b>C1101, C1102, C1103, C1104 WHEEL SEN- SOR .....</b>	<b>52</b>	Diagnosis Procedure .....	98
DTC Logic .....	52	<b>C1145, C1146 YAW RATE/SIDE G SENSOR..</b>	<b>100</b>
Diagnosis Procedure .....	53	DTC Logic .....	100
<b>C1105, C1106, C1107, C1108 WHEEL SEN- SOR .....</b>	<b>57</b>	Diagnosis Procedure .....	100
DTC Logic .....	57	<b>C1155 BRAKE FLUID LEVEL SWITCH .....</b>	<b>103</b>
Diagnosis Procedure .....	58	DTC Logic .....	103
<b>C1109 POWER AND GROUND SYSTEM .....</b>	<b>64</b>	Diagnosis Procedure .....	103
DTC Logic .....	64	Component Inspection .....	106
Diagnosis Procedure .....	64	<b>C1161 INCOMPLETE SIDE G SENSOR CAL- IBRATION .....</b>	<b>107</b>
<b>C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) .....</b>	<b>66</b>	DTC Logic .....	107
DTC Logic .....	66	Diagnosis Procedure .....	107
Diagnosis Procedure .....	66	<b>C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION .....</b>	<b>108</b>
<b>C1111 ABS MOTOR, MOTOR RELAY SYS- TEM .....</b>	<b>68</b>	DTC Logic .....	108
DTC Logic .....	68	Diagnosis Procedure .....	108
Diagnosis Procedure .....	68	<b>C1164, C1165 CV SYSTEM .....</b>	<b>110</b>
<b>C1115 WHEEL SENSOR .....</b>	<b>71</b>	DTC Logic .....	110
DTC Logic .....	71	Diagnosis Procedure .....	110
Diagnosis Procedure .....	71	<b>C1166, C1167 SV SYSTEM .....</b>	<b>112</b>
<b>C1116 STOP LAMP SWITCH .....</b>	<b>78</b>	DTC Logic .....	112
DTC Logic .....	78	Diagnosis Procedure .....	112
Diagnosis Procedure .....	79	<b>U1000 CAN COMM CIRCUIT .....</b>	<b>114</b>
Component Inspection .....	82	Description .....	114
<b>C1120, C1122, C1124, C1126 ABS IN VALVE SYSTEM .....</b>	<b>83</b>	DTC Logic .....	114
DTC Logic .....	83	Diagnosis Procedure .....	114
Diagnosis Procedure .....	83	<b>U1002 SYSTEM COMM (CAN) .....</b>	<b>115</b>
<b>C1121, C1123, C1125, C1127 ABS OUT VALVE SYSTEM .....</b>	<b>85</b>	Description .....	115
DTC Logic .....	85	DTC Logic .....	115
Diagnosis Procedure .....	85	Diagnosis Procedure .....	115
<b>C1130 ENGINE SIGNAL .....</b>	<b>87</b>	<b>POWER SUPPLY AND GROUND CIRCUIT ...</b>	<b>117</b>
DTC Logic .....	87	Diagnosis Procedure .....	117
Diagnosis Procedure .....	87	<b>PARKING BRAKE SWITCH .....</b>	<b>120</b>
<b>C1140 ACTUATOR RELAY SYSTEM .....</b>	<b>89</b>	Component Function Check .....	120
DTC Logic .....	89	Diagnosis Procedure .....	120
Diagnosis Procedure .....	89	Component Inspection .....	120
<b>C1142 PRESS SENSOR .....</b>	<b>91</b>	<b>VDC OFF SWITCH .....</b>	<b>122</b>
DTC Logic .....	91	Component Function Check .....	122
Diagnosis Procedure .....	91	Diagnosis Procedure .....	122
<b>C1143 STEERING ANGLE SENSOR .....</b>	<b>94</b>	Component Inspection .....	123
DTC Logic .....	94	<b>ABS WARNING LAMP .....</b>	<b>124</b>
Diagnosis Procedure .....	94	Component Function Check .....	124
<b>C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT .....</b>	<b>98</b>	Diagnosis Procedure .....	124
DTC Logic .....	98	<b>BRAKE WARNING LAMP .....</b>	<b>125</b>
Diagnosis Procedure .....	98	Component Function Check .....	125
<b>C1145, C1146 YAW RATE/SIDE G SENSOR..</b>	<b>100</b>	Diagnosis Procedure .....	125
DTC Logic .....	100	<b>Revision: October 2015</b>	
Diagnosis Procedure .....	100	<b>BRC-2</b>	
<b>C1155 BRAKE FLUID LEVEL SWITCH .....</b>	<b>103</b>		<b>2016 Quest</b>
DTC Logic .....	103		
Diagnosis Procedure .....	103		
Component Inspection .....	106		
<b>C1161 INCOMPLETE SIDE G SENSOR CAL- IBRATION .....</b>	<b>107</b>		
DTC Logic .....	107		
Diagnosis Procedure .....	107		
<b>C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION .....</b>	<b>108</b>		
DTC Logic .....	108		
Diagnosis Procedure .....	108		
<b>C1164, C1165 CV SYSTEM .....</b>	<b>110</b>		
DTC Logic .....	110		
Diagnosis Procedure .....	110		
<b>C1166, C1167 SV SYSTEM .....</b>	<b>112</b>		
DTC Logic .....	112		
Diagnosis Procedure .....	112		
<b>U1000 CAN COMM CIRCUIT .....</b>	<b>114</b>		
Description .....	114		
DTC Logic .....	114		
Diagnosis Procedure .....	114		
<b>U1002 SYSTEM COMM (CAN) .....</b>	<b>115</b>		
Description .....	115		
DTC Logic .....	115		
Diagnosis Procedure .....	115		
<b>POWER SUPPLY AND GROUND CIRCUIT ...</b>	<b>117</b>		
Diagnosis Procedure .....	117		
<b>PARKING BRAKE SWITCH .....</b>	<b>120</b>		
Component Function Check .....	120		
Diagnosis Procedure .....	120		
Component Inspection .....	120		
<b>VDC OFF SWITCH .....</b>	<b>122</b>		
Component Function Check .....	122		
Diagnosis Procedure .....	122		
Component Inspection .....	123		
<b>ABS WARNING LAMP .....</b>	<b>124</b>		
Component Function Check .....	124		
Diagnosis Procedure .....	124		
<b>BRAKE WARNING LAMP .....</b>	<b>125</b>		
Component Function Check .....	125		
Diagnosis Procedure .....	125		

<b>VDC WARNING LAMP</b> .....	126	<b>REMOVAL AND INSTALLATION</b> .....	135	A
Component Function Check .....	126	<b>WHEEL SENSOR</b> .....	135	B
Diagnosis Procedure .....	126	<b>FRONT WHEEL SENSOR</b> .....	135	B
<b>VDC OFF INDICATOR LAMP</b> .....	127	FRONT WHEEL SENSOR : Exploded View .....	135	C
Component Function Check .....	127	FRONT WHEEL SENSOR : Removal and Instal-	135	D
Diagnosis Procedure .....	127	lation .....	135	E
<b>SYMPTOM DIAGNOSIS</b> .....	128	<b>REAR WHEEL SENSOR</b> .....	136	BRC
<b>EXCESSIVE OPERATION FREQUENCY</b> .....	128	REAR WHEEL SENSOR : Exploded View .....	136	G
Description .....	128	REAR WHEEL SENSOR : Removal and Installa-	136	H
Diagnosis Procedure .....	128	tion .....	136	I
<b>UNEXPECTED BRAKE PEDAL REACTION</b> ..	129	<b>SENSOR ROTOR</b> .....	138	J
Description .....	129	<b>FRONT SENSOR ROTOR</b> .....	138	K
Diagnosis Procedure .....	129	FRONT SENSOR ROTOR : Removal and Instal-	138	L
<b>THE BRAKING DISTANCE IS LONG</b> .....	130	lation .....	138	M
Description .....	130	<b>REAR SENSOR ROTOR</b> .....	138	N
Diagnosis Procedure .....	130	REAR SENSOR ROTOR : Removal and Installa-	138	O
<b>DOES NOT OPERATE</b> .....	131	tion .....	138	P
Description .....	131	<b>ABS ACTUATOR AND ELECTRIC UNIT</b>		
Diagnosis Procedure .....	131	<b>(CONTROL UNIT)</b> .....	139	
<b>BRAKE PEDAL VIBRATION OR OPERA-</b>		Exploded View .....	139	
<b>TION SOUND OCCURS</b> .....	132	Removal and Installation .....	139	
Description .....	132	<b>YAW RATE/SIDE/DECEL G SENSOR</b> .....	141	
Diagnosis Procedure .....	132	Exploded View .....	141	
<b>VEHICLE JERKS DURING</b> .....	133	Removal and Installation .....	141	
Description .....	133	<b>STEERING ANGLE SENSOR</b> .....	142	
Diagnosis Procedure .....	133	Removal and Installation .....	142	
<b>NORMAL OPERATING CONDITION</b> .....	134	<b>VDC OFF SWITCH</b> .....	143	
Description .....	134	Removal and Installation .....	143	

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000012406722

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**


Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### Precaution for Procedure without Cowl Top Cover

INFOID:000000012406723

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc to prevent damage to windshield.



#### Precautions for Removing Battery Terminal

INFOID:000000012922828

When disconnecting the battery terminal, pay attention to the following.

- Always use a 12V battery as power source.
- Never disconnect battery terminal while engine is running.


# PRECAUTIONS

[WITH VDC]

## < PRECAUTION >

- When removing the 12V battery terminal, turn OFF the ignition switch and wait at least 30 seconds.
- For vehicles with the engine listed below, remove the battery terminal after a lapse of the specified time:

D4D engine	: 20 minutes	YS23DDT	: 4 minutes
HRA2DDT	: 12 minutes	YS23DDTT	: 4 minutes
K9K engine	: 4 minutes	ZD30DDTi	: 60 seconds
M9R engine	: 4 minutes	ZD30DDTT	: 60 seconds
R9M engine	: 4 minutes		
V9X engine	: 4 minutes		
YD25DDTi	: 2 minutes		



A  
B  
C  
D

### NOTE:

ECU may be active for several tens of seconds after the ignition switch is turned OFF. If the battery terminal is removed before ECU stops, then a DTC detection error or ECU data corruption may occur.

- After high-load driving, if the vehicle is equipped with the V9X engine, turn the ignition switch OFF and wait for at least 15 minutes to remove the battery terminal.

### NOTE:

- Turbocharger cooling pump may operate in a few minutes after the ignition switch is turned OFF.
- Example of high-load driving
  - Driving for 30 minutes or more at 140 km/h (86 MPH) or more.
  - Driving for 30 minutes or more on a steep slope.
- For vehicles with the 2-batteries, be sure to connect the main battery and the sub battery before turning ON the ignition switch.

### NOTE:

If the ignition switch is turned ON with any one of the terminals of main battery and sub battery disconnected, then DTC may be detected.

- After installing the 12V battery, always check "Self Diagnosis Result" of all ECUs and erase DTC.

### NOTE:

The removal of 12V battery may cause a DTC detection error.


## Precaution for Brake System

INFOID:0000000012406725

### WARNING:

Since dust covering the front and rear brakes has an affect on human body, the dust must be removed with a dust collector. Never splatter the dust with an air blow gun.

- Brake fluid use refer to [MA-10, "Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Always confirm the specified tightening torque when installing the brake pipes.
- After pressing the brake pedal more deeply or harder than normal driving, such as air bleeding, check each item of brake pedal. Adjust brake pedal if it is outside the standard value.
- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with a crow-foot (A) and torque wrench (B).
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) harness connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## Precaution for Brake Control System

INFOID:000000012406726

- Always perform a pre-driving check to drive the vehicle.
- Always check speed and safety while driving the vehicle.
- To operate CONSULT while driving, more than one person is required to be in the vehicle to avoid interference to driving and ensure safety.
- Slight vibrations are felt on the brake pedal and the operation noises occur, when VDC function, TCS function, ABS function EBD function or brake limited slip differential (BLSD) function operates. This is not a malfunction because it is caused by VDC function, TCS function, ABS function EBD function or brake limited slip differential (BLSD) function that is normally operated.
- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- Brake stopping distance may become longer than models without ABS function depending on the road conditions, when ABS function is operated on slippery road like rough road, gravel road or snowy road.
- When a malfunction is indicated, always collect information from the customer about conditions of occurrence, estimate cause and perform operation. Check brake booster operation, brake fluid level and brake fluid leakage, as well as electrical system.
- The optimum performance is achieved by control for VDC function, TCS function, ABS function EBD function and brake limited slip differential (BLSD) function when all of brakes, suspensions and tires installed on the vehicle are the specified size and parts. Brake performance and controllability may be negatively affected when other parts than the specified are installed.
- Brake stopping distance may become longer and steering stability may be negatively affected, when tires in different size and combination or other parts than the specified are used.
- When a radio (including wiring), antenna and antenna lead line are located near ABS actuator and electric unit (control unit), a malfunction or improper operation may occur for the control of VDC function, TCS function, ABS function EBD function and brake limited slip differential (BLSD) function.
- When the following items are replaced by other parts than genuine parts or modified, ABS warning lamp, brake warning lamp and VDC warning lamp may turn ON, and the control may not operate normally for VDC function, TCS function, ABS function EBD function and brake limited slip differential (BLSD) function.
  - Suspension component parts (shock absorber, spring, bushing and others)
  - Tire and wheel (other than the specified size)
  - Brake component parts (brake pad, disc rotor, brake caliper and others)
  - Engine component parts (ECM, muffler and others)
  - Body reinforcement component parts (rollover bar, tower bar and others)
- When suspension, tire and brake component parts are excessively worn or deteriorated and the vehicle is driven, ABS warning lamp, brake warning lamp and VDC warning lamp may turn ON, and the control may not operate normally for VDC function, TCS function, ABS function EBD function and brake limited slip differential (BLSD) function.
- ABS warning lamp, brake warning lamp and VDC warning lamp may turn ON, when only front wheel or rear wheel is rotated using a free roller. This is not a malfunction, because it is caused by wheel speed difference between wheel that is rotated and wheel that is not rotated. In this case, perform self-diagnosis, check self-diagnosis results, and erase memory.
- When power supply voltage is not normal, ABS warning lamp, brake warning lamp and VDC warning lamp turn ON. ABS actuator and electric unit (control unit) stops control for VDC function, TCS function, ABS function EBD function and brake limited slip differential (BLSD) function. Ordinary brake operates. After power supply returns to normal, ABS warning lamp, brake warning lamp and VDC warning lamp turn OFF. The control becomes operative for VDC function, TCS function, ABS function EBD function and brake limited slip differential (BLSD) function.
- Brake pedal vibrates and operation sound occurs during sudden acceleration and cornering, when VDC function, TCS function or brake limited slip differential (BLSD) function is operated. This is not a malfunction because it is caused by VDC function, TCS function or brake limited slip differential (BLSD) function that is operated normally.
- VDC warning lamp may turn ON and VDC function, TCS function and brake limited slip differential (BLSD) function may not normally operate, when driving on a special road the is extremely slanted (bank in a circuit course). This is not a malfunction if the status returns to normal for VDC function, TCS function and brake limited slip differential (BLSD) function after the engine is started again. In this case, perform self-diagnosis, check self-diagnosis results, and erase memory.
- A malfunction in yaw rate/side G sensor system may be detected when the vehicle sharply turns during a spin turn, acceleration turn or drift driving while VDC function, TCS function and brake limited slip differential (BLSD) function are OFF (VDC OFF switch is pressed and VDC OFF indicator lamp is in ON status). This is not a malfunction if the status returns to normal for VDC function, TCS function and brake limited slip differ-

# PRECAUTIONS

[WITH VDC]


## < PRECAUTION >

ential (BLSD) function after the engine is started again. In this case, perform self-diagnosis, check self-diagnosis results, and erase memory.


### Precaution for Harness Repair

INFOID:000000012406727

- Solder the repair part, and wrap it with tape. [Twisted wire fray must be 110 mm (4.33 in) or less.]



- Never bypass the repair point with wire. (If it is bypassed, the turnout point cannot be separated and the twisted wire characteristics are lost.)



A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# PREPARATION

< PREPARATION >

[WITH VDC]


## PREPARATION

### PREPARATION

#### Special Service Tool


INFOID:0000000012780028

The actual shapes of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
KV991J0080 (J-45741-A) ABS active wheel sensor tester	 <p>Checking operation of wheel sensors</p>

#### Commercial Service Tool

INFOID:0000000012780029

Tool name	Description
Power tool	 <p>Loosening bolts and nuts</p>




SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000012406729



- A. Back of spiral cable assembly
- B. Inside instrument stay cover
- C. Inside engine room (RH side)
- D. ABS warning lamp, brake warning lamp, VDC warning lamp, VDC OFF indicator lamp (in combination meter)
- E. Brake pedal
- F. Steering knuckle
- G. Rear axle housing

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[WITH VDC]

No.	Components	Function
1.	TCM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Shift position signal</li> <li>• Current gear position signal</li> <li>• P range signal</li> <li>• R range signal</li> <li>• N range signal</li> </ul>
2.	ECM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Accelerator pedal position signal</li> <li>• Engine speed signal</li> </ul> Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Target throttle position signal</li> </ul>
3.	VDC OFF switch	<a href="#">BRC-12. "VDC OFF Switch"</a>
4.	Steering angle sensor	<a href="#">BRC-11. "Steering Angle Sensor"</a>
5.	Yaw rate/side G sensor	<a href="#">BRC-11. "Yaw Rate/Side G Sensor"</a>
6.	ABS actuator and electric unit (control unit)	<a href="#">BRC-10. "ABS Actuator and Electric Unit (Control Unit)"</a>
7.	Stop lamp switch	<a href="#">BRC-11. "Stop Lamp Switch"</a>
8.	Front wheel sensor	<a href="#">BRC-11. "Wheel Sensor and Sensor Rotor"</a>
9.	Rear wheel sensor	

## ABS Actuator and Electric Unit (Control Unit)

INFOID:000000012406730

Electric unit (control unit) is integrated with actuator and comprehensively controls VDC function, TCS function, ABS function, EBD function and brake limited slip differential (BLSD) function.

### ELECTRIC UNIT (CONTROL UNIT)

- Brake fluid pressure, engine and transaxle are controlled according to signals from each sensor.
- If malfunction is detected, the system enters fail-safe mode.

### ACTUATOR

The following components are integrated with ABS actuator.

#### Pump

Feeds brake fluid by the motor.

#### Motor

Activates the pump according to signals from ABS actuator and electric unit (control unit).

#### Motor Relay

Operates the motor ON/OFF according to signals from ABS actuator and electric unit (control unit).

#### Actuator Relay (Main Relay)

Operates each valve ON/OFF according to signals from ABS actuator and electric unit (control unit).

#### ABS IN Valve

Switches the fluid pressure line to increase or hold according to signals from control unit.

#### **NOTE:**

Valve is a solenoid valve.

#### ABS OUT Valve

Switches the fluid pressure line to increase, hold or decrease according to signals from control unit.

#### **NOTE:**

Valve is a solenoid valve.

#### Cut Valve 1, Cut Valve2

Shuts off the ordinary brake line from master cylinder, when VDC function, TCS function and brake limited slip differential (BLSD) function are activated.

#### Suction Valve 1, Suction Valve 2

# COMPONENT PARTS

[WITH VDC]

## < SYSTEM DESCRIPTION >

Supplies the brake fluid from master cylinder to the pump, when VDC function, TCS function and brake limited slip differential (BLSD) function are activated.

### Inlet Valve

Brake fluid sucked from the reservoir by the pump does not backflow.

#### NOTE:

Valve is a check valve.

### Outlet Valve

Brake fluid discharged from the pump does not backflow.

#### NOTE:

Valve is a check valve.

### Return Check Valve

Returns the brake fluid from brake caliper to master cylinder by bypassing orifice of each valve when brake is released.

### Pressure sensor

Detects the brake fluid pressure and transmits signal to control unit.

### Reservoir

Temporarily reserves the brake fluid drained from brake caliper, so that pressure efficiently decreases when decreasing pressure of brake caliper.

### Damper


Reduces the vibrations travelling to the brake pedal during the operation of the VDC function, TCS function, ABS function, EBD function, or brake limited slip differential (BLSD) function.

## Wheel Sensor and Sensor Rotor

INFOID:0000000012406731

#### NOTE:

- Wheel sensor of front wheel is installed on steering knuckle.
- Sensor rotor of front wheel is integrated in wheel hub and bearing assembly.
- Wheel sensor of rear wheel is installed on axle housing.
- Sensor rotor of rear wheel is integrated in wheel hub and bearing assembly.
- Never measure resistance and voltage value using a tester because sensor is active sensor.
- Downsize and weight reduction is aimed. IC for detection portion and magnet for sensor rotor are adopted.
- Power supply is supplied to detection portion so that magnetic field line is read. Magnetic field that is detected is converted to current signal.
- When sensor rotor rotates, magnetic field changes. Magnetic field change is converted to current signals (rectangular wave) and is transmitted to ABS actuator and electric unit (control unit). Change of magnetic field is proportional to wheel speed.



## Stop Lamp Switch

INFOID:0000000012406732

Detects the operation status of brake pedal and transmits converted electric signal to ABS actuator and electric unit (control unit).

## Steering Angle Sensor

INFOID:0000000012406733

Detects the following information and transmits steering angle signal to ABS actuator and electric unit (control unit) via CAN communication.

- Steering wheel rotation amount
- Steering wheel rotation angular velocity
- Steering wheel rotation direction

## Yaw Rate/Side G Sensor

INFOID:0000000012406734

Calculates the following information that affects the vehicle, and transmits a signal to ABS actuator and electric unit (control unit) via communication lines.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## COMPONENT PARTS

[WITH VDC]

### < SYSTEM DESCRIPTION >

---

- Vehicle rotation angular velocity (yaw rate signal)
- Vehicle lateral acceleration (side G signal)

### Brake Fluid Level Switch

INFOID:0000000012406735

Detects the brake fluid level in reservoir tank and transmits converted electric signal from combination meter to ABS actuator and electric unit (control unit) via CAN communication, when brake fluid level is the specified level or less.

### VDC OFF Switch

INFOID:0000000012406736

- This is an integrated switch with switches for other functions.
- Non-operational status or standby status of the following functions can be selected using VDC OFF switch. VDC OFF indicator lamp indicates the operation status of function. (ON: Non-operational status, OFF: Standby status)
  - VDC function
  - TCS function

#### **NOTE:**

ABS function, EBD function and Brake limited slip differential (BLSD) function control operates.

- VDC OFF indicator lamp turns OFF (standby status) when the engine is started again after it is stopped once while VDC OFF indicator lamp is ON (non-operational status).


SYSTEM

System Description

INFOID:000000012406737

- The system switches fluid pressure of each brake caliper to increase, to hold or to decrease according to signals from control unit in ABS actuator and electric unit (control unit). This control system is applied to VDC function, TCS function, ABS function, EBD function and brake limited slip differential (BLSD) function.
- Fail-safe function is available for each function and is activated by each function when system malfunction occurs.

SYSTEM DIAGRAM



INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# SYSTEM


< SYSTEM DESCRIPTION >

[WITH VDC]

Component	Signal description
Yaw rate/side G sensor	<p>Mainly transmits the following signals to ABS actuator and electric unit (control unit) via communication line* .</p> <ul style="list-style-type: none"> <li>• Yaw rate signal</li> <li>• Side G sensor signal</li> </ul>
ECM	<p>Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication.</p> <ul style="list-style-type: none"> <li>• Accelerator pedal position signal</li> <li>• Engine speed signal</li> </ul> <p>Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication.</p> <ul style="list-style-type: none"> <li>• Target throttle position signal</li> </ul>
TCM	<p>Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication.</p> <ul style="list-style-type: none"> <li>• Shift position signal</li> <li>• Current gear position signal</li> <li>• P range signal</li> <li>• N range signal</li> <li>• R range signal</li> </ul>
Steering angle sensor	<p>Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication.</p> <ul style="list-style-type: none"> <li>• Steering angle sensor signal</li> </ul>
Combination meter	<p>Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication.</p> <ul style="list-style-type: none"> <li>• Brake fluid level switch signal</li> </ul> <p>Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication.</p> <ul style="list-style-type: none"> <li>• ABS warning lamp signal</li> <li>• Brake warning lamp signal</li> <li>• VDC warning lamp signal</li> <li>• VDC OFF indicator lamp signal</li> </ul>

\*: Communication line between yaw rate/side G sensor and ABS actuator and electric unit (control unit)

VALVE OPERATION [VDC FUNCTION, TCS FUNCTION AND BRAKE LIMITED SLIP DIFFERENTIAL (BLSD) FUNCTION



A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N

The following descriptions explains the control of front brake right side, as an example.

**When Pressure Increases**

The control unit closes the cut valve 1 port and opens the suction valve 1 port by supplying current to the cut valve 1 and the suction valve 1. Fluid pressure generated in the master cylinder passes through the suction valve 1 and the fluid pressure is pressurized by the pump. Since power is not applied to the ABS IN valve and the ABS OUT valve, the port of ABS IN valve is open and that of the ABS out valve is closed. This enables the supply of intensified fluid pressure to the front RH caliper.

**When Pressure Holds**

The control unit closes the cut valve 1 port by supplying current to the cut valve 1. Since power is not applied to the suction valve 1, the suction valve 1 port closes. The ABS IN valve port opens and the ABS OUT valve port closes because power is not supplied to the ABS OUT valve. Since each port of the cut valve 1 and suc-

# SYSTEM

[WITH VDC]

## < SYSTEM DESCRIPTION >

tion valve 1 is closed, the paths to the master cylinder, front RH caliper, and pump and reservoir are cut to maintain fluid pressure of the front RH caliper.

### When Pressure Decreases


Since power is not supplied to the cut valve 1, suction valve 1, ABS IN valve, and ABS OUT valve, each port of the suction valve 1 and the ABS OUT valve is closed and the ports of the cut valve 1 and the ABS IN valve are open. This allows front RH caliper fluid pressure to flow into the cylinder side.

### Component Parts and Function

Component	Function
Pump	Feeds brake fluid by the motor.
Motor	Activates the pump according to signals from ABS actuator and electric unit (control unit).
ABS IN valve	Switches the fluid pressure line to increase or hold according to signals from control unit.
ABS OUT valve	Switches the fluid pressure line to increase, hold or decrease according to signals from control unit.
Cut valve 1 Cut valve 2	Shuts off the ordinary brake line from master cylinder, when VDC function, TCS function and brake limited slip differential (BLSD) function are activated.
Suction valve 1 Suction valve 2	Supplies the brake fluid from master cylinder to the pump, when VDC function, TCS function and brake limited slip differential (BLSD) function are activated.
Inlet valve	Brake fluid sucked from the reservoir by the pump does not backflow.
Outlet valve	Brake fluid discharged from the pump does not backflow.
Return check valve	Returns the brake fluid from brake caliper and wheel cylinder to master cylinder by bypassing orifice of each valve when brake is released.
Pressure sensor	Detects the brake fluid pressure and transmits signal to control unit.
Reservoir	Temporarily reserves the brake fluid drained from brake caliper, so that pressure efficiently decreases when decreasing pressure of brake caliper and wheel cylinder.
Damper	Reduces the vibrations travelling to the brake pedal during the operation of the VDC function, TCS function, ABS function, EBD function, or brake limited slip differential (BLSD) function.

## VALVE OPERATION (ABS FUNCTION AND EBD FUNCTION)





A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

The following descriptions explains the control of front brake right side, as an example.

### Under Normal Brake Operation

Since power is not supplied to the ABS IN valve and the ABS OUT valve, the ABS IN valve port is open and the ABS OUT valve port is closed. This allows the master cylinder fluid pressure to be sent to the front RH caliper and blocks the brake fluid passage to the reservoir.

### When Pressure Increases

The control unit pressurizes the inside of the brake caliper by opening the ABS IN valve port and closing the ABS OUT valve port. After breaking the circuit, the valves operate in the same way as described in "Under Normal Brake Operation." The fluid amount supplied from the master cylinder to the brake caliper is controlled, according to the power supply cut-off time (time to open the port) to the ABS IN valve.

### When Pressure Holds

# SYSTEM

**[WITH VDC]**

## < SYSTEM DESCRIPTION >

The control unit passes an electric current to the ABS IN valve and closes the ABS IN valve port. Since power is not supplied to the ABS OUT valve, its port is closed. The paths to the brake caliper, master cylinder, and reservoir are cut off. This allows the front RH caliper fluid pressure to be maintained.

### When Pressure Decreases

The control unit closes the ABS IN valve port and opens the ABS OUT valve port by supplying power to the ABS IN valve and the ABS OUT valve. The brake fluid of the front RH caliper passes through the ABS OUT valve to the reservoir and stays in the reservoir. After this the brake fluid is pumped up to return to the master cylinder.

### When brake released

The fluid pressure returns from the front RH caliper to the master cylinder through the return check valve opened by the ABS IN valve port and fluid pressure.

### Component Parts and Function

Component	Function
Pump	Feeds brake fluid by the motor.
Motor	Activates the pump according to signals from ABS actuator and electric unit (control unit).
ABS IN valve	Switches the fluid pressure line to increase or hold according to signals from control unit.
ABS OUT valve	Switches the fluid pressure line to increase, hold or decrease according to signals from control unit.
Cut valve 1 Cut valve 2	Shuts off the ordinary brake line from master cylinder, when VDC function, TCS function and brake limited slip differential (BLSD) function are activated.
Suction valve 1 Suction valve 2	Supplies the brake fluid from master cylinder to the pump, when VDC function, TCS function and brake limited slip differential (BLSD) function are activated.
Inlet valve	Brake fluid sucked from the reservoir by the pump does not backflow.
Outlet valve	Brake fluid discharged from the pump does not backflow.
Return check valve	Returns the brake fluid from brake caliper and wheel cylinder to master cylinder by bypassing orifice of each valve when brake is released.
Pressure sensor	Detects the brake fluid pressure and transmits signal to control unit.
Reservoir	Temporarily reserves the brake fluid drained from brake caliper, so that pressure efficiently decreases when decreasing pressure of brake caliper and wheel cylinder.
Damper	Reduces the vibrations travelling to the brake pedal during the operation of the VDC function, TCS function, ABS function, EBD function, or brake limited slip differential (BLSD) function.

### CONDITION FOR TURN ON THE WARNING LAMP

Turns ON when ignition switch turns ON and turns OFF when the system is normal, for bulb check purposes.

Condition (status)	ABS warning lamp	Brake warning lamp	VDC warning lamp
Ignition switch OFF	OFF	OFF	OFF
For approx. 2 seconds after the ignition switch is turned ON	ON	ON	ON
Approx. 2 seconds after ignition switch is turned ON (when the system is in normal operation)	OFF	OFF	OFF
When parking brake operates (parking brake switch ON)	OFF	ON	OFF
When brake fluid is less than the specified level (brake fluid level switch ON)	OFF	ON	OFF
VDC function is malfunctioning	OFF	OFF	ON
TCS function is malfunctioning	OFF	OFF	ON
ABS function is malfunctioning	ON	OFF	ON
EBD function is malfunctioning	ON	ON	ON
Brake limited slip differential (BLSD) function is malfunctioning	OFF	OFF	ON
VDC function is operating	OFF	OFF	Blinking
TCS function is operating	OFF	OFF	Blinking

### CONDITION FOR TURN ON THE INDICATOR LAMP

# SYSTEM

[WITH VDC]

## < SYSTEM DESCRIPTION >

- Turns ON when VDC function and TCS function are switched to non-operational status (OFF) by VDC OFF switch.
- Turns ON when ignition switch turns ON and turns OFF when the system is normal, for bulb check purposes.

Condition (status)	VDC OFF indicator lamp
Ignition switch OFF	OFF
For approx. 2 seconds after the ignition switch is turned ON	ON
Approx. 2 seconds after ignition switch is turned ON (when the system is in normal operation)	OFF
When VDC OFF switch is ON (VDC function and TCS function are OFF)	ON

A

B

C

D

E

**BRC**

G

H

I

J

K

L

M

N

O

P


# SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

## Circuit Diagram

INFOID:000000012406738



JSFIA3682GB

### Fail-safe

INFOID:000000012406739

VDC FUNCTION, TCS FUNCTION AND BRAKE LIMITED SLIP DIFFERENTIAL (BLS) FUNCTION  
 VDC warning lamp in combination meter turn ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function and brake limited slip dif-

# SYSTEM

[WITH VDC]

## < SYSTEM DESCRIPTION >

ferential (BLSD) function. The vehicle status becomes the same as models without VDC function, TCS function and brake limited slip differential (BLSD) function. However, ABS function and EBD function are operated normally.

### ABS FUNCTION

ABS warning lamp and VDC warning lamp in combination meter turn ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, ABS function and brake limited slip differential (BLSD) function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function and brake limited slip differential (BLSD) function. However, EBD function is operated normally.

#### NOTE:

ABS self-diagnosis sound may be heard the same as in the normal condition, because self-diagnosis is performed when ignition switch turns ON and when vehicle initially starts.

### EBD FUNCTION


ABS warning lamp, brake warning lamp and VDC warning lamp in combination meter turn ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, ABS function, EBD function and brake limited slip differential (BLSD) function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, EBD function and brake limited slip differential (BLSD) function.

### VDC FUNCTION

#### VDC FUNCTION : System Description

INFOID:000000012406740

- Side slip or tail slip may occur while driving on a slippery road or intending an urgent evasive driving. VDC function detects side slip status using each sensor when side slip or tail slip is about to occur and improves vehicle stability by brake control and engine output control during driving.
- In addition to ABS function, EBD function and TCS function, target side slip amount is calculated according to steering operation amount from steering angle sensor. By comparing this information with vehicle side slip amount that is calculated from information from yaw rate/side G sensor and wheel sensor, vehicle driving conditions (conditions of understeer or oversteer) are judged and vehicle stability is improved by brake force control on all 4 wheels and engine output control.



- VDC function can be switched to non-operational status (OFF) by operating VDC OFF switch. In this case, VDC OFF indicator lamp turns ON.
- Control unit portion automatically improves driving stability by performing brake force control as well as engine output control, by transmitting drive signal to actuator portion according to difference between target side slip amount and vehicle side slip amount
- VDC warning lamp blinks while VDC function is in operation and indicates to the driver that the function is in operation.
- CONSULT can be used to diagnose the system diagnosis.
- Fail-safe function is adopted. When a malfunction occurs in VDC function, the control is suspended for VDC function, TCS function and brake limited slip differential (BLSD) function. The vehicle status becomes the same as models without VDC function, TCS function and brake limited slip differential (BLSD) function. However, ABS function and EBD function are operated normally. Refer to [BRC-20, "Fail-safe"](#).

#### NOTE:


VDC has the characteristic as described here, This is not the device that helps reckless driving.

# SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

## SYSTEM DIAGRAM



## INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

Component	Signal description
Yaw rate/side G sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via communication line*. <ul style="list-style-type: none"> <li>• Yaw rate signal</li> <li>• Side G sensor signal</li> </ul>
ECM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Acceleration pedal position signal</li> <li>• Engine speed signal</li> </ul> Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Target throttle position signal</li> </ul>
TCM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Shift position signal</li> <li>• Current gear position signal</li> <li>• P range signal</li> <li>• R range signal</li> <li>• N range signal</li> </ul>
Steering angle sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Steering angle sensor signal</li> </ul>
Combination meter	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Brake fluid level switch signal</li> </ul> Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• VDC warning lamp signal</li> <li>• VDC OFF indicator lamp signal</li> </ul>


\*: Communication line between yaw rate/side G sensor and ABS actuator and electric unit (control unit)

< SYSTEM DESCRIPTION >


OPERATION CHARACTERISTICS

VDC Function That Prevents Oversteer Tendency

- During a cornering, brake force (brake fluid pressure) is applied on front wheel and rear wheel on the outer side of turn. Moment directing towards the outer side of turn is generated. Oversteer is prevented.




- Changing driving lane on a slippery road, when oversteer tendency is judged large, engine output is controlled as well as brake force (brake fluid pressure) of 4 wheels. Oversteer tendency decreases.




VDC Function That Prevents Understeer Tendency

- During a cornering, brake force (brake fluid pressure) is applied on front wheel and rear wheel on the inner side of turn. Moment directing towards the inner side of turn is generated. Understeer is prevented.



- Applying braking during a cornering on a slippery road, when understeer tendency is judged large, engine output is controlled as well as brake force (brake fluid pressure) of four wheels. Understeer tendency decreases.




TCS FUNCTION

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


TCS FUNCTION : System Description

INFOID:000000012406741

- Wheel spin status of drive wheel is detected by wheel sensor of 4 wheels. Engine output and transmission shift status is controlled so that slip rate of drive wheels is in appropriate level. When wheel spin occurs on drive wheel, ABS actuator and electric unit (control unit) perform brake force control of LH and RH drive wheels (apply brake force by increasing brake fluid pressure of drive wheel) and decrease engine torque by engine torque control. Wheel spin amount decreases. Engine torque is controlled to appropriate level.
- TCS function can be switched to non-operational status (OFF) by operating VDC OFF switch. In this case, VDC OFF indicator lamp turns ON.
- VDC warning lamp blinks while TCS function is in operation and indicates to the driver that the function is in operation.
- CONSULT can be used to diagnose the system diagnosis.
- Fail-safe function is adopted. When a malfunction occurs in TCS function, the control is suspended for VDC function, TCS function and brake limited slip differential (BLSD) function. The vehicle status becomes the same as models without VDC function, TCS function and brake limited slip differential (BLSD) function. However, ABS function and EBD function are operated normally. Refer to [BRC-20, "Fail-safe"](#).



SYSTEM DIAGRAM



INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.



# SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

Component	Signal description
Yaw rate/side G sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via communication line*. <ul style="list-style-type: none"> <li>• Yaw rate signal</li> <li>• Side G sensor signal</li> </ul>
ECM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Acceleration pedal position signal</li> <li>• Engine speed signal</li> </ul> Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Target throttle position signal</li> </ul>
TCM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Shift position signal</li> <li>• Current gear position signal</li> <li>• P range signal</li> <li>• R range signal</li> <li>• N range signal</li> </ul>
Steering angle sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Steering angle sensor signal</li> </ul>
Combination meter	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Brake fluid level switch signal</li> </ul> Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• VDC warning lamp signal</li> <li>• VDC OFF indicator lamp signal</li> </ul>

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

\*: Communication line between yaw rate/side G sensor and ABS actuator and electric unit (control unit)

## ABS FUNCTION

### ABS FUNCTION : System Description

INFOID:0000000012406742

- By preventing wheel lock through brake force (brake fluid pressure) control that is electronically controlled by detecting wheel speed during braking, stability during emergency braking is improved so that obstacles can be easily bypassed by steering operation.
- During braking, control units calculates wheel speed and pseudo-vehicle speed, and transmits pressure increase, hold or decrease signals to actuator portion according to wheel slip status.

# SYSTEM


[WITH VDC]

## < SYSTEM DESCRIPTION >

- The following effects are obtained by preventing wheel lock during braking.
- Vehicle tail slip is prevented during braking when driving straight.
- Understeer and oversteer tendencies are moderated during braking driving on a corner.
- Obstacles may be easily bypassed by steering operation during braking.
- CONSULT can be used to diagnose the system diagnosis.
- Fail-safe function is adopted. When a malfunction occurs in ABS function, the control is suspended for VDC function, TCS function, ABS function and brake limited slip differential (BLSD) function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function and brake limited slip differential (BLSD) function. However, EBD function is operated normally. Refer to [BRC-20, "Fail-safe"](#).


### NOTE:

- ABS has the characteristic as described here, but it is not the device that helps reckless driving.
- To stop vehicle efficiently, ABS does not operate and ordinary brake operates at low speed [approx. 10 km/h (6.2 MPH) or less, but differs subject to road conditions).
- Self-diagnosis is performed immediately after when engine starts and when vehicle initially is driven [by vehicle speed approx. 15 km/h (9.3 MPH)]. Motor sounds are generated during self-diagnosis. In addition, brake pedal may be felt heavy when depressing brake pedal lightly. These symptoms are not malfunctions.



JPFIC0140GB

## SYSTEM DIAGRAM



JSFIA0973GB

## INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

# SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

Component	Signal description
Yaw rate/side G sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via communication line*. <ul style="list-style-type: none"> <li>• Yaw rate signal</li> <li>• Side G sensor signal</li> </ul>
Steering angle sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Steering angle sensor signal</li> </ul>
Combination meter	Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• VDC warning lamp signal</li> <li>• ABS warning lamp signal</li> </ul>

\*: Communication line between yaw rate/side G sensor and ABS actuator and electric unit (control unit)


## EBD FUNCTION

### EBD FUNCTION : System Description


INFOID:000000012406743

A  
B  
C  
D  
E

- By preventing rear wheel slip increase through rear wheel brake force (brake fluid pressure) control that is electronically controlled when slight skip on front and rear wheels are detected during braking, stability during braking is improved.
- EBD function is expanded and developed from conventional ABS function and corrects rear wheel brake force to appropriate level by electronic control according to load weight (number of passengers).




- During braking, control unit portion compares slight slip on front and rear wheels by wheel speed sensor signal, transmits drive signal to actuator portion when rear wheel slip exceeds front wheel slip for the specified value or more, and controls rear wheel brake force (brake fluid pressure) so that increase of rear wheel slip is prevented and slips on front wheel and rear wheel are nearly equalized. ABS control is applied when slip on each wheel increases and wheel speed is the threshold value of ABS control or less.
- CONSULT can be used to diagnose the system diagnosis.
- Fail-safe function is adopted. When a malfunction occurs in EBD function, the control is suspended for VDC function, TCS function, ABS function, EBD function and brake limited slip differential (BLSD) function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, EBD function and brake limited slip differential (BLSD) function. Refer to [BRC-20, "Fail-safe"](#).



BRC

G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SYSTEM DIAGRAM



INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

Component	Signal description
Combination meter	Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• VDC warning lamp signal</li> <li>• ABS warning lamp signal</li> <li>• Brake warning lamp signal</li> </ul>

BRAKE LIMITED SLIP DIFFERENTIAL (BLSD) FUNCTION

BRAKE LIMITED SLIP DIFFERENTIAL (BLSD) FUNCTION : System Description

INFOID:0000000012406744


- LH and RH driving wheel spin is always monitored. If necessary, appropriate brake force is independently applied to LH or RH driving wheel so that one-sided wheel spin is avoided and traction is maintained. Mainly starting ability is improved.
- Brake limited slip differential (BLSD) function operates while VDC function is in non-operational status (OFF) by VDC OFF switch.
- VDC warning lamp blinking while brake limited slip differential (BLSD) function is in operation and indicates to the driver that the function is in operation.
- Slight vibrations are felt on the brake pedal and the operation noises occur, when brake limited slip differential (BLSD) function operates. This is not a malfunction because it is caused by brake limited slip differential (BLSD) function that is normally operated.
- CONSULT can be used to diagnose the system diagnosis.
- Fail-safe function is adopted. When a malfunction occurs in brake limited slip differential (BLSD) function, the control is suspended for VDC function, TCS function and brake limited slip differential (BLSD) function. The vehicle status becomes the same as models without VDC function, TCS function and brake limited slip differential (BLSD) function. However, ABS function and EBD function are operated normally. Refer to [BRC-20. "Fail-safe"](#).

# SYSTEM

< SYSTEM DESCRIPTION >

[WITH VDC]

## SYSTEM DIAGRAM



### INPUT SIGNAL AND OUTPUT SIGNAL

Major signal transmission between each unit via communication lines is shown in the following table.

Component	Signal description
Yaw rate/side G sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via communication line*. <ul style="list-style-type: none"> <li>• Yaw rate signal</li> <li>• Side G sensor signal</li> </ul>
ECM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Acceleration pedal position signal</li> <li>• Engine speed signal</li> </ul> Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Target throttle position signal</li> </ul>
TCM	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Shift position signal</li> <li>• Current gear position signal</li> <li>• P range signal</li> <li>• R range signal</li> <li>• N range signal</li> </ul>
Steering angle sensor	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Steering angle sensor signal</li> </ul>
Combination meter	Mainly transmits the following signals to ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• Brake fluid level switch signal</li> </ul> Mainly receives the following signals from ABS actuator and electric unit (control unit) via CAN communication. <ul style="list-style-type: none"> <li>• VDC warning lamp signal</li> </ul>

\*: Communication line between yaw rate/side G sensor and ABS actuator and electric unit (control unit)

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

## DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

### CONSULT Function

INFOID:000000012406745

### APPLICATION ITEMS

CONSULT can display each diagnostic item using the diagnostic test modes as follows.

Mode	Function description
ECU identification	Parts number of ABS actuator and electric unit (control unit) can be read.
Self Diagnostic Result	Self-diagnostic results and freeze frame data can be read and erased quickly.*
DATA MONITOR	Input/Output data in the ABS actuator and electric unit (control unit) can be read.
ACTIVE TEST	Diagnostic Test Mode in which CONSULT drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range.
Function Test	Although "Function Test" is selectable, do not use its.
Work support	Components can be quickly and accurately adjusted.

\*: The following diagnosis information is erased by erasing.

- DTC
- Freeze frame data (FFD)

### ECU IDENTIFICATION

ABS actuator and electric unit (control unit) part number can be read.

### SELF DIAGNOSTIC RESULT

Refer to [BRC-38, "DTC Index"](#).

When "CRNT" is displayed on self-diagnosis result

- The system is presently malfunctioning.

When "PAST" is displayed on self-diagnosis result

- System malfunction in the past is detected, but the system is presently normal.

Freeze frame data (FFD)

When DTC is detected, a vehicle state shown below is recorded and displayed on CONSULT.

Item name	Display item
IGN counter (0 – 39)	<p>The number of times that ignition switch is turned ON after the DTC is detected is displayed.</p> <ul style="list-style-type: none"> <li>• When "0" is displayed: It indicates that the system is presently malfunctioning.</li> <li>• When except "0" is displayed: It indicates that system malfunction in the past is detected, but the system is presently normal.</li> </ul> <p><b>NOTE:</b> Each time when ignition switch is turned OFF to ON, numerical number increases in 1 → 2 → 3...38 → 39. When the operation number of times exceeds 39, the number do not increase and "39" is displayed until self-diagnosis is erased.</p>

### DATA MONITOR

#### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

×: Applicable

Item (Unit)	Monitor item selection		Note
	ECU INPUT SIGNALS	MAIN SIGNALS	
FR LH SENSOR [km/h (MPH)]	×	×	Wheel speed calculated by front LH wheel sensor is displayed.
FR RH SENSOR [km/h (MPH)]	×	×	Wheel speed calculated by front RH wheel sensor is displayed.

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

Item (Unit)	Monitor item selection		Note	
	ECU INPUT SIGNALS	MAIN SIGNALS		
RR LH SENSOR [km/h (MPH)]	×	×	Wheel speed calculated by rear LH wheel sensor is displayed.	A
RR RH SENSOR [km/h (MPH)]	×	×	Wheel speed calculated by rear RH wheel sensor is displayed.	B
FR RH IN SOL (On/Off)		×	Operation status of front RH wheel ABS IN valve is displayed.	C
FR RH OUT SOL (On/Off)		×	Operation status of front RH wheel ABS OUT valve is displayed.	D
FR LH IN SOL (On/Off)		×	Operation status of front LH wheel ABS IN valve is displayed.	E
FR LH OUT SOL (On/Off)		×	Operation status of front LH wheel ABS OUT valve is displayed.	E
RR RH IN SOL (On/Off)		×	Operation status of rear RH wheel ABS IN valve is displayed.	BRC
RR RH OUT SOL (On/Off)		×	Operation status of rear RH wheel ABS OUT valve is displayed.	BRC
RR LH IN SOL (On/Off)		×	Operation status of rear LH wheel ABS IN valve is displayed.	G
RR LH OUT SOL (On/Off)		×	Operation status of rear LH wheel ABS OUT valve is displayed.	G
EBD WARN LAMP (On/Off)			Brake warning lamp ON/OFF status is displayed. *	H
STOP LAMP SW (On/Off)	×	×	Stop lamp switch signal input status is displayed.	I
MOTOR RELAY (On/Off)		×	ABS motor and motor relay status is displayed.	J
ACTUATOR RLY (On/Off)		×	ABS actuator relay status is displayed.	J
ABS WARN LAMP (On/Off)		×	ABS warning lamp ON/OFF status is displayed. *	K
OFF LAMP (On/Off)		×	VDC OFF indicator lamp ON/OFF status is displayed. *	K
OFF SW (On/Off)	×	×	VDC OFF switch signal input status is displayed.	L
SLIP/VDC LAMP (On/Off)		×	VDC warning lamp ON/OFF status is displayed. *	M
BATTERY VOLT (V)	×	×	Voltage supplied to ABS actuator and electric unit (control unit) is displayed.	M
GEAR	×	×	Current gear position judged from current gear position signal is displayed.	N
SLCT LVR POSI	×	×	Current shift position judged from shift position signal is displayed.	O
ENGINE SPEED [tr/min (rpm)]	×	×	Engine speed status is displayed.	O
YAW RATE SEN (d/s)	×	×	Yaw rate detected by yaw rate sensor is displayed.	P
R POSI SIG (On/Off)			R range signal input status judged from R range signal is displayed.	
N POSI SIG (On/Off)			N range signal input status judged from N range signal is displayed.	
P POSI SIG (On/Off)			P range signal input status judged from P range signal is displayed.	

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

Item (Unit)	Monitor item selection		Note
	ECU INPUT SIGNALS	MAIN SIGNALS	
CV1 (On/Off)			Cut valve 1 operation status is displayed.
CV2 (On/Off)			Cut valve 2 operation status is displayed.
SV1 (On/Off)			Suction valve 1 operation status is displayed.
SV2 (On/Off)			Suction valve 2 operation status is displayed.
ACCEL POS SIG (%)	×		Displays the Accelerator pedal position
SIDE G-SENSOR (m/s <sup>2</sup> )	×		Side G detected by side G sensor is displayed.
STR ANGLE SIG (deg)	×		Steering angle detected by steering angle sensor is displayed.
PRESS SENSOR (bar)	×		Brake fluid pressure detected by pressure sensor is displayed.
EBD SIGNAL (On/Off)			EBD operation status is displayed.
ABS SIGNAL (On/Off)			ABS operation status is displayed.
TCS SIGNAL (On/Off)			TCS operation status is displayed.
VDC SIGNAL (On/Off)			VDC operation status is displayed.
EBD FAIL SIG (On/Off)			EBD fail-safe signal status is displayed.
ABS FAIL SIG (On/Off)			ABS fail-safe signal status is displayed.
TCS FAIL SIG (On/Off)			TCS fail-safe signal status is displayed.
VDC FAIL SIG (On/Off)			VDC fail-safe signal status is displayed.
CRANKING SIG (On/Off)			Cranking status is displayed.
FLUID LEV SW (On/Off)	×		Brake fluid level signal input status via CAN communication is displayed.

\*: Refer to [BRC-13, "System Description"](#) for ON/OFF conditions of each warning lamp and indicator lamp.

## ACTIVE TEST

The active test is used to determine and identify details of a malfunction, based on self-diagnosis test result and data obtained in the DATA MONITOR. In response to instructions from CONSULT, instead of those from ABS actuator and electric unit (control unit) on the vehicle, a drive signal is sent to the actuator to check its operation.

### CAUTION:

- **Never perform ACTIVE TEST while driving the vehicle.**
- **Always bleed air from brake system before ACTIVE TEST.**
- **Never perform ACTIVE TEST when system is malfunctioning.**

### NOTE:

- When active test is performed while depressing the pedal, the pedal depressing stroke may change. This is not a malfunction.
- "TEST IS STOPPED" is displayed approx. 10 seconds after operation start.
- When performing active test again after "TEST IS STOPPED" is displayed, select "BACK".
- ABS warning lamp and brake warning lamp may turn ON during active test. This is not a malfunction.



# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

ABS IN Valve and ABS OUT Valve

When "Up", "Keep" or "Down" is selected on display screen, the following items are displayed when system is normal.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
FR LH SOL	FRLH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*

\*: Immediately after being selected, status is "On". Status changes to "Off" after approx. 2 seconds.

**NOTE:**

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

ABS IN Valve (ACT) and ABS OUT Valve (ACT)

When "Up", "ACT KEEP" or "ACT UP" is selected on display screen, the following items are displayed when system is normal.

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
FR RH ABS SOLE-NOID (ACT)	FR RH IN SOL	Off	Off	Off
	FR RH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off
FR LH ABS SOLE-NOID (ACT)	FRLH IN SOL	Off	Off	Off
	FR LH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR RH ABS SOLE-NOID (ACT)	RR RH IN SOL	Off	Off	Off
	RR RH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR LH ABS SOLE-NOID (ACT)	RR LH IN SOL	Off	Off	Off
	RR LH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off

\*: Immediately after being selected, status is "On". Status changes to "Off" after approx. 2 seconds.

**NOTE:**

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is a operation for checking.

ABS Motor

When "On" or "Off" is selected on display screen, the following items are displayed when system is normal.

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[WITH VDC]

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY	On*	On*

\*: When the ignition switch is turned ON, the indication switches between “On” and “Off” for an extremely brief moment at irregular intervals. This is not a malfunction. The symptom is merely a result of confirmatory checks.

## WORK SUPPORT

Item	Description
ST ANGLE SENSOR ADJUSTMENT	Perform neutral position adjustment of steering angle sensor.

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

## ECU DIAGNOSIS INFORMATION

### ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

#### Reference Value

INFOID:0000000012406746

#### CONSULT DATA MONITOR STANDARD VALUE

**NOTE:**

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item	Condition	Reference values in normal operation
FR LH SENSOR	Vehicle stopped	0.00 km/h (MPH)
	When driving straight ahead*1	Nearly matches the speedometer display (within ±10%)
FR RH SENSOR	Vehicle stopped	0.00 km/h (MPH)
	When driving straight ahead*1	Nearly matches the speedometer display (within ±10%)
RR LH SENSOR	Vehicle stopped	0.00 km/h (MPH)
	When driving straight ahead*1	Nearly matches the speedometer display (within ±10%)
RR RH SENSOR	Vehicle stopped	0.00 km/h (MPH)
	When driving straight ahead*1	Nearly matches the speedometer display (within ±10%)
FR RH IN SOL*2	Active	On
	Not activated	Off
FR RH OUT SOL*2	Active	On
	Not activated	Off
FR LH IN SOL*2	Active	On
	Not activated	Off
FR LH OUT SOL*2	Active	On
	Not activated	Off
RR RH IN SOL*2	Active	On
	Not activated	Off
RR RH OUT SOL*2	Active	On
	Not activated	Off
RR LH IN SOL*2	Active	On
	Not activated	Off
RR LH OUT SOL*2	Active	On
	Not activated	Off
EBD WARN LAMP	When brake warning lamp is ON*3	On
	When brake warning lamp is OFF*3	Off
STOP LAMP SW	Brake pedal depressed	On
	Brake pedal not depressed	Off
MOTOR RELAY	Active	On
	Not activated	Off
ACTUATOR RLY	Active	On
	Not activated (in fail-safe mode)	Off

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

Monitor item	Condition	Reference values in normal operation
ABS WARN LAMP	When ABS warning lamp is ON*3	On
	When ABS warning lamp is OFF*3	Off
OFF LAMP	When VDC OFF indicator lamp is ON*3	On
	When VDC OFF indicator lamp is OFF*3	Off
OFF SW	VDC OFF switch ON	On
	VDC OFF switch OFF	Off
SLIP/VDC LAMP	When VDC warning lamp is ON*3	On
	When VDC warning lamp is OFF*3	Off
BATTERY VOLT	Ignition switch ON	10 – 16 V
GEAR	Driving	1 – 6 Depending on shift status
SLCT LVR POSI	When ignition switch is ON	P, R, N, D
ENGINE SPEED	Engine stopped	0 rpm
	Engine running	Almost same reading as tachometer
YAW RATE SEN	Vehicle stopped	Approx. 0 d/s
	Turning right	Negative value
	Turning left	Positive value
R POSI SIG	When selector lever is in the R position	On
	When selector lever is in the other position than R	Off
N POSI SIG	When selector lever is in the N position	On
	When selector lever is in the other position than N	Off
P POSI SIG	When selector lever is in the P position	On
	When selector lever is in the other position than P	Off
CV1*2	Active	On
	Not activated	Off
CV2*2	Active	On
	Not activated	Off
SV1*2	Active	On
	Not activated	Off
SV2*2	Active	On
	Not activated	Off
ACCEL POS SIG	Never depress accelerator pedal (with ignition switch ON)	0%
	Depress accelerator pedal (with ignition switch ON)	0 – 100%
SIDE G-SENSOR	Vehicle stopped	Approx. 0 m/s <sup>2</sup>
	Turning right	Negative value
	Turning left	Positive value
STR ANGLE SIG	When driving straight	0±3.5°
	When steering wheel is steered to LH by 90°	Approx. -90°
	When steering wheel is steered to RH by 90°	Approx. +90°
PRESS SENSOR	Brake pedal not depressed	Approx. 0 bar
	Brake pedal depressed	(-40) – (+300 bar)
EBD SIGNAL	EBD is activated	On
	EBD is not activated	Off

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[WITH VDC]

< ECU DIAGNOSIS INFORMATION >

Monitor item	Condition	Reference values in normal operation
ABS SIGNAL	ABS is activated	On
	ABS is not activated	Off
TCS SIGNAL	TCS is activated	On
	TCS is not activated	Off
VDC SIGNAL	VDC is activated	On
	VDC is not activated	Off
EBD FAIL SIG	In EBD fail-safe	On
	EBD is normal	Off
ABS FAIL SIG	In ABS fail-safe	On
	ABS is normal	Off
TCS FAIL SIG	In TCS fail-safe	On
	TCS is normal	Off
VDC FAIL SIG	In VDC fail-safe	On
	VDC is normal	Off
CRANKING SIG	At cranking	On
	Other than at cranking	Off
FLUID LEV SW	When brake fluid level switch is ON (brake fluid level is less than the specified level)	On
	When brake fluid level switch is OFF	Off

\*1: Confirm tire pressure is standard value.

\*2: Refer to "valve operation" in [BRC-13, "System Description"](#) for valve operation of each valve.

\*3: Refer to [BRC-13, "System Description"](#) for ON/OFF conditions of each warning lamp and indicator lamp.

## Fail-safe

INFOID:000000012406747

**VDC FUNCTION, TCS FUNCTION AND BRAKE LIMITED SLIP DIFFERENTIAL (BLSD) FUNCTION**  
VDC warning lamp in combination meter turn ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function and brake limited slip differential (BLSD) function. The vehicle status becomes the same as models without VDC function, TCS function and brake limited slip differential (BLSD) function. However, ABS function and EBD function are operated normally.

## ABS FUNCTION

ABS warning lamp and VDC warning lamp in combination meter turn ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, ABS function and brake limited slip differential (BLSD) function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function and brake limited slip differential (BLSD) function. However, EBD function is operated normally.

### NOTE:

ABS self-diagnosis sound may be heard the same as in the normal condition, because self-diagnosis is performed when ignition switch turns ON and when vehicle initially starts.

## EBD FUNCTION

ABS warning lamp, brake warning lamp and VDC warning lamp in combination meter turn ON when a malfunction occurs in system [ABS actuator and electric unit (control unit)]. The control is suspended for VDC function, TCS function, ABS function, EBD function and brake limited slip differential (BLSD) function. The vehicle status becomes the same as models without VDC function, TCS function, ABS function, EBD function and brake limited slip differential (BLSD) function.

## DTC Inspection Priority Chart

INFOID:000000012406748

When multiple DTCs are displayed simultaneously, check one by one depending on the following priority list.

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

Priority	Detected item (DTC)
1	<ul style="list-style-type: none"> <li>• U1000 CAN COMM CIRCUIT</li> <li>• U1002 SYSTEM COMM(CAN)</li> </ul>
2	<ul style="list-style-type: none"> <li>• C1110 CONTROLLER FAILURE</li> </ul>
3	<ul style="list-style-type: none"> <li>• C1130 ENGINE SIGNAL 1</li> </ul>
4	<ul style="list-style-type: none"> <li>• C1109 BATTERY VOLTAGE [ABNORMAL]</li> <li>• C1111 PUMP MOTOR</li> <li>• C1140 ACTUATOR RLY</li> </ul>
5	<ul style="list-style-type: none"> <li>• C1101 RR RH SENSOR-1</li> <li>• C1102 RR LH SENSOR-1</li> <li>• C1103 FR RH SENSOR-1</li> <li>• C1104 FR LH SENSOR-1</li> <li>• C1105 RR RH SENSOR-2</li> <li>• C1106 RR LH SENSOR-2</li> <li>• C1107 FR RH SENSOR-2</li> <li>• C1108 FR LH SENSOR-2</li> <li>• C1115 ABS SENSOR [ABNORMAL SIGNAL]</li> <li>• C1116 STOP LAMP SW</li> <li>• C1120 FR LH IN ABS SOL</li> <li>• C1121 FR LH OUT ABS SOL</li> <li>• C1122 FR RH IN ABS SOL</li> <li>• C1123 FR RH OUT ABS SOL</li> <li>• C1124 RR LH IN ABS SOL</li> <li>• C1125 RR LH OUT ABS SOL</li> <li>• C1126 RR RH IN ABS SOL</li> <li>• C1127 RR RH OUT ABS SOL</li> <li>• C1142 PRESS SEN CIRCUIT</li> <li>• C1143 ST ANG SEN CIRCUIT</li> <li>• C1144 ST ANG SEN SIGNAL</li> <li>• C1145 YAW RATE SENSOR</li> <li>• C1146 SIDE G SEN CIRCUIT</li> <li>• C1161 SIDE G SEN SET</li> <li>• C1162 PRESS SEN SET</li> <li>• C1164 CV 1</li> <li>• C1165 CV 2</li> <li>• C1166 SV 1</li> <li>• C1167 SV 2</li> </ul>
6	<ul style="list-style-type: none"> <li>• C1155 BR FLUID LEVEL LOW</li> </ul>

## DTC Index

INFOID:000000012406749

DTC	Display Item	Refer to
C1101	RR RH SENSOR-1	<a href="#">BRC-52. "DTC Logic"</a>
C1102	RR LH SENSOR-1	
C1103	FR RH SENSOR-1	
C1104	FR LH SENSOR-1	
C1105	RR RH SENSOR-2	<a href="#">BRC-57. "DTC Logic"</a>
C1106	RR LH SENSOR-2	
C1107	FR RH SENSOR-2	
C1108	FR LH SENSOR-2	
C1109	BATTERY VOLTAGE [ABNORMAL]	<a href="#">BRC-64. "DTC Logic"</a>
C1110	CONTROLLER FAILURE	<a href="#">BRC-66. "DTC Logic"</a>
C1111	PUMP MOTOR	<a href="#">BRC-68. "DTC Logic"</a>
C1115	ABS SENSOR [ABNORMAL SIGNAL]	<a href="#">BRC-71. "DTC Logic"</a>
C1116	STOP LAMP SW	<a href="#">BRC-78. "DTC Logic"</a>

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[WITH VDC]

DTC	Display Item	Refer to	
C1120	FR LH IN ABS SOL	<a href="#">BRC-83, "DTC Logic"</a>	A
C1121	FR LH OUT ABS SOL	<a href="#">BRC-85, "DTC Logic"</a>	
C1122	FR RH IN ABS SOL	<a href="#">BRC-83, "DTC Logic"</a>	B
C1123	FR RH OUT ABS SOL	<a href="#">BRC-85, "DTC Logic"</a>	
C1124	RR LH IN ABS SOL	<a href="#">BRC-83, "DTC Logic"</a>	
C1125	RR LH OUT ABS SOL	<a href="#">BRC-85, "DTC Logic"</a>	C
C1126	RR RH IN ABS SOL	<a href="#">BRC-83, "DTC Logic"</a>	
C1127	RR RH OUT ABS SOL	<a href="#">BRC-85, "DTC Logic"</a>	D
C1130	ENGINE SIGNAL 1	<a href="#">BRC-87, "DTC Logic"</a>	
C1140	ACTUATOR RLY	<a href="#">BRC-89, "DTC Logic"</a>	
C1142	PRESS SEN CIRCUIT	<a href="#">BRC-91, "DTC Logic"</a>	E
C1143	ST ANG SEN CIRCUIT	<a href="#">BRC-94, "DTC Logic"</a>	
C1144	ST ANG SEN SIGNAL	<a href="#">BRC-98, "DTC Logic"</a>	BRC
C1145	YAW RATE SENSOR	<a href="#">BRC-100, "DTC Logic"</a>	
C1146	SIDE G SEN CIRCUIT		
C1155	BR FLUID LEVEL LOW	<a href="#">BRC-103, "DTC Logic"</a>	G
C1161	SIDE G SEN SET	<a href="#">BRC-107, "DTC Logic"</a>	
C1162	PRESS SEN SET	<a href="#">BRC-108, "DTC Logic"</a>	
C1164	CV 1	<a href="#">BRC-110, "DTC Logic"</a>	H
C1165	CV 2		
C1166	SV 1	<a href="#">BRC-112, "DTC Logic"</a>	I
C1167	SV 2		
U1000	CAN COMM CIRCUIT	<a href="#">BRC-114, "DTC Logic"</a>	J
U1002	SYSTEM COMM(CAN)	<a href="#">BRC-115, "DTC Logic"</a>	

# BRAKE CONTROL SYSTEM

[WITH VDC]


< WIRING DIAGRAM >

## WIRING DIAGRAM

### BRAKE CONTROL SYSTEM

Wiring Diagram

INFOID:000000012406750



2015/09/04

JRFWC4315GB




# BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[WITH VDC]

## BRAKE CONTROL SYSTEM


Connector No.	B4
Connector Name	WIRE TO WIRE
Connector Type	W13DMV/CS10



**HS**

Terminal No.	Color Of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	LG	-
4	P	-
5	L	-
6	R	-
7	W	-
8	B	-
9	SB	-
10	L	-
11	V	-
12	LG	-
14	OG	-
15	V	-
16	O	-
17	G	-
18	G	-
20	SB	-


Connector No.	B1D
Connector Name	WIRE TO WIRE
Connector Type	RH04FB



**HS**

Terminal No.	Color Of Wire	Signal Name [Specification]
1	SB	-
2	L	-
3	V	-
4	LG	-


Connector No.	CS
Connector Name	REAR WHEEL SENSOR LH
Connector Type	RH02FY



**HS**

Terminal No.	Color Of Wire	Signal Name [Specification]
5	L	-
6	R	-


Connector No.	C1D
Connector Name	REAR WHEEL SENSOR RH
Connector Type	RH02FY



**HS**

Terminal No.	Color Of Wire	Signal Name [Specification]
7	P	-
8	V	-


Connector No.	C11
Connector Name	WIRE TO WIRE
Connector Type	RH04MB



**HS**

Terminal No.	Color Of Wire	Signal Name [Specification]
2	L	-
3	V	-
4	P	-

Connector No.	E1D
Connector Name	POWER DISTRIBUTION MODULE ENGINE ROOM
Connector Type	W12DFW/CS12/AMA 1V



**HS**

Terminal No.	Color Of Wire	Signal Name [Specification]
4	LG	-
5	Y	-
7	BR	-
10	P	-
12	B	-
13	G	-
15	L	-
16	R	-
18	P	-
19	V	-
20	W	-
21	O	-
22	SB	-
23	GR	-
24	G	-
25	GR	-
26	BR	-
30	LG	-
34	O	-
35	P	-
36	G	-
38	GR	-

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# BRAKE CONTROL SYSTEM

[WITH VDC]

< WIRING DIAGRAM >


## BRAKE CONTROL SYSTEM

Connector No.	E22
Connector Name	FRONT WHEEL SENSOR LH
Connector Type	RN0234B




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	LG	-

Connector No.	E27
Connector Name	PARKING BRAKE SWITCH
Connector Type	PD1FB-A



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-

Connector No.	E36
Connector Name	MANUFACTURER AND ELECTRIC UNIT (GENERAL UNIT)
Connector Type	AE227FB-A1Z4-LH



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	VALVE BATTERY
2	X	RR LH WHEEL SENSOR SIGNAL
3	L	RR RH WHEEL SENSOR POWER SUPPLY
4	G	G SENSOR POWER SUPPLY
5	B	FR RH WHEEL SENSOR POWER SUPPLY
6	W	FR RH WHEEL SENSOR SIGNAL
7	V	BRAKE FLUID LEVEL SWITCH SIGNAL
8	LG	FR LH WHEEL SENSOR SIGNAL
9	L	FR LH WHEEL SENSOR POWER SUPPLY
10	B	G SENSOR GND
11	V	RR RH WHEEL SENSOR POWER SUPPLY
12	P	RR RH WHEEL SENSOR SIGNAL
13	B	GROUND
14	G	MOTOR BATTERY
16	SB	STOP LAMP SWITCH SIGNAL
19	Y	G SENSOR SIGNAL (L)
20	GR	IGN
21	P	CAN-L
22	BR	VDC OFF SWITCH SIGNAL
23	L	CAN-H
25	O	G SENSOR SIGNAL (L)
26	B	GROUND

Connector No.	E37
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	Y027G1



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	B/W	-

Connector No.	E39
Connector Name	FRONT WHEEL SENSOR RH
Connector Type	RN0234B




Terminal No.	Color of Wire	Signal Name [Specification]
3	B	-
4	W	-

Connector No.	E100
Connector Name	FUSE BLOCK (1/8)
Connector Type	NS16FFV-CS




Terminal No.	Color of Wire	Signal Name [Specification]
11E	G	-
12F	V	-
1F	SB	-
2F	R	-
4F	L	-
6F	LG	-
8F	P	-
9F	BR	-

Connector No.	E104
Connector Name	WIRE TO WIRE
Connector Type	NR10FFV-CS10



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	-
2	GR	-
3	BR	-
4	L	-
5	R	-
6	LG	-
7	G	-
8	R	-
9	Y	-
10	L	-
11	P	-
12	V	-
14	LG	-
15	V	-
19	W	-
18	GR	-
19	SB	-
20	V	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TR70MW-CS10-M3



JRFWC4317GB

# BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >


[WITH VDC]

## BRAKE CONTROL SYSTEM

Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	W	-
3	R	-
4	R	-
6	LG	-
7	R	-
8	GR	-
9	V	-
10	BR	-
11	Y	-
12	O	-
13	W	-
14	L	-
15	P	-
31	GR	-
32	V	-
37	BR	-
38	G	-
39	V	-
40	P	-
41	L	-
42	LG	-
43	O	-
45	P	-
46	SB	-
47	V	-
49	L	-
51	BR	-
52	G	-
53	O	-
54	Y	-
55	V	-
56	SHIELD	-
61	P	-
62	G	-
63	W/L	-
64	W/R	-
66	W	-
67	Y	-
69	R	-
71	R	-
72	L	-
73	GR	-
74	Y	-
75	SB	-
76	Y	-
77	G	-
78	O	-

80	R	-
81	LG	-
82	R	-

Connector No.	E118
Connector Name	JOINT CONNECTOR-E18
Connector Type	B130FW



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	L	-
3	L	-
6	Y	-
7	Y	-
8	Y	-
9	Y	-
10	Y	-
11	R	-
12	R	-
13	R	-
14	R	-
15	V	-
16	V	-
17	V	-
19	L	-
20	L	-
21	L	-
23	SB	-
24	SB	-
25	BR	-
26	BR	-
27	R	-
28	R	-
29	B/Y	-
30	B/Y	-
32	P	-
33	P	-

Connector No.	E119
Connector Name	JOINT CONNECTOR-E05
Connector Type	B130FW




Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
3	GR	-
4	GR	-
5	GR	-
19	SB	-
20	SB	-
21	SB	-
23	W	-
24	W	-
25	O	-
26	O	-
29	Y	-
30	Y	-
32	BR	-
33	BR	-

Connector No.	E122
Connector Name	JOINT CONNECTOR-E03
Connector Type	TK04FW-J



Terminal No.	Color Of Wire	Signal Name [Specification]
1	L	-
2	L	-
3	L	-
4	L	-

Connector No.	E123
Connector Name	JOINT CONNECTOR-E04
Connector Type	TK04FW-J



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	P	-
3	P	-
4	P	-

Connector No.	E126
Connector Name	STOP LAMP SWITCH
Connector Type	TK04FB-LC



Terminal No.	Color Of Wire	Signal Name [Specification]
1	P	-
2	R	-
3	O	-
4	W	-

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[WITH VDC]


## BRAKE CONTROL SYSTEM

Connector No.	M5
Connector Name	VDC OFF SWITCH
Connector Type	TH08FW-NH




Terminal No.	Color Of Wire	Signal Name [Specification]
1	G	-
2	B	-
3	P	-
4	GR	-

Connector No.	M6
Connector Name	FUSE BLOCK (I/B)
Connector Type	CS08FW-MZ




Terminal No.	Color Of Wire	Signal Name [Specification]
1A	Y	-
2A	G	-
3A	L	-
4A	GR	-
5A	V	-
6A	R	-
7A	GR	-
8A	L	-

Connector No.	M11
Connector Name	WIRE TO WIRE
Connector Type	TH708FW-CS10-4B3



Terminal No.	Color Of Wire	Signal Name [Specification]
1	SHIELD	-
2	W	-
3	B	-
4	R	-
6	G	-
7	R	-
8	G	-
9	B	-
10	R	-
11	W	-
12	L	- [Without automatic drive positioner]
12	LG	- [With automatic drive positioner]
13	G	- [Without automatic drive positioner]
13	L	- [With automatic drive positioner]
14	P	-
15	R	-
17	R	-
18	GR	-
37	BR	- [Without automatic drive positioner]
37	W	- [With automatic drive positioner]
38	R	-
39	BE	- [Without automatic drive positioner]
39	Y	- [With automatic drive positioner]
40	P	-
41	L	-
42	G	-
43	W	-
45	P	-
46	V	-
47	R	-
49	G	-
51	G	-
52	W	-
53	B	-
54	LG	-
55	L	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH08FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	O	BATTERY POWER SUPPLY [With automatic drive positioner]
1	P	BATTERY POWER SUPPLY [Without automatic drive positioner]
2	G	IGNITION SIGNAL [Without automatic drive positioner]
2	Y	IGNITION SIGNAL [With automatic drive positioner]
3	B	GROUND
4	B	GROUND
5	B	ILLUMINATION CONTROL SIGNAL [Without automatic drive positioner]
5	B/P	ILLUMINATION CONTROL SIGNAL [With automatic drive positioner]
6	G	TIP RESET SWITCH SIGNAL [Without automatic drive positioner]
6	SB	TIP RESET SWITCH SIGNAL [With automatic drive positioner]
10	P	METER CONTROL SWITCH GROUND
11	G	METER CONTROL SWITCH GROUND
12	BR	SELECT SWITCH SIGNAL [With automatic drive positioner]
12	R	SELECT SWITCH SIGNAL [Without automatic drive positioner]
13	W	SELECT SWITCH SIGNAL [Without automatic drive positioner]
13	V	SELECT SWITCH SIGNAL [With automatic drive positioner]
14	G	ILLUMINATION CONTROL SWITCH SIGNAL [Without automatic drive positioner]
14	V	ILLUMINATION CONTROL SWITCH SIGNAL [With automatic drive positioner]
15	BR	AIR BAGS SIGNAL
16	L	ENGINE COOLANT TEMPERATURE SIGNAL
18	L	AMBIENT SENSOR SIGNAL [Without automatic drive positioner]
18	LG	AMBIENT SENSOR SIGNAL [With automatic drive positioner]
19	R	A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL
20	G	AMBIENT SENSOR GROUND [Without automatic drive positioner]
20	V	AMBIENT SENSOR GROUND [With automatic drive positioner]
21	L	CAN-H
22	P	CAN-L
23	B	GROUND
24	B	FUEL LEVEL SENSOR GROUND
25	BR	ALTERNATOR SIGNAL [Without automatic drive positioner]
25	W	ALTERNATOR SIGNAL [With automatic drive positioner]
26	BR	PARKING BRAKE SWITCH SIGNAL
27	BE	BIKING BRAKE SWITCH SIGNAL [Without automatic drive positioner]
27	Y	BIKING BRAKE SWITCH SIGNAL [With automatic drive positioner]
28	V	SECURITY SIGNAL
29	G	WASHER LEVEL SWITCH SIGNAL

56	SHIELD	-
57	W	-
58	R	-
59	W	-
60	W	-
61	W	-
62	W	-
63	W	-
64	W	-
65	W	-
66	W	-
67	BR	-
68	P	-
69	R	-
70	L	-
71	R	-
72	L	-
73	LG	-
74	Y	-
75	Y	-
76	V	-
77	P	-
78	BR	-
80	Y	-
81	W	-
82	L	-
83	R	-

Connector No.	M30
Connector Name	STEERING ANGLE SENSOR
Connector Type	TH08FW-NH



Terminal No.	Color Of Wire	Signal Name [Specification]
1	GR	-
2	P	-
4	G	-
5	L	-

# BRAKE CONTROL SYSTEM

< WIRING DIAGRAM >

[WITH VDC]


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

## BRAKE CONTROL SYSTEM

31	SB	VEHICLE SPEED SIGNAL (8-PULSE)
32	B	OVERDRIVE CONTROL SWITCH SIGNAL
33	R	FUEL LEVEL SENSOR SIGNAL
34	BR	DRIVER'S SEAT BELT WARNING SIGNAL
35	BR	PASSENGER'S SEAT BELT WARNING SIGNAL
36	BR	PASSENGER SEAT BELT WARNING SIGNAL

Connector No.	M52
Connector Name	YAW RATE / SIDE G SENSOR
Connector Type	AAZDHF85




Terminal No.	Color Of Wire	Signal Name (Specification)
1	B	GROUND
2	P	CANL
3	L	CANH
4	LG	12V

Connector No.	M55
Connector Name	WIRE TO WIRE
Connector Type	TRH4FW-NH



Terminal No.	Color Of Wire	Signal Name (Specification)
1	W	-
2	L	-
3	LG	-
4	B	-

Connector No.	M107
Connector Name	JOINT CONNECTOR-M14
Connector Type	BB3FW



Terminal No.	Color Of Wire	Signal Name (Specification)
2	R	-
3	R	-
4	R	-
6	O	-
7	O	-
8	O	-
9	P	-
10	P	-
11	O	-
12	Y	-
13	Y	-
14	Y	-
15	B	-
16	B	-
17	B	-
20	G	-
21	G	[With automatic drive positioner]
22	G	[With automatic drive positioner]
23	V	[With automatic drive positioner]
24	V	[With automatic drive positioner]
25	LG	-
26	LG	-
27	V	-
29	P	-
30	P	-
31	P	-
32	P	-
33	P	-

Connector No.	M137
Connector Name	WIRE TO WIRE
Connector Type	TRH4FW-NH



Terminal No.	Color Of Wire	Signal Name (Specification)
1	LG	-
2	L	-
3	P	-
4	B	-

# BASIC INSPECTION

## DIAGNOSIS AND REPAIR WORK FLOW

### Work Flow

INFOID:000000012780030

#### DETAILED FLOW

### 1. INTERVIEW FROM THE CUSTOMER

Clarify customer complaints before inspection. First of all, perform an interview utilizing [BRC-47, "Diagnostic Work Sheet"](#) and reproduce the symptom as well as fully understand it. Ask customer about his/her complaints carefully. Check symptoms by driving vehicle with customer, if necessary.

**CAUTION:**

**Customers are not professional. Never guess easily like "maybe the customer means that..." or "maybe the customer mentions this symptom".**

&gt;&gt; GO TO 2.

### 2. CHECK SYMPTOM

Reproduce the symptom that is indicated by the customer, based on the information from the customer obtained by interview. Also check that the symptom is not caused by fail-safe mode. Refer to [BRC-37, "Fail-safe"](#).

**CAUTION:**

**When the symptom is caused by normal operation, fully inspect each portion and obtain the understanding of customer that the symptom is not caused by a malfunction.**

&gt;&gt; GO TO 3.

### 3. PERFORM THE SELF-DIAGNOSIS

Ⓟ With CONSULT

1. Turn the ignition switch OFF → ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "ABS".

Is DTC detected?

YES >> Record or print self-diagnosis results and freeze frame data (FFD). GO TO 4.

NO >> GO TO 6.

### 4. RECHECK THE SYMPTOM

Ⓟ With CONSULT

1. Erase self-diagnostic results for "ABS".
2. Turn the ignition switch OFF → ON → OFF.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

3. Perform DTC confirmation procedures for the error-detected system.

**NOTE:**

If some DTCs are detected at the same time, determine the order for performing the diagnosis based on [BRC-37, "DTC Inspection Priority Chart"](#).

Is DTC detected?

YES >> GO TO 5.

NO >> Check harness and connectors based on the information obtained by interview. Refer to [GI-41, "Intermittent Incident"](#).

### 5. REPAIR OR REPLACE ERROR-DETECTED PART

Ⓟ With CONSULT

1. Repair or replace error-detected parts.
2. Reconnect part or connector after repairing or replacing.
3. When DTC is detected, erase self-diagnostic result for "ABS".

# DIAGNOSIS AND REPAIR WORK FLOW

[WITH VDC]

< BASIC INSPECTION >

**CAUTION:**

- Turn the ignition switch OFF → ON → OFF after erase self-diagnosis result.
- Be sure to wait of 10 seconds after turning ignition switch OFF or ON.

>> GO TO 7.

## 6. IDENTIFY ERROR-DETECTED SYSTEM BY SYMPTOM DIAGNOSIS

Estimate error-detected system based on symptom diagnosis and perform inspection.

Can the error-detected system be identified?

YES >> GO TO 7.

NO >> Check harness and connectors based on the information obtained by interview. Refer to [GI-41](#).  
"Intermittent Incident".

## 7. FINAL CHECK

With CONSULT

1. Check the reference value for "ABS".
2. Recheck the symptom and check that the symptom is not reproduced on the same conditions.

Is the symptom reproduced?

YES >> GO TO 3.

NO >> INSPECTION END

## Diagnostic Work Sheet

INFOID:000000012780031

### DESCRIPTION

- In general, customers have their own criteria for a problem. Therefore, it is important to understand the symptom and status well enough by asking the customer about his/her concerns carefully. To systemize all the information for the diagnosis, prepare the interview sheet referring to the interview points.
- In some cases, multiple conditions that appear simultaneously may cause a DTC to be detected.

### INTERVIEW SHEET SAMPLE

Interview sheet					
Customer name	MR/MS	Registration number		Initial year registration	
		Vehicle type		VIN	
Storage date		Engine/traction Motor		Mileage	km (Mile)
Symptom		<input type="checkbox"/> Does not operate ( ) function			
		<input type="checkbox"/> Warning lamp turns ON.			
		<input type="checkbox"/> ABS or <input type="checkbox"/> BRAKE or <input type="checkbox"/> <input type="checkbox"/> OFF			
		<input type="checkbox"/> Other ( )			
		<input type="checkbox"/> Noise (Location: )		<input type="checkbox"/> Vibration (Location: )	
<input type="checkbox"/> Other ( )					
First occurrence		<input type="checkbox"/> Recently <input type="checkbox"/> Other ( )			
Frequency of occurrence		<input type="checkbox"/> Always <input type="checkbox"/> Under a certain conditions of <input type="checkbox"/> Sometimes ( time(s)/day)			
Climate conditions	<input type="checkbox"/> Irrelevant				
	Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloud <input type="checkbox"/> Rain <input type="checkbox"/> Snow <input type="checkbox"/> Others ( )			
	Temperature	<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold <input type="checkbox"/> Temperature [Approx. °C (°F)]			
	Relative humidity	<input type="checkbox"/> High <input type="checkbox"/> Moderate <input type="checkbox"/> Low			
Road conditions		<input type="checkbox"/> Ordinary road <input type="checkbox"/> Highway <input type="checkbox"/> Mountainous road (uphill or downhill) <input type="checkbox"/> Rough road			

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[WITH VDC]

Interview sheet

Customer name	MR/MS	Registration number		Initial year registration	
		Vehicle type		VIN	
Storage date		Engine/traction Motor		Mileage	km (Mile)
Operating condition, etc.		<input type="checkbox"/> Irrelevant <input type="checkbox"/> When engine/traction motor starts <input type="checkbox"/> During idling <input type="checkbox"/> During driving <input type="checkbox"/> During acceleration <input type="checkbox"/> At constant speed driving <input type="checkbox"/> During deceleration <input type="checkbox"/> Immediately before stop [Vehicle speed: Approx.      km/h (MPH)] <input type="checkbox"/> During cornering (right curve or left curve) <input type="checkbox"/> When steering wheel is steered (to right or to left)			
Other conditions	VDC OFF switch operation	<input type="checkbox"/> Yes <input type="checkbox"/> No			
	Use of other functions (ex. ICC)	<input type="checkbox"/> Yes <input type="checkbox"/> No (      )			
	Presence of non-genuine parts installation	<input type="checkbox"/> Yes <input type="checkbox"/> No (      )			

Memo



# ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< BASIC INSPECTION >

[WITH VDC]

## ADDITIONAL SERVICE WHEN REPLACING ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### Description

INFOID:000000012406753

When replaced the ABS actuator and electric unit (control unit), Perform steering angle sensor neutral position. Refer to [BRC-50, "Description"](#).

- A
- B
- C
- D
- E
- BRC**
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P

# ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

< BASIC INSPECTION >

[WITH VDC]

## ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

### Description

INFOID:000000012406754

Always adjust the neutral position of steering angle sensor before driving when the following operation is performed Refer to [BRC-50. "Work Procedure"](#).

×: Required —: Not required

Procedure	Adjust the neutral position of steering angle sensor
Removing/ installing ABS actuator and electric unit (control unit)	—
Replacing ABS actuator and electric unit (control unit)	×
Removing/installing steering angle sensor	×
Replacing steering angle sensor	×
Removing/installing steering components	×
Replacing steering components	×
Removing/installing suspension components	×
Replacing suspension components	×
Removing/installing tire	—
Replacing tire	—
Tire rotation	—
Adjusting wheel alignment.	×

### Work Procedure

INFOID:000000012406755

#### ADJUST THE NEUTRAL POSITION OF STEERING ANGLE SENSOR

##### **CAUTION:**

**Always use CONSULT when adjusting the neutral position of steering angle sensor. (It cannot be adjusted other than with CONSULT.)**

#### 1. CHECK THE VEHICLE STATUS


Stop vehicle with front wheels in the straight-ahead position.

Does the vehicle stay in the straight-ahead position?

YES >> GO TO 2.

NO >> Steer the steering wheel to the straight-ahead position. Stop the vehicle.

#### 2. ADJUST NEUTRAL POSITION OF STEERING ANGLE SENSOR

 With CONSULT

1. Turn the ignition switch ON.

##### **CAUTION:**

**Never start engine.**

2. Select "ABS", "WORK SUPPORT" and "ST ANGLE SENSOR ADJUSTMENT" in this order.

3. Select "START".

##### **CAUTION:**

**Never touch steering wheel while adjusting steering angle sensor.**

4. After approx. 10 seconds, select "END".


5. Turn ignition switch OFF, and then turn it ON again.

##### **CAUTION:**

**Be sure to perform the operation above.**

>> GO TO 3.

#### 3. CHECK DATA MONITOR

 With CONSULT

1. The vehicle is either pointing straight ahead, or the vehicle needs to be moved [30 – 50 km/h (19 – 31 MPH)]. Stop when it is pointing straight ahead.

# ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

< BASIC INSPECTION >

[WITH VDC]

2. Select "ABS", "DATA MONITOR", "ECU INPUT SIGNALS" and "STR ANGLE SIG" in the order. Check that the signal is within the specified value.

**STR ANGLE SIG :  $0 \pm 3.5^\circ$**

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 1.

## 4. ERASE SELF-DIAGNOSIS MEMORY

 With CONSULT

Erase self-diagnosis result of "ABS".

Are the memories erased?

- YES >> INSPECTION END  
NO >> Check the items indicated by the self-diagnosis.

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## DTC/CIRCUIT DIAGNOSIS

### C1101, C1102, C1103, C1104 WHEEL SENSOR

#### DTC Logic

INFOID:000000012780033

#### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1101	RR RH SENSOR-1 (Rear RH wheel sensor-1)	When an open circuit is detected in rear RH wheel sensor circuit.
C1102	RR LH SENSOR-1 (Rear LH wheel sensor-1)	When an open circuit is detected in rear LH wheel sensor circuit.
C1103	FR RH SENSOR-1 (Front RH wheel sensor-1)	When an open circuit is detected in front RH wheel sensor circuit.
C1104	FR LH SENSOR-1 (Front LH wheel sensor-1)	When an open circuit is detected in front LH wheel sensor circuit.

#### POSSIBLE CAUSE

##### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Wheel sensor</li><li>• ABS actuator and electric unit (control unit)</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li><li>• Vehicle was not driven after previous repair</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

##### 2. CHECK DTC DETECTION

Ⓟ With CONSULT

1. Start the engine.
2. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
3. Stop the vehicle.
4. Turn the ignition switch OFF.

##### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

5. Start the engine.

##### NOTE:

Wait at least 10 seconds after start the engine.

6. Perform self-diagnosis for "ABS".

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES-1 >> "C1101", "C1102", "C1103" or "C1104" is displayed by "CRNT": Proceed to [BRC-53. "Diagnosis Procedure"](#).

# C1101, C1102, C1103, C1104 WHEEL SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

YES-2 >> "C1101", "C1102", "C1103" and "C1104" are displayed by "PAST": INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

## Diagnosis Procedure

INFOID:000000012780034

### CAUTION:

Never check between wheel sensor harness connector terminals.

### 1. CHECK WHEEL SENSOR

1. Turn the ignition switch OFF.
2. Check the wheel sensor for damage.

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

### 2. REPLACE WHEEL SENSOR (1)

Ⓜ With CONSULT

1. Replace the wheel sensor.
  - Front: Refer to [BRC-135, "FRONT WHEEL SENSOR : Removal and Installation"](#).
  - Rear: Refer to [BRC-136, "REAR WHEEL SENSOR : Removal and Installation"](#).
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF → ON → OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

4. Start the engine.
5. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.

#### NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

6. Stop the vehicle.
7. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

8. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

9. Perform self-diagnosis for "ABS".

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 3.

NO >> INSPECTION END

### 3. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check the wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 4.

### 4. PERFORM SELF-DIAGNOSIS (1)

Ⓜ With CONSULT

1. Erase self-diagnosis result for "ABS".
2. Turn the ignition switch OFF → ON → OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.
4. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.

#### NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs.

# C1101, C1102, C1103, C1104 WHEEL SENSOR

[WITH VDC]

## < DTC/CIRCUIT DIAGNOSIS >

5. Stop the vehicle.
6. Turn the ignition switch OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF.
7. Start the engine.  
**NOTE:**  
Wait at least 10 seconds after start the engine.
8. Perform self-diagnosis for "ABS".

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

- YES >> GO TO 5.  
NO >> INSPECTION END

## 5.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Repair / replace harness, connector, fuse, or fusible link.

## 6.CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
3. Disconnect wheel sensor harness connector and check each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 8.  
NO >> Repair / replace harness, connector, or terminal, and GO TO 7.

## 7.PERFORM SELF-DIAGNOSIS (2)

 With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF → ON → OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF or ON.
5. Start the engine.
6. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.  
**NOTE:**  
Vehicle must be driven after repair or replacement to erase the previous DTCs.
7. Stop the vehicle.
8. Turn the ignition switch OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF.
9. Start the engine.  
**NOTE:**  
Wait at least 10 seconds after start the engine.
10. Perform self-diagnosis for "ABS".

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

- YES >> GO TO 8.  
NO >> INSPECTION END

## 8.CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect wheel sensor harness connector.

# C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Check the continuity while turning steering wheel left and right, or while moving center harness in wheel housing.)
  - Measurement connector and terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor			Continuity
Connector	Terminal	Connector	Terminal	Terminal	
E36	9	E22	(Front LH wheel)	1	Existed
	5	E39	(Front RH wheel)	3	
	3	C9	(Rear LH wheel)	5	
	11	C10	(Rear RH wheel)	7	

- Measurement connector and terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor			Continuity
Connector	Terminal	Connector	Terminal	Terminal	
E36	8	E22	(Front LH wheel)	2	Existed
	6	E39	(Front RH wheel)	4	
	2	C9	(Rear LH wheel)	6	
	12	C10	(Rear RH wheel)	8	

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair / replace harness or connector, and GO TO 9.

## 9. PERFORM SELF-DIAGNOSIS (3)

Ⓜ With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF → ON → OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF or ON.

5. Start the engine.
6. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.

**NOTE:**

Vehicle must be driven after repair or replacement to erase the previous DTCs.

7. Stop the vehicle.
8. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

9. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

10. Perform self-diagnosis for "ABS".

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> GO TO 10.

NO >> INSPECTION END

## 10. CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Disconnect ABS actuator and electric unit (control unit) harness connector.
2. Disconnect wheel sensor harness connector.
3. Connect ABS active wheel sensor tester (SST: J-45741-A) to wheel sensor using appropriate adapter.
4. Turn the ABS active wheel sensor tester power switch ON.

**NOTE:**

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

## C1101, C1102, C1103, C1104 WHEEL SENSOR

[WITH VDC]

### < DTC/CIRCUIT DIAGNOSIS >

5. Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash ON and OFF to indicate an output signal.

**NOTE:**

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).

NO >> GO TO 11.

## 11. REPLACE WHEEL SENSOR

### Ⓟ With CONSULT

1. Replace the wheel sensor.
  - Front: Refer to [BRC-135. "FRONT WHEEL SENSOR : Removal and Installation"](#).
  - Rear: Refer to [BRC-136. "REAR WHEEL SENSOR : Removal and Installation"](#).
2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF → ON → OFF.

**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF or ON.
5. Start the engine.
6. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.

**NOTE:**  
Vehicle must be driven after repair or replacement to erase the previous DTCs.
7. Stop the vehicle.
8. Turn the ignition switch OFF.

**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF.
9. Start the engine.

**NOTE:**  
Wait at least 10 seconds after start the engine.
10. Perform self-diagnosis for "ABS".

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).

NO >> INSPECTION END



# C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1105, C1106, C1107, C1108 WHEEL SENSOR

### DTC Logic

INFOID:000000012780035

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1105	RR RH SENSOR-2 (Rear RH wheel sensor-2)	<ul style="list-style-type: none"> <li>When power supply voltage of rear RH wheel sensor is low.</li> <li>When distance between rear RH wheel sensor and rear RH wheel sensor rotor is large.</li> <li>When installation of rear RH wheel sensor or rear RH wheel sensor rotor is not normal.</li> <li>When there is contamination on or damage to the rear RH wheel sensor or rear RH sensor rotor.</li> </ul>
C1106	RR LH SENSOR-2 (Rear LH wheel sensor-2)	<ul style="list-style-type: none"> <li>When power supply voltage of rear LH wheel sensor is low.</li> <li>When distance between rear LH wheel sensor and rear LH wheel sensor rotor is large.</li> <li>When installation of rear LH wheel sensor or rear LH wheel sensor rotor is not normal.</li> <li>When there is contamination on or damage to the rear LH wheel sensor or rear LH sensor rotor.</li> </ul>
C1107	FR RH SENSOR-2 (Front RH wheel sensor-2)	<ul style="list-style-type: none"> <li>When power supply voltage of front RH wheel sensor is low.</li> <li>When distance between front RH wheel sensor and front RH wheel sensor rotor is large.</li> <li>When installation of front RH wheel sensor or front RH wheel sensor rotor is not normal.</li> <li>When there is contamination on or damage to the front RH wheel sensor or front RH sensor rotor.</li> </ul>
C1108	FR LH SENSOR-2 (Front LH wheel sensor-2)	<ul style="list-style-type: none"> <li>When power supply voltage of front LH wheel sensor is low.</li> <li>When distance between front LH wheel sensor and front LH wheel sensor rotor is large.</li> <li>When installation of front LH wheel sensor or front LH wheel sensor rotor is not normal.</li> <li>When there is contamination on or damage to the front LH wheel sensor or front LH sensor rotor.</li> </ul>

### POSSIBLE CAUSE

**NOTE:**

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"> <li>Harness or connector</li> <li>Wheel sensor</li> <li>Sensor rotor</li> <li>Tire size</li> <li>ABS actuator and electric unit (control unit) power supply system</li> <li>Fuse</li> <li>Fusible link</li> <li>Battery</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connector</li> <li>Wheel sensor</li> <li>Sensor rotor</li> <li>ABS actuator and electric unit (control unit)</li> <li>Tire size</li> <li>ABS actuator and electric unit (control unit) power supply system</li> <li>Fuse</li> <li>Fusible link</li> <li>Battery</li> <li>Vehicle was not driven after previous repair</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

Ⓜ With CONSULT

1. Start the engine.
2. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
3. Stop the vehicle.
4. Turn the ignition switch OFF.

# C1105, C1106, C1107, C1108 WHEEL SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

5. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

6. Perform self-diagnosis for "ABS".

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES-1 >> "C1105", "C1106", "C1107" or "C1108" is displayed by "CRNT": Proceed to [BRC-58, "Diagnosis Procedure"](#).

YES-2 >> "C1105", "C1106", "C1107" and "C1108" are displayed by "PAST": INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

## Diagnosis Procedure

INFOID:000000012780036

**CAUTION:**

**Never check between wheel sensor harness connector terminals.**

### 1. CHECK WHEEL HUB ASSEMBLY

Check that there is no excessive looseness in wheel hub assembly.

- Front: Refer to [FAX-11, "Inspection"](#).
- Rear: Refer to [RAX-8, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

- NO >> Repair or replace the wheel hub assembly, and GO TO 2.
- Front: Refer to [FAX-9, "Removal and Installation"](#).
  - Rear: Refer to [RAX-7, "Removal and Installation"](#).

### 2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

- NO >> Repair / replace harness, connector, fuse, or fusible link.

### 3. CHECK TIRE


1. Turn the ignition switch OFF.
2. Check the tire air pressure, wear and size. Refer to [WT-55, "Tire Air Pressure"](#).

Is the inspection result normal?

YES >> GO TO 6.

- NO >> Adjust air pressure or replace tire, and GO TO 4.

### 4. CHECK DATA MONITOR (1)

 With CONSULT

1. Erase self-diagnosis result for "ABS".
2. Turn the ignition switch OFF → ON → OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

**NOTE:**

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

**NOTE:**

Vehicle must be driven after repair or replacement to erase the previous DTCs.

# C1105, C1106, C1107, C1108 WHEEL SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%. respectively?

- YES >> GO TO 5.  
NO >> GO TO 6.

## 5.PERFORM SELF-DIAGNOSIS (1)

Ⓜ With CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

3. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

4. Perform self-diagnosis for "ABS".

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> GO TO 6.  
NO >> INSPECTION END

## 6.CHECK WHEEL SENSOR AND SENSOR ROTOR

1. Turn the ignition switch OFF.
2. Disconnect wheel sensor harness connector.
3. Remove dust and foreign matter adhered to the wheel sensor and sensor rotor with a vacuum dust collector through the wheel sensor mounting hole.

**CAUTION:**

**Install wheel sensor with no backlash and float, and tighten the mounting bolt to the specified torque.**

- Front: Refer to [BRC-135, "FRONT WHEEL SENSOR : Exploded View"](#).
- Rear: Refer to [BRC-136, "REAR WHEEL SENSOR : Exploded View"](#).

>> GO TO 7.

## 7.CHECK WHEEL SENSOR

Check the wheel sensor for damage.

Is the inspection result normal?

- YES >> GO TO 8.  
NO >> GO TO 9.

## 8.CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Disconnect ABS actuator and electric unit (control unit) harness connector.
2. Connect ABS active wheel sensor tester (SST: J-45741-A) to wheel sensor using appropriate adapter.
3. Turn the ABS active wheel sensor tester power switch ON.

**NOTE:**

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

4. Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash ON and OFF to indicate an output signal.

**NOTE:**

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

- YES >> GO TO 12.  
NO >> GO TO 9.

## 9.REPLACE WHEEL SENSOR (1)

Ⓜ With CONSULT

1. Replace the wheel sensor.

- Front: Refer to [BRC-135, "FRONT WHEEL SENSOR : Removal and Installation"](#).

# C1105, C1106, C1107, C1108 WHEEL SENSOR

[WITH VDC]

## < DTC/CIRCUIT DIAGNOSIS >

- Rear: Refer to [BRC-136. "REAR WHEEL SENSOR : Removal and Installation"](#).
2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF → ON → OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF or ON.
5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".  
**NOTE:**  
Set the "DATA MONITOR" recording speed to "10 msec".
7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.  
**NOTE:**  
Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors. is the difference within 5%, respectively?

- YES >> GO TO 10.  
NO >> GO TO 20.

## 10. PERFORM SELF-DIAGNOSIS (2)

Ⓟ With CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF.
3. Start the engine.  
**NOTE:**  
Wait at least 10 seconds after start the engine.
4. Perform self-diagnosis for "ABS".

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> GO TO 11.  
NO >> INSPECTION END

## 11. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check the wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

- YES >> GO TO 14.  
NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 12.

## 12. CHECK DATA MONITOR (2)

Ⓟ With CONSULT

1. Erase self-diagnosis result for "ABS".
2. Turn the ignition switch OFF → ON → OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF or ON.
3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".  
**NOTE:**  
Set the "DATA MONITOR" recording speed to "10 msec".
5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.  
**NOTE:**  
Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors. is the difference within 5%, respectively?

# C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

- YES >> GO TO 13.
- NO >> GO TO 14.

## 13.PERFORM SELF-DIAGNOSIS (3)

ⓂWith CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF.
3. Start the engine.  
**NOTE:**  
Wait at least 10 seconds after start the engine.
4. Perform self-diagnosis for "ABS".

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> GO TO 14.
- NO >> INSPECTION END

## 14.CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
3. Disconnect wheel sensor harness connector and check each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 17.
- NO >> Repair / replace harness, connector, or terminal, and GO TO 15.

## 15.CHECK DATA MONITOR (3)

ⓂWith CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF → ON → OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF or ON.
5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".  
**NOTE:**  
Set the "DATA MONITOR" recording speed to "10 msec".
7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.  
**NOTE:**  
Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%. respectively?

- YES >> GO TO 16.
- NO >> GO TO 17.

## 16.PERFORM SELF-DIAGNOSIS (4)

ⓂWith CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF.
3. Start the engine.  
**NOTE:**  
Wait at least 10 seconds after start the engine.
4. Perform self-diagnosis for "ABS".

# C1105, C1106, C1107, C1108 WHEEL SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> GO TO 17.

NO >> INSPECTION END

## 17. CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect wheel sensor harness connector.
4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	9, 8	Ground	Not existed
	5, 6		
	3, 2		
	11, 12		

Is the inspection result normal?

YES >> GO TO 18.

NO >> Repair / replace harness or connector, and GO TO 18.

## 18. CHECK DATA MONITOR (4)

Ⓜ With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF → ON → OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF or ON.

5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

**NOTE:**

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

**NOTE:**

Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors. Is the difference within 5%, respectively?

YES >> GO TO 19.

NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).

## 19. PERFORM SELF-DIAGNOSIS (5)

Ⓜ With CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

3. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

4. Perform self-diagnosis for "ABS".

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).

# C1105, C1106, C1107, C1108 WHEEL SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

NO >> INSPECTION END

**20**.REPLACE SENSOR ROTOR

 With CONSULT

1. Replace the sensor rotor.
  - Front: Refer to [BRC-138. "FRONT SENSOR ROTOR : Removal and Installation"](#).
  - Rear: Refer to [BRC-138. "REAR SENSOR ROTOR : Removal and Installation"](#).
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF → ON → OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF or ON.

4. Start the engine.
5. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.

**NOTE:**

Vehicle must be driven after repair or replacement to erase the previous DTCs.

6. Stop the vehicle.
7. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

8. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

9. Perform self-diagnosis for "ABS".

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).

NO >> INSPECTION END

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1109 POWER AND GROUND SYSTEM

### DTC Logic

INFOID:000000012780037

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1109	BATTERY VOLTAGE [ABNORMAL] (Battery voltage [abnormal])	When ignition power supply voltage is in following state. <ul style="list-style-type: none"><li>• Ignition power supply voltage: <math>10\text{ V} \geq</math> ignition power supply voltage.</li><li>• Ignition power supply voltage: <math>16\text{ V} \leq</math> ignition power supply voltage.</li></ul>

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li><li>• Charge system</li></ul>	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li><li>• IPDM E/R</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li><li>• Charge system</li></ul>


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

#### Is DTC "C1109" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-64, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780038

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.

2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

#### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.



# C1109 POWER AND GROUND SYSTEM

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

## 2. PERFORM SELF-DIAGNOSIS

Ⓜ With CONSULT

1. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1109" detected?

YES >> GO TO 3.

NO >> INSPECTION END

## 3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, fuse, or fusible link.

## 4. CHECK TERMINAL

1. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
2. Check the IPDM E/R pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

NO >> Repair / replace harness, connector, or terminal.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### DTC Logic

INFOID:000000012780039

#### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1110	CONTROLLER FAILURE (Controller failure)	When there is an internal malfunction in the ABS actuator and electric unit (control unit).

#### POSSIBLE CAUSE

##### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>• The vehicle travels near high-voltage electrical power lines.</li><li>• Motor built-in the ABS actuator and electric unit (control unit) operates temporarily without a break.</li><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>	<ul style="list-style-type: none"><li>• Incomplete neutral position adjustment of steering angle sensor</li><li>• ABS actuator and electric unit (control unit)</li><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

##### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF.

##### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

##### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1110" detected?

YES-1 >> "C1110" is displayed by "CRNT": Proceed to [BRC-66, "Diagnosis Procedure"](#).

YES-2 >> "C1110" is displayed by "PAST": INSPECTION END (Erase the memory of self-diagnosis results.)


NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

#### Diagnosis Procedure

INFOID:000000012780040

##### 1. ADJUST THE NEUTRAL POSITION OF STEERING ANGLE SENSOR

 With CONSULT

Perform neutral position adjustment of steering angle sensor. Refer to [BRC-50, "Description"](#).

Was neutral position adjustment of steering angle sensor finished?

YES >> GO TO 2.

NO >> Check the steering angle sensor system. Refer to [BRC-94, "DTC Logic"](#).

# C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## 2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness, connector, fuse, or fusible link.

## 3. PERFORM SELF-DIAGNOSIS

 With CONSULT

Perform self-diagnosis for "ABS".

### NOTE:

Replace the ABS actuator and electric unit (control unit) even if other DTCs are displayed along with "C1110" in self-diagnosis for "ABS".

Is DTC "C1110" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

NO >> INSPECTION END (Although motor built-in the ABS actuator and electric unit (control unit) operates temporarily without a break, this is not a malfunction. Erase the memory of self-diagnosis results.)

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1111 ABS MOTOR, MOTOR RELAY SYSTEM

### DTC Logic

INFOID:000000012780041

#### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1111	PUMP MOTOR (Pump motor and motor relay)	When a malfunction is detected in motor or motor relay.

#### POSSIBLE CAUSE

##### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

##### 2. CHECK DTC DETECTION

###### Ⓜ With CONSULT

1. Turn the ignition switch OFF → ON, and wait 30 seconds.
2. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
3. Stop the vehicle.
4. Turn the ignition switch OFF.

##### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

5. Start the engine.

##### NOTE:

Wait at least 10 seconds after start the engine.

6. Perform self-diagnosis for "ABS".

##### Is DTC "C1111" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-68, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

#### Diagnosis Procedure

INFOID:000000012780042

##### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

##### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## 2. PERFORM SELF-DIAGNOSIS

Ⓜ With CONSULT

1. Turn the ignition switch OFF → ON, and wait 30 seconds.
2. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.  
**NOTE:**  
Vehicle must be driven after repair or replacement to erase the previous DTCs.
3. Stop the vehicle.
4. Turn the ignition switch OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF.
5. Start the engine.  
**NOTE:**  
Wait at least 10 seconds after start the engine.
6. Perform self-diagnosis for "ABS".

Is DTC "C1111" detected?

- YES >> GO TO 3.  
NO >> INSPECTION END

## 3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair / replace harness, connector, or fuse, and GO TO 4.

## 4. ERASE SELF-DIAGNOSIS RESULT (1)

Ⓜ With CONSULT

1. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.  
**NOTE:**  
Vehicle must be driven after repair or replacement to erase the previous DTCs.
2. Stop the vehicle.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF → ON → OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF or ON.

>> INSPECTION END

## 5. CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).  
NO >> Repair / replace harness or connector, and GO TO 6.

## 6. ERASE SELF-DIAGNOSIS RESULT (2)

Ⓜ With CONSULT

1. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.  
**NOTE:**  
Vehicle must be driven after repair or replacement to erase the previous DTCs.
2. Stop the vehicle.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF → ON → OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF or ON.

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

---

>> INSPECTION END

# C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1115 WHEEL SENSOR

### DTC Logic

INFOID:000000012780043

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1115	ABS SENSOR [ABNORMAL SIGNAL] (Wheel sensor [abnormal signal])	When difference in wheel speed between any wheel and others is detected the vehicle is driven, because of installation of other tires than specified.

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• Wheel sensor</li> <li>• Sensor rotor</li> <li>• ABS actuator and electric unit (control unit) power supply system</li> <li>• Fuse</li> <li>• Fusible link</li> <li>• Battery</li> </ul>	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• Wheel sensor</li> <li>• Sensor rotor</li> <li>• ABS actuator and electric unit (control unit)</li> <li>• ABS actuator and electric unit (control unit) power supply system</li> <li>• Fuse</li> <li>• Fusible link</li> <li>• Battery</li> <li>• Tire size</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

Ⓜ With CONSULT

1. Start the engine.
2. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.
3. Stop the vehicle.
4. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

5. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

6. Perform self-diagnosis for "ABS".

Is DTC "C1115" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-71, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780044

#### CAUTION:

Never check between wheel sensor harness connector terminals.

# C1115 WHEEL SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

## 1. CHECK TIRE

Check the tire air pressure, wear and size. Refer to [WT-55, "Tire Air Pressure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Adjust air pressure or replace tire and GO TO 2.

## 2. CHECK DATA MONITOR (1)

Ⓜ With CONSULT

1. Erase self-diagnosis result for "ABS".
2. Turn the ignition switch OFF → ON → OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

**NOTE:**

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

**NOTE:**

Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors. is the difference within 5%, respectively?

YES >> GO TO 3.

NO >> GO TO 4.

## 3. PERFORM SELF-DIAGNOSIS (1)

Ⓜ With CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

3. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

4. Perform self-diagnosis for "ABS".

Is DTC "C1115" detected?

YES >> GO TO 4.

NO >> INSPECTION END

## 4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair / replace harness, connector, fuse, or fusible link.

## 5. CHECK WHEEL SENSOR AND SENSOR ROTOR

1. Turn the ignition switch OFF.
2. Disconnect wheel sensor harness connector.
3. Remove dust and foreign matter adhered to the wheel sensor and sensor rotor with a vacuum dust collector through the wheel sensor mounting hole.

**CAUTION:**

Install wheel sensor with no backlash and float, and tighten the mounting bolt to the specified torque.

- Front: Refer to [BRC-135, "FRONT WHEEL SENSOR : Exploded View"](#).
- Rear: Refer to [BRC-136, "REAR WHEEL SENSOR : Exploded View"](#).



# C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

>> GO TO 6.

## 6. CHECK WHEEL SENSOR

Check the wheel sensor for damage.

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 8.

## 7. CHECK WHEEL SENSOR OUTPUT SIGNAL

1. Disconnect ABS actuator and electric unit (control unit) harness connector.
2. Connect ABS active wheel sensor tester (SST: J-45741-A) to wheel sensor using appropriate adapter.
3. Turn the ABS active wheel sensor tester power switch ON.

**NOTE:**

The green POWER indicator should illuminate. If the POWER indicator does not illuminate, replace the battery in the ABS active wheel sensor tester before proceeding.

4. Spin the wheel of the vehicle by hand and observe the red SENSOR indicator on the ABS active wheel sensor tester. The red SENSOR indicator should flash ON and OFF to indicate an output signal.

**NOTE:**

If the red SENSOR indicator illuminates but does not flash, reverse the polarity of the tester leads and retest.

Does the ABS active wheel sensor tester detect a signal?

YES >> GO TO 11.

NO >> GO TO 8.

## 8. REPLACE WHEEL SENSOR (1)

Ⓜ With CONSULT

1. Replace the wheel sensor.
  - Front: Refer to [BRC-135, "FRONT WHEEL SENSOR : Removal and Installation"](#).
  - Rear: Refer to [BRC-136, "REAR WHEEL SENSOR : Removal and Installation"](#).
2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF → ON → OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF or ON.

5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

**NOTE:**

Set the "DATA MONITOR" recording speed to "10 msec".

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

**NOTE:**

Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

YES >> GO TO 9.

NO >> GO TO 19.

## 9. PERFORM SELF-DIAGNOSIS (2)

Ⓜ With CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

3. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

4. Perform self-diagnosis for "ABS".

# C1115 WHEEL SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

Is DTC "C1115" detected?

- YES >> GO TO 10.
- NO >> INSPECTION END

## 10. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check the wheel sensor harness connector for disconnection or looseness.

Is the inspection result normal?

- YES >> GO TO 12.
- NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 11.

## 11. CHECK DATA MONITOR (2)

Ⓜ With CONSULT

1. Erase self-diagnosis result for "ABS".
2. Turn the ignition switch OFF → ON → OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF or ON.
3. Start the engine.
4. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".

**NOTE:**

Set the "DATA MONITOR" recording speed to "10 msec".

5. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

**NOTE:**

Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

- YES >> GO TO 12.
- NO >> GO TO 13.

## 12. PERFORM SELF-DIAGNOSIS (3)

Ⓜ With CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF.
3. Start the engine.  
**NOTE:**  
Wait at least 10 seconds after start the engine.
4. Perform self-diagnosis for "ABS".

Is DTC "C1115" detected?

- YES >> GO TO 13.
- NO >> INSPECTION END

## 13. CHECK TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector and then check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
3. Disconnect wheel sensor harness connector and check each wheel sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 16.
- NO >> Repair / replace harness, connector, or terminal, and GO TO 14.

## 14. CHECK DATA MONITOR (3)

Ⓜ With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.

# C1115 WHEEL SENSOR

[WITH VDC]

## < DTC/CIRCUIT DIAGNOSIS >

2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF → ON → OFF.
 

**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF or ON.
5. Start the engine.
6. Select "ABS" and "DATA MONITOR", check "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR".
 

**NOTE:**  
Set the "DATA MONITOR" recording speed to "10 msec".
7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.
 

**NOTE:**  
Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors, is the difference within 5%, respectively?

- YES >> GO TO 15.  
NO >> GO TO 16.

## 15. PERFORM SELF-DIAGNOSIS (4)

Ⓜ With CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.
 

**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF.
3. Start the engine.
 

**NOTE:**  
Wait at least 10 seconds after start the engine.
4. Perform self-diagnosis for "ABS".

Is DTC "C1115" detected?

- YES >> GO TO 16.  
NO >> INSPECTION END

## 16. CHECK WHEEL SENSOR HARNESS

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect wheel sensor harness connector.
4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and wheel sensor harness connector. (Check continuity while turning steering wheel left and right, or while moving center harness in wheel housing.)
  - Measurement connector and terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor			Continuity
Connector	Terminal	Connector	Terminal		
E36	9	E22	(Front LH wheel)	1	Existed
	5	E39	(Front RH wheel)	3	
	3	C9	(Rear LH wheel)	5	
	11	C10	(Rear RH wheel)	7	

- Measurement connector and terminal for signal circuit

# C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

ABS actuator and electric unit (control unit)		Wheel sensor			Continuity
Connector	Terminal	Connector	Terminal	Terminal	
E36	8	E22	(Front LH wheel)	2	Existed
	6	E39	(Front RH wheel)	4	
	2	C9	(Rear LH wheel)	6	
	12	C10	(Rear RH wheel)	8	

5. Check the continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	9, 8	Ground	Not existed
	5, 6		
	3, 2		
	11, 12		

Is the inspection result normal?

YES >> GO TO 17.

NO >> Repair / replace harness or connector, and GO TO 17.

## 17. CHECK DATA MONITOR (4)

With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect wheel sensor harness connector.
3. Erase self-diagnosis result for “ABS”.
4. Turn the ignition switch OFF → ON → OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF or ON.

5. Start the engine.
6. Select “ABS” and “DATA MONITOR”, check “FR LH SENSOR”, “FR RH SENSOR”, “RR LH SENSOR” and “RR RH SENSOR”.

**NOTE:**

Set the “DATA MONITOR” recording speed to “10 msec”.

7. Read a value (wheel speed) of both normal wheel sensors and error-detecting wheel sensor.

**NOTE:**

Vehicle must be driven after repair or replacement to erase the previous DTCs.

Note the difference at 50 km/h (31 MPH) between the wheel speed detected by the error detecting wheel sensor and the maximum/minimum wheel speed detected by the normal wheel sensors. is the difference within 5%. respectively?

YES >> GO TO 18.

NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).

## 18. PERFORM SELF-DIAGNOSIS (5)

With CONSULT

1. Stop the vehicle.
2. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

3. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

4. Perform self-diagnosis for “ABS”.

Is DTC “C1115” detected?

# C1115 WHEEL SENSOR

[WITH VDC]

## < DTC/CIRCUIT DIAGNOSIS >

- YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#). A
- NO >> INSPECTION END

## 19.REPLACE SENSOR ROTOR

### ⓂWith CONSULT

1. Replace the sensor rotor.
  - Front: Refer to [BRC-138. "FRONT SENSOR ROTOR : Removal and Installation"](#).
  - Rear: Refer to [BRC-138. "REAR SENSOR ROTOR : Removal and Installation"](#).
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF → ON → OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON. D

4. Start the engine.
5. Drive the vehicle at approx. 50 km/h (31 MPH) or more for approx. 2 minutes.

#### NOTE:

Vehicle must be driven after repair or replacement to erase the previous DTCs. E

6. Stop the vehicle.
7. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF. BRC

8. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine. G

9. Perform self-diagnosis for "ABS".

### Is DTC "C1115" detected? H

- YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).
- NO >> INSPECTION END I

# C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1116 STOP LAMP SWITCH

### DTC Logic

INFOID:000000012780045

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1116	STOP LAMP SW (Stop lamp switch)	When stop lamp switch signal is not input when brake pedal operates.

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Stop lamp switch signal circuit</li></ul>	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Stop lamp switch</li><li>• ABS actuator and electric unit (control unit)</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF, and wait 10 seconds or more.
2. Start the engine.

#### NOTE:

Stop the vehicle.

3. Wait 1 minute or more.

#### NOTE:

Never depress brake pedal.

4. Depress brake pedal by 100 mm (3.94 in) or more, and maintain at that position for a minimum of 1 minute or more.
5. Release brake pedal, and wait 1 minute or more.
6. Repeat step 4 to 5 ten or more times.
7. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

8. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

9. Perform self-diagnosis for "ABS".

#### Is DTC "C1116" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-79, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

# C1116 STOP LAMP SWITCH

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

## Diagnosis Procedure

INFOID:000000012780046

### NOTE:

DTC "C1116" may be detected when the brake pedal and the accelerator pedal are simultaneously depressed for 1 minute or more while driving the vehicle. This is not a malfunction.

### 1. INTERVIEW FROM THE CUSTOMER

Check if the brake pedal and the accelerator pedal are simultaneously depressed for 1 minute or more while driving the vehicle.

Is there such a history?

YES >> GO TO 2.

NO >> GO TO 3.

### 2. PERFORM SELF-DIAGNOSIS

Ⓟ With CONSULT

1. Erase self-diagnosis result for "ABS".

2. Turn the ignition switch OFF → ON → OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.

#### NOTE:

Stop the vehicle.

4. Depress the brake pedal several times.

5. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

6. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

7. Perform self-diagnosis for "ABS".

Is DTC "C1116" detected?

YES >> GO TO 3.

NO >> INSPECTION END

### 3. STOP LAMP FOR ILLUMINATION

Depress brake pedal and check that stop lamp turns ON.

Does stop lamp turn ON?

YES >> GO TO 5.

NO >> Check the stop lamp system circuit. GO TO 4.

### 4. CHECK DATA MONITOR (1)

Ⓟ With CONSULT

1. Erase self-diagnosis result for "ABS".

2. Turn the ignition switch OFF → ON → OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.

#### NOTE:

Stop the vehicle.

4. Select "ABS", "DATA MONITOR" and "STOP LAMP SW" according to this order. Check that data monitor displays "On" or "Off" when brake pedal is depressed or released. Refer to [BRC-35. "Reference Value"](#).

5. Select "ABS", "DATA MONITOR" and "PRESS SENSOR" according to this order. Check that data monitor displays "5 bar" or less when brake pedal is depressed. Refer to [BRC-35. "Reference Value"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 5.

### 5. CHECK CONNECTOR

1. Turn the ignition switch OFF.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

## C1116 STOP LAMP SWITCH

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check the stop lamp switch harness connector for disconnection or looseness.

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Repair / replace harness or connector, and GO TO 6.

### 6. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 7.  
NO >> Repair / replace harness, connector, fuse, or fusible link.

### 7. CHECK STOP LAMP SWITCH CLEARANCE

1. Turn the ignition switch OFF.
2. Check the stop lamp switch clearance. Refer to [BR-9, "Inspection and Adjustment"](#).

Is the inspection result normal?

- YES >> GO TO 8.  
NO >> Adjust stop lamp switch clearance. Refer to [BR-9, "Inspection and Adjustment"](#). GO TO 8.

### 8. CHECK DATA MONITOR (2)

Ⓜ With CONSULT

1. Erase self-diagnosis result for "ABS".
2. Turn the ignition switch OFF → ON → OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF or ON.
3. Start the engine.  
**NOTE:**  
Stop the vehicle.
4. Select "ABS", "DATA MONITOR" and "STOP LAMP SW" according to this order. Check that data monitor displays "On" or "Off" when brake pedal is depressed or released. Refer to [BRC-35, "Reference Value"](#).
5. Select "ABS", "DATA MONITOR" and "PRESS SENSOR" according to this order. Check that data monitor displays "5 bar" or less when brake pedal is depressed. Refer to [BRC-35, "Reference Value"](#).

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> GO TO 9.

### 9. CHECK STOP LAMP SWITCH

Check the stop lamp switch. Refer to [BRC-82, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 10.  
NO >> Adjust stop lamp switch clearance. Refer to [BR-20, "Exploded View"](#). GO TO 10.

### 10. CHECK DATA MONITOR (3)

Ⓜ With CONSULT

1. Erase self-diagnosis result for "ABS".
2. Turn the ignition switch OFF → ON → OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF or ON.
3. Start the engine.  
**NOTE:**  
Start the vehicle.
4. Select "ABS", "DATA MONITOR" and "STOP LAMP SW" according to this order. Check that data monitor displays "On" or "Off" when brake pedal is depressed or released. Refer to [BRC-35, "Reference Value"](#).
5. Select "ABS", "DATA MONITOR" and "PRESS SENSOR" according to this order. Check that data monitor displays "5 bar" or less when brake pedal is depressed. Refer to [BRC-35, "Reference Value"](#).

Is the inspection result normal?



# C1116 STOP LAMP SWITCH

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> INSPECTION END
- NO >> GO TO 11.


## 11. CHECK CONNECTOR AND TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
4. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
5. Disconnect stop lamp switch harness connector.
6. Check the stop lamp switch harness connector for disconnection or looseness.
7. Check the stop lamp switch pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 13.
- NO >> Repair / replace harness, connector, or terminal, and GO TO 12.

## 12. CHECK DATA MONITOR (4)

 With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect stop lamp switch harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF → ON → OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF or ON.
5. Start the engine.  
**NOTE:**  
Stop the vehicle.
6. Select "ABS", "DATA MONITOR" and "STOP LAMP SW" according to this order. Check that data monitor displays "On" or "Off" when brake pedal is depressed or released. Refer to [BRC-35, "Reference Value"](#).
7. Select "ABS", "DATA MONITOR" and "PRESS SENSOR" according to this order. Check that data monitor displays "5 bar" or less when brake pedal is depressed. Refer to [BRC-35, "Reference Value"](#).

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 13.

## 13. CHECK STOP LAMP SWITCH CIRCUIT (1)

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

+		-	Condition	Voltage
ABS actuator and electric unit (control unit)				
Connector	Terminal	Ground	Brake pedal depressed	10 – 16 V
E36	16			

Is the inspection result normal?

- YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).
- NO >> Repair / replace harness or connector, and GO TO 14.

## 14. CHECK STOP LAMP SWITCH CIRCUIT (2)

1. Turn the ignition switch OFF.
2. Disconnect stop lamp relay harness connector.
3. Check the continuity between ABS actuator and electric unit (control unit) harness connector and stop lamp relay harness connector.

# C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

ABS actuator and electric unit (control unit)		Stop lamp switch		Continuity
Connector	Terminal	Connector	Terminal	
E36	16	E126	2	Existed

- Check the continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	16	Ground	Not existed

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

NO >> Repair / replace harness or connector, and GO TO 15.

## 15.CHECK DATA MONITOR (5)

 With CONSULT

- Connect ABS actuator and electric unit (control unit) harness connector.
- Connect stop lamp switch harness connector.
- Erase self-diagnosis result for "ABS".
- Turn the ignition switch OFF → ON → OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF or ON.

- Start the engine.

**NOTE:**

Stop the vehicle.

- Select "ABS", "DATA MONITOR" and "STOP LAMP SW" according to this order. Check that data monitor displays "On" or "Off" when brake pedal is depressed or released. Refer to [BRC-35, "Reference Value"](#).
- Select "ABS", "DATA MONITOR" and "PRESS SENSOR" according to this order. Check that data monitor displays "5 bar" or less when brake pedal is depressed. Refer to [BRC-35, "Reference Value"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

## Component Inspection

INFOID:000000012780047

### STOP LAMP SWITCH

#### 1.CHECK STOP LAMP SWITCH

- Turn the ignition switch OFF.
- Disconnect stop lamp switch harness connector.
- Check continuity when stop lamp switch is operated.

Stop lamp switch	Condition	Continuity
Terminal		
1 - 2	When stop lamp switch is released (When brake pedal is depressed)	Existed
	When stop lamp switch is pressed (When brake pedal is released)	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace stop lamp switch. Refer to [BR-20, "Exploded View"](#).

# C1120, C1122, C1124, C1126 ABS IN VALVE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1120, C1122, C1124, C1126 ABS IN VALVE SYSTEM

### DTC Logic

INFOID:000000012780048

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1120	FR LH IN ABS SOL (Front LH ABS IN solenoid valve)	When a malfunction is detected in front LH ABS IN valve.
C1122	FR RH IN ABS SOL (Front RH ABS IN solenoid valve)	When a malfunction is detected in front RH ABS IN valve.
C1124	RR LH IN ABS SOL (Rear LH ABS IN solenoid valve)	When a malfunction is detected in rear LH ABS IN valve.
C1126	RR RH IN ABS SOL (Rear RH ABS IN solenoid valve)	When a malfunction is detected in rear RH ABS IN valve.

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit) power supply system</li> <li>• Fuse</li> <li>• Fusible link</li> <li>• Battery</li> </ul>	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit)</li> <li>• ABS actuator and electric unit (control unit) power supply system</li> <li>• Fuse</li> <li>• Fusible link</li> <li>• Battery</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

Ⓜ With CONSULT

1. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1120", "C1122", "C1124" or "C1126" detected?

YES-1 >> "C1120", "C1122", "C1124" or "C1126" is displayed by "CRNT": Proceed to [BRC-83, "Diagnosis Procedure"](#).

YES-2 >> "C1120", "C1122", "C1124" or "C1126" is displayed by "PAST": INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780049

#### 1. CHECK CONNECTOR

## C1120, C1122, C1124, C1126 ABS IN VALVE SYSTEM

[WITH VDC]

### < DTC/CIRCUIT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

#### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.

### 2.PERFORM SELF-DIAGNOSIS

#### With CONSULT

1. Turn the ignition switch OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF.
2. Start the engine.  
**NOTE:**  
Wait at least 10 seconds after start the engine.
3. Perform self-diagnosis for "ABS".

#### Is DTC "C1120", "C1122", "C1124" or "C1126" detected?

YES >> GO TO 3.

NO >> INSPECTION END

### 3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

#### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, fuse, or fusible link.

### 4.CHECK TERMINAL

Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

#### Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

NO >> Repair / replace harness, connector, or terminal.

# C1121, C1123, C1125, C1127 ABS OUT VALVE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1121, C1123, C1125, C1127 ABS OUT VALVE SYSTEM

### DTC Logic

INFOID:000000012780050

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1121	FR LH OUT ABS SOL (Front LH ABS OUT solenoid valve)	When a malfunction is detected in front LH ABS OUT valve.
C1123	FR RH OUT ABS SOL (Front RH ABS OUT solenoid valve)	When a malfunction is detected in front RH ABS OUT valve.
C1125	RR LH OUT ABS SOL (Rear LH ABS OUT solenoid valve)	When a malfunction is detected in rear LH ABS OUT valve.
C1127	RR RH OUT ABS SOL (Rear RH ABS OUT solenoid valve)	When a malfunction is detected in rear RH ABS OUT valve.

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit) power supply system</li> <li>• Fuse</li> <li>• Fusible link</li> <li>• Battery</li> </ul>	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit)</li> <li>• ABS actuator and electric unit (control unit) power supply system</li> <li>• Fuse</li> <li>• Fusible link</li> <li>• Battery</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

④ With CONSULT

1. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1121", "C1123", "C1125" or "C1127" detected?

YES-1 >> "C1121", "C1123", "C1125" or "C1127" is displayed by "CRNT": Proceed to [BRC-85, "Diagnosis Procedure"](#).

YES-2 >> "C1121", "C1123", "C1125" and "C1127" are displayed by "PAST": INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780051

#### 1. CHECK CONNECTOR

## C1121, C1123, C1125, C1127 ABS OUT VALVE SYSTEM

[WITH VDC]

### < DTC/CIRCUIT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

#### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.

### 2.PERFORM SELF-DIAGNOSIS

#### With CONSULT

1. Turn the ignition switch OFF.  
**NOTE:**  
Wait at least 10 seconds after turning ignition switch OFF.
2. Start the engine.  
**NOTE:**  
Wait at least 10 seconds after start the engine.
3. Perform self-diagnosis for "ABS".

#### Is DTC "C1121", "C1123", "C1125" or "C1127" detected?

YES >> GO TO 3.

NO >> INSPECTION END

### 3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

#### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, fuse, or fusible link.

### 4.CHECK TERMINAL

Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

#### Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

NO >> Repair / replace harness, connector, or terminal.

# C1130 ENGINE SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1130 ENGINE SIGNAL

### DTC Logic

INFOID:000000012780052

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1130	ENGINE SIGNAL 1 (Engine system signal)	When a malfunction is detected in ECM system.

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li><li>• CAN communication line</li></ul>	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ECM</li><li>• ABS actuator and electric unit (control unit)</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li><li>• CAN communication line</li></ul>


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1130" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-87, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780053

#### 1. CHECK ENGINE SYSTEM

 With CONSULT

Perform self-diagnosis for "ENGINE". Refer to [EC-73, "CONSULT Function"](#).

Is DTC detected?

YES >> Check the DTC. Refer to [EC-103, "DTC Index"](#).

NO >> GO TO 2.

## C1130 ENGINE SIGNAL

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

### 2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness, connector, fuse, or fusible link.

### 3. CHECK CONNECTOR AND TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect ECM harness connector.
3. Disconnect ABS actuator and electric unit (control unit) harness connector.
4. Check the connector for disconnection or looseness.
5. Check the pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, or terminal, securely lock the connector, and GO TO 4.

### 4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

 With CONSULT

1. Connect ECM harness connector.
2. Connect ABS actuator and electric unit (control unit) harness connector.
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

5. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

6. Perform self-diagnosis for "ABS".

Is DTC "C1130" or "U1000" detected?

YES ("C1130")>>Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

YES ("U1000")>>Refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

NO >> INSPECTION END



# C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1140 ACTUATOR RELAY SYSTEM

### DTC Logic

INFOID:000000012780054

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1140	ACTUATOR RLY (Actuator relay)	When a malfunction is detected in actuator relay.

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF.

##### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

##### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1140" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-89, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780055

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.


2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

 With CONSULT

## C1140 ACTUATOR RELAY SYSTEM

[WITH VDC]

### < DTC/CIRCUIT DIAGNOSIS >

---

1. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

#### Is DTC "C1140" detected?

YES >> GO TO 3.

NO >> INSPECTION END

### **3.**CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

---

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117. "Diagnosis Procedure"](#).

#### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, fuse, or fusible link.

### **4.**CHECK TERMINAL

---

Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

#### Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).

NO >> Repair / replace harness, connector, or terminal.

# C1142 PRESS SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

## C1142 PRESS SENSOR

### DTC Logic

INFOID:000000012780056

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1142	PRESS SEN CIRCUIT (Pressure sensor circuit)	When a malfunction is detected in pressure sensor.

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Air inclusion in the brake piping</li><li>• Stop lamp switch system</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>	<ul style="list-style-type: none"><li>• Stop lamp switch system</li><li>• ABS actuator and electric unit (control unit)</li><li>• Brake system</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li><li>• Air inclusion in the brake piping</li></ul>


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1142" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-91, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780057

#### 1. STOP LAMP SWITCH SYSTEM

Check the stop lamp switch system. Refer to [BRC-78, "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace stop lamp switch system.

#### 2. CHECK BRAKE FLUID LEAKAGE

## C1142 PRESS SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

Check the brake fluid leakage. Refer to [BR-14, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace brake fluid leakage part.

### 3.CHECK BRAKE PIPING

Check the brake piping.

• Front: Refer to [BR-24, "FRONT : Inspection"](#).

• Rear: Refer to [BR-27, "REAR : Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace brake piping.

• Front: Refer to [BR-23, "FRONT : Removal and Installation"](#).

• Rear: Refer to [BR-26, "REAR : Removal and Installation"](#).

### 4.CHECK BRAKE PEDAL

Check the brake pedal.

• Brake pedal height: Refer to [BR-9, "Inspection and Adjustment"](#).

• Brake pedal assembly: Refer to [BR-21, "Inspection and Adjustment"](#).

Is the inspection result normal?

YES >> GO TO 5.

NO >> Adjust the brake pedal height or replace brake pedal assembly.

• Adjust the brake pedal: Refer to [BR-9, "Inspection and Adjustment"](#).

• Replace the brake pedal: Refer to [BR-20, "Removal and Installation"](#).

### 5.CHECK BRAKE MASTER CYLINDER

Check the brake master cylinder. Refer to [BR-14, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair or replace brake master cylinder. Refer to [BR-29, "Removal and Installation"](#).

### 6.CHECK BRAKE BOOSTER

Check the brake booster. Refer to [BR-15, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace brake booster. Refer to [BR-33, "Removal and installation"](#).

### 7.CHECK VACUUM PIPING

Check the vacuum piping. Refer to [BR-35, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace vacuum piping. Refer to [BR-35, "Removal and Installation"](#).

### 8.CHECK FRONT DISC BRAKE

Check the front disc brake. Refer to [BR-39, "BRAKE PAD : Inspection"](#).

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace front disc brake. Refer to [BR-37, "BRAKE PAD : Removal and Installation"](#).

### 9.CHECK REAR DISC BRAKE

Check the rear disc brake. Refer to [BR-47, "BRAKE PAD : Inspection"](#).

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair or replace rear disc brake. Refer to [BR-45, "BRAKE PAD : Removal and Installation"](#).

### 10.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

# C1142 PRESS SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair / replace harness, connector, fuse, or fusible link.

## 11. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Ⓟ With CONSULT

1. Erase self-diagnosis result for "ABS".

2. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

3. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

4. Start the engine and drive the vehicle for a short period of time.

**NOTE:**

Vehicle must be driven after repair or replacement to erase the previous DTCs.

5. Stop the vehicle.

6. Perform self-diagnosis for "ABS".

Is DTC "C1142" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

NO >> Check the ABS actuator and electric unit (control unit) harness connector and terminal for damage, looseness and disconnection. Repair / replace harness, connector, or terminal.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# C1143 STEERING ANGLE SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

## C1143 STEERING ANGLE SENSOR

### DTC Logic

INFOID:000000012780058

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1143	ST ANG SEN CIRCUIT (Steering angle sensor circuit)	When a malfunction is detected in steering angle sensor.

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li><li>• CAN communication line</li><li>• Incomplete neutral position adjustment of steering angle sensor</li><li>• Improper installation of steering angle sensor</li></ul>	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Steering angle sensor</li><li>• ABS actuator and electric unit (control unit)</li><li>• Fuse block (J/B)</li><li>• CAN communication line</li><li>• Wheel alignment</li><li>• Incomplete neutral position adjustment of steering angle sensor</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

Ⓟ With CONSULT

1. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1143" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-94, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780059

#### 1. ADJUST THE NEUTRAL POSITION OF STEERING ANGLE SENSOR

Ⓟ With CONSULT

Perform neutral position adjustment of steering angle sensor. Refer to [BRC-50, "Description"](#).

# C1143 STEERING ANGLE SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

>> GO TO 2.

## 2. PERFORM SELF-DIAGNOSIS (1)

Ⓜ With CONSULT

1. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1143" detected?

YES-1 >> "CRNT" is displayed: GO TO 3.

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO >> INSPECTION END

## 3. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
3. Check the steering angle sensor harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 4.

## 4. PERFORM SELF-DIAGNOSIS (2)

Ⓜ With CONSULT

1. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1143" detected?

YES >> GO TO 5.

NO >> INSPECTION END

## 5. CHECK STEERING ANGLE SENSOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect steering angle sensor harness connector.
3. Check the voltage between steering angle sensor harness connector and ground.

+		-	Voltage
Connector	Terminal		
M30	4	Ground	Approx. 0 V

4. Turn the ignition switch ON.

**NOTE:**

Start the engine.

5. Check the voltage between steering angle sensor harness connector and ground.

+		-	Voltage
Connector	Terminal		
M30	4	Ground	10 – 16 V

Is the inspection result normal?

# C1143 STEERING ANGLE SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 7.
- NO >> GO TO 6.

## 6. CHECK STEERING ANGLE SENSOR POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#3).
3. Disconnect fuse block (J/B) harness connector.
4. Check the continuity between steering angle sensor harness connector and fuse block (J/B) harness connector.

Steering angle sensor		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M30	4	M6	2A	Existed

5. Check the continuity between steering angle sensor harness connector and ground.

Steering angle sensor		—	Continuity
Connector	Terminal		
M30	4	Ground	Not existed

Is the inspection result normal?

- YES >> Perform trouble diagnosis for ignition power supply.
- NO >> Repair / replace harness, connector, or fuse.

## 7. CHECK STEERING ANGLE SENSOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check the continuity between steering angle sensor harness connector and ground.

Steering angle sensor		—	Continuity
Connector	Terminal		
M30	1	Ground	Existed

Is the inspection result normal?

- YES >> GO TO 8.
- NO >> Repair / replace harness or connector.

## 8. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 9.
- NO >> Repair / replace harness, connector, fuse, or fusible link.

## 9. CHECK TERMINAL

1. Check the steering angle sensor pin terminals for damage or loose connection with harness connector.
2. Check the fuse block (J/B) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 10.
- NO >> Repair / replace harness, connector, or terminal.

## 10. CHECK CAN COMMUNICATION LINE

1. Connect steering angle sensor harness connector.
2. Connect fuse block (J/B) harness connector.
3. Check the CAN communication line. Refer to [LAN-17. "Trouble Diagnosis Flow Chart"](#).

Is the inspection result normal?

- YES >> GO TO 11.



# C1143 STEERING ANGLE SENSOR

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair / replace harness or connector. Refer to [LAN-7. "Precautions for Harness Repair"](#).

## 11. CHECK DATA MONITOR

Ⓜ With CONSULT

1. "ABS", "DATA MONITOR" and "STR ANGLE SIG" according to this order.
2. Check that the indication changes with the steering angle when the steering wheel is turned left/right from the neutral position. Refer to [BRC-35. "Reference Value"](#).

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).

NO >> Replace the steering angle sensor. Refer to [BRC-142. "Removal and Installation"](#).

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

### DTC Logic

INFOID:000000012780060

#### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1144	ST ANG SEN SIGNAL (Steering angle sensor not complete)	When neutral position adjustment of steering angle sensor is not complete.

#### POSSIBLE CAUSE

##### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
Incomplete neutral position adjustment of steering angle sensor	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Steering angle sensor</li><li>• ABS actuator and electric unit (control unit)</li><li>• Incomplete neutral position adjustment of steering angle sensor</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

##### 2. CHECK DTC DETECTION

###### Ⓟ With CONSULT

1. Turn the ignition switch OFF.

##### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

##### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

##### Is DTC "C1144" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-98, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

#### Diagnosis Procedure

INFOID:000000012780061

##### 1. ADJUST THE NEUTRAL POSITION OF STEERING ANGLE SENSOR

Perform neutral position adjustment of steering angle sensor. Refer to [BRC-50, "Description"](#).

>> GO TO 2.

##### 2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

###### Ⓟ With CONSULT

1. Turn the ignition switch OFF.

##### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

# C1144 INCOMPLETE STEERING ANGLE SENSOR ADJUSTMENT

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

2. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1144" detected?

YES >> GO TO 3.

NO >> INSPECTION END

## 3.CHECK STEERING ANGLE SENSOR SYSTEM

1. Turn the ignition switch OFF.

2. Check the steering angle sensor system. Refer to [BRC-94. "DTC Logic"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, or terminal.

## 4.CHECK DATA MONITOR

ⓂWith CONSULT

1. "ABS", "DATA MONITOR" and "STR ANGLE SIG" according to this order.

2. Check that the indication changes with the steering angle when the steering wheel is turned left/right from the neutral position. Refer to [BRC-35. "Reference Value"](#).

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).

NO >> Replace the steering angle sensor. Refer to [BRC-142. "Removal and Installation"](#).

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# C1145, C1146 YAW RATE/SIDE G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1145, C1146 YAW RATE/SIDE G SENSOR

### DTC Logic

INFOID:000000012780062

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1145	YAW RATE SENSOR (Yaw rate sensor circuit)	<ul style="list-style-type: none"><li>• When a malfunction is detected in yaw rate signal.</li><li>• When a signal line of yaw rate/side/decel G sensor is open or shorted.</li></ul>
C1146	SIDE G SEN CIRCUIT (Side G sensor circuit)	<ul style="list-style-type: none"><li>• When a malfunction is detected in side/decel G signal.</li><li>• When a signal line of yaw rate/side/decel G sensor is open or shorted.</li></ul>

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Yaw rate/side/decel G sensor</li><li>• ABS actuator and electric unit (control unit)</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

Ⓟ With CONSULT

1. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1145" or "C1146" detected?

YES-1 >> "C1145" or "C1146" is displayed by "CRNT": Proceed to [BRC-100, "Diagnosis Procedure"](#).

YES-2 >> "C1145" and "C1146" are displayed by "PAST": INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780063

#### CAUTION:

• A malfunction in yaw rate/side/decel G sensor system may be detected when the vehicle sharply turns during a spin turn, acceleration turn or drift driving while VDC function is OFF (VDC OFF indicator lamp is in ON status). This is not a malfunction if the status returns to normal after engine is started again. In that case, erase self-diagnosis result memory using CONSULT.

# C1145, C1146 YAW RATE/SIDE G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

- When the engine is in running status and the vehicle is on a turntable at the entrance of parking lot or on a moving unit, VDC warning lamp may turn ON and “ABS” self-diagnosis may display “YAW RATE SENSOR”. In this case, yaw rate sensor is not malfunctioning. The status returns to normal when the vehicle is left from the turntable or moving unit and the engine is started again. In that case, erase self-diagnosis result memory using CONSULT.

## 1. CHECK YAW RATE/SIDE/DECEL G SENSOR POWER SUPPLY

1. Turn the ignition switch OFF.
2. Disconnect yaw rate/side/decel G sensor harness connector.
3. Check the voltage between yaw rate/side/decel G sensor harness connector and ground.

+		-	Voltage
Yaw rate/side/decel G sensor			
Connector	Terminal		
M52	4	Ground	Approx. 0 V

4. Turn the ignition switch ON.  
**NOTE:**  
Never start engine.
5. Check the voltage between yaw rate/side/decel G sensor harness connector and ground.

+		-	Voltage
Yaw rate/side/decel G sensor			
Connector	Terminal		
M52	4	Ground	Approx. 12 V

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair / replace harness connector.

## 2. CHECK YAW RATE/SIDE/DECEL G SENSOR GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check the continuity between yaw rate/side/decel G sensor harness connector and ground.

Yaw rate/side/decel G sensor		—	Continuity
Connector	Terminal		
M52	1	Ground	Existed

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair / replace harness or connector.

## 3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair / replace harness, connector, fuse, or fusible link.

## 4. CHECK COMMUNICATION LINE

Check the continuity between yaw rate/side/decel G sensor harness connector and ABS actuator and electric unit (control unit) harness connector.

# C1145, C1146 YAW RATE/SIDE G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

Yaw rate/side/decel G sensor		ABS actuator and electric unit (control unit)		Continuity
Connector	Terminal	Connector	Terminal	
M52	2	E36	25	Existed
	3		19	

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair / replace harness or connector. Refer to [BRC-7, "Precaution for Harness Repair"](#).

## 5. CHECK TERMINAL

1. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
2. Check the yaw rate/side/decel G sensor pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 6.

NO >> Repair / replace harness, connector, or terminal.

## 6. REPLACE YAW RATE/SIDE/DECEL G SENSOR

Ⓜ With CONSULT.

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Replace the yaw rate/side/decel G sensor. Refer to [BRC-141, "Removal and Installation"](#).
3. Erase self-diagnosis result for "ABS".
4. Turn the ignition switch OFF.
5. Turn the ignition switch ON.

### NOTE:

Never start engine.

6. Perform self-diagnosis for "ABS".

Is DTC "C1145" or "C1146" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

NO >> INSPECTION END

# C1155 BRAKE FLUID LEVEL SWITCH

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

## C1155 BRAKE FLUID LEVEL SWITCH

### DTC Logic

INFOID:000000012780064

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1155	BR FLUID LEVEL LOW (Brake fluid level low)	<ul style="list-style-type: none"><li>When brake fluid level low signal is detected.</li><li>When an open circuit is detected in brake fluid level switch circuit.</li></ul>

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>Harness or connector</li><li>Brake fluid level is low</li></ul>	<ul style="list-style-type: none"><li>Harness or connector</li><li>ABS actuator and electric unit (control unit)</li><li>Brake fluid level switch</li><li>Combination meter</li><li>Brake fluid level is low</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1155" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-103. "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780065

#### 1. CHECK BRAKE FLUID LEVEL

1. Turn the ignition switch OFF.


2. Check the brake fluid level. Refer to [BR-12. "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Refill brake fluid. Refer to [BR-12. "Refilling"](#). GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS (1)

 With CONSULT

1. Erase self-diagnosis result for "ABS".

# C1155 BRAKE FLUID LEVEL SWITCH

[WITH VDC]

## < DTC/CIRCUIT DIAGNOSIS >

2. Turn the ignition switch OFF → ON → OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

4. Perform self-diagnosis for "ABS".

### Is DTC "C1155" detected?

YES >> GO TO 3.

NO >> INSPECTION END

## 3. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the brake fluid level switch harness connector for disconnection or looseness.
3. Check the combination meter harness connector for disconnection or looseness.
4. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

### Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair / replace harness or connector, and GO TO 4.

## 4. PERFORM SELF-DIAGNOSIS (2)

### Ⓟ With CONSULT

1. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

### Is DTC "C1155" detected?

YES >> GO TO 5.

NO >> INSPECTION END

## 5. CHECK BRAKE FLUID LEVEL SWITCH

Check the brake fluids level switch. Refer to [BRC-106, "Component Inspection"](#).

### Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace the reservoir tank. Refer to [BR-31, "Disassembly and Assembly"](#). GO TO 6.

## 6. PERFORM SELF-DIAGNOSIS (3)

### Ⓟ With CONSULT

1. Erase self-diagnosis result for "ABS".
2. Turn the ignition switch OFF → ON → OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF or ON.

3. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

4. Perform self-diagnosis for "ABS".

### Is DTC "C1155" detected?

YES >> GO TO 7.

NO >> INSPECTION END

## 7. CHECK CONNECTOR AND TERMINAL

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Check the brake fluid level switch harness connector for disconnection or looseness.
4. Check the brake fluid level switch pin terminals for damage or loose connection with harness connector.



# C1155 BRAKE FLUID LEVEL SWITCH

[WITH VDC]

## < DTC/CIRCUIT DIAGNOSIS >

5. Disconnect combination meter harness connector.
6. Check the combination meter harness connector for disconnection or looseness.
7. Check the combination meter pin terminals for damage or loose connection with harness connector.
8. Disconnect ABS actuator and electric unit (control unit) harness connector.
9. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.
10. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair / replace harness, connector, or terminal, and GO TO 8.

## 8.PERFORM SELF-DIAGNOSIS (4)

 With CONSULT

1. Connect brake fluid level switch harness connector.
2. Connect combination meter harness connector.
3. Connect ABS actuator and electric unit (control unit) harness connector.
4. Erase self-diagnosis result for "ABS".
5. Turn the ignition switch OFF → ON → OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF or ON.

6. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

7. Perform self-diagnosis for "ABS".

Is DTC "C1155" detected?

YES >> GO TO 9.

NO >> INSPECTION END

## 9.CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT (1)

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Disconnect combination meter harness connector.
4. Check the continuity between brake fluid level switch harness connector and combination meter harness connector.

Brake fluid level switch		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
E37	1	M34	27	Existed

5. Check the continuity between brake fluid level switch harness connector and ground.

Brake fluid level switch		—	Continuity
Connector	Terminal		
E37	1	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 10.

NO >> Repair / replace harness or connector, and GO TO 10.

## 10.CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT (2)

1. Disconnect ABS actuator and electric unit (control unit) harness connector.
2. Check the continuity between brake fluid level switch harness connector and ABS actuator and electric unit (control unit) harness connector.

# C1155 BRAKE FLUID LEVEL SWITCH

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

Brake fluid level switch		ABS actuator and electric unit (control unit)		Continuity
Connector	Terminal	Connector	Terminal	
E37	1	E36	7	Existed

3. Check the continuity between brake fluid level switch harness connector and ground.

Brake fluid level switch		—	Continuity
Connector	Terminal		
E37	1	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 11.

NO >> Repair / replace harness or connector, and GO TO 11.

## 11.CHECK BRAKE FLUID LEVEL SWITCH GROUND CIRCUIT

Check the continuity between brake fluid level switch harness connector and ground.

Brake fluid level switch		—	Continuity
Connector	Terminal		
E37	2	Ground	Existed

Is the inspection result normal?

YES >> GO TO 12.

NO >> Repair / replace harness or connector, and GO TO 12.

## 12.CHECK COMBINATION METER

1. Connect brake fluid level switch harness connector.
2. Connect combination meter harness connector.
3. Connect ABS actuator and electric unit (control unit) harness connector.
4. Check the combination meter. Refer to [MWI-35. "On Board Diagnosis Function"](#).

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).

NO >> Repair or replace combination meter. Refer to [MWI-96. "Removal and Installation"](#).

## Component Inspection

INFOID:000000012780066

## 1.CHECK BRAKE FLUID LEVEL SWITCH

1. Turn the ignition switch OFF.
2. Disconnect brake fluid level switch harness connector.
3. Check continuity between terminals of brake fluid level switch.

Brake fluid level switch	Condition	Continuity
Terminal		
1 – 2	When brake fluid level in reservoir tank is within the specified level.	Not existed
	When brake fluid level in reservoir tank is less than the specified level.	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace reservoir tank. Refer to [BR-29. "Removal and Installation"](#).

# C1161 INCOMPLETE SIDE G SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1161 INCOMPLETE SIDE G SENSOR CALIBRATION

### DTC Logic

INFOID:000000012780067

### DTC DETECTION LOGIC

DTC	Display item (Trouble diagnosis content)	Malfunction detected condition
C1161	SIDE G SEN SET (Side G sensor set)	When there is an internal malfunction in the ABS actuator and electric unit (control unit).

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit) power supply system</li> <li>• Fuse</li> <li>• Fusible link</li> <li>• Battery</li> </ul>	<ul style="list-style-type: none"> <li>• ABS actuator and electric unit (control unit)</li> <li>• Yaw rate/side/decel G sensor</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

Ⓜ With CONSULT

1. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1161" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-107, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [Gl-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780068

#### 1. CHECK YAW RATE/SIDE/DECEL G SENSOR SYSTEM

1. Turn the ignition switch OFF.

2. Check the yaw rate/side/decel G sensor system. Refer to [BRC-100, "DTC Logic"](#).

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

NO >> Replace the yaw rate/side/decel G sensor. Refer to [BRC-141, "Removal and Installation"](#).

# C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION

### DTC Logic

INFOID:000000012780069

### DTC DETECTION LOGIC

DTC	Display item (Trouble diagnosis content)	Malfunction detected condition	Possible cause
C1162	PRESS SEN SET (Pressure sensor set)	When there is an internal malfunction in the ABS actuator and electric unit (control unit).	ABS actuator and electric unit (control unit)

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit) power supply system</li><li>• Fuse</li><li>• Fusible link</li><li>• Battery</li></ul>	ABS actuator and electric unit (control unit)

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

##### Ⓜ With CONSULT

1. Turn the ignition switch OFF.

##### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

##### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

##### Is DTC "C1162" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-108, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780070

#### 1. PERFORM SELF-DIAGNOSIS

##### Ⓜ With CONSULT

1. Erase self-diagnosis result for "ABS".

2. Turn the ignition switch OFF.

##### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

3. Start the engine.

##### NOTE:

Wait at least 10 seconds after start the engine.

4. Perform self-diagnosis for "ABS".

# C1162 INCOMPLETE PRESSURE SENSOR CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

Is DTC "C1162" detected?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

NO >> INSPECTION END

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

## C1164, C1165 CV SYSTEM

### DTC Logic

INFOID:000000012780071

#### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1164	CV 1 (Cut valve 1)	When a malfunction is detected in cut valve 1.
C1165	CV 2 (Cut valve 2)	When a malfunction is detected in cut valve 2.

#### POSSIBLE CAUSE

**NOTE:**

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit) power supply system</li> <li>• Fuse</li> <li>• Fusible link</li> <li>• Battery</li> </ul>	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit)</li> <li>• ABS actuator and electric unit (control unit) power supply system</li> <li>• Fuse</li> <li>• Fusible link</li> <li>• Battery</li> </ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

##### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1164" or "C1165" detected?

YES-1 >> "C1164" or "C1165" is displayed by "CRNT": Proceed to [BRC-110, "Diagnosis Procedure"](#).

YES-2 >> "C1164" and "C1165" are displayed by "PAST": INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

#### Diagnosis Procedure

INFOID:000000012780072

##### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 3.

# C1164, C1165 CV SYSTEM

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.

## 2.PERFORM SELF-DIAGNOSIS

ⓂWith CONSULT

Perform self-diagnosis for “ABS” again.

Is DTC “C1164” or “C1165” detected?

YES >> GO TO 3.

NO >> INSPECTION END

## 3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, fuse, or fusible link.

## 4.CHECK TERMINAL

Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness.

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

NO >> Repair / replace harness, connector, or terminal.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## C1166, C1167 SV SYSTEM

### DTC Logic

INFOID:000000012780073

#### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1166	SV 1 (Suction valve 1)	When a malfunction is detected in suction valve 1.
C1167	SV 2 (Suction valve 2)	When a malfunction is detected in suction valve 2.

#### POSSIBLE CAUSE

**NOTE:**

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit) power supply system</li> <li>• Fuse</li> <li>• Fusible link</li> <li>• Battery</li> </ul>	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit)</li> <li>• ABS actuator and electric unit (control unit) power supply system</li> <li>• Fuse</li> <li>• Fusible link</li> <li>• Battery</li> </ul>

#### DTC CONFIRMATION PROCEDURE

### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

### 2. CHECK DTC DETECTION

With CONSULT

1. Turn the ignition switch OFF.

**NOTE:**

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

**NOTE:**

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "C1166" or "C1167" detected?

YES-1 >> "C1166" or "C1167" is displayed by "CRNT": Proceed to [BRC-112, "Diagnosis Procedure"](#).

YES-2 >> "C1166" and "C1167" is displayed by "PAST": INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

#### Diagnosis Procedure

INFOID:000000012780074

### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Check the ABS actuator and electric unit (control unit) harness connector for disconnection or looseness.

Is the inspection result normal?

YES >> GO TO 3.



# C1166, C1167 SV SYSTEM

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Repair / replace harness or connector, securely lock the connector, and GO TO 2.

## 2.PERFORM SELF-DIAGNOSIS

ⓂWith CONSULT

Perform self-diagnosis for "ABS" again.

Is DTC "C1166" or "C1167" detected?

YES >> GO TO 3.

NO >> INSPECTION END

## 3.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check the ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair / replace harness, connector, fuse, or fusible link.

## 4.CHECK TERMINAL

Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness.

Is the inspection result normal?

YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

NO >> Repair / replace harness, connector, or terminal.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## U1000 CAN COMM CIRCUIT

### Description

INFOID:000000012780075

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### DTC Logic

INFOID:000000012780076

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
U1000	CAN COMM CIRCUIT (CAN communication circuit)	When CAN communication signal is not continuously transmitted or received for 2 seconds or more.

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>• Harness or connector</li><li>• CAN communication line</li></ul>	CAN communication system malfunction

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

Ⓟ With CONSULT

1. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

Is DTC "U1000" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-114, "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780077

Proceed to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

# U1002 SYSTEM COMM (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## U1002 SYSTEM COMM (CAN)

### Description

INFOID:000000012780078

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### DTC Logic

INFOID:000000012780079

### DTC DETECTION LOGIC

DTC	Display item (Trouble diagnosis content)	Malfunction detected condition
U1002	SYSTEM COMM (CAN) (CAN system communication)	When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or less.

BRC

### POSSIBLE CAUSE

#### NOTE:

Confirm if DTC is PAST or CRNT. If DTC is CRNT, proceed with Diagnosis Procedure. If DTC is PAST, clear DTC. Do not replace the ABS actuator and electric unit (control unit) for a PAST DTC.

PAST DTC	CRNT DTC
<ul style="list-style-type: none"><li>CAN communication line</li><li>Harness or connector</li></ul>	<ul style="list-style-type: none"><li>CAN communication line</li><li>ABS actuator and electric unit (control unit)</li><li>Steering angle sensor</li></ul>


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. DTC REPRODUCTION PROCEDURE

 With CONSULT

1. Turn the ignition switch OFF.

#### NOTE:

Wait at least 10 seconds after turning ignition switch OFF.

2. Start the engine.

#### NOTE:

Wait at least 10 seconds after start the engine.

3. Perform self-diagnosis for "ABS".

#### Is DTC "U1002" detected?

YES-1 >> "CRNT" is displayed: Proceed to [BRC-115. "Diagnosis Procedure"](#).

YES-2 >> "PAST" is displayed: INSPECTION END (Erase the memory of self-diagnosis results.)

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000012780080

#### CAUTION:

- Never apply 7.0 V or more to the measurement terminal.
- Use a tester with open terminal voltage of 7.0 V or less.

## U1002 SYSTEM COMM (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

- Turn the ignition switch OFF and disconnect the battery cable from the negative terminal when checking the harness.

### 1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

---

Ⓜ With CONSULT

1. Select "ABS" and "CAN Diagnosis Support Monitor" in order.
2. Check the malfunction history between each control unit connected to ABS actuator and electric unit (control unit).

Check the result of "PAST"?

All items are "OK">>Check the intermittent incident. Refer to [GI-41, "Intermittent Incident"](#).

"TRANSMIT DIAG" is other than "OK">>GO TO 2.

A control unit other than ABS actuator and electric unit (control unit) is anything other than "OK">>GO TO 3.

### 2. CHECK TRANSMITTING SIDE UNIT

---

Check the ABS actuator and electric unit (control unit) harness connector terminals No. 23 and 21 for damage or loose connection.

Is the inspection result normal?

YES >> Erase self-diagnosis results. Then perform self-diagnosis for "ABS" with CONSULT.

NO >> Recheck the terminals for damage or loose connection. Refer to [BRC-7, "Precaution for Harness Repair"](#).

### 3. CHECK APPLICABLE CONTROL UNIT

---

Check the terminals of each harness connector for damage or loose connection.

Is the inspection result normal?

YES >> Erase self-diagnosis results. Then perform self-diagnosis for applicable control unit with CONSULT.

NO >> Recheck the terminals for damage or loose connection. Refer to [BRC-7, "Precaution for Harness Repair"](#).

# POWER SUPPLY AND GROUND CIRCUIT

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

## POWER SUPPLY AND GROUND CIRCUIT

### Diagnosis Procedure

INFOID:000000012780081

#### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) IGNITION POWER SUPPLY (1)

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

+		-	Voltage
ABS actuator and electric unit (control unit)			
Connector	Terminal		
E36	20	Ground	Approx. 0 V

4. Turn the ignition switch ON  
**NOTE:**  
Start the engine.
5. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

+		-	Voltage
ABS actuator and electric unit (control unit)			
Connector	Terminal		
E36	20	Ground	10 – 16 V

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 2.

#### 2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) IGNITION POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#45)
3. Disconnect IPDM E/R harness connector.
4. Check the continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R harness connector.

ABS actuator and electric unit (control unit)		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
E36	20	E10	25	Existed

5. Check the continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	20	Ground	No existed

Is the inspection result normal?

- YES >> Perform trouble diagnosis for ignition power supply.  
NO >> Repair / replace harness, connector, or fuse.

#### 3. CHECK MOTOR AND MOTOR RELAY POWER SUPPLY

1. Turn the ignition switch OFF.
2. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# POWER SUPPLY AND GROUND CIRCUIT

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

+		-	Voltage
ABS actuator and electric unit (control unit)			
Connector	Terminal		
E36	14	Ground	10 – 16 V

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> GO TO 4.

## 4. CHECK MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 30A fusible link (#F).
3. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal (14) and 30A fusible link (#F).

Is the inspection result normal?

- YES >> Perform trouble diagnosis for battery power supply.
- NO >> Repair / replace harness, connector, or fusible link.

## 5. CHECK ACTUATOR RELAY, ABS IN VALVE, ABS OUT VALVE POWER SUPPLY

1. Turn the ignition switch OFF.
2. Check the voltage between ABS actuator and electric unit (control unit) harness connector and ground.

+		-	Voltage
ABS actuator and electric unit (control unit)			
Connector	Terminal		
E36	1	Ground	10 – 16 V

Is the inspection result normal?

- YES >> GO TO 7.
- NO >> GO TO 6.

## 6. CHECK ACTUATOR RELAY, ABS IN VALVE, ABS OUT VALVE POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 20A fusible link (#G).
3. Check the continuity and short circuit between ABS actuator and electric unit (control unit) harness connector terminal (1) and 20A fusible link (#G).

Is the inspection result normal?

- YES >> Perform trouble diagnosis for battery power supply.
- NO >> Repair / replace harness, connector, or fusible link.

## 7. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

Check the continuity between ABS actuator and electric unit (control unit) harness connector and the ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	13	Ground	Existed
	26		

Is the inspection result normal?

- YES >> GO TO 8.
- NO >> Repair / replace harness, connector, or terminal.

## 8. CHECK TERMINAL

1. Check the ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
2. Check the IPDM E/R pin terminals for damage or loose connection with harness connector.

# POWER SUPPLY AND GROUND CIRCUIT

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> Replace the ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).
- NO >> Repair / replace harness, connector, or terminal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

## PARKING BRAKE SWITCH

### Component Function Check

INFOID:000000012780082

#### 1.CHECK PARKING BRAKE SWITCH OPERATION

Operate the parking brake pedal. Then check that the brake warning lamp in the combination meter turns ON/OFF correctly.

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Proceed to [BRC-120. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012780083

#### 1.CHECK PARKING BRAKE SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect parking brake switch harness connector.
3. Disconnect combination meter harness connector.
4. Check continuity between parking brake switch harness connector and combination meter harness connector.

Parking brake switch		Combination meter		Continuity
Connector	Terminal	Connector	Terminal	
E27	1	M34	26	Existed

5. Check continuity between parking brake switch harness connector and ground.

Parking brake switch		—	Continuity
Connector	Terminal		
E27	1	Ground	Not existed

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace error-detected parts.

#### 2.CHECK PARKING BRAKE SWITCH

Check the parking brake switch. Refer to [BRC-120. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Replace parking brake switch. Refer to [PB-7. "Exploded View"](#).

#### 3.CHECK COMBINATION METER

Check combination meter. Refer to [MWI-36. "CONSULT Function"](#).

Is the inspection result normal?

- YES >> Check each pin terminals for damage or loose connection with harness connector. If any items are damaged, repair or replace error-detected parts.
- NO >> Repair or replace combination meter. Refer to [MWI-96. "Removal and Installation"](#).

### Component Inspection

INFOID:000000012780084

#### 1.CHECK PARKING BRAKE SWITCH

1. Turn the ignition switch OFF.
2. Disconnect parking brake switch harness connector.
3. Check continuity between parking brake switch harness connector.



# PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH VDC]

Parking brake switch Terminal	—	Condition	Continuity
1	Ground	When the parking brake switch is operated.	Existed
		When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch. Refer to [PB-7. "Exploded View"](#).

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

**BRC**

# VDC OFF SWITCH

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

## VDC OFF SWITCH

### Component Function Check

INFOID:000000012780085

#### 1. CHECK VDC OFF SWITCH OPERATION

Check that VDC OFF indicator lamp in combination meter turns ON/OFF when VDC OFF switch is operated.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-122, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012780086

#### 1. CHECK VDC OFF SWITCH

Check VDC OFF switch. Refer to [BRC-123, "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace VDC OFF switch. Refer to [BRC-143, "Removal and Installation"](#).

#### 2. CHECK VDC OFF SWITCH CIRCUIT

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Disconnect VDC OFF switch harness connector.
4. Check continuity between ABS actuator and electric unit (control unit) harness connector and VDC OFF switch harness connector.

ABS actuator and electric unit (control unit)		VDC OFF switch		Continuity
Connector	Terminal	Connector	Terminal	
E36	22	M5	1	Existed

5. Check continuity between ABS actuator and electric unit (control unit) harness connector and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	22	Ground	Not existed

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

#### 3. CHECK VDC OFF SWITCH GROUND CIRCUIT

Check continuity between VDC OFF switch harness connector and ground.

VDC OFF switch		—	Continuity
Connector	Terminal		
M5	2	Ground	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace error-detected parts.

#### 4. CHECK VDC OFF SWITCH SIGNAL

Ⓜ With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Connect VDC OFF switch harness connector.
3. Select "ABS", "DATA MONITOR" and "OFF SW" according to this order. Check VDC OFF switch signal.

# VDC OFF SWITCH

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

Condition	DATA MONITOR
When VDC OFF switch is pressed and VDC OFF indicator lamp in combination meter is in ON status	On
When VDC OFF switch is pressed and VDC OFF indicator lamp in combination meter is in OFF status	Off

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> GO TO 5.

## 5.CHECK TERMINAL

1. Check ABS actuator and electric unit (control unit) pin terminals for damage or loose connection with harness connector.
2. Check VDC OFF switch pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).
- NO >> Repair or replace error-detected parts.

## Component Inspection

INFOID:0000000012780087

## 1.CHECK VDC OFF SWITCH

1. Turn the ignition switch OFF.
2. Disconnect triple switch harness connector.
3. Check continuity between terminals of VDC OFF switch connector.

VDC OFF switch	Condition	Continuity
Terminal		
1 – 2	When VDC OFF switch is pressed	Existed
	When VDC OFF switch is not pressed	Not existed

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Replace VDC OFF switch. Refer to [BRC-143. "Removal and Installation"](#).

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

## ABS WARNING LAMP

### Component Function Check

INFOID:000000012780088

#### 1. CHECK ABS WARNING LAMP FUNCTION

Check that ABS warning lamp in combination meter turns ON for approx. 2 second after ignition switch is turned ON.

**CAUTION:**

**Never start engine.**

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Proceed to [BRC-124, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000012780089

#### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Perform the trouble diagnosis for ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace error-detected parts.

#### 2. PERFORM SELF-DIAGNOSIS

 With CONSULT

Perform self-diagnosis for "ABS".

Is any DTC detected?

- YES >> Check the DTC. Refer to [BRC-38, "DTC Index"](#).
- NO >> GO TO 3.

#### 3. CHECK ABS WARNING LAMP SIGNAL

 With CONSULT

1. Select "ABS", "DATA MONITOR" and "ABS WARN LAMP" according to this order.
2. Turn the ignition switch OFF.
3. Check that data monitor displays "On" for approx. 1 second after ignition switch is turned ON and then changes to "Off".

**CAUTION:**

**Never start engine.**

Is the inspection result normal?

- YES >> Check combination meter. Refer to [MWI-36, "CONSULT Function"](#).
- NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

# BRAKE WARNING LAMP

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

## BRAKE WARNING LAMP

### Component Function Check

INFOID:000000012780090

#### 1. CHECK BRAKE WARNING LAMP FUNCTION (1)

Check that brake warning lamp in combination meter turns ON for approx. 2 second after ignition switch is turned ON.

**CAUTION:**

**Never start engine.**

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to [BRC-125, "Diagnosis Procedure"](#).

#### 2. CHECK BRAKE WARNING LAMP FUNCTION (2)

Check that brake warning lamp in combination meter turns ON/OFF when parking brake is operated.

**NOTE:**

Brake warning lamp turns ON when parking brake is operated (when parking brake switch is ON).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check parking brake switch system. Refer to [BRC-120, "Diagnosis Procedure"](#).

#### 3. CHECK BRAKE WARNING LAMP FUNCTION (3)

Check that brake warning lamp in combination meter turns ON/OFF when brake fluid level switch is operated while brake fluid level in reservoir tank is with the specified level.

**NOTE:**

Brake warning lamp turns ON when brake fluid is less than the specified level (when brake fluid level switch is ON).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check brake fluid level switch system. Refer to [BRC-103, "Diagnosis Procedure"](#).

## Diagnosis Procedure

INFOID:000000012780091

#### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT


Perform the trouble diagnosis for ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

#### 2. PERFORM THE SELF-DIAGNOSIS

 With CONSULT

Perform self-diagnosis for "ABS".

Is any DTC detected?

YES >> Check the DTC. Refer to [BRC-38, "DTC Index"](#).

NO >> GO TO 3.

#### 3. CHECK COMBINATION METER

Check combination meter. Refer to [MWI-36, "CONSULT Function"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

NO >> Repair or replace combination meter. Refer to [MWI-96, "Removal and Installation"](#).

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

## VDC WARNING LAMP

## Component Function Check

INFOID:000000012780092

**1.**CHECK VDC WARNING LAMP FUNCTION

Check that VDC warning lamp in combination meter turns ON for approx. 2 second after ignition switch is turned ON.

**CAUTION:**

**Never start engine.**

Is the inspection result normal?

YES >> INSPECTION END

NO >> Proceed to diagnosis procedure. Refer to [BRC-126, "Diagnosis Procedure"](#).

## Diagnosis Procedure

INFOID:000000012780093

**1.**CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Perform the trouble diagnosis for ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

**2.**PERFORM THE SELF-DIAGNOSIS

 With CONSULT

Perform self-diagnosis for "ABS".

Is any DTC detected?

YES >> Check the DTC. Refer to [BRC-38, "DTC Index"](#).

NO >> GO TO 3.

**3.**CHECK VDC WARNING LAMP SIGNAL

 With CONSULT

1. Select "ABS", "DATA MONITOR" and "SLIP/VDC LAMP" according to this order.

2. Turn the ignition switch OFF.

3. Check that data monitor displays "On" for approx. 1 second after ignition switch is turned ON, and then changes to "Off".

**CAUTION:**

**Never start engine.**

Is the inspection result normal?

YES >> Check combination meter. Refer to [MWI-36, "CONSULT Function"](#).

NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

# VDC OFF INDICATOR LAMP

[WITH VDC]

< DTC/CIRCUIT DIAGNOSIS >

## VDC OFF INDICATOR LAMP

### Component Function Check

INFOID:0000000012780094

#### 1.CHECK VDC OFF INDICATOR LAMP FUNCTION (1)

Check that VDC OFF indicator lamp in combination meter turns ON for approx. 2 second after ignition switch is turned ON.

**CAUTION:**

**Never start engine.**

Is the inspection result normal?

YES >> GO TO 2.

NO >> Proceed to diagnosis procedure. Refer to [BRC-127, "Diagnosis Procedure"](#).

#### 2.CHECK VDC OFF INDICATOR LAMP FUNCTION (2)

Check that VDC OFF indicator lamp in combination meter turns ON/OFF when VDC OFF switch is operated.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check VDC OFF switch system. Refer to [BRC-122, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000012780095

#### 1.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Perform the trouble diagnosis for ABS actuator and electric unit (control unit) power supply and ground circuit. Refer to [BRC-117, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts.

#### 2.CHECK VDC OFF INDICATOR LAMP SIGNAL (1)

ⓂWith CONSULT

1. Select "ABS", "DATA MONITOR" and "OFF LAMP" according to this order.

2. Turn the ignition switch OFF.

3. Check that data monitor displays "On" for approx. 1 second after ignition switch is turned ON, and then changes to "Off".

**CAUTION:**

**Never start engine.**

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-139, "Removal and Installation"](#).

#### 3.CHECK VDC OFF INDICATOR LAMP SIGNAL (2)

ⓂWith CONSULT

1. Select "ABS", "DATA MONITOR" and "OFF LAMP" according to this order.

2. Check that data monitor displays "On" or "Off" each time when VDC OFF switch is operated.

Is the inspection result normal?

YES >> Check combination meter. Refer to [MWI-36, "CONSULT Function"](#).

NO >> Check VDC OFF switch system. Refer to [BRC-122, "Diagnosis Procedure"](#).

A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# EXCESSIVE OPERATION FREQUENCY

[WITH VDC]

< SYMPTOM DIAGNOSIS >

## SYMPTOM DIAGNOSIS

### EXCESSIVE OPERATION FREQUENCY

#### Description

INFOID:0000000012406819

VDC function, TCS function, ABS function, EBD function and brake limited slip differential (BLSD) function operates in excessive operation frequency.

#### Diagnosis Procedure

INFOID:0000000012406820

#### 1. CHECK BRAKING FORCE

Check brake force using a brake tester.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

#### 2. CHECK FRONT AND REAR AXLE

Check that there is no excessive looseness in front and rear axle.

• Front axle: Refer to [FAX-7, "Inspection"](#).

• Rear axle: Refer to [RAX-5, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace error-detected parts.

#### 3. CHECK WHEEL SENSOR

Check wheel sensor.

- Check installation and damage of wheel sensor.
- Check connection of wheel sensor harness connector.
- Check terminal of wheel sensor harness connector.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace wheel sensor.

• Front wheel sensor: Refer to [BRC-135, "FRONT WHEEL SENSOR : Removal and Installation"](#).

• Rear wheel sensor: Refer to [BRC-136, "REAR WHEEL SENSOR : Removal and Installation"](#).

#### 4. CHECK SENSOR ROTOR

Check that there is no looseness, damage or foreign material on sensor rotor.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair installation or replace sensor rotor.

• Front sensor rotor: Refer to [BRC-138, "FRONT SENSOR ROTOR : Removal and Installation"](#).

• Rear sensor rotor: Refer to [BRC-138, "REAR SENSOR ROTOR : Removal and Installation"](#).

#### 5. CHECK WARNING LAMP TURNS OFF

Check that ABS warning lamp, brake warning lamp and VDC warning lamp turn OFF approx. 2 second after key switch is turned ON and stay in OFF status during driving.

#### CAUTION:

- **Brake warning lamp turns ON when parking brake is operated (parking brake switch is ON) or brake fluid is less than the specified level (brake fluid level switch is ON).**
- **VDC function and TCS function never operate when VDC OFF switch is operated (when VDC OFF indicator lamp turns ON).**

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis for "ABS" with CONSULT.



# UNEXPECTED BRAKE PEDAL REACTION

[WITH VDC]

< SYMPTOM DIAGNOSIS >

## UNEXPECTED BRAKE PEDAL REACTION

### Description

INFOID:000000012406821

A malfunction of brake pedal feel (height or others) is detected when brake pedal is depressed.

### Diagnosis Procedure

INFOID:000000012406822

#### 1.CHECK FRONT AND REAR AXLE

Check that there is no excessive looseness in front and rear axle.

- Front axle: Refer to [FAX-7, "Inspection"](#).
- Rear axle: Refer to [RAX-5, "Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace error-detected parts.

#### 2.CHECK DISC ROTOR

Check disc rotor runout.

- Front: Refer to [BR-16, "DISC ROTOR : Inspection and Adjustment"](#).
- Rear: Refer to [BR-18, "DISC ROTOR : Inspection and Adjustment"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Refinish disc rotor.
  - Front: Refer to [BR-16, "DISC ROTOR : Inspection and Adjustment"](#).
  - Rear: Refer to [BR-18, "DISC ROTOR : Inspection and Adjustment"](#).

#### 3.CHECK BRAKE FLUID LEAKAGE

Check fluid leakage.

- Front: Refer to [BR-24, "FRONT : Inspection"](#).
- Rear: Refer to [BR-27, "REAR : Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace error-detected parts.

#### 4.CHECK BRAKE PEDAL

Check each item of brake pedal. Refer to [BR-9, "Inspection and Adjustment"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Adjust each item of brake pedal. Refer to [BR-9, "Inspection and Adjustment"](#).

#### 5.CHECK BRAKING FORCE

Check brake force using a brake tester.

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Check each components of brake system.

#### 6.CHECK BRAKE PERFORMANCE

Disconnect ABS actuator and electric unit (control unit) connector so that ABS does not operate. Check that brake force is normal in this condition. Connect harness connectors after checking.

Is the inspection result normal?

- YES >> Normal
- NO >> Check each components of brake system.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# THE BRAKING DISTANCE IS LONG

[WITH VDC]

< SYMPTOM DIAGNOSIS >

---

## THE BRAKING DISTANCE IS LONG

### Description

INFOID:000000012406823

Brake stopping distance is long when ABS function is operated.

### Diagnosis Procedure

INFOID:000000012406824

#### **CAUTION:**

**Brake stopping distance on slippery road like rough road, gravel road or snowy road may become longer when ABS is operated than when ABS is not operated.**

#### **1.CHECK BRAKING FORCE**

---

Check brake force using a brake tester.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check each components of brake system.

#### **2.CHECK BRAKE PERFORMANCE**

---

Disconnect ABS actuator and electric unit (control unit) connector so that ABS does not operate. Check brake stopping distance in this condition. Connect harness connectors after checking.

Is the inspection result normal?

YES >> Normal

NO >> Check each components of brake system.

# DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH VDC]

## DOES NOT OPERATE

### Description

INFOID:000000012406825

VDC function, TCS function, ABS function, EBD function and brake limited slip differential (BLSD) function does not operate.

### Diagnosis Procedure

INFOID:000000012406826

#### CAUTION:

- VDC function, ABS function and EBD function never operate when the vehicle speed is 10 km/h (6.2 MPH) or less.
- VDC function and TCS function never operate when VDC OFF switch is operated (when VDC OFF indicator lamp turns ON).

#### 1. CHECK WARNING LAMP

Check that ABS warning lamp, brake warning lamp and VDC warning lamp turn ON and turn OFF approx. 2 second after key switch is turned ON. Check that ABS warning lamp, brake warning lamp and VDC warning lamp and stay in OFF status during driving.

#### CAUTION:

- Brake warning lamp turns ON when parking brake is operated (parking brake switch is ON) or brake fluid is less than the specified level (brake fluid level switch is ON).
- VDC function and TCS function never operate when VDC OFF switch is operated (when VDC OFF indicator lamp turns ON).

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis for "ABS" with CONSULT.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# BRAKE PEDAL VIBRATION OR OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[WITH VDC]

## BRAKE PEDAL VIBRATION OR OPERATION SOUND OCCURS

### Description

INFOID:000000012406827

- Brake pedal vibrates and motor sound from ABS actuator and electric unit (control unit) occurs, when the engine starts.
- Brake pedal vibrates during braking.

#### **CAUTION:**

Vibration may be felt during brake pedal is lightly depressed (just placing a foot on it) in the following conditions. This is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [Approx. 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approx. 15 km/h (9.3 MPH) or higher]

### Diagnosis Procedure

INFOID:000000012406828

#### 1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Check brake pedal. Refer to [BR-21, "Inspection and Adjustment"](#).

#### 2. SYMPTOM CHECK 2

Check that motor noise from ABS actuator and electric unit (control unit) occurs when the engine starts.

Does the operation sound occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis for "ABS" with CONSULT.

#### 3. SYMPTOM CHECK 3

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Does the symptom occur?

YES >> Check that radio (including wiring), antenna and antenna lead-in wires are not located near ABS actuator and electric unit (control unit). Move them if they are located near ABS actuator and electric unit (control unit).

NO >> Normal

# VEHICLE JERKS DURING

[WITH VDC]

< SYMPTOM DIAGNOSIS >

## VEHICLE JERKS DURING

### Description

INFOID:000000012406829

The vehicle jerks when VDC function, TCS function, ABS function, EBD function or brake limited slip differential (BLSD) function operates.

### Diagnosis Procedure

INFOID:000000012406830

#### 1.CHECK SYMPTOM

Check that the vehicle jerks when VDC function, TCS function, ABS function, EBD function or brake limited slip differential (BLSD) function operates.

Is the inspection result normal?

- YES >> Normal
- NO >> GO TO 2.

#### 2.PERFORM SELF-DIAGNOSIS

 With CONSULT

Perform self-diagnosis for "ABS".

Is any DTC detected?

- YES >> Check the DTC. Refer to [BRC-38. "DTC Index"](#).
- NO >> GO TO 3.

#### 3.CHECK CONNECTOR

 With CONSULT

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check connector terminal for deformation, disconnection and looseness.
4. Connect harness connector and perform self-diagnosis for "ABS" again.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Poor connection of connector terminal. Repair or replace connector terminal.

#### 4.CHECK ECM AND TCM SELF-DIAGNOSIS RESULTS

 With CONSULT

Perform self-diagnosis for "ENGINE" and "TRANSMISSION".

Is any DTC detected?

- YES >> Check the DTC.
- NO >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-139. "Removal and Installation"](#).

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[WITH VDC]

### NORMAL OPERATING CONDITION

#### Description

INFOID:000000012406831

Symptom	Result
Brake pedal slightly vibrates and operation sound (motor sound and sound from suspension) occurs when VDC function, TCS function, ABS function, EBD function or brake limited differential (BLSD) function operates.	This is not a malfunction, The symptom occurs VDC function, TCS function, ABS function, EBD function and brake limited differential (BLSD) function that are normally operated.
Brake stopping distance may become longer than models without ABS function depending on the road conditions, when ABS function is operated on slippery road like rough road, gravel road or snowy road.	
Brake pedal vibrates and operation sound occurs during sudden acceleration and cornering, when VDC function, TCS function or brake limited slip differential (BLSD) function is operated.	
Brake pedal vibrates and motor sound from the engine room occurs, when the engine starts or the vehicle starts just after starting the engine.	This is not a malfunction, because it is caused by operation check of ABS actuator and electric unit (control unit).
Acceleration may be felt insufficient depending on the road conditions.	This is not a malfunction, because it is caused by TCS function that puts the highest priority to obtain the optimum traction (stability).
TCS function may operate momentarily, while driving on a road where friction coefficient varies, or when downshifting, or fully depressing accelerator pedal.	
VDC warning lamp may turn ON, when the vehicle is on a rotating turntable or is given a strong shaking or large vibrations on a ship while the engine is running.	In this case, restart the engine on a normal road. If the normal condition is restored, there is no malfunction. In that case, erase "ABS" self-diagnosis result memory with CONSULT.
VDC warning lamp may turn ON and VDC function, TCS function and brake limited slip differential (BLSD) function may not normally operate, when driving on a special road the is extremely slanted (bank in a circuit course).	
A malfunction in yaw rate/side G sensor system may be detected when the vehicle sharply turns during a spin turn, acceleration turn or drift driving while VDC function, TCS function and brake limited slip differential (BLSD) function are OFF (VDC OFF switch is pressed and VDC OFF indicator lamp is in ON status).	
The vehicle speed does not increase, when the accelerator pedal is depressed while the vehicle is on a 2-wheel chassis dynamometer for speedometer check.	This is not a malfunction. (When checking the vehicle on a chassis dynamometer, operate VDC OFF switch so that TCS function is OFF.)

# WHEEL SENSOR

< REMOVAL AND INSTALLATION >

[WITH VDC]


## REMOVAL AND INSTALLATION

### WHEEL SENSOR

### FRONT WHEEL SENSOR

### FRONT WHEEL SENSOR : Exploded View

INFOID:000000012406832



1. Front LH wheel sensor harness connector
  2. Front LH wheel sensor
- B. Identification line

←: Vehicle front

: N·m (kg-m, in-lb)

#### NOTE:

Front RH wheel sensor is symmetrically opposite of LH.

### FRONT WHEEL SENSOR : Removal and Installation

INFOID:000000012406833

#### REMOVAL

1. Remove tires with power tool.
2. Remove front wheel sensor from steering knuckle.  
**CAUTION:**  
**Never rotate and never pull front wheel sensor as much as possible, when pulling out.**
3. Remove front wheel sensor harness from the vehicle.  
**CAUTION:**  
**Never twist or pull front wheel sensor harness, when removing.**

#### INSTALLATION

Note the following, and install in the reverse order of the removal.

# WHEEL SENSOR


< REMOVAL AND INSTALLATION >

[WITH VDC]

- Check that there is no foreign material like iron powder or damage on inner surface of front wheel sensor mounting hole of steering knuckle and sensor rotor. Install after cleaning when there are foreign material like iron powder, or replace when there is a malfunction.
- Never twist front wheel sensor harness when installing front wheel sensor. Check that grommet (2) is fully inserted to bracket (1). Check that front wheel sensor harness is not twisted after installation.

**CAUTION:**

Check that the identification line of the front wheel sensor is faced vehicle front.




JPFIC0209ZZ

## REAR WHEEL SENSOR

### REAR WHEEL SENSOR : Exploded View

INFOID:000000012406834



- |                         |   |   |
|-------------------------|---|---|
| 1. Rear RH wheel sensor | 2. Rear RH wheel sensor harness connector | 3. Rear LH wheel sensor harness connector |
| 4. Rear LH wheel sensor |   |   |
| C. Identification line  |   |   |

←: Vehicle front

: N·m (kg·m, in·lb)

### REAR WHEEL SENSOR : Removal and Installation

INFOID:000000012406835

#### REMOVAL

1. Remove rear wheel sensor from rear axle housing.

**CAUTION:**



# WHEEL SENSOR

< REMOVAL AND INSTALLATION >

[WITH VDC]

**Never rotate or pull rear wheel sensor as much as possible, when pulling out.**

2. Remove rear wheel sensor harness from the vehicle.

**CAUTION:**

**Never twist and never pull rear wheel sensor harness, when removing.**


## INSTALLATION

Note the following, and install in the reverse order of the removal.

- Check that there is no foreign material like iron powder or damage on inner surface of rear wheel sensor mounting hole of wheel hub and bearing assembly and sensor rotor. Install after cleaning when there are foreign material like iron powder, or replace when there is a malfunction.
- Never twist rear wheel sensor harness when installing rear wheel sensor. Check that grommet (2) is fully inserted to bracket (1). Check that rear wheel sensor harness is not twisted after installation.

**CAUTION:**

**Check that the identification line of the rear wheel sensor is faced vehicle front.**



A  
B  
C  
D  
E  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# SENSOR ROTOR

< REMOVAL AND INSTALLATION >

[WITH VDC]

## SENSOR ROTOR

### FRONT SENSOR ROTOR

#### FRONT SENSOR ROTOR : Removal and Installation

INFOID:0000000012406836

##### REMOVAL

Replace wheel hub as an assembly when replacing because sensor rotor cannot be disassembled. Refer to [FAX-9, "Removal and Installation"](#).

##### INSTALLATION

Replace wheel hub as an assembly when replacing because sensor rotor cannot be disassembled. Refer to [RAX-7, "Removal and Installation"](#).

### REAR SENSOR ROTOR

#### REAR SENSOR ROTOR : Removal and Installation

INFOID:0000000012406837

##### REMOVAL

Replace wheel hub as an assembly when replacing because sensor rotor cannot be disassembled. Refer to [RAX-7, "Removal and Installation"](#).

##### INSTALLATION

Replace wheel hub as an assembly when replacing because sensor rotor cannot be disassembled. Refer to [RAX-7, "Removal and Installation"](#).

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< REMOVAL AND INSTALLATION >

[WITH VDC]

## ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000012406838



- |  |  |                        |
|--|--|------------------------|
| 1. ABS actuator and electric unit (control unit) | 2. ABS actuator and electric unit (control unit) harness connector | 3. Bracket             |
| A. To master cylinder primary side               | B. To front RH caliper   | C. To front LH caliper |
| D. To master cylinder secondary side             | E. To rear RH caliper  | F. To rear LH caliper  |

←: Vehicle front

: N·m (kg-m, ft-lb)

: N·m (kg-m, in-lb)

## Removal and Installation

INFOID:000000012406839

### REMOVAL

1. Disconnect battery cable from negative terminal.
2. Drain brake fluid. Refer to [BR-12. "Draining"](#).
3. Remove cowl top cover. Refer to [EXT-22. "Removal and Installation"](#).
4. Remove brake tube form between ABS actuator and electric unit (control unit) and master cylinder assembly. Refer to [BR-22. "FRONT : Exploded View"](#).
5. Remove vacuum piping. Refer to [BR-35. "Removal and Installation"](#).
6. Move the High-pressure pipe. Refer to [HA-36. "HIGH-PRESSURE PIPE : Removal and Installation"](#).

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[WITH VDC]


## < REMOVAL AND INSTALLATION >

7. Disconnect ABS actuator and electric unit (control unit) harness connector (1), follow the procedure described below.
  - a. Push the pawl (A).
  - b. Move the lever (B) in the direction (C) until locked.
  - c. Disconnect ABS actuator and electric unit (control unit) harness connector.
8. Remove ABS actuator and electric unit (control unit) and bracket.

**CAUTION:**

- Never remove and never install ABS actuator and electric unit (control unit) by holding harness connector.
- Be careful not to drop ABS actuator and electric unit (control unit) and apply excessive impact to it.


9. Remove bracket from ABS actuator and electric unit (control unit).




## INSTALLATION

Note the following, and install in the reverse order of removal.

- When replacing with a new ABS actuator and electric unit (control unit), never remove the protector of the brake tube mounting hole until right before the brake tube is installed.
- Install ABS actuator and electric unit (control unit) as per the following instruction.
- Temporarily tighten mounting bolt (1) and temporarily fix bracket (2). Tighten mounting bolts to the specified torque, according to the tightening order (3) → (4) → (1).
- When installing brake tube, tighten to the specified torque using a crowfoot and torque wrench so that flare nut and brake tube are not damaged. Refer to [BR-22, "FRONT : Exploded View"](#).
- Never remove and install ABS actuator and electric unit (control unit) by holding actuator harness.
- Bleed the brake piping after installation. Refer to [BR-13, "Bleeding Brake System"](#).
- Never apply excessive impact to actuator, such as by dropping it.



- After installing the ABS actuator and electric unit (control unit) harness connector (1), move the lever (A) in the direction (B) to secure the locking.
- Perform steering angle sensor neutral position adjustment when ABS actuator and electric unit (control unit) is replaced. Refer to [BRC-50, "Work Procedure"](#).



# YAW RATE/SIDE/DECEL G SENSOR


< REMOVAL AND INSTALLATION >

[WITH VDC]

## YAW RATE/SIDE/DECEL G SENSOR

Exploded View

INFOID:000000012406840



1. Yaw rate/side G sensor
2. Yaw rate/side G sensor harness connector

↔: Vehicle front

🔧: N·m (kg-m, in-lb)

## Removal and Installation

INFOID:000000012406841

### REMOVAL

#### CAUTION:

Never drop or strike yaw rate/side G sensor, because it has little endurance to impact. Never use a pneumatic tool.

1. Remove instrument lower cover LH and RH. Refer to [IP-14, "Removal and Installation"](#).
2. Disconnect yaw rate/side G sensor harness connector.
3. Remove yaw rate/side G sensor.

### INSTALLATION

Note the following, and install in the reverse order of removal.

- Never drop or strike yaw rate/transverse G sensor, because it has little endurance to impact. Never use a power tool.

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# STEERING ANGLE SENSOR

[WITH VDC]

< REMOVAL AND INSTALLATION >

---

## STEERING ANGLE SENSOR

### Removal and Installation

INFOID:000000012406842

#### REMOVAL

1. Remove spiral cable assembly. Refer to [SR-16, "Removal and Installation"](#).
2. Remove steering angle sensor.

#### INSTALLATION

Note the following, and install in the reverse order of removal.

- Perform steering angle sensor neutral position adjustment when steering angle sensor is removed and installed, or replaced. Refer to [BRC-50, "Work Procedure"](#).

# VDC OFF SWITCH

[WITH VDC]

< REMOVAL AND INSTALLATION >

## VDC OFF SWITCH

### Removal and Installation

INFOID:000000012406843

#### REMOVAL

1. Remove lower instrument panel. Refer to [IP-14, "Removal and Installation"](#).
2. Remove VDC OFF switch.

#### INSTALLATION

Installation is the reverse order of removal.

A

B

C

D

E

**BRC**

G

H

I

J

K

L

M

N

O

P