

SECTION **BRC**

BRAKE CONTROL SYSTEM

A
B
C
D
E

CONTENTS

ABS	C1109 POWER AND GROUND SYSTEM	24
BASIC INSPECTION	Description	24
DIAGNOSIS AND REPAIR WORKFLOW	DTC Logic	24
Work Flow	Diagnosis Procedure	24
Diagnostic Work Sheet	C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)	26
SYSTEM DESCRIPTION	Description	26
ABS	DTC Logic	26
System Diagram	Diagnosis Procedure	26
System Description	C1111 ABS MOTOR, MOTOR RELAY SYSTEM	27
Component Parts Location	Description	27
Component Description	DTC Logic	27
EBD	Diagnosis Procedure	27
System Diagram	Component Inspection	28
System Description	C1113 G SENSOR	29
Component Parts Location	Description	29
Component Description	DTC Logic	29
DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]	Diagnosis Procedure	29
CONSULT-III Function	Component Inspection	30
DTC/CIRCUIT DIAGNOSIS	C1115 WHEEL SENSOR	32
C1101, C1102, C1103, C1104 WHEEL SENSOR	Description	32
Description	DTC Logic	32
DTC Logic	Diagnosis Procedure	32
Diagnosis Procedure	Component Inspection	33
Component Inspection	C1120, C1122, C1124, C1126 IN ABS SOL	35
C1105, C1106, C1107, C1108 WHEEL SENSOR	Description	35
Description	DTC Logic	35
DTC Logic	Diagnosis Procedure	35
Diagnosis Procedure	Component Inspection	36
Component Inspection	C1121, C1123, C1125, C1127 OUT ABS SOL	37
C1109 POWER AND GROUND SYSTEM	Description	37
Description	DTC Logic	37
DTC Logic	Diagnosis Procedure	37
Diagnosis Procedure	Component Inspection	38

BRC

G
H
I
J
K
L
M
N
O
P

C1140 ACTUATOR RELAY SYSTEM	39	PEDAL VIBRATION OR ABS OPERATION	
Description	39	SOUND OCCURS	61
DTC Logic	39	Diagnosis Procedure	61
Diagnosis Procedure	39	NORMAL OPERATING CONDITION	62
Component Inspection	40	Description	62
U1000 CAN COMM CIRCUIT	41	PRECAUTION	63
Description	41	PRECAUTIONS	63
DTC Logic	41	FOR USA AND CANADA	63
Diagnosis Procedure	41	FOR USA AND CANADA : Precaution for Supple-	
U1010 CONTROL UNIT (CAN)	42	mental Restraint System (SRS) "AIR BAG" and	
Description	42	"SEAT BELT PRE-TENSIONER"	63
DTC Logic	42	FOR USA AND CANADA : Precaution for Proce-	
Diagnosis Procedure	42	dure without Cowl Top Cover	63
BRAKE FLUID LEVEL SWITCH	43	FOR USA AND CANADA : Precaution for Brake	
Description	43	System	63
Component Function Check	43	FOR USA AND CANADA : Precaution for Brake	
Diagnosis Procedure	43	Control	64
Component Inspection	44	FOR MEXICO	64
PARKING BRAKE SWITCH	45	FOR MEXICO : Precaution for Supplemental Re-	
Description	45	straint System (SRS) "AIR BAG" and "SEAT BELT	
Component Function Check	45	PRE-TENSIONER"	64
Diagnosis Procedure	45	FOR MEXICO : Precaution for Procedure without	
Component Inspection	45	Cowl Top Cover	65
ABS WARNING LAMP	47	FOR MEXICO : Precaution for Brake System	65
Description	47	FOR MEXICO : Precaution for Brake Control	65
Component Function Check	47	REMOVAL AND INSTALLATION	66
Diagnosis Procedure	47	WHEEL SENSOR	66
BRAKE WARNING LAMP	48	FRONT WHEEL SENSOR	66
Description	48	FRONT WHEEL SENSOR : Exploded View	66
Component Function Check	48	FRONT WHEEL SENSOR : Removal and Instal-	
Diagnosis Procedure	48	lation	66
ECU DIAGNOSIS INFORMATION	49	REAR WHEEL SENSOR	66
ABS ACTUATOR AND ELECTRIC UNIT		REAR WHEEL SENSOR : Exploded View	67
(CONTROL UNIT)	49	REAR WHEEL SENSOR : Removal and Installa-	
Reference Value	49	tion	67
Wiring Diagram -BRAKE CONTROL SYSTEM-	52	SENSOR ROTOR	68
Fail-Safe	55	FRONT SENSOR ROTOR	68
DTC Index	56	FRONT SENSOR ROTOR : Exploded View	68
SYMPTOM DIAGNOSIS	57	FRONT SENSOR ROTOR : Removal and Instal-	
EXCESSIVE ABS FUNCTION OPERATION		lation	68
FREQUENCY	57	REAR SENSOR ROTOR	68
Diagnosis Procedure	57	REAR SENSOR ROTOR : Exploded View	68
UNEXPECTED PEDAL REACTION	58	REAR SENSOR ROTOR : Removal and Installa-	
Diagnosis Procedure	58	tion	68
THE BRAKING DISTANCE IS LONG	59	ABS ACTUATOR AND ELECTRIC UNIT	
Diagnosis Procedure	59	(CONTROL UNIT)	69
ABS FUNCTION DOES NOT OPERATE	60	Exploded View	69
Diagnosis Procedure	60	Removal and Installation	69

G SENSOR	71	C1105, C1106, C1107, C1108 WHEEL SEN-	
Exploded View	71	SOR	102
Removal and Installation	71	Description	102
VDC/TCS/ABS		DTC Logic	102
BASIC INSPECTION	72	Diagnosis Procedure	102
DIAGNOSIS AND REPAIR WORKFLOW	72	Component Inspection	104
Work Flow	72	Special Repair Requirement	104
Diagnostic Work Sheet	75	C1109 POWER AND GROUND SYSTEM	105
INSPECTION AND ADJUSTMENT	76	Description	105
ADJUSTMENT OF STEERING ANGLE SENSOR		DTC Logic	105
NEUTRAL POSITION	76	Diagnosis Procedure	105
ADJUSTMENT OF STEERING ANGLE SENSOR		Diagnosis Procedure	106
NEUTRAL POSITION : Description	76	C1110 ABS ACTUATOR AND ELECTRIC	
ADJUSTMENT OF STEERING ANGLE SENSOR		UNIT (CONTROL UNIT)	108
NEUTRAL POSITION : Special Repair Require-		Description	108
ment	76	DTC Logic	108
SYSTEM DESCRIPTION	78	Diagnosis Procedure	108
VDC	78	Special Repair Requirement	108
System Diagram	78	C1111 ABS MOTOR, MOTOR RELAY SYS-	
System Description	78	TEM	109
Component Parts Location	78	Description	109
Component Description	81	DTC Logic	109
TCS	82	Diagnosis Procedure	109
System Diagram	82	Component Inspection	110
System Description	82	Special Repair Requirement	110
Component Parts Location	82	C1113, C1145, C1146 YAW RATE/SIDE/DE-	
Component Description	85	CEL G SENSOR	111
ABS	86	Description	111
System Diagram	86	DTC Logic	111
System Description	86	Diagnosis Procedure	111
Component Parts Location	86	Component Inspection	113
Component Description	89	Special Repair Requirement	113
EBD	90	C1115 WHEEL SENSOR	115
System Diagram	90	Description	115
System Description	90	DTC Logic	115
Component Parts Location	90	Diagnosis Procedure	115
Component Description	93	Component Inspection	116
DIAGNOSIS SYSTEM [ABS ACTUATOR		Special Repair Requirement	117
AND ELECTRIC UNIT (CONTROL UNIT)]	94	C1116 STOP LAMP SWITCH	118
CONSULT-III Function	94	Description	118
DTC/CIRCUIT DIAGNOSIS	99	DTC Logic	118
C1101, C1102, C1103, C1104 WHEEL SEN-		Diagnosis Procedure	118
SOR	99	Component Inspection	119
Description	99	Component Inspection	119
DTC Logic	99	C1118 AWD SYSTEM	120
Diagnosis Procedure	99	Description	120
Component Inspection	101	DTC Logic	120
Special Repair Requirement	101	Diagnosis Procedure	120
C1105, C1106, C1107, C1108 WHEEL SEN-		Special Repair Requirement	120
SOR	102	C1120, C1122, C1124, C1126 IN ABS SOL ...	121
Description	102	Description	121
DTC Logic	102	DTC Logic	121
Diagnosis Procedure	102		
Component Inspection	104		
Special Repair Requirement	104		

Diagnosis Procedure	121	DTC Logic	141
Component Inspection	122	Diagnosis Procedure	141
Special Repair Requirement	123	Special Repair Requirement	141
C1121, C1123, C1125, C1127 OUT ABS SOL	124	U1010 CONTROL UNIT (CAN)	142
Description	124	Description	142
DTC Logic	124	DTC Logic	142
Diagnosis Procedure	124	Diagnosis Procedure	142
Component Inspection	125	Special Repair Requirement	142
Special Repair Requirement	126	PARKING BRAKE SWITCH	143
C1130 ENGINE SIGNAL	127	Description	143
Description	127	Component Function Check	143
DTC Logic	127	Diagnosis Procedure	143
Diagnosis Procedure	127	Component Inspection	143
Diagnosis Procedure	127	VDC OFF SWITCH	145
C1140 ACTUATOR RELAY SYSTEM	128	Description	145
Description	128	Component Function Check	145
DTC Logic	128	Diagnosis Procedure	145
Diagnosis Procedure	128	Component Inspection	146
Component Inspection	129	Special Repair Requirement	146
Special Repair Requirement	129	ABS WARNING LAMP	147
C1143, C1144 STEERING ANGLE SENSOR	130	Description	147
Description	130	Component Function Check	147
DTC Logic	130	Diagnosis Procedure	147
Diagnosis Procedure	130	Special Repair Requirement	147
Component Inspection	131	BRAKE WARNING LAMP	148
Special Repair Requirement	131	Description	148
C1155 BRAKE FLUID LEVEL SWITCH	132	Component Function Check	148
Description	132	Diagnosis Procedure	148
DTC Logic	132	Special Repair Requirement	148
Diagnosis Procedure	132	VDC OFF INDICATOR LAMP	150
Component Inspection	133	Description	150
Special Repair Requirement	134	Component Function Check	150
C1164, C1165 CV SYSTEM	135	Diagnosis Procedure	150
Description	135	Special Repair Requirement	150
DTC Logic	135	SLIP INDICATOR LAMP	152
Diagnosis Procedure	135	Description	152
Component Inspection	136	Component Function Check	152
Special Repair Requirement	136	Diagnosis Procedure	152
C1166, C1167 SV SYSTEM	137	Special Repair Requirement	152
Description	137	ECU DIAGNOSIS INFORMATION	153
DTC Logic	137	ABS ACTUATOR AND ELECTRIC UNIT	
Diagnosis Procedure	137	(CONTROL UNIT)	153
Component Inspection	138	Reference Value	153
Special Repair Requirement	138	Wiring Diagram -BRAKE CONTROL SYSTEM- ..	157
C1176 STOP LAMP SW2	139	Fail-Safe	160
Description	139	DTC Index	161
DTC Logic	139	SYMPTOM DIAGNOSIS	163
Diagnosis Procedure	139	EXCESSIVE ABS FUNCTION OPERATION	
Component Inspection	140	FREQUENCY	163
Special Repair Requirement	140	Diagnosis Procedure	163
U1000 CAN COMM CIRCUIT	141		
Description	141		

UNEXPECTED PEDAL REACTION	164	FOR MEXICO : Precaution for Brake System	172	
Diagnosis Procedure	164	FOR MEXICO : Precaution for Brake Control	173	A
THE BRAKING DISTANCE IS LONG	165	FOR MEXICO : Precautions for Harness Repair ..	173	
Diagnosis Procedure	165	REMOVAL AND INSTALLATION	175	B
ABS FUNCTION DOES NOT OPERATE	166	WHEEL SENSOR	175	
Diagnosis Procedure	166	FRONT WHEEL SENSOR	175	C
PEDAL VIBRATION OR ABS OPERATION		FRONT WHEEL SENSOR : Exploded View	175	
SOUND OCCURS	167	FRONT WHEEL SENSOR : Removal and Instal-		D
Diagnosis Procedure	167	lation	175	
VEHICLE JERKS DURING VDC/TCS/ABS		REAR WHEEL SENSOR	175	E
CONTROL	168	REAR WHEEL SENSOR : Exploded View	176	
Diagnosis Procedure	168	REAR WHEEL SENSOR : Removal and Installa-		
NORMAL OPERATING CONDITION	169	tion	176	
Description	169	SENSOR ROTOR	177	BRC
PRECAUTION	170	FRONT SENSOR ROTOR	177	
PRECAUTIONS	170	FRONT SENSOR ROTOR : Exploded View	177	
FOR USA AND CANADA	170	FRONT SENSOR ROTOR : Removal and Instal-		G
FOR USA AND CANADA : Precaution for Supple-		lation	177	
mental Restraint System (SRS) "AIR BAG" and		REAR SENSOR ROTOR	177	
"SEAT BELT PRE-TENSIONER"	170	REAR SENSOR ROTOR : Exploded View	177	H
FOR USA AND CANADA : Precaution for Proce-		REAR SENSOR ROTOR : Removal and Installa-		
dure without Cowl Top Cover	170	tion	177	
FOR USA AND CANADA : Precaution for Brake		ABS ACTUATOR AND ELECTRIC UNIT		I
System	170	(CONTROL UNIT)	178	
FOR USA AND CANADA : Precaution for Brake		Exploded View	178	
Control	171	Removal and Installation	178	J
FOR USA AND CANADA : Precautions for Har-		G SENSOR	180	
ness Repair	171	Exploded View	180	K
FOR MEXICO	172	Removal and Installation	180	
FOR MEXICO : Precaution for Supplemental Re-		STEERING ANGLE SENSOR	181	L
straint System (SRS) "AIR BAG" and "SEAT BELT		Exploded View	181	
PRE-TENSIONER"	172	Removal and Installation	181	
FOR MEXICO : Precaution for Procedure without				M
Cowl Top Cover	172			
				N
				O
				P

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[ABS]


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006202887

OVERALL SEQUENCE



DETAILED FLOW

DIAGNOSIS AND REPAIR WORKFLOW

[ABS]

< BASIC INSPECTION >

1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis worksheet. Refer to [BRC-8, "Diagnostic Work Sheet"](#).

>> GO TO 2.

2. PERFORM THE SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III. Refer to [BRC-15, "CONSULT-III Function"](#).

Is there any DTC displayed?

YES >> GO TO 3.

NO >> GO TO 4.

3. PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC of "ABS" with CONSULT-III. Refer to [BRC-56, "DTC Index"](#).

>> GO TO 7.

4. CHECK THE SYMPTOM THAT IS NOT CONSIDERED A SYSTEM MALFUNCTION

Check that the symptom is a normal operation that is not considered a system malfunction. Refer to [BRC-62, "Description"](#).

Is the symptom a normal operation?

YES >> INSPECTION END

NO >> GO TO 5.

5. CHECK THE WARNING LAMP FOR ILLUMINATION

Check that the warning lamp illuminate.

• ABS warning lamp: Refer to [BRC-47, "Description"](#).

• Brake warning lamp: Refer to [BRC-48, "Description"](#).

Is ON/OFF timing normal?

YES >> GO TO 6.

NO >> GO TO 2.

6. PERFORM THE DIAGNOSIS BY SYMPTOM

Perform the diagnosis applicable to the displayed DTC of "ABS" with CONSULT-III.

>> GO TO 7.

7. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 8.

8. MEMORY CLEAR

Perform self-diagnosis memory clear for "ABS" with CONSULT-III.

>> GO TO 9.

9. FINAL CHECK

Perform the again, and check that the malfunction is repaired completely.

Is no other DTC present and the repair completed?

YES >> INSPECTION END

NO >> GO TO 3.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[ABS]

Diagnostic Work Sheet

INFOID:000000006202888

Customer name MR/MS	Model & Year	VIN	
Engine #	Trans.	Mileage	
Incident Date	Manuf. Date	In Service Date	
Symptoms	<input type="checkbox"/> Noise and vibration (from engine compartment) <input type="checkbox"/> Noise and vibration (from axle)	<input type="checkbox"/> Warning / Indicator activate	<input type="checkbox"/> Firm pedal operation <input type="checkbox"/> Large stroke pedal operation
	<input type="checkbox"/> ABS does not work (Wheels lock when braking)	<input type="checkbox"/> Lack of sense of acceleration	
Engine conditions	<input type="checkbox"/> When starting <input type="checkbox"/> After starting		
Road conditions	<input type="checkbox"/> Low friction road (<input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other) <input type="checkbox"/> Bumps / potholes		
Driving conditions	<input type="checkbox"/> Full-acceleration <input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped		
Applying brake conditions	<input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually		
Other conditions	<input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Shift change <input type="checkbox"/> Other descriptions		


SFIA3264E

SYSTEM DESCRIPTION

ABS

System Diagram

INFOID:000000006202889



A
B
C
D
E
BRC
G
H
I
J

System Description

INFOID:000000006202890

- Anti-Lock Braking System is a function that detects wheel revolution while braking, electronically controls braking force, and prevents wheel locking during sudden braking. It improves handling stability and maneuverability for avoiding obstacles.
- Electrical system diagnosis by CONSULT-III is available.

K
L
M
N
O
P


ABS

< SYSTEM DESCRIPTION >

[ABS]

Component Parts Location

INFOID:00000006202891



- | | | |
|--|-----------------------|-----------------------------------|
| 1. ABS warning lamp | 2. Brake warning lamp | 3. G sensor (AWD models) |
| 4. ABS actuator and electric unit (control unit) | 5. Front wheel sensor | 6. Rear wheel sensor (2WD models) |
| 7. Rear wheel sensor (AWD models) | | |
| A. Combination meter | B. Center console | C. Engine room (right side) |
| D. Steering knuckle | E. Rear axle | |

ABS

< SYSTEM DESCRIPTION >

[ABS]

Component Description

INFOID:000000006202892

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	BRC-27. "Description"
	Motor	
	Actuator relay (Main relay)	BRC-39. "Description"
	Solenoid valve	BRC-35. "Description"
Wheel sensor		BRC-18. "Description"
G sensor (AWD models)		BRC-29. "Description"
ABS warning lamp		BRC-47. "Description"
Brake warning lamp		BRC-48. "Description"

A
B
C
D
E


BRC

G
H
I
J
K
L
M
N
O
P

EBD

System Diagram


INFOID:000000006202893



System Description

INFOID:000000006202894

- Electric Brake force Distribution is a following function. ABS actuator and electric unit (control unit) detects subtle slippages between the front and rear wheels during braking. Then is electronically controls the rear braking force (brake fluid pressure) to reducing and reduces rear wheel slippage. Accordingly it improves vehicle stability.
- Electrical system diagnosis by CONSULT-III is available.



- | | | |
|--|-----------------------|-----------------------------------|
| 1. ABS warning lamp | 2. Brake warning lamp | 3. G sensor (AWD models) |
| 4. ABS actuator and electric unit (control unit) | 5. Front wheel sensor | 6. Rear wheel sensor (2WD models) |
| 7. Rear wheel sensor (AWD models) | | |
| A. Combination meter | B. Center console | C. Engine room (right side) |
| D. Steering knuckle | E. Rear axle | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

Component Description

INFOID:000000006202896

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	BRC-27. "Description"
	Motor	
	Actuator relay (Main relay)	BRC-39. "Description"
	Solenoid valve	BRC-35. "Description"
Wheel sensor		BRC-18. "Description"
G sensor (AWD models)		BRC-29. "Description"
ABS warning lamp		BRC-47. "Description"
Brake warning lamp		BRC-48. "Description"

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[ABS]

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

CONSULT-III Function

INFOID:000000006202897

FUNCTION

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

Diagnostic test mode	Function
Self diagnostic result	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the ABS actuator and electric unit (control unit) can be read.
Active test	Diagnostic test mode is which CONSULT-III drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range.
ECU identification	ABS actuator and electric unit (control unit) part number can be read.

SELF DIAGNOSTIC RESULT

Operation Procedure

Before performing the self-diagnosis for "ABS" with CONSULT-III, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.

How to Erase Self-diagnosis Results

After erasing DTC memory for "ABS" with CONSULT-III, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute as the final inspection, and make sure that the ABS warning lamp and brake warning lamp turn OFF.

CAUTION:

If memory cannot be erased, perform applicable diagnosis.

NOTE:

- When the wheel sensor malfunctions, after inspecting the wheel sensor system, the ABS warning lamp and brake warning lamp will not turn OFF even when the system is normal unless the vehicle is driving at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
- Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).

Display Item List

Refer to [BRC-56. "DTC Index"](#).

DATA MONITOR

Display Item List

×: Applicable ▼: Optional item

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
FR LH SENSOR [km/h (MPH)]	×	×	Wheel speed
FR RH SENSOR [km/h (MPH)]	×	×	
RR LH SENSOR [km/h (MPH)]	×	×	
RR RH SENSOR [km/h (MPH)]	×	×	
STOP LAMP SW (On/Off)	×	×	Stop lamp switch signal status
BATTERY VOLT (V)	×	×	Battery voltage supplied to the ABS actuator and electric unit (control unit)

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[ABS]

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
DECEL G-SEN1 (On/Off) (AWD models)	×	×	Vehicle on level surface or on slope
DECEL G-SEN2 (On/Off) (AWD models)	×	×	
FR RH IN SOL (On/Off)	▼	×	Operation status of each solenoid valve
FR RH OUT SOL (On/Off)	▼	×	
FR LH IN SOL (On/Off)	▼	×	
FR LH OUT SOL (On/Off)	▼	×	
RR RH IN SOL (On/Off)	▼	×	
RR RH OUT SOL (On/Off)	▼	×	
RR LH IN SOL (On/Off)	▼	×	
RR LH OUT SOL (On/Off)	▼	×	
MOTOR RELAY (On/Off)	▼	×	Motor and motor relay operation
ACTUATOR RLY (On/Off)	▼	×	Actuator relay operation
ABS WARN LAMP (On/Off)	▼	×	ABS warning lamp
EBD SIGNAL (On/Off)	▼	▼	EBD operation
ABS SIGNAL (On/Off)	▼	▼	ABS operation
EBD FAIL SIG (On/Off)	▼	▼	EBD fail-safe signal
ABS FAIL SIG (On/Off)	▼	▼	ABS fail-safe signal

ACTIVE TEST

CAUTION:

- Never perform active test while driving vehicle.
- Make sure to completely bleed air from brake system.
- The active test cannot be performed with the ABS warning lamp and brake warning lamp are on.
- ABS warning lamp and brake warning lamp are on during active test.

NOTE:

- When active test is performed while depressing the pedal, the pedal depression amount will change. This is normal. (Only solenoid valve and ABS motor.)
- "TEST IS STOPPED" in "ABS" with CONSULT-III is displayed 10 seconds after operation start.
- After "TEST IS STOPPED" in "ABS" with CONSULT-III is displayed, to perform test again.

Test Item

ABS SOLENOID VALVE

- Select "Up", "Keep" and "Down" of "ACTIVE TEST" in "ABS" with CONSULT-III. Then use screen monitor to check that solenoid valve operates as shown in solenoid valve operation chart.

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[ABS]

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*

*: On for 1 to 2 seconds after the select, and then Off.

ABS MOTOR

- Select "On" and "Off" of "ACTIVE TEST" in "ABS" with CONSULT-III on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY (Note)	On	On

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

ECU IDENTIFICATION

ABS actuator and electric unit (control unit) part number can be read.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

DTC/CIRCUIT DIAGNOSIS

C1101, C1102, C1103, C1104 WHEEL SENSOR

Description

INFOID:000000006202898

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006202899

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1101	RR RH SENSOR-1	Circuit of rear RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	<ul style="list-style-type: none">• Harness or connector• Wheel sensor• ABS actuator and electric unit (control unit)
C1102	RR LH SENSOR-1	Circuit of rear LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1103	FR RH SENSOR-1	Circuit of front RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1104	FR LH SENSOR-1	Circuit of front LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
RR RH SENSOR-1
RR LH SENSOR-1
FR RH SENSOR-1
FR LH SENSOR-1

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-18. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006202900

CAUTION:

Never check between wheel sensor terminals.

1. CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

- YES >> GO TO 2.
NO >> Adjust air pressure, or replace tire.

2. CHECK WHEEL SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

- YES >> GO TO 3.
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

C1101, C1102, C1103, C1104 WHEEL SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 4.

NO >> Poor connection of connector terminal. Repair or replace connector.

4. CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	12	E39 (Front RH)	4	Existed
	27	E22 (Front LH)	2	
	15	B41 (Rear RH)	8	
	30	B44 (Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	E39 (Front RH)	3	Existed
	23	E22 (Front LH)	1	
	11	B41 (Rear RH)	7	
	26	B44 (Rear LH)	5	

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)		Connector	Terminal	Continuity
Connector	Terminal			
E36	12, 21	E36	3, 4	Not existed
	27, 23			
	15, 11			
	30, 26			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5. REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.

CAUTION:

Never start engine.

C1101, C1102, C1103, C1104 WHEEL SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

5. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

- YES >> Replace ABS actuator and electric unit (control unit).
- NO >> INSPECTION END

Component Inspection

INFOID:000000006202901

1. CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ($\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to diagnosis procedure. Refer to [BRC-18, "Diagnosis Procedure"](#).

C1105, C1106, C1107, C1108 WHEEL SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

C1105, C1106, C1107, C1108 WHEEL SENSOR

Description

INFOID:000000006202902

ABS unit continually monitors wheel speed sensors to detect abnormal signals.

DTC Logic

INFOID:000000006202903

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1105	RR RH SENSOR-2	Signal from rear RH wheel sensor does not match other 3 wheel speed signals.	<ul style="list-style-type: none">• Sensor not installed currently• Sensor rotor or encoder damaged• Sensor rotor loose on axle• Electrical interference• Wheel not turning - e.g. vehicle driven on 2WD dyno• Sensor damaged• ABS unit damaged
C1106	RR LH SENSOR-2	Signal from rear LH wheel sensor does not match other 3 wheel speed signals.	
C1107	FR RH SENSOR-2	Signal from front RH wheel sensor does not match other 3 wheel speed signals.	
C1108	FR LH SENSOR-2	Signal from front LH wheel sensor does not match other 3 wheel speed signals.	

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
RR RH SENSOR-2
RR LH SENSOR-2
FR RH SENSOR-2
FR LH SENSOR-2

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-21. "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006202904

CAUTION:

Never check between wheel sensor terminals.

1.CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

YES >> GO TO 2.

NO >> Adjust air pressure, or replace tire.

2.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

YES >> GO TO 3.

NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

3.CHECK CONNECTOR

1. Turn ignition switch OFF.

C1105, C1106, C1107, C1108 WHEEL SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 4.

NO >> Poor connection of connector terminal. Repair or replace connector.

4. CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	12	E39 (Front RH)	4	Existed
	27	E22 (Front LH)	2	
	15	B41 (Rear RH)	8	
	30	B44 (Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	E39 (Front RH)	3	Existed
	23	E22 (Front LH)	1	
	11	B41 (Rear RH)	7	
	26	B44 (Rear LH)	5	

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	12, 21	E36	3, 4	Not existed
	27, 23			
	15, 11			
	30, 26			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5. REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.

CAUTION:

Never start engine.

5. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> Replace ABS actuator and electric unit (control unit).

C1105, C1106, C1107, C1108 WHEEL SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

NO >> INSPECTION END

Component Inspection

INFOID:000000006202905

1. CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ($\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-21, "Diagnosis Procedure"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1109 POWER AND GROUND SYSTEM

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

C1109 POWER AND GROUND SYSTEM

Description

INFOID:000000006202906

Supplies electric power to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006202907

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1109	BATTERY VOLTAGE [ABNORMAL]	When the ABS actuator and electric unit (control unit) power supply is lower than normal and vehicle speed is greater than 6km/h (4 MPH). Power supply is greater than normal limits.	<ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) • Fuse • Vehicle electrical power system

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
BATTERY VOLTAGE [ABNORMAL]

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-24, "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006202908

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 2.

NO >> Poor connection of connector terminal. Repair or replace connector.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Turn ignition switch ON or OFF and check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E36	16	Ground	Ignition switch: ON	Battery voltage
			Ignition switch: OFF	Approx. 0 V

4. Check 10A fusible link (59).
5. Check continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R.

C1109 POWER AND GROUND SYSTEM

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

ABS actuator and electric unit (control unit)		IPDM E/R		continuity
Connector	Terminal	Connector	Terminal	
E36	16	E15	59	Existed

A

6. Reconnect ABS actuator and electric unit (control unit) connector.

B

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

C

3. ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

1. Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 16 and 4. With ignition switch ON check bulb illuminates correctly.
2. Check ABS motor supply under loaded condition (connector E36 terminals 1 and 3).

D

Is the inspection result normal?

E

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

BRC

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

G

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

H

Is the inspection result normal?

I

YES >> Check battery for terminal looseness, low voltage, etc. if any malfunction is found, repair malfunctioning parts.

J

NO >> Repair or replace malfunctioning components (check ABS earth bolt for tightness and corrosion).

K

L

M

N

O

P

C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Description

INFOID:000000006202909

ABS unit is continuously monitoring ECU hardware and software for correct operation.

DTC Logic

INFOID:000000006202910

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1110	CONTROLLER FAILURE	Possible internal failure of control unit components.	Internal failure of control unit components. ABS solenoid valve or motor power supply/ ground abnormality.

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

1. Check both ABS solenoid valve and motor supply and ground circuits using a suitable electrical load.
2. Check wheel speed sensor inputs.
3. Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results

CONTROLLER FAILURE

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-26. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006202911

1. REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

CAUTION:

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

>> Replace ABS actuator and electric unit (control unit).

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

Description

INFOID:000000006202912

PUMP

The pump returns the brake fluid stored in the reservoir to the master cylinder by reducing the pressure.

MOTOR

The motor drives the pump according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006202913

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1111	PUMP MOTOR	During the actuator motor operating with ON, when the actuator motor turns OFF, or when the control line for actuator motor relay is open.	<ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit)
		During the actuator motor operating with OFF, when the actuator motor turns ON, or when the control line for relay is shorted to ground.	

A
B
C
D
E
BRC

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
PUMP MOTOR

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-27, "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006202914

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnect, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
- NO >> Poor connection of connector terminal. Replace or repair connector.

2. CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between the ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	1	Ground	Battery voltage

4. Reconnect ABS actuator and electric unit (control unit) connector.

G
H
I
J
K
L
M
N
O
P

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3.ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 1 and 2. With ignition switch ON check bulb illuminates correctly.

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Check both power supply and ground circuit.

4.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
NO >> Repair or replace malfunctioning components. (Check ABS each bolt for tightness and corrosion).

Component Inspection

INFOID:000000006202915

1.CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and "ABS MOTOR" in order with CONSULT-III.
2. Select "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY (Note)	On	On

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Go to diagnosis procedure. Refer to [BRC-27. "Diagnosis Procedure"](#).

C1113 G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

C1113 G SENSOR

Description

INFOID:000000006202916

G sensor detects G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

DTC Logic

INFOID:000000006202917

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1113	G SENSOR	G sensor is malfunctioning, or signal line of G sensor is open or shorted.	<ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit) • G sensor • Electrical interference • Vehicle driven on AWD rolling road

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
G SENSOR

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-29. "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006202918

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect G sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
 NO >> Poor connection of connector terminal. Replace or repair connector.

2.CHECK G SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect G sensor connector.
4. Check continuity between G sensor harness connector terminals and ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit)		G sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	13	B32	2	Existed
	29		3	
	14		4	
	28		5	

C1113 G SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace malfunctioning components.

3.CHECK G SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between G sensor harness connector terminal and ground.

G sensor		—	Condition	Voltage
Connector	Terminal			
B32	1	Ground	Ignition switch: ON	Battery voltage
			Ignition switch: OFF	Approx. 0 V

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace malfunctioning components.

4.CHECK G SENSOR

1. Remove G sensor from the vehicle. Refer to [BRC-71, "Exploded View"](#).
2. Connect the following terminals between G sensor and connector.

G sensor	Harness connector	
Terminal	Connector	Terminal
1	B32	1
2		2
3		3
4		4
5		5

3. Turn ignition switch ON.
4. Check voltage between G sensor terminals.

Condition	G sensor	
	Terminals 4 – 5	Terminals 3 – 5
Horizontal	1.50 – 1.95 V	1.50 – 1.95 V
Longitudinally 20°	3.51 – 4.14 V	3.51 – 4.14 V
Longitudinally 40°	1.50 – 1.95 V	3.51 – 4.14 V

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
 NO >> Replace G sensor.

Component Inspection

INFOID:000000006202919

1.CHECK DATA MONITOR

Select "ABS", "DATA MONITOR", "DECEL G-SEN1" and "DECEL G-SEN2", in order with CONSULT-III" and check G sensor signal.

Monitor item	Condition	DATA MONITOR
DECEL G-SEN1	Changes according to an indication shown by the decel G sensor	On
		Off
DECEL G-SEN2	Changes according to an indication shown by the decel G sensor	On
		Off

C1113 G SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-29. "Diagnosis Procedure"](#).

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

C1115 WHEEL SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

C1115 WHEEL SENSOR

Description

INFOID:000000006202920

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006202921

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1115	ABS SENSOR [ABNORMAL SIGNAL]	Miss-match between the 4 wheel speed sensor signals.	Harness or connector not a possible cause. Other possible causes tire radius (due to wrong size or pressure) interference.

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results

ABS SENSOR [ABNORMAL SIGNAL]

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-32. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006202922

CAUTION:

Never check between wheel sensor terminals.

1.CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

- YES >> GO TO 2.
NO >> Adjust air pressure, or replace tire.

2.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check that there is no deformation, misalignment, float, and backlash on the wheel sensor and wheel sensor mounting surface.
- Check that the wheel sensor is installed with no misalignment and backlash.

Are the sensor and sensor rotor normal?

- YES >> GO TO 3.
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

3.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 4.

C1115 WHEEL SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Poor connection of connector terminal. Repair or replace connector.

4.CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	12	E39 (Front RH)	4	Existed
	27	E22 (Front LH)	2	
	15	B41 (Rear RH)	8	
	30	B44 (Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	E39 (Front RH)	3	Existed
	23	E22 (Front LH)	1	
	11	B41 (Rear RH)	7	
	26	B44 (Rear LH)	5	

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)		Connector	Terminal	Continuity
Connector	Terminal			
E36	12, 21	E36	3, 4	Not existed
	27, 23			
	15, 11			
	30, 26			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.

CAUTION:

Never start engine.

5. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1115" detected?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> INSPECTION END

Component Inspection

INFOID:000000006202923

1.CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR", and check the vehicle speed.

C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ($\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-32, "Diagnosis Procedure"](#).

C1120, C1122, C1124, C1126 IN ABS SOL

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

C1120, C1122, C1124, C1126 IN ABS SOL

Description

INFOID:000000006202924

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006202925

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1120	FR LH IN ABS SOL	When the control unit detects a malfunction in the front LH inlet solenoid circuit.	ABS actuator and electric unit (control unit)
C1122	FR RH IN ABS SOL	When the control unit detects a malfunction in the front RH inlet solenoid circuit.	
C1124	RR LH IN ABS SOL	When the control unit detects a malfunction in the rear LH inlet solenoid circuit.	
C1126	RR RH IN ABS SOL	When the control unit detects a malfunction in the rear RH inlet solenoid circuit.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
FR LH IN ABS SOL
FR RH IN ABS SOL
RR LH IN ABS SOL
RR RH IN ABS SOL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-35. "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006202926

1. CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

- YES >> GO TO 2.
- NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

2. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.
- NO >> Poor connection of connector terminal. Replace or repair connector.

C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

3. CHECK ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace malfunctioning components.

4. CHECK ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
 NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000006202927

1. CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and each test item in order with CONSULT-III.
2. On the display, select "Up", "Keep" and "Down", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*

*: On for 1 to 2 seconds after the select, and then Off.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Go to diagnosis procedure. Refer to [BRC-35, "Diagnosis Procedure"](#).

C1121, C1123, C1125, C1127 OUT ABS SOL

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

C1121, C1123, C1125, C1127 OUT ABS SOL

Description

INFOID:000000006202928

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006202929

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1121	FR LH OUT ABS SOL	When the control unit detects a malfunction in the front LH outlet solenoid circuit.	ABS actuator and electric unit (control unit)
C1123	FR RH OUT ABS SOL	When the control unit detects a malfunction in the front RH outlet solenoid circuit.	
C1125	RR LH OUT ABS SOL	When the control unit detects a malfunction in the rear LH outlet solenoid circuit.	
C1127	RR RH OUT ABS SOL	When the control unit detects a malfunction in the rear RH outlet solenoid circuit.	

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
FR LH OUT ABS SOL
FR RH OUT ABS SOL
RR LH OUT ABS SOL
RR RH OUT ABS SOL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-37. "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006202930

1.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

- YES >> GO TO 2.
- NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.
- NO >> Poor connection of connector terminal. Replace or repair connector.

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

3. CHECK ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

4. CHECK ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000006202931

1. CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and each test item in order with CONSULT-III.
2. On the display, select "Up", "Keep" and "Down", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*

*: On for 1 to 2 seconds after the select, and then Off.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-37, "Diagnosis Procedure"](#).

C1140 ACTUATOR RELAY SYSTEM

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

C1140 ACTUATOR RELAY SYSTEM

Description

INFOID:000000006202932

Activates or deactivates each solenoid valve according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006202933

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1140	ACTUATOR RLY	During the actuator relay operating with OFF, when the actuator relay turns ON, or when the control line for the relay is shorted to the ground.	<ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)
		During the actuator relay operating with ON, when the actuator relay turns ON, or when the control line for the relay is open.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
ACTUATOR RLY

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-39, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006202934

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Replace or repair connector.

2. CHECK ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

4. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

C1140 ACTUATOR RELAY SYSTEM

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

3. ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 1 and 3. With ignition switch ON check bulb illuminates correctly.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components. (Check ABS each bolt for tightness and corrosion).

Component Inspection

INFOID:000000006202935

1. CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and "ABS MOTOR" in order with CONSULT-III,
2. Select "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY (Note)	On	On

NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-39. "Diagnosis Procedure"](#).

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

U1000 CAN COMM CIRCUIT

Description

INFOID:000000006202936

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000006202937

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or more.	<ul style="list-style-type: none">CAN communication lineABS actuator and electric unit (control unit)

BRC

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
CAN COMM CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-41, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006202938

1.CHECK CONNECTOR

- Turn ignition switch OFF.
- Disconnect ABS actuator and electric unit (control unit) connector.
- Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
- Reconnect connector and perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
CAN COMM CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Go to [LAN-15, "Trouble Diagnosis Flow Chart"](#).
NO >> INSPECTION END

U1010 CONTROL UNIT (CAN)

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000006202939

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000006202940

DTC DETECTION LOGIC

DTC	Items	Diagnostic item is detected when...	Possible cause
U1010	CONTROL UNIT (CAN)	When detecting error during the initial diagnosis of CAN controller of ABS actuator and electric unit (control unit).	ABS actuator and electric unit (control unit) error

DTC CONFIRMATION PROCEDURE

1. RECHECK DTC

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "U1010" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-42. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006202941

1. ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Check that there is no malfunction in ABS actuator and electric unit (control unit) harness connector or disconnection.

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
NO >> Repair or replace the harnesses and connectors.

BRAKE FLUID LEVEL SWITCH

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

BRAKE FLUID LEVEL SWITCH

Description

INFOID:000000006202942

The brake fluid level switch converts the brake fluid level to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

Component Function Check

INFOID:000000006202943

1. CHECK BRAKE FLUID LEVEL SWITCH OPERATION

Operate the brake fluid level switch. Then check that the brake warning lamp in the combination meter turns on/off correctly.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-43, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006202944

1. CHECK BRAKE FLUID LEVEL

Check brake fluid level. Refer to [BR-12, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refill brake fluid. Refer to [BR-12, "Refilling"](#).

2. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector and combination meter connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform component function check. Refer to [BRC-43, "Component Function Check"](#).

Is the inspection result normal?

YES >> Poor connection of connector terminal. Replace or repair connector.

NO >> GO TO 3.

3. CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

Brake fluid level switch		Condition	Continuity
Connector	Terminal		
E37	1 – 2	When brake fluid is full in the reservoir tank.	Not existed
		When brake fluid is empty in the reservoir tank.	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Brake fluid level switch is malfunction. Replace reservoir tank.

4. CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between brake fluid level switch harness connector terminals and combination meter harness connector terminal and/or ground.

BRAKE FLUID LEVEL SWITCH

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

Combination meter		Brake fluid level switch		Continuity
Connector	Terminal	Connector	Terminal	
M34	27	E37	1	Existed

Combination meter		—	Continuity
Connector	Terminal		
M34	27	Ground	Not existed

Brake fluid level switch		—	Continuity
Connector	Terminal		
E37	2	Ground	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000006202945

1. CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

Brake fluid level switch		Condition	Continuity
Connector	Terminal		
E37	1 – 2	When brake fluid is full in the reservoir tank.	Not existed
		When brake fluid is empty in the reservoir tank.	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace reservoir tank.

PARKING BRAKE SWITCH

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

PARKING BRAKE SWITCH

Description

INFOID:000000006202946

The parking brake switch converts the status of the parking brake pedal to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

Component Function Check

INFOID:000000006202947

1.CHECK PARKING BRAKE SWITCH OPERATION

Operate the parking brake pedal. Then check that the brake warning lamp in the combination meter turns on/off correctly.

Condition	Brake warning lamp illumination status
When the parking brake switch is operation	ON
When the parking brake switch is not operation.	OFF

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-45, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006202948

1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch connector terminal and ground.

Parking brake switch		Condition	Continuity
Connector	Terminal		
E103	1 – Ground	When the parking brake switch is operated.	Existed
		When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace parking brake switch.

2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-27, "CONSULT-III Function"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace combination meter.

Component Inspection

INFOID:000000006202949

1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch connector terminal and ground.

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

Parking brake switch		Condition	Continuity
Connector	Terminal		
E103	1 – Ground	When the parking brake switch is operated.	Existed
		When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch. Refer to [PB-6, "Exploded View"](#).

ABS WARNING LAMP

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

ABS WARNING LAMP

Description

INFOID:000000006202950

x: ON –: OFF

Condition	ABS warning lamp
Ignition switch OFF	–
For 1 second after turning ignition switch ON	x
1 second later after turning ignition switch ON	–
ABS function is malfunctioning.	x
EBD function is malfunctioning.	x

Component Function Check

INFOID:000000006202951

1.CHECK ABS WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-47, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006202952

1.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-27, "CONSULT-III Function"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

BRAKE WARNING LAMP

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

BRAKE WARNING LAMP

Description

INFOID:000000006202953

×: ON –: OFF

Condition	Brake warning lamp (Note 1)
Ignition switch OFF	–
For 1 second after turning ignition switch ON	× (Note 2)
1 second later after turning ignition switch ON	× (Note 2)
EBD function is malfunctioning.	×

NOTE:

- 1: Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- 2: After starting engine, brake warning lamp is turned off.

Component Function Check

INFOID:000000006202954

1. BRAKE WARNING LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to diagnosis procedure. Refer to [BRC-48, "Diagnosis Procedure"](#).

2. BRAKE WARNING LAMP OPERATION CHECK 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check parking brake switch. Refer to [BRC-45, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006202955

1. CHECK PARKING BRAKE SWITCH

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking brake switch. Refer to [BRC-45, "Diagnosis Procedure"](#).

2. CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check items displayed by self-diagnosis.

3. CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-27, "CONSULT-III Function"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[ABS]

ECU DIAGNOSIS INFORMATION

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Reference Value

INFOID:000000006202956

VALUES ON THE DIAGNOSIS TOOL

CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short-circuited.

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
FR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
FR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
RR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
RR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
STOP LAMP SW	Stop lamp switch signal status	When brake pedal is depressed	On
		When brake pedal is not depressed	Off
BATTERY VOLT	Battery voltage supplied to the ABS actuator and electric unit (control unit)	Ignition switch ON	10 – 16 V
DECEL G-SEN1 (Note 2)	Decel G detected by decel G sensor	Changes according to an indication shown by the decel G sensor	On
			Off
DECEL G-SEN2 (Note 2)	Decel G detected by decel G sensor	Changes according to an indication shown by the decel G sensor	On
			Off
FR RH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR RH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[ABS]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
FR LH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR LH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR RH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR RH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR LH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR LH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
MOTOR RELAY	Motor and motor relay operation	When the motor relay and motor are operating	On
		When the motor relay and motor are not operating	Off
ACTUATOR RLY (Note 3)	Actuator relay operation	When the actuator relay is operating	On
		When the actuator relay is not operating	Off
ABS WARN LAMP	ABS warning lamp (Note 4)	When ABS warning lamp is ON	On
		When ABS warning lamp is OFF	Off
EBD SIGNAL	EBD operation	EBD is active	On
		EBD is inactive	Off
ABS SIGNAL	ABS operation	ABS is active	On
		ABS is inactive	Off
EBD FAIL SIG	EBD fail-safe signal	In EBD fail-safe	On
		EBD is normal	Off

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[ABS]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
ABS FAIL SIG	ABS fail-safe signal	In ABS fail-safe	On
		ABS is normal	Off

NOTE:

- 1: Confirm tire pressure is normal.
- 2: Only AWD models.
- 3: Every 20 seconds momentary switch to Off.
- 4: On and off timing for warning lamp and indicator lamp.
- ABS warning lamp: Refer to [BRC-47, "Description"](#).

A
B
C
D
E

G
H
I
J
K
L
M
N
O
P

BRC


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[ABS]

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram -BRAKE CONTROL SYSTEM-

INFOID:000000006202957



2008/07/15

JCFWM0259GB


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[ABS]

BRAKE CONTROL SYSTEM (WITHOUT VDC)

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	TF80MW-ZS16-TM4



Connector No.	B41
Connector Name	REAR WHEEL SENSOR RH
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	
5	L	
8	R	
9	Y	
12	BR	
13	O	
22	G	-- [For Mexico]
22	SB	-- [Except for Mexico]
23	SB	-- [For Mexico]
23	G	-- [Except for Mexico]
51	GR	
52	SHIELD	
53	L	
54	B	
62	Y	
63	R	
96	G	

50	G	
51	L	
52	P	
55	O	
56	SB	
57	V	
58	LG	
59	BR	
60	SB	
61	R	


Connector No.	E22
Connector Name	FRONT WHEEL SENSOR LH
Connector Type	RK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	
2	P	

Terminal No.	5
Color of Wire	BR
Terminal No.	6
Color of Wire	G

Connector No.	E36
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	RI28FB-NM4-DH



Terminal No.	53
Color of Wire	52
Terminal No.	61
Color of Wire	60
Terminal No.	59
Color of Wire	58
Terminal No.	57
Color of Wire	56
Terminal No.	55
Color of Wire	54

Connector No.	E15
Connector Name	POWER INTELLENT POWER DISTRIBUTION MODULE (POWER ROOM)
Connector Type	NS16FW-CS



11	O	RR SENSOR VB
12	R	FR SENSOR SIG
13	B	G CHECK
14	L	G SW 1
15	SB	RR SENSOR SIG
16	BR	IGN
20	Y	AMD COMM
21	G	FR SENSOR VB
22	L	CAN H
23	W	FL SENSOR VB
24	GR	DIAG K
26	BR	RL SENSOR VB
27	P	FL SENSOR SIG
28	Y	G GND
29	R	G SW 2
30	G	RL SENSOR SIG

Connector No.	E37
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	YV02FGY



Terminal No.	1
Color of Wire	LG
Terminal No.	2
Color of Wire	B

Terminal No.	1
Color of Wire	LG
Terminal No.	2
Color of Wire	B

Connector No.	E39
Connector Name	FRONT WHEEL SENSOR RH
Connector Type	RK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	IGN
2	B	GST
3	R	GS 2
4	L	GS 1
5	Y	GND

Terminal No.	3
Color of Wire	G
Terminal No.	4
Color of Wire	R

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	MOTOR
2	BR	ACTR
3	B	GND A
4	B	GND M
5	BR	VDC OFF SW
6	GR	ASCD CANCEL SW
8	SB	STOP LAMP SW
9	P	CAN L

JCFWM0674GB

A B C D E G H I J K L M N O P

BRC


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >


[ABS]

BRAKE CONTROL SYSTEM (WITHOUT VDC)

Connector No.	E101
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
2	L	-
3	R	-
4	Y	-
5	BR	-
6	O	-
7	GR	-
8	SB	-
9	GR	-
10	SHIELD	-
11	L	-
12	B	-
13	Y	-
14	R	-
15	O	-
16	O	-

Connector No.	E103
Connector Name	PARKING BRAKE SWITCH
Connector Type	P01FB-A



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-


Terminal No.	Color of Wire	Signal Name [Specification]
80	Y	-
81	W	-
82	O	-
83	L	-
84	BR	-
85	R	-
86	GR	-
87	O	-
88	BR	-
89	W	-
90	GR	-
91	R	-
92	O	-
93	BR	-
94	W	-
95	BR	-
96	GR	-
97	G	-
98	SB	-
99	SB	-
100	L	-

Connector No.	E115
Connector Name	STOP LAMP SWITCH
Connector Type	IM04FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	Y	-
3	G	-
4	L	-


Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
4	B	-

5	B	-
6	L	-
7	O	-
8	W	-
14	P	-
16	V	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH04FW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	BATTERY POWER SUPPLY
2	O	IGNITION SIGNAL
3	B	GROUND
4	B	GROUND
5	BR	A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL
7	GR	OVERDRIVE CONTROL SWITCH SIGNAL
9	L	PADDLE SHIFTER SHIFT UP SIGNAL
10	G	PADDLE SHIFTER SHIFT DOWN SIGNAL
13	Y	ILLUMINATION CONTROL SIGNAL
15	LG	AIR BAG SIGNAL
16	O	ENGINE COOLANT TEMPERATURE SIGNAL
19	BR	AMBIENT SENSOR SIGNAL
20	SB	AMBIENT SENSOR GROUND
21	L	CAN-H
22	P	CAN-L
24	B	FUEL LEVEL SENSOR SIGNAL GROUND
25	SB	ALTERNATOR SIGNAL
26	V	PARKING BRAKE SWITCH SIGNAL
27	BR	BRAKE FLUID LEVEL SWITCH SIGNAL
28	B	SECURITY SIGNAL
29	W	WASHER LEVEL SWITCH SIGNAL
30	Y	VEHICLE SPEED SIGNAL (2-PULSE)
31	L	VEHICLE SPEED SIGNAL (8-PULSE)
34	G	FUEL LEVEL SENSOR SIGNAL
35	O	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
36	G	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)
37	P	NON-MANUAL MODE SIGNAL
38	O	MANUAL MODE SHIFT DOWN SIGNAL
39	V	MANUAL MODE SHIFT UP SIGNAL
40	LG	MANUAL MODE SIGNAL

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[ABS]

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

BRAKE CONTROL SYSTEM (WITHOUT VDC)

Connector No.	M77	80	L	-
Connector Name	WIRE TO WIRE	81	W	-
Connector Type	TF80MM-ZS16-TM4	82	B	-
		83	LG	-
		88	BR	-
		89	G	-
		90	GR	-
		91	R	-
		92	L	-
		93	P	-
		94	W	-
		96	BR	-
		97	G	-
		99	SB	-
		100	Y	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	O	-
3	LG	-
4	Y	-
5	Y	-
6	G	-
7	R	-
8	GR	-
9	BR	-
10	L	-
11	GR	-
12	P	-
14	SB	-
15	V	-
19	R	-
20	P	-
21	O	-
22	L	-
24	BR	-
26	W	-
30	L	-
31	W	-
42	O	-
43	SHIELD	-
51	W	-
52	SB	-
53	L	-
54	Y	-
60	O	-
61	BR	-
62	G	-
63	P	-
69	W	-
70	B	-
71	P	-
72	O	-
76	SB	-
79	V	-

JCFWM0676GB

INFOID:000000006202958

Fail-Safe

ABS, EBD SYSTEM

In case of electrical malfunctions with the ABS, ABS warning lamp will turn ON. In case of electrical malfunctions with the EBD, brake warning lamp, ABS warning lamp will turn ON. Simultaneously, the ABS become one of the following conditions of the fail-safe function.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[ABS]

< ECU DIAGNOSIS INFORMATION >

- For malfunction of ABS, only the EBD is activated and the condition of vehicle is the same condition of vehicles without ABS system.

NOTE:

ABS self-diagnosis sound may be heard. That is a normal condition because a self-diagnosis for "Ignition switch ON" and "The first starting" are being performed.

- For malfunction of EBD, EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without ABS, EBD system.

DTC Index

INFOID:000000006202959

DTC	Items (CONSULT screen terms)	Reference
C1101	RR RH SENSOR-1	BRC-18, "DTC Logic"
C1102	RR LH SENSOR-1	
C1103	FR RH SENSOR-1	
C1104	FR LH SENSOR-1	
C1105	RR RH SENSOR-2	BRC-21, "DTC Logic"
C1106	RR LH SENSOR-2	
C1107	FR RH SENSOR-2	
C1108	FR LH SENSOR-2	
C1109	BATTERY VOLTAGE [ABNORMAL]	BRC-24, "DTC Logic"
C1110	CONTROLLER FAILURE	BRC-26, "DTC Logic"
C1111	PUMP MOTOR	BRC-27, "DTC Logic"
C1113	G SENSOR	BRC-29, "DTC Logic"
C1115	ABS SENSOR [ABNORMAL SIGNAL]	BRC-32, "DTC Logic"
C1120	FR LH IN ABS SOL	BRC-35, "DTC Logic"
C1121	FR LH OUT ABS SOL	BRC-37, "DTC Logic"
C1122	FR RH IN ABS SOL	BRC-35, "DTC Logic"
C1123	FR RH OUT ABS SOL	BRC-37, "DTC Logic"
C1124	RR LH IN ABS SOL	BRC-35, "DTC Logic"
C1125	RR LH OUT ABS SOL	BRC-37, "DTC Logic"
C1126	RR RH IN ABS SOL	BRC-35, "DTC Logic"
C1127	RR RH OUT ABS SOL	BRC-37, "DTC Logic"
C1140	ACTUATOR RLY	BRC-39, "DTC Logic"
U1000	CAN COMM CIRCUIT	BRC-41, "DTC Logic"
U1010	CONTROL UNIT (CAN)	BRC-42, "DTC Logic"

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

[ABS]

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

Diagnosis Procedure

INFOID:000000006202960

1. CHECK START

Check front and rear brake force distribution using a brake tester. Refer to [BR-49, "General Specifications"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

2. CHECK FRONT AND REAR AXLE

Make sure that there is no excessive play in the front and rear axles.

- Front

- 2WD models: Refer to [FAX-8, "Inspection"](#).

- AWD models: Refer to [FAX-32, "Inspection"](#).

- Rear

- 2WD models: Refer to [RAX-4, "Inspection"](#).

- AWD models: Refer to [RAX-11, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3. CHECK WHEEL SENSOR AND SENSOR ROTOR

Check the following.

- Wheel sensor installation for damage.

- Sensor rotor installation for damage.

- Wheel sensor connector connection.

- Wheel sensor harness inspection.

Is the inspection result normal?

YES >> GO TO 4.

NO >>

- Replace wheel sensor or sensor rotor.
- Repair harness.

4. CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned off after the ignition switch is turned ON or when driving.

Is the ABS warning lamp illuminated?

YES >> Perform self-diagnosis for "ABS" with CONSULT-III.

NO >> Normal

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

UNEXPECTED PEDAL REACTION

[ABS]

< SYMPTOM DIAGNOSIS >

UNEXPECTED PEDAL REACTION

Diagnosis Procedure

INFOID:000000006202961

1.CHECK BRAKE PEDAL STROKE

Check brake pedal stroke. Refer to [BR-9, "Inspection and Adjustment"](#).

Is the stroke too large?

- YES >> • Bleed air from brake tube and hose. Refer to [BR-13, "Bleeding Brake System"](#).
• Check brake pedal, brake booster, and master cylinder for mount play, looseness, brake system fluid leakage, etc.
- Brake pedal: Refer to [BR-9, "Inspection and Adjustment"](#).
- Master cylinder: Refer to [BR-14, "Inspection"](#).
- Brake booster: Refer to [BR-15, "Inspection"](#).

NO >> GO TO 2.

2.CHECK FUNCTION

Disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. Check if braking force is normal in this condition. Connect connector after inspection.

Is the inspection result normal?

- YES >> Normal
NO >> Check brake system.

THE BRAKING DISTANCE IS LONG

[ABS]

< SYMPTOM DIAGNOSIS >

THE BRAKING DISTANCE IS LONG

Diagnosis Procedure

INFOID:000000006202962

CAUTION:

The stopping distance on slippery road surfaces might be longer with the ABS operating than when the ABS is not operating.

1.CHECK FUNCTION

Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. In this condition, check stopping distance. After inspection, connect connector.

Is the inspection result normal?

YES >> Normal

NO >> Check brake system.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[ABS]

ABS FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000006202963

CAUTION:

ABS does not operate when speed is 10 km/h (6 MPH) or lower.

1.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp turns OFF after ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis for "ABS" with CONSULT-III.

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

[ABS]

< SYMPTOM DIAGNOSIS >

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

Diagnosis Procedure

INFOID:000000006202964

CAUTION:

Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Inspect the brake pedal.

2. SYMPTOM CHECK 2

Check that there are ABS operation noises when the engine is started.

Do the operation noises occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis for "ABS" with CONSULT-III.

3. SYMPTOM CHECK 3

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Do symptoms occur?

YES >> Check if there is a radio, antenna, antenna lead wire, or wiring close to the control unit. If there is, move it farther away.

NO >> Normal

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[ABS]

NORMAL OPERATING CONDITION

Description

INFOID:000000006202965

Symptom	Result
Slight vibrations are felt on the brake pedal and the operation noises occur, when ABS is activated.	This is a normal condition due to the ABS activation.
Stopping distance is longer than that of vehicles without ABS when the vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.	
The brake pedal vibrates and motor operation noises occur from the engine room, after the engine starts and just after the vehicle starts.	This is a normal, and it is caused by the ABS operation check.

< PRECAUTION >

PRECAUTION

PRECAUTIONS
FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006445157

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

BRC

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR USA AND CANADA : Precaution for Procedure without Cowl Top Cover

INFOID:000000006445159

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



FOR USA AND CANADA : Precaution for Brake System

INFOID:000000006202968

WARNING:

Clean any dust from the front brake and rear brake with a vacuum dust collector. Never blow with compressed air.

- Brake fluid use refer to [MA-15, "FOR NORTH AMERICA : Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.


A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

PRECAUTIONS

[ABS]

< PRECAUTION >

- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crow-foot (A) and torque wrench (B).
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



FOR USA AND CANADA : Precaution for Brake Control

INFOID:000000006202969

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006445158

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- **To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.**
- **Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".**
- **Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.**

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- **When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.**
- **When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.**

PRECAUTIONS


[ABS]

< PRECAUTION >

FOR MEXICO : Precaution for Procedure without Cowl Top Cover

INFOID:000000006445160

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.




FOR MEXICO : Precaution for Brake System

INFOID:000000006445161

WARNING:

Clean any dust from the front brake and rear brake with a vacuum dust collector. Never blow with compressed air.

- Brake fluid use refer to [MA-15. "FOR NORTH AMERICA : Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crow-foot (A) and torque wrench (B).
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



FOR MEXICO : Precaution for Brake Control

INFOID:000000006202973

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

WHEEL SENSOR

< REMOVAL AND INSTALLATION >

[ABS]


REMOVAL AND INSTALLATION

WHEEL SENSOR

FRONT WHEEL SENSOR

FRONT WHEEL SENSOR : Exploded View

INFOID:000000006202974



1. Front LH wheel sensor

A. Yellow line (slant line)

Refer to [GI-4, "Components"](#) for symbol in the figure.

NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

FRONT WHEEL SENSOR : Removal and Installation

INFOID:000000006202975

REMOVAL

Pay attention to the following when removing sensor.

CAUTION:

- Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.
- Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.
- When you see the harness of the wheel sensor from the front side of the vehicle ensure that the yellow lines (A) are not twisted.

INSTALLATION

Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

REAR WHEEL SENSOR


WHEEL SENSOR

[ABS]

< REMOVAL AND INSTALLATION >

REAR WHEEL SENSOR : Exploded View

INFOID:000000006202976



1. Rear LH wheel sensor

A. 2WD models

B. AWD models

Refer to [GI-4, "Components"](#) for symbol in the figure.

NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

REAR WHEEL SENSOR : Removal and Installation

INFOID:000000006202977

REMOVAL

Pay attention to the following when removing sensor.

CAUTION:

- Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.
- Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.

INSTALLATION

Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

SENSOR ROTOR

[ABS]

< REMOVAL AND INSTALLATION >

SENSOR ROTOR

FRONT SENSOR ROTOR

FRONT SENSOR ROTOR : Exploded View

INFOID:000000006202978

Refer to [FAX-10, "Exploded View"](#) (2WD models), [FAX-34, "Exploded View"](#) (AWD models).

FRONT SENSOR ROTOR : Removal and Installation

INFOID:000000006202979

REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [FAX-10, "Removal and Installation"](#) (2WD models), [FAX-34, "Removal and Installation"](#) (AWD models).

INSTALLATION

Sensor rotor cannot be disassembled. Installation the sensor rotor together with hub bearing assembly. Refer to [FAX-10, "Removal and Installation"](#) (2WD models), [FAX-34, "Removal and Installation"](#) (AWD models).

REAR SENSOR ROTOR

REAR SENSOR ROTOR : Exploded View

INFOID:000000006202980

Refer to [RAX-5, "Exploded View"](#) (2WD models), [RAX-13, "Exploded View"](#) (AWD models).

REAR SENSOR ROTOR : Removal and Installation

INFOID:000000006202981

2WD MODELS

Removal

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [RAX-5, "Removal and Installation"](#).

Installation

Sensor rotor cannot be disassembled. Installation the sensor rotor together with hub bearing assembly. Refer to [RAX-5, "Removal and Installation"](#).

AWD MODELS

For removal and installation of sensor rotor, refer to [RAX-16, "Disassembly and Assembly"](#).

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< REMOVAL AND INSTALLATION >

[ABS]

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000006202982



- | | | |
|--|--------------------------------------|--|
| 1. ABS actuator and electric unit (control unit) | 2. Connector | 3. Bracket |
| A. To front LH brake caliper | B. To rear RH brake caliper | C. To Rear LH brake caliper |
| D. To front RH brake caliper | E. From master cylinder primary side | F. From master cylinder secondary side |

← Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

Removal and Installation

INFOID:000000006202983

REMOVAL

CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-13, "Bleeding Brake System"](#).

1. Remove cowl top. Refer to [EXT-20, "Exploded View"](#).
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Loosen brake tube flare nuts, then remove brake tubes from ABS actuator and electric unit (control unit).
4. Remove tire (front LH side).
5. Remove fender protector (rear): (front LH side). Refer to [EXT-22, "Exploded View"](#).
6. Remove ABS actuator and electric unit (control unit) bracket mounting nut.
7. Remove ABS actuator and electric unit (control unit) from vehicle.

INSTALLATION

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[ABS]

< REMOVAL AND INSTALLATION >

Note the following, and install in the reverse order of removal.

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-13. "Bleeding Brake System"](#).
- After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.

G SENSOR


< REMOVAL AND INSTALLATION >

[ABS]

G SENSOR

Exploded View

INFOID:000000006202984



1. G sensor
2. Bracket

↔ Vehicle front

Refer to [GI-4. "Components"](#) for symbol in the figure.

Removal and Installation

INFOID:000000006202985

REMOVAL

CAUTION:

Never drop or strike G sensor, or never use power tool etc., because G sensor is sensitive to the impact.

1. Remove center console assembly. Refer to [IP-22. "Exploded View"](#).
2. Disconnect G sensor harness connector.
3. Remove mounting nuts. Remove G sensor.

INSTALLATION

Note the following, and install in the reverse order of removal.

- Never drop or strike G sensor, or never use power tool etc., because G sensor is sensitive to the impact.

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000006202986

PRECAUTIONS FOR DIAGNOSIS


If steering angle sensor, steering system parts, suspension system parts, ABS actuator and electric unit (control unit) or tires have been replaced, or if wheel alignment has been adjusted, be sure to adjust neutral position of steering angle sensor before driving. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

OVERALL SEQUENCE



A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DETAILED FLOW

1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis worksheet. Refer to [BRC-75, "Diagnostic Work Sheet"](#).

>> GO TO 2.

DIAGNOSIS AND REPAIR WORKFLOW

[VDC/TCS/ABS]

< BASIC INSPECTION >

2. PERFORM THE SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III. Refer to [BRC-94, "CONSULT-III Function"](#).

Is there any DTC displayed?

- YES >> GO TO 3.
- NO >> GO TO 4.

3. PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC of "ABS" with CONSULT-III. Refer to [BRC-161, "DTC Index"](#).

>> GO TO 7.

4. CHECK THE SYMPTOM THAT IS NOT CONSIDERED A SYSTEM MALFUNCTION

Check that the symptom is a normal operation that is not considered a system malfunction. Refer to [BRC-169, "Description"](#).

Is the symptom a normal operation?

- YES >> INSPECTION END
- NO >> GO TO 5.

5. CHECK THE WARNING LAMP AND INDICATOR LAMP FOR ILLUMINATION

Check that the warning lamp and indicator lamp illuminate.

- ABS warning lamp: Refer to [BRC-147, "Description"](#).
- Brake warning lamp: Refer to [BRC-148, "Description"](#).
- VDC OFF indicator lamp: Refer to [BRC-150, "Description"](#).
- SLIP indicator lamp: Refer to [BRC-152, "Description"](#).

Is ON/OFF timing normal?

- YES >> GO TO 6.
- NO >> GO TO 2.

6. PERFORM THE DIAGNOSIS BY SYMPTOM

Perform the diagnosis applicable to the displayed DTC of "ABS" with CONSULT-III.

>> GO TO 7.

7. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 8.

8. MEMORY CLEAR

Perform self-diagnosis memory clear for "ABS" with CONSULT-III.

>> GO TO 9.

9. FINAL CHECK

Perform the self-diagnosis again, and check that the malfunction is repaired completely.

Is no other DTC present and the repair completed?

- YES >> INSPECTION END
- NO >> GO TO 3.

DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

Diagnostic Work Sheet

INFOID:000000006202987

Customer name MR/MS	Model & Year	VIN	
Engine #	Trans.	Mileage	
Incident Date	Manuf. Date	In Service Date	
Symptoms	<input type="checkbox"/> Noise and vibration (from engine compartment) <input type="checkbox"/> Noise and vibration (from axle)	<input type="checkbox"/> Warning / Indicator activate	<input type="checkbox"/> Firm pedal operation Large stroke pedal operation
	<input type="checkbox"/> TCS does not work (Rear wheels slip when accelerating)	<input type="checkbox"/> ABS does not work (Wheels lock when braking)	<input type="checkbox"/> Lack of sense of acceleration
Engine conditions	<input type="checkbox"/> When starting <input type="checkbox"/> After starting		
Road conditions	<input type="checkbox"/> Low friction road (<input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other) <input type="checkbox"/> Bumps / potholes		
Driving conditions	<input type="checkbox"/> Full-acceleration <input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped		
Applying brake conditions	<input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually		
Other conditions	<input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Shift change <input type="checkbox"/> Other descriptions		

SFIA3265E

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[VDC/TCS/ABS]

INSPECTION AND ADJUSTMENT

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description

INFOID:000000006202988

In case of doing work that applies to the list below, make sure to adjust neutral position of steering angle sensor before running vehicle.

×: Required –: Not required

Situation	Adjustment of steering angle sensor neutral position
Removing/Installing steering angle sensor	×
Replacing steering angle sensor	×
Removing/Installing steering wheel	×
Replacing steering wheel	×
Removing/Installing steering components	×
Replacing steering components	×
Removing/Installing suspension components	×
Replacing suspension components	×
Change tires to new ones	—
Tire rotation	—
Adjusting wheel alignment	×

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement

INFOID:000000006202989

ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

CAUTION:

To adjust neutral position of steering angle sensor, make sure to use CONSULT-III (Adjustment cannot be done without CONSULT-III)

1. ALIGN THE VEHICLE STATUS

Stop vehicle with front wheels in straight-ahead position.

>> GO TO 2.

2. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR

1. Select "ABS", "WORK SUPPORT" and "ST ANGLE SENSOR ADJUSTMENT" in order with CONSULT-III.
2. Select "START".

CAUTION:

Never touch steering wheel while adjusting steering angle sensor.

3. After approximately 10 seconds, select "END".

NOTE:

After approximately 60 seconds, it ends automatically.

4. Turn ignition switch OFF, then turn it ON again.

CAUTION:

Be sure to perform above operation.

>> GO TO 3.

3. CHECK DATA MONITOR

1. Run vehicle with front wheels in straight-ahead position, then stop.
2. Select "ABS", "DATA MONITOR" and "STR ANGLE SIG" in order with CONSULT-III, and check steering angle sensor signal.

STR ANGLE SIG : 0±2.5°

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[VDC/TCS/ABS]

Is the steering angle within the specified range?

YES >> GO TO 4.

NO >> Perform the neutral position adjustment for the steering angle sensor again, GO TO 1.

4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memories for "ABS" and "ENGINE" with CONSULT-III.

- "ABS": Refer to [BRC-94, "CONSULT-III Function"](#).
- "ENGINE"
 - For CALIFORNIA: Refer to [EC-116, "CONSULT-III Function"](#).
 - For USA (FEDERAL) and CANADA: Refer to [EC-597, "CONSULT-III Function"](#).
 - For MEXICO: Refer to [EC-1029, "CONSULT-III Function"](#).

Are the memories erased?

YES >> INSPECTION END

NO >> Check the items indicated by the self-diagnosis.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P


BRC

SYSTEM DESCRIPTION

VDC

System Diagram

INFOID:000000006202990



System Description


INFOID:000000006202991

- Vehicle Dynamics Control system detects driver's steering operation amount and brake pedal travel from steering angle sensor and pressure sensor. Using information from yaw rate/side/decel G sensor and wheel sensor, VDC judges driving condition (conditions of under steer and over steer) to improve vehicle driving stability by controlling brake application to 4 wheels and engine output.
- During VDC operation, it informs driver of system operation by flashing SLIP indicator lamp.
- Electrical system diagnosis by CONSULT-III is available.

Component Parts Location

INFOID:000000006202992

FOR USA




A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

- | | | |
|--|------------------------------------|---------------------------------|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Yaw rate/side/decel G sensor |
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor | 9. VDC OFF switch |
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (AWD models) | |

< SYSTEM DESCRIPTION >

- A. Back of spiral cable assembly
- B. Combination meter
- C. Center console
- D. Engine room (right side)
- E. Steering knuckle
- F. Instrument driver lower panel
- G. Rear axle

EXCEPT FOR USA



- 1. Steering angle sensor
- 2. ABS warning lamp
- 3. Brake warning lamp
- 4. VDC OFF indicator lamp
- 5. SLIP indicator lamp
- 6. Yaw rate/side/decel G sensor

VDC

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- | | | |
|--|------------------------------------|----------------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor | 9. VDC OFF switch |
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (AWD models) | |
| A. Back of spiral cable assembly | B. Combination meter | C. Center console |
| D. Engine room (right side) | E. Steering knuckle | F. Instrument driver lower panel |
| G. Rear axle | | |

Component Description

INFOID:000000006202993


Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	BRC-109, "Description"
	Motor	
	Actuator relay (Main relay)	BRC-128, "Description"
	Solenoid valve	BRC-121, "Description"
	VDC switch-over valve (CV1, CV2)	BRC-135, "Description"
	VDC switch-over valve (SV1, SV2)	BRC-137, "Description"
Wheel sensor		BRC-99, "Description"
Yaw rate/side/decel G sensor		BRC-111, "Description"
Steering angle sensor		BRC-130, "Description"
VDC OFF switch		BRC-145, "Description"
ABS warning lamp		BRC-147, "Description"
Brake warning lamp		BRC-148, "Description"
VDC OFF indicator lamp		BRC-150, "Description"
SLIP indicator lamp		BRC-152, "Description"

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

TCS

System Diagram

INFOID:000000006202994



System Description

INFOID:000000006202995


- Traction Control System is a function that electronically controls engine torque, brake fluid pressure and CVT shift position to ensure the optimum slippage ratio at drive wheels by computing wheel speed signals from 4 wheel sensors. When ABS actuator and electric unit (control unit) detects a spin at drive wheels (rear wheels), it compares wheel speed signals from all 4 wheels. At this time, LH and RH rear brake fluid pressure are controlled, while fuel being cut to engine and throttle valve being closed to reduce engine torque by the control unit. Further more, throttle position is continuously controlled to ensure the optimum engine torque at all times.
- During TCS operation, it informs driver of system operation by flashing SLIP indicator lamp.
- Electrical system diagnosis by CONSULT-III is available.

Component Parts Location

INFOID:000000006444599

FOR USA

TCS



- | | | |
|--|------------------------------------|---------------------------------|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Yaw rate/side/decel G sensor |
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor | 9. VDC OFF switch |
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (AWD models) | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


TCS

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- | | | |
|----------------------------------|----------------------|----------------------------------|
| A. Back of spiral cable assembly | B. Combination meter | C. Center console |
| D. Engine room (right side) | E. Steering knuckle | F. Instrument driver lower panel |
| G. Rear axle | | |

EXCEPT FOR USA



- | | | |
|---------------------------|------------------------|---------------------------------|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Yaw rate/side/decel G sensor |

JPFIC0226ZZ

TCS

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- | | | |
|--|------------------------------------|----------------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor | 9. VDC OFF switch |
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (AWD models) | |
| A. Back of spiral cable assembly | B. Combination meter | C. Center console |
| D. Engine room (right side) | E. Steering knuckle | F. Instrument driver lower panel |
| G. Rear axle | | |

Component Description

INFOID:000000006202997


Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	BRC-109, "Description"
	Motor	
	Actuator relay (Main relay)	BRC-128, "Description"
	Solenoid valve	BRC-121, "Description"
	VDC switch-over valve (CV1, CV2)	BRC-135, "Description"
	VDC switch-over valve (SV1, SV2)	BRC-137, "Description"
Wheel sensor		BRC-99, "Description"
Yaw rate/side/decel G sensor		BRC-111, "Description"
Steering angle sensor		BRC-130, "Description"
VDC OFF switch		BRC-145, "Description"
ABS warning lamp		BRC-147, "Description"
Brake warning lamp		BRC-148, "Description"
VDC OFF indicator lamp		BRC-150, "Description"
SLIP indicator lamp		BRC-152, "Description"

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS

System Diagram

INFOID:000000006202998



System Description

INFOID:000000006202999

- Anti-Lock Braking System is a function that detects wheel revolution while braking, electronically controls braking force, and prevents wheel locking during sudden braking. It improves handling stability and maneuverability for avoiding obstacles.
- Electrical system diagnosis by CONSULT-III is available.

Component Parts Location


INFOID:000000006444600

FOR USA

ABS

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]



- | | | |
|--|------------------------------------|---------------------------------|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Yaw rate/side/decel G sensor |
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor | 9. VDC OFF switch |
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (AWD models) | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


ABS

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- | | | |
|----------------------------------|----------------------|----------------------------------|
| A. Back of spiral cable assembly | B. Combination meter | C. Center console |
| D. Engine room (right side) | E. Steering knuckle | F. Instrument driver lower panel |
| G. Rear axle | | |

EXCEPT FOR USA



- | | | |
|---------------------------|------------------------|---------------------------------|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Yaw rate/side/decel G sensor |

JPFIC0226ZZ

ABS

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

- | | | |
|--|------------------------------------|----------------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor | 9. VDC OFF switch |
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (AWD models) | |
| A. Back of spiral cable assembly | B. Combination meter | C. Center console |
| D. Engine room (right side) | E. Steering knuckle | F. Instrument driver lower panel |
| G. Rear axle | | |

Component Description

INFOID:000000006203001


Component parts	Reference	
ABS actuator and electric unit (control unit)	Pump	BRC-109, "Description"
	Motor	
	Actuator relay (Main relay)	BRC-128, "Description"
	Solenoid valve	BRC-121, "Description"
	VDC switch-over valve (CV1, CV2)	BRC-135, "Description"
	VDC switch-over valve (SV1, SV2)	BRC-137, "Description"
Wheel sensor	BRC-99, "Description"	
Yaw rate/side/decel G sensor	BRC-111, "Description"	
Steering angle sensor	BRC-130, "Description"	
VDC OFF switch	BRC-145, "Description"	
ABS warning lamp	BRC-147, "Description"	
Brake warning lamp	BRC-148, "Description"	
VDC OFF indicator lamp	BRC-150, "Description"	
SLIP indicator lamp	BRC-152, "Description"	

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

EBD

System Diagram

INFOID:000000006203002



System Description

INFOID:000000006203003

- Electric Brake force Distribution is a following function. ABS actuator and electric unit (control unit) detects subtle slippages between the front and rear wheels during braking. Then is electronically controls the rear braking force (brake fluid pressure) to reducing and reduces rear wheel slippage. Accordingly it improves vehicle stability.
- Electrical system diagnosis by CONSULT-III is available.

Component Parts Location


INFOID:000000006444601

FOR USA

EBD

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]



- | | | |
|--|------------------------------------|---------------------------------|
| 1. Steering angle sensor | 2. ABS warning lamp | 3. Brake warning lamp |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Yaw rate/side/decel G sensor |
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor | 9. VDC OFF switch |
| 10. Rear wheel sensor (2WD models) | 11. Rear wheel sensor (AWD models) | |

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


EBD

[VDC/TCS/ABS]

< SYSTEM DESCRIPTION >

- A. Back of spiral cable assembly
- B. Combination meter
- C. Center console
- D. Engine room (right side)
- E. Steering knuckle
- F. Instrument driver lower panel
- G. Rear axle

EXCEPT FOR USA



- 1. Steering angle sensor
- 2. ABS warning lamp
- 3. Brake warning lamp
- 4. VDC OFF indicator lamp
- 5. SLIP indicator lamp
- 6. Yaw rate/side/decel G sensor

JPFIC0226ZZ

< SYSTEM DESCRIPTION >

- 7. ABS actuator and electric unit (control unit)
- 8. Front wheel sensor
- 9. VDC OFF switch
- 10. Rear wheel sensor (2WD models)
- 11. Rear wheel sensor (AWD models)
- A. Back of spiral cable assembly
- B. Combination meter
- C. Center console
- D. Engine room (right side)
- E. Steering knuckle
- F. Instrument driver lower panel
- G. Rear axle

Component Description

INFOID:000000006203005

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	BRC-109, "Description"
	Motor	
	Actuator relay (Main relay)	BRC-128, "Description"
	Solenoid valve	BRC-121, "Description"
	VDC switch-over valve (CV1, CV2)	BRC-135, "Description"
	VDC switch-over valve (SV1, SV2)	BRC-137, "Description"
Wheel sensor		BRC-99, "Description"
Yaw rate/side/decel G sensor		BRC-111, "Description"
Steering angle sensor		BRC-130, "Description"
VDC OFF switch		BRC-145, "Description"
ABS warning lamp		BRC-147, "Description"
Brake warning lamp		BRC-148, "Description"
VDC OFF indicator lamp		BRC-150, "Description"
SLIP indicator lamp		BRC-152, "Description"

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

CONSULT-III Function

INFOID:000000006203006

FUNCTION

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT-III.
Self diagnostic result	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the ABS actuator and electric unit (control unit) can be read.
Active test	Diagnostic test mode is which CONSULT-III drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range.
ECU identification	ABS actuator and electric unit (control unit) part number can be read.

WORK SUPPORT

Item	Description
ST ANGLE SENSOR ADJUSTMENT	Adjusts the neutral position of the steering angle sensor.

SELF DIAGNOSTIC RESULT

Operation Procedure

Before performing the self-diagnosis for "ABS" with CONSULT-III, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.

How to Erase Self-diagnosis Results

After erasing DTC memory for "ABS" with CONSULT-III, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute as the final inspection, and make sure that the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp turn OFF.

CAUTION:

If memory cannot be erased, perform applicable diagnosis.

NOTE:

- When the wheel sensor malfunctions, after inspecting the wheel sensor system, the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp will not turn OFF even when the system is normal unless the vehicle is driving at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
- Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- VDC OFF switch should not stay "ON" position.

Display Item List

Refer to [BRC-161, "DTC Index"](#).

DATA MONITOR MODE

Display Item List

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

×: Applicable ▼: Optional item

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks	
	ECU INPUT SIGNALS	MAIN SIGNALS		
FR LH SENSOR [km/h (MPH)]	×	×	Wheel speed	A
FR RH SENSOR [km/h (MPH)]	×	×		B
RR LH SENSOR [km/h (MPH)]	×	×		C
RR RH SENSOR [km/h (MPH)]	×	×		D
STOP LAMP SW (On/Off)	×	×	Stop lamp switch signal status	E
BATTERY VOLT (V)	×	×	Battery voltage supplied to the ABS actuator and electric unit (control unit)	
GEAR	×	×	Gear position determined by TCM	BRC
OFF SW (On/Off)	×	×	VDC OFF switch	
YAW RATE SEN (d/s)	×	×	Yaw rate detected by yaw rate/side/decel G sensor	G
DECEL G-SEN (G)	×	×	Decel G detected by yaw rate/side/decel G sensor	H
ACCEL POS SIG (%)	×	▼	Throttle actuator opening/closing is displayed (Linked with accelerator pedal)	
SIDE G-SENSOR (m/s ²)	×	▼	Transverse G detected by yaw rate/side/decel G sensor	I
STR ANGLE SIG (°)	×	▼	Steering angle detected by steering angle sensor	J
ENGINE RPM [tr/min (rpm)]	×	▼	Engine speed	
FLUID LEV SW (On/Off)	×	▼	Brake fluid level switch signal status	K
FR RH IN SOL (On/Off)	▼	×	Operation status of each solenoid valve	L
FR RH OUT SOL (On/Off)	▼	×		M
FR LH IN SOL (On/Off)	▼	×		N
FR LH OUT SOL (On/Off)	▼	×		O
RR RH IN SOL (On/Off)	▼	×		P
RR RH OUT SOL (On/Off)	▼	×		
RR LH IN SOL (On/Off)	▼	×		
RR LH OUT SOL (On/Off)	▼	×		
MOTOR RELAY (On/Off)	▼	×	Motor and motor relay operation	
ACTUATOR RLY (On/Off)	▼	×	Actuator relay operation	

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
ABS WARN LAMP (On/Off)	▼	×	ABS warning lamp
OFF LAMP (On/Off)	▼	×	VDC OFF indicator lamp
SLIP/VDC LAMP (On/Off)	▼	×	SLIP indicator lamp
N POSI SIG (On/Off)	▼	▼	N range status
P POSI SIG (On/Off)	▼	▼	P range status
R POSI SIG (On/Off)	▼	▼	R range status
CRANKING SIG (On/Off)	▼	▼	CAN mask request for cranking
CV1 (On/Off)	▼	▼	Cut valve 1 monitor
CV2 (On/Off)	▼	▼	Cut valve 2 monitor
SV1 (On/Off)	▼	▼	Suction valve 1 monitor
SV2 (On/Off)	▼	▼	Suction valve 2 monitor
STOP LAMP SW2 (On/Off)	▼	▼	ASCD brake switch signal status
EBD SIGNAL (On/Off)	▼	▼	EBD operation
ABS SIGNAL (On/Off)	▼	▼	ABS operation
TCS SIGNAL (On/Off)	▼	▼	TCS operation
VDC SIGNAL (On/Off)	▼	▼	VDC operation
EBD FAIL SIG (On/Off)	▼	▼	EBD fail-safe status
ABS FAIL SIG (On/Off)	▼	▼	ABS fail-safe status
TCS FAIL SIG (On/Off)	▼	▼	TCS fail-safe status
VDC FAIL SIG (On/Off)	▼	▼	VDC fail-safe status
4WD MODE MON (On/Off)	▼	▼	AWD mode monitor

ACTIVE TEST MODE

CAUTION:

- Never perform active test while driving vehicle.
- Make sure to completely bleed air from brake system.
- The active test cannot be performed with the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp are on.
- ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp are on during active test.
- Erase memory of ICC system after implementing active test.

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

NOTE:

- When active test is performed while depressing the pedal, the pedal depression amount will change. This is normal. (Only solenoid valve and ABS motor.)
- "TEST IS STOPPED" in "ABS" with CONSULT-III is displayed 10 seconds after operation start.
- After "TEST IS STOPPED" in "ABS" with CONSULT-III is displayed, to perform test again.

Test Item

ABS SOLENOID VALVE

- Select "Up", "Keep" and "Down" of "ACTIVE TEST" in "ABS" with CONSULT-III. Then use screen monitor to check that solenoid valve operates as shown in solenoid valve operation chart.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
	CV1	Off	Off	Off
	SV1	Off	Off	Off
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
	CV2	Off	Off	Off
	SV2	Off	Off	Off
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
	CV2	Off	Off	Off
	SV2	Off	Off	Off
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*
	CV1	Off	Off	Off
	SV1	Off	Off	Off

BRC

*: On for 1 to 2 seconds after the select, and then Off.

ABS SOLENOID VALVE (ACT)

- Select "Up", "Keep" and "Down" of "ACTIVE TEST" in "ABS" with CONSULT-III. Then use screen monitor to check that solenoid valve operates as shown in solenoid valve operation chart.

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
FR RH ABS SOLENOID (ACT)	FR RH IN SOL	Off	Off	Off
	FR RH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off
FR LH ABS SOLENOID (ACT)	FR LH IN SOL	Off	Off	Off
	FR LH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR RH ABS SOLENOID (ACT)	RR RH IN SOL	Off	Off	Off
	RR RH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off

DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
RR LH ABS SOLENOID (ACT)	RR LH IN SOL	Off	Off	Off
	RR LH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off

*: On for 1 to 2 seconds after the select, and then Off.

ABS MOTOR

- Select "On" and "Off" of "ACTIVE TEST" in "ABS" with CONSULT-III on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY	On	On

ECU IDENTIFICATION

ABS actuator and electric unit (control unit) part number can be read.

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

DTC/CIRCUIT DIAGNOSIS

C1101, C1102, C1103, C1104 WHEEL SENSOR

Description

INFOID:000000006203007

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006203008

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1101	RR RH SENSOR-1	Circuit of rear RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	<ul style="list-style-type: none">• Harness or connector• Wheel sensor• ABS actuator and electric unit (control unit)
C1102	RR LH SENSOR-1	Circuit of rear LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1103	FR RH SENSOR-1	Circuit of front RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1104	FR LH SENSOR-1	Circuit of front LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
RR RH SENSOR-1
RR LH SENSOR-1
FR RH SENSOR-1
FR LH SENSOR-1

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-99. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203009

CAUTION:

Never check between wheel sensor terminals.

1. CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

- YES >> GO TO 2.
NO >> Adjust air pressure, or replace tire.

2. CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

- YES >> GO TO 3.
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

3. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 4.

NO >> Poor connection of connector terminal. Repair or replace connector.

4. CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	12	E39 (Front RH)	4	Existed
	27	E22 (Front LH)	2	
	15	B41 (Rear RH)	8	
	30	B44 (Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	E39 (Front RH)	3	Existed
	23	E22 (Front LH)	1	
	11	B41 (Rear RH)	7	
	26	B44 (Rear LH)	5	

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	12, 21	E36	3, 4	Not existed
	27, 23			
	15, 11			
	30, 26			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5. REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.

CAUTION:

C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Never start engine.

5. Perform self-diagnosis results for "ABS" with CONSULT-III.

IS DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> INSPECTION END

Component Inspection

INFOID:000000006203010

1. CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ($\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-99. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000006203011

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1105, C1106, C1107, C1108 WHEEL SENSOR

Description

INFOID:000000006203012

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006203013

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1105	RR RH SENSOR-2	Signal from rear RH wheel sensor does not match other 3 wheel speed signal.	<ul style="list-style-type: none">• Sensor not installed currently• Sensor rotor or encoder damaged• Sensor rotor loose on axle• Electrical interference• Wheel not turning - e.g. vehicle driven on 2WD dyno• Sensor damaged• ABS unit damaged
C1106	RR LH SENSOR-2	Signal from rear LH wheel sensor does not match other 3 wheel speed signal.	
C1107	FR RH SENSOR-2	Signal from front RH wheel sensor does not match other 3 wheel speed signal.	
C1108	FR LH SENSOR-2	Signal from front LH wheel sensor does not match other 3 wheel speed signal.	

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
RR RH SENSOR-2
RR LH SENSOR-2
FR RH SENSOR-2
FR LH SENSOR-2

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-102. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203014

CAUTION:

Never check between wheel sensor terminals.

1.CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

- YES >> GO TO 2.
NO >> Adjust air pressure, or replace tire.

2.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

- YES >> GO TO 3.
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

3.CHECK CONNECTOR

C1105, C1106, C1107, C1108 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 4.

NO >> Poor connection of connector terminal. Repair or replace connector.

4. CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	12	E39 (Front RH)	4	Existed
	27	E22 (Front LH)	2	
	15	B41 (Rear RH)	8	
	30	B44 (Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	E39 (Front RH)	3	Existed
	23	E22 (Front LH)	1	
	11	B41 (Rear RH)	7	
	26	B44 (Rear LH)	5	

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)		Connector	Terminal	Continuity
Connector	Terminal			
E36	12, 21	E36	3, 4	Not existed
	27, 23			
	15, 11			
	30, 26			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5. REPLACE WHEEL SENSOR

1. Replace wheel sensor.
 2. Erase self-diagnosis results for "ABS" with CONSULT-III.
 3. Turn the ignition switch OFF.
 4. Turn the ignition switch ON.
- CAUTION:**
Never start engine.
5. Perform self-diagnosis results for "ABS" with CONSULT-III.

C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

IS DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> INSPECTION END

Component Inspection

INFOID:000000006203015

1. CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ($\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-102, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000006203016

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1109 POWER AND GROUND SYSTEM

Description

INFOID:000000006203017

Supplies electric power to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006203018

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1109	BATTERY VOLTAGE [ABNORMAL]	When the ABS actuator and electric unit (control unit) power supply is lower than normal. Power supply is greater than normal limits.	<ul style="list-style-type: none"> • Harness or connector • ABS unit • Fuse • Vehicle electrical power system

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
BATTERY VOLTAGE [ABNORMAL]

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-105, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203019

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
 NO >> Poor connection of connector terminal. Repair or replace connector.

2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT AND GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Turn ignition switch ON or OFF and check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E36	16	Ground	Ignition switch: ON	Battery voltage
			Ignition switch: OFF	Approx. 0 V

4. Check 10A fusible link (59).
5. Check continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R.

C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS actuator and electric unit (control unit)		IPDM E/R		continuity
Connector	Terminal	Connector	Terminal	
E36	16	E15	59	Existed

6. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3. ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

1. Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 16 and 4. With ignition switch ON check bulb illuminates correctly.
2. Check ABS motor supply under loaded condition (connector E36 terminals 1 and 3).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Check battery for terminal looseness, low voltage, etc. if any malfunction is found, repair malfunctioning parts.

NO >> Repair or replace malfunctioning components. (Check ABS earth bolt for tightness and corrosion.)

Diagnosis Procedure

INFOID:000000006203020

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 2.

NO >> Poor connection of connector terminal. Repair or replace connector.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT AND GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Turn ignition switch ON or OFF and check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E36	16	Ground	Ignition switch: ON	Battery voltage
			Ignition switch: OFF	Approx. 0 V

4. Check 10A fusible link (59).

C1109 POWER AND GROUND SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

5. Check continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R.

ABS actuator and electric unit (control unit)		IPDM E/R		continuity
Connector	Terminal	Connector	Terminal	
E36	16	E15	59	Existed

6. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3. ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

1. Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 16 and 4. With ignition switch ON check bulb illuminates correctly.

2. Check ABS motor supply under loaded condition (connector E36 terminals 1 and 3).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.

2. Disconnect ABS actuator and electric unit (control unit) connector.

3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Check battery for terminal looseness, low voltage, etc. if any malfunction is found, repair malfunctioning parts.

NO >> Repair or replace malfunctioning components. (Check ABS earth bolt for tightness and corrosion.)

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Description

INFOID:000000006203021

ABS unit is continuously monitoring ECU hardware and software for correct operation.

DTC Logic

INFOID:000000006203022

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1110	CONTROLLER FAILURE	Possible internal failure of control unit components.	Internal failure of control unit components. ABS solenoid valve or motor power supply / ground abnormal.

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

1. Check both ABS solenoid valve and motor supply and ground circuits using a suitable electrical load.
2. Check wheel speed sensor inputs.
3. Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results

CONTROLLER FAILURE

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-108. "Diagnosis Procedure"](#).

NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203023

1. REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

CAUTION:

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

>> Replace ABS actuator and electric unit (control unit).

Special Repair Requirement

INFOID:000000006203024

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

Description

INFOID:000000006203025

PUMP

The pump returns the brake fluid stored in the reservoir to the master cylinder by reducing the pressure.

MOTOR

The motor drives the pump according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006203026

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1111	PUMP MOTOR	During the actuator motor operating with ON, when the actuator motor turns OFF, or when the control line for actuator motor relay is open.	<ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit)
		During the actuator motor operating with OFF, when the actuator motor turns ON, or when the control line for relay is shorted to ground.	

A

B

C

D

E

BRC

G

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
PUMP MOTOR

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-109, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

H

I

J

Diagnosis Procedure

INFOID:000000006203027

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnect, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
 NO >> Poor connection of connector terminal. Replace or repair connector.

2. CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between the ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	1	Ground	Battery voltage

4. Reconnect ABS actuator and electric unit (control unit) connector.

L

M

N

O

P

C1111 ABS MOTOR, MOTOR RELAY SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace malfunctioning components.

3.ABS POWER SUPPLY CHECK (UNDER LOAD CONDITION)

Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 2 and 3. With ignition switch ON check bulb illuminates correctly.

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Check both power supply and ground circuit.

4.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
- NO >> Repair or replace malfunctioning components. (Check ABS each bolt for tightness and corrosion.)

Component Inspection

INFOID:000000006203028

1.CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and "ABS MOTOR" in order with CONSULT-III.
2. Select "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY	On	On

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to diagnosis procedure. Refer to [BRC-109, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000006203029

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

Description

INFOID:000000006203030

Yaw rate/side/decel G sensor detects yaw rate/side/decel G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

DTC Logic

INFOID:000000006203031

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1113	G SENSOR	Yaw rate/side/decel G sensor is malfunctioning, or signal line of yaw rate/side/decel G sensor is open or shorted.	<ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• Yaw rate/side/decel G sensor• Electrical interference• Vehicle driven on AWD rolling road
C1145	YAW RATE SENSOR		
C1146	SIDE G-SEN CIRCUIT		

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
G SENSOR
YAW RATE SENSOR
SIDE G-SEN CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-111, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203032

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect yaw rate/side/decel G sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Replace or repair connector.

2.CHECK YAW RATE/SIDE/DECEL G SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect yaw rate/side/decel G sensor connector.
4. Check continuity between yaw rate/side/decel G sensor harness connector terminals and ABS actuator and electric unit (control unit) harness connector terminals.

C1113, C1145, C1146 YAW RATE/SIDE/DECCEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS actuator and electric unit (control unit)		Yaw rate/side/deccl G sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	13	B38	4	Existed
	14		5	
	28		2	
	29		6	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3.CHECK YAW RATE/SIDE/DECCEL G SENSOR HARNESS CONNECTOR

Check continuity between G sensor harness connector terminal and ground.

Yaw rate/side/deccl G sensor		Continuity
Connector	Terminal	
B38	2 - 4	Not existed
	2 - 5	
	2 - 6	
	4 - 5	
	4 - 6	
	5 - 6	

Is the inspection result normal?


YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

4.CHECK YAW RATE/SIDE/DECCEL G SENSOR 1

1. Connect yaw rate/side/deccl G sensor connector.
2. Connect ABS actuator and electric unit (control unit) connector.
3. Turn ignition switch ON.
4. Move yaw rate/side/deccl G sensor as shown in the figure to check the output of before and after moving the sensor with the "ABS", "DATA MONITOR" and "DECCEL G-SEN" in order with CONSULT-III.

Condition	DATA MONITOR
Horizontal	Approx. 0 G
Vertical	Approx. +1 G



Is the inspection result normal?

YES >> Replace yaw rate/side/deccl G sensor.

NO >> GO TO 5.

5.CHECK YAW RATE/SIDE/DECCEL G SENSOR 2

1. Turn ignition switch OFF.
2. Connect following terminals between yaw rate/side/deccl G sensor and connector.

C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Yaw rate/side/decel G sensor	Harness connector	
	Connector	Terminal
2	B38	2
4		4
5		5
6		6

- Turn ignition switch ON.
- Check voltage between yaw rate/side/decel G sensor harness connector terminals.

CAUTION:

Never short out the terminals while measuring voltages.

Yaw rate/side/decel G sensor		Voltage
connector	Terminal	
B38	5 - 2	2.5 - 4.5 V
	6 - 2	0.5 - 2.5 V

Is the inspection result normal?

- YES >> Replace ABS actuator end electric unit (control unit). Perform self-diagnosis for "ABS" with CONSULT-III.
- NO >> Replace yaw rate/side/decel G sensor. Perform self-diagnosis for "ABS" with CONSULT-III.

Component Inspection

INFOID:000000006203033

1. CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" and "YAW RATE SENSOR", "SIDE G-SENSOR" and/or "DECEL G-SEN" in order with CONSULT-III, and check yaw rate/side/decel G sensor signal.

YAW RATE SENSOR

Vehicle condition	DATA MONITOR
Vehicle stopped	Approx. 0 d/s
Vehicle turning	-100 to 100 d/s

SIDE G SENSOR

Vehicle condition	DATA MONITOR
Vehicle stopped	Approx. 0 m/s ²
Vehicle turning right	Negative value
Vehicle turning left	Positive value

DECEL G SENSOR

Vehicle condition	DATA MONITOR
Vehicle stopped	-0.11 to +0.11 G
During acceleration	Negative value
During deceleration	Positive value

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to diagnosis procedure. Refer to [BRC-111, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000006203034

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76](#). "[ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement](#)".

>> END

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

C1115 WHEEL SENSOR

Description

INFOID:000000006203035

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006203036

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1115	ABS SENSOR [ABNORMAL SIGNAL]	Miss-match between the 4 wheel speed sensor signals.	Harness or connector not a possible cause. Other possible causes tire radius (due to wrong size or pressure) interference.

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results

ABS SENSOR [ABNORMAL SIGNAL]

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-115. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203037

CAUTION:

Never check between wheel sensor terminals.

1.CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

- YES >> GO TO 2.
NO >> Adjust air pressure, or replace tire.

2.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check that there is no deformation, misalignment, float, and backlash on the wheel sensor and wheel sensor mounting surface.
- Check that the wheel sensor is installed with no misalignment and backlash.

Are the sensor and sensor rotor normal?

- YES >> GO TO 3.
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

3.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 4.

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Poor connection of connector terminal. Repair or replace connector.

4.CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	12	E39 (Front RH)	4	Existed
	27	E22 (Front LH)	2	
	15	B41 (Rear RH)	8	
	30	B44 (Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	E39 (Front RH)	3	Existed
	23	E22 (Front LH)	1	
	11	B41 (Rear RH)	7	
	26	B44 (Rear LH)	5	

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)		Connector	Terminal	Continuity
Connector	Terminal			
E36	12, 21	E36	3, 4	Not existed
	27, 23			
	15, 11			
	30, 26			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.

CAUTION:

Never start engine.

5. Perform self-diagnosis results for "ABS" with CONSULT-III.

IS DTC "C1115" detected?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> INSPECTION END

Component Inspection

INFOID:000000006203038

1.CHECK DATA MONITOR

C1115 WHEEL SENSOR

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ($\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-115. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000006203039

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1116 STOP LAMP SWITCH

Description

INFOID:000000006203040

The stop lamp switch transmits the stop lamp switch signal (ON/OFF) to the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006203041

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1116	STOP LAMP SW	When a stop lamp switch signal is not input where the brake pedal is depressed.	<ul style="list-style-type: none">• Harness or connector• Stop lamp switch• ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results

STOP LAMP SW

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-118, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203042

1.CHECK STOP LAMP ILLUMINATE

Check stop lamps illuminate when brake pedal is pressed.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Check stop lamp circuit.

2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect stop lamp switch connector.
4. Check terminal for deformation, disconnection, looseness, etc.
5. Reconnect ABS actuator and electric unit (control unit) and stop lamp switch connectors securely.
6. Start engine.
7. Repeat pumping brake pedal carefully several times, and perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated in the self-diagnosis display?

- YES >> GO TO 3.
NO >> Poor connection of connector terminal. Replace or repair error-detected parts.

3.CHECK STOP LAMP SWITCH CLEARANCE

Check stop lamp switch clearance. Refer to [BR-9, "Inspection and Adjustment"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Adjust stop lamp switch clearance. Refer to [BR-9, "Inspection and Adjustment"](#).

4.CHECK STOP LAMP SWITCH CIRCUIT

1. Turn ignition switch OFF.

C1116 STOP LAMP SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E36	8	Ground	Brake pedal is depressed	Battery voltage
			Brake pedal is released	Approx. 0 V

Is the inspection result normal?

- YES >> GO TO 5.
 NO >> Repair or replace malfunctioning components.

5.CHECK STOP LAMP SWITCH

Check stop lamp switch. Refer to [BRC-119. "Component Inspection"](#).

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace stop lamp switch. Refer to [BR-20. "Exploded View"](#).

Component Inspection

INFOID:000000006203043

1.CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch connector terminals.

Stop lamp switch	Condition	Continuity
Terminal		
1 - 2	Release stop lamp switch (When brake pedal is depressed.)	Existed
	Push stop lamp switch (When brake pedal is released.)	Not existed

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace stop lamp switch. Refer to [BR-20. "Exploded View"](#).

Component Inspection

INFOID:000000006203044

1.CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch connector terminals.

Stop lamp switch	Condition	Continuity
Terminal		
1 - 2	Release stop lamp switch (When brake pedal is depressed.)	Existed
	Push stop lamp switch (When brake pedal is released.)	Not existed

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace stop lamp switch. Refer to [BR-20. "Exploded View"](#).

C1118 AWD SYSTEM

Description

INFOID:000000006203045

It transmits the value calculated by AWD control unit to ABS actuator and electric unit (control unit) with AWD communication line (line for AWD system only). ABS actuator and electric unit (control unit) controls AWD solenoid valve according to the received command value.

DTC Logic

INFOID:000000006203046

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1118	4WD SYSTEM	An error is detected on AWD control unit side. (AWD control unit fail-safe mode)	<ul style="list-style-type: none"> Harness or connector AWD communication line AWD control unit ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
4WD SYSTEM

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-120, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203047

1.CHECK AWD CONTROL UNIT

Perform self-diagnosis for "ALL MODE AWD/4WD" with CONSULT-III.

Is any error system detected?

- YES >> Check the error system. Refer to [DLN-42, "DTC Index"](#).
 NO >> Replace ABS actuator and electric unit (control unit).

Special Repair Requirement

INFOID:000000006203048

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1120, C1122, C1124, C1126 IN ABS SOL

Description

INFOID:000000006203049

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006203050

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1120	FR LH IN ABS SOL	When the control unit detects a malfunction in the front LH inlet solenoid circuit.	ABS actuator and electric unit (control unit)
C1122	FR RH IN ABS SOL	When the control unit detects a malfunction in the front RH inlet solenoid circuit.	
C1124	RR LH IN ABS SOL	When the control unit detects a malfunction in the rear LH inlet solenoid circuit.	
C1126	RR RH IN ABS SOL	When the control unit detects a malfunction in the rear RH inlet solenoid circuit.	

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
FR LH IN ABS SOL
FR RH IN ABS SOL
RR LH IN ABS SOL
RR RH IN ABS SOL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-121. "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203051

1.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

- YES >> GO TO 2.
- NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.
- NO >> Poor connection of connector terminal. Replace or repair connector.

C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

3. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Repair or replace malfunctioning components.

4. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
 NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000006203052

1. CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and each test menu item in order with CONSULT-III.
2. On the display, select "Up", "Keep", and "Down", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
	CV1	Off	Off	Off
	SV1	Off	Off	Off
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
	CV2	Off	Off	Off
	SV2	Off	Off	Off
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
	CV2	Off	Off	Off
	SV2	Off	Off	Off
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*
	CV1	Off	Off	Off
	SV1	Off	Off	Off

*: On for 1 to 2 seconds after the select, and then Off.

C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-121. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000006203053

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1121, C1123, C1125, C1127 OUT ABS SOL

Description

INFOID:000000006203054

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006203055

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1121	FR LH OUT ABS SOL	When the control unit detects a malfunction in the front LH outlet solenoid circuit.	ABS actuator and electric unit (control unit)
C1123	FR RH OUT ABS SOL	When the control unit detects a malfunction in the front RH outlet solenoid circuit.	
C1125	RR LH OUT ABS SOL	When the control unit detects a malfunction in the rear LH outlet solenoid circuit.	
C1127	RR RH OUT ABS SOL	When the control unit detects a malfunction in the rear RH outlet solenoid circuit.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
FR LH OUT ABS SOL
FR RH OUT ABS SOL
RR LH OUT ABS SOL
RR RH OUT ABS SOL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-124, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203056

1. CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

- YES >> GO TO 2.
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

2. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.
NO >> Poor connection of connector terminal. Replace or repair connector.

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

3. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

4. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000006203057

1. CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and each test menu item in order with CONSULT-III.
2. On the display, select "Up", "Keep", and "Down", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
	CV1	Off	Off	Off
	SV1	Off	Off	Off
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
	CV2	Off	Off	Off
	SV2	Off	Off	Off
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
	CV2	Off	Off	Off
	SV2	Off	Off	Off
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*
	CV1	Off	Off	Off
	SV1	Off	Off	Off

*: On for 1 to 2 seconds after the select, and then Off.

C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-124. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000006203058

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1130 ENGINE SIGNAL

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

C1130 ENGINE SIGNAL

Description

INFOID:000000006203059

ABS actuator and electric unit (control unit) and ECM exchange the engine signal via CAN communication line.

DTC Logic

INFOID:000000006203060

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1130	ENGINE SIGNAL 1	ECM signals are invalid or ECM self diagnosis indicates a fault that prevents correct TCS operation.	<ul style="list-style-type: none">• Harness or connector• ABS actuator and electric unit (control unit)• ECM• CAN communication line

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
ENGINE SIGNAL 1

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-127. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203061

1.CHECK ENGINE SYSTEM

1. Perform self-diagnosis for "ENGINE" with CONSULT-III. Repair or replace items indicated, then Perform self-diagnosis for "ENGINE" with CONSULT-III.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> Repair or replace the affected part.
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203062

1.CHECK ENGINE SYSTEM

1. Perform self-diagnosis for "ENGINE" with CONSULT-III. Repair or replace items indicated, then Perform self-diagnosis for "ENGINE" with CONSULT-III.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> Repair or replace the affected part.
NO >> INSPECTION END

C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1140 ACTUATOR RELAY SYSTEM

Description

INFOID:000000006203063

Activates or deactivates each solenoid valve according to the signals transmitted by the ABS actuator and electric unit (control unit).

DTC Logic

INFOID:000000006203064

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1140	ACTUATOR RLY	During the actuator relay operating with OFF, when the actuator relay turns ON, or when the control line for the relay is shorted to the ground.	<ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit)
		During the actuator relay operating with ON, when the actuator relay turns ON, or when the control line for the relay is open.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
ACTUATOR RLY

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-128, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203065

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
 NO >> Poor connection of connector terminal. Replace or repair connector.

2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

4. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Repair or replace malfunctioning components.

C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

3. ABS POWER SUPPLY CHECK (UNDER LOAD CONDITION)

Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 1 and 3. With ignition switch ON check bulb illuminates correctly.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

4. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components. (Check ABS each bolt for tightness and corrosion.)

Component Inspection

INFOID:000000006203066

1. CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and "ABS MOTOR" in order with CONSULT-III.
2. Select "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY	On	On

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-128, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000006203067

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1143, C1144 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1143, C1144 STEERING ANGLE SENSOR

Description

INFOID:000000006203068

The steering angle sensor detects the rotation amount, angular velocity and direction of the steering wheel, and transmits the data to the ABS actuator and electric unit (control unit) via CAN communication.

DTC Logic

INFOID:000000006203069

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1143	ST ANG SEN CIRCUIT	Neutral position of steering angle sensor is dislocated, or the steering angle sensor is malfunctioning.	• Harness or connector • Steering angle sensor • ABS actuator and electric unit (control unit)
C1144	ST ANG SEN SIGNAL	Neutral position of steering angle sensor is not finished.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
ST ANG SEN CIRCUIT
ST ANG SEN SIGNAL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-130, "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203070

1. CHECK VEHICLE STATE

Check vehicle for any suspension/steering misalignment or damage.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Correct any damage found.

2. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect steering angle sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.
NO >> Poor connection of connector terminal. Replace or repair connector.

3. CHECK STEERING ANGLE SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect steering angle sensor connector.
3. Check continuity between steering angle sensor harness connector terminal and ground.

Steering angle sensor		—	Continuity
Connector	Terminal		
M30	3	Ground	Existed

C1143, C1144 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

4. Turn ignition switch ON.
5. Check voltage between steering angle sensor harness connector terminal and ground.

Steering angle sensor		—	Voltage
Connector	Terminal		
M30	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Repair or replace malfunctioning components.

4.CHECK DATA MONITOR

1. Connect the steering angle sensor connector and ABS actuator and electric unit (control unit) connector.
2. Select "ABS", "DATA MONITOR" and "STR ANGLE SIG" in order with CONSULT-III, and check steering angle sensor signal.

Steering condition	STR ANGLE SIG (DATA MONITOR)
Driving straight	$\pm 2.5^\circ$
Turn 90° to right	Approx. +90°
Turn 90° to left	Approx. -90°

Is the inspection result normal?

- YES >> GO TO 5.
NO >> Adjust neutral position of steering angle sensor.

5.CHECK FOR BACKLASH

1. Check for backlash [turn wheel to left then straight then right then straight (approx. 90°)].
2. Check straight position is always similar value.

Is there noticeable backlash?

- YES >> Check sensor is correctly fitted to combination switch.
NO >> Check sensor output is correct from lock to lock.

Component Inspection

INFOID:0000000006203071

1.CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" and "STR ANGLE SIG" in order with CONSULT-III, and check steering angle sensor signal.

Steering condition	STR ANGLE SIG (DATA MONITOR)
Driving straight	$\pm 2.5^\circ$
Turn 90° to right	Approx. +90°
Turn 90° to left	Approx. -90°

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Go to diagnosis procedure. Refer to [BRC-130, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:0000000006203072

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1155 BRAKE FLUID LEVEL SWITCH

Description

INFOID:000000006203073

Brake fluid level switch contacts close when brake fluid level is low. This is detected by the combination meter which sends the status of fluid level to the VDC unit via the CAN bus.

DTC Logic

INFOID:000000006203074

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1155	BR FLUID LEVEL LOW	Ignition switch ON and brake fluid signal low or not available for 10 seconds.	<ul style="list-style-type: none">• Brake fluid level low• Brake fluid level switch failure• Wiring to brake fluid level switch short circuit• CAN bus failure• Combination meter failure

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results

BR FLUID LEVEL LOW

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-132. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203075

1.CHECK BRAKE FLUID LEVEL

Check brake fluid level. Refer to [BR-12. "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.
NO >> Refill brake fluid. Refer to [BR-12. "Refilling"](#).

2.CHECK BRAKE WARNING LAMP 1

Check that the brake warning lamp illuminates after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 3.
NO >> Check wiring to brake fluid level sensor and brake fluid level sensor.

3.CHECK BRAKE WARNING LAMP 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake.

Is the inspection result normal?

YES >> GO TO 4.
NO >> Check parking brake switch.

4.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector and combination meter connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

C1155 BRAKE FLUID LEVEL SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is any item indicated on the self-diagnosis display?

YES >> GO TO 5.

NO >> Poor connection of connector terminal. Replace or repair connector.

5. CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

Brake fluid level switch		Condition	Continuity
Connector	Terminal		
E37	1 – 2	When brake fluid is full in the reservoir tank.	Not existed
		When brake fluid is empty in the reservoir tank.	Existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Brake fluid level switch is malfunction. Replace reservoir tank.

6. CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between brake fluid level switch harness connector terminals and combination meter harness connector terminal and/or ground.

Combination meter		Brake fluid level switch		Continuity
Connector	Terminal	Connector	Terminal	
M34	27	E37	1	Existed

Combination meter		—	Continuity
Connector	Terminal		
M34	27	Ground	Not existed

Brake fluid level switch		—	Continuity
Connector	Terminal		
E37	2	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000006203076

1. CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

Brake fluid level switch		Condition	Continuity
Connector	Terminal		
E37	1 – 2	When brake fluid is full in the reservoir tank.	Not existed
		When brake fluid is empty in the reservoir tank.	Existed

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

C1155 BRAKE FLUID LEVEL SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-132. "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000006203077

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1164, C1165 CV SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1164, C1165 CV SYSTEM

Description

INFOID:000000006203078

The cut valve shuts off the normal brake fluid path from the master cylinder, when VDC/TCS is activated.

DTC Logic

INFOID:000000006203079

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1164	CV1	VDC switch-over solenoid valve (CV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	• Harness or connector • ABS actuator and electric unit (control unit)
C1165	CV2	VDC switch-over solenoid valve (CV2) on the secondary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
CV1
CV2

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-135. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203080

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
NO >> Poor connection of connector terminal. Replace or repair connector.

2. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace malfunctioning components.

3. CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

C1164, C1165 CV SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
 NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000006203081

1. CHECK ACTIVE TEST

- Select "ABS", "ACTIVE TEST" and each test menu item in order with CONSULT-III.
- On the display, select "Up", "ACT UP", and "ACT KEEP", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
FR RH ABS SOLENOID (ACT)	FR RH IN SOL	Off	Off	Off
	FR RH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off
FR LH ABS SOLENOID (ACT)	FR LH IN SOL	Off	Off	Off
	FR LH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR RH ABS SOLENOID (ACT)	RR RH IN SOL	Off	Off	Off
	RR RH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR LH ABS SOLENOID (ACT)	RR LH IN SOL	Off	Off	Off
	RR LH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off

*: On for 1 to 2 seconds after the select, and then Off.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Go to diagnosis procedure. Refer to [BRC-135, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000006203082

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1166, C1167 SV SYSTEM

Description

INFOID:000000006203083

The suction valve supplies the brake fluid from the master cylinder to the pump, when VDC/TCS is activated.

DTC Logic

INFOID:000000006203084

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1166	SV1	VDC switch-over solenoid valve (SV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	<ul style="list-style-type: none"> • Harness or connector • ABS actuator and electric unit (control unit)
C1167	SV2	VDC switch-over solenoid valve (SV2) on the secondary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for “ABS” with CONSULT-III.

Self-diagnosis results
SV1
SV2

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-137. "Diagnosis Procedure"](#).
- NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203085

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform self-diagnosis for “ABS” with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
- NO >> Poor connection of connector terminal. Replace or repair connector.

2.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace malfunctioning components.

3.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

C1166, C1167 SV SYSTEM

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
 NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000006203086

1. CHECK ACTIVE TEST

- Select "ABS", "ACTIVE TEST" and each test menu item in order with CONSULT-III.
- On the display, select "Up", "ACT UP", and "ACT KEEP", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
FR RH ABS SOLENOID (ACT)	FR RH IN SOL	Off	Off	Off
	FR RH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off
FR LH ABS SOLENOID (ACT)	FR LH IN SOL	Off	Off	Off
	FR LH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR RH ABS SOLENOID (ACT)	RR RH IN SOL	Off	Off	Off
	RR RH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR LH ABS SOLENOID (ACT)	RR LH IN SOL	Off	Off	Off
	RR LH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off

*: On for 1 to 2 seconds after the select, and then Off.

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Go to diagnosis procedure. Refer to [BRC-137, "Diagnosis Procedure"](#).

Special Repair Requirement

INFOID:000000006203087

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

C1176 STOP LAMP SW2

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

C1176 STOP LAMP SW2

Description

INFOID:000000006203088

When the brake pedal is depressed, ASCD brake switch is turned OFF and stop lamp switch is turned ON.

DTC Logic

INFOID:000000006203089

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1176	STOP LAMP SW2	When a ASCD brake switch signal is not input where the brake pedal is depressed.	<ul style="list-style-type: none"> • Harness or connector • ASCD brake switch • ABS actuator and electric unit (control unit)

DTC CONFIRMATION PROCEDURE

1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
STOP LAMP SW2

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-139, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203090

1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.
 NO >> Poor connection of connector terminal. Replace or repair connector.

2.CHECK ASCD BRAKE SWITCH CLEARANCE

Check ASCD brake switch clearance. Refer to [BR-9, "Inspection and Adjustment"](#).

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> Adjust ASCD brake switch clearance. Refer to [BR-9, "Inspection and Adjustment"](#)

3.CHECK ASCD BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch connector.
3. Check continuity between ASCD brake switch connector terminals.

ASCD brake switch	Condition	Continuity
Terminal		
1 – 2	Brake pedal is fully released.	Existed
	Brake pedal is slightly depressed.	Not existed

Is the inspection result normal?

- YES >> GO TO 4.

C1176 STOP LAMP SW2

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace ASCD brake switch. Refer to [BR-20, "Exploded View"](#).

4.CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch connector.
3. Turn ignition switch ON.
4. Check voltage between ASCD brake switch harness connector and ground.

ASCD brake switch		—	Voltage
Connector	Terminal		
E112	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

5.CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ASCD brake switch harness connector and ABS actuator and electric unit (control unit) harness connector.

ASCD brake switch		ABS actuator and electric unit (control unit)		Continuity
Connector	Terminal	Connector	Terminal	
E112	2	E36	6	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace malfunctioning components.

Component Inspection

INFOID:000000006203091

1.CHECK ASCD BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch connector.
3. Check continuity between ASCD brake switch connector terminals.

ASCD brake switch	Condition	Continuity
Terminal		
1 – 2	Brake pedal is fully released.	Existed
	Brake pedal is slightly depressed.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace ASCD brake switch. Refer to [BR-20, "Exploded View"](#).

Special Repair Requirement

INFOID:000000006203092

1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

U1000 CAN COMM CIRCUIT

Description

INFOID:000000006203093

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000006203094

DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or more.	<ul style="list-style-type: none"> CAN communication line ABS actuator and electric unit (control unit)

BRC

DTC CONFIRMATION PROCEDURE

1. CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
CAN COMM CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-141, "Diagnosis Procedure"](#).
 NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203095

1. CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
CAN COMM CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Go to [LAN-15, "Trouble Diagnosis Flow Chart"](#).
 NO >> INSPECTION END

Special Repair Requirement

INFOID:000000006203096

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000006203097

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

DTC Logic

INFOID:000000006203098

DTC DETECTION LOGIC

DTC	Items	Diagnostic item is detected when...	Possible cause
U1010	CONTROL UNIT (CAN)	When detecting error during the initial diagnosis of CAN controller of ABS actuator and electric unit (control unit).	ABS actuator and electric unit (control unit) error

DTC CONFIRMATION PROCEDURE

1. RECHECK DTC

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "U1010" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-142. "Diagnosis Procedure"](#).
NO >> INSPECTION END

Diagnosis Procedure

INFOID:000000006203099

1. ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Check that there is no malfunction in ABS actuator and electric unit (control unit) harness connector or disconnection.

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-178. "Exploded View"](#).
NO >> Repair or replace the harnesses and connectors.

Special Repair Requirement

INFOID:000000006203100

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

PARKING BRAKE SWITCH

Description

INFOID:000000006203101

The parking brake switch converts the status of the parking brake pedal to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

Component Function Check

INFOID:000000006203102

1.CHECK PARKING BRAKE SWITCH OPERATION

Operate the parking brake pedal. Then check that the brake warning lamp in the combination meter turns on/off correctly.

Condition	Brake warning lamp illumination status
When the parking brake switch is operation	ON
When the parking brake switch is not operation.	OFF

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-143, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006203103

1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch connector terminal and ground.

Parking brake switch		—	Condition	Continuity
Connector	Terminal			
E103	1	Ground	When the parking brake switch is operated.	Existed
			When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace parking brake switch.

2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-27, "CONSULT-III Function"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check ABS actuator and electric unit (control unit). Refer to [BRC-94, "CONSULT-III Function"](#).

Component Inspection

INFOID:000000006203104

1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch connector terminal and ground.

PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Parking brake switch		—	Condition	Continuity
Connector	Terminal			
E103	1	Ground	When the parking brake switch is operated.	Existed
			When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch. Refer to [PB-6. "Exploded View"](#).

VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

VDC OFF SWITCH

Description

INFOID:000000006203105

VDC OFF switch can deactivate (turn OFF) the VDC/TCS function by pressing the VDC OFF switch.

Component Function Check

INFOID:000000006203106

1. CHECK VDC OFF SWITCH OPERATION

Turn ON/OFF the VDC OFF switch and check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly.

Condition	VDC OFF indicator lamp illumination status
VDC OFF switch: ON	ON
VDC OFF switch: OFF	OFF

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-145. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006203107

1. CHECK VDC OFF SWITCH

1. Turn ignition switch OFF.
2. Disconnect VDC OFF switch connector.
3. Check continuity between VDC OFF switch connector terminals.

VDC OFF switch Terminal	Condition	Continuity
1 - 2	When VDC OFF switch is hold pressed.	Existed
	When releasing VDC OFF switch.	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> VDC OFF switch is malfunctioning. Replace VDC OFF switch.

2. CHECK VDC OFF SWITCH HARNESS

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between VDC OFF switch connector terminals and ABS actuator and electric unit (control unit) connector terminal and/or ground.

ABS actuator and electric unit (control unit)		VDC OFF switch		Continuity
Connector	Terminal	Connector	Terminal	
E36	5	M5	1	Existed

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	5	Ground	Not existed

VDC OFF switch		—	Continuity
Connector	Terminal		
M5	2	Ground	Existed

Is the inspection result normal?

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

VDC OFF SWITCH

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.
NO >> If the open or short in harness, repair or replace harness.

3.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-27. "CONSULT-III Function"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).
NO >> Repair or replace combination meter.

Component Inspection

INFOID:000000006203108

1.CHECK VDC OFF SWITCH

1. Turn ignition switch OFF.
2. Disconnect VDC OFF switch connector.
3. Check continuity between VDC OFF switch connector terminals.

VDC OFF switch	Condition	Condition
Terminal		
1 – 2	When VDC OFF switch is hold pressed.	Existed
	When releasing VDC OFF switch.	Not existed

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace VDC OFF switch.

Special Repair Requirement

INFOID:000000006203109

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

ABS WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS WARNING LAMP

Description

INFOID:000000006203110

x: ON –: OFF

Condition	ABS warning lamp
Ignition switch OFF	–
For 1 second after turning ignition switch ON	x
1 second later after turning ignition switch ON	–
ABS function is malfunctioning.	x
EBD function is malfunctioning.	x

Component Function Check

INFOID:000000006203111

1.CHECK ABS WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-147, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006203112

1.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-27, "CONSULT-III Function"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

Special Repair Requirement

INFOID:000000006203113

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

BRAKE WARNING LAMP

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

BRAKE WARNING LAMP

Description

INFOID:000000006203114

×: ON –: OFF

Condition	Brake warning lamp (Note 1)
Ignition switch OFF	–
For 1 second after turning ignition switch ON	× (Note 2)
1 second later after turning ignition switch ON	× (Note 2)
EBD function is malfunctioning.	×

NOTE:

- 1: Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- 2: After starting engine, brake warning lamp is turned off.

Component Function Check

INFOID:000000006203115

1. BRAKE WARNING LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to diagnosis procedure. Refer to [BRC-148, "Diagnosis Procedure"](#).

2. BRAKE WARNING LAMP OPERATION CHECK 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check parking brake switch. Refer to [BRC-143, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006203116

1. CHECK PARKING BRAKE SWITCH

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking brake switch. Refer to [BRC-143, "Diagnosis Procedure"](#).

2. CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check items displayed by self-diagnosis.

3. CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-27, "CONSULT-III Function"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

Special Repair Requirement

INFOID:000000006203117

1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

BRAKE WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

VDC OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

VDC OFF INDICATOR LAMP

Description

INFOID:000000006203118

×: ON –: OFF

Condition	VDC OFF indicator lamp
Ignition switch OFF	–
For 1 second after turning ignition switch ON	×
1 second later after turning ignition switch ON	–
VDC OFF switch turned ON. (VDC function is OFF.)	×
VDC/TCS function is malfunctioning.	×
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

Component Function Check

INFOID:000000006203119

1.VDC OFF INDICATOR LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to diagnosis procedure. Refer to [BRC-150, "Diagnosis Procedure"](#).

2.VDC OFF INDICATOR LAMP OPERATION CHECK 2

Check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check VDC OFF switch. Refer to [BRC-145, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006203120

1.CHECK VDC OFF SWITCH

Check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check VDC OFF switch. Refer to [BRC-145, "Diagnosis Procedure"](#).

2.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check items displayed by self-diagnosis.

3.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-27, "CONSULT-III Function"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

Special Repair Requirement

INFOID:000000006203121

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

VDC OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

- A
- B
- C
- D
- E
- BRC**
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P

SLIP INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

SLIP INDICATOR LAMP

Description

INFOID:000000006203122

×: ON –: OFF

Condition	SLIP indicator lamp
Ignition switch OFF	–
For 1 second after turning ignition switch ON	×
1 second later after turning ignition switch ON	–
VDC/TCS function is malfunctioning.	×
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

Component Function Check

INFOID:000000006203123

1.CHECK SLIP INDICATOR LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-152. "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000006203124

1.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-27. "CONSULT-III Function"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

Special Repair Requirement

INFOID:000000006203125

1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

ECU DIAGNOSIS INFORMATION

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Reference Value

INFOID:000000006203126

VALUES ON THE DIAGNOSIS TOOL

CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short-circuited.

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
FR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
FR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
RR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
RR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
STOP LAMP SW	Stop lamp switch signal status	When brake pedal is depressed	On
		When brake pedal is not depressed	Off
BATTERY VOLT	Battery voltage supplied to the ABS actuator and electric unit (control unit)	Ignition switch ON	10 – 16 V
GEAR	Gear position determined by TCM	First gear (1GR)	1
		Second gear (2GR)	2
		Third gear (3GR)	3
		Forth gear (4GR)	4
		Fifth gear (5GR)	5
		Sixth gear (6GR)	6
OFF SW	VDC OFF switch ON/OFF	VDC OFF switch ON (When VDC OFF indicator lamp is ON)	On
		VDC OFF switch OFF (When VDC OFF indicator lamp is OFF)	Off
YAW RATE SEN	Yaw rate detected by yaw rate sensor	Vehicle stopped	Approx. 0 d/s
		Vehicle turning	-100 to 100 d/s
DECEL G-SEN	Decel G detected by decel G sensor	Vehicle stopped	-0.11 – +0.11 G
		During acceleration	Negative value
		During deceleration	Positive value
ACCEL POS SIG	Throttle actuator opening/closing is displayed (linked with accelerator pedal)	Accelerator pedal not depressed (ignition switch is ON)	0 %
		Depress accelerator pedal (ignition switch is ON)	0 - 100 %

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
SIDE G-SENSOR	Transverse G detected by side G sensor	Vehicle stopped	Approx. 0 m/s ²
		Vehicle turning right	Negative value
		Vehicle turning left	Positive value
STR ANGLE SIG	Steering angle detected by steering angle sensor	During straight	Approx. 0°
		Steering wheel turned	-720 to 720°
ENGINE SPEED	With engine running	With engine stopped	0 [tr/min (rpm)]
		Engine running	Almost in accordance with tachometer display
FLUID LEV SW	Brake fluid level switch signal status	When brake fluid level switch ON	On
		When brake fluid level switch OFF	Off
FR RH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR RH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR LH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR LH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR RH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR RH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Monitor item	Display content	Data monitor		
		Condition	Reference value in normal operation	
RR LH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On	A
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off	B
RR LH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On	C
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off	D
MOTOR RELAY	Motor and motor relay operation	When the motor relay and motor are operating	On	E
		When the motor relay and motor are not operating	Off	BRC
ACTUATOR RLY	Actuator relay operation	When the actuator relay is operating	On	G
		When the actuator relay is not operating	Off	
ABS WARN LAMP	ABS warning lamp (Note 2)	When ABS warning lamp is ON	On	H
		When ABS warning lamp is OFF	Off	
OFF LAMP	VDC OFF indicator lamp (Note 2)	When VDC OFF indicator lamp is ON	On	I
		When VDC OFF indicator lamp is OFF	Off	
SLIP/VDC LAMP	SLIP indicator lamp (Note 2)	When SLIP indicator lamp is ON	On	J
		When SLIP indicator lamp is OFF	Off	
EBD SIGNAL	EBD operation	EBD is active	On	K
		EBD is inactive	Off	
ABS SIGNAL	ABS operation	ABS is active	On	L
		ABS is inactive	Off	
TCS SIGNAL	TCS operation	TCS is active	On	M
		TCS is inactive	Off	
VDC SIGNAL	VDC operation	VDC is active	On	N
		VDC is inactive	Off	
EBD FAIL SIG	EBD fail-safe signal	In EBD fail-safe	On	O
		EBD is normal	Off	
ABS FAIL SIG	ABS fail-safe signal	In ABS fail-safe	On	P
		ABS is normal	Off	
TCS FAIL SIG	TCS fail-safe signal	In TCS fail-safe	On	
		TCS is normal	Off	
VDC FAIL SIG	VDC fail-safe signal	In VDC fail-safe	On	
		VDC is normal	Off	
CRANKING SIG	Crank operation	Crank is active	On	
		Crank is inactive	Off	
N POSI SIG	N position signal	For N range	On	
		Except for N range	Off	
P POSI SIG	P position signal	For P range	On	
		Except for P range	Off	

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
R POSI SIG	R position signal	For R range	On
		Except for R range	Off
4WD MODE MON	Axle condition	AUTO is active	AUTO
		LOCK is active	LOCK
		2WD is active	2WD
CV1	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
CV2	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
SV1	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
SV2	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
STOP LAMP SW2	Stop lamp switch signal status	When brake pedal is depressed	On
		When brake pedal is not depressed	Off

NOTE:

- 1: Confirm tire pressure is normal.
- 2: On and off timing for warning lamp and indicator lamp.
- ABS warning lamp: Refer to [BRC-147, "Description"](#).
- Brake warning lamp: Refer to [BRC-148, "Description"](#).
- VDC OFF indicator lamp: Refer to [BRC-150, "Description"](#).
- SLIP indicator lamp: Refer to [BRC-152, "Description"](#).

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >


[VDC/TCS/ABS]

Wiring Diagram -BRAKE CONTROL SYSTEM-

INFOID:000000006203127

BRAKE CONTROL SYSTEM (WITH VDC)

AW: AWD models



2008/07/15

JCFWM0255GB

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM (WITH VDC)

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
5	L	-
8	R	-
9	Y	-
12	BR	-
13	O	-
22	G	- [For Mexico]
22	SB	- [Except for Mexico]
23	G	- [For Mexico]
23	SB	- [Except for Mexico]
51	GR	-
52	SHIELD	-
53	L	-
54	B	-
62	Y	-
63	R	-
96	G	-

Connector No.	B38
Connector Name	YAW RATE / SIDE / DECEL G SENSOR
Connector Type	SCZ06FB



Terminal No.	Color of Wire	Signal Name [Specification]
2	Y	GND
4	B	VCC (POWER)
5	L	SERIAL+
6	R	SERIAL-

Connector No.	B41
Connector Name	REAR WHEEL SENSOR RH
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
7	O	-
8	SB	-

Connector No.	B44
Connector Name	REAR WHEEL SENSOR LH
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
5	BR	-
6	G	-

Connector No.	E15
Connector Name	SWAY BY INTELLI LIGHT POWER DISTRIBUTION MODULE (ENGINE ROOM)
Connector Type	NS16FW-CS



Terminal No.	Color of Wire	Signal Name [Specification]
47	BR	-
48	R	-


50	G	-
51	L	-
52	P	-
55	O	-
56	SB	-
57	Y	-
58	LG	-
59	BR	-
60	SB	-
61	R	-

Connector No.	E22
Connector Name	FRONT WHEEL SENSOR LH
Connector Type	RK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	P	-

Connector No.	E36
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	RH28FE-NJ4-DH



Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	MOTOR
2	BR	ACTR
3	B	GND A
4	B	GND M
5	BR	VDC OFF SW
6	GR	ASGD CANCEL SW
8	SB	STOP LAMP SW
9	P	CAN L

11	O	RR SENSOR VB
12	R	FR SENSOR SIG
13	B	G CHECK
14	L	G SW 1
15	SB	RR SENSOR SIG
16	BR	GND
20	Y	AMD COMM
21	G	FR SENSOR VB
22	L	CAN H
23	W	FL SENSOR VB
24	GR	DIAG K
26	BR	RL SENSOR VB
27	P	FL SENSOR SIG
28	Y	G GND
29	R	G SW 2
30	G	RL SENSOR SIG

Connector No.	E37
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	YK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	B	-

Connector No.	E39
Connector Name	FRONT WHEEL SENSOR RH
Connector Type	RK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
3	G	-
4	R	-



ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM (WITH VDC)

Connector No.	E101
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CST16-TM4



Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CST16-TM4

80	Y	-	-
81	W	-	-
82	R	-	-
83	L	-	-
88	BR	-	-
89	R	-	-
90	GR	-	-
91	R	-	-
92	O	-	-
93	BR	-	-
94	W	-	-
96	BR	-	-
97	G	-	-
99	SB	-	-
100	L	-	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	G	-
5	L	-
8	R	-
9	Y	-
12	BR	-
13	O	-
22	G	-
23	SB	-
51	GR	-
52	SHIELD	-
53	L	-
54	B	-
62	Y	-
63	R	-
96	O	-

Connector No.	E103
Connector Name	PARKING BRAKE SWITCH
Connector Type	P01FB-A



Terminal No.	1	V	-
--------------	---	---	---

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	O	-
3	LG	-
4	V	-
5	Y	-
6	G	-
7	R	-
8	GR	-
9	BR	-
10	L	-
11	GR	-
12	P	-
14	L	-
15	V	-
19	R	-
20	P	-
21	L	-
22	L	-
24	LG	-
25	SB	-
30	L	-
31	BR	-
42	Y	-
43	SHIELD	-
51	L	-
52	W	-
53	BR	-
54	Y	-
60	O	-
61	BR	-
62	R	-
63	P	-
69	G	-
70	B	-
71	O	-
72	LG	-
78	L	-
79	V	-

Connector No.	E112
Connector Name	ASC D BRAKE SWITCH
Connector Type	IM02FB-LC



Terminal No.	1	L	-
2	GR	-	-


Connector No.	E115
Connector Name	STOP LAMP SWITCH
Connector Type	IM04FW-LC



Terminal No.	1	V	-
2	Y	-	-
3	G	-	-

4	L	-
---	---	---

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
4	B	-
5	B	-
6	L	-
7	O	-
8	W	-
14	P	-
16	V	-

Connector No.	M5
Connector Name	VDC OFF SWITCH
Connector Type	TK08FGY



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	B	-
3	R	-
4	Y	-

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

BRAKE CONTROL SYSTEM (WITH VDC)

Connector No.	M30
Connector Name	STEERING ANGLE SENSOR
Connector Type	TH8BEW-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	W	IGN
3	B	GND
4	L	CAN H
8	P	CAN L


Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	TH40FV-NH



Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	BATTERY POWER SUPPLY
2	O	IGNITION SIGNAL
3	B	GROUND
4	B	GROUND
5	BR	4/C AUTO AMB CONNECTOR RECOGNITION SIGNAL
7	GR	OVERDRIVE CONTROL SWITCH SIGNAL
9	L	PADDLE SHIFTER SHIFT UP SIGNAL
10	G	PADDLE SHIFTER SHIFT DOWN SIGNAL
13	Y	ILLUMINATION CONTROL SIGNAL
15	LG	AIR BAG SIGNAL
16	O	ENGINE COOLANT TEMPERATURE SIGNAL
19	BR	AMBIENT SENSOR SIGNAL
20	SB	AMBIENT SENSOR GROUND
21	L	CAN-H
22	P	CAN-L
24	B	FUEL LEVEL SENSOR SIGNAL GROUND
25	SB	ALTERNATOR SIGNAL
26	V	PARKING BRAKE SWITCH SIGNAL

27	BR	BRAKE FLUID LEVEL SWITCH SIGNAL
28	B	SECURITY SIGNAL
29	W	WASHER LEVEL SWITCH SIGNAL
30	Y	VEHICLE SPEED SIGNAL (2-PULSE)
31	L	VEHICLE SPEED SIGNAL (8-PULSE)
34	G	FUEL LEVEL SENSOR SIGNAL
35	O	SEAT BELT BUCKLE SWITCH SIGNAL (DRIVER SIDE)
36	G	SEAT BELT BUCKLE SWITCH SIGNAL (PASSENGER SIDE)
37	P	NON-MANUAL MODE SIGNAL
38	O	MANUAL MODE SHIFT DOWN SIGNAL
39	V	MANUAL MODE SHIFT UP SIGNAL
40	LG	MANUAL MODE SIGNAL

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS 16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	
2	O	
3	LG	
4	Y	
5	Y	
6	G	
7	R	
8	GR	
9	BR	
10	L	
11	GR	
12	P	
14	SB	
15	V	
19	R	
20	P	
21	O	
22	L	
24	BR	
25	W	
30	L	
31	W	
42	O	
43	SHIELD	

Fail-Safe

ABS, EBD SYSTEM

In case of electrical malfunctions with the ABS, ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp will turn on. In case of electrical malfunctions with the EBD, brake warning lamp, ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp will turn on. Simultaneously, the VDC/TCS/ABS become one of the following conditions of the fail-safe function.

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

- For malfunction of ABS, only the EBD is activated and the condition of vehicle is the same condition of vehicles without TCS/ABS system.

NOTE:

ABS self-diagnosis sound may be heard. That is a normal condition because a self-diagnosis for "Ignition switch ON" and "The first starting" are being performed.

- For malfunction of EBD, EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without TCS/ABS, EBD system.

VDC/TCS

In case of malfunction in the VDC/TCS/ABS system, VDC OFF indicator lamp, SLIP indicator lamp are turned on, and the condition of vehicle is the same as the condition of vehicles without VDC/TCS control.

CAUTION:

If the Fail-Safe function is activated, then perform self-diagnosis for "ABS" with CONSULT-III.

DTC Index

INFOID:000000006203129

DTC	Items (CONSULT screen terms)	Reference
C1101	RR RH SENSOR-1	BRC-99, "DTC Logic"
C1102	RR LH SENSOR-1	
C1103	FR RH SENSOR-1	
C1104	FR LH SENSOR-1	
C1105	RR RH SENSOR-2	BRC-102, "DTC Logic"
C1106	RR LH SENSOR-2	
C1107	FR RH SENSOR-2	
C1108	FR LH SENSOR-2	
C1109	BATTERY VOLTAGE [ABNORMAL]	BRC-105, "DTC Logic"
C1110	CONTROLLER FAILURE	BRC-108, "DTC Logic"
C1111	PUMP MOTOR	BRC-109, "DTC Logic"
C1113	G SENSOR	BRC-111, "DTC Logic"
C1115	ABS SENSOR [ABNORMAL SIGNAL]	BRC-115, "DTC Logic"
C1116	STOP LAMP SW	BRC-118, "DTC Logic"
C1118	4WD SYSTEM	BRC-120, "DTC Logic"
C1120	FR LH IN ABS SOL	BRC-121, "DTC Logic"
C1121	FR LH OUT ABS SOL	BRC-124, "DTC Logic"
C1122	FR RH IN ABS SOL	BRC-121, "DTC Logic"
C1123	FR RH OUT ABS SOL	BRC-124, "DTC Logic"
C1124	RR LH IN ABS SOL	BRC-121, "DTC Logic"
C1125	RR LH OUT ABS SOL	BRC-124, "DTC Logic"
C1126	RR RH IN ABS SOL	BRC-121, "DTC Logic"
C1127	RR RH OUT ABS SOL	BRC-124, "DTC Logic"
C1130	ENGINE SIGNAL 1	BRC-127, "DTC Logic"
C1140	ACTUATOR RLY	BRC-128, "DTC Logic"
C1143	ST ANG SEN CIRCUIT	BRC-130, "DTC Logic"
C1144	ST ANG SEN SIGNAL	
C1145	YAW RATE SENSOR	BRC-111, "DTC Logic"
C1146	SIDE G-SEN CIRCUIT	
C1155	BR FLUID LEVEL LOW	BRC-132, "DTC Logic"
C1164	CV1	BRC-135, "DTC Logic"
C1165	CV2	

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

DTC	Items (CONSULT screen terms)	Reference
C1166	SV1	BRC-137. "DTC Logic"
C1167	SV2	
C1176	STOP LAMP SW2	BRC-139. "DTC Logic"
U1000	CAN COMM CIRCUIT	BRC-141. "DTC Logic"
U1010	CONTROL UNIT(CAN)	BRC-142. "DTC Logic"

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

SYMPTOM DIAGNOSIS

EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

Diagnosis Procedure

INFOID:000000006203130

1. CHECK START

Check front and rear brake force distribution using a brake tester. Refer to [BR-49, "General Specifications"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

2. CHECK FRONT AND REAR AXLE

Make sure that there is no excessive play in the front and rear axles.

- Front
 - 2WD models: Refer to [FAX-8, "Inspection"](#).
 - AWD models: Refer to [FAX-32, "Inspection"](#).
- Rear
 - 2WD models: Refer to [RAX-4, "Inspection"](#).
 - AWD models: Refer to [RAX-11, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

3. CHECK WHEEL SENSOR AND SENSOR ROTOR

Check the following.

- Wheel sensor installation for damage.
- Sensor rotor installation for damage.
- Wheel sensor connector connection.
- Wheel sensor harness inspection.

Is the inspection result normal?

YES >> GO TO 4.

NO >>

- Replace wheel sensor or sensor rotor.
- Repair harness.

4. CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned off after the ignition switch is turned ON or when driving.

Is the ABS warning lamp illuminated?

YES >> Perform self-diagnosis for "ABS" with CONSULT-III.

NO >> Normal

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

UNEXPECTED PEDAL REACTION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

UNEXPECTED PEDAL REACTION

Diagnosis Procedure

INFOID:000000006203131

1.CHECK BRAKE PEDAL STROKE

Check brake pedal stroke. Refer to [BR-9, "Inspection and Adjustment"](#).

Is the stroke too large?

- YES >>
- Bleed air from brake tube and hose. Refer to [BR-13, "Bleeding Brake System"](#).
 - Check brake pedal, brake booster, and master cylinder for mount play, looseness, brake system fluid leakage, etc.
 - Brake pedal: Refer to [BR-9, "Inspection and Adjustment"](#).
 - Master cylinder: Refer to [BR-14, "Inspection"](#).
 - Brake booster: Refer to [BR-15, "Inspection"](#).

NO >> GO TO 2.

2.CHECK FUNCTION

Disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. Check if braking force is normal in this condition. Connect connector after inspection.

Is the inspection result normal?

- YES >> Normal
NO >> Check brake system.

THE BRAKING DISTANCE IS LONG

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

THE BRAKING DISTANCE IS LONG

Diagnosis Procedure

INFOID:000000006203132

CAUTION:

The stopping distance on slippery road surfaces might be longer with the ABS operating than when the ABS is not operating.

1.CHECK FUNCTION

Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. In this condition, check stopping distance. After inspection, connect connector.

Is the inspection result normal?

YES >> Normal

NO >> Check brake system.

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

ABS FUNCTION DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000006203133

CAUTION:

ABS does not operate when speed is 10 km/h (6 MPH) or lower.

1.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp turns OFF after ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis for "ABS" with CONSULT-III.

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

Diagnosis Procedure

INFOID:000000006203134

CAUTION:

Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Inspect the brake pedal.

2. SYMPTOM CHECK 2

Check that there are ABS operation noises when the engine is started.

Do the operation noises occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis for "ABS" with CONSULT-III.

3. SYMPTOM CHECK 3

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Do symptoms occur?

YES >> Check if there is a radio, antenna, antenna lead wire, or wiring close to the control unit. If there is, move it farther away.

NO >> Normal

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

Diagnosis Procedure

INFOID:000000006203135

1.SYMPTOM CHECK

Check if the vehicle jerks during VDC/TCS/ABS control.

Is the inspection result normal?

- YES >> Normal.
- NO >> GO TO 2.

2.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Are self-diagnosis results indicated?

- YES >> Check corresponding items, make repairs, and perform self-diagnosis for "ABS" with CONSULT-III.
- NO >> GO TO 3.

3.CHECK CONNECTOR

- Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector and check terminal for deformation, disconnection, looseness, etc.
- Securely connect connectors and perform self-diagnosis for "ABS" with CONSULT-III.

Are self-diagnosis results indicated?

- YES >> If poor contact, damage, open or short circuit of connector terminal is found, repair or replace.
- NO >> GO TO 4.

4.CHECK ECM AND TCM SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ENGINE" and "TRANSMISSION" with CONSULT-III.

Are self-diagnosis results indicated?

- YES >> Check the corresponding items.
 - "ENGINE"
 - For CALIFORNIA: Refer to [EC-116, "CONSULT-III Function"](#).
 - For USA (FEDERAL) and CANADA: Refer to [EC-597, "CONSULT-III Function"](#).
 - For MEXICO: Refer to [EC-1029, "CONSULT-III Function"](#).
 - "TRANSMISSION": Refer to [TM-42, "Diagnosis Description"](#).
- NO >> Replace ABS actuator and electric unit (control unit).

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

NORMAL OPERATING CONDITION

Description

INFOID:000000006203136

Symptom	Result
Slight vibrations are felt on the brake pedal and the operation noises occur, when VDC, TCS or ABS is activated.	This is a normal condition due to the VDC, TCS or ABS activation.
Stopping distance is longer than that of vehicles without ABS when the vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.	
The brake pedal moves and generates noises, when TCS or VDC is activated due to rapid acceleration or sharp turn.	
The brake pedal vibrates and motor operation noises occur from the engine room, after the engine starts and just after the vehicle starts.	This is a normal, and it is caused by the ABS operation check.
Depending on the road conditions, the driver may experience a sluggish feel.	This is normal, because TCS places the highest priority on the optimum traction (stability).
TCS may activate momentarily if wheel speed changes when driving over location where friction coefficient varies, when downshifting, or when fully depressing accelerator pedal.	
The ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp may turn ON when the vehicle is subject to strong shaking or large vibration, such as when the vehicle is rotating on a turntable or located on a ship while the engine is running.	In this case, restart the engine on a normal road. If the normal condition is restored, there is no malfunction. At that time, erase the self-diagnosis memory.
VDC may not operate normally or the ABS warning lamp, VDC OFF indicator lamp, and SLIP indicator lamp may illuminate, when running on a special road that is extremely slanted (e.g. bank in a circuit course).	
A malfunction may occur in the yaw rate/side G sensor system, when the vehicle turns sharply, such as during a spin turn, axle turn, or drift driving, while the VDC function is off (VDC OFF indicator lamp illuminated).	
The vehicle speed will not increase even though the accelerator pedal is depressed, when inspecting the speedometer on a 2-wheel chassis dynamometer.	Normal (Deactivate the VDC/TCS function before performing an inspection on a chassis dynamometer.)

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

PRECAUTION

PRECAUTIONS
FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006444924

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR USA AND CANADA : Precaution for Procedure without Cowl Top Cover

INFOID:000000006445133

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



FOR USA AND CANADA : Precaution for Brake System

INFOID:000000006203139

WARNING:

Clean any dust from the front brake and rear brake with a vacuum dust collector. Never blow with compressed air.


- Brake fluid use refer to [MA-15, "FOR NORTH AMERICA : Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.

PRECAUTIONS

< PRECAUTION >

[VDC/TCS/ABS]

- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crowfoot (A) and torque wrench (B).
-
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



FOR USA AND CANADA : Precaution for Brake Control

INFOID:000000006203140

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.
- VDC system may not operate normally or a VDC OFF indicator lamp or SLIP indicator lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

FOR USA AND CANADA : Precautions for Harness Repair


INFOID:000000006203141

COMMUNICATION LINE

- Solder the repaired area and wrap tape around the soldered area.

NOTE:

A fray of twisted lines must be within 110 mm (4.33 in).



PRECAUTIONS


[VDC/TCS/ABS]

< PRECAUTION >

- Bypass connection is never allowed at the repaired area.

NOTE:

- Bypass connection may cause communication error as spliced wires that are separate from the main line or twisted lines lose noise immunity.
- Replace the applicable harness as an assembly if error is detected on the shield lines of communication line.



FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000006444925

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


WARNING:

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR MEXICO : Precaution for Procedure without Cowl Top Cover

INFOID:000000006445134

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



FOR MEXICO : Precaution for Brake System

INFOID:000000006445155

WARNING:

Clean any dust from the front brake and rear brake with a vacuum dust collector. Never blow with compressed air.


- Brake fluid use refer to [MA-16, "FOR MEXICO : Fluids and Lubricants"](#).

PRECAUTIONS

[VDC/TCS/ABS]

< PRECAUTION >

- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crowfoot (A) and torque wrench (B).
-
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



FOR MEXICO : Precaution for Brake Control

INFOID:000000006203145

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.
- VDC system may not operate normally or a VDC OFF indicator lamp or SLIP indicator lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

FOR MEXICO : Precautions for Harness Repair


INFOID:000000006203146

COMMUNICATION LINE

- Solder the repaired area and wrap tape around the soldered area.

NOTE:

A fray of twisted lines must be within 110 mm (4.33 in).



PRECAUTIONS


[VDC/TCS/ABS]

< PRECAUTION >

- Bypass connection is never allowed at the repaired area.

NOTE:

- Bypass connection may cause communication error as spliced wires that are separate from the main line or twisted lines lose noise immunity.
- Replace the applicable harness as an assembly if error is detected on the shield lines of communication line.




REMOVAL AND INSTALLATION

WHEEL SENSOR

FRONT WHEEL SENSOR

FRONT WHEEL SENSOR : Exploded View

INFOID:000000006203147



1. Front LH wheel sensor

A. Yellow line (slant line)

Refer to [GI-4, "Components"](#) for symbol in the figure.

NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

FRONT WHEEL SENSOR : Removal and Installation

INFOID:000000006203148

REMOVAL

Pay attention to the following when removing sensor.

CAUTION:

- **Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.**
- **Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.**
- **When you see the harness of the wheel sensor from the front side of the vehicle ensure that the yellow lines (A) are not twisted.**

INSTALLATION

Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

REAR WHEEL SENSOR

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P


WHEEL SENSOR

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

REAR WHEEL SENSOR : Exploded View

INFOID:000000006203149



1. Rear LH wheel sensor

A. 2WD models

B. AWD models

Refer to [GI-4, "Components"](#) for symbol in the figure.

NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

REAR WHEEL SENSOR : Removal and Installation

INFOID:000000006203150

REMOVAL

Pay attention to the following when removing sensor.

CAUTION:

- **Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.**
- **Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.**

INSTALLATION

Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

SENSOR ROTOR

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

SENSOR ROTOR

FRONT SENSOR ROTOR

FRONT SENSOR ROTOR : Exploded View

INFOID:000000006203151

Refer to [FAX-10. "Exploded View"](#) (2WD models), [FAX-34. "Exploded View"](#) (AWD models).

FRONT SENSOR ROTOR : Removal and Installation

INFOID:000000006203152

REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [FAX-10. "Removal and Installation"](#) (2WD models), [FAX-34. "Removal and Installation"](#) (AWD models).

INSTALLATION

Sensor rotor cannot be disassembled. Installation the sensor rotor together with hub bearing assembly. Refer to [FAX-10. "Removal and Installation"](#) (2WD models), [FAX-34. "Removal and Installation"](#) (AWD models).

REAR SENSOR ROTOR

REAR SENSOR ROTOR : Exploded View

INFOID:000000006203153

Refer to [RAX-5. "Exploded View"](#) (2WD models), [RAX-15. "Exploded View"](#) (AWD models).

REAR SENSOR ROTOR : Removal and Installation

INFOID:000000006203154

2WD MODELS

Removal

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [RAX-5. "Removal and Installation"](#).

Installation

Sensor rotor cannot be disassembled. Installation the sensor rotor together with hub bearing assembly. Refer to [RAX-5. "Removal and Installation"](#).

AWD MODELS

For removal and installation of sensor rotor, refer to [RAX-16. "Disassembly and Assembly"](#).

A
B
C
D
E
BRC
G
H
I
J
K
L
M
N
O
P

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Exploded View

INFOID:000000006203155



- | | | |
|--|--------------------------------------|--|
| 1. ABS actuator and electric unit (control unit) | 2. Connector | 3. Bracket |
| A. To front LH brake caliper | B. To rear RH brake caliper | C. To Rear LH brake caliper |
| D. To front RH brake caliper | E. From master cylinder primary side | F. From master cylinder secondary side |

↔: Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

Removal and Installation

INFOID:000000006203156

REMOVAL

CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-13, "Bleeding Brake System"](#).

1. Remove cowl top. Refer to [EXT-20, "Exploded View"](#).
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Loosen brake tube flare nuts, then remove brake tubes from ABS actuator and electric unit (control unit).
4. Remove tire (front LH side).
5. Remove fender protector (rear): (front LH side). Refer to [EXT-22, "Exploded View"](#).
6. Remove ABS actuator and electric unit (control unit) bracket mounting nut.
7. Remove ABS actuator and electric unit (control unit) from vehicle.

INSTALLATION

ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

Note the following, and install in the reverse order of removal.

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-13, "Bleeding Brake System"](#).
- After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.
- When replacing ABS actuator and electric unit (control unit), make sure adjust neutral position of steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

A
B
C
D
E

BRC

G
H
I
J
K
L
M
N
O
P

G SENSOR


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

G SENSOR

Exploded View

INFOID:000000006203157



1. yaw rate/side/decel G sensor
2. Bracket

↔ Vehicle front

Refer to [GI-4. "Components"](#) for symbol in the figure.

Removal and Installation

INFOID:000000006203158

REMOVAL

CAUTION:

Never drop or strike yaw rate/side/decel G sensor, or never use power tool etc., because yaw rate/side/decel G sensor is sensitive to the impact.

1. Remove center console assembly. Refer to [IP-22. "Exploded View"](#).
2. Disconnect yaw rate/side/decel G sensor harness connector.
3. Remove mounting bolts. Remove yaw rate/side/decel G sensor.

INSTALLATION

Note the following, and install in the reverse order of removal.

- Never drop or strike yaw rate/side/decel G sensor, or never use power tool etc., because yaw rate/side/decel G sensor is sensitive to the impact.

STEERING ANGLE SENSOR


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

STEERING ANGLE SENSOR

Exploded View

INFOID:000000006203159



1. Steering angle sensor

↔: Vehicle front

Removal and Installation

INFOID:000000006203160

REMOVAL

1. Remove spiral cable assembly. Refer to [SR-14. "Exploded View"](#) (for USA and Canada), [SR-39. "Exploded View"](#) (for Mexico).
2. Remove steering angle sensor from spiral cable assembly.

INSTALLATION

Note the following, and install in the reverse order of removal.

- After work, make sure to adjust neutral position of steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

A
B
C
D
E
G
H
I
J
K
L
M
N
O
P

BRC