

MWI

SECTION

METER, WARNING LAMP & INDICATOR

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

CONTENTS

| | | | |
|---|----|---|----|
| PRECAUTION | 3 | ENGINE COOLANT TEMPERATURE GAUGE : | |
| PRECAUTIONS | 3 | System Description | 12 |
| FOR USA AND CANADA | 3 | FUEL GAUGE | 13 |
| FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 3 | FUEL GAUGE : System Diagram | 13 |
| FOR MEXICO | 3 | FUEL GAUGE : System Description | 13 |
| FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 3 | OIL PRESSURE WARNING LAMP | 13 |
| PREPARATION | 5 | OIL PRESSURE WARNING LAMP : System Diagram | 13 |
| PREPARATION | 5 | OIL PRESSURE WARNING LAMP : System Description | 13 |
| Commercial Service Tools | 5 | MASTER WARNING LAMP | 14 |
| SYSTEM DESCRIPTION | 6 | MASTER WARNING LAMP : System Diagram | 14 |
| COMPONENT PARTS | 6 | MASTER WARNING LAMP : System Description | 14 |
| Component Parts Location | 6 | METER ILLUMINATION CONTROL | 14 |
| Component Description | 7 | METER ILLUMINATION CONTROL : System Diagram | 14 |
| SYSTEM (METER SYSTEM) | 8 | METER ILLUMINATION CONTROL : System Description | 14 |
| METER SYSTEM | 8 | INFORMATION DISPLAY | 15 |
| METER SYSTEM : System Diagram | 8 | INFORMATION DISPLAY : System Diagram | 15 |
| METER SYSTEM : System Description | 8 | INFORMATION DISPLAY : System Description | 15 |
| METER SYSTEM : Fail-safe | 11 | SYSTEM (COMPASS) | 24 |
| SPEEDOMETER | 11 | System Description | 24 |
| SPEEDOMETER : System Diagram | 12 | DIAGNOSIS SYSTEM (COMBINATION METER) | 25 |
| SPEEDOMETER : System Description | 12 | On Board Diagnosis Function | 25 |
| TACHOMETER | 12 | CONSULT Function | 27 |
| TACHOMETER : System Diagram | 12 | ECU DIAGNOSIS INFORMATION | 32 |
| TACHOMETER : System Description | 12 | COMBINATION METER | 32 |
| ENGINE COOLANT TEMPERATURE GAUGE | 12 | Reference Value | 32 |
| ENGINE COOLANT TEMPERATURE GAUGE : System Diagram | 12 | Fail-safe | 39 |
| | | DTC Index | 40 |
| | | IPDM E/R | 41 |

MWI

| | | | |
|---|-----------|---|-----------|
| List of ECU Reference | 41 | Component Function Check | 56 |
| WIRING DIAGRAM | 42 | Diagnosis Procedure | 56 |
| METER SYSTEM | 42 | Component Inspection | 57 |
| Wiring Diagram | 42 | OIL PRESSURE SWITCH SIGNAL CIRCUIT ... | 60 |
| COMPASS | 45 | Component Function Check | 60 |
| Wiring Diagram | 45 | Diagnosis Procedure | 60 |
| BASIC INSPECTION | 46 | Component Inspection | 60 |
| DIAGNOSIS AND REPAIR WORKFLOW | | AMBIENT SENSOR SIGNAL CIRCUIT | 62 |
| (METER SYSTEM) | 46 | Diagnosis Procedure | 62 |
| Work flow | 46 | Component Inspection | 62 |
| ZONE VARIATION SETTING (COMPASS) | 48 | A/C AUTO AMP. CONNECTION RECOGNITION | |
| Work Procedure | 48 | SIGNAL CIRCUIT | 63 |
| CALIBRATION (COMPASS) | 49 | Diagnosis Procedure | 63 |
| Work Procedure | 49 | SYMPTOM DIAGNOSIS | 64 |
| DTC/CIRCUIT DIAGNOSIS | 50 | THE FUEL GAUGE DOES NOT MOVE | 64 |
| U1000 CAN COMM CIRCUIT | 50 | Description | 64 |
| Description | 50 | Diagnosis Procedure | 64 |
| DTC Logic | 50 | THE OIL PRESSURE WARNING LAMP | |
| Diagnosis Procedure | 50 | DOES NOT TURN ON | 65 |
| U1010 CONTROL UNIT (CAN) | 51 | Description | 65 |
| Description | 51 | Diagnosis Procedure | 65 |
| DTC Logic | 51 | THE OIL PRESSURE WARNING LAMP | |
| Diagnosis Procedure | 51 | DOES NOT TURN OFF | 66 |
| B2205 VEHICLE SPEED | 52 | Description | 66 |
| Description | 52 | Diagnosis Procedure | 66 |
| DTC Logic | 52 | THE AMBIENT TEMPERATURE DISPLAY IS | |
| Diagnosis Procedure | 52 | INCORRECT | 67 |
| B2267 ENGINE SPEED | 53 | Description | 67 |
| Description | 53 | Diagnosis Procedure | 67 |
| DTC Logic | 53 | NORMAL OPERATING CONDITION | 68 |
| Diagnosis Procedure | 53 | INFORMATION DISPLAY | 68 |
| B2268 WATER TEMP | 54 | INFORMATION DISPLAY : Description | 68 |
| Description | 54 | REMOVAL AND INSTALLATION | 69 |
| DTC Logic | 54 | COMBINATION METER | 69 |
| Diagnosis Procedure | 54 | Exploded View | 69 |
| POWER SUPPLY AND GROUND CIRCUIT | 55 | Removal and Installation | 69 |
| COMBINATION METER | 55 | Disassembly and Assembly | 69 |
| COMBINATION METER : Diagnosis Procedure ... | 55 | COMPASS | 71 |
| FUEL LEVEL SENSOR SIGNAL CIRCUIT | 56 | Exploded View | 71 |
| | | Removal and Installation | 71 |

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007350280

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007350281

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

PRECAUTIONS

< PRECAUTION >

Always observe the following items for preventing accidental activation.

- **When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.**
- **When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.**

PREPARATION


< PREPARATION >

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000007350282

| Tool name | Description |
|--|-------------------------|
| <p>Power tool</p>  <p>PBIC0191E</p> | <p>Loosening screws</p> |

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

COMPONENT PARTS


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

COMPONENT PARTS

Component Parts Location

INFOID:000000007350283



JSNIA3498ZZ

COMPONENT PARTS

< SYSTEM DESCRIPTION >

- | | | | |
|----------------------------------|----------------------------------|--|---|
| 1. Fuel level sensor unit (main) | 2. Auto amp. | 3. ABS actuator and electric unit (control unit) | A |
| 4. BCM | 5. Oil pressure switch | 6. Washer level switch | |
| 7. Ambient sensor | 8. ECM | 9. TCM | B |
| 10. IPDM E/R | 11. Combination meter | 12. Fuel level sensor unit (sub) | |
| A. Lower right side of rear seat | B. Left side of engine room | C. Over the glove box | |
| D. Left side of engine room | E. Behind of front bumper center | F. Right side of engine room | C |
| G. Right side of engine room | H. Lower left side of rear seat | | |

Component Description

INFOID:000000007350284

| Unit | Description | |
|---|---|-----|
| Combination meter | Controls the following with the signals received from each unit via CAN communication and the signals from switches and sensors. <ul style="list-style-type: none"> • Speedometer • Tachometer • Engine coolant temperature gauge • Fuel gauge • Warning lamps • Indicator lamps • Meter illumination control • Information display | E |
| ECM | Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Engine speed signal • Engine coolant temperature signal • Fuel consumption monitor signal • Fuel filler cap warning display signal | H |
| ABS actuator and electric unit (control unit) | Transmits the vehicle speed signal to the combination meter via CAN communication. | I |
| IPDM E/R | Transmits the oil pressure switch signal to the BCM via CAN communication. | J |
| BCM | Transmits the following signals to the combination meter via CAN communication. <ul style="list-style-type: none"> • Oil pressure switch signal • Position light request signal • Door switch signal • Low tire pressure warning lamp signal | K |
| TCM | Transmits the shift position signal to the combination meter via CAN communication. | L |
| CVT shift selector (with manual mode) | Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Manual mode signal • Non-manual mode signal • Manual mode shift up signal • Manual mode shift down signal | M |
| Paddle shifter | Transmits the following signals to the combination meter. <ul style="list-style-type: none"> • Paddle shifter shift up signal • Paddle shifter shift down signal | MWI |
| Fuel level sensor unit | Transmits the fuel level sensor signal to the combination meter. | |
| Oil pressure switch | Transmits the oil pressure switch signal to the IPDM E/R. | O |
| Ambient sensor | Transmits the ambient sensor signal to the combination meter. | |
| Auto amp. | Transmits the A/C auto amp connection recognition signal to the combination meter. | |
| Parking brake switch | Transmits the parking brake switch signal to the combination meter. | P |
| Washer level switch | Transmits the washer level switch signal to the combination meter. | |

SYSTEM (METER SYSTEM)


< SYSTEM DESCRIPTION >

SYSTEM (METER SYSTEM)

METER SYSTEM

METER SYSTEM : System Diagram

INFOID:000000007350285



METER SYSTEM : System Description

INFOID:000000007350286

COMBINATION METER

- The combination meter receives necessary signals from each unit, switch, and sensor to control the following functions.
 - Measuring instruments
 - Warning lamps
 - Indicator lamps
 - Meter illumination control
 - Information display
- The combination meter incorporates a buzzer function that sounds an audible alarm with the integrated buzzer device. Refer to [WCS-5. "WARNING CHIME SYSTEM : System Description"](#) for further details.
- The combination meter includes an on board diagnosis function.
- The combination meter can be diagnosed with CONSULT.

METER CONTROL FUNCTION LIST

SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

| System | | Description | Reference | |
|-----------------------------|----------------------------------|--|---|------------------------------------|
| Measuring instruments | Speedometer | Indicates vehicle speed. | MWI-12, "SPEEDOMETER : System Description" | |
| | Tachometer | Indicates engine speed. | MWI-12, "TACHOMETER : System Description" | |
| | Engine coolant temperature gauge | Indicates engine coolant temperature. | MWI-12, "ENGINE COOLANT TEMPERATURE GAUGE : System Description" | |
| | Fuel gauge | Indicates fuel level. | MWI-13, "FUEL GAUGE : System Description" | |
| Warning lamp/indicator lamp | Oil pressure warning lamp | The warning lamp turns ON or turns OFF, according to engine hydraulic pressure. | MWI-13, "OIL PRESSURE WARNING LAMP : System Description" | |
| | Master warning lamp | Turns ON/OFF in synchronization with a warning indicated on the information display. | MWI-14, "MASTER WARNING LAMP : System Description" | |
| Meter illumination control | | Switches back and forth between daytime mode and nighttime mode, according to a light switch position. | MWI-14, "METER ILLUMINATION CONTROL : System Description" | |
| Information display | Odo/trip meter | Displays mileage. | MWI-15, "INFORMATION DISPLAY : System Description" | |
| | Shift position indicator | Displays shift position. | | |
| | Clock | Displays time. | | |
| | Trip computer | Current fuel consumption | | Displays current fuel consumption. |
| | | Average fuel consumption | | Displays average fuel consumption. |
| | | Range (Distance to empty) | | Displays distance to empty. |
| | | Average vehicle speed | | Displays average vehicle speed. |
| | | Elapsed time | | Displays elapsed time. |
| Driving distance | Displays mileage. | | | |
| Outside temperature | Displays outside temperature. | | | |

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

| System | | Description | Reference |
|---------------------|----------------------------|---------------------------------|---|
| Information display | Warning | Door open warning | Warns when a door is open. |
| | | Parking brake release warning | Warns if traveling when the parking brake is under operating condition. |
| | | Low fuel warning | Warns when being low on fuel. |
| | | Low washer fluid warning | Displayed/Hidden, depending on washer fluid level. |
| | | Low tire pressure warning | Warns, according to tire inflation pressure. |
| | | Fuel filler cap warning | Warns, according to the tightening condition of fuel filler cap. |
| | Alert | Driver alert | Causes an interrupt when exceeding randomly set time. |
| | | Low ambient temperature | Causes an interrupt when ambient temperature reaches below 3°C (37°F). |
| | Maintenance | Service | Causes an interrupt when exceeding randomly set distance. |
| | | Tire | Causes an interrupt when exceeding randomly set distance. |
| | | Other | Causes an interrupt when exceeding randomly set distance. |
| | Meter illumination control | | Indicates the brightness of the meter illumination in stages. |
| | Settings | Clock | Clock-related items can be set. |
| | | Units | Unit can be set. |
| | | Maintenance | Maintenance-related items can be set. |
| Alarm | | Alarm-related items can be set. | |
| Language | | Language can be selected. | |
| Factory | | Settings can be reset. | |


[MWI-15. "INFORMATION DISPLAY : System Description"](#)

[WT-9. "System Description"](#)

[EC-94. "System Description"](#)

[MWI-15. "INFORMATION DISPLAY : System Description"](#)

ARRANGEMENT OF COMBINATION METER



A. For U.S.A.

B. Except for U.S.A.

SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

METER SYSTEM : Fail-safe

INFOID:000000007547333

The combination meter activates the fail-safe control if the CAN communication lines between each unit are malfunctioning.

| Function | | Specifications | |
|----------------------------------|---|---|---|
| Speedometer | | Reset to zero by suspending communication. | |
| Tachometer | | | |
| Engine coolant temperature gauge | | | |
| Meter illumination control | | When suspending communication, changes to nighttime mode. | |
| Buzzer | | Turned off by suspending communication. | |
| Information display | Trip computer | Current fuel consumption | <ul style="list-style-type: none"> When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result. When reception time of an abnormal signal is more than 2 seconds, the last result calculated during normal condition is indicated. |
| | | Average fuel consumption | |
| | | Average vehicle speed | |
| | | Range (Distance to empty) | |
| | | Driving distance | |
| | Interrupt indication | Door open warning | The indicator turns OFF by suspending communication. |
| | | Low tire pressure warning | |
| | | Fuel filler cap warning | |
| | Odo/trip meter | | An indicated value is maintained at communications blackout. |
| | Shift position indicator | | The indicator turns OFF by suspending communication. |
| Warning lamp/indicator lamp | ABS warning lamp | Turned on by suspending communication. | |
| | Brake warning lamp | | |
| | EPS warning lamp | | |
| | VDC warning lamp | | |
| | AWD warning lamp | | |
| | Malfunction indicator lamp | | |
| | VDC OFF indicator lamp | Turned off by suspending communication. | |
| | SPORT mode indicator lamp | | |
| | AWD LOCK indicator lamp | | |
| | Oil pressure warning lamp | | |
| | High beam indicator lamp | | |
| | Turn signal indicator lamp | | |
| | Position lamp indicator lamp | | |
| | A/T CHECK indicator lamp | | |
| | OD OFF indicator lamp | | |
| Low tire pressure warning lamp | After blinking for 1 minute, the lamp remains ON. | | |


SPEEDOMETER

SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

SPEEDOMETER : System Diagram

INFOID:000000007350288



SPEEDOMETER : System Description


INFOID:000000007350289

- The ABS actuator and electric unit (control unit) converts the rectangular wave signal provided by the wheel sensor to a vehicle speed signal and transmits it to the combination meter via CAN communication.
- The combination meter indicates the vehicle speed to the speedometer according to the vehicle speed signal received via CAN communication.

TACHOMETER

TACHOMETER : System Diagram

INFOID:000000007350290



TACHOMETER : System Description


INFOID:000000007350291

- ECM converts the pulse signal provided by the crankshaft position sensor to an engine speed signal and transmits it to the combination meter via CAN communication.
- The combination meter indicates the engine speed to the tachometer according to the engine speed signal received via CAN communication.

ENGINE COOLANT TEMPERATURE GAUGE

ENGINE COOLANT TEMPERATURE GAUGE : System Diagram

INFOID:000000007350292



ENGINE COOLANT TEMPERATURE GAUGE : System Description

INFOID:000000007350293

- ECM reads the engine coolant temperature signal from the engine coolant temperature sensor and transmits the signal to the combination meter via CAN communication.
- The combination meter indicates the engine coolant temperature to the engine coolant temperature gauge according to the engine coolant temperature signal received via CAN communication.

SYSTEM (METER SYSTEM)


< SYSTEM DESCRIPTION >

FUEL GAUGE


FUEL GAUGE : System Diagram

INFOID:000000007350294

2WD MODELS FOR NORTH AMERICA



AWD MODELS FOR NORTH AMERICA/FOR MEXICO



FUEL GAUGE : System Description

INFOID:000000007350295

CONTROL OUTLINE

The combination meter reads the fuel level sensor signal from the fuel level sensor unit and indicates the fuel level to the fuel gauge.

REFUEL CONTROL


The combination meter accelerates the fuel gauge segment if the all conditions listed below are met, or the ignition switch is ON from OFF.

- Ignition switch is ON position.
- The vehicle is not moving.
- The fuel level change by 15 ℓ (4 US gal, 3-1/4 Imp gal) or more.

OIL PRESSURE WARNING LAMP

OIL PRESSURE WARNING LAMP : System Diagram

INFOID:000000007350296



OIL PRESSURE WARNING LAMP : System Description

INFOID:000000007350297

- IPDM E/R receives an oil pressure switch signal from the oil pressure switch and transmits the signal to BCM via CAN communication.
- BCM transmits the oil pressure switch signal received from IPDM E/R to the combination meter via CAN communication.

A
B
C
D
E
F
G
H
I
J
K
L
M
P

MWI


SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

- The combination meter turns ON/OFF the oil pressure warning lamp, according to an oil pressure switch signal received from BCM via CAN communication.

MASTER WARNING LAMP

MASTER WARNING LAMP : System Diagram



MASTER WARNING LAMP : System Description

INFOID:000000007350299

When receiving a signal from each unit, switch, or sensor, the combination meter turns ON/OFF the master warning lamp in synchronization with the following warnings on the information display.

- Door open warning
- NO KEY warning
- Parking brake release warning
- Low fuel warning
- Low tire pressure warning
- Low washer fluid warning
- Fuel filler cap warning


NOTE:

For details on warnings displayed on the information display, refer to [MWI-15. "INFORMATION DISPLAY : System Description"](#).

METER ILLUMINATION CONTROL

METER ILLUMINATION CONTROL : System Diagram

INFOID:000000007350300



METER ILLUMINATION CONTROL : System Description

INFOID:000000007350301

METER ILLUMINATION CONTROL FUNCTION

- Combination meter controls meter illumination, based on the following signal.
 - Position light request signal
- The operation of the illumination control switch allows the brightness adjustment of meter illumination.

SYSTEM (METER SYSTEM)


< SYSTEM DESCRIPTION >

| | |
|--------------------|--------------------------------|
| Meter illumination | The number of adjustable steps |
| Daytime | Not adjustable |
| Nighttime | 22 step |

INFORMATION DISPLAY

INFORMATION DISPLAY : System Diagram

INFOID:000000007350302



INFORMATION DISPLAY : System Description


INFOID:000000007350303

DESCRIPTION

- The combination meter receives signals necessary for controlling the operation of the information display from each unit, sensor and switch.
- The combination meter incorporates a trip computer that displays the warning/information according to the information received from each unit, sensor and switch.
- The combination meter shows the following functions on the information display.
 - Odo/trip meter
 - Shift position indicator
 - Clock
 - Trip computer
 - Interrupt indication
 - Settings

ODO/TRIP METER

The combination meter calculates mileage, based on the following signals and displays the mileage on the information display.

| Signal name | Signal path |
|----------------------|---|
| Ignition signal | — |
| Vehicle speed signal | ABS actuator and electric unit (control unit)  Combination meter |

SHIFT POSITION INDICATOR

Manual Mode

WHEN OPERATED WITH CVT SHIFT SELECTOR


1. The combination meter receives the following signal and transmits the signal to TCM via CAN communication.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P


MWI

SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

| Signal name | Signal path |
|-------------------------------|--|
| Manual mode signal | CVT shift selector → Combination meter  TCM |
| Non-manual mode signal | |
| Manual mode shift up signal | |
| Manual mode shift down signal | |


2. TCM judges a shift position, based on a signal received from the combination meter via CAN communication and transmits the following signals to the combination meter via CAN communication.

| Signal name | Signal path |
|-----------------------|---|
| Shift position signal | TCM  Combination meter |


3. The combination meter activates the shift position indicator, and manual mode information, based on signals received from TCM via CAN communication.

WHEN OPERATED WITH PADDLE SHIFTER

1. The combination meter receives the following signal and transmits the signal to TCM via CAN communication.

| Signal name | Signal path |
|----------------------------------|--|
| Paddle shifter shift up signal | Paddle shifter → Combination meter  TCM |
| Paddle shifter shift down signal | |

2. TCM judges a shift position and manual mode information, based on a signal received from the combination meter via CAN communication and transmits the following signals to the combination meter via CAN communication.

| Signal name | Signal path |
|-----------------------|---|
| Shift position signal | TCM  Combination meter |

3. The combination meter activates the shift position indicator based on signal received from TCM via CAN communication.



Non-manual Mode

- Combination meter inputs non-manual mode signal from CVT shift selector (manual mode switch), and transmits the signals to TCM with CAN communication line.
- TCM transmits shift position signal to combination meter with CAN communication line.
- Combination meter indicates shift position when receiving shift position signal.

TRIP COMPUTER

Current Fuel Consumption

The combination meter calculates current fuel consumption based on the following signals, and the calculated value is displayed on the information display.

| Signal name | Signal path |
|---------------------------------|---|
| Ignition signal | — |
| Fuel consumption monitor signal | ECM  Combination meter |
| Vehicle speed signal | ABS actuator and electric unit (control unit)  Combination meter |

NOTE:



- Current fuel consumption on the information display is updated approximately every 0.1 seconds.
- Current fuel consumption on the information display shows 0 l/100km (0 mpg) when vehicle speed is 0 km/h (0 MPH).

SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

Average Fuel Consumption

The combination meter calculates average fuel consumption based on the following signals, and the calculated value is displayed on the information display.




| Signal name | Signal path |
|---------------------------------|---|
| Ignition signal | — |
| Fuel consumption monitor signal | ECM  → Combination meter |
| Vehicle speed signal | ABS actuator and electric unit (control unit)  → Combination meter |

NOTE:

- Average fuel consumption on the information display is updated approximately every 30 seconds.
- Soon after a reset or when the ignition switch is turned ON right after battery removal and installation, “—” is displayed until after a travel of 30 seconds and approximately 500 m (0.31 mile).
- The numerical figure following after “φ” indicated on the vehicle information display shows average fuel consumption.

Range (Distance to Empty)

The combination meter calculates range based on the following signals, and the calculated value is displayed on the information display.


| Signal name | Signal path |
|---------------------------------|---|
| Ignition signal | — |
| Fuel level sensor signal | Fuel level sensor unit  → Combination meter |
| Fuel consumption monitor signal | ECM  → Combination meter |
| Vehicle speed signal | ABS actuator and electric unit (control unit)  → Combination meter |

NOTE:

- Distance to empty on the information display is updated approximately every 30 seconds.
- When the ignition switch is turned from OFF to ON, “—” is displayed until after a travel of approximately 500 m (0.31 mile).
- The indicated values may not match each other when refueling with the ignition switch ON.

Average Vehicle Speed

The combination meter calculates average vehicle speed based on the following signals, and the calculated value is displayed on the information display.

| Signal name | Signal path |
|----------------------|---|
| Ignition signal | — |
| Vehicle speed signal | ABS actuator and electric unit (control unit)  → Combination meter |

NOTE:

- Average vehicle speed on the information display is updated approximately every 30 seconds.
- Soon after a reset or when the ignition switch is turned ON right after battery removal and installation, “—” is displayed until after a 30 seconds.

Elapsed Time


The combination meter measures and displays elapsed time (ignition switch ON time).

Driving Distance

The combination meter calculates mileage, based on the following signals and displays the mileage on the information display.



SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

| Signal name | Signal path |
|----------------------|---|
| Ignition signal | — |
| Vehicle speed signal | ABS actuator and electric unit (control unit)  → Combination meter |

Outside Temperature

- The combination meter corrects an indicated temperature, based on various signals.
- The combination meter calculates outside temperature based on the following signals, and the calculated value is displayed on the information display.

| Signal name | Signal path |
|-----------------------|---|
| Ignition signal | — |
| Ambient sensor signal | Ambient sensor  → Combination meter |
| Vehicle speed signal | ABS actuator and electric unit (control unit)  → Combination meter |

Correction Process (Temperature indicated soon after the ignition switch ON)

- A temperature indicated soon after the ignition switch is turned ON depends on the time from the ignition switch OFF to ON and a temperature detected by the ambient sensor.

When any condition described below is met, an ambient sensor-detected temperature is indicated.

- Time from the ignition switch OFF to ON \geq Predetermined time
- Sensor-detected temperature $<$ Temperature at the last ignition switch OFF

Correction Process (Temperature at the Ignition switch ON)

- A temperature indicated when the ignition switch is ON depends on a vehicle speed, an ambient sensor-detected temperature, and traveling time.

The temperature on the information display is corrected to an ambient sensor-detected temperature when the following condition is met.

- Ambient sensor-detected temperature $<$ Temperature on the information display

A temperature on the information display is not updated when the following condition is met.

- Ambient sensor-detected temperature \geq Temperature on the information display
- Vehicle speed \leq 20 km/h (12 MPH)

A temperature on the information display slowly rises to an ambient sensor-detected temperature when the following condition is met.

- Ambient sensor-detected temperature \geq Temperature on the information display
- Vehicle speed \geq 20 km/h (12 MPH)

A temperature on the information display rapidly rises to an ambient sensor-detected temperature when the following condition is met.

- Ambient sensor-detected temperature \geq Temperature on the information display
- Vehicle speed \geq 20 km/h (12 MPH)
- When driving more than set time

NOTE:

- After an ignition switch is turned ON, “—” is displayed until after a 2.5 seconds.
- The ambient sensor input value that is displayed on “Data Monitor” of CONSULT is the value before the correction. It may not match the indicated temperature on the information display.
- After removal and installation of the battery and combination meter, an ambient sensor-detected temperature is indicated on the information display.
- Depending on engine heat or heat on the road surfaces, an ambient temperature may be indicated higher than actual one.

INTERRUPT INDICATION

- The combination meter displays an interrupt regarding a warning, alert, and maintenance on the information display, based on signals received from each unit and switch.
- When conditions are satisfied, the normal screen switches to a warning screen to display an interrupt.

Door Open Warning

SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

- When all the following operating conditions are satisfied, the combination meter displays a door open warning on the information display by an interrupt.

| Operating condition | |
|---------------------|------------------|
| Ignition switch | ON |
| Door | Any door is open |

- The combination meter judges showing/hiding of “door open warning”, according to the signals below:

| Signal name | Signal path |
|--------------------|-------------------------------------|
| Ignition signal | — |
| Door switch signal | Door switch BCM Combination meter |

Parking Brake Release Warning

- When all the following operating conditions are satisfied, the combination meter displays a parking brake release warning on the information display by an interrupt.

| Operating condition | |
|---------------------|--------------------------|
| Ignition switch | ON |
| Parking brake | Applied |
| Vehicle speed | 7 km/h (4.3 MPH) or more |

- The combination meter judges showing/hiding of “parking brake release warning”, according to the signals below:

| Signal name | Signal path |
|-----------------------------|--|
| Ignition signal | — |
| Parking brake switch signal | Parking brake switch Combination meter |
| Vehicle speed signal | ABS actuator and electric unit (control unit) Combination meter |

Low Fuel Warning

- When all the following operating conditions are satisfied, the combination meter displays a low fuel warning on the information display by an interrupt.

| Operating condition | |
|--------------------------|--|
| Ignition switch | ON |
| Fuel remaining quantity* | Approximately 11.2 ℓ (3 US gal, 2-1/2 Imp gal) or less (including fuel remained) |

*: With the vehicle in a horizontal position

- The combination meter judges showing/hiding of “low fuel warning”, according to the signals below:

| Signal name | Signal path |
|--------------------------|--------------------------------------|
| Ignition signal | — |
| Fuel level sensor signal | Fuel level sensor Combination meter |

Low washer fluid warning


- When all the following operating conditions are satisfied, the combination meter displays a low washer fluid warning on the information display by an interrupt.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

| Operating condition | |
|---------------------|--|
| Ignition switch | ON |
| Washer level switch | Decrease in fluid level (washer level switch ON for 180 seconds or more) |



- The combination meter judges showing/hiding of “low washer fluid warning”, according to the signals below:

| Signal name | Signal path |
|----------------------------|---|
| Ignition signal | — |
| Washer level switch signal | Washer level switch \longrightarrow Combination meter |

Low tire pressure warning

- The combination meter judges showing/hiding of “low tire pressure warning”, according to the signals below:

| Signal name | Signal path |
|---------------------------------------|--|
| Ignition signal | — |
| Low tire pressure warning lamp signal | BCM $\xrightarrow{\text{CAN}}$ Combination meter |

- For further information, refer to [WT-9. "System Description"](#).

Fuel filler cap warning

- The combination meter judges showing/hiding of “fuel filler cap warning”, according to the signals below:

| Signal name | Signal path |
|--|--|
| Ignition signal | — |
| Fuel filler cap warning display signal | ECM $\xrightarrow{\text{CAN}}$ Combination meter |

- For further information, refer to [EC-94. "System Description"](#).

Low Outside Temperature (Alert)

- When all the following operating conditions are satisfied, the combination meter displays a low ambient temperature on the information display by an interrupt.

| Operating condition | |
|---------------------|-------------------------------|
| Ignition switch | ON |
| Ambient temperature | 3 °C (37 °F) or less |
| information display | “ON” is selected in “SETTING” |

- The combination meter judges showing/hiding of “low outside temperature”, according to the signals below:

SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

| Signal name | Signal path |
|-----------------------|-----------------------------------|
| Ignition signal | — |
| Ambient sensor signal | Ambient sensor Combination meter |

Driver Alert (Alert)

- When all the following operating conditions are satisfied, the combination meter displays a driver alert on the information display by an interrupt.

| Operating condition | |
|---------------------|----------------|
| Ignition switch | Switch-ON time |

- The combination meter judges showing/hiding of “driver alert”, according to the signal below:

| Signal name | Signal path |
|-----------------|-------------|
| Ignition signal | — |

Service (Maintenance)

- When all the following operating conditions are satisfied, the combination meter displays a service warning on the information display by an interrupt.

| Operating condition | |
|---------------------|----------------------------------|
| Ignition switch | ON |
| Mileage | More than value set in “SETTING” |

- The combination meter judges showing/hiding of “service warning”, according to the signals below:

| Signal name | Signal path |
|----------------------|--|
| Ignition signal | — |
| Vehicle speed signal | ABS actuator and electric unit (control unit) Combination meter |

Tire (Maintenance)

- When all the following operating conditions are satisfied, the combination meter displays a tire warning on the information display by an interrupt.

| Operating condition | |
|---------------------|----------------------------------|
| Ignition switch | ON |
| Mileage | More than value set in “SETTING” |

- The combination meter judges showing/hiding of “tire warning”, according to the signals below:

| Signal name | Signal path |
|----------------------|--|
| Ignition signal | — |
| Vehicle speed signal | ABS actuator and electric unit (control unit) Combination meter |

Other (Maintenance)

- When all the following operating conditions are satisfied, the combination meter displays a other warning on the information display by an interrupt.

| Operating condition | |
|---------------------|----------------------------------|
| Ignition switch | ON |
| Mileage | More than value set in “SETTING” |

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

- The combination meter judges showing/hiding of “other warning”, according to the signals below:

| Signal name | Signal path |
|----------------------|--|
| Ignition signal | — |
| Vehicle speed signal | ABS actuator and electric unit (control unit) → Combination meter |

Meter Illumination Control Indication

The level of brightness is displayed by operating the illumination control switch on the meter.

SETTING

Warning indication timing, unit, language, and time can be set.

Clock

This function is used for adjusting the clock and switching the clock display between Show and Hide, in addition to the display method between 12 hours and 24 hours.

| Setting item | | Setting range | |
|--------------|--------------|---------------|--------------|
| Clock | Set clock | 24 Hr | 0:00 - 23:59 |
| | | 12 Hr | 0:00 - 11:59 |
| | 24/12 Hr | 24 Hr | — |
| | | 12 Hr | — |
| | Clock ON/OFF | ON | — |
| | | OFF | — |

Units

Setting values for unit items can be adjusted to meet the user's needs.

| Setting item | | |
|--------------|--------------|--------------|
| Unit | Temperature | Deg C |
| | | Deg F |
| | Dist. / Fuel | Miles, MPG |
| | | km, l/100 km |
| | | km, km/l |

Maintenance

Setting values for service, tire, and other maintenance items can be adjusted to meet the user's needs.

| Setting item | | Setting range |
|--------------|---------|--|
| Maintenance | Service | No setting, 500 km - 30,000 km (No setting, 250 mile - 18,500 mile) |
| | Tire | No setting, 500 km - 30,000 km (No setting, 250 mile - 18,500 mile) |
| | Other | No setting, 500 km - 30,000 km (No setting, 250 mile - 18,500 mile) |

Alert

Setting values for travel time, and low ambient temperature can be adjusted to meet the user's needs.

| Setting item | | Setting range | Setting unit |
|--------------|----------------------------|------------------------------|--------------|
| Alert | Driver alert | No setting, 30 min - 360 min | 30 min |
| | Outside temp (Low temp) | ON/OFF | — |

Language

SYSTEM (METER SYSTEM)

< SYSTEM DESCRIPTION >

Setting values for language items can be adjusted to meet the user's needs.


| Setting item | |
|--------------|---------|
| Language | English |
| | French |
| | Espanol |

Factory


Settings can be reset.

Settings-reject Indication

- Regarding settings-reject indications, "SETTING CAN BE OPERATED WHEN STOPPED" is shown on the information display when indication conditions are satisfied.
- When reaching 5 km/h (3.1 MPH) after accelerating from a stopping condition, a settings-reject indication is displayed.
- When reaching less than 1 km/h (0.6 MPH) after decelerating from 5 km/h (3.1 MPH), a settings-reject indication is cancelled to allow settings.
- The combination meter judges a vehicle condition based on the following signals and displays a settings-reject indication on the information display.

| Signal name | Signal path |
|----------------------|---|
| Ignition signal | — |
| Vehicle speed signal | ABS actuator and electric unit (control unit)  Combination meter |

TIMING CHART



JSNIA2408GB

SYSTEM (COMPASS)

< SYSTEM DESCRIPTION >

SYSTEM (COMPASS)

System Description


INFOID:000000007350304

DESCRIPTION

- This electronic compass is able to display 8 primary directions: N, NE, E, SE, S, SW, W, NW.
- The compass switch (1) is used to operate the compass.

Switch Operation

| | |
|---------------------------------------|---|
| Press | Compass is turned ON/OFF |
| Press and hold (for 3- 9 sec.) | Compass display (2) turns to zone variation change mode Compass |
| Press and hold (for more than 9 sec.) | Compass display turns to calibration mode |



- All standard compasses determine direction relative to Magnetic North; however, this electronic compass is designed to display direction relative to True North.
- The difference between Magnetic North and True North varies from place to place across the surface of the earth.
- This electronic compass must be “told” approximately where it is on the earth’s surface so that the Magnetic North reading can be properly converted into a True North display.
- To tell the electronic compass where it’s at, the earth is separated into numbered “Zone Variances”. The Zone Variance number in which the compass is to function must be entered into this electronic compass.
- Each zone is magnetically about 4.2° wide. Typically, anything under 22.5° total zone change is not noticed on the electronic compass display. However, over 22.5°, a reading may be off by one or more primary directions.
- On long trips, a vehicle may leave its original zone and enter one or more new zones. Generally, you do not need to reset the compass zone if you travel between 3 or 4 zones, such as business travel or vacation. The typical driver will not notice any difference on the display within 3 or 4 zones. However, if the vehicle is “permanently” moved to a new location, it is recommended that the compass zone be reset.

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (COMBINATION METER)

On Board Diagnosis Function

INFOID:000000007350305


ON BOARD DIAGNOSIS ITEM

On board diagnosis allows the user to check the following items:

- Part number
- Meter drive circuits
- Meter readings recognized by the combination meter
- LCD [liquid crystal display] on the information display
- Lighting circuit of the warning lamp and the indicator lamp
- Internal circuit

METHOD OF STARTING

1. Turn ignition switch OFF.
2. Turn ON the ignition switch with the trip reset switch (1) pressed.



3. "TEST" is indicated in the top portion of the information display after a lapse of 6 seconds after the ignition switch is turned ON.
4. When the pressed trip reset switch is released within 3 seconds after the "TEST" indication, "WI code XX" is indicated in the top portion of the information display and On board diagnosis is started.

NOTE:

On board diagnosis does not start if the trip reset switch is pressed for 3 seconds or more.

5. The mode switches in the order shown below each time the trip reset switch is pressed.

| Test order | Test item | Operation/Indication (Indicated in the top portion of Information Display) | Notes |
|------------|--------------------------|--|---|
| 1 | Part No XXXXX | Part number is indicated. | — |
| 2 | Gauge sweep | Each gauge pointer sweeps. | <ul style="list-style-type: none"> • The pointers sweep for 10 seconds. • If any one of the pointers does not sweep, replace combination meter. |
| 3 | (All pixels illuminated) | All the dots of the information display illuminate. | If any dot does not illuminates, replace combination meter. |
| 4 | Telltals | All the warning lamps and indicator lamps turns ON. | If any one of the indicator lamps of warning lamps does not turn ON, replace combination meter. |
| 5 | ROM XXXX | "r XXXX" or "FAIL" is indicated. | If "FAIL" is indicated, replace combination meter. |
| 6 | N ROM XXXX | — | Not used |
| 7 | EE XX, FAIL | "EE XX" or "FAIL" is indicated. | If "FAIL" is indicated, replace combination meter. |
| 8 | Dtcs XXXXXX | — | Not used |
| 9 | Date XXXX | — | Not used |
| 10 | SCEM0 XX | — | Not used |
| 11 | SCEM1 XX | — | Not used |
| 12 | EprJmp XX | — | Not used |
| 13 | Market XX | — | Not used |

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

| Test order | Test item | Operation/Indication (Indicated in the top portion of Information Display) | Notes |
|------------|----------------|--|---|
| 14 | TF a XXXX | — | Not used |
| 15 | TF b XXXX | — | Not used |
| 16 | OAT rad xxx | — | Not used |
| 17 | OAT xxx °C | — | Not used |
| 18 | DC Speed XXXX | — | Not used |
| 19 | Mph XXXXX | A vehicle speed signal value is indicated. (MPH) | <ul style="list-style-type: none"> • The “----” indication means no signal reception. • The “99999” indication means the reception of an abnormal signal. |
| 20 | Kmh XXXXX | A vehicle speed signal value is indicated. (km/h) | <ul style="list-style-type: none"> • The “----” indication means no signal reception. • The “99999” indication means the reception of an abnormal signal. |
| 21 | DC Tasho XXXX | — | Not used |
| 22 | Tacho XXXX | An engine speed signal value is indicated. (RPM) | The “----” indication means no signal reception. |
| 23 | DC Fuel XXXX | — | Not used |
| 24 | Fuel rad XXX | A fuel gauge signal value is indicated. | <ul style="list-style-type: none"> • The “000” - “009” indications mean that the fuel gauge signal circuit is open. • The “010” - “254” indication mean that the fuel gauge signal circuit is normal. • The “255” indication means that the fuel gauge signal circuit is shorted. • “---” is indicated for 5 seconds. |
| 25 | Fuel % xxx | — | Not used |
| 26 | FPhyst xxx | — | Not used |
| 27 | DC Temp XXXX | — | Not used |
| 28 | Temp ect XXX | A water temperature signal value is indicated. (°C) | <ul style="list-style-type: none"> • The “--- C” indication means no signal reception. • The “999 C” indication means the reception of an abnormal signal. |
| 29 | Oil level xxxx | — | Not used |
| 30 | Batt XXX | — | Not used |
| 31 | Port A -XX | — | Not used |
| 32 | Port B -XX | — | Not used |
| 33 | Port C -XX | — | Not used |
| 34 | Port E -XX | — | Not used |
| 35 | Port L -XX | — | Not used |
| 36 | Port K -XX | — | Not used |
| 37 | Port M -XX | — | Not used |
| 38 | Port P -XX | — | Not used |
| 39 | Port S -XX | — | Not used |
| 40 | Port T -XX | — | Not used |
| 41 | Port U -XX | — | Not used |
| 42 | Port V -XX | — | Not used |
| 43 | Port W -XX | — | Not used |
| 44 | A00 XXX | — | Not used |
| 45 | A01 XXX | — | Not used |
| 46 | A02 XXX | — | Not used |
| 47 | A03 XXX | — | Not used |

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

| Test order | Test item | Operation/Indication (Indicated in the top portion of Information Display) | Notes |
|------------|------------|--|----------|
| 48 | A04 XXX | — | Not used |
| 49 | A05 XXX | — | Not used |
| 50 | A06 XXX | — | Not used |
| 51 | A07 XXX | — | Not used |
| 52 | A08 XXX | — | Not used |
| 53 | A09 XXX | — | Not used |
| 54 | A10 XXX | — | Not used |
| 55 | A11 XXX | — | Not used |
| 56 | A12 XXX | — | Not used |
| 57 | A13 XXX | — | Not used |
| 58 | A14 XXX | — | Not used |
| 59 | A15 XXX | — | Not used |
| 60 | WI code XX | — | Not used |

NOTE:

"X" in the table shows a variable.

CONSULT Function

INFOID:000000007350306

CONSULT APPLICATION ITEMS

CONSULT can perform the following diagnosis modes via CAN communication and the combination meter.

| System | Diagnosis mode | Description |
|-----------|------------------------|--|
| METER/M&A | Self Diagnostic Result | The combination meter checks the conditions and displays memorized errors. |
| | Data Monitor | Displays the combination meter input/output data in real time. |
| | Warning History | Lighting history of the warning lamp and indicator lamp can be checked. |

SELF DIAG RESULT

Refer to [MWI-40, "DTC Index"](#).

DATA MONITOR

Display Item List

X: Applicable

| Display item [Unit] | MAIN SIGNALS | Description |
|-----------------------------|--------------|--|
| SPEED METER [km/h] | X | Value of vehicle speed signal received from ABS actuator and electric unit (control unit) via CAN communication. NOTE: 655.35 is displayed when the malfunction signal is received. |
| SPEED OUTPUT [km/h] | X | Vehicle speed signal value transmitted to other units via CAN communication. NOTE: 655.35 is displayed when the malfunction signal is received. |
| ODO OUTPUT [km/h or mph] | | Odometer signal value transmitted to other units via CAN communication. |
| TACHO METER [rpm] | X | Value of the engine speed signal received from ECM via CAN communication. NOTE: 8191.875 is displayed when the malfunction signal is received. |
| FUEL METER [L] | X | Fuel level indicated on combination meter. |

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

| Display item [Unit] | MAIN SIGNALS | Description |
|-------------------------|--------------|--|
| W TEMP METER [°C] | X | Value of engine coolant temperature signal is received from ECM via CAN communication. NOTE: 215 is displayed when the malfunction signal is input. |
| ABS W/L [On/Off] | | Status of ABS warning lamp detected from ABS warning lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication. |
| VDC/TCS IND [On/Off] | | Status of VDC OFF indicator lamp detected from VDC OFF indicator lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication. |
| SLIP IND [On/Off] | | Status of VDC warning lamp detected from VDC warning lamp signal received from ABS actuator and electric unit (control unit) via CAN communication. |
| BRAKE W/L [On/Off] | | Status of brake warning lamp detected from brake warning lamp signal is received from ABS actuator and electric unit (control unit) via CAN communication. NOTE: Displays "Off" if the brake warning lamp is illuminated when the valve check starts, the parking brake switch is turned ON or the brake fluid level switch is turned ON. |
| DOOR W/L [On/Off] | | Status of door open warning detected from door switch signal received from BCM via CAN communication. |
| TRUNK/GLAS-H [Off] | | This item is displayed, but cannot be monitored. |
| HI-BEAM IND [On/Off] | | Status of high beam indicator lamp detected from high beam request signal is received from BCM via CAN communication. |
| TURN IND [On/Off] | | Status of turn indicator lamp detected from turn indicator signal is received from BCM via CAN communication. |
| FR FOG IND [On/Off] | | This item is displayed, but cannot be monitored. |
| RR FOG IND [Off] | | This item is displayed, but cannot be monitored. |
| LIGHT IND [On/Off] | | Status of position lamp indicator lamp detected from position light request signal is received from BCM via CAN communication. |
| OIL W/L [On/Off] | | Status of oil pressure warning lamp detected from oil pressure switch signal is received from BCM via CAN communication. |
| MIL [On/Off] | | Status of malfunction indicator (Yellow) detected from malfunctioning indicator signal is received from ECM via CAN communication. |
| GLOW IND [Off] | | This item is displayed, but cannot be monitored. |
| C-ENG2 W/L [Off] | | This item is displayed, but cannot be monitored. |
| CRUISE IND [On/Off] | | Status of CRUISE indicator detected from ASCD status signal is received from ECM via CAN communication. |
| SET IND [On/Off] | | Status of SET indicator detected from ASCD status signal is received from ECM via CAN communication. |
| O/D OFF IND [On/Off] | | Status of OD OFF indicator lamp detected from OD OFF indicator signal is received from TCM via CAN communication. |
| ATC/T-AMT W/L [Off] | | This item is displayed, but cannot be monitored. |
| ATF TEMP W/L [Off] | | This item is displayed, but cannot be monitored. |
| CVT IND [Off] | | This item is displayed, but cannot be monitored. |
| 4WD W/L [On/Off] | | Status of AWD warning lamp judged from AWD warning lamp signal received from AWD control unit with CAN communication line. |

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

| Display item [Unit] | MAIN SIGNALS | Description | |
|--|--------------|--|---|
| 4WD LOCK IND [On/Off] | | Status of AWD lock indicator lamp judged from mode lamp signal received from AWD control unit with CAN communication line. | A |
| FUEL W/L [On/Off] | | Low fuel warning status detected by the identified fuel level. | B |
| WASHER W/L [On/Off] | | Status of low washer fluid warning judged from washer level switch input to combination meter. | C |
| AIR PRES W/L [On/Off] | | Status of low tire pressure warning judged from TPMS malfunction warning lamp signal received from BCM with CAN communication line. | D |
| KEY G/Y W/L [On/Off] | | Status of Intelligent Key system malfunction detected from KEY/LOCK warning request signal is received from BCM via CAN communication. | D |
| KEY R W/L [Off] | | This item is displayed, but cannot be monitored. | E |
| KEY KNOB W/L [Off] | | This item is displayed, but cannot be monitored. | E |
| EPS W/L [On/Off] | | Status of EPS warning lamp detected from EPS warning lamp signal is received from EPS control unit via CAN communication. | F |
| DDS* W/L [Off] | | This item is displayed, but cannot be monitored. | G |
| SPORT MODE IND [On/Off] | | Status of SPORT mode indicator lamp detected from SPORT mode switch signal is received from ECM via CAN communication. | G |
| DPF W/L [Off] | | This item is displayed, but cannot be monitored. | H |
| TRAILER IND [Off] | | This item is displayed, but cannot be monitored. | I |
| SHIFT IND [P, R, N, D, L, M1, M2, M3, M4, M5, M6] | | Status of shift position indicator judged from shift position signal received from TCM with CAN communication line. | I |
| O/D OFF SW [On/Off] | | Status of overdrive control switch. | J |
| M RANGE SW [On/Off] | | Status of manual mode switch. | K |
| NM RANGE SW [On/Off] | | Status of non-manual mode switch. | K |
| AT SFT UP SW [On/Off] | | Status of manual mode shift up switch. | L |
| AT SFT DWN SW [On/Off] | | Status of manual mode shift down switch. | M |
| ST SFT UP SW [On/Off] | | Status of paddle shifter shift up switch. | M |
| ST SFT DWN SW [On/Off] | | Status of paddle shifter shift down switch. | M |
| A/C LOW TEMP [Off] | | This item is displayed, but cannot be monitored. | O |
| COMP F/B SIG [Off] | | This item is displayed, but cannot be monitored. | O |
| PKB SW [On/Off] | | Status of parking brake switch. | P |
| BUCKLE SW [On/Off] | | Status of seat belt buckle switch (driver side). | P |
| BRAKE OIL SW [On/Off] | | Status of brake fluid level switch. | P |

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

| Display item [Unit] | MAIN SIGNALS | Description |
|----------------------------|--------------|---|
| A/C AMP CONN [On/Off] | | Status of A/C auto amp. connection recognition signal. |
| DISTANCE [km] | | Value of distance to empty calculated by combination meter. |
| OUTSIDE TEMP [°C or °F] | | Ambient temperature value converted from ambient sensor signal received from ambient sensor. NOTE: This may not match with the temperature value indicated on the information display. (Because the information display value is a corrected value from the ambient sensor input value.) |
| FUEL LOW SIG [On/Off] | | Status of fuel level low warning signal to output to AV control unit via CAN communication. |
| SPORT MODE SW [On/Off] | | Status of SPORT mode switch. |
| BUZZER [On/Off] | X | Buzzer status (in the combination meter) is detected from the buzzer output signal received from each unit via CAN communication and the warning output condition of the combination meter. |
| ASCD SPD BLNK [Off] | | This item is displayed, but cannot be monitored. |
| ASCD STATUS [Off] | | This item is displayed, but cannot be monitored. |
| ASCD REQ SPD [Off] | | This item is displayed, but cannot be monitored. |

*: DDS (hill descent control)

NOTE:

Some items are not available according to vehicle specification.

WARNING HISTORY

- Stores histories when warning/indicator lamp is turned on.
- “WARNING HISTORY” indicates the “TIME” when the warning/ indicator lamp is turned on.
- The “TIME” above is:
 - 0: The condition that the warning/indicator lamp has been turned on 1 or more times after starting the engine and waiting for 30 seconds.
 - 1 - 39: The number of times the engine was restarted after the 0 condition.
 - NO WARNING HISTORY: Stores NO (0) turning on history of warning/indicator lamp.

NOTE:

- WARNING HISTORY is not stored for approximately 30 seconds after the engine starts.
- Brake warning lamp does not store any history when the parking brake is applied or the brake fluid level gets low.

Display Item

| Display item | Description |
|--------------|---|
| ABS W/L | Lighting history of ABS warning lamp. |
| VDC/TCS IND | Lighting history of VDC OFF indicator lamp. |
| SLIP IND | Lighting history of VDC warning lamp. |
| BRAKE W/L | Lighting history of brake warning lamp. |
| DOOR W/L | Lighting history of door open warning. |
| OIL W/L | Lighting history of oil pressure warning lamp. |
| C-ENG W/L | Lighting history of malfunction indicator lamp. |
| CRUISE IND | Lighting history of CRUISE indicator. |
| SET IND | Lighting history of SET indicator. |
| O/D OFF IND | Lighting history of OD OFF indicator lamp. |

DIAGNOSIS SYSTEM (COMBINATION METER)

< SYSTEM DESCRIPTION >

| Display item | Description | |
|--------------|---|---|
| 4WD W/L | Lighting history of AWD warning lamp. | A |
| FUEL W/L | Lighting history of low fuel level warning. | |
| WASHER W/L | Lighting history of low washer fluid warning. | B |
| AIR PRES W/L | Lighting history of low tire pressure warning lamp. | |
| KEY G/Y W/L | Lighting history of Intelligent Key system malfunction. | |
| EPS W/L | Lighting history of EPS warning lamp. | C |

NOTE:

In items displayed on the CONSULT screen, only those listed in the above table are used.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

COMBINATION METER

Reference Value

INFOID:000000007350307

VALUES ON THE DIAGNOSIS TOOL

| Monitor Item | Condition | | Value/Status |
|------------------------|-----------------------|--|--|
| SPEED METER [km/h] | Ignition switch ON | While driving | Input value of vehicle speed signal (CAN communication signal) NOTE: 655.35 is displayed when the malfunction signal is received |
| SPEED OUTPUT [km/h] | Ignition switch ON | While driving | Output value of vehicle speed signal (CAN communication signal) NOTE: 655.35 is displayed when the malfunction signal is received |
| ODO OUTPUT | Ignition switch ON | — | Output value of odometer signal (CAN communication signal) |
| TACHO METER [rpm] | Ignition switch ON | While driving | Input value of engine speed signal (CAN communication signal) NOTE: 8191.875 is displayed when the malfunction signal is received |
| FUEL METER [lit] | Ignition switch ON | — | Input value of fuel level sensor signal |
| W TEMP METER [°C] | Ignition switch ON | — | Input value of engine coolant temperature signal (CAN communication signal) NOTE: 215 is displayed when the malfunction signal is input |
| ABS W/L | Ignition switch ON | ABS warning lamp ON | On |
| | | ABS warning lamp OFF | Off |
| VDC/TCS IND | Ignition switch ON | VDC OFF indicator lamp ON | On |
| | | VDC OFF indicator lamp OFF | Off |
| SLIP IND | Ignition switch ON | VDC warning lamp ON | On |
| | | VDC warning lamp OFF | Off |
| BRAKE W/L | Ignition switch ON | Brake warning lamp ON | On |
| | | Brake warning lamp OFF | Off |
| DOOR W/L | Ignition switch ON | During door open warning indication | On |
| | | Other than the above | Off |
| TRUNK/GLAS-H | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off |
| HI-BEAM IND | Ignition switch ON | High beam indicator lamp ON | On |
| | | High beam indicator lamp OFF | Off |
| TURN IND | Ignition switch ON | Turn signal indicator lamp ON | On |
| | | Turn signal indicator lamp OFF | Off |
| FR FOG IND | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off |

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | | Value/Status | |
|---------------|--------------------|--|--------------|-----|
| RR FOG IND | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off | A |
| LIGHT IND | Ignition switch ON | Position lamp indicator lamp ON | On | B |
| | | Position lamp indicator lamp OFF | Off | |
| OIL W/L | Ignition switch ON | Oil pressure warning lamp ON | On | C |
| | | Oil pressure warning lamp OFF | Off | |
| MIL | Ignition switch ON | Malfunction indicator (Yellow) ON | On | D |
| | | Malfunction indicator (Yellow) OFF | Off | |
| GLOW IND | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off | E |
| C-ENG2 W/L | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off | F |
| CRUISE IND | Ignition switch ON | Cruise indicator ON | On | F |
| | | Cruise indicator OFF | Off | |
| SET IND | Ignition switch ON | SET indicator ON | On | G |
| | | SET indicator OFF | Off | |
| O/D OFF IND | Ignition switch ON | OD OFF indicator lamp ON | On | H |
| | | OD OFF indicator lamp OFF | Off | |
| ATC/T-AMT W/L | Ignition switch ON | A/T CHECK indicator lamp ON | On | I |
| | | A/T CHECK indicator lamp OFF | Off | |
| ATF TEMP W/L | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off | J |
| CVT IND | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off | K |
| 4WD W/L | Ignition switch ON | AWD warning lamp ON | On | L |
| | | AWD warning lamp OFF | Off | |
| 4WD LOCK IND | Ignition switch ON | AWD LOCK indicator lamp ON | On | L |
| | | AWD LOCK indicator lamp OFF | Off | |
| FUEL W/L | Ignition switch ON | During low fuel warning indication | On | M |
| | | Other than the above | Off | |
| WASHER W/L | Ignition switch ON | During low washer fluid warning indication | On | MWI |
| | | Other than the above | Off | |
| AIR PRES W/L | Ignition switch ON | Low tire pressure warning lamp ON | On | O |
| | | Other than the above | Off | |
| KEY G/Y W/L | Ignition switch ON | Intelligent Key system malfunction ON | On | P |
| | | Intelligent Key system malfunction OFF | Off | |
| KEY R W/L | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off | P |
| KEY KNOB W/L | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off | |
| EPS W/L | Ignition switch ON | EPS warning lamp ON | On | |
| | | EPS warning lamp OFF | Off | |

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | | Value/Status |
|----------------|--------------------|--|--------------|
| DDS W/L * | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off |
| SPORT MODE IND | Ignition switch ON | SPORT mode indicator lamp ON | On |
| | | SPORT mode indicator lamp OFF | Off |
| DPF W/L | Engine running | NOTE: This item is displayed, but cannot be monitored. | Off |
| TRAILER IND | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off |
| SHIFT IND | Ignition switch ON | During the indication of "P" by shift position indicator | P |
| | | During the indication of "R" by shift position indicator | R |
| | | During the indication of "N" by shift position indicator | N |
| | | During the indication of "D" by shift position indicator | D |
| | | During the indication of "L" by shift position indicator | L |
| | | During the indication of "M1" by shift position indicator | M1 |
| | | During the indication of "M2" by shift position indicator | M2 |
| | | During the indication of "M3" by shift position indicator | M3 |
| | | During the indication of "M4" by shift position indicator | M4 |
| | | During the indication of "M5" by shift position indicator | M5 |
| | | During the indication of "M6" by shift position indicator | M6 |
| O/D OFF SW | Ignition switch ON | Overdrive control switch ON | On |
| | | Overdrive control switch OFF | Off |
| M RANGE SW | Ignition switch ON | Selector lever in manual mode position | On |
| | | Other than the above | Off |
| NM RANGE SW | Ignition switch ON | Selector lever in manual mode position | Off |
| | | Other than the above | On |
| AT SFT UP SW | Ignition switch ON | Selector lever in + position | On |
| | | Other than the above | Off |
| AT SFT DWN SW | Ignition switch ON | Selector lever in – position | On |
| | | Other than the above | Off |
| ST SFT UP SW | Ignition switch ON | Paddle shifter in + position | On |
| | | Other than the above | Off |
| ST SFT DWN SW | Ignition switch ON | Paddle shifter in – position | On |
| | | Other than the above | Off |
| A/C LOW TEMP | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off |

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >


| Monitor Item | Condition | | Value/Status |
|----------------------------|--------------------|--|---|
| COMP F/B SIG | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off |
| PKB SW | Ignition switch ON | Parking brake switch ON | On |
| | | Parking brake switch OFF | Off |
| BUCKLE SW | Ignition switch ON | Driver seat belt not fastened | On |
| | | Driver seat belt fastened | Off |
| BRAKE OIL SW | Ignition switch ON | Brake fluid level switch ON | On |
| | | Brake fluid level switch OFF | Off |
| A/C AMP CONN | Ignition switch ON | Other than the following | On |
| | | Receives A/C auto amp. connection recognition signal | Off |
| DISTANCE [km] | Ignition switch ON | — | Distance to empty calculated by combination meter |
| OUTSIDE TEMP [°C or °F] | Ignition switch ON | — | Input value of ambient sensor signal (CAN communication signal) NOTE: This may not match the indicated value on the information display. |
| FUEL LOW SIG | Ignition switch ON | Low fuel warning displayed | On |
| | | Low fuel warning not displayed | Off |
| SPORT MODE SW | Ignition switch ON | SPORT mode switch ON | On |
| | | SPORT mode switch OFF | Off |
| BUZZER | Ignition switch ON | Buzzer ON | On |
| | | Buzzer OFF | Off |
| ASCD SPD BLNK | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off |
| ASCD STATUS | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off |
| ASCD REQ SPD [km/h or Off] | Ignition switch ON | NOTE: This item is displayed, but cannot be monitored. | Off |

*: DDS (hill descent control)

NOTE:

Some items are not available according to vehicle specification.



TERMINAL LAYOUT



PHYSICAL VALUES

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|---------------------|--|---|
| + | - | Signal name | Input/ Output | | | |
| 1 (LG) | Ground | Battery power supply | Input | Ignition switch OFF | — | Battery voltage |
| 2 (BG) | Ground | Ignition signal | Input | Ignition switch ON | — | Battery voltage |
| 3 (B) | Ground | Ground | — | Ignition switch ON | — | 0 V |
| 4 (L) | Ground | SPORT mode switch signal | Input | Ignition switch ON | SPORT mode switch pressed | 0 V |
| | | | | | SPORT mode switch not pressed | 12 V |
| 5 (BR) | Ground | A/C auto amp. connection recognition signal | Input | Ignition switch ON | When auto amp. is connected | 5 V |
| | | | | | Other than the above | 0 V |
| 7 (GR) | Ground | Overdrive control switch signal | Input | Ignition switch ON | Overdrive control switch pressed | 0 V |
| | | | | | Overdrive control switch not pressed | 12 V |
| 9 (L) | Ground | Paddle shifter shift up signal | Input | Ignition switch ON | Paddle shifter shift up operation | 0 V |
| | | | | | Other than the above | 12 V |
| 10 (G) | Ground | Paddle shifter shift down signal | Input | Ignition switch ON | Paddle shifter shift down operation | 0 V |
| | | | | | Other than the above | 12 V |
| 13 (Y) | Ground | Illumination control signal | Output | Ignition switch ON | <ul style="list-style-type: none"> Lighting switch 1ST position When meter illumination is maximum |  |
| | | | | | <ul style="list-style-type: none"> Lighting switch 1ST position When meter illumination is step 11 |  |
| | | | | | <ul style="list-style-type: none"> Lighting switch 1ST position When meter illumination is minimum | 12 V |
| 15 (LG) | Ground | Air bag signal | Input | Ignition switch ON | Air bag warning lamp ON | 4 V |
| | | | | | Air bag warning lamp OFF | 0 V |

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >




| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|-----------------------------------|------------------|---------------------|---|
| + | - | Signal name | Input/ Output | | |
| 16 (W) | Ground | Engine coolant temperature signal | Output | Ignition switch ON | <p style="text-align: right;">PKID0590E</p> |
| | | | | Ignition switch ON | <p style="text-align: right;">SKIB3651J</p> |
| 19 (BR) | Ground | Ambient sensor signal | Input | Ignition switch ON | <p style="text-align: right;">JSNIA0014GB</p> |
| 20 (SB) | Ground | Ambient sensor ground | — | Ignition switch ON | 0 V |
| 21 (L) | — | CAN-H | — | — | — |
| 22 (P) | — | CAN-L | — | — | — |
| 24 (B) | Ground | Fuel level sensor signal ground | — | Ignition switch ON | 0 V |
| 25 (SB) | Ground | Alternator signal | Input | Ignition switch ON | Charge warning lamp ON 0 V |
| | | | | Ignition switch OFF | Charge warning lamp OFF 12 V |
| 26 (V) | Ground | Parking brake switch signal | Input | Ignition switch ON | Parking brake ON 0 V |
| | | | | Ignition switch OFF | Parking brake OFF 5 V |
| 27 (BR) | Ground | Brake fluid level switch signal | Input | Ignition switch ON | Brake fluid level is normal 5 V |
| | | | | Ignition switch OFF | Brake fluid level is less than low level 0 V |
| 28 (B) | Ground | Security signal | Input | Ignition switch ON | Security warning lamp ON 0 V |
| | | | | Ignition switch OFF | Security warning lamp OFF 12 V |
| 29 (W) | Ground | Washer level switch signal | Input | Ignition switch ON | Washer level switch ON 0 V |
| | | | | Ignition switch OFF | Washer level switch OFF 12 V |

A
B
C
D
E
F
G
H
I
J
K
L
M
MWI
O
P

MWI

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|---|--|------|
| + | - | Signal name | Input/ Output | | | |
| 30 (Y) | Ground | Vehicle speed signal (2-pulse) | Output | Ignition switch ON Speedometer operated [When vehicle speed is ap- prox. 40 km/h (25 MPH)] | NOTE: The maximum voltage varies de- pending on the specification (destination unit).  <small>JSNIA0015GB</small> | |
| 31 (L) | Ground | Vehicle speed signal (8-pulse) | Output | Ignition switch ON Vehicle speed is approxi- mately 40 km/h (25 MPH) | NOTE: The maximum voltage varies de- pending on the specification (destination unit).  <small>JSNIA0012GB</small> | |
| 34 (G) | Ground | Fuel level sensor signal | Input | Ignition switch ON — |  <small>JSNIA3463ZZ</small> | |
| 35 (BG) | Ground | Seat belt buckle switch sig- nal (driver side) | Input | Ignition switch ON | When driver seat belt is fas- tened | 12 V |
| | | | | Ignition switch OFF | When driver seat belt is not fastened | 0 V |
| 36 (G) | Ground | Seat belt buckle switch sig- nal (passenger side) | Input | Ignition switch ON | <ul style="list-style-type: none"> When getting in the pas- senger seat When passenger seat belt is fastened | 12 V |
| | | | | Ignition switch OFF | <ul style="list-style-type: none"> When getting in the pas- senger seat When passenger seat belt is not fastened | 0 V |
| 37 (P) | Ground | Non-manual mode signal | Input | Ignition switch ON | Manual mode | 12 V |
| | | | | Ignition switch OFF | Other than the above | 0 V |
| 38 (BG) | Ground | Manual mode shift down signal | Input | Ignition switch ON | Selector lever (-) position | 0 V |
| | | | | Ignition switch OFF | Other than the above | 12 V |
| 39 (V) | Ground | Manual mode shift up sig- nal | Input | Ignition switch ON | Selector lever (+) position | 0 V |
| | | | | Ignition switch OFF | Other than the above | 12 V |
| 40 (LG) | Ground | Manual mode signal | Input | Ignition switch ON | Manual mode | 0 V |
| | | | | Ignition switch OFF | Other than the above | 12 V |

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

Fail-safe

INFOID:000000007350308

The combination meter activates the fail-safe control if the CAN communication lines between each unit are malfunctioning.

| Function | | Specifications | |
|----------------------------------|---|--|---|
| Speedometer | | Reset to zero by suspending communication. | |
| Tachometer | | | |
| Engine coolant temperature gauge | | | |
| Meter illumination control | | When suspending communication, changes to nighttime mode. | |
| Buzzer | | Turned off by suspending communication. | |
| Information display | Trip computer | Current fuel consumption | <ul style="list-style-type: none"> When reception time of an abnormal signal is 2 seconds or less, the last received datum is used for calculation to indicate the result. When reception time of an abnormal signal is more than 2 seconds, the last result calculated during normal condition is indicated. |
| | | Average fuel consumption | |
| | | Average vehicle speed | |
| | | Range (Distance to empty) | |
| | | Driving distance | |
| | Interrupt indication | Door open warning | The indicator turns OFF by suspending communication. |
| | | Low tire pressure warning | |
| | | Fuel filler cap warning | |
| Odo/trip meter | | An indicated value is maintained at communications blackout. | |
| Shift position indicator | | The indicator turns OFF by suspending communication. | |
| Warning lamp/indicator lamp | ABS warning lamp | Turned on by suspending communication. | |
| | Brake warning lamp | | |
| | EPS warning lamp | | |
| | VDC warning lamp | | |
| | AWD warning lamp | | |
| | Malfunction indicator lamp | | |
| | VDC OFF indicator lamp | Turned off by suspending communication. | |
| | SPORT mode indicator lamp | | |
| | AWD LOCK indicator lamp | | |
| | Oil pressure warning lamp | | |
| | High beam indicator lamp | | |
| | Turn signal indicator lamp | | |
| | Position lamp indicator lamp | | |
| | A/T CHECK indicator lamp | | |
| | OD OFF indicator lamp | | |
| Low tire pressure warning lamp | After blinking for 1 minute, the lamp remains ON. | | |

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

COMBINATION METER

< ECU DIAGNOSIS INFORMATION >

DTC Index

INFOID:000000007350309

| Display contents of CONSULT | Time | Diagnostic item is detected when... | Refer to |
|-------------------------------|--------------|--|------------------------|
| CAN COMM CIRCUIT [U1000] | CRNT, 1 - 39 | Combination meter is not transmitting or receiving CAN communication signal for 2 seconds or more. | MWI-50 |
| CONTROL UNIT (CAN) [U1010] | CRNT, 1 - 39 | Detecting error during the initial diagnosis of CAN controller of combination meter. | MWI-51 |
| VEHICLE SPEED [B2205] | CRNT, 1 - 39 | The abnormal vehicle speed signal is input from ABS actuator and electric unit (control unit) for 2 seconds or more. | MWI-52 |
| ENGINE SPEED [B2267] | CRNT, 1 - 39 | ECM continuously transmits abnormal engine speed signals for 2 seconds or more. | MWI-53 |
| WATER TEMP [B2268] | CRNT, 1 - 39 | ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more. | MWI-54 |

IPDM E/R

< ECU DIAGNOSIS INFORMATION >

IPDM E/R

List of ECU Reference

INFOID:000000007350310

| ECU | Reference |
|----------|---|
| IPDM E/R | PCS-16. "Reference Value" |
| | PCS-23. "Fail-safe" |
| | PCS-25. "DTC Index" |

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

METER SYSTEM

< WIRING DIAGRAM >


WIRING DIAGRAM

METER SYSTEM

Wiring Diagram

INFOID:000000007350311


For connector terminal arrangements, harness layouts, and alphabets in a ◊ (option abbreviation; if not described in wiring diagram), refer to [GI-12. "Connector Information"](#).



METER SYSTEM

< WIRING DIAGRAM >

- ★ 1 23 : 2WD models for North America
- 15 : Except 2WD models for North America
- 24 : <WA> : With Intelligent Key
- 29 : <WA> : With advanced air bag
- 36 : <WA> : Without advanced air bag
- 39 : <XX> : Except for Mexico with 4-speakers
- 40 : <WL> : With washer level switch
- 41 : <SM> : With sport mode




* : This connector is not shown in "Harness Layout".

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

METER SYSTEM

< WIRING DIAGRAM >



JRNWC0819GB


COMPASS


< WIRING DIAGRAM >

COMPASS

Wiring Diagram

INFOID:000000007350312

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).



COMPASS

2008/07/15

JCNWM1631GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

MWI

DIAGNOSIS AND REPAIR WORKFLOW (METER SYSTEM)

< BASIC INSPECTION >


BASIC INSPECTION

DIAGNOSIS AND REPAIR WORKFLOW (METER SYSTEM)

Work flow

INFOID:000000007350313

OVERALL SEQUENCE



- Reference 1...[MWI-25, "On Board Diagnosis Function"](#).
- Reference 2...[MWI-40, "DTC Index"](#).
- Reference 3...[MWI-55, "COMBINATION METER : Diagnosis Procedure"](#).

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain as much information as possible about the conditions and environment under which the malfunction occurred.

>> GO TO 2.

2.CHECK SYMPTOM

DIAGNOSIS AND REPAIR WORKFLOW (METER SYSTEM)

< BASIC INSPECTION >

- Check the symptom based on the information obtained from the customer.
- Check that any other malfunctions are present.

>> GO TO 3.

3.CHECK ON BOARD DIAGNOSIS OPERATION

Check that the on board diagnosis function operates. Refer to [MWI-25, "On Board Diagnosis Function"](#).

Does the on board diagnosis function operate normally?

YES >> GO TO 4.

NO >> GO TO 6.

4.CHECK CONSULT SELF-DIAGNOSIS RESULTS

1. Connect CONSULT and perform self-diagnosis. Refer to [MWI-40, "DTC Index"](#).
2. When DTC is detected, follow the instructions below:
 - Record DTC and Freeze Frame Data.

Are self-diagnosis results normal?

YES >> GO TO 5.

NO >> GO TO 8.

5.NARROW DOWN THE MALFUNCTIONING PARTS BY SYMPTOM DIAGNOSIS

Perform symptom diagnosis and narrow down the malfunctioning parts.

>> GO TO 8.

6.CHECK COMBINATION METER POWER SUPPLY AND GROUND CIRCUITS

Check combination meter power supply and ground circuits. Refer to [MWI-55, "COMBINATION METER : Diagnosis Procedure"](#).

Is inspection result OK?

YES >> GO TO 7.

NO >> GO TO 8.

7.REPLACE COMBINATION METER

Replace combination meter.

>> GO TO 9.

8.REPAIR OR REPLACE MALFUNCTIONING PARTS

Repair or replace the malfunctioning parts.

NOTE:

If DTC is displayed, erase DTC after repair or replace malfunctioning parts.

>> GO TO 9.

9.FINAL CHECK

Check that the combination meter operates normally.

Do they operate normally?

YES >> INSPECTION END

NO >> GO TO 1.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

ZONE VARIATION SETTING (COMPASS)


< BASIC INSPECTION >

ZONE VARIATION SETTING (COMPASS)

Work Procedure

INFOID:000000007350314

1. Press and hold the compass switch for 3 – 9 seconds.
2. The current zone setting appears on the compass display.
3. Find the current geographical location number in the Zone Variation Chart.
4. Select the new zone number. (Press the compass switch until the new zone number appears on the compass display.)
5. After select the new zone number, the compass display will automatically shows a direction within a few seconds.
6. Perform the following Calibration Procedure for more accurate indications.



CALIBRATION (COMPASS)

< BASIC INSPECTION >

CALIBRATION (COMPASS)

Work Procedure

INFOID:000000007350315

NOTE:

The compass calibrates itself under normal driving conditions. However, occasional circumstances may cause the compass to operate inaccurately. Example: Driving from rural (wide open) areas to crowded city areas, or if an aftermarket (i.e., non original equipment) antenna with a magnetic base is attached to the vehicle. Calibrate the mirror compass if the display shows only one direction or a limited number of directions.

NOTE:

- If “magnetic hats” are used in the dealership for vehicle identification, remove the hat from the vehicle before performing the following steps. Do not put the hat back on the vehicle after the procedure is completed.
- Drive the vehicle to an open level area; away from large metallic objects, structures, and overhead power lines.
- Turn off “non-essential” electrical accessories (rear window defrost, heater/air conditioning, wipers) and close the doors.

1. Verify the correct compass zone setting for the geographical location.
2. Press and hold the compass switch for more than 9 seconds.
3. “C” is displayed on the compass display, when calibration starts.
4. Drive slowly [less than 8 km/h (5 MPH)] in a circle until the “C / CAL” is replaced with primary headings (N, NE, E, SE, S, SW, W, or NW).

NOTE:

This will require driving at least 2 complete 360 degree circles; 3 complete circles may be required.

5. The compass calibration procedure is now complete. The compass should operate normally.

NOTE:

If at any time the compass continually displays the incorrect direction or the reading is erratic or locked, repeat the calibration procedure.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000007350316

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

Refer to [LAN-25, "CAN Communication Signal Chart"](#).

DTC Logic

INFOID:000000007350317

DTC DETECTION LOGIC

| DTC | Display contents of CONSULT | Diagnostic item is detected when ... | Probable malfunction location |
|-------|-----------------------------|---|-------------------------------|
| U1000 | CAN COMM CIRCUIT | When combination meter is not transmitting or receiving CAN communication signal for 2 seconds or more. | CAN communication system |

Diagnosis Procedure

INFOID:000000007350318

1. PERFORM SELF DIAGNOSTIC

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Check "Self Diagnostic Result" of "METER/M&A".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Refer to [LAN-16, "Trouble Diagnosis Flow Chart"](#).
NO >> Refer to [GI-45, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

U1010 CONTROL UNIT (CAN)

Description

INFOID:000000007350319

Initial diagnosis of combination meter.

DTC Logic

INFOID:000000007350320

DTC DETECTION LOGIC

| DTC | Display contents of CONSULT | Diagnostic item is detected when ... | Probable malfunction location |
|-------|-----------------------------|---|-------------------------------|
| U1010 | CONTROL UNIT (CAN) | Any malfunction is detected during initial diagnosis of combination meter CAN controller. | Combination meter |

Diagnosis Procedure

INFOID:000000007350321

1. REPLACE COMBINATION METER

When DTC "U1010" is detected, replace combination meter.

>> INSPECTION END

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

B2205 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

B2205 VEHICLE SPEED

Description

INFOID:000000007350322

Vehicle speed signal is transmitted from ABS actuator and electric unit (control unit) via CAN communication line to combination meter.

DTC Logic

INFOID:000000007350323

DTC DETECTION LOGIC

| DTC | Display contents of CONSULT | Diagnostic item is detected when ... | Probable malfunction location |
|-------|-----------------------------|--|--|
| B2205 | VEHICLE SPEED | The abnormal vehicle speed signal is input from ABS actuator and electric unit (control unit) for 2 seconds or more. | <ul style="list-style-type: none">• Wheel sensor• ABS actuator and electric unit (control unit) |

Diagnosis Procedure

INFOID:000000007350324

1. PERFORM SELF DIAGNOSIS OF ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Perform "Self Diagnosis Result" of ABS actuator and electric unit (control unit), and repair or replace malfunctioning parts.

- >> • [BRC-15, "CONSULT Function"](#) (Without VDC system)
- [BRC-94, "CONSULT Function"](#) (With VDC system)

B2267 ENGINE SPEED

< DTC/CIRCUIT DIAGNOSIS >

B2267 ENGINE SPEED

Description

INFOID:000000007350325

The engine speed signal is transmitted from ECM to the combination meter with CAN communication.

DTC Logic

INFOID:000000007350326

DTC DETECTION LOGIC

| DTC | Display contents of CONSULT | Diagnostic item is detected when ... | Probable malfunction location |
|-------|-----------------------------|---|--|
| B2267 | ENGINE SPEED | ECM continuously transmits abnormal engine speed signals for 2 seconds or more. | <ul style="list-style-type: none">• Crankshaft position sensor• ECM |

Diagnosis Procedure

INFOID:000000007350327

1. PERFORM SELF DIAGNOSIS OF ECM

Perform "Self Diagnosis Result" of ECM, and repair or replace malfunctioning parts.

- >> • [EC-107, "CONSULT Function"](#) (EXCEPT FOR MEXICO)
- [EC-542, "CONSULT Function"](#) (FOR MEXICO)

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

B2268 WATER TEMP

< DTC/CIRCUIT DIAGNOSIS >

B2268 WATER TEMP

Description

INFOID:000000007350328

The engine coolant temperature signal is transmitted from ECM to the combination meter via CAN communication.

DTC Logic

INFOID:000000007350329

DTC DETECTION LOGIC

| DTC | Display contents of CONSULT | Diagnostic item is detected when ... | Probable malfunction location |
|-------|-----------------------------|--|---|
| B2268 | WATER TEMP | ECM continuously transmits abnormal engine coolant temperature signals for 60 seconds or more. | <ul style="list-style-type: none">• Engine coolant temperature sensor• ECM |

Diagnosis Procedure

INFOID:000000007350330

1. PERFORM SELF DIAGNOSIS OF ECM

Perform "Self Diagnosis Result" of ECM, and repair or replace malfunctioning parts.

- >> • [EC-107, "CONSULT Function"](#) (EXCEPT FOR MEXICO)
• [EC-542, "CONSULT Function"](#) (FOR MEXICO)

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

POWER SUPPLY AND GROUND CIRCUIT COMBINATION METER

COMBINATION METER : Diagnosis Procedure

INFOID:000000007350331

1. CHECK FUSE

Check for blown fuses.

| Terminal No. | Signal name | Fuses No. |
|--------------|----------------------|-----------|
| 1 | Battery power supply | 9 |
| 2 | Ignition signal | 3 |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Be sure to eliminate cause of malfunction before installing new fuse.

2. CHECK POWER SUPPLY CIRCUIT

Check voltage between combination meter harness connector and ground.

| Terminals | | Ignition switch position | |
|-------------------|----------|--------------------------|-----------------|
| (+) | (-) | | |
| Combination meter | | OFF | ON |
| Connector | Terminal | | |
| M34 | 1 | Battery voltage | Battery voltage |
| | 2 | Approx. 0 V | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check harness between combination meter and fuse.

3. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check continuity between combination meter harness connector and ground.

| Combination meter | | Ground | Continuity |
|-------------------|----------|--------|------------|
| Connector | Terminal | | |
| M34 | 3 | | Existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FUEL LEVEL SENSOR SIGNAL CIRCUIT

Component Function Check

INFOID:000000007350332

1. PERFORM COMPONENT FUNCTION CHECK (1)

1. Turn ignition switch OFF.
2. Disconnect fuel level sensor unit and fuel pump (fuel level sensor) connector.
3. Connect variable resistor between harness connector terminals located on the vehicle side of the fuel level sensor unit and fuel pump (fuel level sensor).

| Fuel level sensor unit and fuel pump (fuel level sensor) | | |
|--|-----------|---|
| Connector | Terminals | |
| B40 | 1 | 4 |

4. Set variable resistor according to the resistance value shown in the following table and turn ignition switch ON.

| Resistance (Ω *) (Approx.) | Fuel gauge indication position (Approx.) |
|---------------------------------------|---|
| Less than 6 | Full |
| 24.5 | 3/4 |
| 43 | 2/4 |
| 61.5 | 1/4 |
| More than 80.0 | Empty |

*: Reference resistance values used when the combination meter judges the indication position of the fuel gauge.

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Refer to [MWI-56, "Diagnosis Procedure"](#).

2. PERFORM COMPONENT FUNCTION CHECK (2)

Check the fuel level sensor unit and fuel pump (fuel level sensor) and/or fuel level sensor unit (sub). Refer to [MWI-57, "Component Inspection"](#).

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Replace the fuel level sensor unit and fuel pump (fuel level sensor) and/or fuel level sensor unit (sub). Refer to [FL-7, "2WD : Removal and Installation"](#) (2WD models for North America), [FL-11, "AWD : Removal and Installation"](#) (AWD models for North America) or [FL-28, "Removal and Installation"](#) (For Mexico).

Diagnosis Procedure

INFOID:000000007350333

1. CHECK FUEL LEVEL SENSOR UNIT AND FUEL PUMP (FUEL LEVEL SENSOR) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and fuel level sensor unit and fuel pump (fuel level sensor) connector.
3. Check continuity between combination meter harness connector and fuel level sensor unit and fuel pump (fuel level sensor) harness connector.

| Combination meter | | Fuel level sensor unit and fuel pump (fuel level sensor) | | Continuity |
|-------------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M34 | 34 | B40 | 4 | Existed |

4. Check continuity between combination meter harness connector and ground.

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

| | | | |
|-------------------|----------|--------|-------------|
| Combination meter | | Ground | Continuity |
| Connector | Terminal | | Not existed |
| M34 | 34 | | |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2. CHECK FUEL LEVEL SENSOR UNIT AND FUEL PUMP (FUEL LEVEL SENSOR) GROUND CIRCUIT

Check continuity between fuel level sensor unit and fuel pump (fuel level sensor) harness connector and combination meter harness connector.

| | | | | |
|--|----------|-------------------|----------|------------|
| Fuel level sensor unit and fuel pump (fuel level sensor) | | Combination meter | | Continuity |
| Connector | Terminal | Connector | Terminal | |
| B40 | 1 | M34 | 24 | |

Is the inspection result normal?

YES >> Replace combination meter. Refer to [MWI-69, "Removal and Installation"](#).

NO >> Repair harness or connector.

Component Inspection

INFOID:000000007350334


2WD MODELS FOR NORTH AMERICA

1. CHECK FUEL LEVEL SENSOR UNIT AND FUEL PUMP (FUEL LEVEL SENSOR)

1. Remove the fuel level sensor unit and fuel pump (fuel level sensor). Refer to [FL-7, "2WD : Removal and Installation"](#).
2. Check the resistance between fuel level sensor unit and fuel pump (fuel level sensor).

| Terminals | | Condition | Resistance (Ω) (Approx.) | Height [mm (in)] |
|--|---|------------|-----------------------------|------------------|
| Fuel level sensor unit and fuel pump (fuel level sensor) | | | | |
| 1 | 4 | Full* (A) | 5 | 178.4 (7.02) |
| | | Empty* (B) | 81.5 | 36.2 (1.425) |

*: When float rod is contact with stopper.



Is inspection result OK?

YES >> INSPECTION END

NO >> Replace fuel level sensor unit and fuel pump (fuel level sensor). Refer to [FL-7, "2WD : Removal and Installation"](#).

AWD MODELS FOR NORTH AMERICA

1. CHECK FUEL LEVEL SENSOR UNIT AND FUEL PUMP (FUEL LEVEL SENSOR)

1. Remove the fuel level sensor unit and fuel pump (fuel level sensor). Refer to [FL-11, "AWD : Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI


FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

- Check the resistance between fuel level sensor unit and fuel pump (fuel level sensor).

| Terminals | | Condition | Resistance (Ω) (Approx.) | Height [mm (in)] |
|--|---|------------|--------------------------------------|------------------|
| Fuel level sensor unit and fuel pump (fuel level sensor) | | | | |
| 6 | 1 | Full* (A) | 2.4 | 186.3 (7.33) |
| | | Empty* (B) | 79 | 36.3 (1.429) |
| 4 | 7 | — | 0 | — |

*: When float rod is contact with stopper.



Is inspection result OK?

YES >> GO TO 2.


NO >> Replace fuel level sensor unit and fuel pump (fuel level sensor). Refer to [FL-11, "AWD : Removal and Installation"](#).

2.CHECK FUEL LEVEL SENSOR UNIT (SUB)

- Remove the fuel level sensor unit (sub). Refer to [FL-11, "AWD : Removal and Installation"](#).
- Check the resistance between fuel level sensor unit (sub).

| Terminals | | Condition | Resistance (Ω) (Approx.) | Height [mm (in)] |
|---------------------------------|---|------------|--------------------------------------|------------------|
| Fuel level sensor unit (sub) | | | | |
| 7 | 6 | Full* (A) | 2.4 | 188 (7.4) |
| | | Empty* (B) | 39 | 31.5 (1.24) |

*: When float rod is contact with stopper.



Is inspection result OK?

YES >> INSPECTION END

NO >> Replace fuel level sensor unit (sub). Refer to [FL-11, "AWD : Removal and Installation"](#).


FOR MEXICO

1.CHECK FUEL LEVEL SENSOR UNIT AND FUEL PUMP (FUEL LEVEL SENSOR)

- Remove the fuel level sensor unit and fuel pump (fuel level sensor). Refer to [FL-28, "Removal and Installation"](#).
- Check the resistance between fuel level sensor unit and fuel pump (fuel level sensor).

| Terminals | | Condition | Resistance (Ω) (Approx.) | Height [mm (in)] |
|--|---|------------|--------------------------------------|------------------|
| Fuel level sensor unit and fuel pump (fuel level sensor) | | | | |
| 6 | 1 | Full* (A) | 2.4 | 187.8 (7.39) |
| | | Empty* (B) | 79 | 30.6 (1.205) |
| 4 | 7 | — | 0 | — |

*: When float rod is contact with stopper.



Is inspection result OK?

YES >> GO TO 2.

NO >> Replace fuel level sensor unit and fuel pump (fuel level sensor). Refer to [FL-28, "Removal and Installation"](#).

2.CHECK FUEL LEVEL SENSOR UNIT (SUB)

- Remove the fuel level sensor unit (sub). Refer to [FL-28, "Removal and Installation"](#).

FUEL LEVEL SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

2. Check the resistance between fuel level sensor unit (sub).


| Terminals | | Condition | Resistance (Ω) (Approx.) | Height [mm (in)] |
|------------------------------|---|------------|--------------------------------------|------------------|
| Fuel level sensor unit (sub) | | | | |
| 7 | 6 | Full* (A) | 2.4 | 187.8 (7.39) |
| | | Empty* (B) | 47 | 30.6 (1.205) |

*: When float rod is contact with stopper.

Is inspection result OK?

YES >> INSPECTION END

NO >> Replace fuel level sensor unit (sub). Refer to [FL-28, "Removal and Installation"](#).



A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

OIL PRESSURE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

OIL PRESSURE SWITCH SIGNAL CIRCUIT

Component Function Check

INFOID:000000007350335

1. CHECK COMBINATION METER INPUT SIGNAL

Select the "Data Monitor" for the "METER/M&A" and check the "OIL W/L" monitor value.

"OIL W/L"
 Ignition switch ON : On
 Engine running : Off

>> INSPECTION END

Diagnosis Procedure

INFOID:000000007350336

1. CHECK OIL PRESSURE SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector and oil pressure switch connector.
3. Check continuity between IPDM E/R harness connector and oil pressure switch harness connector.

| Terminals | | | | Continuity |
|-----------|----------|---------------------|----------|------------|
| (+) | | (-) | | |
| IPDM E/R | | Oil pressure switch | | |
| Connector | Terminal | Connector | Terminal | Existed |
| E13 | 23 | F63 | 1 | |

4. Check continuity between IPDM E/R harness connector and ground.

| Terminals | | | | Continuity |
|-----------|----------|--------|--|-------------|
| (+) | | (-) | | |
| IPDM E/R | | Ground | | |
| Connector | Terminal | Ground | | Not existed |
| E13 | 23 | | | |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Repair harness or connector.


Component Inspection

INFOID:000000007350337

1. CHECK OIL PRESSURE SWITCH

Check continuity between oil pressure switch and ground.

| Condition | Continuity |
|----------------|-------------|
| Engine stopped | Existed |
| Engine running | Not existed |



Is the inspection result normal?

- YES >> INSPECTION END

OIL PRESSURE SWITCH SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

NO >> Replace oil pressure switch.

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P

AMBIENT SENSOR SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

AMBIENT SENSOR SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:000000007350338

1. CHECK AMBIENT SENSOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and ambient sensor connector.
3. Check continuity between combination meter harness connector and ambient sensor harness connector.

| Terminals | | | | Continuity |
|-------------------|----------|----------------|----------|------------|
| (+) | | (-) | | |
| Combination meter | | Ambient sensor | | |
| Connector | Terminal | Connector | Terminal | |
| M34 | 19 | E44 | 1 | Existed |

4. Check continuity between combination meter harness connector and ground.

| Terminals | | | Continuity |
|-------------------|----------|--------|-------------|
| (+) | | (-) | |
| Combination meter | | Ground | |
| Connector | Terminal | | |
| M34 | 19 | | Not existed |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2. CHECK AMBIENT SENSOR GROUND CIRCUIT

Check continuity between combination meter harness connector and ambient sensor harness connector.

| Terminals | | | | Continuity |
|-------------------|----------|----------------|----------|------------|
| (+) | | (-) | | |
| Combination meter | | Ambient sensor | | |
| Connector | Terminal | Connector | Terminal | |
| M34 | 20 | E44 | 2 | Existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair harness or connector.

Component Inspection

INFOID:000000007350339

Refer to [HAC-52, "Component Inspection"](#).

A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT

Diagnosis Procedure

INFOID:000000007350340

1. CHECK A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL

1. Turn ignition switch ON.
2. Check voltage between combination meter harness connector and ground.

| Terminals | | Voltage (Pyrex.) |
|-------------------|----------|---------------------|
| (+) | (-) | |
| Combination meter | | Ground |
| Connector | Terminal | |
| M34 | 5 | |
| | | 5 V |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 2.

2. CHECK A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector and auto amp. connector.
3. Check continuity between combination meter harness connector and auto amp. harness connector.

| Combination meter | | Auto amp. | | Continuity |
|-------------------|----------|-----------|----------|------------|
| Connector | Terminal | Connector | terminal | |
| M34 | 5 | M55 | 28 | Existed |

4. Check continuity between combination meter harness connector and ground.

| Combination meter | | Ground | Continuity |
|-------------------|----------|--------|-------------|
| Connector | Terminal | | |
| M34 | 5 | | Not existed |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> Repair harness or connector.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P



THE FUEL GAUGE DOES NOT MOVE

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

THE FUEL GAUGE DOES NOT MOVE

Description

INFOID:000000007350341

Fuel gauge does not move from a certain position.

Diagnosis Procedure

INFOID:000000007350342

1. CONDUCTING THE COMBINATION METER SELF-DIAGNOSIS MODE

Perform the self-diagnosis mode of combination meter, and then check that the fuel gauge operates normally. Refer to [MWI-25, "On Board Diagnosis Function"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace combination meter. Refer to [MWI-69, "Removal and Installation"](#).

2. CHECK FLOAT INTERFERENCE

Check that the float arm interferes with or binds to other components in the fuel tank.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning part.

3. CHECK FUEL LEVEL SENSOR SIGNAL CIRCUIT

Check the fuel level sensor signal circuit. Refer to [MWI-56, "Component Function Check"](#).

Is the inspection result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> Repair or replace malfunctioning parts.

THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

< SYMPTOM DIAGNOSIS >

THE OIL PRESSURE WARNING LAMP DOES NOT TURN ON

Description

INFOID:000000007350343

The oil pressure warning lamp stays off when the ignition switch is turned ON.

Diagnosis Procedure

INFOID:000000007350344

1.CHECK OIL PRESSURE WARNING LAMP

Perform auto active test of IPDM E/R. Refer to [PCS-8, "Diagnosis Description"](#).

Is oil pressure warning lamp illuminated?

YES >> GO TO 2.

NO >> Replace combination meter.

2.CHECK OIL PRESSURE SWITCH SIGNAL CIRCUIT

Check the oil pressure switch signal circuit. Refer to [MWI-60, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK OIL PRESSURE SWITCH UNIT

Perform a unit check for the oil pressure switch. Refer to [MWI-60, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace IPDM E/R.

NO >> Replace oil pressure switch.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

THE OIL PRESSURE WARNING LAMP DOES NOT TURN OFF

Description

INFOID:000000007350345

The oil pressure warning lamp remains illuminated while the engine is running (normal oil pressure).

Diagnosis Procedure

INFOID:000000007350346

1. CHECK OIL PRESSURE WARNING LAMP

Perform auto active test of IPDM E/R. Refer to [PCS-8, "Diagnosis Description"](#).

Is oil pressure warning lamp illuminated?

- YES >> GO TO 2.
- NO >> Replace combination meter.

2. CHECK IPDM E/R OUTPUT VOLTAGE

1. Turn ignition switch OFF.
2. Disconnect the oil pressure switch connector.
3. Turn ignition switch ON.
4. Check voltage between the oil pressure switch harness connector and ground.

| Terminals | | Voltage (Approx.) |
|---------------------|----------|----------------------|
| (+) | (-) | |
| Oil pressure switch | | 12 V |
| Connector | Terminal | |
| F63 | 1 | |
| | Ground | |

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 4.

3. CHECK OIL PRESSURE SWITCH UNIT

Perform a unit check for the oil pressure switch. Refer to [MWI-60, "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace IPDM E/R.
- NO >> Replace oil pressure switch.

4. CHECK OIL PRESSURE SWITCH SIGNAL CIRCUIT

check the oil pressure switch signal circuit. Refer to [MWI-60, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace IPDM E/R.
- NO >> Repair harness or connector.

THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

< SYMPTOM DIAGNOSIS >

THE AMBIENT TEMPERATURE DISPLAY IS INCORRECT

Description

INFOID:000000007350347

- The ambient air temperature display flashes and the ambient air temperature is not displayed.
- The displayed air ambient temperature is higher than the actual temperature.
- The displayed air ambient temperature is lower than the actual temperature.

Diagnosis Procedure

INFOID:000000007350348

NOTE:

Check that the symptom is not applicable to the normal operating condition before starting diagnosis. Refer to [MWI-68, "INFORMATION DISPLAY : Description"](#).

1.CHECK AMBIENT SENSOR SIGNAL CIRCUIT

Check the ambient sensor signal circuit. Refer to [MWI-62, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connector.

2.CHECK A/C AUTO AMP. CONNECTION RECOGNITION SIGNAL CIRCUIT

Check the a/c auto amp. connection recognition signal circuit. Refer to [MWI-63, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3.CHECK AMBIENT SENSOR

Perform a unit check for the ambient sensor. Refer to [MWI-62, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace combination meter.

NO >> Replace ambient sensor. Refer to [HAC-109, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

NORMAL OPERATING CONDITION INFORMATION DISPLAY

INFORMATION DISPLAY : Description

INFOID:000000007350349

OIL LEVEL

Oil level is not displayed after installation/removal of battery or combination meter. To display the oil level again, follow the steps below.

1. More than 5 minutes after turning key switch OFF, open the driver's door.
2. Turn key switch ON.

AMBIENT AIR TEMPERATURE

The displayed ambient air temperature on the information display may differ from the actual temperature because it is a corrected value calculated from the ambient sensor signal by the combination meter. Refer to [MWI-15. "INFORMATION DISPLAY : System Description"](#) for details on the correction process.

POSSIBLE DRIVING DISTANCE

The calculated possible driving distance may differ from the actual distance to empty if the refueling amount is approximately 15 ℓ (4 US gal, 3 - 1/4 Imp gal) or less. This is because the refuel control (moves the fuel gauge segment quicker than normal judging that the driver is refueling the vehicle) is not performed in such a case.

COMBINATION METER

< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

COMBINATION METER


Exploded View

INFOID:000000007350350

REMOVAL

Refer to [IP-13. "Exploded View"](#).

DISASSEMBLY



1. Front cover
2. Meter lens
3. Meter housing
4. Unified meter control unit

Removal and Installation

INFOID:000000007350351

Removal

1. Remove the cluster lid A. Refer to [IP-14. "Removal and Installation"](#).
2. Remove steering column cover upper. Refer to [IP-14. "Removal and Installation"](#).
3. Remove screw and connector, and then remove combination meter.

Installation

Install in the reverse order of removal.

Disassembly and Assembly

INFOID:000000007350352

DISASSEMBLY

1. Unlatch the pawls and unscrew the screws to remove the front cover assembly from the unified meter control unit.

CAUTION:

- Never touch the display, pointer, and the printed area of the dial during the work.
- Keep away from magnetic sources.

A
B
C
D
E
F
G
H
I
J
K
L
M
O
P

MWI

COMBINATION METER


< REMOVAL AND INSTALLATION >

ASSEMBLY

1. Check that the dial of the unified meter control unit is securely placed in the protrusion (A) and install the front cover assembly to the unified meter control unit.

CAUTION:

- Never touch the display, pointer, and the printed area of the dial during the work.
 - Keep away from magnetic sources.
 - If the front cover assembly is installed with the dial not placed properly, the following malfunction may occur.
 - The dial becomes dislocated and the pointer gets stuck, resulting in deactivation.
 - The basal portion of the step motor axis bends.
 - The dial gets deformed.
2. Install screws.



COMPASS

< REMOVAL AND INSTALLATION >

COMPASS

Exploded View

INFOID:000000007350353

Refer to [MIR-16. "Exploded View"](#).

Removal and Installation

INFOID:000000007350354

Refer to [MIR-16. "Removal and Installation"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

MWI

O

P