

A  
B  
C

# EXL

## SECTION

# EXTERIOR LIGHTING SYSTEM

D  
E

## CONTENTS

<p style="text-align: center;"><b>HALOGEN HEADLAMP</b></p> <p><b>PRECAUTION</b> ..... 7</p> <p><b>PRECAUTIONS</b> ..... 7</p> <p style="padding-left: 20px;">Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" ..... 7</p> <p style="padding-left: 20px;">Precaution for Work ..... 7</p> <p><b>PREPARATION</b> ..... 8</p> <p><b>PREPARATION</b> ..... 8</p> <p style="padding-left: 20px;">Special Service Tool ..... 8</p> <p><b>SYSTEM DESCRIPTION</b> ..... 9</p> <p><b>COMPONENT PARTS</b> ..... 9</p> <p style="padding-left: 20px;">Component Parts Location ..... 9</p> <p style="padding-left: 20px;">Optical Sensor ..... 10</p> <p style="padding-left: 20px;">Hazard Switch ..... 11</p> <p><b>SYSTEM</b> ..... 12</p> <p><b>HEADLAMP SYSTEM</b> ..... 12</p> <p style="padding-left: 20px;">HEADLAMP SYSTEM : System Description ..... 12</p> <p style="padding-left: 20px;">HEADLAMP SYSTEM : Fail-Safe ..... 12</p> <p><b>AUTO LIGHT SYSTEM</b> ..... 13</p> <p style="padding-left: 20px;">AUTO LIGHT SYSTEM : System Description ..... 13</p> <p><b>DAYTIME RUNNING LIGHT SYSTEM</b> ..... 14</p> <p style="padding-left: 20px;">DAYTIME RUNNING LIGHT SYSTEM : System Description ..... 14</p> <p><b>TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM</b> ..... 14</p> <p style="padding-left: 20px;">TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description ..... 15</p> <p><b>PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM</b> ..... 15</p>	<p style="text-align: right;">F G H I J K EXL M N O P</p> <p style="padding-left: 20px;">PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description ..... 15</p> <p style="padding-left: 20px;">PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-Safe ..... 16</p> <p><b>FRONT FOG LAMP SYSTEM</b> ..... 16</p> <p style="padding-left: 20px;">FRONT FOG LAMP SYSTEM : System Description ..... 17</p> <p style="padding-left: 20px;">FRONT FOG LAMP SYSTEM : Fail-Safe ..... 17</p> <p><b>EXTERIOR LAMP BATTERY SAVER SYSTEM</b> ..... 17</p> <p style="padding-left: 20px;">EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description ..... 18</p> <p><b>DIAGNOSIS SYSTEM (BCM)</b> ..... 19</p> <p><b>WITH INTELLIGENT KEY</b> ..... 19</p> <p style="padding-left: 20px;">WITH INTELLIGENT KEY : CONSULT Function (BCM - COMMON ITEM) ..... 19</p> <p style="padding-left: 20px;">WITH INTELLIGENT KEY : CONSULT Function (BCM - HEADLAMP) ..... 19</p> <p style="padding-left: 20px;">WITH INTELLIGENT KEY : CONSULT Function (BCM - FLASHER) ..... 21</p> <p><b>WITHOUT INTELLIGENT KEY</b> ..... 21</p> <p style="padding-left: 20px;">WITHOUT INTELLIGENT KEY : CONSULT Function (BCM - COMMON ITEM) ..... 21</p> <p style="padding-left: 20px;">WITHOUT INTELLIGENT KEY : CONSULT Function (BCM - HEADLAMP) ..... 22</p> <p style="padding-left: 20px;">WITHOUT INTELLIGENT KEY : CONSULT Function (BCM - FLASHER) ..... 23</p> <p><b>DIAGNOSIS SYSTEM (IPDM E/R)</b> ..... 24</p> <p style="padding-left: 20px;">CONSULT Function (IPDM E/R) ..... 24</p> <p><b>ECU DIAGNOSIS INFORMATION</b> ..... 27</p> <p><b>BCM, IPDM E/R</b> ..... 27</p> <p style="padding-left: 20px;">List of ECU Reference ..... 27</p> <p><b>WIRING DIAGRAM</b> ..... 28</p> <p><b>HEADLAMP</b> ..... 28</p>
--	---

Wiring Diagram .....	28	<b>HAZARD SWITCH .....</b>	<b>91</b>
<b>DAYTIME LIGHT SYSTEM .....</b>	<b>35</b>	Component Function Check .....	91
Wiring Diagram .....	35	Diagnosis Procedure .....	91
<b>AUTO LIGHT SYSTEM .....</b>	<b>42</b>	<b>TURN SIGNAL LAMP CIRCUIT .....</b>	<b>93</b>
Wiring Diagram .....	42	Description .....	93
<b>FRONT FOG LAMP SYSTEM .....</b>	<b>49</b>	Component Function Check .....	93
Wiring Diagram .....	49	Diagnosis Procedure .....	93
<b>TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM .....</b>	<b>55</b>	<b>B121A FRONT FOG LAMP LH POWER SUP- PLY CIRCUIT .....</b>	<b>96</b>
Wiring Diagram .....	55	DTC Logic .....	96
<b>PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM .....</b>	<b>62</b>	Diagnosis Procedure .....	96
Wiring Diagram .....	62	<b>B1231 DAYTIME RUNNING LIGHT RH POW- ER SUPPLY CIRCUIT .....</b>	<b>97</b>
<b>STOP LAMP .....</b>	<b>74</b>	DTC Logic .....	97
Wiring Diagram .....	74	Diagnosis Procedure .....	97
<b>BACK-UP LAMP .....</b>	<b>78</b>	<b>B1256 FRONT FOG LAMP RH POWER SUP- PLY CIRCUIT .....</b>	<b>98</b>
Wiring Diagram .....	78	DTC Logic .....	98
<b>BASIC INSPECTION .....</b>	<b>82</b>	Diagnosis Procedure .....	98
<b>DIAGNOSIS AND REPAIR WORKFLOW .....</b>	<b>82</b>	<b>B20CB DAYTIME RUNNING LIGHT LH POW- ER SUPPLY CIRCUIT .....</b>	<b>99</b>
Work Flow .....	82	DTC Logic .....	99
<b>INSPECTION AND ADJUSTMENT .....</b>	<b>85</b>	Diagnosis Procedure .....	99
<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT .....</b>	<b>85</b>	<b>B20CE HEADLAMP (HI) LH POWER SUP- PLY CIRCUIT .....</b>	<b>100</b>
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description .....	85	DTC Logic .....	100
ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement ....	85	Diagnosis Procedure .....	100
<b>SENSOR INITIALIZE .....</b>	<b>85</b>	<b>B20CF HEADLAMP (HI) RH POWER SUP- PLY CIRCUIT .....</b>	<b>101</b>
SENSOR INITIALIZE : Description .....	85	DTC Logic .....	101
SENSOR INITIALIZE : Special Repair Require- ment .....	85	Diagnosis Procedure .....	101
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>86</b>	<b>B20D0 HEADLAMP (LO) LH POWER SUP- PLY CIRCUIT .....</b>	<b>102</b>
<b>POWER SUPPLY AND GROUND CIRCUIT ....</b>	<b>86</b>	DTC Logic .....	102
<b>BCM (BODY CONTROL SYSTEM) (WITH INTEL- LIGENT KEY SYSTEM) .....</b>	<b>86</b>	Diagnosis Procedure .....	102
BCM (BODY CONTROL SYSTEM) (WITH INTEL- LIGENT KEY SYSTEM) : Diagnosis Procedure ....	86	<b>B20D1 HEADLAMP (LO) RH POWER SUP- PLY CIRCUIT .....</b>	<b>103</b>
<b>BCM (BODY CONTROL SYSTEM) (WITHOUT IN- TELLIGENT KEY SYSTEM) .....</b>	<b>86</b>	DTC Logic .....	103
BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM) : Diagnosis Proce- dure .....	86	Diagnosis Procedure .....	103
<b>OPTICAL SENSOR .....</b>	<b>88</b>	<b>B20D2 PARKING LAMP POWER SUPPLY CIRCUIT .....</b>	<b>104</b>
Component Function Check .....	88	DTC Logic .....	104
Diagnosis Procedure .....	88	Diagnosis Procedure .....	104
		<b>B20D4 TAIL LAMP LH POWER SUPPLY CIR- CUIT .....</b>	<b>105</b>
		DTC Logic .....	105
		Diagnosis Procedure .....	105
		<b>B20D5 TAIL LAMP RH POWER SUPPLY CIRCUIT .....</b>	<b>106</b>

DTC Logic .....	106	<b>SIDE TURN SIGNAL LAMP .....</b>	<b>126</b>	
Diagnosis Procedure .....	106	Removal and Installation .....	126	A
<b>SYMPTOM DIAGNOSIS .....</b>	<b>107</b>	Bulb Replacement .....	126	
<b>EXTERIOR LIGHTING SYSTEM SYMPTOMS. 107</b>		<b>REAR COMBINATION LAMP .....</b>	<b>127</b>	B
Symptom Table .....	107	Exploded View .....	127	
<b>NORMAL OPERATING CONDITION .....</b>	<b>109</b>	Removal and Installation .....	127	
Description .....	109	Bulb Replacement .....	127	C
<b>BOTH SIDE HEADLAMPS (HI) ARE NOT</b>		<b>HIGH-MOUNTED STOP LAMP .....</b>	<b>129</b>	
<b>TURNED ON .....</b>	<b>110</b>	Exploded View .....	129	
Description .....	110	Removal and Installation .....	129	D
Diagnosis Procedure .....	110	Bulb Replacement .....	129	
<b>BOTH SIDE HEADLAMPS (LO) ARE NOT</b>		<b>BACK-UP LAMP ASSEMBLY .....</b>	<b>130</b>	E
<b>TURNED ON .....</b>	<b>111</b>	Exploded View .....	130	
Description .....	111	Removal and Installation .....	130	
Diagnosis Procedure .....	111	Bulb Replacement .....	130	F
<b>PARKING, LICENSE PLATE, SIDE MARKER</b>		<b>LICENSE PLATE LAMP .....</b>	<b>132</b>	
<b>AND TAIL LAMPS ARE NOT TURNED ON ... 112</b>		Exploded View .....	132	
Description .....	112	Removal and Installation .....	132	G
Diagnosis Procedure .....	112	Bulb Replacement .....	132	
<b>BOTH SIDE FRONT FOG LAMPS ARE NOT</b>		<b>UNIT DISASSEMBLY AND ASSEMBLY . 134</b>		
<b>TURNED ON .....</b>	<b>113</b>	<b>FRONT COMBINATION LAMP .....</b>	<b>134</b>	H
Description .....	113	Exploded View .....	134	
Diagnosis Procedure .....	113	Disassembly and Assembly .....	134	I
<b>PERIODIC MAINTENANCE .....</b>	<b>114</b>	<b>REAR COMBINATION LAMP .....</b>	<b>135</b>	
<b>HEADLAMP AIMING ADJUSTMENT .....</b>	<b>114</b>	Exploded View .....	135	J
Inspection .....	114	Disassembly and Assembly .....	135	
Aiming Adjustment Procedure .....	115	<b>SERVICE DATA AND SPECIFICATIONS</b>		
<b>FRONT FOG LAMP AIMING ADJUSTMENT .. 117</b>		<b>(SDS) .....</b>	<b>136</b>	K
Aiming Adjustment Procedure .....	117	<b>SERVICE DATA AND SPECIFICATIONS</b>		
<b>REMOVAL AND INSTALLATION .....</b>	<b>119</b>	<b>(SDS) .....</b>	<b>136</b>	
<b>FRONT COMBINATION LAMP .....</b>	<b>119</b>	Bulb Specifications .....	136	
Exploded View .....	119	<b>LED HEADLAMP</b>		EXL
Removal and Installation .....	119	<b>PRECAUTION .....</b>	<b>137</b>	M
Bulb Replacement .....	119	<b>PRECAUTIONS .....</b>	<b>137</b>	
<b>FOG LAMP .....</b>	<b>121</b>	Precaution for Supplemental Restraint System		
Exploded View .....	121	(SRS) "AIR BAG" and "SEAT BELT PRE-TEN-		N
Removal and Installation .....	121	SIONER" .....	137	
Bulb Replacement .....	121	Precaution for Work .....	137	
<b>OPTICAL SENSOR .....</b>	<b>123</b>	<b>PREPARATION .....</b>	<b>138</b>	O
Removal and Installation .....	123	<b>PREPARATION .....</b>	<b>138</b>	
<b>COMBINATION SWITCH .....</b>	<b>124</b>	Special Service Tool .....	138	P
Exploded View .....	124	<b>SYSTEM DESCRIPTION .....</b>	<b>139</b>	
Removal and Installation .....	124	<b>COMPONENT PARTS .....</b>	<b>139</b>	
<b>HAZARD SWITCH .....</b>	<b>125</b>	Component Parts Location .....	139	
Exploded View .....	125	Optical Sensor .....	140	
Removal and Installation .....	125	Hazard Switch .....	141	

<b>SYSTEM</b> .....	142	<b>BCM, IPDM E/R</b> .....	158
<b>HEADLAMP SYSTEM</b> .....	142	List of ECU Reference .....	158
HEADLAMP SYSTEM : System Description .....	142	<b>WIRING DIAGRAM</b> .....	159
HEADLAMP SYSTEM : Fail-Safe .....	142	<b>HEADLAMP</b> .....	159
<b>AUTO LIGHT SYSTEM</b> .....	143	Wiring Diagram .....	159
AUTO LIGHT SYSTEM : System Description .....	143	<b>DAYTIME LIGHT SYSTEM</b> .....	165
<b>DAYTIME RUNNING LIGHT SYSTEM</b> .....	144	Wiring Diagram .....	165
DAYTIME RUNNING LIGHT SYSTEM : System Description .....	144	<b>AUTO LIGHT SYSTEM</b> .....	172
<b>HEADLAMP AIMING CONTROL SYSTEM (AUTO)</b> .....	144	Wiring Diagram .....	172
HEADLAMP AIMING CONTROL SYSTEM (AUTO) : System Diagram .....	145	<b>FRONT FOG LAMP SYSTEM</b> .....	179
HEADLAMP AIMING CONTROL SYSTEM (AUTO) : System Description .....	145	Wiring Diagram .....	179
<b>TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM</b> .....	145	<b>TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM</b> .....	185
TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description .....	146	Wiring Diagram .....	185
<b>PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM</b> .....	146	<b>PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM</b> .....	192
PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System Description .....	146	Wiring Diagram .....	192
PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-Safe .....	147	<b>STOP LAMP</b> .....	204
<b>FRONT FOG LAMP SYSTEM</b> .....	147	Wiring Diagram .....	204
FRONT FOG LAMP SYSTEM : System Description .....	148	<b>BACK-UP LAMP</b> .....	208
FRONT FOG LAMP SYSTEM : Fail-Safe .....	148	Wiring Diagram .....	208
<b>EXTERIOR LAMP BATTERY SAVER SYSTEM</b> .....	148	<b>HEADLAMP AIMING SYSTEM (AUTOMATIC)</b> .....	212
EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description .....	149	Wiring Diagram .....	212
<b>DIAGNOSIS SYSTEM (BCM)</b> .....	150	<b>BASIC INSPECTION</b> .....	219
<b>WITH INTELLIGENT KEY</b> .....	150	<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	219
WITH INTELLIGENT KEY : CONSULT Function (BCM - COMMON ITEM) .....	150	Work Flow .....	219
WITH INTELLIGENT KEY : CONSULT Function (BCM - HEADLAMP) .....	150	<b>INSPECTION AND ADJUSTMENT</b> .....	222
WITH INTELLIGENT KEY : CONSULT Function (BCM - FLASHER) .....	152	<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT</b> .....	222
<b>WITHOUT INTELLIGENT KEY</b> .....	152	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description .....	222
WITHOUT INTELLIGENT KEY : CONSULT Function (BCM - COMMON ITEM) .....	152	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement ..	222
WITHOUT INTELLIGENT KEY : CONSULT Function (BCM - HEADLAMP) .....	153	<b>SENSOR INITIALIZE</b> .....	222
WITHOUT INTELLIGENT KEY : CONSULT Function (BCM - FLASHER) .....	154	SENSOR INITIALIZE : Description .....	222
<b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....	155	SENSOR INITIALIZE : Special Repair Requirement .....	222
CONSULT Function (IPDM E/R) .....	155	<b>LED HEADLAMP OPERATION INSPECTION</b> .....	223
<b>ECU DIAGNOSIS INFORMATION</b> .....	158	Diagnosis Procedure .....	223
		<b>DTC/CIRCUIT DIAGNOSIS</b> .....	224
		<b>POWER SUPPLY AND GROUND CIRCUIT</b> .....	224
		<b>BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM)</b> .....	224

BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM) : Diagnosis Procedure ...	224	Diagnosis Procedure .....	246	A
<b>BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM) .....</b>	<b>224</b>	<b>B20CF HEADLAMP (HI) RH POWER SUPPLY CIRCUIT .....</b>	<b>247</b>	B
BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM) : Diagnosis Procedure .....	224	DTC Logic .....	247	
<b>OPTICAL SENSOR .....</b>	<b>226</b>	Diagnosis Procedure .....	247	
Component Function Check .....	226	<b>B20D0 HEADLAMP (LO) LH POWER SUPPLY CIRCUIT .....</b>	<b>248</b>	C
Diagnosis Procedure .....	226	DTC Logic .....	248	
<b>HAZARD SWITCH .....</b>	<b>229</b>	Diagnosis Procedure .....	248	D
Component Function Check .....	229	<b>B20D1 HEADLAMP (LO) RH POWER SUPPLY CIRCUIT .....</b>	<b>249</b>	E
Diagnosis Procedure .....	229	DTC Logic .....	249	
<b>TURN SIGNAL LAMP CIRCUIT .....</b>	<b>231</b>	Diagnosis Procedure .....	249	
Description .....	231	<b>B20D2 PARKING LAMP POWER SUPPLY CIRCUIT .....</b>	<b>250</b>	F
Component Function Check .....	231	DTC Logic .....	250	
Diagnosis Procedure .....	231	Diagnosis Procedure .....	250	
<b>B121A FRONT FOG LAMP LH POWER SUPPLY CIRCUIT .....</b>	<b>234</b>	<b>B20D4 TAIL LAMP LH POWER SUPPLY CIRCUIT .....</b>	<b>251</b>	G
DTC Logic .....	234	DTC Logic .....	251	
Diagnosis Procedure .....	234	Diagnosis Procedure .....	251	H
<b>B1231 DAYTIME RUNNING LIGHT RH POWER SUPPLY CIRCUIT .....</b>	<b>235</b>	<b>B20D5 TAIL LAMP RH POWER SUPPLY CIRCUIT .....</b>	<b>252</b>	I
DTC Logic .....	235	DTC Logic .....	252	
Diagnosis Procedure .....	235	Diagnosis Procedure .....	252	
<b>B1256 FRONT FOG LAMP RH POWER SUPPLY CIRCUIT .....</b>	<b>236</b>	<b>B20DB HEIGHT SENSOR INITIALIZE NOT DONE .....</b>	<b>253</b>	J
DTC Logic .....	236	DTC Logic .....	253	
Diagnosis Procedure .....	236	Diagnosis Procedure .....	253	K
<b>B1C00 HEIGHT SENSOR POWER SUPPLY CIRCUIT .....</b>	<b>237</b>	<b>B20E2 LED HEADLAMP RH .....</b>	<b>254</b>	EXL
DTC Logic .....	237	DTC Logic .....	254	
Diagnosis Procedure .....	237	Diagnosis Procedure .....	254	
<b>B1C01 FRONT HEIGHT SENSOR SIGNAL ...</b>	<b>239</b>	<b>B20E3 LED HEADLAMP LH .....</b>	<b>255</b>	M
DTC Logic .....	239	DTC Logic .....	255	
Diagnosis Procedure .....	239	Diagnosis Procedure .....	255	
<b>B1C02 REAR HEIGHT SENSOR SIGNAL .....</b>	<b>241</b>	<b>SYMPTOM DIAGNOSIS .....</b>	<b>256</b>	N
DTC Logic .....	241	<b>EXTERIOR LIGHTING SYSTEM SYMPTOMS.</b>	<b>256</b>	
Diagnosis Procedure .....	241	Symptom Table .....	256	
<b>B1C07 AIMING MOTOR DRIVE SIGNAL .....</b>	<b>243</b>	<b>NORMAL OPERATING CONDITION .....</b>	<b>258</b>	O
DTC Logic .....	243	Description .....	258	
Diagnosis Procedure .....	243	<b>BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON .....</b>	<b>259</b>	P
<b>B20CB DAYTIME RUNNING LIGHT LH POWER SUPPLY CIRCUIT .....</b>	<b>245</b>	Description .....	259	
DTC Logic .....	245	Diagnosis Procedure .....	259	
Diagnosis Procedure .....	245	<b>BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON .....</b>	<b>260</b>	
<b>B20CE HEADLAMP (HI) LH POWER SUPPLY CIRCUIT .....</b>	<b>246</b>	Description .....	260	
DTC Logic .....	246			

Diagnosis Procedure .....	260	<b>HAZARD SWITCH .....</b>	<b>276</b>
<b>PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON ..</b>	<b>261</b>	Exploded View .....	276
Description .....	261	Removal and Installation .....	276
Diagnosis Procedure .....	261	<b>SIDE TURN SIGNAL LAMP .....</b>	<b>277</b>
<b>BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON .....</b>	<b>262</b>	Removal and Installation .....	277
Description .....	262	Bulb Replacement .....	277
Diagnosis Procedure .....	262	<b>REAR COMBINATION LAMP .....</b>	<b>278</b>
<b>PERIODIC MAINTENANCE .....</b>	<b>263</b>	Exploded View .....	278
<b>HEADLAMP AIMING ADJUSTMENT .....</b>	<b>263</b>	Removal and Installation .....	278
Inspection .....	263	Bulb Replacement .....	278
Aiming Adjustment Procedure .....	264	<b>HIGH-MOUNTED STOP LAMP .....</b>	<b>280</b>
<b>FRONT FOG LAMP AIMING ADJUSTMENT .</b>	<b>266</b>	Exploded View .....	280
Aiming Adjustment Procedure .....	266	Removal and Installation .....	280
<b>REMOVAL AND INSTALLATION .....</b>	<b>268</b>	Bulb Replacement .....	280
<b>FRONT COMBINATION LAMP .....</b>	<b>268</b>	<b>BACK-UP LAMP ASSEMBLY .....</b>	<b>281</b>
Exploded View .....	268	Exploded View .....	281
Removal and Installation .....	268	Removal and Installation .....	281
Bulb Replacement .....	268	Bulb Replacement .....	281
<b>HEIGHT SENSOR .....</b>	<b>270</b>	<b>LICENSE PLATE LAMP .....</b>	<b>283</b>
Exploded View .....	270	Exploded View .....	283
Removal and Installation - Front Height Sensor ...	270	Removal and Installation .....	283
Exploded View .....	271	Bulb Replacement .....	283
Removal and Installation - Rear Height Sensor ...	271	<b>UNIT DISASSEMBLY AND ASSEMBLY ..</b>	<b>285</b>
<b>FOG LAMP .....</b>	<b>272</b>	<b>FRONT COMBINATION LAMP .....</b>	<b>285</b>
Exploded View .....	272	Exploded View .....	285
Removal and Installation .....	272	Disassembly and Assembly .....	285
Bulb Replacement .....	272	<b>REAR COMBINATION LAMP .....</b>	<b>286</b>
<b>OPTICAL SENSOR .....</b>	<b>274</b>	Exploded View .....	286
Removal and Installation .....	274	Disassembly and Assembly .....	286
<b>COMBINATION SWITCH .....</b>	<b>275</b>	<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	<b>287</b>
Exploded View .....	275	<b>SERVICE DATA AND SPECIFICATIONS (SDS) .....</b>	<b>287</b>
Removal and Installation .....	275	Bulb Specifications .....	287

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010336851

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000010336852

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

< PREPARATION >

# PREPARATION


## PREPARATION

### Special Service Tool

INFOID:0000000010351310

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ



# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[HALOGEN HEADLAMP]

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000010286948



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]


- A. Right rear wheel area                      B. Instrument panel                      C. Engine compartment  
 D. Left side of instrument panel (view with trim panel removed)

No.	Part	Function
1.	Optical sensor	Refer to <a href="#">EXL-10, "Optical Sensor"</a> .
2.	LED headlamp control module	Turns the headlamps ON according to the power supply from IPDM E/R.
3.	Headlamp aiming motor	Moves the headlamps up/down based on inputs from the front and rear height sensors.
4.	Front height sensor	Sends the vehicles pitch angle signal to the IPDM E/R necessary for adjusting the headlamp aiming motors.
5.	Rear height sensor	Sends the vehicles pitch angle signal to the IPDM E/R necessary for adjusting the headlamp aiming motors.
6.	Combination switch (Lighting and turn signal switch)	Refer to <a href="#">BCS-9, "COMBINATION SWITCH READING SYSTEM : System Description"</a> (with Intelligent Key) or <a href="#">BCS-81, "COMBINATION SWITCH READING SYSTEM : System Description"</a> (without Intelligent Key).
7.	Hazard switch	Refer to <a href="#">EXL-11, "Hazard Switch"</a> .
8.	IPDM E/R	<ul style="list-style-type: none"> <li>Supplies voltage to the load according to the request from BCM (via CAN communication).</li> <li>Refer to <a href="#">PCS-4, "Component Parts Location"</a> for detailed installation location.</li> </ul>
9.	BCM	<ul style="list-style-type: none"> <li>Detects each switch condition by the combination switch reading function.</li> <li>Judges that the exterior lamps are turned ON according to the vehicle condition.</li> <li>Requests the headlamp (HI/LO), tail lamp and front fog lamp ON to IPDM E/R (via CAN communication).</li> <li>Requests high beam indicator lamp ON to the combination meter (via CAN communication).</li> <li>Judges the outside brightness from the optical sensor signal.</li> <li>Judges the ON/OFF timing according to the vehicle condition.</li> <li>Judges the ON/OFF status of the exterior lamp according to the outside brightness and the vehicle condition.</li> <li>Refer to <a href="#">BCS-7, "BODY CONTROL SYSTEM : Component Parts Location"</a> (with Intelligent Key) or <a href="#">BCS-79, "BODY CONTROL SYSTEM : Component Parts Location"</a> (without Intelligent Key).</li> </ul>

## Optical Sensor

INFOID:000000010286949

Optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.



# COMPONENT PARTS


< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]

## Hazard Switch

INFOID:000000010286950

Inputs the hazard switch ON/OFF signal to BCM.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


SYSTEM

HEADLAMP SYSTEM

HEADLAMP SYSTEM : System Description

INFOID:000000010336173

SYSTEM DIAGRAM



OUTLINE

Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and Smart FET control function of IPDM E/R.

HEADLAMP (LO) OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R with CAN communication according to the headlamp (LO) ON condition.

Headlamp (LO) ON condition

- Lighting switch 2ND
- Lighting switch AUTO (auto light function ON judgment)
- Lighting switch AUTO, with the front fog lamp switch ON and the power switch ON
- Lighting switch PASS

HEADLAMP (HI) OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter with CAN communication according to the headlamp (HI) ON condition.

Headlamp (HI) ON condition:

- Lighting switch HI with the lighting switch 2ND or AUTO (auto light function ON judgment)
- Lighting switch PASS
- Lighting switch AUTO, with the front fog lamp switch ON, the power switch ON and lighting switch HI
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the headlamp ON according to the high beam request signal.

HEADLAMP SYSTEM : Fail-Safe

INFOID:000000010336174

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If no CAN communication is available with BCM

# SYSTEM

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]


Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"> <li>• Turns ON the headlamp low beam when the power switch is turned ON</li> <li>• Turns OFF the headlamp low beam when the power switch is turned OFF</li> </ul>

## AUTO LIGHT SYSTEM

### AUTO LIGHT SYSTEM : System Description

INFOID:000000010336175

#### SYSTEM DIAGRAM



#### OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Controlled by BCM:

- Combination switch reading function
- Headlamp control function
- Auto light function
- Delay timer function
- Auto light adjustment system

Controlled by IPDM E/R:

- Auto light system has the auto light function and delay timer function.
- Auto light function automatically turns ON/OFF the exterior lamps\* and each illumination automatically, depending on the outside brightness.
- When auto light system turns the exterior lamps ON with the power switch OFF, delay timer function turns the exterior lamps OFF, depending on the vehicle condition with the auto light function after a certain period of time.

\*: Headlamp (LO/HI), parking lamp, side marker lamp, tail lamp and front fog lamp (Headlamp HI and front fog lamp depend on the combination switch condition).

#### AUTO LIGHT FUNCTION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM supplies voltage to optical sensor when the power switch is turned ON or ACC.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM judges outside brightness from the optical sensor signal and judges ON/OFF condition of the exterior lamp and each illumination according to the outside brightness.
- BCM transmits each request signal to IPDM E/R and combination meter via CAN communication according to ON/OFF condition by the auto light function.

#### NOTE:

ON/OFF timing differs based on the sensitivity from the setting. The setting can be set by CONSULT. Refer to.

#### AUTO LIGHT ADJUSTMENT SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P

# SYSTEM

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]

The auto light adjustment system automatically, dims/brightens the display, according to brightness outside the vehicle, when lighting switch 1ST, lighting switch 2ND or lighting switch AUTO is operated. Refer to [EXL-13, "AUTO LIGHT SYSTEM : System Description"](#).

## DELAY TIMER FUNCTION

BCM turns the exterior lamp OFF depending on the vehicle condition with the auto light function when the power switch is turned OFF.

- Turns the exterior lamp OFF 5 minutes after detecting that any door opens. (Door switch ON).
- Turns the exterior lamp OFF a certain period of time\* after closing all doors. (Door switch ON→OFF).
- Turns the exterior lamp OFF with the power switch ACC or the light switch OFF.

\*: The preset time is 45 seconds. The timer operating time can be set by CONSULT. Refer to [BCS-19, "HEADLAMP : CONSULT Function \(BCM - HEADLAMP\)"](#) (with Intelligent Key) or [BCS-90, "HEADLAMP : CONSULT Function \(BCM - HEADLAMP\)"](#) (without Intelligent Key).

### NOTE:


When any position other than the light switch AUTO is set, the auto light system function switches to the exterior lamp battery saver function.

## DAYTIME RUNNING LIGHT SYSTEM

### DAYTIME RUNNING LIGHT SYSTEM : System Description

INFOID:000000010336176

### SYSTEM DIAGRAM



### OUTLINE

- Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and smart FET of IPDM E/R.

### DAYTIME RUNNING LIGHT OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects the vehicle condition according to power switch
- BCM detects the parking brake condition by the parking brake switch signal received from combination meter using CAN communication.
- BCM transmits the daytime running light request signal to IPDM E/R using CAN communication according to the daytime running light ON condition.

Daytime running light ON condition:


- Vehicle condition READY
- Lighting switch OFF or 1ST
- Lighting switch AUTO, and the auto light function OFF judgment
- Parking brake switch OFF
- IPDM E/R controls the daytime running light request signal.
- Power is supplied from the IPDM E/R to the daytime lights.

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description

INFOID:0000000010336177

SYSTEM DIAGRAM



OUTLINE

Turn signal lamp and the hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the power switch is ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuit when the hazard switch is ON. BCM blinks the hazard warning lamp.

TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL OPERATION

- BCM transmits the turn signal indicator lamp signal to the combination meter using CAN communication while the turn signal lamp and the hazard warning lamp are operating.
- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn signal indicator lamp signal.

HIGH FLASHER OPERATION

- BCM detects the turn signal lamp circuit status from the current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

**NOTE:**

The blinking speed is normal while operating the hazard warning lamp.


PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System De-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

scription

SYSTEM DIAGRAM



OUTLINE

Parking, license plate, side marker and tail lamps are controlled by combination switch reading function and headlamp control function of BCM, and smart FET of IPDM E/R.

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter via CAN communication according to the ON/OFF condition of the parking, license plate, side marker and tail lamps.

Parking, license plate, side marker and tail lamps ON condition:

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment
- Lighting switch AUTO, with the front fog lamp switch ON and the power switch ON
- IPDM E/R turns the parking, license plate, side marker and tail lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-Safe

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If no CAN communication is available with BCM

Control part	Fail-safe operation
<ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Illumination</li> <li>• Tail lamp</li> <li>• Side marker lamp</li> </ul>	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp when the power switch is turned ON</li> <li>• Turns OFF the tail lamp when the power switch is turned OFF</li> </ul>


FRONT FOG LAMP SYSTEM



FRONT FOG LAMP SYSTEM : System Description

INFOID:000000010336180

SYSTEM DIAGRAM



OUTLINE

Front fog lamp is controlled by combination switch reading function, front fog lamp control function of BCM, and smart FET function of IPDM E/R.

FRONT FOG LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front fog lights request signal to IPDM E/R and the combination meter via CAN communication according to the front fog lamp ON condition.

Front fog lamp ON condition:

- Front fog lamp switch ON, and any of the following condition is satisfied (except for the high beam ON).
- Lighting switch 2ND
- Lighting switch AUTO and the power switch ON

IPDM E/R turns the front fog lamp ON according to the front fog lights request signal.

Combination meter turns the front fog lamp indicator lamp ON according to the front fog lights request signal.

FRONT FOG LAMP SYSTEM : Fail-Safe

INFOID:000000010336181

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If no CAN communication is available with BCM

Control part	Fail-safe operation
Front fog lamp	Front fog lamp OFF


EXTERIOR LAMP BATTERY SAVER SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000010336182

SYSTEM DIAGRAM



OUTLINE

- Exterior lamp battery saver system is controlled by each function of BCM and IPDM E/R.

Controlled by BCM:

- Combination switch reading function
- Headlamp control function
- Exterior lamp battery saver function

Controlled by IPDM E/R:

- BCM turns the exterior lamps\* OFF after a period of time to prevent the battery from over-discharge when the power switch is turned OFF with the exterior lamps ON.

\*: Headlamp (LO/HI), parking lamp, tail lamp, side marker lamp, license plate lamp and front fog lamp

EXTERIOR LAMP BATTERY SAVER ACTIVATION

BCM activates the timer and turns the exterior lamp OFF 5 minutes after the power switch is turned from ON → OFF with the exterior lamps ON.

**NOTE:**

- Headlamp control function turns the exterior lamps ON normally when the power switch is turned ACC or set the vehicle to READY (both before and after the exterior lamp battery saver is turned OFF).
- The timer starts at the time that the lighting switch is turned from OFF → 1ST or 2ND with the exterior lamps OFF.

# DIAGNOSIS SYSTEM (BCM)

[HALOGEN HEADLAMP]

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM) WITH INTELLIGENT KEY

WITH INTELLIGENT KEY : CONSULT Function (BCM - COMMON ITEM) INFOID:0000000010287175

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> <li>The vehicle specification can be read and saved.</li> <li>The vehicle specification can be written when replacing BCM.</li> </ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

### SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		x	x	x	x		
Rear window defogger	REAR DEFOGGER			x	x	x		
Warning chime	BUZZER			x	x			
Interior room lamp timer	INT LAMP			x	x	x		
Exterior lamp	HEADLAMP			x	x	x		
Wiper and washer	WIPER			x	x	x		
Turn signal and hazard warning lamps	FLASHER			x	x			
Intelligent Key system	INTELLIGENT KEY		x	x	x	x		
Combination switch	COMB SW			x				
BCM	BCM	x	x			x	x	x
Immobilizer	IMMU		x	x	x			
Interior room lamp battery saver	BATTERY SAVER			x	x			
Back door open	TRUNK			x				
Vehicle security system	THEFT ALM			x	x	x		
RAP system	RETAINED PWR			x				
Signal buffer system	SIGNAL BUFFER			x				
TPMS	AIR PRESSURE MONITOR		x	x	x	x		

WITH INTELLIGENT KEY : CONSULT Function (BCM - HEADLAMP)

INFOID:0000000010287175

### DATA MONITOR

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]

Monitor Item [Unit]	Description
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
ENGINE STATE [STOP/STALL/CRANK/RUN]	Indicates engine status received from ECM on CAN communication line.
VEH SPEED 1 [km/h]	Indicates vehicle speed signal received from ABS on CAN communication line.
TURN SIGNAL R [On/Off]	Indicates condition of combination switch.
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW [On/Off]	
LIGHT OFF SW [On/Off]	
PASSING SW [On/Off]	
AUTO LIGHT SW [On/Off]	
FR FOG SW [On/Off]	
DOOR SW-DR [On/Off]	
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of back door switch.
OPTI SEN (DTCT) [V]	Indicates outside brightness voltage signal from optical sensor.
OPTI SEN (FILT) [V]	Indicates outside brightness voltage signal from optical sensor filtered by BCM.

## ACTIVE TEST

Test Item	Description
FR FOG LAMP	This test is able to check front fog lamp operation [On/Off].
STOP LAMP 1	This test is able to check rear combination lamp stop lamp operation [On/Off].
STOP LAMP 3	This test is able to check high-mounted stop lamp operation [On/Off].

## WORK SUPPORT

Support Item	Setting	Description
TWILIGHT ON	MODE2*	Autolamp function ON.
	MODE1	Autolamp function OFF.
CUSTOM A/LIGHT SETTING	MODE4	Less sensitive than normal setting (turns ON later).
	MODE3	More sensitive than MODE2.
	MODE2	More sensitive than normal setting (turns ON earlier).
	MODE1*	Normal setting.
ILL DELAY SET	MODE 8	Autolamp delay timer.
	MODE 7	
	MODE 6	
	MODE 4	
	MODE 5	
	MODE 3	
	MODE 2	
MODE 1*		

\*: Initial setting

# DIAGNOSIS SYSTEM (BCM)

[HALOGEN HEADLAMP]

< SYSTEM DESCRIPTION >

WITH INTELLIGENT KEY : CONSULT Function (BCM - FLASHER)

INFOID:000000010287177

## DATA MONITOR

Monitor Item [Unit]	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
TURN SIGNAL R [On/Off]	Indicates condition of turn signal function of combination switch.
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	Indicates condition of hazard switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.
RKE-PANIC [On/Off]	Indicates condition of panic alarm signal from Intelligent Key.

## ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [Off/LH/RH].

## WITHOUT INTELLIGENT KEY

WITHOUT INTELLIGENT KEY : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000010287178

## APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> <li>The vehicle specification can be read and saved.</li> <li>The vehicle specification can be written when replacing BCM.</li> </ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

## SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK			x	x	x		
Rear window defogger	REAR DEFOGGER			x	x	x		

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Warning chime	BUZZER			×	×			
Interior room lamp timer	INT LAMP			×	×	×		
Remote keyless entry system	MULTI REMOTE ENT					×		
Exterior lamp	HEADLAMP			×	×			
Wiper and washer	WIPER			×	×	×		
Turn signal and hazard warning lamps	FLASHER			×	×			
Combination switch	COMB SW			×				
BCM	BCM	×	×			×	×	×
Immobilizer	IMMU		×		×			
Interior room lamp battery saver	BATTERY SAVER			×	×			
Back door open	TRUNK			×				
Vehicle security system	THEFT ALM			×	×	×		
RAP system	RETAINED PWR			×				
TPMS	AIR PRESSURE MONITOR		×	×	×	×		

**WITHOUT INTELLIGENT KEY : CONSULT Function (BCM - HEADLAMP)** INFOID:000000010287179

## DATA MONITOR

Monitor Item [Unit]	Description
TURN SIGNAL R [On/Off]	Indicates condition of combination switch.
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW [On/Off]	
LIGHT OFF SW [On/Off]	
PASSING SW [On/Off]	
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of back door switch.

## ACTIVE TEST

Test Item	Description
DAYTIME RUNNING LIGHT	This test is able to check daytime running lamp operation [On/Off].
ILL DIM SIGNAL	This test is able to check head lamp illumination dimming operation [On/Off].

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]

WITHOUT INTELLIGENT KEY : CONSULT Function (BCM - FLASHER)

INFOID:000000010287180

## DATA MONITOR

Monitor Item [Unit]	Description
TURN SIGNAL R [On/Off]	Indicates condition of turn signal function of combination switch.
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	Indicates condition of hazard switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.
RKE-PANIC [On/Off]	Indicates condition of panic alarm signal from Intelligent Key.

## ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [Off/LH/RH].

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P

# DIAGNOSIS SYSTEM (IPDM E/R)

[HALOGEN HEADLAMP]

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (IPDM E/R)

### CONSULT Function (IPDM E/R)

INFOID:000000010287181

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
Ecu Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

#### ECU IDENTIFICATION

The IPDM E/R part number is displayed.

#### SELF DIAGNOSTIC RESULT

Refer to [PCS-20. "DTC Index"](#).

#### DATA MONITOR

Monitor Item [Unit]	Description
REVERSE SIGNAL [Open/Close]	Indicates condition of transmission range switch R (Reverse) position.
IGN RELAY [Open/Close]	Indicates condition of ignition relay-1.
PUSH SW [Open/Close]	Indicates condition of push-button ignition switch.
INTERLOCK/PNP SW [Open/Close]	Indicates condition of transmission range switch P (Park) and N (Neutral) positions.
OIL PRESSURE SW [Open/Close]	Indicates condition of oil pressure switch.
HOOD SW [Open/Close]	Indicates condition of hood switch.
COMPRESSOR [OFF/ON]	Indicates condition of A/C compressor.
HORN RELAY [OFF/ ON]	Indicates condition of horn relay.
COOLING FAN [OFF/ON]	Indicates condition of cooling fan relay-1.
FRONT WIPER HI/LO RELAY [OFF/ON]	Indicates condition of front wiper high relay.
FRONT WIPER RELAY [OFF/ON]	Indicates condition of front wiper relay.
IGN RELAY OFF STATUS [OFF/ON]	Indicates condition of ignition relay-1 OFF status.
IGN RELAY ON STATUS [OFF/ON]	Indicates condition of ignition relay-1 ON status.
COOLING FAN RELAY 1 [OFF/ON]	Indicates condition of cooling fan relay-1.
STARTER RELAY [OFF/ON]	Indicates condition of starter relay.
COMP ECV DUTY [%]	Indicates condition of A/C compressor.
COOLING FAN RELAY 2 [%]	Indicates condition of cooling fan relay-2.
FR FOG LAMP LH [%]	Indicates condition of front fog lamp LH.
FR FOG LAMP RH [%]	Indicates condition of front fog lamp RH.
PARKING LAMP [%]	Indicates condition of parking lamp.
TAIL LAMP LH [%]	Indicates condition of tail lamp LH.
TAIL LAMP RH [%]	Indicates condition of tail lamp RH.
DAYTIME RUNNING LIGHT LH [%]	Indicates condition of daytime running light LH.
DAYTIME RUNNING LIGHT RH [%]	Indicates condition of daytime running light RH.
HEADLAMP (HI) LH [%]	Indicates condition of headlamp high beam LH.



# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[HALOGEN HEADLAMP]

Monitor Item [Unit]	Description	
HEADLAMP (HI) RH [%]	Indicates condition of headlamp high beam RH.	A
HEADLAMP (LO) LH [%]	Indicates condition of headlamp low beam LH.	
HEADLAMP (LO) RH [%]	Indicates condition of headlamp low beam RH.	B
A/C RELAY STUCK [NG/OK]	Indicates condition of A/C relay.	
A/C RELAY [Off/On]	Indicates condition of A/C relay.	
COMP ECV STATUS [NG/OK]	Indicates condition of A/C compressor.	C
VEHICLE SECURITY HORN [Off/On]	Indicates condition of horn relay.	
BATTERY CURRENT SENSOR [NG/OK]	Indicates condition of battery current sensor.	D
FRONT FOG LAMP [Off/On]	Indicates condition of front fog lamps.	
COMP ECV CURRENT [A]	Indicates condition of A/C compressor current.	
BATTERY VOLTAGE [V]	Indicates condition of battery voltage.	E
COOLING FAN DUTY [%]	Indicates condition of cooling fans.	
HOOD SW (CAN) [OPEN/CLOSE]	Indicates condition of hood switch.	F
FRONT WIPER [STOP/LOW/HIGH]	Indicates condition of front wiper motor.	
FR WIPER STOP POSITION [STOP P/ACTIVE P]	Indicates condition of front wiper motor stop.	
HEADLAMP (HI) [Off/On]	Indicates condition of headlamp high beams.	G
HEADLAMP (LO) [Off/On]	Indicates condition of headlamp low beams.	
IGNITION RELAY STATUS [Off/On]	Indicates condition of ignition relay-1.	
IGN RELAY MONITOR [Off/On]	Indicates condition of ignition relay-1 feedback.	H
IGNITION POWER SUPPLY [Off/On]	Indicates condition of ignition relay-1.	
INTERLOCK/PNP SW (CAN) [Off/On]	Indicates condition of transmission range switch P (Park) and N (Neutral) positions.	I
PUSH-BUTTON IGN SW (CAN) [Off/On]	Indicates condition of push-button ignition switch.	
TAIL LAMP [Off/On]	Indicates condition of tail lamps.	J
REVERSE SIGNAL (CAN) [Off/On]	Indicates condition of transmission range switch R (Reverse) position.	
ST&ST CONT RELAY STATUS [Off/ST R On]	Indicates condition of starter cut and starter relays.	K
STARTER MOTOR STATUS [Off/On]	Indicates condition of starter motor.	
STARTER RELAY (CAN) [LOW/HIGH]	Indicates condition of starter relay.	EXL
IPDM NOT SLEEP [NO RDY/RDY]	Indicates condition of IPDM E/R sleep status.	
AFTER COOLING TIME [No request/Request]	Indicates condition of cooling fan request.	
AFTER COOLING SPEED [%]	Indicates condition of cooling fans.	M
COOLING FAN TYPE [NISSAN/RENAULT]	Indicates cooling fan type.	
COMPRESSOR REQ1 [Off/On]	Indicates condition of A/C compressor request.	
VHCL SECURITY HORN REQ [Off/On]	Indicates condition of horn relay request.	N
DTRL REQ [Off/On]	Indicates condition of daytime running light request.	
SLEEP/WAKE UP [WAKEUP/SLEEP]	Indicates condition of IPDM E/R sleep/wake.	O
CRANKING ENABLE-TCM [NG/OK]	Indicates condition of crank enable from TCM.	
CRANKING ENABLE-ECM [NG/OK]	Indicates condition of crank enable from ECM.	
CAN DIAGNOSIS [NG/OK]	Indicates condition of CAN diagnosis.	P
FRONT FOG LAMP REQ [Off/On]	Indicates condition of front fog lamp request.	
HIGH BEAM REQ [Off/On]	Indicates condition of headlamp high beam request.	
HORN CHIRP [Off/On]	Indicates condition of horn relay request.	
COOLING FAN REQ [%]	Indicates condition of cooling fan request.	
ENGINE STATUS [STOP/RUN/IDLING]	Indicates condition of engine status.	

# DIAGNOSIS SYSTEM (IPDM E/R)

[HALOGEN HEADLAMP]

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
TURN SIGNAL REQ [Off/LH/RH]	Indicates condition of turn signal request.
FR WIPER REQ [RETURN/LOW/HIGH]	Indicates condition of front wiper motor request.
SHIFT POSITION [P/R/N/D/L]	Indicates condition of transmission range switch positions.
LOW BEAM REQ [Off/On]	Indicates condition of headlamp low beam request.
POSITION LIGHT REQ [Off/On]	Indicates condition of parking lamp request.
COMPRESSOR REQ2 [Off/On]	Indicates condition of A/C compressor request.
IGNITION SW [Off/On]	Indicates condition of ignition switch.
VEHICLE SPEED (METER) [mph/km/h]	Indicates vehicle speed.
BAT DISCHARGE COUNT [0-100]	Indicates condition of battery discharge.
BATTERY STATUS [NG/OK]	Indicates battery status.

## ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [Off/On].
FRONT WIPER	This test is able to check wiper motor operation [Off/Low/High].
COMPRESSOR	This test is able to check A/C compressor operation [Off/On].
COOLING FAN (DUAL)	This test is able to check cooling fan operation [Off/LO/HI].
HEADLAMP (HI)	This test is able to check headlamp high beam operation [Off/3/5].
HEADLAMP (LO)	This test is able to check headlamp low beam operation [Off/3/5].
FRONT FOG LAMP	This test is able to check front fog lamp operation [Off/3/5].
DAYTIME RUNNING LAMP	This test is able to check daytime running lamp operation [Off/3/5].
PARKING LAMP	This test is able to check parking lamp operation [Off/3/5].
TAIL LAMP	This test is able to check tail lamp operation [Off/3/5].

## CAN DIAG SUPPORT MNTR

Refer to [LAN-14, "CAN Diagnostic Support Monitor"](#).

# ECU DIAGNOSIS INFORMATION

## BCM, IPDM E/R

### List of ECU Reference

INFOID:000000010286972

ECU	Reference
BCM	<a href="#">BCS-28. "Reference Value"</a> (with Intelligent Key) <a href="#">BCS-96. "Reference Value"</a> (without Intelligent Key)
	<a href="#">BCS-47. "Fail Safe"</a> (with Intelligent Key) <a href="#">BCS-107. "Fail Safe"</a> (without Intelligent Key)
	<a href="#">BCS-47. "DTC Inspection Priority Chart"</a> (with Intelligent Key) <a href="#">BCS-107. "DTC Inspection Priority Chart"</a> (without Intelligent Key)
	<a href="#">BCS-48. "DTC Index"</a> (with Intelligent Key) <a href="#">BCS-108. "DTC Index"</a> (without Intelligent Key)
IPDM E/R	<a href="#">PCS-12. "Reference Value".</a>
	<a href="#">PCS-19. "Fail-safe"</a>
	<a href="#">PCS-20. "DTC Index"</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HEADLAMP

[HALOGEN HEADLAMP]


< WIRING DIAGRAM >

## WIRING DIAGRAM

### HEADLAMP

#### Wiring Diagram

INFOID:000000010288622



AALWA0768GB


# HEADLAMP

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]


## HEAD LAMP - HALOGEN CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
33	LG	ICSW 5
34	Y	OCSW 5
36	G	ICSW 3
37	GR	ICSW 4
38	V	ICSW 1
39	W	ICSW 2

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
84	BR	OCSW 2
85	SB	OCSW 1
86	P	OCSW 3
87	BG	OCSW 4
95	V	I SHORTING PIN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-

Terminal No.	Color of Wire	Signal Name
4	BG	-
5	G	-
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-


A B C D E F G H I J K EXL M N O P

# HEADLAMP

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
5	L	-
11	P	-
12	P	-
15	P	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8P	LA/BR	-
13P	LA/G	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

# HEADLAMP

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	E40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	-
3	B	-

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L
45	LA/G	BAT
46	LA/BR	IGN
52	B	GND2

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	GND1

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
12	B	SIGNAL GROUND

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	L	-
6	P	-
9	L	-
10	P	-

AALIA2134GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL


# HEADLAMP

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED



Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Connector No.	E201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
59	G	O LIGHT HBEAM LH
62	SB	O LIGHT LBEAM RH

Terminal No.	Color of Wire	Signal Name
50	L	O LIGHT LBEAM LH
54	LG	O LIGHT HBEAM RH

Terminal No.	Color of Wire	Signal Name
2	B	-
3	B	-

AALIA2135GB



# HEADLAMP

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	E235
Connector Name	FRONT COMBINATION LAMP LH (WITH HALOGEN HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
4	L	-
5	B	-

Connector No.	E234
Connector Name	FRONT COMBINATION LAMP RH (WITH HALOGEN HEADLAMPS)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
14	B	-
15	LG	-

Connector No.	E233
Connector Name	FRONT COMBINATION LAMP RH (WITH HALOGEN HEADLAMPS)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
4	SB	-
5	B	-

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

Connector No.	E236
Connector Name	FRONT COMBINATION LAMP LH (WITH HALOGEN HEADLAMPS)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
14	B	-
15	G	-

AALIA2136GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HEADLAMP

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

AALIA2137GB

# DAYTIME LIGHT SYSTEM


< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

## DAYTIME LIGHT SYSTEM

### Wiring Diagram

INFOID:000000010288623




AALWA0771GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


DAYTIME LIGHT SYSTEM CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
33	LG	I CSW 5
34	Y	O CSW 5
36	G	I CSW 3
37	GR	I CSW 4
38	V	I CSW 1
39	W	I CSW 2

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
84	BR	O CSW 2
85	SB	O CSW 1
86	P	O CSW 3
87	BG	O CSW 4
95	V	I SHORTING PIN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-
4	BG	-


Terminal No.	Color of Wire	Signal Name
5	G	-
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-

# DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
27J	G	-
61J	L	-
62J	P	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
5	L	-
11	P	-
12	P	-
15	P	-

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	LA/BR	-
13P	LA/G	-

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND1
26	G	PBK SW

AALIA2122GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	E40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	-
3	B	-

Connector No.	E16
Connector Name	ECM
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
99	P	CAN-L
100	L	CAN-H

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L
45	LA/G	BAT
46	LA/BR	IGN
52	B	GND2

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Connector No.	E52
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
12	B	SIGNAL GROUND

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-
5	L	-
6	P	-
9	L	-
10	P	-

AALIA2123GB

# DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED



Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND


Connector No.	E201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
3	B	-

Terminal No.	Color of Wire	Signal Name
27J	G	-
61J	L	-
62J	P	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



AALIA2124GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	E234
Connector Name	FRONT COMBINATION LAMP RH (WITH HALOGEN HEADLAMPS)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
10	R	-
11	GR	-

Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
58	R	O LIGHT DTRL RH

Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
49	R	O LIGHT DTRL LH

Connector No.	E240
Connector Name	FRONT COMBINATION LAMP RH (WITH LED HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
8	R	-
11	B	-

Connector No.	E239
Connector Name	FRONT COMBINATION LAMP LH (WITH LED HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
8	R	-
11	B	-

Connector No.	E236
Connector Name	FRONT COMBINATION LAMP LH (WITH HALOGEN HEADLAMPS)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
10	R	-
11	GR	-

AALIA2125GB




# DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

AALIA2126GB

# AUTO LIGHT SYSTEM


< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

## AUTO LIGHT SYSTEM

### Wiring Diagram


INFOID:000000010288624



AALWA0767GB

## AUTO LIGHT SYSTEM CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M13
Connector Name	OPTICAL SENSOR
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	LG	-
3	V	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
12	W	O PWR AUTOLIGHT SENSOR
19	LG	I AUTOLIGHT SENSOR
30	V	O GND AUTOLIGHT SENSOR
33	LG	I CSW 5
34	Y	O CSW 5
36	G	I CSW 3
37	GR	I CSW 4
38	V	I CSW 1
39	W	I CSW 2

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
84	BR	O CSW 2
85	SB	O CSW 1
86	P	O CSW 3
87	BG	O CSW 4
95	V	I SHORTING PIN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2

AALIA2112GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-
4	BG	-
5	G	-
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
11	P	-
12	P	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	L	-
6	P	-
9	L	-
10	P	-

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED




Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
4	Y	O LIGHT POSITION REAR LH
12	B	SIGNAL GROUND
17	W	O LIGHT POSITION REAR RH

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	B16	
Connector Name	BCM (BODY CONTROL MODULE)	
Connector Color	GREEN	

Terminal No.	Color of Wire	Signal Name
50	W	I RR DOOR SW
51	LG	I TGATE SW
52	R	I RL DOOR SW
53	SB	I AS DOOR2 SW
57	SB	I DR DOOR2 SW
60	L	CAN-H
80	P	CAN-L

Connector No.	E218	
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	
Connector Color	WHITE	

Terminal No.	Color of Wire	Signal Name
57	W	O LIGHT FR FOG LAMPS RH
58	R	O LIGHT DTRL RH
59	G	O LIGHT HBEAM LH
61	GR	O LIGHT CLEARANCE FR RH
62	SB	O LIGHT LBEAM RH

Connector No.	E217	
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)	
Connector Color	BROWN	

Terminal No.	Color of Wire	Signal Name
49	R	O LIGHT DTRL LH
50	L	O LIGHT LBEAM LH
51	V	O LIGHT FR FOG LAMPS LH
54	LG	O LIGHT HBEAM RH
56	BG	O LIGHT CLEARANCE FR LH

Connector No.	B49	
Connector Name	WIRE TO WIRE	
Connector Color	WHITE	

Terminal No.	Color of Wire	Signal Name
6	SB	-
10	W	-

Connector No.	B46	
Connector Name	WIRE TO WIRE	
Connector Color	WHITE	

Terminal No.	Color of Wire	Signal Name
19	LG	-

Connector No.	B41	
Connector Name	WIRE TO WIRE	
Connector Color	WHITE	

Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-


AALIA2115GB

# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	B70
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	B54
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	B141
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	GR	-

Connector No.	B140
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	GR	-
10	W	-

Connector No.	B71
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	SB	-

AALIA2116GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
19	W	-

Connector No.	B142
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	W	-

Connector No.	D512
Connector Name	BACK DOOR LOCK ASSEMBLY (WITH POWER BACK DOOR SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	W	-
8	B	-

Connector No.	D508
Connector Name	BACK DOOR LOCK ASSEMBLY (WITHOUT POWER BACK DOOR SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	W	-
4	GR	-

AALIA2117GB



# FRONT FOG LAMP SYSTEM


[HALOGEN HEADLAMP]

< WIRING DIAGRAM >

## FRONT FOG LAMP SYSTEM

### Wiring Diagram

INFOID:000000010288625



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]


## FOG LAMP CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
33	LG	I CSW 5
34	Y	O CSW 5
36	G	I CSW 3
37	GR	I CSW 4
38	V	I CSW 1
39	W	I CSW 2

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
84	BR	O CSW 2
85	SB	O CSW 1
86	P	O CSW 3
87	BG	O CSW 4
95	V	I SHORTING PIN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-
4	BG	-
5	G	-


Terminal No.	Color of Wire	Signal Name
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-

# FRONT FOG LAMP SYSTEM

[HALOGEN HEADLAMP]

< WIRING DIAGRAM >


Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
5	L	-
11	P	-
12	P	-
15	P	-

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	LA/BR	-
13P	LA/G	-

AALIA2128GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	E40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	-

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L
45	LA/G	BAT
46	LA/BR	IGN
52	B	GND2

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	GND1


Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND

Terminal No.	Color of Wire	Signal Name
12	B	SIGNAL GROUND

Terminal No.	Color of Wire	Signal Name
5	L	-
6	P	-
9	L	-
10	P	-

AALIA2129GB


# FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED



Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Connector No.	E201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
57	W	O LIGHT FR FOG LAMPS RH

Terminal No.	Color of Wire	Signal Name
51	V	O LIGHT FR FOG LAMPS LH

Terminal No.	Color of Wire	Signal Name
2	B	-

AALIA2130GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	E221
Connector Name	FRONT FOG LAMP RH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W	-
2	GR	-

Connector No.	E222
Connector Name	FRONT FOG LAMP LH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	V	-
2	GR	-

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM


< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

### Wiring Diagram

INFOID:000000010288626



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL


# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

[HALOGEN HEADLAMP]

< WIRING DIAGRAM >


## TURN SIGNAL AND HAZARD WARNING LAMPS CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	LA/G	O D I FR LEFT D
3	LA/Y	O D I FR RIGHT D
11	Y	I HAZARD SW D
33	LG	I CSW 5
34	Y	O CSW 5
36	G	I CSW 3
37	GR	I CSW 4
38	V	I CSW 1
39	W	I CSW 2

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
84	BR	O CSW 2
85	SB	O CSW 1
86	P	O CSW 3
87	BG	O CSW 4
95	V	I SHORTING PIN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
168	BG	I PWR FLASHERS
170	B	I GND1
171	B	I GND2

Connector No.	M26
Connector Name	HAZARD SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	Y	-
3	GR	-

AALIA2162GB




# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
2	L	-
5	L	-
12	P	-
15	P	-

Connector No.	M33
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6N	BG	-

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-
4	BG	-
5	G	-
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M65
Connector Name	JOINT CONNECTOR-M26
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
4	B	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	LA/BR	-
13P	LA/G	-

AALIA2163GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L
45	LA/G	BAT
46	LA/BR	IGN
52	B	GND2

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	GND1

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M158
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	LAY	-

Connector No.	M78
Connector Name	JOINT CONNECTOR-M28
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
7	GR	-


AALIA2164GB

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	E29
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
135	BR	DI FR LEFT E
136	GR	O DI FR RIGHT E

Connector No.	M170
Connector Name	JOINT CONNECTOR-M29
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
4	B	-

Connector No.	M168
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
22	LA/G	-

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

Connector No.	E105
Connector Name	FRONT COMBINATION LAMP LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	B	-

Connector No.	E103
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	BR	-

AALIA2165GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	B49
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	P	-

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	B23
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
157	GR	O DI RR LEFT B
160	P	O DI RR RIGHT B

Connector No.	B102
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	LA/V	-
4	B	-

Connector No.	B90
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-


AALIA2166GB

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	D14
Connector Name	DOOR MIRROR LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	LA/G	-
14	LA/B	-

Connector No.	D3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	LA/B	-
22	LA/G	-

Connector No.	B140
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
11	LAV	-

Connector No.	D107
Connector Name	DOOR MIRROR RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	LA/G	-
14	LA/B	-

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LA/B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	LA/G	-

AALIA2239GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

## PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

Wiring Diagram

INFOID:000000010288627




AALWA0786GB

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

(HK) : WITH HALOGEN HEADLAMPS  
 (LV) : WITH LED HEADLAMPS  
 (HK) : 12 \*2  
 (LV) : 9 \*1  
 (LV) : 9 \*2  
 (LV) : 10



AALWA0787GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]


## PARKING, LICENSE AND TAIL LAMPS CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
33	LG	ICSW 5
34	Y	OCSW 5
36	G	ICSW 3
37	GR	ICSW 4
38	V	ICSW 1
39	W	ICSW 2

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2


Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
84	BR	OCSW 2
85	SB	OCSW 1
86	P	OCSW 3
87	BG	OCSW 4
95	V	I SHORTING PIN

Terminal No.	Color of Wire	Signal Name
5	G	-
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-
4	BG	-




# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]


Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
5	L	-
11	P	-
12	P	-
15	P	-

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	LA/BR	-
13P	LA/G	-

AALIA2150GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6M	Y	-

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L
45	LA/G	BAT
46	LA/BR	IGN
52	B	GND2

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND1


Connector No.	E40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
3	B	-

Terminal No.	99A	Color of Wire	W	Signal Name	-
--------------	-----	---------------	---	-------------	---

Connector No.	E34
Connector Name	WIRE TO WIRE
Connector Color	GRAY




AALIA2151GB

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	Y	O LIGHT POSITION REAR LH
12	B	SIGNAL GROUND
17	W	O LIGHT POSITION REAR RH

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	L	-
6	P	-
9	L	-
10	P	-

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED



Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

AALIA2152GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]


Connector No.	E201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
3	B	-

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E233
Connector Name	FRONT COMBINATION LAMP RH (WITH HALOGEN HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
8	B	-
9	W	-

Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
61	GR	O LIGHT CLEARANCE FR RH

Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
56	BG	O LIGHT CLEARANCE FRLH

AALIA2153GB

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	E236
Connector Name	FRONT COMBINATION LAMP LH (WITH HALOGEN HEADLAMPS)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
11	GR	-
12	BG	-

Connector No.	E235
Connector Name	FRONT COMBINATION LAMP LH (WITH HALOGEN HEADLAMPS)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
8	B	-
9	P	-

Connector No.	E234
Connector Name	FRONT COMBINATION LAMP RH (WITH HALOGEN HEADLAMPS)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
11	GR	-
12	GR	-

Connector No.	B2
Connector Name	JOINT CONNECTOR-B27
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LA/R	-
2	LA/R	-
3	LA/R	-
4	LA/R	-

Connector No.	E240
Connector Name	FRONT COMBINATION LAMP RH (WITH LED HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
9	GR	-
10	W	-
11	B	-

Connector No.	E239
Connector Name	FRONT COMBINATION LAMP LH (WITH LED HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
9	BG	-
10	P	-
11	B	-

AALIA2154GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	B29
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1T	LA/R	-

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

Connector No.	B3
Connector Name	JOINT CONNECTOR-B03
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LA/BR	-
2	LA/BR	-
3	LA/BR	-


Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Terminal No.	99A	Color of Wire	LA/BR	Signal Name	-
--------------	-----	---------------	-------	-------------	---

Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



AALIA2155GB

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	B54
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	B49
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	LA/BR	-

Connector No.	B46
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	LA/BR	-
22	LA/R	-
23	LA/R	-

Connector No.	B102
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LA/BR	-
4	B	-

Connector No.	B90
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LA/R	-
4	B	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

AALIA2156GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

Connector No.	B140
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	LA/BR	-

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	LA/R	-
22	LA/Y	-
23	P	-

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	D516
Connector Name	LICENSE PLATE LAMP LH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	-
2	P	-

Connector No.	D517
Connector Name	LICENSE PLATE LAMP RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-

Connector No.	D518
Connector Name	BACK-UP LAMP ASSEMBLY LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
3	LA/Y	-




# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

Connector No.	D519
Connector Name	BACK-UP LAMP ASSEMBLY RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
3	LA/R	-

AALIA2173GB

# STOP LAMP

< WIRING DIAGRAM >


[HALOGEN HEADLAMP]

## STOP LAMP

Wiring Diagram

INFOID:000000010288628

STOP LAMP



AALWA0765GB

# STOP LAMP

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

## STOP LAMP CONNECTORS

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
169	GR	I PWR STOP LAMP
170	B	I GND1
171	B	I GND2

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
10R	GR	-

Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5M	V	-

Connector No.	E29
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
125	LG	I BRAKE SW2

Connector No.	E38
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	LG	-

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE









Terminal No.	Color of Wire	Signal Name
23	LG	-
27	LG	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# STOP LAMP

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]




AALIA2159GB

# STOP LAMP

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]

Connector No.	B140
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	8	Color of Wire	LAY	Signal Name	-
--------------	---	---------------	-----	-------------	---

Connector No.	B102
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE



Terminal No.	2	Color of Wire	LAY	Signal Name	-
4	B	B	B	-	-

Connector No.	B90
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



Terminal No.	2	Color of Wire	LAY	Signal Name	-
4	B	B	B	-	-

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	1	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	D503
Connector Name	HIGH-MOUNTED STOP LAMP
Connector Color	WHITE



Terminal No.	1	Color of Wire	Y	Signal Name	-
2	B	B	B	-	-

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	17	Color of Wire	Y	Signal Name	-
--------------	----	---------------	---	-------------	---

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BACK-UP LAMP

[HALOGEN HEADLAMP]


< WIRING DIAGRAM >

## BACK-UP LAMP

Wiring Diagram

INFOID:000000010288629

BACK - UP LAMP



AALWA0763GB


# BACK-UP LAMP

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]


## BACK-UP LAMP CONNECTORS

Connector No.	E34
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
100A	G	-

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
16	G	O LIGHT REVERSE LAMP

Connector No.	F35
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
71	SB	O IGN REVERSE SW AC VALVE
79	G	LI LIGHT REVERSE SW

Connector No.	F78
Connector Name	TRANSMISSION RANGE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
4	W	-
8	G	-

AALIA2118GB








A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# BACK-UP LAMP

< WIRING DIAGRAM >

[HALOGEN HEADLAMP]



AALIA2119GB





# BACK-UP LAMP

< WIRING DIAGRAM >



[HALOGEN HEADLAMP]

Connector No.	D519
Connector Name	BACK-UP LAMP ASSEMBLY RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	LA/L	-

Connector No.	D518
Connector Name	BACK-UP LAMP ASSEMBLY LH
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	GR	-
2	LA/G	-

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

AALIA2120GB

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[HALOGEN HEADLAMP]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000010286974

OVERALL SEQUENCE



JMKIA8652GB

DETAILED FLOW

Revision: November 2013

EXL-82

2014 Rogue NAM

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[HALOGEN HEADLAMP]

## 1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

## 2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

### Are any symptoms described and any DTC detected?

- Symptom is described, DTC is detected>>GO TO 3.
- Symptom is described, DTC is not detected>>GO TO 4.
- Symptom is not described, DTC is detected>>GO TO 5.

## 3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.  
Also study the normal operation and fail-safe related to the symptom.  
Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

## 4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.  
Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

## 5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to [BCS-47. "DTC Inspection Priority Chart"](#) (BCM) (with Intelligent Key System) or [BCS-107. "DTC Inspection Priority Chart"](#) (BCM) (without Intelligent Key System) or [PCS-12. "Reference Value"](#) (IPDM E/R), and determine trouble diagnosis order.

### **NOTE:**

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.  
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

### Is DTC detected?

- YES >> GO TO 7.
- NO >> Check according to [GI-41. "Intermittent Incident"](#).

## 6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

### Is the symptom described?

- YES >> GO TO 7.
- NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[HALOGEN HEADLAMP]

---

### 7. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

---

Inspect according to Diagnostic Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-41, "Intermittent Incident"](#).

### 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

---

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

### 9. FINAL CHECK

---

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[HALOGEN HEADLAMP]

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000010376487

#### **CAUTION:**

- When the IPDM E/R is replaced or disconnected and reconnected, perform “SENSOR INITIALIZE” with CONSULT.

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000010376488

### 1. SENSOR INITIALIZE

#### CONSULT WORK SUPPORT

Perform “SENSOR INITIALIZE”. Refer to [EXL-85, "SENSOR INITIALIZE : Special Repair Requirement"](#).

>> WORK END

### SENSOR INITIALIZE

#### SENSOR INITIALIZE : Description

INFOID:000000010376489

#### HEADLAMP AIMING CONTROL SYSTEM

Perform the sensor initialize when installing, removing and replacing the auto levelizer control unit or suspension components.

#### SENSOR INITIALIZE : Special Repair Requirement

INFOID:000000010376490

#### **CAUTION:**

If performing aiming adjustment after the levelizer initialization, be sure to start the engine after turning ignition switch OFF.

### 1. VEHICLE CONDITION CHECK

1. Park the vehicle in the straight-forward position.
2. Unload the vehicle (no passenger aboard).

>> GO TO 2.

### 2. SENSOR INITIALIZE

#### CONSULT WORK SUPPORT

1. Select “SENSOR INITIALIZE” of IPDM E/R work support item.
2. Select “START”.
3. When “INITIALIZE COMPLETE”, select “END”.

#### **CAUTION:**

If “INITIALIZE NOT DONE” is indicated, auto levelizer control unit detects that the sensor lever signal was changing. The sensor initialization is cancelled. In this case, turn the ignition switch OFF, do not allow the vehicle height to change. Perform the sensor initialization again.

Is the sensor initialize completed?

- YES >> GO TO 3.  
NO >> Perform the sensor initialize again.

### 3. SELF-DIAGNOSIS RESULT CHECK

Perform the self-diagnosis with CONSULT. Check that any DTC is not detected.

Is any DTC detected?

- YES >> GO TO 2.  
NO >> Sensor initialize completed.

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## DTC/CIRCUIT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT

#### BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM)

#### BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM) : Diagnosis Procedure

INFOID:000000010290265

Regarding Wiring Diagram information, refer to [BCS-50, "Wiring Diagram"](#).

### 1. CHECK FUSE

Check that the following fuse is not blown.

Terminal No.	Signal name	Fuse No.
161	BCM power supply	7 (10A)

#### Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.  
NO >> GO TO 2.

### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M20.
2. Check voltage between BCM connector M20 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M20	161	—	Battery voltage

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness or connectors.

### 3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M20 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	170	—	Yes
	171		

#### Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

#### BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM)

#### BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM) : Diagnosis Procedure

INFOID:000000010290266

Regarding Wiring Diagram information, refer to [BCS-110, "Wiring Diagram"](#).

### 1. CHECK FUSE

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

Check that the following fuse is not blown.

Terminal No.	Signal name	Fuse No.
161	BCM power supply	7 (10A)

Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.  
NO >> GO TO 2.

## 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M20.
2. Check voltage between BCM connector M20 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M20	161	—	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness or connectors.

## 3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M20 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	170	—	Yes
	171		

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

## OPTICAL SENSOR

### Component Function Check

INFOID:000000010286996

#### 1. CHECK OPTICAL SENSOR SIGNAL BY CONSULT

##### CONSULT DATA MONITOR

1. Turn power switch ON.
2. Select "OPTICAL SENSOR" of BCM (HEADLAMP) data monitor item.
3. Turn lighting switch AUTO.
4. With the optical sensor illuminating, check the monitor status.

Monitor item	Condition	Voltage (Approx.)
OPTICAL SENSOR	Optical sensor	
	When illuminating	3.1 V or more *
	When shutting off light	0.6 V or less

\*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

##### Is the inspection result normal?

- YES >> Optical sensor is normal.  
 NO >> Refer to [EXL-88, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010286997

#### 1. CHECK OPTICAL SENSOR POWER SUPPLY INPUT

1. Turn power switch ON.
2. Turn lighting switch AUTO.
3. Check voltage between optical sensor harness connector and ground.

(+)		(-)	Voltage (Approx.)
Optical sensor			
Connector	Terminal		
M13	1	Ground	5 V

##### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> GO TO 4.

#### 2. CHECK OPTICAL SENSOR GROUND INPUT

Check voltage between optical sensor harness connector and ground.

(+)		(-)	Voltage (Approx.)
Optical sensor			
Connector	Terminal		
M13	3	Ground	0 V

##### Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 6.

#### 3. CHECK OPTICAL SENSOR SIGNAL OUTPUT

With illuminating the optical sensor, check voltage between optical sensor harness connector and ground.



# OPTICAL SENSOR

[HALOGEN HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Condition	Voltage (Approx.)	
Optical sensor					
Connector	Terminal				
M13	2	Ground	Optical sensor	When illuminating	3.1 V or more *
				When shutting off light	0.6 V or less

\*: Illuminate the optical sensor. The value may be less than the standard if brightness is weak.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace the optical sensor.

## 4.CHECK OPTICAL SENSOR OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M13	1	M18	12	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 5.CHECK OPTICAL SENSOR SHORT CIRCUIT

Check continuity between optical sensor harness connector and ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M13	1		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key system) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key system).

NO >> Repair or replace harness.

## 6.CHECK OPTICAL SENSOR GROUND OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M13	3	M18	30	Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key system) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key system).

NO >> Repair or replace harness.

## 7.CHECK OPTICAL SENSOR SIGNAL OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

# OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M13	2	M18	19	Yes

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

## 8. CHECK OPTICAL SENSOR SHORT CIRCUIT

Check continuity between optical sensor harness connector and ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M13	2		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-75. "Removal and Installation"](#) (with Intelligent Key system) or [BCS-135. "Removal and Installation"](#) (without Intelligent Key system).

NO >> Repair or replace harness.

# HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## HAZARD SWITCH

### Component Function Check

INFOID:000000010286998

#### 1.CHECK HAZARD SWITCH SIGNAL BY CONSULT

##### CONSULT DATA MONITOR

1. Turn power switch ON.
2. Select "HAZARD SW" of BCM (FLASHER) data monitor item.
3. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the inspection result normal?

- YES >> Hazard switch circuit is normal.  
 NO >> Refer to [EXL-91, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010286999

#### 1.CHECK HAZARD SWITCH SIGNAL INPUT

1. Turn power switch OFF.
2. Disconnect hazard switch connector.
3. Check voltage between hazard switch connector and ground.

(+)		(-)	Voltage (Approx.)
Hazard switch			
Connector	Terminal	Ground	Battery voltage
M26	2		

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> GO TO 2.

#### 2.CHECK HAZARD SWITCH SIGNAL OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between hazard switch harness connector and BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M26	2	M18	11	Yes

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

#### 3.CHECK HAZARD SWITCH SIGNAL SHORT CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M26	2		No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key).  
 NO >> Repair or replace harness.

# HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## 4. CHECK HAZARD SWITCH GROUND OPEN CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		Yes
M26	3		

Is the inspection result normal?

- YES >> Replace hazard switch. Refer to [EXL-125, "Removal and Installation"](#).
- NO >> Repair or replace harness.

# TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## TURN SIGNAL LAMP CIRCUIT

### Description

INFOID:000000010330247

The BCM monitors inputs from the combination switch (lighting and turn signal switch) to determine when to activate the turn signals. The BCM outputs voltage direction to the left and right turn signals during turn signal operation or both during hazard warning operation. The BCM sends a turn signal indicator request to the combination meter via the CAN communication lines.

The BCM performs the fast flasher operation (fail-safe) if any bulb or harness of the turn signal lamp circuit is open.

#### NOTE:

Turn signal lamp blinks at normal speed when using the hazard warning lamp.

### Component Function Check

INFOID:000000010330248

#### 1.CHECK TURN SIGNAL LAMP

##### CONSULT

1. Select FLASHER of BCM (FLASHER) active test item.
2. While operating the test items, check that the turn signal lamp blinks.

**LH : Turn signal lamps (LH) ON**

**RH : Turn signal lamps (RH) ON**

**Off : Turn signal lamps OFF**

Is the inspection result normal?

YES >> Turn signal lamp circuit is normal.

NO >> Refer to [EXL-93, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010330249

Regarding Wiring Diagram information, refer to [EXL-185, "Wiring Diagram"](#).

#### 1.CHECK TURN SIGNAL LAMP BULB

Check the applicable lamp bulb to be sure the proper bulb standard is in use and the bulb is not open.

Is the bulb OK?

YES >> GO TO 2.

NO >> Replace the bulb.

#### 2.CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE


1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp harness connector or the side turn signal harness connector or the rear combination lamp harness connector in question.
3. Turn the ignition switch ON.
4. Operate the turn signal switch.
5. While the turn signal is operating, check the voltage between the front combination lamp harness connector and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		


# TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

LH	E105	1	Ground	 <p style="text-align: right; font-size: small;">PKID0926E</p>
RH	E103			

6. While the turn signal is operating, check the voltage between the rear combination lamp harness connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Connector				
LH	B90	3	Ground	 <p style="text-align: right; font-size: small;">PKID0926E</p>
RH	B102			

Are the inspection results normal?

YES >> GO TO 5.

NO >> GO TO 3.

### 3. CHECK TURN SIGNAL LAMP CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector E29 or B23.
3. Check continuity between the BCM harness connector E29 and the front combination lamp harness connector.

BCM			Front combination lamp		Continuity
Connector	Terminal	Connector	Terminal		
LH	E29	135	E105	1	Yes
RH		136	E103		

4. Check continuity between the BCM harness connector B23 and the rear combination lamp harness connector.

BCM			Rear combination lamp		Continuity
Connector	Terminal	Connector	Terminal		
LH	B23	157	B90	3	Yes
RH		160	B102		

Are the inspection results normal?

YES >> GO TO 4.

NO >> Repair or replace the harness or connectors.

### 4. CHECK TURN SIGNAL LAMP SHORT CIRCUIT

1. Check continuity between the BCM harness connector E29 and ground.

# TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

BCM			Ground	Continuity
Connector		Terminal		No
LH	E29	135		
RH		136		

2. Check continuity between the BCM harness connector M20 and ground.

BCM			Ground	Continuity
Connector		Terminal		No
LH	B23	157		
RH		160		

Are the inspection results normal?

YES >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key).

NO >> Repair or replace the harness or connectors.

## 5. CHECK TURN SIGNAL LAMP GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check continuity between the front combination lamp harness connector or the side turn signal harness connector or the rear combination lamp harness connector in question and ground.

Front combination lamp			(-)	Continuity
Connector		Terminal		
LH	E105	2	Ground	Yes
RH	E103			

3. Check continuity between the rear combination lamp harness connector and ground.

Rear combination lamp			(-)	Continuity
Connector		Terminal		
LH	B90	4	Ground	Yes
RH	B102			

Are the inspection results normal?

YES >> Replace the malfunctioning lamp.

NO >> Repair or replace the harness or connectors.

# B121A FRONT FOG LAMP LH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## B121A FRONT FOG LAMP LH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010321286

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B121A	FR FOG LAMP LH PWR SPLY CIRC [CIRC SHORT TO GROUND]	• Short to ground	• IPDM E/R • Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

#### Is DTC B121A detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-96, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010321287

#### 1. CHECK FOG LAMP SHORT CIRCUIT TO GROUND

1. Disconnect fog lamp connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
LH	E217		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness.

#### 2. CHECK FOG LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.
2. Check continuity between fog lamp harness connector and ground.

Fog lamp (LH)		Ground	Continuity
Connector	Terminal		
LH	E222		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).



# B1231 DAYTIME RUNNING LIGHT RH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## B1231 DAYTIME RUNNING LIGHT RH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010287232

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B1231	DTRL RH PWR SPLY CIRC [CIRC SHORT TO GRND]	When a short circuit to ground in the daytime running lamp circuit is detected.	<ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Short to ground</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch ON.

2. Perform self-diagnostic result.

#### Is DTC B1231 detected?

YES >> Proceed to diagnosis procedure. Refer to [EXL-97, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010375484

#### 1. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connector and IPDM E/R connector.

2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E218		No

#### Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

#### 2. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.

2. Check continuity between front combination lamp harness connector and ground.

Front combination lamp (RH)		Ground	Continuity
Connector	Terminal		
RH	E234		No

#### Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B1256 FRONT FOG LAMP RH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## B1256 FRONT FOG LAMP RH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010321292

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B1256	FR FOG LAMP RH PWR SPLY CIRC [CIRC SHORT TO GRND]	When a short circuit to ground is detected.	<ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Short to ground</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

- Turn ignition switch ON.
- Perform self-diagnostic result.

#### Is DTC B1256 detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-98, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010375499

#### 1. CHECK FOG LAMP SHORT CIRCUIT TO GROUND

- Disconnect fog lamp connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
LH	E217		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness.

#### 2. CHECK FOG LAMP SHORT CIRCUIT TO GROUND

- Reconnect IPDM E/R connector.
- Check continuity between fog lamp harness connector and ground.

Fog lamp (LH)		Ground	Continuity
Connector	Terminal		
LH	E222		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
 NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20CB DAYTIME RUNNING LIGHT LH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## B20CB DAYTIME RUNNING LIGHT LH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010296914

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B02CB	DTRL LH PWR SPLY CIRC [CIRC SHORT TO GRND]	When a short circuit to ground is detected.	<ul style="list-style-type: none"><li>• IPDM E/R</li><li>• Short to ground</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch ON.

2. Perform self-diagnostic result.

Is DTC B02CB detected?

YES >> Proceed to diagnosis procedure. Refer to [EXL-99. "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010375500

#### 1. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connector and IPDM E/R connector.

2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
LH	E217		No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

#### 2. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.

2. Check continuity between fog lamp harness connector and ground.

Front combination lamp (LH)		Ground	Continuity
Connector	Terminal		
LH	E236		No

Is the inspection result normal?

YES >> Refer to [GI-41. "Intermittent Incident"](#).

NO >> Replace IPDM E/R. Refer to [PCS-35. "Removal and Installation"](#).

# B20CE HEADLAMP (HI) LH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## B20CE HEADLAMP (HI) LH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010296917

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20CE	DTRL LH PWR SPLY CIRC [CIRC SHORT TO GRND]	• Short to ground	• IPDM E/R • Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

 With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

#### Is DTC B20CE detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-100, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010375501

#### 1. CHECK HEAD LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
LH	E218		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness.

#### 2. CHECK HEAD LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.
2. Check continuity between front combination lamp harness connector and ground.

Front combination lamp (LH)		Ground	Continuity
Connector	Terminal		
LH	E234		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20CF HEADLAMP (HI) RH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## B20CF HEADLAMP (HI) RH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010296918

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20CF	HL (HI) RH PWR SPLY CIRC [CIRC SHORT TO GRND]	• Short to ground	• IPDM E/R • Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch ON.

2. Perform self-diagnostic result.

Is DTC B20CF detected?

YES >> Proceed to diagnosis procedure. Refer to [EXL-101, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010375502

#### 1.CHECK HEAD LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connector and IPDM E/R connector.

2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R			Ground	Continuity
Connector	Terminal			
RH	E217	54		No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

#### 2.CHECK HEAD LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.

2. Check continuity between front combination lamp harness connector and ground.

Front combination lamp (RH)			Ground	Continuity
Connector	Terminal			
RH	E234	15		No

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20D0 HEADLAMP (LO) LH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## B20D0 HEADLAMP (LO) LH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010297886

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20D0	HI (LO) RH PWR SPLY CIRC [CIRC SHORT TO GRND]	• Short to ground	• IPDM E/R • Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

#### Is DTC B20D0 detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-102, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010375503

#### 1. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
LH	E217		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness.

#### 2. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.
2. Check continuity between front combination lamp harness connector and ground.

Front combination lamp (LH)		Ground	Continuity
Connector	Terminal		
LH	E233		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20D1 HEADLAMP (LO) RH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## B20D1 HEADLAMP (LO) RH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010297888

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20D1	HL (LO) RH PWR SPLY CIRC [CIRC SHORT TO GRND]	• Short to ground	• IPDM E/R • Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch ON.

2. Perform self-diagnostic result.

Is DTC B20D1 detected?

YES >> Proceed to diagnosis procedure. Refer to [EXL-103, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010375504

#### 1.CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connector and IPDM E/R connector.

2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R			Ground	Continuity
Connector		Terminal		
LH	E218	62		No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

#### 2.CHECK FOG LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.

2. Check continuity between fog lamp harness connector and ground.

Fog lamp (LH)			Ground	Continuity
Connector		Terminal		
LH	E233	4		No

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20D2 PARKING LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## B20D2 PARKING LAMP POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010297890

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20D2	PARKING LAMP PWR SPLY CIRC [CIRC SHORT TO GROUND]	When a short to ground is detected in the parking lamp power supply circuit.	• Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

Is DTC B20D2 detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-104, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010375505

#### 1. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connectors and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R			Ground	Continuity
Connector		Terminal		
LH		E217	No	
RH		E218		

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness.

#### 2. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.
2. Check continuity between front combination lamp harness connector and ground.

IPDM E/R			Ground	Continuity
Connector		Terminal		
LH		E217	No	
RH		E218		

Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).



# B20D4 TAIL LAMP LH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## B20D4 TAIL LAMP LH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010297892

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20D4	TAIL LAMP LH PWR SPLY CIRC [CIRC SHORT TO GRND]	• Short to ground	• IPDM E/R • Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

 With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

#### Is DTC B20D4 detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-105, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010375506

#### 1. CHECK TAIL LAMP SHORT CIRCUIT TO GROUND

1. Disconnect rear combination lamp (LH), license plate lamps, back up lamp connectors and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
LH	E119		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness.

#### 2. CHECK TAIL LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.
2. Check continuity between rear combination lamp harness connector and ground.

Rear combination lamp (LH)		Ground	Continuity
Connector	Terminal		
LH	B90		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
 NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# B20D5 TAIL LAMP RH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[HALOGEN HEADLAMP]

## B20D5 TAIL LAMP RH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010297894

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20D5	TAIL LAMP RH PWR SPLY CIRC [CIRC SHORT TO GRND]	When a short circuit to ground is detected in the tail lamp supply voltage circuit.	<ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Short to ground</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

#### Is DTC B20D5 detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-106, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010375507

#### 1. CHECK TAIL LAMP SHORT CIRCUIT TO GROUND

1. Disconnect rear combination lamp (RH), back up lamp connectors and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E119		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness.

#### 2. CHECK TAIL LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.
2. Check continuity between rear combination lamp harness connector and ground.

Rear combination lamp (RH)		Ground	Continuity
Connector	Terminal		
RH	B102		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
 NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

## SYMPTOM DIAGNOSIS

### EXTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:0000000010325965

**CAUTION:**

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp (HI) is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Halogen bulb (HI)</li> <li>• Harness between IPDM E/R and headlamp (HI)</li> <li>• Harness between headlamp (HI) and ground</li> <li>• IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-100, "DTC Logic"</a> (LH) or <a href="#">EXL-101, "DTC Logic"</a> (RH).
	Both sides	<p><b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to <a href="#">EXL-100, "DTC Logic"</a> (LH) or <a href="#">EXL-101, "DTC Logic"</a> (RH).</p>	
High beam indicator lamp is not turned ON. [Headlamp (HI) is turned ON.]		Combination meter	<ul style="list-style-type: none"> <li>• Combination meter Data monitor "HI-BEAM IND"</li> <li>• BCM (HEAD LAMP) Active test "HEADLAMP"</li> </ul>
Headlamp (LO) is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Halogen bulb (LO)</li> <li>• Harness between IPDM E/R and headlamp lamp (LO)</li> <li>• Harness between headlamp (LO) and ground</li> <li>• IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-102, "DTC Logic"</a> (LH) or <a href="#">EXL-103, "DTC Logic"</a> (RH).
	Both sides	<p><b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-102, "DTC Logic"</a> (LH) or <a href="#">EXL-103, "DTC Logic"</a> (RH).</p>	
Each lamp is not turned ON/OFF with lighting switch AUTO.		<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-73, "Symptom Table"</a> (with Intelligent Key) or <a href="#">BCS-133, "Symptom Table"</a> (without Intelligent Key).
		<ul style="list-style-type: none"> <li>• Optical sensor</li> <li>• Harness between optical sensor and BCM</li> <li>• BCM</li> </ul>	Optical sensor Refer to <a href="#">EXL-88, "Component Function Check"</a> .
Daytime running light is not turned ON. [Headlamp (HI) is turned ON.]		<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Harness between IPDM E/R and front combination lamp</li> <li>• IPDM E/R</li> <li>• BCM</li> <li>• ECM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Daytime running light circuit Refer to <a href="#">EXL-97, "DTC Logic"</a>.</li> <li>• BCM (HEADLAMP) Data monitor "ENGINE STATE"</li> <li>• Combination meter Data monitor "PKB SW"</li> <li>• BCM (HEADLAMP) Active test "DAYTIME RUNNING LIGHT"</li> </ul>
Parking lamp is not turned ON.		<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Parking lamp bulb</li> <li>• Harness between IPDM E/R and front combination lamp</li> <li>• IPDM E/R</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-104, "DTC Logic"</a> .

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

## EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

Symptom	Possible cause	Inspection item	
Front side marker lamp is not turned ON.	<ul style="list-style-type: none"> <li>• Front side marker lamp bulb</li> <li>• Harness between IPDM E/R and front side marker lamp</li> <li>• Harness between front side marker lamp and ground</li> <li>• IPDM E/R</li> </ul>	Front side marker lamp circuit Refer to <a href="#">EXL-104, "DTC Logic"</a> .	
License plate lamp is not turned ON.	<ul style="list-style-type: none"> <li>• License plate lamp bulb</li> <li>• Harness between IPDM E/R and license plate lamp</li> <li>• Harness between license plate lamp and ground</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-105, "DTC Logic"</a> .	
Parking lamp, side marker lamp, tail lamp and license plate lamp are not turned ON.	<b>Symptom diagnosis</b> "PARKING, SIDE MARKER, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-104, "DTC Logic"</a> .		
Tail lamp indicator is not turned ON. (Exterior lamps are turned ON.)	Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Data monitor "LIGHT IND"</li> <li>• BCM (HEADLAMP)</li> <li>• Active test "TAIL LAMP"</li> </ul>	
Turn signal lamp does not blink.	Indicator lamp is normal. (Applicable side performs high flasher activation.)	<ul style="list-style-type: none"> <li>• Turn signal lamp bulb</li> <li>• Door mirror</li> <li>• Harness between BCM and each turn signal lamp</li> <li>• Harness between each turn signal lamp and ground</li> </ul>	Turn signal lamp circuit Refer to <a href="#">EXL-93, "Component Function Check"</a> .
Turn signal indicator lamp does not blink. (Turn signal lamp is normal.)	One side	Combination meter	—
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn signal indicator lamp signal</li> <li>• BCM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Data monitor "TURN IND"</li> <li>• BCM (FLASHER)</li> <li>• Active test "FLASHER"</li> </ul>
	Both sides (Only when activating hazard warning lamp with ignition switch OFF)	<ul style="list-style-type: none"> <li>• Combination meter power supply and ground circuit</li> <li>• Combination meter</li> </ul>	Combination meter Power supply and ground circuit Refer to <a href="#">MWI-59, "COMBINATION METER : Diagnosis Procedure"</a> .
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate.</li> <li>• Hazard warning lamp continues activating. (Turn signal is normal.)</li> </ul>	<ul style="list-style-type: none"> <li>• Hazard switch</li> <li>• Harness between hazard switch and BCM</li> <li>• Harness between hazard switch and ground</li> <li>• BCM</li> </ul>	Hazard switch circuit Refer to <a href="#">EXL-91, "Component Function Check"</a> .	
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Front fog lamp bulb</li> <li>• Harness between IPDM E/R and front fog lamp</li> <li>• Harness between front fog lamp and ground</li> <li>• IPDM E/R</li> </ul>	Front fog lamp circuit Refer to <a href="#">EXL-96, "DTC Logic"</a> (LH) or <a href="#">EXL-98, "DTC Logic"</a> (RH).
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-96, "DTC Logic"</a> (LH) or <a href="#">EXL-98, "DTC Logic"</a> (RH).	

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000010325966

#### AUTO LIGHT SYSTEM

The headlamp may not be turned ON/OFF immediately after passing dark area or bright area (short tunnel, sky bridge, shadowed area, etc.) while using the auto light system. This is caused by for the control difference. This is normal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

## BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

### Description

INFOID:000000010325969

Both side headlamps (HI) are not turned ON when setting to the lighting switch HI or PASS.

### Diagnosis Procedure

INFOID:000000010325970

#### 1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-73, "Symptom Table"](#) (with Intelligent Key system) or [BCS-133, "Symptom Table"](#) (without Intelligent Key system).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

##### ④CONSULT DATA MONITOR

1. Select "HEADLAMP (HI)" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HEADLAMP (HI)	Lighting switch (2ND)	HI or PASS	On
		LO	Off

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key system) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key system).

#### 3.HEADLAMP (HI) CIRCUIT INSPECTION

Check headlamp (HI) circuit. Refer to [EXL-100, "DTC Logic"](#) (LH) or [EXL-101, "DTC Logic"](#) (RH).

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning part.

# BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

## BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

### Description

INFOID:000000010325971

Both side headlamps (LO) are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000010325972

#### 1. CHECK COMBINATION SWITCH

Check combination switch. Refer to [BCS-73, "Symptom Table"](#) ( with Intelligent Key) or [BCS-133, "Symptom Table"](#) ( without Intelligent Key).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2. CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

##### CONSULT DATA MONITOR

1. Select "HEADLAMP (LO)" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HEADLAMP (LO)	Lighting switch	2ND	On
		OFF	Off

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key).

#### 3. HEADLAMP (LO) CIRCUIT INSPECTION

Check headlamp (LO) circuit. Refer to [EXL-102, "DTC Logic"](#) (LH) or [EXL-103, "DTC Logic"](#) (RH).

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning part.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

## PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

### Description

INFOID:000000010325973

The parking, license plate, side marker, tail lamps and each illumination are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000010325974

#### 1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-73, "Symptom Table"](#) (with Intelligent Key) or [BCS-133, "Symptom Table"](#) (without Intelligent Key).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK TAIL LAMP REQUEST SIGNAL INPUT

##### CONSULT DATA MONITOR

1. Select "TAIL LAMP" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
TAIL LAMP	Lighting switch	1ST	On
		OFF	Off

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key).



# BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[HALOGEN HEADLAMP]

## BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

### Description

INFOID:000000010325975

The front fog lamps are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000010325976

#### 1. CHECK COMBINATION SWITCH

Check combination switch. Refer to [BCS-73, "Symptom Table"](#) (with Intelligent Key) or [BCS-133, "Symptom Table"](#) (without Intelligent Key).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning part.

#### 2. CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

##### CONSULT DATA MONITOR

1. Select "FRONT FOG LAMP REQ" of IPDM E/R data monitor item.
2. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition		Monitor status
FRONT FOG LAMP REQ	Front fog lamp switch (With lighting switch 2ND)	ON	On
		OFF	Off

Is the item status normal?

YES >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN HEADLAMP]

## PERIODIC MAINTENANCE

### HEADLAMP AIMING ADJUSTMENT

#### Inspection

INFOID:000000009795989

#### PREPARATION BEFORE ADJUSTING

Before performing aiming adjustment, check the following:

- Make sure all tires are inflated to correct pressure.
- Place vehicle and screen on level surface.
- Make sure there is no load in vehicle other than the driver (or equivalent weight placed in driver's position).
- Coolant and engine oil filled to correct level, and fuel tank full.
- Remove cargo and/or luggage to maintain an unloaded vehicle condition.
- Confirm spare tire, jack and tools are properly stowed.
- Carefully wipe off any dirt from headlamp lens.

#### **CAUTION:**


**Do not use organic solvent (thinner, gasoline etc.)**

- Place a driver or equivalent weight of 68.5 kg (150 lb) on the driver seat.
- By hand, bounce the front and rear of the vehicle to settle the suspension and eliminate any static load.
- Place the front tires in the straight ahead position.
- Aim each headlamp individually and ensure other headlamp beam pattern is blocked from screen.

#### **NOTE:**

- For headlamp aiming details, refer to regulations in your area.
- By regulation, no means for horizontal aim adjustment is provided from the factory; only vertical aim is adjustable.
- Use adjusting screw to perform aiming adjustment.
- Perform headlamp aiming if:
  - The vehicle front body has been repaired;
  - The front combination lamp has been removed or replaced;
  - Any outfitting has been installed;
  - The vehicle's standard load condition has been substantially increased.

#### AIMING ADJUSTMENT SCREW



1. Front combination lamp  
(view from rear)

A. Headlamp HI/LO (UP/DOWN)  
adjustment screw

# HEADLAMP AIMING ADJUSTMENT


< PERIODIC MAINTENANCE >

[HALOGEN HEADLAMP]

## Aiming Adjustment Procedure

INFOID:000000009795990

Aiming Chart



- |   |   |   |
|---|---|---|
| 1. Adjustment screen  | A. Highest cutoff line height                                     | B. Lowest cutoff line height  |
| C. Headlamp bulb center (H-V point)   | D. Distance of headlamp aiming screen from vehicle 7.62 m (25 ft) | E. Maximum aim evaluation distance from vertical center on aiming screen 399 mm (3°R) |
| F. Minimum aim evaluation distance from vertical center on aiming screen 133 mm (1°R) | G. Aim evaluation area  | H. Horizontal aiming evaluation line  |
| V. Vertical aiming evaluation line  | ↔ Right   |   |

<b>A (Highest cutoff line height)</b>	<b>-13.3 mm (0.5 in)</b>	<b>0.1° up</b>
<b>B (Lowest cutoff line height)</b>	<b>53.2 mm (2.1 in)</b>	<b>0.4° down</b>

### LOW BEAM AND HIGH BEAM

#### NOTE:

- Basic illuminating area for evaluation and/or adjustment should be within range shown on aiming chart.

- Use adjustment screw to perform aiming adjustment.
  - Ensure fog lamps are turned off.
- Block the opposite headlamp from projecting a beam pattern onto the adjustment screen, using a suitable object. Aim each headlamp individually.

#### CAUTION:

**Do not cover the lens surface with a tape etc. The lens is made of resin.**

- Place the screen on the same level and flat surface as the vehicle.

#### NOTE:

Surface should be free of any debris that would cause a difference between the headlamp center and the adjustment screen.

- Face the front of the vehicle to the screen and measure distance between the headlamp center and the screen surface.

## HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN HEADLAMP]

---

**Distance between the headlamp center and the screen (D) : 7.62 m (25 ft)**

5. Start the engine. Turn the headlamp on.
6. Determine the preferred vertical aim range dimensions, using the aiming chart.
7. Measure the projected beam within the aim evaluation segment on the screen.
8. Adjust the beam pattern of each headlamp until the aim evaluation segment (the area relative to both the highest and lowest cutoff line height) is positioned within the vertical aim range dimensions shown on the aiming chart.

# FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >


[HALOGEN HEADLAMP]

## FRONT FOG LAMP AIMING ADJUSTMENT

### Aiming Adjustment Procedure

INFOID:000000009795992

Aiming Chart




- |  |                             |                                      |
|--|-----------------------------|--------------------------------------|
| 1. Vertical center line of fog lamp (LH) | 2. Lamp center above ground | 3. Fog lamp high intensity area (LH) |
| 4. Vertical center line of fog lamp (RH) | 5. Vertical center axis     | A. 100mm (4in)                       |

#### NOTE:

- (LH) Fog lamp aiming specifications shown, (RH) similar.
- Check the following conditions before performing the aiming adjustment.
  - Keep all tires inflated to correct pressure.
  - Place vehicle on level ground.
  - See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver seat.
  - When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.

1. Set the distance between the screen and the center of the fog lamp lens as shown.

- (1) Aiming screen or a matte white surface
- (2) 7.62 m (25 ft)
- (3) Floor to center of fog lamp lens
- (4) Floor




2. Turn front fog lamps ON.

## FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[HALOGEN HEADLAMP]

3. Access adjusting screw (A) from underneath front bumper fascia. Adjust front fog lamps using adjusting screw so that the top edge of the high intensity zone is at the fog lamp centers above ground.



# FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[HALOGEN HEADLAMP]

## REMOVAL AND INSTALLATION

### FRONT COMBINATION LAMP

Exploded View

INFOID:000000009795993



1. Front fender

2. Front combination lamp

Clip

## Removal and Installation

INFOID:000000009795994

### REMOVAL

1. Remove front bumper fascia. Refer to [EXT-17, "Removal and Installation"](#).
2. Remove front combination lamp bolts and clip.
3. Pull front combination lamp forward.
4. Disconnect the harness connectors from the front combination lamp and remove.

### INSTALLATION

Installation is in the reverse order of removal.

#### NOTE:

After installation, perform headlamp aiming adjustment. Refer to [EXL-114, "Inspection"](#).

### Bulb Replacement

INFOID:000000009795995

#### WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

#### CAUTION:

- Do not touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P

## FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

- **Do not leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.**

### HEADLAMP (LOW BEAM) BULB

#### Removal

1. Rotate the bulb counterclockwise and remove from the front combination lamp.
2. Disconnect the harness connector from bulb and remove.

#### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install the bulb socket securely for watertightness.**

### HEADLAMP (HIGH BEAM) BULB

#### Removal

1. Remove plastic cover.
2. Rotate the bulb counterclockwise and remove from the front combination lamp.
3. Disconnect the harness connector from bulb and remove.

#### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install the bulb socket securely for watertightness.**

### PARKING (SIDE MARKER) LAMP BULB

#### Removal

1. Rotate the bulb counterclockwise and remove from the front combination lamp.
2. Remove the bulb from the bulb socket.

#### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install the bulb socket securely for watertightness.**

### TURN SIGNAL LAMP BULB

#### Removal

1. Rotate bulb socket counterclockwise and remove from the front combination lamp.
2. Remove the bulb from bulb socket.

#### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install the bulb socket securely for watertightness.**



# FOG LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

## FOG LAMP

### Exploded View

INFOID:000000009795997



1. Front bumper fascia      2. Fog lamp      3. Fog lamp bulb  
← Front

## Removal and Installation

INFOID:000000009795998

### REMOVAL

1. Partially remove front fender protector. Refer to [EXT-28. "FENDER PROTECTOR : Exploded View"](#).
2. Disconnect the harness connector from the fog lamp.
3. Remove fog lamp bolts and fog lamp.

### INSTALLATION

Installation in the reverse order of removal.

#### NOTE:

After installation, perform fog lamp aiming adjustment. Refer to [EXL-117. "Aiming Adjustment Procedure"](#).

## Bulb Replacement

INFOID:000000009795999

#### WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

#### CAUTION:

- Do not touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.


# FOG LAMP

[HALOGEN HEADLAMP]

## < REMOVAL AND INSTALLATION >

### REMOVAL

1. Partially remove front fender protector. Refer to [EXT-28. "FENDER PROTECTOR : Exploded View"](#).
2. Disconnect the harness connector from the fog lamp (A).
3. Rotate bulb (1) counterclockwise and remove.



### INSTALLATION

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install the bulb socket securely for watertightness.**

< REMOVAL AND INSTALLATION >


### OPTICAL SENSOR

#### Removal and Installation

INFOID:000000010336279

#### REMOVAL

1. Release the optical sensor (2) from defroster grille (1) using a suitable tool.
2. Disconnect the harness connector (A) from the optical sensor (2) and remove.



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# COMBINATION SWITCH


< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

## COMBINATION SWITCH

Exploded View

INFOID:000000010351322



1. Combination switch

2. Steering column

A. Screw


⇐ Front

## Removal and Installation

INFOID:000000010351323

### REMOVAL

1. Remove the steering angle sensor. Refer to [BRC-139, "Removal and Installation"](#).
2. Disconnect harness connector from combination switch.
3. Remove screw (A) and combination switch (1).



### INSTALLATION

Installation is in the reverse order of removal.

# HAZARD SWITCH


< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

## HAZARD SWITCH

Exploded View

INFOID:000000009796002



1. Center ventilator grille

2. Hazard switch

3. Pawl

## Removal and Installation

INFOID:000000009796003

### REMOVAL

1. Remove center ventilator grille. Refer to [VTL-13. "CENTER VENTILATOR GRILLE : Removal and Installation"](#).
2. Release the pawls and remove the hazard switch.

### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

## SIDE TURN SIGNAL LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]


### SIDE TURN SIGNAL LAMP

#### Removal and Installation

INFOID:000000010357679

#### REMOVAL

1. Remove door mirror rear finisher. Refer to [MIR-25, "Removal and Installation"](#).
2. Remove door mirror glass. Refer to [MIR-24, "Removal and Installation"](#).
3. Remove the screws (A) and reposition side turn signal lamp.



4. Disconnect the harness connector from the side turn signal lamp and remove.

#### INSTALLATION

Installation is in the reverse order of removal.

#### Bulb Replacement

INFOID:000000010357680

The side turn signal lamp bulb is not serviced separately. Refer to [EXL-126, "Removal and Installation"](#).

# REAR COMBINATION LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

## REAR COMBINATION LAMP

Exploded View

INFOID:000000009796004



1. Rear combination lamp

A. Grommet

B. Clip

## Removal and Installation

INFOID:000000009796005

### REMOVAL

1. Remove side air spoiler. Refer to [EXT-48, "Removal and Installation"](#).
2. Remove rear combination lamp bolts.
3. Pull rear combination lamp rearward to release from clip and locators.
4. Disconnect the harness connector from the rear combination lamp and remove.

### INSTALLATION

Installation is in the reverse order of removal.

## Bulb Replacement

INFOID:0000000010338569

### WARNING:

Do not touch bulb with bare hand while it is lit or right after being turned off. Burning may result.

### CAUTION:

- Do not touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

## STOP LAMP BULB

## REAR COMBINATION LAMP

[HALOGEN HEADLAMP]

### < REMOVAL AND INSTALLATION >

---

#### Removal

1. Remove rear combination lamp. Refer to [EXL-127. "Removal and Installation"](#).
2. Rotate stop lamp bulb socket counterclockwise and remove.
3. Remove stop lamp bulb from bulb socket.

#### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install bulb socket securely for watertightness.**

### TAIL LAMP BULB

#### Removal

1. Remove rear combination lamp. Refer to [EXL-127. "Removal and Installation"](#).
2. Rotate tail lamp bulb socket counterclockwise and remove.
3. Remove tail lamp bulb from bulb socket.

#### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install bulb socket securely for watertightness.**

### TURN SIGNAL LAMP BULB

#### Removal

1. Remove rear combination lamp. Refer to [EXL-127. "Removal and Installation"](#).
2. Rotate turn signal lamp bulb socket counterclockwise and remove.
3. Remove turn signal lamp bulb from bulb socket.

#### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install bulb socket securely for watertightness.**



# HIGH-MOUNTED STOP LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

## HIGH-MOUNTED STOP LAMP

Exploded View

INFOID:000000009796007



1. High-mounted stop lamp

2. Back door

Stud

### Removal and Installation

INFOID:000000009796008

#### REMOVAL

1. Remove access cover using a suitable tool. Refer to [INT-38, "Exploded View"](#).
2. Remove high-mounted stop lamp nuts.
3. Disconnect the harness connector from high-mounted stop lamp and remove.

#### INSTALLATION

Installation is in the reverse order of removal.

### Bulb Replacement

INFOID:0000000010338573

#### HIGH-MOUNTED STOP LAMP BULB

The high-mounted stop lamp bulb is not serviced separately. Refer to [EXL-129, "Removal and Installation"](#).

# BACK-UP LAMP ASSEMBLY


< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

## BACK-UP LAMP ASSEMBLY


Exploded View


INFOID:000000009796009



1. Back-up lamp assembly

2. Back door

 Clip

 Stud

## Removal and Installation

INFOID:000000009796010

### REMOVAL

1. Remove back door finisher. Refer to [INT-38. "Removal and Installation"](#).
2. Remove back-up lamp assembly nuts.
3. Pull back-up lamp assembly rearward, disconnect the harness connector and remove.

### INSTALLATION

Installation is in the reverse order of removal.

## Bulb Replacement

INFOID:000000009796011

### **WARNING:**

**Do not touch bulb with bare hand while it is lit or right after being turned off. Burning may result.**

### **CAUTION:**

- Do not touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

## TAIL LAMP BULB

### Removal

1. Remove back-up lamp assembly. Refer to [EXL-130. "Removal and Installation"](#).
2. Rotate tail lamp bulb socket counterclockwise and remove.
3. Remove tail lamp bulb from bulb socket.

### Installation

Installation is in the reverse order of removal.

### **CAUTION:**

**After installing the bulb, install bulb socket securely for watertightness.**

## BACK-UP LAMP BULB

### Removal

## BACK-UP LAMP ASSEMBLY

[HALOGEN HEADLAMP]

### < REMOVAL AND INSTALLATION >

1. Remove back-up lamp assembly. Refer to [EXL-130. "Removal and Installation"](#).
2. Rotate back-up lamp bulb socket counterclockwise and remove.
3. Remove back-up lamp bulb from bulb socket.

#### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install bulb socket securely for watertightness.**

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# LICENSE PLATE LAMP


< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

## LICENSE PLATE LAMP

### Exploded View

INFOID:000000010365316




- |                                |                                   |                       |
|--------------------------------|-----------------------------------|-----------------------|
| 1. License plate lamp bulb     | 2. License plate lamp seal        | 3. License plate lamp |
| 4. License plate lamp assembly | A. License plate lamp bulb socket |                       |

### Removal and Installation

INFOID:000000009796013

#### REMOVAL

1. Release the license lamp finisher. Refer to [EXT-50. "Exploded View"](#).
2. Remove the screw (A) (LH or RH) and pull license plate lamp (1) (LH or RH) downward.



3. Disconnect the harness connector from the license plate lamp and remove.

#### INSTALLATION

Installation is in the reverse order of removal.

#### Bulb Replacement

INFOID:000000009796014

#### **WARNING:**

**Do not touch bulb with your hand while it is on or right after being turned off. Burning may result.**

# LICENSE PLATE LAMP

< REMOVAL AND INSTALLATION >

[HALOGEN HEADLAMP]

**CAUTION:**

- Do not touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

REMOVAL

1. Remove license plate lamp. Refer to [EXL-132. "Removal and Installation"](#).
2. Rotate license plate lamp bulb socket counterclockwise and remove.
3. Remove license plate lamp bulb from bulb socket.

INSTALLATION

Installation is in the reverse order of removal.

**CAUTION:**

**After installing the bulb, install the bulb socket securely for watertightness.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# FRONT COMBINATION LAMP

< UNIT DISASSEMBLY AND ASSEMBLY >


[HALOGEN HEADLAMP]

## UNIT DISASSEMBLY AND ASSEMBLY

### FRONT COMBINATION LAMP

Exploded View

INFOID:0000000010377938



ALLIA1425ZZ

- |                           |   |                                 |
|---------------------------|---|---------------------------------|
| 1. Front combination lamp | 2. Parking (side marker) lamp bulb socket | 3. Headlamp (low beam) bulb     |
| 4. Plastic cover          | 5. Headlamp (high beam) bulb              | 5. Turn signal lamp bulb socket |

### Disassembly and Assembly

INFOID:000000009795996

#### DISASSEMBLY

1. Remove front combination lamp. Refer to [EXL-119. "Removal and Installation"](#).
2. Rotate the headlamp (low beam) bulb counterclockwise and remove.
3. Disconnect the harness connector from headlamp (low beam) bulb.
4. Remove plastic cover.
5. Rotate the headlamp (high beam) bulb counterclockwise and remove.
6. Disconnect the harness connector from headlamp (high beam) bulb.
7. Rotate the parking (side marker) lamp bulb socket counterclockwise and remove.
8. Remove the parking (side marker) lamp bulb from the bulb socket.
9. Rotate the turn signal lamp bulb socket counterclockwise and remove.
10. Remove the turn signal lamp bulb from the bulb socket.

#### ASSEMBLY

Assembly is in the reverse order of disassembly.

# REAR COMBINATION LAMP


< UNIT DISASSEMBLY AND ASSEMBLY >

[HALOGEN HEADLAMP]

## REAR COMBINATION LAMP

### Exploded View

INFOID:000000010377939



- |                          |                                  |                   |
|--------------------------|----------------------------------|-------------------|
| 1. Rear combination lamp | 2. Turn signal lamp bulb         | 3. Tail lamp bulb |
| 4. Stop lamp bulb        | A. Rear combination lamp harness |                   |

### Disassembly and Assembly

INFOID:000000010377940

#### DISASSEMBLY

1. Remove rear combination lamp. Refer to [EXL-127, "Removal and Installation"](#).
2. Rotate the stop lamp bulb socket counterclockwise and remove.
3. Remove the stop lamp bulb from the bulb socket.
4. Rotate the tail lamp bulb socket counterclockwise and remove.
5. Remove the tail lamp bulb from the bulb socket.
6. Rotate the turn signal lamp bulb socket counterclockwise and remove.
7. Remove the turn signal lamp bulb from bulb socket.

#### ASSEMBLY

Assembly is in the reverse order of disassembly.

#### **CAUTION:**

**After installing, be sure to install the bulb sockets securely to ensure watertightness.**

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[HALOGEN HEADLAMP]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Bulb Specifications

INFOID:0000000010336293

	Item	Wattage (W)*
Front combination lamp	High beam	65
	Low beam	55
	Turn signal lamp	28/8
	Parking (side marker) lamp	5
	Daytime running lamp	—
Fog lamp (if equipped)		55
Side turn signal lamp		—
Rear combination lamp	Stop lamp	21
	Tail lamp	5
	Turn signal lamp	21
Back-up lamp	Tail lamp	5
	Back-up lamp	16
License plate lamp		5
High-mounted stop lamp		—

\*: Always check with the Parts Department for the latest parts info.



PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010335190

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000010335191

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

# PREPARATION

< PREPARATION >

[LED HEADLAMP]

## PREPARATION


### PREPARATION

#### Special Service Tool

INFOID:0000000010351309

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[LED HEADLAMP]

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:0000000010330263



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

ALLIA1386ZZ

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[LED HEADLAMP]


- A. Right rear wheel area                      B. Instrument panel                      C. Engine compartment  
 D. Left side of instrument panel (view with trim panel removed)

No.	Part	Function
1.	Optical sensor	Refer to <a href="#">EXL-140, "Optical Sensor"</a> .
2.	LED headlamp control module	Turns the headlamps ON according to the power supply from IPDM E/R.
3.	Headlamp aiming motor	Moves the headlamps up/down based on inputs from the front and rear height sensors.
4.	Front height sensor	Sends the vehicles pitch angle signal to the IPDM E/R necessary for adjusting the headlamp aiming motors.
5.	Rear height sensor	Sends the vehicles pitch angle signal to the IPDM E/R necessary for adjusting the headlamp aiming motors.
6.	Combination switch (Lighting and turn signal switch)	Refer to <a href="#">BCS-9, "COMBINATION SWITCH READING SYSTEM : System Description"</a> .
7.	Hazard switch	Refer to <a href="#">EXL-141, "Hazard Switch"</a> .
8.	IPDM E/R	<ul style="list-style-type: none"> <li>Supplies voltage to the load according to the request from BCM (via CAN communication).</li> <li>Refer to <a href="#">PCS-4, "Component Parts Location"</a> for detailed installation location.</li> </ul>
9.	BCM	<ul style="list-style-type: none"> <li>Detects each switch condition by the combination switch reading function.</li> <li>Judges that the exterior lamps are turned ON according to the vehicle condition.</li> <li>Requests the headlamp (HI/LO), tail lamp and front fog lamp ON to IPDM E/R (via CAN communication).</li> <li>Requests high beam indicator lamp ON to the combination meter (via CAN communication).</li> <li>Judges the outside brightness from the optical sensor signal.</li> <li>Judges the ON/OFF timing according to the vehicle condition.</li> <li>Judges the ON/OFF status of the exterior lamp according to the outside brightness and the vehicle condition.</li> <li>Refer to <a href="#">BCS-7, "BODY CONTROL SYSTEM : Component Parts Location"</a> (with Intelligent Key) or <a href="#">BCS-79, "BODY CONTROL SYSTEM : Component Parts Location"</a> (without Intelligent Key).</li> </ul>

## Optical Sensor

INFOID:000000010330264

Optical sensor converts the outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.



# COMPONENT PARTS


< SYSTEM DESCRIPTION >

[LED HEADLAMP]

## Hazard Switch

INFOID:000000010330265

Inputs the hazard switch ON/OFF signal to BCM.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


## SYSTEM

### HEADLAMP SYSTEM

#### HEADLAMP SYSTEM : System Description

INFOID:000000010330266

#### SYSTEM DIAGRAM



#### OUTLINE

Headlamp is controlled by combination switch reading function and headlamp control function of BCM, and smart FET control function of IPDM E/R.

#### HEADLAMP (LO) OPERATION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM transmits the low beam request signal to IPDM E/R with CAN communication according to the headlamp (LO) ON condition.

#### Headlamp (LO) ON condition

- Lighting switch 2ND
- Lighting switch AUTO (auto light function ON judgment)
- Lighting switch AUTO, with the front fog lamp switch ON and the power switch ON
- Lighting switch PASS

#### HEADLAMP (HI) OPERATION

- BCM transmits the high beam request signal to IPDM E/R and the combination meter with CAN communication according to the headlamp (HI) ON condition.

#### Headlamp (HI) ON condition

- Lighting switch HI with the lighting switch 2ND or AUTO (auto light function ON judgment)
- Lighting switch PASS
- Lighting switch AUTO, with the front fog lamp switch ON, the power switch ON and lighting switch HI
- Combination meter turns the high beam indicator lamp ON according to the high beam request signal.
- IPDM E/R turns the headlamp ON according to the high beam request signal.

#### HEADLAMP SYSTEM : Fail-Safe

INFOID:000000010330267

#### CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If no CAN communication is available with BCM

# SYSTEM

< SYSTEM DESCRIPTION >

[LED HEADLAMP]


Control part	Fail-safe operation
Headlamp	<ul style="list-style-type: none"><li>• Turns ON the headlamp low beam when the power switch is turned ON</li><li>• Turns OFF the headlamp low beam when the power switch is turned OFF</li></ul>

## AUTO LIGHT SYSTEM

### AUTO LIGHT SYSTEM : System Description

INFOID:000000010336120

#### SYSTEM DIAGRAM



#### OUTLINE

- Auto light system is controlled by each function of BCM and IPDM E/R.

Controlled by BCM:

- Combination switch reading function
- Headlamp control function
- Auto light function
- Delay timer function
- Auto light adjustment system

Controlled by IPDM E/R:

- Auto light system has the auto light function and delay timer function.
- Auto light function automatically turns ON/OFF the exterior lamps\* and each illumination automatically, depending on the outside brightness.
- When auto light system turns the exterior lamps ON with the power switch OFF, delay timer function turns the exterior lamps OFF, depending on the vehicle condition with the auto light function after a certain period of time.

\*: Headlamp (LO/HI), parking lamp, side marker lamp, tail lamp and front fog lamp (Headlamp HI and front fog lamp depend on the combination switch condition).

#### AUTO LIGHT FUNCTION

- BCM detects the combination switch condition with the combination switch reading function.
- BCM supplies voltage to optical sensor when the power switch is turned ON or ACC.
- Optical sensor converts outside brightness (lux) to voltage and transmits the optical sensor signal to BCM.
- BCM judges outside brightness from the optical sensor signal and judges ON/OFF condition of the exterior lamp and each illumination according to the outside brightness.
- BCM transmits each request signal to IPDM E/R and combination meter via CAN communication according to ON/OFF condition by the auto light function.

#### NOTE:

ON/OFF timing differs based on the sensitivity from the setting. The setting can be set by CONSULT. Refer to.

#### AUTO LIGHT ADJUSTMENT SYSTEM

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

# SYSTEM

[LED HEADLAMP]

## < SYSTEM DESCRIPTION >

The auto light adjustment system automatically, dims/brightens the display, according to brightness outside the vehicle, when lighting switch 1ST, lighting switch 2ND or lighting switch AUTO is operated. Refer to [EXL-143, "AUTO LIGHT SYSTEM : System Description"](#).

### DELAY TIMER FUNCTION

BCM turns the exterior lamp OFF depending on the vehicle condition with the auto light function when the power switch is turned OFF.

- Turns the exterior lamp OFF 5 minutes after detecting that any door opens. (Door switch ON).
- Turns the exterior lamp OFF a certain period of time\* after closing all doors. (Door switch ON→OFF).
- Turns the exterior lamp OFF with the power switch ACC or the light switch OFF.

\*: The preset time is 45 seconds. The timer operating time can be set by CONSULT. Refer to [BCS-19, "HEADLAMP : CONSULT Function \(BCM - HEADLAMP\)"](#) with (Intelligent Key) or [BCS-90, "HEADLAMP : CONSULT Function \(BCM - HEADLAMP\)"](#) (without Intelligent Key).

### NOTE:


When any position other than the light switch AUTO is set, the auto light system function switches to the exterior lamp battery saver function.

## DAYTIME RUNNING LIGHT SYSTEM

### DAYTIME RUNNING LIGHT SYSTEM : System Description

INFOID:000000010330272

### SYSTEM DIAGRAM



### OUTLINE

- Daytime running light is controlled by daytime running light control function and combination switch reading function of BCM, and smart FET of IPDM E/R.

### DAYTIME RUNNING LIGHT OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM detects the vehicle condition according to power switch
- BCM detects the parking brake condition by the parking brake switch signal received from combination meter using CAN communication.
- BCM transmits the daytime running light request signal to IPDM E/R using CAN communication according to the daytime running light ON condition.

Daytime running light ON condition:

- Vehicle condition READY
- Lighting switch OFF or 1ST
- Lighting switch AUTO, and the auto light function OFF judgment
- Parking brake switch OFF

- IPDM E/R controls the daytime running light request signal.
- Power is supplied from the IPDM E/R to the daytime lights.

## HEADLAMP AIMING CONTROL SYSTEM (AUTO)




# SYSTEM

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

## HEADLAMP AIMING CONTROL SYSTEM (AUTO) : System Diagram

INFOID:000000010340297



## HEADLAMP AIMING CONTROL SYSTEM (AUTO) : System Description

INFOID:000000010340298

### OUTLINE

- Headlamp aiming control system is controlled by the IPDM E/R.
- The IPDM E/R controls the headlamp light axis height appropriately depending on the vehicle front and rear height sensor positions.
- Auto levelizer control unit detects the vehicle condition necessary for the aiming motor control with the following signals.
  - Front and rear height sensor signals

### HEADLAMP AUTO AIMING OPERATION

- The IPDM E/R calculates vehicle pitch angle from the front and rear height sensor signals and determines the necessary correction to compensate the deviation from standard light axis position.
- The IPDM E/R outputs aiming motor drive signal when operating conditions are met.

#### Operating condition:

- Ignition switch ON
- Parking lamp ON
- The IPDM E/R unit changes the aiming motor drive signal when any of the correcting conditions are detected. Output is maintained if other condition is detected.

#### Correcting condition:

- Parking lamp is turned ON.
- Vehicle posture becomes stable after the vehicle posture change is detected with the parking lamp ON and the vehicle stopped.
- Vehicle speed is maintained with the parking lamp ON and the vehicle driven.

#### CAUTION:


**If the suspension is worn, the adjusted axis position may differ from the preset position.**

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM : System Description

INFOID:0000000010330273

SYSTEM DIAGRAM



OUTLINE

Turn signal lamp and the hazard warning lamp is controlled by combination switch reading function and the flasher control function of BCM.

TURN SIGNAL LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM supplies voltage to the right (left) turn signal lamp circuit when the power switch is ON and the turn signal switch is in the right (left) position. BCM blinks the turn signal lamp.

HAZARD WARNING LAMP OPERATION

BCM supplies voltage to both turn signal lamp circuit when the hazard switch is ON. BCM blinks the hazard warning lamp.

TURN SIGNAL INDICATOR LAMP AND TURN SIGNAL OPERATION

- BCM transmits the turn signal indicator lamp signal to the combination meter using CAN communication while the turn signal lamp and the hazard warning lamp are operating.
- Combination meter outputs the turn signal sound with the integrated buzzer while blinking the turn signal indicator lamp according to the turn signal indicator lamp signal.

HIGH FLASHER OPERATION

- BCM detects the turn signal lamp circuit status from the current value.
- BCM increases the turn signal lamp blinking speed if the bulb or harness open is detected with the turn signal lamp operating.

**NOTE:**

The blinking speed is normal while operating the hazard warning lamp.

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM

PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : System De-

# SYSTEM


< SYSTEM DESCRIPTION >

[LED HEADLAMP]

scription

INFOID:000000010330274

## SYSTEM DIAGRAM



## OUTLINE

Parking, license plate, side marker and tail lamps are controlled by combination switch reading function and headlamp control function of BCM, and smart FET control function of IPDM E/R.

## PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the position light request signal to IPDM E/R and the combination meter via CAN communication according to the ON/OFF condition of the parking, license plate, side marker and tail lamps.

Parking, license plate, side marker and tail lamps ON condition:

- Lighting switch 1ST
- Lighting switch 2ND
- Lighting switch AUTO, and the auto light function ON judgment
- Lighting switch AUTO, with the front fog lamp switch ON and the power switch ON
- IPDM E/R turns the integrated tail lamp ON and turns the parking, license plate, side marker and tail lamps ON according to the position light request signal.
- Combination meter turns the tail lamp indicator lamp ON according to the position light request signal.

## PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMP SYSTEM : Fail-Safe

INFOID:000000010330276

## CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If no CAN communication is available with BCM

Control part	Fail-safe operation
<ul style="list-style-type: none"> <li>• Parking lamp</li> <li>• License plate lamp</li> <li>• Illumination</li> <li>• Tail lamp</li> <li>• Side marker lamp</li> </ul>	<ul style="list-style-type: none"> <li>• Turns ON the tail lamp when the power switch is turned ON</li> <li>• Turns OFF the tail lamp when the power switch is turned OFF</li> </ul>

## FRONT FOG LAMP SYSTEM


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

FRONT FOG LAMP SYSTEM : System Description

INFOID:000000010330277

SYSTEM DIAGRAM



OUTLINE

Front fog lamp is controlled by combination switch reading function, front fog lamp control function of BCM, and smart FET function of IPDM E/R.

FRONT FOG LAMP OPERATION

- BCM detects the combination switch condition by the combination switch reading function.
- BCM transmits the front fog lights request signal to IPDM E/R and the combination meter via CAN communication according to the front fog lamp ON condition.

Front fog lamp ON condition:

- Front fog lamp switch ON, and any of the following condition is satisfied (except for the high beam ON).
- Lighting switch 2ND
- Lighting switch AUTO and the power switch ON

IPDM E/R turns the front fog lamp ON according to the front fog lights request signal.

Combination meter turns the front fog lamp indicator lamp ON according to the front fog lights request signal.

FRONT FOG LAMP SYSTEM : Fail-Safe

INFOID:000000010330279

CAN COMMUNICATION CONTROL

When CAN communication with BCM is impossible, IPDM E/R performs fail-safe control. After CAN communication recovers normally, it also returns to normal control.

If no CAN communication is available with BCM


Control part	Fail-safe operation
Front fog lamp	Front fog lamp OFF

EXTERIOR LAMP BATTERY SAVER SYSTEM

## EXTERIOR LAMP BATTERY SAVER SYSTEM : System Description

INFOID:000000010330280

### SYSTEM DIAGRAM



### OUTLINE

- Exterior lamp battery saver system is controlled by each function of BCM and IPDM E/R.

Controlled by BCM:

- Combination switch reading function
- Headlamp control function
- Exterior lamp battery saver function

Controlled by IPDM E/R:

- BCM turns the exterior lamps\* OFF after a period of time to prevent the battery from over-discharge when the power switch is turned OFF with the exterior lamps ON.

\*: Headlamp (LO/HI), parking lamp, tail lamp, side marker lamp, license plate lamp and front fog lamp

### EXTERIOR LAMP BATTERY SAVER ACTIVATION

BCM activates the timer and turns the exterior lamp OFF 5 minutes after the power switch is turned from ON → OFF with the exterior lamps ON.

#### NOTE:

- Headlamp control function turns the exterior lamps ON normally when the power switch is turned ACC or set the vehicle to READY (both before and after the exterior lamp battery saver is turned OFF).
- The timer starts at the time that the lighting switch is turned from OFF → 1ST or 2ND with the exterior lamps OFF.

# DIAGNOSIS SYSTEM (BCM)

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM) WITH INTELLIGENT KEY

WITH INTELLIGENT KEY : CONSULT Function (BCM - COMMON ITEM) INFOID:0000000010287185

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> <li>The vehicle specification can be read and saved.</li> <li>The vehicle specification can be written when replacing BCM.</li> </ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

### SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		x	x	x	x		
Rear window defogger	REAR DEFOGGER			x	x	x		
Warning chime	BUZZER			x	x			
Interior room lamp timer	INT LAMP			x	x	x		
Exterior lamp	HEADLAMP			x	x	x		
Wiper and washer	WIPER			x	x	x		
Turn signal and hazard warning lamps	FLASHER			x	x			
Intelligent Key system	INTELLIGENT KEY		x	x	x	x		
Combination switch	COMB SW			x				
BCM	BCM	x	x			x	x	x
Immobilizer	IMMU		x	x	x			
Interior room lamp battery saver	BATTERY SAVER			x	x			
Back door open	TRUNK			x				
Vehicle security system	THEFT ALM			x	x	x		
RAP system	RETAINED PWR			x				
Signal buffer system	SIGNAL BUFFER			x				
TPMS	AIR PRESSURE MONITOR		x	x	x	x		

WITH INTELLIGENT KEY : CONSULT Function (BCM - HEADLAMP)

INFOID:0000000010287188

### DATA MONITOR

# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

Monitor Item [Unit]	Description	
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.	A
ENGINE STATE [STOP/STALL/CRANK/RUN]	Indicates engine status received from ECM on CAN communication line.	B
VEH SPEED 1 [km/h]	Indicates vehicle speed signal received from ABS on CAN communication line.	
TURN SIGNAL R [On/Off]	Indicates condition of combination switch.	C
TURN SIGNAL L [On/Off]		D
TAIL LAMP SW [On/Off]		E
HI BEAM SW [On/Off]		F
HEAD LAMP SW [On/Off]		G
LIGHT OFF SW [On/Off]		H
PASSING SW [On/Off]		I
AUTO LIGHT SW [On/Off]		J
FR FOG SW [On/Off]		K
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.	
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.	
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.	
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.	
DOOR SW-BK [On/Off]	Indicates condition of back door switch.	
OPTI SEN (DTCT) [V]	Indicates outside brightness voltage signal from optical sensor.	
OPTI SEN (FILT) [V]	Indicates outside brightness voltage signal from optical sensor filtered by BCM.	

## ACTIVE TEST

Test Item	Description	
FR FOG LAMP	This test is able to check front fog lamp operation [On/Off].	J
STOP LAMP 1	This test is able to check rear combination lamp stop lamp operation [On/Off].	
STOP LAMP 3	This test is able to check high-mounted stop lamp operation [On/Off].	K

## WORK SUPPORT

Support Item	Setting	Description	
TWILIGHT ON	MODE2*	Autolamp function ON.	
	MODE1	Autolamp function OFF.	M
CUSTOM A/LIGHT SETTING	MODE4	Less sensitive than normal setting (turns ON later).	
	MODE3	More sensitive than MODE2.	
	MODE2	More sensitive than normal setting (turns ON earlier).	N
	MODE1*	Normal setting.	
ILL DELAY SET	MODE 8	Autolamp delay timer.	O
	MODE 7		
	MODE 6		
	MODE 4		
	MODE 5		
	MODE 3		
	MODE 2		
MODE 1*		P	

\*: Initial setting

# DIAGNOSIS SYSTEM (BCM)

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

WITH INTELLIGENT KEY : CONSULT Function (BCM - FLASHER)

INFOID:000000010287191

## DATA MONITOR

Monitor Item [Unit]	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
TURN SIGNAL R [On/Off]	Indicates condition of turn signal function of combination switch.
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	Indicates condition of hazard switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.
RKE-PANIC [On/Off]	Indicates condition of panic alarm signal from Intelligent Key.

## ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [Off/LH/RH].

## WITHOUT INTELLIGENT KEY

WITHOUT INTELLIGENT KEY : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000010287193

## APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> <li>The vehicle specification can be read and saved.</li> <li>The vehicle specification can be written when replacing BCM.</li> </ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

## SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK			×	×	×		
Rear window defogger	REAR DEFOGGER			×	×	×		



# DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Warning chime	BUZZER			x	x			
Interior room lamp timer	INT LAMP			x	x	x		
Remote keyless entry system	MULTI REMOTE ENT					x		
Exterior lamp	HEADLAMP			x	x			
Wiper and washer	WIPER			x	x	x		
Turn signal and hazard warning lamps	FLASHER			x	x			
Combination switch	COMB SW			x				
BCM	BCM	x	x			x	x	x
Immobilizer	IMMU		x		x			
Interior room lamp battery saver	BATTERY SAVER			x	x			
Back door open	TRUNK			x				
Vehicle security system	THEFT ALM			x	x	x		
RAP system	RETAINED PWR			x				
TPMS	AIR PRESSURE MONITOR		x	x	x	x		

**WITHOUT INTELLIGENT KEY : CONSULT Function (BCM - HEADLAMP)** INFOID:0000000010287194

## DATA MONITOR

Monitor Item [Unit]	Description
TURN SIGNAL R [On/Off]	Indicates condition of combination switch.
TURN SIGNAL L [On/Off]	
TAIL LAMP SW [On/Off]	
HI BEAM SW [On/Off]	
HEAD LAMP SW [On/Off]	
LIGHT OFF SW [On/Off]	
PASSING SW [On/Off]	
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of back door switch.

## ACTIVE TEST

Test Item	Description
DAYTIME RUNNING LIGHT	This test is able to check daytime running lamp operation [On/Off].
ILL DIM SIGNAL	This test is able to check head lamp illumination dimming operation [On/Off].

# DIAGNOSIS SYSTEM (BCM)

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

WITHOUT INTELLIGENT KEY : CONSULT Function (BCM - FLASHER)

INFOID:000000010287195

## DATA MONITOR

Monitor Item [Unit]	Description
TURN SIGNAL R [On/Off]	Indicates condition of turn signal function of combination switch.
TURN SIGNAL L [On/Off]	
HAZARD SW [On/Off]	Indicates condition of hazard switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.
RKE-PANIC [On/Off]	Indicates condition of panic alarm signal from Intelligent Key.

## ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [Off/LH/RH].

# DIAGNOSIS SYSTEM (IPDM E/R)

[LED HEADLAMP]

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (IPDM E/R)

### CONSULT Function (IPDM E/R)

INFOID:000000010287196

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
Ecu Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

#### ECU IDENTIFICATION

The IPDM E/R part number is displayed.

#### SELF DIAGNOSTIC RESULT

Refer to [PCS-20, "DTC Index"](#).

#### DATA MONITOR

Monitor Item [Unit]	Description
REVERSE SIGNAL [Open/Close]	Indicates condition of transmission range switch R (Reverse) position.
IGN RELAY [Open/Close]	Indicates condition of ignition relay-1.
PUSH SW [Open/Close]	Indicates condition of push-button ignition switch.
INTERLOCK/PNP SW [Open/Close]	Indicates condition of transmission range switch P (Park) and N (Neutral) positions.
OIL PRESSURE SW [Open/Close]	Indicates condition of oil pressure switch.
HOOD SW [Open/Close]	Indicates condition of hood switch.
COMPRESSOR [OFF/ON]	Indicates condition of A/C compressor.
HORN RELAY [OFF/ ON]	Indicates condition of horn relay.
COOLING FAN [OFF/ON]	Indicates condition of cooling fan relay-1.
FRONT WIPER HI/LO RELAY [OFF/ON]	Indicates condition of front wiper high relay.
FRONT WIPER RELAY [OFF/ON]	Indicates condition of front wiper relay.
IGN RELAY OFF STATUS [OFF/ON]	Indicates condition of ignition relay-1 OFF status.
IGN RELAY ON STATUS [OFF/ON]	Indicates condition of ignition relay-1 ON status.
COOLING FAN RELAY 1 [OFF/ON]	Indicates condition of cooling fan relay-1.
STARTER RELAY [OFF/ON]	Indicates condition of starter relay.
COMP ECV DUTY [%]	Indicates condition of A/C compressor.
COOLING FAN RELAY 2 [%]	Indicates condition of cooling fan relay-2.
FR FOG LAMP LH [%]	Indicates condition of front fog lamp LH.
FR FOG LAMP RH [%]	Indicates condition of front fog lamp RH.
PARKING LAMP [%]	Indicates condition of parking lamp.
TAIL LAMP LH [%]	Indicates condition of tail lamp LH.
TAIL LAMP RH [%]	Indicates condition of tail lamp RH.
DAYTIME RUNNING LIGHT LH [%]	Indicates condition of daytime running light LH.
DAYTIME RUNNING LIGHT RH [%]	Indicates condition of daytime running light RH.
HEADLAMP (HI) LH [%]	Indicates condition of headlamp high beam LH.

# DIAGNOSIS SYSTEM (IPDM E/R)

**[LED HEADLAMP]**

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
HEADLAMP (HI) RH [%]	Indicates condition of headlamp high beam RH.
HEADLAMP (LO) LH [%]	Indicates condition of headlamp low beam LH.
HEADLAMP (LO) RH [%]	Indicates condition of headlamp low beam RH.
A/C RELAY STUCK [NG/OK]	Indicates condition of A/C relay.
A/C RELAY [Off/On]	Indicates condition of A/C relay.
COMP ECV STATUS [NG/OK]	Indicates condition of A/C compressor.
VEHICLE SECURITY HORN [Off/On]	Indicates condition of horn relay.
BATTERY CURRENT SENSOR [NG/OK]	Indicates condition of battery current sensor.
FRONT FOG LAMP [Off/On]	Indicates condition of front fog lamps.
COMP ECV CURRENT [A]	Indicates condition of A/C compressor current.
BATTERY VOLTAGE [V]	Indicates condition of battery voltage.
COOLING FAN DUTY [%]	Indicates condition of cooling fans.
HOOD SW (CAN) [OPEN/CLOSE]	Indicates condition of hood switch.
FRONT WIPER [STOP/LOW/HIGH]	Indicates condition of front wiper motor.
FR WIPER STOP POSITION [STOP P/ACTIVE P]	Indicates condition of front wiper motor stop.
HEADLAMP (HI) [Off/On]	Indicates condition of headlamp high beams.
HEADLAMP (LO) [Off/On]	Indicates condition of headlamp low beams.
IGNITION RELAY STATUS [Off/On]	Indicates condition of ignition relay-1.
IGN RELAY MONITOR [Off/On]	Indicates condition of ignition relay-1 feedback.
IGNITION POWER SUPPLY [Off/On]	Indicates condition of ignition relay-1.
INTERLOCK/PNP SW (CAN) [Off/On]	Indicates condition of transmission range switch P (Park) and N (Neutral) positions.
PUSH-BUTTON IGN SW (CAN) [Off/On]	Indicates condition of push-button ignition switch.
TAIL LAMP [Off/On]	Indicates condition of tail lamps.
REVERSE SIGNAL (CAN) [Off/On]	Indicates condition of transmission range switch R (Reverse) position.
ST&ST CONT RELAY STATUS [Off/ST R On]	Indicates condition of starter cut and starter relays.
STARTER MOTOR STATUS [Off/On]	Indicates condition of starter motor.
STARTER RELAY (CAN) [LOW/HIGH]	Indicates condition of starter relay.
IPDM NOT SLEEP [NO RDY/RDY]	Indicates condition of IPDM E/R sleep status.
AFTER COOLING TIME [No request/Request]	Indicates condition of cooling fan request.
AFTER COOLING SPEED [%]	Indicates condition of cooling fans.
COOLING FAN TYPE [NISSAN/RENAULT]	Indicates cooling fan type.
COMPRESSOR REQ1 [Off/On]	Indicates condition of A/C compressor request.
VHCL SECURITY HORN REQ [Off/On]	Indicates condition of horn relay request.
DTRL REQ [Off/On]	Indicates condition of daytime running light request.
SLEEP/WAKE UP [WAKEUP/SLEEP]	Indicates condition of IPDM E/R sleep/wake.
CRANKING ENABLE-TCM [NG/OK]	Indicates condition of crank enable from TCM.
CRANKING ENABLE-ECM [NG/OK]	Indicates condition of crank enable from ECM.
CAN DIAGNOSIS [NG/OK]	Indicates condition of CAN diagnosis.
FRONT FOG LAMP REQ [Off/On]	Indicates condition of front fog lamp request.
HIGH BEAM REQ [Off/On]	Indicates condition of headlamp high beam request.
HORN CHIRP [Off/On]	Indicates condition of horn relay request.
COOLING FAN REQ [%]	Indicates condition of cooling fan request.
ENGINE STATUS [STOP/RUN/IDLING]	Indicates condition of engine status.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[LED HEADLAMP]

Monitor Item [Unit]	Description
TURN SIGNAL REQ [Off/LH/RH]	Indicates condition of turn signal request.
FR WIPER REQ [RETURN/LOW/HIGH]	Indicates condition of front wiper motor request.
SHIFT POSITION [P/R/N/D/L]	Indicates condition of transmission range switch positions.
LOW BEAM REQ [Off/On]	Indicates condition of headlamp low beam request.
POSITION LIGHT REQ [Off/On]	Indicates condition of parking lamp request.
COMPRESSOR REQ2 [Off/On]	Indicates condition of A/C compressor request.
IGNITION SW [Off/On]	Indicates condition of ignition switch.
VEHICLE SPEED (METER) [mph/km/h]	Indicates vehicle speed.
BAT DISCHARGE COUNT [0-100]	Indicates condition of battery discharge.
BATTERY STATUS [NG/OK]	Indicates battery status.

## ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [Off/On].
FRONT WIPER	This test is able to check wiper motor operation [Off/Low/High].
COMPRESSOR	This test is able to check A/C compressor operation [Off/On].
COOLING FAN (DUAL)	This test is able to check cooling fan operation [Off/LO/HI].
HEADLAMP (HI)	This test is able to check headlamp high beam operation [Off/3/5].
HEADLAMP (LO)	This test is able to check headlamp low beam operation [Off/3/5].
FRONT FOG LAMP	This test is able to check front fog lamp operation [Off/3/5].
DAYTIME RUNNING LAMP	This test is able to check daytime running lamp operation [Off/3/5].
PARKING LAMP	This test is able to check parking lamp operation [Off/3/5].
TAIL LAMP	This test is able to check tail lamp operation [Off/3/5].

## CAN DIAG SUPPORT MNTR

Refer to [LAN-14, "CAN Diagnostic Support Monitor"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

M  
N  
O  
P

# ECU DIAGNOSIS INFORMATION

## BCM, IPDM E/R

### List of ECU Reference

INFOID:000000010330283

ECU	Reference
BCM	<a href="#">BCS-28. "Reference Value"</a> (with Intelligent Key system) <a href="#">BCS-96. "Reference Value"</a> (without Intelligent Key system)
	<a href="#">BCS-47. "Fail Safe"</a> (with Intelligent Key system) <a href="#">BCS-107. "Fail Safe"</a> (without Intelligent Key system)
	<a href="#">BCS-47. "DTC Inspection Priority Chart"</a> (with Intelligent Key system) <a href="#">BCS-107. "DTC Inspection Priority Chart"</a> (without Intelligent Key system)
	<a href="#">BCS-48. "DTC Index"</a> (with Intelligent Key system) <a href="#">BCS-108. "DTC Index"</a> (without Intelligent Key system)
IPDM E/R	<a href="#">PCS-12. "Reference Value"</a> .
	<a href="#">PCS-19. "Fail-safe"</a>
	<a href="#">PCS-20. "DTC Index"</a>

# HEADLAMP

< WIRING DIAGRAM >

[LED HEADLAMP]


## WIRING DIAGRAM

### HEADLAMP

#### Wiring Diagram

INFOID:000000010288648

### HEADLAMP - LED



AALWA0769GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# HEADLAMP

< WIRING DIAGRAM >

[LED HEADLAMP]


## HEAD LAMP - LED CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
33	LG	I CSW 5
34	Y	O CSW 5
36	G	I CSW 3
37	GR	I CSW 4
38	V	I CSW 1
39	W	I CSW 2

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
84	BR	O CSW 2
85	SB	O CSW 1
86	P	O CSW 3
87	BG	O CSW 4
95	V	I SHORTING PIN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-
4	BG	-

Terminal No.	Color of Wire	Signal Name
5	G	-
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-




# HEADLAMP

< WIRING DIAGRAM >

[LED HEADLAMP]


Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
5	L	-
11	P	-
12	P	-
15	P	-

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	LA/BR	-
13P	LA/G	-

AALIA2139GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HEADLAMP

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	E40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	-
3	B	-

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L
45	LA/G	BAT
46	LA/BR	IGN
52	B	GND2

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND1

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
12	B	SIGNAL GROUND

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	L	-
6	P	-
9	L	-
10	P	-

AALIA2140GB


# HEADLAMP

< WIRING DIAGRAM >

[LED HEADLAMP]

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED




Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
59	G	O LIGHT HBEAM LH
60	Y	L LED DETECTION 1
62	SB	O LIGHT LBEAM RH

Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
50	L	O LIGHT LBEAM LH
53	GR	L LED DETECTION 2
54	LG	O LIGHT HBEAM RH

Connector No.	E201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
3	B	-

AALIA2141GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HEADLAMP

< WIRING DIAGRAM >

[LED HEADLAMP]

Connector No.	E239
Connector Name	FRONT COMBINATION LAMP LH (WITH LED HEADLAMPS)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
4	B	-
5	G	-
6	L	-
7	GR	-

Connector No.	E240
Connector Name	FRONT COMBINATION LAMP RH (WITH LED HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
4	B	-
5	LG	-
6	SB	-
7	Y	-

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

# DAYTIME LIGHT SYSTEM


< WIRING DIAGRAM >

[LED HEADLAMP]

## DAYTIME LIGHT SYSTEM

### Wiring Diagram

INFOID:000000010288649



AALWA0771GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


## DAYTIME LIGHT SYSTEM CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
33	LG	I CSW 5
34	Y	O CSW 5
36	G	I CSW 3
37	GR	I CSW 4
38	V	I CSW 1
39	W	I CSW 2

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
84	BR	O CSW 2
85	SB	O CSW 1
86	P	O CSW 3
87	BG	O CSW 4
95	V	I SHORTING PIN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-
4	BG	-

Terminal No.	Color of Wire	Signal Name
5	G	-
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-

# DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
8P	LA/BR	-
13P	LA/G	-

Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
5	L	-
11	P	-
12	P	-
15	P	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
27J	G	-
61J	L	-
62J	P	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND1
26	G	PBK SW

AALIA2122GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	E40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	-
3	B	-

Connector No.	E16
Connector Name	ECM
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
99	P	CAN-L
100	L	CAN-H

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L
45	LA/G	BAT
46	LA/BR	IGN
52	B	GND2

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Connector No.	E52
Connector Name	PARKING BRAKE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
12	B	SIGNAL GROUND

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-
5	L	-
6	P	-
9	L	-
10	P	-

AALIA2123GB



# DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED



Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND


Connector No.	E201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
3	B	-

Terminal No.	Color of Wire	Signal Name
27J	G	-
61J	L	-
62J	P	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



AALIA2124GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	E234
Connector Name	FRONT COMBINATION LAMP RH (WITH HALOGEN HEADLAMPS)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
10	R	-
11	GR	-

Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
58	R	O LIGHT DTRL RH

Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
49	R	O LIGHT DTRL LH

Connector No.	E240
Connector Name	FRONT COMBINATION LAMP RH (WITH LED HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
8	R	-
11	B	-

Connector No.	E239
Connector Name	FRONT COMBINATION LAMP LH (WITH LED HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
8	R	-
11	B	-

Connector No.	E236
Connector Name	FRONT COMBINATION LAMP LH (WITH HALOGEN HEADLAMPS)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
10	R	-
11	GR	-


AALIA2125GB

# DAYTIME LIGHT SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# AUTO LIGHT SYSTEM


[LED HEADLAMP]

< WIRING DIAGRAM >

## AUTO LIGHT SYSTEM

### Wiring Diagram

INFOID:000000010288650



AALWA0767GB


# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

## AUTO LIGHT SYSTEM CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M13
Connector Name	OPTICAL SENSOR
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	W	-
2	LG	-
3	V	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
12	W	O PWR AUTOLIGHT SENSOR
19	LG	I AUTOLIGHT SENSOR
30	V	O GND AUTOLIGHT SENSOR
33	LG	I CSW 5
34	Y	O CSW 5
36	G	I CSW 3
37	GR	I CSW 4
38	V	I CSW 1
39	W	I CSW 2

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
84	BR	O CSW 2
85	SB	O CSW 1
86	P	O CSW 3
87	BG	O CSW 4
95	V	I SHORTING PIN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2

AALIA2112GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-
4	BG	-
5	G	-
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
11	P	-
12	P	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	L	-
6	P	-
9	L	-
10	P	-

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED




Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
4	Y	O LIGHT POSITION REAR LH
12	B	SIGNAL GROUND
17	W	O LIGHT POSITION REAR RH

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN

Terminal No.	Color of Wire	Signal Name
50	W	I RR DOOR SW
51	LG	I TGATE SW
52	R	I RL DOOR SW
53	SB	I AS DOOR2 SW
57	SB	I DR DOOR2 SW
60	L	CAN-H
80	P	CAN-L

Connector No.	B49
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
6	SB	—
10	W	—

Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
57	W	O LIGHT FR FOG LAMPS RH
58	R	O LIGHT DTRL RH
59	G	O LIGHT HBEAM LH
61	GR	O LIGHT CLEARANCE FR RH
62	SB	O LIGHT LBEAM RH

Connector No.	B46
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
19	LG	—

Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN

Terminal No.	Color of Wire	Signal Name
49	R	O LIGHT DTRL LH
50	L	O LIGHT LBEAM LH
51	V	O LIGHT FR FOG LAMPS LH
54	LG	O LIGHT HBEAM RH
56	BG	O LIGHT CLEARANCE FR LH

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
24	P	—
25	L	—

AALIA2115GB




# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	B70
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	R	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	B54
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	B141
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	GR	-

Connector No.	B140
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	GR	-
10	W	-

Connector No.	B71
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	SB	-

AALIA2116GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# AUTO LIGHT SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
19	W	-

Connector No.	B142
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	W	-

Connector No.	D512
Connector Name	BACK DOOR LOCK ASSEMBLY (WITH POWER BACK DOOR SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	W	-
8	B	-

Connector No.	D508
Connector Name	BACK DOOR LOCK ASSEMBLY (WITHOUT POWER BACK DOOR SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	W	-
4	GR	-

AALIA2117GB

# FRONT FOG LAMP SYSTEM


< WIRING DIAGRAM >

[LED HEADLAMP]

## FRONT FOG LAMP SYSTEM

### Wiring Diagram

INFOID:000000010288651



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


## FOG LAMP CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
33	LG	I CSW 5
34	Y	O CSW 5
36	G	I CSW 3
37	GR	I CSW 4
38	V	I CSW 1
39	W	I CSW 2

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
84	BR	O CSW 2
85	SB	O CSW 1
86	P	O CSW 3
87	BG	O CSW 4
95	V	I SHORTING PIN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-
4	BG	-
5	G	-


Terminal No.	Color of Wire	Signal Name
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-

# FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
5	L	-
11	P	-
12	P	-
15	P	-

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	LA/BR	-
13P	LA/G	-

AALIA2128GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	E40
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	GR	-

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L
45	LA/G	BAT
46	LA/BR	IGN
52	B	GND2

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	GND1

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	L	-
6	P	-
9	L	-
10	P	-

AALIA2129GB


# FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED




Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
57	W	O LIGHT FR FOG LAMPS RH

Terminal No.	Color of Wire	Signal Name
51	V	O LIGHT FR FOG LAMPS LH

Connector No.	E201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-

AALIA2130GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# FRONT FOG LAMP SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Connector No.	E221
Connector Name	FRONT FOG LAMP RH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	W	-
2	GR	-

Connector No.	E222
Connector Name	FRONT FOG LAMP LH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	V	-
2	GR	-

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-



# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

## TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

### Wiring Diagram

INFOID:000000010288652

#### TURN SIGNAL AND HAZARD WARNING LAMPS



AALWA0772GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


## TURN SIGNAL AND HAZARD WARNING LAMPS CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	LA/G	O D I FR LEFT D
3	LA/Y	O D I FR RIGHT D
11	Y	I HAZARD SW D
33	LG	I CSW 5
34	Y	O CSW 5
36	G	I CSW 3
37	GR	I CSW 4
38	V	I CSW 1
39	W	I CSW 2

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
84	BR	O CSW 2
85	SB	O CSW 1
86	P	O CSW 3
87	BG	O CSW 4
95	V	I SHORTING PIN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
168	BG	I PWR FLASHERS
170	B	I GND1
171	B	I GND2

Connector No.	M26
Connector Name	HAZARD SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	Y	-
3	GR	-


AALIA2162GB

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
2	L	-
5	L	-
12	P	-
15	P	-

Connector No.	M33
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6N	BG	-

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-
4	BG	-
5	G	-
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M65
Connector Name	JOINT CONNECTOR-M26
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
4	B	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	LA/BR	-
13P	LA/G	-

AALIA2163GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L
45	LA/G	BAT
46	LA/BR	IGN
52	B	GND2

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	GND1

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M158
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	LAY	-

Connector No.	M78
Connector Name	JOINT CONNECTOR-M28
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
7	GR	-


AALIA2164GB

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Connector No.	E29
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
135	BR	DI FR LEFT E
136	GR	O DI FR RIGHT E

Connector No.	M170
Connector Name	JOINT CONNECTOR-M29
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
4	B	-

Connector No.	M168
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
22	LA/G	-

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

Connector No.	E105
Connector Name	FRONT COMBINATION LAMP LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	BR	-
2	B	-

Connector No.	E103
Connector Name	FRONT COMBINATION LAMP RH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	BR	-

AALIA2165GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Connector No.	B49
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
11	P	-

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	B23
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
157	GR	O DI RR LEFT B
160	P	O DI RR RIGHT B

Connector No.	B102
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	LA/V	-
4	B	-

Connector No.	B90
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	GR	-
4	B	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-


AALIA2166GB

# TURN SIGNAL AND HAZARD WARNING LAMP SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	D14
Connector Name	DOOR MIRROR LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	LA/G	-
14	LA/B	-

Connector No.	D3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	LA/B	-
22	LA/G	-

Connector No.	B140
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
11	LAV	-

Connector No.	D107
Connector Name	DOOR MIRROR RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13	LA/G	-
14	LA/B	-

Connector No.	D102
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LA/B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
21	LA/G	-

AALIA2239GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM


< WIRING DIAGRAM >

[LED HEADLAMP]

## PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

Wiring Diagram

INFOID:000000010288653



AALWA0786GB




# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

(HK) : WITH HALOGEN HEADLAMPS  
 (LV) : WITH LED HEADLAMPS  
 (HK) : 12 \*2  
 (LV) : 9 \*1  
 (LV) : 9 \*2  
 (LV) : 10



AALWA0787GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P


# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


## PARKING, LICENSE AND TAIL LAMPS CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
33	LG	I CSW 5
34	Y	O CSW 5
36	G	I CSW 3
37	GR	I CSW 4
38	V	I CSW 1
39	W	I CSW 2

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
84	BR	O CSW 2
85	SB	O CSW 1
86	P	O CSW 3
87	BG	O CSW 4
95	V	I SHORTING PIN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-
4	BG	-


Terminal No.	Color of Wire	Signal Name
5	G	-
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
5	L	-
11	P	-
12	P	-
15	P	-

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	LA/BR	-
13P	LA/G	-

AALIA2150GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6M	Y	-

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L
45	LA/G	BAT
46	LA/BR	IGN
52	B	GND2

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND1


Connector No.	E40
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
3	B	-

Terminal No.	99A
Color of Wire	W
Signal Name	-

Connector No.	E34
Connector Name	WIRE TO WIRE
Connector Color	GRAY




AALIA2151GB

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	Y	O LIGHT POSITION REAR LH
12	B	SIGNAL GROUND
17	W	O LIGHT POSITION REAR RH

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	L	-
6	P	-
9	L	-
10	P	-

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED



Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

AALIA2152GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]


Connector No.	E201
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
3	B	-

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E233
Connector Name	FRONT COMBINATION LAMP RH (WITH HALOGEN HEADLAMPS)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
8	B	-
9	W	-

Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
61	GR	O LIGHT CLEARANCE FR RH

Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
56	BG	O LIGHT CLEARANCE FR LH

AALIA2153GB

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

Connector No.	E236
Connector Name	FRONT COMBINATION LAMP LH (WITH HALOGEN HEADLAMPS)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
11	GR	-
12	BG	-

Connector No.	E235
Connector Name	FRONT COMBINATION LAMP LH (WITH HALOGEN HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
8	B	-
9	P	-

Connector No.	E234
Connector Name	FRONT COMBINATION LAMP RH (WITH HALOGEN HEADLAMPS)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
11	GR	-
12	GR	-

Connector No.	B2
Connector Name	JOINT CONNECTOR-B27
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LA/R	-
2	LA/R	-
3	LA/R	-
4	LA/R	-

Connector No.	E240
Connector Name	FRONT COMBINATION LAMP RH (WITH LED HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
9	GR	-
10	W	-
11	B	-

Connector No.	E239
Connector Name	FRONT COMBINATION LAMP LH (WITH LED HEADLAMPS)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
9	BG	-
10	P	-
11	B	-

AALIA2154GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	B29
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1T	LA/R	—

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

Connector No.	B3
Connector Name	JOINT CONNECTOR-B03
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LA/BR	—
2	LA/BR	—
3	LA/BR	—


Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	—
25	L	—

Terminal No.	99A	Color of Wire	LA/BR	Signal Name	—
--------------	-----	---------------	-------	-------------	---

Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



AALIA2155GB



# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	B54
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	B49
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	LA/BR	-

Connector No.	B46
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	LA/BR	-
22	LA/R	-
23	LA/R	-

Connector No.	B102
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LA/BR	-
4	B	-

Connector No.	B90
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LA/R	-
4	B	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

AALIA2156GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	B140
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
9	LA/BR	-

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
18	LA/R	-
22	LA/Y	-
23	P	-

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	D516
Connector Name	LICENSE PLATE LAMP LH
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	B	-
2	P	-

Connector No.	D517
Connector Name	LICENSE PLATE LAMP RH
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	B	-
2	R	-

Connector No.	D518
Connector Name	BACK-UP LAMP ASSEMBLY LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
3	LA/Y	-

AALIA2157GB


# PARKING, LICENSE PLATE AND TAIL LAMPS SYSTEM

< WIRING DIAGRAM >

[LED HEADLAMP]

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

Connector No.	D519
Connector Name	BACK-UP LAMP ASSEMBLY RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
3	LA/R	-

AALIA2173GB

# STOP LAMP

< WIRING DIAGRAM >


[LED HEADLAMP]

## STOP LAMP

Wiring Diagram

INFOID:000000010288654

STOP LAMP



AALWA0765GB

# STOP LAMP

< WIRING DIAGRAM >

[LED HEADLAMP]

## STOP LAMP CONNECTORS

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
169	GR	I PWR STOP LAMP
170	B	I GND1
171	B	I GND2

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
10R	GR	-

Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5M	V	-

Connector No.	E29
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
125	LG	I BRAKE SW2

Connector No.	E38
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	LG	-

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
23	LG	-
27	LG	-

AALIA2158GB







A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# STOP LAMP

< WIRING DIAGRAM >

[LED HEADLAMP]




AALIA2159GB

# STOP LAMP

< WIRING DIAGRAM >

[LED HEADLAMP]

Connector No.	B140
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	8	Color of Wire	LAY	Signal Name	-
--------------	---	---------------	-----	-------------	---

Connector No.	B102
Connector Name	REAR COMBINATION LAMP RH
Connector Color	WHITE



Terminal No.	2	Color of Wire	LAY	Signal Name	-
4	B	B	B	-	-

Connector No.	B90
Connector Name	REAR COMBINATION LAMP LH
Connector Color	WHITE



Terminal No.	2	Color of Wire	LAY	Signal Name	-
4	B	B	B	-	-

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	1	Color of Wire	B	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	D503
Connector Name	HIGH-MOUNTED STOP LAMP
Connector Color	WHITE



Terminal No.	1	Color of Wire	Y	Signal Name	-
2	B	B	B	-	-

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	17	Color of Wire	Y	Signal Name	-
--------------	----	---------------	---	-------------	---

AALIA2160GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BACK-UP LAMP

< WIRING DIAGRAM >


[LED HEADLAMP]

## BACK-UP LAMP

Wiring Diagram

INFOID:000000010288655

BACK - UP LAMP



AALWA0763GB




# BACK-UP LAMP

< WIRING DIAGRAM >

[LED HEADLAMP]


## BACK-UP LAMP CONNECTORS

Connector No.	E34
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
100A	G	-

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
16	G	O LIGHT REVERSE LAMP

Connector No.	F35
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
71	SB	O IGN REVERSE SW AC VALVE
79	G	LI LIGHT REVERSE SW

Connector No.	F78
Connector Name	TRANSMISSION RANGE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
4	W	-
8	G	-

AALIA2118GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# BACK-UP LAMP

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
100A	G	-

Connector No.	B46
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
20	LA/G	-
21	LA/G	-

Connector No.	B54
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20	LA/L	-
21	LA/G	-



Terminal No.	Color of Wire	Signal Name
2	G	-
6	LA/G	-
10	LA/G	-

# BACK-UP LAMP

< WIRING DIAGRAM >



[LED HEADLAMP]

Connector No.	D519
Connector Name	BACK-UP LAMP ASSEMBLY RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	GR	-
2	LA/L	-

Connector No.	D518
Connector Name	BACK-UP LAMP ASSEMBLY LH
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	GR	-
2	LA/G	-

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	B	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

AALIA2120GB

# HEADLAMP AIMING SYSTEM (AUTOMATIC)

< WIRING DIAGRAM >


[LED HEADLAMP]

## HEADLAMP AIMING SYSTEM (AUTOMATIC)

Wiring Diagram

INFOID:000000010288656

### HEADLAMP AIMING SYSTEM



AALWA0770GB


# HEADLAMP AIMING SYSTEM (AUTOMATIC)

< WIRING DIAGRAM >

[LED HEADLAMP]


## HEADLAMP AIMING SYSTEM CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
33	LG	I CSW 5
34	Y	O CSW 5
36	G	I CSW 3
37	GR	I CSW 4
38	V	I CSW 1
39	W	I CSW 2

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
84	BR	O CSW 2
85	SB	O CSW 1
86	P	O CSW 3
87	BG	O CSW 4
95	V	I SHORTING PIN

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2

Connector No.	M28
Connector Name	COMBINATION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	LG	-
2	SB	-
3	GR	-
4	BG	-

Terminal No.	Color of Wire	Signal Name
5	G	-
6	W	-
7	Y	-
8	V	-
10	BR	-
15	P	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


EXL

# HEADLAMP AIMING SYSTEM (AUTOMATIC)

< WIRING DIAGRAM >

[LED HEADLAMP]


Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
5	L	-
11	P	-
12	P	-
15	P	-

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8P	LA/BR	-
13P	LA/G	-


AALIA2144GB

# HEADLAMP AIMING SYSTEM (AUTOMATIC)

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L
45	LA/G	BAT
46	LA/BR	IGN
52	B	GND2

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND1


Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	L	-
6	P	-
9	L	-
10	P	-

Terminal No.	Color of Wire	Signal Name
75A	B	-
76A	G	-
77A	SB	-

Connector No.	E34
Connector Name	WIRE TO WIRE
Connector Color	GRAY



AALIA2145GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HEADLAMP AIMING SYSTEM (AUTOMATIC)

< WIRING DIAGRAM >


[LED HEADLAMP]

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
20	W	I HEIGHT FRONT
21	SB	I HEIGHT REAR
22	P	CAN-L
24	L	CAN-H
25	G	O HEIGHT SENSOR SUPPLY
26	B	O HEIGHT SENSOR GROUND
31	B	2ND SIGNAL GROUND

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
12	B	SIGNAL GROUND

Connector No.	E110
Connector Name	FRONT HEIGHT SENSOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	W	-
2	B	-
3	BR	-

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED



Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

AALIA2146GB




# HEADLAMP AIMING SYSTEM (AUTOMATIC)

< WIRING DIAGRAM >

[LED HEADLAMP]


Connector No.	E217
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
55	SB	O IGN REVERSE SW AC VALVE 1

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	E238
Connector Name	FRONT COMBINATION LAMP RH (HEAD LAMP AIMING MOTOR)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
12	SB	-
13	B	-
14	V	-

Connector No.	E237
Connector Name	FRONT COMBINATION LAMP LH (HEAD LAMP AIMING MOTOR)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
12	L	-
13	B	-
14	V	-

Connector No.	E218
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
63	B	I LEVELIZER DC MOTOR GROUND
64	V	O LEVELIZER DC MOTOR

AALIA2147GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL


# HEADLAMP AIMING SYSTEM (AUTOMATIC)

< WIRING DIAGRAM >

[LED HEADLAMP]

Terminal No.	Color of Wire	Signal Name
75A	B	-
76A	G	-
77A	SB	-

Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN




60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61

Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

Connector No.	B91
Connector Name	REAR HEIGHT SENSOR
Connector Color	BLACK




Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	B	-
3	G	-

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

AALIA2148GB

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LED HEADLAMP]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000010287040

OVERALL SEQUENCE



DETAILED FLOW

Revision: November 2013

EXL-219

2014 Rogue NAM

JMKIA8652GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LED HEADLAMP]

---

## 1. GET INFORMATION FOR SYMPTOM

---

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

---

## 2. CHECK DTC

---

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

### Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

---

## 3. CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

---

## 4. CONFIRM THE SYMPTOM

---

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

---

## 5. PERFORM DTC CONFIRMATION PROCEDURE

---

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time.

If two or more DTCs are detected, refer to [BCS-47, "DTC Inspection Priority Chart"](#) (with Intelligent Key system) or [BCS-107, "DTC Inspection Priority Chart"](#) (without Intelligent Key system) (BCM) or [PCS-20, "DTC Index"](#) (IPDM E/R), and determine trouble diagnosis order.

### **NOTE:**

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.

If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

### Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-41, "Intermittent Incident"](#).

---

## 6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

---

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

### Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[LED HEADLAMP]

## 7. DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-41, "Intermittent Incident"](#).

## 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

## 9. FINAL CHECK

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[LED HEADLAMP]

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:0000000010365309

#### **CAUTION:**

- When the IPDM E/R is replaced or disconnected and reconnected, perform “SENSOR INITIALIZE” with CONSULT.

#### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:0000000010365310

### 1.SENSOR INITIALIZE

#### ⓈCONSULT WORK SUPPORT

Perform “SENSOR INITIALIZE”. Refer to [EXL-222. "SENSOR INITIALIZE : Special Repair Requirement"](#).

>> WORK END

### SENSOR INITIALIZE

#### SENSOR INITIALIZE : Description

INFOID:0000000010365313

#### HEADLAMP AIMING CONTROL SYSTEM

Perform the sensor initialize when installing, removing and replacing the auto levelizer control unit or suspension components.

#### SENSOR INITIALIZE : Special Repair Requirement

INFOID:0000000010365314

#### **CAUTION:**

If performing aiming adjustment after the levelizer initialization, be sure to start the engine after turning ignition switch OFF.

### 1.VEHICLE CONDITION CHECK

1. Park the vehicle in the straight-forward position.
2. Unload the vehicle (no passenger aboard).

>> GO TO 2.

### 2.SENSOR INITIALIZE

#### ⓈCONSULT WORK SUPPORT

1. Select “SENSOR INITIALIZE” of IPDM E/R work support item.
2. Select “START”.
3. When “INITIALIZE COMPLETE”, select “END”.

#### **CAUTION:**

If “INITIALIZE NOT DONE” is indicated, auto levelizer control unit detects that the sensor lever signal was changing. The sensor initialization is cancelled. In this case, turn the ignition switch OFF, do not allow the vehicle height to change. Perform the sensor initialization again.

Is the sensor initialize completed?

- YES >> GO TO 3.  
NO >> Perform the sensor initialize again.

### 3.SELF-DIAGNOSIS RESULT CHECK

Perform the self-diagnosis with CONSULT. Check that any DTC is not detected.

Is any DTC detected?

- YES >> GO TO 2.  
NO >> Sensor initialize completed.

# LED HEADLAMP OPERATION INSPECTION

< BASIC INSPECTION >

[LED HEADLAMP]

## LED HEADLAMP OPERATION INSPECTION

### Diagnosis Procedure

INFOID:000000010287041

#### 1. CHECK START

1. In the cool LED status (wait for more than 10 minutes after turning headlamp OFF), turn ON and turn OFF headlamp for the several times. Check that headlamp operates normally each time.
2. In the cool LED status, turn headlamp ON, wait until headlamp enters to the stable status (approximately 5 minutes after turning headlamp ON), and then check that headlamp operates normally without blinking or flickering.
3. In the warm LED status (turn headlamp ON for more than 15 minutes and wait for 1 minute after turning OFF), turn ON and turn OFF headlamp for the several times. Check that headlamp operates normally each time.
4. Turn headlamp ON for approximately 30 minutes, and then check that headlamp operates normally without difference in brightness between LH and RH, blinking or flickering.

#### Is the inspection result normal?

- YES >> Inspection End.  
NO >> Refer to [EXL-256, "Symptom Table"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## DTC/CIRCUIT DIAGNOSIS

### POWER SUPPLY AND GROUND CIRCUIT

#### BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM)

#### BCM (BODY CONTROL SYSTEM) (WITH INTELLIGENT KEY SYSTEM) : Diagnosis Procedure

INFOID:000000010290271

Regarding Wiring Diagram information, refer to [BCS-50, "Wiring Diagram"](#).

### 1. CHECK FUSE

Check that the following fuse is not blown.

Terminal No.	Signal name	Fuse No.
161	BCM power supply	7 (10A)

#### Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.  
NO >> GO TO 2.

### 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M20.
2. Check voltage between BCM connector M20 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M20	161	—	Battery voltage

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness or connectors.

### 3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M20 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	170	—	Yes
	171		

#### Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

#### BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM)

#### BCM (BODY CONTROL SYSTEM) (WITHOUT INTELLIGENT KEY SYSTEM) : Diagnosis Procedure

INFOID:000000010290272

Regarding Wiring Diagram information, refer to [BCS-110, "Wiring Diagram"](#).

### 1. CHECK FUSE



# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

Check that the following fuse is not blown.

Terminal No.	Signal name	Fuse No.
161	BCM power supply	7 (10A)

Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.  
NO >> GO TO 2.

## 2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M20.
2. Check voltage between BCM connector M20 and ground.

BCM		Ground	Voltage (Approx.)
Connector	Terminal		
M20	161	—	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness or connectors.

## 3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M20 and ground.

BCM		Ground	Continuity
Connector	Terminal		
M20	170	—	Yes
	171		

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# OPTICAL SENSOR

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

## OPTICAL SENSOR

### Component Function Check

INFOID:000000010350547

#### 1.CHECK OPTICAL SENSOR SIGNAL BY CONSULT

##### CONSULT DATA MONITOR

1. Turn power switch ON.
2. Select "OPTICAL SENSOR" of BCM (HEADLAMP) data monitor item.
3. Turn lighting switch AUTO.
4. With the optical sensor illuminating, check the monitor status.

Monitor item	Condition		Voltage (Approx.)
OPTICAL SENSOR	Optical sensor	When illuminating	3.1 V or more *
		When shutting off light	0.6 V or less

\*: Illuminates the optical sensor. The value may be less than the standard value if brightness is weak.

##### Is the inspection result normal?

- YES >> Optical sensor is normal.  
NO >> Refer to [EXL-226, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010350548

#### 1.CHECK OPTICAL SENSOR POWER SUPPLY INPUT

1. Turn power switch ON.
2. Turn lighting switch AUTO.
3. Check voltage between optical sensor harness connector and ground.

(+)		(-)	Voltage (Approx.)
Optical sensor			
Connector	Terminal	Ground	5 V
M13	1		

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> GO TO 4.

#### 2.CHECK OPTICAL SENSOR GROUND INPUT

Check voltage between optical sensor harness connector and ground.

(+)		(-)	Voltage (Approx.)
Optical sensor			
Connector	Terminal	Ground	0 V
M13	3		

##### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 6.

#### 3.CHECK OPTICAL SENSOR SIGNAL OUTPUT

With illuminating the optical sensor, check voltage between optical sensor harness connector and ground.

# OPTICAL SENSOR

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

(+)		(-)	Condition	Voltage (Approx.)	
Optical sensor					
Connector	Terminal				
M13	2	Ground	Optical sensor	When illuminating	3.1 V or more *
				When shutting off light	0.6 V or less

\*: Illuminate the optical sensor. The value may be less than the standard if brightness is weak.

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace the optical sensor.

## 4. CHECK OPTICAL SENSOR OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M13	1	M18	12	Yes

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 5. CHECK OPTICAL SENSOR SHORT CIRCUIT

Check continuity between optical sensor harness connector and ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M13	1		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with I Key) or [BCS-135, "Removal and Installation"](#) (without I Key).

NO >> Repair or replace harness.

## 6. CHECK OPTICAL SENSOR GROUND OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M13	3	M18	30	Yes

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with I Key) or [BCS-135, "Removal and Installation"](#) (without I Key).

NO >> Repair or replace harness.

## 7. CHECK OPTICAL SENSOR SIGNAL OPEN CIRCUIT

1. Turn power switch OFF.
2. Disconnect optical sensor connector and BCM connector.
3. Check continuity between optical sensor harness connector and BCM harness connector.

# OPTICAL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

Optical sensor		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M13	2	M18	19	Yes

Is the inspection result normal?

YES >> GO TO 8.

NO >> Repair or replace harness.

## 8. CHECK OPTICAL SENSOR SHORT CIRCUIT

Check continuity between optical sensor harness connector and ground.

Optical sensor		Ground	Continuity
Connector	Terminal		
M13	2		No

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with I Key) or [BCS-135, "Removal and Installation"](#) (without I Key).

NO >> Repair or replace harness.

# HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## HAZARD SWITCH

### Component Function Check

INFOID:000000010350549

#### 1.CHECK HAZARD SWITCH SIGNAL BY CONSULT

##### CONSULT DATA MONITOR

1. Turn power switch ON.
2. Select "HAZARD SW" of BCM (FLASHER) data monitor item.
3. With operating the hazard switch, check the monitor status.

Monitor item	Condition		Monitor status
HAZARD SW	Hazard switch	ON	On
		OFF	Off

Is the inspection result normal?

- YES >> Hazard switch circuit is normal.  
 NO >> Refer to [EXL-229. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010350550

#### 1.CHECK HAZARD SWITCH SIGNAL INPUT

1. Turn power switch OFF.
2. Disconnect hazard switch connector.
3. Check voltage between hazard switch connector and ground.

(+)		(-)	Voltage (Approx.)
Hazard switch			
Connector	Terminal	Ground	Battery voltage
M26	2		

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> GO TO 2.

#### 2.CHECK HAZARD SWITCH SIGNAL OPEN CIRCUIT

1. Disconnect BCM connector.
2. Check continuity between hazard switch harness connector and BCM harness connector.

Hazard switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M26	2	M18	11	Yes

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

#### 3.CHECK HAZARD SWITCH SIGNAL SHORT CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		
M26	2		No

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-75. "Removal and Installation"](#) (with Intelligent Key system) or [BCS-135. "Removal and Installation"](#) (without Intelligent Key system).  
 NO >> Repair or replace harness.

# HAZARD SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## 4. CHECK HAZARD SWITCH GROUND OPEN CIRCUIT

Check continuity between hazard switch harness connector and ground.

Hazard switch		Ground	Continuity
Connector	Terminal		Yes
M26	3		

Is the inspection result normal?

- YES >> Replace hazard switch. Refer to [EXL-276, "Removal and Installation"](#).
- NO >> Repair or replace harness.

# TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## TURN SIGNAL LAMP CIRCUIT

### Description

INFOID:000000010350551

The BCM monitors inputs from the combination switch (lighting and turn signal switch) to determine when to activate the turn signals. The BCM outputs voltage direction to the left and right turn signals during turn signal operation or both during hazard warning operation. The BCM sends a turn signal indicator request to the combination meter via the CAN communication lines.

The BCM performs the fast flasher operation (fail-safe) if any bulb or harness of the turn signal lamp circuit is open.

#### NOTE:

Turn signal lamp blinks at normal speed when using the hazard warning lamp.

### Component Function Check

INFOID:000000010350552

#### 1. CHECK TURN SIGNAL LAMP

##### CONSULT

1. Select FLASHER of BCM (FLASHER) active test item.
2. While operating the test items, check that the turn signal lamp blinks.

- LH** : Turn signal lamps (LH) ON
- RH** : Turn signal lamps (RH) ON
- Off** : Turn signal lamps OFF

#### Is the inspection result normal?

- YES >> Turn signal lamp circuit is normal.
- NO >> Refer to [EXL-231, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010350553

Regarding Wiring Diagram information, refer to [EXL-185, "Wiring Diagram"](#).

#### 1. CHECK TURN SIGNAL LAMP BULB

Check the applicable lamp bulb to be sure the proper bulb standard is in use and the bulb is not open.

#### Is the bulb OK?

- YES >> GO TO 2.
- NO >> Replace the bulb.

#### 2. CHECK TURN SIGNAL LAMP OUTPUT VOLTAGE


1. Turn the ignition switch OFF.
2. Disconnect the front combination lamp harness connector or the side turn signal harness connector or the rear combination lamp harness connector in question.
3. Turn the ignition switch ON.
4. Operate the turn signal switch.
5. While the turn signal is operating, check the voltage between the front combination lamp harness connector and ground.

(+)		(-)	Voltage (Approx.)
Connector	Terminal		


# TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

LH	E105	1	Ground	 <p style="text-align: right; font-size: small;">PKID0926E</p>
RH	E103			

6. While the turn signal is operating, check the voltage between the rear combination lamp harness connector and ground.

(+)		Terminal	(-)	Voltage (Approx.)
Connector				
LH	B90	3	Ground	 <p style="text-align: right; font-size: small;">PKID0926E</p>
RH	B102			

Are the inspection results normal?

YES >> GO TO 5.

NO >> GO TO 3.

### 3. CHECK TURN SIGNAL LAMP CIRCUIT FOR OPEN

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector E29 or B23.
3. Check continuity between the BCM harness connector E29 and the front combination lamp harness connector.

BCM			Front combination lamp		Continuity
Connector	Terminal		Connector	Terminal	
LH	E29	135	E105	1	Yes
RH		136	E103		

4. Check continuity between the BCM harness connector B23 and the rear combination lamp harness connector.

BCM			Rear combination lamp		Continuity
Connector	Terminal		Connector	Terminal	
LH	B23	157	B90	3	Yes
RH		160	B102		

Are the inspection results normal?

YES >> GO TO 4.

NO >> Repair or replace the harness or connectors.

### 4. CHECK TURN SIGNAL LAMP SHORT CIRCUIT

1. Check continuity between the BCM harness connector E29 and ground.



# TURN SIGNAL LAMP CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

BCM			Ground	Continuity
Connector		Terminal		No
LH	E29	135		
RH		136		

2. Check continuity between the BCM harness connector M20 and ground.

BCM			Ground	Continuity
Connector		Terminal		No
LH	B23	157		
RH		160		

Are the inspection results normal?

YES >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key).

NO >> Repair or replace the harness or connectors.

## 5. CHECK TURN SIGNAL LAMP GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check continuity between the front combination lamp harness connector or the side turn signal harness connector or the rear combination lamp harness connector in question and ground.

Front combination lamp			(-)	Continuity
Connector		Terminal		
LH	E105	2	Ground	Yes
RH	E103			

3. Check continuity between the rear combination lamp harness connector and ground.

Rear combination lamp			(-)	Continuity
Connector		Terminal		
LH	B90	4	Ground	Yes
RH	B102			

Are the inspection results normal?

YES >> Replace the malfunctioning lamp.

NO >> Repair or replace the harness or connectors.

# B121A FRONT FOG LAMP LH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B121A FRONT FOG LAMP LH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010376092

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B121A	FR FOG LAMP LH PWR SPLY CIRC [CIRC SHORT TO GROUND]	• Short to ground	• IPDM E/R • Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

#### Is DTC B121A detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-234, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376093

#### 1. CHECK FOG LAMP SHORT CIRCUIT TO GROUND

1. Disconnect fog lamp connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
LH	E217		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness.

#### 2. CHECK FOG LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.
2. Check continuity between fog lamp harness connector and ground.

Fog lamp (LH)		Ground	Continuity
Connector	Terminal		
LH	E222		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
 NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B1231 DAYTIME RUNNING LIGHT RH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B1231 DAYTIME RUNNING LIGHT RH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010376094

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B1231	DTRL RH PWR SPLY CIRC [CIRC SHORT TO GRND]	When a short circuit to ground in the daytime running lamp circuit is detected.	<ul style="list-style-type: none"> <li>IPDM E/R</li> <li>Short to ground</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSTIC RESULT

 With CONSULT.

1. Turn ignition switch ON.

2. Perform self-diagnostic result.

#### Is DTC B1231 detected?

YES >> Proceed to diagnosis procedure. Refer to [EXL-235, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376095

#### 1.CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connector and IPDM E/R connector.

2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E218		No

#### Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

#### 2.CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.

2. Check continuity between front combination lamp harness connector and ground.

Front combination lamp (RH)		Ground	Continuity
Connector	Terminal		
RH	E240		No

#### Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B1256 FRONT FOG LAMP RH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B1256 FRONT FOG LAMP RH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010376096

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B1256	FR FOG LAMP RH PWR SPLY CIRC [CIRC SHORT TO GRND]	When a short circuit to ground is detected.	<ul style="list-style-type: none"><li>IPDM E/R</li><li>Short to ground</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

- Turn ignition switch ON.
- Perform self-diagnostic result.

#### Is DTC B1256 detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-236, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376097

#### 1. CHECK FOG LAMP SHORT CIRCUIT TO GROUND

- Disconnect fog lamp connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
LH	E217		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness.

#### 2. CHECK FOG LAMP SHORT CIRCUIT TO GROUND

- Reconnect IPDM E/R connector.
- Check continuity between fog lamp harness connector and ground.

Fog lamp (LH)		Ground	Continuity
Connector	Terminal		
LH	E222		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B1C00 HEIGHT SENSOR POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B1C00 HEIGHT SENSOR POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010376098

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B1C00	HEIGHT SENSOR PWR SPLY CIRC [CIRC SHORT TO GRND]	When the height sensor power supply circuit is shorted to supply power or shorted to ground	<ul style="list-style-type: none"> <li>Short to ground</li> <li>Short to supply voltage</li> </ul>
	HEIGHT SENSOR PWR SPLY CIRC [CIRC SHORT TO BATTERY]		

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

ⓑ With CONSULT.

- Turn ignition switch ON.
- Perform self-diagnostic result.

Is DTC B1C00 detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-237, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376099

#### 1. CHECK HEIGHT SENSOR SHORT CIRCUIT TO GROUND

- Disconnect front and rear height sensor connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E120	25		No

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness.

#### 2. CHECK HEIGHT SENSOR SHORT CIRCUIT TO BATTERY VOLTAGE

Check the voltage between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E120	25		0 V

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

#### 3. CHECK HEIGHT SENSOR SHORT CIRCUIT TO BATTERY VOLTAGE

- Reconnect IPDM E/R connector.
- Check the voltage between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E120	25		0 V

Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).

## B1C00 HEIGHT SENSOR POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

---

NO >> Replace IPDM E/R. Refer to [PCS-35. "Removal and Installation"](#).

# B1C01 FRONT HEIGHT SENSOR SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B1C01 FRONT HEIGHT SENSOR SIGNAL

### DTC Logic

INFOID:000000010376100

### DTC DETECTION LOGIC

DTC No.	Self-diagnosis item	DTC Detection Condition	Possible causes
B1C01	FR HEIGHT SENSOR SIGNAL [CIRC SHORT TO BATTERY]	<ul style="list-style-type: none"> <li>Short to ground</li> <li>Short to supply voltage</li> <li>Circuit voltage out of range</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connectors between the front height sensor and the IPDM E/R (The sensor circuit is open or shorted)</li> <li>IPDM E/R</li> <li>Height sensor</li> </ul>
	FR HEIGHT SENSOR SIGNAL [CIRC SHORT TO GROUND OR OPEN]		
	FR HEIGHT SENSOR SIGNAL [CIRC VOLTAGE OUT OF RANGE]		

### DTC CONFIRMATION PROCEDURE

#### 1. SELF-DIAGNOSIS WITH IPDM E/R

- Turn ignition switch ON.
- Check Self-diagnostic result with CONSULT.

Is DTC detected?

- YES >> Refer to [EXL-239, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376101

#### 1. CHECK HEIGHT SENSOR SHORT CIRCUIT TO GROUND

- Disconnect front height sensor connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E120	20		No

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness.

#### 2. CHECK HEIGHT SENSOR SHORT OPEN CIRCUIT

Check the continuity between IPDM E/R harness connector and height sensor connector.

IPDM E/R		Front height sensor		Ground	Continuity
Connector	Terminal	Connector	Terminal		
E120	20	E110	1		Yes

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

#### 3. CHECK HEIGHT SENSOR SHORT CIRCUIT TO BATTERY VOLTAGE

Check the voltage between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E120	20		0 V

Is the inspection result normal?

## B1C01 FRONT HEIGHT SENSOR SIGNAL

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.  
NO >> Repair or replace harness.

### 4. CHECK HEIGHT SENSOR SHORT CIRCUIT TO BATTERY VOLTAGE

1. Reconnect IPDM E/R connector.
2. Check the voltage between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E120	20		0 V

Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).



# B1C02 REAR HEIGHT SENSOR SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B1C02 REAR HEIGHT SENSOR SIGNAL

### DTC Logic

INFOID:000000010376102

### DTC DETECTION LOGIC

DTC No.	Self-diagnosis item	DTC Detection Condition	Possible causes
B1C02	RR HEIGHT SENSOR SIGNAL [CIRC SHORT TO BATTERY]	<ul style="list-style-type: none"> <li>Short to ground</li> <li>Short to supply voltage</li> <li>Circuit voltage out of range</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connectors between the rear height sensor and the IPDM E/R (The sensor circuit is open or shorted)</li> <li>IPDM E/R</li> <li>Height sensor</li> </ul>
	RR HEIGHT SENSOR SIGNAL [CIRC SHORT TO GROUND OR OPEN]		
	RR HEIGHT SENSOR SIGNAL [CIRC VOLTAGE OUT OF RANGE]		

### DTC CONFIRMATION PROCEDURE

#### 1. SELF-DIAGNOSIS WITH IPDM E/R

- Turn ignition switch ON.
- Check Self-diagnostic result with CONSULT.

Is DTC detected?

- YES >> Refer to [EXL-241, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376103

#### 1. CHECK HEIGHT SENSOR SHORT CIRCUIT TO GROUND

- Disconnect rear height sensor connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E120	21		No

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness.

#### 2. CHECK HEIGHT SENSOR SHORT OPEN CIRCUIT

Check the continuity between IPDM E/R harness connector and height sensor connector.

IPDM E/R		Rear height sensor		Ground	Continuity
Connector	Terminal	Connector	Terminal		
E120	20	B91	1		Yes

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

#### 3. CHECK HEIGHT SENSOR SHORT CIRCUIT TO BATTERY VOLTAGE

Check the voltage between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E120	21		0 V

Is the inspection result normal?

## B1C02 REAR HEIGHT SENSOR SIGNAL

[LED HEADLAMP]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.  
NO >> Repair or replace harness.

### 4. CHECK HEIGHT SENSOR SHORT CIRCUIT TO BATTERY VOLTAGE

1. Reconnect IPDM E/R connector.
2. Check the voltage between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E120	21		0 V

Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B1C07 AIMING MOTOR DRIVE SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B1C07 AIMING MOTOR DRIVE SIGNAL

### DTC Logic

INFOID:000000010376104

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B1C07	AIMING MOTOR DRIVE SIGNAL [CIRC SHORT TO GRND]	<ul style="list-style-type: none"> <li>DC motor circuit short to ground</li> <li>DC motor circuit short to supply voltage</li> </ul>	<ul style="list-style-type: none"> <li>Front combination lamp harness</li> <li>IPDM E/R</li> </ul>
	AIMING MOTOR DRIVE SIGNAL [CIRC SHORT TO BATTERY]		
	AIMING MOTOR DRIVE SIGNAL [SIGNAL COMPARE FAILURE]		

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

- Turn ignition switch ON.
- Perform self-diagnostic result.

Is DTC B1C07 detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-243, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376105

#### 1. CHECK HEADLAMP AIMING MOTOR DRIVE SIGNAL SHORT CIRCUIT TO GROUND

- Disconnect LH and RH headlamp aiming motor connectors and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E218	64		No

Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness.

#### 2. CHECK HEADLAMP AIMING MOTOR DRIVE SIGNAL SHORT CIRCUIT TO BATTERY VOLTAGE

Check the voltage between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E218	64		0 V

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness.

#### 3. CHECK HEADLAMP AIMING MOTOR DRIVE SIGNAL SHORT CIRCUIT TO BATTERY VOLTAGE

- Reconnect IPDM E/R connector.
- Check the voltage between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Voltage (Approx.)
Connector	Terminal		
E218	64		0 V

## B1C07 AIMING MOTOR DRIVE SIGNAL

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

---

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20CB DAYTIME RUNNING LIGHT LH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B20CB DAYTIME RUNNING LIGHT LH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010376106

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20CB	DTRL LH PWR SPLY CIRC [CIRC SHORT TO GRND]	When a short circuit to ground is detected.	<ul style="list-style-type: none"><li>IPDM E/R</li><li>Short to ground</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch ON.

2. Perform self-diagnostic result.

Is DTC B02CB detected?

YES >> Proceed to diagnosis procedure. Refer to [EXL-245, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376107

#### 1. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connector and IPDM E/R connector.

2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
LH	E217		No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

#### 2. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.

2. Check continuity between fog lamp harness connector and ground.

Front combination lamp (LH)		Ground	Continuity
Connector	Terminal		
LH	E239		No

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20CE HEADLAMP (HI) LH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B20CE HEADLAMP (HI) LH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010376108

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20CE	DTRL LH PWR SPLY CIRC [CIRC SHORT TO GRND]	• Short to ground	• IPDM E/R • Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

 With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

#### Is DTC B20CE detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-246, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376109

#### 1. CHECK HEAD LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
LH	E218		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness.

#### 2. CHECK HEAD LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.
2. Check continuity between front combination lamp harness connector and ground.

Front combination lamp (LH)		Ground	Continuity
Connector	Terminal		
LH	E236		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20CF HEADLAMP (HI) RH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B20CF HEADLAMP (HI) RH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:0000000010376110

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20CF	HL (HI) RH PWR SPLY CIRC [CIRC SHORT TO GRND]	• Short to ground	• IPDM E/R • Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSTIC RESULT

 With CONSULT.

1. Turn ignition switch ON.

2. Perform self-diagnostic result.

Is DTC B20CF detected?

YES >> Proceed to diagnosis procedure. Refer to [EXL-247, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000010376111

#### 1.CHECK HEAD LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connector and IPDM E/R connector.

2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R			Ground	Continuity
Connector		Terminal		
RH	E217	54		No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

#### 2.CHECK HEAD LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.

2. Check continuity between front combination lamp harness connector and ground.

Front combination lamp (RH)			Ground	Continuity
Connector		Terminal		
RH	E240	5		No

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20D0 HEADLAMP (LO) LH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B20D0 HEADLAMP (LO) LH POWER SUPPLY CIRCUIT

### DTC Logic


INFOID:000000010376112

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20D0	HI (LO) RH PWR SPLY CIRC [CIRC SHORT TO GRND]	• Short to ground	• IPDM E/R • Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

 With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

#### Is DTC B20D0 detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-248, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376113

#### 1. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
LH	E217		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness.

#### 2. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.
2. Check continuity between front combination lamp harness connector and ground.

Front combination lamp (LH)		Ground	Continuity
Connector	Terminal		
LH	E239		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).



# B20D1 HEADLAMP (LO) RH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B20D1 HEADLAMP (LO) RH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:0000000010376114

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20D1	HL (LO) RH PWR SPLY CIRC [CIRC SHORT TO GRND]	• Short to ground	• IPDM E/R • Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

 With CONSULT.

1. Turn ignition switch ON.

2. Perform self-diagnostic result.

Is DTC B20D1 detected?

YES >> Proceed to diagnosis procedure. Refer to [EXL-249, "Diagnosis Procedure"](#).

NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000010376115

#### 1. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connector and IPDM E/R connector.

2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E218		No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness.

#### 2. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.

2. Check continuity between front combination lamp harness connector and ground.

Front combination lamp (LH)		Ground	Continuity
Connector	Terminal		
RH	E240		No

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20D2 PARKING LAMP POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B20D2 PARKING LAMP POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010376116

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20D2	PARKING LAMP PWR SPLY CIRC [CIRC SHORT TO GROUND]	When a short to ground is detected in the parking lamp power supply circuit.	• Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

1. Turn ignition switch ON.
2. Perform self-diagnostic result.

Is DTC B20D2 detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-250, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376117

#### 1. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp connectors and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R			Ground	Continuity
Connector		Terminal		
LH		E217	No	
RH		E218		

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness.

#### 2. CHECK FRONT COMBINATION LAMP SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.
2. Check continuity between front combination lamp harness connector and ground.

IPDM E/R			Ground	Continuity
Connector		Terminal		
LH		E217	No	
RH		E218		

Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20D4 TAIL LAMP LH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B20D4 TAIL LAMP LH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:0000000010376118

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20D4	TAIL LAMP LH PWR SPLY CIRC [CIRC SHORT TO GRND]	• Short to ground	• IPDM E/R • Short to ground

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

- Turn ignition switch ON.
- Perform self-diagnostic result.

#### Is DTC B20D4 detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-251, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000010376119

#### 1. CHECK TAIL LAMP SHORT CIRCUIT TO GROUND

- Disconnect rear combination lamp (LH), license plate lamps, back up lamp connectors and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
LH	E119		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness.

#### 2. CHECK TAIL LAMP SHORT CIRCUIT TO GROUND

- Reconnect IPDM E/R connector.
- Check continuity between rear combination lamp harness connector and ground.

Rear combination lamp (LH)		Ground	Continuity
Connector	Terminal		
LH	B90		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
 NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20D5 TAIL LAMP RH POWER SUPPLY CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B20D5 TAIL LAMP RH POWER SUPPLY CIRCUIT

### DTC Logic

INFOID:000000010376120

### DTC DETECTION LOGIC

DTC	Display Item	Malfunction detected condition	Possible causes
B20D5	TAIL LAMP RH PWR SPLY CIRC [CIRC SHORT TO GRND]	When a short circuit to ground is detected in the tail lamp supply voltage circuit.	<ul style="list-style-type: none"><li>IPDM E/R</li><li>Short to ground</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF-DIAGNOSTIC RESULT

Ⓜ With CONSULT.

- Turn ignition switch ON.
- Perform self-diagnostic result.

#### Is DTC B20D5 detected?

- YES >> Proceed to diagnosis procedure. Refer to [EXL-252, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376121

#### 1. CHECK TAIL LAMP SHORT CIRCUIT TO GROUND

- Disconnect rear combination lamp (RH), back up lamp connectors and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
RH	E119		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness.

#### 2. CHECK TAIL LAMP SHORT CIRCUIT TO GROUND

- Reconnect IPDM E/R connector.
- Check continuity between rear combination lamp harness connector and ground.

Rear combination lamp (RH)		Ground	Continuity
Connector	Terminal		
RH	B102		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20DB HEIGHT SENSOR INITIALIZE NOT DONE

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B20DB HEIGHT SENSOR INITIALIZE NOT DONE

### DTC Logic

INFOID:000000010376122

### DTC DETECTION LOGIC

DTC	Display Item	DTC detection condition	Possible causes
B20DB	HEIGHT SENS INITIALIZE NOT DONE [MISSING CALIBRATION]	Sensor initialization is not complete.	<ul style="list-style-type: none"><li>• Incomplete sensor initialization.</li><li>• Rear height sensor</li><li>• Front height sensor</li></ul>
	HEIGHT SENS INITIALIZE NOT DONE [NOT CONFIGURED]		

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM SELF-DIAGNOSIS

##### CONSULT

1. Turn ignition switch ON.
2. Perform self-diagnosis of IPDM E/R using CONSULT.

##### Is DTC B20DB detected?

- YES >> Refer to [EXL-253, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010376123

#### 1.CHECK SELF-DIAGNOSTIC RESULT

##### With CONSULT.

1. Turn ignition ON.
2. Select "SENSOR INITIALIZE" of IPDM E/R Work Support item.

##### Is DTC B20DB detected?

- YES >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).  
NO >> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K

EXL

# B20E2 LED HEADLAMP RH

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B20E2 LED HEADLAMP RH

### DTC Logic

INFOID:000000010350724

### DTC DETECTION LOGIC

DTC No.	Self-diagnosis item	DTC Detection Condition	Possible causes
B20E2	LED HEADLAMP RH [CMPNENT INTERNAL MLFNCTN]	• Detection signal circuit short to ground	• Harness or connectors between the front combination lamp RH and the IPDM E/R • IPDM E/R

### DTC CONFIRMATION PROCEDURE

#### 1.SELF-DIAGNOSIS WITH IPDM E/R

1. Turn ignition switch ON.
2. Check Self-diagnostic result with CONSULT.

#### Is DTC detected?

- YES >> Refer to [EXL-254, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010350725

#### 1.CHECK FRONT COMBINATION LAMP RH SHORT CIRCUIT TO GROUND

1. Disconnect front combination lamp RH connector and IPDM E/R connector.
2. Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E218	60		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness.

#### 2.CHECK FRONT COMBINATION LAMP RH SHORT CIRCUIT TO GROUND

1. Reconnect IPDM E/R connector.
2. Check continuity between front combination lamp RH harness connector and ground.

Front combination lamp RH		Ground	Ground
Connector	Terminal		
E240	7		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# B20E3 LED HEADLAMP LH

< DTC/CIRCUIT DIAGNOSIS >

[LED HEADLAMP]

## B20E3 LED HEADLAMP LH

### DTC Logic

INFOID:000000010350728

### DTC DETECTION LOGIC

DTC No.	Self-diagnosis item	DTC Detection Condition	Possible causes
B20E3	LED HEADLAMP LH [CMPNENT INTERNAL MLFNCTN]	<ul style="list-style-type: none"> <li>Detection signal circuit short to ground</li> </ul>	<ul style="list-style-type: none"> <li>Harness or connectors between the front combination lamp LH and the IPDM E/R</li> <li>IPDM E/R</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. SELF-DIAGNOSIS WITH IPDM E/R

- Turn ignition switch ON.
- Check Self-diagnostic result with CONSULT.

#### Is DTC detected?

- YES >> Refer to [EXL-255, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010350729

#### 1. CHECK FRONT COMBINATION LAMP LH SHORT CIRCUIT TO GROUND

- Disconnect front combination lamp LH connector and IPDM E/R connector.
- Check continuity between IPDM E/R harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
E217	53		No

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness.

#### 2. CHECK FRONT COMBINATION LAMP LH SHORT CIRCUIT TO GROUND

- Reconnect IPDM E/R connector.
- Check continuity between front combination lamp LH harness connector and ground.

Front combination lamp LH		Ground	Ground
Connector	Terminal		
E239	7		No

#### Is the inspection result normal?

- YES >> Refer to [GI-41, "Intermittent Incident"](#).  
 NO >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

## SYMPTOM DIAGNOSIS

### EXTERIOR LIGHTING SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000010350643

**CAUTION:**

Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item
Headlamp (HI) is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• LED</li> <li>• Harness between IPDM E/R and headlamp (HI)</li> <li>• Harness between headlamp (HI) and ground</li> <li>• IPDM E/R</li> </ul>	Headlamp (HI) circuit Refer to <a href="#">EXL-246, "DTC Logic"</a> (LH) or <a href="#">EXL-247, "DTC Logic"</a> (RH).
	Both sides	<p><b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON" Refer to <a href="#">EXL-246, "DTC Logic"</a> (LH) or <a href="#">EXL-247, "DTC Logic"</a> (RH).</p>	
High beam indicator lamp is not turned ON. [Headlamp (HI) is turned ON.]		Combination meter	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Data monitor "HI-BEAM IND"</li> <li>• BCM (HEAD LAMP)</li> <li>• Active test "HEADLAMP"</li> </ul>
Headlamp (LO) is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• LED</li> <li>• Harness between IPDM E/R and headlamp lamp (LO)</li> <li>• Harness between headlamp (LO) and ground</li> <li>• IPDM E/R</li> </ul>	Headlamp (LO) circuit Refer to <a href="#">EXL-248, "DTC Logic"</a> (LH) or <a href="#">EXL-249, "DTC Logic"</a> (RH).
	Both sides	<p><b>Symptom diagnosis</b> "BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON" Refer to <a href="#">EXL-248, "DTC Logic"</a> (LH) or <a href="#">EXL-249, "DTC Logic"</a> (RH).</p>	
Each lamp is not turned ON/OFF with lighting switch AUTO.		<ul style="list-style-type: none"> <li>• Combination switch</li> <li>• Harness between combination switch and BCM</li> <li>• BCM</li> </ul>	Combination switch Refer to <a href="#">BCS-73, "Symptom Table"</a> (with Intelligent Key) or <a href="#">BCS-133, "Symptom Table"</a> (without Intelligent Key).
		<ul style="list-style-type: none"> <li>• Optical sensor</li> <li>• Harness between optical sensor and BCM</li> <li>• BCM</li> </ul>	Optical sensor Refer to <a href="#">EXL-226, "Component Function Check"</a> .
Daytime running light is not turned ON. [Headlamp (HI) is turned ON.]		<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Harness between IPDM E/R and front combination lamp</li> <li>• IPDM E/R</li> <li>• BCM</li> <li>• ECM</li> <li>• Combination meter</li> </ul>	<ul style="list-style-type: none"> <li>• Daytime running light circuit Refer to <a href="#">EXL-235, "DTC Logic"</a>.</li> <li>• BCM (HEADLAMP)</li> <li>• Data monitor "ENGINE STATE"</li> <li>• Combination meter</li> <li>• Data monitor "PKB SW"</li> <li>• BCM (HEADLAMP)</li> <li>• Active test "DAYTIME RUNNING LIGHT"</li> </ul>
Parking lamp is not turned ON.		<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Parking lamp bulb</li> <li>• Harness between IPDM E/R and front combination lamp</li> <li>• IPDM E/R</li> </ul>	Parking lamp circuit Refer to <a href="#">EXL-250, "DTC Logic"</a> .



# EXTERIOR LIGHTING SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

Symptom	Possible cause	Inspection item
Front side marker lamp is not turned ON.	<ul style="list-style-type: none"> <li>• Front side marker lamp bulb</li> <li>• Harness between IPDM E/R and front side marker lamp</li> <li>• Harness between front side marker lamp and ground</li> <li>• IPDM E/R</li> </ul>	Front side marker lamp circuit Refer to <a href="#">EXL-250, "DTC Logic"</a> .
License plate lamp is not turned ON.	<ul style="list-style-type: none"> <li>• License plate lamp bulb</li> <li>• Harness between IPDM E/R and license plate lamp</li> <li>• Harness between license plate lamp and ground</li> </ul>	License plate lamp circuit Refer to <a href="#">EXL-251, "DTC Logic"</a> .
Parking lamp, side marker lamp, tail lamp and license plate lamp are not turned ON.	<b>Symptom diagnosis</b> "PARKING, SIDE MARKER, LICENSE PLATE AND TAIL LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-261, "Description"</a> .	
Tail lamp indicator is not turned ON. (Exterior lamps are turned ON.)	Combination meter	<ul style="list-style-type: none"> <li>• Combination meter Data monitor "LIGHT IND"</li> <li>• BCM (HEADLAMP) Active test "TAIL LAMP"</li> </ul>
Turn signal lamp does not blink.	Indicator lamp is normal. (Applicable side performs high flasher activation.)	<ul style="list-style-type: none"> <li>• Turn signal lamp bulb</li> <li>• Door mirror</li> <li>• Harness between BCM and each turn signal lamp</li> <li>• Harness between each turn signal lamp and ground</li> </ul> Turn signal lamp circuit Refer to <a href="#">EXL-93, "Component Function Check"</a> .
Turn signal indicator lamp does not blink. (Turn signal lamp is normal.)	One side	Combination meter  —
	Both sides (Always)	<ul style="list-style-type: none"> <li>• Turn signal indicator lamp signal</li> <li>• BCM</li> <li>• Combination meter</li> </ul> • Combination meter Data monitor "TURN IND" • BCM (FLASHER) Active test "FLASHER"
	Both sides (Only when activating hazard warning lamp with ignition switch OFF)	<ul style="list-style-type: none"> <li>• Combination meter power supply and ground circuit</li> <li>• Combination meter</li> </ul> Combination meter Power supply and ground circuit Refer to <a href="#">MWI-59, "COMBINATION METER : Diagnosis Procedure"</a> .
<ul style="list-style-type: none"> <li>• Hazard warning lamp does not activate.</li> <li>• Hazard warning lamp continues activating. (Turn signal is normal.)</li> </ul>	<ul style="list-style-type: none"> <li>• Hazard switch</li> <li>• Harness between hazard switch and BCM</li> <li>• Harness between hazard switch and ground</li> <li>• BCM</li> </ul>	Hazard switch circuit Refer to <a href="#">EXL-229, "Component Function Check"</a> .
Front fog lamp is not turned ON.	One side	<ul style="list-style-type: none"> <li>• Front fog lamp bulb</li> <li>• Harness between IPDM E/R and front fog lamp</li> <li>• Harness between front fog lamp and ground</li> <li>• IPDM E/R</li> </ul> Front fog lamp circuit Refer to <a href="#">EXL-234, "DTC Logic"</a> (LH) or <a href="#">EXL-236, "DTC Logic"</a> (RH).
	Both sides	<b>Symptom diagnosis</b> "BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON" Refer to <a href="#">EXL-234, "DTC Logic"</a> (LH) or <a href="#">EXL-236, "DTC Logic"</a> (RH).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
M  
N  
O  
P

EXL

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

---

### NORMAL OPERATING CONDITION

#### Description

*INFOID:000000010350644*

#### AUTO LIGHT SYSTEM

The headlamp may not be turned ON/OFF immediately after passing dark area or bright area (short tunnel, sky bridge, shadowed area, etc.) while using the auto light system. This is caused by for the control difference. This is normal.

# BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

## BOTH SIDE HEADLAMPS (HI) ARE NOT TURNED ON

### Description

INFOID:000000010350645

Both side headlamps (HI) are not turned ON when setting to the lighting switch HI or PASS.

### Diagnosis Procedure

INFOID:000000010350646

#### 1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-73, "Symptom Table"](#) (with Intelligent Key system) or [BCS-133, "Symptom Table"](#) (without Intelligent Key system).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK HEADLAMP (HI) REQUEST SIGNAL INPUT

##### CONSULT DATA MONITOR

1. Select "HEADLAMP (HI)" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition		Monitor status
HEADLAMP (HI)	Lighting switch (2ND)	HI or PASS	On
		LO	Off

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key system) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key system).

#### 3.HEADLAMP (HI) CIRCUIT INSPECTION

Check headlamp (HI) circuit. Refer to [EXL-246, "DTC Logic"](#) (LH) or [EXL-247, "DTC Logic"](#) (RH).

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning part.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

## BOTH SIDE HEADLAMPS (LO) ARE NOT TURNED ON

### Description

INFOID:000000010350647

Both side headlamps (LO) are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000010350648

#### 1. CHECK COMBINATION SWITCH

Check combination switch. Refer to [BCS-73, "Symptom Table"](#) (with Intelligent Key system) or [BCS-133, "Symptom Table"](#) (without Intelligent Key system).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2. CHECK HEADLAMP (LO) REQUEST SIGNAL INPUT

##### CONSULT DATA MONITOR

1. Select "HEADLAMP (LO)" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status
HEADLAMP (LO)	Lighting switch	2ND
		OFF
		On
		Off

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key system) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key system).

#### 3. HEADLAMP (LO) CIRCUIT INSPECTION

Check headlamp (LO) circuit. Refer to [EXL-248, "DTC Logic"](#) (LH) or [EXL-249, "DTC Logic"](#) (RH).

Is the inspection result normal?

YES >> Refer to [GI-41, "Intermittent Incident"](#).

NO >> Repair or replace the malfunctioning part.

# PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

## PARKING, LICENSE PLATE, SIDE MARKER AND TAIL LAMPS ARE NOT TURNED ON

### Description

INFOID:000000010350649

The parking, license plate, side marker, tail lamps and each illumination are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000010350650

#### 1.COMBINATION SWITCH INSPECTION

Check combination switch. Refer to [BCS-73, "Symptom Table"](#) (with Intelligent Key system) or [BCS-133, "Symptom Table"](#) (without Intelligent Key system).

Is the combination switch normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning part.

#### 2.CHECK TAIL LAMP REQUEST SIGNAL INPUT

##### CONSULT DATA MONITOR

1. Select "TAIL LAMP" of IPDM E/R data monitor item.
2. With operating the lighting switch, check the monitor status.

Monitor item	Condition	Monitor status	
TAIL LAMP	Lighting switch	1ST	On
		OFF	Off

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key system) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key system).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

< SYMPTOM DIAGNOSIS >

[LED HEADLAMP]

## BOTH SIDE FRONT FOG LAMPS ARE NOT TURNED ON

### Description

INFOID:000000010350651

The front fog lamps are not turned ON in any condition.

### Diagnosis Procedure

INFOID:000000010350652

#### 1. CHECK COMBINATION SWITCH

Check combination switch. Refer to [BCS-73, "Symptom Table"](#) (with Intelligent Key) or [BCS-133, "Symptom Table"](#) (without Intelligent Key).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning part.

#### 2. CHECK FRONT FOG LAMP REQUEST SIGNAL INPUT

##### ④ CONSULT DATA MONITOR

1. Select "FRONT FOG LAMP REQ" of IPDM E/R data monitor item.
2. With operating the front fog lamp switch, check the monitor status.

Monitor item	Condition	Monitor status
FRONT FOG LAMP REQ	Front fog lamp switch (With lighting switch 2ND)	ON
		OFF
		On
		Off

Is the item status normal?

YES >> Replace IPDM E/R. Refer to [PCS-35, "Removal and Installation"](#).

NO >> Replace BCM. Refer to [BCS-75, "Removal and Installation"](#) (with Intelligent Key) or [BCS-135, "Removal and Installation"](#) (without Intelligent Key).

# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[LED HEADLAMP]

## PERIODIC MAINTENANCE

### HEADLAMP AIMING ADJUSTMENT

#### Inspection

INFOID:0000000010247821

#### PREPARATION BEFORE ADJUSTING

Before performing aiming adjustment, check the following:

- Make sure all tires are inflated to correct pressure.
- Place vehicle and screen on level surface.
- Make sure there is no load in vehicle other than the driver (or equivalent weight placed in driver's position).
- Coolant and engine oil filled to correct level, and fuel tank full.
- Remove cargo and/or luggage to maintain an unloaded vehicle condition.
- Confirm spare tire, jack and tools are properly stowed.
- Carefully wipe off any dirt from headlamp lens.

#### CAUTION:


**Do not use organic solvent (thinner, gasoline etc.)**

- Place a driver or equivalent weight of 68.5 kg (150 lb) on the driver seat.
- By hand, bounce the front and rear of the vehicle to settle the suspension and eliminate any static load.
- Place the front tires in the straight ahead position.
- Aim each headlamp individually and ensure other headlamp beam pattern is blocked from screen.

#### NOTE:

- For headlamp aiming details, refer to regulations in your area.
- By regulation, no means for horizontal aim adjustment is provided from the factory; only vertical aim is adjustable.
- Use adjusting screw to perform aiming adjustment.
- Perform headlamp aiming if:
  - The vehicle front body has been repaired;
  - The front combination lamp has been removed or replaced;
  - Any outfitting has been installed;
  - The vehicle's standard load condition has been substantially increased.

#### AIMING ADJUSTMENT SCREW



1. Front combination lamp  
(view from rear)

A. Headlamp HI/LO (UP/DOWN)  
adjustment screw

# HEADLAMP AIMING ADJUSTMENT


< PERIODIC MAINTENANCE >

[LED HEADLAMP]

## Aiming Adjustment Procedure

INFOID:000000010247822

Aiming Chart



AWLIA2314ZZ

- |   |   |   |
|---|---|---|
| 1. Adjustment screen  | A. Highest cutoff line height                                     | B. Lowest cutoff line height  |
| C. Headlamp bulb center (H-V point)   | D. Distance of headlamp aiming screen from vehicle 7.62 m (25 ft) | E. Maximum aim evaluation distance from vertical center on aiming screen 399 mm (3°R) |
| F. Minimum aim evaluation distance from vertical center on aiming screen 133 mm (1°R) | G. Aim evaluation area  | H. Horizontal aiming evaluation line  |
| V. Vertical aiming evaluation line  | ↔ Right   |   |

<b>A (Highest cutoff line height)</b>	<b>-13.3 mm (0.5 in)</b>	<b>0.1° up</b>
<b>B (Lowest cutoff line height)</b>	<b>53.2 mm (2.1 in)</b>	<b>0.4° down</b>

### LOW BEAM AND HIGH BEAM

#### NOTE:

- Basic illuminating area for evaluation and/or adjustment should be within range shown on aiming chart.

- Use adjustment screw to perform aiming adjustment.
  - Ensure fog lamps are turned off.
- Block the opposite headlamp from projecting a beam pattern onto the adjustment screen, using a suitable object. Aim each headlamp individually.

#### CAUTION:

**Do not cover the lens surface with a tape etc. The lens is made of resin.**

- Place the screen on the same level and flat surface as the vehicle.

#### NOTE:

Surface should be free of any debris that would cause a difference between the headlamp center and the adjustment screen.

- Face the front of the vehicle to the screen and measure distance between the headlamp center and the screen surface.



# HEADLAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[LED HEADLAMP]

**Distance between the headlamp center and the screen (D) : 7.62 m (25 ft)**

5. Start the engine. Turn the headlamp on.
6. Determine the preferred vertical aim range dimensions, using the aiming chart.
7. Measure the projected beam within the aim evaluation segment on the screen.
8. Adjust the beam pattern of each headlamp until the aim evaluation segment (the area relative to both the highest and lowest cutoff line height) is positioned within the vertical aim range dimensions shown on the aiming chart.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >


[LED HEADLAMP]

## FRONT FOG LAMP AIMING ADJUSTMENT

### Aiming Adjustment Procedure

INFOID:000000010247824

Aiming Chart




- |  |                             |                                      |
|--|-----------------------------|--------------------------------------|
| 1. Vertical center line of fog lamp (LH) | 2. Lamp center above ground | 3. Fog lamp high intensity area (LH) |
| 4. Vertical center line of fog lamp (RH) | 5. Vertical center axis     | A. 100mm (4in)                       |

#### NOTE:

- (LH) Fog lamp aiming specifications shown, (RH) similar.
- Check the following conditions before performing the aiming adjustment.
  - Keep all tires inflated to correct pressure.
  - Place vehicle on level ground.
  - See that vehicle is unloaded (except for full levels of coolant, engine oil and fuel, and spare tire, jack, and tools). Have the driver or equivalent weight placed in driver seat.
  - When performing adjustment, if necessary, cover the headlamps and opposite fog lamp.

1. Set the distance between the screen and the center of the fog lamp lens as shown.

- (1) Aiming screen or a matte white surface
- (2) 7.62 m (25 ft)
- (3) Floor to center of fog lamp lens
- (4) Floor




2. Turn front fog lamps ON.

# FRONT FOG LAMP AIMING ADJUSTMENT

< PERIODIC MAINTENANCE >

[LED HEADLAMP]

3. Access adjusting screw (A) from underneath front bumper fascia. Adjust front fog lamps using adjusting screw so that the top edge of the high intensity zone is at the fog lamp centers above ground.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >


[LED HEADLAMP]

## REMOVAL AND INSTALLATION

### FRONT COMBINATION LAMP

Exploded View

INFOID:0000000010247825



1. Front fender

2. Front combination lamp

Clip

## Removal and Installation

INFOID:0000000010247826

### REMOVAL

1. Remove front bumper fascia. Refer to [EXT-17, "Removal and Installation"](#).
2. Remove front combination lamp bolts and clip.
3. Pull front combination lamp forward.
4. Disconnect the harness connectors from the front combination lamp and remove.

### INSTALLATION

Installation is in the reverse order of removal.

#### NOTE:

After installation, perform headlamp aiming adjustment. Refer to [EXL-114, "Inspection"](#).

## Bulb Replacement

INFOID:0000000010247827

### HEADLAMP (LOW BEAM) BULB

The headlamp (low beam) bulb is not serviced separately. Refer to [EXL-119, "Removal and Installation"](#).

### HEADLAMP (HIGH BEAM) BULB

The headlamp (high beam) bulb is not serviced separately. Refer to [EXL-119, "Removal and Installation"](#).

# FRONT COMBINATION LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

## PARKING (SIDE MARKER) LAMP BULB

The parking lamp (side marker) bulb is not serviced separately. Refer to [EXL-119. "Removal and Installation"](#).

## TURN SIGNAL LAMP BULB

### Removal

1. Rotate bulb socket counterclockwise and remove from the front combination lamp.
2. Remove the bulb from bulb socket.

### Installation

Installation is in the reverse order of removal.

### **CAUTION:**

**After installing the bulb, install the bulb socket securely for watertightness.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

EXL

# HEIGHT SENSOR


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

## HEIGHT SENSOR

Exploded View

INFOID:000000010353869



1. Front suspension member

2. Front height sensor

A. Harness connector

Locator

## Removal and Installation - Front Height Sensor

INFOID:000000010335195

### REMOVAL

1. Disconnect the harness connector from the front height sensor.
2. Remove the nuts and the front height sensor.

### INSTALLATION

Installation is in the reverse order of removal.

After installation, perform height sensor initialization. Refer to [EXL-222, "SENSOR INITIALIZE : Description"](#).


# HEIGHT SENSOR

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

## Exploded View

INFOID:000000010353870



1. Rear suspension member

2. Rear height sensor

A. Harness connector

Locator

## Removal and Installation - Rear Height Sensor

INFOID:000000010335196

### REMOVAL

1. Disconnect the harness connector from the rear height sensor.
2. Remove the bolts and rear height sensor.

### INSTALLATION

Installation is in the reverse order of removal.

After installation, perform height sensor initialization. Refer to [EXL-222, "SENSOR INITIALIZE : Description"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# FOG LAMP


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

## FOG LAMP

### Exploded View

INFOID:000000010247829



1. Front bumper fascia

2. Fog lamp

3. Fog lamp bulb

⇐ Front

## Removal and Installation

INFOID:000000010247830

### REMOVAL

1. Partially remove front fender protector. Refer to [EXT-28. "FENDER PROTECTOR : Exploded View"](#).
2. Disconnect the harness connector from the fog lamp.
3. Remove fog lamp bolts and fog lamp.

### INSTALLATION

Installation in the reverse order of removal.

#### NOTE:

After installation, perform fog lamp aiming adjustment. Refer to [EXL-117. "Aiming Adjustment Procedure"](#).

## Bulb Replacement

INFOID:000000010247831

#### WARNING:

Do not touch bulb by hand while it is lit or right after being turned off. Burning may result.

#### CAUTION:

- Do not touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.




# FOG LAMP

[LED HEADLAMP]

## < REMOVAL AND INSTALLATION >

### REMOVAL

1. Partially remove front fender protector. Refer to [EXT-28. "FENDER PROTECTOR : Exploded View"](#).
2. Disconnect the harness connector from the fog lamp (A).
3. Rotate bulb (1) counterclockwise and remove.



### INSTALLATION

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install the bulb socket securely for watertightness.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# OPTICAL SENSOR

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]


## OPTICAL SENSOR

### Removal and Installation

INFOID:000000010335202

#### REMOVAL

1. Release the optical sensor (2) from defroster grille (1) using a suitable tool.
2. Disconnect the harness connector (A) from the optical sensor (2) and remove.



#### INSTALLATION

Installation is in the reverse order of removal.

# COMBINATION SWITCH


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

## COMBINATION SWITCH

Exploded View

INFOID:000000010351324



1. Combination switch

2. Steering column

A. Screw


⇐ Front

## Removal and Installation

INFOID:000000010351325

### REMOVAL

1. Remove the steering angle sensor. Refer to [BRC-139. "Removal and Installation"](#).
2. Disconnect harness connector from combination switch.
3. Remove screw (A) and combination switch (1).



### INSTALLATION

Installation is in the reverse order of removal.

# HAZARD SWITCH


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

## HAZARD SWITCH

Exploded View

INFOID:000000010247834



1. Center ventilator grille

2. Hazard switch

 Pawl

## Removal and Installation

INFOID:000000010247835

### REMOVAL

1. Remove center ventilator grille. Refer to [VTL-13. "CENTER VENTILATOR GRILLE : Removal and Installation"](#).
2. Release the pawls and remove the hazard switch.

### INSTALLATION

Installation is in the reverse order of removal.

# SIDE TURN SIGNAL LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]


## SIDE TURN SIGNAL LAMP

### Removal and Installation

INFOID:000000010365194

#### REMOVAL

1. Remove door mirror rear finisher. Refer to [MIR-25, "Removal and Installation"](#).
2. Remove door mirror glass. Refer to [MIR-24, "Removal and Installation"](#).
3. Remove the screws (A) and reposition side turn signal lamp.



4. Disconnect the harness connector from the side turn signal lamp and remove.

#### INSTALLATION

Installation is in the reverse order of removal.

#### Bulb Replacement

INFOID:000000010365196

The side turn signal lamp bulb is not serviced separately. Refer to [EXL-126, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# REAR COMBINATION LAMP


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

## REAR COMBINATION LAMP

Exploded View

INFOID:000000010247838



1. Rear combination lamp

A. Grommet

B. Clip

## Removal and Installation

INFOID:000000010247839

### REMOVAL

1. Remove side air spoiler. Refer to [EXT-48, "Removal and Installation"](#).
2. Remove rear combination lamp bolts.
3. Pull rear combination lamp rearward to release from clip and locators.
4. Disconnect the harness connector from the rear combination lamp and remove.

### INSTALLATION

Installation is in the reverse order of removal.

## Bulb Replacement

INFOID:000000010338571

### WARNING:

Do not touch bulb with bare hand while it is lit or right after being turned off. Burning may result.

### CAUTION:

- Do not touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

STOP LAMP BULB

# REAR COMBINATION LAMP

[LED HEADLAMP]

## < REMOVAL AND INSTALLATION >

### Removal

1. Remove rear combination lamp. Refer to [EXL-127. "Removal and Installation"](#).
2. Rotate stop lamp bulb socket counterclockwise and remove.
3. Remove stop lamp bulb from bulb socket.

### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install bulb socket securely for watertightness.**

### TAIL LAMP BULB

#### Removal

1. Remove rear combination lamp. Refer to [EXL-127. "Removal and Installation"](#).
2. Rotate tail lamp bulb socket counterclockwise and remove.
3. Remove tail lamp bulb from bulb socket.

#### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install bulb socket securely for watertightness.**

### TURN SIGNAL LAMP BULB

#### Removal

1. Remove rear combination lamp. Refer to [EXL-127. "Removal and Installation"](#).
2. Rotate turn signal lamp bulb socket counterclockwise and remove.
3. Remove turn signal lamp bulb from bulb socket.

#### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install bulb socket securely for watertightness.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P

# HIGH-MOUNTED STOP LAMP


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

## HIGH-MOUNTED STOP LAMP

Exploded View

INFOID:000000010247841



1. High-mounted stop lamp

2. Back door

[ ] Stud

### Removal and Installation

INFOID:000000010247842

#### REMOVAL

1. Remove access cover using a suitable tool. Refer to [INT-38, "Exploded View"](#).
2. Remove high-mounted stop lamp nuts.
3. Disconnect the harness connector from high-mounted stop lamp and remove.

#### INSTALLATION

Installation is in the reverse order of removal.

### Bulb Replacement

INFOID:000000010338577

#### HIGH-MOUNTED STOP LAMP BULB

The high-mounted stop lamp bulb is not serviced separately. Refer to [EXL-129, "Removal and Installation"](#).



# BACK-UP LAMP ASSEMBLY


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

## BACK-UP LAMP ASSEMBLY


### Exploded View


INFOID:000000010247843



1. Back-up lamp assembly

2. Back door

 Clip

 Stud

### Removal and Installation

INFOID:000000010247844

#### REMOVAL

1. Remove back door finisher. Refer to [INT-38. "Removal and Installation"](#).
2. Remove back-up lamp assembly nuts.
3. Pull back-up lamp assembly rearward, disconnect the harness connector and remove.

#### INSTALLATION

Installation is in the reverse order of removal.

### Bulb Replacement

INFOID:000000010247845

#### **WARNING:**

**Do not touch bulb with bare hand while it is lit or right after being turned off. Burning may result.**

#### **CAUTION:**

- Do not touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

#### TAIL LAMP BULB

##### Removal

1. Remove back-up lamp assembly. Refer to [EXL-130. "Removal and Installation"](#).
2. Rotate tail lamp bulb socket counterclockwise and remove.
3. Remove tail lamp bulb from bulb socket.

##### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install bulb socket securely for watertightness.**

#### BACK-UP LAMP BULB

##### Removal

A

B

C

D

E

F

G

H

I

J

K

EXL

M

N

O

P

## BACK-UP LAMP ASSEMBLY

[LED HEADLAMP]

### < REMOVAL AND INSTALLATION >

---

1. Remove back-up lamp assembly. Refer to [EXL-130, "Removal and Installation"](#).
2. Rotate back-up lamp bulb socket counterclockwise and remove.
3. Remove back-up lamp bulb from bulb socket.

#### Installation

Installation is in the reverse order of removal.

#### **CAUTION:**

**After installing the bulb, install bulb socket securely for watertightness.**

# LICENSE PLATE LAMP


< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

## LICENSE PLATE LAMP

### Exploded View

INFOID:000000010365390




- |                                |                                   |                       |
|--------------------------------|-----------------------------------|-----------------------|
| 1. License plate lamp bulb     | 2. License plate lamp seal        | 3. License plate lamp |
| 4. License plate lamp assembly | A. License plate lamp bulb socket |                       |

### Removal and Installation

INFOID:000000010247847

#### REMOVAL

1. Release the license lamp finisher. Refer to [EXT-50. "Exploded View"](#).
2. Remove the screw (A) (LH or RH) and pull license plate lamp (1) (LH or RH) rearward.



3. Disconnect the harness connector from the license plate lamp and remove.

#### INSTALLATION

Installation is in the reverse order of removal.

#### Bulb Replacement

INFOID:000000010247848

#### **WARNING:**

**Do not touch bulb with your hand while it is on or right after being turned off. Burning may result.**

## LICENSE PLATE LAMP

< REMOVAL AND INSTALLATION >

[LED HEADLAMP]

### **CAUTION:**

- Do not touch the glass surface of the bulb with bare hands or allow oil or grease to get on it to prevent damage to the bulb.
- Do not leave bulb out of lamp reflector for a long time because dust, moisture smoke, etc. may affect the performance of lamp. When replacing bulb, be sure to replace it with new one.

### REMOVAL

1. Remove license plate lamp. Refer to [EXL-283. "Removal and Installation"](#).
2. Rotate license plate lamp bulb socket counterclockwise and remove.
3. Remove license plate lamp bulb from bulb socket.

### INSTALLATION

Installation is in the reverse order of removal.

### **CAUTION:**

**After installing the bulb, install the bulb socket securely for watertightness.**

# FRONT COMBINATION LAMP


< UNIT DISASSEMBLY AND ASSEMBLY >

[LED HEADLAMP]

## UNIT DISASSEMBLY AND ASSEMBLY

### FRONT COMBINATION LAMP

Exploded View



1. Front combination lamp

2. Turn signal lamp bulb socket

### Disassembly and Assembly

INFOID:0000000010377948

#### DISASSEMBLY

1. Remove front combination lamp. Refer to [EXL-268, "Removal and Installation"](#).
2. Rotate the turn signal lamp bulb socket counterclockwise and remove.
3. Remove the turn signal lamp bulb from the bulb socket.

#### ASSEMBLY

Assembly is in the reverse order of disassembly.

# REAR COMBINATION LAMP


< UNIT DISASSEMBLY AND ASSEMBLY >

[LED HEADLAMP]

## REAR COMBINATION LAMP

### Exploded View

INFOID:000000010377949



- |                          |                                  |                   |
|--------------------------|----------------------------------|-------------------|
| 1. Rear combination lamp | 2. Turn signal lamp bulb         | 3. Tail lamp bulb |
| 4. Stop lamp bulb        | A. Rear combination lamp harness |                   |

### Disassembly and Assembly

INFOID:000000010377950

#### DISASSEMBLY

1. Remove rear combination lamp. Refer to [EXL-278, "Removal and Installation"](#).
2. Rotate the stop lamp bulb socket counterclockwise and remove.
3. Remove the stop lamp bulb from the bulb socket.
4. Rotate the tail lamp bulb socket counterclockwise and remove.
5. Remove the tail lamp bulb from the bulb socket.
6. Rotate the turn signal lamp bulb socket counterclockwise and remove.
7. Remove the turn signal lamp bulb from bulb socket.

#### ASSEMBLY

Assembly is in the reverse order of disassembly.

#### **CAUTION:**

**After installing, be sure to install the bulb sockets securely to ensure watertightness.**

# SERVICE DATA AND SPECIFICATIONS (SDS)

< SERVICE DATA AND SPECIFICATIONS (SDS)

[LED HEADLAMP]

## SERVICE DATA AND SPECIFICATIONS (SDS)

### SERVICE DATA AND SPECIFICATIONS (SDS)

#### Bulb Specifications

INFOID:0000000010336294

Item		Wattage (W)*
Front combination lamp	High beam	—
	Low beam	—
	Turn signal lamp	28/8
	Parking (side marker) lamp	—
	Daytime running lamp	—
Fog lamp		55
Side turn signal lamp		—
Rear combination lamp	Stop lamp	21
	Tail lamp	5
	Turn signal lamp	21
Back-up lamp	Tail lamp	5
	Back-up lamp	16
License plate lamp		5
High-mounted stop lamp		—

\*: Always check with the Parts Department for the latest parts info.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
EXL  
M  
N  
O  
P