

# BRC

## SECTION

### BRAKE CONTROL SYSTEM

## CONTENTS

<b>ABS</b>		<b>C1109 POWER AND GROUND SYSTEM</b> .....	24
<b>BASIC INSPECTION</b> .....	6	Description .....	24
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	6	DTC Logic .....	24
Work Flow .....	6	Diagnosis Procedure .....	24
Diagnostic Work Sheet .....	8	<b>C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)</b> .....	26
<b>SYSTEM DESCRIPTION</b> .....	9	Description .....	26
<b>ABS</b> .....	9	DTC Logic .....	26
System Diagram .....	9	Diagnosis Procedure .....	26
System Description .....	9	<b>C1111 ABS MOTOR, MOTOR RELAY SYSTEM</b> .....	27
Component Parts Location .....	10	Description .....	27
Component Description .....	11	DTC Logic .....	27
<b>EBD</b> .....	12	Diagnosis Procedure .....	27
System Diagram .....	12	Component Inspection .....	28
System Description .....	12	<b>C1113 G SENSOR</b> .....	29
Component Parts Location .....	13	Description .....	29
Component Description .....	14	DTC Logic .....	29
<b>DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]</b> .....	15	Diagnosis Procedure .....	29
CONSULT-III Function .....	15	Component Inspection .....	30
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	18	<b>C1115 WHEEL SENSOR</b> .....	32
<b>C1101, C1102, C1103, C1104 WHEEL SENSOR</b> .....	18	Description .....	32
Description .....	18	DTC Logic .....	32
DTC Logic .....	18	Diagnosis Procedure .....	32
Diagnosis Procedure .....	18	Component Inspection .....	33
Component Inspection .....	20	<b>C1120, C1122, C1124, C1126 IN ABS SOL</b> .....	35
<b>C1105, C1106, C1107, C1108 WHEEL SENSOR</b> .....	21	Description .....	35
Description .....	21	DTC Logic .....	35
DTC Logic .....	21	Diagnosis Procedure .....	35
Diagnosis Procedure .....	21	Component Inspection .....	36
Component Inspection .....	23	<b>C1121, C1123, C1125, C1127 OUT ABS SOL</b> .....	37
		Description .....	37
		DTC Logic .....	37
		Diagnosis Procedure .....	37
		Component Inspection .....	38

BRC

G

H

I

J

K

L

M

N

O

P

<b>C1140 ACTUATOR RELAY SYSTEM .....</b>	<b>39</b>	<b>PEDAL VIBRATION OR ABS OPERATION</b>	
Description .....	39	<b>SOUND OCCURS .....</b>	<b>61</b>
DTC Logic .....	39	Diagnosis Procedure .....	61
Diagnosis Procedure .....	39	<b>NORMAL OPERATING CONDITION .....</b>	<b>62</b>
Component Inspection .....	40	Description .....	62
<b>U1000 CAN COMM CIRCUIT .....</b>	<b>41</b>	<b>PRECAUTION .....</b>	<b>63</b>
Description .....	41	<b>PRECAUTIONS .....</b>	<b>63</b>
DTC Logic .....	41	<b>FOR USA AND CANADA .....</b>	<b>63</b>
Diagnosis Procedure .....	41	FOR USA AND CANADA : Precaution for Supple-	
<b>U1010 CONTROL UNIT (CAN) .....</b>	<b>42</b>	mental Restraint System (SRS) "AIR BAG" and	
Description .....	42	"SEAT BELT PRE-TENSIONER" .....	63
DTC Logic .....	42	FOR USA AND CANADA : Precaution for Proce-	
Diagnosis Procedure .....	42	dure without Cowl Top Cover .....	63
<b>BRAKE FLUID LEVEL SWITCH .....</b>	<b>43</b>	FOR USA AND CANADA : Precaution for Brake	
Description .....	43	System .....	63
Component Function Check .....	43	FOR USA AND CANADA : Precaution for Brake	
Diagnosis Procedure .....	43	Control .....	64
Component Inspection .....	44	<b>FOR MEXICO .....</b>	<b>64</b>
<b>PARKING BRAKE SWITCH .....</b>	<b>45</b>	FOR MEXICO : Precaution for Supplemental Re-	
Description .....	45	straint System (SRS) "AIR BAG" and "SEAT BELT	
Component Function Check .....	45	PRE-TENSIONER" .....	64
Diagnosis Procedure .....	45	FOR MEXICO : Precaution for Procedure without	
Component Inspection .....	45	Cowl Top Cover .....	65
<b>ABS WARNING LAMP .....</b>	<b>47</b>	FOR MEXICO : Precaution for Brake System .....	65
Description .....	47	FOR MEXICO : Precaution for Brake Control .....	65
Component Function Check .....	47	<b>REMOVAL AND INSTALLATION .....</b>	<b>66</b>
Diagnosis Procedure .....	47	<b>WHEEL SENSOR .....</b>	<b>66</b>
<b>BRAKE WARNING LAMP .....</b>	<b>48</b>	<b>FRONT WHEEL SENSOR .....</b>	<b>66</b>
Description .....	48	FRONT WHEEL SENSOR : Exploded View .....	66
Component Function Check .....	48	FRONT WHEEL SENSOR : Removal and Instal-	
Diagnosis Procedure .....	48	lation .....	66
<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>49</b>	<b>REAR WHEEL SENSOR .....</b>	<b>66</b>
<b>ABS ACTUATOR AND ELECTRIC UNIT</b>		REAR WHEEL SENSOR : Exploded View .....	67
<b>(CONTROL UNIT) .....</b>	<b>49</b>	REAR WHEEL SENSOR : Removal and Installa-	
Reference Value .....	49	tion .....	67
Wiring Diagram -BRAKE CONTROL SYSTEM- ....	52	<b>SENSOR ROTOR .....</b>	<b>68</b>
Fail-Safe .....	55	<b>FRONT SENSOR ROTOR .....</b>	<b>68</b>
DTC Index .....	56	FRONT SENSOR ROTOR : Exploded View .....	68
<b>SYMPTOM DIAGNOSIS .....</b>	<b>57</b>	FRONT SENSOR ROTOR : Removal and Instal-	
<b>EXCESSIVE ABS FUNCTION OPERATION</b>		lation .....	68
<b>FREQUENCY .....</b>	<b>57</b>	<b>REAR SENSOR ROTOR .....</b>	<b>68</b>
Diagnosis Procedure .....	57	REAR SENSOR ROTOR : Exploded View .....	68
<b>UNEXPECTED PEDAL REACTION .....</b>	<b>58</b>	REAR SENSOR ROTOR : Removal and Installa-	
Diagnosis Procedure .....	58	tion .....	68
<b>THE BRAKING DISTANCE IS LONG .....</b>	<b>59</b>	<b>ABS ACTUATOR AND ELECTRIC UNIT</b>	
Diagnosis Procedure .....	59	<b>(CONTROL UNIT) .....</b>	<b>69</b>
<b>ABS FUNCTION DOES NOT OPERATE .....</b>	<b>60</b>	Exploded View .....	69
Diagnosis Procedure .....	60	Removal and Installation .....	69

<b>G SENSOR</b> .....	71	<b>C1105, C1106, C1107, C1108 WHEEL SENSOR</b> .....	102	A
Exploded View .....	71	Description .....	102	
Removal and Installation .....	71	DTC Logic .....	102	
<b>VDC/TCS/ABS</b>		Diagnosis Procedure .....	102	B
<b>BASIC INSPECTION</b> .....	72	Component Inspection .....	104	
<b>DIAGNOSIS AND REPAIR WORKFLOW</b> .....	72	Special Repair Requirement .....	104	
Work Flow .....	72	<b>C1109 POWER AND GROUND SYSTEM</b> .....	105	C
Diagnostic Work Sheet .....	75	Description .....	105	
<b>INSPECTION AND ADJUSTMENT</b> .....	76	DTC Logic .....	105	
<b>ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION</b> .....	76	Diagnosis Procedure .....	105	D
ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description .....	76	Diagnosis Procedure .....	106	
ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement .....	76	<b>C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)</b> .....	108	E
<b>SYSTEM DESCRIPTION</b> .....	78	Description .....	108	
<b>VDC</b> .....	78	DTC Logic .....	108	
System Diagram .....	78	Diagnosis Procedure .....	108	
System Description .....	78	Special Repair Requirement .....	108	BRC
Component Parts Location .....	78	<b>C1111 ABS MOTOR, MOTOR RELAY SYSTEM</b> .....	109	G
Component Description .....	81	Description .....	109	
<b>TCS</b> .....	82	DTC Logic .....	109	
System Diagram .....	82	Diagnosis Procedure .....	109	H
System Description .....	82	Component Inspection .....	110	
Component Parts Location .....	82	Special Repair Requirement .....	110	I
Component Description .....	85	<b>C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR</b> .....	111	J
<b>ABS</b> .....	86	Description .....	111	
System Diagram .....	86	DTC Logic .....	111	
System Description .....	86	Diagnosis Procedure .....	111	
Component Parts Location .....	86	Component Inspection .....	113	K
Component Description .....	89	Special Repair Requirement .....	113	
<b>EBD</b> .....	90	<b>C1115 WHEEL SENSOR</b> .....	115	L
System Diagram .....	90	Description .....	115	
System Description .....	90	DTC Logic .....	115	
Component Parts Location .....	90	Diagnosis Procedure .....	115	
Component Description .....	93	Component Inspection .....	116	M
<b>DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]</b> .....	94	Special Repair Requirement .....	117	
CONSULT-III Function .....	94	<b>C1116 STOP LAMP SWITCH</b> .....	118	N
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	99	Description .....	118	
<b>C1101, C1102, C1103, C1104 WHEEL SENSOR</b> .....	99	DTC Logic .....	118	
Description .....	99	Diagnosis Procedure .....	118	
DTC Logic .....	99	Component Inspection .....	119	O
Diagnosis Procedure .....	99	Component Inspection .....	119	
Component Inspection .....	101	<b>C1118 AWD SYSTEM</b> .....	120	P
Special Repair Requirement .....	101	Description .....	120	
<b>C1105, C1106, C1107, C1108 WHEEL SENSOR</b> .....	102	DTC Logic .....	120	
Description .....	102	Diagnosis Procedure .....	120	
DTC Logic .....	102	Special Repair Requirement .....	120	
Diagnosis Procedure .....	102	<b>C1120, C1122, C1124, C1126 IN ABS SOL</b> ...	121	
Component Inspection .....	104	Description .....	121	
Special Repair Requirement .....	104	DTC Logic .....	121	
<b>C1109 POWER AND GROUND SYSTEM</b> .....	105			
Description .....	105			
DTC Logic .....	105			
Diagnosis Procedure .....	105			
Diagnosis Procedure .....	106			

Diagnosis Procedure .....	121	DTC Logic .....	141
Component Inspection .....	122	Diagnosis Procedure .....	141
Special Repair Requirement .....	123	Special Repair Requirement .....	141
<b>C1121, C1123, C1125, C1127 OUT ABS SOL</b> .....	<b>124</b>	<b>U1010 CONTROL UNIT (CAN)</b> .....	<b>142</b>
Description .....	124	Description .....	142
DTC Logic .....	124	DTC Logic .....	142
Diagnosis Procedure .....	124	Diagnosis Procedure .....	142
Component Inspection .....	125	Special Repair Requirement .....	142
Special Repair Requirement .....	126		
<b>C1130 ENGINE SIGNAL</b> .....	<b>127</b>	<b>PARKING BRAKE SWITCH</b> .....	<b>143</b>
Description .....	127	Description .....	143
DTC Logic .....	127	Component Function Check .....	143
Diagnosis Procedure .....	127	Diagnosis Procedure .....	143
Diagnosis Procedure .....	127	Component Inspection .....	143
<b>C1140 ACTUATOR RELAY SYSTEM</b> .....	<b>128</b>	<b>VDC OFF SWITCH</b> .....	<b>145</b>
Description .....	128	Description .....	145
DTC Logic .....	128	Component Function Check .....	145
Diagnosis Procedure .....	128	Diagnosis Procedure .....	145
Component Inspection .....	129	Component Inspection .....	146
Special Repair Requirement .....	129	Special Repair Requirement .....	146
<b>C1143, C1144 STEERING ANGLE SENSOR</b> .....	<b>130</b>	<b>ABS WARNING LAMP</b> .....	<b>147</b>
Description .....	130	Description .....	147
DTC Logic .....	130	Component Function Check .....	147
Diagnosis Procedure .....	130	Diagnosis Procedure .....	147
Component Inspection .....	131	Special Repair Requirement .....	147
Special Repair Requirement .....	131		
		<b>BRAKE WARNING LAMP</b> .....	<b>148</b>
<b>C1155 BRAKE FLUID LEVEL SWITCH</b> .....	<b>132</b>	Description .....	148
Description .....	132	Component Function Check .....	148
DTC Logic .....	132	Diagnosis Procedure .....	148
Diagnosis Procedure .....	132	Special Repair Requirement .....	148
Component Inspection .....	133		
Special Repair Requirement .....	134	<b>VDC OFF INDICATOR LAMP</b> .....	<b>150</b>
		Description .....	150
<b>C1164, C1165 CV SYSTEM</b> .....	<b>135</b>	Component Function Check .....	150
Description .....	135	Diagnosis Procedure .....	150
DTC Logic .....	135	Special Repair Requirement .....	150
Diagnosis Procedure .....	135		
Component Inspection .....	136	<b>SLIP INDICATOR LAMP</b> .....	<b>152</b>
Special Repair Requirement .....	136	Description .....	152
		Component Function Check .....	152
<b>C1166, C1167 SV SYSTEM</b> .....	<b>137</b>	Diagnosis Procedure .....	152
Description .....	137	Special Repair Requirement .....	152
DTC Logic .....	137		
Diagnosis Procedure .....	137	<b>ECU DIAGNOSIS INFORMATION</b> .....	<b>153</b>
Component Inspection .....	138		
Special Repair Requirement .....	138	<b>ABS ACTUATOR AND ELECTRIC UNIT</b>	
		<b>(CONTROL UNIT)</b> .....	<b>153</b>
<b>C1176 STOP LAMP SW2</b> .....	<b>139</b>	Reference Value .....	153
Description .....	139	Wiring Diagram -BRAKE CONTROL SYSTEM- ..	157
DTC Logic .....	139	Fail-Safe .....	160
Diagnosis Procedure .....	139	DTC Index .....	161
Component Inspection .....	140		
Special Repair Requirement .....	140	<b>SYMPTOM DIAGNOSIS</b> .....	<b>163</b>
<b>U1000 CAN COMM CIRCUIT</b> .....	<b>141</b>	<b>EXCESSIVE ABS FUNCTION OPERATION</b>	
Description .....	141	<b>FREQUENCY</b> .....	<b>163</b>
		Diagnosis Procedure .....	163

<b>UNEXPECTED PEDAL REACTION</b> .....	164	FOR MEXICO : Precaution for Brake System .....	172	A
Diagnosis Procedure .....	164	FOR MEXICO : Precaution for Brake Control .....	173	
<b>THE BRAKING DISTANCE IS LONG</b> .....	165	FOR MEXICO : Precautions for Harness Repair ..	173	B
Diagnosis Procedure .....	165	<b>REMOVAL AND INSTALLATION</b> .....	175	
<b>ABS FUNCTION DOES NOT OPERATE</b> .....	166	<b>WHEEL SENSOR</b> .....	175	C
Diagnosis Procedure .....	166	<b>FRONT WHEEL SENSOR</b> .....	175	
<b>PEDAL VIBRATION OR ABS OPERATION</b>		FRONT WHEEL SENSOR : Exploded View .....	175	D
<b>SOUND OCCURS</b> .....	167	FRONT WHEEL SENSOR : Removal and Instal-	175	
Diagnosis Procedure .....	167	lation .....	175	E
<b>VEHICLE JERKS DURING VDC/TCS/ABS</b>		<b>REAR WHEEL SENSOR</b> .....	175	
<b>CONTROL</b> .....	168	REAR WHEEL SENSOR : Exploded View .....	176	BRC
Diagnosis Procedure .....	168	REAR WHEEL SENSOR : Removal and Installa-	176	
<b>NORMAL OPERATING CONDITION</b> .....	169	tion .....	176	
Description .....	169	<b>SENSOR ROTOR</b> .....	177	G
<b>PRECAUTION</b> .....	170	<b>FRONT SENSOR ROTOR</b> .....	177	
<b>PRECAUTIONS</b> .....	170	FRONT SENSOR ROTOR : Exploded View .....	177	H
<b>FOR USA AND CANADA</b> .....	170	FRONT SENSOR ROTOR : Removal and Instal-	177	
FOR USA AND CANADA : Precaution for Supple-		lation .....	177	I
mental Restraint System (SRS) "AIR BAG" and		<b>REAR SENSOR ROTOR</b> .....	177	
"SEAT BELT PRE-TENSIONER" .....	170	REAR SENSOR ROTOR : Exploded View .....	177	J
FOR USA AND CANADA : Precaution for Proce-		REAR SENSOR ROTOR : Removal and Installa-	177	
dure without Cowl Top Cover .....	170	tion .....	177	K
FOR USA AND CANADA : Precaution for Brake		<b>ABS ACTUATOR AND ELECTRIC UNIT</b>		
System .....	170	<b>(CONTROL UNIT)</b> .....	178	
FOR USA AND CANADA : Precaution for Brake		Exploded View .....	178	L
Control .....	171	Removal and Installation .....	178	
FOR USA AND CANADA : Precautions for Har-		<b>G SENSOR</b> .....	180	
ness Repair .....	171	Exploded View .....	180	M
<b>FOR MEXICO</b> .....	172	Removal and Installation .....	180	
FOR MEXICO : Precaution for Supplemental Re-		<b>STEERING ANGLE SENSOR</b> .....	181	N
straint System (SRS) "AIR BAG" and "SEAT BELT		Exploded View .....	181	
PRE-TENSIONER" .....	172	Removal and Installation .....	181	O
FOR MEXICO : Precaution for Procedure without				P
Cowl Top Cover .....	172			

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[ABS]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000005255384

#### OVERALL SEQUENCE



JSFIA0010GB

#### DETAILED FLOW

# DIAGNOSIS AND REPAIR WORKFLOW

[ABS]

< BASIC INSPECTION >

## 1. COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis worksheet. Refer to [BRC-8, "Diagnostic Work Sheet"](#).

>> GO TO 2.

## 2. PERFORM THE SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III. Refer to [BRC-15, "CONSULT-III Function"](#).

Is there any DTC displayed?

YES >> GO TO 3.

NO >> GO TO 4.

## 3. PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC of "ABS" with CONSULT-III. Refer to [BRC-56, "DTC Index"](#).

>> GO TO 7.

## 4. CHECK THE SYMPTOM THAT IS NOT CONSIDERED A SYSTEM MALFUNCTION

Check that the symptom is a normal operation that is not considered a system malfunction. Refer to [BRC-62, "Description"](#).

Is the symptom a normal operation?

YES >> INSPECTION END

NO >> GO TO 5.

## 5. CHECK THE WARNING LAMP FOR ILLUMINATION

Check that the warning lamp illuminate.

- ABS warning lamp: Refer to [BRC-47, "Description"](#).

- Brake warning lamp: Refer to [BRC-48, "Description"](#).

Is ON/OFF timing normal?

YES >> GO TO 6.

NO >> GO TO 2.

## 6. PERFORM THE DIAGNOSIS BY SYMPTOM

Perform the diagnosis applicable to the displayed DTC of "ABS" with CONSULT-III.

>> GO TO 7.

## 7. REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 8.

## 8. MEMORY CLEAR

Perform self-diagnosis memory clear for "ABS" with CONSULT-III.

>> GO TO 9.

## 9. FINAL CHECK

Perform the again, and check that the malfunction is repaired completely.

Is no other DTC present and the repair completed?

YES >> INSPECTION END

NO >> GO TO 3.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[ABS]

## Diagnostic Work Sheet

INFOID:000000005255385

Customer name MR/MS	Model & Year		VIN
Engine #	Trans.		Mileage
Incident Date	Manuf. Date		In Service Date
Symptoms	<input type="checkbox"/> Noise and vibration (from engine compartment) <input type="checkbox"/> Noise and vibration (from axle)	<input type="checkbox"/> Warning / Indicator activate	<input type="checkbox"/> Firm pedal operation <input type="checkbox"/> Large stroke pedal operation
	<input type="checkbox"/> ABS does not work (Wheels lock when braking)	<input type="checkbox"/> Lack of sense of acceleration	
Engine conditions	<input type="checkbox"/> When starting <input type="checkbox"/> After starting		
Road conditions	<input type="checkbox"/> Low friction road ( <input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other ) <input type="checkbox"/> Bumps / potholes		
Driving conditions	<input type="checkbox"/> Full-acceleration <input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped		
Applying brake conditions	<input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually		
Other conditions	<input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Shift change <input type="checkbox"/> Other descriptions		

SFIA3264E




# SYSTEM DESCRIPTION

## ABS

### System Diagram


INFOID:000000005255386



### System Description

INFOID:000000005255387

- Anti-Lock Braking System is a function that detects wheel revolution while braking, electronically controls braking force, and prevents wheel locking during sudden braking. It improves handling stability and maneuverability for avoiding obstacles.
- Electrical system diagnosis by CONSULT-III is available.



- |  |                       |                                   |
|--|-----------------------|-----------------------------------|
| 1. ABS warning lamp                              | 2. Brake warning lamp | 3. G sensor (AWD models)          |
| 4. ABS actuator and electric unit (control unit) | 5. Front wheel sensor | 6. Rear wheel sensor (2WD models) |
| 7. Rear wheel sensor (AWD models)                |                       |                                   |
| A. Combination meter                             | B. Center console     | C. Engine room (right side)       |
| D. Steering knuckle                              | E. Rear axle          |                                   |

Component Description

INFOID:0000000005255389

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-27, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-39, "Description"</a>
	Solenoid valve	<a href="#">BRC-35, "Description"</a>
Wheel sensor		<a href="#">BRC-18, "Description"</a>
G sensor (AWD models)		<a href="#">BRC-29, "Description"</a>
ABS warning lamp		<a href="#">BRC-47, "Description"</a>
Brake warning lamp		<a href="#">BRC-48, "Description"</a>


A  
B  
C  
D  
E  
  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

## EBD

## System Diagram


INFOID:000000005255390



## System Description

INFOID:000000005255391

- Electric Brake force Distribution is a following function. ABS actuator and electric unit (control unit) detects subtle slippages between the front and rear wheels during braking. Then is electronically controls the rear braking force (brake fluid pressure) to reducing and reduces rear wheel slippage. Accordingly it improves vehicle stability.
- Electrical system diagnosis by CONSULT-III is available.



A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

## &lt; SYSTEM DESCRIPTION &gt;

## Component Description

INFOID:0000000005255393

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-27, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-39, "Description"</a>
	Solenoid valve	<a href="#">BRC-35, "Description"</a>
Wheel sensor		<a href="#">BRC-18, "Description"</a>
G sensor (AWD models)		<a href="#">BRC-29, "Description"</a>
ABS warning lamp		<a href="#">BRC-47, "Description"</a>
Brake warning lamp		<a href="#">BRC-48, "Description"</a>

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[ABS]

## DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

### CONSULT-III Function

INFOID:000000005255394

#### FUNCTION

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

Diagnostic test mode	Function
Self diagnostic result	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the ABS actuator and electric unit (control unit) can be read.
Active test	Diagnostic test mode is which CONSULT-III drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range.
ECU identification	ABS actuator and electric unit (control unit) part number can be read.

### SELF DIAGNOSTIC RESULT

#### Operation Procedure

Before performing the self-diagnosis for "ABS" with CONSULT-III, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.

#### How to Erase Self-diagnosis Results

After erasing DTC memory for "ABS" with CONSULT-III, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute as the final inspection, and make sure that the ABS warning lamp and brake warning lamp turn OFF.

#### CAUTION:

**If memory cannot be erased, perform applicable diagnosis.**

#### NOTE:

- When the wheel sensor malfunctions, after inspecting the wheel sensor system, the ABS warning lamp and brake warning lamp will not turn OFF even when the system is normal unless the vehicle is driving at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
- Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).

#### Display Item List

Refer to [BRC-56. "DTC Index"](#).

### DATA MONITOR

#### Display Item List

×: Applicable ▼: Optional item

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
FR LH SENSOR [km/h (MPH)]	×	×	Wheel speed
FR RH SENSOR [km/h (MPH)]	×	×	
RR LH SENSOR [km/h (MPH)]	×	×	
RR RH SENSOR [km/h (MPH)]	×	×	
STOP LAMP SW (On/Off)	×	×	Stop lamp switch signal status
BATTERY VOLT (V)	×	×	Battery voltage supplied to the ABS actuator and electric unit (control unit)

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[ABS]

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
DECEL G-SEN1 (On/Off) (AWD models)	×	×	Vehicle on level surface or on slope
DECEL G-SEN2 (On/Off) (AWD models)	×	×	
FR RH IN SOL (On/Off)	▼	×	Operation status of each solenoid valve
FR RH OUT SOL (On/Off)	▼	×	
FR LH IN SOL (On/Off)	▼	×	
FR LH OUT SOL (On/Off)	▼	×	
RR RH IN SOL (On/Off)	▼	×	
RR RH OUT SOL (On/Off)	▼	×	
RR LH IN SOL (On/Off)	▼	×	
RR LH OUT SOL (On/Off)	▼	×	
MOTOR RELAY (On/Off)	▼	×	Motor and motor relay operation
ACTUATOR RLY (On/Off)	▼	×	Actuator relay operation
ABS WARN LAMP (On/Off)	▼	×	ABS warning lamp
EBD SIGNAL (On/Off)	▼	▼	EBD operation
ABS SIGNAL (On/Off)	▼	▼	ABS operation
EBD FAIL SIG (On/Off)	▼	▼	EBD fail-safe signal
ABS FAIL SIG (On/Off)	▼	▼	ABS fail-safe signal

## ACTIVE TEST

### CAUTION:

- Never perform active test while driving vehicle.
- Make sure to completely bleed air from brake system.
- The active test cannot be performed with the ABS warning lamp and brake warning lamp are on.
- ABS warning lamp and brake warning lamp are on during active test.

### NOTE:

- When active test is performed while depressing the pedal, the pedal depression amount will change. This is normal. (Only solenoid valve and ABS motor.)
- "TEST IS STOPPED" in "ABS" with CONSULT-III is displayed 10 seconds after operation start.
- After "TEST IS STOPPED" in "ABS" with CONSULT-III is displayed, to perform test again.

### Test Item

#### ABS SOLENOID VALVE

- Select "Up", "Keep" and "Down" of "ACTIVE TEST" in "ABS" with CONSULT-III. Then use screen monitor to check that solenoid valve operates as shown in solenoid valve operation chart.



# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[ABS]

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*

\*: On for 1 to 2 seconds after the select, and then Off.

## ABS MOTOR

- Select "On" and "Off" of "ACTIVE TEST" in "ABS" with CONSULT-III on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY (Note)	On	On

## NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

## ECU IDENTIFICATION

ABS actuator and electric unit (control unit) part number can be read.

# C1101, C1102, C1103, C1104 WHEEL SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

## DTC/CIRCUIT DIAGNOSIS

### C1101, C1102, C1103, C1104 WHEEL SENSOR

#### Description

INFOID:000000005255395

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

#### DTC Logic

INFOID:000000005255396

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1101	RR RH SENSOR-1	Circuit of rear RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Wheel sensor</li><li>• ABS actuator and electric unit (control unit)</li></ul>
C1102	RR LH SENSOR-1	Circuit of rear LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1103	FR RH SENSOR-1	Circuit of front RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1104	FR LH SENSOR-1	Circuit of front LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	

#### DTC CONFIRMATION PROCEDURE

##### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
RR RH SENSOR-1
RR LH SENSOR-1
FR RH SENSOR-1
FR LH SENSOR-1

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-18. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

#### Diagnosis Procedure

INFOID:000000005255397

#### CAUTION:

**Never check between wheel sensor terminals.**

##### 1.CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

YES >> GO TO 2.  
NO >> Adjust air pressure, or replace tire.

##### 2.CHECK WHEEL SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

YES >> GO TO 3.  
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

# C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

## 3.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 4.

NO >> Poor connection of connector terminal. Repair or replace connector.

## 4.CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	12	E39 (Front RH)	4	Existed
	27	E22 (Front LH)	2	
	15	B41 (Rear RH)	8	
	30	B44 (Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	E39 (Front RH)	3	Existed
	23	E22 (Front LH)	1	
	11	B41 (Rear RH)	7	
	26	B44 (Rear LH)	5	

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	12, 21	E36	3, 4	Not existed
	27, 23			
	15, 11			
	30, 26			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

## 5.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.

**CAUTION:**

**Never start engine.**

## C1101, C1102, C1103, C1104 WHEEL SENSOR

[ABS]

### < DTC/CIRCUIT DIAGNOSIS >

5. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> INSPECTION END

### Component Inspection

INFOID:000000005255398

#### 1. CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-18, "Diagnosis Procedure"](#).

# C1105, C1106, C1107, C1108 WHEEL SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

## C1105, C1106, C1107, C1108 WHEEL SENSOR

### Description

INFOID:000000005255399

ABS unit continually monitors wheel speed sensors to detect abnormal signals.

### DTC Logic

INFOID:000000005255400

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1105	RR RH SENSOR-2	Signal from rear RH wheel sensor does not match other 3 wheel speed signals.	<ul style="list-style-type: none"><li>• Sensor not installed currently</li><li>• Sensor rotor or encoder damaged</li><li>• Sensor rotor loose on axle</li><li>• Electrical interference</li><li>• Wheel not turning - e.g. vehicle driven on 2WD dyno</li><li>• Sensor damaged</li><li>• ABS unit damaged</li></ul>
C1106	RR LH SENSOR-2	Signal from rear LH wheel sensor does not match other 3 wheel speed signals.	
C1107	FR RH SENSOR-2	Signal from front RH wheel sensor does not match other 3 wheel speed signals.	
C1108	FR LH SENSOR-2	Signal from front LH wheel sensor does not match other 3 wheel speed signals.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
RR RH SENSOR-2
RR LH SENSOR-2
FR RH SENSOR-2
FR LH SENSOR-2

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-21. "Diagnosis Procedure"](#).

NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255401

#### CAUTION:

**Never check between wheel sensor terminals.**

#### 1.CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

YES >> GO TO 2.

NO >> Adjust air pressure, or replace tire.

#### 2.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

YES >> GO TO 3.

NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

#### 3.CHECK CONNECTOR

1. Turn ignition switch OFF.

# C1105, C1106, C1107, C1108 WHEEL SENSOR

[ABS]

## < DTC/CIRCUIT DIAGNOSIS >

2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 4.

NO >> Poor connection of connector terminal. Repair or replace connector.

## 4.CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	12	E39 (Front RH)	4	Existed
	27	E22 (Front LH)	2	
	15	B41 (Rear RH)	8	
	30	B44 (Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	E39 (Front RH)	3	Existed
	23	E22 (Front LH)	1	
	11	B41 (Rear RH)	7	
	26	B44 (Rear LH)	5	

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	12, 21	E36	3, 4	Not existed
	27, 23			
	15, 11			
	30, 26			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

## 5.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.

**CAUTION:**

**Never start engine.**

5. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1105", "C1106", "C1107" or "C1108" detected?

YES >> Replace ABS actuator and electric unit (control unit).

# C1105, C1106, C1107, C1108 WHEEL SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

NO >> INSPECTION END

## Component Inspection

INFOID:000000005255402

### 1.CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-21, "Diagnosis Procedure"](#).

BRC

# C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

## C1109 POWER AND GROUND SYSTEM

### Description

INFOID:000000005255403

Supplies electric power to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005255404

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1109	BATTERY VOLTAGE [ABNORMAL]	When the ABS actuator and electric unit (control unit) power supply is lower than normal and vehicle speed is greater than 6km/h (4 MPH). Power supply is greater than normal limits.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li><li>• Fuse</li><li>• Vehicle electrical power system</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
BATTERY VOLTAGE [ABNORMAL]

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-24, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255405

#### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Repair or replace connector.

#### 2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Turn ignition switch ON or OFF and check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E36	16	Ground	Ignition switch: ON	Battery voltage
			Ignition switch: OFF	Approx. 0 V

4. Check 10A fusible link (59).
5. Check continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R.



# C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

ABS actuator and electric unit (control unit)		IPDM E/R		continuity
Connector	Terminal	Connector	Terminal	
E36	16	E15	59	Existed

6. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

## 3.ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

1. Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 16 and 4. With ignition switch ON check bulb illuminates correctly.
2. Check ABS motor supply under loaded condition (connector E36 terminals 1 and 3).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

## 4.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Check battery for terminal looseness, low voltage, etc. if any malfunction is found, repair malfunctioning parts.

NO >> Repair or replace malfunctioning components (check ABS earth bolt for tightness and corrosion).

# C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

## C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### Description

INFOID:000000005255406

ABS unit is continuously monitoring ECU hardware and software for correct operation.

### DTC Logic

INFOID:000000005255407

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1110	CONTROLLER FAILURE	Possible internal failure of control unit components.	Internal failure of control unit components. ABS solenoid valve or motor power supply/ ground abnormality.

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

1. Check both ABS solenoid valve and motor supply and ground circuits using a suitable electrical load.
2. Check wheel speed sensor inputs.
3. Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
CONTROLLER FAILURE

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-26. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255408

#### 1.REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

#### **CAUTION:**

**Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.**

>> Replace ABS actuator and electric unit (control unit).

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

## C1111 ABS MOTOR, MOTOR RELAY SYSTEM

### Description

INFOID:000000005255409

#### PUMP

The pump returns the brake fluid stored in the reservoir to the master cylinder by reducing the pressure.

#### MOTOR

The motor drives the pump according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005255410

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1111	PUMP MOTOR	During the actuator motor operating with ON, when the actuator motor turns OFF, or when the control line for actuator motor relay is open.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li></ul>
		During the actuator motor operating with OFF, when the actuator motor turns ON, or when the control line for relay is shorted to ground.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
PUMP MOTOR

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-27, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255411

#### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnect, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2.CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between the ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	1	Ground	Battery voltage

4. Reconnect ABS actuator and electric unit (control unit) connector.

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

[ABS]

## < DTC/CIRCUIT DIAGNOSIS >

### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace malfunctioning components.

### 3.ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 1 and 2. With ignition switch ON check bulb illuminates correctly.

### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Check both power supply and ground circuit.

### 4.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

### Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).  
NO >> Repair or replace malfunctioning components. (Check ABS each bolt for tightness and corrosion).

## Component Inspection

INFOID:0000000005255412

### 1.CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and "ABS MOTOR" in order with CONSULT-III.
2. Select "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY (Note)	On	On

#### NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

### Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Go to diagnosis procedure. Refer to [BRC-27. "Diagnosis Procedure"](#).

# C1113 G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

## C1113 G SENSOR

### Description

INFOID:000000005255413

G sensor detects G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

### DTC Logic

INFOID:000000005255414

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1113	G SENSOR	G sensor is malfunctioning, or signal line of G sensor is open or shorted.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li><li>• G sensor</li><li>• Electrical interference</li><li>• Vehicle driven on AWD rolling road</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
G SENSOR

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-29. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255415

#### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect G sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2.CHECK G SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect G sensor connector.
4. Check continuity between G sensor harness connector terminals and ABS actuator and electric unit (control unit) harness connector terminals.

ABS actuator and electric unit (control unit)		G sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	13	B32	2	Existed
	29		3	
	14		4	
	28		5	

# C1113 G SENSOR

[ABS]

## < DTC/CIRCUIT DIAGNOSIS >

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

### 3.CHECK G SENSOR POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between G sensor harness connector terminal and ground.

G sensor		—	Condition	Voltage
Connector	Terminal			
B32	1	Ground	Ignition switch: ON	Battery voltage
			Ignition switch: OFF	Approx. 0 V

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

### 4.CHECK G SENSOR

1. Remove G sensor from the vehicle. Refer to [BRC-71, "Exploded View"](#).
2. Connect the following terminals between G sensor and connector.

G sensor	Harness connector	
Terminal	Connector	Terminal
1	B32	1
2		2
3		3
4		4
5		5

3. Turn ignition switch ON.
4. Check voltage between G sensor terminals.

Condition	G sensor	
	Terminals 4 – 5	Terminals 3 – 5
Horizontal	1.50 – 1.95 V	1.50 – 1.95 V
Longitudinally 20°	3.51 – 4.14 V	3.51 – 4.14 V
Longitudinally 40°	1.50 – 1.95 V	3.51 – 4.14 V

### Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Replace G sensor.

## Component Inspection

INFOID:000000005255416

### 1.CHECK DATA MONITOR

Select “ABS”, “DATA MONITOR”, “DECEL G-SEN1” and “DECEL G-SEN2”, in order with CONSULT-III and check G sensor signal.

Monitor item	Condition	DATA MONITOR
DECEL G-SEN1	Changes according to an indication shown by the decel G sensor	On
		Off
DECEL G-SEN2	Changes according to an indication shown by the decel G sensor	On
		Off

## C1113 G SENSOR

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-29. "Diagnosis Procedure"](#).

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

## C1115 WHEEL SENSOR

## Description

INFOID:000000005255417

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

## DTC Logic

INFOID:000000005255418

## DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1115	ABS SENSOR [ABNORMAL SIGNAL]	Miss-match between the 4 wheel speed sensor signals.	Harness or connector not a possible cause. Other possible causes tire radius (due to wrong size or pressure) interference.

## DTC CONFIRMATION PROCEDURE

## 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
ABS SENSOR [ABNORMAL SIGNAL]

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-32. "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

## Diagnosis Procedure

INFOID:000000005255419

**CAUTION:**

**Never check between wheel sensor terminals.**

## 1.CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

- YES >> GO TO 2.  
 NO >> Adjust air pressure, or replace tire.

## 2.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check that there is no deformation, misalignment, float, and backlash on the wheel sensor and wheel sensor mounting surface.
- Check that the wheel sensor is installed with no misalignment and backlash.

Are the sensor and sensor rotor normal?

- YES >> GO TO 3.  
 NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

## 3.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 4.



# C1115 WHEEL SENSOR

[ABS]

## < DTC/CIRCUIT DIAGNOSIS >

NO >> Poor connection of connector terminal. Repair or replace connector.

### 4.CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	12	E39 (Front RH)	4	Existed
	27	E22 (Front LH)	2	
	15	B41 (Rear RH)	8	
	30	B44 (Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	E39 (Front RH)	3	Existed
	23	E22 (Front LH)	1	
	11	B41 (Rear RH)	7	
	26	B44 (Rear LH)	5	

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	12, 21	E36	3, 4	Not existed
	27, 23			
	15, 11			
	30, 26			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

### 5.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.

**CAUTION:**

**Never start engine.**

5. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "C1115" detected?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> INSPECTION END

## Component Inspection

INFOID:0000000005255420

### 1.CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR", and check the vehicle speed.

# C1115 WHEEL SENSOR

[ABS]

## < DTC/CIRCUIT DIAGNOSIS >

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

### Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to diagnosis procedure. Refer to [BRC-32, "Diagnosis Procedure"](#).

# C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

## C1120, C1122, C1124, C1126 IN ABS SOL

### Description

INFOID:000000005255421

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005255422

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1120	FR LH IN ABS SOL	When the control unit detects a malfunction in the front LH inlet solenoid circuit.	ABS actuator and electric unit (control unit)
C1122	FR RH IN ABS SOL	When the control unit detects a malfunction in the front RH inlet solenoid circuit.	
C1124	RR LH IN ABS SOL	When the control unit detects a malfunction in the rear LH inlet solenoid circuit.	
C1126	RR RH IN ABS SOL	When the control unit detects a malfunction in the rear RH inlet solenoid circuit.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
FR LH IN ABS SOL
FR RH IN ABS SOL
RR LH IN ABS SOL
RR RH IN ABS SOL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-35. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255423

#### 1.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

- YES >> GO TO 2.  
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

#### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.  
NO >> Poor connection of connector terminal. Replace or repair connector.

**< DTC/CIRCUIT DIAGNOSIS >**
**3.CHECK ACTUATOR RELAY POWER SUPPLY CIRCUIT**

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

**4.CHECK ACTUATOR RELAY GROUND CIRCUIT**

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

**Component Inspection**

INFOID:000000005255424

**1.CHECK ACTIVE TEST**

1. Select "ABS", "ACTIVE TEST" and each test item in order with CONSULT-III.
2. On the display, select "Up", "Keep" and "Down", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*

\*: On for 1 to 2 seconds after the select, and then Off.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-35, "Diagnosis Procedure"](#).

# C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

## C1121, C1123, C1125, C1127 OUT ABS SOL

### Description

INFOID:000000005255425

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005255426

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1121	FR LH OUT ABS SOL	When the control unit detects a malfunction in the front LH outlet solenoid circuit.	ABS actuator and electric unit (control unit)
C1123	FR RH OUT ABS SOL	When the control unit detects a malfunction in the front RH outlet solenoid circuit.	
C1125	RR LH OUT ABS SOL	When the control unit detects a malfunction in the rear LH outlet solenoid circuit.	
C1127	RR RH OUT ABS SOL	When the control unit detects a malfunction in the rear RH outlet solenoid circuit.	

#### DTC CONFIRMATION PROCEDURE

##### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
FR LH OUT ABS SOL
FR RH OUT ABS SOL
RR LH OUT ABS SOL
RR RH OUT ABS SOL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-37. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255427

##### 1.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

- YES >> GO TO 2.  
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

##### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.  
NO >> Poor connection of connector terminal. Replace or repair connector.

# C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

## 3.CHECK ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

## 4.CHECK ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000005255428

## 1.CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and each test item in order with CONSULT-III.
2. On the display, select "Up", "Keep" and "Down", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*

\*: On for 1 to 2 seconds after the select, and then Off.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-37, "Diagnosis Procedure"](#).

# C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

## C1140 ACTUATOR RELAY SYSTEM

### Description

INFOID:000000005255429

Activates or deactivates each solenoid valve according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005255430

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1140	ACTUATOR RLY	During the actuator relay operating with OFF, when the actuator relay turns ON, or when the control line for the relay is shorted to the ground.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li></ul>
		During the actuator relay operating with ON, when the actuator relay turns ON, or when the control line for the relay is open.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
ACTUATOR RLY

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-39, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255431

#### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2.CHECK ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

4. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace malfunctioning components.

# C1140 ACTUATOR RELAY SYSTEM

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

## 3.ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 1 and 3. With ignition switch ON check bulb illuminates correctly.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

## 4.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components. (Check ABS each bolt for tightness and corrosion).

## Component Inspection

INFOID:000000005255432

## 1.CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and "ABS MOTOR" in order with CONSULT-III,
2. Select "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY (Note)	On	On

### NOTE:

A brief moment of On/Off condition occurs every 20 seconds after ignition switch turned ON. This is not malfunction because it is an operation for checking.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-39. "Diagnosis Procedure"](#).



## U1000 CAN COMM CIRCUIT

## Description

INFOID:0000000005255433

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## DTC Logic

INFOID:0000000005255434

## DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or more.	<ul style="list-style-type: none"> <li>CAN communication line</li> <li>ABS actuator and electric unit (control unit)</li> </ul>

BRC

## DTC CONFIRMATION PROCEDURE

## 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
CAN COMM CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-41, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

## Diagnosis Procedure

INFOID:0000000005255435

## 1.CHECK CONNECTOR

- Turn ignition switch OFF.
- Disconnect ABS actuator and electric unit (control unit) connector.
- Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
- Reconnect connector and perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
CAN COMM CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Go to [LAN-16, "Trouble Diagnosis Flow Chart"](#).  
 NO >> INSPECTION END

# U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

## U1010 CONTROL UNIT (CAN)

### Description

INFOID:000000005255436

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### DTC Logic

INFOID:000000005255437

### DTC DETECTION LOGIC

DTC	Items	Diagnostic item is detected when...	Possible cause
U1010	CONTROL UNIT (CAN)	When detecting error during the initial diagnosis of CAN controller of ABS actuator and electric unit (control unit).	ABS actuator and electric unit (control unit) error

### DTC CONFIRMATION PROCEDURE

#### 1.RECHECK DTC

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "U1010" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-42. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255438

#### 1.ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Check that there is no malfunction in ABS actuator and electric unit (control unit) harness connector or disconnection.

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).  
NO >> Repair or replace the harnesses and connectors.

# BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

## BRAKE FLUID LEVEL SWITCH

### Description

INFOID:000000005255439

The brake fluid level switch converts the brake fluid level to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

### Component Function Check

INFOID:000000005255440

#### 1.CHECK BRAKE FLUID LEVEL SWITCH OPERATION

Operate the brake fluid level switch. Then check that the brake warning lamp in the combination meter turns on/off correctly.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-43. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005255441

#### 1.CHECK BRAKE FLUID LEVEL

Check brake fluid level. Refer to [BR-12. "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Refill brake fluid. Refer to [BR-12. "Refilling"](#).

#### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector and combination meter connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform component function check. Refer to [BRC-43. "Component Function Check"](#).

Is the inspection result normal?

YES >> Poor connection of connector terminal. Replace or repair connector.

NO >> GO TO 3.

#### 3.CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

Brake fluid level switch		Condition	Continuity
Connector	Terminal		
E37	1 – 2	When brake fluid is full in the reservoir tank.	Not existed
		When brake fluid is empty in the reservoir tank.	Existed

Is the inspection result normal?

YES >> GO TO 4.

NO >> Brake fluid level switch is malfunction. Replace reservoir tank.

#### 4.CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between brake fluid level switch harness connector terminals and combination meter harness connector terminal and/or ground.

# BRAKE FLUID LEVEL SWITCH

[ABS]

## < DTC/CIRCUIT DIAGNOSIS >

Combination meter		Brake fluid level switch		Continuity
Connector	Terminal	Connector	Terminal	
M34	27	E37	1	Existed

Combination meter		—	Continuity
Connector	Terminal		
M34	27	Ground	Not existed

Brake fluid level switch		—	Continuity
Connector	Terminal		
E37	2	Ground	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:0000000005255442

### 1. CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

Brake fluid level switch		Condition	Continuity
Connector	Terminal		
E37	1 – 2	When brake fluid is full in the reservoir tank.	Not existed
		When brake fluid is empty in the reservoir tank.	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace reservoir tank.

# PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

## PARKING BRAKE SWITCH

### Description

INFOID:000000005255443

The parking brake switch converts the status of the parking brake pedal to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

### Component Function Check

INFOID:000000005255444

#### 1.CHECK PARKING BRAKE SWITCH OPERATION

Operate the parking brake pedal. Then check that the brake warning lamp in the combination meter turns on/off correctly.

Condition	Brake warning lamp illumination status
When the parking brake switch is operation	ON
When the parking brake switch is not operation.	OFF

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-45, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005255445

#### 1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch connector terminal and ground.

Parking brake switch		Condition	Continuity
Connector	Terminal		
E103	1 – Ground	When the parking brake switch is operated.	Existed
		When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace parking brake switch.

#### 2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-32, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace combination meter.

### Component Inspection

INFOID:000000005255446

#### 1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch connector terminal and ground.

## PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

Parking brake switch		Condition	Continuity
Connector	Terminal		
E103	1 – Ground	When the parking brake switch is operated.	Existed
		When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch. Refer to [PB-6, "Exploded View"](#).

# ABS WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[ABS]

## ABS WARNING LAMP

### Description

INFOID:000000005255447

×: ON –: OFF

Condition	ABS warning lamp
Ignition switch OFF	–
For 1 second after turning ignition switch ON	×
1 second later after turning ignition switch ON	–
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

### Component Function Check

INFOID:000000005255448

#### 1.CHECK ABS WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-47. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005255449

#### 1.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

#### 2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-32. "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

# BRAKE WARNING LAMP

[ABS]

< DTC/CIRCUIT DIAGNOSIS >

## BRAKE WARNING LAMP

### Description

INFOID:000000005255450

×: ON –: OFF

Condition	Brake warning lamp (Note 1)
Ignition switch OFF	–
For 1 second after turning ignition switch ON	× (Note 2)
1 second later after turning ignition switch ON	× (Note 2)
EBD function is malfunctioning.	×

#### NOTE:

- 1: Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- 2: After starting engine, brake warning lamp is turned off.

### Component Function Check

INFOID:000000005255451

#### 1.BRAKE WARNING LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to diagnosis procedure. Refer to [BRC-48. "Diagnosis Procedure"](#).

#### 2.BRAKE WARNING LAMP OPERATION CHECK 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check parking brake switch. Refer to [BRC-45. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005255452

#### 1.CHECK PARKING BRAKE SWITCH

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking brake switch. Refer to [BRC-45. "Diagnosis Procedure"](#).

#### 2.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check items displayed by self-diagnosis.

#### 3.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-32. "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.



# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[ABS]

## ECU DIAGNOSIS INFORMATION

### ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

#### Reference Value

INFOID:0000000005255453

#### VALUES ON THE DIAGNOSIS TOOL

##### CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short-circuited.

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
FR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
FR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
RR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
RR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
STOP LAMP SW	Stop lamp switch signal status	When brake pedal is depressed	On
		When brake pedal is not depressed	Off
BATTERY VOLT	Battery voltage supplied to the ABS actuator and electric unit (control unit)	Ignition switch ON	10 – 16 V
DECEL G-SEN1 (Note 2)	Decel G detected by decel G sensor	Changes according to an indication shown by the decel G sensor	On
			Off
DECEL G-SEN2 (Note 2)	Decel G detected by decel G sensor	Changes according to an indication shown by the decel G sensor	On
			Off
FR RH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR RH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[ABS]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
FR LH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR LH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR RH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR RH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR LH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR LH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
MOTOR RELAY	Motor and motor relay operation	When the motor relay and motor are operating	On
		When the motor relay and motor are not operating	Off
ACTUATOR RLY (Note 3)	Actuator relay operation	When the actuator relay is operating	On
		When the actuator relay is not operating	Off
ABS WARN LAMP	ABS warning lamp (Note 4)	When ABS warning lamp is ON	On
		When ABS warning lamp is OFF	Off
EBD SIGNAL	EBD operation	EBD is active	On
		EBD is inactive	Off
ABS SIGNAL	ABS operation	ABS is active	On
		ABS is inactive	Off
EBD FAIL SIG	EBD fail-safe signal	In EBD fail-safe	On
		EBD is normal	Off

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[ABS]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
ABS FAIL SIG	ABS fail-safe signal	In ABS fail-safe	On
		ABS is normal	Off

## NOTE:

- 1: Confirm tire pressure is normal.
- 2: Only AWD models.
- 3: Every 20 seconds momentary switch to Off.
- 4: On and off timing for warning lamp and indicator lamp.
- ABS warning lamp: Refer to [BRC-47, "Description"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC


# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[ABS]

## Wiring Diagram -BRAKE CONTROL SYSTEM-

INFOID:000000005255454





# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[ABS]

## BRAKE CONTROL SYSTEM (WITHOUT VDC)

Connector No.	B11
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-CS16-TM4



Connector No.	B32
Connector Name	G SENSOR
Connector Type	YD20FW



Terminal No.	Color of Wire	Signal Name [Specification]
12	BR	-
13	O	-
22	G	-
23	SB	-
31	GR	-
33	L	-
34	B	-
62	Y	-
63	R	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	GR	IGN
2	B	GST
3	R	GS2
4	L	GS1
5	Y	GND

Connector No.	B41
Connector Name	REAR WHEEL SENSOR RH
Connector Type	RK02FGY



Connector No.	B44
Connector Name	REAR WHEEL SENSOR LH
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
5	BR	-
6	G	-

Connector No.	E15
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS18FW-CS



Connector No.	E22
Connector Name	FRONT WHEEL SENSOR LH
Connector Type	RK02MGY



16	BR	IGN
21	G	FR SENSOR VB
22	L	CAN H
23	W	FL SENSOR VB
24	GR	DIAG K
26	BR	RL SENSOR VB
27	P	FL SENSOR SIG
28	Y	G GND
29	R	G SW2
30	G	RL SENSOR SIG

Terminal No.	Color of Wire	Signal Name [Specification]
59	BR	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	W	-
2	P	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	MOTOR
2	BR	ACTR
3	B	GND A
4	B	GND M
8	SB	STOP LAMP SW
9	P	CAN L
11	O	RR SENSOR VB
12	R	FR SENSOR SIG
13	B	G CHECK
14	L	G SW1
15	SB	RR SENSOR SIG

JCFWM0260Gf

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[ABS]

## BRAKE CONTROL SYSTEM (WITHOUT VDC)

Connector No.	E37
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	XY02EGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	B	-

Connector No.	E39
Connector Name	FRONT WHEEL SENSOR RH
Connector Type	BK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
3	G	-
4	R	-

Connector No.	E101
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS18-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
12	BR	-
13	O	-
22	G	-
23	SB	-
51	GR	-
53	L	-
54	B	-
62	Y	-
63	R	-

Connector No.	E103
Connector Name	PARKING BRAKE SWITCH
Connector Type	P01FB-A



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CS18-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
4	V	-
12	P	-
15	V	-
21	L	-
22	L	-
24	LG	-

Connector No.	E115
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LC



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	Y	-
3	G	-
4	L	-

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	BD16FW



Terminal No.	Color of Wire	Signal Name [Specification]
7	O	-

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L
26	V	PARKING BRAKE SW
27	BR	BRAKE FLUID LEVEL SE

JCFWM0261Gt

**[ABS]**

A  
B  
C  
D  
E  
**BR**  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



INFOID:0000000005255455

## ABS, EBD SYSTEM

Revision: 2009 October

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[ABS]

## < ECU DIAGNOSIS INFORMATION >

- For malfunction of ABS, only the EBD is activated and the condition of vehicle is the same condition of vehicles without ABS system.

### NOTE:

ABS self-diagnosis sound may be heard. That is a normal condition because a self-diagnosis for "Ignition switch ON" and "The first starting" are being performed.

- For malfunction of EBD, EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without ABS, EBD system.

## DTC Index

INFOID:000000005255456

DTC	Items (CONSULT screen terms)	Reference
C1101	RR RH SENSOR-1	<a href="#">BRC-18, "DTC Logic"</a>
C1102	RR LH SENSOR-1	
C1103	FR RH SENSOR-1	
C1104	FR LH SENSOR-1	
C1105	RR RH SENSOR-2	<a href="#">BRC-21, "DTC Logic"</a>
C1106	RR LH SENSOR-2	
C1107	FR RH SENSOR-2	
C1108	FR LH SENSOR-2	
C1109	BATTERY VOLTAGE [ABNORMAL]	<a href="#">BRC-24, "DTC Logic"</a>
C1110	CONTROLLER FAILURE	<a href="#">BRC-26, "DTC Logic"</a>
C1111	PUMP MOTOR	<a href="#">BRC-27, "DTC Logic"</a>
C1113	G SENSOR	<a href="#">BRC-29, "DTC Logic"</a>
C1115	ABS SENSOR [ABNORMAL SIGNAL]	<a href="#">BRC-32, "DTC Logic"</a>
C1120	FR LH IN ABS SOL	<a href="#">BRC-35, "DTC Logic"</a>
C1121	FR LH OUT ABS SOL	<a href="#">BRC-37, "DTC Logic"</a>
C1122	FR RH IN ABS SOL	<a href="#">BRC-35, "DTC Logic"</a>
C1123	FR RH OUT ABS SOL	<a href="#">BRC-37, "DTC Logic"</a>
C1124	RR LH IN ABS SOL	<a href="#">BRC-35, "DTC Logic"</a>
C1125	RR LH OUT ABS SOL	<a href="#">BRC-37, "DTC Logic"</a>
C1126	RR RH IN ABS SOL	<a href="#">BRC-35, "DTC Logic"</a>
C1127	RR RH OUT ABS SOL	<a href="#">BRC-37, "DTC Logic"</a>
C1140	ACTUATOR RLY	<a href="#">BRC-39, "DTC Logic"</a>
U1000	CAN COMM CIRCUIT	<a href="#">BRC-41, "DTC Logic"</a>
U1010	CONTROL UNIT (CAN)	<a href="#">BRC-42, "DTC Logic"</a>



# EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

< SYMPTOM DIAGNOSIS >

[ABS]

## SYMPTOM DIAGNOSIS

### EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

#### Diagnosis Procedure

INFOID:000000005255457

#### 1.CHECK START

Check front and rear brake force distribution using a brake tester. Refer to [BR-49, "General Specifications"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

#### 2.CHECK FRONT AND REAR AXLE

Make sure that there is no excessive play in the front and rear axles.

- Front

- 2WD models: Refer to [FAX-8, "Inspection"](#).

- AWD models: Refer to [FAX-32, "Inspection"](#).

- Rear

- 2WD models: Refer to [RAX-4, "Inspection"](#).

- AWD models: Refer to [RAX-11, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

#### 3.CHECK WHEEL SENSOR AND SENSOR ROTOR

Check the following.

- Wheel sensor installation for damage.

- Sensor rotor installation for damage.

- Wheel sensor connector connection.

- Wheel sensor harness inspection.

Is the inspection result normal?

YES >> GO TO 4.

NO >> 

- Replace wheel sensor or sensor rotor.
- Repair harness.

#### 4.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned off after the ignition switch is turned ON or when driving.

Is the ABS warning lamp illuminated?

YES >> Perform self-diagnosis for "ABS" with CONSULT-III.

NO >> Normal

# UNEXPECTED PEDAL REACTION

[ABS]

< SYMPTOM DIAGNOSIS >

## UNEXPECTED PEDAL REACTION

### Diagnosis Procedure

INFOID:000000005255458

#### 1.CHECK BRAKE PEDAL STROKE

Check brake pedal stroke. Refer to [BR-9, "Inspection and Adjustment"](#).

Is the stroke too large?

- YES >> • Bleed air from brake tube and hose. Refer to [BR-13, "Bleeding Brake System"](#).  
• Check brake pedal, brake booster, and master cylinder for mount play, looseness, brake system fluid leakage, etc.  
- Brake pedal: Refer to [BR-9, "Inspection and Adjustment"](#).  
- Master cylinder: Refer to [BR-14, "Inspection"](#).  
- Brake booster: Refer to [BR-15, "Inspection"](#).

NO >> GO TO 2.

#### 2.CHECK FUNCTION

Disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. Check if braking force is normal in this condition. Connect connector after inspection.

Is the inspection result normal?

- YES >> Normal  
NO >> Check brake system.

## THE BRAKING DISTANCE IS LONG

< SYMPTOM DIAGNOSIS >

[ABS]

### THE BRAKING DISTANCE IS LONG

#### Diagnosis Procedure

INFOID:000000005255459

#### **CAUTION:**

The stopping distance on slippery road surfaces might be longer with the ABS operating than when the ABS is not operating.

#### **1.**CHECK FUNCTION

Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. In this condition, check stopping distance. After inspection, connect connector.

Is the inspection result normal?

YES >> Normal

NO >> Check brake system.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

## ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[ABS]

---

### ABS FUNCTION DOES NOT OPERATE

#### Diagnosis Procedure

INFOID:0000000005255460

**CAUTION:**

**ABS does not operate when speed is 10 km/h (6 MPH) or lower.**

**1**.CHECK ABS WARNING LAMP DISPLAY

---

Make sure that the ABS warning lamp turns OFF after ignition switch is turned ON or when driving.

Is the inspection result normal?

YES    >> Normal

NO     >> Perform self-diagnosis for "ABS" with CONSULT-III.

# PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[ABS]

## PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

### Diagnosis Procedure

INFOID:000000005255461

#### CAUTION:

Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

### 1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Inspect the brake pedal.

### 2. SYMPTOM CHECK 2

Check that there are ABS operation noises when the engine is started.

Do the operation noises occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis for "ABS" with CONSULT-III.

### 3. SYMPTOM CHECK 3

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Do symptoms occur?

YES >> Check if there is a radio, antenna, antenna lead wire, or wiring close to the control unit. If there is, move it farther away.

NO >> Normal

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

## NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[ABS]

### NORMAL OPERATING CONDITION

#### Description

INFOID:000000005255462

Symptom	Result
Slight vibrations are felt on the brake pedal and the operation noises occur, when ABS is activated.	This is a normal condition due to the ABS activation.
Stopping distance is longer than that of vehicles without ABS when the vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.	
The brake pedal vibrates and motor operation noises occur from the engine room, after the engine starts and just after the vehicle starts.	This is a normal, and it is caused by the ABS operation check.

## PRECAUTION

### PRECAUTIONS

#### FOR USA AND CANADA

#### FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005530481

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### FOR USA AND CANADA : Precaution for Procedure without Cowl Top Cover

INFOID:000000005530484

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



#### FOR USA AND CANADA : Precaution for Brake System

INFOID:0000000055255465

#### **WARNING:**

Clean any dust from the front brake and rear brake with a vacuum dust collector. Never blow with compressed air.


- Only use "DOT 3" brake fluid. Refer to [MA-14, "FOR NORTH AMERICA : Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.

## PRECAUTIONS

[ABS]

### < PRECAUTION >

- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crow-foot (A) and torque wrench (B).
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



### FOR USA AND CANADA : Precaution for Brake Control

INFOID:000000005255466

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.

### FOR MEXICO

### FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005530482

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.



## PRECAUTIONS


< PRECAUTION >

[ABS]

### FOR MEXICO : Precaution for Procedure without Cowl Top Cover

INFOID:000000005530486

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.




### FOR MEXICO : Precaution for Brake System

INFOID:000000005255469

#### **WARNING:**

**Clean any dust from the front brake and rear brake with a vacuum dust collector. Never blow with compressed air.**

- Only use "DOT 3" brake fluid. Refer to [MA-15, "FOR MEXICO : Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crow-foot (A) and torque wrench (B).
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



### FOR MEXICO : Precaution for Brake Control

INFOID:000000005255470

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.


## REMOVAL AND INSTALLATION

### WHEEL SENSOR

#### FRONT WHEEL SENSOR

#### FRONT WHEEL SENSOR : Exploded View

INFOID:000000005255471



1. Front LH wheel sensor

A. Yellow line (slant line)

Refer to [GI-4, "Components"](#) for symbol in the figure.

#### NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

#### FRONT WHEEL SENSOR : Removal and Installation

INFOID:000000005255472

#### REMOVAL

Pay attention to the following when removing sensor.

#### CAUTION:

- Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.
- Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.
- When you see the harness of the wheel sensor from the front side of the vehicle ensure that the yellow lines (A) are not twisted.

#### INSTALLATION

Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

#### REAR WHEEL SENSOR


# WHEEL SENSOR

< REMOVAL AND INSTALLATION >

[ABS]

## REAR WHEEL SENSOR : Exploded View

INFOID:0000000005255473



1. Rear LH wheel sensor

A. 2WD models

B. AWD models

Refer to [GI-4, "Components"](#) for symbol in the figure.

### NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

## REAR WHEEL SENSOR : Removal and Installation

INFOID:0000000005255474

### REMOVAL

Pay attention to the following when removing sensor.

#### CAUTION:

- **Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.**
- **Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.**

### INSTALLATION

Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

## SENSOR ROTOR

### FRONT SENSOR ROTOR

#### FRONT SENSOR ROTOR : Exploded View

INFOID:000000005255475

Refer to [FAX-10, "Exploded View"](#) (2WD models), [FAX-34, "Exploded View"](#) (AWD models).

#### FRONT SENSOR ROTOR : Removal and Installation

INFOID:000000005255476

#### REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [FAX-10, "Removal and Installation"](#) (2WD models), [FAX-34, "Removal and Installation"](#) (AWD models).

#### INSTALLATION

Sensor rotor cannot be disassembled. Installation the sensor rotor together with hub bearing assembly. Refer to [FAX-10, "Removal and Installation"](#) (2WD models), [FAX-34, "Removal and Installation"](#) (AWD models).

### REAR SENSOR ROTOR

#### REAR SENSOR ROTOR : Exploded View

INFOID:000000005255477

Refer to [RAX-5, "Exploded View"](#) (2WD models), [RAX-13, "Exploded View"](#) (AWD models).

#### REAR SENSOR ROTOR : Removal and Installation

INFOID:000000005255478

#### 2WD MODELS

##### Removal

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [RAX-5, "Removal and Installation"](#).

##### Installation

Sensor rotor cannot be disassembled. Installation the sensor rotor together with hub bearing assembly. Refer to [RAX-5, "Removal and Installation"](#).

#### AWD MODELS

For removal and installation of sensor rotor, refer to [RAX-16, "Disassembly and Assembly"](#).

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< REMOVAL AND INSTALLATION >

[ABS]

## ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### Exploded View

INFOID:000000005255479



- |  |                                      |  |
|--|--------------------------------------|--|
| 1. ABS actuator and electric unit (control unit) | 2. Connector                         | 3. Bracket                             |
| A. To front LH brake caliper                     | B. To rear RH brake caliper          | C. To Rear LH brake caliper            |
| D. To front RH brake caliper                     | E. From master cylinder primary side | F. From master cylinder secondary side |

⇐: Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

### Removal and Installation

INFOID:000000005255480

#### REMOVAL

##### CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-13, "Bleeding Brake System"](#).

1. Remove cowl top. Refer to [EXT-20, "Exploded View"](#).
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Loosen brake tube flare nuts, then remove brake tubes from ABS actuator and electric unit (control unit).
4. Remove tire (front LH side).
5. Remove fender protector (rear): (front LH side). Refer to [EXT-22, "Exploded View"](#).
6. Remove ABS actuator and electric unit (control unit) bracket mounting nut.
7. Remove ABS actuator and electric unit (control unit) from vehicle.

#### INSTALLATION

## ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

[ABS]

### < REMOVAL AND INSTALLATION >

---

Note the following, and install in the reverse order of removal.

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-13. "Bleeding Brake System"](#).
- After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.

# G SENSOR


< REMOVAL AND INSTALLATION >

[ABS]

## G SENSOR

### Exploded View

INFOID:0000000005255481



1. G sensor
2. Bracket

↔ Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

BRC

### Removal and Installation

INFOID:0000000005255482

#### REMOVAL

##### **CAUTION:**

**Never drop or strike G sensor, or never use power tool etc., because G sensor is sensitive to the impact.**

1. Remove center console assembly. Refer to [IP-21, "Exploded View"](#).
2. Disconnect G sensor harness connector.
3. Remove mounting nuts. Remove G sensor.

#### INSTALLATION

Note the following, and install in the reverse order of removal.

- Never drop or strike G sensor, or never use power tool etc., because G sensor is sensitive to the impact.

## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

#### Work Flow

INFOID:000000005255483

#### PRECAUTIONS FOR DIAGNOSIS

If steering angle sensor, steering system parts, suspension system parts, ABS actuator and electric unit (control unit) or tires have been replaced, or if wheel alignment has been adjusted, be sure to adjust neutral position of steering angle sensor before driving. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).




# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

## OVERALL SEQUENCE



## DETAILED FLOW

### 1.COLLECT THE INFORMATION FROM THE CUSTOMER

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred) using the diagnosis worksheet. Refer to [BRC-75, "Diagnostic Work Sheet"](#).

>> GO TO 2.

# DIAGNOSIS AND REPAIR WORKFLOW

[VDC/TCS/ABS]

< BASIC INSPECTION >

## 2.PERFORM THE SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III. Refer to [BRC-94, "CONSULT-III Function"](#).

Is there any DTC displayed?

YES >> GO TO 3.

NO >> GO TO 4.

## 3.PERFORM THE SYSTEM DIAGNOSIS

Perform the diagnosis applicable to the displayed DTC of "ABS" with CONSULT-III. Refer to [BRC-161, "DTC Index"](#).

>> GO TO 7.

## 4.CHECK THE SYMPTOM THAT IS NOT CONSIDERED A SYSTEM MALFUNCTION

Check that the symptom is a normal operation that is not considered a system malfunction. Refer to [BRC-169, "Description"](#).

Is the symptom a normal operation?

YES >> INSPECTION END

NO >> GO TO 5.

## 5.CHECK THE WARNING LAMP AND INDICATOR LAMP FOR ILLUMINATION

Check that the warning lamp and indicator lamp illuminate.

- ABS warning lamp: Refer to [BRC-147, "Description"](#).
- Brake warning lamp: Refer to [BRC-148, "Description"](#).
- VDC OFF indicator lamp: Refer to [BRC-150, "Description"](#).
- SLIP indicator lamp: Refer to [BRC-152, "Description"](#).

Is ON/OFF timing normal?

YES >> GO TO 6.

NO >> GO TO 2.

## 6.PERFORM THE DIAGNOSIS BY SYMPTOM

Perform the diagnosis applicable to the displayed DTC of "ABS" with CONSULT-III.

>> GO TO 7.

## 7.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 8.

## 8.MEMORY CLEAR

Perform self-diagnosis memory clear for "ABS" with CONSULT-III.

>> GO TO 9.

## 9.FINAL CHECK

Perform the self-diagnosis again, and check that the malfunction is repaired completely.

Is no other DTC present and the repair completed?

YES >> INSPECTION END

NO >> GO TO 3.

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[VDC/TCS/ABS]

## Diagnostic Work Sheet

INFOID:000000005255484

Customer name MR/MS	Model & Year		VIN
Engine #	Trans.		Mileage
Incident Date	Manuf. Date		In Service Date
Symptoms	<input type="checkbox"/> Noise and vibration (from engine compartment) <input type="checkbox"/> Noise and vibration (from axle)	<input type="checkbox"/> Warning / Indicator activate	<input type="checkbox"/> Firm pedal operation Large stroke pedal operation
	<input type="checkbox"/> TCS does not work (Rear wheels slip when accelerating)	<input type="checkbox"/> ABS does not work (Wheels lock when braking)	<input type="checkbox"/> Lack of sense of acceleration
Engine conditions	<input type="checkbox"/> When starting <input type="checkbox"/> After starting		
Road conditions	<input type="checkbox"/> Low friction road ( <input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other ) <input type="checkbox"/> Bumps / potholes		
Driving conditions	<input type="checkbox"/> Full-acceleration <input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped		
Applying brake conditions	<input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually		
Other conditions	<input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Shift change <input type="checkbox"/> Other descriptions		

SFIA3265E

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

## INSPECTION AND ADJUSTMENT

## ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

## ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description

INFOID:000000005255485

In case of doing work that applies to the list below, make sure to adjust neutral position of steering angle sensor before running vehicle.

×: Required —: Not required

Situation	Adjustment of steering angle sensor neutral position
Removing/Installing steering angle sensor	×
Replacing steering angle sensor	×
Removing/Installing steering wheel	×
Replacing steering wheel	×
Removing/Installing steering components	×
Replacing steering components	×
Removing/Installing suspension components	×
Replacing suspension components	×
Change tires to new ones	—
Tire rotation	—
Adjusting wheel alignment	×

## ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement

INFOID:000000005255486

## ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

**CAUTION:**

To adjust neutral position of steering angle sensor, make sure to use CONSULT-III  
(Adjustment cannot be done without CONSULT-III)

**1. ALIGN THE VEHICLE STATUS**

Stop vehicle with front wheels in straight-ahead position.

>> GO TO 2.

**2. PERFORM THE NEUTRAL POSITION ADJUSTMENT FOR THE STEERING ANGLE SENSOR**

1. Select "ABS", "WORK SUPPORT" and "ST ANGLE SENSOR ADJUSTMENT" in order with CONSULT-III.
2. Select "START".

**CAUTION:**

**Never touch steering wheel while adjusting steering angle sensor.**

3. After approximately 10 seconds, select "END".

**NOTE:**

After approximately 60 seconds, it ends automatically.

4. Turn ignition switch OFF, then turn it ON again.

**CAUTION:**

**Be sure to perform above operation.**

>> GO TO 3.

**3. CHECK DATA MONITOR**

1. Run vehicle with front wheels in straight-ahead position, then stop.
2. Select "ABS", "DATA MONITOR" and "STR ANGLE SIG" in order with CONSULT-III, and check steering angle sensor signal.

**STR ANGLE SIG : 0±2.5°**

## INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[VDC/TCS/ABS]

Is the steering angle within the specified range?

YES >> GO TO 4.

NO >> Perform the neutral position adjustment for the steering angle sensor again, GO TO 1.

### 4. ERASE THE SELF-DIAGNOSIS MEMORY

Erase the self-diagnosis memories for "ABS" and "ENGINE" with CONSULT-III.

- "ABS": Refer to [BRC-94, "CONSULT-III Function"](#).
- "ENGINE"
  - For CALIFORNIA: Refer to [EC-107, "CONSULT-III Function"](#).
  - For USA (FEDERAL) and CANADA: Refer to [EC-588, "CONSULT-III Function"](#).
  - For MEXICO: Refer to [EC-1022, "CONSULT-III Function"](#).

Are the memories erased?

YES >> INSPECTION END

NO >> Check the items indicated by the self-diagnosis.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

## System Diagram


The diagram illustrates the vehicle network system architecture. At the top, four main control units are connected to a central CAN communication line: ECM (Engine Control Module), TCM (Transmission Control Module), Steering angle sensor, and a Combination meter (which includes the Brake warning lamp, ABS warning lamp, VDC OFF indicator lamp, and SLIP indicator lamp). The ECM is also connected to the Injector operation signal. The TCM is connected to the AWD communication line. The AWD communication line connects to the AWD control unit (With AWD), Yaw rate/side/decel G sensor, and VDC OFF switch. The ABS actuator and electric unit (control unit) is connected to the Front RH wheel sensor, Front LH wheel sensor, and Rear RH wheel sensor. The Rear LH wheel sensor is also connected to the AWD communication line. The combination meter is connected to the VDC OFF switch.

INFOID:000000005255488

- Vehicle Dynamics Control system detects driver's steering operation amount and brake pedal travel from steering angle sensor and pressure sensor. Using information from yaw rate/side/decel G sensor and wheel sensor, VDC judges driving condition (conditions of under steer and over steer) to improve vehicle driving stability by controlling brake application to 4 wheels and engine output.
- During VDC operation, it informs driver of system operation by flashing SLIP indicator lamp.
- Electrical system diagnosis by CONSULT-III is available.

INFOID:0000000005255489

FOR USA




- |  |                                    |                                 |
|--|------------------------------------|---------------------------------|
| 1. Steering angle sensor                         | 2. ABS warning lamp                | 3. Brake warning lamp           |
| 4. VDC OFF indicator lamp                        | 5. SLIP indicator lamp             | 6. Yaw rate/side/decel G sensor |
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor              | 9. VDC OFF switch               |
| 10. Rear wheel sensor (2WD models)               | 11. Rear wheel sensor (AWD models) |                                 |

## &lt; SYSTEM DESCRIPTION &gt;

- |                                  |                      |                                  |
|----------------------------------|----------------------|----------------------------------|
| A. Back of spiral cable assembly | B. Combination meter | C. Center console                |
| D. Engine room (right side)      | E. Steering knuckle  | F. Instrument driver lower panel |
| G. Rear axle                     |                      |                                  |

EXCEPT FOR USA



- |                           |                        |                                 |
|---------------------------|------------------------|---------------------------------|
| 1. Steering angle sensor  | 2. ABS warning lamp    | 3. Brake warning lamp           |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Yaw rate/side/decel G sensor |



## &lt; SYSTEM DESCRIPTION &gt;

- |  |                                    |                                  |
|--|------------------------------------|----------------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor              | 9. VDC OFF switch                |
| 10. Rear wheel sensor (2WD models)               | 11. Rear wheel sensor (AWD models) |                                  |
| A. Back of spiral cable assembly                 | B. Combination meter               | C. Center console                |
| D. Engine room (right side)                      | E. Steering knuckle                | F. Instrument driver lower panel |
| G. Rear axle                                     |                                    |                                  |

## Component Description


INFOID:000000005255490

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-109, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-128, "Description"</a>
	Solenoid valve	<a href="#">BRC-121, "Description"</a>
	VDC switch-over valve (CV1, CV2)	<a href="#">BRC-135, "Description"</a>
	VDC switch-over valve (SV1, SV2)	<a href="#">BRC-137, "Description"</a>
Wheel sensor		<a href="#">BRC-99, "Description"</a>
Yaw rate/side/decel G sensor		<a href="#">BRC-111, "Description"</a>
Steering angle sensor		<a href="#">BRC-130, "Description"</a>
VDC OFF switch		<a href="#">BRC-145, "Description"</a>
ABS warning lamp		<a href="#">BRC-147, "Description"</a>
Brake warning lamp		<a href="#">BRC-148, "Description"</a>
VDC OFF indicator lamp		<a href="#">BRC-150, "Description"</a>
SLIP indicator lamp		<a href="#">BRC-152, "Description"</a>

## TCS

## System Diagram

INFOID:000000005255491



## System Description


INFOID:000000005255492

- Traction Control System is a function that electronically controls engine torque, brake fluid pressure and CVT shift position to ensure the optimum slippage ratio at drive wheels by computing wheel speed signals from 4 wheel sensors. When ABS actuator and electric unit (control unit) detects a spin at drive wheels (rear wheels), it compares wheel speed signals from all 4 wheels. At this time, LH and RH rear brake fluid pressure are controlled, while fuel being cut to engine and throttle valve being closed to reduce engine torque by the control unit. Further more, throttle position is continuously controlled to ensure the optimum engine torque at all times.
- During TCS operation, it informs driver of system operation by flashing SLIP indicator lamp.
- Electrical system diagnosis by CONSULT-III is available.

## Component Parts Location

INFOID:000000005255493

FOR USA




- |  |                                    |                                 |
|--|------------------------------------|---------------------------------|
| 1. Steering angle sensor                         | 2. ABS warning lamp                | 3. Brake warning lamp           |
| 4. VDC OFF indicator lamp                        | 5. SLIP indicator lamp             | 6. Yaw rate/side/decel G sensor |
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor              | 9. VDC OFF switch               |
| 10. Rear wheel sensor (2WD models)               | 11. Rear wheel sensor (AWD models) |                                 |

## < SYSTEM DESCRIPTION >

- |                                  |                      |                                  |
|----------------------------------|----------------------|----------------------------------|
| A. Back of spiral cable assembly | B. Combination meter | C. Center console                |
| D. Engine room (right side)      | E. Steering knuckle  | F. Instrument driver lower panel |
| G. Rear axle                     |                      |                                  |

EXCEPT FOR USA



- |                           |                        |                                 |
|---------------------------|------------------------|---------------------------------|
| 1. Steering angle sensor  | 2. ABS warning lamp    | 3. Brake warning lamp           |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Yaw rate/side/decel G sensor |

- |  |                                    |                                  |
|--|------------------------------------|----------------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor              | 9. VDC OFF switch                |
| 10. Rear wheel sensor (2WD models)               | 11. Rear wheel sensor (AWD models) |                                  |
| A. Back of spiral cable assembly                 | B. Combination meter               | C. Center console                |
| D. Engine room (right side)                      | E. Steering knuckle                | F. Instrument driver lower panel |
| G. Rear axle                                     |                                    |                                  |

## Component Description


INFOID:000000005255494

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-109, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-128, "Description"</a>
	Solenoid valve	<a href="#">BRC-121, "Description"</a>
	VDC switch-over valve (CV1, CV2)	<a href="#">BRC-135, "Description"</a>
	VDC switch-over valve (SV1, SV2)	<a href="#">BRC-137, "Description"</a>
Wheel sensor		<a href="#">BRC-99, "Description"</a>
Yaw rate/side/decel G sensor		<a href="#">BRC-111, "Description"</a>
Steering angle sensor		<a href="#">BRC-130, "Description"</a>
VDC OFF switch		<a href="#">BRC-145, "Description"</a>
ABS warning lamp		<a href="#">BRC-147, "Description"</a>
Brake warning lamp		<a href="#">BRC-148, "Description"</a>
VDC OFF indicator lamp		<a href="#">BRC-150, "Description"</a>
SLIP indicator lamp		<a href="#">BRC-152, "Description"</a>

# ABS

## System Diagram

INFOID:000000005255495



## System Description


INFOID:000000005255496

- Anti-Lock Braking System is a function that detects wheel revolution while braking, electronically controls braking force, and prevents wheel locking during sudden braking. It improves handling stability and maneuverability for avoiding obstacles.
- Electrical system diagnosis by CONSULT-III is available.

## Component Parts Location

INFOID:000000005255497

FOR USA



- |  |                                    |                                 |
|--|------------------------------------|---------------------------------|
| 1. Steering angle sensor                         | 2. ABS warning lamp                | 3. Brake warning lamp           |
| 4. VDC OFF indicator lamp                        | 5. SLIP indicator lamp             | 6. Yaw rate/side/decel G sensor |
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor              | 9. VDC OFF switch               |
| 10. Rear wheel sensor (2WD models)               | 11. Rear wheel sensor (AWD models) |                                 |


# ABS

[VDC/TCS/ABS]

## < SYSTEM DESCRIPTION >

- |                                  |                      |                                  |
|----------------------------------|----------------------|----------------------------------|
| A. Back of spiral cable assembly | B. Combination meter | C. Center console                |
| D. Engine room (right side)      | E. Steering knuckle  | F. Instrument driver lower panel |
| G. Rear axle                     |                      |                                  |

EXCEPT FOR USA



- |                           |                        |                                 |
|---------------------------|------------------------|---------------------------------|
| 1. Steering angle sensor  | 2. ABS warning lamp    | 3. Brake warning lamp           |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Yaw rate/side/decel G sensor |



# ABS

[VDC/TCS/ABS]

## < SYSTEM DESCRIPTION >

- |  |                                    |                                  |
|--|------------------------------------|----------------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor              | 9. VDC OFF switch                |
| 10. Rear wheel sensor (2WD models)               | 11. Rear wheel sensor (AWD models) |                                  |
| A. Back of spiral cable assembly                 | B. Combination meter               | C. Center console                |
| D. Engine room (right side)                      | E. Steering knuckle                | F. Instrument driver lower panel |
| G. Rear axle                                     |                                    |                                  |

## Component Description


INFOID:000000005255498

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-109, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-128, "Description"</a>
	Solenoid valve	<a href="#">BRC-121, "Description"</a>
	VDC switch-over valve (CV1, CV2)	<a href="#">BRC-135, "Description"</a>
	VDC switch-over valve (SV1, SV2)	<a href="#">BRC-137, "Description"</a>
Wheel sensor		<a href="#">BRC-99, "Description"</a>
Yaw rate/side/decel G sensor		<a href="#">BRC-111, "Description"</a>
Steering angle sensor		<a href="#">BRC-130, "Description"</a>
VDC OFF switch		<a href="#">BRC-145, "Description"</a>
ABS warning lamp		<a href="#">BRC-147, "Description"</a>
Brake warning lamp		<a href="#">BRC-148, "Description"</a>
VDC OFF indicator lamp		<a href="#">BRC-150, "Description"</a>
SLIP indicator lamp		<a href="#">BRC-152, "Description"</a>

## EBD

## System Diagram

INFOID:000000005255499



## System Description


INFOID:000000005255500

- Electric Brake force Distribution is a following function. ABS actuator and electric unit (control unit) detects subtle slippages between the front and rear wheels during braking. Then is electronically controls the rear braking force (brake fluid pressure) to reducing and reduces rear wheel slippage. Accordingly it improves vehicle stability.
- Electrical system diagnosis by CONSULT-III is available.

## Component Parts Location

INFOID:000000005255501

FOR USA




- |  |                                    |                                 |
|--|------------------------------------|---------------------------------|
| 1. Steering angle sensor                         | 2. ABS warning lamp                | 3. Brake warning lamp           |
| 4. VDC OFF indicator lamp                        | 5. SLIP indicator lamp             | 6. Yaw rate/side/decel G sensor |
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor              | 9. VDC OFF switch               |
| 10. Rear wheel sensor (2WD models)               | 11. Rear wheel sensor (AWD models) |                                 |

## &lt; SYSTEM DESCRIPTION &gt;

- |                                  |                      |                                  |
|----------------------------------|----------------------|----------------------------------|
| A. Back of spiral cable assembly | B. Combination meter | C. Center console                |
| D. Engine room (right side)      | E. Steering knuckle  | F. Instrument driver lower panel |
| G. Rear axle                     |                      |                                  |

EXCEPT FOR USA



- |                           |                        |                                 |
|---------------------------|------------------------|---------------------------------|
| 1. Steering angle sensor  | 2. ABS warning lamp    | 3. Brake warning lamp           |
| 4. VDC OFF indicator lamp | 5. SLIP indicator lamp | 6. Yaw rate/side/decel G sensor |

## &lt; SYSTEM DESCRIPTION &gt;

- |  |                                    |                                  |
|--|------------------------------------|----------------------------------|
| 7. ABS actuator and electric unit (control unit) | 8. Front wheel sensor              | 9. VDC OFF switch                |
| 10. Rear wheel sensor (2WD models)               | 11. Rear wheel sensor (AWD models) |                                  |
| A. Back of spiral cable assembly                 | B. Combination meter               | C. Center console                |
| D. Engine room (right side)                      | E. Steering knuckle                | F. Instrument driver lower panel |
| G. Rear axle                                     |                                    |                                  |

## Component Description

INFOID:000000005255502

Component parts		Reference
ABS actuator and electric unit (control unit)	Pump	<a href="#">BRC-109, "Description"</a>
	Motor	
	Actuator relay (Main relay)	<a href="#">BRC-128, "Description"</a>
	Solenoid valve	<a href="#">BRC-121, "Description"</a>
	VDC switch-over valve (CV1, CV2)	<a href="#">BRC-135, "Description"</a>
	VDC switch-over valve (SV1, SV2)	<a href="#">BRC-137, "Description"</a>
Wheel sensor		<a href="#">BRC-99, "Description"</a>
Yaw rate/side/decel G sensor		<a href="#">BRC-111, "Description"</a>
Steering angle sensor		<a href="#">BRC-130, "Description"</a>
VDC OFF switch		<a href="#">BRC-145, "Description"</a>
ABS warning lamp		<a href="#">BRC-147, "Description"</a>
Brake warning lamp		<a href="#">BRC-148, "Description"</a>
VDC OFF indicator lamp		<a href="#">BRC-150, "Description"</a>
SLIP indicator lamp		<a href="#">BRC-152, "Description"</a>

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

## DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

### CONSULT-III Function

INFOID:000000005255503

#### FUNCTION

CONSULT-III can display each diagnostic item using the diagnostic test modes shown following.

Diagnostic test mode	Function
Work support	This mode enables a technician to adjust some devices faster and more accurately by following the indications on CONSULT-III.
Self diagnostic result	Self-diagnostic results can be read and erased quickly.
Data monitor	Input/Output data in the ABS actuator and electric unit (control unit) can be read.
Active test	Diagnostic test mode is which CONSULT-III drives some actuators apart from the ABS actuator and electric unit (control unit) and also shifts some parameters in a specified range.
ECU identification	ABS actuator and electric unit (control unit) part number can be read.

### WORK SUPPORT

Item	Description
ST ANGLE SENSOR ADJUSTMENT	Adjusts the neutral position of the steering angle sensor.

### SELF DIAGNOSTIC RESULT

#### Operation Procedure

Before performing the self-diagnosis for "ABS" with CONSULT-III, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute.

#### How to Erase Self-diagnosis Results

After erasing DTC memory for "ABS" with CONSULT-III, start engine and drive vehicle at 30 km/h (19 MPH) or more for approximately 1 minute as the final inspection, and make sure that the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp turn OFF.

#### **CAUTION:**

**If memory cannot be erased, perform applicable diagnosis.**

#### **NOTE:**

- When the wheel sensor malfunctions, after inspecting the wheel sensor system, the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp will not turn OFF even when the system is normal unless the vehicle is driving at approximately 30 km/h (19 MPH) or more for approximately 1 minute.
- Brake warning lamp will turn ON in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- VDC OFF switch should not stay "ON" position.

#### Display Item List

Refer to [BRC-161, "DTC Index"](#).

### DATA MONITOR MODE

#### Display Item List

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

×: Applicable ▼: Optional item

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
FR LH SENSOR [km/h (MPH)]	×	×	Wheel speed
FR RH SENSOR [km/h (MPH)]	×	×	
RR LH SENSOR [km/h (MPH)]	×	×	
RR RH SENSOR [km/h (MPH)]	×	×	
STOP LAMP SW (On/Off)	×	×	Stop lamp switch signal status
BATTERY VOLT (V)	×	×	Battery voltage supplied to the ABS actuator and electric unit (control unit)
GEAR	×	×	Gear position determined by TCM
OFF SW (On/Off)	×	×	VDC OFF switch
YAW RATE SEN (d/s)	×	×	Yaw rate detected by yaw rate/side/decel G sensor
DECEL G-SEN (G)	×	×	Decel G detected by yaw rate/side/decel G sensor
ACCEL POS SIG (%)	×	▼	Throttle actuator opening/closing is displayed (Linked with accelerator pedal)
SIDE G-SENSOR (m/s <sup>2</sup> )	×	▼	Transverse G detected by yaw rate/side/decel G sensor
STR ANGLE SIG (°)	×	▼	Steering angle detected by steering angle sensor
ENGINE RPM [tr/min (rpm)]	×	▼	Engine speed
FLUID LEV SW (On/Off)	×	▼	Brake fluid level switch signal status
FR RH IN SOL (On/Off)	▼	×	Operation status of each solenoid valve
FR RH OUT SOL (On/Off)	▼	×	
FR LH IN SOL (On/Off)	▼	×	
FR LH OUT SOL (On/Off)	▼	×	
RR RH IN SOL (On/Off)	▼	×	
RR RH OUT SOL (On/Off)	▼	×	
RR LH IN SOL (On/Off)	▼	×	
RR LH OUT SOL (On/Off)	▼	×	
MOTOR RELAY (On/Off)	▼	×	Motor and motor relay operation
ACTUATOR RLY (On/Off)	▼	×	Actuator relay operation

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

Monitor item (Unit)	SELECT MONITOR ITEM		Remarks
	ECU INPUT SIGNALS	MAIN SIGNALS	
ABS WARN LAMP (On/Off)	▼	×	ABS warning lamp
OFF LAMP (On/Off)	▼	×	VDC OFF indicator lamp
SLIP LAMP (On/Off)	▼	×	SLIP indicator lamp
N POSI SIG (On/Off)	▼	▼	N range status
P POSI SIG (On/Off)	▼	▼	P range status
R POSI SIG (On/Off)	▼	▼	R range status
CRANKING SIG (On/Off)	▼	▼	CAN mask request for cranking
CV1 (On/Off)	▼	▼	Cut valve 1 monitor
CV2 (On/Off)	▼	▼	Cut valve 2 monitor
SV1 (On/Off)	▼	▼	Suction valve 1 monitor
SV2 (On/Off)	▼	▼	Suction valve 2 monitor
STOP LAMP SW2 (On/Off)	▼	▼	ASCD brake switch signal status
EBD SIGNAL (On/Off)	▼	▼	EBD operation
ABS SIGNAL (On/Off)	▼	▼	ABS operation
TCS SIGNAL (On/Off)	▼	▼	TCS operation
VDC SIGNAL (On/Off)	▼	▼	VDC operation
EBD FAIL SIG (On/Off)	▼	▼	EBD fail-safe status
ABS FAIL SIG (On/Off)	▼	▼	ABS fail-safe status
TCS FAIL SIG (On/Off)	▼	▼	TCS fail-safe status
VDC FAIL SIG (On/Off)	▼	▼	VDC fail-safe status
4WD MODE MON (On/Off)	▼	▼	AWD mode monitor

## ACTIVE TEST MODE

### CAUTION:

- Never perform active test while driving vehicle.
- Make sure to completely bleed air from brake system.
- The active test cannot be performed with the ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp are on.
- ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp and brake warning lamp are on during active test.
- Erase memory of ICC system after implementing active test.



# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

## NOTE:

- When active test is performed while depressing the pedal, the pedal depression amount will change. This is normal. (Only solenoid valve and ABS motor.)
- "TEST IS STOPPED" in "ABS" with CONSULT-III is displayed 10 seconds after operation start.
- After "TEST IS STOPPED" in "ABS" with CONSULT-III is displayed, to perform test again.

Test Item

## ABS SOLENOID VALVE

- Select "Up", "Keep" and "Down" of "ACTIVE TEST" in "ABS" with CONSULT-III. Then use screen monitor to check that solenoid valve operates as shown in solenoid valve operation chart.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
	CV1	Off	Off	Off
	SV1	Off	Off	Off
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
	CV2	Off	Off	Off
	SV2	Off	Off	Off
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
	CV2	Off	Off	Off
	SV2	Off	Off	Off
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*
	CV1	Off	Off	Off
	SV1	Off	Off	Off

\*: On for 1 to 2 seconds after the select, and then Off.

## ABS SOLENOID VALVE (ACT)

- Select "Up", "Keep" and "Down" of "ACTIVE TEST" in "ABS" with CONSULT-III. Then use screen monitor to check that solenoid valve operates as shown in solenoid valve operation chart.

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
FR RH ABS SOLENOID (ACT)	FR RH IN SOL	Off	Off	Off
	FR RH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off
FR LH ABS SOLENOID (ACT)	FR LH IN SOL	Off	Off	Off
	FR LH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR RH ABS SOLENOID (ACT)	RR RH IN SOL	Off	Off	Off
	RR RH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off

# DIAGNOSIS SYSTEM [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

< SYSTEM DESCRIPTION >

[VDC/TCS/ABS]

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
RR LH ABS SOLENOID (ACT)	RR LH IN SOL	Off	Off	Off
	RR LH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off

\*: On for 1 to 2 seconds after the select, and then Off.

## ABS MOTOR

- Select “On” and “Off” of “ACTIVE TEST” in “ABS” with CONSULT-III on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY	On	On

## ECU IDENTIFICATION

ABS actuator and electric unit (control unit) part number can be read.

# C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## DTC/CIRCUIT DIAGNOSIS

### C1101, C1102, C1103, C1104 WHEEL SENSOR

#### Description

INFOID:0000000005255504

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

#### DTC Logic

INFOID:0000000005255505

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1101	RR RH SENSOR-1	Circuit of rear RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Wheel sensor</li><li>• ABS actuator and electric unit (control unit)</li></ul>
C1102	RR LH SENSOR-1	Circuit of rear LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1103	FR RH SENSOR-1	Circuit of front RH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	
C1104	FR LH SENSOR-1	Circuit of front LH wheel sensor is open or short circuit. Current signal from sensor is outside limits.	

#### DTC CONFIRMATION PROCEDURE

##### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
RR RH SENSOR-1
RR LH SENSOR-1
FR RH SENSOR-1
FR LH SENSOR-1

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-99. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

#### Diagnosis Procedure

INFOID:0000000005255506

#### CAUTION:

**Never check between wheel sensor terminals.**

##### 1.CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

YES >> GO TO 2.  
NO >> Adjust air pressure, or replace tire.

##### 2.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

YES >> GO TO 3.  
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

# C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## 3.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 4.

NO >> Poor connection of connector terminal. Repair or replace connector.

## 4.CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	12	E39 (Front RH)	4	Existed
	27	E22 (Front LH)	2	
	15	B41 (Rear RH)	8	
	30	B44 (Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	E39 (Front RH)	3	Existed
	23	E22 (Front LH)	1	
	11	B41 (Rear RH)	7	
	26	B44 (Rear LH)	5	

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	12, 21	E36	3, 4	Not existed
	27, 23			
	15, 11			
	30, 26			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

## 5.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.

**CAUTION:**

# C1101, C1102, C1103, C1104 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## Never start engine.

5. Perform self-diagnosis results for "ABS" with CONSULT-III.

IS DTC "C1101", "C1102", "C1103" or "C1104" detected?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> INSPECTION END

## Component Inspection

INFOID:0000000005255507

### 1.CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-99, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:0000000005522786

### 1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

# C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1105, C1106, C1107, C1108 WHEEL SENSOR

### Description

INFOID:000000005255508

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005255509

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1105	RR RH SENSOR-2	Signal from rear RH wheel sensor does not match other 3 wheel speed signal.	<ul style="list-style-type: none"><li>• Sensor not installed currently</li><li>• Sensor rotor or encoder damaged</li><li>• Sensor rotor loose on axle</li><li>• Electrical interference</li><li>• Wheel not turning - e.g. vehicle driven on 2WD dyno</li><li>• Sensor damaged</li><li>• ABS unit damaged</li></ul>
C1106	RR LH SENSOR-2	Signal from rear LH wheel sensor does not match other 3 wheel speed signal.	
C1107	FR RH SENSOR-2	Signal from front RH wheel sensor does not match other 3 wheel speed signal.	
C1108	FR LH SENSOR-2	Signal from front LH wheel sensor does not match other 3 wheel speed signal.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
RR RH SENSOR-2
RR LH SENSOR-2
FR RH SENSOR-2
FR LH SENSOR-2

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-102. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255510

#### CAUTION:

**Never check between wheel sensor terminals.**

#### 1.CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

YES >> GO TO 2.  
NO >> Adjust air pressure, or replace tire.

#### 2.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

YES >> GO TO 3.  
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

#### 3.CHECK CONNECTOR

# C1105, C1106, C1107, C1108 WHEEL SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 4.

NO >> Poor connection of connector terminal. Repair or replace connector.

## 4.CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	12	E39 (Front RH)	4	Existed
	27	E22 (Front LH)	2	
	15	B41 (Rear RH)	8	
	30	B44 (Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	E39 (Front RH)	3	Existed
	23	E22 (Front LH)	1	
	11	B41 (Rear RH)	7	
	26	B44 (Rear LH)	5	

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	12, 21	E36	3, 4	Not existed
	27, 23			
	15, 11			
	30, 26			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

## 5.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.  
**CAUTION:**  
**Never start engine.**
5. Perform self-diagnosis results for "ABS" with CONSULT-III.

## C1105, C1106, C1107, C1108 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

IS DTC "C1105", "C1106", "C1107" or "C1108" detected?

- YES >> Replace ABS actuator and electric unit (control unit).  
NO >> INSPECTION END

### Component Inspection

INFOID:000000005255511

#### 1.CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display ( $\pm 10\%$ or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Go to diagnosis procedure. Refer to [BRC-102, "Diagnosis Procedure"](#).

### Special Repair Requirement

INFOID:00000000522802

#### 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END



# C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1109 POWER AND GROUND SYSTEM

### Description

INFOID:000000005255512

Supplies electric power to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005255513

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1109	BATTERY VOLTAGE [ABNORMAL]	When the ABS actuator and electric unit (control unit) power supply is lower than normal. Power supply is greater than normal limits.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS unit</li><li>• Fuse</li><li>• Vehicle electrical power system</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
BATTERY VOLTAGE [ABNORMAL]

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-105, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255514

#### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Repair or replace connector.

#### 2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT AND GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Turn ignition switch ON or OFF and check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E36	16	Ground	Ignition switch: ON	Battery voltage
			Ignition switch: OFF	Approx. 0 V

4. Check 10A fusible link (59).
5. Check continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R.

# C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS actuator and electric unit (control unit)		IPDM E/R		continuity
Connector	Terminal	Connector	Terminal	
E36	16	E15	59	Existed

6. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

## 3.ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

1. Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 16 and 4. With ignition switch ON check bulb illuminates correctly.

2. Check ABS motor supply under loaded condition (connector E36 terminals 1 and 3).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

## 4.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.

2. Disconnect ABS actuator and electric unit (control unit) connector.

3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Check battery for terminal looseness, low voltage, etc. if any malfunction is found, repair malfunctioning parts.

NO >> Repair or replace malfunctioning components. (Check ABS earth bolt for tightness and corrosion.)

## Diagnosis Procedure

INFOID:000000000522803

### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.

2. Disconnect ABS actuator and electric unit (control unit) connector.

3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.

4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 2.

NO >> Poor connection of connector terminal. Repair or replace connector.

### 2.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY CIRCUIT AND GROUND CIRCUIT

1. Turn ignition switch OFF.

2. Disconnect ABS actuator and electric unit (control unit) connector.

3. Turn ignition switch ON or OFF and check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E36	16	Ground	Ignition switch: ON	Battery voltage
			Ignition switch: OFF	Approx. 0 V

4. Check 10A fusible link (59).

## C1109 POWER AND GROUND SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

5. Check continuity between ABS actuator and electric unit (control unit) harness connector and IPDM E/R.

ABS actuator and electric unit (control unit)		IPDM E/R		continuity
Connector	Terminal	Connector	Terminal	
E36	16	E15	59	Existed

6. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

### 3.ABS POWER SUPPLY CHECK (UNDER LOAD CONDITIONS)

1. Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 16 and 4. With ignition switch ON check bulb illuminates correctly.
2. Check ABS motor supply under loaded condition (connector E36 terminals 1 and 3).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

### 4.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Check battery for terminal looseness, low voltage, etc. if any malfunction is found, repair malfunctioning parts.

NO >> Repair or replace malfunctioning components. (Check ABS earth bolt for tightness and corrosion.)

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1110 ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### Description

INFOID:000000005255515

ABS unit is continuously monitoring ECU hardware and software for correct operation.

### DTC Logic

INFOID:000000005255516

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1110	CONTROLLER FAILURE	Possible internal failure of control unit components.	Internal failure of control unit components. ABS solenoid valve or motor power supply / ground abnormal.

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

1. Check both ABS solenoid valve and motor supply and ground circuits using a suitable electrical load.
2. Check wheel speed sensor inputs.
3. Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
CONTROLLER FAILURE

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-108. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255517

#### 1.REPLACE ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

#### **CAUTION:**

Replace ABS actuator and electric unit (control unit) when self-diagnostic result shows items other than those applicable.

>> Replace ABS actuator and electric unit (control unit).

### Special Repair Requirement

INFOID:00000000522804

#### 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1111 ABS MOTOR, MOTOR RELAY SYSTEM

### Description

INFOID:0000000005255518

#### PUMP

The pump returns the brake fluid stored in the reservoir to the master cylinder by reducing the pressure.

#### MOTOR

The motor drives the pump according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:0000000005255519

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1111	PUMP MOTOR	During the actuator motor operating with ON, when the actuator motor turns OFF, or when the control line for actuator motor relay is open.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li></ul>
		During the actuator motor operating with OFF, when the actuator motor turns ON, or when the control line for relay is shorted to ground.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
PUMP MOTOR

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-109, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:0000000005255520

#### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnect, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2.CHECK ABS MOTOR AND MOTOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between the ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	1	Ground	Battery voltage

4. Reconnect ABS actuator and electric unit (control unit) connector.

# C1111 ABS MOTOR, MOTOR RELAY SYSTEM

[VDC/TCS/ABS]

## < DTC/CIRCUIT DIAGNOSIS >

### Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

### 3.ABS POWER SUPPLY CHECK (UNDER LOAD CONDITION)

Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 2 and 3. With ignition switch ON check bulb illuminates correctly.

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

### 4.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

### Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components. (Check ABS each bolt for tightness and corrosion.)

## Component Inspection

INFOID:000000005255521

### 1.CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and "ABS MOTOR" in order with CONSULT-III.
2. Select "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY	On	On

### Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-109, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000005522805

### 1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

# C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

### Description

INFOID:0000000005255522

Yaw rate/side/decel G sensor detects yaw rate/side/decel G affecting the vehicle, and transmits the data to the ABS actuator and electric unit (control unit) as an analog voltage signal.

### DTC Logic

INFOID:0000000005255523

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1113	G SENSOR	Yaw rate/side/decel G sensor is malfunctioning, or signal line of yaw rate/side/decel G sensor is open or shorted.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li><li>• Yaw rate/side/decel G sensor</li><li>• Electrical interference</li><li>• Vehicle driven on AWD rolling road</li></ul>
C1145	YAW RATE SENSOR		
C1146	SIDE G-SEN CIRCUIT		

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
G SENSOR
YAW RATE SENSOR
SIDE G-SEN CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-111, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:0000000005255524

#### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect yaw rate/side/decel G sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2.CHECK YAW RATE/SIDE/DECEL G SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect yaw rate/side/decel G sensor connector.
4. Check continuity between yaw rate/side/decel G sensor harness connector terminals and ABS actuator and electric unit (control unit) harness connector terminals.

# C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

ABS actuator and electric unit (control unit)		Yaw rate/side/decel G sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	13	B38	4	Existed
	14		5	
	28		2	
	29		6	

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

## 3.CHECK YAW RATE/SIDE/DECEL G SENSOR HARNESS CONNECTOR

Check continuity between G sensor harness connector terminal and ground.

Yaw rate/side/decel G sensor		Continuity
Connector	Terminal	
B38	2 - 4	Not existed
	2 - 5	
	2 - 6	
	4 - 5	
	4 - 6	
	5 - 6	

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

## 4.CHECK YAW RATE/SIDE/DECEL G SENSOR 1

1. Connect yaw rate/side/decel G sensor connector.
2. Connect ABS actuator and electric unit (control unit) connector.
3. Turn ignition switch ON.
4. Move yaw rate/side/decel G sensor as shown in the figure to check the output of before and after moving the sensor with the "ABS", "DATA MONITOR" and "DECEL G-SEN" in order with CONSULT-III.

Condition	DATA MONITOR
Horizontal	Approx. 0 G
Vertical	Approx. +1 G


Is the inspection result normal?

YES >> Replace yaw rate/side/decel G sensor.

NO >> GO TO 5.

## 5.CHECK YAW RATE/SIDE/DECEL G SENSOR 2

1. Turn ignition switch OFF.
2. Connect following terminals between yaw rate/side/decel G sensor and connector.





# C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Yaw rate/side/decel G sensor	Harness connector	
	Connector	Terminal
2	B38	2
4		4
5		5
6		6

- Turn ignition switch ON.
- Check voltage between yaw rate/side/decel G sensor harness connector terminals.

## CAUTION:

Never short out the terminals while measuring voltages.

Yaw rate/side/decel G sensor		Voltage
connector	Terminal	
B38	5 – 2	2.5 – 4.5 V
	6 – 2	0.5 – 2.5 V

Is the inspection result normal?

- YES >> Replace ABS actuator end electric unit (control unit). Perform self-diagnosis for “ABS” with CONSULT-III.
- NO >> Replace yaw rate/side/decel G sensor. Perform self-diagnosis for “ABS” with CONSULT-III.

## Component Inspection

INFOID:000000000525525

### 1.CHECK DATA MONITOR

Select “ABS”, “DATA MONITOR” and “YAW RATE SENSOR”, “SIDE G-SENSOR” and/or “DECEL G-SEN” in order with CONSULT-III, and check yaw rate/side/decel G sensor signal.

#### YAW RATE SENSOR

Vehicle condition	DATA MONITOR
Vehicle stopped	Approx. 0 d/s
Vehicle turning	–100 to 100 d/s

#### SIDE G SENSOR

Vehicle condition	DATA MONITOR
Vehicle stopped	Approx. 0 m/s <sup>2</sup>
Vehicle turning right	Negative value
Vehicle turning left	Positive value

#### DECEL G SENSOR

Vehicle condition	DATA MONITOR
Vehicle stopped	–0.11 to +0.11 G
During acceleration	Negative value
During deceleration	Positive value

Is the inspection result normal?

- YES >> INSPECTION END
- NO >> Go to diagnosis procedure. Refer to [BRC-111, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:0000000005522806

### 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

## **C1113, C1145, C1146 YAW RATE/SIDE/DECEL G SENSOR**

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

# C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1115 WHEEL SENSOR

### Description

INFOID:000000005255526

When the sensor rotor rotates, the magnetic field changes. It converts the magnetic field changes to current signals (rectangular wave) and transmits them to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005255527

#### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1115	ABS SENSOR [ABNORMAL SIGNAL]	Miss-match between the 4 wheel speed sensor signals.	Harness or connector not a possible cause. Other possible causes tire radius (due to wrong size or pressure) interference.

#### DTC CONFIRMATION PROCEDURE

##### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
ABS SENSOR [ABNORMAL SIGNAL]

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-115. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255528

#### CAUTION:

**Never check between wheel sensor terminals.**

##### 1.CHECK TIRES

Check air pressure, wear and size.

Are air pressure, wear and size within standard?

- YES >> GO TO 2.  
NO >> Adjust air pressure, or replace tire.

##### 2.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check that there is no deformation, misalignment, float, and backlash on the wheel sensor and wheel sensor mounting surface.
- Check that the wheel sensor is installed with no misalignment and backlash.

Are the sensor and sensor rotor normal?

- YES >> GO TO 3.  
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform self-diagnosis for "ABS" with CONSULT-III.

##### 3.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check terminal to see if it is deformed, disconnected, loose, etc., Repair or replace it if any malfunction condition is found.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 4.

# C1115 WHEEL SENSOR

[VDC/TCS/ABS]

## < DTC/CIRCUIT DIAGNOSIS >

NO >> Poor connection of connector terminal. Repair or replace connector.

### 4.CHECK WHEEL SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect malfunctioning wheel sensor connector.
4. Check continuity between terminals. (Also check continuity when steering wheel is turned right and left and when sensor harness inside the wheel house is moved.)

Measurement terminal for signal circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	12	E39 (Front RH)	4	Existed
	27	E22 (Front LH)	2	
	15	B41 (Rear RH)	8	
	30	B44 (Rear LH)	6	

Measurement terminal for power supply circuit

ABS actuator and electric unit (control unit)		Wheel sensor		Continuity
Connector	Terminal	Connector	Terminal	
E36	21	E39 (Front RH)	3	Existed
	23	E22 (Front LH)	1	
	11	B41 (Rear RH)	7	
	26	B44 (Rear LH)	5	

Measurement terminal for ground circuit

ABS actuator and electric unit (control unit)				Continuity
Connector	Terminal	Connector	Terminal	
E36	12, 21	E36	3, 4	Not existed
	27, 23			
	15, 11			
	30, 26			

5. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

### 5.REPLACE WHEEL SENSOR

1. Replace wheel sensor.
2. Erase self-diagnosis results for "ABS" with CONSULT-III.
3. Turn the ignition switch OFF.
4. Turn the ignition switch ON.

**CAUTION:**

**Never start engine.**

5. Perform self-diagnosis results for "ABS" with CONSULT-III.

IS DTC "C1115" detected?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> INSPECTION END

## Component Inspection

INFOID:000000005255529

### 1.CHECK DATA MONITOR

# C1115 WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Select "ABS", "DATA MONITOR" in order with CONSULT-III, select "FR LH SENSOR", "FR RH SENSOR", "RR LH SENSOR" and "RR RH SENSOR", and check the vehicle speed.

Wheel sensor	Vehicle speed (DATA MONITOR)
FR LH SENSOR	Nearly matches the speedometer display (±10% or less)
FR RH SENSOR	
RR LH SENSOR	
RR RH SENSOR	

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-115. "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:0000000005522807

### 1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

# C1116 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1116 STOP LAMP SWITCH

### Description

INFOID:000000005255530

The stop lamp switch transmits the stop lamp switch signal (ON/OFF) to the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005255531

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1116	STOP LAMP SW	When a stop lamp switch signal is not input where the brake pedal is depressed.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Stop lamp switch</li><li>• ABS actuator and electric unit (control unit)</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
STOP LAMP SW

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-118. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255532

#### 1.CHECK STOP LAMP ILLUMINATE

Check stop lamps illuminate when brake pedal is pressed.

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Check stop lamp circuit.

#### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect stop lamp switch connector.
4. Check terminal for deformation, disconnection, looseness, etc.
5. Reconnect ABS actuator and electric unit (control unit) and stop lamp switch connectors securely.
6. Start engine.
7. Repeat pumping brake pedal carefully several times, and perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated in the self-diagnosis display?

- YES >> GO TO 3.  
NO >> Poor connection of connector terminal. Replace or repair error-detected parts.

#### 3.CHECK STOP LAMP SWITCH CLEARANCE

Check stop lamp switch clearance. Refer to [BR-9. "Inspection and Adjustment"](#).

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Adjust stop lamp switch clearance. Refer to [BR-9. "Inspection and Adjustment"](#).

#### 4.CHECK STOP LAMP SWITCH CIRCUIT

1. Turn ignition switch OFF.

# C1116 STOP LAMP SWITCH

[VDC/TCS/ABS]

## < DTC/CIRCUIT DIAGNOSIS >

2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Condition	Voltage
Connector	Terminal			
E36	8	Ground	Brake pedal is depressed	Battery voltage
			Brake pedal is released	Approx. 0 V

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

## 5.CHECK STOP LAMP SWITCH

Check stop lamp switch. Refer to [BRC-119. "Component Inspection"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace stop lamp switch. Refer to [BR-20. "Exploded View"](#).

## Component Inspection

INFOID:0000000005255533

## 1.CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch connector terminals.

Stop lamp switch	Condition	Continuity
Terminal		
1 – 2	Release stop lamp switch (When brake pedal is depressed.)	Existed
	Push stop lamp switch (When brake pedal is released.)	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace stop lamp switch. Refer to [BR-20. "Exploded View"](#).

## Component Inspection

INFOID:0000000005522808

## 1.CHECK STOP LAMP SWITCH

1. Turn ignition switch OFF.
2. Disconnect stop lamp switch connector.
3. Check continuity between stop lamp switch connector terminals.

Stop lamp switch	Condition	Continuity
Terminal		
1 – 2	Release stop lamp switch (When brake pedal is depressed.)	Existed
	Push stop lamp switch (When brake pedal is released.)	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace stop lamp switch. Refer to [BR-20. "Exploded View"](#).

## C1118 AWD SYSTEM

## Description

INFOID:00000000525534

It transmits the value calculated by AWD control unit to ABS actuator and electric unit (control unit) with AWD communication line (line for AWD system only). ABS actuator and electric unit (control unit) controls AWD solenoid valve according to the received command value.

## DTC Logic

INFOID:00000000525535

## DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1118	4WD SYSTEM	An error is detected on AWD control unit side. (AWD control unit fail-safe mode)	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• AWD communication line</li> <li>• AWD control unit</li> <li>• ABS actuator and electric unit (control unit)</li> </ul>

## DTC CONFIRMATION PROCEDURE

## 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
4WD SYSTEM

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-120, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

## Diagnosis Procedure

INFOID:00000000525536

## 1.CHECK AWD CONTROL UNIT

Perform self-diagnosis for "ALL MODE AWD/4WD" with CONSULT-III.

Is any error system detected?

- YES >> Check the error system. Refer to [DLN-40, "DTC Index"](#).  
 NO >> Replace ABS actuator and electric unit (control unit).

## Special Repair Requirement

INFOID:00000000522809

## 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END



# C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1120, C1122, C1124, C1126 IN ABS SOL

### Description

INFOID:000000005255537

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005255538

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1120	FR LH IN ABS SOL	When the control unit detects a malfunction in the front LH inlet solenoid circuit.	ABS actuator and electric unit (control unit)
C1122	FR RH IN ABS SOL	When the control unit detects a malfunction in the front RH inlet solenoid circuit.	
C1124	RR LH IN ABS SOL	When the control unit detects a malfunction in the rear LH inlet solenoid circuit.	
C1126	RR RH IN ABS SOL	When the control unit detects a malfunction in the rear RH inlet solenoid circuit.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
FR LH IN ABS SOL
FR RH IN ABS SOL
RR LH IN ABS SOL
RR RH IN ABS SOL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-121, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255539

#### 1.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

- YES >> GO TO 2.  
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

#### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.  
NO >> Poor connection of connector terminal. Replace or repair connector.

# C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## 3.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

## 4.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:0000000005255540

## 1.CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and each test menu item in order with CONSULT-III.
2. On the display, select "Up", "Keep", and "Down", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
	CV1	Off	Off	Off
	SV1	Off	Off	Off
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
	CV2	Off	Off	Off
	SV2	Off	Off	Off
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
	CV2	Off	Off	Off
	SV2	Off	Off	Off
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*
	CV1	Off	Off	Off
	SV1	Off	Off	Off

\*: On for 1 to 2 seconds after the select, and then Off.

## C1120, C1122, C1124, C1126 IN ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-121. "Diagnosis Procedure"](#).

### Special Repair Requirement

INFOID:0000000005522810

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

# C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1121, C1123, C1125, C1127 OUT ABS SOL

### Description

INFOID:000000005255541

The solenoid valve increases, holds or decreases the fluid pressure of each brake caliper according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005255542

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1121	FR LH OUT ABS SOL	When the control unit detects a malfunction in the front LH outlet solenoid circuit.	ABS actuator and electric unit (control unit)
C1123	FR RH OUT ABS SOL	When the control unit detects a malfunction in the front RH outlet solenoid circuit.	
C1125	RR LH OUT ABS SOL	When the control unit detects a malfunction in the rear LH outlet solenoid circuit.	
C1127	RR RH OUT ABS SOL	When the control unit detects a malfunction in the rear RH outlet solenoid circuit.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
FR LH OUT ABS SOL
FR RH OUT ABS SOL
RR LH OUT ABS SOL
RR RH OUT ABS SOL

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-124. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255543

#### 1.CHECK SENSOR AND SENSOR ROTOR

- Check that there is no damage or adherence of foreign matter on the sensor rotor surface.
- Check sensor rotor for damage.
- Check wheel sensor for damage, disconnection or looseness.
- Check that there is no deformation on the wheel sensor mounting surface.

Are the sensor and sensor rotor normal?

- YES >> GO TO 2.  
NO >> Repair wheel sensor mount or replace sensor rotor. Then perform the self-diagnosis.

#### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 3.  
NO >> Poor connection of connector terminal. Replace or repair connector.

# C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## 3.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning components.

## 4.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000005255544

## 1.CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and each test menu item in order with CONSULT-III.
2. On the display, select "Up", "Keep", and "Down", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	Keep	Down
FR RH SOL	FR RH IN SOL	Off	On	On
	FR RH OUT SOL	Off	Off	On*
	CV1	Off	Off	Off
	SV1	Off	Off	Off
FR LH SOL	FR LH IN SOL	Off	On	On
	FR LH OUT SOL	Off	Off	On*
	CV2	Off	Off	Off
	SV2	Off	Off	Off
RR RH SOL	RR RH IN SOL	Off	On	On
	RR RH OUT SOL	Off	Off	On*
	CV2	Off	Off	Off
	SV2	Off	Off	Off
RR LH SOL	RR LH IN SOL	Off	On	On
	RR LH OUT SOL	Off	Off	On*
	CV1	Off	Off	Off
	SV1	Off	Off	Off

\*: On for 1 to 2 seconds after the select, and then Off.

## C1121, C1123, C1125, C1127 OUT ABS SOL

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-124. "Diagnosis Procedure"](#).

### Special Repair Requirement

INFOID:0000000005522811

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

&lt; DTC/CIRCUIT DIAGNOSIS &gt;

## C1130 ENGINE SIGNAL

## Description

INFOID:000000005255545

ABS actuator and electric unit (control unit) and ECM exchange the engine signal via CAN communication line.

## DTC Logic

INFOID:000000005255546

## DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1130	ENGINE SIGNAL 1	ECM signals are invalid or ECM self diagnosis indicates a fault that prevents correct TCS operation.	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit)</li> <li>• ECM</li> <li>• CAN communication line</li> </ul>

## DTC CONFIRMATION PROCEDURE

## 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
ENGINE SIGNAL 1

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-127, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

## Diagnosis Procedure

INFOID:000000005255547

## 1.CHECK ENGINE SYSTEM

1. Perform self-diagnosis for "ENGINE" with CONSULT-III. Repair or replace items indicated, then Perform self-diagnosis for "ENGINE" with CONSULT-III.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> Repair or replace the affected part.  
 NO >> INSPECTION END

## Diagnosis Procedure

INFOID:00000000522812

## 1.CHECK ENGINE SYSTEM

1. Perform self-diagnosis for "ENGINE" with CONSULT-III. Repair or replace items indicated, then Perform self-diagnosis for "ENGINE" with CONSULT-III.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> Repair or replace the affected part.  
 NO >> INSPECTION END

# C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1140 ACTUATOR RELAY SYSTEM

### Description

INFOID:000000005255548

Activates or deactivates each solenoid valve according to the signals transmitted by the ABS actuator and electric unit (control unit).

### DTC Logic

INFOID:000000005255549

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1140	ACTUATOR RLY	During the actuator relay operating with OFF, when the actuator relay turns ON, or when the control line for the relay is shorted to the ground.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li></ul>
		During the actuator relay operating with ON, when the actuator relay turns ON, or when the control line for the relay is open.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
ACTUATOR RLY

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-128, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255550

#### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connector and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

4. Reconnect ABS actuator and electric unit (control unit) connector.

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace malfunctioning components.



# C1140 ACTUATOR RELAY SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## 3.ABS POWER SUPPLY CHECK (UNDER LOAD CONDITION)

Use 12 V lamp (normal rating 10 to 20 W) connected between E36 terminals 1 and 3. With ignition switch ON check bulb illuminates correctly.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Check both power supply and ground circuit.

## 4.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components. (Check ABS each bolt for tightness and corrosion.)

## Component Inspection

INFOID:00000000525551

## 1.CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and "ABS MOTOR" in order with CONSULT-III.
2. Select "On" and "Off" on screen. Make sure motor relay and actuator relay operates as shown in table below.

Test item	Display item	Display	
		On	Off
ABS MOTOR	MOTOR RELAY	On	Off
	ACTUATOR RLY	On	On

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-128, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:00000000522813

## 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

# C1143, C1144 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1143, C1144 STEERING ANGLE SENSOR

### Description

INFOID:000000005255552

The steering angle sensor detects the rotation amount, angular velocity and direction of the steering wheel, and transmits the data to the ABS actuator and electric unit (control unit) via CAN communication.

### DTC Logic

INFOID:000000005255553

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1143	ST ANG SEN CIRCUIT	Neutral position of steering angle sensor is dislocated, or the steering angle sensor is malfunctioning.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• Steering angle sensor</li><li>• ABS actuator and electric unit (control unit)</li></ul>
C1144	ST ANG SEN SIGNAL	Neutral position of steering angle sensor is not finished.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
ST ANG SEN CIRCUIT
ST ANG SEN SIGNAL

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-130, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255554

#### 1.CHECK VEHICLE STATE

Check vehicle for any suspension/steering misalignment or damage.

Is the inspection result normal?

YES >> GO TO 2.  
NO >> Correct any damage found.

#### 2.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Disconnect steering angle sensor connector.
4. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
5. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

YES >> GO TO 3.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 3.CHECK STEERING ANGLE SENSOR HARNESS

1. Turn ignition switch OFF.
2. Disconnect steering angle sensor connector.
3. Check continuity between steering angle sensor harness connector terminal and ground.

Steering angle sensor		—	Continuity
Connector	Terminal		
M30	3	Ground	Existed

# C1143, C1144 STEERING ANGLE SENSOR

## < DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

- Turn ignition switch ON.
- Check voltage between steering angle sensor harness connector terminal and ground.

Steering angle sensor		—	Voltage
Connector	Terminal		
M30	1	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace malfunctioning components.

## 4.CHECK DATA MONITOR

- Connect the steering angle sensor connector and ABS actuator and electric unit (control unit) connector.
- Select "ABS", "DATA MONITOR" and "STR ANGLE SIG" in order with CONSULT-III, and check steering angle sensor signal.

Steering condition	STR ANGLE SIG (DATA MONITOR)
Driving straight	$\pm 2.5^{\circ}$
Turn $90^{\circ}$ to right	Approx. $+90^{\circ}$
Turn $90^{\circ}$ to left	Approx. $-90^{\circ}$

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Adjust neutral position of steering angle sensor.

## 5.CHECK FOR BACKLASH

- Check for backlash [turn wheel to left then straight then right then straight (approx.  $90^{\circ}$ )].
- Check straight position is always similar value.

Is there noticeable backlash?

- YES >> Check sensor is correctly fitted to combination switch.  
NO >> Check sensor output is correct from lock to lock.

## Component Inspection

INFOID:0000000005255555

## 1.CHECK DATA MONITOR

Select "ABS", "DATA MONITOR" and "STR ANGLE SIG" in order with CONSULT-III, and check steering angle sensor signal.

Steering condition	STR ANGLE SIG (DATA MONITOR)
Driving straight	$\pm 2.5^{\circ}$
Turn $90^{\circ}$ to right	Approx. $+90^{\circ}$
Turn $90^{\circ}$ to left	Approx. $-90^{\circ}$

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Go to diagnosis procedure. Refer to [BRC-130. "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:000000000522814

## 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

# C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1155 BRAKE FLUID LEVEL SWITCH

### Description

INFOID:000000005255557

Brake fluid level switch contacts close when brake fluid level is low. This is detected by the combination meter which sends the status of fluid level to the VDC unit via the CAN bus.

### DTC Logic

INFOID:000000005255558

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1155	BR FLUID LEVEL LOW	Ignition switch ON and brake fluid signal low or not available for 10 seconds.	<ul style="list-style-type: none"><li>• Brake fluid level low</li><li>• Brake fluid level switch failure</li><li>• Wiring to brake fluid level switch short circuit</li><li>• CAN bus failure</li><li>• Combination meter failure</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results

BR FLUID LEVEL LOW

Is above displayed on the self-diagnosis display?

YES >> Proceed to diagnosis procedure. Refer to [BRC-132. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255559

#### 1.CHECK BRAKE FLUID LEVEL

Check brake fluid level. Refer to [BR-12. "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 2.  
NO >> Refill brake fluid. Refer to [BR-12. "Refilling"](#).

#### 2.CHECK BRAKE WARNING LAMP 1

Check that the brake warning lamp illuminates after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 3.  
NO >> Check wiring to brake fluid level sensor and brake fluid level sensor.

#### 3.CHECK BRAKE WARNING LAMP 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake.

Is the inspection result normal?

YES >> GO TO 4.  
NO >> Check parking brake switch.

#### 4.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector and combination meter connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

# C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Is any item indicated on the self-diagnosis display?

YES >> GO TO 5.

NO >> Poor connection of connector terminal. Replace or repair connector.

## 5.CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

Brake fluid level switch		Condition	Continuity
Connector	Terminal		
E37	1 – 2	When brake fluid is full in the reservoir tank.	Not existed
		When brake fluid is empty in the reservoir tank.	Existed

Is the inspection result normal?

YES >> GO TO 6.

NO >> Brake fluid level switch is malfunction. Replace reservoir tank.

## 6.CHECK BRAKE FLUID LEVEL SWITCH CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between brake fluid level switch harness connector terminals and combination meter harness connector terminal and/or ground.

Combination meter		Brake fluid level switch		Continuity
Connector	Terminal	Connector	Terminal	
M34	27	E37	1	Existed

Combination meter		—	Continuity
Connector	Terminal		
M34	27	Ground	Not existed

Brake fluid level switch		—	Continuity
Connector	Terminal		
E37	2	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:0000000005255560

## 1.CHECK BRAKE FLUID LEVEL SWITCH

1. Turn ignition switch OFF.
2. Disconnect brake fluid level switch connector.
3. Check continuity between brake fluid level switch connector terminals.

Brake fluid level switch		Condition	Continuity
Connector	Terminal		
E37	1 – 2	When brake fluid is full in the reservoir tank.	Not existed
		When brake fluid is empty in the reservoir tank.	Existed

## C1155 BRAKE FLUID LEVEL SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-132. "Diagnosis Procedure"](#).

### Special Repair Requirement

INFOID:0000000005522815

#### 1. ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

# C1164, C1165 CV SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1164, C1165 CV SYSTEM

### Description

INFOID:000000005255561

The cut valve shuts off the normal brake fluid path from the master cylinder, when VDC/TCS is activated.

### DTC Logic

INFOID:000000005255562

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1164	CV1	VDC switch-over solenoid valve (CV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ABS actuator and electric unit (control unit)</li></ul>
C1165	CV2	VDC switch-over solenoid valve (CV2) on the secondary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
CV1
CV2

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-135. "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255563

#### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace malfunctioning components.

#### 3.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

# C1164, C1165 CV SYSTEM

[VDC/TCS/ABS]

## < DTC/CIRCUIT DIAGNOSIS >

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

### Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).  
NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000005255564

### 1.CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and each test menu item in order with CONSULT-III.
2. On the display, select "Up", "ACT UP", and "ACT KEEP", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
FR RH ABS SOLENOID (ACT)	FR RH IN SOL	Off	Off	Off
	FR RH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off
FR LH ABS SOLENOID (ACT)	FR LH IN SOL	Off	Off	Off
	FR LH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR RH ABS SOLENOID (ACT)	RR RH IN SOL	Off	Off	Off
	RR RH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR LH ABS SOLENOID (ACT)	RR LH IN SOL	Off	Off	Off
	RR LH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off

\*: On for 1 to 2 seconds after the select, and then Off.

### Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Go to diagnosis procedure. Refer to [BRC-135, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:00000000522816

### 1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END



## C1166, C1167 SV SYSTEM

## Description

INFOID:000000005255565

The suction valve supplies the brake fluid from the master cylinder to the pump, when VDC/TCS is activated.

## DTC Logic

INFOID:000000005255566

## DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1166	SV1	VDC switch-over solenoid valve (SV1) on the primary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	<ul style="list-style-type: none"> <li>• Harness or connector</li> <li>• ABS actuator and electric unit (control unit)</li> </ul>
C1167	SV2	VDC switch-over solenoid valve (SV2) on the secondary side is open circuit or shorted, or the control line is open or shorted to the power supply or the ground.	

## DTC CONFIRMATION PROCEDURE

## 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
SV1
SV2

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-137, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

## Diagnosis Procedure

INFOID:000000005255567

## 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
 NO >> Poor connection of connector terminal. Replace or repair connector.

## 2.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check voltage between ABS actuator and electric unit (control unit) harness connector terminal and ground.

ABS actuator and electric unit (control unit)		—	Voltage
Connector	Terminal		
E36	2	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace malfunctioning components.

## 3.CHECK SOLENOID, VDC SWITCH-OVER VALVE AND ACTUATOR RELAY GROUND CIRCUIT

## < DTC/CIRCUIT DIAGNOSIS >

Check continuity between ABS actuator and electric unit (control unit) harness connector terminals and ground.

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	3, 4	Ground	Existed

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace malfunctioning components.

## Component Inspection

INFOID:000000005255568

### 1.CHECK ACTIVE TEST

1. Select "ABS", "ACTIVE TEST" and each test menu item in order with CONSULT-III.
2. On the display, select "Up", "ACT UP", and "ACT KEEP", and check that the system operates as shown in the table below.

Test item	Display item	Display		
		Up	ACT UP	ACT KEEP
FR RH ABS SOLENOID (ACT)	FR RH IN SOL	Off	Off	Off
	FR RH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off
FR LH ABS SOLENOID (ACT)	FR LH IN SOL	Off	Off	Off
	FR LH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR RH ABS SOLENOID (ACT)	RR RH IN SOL	Off	Off	Off
	RR RH OUT SOL	Off	Off	Off
	CV2	Off	On	On
	SV2	Off	On*	Off
RR LH ABS SOLENOID (ACT)	RR LH IN SOL	Off	Off	Off
	RR LH OUT SOL	Off	Off	Off
	CV1	Off	On	On
	SV1	Off	On*	Off

\*: On for 1 to 2 seconds after the select, and then Off.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-137, "Diagnosis Procedure"](#).

## Special Repair Requirement

INFOID:00000000522817

### 1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

# C1176 STOP LAMP SW2

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## C1176 STOP LAMP SW2

### Description

INFOID:000000005255569

When the brake pedal is depressed, ASCD brake switch is turned OFF and stop lamp switch is turned ON.

### DTC Logic

INFOID:000000005255570

### DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
C1176	STOP LAMP SW2	When a ASCD brake switch signal is not input where the brake pedal is depressed.	<ul style="list-style-type: none"><li>• Harness or connector</li><li>• ASCD brake switch</li><li>• ABS actuator and electric unit (control unit)</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
STOP LAMP SW2

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-139, "Diagnosis Procedure"](#).  
NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255571

#### 1.CHECK CONNECTOR

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
4. Reconnect connectors and then perform self-diagnosis for "ABS" with CONSULT-III.

Is any item indicated on the self-diagnosis display?

- YES >> GO TO 2.  
NO >> Poor connection of connector terminal. Replace or repair connector.

#### 2.CHECK ASCD BRAKE SWITCH CLEARANCE

Check ASCD brake switch clearance. Refer to [BR-9, "Inspection and Adjustment"](#).

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Adjust ASCD brake switch clearance. Refer to [BR-9, "Inspection and Adjustment"](#)

#### 3.CHECK ASCD BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch connector.
3. Check continuity between ASCD brake switch connector terminals.

ASCD brake switch	Condition	Continuity
Terminal		
1 – 2	Brake pedal is fully released.	Existed
	Brake pedal is slightly depressed.	Not existed

Is the inspection result normal?

- YES >> GO TO 4.

## C1176 STOP LAMP SW2

[VDC/TCS/ABS]

### < DTC/CIRCUIT DIAGNOSIS >

NO >> Replace ASCD brake switch. Refer to [BR-20, "Exploded View"](#).

#### 4.CHECK ASCD BRAKE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch connector.
3. Turn ignition switch ON.
4. Check voltage between ASCD brake switch harness connector and ground.

ASCD brake switch		—	Voltage
Connector	Terminal		
E112	1	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace malfunctioning components.

#### 5.CHECK ASCD BRAKE SWITCH INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Check continuity between ASCD brake switch harness connector and ABS actuator and electric unit (control unit) harness connector.

ASCD brake switch		ABS actuator and electric unit (control unit)		Continuity
Connector	Terminal	Connector	Terminal	
E112	2	E36	6	Existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace malfunctioning components.

### Component Inspection

INFOID:000000005255572

#### 1.CHECK ASCD BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect ASCD brake switch connector.
3. Check continuity between ASCD brake switch connector terminals.

ASCD brake switch	Condition	Continuity
Terminal		
1 – 2	Brake pedal is fully released.	Existed
	Brake pedal is slightly depressed.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace ASCD brake switch. Refer to [BR-20, "Exploded View"](#).

### Special Repair Requirement

INFOID:00000000522818

#### 1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

## U1000 CAN COMM CIRCUIT

## Description

INFOID:0000000005255573

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

## DTC Logic

INFOID:0000000005255574

## DTC DETECTION LOGIC

DTC	Display item	Malfunction detected condition	Possible cause
U1000	CAN COMM CIRCUIT	When ABS actuator and electric unit (control unit) is not transmitting or receiving CAN communication signal for 2 seconds or more.	<ul style="list-style-type: none"> <li>CAN communication line</li> <li>ABS actuator and electric unit (control unit)</li> </ul>

BRC

## DTC CONFIRMATION PROCEDURE

## 1.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
CAN COMM CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-141, "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

## Diagnosis Procedure

INFOID:0000000005255575

## 1.CHECK CONNECTOR

- Turn ignition switch OFF.
- Disconnect ABS actuator and electric unit (control unit) connector.
- Check terminal for deformation, disconnection, looseness, and so on. If any malfunction is found, repair or replace terminal.
- Reconnect connector and perform self-diagnosis for "ABS" with CONSULT-III.

Self-diagnosis results
CAN COMM CIRCUIT

Is above displayed on the self-diagnosis display?

- YES >> Go to [LAN-16, "Trouble Diagnosis Flow Chart"](#).  
 NO >> INSPECTION END

## Special Repair Requirement

INFOID:000000000522819

## 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

## U1010 CONTROL UNIT (CAN)

### Description

INFOID:000000005255576

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent error detection ability. Many electronic control units are equipped onto a vehicle, and each control unit shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN-H line, CAN-L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.

### DTC Logic

INFOID:000000005255577

### DTC DETECTION LOGIC

DTC	Items	Diagnostic item is detected when...	Possible cause
U1010	CONTROL UNIT (CAN)	When detecting error during the initial diagnosis of CAN controller of ABS actuator and electric unit (control unit).	ABS actuator and electric unit (control unit) error

### DTC CONFIRMATION PROCEDURE

#### 1.RECHECK DTC

1. Turn the ignition switch OFF to ON.
2. Perform self-diagnosis for "ABS" with CONSULT-III.

Is DTC "U1010" detected?

- YES >> Proceed to diagnosis procedure. Refer to [BRC-142. "Diagnosis Procedure"](#).  
 NO >> INSPECTION END

### Diagnosis Procedure

INFOID:000000005255578

#### 1.ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Check that there is no malfunction in ABS actuator and electric unit (control unit) harness connector or disconnection.

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit). Refer to [BRC-178. "Exploded View"](#).  
 NO >> Repair or replace the harnesses and connectors.

### Special Repair Requirement

INFOID:000000005252820

#### 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

# PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## PARKING BRAKE SWITCH

### Description

INFOID:000000005255579

The parking brake switch converts the status of the parking brake pedal to an electric signal and transmits it to the ABS actuator and electric unit (control unit).

### Component Function Check

INFOID:000000005255580

#### 1.CHECK PARKING BRAKE SWITCH OPERATION

Operate the parking brake pedal. Then check that the brake warning lamp in the combination meter turns on/off correctly.

Condition	Brake warning lamp illumination status
When the parking brake switch is operation	ON
When the parking brake switch is not operation.	OFF

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-143, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005255581

#### 1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch connector terminal and ground.

Parking brake switch		—	Condition	Continuity
Connector	Terminal			
E103	1	Ground	When the parking brake switch is operated.	Existed
			When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace parking brake switch.

#### 2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-32, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check ABS actuator and electric unit (control unit). Refer to [BRC-94, "CONSULT-III Function"](#).

### Component Inspection

INFOID:000000005255582

#### 1.CHECK PARKING BRAKE SWITCH

1. Turn ignition switch OFF.
2. Disconnect parking brake switch connector.
3. Check continuity between parking brake switch connector terminal and ground.

## PARKING BRAKE SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Parking brake switch		—	Condition	Continuity
Connector	Terminal			
E103	1	Ground	When the parking brake switch is operated.	Existed
			When the parking brake switch is not operated.	Not existed

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace parking brake switch. Refer to [PB-6. "Exploded View"](#).



# VDC OFF SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## VDC OFF SWITCH

### Description

INFOID:000000005255583

VDC OFF switch can deactivate (turn OFF) the VDC/TCS function by pressing the VDC OFF switch.

### Component Function Check

INFOID:000000005255584

#### 1.CHECK VDC OFF SWITCH OPERATION

Turn ON/OFF the VDC OFF switch and check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly.

Condition	VDC OFF indicator lamp illumination status
VDC OFF switch: ON	ON
VDC OFF switch: OFF	OFF

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-145. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005255585

#### 1.CHECK VDC OFF SWITCH

1. Turn ignition switch OFF.
2. Disconnect VDC OFF switch connector.
3. Check continuity between VDC OFF switch connector terminals.

VDC OFF switch	Condition	Continuity
Terminal		
1 – 2	When VDC OFF switch is hold pressed.	Existed
	When releasing VDC OFF switch.	Not existed

Is the inspection result normal?

YES >> GO TO 2.

NO >> VDC OFF switch is malfunctioning. Replace VDC OFF switch.

#### 2.CHECK VDC OFF SWITCH HARNESS

1. Disconnect ABS actuator and electric unit (control unit) connector.
2. Check continuity between VDC OFF switch connector terminals and ABS actuator and electric unit (control unit) connector terminal and/or ground.

ABS actuator and electric unit (control unit)		VDC OFF switch		Continuity
Connector	Terminal	Connector	Terminal	
E36	5	M5	1	Existed

ABS actuator and electric unit (control unit)		—	Continuity
Connector	Terminal		
E36	5	Ground	Not existed

VDC OFF switch		—	Continuity
Connector	Terminal		
M5	2	Ground	Existed

Is the inspection result normal?

## VDC OFF SWITCH

[VDC/TCS/ABS]

### < DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 3.  
NO >> If the open or short in harness, repair or replace harness.

### 3.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-32. "Diagnosis Description"](#).

Is the inspection result normal?

- YES >> Replace ABS actuator and electric unit (control unit).  
NO >> Repair or replace combination meter.

### Component Inspection

INFOID:000000005255586

### 1.CHECK VDC OFF SWITCH

1. Turn ignition switch OFF.
2. Disconnect VDC OFF switch connector.
3. Check continuity between VDC OFF switch connector terminals.

VDC OFF switch	Condition	
Terminal		
1 – 2	When VDC OFF switch is hold pressed.	Existed
	When releasing VDC OFF switch.	Not existed

Is the inspection result normal?

- YES >> INSPECTION END  
NO >> Replace VDC OFF switch.

### Special Repair Requirement

INFOID:00000000522821

### 1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

# ABS WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## ABS WARNING LAMP

### Description

INFOID:0000000005255587

×: ON –: OFF

Condition	ABS warning lamp
Ignition switch OFF	–
For 1 second after turning ignition switch ON	×
1 second later after turning ignition switch ON	–
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

### Component Function Check

INFOID:0000000005255588

#### 1.CHECK ABS WARNING LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-147, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000005255589

#### 1.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

#### 2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-32, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

### Special Repair Requirement

INFOID:0000000005252822

#### 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

# BRAKE WARNING LAMP

[VDC/TCS/ABS]

< DTC/CIRCUIT DIAGNOSIS >

## BRAKE WARNING LAMP

### Description

INFOID:0000000005255590

×: ON –: OFF

Condition	Brake warning lamp (Note 1)
Ignition switch OFF	–
For 1 second after turning ignition switch ON	× (Note 2)
1 second later after turning ignition switch ON	× (Note 2)
EBD function is malfunctioning.	×

#### NOTE:

- 1: Brake warning lamp will turn on in case of parking brake operation (when switch is ON) or of brake fluid level switch operation (when brake fluid is insufficient).
- 2: After starting engine, brake warning lamp is turned off.

### Component Function Check

INFOID:0000000005255591

#### 1.BRAKE WARNING LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to diagnosis procedure. Refer to [BRC-148, "Diagnosis Procedure"](#).

#### 2.BRAKE WARNING LAMP OPERATION CHECK 2

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check parking brake switch. Refer to [BRC-143, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:0000000005255592

#### 1.CHECK PARKING BRAKE SWITCH

Check that the brake warning lamp in the combination meter turns ON/OFF correctly when operating the parking brake pedal.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check parking brake switch. Refer to [BRC-143, "Diagnosis Procedure"](#).

#### 2.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check items displayed by self-diagnosis.

#### 3.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-32, "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

### Special Repair Requirement

INFOID:000000000522823

#### 1.ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

# BRAKE WARNING LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

BRC

# VDC OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## VDC OFF INDICATOR LAMP

### Description

INFOID:000000005255593

×: ON –: OFF

Condition	VDC OFF indicator lamp
Ignition switch OFF	–
For 1 second after turning ignition switch ON	×
1 second later after turning ignition switch ON	–
VDC OFF switch turned ON. (VDC function is OFF.)	×
VDC/TCS function is malfunctioning.	×
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

### Component Function Check

INFOID:000000005255594

#### 1.VDC OFF INDICATOR LAMP OPERATION CHECK 1

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Go to diagnosis procedure. Refer to [BRC-150. "Diagnosis Procedure"](#).

#### 2.VDC OFF INDICATOR LAMP OPERATION CHECK 2

Check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Check VDC OFF switch. Refer to [BRC-145. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005255595

#### 1.CHECK VDC OFF SWITCH

Check that the VDC OFF indicator lamp in the combination meter turns ON/OFF correctly when operating the VDC OFF switch.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check VDC OFF switch. Refer to [BRC-145. "Diagnosis Procedure"](#).

#### 2.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> GO TO 3.

NO >> Check items displayed by self-diagnosis.

#### 3.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-32. "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

### Special Repair Requirement

INFOID:00000000522824

#### 1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

VDC OFF INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END

- A
- B
- C
- D
- E
- BRC**
- G
- H
- I
- J
- K
- L
- M
- N
- O
- P

# SLIP INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[VDC/TCS/ABS]

## SLIP INDICATOR LAMP

### Description

INFOID:000000005255596

×: ON –: OFF

Condition	SLIP indicator lamp
Ignition switch OFF	–
For 1 second after turning ignition switch ON	×
1 second later after turning ignition switch ON	–
VDC/TCS function is malfunctioning.	×
ABS function is malfunctioning.	×
EBD function is malfunctioning.	×

### Component Function Check

INFOID:000000005255597

#### 1.CHECK SLIP INDICATOR LAMP OPERATION

Check that the lamp illuminates for approximately 1 second after the ignition switch is turned ON.

Is the inspection result normal?

YES >> INSPECTION END

NO >> Go to diagnosis procedure. Refer to [BRC-152. "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000005255598

#### 1.CHECK SELF-DIAGNOSIS

Perform self-diagnosis for "ABS" with CONSULT-III.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check items displayed by self-diagnosis.

#### 2.CHECK COMBINATION METER

Check if the indication and operation of combination meter are normal. Refer to [MWI-32. "Diagnosis Description"](#).

Is the inspection result normal?

YES >> Replace ABS actuator and electric unit (control unit).

NO >> Repair or replace combination meter.

### Special Repair Requirement

INFOID:000000005252825

#### 1.AJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION

Always perform the neutral position adjustment for the steering angle sensor, when replacing the ABS actuator and electric unit (control unit) or steering angle sensor and removing steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Special Repair Requirement"](#).

>> END



# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

## ECU DIAGNOSIS INFORMATION

### ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

#### Reference Value

INFOID:0000000005255599

#### VALUES ON THE DIAGNOSIS TOOL

#### CAUTION:

The display shows the control unit calculation data, so a normal value might be displayed even in the event the output circuit (harness) is open or short-circuited.

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
FR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
FR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
RR LH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
RR RH SENSOR	Wheel speed	Vehicle stopped	0 [km/h (MPH)]
		Vehicle running (Note 1)	Nearly matches the speed meter display (± 10% or less)
STOP LAMP SW	Stop lamp switch signal status	When brake pedal is depressed	On
		When brake pedal is not depressed	Off
BATTERY VOLT	Battery voltage supplied to the ABS actuator and electric unit (control unit)	Ignition switch ON	10 – 16 V
GEAR	Gear position determined by TCM	First gear (1GR)	1
		Second gear (2GR)	2
		Third gear (3GR)	3
		Forth gear (4GR)	4
		Fifth gear (5GR)	5
		Sixth gear (6GR)	6
OFF SW	VDC OFF switch ON/OFF	VDC OFF switch ON (When VDC OFF indicator lamp is ON)	On
		VDC OFF switch OFF (When VDC OFF indicator lamp is OFF)	Off
YAW RATE SEN	Yaw rate detected by yaw rate sensor	Vehicle stopped	Approx. 0 d/s
		Vehicle turning	–100 to 100 d/s
DECEL G-SEN	Decel G detected by decel G sensor	Vehicle stopped	–0.11 – +0.11 G
		During acceleration	Negative value
		During deceleration	Positive value
ACCEL POS SIG	Throttle actuator opening/closing is displayed (linked with accelerator pedal)	Accelerator pedal not depressed (ignition switch is ON)	0 %
		Depress accelerator pedal (ignition switch is ON)	0 - 100 %

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
SIDE G-SENSOR	Transverse G detected by side G sensor	Vehicle stopped	Approx. 0 m/s <sup>2</sup>
		Vehicle turning right	Negative value
		Vehicle turning left	Positive value
STR ANGLE SIG	Steering angle detected by steering angle sensor	During straight	Approx. 0°
		Steering wheel turned	-720 to 720°
ENGINE SPEED	With engine running	With engine stopped	0 [tr/min (rpm)]
		Engine running	Almost in accordance with tachometer display
FLUID LEV SW	Brake fluid level switch signal status	When brake fluid level switch ON	On
		When brake fluid level switch OFF	Off
FR RH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR RH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR LH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
FR LH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR RH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR RH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
RR LH IN SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
RR LH OUT SOL	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
MOTOR RELAY	Motor and motor relay operation	When the motor relay and motor are operating	On
		When the motor relay and motor are not operating	Off
ACTUATOR RLY	Actuator relay operation	When the actuator relay is operating	On
		When the actuator relay is not operating	Off
ABS WARN LAMP	ABS warning lamp (Note 2)	When ABS warning lamp is ON	On
		When ABS warning lamp is OFF	Off
OFF LAMP	VDC OFF indicator lamp (Note 2)	When VDC OFF indicator lamp is ON	On
		When VDC OFF indicator lamp is OFF	Off
SLIP LAMP	SLIP indicator lamp (Note 2)	When SLIP indicator lamp is ON	On
		When SLIP indicator lamp is OFF	Off
EBD SIGNAL	EBD operation	EBD is active	On
		EBD is inactive	Off
ABS SIGNAL	ABS operation	ABS is active	On
		ABS is inactive	Off
TCS SIGNAL	TCS operation	TCS is active	On
		TCS is inactive	Off
VDC SIGNAL	VDC operation	VDC is active	On
		VDC is inactive	Off
EBD FAIL SIG	EBD fail-safe signal	In EBD fail-safe	On
		EBD is normal	Off
ABS FAIL SIG	ABS fail-safe signal	In ABS fail-safe	On
		ABS is normal	Off
TCS FAIL SIG	TCS fail-safe signal	In TCS fail-safe	On
		TCS is normal	Off
VDC FAIL SIG	VDC fail-safe signal	In VDC fail-safe	On
		VDC is normal	Off
CRANKING SIG	Crank operation	Crank is active	On
		Crank is inactive	Off
N POSI SIG	N position signal	For N range	On
		Except for N range	Off
P POSI SIG	P position signal	For P range	On
		Except for P range	Off

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

Monitor item	Display content	Data monitor	
		Condition	Reference value in normal operation
R POSI SIG	R position signal	For R range	On
		Except for R range	Off
4WD MODE MON	Axle condition	AUTO is active	AUTO
		LOCK is active	LOCK
		2WD is active	2WD
CV1	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
CV2	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
SV1	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
SV2	Operation status of each solenoid valve	Actuator (solenoid valve) is active ("ACTIVE TEST" in "ABS" with CONSULT-III)	On
		When the actuator (solenoid valve) is not active and actuator relay is active (ignition switch ON)	Off
STOP LAMP SW2	Stop lamp switch signal status	When brake pedal is depressed	On
		When brake pedal is not depressed	Off

## NOTE:

- 1: Confirm tire pressure is normal.
- 2: On and off timing for warning lamp and indicator lamp.
- ABS warning lamp: Refer to [BRC-147, "Description"](#).
- Brake warning lamp: Refer to [BRC-148, "Description"](#).
- VDC OFF indicator lamp: Refer to [BRC-150, "Description"](#).
- SLIP indicator lamp: Refer to [BRC-152, "Description"](#).

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

## Wiring Diagram -BRAKE CONTROL SYSTEM-

INFOID:000000005255600

### BRAKE CONTROL SYSTEM (WITH VDC)



2008/07/15

JCFWM0255Gf

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

## BRAKE CONTROL SYSTEM (WITH VDC)

Connector No.	BI1
Connector Name	WIRE TO WIRE
Connector Type	TH80MW-GS16-TM4



Connector No.	B38
Connector Name	YAW RATE / SIDE / DECEL G SENSOR
Connector Type	SC20MF8



Terminal No.	Color of Wire	Signal Name [Specification]
12	BR	-
13	O	-
22	G	-
23	SB	-
52	SHIELD	-
53	L	-
54	B	-
52	Y	-
53	R	-

Terminal No.	Color of Wire	Signal Name [Specification]
2	Y	GND
4	B	VCC(POWER)
5	L	SERIAL+
6	R	SERIAL-

Connector No.	B41
Connector Name	REAR WHEEL SENSOR RH
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
7	O	-
8	SB	-

Connector No.	B44
Connector Name	REAR WHEEL SENSOR LH
Connector Type	RK02FGY



Terminal No.	Color of Wire	Signal Name [Specification]
5	BR	-
6	G	-


Connector No.	E15
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Type	NS10FW-CS



Connector No.	E22
Connector Name	FRONT WHEEL SENSOR LH
Connector Type	RK02MGY



Connector No.	E36
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Type	RH2BF-NJ4-DH



14	L	G SW1
15	SB	RR SENSOR SIG
16	BR	IGN
20	Y	4WD COMM
21	G	FR SENSOR VB
22	L	CAN H
23	W	FL SENSOR VB
24	GR	DIAG K
26	BR	RL SENSOR VB
27	P	FL SENSOR SIG
28	Y	G GND
29	R	G SW2
30	G	RL SENSOR SIG

Terminal No.	Color of Wire	Signal Name [Specification]
59	BR	-

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	MOTOR
2	BR	ACTR
3	B	GND A
4	B	GND M
5	BR	VDC OFF SW
6	GR	ASCD CANCEL SW
8	SB	STOP LAMP SW
9	P	CAN L
11	O	RR SENSOR VB
12	R	FR SENSOR SIG
13	B	G CHECK

Terminal No.	Color of Wire	Signal Name [Specification]
1	Y	MOTOR
2	BR	ACTR
3	B	GND A
4	B	GND M
5	BR	VDC OFF SW
6	GR	ASCD CANCEL SW
8	SB	STOP LAMP SW
9	P	CAN L
11	O	RR SENSOR VB
12	R	FR SENSOR SIG
13	B	G CHECK

JCFWM0256Gt

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

## BRAKE CONTROL SYSTEM (WITH VDC)

Connector No.	E27
Connector Name	BRAKE FLUID LEVEL SWITCH
Connector Type	YV02PGY




Terminal No.	Color of Wire	Signal Name [Specification]
1	LG	-
2	B	-

Connector No.	E39
Connector Name	FRONT WHEEL SENSOR RH
Connector Type	PK02MGY



Terminal No.	Color of Wire	Signal Name [Specification]
3	G	-
4	R	-

Connector No.	E101
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CSI6-TM4




Terminal No.	Color of Wire	Signal Name [Specification]
12	BR	-
13	O	-
22	G	-
23	SB	-
32	SHIELD	-
33	L	-
34	B	-
62	Y	-
63	R	-

Connector No.	E103
Connector Name	PARKING BRAKE SWITCH
Connector Type	P01FB-A



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-

Connector No.	E105
Connector Name	WIRE TO WIRE
Connector Type	TH80FW-CSI6-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
4	V	-
12	P	-
15	V	-
21	L	-
22	L	-
24	LG	-
51	L	-
61	BR	-

Connector No.	E112
Connector Name	ASCD BRAKE SWITCH
Connector Type	M02FBR-LG




Terminal No.	Color of Wire	Signal Name [Specification]
1	L	-
2	GR	-

Connector No.	E115
Connector Name	STOP LAMP SWITCH
Connector Type	M04FW-LG



Terminal No.	Color of Wire	Signal Name [Specification]
1	V	-
2	Y	-
3	G	-
4	L	-

Connector No.	M4
Connector Name	DATA LINK CONNECTOR
Connector Type	B010FW



Terminal No.	Color of Wire	Signal Name [Specification]
7	O	-

JCFWM0257Gf

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]


## BRAKE CONTROL SYSTEM (WITH VDC)

Connector No.	M5
Connector Name	VDC OFF SWITCH
Connector Type	TK08FCY



Terminal No.	Color of Wire	Signal Name [Specification]
1	BR	-
2	B	-

Connector No.	M30
Connector Name	STEERING ANGLE SENSOR
Connector Type	TH08FW-NH




Terminal No.	Color of Wire	Signal Name [Specification]
1	W	IGN
3	B	GND
4	L	CAN H
8	P	CAN L

Connector No.	M34
Connector Name	COMBINATION METER
Connector Type	SAB40FW



Terminal No.	Color of Wire	Signal Name [Specification]
21	L	CAN-H
22	P	CAN-L
26	V	PARKING BRAKE SW
27	BR	BRAKE FLUID LEVEL SE

Connector No.	M77
Connector Name	WIRE TO WIRE
Connector Type	TH03MW-GS16-TM4



Terminal No.	Color of Wire	Signal Name [Specification]
4	Y	-
12	P	-
15	V	-
21	O	-
22	L	-
24	BR	-
51	W	-
61	BR	-

## Fail-Safe

### ABS, EBD SYSTEM

In case of electrical malfunctions with the ABS, ABS warning lamp, VDC OFF indicator lamp, SLIP indicator lamp will turn on. In case of electrical malfunctions with the EBD, brake warning lamp, ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp will turn on. Simultaneously, the VDC/TCS/ABS become one of the following conditions of the fail-safe function.

JCFWM0258Gi

INFOID:000000005255601



# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

- For malfunction of ABS, only the EBD is activated and the condition of vehicle is the same condition of vehicles without TCS/ABS system.

## NOTE:

ABS self-diagnosis sound may be heard. That is a normal condition because a self-diagnosis for "Ignition switch ON" and "The first starting" are being performed.

- For malfunction of EBD, EBD and ABS become inoperative, and the condition of vehicle is the same as the condition of vehicles without TCS/ABS, EBD system.

## VDC/TCS

In case of malfunction in the VDC/TCS/ABS system, VDC OFF indicator lamp, SLIP indicator lamp are turned on, and the condition of vehicle is the same as the condition of vehicles without VDC/TCS control.

## CAUTION:

If the Fail-Safe function is activated, then perform self-diagnosis for "ABS" with CONSULT-III.

## DTC Index

INFOID:0000000005255602

DTC	Items (CONSULT screen terms)	Reference
C1101	RR RH SENSOR-1	<a href="#">BRC-99, "DTC Logic"</a>
C1102	RR LH SENSOR-1	
C1103	FR RH SENSOR-1	
C1104	FR LH SENSOR-1	
C1105	RR RH SENSOR-2	<a href="#">BRC-102, "DTC Logic"</a>
C1106	RR LH SENSOR-2	
C1107	FR RH SENSOR-2	
C1108	FR LH SENSOR-2	
C1109	BATTERY VOLTAGE [ABNORMAL]	<a href="#">BRC-105, "DTC Logic"</a>
C1110	CONTROLLER FAILURE	<a href="#">BRC-108, "DTC Logic"</a>
C1111	PUMP MOTOR	<a href="#">BRC-109, "DTC Logic"</a>
C1113	G SENSOR	<a href="#">BRC-111, "DTC Logic"</a>
C1115	ABS SENSOR [ABNORMAL SIGNAL]	<a href="#">BRC-115, "DTC Logic"</a>
C1116	STOP LAMP SW	<a href="#">BRC-118, "DTC Logic"</a>
C1118	4WD SYSTEM	<a href="#">BRC-120, "DTC Logic"</a>
C1120	FR LH IN ABS SOL	<a href="#">BRC-121, "DTC Logic"</a>
C1121	FR LH OUT ABS SOL	<a href="#">BRC-124, "DTC Logic"</a>
C1122	FR RH IN ABS SOL	<a href="#">BRC-121, "DTC Logic"</a>
C1123	FR RH OUT ABS SOL	<a href="#">BRC-124, "DTC Logic"</a>
C1124	RR LH IN ABS SOL	<a href="#">BRC-121, "DTC Logic"</a>
C1125	RR LH OUT ABS SOL	<a href="#">BRC-124, "DTC Logic"</a>
C1126	RR RH IN ABS SOL	<a href="#">BRC-121, "DTC Logic"</a>
C1127	RR RH OUT ABS SOL	<a href="#">BRC-124, "DTC Logic"</a>
C1130	ENGINE SIGNAL 1	<a href="#">BRC-127, "DTC Logic"</a>
C1140	ACTUATOR RLY	<a href="#">BRC-128, "DTC Logic"</a>
C1143	ST ANG SEN CIRCUIT	<a href="#">BRC-130, "DTC Logic"</a>
C1144	ST ANG SEN SIGNAL	
C1145	YAW RATE SENSOR	<a href="#">BRC-111, "DTC Logic"</a>
C1146	SIDE G-SEN CIRCUIT	
C1155	BR FLUID LEVEL LOW	<a href="#">BRC-132, "DTC Logic"</a>
C1164	CV1	<a href="#">BRC-135, "DTC Logic"</a>
C1165	CV2	

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

## ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

< ECU DIAGNOSIS INFORMATION >

[VDC/TCS/ABS]

DTC	Items (CONSULT screen terms)	Reference
C1166	SV1	<a href="#">BRC-137, "DTC Logic"</a>
C1167	SV2	
C1176	STOP LAMP SW2	<a href="#">BRC-139, "DTC Logic"</a>
U1000	CAN COMM CIRCUIT	<a href="#">BRC-141, "DTC Logic"</a>
U1010	CONTROL UNIT(CAN)	<a href="#">BRC-142, "DTC Logic"</a>

# EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

## SYMPTOM DIAGNOSIS

### EXCESSIVE ABS FUNCTION OPERATION FREQUENCY

#### Diagnosis Procedure

INFOID:000000005255603

#### 1.CHECK START

Check front and rear brake force distribution using a brake tester. Refer to [BR-49, "General Specifications"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check brake system.

#### 2.CHECK FRONT AND REAR AXLE

Make sure that there is no excessive play in the front and rear axles.

- Front

- 2WD models: Refer to [FAX-8, "Inspection"](#).

- AWD models: Refer to [FAX-32, "Inspection"](#).

- Rear

- 2WD models: Refer to [RAX-4, "Inspection"](#).

- AWD models: Refer to [RAX-11, "Inspection"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace malfunctioning components.

#### 3.CHECK WHEEL SENSOR AND SENSOR ROTOR

Check the following.

- Wheel sensor installation for damage.

- Sensor rotor installation for damage.

- Wheel sensor connector connection.

- Wheel sensor harness inspection.

Is the inspection result normal?

YES >> GO TO 4.

NO >> • Replace wheel sensor or sensor rotor.

- Repair harness.

#### 4.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp is turned off after the ignition switch is turned ON or when driving.

Is the ABS warning lamp illuminated?

YES >> Perform self-diagnosis for "ABS" with CONSULT-III.

NO >> Normal

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

# UNEXPECTED PEDAL REACTION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

## UNEXPECTED PEDAL REACTION

### Diagnosis Procedure

INFOID:000000005255604

#### 1.CHECK BRAKE PEDAL STROKE

Check brake pedal stroke. Refer to [BR-9, "Inspection and Adjustment"](#).

Is the stroke too large?

- YES >> • Bleed air from brake tube and hose. Refer to [BR-13, "Bleeding Brake System"](#).  
• Check brake pedal, brake booster, and master cylinder for mount play, looseness, brake system fluid leakage, etc.  
- Brake pedal: Refer to [BR-9, "Inspection and Adjustment"](#).  
- Master cylinder: Refer to [BR-14, "Inspection"](#).  
- Brake booster: Refer to [BR-15, "Inspection"](#).

NO >> GO TO 2.

#### 2.CHECK FUNCTION

Disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. Check if braking force is normal in this condition. Connect connector after inspection.

Is the inspection result normal?

- YES >> Normal  
NO >> Check brake system.

## THE BRAKING DISTANCE IS LONG

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

### THE BRAKING DISTANCE IS LONG

#### Diagnosis Procedure

INFOID:000000005255605

#### CAUTION:

The stopping distance on slippery road surfaces might be longer with the ABS operating than when the ABS is not operating.

#### 1. CHECK FUNCTION

Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector to deactivate ABS. In this condition, check stopping distance. After inspection, connect connector.

Is the inspection result normal?

YES >> Normal

NO >> Check brake system.

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

## ABS FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

### ABS FUNCTION DOES NOT OPERATE

#### Diagnosis Procedure

INFOID:000000005255606

#### **CAUTION:**

**ABS does not operate when speed is 10 km/h (6 MPH) or lower.**

#### **1**.CHECK ABS WARNING LAMP DISPLAY

Make sure that the ABS warning lamp turns OFF after ignition switch is turned ON or when driving.

Is the inspection result normal?

YES >> Normal

NO >> Perform self-diagnosis for "ABS" with CONSULT-III.

# PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

## PEDAL VIBRATION OR ABS OPERATION SOUND OCCURS

### Diagnosis Procedure

INFOID:000000005255607

#### CAUTION:

Under the following conditions, ABS is activated and vibration is felt when brake pedal is lightly depressed (just place a foot on it). However, this is normal.

- When shifting gears
- When driving on slippery road
- During cornering at high speed
- When passing over bumps or grooves [at approximately 50 mm (1.97 in) or more]
- When pulling away just after starting engine [at approximately 10 km/h (6 MPH) or higher]

### 1. SYMPTOM CHECK 1

Check that there are pedal vibrations when the engine is started.

Do vibrations occur?

YES >> GO TO 2.

NO >> Inspect the brake pedal.

### 2. SYMPTOM CHECK 2

Check that there are ABS operation noises when the engine is started.

Do the operation noises occur?

YES >> GO TO 3.

NO >> Perform self-diagnosis for "ABS" with CONSULT-III.

### 3. SYMPTOM CHECK 3

Check symptoms when electrical component (headlamps, etc.) switches are operated.

Do symptoms occur?

YES >> Check if there is a radio, antenna, antenna lead wire, or wiring close to the control unit. If there is, move it farther away.

NO >> Normal

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

## VEHICLE JERKS DURING VDC/TCS/ABS CONTROL

### Diagnosis Procedure

INFOID:000000005255608

#### 1.SYMPTOM CHECK

Check if the vehicle jerks during VDC/TCS/ABS control.

Is the inspection result normal?

- YES >> Normal.
- NO >> GO TO 2.

#### 2.CHECK SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ABS" with CONSULT-III.

Are self-diagnosis results indicated?

- YES >> Check corresponding items, make repairs, and perform self-diagnosis for "ABS" with CONSULT-III.
- NO >> GO TO 3.

#### 3.CHECK CONNECTOR

- Turn ignition switch OFF and disconnect ABS actuator and electric unit (control unit) connector and check terminal for deformation, disconnection, looseness, etc.
- Securely connect connectors and perform self-diagnosis for "ABS" with CONSULT-III.

Are self-diagnosis results indicated?

- YES >> If poor contact, damage, open or short circuit of connector terminal is found, repair or replace.
- NO >> GO TO 4.

#### 4.CHECK ECM AND TCM SELF-DIAGNOSIS RESULTS

Perform self-diagnosis for "ENGINE" and "TRANSMISSION" with CONSULT-III.

Are self-diagnosis results indicated?

- YES >> Check the corresponding items.
  - "ENGINE"
    - For CALIFORNIA: Refer to [EC-107, "CONSULT-III Function"](#).
    - For USA (FEDERAL) and CANADA: Refer to [EC-588, "CONSULT-III Function"](#).
    - For MEXICO: Refer to [EC-1022, "CONSULT-III Function"](#).
  - "TRANSMISSION": Refer to [TM-42, "Diagnosis Description"](#).
- NO >> Replace ABS actuator and electric unit (control unit).



# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[VDC/TCS/ABS]

## NORMAL OPERATING CONDITION

### Description

INFOID:0000000005255609

Symptom	Result
Slight vibrations are felt on the brake pedal and the operation noises occur, when VDC, TCS or ABS is activated.	This is a normal condition due to the VDC, TCS or ABS activation.
Stopping distance is longer than that of vehicles without ABS when the vehicle drives on rough, gravel, or snow-covered (fresh, deep snow) roads.	
The brake pedal moves and generates noises, when TCS or VDC is activated due to rapid acceleration or sharp turn.	
The brake pedal vibrates and motor operation noises occur from the engine room, after the engine starts and just after the vehicle starts.	This is a normal, and it is caused by the ABS operation check.
Depending on the road conditions, the driver may experience a sluggish feel.	This is normal, because TCS places the highest priority on the optimum traction (stability).
TCS may activate momentarily if wheel speed changes when driving over location where friction coefficient varies, when downshifting, or when fully depressing accelerator pedal.	
The ABS warning lamp, VDC OFF indicator lamp and SLIP indicator lamp may turn ON when the vehicle is subject to strong shaking or large vibration, such as when the vehicle is rotating on a turntable or located on a ship while the engine is running.	In this case, restart the engine on a normal road. If the normal condition is restored, there is no malfunction. At that time, erase the self-diagnosis memory.
VDC may not operate normally or the ABS warning lamp, VDC OFF indicator lamp, and SLIP indicator lamp may illuminate, when running on a special road that is extremely slanted (e.g. bank in a circuit course).	
A malfunction may occur in the yaw rate/side G sensor system, when the vehicle turns sharply, such as during a spin turn, axle turn, or drift driving, while the VDC function is off (VDC OFF indicator lamp illuminated).	
The vehicle speed will not increase even though the accelerator pedal is depressed, when inspecting the speedometer on a 2-wheel chassis dynamometer.	Normal (Deactivate the VDC/TCS function before performing an inspection on a chassis dynamometer.)

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N

O

P

## PRECAUTION

### PRECAUTIONS

#### FOR USA AND CANADA

#### FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005530547

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted.

Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


#### **WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

#### FOR USA AND CANADA : Precaution for Procedure without Cowl Top Cover

INFOID:000000005530587

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



#### FOR USA AND CANADA : Precaution for Brake System

INFOID:000000005255612

#### **WARNING:**

**Clean any dust from the front brake and rear brake with a vacuum dust collector. Never blow with compressed air.**


- Only use "DOT 3" brake fluid. Refer to [MA-14, "FOR NORTH AMERICA : Fluids and Lubricants"](#).
- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.

## PRECAUTIONS

### < PRECAUTION >

[VDC/TCS/ABS]

- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crowfoot (A) and torque wrench (B).
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



### FOR USA AND CANADA : Precaution for Brake Control

INFOID:0000000005255613

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.
- VDC system may not operate normally or a VDC OFF indicator lamp or SLIP indicator lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

### FOR USA AND CANADA : Precautions for Harness Repair


INFOID:0000000005530646

#### COMMUNICATION LINE

- Solder the repaired area and wrap tape around the soldered area.

#### NOTE:

A fray of twisted lines must be within 110 mm (4.33 in).



## PRECAUTIONS

< PRECAUTION >


[VDC/TCS/ABS]

- Bypass connection is never allowed at the repaired area.

**NOTE:**

Bypass connection may cause communication error as spliced wires that are separate from the main line or twisted lines lose noise immunity.

- Replace the applicable harness as an assembly if error is detected on the shield lines of communication line.



### FOR MEXICO

### FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000005530548

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the "SRS AIR BAG".
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS


**WARNING:**

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

### FOR MEXICO : Precaution for Procedure without Cowl Top Cover

INFOID:000000005530607

When performing the procedure after removing cowl top cover, cover the lower end of windshield with urethane, etc.



### FOR MEXICO : Precaution for Brake System

INFOID:0000000055255616

**WARNING:**

Clean any dust from the front brake and rear brake with a vacuum dust collector. Never blow with compressed air.


- Only use "DOT 3" brake fluid. Refer to [MA-15, "FOR MEXICO : Fluids and Lubricants"](#).

## PRECAUTIONS

< PRECAUTION >

[VDC/TCS/ABS]

- Never reuse drained brake fluid.
- Never spill or splash brake fluid on painted surfaces. Brake fluid may seriously damage paint. Wipe it off immediately and wash with water if it gets on a painted surface.
- Never use mineral oils such as gasoline or light oil to clean. They may damage rubber parts and cause improper operation.
- Always loosen the brake tube flare nut with a flare nut wrench.
- Tighten the brake tube flare nut to the specified torque with crow-foot (A) and torque wrench (B).
- Always confirm the specified tightening torque when installing the brake pipes.
- Turn the ignition switch OFF and disconnect the ABS actuator and electric unit (control unit) connector or the battery negative terminal before performing the work.
- Check that no brake fluid leakage is present after replacing the parts.



### FOR MEXICO : Precaution for Brake Control

INFOID:000000005255617

BRC

- When starting engine or when starting vehicle just after starting engine, brake pedal may vibrate or motor operating noise may be heard from engine compartment. This is normal condition.
- When an error is indicated by ABS or another warning lamp, collect all necessary information from customer (what symptoms are present under what conditions) and check for estimate causes before starting diagnostic servicing. Besides electrical system inspection, check brake booster operation, brake fluid level, and oil leaks.
- If tire size and type are used in an improper combination, or brake pads are not Genuine NISSAN parts, stopping distance or steering stability may deteriorate.
- ABS might be out of order or malfunctions by putting a radio (wiring inclusive), an antenna and a lead-in wire near the control unit.
- If aftermarket parts (car stereo, CD player, etc.) have been installed, check for incidents such as harness pinches, open circuits, and improper wiring.
- VDC system may not operate normally or a VDC OFF indicator lamp or SLIP indicator lamp may light.
- When replacing the following parts with parts other than genuine parts or making modifications: Suspension-related parts (shock absorber, spring, bushing, etc.), tires, wheels (other than specified sizes), brake-related parts (pad, rotor, caliper, etc.), engine-related parts (muffler, ECM, etc.) and body reinforcement-related parts (roll bar, tower bar, etc.).
- When driving with worn or deteriorated suspension, tires and brake-related parts.

### FOR MEXICO : Precautions for Harness Repair


INFOID:000000005530647

#### COMMUNICATION LINE

- Solder the repaired area and wrap tape around the soldered area.

#### NOTE:

A fray of twisted lines must be within 110 mm (4.33 in).



## PRECAUTIONS

[VDC/TCS/ABS]


### < PRECAUTION >

- Bypass connection is never allowed at the repaired area.

**NOTE:**

Bypass connection may cause communication error as spliced wires that are separate from the main line or twisted lines lose noise immunity.

- Replace the applicable harness as an assembly if error is detected on the shield lines of communication line.




## REMOVAL AND INSTALLATION

## WHEEL SENSOR

## FRONT WHEEL SENSOR

## FRONT WHEEL SENSOR : Exploded View

INFOID:0000000005255618



1. Front LH wheel sensor

A. Yellow line (slant line)

Refer to [GI-4, "Components"](#) for symbol in the figure.**NOTE:**

The above figure (front side) shows left side. Right side is the mirror image.

## FRONT WHEEL SENSOR : Removal and Installation

INFOID:0000000005255619

## REMOVAL

Pay attention to the following when removing sensor.

**CAUTION:**

- **Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.**
- **Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.**
- **When you see the harness of the wheel sensor from the front side of the vehicle ensure that the yellow lines (A) are not twisted.**

## INSTALLATION

Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.

## REAR WHEEL SENSOR


# WHEEL SENSOR

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

## REAR WHEEL SENSOR : Exploded View

INFOID:000000005255620



1. Rear LH wheel sensor

A. 2WD models

B. AWD models

Refer to [GI-4, "Components"](#) for symbol in the figure.

### NOTE:

The above figure (front side) shows left side. Right side is the mirror image.

## REAR WHEEL SENSOR : Removal and Installation

INFOID:000000005255621

### REMOVAL

Pay attention to the following when removing sensor.

#### CAUTION:

- **Never twist sensor harness as much as possible, when removing it. Pull sensors out without pulling sensor harness.**
- **Take care to avoid damaging sensor edges or rotor teeth. Remove wheel sensor first before removing front or rear wheel hub. This is to avoid damage to sensor wiring and loss of sensor function.**

### INSTALLATION

Pay attention to the following when installing wheel sensor. Tighten installation bolts to the specified torques.

- When installing, make sure there is no foreign material such as iron chips on and in the mounting hole of the wheel sensor. Make sure no foreign material has been caught in the sensor rotor. Remove any foreign material and clean the mount.
- When installing wheel sensor, be sure to press rubber grommets in until they lock at locations shown above in the figure. When installed, harness must not be twisted.



# SENSOR ROTOR

< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

## SENSOR ROTOR

### FRONT SENSOR ROTOR

#### FRONT SENSOR ROTOR : Exploded View

INFOID:0000000005255622

Refer to [FAX-10. "Exploded View"](#) (2WD models), [FAX-34. "Exploded View"](#) (AWD models).

#### FRONT SENSOR ROTOR : Removal and Installation

INFOID:0000000005255623

#### REMOVAL

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [FAX-10. "Removal and Installation"](#) (2WD models), [FAX-34. "Removal and Installation"](#) (AWD models).

#### INSTALLATION

Sensor rotor cannot be disassembled. Installation the sensor rotor together with hub bearing assembly. Refer to [FAX-34. "Removal and Installation"](#) (2WD models), [FAX-34. "Removal and Installation"](#) (AWD models).

### REAR SENSOR ROTOR

#### REAR SENSOR ROTOR : Exploded View

INFOID:0000000005255624

Refer to [RAX-5. "Exploded View"](#) (2WD models), [RAX-15. "Exploded View"](#) (AWD models).

#### REAR SENSOR ROTOR : Removal and Installation

INFOID:0000000005255625

#### 2WD MODELS

##### Removal

Sensor rotor cannot be disassembled. Remove the sensor rotor together with hub bearing assembly. Refer to [RAX-5. "Removal and Installation"](#).

##### Installation

Sensor rotor cannot be disassembled. Installation the sensor rotor together with hub bearing assembly. Refer to [RAX-5. "Removal and Installation"](#).

#### AWD MODELS

For removal and installation of sensor rotor, refer to [RAX-16. "Disassembly and Assembly"](#).

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

# ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

## ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### Exploded View

INFOID:000000005255626



1. ABS actuator and electric unit (control unit) 2. Connector

3. Bracket

- A. To front LH brake caliper B. To rear RH brake caliper C. To Rear LH brake caliper  
D. To front RH brake caliper E. From master cylinder primary side F. From master cylinder secondary side

↔: Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

### Removal and Installation

INFOID:000000005255627

#### REMOVAL

##### CAUTION:

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-13, "Bleeding Brake System"](#).

1. Remove cowl top. Refer to [EXT-20, "Exploded View"](#).
2. Disconnect ABS actuator and electric unit (control unit) connector.
3. Loosen brake tube flare nuts, then remove brake tubes from ABS actuator and electric unit (control unit).
4. Remove tire (front LH side).
5. Remove fender protector (rear): (front LH side). Refer to [EXT-22, "Exploded View"](#).
6. Remove ABS actuator and electric unit (control unit) bracket mounting nut.
7. Remove ABS actuator and electric unit (control unit) from vehicle.

#### INSTALLATION

## ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

### < REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

Note the following, and install in the reverse order of removal.

- Before servicing, disconnect the battery cable from negative terminal.
- To remove brake tube, use a flare nut wrench to prevent flare nuts and brake tube from being damaged. To install, use flare nut crowfoot and torque wrench.
- Never apply excessive impact to ABS actuator and electric unit (control unit), such as dropping it.
- Never remove and install actuator by holding harness.
- After work is completed, bleed air from brake tube. Refer to [BR-13, "Bleeding Brake System"](#).
- After installing harness connector in the ABS actuator and electric unit (control unit), make sure connector is securely locked.
- When replacing ABS actuator and electric unit (control unit), make sure adjust neutral position of steering angle sensor. Refer to [BRC-76, "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

A

B

C

D

E

BRC

G

H

I

J

K

L

M

N


O

P

## G SENSOR

## Exploded View

INFOID:000000005255628



1. yaw rate/side/decel G sensor      2. Bracket

↔: Vehicle front

Refer to [GI-4, "Components"](#) for symbol in the figure.

## Removal and Installation

INFOID:000000005255629

## REMOVAL

**CAUTION:**

**Never drop or strike yaw rate/side/decel G sensor, or never use power tool etc., because yaw rate/side/decel G sensor is sensitive to the impact.**

1. Remove center console assembly. Refer to [IP-21, "Exploded View"](#).
2. Disconnect yaw rate/side/decel G sensor harness connector.
3. Remove mounting bolts. Remove yaw rate/side/decel G sensor.

## INSTALLATION

Note the following, and install in the reverse order of removal.

- Never drop or strike yaw rate/side/decel G sensor, or never use power tool etc., because yaw rate/side/decel G sensor is sensitive to the impact.

# STEERING ANGLE SENSOR


< REMOVAL AND INSTALLATION >

[VDC/TCS/ABS]

## STEERING ANGLE SENSOR

### Exploded View

INFOID:000000005255630



1. Steering angle sensor

↩: Vehicle front

### Removal and Installation

INFOID:000000005255631

#### REMOVAL

1. Remove spiral cable assembly. Refer to [SR-14. "Exploded View"](#) (for USA and Canada), [SR-39. "Exploded View"](#) (for Mexico).
2. Remove steering angle sensor from spiral cable assembly.

#### INSTALLATION

Note the following, and install in the reverse order of removal.

- After work, make sure to adjust neutral position of steering angle sensor. Refer to [BRC-76. "ADJUSTMENT OF STEERING ANGLE SENSOR NEUTRAL POSITION : Description"](#).

A  
B  
C  
D  
E  
BRC  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P