

SECTION **PWC**

POWER WINDOW CONTROL SYSTEM

A
B
C

CONTENTS

| | |
|--|---|
| <p>BASIC INSPECTION 3</p> <p>DIAGNOSIS AND REPAIR WORK FLOW 3 WorkFlow3</p> <p>INSPECTION AND ADJUSTMENT 4</p> <p>ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL4 ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description4 ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement4</p> <p>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT4 ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description4 ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement4</p> <p>SYSTEM DESCRIPTION 5</p> <p>POWER WINDOW SYSTEM 5 System Diagram5 System Description5 Component Parts Location7 Component Description7</p> <p>DIAGNOSIS SYSTEM (BCM) 8</p> <p>COMMON ITEM8 COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)8</p> <p>RETAIND PWR8 RETAIND PWR : CONSULT Function (BCM - RETAINED PWR)9</p> <p>DTC/CIRCUIT DIAGNOSIS10</p> <p>POWER SUPPLY AND GROUND CIRCUIT10</p> | <p>POWER WINDOW MAIN SWITCH10 POWER WINDOW MAIN SWITCH : Diagnosis Procedure10</p> <p>FRONT POWER WINDOW SWITCH (PASSENGER SIDE)10 FRONT POWER WINDOW SWITCH (PASSENGER SIDE) : Diagnosis Procedure11</p> <p>REAR POWER WINDOW SWITCH11 REAR POWER WINDOW SWITCH : Diagnosis Procedure11</p> <p>FRONT POWER WINDOW SWITCH (PASSENGER SIDE)13 Description13 Component Function Check13 Diagnosis Procedure13 Component Inspection14</p> <p>REAR POWER WINDOW SWITCH15 Description15 Component Function Check15 Diagnosis Procedure15 Component Inspection16</p> <p>POWER WINDOW MOTOR17</p> <p>DRIVER SIDE17 DRIVER SIDE : Description17 DRIVER SIDE : Component Function Check17 DRIVER SIDE : Diagnosis Procedure17 DRIVER SIDE : Component Inspection18</p> <p>PASSENGER SIDE18 PASSENGER SIDE : Description18 PASSENGER SIDE : Component Function Check18 PASSENGER SIDE : Diagnosis Procedure18 PASSENGER SIDE : Component Inspection19</p> <p>REAR LH20 REAR LH : Description20</p> |
|--|---|

D
E
F
G
H
I
J



L
M

N
O

P

| | | | |
|---|-----------|---|-----------|
| REAR LH : Component Function Check | 20 | WITH REAR POWER WINDOW SWITCH LH ONLY | 54 |
| REAR LH : Diagnosis Procedure | 20 | WITH REAR POWER WINDOW SWITCH LH ONLY : Diagnosis Procedure | 54 |
| REAR LH : Component Inspection | 21 | | |
| REAR RH | 21 | REAR RH SIDE POWER WINDOW DOES NOT OPERATE | 55 |
| REAR RH : Description | 21 | WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH | 55 |
| REAR RH : Component Function Check | 21 | WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH : Diagnosis Procedure | 55 |
| REAR RH : Diagnosis Procedure | 22 | | |
| REAR RH : Component Inspection | 23 | WITH REAR POWER WINDOW SWITCH RH ONLY | 55 |
| ENCODER CIRCUIT | 24 | WITH REAR POWER WINDOW SWITCH RH ONLY : Diagnosis Procedure | 55 |
| Description | 24 | | |
| Component Function Check | 24 | ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE) | 56 |
| Diagnosis Procedure | 24 | Diagnosis Procedure | 56 |
| ECU DIAGNOSIS INFORMATION | 27 | POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY | 57 |
| BCM (BODY CONTROL MODULE) | 27 | Diagnosis Procedure | 57 |
| Reference Value | 27 | AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE) | 58 |
| Wiring Diagram - BCM - | 42 | Diagnosis Procedure | 58 |
| Fail-safe | 45 | POWER WINDOW LOCK SWITCH DOES NOT FUNCTION | 59 |
| DTC Inspection Priority Chart | 46 | Diagnosis Procedure | 59 |
| DTC Index | 46 | PRECAUTION | 60 |
| POWER WINDOW MAIN SWITCH | 47 | PRECAUTIONS | 60 |
| Reference Value | 47 | FOR MEXICO | 60 |
| Wiring Diagram - POWER WINDOW CONTROL SYSTEM - | 49 | FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 60 |
| Fail Safe | 49 | FOR USA AND CANADA | 60 |
| SYMPTOM DIAGNOSIS | 51 | FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 60 |
| NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH | 51 | PREPARATION | 62 |
| Diagnosis Procedure | 51 | PREPARATION | 62 |
| DRIVER SIDE POWER WINDOW DOES NOT OPERATE | 52 | Commercial Service Tools | 62 |
| Diagnosis Procedure | 52 | REMOVAL AND INSTALLATION | 63 |
| FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE | 53 | POWER WINDOW MAIN SWITCH | 63 |
| WITH BOTH POWER WINDOW MAIN SWITCH AND FRONT PASSENGER SIDE POWER WINDOW SWITCH | 53 | Exploded View | 63 |
| WITH BOTH POWER WINDOW MAIN SWITCH AND FRONT PASSENGER SIDE POWER WINDOW SWITCH : Diagnosis Procedure | 53 | Removal and Installation | 63 |
| WITH FRONT POWER WINDOW SWITCH ONLY ... | 53 | | |
| WITH FRONT POWER WINDOW SWITCH ONLY : Diagnosis Procedure | 53 | | |
| REAR LH SIDE POWER WINDOW DOES NOT OPERATE | 54 | | |
| WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH LH | 54 | | |
| WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH LH : Diagnosis Procedure | 54 | | |

DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

BASIC INSPECTION

DIAGNOSIS AND REPAIR WORK FLOW

WorkFlow

INFOID:000000007350724

DETAILED FLOW

1.OBTAIN INFORMATION ABOUT SYMPTOM

Interview the customer to obtain the malfunction information (conditions and environment when the malfunction occurred) as much as possible when the customer brings the vehicle in.

>> GO TO 2.

2.REPRODUCE THE MALFUNCTION INFORMATION

Check the malfunction on the vehicle that the customer describes.
Inspect the relation of the symptoms and the condition when the symptoms occur.

>> GO TO 3.

3.IDENTIFY THE MALFUNCTIONING SYSTEM WITH "SYMPTOM DIAGNOSIS"

Use "Symptom diagnosis" from the symptom inspection result in step 2 and then identify where to start performing the diagnosis based on possible causes and symptoms.

>> GO TO 4.

4.IDENTIFY THE MALFUNCTIONING PARTS WITH "COMPONENT DIAGNOSIS"

Perform the diagnosis with "Component diagnosis" of the applicable system.

>> GO TO 5.

5.REPAIR OR REPLACE THE MALFUNCTIONING PARTS

Repair or replace the specified malfunctioning parts.

>> GO TO 6.

6.FINAL CHECK

Check that malfunctions are not reproduced when obtaining the malfunction information from the customer, referring to the symptom inspection result in step 2.

Are the malfunctions corrected?

YES >> INSPECTION END

NO >> GO TO 3.

A
B
C
D
E
F
G
H
I
J
PWC
L
M
N
O
P

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description

INFOID:000000007350725

If any of the following work has been done Initial setting is necessary.

- Power supply to the power window main switch or power window motor is cut off by the removal of battery terminal or the battery fuse is blown.
- Disconnection and connection of power window main switch harness connector.
- Removal and installation of motor from regulator assembly.
- Operation of regulator assembly as an independent unit.
- Removal and installation of glass.
- Removal and installation of door glass run.

The following specified operations can not be performed under the non-initialized condition.

- Auto-up operation
- Anti-pinch function

ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement

INFOID:000000007350726

INITIALIZATION PROCEDURE

1. Disconnect battery minus terminal or power window main switch connector. Reconnect it after a minute or more.
2. Turn ignition switch ON.
3. Operate power window switch to fully open the window. (This operation is unnecessary if the window is already fully open)
4. Continue pulling the power window switch UP (AUTO-UP operation). Even after glass stops at fully closed position, keep pulling the switch for 2 seconds or more.
5. Initializing procedure is completely.
6. Inspect anti-pinch function.

CHECK ANTI-PINCH FUNCTION

1. Fully open the door window.
 2. Place a piece of wood near fully closed position.
 3. Close door glass completely with AUTO-UP.
- Check that glass lowers for approximately 150 mm (5.9 in) without pinching piece of wood and stops.
 - Check that glass does not rise when operating the power window main switch while lowering.

CAUTION:

- Perform initial setting when auto-up operation or anti-pinch function does not operate normally.
- Check that AUTO-UP operates before inspection when system initialization is performed.
- Do not check with hands and other body parts because they may be pinched. Do not get pinched.
- It may switch to fail-safe mode if open/close operation is performed continuously without full close. Perform initial setting in that situation. Refer to [PWC-49, "Fail Safe"](#)
- Finish initial setting. Otherwise, next operation cannot be done.

1. Auto-up operation
2. Anti-pinch function

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Description

INFOID:000000007350727

Refer to [PWC-4, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Description"](#).

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:000000007350728

Refer to [PWC-4, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#) for initialization procedure and check anti-pinch function.

POWER WINDOW SYSTEM


< SYSTEM DESCRIPTION >

SYSTEM DESCRIPTION

POWER WINDOW SYSTEM

System Diagram

INFOID:000000007350729



System Description

INFOID:000000007350730

POWER WINDOW MAIN SWITCH INPUT/OUTPUT SIGNAL CHART

PWC

| Item | Input signal to power window main switch | Power window main switch function | Actuator |
|--|--|-----------------------------------|--|
| Encoder | Encoder pulse signal | Power window control | Front power window motor (driver side) |
| Power window main switch | Front power window motor (driver side) UP/DOWN signal | | |
| Front power window switch (passenger side) | Front power window motor (passenger side) UP/DOWN signal | | |
| Rear power window switch | Rear power window motor UP/DOWN signal | | Rear power window motor (LH & RH) |
| BCM | Retained power signal | | Each power window motor |

FRONT POWER WINDOW SWITCH (PASSENGER SIDE) & REAR POWER WINDOW SWITCH (LH & RH)

INPUT/OUTPUT SIGNAL CHART

POWER WINDOW SYSTEM

< SYSTEM DESCRIPTION >

| Item | Input signal to front power window switch (passenger side) & rear power window switch (LH & RH) | Front power window switch (passenger side) & rear power window switch (LH & RH) function | Actuator |
|--|---|--|---|
| Front power window switch (passenger side) | Front power window motor (passenger side) UP/DOWN signal | Power window control | Front power window motor (passenger side) |
| Rear power window switch (LH & RH) | Rear power window motor (LH & RH) UP/DOWN signal | | Rear power window motor (LH & RH) |

POWER WINDOW OPERATION

- Power window main switch (driver side) can open/close all windows.
- Front & rear power window switch can open/close the corresponding windows.
- Power window system is operable during the retained power operation timer after turning ignition switch ON and OFF.

POWER WINDOW AUTO-OPERATION (FRONT DRIVER SIDE)

- AUTO UP/DOWN operation can be performed when power window main switch turns to AUTO.
- Encoder continues detecting the movement of power window motor and transmits to power window switch as the encoder pulse signal while power window motor is operating.
- Power window switch reads the changes of encoder signal and stops AUTO operation when door glass is at fully opened/closed position.
- Power window motor is operable in case encoder is malfunctioning.

RETAINED POWER OPERATION

Retained power operation is an additional power supply function that enables sunroof system to operate for 45 seconds even when ignition switch is turned OFF.

RETAINED POWER FUNCTION CANCEL CONDITIONS

- Front door CLOSE (door switch OFF) → OPEN (door switch ON).
- When ignition switch is ON again.
- When timer time passes. (45 seconds)

POWER WINDOW LOCK

Ground circuit inside power window main switch shuts off when power window lock switch is ON. This inhibits power window switch operation except with the power window main switch.

ANTI-PINCH SYSTEM (FRONT DRIVER SIDE)

- Pinch foreign material in the door glass during AUTO-UP operation, and it is the anti-pinch function that lowers the door glass 150 mm (5.9 in) when detected.
- Encoder continues detecting the movement of front power window motor (driver side) and transmits to power window main switch as the encoder pulse signal while front power window motor (driver side) is operating.
- Resistance is applied to the front power window motor (driver side) rotation that changes the frequency of encoder pulse signal if foreign material is trapped in the door glass.
- Power window main switch controls to lower the window glass for 150 mm (5.9 in) after it detects encoder pulse signal frequency change.

OPERATION CONDITION

- When front door glass (driver side) AUTO-UP operation is performed (anti-pinch function does not operate just before the door glass closes and is fully closed)

NOTE:


Depending on environment and driving conditions, if a similar impact or load is applied to the door glass, it may lower.

POWER WINDOW SYSTEM

< SYSTEM DESCRIPTION >

Component Parts Location

INFOID:000000007350731



- | | | |
|---------------------------------------|---|---|
| 1. BCM M65, M66, M67 | 2. Front power window motor (driver side) D7 | 3. Rear power window motor LH D82 |
| 4. Power window main switch D5, D6 | 5. Rear power window switch LH D83 | 6. Front door switch (driver side) B34 |

A. Over the globe box

B. View with front door finisher removed.

C. View with rear door finisher removed.

Component Description

INFOID:000000007350732

| Component | Function |
|---|--|
| BCM | <ul style="list-style-type: none"> Supplies power supply to power window switch. Controls retained power. |
| Power window main switch | <ul style="list-style-type: none"> Directly controls all power window motor of all doors. Controls anti-pinch operation of power window. |
| Front power window switch | Controls power window motor of front passenger side door. |
| Rear power window switch (LH & RH) | Controls power window motor of rear right and left doors. |
| Front power window motor (driver side) | <ul style="list-style-type: none"> Integrates the encoder and power window motor. Starts operating with signals from power window main switch. Transmits front power window motor (driver side) rotation as a pulse signal to power window main switch. |
| Front power window motor (passenger side) | Starts operating with signals from power window main switch & front power window switch (passenger side). |
| Rear power window motor (LH & RH) | Starts operating with signals from power window main switch & rear power window switch (LH & RH). |
| Front door switch (diver side) | Detects door open/close condition and transmits to BCM. |

A
B
C
D
E
F
G
H
I
J

PWC

L
M
N
O
P

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000007628024

APPLICATION ITEM

CONSULT can display each diagnostic item using the diagnostic test modes shown following.

| Diagnosis mode | Function description |
|--------------------------|---|
| ECU Identification | BCM part number is displayed. |
| Self-Diagnostic Result | Displays the diagnosis results judged by BCM. Refer to BCS-61, "DTC Index" . |
| Data Monitor | BCM input/output signals are displayed. |
| Active Test | The signals used to activate each device are forcibly supplied from BCM. |
| Work Support | Changes the setting for each system function. |
| Configuration | <ul style="list-style-type: none"> Read and save the vehicle specification. Write the vehicle specification when replacing BCM. |
| CAN Diag Support Monitor | Monitors the reception status of CAN communication viewed from BCM. |

SYSTEM APPLICATION

BCM can perform the following functions for each system.

NOTE:

It can perform the diagnosis modes except the following for all sub system selection items.

×: Applicable item

| System | CONSULT sub system selection item | Diagnosis mode | | |
|--|-----------------------------------|----------------|--------------|-------------|
| | | Work Support | Data Monitor | Active Test |
| Door lock | DOOR LOCK | × | × | × |
| Rear window defogger | REAR DEFOGGER | | × | × |
| Warning chime | BUZZER | | × | × |
| Interior room lamp control | INT LAMP | × | × | × |
| Remote keyless entry system | MULTI REMOTE ENT | × | × | × |
| Exterior lamp | HEAD LAMP | × | × | × |
| Wiper and washer | WIPER | × | × | × |
| Turn signal and hazard warning lamps | FLASHER | | × | × |
| <ul style="list-style-type: none"> Auto air conditioning system Manual air conditioning system | AIR CONDITONER | | × | |
| Intelligent Key system | INTELLIGENT KEY | | × | |
| Combination switch | COMB SW | | × | |
| Body control system | BCM | × | | |
| Immobilizer | IMMU | | × | × |
| Interior room lamp battery saver | BATTERY SAVER | × | × | × |
| Back door open | TRUNK | | × | × |
| Vehicle security system | THEFT ALM | × | × | × |
| RAP system | RETAINED PWR | × | × | × |
| Signal buffer system | SIGNAL BUFFER | | × | × |
| — | FUEL LID* | | | |
| TPMS | AIR PRESSURE MONITOR | × | × | × |
| Panic alarm system | PANIC ALARM | | | × |

*: This item is displayed, but is not function.

RETAINED PWR

DIAGNOSIS SYSTEM (BCM)

< SYSTEM DESCRIPTION >

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000007350734

Data monitor

| Monitor Item | Description |
|--------------|---|
| DOOR SW-DR | Indicates [ON/OFF] condition of driver side door switch. |
| DOOR SW-AS | Indicates [ON/OFF] condition of passenger side door switch. |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

DTC/CIRCUIT DIAGNOSIS

POWER SUPPLY AND GROUND CIRCUIT

POWER WINDOW MAIN SWITCH

POWER WINDOW MAIN SWITCH : Diagnosis Procedure

INFOID:000000007350736

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition OFF.
2. Disconnect power window main switch connector.
3. Turn ignition switch ON.
4. Check voltage between power window main switch harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|--------------------------|----------|--------|--------------------------|
| Power window main switch | | | |
| Connector | Terminal | Ground | Battery voltage |
| D5 | 10 | | |
| D6 | 19 | | |

Is the inspection result normal?

YES >> GO TO 2.

NO >> GO TO 3.

2. CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between power window main switch harness connector and ground.

| Power window main switch | | Ground | Continuity |
|--------------------------|----------|--------|------------|
| Connector | Terminal | | |
| D6 | 17 | | Existed |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Repair or replace harness.

3. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and power window main switch harness connector.

| BCM | | Power window main switch | | Continuity |
|-----------|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M67 | 68 | D5 | 10 | Existed |
| | 69 | D6 | 19 | |

4. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M67 | 68 | | Not existed |
| | 69 | | |

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-65. "Removal and Installation"](#).

NO >> Repair or replace harness.

FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

FRONT POWER WINDOW SWITCH (PASSENGER SIDE) : Diagnosis Procedure

INFOID:000000007350737

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between front power window switch (passenger side) harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|--|----------|--------|--------------------|--------------------------|
| Front power window switch (passenger side) | | | | |
| Connector | Terminal | | | |
| D45 | 8 | Ground | Ignition switch ON | Battery voltage |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 2.

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and front power window switch (passenger side) harness connector.

| BCM | | Front power window switch (passenger side) | | Continuity |
|-----------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M67 | 68 | D45 | 8 | Existed |

4. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M67 | 68 | | Not existed |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-65, "Removal and Installation"](#).
NO >> Repair or replace harness.

REAR POWER WINDOW SWITCH

REAR POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000007350738

1. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power window switch connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window switch harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|--------------------------|----------|--------|--------------------|--------------------------|
| Rear power window switch | | | | |
| Connector | Terminal | | | |
| LH | D83 | Ground | Ignition switch ON | Battery voltage |
| RH | D103 | | | |

Is the inspection result normal?

- YES >> INSPECTION END
NO >> GO TO 2.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

2. CHECK HARNESS CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Check continuity between BCM harness connector and rear power window switch harness connector.

| BCM | | Rear power window switch | | Continuity |
|-----------|----------|--------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| M67 | 68 | LH | D83 | Existed |
| | | RH | D103 | |

4. Check continuity between BCM harness connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|-------------|
| Connector | Terminal | | |
| M67 | 68 | | Not existed |

Is the inspection result normal?

- YES >> Replace BCM. Refer to [BCS-65. "Removal and Installation"](#).
- NO >> Repair or replace harness.

FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Description

INFOID:000000007350739

Front power window motor (passenger side) will be operated if front power window switch (passenger side) is operated.

Component Function Check

INFOID:000000007350740

1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE) FUNCTION

Check front power window motor (passenger side) operation with front power window switch (passenger side).

Is the inspection result normal?

- YES >> Front power window switch (passenger side) is OK.
- NO >> Refer to [PWC-13, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007350741

1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE) INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window switch (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between front power window switch (passenger side) harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|-----------|----------|--------|--|--------------------------|
| Connector | Terminal | | | |
| D45 | 12 | Ground | Power window main switch (passenger side) UP | Battery voltage |
| | | | DOWN | 0 |
| | 11 | | UP | 0 |
| | | | DOWN | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 3.

2. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Check front power window switch (passenger side).

Refer to [PWC-14, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Replace front power window switch (passenger side). Refer to [PWC-63, "Removal and Installation"](#).

3. CHECK FRONT WINDOW SWITCH (PASSENGER SIDE) CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch harness connector and front power window switch (passenger side) harness connector.

| Power window main switch | | Front power window switch (passenger side) | | Continuity |
|--------------------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D5 | 16 | D45 | 12 | Existed |
| | 12 | | 11 | |

4. Check continuity between power window main switch harness connector and ground.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

< DTC/CIRCUIT DIAGNOSIS >

| Power window main switch | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D5 | 16 | | |
| | 12 | | Not existed |

Is the inspection result normal?

YES >> Replace power window main switch.

NO >> Repair or replace harness.

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-45. "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000007350742

1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

1. Turn ignition OFF.
2. Disconnect front power window switch (passenger side) connector.
3. Check front power window switch (passenger side).

| Front power window switch (passenger side) | Terminal | | Front power window switch condition | Continuity |
|---|----------|---|-------------------------------------|------------|
| D45 | 8 | 7 | UP | Existed |
| | 11 | 6 | | |
| | 11 | 6 | NEUTRAL | |
| | 12 | 7 | | |
| | 8 | 6 | DOWN | |
| | 12 | 7 | | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace front power window switch (passenger side). Refer to [PWC-63. "Removal and Installation"](#).

REAR POWER WINDOW SWITCH

< DTC/CIRCUIT DIAGNOSIS >

REAR POWER WINDOW SWITCH

Description

INFOID:000000007350743

Rear power window motor will be operated if rear power window switch is operated.

Component Function Check

INFOID:000000007350744

1. CHECK REAR POWER WINDOW SWITCH FUNCTION

Check rear power window motor operation with rear power window switch.

Is the inspection result normal?

- YES >> Rear power window switch is OK.
- NO >> Refer to [PWC-15, "Diagnosis Procedure"](#).

Diagnosis Procedure

INFOID:000000007350745

1. CHECK REAR POWER WINDOW SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window switch connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window switch harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) | |
|-----------|----------|--------|---------------------------------|--------------------------|-----------------|
| Connector | Terminal | | | | |
| LH: D83 | 2 | Ground | Power window main switch: LH | UP | Battery voltage |
| | | | | DOWN | 0 |
| | 3 | | UP | 0 | |
| | | | DOWN | Battery voltage | |
| RH: D103 | 2 | | Power window main switch: RH | UP | Battery voltage |
| | | | | DOWN | 0 |
| | 3 | | | UP | 0 |
| | | | | DOWN | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> GO TO 3.

2. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-16, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Replace rear power window switch. Refer to [PWC-63, "Removal and Installation"](#).

3. CHECK REAR POWER WINDOW SWITCH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch harness connector and rear power window switch harness connector.

REAR POWER WINDOW SWITCH

< DTC/CIRCUIT DIAGNOSIS >

| Power window main switch | | Rear power window switch | | | Continuity |
|--------------------------|----------|--------------------------|------|----------|------------|
| Connector | Terminal | Connector | | Terminal | |
| D5 | 1 | LH | D83 | 2 | Existed |
| | 3 | | | 3 | |
| | 5 | RH | D103 | 3 | |
| | 7 | | | 2 | |

4. Check continuity between power window main switch harness connector and ground.

| Power window main switch | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D5 | 1 | | Not existed |
| | 3 | | |
| | 5 | | |
| | 7 | | |

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-63, "Removal and Installation"](#) .

NO >> Repair or replace harness.

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

Component Inspection

INFOID:000000007350746

1.CHECK REAR POWER WINDOW SWITCH

- Turn ignition switch OFF.
- Disconnect rear power window switch connector.
- Check rear power window switch.

| Rear power window switch | Terminal | | Rear power window switch condition | Continuity |
|--------------------------|----------|---|------------------------------------|------------|
| LH:D83 RH:D103 | 1 | 5 | UP | Existed |
| | 3 | 4 | | |
| | 3 | 4 | NEUTRAL | |
| | 2 | 5 | | |
| | 1 | 4 | DOWN | |
| | 2 | 5 | | |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace rear power window switch. Refer to [PWC-63, "Removal and Installation"](#).

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

POWER WINDOW MOTOR DRIVER SIDE

DRIVER SIDE : Description

INFOID:000000007350747

Door glass moves UP/DOWN by receiving the signal from power window main switch.

DRIVER SIDE : Component Function Check

INFOID:000000007350748

1. CHECK FRONT POWER WINDOW MOTOR (DRIVER SIDE) OPERATION

Check front power window motor (driver side) operation with power window main switch.

Is the inspection result normal?

- YES >> Front power window motor (driver side) is OK.
 NO >> Refer to [PWC-17, "DRIVER SIDE : Diagnosis Procedure"](#).

DRIVER SIDE : Diagnosis Procedure

INFOID:000000007350749

1. CHECK POWER WINDOW MOTOR (DRIVER SIDE) INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor (driver side) connector.
3. Turn ignition switch ON.
4. Check voltage between power window motor (driver side) harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|-----------|----------|--------|-------------------------------|--------------------------|
| Connector | Terminal | | | |
| D7 | 1 | Ground | Power window main switch UP | Battery voltage |
| | | | Power window main switch DOWN | 0 |
| | 2 | | Power window main switch UP | 0 |
| | | | Power window main switch DOWN | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
 NO >> GO TO 2.

2. CHECK POWER WINDOW MOTOR CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector.
3. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

| Power window main switch | | Front power window motor (driver side) | | Continuity |
|--------------------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D5 | 8 | D7 | 2 | Existed |
| | 11 | | 1 | |

4. Check continuity between power window main switch harness connector and ground.

| Power window main switch | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D5 | 8 | | Not existed |
| | 11 | | |

Is the inspection result normal?

- YES >> Replace power window main switch. Refer to [PWC-63, "Removal and Installation"](#).
 NO >> Repair or replace harness.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P



POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

3. CHECK FRONT POWER WINDOW MOTOR (DRIVER SIDE)

Check front power window motor (driver side).

Refer to [PWC-18, "DRIVER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace power window motor (driver side). Refer to [GW-23, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

DRIVER SIDE : Component Inspection

INFOID:000000007350750

1. CHECK FRONT POWER WINDOW MOTOR (DRIVER SIDE)

1. Turn ignition switch OFF.
2. Disconnect front power window motor (driver side) connector.
3. Check motor operate by connecting the battery voltage directly to front power window motor (driver side) connector.

| Front power window motor (driver side) connector | Terminal | | Motor condition |
|--|----------|-----|-----------------|
| | (+) | (-) | |
| D7 | 1 | 2 | DOWN |
| | 2 | 1 | UP |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace front power window motor (driver side). Refer to [GW-23, "Removal and Installation"](#).

PASSENGER SIDE

PASSENGER SIDE : Description

INFOID:000000007350751

Door glass moves UP/DOWN by receiving the signal from power window main switch or front power window switch (passenger side).

PASSENGER SIDE : Component Function Check

INFOID:000000007350752

1. CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE) OPERATION

Check front power window motor (passenger side) operation with power window main switch or front power window switch (passenger side).

Is the inspection result normal?

YES >> Power window motor (passenger side) is OK.

NO >> Refer to [PWC-18, "PASSENGER SIDE : Diagnosis Procedure"](#).

PASSENGER SIDE : Diagnosis Procedure

INFOID:000000007350753

1. CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE) INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect front power window motor (passenger side) connector.
3. Turn ignition switch ON.
4. Check voltage between front power window motor (passenger side) harness connector and ground.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

| (+) | | (-) | Condition | Voltage (V) (Approx.) | |
|---|----------|--------|--|--------------------------|-----------------|
| Front power window motor (passenger side) | | | | | |
| Connector | Terminal | | | | |
| D46 | 2 | Ground | Front power window switch (passenger side) | UP | Battery voltage |
| | | | | DOWN | 0 |
| | 1 | | UP | 0 | |
| | | | DOWN | Battery voltage | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE) CIRCUIT

- Turn ignition switch OFF.
- Disconnect front power window switch (passenger side) connector.
- Check continuity between front power window switch (passenger side) harness connector and front power window motor (passenger side) harness connector.

| Front power window switch (passenger side) | | Front power window motor (passenger side) | | Continuity |
|--|----------|---|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D45 | 6 | D46 | 1 | Existed |
| | 7 | | 2 | |

- Check continuity between front power window switch (passenger side) harness connector and ground.

| Front power window switch (passenger side) | | Ground | Continuity |
|--|----------|--------|-------------|
| Connector | Terminal | | |
| D45 | 6 | | Not existed |
| | 7 | | |

Is the inspection result normal?

YES >> Replace front power window switch (passenger side). [PWC-63, "Removal and Installation"](#).

NO >> Repair or replace harness.

3.CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE)

Check front power window motor (passenger side).

Refer to [PWC-19, "PASSENGER SIDE : Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace front power window motor (passenger side). Refer to [GW-23, "Removal and Installation"](#).

4.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

PASSENGER SIDE : Component Inspection

INFOID:000000007350754

1.CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE)

- Turn ignition switch OFF.
- Disconnect front power window motor (passenger side) connector.
- Check motor operate by connecting the battery voltage directly to front power window motor (passenger side) connector.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

| Front power window motor (passenger side) connector | Terminal | | Motor condition |
|---|----------|-----|-----------------|
| | (+) | (-) | |
| D46 | 1 | 2 | DOWN |
| | 2 | 1 | UP |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace front power window motor (passenger side). Refer to [GW-23, "Removal and Installation"](#).

REAR LH

REAR LH : Description

INFOID:000000007350755

Door glass moves UP/DOWN by receiving the signal from power window main switch or rear power window switch LH.

REAR LH : Component Function Check

INFOID:000000007350756

1.CHECK REAR POWER WINDOW MOTOR LH OPERATION

Check rear power window motor LH operation with power window main switch or rear power window switch LH.

Is the inspection result normal?

YES >> Rear power window motor LH is OK.

NO >> Refer to [PWC-20, "REAR LH : Diagnosis Procedure"](#)

REAR LH : Diagnosis Procedure

INFOID:000000007350757

1.CHECK REAR POWER WINDOW MOTOR LH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor LH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor LH harness connector and ground.

| (+) Rear power window motor LH Connector | | Terminal | (-) Ground | Condition Rear power window switch LH | Voltage (V) (Approx.) |
|--|----------|----------|------------|---------------------------------------|-----------------------|
| Connector | Terminal | | | | |
| D82 | 1 | 3 | Ground | UP | Battery voltage |
| | | | | DOWN | 0 |
| | UP | | | 0 | |
| | DOWN | | | Battery voltage | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> GO TO 2.

2.CHECK REAR POWER WINDOW MOTOR LH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power window switch LH connector.
3. Check continuity between rear power window switch LH harness connector and rear power window motor LH harness connector.

| Rear power window switch LH Connector | | Rear power window motor LH Connector | | Continuity |
|---------------------------------------|----------|--------------------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D83 | 4 | D82 | 3 | Existed |
| | 5 | | 1 | |

4. Check continuity between rear power window switch LH connector and ground.

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

| Rear power window switch LH | | Ground | Continuity |
|-----------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D83 | 4 | | Not existed |
| | 5 | | |

Is the inspection result normal?

- YES >> Replace rear power window switch LH. Refer to [PWC-63, "Removal and Installation"](#).
 NO >> Repair or replace harness.

3. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-21, "REAR LH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
 NO >> Replace rear power window motor LH. Refer to [GW-28, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

REAR LH : Component Inspection

INFOID:000000007350758

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR LH

- Turn ignition switch OFF.
- Disconnect rear power window motor LH connector.
- Check motor operate by connecting the battery voltage directly to rear power window motor LH connector.

| Rear power window motor LH connector | Terminal | | Motor condition |
|--------------------------------------|----------|-----|-----------------|
| | (+) | (-) | |
| D82 | 3 | 1 | DOWN |
| | 1 | 3 | UP |

Is the inspection result normal?

- YES >> INSPECTION END
 NO >> Replace rear power window motor LH. Refer to [GW-28, "Removal and Installation"](#).

REAR RH

REAR RH : Description

INFOID:000000007350759

Door glass moves UP/DOWN by receiving the signal from power window main switch or rear power window switch RH.

REAR RH : Component Function Check

INFOID:000000007350760

1. CHECK REAR POWER WINDOW MOTOR RH OPERATION

Check rear power window motor RH operation with power window main switch or rear power window switch RH.

Is the inspection result normal?

- YES >> Rear power window motor RH is OK.
 NO >> Refer to [PWC-22, "REAR RH : Diagnosis Procedure"](#).

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

REAR RH : Diagnosis Procedure

INFOID:000000007350761

1. CHECK REAR POWER WINDOW MOTOR RH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH connector.
3. Turn ignition switch ON.
4. Check voltage between rear power window motor RH harness connector and ground.

| (+) | | (-) | Condition | Voltage (V) (Approx.) |
|-----------|----------|--------|-----------|--------------------------|
| Connector | Terminal | | | |
| D102 | 1 | Ground | UP | Battery voltage |
| | | | DOWN | 0 |
| | 3 | | UP | 0 |
| | | | DOWN | Battery voltage |

Is the inspection result normal?

- YES >> GO TO 3.
NO >> GO TO 2.

2. CHECK REAR POWER WINDOW MOTOR RH CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear power window switch RH connector.
3. Check continuity between rear power window switch RH harness connector and rear power window motor RH harness connector.

| Rear power window switch RH | | Rear power window motor RH | | Continuity |
|-----------------------------|----------|----------------------------|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D103 | 4 | D102 | 3 | Existed |
| | 5 | | 1 | |

4. Check continuity between rear power window switch RH harness connector and ground.

| Rear power window switch RH | | Ground | Continuity |
|-----------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D103 | 4 | | Not existed |
| | 5 | | |

Is the inspection result normal?

- YES >> Replace rear power window switch RH. Refer to [PWC-63, "Removal and Installation"](#).
NO >> Repair or replace harness.

3. CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.
Refer to [PWC-23, "REAR RH : Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 4.
NO >> Replace rear power window motor RH. Refer to [GW-28, "Removal and Installation"](#).

4. CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

POWER WINDOW MOTOR

< DTC/CIRCUIT DIAGNOSIS >

REAR RH : Component Inspection

INFOID:000000007350762

COMPONENT INSPECTION

1. CHECK REAR POWER WINDOW MOTOR RH

1. Turn ignition switch OFF.
2. Disconnect rear power window motor RH connector.
3. Check motor operation by connecting the battery voltage directly to rear power window motor RH connector.

| Rear power window motor RH connector | Terminal | | Motor condition |
|--------------------------------------|----------|-----|-----------------|
| | (+) | (-) | |
| D102 | 3 | 1 | DOWN |
| | 1 | 3 | UP |

Is the inspection result normal?

YES >> INSPECTION END

NO >> Replace rear power window motor RH. Refer to [GW-28. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ENCODER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

ENCODER CIRCUIT

Description

INFOID:000000007350767

Detects condition of the front power window motor (driver side) operation and transmits to power window main switch as pulse signal.

Component Function Check

INFOID:000000007350768

1.CHECK ENCODER OPERATION

Check front driver side door glass perform AUTO open/close operation normally when power window main switch.

Is the inspection result normal?

- YES >> Encoder operation is OK.
- NO >> Refer to [PWC-24, "Diagnosis Procedure"](#)

Diagnosis Procedure


INFOID:000000007350769

Encoder Circuit Check

1.CHECK ENCODER OPERATION

1. Turn ignition switch ON.
2. Check signal between power window main switch harness connector and ground with oscilloscope.

| (+) | | (-) | Signal (Reference value) |
|--------------------------|----------|--------|-----------------------------|
| Power window main switch | | | |
| Connector | Terminal | Ground | Refer to following signal |
| D5 | 9 | | |
| | 13 | | |



Is the inspection result normal?

- YES >> GO TO 7.
- NO >> GO TO 2.

2.CHECK ENCODER SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect power window main switch connector and front power window motor (driver side) connector.
3. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

| Power window main switch | | Front power window motor (driver side) | | Continuity |
|--------------------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D5 | 9 | D7 | 3 | Existed |
| | 13 | | 5 | |

4. Check continuity between power window main switch harness connector and ground.

ENCODER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

| Power window main switch | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D5 | 9 | | Not existed |
| | 13 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

3.CHECK ENCODER POWER SUPPLY CIRCUIT

1. Connect power window main switch connector.
2. Turn ignition switch ON.
3. Check voltage between front power window motor (driver side) harness connector and ground.

| (+) | | (-) | Voltage (V) (Approx.) |
|--|----------|--------|--------------------------|
| Front power window motor (driver side) | | | |
| Connector | Terminal | | |
| D7 | 4 | Ground | Battery voltage |

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 5.

4.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between front power window motor (driver side) harness connector and ground.

| Front power window motor (driver side) | | Ground | Continuity |
|--|----------|--------|------------|
| Connector | Terminal | | |
| D7 | 6 | | Existed |

Is the inspection result normal?

YES >> GO TO 7.

NO >> GO TO 6.

5.CHECK HARNESS CONTINUITY 1

1. Turn ignition switch OFF.
2. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

| Power window main switch | | Front power window motor (driver side) | | Continuity |
|--------------------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D5 | 15 | D7 | 4 | Existed |

3. Check continuity between power window main switch harness connector and ground.

| Power window main switch | | Ground | Continuity |
|--------------------------|----------|--------|-------------|
| Connector | Terminal | | |
| D5 | 15 | | Not existed |

Is the inspection result normal?

YES >> Replace power window main switch. Refer to [PWC-63, "Removal and Installation"](#).

NO >> Repair or replace harness.

6.CHECK HARNESS CONTINUITY 2

1. Disconnect power window main switch connector.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ENCODER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

2. Check continuity between power window main switch harness connector and front power window motor (driver side) harness connector.

| Power window main switch | | Front power window motor (driver side) | | Continuity |
|--------------------------|----------|--|----------|------------|
| Connector | Terminal | Connector | Terminal | |
| D5 | 2 | D7 | 6 | Existed |

Is the inspection result normal?

- YES >> Replace power window main switch. Refer to [PWC-63, "Removal and Installation"](#).
NO >> Repair or replace harness.

7. CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> INSPECTION END

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

ECU DIAGNOSIS INFORMATION

BCM (BODY CONTROL MODULE)

Reference Value

INFOID:000000007628027

VALUES ON THE DIAGNOSIS TOOL

| Monitor Item | Condition | Value/Status |
|----------------|---|--------------|
| IGN ON SW | Ignition switch OFF or ACC | Off |
| | Ignition switch ON | On |
| KEY ON SW | Mechanical key is removed from key cylinder | Off |
| | Mechanical key is inserted to key cylinder | On |
| CDL LOCK SW | Door lock/unlock switch does not operate | Off |
| | Press door lock/unlock switch to the lock side | On |
| CDL UNLOCK SW | Door lock/unlock switch does not operate | Off |
| | Press door lock/unlock switch to the unlock side | On |
| DOOR SW-DR | Driver's door closed | Off |
| | Driver's door opened | On |
| DOOR SW-AS | Passenger door closed | Off |
| | Passenger door opened | On |
| DOOR SW-RR | Rear RH door closed | Off |
| | Rear RH door opened | On |
| DOOR SW-RL | Rear LH door closed | Off |
| | Rear LH door opened | On |
| BACK DOOR SW | Back door closed | Off |
| | Back door opened | On |
| KEY CYL LK-SW | Other than driver door key cylinder LOCK position | Off |
| | Driver door key cylinder LOCK position | On |
| KEY CYL UN-SW | Other than driver door key cylinder UNLOCK position | Off |
| | Driver door key cylinder UNLOCK position | On |
| KEYLESS LOCK | "LOCK" button of key fob is not pressed | Off |
| | "LOCK" button of key fob is pressed | On |
| KEYLESS UNLOCK | "UNLOCK" button of key fob is not pressed | Off |
| | "UNLOCK" button of key fob is pressed | On |
| I-KEY LOCK | "LOCK" button of Intelligent Key or door request switch are not pressed | Off |
| | "LOCK" button of Intelligent Key or door request switch are pressed | On |
| I-KEY UNLOCK | "UNLOCK" button of Intelligent Key or door request switch are not pressed | Off |
| | "UNLOCK" button of Intelligent Key or door request switch are pressed | On |
| ACC ON SW | Ignition switch OFF | Off |
| | Ignition switch ACC or ON | On |
| REAR DEF SW | Rear window defogger switch OFF | Off |
| | Rear window defogger switch ON | On |
| LIGHT SW 1ST | Lighting switch OFF | Off |
| | Lighting switch 1ST | On |

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|----------------|---|--------------|
| BUCKLE SW | The seat belt (driver side) is unfastened. [Seat belt switch (driver side) OFF] | Off |
| | The seat belt (driver side) is fastened. [Seat belt switch (driver side) ON] | On |
| KEYLESS PANIC | PANIC button of key fob is not pressed | Off |
| | PANIC button of key fob is pressed | On |
| KEYLESS TRUNK | NOTE: The item is indicated, but not monitored. | Off |
| TRNK OPN MNTR | NOTE: The item is indicated, but not monitored. | Off |
| RKE LCK-UNLCK | LOCK/UNLOCK button of key fob is not pressed and held simultaneously | Off |
| | LOCK/UNLOCK button of key fob is pressed and held simultaneously | On |
| RKE KEEP UNLK | UNLOCK button of key fob is not pressed | Off |
| | UNLOCK button of key fob is pressed and held | On |
| HI BEAM SW | Lighting switch OFF | Off |
| | Lighting switch HI | On |
| HEAD LAMP SW 1 | Lighting switch OFF | Off |
| | Lighting switch 2ND | On |
| HEAD LAMP SW 2 | Lighting switch OFF | Off |
| | Lighting switch 2ND | On |
| AUTO LIGHT SW | Other than lighting switch AUTO | Off |
| | Lighting switch AUTO | On |
| PASSING SW | Other than lighting switch PASS | Off |
| | Lighting switch PASS | On |
| FR FOG SW | Front fog lamp switch OFF | Off |
| | Front fog lamp switch ON | On |
| RR FOG SW | NOTE: The item is indicated, but not monitored. | Off |
| TURN SIGNAL R | Turn signal switch OFF | Off |
| | Turn signal switch RH | On |
| TURN SIGNAL L | Turn signal switch OFF | Off |
| | Turn signal switch LH | On |
| ENGINE RUN | Engine stopped | Off |
| | Engine running | On |
| PKB SW | Parking brake switch is OFF | Off |
| | Parking brake switch is ON | On |
| CARGO LAMP SW | NOTE: The item is indicated, but not monitored. | Off |
| OPTICAL SENSOR | Bright outside of the vehicle | Close to 5 V |
| | Dark outside of the vehicle | Close to 0 V |
| IGN SW CAN | Ignition switch OFF or ACC | Off |
| | Ignition switch ON | On |
| FR WIPER HI | Front wiper switch OFF | Off |
| | Front wiper switch HI | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status | |
|---------------|---|-----------------------------------|-----|
| FR WIPER LOW | Front wiper switch OFF | Off | A |
| | Front wiper switch LO | On | |
| FR WIPER INT | Front wiper switch OFF | Off | B |
| | Front wiper switch INT | On | |
| FR WASHER SW | Front washer switch OFF | Off | C |
| | Front washer switch ON | On | |
| INT VOLUME | Wiper intermittent dial is in a dial position 1 - 7 | 1 - 7 | |
| FR WIPER STOP | Any position other than front wiper stop position | Off | D |
| | Front wiper stop position | On | |
| VEHICLE SPEED | While driving | Equivalent to speedometer reading | |
| RR WIPER ON | Rear wiper switch OFF | Off | E |
| | Rear wiper switch ON | On | |
| RR WIPER INT | Rear wiper switch OFF | Off | F |
| | Rear wiper switch INT | On | |
| RR WASHER SW | Rear washer switch OFF | Off | G |
| | Rear washer switch ON | On | |
| RR WIPER STOP | Rear wiper stop position | Off | H |
| | Other than rear wiper stop position | On | |
| RR WIPER STP2 | NOTE: The item is indicated, but not monitored. | Off | |
| H/L WASH SW | NOTE: The item is indicated, but not monitored. | Off | I |
| HAZARD SW | Hazard switch OFF | Off | J |
| | Hazard switch ON | On | |
| BRAKE SW | Brake pedal is not depressed | Off | |
| | Brake pedal is depressed | On | |
| FAN ON SIG | Blower fan motor switch OFF | Off | PWC |
| | Blower fan motor switch ON (other than OFF) | On | |
| AIR COND SW | <ul style="list-style-type: none"> • A/C conditioner OFF (A/C switch indicator OFF) (Automatic air conditioner) • A/C switch OFF (Manual air conditioner) | Off | L |
| | <ul style="list-style-type: none"> • A/C conditioner ON (A/C switch indicator ON) (Automatic air conditioner) • A/C switch ON (Manual air conditioner) | On | M |
| I-KEY TRUNK | NOTE: The item is indicated, but not monitored. | Off | N |
| I-KEY PW DWN | UNLOCK button of Intelligent Key is not pressed | Off | |
| | UNLOCK button of Intelligent Key is pressed and held | On | |
| I-KEY PANIC | PANIC button of Intelligent Key is not pressed | Off | O |
| | PANIC button of Intelligent Key is pressed | On | |
| PUSH SW | Return to ignition switch to "LOCK" position | Off | P |
| | Press ignition switch | On | |
| TRNK OPNR SW | When back door opener switch is not pressed | Off | |
| | When back door opener switch is pressed | On | |
| TRUNK CYL SW | NOTE: The item is indicated, but not monitored. | Off | |

BCM (BODY CONTROL MODULE)


< ECU DIAGNOSIS INFORMATION >

| Monitor Item | Condition | Value/Status |
|--------------|--|-------------------------------|
| HOOD SW | Close the hood NOTE: Vehicles of except for Mexico are OFF-fixed | Off |
| | Open the hood | On |
| OIL PRESS SW | <ul style="list-style-type: none"> • Ignition switch OFF or ACC • Engine running | Off |
| | Ignition switch ON | On |
| AIR PRESS FL | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of front LH tire |
| AIR PRESS FR | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of front RH tire |
| AIR PRESS RR | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of rear RH tire |
| AIR PRESS RL | Ignition switch ON (Only when the signal from the transmitter is received) | Air pressure of rear LH tire |
| ID REGST FL1 | ID of front LH tire transmitter is registered | Done |
| | ID of front LH tire transmitter is not registered | Yet |
| ID REGST FR1 | ID of front RH tire transmitter is registered | Done |
| | ID of front RH tire transmitter is not registered | Yet |
| ID REGST RR1 | ID of rear RH tire transmitter is registered | Done |
| | ID of rear RH tire transmitter is not registered | Yet |
| ID REGST RL1 | ID of rear LH tire transmitter is registered | Done |
| | ID of rear LH tire transmitter is not registered | Yet |
| WARNING LAMP | Tire pressure indicator OFF | Off |
| | Tire pressure indicator ON | On |
| BUZZER | Tire pressure warning alarm is not sounding | Off |
| | Tire pressure warning alarm is sounding | On |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

TERMINAL LAYOUT



PHYSICAL VALUES

CAUTION:

- Check combination switch system terminal waveform under the loaded condition with lighting switch, turn signal switch and wiper switch OFF is not to be fluctuated by being overloaded.
- Turn wiper intermittent dial position to 4 except when checking waveform or voltage of wiper intermittent dial position. Wiper intermittent dial position can be confirmed on CONSULT. Refer to [BCS-26, "COMB SW : CONSULT Function \(BCM - COMB SW\)"](#).
- BCM reads the status of the combination switch at 10 ms internal normally. Refer to [BCS-9, "System Diagram"](#).

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|-----------------------------------|-----------|------------------------|
| + | - | Signal name | Input/ Output | Ignition key hole illumination | OFF ON | Battery voltage 0 V |
| 1 (V) | Ground | Ignition key hole illumination control | Output | Ignition key hole illumination | OFF ON | Battery voltage 0 V |






BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | | |
|------------------------------|--------|-------------------------------|------------------|---|--------------------------|-----|-------|
| + | - | Signal name | Input/ Output | | | | |
| 2 (G) | Ground | Combination switch INPUT 5 | Input | Combination switch (Wiper intermit- tent dial 4) | All switch OFF | 0 V | |
| | | | | | Turn signal switch RH | | |
| | | | | | Lighting switch HI | | |
| | | | | | Lighting switch 1ST | | 1.0 V |
| | | | | | Lighting switch 2ND | | 2.0 V |
| 3 (Y) | Ground | Combination switch INPUT 4 | Input | Combination switch (Wiper intermit- tent dial 4) | All switch OFF | 0 V | |
| | | | | | Turn signal switch LH | | |
| | | | | | Lighting switch PASS | | |
| | | | | | Lighting switch 2ND | | 1.0 V |
| | | | | | Front fog lamp switch ON | | 0.8 V |
| 4 (W) | Ground | Combination switch INPUT 3 | Input | Combination switch (Wiper intermit- tent dial 4) | All switch OFF | 0 V | |
| | | | | | Lighting switch AUTO | | |
| | | | | | Front wiper switch LO | | |
| | | | | | Front wiper switch MIST | | |
| Front wiper switch INT | 1.0 V | | | | | | |

BCM (BODY CONTROL MODULE)





< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | | | |
|------------------------------|--------|-------------------------------|------------------|-----------------------|---|---|-------|---|
| | | Signal name | Input/ Output | | | | | |
| + | - | | | | | | | |
| 5 (R) | Ground | Combination switch INPUT 2 | Input | Combination switch | All switch OFF (Wiper intermittent dial 4) | 0 V | A | |
| | | | | | Front washer switch (Wiper intermittent dial 4) |  | B | |
| | | | | | Rear washer ON (Wiper intermittent dial 4) | | C | |
| | | | | | Any of the condition below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 | | 1.0 V | D |
| | | | | | | | E | |
| | | | | | Rear wiper switch ON (Wiper intermittent dial 4) |  | 0.8 V | F |
| 6 (P) | Ground | Combination switch INPUT 1 | Input | Combination switch | All switch OFF (Wiper intermittent dial 4) | 0 V | G | |
| | | | | | Front wiper switch HI (Wiper intermittent dial 4) |  | H | |
| | | | | | Rear wiper switch INT (Wiper intermittent dial 4) | | I | |
| | | | | | Wiper intermittent dial 3 (All switch OFF) | | 1.0 V | J |
| | | | | | | | K | |
| | | | | | Any of the condition below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 |  | 1.7 V | L |
| | | | | | Any of the condition below with all switch OFF <ul style="list-style-type: none"> • Wiper intermittent dial 6 • Wiper intermittent dial 7 |  | 0.8 V | M |
| | | | | | | | N | |
| | | | | | | | O | |
| | | | | | | | P | |

PWC




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|--------------------------------|--|--|
| + | - | Signal name | Input/ Output | | | |
| 7 (L) | Ground | Door key cylinder switch UNLOCK signal | Input | Door key cylinder switch | NEUTRAL position |  <small>JPMIA0587GB</small> 8.0 - 8.5 V |
| | | | | | UNLOCK position | 0 V |
| 8 (R) | Ground | Door key cylinder switch LOCK signal | Input | Door key cylinder switch | NEUTRAL position |  <small>JPMIA0587GB</small> 8.0 - 8.5 V |
| | | | | | LOCK position | 0 V |
| 9 (R) | Ground | Stop lamp switch | Input | Stop lamp switch | OFF (Brake pedal is not depressed) | 0 V |
| | | | | | ON (Brake pedal is de- pressed) | Battery voltage |
| 10 (SB) | Ground | Rear window defog- ger switch | Input | Rear window defogger switch | Not pressed | Battery voltage |
| | | | | | Pressed | 0 V |
| 11 (SB) | Ground | Ignition switch ACC | Input | Ignition switch OFF | 0 V | |
| | | | | Ignition switch ACC or ON | Battery voltage | |
| 12 (P) | Ground | Passenger door switch | Input | Passenger door switch | OFF (When passenger door closed) |  <small>JPMIA0586GB</small> 7.5 - 8.0 V |
| | | | | | ON (When passenger door opened) | 0 V |
| 13 (LG) | Ground | Rear door switch RH | Input | Rear door switch RH | OFF (When rear door RH closed) |  <small>JPMIA0587GB</small> 8.0 - 8.5 V |
| | | | | | ON (When rear door RH opened) | 0 V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >





| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|--|--|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 14 (G) | Ground | Optical sensor | Input | Ignition switch ON | When bright outside of the vehicle | Close to 5 V |
| | | | | | When dark outside of the vehicle | Close to 0 V |
| 17 (W) | Ground | Optical sensor power supply | Output | Ignition switch | OFF, ACC | 0 V |
| | | | | | ON | 5 V |
| 18* (R) | Ground | Receiver and sensor ground | Input | Ignition switch ON | | 0 V |
| 19* (V) | Ground | Remote keyless entry receiver power supply | Input | Without Intelligent Key system | At any condition | 5 V |
| | | | | With Intelligent Key system | <ul style="list-style-type: none"> • Ignition switch OFF • For 3 seconds after ignition switch OFF to ON | 0 V |
| | | | | | 3 seconds or later after ignition switch OFF to ON | 5 V |
| 20* (GR) | Ground | Remote keyless entry receiver signal | Input | Without Intelligent Key system | At any condition |  <p style="text-align: right; font-size: small;">JPMIA0589GB</p> <p>NOTE: The wave form changes according to signal-receiving condition.</p> |
| | | | | <ul style="list-style-type: none"> • Ignition switch OFF • For 3 seconds after ignition switch OFF to ON | 0 V |  <p style="text-align: right; font-size: small;">JPMIA0589GB</p> <p>NOTE: The wave form changes according to signal-receiving condition.</p> |
| 21 (G) | Ground | NATS antenna amp. | Input/ Output | Just after inserting ignition key in key cylinder | | Pointer of tester should move |
| 23 (B) | Ground | Security indicator signal | Input | Security indicator | ON | 0 V |
| | | | | | Blinking (Ignition switch OFF) |  <p style="text-align: right; font-size: small;">JPMIA0590GB</p> <p style="text-align: center;">12.0 V</p> |
| | | | | | OFF | Battery voltage |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) | |
|------------------------------|--------|-----------------------------|------------------|---|---|--|-----|
| + | - | Signal name | Input/ Output | | | | |
| 25 (BR) | Ground | NATS antenna amp. | Input/ Output | Just after inserting ignition key in key cylinder | | Pointer of tester should move | |
| 27 (Y) | Ground | A/C switch | Input | Ignition switch OFF | |  <p style="text-align: center;">1.6 V</p> | |
| | | | | Ignition switch ON | A/C switch OFF | | 0 V |
| | | | | A/C switch ON | | | 0 V |
| 28 (LG) | Ground | Blower fan switch | Input | Ignition switch OFF | |  <p style="text-align: center;">7.0 - 7.5 V</p> | |
| | | | | Ignition switch ON | Blower fan switch OFF | | 0 V |
| | | | | Blower fan switch ON | | | 0 V |
| 29 (W) | Ground | Hazard switch | Input | Hazard switch | OFF | Battery voltage | |
| | | | | ON | | 0 V | |
| 30 (G) | Ground | Back door opener switch | Input | Back door opener switch | Not pressed | Battery voltage | |
| | | | | Pressed | | 0 V | |
| 32 (BR) | Ground | Combination switch OUTPUT 5 | Output | Combination switch | All switch OFF (Wiper intermittent dial 4) |  <p style="text-align: center;">7.2 V</p> | |
| | | | | | Front fog lamp switch ON (Wiper intermittent dial 4) |  <p style="text-align: center;">1.0 V</p> | |
| | | | | | Rear wiper switch ON (Wiper intermittent dial 4) | | |
| | | | | | Any of the condition below with all switch OFF | | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|---|--------|--------------------------------|------------------|-----------------------|--|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 33 (GR) | Ground | Combination switch OUTPUT 4 | Output | Combination switch | All switch OFF (Wiper intermittent dial 4) |  <p style="text-align: center;">7.2 V</p> |
| | | | | | Lighting switch 1ST (Wiper intermittent dial 4) |  <p style="text-align: center;">1.2 V</p> |
| | | | | | Lighting switch AUTO (Wiper intermittent dial 4) | |
| | | | | | Rear wiper switch INT (Wiper intermittent dial 4) | |
| Any of the condition below with all switch OFF | | | | | | |
| <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 5 • Wiper intermittent dial 6 | | | | | | |
| 34 (L) | Ground | Combination switch OUTPUT 3 | Output | Combination switch | All switch OFF (Wiper intermittent dial 4) |  <p style="text-align: center;">7.2 V</p> |
| | | | | | Lighting switch 2ND (Wiper intermittent dial 4) |  <p style="text-align: center;">1.2 V</p> |
| | | | | | Lighting switch HI (Wiper intermittent dial 4) | |
| | | | | | Rear washer switch ON (Wiper intermittent dial 4) | |
| Any of the condition below with all switch OFF | | | | | | |
| <ul style="list-style-type: none"> • Wiper intermittent dial 1 • Wiper intermittent dial 2 • Wiper intermittent dial 3 | | | | | | |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC





BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--------------------------------|------------------|---|--|--|
| + | - | Signal name | Input/ Output | | | |
| 35 (B) | Ground | Combination switch OUTPUT 2 | Output | Combination switch (Wiper intermit- tent dial 4) | All switch OFF | <p style="text-align: center;">7.2 V</p> |
| | | | | | Lighting switch 2ND | <p style="text-align: center;">1.2 V</p> |
| | | | | | Lighting switch PASS | |
| | | | | | Front wiper switch INT | |
| Front wiper switch HI | | | | | | |
| 36 (V) | Ground | Combination switch OUTPUT 1 | Output | Combination switch (Wiper intermit- tent dial 4) | All switch OFF | <p style="text-align: center;">7.2 V</p> |
| | | | | | Turn signal switch RH | <p style="text-align: center;">1.2 V</p> |
| | | | | | Turn signal switch LH | |
| | | | | | Front wiper switch LO (Front wiper switch MIST) | |
| Front washer switch ON | | | | | | |
| 37 (LG) | Ground | Key switch | Input | Insert mechanical key into ignition key cylinder | Battery voltage | |
| | | | | Remove mechanical key from ignition key cylinder | 0 V | |
| 38 (G) | Ground | Ignition switch ON | Input | Ignition switch OFF or ACC | 0 V | |
| | | | | Ignition switch ON or START | Battery voltage | |
| 39 (L) | Ground | CAN-H | Input/ Output | — | — | |
| 40 (P) | Ground | CAN-L | Input/ Output | — | — | |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|---|------------------|-----------------------------|--|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 43 (V) | Ground | Back door switch | Input | Back door switch | OFF (When back door closed) |  <p style="text-align: right; font-size: small;">JPMIA0593GB</p> <p style="text-align: center;">9.5 - 10.0 V</p> |
| | | | | | ON (When back door opened) | 0 V |
| 44 (B) | Ground | Rear wiper auto stop position | Input | Ignition switch ON | Rear wiper stop position | 0 V |
| | | | | | Any position other than rear wiper stop position | Battery voltage |
| 45 (P) | Ground | Door lock and unlock switch LOCK signal | Input | Door lock and unlock switch | NEUTRAL position |  <p style="text-align: right; font-size: small;">JPMIA0591GB</p> <p style="text-align: center;">1.6 V</p> |
| | | | | | LOCK position | 0 V |
| 46 (BR) | Ground | Door lock and unlock switch UNLOCK signal | Input | Door lock and unlock switch | NEUTRAL position |  <p style="text-align: right; font-size: small;">JPMIA0591GB</p> <p style="text-align: center;">1.6 V</p> |
| | | | | | UNLOCK position | 0 V |
| 47 (W) | Ground | Driver door switch | Input | Driver door switch | OFF (When driver door closed) |  <p style="text-align: right; font-size: small;">JPMIA0587GB</p> <p style="text-align: center;">8.0 - 8.5 V</p> |
| | | | | | ON (When driver door opened) | 0 V |

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P




BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---------------------------------|------------------|---|--|--|
| + | - | Signal name | Input/ Output | | | |
| 48 (GR) | Ground | Rear door switch LH | Input | Rear door switch LH | OFF (When rear door LH closed) |  8.5 - 9.0 V |
| | | | | | ON (When rear door LH opened) | 0 V |
| 49 (L) | Ground | Luggage room lamp control | Output | Luggage room lamp switch DOOR position | Back door is closed (Luggage room lamp turns OFF) | Battery voltage |
| | | | | Back door is opened (Luggage room lamp turns ON) | 0 V | |
| 53 (V) | Ground | Back door open | Output | Back door opener switch | Not pressed (Back door actuator is activated) | 0 V |
| | | | | | Pressed (Back door actuator is activated) | Battery voltage |
| 55 (SB) | Ground | Rear wiper motor | Output | Ignition switch ON | Rear wiper switch OFF | 0 V |
| | | | | | Rear wiper switch ON | Battery voltage |
| 56 (Y) | Ground | Interior room lamp power supply | Output | After passing the interior room lamp battery saver operation time | Rear wiper switch OFF | 0 V |
| | | | | | Any other time after passing the interior room lamp battery saver operation time | Battery voltage |
| 57 (G) | Ground | Battery power supply | Input | Ignition switch OFF | Battery voltage | Battery voltage |
| 59 (L) | Ground | Driver door UN-LOCK | Output | Driver door | UNLOCK (Actuator is activated) | Battery voltage |
| | | | | | Other then UNLOCK (Actuator is not activated) | 0 V |
| 60 (BR) | Ground | Turn signal LH | Output | Ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | | Turn signal switch LH |  6.0 V |

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|--|------------------|--|--|
| + | - | Signal name | Input/ Output | | |
| 61 (GR) | Ground | Turn signal RH | Output | Ignition switch ON | Turn signal switch OFF 0 V |
| | | | | Turn signal switch RH |  6.0 V |
| 63 (R) | Ground | Interior room lamp timer control | Output | Interior room lamp | OFF Battery voltage |
| | | | | ON | 0 V |
| 65 (V) | Ground | All doors LOCK | Output | All doors | LOCK (Actuator is activat- ed) Battery voltage |
| | | | | Other then LOCK (Actua- tor is not activated) | 0 V |
| 66 (G) | Ground | Passenger door and rear door UNLOCK | Output | Passenger door and rear door | UNLOCK (Actuator is acti- vated) Battery voltage |
| | | | | Other then UNLOCK (Ac- tuator is not activated) | 0 V |
| 67 (B) | Ground | Ground | Output | Ignition switch ON | 0 V |
| 68 (L) | Ground | P/W power supply (RAP) | Output | Ignition switch ON | Battery voltage |
| 69 (P) | Ground | P/W power supply (BAT) | Output | Ignition switch OFF | Battery voltage |
| 70 (Y) | Ground | Battery power sup- ply | Input | Ignition switch OFF | Battery voltage |

*: Except for Mexico with Intelligent Key

PWC

L

M

N

O


P


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - BCM -

INFOID:000000007628028


For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

- ◊ AA : With auto A/C
- ◊ MA : With manual A/C
- ◊ IK : With Intelligent Key
- ◊ OI : Without Intelligent Key




A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

JRMWC3696GB


BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >



JRMWC3698GB

INFOID:000000007628029

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

Fail-safe

REAR WIPER MOTOR PROTECTION

BCM detects the rear wiper stopping position according to the rear wiper stop position signal. When the rear wiper stop position signal does not change more than 5 seconds while driving the rear wiper, BCM stops power supply to protect the rear wiper motor.

Condition of cancellation

BCM (BODY CONTROL MODULE)

< ECU DIAGNOSIS INFORMATION >

1. Pass more than 1 minute after the rear wiper stop.
2. Turn the rear wiper switch OFF.
3. Operate the rear wiper switch or rear washer switch.

DTC Inspection Priority Chart

INFOID:000000007628030

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | DTC |
|----------|---|
| 1 | U1000: CAN COMM CIRCUIT |
| 2 | C1735: IGN CIRCUIT OPEN |
| 3 | <ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1716: [PRESS DATA ERR] FL • C1717: [PRESS DATA ERR] FR • C1718: [PRESS DATA ERR] RR • C1719: [PRESS DATA ERR] RL • C1729: VHCL SPEED SIG ERR |

DTC Index

INFOID:000000007628031

NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

| CONSULT display | Tire pressure monitor warning lamp ON | Reference |
|----------------------------|---------------------------------------|------------------------|
| U1000: CAN COMM CIRCUIT | — | BCS-34 |
| C1704: LOW PRESSURE FL | × | WT-14 |
| C1705: LOW PRESSURE FR | × | |
| C1706: LOW PRESSURE RR | × | |
| C1707: LOW PRESSURE RL | × | |
| C1708: [NO DATA] FL | × | WT-16 |
| C1709: [NO DATA] FR | × | |
| C1710: [NO DATA] RR | × | |
| C1711: [NO DATA] RL | × | |
| C1716: [PRESS DATA ERR] FL | × | WT-19 |
| C1717: [PRESS DATA ERR] FR | × | |
| C1718: [PRESS DATA ERR] RR | × | |
| C1719: [PRESS DATA ERR] RL | × | |
| C1729: VHCL SPEED SIG ERR | × | WT-21 |
| C1735: IGN CIRCUIT OPEN | — | BCS-35 |

POWER WINDOW MAIN SWITCH


< ECU DIAGNOSIS INFORMATION >

POWER WINDOW MAIN SWITCH

Reference Value

INFOID:000000007350775

TERMINAL LAYOUT



A. D5

B. D6

PHYSICAL VALUES

POWER WINDOW MAIN SWITCH

| Terminal No. (Wire color) | | Description | | Condition | Voltage [V] (Approx.) |
|------------------------------|--------|---|------------------|---|--------------------------|
| + | - | Signal name | Input/ Output | | |
| 1 (R) | Ground | Rear power window motor LH UP signal | Output | When rear LH switch in power window main switch is UP at operated. | Battery voltage |
| 2 (Y) | Ground | Encoder ground | — | — | 0 |
| 3 (BG) | Ground | Rear power window motor LH DOWN signal | Output | When rear LH switch in power window main switch is DOWN at operated. | Battery voltage |
| 5 (Y) | Ground | Rear power window motor RH DOWN signal | Output | When rear RH switch in power window main switch is DOWN at operated. | Battery voltage |
| 7 (LG) | Ground | Rear power window motor RH UP signal | Output | When rear RH switch in power window main switch is UP at operated. | Battery voltage |
| 8 (BR) | 11 | Front power window motor (driver side) UP signal | Output | When front LH switch in power window main switch is UP at operated. | Battery voltage |
| 9 (V) | 2 | Encoder pulse signal 2 | Input | When front power window motor (driver side) operates. | |
| 10 (L) | Ground | Ignition switch power supply | Input | Ignition switch ON | Battery voltage |
| | | | | Other than above | 0 |
| 11 (GR) | 8 | Front power window motor (driver side) DOWN signal | Output | When front LH switch in power window main switch is DOWN at operated. | Battery voltage |


JMKIA0070GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >


| Terminal No. (Wire color) | | Description | | Condition | Voltage [V] (Approx.) |
|------------------------------|--------|---|------------------|---|---|
| + | - | Signal name | Input/ Output | | |
| 12 (SB) | Ground | Front power window motor (passenger side) DOWN signal | Output | When front RH switch in power window main switch is DOWN at operated. | Battery voltage |
| 13 (R) | 2 | Encoder pulse signal 1 | Input | When front power window motor (driver side) operates. |  <p style="text-align: right; font-size: small;">JMKIA0070GB</p> |
| 15 (G) | Ground | Encoder power supply | Output | Ignition switch ON. | Battery voltage |
| 16 (W) | Ground | Front power window motor (passenger side) UP signal | Output | When front RH switch in power window main switch is UP at operated. | Battery voltage |
| 17 (B) | Ground | Ground | — | — | 0 |
| 19 (R) | Ground | Battery power supply | Input | Ignition switch OFF | Battery voltage |


POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >

Wiring Diagram - POWER WINDOW CONTROL SYSTEM -

INFOID:000000007350776

For connector terminal arrangements, harness layouts, and alphabets in a  (option abbreviation; if not described in wiring diagram), refer to [GI-12, "Connector Information"](#).



2011/06/14

JRKWC0741GB

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

Fail Safe

FAIL-SAFE CONTROL

Revision: 2013 February

PWC-49

INFOID:000000007350778

2012 ROGUE

POWER WINDOW MAIN SWITCH

< ECU DIAGNOSIS INFORMATION >

Switches to fail-safe control when malfunction is detected in encoder signal that detects up/down speed and direction of door glass. Switches to fail-safe control when error beyond regulation value is detected between the fully closed position and the actual position of the glass.

| Error | Error condition |
|---|--|
| Pulse sensor malfunction | When only one side of pulse signal is being detected for more than the specified value. |
| Both pulse sensors malfunction | When both pulse signals have not been detected for more than the specified value during glass open/close operation. |
| Pulse direction malfunction | When the pulse signal that is detected during glass open/close operation detects the opposite condition of power window motor operating direction. |
| Glass recognition position malfunction 1 | When it detects the error between glass fully closed position in power window switch memory and actual fully closed position during glass open/close operation is more than the specified value. |
| Glass recognition position malfunction 2 | When it detects pulse count more than the value of glass full stroke during glass open/close operation. |
| Malfunction of not yet updated closed position of glass | When glass open/close operation is continuously performed without fully closing more than the specified value (approximately 10 strokes). |

It changes to condition before initialization and the following functions do not operate when switched to fail-safe control.

- Auto-up operation
- Anti-pinch function

Perform initial operation to recover when switched to fail-safe mode. However, it switches back to fail-safe control when malfunction is found in power window main switch or front power window motor (driver side).

NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

< SYMPTOM DIAGNOSIS >

SYMPTOM DIAGNOSIS

NONE OF THE POWER WINDOWS CAN BE OPERATED USING ANY SWITCH

Diagnosis Procedure

INFOID:000000007350779

1. CHECK BCM POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit.

Refer to [BCS-36, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK POWER WINDOW MAIN SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check power window main switch power supply and ground circuit.

Refer to [PWC-10, "POWER WINDOW MAIN SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

DRIVER SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

DRIVER SIDE POWER WINDOW DOES NOT OPERATE

Diagnosis Procedure

INFOID:000000007350780

1. CHECK FRONT POWER WINDOW MOTOR (DRIVER SIDE)

Check power window motor.

Refer to [PWC-17, "DRIVER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

FRONT PASSENGER SIDE POWER WINDOW DOES NOT OPERATE WITH BOTH POWER WINDOW MAIN SWITCH AND FRONT PASSENGER SIDE POWER WINDOW SWITCH

WITH BOTH POWER WINDOW MAIN SWITCH AND FRONT PASSENGER SIDE
POWER WINDOW SWITCH : Diagnosis Procedure

INFOID:000000007350781

1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Check front power window switch (passenger side).
Refer to [PWC-13, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts

2. CHECK FRONT POWER WINDOW MOTOR (PASSENGER SIDE)

Check front power window motor (passenger side).
Refer to [PWC-18, "PASSENGER SIDE : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

WITH FRONT POWER WINDOW SWITCH ONLY

WITH FRONT POWER WINDOW SWITCH ONLY : Diagnosis Procedure

INFOID:000000007350782

1. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE) POWER SUPPLY AND GROUND CIRCUIT

Check front power window switch (passenger side) power supply and ground circuit.
Refer to [PWC-11, "FRONT POWER WINDOW SWITCH \(PASSENGER SIDE\) : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK FRONT POWER WINDOW SWITCH (PASSENGER SIDE)

Check front power window switch (passenger side).
Refer to [PWC-13, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

REAR LH SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR LH SIDE POWER WINDOW DOES NOT OPERATE WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH LH

WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW
SWITCH LH : Diagnosis Procedure

INFOID:000000007350783

1. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-15, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW MOTOR LH

Check rear power window motor LH.

Refer to [PWC-20, "REAR LH : Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

WITH REAR POWER WINDOW SWITCH LH ONLY

WITH REAR POWER WINDOW SWITCH LH ONLY : Diagnosis Procedure

INFOID:000000007350784

1. CHECK REAR POWER WINDOW SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check rear power window switch power supply and ground circuit.

Refer to [PWC-11, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.

Refer to [PWC-15, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

REAR RH SIDE POWER WINDOW DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

REAR RH SIDE POWER WINDOW DOES NOT OPERATE
WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH

WITH BOTH POWER WINDOW MAIN SWITCH AND REAR POWER WINDOW SWITCH RH : Diagnosis Procedure

INFOID:000000007350785

1.CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.
Refer to [PWC-15, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning parts.

2.CHECK REAR POWER WINDOW MOTOR RH

Check rear power window motor RH.
Refer to [PWC-21, "REAR RH : Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).
- NO >> GO TO 1.

WITH REAR POWER WINDOW SWITCH RH ONLY

WITH REAR POWER WINDOW SWITCH RH ONLY : Diagnosis Procedure

INFOID:000000007350786

1.CHECK REAR POWER WINDOW SWITCH POWER SUPPLY AND GROUND CIRCUIT

Check rear power window switch power supply and ground circuit.
Refer to [PWC-11, "REAR POWER WINDOW SWITCH : Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning parts.

2.CHECK REAR POWER WINDOW SWITCH

Check rear power window switch.
Refer to [PWC-15, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

- YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).
- NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

ANTI-PINCH SYSTEM DOES NOT OPERATE NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000007350787

1.PERFORM INITIALIZATION PROCEDURE

Initialization procedure is executed and operation is confirmed.

Refer to [PWC-4, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> INSPECTION END

NO >> GO TO 2.

2.CHECK ENCODER CIRCUIT

Check encoder circuit.

Refer to [PWC-24, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

< SYMPTOM DIAGNOSIS >

POWER WINDOW RETAINED POWER OPERATION DOES NOT OPERATE PROPERLY

Diagnosis Procedure

INFOID:000000007350788

1. CHECK DOOR SWITCH

Check door switch.

Refer to [DLK-57, "Component Function Check"](#) (With intelligent Key system), [DLK-277, "Component Function Check"](#) (Without Intelligent Key system).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE)

< SYMPTOM DIAGNOSIS >

AUTO OPERATION DOES NOT OPERATE BUT MANUAL OPERATE NORMALLY (DRIVER SIDE)

Diagnosis Procedure

INFOID:000000007350789

1.PERFORM INITIALIZATION PROCEDURE

Initialization procedure is executed and operation is confirmed.

Refer to [PWC-4, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).

Is the inspection result normal?

YES >> INSPECTION END
NO >> GO TO 2.

2.CHECK ENCODER

Check encoder.

Refer to [PWC-24, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.
NO >> Repair or replace the malfunctioning parts.

3.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).
NO >> GO TO 1.

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

< SYMPTOM DIAGNOSIS >

POWER WINDOW LOCK SWITCH DOES NOT FUNCTION

Diagnosis Procedure

INFOID:000000007350790

1. REPLACE POWER WINDOW MAIN SWITCH

Replace power window main switch.

>> Refer to [PWC-63. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
L
M
N
O
P

PWC

PRECAUTIONS

< PRECAUTION >

PRECAUTION

PRECAUTIONS FOR MEXICO

FOR MEXICO : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007350791

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

FOR USA AND CANADA

FOR USA AND CANADA : Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000007350792

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. This system includes seat belt switch inputs and dual stage front air bag modules. The SRS system uses the seat belt switches to determine the front air bag deployment, and may only deploy one front air bag, depending on the severity of a collision and whether the front occupants are belted or unbelted. Information necessary to service the system safely is included in the "SRS AIR BAG" and "SEAT BELT" of this Service Manual.

WARNING:

Always observe the following items for preventing accidental activation.

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision that would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see "SRS AIR BAG".
- Never use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

PRECAUTIONS

< PRECAUTION >

Always observe the following items for preventing accidental activation.

- When working near the Air Bag Diagnosis Sensor Unit or other Air Bag System sensors with the ignition ON or engine running, never use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the ignition OFF, disconnect the battery, and wait at least 3 minutes before performing any service.

A

B

C

D

E

F

G

H

I

J

PWC

L

M

N

O

P

PREPARATION


< PREPARATION >

PREPARATION

PREPARATION

Commercial Service Tools

INFOID:000000007657429

| Tool name | Description |
|--|--------------------------------------|
| Remover tool  JMKIA3050ZZ | Removes clips, pawls and metal clips |

POWER WINDOW MAIN SWITCH


< REMOVAL AND INSTALLATION >

REMOVAL AND INSTALLATION

POWER WINDOW MAIN SWITCH

Exploded View

INFOID:000000007350793



1. Power window main switch
2. Power window main switch finisher

NOTE:

The same procedure is also performed for front power window switch (passenger side) and rear power switch (LH & RH).


Refer to removal and installation procedure. Refer to [PWC-63, "Removal and Installation"](#).

Removal and Installation

INFOID:000000007350794

REMOVAL

1. Remove the power window main switch finisher (2).
Refer to [INT-12, "FRONT DOOR FINISHER : Exploded View"](#) and [INT-12, "FRONT DOOR FINISHER : Removal and Installation"](#).
2. Power window main switch (1) is removed from power window main switch finisher (2) using remover tool (A).


 : Pawl

CAUTION:

Do not fold the pawl of power window main switch finisher.

NOTE:

The same procedure is also performed for front power window switch (passenger side) and rear power window switch (LH & RH).



INSTALLATION

Install in the reverse order of removal.

NOTE:

Power window main switch is exchanged or is detached it is necessary to do the initialization procedure. Refer to [PWC-4, "ADDITIONAL SERVICE WHEN REMOVING BATTERY NEGATIVE TERMINAL : Special Repair Requirement"](#).