

# SECTION **DAS**

## DRIVER ASSISTANCE SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

### CONTENTS

<b>DRIVER ASSISTANCE SYSTEM</b>	
<b>PRECAUTION</b> ..... 8	<b>MOD : System Description</b> .....26
<b>PRECAUTIONS</b> ..... 8	<b>FCW</b> ..... <b>28</b>
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....8	FCW : System Description .....29
Precaution for Work .....8	<b>OPERATION</b> ..... <b>31</b>
Precautions For Harness Repair .....8	<b>BSW</b> ..... <b>31</b>
Precautions for Driver Assistance Systems .....9	BSW : Switch Name and Function .....31
<b>PREPARATION</b> ..... <b>10</b>	BSW : System Display and Warning .....31
<b>PREPARATION</b> ..... <b>10</b>	<b>LDW</b> ..... <b>32</b>
Special Service Tool ..... 10	LDW : Switch Name and Function .....32
<b>SYSTEM DESCRIPTION</b> ..... <b>11</b>	LDW : Menu Displayed by Pressing Each Switch...33
<b>COMPONENT PARTS</b> ..... <b>11</b>	<b>MOD</b> ..... <b>33</b>
Component Parts Location ..... 11	MOD : System Display and Warning .....33
Distance Sensor ..... 12	<b>FCW</b> ..... <b>34</b>
Steering Switch ..... 13	FCW : Switch Name and Function .....34
Around View Monitor Control Unit ..... 13	FCW : Menu Displayed by Pressing Each Switch...35
Rear View Camera Air Pump Motor ..... 13	<b>HANDLING PRECAUTION</b> ..... <b>36</b>
Combination Meter ..... 13	Precautions for Forward Collision Warning .....36
Rear View Camera ..... 13	Precautions for Lane Departure Warning .....36
Front Camera ..... 14	Precautions for Blind Spot Warning .....37
Rear View Camera Washer Control Unit ..... 14	Precautions for Moving Objects Detection .....37
Warning System Buzzer ..... 14	<b>DIAGNOSIS SYSTEM (AROUND VIEW MONITOR CONTROL UNIT)</b> ..... <b>39</b>
Side Cameras ..... 14	CONSULT Function ..... 39
Blind Spot Warning Indicator LH/RH ..... 14	<b>DIAGNOSIS SYSTEM (DISTANCE SENSOR)</b> ... <b>42</b>
Warning System Switch ..... 15	CONSULT Function (LASER/RADAR) .....42
<b>SYSTEM</b> ..... <b>16</b>	<b>ECU DIAGNOSIS INFORMATION</b> ..... <b>44</b>
<b>LDW</b> ..... <b>16</b>	<b>AROUND VIEW MONITOR CONTROL UNIT</b> ... <b>44</b>
LDW : System Description ..... 16	Reference Value .....44
<b>BSW</b> ..... <b>19</b>	DTC Index .....47
BSW : System Description .....20	<b>DISTANCE SENSOR</b> ..... <b>48</b>
<b>MOD</b> ..... <b>25</b>	Reference Value .....48
	Fail-safe (Distance Sensor) .....49

DAS

DTC Inspection Priority Chart .....	49	<b>CONFIGURATION (AROUND VIEW MONITOR CONTROL UNIT) .....</b>	<b>86</b>
DTC Index .....	49	Description .....	86
<b>REAR VIEW CAMERA WASHER CONTROL UNIT .....</b>	<b>51</b>	Work Procedure .....	86
Reference Value .....	51	Configuration List .....	87
<b>WIRING DIAGRAM .....</b>	<b>53</b>	<b>PREDICTIVE COURSE LINE CENTER POSITION ADJUSTMENT .....</b>	<b>88</b>
<b>DRIVER ASSISTANCE SYSTEMS .....</b>	<b>53</b>	Description .....	88
Wiring Diagram .....	53	Work Procedure .....	88
<b>BASIC INSPECTION .....</b>	<b>64</b>	<b>REAR VIEW CAMERA CALIBRATION .....</b>	<b>89</b>
<b>DIAGNOSIS AND REPAIR WORK FLOW .....</b>	<b>64</b>	Description .....	89
Work Flow .....	64	Work Procedure (Preparation) .....	89
<b>PRE-INSPECTION FOR DIAGNOSIS .....</b>	<b>67</b>	Work Procedure (Target Setting) .....	90
Inspection Procedure .....	67	Work Procedure (Rear View Camera Calibration)...	91
<b>REAR VIEW CAMERA WASHER/AIR BLOWER FUNCTION INSPECTION .....</b>	<b>68</b>	<b>CALIBRATING CAMERA IMAGE (AROUND VIEW MONITOR) .....</b>	<b>93</b>
Inspection Procedure .....	68	Description .....	93
<b>ADDITIONAL SERVICE WHEN REPLACING DISTANCE SENSOR .....</b>	<b>69</b>	Work Procedure .....	93
Description .....	69	<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>99</b>
Work Procedure .....	69	<b>U0121 VDC CAN 2 .....</b>	<b>99</b>
<b>DISTANCE SENSOR INITIAL VERTICAL ALIGNMENT .....</b>	<b>70</b>	DTC Logic .....	99
Description .....	70	Diagnosis Procedure .....	99
Required Tools .....	70	<b>U0122 VDC P-RUN DIAG .....</b>	<b>100</b>
Preparation .....	70	DTC Logic .....	100
Distance Sensor Initial Vertical Alignment .....	71	Diagnosis Procedure .....	100
<b>DISTANCE SENSOR ALIGNMENT .....</b>	<b>72</b>	<b>U0126 STRG SEN CAN 1 .....</b>	<b>101</b>
Description .....	72	DTC Logic .....	101
Required Tools .....	72	Diagnosis Procedure .....	101
Preparation .....	74	<b>U0401 ECM CAN 1 .....</b>	<b>102</b>
Vehicle Set Up .....	74	DTC Logic .....	102
Setting The Distance Sensor Target Board .....	76	Diagnosis Procedure .....	102
Distance Sensor Adjustment .....	77	<b>U0415 VDC CAN 1 .....</b>	<b>103</b>
<b>ACTION TEST .....</b>	<b>80</b>	DTC Logic .....	103
<b>LDW .....</b>	<b>80</b>	Diagnosis Procedure .....	103
LDW : Description .....	80	<b>U0416 VDC CHECKSUM DIAG .....</b>	<b>104</b>
LDW : Inspection Procedure .....	80	DTC Logic .....	104
<b>BSW .....</b>	<b>81</b>	Diagnosis Procedure .....	104
BSW : Description .....	81	<b>U0428 STEERING ANGLE SENSOR .....</b>	<b>105</b>
BSW : Inspection Procedure .....	81	<b>AROUND VIEW MONITOR CONTROL UNIT .....</b>	<b>105</b>
<b>MOD .....</b>	<b>82</b>	AROUND VIEW MONITOR CONTROL UNIT :	
MOD : Description .....	82	DTC Logic .....	105
MOD : Inspection Procedure .....	83	AROUND VIEW MONITOR CONTROL UNIT : Di-	
<b>ADDITIONAL SERVICE WHEN REPLACING AROUND VIEW MONITOR CONTROL UNIT ...</b>	<b>84</b>	agnosis Procedure .....	105
Description .....	84	<b>DISTANCE SENSOR .....</b>	<b>105</b>
Work Procedure .....	84	DISTANCE SENSOR : DTC Logic .....	105
		DISTANCE SENSOR : Diagnosis Procedure .....	105
		<b>U1000 CAN COMM CIRCUIT .....</b>	<b>106</b>

<b>AROUND VIEW MONITOR CONTROL UNIT</b> .....	<b>106</b>	<b>U1309 PUMP UNIT CURRENT</b> .....	<b>125</b>	
AROUND VIEW MONITOR CONTROL UNIT :		DTC Logic .....	125	A
DTC Logic .....	106	Diagnosis Procedure .....	125	
AROUND VIEW MONITOR CONTROL UNIT : Di-		<b>U130A PUMP CONTROL UNIT</b> .....	<b>127</b>	B
agnosis Procedure .....	106	DTC Logic .....	127	
<b>DISTANCE SENSOR</b> .....	<b>106</b>	Diagnosis Procedure .....	127	
DISTANCE SENSOR : DTC Logic .....	106	<b>U130B REAR CAMERA COMM ERROR</b> .....	<b>128</b>	C
DISTANCE SENSOR : Diagnosis Procedure .....	106	DTC Logic .....	128	
<b>U1010 CONTROL UNIT (CAN)</b> .....	<b>107</b>	Diagnosis Procedure .....	128	
<b>AROUND VIEW MONITOR CONTROL UNIT</b> .....	<b>107</b>	<b>C10B7 YAW RATE SENSOR</b> .....	<b>129</b>	D
AROUND VIEW MONITOR CONTROL UNIT :		DTC Logic .....	129	
DTC Logic .....	107	Diagnosis Procedure .....	129	
<b>DISTANCE SENSOR</b> .....	<b>107</b>	<b>C1A01 POWER SUPPLY CIRCUIT 1, C1A02</b>		E
DISTANCE SENSOR : DTC Logic .....	107	<b>POWER SUPPLY CIRCUIT 2</b> .....	<b>130</b>	
<b>U111A REAR CAMERA IMAGE SIGNAL CIR-</b>		DTC Logic .....	130	F
<b>CUIT</b> .....	<b>108</b>	Diagnosis Procedure .....	130	
DTC Logic .....	108	<b>C1A03 VEHICLE SPEED SENSOR</b> .....	<b>131</b>	G
Diagnosis Procedure .....	108	<b>AROUND VIEW MONITOR CONTROL UNIT</b> .....	<b>131</b>	
<b>U111B SIDE CAMERA RH IMAGE SIGNAL</b>		AROUND VIEW MONITOR CONTROL UNIT :		H
<b>CIRCUIT</b> .....	<b>110</b>	DTC Logic .....	131	
DTC Logic .....	110	AROUND VIEW MONITOR CONTROL UNIT : Di-		
Diagnosis Procedure .....	110	agnosis Procedure .....	131	
<b>U111C FRONT CAMERA IMAGE SIGNAL</b>		<b>DISTANCE SENSOR</b> .....	<b>131</b>	I
<b>CIRCUIT</b> .....	<b>112</b>	DISTANCE SENSOR : DTC Logic .....	131	
DTC Logic .....	112	DISTANCE SENSOR : Diagnosis Procedure .....	131	
Diagnosis Procedure .....	112	<b>C1A04 ABS/TCS/VDC SYSTEM</b> .....	<b>132</b>	J
<b>U111D SIDE CAMERA LH IMAGE SIGNAL</b>		<b>AROUND VIEW MONITOR CONTROL UNIT</b> .....	<b>132</b>	
<b>CIRCUIT</b> .....	<b>114</b>	AROUND VIEW MONITOR CONTROL UNIT :		K
DTC Logic .....	114	DTC Logic .....	132	
Diagnosis Procedure .....	114	AROUND VIEW MONITOR CONTROL UNIT : Di-		
<b>U1232 STEERING ANGLE SENSOR</b> .....	<b>116</b>	agnosis Procedure .....	132	L
DTC Logic .....	116	<b>DISTANCE SENSOR</b> .....	<b>132</b>	
Diagnosis Procedure .....	116	DISTANCE SENSOR : DTC Logic .....	132	
<b>U1302 CAMERA POWER VOLT</b> .....	<b>117</b>	DISTANCE SENSOR : Diagnosis Procedure .....	132	M
DTC Logic .....	117	<b>C1A05 BRAKE SW/STOP LAMP SW</b> .....	<b>133</b>	
Diagnosis Procedure .....	117	DTC Logic .....	133	N
<b>U1303 LED POWER SUPPLY VOLT</b> .....	<b>121</b>	Diagnosis Procedure .....	133	
DTC Logic .....	121	<b>C1A12 LASER BEAM OFF CENTER</b> .....	<b>134</b>	
Diagnosis Procedure .....	121	DTC Logic .....	134	
<b>U1304 CAMERA IMAGE CALIBRATION</b> .....	<b>122</b>	Diagnosis Procedure .....	134	DAS
DTC Logic .....	122	<b>C1A14 ECM</b> .....	<b>135</b>	
Diagnosis Procedure .....	122	DTC Logic .....	135	P
<b>U1305 CONFIG UNFINISH</b> .....	<b>123</b>	Diagnosis Procedure .....	135	
DTC Logic .....	123	<b>C1A15 GEAR POSITION</b> .....	<b>136</b>	
Diagnosis Procedure .....	123	DTC Logic .....	136	
<b>U1308 CAMERA CONFIG</b> .....	<b>124</b>	Diagnosis Procedure .....	136	
DTC Logic .....	124	<b>C1A16 RADAR BLOCKED</b> .....	<b>137</b>	
Diagnosis Procedure .....	124	DTC Logic .....	137	

Diagnosis Procedure .....	137	<b>SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY</b> .....	155
<b>C1A17 DISTANCE SENSOR</b> .....	138	Description .....	155
DTC Logic .....	138	Diagnosis Procedure .....	155
Diagnosis Procedure .....	138	<b>SWITCH DOES NOT TURN ON / SWITCH DOES NOT TURN OFF</b> .....	156
<b>C1A18 RADAR AIMING INCMP</b> .....	139	Description .....	156
DTC Logic .....	139	Diagnosis Procedure .....	156
Diagnosis Procedure .....	139	<b>NORMAL OPERATING CONDITION</b> .....	157
<b>C1A21 UNIT HIGH TEMP</b> .....	140	Description .....	157
DTC Logic .....	140	<b>REMOVAL AND INSTALLATION</b> .....	159
<b>C1A24 NP RANGE</b> .....	141	<b>FRONT CAMERA</b> .....	159
DTC Logic .....	141	Exploded View .....	159
Diagnosis Procedure .....	141	Removal and Installation .....	159
<b>C1A39 STEERING ANGLE SENSOR</b> .....	142	<b>DISTANCE SENSOR</b> .....	160
<b>AROUND VIEW MONITOR CONTROL UNIT</b> .....	142	Exploded View .....	160
AROUND VIEW MONITOR CONTROL UNIT :		Removal and Installation .....	160
DTC Logic .....	142	<b>SIDE CAMERA</b> .....	161
AROUND VIEW MONITOR CONTROL UNIT : Di-		Removal and Installation .....	161
agnosis Procedure .....	142	<b>BSW INDICATOR</b> .....	162
<b>DISTANCE SENSOR</b> .....	142	Removal and Installation .....	162
DISTANCE SENSOR : DTC Logic .....	142	<b>AROUND VIEW MONITOR CONTROL UNIT</b> ..	163
DISTANCE SENSOR : Diagnosis Procedure .....	142	Exploded View .....	163
<b>POWER SUPPLY AND GROUND CIRCUIT</b> ..	143	Removal and Installation .....	163
<b>AROUND VIEW MONITOR CONTROL UNIT</b> .....	143	<b>WARNING SYSTEMS SWITCH</b> .....	164
AROUND VIEW MONITOR CONTROL UNIT : Di-		Removal and Installation .....	164
agnosis Procedure .....	143	<b>WARNING SYSTEMS BUZZER</b> .....	165
<b>DISTANCE SENSOR</b> .....	144	Exploded View .....	165
DISTANCE SENSOR : Diagnosis Procedure .....	144	Removal and Installation .....	165
<b>WARNING SYSTEMS SWITCH CIRCUIT</b> .....	146	<b>REAR VIEW CAMERA</b> .....	166
Diagnosis Procedure .....	146	Removal and Installation .....	166
Component Inspection .....	147	<b>REAR VIEW CAMERA WASHER MOTOR</b> .....	167
<b>WARNING SYSTEMS ON INDICATOR CIR-</b>		Exploded View .....	167
<b>CUIT</b> .....	148	Removal and Installation .....	167
Diagnosis Procedure .....	148	<b>REAR VIEW CAMERA AIR PUMP MOTOR</b> ...	168
Component Inspection .....	149	Exploded View .....	168
<b>WARNING BUZZER CIRCUIT</b> .....	150	Removal and Installation .....	168
Component Function Check .....	150	<b>REAR VIEW CAMERA WASHER CONTROL</b>	
Diagnosis Procedure .....	150	<b>UNIT</b> .....	169
<b>REAR VIEW CAMERA WASHER MOTOR</b>		Exploded View .....	169
<b>CIRCUIT</b> .....	151	Removal and Installation .....	169
Component Function Check .....	151	<b>CHASSIS CONTROL</b>	
Diagnosis Procedure .....	151	<b>PRECAUTION</b> .....	170
<b>SYMPTOM DIAGNOSIS</b> .....	152	<b>PRECAUTIONS</b> .....	170
<b>DRIVER ASSISTANCE SYSTEM SYMP-</b>			
<b>TOMS</b> .....	152		
Symptom Table .....	152		

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....	170	<b>CONFIGURATION (CHASSIS CONTROL MODULE) .....</b>	<b>205</b>	A
Precaution for Work .....	170	Work Procedure .....	205	
Precautions for Harness Repair .....	171	<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>207</b>	B
Precautions for Chassis control .....	171	<b>C1B92-00 BRAKE CONTROL SYSTEM .....</b>	<b>207</b>	
<b>PREPARATION .....</b>	<b>172</b>	DTC Description .....	207	C
<b>PREPARATION .....</b>	<b>172</b>	Diagnosis Procedure .....	207	
Special Service Tool .....	172	<b>C1B93-00 ENGINE/HEV SYSTEM .....</b>	<b>209</b>	D
<b>SYSTEM DESCRIPTION .....</b>	<b>173</b>	DTC Description .....	209	
<b>COMPONENT PARTS .....</b>	<b>173</b>	Diagnosis Procedure .....	209	
Component Parts Location .....	173	<b>C1B94-00 TRANSMISSION SYSTEM .....</b>	<b>211</b>	E
Chassis Control Module .....	174	DTC Description .....	211	
<b>SYSTEM .....</b>	<b>175</b>	Diagnosis Procedure .....	211	
System Description - Chassis Control .....	175	<b>C1B95-00 CONTROL MODULE .....</b>	<b>213</b>	F
System Description - Active Engine Brake .....	175	DTC Description .....	213	
System Description - Active Ride Control .....	176	Diagnosis Procedure .....	213	
System Description - Active Trace Control .....	176	<b>C1B99-00 CONTROL MODULE .....</b>	<b>214</b>	G
Fail-Safe (Chassis Control Module) .....	177	DTC Description .....	214	
<b>INFORMATION DISPLAY (COMBINATION METER) .....</b>	<b>179</b>	Diagnosis Procedure .....	214	
INFORMATION DISPLAY (COMBINATION METER) : Chassis Control Display .....	179	<b>C1BA0-00 ADAS/CHASSIS CONTROL BRAKE SYSTEM .....</b>	<b>215</b>	H
<b>HANDLING PRECAUTION .....</b>	<b>181</b>	DTC Description .....	215	
Precautions for Chassis Control (Engine Brake, Active Ride, and Active Trace) .....	181	Diagnosis Procedure .....	215	I
<b>DIAGNOSIS SYSTEM (CHASSIS CONTROL MODULE) .....</b>	<b>182</b>	<b>C1BA2-00 STEERING ANGLE SENSOR .....</b>	<b>217</b>	J
CONSULT Function .....	182	DTC Description .....	217	
<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>187</b>	Diagnosis Procedure .....	217	
<b>CHASSIS CONTROL MODULE .....</b>	<b>187</b>	<b>C1BA5-00 ADAS/CHASSIS CONTROL ENGINE SYSTEM .....</b>	<b>219</b>	K
Reference Value .....	187	DTC Description .....	219	
Fail-Safe (Chassis Control Module) .....	191	Diagnosis Procedure .....	219	
DTC Inspection Priority Chart .....	193	<b>C1BAB-00 STOP LAMP SWITCH .....</b>	<b>220</b>	L
DTC Index .....	194	DTC Description .....	220	
<b>WIRING DIAGRAM .....</b>	<b>195</b>	Diagnosis Procedure .....	220	M
<b>CHASSIS CONTROL .....</b>	<b>195</b>	<b>C1BB2-00 CONTROL MODULE .....</b>	<b>222</b>	
Wiring Diagram .....	195	DTC Description .....	222	N
<b>BASIC INSPECTION .....</b>	<b>201</b>	Diagnosis Procedure .....	222	
<b>DIAGNOSIS AND REPAIR WORK FLOW .....</b>	<b>201</b>	<b>C1BB3-00 CONTROL MODULE .....</b>	<b>223</b>	
Work Flow .....	201	DTC Description .....	223	
Diagnostic Work Sheet .....	202	Diagnosis Procedure .....	223	DAS
<b>ADDITIONAL SERVICE WHEN REPLACING CHASSIS CONTROL MODULE .....</b>	<b>204</b>	<b>C1BB4-00 CONTROL MODULE .....</b>	<b>224</b>	
Description .....	204	DTC Description .....	224	P
		Diagnosis Procedure .....	224	
		<b>C1BB5-00 IGNITION POWER SUPPLY .....</b>	<b>225</b>	
		DTC Description .....	225	
		Diagnosis Procedure .....	225	
		<b>C1BB6-00 IGNITION POWER SUPPLY .....</b>	<b>228</b>	
		DTC Description .....	228	

Diagnosis Procedure .....	228	<b>U1A34-00 BRAKE CONTROL COMMUNICA-</b>	<b>TION .....</b>	<b>252</b>
<b>C1BB7-00 CONTROL MODULE .....</b>	<b>230</b>	DTC Description .....	252	
DTC Description .....	230	Diagnosis Procedure .....	252	
Diagnosis Procedure .....	230	<b>U1A35-00 BRAKE CONTROL COMMUNICA-</b>	<b>TION .....</b>	<b>254</b>
<b>C1BB8-00 CONTROL MODULE .....</b>	<b>231</b>	DTC Description .....	254	
DTC Description .....	231	Diagnosis Procedure .....	254	
Diagnosis Procedure .....	231	<b>U1A36-00 BCM/IPDM COMMUNICATION .....</b>	<b>256</b>	
<b>C1BB9-00 CONTROL MODULE .....</b>	<b>232</b>	DTC Description .....	256	
DTC Description .....	232	Diagnosis Procedure .....	256	
Diagnosis Procedure .....	232	<b>U1A39-00 COMBINATION METER COMMU-</b>	<b>NICATION .....</b>	<b>258</b>
<b>C1BBA-00 CONTROL MODULE .....</b>	<b>233</b>	DTC Description .....	258	
DTC Description .....	233	Diagnosis Procedure .....	258	
Diagnosis Procedure .....	233	<b>U1A3B-00 TCM COMMUNICATION .....</b>	<b>260</b>	
<b>C1BBB-00 CONTROL MODULE .....</b>	<b>234</b>	DTC Description .....	260	
DTC Description .....	234	Diagnosis Procedure .....	260	
Diagnosis Procedure .....	234	<b>U1A42-00 STEERING ANGLE SENSOR</b>	<b>COMMUNICATION .....</b>	<b>262</b>
<b>C1BBC-00 CONTROL MODULE .....</b>	<b>235</b>	DTC Description .....	262	
DTC Description .....	235	Diagnosis Procedure .....	262	
Diagnosis Procedure .....	235	<b>U1A43-00 STEERING ANGLE SENSOR</b>	<b>COMMUNICATION .....</b>	<b>264</b>
<b>C1BBD-00 VARIANT CODING .....</b>	<b>236</b>	DTC Description .....	264	
DTC Description .....	236	Diagnosis Procedure .....	264	
Diagnosis Procedure .....	236	<b>U1A48-00 ECM/HPCM COMMUNICATION .....</b>	<b>266</b>	
<b>C1BC0-00 FRONT RIGHT WHEEL SENSOR .....</b>	<b>237</b>	DTC Description .....	266	
DTC Description .....	237	Diagnosis Procedure .....	266	
Diagnosis Procedure .....	237	<b>U1A4A-00 CONTROL MODULE (CAN) .....</b>	<b>268</b>	
<b>C1BC1-00 FRONT LEFT WHEEL SENSOR ..</b>	<b>239</b>	DTC Description .....	268	
DTC Description .....	239	Diagnosis Procedure .....	268	
Diagnosis Procedure .....	239	<b>U1A4B-00 CONTROL MODULE (CAN) .....</b>	<b>269</b>	
<b>C1BC2-00 REAR RIGHT WHEEL SENSOR ..</b>	<b>241</b>	DTC Description .....	269	
DTC Description .....	241	Diagnosis Procedure .....	269	
Diagnosis Procedure .....	241	<b>U1A4E-00 ECM/HPCM COMMUNICATION .....</b>	<b>270</b>	
<b>C1BC3-00 REAR LEFT WHEEL SENSOR ....</b>	<b>243</b>	DTC Description .....	270	
DTC Description .....	243	Diagnosis Procedure .....	270	
Diagnosis Procedure .....	243	<b>POWER SUPPLY AND GROUND CIRCUIT ...</b>	<b>272</b>	
<b>C1BC4-00 DECEL G SENSOR .....</b>	<b>245</b>	Diagnosis Procedure .....	272	
DTC Description .....	245	<b>SYMPTOM DIAGNOSIS .....</b>	<b>273</b>	
Diagnosis Procedure .....	245	<b>CHASSIS CONTROL .....</b>	<b>273</b>	
<b>C1BC5-00 SIDE G SENSOR .....</b>	<b>247</b>	Active Engine Brake .....	273	
DTC Description .....	247	Active Ride Control .....	273	
Diagnosis Procedure .....	247	Active Trace Control .....	274	
<b>C1BC6-00 PRESSURE SENSOR .....</b>	<b>249</b>	<b>NORMAL OPERATING CONDITION .....</b>	<b>276</b>	
DTC Description .....	249	Description .....	276	
Diagnosis Procedure .....	249			
<b>U1000-00 CAN COMM CIRCUIT .....</b>	<b>251</b>			
DTC Logic .....	251			
Diagnosis Procedure .....	251			

---

<b>REMOVAL AND INSTALLATION</b> .....	277	Exploded View .....	277
<b>CHASSIS CONTROL MODULE</b> .....	277	Removal and Installation .....	277

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

**DAS**

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010284553

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

#### Precaution for Work

INFOID:000000010287283

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

#### Precautions For Harness Repair

INFOID:000000010227164

ITS communication uses a twisted pair line. Be careful when repairing it.



# PRECAUTIONS


## [DRIVER ASSISTANCE SYSTEM]

### < PRECAUTION >

- Solder the repaired area and wrap tape around the soldered area.

**NOTE:**


A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.

**NOTE:**

Bypass connection may cause ITS communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



## Precautions for Driver Assistance Systems

INFOID:000000010227165

**CAUTION:**

- Do not use or disassemble the distance sensor removed from the vehicle.
- Erase DTC when replacing parts of FCW system, then check the operation of FCW system after alignment, if necessary.

**WARNING:**

Be cautious of traffic conditions and other vehicles when performing a road test.

**CAUTION:**

- Do not use the DAS system when driving with free rollers or on a chassis dynamometer.
- Do not disassemble or alter the rear view camera.
- Do not disable the DAS system without the consent of the customer.

OBSERVE THE FOLLOWING ITEMS IN ORDER TO KEEP THE DAS SYSTEM OPERATING PROPERLY:

### Rear view Camera Maintenance

The rear view camera for the DAS system is located in the back door. To keep the DAS system operating properly and prevent a malfunction, be sure to observe the following:

- Always keep the camera lens area clean.
- Do not attach bumper stickers (including transparent materials) or install an accessory near the rear view-camera.
- Do not strike or damage the areas around the rear view camera.
- Do not touch the camera lens (except for cleaning) or remove the rear view camera.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# PREPARATION

[DRIVER ASSISTANCE SYSTEM]

< PREPARATION >





## PREPARATION

### PREPARATION

#### Special Service Tool

INFOID:0000000010246047

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
<p>— (J-46534) Trim Tool Set</p>  <p style="text-align: center;">AWJIA0483ZZ</p>	<p>Removing trim components</p>
<p>— (1-20-2721-1-IF) Distance Sensor Alignment Kit</p>  <p style="text-align: center;">AWOIA0016ZZ</p>	<p>Adjusting distance sensor</p>
<p>— (1-20-2722-1-IF) Wheel Adapter</p>  <p style="text-align: center;">AWOIA0017ZZ</p>	<p>Adjusting distance sensor</p>
<p>— (J-50808) Distance Sensor Alignment Attachment Board</p>  <p style="text-align: center;">ALOIA0218ZZ</p>	<p>Adjusting distance sensor</p>

# COMPONENT PARTS

< SYSTEM DESCRIPTION >



[DRIVER ASSISTANCE SYSTEM]

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000010227170



- A. View with back door finisher removed
- B. View with glove box assembly removed
- C. View with front bumper removed
- D. View with front bumper removed
- E. Rear under body LH
- F. View with luggage rear plate removed

No.	Component	Function
1.	Rear view camera	Refer to <a href="#">DAS-13. "Rear View Camera"</a> .
2.	Side camera RH	Refer to <a href="#">DAS-14. "Side Cameras"</a> .
3.	Blind spot warning indicator RH	Refer to <a href="#">DAS-14. "Blind Spot Warning Indicator LH/RH"</a> .
4.	Around View® Monitor control unit	Refer to <a href="#">DAS-13. "Around View Monitor Control Unit"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[DRIVER ASSISTANCE SYSTEM]

No.	Component	Function
5.	ABS actuator and electric unit (control unit)	Transmits the vehicle speed signal (wheel speed) to around view monitor via CAN communication Refer to <a href="#">BRC-8, "Component Parts Location"</a> for detailed installation location.
6.	Rear washer motor	Pumps washer fluid to the rear view camera.
7.	Distance sensor	Refer to <a href="#">DAS-12, "Distance Sensor"</a> .
8.	Front camera	Refer to <a href="#">DAS-14, "Front Camera"</a> .
9.	ECM	<ul style="list-style-type: none"> <li>Transmits engine speed signal to around view monitor control unit via CAN communication.</li> <li>Refer to <a href="#">EC-14, "Component Parts Location"</a> for detailed installation location.</li> </ul>
10.	TCM	Refer to <a href="#">TM-12, "CVT CONTROL SYSTEM : Component Parts Location"</a> for detailed installation location.
11.	BCM	Transmits the turn indicator signal, dimmer signal, and back door switch signal to around view monitor via CAN communication. Refer to the following for detailed installation location: <ul style="list-style-type: none"> <li>With Intelligent Key system: <a href="#">BCS-7, "BODY CONTROL SYSTEM : Component Parts Location"</a>.</li> <li>Without Intelligent Key system: <a href="#">BCS-79, "BODY CONTROL SYSTEM : Component Parts Location"</a>.</li> </ul>
12.	Blind spot warning indicator LH	Refer to <a href="#">DAS-14, "Blind Spot Warning Indicator LH/RH"</a> .
13.	Side camera LH	Refer to <a href="#">DAS-14, "Side Cameras"</a> .
14.	Rear view camera air pump motor	Refer to <a href="#">DAS-13, "Rear View Camera Air Pump Motor"</a> .
15.	Rear view camera washer control unit	Refer to <a href="#">DAS-14, "Rear View Camera Washer Control Unit"</a> .
16.	AV control unit	Receives the various systems and camera signals via CAN communication and routes them to the AV control unit display. Refer to <a href="#">AV-77, "Component Parts Location"</a> for detailed installation location.
17.	Combination meter	<ul style="list-style-type: none"> <li>Description: <a href="#">DAS-13, "Combination Meter"</a>.</li> <li>Refer to <a href="#">MWI-6, "METER SYSTEM : Component Parts Location"</a> for detailed installation location.</li> </ul>
18.	Steering switch	Refer to <a href="#">DAS-13, "Steering Switch"</a> .
19.	Warning system switch	Refer to <a href="#">DAS-15, "Warning System Switch"</a> .
20.	Warning system buzzer	Refer to <a href="#">DAS-14, "Warning System Buzzer"</a> .
21.	Steering angle sensor	Transmits the steering angle sensor signal to around view monitor via CAN communication. Refer to <a href="#">BRC-8, "Component Parts Location"</a> for detailed installation location.

## Distance Sensor

INFOID:000000010227171

- Distance sensor is installed to the back of the front bumper and detects a vehicle ahead by using millimeter waves.
- Distance sensor detects radar reflected from a vehicle ahead by irradiating radar forward and calculates a distance from the vehicle ahead and relative speed, based on the detected signal.
- Distance sensor transmits the presence/absence of vehicle ahead and the distance from the vehicle to around view monitor control unit via CAN communication.



# COMPONENT PARTS


< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

## Steering Switch

INFOID:000000010227172


- Steering switches are installed in the steering wheel.
- Settings for driver assistance systems are possible.
- Switch is connected to the combination meter and signals are transmitted to the around view monitor via CAN communication.



## Around View Monitor Control Unit

INFOID:000000010227173


- The around view monitor control unit is installed behind the glove box.
- Vehicle width guide lines, predicted course line, vehicle front guiding line and vehicle side line, and vehicle icon are displayed and combined with camera images.



## Rear View Camera Air Pump Motor

INFOID:000000010227174

- Rear view camera air pump motor is installed to the rear left underbody.
- Air pump is activated and generates compressed air when power is supplied from the rear view camera washer control unit.
- Compressed air jets out from the air nozzle of rear view camera via air tube.



## Combination Meter


INFOID:000000010227175

- Displays the system status according to a signal received.
- Operates the buzzer according to the signal from the distance sensor.

## Rear View Camera

INFOID:000000010227176

- The rear view camera is installed in the back door finisher.
- With the mirror processing function, a mirror image is sent as if it is viewed by a rear view mirror.
- Power for the camera is supplied from the around view monitor control unit, and the image at the rear of the vehicle is sent to the around view monitor control unit.
- The rear view camera is equipped with a washer nozzle and air nozzle for cleaning camera. A check valve is installed to the tube connected to the washer nozzle.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N

DAS


P

### < SYSTEM DESCRIPTION >

#### Front Camera

INFOID:000000010227177


- The front camera is installed in the front grille.
- Power is supplied from the around view monitor control unit.



#### Rear View Camera Washer Control Unit

INFOID:000000010227178


- Rear view camera washer control unit is installed under the luggage rear plate.
- Communicates with around view monitor control unit via serial communication line.
- Activates air pump and washer pump according to the signal from around view monitor control unit.



#### Warning System Buzzer

INFOID:000000010227179


- Warning system buzzer is installed to the back of the instrument lower panel LH.
- When a warning buzzer signal is received from the around view monitor, the buzzer sounds.



#### Side Cameras

INFOID:000000010227180

- The side cameras are installed in the door mirrors.
- Power is supplied from the around view monitor control unit.



#### Blind Spot Warning Indicator LH/RH

INFOID:000000010227181

- Installed on the front door corner finisher, the blind spot warning indicator warns the driver by lighting/blinking.
- Receives a blind spot warning indicator operation signal from the around view monitor control unit.

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

## Warning System Switch

INFOID:000000010227182

- Installed to the back of the instrument lower panel LH, the warning system switch is used to activate/deactivate the driver assistance system.
- Transmits a warning system switch signal to the around view monitor control unit.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# SYSTEM

[DRIVER ASSISTANCE SYSTEM]

< SYSTEM DESCRIPTION >


## SYSTEM

LDW

LDW : System Description

INFOID:000000010227185

## SYSTEM DIAGRAM



AWOIA0066GB

## AROUND VIEW MONITOR CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM



# SYSTEM

< SYSTEM DESCRIPTION >

**[DRIVER ASSISTANCE SYSTEM]**

**Input Signal Item**

Transmit unit	Signal name		Description
BCM	CAN communication	Turn indicator signal	Receives an operational state of the turn signal lamp and the hazard lamp
Combination meter	CAN communication	System selection signal	Receives a selection state of each item in "Driver assistance" selected with the information display
Steering angle sensor	CAN communication	Steering angle sensor signal	Receives the number of revolutions, turning direction of the steering wheel
ECM	CAN communication	Engine status signal	Receives the engine status
Rear view camera	Communication line	Detected lane condition signal	Receives detection results of lane marker
Warning system switch	Warning system switch signal		Receives an ON/OFF state of the warning system switch


**Output Signal Item**

Reception unit	Signal name		Description	
Combination meter	CAN communication	Meter display signal	LDW warning signal	Transmits a meter display signal to turn ON the LDW warning
			LDW ON indicator signal	Transmits a meter display signal to turn ON the LDW ON indicator
		Buzzer output signal		Transmits a buzzer output signal to activate the warning buzzer
Rear view camera washer control unit	Communication line	Rear view camera washer signal		Transmits a rear view camera washer signal to activate the washer motor
		Rear view camera air blow signal		Transmits a rear view camera air blow signal to activate the air pump
Warning buzzer	Warning buzzer signal		Activates the warning buzzer	
Warning system ON indicator	Warning systems ON indicator signal		Turns ON the warning systems ON indicator	

**FUNCTION DESCRIPTION**

- Lane Departure Warning (LDW) system provides a lane departure warning function when the vehicle is driven at speeds of approximately 45 MPH (70 km/h) or more.
- When the vehicle approaches either the left or the right side of the traveling lane, a warning will sound and the lane departure warning lamp (orange) on the combination meter will blink to alert the driver.
- The warning does not occur during turn signal operation (Lane change side).
- The warning function will stop when the vehicle returns inside of the lane markers.

**EXAMPLE**



When the vehicle approaches the right lane marker, the driver is alerted by the buzzer and the blinking of lane departure warning lamp (orange).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# SYSTEM

## [DRIVER ASSISTANCE SYSTEM]

### < SYSTEM DESCRIPTION >

#### OPERATION DESCRIPTION

- When the system is turned ON by operating the warning systems switch, around view monitor control unit turns ON the LDW ON indicator and the warning systems ON indicator.
- Rear view camera monitors the traveling lane. It transmits the camera image signal to around view monitor control unit.
- When judging from a camera image signal that the vehicle is approaching the lane marker, the around view monitor control unit controls the following item to alert the driver.
  - Activates warning buzzer in the combination meter.
  - Around view monitor control unit transmits a meter display signal to combination meter via CAN communication and turns ON/OFF the LDW warning.



#### Operating Condition

- LDW ON indicator: ON
- Warning systems ON indicator: ON
- Vehicle speed: approximately 45 MPH (70 km/h) or more
- Turn indicator signal: After 2 seconds or more from turned OFF
- Back door: Close
- Low washer fluid warning: OFF

#### NOTE:

- When the LDW system setting on the combination meter is ON.
- After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 40 MPH (60 km/h)
- The LDW system may not function properly, depending on the situation. Refer to [DAS-36, "Precautions for Lane Departure Warning"](#).




#### Fail-safe Indication

Vehicle condition/ Driver's operation	Warning systems ON indicator	Indication on the combination meter
When DTC is detected (Except "U1308")	ON	 <small>JSOIA0736ZZ</small>
Camera calibration is not completed ("U1308" is detected) <b>NOTE:</b> This is detected while driving the vehicle and the indication remains ON until the ignition switch is turned OFF	ON	
When lane markers cannot be detected due to dirt on the camera.	ON	 <small>JSOIA0737ZZ</small>
		<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: 0 auto;">                         Unavailable: Clean Rear Camera                     </div> <small>JSOIA0738ZZ</small>

# SYSTEM

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

Vehicle condition/ Driver's operation	Warning systems ON indicator	Indication on the combination meter
When the washer fluid level is low (Low washer fluid warning ON)	ON	Blinks at intervals of two seconds.  <small>JSOIA0739ZZ</small>
When the back door is open (Back door open warning ON)	ON	Blinks at intervals of two seconds.  <small>JSOIA0739ZZ</small>
Blinks when the setting of LDW and BSW are "OFF" and the warning systems switch is pressed	OFF	 Unavailable: Select Driving Aids in Settings. <small>JSOIA0780ZZ</small>

## REAR VIEW CAMERA WASHER OPERATION

- When judging that the rear view camera has water droplets, the around view monitor control unit transmits a rear view camera washer activation signal or rear view camera air blow signal to the rear view camera washer control unit via serial communication.
- When receiving a rear view camera washer signal, the rear view camera washer control unit simultaneously activates the rear view camera washer motor to clean the rear view camera by spraying washer fluid from the nozzle installed to the rear view camera bracket.
- When receiving a rear view camera air blow signal, the rear view camera washer control unit activates the air pump to clean the rear view camera by blowing air from the nozzle installed to the rear view camera bracket.

### OPERATION CONDITION

- Approximately 20 MPH (30 km/h) or more
- When the around view monitor control unit judges that the rear view camera has water droplets.
- When the low washer fluid warning is OFF.

#### NOTE:

The camera is cleaned intermittently by spraying washer fluid and blowing air. When the around view monitor control unit judges that dirt on the camera cannot be removed even after approximately 5 minutes from the first detection of dirt, the activation of LDW is canceled.

## BSW

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# SYSTEM


## [DRIVER ASSISTANCE SYSTEM]

< SYSTEM DESCRIPTION >

### BSW : System Description

INFOID:000000010227187

### SYSTEM DIAGRAM



#### CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Control unit receives signals via CAN communication. It also detects vehicle conditions that are necessary for BSW control.

Input Signal Item

# SYSTEM

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

Transmit unit	Signal name		Description
BCM	CAN communication	Turn indicator signal	Receives an operational state of the turn signal lamp and the hazard lamp.
		Back door switch signal	Receives a state of the back door switch.
Combination meter	CAN communication	System selection signal	Receives a selection state of each item in "Driver assistance" selected with the combination meter.
Steering angle sensor	CAN communication	Steering angle sensor signal	Receives the number of revolutions, turning direction of the steering wheel.
ECM	CAN communication	Engine status signal	Receives the engine status.
ABS actuator and electric unit (control unit)	CAN communication	Wheel speed signal	Receives wheel speed.
Rear view camera	Communication line	Camera image signal	Receives the camera image signal.
Warning system switch	Warning system switch signal		Receives an ON/OFF state of the warning system switch.

## Output Signal Item

Reception unit	Signal name		Description	
Combination meter	CAN communication	Meter display signal	BSW warning signal	Transmits a meter display signal to turn ON the BSW warning.
			BSW ON indicator signal	Transmits a meter display signal to turn ON the BSW ON indicator.
		Buzzer output signal		Transmits a buzzer output signal to activate the warning buzzer.
Rear view camera washer control unit	Communication line	Rear view camera washer signal	Transmits a rear view camera washer motor signal to activate the rear view camera washer motor.	
		Rear view camera air blow signal	Transmits a rear view camera air blow signal to activate the air pump	
Warning system ON indicator	Warning systems ON indicator signal		Turns ON the warning system ON indicator.	
Warning buzzer	Warning buzzer operation signal		Activates the warning buzzer.	
BSW indicator LH, RH	Indicator operation signal		Turns ON the BSW indicator LH, RH.	

## FUNCTION DESCRIPTION

- The BSW system can help alert the driver of other vehicles in adjacent lanes when changing lanes.
- The BSW system uses rear view camera near the rear bumper to detect vehicles in an adjacent lane.
- The rear view camera can detect vehicles on either side of vehicle within the detection zone shown as illustrated.
- This detection zone starts from the back of the vehicle and extends approximately 10 ft. (3.0 m) behind the rear bumper, and approximately 10 ft. (3.0 m) sideways.
- The BSW system operates above approximately 20 MPH (32 km/h).


DAS

# SYSTEM

## < SYSTEM DESCRIPTION >

## [DRIVER ASSISTANCE SYSTEM]


- If the rear view camera detects vehicles in the detection zone, the blind spot warning indicator illuminates.



- If the driver then activates the turn signal, a buzzer will sound twice and the blind spot warning indicator will blink.

### NOTE:

A buzzer sounds if the rear view camera has already detected vehicles when the driver activates the turn signal. If a vehicle comes into the detection zone after the driver activates the turn signal, then only the blind spot warning indicator blinks and no buzzer sounds.



## BSW SYSTEM OPERATION DESCRIPTION

- Control unit enables BSW system.
- The control unit turns on the BSW system when the warning systems switch is turned ON.
- Rear view camera detects a vehicle in the adjacent lane, and transmits the vehicle detection signal to control unit.
- Control unit starts the control as follows, based on a vehicle detection signal and turn signal transmitted from BCM via CAN communication:
  - Buzzer signal transmission to warning buzzer.
- Around view monitor transmits a blind spot warning indicator signal LH or RH to the blind spot warning indicator LH or RH.

### Operation Condition of BSW System

control unit performs the control when the following conditions are satisfied:

- When the warning system switch is turned ON\*.
- When the vehicle drives at 20 MPH (32 km/h) or more in the forward direction.

### NOTE:

- \*: When the BSW system setting on the vehicle information display screen is ON.
- After the operating conditions of warning are satisfied, the warning continues until the vehicle speed is reduced below approximately 18 MPH (29 km/h)
- The BSW system may not function properly, depending on the situation.

## BULB CHECK ACTION AND FAIL-SAFE INDICATION


# SYSTEM

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

Vehicle condition/Driver's operation	Blind Spot Warning/ Blind Spot Intervention indicator	Warning systems ON indicator	Indication on the combination meter
When DTC is detected.	OFF	ON	OFF → Orange  <div style="border: 1px solid black; padding: 5px; text-align: center; width: fit-content; margin: auto;"> <span style="border: 1px solid black; padding: 2px;">BSW</span>    <b>Malfunction</b>                          See Owner's Manual                     </div> <small style="display: block; text-align: right; margin-top: 5px;">AL0IA0172GB</small>
Temporary disabled status.	OFF	ON	BSW light (white) will blink
When rear view camera needs cleaning.	OFF	ON	Unavailable: Clean Rear Camera
When the warning system switch is pressed. (When the settings of LDW system and BSW system on the combination meter information screen are "OFF").	OFF	Blink	—

\*: Blinking cycle when there is a rear view camera blockage condition or lane camera unit high temperature condition



**NOTE:**  
Time shown in the figure is approximate.

FAIL-SAFE INDICATION






A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# SYSTEM

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

Vehicle condition/Driver's operation	BSW indicator	Warning systems ON indicator	Indication on the combination meter
When DTC is detected	OFF	ON	 <small>JSOIA0749ZZ</small>
When vehicles cannot be detected due to dirt on the rear view camera	OFF	ON	 <small>JSOIA0750ZZ</small>
			<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;">                     Unavailable: Clean Rear Camera                 </div> <small>JSOIA0738ZZ</small>
When the washer fluid level is low (Low washer warning ON)	OFF	ON	Blinks at intervals of two seconds.  <small>JSOIA0751ZZ</small>
When the back door is open (Back door open warning ON)	OFF	ON	Blinks at intervals of two seconds.  <small>JSOIA0751ZZ</small>
Blinks when the setting of LDW and BSW are "OFF" and the warning systems switch is pressed	OFF	OFF	<div style="border: 1px solid black; padding: 5px; width: fit-content; margin: auto;">                      Unavailable: Select Driving Aids in Settings.                 </div> <small>JSOIA0780ZZ</small>

## REAR VIEW CAMERA WASHER OPERATION

- When judging that the rear view camera has water droplets, the around view monitor control unit transmits a rear view camera washer activation signal or rear view camera air blow signal to the pump control unit via serial communication.
- When receiving a rear view camera washer activation signal, the pump control unit simultaneously activates the washer pump to clean the rear view camera by spraying washer fluid from the nozzle installed to the rear view camera bracket.



# SYSTEM

## [DRIVER ASSISTANCE SYSTEM]

### < SYSTEM DESCRIPTION >

- When receiving a rear view camera air blow signal, the pump control unit activates the air pump to clean the rear view camera by blowing air from the nozzle installed to the rear view camera bracket.

A

### OPERATION CONDITION

- Approximately 20 MPH (30 km/h) or more
- When the around view monitor control unit judges that the rear view camera has water droplets.
- When the low washer fluid warning is OFF.

B

### NOTE:

The camera is cleaned intermittently by spraying washer fluid and blowing air. When the around view monitor control unit judges that dirt on the camera cannot be removed even after approximately 5 minutes from the first detection of dirt, the activation of BSW is canceled.

C

### MOD

D

E

F

G

H

I

J

K

L

M

N

DAS

P

# SYSTEM


[DRIVER ASSISTANCE SYSTEM]

< SYSTEM DESCRIPTION >

MOD : System Description

INFOID:000000010227183

## SYSTEM DIAGRAM



### AROUND VIEW MONITOR CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Input Signal Item

# SYSTEM

## < SYSTEM DESCRIPTION >

## [DRIVER ASSISTANCE SYSTEM]


Transmit unit	Signal name		Description
ECM	CAN communication	Engine speed signal	Receives engine status
BCM	CAN communication	Back door open status signal	Receives back door open status
		Light status signal	Receives light status
		Turn signal	Receives turn signal status
ABS actuator and electric unit (control unit)	CAN communication	Wheel speed signal	Receives wheel speed
TCM	CAN communication	Shift selector position signal	Receives shift selector position
Combination meter	CAN communication	Moving Object Detection ON/OFF signal	Receives the ON/OFF status for Moving Object Detection function
Rear view camera	Communication line	Video signal	Receives the Rear View Camera image from camera for Moving Object Detection function in around view monitor control unit

### Output Signal Item


Reception unit	Signal name		Description
Warning system buzzer	Warning buzzer signal		Activates the warning buzzer
AV control unit display	CAN communication	Visual signal request	Transmits a visual signal request from the around view monitor control unit to display Rear View while the shift selector is in R (reverse).

### FUNCTION DESCRIPTION

- The Moving Object Detection (MOD) system can help alert the driver of approaching vehicles or rear objects when the driver is backing out of a parking space.
- The MOD system comprises of the rear view camera as the main detection system, which is located on the back door as illustrated.
- The MOD system operates at speeds below 5 MPH (8 km/h) whenever the vehicle is in R (reverse).



- The MOD system uses the rear view camera to detect approaching moving objects from either side.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P


DAS

# SYSTEM

## < SYSTEM DESCRIPTION >

## [DRIVER ASSISTANCE SYSTEM]

- The MOD system can detect moving objects on either side as close as rear obstacles of up to approximately 10 feet (3 m).



### MOVING OBJECT DETECTION SYSTEM OPERATION DESCRIPTION

- Around view monitor control unit enables Moving Object Detection system.
- Combination meter turns Moving Object Detection ON indicator lamp ON/OFF according to the signals from around view monitor control unit via CAN communication.
- Around view monitor control unit starts the control as follows, based on a vehicle detection signal.

#### Operation Condition of Moving Object Detection System

Around view monitor control unit performs the control when the following conditions are satisfied:


- Moving Object Detection ON indicator: ON
- When the vehicle is moving in R (reverse) at 5 MPH (8 km/h) or less.

#### NOTE:

- When the Moving Object Detection system setting on the Vehicle Information Display is ON.
- Moving Object Detection braking will not operate or will stop operating and only a warning chime will sound under the following conditions:
  - When driving with a tire that is not within normal tire conditions (pressure, wear, chain, spare, etc.)
  - When the vehicle is equipped with non-original brake parts or suspension parts.
- Do not use the MOD system when towing a trailer.
- Excessive noise such as the audio system will interfere with the chime sound, and it may not be heard.

### FCW

SYSTEM DIAGRAM



AROUND VIEW MONITOR CONTROL UNIT INPUT/OUTPUT SIGNAL ITEM

Input Signal Item

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# SYSTEM

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

Transmit unit	Signal name		Description
ABS actuator and electric unit (control unit)	CAN communication	Wheel speed signal	Receives wheel speed
Combination meter	CAN communication	System selection signal	Receives a selection state each item in "Driver Aids" selected with the steering switch
Distance sensor	CAN communication	Distance sensor signal	Receives detection results, such as the presence or absence of a leading vehicle and distance from the vehicle
Warning system switch	Warning system switch signal		Receives an ON/OFF state of the warning system switch

## Output Signal Item

Reception unit	Signal name		Description
Combination meter	CAN communication	Meter display signal	Transmits a signal to display a state of the system on the information display
		Vehicle ahead detection indicator signal	
Distance sensor	CAN communication	Buzzer signal	Transmits a output signal to activate the buzzer
		Vehicle speed signal	Transmits a vehicle speed calculated by the distance sensor

## DESCRIPTION

- The Forward Collision Warning (FCW) System alerts the driver by a warning lamp (vehicle ahead detection indicator) and chime when own vehicle is getting close to the vehicle ahead in the traveling lane.
- The FCW system will function when own vehicle is driven at speeds of approximately 10 MPH (15 km/h) and above.

## FUNCTION DESCRIPTION

The distance from the vehicle ahead and a relative speed are calculated by using the distance sensor signal transmitted to the combination meter via CAN communication. When judging the necessity of warning from the received distance sensor signal, the distance sensor transmits a buzzer signal and warning signal to the combination meter via CAN communication.

### FCW Operating Condition

- Warning system switch ON)
- Vehicle speed: Approximately 10 MPH (15 km/h) and above.

# OPERATION

[DRIVER ASSISTANCE SYSTEM]


< SYSTEM DESCRIPTION >

## OPERATION

### BSW

#### BSW : Switch Name and Function

INFOID:000000010287276




No.	Name	Function
1.	Warning systems switch	Turns BSW system ON/OFF (When the setting of BSW system on the vehicle information display setting screen is ON)

#### BSW : System Display and Warning

INFOID:000000010287277

#### INDICATOR AND WARNING LAMP



No.	Name	Description
1.	Warning systems ON indicator	Indicates that the LDW system is ON.
2.	Blind Spot Warning lamp (orange)	<ul style="list-style-type: none"> <li>• Turns ON when Blind Spot Warning system is malfunctioning.</li> <li>• Blinks during the following conditions:                             <ul style="list-style-type: none"> <li>- DTC is detected or system is temporarily disabled.</li> <li>- When rear view camera blockage is detected.</li> </ul> </li> </ul>

#### DISPLAY AND WARNING OPERATION

Vehicle condition/ Driver's operation				Action	
Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of vehicle detection within detection area	Indication on the Blind Spot Warning indicator	Buzzer
OFF	—	—	—	OFF	OFF

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# OPERATION

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

Vehicle condition/ Driver's operation				Action	
Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of vehicle detection within detection area	Indication on the Blind Spot Warning indicator	Buzzer
ON	Less than approx. 29km/h (18MPH)	—	—	OFF	OFF
	Approx. 32 km/h (20 MPH) or more	—	Vehicle is absent	OFF	OFF
		OFF	Vehicle is detected	ON	ON
		ON (vehicle detected direction)	Before turn signal operates Vehicle is detected	Blink Indicator ON Indicator OFF  JSOIA0251GB	Short continuous beep Buzzer ON Buzzer OFF  JSOIA0252GB
	ON (vehicle detected direction)	Vehicle is detected after turn signal operates	Blink Indicator ON Indicator OFF  JSOIA0251GB	OFF	


**NOTE:**

- If vehicle speed exceeds approximately 32 km/h (20 MPH), BSW function operates until the vehicle speed becomes lower than approximately 29 km/h (18 MPH).
- Time shown in the figure is approximate.
- Whenever Blind Spot Warning system is turned off, the warning systems ON indicator remains OFF.

## LDW

### LDW : Switch Name and Function

INFOID:000000010287278



No.	Switch name	Description
1.	Warning systems switch	Turns LDW system ON/OFF (When the setting of LDW system on the vehicle information display setting screen is ON)



# OPERATION


< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

## LDW : Menu Displayed by Pressing Each Switch


INFOID:000000010287279

### INDICATOR LAMP AND WARNING LAMP



No.	Display item	Description
1.	Warning systems ON indicator	Indicates that the LDW system is ON
2.	Lane departure warning lamp	<ul style="list-style-type: none"> <li>• Blinks when LDW system is activated</li> <li>• Turns ON when LDW system has a malfunction</li> <li>• Blinks when DTC is detected or system is temporarily disabled</li> <li>• Blinks when rear view camera blockage is detected</li> </ul>

### DISPLAY AND WARNING

Vehicle condition/ Driver's operation	Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Less than Approx. 60 km/h (40 MPH)	Close to lane marker	No action	White	—
Approx. 70 km/h (45 MPH) or more	Close to lane marker	Warning <ul style="list-style-type: none"> <li>• Buzzer sounds</li> <li>• Warning lamp blinks (orange)</li> </ul>	OFF (orange) Blink 	Short continuous beeps
	<ul style="list-style-type: none"> <li>• Close to lane marker</li> <li>• Turn signal ON (Deviate side)</li> </ul>	No action	White	—

#### NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to [DAS-16, "LDW : System Description"](#).

### MOD

#### MOD : System Display and Warning

INFOID:000000010287280

DAS

### INDICATOR AND WARNING LAMP

The MOD system can be turned ON or OFF for the current ignition cycle using the warning system switch. When toggled between ON and OFF, the indicator will appear on the right side of the rear view camera screen.

# OPERATION

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

No.	Name	Description
1.	MOD indicator (blue)	<ul style="list-style-type: none"> <li>• Turns ON while MOD system is ON.</li> <li>• Under the following conditions, the MOD indicator (blue) will blink.                             <ul style="list-style-type: none"> <li>- When the VDC system (except TCS function) or ABS operates.</li> <li>- When the VDC system is turned off.</li> </ul> </li> </ul>
	MOD warning lamp (orange)	<ul style="list-style-type: none"> <li>• Turns ON when MOD system is malfunctioning.</li> <li>• Blinks under the following conditions:                             <ul style="list-style-type: none"> <li>- When the component temperature reaches high level.</li> <li>- When rear view camera blockage is detected.</li> </ul> </li> </ul>


## DISPLAY AND WARNING OPERATION

Vehicle condition/Driver's operation			Indication on the Moving Object Detection indicator	Buzzer
Moving Object Detection ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Status of vehicle detection within detection area		
OFF	—	—	OFF	OFF
Blue	Less than approx. 8 km/h (5 MPH)	Vehicle is detected	ON	ON
		Vehicle is absent	ON	OFF
	Approx. 8 km/h (5 MPH) or more	Vehicle is detected	ON	OFF
Vehicle is not detected		ON	OFF	

## FCW

### FCW : Switch Name and Function

INFOID:0000000010287281



No.	Switch name	Description
1.	Warning systems switch	Turns FCW system ON/OFF (When the setting of FCW system in the vehicle information display is ON)
2.	FCW system setting screen (the vehicle information display)	The setting of FCW system can be switched between ON and OFF

# OPERATION


## [DRIVER ASSISTANCE SYSTEM]

< SYSTEM DESCRIPTION >

### FCW : Menu Displayed by Pressing Each Switch


INFOID:000000010287282

#### DISPLAY AND WARNING LAMP



No.	Display item	Description
1.	Warning systems ON indicator	Indicates that the FCW system is ON.
2.	Vehicle ahead detection indicator	Vehicle ahead detection indicator blinks when the FCW system is activated.

#### SYSTEM CONTROL CONDITION DISPLAY

Condition	Warning systems ON indicator	Vehicle ahead detection indicator (In the combination meter)	Buzzer
Set condition	ON	OFF	—
When the warning systems switch is turned ON with settings of FCW system OFF.	Blink	OFF	—
When own vehicle comes close to the vehicle ahead and it is judged that the distance between the vehicles is not sufficient.	ON		Beep

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

## HANDLING PRECAUTION

### Precautions for Forward Collision Warning

INFOID:000000010227204

- The forward collision warning system is designed to warn the driver before a collision but will not avoid a collision. It is the driver's responsibility to stay alert, drive safely and be in control of the vehicle at all times.
- The distance sensor does not detect the following objects:
  - Pedestrians, animals, or obstacles in the roadway.
  - Oncoming vehicles
  - Crossing vehicles
- The forward collision warning system does not function when a vehicle ahead is a narrow vehicle, such as a motorcycle.
- The distance sensor may not detect a vehicle ahead in the following conditions:
  - Snow or heavy rain
  - Dirt, ice, snow or other material covering the radar sensor
  - Interference by other radar sources
  - Snow or road spray from traveling vehicles is splashed
  - Driving in a tunnel
- When the distance to the vehicle ahead is too close, the beam of the radar sensor is obstructed.
- The distance sensor may not detect a second vehicle when driving on a steep downhill slope or on roads with sharp curves.
- Excessive noise will interfere with the warning tone sound, and it may not be heard.

### Precautions for Lane Departure Warning


INFOID:000000010227205

#### REAR VIEW CAMERA HANDLING

The rear camera unit "1" for the LDW/BSW systems is located above the rear license plate.

To keep the proper operation of the LDW systems and prevent a system malfunction, be sure to observe the following:

- Always keep the camera lens clean. Be careful not to damage the nozzle of the automatic washer and blower.
- Do not attach "license plate accessories" that reflect light.
- Do not strike or damage the areas around the camera unit.



#### LANE DEPARTURE WARNING (LDW)

- LDW system is only a warning device to inform the driver of a potential unintended lane departure. It will not steer the vehicle or prevent loss of control. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the traveling lane, and be in control of the vehicle at all times.
- The camera unit may not detect properly under the following conditions:
  - When towing a trailer.
  - When strong light enters the camera unit. (For example, direct sunlight or headlight from the rear.)
  - When ambient light changes instantly. (For example, when the vehicle enters or exits a tunnel or passes under a bridge.)
- Automatic washer and blower may not be able to secure detection capability when excessive dirt adheres on the camera lens.
- Excessive noise (e.g. audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- The camera unit may not be able to detect properly under the following conditions:
  - On roads where there are multiple parallel lane markers; lane markers that are faded or not painted clearly; yellow painted lane markers; non-standard lane markers; or lane markers covered with water, dirt or snow, etc.

# HANDLING PRECAUTION

## < SYSTEM DESCRIPTION >

## [DRIVER ASSISTANCE SYSTEM]

- On roads where the discontinued lane markers are still detectable.
- On roads where there are sharp curves.
- On roads where there are sharply contrasting objects, such as shadows, snow, water, wheel ruts, seams or lines remaining after road repairs. (The LDW system could detect these items as lane markers.)
- On roads where the traveling lane merges or separates.
- When the vehicle's traveling direction does not align with the lane marker.
- When the road surface is very dark due to scarce ambient light or impaired tail lamp.
- When driving on a curved road, warning will be late on the outside of the curve due to the nature of the system.

### Precautions for Blind Spot Warning


INFOID:000000010227206

#### REAR VIEW CAMERA HANDLING

The rear camera unit (1) for the LDW/BSW systems is located above the rear license plate.

To keep the proper operation of the LDW systems and prevent a system malfunction, be sure to observe the following:

- Always keep the camera lens clean. Be careful not to damage the nozzle of the automatic washer and blower.
- Do not attach "license plate accessories" that reflect light.
- Do not strike or damage the areas around the camera unit.



#### BLIND SPOT WARNING (BSW)

- BSW system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When changing lanes, always use the side and rear mirrors and turn and look in the direction you will move to ensure it is safe to change lanes. Never rely solely on the BSW system.
- The camera unit may not detect properly under the following conditions:
  - When towing a trailer.
  - When strong light enters the camera unit. (For example, direct sunlight or headlight from the rear.)
  - When ambient light changes instantly. (For example, when the vehicle enters or exits a tunnel or passes under a bridge.)
- Automatic washer and blower may not be able to secure detection capability when excessive dirt adheres on the camera lens.
- Excessive noise (e.g. audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- The camera unit may not be able to detect when certain objects are present such as:
  - Pedestrians, bicycles, animals.
  - Several types of vehicles such as motorcycles.
  - Oncoming vehicles.
  - A vehicle approaching rapidly from behind
  - A vehicle which your vehicle overtakes rapidly.
- The camera unit may not be able to detect properly when your vehicle travels beside the middle section of a vehicle with a long wheelbase (e.g., trailer truck, semi-trailer, tractor).
- The camera unit is designed to ignore most stationary objects, however objects such as guardrails, walls, foliage and parked vehicles may occasionally be detected. This is a normal operating condition.
- The camera unit may detect reflection image of vehicles or roadside objects that are not actually in the detection zone, especially when the road is wet.

### Precautions for Moving Objects Detection

INFOID:000000010425175

#### REAR VIEW CAMERA HANDLING

- The rear view camera is located on the back door.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

## HANDLING PRECAUTION

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

- Always keep the rear view camera lens clean.
- Do not attach a sticker (including transparent material), install an accessory or paint work over the camera lens.
- Do not strike or scratch the lens causing physical damage to the camera or the surrounding area.

### MOVING OBJECT DETECTION

- The Moving Object Detection system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When backing up, always look in the direction driver will move to ensure it is safe to proceed. Never rely solely on the Moving Object Detection system.
- Using the Moving Object Detection system under some road or weather conditions could lead to improper system operation. Always rely on driver's own steering and braking operation to avoid accidents.
- The Moving Object Detection system may not provide a warning for vehicles that pass through the detection zone quickly.
- Do not use the Moving Object Detection system when towing a trailer.
- Excessive noise (e.g., audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- The rear view camera may not be able to detect and activate Moving Object Detection when certain objects are present such as:
  - Pedestrians, bicycles, animals.
  - A vehicle passing at a speed greater than approximately 15 MPH (24km/h).
  - Severe weather or road spray conditions may reduce the ability of the radar to detect other vehicles.
- Do not use the MOD system under the following conditions because the system may not function properly:
  - When driving with a tire that is not within normal tire condition (example: tire wear, low pressure, spare tire, chain, non-standard wheels).
  - When the vehicle is equipped with non-original brake parts or suspension parts.

# DIAGNOSIS SYSTEM (AROUND VIEW MONITOR CONTROL UNIT)

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

## DIAGNOSIS SYSTEM (AROUND VIEW MONITOR CONTROL UNIT)

### CONSULT Function

INFOID:0000000010284113

### CONSULT FUNCTIONS

CONSULT performs the following functions via communication with the around view monitor control unit.

Direct Diagnostic Mode	Description
Ecu Identification	The around view monitor control unit part number is displayed.
Self Diagnostic Result	The around view monitor control unit self diagnostic results are displayed.
Data Monitor	The around view monitor control unit input/output data is displayed in real time.
Work support	The settings for around view monitor control unit functions can be changed.
Configuration	<ul style="list-style-type: none"><li>The vehicle specification can be read and saved.</li><li>The vehicle specification can be written when replacing around view monitor control unit.</li></ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

### ECU IDENTIFICATION

The part number of around view monitor control unit is displayed.

### SELF DIAGNOSTIC RESULT

Refer to [DAS-47, "DTC Index"](#).

### DATA MONITOR

Monitor Item	Description
ST ANGLE SENSOR SIGNAL [On/Off]	Indicates condition of steering angle sensor signal.
REVERSE SIGNAL [On/Off]	Indicates selector lever position.
VEHICLE SPEED SIGNAL [mph/km/h]	Indicates condition of vehicle speed signal.
CAMERA SWITCH SIGNAL [On/Off]	Indicates condition of camera switch signal.
CAMERA OFF SIGNAL [On/Off]	Indicates condition of camera OFF signal.
ST ANGLE SENSOR TYPE [Absolute]	Indicates steering angle sensor type.
ST GEAR RATIO TYPE [Type O]	Indicates steering gear ratio type.
STEERING POSITION [LHD/RHD]	Indicates LH or RH drive type.
REAR CAMERA IMAGE SIGNAL [OK/NG]	Indicates condition of camera image signal.
WASH SW [On/Off]	Indicates state of wash switch indicator output.
R-CAMERA COMM STATUS [OK/Not]	Indicates status of rear camera communication.
R-CAMERA COMM LINE [OK/Not]	Indicates condition of rear camera communication line.
F-CAMERA IMAGE SIGNAL [OK/NG]	Indicates condition of camera image signal.
DR-SIDE CAMERA IMAGE SIG [OK/NG]	Indicates condition of camera image signal.
PA-SIDE CAMERA IMAGE SIG [OK/NG]	Indicates condition of camera image signal.
PUMP COMM STATUS [OK/Not]	Indicates state of communication signal from pump control unit.
ILL [On/Off]	Indicates status of illumination signal.
ITS SW 1 [On/Off]	Indicates state of warning system switch.
ITS SW 1 IND [On/Off]	Indicates state of warning system switch indicator output.
TURN SIGNAL [Left/N/Right]	Indicates status of turn signal output.
ITS SW 2 [ON/OFF/No setting]	Indicates state of warning system secondary switch.
ITS SW 2 IND [ON/OFF/No setting]	Indicates state of warning system secondary switch indicator output.

### ACTIVE TEST

# DIAGNOSIS SYSTEM (AROUND VIEW MONITOR CONTROL UNIT)

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

Test item	Description
LED RH INDICATOR	This test is able to check RH LED indicator operation [LED Off/LED On].
LED LH INDICATOR	This test is able to check LH LED indicator operation [LED Off/LED On].
WASH ACTIVE	This test is able to check rear camera wash operation [WASH Off/WASH On].
AIR ACTIVE	This test is able to check rear camera air operation [AIR Off/AIR On].
AIR & WASH ACTIVE	This test is able to check rear camera air and wash operation [Off/On].
AVM BUZZER CONTROL	This test is able to check AVM buzzer operation [Off/On].

## WORK SUPPORT

Support Item	Setting	Description
REAR CAMERA ITS	—	Displays and sets camera image calibration values.
CAUSE OF LDW CANCEL	—	Displays the information about reason of LDW cancellation.
CAUSE OF BSW CANCEL	—	Displays the information about reason of BSW cancellation.
CALIBRATING CAMERA IMAGE (FRONT CAMERA)	STATUS	Performs calibration of front camera.
	AXIS X	
	AXIS Y	
	ROTATE	
CALIBRATING CAMERA IMAGE (PASS-SIDE CAMERA)	STATUS	Performs calibration of passenger side camera.
	AXIS X	
	AXIS Y	
	ROTATE	
CALIBRATING CAMERA IMAGE (DR-SIDE CAMERA)	STATUS	Performs calibration of driver side camera.
	AXIS X	
	AXIS Y	
	ROTATE	
CALIBRATING CAMERA IMAGE (REAR CAMERA)	STATUS	Performs calibration of rear camera.
	AXIS X	
	AXIS Y	
	ROTATE	
FINE TUNING OF BIRDS-EYE VIEW	STATUS	Confirmation and adjustment of difference between each camera can be performed.
	SELECT	
	AXIS X	
	AXIS Y	
	ROTATE	
REAR WIDE-VIEW FIXED GUIDE LINE CORRECTION	STATUS	Adjusts position of fixed guide line on rear wide view
	AXIS X	
	AXIS Y	
	Pattern	
FRONT WIDE-VIEW FIXED GUIDE LINE CORRECTION	STATUS	Adjusts position of fixed guide line on front wide view
	AXIS X	
	AXIS Y	
	Pattern	
NON-VIEWABLE AREA REMINDER	ON	ON/OFF setting of non-viewable area can be performed.
	OFF	



# DIAGNOSIS SYSTEM (AROUND VIEW MONITOR CONTROL UNIT)

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

Support Item	Setting	Description
PREDICTIVE COURSE LINE DISPLAY	ON	ON/OFF setting of predictive course line display can be performed.
	OFF	
INITIALIZE CAMERA IMAGE CALIBRATION	—	Factory image calibration restoration can be performed.
STEERING ANGLE SENSOR ADJUSTMENT	—	Steering angle sensor neutral position adjustment can be performed.

## CONFIGURATION

Refer to [AV-289, "CONFIGURATION \(AV CONTROL UNIT\) : Description"](#).

## CAN DIAG SUPPORT MNTR

Refer to [LAN-14, "CAN Diagnostic Support Monitor"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# DIAGNOSIS SYSTEM (DISTANCE SENSOR)

< SYSTEM DESCRIPTION >

[DRIVER ASSISTANCE SYSTEM]

## DIAGNOSIS SYSTEM (DISTANCE SENSOR)

### CONSULT Function (LASER/RADAR)

INFOID:000000010227210

#### APPLICATION ITEMS

CONSULT performs the following functions via CAN communication with Distance sensor.

Diagnosis mode	Description
Self Diagnostic Result	Displays malfunctioning system memorized in Distance sensor.
Data Monitor	Displays real-time input/output data of Distance sensor.
Active Test	Distance sensor activates outputs to components.
Work Support	It can monitor the adjustment direction indication in order to perform the radar alignment operation smoothly.
ECU Identification	Displays Distance sensor part number.
CAN Diag Support Monitor	Monitor the reception status of CAN communication viewed from Distance sensor.

#### SELF DIAGNOSTIC RESULT

Refer to [DAS-49. "DTC Index"](#).

#### DATA MONITOR

##### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitored item [Unit]	Description
VHCL SPEED SE [mph] or [km/h]	Vehicle speed signal received from ABS actuator and electric unit (control unit) via CAN communication.
YAW RATE [deg/s]	Yaw rate signal received from ABS actuator and electric unit (control unit) via CAN communication.
PWR SUP MONI [V]	Indicates IGN voltage input by Distance sensor.
DISTANCE [feet]	Indicates the distance from the vehicle ahead.
RELATIVE SPD [fps]	Indicates the relative speed of the vehicle ahead.
LASER OFFSET [deg]	<b>NOTE:</b> The item is indicated, but not used.
LASER HEIGHT [deg]	<b>NOTE:</b> The item is indicated, but not used.
STEERING ANGLE [deg]	The steering angle is displayed.
STRG ANGLE SPEED [deg/s]	The steering angle speed is displayed.
L/R ADJUST [deg]	Indicates a horizontal correction value of the radar.
U/D ADJUST [deg]	Indicates a vertical correction value of the radar.

#### WORK SUPPORT

Work support items	Description
MILLIWAVE RADAR ADJUST	Outputs millimeter waves, calculates dislocation of the millimeter waves, and indicates adjustment direction.

Distance sensor alignment

# DIAGNOSIS SYSTEM (DISTANCE SENSOR)

[DRIVER ASSISTANCE SYSTEM]

< SYSTEM DESCRIPTION >

Refer to [DAS-72, "Description"](#).

## ACTIVE TEST

Test item	Description
ICC BUZZER	This test is able to check FCW warning chime operation [On/Off] in the combination meter.
METER LAMP	This test is able to check FCW warning indicator operation [On/Off] in the combination meter information display.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# AROUND VIEW MONITOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[DRIVER ASSISTANCE SYSTEM]

## ECU DIAGNOSIS INFORMATION

### AROUND VIEW MONITOR CONTROL UNIT

Reference Value

INFOID:0000000010284114

#### VALUES ON THE DIAGNOSIS TOOL

Monitor Item	Condition	Value/Status
CAMERA OFF SIGNAL	CAMERA switch ON.	Off
	CAMERA switch OFF.	On
CAMERA SWITCH SIGNAL	CAMERA switch OFF.	Off
	CAMERA switch ON.	On
DR-SIDE CAMERA IMAGE SIG	Side camera LH inoperative.	NG
	Side camera LH operative.	OK
ILL	Illumination is ON	On
	Illumination is OFF	Off
ITS SW 1	ITS switch is pressed	On
	ITS switch is not pressed	Off
ITS SW 1 IND	Indicator of ITS switch 1 is lighting	On
	Indicator of ITS switch 1 is not lighting	Off
ITS SW 2	For this vehicle, the displaying is fixed	No SET
ITS SW 2 IND	For this vehicle, the displaying is fixed	No SET
F-CAMERA IMAGE SIG	Front camera inoperative.	NG
	Front camera operative.	OK
PA-SIDE CAMERA IMAGE SIG	Side camera RH inoperative.	NG
	Side camera RH operative.	OK
PUMP COMM STATUS	Pump communication signal is received	On
	Pump communication signal is not received	Off
R-CAMERA COMM STATUS	Rear camera serial status is OK	OK
	Rear camera serial status is not OK	NG
R-CAMERA COMM LINE	Rear camera serial communication signal is received	OK
	Rear camera serial communication signal is not received	NG
REAR CAMERA IMAGE SIGNAL	Rear camera LH inoperative.	NG
	Rear camera LH operative.	OK
REVERSE SIGNAL	When selector lever is in any position other than R (reverse).	Off
	When selector lever in R (reverse).	On
ST ANGLE SENSOR SIGNAL	Around view monitor control unit is not receiving steering angle sensor signal.	Off
	Around view monitor control unit is receiving steering angle sensor signal.	On
ST ANGLE SENSOR TYPE	Steering angle sensor type.	Absolute
ST GEAR RATIO TYPE	Steering gear ratio type.	Type O
STEERING POSITION	Left hand drive vehicle.	LHD
	Right hand drive vehicle.	RHD
TURN SIGNAL	Turn signal left is received	Left
	Turn signal neutral is received	N
	Turn signal right is received	Right


# AROUND VIEW MONITOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[DRIVER ASSISTANCE SYSTEM]

Monitor Item	Condition	Value/Status
VEHICLE SPEED SIGNAL	While driving, equivalent to speedometer reading	mph, km/h
WASH SW	Wash switch signal is pressed	On
	Wash switch signal is not pressed	Off

## TERMINAL LAYOUT







## PHYSICAL VALUES

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/Output	Ignition switch	Operation	
1 (B)	Ground	Ground	—	ON	—	0 V
2 (Y)	Ground	Battery power supply	Input	OFF	—	Battery voltage
3 (SB)	Ground	Ignition signal	Input	ON	—	Battery voltage
7 (R)	Ground	SOW LED signal L	Output	—	LDW/BSW detected (while driving)	12 V
					LDW/BSW is not detected (while driving)	0 V
8 (G)	Ground	SOW LED signal R	Output	—	LDW/BSW detected (while driving)	12 V
					LDW/BSW is not detected (while driving)	0 V
15 (BR)	Ground	ITS sw indicator	Output	ON	Warning system is ON	12 V
					Warning system is OFF	0 V
16 (Y)	Ground	Warning buzzer control	Output	—	—	—
17 (W)	Ground	ITS OFF sw	Input	ON	Cancel switch pressed	0 V
					Cancel switch released	12 V
27 (L)	—	CAN (H)	Input/Output	—	—	—
28 (R)	—	CAN (L)	Input/Output	—	—	—
36 (Y)	Ground	Washer signal AVM to pump	Output	ON	Rear view camera washer motor operated	5 V
37 (V)	Ground	Pump signal ground	Input	ON	—	0 V
38 (SB)	Ground	Washer signal pump to AVM	Input	ON	Rear view camera washer motor operated	5 V

# AROUND VIEW MONITOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[DRIVER ASSISTANCE SYSTEM]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
47 (G)	Ground	Camera image signal	Output	ON	When camera image display	
48 (Shield)	—	Camera image signal shield	—	—	—	—
49 (LG)	—	Rear view serial signal	Input/ Output	—	—	—
50 (R)	Ground	Rear camera power supply	Output	ON	CAMERA selected or Shift selector in R (reverse) position.	6.0 V
52 (B)	Ground	Rear camera ground	—	ON	—	0 V
53 (W)	54 (Shield)	Rear camera image signal	Input	ON	CAMERA selected or Shift selector in R (reverse) position.	
56 (L)	Ground	Side camera LH power supply	Output	ON	CAMERA selected or Shift selector in R (reverse) position.	6.0 V
58 (Y)	Ground	Side camera LH ground	—	ON	—	0 V
59 (G)	60 (Shield)	Side camera LH image signal	Input	ON	CAMERA selected or Shift selector in R (reverse) position.	
62 (B)	Ground	Side camera RH power supply	Output	ON	CAMERA selected or Shift selector in R (reverse) position.	6.0 V
64 (L)	Ground	Side camera RH ground	—	ON	—	0 V
65 (Y)	66 (Shield)	Side camera RH image signal	Input	ON	CAMERA selected or Shift selector in R (reverse) position.	

# AROUND VIEW MONITOR CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[DRIVER ASSISTANCE SYSTEM]

Terminal (Wire color)		Description		Condition		Reference value (Approx.)
+	-	Signal name	Input/ Output	Ignition switch	Operation	
68 (L)	Ground	Front camera power supply	Output	ON	CAMERA selected or Shift selector in R (reverse) position.	6.0 V
70 (V)	Ground	Front camera ground	—	ON	—	0 V
71 (LG)	72 (Shield)	Front camera image signal	Input	ON	CAMERA selected or Shift selector in R (reverse) position.	 <p style="text-align: right; font-size: small;">JSNIA0834GB</p>

## DTC Index

INFOID:0000000010284115

CONSULT Display	Reference Page
U0428: ST ANG SEN CALIB	<a href="#">AV-141, "DTC Logic"</a>
U1000: CAN COMM CIRCUIT	<a href="#">AV-142, "AROUND VIEW MONITOR CONTROL UNIT : DTC Logic"</a>
U1010: CONTROL UNIT (CAN)	<a href="#">AV-143, "AROUND VIEW MONITOR CONTROL UNIT : DTC Logic"</a>
U111A: Rear display output signal diagnosis (Harness disconnection)	<a href="#">AV-144, "DTC Logic"</a>
U111B: Right side display output signal diagnosis (Harness disconnection)	<a href="#">AV-148, "DTC Logic"</a>
U111C: Front display output signal diagnosis (Harness disconnection)	<a href="#">AV-152, "DTC Logic"</a>
U111D: Left side display output signal diagnosis (Harness disconnection)	<a href="#">AV-156, "DTC Logic"</a>
U1232: ST ANG SEN CALIB	<a href="#">AV-163, "DTC Logic"</a>
U1302: Camera supply power supply voltage abnormality	<a href="#">DAS-117, "DTC Logic"</a>
U1303: LED supply power supply voltage abnormality	<a href="#">DAS-121, "DTC Logic"</a>
U1304: Non-completion of the calibration	<a href="#">AV-177, "DTC Logic"</a>
U1305: Non-completion of the configuration	<a href="#">AV-178, "DTC Logic"</a>
U1308: Rear camera judgment	<a href="#">DAS-124, "DTC Logic"</a>
U1309 PUMP UNIT CURRENT	<a href="#">DAS-125, "DTC Logic"</a>
U130A: PUMP ECU JUDGE	<a href="#">DAS-127, "DTC Logic"</a>
U0122: VDC CAN CIR1 (LDP)	<a href="#">DAS-100, "DTC Logic"</a>
U0416: VDC CAN CIR2 (LDP)	<a href="#">DAS-104, "DTC Logic"</a>
U1232: ST ANG SEN CALIB	<a href="#">DAS-116, "DTC Logic"</a>
C1A03: VHCL SPEED SE CIRC	<a href="#">DAS-131, "AROUND VIEW MONITOR CONTROL UNIT : DTC Logic"</a>
C1A39: STRG SEN CIR	<a href="#">DAS-142, "AROUND VIEW MONITOR CONTROL UNIT : DTC Logic"</a>
C1A04: ABS/TCS/VDC CIRC	<a href="#">DAS-132, "AROUND VIEW MONITOR CONTROL UNIT : DTC Logic"</a>
U130B: Rear camera serial communication err	<a href="#">DAS-128, "DTC Logic"</a>

# DISTANCE SENSOR

< ECU DIAGNOSIS INFORMATION >

[DRIVER ASSISTANCE SYSTEM]

## DISTANCE SENSOR

### Reference Value

INFOID:000000010227221


### VALUES ON THE DIAGNOSIS TOOL

**NOTE:**

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item	Condition		Value/Status
VHCL SPEED SE	While driving		Value of vehicle speed signal (wheel speed)
YAW RATE	While driving	Vehicle stopped	0.0
		Vehicle turning right	Positive value
		Vehicle turning left	Negative value
PWR SUP MONI	Ignition switch ON		Power supply voltage value of Distance sensor
DISTANCE	Drive the vehicle and activate the vehicle-to-vehicle distance control mode	When a vehicle ahead is detected	Displays the distance from the preceding vehicle
		When a vehicle ahead is not detected	0.0
RELATIVE SPD	Drive the vehicle and activate the vehicle-to-vehicle distance control mode	When a vehicle ahead is detected	Displays the relative speed
		When a vehicle ahead is not detected	0.0
RADAR OFFSET	<b>NOTE:</b> The item is indicated, but not used		—
RADAR HEIGHT	<b>NOTE:</b> The item is indicated, but not used		—
STEERING ANGLE	Ignition switch ON	When setting the steering wheel in straight-ahead position	0.0
		When turning the steering wheel 90° rightward	+90
		When turning the steering wheel 90° leftward	-90
STRG ANGLE SPEED	Ignition switch ON	At the time of turning the steering wheel	Steering wheel turning speed is displayed
L/R ADJUST	Ignition switch ON	At the completion of radar alignment adjustment	Horizontal correction value is displayed
U/D ADJUST	Ignition switch ON	At the completion of radar alignment adjustment	Vertical correction value is displayed

### TERMINAL LAYOUT





# DISTANCE SENSOR

< ECU DIAGNOSIS INFORMATION >

[DRIVER ASSISTANCE SYSTEM]

## PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Standard value	Reference value
+	-	Signal name	Input/ Output			
1 (P)	Ground	Ignition power supply	Input	Ignition switch ON	10 - 16 V	Battery voltage
6 (R)		CAN communication-L	—	—	—	—
7 (L)		CAN communication-H	—	—	—	—
8 (B)		Ground	—	—	Ignition switch ON	0 - 0.1 V

### Fail-safe (Distance Sensor)

INFOID:000000010227222

If a malfunction occurs in the distance sensor, around view monitor control unit cancels control, sounds a beep, and turns ON the FCW system warning in the information display.

### DTC Inspection Priority Chart

INFOID:000000010227223

If multiple DTCs are detected simultaneously, check them one by one depending on the following DTC inspection priority chart.

Priority	Detected items (DTC)
1	<ul style="list-style-type: none"> <li>• U1000: CAN COMM CIRCUIT</li> <li>• U1010: CONTROL UNIT (CAN)</li> </ul>
2	<ul style="list-style-type: none"> <li>• C1A50: ADAS MALFUNCTION</li> </ul>
3	<ul style="list-style-type: none"> <li>• C1A01: POWER SUPPLY CIR</li> <li>• C1A02: POWER SUPPLY CIR 2</li> <li>• C1A12: RADAR OFF-CENTER</li> <li>• C1A16: RADAR BLOCKED</li> <li>• C1A21: UNIT HIGH TEMP</li> <li>• C1A23: UNIT LOW TEMP</li> <li>• C1A39: STRG SEN CIR</li> <li>• U0104: ADAS CAN CIR1</li> <li>• U0121: VDC CAN CIR2</li> <li>• U0126: STRG SEN CAN CIR1</li> <li>• U0405: ADAS CAN CIR2</li> <li>• U0415: VDC CAN CIR1</li> <li>• U0428: STRG SEN CAN CIR2</li> </ul>
4	<ul style="list-style-type: none"> <li>• C1A00: CONTROL UNIT</li> </ul>

### DTC Index

INFOID:000000010227224

×: Applicable

DTC	CONSULT display	Reference
CONSULT		
C1A01	POWER SUPPLY CIR	<a href="#">DAS-130</a>
C1A02	POWER SUPPLY CIR2	<a href="#">DAS-130</a>
C1A12	RADAR OFF-CENTER	<a href="#">DAS-134</a>
C1A16	RADAR BLOCKED	<a href="#">DAS-137</a>
C1A18	RADAR ALIGNMENT INCMP	<a href="#">DAS-139</a>
C1A21	UNIT HIGH TEMP	<a href="#">DAS-140</a>
C1A39	STRG SEN CIR	<a href="#">DAS-142</a>

# DISTANCE SENSOR

< ECU DIAGNOSIS INFORMATION >

[DRIVER ASSISTANCE SYSTEM]

DTC	CONSULT display	Reference
CONSULT		
U1000	CAN COMM CIRCUIT	<a href="#">DAS-106</a>
U1010	CONTROL UNIT (CAN)	<a href="#">DAS-107</a>
U0121	VDC CAN CIR2	<a href="#">DAS-99</a>
U0126	STRG MSG COUNTER	<a href="#">DAS-101</a>
U0415	VDC CAN CIR1	<a href="#">DAS-103</a>
U0428	STRG SEN CAN CIR2	<a href="#">DAS-105</a>
U0401	ECM MSG COUNTER	<a href="#">DAS-102</a>
C1A03	VHCL SPEED SE CIRC	<a href="#">DAS-131</a>
C1A04	ABS/TCS/VDC CIRC	<a href="#">DAS-132</a>
C1A05	BRAKE SW/STOP L SW	<a href="#">DAS-133</a>
C10B7	YAW RATE SENSOR	<a href="#">DAS-129</a>
C1A14	ECM CIRCUIT	<a href="#">DAS-135</a>
C1A15	GEAR POSITION	<a href="#">DAS-136</a>
C1A24	NP RANGE	<a href="#">DAS-141</a>
C1A17	RADAR SENSOR FAIL	<a href="#">DAS-141</a>

# REAR VIEW CAMERA WASHER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >


[DRIVER ASSISTANCE SYSTEM]

## REAR VIEW CAMERA WASHER CONTROL UNIT

Reference Value

INFOID:000000010275762

TERMINAL LAYOUT



PHYSICAL VALUES



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# REAR VIEW CAMERA WASHER CONTROL UNIT

< ECU DIAGNOSIS INFORMATION >

[DRIVER ASSISTANCE SYSTEM]

Terminal (Wire color)		Description		Condition	Standard value	Reference value (Approx.)	
+	-	Signal name	Input/ Output				
1 (SB)	Ground	Air pump power supply	Output	Ignition switch ON	Air pump operated	9.5 - 16 V	Battery voltage
					Air pump not operated	0 - 0.1 V	0 V
2 (LG)		Air pump ground	—	Ignition switch ON	—	0 - 0.1 V	0 V
3 (GR)		Washer motor ground	—	—	—	0 - 0.1 V	0 V
4 (Y)		Washer motor power supply	Output	Ignition switch ON	Rear view camera washer motor operated	0 - 0.1 V	0 V
					Rear view camera washer motor not operated	9.5 - 16 V	Battery voltage
5 (B)		Ground	—	Ignition switch ON	—	0 - 0.1 V	0 V
6 (V)		Communication line ground	—	Ignition switch ON	—	0 - 0.1 V	0 V
7 (L)		Communication line (PUMP → CAMERA)	Output	Ignition switch ON	—	Input the waveform synchronized with the communication status. 	
8 (BR)		Communication line (CAMERA → PUMP)	Input	Ignition switch ON	—	Input the waveform synchronized with the communication status. 	
12 (LG)	Ignition power supply	Input	Ignition switch ON	—	9.5 - 16 V	Battery voltage	


< WIRING DIAGRAM >

# WIRING DIAGRAM

## DRIVER ASSISTANCE SYSTEMS

### Wiring Diagram

INFOID:000000010227247



AAOWA0029GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P


DAS

# DRIVER ASSISTANCE SYSTEMS

## [DRIVER ASSISTANCE SYSTEM]

< WIRING DIAGRAM >


- OB: WITHOUT BOSE AUDIO SYSTEM
- WB: WITH BOSE AUDIO SYSTEM
- YG: WITH FORWARD COLLISION WARNING SYSTEM



AAOWA0030GB


DRIVER ASSISTANCE SYSTEM CONNECTORS

Connector No.	M9
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	W	-
4	B	-
12	SB	-
13	BR	-

Connector No.	M18
Connector Name	BODY CONTROL MODULE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
5	R	CAN-L
6	L	CAN-H
8	L	CAN-L
9	R	CAN-H

Connector No.	M27
Connector Name	JOINT CONNECTOR-M13
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	SB	-
3	SB	-
5	P	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
22J	SHIELD	-
23J	LG	-
24J	V	-
25J	L	-
33J	R	-
34J	L	-
44J	B	-
45J	P	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7P	Y	-



AAOIA0129GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P



DAS

# DRIVER ASSISTANCE SYSTEMS

## [DRIVER ASSISTANCE SYSTEM]



< WIRING DIAGRAM >

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13	LG	-
14	V	-
15	SB	-
16	Y	-
29	SHIELD	-
30	W	-
31	B	-
32	R	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN

Terminal No.	Color of Wire	Signal Name
3R	V	-
5R	L	-

Connector No.	M65
Connector Name	JOINT CONNECTOR-M26
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	B	-
8	B	-

Connector No.	M97
Connector Name	JOINT CONNECTOR-M24
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
4	B	-
5	B	-
6	B	-

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	GR	-
7	B	-
8	L	-
9	Y	-
10	SHIELD	-
11	G	-

Connector No.	M71
Connector Name	JOINT CONNECTOR-M03
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	L	-
5	L	-
7	L	-
11	R	-
12	R	-
13	R	-
15	R	-
17	R	-

AAOIA0130GB




# DRIVER ASSISTANCE SYSTEMS

## [DRIVER ASSISTANCE SYSTEM]


< WIRING DIAGRAM >

Connector No.	M108
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	R	CAN-L

Connector No.	M102
Connector Name	AV CONTROL UNIT (WITHOUT BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
41	G	CAMERA+
42	SHIELD	CAMERA-(SHIELD)


Connector No.	M101
Connector Name	AV CONTROL UNIT (WITHOUT BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
8	L	CAN-H
17	R	CAN-L


Terminal No.	Color of Wire	Signal Name
17	W	ITS SW
27	L	CAN-H
28	R	CAN-L
36	Y	FROM C/U TO PUMP
37	V	SIGNAL GND
38	SB	FROM PUMP TO C/U

Connector No.	M113
Connector Name	AROUND VIEW MONITOR CONTROL UNIT (WITH DRIVER ASSISTANCE SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	GND
2	Y	+B
3	SB	IGN
7	R	INDICATOR L
8	G	INDICATOR R
15	BR	ITS SW INDICATOR
16	Y	BUZZER CONT

Connector No.	M109
Connector Name	AV CONTROL UNIT (WITH BOSE AUDIO SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
41	G	CAMERA+
42	SHIELD	CAMERA-(SHIELD)

AAOIA0131GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P


DAS

# DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[DRIVER ASSISTANCE SYSTEM]


Connector No.	M120
Connector Name	WARNING SYSTEM BUZZER
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	Y	-
3	B	-


Terminal No.	Color of Wire	Signal Name
59	G	SV2 VIDEO SIGNAL
60	SHIELD	SV2 VIDEO GND
62	B	SV1 POWER 6.2V
64	L	SV1 POWER GND
65	Y	SV1 VIDEO SIGNAL
66	SHIELD	SV1 VIDEO GND
68	L	FV POWER 6.2V
70	V	FV POWER GND
71	LG	FV VIDEO SIGNAL
72	SHIELD	FV VIDEO GND

Connector No.	M114
Connector Name	AROUND VIEW MONITOR CONTROL UNIT (WITH DRIVER ASSISTANCE SYSTEM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
47	G	VIDEO OUTPUT SIGNAL
48	SHIELD	VIDEO OUTPUT GND
49	LG	RV SERIAL SIGNAL
50	R	RV POWER 6.2V
52	B	RV POWER GND
53	W	RV VIDEO SIGNAL
54	SHIELD	RV VIDEO GND
56	L	SV2 POWER 6.2V
58	Y	SV2 POWER GND

Connector No.	M251
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	W	-
4	B	-
12	BG	-
13	BR	-

Connector No.	M168
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	L	-
8	Y	-
9	G	-
10	SHIELD	-
11	R	-

Connector No.	M167
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	B	-


AAOIA0132GB

# DRIVER ASSISTANCE SYSTEMS

## [DRIVER ASSISTANCE SYSTEM]


< WIRING DIAGRAM >

Connector No.	M253
Connector Name	WARNING SYSTEM SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	BR	-
5	BG	-
6	W	-
8	B	-

Connector No.	E21
Connector Name	DISTANCE SENSOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	P	IGN
6	R	CAN-L
7	L	CAN-H
8	B	GND

Connector No.	E26
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	V	-
2	L	-
13	SHIELD	-
14	LG	-

Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
10M	L	-

Connector No.	E34
Connector Name	WIRE TO WIRE
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
6A	L	-
7A	R	-
8A	GR	-

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P




# DRIVER ASSISTANCE SYSTEMS

< WIRING DIAGRAM >

[DRIVER ASSISTANCE SYSTEM]

Terminal No.	Color of Wire	Signal Name
22J	SHIELD	-
23J	LG	-
24J	V	-
25J	L	-
33J	R	-
34J	L	-
44J	B	-
45J	P	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E55
Connector Name	REAR VIEW CAMERA WASHER MOTOR
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	R	-

Connector No.	E226
Connector Name	FRONT CAMERA
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	V	-
2	L	-
4	LG	-
5	SHIELD	-

Connector No.	E209
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	V	-
2	L	-
13	SHIELD	-
14	LG	-



AAOIA0134GB

# DRIVER ASSISTANCE SYSTEMS

## [DRIVER ASSISTANCE SYSTEM]


< WIRING DIAGRAM >

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE





Terminal No.	Color of Wire	Signal Name
13	W	-
14	V	-
15	L	-
16	BR	-
29	SHIELD	-
30	W	-
31	B	-
32	R	-

Terminal No.	Color of Wire	Signal Name
6A	LG	-
7A	Y	-
8A	GR	-





Connector No.	B40
Connector Name	WIRE TO WIRE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
4	Y	CAMERA -
5	B	GND
6	V	SIGNAL GND
7	L	FROM PUMP TO CAMERA C/U
8	BR	FRONT CAMERA C/U TO PUMP
12	LG	IGN

Connector No.	B67
Connector Name	REAR VIEW CAMERA WASHER CONTROL UNIT
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	SB	PUMP MOTOR +
2	LG	PUMP MOTOR -
3	GR	CAMERA WASHER +

Connector No.	B46
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
4	W	-
5	R	-
6	B	-
7	W	-
8	SHIELD	-

AAOIA0135GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P


DAS

# DRIVER ASSISTANCE SYSTEMS

## [DRIVER ASSISTANCE SYSTEM]


< WIRING DIAGRAM >

Connector No.	D3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	GR	-
8	G	-
9	Y	-
10	B	-
11	R	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
5	B	-

Connector No.	B72
Connector Name	REAR VIEW CAMERA AIR PUMP MOTOR
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	LG	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	B	-
7	L	-
8	V	-
9	Y	-
10	B	-
11	G	-

Connector No.	D14
Connector Name	DOOR MIRROR LH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	GR	-
8	G	-
15	B	-
16	Y	-

Connector No.	D5
Connector Name	BLIND SPOT WARNING INDICATOR LH/BLIND SPOT INTERVENTION
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	R	-
4	B	-



AAOIA0136GB

# DRIVER ASSISTANCE SYSTEMS

## [DRIVER ASSISTANCE SYSTEM]



< WIRING DIAGRAM >

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	L	-
5	R	-
6	B	-
7	W	-
8	V	-

Connector No.	D108
Connector Name	BLIND SPOT WARNING/BLIND SPOT INTERVENTION INDICATOR RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	G	-
4	B	-

Connector No.	D107
Connector Name	DOOR MIRROR RH
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
7	L	-
8	V	-
15	B	-
16	Y	-

Connector No.	D514
Connector Name	REAR VIEW CAMERA
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	V	-
4	L	-
5	W	-
7	B	-
8	R	-

AAOIA0137GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000010227248

#### OVERALL SEQUENCE



#### DETAILED FLOW

### 1. INTERVIEW FOR MALFUNCTION

It is also important to clarify the customer concerns before starting the inspection. Interview the customer about the concerns carefully and understand the symptoms fully.



# DIAGNOSIS AND REPAIR WORK FLOW

[DRIVER ASSISTANCE SYSTEM]

< BASIC INSPECTION >

## NOTE:

The customers are not professionals. Never assume that “maybe the customer means…” or “maybe the customer mentioned this symptom”.

>> GO TO 2.

## 2.SELF-DIAGNOSIS WITH CONSULT

1. Perform “All DTC Reading” with CONSULT.
2. Check if the DTC is detected on the “Self-Diagnostic Results” of following:
  - “DISTANCE SENSOR”
  - “AROUND VIEW MONITOR”

Is any DTC detected?

- YES >> GO TO 5.  
NO >> GO TO 3.

## 3.ACTION TEST

Perform the following system action test to check the system operation:

- LDW refer to [DAS-80. "LDW : Description"](#).
- BSW refer to [DAS-81. "BSW : Description"](#).
- MOD refer to [DAS-82. "MOD : Description"](#).

Check if any other malfunctions occur.

>> GO TO 4.

## 4.SYMPTOM DIAGNOSIS

Perform the applicable diagnosis according to the diagnosis chart by symptom. Refer to [DAS-152. "Symptom Table"](#).

>> GO TO 6.

## 5.TROUBLE DIAGNOSIS BY DTC

1. Check the DTC in the “Self-Diagnostic Results”.
2. Perform trouble diagnosis for the detected DTC following:
  - “DISTANCE SENSOR”: Refer to [DAS-49. "DTC Index"](#).
  - “AROUND VIEW MONITOR”: Refer to [DAS-47. "DTC Index"](#).

>> GO TO 6.

## 6.MALFUNCTIONING PART REPAIR

Repair or replace the identified malfunctioning parts.

>> GO TO 7.

## 7.REPAIR CHECK (SELF-DIAGNOSIS WITH CONSULT)

1. Erases self-diagnosis results.
2. Perform “All DTC Reading” again after repairing or replacing the specific items.
3. Check if any DTC is detected in self-diagnosis results of following:
  - “DISTANCE SENSOR”
  - “AROUND VIEW MONITOR”

Is any DTC detected?

- YES >> GO TO 5.  
NO >> GO TO 8.

## 8.REPAIR CHECK (ACTION TEST)

Perform the following system action test. Check that the malfunction symptom is solved or no other symptoms occur.

Is there a malfunction symptom?

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

## DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

---

YES >> GO TO 4.

NO >> Inspection End.

# PRE-INSPECTION FOR DIAGNOSIS

[DRIVER ASSISTANCE SYSTEM]

< BASIC INSPECTION >

## PRE-INSPECTION FOR DIAGNOSIS

### Inspection Procedure

INFOID:000000010284235

#### 1. CHECK REAR VIEW CAMERA LENS

Is the rear view camera lens contaminated with foreign materials?

YES >> Clean rear view camera lens.

NO >> GO TO 2.

#### 2. CHECK REAR VIEW CAMERA INSTALLATION CONDITION

Check rear view camera installation condition (e.g. position, looseness, bent in back door).

Is it properly installed?

YES >> Inspection End.

NO >> Install rear view camera properly, and perform rear view camera calibration. Refer to [DAS-89](#), "[Description](#)".

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# REAR VIEW CAMERA WASHER/AIR BLOWER FUNCTION INSPECTION

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

---

## REAR VIEW CAMERA WASHER/AIR BLOWER FUNCTION INSPECTION

### Inspection Procedure

INFOID:000000010284236

#### 1. CHECK REAR VIEW CAMERA WASHER/AIR BLOWER FUNCTION

---

1. Start the engine.
2. Select the "Active Test" item "AIR&WASH ACTIVE" of "AVM" with CONSULT.

**NOTE:**

Before function check, perform the following items:

- Fill with washer fluid.
- Perform "Active Test" item "WASH ACTIVE" of "AVM" with CONSULT for 4 seconds.

3. While operating the test item, check the operation.

#### Is it properly operated?

Washer fluid ejects 4 - 6 times. (Normal function)>>Inspection End.

Washer fluid ejects 7 times or more.>>Properly install or replace air tube.

Washer fluid ejects only once>> Properly install or replace air tube.

Washer fluid does not eject>>Properly install washer tube or replace washer tube and check valve.

# ADDITIONAL SERVICE WHEN REPLACING DISTANCE SENSOR

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

## ADDITIONAL SERVICE WHEN REPLACING DISTANCE SENSOR

### Description

INFOID:0000000010227249

Always perform the following after removing and installing or replacing the Distance sensor:

- Distance sensor initial vertical alignment
- Distance sensor alignment

• **CAUTION:**

**The system does not operate normally unless the Distance sensor is aligned properly.**

### Work Procedure

INFOID:0000000010227250

#### 1. DISTANCE SENSOR INITIAL VERTICAL ALIGNMENT

Perform the distance sensor initial vertical alignment. Refer to [DAS-70, "Description"](#).

>> GO TO 2.

#### 2. DISTANCE SENSOR ALIGNMENT

Perform the distance sensor alignment. Refer to [DAS-72, "Description"](#).

>> Work End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# DISTANCE SENSOR INITIAL VERTICAL ALIGNMENT

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

## DISTANCE SENSOR INITIAL VERTICAL ALIGNMENT

### Description

INFOID:000000010250289

#### **WARNING:**

Radio waves could adversely affect electric medical equipment. Those who use a pacemaker should contact the electric medical equipment manufacturer for the possible influences before use.

#### OUTLINE OF DISTANCE SENSOR INITIAL ALIGNMENT PROCEDURE

- Always perform the Distance sensor initial vertical alignment after removing and installing or replacing the Distance sensor.

#### **CAUTION:**

The system does not operate normally unless the Distance sensor is aligned properly.

1. Required tools, refer to [DAS-70, "Required Tools"](#).
2. Preparation, refer to [DAS-70, "Preparation"](#).
3. Distance sensor initial vertical alignment, refer to [DAS-71, "Distance Sensor Initial Vertical Alignment"](#).

#### CAUTIONARY POINT FOR DISTANCE SENSOR ALIGNMENT PROCEDURE

#### **CAUTION:**

- For Distance sensor alignment procedure, choose a level location with a few feet of working space in front and surrounding the vehicle.
- Vehicle must be stationary and unoccupied during the whole alignment procedure.
- Never enter the vehicle during distance sensor alignment.
- For proper system operation and adjustment, all vehicle wheels must be the original factory size.


The Distance sensor requires alignment whenever the Distance sensor is removed and reinstalled and whenever front end structural repairs are performed. Distance sensor alignment consists of performing the mechanical vertical alignment (Distance sensor initial vertical alignment) described in the following procedure, followed by the electronic horizontal alignment (Distance sensor alignment) that is performed using CONSULT and the appropriate special service tools.

### Required Tools

INFOID:000000010250290

The following tool is necessary to perform the Distance sensor initial vertical alignment:

- Carpenters level.



### Preparation

INFOID:000000010250291

#### 1. PREPARATION FOR DISTANCE SENSOR INITIAL VERTICAL ALIGNMENT PROCEDURE

1. Verify correct vehicle suspension height. Refer to [WT-65, "Wheel"](#).
2. Repair or replace any damaged body components.
3. Verify proper tire inflation pressures. Refer to [WT-65, "Tire Air Pressure"](#).
4. Remove any accumulations of mud, snow or ice from the vehicle underbody.
5. Verify that there is no load in the vehicle (cargo or passenger).
6. Place the vehicle on a known level horizontal surface such as a wheel or frame alignment rack to achieve satisfactory sensor vertical alignment results.
7. Remove front fascia. Refer to [EXT-17, "Removal and Installation"](#).

# DISTANCE SENSOR INITIAL VERTICAL ALIGNMENT

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

>> Refer to [DAS-71, "Distance Sensor Initial Vertical Alignment"](#).


## Distance Sensor Initial Vertical Alignment

INFOID:000000010250292


### NOTE:

The Distance sensor initial vertical alignment procedure must be performed anytime the Distance sensor is removed and reinstalled.


1. The Distance sensor (1) is located near the right front head lamp behind the front bumper fascia.



2. Place the carpenter's level (2) against the face of the Distance sensor (1).



3. Turn the Distance sensor adjustment screw (3) to level the sensor.



4. Insure the Distance sensor electrical connector located on the bottom of the sensor is connected.
5. Reinstall the front bumper fascia.
6. Perform the Distance sensor alignment procedure. Refer to [DAS-72, "Description"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# DISTANCE SENSOR ALIGNMENT

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

## DISTANCE SENSOR ALIGNMENT

### Description

INFOID:000000010250293

#### **WARNING:**

Radio waves could adversely affect electric medical equipment. Those who use a pacemaker should contact the electric medical equipment manufacturer for the possible influences before use.

#### OUTLINE OF RADAR ALIGNMENT PROCEDURE

- A 4-wheel vehicle alignment must be performed before proceeding with radar alignment procedure.
- Always perform the radar alignment after removing and installing or replacing the Distance sensor.
- If the Distance sensor was removed and installed or replaced, first perform Distance Sensor Initial Vertical Alignment, refer to [DAS-70. "Description"](#).

#### **CAUTION:**

The system does not operate normally unless the Distance sensor is aligned properly.

1. Required tools, refer to [DAS-72. "Required Tools"](#).
2. Preparation, refer to [DAS-74. "Preparation"](#).
3. Vehicle set up, refer to [DAS-74. "Vehicle Set Up"](#).
4. Setting the Distance sensor target board, refer to [DAS-76. "Setting The Distance Sensor Target Board"](#).
5. Distance sensor adjustment, refer to [DAS-77. "Distance Sensor Adjustment"](#).

#### CAUTIONARY POINT FOR RADAR ALIGNMENT PROCEDURE

#### **CAUTION:**

- For radar alignment procedure, choose a level location with a few feet of working space in front and surrounding the vehicle.
- Vehicle must be stationary and unoccupied during the whole alignment procedure.
- Any slight vibration during the alignment procedure can cause the test to fail. If this happens, you will have to restart the alignment process.
- The ignition switch must be in the ON position.
- The battery voltage must not fall below 12 volts during the whole alignment procedure. Failure to maintain adequate battery voltage will cause the test to fail. If this happens, you will have to restart the alignment process.
- The Distance sensor target board must be set in front of the vehicle facing the sensor.
- Adjust the radar alignment with CONSULT. (The radar alignment procedure cannot be adjusted without CONSULT.)
- Never enter the vehicle during radar alignment.
- Never block the area between the radar and the Distance sensor target board at any time during the alignment process.
- Never break the laser beam between the laser assembly and front Distance sensor target board or rear reflector at any time during alignment.
- Accurate steering wheel setting is crucial. Once set, do not disturb the steering wheel for the remainder of the alignment procedure.
- To avoid physical damage, the Distance sensor adjustment screw must not be forced to either clockwise or counter-clockwise limit. For proper adjustment procedure, follow the directions of the CONSULT exactly as instructed.
- For proper system operation and adjustment, all vehicle wheels must be of the same size.

### Required Tools

INFOID:000000010250294

- Distance sensor alignment kit 1-20-2721-1-IF in addition to one of the following:
  - a) Hunter self-centering wheel adapter (Hunter wheel alignment tool)
  - b) Special Service Tool kit 1-20-2722-1-IF (kit SCA W/Tire Clamp-ICC Aiming)
- Distance sensor alignment kit attachment board J-50808

The following Distance sensor alignment kit (1-20-2721-1-IF) and Distance sensor alignment kit attachment board (target board) (J-50808) are necessary to perform the Distance sensor alignment:




# DISTANCE SENSOR ALIGNMENT


## [DRIVER ASSISTANCE SYSTEM]

### < BASIC INSPECTION >

- Distance sensor alignment kit attachment board (target board) (1).




- Distance sensor target board (1).



- Hunter self-centering wheel adapter (1) [shown with laser assembly (2) installed] (Hunter alignment rack head may be substituted).


**NOTE:**

Dealers that are not equipped with a Hunter self-centering wheel adapter will require the following kit:  
Part No. 1-20-2722-1-IF (kit SCA W/Tire Clamp-Distance Sensor Aiming)



- Laser assembly (with bi-directional laser beam) as shown in the illustration.

- Tightening knob (1)
- Power ON/OFF button (2)
- Front laser beam opening (3)
- Rear laser beam opening (4)
- Attaching shaft (5)



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P


DAS

# DISTANCE SENSOR ALIGNMENT

[DRIVER ASSISTANCE SYSTEM]

## < BASIC INSPECTION >

- Stationary target as shown in the illustration.
- Stationary target (1)
- Laser signal reception plate (2)



- Distance chain (not shown).

## Preparation

INFOID:0000000010250295

### 1. ADVANCE PREPARATION FOR RADAR ALIGNMENT PROCEDURE


1. Adjust all tire pressures to the specified value.
2. Empty the vehicle. (Remove any luggage from the passenger compartment, luggage room, etc.)
3. Shift the selector lever to "P" position, and release the parking brake.
4. Fully fill the fuel tank, and then check that the coolant and oils are filled up to correct level.
5. Clean off the right front side of the fascia in front of the Distance sensor.

#### NOTE:

The Distance sensor is located behind the fascia and it is not exposed to the elements. Therefore it should not require any cleaning.

1 : Distance sensor

>> Refer to [DAS-74. "Vehicle Set Up"](#).



## Vehicle Set Up

INFOID:0000000010250296

### DESCRIPTION

Accurate adjustment of the radar alignment requires that the Distance sensor target board, wheel adapter, laser assembly, and stationary target be properly positioned.

#### CAUTION:


If the radar alignment is adjusted with the Distance sensor target board, wheel adapter, laser assembly, or stationary target in the incorrect position, the Distance system will not function properly or the alignment procedure may not be completed successfully.

### 1. PREPOSITION TARGET BOARD

#### NOTE:

- The center of the distance sensor (A).

B : Up-down direction adjusting screw




# DISTANCE SENSOR ALIGNMENT

< BASIC INSPECTION >


[DRIVER ASSISTANCE SYSTEM]

- To locate the center of the distance sensor (A) easily, on a flat level surface measure 27 in (685 mm) (H) up from the floor, and 7 in (178 mm) (W) to the right from the point of the right front head lamp (1) when viewed from the front of the vehicle.




- Initial distance sensor target board setting must be in the center position.

- Position the distance sensor target board in front facing the right front side of the vehicle:
  - Using the full length of the supplied chain for distance, place the marked center of the distance sensor target board (1) 1375 mm (54.1 in.)  $\pm$  625 mm (24.6 in) facing the distance sensor.
  - Adjust the height of the distance sensor target board using the adjustable nut (2) to achieve the proper height. The up/down tolerance is  $\pm$  80 mm (3.15 in).
  - Adjust the distance sensor target board lateral position aligning the marked center of the board horizontally with the center of the distance sensor front. The right/left tolerance is  $\pm$  80 mm (3.15 in).



- Extend the machined arm of the distance sensor target board exposing the reflective surface (3) to the right front side of the vehicle.
- Place one side of the laser assembly (2) flush against the center of the distance sensor target board (1) to assist in the positioning.



- Turn the laser assembly ON (3) allowing the laser beam to emit through the opening of the laser assembly toward the center of the distance sensor.
- Move the distance sensor target board (1) as necessary so that center of distance sensor target board aligns with center of distance sensor.
- Turn the laser assembly OFF when done.

## Are you using Hunter alignment equipment?

YES >> Refer to Hunter's equipment instructions for complete vehicle set up and distance sensor target board setting. Then, refer to [DAS-77, "Distance Sensor Adjustment"](#).

NO >> GO TO 2.

## 2. INSTALLING LASER ASSEMBLY

### NOTE:

- Insure the steering wheel is positioned in the center straight forward position.
- Insure all 4 vehicle wheels do not contain any physical damage.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# DISTANCE SENSOR ALIGNMENT

[DRIVER ASSISTANCE SYSTEM]


## < BASIC INSPECTION >

1. Install the wheel adapter (1) on the right front wheel.
2. Mount the laser assembly (2) to the wheel adapter (1) as shown in the figure.

**NOTE:**


When the power switch is turned ON, the front laser signal (A) will be emitted toward the front distance sensor target board, and the rear laser signal (B) will be emitted toward the rear of the vehicle.

>> GO TO 3.



## 3. SETTING UP STATIONARY TARGET

1. Place the stationary target next to the right rear tire as shown in the figure.
2. Turn the laser assembly ON allowing the laser beam to be emitted through the front and rear laser assembly openings.
3. Measure and record the distance ( $D_r$ ) between the edge of the right rear wheel and the laser beam (1) on the stationary target (horizontal line).
4. Measure and record the height ( $H_r$ ) between the laser beam (1) on the stationary target and ground level (vertical line).



5. Measure and record the distance ( $D_f$ ) between the edge of the right front wheel and the laser beam signal/opening (1) on the laser assembly (horizontal line).
6. Measure and record the height ( $H_f$ ) between the laser beam signal/opening (1) on the laser assembly and ground level (vertical line).

**NOTE:**


- Horizontal adjustment [front distance ( $D_f$ ) and rear distance ( $D_r$ )] is accomplished by slowly turning the steering wheel until the 2 distances are the same.
- Vertical adjustment [front height ( $H_f$ ) and rear height ( $H_r$ )] is accomplished by rotating the laser assembly around its axis until the two heights are the same.
- Directional arrows (A) and (B) are shown to illustrate the direction of the laser assembly beams.

7. Adjust laser beam as necessary until the two distances match and the two heights match.

**NOTE:**

You will have to verify both horizontal and vertical adjustments anytime one adjustment is made.

>> Refer to [DAS-76, "Setting The Distance Sensor Target Board"](#).



## Setting The Distance Sensor Target Board

INFOID:000000010250297

### DESCRIPTION

Accurate adjustment of the radar alignment requires that the distance sensor target board be accurately positioned.

**CAUTION:**

If the radar alignment is adjusted with the distance sensor target board in the incorrect position, the distance system will not function properly or the alignment procedure may not be completed successfully.

### 1. DISTANCE SENSOR TARGET BOARD FINAL SETTING

# DISTANCE SENSOR ALIGNMENT

[DRIVER ASSISTANCE SYSTEM]


## < BASIC INSPECTION >

1. With the distance sensor target board arm extended, the laser beam (1) emitted by the laser assembly (A) will be reflected back (B) toward the laser assembly.


**NOTE:**

When adjusted properly, reflected laser beam (B) must align with emitted laser beam (A) and the two laser beams will be seen as one.

2. Rotate the distance sensor target board to achieve the necessary horizontal adjustment.
3. Adjust the distance sensor target board leveling screws to achieve the necessary vertical adjustment.




4. The figure shown illustrates the laser beam (A) emitted by the laser assembly (1) and its reflection (B) off of the distance sensor target board arm.



>> GO TO 2.

## 2. CHECK THE POSITION OF THE DISTANCE SENSOR TARGET BOARD

Do not place anything other than the distance sensor target board in the space shown in front of the vehicle (view from top).



- |   |  |  |
|---|--|--|
| 1. Distance sensor target board arm                     | 2. Distance sensor target board                          | 3. Distance sensor   |
| 4. Vehicle  | A. Distance between front wheel and laser beam ( $D_f$ ) | B. Distance between rear wheel and laser beam ( $D_r$ )      |
| C. Height between front laser beam and ground ( $H_f$ ) | D. Height between rear laser beam and ground ( $H_r$ )   | E. Distance sensor target board center position (Position 2) |
| L. 750 - 2000 mm (29.5 - 78.7 in)                       |  |  |

>> Refer to [DAS-77, "Distance Sensor Adjustment"](#).

## Distance Sensor Adjustment

INFOID:0000000010250298

### DESCRIPTION

The radar alignment is performed automatically with CONSULT.

**CAUTION:**

Perform all necessary work for radar alignment until the adjustment completes as shown in the procedure. If the procedure does not complete, the FCW system is inoperable.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# DISTANCE SENSOR ALIGNMENT

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

## 1. PERFORM RADAR ALIGNMENT

1. Start the engine.
2. Connect CONSULT and select “Work support” of “LASER/RADAR”.
3. Select “MILLIWAVE RADAR ADJUST” after the “Work support” screen is displayed.

**NOTE:**

- Confirm the following items;
- The target should be accurately placed.
  - The vehicle should be stopped.

4. Select “Start” after the “MILLIWAVE RADAR ADJUST” screen is displayed.

**CAUTION:**

**Never select “Start” when the target is not accurately placed.**

5. Select “Start” after the preparation information is displayed.
6. Select “Next” after the “Starting alignment.” screen is displayed.

**NOTE:**

If the radar is in alignment at this time, “Alignment in progress” is displayed. It may take several 10s of seconds until the result is displayed.

7. Confirm the displayed item.
  - “Alignment completed.”: Go to 8.
  - Except “Alignment completed.”: Perform the following services.

Displayed item	Possible cause	Service procedure
Alignment condition is not ready.	<ul style="list-style-type: none"> <li>• DTC is detected (Except C1A12).</li> <li>• The position of the Distance sensor target board is not correct.</li> <li>• Vehicle is moving.</li> </ul>	Check the vehicle condition and perform radar alignment again.
Alignment condition is not ready. (Stop the vehicle.)	Vehicle is moving.	Stop the vehicle and perform radar alignment again.
Target is not detected.	<ul style="list-style-type: none"> <li>• A target is not-yet-placed. (The Distance sensor cannot detect target)</li> <li>• The position of the Distance sensor target board is not correct.</li> <li>• The position of the Distance sensor is not correct.</li> </ul>	Check the target board condition and perform radar alignment again.
Sensor malfunction.	Distance sensor malfunction.	Check the vehicle condition and perform radar alignment again.

**NOTE:**

Replace Distance sensor if “Sensor malfunction.” is repeatedly indicated.

8. Confirm displayed value.

Displayed item	Monitor item	Reference value
Alignment completed.	FACTORY AIM L/R	Less than 3.00 deg
	FACTORY AIM U/D	Less than 3.00 deg
	AIMING VALUE L/R	Less than 3.00 deg
	AIMING VALUE U/D	Less than 3.00 deg

- Within reference value: Go to 9.
- Outside of reference value: Check the target board condition and perform radar alignment again.

**NOTE:**

- Check the condition of the Distance sensor installation.
- Check the vehicle for damage.
- Replace Distance sensor if it is outside the reference value, even when Distance sensor installation is installed normally and the vehicle is not damaged.

9. Select “OK” after the “No error detected.” is displayed.
10. Select “OK” after the “End of alignment.” is displayed.

**CAUTION:**

**Once “MILLIWAVE RADAR ADJUST” is started with CONSULT, always continue the work until the horizontal radar alignment is completed successfully. If the job is stopped midway, the radar alignment is not adjusted and the FCW system cannot operate.**

# DISTANCE SENSOR ALIGNMENT

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

---

>> RADAR ALIGNMENT END

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

## ACTION TEST

## LDW

## LDW : Description

INFOID:000000010282430

- Perform action test to verify the customer's concern.
- Perform action test and check the system operation after system diagnosis.

**WARNING:**

Be careful of traffic conditions and safety around the vehicle when performing road test.

**CAUTION:**

- Fully understand the following items well before the road test;
  - Precautions: Refer to [DAS-9, "Precautions for Driver Assistance Systems"](#).
  - System description for LDW: Refer to [DAS-16, "LDW : System Description"](#).
  - System description for BSW: Refer to [DAS-20, "BSW : System Description"](#).
  - System description for MOD: Refer to [DAS-26, "MOD : System Description"](#).
  - Handling precaution: Refer to [DAS-36, "Precautions for Lane Departure Warning"](#).

## LDW : Inspection Procedure

INFOID:000000010282431

**WARNING:**

Be careful of traffic conditions and safety around the vehicle when performing road test.

**CAUTION:**

- Fully understand the following items well before the road test;
  - Precautions: Refer to [DAS-9, "Precautions for Driver Assistance Systems"](#).
  - System description for LDW: Refer to [DAS-16, "LDW : System Description"](#).
  - System description for BSW: Refer to [DAS-20, "BSW : System Description"](#).
  - System description for MOD: Refer to [DAS-26, "MOD : System Description"](#).
  - Handling precaution: Refer to [DAS-36, "Precautions for Lane Departure Warning"](#).

**1.** CHECK LDW SYSTEM SETTING

1. Start the engine.
2. Check that the LDW system setting can be enabled/disabled on the vehicle information display.
3. Turn OFF the ignition switch and wait for 30 seconds or more.
4. Check that the previous setting is saved when the engine starts again.

>> GO TO 2.

**2.** ACTION TEST FOR LDW




1. Enable the setting of the LDW system on the vehicle information display.
2. Turn warning systems switch ON (warning systems ON indicator is ON).
3. Check the LDW operation according to the following table.



# ACTION TEST

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

Vehicle condition/ Driver's operation	Action	Warning systems ON indicator	Indication on the combination meter	Buzzer
Less than Approx. 60 km/h (40 MPH)	Close to lane marker	No action	 White <sub>ALOIA0191GB</sub>	—
Approx. 70 km/h (45 MPH) or more	Close to lane marker	Warning • Buzzer sounds • Warning lamp blinks	 White (Orange) Blink <small>ALOIA0190GB</small>	Short continuous beeps
	<ul style="list-style-type: none"> <li>• Close to lane marker</li> <li>• Turn signal ON (Deviate side)</li> </ul>	No action	 White <sub>ALOIA0191GB</sub>	—

**NOTE:**

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to [DAS-16, "LDW : System Description"](#).

>> Inspection End.

## BSW

### BSW : Description

INFOID:000000010282432

- Perform action test to verify the customer's concern.
- Perform action test and check the system operation after system diagnosis.

**WARNING:**

**Be careful of traffic conditions and safety around the vehicle when performing road test.**

**CAUTION:**

- Fully understand the following items well before the road test;
- Precautions: Refer to [DAS-9, "Precautions for Driver Assistance Systems"](#).
- System description for LDW: Refer to [DAS-20, "BSW : System Description"](#).
- System description for BSW: Refer to [DAS-20, "BSW : System Description"](#).
- System description for MOD: Refer to [DAS-26, "MOD : System Description"](#).
- Handling precaution: Refer to [DAS-37, "Precautions for Blind Spot Warning"](#).

### BSW : Inspection Procedure

INFOID:000000010282433

**WARNING:**

**Be careful of traffic conditions and safety around the vehicle when performing road test.**

**CAUTION:**

- Fully understand the following items well before the road test;
- Precautions: Refer to [DAS-9, "Precautions for Driver Assistance Systems"](#).
- System description for LDW: Refer to [DAS-16, "LDW : System Description"](#).
- System description for BSW: Refer to [DAS-20, "BSW : System Description"](#).
- System description for MOD: Refer to [DAS-26, "MOD : System Description"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P



# ACTION TEST

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

- Handling precaution: Refer to [DAS-37, "Precautions for Blind Spot Warning"](#).

## 1. CHECK BSW SYSTEM SETTING




1. Start the engine.
2. Check that the BSW system setting can be enabled/disabled on the vehicle information display.
3. Turn OFF the ignition switch and wait for 30 seconds or more.
4. Check that the previous setting is saved when the engine starts again.

>> GO TO 2.

## 2. ACTION TEST FOR BSW

1. Enable the setting of the BSW system on the vehicle information display.
2. Turn warning systems switch ON (warning systems ON indicator is ON).
3. Check the BSW operation according to the following table.

Vehicle condition/Driver's operation

Warning systems ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Turn signal condition	Status of vehicle detection within detection area	Indication on the combination meter	Buzzer	
ON	Less than Approx. 29 km/h (18 MPH)	—	—	OFF	OFF	
	Approx. 32 km/h (20 MPH) or more	—	Vehicle is absent	OFF	OFF	
		OFF	Vehicle is detected	ON	ON	Short continuous beeps
		ON (vehicle detected direction)	Before turn signal operates vehicle is detected	Blink		
ON (vehicle detected after turn signal operates)	Vehicle is detected after turn signal operates	Blink		OFF		

**NOTE:**

After the operating conditions of warning are satisfied, the warning continues until the vehicle speed reaches approximately 60 km/h (40 MPH). Refer to [DAS-20, "BSW : System Description"](#).

>> Inspection End.

## MOD

### MOD : Description

INFOID:0000000010282434

- Perform action test to verify the customer's concern.
- Perform action test and check the system operation after system diagnosis.

**WARNING:**

**Be careful of traffic conditions and safety around the vehicle when performing road test.**

**CAUTION:**

- Fully understand the following items well before the road test;
- Precautions: Refer to [DAS-9, "Precautions for Driver Assistance Systems"](#).

# ACTION TEST

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

- System description for LDW: Refer to [DAS-16, "LDW : System Description"](#).
- System description for BSW: Refer to [DAS-20, "BSW : System Description"](#).
- System description for MOD: Refer to [DAS-26, "MOD : System Description"](#).
- Handling precaution: Refer to [DAS-37, "Precautions for Moving Objects Detection"](#).

MOD : Inspection Procedure

INFOID:000000010282435

## WARNING:

Be careful of traffic conditions and safety around the vehicle when performing road test.

## CAUTION:

- Fully understand the following items well before the road test;
- Precautions: Refer to [DAS-9, "Precautions for Driver Assistance Systems"](#).
- System description for LDW: Refer to [DAS-16, "LDW : System Description"](#).
- System description for BSW: Refer to [DAS-20, "BSW : System Description"](#).
- System description for MOD: Refer to [DAS-26, "MOD : System Description"](#).
- Handling precaution: Refer to [DAS-37, "Precautions for Moving Objects Detection"](#).

## 1. CHECK MOD SYSTEM SETTING

1. Start the engine.
2. Check that the MOD system setting can be enabled/disabled on the vehicle information display.
3. Turn OFF the ignition switch and wait for 30 seconds or more.
4. Check that the previous setting is saved when the engine starts again.

>> GO TO 2.

## 2. ACTION TEST FOR MOD

1. Enable the setting of the MOD system on the vehicle information display.
2. Turn warning systems switch ON (warning systems ON indicator is ON).
3. Check the MOD operation according to the following table.

Vehicle condition/ Driver's operation			Vehicle response	
Moving Object De- tection ON indicator	Vehicle speed (Approx.) [km/h (MPH)]	Status of vehicle detection within detection area	Indication on the Moving Object Detection indicator	Buzzer
OFF	—	—	OFF	OFF
Blue	Less than approx. 8 km/h (5 MPH)	Vehicle is detected	ON	ON
		Vehicle is absent	ON	OFF
	Approx. 8 km/h (5 MPH) or more	Vehicle is detected	ON	OFF
Vehicle is not detected		ON	OFF	

## NOTE:

After the operating conditions of warning are satisfied, the warning continues until the vehicle reaches a higher speed. Refer to [DAS-26, "MOD : System Description"](#).

>> Inspection End.

DAS

# ADDITIONAL SERVICE WHEN REPLACING AROUND VIEW MONITOR CONTROL UNIT

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

## ADDITIONAL SERVICE WHEN REPLACING AROUND VIEW MONITOR CONTROL UNIT

### Description

INFOID:000000010284132

#### BEFORE REPLACEMENT

When replacing around view monitor control unit, save or print current vehicle specification with CONSULT configuration before replacement.

#### NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing around view monitor control unit.

#### AFTER REPLACEMENT

#### CAUTION:

When replacing around view monitor control unit, you must perform "After Replace ECU" with CONSULT.

- Complete the procedure of "After Replace ECU" in order.
- If you set incorrect "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.

### Work Procedure

INFOID:000000010284133

#### 1. SAVING VEHICLE SPECIFICATION

##### Ⓜ-CONSULT

Enter "Re/Programming, Configuration" and perform "Before Replace ECU" to save or print current vehicle specification.

#### NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing around view monitor control unit.

>> GO TO 2.

#### 2. REPLACE AROUND VIEW MONITOR CONTROL UNIT

Replace around view monitor control unit. Refer to [DAS-163. "Removal and Installation"](#).

>> GO TO 3.

#### 3. WRITING VEHICLE SPECIFICATION

##### ⓂCONSULT

1. Enter "Re/Programming, Configuration".
2. If "Before Replace ECU" operation was performed, automatically an "Operation Log Selection" screen will be displayed. Select the applicable file from the "Saved Data List" and press "Confirm" to write vehicle specification. Refer to [DAS-86. "Work Procedure"](#).
3. If "Before Replace ECU" operation was not performed, select "After Replace ECU" or "Manual Configuration" to write vehicle specification. Refer to [DAS-86. "Work Procedure"](#).

>> GO TO 4.

#### 4. REAR VIEW CAMERA CALIBRATION

Perform rear view camera calibration. Refer to [DAS-89. "Description"](#).

>> GO TO 5.

#### 5. AROUND VIEW MONITOR CALIBRATION

Perform around view monitor calibration. Refer to [DAS-93. "Description"](#).

>> GO TO 6.

# ADDITIONAL SERVICE WHEN REPLACING AROUND VIEW MONITOR CONTROL UNIT

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

## 6. OPERATION CHECK

Check that the operation of the around view monitor control unit and camera images (fixed guide lines and predictive course lines) are normal.

>> Work End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# CONFIGURATION (AROUND VIEW MONITOR CONTROL UNIT)

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

## CONFIGURATION (AROUND VIEW MONITOR CONTROL UNIT)

### Description

INFOID:0000000010284129

Vehicle specification needs to be written with CONSULT because it is not written after replacing around view monitor control unit.

Configuration has three functions as follows:

Function	Description
"Before Replace ECU"	<ul style="list-style-type: none"><li>• Reads the vehicle configuration of current around view monitor control unit.</li><li>• Saves the read vehicle configuration.</li></ul>
"After Replace ECU"	Writes the vehicle configuration with manual selection.
"Select Saved Data List"	Writes the vehicle configuration with saved data.

### CAUTION:

- When replacing around view monitor control unit, you must perform "Select Saved Data List" or "After Replace ECU" with CONSULT.
- Complete the procedure of "Select Saved Data List" or "After Replace ECU" in order.
- If you set incorrect "Select Saved Data List" or "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Select Saved Data List" or "After Replace ECU" except for new around view monitor control unit.

### Work Procedure

INFOID:0000000010284130

#### 1. WRITING MODE SELECTION

##### CONSULT

Select "Reprogramming, Configuration" of around view monitor control unit.

When writing saved data>>GO TO 2.

When writing manually>>GO TO 3.

#### 2. PERFORM "SAVED DATA LIST"

##### CONSULT

Automatically "Operation Log Selection" window will display if "Before Replace ECU" was performed. Select applicable file from the "Save Data List" and press "Confirm".

>> Work End.

#### 3. PERFORM "AFTER REPLACE ECU" OR "MANUAL CONFIGURATION"

##### CONSULT

1. Select "After Replace ECU" or "Manual Configuration".
2. Identify the correct model and configuration list. Refer to [DAS-87. "Configuration List"](#).
3. Confirm and/or change setting value for each item.

### CAUTION:

**Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.**

4. Select "Next".

### CAUTION:

**Make sure to select "Next", confirm each setting value and press "OK" even if the indicated configuration of brand new around view monitor control unit is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model can not be memorized.**

5. When "Completed", select "End".

>> GO TO 4.

#### 4. OPERATION CHECK

# CONFIGURATION (AROUND VIEW MONITOR CONTROL UNIT)

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

Confirm that each function controlled by around view monitor control unit operates normally.

>> Work End.

## Configuration List

INFOID:0000000010284131

### CAUTION:

Thoroughly read and understand the vehicle specification. Incorrect settings may result in abnormal control of ECU.

MANUAL SETTING ITEM	
Items	Setting value
BCI FUNCTION	WITH ⇔ WITHOUT

⇔: Items which confirm vehicle specifications

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# PREDICTIVE COURSE LINE CENTER POSITION ADJUSTMENT

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

---

## PREDICTIVE COURSE LINE CENTER POSITION ADJUSTMENT

### Description

*INFOID:000000010286877*

Adjust the center position of the predictive course line of the rear view monitor if it is shifted.

### Work Procedure

*INFOID:000000010286878*

#### 1.DRIVING

---

Drive the vehicle straight ahead 100 m (328.1 ft) or more at a speed of 30 km/h (18.6 MPH) or more.

>> END



# REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

## REAR VIEW CAMERA CALIBRATION

### Description

INFOID:000000010351316

Always perform the calibration after removing and installing or replacing the rear view camera:

- AVM control unit
- Rear view camera

#### CAUTION:

- Place the vehicle on level ground when the calibration is performed.
- Follow the CONSULT when performing the calibration. (Rear view camera calibration cannot be operated without CONSULT).

### Work Procedure (Preparation)

INFOID:000000010351317

#### 1. PERFORM SELF-DIAGNOSIS

Perform "Self-Diagnosis" of the "AVM" control unit.

Is any DTC detected?

Except "U1308">> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-47, "DTC Index"](#).

"U1308" or no DTC>>GO TO 2.

#### 2. PREPARATION BEFORE REAR VIEW CAMERA CALIBRATION

##### NOTE:


Select the "AVM" to diagnose the AVM control unit by CONSULT.

1. Perform pre-inspection for diagnosis. Refer to [DAS-67, "Inspection Procedure"](#).
2. Adjust the tire pressure to the specified pressure value.
3. Maintain no-load in vehicle.
4. Check if coolant and engine oil are filled up to correct level and fuel tank is full.
5. Situate vehicle where the camera is exposed at an atmosphere temperature between 0°C (32°F) and 30°C (86°F)
6. Move the shift selector to P (Park) and release the parking brake.
7. Clean the rear view camera.

>> GO TO 3.

#### 3. PREPARATION OF CALIBRATION TARGET MARK

Prepare the calibration target mark according to the following figure:



(1) : Left and right targets

(2) : Center target

# REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

(A) : Side of the black or white area = 200 mm (7.87 in)

(B) : Side of the square target = 400 mm (15.75 in)

>> Refer to [DAS-90, "Work Procedure \(Target Setting\)"](#).


## Work Procedure (Target Setting)

INFOID:000000010351318

### CAUTION:

- Perform this operation in a horizontal position where there is a clear view for 3 m (9.84 ft) backward and 4 m (13.12 ft) wide.
- Place the target in a well-lighted location. (Poor lighting may make it hard to adjust.)
- The target may not be detected when it shines by the reflected light of the sun or lighting.
- The target may not be detected when there is the same pattern of black and white as the target when the pattern is within 0.5 m (1.64 ft) from either side and upward/downward position from the target. (It is desirable that the vehicle is positioned on a single-color floor.)

### 1. TARGET SETTING



Side distance (Sd): "B"–"E" ("D"–"F") : 2125 mm (83.66 in)

Left distance (Ld): "Ct"–"Lt" : 1500 mm (59.06 in)

Right distance (Rd): "Ct"–"Rt" : 1500 mm (59.06 in)

1. Mark points "A", "B", "C" and "D" at the center of the lateral surface of each wheel.

#### NOTE:

Hang a string with a cone from the fender so as to pass through the center of wheel, and then mark a point at the center of the lateral surface of the wheel.

2. Draw line "LH" passing through points "A" and "B" on the left side of vehicle.

#### NOTE:

Approximately 2.2 m (7.22 ft) or more at the rear from the rear axle.

3. Mark point "E" on the line "LH" at the positions 2125 mm (83.66 in) from point "B".

4. Draw line "RH" passing through points "C" and "D" on the right side of vehicle in the same way as step 2.

5. Mark point "F" on the line "RH" at the positions 2125 mm (83.66 in) from point "D".


6. Draw line "RW" passing through the points "E" and "F" on the rear of the vehicle.

#### NOTE:

Approximately 1.8 m (5.91 ft) or more at both left and right sides from vehicle center.

7. Mark point "Ct" at the center of point "E" and "F" on the line "RW".

### CAUTION:




# REAR VIEW CAMERA CALIBRATION

[DRIVER ASSISTANCE SYSTEM]

< BASIC INSPECTION >

Make sure that "E" to "Ct" is equal to "F" to "Ct".

8. Mark point "Lt" and "Rt" on the line "RW" at the positions 1500 mm (59.06 in) from point "Ct".
9. Position the center of the target mark to point of "Ct".



## CAUTION:

Make sure that the black/white pattern of the center target is rotated as compared with the left and right targets.

>> Go to [DAS-91, "Work Procedure \(Rear View Camera Calibration\)"](#).

## Work Procedure (Rear View Camera Calibration)

INFOID:000000010351319


## CAUTION:

Perform the calibration under the specified vehicle condition (fuel full, no-load, specified tire pressure, etc.). Refer to [DAS-89, "Work Procedure \(Preparation\)"](#).

### 1. CHECK REAR VIEW CAMERA HEIGHT

Measure the rear view camera height "H".

>> GO TO 2.



### 2. REAR VIEW CAMERA CALIBRATION

1. Select "Work Support" on "AVM" with CONSULT.
2. Select "REAR CAMERA ITS".
3. Select "OK".

## CAUTION:

- Perform the calibration after the ignition or engine has been kept on for at least 10 minutes to stabilize camera.
  - Operate CONSULT outside the vehicle, and close all doors to retain appropriate vehicle altitude.
4. Input the rear view camera height "H", and then touch "APPLY".
  5. Confirm that the same value is displayed on the center display.
  6. Confirm the following items:
    - The target should be accurately placed.
    - The vehicle should be stopped.
    - The vehicle should be under the specified vehicle condition.
  7. Select "Start" to perform calibration.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N

DAS

P

# REAR VIEW CAMERA CALIBRATION

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

8. Confirm the displayed item.
- "Completed": Select "Completion".
  - Otherwise, perform the following services:

Displayed item		Possible cause	Service procedure
SUSPENSION	—	Temporary malfunction in internal processing of the rear view camera.	Go back to Step 1
	00H Routine not activated	Rear view camera unit malfunction.	Position the target appropriately again. Perform the aiming again. Refer to <a href="#">DAS-90, "Work Procedure (Target Setting)"</a> .
	10H Writing error	<ul style="list-style-type: none"> <li>• Temporary malfunction in internal processing of the rear view camera.</li> <li>• Rear view camera malfunction.</li> </ul>	
X AIMING NG Y (X: 0 - 7, Y: 1 - 8)	—	<ul style="list-style-type: none"> <li>• A target is not-yet-placed. (The rear view camera cannot detect a target.)</li> <li>• The position of the rear view camera is not correct.</li> </ul>	Position the target appropriately again. Perform the aiming again. Refer to <a href="#">DAS-89, "Work Procedure (Preparation)"</a> .
ABNORMALLY COMPLETED	—	<ul style="list-style-type: none"> <li>• Inappropriate work environment.</li> <li>• Inappropriate vehicle condition.</li> </ul>	

**NOTE:**

Replace camera unit if "00H Routine not activated" or "10H Writing error" are repeatedly indicated during the above two services are performed.

9. Confirm that "Completed" is displayed and then select "End" to close the calibration procedure.

>> GO TO 3.

### 3.PERFORM SELF-DIAGNOSIS

Perform "Self-diagnosis" of "AVM" control unit with CONSULT.

Is any DTC detected?

- YES >> Perform diagnosis on the detected DTC and repair or replace the applicable item. Refer to [DAS-47, "DTC Index"](#).
- NO >> GO TO 4.

### 4.ACTION TEST

Test the system operation by action test. Refer to [DAS-80, "LDW : Description"](#).

>> Work End.

# CALIBRATING CAMERA IMAGE (AROUND VIEW MONITOR)

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

## CALIBRATING CAMERA IMAGE (AROUND VIEW MONITOR)

### Description

INFOID:000000010284127


- Calibration must be performed after removing/replacing the cameras, removing parts (e.g. front grille, door mirror, and others) mounted on the cameras, or replacing the Around view monitor control unit.
- The use of CONSULT is required to perform calibration or writing of calibration results to the Around view monitor control unit.
- Align the white lines on the road near the vehicle at the boundary of each camera image by this camera calibration. The white lines far from the vehicle may not be aligned at the boundary of each camera image. The farther the line, the greater the difference is.

### Work Procedure

INFOID:000000010284128


#### CALIBRATION FLOWCHART

Following the flowchart shown in the figure, perform the calibration.



#### NOTE:

View in the incomplete calibration state is indicated by "⊠" on the around view monitor.



#### CALIBRATION PROCEDURE

##### 1. AROUND VIEW MONITOR SCREEN CONFIRMATION

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# CALIBRATING CAMERA IMAGE (AROUND VIEW MONITOR)


< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

Check that there is no indication of "Incomplete calibration".

Is the "Incomplete calibration" display visible?

- YES >> GO TO 2.
- NO >> GO TO 4.



## 2. CHECK THAT AROUND VIEW MONITOR CONTROL UNIT IS REPLACED

Check that the around view monitor control unit is replaced.

Is the around view monitor control unit replaced?

- YES >> GO TO 3.
- NO >> GO TO 5.

## 3. CANCEL THE INDICATION OF INCOMPLETE CALIBRATION (PERFORM THIS ONLY AFTER REPLACING AROUND VIEW MONITOR CONTROL UNIT.)

CONSULT work support

1. On the CONSULT screen, touch "CALIBRATING CAMERA IMAGE (FRONT CAMERA)", "CALIBRATING CAMERA IMAGE (PASS-SIDE CAMERA)", "CALIBRATING CAMERA IMAGE (DR-SIDE CAMERA)", or "CALIBRATING CAMERA IMAGE (REAR CAMERA)" to accept the selection.

### NOTE:

To cancel the indication of Incomplete calibration, select items based on the target camera.

2. On the adjustment screen of each camera, touch "APPLY" button. After this, touch "OK" button.


### CAUTION:

- Never perform operations other than those mentioned above.
- Never perform "Initialize Camera Image Calibration".

3. Display the around view monitor screen to check that there is no errors, such as deviations among the camera images.

Is there a malfunction?

- YES >> Calibration End.
- NO >> GO TO 1.



## 4. PERFORM SIMPLIFIED CONFIRMATION/ADJUSTMENT BY "FINE TUNING OF BIRDS-EYE VIEW"


1. Put target line 1 on the ground beside each axle using packing tape, etc.
2. Put target lines 2 equal to the vehicle total length + approximately 1.0 m (39.3 in) from the vehicle side (right and left) at approximately 30 cm (11.8 in) away from the vehicle (make the line as parallel with the vehicle as possible)

# CALIBRATING CAMERA IMAGE (AROUND VIEW VIEW MONITOR)

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

## Preparation of simplified target line




- |                            |                            |
|----------------------------|----------------------------|
| 1. Target lines 1          | 2. Target lines 2          |
| A. Approx. 30 cm (11.8 in) | B. Approx. 1.0 m (39.3 in) |

3. CONSULT work support  
Touch "FINE TUNING OF BIRDS-EYE VIEW" on the CONSULT screen.
4. On the CONSULT screen, touch "SELECT" button to select right or left camera and perform camera calibration as instructed below:
  - If the marker on the screen deviates from Target line 1, touch "AXIS X" button and "AXIS Y" button to adjust so that the marker is placed on the Target line 1.
  - If Target line 2 is misaligned among the cameras, adjust each camera image to bring Target line 2 into a straight line.

**CAUTION:**

**Never adjust the front camera and rear camera. Only adjust the right and left cameras.**

## Simplified target line adjustment method



- |   |   |                             |
|---|---|-----------------------------|
| 1. Target lines 1                               | 2. Target lines 2   | 3. Marker for target line 1 |
| 4. Boundary between cameras                     | 5. Crosshairs cursor (mark indicated the selected camera) |                             |
| A. Adjustment method for target lines 1 (right) | B. Adjustment method for target lines 2 (right)           |                             |

5. Adjust right and left cameras. Touch "APPLY" on the CONSULT screen to display adjustment results.
6. After adjusting right and left cameras, check that the marker is properly placed on the screen and there is no deviation in Target line 1.

**NOTE:**

- It can be initialized to the NISSAN factory default condition with "Initialize Camera Image Calibration".
- The adjustment value is cancelled on this mode by performing "Initialize Camera Image Calibration".

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

**DAS**

# CALIBRATING CAMERA IMAGE (AROUND VIEW MONITOR)

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

Is the difference corrected?

YES >> On the CONSULT screen, touch "OK" button to complete writing to the around view monitor control unit.


NO >> GO TO 5.

## 5.PERFORM "CALIBRATING CAMERA IMAGE"

Preparation of target line

1. Hang a string with a weight as shown in the figure. Put the points FM0, RM0 (mark) on the ground at the center of the vehicle front end and rear end with white packing tape or a pen.
2. Route the vinyl string under the vehicle, and then pull and fix it on the point approximately 1.0 m (39.9 in) to the front and rear of the vehicle through the points FM0 and RM0 using packing tape.


Target line preparation procedure 1



- |                     |   |                     |
|---------------------|---|---------------------|
| 1. Thread           | 2. Weight                                 | 3. Point FM0 (mark) |
| 4. Point RM0 (mark) | 5. Packing tape (to fix the vinyl string) | 6. Vinyl string     |

3. Put the points FM and RM (mark) 75 cm (29.5 in) from the points FM0 and RM0 individually.
4. Route the vinyl string through the points FM and RM using a triangle scale, and then fix it at approximately 1.5 m (59 in) on both sides with packing tape.
5. Put the points FL, FR, RL, and RR (mark) to both right and left [vehicle width / 2 + 30 cm (11.8 in)] from the points FM and RM.

Target line preparation procedure 2



- |                    |                    |                    |
|--------------------|--------------------|--------------------|
| 1. Point FM        | 2. Point RM        | 3. Triangle scale  |
| 4. Point FL (mark) | 5. Point FR (mark) | 6. Point RL (mark) |
|                    |                    | 7. Point RR (mark) |



# CALIBRATING CAMERA IMAGE (AROUND VIEW MONITOR)

< BASIC INSPECTION >

[DRIVER ASSISTANCE SYSTEM]

7. Point RR (mark)

A. 75 cm (29.5 in)

B. Approx. 1.5 m (59 in)


30 cm (11.8 in)

C. [Vehicle width/ 2 + 30 cm (11.8 in) from the points FM and RM]

6. Draw the lines of the points FL – RL and FR – RR with vinyl string, and fix it with packing tape.

7. Put a mark on the center of each axle, draw vertical lines to the lines of the points FL – RL and FR – RR from the marks on the center of the axle using a triangle scale, and then fix the lines using packing tape.

Target line preparation procedure 3



1. Point FL

2. Point FR

3. Point RL

4. Point RR

5. Center position of axle

6. Triangle scale

Perform “Calibrating Camera Image”

CONSULT work support

1. On the CONSULT screen, touch “CALIBRATING CAMERA IMAGE (FRONT CAMERA)”, “CALIBRATING CAMERA IMAGE (PASS-SIDE CAMERA)”, “CALIBRATING CAMERA IMAGE (DR-SIDE CAMERA)”, or “CALIBRATING CAMERA IMAGE (REAR CAMERA)” to accept the selection.

**NOTE:**

To cancel the indication of Incomplete calibration, select items based on the target camera.

2. On the adjustment screen of each camera, adjust the parameter by touching the “AXIS X” button, “AXIS Y” button, and “ROTATE” button to place the calibration marker shown on the camera screen on the target line drawn on the ground.

Adjustment range

Rotation direction (Center dial) : 31 patterns (16 on the center)

Upper/lower direction (upper/lower switch) : -22 – 22

Left/right direction (left/right switch) : -22 – 22

3. Touch “APPLY” button on the CONSULT screen. “PRCSNG” is displayed and adjustment results are shown on the camera screen.


**CAUTION:**

Check that “PRCSNG” is displayed. Never perform other operations while “PRCSNG” is displayed.

4. Touch “OK” button on the CONSULT screen. “PRCSNG” is displayed and adjustment results are written to the around view monitor control unit.

**CAUTION:**

Check that “PRCSNG” is displayed. Never perform other operations while “PRCSNG” is displayed.



>> GO TO 6.

## 6. PERFORM “FINE TUNING OF BIRDS-EYE VIEW”

# CALIBRATING CAMERA IMAGE (AROUND VIEW MONITOR)

[DRIVER ASSISTANCE SYSTEM]

< BASIC INSPECTION >

This mode is designed to align the boundary between each camera image that could not be aligned in the "Calibrating Camera Image" mode.

CONSULT work support

1. Select "FINE TUNING OF BIRDS-EYE VIEW" by touching CONSULT screen.
2. On the adjustment screen of each camera, adjust the parameter by touching the "AXIS X" button, "AXIS Y" button", and "ROTATE" button to place the calibration marker shown on the camera screen on the target line drawn on the ground.

**NOTE:**

Touch "SELECT" button on the CONSULT screen to select the target camera.

3. Touch "APPLY" button on the CONSULT screen. "PRCSNG" is displayed and adjustment results are shown on the camera screen.

**CAUTION:**

**Check that "PRCSNG" is displayed. Never perform other operations while "PRCSNG" is displayed.**

4. Touch "OK" button on the CONSULT screen. "PRCSNG" is displayed and adjustment results are written to the around view monitor control unit.


**CAUTION:**

• **Check that "PRCSNG" is displayed. Never perform other operations while "PRCSNG" is displayed.**

• **After pressing the "OK" button, never press buttons other than the "BACK" button.**

**NOTE:**

- It can be initialized to the NISSAN factory default condition with "Initialize Camera Image Calibration".
- The adjustment value is cancelled in this mode by performing "Initialize Camera Image Calibration".



>> Calibration End.

# DTC/CIRCUIT DIAGNOSIS

## U0121 VDC CAN 2

### DTC Logic

INFOID:0000000010275633

### DTC DETECTION LOGIC

**NOTE:**

If DTC U0121 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [DAS-106, "DISTANCE SENSOR : DTC Logic"](#).

CONSULT Display	DTC Detection Condition	Possible Cause
VDC CAN CIR1 [U0121]	Distance sensor receives an error signal from ABS actuator and electric unit (control unit) via CAN communication.	<ul style="list-style-type: none"> <li>• ABS actuator and electric unit (control unit).</li> <li>• Distance sensor.</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Start the engine.
2. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

Is display history of DTC U0121 CRNT?

- YES >> Refer to [DAS-99, "Diagnosis Procedure"](#).  
 NO >> Refer to [GI-41, "Intermittent Incident"](#).

### Diagnosis Procedure

INFOID:0000000010275634

#### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "ABS" using CONSULT.

Are any DTCs detected?

- YES >> Refer to [BRC-55, "DTC Index"](#).  
 NO >> Replace the distance sensor. Refer to [DAS-160, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P



# U0122 VDC P-RUN DIAG

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U0122 VDC P-RUN DIAG

### DTC Logic

INFOID:000000010275600

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
VDC CAN CIR1(LDP) [U0122]	Around view monitor control unit receives incorrect signal (P-RUN) from ABS actuator and electric unit (control Unit) via CAN communication.	<ul style="list-style-type: none"><li>• ABS actuator and electric unit (control unit).</li><li>• Around view monitor control unit.</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition ON.
2. Perform "Self Diagnostic Result" of "AVM" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [DAS-100, "Diagnosis Procedure"](#).  
NO >> Refer to [GI-41, "Intermittent Incident"](#).

### Diagnosis Procedure

INFOID:000000010275601

#### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "ABS" using CONSULT.

#### Are any DTCs detected?

- YES >> Refer to [BRC-55, "DTC Index"](#).  
NO >> Replace the around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).

< DTC/CIRCUIT DIAGNOSIS >

U0126 STRG SEN CAN 1

DTC Logic

INFOID:000000010275635

DTC DETECTION LOGIC

**NOTE:**

If DTC U0126 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [DAS-106, "DISTANCE SENSOR : DTC Logic"](#).

CONSULT Display	DTC Detection Condition	Possible Cause
ST ANG SEN SIG [U0126]	Distance sensor receives an error signal from steering angle sensor via CAN communication.	<ul style="list-style-type: none"> <li>Steering angle sensor.</li> <li>Distance sensor.</li> </ul>

DTC CONFIRMATION PROCEDURE

**1**.PERFORM SELF DIAGNOSTIC RESULT

1. Start the engine.
2. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DAS-101, "Diagnosis Procedure"](#).
- NO >> Refer to [GI-41, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000010275636

**1**.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "ABS" using CONSULT.

Are any DTCs detected?

- YES >> Refer to [BRC-55, "DTC Index"](#).
- NO >> Replace the distance sensor. Refer to [DAS-160, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

## U0401 ECM CAN 1

### DTC Logic

INFOID:0000000010275637

#### DTC DETECTION LOGIC

**NOTE:**

If DTC U0401 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [DAS-106, "DISTANCE SENSOR : DTC Logic"](#).

CONSULT Display	DTC Detection Condition	Possible Cause
ECM CAN CIR2 [U0401]	Distance sensor receives an error signal from ECM via CAN communication.	<ul style="list-style-type: none"> <li>• ECM.</li> <li>• Distance sensor.</li> </ul>

#### DTC CONFIRMATION PROCEDURE

### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Start the engine.
2. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DAS-102, "Diagnosis Procedure"](#).  
 NO >> Refer to [GI-41, "Intermittent Incident"](#).

### Diagnosis Procedure

INFOID:0000000010275638

### 1. CHECK ECM SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "ENGINE" using CONSULT.

Are any DTCs detected?

- YES >> Refer to [EC-93, "DTC Index"](#).  
 NO >> Replace the distance sensor. Refer to [DAS-160, "Removal and Installation"](#).

U0415 VDC CAN 1

DTC Logic

INFOID:000000010275639

DTC DETECTION LOGIC

**NOTE:**

If DTC U0415 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [DAS-106, "DISTANCE SENSOR : DTC Logic"](#).

CONSULT Display	DTC Detection Condition	Possible Cause
VDC CAN CIR2 [U0415]	Distance sensor receives an error signal from ABS actuator and electric unit (control unit) via CAN communication.	<ul style="list-style-type: none"> <li>• ABS actuator and electric unit (control unit).</li> <li>• Distance sensor.</li> </ul>

DTC CONFIRMATION PROCEDURE

**1**.PERFORM SELF DIAGNOSTIC RESULT

1. Start the engine.
2. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

Is display history of DTC U0415 CRNT?

- YES >> Refer to [DAS-103, "Diagnosis Procedure"](#).  
 NO >> Refer to [GI-41, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000010275640

**1**.CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "ABS" using CONSULT.

Are any DTCs detected?

- YES >> Refer to [BRC-55, "DTC Index"](#).  
 NO >> Replace the distance sensor. Refer to [DAS-160, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P



# U0416 VDC CHECKSUM DIAG

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U0416 VDC CHECKSUM DIAG

### DTC Logic

INFOID:000000010275602

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
VDC CAN CIR2(LDP) [U0416]	Around view monitor control unit receives incorrect signal (P-RUN) from ABS actuator and electric unit (control unit) via CAN communication.	<ul style="list-style-type: none"><li>• ABS actuator and electric unit (control unit).</li><li>• Around view monitor control unit.</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition ON.
2. Perform "Self Diagnostic Result" of "AVM" using CONSULT.

#### Are any DTCs displayed?

- YES >> Refer to [DAS-104, "Diagnosis Procedure"](#).  
NO >> Refer to [GI-41, "Intermittent Incident"](#).

### Diagnosis Procedure

INFOID:000000010275603

#### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "ABS" using CONSULT.

#### Are any DTCs detected?

- YES >> Refer to [BRC-55, "DTC Index"](#).  
NO >> Replace the around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).



# U0428 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U0428 STEERING ANGLE SENSOR AROUND VIEW MONITOR CONTROL UNIT

AROUND VIEW MONITOR CONTROL UNIT : DTC Logic

INFOID:000000010284257

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
ST ANG SEN CALIB [U0428]	Predictive course line center position adjustment of steering angle sensor is incomplete.	Adjust predictive course line center position adjustment of steering angle sensor.

### AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure

INFOID:000000010284258

#### 1. ADJUST PREDICTIVE COURSE LINE CENTER POSITION ADJUSTMENT OF STEERING ANGLE SENSOR

When U0428 is detected, the predictive course line center position of steering angle sensor needs to be adjusted.

>> Adjust the predictive course line center position of steering angle sensor. Refer to [AV-291, "PREDICTED COURSE LINE CENTER POSITION ADJUSTMENT : Work Procedure"](#).

## DISTANCE SENSOR

DISTANCE SENSOR : DTC Logic

INFOID:000000010284279

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
ST ANG SEN CALIB [U0428]	Predictive course line center position adjustment of steering angle sensor is incomplete.	Adjust predictive course line center position adjustment of steering angle sensor.

### DISTANCE SENSOR : Diagnosis Procedure

INFOID:000000010284280

#### 1. ADJUST PREDICTIVE COURSE LINE CENTER POSITION ADJUSTMENT OF STEERING ANGLE SENSOR

When U0428 is detected, the predictive course line center position of steering angle sensor needs to be adjusted.

>> Adjust the predictive course line center position of steering angle sensor. Refer to [DAS-88, "Work Procedure"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P



# U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U1000 CAN COMM CIRCUIT AROUND VIEW MONITOR CONTROL UNIT AROUND VIEW MONITOR CONTROL UNIT : DTC Logic

INFOID:000000010284261

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CAN COMM CIRCUIT [U1000]	Around view monitor control unit is not transmitting or receiving CAN communication signal for 2 seconds or more.	CAN communication system.

## AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure

INFOID:000000010284262

### 1.PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Perform "Self Diagnostic Result" for "AVM".

#### Is CAN COMM CIRCUIT displayed?

YES >> Refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

NO >> Refer to [GI-41, "Intermittent Incident"](#).

## DISTANCE SENSOR

### DISTANCE SENSOR : DTC Logic

INFOID:000000010284259

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CAN COMM CIRCUIT [U1000]	Distance sensor is not transmitting or receiving CAN communication signal for 2 seconds or more.	CAN communication system.

## DISTANCE SENSOR : Diagnosis Procedure

INFOID:000000010284260

### 1.PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Perform "Self Diagnostic Result" for "LASER/RADAR"

#### Is CAN COMM CIRCUIT displayed?

YES >> Refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).

NO >> Refer to [GI-41, "Intermittent Incident"](#).

# U1010 CONTROL UNIT (CAN)

[DRIVER ASSISTANCE SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## U1010 CONTROL UNIT (CAN) AROUND VIEW MONITOR CONTROL UNIT

### AROUND VIEW MONITOR CONTROL UNIT : DTC Logic

INFOID:0000000010284264

#### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CONTROL UNIT (CAN) [U1010]	Error during CAN controller hardware initialization (VCAN).	Replace the Around view monitor control unit if the malfunction occurs constantly. Refer to <a href="#">AV-387</a> . "Removal and Installation".

## DISTANCE SENSOR

### DISTANCE SENSOR : DTC Logic

INFOID:0000000010284263

#### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CONTROL UNIT (CAN) [U1010]	Error during CAN controller hardware initialization (VCAN).	Replace the distance sensor if the malfunction occurs constantly. Refer to <a href="#">DAS-160</a> . "Removal and Installation".

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

### DTC Logic

INFOID:000000010284265

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Rear display output signal diagnosis (Harness disconnection) [U111A]	Rear view camera image signal circuit open or short.	Check rear view camera image signal circuit.

### Diagnosis Procedure

INFOID:000000010284266

Regarding Wiring Diagram information, refer to [DAS-53, "Wiring Diagram"](#).

### 1. CHECK REAR VIEW CAMERA POWER SUPPLY AND GROUND CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit and rear view camera connectors.
3. Check continuity between around view monitor control unit connector M114 and rear view camera connector D514.

Around view monitor control unit		Rear view camera		Continuity
Connector	Terminals	Connector	Terminals	
M114	50	D514	8	Yes
	52		7	

4. Check continuity between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	50		No

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness or connectors.

### 2. CHECK REAR VIEW CAMERA POWER SUPPLY VOLTAGE

1. Connect around view monitor control unit and rear view camera connectors.
2. Turn ignition switch ON.
3. Check voltage between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M114	50	—	CAMERA switch is ON or selector lever in R (reverse).	6.0 V

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).

### 3. CHECK REAR VIEW CAMERA IMAGE SIGNAL AND IMAGE SIGNAL GROUND CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit and rear view camera connectors.

# U111A REAR CAMERA IMAGE SIGNAL CIRCUIT

**[DRIVER ASSISTANCE SYSTEM]**

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between around view monitor control unit connector M114 and rear view camera connector D514.

Around view monitor control unit		Rear view camera		Continuity
Connector	Terminals	Connector	Terminals	
M114	53	D514	5	Yes
	54		1	

4. Check continuity between around view monitor control unit connector M114 and ground.


Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	53		No

Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> Repair or replace harness or connectors.

## 4. CHECK REAR VIEW CAMERA IMAGE SIGNAL

1. Connect around view monitor control unit and rear view camera connectors.
2. Turn ignition switch ON.
3. Check signal between the terminals of around view monitor control unit connector M114.

Around view monitor control unit connector M114		Condition	Reference value
(+) Terminal	(-) Terminal		
53	54	CAMERA switch is ON or selector lever in R (reverse).	 <p style="text-align: right; font-size: small;">JSNIA0834GB</p>

Is the inspection result normal?

- YES >> Replace around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).  
 NO >> Replace rear view camera. Refer to [DAS-166, "Removal and Installation"](#).

DAS

# U111B SIDE CAMERA RH IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U111B SIDE CAMERA RH IMAGE SIGNAL CIRCUIT

### DTC Logic

INFOID:000000010284267

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Right side display output signal diagnosis (Harness disconnection) [U111B]	Right side camera image signal circuit open or short.	Check right side camera image signal circuit.

### Diagnosis Procedure

INFOID:000000010284268

Regarding Wiring Diagram information, refer to [DAS-53, "Wiring Diagram"](#).

### 1. CHECK RH SIDE CAMERA POWER SUPPLY AND GROUND CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit and RH side camera connectors.
3. Check continuity between around view monitor control unit connector M114 and RH side camera connector D107.

Around view monitor control unit		RH side camera		Continuity
Connector	Terminals	Connector	Terminals	
M114	62	D107	7	Yes
	64		8	

4. Check continuity between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	62		No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

### 2. CHECK RH SIDE CAMERA POWER SUPPLY VOLTAGE

1. Connect around view monitor control unit and RH side camera connectors.
2. Turn ignition switch ON.
3. Check voltage between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M114	62	—	CAMERA switch is ON or selector lever in R (reverse).	6.0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).

### 3. CHECK RH SIDE CAMERA IMAGE SIGNAL AND IMAGE SIGNAL GROUND CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit and RH side camera connectors.

# U111B SIDE CAMERA RH IMAGE SIGNAL CIRCUIT

[DRIVER ASSISTANCE SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between around view monitor control unit connector M114 and RH side camera connector D107.

Around view monitor control unit		RH side camera		Continuity
Connector	Terminals	Connector	Terminals	
M114	65	D107	16	Yes
	66		15	

4. Check continuity between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	65		No


Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness or connectors.

## 4. CHECK RH SIDE CAMERA IMAGE SIGNAL

1. Connect around view monitor control unit and RH side camera connectors.
2. Turn ignition switch ON.
3. Check signal between the terminals of around view monitor control unit connector M114.

Around view monitor control unit connector M114		Condition	Reference value
(+) Terminal	(-) Terminal		
65	66	CAMERA switch is ON or selector lever in R (reverse).	 <p style="text-align: right; font-size: small;">JSNIA0834GB</p>

Is the inspection result normal?

YES >> Replace around view monitor control unit. Refer to [DAS-163. "Removal and Installation"](#).

NO >> Replace RH side camera. Refer to [DAS-161. "Removal and Installation"](#).

# U111C FRONT CAMERA IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U111C FRONT CAMERA IMAGE SIGNAL CIRCUIT

### DTC Logic

INFOID:000000010284269

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Front display output signal diagnosis (Harness disconnection) [U111C]	Front camera image signal circuit open or short.	Check front camera image signal circuit.

### Diagnosis Procedure

INFOID:000000010284270

Regarding Wiring Diagram information, refer to [DAS-53, "Wiring Diagram"](#).

### 1. CHECK FRONT CAMERA POWER SUPPLY AND GROUND CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit and front camera connectors.
3. Check continuity between around view monitor control unit connector M114 and front camera connector E226.

Around view monitor control unit		Front camera		Continuity
Connector	Terminals	Connector	Terminals	
M114	68	E226	2	Yes
	70		1	

4. Check continuity between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	68		No

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace harness or connectors.

### 2. CHECK FRONT CAMERA POWER SUPPLY VOLTAGE

1. Connect around view monitor control unit and front camera connectors.
2. Turn ignition switch ON.
3. Check voltage between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M114	68	—	CAMERA switch is ON or selector lever in R (reverse).	6.0 V

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).

### 3. CHECK FRONT CAMERA IMAGE SIGNAL AND IMAGE SIGNAL GROUND CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit and front camera connectors.



# U111C FRONT CAMERA IMAGE SIGNAL CIRCUIT

[DRIVER ASSISTANCE SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

3. Check continuity between around view monitor control unit connector M114 and front camera connector E226.

Around view monitor control unit		Front camera		Continuity
Connector	Terminals	Connector	Terminals	
M114	71	E226	4	Yes
	72		5	

4. Check continuity between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	71		No


Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness or connectors.

## 4. CHECK FRONT CAMERA IMAGE SIGNAL

1. Connect around view monitor control unit and front camera connectors.
2. Turn ignition switch ON.
3. Check signal between the terminals of around view monitor control unit connector M114.

Around view monitor control unit connector M114		Condition	Reference value
(+) Terminal	(-) Terminal		
71	72	CAMERA switch is ON or selector lever in R (reverse).	

Is the inspection result normal?

YES >> Replace around view monitor control unit. Refer to [DAS-163. "Removal and Installation"](#).

NO >> Replace front camera. Refer to [DAS-159. "Removal and Installation"](#).

# U111D SIDE CAMERA LH IMAGE SIGNAL CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U111D SIDE CAMERA LH IMAGE SIGNAL CIRCUIT

### DTC Logic

INFOID:000000010284271

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Left side display output signal diagnosis (Harness disconnection) [U111D]	Left side camera image signal circuit open or short.	Check left side camera image signal circuit.

### Diagnosis Procedure

INFOID:000000010284272

Regarding Wiring Diagram information, refer to [DAS-53, "Wiring Diagram"](#).

### 1. CHECK LH SIDE CAMERA POWER SUPPLY AND GROUND CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit and LH side camera connectors.
3. Check continuity between around view monitor control unit connector M114 and LH side camera connector D4.

Around view monitor control unit		LH side camera		Continuity
Connector	Terminals	Connector	Terminals	
M114	56	D4	7	Yes
	58		8	

4. Check continuity between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	56		No

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connectors.

### 2. CHECK LH SIDE CAMERA POWER SUPPLY VOLTAGE

1. Connect around view monitor control unit and LH side camera connectors.
2. Turn ignition switch ON.
3. Check voltage between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M114	56	—	CAMERA switch is ON or selector lever in R (reverse).	6.0 V

Is the inspection result normal?

YES >> GO TO 3.

NO >> Replace around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).

### 3. CHECK LH SIDE CAMERA IMAGE SIGNAL AND IMAGE SIGNAL GROUND CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit and LH side camera connectors.

# U111D SIDE CAMERA LH IMAGE SIGNAL CIRCUIT

[DRIVER ASSISTANCE SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

- Check continuity between around view monitor control unit connector M114 and LH side camera connector D4.

Around view monitor control unit		LH side camera		Continuity
Connector	Terminals	Connector	Terminals	
M114	59	D4	16	Yes
	60		15	

- Check continuity between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	59		No


Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness or connectors.

## 4. CHECK LH SIDE CAMERA IMAGE SIGNAL

- Connect around view monitor control unit and LH side camera connectors.
- Turn ignition switch ON.
- Check signal between the terminals of around view monitor control unit connector M114.

Around view monitor control unit connector M114		Condition	Reference value
(+) Terminal	(-) Terminal		
59	60	CAMERA switch is ON or selector lever in R (reverse).	

Is the inspection result normal?

YES >> Replace around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).

NO >> Replace LH side camera. Refer to [DAS-161, "Removal and Installation"](#).

# U1232 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U1232 STEERING ANGLE SENSOR

### DTC Logic

INFOID:00000001028557

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
ST ANG SEN CALIB [U1232]	Predictive course line center position adjustment of steering angle sensor is incomplete.	Adjust predictive course line center position adjustment of steering angle sensor.

### Diagnosis Procedure

INFOID:00000001028558

#### 1. ADJUST PREDICTIVE COURSE LINE CENTER POSITION ADJUSTMENT OF STEERING ANGLE SENSOR

When U1232 is detected, the predictive course line center position of steering angle sensor needs to be adjusted.

>> Adjust the predictive course line center position of steering angle sensor. Refer to [AV-291, "PREDICTED COURSE LINE CENTER POSITION ADJUSTMENT : Work Procedure"](#).

# U1302 CAMERA POWER VOLT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U1302 CAMERA POWER VOLT

### DTC Logic

INFOID:0000000010275656

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Camera supply power supply voltage abnormality [U1302]	Short in camera power supply circuit.	<ul style="list-style-type: none"><li>• Harness or connectors.</li><li>• Camera.</li><li>• Around view monitor control unit.</li></ul>

### Diagnosis Procedure

INFOID:0000000010275657

Regarding Wiring Diagram information, refer to [DAS-53. "Wiring Diagram"](#).

### 1. CHECK AVM CAMERA DATA MONITOR ITEMS

Check "F-CAMERA IMAGE SIGNAL", "REAR CAMERA IMAGE SIGNAL", "DR-SIDE CAMERA IMAGE SIG" and "PA-SIDE CAMERA IMAGE SIG" in "DATA MONITOR" of "AVM" using CONSULT.

Is "OK" displayed for all cameras?

YES >> Refer to [GI-41. "Intermittent Incident"](#).

NO-1 (Front camera)>>GO TO 2.

NO-2 (Rear camera)>>GO TO 5.

NO-3 (LH side camera)>>GO TO 8.

NO-4 (RH side camera)>>GO TO 11.

### 2. CHECK FRONT CAMERA POWER SUPPLY (CAMERA)

1. Turn ignition switch ON.
2. Check voltage between front camera connector E226 and ground.

Front camera		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E226	2	—	CAMERA switch is ON.	6.0 V

Is the inspection result normal?

YES >> Replace front camera. Refer to [DAS-159. "Removal and Installation"](#).

NO >> GO TO 3.

### 3. CHECK FRONT CAMERA POWER SUPPLY (AROUND VIEW MONITOR CONTROL UNIT)

Check voltage between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M114	68	—	CAMERA switch is ON.	6.0 V

Is the inspection result normal?

YES >> GO TO 4.

NO >> Replace around view monitor control unit. Refer to [DAS-163. "Removal and Installation"](#).

### 4. CHECK FRONT CAMERA POWER SUPPLY CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit connector M114 and front camera connector.
3. Check continuity between around view monitor control unit connector M114 and front camera connector E226.

# U1302 CAMERA POWER VOLT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

Around view monitor control unit		Front camera		Continuity
Connector	Terminal	Connector	Terminal	
M114	68	E226	2	Yes

4. Check continuity between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	68	—	No

Is the inspection result normal?

YES >> Replace front camera. Refer to [DAS-159. "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

## 5. CHECK REAR CAMERA POWER SUPPLY (CAMERA)

1. Turn ignition switch ON.
2. Check voltage between rear camera connector D514 and ground.

Rear camera		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
D514	8	—	CAMERA switch is ON.	6.0 V

Is the inspection result normal?

YES >> Replace rear camera. Refer to [DAS-166. "Removal and Installation"](#).

NO >> GO TO 6.

## 6. CHECK REAR CAMERA POWER SUPPLY (AROUND VIEW MONITOR CONTROL UNIT)

Check voltage between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M114	50	—	CAMERA switch is ON.	6.0 V

Is the inspection result normal?

YES >> GO TO 7.

NO >> Replace around view monitor control unit. Refer to [DAS-163. "Removal and Installation"](#).

## 7. CHECK REAR CAMERA POWER SUPPLY CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit connector M114 and rear camera connector.
3. Check continuity between around view monitor control unit connector M114 and rear camera connector D514.

Around view monitor control unit		Rear camera		Continuity
Connector	Terminal	Connector	Terminal	
M114	50	D514	8	Yes

4. Check continuity between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	50	—	No

Is the inspection result normal?

YES >> Replace rear camera. Refer to [DAS-166. "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

# U1302 CAMERA POWER VOLT

[DRIVER ASSISTANCE SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## 8. CHECK SIDE CAMERA LH POWER SUPPLY (CAMERA)

1. Turn ignition switch ON.
2. Check voltage between side camera LH connector D14 and ground.

Side camera LH		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
D14	7	—	CAMERA switch is ON.	6.0 V

Is the inspection result normal?

- YES >> Replace side camera LH. Refer to [DAS-161, "Removal and Installation"](#).  
 NO >> GO TO 9.

## 9. CHECK SIDE CAMERA LH POWER SUPPLY (AROUND VIEW MONITOR CONTROL UNIT)

Check voltage between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M114	56	—	CAMERA switch is ON.	6.0 V

Is the inspection result normal?

- YES >> GO TO 10.  
 NO >> Replace around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).

## 10. CHECK SIDE CAMERA LH POWER SUPPLY CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit connector M114 and side camera LH connector.
3. Check continuity between around view monitor control unit connector M114 and side camera LH connector D14.

Around view monitor control unit		Side camera LH		Continuity
Connector	Terminal	Connector	Terminal	
M114	56	D14	7	Yes

4. Check continuity between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	56	—	No

Is the inspection result normal?

- YES >> Replace side camera LH. Refer to [DAS-161, "Removal and Installation"](#).  
 NO >> Repair or replace harness or connectors.

## 11. CHECK SIDE CAMERA RH POWER SUPPLY (CAMERA)

1. Turn ignition switch ON.
2. Check voltage between side camera RH connector D107 and ground.

Side camera RH		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
D107	7	—	CAMERA switch is ON.	6.0 V

Is the inspection result normal?

- YES >> Replace side camera RH. Refer to [DAS-161, "Removal and Installation"](#).  
 NO >> GO TO 12.

## 12. CHECK SIDE CAMERA RH POWER SUPPLY (AROUND VIEW MONITOR CONTROL UNIT)

# U1302 CAMERA POWER VOLT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

Check voltage between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M114	62	—	CAMERA switch is ON.	6.0 V

Is the inspection result normal?

YES >> GO TO 13.

NO >> Replace around view monitor control unit. Refer to [DAS-163. "Removal and Installation"](#).

## 13. CHECK SIDE CAMERA RH POWER SUPPLY CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit connector M114 and side camera RH connector.
3. Check continuity between around view monitor control unit connector M114 and side camera RH connector D107.

Around view monitor control unit		Side camera RH		Continuity
Connector	Terminal	Connector	Terminal	
M114	62	D107	7	Yes

4. Check continuity between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	62	—	No

Is the inspection result normal?

YES >> Replace side camera RH. Refer to [DAS-161. "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.



# U1303 LED POWER SUPPLY VOLT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U1303 LED POWER SUPPLY VOLT

### DTC Logic

INFOID:000000010275658

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
LED supply power supply voltage abnormality [U1303]	Open or short in blind spot warning indicator power supply circuit.	<ul style="list-style-type: none"><li>• Harness or connectors.</li><li>• Around view monitor control unit.</li></ul>

### Diagnosis Procedure

INFOID:000000010275659

Regarding Wiring Diagram information, refer to [DAS-53, "Wiring Diagram"](#).

#### 1. CHECK BLIND SPOT WARNING POWER SUPPLY CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit connector M113 and blind spot warning indicators connectors.
3. Check continuity between around view monitor control unit connector M113 and blind spot warning indicators connectors.

Around view monitor control unit		Blind spot warning indicator		Continuity
Connector	Terminal	Connector	Terminal	
M113	7	D5 (LH)	1	Yes
	8	D108 (RH)	1	

4. Check continuity between around view monitor control unit connector M113 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M113	7	—	No
	8		

#### Is the inspection result normal?

- YES >> Replace around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).  
NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U1304 CAMERA IMAGE CALIBRATION

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U1304 CAMERA IMAGE CALIBRATION

### DTC Logic

INFOID:000000010284275

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Non-completion of the calibration [U1304]	Camera image calibration is incomplete.	Perform calibration of camera image.

### Diagnosis Procedure

INFOID:000000010284276

#### 1.PERFORM CALIBRATION

When U1304 is detected, perform calibration of camera image.

>> Refer to [AV-292, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Work Procedure"](#).

# U1305 CONFIG UNFINISH

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U1305 CONFIG UNFINISH

### DTC Logic

INFOID:000000010284277

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Non-completion of the configuration [U1305]	Configuration of around view monitor control unit is incomplete.	Perform configuration of around view monitor control unit.

### Diagnosis Procedure

INFOID:000000010284278

#### 1.PERFORM CONFIGURATION

When U1305 is detected, perform configuration of around view monitor control unit.

>> Refer to [AV-290, "CONFIGURATION \(AROUND VIEW MONITOR CONTROL UNIT\) : Work Procedure"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U1308 CAMERA CONFIG

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U1308 CAMERA CONFIG

### DTC Logic

INFOID:000000010275598

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Rear camera judgement [U1308]	Around view monitor control unit camera calibration is incomplete.	Perform Around view monitor control unit camera calibration.

### Diagnosis Procedure

INFOID:000000010275599

#### 1. PERFORM AROUND VIEW MONITOR CAMERA CALIBRATION

When U1308 is detected, the rear view camera needs to be calibrated.

>> Calibrate the rear view camera. Refer to [DAS-89. "Description"](#).

# U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U1309 PUMP UNIT CURRENT

### DTC Logic

INFOID:000000010275604

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
PUMP UNIT CURRENT [U1309]	Around view monitor control unit detects incorrect pump current from rear view camera washer control unit.	<ul style="list-style-type: none"> <li>• Harness</li> <li>• Rear view camera washer control unit</li> <li>• Around view monitor control unit</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" of "AVM" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [DAS-125, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010275605

Regarding Wiring Diagram information, refer to [DAS-53, "Wiring Diagram"](#).

#### 1. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rear view camera washer control unit connector B67 and ground.

Rear view camera washer control unit		Ground	Voltage
Connector	Terminal		
B67	12	—	Battery voltage

#### Is inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness or connectors.

#### 2. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear view camera washer control unit connector.
3. Check continuity between rear view camera washer control unit connector B67 and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B67	5	—	Yes

#### Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness or connectors.

#### 3. CHECK REAR VIEW CAMERA WASHER CONTROL UNIT CIRCUITS CONTINUITY

1. Disconnect around view monitor control unit connector M113.
2. Check continuity between around view monitor control unit connector M113 and rear view camera washer control unit connector B67.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U1309 PUMP UNIT CURRENT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

Around view monitor control unit		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
M113	36	B67	8	Yes
	37		6	
	38		7	

3. Check continuity between around view monitor control unit connector M113 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M113	36	—	No
	38		

Is inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness or connectors.

## 4. CHECK CONTINUITY REAR VIEW CAMERA WASHER CONTROL UNIT TO PUMP

1. Disconnect rear view camera air pump motor connector.
2. Check continuity between rear view camera washer control unit connector B67 and rear view camera air pump motor connector B72.

Rear view camera washer control unit		Rear view camera air pump motor		Continuity
Connector	Terminal	Connector	Terminal	
B67	1	B72	1	Yes
	2		2	

3. Check for continuity between rear view camera washer control unit connector and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B67	1	—	No
	2		

Is inspection result normal?

YES >> Replace the rear view camera air pump motor. Refer to [DAS-168, "Removal and Installation"](#).

NO >> Repair or replace harness or connectors.

# U130A PUMP CONTROL UNIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U130A PUMP CONTROL UNIT

### DTC Logic

INFOID:000000010275763

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
PUMP ECU JUDGE [U130A]	Rear view camera washer control unit malfunction.	Rear view camera washer control unit.

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM SELF DIAGNOSTIC RESULT

1. Start the engine.
2. Perform "Self Diagnostic Result" of "AVM" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [DAS-127, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010275764

#### 1.CHECK REAR VIEW CAMERA WASHER CONTROL UNIT POWER SUPPLY CIRCUIT

1. Turn ignition switch ON.
2. Check voltage between rear view camera washer control unit connector B67 and ground.

Rear view camera washer control unit		Ground	Voltage
Connector	Terminal		
B67	12	—	Battery voltage

#### Is inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace harness or connectors.

#### 2.CHECK REAR VIEW CAMERA WASHER CONTROL UNIT GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear view camera washer control unit connector.
3. Check continuity between rear view camera washer control unit connector B67 and ground.

Rear view camera washer control unit		Ground	Continuity
Connector	Terminal		
B67	5	—	Yes

#### Is the inspection result normal?

- YES >> Replace rear view camera washer control unit. Refer to [DAS-169, "Removal and Installation"](#).  
 NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U130B REAR CAMERA COMM ERROR

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## U130B REAR CAMERA COMM ERROR

### DTC Logic

INFOID:000000010275606

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
Rear Camera Serial Communication [U130B]	Around view monitor control unit receives incorrect communication signal from rear view camera.	<ul style="list-style-type: none"> <li>• Rear view camera.</li> <li>• Harness.</li> <li>• Around view monitor control unit.</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON.
2. Perform "Self Diagnostic Result" of "AVM" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [DAS-128, "Diagnosis Procedure"](#).
- NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010275607

Regarding Wiring Diagram information, refer to [DAS-53, "Wiring Diagram"](#).

#### 1. CHECK REAR VIEW CAMERA SERIAL SIGNAL CIRCUIT CONTINUITY

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit connector M114 and rear camera connector.
3. Check continuity between around view monitor control unit connector M114 and rear camera connector D514.

Around view monitor control unit		Rear camera		Continuity
Connector	Terminal	Connector	Terminal	
M114	49	D514	4	Yes

4. Check continuity between around view monitor control unit connector M114 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M114	49	—	No

#### Is the inspection result normal?

- YES >> Replace around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).
- NO >> Repair or replace harness or connectors.



# C10B7 YAW RATE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## C10B7 YAW RATE SENSOR

### DTC Logic

INFOID:000000010275660

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
YAW RATE SENSOR [C10B7]	Yaw rate/side/decel G sensor calibration incor- rect.	<ul style="list-style-type: none"><li>• Calibration of yaw rate/side/decel G sensor not performed.</li><li>• Interruption in yaw rate/side/decel G sensor calibration.</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Start the engine.
2. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [DAS-129, "Diagnosis Procedure"](#).
- NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010275661

#### 1. PERFORM YAW RATE/SIDE/DECEL G SENSOR CALIBRATION

1. Perform calibration of yaw rate/side/decel G sensor. Refer to [BRC-72, "Work Procedure"](#).
2. Erase DTCs using CONSULT.
3. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

#### Is DTC detected?

- YES >> Replace the distance sensor. Refer to [DAS-160, "Removal and Installation"](#).
- NO >> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# C1A01 POWER SUPPLY CIRCUIT 1, C1A02 POWER SUPPLY CIRCUIT 2

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## C1A01 POWER SUPPLY CIRCUIT 1, C1A02 POWER SUPPLY CIRCUIT 2

### DTC Logic

INFOID:000000010275621

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
POWER SUPPLY CIR [C1A01]	Distance sensor battery voltage is less than 7.9 V for 5 seconds.	<ul style="list-style-type: none"><li>• Harness</li><li>• Distance sensor</li></ul>
POWER SUPPLY CIR 2 [C1A02]	Distance sensor battery voltage is greater than 19.3 V for 5 seconds.	

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start the engine.
2. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [DAS-130, "Diagnosis Procedure"](#).  
NO >> Refer to [GI-41, "Intermittent Incident"](#).

### Diagnosis Procedure

INFOID:000000010275622

#### 1. CHECK DISTANCE SENSOR POWER SUPPLY AND GROUND CIRCUIT

Check power supply and ground circuit of distance sensor. Refer to [DAS-144, "DISTANCE SENSOR : Diagnosis Procedure"](#).

#### Is the inspection result normal?

- YES >> Replace the distance sensor. Refer to [DAS-160, "Removal and Installation"](#).  
NO >> Repair or replace harness or connectors.

# C1A03 VEHICLE SPEED SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## C1A03 VEHICLE SPEED SENSOR AROUND VIEW MONITOR CONTROL UNIT

AROUND VIEW MONITOR CONTROL UNIT : DTC Logic

INFOID:0000000010275610

### DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible causes
VHCL SPEED SE CIRC [C1A03]	Around view monitor control unit detects a velocity calculation error.	<ul style="list-style-type: none"><li>• ABS actuator and electric unit (control unit).</li><li>• Around view monitor control unit.</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition ON.
2. Perform "Self Diagnostic Result" of "AVM" using CONSULT.

Is DTC detected?

- YES >> Refer to [DAS-131, "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).  
NO >> Refer to [GI-41, "Intermittent Incident"](#).

### AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure

INFOID:0000000010275611

#### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "ABS" using CONSULT.

Are any DTCs detected?

- YES >> Refer to [BRC-55, "DTC Index"](#).  
NO >> Replace around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).

## DISTANCE SENSOR

DISTANCE SENSOR : DTC Logic

INFOID:0000000010284470

### DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible causes
VHCL SPEED SE CIRC [C1A03]	Distance sensor detects a velocity calculation error.	<ul style="list-style-type: none"><li>• ABS actuator and electric unit (control unit).</li><li>• Distance sensor.</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition ON.
2. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DAS-131, "DISTANCE SENSOR : Diagnosis Procedure"](#).  
NO >> Refer to [GI-41, "Intermittent Incident"](#).

### DISTANCE SENSOR : Diagnosis Procedure

INFOID:0000000010284471

#### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "ABS" using CONSULT.

Are any DTCs detected?

- YES >> Refer to [BRC-55, "DTC Index"](#).  
NO >> Replace distance sensor. Refer to [DAS-160, "Removal and Installation"](#).

# C1A04 ABS/TCS/VDC SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## C1A04 ABS/TCS/VDC SYSTEM

### AROUND VIEW MONITOR CONTROL UNIT

#### AROUND VIEW MONITOR CONTROL UNIT : DTC Logic

INFOID:0000000010275614

#### DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible causes
ABS/TCS/VDC CIRC [C1A04]	Around view monitor control unit receives VDC failed message from ABS actuator and electric unit (control unit).	<ul style="list-style-type: none"><li>• ABS actuator and electric unit (control unit).</li><li>• Around view monitor control unit.</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition ON.
2. Perform "Self Diagnostic Result" of "AVM" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [DAS-132, "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).  
NO >> Inspection End.

#### AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure

INFOID:0000000010275615

##### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "ABS" using CONSULT.

##### Are any DTCs detected?

- YES >> Refer to [BRC-55, "DTC Index"](#).  
NO >> Replace around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).

## DISTANCE SENSOR

#### DISTANCE SENSOR : DTC Logic

INFOID:0000000010284472

#### DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible causes
ABS/TCS/VDC CIRC [C1A04]	Distance sensor receives VDC failed message from ABS actuator and electric unit (control unit).	<ul style="list-style-type: none"><li>• ABS actuator and electric unit (control unit).</li><li>• Distance sensor.</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition ON.
2. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

##### Is DTC detected?

- YES >> Refer to [DAS-132, "DISTANCE SENSOR : Diagnosis Procedure"](#).  
NO >> Inspection End.

#### DISTANCE SENSOR : Diagnosis Procedure

INFOID:0000000010284473

##### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "ABS" using CONSULT.

##### Are any DTCs detected?

- YES >> Refer to [BRC-55, "DTC Index"](#).  
NO >> Replace distance sensor. Refer to [DAS-160, "Removal and Installation"](#).

# C1A05 BRAKE SW/STOP LAMP SW

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## C1A05 BRAKE SW/STOP LAMP SW

### DTC Logic

INFOID:000000010275641

### DTC DETECTION LOGIC

#### NOTE:

If DTC C1A05 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [DAS-106. "DISTANCE SENSOR : DTC Logic"](#).

CONSULT Display	DTC Detection Condition	Possible Cause
BRAKE SW/STOP L SW [C1A05]	Mismatch between stop lamp switch signal and ICC brake switch signal received from ECM and stop lamp switch signal received from ABS actuator and electric unit (control unit) that continues for 10 seconds or more with vehicle speeds at approximately 40 km/h or more.	<ul style="list-style-type: none"><li>• ECM.</li><li>• ABS actuator and electric unit (control unit).</li><li>• Distance sensor.</li></ul>

### Diagnosis Procedure

INFOID:000000010275642

#### 1. CHECK SELF DIAGNOSTIC RESULT OF ECM

1. Perform "Self Diagnostic Result" of "ENGINE" using CONSULT.

##### Are any DTCs detected?

YES >> Refer to [EC-93. "DTC Index"](#).

NO >> GO TO 2.

#### 2. CHECK SELF DIAGNOSTIC RESULT OF ABS

1. Perform "Self Diagnostic Result" of "ABS" using CONSULT.

##### Are any DTCs detected?

YES >> Refer to [BRC-55. "DTC Index"](#).

NO >> Replace distance sensor. Refer to [DAS-160. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# C1A12 LASER BEAM OFF CENTER

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## C1A12 LASER BEAM OFF CENTER

### DTC Logic

INFOID:000000010275623

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
LASER BEAM OFFCNTR [C1A12]	Distance sensor is off the aiming point.	Distance sensor.

### Diagnosis Procedure

INFOID:000000010275624

#### 1. PERFORM DISTANCE SENSOR SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

#### Is DTC detected?

- YES >> Replace distance sensor. Refer to [DAS-160. "Removal and Installation"](#).
- NO >> Inspection End.

C1A14 ECM

DTC Logic

INFOID:000000010275645

DTC DETECTION LOGIC

**NOTE:**

If DTC C1A14 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [DAS-106, "DISTANCE SENSOR : DTC Logic"](#).

CONSULT Display	DTC detecting condition	Possible causes
ECM CIRCUIT [C1A14]	ECM is malfunctioning.	<ul style="list-style-type: none"> <li>• Accelerator pedal position sensor.</li> <li>• ECM.</li> <li>• Distance sensor.</li> </ul>

**1**.PERFORM SELF DIAGNOSTIC RESULT

1. Start the engine.
2. Drive the vehicle.
3. Stop the vehicle.
4. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

Is DTC detected?

- YES >> Refer to [DAS-135, "Diagnosis Procedure"](#).
- NO >> Refer to [GI-41, "Intermittent Incident"](#).

Diagnosis Procedure

INFOID:000000010275646

**1**.PERFORM SELF DIAGNOSTIC RESULT OF ECM

Perform "Self Diagnostic Result" of "ENGINE" using CONSULT.

Are any DTCs detected?

- YES >> Refer to [EC-93, "DTC Index"](#).
- NO >> Replace distance sensor. Refer to [DAS-160, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# C1A15 GEAR POSITION

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## C1A15 GEAR POSITION

### DTC Logic

INFOID:000000010275648

#### DTC DETECTION LOGIC

**NOTE:**

If DTC C1A15 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [DAS-106, "DISTANCE SENSOR : DTC Logic"](#).

If DTC C1A15 is displayed with DTC C1A03, first perform the trouble diagnosis for DTC U1000. Refer to [DAS-131, "DISTANCE SENSOR : DTC Logic"](#).

If DTC C1A15 is displayed with DTC C1A04, first perform the trouble diagnosis for DTC U1000. Refer to [DAS-132, "DISTANCE SENSOR : DTC Logic"](#).

CONSULT Display	DTC detecting condition	Possible causes
GEAR POSITION [C1A15]	A mismatch between current gear position signal transmitted from TCM via CAN communication and gear position calculated by distance sensor continues for approximately 11 minutes or more.	<ul style="list-style-type: none"><li>• Input speed sensor.</li><li>• Vehicle speed sensor CVT (output speed sensor).</li><li>• TCM.</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Start the engine.
2. Drive the vehicle at 10 km/h (6 MPH) or faster for approximately 15 minutes or more.
3. Stop the vehicle.
4. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

##### Is DTC detected?

YES >> Refer to [DAS-136, "Diagnosis Procedure"](#).

NO >> Refer to [GI-41, "Intermittent Incident"](#).

#### Diagnosis Procedure

INFOID:000000010275649

##### 1. CHECK SELF DIAGNOSTIC RESULT OF TCM

Perform "Self Diagnostic Result" of "TRANSMISSION" using CONSULT.

##### Are any DTCs detected?

YES >> Refer to [TM-63, "DTC Index"](#).

NO >> Replace distance sensor. Refer to [DAS-160, "Removal and Installation"](#).



# C1A16 RADAR BLOCKED

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## C1A16 RADAR BLOCKED

### DTC Logic

INFOID:000000010275625

### DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible causes
RADAR STAIN [C1A16]	If any stain occurs to distance sensor body window.	<ul style="list-style-type: none"><li>• Stain or foreign materials deposited.</li><li>• Cracks or scratches exist.</li></ul>

#### NOTE:

DTC C1A16 may be detected under the following conditions. (Explain to the customer about the difference between the contamination detection function and the indication when the malfunction is detected and tell them this is not a malfunction.)

- When contamination or foreign materials adhere to the ICC sensor area of the front bumper
- When driving while it is snowing or when frost forms on the ICC sensor area of the front bumper
- When ICC sensor area of the front bumper is temporarily fogged

### Diagnosis Procedure

INFOID:000000010275626

#### 1. VISUAL CHECK

1. Check for contamination and foreign material on the distance sensor area of the front bumper.
2. Check distance sensor for contamination and foreign materials.
3. Check distance sensor for cracks and scratches.

#### Is the inspection result normal?

- YES >> Replace the distance sensor. Refer to [DAS-160, "Removal and Installation"](#).
- NO >> Repair as necessary.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# C1A17 DISTANCE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## C1A17 DISTANCE SENSOR

### DTC Logic

INFOID:000000010275650

### DTC DETECTION LOGIC

**NOTE:**

If DTC C1A17 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [DAS-106. "DISTANCE SENSOR : DTC Logic"](#).

CONSULT Display	DTC detecting condition	Possible causes
LASER SENSOR FAIL [C1A17]	Distance sensor is malfunctioning.	Distance sensor.

### Diagnosis Procedure

INFOID:000000010275651

#### 1. REPLACE DISTANCE SENSOR

>> Replace distance sensor. Refer to [DAS-160. "Removal and Installation"](#).

# C1A18 RADAR AIMING INCOMP

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## C1A18 RADAR AIMING INCOMP

### DTC Logic

INFOID:000000010275629

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
LASER AIMING INCOMP [C1A18]	Distance sensor not adjusted.	<ul style="list-style-type: none"><li>Distance sensor aiming adjustment not performed.</li><li>Distance sensor aiming adjustment interrupted.</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM SELF DIAGNOSTIC RESULT

1. Start the engine.
2. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [DAS-139, "Diagnosis Procedure"](#).
- NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000010275630

#### 1.ADJUST DISTANCE SENSOR

Perform Distance Sensor Initial Vertical Alignment and Distance Sensor Alignment.

>> Refer to [DAS-70, "Description"](#) and [DAS-72, "Description"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# C1A21 UNIT HIGH TEMP

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## C1A21 UNIT HIGH TEMP

### DTC Logic

INFOID:000000010275627

### DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible causes
UNIT HIGH TEMP [C1A21]	Distance sensor judges high temperature abnormality.	Temperature around distance sensor high.

### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch OFF.
2. Wait for 10 minutes or more to cool the distance sensor.
3. Start the engine.
4. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

#### Is DTC detected?

- YES >> Replace distance sensor. Refer to [DAS-160, "Removal and Installation"](#).
- NO >> Refer to [GI-41, "Intermittent Incident"](#).

# C1A24 NP RANGE

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## C1A24 NP RANGE

### DTC Logic

INFOID:000000010275652

### DTC DETECTION LOGIC

#### NOTE:

If DTC C1A24 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [DAS-106, "DISTANCE SENSOR : DTC Logic"](#).

CONSULT Display	DTC Detection Condition	Possible Cause
NP RANGE [C1A24]	A mismatch between shift position signal and a current gear position signal transmitted from TCM via CAN communication that continues for 60 seconds or more.	<ul style="list-style-type: none"><li>• TCM.</li><li>• Transmission range switch.</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK SELF DIAGNOSTIC RESULT (1)

1. Start the engine.
2. Shift selector lever to P position and wait for approximately 5 minutes or more.
3. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [DAS-141, "Diagnosis Procedure"](#).  
NO >> GO TO 2.

#### 2. CHECK SELF DIAGNOSTIC RESULT (2)

1. Shift selector lever to N position and wait for approximately 5 minutes or more.
2. Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [DAS-141, "Diagnosis Procedure"](#).  
NO >> Refer to [GI-41, "Intermittent Incident"](#).

### Diagnosis Procedure

INFOID:000000010275653

#### 1. CHECK SELF DIAGNOSTIC RESULT OF TCM

Perform "Self Diagnostic Result" of "TRANSMISSION" using CONSULT.

#### Are any DTCs detected?

- YES >> Refer to [TM-63, "DTC Index"](#).  
NO >> Replace distance sensor. Refer to [DAS-160, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# C1A39 STEERING ANGLE SENSOR

[DRIVER ASSISTANCE SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## C1A39 STEERING ANGLE SENSOR AROUND VIEW MONITOR CONTROL UNIT AROUND VIEW MONITOR CONTROL UNIT : DTC Logic

INFOID:0000000010275612

### DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible causes
STRG SEN CIR [C1A39]	control unit receives steering angle sensor failed message from steering angle sensor.	<ul style="list-style-type: none"><li>Steering angle sensor.</li><li>Around view monitor control unit.</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

- Turn ignition ON.
- Perform "Self Diagnostic Result" of "AVM" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [DAS-142, "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"](#).  
NO >> Refer to [GI-41, "Intermittent Incident"](#).

### AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure

INFOID:0000000010275613

#### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "ABS" using CONSULT.

#### Are any DTCs detected?

- YES >> Refer to [BRC-55, "DTC Index"](#).  
NO >> Replace around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).

## DISTANCE SENSOR

### DISTANCE SENSOR : DTC Logic

INFOID:0000000010284474

### DTC DETECTION LOGIC

CONSULT Display	DTC detecting condition	Possible causes
STRG SEN CIR [C1A39]	Distance sensor receives steering angle sensor failed message from steering angle sensor.	<ul style="list-style-type: none"><li>Steering angle sensor.</li><li>Distance sensor.</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM SELF DIAGNOSTIC RESULT

- Turn ignition ON.
- Perform "Self Diagnostic Result" of "LASER/RADAR" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [DAS-142, "DISTANCE SENSOR : Diagnosis Procedure"](#).  
NO >> Refer to [GI-41, "Intermittent Incident"](#).

### DISTANCE SENSOR : Diagnosis Procedure

INFOID:0000000010284475

#### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

Perform "Self Diagnostic Result" of "ABS" using CONSULT.

#### Are any DTCs detected?

- YES >> Refer to [BRC-55, "DTC Index"](#).  
NO >> Replace distance sensor. Refer to [DAS-160, "Removal and Installation"](#).

# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## POWER SUPPLY AND GROUND CIRCUIT AROUND VIEW MONITOR CONTROL UNIT

### AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure

INFOID:000000010408908

Regarding Wiring Diagram information, refer to [AV-262. "Wiring Diagram"](#).

#### WITHOUT DRIVER ASSISTANCE SYSTEM

##### 1.CHECK FUSE

Check that the following fuses are not blown.

Terminal No.	Signal name	Fuse No.
2	Battery power supply	15 (20A)

Are the fuses blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

##### 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit connector M103.
3. Check voltage between around view monitor control unit connector M103 and ground.

Around view monitor control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M103	2	—	Ignition switch: OFF	Battery voltage

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness or connectors.

##### 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between around view monitor control unit connector M103 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M103	1	—	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

#### WITH DRIVER ASSISTANCE SYSTEM

##### 1.CHECK FUSE

Check that the following fuses are not blown.

Terminal No.	Signal name	Fuse No.
2	Battery power supply	15 (20A)

Are the fuses blown?

YES >> Replace the blown fuse after repairing the affected circuit.

NO >> GO TO 2.

##### 2.CHECK POWER SUPPLY CIRCUIT

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N

DAS

P

# POWER SUPPLY AND GROUND CIRCUIT

[DRIVER ASSISTANCE SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn ignition switch OFF.
2. Disconnect around view monitor control unit connector M113.
3. Check voltage between around view monitor control unit connector M113 and ground.

Around view monitor control unit		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
M113	2	—	Ignition switch: OFF	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness or connectors.

## 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between around view monitor control unit connector M113 and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M113	1	—	Yes

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Repair or replace harness or connectors.

## DISTANCE SENSOR

### DISTANCE SENSOR : Diagnosis Procedure

INFOID:0000000010284476

Regarding Wiring Diagram information, refer to [DAS-53, "Wiring Diagram"](#).

## 1.CHECK FUSE

Check that the following fuse is not blown.

Terminal No.	Signal name	Fuse No.
1	Ignition power supply	30 (10A)

Is the fuse blown?

- YES >> Replace the blown fuse after repairing the affected circuit.  
NO >> GO TO 2.

## 2.CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect distance sensor connector E21.
3. Check voltage between distance sensor connector E21 and ground.

Distance sensor		Ground	Condition	Voltage (Approx.)
Connector	Terminal			
E21	1	—	Ignition switch: ON	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace harness or connectors.

## 3.CHECK GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Check continuity between distance sensor connector E21 and ground.



# POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

Distance sensor		Ground	Continuity
Connector	Terminal		
E21	8	—	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair or replace harness or connectors.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# WARNING SYSTEMS SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## WARNING SYSTEMS SWITCH CIRCUIT

### Diagnosis Procedure

INFOID:000000010275681

Regarding Wiring Diagram information, refer to [DAS-53, "Wiring Diagram"](#).

#### 1. CHECK WARNING SYSTEMS SWITCH SIGNAL INPUT

1. Turn the ignition switch ON.
2. Check voltage between around view monitor control unit harness connector and ground.

Terminals		Condition	Voltage (Approx.)
(+)	(-)		
AVM control unit		Warning systems switch	
Connector	Terminal		
M113	17		
		Pressed	0 V
		Released	Battery voltage

Is the inspection result normal?

- YES >> Replace the around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).  
NO >> GO TO 2.

#### 2. CHECK WARNING SYSTEMS SWITCH

1. Turn ignition switch OFF.
2. Remove warning system switch.
3. Check warning system switch. Refer to [DAS-147, "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace the warning system switch. Refer to [DAS-164, "Removal and Installation"](#).

#### 3. CHECK WARNING SYSTEM SWITCH GROUND CIRCUIT

Check continuity between warning system switch harness connector terminal and ground.

Warning system switch		Ground	Continuity
Connector	Terminal		
M253	8		Yes

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair harness or connector.

#### 4. CHECK WARNING SYSTEM SWITCH SIGNAL INPUT CIRCUIT FOR OPEN

1. Disconnect the around view monitor control unit control unit connector.
2. Check continuity between the around view monitor control unit harness connector and warning system switch harness connector.

Around view monitor control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M113	17	M253	6	Yes

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair the harnesses or connectors.

#### 5. CHECK WARNING SYSTEM SWITCH SIGNAL INPUT CIRCUIT FOR SHORT

# WARNING SYSTEMS SWITCH CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

Check continuity between the around view monitor control unit harness connector and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M113	17		No

Is the inspection result normal?

- YES >> Replace the around view monitor control unit. Refer to [DAS-163. "Removal and Installation"](#).
- NO >> Repair the harnesses or connectors.

## Component Inspection

INFOID:000000010275682

### 1. CHECK WARNING SYSTEMS SWITCH

Check continuity of warning system switch.

Terminal		Condition	Continuity
6	8	When warning system switch is pressed	Yes
		When warning system switch is released	No

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace the warning system switch. Refer to [DAS-164. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P



# WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## WARNING SYSTEMS ON INDICATOR CIRCUIT

### Diagnosis Procedure

INFOID:000000010275684

Regarding Wiring Diagram information, refer to [DAS-53. "Wiring Diagram"](#).

#### 1. CHECK WARNING SYSTEM ON INDICATOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect warning system switch connector.
3. Turn ignition switch ON.
4. Check voltage between warning system switch harness connector and ground.

Terminals		Voltage (Approx.)
(+)	(-)	
Warning system switch		Ground
Connector	Terminal	
M253	5	
		Battery voltage

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair the harness or connector.

#### 2. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect the around view monitor control unit harness connector.
3. Check continuity between the around view monitor control unit harness connector and warning system switch harness connector.

Around view monitor control unit		Warning system switch		Continuity
Connector	Terminal	Connector	Terminal	
M113	15	M253	3	Yes

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair the harnesses or connectors.

#### 3. CHECK WARNING SYSTEMS ON INDICATOR SIGNAL CIRCUIT FOR SHORT

Check continuity between the around view monitor control unit harness connector and ground.

Around view monitor control unit		Ground	Continuity
Connector	Terminal		
M113	15		No

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair the harnesses or connectors.

#### 4. CHECK WARNING SYSTEMS ON INDICATOR

Check the warning systems ON indicator. Refer to [DAS-149. "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the around view monitor control unit. Refer to [DAS-163. "Removal and Installation"](#).

NO >> Replace warning systems switch. [DAS-164. "Removal and Installation"](#).

# WARNING SYSTEMS ON INDICATOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## Component Inspection

INFOID:000000010275685

### 1. CHECK WARNING SYSTEMS ON INDICATOR

Apply battery voltage to warning system switch terminals 3 and 5, and then check if the warning systems ON indicator illuminates.

Terminals		Condition	Warning system switch ON indicator
(+)	(-)		
5	3	When the battery voltage is applied	On
		When the battery voltage is not applied	Off

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace the warning systems switch. Refer to [DAS-164, "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# WARNING BUZZER CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## WARNING BUZZER CIRCUIT

### Component Function Check

INFOID:000000010275686

#### 1. CHECK WARNING BUZZER

---

1. Turn the ignition switch ON.
2. Select the "Active Test" item "BUZZER" of "BCM" with CONSULT.
3. While operating the test item, check the operation.

**On** : Warning buzzer is activated.

**Off** : Warning buzzer is not activated.

#### Is the inspection result normal?

YES >> Inspection End.

NO >> Refer to [DAS-150, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010275687

#### 1. CHECK WARNING BUZZER OPERATION

---

While activating the buzzer with CONSULT, listen for the buzzer sound.

#### Does warning buzzer sound?

YES >> Replace the around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).

NO >> Replace the combination meter (buzzer).

# REAR VIEW CAMERA WASHER MOTOR CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## REAR VIEW CAMERA WASHER MOTOR CIRCUIT

### Component Function Check

INFOID:000000010275765

#### 1. CHECK REAR VIEW CAMERA WASHER MOTOR CIRCUIT

1. Turn ignition switch ON.
2. Select "WASH ACTIVE" of "AVM" with CONSULT.
3. Check operation while operating the test item.

**On** : Rear view camera washer motor is activated.

**Off** : Rear view camera washer motor is not activated.

Is the inspection result normal?

- YES >> Rear view camera washer motor circuit is normal.  
 NO >> Refer to [DAS-151, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000010275766

#### 1. CHECK REAR VIEW CAMERA WASHER MOTOR POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear view camera washer motor connector.
3. Turn ignition switch ON.
4. Select "WASH ACTIVE" of "AVM" with CONSULT.
5. Check voltage between rear view camera washer motor connector E55 and ground.

Rear view camera washer motor		Ground	Voltage
Connector	Terminal		
E55	2	—	Battery voltage

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> Repair or replace harness or connector.

#### 2. CHECK REAR VIEW CAMERA WASHER MOTOR GROUND CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect rear view camera washer control unit connector.
3. Check continuity between rear view camera washer motor connector E55 and rear view camera washer control unit connector B67.

Rear view camera washer motor		Rear view camera washer control unit		Continuity
Connector	Terminal	Connector	Terminal	
E55	1	B67	3	Yes

Is the inspection result normal?

- YES >> Replace rear view camera washer motor. Refer to [DAS-167, "Removal and Installation"](#).  
 NO >> Repair or replace harness or connector.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# DRIVER ASSISTANCE SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## SYMPTOM DIAGNOSIS

### DRIVER ASSISTANCE SYSTEM SYMPTOMS

#### Symptom Table

INFOID:000000010227323

#### LANE DEPARTURE WARNING SYSTEM SYMPTOMS

**NOTE:**

Refer to the following the operation condition of the Lane Departure Warning system.

- Lane Departure Warning system: [DAS-16, "LDW : System Description"](#).

Symptom	Possible cause	Inspection item/Reference page
Indicator/warning lamps do not illuminate when ignition switch OFF ⇒ ON	LDW warning does not illuminate.	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Around view monitor control unit</li> </ul> Combination meter. Refer to <a href="#">MWI-21, "CONSULT Function (METER/M&amp;A)"</a> . Around view monitor control unit.
	LDW ON indicator does not illuminate.	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Around view monitor control unit</li> </ul> Refer to <a href="#">DAS-39, "CONSULT Function"</a> .
	Warning systems ON indicator does not illuminate.	<ul style="list-style-type: none"> <li>• Harness between around view monitor control unit and warning systems switch</li> <li>• Warning systems switch</li> <li>• Around view monitor control unit</li> </ul> Warning systems ON indicator circuit. Refer to <a href="#">DAS-149, "Component Inspection"</a> .
	LDW warning or LDW ON indicator does not illuminate.	<ul style="list-style-type: none"> <li>• Combination meter</li> </ul> Combination meter. Refer to <a href="#">MWI-19, "Description"</a> .
	All of indicator/warning lamps does not illuminate; <ul style="list-style-type: none"> <li>• LDW warning</li> <li>• LDW ON indicator</li> <li>• Warning systems ON indicator</li> </ul>	<ul style="list-style-type: none"> <li>• Power supply and ground circuit of around view monitor control unit</li> <li>• Around view monitor control unit</li> </ul> Power supply and ground circuit of around view monitor control unit. Refer to <a href="#">DAS-143, "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"</a> .
LDW system is not activated. (Indicator/warning lamps illuminate when ignition switch OFF ⇒ ON)	LDW ON indicator is not turned ON ⇔ OFF when operating warning systems switch	<ul style="list-style-type: none"> <li>• Harness between around view monitor control unit and warning systems switch</li> <li>• Harness between warning systems switch and ground</li> <li>• Warning systems switch</li> <li>• Around view monitor control unit</li> </ul> <ul style="list-style-type: none"> <li>• Warning systems switch circuit. Refer to <a href="#">DAS-146, "Diagnosis Procedure"</a>.</li> <li>• LDW system setting can not be turned ON/OFF on the information display. Refer to <a href="#">DAS-155, "Diagnosis Procedure"</a>.</li> </ul>
	Warning buzzer is not sounding. (LDW warning is activated.)	<ul style="list-style-type: none"> <li>• Around view monitor control unit</li> </ul> Meter buzzer circuit. Refer to <a href="#">DAS-150, "Component Function Check"</a> .
Warning functions are not timely (Example) <ul style="list-style-type: none"> <li>• Does not function when driving on lane markers</li> <li>• Functions when driving in a lane</li> <li>• Functions in a different position from the actual position</li> </ul>	<ul style="list-style-type: none"> <li>• Camera calibration</li> <li>• Rear camera</li> <li>• Around view monitor control unit</li> </ul> Camera calibration. Refer to <a href="#">DAS-89, "Description"</a> .	
Rear view camera washer is not activated	Rear view camera washer motor	Rear view camera washer motor circuit. Refer to <a href="#">DAS-151, "Diagnosis Procedure"</a> .
Rear view camera wash is insufficient	<ul style="list-style-type: none"> <li>• Washer tube (include check valve)</li> <li>• Air tube</li> <li>• Washer/Air nozzle (Rear view camera)</li> </ul>	Rear view camera washer/air blower function. Refer to <a href="#">DAS-68, "Inspection Procedure"</a> .



# DRIVER ASSISTANCE SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## BLIND SPOT WARNING SYSTEM SYMPTOMS

**NOTE:**

Refer to the following the operation condition of the Blind Spot Warning system.

- Blind Spot Warning system: [DAS-20, "BSW : System Description"](#).

Symptom	Possible cause	Inspection item/Reference page
Indicator/warning lamps do not illuminate when ignition switch OFF ⇒ ON.	BSW warning does not illuminate	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Around view monitor control unit</li> </ul> Combination meter. Refer to <a href="#">MWI-21, "CONSULT Function (METER/M&amp;A)"</a> .
	BSW ON indicator does not illuminate	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Around view monitor control unit</li> </ul> Around view monitor control unit. Refer to <a href="#">DAS-39, "CONSULT Function"</a> .
	Warning systems ON indicator (on the warning systems switch) does not illuminate	<ul style="list-style-type: none"> <li>• Harness between around view monitor control unit and warning systems switch</li> <li>• Warning systems switch</li> <li>• Around view monitor control unit</li> </ul> Warning systems ON indicator circuit. Refer to <a href="#">DAS-148, "Diagnosis Procedure"</a> .
	BSW ON indicator or BSW warning do not illuminate	<ul style="list-style-type: none"> <li>• Combination meter</li> <li>• Around view monitor control unit</li> </ul> Combination meter. Refer to <a href="#">MWI-19, "Description"</a> .
	All of indicator/warning lamps do not illuminate; <ul style="list-style-type: none"> <li>• BSW warning</li> <li>• BSW ON indicator</li> <li>• Warning systems ON indicator</li> </ul>	<ul style="list-style-type: none"> <li>• Power supply and ground circuit of around view monitor control unit</li> <li>• Around view monitor control unit</li> <li>• Combination meter</li> </ul> Power supply and ground circuit of around view monitor control unit. Refer to <a href="#">DAS-143, "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"</a> .
	BSW indicator does not turn ON	<ul style="list-style-type: none"> <li>• Harness between around view monitor control unit and BSW indicator</li> <li>• Around view monitor control unit</li> <li>• BSW indicator</li> </ul> Around view monitor control unit. Refer to <a href="#">DAS-39, "CONSULT Function"</a> .
BSW system is not activated. (Indicator/warning lamps illuminate when ignition switch OFF ⇒ ON.)	Warning systems ON indicator is not turned ON ⇔ OFF when operating warning systems switch	<ul style="list-style-type: none"> <li>• Harness between around view monitor control unit and warning systems switch</li> <li>• Harness between warning systems switch and ground</li> <li>• Around view monitor control unit</li> <li>• Warning systems switch</li> </ul> <ul style="list-style-type: none"> <li>• Warning systems switch circuit. Refer to <a href="#">DAS-146, "Diagnosis Procedure"</a>.</li> <li>• BSW system setting cannot be turned ON/OFF on the information display. Refer to <a href="#">DAS-155, "Diagnosis Procedure"</a>.</li> </ul>
	Buzzer is not sounding	<ul style="list-style-type: none"> <li>• Warning system buzzer</li> <li>• Around view monitor control unit</li> </ul> Buzzer circuit. Refer to <a href="#">DAS-150, "Component Function Check"</a> .
BSW functions are not are not timely (Example) <ul style="list-style-type: none"> <li>• Does not function when approaching a adjacent vehicle while BSW ON indicator lamp is illuminated</li> </ul>	<ul style="list-style-type: none"> <li>• Rear camera calibration</li> <li>• Rear camera</li> <li>• Around view monitor control unit</li> </ul> Rear camera calibration. Refer to <a href="#">DAS-89, "Description"</a> .	
Rear view camera washer is not activated	Rear view camera washer motor	Rear view camera washer motor circuit. Refer to <a href="#">DAS-151, "Component Function Check"</a> .
Rear camera wash is insufficient	<ul style="list-style-type: none"> <li>• Washer tube (include check valve)</li> <li>• Air tube</li> <li>• Washer/Air nozzle (Rear camera)</li> </ul>	Refer to <a href="#">DAS-68, "Inspection Procedure"</a> . Rear view camera washer/air blower function.

## MOVING OBJECT DETECTION SYSTEM SYMPTOMS

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

## DRIVER ASSISTANCE SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

**NOTE:**

Refer to the following the operation condition of the Moving Object Detection system.

- Moving Object Detection system: [DAS-26. "MOD : System Description"](#).

Symptom		Possible cause	Inspection item/Reference page
Indicator/warning lamps do not illuminate when ignition switch OFF ⇒ ON.	All of indicator/warning lamps do not illuminate; • Moving Object Detection warning lamp • Moving Object Detection ON indicator • Warning systems ON indicator	<ul style="list-style-type: none"> <li>• Power supply and ground circuit of around view monitor control unit</li> <li>• Around view monitor control unit</li> <li>• Combination meter</li> </ul>	Power supply and ground circuit of around view monitor control unit. Refer to <a href="#">DAS-143. "AROUND VIEW MONITOR CONTROL UNIT : Diagnosis Procedure"</a> .
	Buzzer is not sounding	<ul style="list-style-type: none"> <li>• Warning system buzzer</li> </ul>	Buzzer circuit. Refer to <a href="#">DAS-150. "Component Function Check"</a> .

### FORWARD COLLISION WARNING SYSTEM SYMPTOMS

**NOTE:**

Refer to the following the operation condition of the Forward Collision Warning system.

- Forward Collision Warning system: [DAS-29. "FCW : System Description"](#).

Symptom		Possible cause	Inspection item/Reference page
Operation	FCW system is not activated	Warning system switch	Warning system switch. Refer to <a href="#">DAS-146. "Diagnosis Procedure"</a> .
	FCW system setting cannot be turned ON/OFF on the information display	Steering switch	Steering switch. Refer to <a href="#">DAS-155. "Description"</a> .

# SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

< SYMPTOM DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## SYSTEM SETTINGS CANNOT BE TURNED ON/OFF IN VEHICLE INFORMATION DISPLAY

### Description

INFOID:000000010227324

The system setting cannot be turned ON/OFF in the combination meter information display using the steering switch.

### Diagnosis Procedure

INFOID:000000010227325

#### 1. CHECK DRIVER ASSISTANCE SYSTEM SETTING

1. Ignition On.
2. Check that the driver assistance system setting can be turned ON/OFF in the combination meter information display using the steering switch.

Is the inspection result normal?

- YES >> Inspection End.
- NO >> GO TO 2.

#### 2. CHECK STEERING SWITCH CIRCUIT

Check the steering switch. Refer to [MWI-69. "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace harness or connector.

#### 3. CHECK STEERING SWITCH RESISTANCE

Check the steering switch resistance. Refer to [MWI-69. "Component Inspection"](#).

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-82. "Removal and Installation"](#).
- NO >> Replace steering switch. Refer to [AV-211. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# SWITCH DOES NOT TURN ON / SWITCH DOES NOT TURN OFF

< SYMPTOM DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

---

## SWITCH DOES NOT TURN ON / SWITCH DOES NOT TURN OFF

### Description

INFOID:000000010227328

The switch does not turn ON

- The driver assistance system does not turn On when the warning system switch is pressed.

The switch does not turn OFF

- The driver assistance system does not turn Off when the warning system switch is pressed.

### Diagnosis Procedure

INFOID:000000010227329

#### 1. CHECK WARNING SYSTEM SWITCH CIRCUIT

---

Check the warning system switch circuit. Refer to [DAS-146, "Diagnosis Procedure"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace harness or connector.

#### 2. CHECK WARNING SYSTEM SWITCH

---

Check the warning system switch. Refer to [DAS-147, "Component Inspection"](#).

Is the inspection result normal?

YES >> Replace the around view monitor control unit. Refer to [DAS-163, "Removal and Installation"](#).

NO >> Replace the warning system switch. Refer to [DAS-164, "Removal and Installation"](#).

# NORMAL OPERATING CONDITION

< SYMPTOM DIAGNOSIS >

[DRIVER ASSISTANCE SYSTEM]

## NORMAL OPERATING CONDITION

### Description

INFOID:000000010227338

#### PRECAUTIONS FOR FORWARD COLLISION WARNING (FCW)

- The forward collision warning system is designed to warn driver before a collision but will not avoid a collision. It is the driver's responsibility to stay alert, drive safely and be in control of the vehicle at all times.
- The radar sensor does not detect the following objects.
  - Pedestrians, animals, or obstacles in the roadway.
  - Oncoming vehicles
  - Crossing vehicles
- The forward collision warning system does not function when a vehicle ahead is a narrow vehicle, such as a motorcycle.
- The radar sensor may not detect a vehicle ahead in the following conditions:
  - Snow or heavy rain
  - Dirt, ice, snow or other material covering the radar sensor
  - Interference by other radar sources
  - Snow or road spray from traveling vehicles is splashed
  - Driving in a tunnel
- The radar sensor may not detect a vehicle when the vehicle ahead is being towed.
- When the distance to the vehicle ahead is too close, the beam of the radar sensor is obstructed.
- The radar sensor may not detect a vehicle when driving on a steep downhill slope or on roads with sharp curves.
- Excessive noise will interfere with the warning tone sound, and it may not be heard.

#### PRECAUTIONS FOR LANE DEPARTURE WARNING (LDW)

- The LDW system is only a warning device to inform the driver of a potential unintended lane departure. It will not steer the vehicle or prevent loss of control. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the traveling lane, and be in control of the vehicle at all times.
- The rear view camera may not detect properly under the following conditions:
  - When towing a trailer.
  - When strong light enters the rear view camera. (For example, direct sunlight or headlight from the rear)
  - When ambient brightness changes instantly. (For example, when the vehicle enters or exits a tunnel or passes under a bridge.)
- Automatic washer and blower may not be able to secure detection capability when excessive dirt adheres on the camera lens.
- LDW system may not function properly under the following conditions:
  - Excessive noise (e.g. audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
  - The rear view camera may not be able to detect properly under the following conditions:
    - On roads where there are multiple parallel lane markers; lane markers that are faded or not painted clearly; yellow painted lane markers; non-standard lane markers; or lane markers covered with water, dirt, snow, etc.
    - On roads where the discontinued lane markers are still detectable.
    - On roads where there are sharply contrasting objects, such as shadows, snow, water, wheel ruts, seams or lines remaining after road repairs. (The LDW system could detect these items as lane markers.)
    - On roads where the traveling lane merges or separates.
    - When the vehicle's traveling direction does not align with the lane marker.
    - When the road surface is very dark due to scarce ambient light or impaired tail lamp.
- When driving on curved road, warning will be late on the outside of the curve due to the nature of the system.

#### PRECAUTIONS FOR BLIND SPOT WARNING (BSW)

- The BSW system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When changing lanes, always use the side and rear mirrors and turn and look in the direction you will move to ensure it is safe to change lanes. Never rely solely on the BSW system.
- The rear camera may not detect properly under the following conditions:
  - When towing a trailer.
  - When strong light enters the rear camera. (For example, direct sunlight or headlight from the rear)
  - When ambient brightness changes instantly. (For example, when the vehicle enters or exits a tunnel or passes under a bridge.)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N

DAS

P

## NORMAL OPERATING CONDITION

### [DRIVER ASSISTANCE SYSTEM]

#### < SYMPTOM DIAGNOSIS >

- Automatic washer and blower may not be able to secure detection capability when excessive dirt adheres on the camera lens.
- The camera unit may not be able to detect when certain objects are present such as:
  - Pedestrians, bicycles, animals
  - Several types of vehicles such as motorcycles
  - Oncoming vehicles
  - A vehicle approaching rapidly from behind.
  - A vehicle which your vehicle overtakes rapidly.
- The rear camera may not be able to detect properly when your vehicle travels beside the middle section of a vehicle with long wheelbase(e.g. trailer truck, semi-trailer, tractor).
- The rear camera detection zone is designed based on a standard lane width. When driving in a wider lane, the camera unit may not detect vehicles in an adjacent lane. When driving in a narrow lane, the camera unit may detect vehicles driving two lanes away.
- The rear camera is designed to ignore most stationary objects, however objects such as guardrails, walls, foliage and parked vehicles may occasionally be detected. This is a normal operating condition.
- The rear camera may detect reflection image of vehicles or roadside objects that are not actually in the detection zone, especially when the road is wet.

#### MOVING OBJECT DETECTION


- The Moving Object Detection system is not a replacement for proper driving procedure and is not designed to prevent contact with vehicles or objects. When backing up, always look in the direction the driver will move to ensure it is safe to proceed. Never rely solely on the Moving Object Detection system.
- Using the Moving Object Detection system under some road or weather condition could lead to improper system operation. Always rely on driver's own steering and braking operation to avoid accidents.
- The Moving Object Detection system may not provide a warning for vehicles that pass through the detection zone quickly.
- Do not use the Moving Object Detection system when towing a trailer.
- Excessive noise (e.g., audio system volume, open vehicle window) will interfere with the chime sound, and it may not be heard.
- A rear view camera may not detect approaching vehicles in certain situations:
  - When a vehicle parked alongside obstructs the beam of the rear view camera.
  - When the vehicle is parked in an angled parking space.
  - When the vehicle is parked on an incline.
  - When a vehicle turns into your vehicle's aisle.
  - When the angle formed by your vehicle and approaching vehicle is small.
- Severe weather or road spray conditions may reduce the ability of the radar to detect other vehicles.
- The rear view camera system may not detect:
  - Small or moving object.
  - Wedge-shaped objects.
  - Object closer to the bumper than 30 cm (10 inch).
  - Thin objects such as rope, wire, chain, etc.
- Do not use the MOD system under the following conditions because the system may not function properly:
  - When driving with a tire that is not the within normal tire condition (example: tire wear, low pressure, spare tire, chain, non-standard wheels).
  - When the vehicle is equipped with non-original brake parts or suspension parts.

## REMOVAL AND INSTALLATION

## FRONT CAMERA

## Exploded View

INFOID:000000010283553



1. Front grille

2. Front camera

## Removal and Installation

INFOID:000000010283554

## REMOVAL

1. Remove the front grille. Refer to [EXT-23, "Removal and Installation"](#).
2. Remove screws and front camera.

## INSTALLATION

Installation is in the reverse order of removal.

**NOTE:**

Perform camera image calibration. Refer to [AV-292, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Work Procedure"](#).

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

# DISTANCE SENSOR


< REMOVAL AND INSTALLATION >

[DRIVER ASSISTANCE SYSTEM]

## DISTANCE SENSOR

Exploded View

INFOID:000000010283578



1. Distance sensor

2. Bracket

← Front

## Removal and Installation

INFOID:000000010227341

### REMOVAL

1. Remove the front bumper fascia. Refer to [EXT-20, "Removal and Installation"](#).
2. Remove distance sensor bolts and the distance sensor.  
**CAUTION:**  
**Do not drop or shock distance sensor.**
3. Remove bolts and distance sensor bracket (if necessary).

### INSTALLATION

Installation is in the reverse order of removal.

#### **CAUTION:**

**Perform additional service when replacing distance sensor. Refer to [DAS-69, "Work Procedure"](#).**




## SIDE CAMERA

### Removal and Installation

INFOID:000000010283555

#### REMOVAL

1. Remove door mirror rear finisher (2). Refer to [MIR-25. "Removal and Installation"](#).
2. Remove screws (A) and side camera (1).  
○: Pawl



#### INSTALLATION

Installation is in the reverse order of removal.

**CAUTION:**

Perform camera image calibration (if equipped with around view camera). Refer to [AV-135. "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Description"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS


## BSW INDICATOR

### Removal and Installation

INFOID:000000010227342

#### REMOVAL

1. Remove the front door finisher. Refer to [INT-15, "Removal and Installation"](#).
2. Release the door mirror corner finisher using a suitable tool. Refer to [MIR-22, "Exploded View"](#).
3. Disconnect the harness connector (A), release the harness clip and remove the door mirror corner finisher (1).
4. Remove screws and blind spot warning indicator (2).



#### INSTALLATION

Installation is in the reverse order of removal.

# AROUND VIEW MONITOR CONTROL UNIT


< REMOVAL AND INSTALLATION >

[DRIVER ASSISTANCE SYSTEM]

## AROUND VIEW MONITOR CONTROL UNIT

### Exploded View

INFOID:000000010283558



1. Around view monitor control unit A. Harness connector

### Removal and Installation

INFOID:000000010283559

#### REMOVAL

##### **CAUTION:**

Before replacing around view monitor control unit, save or print current vehicle specification with CONSULT configuration before replacement. Refer to [AV-288, "ADDITIONAL SERVICE WHEN REPLACING AROUND VIEW MONITOR CONTROL UNIT : Work Procedure"](#).

1. Remove glove box assembly. Refer to [IP-23, "Removal and Installation"](#).
2. Remove around view monitor control unit screws.
3. Disconnect the harness connector from the around view monitor control unit and remove.

#### INSTALLATION

Installation is in the reverse order of removal.

##### **CAUTION:**

- Replace the around view monitor control unit if it has been dropped or sustained an impact.
- When replacing around view monitor control unit, you must perform "After Replace ECU" with CONSULT. Refer to [AV-288, "ADDITIONAL SERVICE WHEN REPLACING AROUND VIEW MONITOR CONTROL UNIT : Work Procedure"](#).

##### **NOTE:**

Perform camera image calibration. Refer to [AV-292, "CALIBRATING CAMERA IMAGE \(AROUND VIEW MONITOR\) : Work Procedure"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# WARNING SYSTEMS SWITCH

< REMOVAL AND INSTALLATION >

[DRIVER ASSISTANCE SYSTEM]


## WARNING SYSTEMS SWITCH

### Removal and Installation


INFOID:000000010269651

#### REMOVAL

1. Remove the instrument lower panel LH. Refer to [IP-14. "Exploded View"](#).
2. Remove the screws (A) that retain the upper (1) and lower (2) switch carriers.



3. Release pawls using a suitable tool (A), then remove the warning systems switch (2) from the lower switch carrier.  
(1): Blank  
(3): AWD LOCK switch (if equipped)  
(4): Hill descent control switch (if equipped)



#### INSTALLATION

Installation is in the reverse order of removal.

# WARNING SYSTEMS BUZZER


< REMOVAL AND INSTALLATION >

[DRIVER ASSISTANCE SYSTEM]

## WARNING SYSTEMS BUZZER

Exploded View

INFOID:000000010288646



1. Instrument lower panel LH

2. Warning systems buzzer

A. Harness connector

○ Pawl

## Removal and Installation

INFOID:000000010227344

### REMOVAL

1. Remove instrument lower panel LH. Refer to [IP-14, "Exploded View"](#).
2. Remove warning systems buzzer from bracket on the back of the instrument lower panel LH.

### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

## REAR VIEW CAMERA

< REMOVAL AND INSTALLATION >

[DRIVER ASSISTANCE SYSTEM]


### REAR VIEW CAMERA

#### Removal and Installation

INFOID:000000010283557

#### REMOVAL

1. Remove the back door outer finisher. Refer to [EXT-50. "Removal and Installation"](#).
2. Disconnect washer tubes (1,3) and air tube (2) (if equipped).
3. Release pawl (B), disconnect harness connector (A) from rear view camera and remove.



#### INSTALLATION

Installation is in the reverse order of removal.

# REAR VIEW CAMERA WASHER MOTOR


< REMOVAL AND INSTALLATION >

[DRIVER ASSISTANCE SYSTEM]

## REAR VIEW CAMERA WASHER MOTOR

### Exploded View

INFOID:000000010290336



1. Front and rear wiper motor

2. Seal

3. Rear view camera  
washer motor

4. Washer tank

← Front

### Removal and Installation

INFOID:000000010283566

#### REMOVAL

1. Drain the washer fluid.
2. Remove the front under cover. Refer to [EXT-16, "Exploded View"](#).
3. Remove engine side cover. Refer to [EXT-28, "FENDER PROTECTOR : Exploded View"](#).
4. Disconnect the harness connector from the rear view camera washer motor.
5. Disconnect the washer tube from the rear view camera washer motor.
6. Remove the rear view camera washer motor.
7. Remove the washer tank seal (if necessary).

#### INSTALLATION

Installation is in the reverse order of removal.

#### **CAUTION:**

**Add water to the top of washer tank inlet after installing. Check that no leaks exist.**

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# REAR VIEW CAMERA AIR PUMP MOTOR


< REMOVAL AND INSTALLATION >

[DRIVER ASSISTANCE SYSTEM]

## REAR VIEW CAMERA AIR PUMP MOTOR

Exploded View

INFOID:000000010269645



1. Rear floor

2. Rear view camera air pump motor

3. Bracket

← Front

## Removal and Installation

INFOID:000000010269646

### REMOVAL

1. Remove the rear bumper fascia under cover (LH). Refer to [EXT-20. "Exploded View"](#).
2. Disconnect the air tubes from the rear view camera air pump motor.
3. Disconnect the harness connector from the rear view camera air pump motor.
4. Remove bolts and rear view camera air pump motor.
5. Remove nuts and remove bracket (if necessary).

### INSTALLATION

Installation is in the reverse order of removal.



# REAR VIEW CAMERA WASHER CONTROL UNIT


< REMOVAL AND INSTALLATION >

[DRIVER ASSISTANCE SYSTEM]

## REAR VIEW CAMERA WASHER CONTROL UNIT

Exploded View

INFOID:000000010269647



1. Body panel

2. Rear view camera washer control unit

### Removal and Installation

INFOID:000000010269648

#### REMOVAL

1. Remove the luggage rear plate. Refer to [INT-37, "LUGGAGE REAR PLATE : Removal and Installation"](#).
2. Disconnect the harness connector from the rear view camera washer control unit.
3. Remove the rear view camera washer control unit nuts.
4. Remove the rear view camera washer control unit.

#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000010246043

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

#### Precaution for Work

INFOID:000000010287284

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

# PRECAUTIONS


< PRECAUTION >

[CHASSIS CONTROL]


## Precautions for Harness Repair

INFOID:000000010227346

- Solder the repaired area and wrap tape around the soldered area.  
**NOTE:**  
A fray of twisted lines must be within 110 mm (4.33 in).



- Bypass connection is never allowed at the repaired area.  
**NOTE:**  
Bypass connection may cause CAN communication error. The spliced wire becomes separated and the characteristics of twisted line are lost.



- Replace the applicable harness as an assembly if error is detected on the shield lines of CAN communication line.

## Precautions for Chassis control

INFOID:000000010227347

- Do not disassemble the chassis control module.
- Do not reuse if the chassis control module has been dropped.
- Do not perform ACTIVE TEST while driving the vehicle.
- Slight vibrations are felt on the brake pedal and the operation noises occur, when Active Trace Control and Active Ride Control function operates. This is not a malfunction because it is caused by the functions that are normally operated.
- Tachometer will rise and engine noise may be noticeable during Active Engine Brake function operation. This is not a malfunction because it is caused by the function that is normally operated.
- Active Trace Control, Active Ride Control and Active Engine Brake are not always activated in any driving conditions.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

< PREPARATION >

# PREPARATION


## PREPARATION

### Special Service Tool

INFOID:000000010246044

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components




AWJIA0483ZZ

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:0000000010227348



↔ Front of vehicle

**A** Instrument panel LH

**B** View with glove box removed

**C** Rear of engine compartment RH

**D** RH front of vehicle

**E** Front of engine compartment LH

**F** Rear of battery

No.	Component parts	Function
①	Steering angle sensor	<a href="#">BRC-14, "System Description"</a>
②	Data link connector	<a href="#">LAN-26, "CAN COMMUNICATION SYSTEM : System Description"</a>
③	Combination meter	<a href="#">MWI-8, "METER SYSTEM : System Description"</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# COMPONENT PARTS

< SYSTEM DESCRIPTION >

[CHASSIS CONTROL]


No.	Component parts	Function
④	Vehicle information display	<a href="#">MWI-15. "INFORMATION DISPLAY : System Description"</a>
⑤	Chassis control module	<a href="#">DAS-174. "Chassis Control Module"</a>
⑥	ABS actuator and electric unit (control unit)	<a href="#">BRC-14. "System Description"</a>
⑦	Distance sensor	<a href="#">DAS-16. "LDW : System Description"</a>
⑧	Engine control module	<a href="#">EC-31. "ENGINE CONTROL SYSTEM : System Description"</a>
⑨	Transmission control module	<a href="#">TM-31. "CVT CONTROL SYSTEM : System Description"</a>

## Chassis Control Module

INFOID:0000000010227349

Chassis control module controls the following systems based on the signals from each sensor, switch, and control unit.

- Active engine brake
- Active ride control
- Active trace control



SYSTEM


System Description - Chassis Control

INFOID:000000010227350

- Chassis control to integrally control the driving system was adopted.
- Chassis control module inputs the necessary information for control from CAN communication and each switch and integrally controls each system. Refer to the following table for systems controlled and input/output signals.

System	Reference page
Active Engine Brake	<a href="#">DAS-175. "System Description - Active Engine Brake"</a>
Active Ride Control	<a href="#">DAS-176. "System Description - Active Ride Control"</a>
Active Trace Control	<a href="#">DAS-176. "System Description - Active Trace Control"</a>

SYSTEM DIAGRAM




System Description - Active Engine Brake

INFOID:000000010287268

Active Engine Brake function can be switched ON/OFF through the "Chassis Control" settings on the vehicle information display.

- Assist at corners - to lessen the workload of adjusting speed with brake pedal operations at corners. Active Engine Brake function adds small amount of deceleration by controlling the CVT gear ratio depending on the steering input and various sensors. This benefits to easier traceability at corners.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P


DAS

# SYSTEM

## < SYSTEM DESCRIPTION >

## [CHASSIS CONTROL]

- Assist at breaking - To enhance braking feel, Active Engine Brake adds deceleration by shifting the CVT gear ratio to lower side depending on the driver's brake pedal operation.




### System Description - Active Ride Control


INFOID:000000010287270

The Active Ride Control function can be turned ON/OFF by turning the VDC OFF switch ON/OFF.


- Engine control - Enhances ride comfort by adding/subtracting engine torque in an effort to control the front and rear wheel load balance.



- Engine control - Enhances handling by adding/subtracting engine torque in an effort to control the front and rear wheel load balance.



- Brake control - Enhances ride comfort by restraining upper body movement with small amount of brake control when driving on bumpy roads.



### System Description - Active Trace Control

INFOID:000000010287269

Active Trace Control function controls the braking utilizing the ABS actuator and electric unit (control unit), depending on cornering condition calculated from driver's steering input and plural sensors. Active Trace Control function is aimed to enhance traceability at corners and smooth the vehicle movement to provide confident driving.



# SYSTEM


## < SYSTEM DESCRIPTION >

## [CHASSIS CONTROL]


Active Trace Control function can be switched ON/OFF through the "Chassis Control" settings on the vehicle information display. When the Active Trace Control is selected OFF, some functions will be kept ON to assist driver (for example, avoidance condition).

When the VDC OFF switch is used to turn OFF the VDC system, the Active Trace Control system is also completely turned OFF.


- Steady cornering - The change of forward and lateral acceleration is smoothed by applying the necessary amount of brake pressure.




- Transient steering input - Reduces lag of yaw rate against steering operation.



- Acceleration at corners - Restrains understeer by applying the necessary amount of brake pressure to the inner wheels.



- Quick lane change - achieves stable vehicle behavior at quick steering operation by applying the necessary amount of brake pressure to the appropriate wheels.



## Fail-Safe (Chassis Control Module)

INFOID:000000010227352

- When chassis control module detects an error in the chassis control system architecture (including other system components), the master warning lamp turns ON and an interrupt is displayed on the information display of the combination meter. Please check the DTCs and investigate the cause of error.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# SYSTEM

< SYSTEM DESCRIPTION >

[CHASSIS CONTROL]

DTC	Vehicle condition
C1B92-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
C1B93-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (engine)</li> <li>• Active Engine Brake</li> </ul>
C1B94-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (engine)</li> </ul>
C1B95-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (brake)</li> </ul>
C1B99-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
C1BA0-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (brake)</li> </ul>
C1BA2-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (engine)</li> </ul>
C1BA5-00	Normal control
C1BAB-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (engine)</li> </ul>
C1BB2-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
C1BB3-00	
C1BB4-00	
C1BB5-00	
C1BB6-00	Normal control
C1BB7-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
C1BB8-00	
C1BB9-00	
C1BBA-00	
C1BBB-00	Normal control
C1BBC-00	
C1BBD-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
C1BC0-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> </ul>
C1BC1-00	
C1BC2-00	
C1BC3-00	
C1BC4-00	The following function is suspended. <ul style="list-style-type: none"> <li>• Active Ride Control (brake)</li> </ul>
C1BC5-00	The following function is suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> </ul>

# SYSTEM

< SYSTEM DESCRIPTION >

[CHASSIS CONTROL]

DTC	Vehicle condition
C1BC6-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (brake)</li> </ul>
U1A34-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
U1A35-00	
U1A36-00	
U1A39-00	Normal control
U1A3B-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (brake)</li> <li>• Active Engine Brake</li> </ul>
U1A42-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (engine)</li> </ul>
U1A43-00	
U1A48-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
U1A4A-00	
U1A4B-00	
U1A4E-00	The following function is suspended. <ul style="list-style-type: none"> <li>• Active Ride Control</li> </ul>

## INFORMATION DISPLAY (COMBINATION METER)

### INFORMATION DISPLAY (COMBINATION METER) : Chassis Control Display

INFOID:000000010227353



#### DESIGN/PURPOSE

- The warning message is displayed on the vehicle information display when chassis control module detects an error in the chassis control system architecture. Please check the DTCs and investigate the cause of error.
- Each chassis control system information is displayed on the vehicle information display.

#### Warning Message

Design	Warning Message
—	Chassis Control System Error See Owner's Manual

#### System Information

Design	Description
 <p style="text-align: center; font-size: x-small;">ALG1A0220ZZ</p>	Active Engine Brake inactive Active Ride Control inactive Active Trace Control inactive
 <p style="text-align: center; font-size: x-small;">ALG1A0221ZZ</p>	Active Engine Brake (assist at corners). Active Trace Control is active. (Steering angle is less than the specified angle)

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N




DAS

P

# SYSTEM

< SYSTEM DESCRIPTION >

[CHASSIS CONTROL]

Design	Description
<p>Chassis Control</p> 	<p>Active Engine Brake (assist at corner).                      Active Trace Control assist is active.                      (Steering angle is the specified angle or more in the leftward direction)</p>
<p>Chassis Control</p> 	<p>Active Engine Brake (assist at corner).                      Active Trace Control assist is active.                      (Steering angle is the specified angle or more in the rightward direction)</p>
<p>Chassis Control</p> 	<p>Active Ride Control is active (assist).</p>

Indicator operating

- Active Engine Brake: Refer to [DAS-175. "System Description - Active Engine Brake"](#).
- Active Ride Control: Refer to [DAS-176. "System Description - Active Ride Control"](#).
- Active Trace Control: Refer to [DAS-176. "System Description - Active Trace Control"](#).

## HANDLING PRECAUTION

### Precautions for Chassis Control (Engine Brake, Active Ride, and Active Trace)

INFOID:000000010385678

#### CHASSIS CONTROL

- Chassis Control will not provide all the necessary controls to replace driver intervention. It is not designed to prevent loss of control. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the traveling lane, and be in control of vehicle at all times.
- Chassis Control is primarily intended for use on well-developed freeways or highways. It may not perform satisfactorily in certain roads, weather or driving conditions.
- Using Chassis Control under some conditions of road, corner or severe weather could lead to an unexpected system operation. In such conditions, driver needs to correct the vehicle's direction with driver's steering operation to avoid accidents.
- When Chassis Control is operating, avoid excessive or sudden steering maneuvers. Otherwise, you could lose control of the vehicle.
- Engine Brake Control is designed to enhance braking feel and traceability at corners.
- Active Ride Control is designed to enhance handling and drive comfort.
- Active Trace Control is designed to enhance traceability at corners and smooth vehicle movement for more confident driving.
- Chassis Control may not function properly under the following conditions:
  - During bad weather (rain, fog, snow, wind, etc.).
  - When driving on slippery roads, such as on ice or snow, etc.
  - When driving on winding or uneven roads.
  - When driving with a tire that is not within normal tire conditions (for example, tire wear, low tire pressure, installation of spare tire, tire chains, non-standard wheels).
  - When the vehicle is equipped with non-original steering parts or suspension parts.
- The functions of Chassis Control may or may not operate properly under the following conditions:
  - On roads covered with water, dirt or snow, etc.
  - On roads where there are sharp curves.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# DIAGNOSIS SYSTEM (CHASSIS CONTROL MODULE)

< SYSTEM DESCRIPTION >

[CHASSIS CONTROL]

## DIAGNOSIS SYSTEM (CHASSIS CONTROL MODULE)

### CONSULT Function

INFOID:000000010227354

#### APPLICATION ITEM

CONSULT can display each diagnostic item using the diagnostic test modes as follows.

Mode	Function description
ECU identification	Parts number of chassis control module can be read.
Self Diagnostic Result	Self-diagnostic results and freeze frame data can be read and erased quickly.*1
Data Monitor	Input/Output data in chassis control module can be read.
Active Test	Send the drive signal from CONSULT to the actuator. The operation check can be performed.
Re/programming, Configuration	<ul style="list-style-type: none"><li>• Read and save the vehicle specification (TYPE ID).</li><li>• Write the vehicle specification (TYPE ID) when replacing Chassis Control Module.</li></ul>

\*1: The following diagnosis information is erased by erasing.

- DTC
- Freeze frame data (FFD)

#### ECU IDENTIFICATION

Chassis control module part number can be read.

#### SELF DIAGNOSTIC RESULT

Refer to [DAS-194, "DTC Index"](#).

When "CRNT" is displayed on "self-diagnosis result"

- The system is presently malfunctioning.

When "PAST" is displayed on "self-diagnosis result"

- System malfunction in the past is detected, but the system is presently normal.

#### Freeze frame data (FFD)

When DTC is detected, a vehicle state shown below is recorded and displayed on CONSULT.

Item name	Indication/Unit	Display item
Odometer/Trip meter	km	Total mileage (Odometer value) of the moment a particular.
DTC LOCAL CODE	—	DTC code is displayed but not used.
CAN DIAG PERMIS CONDITION	Off / On	Displays CAN network diagnosis status.
BRAKE SWITCH 1	Off / On	Displays brake switch operating status (Off: close / On: open).
BRAKE SWITCH 2	Off / On	Displays brake switch operating status (Off: open / On: close).
ABS	NORMAL / ABNOR	Displays ABS function status.
TCS	NORMAL / ABNOR	Displays TCS function status.
VDC	NORMAL / ABNOR	Displays VDC function status.
VEHICLE SPEED	km	Displays the vehicle speed.
FR WHEEL SPEED	rpm	Displays the rotational speed of front RH tire.
FL WHEEL SPEED	rpm	Displays the rotational speed of front LH tire.
RR WHEEL SPEED	rpm	Displays the rotational speed of rear RH tire.
RL WHEEL SPEED	rpm	Displays the rotational speed of rear LH tire.
STEERING ANG SENSOR	deg	Displays the steering angle from the steering angle sensor.
SIDE G SENSOR	G	Displays the side G.
DECEL G SENSOR	G	Displays the decel G.
YAW RATE SENSOR	deg/s	Displays the yaw rate.
THRTL OPENING	%	Displays the electric throttle position.

# DIAGNOSIS SYSTEM (CHASSIS CONTROL MODULE)

< SYSTEM DESCRIPTION >

[CHASSIS CONTROL]

Item name	Indication/Unit	Display item
SHIFT POSITION	Off / P / R / N / D (A) / S / L / B / 1 – 6 / M 1 – M 8 / A 1 – A 6	Displayed but not used.
PRESS SENSOR	bar	Displays the brake fluid pressure.

## DATA MONITOR

### NOTE:

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Item	Item [Unit]	Description
IGN VOLT	[V]	Displays the ignition power supply voltage.
CONTROL MODULE MALF	[Off / On]	Displays chassis control module malfunction.
CAN DIAG STATUS	[Off / On]	Displays CAN network diagnosis status.
VEHICLE SPEED	[km/m]	Displays the vehicle speed.
FR WHEEL SPEED	[rpm]	Displays the rotational speed of front RH tire.
FL WHEEL SPEED	[rpm]	Displays the rotational speed of front LH tire.
RR WHEEL SPEED	[rpm]	Displays the rotational speed of rear RH tire.
RL WHEEL SPEED	[rpm]	Displays the rotational speed of rear LH tire.
STEERING ANG SENSOR	[deg]	Displays the steering angle from the steering angle sensor.
DECEL G SENSOR	[G]	Displays the decel G.
SIDE G SENSOR	[G]	Displays the side G.
YAW RATE SENSOR	[deg/s]	Displays the yaw rate.
ACCELE PEDAL POSITION	[%]	Displays the accelerator pedal position.
THROTTLE CONTROL	[NORMAL / INCORR / PREV / IN-POSSI]	Displays the electric throttle status.
SHIFT POSITION	[Off / P / R / N / D (A) / S / L / B / 1 – 6 / M 1 – M 8 / A 1 – A 6]	Displayed but not used.
BRAKE SWITCH 2	[Off / On]	Displays brake switch operating status (Off: close / On: open).
BRAKE SWITCH 1	[Off / On]	Displays brake switch operating status (Off: open / On: close).
PRESS SENSOR	[bar]	Displays the brake fluid pressure.
ABS	[NORMAL / ABNOR]	Displays ABS function status.
ABS MALF	[NORMAL / ABNOR]	Displays ABS function status.
EBD	[NORMAL / ABNOR]	Displays EBD function status.
ACCELE PEDAL MALF	[NORMAL / ABNOR]	Displays the accelerator pedal status.
TCS	[NORMAL / ABNOR]	Displays TCS function status.
TCS MALF	[NORMAL / ABNOR]	Displays TCS function status.
VDC	[NORMAL / ABNOR]	Displays VDC function status.
VDC MALF	[NORMAL / ABNOR]	Displays VDC function status.
VDC OFF SWITCH	[Off / On]	Displays VDC OFF switch status.
PARKING BRAKE	[Off / On]	Displayed but not used.
DRV TRQ CTRL MODE	[INITIAL / NORMAL / STOP 1 / STOP 2 / LIMIT 1 / PROHIBI]	Displays the status of correction to slightly increase/decrease the drive torque.
DRV TRQ CTRL PERMIS 1	[NO PER / PERMIS]	Displays the permission status (basic requirement) of correction to slightly increase/decrease drive torque.
DRV TRQ CTRL PERMIS 2	[NO PER / PERMIS]	Displays the permission status (system requirement) of correction to slightly increase/decrease drive torque.

# DIAGNOSIS SYSTEM (CHASSIS CONTROL MODULE)

< SYSTEM DESCRIPTION >

[CHASSIS CONTROL]

Item [Unit]	Description
DRV TRQ CTRL STOP [REQ / NO REQ]	Displays the stop request status of correction to slightly increase/decrease drive torque.
DRV TRQ CTRL PROHIBIT [REQ / NO REQ]	Displays the prohibition request status of correction to slightly increase/decrease drive torque.
AEB [Off / On]	Displays the Active Engine Brake (corner) function operating status
ATC 1 [Off / On]	Displays active trace control function operating status.
ATC 2 [Off / On]	Displays active trace control function operating status.
ATC 3 [Off / On]	Displays active trace control function operating status.
ATC 4 [Off / On]	Displays active trace control function operating status.
ATC 5 [Off / On]	Displays active trace control function operating status.
BRAKE HOLD [INACT / ACT / RELEA]	Displays the status of Hill Start Assist function.
ARC BRAKE [Off / On]	Displays the brake control effect of Active Trace Control function on the information display in the combination meter.
FL TIRE DISP [DEF / 1]	Displays tire status.
FR TIRE DISP [DEF / 1]	Displays tire status.
RL TIRE DISP [DEF / 1]	Displays tire status.
RR TIRE DISP [DEF / 1]	Displays tire status.
VEHICLE DISP [Off / On]	Displays Active Ride Control (brake) activation status.
INTERRUPT DISP [NOREQ / HOLD1 / HOLD2 / HDC]	Displays the interruption status.
TURN DISP [NSTEER / LEFT / RIGHT]	Displays the turn status.
ALC LEVEL [0]	Displayed but not used.
ALC STATUS [ACTIVE / INACT]	Displayed but not used.
BRAKE HOLD DISP [INACT / ACT / RELEA]	Displays the brake hold status.
ATC DISP [Off / On]	Displays Active Trace Control status.
ARC BRAKE DISP [Off / On]	Displays the status of Active Ride Control (brake).
HDC DISP [Off / On]	Displays the Hill Descent Control.
CVT ENABLE [Off / On]	Displays the CVT authorized state for Active Engine Brake.
ADA SW [Off / On]	Displays the Active Engine Brake status.
COMMAND(REL) [0.0000]	Displays the relative command value of Active Engine Brake.
COMMAND(ABS) [0.0000]	Displays absolute command value of Active Engine Brake.
SLIP RATE [%]	Displays slip ratio of Active Engine Brake.
ASA CHARACTERISTIC [Off / On]	Displays Active Trace Control state on METER.
ADA CHARACTERISTIC [Off / On]	Displays Active Engine Brake state on METER.

## ACTIVE TEST

The active test is used to determine and identify details of a malfunction, based on self-diagnosis test results and data obtained in the DATA MONITOR. In response to instructions from CONSULT, instead of those from chassis control module on the vehicle, a drive signal is sent to the actuator to check its operation.

### CAUTION:

- **Never perform ACTIVE TEST while driving the vehicle.**
- **Always bleed air from brake system before active test.**
- **Never perform active test when system is malfunctioning.**

### NOTE:

- When active test is performed while depressing the brake pedal, the brake pedal depressing stroke may change. This is not a malfunction.
- During an active test, sometimes a chassis control warning is displayed and the master warning lamp illuminates on the information display in the combination meter; however, this is not a malfunction.



# DIAGNOSIS SYSTEM (CHASSIS CONTROL MODULE)

< SYSTEM DESCRIPTION >

[CHASSIS CONTROL]

Test item	Operation	Description
BRAKE ACTUATOR 1 MODE 1	Start	Controls brake fluid pressure.
BRAKE ACTUATOR 1 MODE 2	Start	Controls brake fluid pressure.
BRAKE ACTUATOR 1 MODE 3	Start	Controls brake fluid pressure.
BRAKE ACTUATOR 2 MODE 1	Start	Controls brake fluid pressure.
BRAKE ACTUATOR 2 MODE 2	Start	Controls brake fluid pressure.
BRAKE ACTUATOR 2 MODE 3	Start	Controls brake fluid pressure.
BRAKE ACTUATOR 3 MODE 1	Start	Controls brake fluid pressure.
BRAKE ACTUATOR 3 MODE 2	Start	Controls brake fluid pressure.
BRAKE ACTUATOR 3 MODE 3	Start	Controls brake fluid pressure.
MASTER WARNING ACTIVE	On	If touching "On" with the master warning lamp not illuminated, the master warning lamp illuminates. Stops in approximately 1 minute.
	Off	The master warning lamp turns OFF. (vehicle in normal state)
FL TIRE DISP	On	Displays the front LH tire on the information display in the combination meter.
	Off	Does not display the front LH tire on the information display in the combination meter.
FR TIRE DISP	On	Displays the front RH tire on the information display in the combination meter.
	Off	Does not display the front RH tire on the information display in the combination meter.
RL TIRE DISP	On	Displays the rear LH tire on the information display in the combination meter.
	Off	Does not display the rear LH tire on the information display in the combination meter.
RR TIRE DISP	On	Displays the rear RH tire on the information display in the combination meter.
	Off	Does not display the rear RH tire on the information display in the combination meter.
TURN DISP	NO DISP	Does not display the turning status on the information display in the combination meter.
	LH	Displays the LH turning status on the information display in the combination meter.
	RH	Displays the RH turning status on the information display in the combination meter.
	ROUND	Displayed but not used.
ATC 1 DISP	On	Displays active trace control function active status on the information display in the combination meter.
	Off	Displays active trace control function inactive status on the information display in the combination meter.
ATC 2 DISP	On	Displays active trace control function active status on the information display in the combination meter.
	Off	Displays active trace control function inactive status on the information display in the combination meter.
HDC DISP	On	Displays Hill Descent Control active status on the information display on the combination meter.
	Off	Displays Hill Descent Control inactive status on the information display on the combination meter.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# DIAGNOSIS SYSTEM (CHASSIS CONTROL MODULE)

< SYSTEM DESCRIPTION >

[CHASSIS CONTROL]

Test item	Operation	Description
BRAKE HOLD DISP	INACT	Displays inactive status of controls on the information display on the combination meter.
	READY	Displays ready status of Hill Start Assist on the information display on the combination meter.
	ACTIVE	Displays active status of Hill Start Assist on the information display on the combination meter.
	ERROR	Displays inactive status of controls on the information display on the combination meter.
AEB DISP	On	Displays Active Engine Brake (corner) active status on the information display in the combination meter.
	Off	Displays Active Engine Brake (corner) inactive status on the information display in the combination meter.
VEHICLE DISP	On	Displays Active Ride Control (brake) active status on the information display in the combination meter.
	Off	Displays Active Ride Control (brake) inactive status on the information display in the combination meter.
INTERRUPT DISP	NO REQ	Displays inactive status of controls on the information display in the combination meter.
	READY	Displays ready status of Hill Start Assist on the information display in the combination meter.
	ACTIVE	Displays active status of Hill Start Assist on the information display in the combination meter.
	HDC	Displays Hill Descent Control active status on the information display in the combination meter.
ATC 3 DISP	On	Displays active trace control function active status on the information display in the combination meter.
	Off	Displays active trace control function inactive status on the information display in the combination meter.

## RE/PROGRAMMING, CONFIGURATION

Configuration includes the following functions.

Function		Description
Read/Write Configuration	Before replacing ECU	Allows the reading of vehicle specification (Type ID) written in Chassis Control Module to store the specification in CONSULT.
	After replacing ECU	Allows the writing of vehicle information (Type ID) stored in CONSULT into the Chassis Control Module.
Manual Configuration		Allows the writing of vehicle specification (Type ID) into the Chassis Control Module by hand.

**CAUTION:**

**Use “Manual Configuration” only when “TYPE ID” of Chassis Control Module cannot be read.**

# CHASSIS CONTROL MODULE

< ECU DIAGNOSIS INFORMATION >

[CHASSIS CONTROL]

## ECU DIAGNOSIS INFORMATION

### CHASSIS CONTROL MODULE

#### Reference Value

INFOID:0000000010227355

#### CONSULT DATA MONITOR STANDARD VALUE

**NOTE:**

The following table includes information (items) inapplicable to this vehicle. For information (items) applicable to this vehicle, refer to CONSULT display items.

Monitor item	Condition	Reference values in normal operation
IGN VOLT	Ignition switch ON	10 – 16 V
CONTROL MODULE MALF	When chassis control module is normal	Off
	When chassis control module malfunction is detected	On
CAN DIAG STATUS	When diagnosis of CAN communication malfunction is detected	Off
	When diagnosis of CAN communication is normal	On
STP LAMP OFF RELAY 1	Displayed but not used.	—
STP LAMP OFF RELAY 2	Displayed but not used.	—
ESS RELAY	Displayed but not used.	—
VEHICLE SPEED	Vehicle Stopped	0 km/h (0 MPH)
	Driving*	Almost same reading as speedometer (within ±10%)
FR WHEEL SPEED	Vehicle stopped	0 rpm
	Driving*	Increases according to vehicle speed
FL WHEEL SPEED	Vehicle stopped	0 rpm
	Driving*	Increases according to vehicle speed
RR WHEEL SPEED	Vehicle stopped	0 rpm
	Driving*	Increases according to vehicle speed
RL WHEEL SPEED	Vehicle stopped	0 rpm
	Driving*	Increases according to vehicle speed
STEERING ANG SENSOR	When driving straight	0±3.5 deg
	When steering wheel is steered to RH by 90°	Approx. +90 deg
	When steering wheel is steered to LH by 90°	Approx. -90 deg
DECEL G SENSOR	Vehicle stopped	Approx. 0 G
	When during acceleration	Positive value
	When during deceleration	Negative value
SIDE G SENSOR	Vehicle stopped	Approx. 0 G
	When right turn	Negative value
	When left turn	Positive value
YAW RATE SENSOR	Vehicle stopped	Approx. 0 deg/s
	When right turn	Negative value
	When left turn	Positive value
ACCELE PEDAL POSITION	When accelerator pedal is released	0%
	When accelerator pedal is depressed	0 – 100%

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# CHASSIS CONTROL MODULE

< ECU DIAGNOSIS INFORMATION >

[CHASSIS CONTROL]

Monitor item	Condition	Reference values in normal operation
THROTTLE CONTROL	When electric throttle control actuator is normal	NORMAL
	When the electric throttle control actuator does not achieve the requirement (measured value is inaccurate)	INCORR
	When the electric throttle control actuator does not achieve the requirement (temporary prevention)	PREV
	When the electric throttle control actuator does not achieve the requirement (impossible)	IMPOSSI
SHIFT POSITION	Selector lever in any position	Displayed but not used
BRAKE SWITCH 2	When brake pedal is not depressed	Off
	When brake pedal is depressed	On
BRAKE SWITCH 1	When brake pedal is depressed	Off
	When brake pedal is not depressed	On
PRESS SENSOR	When brake pedal is not depressed	Approx. 0 bar
	when brake pedal is depressed	0 – 255 bar
ABS	When ABS function is normal	NORMAL
	When ABS function malfunction is detected	ABNOR
ABS MALF	When ABS function is normal	NORMAL
	When ABS function malfunction is detected	ABNOR
EBD	When EBD function is normal	NORMAL
	When EBD function malfunction is detected	ABNOR
ACCELE PEDAL MALF	When accelerator pedal is normal	NORMAL
	When accelerator pedal malfunction is detected	ABNOR
TCS	When TCS function is normal	NORMAL
	When TCS function malfunction is detected	ABNOR
TCS MALF	When TCS function is normal	NORMAL
	When TCS function malfunction is detected	ABNOR
VDC	When VDC function is normal	NORMAL
	When VDC function malfunction is detected	ABNOR
VDC MALF	When VDC function is normal	NORMAL
	When VDC function malfunction is detected	ABNOR
VDC OFF SWITCH	When VDC OFF switch is OFF	Off
	When VDC OFF switch is ON	On
PARKING BRAKE	When parking brake is inactive	Displayed but not used
	When parking brake is active	Displayed but not used
DRV TRQ CTRL MODE	When correction coefficients are initialized	INITIAL
	When correction is executed	NORMAL
	When correction is stopped (computing is impossible)	STOP 1
	When correction is stopped (computing is possible)	STOP 2
	When correction is limited	LIMIT 1
	When correction is prohibited	PROHIBI

# CHASSIS CONTROL MODULE

< ECU DIAGNOSIS INFORMATION >

[CHASSIS CONTROL]

Monitor item	Condition	Reference values in normal operation	
DRV TRQ CTRL PERMIS 1	When correction is permitted (basic requirement)	PERMIS	A
	When correction is not permitted (basic requirement)	NO PER	B
DRV TRQ CTRL PERMIS 2	When correction is permitted (system requirement)	PERMIS	C
	When correction is not permitted (system requirement)	NO PER	
DRV TRQ CTRL STOP	When correction is requested to stop	REQ	D
	When correction is not requested to stop	NO REQ	
DRV TRQ CTRL PROHIBIT	When prohibition of correction is requested	REQ	E
	When prohibition of correction is not requested	NO REQ	
AEB	When Active Engine Brake (corner) function is active	On	F
	When Active Engine Brake (corner) function is inactive	Off	
ATC 1	When active trace control function is inactive	Off	G
	When active trace control function is active	On	
ATC 2	When active trace control function is inactive	Off	H
	When active trace control function is active	On	
ATC 3	When active trace control function is inactive	Off	I
	When active trace control function is active	On	
ATC 4	When active trace control function is inactive	Off	J
	When active trace control function is active	On	
ATC 5	When active trace control function is inactive	Off	K
	When active trace control function is active	On	
BRAKE HOLD	When Hill Start Assist function is inactive.	INACT	L
	When Hill Start Assist function is ready.	ACT	
	When Hill Start Assist function is active.	RELEA	M
FL TIRE DISP	When the front LH tire is not displayed on the information display in the combination meter	DEF	N
	When the front LH tire is displayed on the information display in the combination meter	1	
FR TIRE DISP	When the front RH tire is not displayed on the information display in the combination meter	DEF	P
	When the front RH tire is displayed on the information display in the combination meter	1	
RL TIRE DISP	When the rear LH tire is not displayed on the information display in the combination meter	DEF	DAS
	When the rear LH tire is displayed on the information display in the combination meter	1	
RR TIRE DISP	When the rear RH tire is not displayed on the information display in the combination meter	DEF	P
	When the rear RH tire is displayed on the information display in the combination meter	1	

# CHASSIS CONTROL MODULE

< ECU DIAGNOSIS INFORMATION >

[CHASSIS CONTROL]

Monitor item	Condition	Reference values in normal operation
VEHICLE DISP	When active ride control (brake) effect is not displayed on the information display in the combination meter	Off
	When active ride control (brake) effect is displayed on the information display in the combination meter	On
INTERRUPT DISP	When interrupt display is not displayed on the information display in the combination meter	NOREQ
	When Hill Start Assist function (ready) is displayed on the information display in the combination meter	HOLD1
	When Hill Start Assist function (active) is displayed on the information display in the combination meter	HOLD2
	When Hill Descent Control function is displayed on the information display in the combination meter	HDC
TURN DISP	When the straight-ahead status is displayed on the information display in the combination meter	N STEER
	When the left turning status is displayed on the information display in the combination meter	LEFT
	When the right turning status is displayed on the information display in the combination meter	RIGHT
ALC LEVEL	When Active Lane Control is turned ON.	Displayed but not used
	When Active Lane Control is operational or is operating.	Displayed but not used
ALC STATUS	When Active Lane Control is OFF	Displayed but not used
	When Active Lane Control is ON	Displayed but not used
BRAKE HOLD DISP	When Hill Start Assist function is not displayed on the information display in the combination meter	INACT
	When Hill Start Assist function (ready) is displayed on the information display in the combination meter	ACT
	When Hill Start Assist function (active) is displayed on the information display in the combination meter	RELEA
ATC DISP	When the activation of Active Trace Control is not displayed on the information display on the combination meter	Off
	When the activation of Active Trace Control is displayed on the information display on the combination meter	On
ARC BRAKE DISP	When Active Ride Control (Brake) function is not displayed on the information display in the combination meter	Off
	When Active Ride Control (Brake) function is displayed on the information display in the combination meter	On

# CHASSIS CONTROL MODULE


< ECU DIAGNOSIS INFORMATION >

[CHASSIS CONTROL]

Monitor item	Condition	Reference values in normal operation
HDC DISP	When Hill Descent Control function is not displayed on the information display in the combination meter	Off
	When Hill Descent Control function is displayed on the information display in the combination meter	On

\*: Check tire pressure under normal conditions.

## TERMINAL LAYOUT



## PHYSICAL VALUES

Terminal No. (Wire color)		Description		Condition	Value (Approx.)
+	-	Signal name	Input/ Output		
3 (P)	Ground	CAN-L	—	—	—
4 (L)		CAN-H	—	—	—
10 (SB)		IGN	Input	Ignition switch ON	6.4 – 16 V
12 (B)		GROUND	—	Ignition switch ON	0 V

## Fail-Safe (Chassis Control Module)

INFOID:0000000010227356

When a malfunction occurs in the chassis control module, the master warning lamp turns ON and an interrupt is displayed on the information display of the combination meter.

DTC	Vehicle condition
C1B92-00	The following functions are suspended. <ul style="list-style-type: none"> <li>Active Trace Control</li> <li>Active Ride Control</li> <li>Active Engine Brake</li> </ul>
C1B93-00	The following functions are suspended. <ul style="list-style-type: none"> <li>Active Trace Control</li> <li>Active Ride Control (engine)</li> <li>Active Engine Brake</li> </ul>
C1B94-00	The following functions are suspended. <ul style="list-style-type: none"> <li>Active Trace Control</li> <li>Active Ride Control (engine)</li> </ul>
C1B95-00	The following functions are suspended. <ul style="list-style-type: none"> <li>Active Trace Control</li> <li>Active Ride Control (brake)</li> </ul>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# CHASSIS CONTROL MODULE

< ECU DIAGNOSIS INFORMATION >

[CHASSIS CONTROL]

DTC	Vehicle condition
C1B99-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
C1BA0-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (brake)</li> </ul>
C1BA2-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (engine)</li> </ul>
C1BA5-00	Normal control
C1BAB-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (engine)</li> </ul>
C1BB2-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
C1BB3-00	
C1BB4-00	
C1BB5-00	
C1BB6-00	Normal control
C1BB7-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
C1BB8-00	
C1BB9-00	
C1BBA-00	
C1BBB-00	Normal control
C1BBC-00	
C1BBD-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
C1BC0-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> </ul>
C1BC1-00	
C1BC2-00	
C1BC3-00	
C1BC4-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Ride Control (brake)</li> </ul>
C1BC5-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> </ul>
C1BC6-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (brake)</li> </ul>
U1A34-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
U1A35-00	
U1A36-00	
U1A39-00	Normal control
U1A3B-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (brake)</li> <li>• Active Engine Brake</li> </ul>
U1A42-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control (engine)</li> </ul>
U1A43-00	



# CHASSIS CONTROL MODULE

< ECU DIAGNOSIS INFORMATION >

[CHASSIS CONTROL]

DTC	Vehicle condition
U1A48-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Trace Control</li> <li>• Active Ride Control</li> <li>• Active Engine Brake</li> </ul>
U1A4A-00	
U1A4B-00	
U1A4E-00	The following functions are suspended. <ul style="list-style-type: none"> <li>• Active Ride Control</li> </ul>

## DTC Inspection Priority Chart

INFOID:000000010227357

When multiple DTCs are displayed simultaneously, check them one by one according to the following priority list.

Priority	Detected item (DTC)
1	<ul style="list-style-type: none"> <li>• U1000-00 CAN COMM CIRCUIT</li> </ul>
2	<ul style="list-style-type: none"> <li>• U1A34-00 BRAKE CONTROL COMM</li> <li>• U1A35-00 BRAKE CONTROL COMM</li> <li>• U1A36-00 BCM/IPDM COMM</li> <li>• U1A39-00 COMBINATION METER COMM</li> <li>• U1A3B-00 TCM COMM</li> <li>• U1A3F-00 AV COMM</li> <li>• U1A42-00 STEERING ANGLE SENSOR COMM</li> <li>• U1A43-00 STEERING ANGLE SENSOR COMM</li> <li>• U1A48-00 ECM/HPCM COMM</li> <li>• U1A4A-00 CONTROL MODULE (CAN)</li> <li>• U1A4B-00 CONTROL MODULE (CAN)</li> <li>• U1A4E-00 ECM/HPCM COMM</li> </ul>
3	<ul style="list-style-type: none"> <li>• C1BBD-00 VARIANT CODING</li> </ul>
4	<ul style="list-style-type: none"> <li>• C1B92-00 BRAKE CONTROL SYSTEM</li> <li>• C1B93-00 ENGINE/HEV SYSTEM</li> <li>• C1B94-00 TM SYSTEM</li> <li>• C1BA0-00 ADAS/CHASSIS CTRL BRAKE SYS</li> <li>• C1BA2-00 STEERING ANGLE SENSOR</li> <li>• C1BA5-00 ADAS/CHASSIS CTRL ENGINE SYS</li> <li>• C1BAB-00 STOP LAMP SW</li> <li>• C1BC0-00 FR WHEEL SENSOR</li> <li>• C1BC1-00 FL WHEEL SENSOR</li> <li>• C1BC2-00 RR WHEEL SENSOR</li> <li>• C1BC3-00 RL WHEEL SENSOR</li> <li>• C1BC4-00 DECEL G SENSOR</li> <li>• C1BC5-00 SIDE G SENSOR</li> <li>• C1BC6-00 PRESSURE SENSOR</li> </ul>
5	<ul style="list-style-type: none"> <li>• C1BB5-00 IGN POWER SUPPLY</li> <li>• C1BB6-00 IGN POWER SUPPLY</li> </ul>
6	<ul style="list-style-type: none"> <li>• C1B95-00 CONTROL MODULE</li> <li>• C1B99-00 CONTROL MODULE</li> <li>• C1BB2-00 CONTROL MODULE</li> <li>• C1BB3-00 CONTROL MODULE</li> <li>• C1BB4-00 CONTROL MODULE</li> <li>• C1BB7-00 CONTROL MODULE</li> <li>• C1BB8-00 CONTROL MODULE</li> <li>• C1BB9-00 CONTROL MODULE</li> <li>• C1BBA-00 CONTROL MODULE</li> <li>• C1BBB-00 CONTROL MODULE</li> <li>• C1BBC-00 CONTROL MODULE</li> </ul>

DAS

# CHASSIS CONTROL MODULE

< ECU DIAGNOSIS INFORMATION >

[CHASSIS CONTROL]

## DTC Index

INFOID:000000010227358

DTC	Display item	Refer to
C1B92-00	BRAKE CONTROL SYSTEM	<a href="#">DAS-207, "DTC Description"</a>
C1B93-00	ENGINE/HEV SYSTEM	<a href="#">DAS-209, "DTC Description"</a>
C1B94-00	TM SYSTEM	<a href="#">DAS-211, "DTC Description"</a>
C1B95-00	CONTROL MODULE	<a href="#">DAS-213, "DTC Description"</a>
C1B99-00	CONTROL NODULE	<a href="#">DAS-214, "DTC Description"</a>
C1BA0-00	ADAS/CHASSIS CTRL BRAKE SYS	<a href="#">DAS-215, "DTC Description"</a>
C1BA2-00	STEERING ANGLE SENSOR	<a href="#">DAS-217, "DTC Description"</a>
C1BA5-00	ADAS/CHASSIS CTRL ENGINE SYS	<a href="#">DAS-219, "DTC Description"</a>
C1BAB-00	STOP LAMP SW	<a href="#">DAS-220, "DTC Description"</a>
C1BB2-00	CONTROL MODULE	<a href="#">DAS-222, "DTC Description"</a>
C1BB3-00	CONTROL MODULE	<a href="#">DAS-223, "DTC Description"</a>
C1BB4-00	CONTROL MODULE	<a href="#">DAS-224, "DTC Description"</a>
C1BB5-00	IGN POWER SUPPLY	<a href="#">DAS-225, "DTC Description"</a>
C1BB6-00	IGN POWER SUPPLY	<a href="#">DAS-228, "DTC Description"</a>
C1BB7-00	CONTROL MODULE	<a href="#">DAS-230, "DTC Description"</a>
C1BB8-00	CONTROL MODULE	<a href="#">DAS-231, "DTC Description"</a>
C1BB9-00	CONTROL MODULE	<a href="#">DAS-232, "DTC Description"</a>
C1BBA-00	CONTROL MODULE	<a href="#">DAS-233, "DTC Description"</a>
C1BBB-00	CONTROL MODULE	<a href="#">DAS-234, "DTC Description"</a>
C1BBC-00	CONTROL MODULE	<a href="#">DAS-235, "DTC Description"</a>
C1BBD-00	VARIANT CODING	<a href="#">DAS-236, "DTC Description"</a>
C1BC0-00	FR WHEEL SENSOR	<a href="#">DAS-237, "DTC Description"</a>
C1BC1-00	FL WHEEL SENSOR	<a href="#">DAS-239, "DTC Description"</a>
C1BC2-00	RR WHEEL SENSOR	<a href="#">DAS-241, "DTC Description"</a>
C1BC3-00	RL WHEEL SENSOR	<a href="#">DAS-243, "DTC Description"</a>
C1BC4-00	DECEL G SENSOR	<a href="#">DAS-245, "DTC Description"</a>
C1BC5-00	SIDE G SENSOR	<a href="#">DAS-247, "DTC Description"</a>
C1BC6-00	PRESSURE SENSOR	<a href="#">DAS-249, "DTC Description"</a>
U1000-00	CAN COMMUNICATION	<a href="#">DAS-252, "DTC Description"</a>
U1A34-00	BRAKE CONTROL COMM	<a href="#">DAS-252, "DTC Description"</a>
U1A35-00	BRAKE CONTROL COMM	<a href="#">DAS-254, "DTC Description"</a>
U1A36-00	BCM/IPDM COMM	<a href="#">DAS-256, "DTC Description"</a>
U1A39-00	COMBINATION METER COMM	<a href="#">DAS-258, "DTC Description"</a>
U1A3B-00	TCM COMM	<a href="#">DAS-260, "DTC Description"</a>
U1A42-00	STEERING ANGLE SENSOR COMM	<a href="#">DAS-262, "DTC Description"</a>
U1A43-00	STEERING ANGLE SENSOR COMM	<a href="#">DAS-264, "DTC Description"</a>
U1A48-00	ECM/HPCM COMM	<a href="#">DAS-266, "DTC Description"</a>
U1A4A-00	CONTROL MODULE (CAN)	<a href="#">DAS-268, "DTC Description"</a>
U1A4B-00	CONTROL MODULE (CAN)	<a href="#">DAS-269, "DTC Description"</a>
U1A4E-00	ECM/HPCM COMM	<a href="#">DAS-270, "DTC Description"</a>

# CHASSIS CONTROL

< WIRING DIAGRAM >


[CHASSIS CONTROL]

## WIRING DIAGRAM

### CHASSIS CONTROL

Wiring Diagram

INFOID:0000000010227359



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

AAOWA0031GB


# CHASSIS CONTROL

< WIRING DIAGRAM >

[CHASSIS CONTROL]

## CHASSIS CONTROL CONNECTORS


Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-


Terminal No.	Color of Wire	Signal Name
15	P	-
16	L	-
19	P	-
20	L	-

Connector No.	M18
Connector Name	BODY CONTROL MODULE
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
5	R	CAN-L
6	L	CAN-H
8	L	CAN-H
9	R	CAN-L

Connector No.	M22
Connector Name	DATA LINK CONNECTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	L	-
14	P	-

Connector No.	M27
Connector Name	JOINT CONNECTOR-M13
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	SB	-
8	SB	-

# CHASSIS CONTROL

< WIRING DIAGRAM >

[CHASSIS CONTROL]


Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
3	L	-
5	L	-
11	P	-
12	P	-
13	P	-
15	P	-

Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Connector No.	M65
Connector Name	JOINT CONNECTOR-M26
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-
6	B	-

Connector No.	M66
Connector Name	STEERING ANGLE SENSOR
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
2	P	-
5	L	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7P	Y	-

AAOIA0126GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P




# CHASSIS CONTROL

< WIRING DIAGRAM >


[CHASSIS CONTROL]

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L

Connector No.	M71
Connector Name	JOINT CONNECTOR-M03
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
11	R	-
12	R	-

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	E16
Connector Name	ECM
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
99	P	CAN-L
100	L	CAN-H

Connector No.	M96
Connector Name	CHASSIS CONTROL UNIT
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	P	CAN-L
4	L	CAN-H
10	SB	IGN
12	B	GND


AAOIA0127GB

# CHASSIS CONTROL

< WIRING DIAGRAM >


[CHASSIS CONTROL]

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-
5	L	-
6	P	-
9	L	-
10	P	-
13	L	-
14	P	-
17	L	-
18	P	-

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
39	L	CAN-H
40	P	CAN-L

Connector No.	E125
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
14	P	CAN-L
26	L	CAN-H

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
61J	L	-
62J	P	-

AAOIA0128GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P



# CHASSIS CONTROL

< WIRING DIAGRAM >

[CHASSIS CONTROL]

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61

Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

Connector No.	F75
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	BLACK



31	32	33	34	35	36	37	38	39	40	47	48
21	22	23	24	25	26	27	28	29	30	45	46
11	12	13	14	15	16	17	18	19	20	43	44
1	2	3	4	5	6	7	8	9	10	41	42

Terminal No.	Color of Wire	Signal Name
23	P	CAN-L
33	L	CAN-H

Connector No.	F42
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



98	97	96	95	94	93	92	91	90	89	88	87
110	109	108	107	106	105	104	103	102	101	100	99

Terminal No.	Color of Wire	Signal Name
87	L	CAN-H
88	P	CAN-L

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY



4	3	2	1
8	7	6	5
12	11	10	9
16	15	14	13
20	19	18	17
24	23	22	21

Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

AAOIA0141GB



# BASIC INSPECTION

## DIAGNOSIS AND REPAIR WORK FLOW

### Work Flow

INFOID:0000000010227360

#### DETAILED FLOW

### 1. INTERVIEW FROM THE CUSTOMER

Clarify customer complaints before inspection. First of all, perform an interview utilizing [DAS-202. "Diagnostic Work Sheet"](#) and reproduce the symptom as well as fully understand it. Ask customer about his/her complaints carefully. Check symptoms by driving vehicle with customer, if necessary.

**CAUTION:**

**Customers are not professional. Never guess easily like "maybe the customer means that..." or "maybe the customer mentions this symptom".**

>> GO TO 2.

### 2. CHECK SYMPTOM

Reproduce the symptom that is indicated by the customer, based on the information from the customer obtained by the interview. Also check that the symptom is not caused by fail-safe mode. Refer to [DAS-191. "Fail-Safe \(Chassis Control Module\)"](#).

**CAUTION:**

**When the symptom is caused by normal operation, fully inspect each portion and obtain the understanding of customer that the symptom is not caused by a malfunction.**

>> GO TO 3.

### 3. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Perform "Self Diagnostic Result" for "CHASSIS CONTROL".

Is DTC detected?

YES >> Record or print self-diagnosis results and freeze frame data (FFD). GO TO 4.

NO >> Inspection End.

### 4. RECHECK THE SYMPTOM

 With CONSULT

Perform DTC confirmation procedures for the malfunctioning system.

**NOTE:**

If some DTCs are detected at the same time, determine the order for performing the diagnosis based on [DAS-193. "DTC Inspection Priority Chart"](#).

Is DTC detected?

YES >> GO TO 5.


NO >> Check harness and connectors based on the information obtained by the interview. Refer to [DAS-171. "Precautions for Harness Repair"](#).

### 5. REPAIR OR REPLACE MALFUNCTIONING PARTS

1. Repair or replace malfunctioning parts.
2. Reconnect part or connector after repairing or replacing.
3. When DTC is detected, erase "Self Diagnostic Result" for "CHASSIS CONTROL".

>> GO TO 6.

### 6. FINAL CHECK

 With CONSULT

1. Check the reference value for "CHASSIS CONTROL".
2. Recheck the symptom and check that the symptom is not reproduced on the same conditions.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[CHASSIS CONTROL]

Is the symptom reproduced?

- YES >> GO TO 3.  
 NO >> Inspection End.

## Diagnostic Work Sheet

INFOID:000000010227361

### Description

- In general, customers have their own criteria for a symptom. Therefore, it is important to understand the symptom and status well enough by interviewing the customer about the symptom carefully. To systemize all the information for the diagnosis, prepare the interview sheet referring to the interview points.
- In some cases, multiple conditions that appear simultaneously may cause a DTC to be detected.

### INTERVIEW SHEET SAMPLE

Interview sheet					
Customer name	MR/MS	Registration number		Initial year registration	
		Vehicle type		VIN	
Storage date		Engine, Traction motor		Mileage	km ( Mile)
Symptom	<input type="checkbox"/> Does not operate ( ) function				
	<input type="checkbox"/> Warning lamp for ( ) turns ON.				
	<input type="checkbox"/> Noise <span style="float: right;"><input type="checkbox"/> Vibration</span>				
	<input type="checkbox"/> Other ( )				
First occurrence	<input type="checkbox"/> Recently <input type="checkbox"/> Other ( )				
Frequency of occurrence	<input type="checkbox"/> Always <input type="checkbox"/> Under a certain conditions of <input type="checkbox"/> Sometimes ( time(s)/day)				
Climate conditions	<input type="checkbox"/> Irrelevant				
	Weather	<input type="checkbox"/> Fine <input type="checkbox"/> Cloud <input type="checkbox"/> Rain <input type="checkbox"/> Snow <input type="checkbox"/> Others ( )			
	Temperature	<input type="checkbox"/> Hot <input type="checkbox"/> Warm <input type="checkbox"/> Cool <input type="checkbox"/> Cold <input type="checkbox"/> Temperature [Approx. °C ( °F)]			
	Relative humidity	<input type="checkbox"/> High <input type="checkbox"/> Moderate <input type="checkbox"/> Low			
Road conditions	<input type="checkbox"/> Urban area <input type="checkbox"/> Suburb area <input type="checkbox"/> Highway <input type="checkbox"/> Mountainous road (uphill or downhill) <input type="checkbox"/> Rough road				
Operating condition, etc.	<input type="checkbox"/> Irrelevant <input type="checkbox"/> When traction motor starts <input type="checkbox"/> During idling <input type="checkbox"/> During driving <input type="checkbox"/> During acceleration <input type="checkbox"/> At constant speed driving <input type="checkbox"/> During deceleration <input type="checkbox"/> During cornering (right curve or left curve) <input type="checkbox"/> When steering wheel is steered (to right or to left)				
Other conditions					

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[CHASSIS CONTROL]

## Interview sheet

Customer name	MR/MS	Registration number		Initial year registration	
		Vehicle type		VIN	
Storage date		Engine, Traction motor		Mileage	km ( Mile)

Vehicle equipment

Memo

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

## ADDITIONAL SERVICE WHEN REPLACING CHASSIS CONTROL MODULE

< BASIC INSPECTION >

[CHASSIS CONTROL]

---

## ADDITIONAL SERVICE WHEN REPLACING CHASSIS CONTROL MODULE

### Description

INFOID:000000010227362

When replaced the chassis control module, configuration of the chassis control module is required. Refer to [DAS-205, "Work Procedure"](#).

# CONFIGURATION (CHASSIS CONTROL MODULE)

< BASIC INSPECTION >

[CHASSIS CONTROL]

## CONFIGURATION (CHASSIS CONTROL MODULE)

### Work Procedure

INFOID:000000010227363

#### CAUTION:

- Use “Manual Configuration” only when “TYPE ID” of the chassis control module cannot be read.
- After configuration, turn the ignition switch from OFF to ON and check that the chassis control warning to information display of combination meter displays OFF after staying illuminated for approximately two seconds.
- If an error occurs during configuration, start over from the beginning.

### 1. CHECKING TYPE ID (1)

Use FAST (service parts catalogue) to search the chassis control module of the applicable vehicle and find “Type ID”.

Is “Type ID” displayed?

YES >> Print out “Type ID” and GO TO 2.

NO >> “Configuration” is not required for the chassis control module. Replace in the usual manner. Refer to [DAS-277, "Removal and Installation"](#).

### 2. CHECKING TYPE ID (2)

ⓂCONSULT Configuration

1. Select “Before Replace ECU” of “Read/Write Configuration”.
2. Check that “Type ID” is displayed on the CONSULT screen.

Is “Type ID” displayed?

YES >> GO TO 3.

NO >> GO TO 7.

### 3. VERIFYING TYPE ID (1)

ⓂCONSULT Configuration

Compare a “Type ID” displayed on the CONSULT screen with the one searched by using FAST (service parts catalogue) to check that these “Type ID” agree with each other.

#### NOTE:

For the “Type ID” searched by using FAST (service parts catalog), use the last five digits of the “Type ID”.

>> GO TO 4.

### 4. SAVING TYPE ID

ⓂCONSULT Configuration

Save “Type ID” on CONSULT.

>> GO TO 5.

### 5. REPLACING CHASSIS CONTROL MODULE (1)

Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

>> GO TO 6.

### 6. WRITING (AUTOMATIC WRITING)

ⓂCONSULT Configuration

1. Select “After Replace ECU” of “Re/programming, Configuration” or that of “Read / Write Configuration”.
2. Select the “Type ID” agreeing with the one stored on CONSULT and the one searched by using FAST (service parts catalogue) to write the “Type ID” into the chassis control module.

#### NOTE:

For the “Type ID” searched by using FAST (service parts catalog), use the last five digits of the “Type ID”.

>> GO TO 9.

### 7. REPLACING CHASSIS CONTROL MODULE (2)

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

## CONFIGURATION (CHASSIS CONTROL MODULE)

< BASIC INSPECTION >

[CHASSIS CONTROL]

Replace the chassis control module. Refer to [DAS-277. "Removal and Installation"](#).

>> GO TO 8.

### 8. WRITING (MANUAL WRITING)

---

Ⓢ CONSULT Configuration

1. Select "Manual Configuration".
2. Select the "Type ID" searched by using FAST (service parts catalogue) to write the "Type ID" into the chassis control module.

**NOTE:**

For the "Type ID" searched by using FAST (service parts catalog), use the last five digits of the "Type ID".

>> GO TO 9.

### 9. VERIFYING TYPE ID (2)

---

Compare "Type ID" written into the chassis control module with the one searched by using FAST (service parts catalogue) to check that these "Type ID" agree with each other.

**NOTE:**

For the "Type ID" searched by using FAST (service parts catalog), use the last five digits of the "Type ID".

>> GO TO 10.

### 10. CHECKING CHASSIS CONTROL WARNING

---

1. Turn the ignition switch OFF.
2. Turn the ignition switch ON and check that the chassis control warning to information display of combination meter displays OFF after staying illuminated for approximately two seconds.

**CAUTION:**

**Never start the engine.**

Is the inspection result normal?

YES >> GO TO 11.

NO >> Perform the "Self Diagnostic Result" of "CHASSIS CONTROL". Refer to [DAS-182. "CONSULT Function"](#).

### 11. PERFORMING SUPPLEMENTARY WORK

---

1. Perform the self-diagnosis of all systems.
2. Erase self-diagnosis results.

>> End of work.

# C1B92-00 BRAKE CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## DTC/CIRCUIT DIAGNOSIS

### C1B92-00 BRAKE CONTROL SYSTEM

#### DTC Description

INFOID:0000000010227368

#### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1B92-00	BRAKE CONTROL SYSTEM (Brake control system)	When a malfunction is detected in ABS actuator and electric unit (control unit) system.

#### POSSIBLE CAUSE

- ABS actuator and electric unit (control unit) system
- Chassis control module

#### FAIL-SAFE

The following functions are suspended.

- Active Ride Control function
- Active Trace Control function
- Active Engine Brake function

#### DTC CONFIRMATION PROCEDURE

##### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

##### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1B92-01" detected?

YES >> Proceed to [DAS-207, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

#### Diagnosis Procedure

INFOID:0000000010227369

##### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

 With CONSULT

Perform self-diagnosis for "ABS".

Is DTC detected?

YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).

NO >> GO TO 2.

##### 2. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform "All DTC Reading".

Is DTC "C1B92", "U1000" or other DTC detected?

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

## C1B92-00 BRAKE CONTROL SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

---

YES ("C1B92-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END



# C1B93-00 ENGINE/HEV SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1B93-00 ENGINE/HEV SYSTEM

### DTC Description

INFOID:000000010227370

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1B93-00	ENGINE/HEV SYSTEM (Engine/HEV system)	When a malfunction is detected in ECM system.

### POSSIBLE CAUSE

- Engine system
- ECM
- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Ride Control (engine) function
- Active Trace Control function
- Active Engine Brake function


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1B93-00" detected?

YES >> Proceed to [DAS-209. "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227371

#### 1. CHECK ECM SYSTEM

 With CONSULT

Perform self-diagnosis for "ENGINE".

Is DTC detected?

YES >> Check the DTC. Refer to [EC-93. "DTC Index"](#).

NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform "All DTC Reading".

Is DTC "C1B93", "U1000" or other DTC detected?

YES ("C1B93-00")>>Replace the chassis control module. Refer to [DAS-277. "Removal and Installation"](#).

## C1B93-00 ENGINE/HEV SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

---

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

# C1B94-00 TRANSMISSION SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1B94-00 TRANSMISSION SYSTEM

### DTC Description

INFOID:000000010227372

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1B94-00	TM SYSTEM (Transmission system)	When a malfunction is detected in transmission system.

### POSSIBLE CAUSE

- Transmission system
- TCM
- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Ride Control (engine) function
- Active Trace Control function


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1B94-00" detected?

YES >> Proceed to [DAS-211, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227373

#### 1. CHECK TRANSMISSION SYSTEM

 With CONSULT

Perform self-diagnosis for "TRANSMISSION".

Is DTC detected?

YES >> Check the DTC. Refer to [TM-63, "DTC Index"](#).

NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform "All DTC Reading".

Is DTC "C1B94-00", "U1000-00" or other DTC detected?

YES ("C1B94-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

## C1B94-00 TRANSMISSION SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

---

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

# C1B95-00 CONTROL MODULE

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1B95-00 CONTROL MODULE

### DTC Description

INFOID:000000010227374

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1B95-00	CONTROL MODULE (Control module)	When a malfunction is detected in chassis control module.

### POSSIBLE CAUSE

- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control (brake) function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1B95-00" detected?

YES >> Proceed to [DAS-213, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227375

#### 1. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1B95" detected?

YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

NO >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

## C1B99-00 CONTROL MODULE

### DTC Description

INFOID:000000010227380

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1B99-00	CONTROL MODULE (Control module)	When a malfunction is detected in chassis control module.

### POSSIBLE CAUSE

- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Ride Control function
- Active Trace Control function
- Active Engine Brake function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If “DTC CONFIRMATION PROCEDURE” has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for “CHASSIS CONTROL”.

Is DTC “C1B99-00” detected?

YES >> Proceed to [DAS-214, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227381

#### 1. PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnosis result for “CHASSIS CONTROL”.
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for “CHASSIS CONTROL”.

Is DTC “C1B99” detected?

YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

NO >> INSPECTION END

# C1BA0-00 ADAS/CHASSIS CONTROL BRAKE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1BA0-00 ADAS/CHASSIS CONTROL BRAKE SYSTEM

### DTC Description

INFOID:000000010227382

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BA0-00	ADAS/CHASSIS CTRL BRAKE SYS (ADAS/Chassis Control brake system)	<ul style="list-style-type: none"><li>When receiving from ABS actuator and electric unit (control unit) that the value of the brake system signal transmitted from the chassis control module to ABS actuator and electric unit (control unit) is malfunctioning.</li></ul>

### POSSIBLE CAUSE

- ABS actuator and electric unit (control unit)
- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control (brake) function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

- Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

- Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BA0-00" and/or "C1BA7-00" detected?

YES ("C1BA0-00") >> Proceed to [DAS-215, "Diagnosis Procedure"](#).

YES ("C1BA0-00" and "C1BA7-00") >> Perform self-diagnosis for "ICC/ADAS".

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227383

#### 1. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SYSTEM

 With CONSULT

Perform self-diagnosis for "ABS".

Is DTC detected?

YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).

NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

 With CONSULT

- Erase self-diagnosis result for "CHASSIS CONTROL".
- Turn the ignition switch OFF and wait for 10 seconds or more.
- Turn the ignition switch ON.
- Perform "All DTC Reading".

Is DTC "C1BA0-00", "U1000-00" or other DTC detected?

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

## C1BA0-00 ADAS/CHASSIS CONTROL BRAKE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

---

YES ("C1BA0-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END



# C1BA2-00 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1BA2-00 STEERING ANGLE SENSOR

### DTC Description

INFOID:000000010227384

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BA2-00	STEERING ANGLE SENSOR (Steering angle sensor)	When a malfunction is detected in steering angle sensor system.

### POSSIBLE CAUSE

- Steering angle sensor
- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Ride Control (engine) function
- Active Trace Control function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

④ With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BA2-00" detected?

YES >> Proceed to [DAS-217, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227385

#### 1. CHECK STEERING ANGLE SENSOR SYSTEM

④ With CONSULT

Perform self-diagnosis for "ABS".

Is DTC detected?

YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).

NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

④ With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform "All DTC Reading".

Is DTC "C1BA2-00", "U1000-00" or other DTC detected?

YES ("C1BA2-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES (other DTC)>>Check the DTC.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

# C1BA2-00 STEERING ANGLE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

---

NO >> INSPECTION END

# C1BA5-00 ADAS/CHASSIS CONTROL ENGINE SYSTEM

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1BA5-00 ADAS/CHASSIS CONTROL ENGINE SYSTEM

### DTC Description

INFOID:000000010227386

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BA5-00	ADAS/CHASSIS CTRL ENGINE SYS (ADAS/Chassis control engine system)	<ul style="list-style-type: none"><li>When receiving from ECM that the value of the engine system signal transmitted from the chassis control module to ECM is malfunctioning.</li></ul>

### POSSIBLE CAUSE

- Chassis Control Module

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

- Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

- Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BA5-00" detected?

- YES >> Proceed to [DAS-219, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227387

#### 1. CHECK ADAS CONTROL UNIT SYSTEM

 With CONSULT

Perform self-diagnosis for "ECM".

Is DTC detected?

- YES >> Check the DTC. Refer to [EC-93, "DTC Index"](#).
- NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

 With CONSULT

- Erase self-diagnosis result for "CHASSIS CONTROL".
- Turn the ignition switch OFF and wait for 10 seconds or more.
- Turn the ignition switch ON.
- Perform "All DTC Reading".

Is DTC "C1BA5-00", "U1000-00" or other DTC detected?

- YES ("C1BA5-00")>> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).
- YES ("U1000-00")>> Refer to [DAS-251, "Diagnosis Procedure"](#).
- YES (other DTC)>> Check the DTC.
- NO >> INSPECTION END

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

# C1BAB-00 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1BAB-00 STOP LAMP SWITCH

### DTC Description

INFOID:000000010227396

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BAB-00	STOP LAMP SW (Stop lamp switch)	When a malfunction is detected in stop lamp switch system.

### POSSIBLE CAUSE

- Stop lamp switch
- BCM
- Chassis Control Module

### FAIL-SAFE

The following functions are suspended.

- Active Ride Control (engine) function
- Active Trace Control function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BAB-00" detected?

YES >> Proceed to [DAS-220, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227397

#### 1. CHECK STOP LAMP SWITCH SYSTEM

 With CONSULT

Perform self-diagnosis for "BCM".

Is DTC detected?

YES >> Check the DTC. Refer to [BCS-48, "DTC Index"](#) (with Intelligent Key) or [BCS-108, "DTC Index"](#) (without Intelligent Key).

NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform "All DTC Reading".

Is DTC "C1BAB", "U1000-00" or other DTC detected?

YES ("C1BAB-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

# C1BAB-00 STOP LAMP SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

## C1BB2-00 CONTROL MODULE

### DTC Description

INFOID:000000010227408

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BB2-00	CONTROL MODULE (Control module)	When a malfunction is detected in chassis control module.

### POSSIBLE CAUSE

- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BB2-00" detected?

YES >> Proceed to [DAS-222, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227409

#### 1. PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BB2-00" detected?

YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

NO >> INSPECTION END

C1BB3-00 CONTROL MODULE

DTC Description

INFOID:000000010227410

DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BB3-00	CONTROL MODULE (Control module)	When a malfunction is detected in chassis control module.

POSSIBLE CAUSE

- Chassis control module

FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BB3-00" detected?

YES >> Proceed to [DAS-223, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000010227411

1. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BB3-00" detected?

YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

NO >> INSPECTION END

DAS

## C1BB4-00 CONTROL MODULE

## DTC Description

INFOID:000000010227412

## DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BB4-00	CONTROL MODULE (Control module)	When a malfunction is detected in chassis control module.

## POSSIBLE CAUSE

- Chassis control module

## FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function


## DTC CONFIRMATION PROCEDURE

## 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

## 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BB4-00" detected?

- YES >> Proceed to [DAS-224, "Diagnosis Procedure"](#).  
 NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).  
 NO-2 >> Confirmation after repair: INSPECTION END

## Diagnosis Procedure

INFOID:000000010227413

## 1. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BB4-00" detected?

- YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).  
 NO >> INSPECTION END



# C1BB5-00 IGNITION POWER SUPPLY

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1BB5-00 IGNITION POWER SUPPLY

### DTC Description

INFOID:000000010227414

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BB5-00	IGN POWER SUPPLY (Ignition power supply)	Ignition power supply voltage of chassis control module is as shown below. • Ignition power supply voltage: $6.4\text{ V} \geq$ Ignition power supply voltage

### POSSIBLE CAUSE

- Harness or connector
- Fuse
- Ignition power supply system
- Battery
- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

Ⓜ With CONSULT

1. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BB5-00" detected?

YES >> Proceed to [DAS-225, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:000000010227415

Regarding Wiring Diagram information, refer to [DAS-195, "Wiring Diagram"](#).

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect chassis control module harness connector
3. Check the connector for disconnection or looseness.
4. Check the pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace error-detected parts, securely lock the harness connector, and GO TO 2.

#### 2. PERFORM DELF-DIAGNOSIS (1)

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

# C1BB5-00 IGNITION POWER SUPPLY

[CHASSIS CONTROL]

< DTC/CIRCUIT DIAGNOSIS >

1. Connect chassis control module harness connector.
2. Perform "Self Diagnostic Result" for "CHASSIS CONTROL".

Is DTC "C1BB5-00" detected?

- YES >> GO TO 3.  
NO >> Inspection End.

## 3.CHECK CHASSIS CONTROL MODULE IGNITION POWER SUPPLY (1)

1. Turn the ignition switch OFF.
2. Disconnect chassis control module harness connector.
3. Check the voltage between chassis control module harness connector and ground.

Chassis control module		—	Voltage (Approx.)
Connector	Terminal		
M96	10	Ground	0 V

4. Turn the ignition switch ON.  
**CAUTION:**  
**Never start engine.**
5. Check the voltage between chassis control module harness connector and ground.

Chassis control module		—	Voltage (Approx.)
Connector	Terminal		
M96	10	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> GO TO 4.

## 4.CHECK CHASSIS CONTROL MODULE IGNITION POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#30).
3. Check the continuity and for short circuit between chassis control module harness connector terminal (10) and 10A fuse (#30).
4. Check the continuity between chassis control module harness connector and the ground.

Chassis control module		—	Continuity
Connector	Terminal		
M96	10	Ground	No

Is the inspection result normal?

- YES >> Perform trouble diagnosis for ignition power supply.  
NO >> Repair or replace malfunctioning parts.

## 5.CHECK CHASSIS CONTROL MODULE GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check the continuity between chassis control module harness connector and ground.

Chassis control module		—	Continuity
Connector	Terminal		
M96	12	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Repair or replace malfunctioning parts.

## 6.PERFORM SELF-DIAGNOSIS (2)

1. Connect chassis control module harness connector.
2. Perform "Self Diagnostic Result" for "CHASSIS CONTROL".

# C1BB5-00 IGNITION POWER SUPPLY

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

Is DTC "C1BB5-00" detected?

YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

NO >> Inspection End.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

# C1BB6-00 IGNITION POWER SUPPLY

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1BB6-00 IGNITION POWER SUPPLY

### DTC Description

INFOID:000000010227416

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BB6-00	IGNITION POWER SUPPLY (ignition power supply)	Ignition power supply voltage of chassis control module is as shown below. • Ignition power supply voltage: $16\text{ V} \leq$ Ignition power supply voltage

### POSSIBLE CAUSE

- Harness or connector
- Fuse
- Ignition power supply system
- Battery
- Chassis control module

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform "Self Diagnostic Result" for "CHASSIS CONTROL".

Is DTC "C1BB6-00" detected?

- YES >> Proceed to [DAS-228, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:000000010227417

Regarding Wiring Diagram information, refer to [DAS-195, "Wiring Diagram"](#).

#### 1. CHECK CONNECTOR

1. Turn the ignition switch OFF.
2. Disconnect chassis control module harness connector
3. Check the connector for disconnection or looseness.
4. Check the pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> GO TO 2.
- NO >> Repair or replace the malfunctioning parts, securely lock the harness connector, and GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS (1)

1. Connect chassis control module harness connector.
2. Perform "Self Diagnostic Result" for "CHASSIS CONTROL".

Is DTC "C1BB6-00" detected?

- YES >> GO TO 3.
- NO >> Inspection End.

# C1BB6-00 IGNITION POWER SUPPLY

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## 3. CHECK CHASSIS CONTROL MODULE IGNITION POWER SUPPLY (1)

1. Turn the ignition switch OFF.
2. Disconnect chassis control module harness connector.
3. Check the voltage between chassis control module harness connector and ground.

Chassis control module		—	Voltage (Approx.)
Connector	Terminal		
M96	10	Ground	0 V

4. Turn the ignition switch ON.  
**CAUTION:**  
**Never start engine.**
5. Check the voltage between chassis control module harness connector and ground.

Chassis control module		—	Voltage (Approx.)
Connector	Terminal		
M96	10	Ground	Battery voltage

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> GO TO 4.

## 4. CHECK CHASSIS CONTROL MODULE IGNITION POWER SUPPLY CIRCUIT

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#30).
3. Check the continuity and for short circuit between chassis control module harness connector terminal (10) and 10A fuse (#30).
4. Check the continuity between chassis control module harness connector and the ground.

Chassis control module		—	Continuity
Connector	Terminal		
M96	10	Ground	No

Is the inspection result normal?

- YES >> Perform trouble diagnosis for ignition power supply.
- NO >> Repair or replace the malfunctioning parts.

## 5. CHECK CHASSIS CONTROL MODULE GROUND CIRCUIT

1. Turn the ignition switch OFF.
2. Check the continuity between chassis control module harness connector and ground.

Chassis control module		—	Continuity
Connector	Terminal		
M96	12	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair or replace the malfunctioning parts.

## 6. PERFORM DELF-DIAGNOSIS (1)

1. Connect chassis control module harness connector.
2. Perform "Self Diagnostic Result" for "CHASSIS CONTROL".

Is DTC "C1BB6-00" detected?

- YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).
- NO >> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

## C1BB7-00 CONTROL MODULE

### DTC Description

INFOID:000000010227418

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BB7-00	CONTROL MODULE (Control module)	When a malfunction is detected in chassis control module.

### POSSIBLE CAUSE

- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

#### Is DTC "C1BB7-00" detected?

YES >> Proceed to [DAS-230, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227419

#### 1. PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for "CHASSIS CONTROL".

#### Is DTC "C1BB7-00" detected?

YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

NO >> INSPECTION END

C1BB8-00 CONTROL MODULE

DTC Description

INFOID:000000010227420

DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BB8-00	CONTROL MODULE (Control module)	When a malfunction is detected in chassis control module.

POSSIBLE CAUSE

- Chassis control module

FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BB8-00" detected?

YES >> Proceed to [DAS-231, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000010227421

1. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BB8-00" detected?

YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

NO >> INSPECTION END

DAS

## C1BB9-00 CONTROL MODULE

### DTC Description

INFOID:000000010227422

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BB9-00	CONTROL MODULE (Control module)	When a malfunction is detected in chassis control module.

### POSSIBLE CAUSE

- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BB9-00" detected?

YES >> Proceed to [DAS-232, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227423

#### 1. PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BB9-00" detected?

YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

NO >> INSPECTION END



C1BBA-00 CONTROL MODULE

DTC Description

INFOID:000000010227424

DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BBA-00	CONTROL MODULE (Control module)	When a malfunction is detected in chassis control module.

POSSIBLE CAUSE

- Chassis control module

FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If “DTC CONFIRMATION PROCEDURE” has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

④ With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for “CHASSIS CONTROL”.

Is DTC “C1BBA-00” detected?

YES >> Proceed to [DAS-233, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000010227425

1. PERFORM SELF-DIAGNOSIS

④ With CONSULT

1. Erase self-diagnosis result for “CHASSIS CONTROL”.
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for “CHASSIS CONTROL”.

Is DTC “C1BBA-00” detected?

YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

NO >> INSPECTION END

## C1BBB-00 CONTROL MODULE

### DTC Description

INFOID:000000010227426

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BBB-00	CONTROL MODULE (Control module)	When a malfunction is detected in chassis control module.

### POSSIBLE CAUSE

- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

#### Is DTC "C1BBB-00" detected?

YES >> Proceed to [DAS-234, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227427

#### 1. PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for "CHASSIS CONTROL".

#### Is DTC "C1BBB-00" detected?

YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

NO >> INSPECTION END

## C1BBC-00 CONTROL MODULE

### DTC Description

INFOID:000000010227428

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BBC-00	CONTROL MODULE (Control module)	When a malfunction is detected in chassis control module.

### POSSIBLE CAUSE

- Chassis control module

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If “DTC CONFIRMATION PROCEDURE” has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for “CHASSIS CONTROL”.

Is DTC “C1BBC-00” detected?

YES >> Proceed to [DAS-235. "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227429

#### 1. PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnosis result for “CHASSIS CONTROL”.
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for “CHASSIS CONTROL”.

Is DTC “C1BBC-00” detected?

YES >> Replace the chassis control module. Refer to [DAS-277. "Removal and Installation"](#).

NO >> INSPECTION END

DAS

C1BBD-00 VARIANT CODING

DTC Description

INFOID:000000010227430

DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BBD-00	VARIANT CODING (Variant coding)	When variant coding is incomplete.

POSSIBLE CAUSE

- Chassis control module

FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If “DTC CONFIRMATION PROCEDURE” has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for “CHASSIS CONTROL”.

Is DTC “C1BBD-00” detected?

YES >> Proceed to [DAS-236, "Diagnosis Procedure"](#).


NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000010227431

1. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for “CHASSIS CONTROL”.
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for “CHASSIS CONTROL”.

Is DTC “C1BBD-00” detected?

YES >> Perform configuration. Refer to [DAS-205, "Work Procedure"](#).

NO >> INSPECTION END

# C1BC0-00 FRONT RIGHT WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1BC0-00 FRONT RIGHT WHEEL SENSOR

### DTC Description

INFOID:0000000010227432

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BC0-00	FR WHEEL SENSOR (Front right wheel sensor)	When a malfunction is detected in front right wheel sensor system.

### POSSIBLE CAUSE

- Front right wheel sensor
- Front right sensor rotor
- ABS actuator and electric unit (control unit)
- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Start the engine.
2. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
3. Stop the vehicle.
4. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

5. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BC0-00" detected?

YES >> Proceed to [DAS-237, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:0000000010227433

#### 1. CHECK FRONT RH WHEEL SENSOR SYSTEM

 With CONSULT

Perform self-diagnosis for "ABS".

Is DTC detected?

YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).

NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

## C1BC0-00 FRONT RIGHT WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

---

4. Perform "All DTC Reading".

Is DTC "C1BC0-00", "U1000-00" or other DTC detected?

YES ("C1BC0-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

# C1BC1-00 FRONT LEFT WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1BC1-00 FRONT LEFT WHEEL SENSOR

### DTC Description

INFOID:000000010227434

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BC1-00	FL WHEEL SENSOR (Front left wheel sensor)	When a malfunction is detected in front left wheel sensor system.

### POSSIBLE CAUSE

- Front left wheel sensor
- Front left sensor rotor
- ABS actuator and electric unit (control unit)
- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Start the engine.
2. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
3. Stop the vehicle.
4. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

5. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BC1-00" detected?

- YES >> Proceed to [DAS-239, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227435

#### 1. CHECK FRONT LH WHEEL SENSOR SYSTEM

 With CONSULT

Perform self-diagnosis for "ABS".

Is DTC detected?

- YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).
- NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

## C1BC1-00 FRONT LEFT WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

---

4. Perform "All DTC Reading".

Is DTC "C1BC1-00", "U1000-00" or other DTC detected?

YES ("C1BC1-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END



# C1BC2-00 REAR RIGHT WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1BC2-00 REAR RIGHT WHEEL SENSOR

### DTC Description

INFOID:0000000010227436

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BC2-00	RR WHEEL SENSOR (Rear right wheel sensor)	When a malfunction is detected in rear right wheel sensor system.

### POSSIBLE CAUSE

- Rear right wheel sensor
- Rear right sensor rotor
- ABS actuator and electric unit (control unit)
- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Start the engine.
2. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
3. Stop the vehicle.
4. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

5. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BC2-00" detected?

- YES >> Proceed to [DAS-241, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:0000000010227437

#### 1. CHECK REAR RH WHEEL SENSOR SYSTEM

 With CONSULT

Perform self-diagnosis for "ABS".

Is DTC detected?

- YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).
- NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

## C1BC2-00 REAR RIGHT WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

---

4. Perform "All DTC Reading".

Is DTC "C1BC2-00", "U1000-00" or other DTC detected?

YES ("C1BC2-00")>>Replace the chassis control module. Refer to [DAS-277. "Removal and Installation"](#).

YES ("U1000-00")>>Refer to [DAS-251. "Diagnosis Procedure"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

# C1BC3-00 REAR LEFT WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1BC3-00 REAR LEFT WHEEL SENSOR

### DTC Description

INFOID:0000000010227438

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BC3-00	RL WHEEL SENSOR (Rear left wheel sensor)	When a malfunction is detected in rear left wheel sensor system.

### POSSIBLE CAUSE

- Rear left wheel sensor
- Rear left sensor rotor
- ABS actuator and electric unit (control unit)
- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Start the engine.
2. Drive the vehicle at approx. 30 km/h (19 MPH) or more for approx. 1 minute.
3. Stop the vehicle.
4. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

5. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BC3-00" detected?

- YES >> Proceed to [DAS-243, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:0000000010227439

#### 1. CHECK REAR LH WHEEL SENSOR SYSTEM

 With CONSULT

Perform self-diagnosis for "ABS".

Is DTC detected?

- YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).
- NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.

A

B

C

D

E

F

G

H

I

J

K

L

M

N

DAS

P

## C1BC3-00 REAR LEFT WHEEL SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

---

4. Perform "All DTC Reading".

Is DTC "C1BC3-00", "U1000-00" or other DTC detected?

YES ("C1BC3-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

## C1BC4-00 DECEL G SENSOR

### DTC Description

INFOID:000000010227440

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BC4-00	DECEL G SENSOR (Decel G sensor)	When a malfunction is detected in decel G sensor system.

### POSSIBLE CAUSE

- Yaw rate/side/decel G sensor [integrated in ABS actuator and electric unit (control unit)]
- ABS actuator and electric unit (control unit)
- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Ride Control (brake) function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BC4-00" detected?

YES >> Proceed to [DAS-245, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227441

#### 1. CHECK DECEL G SENSOR SYSTEM

With CONSULT

Perform self-diagnosis for "ABS".

Is DTC detected?

YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).

NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform "All DTC Reading".

Is DTC "C1BC4-00", "U1000-00" or other DTC detected?

YES ("C1BC4-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES (other DTC)>>Check the DTC.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# C1BC4-00 DECEL G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

---

NO >> INSPECTION END

C1BC5-00 SIDE G SENSOR

DTC Description

INFOID:000000010227442

DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BC5-00	SIDE G SENSOR (Side G sensor)	When a malfunction is detected in side G sensor system.

POSSIBLE CAUSE

- Yaw rate/side/decel G sensor [integrated in ABS actuator and electric unit (control unit)]
- ABS actuator and electric unit (control unit)
- Chassis control module

FAIL-SAFE

The following functions are suspended.

- Active Trace Control function

DTC CONFIRMATION PROCEDURE

1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

2. CHECK DTC DETECTION

④ With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BC5-00" detected?

YES >> Proceed to [DAS-247, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

Diagnosis Procedure

INFOID:000000010227443

1. CHECK SIDE G SENSOR SYSTEM

④ With CONSULT

Perform self-diagnosis for "ABS".

Is DTC detected?

YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).

NO >> GO TO 2.

2. PERFORM SELF-DIAGNOSIS

④ With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform "All DTC Reading".

Is DTC "C1BC5-00", "U1000-00" or other DTC detected?

YES ("C1BC5-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES (other DTC)>>Check the DTC.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# C1BC5-00 SIDE G SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

---

NO >> INSPECTION END



# C1BC6-00 PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## C1BC6-00 PRESSURE SENSOR

### DTC Description

INFOID:000000010227444

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
C1BC6-00	PRESSURE SENSOR (Pressure sensor)	When a malfunction is detected in brake fluid pressure system.

### POSSIBLE CAUSE

- ABS actuator and electric unit (control unit)
- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control (brake) function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

④ With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "C1BC6-00" detected?

YES >> Proceed to [DAS-249, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227445

#### 1. CHECK BRAKE FLUID PRESSURE SYSTEM

④ With CONSULT

Perform self-diagnosis for "ABS".

Is DTC detected?

YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).

NO >> GO TO 2.

#### 2. PERFORM SELF-DIAGNOSIS

④ With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform "All DTC Reading".

Is DTC "C1BC6-00", "U1000-00" or other DTC detected?

YES ("C1BC6-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES (other DTC)>>Check the DTC.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# C1BC6-00 PRESSURE SENSOR

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

---

NO >> INSPECTION END

# U1000-00 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## U1000-00 CAN COMM CIRCUIT

### DTC Logic

INFOID:000000010355424

### DTC DETECTION LOGIC

CONSULT Display	DTC Detection Condition	Possible Cause
CAN COMM CIRCUIT [U1000-00]	Chassis Control module is not transmitting or receiving CAN communication signal for 2 seconds or more.	CAN communication system.

### Diagnosis Procedure

INFOID:000000010355425

#### 1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON and wait for 2 seconds or more.
2. Perform Self Diagnostic Result for CHASSIS CONTROL.

#### Is CAN COMM CIRCUIT displayed?

- YES >> Refer to [LAN-17, "Trouble Diagnosis Flow Chart"](#).  
NO >> Refer to [GI-41, "Intermittent Incident"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U1A34-00 BRAKE CONTROL COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## U1A34-00 BRAKE CONTROL COMMUNICATION

### DTC Description

INFOID:000000010227456

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
U1A34-00	BRAKE CONTROL COMM (Brake control communication)	When chassis control module is not receiving CAN communication signal [between chassis control module and ABS actuator and electric unit (control unit)] for 2 seconds or more.

### POSSIBLE CAUSE

- ABS actuator and electric unit (control unit)
- Chassis control module
- CAN communication line

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control Function
- Active Ride Control Function
- Active Engine Brake Function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "U1A34-00" detected?

- YES >> Proceed to [DAS-252, "Diagnosis Procedure"](#).  
NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).  
NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227457

Regarding Wiring Diagram information, refer to [DAS-195, "Wiring Diagram"](#).

#### 1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

 With CONSULT

1. Select "CAN Diagnosis Support Monitor". of "CHASSIS CONTROL".
2. Check malfunction between each control unit connected to chassis control module.

Check the result of "PRESENT"?

- Refer to >> [LAN-9, "CAN Communication Control Circuit"](#).  
"TRANSMIT DIAG" is other than "OK" >> GO TO 2.  
"ABS" other than "OK" >> GO TO 3.

#### 2. CHECK TRANSMITTING SIDE UNIT

# U1A34-00 BRAKE CONTROL COMMUNICATION

[CHASSIS CONTROL]

< DTC/CIRCUIT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Disconnect chassis control module harness connector.
3. Check the chassis control module harness connector terminals No. 3 and 4 for damage or loose connection.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 5.

## 3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check ABS actuator and electric unit (control unit) harness connector terminals (CAN communication line) or damage or loose connection.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 4.

## 4. PERFORM SELF-DIAGNOSIS [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

 With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform self-diagnosis for "ABS".

Is DTC detected?

YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).

NO >> GO TO 5.

## 5. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Connect chassis control module harness connector.
2. Erase self-diagnosis result for "CHASSIS CONTROL".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform "All DTC Reading".

Is DTC "U1000-00", "U1A34-00" or other DTC detected?

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES ("U1A34-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U1A35-00 BRAKE CONTROL COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## U1A35-00 BRAKE CONTROL COMMUNICATION

### DTC Description

INFOID:000000010227458

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
U1A35-00	BRAKE CONTROL COMM (Brake control communication)	A calculated signal value differs between a signal transmitted from the ABS actuator and electric unit (control unit) and a signal received from chassis control module via CAN communication.

### POSSIBLE CAUSE

- ABS actuator and electric unit (control unit)
- Chassis control module
- CAN communication line

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "U1A35-00" detected?

YES >> Proceed to [DAS-254, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227459

Regarding Wiring Diagram information, refer to [DAS-195, "Wiring Diagram"](#).

#### 1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

 With CONSULT

1. Select "CAN Diagnosis Support Monitor" of "CHASSIS CONTROL".
2. Check malfunction between each control unit connected to chassis control module.

Check the result of "PRESENT"?

>> Refer to [LAN-9, "CAN Communication Control Circuit"](#).

"TRANSMIT DIAG" is other than "OK">>GO TO 2.

"ABS" other than "OK">>GO TO 3.

#### 2. CHECK TRANSMITTING SIDE UNIT

# U1A35-00 BRAKE CONTROL COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

1. Turn the ignition switch OFF.
2. Disconnect chassis control module harness connector.
3. Check the chassis control module harness connector terminals No. 3 and 4 for damage or loose connection.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Recheck terminals for damage or loose connection. Refer to [DAS-171. "Precautions for Harness Repair"](#), and GO TO 5.

## 3. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

1. Turn the ignition switch OFF.
2. Disconnect ABS actuator and electric unit (control unit) harness connector.
3. Check ABS actuator and electric unit (control unit) harness connector terminals (CAN communication line) or damage or loose connection.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Recheck terminals for damage or loose connection. Refer to [DAS-171. "Precautions for Harness Repair"](#), and GO TO 4.

## 4. PERFORM SELF-DIAGNOSIS [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

 With CONSULT

1. Connect ABS actuator and electric unit (control unit) harness connector.
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform self-diagnosis for "ABS".

Is DTC detected?

YES >> Check the DTC. Refer to [BRC-55. "DTC Index"](#).

NO >> GO TO 5.

## 5. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Connect chassis control module harness connector.
2. Erase self-diagnosis result for "CHASSIS CONTROL".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform "All DTC Reading".

Is DTC "U1000-00", "U1A35-00" or other DTC detected?

YES ("U1000-00")>>Refer to [DAS-251. "Diagnosis Procedure"](#).

YES ("U1A35-00")>>Replace the chassis control module. Refer to [DAS-277. "Removal and Installation"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U1A36-00 BCM/IPDM COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## U1A36-00 BCM/IPDM COMMUNICATION

### DTC Description

INFOID:000000010227460

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
U1A36-00	BCM/IPDM COMM (BCM/IPDM communication)	When chassis control module is not receiving CAN communication signal (between chassis control module and BCM) for 2 seconds or more.

### POSSIBLE CAUSE

- BCM
- Chassis control module
- CAN communication line

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "U1A36-00" detected?

- YES >> Proceed to [DAS-256, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227461

Regarding Wiring Diagram information, refer to [DAS-195, "Wiring Diagram"](#).

#### 1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

 With CONSULT

1. Select "CAN Diagnosis Support Monitor" of "CHASSIS CONTROL".
2. Check malfunction between each control unit connected to chassis control module.

Check the result of "PRESENT"?

>> Refer to [LAN-9, "CAN Communication Control Circuit"](#).

"TRANSMIT DIAG" is other than "OK">>GO TO 2.

"BCM" other than "OK">>GO TO 3.

#### 2. CHECK TRANSMITTING SIDE UNIT

1. Turn the ignition switch OFF.



# U1A36-00 BCM/IPDM COMMUNICATION

[CHASSIS CONTROL]

## < DTC/CIRCUIT DIAGNOSIS >

2. Disconnect chassis control module harness connector.
3. Check the chassis control module harness connector terminals No. 3 and 4 for damage or loose connection.

### Is the inspection result normal?

YES >> GO TO 5.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 5.

## 3.CHECK BCM

1. Turn the ignition switch OFF.
2. Disconnect BCM harness connector.
3. Check BCM harness connector terminals (CAN communication line) or damage or loose connection.

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 4.

## 4.PFEFORM SELF-DIAGNOSIS (BCM)

### With CONSULT

1. Connect BCM harness connector.
2. Erase self-diagnosis result for "BCM".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform self-diagnosis for "BCM".

### Is DTC detected?

YES >> Check the DTC. Refer to [BCS-108, "DTC Index"](#).

NO >> GO TO 5.

## 5.PERFORM SELF-DIAGNOSIS

### With CONSULT

1. Connect chassis control module harness connector.
2. Erase self-diagnosis result for "CHASSIS CONTROL".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform "All DTC Reading".

### Is DTC "U1000-00", "U1A36-00" or other DTC detected?

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES ("U1A36-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U1A39-00 COMBINATION METER COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## U1A39-00 COMBINATION METER COMMUNICATION

### DTC Description

INFOID:000000010227462

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
U1A39-00	COMBINATION METER COMM (Combination meter communication)	When chassis control module is not receiving CAN communication signal (between chassis control module and combination meter) for 2 seconds or more.

### POSSIBLE CAUSE

- Combination meter
- Chassis control module
- CAN communication line

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "U1A39-00" detected?

YES >> Proceed to [DAS-258, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227463

Regarding Wiring Diagram information, refer to [DAS-195, "Wiring Diagram"](#).

#### 1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

 With CONSULT

1. Select "CAN Diagnosis Support Monitor" of "CHASSIS CONTROL".
2. Check malfunction between each control unit connected to chassis control module.

Check the result of "PRESENT"?

>> Refer to [LAN-9, "CAN Communication Control Circuit"](#).

"TRANSMIT DIAG" is other than "OK">>GO TO 2.

"METER/M&A" other than "OK">>GO TO 3.

#### 2. CHECK TRANSMITTING SIDE UNIT

1. Turn the ignition switch OFF.
2. Disconnect chassis control module harness connector.
3. Check the chassis control module harness connector terminals No. 3 and 4 for damage or loose connection.

Is the inspection result normal?

YES >> GO TO 5.

# U1A39-00 COMBINATION METER COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7. "Precautions for Harness Repair"](#), and GO TO 5.

## 3. CHECK COMBINATION METER

1. Turn the ignition switch OFF.
2. Disconnect combination meter harness connector.
3. Check combination meter harness connector terminals (CAN communication line) or damage or loose connection.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7. "Precautions for Harness Repair"](#), and GO TO 4.

## 4. PFEFORM SELF-DIAGNOSIS (COMBINATION METER)

 With CONSULT

1. Connect combination meter harness connector.
2. Erase self-diagnosis result for "MATER/M&A".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform self-diagnosis for "METER/M&A".

Is DTC detected?

YES >> Check the DTC. Refer to [MWI-30. "DTC Index"](#).

NO >> GO TO 5.

## 5. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Connect chassis control module harness connector.
2. Erase self-diagnosis result for "CHASSIS CONTROL".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform "All DTC Reading".

Is DTC "U1000-00", "U1A39-00" or other DTC detected?

YES ("U1000-00")>>Refer to [DAS-251. "Diagnosis Procedure"](#).

YES ("U1A39-00")>>Replace the chassis control module. Refer to [DAS-277. "Removal and Installation"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

## U1A3B-00 TCM COMMUNICATION

### DTC Description

INFOID:0000000010227464

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
U1A3B-00	TCM COMM (TCM communication)	When chassis control module is not receiving CAN communication signal (between chassis control module and TCM) for 2 seconds or more.

### POSSIBLE CAUSE

- TCM
- Chassis control module
- CAN communication line

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control (engine) function
- Active Engine Brake

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If “DTC CONFIRMATION PROCEDURE” has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for “CHASSIS CONTROL”.

Is DTC “U1A3B-00” detected?

- YES >> Proceed to [DAS-260, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:0000000010227465

Regarding Wiring Diagram information, refer to [DAS-195, "Wiring Diagram"](#).

#### 1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

 With CONSULT

1. Select “CAN Diagnosis Support Monitor” of “CHASSIS CONTROL”.
2. Check malfunction between each control unit connected to chassis control module.

Check the result of “PRESENT”?

>> Refer to [LAN-9, "CAN Communication Control Circuit"](#).

“TRANSMIT DIAG” is other than “OK”>>GO TO 2.

“TRANSMISSION” other than “OK”>>GO TO 3.

#### 2. CHECK TRANSMITTING SIDE UNIT

1. Turn the ignition switch OFF.

# U1A3B-00 TCM COMMUNICATION

[CHASSIS CONTROL]

< DTC/CIRCUIT DIAGNOSIS >

2. Disconnect chassis control module harness connector.
3. Check the chassis control module harness connector terminals No. 3 and 4 for damage or loose connection.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 5.

## 3.CHECK TCM

1. Turn the ignition switch OFF.
2. Disconnect TCM harness connector.
3. Check TCM harness connector terminals (CAN communication line) or damage or loose connection.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 4.

## 4.PFEFORM SELF-DIAGNOSIS (TCM)

 With CONSULT

1. Connect TCM harness connector.
2. Erase self-diagnosis result for "TRANSMISSION".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform self-diagnosis for "TRANSMISSION".

Is DTC detected?

YES >> Check the DTC. Refer to [TM-63, "DTC Index"](#).

NO >> GO TO 5.

## 5.PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Connect chassis control module harness connector.
2. Erase self-diagnosis result for "CHASSIS CONTROL".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform "All DTC Reading".

Is DTC "U1000-00", "U1A3B-00" or other DTC detected?

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES ("U1A3B-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U1A42-00 STEERING ANGLE SENSOR COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## U1A42-00 STEERING ANGLE SENSOR COMMUNICATION

### DTC Description

INFOID:000000010227472

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
U1A42-00	STEERING ANGLE SENSOR COMM (Steering angle sensor communication)	When chassis control module is not receiving CAN communication signal (between chassis control module and steering angle sensor) for 2 seconds or more.

### POSSIBLE CAUSE

- Steering angle sensor
- Chassis control module
- CAN communication line

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control (engine) function


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "U1A42-00" detected?

YES >> Proceed to [DAS-262. "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227473

Regarding Wiring Diagram information, refer to [DAS-195. "Wiring Diagram"](#).

#### 1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

 With CONSULT

1. Select "CAN Diagnosis Support Monitor" of "CHASSIS CONTROL".
2. Check malfunction between each control unit connected to chassis control module.

Check the result of "PRESENT"?

>> Refer to [LAN-9. "CAN Communication Control Circuit"](#).

"TRANSMIT DIAG" is other than "OK">>GO TO 2.

"STRG" other than "OK">>GO TO 3.

#### 2. CHECK TRANSMITTING SIDE UNIT

# U1A42-00 STEERING ANGLE SENSOR COMMUNICATION

[CHASSIS CONTROL]

## < DTC/CIRCUIT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Disconnect chassis control module harness connector.
3. Check the chassis control module harness connector terminals No. 3 and 4 for damage or loose connection.

### Is the inspection result normal?

YES >> GO TO 5.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 5.

## 3. CHECK STEERING ANGLE SENSOR

1. Turn the ignition switch OFF.
2. Disconnect steering angle sensor harness connector.
3. Check steering angle sensor harness connector terminals (CAN communication line) or damage or loose connection.

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 4.

## 4. PFEFORM SELF-DIAGNOSIS [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

### With CONSULT

1. Connect steering angle sensor harness connector.
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform self-diagnosis for "ABS".

### Is DTC detected?

YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).

NO >> GO TO 5.

## 5. PERFORM SELF-DIAGNOSIS

### With CONSULT

1. Connect chassis control module harness connector.
2. Erase self-diagnosis result for "CHASSIS CONTROL".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform "All DTC Reading".

### Is DTC "U1000-00", "U1A42-00" other DTC detected?

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES ("U1A42-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U1A43-00 STEERING ANGLE SENSOR COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## U1A43-00 STEERING ANGLE SENSOR COMMUNICATION

### DTC Description

INFOID:000000010227474

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
U1A43-00	STEERING ANGLE SENSOR COMM (Steering angle sensor communication)	A calculated signal value differs between a signal transmitted from the steering angle sensor and a signal received from chassis control module via CAN communication.

### POSSIBLE CAUSE

- Steering angle sensor
- Chassis control module
- CAN communication line

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control (engine) function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "U1A43-00" detected?

YES >> Proceed to [DAS-264. "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41. "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227475

Regarding Wiring Diagram information, refer to [DAS-195. "Wiring Diagram"](#).

#### 1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

 With CONSULT

1. Select "CAN Diagnosis Support Monitor" of "CHASSIS CONTROL".
2. Check malfunction between each control unit connected to chassis control module.

Check the result of "PRESENT"?

>> Refer to [LAN-9. "CAN Communication Control Circuit"](#).

"TRANSMIT DIAG" is other than "OK">>GO TO 2.

"STRG" other than "OK">>GO TO 3.

#### 2. CHECK TRANSMITTING SIDE UNIT



# U1A43-00 STEERING ANGLE SENSOR COMMUNICATION

[CHASSIS CONTROL]

## < DTC/CIRCUIT DIAGNOSIS >

1. Turn the ignition switch OFF.
2. Disconnect chassis control module harness connector.
3. Check the chassis control module harness connector terminals No. 3 and 4 for damage or loose connection.

### Is the inspection result normal?

YES >> GO TO 5.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 5.

## 3. CHECK STEERING ANGLE SENSOR

1. Turn the ignition switch OFF.
2. Disconnect steering angle sensor harness connector.
3. Check steering angle sensor harness connector terminals (CAN communication line) or damage or loose connection.

### Is the inspection result normal?

YES >> GO TO 4.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 4.

## 4. PFEFORM SELF-DIAGNOSIS [ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)]

### With CONSULT

1. Connect steering angle sensor harness connector.
2. Erase self-diagnosis result for "ABS".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform self-diagnosis for "ABS".

### Is DTC detected?

YES >> Check the DTC. Refer to [BRC-55, "DTC Index"](#).

NO >> GO TO 5.

## 5. PERFORM SELF-DIAGNOSIS

### With CONSULT

1. Connect chassis control module harness connector.
2. Erase self-diagnosis result for "CHASSIS CONTROL".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform "All DTC Reading".

### Is DTC "U1000-00", "U1A43-00" or other DTC detected?

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES ("U1A43-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U1A48-00 ECM/HPCM COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## U1A48-00 ECM/HPCM COMMUNICATION

### DTC Description

INFOID:000000010227478

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
U1A48-00	ECM/HPCM COMM (ECM/HPCM communication)	When chassis control module is not receiving CAN communication signal (between chassis control module and ECM) for 2 seconds or more.

### POSSIBLE CAUSE

- ECM
- Chassis control module
- CAN communication line

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function


### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

Is DTC "U1A48-00" detected?

YES >> Proceed to [DAS-266, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227479

Regarding Wiring Diagram information, refer to [DAS-195, "Wiring Diagram"](#).

#### 1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

 With CONSULT

1. Select and "CAN Diagnosis Support Monitor" of "CHASSIS CONTROL".
2. Check malfunction between each control unit connected to chassis control module.

Check the result of "PRESENT"?

>> Refer to [LAN-9, "CAN Communication Control Circuit"](#).

"TRANSMIT DIAG" is other than "OK">>GO TO 2.

"ENGINE" other than "OK">>GO TO 3.

#### 2. CHECK TRANSMITTING SIDE UNIT

1. Turn the ignition switch OFF.

# U1A48-00 ECM/HPCM COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

2. Disconnect chassis control module harness connector.
3. Check the chassis control module harness connector terminals No. 3 and 4 for damage or loose connection.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 5.

## 3. CHECK ECM

1. Turn the ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check ECM harness connector terminals (CAN communication line) or damage or loose connection.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 4.

## 4. PERFORM SELF-DIAGNOSIS (ECM)

 With CONSULT

1. Connect ECM harness connector.
2. Erase self-diagnosis result for "ENGINE".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform self-diagnosis for "ENGINE".

Is DTC detected?

YES >> Check the DTC. Refer to [EC-93, "DTC Index"](#).

NO >> GO TO 5.

## 5. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Connect chassis control module harness connector.
2. Erase self-diagnosis result for "CHASSIS CONTROL".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform "All DTC Reading".

Is DTC "U1000-00", "U1A48-00" or other DTC detected?

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES ("U1A48-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U1A4A-00 CONTROL MODULE (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## U1A4A-00 CONTROL MODULE (CAN)

### DTC Description

INFOID:000000010227480

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
U1A4A-00	CONTROL MODULE (CAN) [Control module (CAN)]	• When a malfunction is detected in chassis control module (transmission via CAN communication is impossible)

### POSSIBLE CAUSE

- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

#### CAUTION:

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

#### Is DTC "U1A4A-00" detected?

- YES >> Proceed to [DAS-268, "Diagnosis Procedure"](#).  
NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).  
NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227481

#### 1. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for "CHASSIS CONTROL".

#### Is DTC "U1A4A-00" detected?

- YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).  
NO >> INSPECTION END

# U1A4B-00 CONTROL MODULE (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## U1A4B-00 CONTROL MODULE (CAN)

### DTC Description

INFOID:000000010227482

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
U1A4B-00	CONTROL MODULE (CAN) [Control module (CAN)]	When a malfunction is detected in chassis control module.

### POSSIBLE CAUSE

- Chassis control module

### FAIL-SAFE

The following functions are suspended.

- Active Trace Control function
- Active Ride Control function
- Active Engine Brake function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

#### Is DTC "U1A4B-00" detected?

YES >> Proceed to [DAS-269, "Diagnosis Procedure"](#).

NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).

NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227483

#### 1. PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Erase self-diagnosis result for "CHASSIS CONTROL".
2. Turn the ignition switch OFF and wait for 10 seconds or more.
3. Turn the ignition switch ON.
4. Perform self-diagnosis for "CHASSIS CONTROL".

#### Is DTC "U1A4B-00" detected?

YES >> Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

NO >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

# U1A4E-00 ECM/HPCM COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

## U1A4E-00 ECM/HPCM COMMUNICATION

### DTC Description

INFOID:000000010227486

### DTC DETECTION LOGIC

DTC	Display Item (Trouble diagnosis content)	Malfunction detected condition
U1A4E-00	ECM/HPCM COMM (ECM/HPCM communication)	A calculated signal value differs between a signal transmitted from the ECM and a signal received from chassis control module via CAN communication.

### POSSIBLE CAUSE

- ECM
- Chassis control module
- CAN communication line

### FAIL-SAFE

The following functions are suspended.

- Active Ride Control (engine) function

### DTC CONFIRMATION PROCEDURE

#### 1. PRECONDITIONING

If "DTC CONFIRMATION PROCEDURE" has been previously conducted, always turn the ignition switch OFF and wait at least 10 seconds before conducting the next test.

>> GO TO 2.

#### 2. CHECK DTC DETECTION

 With CONSULT

1. Turn the ignition switch OFF to ON.

**CAUTION:**

**Be sure to wait of 10 seconds after turning ignition switch OFF or ON.**

2. Perform self-diagnosis for "CHASSIS CONTROL".

#### Is DTC "U1A4E-00" detected?

- YES >> Proceed to [DAS-270, "Diagnosis Procedure"](#).  
NO-1 >> To check malfunction symptom before repair: Refer to [GI-41, "Intermittent Incident"](#).  
NO-2 >> Confirmation after repair: INSPECTION END

### Diagnosis Procedure

INFOID:000000010227487

Regarding Wiring Diagram information, refer to [DAS-195, "Wiring Diagram"](#).

#### 1. CHECK CAN DIAGNOSIS SUPPORT MONITOR

 With CONSULT

1. Select "CAN Diagnosis Support Monitor" of "CHASSIS CONTROL".
2. Check malfunction history between each control unit connected to chassis control module.

#### Check the result of "PAST"?

- All items are "OK">>Refer to [GI-41, "Intermittent Incident"](#).  
"TRANSMIT DIAG" is other than "OK">>GO TO 2.  
"ENGINE" other than "OK">>GO TO 3.

#### 2. CHECK TRANSMITTING SIDE UNIT

1. Turn the ignition switch OFF.
2. Disconnect chassis control module harness connector.

# U1A4E-00 ECM/HPCM COMMUNICATION

< DTC/CIRCUIT DIAGNOSIS >

[CHASSIS CONTROL]

3. Check the chassis control module harness connector terminals No. 3 and 4 for damage or loose connection.

Is the inspection result normal?

YES >> GO TO 5.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 5.

## 3.CHECK ECM

1. Turn the ignition switch OFF.
2. Disconnect ECM harness connector.
3. Check ECM harness connector terminals (CAN communication line) or damage or loose connection.

Is the inspection result normal?

YES >> GO TO 4.

NO >> Recheck terminals for damage or loose connection. Refer to [LAN-7, "Precautions for Harness Repair"](#), and GO TO 4.

## 4.PFEFORM SELF-DIAGNOSIS (ECM)

 With CONSULT

1. Connect ECM harness connector.
2. Erase self-diagnosis result for "ENGINE".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform self-diagnosis for "ENGINE".

Is DTC detected?

YES >> Check the DTC. Refer to [EC-93, "DTC Index"](#).

NO >> GO TO 5.

## 5.PERFORM SELF-DIAGNOSIS

 With CONSULT

1. Connect chassis control module harness connector.
2. Erase self-diagnosis result for "CHASSIS CONTROL".
3. Turn the ignition switch OFF and wait for 10 seconds or more.
4. Turn the ignition switch ON.
5. Perform "All DTC Reading".

Is DTC "U1000-00", "U1A4E-00" or other DTC detected?

YES ("U1000-00")>>Refer to [DAS-251, "Diagnosis Procedure"](#).

YES ("U1A4E-00")>>Replace the chassis control module. Refer to [DAS-277, "Removal and Installation"](#).

YES (other DTC)>>Check the DTC.

NO >> INSPECTION END

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000010227488

Regarding Wiring Diagram information, refer to [DAS-195. "Wiring Diagram"](#).

**1. CHECK CHASSIS CONTROL MODULE IGNITION POWER SUPPLY**

1. Turn the ignition switch OFF.
2. Disconnect chassis control module harness connector.
3. Check the voltage between chassis control module harness connector and ground.

Chassis control module		—	Voltage
Connector	Terminal		
M96	10	Ground	Approx. 0 V

4. Turn the ignition switch ON  
**CAUTION:**  
**Never start the engine.**
5. Check the voltage between chassis control module harness connector and ground.

Chassis control module		—	Voltage
Connector	Terminal		
M96	10	Ground	6.4–16 V

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> GO TO 2.

**2. CHECK CHASSIS CONTROL MODULE IGNITION POWER SUPPLY CIRCUIT**

1. Turn the ignition switch OFF.
2. Check the 10A fuse (#30).
3. Check the continuity and short circuit between chassis control module harness connector terminal (10) and 10A fuse (#30).

Is the inspection result normal?

- YES >> Perform trouble diagnosis for ignition power supply.

**3. CHECK CHASSIS CONTROL MODULE GROUND CIRCUIT**

Check the continuity between chassis control module harness connector and ground.

Chassis control module		—	Continuity
Connector	Terminal		
M96	12	Ground	Yes

Is the inspection result normal?

- YES >> GO TO 4.
- NO >> Repair or replace the malfunctioning parts.

**4. CHECK TERMINAL**

Check the chassis control module pin terminals for damage or loose connection with harness connector.

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Repair or replace the malfunctioning parts.



SYMPTOM DIAGNOSIS

CHASSIS CONTROL

Active Engine Brake

INFOID:0000000010385726

NOTE:

- For the operational conditions of Active Engine Brake, refer to [DAS-175, "System Description - Active Engine Brake"](#).
- Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

Symptom		Possible cause	Inspection item	
Active Engine Brake inoperative/ineffective.	No CVT gear ratio assist.	Active Engine Brake selected OFF in the vehicle information display.	Change Active Engine Brake selection in the vehicle information display to ON.	
		Certain roads, inclement weather or driving conditions.	System is functioning normally. Confirm the condition with the customer. Refer to <a href="#">DAS-181, "Precautions for Chassis Control (Engine Brake, Active Ride, and Active Trace)"</a> .	
		<ul style="list-style-type: none"> <li>• Road wheel tire condition is abnormal</li> <li>• Road wheel tire size is abnormal.</li> </ul>	Check the road wheel tire.	
	Lower CVT gear ratio not achieved.	Continuously	Active Engine Brake selected OFF in the vehicle information display.	Change Active Engine Brake selection in the vehicle information display to ON.
		At cornering	<ul style="list-style-type: none"> <li>• Wheel alignment</li> <li>• Steering malfunction</li> </ul>	Refer to "STEERING WHEEL TURNING FORCE IS HEAVY OR LIGHT" <a href="#">STC-31, "Description"</a> .
		While coming to a complete stop	Certain roads, inclement weather or driving conditions.	System is functioning normally. Confirm the condition with the customer. Refer to <a href="#">DAS-181, "Precautions for Chassis Control (Engine Brake, Active Ride, and Active Trace)"</a> .

Active Ride Control

INFOID:0000000010405793

NOTE:

- For the operational conditions of Active Ride Control, refer to [DAS-176, "System Description - Active Ride Control"](#).
- Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

DAS

# CHASSIS CONTROL

< SYMPTOM DIAGNOSIS >

[CHASSIS CONTROL]

Symptom		Possible cause	Inspection item	
Active Ride Control in-operative/ineffective.	No Active Ride Control assist.	VDC OFF switch is engaged.	Turn VDC OFF switch to the OFF position.	
		Engine or transmission DTCs present.	Refer to EC DTCs <a href="#">EC-93. "DTC Index"</a> , or TM DTCs <a href="#">TM-63. "DTC Index"</a> as necessary.	
	Bumpy ride on bumpy road.	Certain roads, inclement weather or driving conditions.	System is functioning normally. Confirm the condition with the customer. Refer to <a href="#">DAS-181. "Precautions for Chassis Control (Engine Brake, Active Ride, and Active Trace)"</a> .	
		<ul style="list-style-type: none"> <li>Road wheel tire condition is abnormal</li> <li>Road wheel tire size is abnormal.</li> </ul>	Check the road wheel tire.	
	High vehicle pitch on bumps.	Ineffective pitch control	<ul style="list-style-type: none"> <li>Wheel alignment</li> <li>Steering malfunction</li> </ul>	Change Active Engine Brake selection in the vehicle information display to ON.
		No pitch control	Brake system malfunction	Refer to <a href="#">BRC-54. "DTC Inspection Priority Chart"</a> .
No engine torque control on curves		Certain roads, inclement weather or driving conditions.	System is functioning normally. Confirm the condition with the customer. Refer to <a href="#">DAS-181. "Precautions for Chassis Control (Engine Brake, Active Ride, and Active Trace)"</a> .	

## Active Trace Control

INFOID:000000010405794

### NOTE:

- For the operational conditions of Active Trace Control, refer to [DAS-176. "System Description - Active Trace Control"](#).
- Perform the self-diagnosis with CONSULT before the symptom diagnosis. Perform the trouble diagnosis if any DTC is detected.

# CHASSIS CONTROL

< SYMPTOM DIAGNOSIS >

[CHASSIS CONTROL]

Symptom		Possible cause	Inspection item	
Active Trace Control inoperative/ineffective.	No Active Trace Control assist.	Active Trace Control selected OFF in the vehicle information display.	Change Active Trace Control selection in the vehicle information display to ON.	
		VDC OFF switch is engaged.	Turn VDC OFF switch to the OFF position.	
		Certain roads, inclement weather or driving conditions.	System is functioning normally. Confirm the condition with the customer. Refer to <a href="#">DAS-181, "Precautions for Chassis Control (Engine Brake, Active Ride, and Active Trace)"</a> .	
		<ul style="list-style-type: none"> <li>• Road wheel tire condition is abnormal</li> <li>• Road wheel tire size is abnormal.</li> </ul>	Check the road wheel tire.	
	Excessive lag on turns.	On turns	Wheel alignment	Repair alignment malfunction.
		While zigzagging	Steering malfunction	"STEERING WHEEL TURNING FORCE IS HEAVY OR LIGHT" <a href="#">STC-31, "Description"</a> .
		With quick lane change	Certain roads, inclement weather or driving conditions.	System is functioning normally. Confirm the condition with the customer. Refer to <a href="#">DAS-181, "Precautions for Chassis Control (Engine Brake, Active Ride, and Active Trace)"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS

## NORMAL OPERATING CONDITION

### Description

INFOID:000000010406112

#### CHASSIS CONTROL


- Chassis Control will not provide all the necessary controls to replace driver intervention. It is not designed to prevent loss of control. It is the driver's responsibility to stay alert, drive safely, keep the vehicle in the traveling lane, and be in control of vehicle at all times.
- Chassis Control is primarily intended for use on well-developed freeways or highways. It may not perform satisfactorily in certain roads, weather or driving conditions.
- Using Chassis Control under some conditions of road, corner or severe weather could lead to an unexpected system operation. In such conditions, driver needs to correct the vehicle's direction with driver's steering operation to avoid accidents.
- When Chassis Control is operating, avoid excessive or sudden steering maneuvers. Otherwise, you could lose control of the vehicle.
- Engine Brake Control is designed to enhance braking feel and traceability at corners.
- Active Ride Control is designed to enhance handling and drive comfort.
- Active Trace Control is designed to enhance traceability at corners and smooth vehicle movement for more confident driving.
- Chassis Control may not function properly under the following conditions:
  - During bad weather (rain, fog, snow, wind, etc.).
  - When driving on slippery roads, such as on ice or snow, etc.
  - When driving on winding or uneven roads.
  - When driving with a tire that is not within normal tire conditions (for example, tire wear, low tire pressure, installation of spare tire, tire chains, non-standard wheels).
  - When the vehicle is equipped with non-original steering parts or suspension parts.
- The functions of Chassis Control may or may not operate properly under the following conditions:
  - On roads covered with water, dirt or snow, etc.
  - On roads where there are sharp curves.

## REMOVAL AND INSTALLATION

### CHASSIS CONTROL MODULE

Exploded View

INFOID:000000010227489



1. Steering member

2. Chassis control module

⇐ Front

### Removal and Installation

INFOID:000000010227490

**CAUTION:**

When replacing chassis control module, configuration of chassis control module is required. Refer to [DAS-205, "Work Procedure"](#).

#### REMOVAL

**NOTE:**

If the chassis control module is replaced, user registration information is erased, and all setting items for Nissan InTuition related parts are erased.

1. Remove the glove box assembly. Refer to [IP-23, "Removal and Installation"](#).
2. Release the pawl and remove the chassis control module.

**CAUTION:**

**Do not drop the chassis control module.**

#### INSTALLATION

Installation is in the reverse order of removal.

**CAUTION:**

When replacing the chassis control module, perform the configuration of chassis control module. Refer to [DAS-205, "Work Procedure"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
P

DAS