

# SECTION **SEC**

## SECURITY CONTROL SYSTEM

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

### CONTENTS

<b>WITH INTELLIGENT KEY SYSTEM</b>	<b>COMMON ITEM</b> .....19
<b>PRECAUTION</b> ..... 5	COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) .....19
<b>PRECAUTIONS</b> ..... 5	<b>INTELLIGENT KEY</b> .....19
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" .....5	INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) .....20
Precaution for Work .....5	<b>IMMU</b> .....22
<b>PREPARATION</b> ..... 6	IMMU : CONSULT Function (BCM - IMMU) .....22
<b>PREPARATION</b> ..... 6	<b>THEFT ALM</b> .....23
Special Service Tool .....6	THEFT ALM : CONSULT Function (BCM - THEFT ALM) .....23
<b>SYSTEM DESCRIPTION</b> ..... 7	<b>DIAGNOSIS SYSTEM (IPDM E/R)</b> .....24
<b>COMPONENT PARTS</b> ..... 7	CONSULT Function (IPDM E/R) .....24
Component Parts Location .....7	<b>ECU DIAGNOSIS INFORMATION</b> .....30
NATS Antenna Amp. ....9	<b>ECM, IPDM E/R, BCM</b> .....30
<b>SYSTEM</b> .....10	List of ECU Reference .....30
<b>INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION</b> .....10	<b>WIRING DIAGRAM</b> .....31
INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Diagram .....10	<b>ENGINE START FUNCTION</b> .....31
INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description .....10	Wiring Diagram .....31
<b>NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS...</b> 12	<b>NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS</b> .....44
NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Diagram .....13	Wiring Diagram .....44
NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description .....13	<b>VEHICLE SECURITY SYSTEM</b> .....53
<b>VEHICLE SECURITY SYSTEM</b> .....15	Wiring Diagram .....53
VEHICLE SECURITY SYSTEM : System Diagram .....15	<b>BASIC INSPECTION</b> .....66
VEHICLE SECURITY SYSTEM : System Description .....15	<b>DIAGNOSIS AND REPAIR WORK FLOW</b> .....66
<b>DIAGNOSIS SYSTEM (BCM)</b> .....19	Work Flow .....66
	<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT</b> .....69
	<b>ECM</b> .....69

SEC

ECM : Description .....	69	Diagnosis Procedure .....	87
ECM : Work Procedure .....	69	Component Inspection .....	88
<b>BCM .....</b>	<b>69</b>	<b>B2557 VEHICLE SPEED .....</b>	<b>89</b>
BCM : Description .....	69	DTC Logic .....	89
BCM : Work Procedure .....	69	Diagnosis Procedure .....	89
<b>DTC/CIRCUIT DIAGNOSIS .....</b>	<b>71</b>	<b>B2602 SHIFT POSITION .....</b>	<b>90</b>
<b>P1610 LOCK MODE .....</b>	<b>71</b>	DTC Logic .....	90
Description .....	71	Diagnosis Procedure .....	90
DTC Logic .....	71	Component Inspection .....	92
Diagnosis Procedure .....	71	<b>B2604 SHIFT POSITION .....</b>	<b>93</b>
<b>P1611 ID DISCORD, IMMU-ECM .....</b>	<b>72</b>	DTC Logic .....	93
DTC Logic .....	72	Diagnosis Procedure .....	93
Diagnosis Procedure .....	72	Component Inspection .....	95
<b>P1612 CHAIN OF ECM-IMMU .....</b>	<b>73</b>	<b>B2608 STARTER RELAY .....</b>	<b>96</b>
DTC Logic .....	73	DTC Logic .....	96
Diagnosis Procedure .....	73	Diagnosis Procedure .....	96
<b>P161D IMMOBILIZER .....</b>	<b>74</b>	<b>B260F ENGINE STATUS .....</b>	<b>97</b>
DTC Logic .....	74	Description .....	97
Diagnosis Procedure .....	74	DTC Description .....	97
<b>P161E IMMOBILIZER .....</b>	<b>75</b>	Diagnosis Procedure .....	97
DTC Logic .....	75	<b>B261E VEHICLE TYPE .....</b>	<b>99</b>
Diagnosis Procedure .....	75	Description .....	99
<b>P161F IMMOBILIZER .....</b>	<b>76</b>	DTC Logic .....	99
DTC Logic .....	76	Diagnosis Procedure .....	99
Diagnosis Procedure .....	76	<b>B26FC KEY REGISTRATION .....</b>	<b>101</b>
<b>B2190 NATS ANTENNA AMP. ....</b>	<b>77</b>	DTC Logic .....	101
Description .....	77	Diagnosis Procedure .....	101
DTC Logic .....	77	<b>B27D1 START CUT RELAY OFF .....</b>	<b>102</b>
Diagnosis Procedure .....	77	DTC Logic .....	102
<b>B2191 DIFFERENCE OF KEY .....</b>	<b>80</b>	Diagnosis Procedure .....	102
DTC Logic .....	80	Component Inspection .....	104
Diagnosis Procedure .....	80	<b>B27D2 START CUT RELAY ON .....</b>	<b>105</b>
<b>B2192 ID DISCORD, IMMU-ECM .....</b>	<b>81</b>	DTC Logic .....	105
DTC Logic .....	81	Diagnosis Procedure .....	105
Diagnosis Procedure .....	81	Component Inspection .....	107
<b>B2193 CHAIN OF ECM-IMMU .....</b>	<b>82</b>	<b>HEADLAMP FUNCTION .....</b>	<b>108</b>
DTC Logic .....	82	Component Function Check .....	108
Diagnosis Procedure .....	82	Diagnosis Procedure .....	108
<b>B2196 DONGLE UNIT .....</b>	<b>83</b>	<b>HORN FUNCTION .....</b>	<b>109</b>
Description .....	83	Component Function Check .....	109
DTC Logic .....	83	Component Inspection .....	109
Diagnosis Procedure .....	83	<b>SECURITY INDICATOR LAMP .....</b>	<b>110</b>
<b>B2198 NATS ANTENNA AMP. ....</b>	<b>85</b>	Component Function Check .....	110
DTC Logic .....	85	Diagnosis Procedure .....	110
Diagnosis Procedure .....	85	<b>SYMPTOM DIAGNOSIS .....</b>	<b>112</b>
<b>B2556 PUSH-BUTTON IGNITION SWITCH ....</b>	<b>87</b>	<b>ENGINE DOES NOT START WHEN INTELLI-</b>	
DTC Logic .....	87	<b>  GENT KEY IS INSIDE OF VEHICLE .....</b>	<b>112</b>
		Description .....	112

Diagnosis Procedure .....	112	Component Parts Location .....	124	
<b>SECURITY INDICATOR LAMP DOES NOT TURN ON OR BLINK .....</b>	<b>113</b>	NATS Antenna Amp. ....	125	A
Description .....	113	<b>SYSTEM .....</b>	<b>126</b>	
Diagnosis Procedure .....	113	<b>NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS. 126</b>		B
<b>VEHICLE SECURITY SYSTEM CANNOT BE SET .....</b>	<b>114</b>	NISSAN VEHICLE IMMOBILIZER SYSTEM- NATS : System Diagram .....	126	
<b>INTELLIGENT KEY .....</b>	<b>114</b>	NISSAN VEHICLE IMMOBILIZER SYSTEM- NATS : System Description .....	126	C
INTELLIGENT KEY : Description .....	114	<b>VEHICLE SECURITY SYSTEM .....</b>	<b>127</b>	
INTELLIGENT KEY : Diagnosis Procedure .....	114	VEHICLE SECURITY SYSTEM : System Dia- gram .....	127	D
<b>DOOR REQUEST SWITCH .....</b>	<b>114</b>	VEHICLE SECURITY SYSTEM : System Descrip- tion .....	127	E
DOOR REQUEST SWITCH : Description .....	114	<b>DIAGNOSIS SYSTEM (BCM) .....</b>	<b>130</b>	
DOOR REQUEST SWITCH : Diagnosis Proce- dure .....	114	<b>COMMON ITEM .....</b>	<b>130</b>	F
<b>DOOR KEY CYLINDER .....</b>	<b>114</b>	COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) .....	130	
DOOR KEY CYLINDER : Description .....	115	<b>IMMU .....</b>	<b>130</b>	G
DOOR KEY CYLINDER : Diagnosis Procedure ..	115	IMMU : CONSULT Function (BCM - IMMU) .....	130	
<b>VEHICLE SECURITY ALARM DOES NOT ACTIVATE .....</b>	<b>116</b>	<b>THEFT ALM .....</b>	<b>131</b>	H
Description .....	116	THEFT ALM : CONSULT Function (BCM - THEFT ALM) .....	131	
Diagnosis Procedure .....	116	<b>DIAGNOSIS SYSTEM (IPDM E/R) .....</b>	<b>132</b>	I
<b>PANIC ALARM FUNCTION DOES NOT OP- ERATE .....</b>	<b>117</b>	CONSULT Function (IPDM E/R) .....	132	
Description .....	117	<b>ECU DIAGNOSIS INFORMATION .....</b>	<b>138</b>	J
Diagnosis Procedure .....	117	<b>ECM, IPDM E/R, BCM .....</b>	<b>138</b>	
<b>REMOVAL AND INSTALLATION .....</b>	<b>118</b>	List of ECU Reference .....	138	
<b>NATS ANTENNA AMP. ....</b>	<b>118</b>	<b>WIRING DIAGRAM .....</b>	<b>139</b>	
Exploded View .....	118	<b>NVIS .....</b>	<b>139</b>	L
Removal and Installation .....	118	Wiring Diagram .....	139	
<b>PUSH-BUTTON IGNITION SWITCH .....</b>	<b>120</b>	<b>VEHICLE SECURITY SYSTEM .....</b>	<b>149</b>	M
Removal and Installation .....	120	Wiring Diagram .....	149	
<b>DONGLE UNIT .....</b>	<b>121</b>	<b>BASIC INSPECTION .....</b>	<b>162</b>	
Removal and Installation .....	121	<b>DIAGNOSIS AND REPAIR WORKFLOW .....</b>	<b>162</b>	N
<b>WITHOUT INTELLIGENT KEY SYSTEM</b>		Work Flow .....	162	
<b>PRECAUTION .....</b>	<b>122</b>	<b>INSPECTION AND ADJUSTMENT .....</b>	<b>165</b>	O
<b>PRECAUTIONS .....</b>	<b>122</b>	<b>ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT .....</b>	<b>165</b>	
Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TEN- SIONER" .....	122	ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement ...	165	P
Precaution for Work .....	122	<b>ECM RE-COMMUNICATING FUNCTION .....</b>	<b>165</b>	
<b>PREPARATION .....</b>	<b>123</b>	ECM RE-COMMUNICATING FUNCTION : De- scription .....	165	
<b>PREPARATION .....</b>	<b>123</b>	ECM RE-COMMUNICATING FUNCTION : Spe- cial Repair Requirement .....	165	
Special Service Tool .....	123			
<b>SYSTEM DESCRIPTION .....</b>	<b>124</b>			
<b>COMPONENT PARTS .....</b>	<b>124</b>			

<b>KEYFOB ID REGISTRATION</b> .....	166	Diagnosis Procedure .....	181
Description .....	166	<b>B2608 STARTER RELAY</b> .....	184
<b>DTC/CIRCUIT DIAGNOSIS</b> .....	167	DTC Logic .....	184
<b>P1610 LOCK MODE</b> .....	167	Diagnosis Procedure .....	184
Description .....	167	<b>B260F ENGINE STATUS</b> .....	185
DTC Logic .....	167	Description .....	185
Diagnosis Procedure .....	167	DTC Description .....	185
<b>P1611 ID DISCORD, IMMU-ECM</b> .....	168	Diagnosis Procedure .....	185
DTC Logic .....	168	<b>B261E VEHICLE TYPE</b> .....	187
Diagnosis Procedure .....	168	Description .....	187
<b>P1612 CHAIN OF ECM-IMMU</b> .....	169	DTC Logic .....	187
DTC Logic .....	169	Diagnosis Procedure .....	187
Diagnosis Procedure .....	169	<b>B27D1 START CUT RELAY OFF</b> .....	189
<b>P161D IMMOBILIZER</b> .....	170	DTC Logic .....	189
DTC Logic .....	170	Diagnosis Procedure .....	189
Diagnosis Procedure .....	170	Component Inspection .....	191
<b>P161E IMMOBILIZER</b> .....	171	<b>B27D2 START CUT RELAY ON</b> .....	192
DTC Logic .....	171	DTC Logic .....	192
Diagnosis Procedure .....	171	Diagnosis Procedure .....	192
<b>P161F IMMOBILIZER</b> .....	172	Component Inspection .....	194
DTC Logic .....	172	<b>HEADLAMP FUNCTION</b> .....	195
Diagnosis Procedure .....	172	Component Function Check .....	195
<b>B2190 NATS ANTENNA AMP.</b> .....	173	Diagnosis Procedure .....	195
Description .....	173	<b>HORN FUNCTION</b> .....	196
DTC Logic .....	173	Component Function Check .....	196
Diagnosis Procedure .....	173	Component Inspection .....	196
<b>B2191 DIFFERENCE OF KEY</b> .....	176	<b>SECURITY INDICATOR LAMP</b> .....	197
DTC Logic .....	176	Component Function Check .....	197
Diagnosis Procedure .....	176	Diagnosis Procedure .....	197
<b>B2192 ID DISCORD, IMMU-ECM</b> .....	177	<b>SYMPTOM DIAGNOSIS</b> .....	199
DTC Logic .....	177	<b>NISSAN VEHICLE IMMOBILIZER SYSTEM-</b>	
Diagnosis Procedure .....	177	<b>NATS SYMPTOMS</b> .....	199
<b>B2193 CHAIN OF ECM-IMMU</b> .....	178	Symptom Table .....	199
DTC Logic .....	178	<b>VEHICLE SECURITY SYSTEM</b> .....	200
Diagnosis Procedure .....	178	Symptom Table .....	200
<b>B2196 DONGLE UNIT</b> .....	179	<b>REMOVAL AND INSTALLATION</b> .....	201
Description .....	179	<b>NATS ANTENNA AMP.</b> .....	201
DTC Logic .....	179	Removal and Installation .....	201
Diagnosis Procedure .....	179	<b>DONGLE UNIT</b> .....	202
<b>B2198 NATS ANTENNA AMP.</b> .....	181	Removal and Installation .....	202
DTC Logic .....	181		

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000012423928

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

**WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

**WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

Precaution for Work

INFOID:000000012423929

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# PREPARATION

[WITH INTELLIGENT KEY SYSTEM]

< PREPARATION >

## PREPARATION


### PREPARATION

#### Special Service Tool

INFOID:000000012423930

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[WITH INTELLIGENT KEY SYSTEM]

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:0000000012423931



A. View right of steering column.

No.	Component	Function
1.	Combination meter	Combination meter transmits the vehicle speed signal to BCM via CAN communication. BCM also receives the vehicle speed signal from ABS actuator and electric unit (control unit) via CAN communication. BCM compares both signals to detect the vehicle speed. Security indicator lamp is located on combination meter. Security indicator lamp blinks when ignition switch is in any position other than ON to warn that NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)] is on board. Refer to <a href="#">MWI-6, "METER SYSTEM : Component Parts Location"</a> .
2.	Push-button ignition switch	Push-button ignition switch has push switch inside which detects that push-button ignition switch is pressed, and then transmits ON/OFF signal to BCM. BCM changes the ignition switch position with the operation of push-button ignition switch. BCM maintains the ignition switch position status while push-button ignition switch is not operated.
3.	NATS antenna amp.	Refer to <a href="#">SEC-9, "NATS Antenna Amp."</a>
4.	Inside key antenna (instrument center)	Inside key antenna (instrument center) detects whether Intelligent Key is inside the vehicle or not, and then transmits the signal to the BCM. Refer to <a href="#">DLK-24, "Inside Key Antenna (Instrument Center)"</a> .
5.	Horn	Horn is operated when the panic button on the Intelligent Key is pressed or the alarm is activated.
6.	Transmission range switch	Refer to <a href="#">TM-14, "CVT CONTROL SYSTEM : Transmission Range Switch"</a> .

A  
B  
C  
D  
E  
F  
G  
H  
I  
J

## COMPONENT PARTS

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

No.	Component	Function
7.	IPDM E/R	Refer to <a href="#">PCS-6, "Component Parts Location"</a> .
8.	Stop lamp switch	Refer to <a href="#">BRC-12, "Stop Lamp Switch"</a> .
9.	BCM	<p>BCM controls INTELLIGENT KEY SYSTEM (ENGINE START FUNCTION), NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)] and VEHICLE SECURITY SYSTEM.</p> <p>BCM performs the ID verification between BCM and Intelligent Key when the Intelligent Key is carried into the detection area of inside key antenna, and push-button ignition switch is pressed. If the ID verification result is OK, ignition switch operation is available.</p> <p>Then, when the ignition switch is turned ON, BCM performs ID verification between BCM and ECM. If the ID verification result is OK, ECM can start engine.</p> <p>Refer to <a href="#">BCS-7, "BODY CONTROL SYSTEM : Component Parts Location"</a> for detailed installation location.</p>
10.	CVT shift selector	Refer to <a href="#">TM-20, "SHIFT LOCK SYSTEM : Component Parts Location"</a> .
11.	Main power window and door lock/unlock switch (Front power window and door lock/unlock switch RH similar)	<p>Door lock and unlock switch is integrated into the main power window and door lock/unlock switch.</p> <p>Door lock and unlock switch transmits door lock/unlock operation signal to BCM.</p> <p>Refer to <a href="#">PWC-7, "Main Power Window And Door Lock/Unlock Switch"</a>.</p>
12.	Outside key antenna LH	<p>Outside key antenna (LH) detects whether Intelligent Key is outside the vehicle or not, and then transmits the signal to the BCM.</p> <p>Refer to <a href="#">DLK-24, "Outside Key Antenna (LH)"</a>.</p>
13.	Front door lock assembly LH	<p>Door key cylinder switch is integrated into front door lock assembly (driver side).</p> <p>Door key cylinder switch detects door LOCK/UNLOCK operation using mechanical key, and then transmits the operation signal to BCM.</p> <p>Refer to <a href="#">DLK-26, "Front Door Lock Assembly (LH)"</a>.</p>
14.	Front door switch LH	Door switch detects door open/close condition and then transmits ON/OFF signal to BCM.
15.	Rear door switch LH (rear door switch RH similar)	Door switch detects door open/close condition and then transmits ON/OFF signal to BCM.
16.	Outside key antenna RH	<p>Outside key antenna (RH) detects whether Intelligent Key is outside the vehicle or not, and then transmits the signal to the BCM.</p> <p>Refer to <a href="#">DLK-25, "Outside Key Antenna (RH)"</a>.</p>
17.	Front door switch RH	Door switch detects door open/close condition and then transmits ON/OFF signal to BCM.
18.	Inside key antenna (console)	<p>Inside key antenna (console) detects whether Intelligent Key is inside the vehicle or not, and then transmits the signal to the BCM.</p> <p>Refer to <a href="#">DLK-24, "Inside Key Antenna (Console)"</a>.</p>
19.	Back door lock assembly	Back door lock actuator locks/unlocks the back door latch assembly.
20.	Outside key antenna (rear bumper)	<p>Outside key antenna (Rear bumper) detects whether Intelligent Key is outside the vehicle or not, and then transmits the signal to the BCM.</p> <p>Refer to <a href="#">DLK-24, "Outside Key Antenna (Rear Bumper)"</a>.</p>



# COMPONENT PARTS


< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

## NATS Antenna Amp.

INFOID:000000012423932

The ID verification is performed between BCM and transponder integrated into Intelligent Key via NATS antenna amp. when Intelligent Key backside is contacted to push-button ignition switch in case that Intelligent Key battery is discharged. If the ID verification result is OK, the operation of ignition switch is available.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


SEC

SYSTEM

INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION

INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Diagram

INFOID:0000000012423933



INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description

INFOID:0000000012423934

SYSTEM DESCRIPTION

- The engine start function of Intelligent Key system makes it possible to start and stop the engine without using the key, based on the electronic ID verification. The electronic ID verification is performed between BCM and Intelligent Key when the push-button ignition switch is pressed while the Intelligent Key is within the detection area of inside key antenna.

**NOTE:**

The driver should carry the Intelligent Key at all times.

- Intelligent Key has 2 IDs [Intelligent Key ID and NVIS (NATS) ID]. It can perform the door lock/unlock operation and the push-button ignition switch operation when the registered Intelligent Key is carried.
- When Intelligent Key battery is discharged, engine can be started by operating push-button ignition switch after contacting Intelligent Key backside to push-button ignition switch. At that time, the NVIS (NATS) ID verification is performed.
- If the ID is successfully verified, when push-button ignition switch is pressed, the engine can be started.
- Up to 4 Intelligent Keys can be registered (Including the standard Intelligent Key) upon request from the customer.

# SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

## NOTE:

Refer to [SEC-13, "NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description"](#) for any functions other than engine start function of Intelligent Key system.

## PRECAUTIONS FOR INTELLIGENT KEY SYSTEM

**The transponder [the chip for NVIS (NATS) ID verification] is integrated into the Intelligent Key. In that case, the NVIS (NATS) ID verification can be performed when Intelligent Key backside is contacted to push-button ignition switch. If verification result is OK, engine can be started.**

## OPERATION WHEN INTELLIGENT KEY IS CARRIED

1. When the push-button ignition switch is pressed, the BCM activates the inside key antenna and transmits the request signal to the Intelligent Key.
2. The Intelligent Key receives the request signal and transmits the Intelligent Key ID signal to the BCM.
3. BCM receives the Intelligent Key ID signal and verifies it with the registered ID.
4. BCM turns ACC relay ON and transmits the ignition power supply ON signal to IPDM E/R.
5. IPDM E/R turns the ignition relay ON and starts the ignition power supply.
6. BCM detects that the selector lever position and brake pedal operating condition.
7. BCM transmits the starter request signal to IPDM E/R and turns the starter relay in IPDM E/R ON if BCM judges that the engine start condition\* is satisfied.
8. IPDM E/R turns the starter control relay ON when receiving the starter request signal.
9. Power supply is supplied through the starter relay and the starter control relay to operate the starter motor.

### CAUTION:

**If a malfunction is detected in the Intelligent Key system, the "KEY" warning lamp in the combination meter illuminates. At that time, the engine cannot be started.**

10. When BCM receives feedback signal from ECM indicating that the engine is started, the BCM transmits a stop signal to IPDM E/R and stops cranking by turning OFF the starter motor relay. (If engine start is unsuccessful, cranking stops automatically within 5 seconds.)

### CAUTION:

**When the Intelligent Key is carried outside of the vehicle (inside key antenna detection area) while the power supply is in the ACC or ON position, even if the engine start condition\* is satisfied, the engine cannot be started.**

\*: For the engine start condition, refer to the table below "POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION".

## OPERATION RANGE

Engine can be started when Intelligent Key is inside the vehicle. However, sometimes engine may not start when Intelligent Key is on instrument panel or in glove box.

## ENGINE START OPERATION WHEN INTELLIGENT KEY IS CONTACTED TO PUSH-BUTTON IGNITION SWITCH

When Intelligent Key battery is discharged, the NVIS (NATS) ID verification between transponder in Intelligent Key and BCM is performed when Intelligent Key backside is contacted to push-button ignition switch. If the verification result is OK, engine can be started.

## POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION

The power supply position changing operation can be performed with the following operations.

### NOTE:

- When an Intelligent Key is within the detection area of inside key antenna and when Intelligent Key backside is contacted to push-button ignition switch, it is equivalent to the operations below.
- When starting the engine, the BCM monitors under the engine start conditions:
  - Brake pedal operating condition
  - Selector lever position
  - Vehicle speed

Vehicle speed: less than 4 km/h (2.5 MPH)

SEC

# SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
LOCK → ACC	—	Not depressed	1
LOCK → ACC → ON	—	Not depressed	2
LOCK → ACC → ON → OFF	—	Not depressed	3
LOCK → START ACC → START ON → START	P or N position	Depressed	1
Engine is running → OFF	—	—	1

Vehicle speed: 4 km/h (2.5 MPH) or more

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
Engine is running → ACC	—	—	Emergency stop operation
Engine stall return operation while driving	N position	Not depressed	1

Emergency stop operation

- Press and hold the push-button ignition switch for 2 seconds or more.
- Press the push-button ignition switch 3 times or more within 1.5 seconds.

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS


# SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Diagram

INFOID:000000012423935



A  
B  
C  
D  
E  
F  
G  
H  
I  
J

SEC

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description

INFOID:000000012423936

### SYSTEM DESCRIPTION

- The NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)] prevents the engine from being started by Intelligent Key whose ID is not registered to the vehicle (BCM). It has higher protection against auto theft involving the duplication of mechanical keys.
- The ignition key integrated in the Intelligent Key cannot start the engine. When the Intelligent Key battery is discharged, the NVIS (NATS) ID verification is performed between the transponder integrated with Intelligent Key and BCM via NATS antenna amp. when the Intelligent Key backside is contacted to push-button ignition switch. If the verification results are OK, the engine start operation can be performed by the push-button ignition switch operation.
- Locate the security indicator lamp and apply the anti-theft system equipment sticker that warns that the NVIS (NATS) is on-board the model.
- Security indicator lamp always blinks when the power supply position is any position other than ON.
- Up to 4 Intelligent Keys can be registered (including the standard ignition key) upon request from the owner.
- Specified registration is required when replacing ECM, BCM or Intelligent Key.
- Possible symptom of NVIS (NATS) malfunction is "Engine cannot start". The engine can not be started because of other than NVIS (NATS) malfunction, so start the trouble diagnosis according to [SEC-66, "Work Flow"](#).
- If ECM other than genuine part is installed, the engine cannot be started. For ECM replacement procedure, refer to [EC-503, "Removal and Installation"](#).

L  
M  
N  
O  
P

# SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

## PRECAUTIONS FOR KEY REGISTRATION

- The ID registration is a procedure that erases the current NVIS (NATS) ID once, and then reregisters a new ID. Therefore before starting the registration operation, collect all registered Intelligent Keys from the customer.
- When registering the Intelligent Key, perform only one procedure to simultaneously register both ID [NVIS (NATS) ID and Intelligent Key ID].

## SECURITY INDICATOR LAMP

- Warns that the vehicle is equipped with NVIS (NATS).
- Security indicator lamp always blinks when the power supply position is any position other than ON.

### NOTE:

Because security indicator lamp is highly efficient, the battery is barely affected.

## ENGINE START OPERATION WHEN INTELLIGENT KEY IS CONTACTED TO PUSH-BUTTON IGNITION SWITCH

1. When brake pedal is depressed while selector lever is in the P (Park) position, BCM activates NATS antenna amp. that is located behind push-button ignition switch.
2. When Intelligent Key (transponder built-in) backside is contacted to push-button ignition switch, BCM starts NVIS (NATS) ID verification between BCM and Intelligent Key (transponder built-in) via NATS antenna amp.
3. When the NVIS (NATS) ID verification result is OK, buzzer in combination meter sounds and BCM transmits the result to ECM.
4. BCM turns ACC relay ON and transmits ignition power supply ON signal to IPDM E/R.
5. IPDM E/R turns the ignition relay ON and starts the ignition power supply.
6. BCM detects that the selector lever position is P (Park) or N (Neutral).
7. BCM transmits starter request signal to IPDM E/R and turns the starter relay in IPDM E/R ON if BCM judges that the engine start condition\* is satisfied.
8. IPDM E/R turns the starter control relay ON when receiving the starter request signal.
9. Power supply is supplied through the starter relay and the starter control relay to operate the starter motor.
10. When BCM receives feedback signal from ECM indicating that the engine is started, BCM transmits a stop signal to IPDM E/R and stops cranking by turning off the starter motor relay. (If engine start is unsuccessful, cranking stops automatically within 5 seconds.)

\*: For the engine start condition, refer to the table "POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION" below.

## POWER SUPPLY POSITION CHANGE TABLE BY PUSH-BUTTON IGNITION SWITCH OPERATION

The power supply position changing operation can be performed with the following operations.

### NOTE:

- When an Intelligent Key is within the detection area of inside key antenna and when Intelligent Key backside is contacted to push-button ignition switch, it is equivalent to the operations below.
- When starting the engine, the BCM monitors under the engine start conditions:
  - Brake pedal operating condition
  - Selector lever position
  - Vehicle speed

Vehicle speed: less than 4 km/h (2.5 MPH)

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
LOCK → ACC	—	Not depressed	1
LOCK → ACC → ON	—	Not depressed	2
LOCK → ACC → ON → OFF	—	Not depressed	3

# SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
LOCK → START ACC → START ON → START	P (Park) or N (Neutral) position	Depressed	1
Engine is running → OFF	—	—	1

Vehicle speed: 4 km/h (2.5 MPH) or more

Power supply position	Engine start/stop condition		Push-button ignition switch operation frequency
	Selector lever	Brake pedal operation condition	
Engine is running → ACC	—	—	Emergency stop operation
Engine stall return operation while driving	N (Neutral) position	Not depressed	1


Emergency stop operation

- Press and hold the push-button ignition switch for 2 seconds or more.
- Press the push-button ignition switch 3 times or more within 1.5 seconds.

## VEHICLE SECURITY SYSTEM

### VEHICLE SECURITY SYSTEM : System Diagram

INFOID:000000012423937



SEC

### VEHICLE SECURITY SYSTEM : System Description

INFOID:000000012423938

- The vehicle security system has two alarm functions (theft warning alarm and panic alarm) and reduces the possibility of a theft or mischief by activating horns and headlamps intermittently.

# SYSTEM

**[WITH INTELLIGENT KEY SYSTEM]**

**< SYSTEM DESCRIPTION >**


- The panic alarm does not start when the theft warning alarm is activating and the panic alarm stops when the theft warning alarm is activated.
- The priority of the functions are as per the following:

Priority	Function
1	Theft warning alarm
2	Panic alarm

**THEFT WARNING ALARM**

- The theft warning alarm function activates horns and headlamps intermittently when BCM detects that any door is opened by unauthorized means while the system is in the ARMED state.
- Security indicator lamp on combination meter always blinks when power supply position is any position other than ON. Security indicator lamp blinking warns that the vehicle is equipped with a vehicle security system.

**Operation Flow**



No.	System state	Switching condition		
1	DISARMED to PRE-ARMED	When all conditions of A and one condition of B is satisfied.	A	B
			<ul style="list-style-type: none"> <li>• Power supply position: OFF/LOCK</li> <li>• All doors: Closed</li> </ul>	All doors are locked by: <ul style="list-style-type: none"> <li>• Door key cylinder LOCK switch</li> <li>• LOCK button of Intelligent Key</li> <li>• Door request switch</li> </ul>
2	PRE-ARMED to ARMED	When all of the following conditions are satisfied for 30 seconds.	<ul style="list-style-type: none"> <li>• Power supply position: OFF/LOCK</li> <li>• All doors: Locked</li> </ul>	
3	ARMED to ALARM	When one condition of A and one condition of B are satisfied.	A	B
			Intelligent Key: Not used	<ul style="list-style-type: none"> <li>• Any door: Open</li> </ul>
4	DISARMED to PRE-RESET	When all conditions of A and one condition of B is satisfied.	A	B
			<ul style="list-style-type: none"> <li>• Power supply position: OFF/LOCK</li> <li>• All doors: Closed</li> </ul>	All doors are locked by: <ul style="list-style-type: none"> <li>• Door key cylinder LOCK switch</li> <li>• LOCK button of Intelligent Key</li> <li>• Door request switch</li> </ul>
5	PRE-ARMED to PRE-RESET	No conditions.		
6	ARMED to PRE-RESET	No conditions.		
7	ALARM to PRE-RESET	No conditions.		



# SYSTEM

## < SYSTEM DESCRIPTION >

## [WITH INTELLIGENT KEY SYSTEM]

No.	System state	Switching condition	
8	PRE-RESET to DISARMED	When one of the following conditions is satisfied.	<ul style="list-style-type: none"> <li>• Power supply position: ACC/ON/CRANKING/RUN</li> <li>• Door key cylinder UNLOCK switch: ON</li> <li>• UNLOCK button of Intelligent Key: ON</li> <li>• Door request switch: ON</li> <li>• Back door opener switch: ON</li> <li>• UNLOCK switch of door lock and unlock switch: ON</li> <li>• Any door: Open</li> </ul>
9	PRE-RESET to PRE-ARMED	When all of the following conditions are satisfied.	<ul style="list-style-type: none"> <li>• Power supply position: OFF/LOCK</li> <li>• All doors: Closed</li> </ul>
10	PRE-ARMED to DISARMED	When one of the following conditions is satisfied.	<ul style="list-style-type: none"> <li>• Power supply position: ACC/ON/CRANKING/RUN</li> <li>• Door key cylinder UNLOCK switch: ON</li> <li>• UNLOCK button of Intelligent Key: ON</li> <li>• AUTO BACK DOOR button of Intelligent Key: ON</li> <li>• Door request switch: ON</li> <li>• Back door opener switch: ON</li> <li>• Any door: Open</li> </ul>
11	ARMED to DISARMED	When one of the following conditions is satisfied.	<ul style="list-style-type: none"> <li>• Power supply position: ACC/ON/CRANKING/RUN</li> <li>• Door key cylinder UNLOCK switch: ON</li> <li>• UNLOCK button of Intelligent Key: ON</li> <li>• AUTO BACK DOOR button of Intelligent Key: ON</li> <li>• Door request switch: ON</li> <li>• Back door opener switch: ON</li> </ul>
12	ALARM to DISARMED		
13	RE-ALARM	When one of the following conditions is satisfied after the ALARM operation is finished.	<ul style="list-style-type: none"> <li>• Any door: Open</li> </ul>

**NOTE:**

- BCM ignores the door key cylinder UNLOCK switch signal input for 1 second after the door key cylinder LOCK switch signal input.
- To lock/unlock all doors by operating remote controller button of Intelligent Key or door request switch, Intelligent Key must be within the detection area of outside key antenna. For details, refer to [SEC-10. "INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description"](#).
- To open back door by operating back door opener switch, Intelligent Key must be within the detection area of outside key antenna. For details, refer to [SEC-10. "INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description"](#).

### DISARMED Phase

The vehicle security system is not set in the DISARMED phase. The vehicle security system stays in this phase while any door is open because it is assumed that the owner is inside or nearby the vehicle. Security indicator lamp blinks every 2.4 seconds.

When the vehicle security system is reset, each phase switches to the DISARMED phase directly.

### PRE-ARMED Phase

The PRE-ARMED phase is the transient state between the DISARMED phase and the ARMED phase. This phase is maintained for 30 seconds so that the owner can reset the setting due to a mis-operation. This phase switches to the ARMED phase when vehicle conditions are not changed for 30 seconds. Security indicator lamp illuminates while being in this phase.

To reset the PRE-ARMED phase, refer to the switching condition of No. 10 in the table above.

### ARMED Phase

The vehicle security system is set and BCM monitors all necessary inputs. If any door is opened without using Intelligent Key, vehicle security system switches to the ALARM phase. Security indicator lamp blinks every 2.4 seconds.

To reset the ARMED phase, refer to the switching condition of No. 11 in the table above.

### ALARM Phase

BCM transmits "Theft Warning Horn Request" signal and "High Beam Request" signal intermittently to IPDM E/R via CAN communication. In this phase, horns and headlamps are activated intermittently for approximately 50 seconds to warn that the vehicle is accessed by unauthorized means. ON/OFF timing of horns and headlamps are synchronized. After 50 seconds, the vehicle security system returns to the ARMED phase. At this time, if BCM still detects unauthorized access to the vehicle, the system is switched to the ALARM phase again. This RE-ALARM operation is carried out a maximum of 2 times.

To cancel the ALARM operation, refer to the switching condition of No. 12 in the table above.

# SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

## NOTE:

If a battery terminal is disconnected during the ALARM phase, theft warning alarm stops. But when the battery terminal is reconnected, theft warning alarm is activated again.

## PANIC ALARM

- The panic alarm function activates horns and headlamps intermittently when the owner presses the PANIC ALARM button of Intelligent Key outside the vehicle while the power supply position is OFF or LOCK.
- When BCM receives panic alarm signal from Intelligent Key, BCM transmits “Theft Warning Horn Request” signal and “High Beam Request” signal intermittently to IPDM E/R via CAN communication. To prevent the activation due to mis-operation of Intelligent Key by owner, the panic alarm function is activated when BCM receives the signal for 0.4 - 0.6 seconds.
- Panic alarm operation is maintained for 25 seconds.
- Panic alarm operation is cancelled when BCM receives one of the following signals:
  - LOCK button of Intelligent Key: ON
  - UNLOCK button of Intelligent Key: ON
  - PANIC ALARM button of Intelligent Key: Long pressed
  - Any door request switch: ON

# DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:0000000012567349

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> <li>The vehicle specification can be read and saved.</li> <li>The vehicle specification can be written when replacing BCM.</li> </ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

### SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK		x	x	x	x		
Rear window defogger	REAR DEFOGGER			x	x	x		
Warning chime	BUZZER			x	x			
Interior room lamp timer	INT LAMP			x	x	x		
Exterior lamp	HEADLAMP			x	x	x		
Wiper and washer	WIPER			x	x	x		
Turn signal and hazard warning lamps	FLASHER			x	x			
Intelligent Key system	INTELLIGENT KEY		x	x	x	x		
Combination switch	COMB SW			x				
BCM	BCM	x	x			x	x	x
Immobilizer	IMMU		x	x	x			
Interior room lamp battery saver	BATTERY SAVER			x	x			
Back door open	TRUNK			x				
Vehicle security system	THEFT ALM			x	x	x		
RAP system	RETAINED PWR			x				
Signal buffer system	SIGNAL BUFFER			x				
Air conditioner	AIR CONDITIONER				x			

### INTELLIGENT KEY

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

## INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000012567350

### SELF DIAGNOSTIC RESULT

Refer to [BCS-48, "DTC Index"](#).

### DATA MONITOR

Monitor Item [Unit]	Main	Description
REQ SW -DR [On/Off]	×	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	×	Indicates condition of door request switch RH.
REQ SW -BD/TR [On/Off]	×	Indicates condition of back door request switch.
PUSH SW [On/Off]		Indicates condition of push-button ignition switch.
BRAKE SW 1 [On/Off]	×	Indicates condition of brake pedal position switch.
BRAKE SW 2 [On/Off]		Indicates condition of stop lamp switch.
DETE/CANCL SW [On/Off]	×	Indicates condition of park position switch.
PUSH SW -IPDM [On/Off]		Indicates condition of push-button ignition switch received from IPDM E/R on CAN communication line.
IGN RLY1 -F/B [On/Off]		Indicates condition of ignition relay 1 received from IPDM E/R on CAN communication line.
NEUTRAL SW -IPDM [On/Off]		Indicates condition of transmission range switch received from IPDM E/R on CAN communication line.
SFT PN -IPDM [On/Off]		Indicates condition of P (park) or N (neutral) position from TCM on CAN communication line.
STARTER RELAY -IPDM [On/Off]		Indicates condition of starter relay received from IPDM E/R on CAN communication line.
ENGINE STATE [STOP/START/CRANK/RUN]	×	Indicates condition of engine state from ECM on CAN communication line.
ST/INH RELAY - IPDM [On/Off]		Indicates condition of starter relay and starter control relay status signal from IPDM E/R.
REVERSE SIGNAL -IPDM [On/Off]		Indicates condition of transmission range switch received from IPDM E/R on CAN communication line.
CRANKING PERMIT -ECM [PERMIT]		Indicates condition of engine start possibility from ECM on CAN communication line.
IS STATUS -ECM [On/Off]		Indicates IS status from ECM on CAN communication line.
STARTER CUT RELAY -ECM [On/Off]		Indicates condition of starter cut relay from ECM on CAN communication line.
VEH SPEED 1 [mph/km/h]	×	Indicates condition of vehicle speed signal received from ABS on CAN communication line.
VEH SPEED 2 [mph/km/h]	×	Indicates condition of vehicle speed signal received from combination meter on CAN communication line.
IGN REQ -IPDM [On/Off]		Indicates condition of ignition request from IPDM E/R on CAN communication line.
STARTER REQ -IPDM [On/Off]		Indicates condition of starter request received from IPDM E/R on CAN communication line.
DOOR STAT -DR [LOCK/READY/UNLK]	×	Indicates condition of driver side door status.
DOOR STAT -AS [LOCK/READY/UNLK]	×	Indicates condition of passenger side door status.
DOOR STAT -RR [LOCK/READY/UNLK]	×	Indicates condition of rear right side door status.
DOOR STAT -RL [LOCK/READY/UNLK]	×	Indicates condition of rear left side door status.
BK DOOR STATE [LOCK/READY/UNLK]	×	Indicates condition of back door status.
ID OK FLAG [Set/Reset]		Indicates condition of Intelligent Key ID.
PRMT ENG STRT [Set/Reset]		Indicates condition of engine start possibility.
PRMT RKE STRT [Set/Reset]		Indicates condition of engine start possibility from Intelligent Key.

# DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	Main	Description
I-KEY OK FLAG [Key ON/Key OFF]	×	Indicates condition of Intelligent Key OK flag.
PRBT ENG STRT [Set/Reset]		Indicates condition of engine start prohibit.
ID AUTHENT CANCEL TIMER [STOP]		Indicates condition of Intelligent Key ID authentication.
ACC BATTERY SAVER [STOP]		Indicates condition of battery saver.
CRNK PRBT TMR [On/Off]		Indicates condition of crank prohibit timer.
AUT CRNK TMR [On/Off]		Indicates condition of automatic engine crank timer from Intelligent Key.
CRNK PRBT TME [sec]		Indicates condition of engine crank prohibit time.
AUTO CRNK TME [sec]		Indicates condition of automatic engine crank time from Intelligent Key.
CRANKING TME [sec]		Indicates condition of engine cranking time from Intelligent Key.
RKE OPE COUN1 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE OPE COUN2 [0-19]	×	When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing.
RKE-LOCK [On/Off]		Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]		Indicates condition of unlock signal from Intelligent Key.
RKE-TR/BD [On/Off]		Indicates condition of back door open signal from Intelligent Key.
RKE-PANIC [On/Off]		Indicates condition of panic signal from Intelligent Key.
RKE-MODE CHG [On/Off]		Indicates condition of mode change signal from Intelligent Key.
RKE PBD [On/Off]		Indicates condition of automatic back door signal from Intelligent Key.

## ACTIVE TEST

Test Item	Description
OUTSIDE BUZZER	This test is able to check Intelligent Key warning buzzer operation [On/Off].
INSIDE BUZZER	This test is able to check combination meter warning chime operation [Take Out/Knob/Key/Off].
INDICATOR	This test is able to check combination meter warning lamp operation [KEY ON/KEY IND/Off].
FLASHER	This test is able to check flasher operation [On/Off].
HORN	This test is able to check horn operation [On/Off].
IGN CONT2	This test is able to check ignition relay-2 control operation [On/Off].
ENGINE SW ILLUMI	This test is able to check push-button ignition switch START indicator operation [On/Off].
ENGINE START REQUEST	This test is able to check BCM starter request switch signal to IPDM E/R via CAN communication [MODE 1/MODE 2/MODE 3/OFF].
IGNITION RELAY	This test is able to check ignition relay operation [On/Off].
STARTER CUT RELAY	This test is able to check the starter control relay [On/Off].
AUTO ACC 2	This test is able to check BCM sends power supply to audio unit or NAVI control unit [On/Off].
AUTOMATIC BACK DOOR	This test is able to check automatic back door operation [On/Off].
AUTO ACC 1	This test is able to check BCM sends power supply to ACC relay [MODE 1/MODE 2/MODE 3/OFF].
TRUNK LUGGAGE LAMP TEST	This test is able to check luggage room lamp test operation [On/Off].

## WORK SUPPORT

Support Item	Setting	Description
SHORT CRANKING OUTPUT	Start	70 msec
		100 msec
		200 msec
	End	—

# DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

## < SYSTEM DESCRIPTION >

Support Item	Setting	Description
INSIDE ANT DIAGNOSIS	—	This function allows inside key antenna self-diagnosis.
LOCK/UNLOCK BY I-KEY	On*	Door lock/unlock by I-Key ON.
	Off	Door lock/unlock by I-Key OFF.
AUTO LOCK SET	Mode 1	OFF
	Mode 2	30 sec.
	Mode 3*	1 min.
	Mode 4	2 min.
	Mode 5	3 min.
	Mode 6	4 min.
	Mode 7	5 min.
IGN/ACC BATTERY SAVER	On*	Battery saver system ON.
	Off	Battery saver system OFF.
ENGINE START BY I-KEY	On*	Engine start function from Intelligent Key ON.
	Off	Engine start function from Intelligent Key OFF.
TRUNK/GLASS HATCH OPEN	On*	Buzzer reminder function by back door request switch ON.
	Off	Buzzer reminder function by back door request switch OFF.
ANSWER BACK	On	Horn chirp reminder when doors are locked with Intelligent Key.
	Off*	No horn chirp reminder when doors are locked with Intelligent Key.
ANSWER BACK I-KEY LOCK UN-LOCK	BUZZER*	Buzzer reminder function by door lock/unlock request switch ON.
	HORN	Horn chirp reminder function by door lock request switch ON.
	Off	No reminder function by door lock/unlock request switch.
	INVALID	This mode is not used.
ANSWERBACK KEYLESS LOCK UN-LOCK	On*	Buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.
	Off	No buzzer or horn chirp reminder when doors are locked/unlocked with Intelligent Key.

## IMMU

### IMMU : CONSULT Function (BCM - IMMU)

INFOID:000000012567351

### SELF DIAGNOSTIC RESULT

Refer to [BCS-48, "DTC Index"](#).

### DATA MONITOR

Monitor Item [Unit]	Description
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.

### ACTIVE TEST

Test Item	Description
THEFT IND	This test is able to check security indicator operation [On/Off].

### WORK SUPPORT

Support Item	Setting	Description
CONFIRM DONGLE ID	—	Dongle ID can be checked.

## THEFT ALM

# DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

## THEFT ALM : CONSULT Function (BCM - THEFT ALM)

INFOID:000000012567352

### DATA MONITOR

Monitored Item	Description
REQ SW -DR [On/Off]	Indicates condition of door request switch LH.
REQ SW -AS [On/Off]	Indicates condition of door request switch RH.
REQ SW-BD/TR [On/Off]	Indicates condition of back door request switch.
PUSH SW [On/Off]	Indicates condition of push-button ignition switch.
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of back door switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
KEY CYL SW-TR	Indicates condition of key cylinder switch back door.
SEN CANCEL SW	Indicates condition of sensor cancel switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.
RKE-TR/BD [On/Off]	Indicates condition of back door open signal from Intelligent Key.

### ACTIVE TEST

Test Item	Description
VEHICLE SECURITY HORN	This test is able to check vehicle security horn operation [On].
HEAD LAMP	This test is able to check vehicle security lamp operation [MODE 1/MODE 2/MODE 3/OFF].

### WORK SUPPORT

Support Item	Setting	Description
SECURITY ALARM SET	On*	Security alarm ON.
	Off	Security alarm OFF.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

## DIAGNOSIS SYSTEM (IPDM E/R)

### CONSULT Function (IPDM E/R)

INFOID:000000012567353

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
ECU Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

#### ECU IDENTIFICATION

The IPDM E/R part number is displayed.

#### SELF DIAGNOSTIC RESULT

Refer to [PCS-26. "DTC Index"](#).

#### DATA MONITOR

Monitor Item [Unit]	Description
REVERSE SIGNAL [Open/Close]	Indicates condition of transmission range switch R (Reverse) position.
IGN RELAY [Open/Close]	Indicates condition of ignition relay-1.
PUSH SW [Open/Close]	Indicates condition of push-button ignition switch.
INTERLOCK/PNP SW [Open/Close]	Indicates condition of transmission range switch P (Park) and N (Neutral) positions.
OIL PRESSURE SW [Open/Close]	Indicates condition of oil pressure switch.
HOOD SW [Open/Close]	Indicates condition of hood switch.
COMPRESSOR [OFF/ON]	Indicates condition of A/C compressor.
HORN RELAY [OFF/ ON]	Indicates condition of horn relay.
COOLING FAN [OFF/ON]	Indicates condition of cooling fan relay-1.
FRONT WIPER HI/LO RELAY [OFF/ON]	Indicates condition of front wiper high relay.
FRONT WIPER RELAY [OFF/ON]	Indicates condition of front wiper relay.
IGN RELAY OFF STATUS [OFF/ON]	Indicates condition of ignition relay-1 OFF status.
IGN RELAY ON STATUS [OFF/ON]	Indicates condition of ignition relay-1 ON status.
COOLING FAN RELAY 1 [OFF/ON]	Indicates condition of cooling fan relay-1.
STARTER RELAY [OFF/ON]	Indicates condition of starter relay.
COMP ECV DUTY [%]	Indicates condition of A/C compressor.
COOLING FAN RELAY 2 [%]	Indicates condition of cooling fan relay-2.
FR FOG LAMP LH [%]	Indicates condition of front fog lamp LH.
FR FOG LAMP RH [%]	Indicates condition of front fog lamp RH.
PARKING LAMP [%]	Indicates condition of parking lamp.
TAIL LAMP LH [%]	Indicates condition of tail lamp LH.
TAIL LAMP RH [%]	Indicates condition of tail lamp RH.
DAYTIME RUNNING LIGHT LH [%]	Indicates condition of daytime running light LH.
DAYTIME RUNNING LIGHT RH [%]	Indicates condition of daytime running light RH.
HEADLAMP (HI) LH [%]	Indicates condition of headlamp high beam LH.



# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

Monitor Item [Unit]	Description	
HEADLAMP (HI) RH [%]	Indicates condition of headlamp high beam RH.	A
HEADLAMP (LO) LH [%]	Indicates condition of headlamp low beam LH.	
HEADLAMP (LO) RH [%]	Indicates condition of headlamp low beam RH.	B
A/C RELAY STUCK [NG/OK]	Indicates condition of A/C relay.	
A/C RELAY [Off/On]	Indicates condition of A/C relay.	
COMP ECV STATUS [NG/OK]	Indicates condition of A/C compressor.	C
VEHICLE SECURITY HORN [Off/On]	Indicates condition of horn relay.	
BATTERY CURRENT SENSOR [NG/OK]	Indicates condition of battery current sensor.	D
FRONT FOG LAMP [Off/On]	Indicates condition of front fog lamps.	
COMP ECV CURRENT [A]	Indicates condition of A/C compressor current.	
BATTERY VOLTAGE [V]	Indicates condition of battery voltage.	E
COOLING FAN DUTY [%]	Indicates condition of cooling fans.	
HOOD SW (CAN) [OPEN/CLOSE]	Indicates condition of hood switch.	F
FRONT WIPER [STOP/LOW/HIGH]	Indicates condition of front wiper motor.	
FR WIPER STOP POSITION [STOP P/ACTIVE P]	Indicates condition of front wiper motor stop.	
HEADLAMP (HI) [Off/On]	Indicates condition of headlamp high beams.	G
HEADLAMP (LO) [Off/On]	Indicates condition of headlamp low beams.	
IGNITION RELAY STATUS [Off/On]	Indicates condition of ignition relay-1.	
IGN RELAY MONITOR [Off/On]	Indicates condition of ignition relay-1 feedback.	H
IGNITION POWER SUPPLY [Off/On]	Indicates condition of ignition relay-1.	
INTERLOCK/PNP SW (CAN) [Off/On]	Indicates condition of transmission range switch P (Park) and N (Neutral) positions.	I
PUSH-BUTTON IGN SW (CAN) [Off/On]	Indicates condition of push-button ignition switch.	
TAIL LAMP [Off/On]	Indicates condition of tail lamps.	J
REVERSE SIGNAL (CAN) [Off/On]	Indicates condition of transmission range switch R (Reverse) position.	
ST&ST CONT RELAY STATUS [Off/ST R On]	Indicates condition of starter cut and starter relays.	SEC
STARTER MOTOR STATUS [Off/On]	Indicates condition of starter motor.	
STARTER RELAY (CAN) [LOW/HIGH]	Indicates condition of starter relay.	
IPDM NOT SLEEP [NO RDY/RDY]	Indicates condition of IPDM E/R sleep status.	L
AFTER COOLING TIME [No request/Request]	Indicates condition of cooling fan request.	
AFTER COOLING SPEED [%]	Indicates condition of cooling fans.	M
COOLING FAN TYPE [NISSAN/RENAULT]	Indicates cooling fan type.	
COMPRESSOR REQ1 [Off/On]	Indicates condition of A/C compressor request.	
VHCL SECURITY HORN REQ [Off/On]	Indicates condition of horn relay request.	N
DTRL REQ [Off/On]	Indicates condition of daytime running light request.	
SLEEP/WAKE UP [WAKEUP/SLEEP]	Indicates condition of IPDM E/R sleep/wake.	O
CRANKING ENABLE-TCM [NG/OK]	Indicates condition of crank enable from TCM.	
CRANKING ENABLE-ECM [NG/OK]	Indicates condition of crank enable from ECM.	
CAN DIAGNOSIS [NG/OK]	Indicates condition of CAN diagnosis.	P
FRONT FOG LAMP REQ [Off/On]	Indicates condition of front fog lamp request.	
HIGH BEAM REQ [Off/On]	Indicates condition of headlamp high beam request.	
HORN CHIRP [Off/On]	Indicates condition of horn relay request.	
COOLING FAN REQ [%]	Indicates condition of cooling fan request.	
ENGINE STATUS [STOP/RUN/IDLING]	Indicates condition of engine status.	

# DIAGNOSIS SYSTEM (IPDM E/R)

[WITH INTELLIGENT KEY SYSTEM]

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
TURN SIGNAL REQ [Off/LH/RH]	Indicates condition of turn signal request.
FR WIPER REQ [RETURN/LOW/HIGH]	Indicates condition of front wiper motor request.
SHIFT POSITION [P/R/N/D/L]	Indicates condition of transmission range switch positions.
LOW BEAM REQ [Off/On]	Indicates condition of headlamp low beam request.
POSITION LIGHT REQ [Off/On]	Indicates condition of parking lamp request.
COMPRESSOR REQ2 [Off/On]	Indicates condition of A/C compressor request.
IGNITION SW [Off/On]	Indicates condition of ignition switch.
VEHICLE SPEED (METER) [mph/km/h]	Indicates vehicle speed.
STARTER OPERATION COUNT	Displays the number of times the starter motor is turned ON.
H/P F/PUMP OPERATN COUNT	Displays the number of times the high pressure fuel pump is turned ON.
BAT DISCHARGE COUNT [—]	Monitor the cumulative discharge value of the battery. <b>NOTE:</b> When 65,000 or more is counted, replace the battery.
P LAMP CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the parking lamp circuit. <b>NOTE:</b> When the number of parking lamp circuit retries count is 20, this item counts 1.
NMB P LAMP CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the parking lamp circuit. <b>NOTE:</b> When the number of short circuits in the parking lamp circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB P LAMP CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the parking lamp circuit.
DTRL LH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the daytime running light (left) circuit. <b>NOTE:</b> When the number of daytime running light (left) circuit retries count is 20, this item counts 1.
NMB DTRL LH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the daytime running light (left) circuit. <b>NOTE:</b> When the number of short circuits in the daytime running light (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB DTRL LH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the daytime running light (left) circuit.
DTRL RH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the daytime running light (right) circuit. <b>NOTE:</b> When the number of daytime running light (right) circuit retries count is 20, this item counts 1.
NMB DTRL RH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the daytime running light (right) circuit. <b>NOTE:</b> When the number of short circuits in the daytime running light (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB DTRL RH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the daytime running light (right) circuit.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

Monitor Item [Unit]	Description
F FOG LH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the front fog lamp (left) circuit. <b>NOTE:</b> When the number of front fog lamp (left) circuit retries count is 20, this item counts 1.
NMB F FOG LH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the front fog lamp (left) circuit. <b>NOTE:</b> When the number of short circuits in the front fog lamp (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB F FOG LH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the front fog lamp (left) circuit.
F FOG RH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the front fog lamp (right) circuit. <b>NOTE:</b> When the number of front fog lamp (right) circuit retries count is 20, this item counts 1.
NMB F FOG RH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the front fog lamp (right) circuit. <b>NOTE:</b> When the number of short circuits in the front fog lamp (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB F FOG RH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the front fog lamp (right) circuit.
HL (HI) LH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the headlamp (HI) (left) circuit. <b>NOTE:</b> When the number of headlamp (HI) (left) circuit retries count is 20, this item counts 1.
NMB HL (HI) LH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the headlamp (HI) (left) circuit. <b>NOTE:</b> When the number of short circuits in the headlamp (HI) (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB HL (HI) LH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the headlamp (HI) (left) circuit.
HL (HI) RH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the headlamp (HI) (right) circuit. <b>NOTE:</b> When the number of headlamp (HI) (right) circuit retries count is 20, this item counts 1.
NMB HL (HI) RH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the headlamp (HI) (right) circuit. <b>NOTE:</b> When the number of short circuits in the headlamp (HI) (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB HL (HI) RH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the headlamp (HI) (right) circuit.
HL (LO) LH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the headlamp (LO) (left) circuit. <b>NOTE:</b> When the number of headlamp (LO) (left) circuit retries count is 20, this item counts 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# DIAGNOSIS SYSTEM (IPDM E/R)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
NMB HL (LO) LH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the headlamp (LO) (left) circuit. <b>NOTE:</b> When the number of short circuits in the headlamp (LO) (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB HL (LO) LH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the headlamp (LO) (left) circuit.
HL (LO) RH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the headlamp (LO) (right) circuit. <b>NOTE:</b> When the number of headlamp (LO) (right) circuit retries count is 20, this item counts 1.
NMB HL (LO) RH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the headlamp (LO) (right) circuit. <b>NOTE:</b> When the number of short circuits in the headlamp (LO) (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB HL (LO) RH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the headlamp (LO) (right) circuit.
T LAMP LH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the tail lamp (left) circuit. <b>NOTE:</b> When the number of tail lamp (left) circuit retries count is 20, this item counts 1.
NMB T LAMP LH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the tail lamp (left) circuit. <b>NOTE:</b> When the number of short circuits in the tail lamp (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB T LAMP LH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the tail lamp (left) circuit.
T LAMP RH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the tail lamp (right) circuit. <b>NOTE:</b> When the number of tail lamp (right) circuit retries count is 20, this item counts 1.
NMB T LAMP RH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the tail lamp (right) circuit. <b>NOTE:</b> When the number of short circuits in the tail lamp (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB T LAMP RH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the tail lamp (right) circuit.
BATTERY STATUS [OK/NG]	Monitor the battery status from the battery output.
BAT DISCHARGE COUNT [0-100]	Indicates condition of battery discharge.
BATTERY STATUS [NG/OK]	Indicates battery status.

## ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [Off/On].
FRONT WIPER	This test is able to check wiper motor operation [Off/Low/High].

# DIAGNOSIS SYSTEM (IPDM E/R)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

Test item	Description
COMPRESSOR	This test is able to check A/C compressor operation [Off/On].
COOLING FAN (DUAL)	This test is able to check cooling fan operation [Off/LO/HI].
HEADLAMP (HI)	This test is able to check headlamp high beam operation [Off/3/5].
HEADLAMP (LO)	This test is able to check headlamp low beam operation [Off/3/5].
FRONT FOG LAMP	This test is able to check front fog lamp operation [Off/3/5].
DAYTIME RUNNING LAMP	This test is able to check daytime running lamp operation [Off/3/5].
PARKING LAMP	This test is able to check parking lamp operation [Off/3/5].
TAIL LAMP	This test is able to check tail lamp operation [Off/3/5].

## CAN DIAG SUPPORT MNTR

Refer to [LAN-17, "CAN Diagnostic Support Monitor"](#).

## WORK SUPPORT

Work item	Description
CML B/DCHRG CRNT CLEAR	In this mode, cumulative battery discharge current is cleared.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# ECU DIAGNOSIS INFORMATION

## ECM, IPDM E/R, BCM

### List of ECU Reference

INFOID:000000012423944

ECU	Reference
ECM	<a href="#">EC-80. "Reference Value"</a>
	<a href="#">EC-92. "Fail Safe"</a>
	<a href="#">EC-95. "DTC Inspection Priority Chart"</a>
	<a href="#">EC-96. "DTC Index"</a>
IPDM E/R	<a href="#">PCS-17. "Reference Value"</a>
	<a href="#">PCS-25. "Fail-safe"</a>
	<a href="#">PCS-26. "DTC Index"</a>
BCM	<a href="#">BCS-29. "Reference Value"</a>
	<a href="#">BCS-47. "Fail Safe"</a>
	<a href="#">BCS-47. "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-48. "DTC Index"</a>

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >


## WIRING DIAGRAM

### ENGINE START FUNCTION

Wiring Diagram

INFOID:0000000012423945

INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


SEC

AAKWA1326GB

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >




AAKWA1327GB



# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >



AAKWA1328GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# ENGINE START FUNCTION

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]



AAKWA1329GB


# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

## INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M14
Connector Name	JOINT CONNECTOR-M30
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	Y	-
3	Y	-
4	Y	-

Connector No.	M15
Connector Name	INSIDE KEY ANTENNA (INSTRUMENT CENTER)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	GR	-
2	BG	-

Connector No.	M17
Connector Name	PUSH BUTTON IGNITION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
4	B	-
5	Y	-
7	B	-
8	W	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
17	L	O PWR ATDVC
27	Y	O IGN1 RL
35	BG	O SECURITY LED

AAKIA2335GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# ENGINE START FUNCTION

< WIRING DIAGRAM >


[WITH INTELLIGENT KEY SYSTEM]

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2

Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
5	L	-
11	P	-
12	P	-
15	P	-

Terminal No.	Color of Wire	Signal Name
89	Y	I START WO ESCL SW (WITH INTELLIGENT KEY SYSTEM)
94	G	I AT LOCKED IN PARK SW
116	BG	SES INT FRONT ANTENNA B (WITH INTELLIGENT KEY SYSTEM)
117	GR	SES INT FRONT ANTENNA A (WITH INTELLIGENT KEY SYSTEM)


Terminal No.	Color of Wire	Signal Name
37J	Y	-
60J	P	-
61J	L	-

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
88	W	O START SW BACKLIGHT LED (WITH INTELLIGENT KEY SYSTEM)

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE





AAKIA3208GB

# ENGINE START FUNCTION

< WIRING DIAGRAM >



[WITH INTELLIGENT KEY SYSTEM]

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
14R	W	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3P	Y	-
8P	LA/BR	-
13P	LA/G	-

Connector No.	M107
Connector Name	CVT SHIFT SELECTOR
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
12	L	-
13	G	-

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
41	L	CAN-H
42	P	CAN-L
45	LA/G	BAT
46	LA/BR	IGN
52	B	G1

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
1	B	GND
7	BG	SECURITY

AAKIA2311GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

Connector No.	M170
Connector Name	JOINT CONNECTOR-M29
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
2	B	-

Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-

Connector No.	E16
Connector Name	ECM
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
99	P	CAN-L
100	L	CAN-H
115	V	STOP LAMP SWITCH
117	W	PNP SIGNAL

Connector No.	E19
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
7	G	-
8	W	-

Connector No.	E28
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5M	V	-

Connector No.	E29
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
125	LG	I BRAKE SW2
139	G	O STCUT RL


# ENGINE START FUNCTION

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-
5	L	-
6	P	-
9	L	-
10	P	-
13	L	-
14	P	-
17	L	-
18	P	-
19	V	-
23	LG	-
27	LG	-

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Connector No.	E38
Connector Name	STOP LAMP SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	V	-
2	LG	-


Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED



Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND
32	GR	LI PUSH SW
39	L	CAN-H
40	P	CAN-L

Terminal No.	Color of Wire	Signal Name
12	B	SIGNAL GROUND

AAKIA3209GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC


# ENGINE START FUNCTION

< WIRING DIAGRAM >


[WITH INTELLIGENT KEY SYSTEM]

Terminal No.	Color of Wire	Signal Name
37J	GR	-
60J	P	-
61J	L	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	E125
Connector Name	ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
14	P	CAN-L
26	L	CAN-H

Connector No.	F35
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE



Connector No.	F33
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Connector No.	F32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
70	BG	O IGN AT LPG

Terminal No.	Color of Wire	Signal Name
7	G	-
8	W	-

Terminal No.	Color of Wire	Signal Name
1	L	-

AAKIA3210GB



# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	F55
Connector Name	STARTER CUT RELAY
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	G	-
3	L	-
5	GR	-

Connector No.	F42
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
87	L	CAN-H
88	P	CAN-L
92	GR	LI NP SW

Connector No.	F41
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
83	G	O STARTER
86	GR	FL STARTER

Connector No.	F78
Connector Name	TRANSMISSION RANGE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
7	BG	-
10	GR	-

Connector No.	F75
Connector Name	TCM (TRANSMISSION CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
23	P	CAN-L
33	L	CAN-H

AAKIA3211GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P



SEC

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >



Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
62	Y	SES INT MIDDLE ANTENNA B (WITH INTELLIGENT KEY SYSTEM)
63	L	SES INT MIDDLE ANTENNA A (WITH INTELLIGENT KEY SYSTEM)
80	P	CAN-L

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN

Terminal No.	Color of Wire	Signal Name
50	W	I RR DOOR SW
52	R	I RL DOOR SW
53	SB	I AS DOOR2 SW
57	SB	I DR DOOR2 SW

Connector No.	B70
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	B49
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
6	SB	-
10	W	-


AAKIA3212GB

# ENGINE START FUNCTION

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

Connector No.	B140
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	v of Wire	Signal Name
6	GR	-
10	W	-

Connector No.	B77
Connector Name	INSIDE KEY ANTENNA (CONSOLE)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
1	L	-
2	Y	-

Connector No.	B71
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	SB	-

Connector No.	B142
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	W	-

Connector No.	B141
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	GR	-

AAKIA3213GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS


< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

## NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

### Wiring Diagram


INFOID:000000012423946



# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

AAKWA1118GB


# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]


## NVIS CONNECTORS - WITH INTELLIGENT KEY SYSTEM

Connector No.	M5
Connector Name	DONGLE UNIT
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
4	B	-

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M14
Connector Name	JOINT CONNECTOR-M30
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
2	Y	-
3	Y	-
4	Y	-

Connector No.	M17
Connector Name	PUSH BUTTON IGNITION SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
4	B	-
5	Y	-
7	B	-
8	W	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
16	P	DONGLE UART
35	BG	O SECURITY LED

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
88	W	O START SW BACKLIGHT LED (WITH INTELLIGENT KEY SYSTEM)
89	Y	I START WO ESCL SW
95	V	I SHORTING PIN
114	Y	O IMMOBILIZER KAZASHI B (WITH INTELLIGENT KEY SYSTEM)
115	W	O IMMOBILIZER KAZASHI A (WITH INTELLIGENT KEY SYSTEM)

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

Connector No.	M25
Connector Name	NATS ANTENNA AMP (WITH INTELLIGENT KEY SYSTEM)
Connector Color	WHITE

1	2	3
---	---	---

Terminal No.	Color of Wire	Signal Name
1	W	-
3	Y	-

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN


  

167	168	169	170	171	172	173	174	175	176	177	178	179	180	181
-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----	-----

Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2


Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
11	P	-
15	P	-

Terminal No.	Color of Wire	Signal Name
37J	Y	-
60J	P	-
61J	L	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



AAKIA2319GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P



SEC

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >


[WITH INTELLIGENT KEY SYSTEM]

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
3R	V	-
14R	W	-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
13P	LA/G	-

Connector No.	M170
Connector Name	JOINT CONNECTOR-M29
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
2	B	-

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
45	LA/G	BAT

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	BG	SECURITY

AAKIA2320GB



# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	1	Color of Wire	L	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	E16
Connector Name	ECM
Connector Color	BLACK




Terminal No.	99	Color of Wire	P	Signal Name	CAN-L
100	L			CAN-H	

Connector No.	E19
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	7	Color of Wire	G	Signal Name	-
--------------	---	---------------	---	-------------	---

Connector No.	E29
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	139	Color of Wire	G	Signal Name	O STCUT RL
--------------	-----	---------------	---	-------------	------------

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	1	Color of Wire	L	Signal Name	-
2	P			-	
5	L			-	
6	P			-	
9	L			-	
10	P			-	

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	12	Color of Wire	B	Signal Name	SIGNAL GROUND
--------------	----	---------------	---	-------------	---------------

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


SEC

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND
32	GR	LI PUSH SW

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED



Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
37J	GR	-
60J	P	-
61J	L	-

Connector No.	F32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-

AAKIA2322GB

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]

Connector No.	F41
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
83	G	O STARTER
86	GR	FL STARTER

Connector No.	F35
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
70	BG	O IGN AT LPG

Connector No.	F33
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
7	G	-

Connector No.	F78
Connector Name	TRANSMISSION RANGE SWITCH
Connector Color	BLACK




Terminal No.	Color of Wire	Signal Name
7	BG	-
10	GR	-

Connector No.	F55
Connector Name	STARTER CUT RELAY
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	G	-
3	L	-
5	GR	-

Connector No.	F42
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
92	GR	LI NP SW

AAKIA2323GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


SEC

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

< WIRING DIAGRAM >


[WITH INTELLIGENT KEY SYSTEM]

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

AAKIA2324GB

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >


## VEHICLE SECURITY SYSTEM

### Wiring Diagram

INFOID:000000012423947

\*1 <P2> : 7  
 \*2 <P2> : 8  
 <P3> : 3  
 <P3> : 4  
 <P2> : WITH POWER BACK DOOR  
 <P3> : WITHOUT POWER BACK DOOR

### VEHICLE SECURITY SYSTEM



AAKWA1335GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]




AAKWA0985GB

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


SEC

AAKWA0986GB

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >



AAKWA0987GB




# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >


## VEHICLE SECURITY SYSTEM CONNECTORS

Connector No.	M16
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
10	BG	I DOORLOCK SW
35	BG	O SECURITY LED
40	SB	I DOORUNLOCK SW

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
82	W	I SES FR HANDLE BUTTON SW (WITH INTELLIGENT KEY SYSTEM)
92	BR	I-KEY CYLINDER LOCK SW
93	P	I-KEY CYLINDER UNLOCK SW
95	V	I SHORTING PIN
100	V	SES EXT DR ANTENNA A

Terminal No.	Color of Wire	Signal Name
105	Y	I SES FL HANDLE BUTTON (WITH INTELLIGENT KEY SYSTEM)
116	BG	SES INT FRONT ANTENNA B (WITH INTELLIGENT KEY SYSTEM)
117	GR	SES INT FRONT ANTENNA A (WITH INTELLIGENT KEY SYSTEM)
118	SB	SES EXT RIGHT ANTENNA B (WITH INTELLIGENT KEY SYSTEM)
119	P	SES EXT RIGHT ANTENNA A (WITH INTELLIGENT KEY SYSTEM)
120	BR	SES EXT LEFT ANTENNA B (WITH INTELLIGENT KEY SYSTEM)

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
167	LAV	I PWR DOORLOCK1
170	B	I GND1
171	B	I GND2
175	R	I PWR DOORLOCK2

AAKIA3203GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


SEC

# VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]


Connector No.	M33
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	5N	Color of Wire	R	Signal Name	-
--------------	----	---------------	---	-------------	---

Terminal No.	60J	Color of Wire	P	Signal Name	-
	61J		L		-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN




Terminal No.	3R	Color of Wire	V	Signal Name	-
	7R		LAV		-
	14R		W		-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	13P	Color of Wire	LA/G	Signal Name	-
--------------	-----	---------------	------	-------------	---

Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	1	Color of Wire	L	Signal Name	-
	2		L		-
	11		P		-
	12		P		-


AAKIA2337GB

# VEHICLE SECURITY SYSTEM

< WIRING DIAGRAM >


[WITH INTELLIGENT KEY SYSTEM]

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
45	LA/G	BAT

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	BG	SECURITY

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M168
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
20	BR	-
21	P	-
23	BG	-
24	SB	-

Connector No.	M167
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
16	B	-

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
19	LG	-
20	BR	-

AAKIA1807GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

Connector No.	E47
Connector Name	HORN
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	R	-

Connector No.	E46
Connector Name	HORN
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	B	-

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	L	-
6	P	-
9	L	-
10	P	-

Connector No.	E101
Connector Name	ANTI-THEFT HORN RELAY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	R	-
3	GR	-

Connector No.	E49
Connector Name	HORN (LOW)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	R	-

Connector No.	E48
Connector Name	HORN (LOW)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	B	-

AAKIA2448GB

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED




Terminal No.	47	Color of Wire	B	Signal Name	POWER GROUND
--------------	----	---------------	---	-------------	--------------

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	22	Color of Wire	P	Signal Name	CAN-L
Terminal No.	24	Color of Wire	L	Signal Name	CAN-H
Terminal No.	31	Color of Wire	B	Signal Name	2ND SIGNAL GROUND


Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	9	Color of Wire	L	Signal Name	LO HRN RLY
Terminal No.	12	Color of Wire	B	Signal Name	SIGNAL GROUND

Terminal No.	60J	Color of Wire	P	Signal Name	-
Terminal No.	61J	Color of Wire	L	Signal Name	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



AAKIA2338GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61

Terminal No.	Color of Wire	Signal Name
50	W	I RR DOOR SW
51	LG	I TGATESW
52	R	I RL DOOR SW
53	SB	I AS DOOR2 SW
57	SB	I DR DOOR2 SW
60	L	CAN-H

Terminal No.	Color of Wire	Signal Name
61	BR	SES EXT REAR ANTENNA B
62	Y	SES INT MIDDLE ANTENNA B (WITH INTELLIGENT KEY SYSTEM)
63	L	SES INT MIDDLE ANTENNA A (WITH INTELLIGENT KEY SYSTEM)
64	G	SES EXT REAR ANTENNA A (WITH INTELLIGENT KEY SYSTEM)
80	P	CAN-L

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	B46
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Terminal No.	Color of Wire	Signal Name
19	LG	-

Connector No.	B49
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5		
6	7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name
6	SB	-
10	W	-

Connector No.	B54
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2
---	---


Terminal No.	Color of Wire	Signal Name
1	B	-

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	B71
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	SB	-

Connector No.	B70
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	B142
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	W	-

Connector No.	B141
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	GR	-

Connector No.	B140
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	GR	-
10	W	-

AAKIA2450GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


SEC

# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	D6
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	GND
3	L	LOCK SW
15	BG	UNLOCK SW

Connector No.	D3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20	BR	-
21	P	-
23	L	-
24	BG	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
16	B	-

Connector No.	D112
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	BR	-
3	B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
19	LG	-
20	BR	-

Connector No.	D23
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	B	-
5	P	-
6	BR	-

AAKIA3205GB





# VEHICLE SECURITY SYSTEM

[WITH INTELLIGENT KEY SYSTEM]



< WIRING DIAGRAM >

Connector No.	D508
Connector Name	BACK DOOR LOCK ASSEMBLY (WITHOUT AUTOMATIC BACK DOOR SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	W	-
4	GR	-

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
19	W	-

Connector No.	D512
Connector Name	BACK DOOR LOCK ASSEMBLY (WITH AUTOMATIC BACK DOOR SYSTEM)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
7	W	-
8	B	-

AAKIA3218GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# DIAGNOSIS AND REPAIR WORK FLOW

< BASIC INSPECTION >

[WITH INTELLIGENT KEY SYSTEM]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORK FLOW

Work Flow

INFOID:000000012423948

OVERALL SEQUENCE



ALAI0158GB

DETAILED FLOW

Revision: September 2015

SEC-66

2016 Rogue NAM

# DIAGNOSIS AND REPAIR WORK FLOW

[WITH INTELLIGENT KEY SYSTEM]

< BASIC INSPECTION >

## 1. GET INFORMATION FOR SYMPTOM

1. Get detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurs).
2. Check operation condition of the function that is malfunctioning.

>> GO TO 2.

## 2. CHECK DTC

1. Check DTC.
2. Perform the following procedure if DTC is detected.
  - Record DTC and freeze frame data (Print them out using CONSULT.)
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Are any symptoms described and any DTC detected?

Symptom is described, DTC is detected>>GO TO 3.

Symptom is described, DTC is not detected>>GO TO 4.

Symptom is not described, DTC is detected>>GO TO 5.

## 3. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Also study the normal operation and fail-safe related to the symptom.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

## 4. CONFIRM THE SYMPTOM

Try to confirm the symptom described by the customer.

Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

## 5. PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC CONFIRMATION PROCEDURE for the detected DTC, and then check that DTC is detected again. At this time, always connect CONSULT to the vehicle, and check self diagnostic results in real time. If two or more DTCs are detected, refer to [BCS-47. "DTC Inspection Priority Chart"](#) and determine trouble diagnosis order.

**NOTE:**

- Freeze frame data is useful if the DTC is not detected.
- Perform Component Function Check if DTC CONFIRMATION PROCEDURE is not included on Service Manual. This simplified check procedure is an effective alternative though DTC cannot be detected during this check.  
If the result of Component Function Check is NG, it is the same as the detection of DTC by DTC CONFIRMATION PROCEDURE.

Is DTC detected?

YES >> GO TO 7.

NO >> Check according to [GI-45. "Intermittent Incident"](#).

## 6. DETECT MALFUNCTIONING SYSTEM BY SYMPTOM DIAGNOSIS

Detect malfunctioning system according to SYMPTOM DIAGNOSIS based on the confirmed symptom in step 4, and determine the trouble diagnosis order based on possible causes and symptom.

Is the symptom described?

YES >> GO TO 7.

NO >> Monitor input data from related sensors or check voltage of related module terminals using CONSULT.

## 7. DETECT MALFUNCTIONING PART BY DIAGNOSIS PROCEDURE

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## DIAGNOSIS AND REPAIR WORK FLOW

[WITH INTELLIGENT KEY SYSTEM]

< BASIC INSPECTION >

Inspect according to Diagnosis Procedure of the system.

Is malfunctioning part detected?

YES >> GO TO 8.

NO >> Check according to [GI-45. "Intermittent Incident"](#).

### 8. REPAIR OR REPLACE THE MALFUNCTIONING PART

---

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnosis Procedure again after repair and replacement.
3. Check DTC. If DTC is detected, erase it.

>> GO TO 9.

### 9. FINAL CHECK

---

When DTC is detected in step 2, perform DTC CONFIRMATION PROCEDURE again, and then check that the malfunction is repaired securely.

When symptom is described by the customer, refer to confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Is DTC detected and does symptom remain?

YES-1 >> DTC is detected: GO TO 7.

YES-2 >> Symptom remains: GO TO 4.

NO >> Before returning the vehicle to the customer, always erase DTC.

# ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

< BASIC INSPECTION >

[WITH INTELLIGENT KEY SYSTEM]

## ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

### ECM

#### ECM : Description

INFOID:0000000012423949

Performing the following procedure can automatically activate recommunication of ECM and BCM, but only when the ECM is replaced with a new one\*.

\*: New one means an ECM that has never been energized on-board.

(In this step, initialization procedure by CONSULT is not necessary)

#### NOTE:

- If multiple keys are attached to the key holder, separate them before beginning work.
- Distinguish keys with unregistered key IDs from those with registered IDs.

#### ECM : Work Procedure

INFOID:0000000012423950

### 1.PERFORM ECM RECOMMUNICATING FUNCTION

1. Install ECM.
2. Contact backside of registered Intelligent Key\* to push-button ignition switch, then turn ignition switch to ON.  
\*: To perform this step, use the key that is used before performing ECM replacement.
3. Maintain ignition switch in the ON position for at least 5 seconds.
4. Turn ignition switch to OFF.
5. Check that the engine starts.

>> GO TO 2.

### 2.PERFORM ADDITIONAL SERVICE WHEN REPLACING ECM

Perform [EC-139. "Work Procedure"](#).

>> Inspection End.

### BCM

#### BCM : Description

INFOID:0000000012423951

#### BEFORE REPLACEMENT

When replacing BCM, save or print current vehicle specification with CONSULT configuration before replacement.

#### NOTE:

If "READ CONFIGURATION" can not be used, use the "WRITE CONFIGURATION - Manual selection" after replacing BCM.

#### AFTER REPLACEMENT

#### CAUTION:

When replacing BCM, always perform "WRITE CONFIGURATION" with CONSULT. Or not doing so, BCM control function does not operate normally.

- Complete the procedure of "WRITE CONFIGURATION" in order.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- If you set incorrect "WRITE CONFIGURATION", incidents might occur.

#### NOTE:

When replacing BCM, perform the system initialization (NATS). Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### BCM : Work Procedure

INFOID:0000000012423952

### 1.SAVING VEHICLE SPECIFICATION

 CONSULT Configuration

Perform "READ CONFIGURATION" to save or print current vehicle specification. Refer to [BCS-62. "CONFIGURATION \(BCM\) : Description"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

< BASIC INSPECTION >

[WITH INTELLIGENT KEY SYSTEM]

---

### NOTE:

If "READ CONFIGURATION" can not be used, use the "WRITE CONFIGURATION - Manual selection" after replacing BCM.

>> GO TO 2.

## 2. REPLACE BCM

---

Replace BCM. Refer to [BCS-76, "Removal and Installation"](#).

>> GO TO 3.

## 3. WRITING VEHICLE SPECIFICATION

---

### ⓅCONSULT Configuration

Perform "WRITE CONFIGURATION - Config file" or "WRITE CONFIGURATION - Manual selection" to write vehicle specification. Refer to [BCS-62, "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 4.

## 4. INITIALIZE BCM (NATS)

---

Perform BCM initialization. (NATS) Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

# DTC/CIRCUIT DIAGNOSIS

## P1610 LOCK MODE

### Description

INFOID:0000000012423953

ECM forcibly switches to the mode that inhibits engine start, when engine start operation is performed 5 times or more while communication between ECM and BCM is not normal.

### DTC Logic

INFOID:0000000012423954

### DTC DETECTION LOGIC

**NOTE:**

- If DTC B1610 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).
- If DTC B1610 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-66, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1610	LOCK MODE	When ECM detects a communication malfunction between ECM and BCM 5 times or more.	—

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

Is DTC detected?

- YES >> Go to [SEC-71, "Diagnosis Procedure"](#).
- NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012423955

#### 1. CHECK ENGINE START FUNCTION

1. Check that there are no DTC's except for DTC P1610 detected.  
If detected, erase the DTC after fixing.
2. Turn ignition switch OFF.
3. Contact the registered Intelligent Key backside to push-button ignition switch and wait 5 seconds.
4. Turn ignition switch ON.
5. Turn ignition switch OFF and wait 5 seconds.
6. Repeat steps 3 and 5 twice (a total of 3 times).
7. Check that engine can start.

>> Inspection End.



# P1611 ID DISCORD, IMMUECM

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## P1611 ID DISCORD, IMMUECM

### DTC Logic

INFOID:000000012423956

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1611	ID DISCORD, IMMUECM	The ID verification results between BCM and ECM are NG.	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• BCM</li><li>• ECM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-72, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012423957

#### 1. PERFORM INITIALIZATION

Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with reregistered Intelligent Key?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2. CHECK SELF DIAGNOSTIC RESULT

1. Select "Self Diagnostic Result" of "ENGINE" using CONSULT.
2. Erase DTC.
3. Perform DTC CONFIRMATION PROCEDURE for DTC P1611. Refer to [SEC-72, "DTC Logic"](#).

#### Is DTC detected?

- YES >> GO TO 3.  
NO >> Inspection End.

#### 3. REPLACE BCM

1. Replace BCM. Refer to [BCS-76, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with registered Intelligent Key?

- YES >> Inspection End.  
NO >> GO TO 4.

#### 4. REPLACE ECM

1. Replace ECM. Refer to [EC-503, "Removal and Installation"](#).
2. Perform "ADDITIONAL SERVICE WHEN REPLACING ECM". Refer to [EC-139, "Work Procedure"](#).

>> Inspection End.



# P1612 CHAIN OF ECM-IMMU

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## P1612 CHAIN OF ECM-IMMU

### DTC Logic

INFOID:000000012423958

### DTC DETECTION LOGIC

#### NOTE:

- If DTC P1612 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).
- If DTC P1612 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-66, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1612	CHAIN OF BCM-ECM	Inactive communication between BCM and ECM	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• ECM</li><li>• BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-73, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012423959

#### NOTE:

- If DTC P1612 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).
- If DTC P1612 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-66, "DTC Logic"](#).

#### 1.CHECK BCM POWER SUPPLY AND GROUND CIRCUIT.

Check BCM power supply and ground circuit. Refer to [BCS-69, "Diagnosis Procedure"](#).

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace the harness.

#### 2.CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.

Check ECM power supply and ground circuit. Refer to [EC-168, "Diagnosis Procedure"](#).

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace the harness.

#### 3.PERFORM DTC CONFIRMATION PROCEDURE.

Perform the DTC confirmation procedure. Refer to [SEC-73, "DTC Logic"](#).

#### Does the DTC return?

- YES >> Replace BCM. Refer to [BCS-76, "Removal and Installation"](#)  
NO >> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# P161D IMMOBILIZER

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## P161D IMMOBILIZER

### DTC Logic

INFOID:000000012423960

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P161D	IMMOBILIZER	When immobilizer detects a malfunction, and prohibits the engine start.	BCM

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-76. "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012423961

#### 1.REPLACE BCM

Replace BCM. Refer to [BCS-76. "Removal and Installation"](#).

>> Inspection End.

# P161E IMMOBILIZER

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## P161E IMMOBILIZER

### DTC Logic

INFOID:000000012423962

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P161E	IMMOBILIZER	After replacing the ECM, when the ECM is not registered to the vehicle by using the CONSULT.	<ul style="list-style-type: none"><li>• BCM</li><li>• ECM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in “Self Diagnostic Result” of “ENGINE” using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-76, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012423963

#### 1.PERFORM REGISTRATION OF ECM

Perform registration of ECM using CONSULT.

#### Is DTC detected?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2.REPLACE BCM

Replace BCM. Refer to [BCS-76, "Removal and Installation"](#).

#### Is DTC detected?

- YES >> GO TO 3.  
NO >> Inspection End.

#### 3.REPLACE ECM

Replace ECM. Refer to [EC-503, "Removal and Installation"](#).

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# P161F IMMOBILIZER

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## P161F IMMOBILIZER

### DTC Logic

INFOID:000000012423964

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P161F	IMMOBILIZER	When immobilizer detects a malfunction, and prohibits the engine start.	ECM

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-76. "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012423965

#### 1.REPLACE ECM

Replace ECM. Refer to [EC-503. "Removal and Installation"](#).

>> Inspection End.

# B2190 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2190 NATS ANTENNA AMP.

### Description

INFOID:0000000012423966

Performs ID verification through BCM and NATS antenna amplifier when ignition switch turned ON.  
Prohibits the start of engine when an unregistered ID of ignition key is used.

### DTC Logic

INFOID:0000000012423967

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2190	NATS ANTENNA AMP	<ul style="list-style-type: none"><li>Inactive communication between NATS antenna amp. and BCM.</li><li>Ignition key is malfunctioning.</li></ul>	<ul style="list-style-type: none"><li>Harness or connectors (The NATS antenna amp. circuit is open or shorted)</li><li>Ignition key</li><li>NATS antenna amp.</li><li>BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-77, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012423968

#### 1. INTELLIGENT KEY REGISTRATION

Using CONSULT, register all Intelligent Keys again.

>> GO TO 2.

#### 2. CHECK SELF DIAGNOSTIC RESULT

- Select "Self Diagnostic Result" of "BCM" using CONSULT.
- Erase DTC.
- Perform DTC CONFIRMATION PROCEDURE for B2190. Refer to [SEC-77, "Description"](#).

#### Is DTC detected?

- YES >> GO TO 3.  
NO >> Inspection End.



#### 3. CHECK NATS ANTENNA COMMUNICATION SIGNAL

Check voltage signal between NATS antenna amp. harness connector and ground using an oscilloscope.

# B2190 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

(+)		(-)	Condition	Voltage (Approx.)
NATS antenna amp.				
Connector	Terminal			
M25	1	Ground	Other than above.	 <p style="text-align: right; font-size: small;">JMMIA1651GB</p>
	3		When a registered Intelligent Key back-side is contacted to push-button ignition switch.	0 V
	3		Other than above.	 <p style="text-align: right; font-size: small;">JMMIA1650GB</p>
			When a registered Intelligent Key back-side is contacted to push-button ignition switch.	0 V

**Is the inspection result normal?**

- YES >> Replace NATS antenna amp. Refer to [SEC-118, "Removal and Installation"](#).
- NO >> GO TO 4.

## 4. CHECK NATS ANTENNA COMMUNICATION SIGNAL CIRCUIT

1. Disconnect BCM connector and NATS antenna connector.
2. Check continuity between NATS antenna amp. harness connector and BCM harness connector.

NATS antenna amp.		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M25	1	M19	115	Yes
	3		114	

3. Check continuity between NATS antenna amp. connector and ground.

NATS antenna amp.		Ground	Continuity
Connector	Terminal		
M25	1		
	3		

**Is the inspection result normal?**

- YES >> GO TO 5.
- NO >> Repair or replace harness.

## 5. REPLACE BCM

Replace BCM. Refer to [BCS-76, "Removal and Installation"](#).

# B2190 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

>> Inspection End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

# B2191 DIFFERENCE OF KEY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2191 DIFFERENCE OF KEY

### DTC Logic

INFOID:000000012423969

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2191	DIFFERENCE OF KEY	The ID verification results between BCM and Intelligent Key are NG. The registration is necessary.	Intelligent Key

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-80, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012423970

#### 1.INTELLIGENT KEY REGISTRATION

Using CONSULT, register all Intelligent Keys again.

#### Can engine be started with the registered Intelligent Key?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2.REPLACE INTELLIGENT KEY

1. Prepare Intelligent Key that matches the vehicle.
2. Registration of all Intelligent Key using CONSULT.

#### Can engine be started with the registered Intelligent Key?

- YES >> Inspection End.  
NO >> GO TO 3.

#### 3.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> Inspection End.



# B2192 ID DISCORD, IMMUECM

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2192 ID DISCORD, IMMUECM

### DTC Logic

INFOID:000000012423971

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2192	ID DISCORD BCM-ECM	The ID verification results between BCM and ECM are NG.	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• BCM</li><li>• ECM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-81, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012423972

#### 1. PERFORM INITIALIZATION

Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with reregistered Intelligent Key?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2. CHECK SELF-DIAGNOSTIC RESULT

1. Select "Self Diagnostic Result" of "BCM" using CONSULT.
2. Erase DTC.
3. Perform DTC CONFIRMATION PROCEDURE for DTC B2192. Refer to [SEC-81, "DTC Logic"](#).

#### Is DTC detected?

- YES >> GO TO 3.  
NO >> Inspection End.

#### 3. REPLACE BCM

1. Replace BCM. Refer to [BCS-76, "Removal and Installation"](#).
2. Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with registered Intelligent Key?

- YES >> Inspection End.  
NO >> GO TO 4.

#### 4. REPLACE ECM

1. Replace ECM. Refer to [EC-503, "Removal and Installation"](#).
2. Perform "ADDITIONAL SERVICE WHEN REPLACING ECM". Refer to [EC-139, "Work Procedure"](#).

>> Inspection End.

# B2193 CHAIN OF ECM-IMMU

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2193 CHAIN OF ECM-IMMU

### DTC Logic

INFOID:000000012423973

#### DTC DETECTION LOGIC

**NOTE:**

- If DTC B2193 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).
- If DTC B2193 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-66, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2193	CHAIN OF BCM-ECM	Inactive communication between BCM and ECM	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• ECM</li><li>• BCM</li></ul>

#### DTC CONFIRMATION PROCEDURE

### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

Is DTC detected?

- YES >> GO TO [SEC-82, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012423974

**NOTE:**

- If DTC B2193 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).
- If DTC B2193 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-66, "DTC Logic"](#).

### 1.CHECK BCM POWER SUPPLY AND GROUND CIRCUIT.

Check BCM power supply and ground circuit. Refer to [BCS-69, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace the harness.

### 2.CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.

Check ECM power supply and ground circuit. Refer to [EC-168, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> Replace ECM. Refer to [EC-503, "Removal and Installation"](#). GO TO 3.  
NO >> Repair or replace the harness.

### 3.PERFORM DTC CONFIRMATION PROCEDURE.

Perform the DTC confirmation procedure. Refer to [SEC-82, "DTC Logic"](#).

Does the DTC return?

- YES >> Replace BCM. Refer to [BCS-76, "Removal and Installation"](#)  
NO >> Inspection End.

# B2196 DONGLE UNIT

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## B2196 DONGLE UNIT

### Description

INFOID:000000012423975

BCM performs ID verification between BCM and dongle unit.  
When verification result is OK, BCM permits cranking.

### DTC Logic

INFOID:000000012423976

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2196 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).
- If DTC B2196 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-66, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2196	DONGLE NG	The ID verification results between BCM and dongle unit is NG.	<ul style="list-style-type: none"><li>• Harness or connectors (Dongle unit circuit is open or shorted.)</li><li>• Dongle unit</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn ignition switch OFF.
3. Turn ignition switch ON.
4. Check "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is the DTC detected?

- YES >> Refer to [SEC-83, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012423977

Regarding Wiring Diagram information, refer to [SEC-44, "Wiring Diagram"](#).

##### 1. PERFORM INITIALIZATION

1. Perform initialization of BCM and reregistration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.
2. Start the engine.

##### Dose the engine start?

- YES >> Inspection End.  
NO >> GO TO 2.

##### 2. CHECK DONGLE UNIT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and dongle unit connector.
3. Check continuity between BCM harness connector and dongle unit harness connector.

BCM		Dongle unit		Continuity
Connector	Terminal	Connector	Terminal	
M18	16	M5	1	Yes

4. Check continuity between BCM harness connector and ground.

## B2196 DONGLE UNIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

BCM		Ground	Continuity
Connector	Terminal		
M18	16		No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3. CHECK DONGLE UNIT GROUND CIRCUIT

Check continuity between dongle unit harness connector and ground.

Dongle unit		Ground	Continuity
Connector	Terminal		
M5	4		Yes

Is the inspection result normal?

YES >> Replace dongle unit.

NO >> Repair or replace harness.

# B2198 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2198 NATS ANTENNA AMP.

### DTC Logic

INFOID:0000000012423978

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2198	NATS ANTENNA AMP	Inactive communication between NATS antenna amp. and BCM.	<ul style="list-style-type: none"> <li>• Harness or connectors (The NATS antenna amp. circuit is open or shorted)</li> <li>• NATS antenna amp.</li> <li>• BCM</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE 1

1. Contact Intelligent Key back side to push-button ignition switch.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-85. "Diagnosis Procedure"](#).  
 NO >> GO TO 2.

#### 2.PERFORM DTC CONFIRMATION PROCEDURE 2

1. Press the push-button ignition switch.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-85. "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012423979

Regarding Wiring Diagram information, refer to [SEC-44. "Wiring Diagram"](#).

SEC

#### 1.CONNECTOR INSPECTION

1. Disconnect BCM and NATS antenna amp.
2. Check connectors and terminals for deformation, disconnection, looseness or damage.

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Repair or replace as necessary.

#### 2.CHECK NATS ANTENNA AMP. CIRCUIT

1. Disconnect BCM connector and NATS antenna amp. connector.
2. Check continuity between BCM harness connector and NATS antenna amp. harness connector.

BCM		NATS antenna amp.		Continuity
Connector	Terminal	Connector	Terminal	
M19	114	M25	3	Yes
	115		1	

3. Check continuity between BCM harness connector and ground.

## B2198 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

BCM		Ground	Continuity
Connector	Terminal		
M19	114		No
	115		



Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3. CHECK NATS ANTENNA AMP INPUT SIGNAL 1

1. Turn ignition switch ON.
2. Check signal between BCM harness connector and ground using oscilloscope.

(+)		(-)	Condition	Signal (Reference value)
BCM				
Connector	Terminal			
M19	114, 115	Ground	When Intelligent Key is in the antenna detection area	
			When Intelligent Key is not in the antenna detection area	

Is the inspection result normal?

YES >> Replace BCM. Refer to [BCS-76. "Removal and Installation"](#).

NO >> Replace NATS antenna amp. Refer to [SEC-118. "Removal and Installation"](#).

# B2556 PUSH-BUTTON IGNITION SWITCH

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2556 PUSH-BUTTON IGNITION SWITCH

### DTC Logic

INFOID:0000000012423980

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2556	PUSH-BTN IGN SW	BCM detects the push-button ignition switch stuck at ON for 100 seconds or more.	<ul style="list-style-type: none"><li>• Harness or connectors (Push-button ignition switch circuit is shorted.)</li><li>• Push-button ignition switch</li><li>• BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch under the following condition:
  - Brake pedal: Not depressed
2. Release push-button ignition switch and wait 100 seconds or more.
3. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-87. "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012423981

Regarding Wiring Diagram information, refer to [SEC-31. "Wiring Diagram"](#).

#### 1. CHECK PUSH-BUTTON IGNITION SWITCH INPUT SIGNAL

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check voltage between push-button ignition switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Push-button ignition switch			
Connector	Terminal	Ground	Battery voltage
M17	5		

#### Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 2.

#### 2. CHECK PUSH-BUTTON IGNITION SWITCH CIRCUIT

1. Disconnect BCM connector and IPDM E/R connector.
2. Check continuity between push-button ignition switch harness connector and BCM harness connector.

Push-button ignition switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M17	5	M19	89	Yes

3. Check continuity between push-button ignition switch harness connector and ground.

Push-button ignition switch		Ground	Continuity
Connector	Terminal		
M17	5		No

# B2556 PUSH-BUTTON IGNITION SWITCH

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

Is the inspection result normal?

- YES >> GO TO 3.
- NO >> Repair or replace harness.

## 3.REPLACE BCM

1. Replace BCM. Refer to [BCS-76. "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

## 4.CHECK PUSH-BUTTON IGNITION SWITCH

Refer to [SEC-88. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Replace push-button ignition switch. Refer to [SEC-120. "Removal and Installation"](#).

## 5.CHECK INTERMITTENT INCIDENT

Refer to [GI-45. "Intermittent Incident"](#).

>> Inspection End.

## Component Inspection

INFOID:0000000012423982

## 1.CHECK PUSH-BUTTON IGNITION SWITCH

1. Turn ignition switch OFF.
2. Disconnect push-button ignition switch connector.
3. Check continuity between push-button ignition switch terminals.

Push-button ignition switch		Condition	Continuity	
Terminal				
4	5	Push-button ignition switch	Pressed	Yes
			Not pressed	No

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace push-button ignition switch. Refer to [SEC-120. "Removal and Installation"](#).



# B2557 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2557 VEHICLE SPEED

### DTC Logic

INFOID:0000000012423983

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2557 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).
- If DTC B2557 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-66, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible causes
B2557	VEHICLE SPEED	BCM detects one of the following conditions for 10 seconds continuously. <ul style="list-style-type: none"><li>• Vehicle speed signal from combination meter is 10 km/h (6.2 MPH) or more, and vehicle speed signal from ABS actuator and electric unit (control unit) is 4 km/h (2.5 MPH) or less.</li><li>• Vehicle speed signal from combination meter is 4 km/h (2.5 MPH) or less, and vehicle speed signal from ABS actuator and electric unit (control unit) is 10 km/h (6.2 MPH) or more.</li></ul>	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• Combination meter</li><li>• ABS actuator and electric unit (control unit)</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine and wait 10 seconds or more.
2. Drive the vehicle at a vehicle speed of 10 km/h (6.2 MPH) or more for 10 seconds or more.
3. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-89, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012423984

#### 1. CHECK DTC OF "ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)"

Check DTC in "Self Diagnostic Result" of "ABS" using CONSULT.

#### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [BRC-57, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. CHECK DTC OF "COMBINATION METER"

Check DTC in "Self Diagnostic Result" of "METER/M&A" using CONSULT.

#### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-31, "DTC Index"](#).  
NO >> GO TO 3.

#### 3. CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> Inspection End.

# B2602 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2602 SHIFT POSITION

### DTC Logic

INFOID:000000012423985

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2602 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).
- If DTC B2602 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-66, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2602	SHIFT POSITION	BCM detects the following status for 10 seconds. <ul style="list-style-type: none"> <li>• Selector lever is in the P (Park) position</li> <li>• Vehicle speed is 4 km/h (2.5 MPH) or more</li> <li>• Ignition switch is in the ON position</li> </ul>	<ul style="list-style-type: none"> <li>• Harness or connectors (CAN communication line is open or shorted.)</li> <li>• Harness or connectors [CVT shift selector (park position switch) circuit is open or shorted.]</li> <li>• CVT shift selector (park position switch)</li> <li>• Combination meter</li> <li>• BCM</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Start engine.
2. Drive vehicle at a speed of 4 km/h (2.5 MPH) or more for 10 seconds or more.
3. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-90, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012423986

Regarding Wiring Diagram information, refer to [SEC-31, "Wiring Diagram"](#).

#### 1. CHECK CVT SHIFT SELECTOR SWITCH FUNCTION

1. Turn ignition switch ON.
2. Select "DETE/CANCEL SW" and "VEH SPEED 1" in "Data Monitor" with CONSULT.
3. Check "DETE/CANCEL SW" and "VEH SPEED 1" indication under the following conditions:

Monitor item	Condition		Indication
DETE/CANCEL SW	CVT Shift selector	In any position other than P (Park)	OFF
		P (Park)	ON
VEH SPEED 1	Vehicle not moving		0
	Vehicle moving		Varies

#### Is the inspection result normal?

- YES >> Refer to [GI-45, "Intermittent Incident"](#).  
 NO-1 >> If "DETE/CANCEL SW" is incorrect. GO TO 4.  
 NO-2 >> If "VEH SPEED 1" is incorrect. GO TO 2.

#### 2. CHECK DTC OF COMBINATION METER

Check DTC in "Self Diagnostic Result" of "METER/M&A" using CONSULT.

# B2602 SHIFT POSITION

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-31, "DTC Index"](#).
- NO >> GO TO 3.

### 3.CHECK DTC OF ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT)

Check DTC in "Self Diagnostic Result" of "ABS" using CONSULT.

## Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [BRC-57, "DTC Index"](#).
- NO >> GO TO 6.

### 4.CHECK CVT SHIFT SELECTOR CIRCUIT

1. Disconnect BCM connector and CVT shift selector connector.
2. Check continuity between CVT shift selector (park position switch) harness connector and BCM harness connector.

CVT shift selector (park position switch)		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M107	13	M19	94	Yes

3. Check continuity between CVT shift selector (park position switch) harness connector and ground.

CVT shift selector (park position switch)		Ground	Continuity
Connector	Terminal		
M107	13		No

## Is the inspection result normal?

- YES >> GO TO 5.
- NO >> Repair or replace harness.

### 5.CHECK CVT SHIFT SELECTOR CIRCUIT

1. Disconnect BCM connector and CVT shift selector connector.
2. Check continuity between CVT shift selector (park position switch) harness connector and BCM harness connector.

CVT shift selector (park position switch)		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M107	12	M18	17	Yes

3. Check continuity between CVT shift selector (park position switch) harness connector and ground.

CVT shift selector (park position switch)		Ground	Continuity
Connector	Terminal		
M107	12		No

## Is the inspection result normal?

- YES >> GO TO 6.
- NO >> Repair or replace harness.

### 6.CHECK CVT SHIFT SELECTOR (PARK POSITION SWITCH)

Refer to [SEC-92, "Component Inspection"](#).

## Is the inspection result normal?

- YES >> GO TO 7.
- NO >> Replace CVT shift selector. Refer to [TM-193, "Removal and Installation"](#).

### 7.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> Inspection End.

SEC

# B2602 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## Component Inspection

INFOID:000000012423987

### 1. CHECK CVT SHIFT SELECTOR (PARK POSITION SWITCH)

1. Turn ignition switch OFF.
2. Disconnect CVT shift selector connector.
3. Check continuity between CVT shift selector (park position switch) terminals.

CVT shift selector (park position switch)		Condition	Continuity	
Terminal				
12	13	Selector lever	P (Park) position	No
			Other than above	Yes

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace CVT shift selector. Refer to [TM-193, "Removal and Installation"](#).

# B2604 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2604 SHIFT POSITION

### DTC Logic

INFOID:000000012423988

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2604 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).
- If DTC B2604 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-66, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2604	SHIFT PN DIAG CAN	The following states are detected for 5 seconds while ignition switch is ON: <ul style="list-style-type: none"><li>• P/N position signal is sent from transmission range switch but shift position signal input (CAN) from TCM is other than P and N.</li><li>• P/N position signal is not sent from transmission range switch but shift position signal input (CAN) from TCM is P or N.</li></ul>	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• Harness or connectors (Transmission range switch circuit is open or shorted.)</li><li>• TCM</li><li>• BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Shift the selector lever to the P position.
2. Turn ignition switch ON and wait 5 seconds or more.
3. Shift the selector lever to the N position and wait 5 seconds or more.
4. Shift the selector lever to any position other than P and N, and wait 5 seconds or more.
5. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-93, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012423989

Regarding Wiring Diagram information, refer to [SEC-44, "Wiring Diagram"](#).

#### 1. CHECK DTC OF TCM

Check DTC in "Self Diagnostic Result" of "TCM" using CONSULT.

#### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [TM-63, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. CHECK FUSE

1. Turn power switch OFF.
2. Check that the following fuse in IPDM E/R is not blown.

Signal name	Fuse No.
Ignition power supply	46 (10 A)

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Replace the blown fuse after repairing the cause of blowing.

#### 3. CHECK TRANSMISSION RANGE SWITCH POWER SUPPLY

1. Disconnect transmission range switch connector.
2. Turn ignition switch ON.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B2604 SHIFT POSITION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

3. Check voltage between transmission range switch harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Transmission range switch			
Connector	Terminal	Ground	Battery voltage
F78	7		

Is the inspection result normal?

YES >> GO TO 5.

NO >> GO TO 4.

## 4.CHECK TRANSMISSION RANGE SWITCH POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between transmission range switch harness connector and IPDM E/R harness connector.

Transmission range switch		IPDM E/R		Continuity
Connector	Terminal	Connector	Terminal	
F78	7	F35	70	Yes

Is the inspection result normal?

YES >> Replace IPDM E/R. Refer to [PCS-44, "Removal and Installation"](#).

NO >> Repair or replace harness.

## 5.CHECK BCM INPUT SIGNAL

1. Turn ignition switch OFF.
2. Reconnect transmission range switch connector.
3. Turn ignition switch ON.
4. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
BCM				
Connector	Terminal	Ground	P or N position	Battery voltage
M19	89		Ground	Other than above

Is the inspection result normal?

YES >> GO TO 9.

NO >> GO TO 6.

## 6.CHECK BCM INPUT SIGNAL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect transmission range switch connector.
3. Disconnect BCM connector.
4. Check continuity between transmission range switch harness connector and BCM harness connector.

Transmission range switch		BCM		Continuity
Connector	Terminal	Connector	Terminal	
F78	10	M19	89	Yes

5. Check continuity between transmission range switch harness connector and ground.

Transmission range switch		Ground	Continuity
Connector	Terminal		
F78	10		No

Is the inspection result normal?

# B2604 SHIFT POSITION

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

- YES >> GO TO 7.
- NO >> Repair or replace harness.

## 7.CHECK TRANSMISSION RANGE SWITCH

Refer to [SEC-95. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 8.
- NO >> Replace transmission range switch.

## 8.CHECK INTERMITTENT INCIDENT

Refer to [GI-45. "Intermittent Incident"](#).

>> Inspection End.

## 9.REPLACE BCM

1. Replace BCM. Refer to [BCS-76. "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.

>> Inspection End.

## Component Inspection

INFOID:0000000012423990

## 1.CHECK TRANSMISSION RANGE SWITCH

1. Turn ignition switch OFF.
2. Disconnect transmission range switch connector.
3. Check continuity between transmission range switch terminals.

Transmission range switch		Condition	Continuity
Terminal			
7	10	P or N position	Yes
		Other than above	No

Is the inspection result normal?

- YES >> Inspection End.
- NO >> Replace transmission range switch.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B2608 STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B2608 STARTER RELAY

### DTC Logic

INFOID:0000000012423991

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2608 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).
- If DTC B2608 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-66, "DTC Logic"](#).
- If DTC B2608 is displayed with other DTC (BCM), first perform the trouble diagnosis for other DTC detected.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2608	STARTER RELAY	BCM outputs starter relay OFF signal but BCM receives starter relay ON signal from IPDM E/R (CAN).	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• Harness or connectors (Starter relay circuit is open or shorted.)</li><li>• IPDM E/R</li><li>• Starter relay</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch under the following conditions to start engine:
  - Selector lever: In the P position
  - Brake pedal: Depressed
2. Wait 1 second after engine started.
3. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-96, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012423992

#### 1. CHECK DTC OF IPDM E/R

Select "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

#### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [PCS-26, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

#### Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace BCM. Refer to [BCS-76, "Removal and Installation"](#).



# B260F ENGINE STATUS

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B260F ENGINE STATUS

### Description

INFOID:0000000012423993

BCM receives the engine status signal from ECM via CAN communication.

### DTC Description

INFOID:0000000012423994

### DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)	DTC detecting condition
B260F	ENG STATE SIG LOST (Engine state signal lost)	BCM has not yet received the engine status signal from ECM when ignition switch is in the ON position.

### POSSIBLE CAUSE

- Harness or connectors  
(The CAN communication line is open or shorted.)
- ECM

### FAIL-SAFE

Inhibit engine cranking

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK DTC PRIORITY

If DTC B260F is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for DTC U1000 or U1010.

#### Is applicable DTC detected?

- YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-65, "DTC Logic"](#). U1010: Refer to [BCS-66, "DTC Logic"](#).
- NO >> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait 2 seconds or more.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-97, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-45, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:0000000012423995

#### 1. CHECK DTC PRIORITY

If DTC B260F is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for DTC U1000 or U1010.

#### Is applicable DTC detected?

- YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-65, "DTC Logic"](#). U1010: Refer to [BCS-66, "DTC Logic"](#).
- NO >> GO TO 2.

#### 2. INSPECTION START

1. Turn ignition switch ON.
2. Select "Self Diagnostic Result" of "BCM" using CONSULT.
3. Touch "ERASE".
4. Perform DTC CONFIRMATION PROCEDURE for DTC B260F. Refer to [SEC-97, "DTC Description"](#).

#### Is DTC detected?

- YES >> GO TO 3.
- NO >> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## B260F ENGINE STATUS

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

---

### 3.REPLACE ECM

---

Replace ECM. Refer [EC-503. "Removal and Installation"](#).

>> Inspection End

# B261E VEHICLE TYPE

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## B261E VEHICLE TYPE

### Description

INFOID:0000000012423996

There are two types of vehicles.

- HEV
- Conventional

### DTC Logic

INFOID:0000000012423997

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B261E is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).
- If DTC B261E is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-66, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B261E	VEHICLE TYPE	Difference of BCM configuration.	<ul style="list-style-type: none"><li>• BCM mis-configuration</li><li>• Wrong ECM installed</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions.
  - Shift selector lever is in the P (Park) or N (Neutral) position
  - Do not depress brake pedal
2. Check "Self Diagnostic Result" of "BCM" using CONSULT.

Is DTC detected?

- YES >> GO TO [SEC-99, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012423998

#### 1. INSPECTION START

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" of "BCM" using CONSULT.
3. Touch "ERASE".
4. Perform DTC Confirmation Procedure. Refer to [SEC-99, "DTC Logic"](#).

Is the 1st trip DTC B261E displayed again?

- YES >> GO TO 2.  
NO >> Inspection End.

#### 2. PERFORM BCM CONFIGURATION.

Perform the BCM configuration. Refer to [BCS-62, "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 3.

#### 3. INSPECTION START

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" of "BCM" using CONSULT.
3. Touch "ERASE".
4. Perform DTC Confirmation Procedure.  
Refer to [SEC-99, "DTC Logic"](#).

Is the 1st trip DTC B261E displayed again?

- YES >> GO TO 4.  
NO >> Inspection End.

A

B

C

D

E

F

G

H

I

J

SEC

L

M

N

O

P

## B261E VEHICLE TYPE

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

---

### 4. CONFIRM ECM PART NUMBER.

---

Confirm the part number of the installed ECM is correct.

Is the ECM part number correct?

- YES >> Replace BCM. Refer to [BCS-76. "Removal and Installation"](#).
- NO >> Replace ECM. Refer to [EC-503. "Removal and Installation"](#).

# B26FC KEY REGISTRATION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B26FC KEY REGISTRATION

### DTC Logic

INFOID:000000012423999

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B26FC	KEY REGISTRATION	Intelligent Key that does not match the vehicle is registered.	<ul style="list-style-type: none"><li>• Improper registration operation</li><li>• Intelligent Key</li><li>• BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-101, "Diagnosis Procedure"](#)  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424000

#### 1.REPLACE INTELLIGENT KEY

1. Prepare Intelligent Key that matches the vehicle.
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.
3. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO 2.  
NO >> Inspection End.

#### 2.REPLACE BCM

1. Replace BCM. Refer to [BCS-76, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
SEC  
L  
M  
N  
O  
P

# B27D1 START CUT RELAY OFF

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B27D1 START CUT RELAY OFF

### DTC Logic

INFOID:0000000012424001

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B27D1 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).
- If DTC B27D1 is displayed with DTC B2605, first perform the trouble diagnosis for DTC B2605. Refer to [BCS-66, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B27D1	STARTER CUT RELAY OFF	When comparing the starter cut relay signal (CAN) from IPDM E/R, BCM detects that starter cut relay is stuck in the OFF position for 1 second or more.	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• Harness or connector (Starter cut relay circuit is open or shorted.)</li><li>• IPDM E/R</li><li>• BCM</li><li>• Starter cut relay</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch under the following conditions to start engine, and wait 1 second or more.
  - Selector lever: In the P position
  - Brake pedal: Depressed
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-102, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012424002

Regarding Wiring Diagram information, refer to [SEC-31, "Wiring Diagram"](#).

#### 1. CHECK STARTER CUT RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect starter cut relay.
3. Check voltage between starter cut relay harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Starter cut relay			
Connector	Terminal	Ground	Battery voltage
F55	1		
	3		

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO-1 >> Check 30 A fusible link [M, located in the fuse block (J/B)].  
NO-2 >> Check harness for open or short between starter cut relay and fusible link.

#### 2. CHECK STARTER CUT RELAY CONTROL

1. Reconnect starter cut relay.

# B27D1 START CUT RELAY OFF

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

2. Check voltage between BCM harness connector and ground.

(+)		(-)	Condition	Voltage (V) (Approx.)
BCM				
Connector	Terminal			
E29	139	Ground	CVT shift selector lever	N or P position
				Other than above
				0

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> GO TO 3.

## 3.CHECK STARTER CUT RELAY CONTROL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Disconnect starter cut relay.
4. Check continuity between BCM harness connector and starter cut relay harness connector.

BCM		Starter cut relay		Continuity
Connector	Terminal	Connector	Terminal	
E29	139	F55	2	Yes

Is the inspection result normal?

- YES >> GO TO 4.  
NO >> Repair or replace harness.

## 4.CHECK STARTER CUT RELAY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and starter cut relay harness connector.

IPDM E/R		Starter cut relay		Continuity
Connector	Terminal	Connector	Terminal	
F41	86	F55	5	Yes

4. Check continuity between BCM harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
F41	86		No

Is the inspection result normal?

- YES >> GO TO 5.  
NO >> Repair or replace harness.

## 5.CHECK STARTER CUT RELAY

Refer to [SEC-104. "Component Inspection"](#).

Is the inspection result normal?

- YES >> GO TO 6.  
NO >> Replace starter cut relay.

## 6.REPLACE BCM

1. Replace BCM. Refer to [BCS-76. "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.
3. Perform DTC CONFIRMATION PROCEDURE for DTC B27D1. Refer to [SEC-102. "DTC Logic"](#).

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace IPDM E/R. Refer to [PCS-44. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B27D1 START CUT RELAY OFF

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## Component Inspection

INFOID:000000012424003

### 1. CHECK STARTER CUT RELAY

1. Turn ignition switch OFF.
2. Disconnect starter cut relay.
3. Check continuity between starter cut relay terminals.

Starter cut relay		Condition	Continuity
Terminal			
3	5	12 V direct current supply between terminals 1 and 2	Yes
		No current supply	No

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace starter cut relay.



# B27D2 START CUT RELAY ON

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## B27D2 START CUT RELAY ON

### DTC Logic

INFOID:0000000012424004

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B27D2 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-65, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B27D2	STARTER CUT RELAY ON	When comparing the starter cut relay signal (CAN) from IPDM E/R, BCM detects that starter cut relay is stuck in the ON position for 1 second or more.	<ul style="list-style-type: none"> <li>• Harness or connectors (The CAN communication line is open or shorted.)</li> <li>• Harness or connector (Starter cut relay circuit is open or shorted.)</li> <li>• IPDM E/R</li> <li>• BCM</li> <li>• Starter cut relay</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch under the following conditions to start engine, and wait 1 second or more.
  - Selector lever: In the P position
  - Brake pedal: Depressed
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-105, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012424005

Regarding Wiring Diagram information, refer to [SEC-31, "Wiring Diagram"](#).

#### 1. CHECK STARTER CUT RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect starter cut relay.
3. Check voltage between starter cut relay harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Starter cut relay			
Connector	Terminal	Ground	Battery voltage
F55	1		
	3		

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO-1 >> Check 30 A fusible link [M, located in the fuse block (J/B)].  
 NO-2 >> Check harness for open or short between starter cut relay and fusible link.

#### 2. CHECK STARTER CUT RELAY CONTROL

1. Reconnect starter cut relay.
2. Check voltage between BCM harness connector and ground.

# B27D2 START CUT RELAY ON

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

(+)		(-)	Condition	Voltage (V) (Approx.)	
BCM					
Connector	Terminal				
E29	139	Ground	CVT shift selector lever	N or P position	Battery voltage
				Other than above	0

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

## 3. CHECK STARTER CUT RELAY CONTROL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Disconnect starter cut relay.
4. Check continuity between BCM harness connector and starter cut relay harness connector.

BCM		Starter cut relay		Continuity
Connector	Terminal	Connector	Terminal	
E29	139	F55	2	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4. CHECK STARTER CUT RELAY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and starter cut relay harness connector.

IPDM E/R		Starter cut relay		Continuity
Connector	Terminal	Connector	Terminal	
F41	86	F55	5	Yes

4. Check continuity between BCM harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
F41	86		No

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 5. CHECK STARTER CUT RELAY

Refer to [SEC-107. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace starter cut relay.

## 6. REPLACE BCM

1. Replace BCM. Refer to [BCS-76. "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT.
3. Perform DTC CONFIRMATION PROCEDURE for DTC B27D2. Refer to [SEC-105. "DTC Logic"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace IPDM E/R. Refer to [PCS-44. "Removal and Installation"](#).

# B27D2 START CUT RELAY ON

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## Component Inspection

INFOID:000000012424006

### 1. CHECK STARTER CUT RELAY

1. Turn ignition switch OFF.
2. Disconnect starter cut relay.
3. Check continuity between starter cut relay terminals.

Starter cut relay		Condition	Continuity
Terminal			
3	5	12 V direct current supply between terminals 1 and 2	Yes
		No current supply	No

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace starter cut relay.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# HEADLAMP FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## HEADLAMP FUNCTION

### Component Function Check

INFOID:000000012424007

#### 1.CHECK FUNCTION

1. Perform "HEAD LAMP(HI)" in "Active Test" of "THEFT ALM" of "BCM" using CONSULT.
2. Check headlamps operation.

Test item		Description	
HEAD LAMP (HI)	ON	Headlamps (Hi)	Light
	OFF		Does not light

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Refer to [SEC-108, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012424008

#### 1.CHECK HEADLAMP FUNCTION

Refer to [SEC-108, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace the malfunctioning parts.

#### 2.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> Inspection End.

# HORN FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## HORN FUNCTION

### Component Function Check

INFOID:000000012424009

#### 1.CHECK FUNCTION 1

1. Perform "VEHICLE SECURITY HORN" in "Active Test" of "THEFT ALM" of "BCM" using CONSULT.
2. Check the horn operation.

Test item		Description	
VEHICLE SECURITY HORN	ON	Horn	Sounds (for 0.5 sec)

Is the operation normal?

- YES >> Inspection End.  
NO >> Go to [SEC-53. "Wiring Diagram"](#).

### Component Inspection

INFOID:000000012424010

#### 1.CHECK ANTI-THEFT HORN RELAY

1. Turn ignition switch OFF.
2. Disconnect anti-theft horn relay.
3. Check voltage between anti-theft horn relay connector E101 terminal 3 and ground under the following conditions:

(+)	(-)	Condition	Voltage (V) (Approx.)
Anti-theft horn relay Terminal	Ground	12 V direct current supply between terminals 1 and 3	12
3		No current supply	0

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace anti-theft horn relay.

SEC

# SECURITY INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## SECURITY INDICATOR LAMP

### Component Function Check

INFOID:000000012424011

#### 1.CHECK FUNCTION

1. Perform "THEFT IND" in "Active Test" of "IMMU" of "BCM" using CONSULT.
2. Check security indicator lamp operation.

Test item		Description	
THEFT IND	ON	Security indicator lamp	Illuminates
	OFF		Does not illuminate

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Go to [SEC-110, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000012424012

Regarding Wiring Diagram information, refer to [SEC-53, "Wiring Diagram"](#).

#### 1.CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check voltage between combination meter harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Combination meter			
Connector	Terminal	Ground	Battery voltage
M77	45		

Is the inspection result normal?

- YES >> GO TO 2.  
NO-1 >> Check 10 A fuse [No. 13, located in the fuse block (J/B)].  
NO-2 >> Check harness for open or short between combination meter and fuse.

#### 2.CHECK SECURITY INDICATOR LAMP SIGNAL

1. Connect combination meter connector.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
BCM			
Connector	Terminal	Ground	Battery voltage
M18	35		

Is the inspection result normal?

- YES >> GO TO 3.  
NO >> GO TO 4.

#### 3.REPLACE BCM

1. Replace BCM. Refer to [BCS-76, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

# SECURITY INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## 4. CHECK SECURITY INDICATOR LAMP CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between combination meter harness connector and BCM harness connector.

Combination meter		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M76	7	M18	35	Yes

3. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M76	7		No

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-84. "Removal and Installation"](#).  
NO >> Repair or replace harness.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## SYMPTOM DIAGNOSIS

### ENGINE DOES NOT START WHEN INTELLIGENT KEY IS INSIDE OF VEHICLE

#### Description

INFOID:0000000012424013

Engine does not start when push-button ignition switch is pressed while carrying Intelligent Key.

**NOTE:**

- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis, and check each symptom.
- The engine start function, door lock function, power distribution system, and NATS-NVIS in the Intelligent Key system are closely related to each other regarding control. The vehicle security function can operate only when the door lock and power distribution system are operating normally.

#### Conditions of Vehicle (Operating Conditions)

- “ENGINE START BY I-KEY” in “Work support” is “ON” when setting on CONSULT.
- One or more of Intelligent Keys with registered Intelligent Key ID is in the vehicle.

#### Diagnosis Procedure

INFOID:0000000012424014

#### 1.PERFORM WORK SUPPORT

Perform “INSIDE ANT DIAGNOSIS” on “Work support” in “INTELLIGENT KEY”.

Refer to [BCS-22. "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

>> GO TO 2.

#### 2.PERFORM SELF-DIAGNOSTIC RESULT

Perform “Self Diagnostic Result” in “BCM”, and check whether or not DTC of inside key antenna is detected.

Is DTC detected?

YES >> Refer to [BCS-48. "DTC Index"](#).

NO >> GO TO 3.

#### 3.CHECK PUSH-BUTTON IGNITION SWITCH

Check push-button ignition switch.

Refer to [SEC-88. "Component Inspection"](#).

Is the operation normal?

YES >> GO TO 4.

NO >> Repair or replace malfunctioning parts.

#### 4.CONFIRM THE OPERATION

Confirm the operation again.

Is the inspection normal?

YES >> Check intermittent incident. Refer to [GI-45. "Intermittent Incident"](#).

NO >> GO TO 1.



# SECURITY INDICATOR LAMP DOES NOT TURN ON OR BLINK

< SYMPTOM DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## SECURITY INDICATOR LAMP DOES NOT TURN ON OR BLINK

### Description

INFOID:000000012424015

Security indicator lamp does not blink when ignition switch is in a position other than ON

#### NOTE:

- Before performing the diagnosis, check "Work Flow". Refer to [SEC-66, "Work Flow"](#).
- Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.

### Conditions of Vehicle (Operating Conditions)

Ignition switch is not in the ON position.

### Diagnosis Procedure

INFOID:000000012424016

#### 1. CHECK SECURITY INDICATOR LAMP

Check security indicator lamp.

Refer to [SEC-110, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair or replace the malfunctioning parts.

#### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# VEHICLE SECURITY SYSTEM CANNOT BE SET

< SYMPTOM DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## VEHICLE SECURITY SYSTEM CANNOT BE SET INTELLIGENT KEY

### INTELLIGENT KEY : Description

INFOID:0000000012424017

ARMED phase is not activated when door is locked using Intelligent Key.

**NOTE:**

Check that vehicle is under the condition shown in Conditions of vehicle before starting diagnosis and check each symptom.

#### CONDITION OF VEHICLE (OPERATING CONDITION)

Confirm the setting of "SECURITY ALARM SET" is "ON" in "Work support" of "THEFT ALM" of "BCM" using CONSULT.

### INTELLIGENT KEY : Diagnosis Procedure

INFOID:0000000012424018

#### 1. CHECK INTELLIGENT KEY SYSTEM (REMOTE KEYLESS ENTRY FUNCTION)

Lock/unlock door with Intelligent Key.

Refer to [SEC-10. "INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check Intelligent Key system (remote keyless entry function).

#### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45. "Intermittent Incident"](#).

NO >> GO TO 1.

## DOOR REQUEST SWITCH

### DOOR REQUEST SWITCH : Description

INFOID:0000000012424019

ARMED phase is not activated when door is locked using door request switch.

**NOTE:**

Check that vehicle is under the condition shown in Conditions of vehicle before starting diagnosis, and check each symptom.

#### CONDITION OF VEHICLE (OPERATING CONDITION)

Confirm the setting of "SECURITY ALARM SET" is "ON" in "Work support" of "THEFT ALM" of "BCM" using CONSULT.

### DOOR REQUEST SWITCH : Diagnosis Procedure

INFOID:0000000012424020

#### 1. CHECK INTELLIGENT KEY SYSTEM (DOOR LOCK FUNCTION)

Lock/unlock door with door request switch.

Refer to [SEC-10. "INTELLIGENT KEY SYSTEM/ENGINE START FUNCTION : System Description"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check Intelligent Key system (door lock function).

#### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45. "Intermittent Incident"](#).

NO >> GO TO 1.

## DOOR KEY CYLINDER

# VEHICLE SECURITY SYSTEM CANNOT BE SET

[WITH INTELLIGENT KEY SYSTEM]

< SYMPTOM DIAGNOSIS >

## DOOR KEY CYLINDER : Description

INFOID:000000012424021

ARMED phase is not activated when door is locked using mechanical key.

### NOTE:

Check that vehicle is under the condition shown in Conditions of vehicle before starting diagnosis, and check each symptom.

### CONDITION OF VEHICLE (OPERATING CONDITION)

Confirm the setting of "SECURITY ALARM SET" is "ON" in "Work support" of "THEFT ALM" of "BCM" using CONSULT.

## DOOR KEY CYLINDER : Diagnosis Procedure

INFOID:000000012424022

### 1. CHECK POWER DOOR LOCK SYSTEM

Lock/unlock door with mechanical key.

Refer to [SEC-15, "VEHICLE SECURITY SYSTEM : System Description"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Check power door lock system.

### 2. CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# VEHICLE SECURITY ALARM DOES NOT ACTIVATE

< SYMPTOM DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## VEHICLE SECURITY ALARM DOES NOT ACTIVATE

### Description

INFOID:000000012424023

Alarm does not operate when alarm operating condition is satisfied.

**NOTE:**

Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis and check each symptom.

### CONDITIONS OF VEHICLE (OPERATING CONDITIONS)

Confirm the setting of “SECURITY ALARM SET” is “ON” in “Work support” of “THEFT ALM” of “BCM” using CONSULT.

### Diagnosis Procedure

INFOID:000000012424024

#### 1.CHECK DOOR SWITCH

---

Check door switch.

Refer to [DLK-160, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 2.

NO >> Replace the malfunctioning door switch.

#### 2.CHECK HORN FUNCTION

---

Check horn function.

Refer to [SEC-109, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace the malfunctioning parts.

#### 3.CHECK HEADLAMP FUNCTION

---

Check headlamp function.

Refer to [SEC-108, "Component Function Check"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace the malfunctioning parts.

#### 4.CONFIRM THE OPERATION

---

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

# PANIC ALARM FUNCTION DOES NOT OPERATE

< SYMPTOM DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

## PANIC ALARM FUNCTION DOES NOT OPERATE

### Description

INFOID:0000000012424025

#### NOTE:

- Before performing the diagnosis following procedure, check “Work Flow”. Refer to [SEC-66, "Work Flow"](#).
- Check that vehicle is under the condition shown in “Conditions of vehicle” before starting diagnosis and check each symptom.

#### CONDITIONS OF VEHICLE (OPERATION CONDITIONS)

- Ignition switch is in OFF or LOCK position.
- Intelligent Key is removed.

### Diagnosis Procedure

INFOID:0000000012424026

#### 1.CHECK REMOTE KEYLESS ENTRY FUNCTION

Check remote keyless entry function.

Does door lock/unlock with Intelligent Key button?

YES >> GO TO 2.

NO >> Go to [DLK-187, "Diagnosis Procedure"](#).

#### 2.CHECK VEHICLE SECURITY ALARM OPERATION

Check vehicle security alarm operation.

Does alarm (headlamps and horns) active?

YES >> GO TO 3.

NO >> Go to [SEC-15, "VEHICLE SECURITY SYSTEM : System Description"](#).

#### 3.CHECK “PANIC ALARM SET” SETTING IN “WORK SUPPORT”

Check “PANIC ALARM SET” setting in “Work support”.

Refer to [BCS-22, "INTELLIGENT KEY : CONSULT Function \(BCM - INTELLIGENT KEY\)"](#).

Is the inspection result normal?

YES >> GO TO 4.

NO >> Set “PANIC ALARM SET” setting in “Work support”.

#### 4.CONFIRM THE OPERATION

Confirm the operation again.

Is the result normal?

YES >> Check intermittent incident. Refer to [GI-45, "Intermittent Incident"](#).

NO >> GO TO 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# NATS ANTENNA AMP.

< REMOVAL AND INSTALLATION >


[WITH INTELLIGENT KEY SYSTEM]

## REMOVAL AND INSTALLATION

### NATS ANTENNA AMP.

Exploded View


INFOID:000000012424027



1. Instrument finisher B

2. Push button ignition switch

3. NATS antenna amp.


 Pawl


## Removal and Installation

INFOID:000000012424028

### REMOVAL

1. Remove the instrument finisher B. Refer to [IP-16. "INSTRUMENT FINISHER B : Removal and Installation"](#).
2. Release pawls using suitable tool and remove NATS antenna amp. (1) from instrument finisher B (2).

 Pawl




# NATS ANTENNA AMP.

## < REMOVAL AND INSTALLATION >

[WITH INTELLIGENT KEY SYSTEM]

3. Release pawls using suitable tool and remove NATS antenna amp. (2) from push button ignition switch (1).

○: Pawl



## INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## PUSH-BUTTON IGNITION SWITCH

< REMOVAL AND INSTALLATION >

[WITH INTELLIGENT KEY SYSTEM]

---

### PUSH-BUTTON IGNITION SWITCH

#### Removal and Installation

INFOID:000000012424030

For the removal and installation procedures for the push-button ignition switch, refer to [PCS-92. "Exploded View"](#).



# DONGLE UNIT

< REMOVAL AND INSTALLATION >

[WITH INTELLIGENT KEY SYSTEM]


## DONGLE UNIT

### Removal and Installation

INFOID:000000012424031

#### REMOVAL

1. Remove instrument panel assembly. Refer to [IP-14. "INSTRUMENT PANEL ASSEMBLY : Removal and Installation"](#).
2. Disconnect the harness connector from the dongle unit (1).
3. Remove screw (A) and dongle unit (1) from the heating and cooling unit assembly (2).



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# PRECAUTIONS

< PRECAUTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

## PRECAUTION

### PRECAUTIONS

#### Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000012424032

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

#### **WARNING:**

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

#### PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

#### **WARNING:**

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least three minutes before performing any service.

#### Precaution for Work

INFOID:000000012424033

- When removing or disassembling each component, be careful not to damage or deform it. If a component may be subject to interference, be sure to protect it with a shop cloth.
- When removing (disengaging) components with a screwdriver or similar tool, be sure to wrap the component with a shop cloth or vinyl tape to protect it.
- Protect the removed parts with a shop cloth and prevent them from being dropped.
- Replace a deformed or damaged clip.
- If a part is specified as a non-reusable part, always replace it with a new one.
- Be sure to tighten bolts and nuts securely to the specified torque.
- After installation is complete, be sure to check that each part works properly.
- Follow the steps below to clean components:
  - Water soluble dirt:
    - Dip a soft cloth into lukewarm water, wring the water out of the cloth and wipe the dirty area.
    - Then rub with a soft, dry cloth.
  - Oily dirt:
    - Dip a soft cloth into lukewarm water with mild detergent (concentration: within 2 to 3%) and wipe the dirty area.
    - Then dip a cloth into fresh water, wring the water out of the cloth and wipe the detergent off.
    - Then rub with a soft, dry cloth.
  - Do not use organic solvent such as thinner, benzene, alcohol or gasoline.
  - For genuine leather seats, use a genuine leather seat cleaner.

# PREPARATION

[WITHOUT INTELLIGENT KEY SYSTEM]

< PREPARATION >

## PREPARATION


### PREPARATION

#### Special Service Tool

INFOID:0000000012424034

The actual shape of the tools may differ from those illustrated here.

Tool number (TechMate No.) Tool name	Description
— (J-46534) Trim Tool Set	Removing trim components



AWJIA0483ZZ

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[WITHOUT INTELLIGENT KEY SYSTEM]

## SYSTEM DESCRIPTION

### COMPONENT PARTS

#### Component Parts Location

INFOID:000000012424035



No.	Component	Function
1.	Combination meter	Combination meter transmits the vehicle speed signal to BCM via CAN communication. BCM also receives the vehicle speed signal from ABS actuator and electric unit (control unit) via CAN communication. BCM compares both signals to detect the vehicle speed. Security indicator lamp is located on combination meter. Security indicator lamp blinks when ignition switch is in any position other than ON to warn that NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)] is on board. Refer to <a href="#">MWI-6, "METER SYSTEM : Component Parts Location"</a> .
2.	Ignition switch	Ignition switch transmits ON/OFF signal to BCM. BCM changes the ignition switch position with the operation of ignition switch.
3.	NATS antenna amp.	Refer to <a href="#">SEC-125, "NATS Antenna Amp."</a>
4.	Transmission range switch	Refer to <a href="#">TM-14, "CVT CONTROL SYSTEM : Transmission Range Switch"</a> .
5.	IPDM E/R	Refer to <a href="#">PCS-6, "Component Parts Location"</a> .
6.	Stop lamp switch	Refer to <a href="#">BRC-12, "Stop Lamp Switch"</a> .
7.	BCM	BCM controls NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS [NVIS (NATS)] and VEHICLE SECURITY SYSTEM. Then, when the ignition switch is turned ON, BCM performs ID verification between BCM and ECM. If the ID verification result is OK, ECM can start engine. Refer to <a href="#">BCS-80, "BODY CONTROL SYSTEM : Component Parts Location"</a> for detailed installation location.
8.	CVT shift selector	Refer to <a href="#">TM-20, "SHIFT LOCK SYSTEM : Component Parts Location"</a> .
9.	Main power window and door lock/unlock switch	Door lock and unlock switch is integrated into the main power window and door lock/unlock switch. Door lock and unlock switch transmits door lock/unlock operation signal to BCM. Refer to <a href="#">PWC-7, "Main Power Window And Door Lock/Unlock Switch"</a> .
10.	Front door lock assembly LH	Door key cylinder switch is integrated into front door lock assembly (driver side). Door key cylinder switch detects door LOCK/UNLOCK operation using mechanical key, and then transmits the operation signal to BCM. Refer to <a href="#">DLK-296, "Front Door Lock Assembly (Driver Side)"</a> .

# COMPONENT PARTS

< SYSTEM DESCRIPTION >


[WITHOUT INTELLIGENT KEY SYSTEM]

No.	Component	Function
11.	Front door switch LH	Door switch detects door open/close condition and then transmits ON/OFF signal to BCM.
12.	Rear door switch LH	Door switch detects door open/close condition and then transmits ON/OFF signal to BCM.
13.	Front door switch RH	Door switch detects door open/close condition and then transmits ON/OFF signal to BCM.
14.	Back door lock assembly	Back door lock actuator locks/unlocks the back door latch assembly.

## NATS Antenna Amp.

INFOID:000000012424036

The ID verification is performed between BCM and transponder integrated into key via NATS antenna amp. when key backside is contacted to ignition switch in case that key battery is discharged. If the ID verification result is OK, the operation of ignition switch is available.



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# SYSTEM

< SYSTEM DESCRIPTION >


[WITHOUT INTELLIGENT KEY SYSTEM]

## SYSTEM

### NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS

#### NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Diagram

INFOID:000000012424037



#### NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description

INFOID:000000012424038

#### INPUT/OUTPUT SIGNAL CHART

##### BCM

Switch/Input signal	Input signal to BCM	BCM function	Actuator/Output signal
NATS antenna amp.	Key ID	NATS	<ul style="list-style-type: none"> <li>Security indicator lamp</li> <li>Starter request</li> </ul>
ECM	Engine status signal		

#### SYSTEM DESCRIPTION

NATS (Nissan Anti-Theft System) has the following immobilizer functions:

- Engine immobilizer shows high anti-theft performance to prevent engine from starting by anyone other than the owner.
- Only a key with key ID registered in BCM and ECM can start engine, and shows high anti-theft performance to prevent key from being copied or stolen.
- Security indicator always flashes with mechanical key removed condition (key switch: OFF) and ignition knob released condition on LOCK position (ignition knob switch: OFF).
- Therefore, NATS warns outsiders that the vehicle is equipped with the anti-theft system.
- If system detects malfunction, security indicator illuminates when ignition switch is turned to ON position.
- If the owner requires, ignition key ID or mechanical key ID can be registered for up to 4 keys.
- During trouble diagnosis or when the following parts have been replaced, and if ignition key is added, registration<sup>\*1</sup> is required:

<sup>\*1</sup>: All keys kept by the owner of the vehicle should be registered with mechanical key.

- ECM
- BCM
- Ignition key
- Remote keyless entry receiver
- NATS trouble diagnosis, system initialization and additional registration of other mechanical key IDs must be carried out using CONSULT.  
When NATS initialization has been completed, the ID of the inserted mechanical key or mechanical key IDs can be carried out.
- Possible symptom of NATS malfunction is "Engine cannot start". Identify the possible causes according to "Work Flow", Refer to [SEC-162. "Work Flow"](#).
- If ECM other than Genuine NISSAN is installed, the engine cannot be started. For ECM replacement procedure, refer to [SEC-165. "ECM RE-COMMUNICATING FUNCTION : Description"](#).

# SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

## PRECAUTIONS FOR KEY REGISTRATION

- The key registration is a procedure that erases the current NATS ID once, and then re-registers a new ID. Therefore the registered key is necessary for this procedure. Before starting the registration procedure, collect all registered Keys from the customer.
- The NATS ID registration is the procedure that registers the ID stored into the transponder (integrated in mechanical key) to BCM.
- The key ID registration is the procedure that registers the ID to the BCM.
- When performing the key system registration only, the engine cannot be started by inserting the key into the key cylinder. When performing the NATS registration only, the engine cannot be started by using the ignition key.

## SECURITY INDICATOR

- Always flashes with ignition key in the OFF position.

## MAINTENANCE INFORMATION

### CAUTION:


It is necessary to perform NATS ID registration when replacing any of the following parts:  
If ID registration is not performed, the electrical system may not operate properly.

- BCM
- ECM
- IPDM E/R
- Ignition key
- NATS antenna amp.
- Combination meter

## VEHICLE SECURITY SYSTEM

### VEHICLE SECURITY SYSTEM : System Diagram

INFOID:000000012424039



### VEHICLE SECURITY SYSTEM : System Description

INFOID:000000012424040

- The vehicle security system has two alarm functions (theft warning alarm and panic alarm), and reduces the possibility of a theft or mischief by activating horns (and hazard warning lamps) intermittently.
- The panic alarm does not start when the theft warning alarm is activating, and the panic alarm stops when the theft warning alarm is activated.

# SYSTEM

## < SYSTEM DESCRIPTION >

**[WITHOUT INTELLIGENT KEY SYSTEM]**


The priority of the functions are as per the following.

Priority	Function
1	Theft warning alarm
2	Panic alarm

### THEFT WARNING ALARM

- The theft warning alarm function activates horns and hazard warning lamps intermittently when BCM detects that any door is opened by unauthorized means, while the system is in the ARMED state.
- Security indicator lamp on combination meter always blinks when ignition switch is in any position other than ON. Security indicator lamp blinking warns that the vehicle is equipped with a vehicle security system.

### Operation Flow



No.	System state	Switching condition		
1	DISARMED to PRE-ARMED	When all conditions of A and one condition of B are satisfied.	A	B
			<ul style="list-style-type: none"> <li>• Ignition switch: OFF</li> <li>• All doors: Closed</li> </ul>	<ul style="list-style-type: none"> <li>All doors are locked by:</li> <li>• Door lock and unlock switch</li> <li>• LOCK button of Keyfob</li> </ul>
2	PRE-ARMED to ARMED	When all of the following conditions are satisfied for 30 seconds.	<ul style="list-style-type: none"> <li>• Ignition switch: OFF</li> <li>• All doors: Locked</li> </ul>	
3	ARMED to ALARM	When condition of A and one condition of B are satisfied.	A	B
			Keyfob: Not used	<ul style="list-style-type: none"> <li>• Any door: Open</li> </ul>
4	DISARMED to PRE-RESET	When all conditions of A and one condition of B are satisfied.	A	B
			<ul style="list-style-type: none"> <li>• Ignition switch: OFF</li> <li>• All doors: Closed</li> </ul>	<ul style="list-style-type: none"> <li>All doors are locked by:</li> <li>• Door lock and unlock switch</li> <li>• LOCK button of Keyfob</li> </ul>
5	PRE-ARMED to PRE-RESET	No conditions.		
6	ARMED to PRE-RESET	No conditions.		
7	ALARM to PRE-RESET	No conditions.		
8	PRE-RESET to DISARMED	When one of the following conditions is satisfied.	<ul style="list-style-type: none"> <li>• Ignition switch: ACC/ON</li> <li>• UNLOCK button of Keyfob: ON</li> <li>• UNLOCK switch of door lock and unlock switch: ON</li> <li>• Any door: Open</li> </ul>	
9	PRE-RESET to PRE-ARMED	When all of the following conditions are satisfied.	<ul style="list-style-type: none"> <li>• Ignition switch: OFF</li> <li>• All doors: Locked</li> </ul>	



# SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

No.	System state	Switching condition	
10	PRE-ARMED to DISARMED	When one of the following conditions is satisfied.	<ul style="list-style-type: none"><li>Ignition switch: ACC/ON</li><li>UNLOCK button of Keyfob: ON</li><li>UNLOCK switch of door lock and unlock switch: ON</li><li>Any door: Open</li></ul>
11	ARMED to DISARMED	When the following condition is satisfied.	<ul style="list-style-type: none"><li>UNLOCK button of Keyfob: ON</li></ul>
12	ALARM to DISARMED		
13	RE-ALARM	When one of the following condition is satisfied after the ALARM operation is finished.	<ul style="list-style-type: none"><li>Any door: Open</li></ul>

**NOTE:**

- To lock/unlock all doors by operating remote controller button of keyfob, the keyfob must be within the detection area of BCM. For details, refer to [DLK-299, "REMOTE KEYLESS ENTRY SYSTEM : System Description"](#).

### DISARMED Phase

The vehicle security system is not set in the DISARMED phase. The vehicle security system stays in this phase while any door is open, because it is assumed that the owner is inside or nearby the vehicle. Security indicator lamp blinks every 2.4 seconds.

When the vehicle security system is reset, each phase switches to the DISARMED phase directly.

### PRE-ARMED Phase

The PRE-ARMED phase is the transient state between the DISARMED phase and the ARMED phase. This phase is maintained for 30 seconds, so that the owner can reset the setting due to a mis-operation. This phase switches to the ARMED phase when vehicle conditions are not changed for 30 seconds. Security indicator lamp illuminates while being in this phase.

To reset the PRE-ARMED phase, refer to the switching condition of No. 10 in the table above.

### ARMED Phase

The vehicle security system is set, and BCM monitors all necessary inputs. If any door or hood is opened without using Keyfob, vehicle security system switches to the ALARM phase. Security indicator lamp blinks every 2.4 seconds.

To reset the ARMED phase, refer to the switching condition of No. 11 in the table above.

### ALARM Phase

BCM transmits "Theft Warning Horn Request" signal intermittently to IPDM E/R via CAN communication, and blinks hazard warning lamps. In this phase, horns and hazard warning lamps are activated intermittently for approximately 27.5 seconds to warn that the vehicle is accessed by unauthorized means. After 27.5 seconds, the vehicle security system returns to the ARMED phase. At this time, if BCM still detects unauthorized access to the vehicle, the system is switched to the ALARM phase again. This RE-ALARM operation is carried out a maximum of 3 times.

To cancel the ALARM operation, refer to the switching condition of No. 12 in the table above.

**NOTE:**

If a battery terminal is disconnected during the ALARM phase, theft warning alarm stops. But when the battery terminal is reconnected, theft warning alarm is activated again.

### PANIC ALARM

The panic alarm function activates horns intermittently when the owner presses PANIC ALARM button of Keyfob outside the vehicle while ignition switch is OFF.

For details, refer to [SEC-127, "VEHICLE SECURITY SYSTEM : System Description"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (BCM)

### COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000012567359

### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

Direct Diagnostic Mode	Description
Ecu Identification	The BCM part number is displayed.
Self Diagnostic Result	The BCM self diagnostic results are displayed.
Data Monitor	The BCM input/output data is displayed in real time.
Active Test	The BCM activates outputs to test components.
Work support	The settings for BCM functions can be changed.
Configuration	<ul style="list-style-type: none"> <li>The vehicle specification can be read and saved.</li> <li>The vehicle specification can be written when replacing BCM.</li> </ul>
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

### SYSTEM APPLICATION

BCM can perform the following functions.

System	Sub System	Direct Diagnostic Mode						
		Ecu Identification	Self Diagnostic Result	Data Monitor	Active Test	Work support	Configuration	CAN Diag Support Mntr
Door lock	DOOR LOCK			x	x	x		
Rear window defogger	REAR DEFOGGER			x	x	x		
Warning chime	BUZZER			x	x			
Interior room lamp timer	INT LAMP			x	x	x		
Remote keyless entry system	MULTI REMOTE ENT					x		
Exterior lamp	HEADLAMP			x	x			
Wiper and washer	WIPER			x	x	x		
Turn signal and hazard warning lamps	FLASHER			x	x			
Combination switch	COMB SW			x				
BCM	BCM	x	x			x	x	x
Immobilizer	IMMU		x		x			
Interior room lamp battery saver	BATTERY SAVER			x	x			
Back door open	TRUNK			x				
Vehicle security system	THEFT ALM			x	x	x		
RAP system	RETAINED PWR			x				
TPMS	AIR PRESSURE MONITOR		x	x	x	x		

### IMMU

IMMU : CONSULT Function (BCM - IMMU)

INFOID:000000012567360

### SELF DIAGNOSTIC RESULT

# DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

Refer to [BCS-109, "DTC Index"](#).

## ACTIVE TEST

Test Item	Description
THEFT IND	This test is able to check security indicator operation [On/Off].

## WORK SUPPORT

Support Item	Setting	Description
CONFIRM DONGLE ID	—	Dongle ID can be checked.

## THEFT ALM

THEFT ALM : CONSULT Function (BCM - THEFT ALM)

INFOID:000000012567361

## DATA MONITOR

Monitored Item	Description
DOOR SW-DR [On/Off]	Indicates condition of front door switch LH.
DOOR SW-AS [On/Off]	Indicates condition of front door switch RH.
DOOR SW-RR [On/Off]	Indicates condition of rear door switch RH.
DOOR SW-RL [On/Off]	Indicates condition of rear door switch LH.
DOOR SW-BK [On/Off]	Indicates condition of back door switch.
CDL LOCK SW [On/Off]	Indicates condition of lock signal from door lock and unlock switch.
CDL UNLOCK SW [On/Off]	Indicates condition of unlock signal from door lock and unlock switch.
KEY CYL LK-SW [On/Off]	Indicates condition of lock signal from door key cylinder switch.
KEY CYL UN-SW [On/Off]	Indicates condition of unlock signal from door key cylinder switch.
RKE-LOCK [On/Off]	Indicates condition of lock signal from Intelligent Key.
RKE-UNLOCK [On/Off]	Indicates condition of unlock signal from Intelligent Key.

## ACTIVE TEST

Test Item	Description
FLASHER	This test is able to check turn signal lamp operation [LH/RH/Off].
THEFT IND	This test is able to check security indicator lamp operation [On/Off].
VEHICLE SECURITY HORN	This test is able to check vehicle security horn operation [On].
HEADLAMP(HI)	This test is able to check vehicle security lamp operation [On].

## WORK SUPPORT

Support Item	Setting	Description
SECURITY ALARM SET	On*	Security alarm ON.
	Off	Security alarm OFF.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# DIAGNOSIS SYSTEM (IPDM E/R)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

## DIAGNOSIS SYSTEM (IPDM E/R)

### CONSULT Function (IPDM E/R)

INFOID:000000012567362

#### APPLICATION ITEM

CONSULT performs the following functions via CAN communication with IPDM E/R.

Direct Diagnostic Mode	Description
ECU Identification	The IPDM E/R part number is displayed.
Self Diagnostic Result	The IPDM E/R self diagnostic results are displayed.
Data Monitor	The IPDM E/R input/output data is displayed in real time.
Active Test	The IPDM E/R activates outputs to test components.
CAN Diag Support Mntr	The result of transmit/receive diagnosis of CAN communication is displayed.

#### ECU IDENTIFICATION

The IPDM E/R part number is displayed.

#### SELF DIAGNOSTIC RESULT

Refer to [PCS-26. "DTC Index"](#).

#### DATA MONITOR

Monitor Item [Unit]	Description
REVERSE SIGNAL [Open/Close]	Indicates condition of transmission range switch R (Reverse) position.
IGN RELAY [Open/Close]	Indicates condition of ignition relay-1.
PUSH SW [Open/Close]	Indicates condition of push-button ignition switch.
INTERLOCK/PNP SW [Open/Close]	Indicates condition of transmission range switch P (Park) and N (Neutral) positions.
OIL PRESSURE SW [Open/Close]	Indicates condition of oil pressure switch.
HOOD SW [Open/Close]	Indicates condition of hood switch.
COMPRESSOR [OFF/ON]	Indicates condition of A/C compressor.
HORN RELAY [OFF/ ON]	Indicates condition of horn relay.
COOLING FAN [OFF/ON]	Indicates condition of cooling fan relay-1.
FRONT WIPER HI/LO RELAY [OFF/ON]	Indicates condition of front wiper high relay.
FRONT WIPER RELAY [OFF/ON]	Indicates condition of front wiper relay.
IGN RELAY OFF STATUS [OFF/ON]	Indicates condition of ignition relay-1 OFF status.
IGN RELAY ON STATUS [OFF/ON]	Indicates condition of ignition relay-1 ON status.
COOLING FAN RELAY 1 [OFF/ON]	Indicates condition of cooling fan relay-1.
STARTER RELAY [OFF/ON]	Indicates condition of starter relay.
COMP ECV DUTY [%]	Indicates condition of A/C compressor.
COOLING FAN RELAY 2 [%]	Indicates condition of cooling fan relay-2.
FR FOG LAMP LH [%]	Indicates condition of front fog lamp LH.
FR FOG LAMP RH [%]	Indicates condition of front fog lamp RH.
PARKING LAMP [%]	Indicates condition of parking lamp.
TAIL LAMP LH [%]	Indicates condition of tail lamp LH.
TAIL LAMP RH [%]	Indicates condition of tail lamp RH.
DAYTIME RUNNING LIGHT LH [%]	Indicates condition of daytime running light LH.
DAYTIME RUNNING LIGHT RH [%]	Indicates condition of daytime running light RH.
HEADLAMP (HI) LH [%]	Indicates condition of headlamp high beam LH.

# DIAGNOSIS SYSTEM (IPDM E/R)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
HEADLAMP (HI) RH [%]	Indicates condition of headlamp high beam RH.
HEADLAMP (LO) LH [%]	Indicates condition of headlamp low beam LH.
HEADLAMP (LO) RH [%]	Indicates condition of headlamp low beam RH.
A/C RELAY STUCK [NG/OK]	Indicates condition of A/C relay.
A/C RELAY [Off/On]	Indicates condition of A/C relay.
COMP ECV STATUS [NG/OK]	Indicates condition of A/C compressor.
VEHICLE SECURITY HORN [Off/On]	Indicates condition of horn relay.
BATTERY CURRENT SENSOR [NG/OK]	Indicates condition of battery current sensor.
FRONT FOG LAMP [Off/On]	Indicates condition of front fog lamps.
COMP ECV CURRENT [A]	Indicates condition of A/C compressor current.
BATTERY VOLTAGE [V]	Indicates condition of battery voltage.
COOLING FAN DUTY [%]	Indicates condition of cooling fans.
HOOD SW (CAN) [OPEN/CLOSE]	Indicates condition of hood switch.
FRONT WIPER [STOP/LOW/HIGH]	Indicates condition of front wiper motor.
FR WIPER STOP POSITION [STOP P/ACTIVE P]	Indicates condition of front wiper motor stop.
HEADLAMP (HI) [Off/On]	Indicates condition of headlamp high beams.
HEADLAMP (LO) [Off/On]	Indicates condition of headlamp low beams.
IGNITION RELAY STATUS [Off/On]	Indicates condition of ignition relay-1.
IGN RELAY MONITOR [Off/On]	Indicates condition of ignition relay-1 feedback.
IGNITION POWER SUPPLY [Off/On]	Indicates condition of ignition relay-1.
INTERLOCK/PNP SW (CAN) [Off/On]	Indicates condition of transmission range switch P (Park) and N (Neutral) positions.
PUSH-BUTTON IGN SW (CAN) [Off/On]	Indicates condition of push-button ignition switch.
TAIL LAMP [Off/On]	Indicates condition of tail lamps.
REVERSE SIGNAL (CAN) [Off/On]	Indicates condition of transmission range switch R (Reverse) position.
ST&ST CONT RELAY STATUS [Off/ST R On]	Indicates condition of starter cut and starter relays.
STARTER MOTOR STATUS [Off/On]	Indicates condition of starter motor.
STARTER RELAY (CAN) [LOW/HIGH]	Indicates condition of starter relay.
IPDM NOT SLEEP [NO RDY/RDY]	Indicates condition of IPDM E/R sleep status.
AFTER COOLING TIME [No request/Request]	Indicates condition of cooling fan request.
AFTER COOLING SPEED [%]	Indicates condition of cooling fans.
COOLING FAN TYPE [NISSAN/RENAULT]	Indicates cooling fan type.
COMPRESSOR REQ1 [Off/On]	Indicates condition of A/C compressor request.
VHCL SECURITY HORN REQ [Off/On]	Indicates condition of horn relay request.
DTRL REQ [Off/On]	Indicates condition of daytime running light request.
SLEEP/WAKE UP [WAKEUP/SLEEP]	Indicates condition of IPDM E/R sleep/wake.
CRANKING ENABLE-TCM [NG/OK]	Indicates condition of crank enable from TCM.
CRANKING ENABLE-ECM [NG/OK]	Indicates condition of crank enable from ECM.
CAN DIAGNOSIS [NG/OK]	Indicates condition of CAN diagnosis.
FRONT FOG LAMP REQ [Off/On]	Indicates condition of front fog lamp request.
HIGH BEAM REQ [Off/On]	Indicates condition of headlamp high beam request.
HORN CHIRP [Off/On]	Indicates condition of horn relay request.
COOLING FAN REQ [%]	Indicates condition of cooling fan request.
ENGINE STATUS [STOP/RUN/IDLING]	Indicates condition of engine status.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
SEC  
L  
M  
N  
O  
P

# DIAGNOSIS SYSTEM (IPDM E/R)

[WITHOUT INTELLIGENT KEY SYSTEM]

## < SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
TURN SIGNAL REQ [Off/LH/RH]	Indicates condition of turn signal request.
FR WIPER REQ [RETURN/LOW/HIGH]	Indicates condition of front wiper motor request.
SHIFT POSITION [P/R/N/D/L]	Indicates condition of transmission range switch positions.
LOW BEAM REQ [Off/On]	Indicates condition of headlamp low beam request.
POSITION LIGHT REQ [Off/On]	Indicates condition of parking lamp request.
COMPRESSOR REQ2 [Off/On]	Indicates condition of A/C compressor request.
IGNITION SW [Off/On]	Indicates condition of ignition switch.
VEHICLE SPEED (METER) [mph/km/h]	Indicates vehicle speed.
STARTER OPERATION COUNT	Displays the number of times the starter motor is turned ON.
H/P F/PUMP OPERATN COUNT	Displays the number of times the high pressure fuel pump is turned ON.
BAT DISCHARGE COUNT [—]	Monitor the cumulative discharge value of the battery. <b>NOTE:</b> When 65,000 or more is counted, replace the battery.
P LAMP CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the parking lamp circuit. <b>NOTE:</b> When the number of parking lamp circuit retries count is 20, this item counts 1.
NMB P LAMP CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the parking lamp circuit. <b>NOTE:</b> When the number of short circuits in the parking lamp circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB P LAMP CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the parking lamp circuit.
DTRL LH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the daytime running light (left) circuit. <b>NOTE:</b> When the number of daytime running light (left) circuit retries count is 20, this item counts 1.
NMB DTRL LH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the daytime running light (left) circuit. <b>NOTE:</b> When the number of short circuits in the daytime running light (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB DTRL LH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the daytime running light (left) circuit.
DTRL RH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the daytime running light (right) circuit. <b>NOTE:</b> When the number of daytime running light (right) circuit retries count is 20, this item counts 1.
NMB DTRL RH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the daytime running light (right) circuit. <b>NOTE:</b> When the number of short circuits in the daytime running light (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB DTRL RH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the daytime running light (right) circuit.

# DIAGNOSIS SYSTEM (IPDM E/R)

< SYSTEM DESCRIPTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

Monitor Item [Unit]	Description
F FOG LH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the front fog lamp (left) circuit. <b>NOTE:</b> When the number of front fog lamp (left) circuit retries count is 20, this item counts 1.
NMB F FOG LH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the front fog lamp (left) circuit. <b>NOTE:</b> When the number of short circuits in the front fog lamp (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB F FOG LH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the front fog lamp (left) circuit.
F FOG RH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the front fog lamp (right) circuit. <b>NOTE:</b> When the number of front fog lamp (right) circuit retries count is 20, this item counts 1.
NMB F FOG RH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the front fog lamp (right) circuit. <b>NOTE:</b> When the number of short circuits in the front fog lamp (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB F FOG RH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the front fog lamp (right) circuit.
HL (HI) LH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the headlamp (HI) (left) circuit. <b>NOTE:</b> When the number of headlamp (HI) (left) circuit retries count is 20, this item counts 1.
NMB HL (HI) LH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the headlamp (HI) (left) circuit. <b>NOTE:</b> When the number of short circuits in the headlamp (HI) (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB HL (HI) LH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the headlamp (HI) (left) circuit.
HL (HI) RH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the headlamp (HI) (right) circuit. <b>NOTE:</b> When the number of headlamp (HI) (right) circuit retries count is 20, this item counts 1.
NMB HL (HI) RH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the headlamp (HI) (right) circuit. <b>NOTE:</b> When the number of short circuits in the headlamp (HI) (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB HL (HI) RH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the headlamp (HI) (right) circuit.
HL (LO) LH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the headlamp (LO) (left) circuit. <b>NOTE:</b> When the number of headlamp (LO) (left) circuit retries count is 20, this item counts 1.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# DIAGNOSIS SYSTEM (IPDM E/R)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

Monitor Item [Unit]	Description
NMB HL (LO) LH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the headlamp (LO) (left) circuit. <b>NOTE:</b> When the number of short circuits in the headlamp (LO) (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB HL (LO) LH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the headlamp (LO) (left) circuit.
HL (LO) RH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the headlamp (LO) (right) circuit. <b>NOTE:</b> When the number of headlamp (LO) (right) circuit retries count is 20, this item counts 1.
NMB HL (LO) RH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the headlamp (LO) (right) circuit. <b>NOTE:</b> When the number of short circuits in the headlamp (LO) (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB HL (LO) RH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the headlamp (LO) (right) circuit.
T LAMP LH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the tail lamp (left) circuit. <b>NOTE:</b> When the number of tail lamp (left) circuit retries count is 20, this item counts 1.
NMB T LAMP LH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the tail lamp (left) circuit. <b>NOTE:</b> When the number of short circuits in the tail lamp (left) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB T LAMP LH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the tail lamp (left) circuit.
T LAMP RH CIRC MALFUNCTN [0 – 1]	Monitor the number of times that the smart FET in IPDM E/R reaches the retry upper limit of the tail lamp (right) circuit. <b>NOTE:</b> When the number of tail lamp (right) circuit retries count is 20, this item counts 1.
NMB T LAMP RH CIRC RETRY [0 – 20]	Monitor the number of times that the smart FET in IPDM E/R permits the retry of the tail lamp (right) circuit. <b>NOTE:</b> When the number of short circuits in the tail lamp (right) circuit count is 5 and the ignition switch OFF to ON operation is detected, this item counts 1.
NMB T LAMP RH CIRC SHORT [0 – 5]	Monitor the number of times that the smart FET in IPDM E/R detects the over current of the tail lamp (right) circuit.
BATTERY STATUS [OK/NG]	Monitor the battery status from the battery output.
BAT DISCHARGE COUNT [0-100]	Indicates condition of battery discharge.
BATTERY STATUS [NG/OK]	Indicates battery status.

## ACTIVE TEST

Test item	Description
HORN	This test is able to check horn operation [Off/On].
FRONT WIPER	This test is able to check wiper motor operation [Off/Low/High].



# DIAGNOSIS SYSTEM (IPDM E/R)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

Test item	Description
COMPRESSOR	This test is able to check A/C compressor operation [Off/On].
COOLING FAN (DUAL)	This test is able to check cooling fan operation [Off/LO/HI].
HEADLAMP (HI)	This test is able to check headlamp high beam operation [Off/3/5].
HEADLAMP (LO)	This test is able to check headlamp low beam operation [Off/3/5].
FRONT FOG LAMP	This test is able to check front fog lamp operation [Off/3/5].
DAYTIME RUNNING LAMP	This test is able to check daytime running lamp operation [Off/3/5].
PARKING LAMP	This test is able to check parking lamp operation [Off/3/5].
TAIL LAMP	This test is able to check tail lamp operation [Off/3/5].

## CAN DIAG SUPPORT MNTR

Refer to [LAN-17, "CAN Diagnostic Support Monitor"](#).

## WORK SUPPORT

Work item	Description
CML B/DCHRG CRNT CLEAR	In this mode, cumulative battery discharge current is cleared.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# ECU DIAGNOSIS INFORMATION

ECM, IPDM E/R, BCM

List of ECU Reference

INFOID:000000012424045

ECU	Reference
ECM	<a href="#">EC-80, "Reference Value"</a>
	<a href="#">EC-92, "Fail Safe"</a>
	<a href="#">EC-95, "DTC Inspection Priority Chart"</a>
	<a href="#">EC-96, "DTC Index"</a>
IPDM E/R	<a href="#">PCS-17, "Reference Value"</a>
	<a href="#">PCS-25, "Fail-safe"</a>
	<a href="#">PCS-26, "DTC Index"</a>
BCM	<a href="#">BCS-97, "Reference Value"</a>
	<a href="#">BCS-108, "Fail Safe"</a>
	<a href="#">BCS-109, "DTC Inspection Priority Chart"</a>
	<a href="#">BCS-109, "DTC Index"</a>

< WIRING DIAGRAM >

# WIRING DIAGRAM


## NVIS

### Wiring Diagram

INFOID:000000012424046

(N): FOR CANADA  
(OK): WITHOUT INTELLIGENT KEY SYSTEM


### NVIS - WITHOUT INTELLIGENT KEY SYSTEM




A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

AAKWA1324GB



AAKWA0989GB




AAKWA0990GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC


NVIS CONNECTORS - WITHOUT INTELLIGENT KEY SYSTEM

Connector No.	M4
Connector Name	NATS ANTENNA AMP. (WITHOUT INTELLIGENT KEY SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	P	-
2	GR	-
3	BR	-
4	LG	-

Connector No.	M5
Connector Name	DONGLE UNIT
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	P	-
4	B	-

Connector No.	M14
Connector Name	JOINT CONNECTOR-M30
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	Y	-
2	Y	-
4	Y	-

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-


Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
81	L	I KEY SW (WITHOUT INTELLIGENT KEY SYSTEM)
82	LA/R	I STARTER SW (WITHOUT INTELLIGENT KEY SYSTEM)
95	V	I SHORTING PIN
105	Y	I IGN SW (WITHOUT INTELLIGENT KEY SYSTEM)
109	P	O CLK IMMOBILIZER
113	LG	O DATA IMMOBILIZER

Terminal No.	Color of Wire	Signal Name
37J	Y	-
60J	P	-
61J	L	-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
170	B	I GND1
171	B	I GND2

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Connector No.	M32
Connector Name	IGNITION SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
13P	LA/G	-

Terminal No.	Color of Wire	Signal Name
1	L	-
2	L	-
11	P	-
12	P	-

Terminal No.	Color of Wire	Signal Name
1	Y	-
3	B	-
4	LA/R	-

AAKIA2342GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

Connector No.	M65
Connector Name	JOINT CONNECTOR-M26
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
5	B	-

Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
3R	V	-
12R	BR	-
14R	W	-

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
7	BG	SECURITY

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
45	LA/G	BAT


Connector No.	M105
Connector Name	KEY SWITCH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	B	-



Connector No.	E16
Connector Name	ECM
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
99	P	CAN-L
100	L	CAN-H

Connector No.	E2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-

Connector No.	M170
Connector Name	JOINT CONNECTOR-M29
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	-
5	B	-

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	L	-
2	P	-
5	L	-
6	P	-
9	L	-
10	P	-

Connector No.	E29
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
139	G	O STCUT RL

Connector No.	E19
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
7	G	-

AAKIA3202GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


SEC

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED




Terminal No.	Color of Wire	Signal Name
47	B	POWER GROUND

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
22	P	CAN-L
24	L	CAN-H
31	B	2ND SIGNAL GROUND
32	GR	LI PUSH SW

Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
12	B	SIGNAL GROUND


Connector No.	F32
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-

Terminal No.	Color of Wire	Signal Name
37J	GR	-
60J	P	-
61J	L	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE




AAKIA2345GB

Connector No.	F41
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
83	G	O STARTER
86	GR	FL STARTER

Connector No.	F35
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
70	BG	O IGN AT LPG

Connector No.	F33
Connector Name	WIRE TO WIRE
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
7	G	-

Connector No.	F78
Connector Name	TRANSMISSION RANGE SWITCH
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
7	BG	-
10	GR	-

Connector No.	F55
Connector Name	STARTER CUT RELAY
Connector Color	BLUE



Terminal No.	Color of Wire	Signal Name
1	SB	-
2	G	-
3	L	-
5	GR	-

Connector No.	F42
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
92	GR	LI NP SW


AAKIA2346GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

< WIRING DIAGRAM >

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



Terminal No.	Color of Wire	Signal Name
60	L	CAN-H
80	P	CAN-L

AAKIA2347GB

# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >


## VEHICLE SECURITY SYSTEM

### Wiring Diagram

INFOID:000000012424047

\*1 <P2> : 7  
 \*2 <P2> : 8  
 \*3 <P3> : 3  
 \*4 <P3> : 4  
 <P2> : WITH POWER BACK DOOR  
 <P3> : WITHOUT POWER BACK DOOR

### VEHICLE SECURITY SYSTEM



AAKWA1335GB


A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >




AAKWA0985GB

# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >



A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


SEC

AAKWA0986GB

# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >



AAKWA0987GB




# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >


## VEHICLE SECURITY SYSTEM CONNECTORS

Connector No.	M6
Connector Name	JOINT CONNECTOR-M01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	M18
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
10	BG	I DOORLOCK SW
35	BG	O SECURITY LED
40	SB	I DOORUNLOCK SW

Connector No.	M19
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
82	W	I SES FR HANDLE BUTTON SW (WITH INTELLIGENT KEY SYSTEM)
92	BR	I-KEY CYLINDER LOCK SW
93	P	I-KEY CYLINDER UNLOCK SW
95	V	I SHORTING PIN
100	V	SES EXT DR ANTENNA A

Connector No.	M20
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
161	W	I PWR ECU
167	LAV	I PWR DOORLOCK1
170	B	I GND1
171	B	I GND2
175	R	I PWR DOORLOCK2

Terminal No.	Color of Wire	Signal Name
105	Y	I SES FL HANDLE BUTTON (WITH INTELLIGENT KEY SYSTEM)
116	BG	SES INT FRONT ANTENNA B (WITH INTELLIGENT KEY SYSTEM)
117	GR	SES INT FRONT ANTENNA A (WITH INTELLIGENT KEY SYSTEM)
118	SB	SES EXT RIGHT ANTENNA B (WITH INTELLIGENT KEY SYSTEM)
119	P	SES EXT RIGHT ANTENNA A (WITH INTELLIGENT KEY SYSTEM)
120	BR	SES EXT LEFT ANTENNA B (WITH INTELLIGENT KEY SYSTEM)

AAKIA3203GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P


SEC

# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >


Connector No.	M33
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	5N	Color of Wire	R	Signal Name	-
--------------	----	---------------	---	-------------	---

Terminal No.	60J	Color of Wire	P	Signal Name	-
	61J		L		-

Connector No.	M31
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Connector No.	M68
Connector Name	FUSE BLOCK (J/B)
Connector Color	BROWN




Terminal No.	3R	Color of Wire	V	Signal Name	-
	7R		LAV		-
	14R		W		-

Connector No.	M44
Connector Name	FUSE BLOCK (J/B)
Connector Color	WHITE



Terminal No.	13P	Color of Wire	LA/G	Signal Name	-
--------------	-----	---------------	------	-------------	---

Connector No.	M43
Connector Name	JOINT CONNECTOR-M02
Connector Color	BLUE



Terminal No.	1	Color of Wire	L	Signal Name	-
	2		L		-
	11		P		-
	12		P		-


AAKIA2337GB

# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	M77
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
45	LA/G	BAT

Connector No.	M76
Connector Name	COMBINATION METER
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
7	BG	SECURITY

Connector No.	M69
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	M168
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
20	BR	-
21	P	-
23	BG	-
24	SB	-

Connector No.	M167
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
16	B	-

Connector No.	M91
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	GR	-
19	LG	-
20	BR	-

AAKIA1807GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

Connector No.	E47
Connector Name	HORN
Connector Color	BROWN




Terminal No.	Color of Wire	Signal Name
1	R	-

Connector No.	E46
Connector Name	HORN
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	B	-

Connector No.	E44
Connector Name	JOINT CONNECTOR-E01
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
5	L	-
6	P	-
9	L	-
10	P	-

Connector No.	E101
Connector Name	ANTI-THEFT HORN RELAY
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	L	-
2	R	-
3	GR	-

Connector No.	E49
Connector Name	HORN (LOW)
Connector Color	BROWN



Terminal No.	Color of Wire	Signal Name
1	R	-

Connector No.	E48
Connector Name	HORN (LOW)
Connector Color	BLACK



Terminal No.	Color of Wire	Signal Name
2	B	-

AAKIA2448GB

# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	E121
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	RED




Terminal No.	47	Color of Wire	B	Signal Name	POWER GROUND
--------------	----	---------------	---	-------------	--------------

Connector No.	E120
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	22	Color of Wire	P	Signal Name	CAN-L
Terminal No.	24	Color of Wire	L	Signal Name	CAN-H
Terminal No.	31	Color of Wire	B	Signal Name	2ND SIGNAL GROUND


Connector No.	E119
Connector Name	IPDM E/R (INTELLIGENT POWER DISTRIBUTION MODULE ENGINE ROOM)
Connector Color	GRAY



Terminal No.	9	Color of Wire	L	Signal Name	LO HRN RLY
Terminal No.	12	Color of Wire	B	Signal Name	SIGNAL GROUND

Terminal No.	60J	Color of Wire	P	Signal Name	-
Terminal No.	61J	Color of Wire	L	Signal Name	-

Connector No.	E152
Connector Name	WIRE TO WIRE
Connector Color	WHITE



AAKIA2338GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
K  
L  
M  
N  
O  
P

SEC

# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]

< WIRING DIAGRAM >

Connector No.	B16
Connector Name	BCM (BODY CONTROL MODULE)
Connector Color	GREEN



60	59	58	57	56	55	54	53	52	51	50	49	48	47	46	45	44	43	42	41
80	79	78	77	76	75	74	73	72	71	70	69	68	67	66	65	64	63	62	61

Terminal No.	Color of Wire	Signal Name
50	W	I RR DOOR SW
51	LG	I TGATESW
52	R	I RL DOOR SW
53	SB	I AS DOOR2 SW
57	SB	I DR DOOR2 SW
60	L	CAN-H

Terminal No.	Color of Wire	Signal Name
61	BR	SES EXT REAR ANTENNA B
62	Y	SES INT MIDDLE ANTENNA B (WITH INTELLIGENT KEY SYSTEM)
63	L	SES INT MIDDLE ANTENNA A (WITH INTELLIGENT KEY SYSTEM)
64	G	SES EXT REAR ANTENNA A (WITH INTELLIGENT KEY SYSTEM)
80	P	CAN-L

Connector No.	B41
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Terminal No.	Color of Wire	Signal Name
24	P	-
25	L	-

Connector No.	B46
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32

Terminal No.	Color of Wire	Signal Name
19	LG	-

Connector No.	B49
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2	3	4	5		
6	7	8	9	10	11	12

Terminal No.	Color of Wire	Signal Name
6	SB	-
10	W	-

Connector No.	B54
Connector Name	WIRE TO WIRE
Connector Color	WHITE



1	2
---	---


Terminal No.	Color of Wire	Signal Name
1	B	-

# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	B71
Connector Name	FRONT DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	SB	-

Connector No.	B70
Connector Name	REAR DOOR SWITCH LH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	R	-

Connector No.	B63
Connector Name	JOINT CONNECTOR-B01
Connector Color	GRAY




Terminal No.	Color of Wire	Signal Name
3	P	-
4	L	-
7	P	-
8	L	-

Connector No.	B142
Connector Name	REAR DOOR SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
3	W	-

Connector No.	B141
Connector Name	FRONT DOOR SWITCH RH
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	GR	-

Connector No.	B140
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
6	GR	-
10	W	-

AAKIA2450GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P


SEC

# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]


< WIRING DIAGRAM >

Connector No.	D6
Connector Name	MAIN POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	B	GND
3	L	LOCK SW
15	BG	UNLOCK SW

Connector No.	D3
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
20	BR	-
21	P	-
23	L	-
24	BG	-

Connector No.	D2
Connector Name	WIRE TO WIRE
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
16	B	-

Connector No.	D112
Connector Name	POWER WINDOW AND DOOR LOCK/UNLOCK SWITCH RH
Connector Color	WHITE




Terminal No.	Color of Wire	Signal Name
1	LG	-
2	BR	-
3	B	-

Connector No.	D101
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
2	B	-
19	LG	-
20	BR	-

Connector No.	D23
Connector Name	FRONT DOOR LOCK ASSEMBLY LH
Connector Color	GRAY



Terminal No.	Color of Wire	Signal Name
4	B	-
5	P	-
6	BR	-

AAKIA3205GB





# VEHICLE SECURITY SYSTEM

[WITHOUT INTELLIGENT KEY SYSTEM]



< WIRING DIAGRAM >

Connector No.	D508
Connector Name	BACK DOOR LOCK ASSEMBLY (WITHOUT AUTOMATIC BACK DOOR SYSTEM)
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
3	W	-
4	GR	-

Connector No.	D505
Connector Name	WIRE TO WIRE
Connector Color	WHITE



Terminal No.	Color of Wire	Signal Name
1	B	-

Connector No.	D501
Connector Name	WIRE TO WIRE
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
19	W	-

Connector No.	D512
Connector Name	BACK DOOR LOCK ASSEMBLY (WITH AUTOMATIC BACK DOOR SYSTEM)
Connector Color	WHITE

Terminal No.	Color of Wire	Signal Name
7	W	-
8	B	-

AAKIA3218GB

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITHOUT INTELLIGENT KEY SYSTEM]


## BASIC INSPECTION

### DIAGNOSIS AND REPAIR WORKFLOW

Work Flow

INFOID:000000012424048

OVERALL SEQUENCE



ALKIA2308GB

# DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

## DETAILED FLOW

### 1.GET INFORMATION FOR SYMPTOM

Get the detailed information from the customer about the symptom (the condition and the environment when the incident/malfunction occurred).

>> GO TO 2.

### 2.CHECK DTC

1. Check DTC for BCM.
2. Perform the following procedure if DTC is displayed.
  - Erase DTC.
  - Study the relationship between the cause detected by DTC and the symptom described by the customer.
3. Check related service bulletins for information.

Is any symptom described and any DTC detected?

- Symptom is described, DTC is displayed>>GO TO 3.
- Symptom is described, DTC is not displayed>>GO TO 4.
- Symptom is not described, DTC is displayed>>GO TO 5.

### 3.CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.  
Connect CONSULT to the vehicle in "Data Monitor" and check real-time diagnosis results.  
Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 5.

### 4.CONFIRM THE SYMPTOM

Confirm the symptom described by the customer.  
Connect CONSULT to the vehicle in "Data Monitor" and check real-time diagnosis results.  
Verify relation between the symptom and the condition when the symptom is detected.

>> GO TO 6.

### 5.PERFORM DTC CONFIRMATION PROCEDURE

Perform DTC Confirmation Procedure for the displayed DTC, and then check that DTC is detected again.  
If two or more DTCs are detected, refer to [BCS-109. "DTC Inspection Priority Chart"](#) (BCM) and determine trouble diagnosis order.

Is DTC detected?

- YES >> GO TO 7.
- NO >> Refer to [GI-45. "Intermittent Incident"](#).

### 6.DETECT MALFUNCTIONING SYSTEM BY SYMPTOM TABLE

Detect malfunctioning system according to Symptom Table based on the confirmed symptom in step 4.

>> GO TO 7.

### 7.DETECT MALFUNCTIONING PART BY DIAGNOSTIC PROCEDURE

Inspect according to Diagnostic Procedure of the system.

#### NOTE:

The Diagnostic Procedure is described based on open circuit inspection. A short circuit inspection is also required for the circuit check in the Diagnostic Procedure.

>> GO TO 8.

### 8.REPAIR OR REPLACE THE MALFUNCTIONING PART

1. Repair or replace the malfunctioning part.
2. Reconnect parts or connectors disconnected during Diagnostic Procedure again after repair and replacement.

## DIAGNOSIS AND REPAIR WORKFLOW

< BASIC INSPECTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

---

3. Check DTC. If DTC is displayed, erase it.

>> GO TO 9.

### 9.FINAL CHECK

---

When DTC was detected in step 8, perform DTC Confirmation Procedure or Component Function Check again, and then check that the malfunctions have been fully repaired.

When symptom was described by the customer, refer to the confirmed symptom in step 3 or 4, and check that the symptom is not detected.

Does the symptom reappear?

YES (DTC is detected)>>GO TO 7.

YES (Symptom remains)>>GO TO 6.

NO >> Inspection End.

# INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

## INSPECTION AND ADJUSTMENT

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT

### ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement

INFOID:0000000012424049

Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

### ECM RE-COMMUNICATING FUNCTION

### ECM RE-COMMUNICATING FUNCTION : Description

INFOID:0000000012424050

Performing following procedure can automatically perform re-communication of ECM and BCM, but only when the ECM has been replaced with a new one (\*1).

\*1: New one means an ECM which has never been energized on-board.

(In this step, initialization procedure by CONSULT is not necessary)

#### NOTE:

- **When registering new Key IDs or replacing the ECM that is not brand new, refer to CONSULT Immobilizer mode and follow the on-screen instructions.**
- **If multiple keys are attached to the key holder, separate them before work.**
- **Distinguish keys with unregistered key ID from those with registered ID.**

### ECM RE-COMMUNICATING FUNCTION : Special Repair Requirement

INFOID:0000000012424051

## 1. PERFORM ECM RE-COMMUNICATING FUNCTION

1. Install ECM.
2. Using a registered key (\*2), turn ignition switch to "ON".  
\*2: To perform this step, use the key that has been used before performing ECM replacement.
3. Maintain ignition switch in "ON" position for at least 5 seconds.
4. Turn ignition switch to "OFF".
5. Start engine.

#### Can engine be started?

YES >> Procedure is completed.

NO >> Initialize control unit. Refer to CONSULT Immobilizer mode and follow the on-screen instructions.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## KEYFOB ID REGISTRATION

< BASIC INSPECTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

---

### KEYFOB ID REGISTRATION

#### Description

*INFOID:000000012424052*

Perform system initialization when replacing BCM, replacing keyfob or registering an additional keyfob. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

# P1610 LOCK MODE

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## DTC/CIRCUIT DIAGNOSIS

### P1610 LOCK MODE

#### Description

INFOID:0000000012424053

ECM forcibly switches to the mode that inhibits engine start, when engine start operation is performed 5 times or more while communication between ECM and BCM is not normal.

#### DTC Logic

INFOID:0000000012424054

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B1610 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-126, "DTC Logic"](#).
- If DTC B1610 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-127, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1610	LOCK MODE	When ECM detects a communication malfunction between ECM and BCM 5 times or more.	—

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

##### Is DTC detected?

- YES >> Go to [SEC-167, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:0000000012424055

##### 1. CHECK ENGINE START FUNCTION

1. Check that there are no DTC's except for DTC P1610 detected.  
If detected, erase the DTC after fixing.
2. Turn ignition switch OFF.
3. Insert the registered key into the ignition switch and wait 5 seconds.
4. Turn ignition switch ON.
5. Turn ignition switch OFF and wait 5 seconds.
6. Repeat steps 3 and 5 twice (a total of 3 times).
7. Check that engine can start.

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# P1611 ID DISCORD, IMMUECM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## P1611 ID DISCORD, IMMUECM

### DTC Logic

INFOID:000000012424056

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1611	ID DISCORD, IMMUECM	The ID verification results between BCM and ECM are NG.	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• BCM</li><li>• ECM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-168, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424057

#### 1. PERFORM INITIALIZATION

Perform initialization of BCM and reregistration of all keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with reregistered key?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2. CHECK SELF DIAGNOSTIC RESULT

1. Select "Self Diagnostic Result" of "ENGINE" using CONSULT.
2. Erase DTC.
3. Perform DTC CONFIRMATION PROCEDURE for DTC P1611. Refer to [SEC-168, "DTC Logic"](#).

#### Is DTC detected?

- YES >> GO TO 3.  
NO >> Inspection End.

#### 3. REPLACE BCM

1. Replace BCM. Refer to [BCS-137, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with registered key?

- YES >> Inspection End.  
NO >> GO TO 4.

#### 4. REPLACE ECM

1. Replace ECM. Refer to [EC-503, "Removal and Installation"](#).
2. Perform "ADDITIONAL SERVICE WHEN REPLACING ECM". Refer to [EC-139, "Work Procedure"](#).

>> Inspection End.



# P1612 CHAIN OF ECM-IMMU

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## P1612 CHAIN OF ECM-IMMU

### DTC Logic

INFOID:000000012424058

### DTC DETECTION LOGIC

#### NOTE:

- If DTC P1612 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-126, "DTC Logic"](#).
- If DTC P1612 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-127, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P1612	CHAIN OF BCM-ECM	Inactive communication between BCM and ECM.	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• ECM</li><li>• BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-169, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424059

#### NOTE:

- If DTC P1612 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-126, "DTC Logic"](#).
- If DTC P1612 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-127, "DTC Logic"](#).

#### 1.CHECK BCM POWER SUPPLY AND GROUND CIRCUIT.

Check BCM power supply and ground circuit. Refer to [BCS-130, "Diagnosis Procedure"](#).

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace the harness.

#### 2.CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.

Check ECM power supply and ground circuit. Refer to [EC-168, "Diagnosis Procedure"](#).

#### Is the inspection result normal?

- YES >> GO TO 3.  
NO >> Repair or replace the harness.

#### 3.PERFORM DTC CONFIRMATION PROCEDURE.

Perform the DTC confirmation procedure. Refer to [SEC-169, "DTC Logic"](#).

#### Does the DTC return?

- YES >> Replace BCM. Refer to [BCS-137, "Removal and Installation"](#)  
NO >> Inspection End.

# P161D IMMOBILIZER

[WITHOUT INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## P161D IMMOBILIZER

### DTC Logic

INFOID:000000012424060

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P161D	IMMOBILIZER	When immobilizer detects a malfunction, and prohibits the engine start.	BCM

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-172. "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424061

#### 1.REPLACE BCM

Replace BCM. Refer to [BCS-137. "Removal and Installation"](#).

>> Inspection End.

# P161E IMMOBILIZER

[WITHOUT INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## P161E IMMOBILIZER

### DTC Logic

INFOID:000000012424062

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P161E	IMMOBILIZER	After replacing the ECM, when the ECM is not registered to the vehicle by using the CONSULT.	<ul style="list-style-type: none"><li>• BCM</li><li>• ECM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-172, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424063

#### 1.PERFORM REGISTRATION OF ECM

Perform registration of ECM using CONSULT.

#### Is DTC detected?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2.REPLACE BCM

Replace BCM. Refer to [BCS-137, "Removal and Installation"](#).

#### Is DTC detected?

- YES >> GO TO 3.  
NO >> Inspection End.

#### 3.REPLACE ECM

Replace ECM. Refer to [EC-503, "Removal and Installation"](#).

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# P161F IMMOBILIZER

[WITHOUT INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## P161F IMMOBILIZER

### DTC Logic

INFOID:000000012424064

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
P161F	IMMOBILIZER	When immobilizer detects a malfunction, and prohibits the engine start.	ECM

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "ENGINE" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-172. "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424065

#### 1.REPLACE ECM

Replace ECM. Refer to [EC-503. "Removal and Installation"](#).

>> Inspection End.

# B2190 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## B2190 NATS ANTENNA AMP.

### Description

INFOID:0000000012424066

Performs ID verification through BCM and NATS antenna amplifier when ignition switch turned ON.  
Prohibits the start of engine when an unregistered ID of ignition key is used.

### DTC Logic

INFOID:0000000012424067

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2190	NATS ANTENNA AMP	<ul style="list-style-type: none"><li>Inactive communication between NATS antenna amp. and BCM.</li><li>Ignition key is malfunctioning.</li></ul>	<ul style="list-style-type: none"><li>Harness or connectors (The NATS antenna amp. circuit is open or shorted)</li><li>Ignition key</li><li>NATS antenna amp.</li><li>BCM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

- Turn ignition switch ON.
- Check "Self Diagnostic Result" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-173, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012424068

#### 1. IGNITION KEY REGISTRATION

Using CONSULT, register all Ignition Keys again.

>> GO TO 2.

#### 2. CHECK SELF DIAGNOSIS RESULT

- Select "Self Diagnostic Result" of "BCM" using CONSULT.
- Erase DTC.
- Perform DTC CONFIRMATION PROCEDURE for B2190. Refer to [SEC-173, "Description"](#).

#### Is DTC detected?

- YES >> GO TO 3.  
NO >> Inspection End.

#### 3. CHECK FUSE

- Turn ignition switch OFF.
- Check that the following fuse block (J/B) fuse is not blown.

Signal name	Fuse No.
Battery power supply	9 (5A)

#### Is the fuse fusing?

- YES >> Replace the blown fuse after repairing the affected circuit if a fuse is blown.  
NO >> GO TO 4.

#### 4. CHECK NATS ANTENNA AMP. POWER SUPPLY

- Disconnect NATS antenna amp. connector.
- Check voltage between NATS antenna amp. harness connector and ground.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B2190 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

(+)		(-)	Voltage (Approx.)
NATS antenna amp.			
Connector	Terminal		
M4	3	Ground	Battery voltage

Is the inspection result normal?

YES >> GO TO 6.

NO >> GO TO 5.

## 5.CHECK NATS ANTENNA AMP. POWER SUPPLY CIRCUIT

1. Disconnect fuse block (J/B) connector.
2. Check continuity between NATS antenna amp. harness connector and fuse block (J/B) harness connector.

NATS antenna amp.		Fuse block (J/B)		Continuity
Connector	Terminal	Connector	Terminal	
M4	3	M68	12R	Yes

3. Check continuity between NATS antenna amp. harness connector and ground.

NATS antenna amp.		Ground	Continuity
Connector	Terminal		
M4	3		No

Is the inspection result normal?

YES >> Replace fuse block (J/B).

NO >> Repair or replace harness.

## 6.CHECK NATS ANTENNA AMP. GROUND CIRCUIT

Check continuity between NATS antenna amp. harness connector and ground.

NATS antenna amp.		Ground	Continuity
Connector	Terminal		
M4	2		Yes

Is the inspection result normal?

YES >> GO TO 7.

NO >> Repair or replace harness.

## 7.CHECK NATS ANTENNA COMMUNICATION SIGNAL

Check voltage between NATS antenna amp. harness connector and ground.

(+)		(-)	Condition	Voltage (Approx.)
NATS antenna amp.				
Connector	Terminal			
M4	1	Ground	Just after inserting ignition key into key cylinder	Pointer of tester should move
			Other than above	0 V
	4		Just after inserting ignition key into key cylinder	Pointer of tester should move
			Other than above	0 V

Is the inspection result normal?

YES >> Replace NATS antenna amp. Refer to [SEC-201, "Removal and Installation"](#).

NO >> GO TO 8.

## 8.CHECK NATS ANTENNA COMMUNICATION SIGNAL CIRCUIT

# B2190 NATS ANTENNA AMP.

[WITHOUT INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

1. Disconnect BCM connector and NATS antenna connector.
2. Check continuity between NATS antenna amp. harness connector and BCM harness connector.

NATS antenna amp.		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M4	1	M19	109	Yes
	4		113	

3. Check continuity between BCM harness connector and ground.

BCM		Ground	Continuity
Connector	Terminal		
M19	109		No
	113		

Is the inspection result normal?

YES >> GO TO 9.

NO >> Repair or replace harness.

## 9. REPLACE BCM

Replace BCM. Refer to [BCS-137. "Removal and Installation"](#).

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B2191 DIFFERENCE OF KEY

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## B2191 DIFFERENCE OF KEY

### DTC Logic

INFOID:000000012424069

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2191	DIFFERENCE OF KEY	The ID verification results between BCM and mechanical key are NG. The registration is necessary.	Mechanical key

### DTC CONFIRMATION PROCEDURE

#### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-176, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424070

#### 1.KEY REGISTRATION

Using CONSULT, register all keys again.

#### Can engine be started with the registered key?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2.REPLACE KEY

1. Prepare key that matches the vehicle.
2. Registration of all keys using CONSULT.

#### Can engine be started with the registered keys?

- YES >> Inspection End.  
NO >> GO TO 3.

#### 3.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> Inspection End.



# B2192 ID DISCORD, IMMUECM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## B2192 ID DISCORD, IMMUECM

### DTC Logic

INFOID:000000012424071

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2192	ID DISCORD BCM-ECM	The ID verification results between BCM and ECM are NG.	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• BCM</li><li>• ECM</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> GO TO [SEC-177, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424072

#### 1. PERFORM INITIALIZATION

Perform initialization of BCM and reregistration of all keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with reregistered key?

- YES >> Inspection End.  
NO >> GO TO 2.

#### 2. CHECK SELF-DIAGNOSTIC RESULT

1. Select "Self Diagnostic Result" of "BCM" using CONSULT.
2. Erase DTC.
3. Perform DTC CONFIRMATION PROCEDURE for DTC B2192. Refer to [SEC-177, "DTC Logic"](#).

#### Is DTC detected?

- YES >> GO TO 3.  
NO >> Inspection End.

#### 3. REPLACE BCM

1. Replace BCM. Refer to [BCS-137, "Removal and Installation"](#).
2. Perform initialization of BCM and reregistration of all keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

#### Can the system be initialized and can the engine be started with registered key?

- YES >> Inspection End.  
NO >> GO TO 4.

#### 4. REPLACE ECM

1. Replace ECM. Refer to [EC-503, "Removal and Installation"](#).
2. Perform "ADDITIONAL SERVICE WHEN REPLACING ECM". Refer to [EC-139, "Work Procedure"](#).

>> Inspection End.

# B2193 CHAIN OF ECM-IMMU

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## B2193 CHAIN OF ECM-IMMU

### DTC Logic

INFOID:000000012424073

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2193 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-126, "DTC Logic"](#).
- If DTC B2193 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-127, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2193	CHAIN OF BCM-ECM	Inactive communication between BCM and ECM.	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• ECM</li><li>• BCM</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1.PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is DTC detected?

- YES >> GO TO [SEC-178, "Diagnosis Procedure"](#).  
NO >> Inspection End.

#### Diagnosis Procedure

INFOID:000000012424074

##### NOTE:

- If DTC B2193 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-126, "DTC Logic"](#).
- If DTC B2193 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-127, "DTC Logic"](#).

##### 1.CHECK BCM POWER SUPPLY AND GROUND CIRCUIT.

Check BCM power supply and ground circuit. Refer to [BCS-130, "Diagnosis Procedure"](#).

##### Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace the harness.

##### 2.CHECK ECM POWER SUPPLY AND GROUND CIRCUIT.

Check ECM power supply and ground circuit. Refer to [EC-168, "Diagnosis Procedure"](#).

##### Is the inspection result normal?

- YES >> Replace ECM. Refer to [EC-503, "Removal and Installation"](#). GO TO 3.  
NO >> Repair or replace the harness.

##### 3.PERFORM DTC CONFIRMATION PROCEDURE.

Perform the DTC confirmation procedure. Refer to [SEC-178, "DTC Logic"](#).

##### Does the DTC return?

- YES >> Replace BCM. Refer to [BCS-137, "Removal and Installation"](#)  
NO >> Inspection End.

# B2196 DONGLE UNIT

[WITHOUT INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## B2196 DONGLE UNIT

### Description

INFOID:000000012424075

BCM performs ID verification between BCM and dongle unit.  
When verification result is OK, BCM permits cranking.

### DTC Logic

INFOID:000000012424076

#### DTC DETECTION LOGIC

##### NOTE:

- If DTC B2196 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-126, "DTC Logic"](#).
- If DTC B2196 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-127, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2196	DONGLE NG	The ID verification results between BCM and dongle unit is NG.	<ul style="list-style-type: none"><li>• Harness or connectors (Dongle unit circuit is open or shorted.)</li><li>• Dongle unit</li></ul>

#### DTC CONFIRMATION PROCEDURE

##### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON.
2. Turn ignition switch OFF.
3. Turn ignition switch ON.
4. Check "Self Diagnostic Result" of "BCM" using CONSULT.

##### Is the DTC detected?

- YES >> Refer to [SEC-179, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424077

Regarding Wiring Diagram information, refer to [SEC-139, "Wiring Diagram"](#).

##### 1. PERFORM INITIALIZATION

1. Perform initialization of BCM and reregistration of all keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.
2. Start the engine.

##### Dose the engine start?

- YES >> Inspection End.  
NO >> GO TO 2.

##### 2. CHECK DONGLE UNIT CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector and dongle unit connector.
3. Check continuity between BCM harness connector and dongle unit harness connector.

BCM		Dongle unit		Continuity
Connector	Terminal	Connector	Terminal	
M18	16	M5	1	Yes

4. Check continuity between BCM harness connector and ground.

## B2196 DONGLE UNIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

BCM		Ground	Continuity
Connector	Terminal		
M18	16		No

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair or replace harness.

### 3. CHECK DONGLE UNIT GROUND CIRCUIT

Check continuity between dongle unit harness connector and ground.

Dongle unit		Ground	Continuity
Connector	Terminal		
M5	4		Yes

Is the inspection result normal?

YES >> Replace dongle unit.

NO >> Repair or replace harness.

# B2198 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## B2198 NATS ANTENNA AMP.

### DTC Logic

INFOID:000000012424078

### DTC DETECTION LOGIC

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2198	NATS ANTENNA AMP	Inactive communication between NATS antenna amp. and BCM is detected when BCM enters in the low power consumption mode. (BCM sleep condition)	<ul style="list-style-type: none"> <li>• Harness or connectors (NATS antenna amp. circuit is open or shorted.)</li> <li>• NATS antenna amp.</li> <li>• BCM</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Make the conditions that BCM enters in the low power consumption mode (BCM sleep condition). Refer to [BCS-85. "POWER CONSUMPTION CONTROL SYSTEM : System Description"](#).
2. Turn ignition switch ON.
3. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-181. "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424079

Regarding Wiring Diagram information, refer to [SEC-139. "Wiring Diagram"](#).

#### 1. CHECK FUSE

1. Turn power switch OFF.
2. Check that the following fuse in fuse block (J/B) is not blown.

Signal name	Fuse No.
Battery power supply	9 (5 A)

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO >> Replace the blown fuse after repairing the affected circuit.

#### 2. CHECK NATS ANTENNA AMP. POWER SUPPLY

1. Disconnect NATS antenna amp. connector.
2. Check voltage between NATS antenna amp. harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
NATS antenna amp.			
Connector	Terminal		
M4	3	Ground	Battery voltage

#### Is the inspection result normal?

- YES >> GO TO 4.  
 NO >> GO TO 3.

#### 3. CHECK NATS ANTENNA AMP. POWER SUPPLY CIRCUIT

1. Disconnect fuse block (J/B) connector.
2. Check continuity between fuse block (J/B) harness connector and NATS antenna amp. connector.

## B2198 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

Fuse block (J/B)		NATS antenna amp.		Continuity
Connector	Terminal	Connector	Terminal	
M44	12 R	M4	3	Yes

Is the inspection result normal?

- YES >> Replace fuse block (J/B).  
 NO >> Repair or replace harness.

### 4. CHECK NATS ANTENNA AMP. GROUND CIRCUIT

Check continuity between NATS antenna amp. harness connector and ground.


NATS antenna amp.		Ground	Continuity
Connector	Terminal		
M4	2		Yes

Is the inspection result normal?

- YES >> GO TO 5.  
 NO >> Repair or replace harness.

### 5. CHECK NATS ANTENNA AMP. COMMUNICATION SIGNAL 1

Check voltage signal between NATS antenna amp. harness connector and ground using an oscilloscope.

(+)		(-)	Condition	Voltage (V) (Approx.)
NATS antenna amp.				
Connector	Terminal			
M4	1	Ground	Key: Key battery is removed  Brake pedal: Depressed <b>NOTE:</b> Waveform varies each time when brake pedal is depressed.	
			Brake pedal: Not depressed	Battery voltage

Is the inspection result normal?

- YES >> GO TO 7.  
 NO >> GO TO 6.

### 6. CHECK NATS ANTENNA AMP. OUTPUT SIGNAL CIRCUIT 1

1. Disconnect BCM connector.
2. Check continuity between NATS antenna amp. harness connector and BCM connector.

NATS antenna amp.		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M4	1	M19	109	Yes

3. Check continuity between NATS antenna amp. harness connector and ground.

NATS antenna amp.		Ground	Continuity
Connector	Terminal		
M4	1		No

Is the inspection result normal?

- YES >> GO TO 9.  
 NO >> Repair or replace harness.


### 7. CHECK NATS ANTENNA AMP. COMMUNICATION SIGNAL 2

## B2198 NATS ANTENNA AMP.

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

Check voltage signal between NATS antenna amp. harness connector and ground using an oscilloscope.

(+)		(-)		Condition	Voltage (V) (Approx.)
NATS antenna amp.					
Connector	Terminal				
M4	4	Ground	Key: Key battery is removed	Brake pedal: Depressed <b>NOTE:</b> Waveform varies each time when brake pedal is depressed.	 <p style="text-align: right; font-size: small;">JMkia6233JP</p>
				Brake pedal: Not depressed	Battery voltage

Is the inspection result normal?

- YES >> Replace NATS antenna amp. Refer to [SEC-201, "Removal and Installation"](#).  
 NO >> GO TO 8.

### 8. CHECK NATS ANTENNA AMP. OUTPUT SIGNAL CIRCUIT 2

1. Disconnect BCM connector.
2. Check continuity between NATS antenna amp. harness connector and BCM connector.

NATS antenna amp.		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M4	4	M19	113	Yes

3. Check continuity between NATS antenna amp. harness connector and ground.

NATS antenna amp.		Ground	Continuity
Connector	Terminal		
M4	4		No

Is the inspection result normal?

- YES >> GO TO 9.  
 NO >> Repair or replace harness.

### 9. REPLACE BCM

1. Replace BCM. Refer to [BCS-137, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all keys using CONSULT.

>> Inspection End

# B2608 STARTER RELAY

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## B2608 STARTER RELAY

### DTC Logic

INFOID:000000012424080

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B2608 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-126, "DTC Logic"](#).
- If DTC B2608 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-127, "DTC Logic"](#).
- If DTC B2608 is displayed with other DTC (BCM), first perform the trouble diagnosis for other DTC detected.

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B2608	STARTER RELAY	BCM outputs starter relay OFF signal but BCM receives starter relay ON signal from IPDM E/R (CAN).	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• Harness or connectors (Starter relay circuit is open or shorted.)</li><li>• IPDM E/R</li><li>• Starter relay</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Press push-button ignition switch under the following conditions to start engine:
  - Selector lever: In the P position
  - Brake pedal: Depressed
2. Wait 1 second after engine started.
3. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-184, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424081

#### 1. CHECK DTC OF IPDM E/R

Select "Self Diagnostic Result" of "IPDM E/R" using CONSULT.

#### Is DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [PCS-26, "DTC Index"](#).  
NO >> GO TO 2.

#### 2. CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

#### Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace BCM. Refer to [BCS-137, "Removal and Installation"](#).



# B260F ENGINE STATUS

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## B260F ENGINE STATUS

### Description

INFOID:0000000012424082

BCM receives the engine status signal from ECM via CAN communication.

### DTC Description

INFOID:0000000012424083

### DTC DETECTION LOGIC

DTC No.	CONSULT screen items (Trouble diagnosis content)	DTC detecting condition
B260F	ENG STATE SIG LOST (Engine state signal lost)	BCM has not yet received the engine status signal from ECM when ignition switch is in the ON position.

### POSSIBLE CAUSE

- Harness or connectors  
(The CAN communication line is open or shorted.)
- ECM

### FAIL-SAFE

Inhibit engine cranking

### DTC CONFIRMATION PROCEDURE

#### 1. CHECK DTC PRIORITY

If DTC B260F is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for DTC U1000 or U1010.

#### Is applicable DTC detected?

- YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-126, "DTC Logic"](#). U1010: Refer to [BCS-127, "DTC Logic"](#).
- NO >> GO TO 2.

#### 2. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON and wait 2 seconds or more.
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Refer to [SEC-185, "Diagnosis Procedure"](#).
- NO-1 >> To check malfunction symptom before repair: Refer to [GI-45, "Intermittent Incident"](#).
- NO-2 >> Confirmation after repair: Inspection End.

### Diagnosis Procedure

INFOID:0000000012424084

#### 1. CHECK DTC PRIORITY

If DTC B260F is displayed with DTC U1000 or U1010, first perform the trouble diagnosis for DTC U1000 or U1010.

#### Is applicable DTC detected?

- YES >> Perform diagnosis of applicable. U1000: Refer to [BCS-126, "DTC Logic"](#). U1010: Refer to [BCS-127, "DTC Logic"](#).
- NO >> GO TO 2.

#### 2. INSPECTION START

1. Turn ignition switch ON.
2. Select "Self Diagnostic Result" of "BCM" using CONSULT.
3. Touch "ERASE".
4. Perform DTC CONFIRMATION PROCEDURE for DTC B260F. Refer to [SEC-185, "DTC Description"](#).

#### Is DTC detected?

- YES >> GO TO 3.
- NO >> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## B260F ENGINE STATUS

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

---

### 3.REPLACE ECM

---

Replace ECM. Refer [EC-503. "Removal and Installation"](#).

>> Inspection End.

# B261E VEHICLE TYPE

[WITHOUT INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

## B261E VEHICLE TYPE

### Description

INFOID:0000000012424085

There are two types of vehicles.

- HEV
- Conventional

### DTC Logic

INFOID:0000000012424086

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B261E is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-126, "DTC Logic"](#).
- If DTC B261E is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-127, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B261E	VEHICLE TYPE	Difference of BCM configuration.	<ul style="list-style-type: none"><li>• BCM mis-configuration</li><li>• Wrong ECM installed</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch ON under the following conditions.
  - Shift selector lever is in the P (Park) or N (Neutral) position
  - Do not depress brake pedal
2. Check "Self Diagnostic Result" of "BCM" using CONSULT.

Is DTC detected?

- YES >> GO TO [SEC-187, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:0000000012424087

#### 1. INSPECTION START

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" of "BCM" using CONSULT.
3. Touch "ERASE".
4. Perform DTC Confirmation Procedure. Refer to [SEC-187, "DTC Logic"](#).

Is the 1st trip DTC B261E displayed again?

- YES >> GO TO 2.  
NO >> Inspection End.

#### 2. PERFORM BCM CONFIGURATION.

Perform the BCM configuration. Refer to [BCS-123, "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 3.

#### 3. INSPECTION START

1. Turn ignition switch ON.
2. Check "Self Diagnostic Result" of "BCM" using CONSULT.
3. Touch "ERASE".
4. Perform DTC Confirmation Procedure.  
Refer to [SEC-187, "DTC Logic"](#).

Is the 1st trip DTC B261E displayed again?

- YES >> GO TO 4.  
NO >> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## B261E VEHICLE TYPE

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

---

### 4. CONFIRM ECM PART NUMBER.

---

Confirm the part number of the installed ECM is correct.

Is the ECM part number correct?

- YES >> Replace BCM. Refer to [BCS-137. "Removal and Installation"](#).
- NO >> Replace ECM. Refer to [EC-503. "Removal and Installation"](#).

# B27D1 START CUT RELAY OFF

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## B27D1 START CUT RELAY OFF

### DTC Logic

INFOID:000000012424088

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B27D1 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-126, "DTC Logic"](#).
- If DTC B27D1 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-127, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B27D1	STARTER CUT RELAY OFF	When comparing the starter cut relay signal (CAN) from IPDM E/R, BCM detects that starter cut relay is stuck in the OFF position for 1 second or more.	<ul style="list-style-type: none"> <li>• Harness or connectors (The CAN communication line is open or shorted.)</li> <li>• Harness or connector (Starter cut relay circuit is open or shorted.)</li> <li>• IPDM E/R</li> <li>• BCM</li> <li>• Starter cut relay</li> </ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch under the following conditions to start engine, and wait 1 second or more.
  - Selector lever: In the P position
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-189, "Diagnosis Procedure"](#).  
 NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424089

Regarding Wiring Diagram information, refer to [SEC-139, "Wiring Diagram"](#).

SEC

#### 1. CHECK STARTER CUT RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect starter cut relay.
3. Check voltage between starter cut relay harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Starter cut relay			
Connector	Terminal	Ground	Battery voltage
F55	1		
	3		

#### Is the inspection result normal?

- YES >> GO TO 2.  
 NO-1 >> Check 30 A fusible link [M, located in the fuse block (J/B)].  
 NO-2 >> Check harness for open or short between starter cut relay and fusible link.

#### 2. CHECK STARTER CUT RELAY CONTROL

1. Reconnect starter cut relay.
2. Check voltage between BCM harness connector and ground.

# B27D1 START CUT RELAY OFF

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

(+)		(-)	Condition	Voltage (V) (Approx.)	
BCM					
Connector	Terminal				
E29	139	Ground	CVT shift selector lever	N or P position	Battery voltage
				Other than above	0

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

## 3. CHECK STARTER CUT RELAY CONTROL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Disconnect starter cut relay.
4. Check continuity between BCM harness connector and starter cut relay harness connector.

BCM		Starter cut relay		Continuity
Connector	Terminal	Connector	Terminal	
E29	139	F55	2	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4. CHECK STARTER CUT RELAY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and starter cut relay harness connector.

IPDM E/R		Starter cut relay		Continuity
Connector	Terminal	Connector	Terminal	
F41	86	F55	5	Yes

4. Check continuity between BCM harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
F41	86		No

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 5. CHECK STARTER CUT RELAY

Refer to [SEC-191. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace starter cut relay.

## 6. REPLACE BCM

1. Replace BCM. Refer to [BCS-137. "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all keys using CONSULT.
3. Perform DTC CONFIRMATION PROCEDURE for DTC B27D1. Refer to [SEC-189. "DTC Logic"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace IPDM E/R. Refer to [PCS-44. "Removal and Installation"](#).

# B27D1 START CUT RELAY OFF

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## Component Inspection

INFOID:000000012424090

### 1. CHECK STARTER CUT RELAY

1. Turn ignition switch OFF.
2. Disconnect starter cut relay.
3. Check continuity between starter cut relay terminals.

Starter cut relay		Condition	Continuity
Terminal			
3	5	12 V direct current supply between terminals 1 and 2	Yes
		No current supply	No

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace starter cut relay.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B27D2 START CUT RELAY ON

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## B27D2 START CUT RELAY ON

### DTC Logic

INFOID:000000012424091

### DTC DETECTION LOGIC

#### NOTE:

- If DTC B27D2 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-126, "DTC Logic"](#).
- If DTC B27D2 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-127, "DTC Logic"](#).

DTC No.	Trouble diagnosis name	DTC detecting condition	Possible cause
B27D2	STARTER CUT RELAY ON	When comparing the starter cut relay signal (CAN) from IPDM E/R, BCM detects that starter cut relay is stuck in the ON position for 1 second or more.	<ul style="list-style-type: none"><li>• Harness or connectors (The CAN communication line is open or shorted.)</li><li>• Harness or connector (Starter cut relay circuit is open or shorted.)</li><li>• IPDM E/R</li><li>• BCM</li><li>• Starter cut relay</li></ul>

### DTC CONFIRMATION PROCEDURE

#### 1. PERFORM DTC CONFIRMATION PROCEDURE

1. Turn ignition switch under the following conditions to start engine, and wait 1 second or more.
  - Selector lever: In the P position
2. Check DTC in "Self Diagnostic Result" of "BCM" using CONSULT.

#### Is DTC detected?

- YES >> Go to [SEC-192, "Diagnosis Procedure"](#).  
NO >> Inspection End.

### Diagnosis Procedure

INFOID:000000012424092

Regarding Wiring Diagram information, refer to [SEC-139, "Wiring Diagram"](#).

#### 1. CHECK STARTER CUT RELAY POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect starter cut relay.
3. Check voltage between starter cut relay harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Starter cut relay			
Connector	Terminal	Ground	Battery voltage
F55	1		
	3		

#### Is the inspection result normal?

- YES >> GO TO 2.  
NO-1 >> Check 30 A fusible link [M, located in the fuse block (J/B)].  
NO-2 >> Check harness for open or short between starter cut relay and fusible link.

#### 2. CHECK STARTER CUT RELAY CONTROL

1. Reconnect starter cut relay.
2. Check voltage between BCM harness connector and ground.



# B27D2 START CUT RELAY ON

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

(+)		(-)	Condition	Voltage (V) (Approx.)
BCM				
Connector	Terminal			
E29	139	Ground	CVT shift selector lever	N or P position Battery voltage
				Other than above 0

Is the inspection result normal?

YES >> GO TO 4.

NO >> GO TO 3.

## 3. CHECK STARTER CUT RELAY CONTROL CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connector.
3. Disconnect starter cut relay.
4. Check continuity between BCM harness connector and starter cut relay harness connector.

BCM		Starter cut relay		Continuity
Connector	Terminal	Connector	Terminal	
E29	139	F55	2	Yes

Is the inspection result normal?

YES >> GO TO 4.

NO >> Repair or replace harness.

## 4. CHECK STARTER CUT RELAY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect IPDM E/R connector.
3. Check continuity between IPDM E/R harness connector and starter cut relay harness connector.

IPDM E/R		Starter cut relay		Continuity
Connector	Terminal	Connector	Terminal	
F41	86	F55	5	Yes

4. Check continuity between BCM harness connector and ground.

IPDM E/R		Ground	Continuity
Connector	Terminal		
F41	86		No

Is the inspection result normal?

YES >> GO TO 5.

NO >> Repair or replace harness.

## 5. CHECK STARTER CUT RELAY

Refer to [SEC-194. "Component Inspection"](#).

Is the inspection result normal?

YES >> GO TO 6.

NO >> Replace starter cut relay.

## 6. REPLACE BCM

1. Replace BCM. Refer to [BCS-137. "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all keys using CONSULT.
3. Perform DTC CONFIRMATION PROCEDURE for DTC B27D2. Refer to [SEC-192. "DTC Logic"](#).

Is the inspection result normal?

YES >> Inspection End.

NO >> Replace IPDM E/R. Refer to [PCS-44. "Removal and Installation"](#).

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# B27D2 START CUT RELAY ON

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## Component Inspection

INFOID:000000012424093

### 1. CHECK STARTER CUT RELAY

1. Turn ignition switch OFF.
2. Disconnect starter cut relay.
3. Check continuity between starter cut relay terminals.

Starter cut relay		Condition	Continuity
Terminal			
3	5	12 V direct current supply between terminals 1 and 2	Yes
		No current supply	No

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace starter cut relay.

# HEADLAMP FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## HEADLAMP FUNCTION

### Component Function Check

INFOID:000000012424094

#### 1.CHECK FUNCTION

1. Perform "HEAD LAMP(HI)" in "Active Test" of "THEFT ALM" of "BCM" using CONSULT.
2. Check headlamps operation.

Test item		Description	
HEAD LAMP (HI)	ON	Headlamps (Hi)	Light
	OFF		Does not light

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Refer to [SEC-195, "Diagnosis Procedure"](#).

### Diagnosis Procedure

INFOID:000000012424095

#### 1.CHECK HEADLAMP FUNCTION

Refer to [SEC-195, "Component Function Check"](#).

Is the inspection result normal?

- YES >> GO TO 2.  
NO >> Repair or replace the malfunctioning parts.

#### 2.CHECK INTERMITTENT INCIDENT

Refer to [GI-45, "Intermittent Incident"](#).

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# HORN FUNCTION

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## HORN FUNCTION

### Component Function Check

INFOID:000000012424096

#### 1.CHECK FUNCTION 1

1. Perform "VEHICLE SECURITY HORN" in "Active Test" of "THEFT ALM" of "BCM" using CONSULT.
2. Check the horn operation.

Test item		Description	
VEHICLE SECURITY HORN	ON	Horn	Sounds (for 0.5 sec)

Is the operation normal?

- YES >> Inspection End.  
NO >> Go to [SEC-149. "Wiring Diagram"](#).

### Component Inspection

INFOID:000000012424097

#### 1.CHECK ANTI-THEFT HORN RELAY

1. Turn ignition switch OFF.
2. Disconnect anti-theft horn relay.
3. Check voltage between anti-theft horn relay connector E101 terminal 2 and ground under the following conditions.

(+)	(-)	Condition	Voltage (V) (Approx.)
Anti-theft horn relay Terminal			
2	Ground	12 V direct current supply between terminals 1 and 3	12
		No current supply	0

Is the inspection result normal?

- YES >> Inspection End.  
NO >> Replace anti-theft horn relay.

# SECURITY INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## SECURITY INDICATOR LAMP

### Component Function Check

INFOID:000000012424098

#### 1.CHECK FUNCTION

1. Perform "THEFT IND" in "Active Test" of "IMMU" of "BCM" using CONSULT.
2. Check security indicator lamp operation.

Test item		Description	
THEFT IND	ON	Security indicator lamp	Illuminates
	OFF		Does not illuminate

Is the inspection result normal?

- YES >> Inspection End.  
 NO >> Go to [SEC-197, "Diagnosis Procedure"](#).

#### Diagnosis Procedure

INFOID:000000012424099

Regarding Wiring Diagram information, refer to [SEC-149, "Wiring Diagram"](#).

#### 1.CHECK SECURITY INDICATOR LAMP POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect combination meter connector.
3. Check voltage between combination meter harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
Combination meter			
Connector	Terminal	Ground	Battery voltage
M77	45		

Is the inspection result normal?

- YES >> GO TO 2.  
 NO-1 >> Check 10 A fuse [No. 13, located in the fuse block (J/B)].  
 NO-2 >> Check harness for open or short between combination meter and fuse.

#### 2.CHECK SECURITY INDICATOR LAMP SIGNAL

1. Connect combination meter connector.
2. Disconnect BCM connector.
3. Check voltage between BCM harness connector and ground.

(+)		(-)	Voltage (V) (Approx.)
BCM			
Connector	Terminal	Ground	Battery voltage
M18	35		

Is the inspection result normal?

- YES >> GO TO 3.  
 NO >> GO TO 4.

#### 3.REPLACE BCM

1. Replace BCM. Refer to [BCS-137, "Removal and Installation"](#).
2. Perform initialization of BCM and registration of all Intelligent Keys using CONSULT. Refer to the CONSULT Immobilizer mode and follow the on-screen instructions.

>> Inspection End.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# SECURITY INDICATOR LAMP

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## 4. CHECK SECURITY INDICATOR LAMP CIRCUIT

1. Disconnect combination meter connector.
2. Check continuity between combination meter harness connector and BCM harness connector.

Combination meter		BCM		Continuity
Connector	Terminal	Connector	Terminal	
M76	7	M18	35	Yes

3. Check continuity between combination meter harness connector and ground.

Combination meter		Ground	Continuity
Connector	Terminal		
M76	7		No

Is the inspection result normal?

- YES >> Replace combination meter. Refer to [MWI-84. "Removal and Installation"](#).  
NO >> Repair or replace harness.

# NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS SYMPTOMS

< SYMPTOM DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## SYMPTOM DIAGNOSIS

### NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS SYMPTOMS

#### Symptom Table

INFOID:0000000012424100

#### NOTE:

- Before performing the diagnosis in the following table, check "[SEC-162. "Work Flow"](#)".
- Check that vehicle is under the condition shown in "Conditions of vehicle" before starting diagnosis, and check each symptom.
- If the following symptoms are detected, check systems shown in the "Diagnosis/service procedure" column in this order.

#### CONDITIONS OF VEHICLE (OPERATING CONDITIONS)

- Mechanical key is not inserted into key cylinder.
- Ignition knob switch is not depressed.

Symptom	Diagnosis/service procedure	Reference page
Security indicator does not turn ON or flash.	1. Check vehicle security indicator	<a href="#">SEC-197</a>
	2. Check Intermittent Incident	<a href="#">GI-45</a>

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

# VEHICLE SECURITY SYSTEM

< SYMPTOM DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

## VEHICLE SECURITY SYSTEM

### Symptom Table

INFOID:000000012424101

Procedure		Diagnostic procedure	Refer to page
Symptom			
1	Vehicle security system cannot be set by ....	Door switch	Check door switch (front door LH, front door RH, rear door LH, rear door RH). <a href="#">DLK-335</a>
		—	Check Intermittent Incident. <a href="#">GI-45</a>
	Security indicator does not turn ON.		Check vehicle security indicator. <a href="#">SEC-197</a>
			Check Intermittent Incident. <a href="#">GI-45</a>
2	* Vehicle security system does not sound alarm when ....	Any door is opened.	Check door switch (front door LH, front door RH, rear door LH, rear door RH). <a href="#">DLK-335</a>
		—	Check Intermittent Incident. <a href="#">GI-45</a>
3	Vehicle security alarm does not activate.	Horn alarm	Check horn switch. <a href="#">DLK-351</a>
			Check Intermittent Incident. <a href="#">GI-45</a>
		Headlamp flash	Check headlamp switch. <a href="#">DLK-353</a>
			Check Intermittent Incident. <a href="#">GI-45</a>

\*: Check the system is in the armed phase.



# NATS ANTENNA AMP.

< REMOVAL AND INSTALLATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

## REMOVAL AND INSTALLATION


### NATS ANTENNA AMP.


#### Removal and Installation

INFOID:0000000012424102

#### REMOVAL

1. Remove steering column covers. Refer to [IP-18. "Removal and Installation"](#).
2. Remove instrument lower panel LH. Refer to [IP-23. "Removal and Installation"](#).
3. Remove knee protector. Refer to [IP-14. "Exploded View"](#).
4. Disconnect the harness connector from the NATS antenna amp.
5. Release pawls using suitable tool and remove NATS antenna amp. (1) from the steering lock unit (2).

 : Pawl



#### INSTALLATION

Installation is in the reverse order of removal.

A  
B  
C  
D  
E  
F  
G  
H  
I  
J  
L  
M  
N  
O  
P

SEC

## DONGLE UNIT

< REMOVAL AND INSTALLATION >

[WITHOUT INTELLIGENT KEY SYSTEM]


### DONGLE UNIT

#### Removal and Installation

INFOID:000000012424103

#### REMOVAL

1. Remove instrument panel assembly. Refer to [IP-14. "INSTRUMENT PANEL ASSEMBLY : Removal and Installation"](#).
2. Disconnect the harness connector from the dongle unit (1).
3. Remove screw (A) and dongle unit (1) from the heating and cooling unit assembly (2).



#### INSTALLATION

Installation is in the reverse order of removal.