

BRAKE SYSTEM

SECTION **BR**

GI

MA

EM


LC

EF &
EC

CONTENTS

PRECAUTIONS AND PREPARATION	2	Removal.....	21	FE
Precautions.....	2	Disassembly.....	21	
Preparation.....	2	Inspection — Caliper.....	21	CL
Commercial Service Tools	2	Inspection — Rotor.....	22	
CHECK AND ADJUSTMENT	3	Assembly.....	22	
Checking Brake Fluid Level	3	Installation.....	23	MT
Checking Brake Line	3	REAR DRUM BRAKE	24	
Changing Brake Fluid.....	3	Removal.....	24	
Bleeding Brake System	3	Inspection — Wheel Cylinder.....	25	AT
BRAKE HYDRAULIC LINE/CONTROL VALVE	5	Wheel Cylinder Overhaul	25	
Proportioning Valve	7	Inspection — Drum.....	26	FA
BRAKE PEDAL AND BRACKET	8	Inspection — Lining.....	26	
Removal and Installation.....	8	Installation.....	26	
Inspection	8	PARKING BRAKE CONTROL	27	RA
Adjustment	8	Removal and Installation.....	27	
MASTER CYLINDER	9	Inspection	27	
Removal.....	9	Adjustment	27	BR
Disassembly.....	9	ANTI-LOCK BRAKE SYSTEM	28	
Inspection	10	Purpose	28	ST
Assembly.....	10	Operation.....	28	
Installation.....	10	System Components	30	
BRAKE BOOSTER/VACUUM HOSE	12	System Description	30	BF
Brake Booster	12	Circuit Diagram	33	
Vacuum Hose	13	Wiring Diagram	34	HA
FRONT DISC BRAKE	14	Removal and Installation.....	35	
Pad Replacement.....	14	Removal.....	35	
Removal.....	17	Installation.....	37	EL
Disassembly.....	17	Removal and Installation.....	37	
Inspection — Caliper.....	17	TROUBLE DIAGNOSES	38	
Inspection — Rotor.....	17	Contents.....	38	IDX
Assembly.....	18	SERVICE DATA AND SPECIFICATIONS (SDS)	61	
Installation.....	18	General Specifications.....	61	
REAR DISC BRAKE	19	Inspection and Adjustment.....	62	
Pad Replacement.....	19			

PRECAUTIONS AND PREPARATION



Precautions


- Use brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- To clean or wash all parts of master cylinder, disc brake caliper and wheel cylinder, use clean brake fluid.
- Never use mineral oils such as gasoline or kerosene. They will ruin rubber parts of hydraulic system.
- Use flare nut wrench when removing and installing brake tube.
- Always torque brake lines when installing.

WARNING:


- Clean brake pads and shoes with a vacuum dust collector to minimize the hazard of airborne asbestos or other materials.

Preparation


SPECIAL SERVICE TOOL

Tool number (Kent-Moore No.) Tool name	Description
KV991V0010 (—) Brake fluid pressure gauge	 Measuring brake fluid pressure
	NT151

Commercial Service Tools

Tool name	Description
① Flare nut crows foot ② Torque wrench	
	NT223

CHECK AND ADJUSTMENT



Checking Brake Fluid Level

- Check fluid level in reservoir tank. It should be between Max. and Min. lines on reservoir tank.
- If fluid level is extremely low, check brake system for leaks.
- When brake warning lamp comes on even when parking brake lever is released, check brake system for leaks.

GI

Checking Brake Line

CAUTION:

If leakage occurs around joints, retighten or, if necessary, replace damaged parts.

WA

EM

1. Check brake lines (tubes and hoses) for cracks, deterioration or other damage. Replace any damaged parts.
2. Check for oil leakage by fully depressing brake pedal while engine is running.

LC

EF &
EC

Changing Brake Fluid

CAUTION:

- Refill with new brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.

FE

CL

1. Connect a vinyl tube to each air bleeder valve.
2. Drain brake fluid from each air bleeder valve by depressing brake pedal.
3. Refill until new brake fluid comes out of each air bleeder valve.

MT


AT

Use same procedure as in bleeding hydraulic system to refill brake fluid.

Refer to "Bleeding Brake System" shown below.

FA

RA



Bleeding Brake System

CAUTION:

- Carefully monitor brake fluid level at master cylinder during bleeding operation.
- If master cylinder is suspected to have air inside, bleed air from master cylinder first. Refer to "Installation" in "MASTER CYLINDER". (See page BR-10.)
- Fill reservoir with new brake fluid "DOT 3". Make sure it is full at all times while bleeding air out of system.
- Place a container under master cylinder to avoid spillage of brake fluid.

BR


ST

BF

HA

EL


IDX



CHECK AND ADJUSTMENT

Bleeding Brake System (Cont'd)

Models without ABS



1. Connect vinyl tube to air bleeder valve.
2. Fully depress brake pedal several times. While holding brake pedal in depressed position, loosen air bleeder valve of right rear wheel to bleed air, then quickly tighten air bleeder valve.
3. Tighten air bleeder valve to specified torque.

Specified torque:

7 - 9 N·m (0.7 - 0.9 kg-m, 5.1 - 6.5 ft-lb)

4. Bleed each wheel in the following sequence by repeating steps 1 to 3:

Left front caliper



Left rear wheel cylinder or caliper



Right front caliper

Models with ABS


1. Turn ignition switch OFF and disconnect ABS actuator connector.
2. Fill master cylinder reservoir tank with brake fluid. While replenishing brake fluid so that fluid level is always higher than middle of reservoir tank, bleed air using the same method as for models without ABS.

CAUTION:

- No air bleeder is provided on actuator.
- Do not loosen actuator connection during air bleeding.


BRAKE HYDRAULIC LINE/CONTROL VALVE

Without anti-lock braking system



SBR446A


With anti-lock braking system



SBR349B

GI
MA
EM
LC
EF &
EC
FE
CL
WT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

BRAKE HYDRAULIC LINE/CONTROL VALVE




REMOVAL

CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
 - All hoses must be free from excessive bending, twisting and pulling.
1. Connect a vinyl tube to air bleeder valve.
 2. Drain brake fluid from each air bleeder valve by depressing brake pedal.
 3. Remove flare nut securing brake tube to hose, then withdraw lock spring.
 4. Cover openings to prevent entrance of dirt whenever disconnecting hydraulic line.

INSPECTION

Check brake lines (tubes and hoses) for cracks, deterioration or other damage. Replace any damaged parts.



INSTALLATION

CAUTION:

- Refill with new brake fluid "DOT 3".
- Never reuse drained brake fluid.

1. Tighten all flare nuts and connecting bolts.

Specification:

Flare nut

15 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)

Connecting bolt

17 - 20 N·m (1.7 - 2.0 kg-m, 12 - 14 ft-lb)

2. Refill until new brake fluid comes out of each air bleeder valve.
3. Bleed air. Refer to "Bleeding Brake System". (See page BR-3.)

Proportioning Valve

INSPECTION

CAUTION:

- Carefully monitor brake fluid level at master cylinder.
 - Use new brake fluid "DOT 3".
 - Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on paint areas, wash it away with water immediately.
1. Connect Tool to air bleeders of front and rear brakes on either LH and RH side.
 2. Bleed air from the Tool.
 3. Check fluid pressure by depressing brake pedal.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR




ST

BF

HA

EL

IDX



Applied model	Without ABS			With ABS	
	GA16DE	SR20DE		Except SE model	SE model
		SR	SE		
Applied pressure (Front brake) kPa (kg/cm ² , psi)	7,355 (75, 1,067)	5,394 (55, 782)	6,865 (70, 995)	4,904 (50, 711)	6,375 (65, 924)
Output pressure (Rear brake) kPa (kg/cm ² , psi)	4,413 - 4,805 (45 - 49, 640 - 697)	2,452 - 2,844 (25 - 29, 356 - 412)	3,923 - 4,315 (40 - 44, 569 - 626)	1,961 - 2,354 (20 - 24, 284 - 341)	3,432 - 3,825 (35 - 39, 498 - 555)

If output pressure is out of specifications, replace dual proportioning valve (separated type) or master cylinder assembly (built into master cylinder type).

4. Bleed air after disconnecting the Tool. Refer to "Bleeding Brake System". (See page BR-3.)

REMOVAL AND INSTALLATION

CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
 - All hoses must be free from excessive bending, twisting and pulling.
1. Remove proportioning valve mounting bolt.
 2. Remove flare nut with wooden block placed between proportioning valve and dash panel.



Specification:

Flare nut

15 - 18 N·m (1.5 - 1.8 kg·m, 11 - 13 ft·lb)

BRAKE PEDAL AND BRACKET

Removal and Installation



Inspection

Check brake pedal for following items.

- Brake pedal bend
- Clevis pin deformation
- Crack of any welded portion

Adjustment

Check brake pedal free height from dash reinforcement panel. Adjust if necessary.

- H: Free height**
Refer to SDS. (See page BR-61.)
- D: Depressed height**
Refer to SDS.
Under force of 490 N (50 kg, 110 lb)
with engine running
- A: Pedal free play**
Refer to SDS.


1. Loosen lock nut and adjust pedal free height by turning brake booster input rod. Then tighten lock nut.
2. Check pedal free play.
3. Check brake pedal's depressed height while engine is running.

Make sure that stop lamps go off when pedal is released.

3. Check brake pedal's depressed height while engine is running.

If depressed height is below specified value, check brake system for leaks, accumulation of air or any damage to components (master cylinder, wheel cylinder, etc.); then make necessary repairs.

MASTER CYLINDER



Removal


CAUTION:

Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.


1. Connect a vinyl tube to air bleeder valve.
2. Drain brake fluid from each air bleeder valve, depressing brake pedal to empty fluid from master cylinder.
3. Remove brake pipe flare nuts.
4. Remove master cylinder mounting nuts.

Disassembly

1. Bend claws of stopper cap outward.



MASTER CYLINDER



Disassembly (Cont'd)

2. Remove valve stopper while piston is pushed into cylinder. (Models with ABS only)
3. Remove piston assemblies.

If it is difficult to remove secondary piston assembly, gradually apply compressed air through fluid outlet.

4. Draw out reservoir tank.

Inspection

Check for the following items.

Replace any part if damaged.

Master cylinder:

- Pin holes or scratches on inner wall.

Piston:




- Deformation of or scratches on piston cups.

Assembly

1. Insert secondary piston assembly. Then insert primary piston assembly.

- Pay attention to direction of piston cups in figure at left. Also, insert pistons squarely to avoid scratches on cylinder bore.

- Pay attention to alignment of secondary piston slit with valve stopper mounting hole of cylinder body (For models with ABS only).



2. Install stopper cap.

Before installing stopper cap, ensure that claws are bent inward.

3. Push reservoir tank seals.
4. Push reservoir tank into master cylinder.
5. Install valve stopper while piston is pushed into cylinder. (Models with ABS only)


Installation

CAUTION:

- Refill with new brake fluid "DOT 3".
- Never reuse drained brake fluid.


1. Place master cylinder onto brake booster and secure mounting nuts lightly.
2. Fit flare nuts to master cylinder.
3. Tighten mounting nuts.

: 8 - 11 N·m (0.8 - 1.1 kg-m, 5.8 - 8.0 ft-lb)



MASTER CYLINDER

Installation (Cont'd)



4. Fill up reservoir tank with new brake fluid.
5. Plug all ports on master cylinder with fingers in order not to have air sucked while releasing brake pedal.
6. Have driver depress brake pedal slowly several times until no air comes out of master cylinder.
7. Fit brake lines to master cylinder.
8. Tighten flare nuts.
Torque: 15 - 18 N·m (1.5 - 1.8 kg-m, 11 - 13 ft-lb)
9. Bleed air. Refer to "Bleeding Brake System". (See page BR-3.)

GF

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

IDX

BRAKE BOOSTER/VACUUM HOSE



SBR002A

Brake Booster


ON-VEHICLE SERVICE

Operating check


- Depress brake pedal several times with engine off, and check that there is no change in pedal stroke.
- Depress brake pedal, then start engine. If pedal goes down slightly, operation is normal.

Airtight check

- Start engine, and stop it after one or two minutes. Depress brake pedal several times slowly. If pedal goes further down the first time and gradually rises after second or third time, booster is airtight.
- Depress brake pedal while engine is running, and stop engine with pedal depressed. If there is no change in pedal stroke after holding pedal down **30 seconds**, brake booster is airtight.



SBR365AA



SBR232C

REMOVAL

CAUTION:

- Be careful not to splash brake fluid on painted areas; it may cause paint damage. If brake fluid is splashed on painted areas, wash it away with water immediately.
- Be careful not to deform or bend brake pipes, during removal of booster.

INSPECTION

Output rod length check

1. Apply vacuum of -66.7 kPa (-500 mmHg , -19.69 inHg) to brake booster with a handy vacuum pump.
2. Check output rod length.


Specified length:

M20

4.875 - 5.125 mm (0.1919 - 0.2018 in)

M165T, M195T

10.275 - 10.525 mm (0.4045 - 0.4144 in)




SBR281A

INSTALLATION

CAUTION:

- Be careful not to deform or bend brake pipes, during installation of booster.
- Replace clevis pin if damaged.
- Refill with new brake fluid "DOT 3".
- Never reuse drained brake fluid.
- Take care not to damage brake booster mounting bolt thread when installing. Due to the acute angle of installation, the threads can be damaged on the metal surrounding the dash panel holes.



SBR116B

BRAKE BOOSTER/VACUUM HOSE

Brake Booster (Cont'd)

1. Before fitting booster, temporarily adjust clevis to dimension shown.
2. Fit booster, then secure mounting nuts (brake pedal bracket to master cylinder) lightly.
3. Connect brake pedal and booster input rod with clevis pin.
4. Secure mounting nuts.

Specification: 13 - 16 N·m (1.3 - 1.6 kg·m, 9 - 12 ft·lb)

5. Install master cylinder. Refer to "Installation" in "MASTER CYLINDER". (See page BR-10.)
6. Bleed air. Refer to "Bleeding Brake System". (See page BR-3.)

GI

MA

FM

LC

EF & EC

FE

CL

MT

AT

FA

RA

BR



ST

BF

HA

EL

IDX



Vacuum Hose

REMOVAL AND INSTALLATION

CAUTION:

When installing vacuum hoses, pay attention to the following points.

- Do not apply any oil or lubricants to vacuum hose and check valve.
- Insert vacuum tube into vacuum hose as shown.
- Install check valve, paying attention to its direction.


INSPECTION

Hoses and connectors

Check vacuum lines, connections and check valve for airtightness, improper attachment chafing and deterioration.

Check valve

Check vacuum with a vacuum pump.



Connect to booster side	Vacuum should exist.
Connect to engine side	Vacuum should not exist.


Pad Replacement

WARNING:


Clean brake pads with a vacuum dust collector to minimize the hazard of airborne asbestos or other materials.

CAUTION:

- When cylinder body is open, do not depress brake pedal because piston will pop out.
- Be careful not to damage piston boot or get oil on rotor. Always replace shims when replacing pads.
- If shims are rusted or show peeling of the rubber coat, replace them with new shims.
- It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend cylinder body with wire so as not to stretch brake hose.



1. Remove master cylinder reservoir cap.
2. Remove pin bolt.



3. Open cylinder body upward. Then remove pad retainers, and inner and outer shims.


Standard pad thickness: 10 mm (0.39 in)

Pad wear limit: 2.0 mm (0.079 in)

Carefully monitor brake fluid level because brake fluid will return to reservoir when pushing back piston.

FRONT DISC BRAKE

CL18VD




SBR233CA

- | | | |
|-----------------------------|-------------------|-----------------|
| ① Main pin | ⑦ Inner pad | ⑬ Main pin bolt |
| ② Pin boot | ⑧ Pad retainer | ⑭ Bleed valve |
| ③ Torque member fixing bolt | ⑨ Outer pad | ⑮ Cylinder body |
| ④ Torque member | ⑩ Outer shim | ⑯ Piston seal |
| ⑤ Shim cover | ⑪ Connecting bolt | ⑰ Piston |
| ⑥ Inner shim | ⑫ Copper washer | ⑱ Piston boot |

GI
MA
EM
LC
EF &
EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

FRONT DISC BRAKE


AD18VE



SBR351BA

- | | | |
|-----------------------------|-------------------|------------------------|
| ① Pin boot | ⑧ Pad retainer | ⑮ Cylinder body |
| ② Torque member fixing bolt | ⑨ Outer pad | ⑯ Piston seal |
| ③ Torque member | ⑩ Outer shim | ⑰ Piston |
| ④ Plug | ⑪ Connecting bolt | ⑱ Piston boot |
| ⑤ Shim cover | ⑫ Copper washer | ⑲ Piston boot retainer |
| ⑥ Inner shim | ⑬ Sliding pin | ⑳ Brake hose |
| ⑦ Inner pad | ⑭ Air bleeder | |

FRONT DISC BRAKE



Removal

WARNING:


Clean brake pads with a vacuum dust collector to minimize the hazard of airborne asbestos or other materials.

Remove torque member fixing bolts and connecting bolt.

It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend caliper assembly with wire so as not to stretch brake hose.

Disassembly

1. Remove piston boot retainer with a screwdriver. (AD18VE model only)




WARNING:

Do not place your fingers in front of piston.

CAUTION:

Do not scratch or score cylinder wall.

2. Push out piston with dust seal with compressed air.
3. Remove piston seal with a suitable tool.



Inspection — Caliper

CYLINDER BODY

- Check inside surface of cylinder for score, rust, wear, damage or presence of foreign materials. If any of the above conditions are observed, replace cylinder body.
- Minor damage from rust or foreign materials may be eliminated by polishing surface with a fine emery paper. Replace cylinder body if necessary.

CAUTION:

Use brake fluid to clean. Never use mineral oil.

PISTON


Check piston for score, rust, wear, damage or presence of foreign materials. Replace if any of the above conditions are observed.

CAUTION:

Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign materials are stuck to sliding surface.

SLIDE PIN, PIN BOLT AND PIN BOOT

Check for wear, cracks or other damage. Replace if any of the above conditions are observed.



Inspection — Rotor

RUNOUT

1. Secure rotor to wheel hub with at least two nuts (M12 x 1.25).
2. Check runout using a dial indicator.

Make sure that wheel bearing axial end play is within the specifications before measuring. Refer to "Front Wheel Bearing" in FA section.

Maximum runout:

0.07 mm (0.0028 in)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

DX

FRONT DISC BRAKE

Inspection — Rotor (Cont'd)

3. If the runout is out of specification, find minimum runout position as follows:
 - a. Remove nuts and rotor from wheel hub.
 - b. Shift the rotor one hole and secure rotor to wheel hub with nuts.
 - c. Measure runout.
 - d. Repeat steps a. to c. so that minimum runout position can be found.
4. If the runout is still out of specification, turn rotor with on-car brake lathe ("MAD, DL-8700", "AMMCO 700 and 705" or equivalent).

THICKNESS

Thickness variation (At least 8 positions):


Maximum 0.01 mm (0.0004 in)

If thickness variation exceeds the specification, turn rotor with on-car brake lathe.

Rotor repair limit:


Minimum thickness

CL18VD, AD18VE 16.0 mm (0.630 in)



Assembly

1. With piston boot fitted to piston, insert piston boot into groove on cylinder body and install piston.
2. Properly secure piston boot
3. Secure piston boot with retainer.
(AD18VE model only)







Installation

CAUTION:

- Refill with new brake fluid "DOT 3".
 - Never reuse drained brake fluid.
1. Install brake hose to caliper securely.
 2. Install all parts and secure all bolts.
 3. Bleed air. Refer to "Bleeding Brake System" in "CHECK AND ADJUSTMENT". (See page BR-3.)

REAR DISC BRAKE



Pad Replacement

WARNING:

Clean brake pads with a vacuum dust collector to minimize the hazard of airborne asbestos or other materials.

CAUTION:

- When cylinder body is open, do not depress brake pedal, otherwise piston will pop out.
- Be careful not to damage piston boot or let oil get on rotor. Always replace shims in replacing pads.
- If shims are rusted or show peeling of rubber coat, replace them with new shims.
- It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend cylinder body with wire so as not to stretch brake hose.

1. Remove master cylinder reservoir cap.
2. Remove brake cable lock spring.
3. Disconnect cable.
4. Remove pin bolt.

5. Open cylinder body upward. Then remove pad retainers, and inner and outer shims.

Standard pad thickness:

10 mm (0.39 in)

Pad wear limit:

2.0 mm (0.079 in)

6. When installing new pads, push piston into cylinder body by turning piston clockwise.

Carefully monitor brake fluid level because brake fluid will return to reservoir when pushing back piston.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL

IDX

REAR DISC BRAKE

AD7HA








- R** : Rubber grease point
- B** : Brake fluid point
- : N·m (kg·m, ft·lb)
- P** : PBC (Poly Butyl Cuprysil) grease or silicone-based grease point

SBR212BA

- | | | |
|-------------------|----------------|------------------------|
| ① Washer | ⑪ Strut | ⑳ Piston boot |
| ② Spring | ⑫ O-ring | ㉑ Piston boot retainer |
| ③ Toggle lever | ⑬ Push rod | ㉒ Inner shim |
| ④ Cam | ⑭ Key plate | ㉓ Inner pad |
| ⑤ Return spring | ⑮ Spring | ㉔ Outer pad |
| ⑥ Cable guide | ⑯ Spring cover | ㉕ Outer shim |
| ⑦ Connecting bolt | ⑰ Snap ring | ㉖ Torque member |
| ⑧ Copper washer | ⑱ Piston seal | ㉗ Retainer spring |
| ⑨ Bleed screw | ㉀ Piston | ㉘ Side pin |
| ⑩ Cylinder | | |

REAR DISC BRAKE



Removal

WARNING:

Clean brake pads with a vacuum dust collector to minimize the hazard of airborne asbestos or other materials.

1. Remove brake cable mounting bracket bolt and lock spring.
2. Remove torque member fixing bolts and connecting bolt.

It is not necessary to remove connecting bolt except for disassembly or replacement of caliper assembly. In this case, suspend caliper assembly with wire so as not to stretch brake hose.

Disassembly

1. Remove piston by turning it counterclockwise with suitable long nose pliers.

2. Remove piston boot retainer with a suitable tool and remove piston boot.

3. Disassemble cylinder body.

- a. Pry off snap ring with suitable pliers, then remove spring cover, spring, key plate, push rod and strut.

- b. Remove piston seal.

Be careful not to damage cylinder body.

4. Remove return spring and toggle lever.

Inspection — Caliper

CAUTION:

Use brake fluid to clean cylinder. Never use mineral oil.

CYLINDER BODY

- Check inside surface of cylinder for score, rust, wear, damage or presence of foreign materials. If any of the above conditions are observed, replace cylinder body.
- Minor damage from rust or foreign materials may be eliminated by polishing surface with a fine emery paper. Replace cylinder body if necessary.

PISTON

Check piston for score, rust, wear, damage or presence of foreign materials.

Replace if any of the above conditions are observed.

CAUTION:

Piston sliding surface is plated. Do not polish with emery paper even if rust or foreign matter is stuck to sliding surface.

PIN AND PIN BOOT

Check for wear, cracks or other damage.

Replace if any of the above conditions are observed.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

IDX

REAR DISC BRAKE



Inspection — Rotor

RUBBING SURFACE

Check rotor for roughness, cracks or chips.

RUNOUT

1. Secure rotor to wheel hub with at least two nuts (M12 x 1.25).
2. Check runout using a dial indicator.

Make sure that wheel bearing axial end play is within the specifications before measuring. Refer to "Wheel Bearing" in RA section.

3. Change relative positions of rotor and wheel hub so that runout is minimized.

Maximum runout: 0.07 mm (0.0028 in)

THICKNESS


Rotor repair limit:

Minimum thickness 6.0 mm (0.236 in)


Replace rotor if any of the above did not meet the specifications.

Assembly


1. Insert cam with depression facing towards open end of cylinder.




2. Generously apply rubber grease to strut and push rod to make insertion easy.



3. Match depressions in cylinder bottom with key plate protrusions.




4. Install spring, spring cover and snap ring with a suitable tool.




REAR DISC BRAKE

Assembly (Cont'd)



5. Fit piston by turning it clockwise with suitable long nose pliers.



6. Fit toggle lever and return spring.

Installation

CAUTION:

- Refill with new brake fluid "DOT 3".
 - Never reuse drained brake fluid.
1. Install brake hose to caliper securely.
 2. Install all parts and secure all bolts.
 3. Bleed air. Refer to "Bleeding Brake System" in "CHECK AND ADJUSTMENT". (See page BR-3.)

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

IDX

REAR DRUM BRAKE




Removal

WARNING:

Clean brake lining with a vacuum dust collector to minimize the hazard of airborne asbestos or other materials.

CAUTION:

Make sure parking brake lever is released completely.



1. Release parking brake lever fully, then remove drum.






If drum is hard to remove, the following procedures should be carried out.

a. Remove plug. Then shorten adjuster to make clearance between brake shoe and drum as shown.

REAR DRUM BRAKE

Removal (Cont'd)

b. Tighten the two bolts gradually.



2. After removing retainer, remove spring by rotating shoes. **Be careful not to damage parking brake cable when separating it.**
3. Remove adjuster.
4. Disconnect parking brake cable from toggle lever.
5. Remove retainer ring with a suitable tool. Then separate toggle lever and brake shoe.

Inspection — Wheel Cylinder

- Check wheel cylinder for leakage.
- Check for wear, damage and loose conditions. Replace if any such condition exists.

Wheel Cylinder Overhaul

Pay attention so as not to scratch cylinder when installing pistons.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST


BF

HA

EL

IDX

REAR DRUM BRAKE




Inspection — Drum

Standard inner diameter: 180 mm (7.09 in)

Maximum inner diameter: 181 mm (7.13 in)

Out-of-roundness: 0.03 mm (0.0012 in) or less

- Contact surface should be fine finished with No. 120 to 150 emery paper.
- Using a drum lathe, lathe brake drum if it shows scoring, partial wear or stepped wear.
- After brake drum has been completely reconditioned or replaced, check drum and shoes for proper contact pattern.



Inspection — Lining

Check lining thickness.



Standard lining thickness: 4 mm (0.16 in)

Lining wear limit: 1.5 mm (0.059 in)

Installation

Always perform shoe clearance adjustment. Refer to "Adjustment" in "PARKING BRAKE CONTROL" (BR-27).

1. Fit operating lever to brake trailing shoe with retainer ring.
2. Apply brake grease to the contact areas shown at left.




3. Shorten adjuster by rotating it.

● **Pay attention to direction of adjuster.**

● **Adjuster for left-hand brake has a depression. Adjuster for right-hand brake does not have a depression.**

4. Connect parking brake cable to toggle lever.
5. Install all parts.




6. Check all parts are installed properly.

Pay attention to direction of adjuster.


7. Install brake drum.

8. When installing new wheel cylinder or overhauling wheel cylinder, bleed air. Refer to "Bleeding Brake System" in "CHECK AND ADJUSTMENT". (See page BR-3.)

PARKING BRAKE CONTROL



GI
MA
EM
LC
EF &
EC
FE
CL



Removal and Installation

1. To remove parking brake cable, first remove center console.
2. Disconnect warning lamp connector.
3. Remove bolts, slacken off and remove adjusting nut.
4. Remove lock plate and disconnect cable (disc brake only). For drum brake models, refer to "Removal" in "REAR DRUM BRAKE". (See page BR-24.)

MT
AT
FA

Inspection

1. Check control lever for wear or other damage. Replace if necessary.
2. Check wires for discontinuity or deterioration. Replace if necessary.
3. Check warning lamp and switch. Replace if necessary.
4. Check parts at each connecting portion and, if found deformed or damaged, replace.

RA
BR
ST

Adjustment

Before adjustment, pay attention to the following points.

1. Loosen parking brake cable.
2. Depress brake pedal fully more than 5 times to adjust clearance between brake pad and rotor/brake shoes and drum automatically.
3. Pull control lever 4 - 5 notches. Then adjust control lever by turning adjusting nut.
4. Pull control lever with specified amount of force. Check lever stroke and ensure smooth operation.


BF
HA
EL

**Number of notches: Drum brake 5 - 6
Disc brake 7 - 8**

5. Bend parking brake warning lamp switch plate so that brake warning lamp comes on when ratchet at parking brake control lever is pulled "A" notches and goes out when fully released.

Number of "A" notches : 1

IDX



ANTI-LOCK BRAKE SYSTEM

Purpose

- Excessive braking in any condition (Dry or wet) will adversely affect the normal turning of the vehicle's wheels and they may lock up.
- When the front wheels are locked, a vehicle cannot be controlled by the steering system.
- When the rear wheels are locked, the vehicle will enter a flat spin.

The ABS, by the use of electronic and hydraulic components, allows for control of braking force so that locking of the wheels can be avoided in the circumstances described above.

The ABS:

- 1) Ensures proper tracking performance through steering wheel operation.
- 2) Enables obstacles to be avoided through steering wheel operation.
- 3) Ensures vehicle stability by preventing flat spins.

Operation

The ABS is controlled by control unit (CU), which receives signals from various sensors relating to vehicle condition, speed, etc.

The hydraulic circuit is controlled by an actuator containing an electric motor, pump and 2 solenoids. The control unit directs the actuator to increase, hold or decrease hydraulic pressure to all or individual wheels.

The control unit receives information regarding wheel speed from sensors, mounted one per wheel.

When excessive braking force causes a wheel to lock, the control unit sends a 5 amp current to the actuator to release the locked wheel.

As the wheel unlocks, it can be steered. The control unit senses wheel speed is increasing and re-applies hydraulic pressure. The wheel locks again, is released, steered, braked, and so on. This continuous locking and unlocking of the wheels allows for rapid speed reduction and the vehicle to be steered in the correct manner.


The hydraulic pressure can also be "held" constant by a 2 amp current sent from the control unit to the actuator.

The rear wheels utilize a load-sensing valve to further prevent wheel locking, especially under minimum vehicle load conditions.

However, when the vehicle speed is less than 10 km/h (6MPH), this system does not work.

ANTI-LOCK BRAKE SYSTEM

Operation (Cont'd)





$$\text{SLIP RATIO} = \frac{\text{VEHICLE SPEED} - \text{WHEEL SPEED}}{\text{VEHICLE SPEED}}$$

- The applied brake condition is expressed by a slip ratio, as shown above. If the slip ratio is in the range from 0.15 to 0.3, the wheel has adequate cornering performance, and also minimum stopping distance can be achieved.
- The slip ratio formula indicates the control of wheel speed by the brakes. The Anti-lock Brake System (ABS) controls brake fluid pressure using the slip ratios and locking condition calculation contained in the ABS control unit.
- To adjust wheel speed so that the optimum slip ratio can be obtained, the ABS must sense wheel speed and vehicle speed through a wheel speed sensor. If the brake is applied, especially in the locked wheel condition, the vehicle speed differs from the wheel speed.
- After the wheel speed changes from the vehicle speed due to excessive brake force, the ABS calculates vehicle speed when the reduced wheel speed reaches the minimum.

ANTI-LOCK BRAKE SYSTEM

System Components





System Description

SENSOR

The sensor unit consists of a gear-shaped rotor and a sensor element which contains a bar magnet around which a coil is wound. The sensor is installed on the back side of the brake rotor. Sine-wave current is generated by the sensor as the wheel rotates. The frequency and voltage increase(s) as the rotating speed increases.

CONTROL UNIT


The control unit computes the rotating speed of the wheel by the signal current sent from the sensor, and supplies a DC current of about 5 amperes, about 2 amperes, or 0 amperes to the actuator solenoid valve provided for each wheel by changing its internal resistance. It also controls ON-OFF operation of the valve relay and pump relay. If any electrically detectable malfunction should occur in the system, the control unit causes the warning light to light up, and the LED indicator to flash the number of times which corresponds to the malfunction location. In this condition, the ABS will be deactivated by the control unit, and the vehicle's braking system reverts to normal operation.



ANTI-LOCK BRAKE SYSTEM

System Description (Cont'd)

CONTROL UNIT CONTROL CHART




GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

ANTI-LOCK BRAKE SYSTEM

System Description (Cont'd)


ACTUATOR



The actuator consists of solenoid valves, a pump, reservoir (for pressure decreasing). The solenoid valve changes its spool position corresponding to the control unit output amperage: it forms a pressure decreasing circuit at about 5 amperes, a pressure holding circuit at about 2 amperes, and a pressure increasing circuit at 0 amperes. When the pressure decreasing circuit is formed, the brake fluid in the caliper flows into the reservoir and the pressure drops. The pump delivers the fluid to the master cylinder. When the pressure holding circuit is formed, the caliper line is cut off, and the fluid pressure in the caliper is held constant.

ANTI-LOCK BRAKE SYSTEM

Circuit Diagram



GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF


HA

EL


IDX

ANTI-LOCK BRAKE SYSTEM

Wiring Diagram



ANTI-LOCK BRAKE SYSTEM




Removal and Installation


CAUTION:

Be careful not to damage sensor edge and sensor rotor teeth. In case the front or rear wheel hub assembly needs to be removed, disconnect the ABS wheel sensor from the assembly and move it away. Failure to do so may result in damage to the sensor wires making the sensor inoperative.

FRONT WHEEL SENSOR




REAR WHEEL SENSOR



CONTROL UNIT

Location: Front passenger side dash side lower.





Removal ACTUATOR



GI
MA
EM
LC
EF & EC
FE
CL
MT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

ANTI-LOCK BRAKE SYSTEM


Removal (Cont'd)





1. Disconnect battery cable.
2. Drain brake fluid. Refer to "Changing Brake Fluid" in "CHECK AND ADJUSTMENT". (See page BR-3.)
3. Drain power steering fluid. Refer to section ST.
4. Discharge air conditioner refrigerant. Refer to section HA.
5. Disconnect power steering fluid pipe and hose.
6. Disconnect all connectors from actuator relay bracket.
7. Remove mounting nut for relay bracket.
8. Remove mounting bolt for relay bracket. (This bolt is located just under the relay.)
9. Remove actuator relay box with bracket.
10. Remove air conditioner tubes.
11. Disconnect top two brake pipes from actuator. (Pipes from master cylinder to actuator)
It is not necessary to remove these pipes.
12. Remove the other two brake pipes. (Pipes from actuator to DP valve)

ANTI-LOCK BRAKE SYSTEM

Removal (Cont'd)



13. Remove/loosen mounting nuts between actuator and bracket.
14. Remove actuator grounding bolt.





15. Draw out actuator as shown.

Installation

CAUTION:

After installation, pay attention to the following points.

- Refill brake fluid and bleed air. Refer to "CHECK AND ADJUSTMENT". (See page BR-3.)
- Charge air conditioner refrigerant. Refer to "Charging Refrigerant" in HA section.
- Refill power steering fluid and bleed air. Refer to "Bleeding Hydraulic System" in ST section.
- Installation procedure is basically the reverse order of removal.
- It is recommended to install relay bracket first. Then install actuator relay box.



Removal and Installation

ACTUATOR RELAYS

METAL BODY: MOTOR RELAY

LIGHT BLUE: SOLENOID VALVE RELAY

1. Disconnect battery cable.
2. Remove actuator relay cover.

It is not necessary to remove the two screws for relay box.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA



EL

IDX

TROUBLE DIAGNOSES

Contents

How to Perform Trouble Diagnoses for Quick and Accurate Repair	BR-39
Symptom Chart	BR-42
Preliminary Check	BR-43
Self-diagnosis	BR-44
Component Parts and Harness Connector Location	BR-45
Ground Circuit Check	BR-47
Circuit Diagram for Quick Pinpoint Check	BR-47
Diagnostic Procedure 1 — Pedal vibration and noise	BR-48
Diagnostic Procedure 2 — Long stopping distance	BR-50
Diagnostic Procedure 3 — Unexpected pedal action	BR-50
Diagnostic Procedure 4 — ABS does not work	BR-51
Diagnostic Procedure 5 — ABS works but warning activates	BR-51
Diagnostic Procedure 6 — ABS works frequently	BR-51
Diagnostic Procedure 7 — Warning never activates	BR-52
Diagnostic Procedure 8 — ACTUATOR SOLENOID (LED flashing number 1 - 3)	BR-53
Diagnostic Procedure 9 — WHEEL SPEED SENSOR (LED flashing number 5 - 8)	BR-54
Diagnostic Procedure 10 — ACTUATOR MOTOR RELAY (LED flashing number 9)	BR-55
Diagnostic Procedure 11 — ACTUATOR SOLENOID VALVE RELAY (LED flashing number 10)	BR-57
Diagnostic Procedure 12 — SENSOR AND SENSOR ROTOR (LED flashing number 15)	BR-58
Diagnostic Procedure 13 — CONTROL UNIT (LED flashing number 16)	BR-58
Diagnostic Procedure 14 — CONTROL UNIT OR POWER SUPPLY AND GROUND CIRCUIT (Warning activates but LED comes off)	BR-59
Electrical Components Inspection	BR-60



How to Perform Trouble Diagnoses for Quick and Accurate Repair

INTRODUCTION

The ABS system has an electronic control unit to control major functions. The control unit accepts input signals from sensors and instantly drives actuators. It is essential that both kinds of signals are proper and stable. At the same time, it is important that there are no conventional problems such as air leaks in the booster or lines, lack of brake fluid, or other problems with brake system.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or faulty wiring. In this case, careful checking of suspicious circuits may help prevent the replacement of good parts.

A visual check only may not find the cause of the problems, so a road test should be carried out.

Before undertaking actual checks, take just a few minutes to talk with a customer who approaches with a ABS complaint. The customer is a very good source of information on such problems; especially intermittent ones. Through the talks with the customer, find out what symptoms are present and under what conditions they occur.

Start your diagnosis by looking for "conventional" problems first. This is one of the best ways to troubleshoot brake problems on an ABS controlled vehicle.

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

IDX

TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

WORK FLOW



TROUBLE DIAGNOSES

How to Perform Trouble Diagnoses for Quick and Accurate Repair (Cont'd)

KEY POINTS

- WHAT** Vehicle model
WHEN Date, Frequencies
WHERE Road conditions
HOW Operating conditions,
 Weather conditions,
 Symptoms

SBR339B

DIAGNOSTIC WORKSHEET

There are many kinds of operating conditions that lead to customer complaints, even if the system is normal.

A good grasp of such conditions can make trouble-shooting faster and more accurate.

In general, feelings for a problem depend on each customer's information. It is therefore important to fully understand the symptoms or under what conditions a customer complains.

Make good use of a diagnostic worksheet such as the one shown below in order to utilize all the complaints for trouble-shooting.

Worksheet sample


Customer name MR/MS		Model & Year			VIN		
Engine #		Trans.			Mileage		
Incident Date		Manuf. Date			In Service Date		
Symptoms	<input type="checkbox"/> Pedal vibration and noise	<input type="checkbox"/> Warning activates	<input type="checkbox"/> Long stopping distance	<input type="checkbox"/> Unexpected pedal action	<input type="checkbox"/> ABS doesn't work	<input type="checkbox"/> ABS works but warning activates	<input checked="" type="checkbox"/> ABS works frequently
Engine conditions		<input type="checkbox"/> When starting <input type="checkbox"/> After starting <input type="checkbox"/> Engine speed: 5,000 rpm or more					
Road conditions		<input type="checkbox"/> Low friction road (<input type="checkbox"/> Snow <input type="checkbox"/> Gravel <input type="checkbox"/> Other) <input type="checkbox"/> Protrusion					
Driving conditions		<input type="checkbox"/> High speed cornering <input type="checkbox"/> Vehicle speed: Greater than 10 km/h (6 MPH) <input type="checkbox"/> Vehicle speed: 10 km/h (6 MPH) or less <input type="checkbox"/> Vehicle is stopped					
Applying brake conditions		<input type="checkbox"/> Suddenly <input type="checkbox"/> Gradually					
Other conditions		<input type="checkbox"/> Operation of electrical equipment <input type="checkbox"/> Large pedal stroke <input type="checkbox"/> Operation of clutch					

TROUBLE DIAGNOSES

Symptom Chart

PROCEDURE			Diagnostic Procedure								Diagnostic Procedure (Select inspection with LED flashing No.)								Elec- trical Compo- nents Inspec- tion	
REFERENCE PAGE	BR-43	BR-44	BR-48	BR-50	BR-50	BR-51	BR-51	BR-51	BR-52	BR-53	BR-54	BR-55	BR-57	BR-58	BR-58	BR-59	BR-47	BR-60	BR-60	
SYMPTOM	Preliminary Check	Self-diagnosis	Diagnostic Procedure 1	Diagnostic Procedure 2	Diagnostic Procedure 3	Diagnostic Procedure 4	Diagnostic Procedure 5	Diagnostic Procedure 6	Diagnostic Procedure 7	Diagnostic Procedure 8 (LED flashing No. 1 - 3)	Diagnostic Procedure 9 (LED flashing No. 5 - 8)	Diagnostic Procedure 10 (LED flashing No. 9)	Diagnostic Procedure 11 (LED flashing No. 10)	Diagnostic Procedure 12 (LED flashing No. 15)	Diagnostic Procedure 13 (LED flashing No. 16)	Diagnostic Procedure 14 (LED comes off)	Ground Circuit Check	Actuator Motor Relay	Solenoid Valve Relay	
Pedal vibration & noise		<input type="radio"/>	<input type="radio"/>							<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			
Warning activates		<input type="radio"/>								<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			
Long stopping distance	<input type="radio"/>	<input type="radio"/>		<input type="radio"/>						<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			
Unexpected pedal action	<input type="radio"/>	<input type="radio"/>			<input type="radio"/>					<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			
ABS doesn't work		<input type="radio"/>				<input type="radio"/>				<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>
ABS works but warning activates		<input type="radio"/>					<input type="radio"/>			<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>	<input type="radio"/>			<input type="radio"/>
ABS works frequently	<input type="radio"/>	<input type="radio"/>						<input type="radio"/>						<input type="radio"/>			<input type="radio"/>			<input type="radio"/>
Warning never activates		<input type="radio"/>				<input type="radio"/>			<input type="radio"/>								<input type="radio"/>			<input type="radio"/>


TROUBLE DIAGNOSES




Preliminary Check

A
 Check brake fluid level in reservoir tank.
 Low fluid level may indicate brake pad wear or leakage from brake line.

B
 Check brake line for leakage. NG → Repair.
 OK →




C
 Check brake booster for operation and air tightness.
 Refer to "On-vehicle Service" of BRAKE BOOSTER (BR-12). NG → Replace.
 OK →



D
 Check brake pads and rotor.
 Refer to "Inspection" of FRONT and REAR DISC BRAKES (BR-14, 17, 19, 22). NG → Replace.
 OK →

A
 Check brake fluid level in reservoir tank. NG → Fill up brake fluid.
 OK →



END

GI
 MA
 EM
 LC
 EF & EC
 FE
 CL
 WT
 AT
 FA
 RA
BR
 ST
 BF
 HA
 EL
 IDX

TROUBLE DIAGNOSES

Self-diagnosis

CHECKING THE NUMBER OF LED FLASHES

When a problem occurs in the ABS, the warning light on the instrument panel comes on. As shown in the Table, the control unit performs self-diagnosis.

To obtain satisfactory self-diagnosing results, the vehicle must be driven above 30 km/h (19 MPH) for at least one minute before the self-diagnosis is performed. After the vehicle is stopped, the number of LED flashes is counted while the engine is running.


The LED is located on the control unit, identifying a malfunctioning part or unit by the number of flashes. Both the warning light and the LED persistently activate, even after a malfunctioning part or unit has been repaired, unless the ignition switch is turned "OFF". After repairs, turn the ignition switch "OFF". Then start the engine and drive the vehicle over 30 km/h (19 MPH) for at least one minute to ensure that the malfunctioning part or unit has been repaired properly.

If more than two circuits malfunction at the same time, the LED will flash to indicate one of the malfunctioning circuits. After the circuit has been repaired, the LED will then flash to indicate that the other circuit is malfunctioning.

No. of LED flashes	Malfunctioning parts or circuit	Diagnostic Procedure
1	Left front actuator solenoid circuit	8
2	Right front actuator solenoid circuit	8
3	Both actuator solenoid circuits	8
5	Left front wheel sensor circuit	9
6	Right front wheel sensor circuit	9
7	Right rear wheel sensor circuit	9
8	Left rear wheel sensor circuit	9
9	Motor and motor relay	10
10	Solenoid valve relay	11
15	Sensor rotor	12
*16	Solenoid valve relay or control unit	13
Warning activates and LED "OFF"	Power supply and ground circuit	14

Example


Improper operation of left front rotor sensor circuit



SBR531AA

* Turn off the engine, and start it again by slowly turning the ignition key (quickly doing so may cause the ABS warning light to stay on when there is nothing wrong). If the light stays on, carry out the diagnostic procedure.


Component Parts and Harness Connector Location




GI
 MA
 EM
 LC
 EF &
 EC
 FE
 CL
 MT
 AT
 FA
 RA
BR
 ST
 BF
 HA
 EL
 IDX

TROUBLE DIAGNOSES

Component Parts and Harness Connector Location (Cont'd)



TROUBLE DIAGNOSES



Ground Circuit Check


CONTROL UNIT GROUND CIRCUIT

- Check continuity between control unit connector terminal 10 and ground.

Continuity should exist.

Circuit Diagram for Quick Pinpoint Check





- The unit side connectors with a double circle "⊖" are connected to the harness side connectors shown in the "Component Parts and Harness Connector Location". (See page BR-45.)
- The terminal numbers in the connector coincide with the circuit numbers surrounded by a single circle "○".



Diagnostic Procedure 1


SYMPTOM: Pedal vibration and noise

Refer to worksheet result. (See page BR-41.)



TROUBLE DIAGNOSES

Diagnostic Procedure 1 (Cont'd)



GI

MA

EM

LG

EF &
EC

FE

CL

MT

AT

FA

RA

BR


ST

BF

HA

EL




IOX



Diagnostic Procedure 2

SYMPTOM: Long stopping distance



Refer to worksheet results. (See page BR-41.)



Diagnostic Procedure 3

SYMPTOM: Unexpected pedal action


Refer to worksheet results.



Diagnostic Procedure 4



SYMPTOM: ABS does not work.

Refer to worksheet results. (See page BR-41.)




Diagnostic Procedure 5

SYMPTOM: ABS works but warning activates.



Diagnostic Procedure 6





SYMPTOM: ABS works frequently.



TROUBLE DIAGNOSES




Diagnostic Procedure 7

SYMPTOM: Warning never activates.



Diagnostic Procedure 8

ACTUATOR SOLENOID (LED flashing number 1 - 3)



INSPECTION START
Remove battery negative terminal connector.

A

CHECK SOLENOID VALVE RESISTANCE.
Check resistance between control unit connector (vehicle side) terminals shown below.
Flashing number 1: ③③ and ②
Flashing number 2: ③③ and ⑱
Flashing number 3: ③③ and ②, ③③ and ⑱
Resistance: Approx. 3Ω

OK → Replace control unit.

B

Check resistance between actuator relay connector terminals shown below.
Flashing number 1: ⑥ and ①
Flashing number 2: ⑥ and ②
Flashing number 3: ⑥ and ①, ⑥ and ②
Resistance: Approx. 3Ω

OK → Repair harness between actuator relay connector and control unit connector.

C

Check resistance between actuator relay connector terminals shown below.
Flashing number 1: ⑪ and ⑭
Flashing number 2: ⑫ and ⑬
Flashing number 3: ⑪ and ⑭, ⑫ and ⑬
Resistance: Approx. 3Ω





OK → Replace actuator relay assembly.

NG → Replace actuator.

GI
MA
EM
LC
EF & EC
FE
CL
WT
AT
FA
RA
BR
ST
BF
HA
EL
IDX

Diagnostic Procedure 9

WHEEL SPEED SENSOR (LED flashing number 5 - 8)



INSPECTION START
Remove battery negative terminal connector.

A

CHECK SPEED SENSOR RESISTANCE. Check resistance between control unit connector (vehicle side) terminals as shown.

Flashing number 5 (Fr. LH): ④ and ⑤
Flashing number 6 (Fr. RH): ⑪ and ⑰
Flashing number 7 (Rr. RH): ⑳ and ㉔
Flashing number 8 (Rr. LH): ⑧ and ⑨

Resistance: 0.8 - 1.3 kΩ

B

Check resistance for sensor.
Resistance: 0.8 - 1.3 kΩ
(For location of sensor connector, refer to BR-45.)

Repair harness between sensor connector and control unit connector.

Note

WHEEL SENSOR MECHANICAL CHECK

Check for inflation pressure, wear and size of each tire.

Note

Check wheel bearing axial end play. Refer to FA or RA section ("Front/Rear Wheel Bearing", "ON-VEHICLE SERVICE").

C

Note

Check clearance between sensor and rotor.
Clearance: 0.1 - 1.1 mm (0.004 - 0.043 in)

Note

Check sensor rotor for teeth damage.

Replace control module.

OK → **A** (See below.)

NG → Replace sensor.

NG → **Note**
Adjust tire pressure or replace tire(s).

NG → **Note**
Follow the direction in FA or RA section ("Front/Rear Wheel Bearing", "ON-VEHICLE SERVICE").





NG → **Note**
Clean sensor fixing portion, or replace sensor.

NG → **Note**
Replace sensor rotor (with drive shaft, wheel hub).

Note: Wheel position should be distinguished by code No.

Diagnostic Procedure 10

ACTUATOR MOTOR RELAY (LED flashing number 9)



CI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF





HA





EL

DX

TROUBLE DIAGNOSES


Diagnostic Procedure 10 (Cont'd)





Diagnostic Procedure 11

ACTUATOR SOLENOID VALVE RELAY (LED flashing number 10)




GI
 MA
 EM
 LC
 EF & EC
 FF
 CL
 MT
 AT
 FA
 RA
BR
 ST
 BF
 HA
 EL
 IDX

TROUBLE DIAGNOSES


Diagnostic Procedure 12




SENSOR AND SENSOR ROTOR (LED flashing number 15)



Diagnostic Procedure 13


SOLENOID VALVE RELAY OR CONTROL UNIT (LED flashing number 16)





Diagnostic Procedure 14

CONTROL UNIT OR POWER SUPPLY AND GROUND CIRCUIT (Warning activates but LED comes off.)



GI

VA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA


EL

IDX

TROUBLE DIAGNOSES


Electrical Components Inspection

ACTUATOR MOTOR RELAY



Condition	Continuity existence between terminals ③ and ④
Battery voltage not applied between terminals ① and ②.	No
Battery voltage applied between terminals ① and ②.	Yes

SOLENOID VALVE RELAY



Condition	Continuity existence between terminals ③⑩ and ⑧7a	Continuity existence between terminals ③⑩ and ⑧7
Battery voltage not applied between terminals ⑧5 and ⑧6.	Yes	No
Battery voltage applied between terminals ⑧5 and ⑧6.	No	Yes

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

BRAKE UNIT

Applied model	Without ABS				With ABS	
	GA16DE		SR20DE		GA16DE	SR20DE
	STD	GXE, XE	SR	SE		
Front brake						
Brake model	CL18VD		AD18VE		CL18VD	AD18VE
Cylinder bore diameter mm (in)	48.1 (1.894)				48.1 (1.894)	
Lining mm (in) length x width x thickness	106 x 43 x 10 (4.17 x 1.69 x 0.39)		97.5 x 42.5 x 10 (3.839 x 1.673 x 0.39)		106 x 43 x 10 (4.17 x 1.69 x 0.39)	97.5 x 42.5 x 10 (3.839 x 1.673 x 0.39)
Rotor outer diameter x thickness mm (in)	240 x 18 (9.45 x 0.71)		250 x 18 (9.84 x 0.71)		240 x 18 (9.45 x 0.71)	250 x 18 (9.84 x 0.71)
Rear brake						
Brake model	LT18C		AD7HA			
Cylinder bore diameter mm (in)	15.87 (5/8)		30.16 (1-3/16)			
Lining mm (in) length x width x thickness	172.8 x 30 x 4 (6.80 x 1.18 x 0.16)		94 x 29 x 10 (3.70 x 1.14 x 0.39)			
Drum inner diameter or rotor outer diameter x thickness mm (in)	180 (7.09)		234 x 7 (9.21 x 0.28)			
Master cylinder						
Cylinder bore diameter mm (in)	19.05 (3/4)	20.64 (13/16)	22.22 (7/8)		22.22 (7/8)	
Control valve						
Valve model	Dual proportioning valve built into master cylinder				Dual proportioning valve separated from master cylinder	
Split point [kPa (kg/cm ² , psi)] x reducing ratio	3,923 (40, 569) x 0.2		1,961 (20, 284) x 0.2		1,471 (15, 213) x 0.2	
Brake booster						
Booster model	S205 or C205	M195T				
Diaphragm diameter mm (in)	205 (8.07)	Primary: 205 (8.07) Secondary: 180 (7.09)				
Recommended brake fluid	DOT 3					

GI

MA

EM

LC

EF &
EC

FE

CL

MT

AT

FA

RA

BR

ST

BF

HA

EL

IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Inspection and Adjustment

DISC BRAKE

Unit: mm (in)

Brake model	Front		Rear
	CL18VD	AD18VE	AD7HA
Lining wear limit			
Minimum thickness	2.0 (0.079)		
Rotor repair limit			
Minimum thickness	16.0 (0.630)	6.0 (0.236)	

PARKING BRAKE CONTROL

Rear brake type	Drum	Disc
Number of notches [under force of 196 N (20 kg, 44 lb)]	5 - 6	7 - 8
Number of notches when warning switch comes on	1	

DRUM BRAKE

Unit: mm (in)

Brake model	Rear LT18C
Lining wear limit	
Minimum thickness	1.5 (0.059)
Drum repair limit	
Maximum inner diameter	181 (7.13)
Out-of-roundness	0.03 (0.0012)

BRAKE PEDAL

Unit: mm (in)

Applied model	GA16DE	SR20DE
Free height		
M/T	148 - 158 (5.83 - 6.22)	
A/T	157 - 167 (6.18 - 6.57)	
Depressed height [under force of 490 N (50 kg, 110 lb) with engine running] (Minimum)		
M/T	85 (3.35)	90 (3.54)
A/T	90 (3.54)	95 (3.74)
Clearance between switches and pedal stopper bracket	0.1 - 0.3 (0.004 - 0.012)	
Pedal free play	1 - 3 (0.04 - 0.12)	