

AUTOMATIC TRANSAXLE

SECTION **AT**

CONTENTS

TROUBLE DIAGNOSIS - INDEX	6	Line Pressure Test.....	72
Alphabetical & P No. Index for DTC	6	Road Test.....	73
PRECAUTIONS	8	TROUBLE DIAGNOSIS - GENERAL	
Supplemental Restraint System (SRS) "AIR		DESCRIPTION	93
BAG" and "SEAT BELT PRE-TENSIONER"	8	Symptom Chart.....	93
Precautions for On Board Diagnostic (OBD)			
System of A/T and Engine.....	8	<input type="checkbox"/> QG18DE (CALIF. CA) & SR20DE <input type="checkbox"/>	
Precautions	8	TROUBLE DIAGNOSIS - GENERAL	
Service Notice or Precautions	10	DESCRIPTION	108
Wiring Diagrams and Trouble Diagnosis.....	11	TCM Terminals and Reference Value.....	108
PREPARATION	12	TROUBLE DIAGNOSIS FOR POWER SUPPLY	112
Special Service Tools	12	Wiring Diagram - AT - MAIN.....	112
Commercial Service Tools	14	Diagnostic Procedure	113
OVERALL SYSTEM	16	DTC P0705 PARK/NEUTRAL POSITION (PNP)	
A/T Electrical Parts Location	16	SWITCH	115
Circuit Diagram - QG18DE (Calif. CA Model) &		Description	115
SR20DE	17	Wiring Diagram - AT - PNP/SW.....	116
Circuit Diagram - QG18DE (Except Calif. CA		Diagnostic Procedure	117
Model)	18	Component Inspection.....	119
Cross-sectional View - RE4F03B	19	DTC P0710 A/T FLUID TEMPERATURE SENSOR	
Hydraulic Control Circuit.....	20	CIRCUIT	120
Shift Mechanism	21	Description	120
Control System	30	Wiring Diagram - AT - FTS.....	122
Control Mechanism.....	31	Diagnostic Procedure	123
Control Valve	36	Component Inspection.....	125
ON BOARD DIAGNOSTIC SYSTEM		DTC P0720 VEHICLE SPEED SENSOR-A/T	
DESCRIPTION	38	(REVOLUTION SENSOR)	126
Introduction	38	Description	126
OBD-II Function for A/T System	38	Wiring Diagram - AT - VSSA/T	128
One or Two Trip Detection Logic of OBD-II	38	Diagnostic Procedure	129
OBD-II Diagnostic Trouble Code (DTC)	38	DTC P0725 ENGINE SPEED SIGNAL	131
Malfunction Indicator Lamp (MIL).....	42	Description	131
CONSULT-II	42	Wiring Diagram - AT - ENGSS	132
TROUBLE DIAGNOSIS - INTRODUCTION	59	Diagnostic Procedure	133
Introduction	59	DTC P0731 A/T 1ST GEAR FUNCTION	135
Work Flow.....	65	Description	135
TROUBLE DIAGNOSIS - BASIC INSPECTION	68	Wiring Diagram - AT - 1ST	138
A/T Fluid Check	68	Diagnostic Procedure	139
Stall Test	68		

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CONTENTS (Cont'd)

Component Inspection.....	140	Component Inspection.....	202
DTC P0732 A/T 2ND GEAR FUNCTION	142	DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP	
Description.....	142	SENSOR CIRCUIT AND TCM POWER SOURCE)	203
Wiring Diagram - AT - 2ND.....	145	Description.....	203
Diagnostic Procedure.....	146	Wiring Diagram - AT - BA/FTS.....	205
Component Inspection.....	147	Diagnostic Procedure.....	206
DTC P0733 A/T 3RD GEAR FUNCTION	148	Component Inspection.....	209
Description.....	148	DTC VHCL SPEED SEN-MTR VEHICLE SPEED	
Wiring Diagram - AT - 3RD.....	151	SENSOR-MTR	210
Diagnostic Procedure.....	152	Description.....	210
Component Inspection.....	153	Wiring Diagram - AT - VSSMTR.....	212
DTC P0734 A/T 4TH GEAR FUNCTION	154	Diagnostic Procedure.....	213
Description.....	154	DTC CONTROL UNIT (RAM), CONTROL UNIT	
Wiring Diagram - AT - 4TH.....	157	(ROM)	214
Diagnostic Procedure.....	158	Description.....	214
Component Inspection.....	162	Diagnostic Procedure.....	214
DTC P0740 TORQUE CONVERTER CLUTCH		DTC CONTROL UNIT (EEP ROM)	216
SOLENOID VALVE	163	Description.....	216
Description.....	163	Diagnostic Procedure.....	217
Wiring Diagram - AT - TCV.....	164	TROUBLE DIAGNOSES FOR SYMPTOMS	218
Diagnostic Procedure.....	165	Wiring Diagram - AT - NONDTC.....	218
Component Inspection.....	166	1. O/D OFF Indicator Lamp Does Not Come On....	221
DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)	167	2. Engine Cannot Be Started In "P" and "N"	
Description.....	167	Position.....	224
Wiring Diagram - AT - TCCSIG.....	170	3. In "P" Position, Vehicle Moves Forward Or	
Diagnostic Procedure.....	171	Backward When Pushed.....	225
Component Inspection.....	177	4. In "N" Position, Vehicle Moves.....	226
DTC P0745 LINE PRESSURE SOLENOID VALVE	178	5. Large Shock. "N" -> "R" Position.....	228
Description.....	178	6. Vehicle Does Not Creep Backward In "R"	
Wiring Diagram - AT - LPSV.....	179	Position.....	230
Diagnostic Procedure.....	180	7. Vehicle Does Not Creep Forward In "D", "2"	
Component Inspection.....	182	Or "1" Position.....	233
DTC P0750 SHIFT SOLENOID VALVE A	183	8. Vehicle Cannot Be Started From D ₁	236
Description.....	183	9. A/T Does Not Shift: D ₁ -> D ₂ Or Does Not	
Wiring Diagram - AT - SSV/A.....	184	Kickdown: D ₄ -> D ₂	239
Diagnostic Procedure.....	185	10. A/T Does Not Shift: D ₂ -> D ₃	242
Component Inspection.....	186	11. A/T Does Not Shift: D ₃ -> D ₄	245
DTC P0755 SHIFT SOLENOID VALVE B	187	12. A/T Does Not Perform Lock-up.....	248
Description.....	187	13. A/T Does Not Hold Lock-up Condition.....	250
Wiring Diagram - AT - SSV/B.....	188	14. Lock-up Is Not Released.....	252
Diagnostic Procedure.....	189	15. Engine Speed Does Not Return To Idle (Light	
Component Inspection.....	190	Braking D ₄ -> D ₃).....	253
DTC P1705 THROTTLE POSITION SENSOR	191	16. Vehicle Does Not Start From D ₁	255
Description.....	191	17. A/T Does Not Shift: D ₄ -> D ₃ , When	
Wiring Diagram - AT - TPS.....	193	Overdrive Control Switch "ON" -> "OFF".....	256
Diagnostic Procedure.....	194	18. A/T Does Not Shift: D ₃ -> 2 ₂ , When Selector	
Component Inspection.....	198	Lever "D" -> "2" Position.....	257
DTC P1760 OVERRUN CLUTCH SOLENOID		19. A/T Does Not Shift: 2 ₂ -> 1 ₁ , When Selector	
VALVE	199	Lever "2" -> "1" Position.....	258
Description.....	199	20. Vehicle Does Not Decelerate By Engine	
Wiring Diagram - AT - OVRCSV.....	200	Brake.....	259
Diagnostic Procedure.....	201		

CONTENTS (Cont'd)

21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks)	259	
<input type="checkbox"/> QG18DE (EXCEPT CALIF. CA) <input type="checkbox"/>		
TROUBLE DIAGNOSIS - GENERAL		
DESCRIPTION	268	
PCM Terminals and Reference Value	268	
TROUBLE DIAGNOSIS FOR POWER SUPPLY	272	
Wiring Diagram - AT - MAIN	272	
Diagnostic Procedure	273	
DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH	275	
Description	275	
Wiring Diagram - AT - PNP/SW	276	
Diagnostic Procedure	277	
Component Inspection	279	
DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT	280	
Description	280	
Wiring Diagram - AT - FTS	282	
Diagnostic Procedure	283	
Component Inspection	285	
DTC P0720 VEHICLE SPEED SENSOR A/T (REVOLUTION SENSOR)	286	
Description	286	
Wiring Diagram - AT - VSSA/T	288	
Diagnostic Procedure	289	
DTC P0725 ENGINE SPEED SIGNAL	291	
Description	291	
Wiring Diagram - AT - ENGSS	292	
Diagnostic Procedure	293	
DTC P0731 A/T 1ST GEAR FUNCTION	295	
Description	295	
Wiring Diagram - AT - 1ST	298	
Diagnostic Procedure	299	
Component Inspection	300	
DTC P0732 A/T 2ND GEAR FUNCTION	302	
Description	302	
Wiring Diagram - AT - 2ND	305	
Diagnostic Procedure	306	
Component Inspection	307	
DTC P0733 A/T 3RD GEAR FUNCTION	308	
Description	308	
Wiring Diagram - AT - 3RD	311	
Diagnostic Procedure	312	
Component Inspection	313	
DTC P0734 A/T 4TH GEAR FUNCTION	314	
Description	314	
Wiring Diagram - AT - 4TH	317	
Diagnostic Procedure	318	
Component Inspection	322	
DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE	323	GI
Description	323	
Wiring Diagram - AT - TCV	324	MA
Diagnostic Procedure	325	
Component Inspection	326	EM
DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)	327	
Description	327	
Wiring Diagram - AT - TCCSIG	330	LC
Diagnostic Procedure	331	
Component Inspection	337	
DTC P0745 LINE PRESSURE SOLENOID VALVE	338	EC
Description	338	
Wiring Diagram - AT - LPSV	339	
Diagnostic Procedure	340	FE
Component Inspection	342	
DTC P0750 SHIFT SOLENOID VALVE A	343	CL
Description	343	
Wiring Diagram - AT - SSV/A	344	
Diagnostic Procedure	345	MT
Component Inspection	346	
DTC P0755 SHIFT SOLENOID VALVE B	347	AT
Description	347	
Wiring Diagram - AT - SSV/B	348	
Diagnostic Procedure	349	AX
Component Inspection	350	
DTC P1705 THROTTLE POSITION SENSOR	351	SU
Description	351	
Wiring Diagram - AT - TPS	353	
Diagnostic Procedure	354	BR
Component Inspection	358	
DTC P1760 OVERRUN CLUTCH SOLENOID VALVE	359	ST
Description	359	
Wiring Diagram - AT - OVRCSV	360	
Diagnostic Procedure	361	RS
Component Inspection	362	
DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE)	363	BT
Description	363	
Wiring Diagram - AT - BA/FTS	365	HA
Diagnostic Procedure	366	
Component Inspection	368	
DTC VHCL SPEED SEN-MTR VEHICLE SPEED SENSOR-MTR	369	SC
Description	369	
Wiring Diagram - AT - VSSMTR	371	EL
Diagnostic Procedure	372	
DTC CONTROL UNIT (RAM), CONTROL UNIT (ROM)	373	IDX
Description	373	
Diagnostic Procedure	373	

CONTENTS (Cont'd)

DTC CONTROL UNIT (EEP ROM)	375	Differential Side Oil Seal Replacement	435
Description	375	Revolution Sensor Replacement	435
Diagnostic Procedure	376	REMOVAL AND INSTALLATION	436
TROUBLE DIAGNOSES FOR SYMPTOMS	377	Removal	436
Wiring Diagram - AT - NONDTC	377	Installation	437
1. O/D OFF Indicator Lamp Does Not Come On....	380	OVERHAUL	439
2. Engine Cannot Be Started In "P" and "N"		Components	439
Position	383	Oil Channel	442
3. In "P" Position, Vehicle Moves Forward Or		Locations of Adjusting Shims, Needle Bearings,	
Backward When Pushed	384	Thrust Washers and Snap Rings	443
4. In "N" Position, Vehicle Moves	385	DISASSEMBLY	444
5. Large Shock. "N" -> "R" Position	387	REPAIR FOR COMPONENT PARTS	458
6. Vehicle Does Not Creep Backward In "R"		Manual Shaft	458
Position	389	Oil Pump	461
7. Vehicle Does Not Creep Forward In "D", "2"		Control Valve Assembly	465
Or "1" Position	392	Control Valve Upper Body	474
8. Vehicle Cannot Be Started From D ₁	395	Control Valve Lower Body	478
9. A/T Does Not Shift: D ₁ -> D ₂ Or Does Not		Reverse Clutch	481
Kickdown: D ₄ -> D ₂	398	High Clutch	485
10. A/T Does Not Shift: D ₂ -> D ₃	401	Forward Clutch and Overrun Clutch	490
11. A/T Does Not Shift: D ₃ -> D ₄	404	Low & Reverse Brake	497
12. A/T Does Not Perform Lock-up	407	Rear Internal Gear, Forward Clutch Hub and	
13. A/T Does Not Hold Lock-up Condition	409	Overrun Clutch Hub	501
14. Lock-up Is Not Released	411	Output Shaft, Idler Gear, Reduction Pinion Gear	
15. Engine Speed Does Not Return To Idle (Light		and Bearing Retainer	505
Braking D ₄ -> D ₃)	412	Band Servo Piston Assembly	510
16. Vehicle Does Not Start From D ₁	414	Final Drive	515
17. A/T Does Not Shift: D ₄ -> D ₃ , When		ASSEMBLY	519
Overdrive Control Switch "ON" -> "OFF"	415	Assembly (1)	519
18. A/T Does Not Shift: D ₃ -> D ₂ , When Selector		Adjustment (1)	520
Lever "D" -> "2" Position	416	Assembly (2)	525
19. A/T Does Not Shift: D ₂ -> D ₁ , When Selector		Adjustment (2)	529
Lever "2" -> "1" Position	417	Assembly (3)	533
20. Vehicle Does Not Decelerate By Engine		Assembly (4)	535
Brake	418	SERVICE DATA AND SPECIFICATIONS (SDS)	540
21. PCM Self-diagnosis Does Not Activate (PNP,		General Specifications	540
Overdrive Control and Throttle Position Switches		Shift Schedule	540
Circuit Checks)	418	Stall Revolution	541
A/T SHIFT LOCK SYSTEM	425	Line Pressure	541
Description	425	Control Valves	542
Shift Lock System Electrical Parts Location	425	Clutch, Brake and Brake Band	542
Wiring Diagram - SHIFT -	426	Clutch and Brake Return Springs	544
Diagnostic Procedure	427	Oil Pump	544
KEY INTERLOCK CABLE	431	Input Shaft	545
Components	431	Planetary Carrier	545
Removal	431	Final Drive	545
Installation	432	Reduction Pinion Gear	546
ON-VEHICLE SERVICE	433	Output Shaft	548
Control Valve Assembly and Accumulators	433	Bearing Retainer	548
Control Cable Adjustment	434	Total End Play	549
Park/Neutral Position (PNP) Switch Adjustment	434	Reverse Clutch End Play	549
		Accumulator	549

CONTENTS (Cont'd)

Band Servo	549	ATF Temp. Sensor	550	GI
Removal and Installation	550	Revolution Sensor	550	
Shift Solenoid Valves	550	Dropping Resistor	550	MA
Resistance	550			

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC

Alphabetical & P No. Index for DTC ALPHABETICAL INDEX FOR DTC

NIAT0001

NIAT0001S01

Items (CONSULT-II screen terms)	DTC	Reference page	
	CONSULT-II GST*1	QG18DE (Calif. CA Model) & SR20DE	QG18DE (Except Calif. CA Model)
A/T 1ST GR FNCTN	P0731	AT-135	AT-295
A/T 2ND GR FNCTN	P0732	AT-142	AT-302
A/T 3RD GR FNCTN	P0733	AT-148	AT-308
A/T 4TH GR FNCTN	P0734	AT-154	AT-314
A/T TCC S/V FNCTN	P0744	AT-163	AT-323
ATF TEMP SEN/CIRC	P0710	AT-120	AT-280
ENGINE SPEED SIG	P0725	AT-131	AT-291
L/PRESS SOL/CIRC	P0745	AT-178	AT-338
O/R CLTCH SOL/CIRC	P1760	AT-199	AT-359
PNP SW/CIRC	P0705	AT-115	AT-275
SFT SOL A/CIRC*2	P0750	AT-183	AT-343
SFT SOL B/CIRC*2	P0755	AT-187	AT-347
TCC SOLENOID/CIRC	P0740	AT-163	AT-323
TP SEN/CIRC A/T*2	P1705	AT-191	AT-351
VEH SPD SEN/CIR AT*3	P0720	AT-126	AT-286

*1: These numbers are prescribed by SAE J2012.

*2: When the fail-safe operation occurs, the MIL illuminates.

*3: The MIL illuminates when both the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

TROUBLE DIAGNOSIS — INDEX

Alphabetical & P No. Index for DTC (Cont'd)

P NO. INDEX FOR DTC

—NIAT0001S02

DTC CONSULT-II GST*1	Items (CONSULT-II screen terms)	Reference page	
		QG18DE (Calif. CA Model) & SR20DE	QG18DE (Except Calif. CA Model)
P0705	PNP SW/CIRC	AT-115	AT-275
P0710	ATF TEMP SEN/CIRC	AT-120	AT-280
P0720	VEH SPD SEN/CIR AT*3	AT-126	AT-286
P0725	ENGINE SPEED SIG	AT-131	AT-291
P0731	A/T 1ST GR FNCTN	AT-135	AT-295
P0732	A/T 2ND GR FNCTN	AT-142	AT-302
P0733	A/T 3RD GR FNCTN	AT-148	AT-308
P0734	A/T 4TH GR FNCTN	AT-154	AT-314
P0740	TCC SOLENOID/CIRC	AT-163	AT-323
P0744	A/T TCC S/V FNCTN	AT-167	AT-327
P0745	L/PRESS SOL/CIRC	AT-178	AT-338
P0750	SFT SOL A/CIRC*2	AT-183	AT-343
P0755	SFT SOL B/CIRC*2	AT-187	AT-347
P1705	TP SEN/CIRC A/T*2	AT-191	AT-351
P1760	O/R CLTCH SOL/CIRC	AT-199	AT-359

*1: These numbers are prescribed by SAE J2012.

*2: When the fail-safe operation occurs, the MIL illuminates.

*3: The MIL illuminates when both the "Revolution sensor signal" and the "Vehicle speed sensor signal" meet the fail-safe condition at the same time.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

PRECAUTIONS

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

NIAT0002

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER" used along with a seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. The SRS system composition which is available to NISSAN B15 is as follows:

- For a frontal collision
The Supplemental Restraint System consists of driver air bag module (located in the center of the steering wheel), front passenger air bag module (located on the instrument panel on passenger side), front seat belt pre-tensioners, a diagnosis sensor unit, warning lamp, wiring harness and spiral cable.
- For a side collision
The Supplemental Restraint System consists of front side air bag module (located in the outer side of front seat), side air bag (satellite) sensor, diagnosis sensor unit (one of components of air bags for a frontal collision), wiring harness, warning lamp (one of components of air bags for a frontal collision).

Information necessary to service the system safely is included in the **RS section** of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance should be performed by an authorized NISSAN dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the RS section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. Spiral cable and wiring harnesses covered with yellow insulation tape either just before the harness connectors or for the complete harness are related to the SRS.


Precautions for On Board Diagnostic (OBD) System of A/T and Engine

NIAT0003

The ECM/PCM has an on board diagnostic system. It will light up the malfunction indicator lamp (MIL) to warn the driver of a malfunction causing emission deterioration.

CAUTION:

- Be sure to turn the ignition switch "OFF" and disconnect the negative battery terminal before any repair or inspection work. The open/short circuit of related switches, sensors, solenoid valves, etc. will cause the MIL to light up.
- Be sure to connect and lock the connectors securely after work. A loose (unlocked) connector will cause the MIL to light up due to an open circuit. (Be sure the connector is free from water, grease, dirt, bent terminals, etc.)
- Be sure to route and secure the harnesses properly after work. Interference of the harness with a bracket, etc. may cause the MIL to light up due to a short circuit.
- Be sure to connect rubber tubes properly after work. A misconnected or disconnected rubber tube may cause the MIL to light up due to a malfunction of the EGR system or fuel injection system, etc.
- Be sure to erase the unnecessary malfunction information (repairs completed) from the TCM/PCM and ECM before returning the vehicle to the customer.






Precautions

NIAT0004

- Before connecting or disconnecting the TCM/PCM harness connector, turn ignition switch OFF and disconnect negative battery terminal. Failure to do so may damage the TCM/PCM. Because battery voltage is applied to TCM/PCM even if ignition switch is turned off.

PRECAUTIONS

Precautions (Cont'd)



- When connecting or disconnecting pin connectors into or from TCM/PCM, take care not to damage pin terminals (bend or break).
Make sure that there are not any bends or breaks on TCM/PCM pin terminal, when connecting pin connectors.

- Before replacing TCM/PCM, perform TCM/PCM input/output signal inspection and make sure whether TCM/PCM functions properly or not. See page AT-108 [QG18DE (Calif. CA Model) and SR20DE], AT-268 [QG18DE (except Calif. CA Model)].

- After performing each TROUBLE DIAGNOSIS, perform “DTC (Diagnostic Trouble Code) CONFIRMATION PROCEDURE”.
The DTC should not be displayed in the “DTC CONFIRMATION PROCEDURE” if the repair is completed.

- Before proceeding with disassembly, thoroughly clean the outside of the transaxle. It is important to prevent the internal parts from becoming contaminated by dirt or other foreign matter.
- Disassembly should be done in a clean work area.
- Use lint-free cloth or towels for wiping parts clean. Common shop rags can leave fibers that could interfere with the operation of the transaxle.
- Place disassembled parts in order for easier and proper assembly.
- All parts should be carefully cleaned with a general purpose, non-flammable solvent before inspection or reassembly.
- Gaskets, seals and O-rings should be replaced any time the transaxle is disassembled.
- It is very important to perform functional tests whenever they are indicated.
- The valve body contains precision parts and requires extreme care when parts are removed and serviced. Place disassembled valve body parts in order for easier and proper assembly. Care will also prevent springs and small parts from becoming scattered or lost.
- Properly installed valves, sleeves, plugs, etc. will slide along bores in valve body under their own weight.
- Before assembly, apply a coat of recommended ATF to all

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

PRECAUTIONS

Precautions (Cont'd)

parts. Apply petroleum jelly to protect O-rings and seals, or hold bearings and washers in place during assembly. Do not use grease.

- Extreme care should be taken to avoid damage to O-rings, seals and gaskets when assembling.
- Replace ATF cooler if excessive foreign material is found in oil pan or clogging strainer. Refer to AT-11, "ATF COOLER SERVICE".
- After overhaul, refill the transaxle with new ATF.
- When the A/T drain plug is removed, only some of the fluid is drained. Old A/T fluid will remain in torque converter and ATF cooling system.

Always follow the procedures under "Changing A/T Fluid" in the MA section when changing A/T fluid. Refer to "Changing A/T Fluid", **MA-36**.

Service Notice or Precautions

NIAT0005

FAIL-SAFE

The TCM/PCM has an electronic Fail-Safe (limp home mode). This allows the vehicle to be driven even if a major electrical input/output device circuit is damaged.

Under Fail-Safe, the vehicle always runs in third gear, even with a shift lever position of "1", "2" or "D". The customer may complain of sluggish or poor acceleration.

When the ignition key is turned "ON" following Fail-Safe operation, O/D OFF indicator lamp blinks for about 8 seconds. [For "TCM/PCM Self-diagnostic Procedure (No Tools)", refer to AT-52.]

Fail-Safe may occur without electrical circuit damage if the vehicle is driven under extreme conditions (such as excessive wheel spin followed by sudden braking). To recover normal shift pattern, turn the ignition key "OFF" for 5 seconds, then "ON".

The blinking of the O/D OFF indicator lamp for about 8 seconds will appear only once and be cleared. The customer may resume normal driving conditions.

Always follow the "Work Flow" (Refer to AT-65).

The SELF-DIAGNOSIS results will be as follows:

The first SELF-DIAGNOSIS will indicate damage to the vehicle speed sensor or the revolution sensor.

During the next SELF-DIAGNOSIS, performed after checking the sensor, no damages will be indicated.

TORQUE CONVERTER SERVICE

The torque converter should be replaced under any of the following conditions:

- External leaks in the hub weld area.
- Converter hub is scored or damaged.
- Converter pilot is broken, damaged or fits poorly into crankshaft.
- Steel particles are found after flushing the cooler and cooler lines.
- Pump is damaged or steel particles are found in the converter.
- Vehicle has TCC shudder and/or no TCC apply. Replace only after all hydraulic and electrical diagnoses have been made. (Converter clutch material may be glazed.)
- Converter is contaminated with engine coolant containing antifreeze.
- Internal failure of stator roller clutch.
- Heavy clutch debris due to overheating (blue converter).
- Steel particles or clutch lining material found in fluid filter or on magnet when no internal parts in unit are worn or damaged — indicates that lining material came from converter.

The torque converter should not be replaced if:

NIAT0005S02

NIAT0005S01

PRECAUTIONS

Service Notice or Precautions (Cont'd)

- The fluid has an odor, is discolored, and there is no evidence of metal or clutch facing particles.
- The threads in one or more of the converter bolt holes are damaged.
- Transaxle failure did not display evidence of damaged or worn internal parts, steel particles or clutch plate lining material in unit and inside the fluid filter.
- Vehicle has been exposed to high mileage (only). The exception may be where the torque converter clutch dampener plate lining has seen excess wear by vehicles operated in heavy and/or constant traffic, such as taxi, delivery or police use.

GI

MA

EM

ATF COOLER SERVICE

NIAT0005S03

Replace ATF cooler if excessive foreign material is found in oil pan or clogging strainer.

Replace radiator lower tank (which includes ATF cooler) with a new one and flush cooler line using cleaning solvent and compressed air.

Refer to **LC-18**, "Radiator".

LC

OBD-II SELF-DIAGNOSIS

NIAT0005S04

- A/T self-diagnosis is performed by the PCM or the TCM in combination with the ECM. The results can be read through the blinking pattern of the O/D OFF indicator or the malfunction indicator lamp (MIL). Refer to the table on AT-43 for the indicator used to display each self-diagnostic result.
- The self-diagnostic results indicated by the MIL are automatically stored in the PCM or in both the ECM and TCM memories.
Always perform the procedure "HOW TO ERASE DTC" on AT-40 to complete the repair and avoid unnecessary blinking of the MIL.
- The following self-diagnostic items can be detected using ECM/PCM self-diagnostic results mode* only when the O/D OFF indicator lamp does not indicate any malfunctions.
 - PNP switch
 - A/T 1st, 2nd, 3rd, or 4th gear function
 - A/T TCC S/V function (lock-up).

EC

FE

CL

MT

AT

*: For details of OBD-II, refer to **EC-85** [QG18DE (Except Calif. CA Model)], **EC-758** [QG18DE (Calif. CA Model)], **EC-1426** (SR20DE), "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION".

AX

- **Certain systems and components, especially those related to OBD, may use a new style slide-locking type harness connector.**
For description and how to disconnect, refer to EL-5, "HARNESS CONNECTOR".

SU

Wiring Diagrams and Trouble Diagnosis

NIAT0006

When you read wiring diagrams, refer to the following:

- **GI-11**, "HOW TO READ WIRING DIAGRAMS".
- **EL-9**, "POWER SUPPLY ROUTING".

BR

ST

When you perform trouble diagnosis, refer to the following:

- **GI-36**, "How to Follow Test Group in Trouble Diagnosis".
- **GI-25**, "HOW TO PERFORM EFFICIENT DIAGNOSIS FOR AN ELECTRICAL INCIDENT".

RS

BT

HA

SC

EL

IDX







PREPARATION

Special Service Tools

Special Service Tools








NIAT0007

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

Tool number (Kent-Moore No.) Tool name	Description	
(J34301-C) Oil pressure gauge set 1 (J34301-1) Oil pressure gauge 2 (J34301-2) Hoses 3 (J34298) Adapter 4 (J34282) Adapter 5 (790-301-1230-A) 60° Adapter 6 (J34301-15) Square socket	 <p>AAT896</p>	Measuring line pressure
KV31103000 (J38982) Drift	 <p>NT105</p>	Installing differential oil seal (Use with ST35325000.) a: 59 mm (2.32 in) dia. b: 49 mm (1.93 in) dia.
ST35325000 (—) Drift	 <p>NT417</p>	Installing differential oil seal (Use with KV31103000.) a: 215 mm (8.46 in) b: 25 mm (0.98 in) dia. c: M12 x 1.5P
KV38107700 (J39027) Preload adapter	 <p>NT087</p>	<ul style="list-style-type: none"> ● Measuring turning torque of final drive assembly ● Measuring clearance between side gear and differential case with washer ● Selecting differential side bearing adjusting shim
KV31103200 (J34285-A and J34285-87) Clutch spring compressor	 <p>NT423</p>	Removing and installing clutch return spring a: 320 mm (12.60 in) b: 174 mm (6.85 in)
ST23540000 (J25689-A) Pin punch	 <p>NT442</p>	Removing and installing parking rod plate, manual plate and differential pinion mate shaft retaining pins a: 2.3 mm (0.091 in) dia. b: 4 mm (0.16 in) dia.







PREPARATION

Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description		
KV32101000 (J25689-A) Pin punch	 NT410	Installing throttle lever and manual shaft retaining pins a: 4 mm (0.16 in) dia.	GI MA EM
ST25710000 (—) Pin punch	 NT410	Aligning groove of manual shaft and hole of transmission case a: 2 mm (0.08 in) dia.	LC EC
ST3306S001 (J22888-D) Differential side bearing puller set 1 ST33051001 (J22888-D) Puller 2 ST33061000 (J8107-2) Adapter	 NT745	Removing differential side bearing inner race a: 39 mm (1.54 in) dia. b: 29.5 mm (1.161 in) dia. c: 130 mm (5.12 in) d: 135 mm (5.31 in) e: 120 mm (4.72 in)	FE CL MT
KV381054S0 (J34286) Puller	 NT414	<ul style="list-style-type: none"> ● Removing idler gear bearing outer race ● Removing differential side oil seals ● Removing differential side bearing outer race ● Removing needle bearing from bearing retainer a: 250 mm (9.84 in) b: 160 mm (6.30 in)	AT AX SU BR
ST27180001 (J25726-B) Puller	 NT424	<ul style="list-style-type: none"> ● Removing idler gear a: 100 mm (3.94 in) b: 110 mm (4.33 in) c: M8 x 1.25P	ST RS BT
ST30031000 (J22912-O1) Puller	 NT411	Removing reduction gear bearing inner race a: 90 mm (3.54 in) dia. b: 50 mm (1.97 in) dia.	HA SC
ST35272000 (J26092) Drift	 NT426	<ul style="list-style-type: none"> ● Installing reduction gear bearing inner race ● Installing idler gear bearing inner race a: 72 mm (2.83 in) dia. b: 35.5 mm (1.398 in) dia.	EL IDX


PREPARATION

Special Service Tools (Cont'd)

Tool number (Kent-Moore No.) Tool name	Description
ST37830000 (—) Drift	 <p>Installing idler gear bearing outer race a: 62 mm (2.44 in) dia. b: 39 mm (1.54 in) dia.</p> <p>NT427</p>
ST35321000 (—) Drift	 <p>Installing output shaft bearing a: 49 mm (1.93 in) dia. b: 41 mm (1.61 in) dia.</p> <p>NT073</p>
ST30633000 (—) Drift	 <p>Installing differential side bearing outer race a: 67 mm (2.64 in) dia. b: 49 mm (1.93 in) dia.</p> <p>NT073</p>
ST35271000 (J26091) Drift	 <p>● Installing idler gear a: 72 mm (2.83 in) dia. b: 63 mm (2.48 in) dia.</p> <p>NT115</p>
ST33400001 (J26082) Drift	 <p>● Installing oil pump housing oil seal a: 60 mm (2.36 in) dia. b: 47 mm (1.85 in) dia.</p> <p>NT115</p>
KV38105710 (—)	 <p>● Measuring clearance between side gear and differential case</p> <p>NT087</p>




Commercial Service Tools

NIAT0008

Tool name	Description
Puller	 <p>● Removing idler gear bearing inner race ● Removing and installing band servo piston snap ring</p> <p>NT077</p>

PREPARATION

Commercial Service Tools (Cont'd)

Tool name	Description
Drift	 <p>Removing idler gear bearing inner race a: 34 mm (1.34 in) dia.</p> <p>NT109</p>
Drift	 <p>Installing differential left side bearing a: 86 mm (3.39 in) dia. b: 80 mm (3.15 in) dia.</p> <p>NT115</p>
Drift	 <p>Installing differential right side bearing a: 46 mm (1.81 in) dia. b: 40 mm (1.57 in) dia.</p> <p>NT115</p>

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA













SC

EL

IDX

OVERALL SYSTEM

A/T Electrical Parts Location



OVERALL SYSTEM

Circuit Diagram — QG18DE (Calif. CA Model) & SR20DE

Circuit Diagram — QG18DE (Calif. CA Model) & SR20DE

NIAT0010

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX




WAT112

OVERALL SYSTEM

Circuit Diagram — QG18DE (Except Calif. CA Model)

Circuit Diagram — QG18DE (Except Calif. CA Model)

NIAT0328



WAT091

OVERALL SYSTEM

Cross-sectional View — RE4F03B

Cross-sectional View — RE4F03B

NIAT0011

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX




SAT842J

OVERALL SYSTEM

Hydraulic Control Circuit

Hydraulic Control Circuit

NIAT0013



SAT844J

OVERALL SYSTEM


Shift Mechanism

Shift Mechanism

CONSTRUCTION

NIAT0014

NIAT0014S01



SAT998I

- | | | |
|----------------------|-----------------------------|-------------------------|
| 1. Torque converter | 9. Front internal gear | 17. Overrun clutch |
| 2. Oil pump | 10. Front planetary carrier | 18. Low one-way clutch |
| 3. Input shaft | 11. Rear sun gear | 19. Low & reverse brake |
| 4. Brake band | 12. Rear pinion gear | 20. Parking pawl |
| 5. Reverse clutch | 13. Rear internal gear | 21. Parking gear |
| 6. High clutch | 14. Rear planetary carrier | 22. Output shaft |
| 7. Front sun gear | 15. Forward clutch | 23. Idle gear |
| 8. Front pinion gear | 16. Forward one-way clutch | 24. Output gear |

FUNCTION OF CLUTCH AND BRAKE

NIAT0014S02

Clutch and brake components	Abbr.	Function
5 Reverse clutch	R/C	To transmit input power to front sun gear 7.
6 High clutch	H/C	To transmit input power to front planetary carrier 10.
15 Forward clutch	F/C	To connect front planetary carrier 10 with forward one-way clutch 16.
17 Overrun clutch	O/C	To connect front planetary carrier 10 with rear internal gear 13.
4 Brake band	B/B	To lock front sun gear 7.
16 Forward one-way clutch	F/O.C	When forward clutch 15 is engaged, to stop rear internal gear 13 from rotating in opposite direction against engine revolution.
18 Low one-way clutch	L/O.C	To stop front planetary carrier 10 from rotating in opposite direction against engine revolution.
19 Low & reverse brake	L & R/B	To lock front planetary carrier 10.

OVERALL SYSTEM

Shift Mechanism (Cont'd)

CLUTCH AND BAND CHART

NIAT0014S03

Shift position	Reverse clutch 5	High clutch 6	Forward clutch 15	Over-run clutch 17	Band servo			Forward one-way clutch 16	Low one-way clutch 18	Low & reverse brake 19	Lock-up	Remarks
					2nd apply	3rd release	4th apply					
P												PARK POSITION
R	○									○		REVERSE POSITION
N												NEUTRAL POSITION
D*4	1st		○	*1D				B	B			Automatic shift 1 ↔ 2 ↔ 3 ↔ 4
	2nd		○	*1A	○			B				
	3rd		○	○	*1A	*2C	C	B			*5○	
	4th		○	C		*3C	C	○			○	
2	1st		○	D				B	B			Automatic shift 1 ↔ 2
	2nd		○	A	○			B				
1	1st		○	○				B		○		Locks (held stationary) in 1st speed 1 ↔ 2
	2nd		○	○	○			B				

*1: Operates when overdrive control switch is set in "OFF" position.

*2: Oil pressure is applied to both 2nd "apply" side and 3rd "release" side of band servo piston. However, brake band does not contract because oil pressure area on the "release" side is greater than that on the "apply" side.

*3: Oil pressure is applied to 4th "apply" side in condition *2 above, and brake band contracts.

*4: A/T will not shift to 4th when overdrive control switch is set in "OFF" position.

*5: Operates when overdrive control switch is "OFF".

○ : Operates.

A: Operates when throttle opening is less than 3/16, activating engine brake.

B: Operates during "progressive" acceleration.

C: Operates but does not affect power transmission.

D: Operates when throttle opening is less than 3/16, but does not affect engine brake.

OVERALL SYSTEM

Shift Mechanism (Cont'd)


POWER TRANSMISSION

-NIAT0014S04

NIAT0014S0401

"N" and "P" Positions

- "N" position
Power from the input shaft is not transmitted to the output shaft because the clutches do not operate.
- "P" position
Similar to the "N" position, the clutches do not operate. The parking pawl engages with the parking gear to mechanically hold the output shaft so that the power train is locked.



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


OVERALL SYSTEM

Shift Mechanism (Cont'd)

"1" Position

-NIAT0014S0402

<ul style="list-style-type: none"> ● Forward clutch ● Forward one-way clutch ● Overrun clutch ● Low and reverse brake 	<p>As overrun clutch engages, rear internal gear is locked by the operation of low and reverse brake. This is different from that of D₁ and 2₁.</p>
<p>Engine brake</p>	<p>Overrun clutch always engages, therefore engine brake can be obtained when decelerating.</p>




OVERALL SYSTEM

Shift Mechanism (Cont'd)

"D₁" and "2₁" Positions

-NIAT0014S0403

<ul style="list-style-type: none"> ● Forward one-way clutch ● Forward clutch ● Low one-way clutch 	Rear internal gear is locked to rotate counterclockwise because of the functioning of these three clutches.
Overrun clutch engagement conditions (Engine brake)	D ₁ : Overdrive control switch "OFF" and throttle opening is less than 3/16 2 ₁ : Always engaged At D ₁ and 2 ₁ positions, engine brake is not activated due to free turning of low one-way clutch.



SAT377J

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


OVERALL SYSTEM

Shift Mechanism (Cont'd)

"D₂", "2₂" and "1₂" Positions

-NIAT0014S0404

<ul style="list-style-type: none"> ● Forward clutch ● Forward one-way clutch ● Brake band 	<p>Rear sun gear drives rear planetary carrier and combined front internal gear. Front internal gear now rotates around front sun gear accompanying front planetary carrier. As front planetary carrier transfers the power to rear internal gear through forward clutch and forward one-way clutch, this rotation of rear internal gear increases the speed of rear planetary carrier compared with that of the 1st speed.</p>
<p>Overrun clutch engagement conditions</p>	<p>D₂: Overdrive control switch "OFF" and throttle opening is less than 3/16 2₂ and 1₂: Always engaged</p>



SAT378J


OVERALL SYSTEM

Shift Mechanism (Cont'd)

"D₃" Position

-NIAT0014S0405

<ul style="list-style-type: none"> ● High clutch ● Forward clutch ● Forward one-way clutch 	<p>Input power is transmitted to front planetary carrier through high clutch. And front planetary carrier is connected to rear internal gear by operation of forward clutch and forward one-way clutch. This rear internal gear rotation and another input (the rear sun gear) accompany rear planetary carrier to turn at the same speed.</p>
<p>Overrun clutch engagement conditions</p>	<p>D₃: Overdrive control switch "OFF" and throttle opening is less than 3/16</p>



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


OVERALL SYSTEM

Shift Mechanism (Cont'd)

-NIAT0014S0406

"D₄" (OD) Position

<ul style="list-style-type: none"> ● High clutch ● Brake band ● Forward clutch (Does not affect power transmission) 	<p>Input power is transmitted to front carrier through high clutch. This front carrier turns around the sun gear which is fixed by brake band and makes front internal gear (output) turn faster.</p>
<p>Engine brake</p>	<p>At D₄ position, there is no one-way clutch in the power transmission line and engine brake can be obtained when decelerating.</p>




OVERALL SYSTEM

Shift Mechanism (Cont'd)

"R" Position

-NIAT0014S0407

<ul style="list-style-type: none"> ● Reverse clutch ● Low and reverse brake 	<p>Front planetary carrier is stationary because of the operation of low and reverse brake. Input power is transmitted to front sun gear through reverse clutch, which drives front internal gear in the opposite direction.</p>
<p>Engine brake</p>	<p>As there is no one-way clutch in the power transmission line, engine brake can be obtained when decelerating.</p>



SAT381J

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

OVERALL SYSTEM

Control System

Control System

=NIAT0015

OUTLINE


NIAT0015S01

The automatic transaxle senses vehicle operating conditions through various switches and sensors. It always controls the optimum shift position and reduces shifting and lock-up shocks.

SWITCHES & SENSORS		TCM/PCM		ACTUATORS
PNP switch Throttle position sensor Closed throttle position switch Wide open throttle position switch Engine speed signal A/T fluid temperature sensor Revolution sensor Vehicle speed sensor Overdrive control switch ASCD control unit Stop lamp switch	▶	Shift control Line pressure control Lock-up control Overrun clutch control Timing control Fail-safe control Self-diagnosis CONSULT-II communication line control Duet-EA control	▶	Shift solenoid valve A Shift solenoid valve B Overrun clutch solenoid valve Torque converter clutch solenoid valve Line pressure solenoid valve O/D OFF indicator lamp

CONTROL SYSTEM

NIAT0015S02



WAT145

OVERALL SYSTEM

Control System (Cont'd)

TCM/PCM FUNCTION

NIAT0015S03

The function of the TCM/PCM is to:

- Receive input signals sent from various switches and sensors.
- Determine required line pressure, shifting point, lock-up operation, and engine brake operation.
- Send required output signals to the respective solenoids.

INPUT/OUTPUT SIGNAL OF TCM/PCM

NIAT0015S04

	Sensors, switches and solenoid valves	Function
Input	PNP switch	Detects select lever position and sends a signal to TCM/PCM.
	Throttle position sensor	Detects throttle valve position and sends a signal to TCM/PCM.
	Closed throttle position switch	Detects throttle valve's fully-closed position and sends a signal to TCM/PCM.
	Wide open throttle position switch	Detects a throttle valve position of greater than 1/2 of full throttle and sends a signal to TCM/PCM.
	Engine speed signal	From ECM or Tachometer (PCM).
	A/T fluid temperature sensor	Detects transmission fluid temperature and sends a signal to TCM/PCM.
	Revolution sensor	Detects output shaft rpm and sends a signal to TCM/PCM.
	Vehicle speed sensor	Used as an auxiliary vehicle speed sensor. Sends a signal when revolution sensor (installed on transmission) malfunctions.
	Overdrive control switch	Sends a signal, which prohibits a shift to "D ₄ " (overdrive) position, to the TCM/PCM.
	ASCD control unit	Sends the cruise signal and "D ₄ " (overdrive) cancellation signal from ASCD control unit to TCM/PCM.
	Stop lamp switch	Releases lock-up system when depressing pedal in lock-up condition.
Output	Shift solenoid valve A/B	Selects shifting point suited to driving conditions in relation to a signal sent from TCM/PCM.
	Line pressure solenoid valve	Regulates (or decreases) line pressure suited to driving conditions in relation to a signal sent from TCM/PCM.
	Torque converter clutch solenoid valve	Regulates (or decreases) lock-up pressure suited to driving conditions in relation to a signal sent from TCM/PCM.
	Overrun clutch solenoid valve	Controls an "engine brake" effect suited to driving conditions in relation to a signal sent from TCM/PCM.
	O/D OFF indicator lamp	Shows TCM/PCM faults, when A/T control components malfunction.

Control Mechanism

NIAT0016

LINE PRESSURE CONTROL

NIAT0016S01


TCM/PCM has various line pressure control characteristics to match the driving conditions.

An ON-OFF duty signal is sent to the line pressure solenoid valve based on TCM/PCM characteristics.

Hydraulic pressure on the clutch and brake is electronically controlled through the line pressure solenoid valve to accommodate engine torque. This results in smooth shift operation.


OVERALL SYSTEM

Control Mechanism (Cont'd)




Normal Control

The line pressure to throttle opening characteristics is set for suitable clutch operation. NIAT0016S0101




Back-up Control (Engine brake)

If the selector lever is shifted to "2" position while driving in D₄ (OD) or D₃, great driving force is applied to the clutch inside the transmission. Clutch operating pressure (line pressure) must be increased to deal with this driving force. NIAT0016S0102



During Shift Change

The line pressure is temporarily reduced corresponding to a change in engine torque when shifting gears (that is, when the shift solenoid valve is switched for clutch operation) to reduce shifting shock. NIAT0016S0103




At Low Fluid Temperature

- Fluid viscosity and frictional characteristics of the clutch facing change with fluid temperature. Clutch engaging or band-contacting pressure is compensated for, according to fluid temperature, to stabilize shifting quality. NIAT0016S0104

- The line pressure is reduced below 60°C (140°F) to prevent shifting shock due to low viscosity of automatic transmission fluid when temperature is low.

OVERALL SYSTEM

Control Mechanism (Cont'd)



- Line pressure is increased to a maximum irrespective of the throttle opening when fluid temperature drops to -10°C (14°F). This pressure rise is adopted to prevent a delay in clutch and brake operation due to extreme drop of fluid viscosity at low temperature.

GI

MA

EM

LC

SHIFT CONTROL

NIAT0016S02


The shift is regulated entirely by electronic control to accommodate vehicle speed and varying engine operations. This is accomplished by electrical signals transmitted by the revolution sensor and throttle position sensor. This results in improved acceleration performance and fuel economy.

EC

FE

CL

MT



Control of Shift Solenoid Valves A and B

NIAT0016S0201

The TCM/PCM activates shift solenoid valves A and B according to signals from the throttle position sensor and revolution sensor to select the optimum gear position on the basis of the shift schedule memorized in the TCM/PCM.

The shift solenoid valve performs simple ON-OFF operation. When set to "ON", the drain circuit closes and pilot pressure is applied to the shift valve.

AT

AX

SU

BR

Relation Between Shift Solenoid Valves A and B and Gear Positions

NIAT0016S0202


Shift solenoid valve	Gear position				
	D ₁ , 2 ₁ , 1 ₁	D ₂ , 2 ₂ , 1 ₂	D ₃	D ₄ (OD)	N-P
A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)	ON (Closed)
B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)

RS

BT

Control of Shift Valves A and B

NIAT0016S0203



HA

SC

EL

IDX

OVERALL SYSTEM

Control Mechanism (Cont'd)

Pilot pressure generated by the operation of shift solenoid valves A and B is applied to the end face of shift valves A and B.

The drawing above shows the operation of shift valve B. When the shift solenoid valve is "ON", pilot pressure applied to the end face of the shift valve overcomes spring force, moving the valve upward.


LOCK-UP CONTROL

The torque converter clutch piston in the torque converter is locked to eliminate torque converter slip to increase power transmission efficiency. The solenoid valve is controlled by an ON-OFF duty signal sent from the TCM/PCM. The signal is converted to an oil pressure signal which controls the torque converter clutch piston.

Conditions for Lock-up Operation

When vehicle is driven in 4th gear position, vehicle speed and throttle opening are detected. If the detected values fall within the lock-up zone memorized in the TCM/PCM, lock-up is performed.


Overdrive control switch	ON	OFF
Selector lever	"D" position	
Gear position	D ₄	D ₃
Vehicle speed sensor	More than set value	
Throttle position sensor	Less than set opening	
Closed throttle position switch	OFF	
A/T fluid temperature sensor	More than 40°C (104°F)	



Torque Converter Clutch Solenoid Valve Control

The torque converter clutch solenoid valve is controlled by the TCM/PCM. The plunger closes the drain circuit during the "OFF" period, and opens the circuit during the "ON" period. If the percentage of OFF-time increases in one cycle, the pilot pressure drain time is reduced and pilot pressure remains high.

The torque converter clutch piston is designed to slip to adjust the ratio of ON-OFF, thereby reducing lock-up shock.




OFF-time INCREASING
 ↓
 Amount of drain DECREASING
 ↓
 Pilot pressure HIGH
 ↓
 Lock-up RELEASING

OVERALL SYSTEM

Control Mechanism (Cont'd)

Torque Converter Clutch Control Valve Operation

NIAT0016S0303



WAT149

Lock-up released

The OFF-duration of the torque converter clutch solenoid valve is long, and pilot pressure is high. The pilot pressure pushes the end face of the torque converter clutch control valve in combination with spring force to move the valve to the left. As a result, converter pressure is applied to chamber A (torque converter clutch piston release side). Accordingly, the torque converter clutch piston remains unlocked.

Lock-up applied

When the OFF-duration of the torque converter clutch solenoid valve is short, pilot pressure drains and becomes low. Accordingly, the control valve moves to the right by the pilot pressure of the other circuit and converter pressure. As a result, converter pressure is applied to chamber B, keeping the torque converter clutch piston applied.

Also smooth lock-up is provided by transient application and release of the lock-up.

OVERRUN CLUTCH CONTROL (ENGINE BRAKE CONTROL)

NIAT0016S04


Forward one-way clutch is used to reduce shifting shocks in downshifting operations. This clutch transmits engine torque to the wheels. However, drive force from the wheels is not transmitted to the engine because the one-way clutch rotates idle. This means the engine brake is not effective.

The overrun clutch operates when the engine brake is needed.

Overrun Clutch Operating Conditions

NIAT0016S0401


Selector lever position	Gear position	Throttle opening
"D" position	D ₁ , D ₂ , D ₃ gear position	Less than 3/16
"2" position	2 ₁ , 2 ₂ gear position	
"1" position	1 ₁ , 1 ₂ gear position	At any position



SAT014J

OVERALL SYSTEM

Control Mechanism (Cont'd)




Overrun Clutch Solenoid Valve Control

NIAT0016SD402

The overrun clutch solenoid valve is operated by an ON-OFF signal transmitted by the TCM/PCM to provide overrun clutch control (engine brake control).

When this solenoid valve is "ON", the pilot pressure drain port closes. When it is "OFF", the drain port opens.

During the solenoid valve "ON" pilot pressure is applied to the end face of the overrun clutch control valve.



Overrun Clutch Control Valve Operation

NIAT0016SD403

When the solenoid valve is "ON", pilot pressure is applied to the overrun clutch control valve. This pushes up the overrun clutch control valve. The line pressure is then shut off so that the clutch does not engage.

When the solenoid valve is "OFF", pilot pressure is not generated. At this point, the overrun clutch control valve moves downward by spring force. As a result, overrun clutch operation pressure is provided by the overrun clutch reducing valve. This causes the overrun clutch to engage.

In the 1 position, the overrun clutch control valve remains pushed down so that the overrun clutch is engaged at all times.

Control Valve

NIAT0017

FUNCTION OF CONTROL VALVES

NIAT0017S01

Valve name	Function
Pressure regulator valve, plug and sleeve	Regulates oil discharged from the oil pump to provide optimum line pressure for all driving conditions.
Pressure modifier valve and sleeve	Used as a signal supplementary valve to the pressure regulator valve. Regulates pressure-modifier pressure (signal pressure) which controls optimum line pressure for all driving conditions.
Pilot valve	Regulates line pressure to maintain a constant pilot pressure level which controls lock-up mechanism, overrun clutch, shift timing.
Accumulator control valve	Regulates accumulator backpressure to pressure suited to driving conditions.
Manual valve	Directs line pressure to oil circuits corresponding to select positions. Hydraulic pressure drains when the shift lever is in Neutral.
Shift valve A	Simultaneously switches four oil circuits using output pressure of shift solenoid valve A to meet driving conditions (vehicle speed, throttle opening, etc.). Provides automatic downshifting and up-shifting (1st → 2nd → 3rd → 4th gears/4th → 3rd → 2nd → 1st gears) in combination with shift valve B.

OVERALL SYSTEM

Control Valve (Cont'd)

Valve name	Function	
Shift valve B	Simultaneously switches three oil circuits using output pressure of shift solenoid valve B in relation to driving conditions (vehicle speed, throttle opening, etc.). Provides automatic downshifting and up-shifting (1st → 2nd → 3rd → 4th gears/4th → 3rd → 2nd → 1st gears) in combination with shift valve A.	GI MA
Overrun clutch control valve	Switches hydraulic circuits to prevent engagement of the overrun clutch simultaneously with application of the brake band in D ₄ . (Interlocking occurs if the overrun clutch engages during D ₄ .)	EM
1st reducing valve	Reduces low & reverse brake pressure to dampen engine-brake shock when down-shifting from the "1" position 1 ₂ to 1 ₁ .	LC
Overrun clutch reducing valve	Reduces oil pressure directed to the overrun clutch and prevents engine-brake shock. In "1" and "2" positions, line pressure acts on the overrun clutch reducing valve to increase the pressure-regulating point, with resultant engine brake capability.	EC
Torque converter relief valve	Prevents an excessive rise in torque converter pressure.	
Torque converter clutch control valve, plug and sleeve	Activates or inactivates the lock-up function. Also provides smooth lock-up through transient application and release of the lock-up system.	FE
1-2 accumulator valve and piston	Dampens the shock encountered when 2nd gear band servo contracts, and provides smooth shifting.	CL
3-2 timing valve	Switches oil pressure with 3-2 timing valve according to throttle opening.	MT
Shuttle control valve	Reduces shock when down-shifting from 3rd to 2nd and regulates overrun clutch.	
Cooler check valve	Regulates oil pressure which causes lock-up when driving at low speeds.	AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Introduction

Introduction

NIAT0018

The A/T system has two self-diagnostic systems.

The first is the emission-related on board diagnostic system (OBD-II) performed by the PCM or the TCM in combination with the ECM. The malfunction is indicated by the MIL (malfunction indicator lamp) and is stored as a DTC in the PCM or in the ECM memory but not the TCM memory.

The second is the TCM/PCM original self-diagnosis indicated by the O/D OFF indicator lamp. The malfunction is stored in the TCM/PCM memory. The detected items are overlapped with OBD-II self-diagnostic items. For detail, refer to AT-43.

OBD-II Function for A/T System

NIAT0019

The ECM/PCM provides emission-related on board diagnostic (OBD-II) functions for the A/T system. One function is to receive a signal from the TCM/PCM used with OBD-related parts of the A/T system. The signal is sent to the ECM/PCM when a malfunction occurs in the corresponding OBD-related part. The other function is to indicate a diagnostic result by means of the MIL (malfunction indicator lamp) on the instrument panel. Sensors, switches and solenoid valves are used as sensing elements.

The MIL automatically illuminates in One or Two Trip Detection Logic when a malfunction is sensed in relation to A/T system parts.

One or Two Trip Detection Logic of OBD-II

NIAT0020

ONE TRIP DETECTION LOGIC

NIAT0020S01

If a malfunction is sensed during the first test drive, the MIL will illuminate and the malfunction will be stored in the ECM/PCM memory as a DTC. The TCM is not provided with such a memory function.

TWO TRIP DETECTION LOGIC

NIAT0020S02

When a malfunction is sensed during the first test drive, it is stored in the ECM/PCM memory as a 1st trip DTC (diagnostic trouble code) or 1st trip freeze frame data. At this point, the MIL will not illuminate. — First Trip

If the same malfunction as that experienced during the first test drive is sensed during the second test drive, the MIL will illuminate. — Second Trip

A/T-related parts for which the MIL illuminates during the first or second test drive are listed below.

Items	MIL	
	One trip detection	Two trip detection
Shift solenoid valve A — DTC: P0750	X	
Shift solenoid valve B — DTC: P0755	X	
Throttle position sensor or switch — DTC: P1705	X	
Except above		X

The “trip” in the “One or Two Trip Detection Logic” means a driving mode in which self-diagnosis is performed during vehicle operation.



OBD-II Diagnostic Trouble Code (DTC)

NIAT0021

HOW TO READ DTC AND 1ST TRIP DTC

NIAT0021S01

DTC and 1st trip DTC can be read by the following methods.

( with CONSULT-II or  GST) CONSULT-II or GST (Generic Scan Tool) Examples: P0705, P0710, P0720, P0725, etc.

These DTCs are prescribed by SAE J2012.

(CONSULT-II also displays the malfunctioning component or system.)

- **1st trip DTC No. is the same as DTC No.**
- **Output of the diagnostic trouble code indicates that the indicated circuit has a malfunction. However, in case of the Mode II and GST they do not indicate whether the malfunction is still occurring or occurred in the past and returned to normal. CONSULT-II can identify them as shown below. Therefore, using CONSULT-II (if available) is recommended.**

A sample of CONSULT-II display for DTC is shown in the following page. DTC or 1st trip DTC of a malfunction is displayed in SELF DIAGNOSIS mode for “ENGINE” with CONSULT-II. Time data indicates how many times the vehicle was driven after the last detection of a DTC.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD-II Diagnostic Trouble Code (DTC) (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

If the DTC is being detected currently, the time data will be "0".

SELF-DIAG RESULTS	
DTC RESULTS	TIME
PNP SW/CIRC [P0705]	0

SAT015K

If a 1st trip DTC is stored in the ECM/PCM, the time data will be "1t".

SELF-DIAG RESULTS	
DTC RESULTS	TIME
PNP SW/CIRC [P0705]	1 t

SAT016K

Freeze Frame Data and 1st Trip Freeze Frame Data

The ECM/PCM has a memory function, which stores the driving condition such as fuel system status, calculated load value, engine coolant temperature, short term fuel trim, long term fuel trim, engine speed and vehicle speed at the moment the ECM/PCM detects a malfunction.

Data which are stored in the ECM/PCM memory, along with the 1st trip DTC, are called 1st trip freeze frame data, and the data, stored together with the DTC data, are called freeze frame data and displayed on CONSULT-II or GST. The 1st trip freeze frame data can only be displayed on the CONSULT-II screen, not on the GST. For detail, refer to **EC-107**[QG18DE (Except Calif. CAModel)], **EC-779**[QG18DE (Calif. CAModel)], **EC-1447**(SR20DE), "CONSULT-II".

Only one set of freeze frame data (either 1st trip freeze frame data of freeze frame data) can be stored in the ECM/PCM. 1st trip freeze frame data is stored in the ECM/PCM memory along with the 1st trip DTC. There is no priority for 1st trip freeze frame data and it is updated each time a different 1st trip DTC is detected. However, once freeze frame data (2nd trip detection/MIL on) is stored in the ECM/PCM memory, 1st trip freeze frame data is no longer stored. Remember, only one set of freeze frame data can be stored in the ECM/PCM. The ECM/PCM has the following priorities to update the data.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD-II Diagnostic Trouble Code (DTC) (Cont'd)

Priority	Items	
1	Freeze frame data	Misfire — DTC: P0300 - P0306 Fuel Injection System Function — DTC: P0171, P0172, P0174, P0175
2		Except the above items (Includes A/T related items)
3	1st trip freeze frame data	

Both 1st trip freeze frame data and freeze frame data (along with the DTCs) are cleared when the ECM/PCM memory is erased.

HOW TO ERASE DTC

The diagnostic trouble code can be erased by CONSULT-II, GST or ECM/PCM DIAGNOSTIC TEST MODE ^{NIAT0021S02} as described following.

- If the battery terminal is disconnected, the diagnostic trouble code will be lost within 24 hours.
- When you erase the DTC, using CONSULT-II, GST or PCM is easier and quicker than switching the mode selector on the ECM/PCM.

The following emission-related diagnostic information is cleared from the ECM/PCM memory when erasing DTC related to OBD-II. For details, refer to **EC-86** [QG18DE (Except Calif. CA Model)], **EC-759** [QG18DE (Calif. CA Model)], **EC-1427** (SR20DE), "Emission-related Diagnostic Information".

- Diagnostic trouble codes (DTC)
- 1st trip diagnostic trouble codes (1st trip DTC)
- Freeze frame data
- 1st trip freeze frame data
- System readiness test (SRT) codes
- Test values

Ⓟ HOW TO ERASE DTC (WITH CONSULT-II)

- If a DTC is displayed for both ECM and TCM or PCM, it needs to be erased for both ECM and TCM or PCM. ^{NIAT0021S03}

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
2. Turn CONSULT-II "ON" and touch "A/T".
3. Touch "SELF DIAGNOSIS".
4. Touch "ERASE". (The DTC in the TCM will be erased.) Then touch "BACK" twice.
5. Touch "ENGINE".
6. Touch "SELF DIAGNOSIS".
7. Touch "ERASE". (The DTC in the ECM will be erased.)

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

OBD-II Diagnostic Trouble Code (DTC) (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

How to erase DTC (With CONSULT-II)

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.

SELECT SYSTEM
A/T
ENGINE



SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER




SELF-DIAG RESULTS
DTC RESULTS
T/C CLUTCH SOL/V

2. Turn CONSULT-II "ON", and touch "A/T".

3. Turn "SELF-DIAG RESULTS".

4. Touch "ERASE". (The DTC in the TCM will be erased.)



Touch "BACK".

Touch "BACK".

SELECT SYSTEM
A/T
ENGINE



SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SELF-DIAG RESULTS	
DTC RESULTS	TIME
TCC SOLENOID/CIRC [P0740]	0

5. Touch "ENGINE".

6. Touch "SELF-DIAG RESULTS".

7. Touch "ERASE". (The DTC in the ECM will be erased.)

SAT017K

Ⓢ HOW TO ERASE DTC (WITH GST)

NIAT0021S04

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
2. Perform "OBD-II Self-diagnostic Procedure (No Tools)". Refer to AT-52. (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)
3. Select Mode 4 with Generic Scan Tool (GST). For details, refer to **EC-125** [QG18DE (Except Calif. CA Model)], **EC-796** [QG18DE (Calif. CA Model)], **EC-1464** (SR20DE), "Generic Scan Tool (GST)".


Ⓝ HOW TO ERASE DTC (NO TOOLS)

NIAT0021S05

1. If the ignition switch stays "ON" after repair work, be sure to turn ignition switch "OFF" once. Wait at least 5 seconds and then turn it "ON" (engine stopped) again.
2. Perform "TCM/PCM Self-diagnostic Procedure (No Tools)". Refer to AT-52. (The engine warm-up step can be skipped when performing the diagnosis only to erase the DTC.)

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

Malfunction Indicator Lamp (MIL)



Malfunction Indicator Lamp (MIL)

^{=NIAT0022}

1. The malfunction indicator lamp will light up when the ignition switch is turned ON without the engine running. This is for checking the lamp.
 - If the malfunction indicator lamp does not light up, refer to "WARNING LAMPS", **EL-105**.
(Or see MIL & CONSULT-II in EC section. Refer to **EC-100** [QG18DE (Except Calif. CA Model)], **EC-772** [QG18DE (Calif. CA Model)], **EC-1440** (SR20DE), "Malfunction Indicator Lamp (MIL)", and **EC-107** [QG18DE (Except Calif. CA Model)], **EC-779** [QG18DE (Calif. CA Model)], **EC-1447** (SR20DE), "CONSULT-II".)
2. When the engine is started, the malfunction indicator lamp should go off.
If the lamp remains on, the on board diagnostic system has detected an emission-related (OBD-II) malfunction. For detail, refer to **EC-85** [QG18DE (Except Calif. CA Model)], **EC-758** [QG18DE (Calif. CA Model)], **EC-1426** (SR20DE), "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION".

CONSULT-II

^{NIAT0023}

After performing "SELF-DIAGNOSTIC PROCEDURE (WITH CONSULT-II)" (AT-43), place check marks for results on the "DIAGNOSTIC WORKSHEET", AT-61. Reference pages are provided following the items.

NOTICE:

- 1) The CONSULT-II electrically displays shift timing and lock-up timing (that is, operation timing of each solenoid).
Check for time difference between actual shift timing and the CONSULT-II display. If the difference is noticeable, mechanical parts (except solenoids, sensors, etc.) may be malfunctioning. Check mechanical parts using applicable diagnostic procedures.
- 2) Shift schedule (which implies gear position) displayed on CONSULT-II and that indicated in Service Manual may differ slightly. This occurs because of the following reasons:
 - Actual shift schedule has more or less tolerance or allowance,
 - Shift schedule indicated in Service Manual refers to the point where shifts start, and
 - Gear position displayed on CONSULT-II indicates the point where shifts are completed.
- 3) Shift solenoid valve "A" or "B" is displayed on CONSULT-II at the start of shifting. Gear position is displayed upon completion of shifting (which is computed by TCM/PCM).
- 4) Additional CONSULT-II information can be found in the Operation Manual supplied with the CONSULT-II unit.

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

SELECT SYSTEM	
A/T	
ENGINE	

SAT014K

④ SELF-DIAGNOSTIC PROCEDURE (WITH CONSULT-II) NIAT0023S01


- Turn on CONSULT-II and touch "ENGINE" for OBD-II detected items or touch "A/T" for TCM/PCM self-diagnosis.
If A/T is not displayed, check TCM/PCM power supply and ground circuit. Refer to AT-108 (QG18DE (Calif. CA Model) and SR20DE models) or AT-268 (QG18DE (Except Calif. CA Model)). If result is NG, refer to "POWER SUPPLY ROUTING", **EL-9**.
- Touch "SELF DIAG RESULTS".
Display shows malfunction experienced since the last erasing operation.
CONSULT-II performs "REAL TIME DIAG".
Also, any malfunction detected while in this mode will be displayed at real time.

SELF DIAG RESULTS	
DTC RESULTS	
T/C CLUTCH SCL/V	

SAT584J

SELF-DIAGNOSTIC RESULT TEST MODE

NIAT0023S02

Detected items (Screen terms for CONSULT-II, "SELF DIAGNOSIS" test mode)		Malfunction is detected when ...	TCM/PCM self-diagnosis	OBD-II (DTC)
"A/T"	"ENGINE"			 Available by O/D OFF indicator lamp or "A/T" on CONSULT-II
PNP switch circuit		● TCM/PCM does not receive the correct voltage signal (based on the gear position) from the switch.	—	P0705
—	PNP SW/CIRC			
Revolution sensor		● TCM/PCM does not receive the proper voltage signal from the sensor.	X	P0720
VHCL SPEED SEN-A/T	VEH SPD SEN/CIR AT			
Vehicle speed sensor (Meter)		● TCM/PCM does not receive the proper voltage signal from the sensor.	X	—
VHCL SPEED SEN-MTR	—			
A/T 1st gear function		● A/T cannot be shifted to the 1st gear position even if electrical circuit is good.	—	P0731*1
—	A/T 1ST GR FNCTN			
A/T 2nd gear function		● A/T cannot be shifted to the 2nd gear position even if electrical circuit is good.	—	P0732*1
—	A/T 2ND GR FNCTN			
A/T 3rd gear function		● A/T cannot be shifted to the 3rd gear position even if electrical circuit is good.	—	P0733*1
—	A/T 3RD GR FNCTN			

GI
MA
EM
LC
EC
FE
CL
MT

AT

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX



ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

Detected items (Screen terms for CONSULT-II, "SELF DIAGNOSIS" test mode)		Malfunction is detected when ...	TCM/PCM self-diagnosis	OBD-II (DTC)
			 Available by O/D OFF indicator lamp or "A/T" on CONSULT-II	 Available by malfunction indicator lamp*2, "ENGINE" on CON- SULT-II or GST
"A/T"	"ENGINE"			
A/T 4th gear function		● A/T cannot be shifted to the 4th gear position even if electrical circuit is good.	—	P0734*1
—	A/T 4TH GR FNCTN			
A/T TCC S/V function (lock-up)		● A/T cannot perform lock-up even if electrical circuit is good.	—	P0744*1
—	A/T TCC S/V FNCTN			
Shift solenoid valve A		● TCM/PCM detects an improper voltage drop when it tries to operate the solenoid valve.	X	P0750
SHIFT SOLENOID/V A	SFT SOL A/CIRC			
Shift solenoid valve B		● TCM/PCM detects an improper voltage drop when it tries to operate the solenoid valve.	X	P0755
SHIFT SOLENOID/V B	SFT SOL B/CIRC			
Overrun clutch solenoid valve		● TCM/PCM detects an improper voltage drop when it tries to operate the solenoid valve.	X	P1760
OVERRUN CLUTCH S/V	O/R CLUCH SOL/ CIRC			
T/C clutch solenoid valve		● TCM/PCM detects an improper voltage drop when it tries to operate the solenoid valve.	X	P0740
T/C CLUTCH SOL/V	TCC SOLENOID/ CIRC			
Line pressure solenoid valve		● TCM/PCM detects an improper voltage drop when it tries to operate the solenoid valve.	X	P0745
LINE PRESSURE S/V	L/PRESS SOL/ CIRC			
Throttle position sensor, Throttle position switch		● TCM/PCM receives an excessively low or high voltage from the sensor.	X	P1705
THROTTLE POSI SEN	TP SEN/CIRC A/T			
Engine speed signal		● TCM does not receive the proper voltage signal from the ECM or the PCM does not receive the proper voltage signal from the Tachometer.	X	P0725
ENGINE SPEED SIG				
A/T fluid temperature sensor		● TCM/PCM receives an excessively low or high voltage from the sensor.	X	P0710
BATT/FLUID TEMP SEN	ATF TEMP SEN/ CIRC			
TCM/PCM (RAM)		● TCM/PCM memory (RAM) is malfunctioning.	—	—
CONTROL UNIT (RAM)	—			
TCM/PCM (ROM)		● TCM/PCM memory (ROM) is malfunctioning.	—	—
CONTROL UNIT (ROM)	—			

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

Detected items (Screen terms for CONSULT-II, "SELF DIAGNOSIS" test mode)		Malfunction is detected when ...	TCM/PCM self-diagnosis	OBD-II (DTC)	GI
"A/T"	"ENGINE"		 Available by O/D OFF indicator lamp or "A/T" on CONSULT-II	 Available by malfunction indicator lamp*2, "ENGINE" on CON- SULT-II or GST	MA
TCM/PCM (EEP ROM)	CONT UNIT (EEP ROM)	<ul style="list-style-type: none"> TCM/PCM memory (EEP ROM) is malfunctioning. 	—	—	EM
Initial start	INITIAL START		<ul style="list-style-type: none"> This is not a malfunction message (Whenever shutting off a power supply to the TCM/PCM, this message appears on the screen.) 	X	—
No failure (NO SELF DIAGNOSTIC FAILURE INDICATED FURTHER TESTING MAY BE REQUIRED**)		<ul style="list-style-type: none"> No failure has been detected. 		X	X

X: Applicable

—: Not applicable

*1: These malfunctions cannot be displayed by MIL  if another malfunction is assigned to MIL.

*2: Refer to **EC-100** [QG18DE (Except Calif. CA Model)], **EC-772** [QG18DE (Calif. CA Model)], **EC-1440**, "Malfunction Indicator Lamp (MIL)".

DATA MONITOR MODE (A/T)

NIAT0023S03

Item	Display	Monitor item		Description	Remarks	AX
		ECU input signals	Main signals			SU
Vehicle speed sensor 1 (A/T) (Revolution sensor)	VHCL/S SE-A/T [km/h] or [mph]	X	—	<ul style="list-style-type: none"> Vehicle speed computed from signal of revolution sensor is displayed. 	When racing engine in "N" or "P" position with vehicle stationary, CONSULT-II data may not indicate 0 km/h (0 mph).	BR
Vehicle speed sensor 2 (Meter)	VHCL/S SE-MTR [km/h] or [mph]	X	—	<ul style="list-style-type: none"> Vehicle speed computed from signal of vehicle speed sensor is displayed. 	Vehicle speed display may not be accurate under approx. 10 km/h (6 mph). It may not indicate 0 km/h (0 mph) when vehicle is stationary.	ST
Throttle position sensor	THRTL POS SEN [V]	X	—	<ul style="list-style-type: none"> Throttle position sensor signal voltage is displayed. 		RS
A/T fluid temperature sensor	FLUID TEMP SE [V]	X	—	<ul style="list-style-type: none"> A/T fluid temperature sensor signal voltage is displayed. Signal voltage lowers as fluid temperature rises. 		BT
Battery voltage	BATTERY VOLT [V]	X	—	<ul style="list-style-type: none"> Source voltage of TCM/PCM is displayed. 		HA

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

Item	Display	Monitor item		Description	Remarks
		ECU input signals	Main signals		
Engine speed	ENGINE SPEED [rpm]	X	X	<ul style="list-style-type: none"> Engine speed, computed from engine speed signal, is displayed. 	Engine speed display may not be accurate under approx. 800 rpm. It may not indicate 0 rpm even when engine is not running.
Overdrive control switch	OVERDRIVE SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF state computed from signal of overdrive control SW is displayed. 	
P/N position switch	P/N POSI SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF state computed from signal of P/N position SW is displayed. 	
R position switch	R POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF state computed from signal of R position SW is displayed. 	
D position switch	D POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF state computed from signal of D position SW is displayed. 	
2 position switch	2 POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of 2 position SW, is displayed. 	
1 position switch	1 POSITION SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of 1 position SW, is displayed. 	
ASCD cruise signal	ASCD-CRUISE [ON/OFF]	X	—	<ul style="list-style-type: none"> Status of ASCD cruise signal is displayed. ON ... Cruising state OFF ... Normal running state 	<ul style="list-style-type: none"> This is displayed even when no ASCD is mounted.
ASCD OD cut signal	ASCD-OD CUT [ON/OFF]	X	—	<ul style="list-style-type: none"> Status of ASCD OD release signal is displayed. ON ... OD released OFF ... OD not released 	<ul style="list-style-type: none"> This is displayed even when no ASCD is mounted.
Kickdown switch	KICKDOWN SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of kickdown SW, is displayed. 	<ul style="list-style-type: none"> This is displayed even when no kickdown switch is equipped.
Closed throttle position switch	CLOSED THL/SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of closed throttle position SW, is displayed. 	
Wide open throttle position switch	W/O THRL/P-SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status, computed from signal of wide open throttle position SW, is displayed. 	
Gear position	GEAR	—	X	<ul style="list-style-type: none"> Gear position data used for computation by TCM/PCM, is displayed. 	

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

Item	Display	Monitor item		Description	Remarks
		ECU input signals	Main signals		
Selector lever position	SLCT LVR POSI	—	X	<ul style="list-style-type: none"> Selector lever position data, used for computation by TCM/PCM, is displayed. 	<ul style="list-style-type: none"> A specific value used for control is displayed if fail-safe is activated due to error.
Vehicle speed	VEHICLE SPEED [km/h] or [mph]	—	X	<ul style="list-style-type: none"> Vehicle speed data, used for computation by TCM/PCM, is displayed. 	
Stop lamp switch	BRAKE SW [ON/OFF]	X	—	<ul style="list-style-type: none"> ON/OFF status are displayed. ON: Brake pedal is depressed. OFF: Brake pedal is released. 	
Throttle position	THROTTLE POSI [8]	—	X	<ul style="list-style-type: none"> Throttle position data, used for computation by TCM/PCM, is displayed. 	<ul style="list-style-type: none"> A specific value used for control is displayed if fail-safe is activated due to error.
Line pressure duty	LINE PRES DTY [%]	—	X	<ul style="list-style-type: none"> Control value of line pressure solenoid valve, computed by TCM/PCM from each input signal, is displayed. 	
Torque converter clutch solenoid valve duty	TCC S/V DUTY [%]	—	X	<ul style="list-style-type: none"> Control value of torque converter clutch solenoid valve, computed by TCM/PCM from each input signal, is displayed. 	
Shift solenoid valve A	SHIFT S/V A [ON/OFF]	—	X	<ul style="list-style-type: none"> Control value of shift solenoid valve A, computed by TCM/PCM from each input signal, is displayed. 	Control value of solenoid is displayed even if solenoid circuit is disconnected. The "OFF" signal is displayed if solenoid circuit is shorted.
Shift solenoid valve B	SHIFT S/V B [ON/OFF]	—	X	<ul style="list-style-type: none"> Control value of shift solenoid valve B, computed by TCM/PCM from each input signal, is displayed. 	
Overrun clutch solenoid valve	OVERRUN/C S/V [ON/OFF]	—	X	<ul style="list-style-type: none"> Control value of overrun clutch solenoid valve computed by TCM/PCM from each input signal is displayed. 	
Self-diagnosis display lamp (O/D OFF indicator lamp)	SELF-D DP LMP [ON/OFF]	—	X	<ul style="list-style-type: none"> Control status of O/D OFF indicator lamp is displayed. 	

X: Applicable
 —: Not applicable

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)




DTC WORK SUPPORT MODE WITH CONSULT-II

NIAT0023S04


CONSULT-II Setting Procedure

NIAT0023S0401


1. Turn ignition switch "OFF".
2. Connect CONSULT-II to Data link connector which is located in left side lower dash panel.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "A/T".




6. Touch "DTC WORK SUPPORT".




7. Touch select item menu (1ST, 2ND, etc.).

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION


CONSULT-II (Cont'd)




8. Touch "START".




9. Perform driving test according to "DTC CONFIRMATION PROCEDURE" in "TROUBLE DIAGNOSIS FOR DTC".



• When testing conditions are satisfied, CONSULT-II screen changes from "OUT OF CONDITION" to "TESTING".



10. Stop vehicle. If "NG" appears on the screen, malfunction may exist. Go to "DIAGNOSTIC PROCEDURE".



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION


CONSULT-II (Cont'd)




11. Perform test drive to check gear shift feeling in accordance with instructions displayed.



12. Touch "YES" or "NO".



13. CONSULT-II procedure ended. If "NG" appears on the screen, a malfunction may exist. Go to "DIAGNOSTIC PROCEDURE".



DTC WORK SUPPORT MODE

NIAT0023S05

DTC work support item	Description	Check items (Possible cause)
1ST GR FNCTN P0731	<p>Following items for "A/T 1st gear function (P0731)" can be confirmed.</p> <ul style="list-style-type: none"> Self-diagnosis status (whether the diagnosis is being conducted or not) Self-diagnosis result (OK or NG) 	<ul style="list-style-type: none"> Shift solenoid valve A Shift solenoid valve B Each clutch Hydraulic control circuit

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

DTC work support item	Description	Check items (Possible cause)
2ND GR FNCTN P0732	Following items for "A/T 2nd gear function (P0732)" can be confirmed. <ul style="list-style-type: none"> ● Self-diagnosis status (whether the diagnosis is being conducted or not) ● Self-diagnosis result (OK or NG) 	<ul style="list-style-type: none"> ● Shift solenoid valve B ● Each clutch ● Hydraulic control circuit
3RD GR FNCTN P0733	Following items for "A/T 3rd gear function (P0733)" can be confirmed. <ul style="list-style-type: none"> ● Self-diagnosis status (whether the diagnosis is being conducted or not) ● Self-diagnosis result (OK or NG) 	<ul style="list-style-type: none"> ● Shift solenoid valve A ● Each clutch ● Hydraulic control circuit
4TH GR FNCTN P0734	Following items for "A/T 4th gear function (P0734)" can be confirmed. <ul style="list-style-type: none"> ● Self-diagnosis status (whether the diagnosis is being conducted or not) ● Self-diagnosis result (OK or NG) 	<ul style="list-style-type: none"> ● Shift solenoid valve A ● Shift solenoid valve B ● Overrun clutch solenoid valve ● Line pressure solenoid valve ● Each clutch ● Hydraulic control circuit
TCC S/V FNCTN P0744	Following items for "A/T TCC S/V function (lock-up) (P0744)" can be confirmed. <ul style="list-style-type: none"> ● Self-diagnosis status (whether the diagnosis is being conducted or not) ● Self-diagnosis result (OK or NG) 	<ul style="list-style-type: none"> ● Torque converter clutch solenoid valve ● Each clutch ● Hydraulic control circuit

DIAGNOSTIC PROCEDURE WITHOUT CONSULT-II

OBD-II Self-diagnostic Procedure (With GST)

NIAT0023S06

Refer to **EC-125** [QG18DE (Except Calif. CA Model)], **EC-796** [QG18DE (Calif. CA Model)], **EC-1464** (SR20DE), "Generic Scan Tool (GST)".

OBD-II Self-diagnostic Procedure (No Tools)

NIAT0023S0602

Refer to **EC-100** [QG18DE (Except Calif. CA Model)], **EC-772** [QG18DE (Calif. CA Model)], **EC-1440** (SR20DE), "Malfunction Indicator Lamp (MIL)".

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)



TCM/PCM Self-diagnostic Procedure (No Tools)

NIAT0023S0603


Preparation

1. Turn ignition switch to "OFF" position.
2. Connect the handy type vacuum pump to the throttle opener and apply vacuum -25.3 kPa (-190 mmHg, -7.48 inHg).
3. Disconnect the throttle position switch harness connector.
4. Turn ignition switch to "ON" position.
5. Check continuity of the closed throttle position switch.

Continuity should exist.




(If continuity does not exist, check throttle opener and closed throttle position switch. Then increase vacuum until closed throttle position switch shows continuity.)

6. Go to test group 1, "CHECK O/D OFF INDICATOR LAMP", AT-53.



ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)


1	CHECK O/D OFF INDICATOR LAMP	<p>1. Move A/T selector lever in "P" position. Start the engine. Warm engine to normal operating temperature.</p> <p>2. Turn ignition switch to "OFF" position.</p> <p>3. Wait 5 seconds.</p> <div style="text-align: center;">  </div> <p>4. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>5. Does O/D OFF indicator lamp come on for about 2 seconds?</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Without tachometer</p>  </div> <div style="text-align: center;"> <p>With tachometer</p>  </div> </div> <p style="text-align: right;">SAT967I</p>	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p>
Yes or No			
Yes	▶	GO TO 2.	
No	▶	Go to "1. O/D OFF Indicator Lamp Does Not Come On", AT-221 [QG18DE (Calif. CA Model) and SR20DE], AT-380 [QG18DE (Except Calif. CA Model)].	

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)


2 JUDGEMENT PROCEDURE STEP 1

1. Turn ignition switch to "OFF" position.
2. Turn ignition switch to "ACC" position.
3. Move A/T selector lever from "P" to "D" position.
4. Turn ignition switch to "ON" position.
(Do not start engine.)
5. Depress and hold overdrive control switch in "OFF" position (the O/D OFF indicator lamp will be "ON") until directed to release the switch.
If O/D OFF indicator lamp does not come on, go to "21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks)" on AT-259 [QG18DE (Calif. CA Model) and SR20DE], or "21. PCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks)" AT-418 [QG18DE (Except Calif. CA Model)].
6. Turn ignition switch to "OFF" position.



SAT968I

7. Turn ignition switch to "ON" position.
(Do not start engine.)
8. Release the overdrive control switch (the O/D OFF indicator lamp will be "OFF").
9. Wait 2 seconds.
10. Move A/T selector lever to "2" position.
11. Depress and release the overdrive control switch (the O/D OFF indicator lamp will be "ON").
12. Depress and hold the overdrive control switch (the O/D OFF indicator lamp will be "OFF") until directed to release the switch.



SAT969I

▶ GO TO 3.


ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


3 JUDGEMENT PROCEDURE STEP 2

1. Move A/T selector lever to "1" position.
2. Release the overdrive control switch.
3. Depress and release the overdrive control switch (the O/D OFF indicator lamp will be "ON").
4. Depress and release the overdrive control switch (the O/D OFF indicator lamp will be "OFF").
5. Depress and hold the overdrive control switch (the O/D OFF indicator lamp will be "ON") until directed to release the switch.



6. Depress accelerator pedal fully and release.

SAT970I



7. Release the overdrive control switch (the O/D OFF indicator lamp will begin to flash "ON" and "OFF").


SAT981F

▶ GO TO 4.


4 CHECK SELF-DIAGNOSIS CODE

Check O/D OFF indicator lamp. Refer to "Judgement of Self-diagnosis Code", AT-56.

Without tachometer



With tachometer



LAT154

▶ DIAGNOSIS END

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION


CONSULT-II (Cont'd)

Judgement of Self-diagnosis Code

NIAT0023S0604

O/D OFF indicator lamp:


All judgement flickers are the same.



SAT436F

All circuits that can be confirmed by self-diagnosis are OK.

1st judgement flicker is longer than others.




SAT437F

Revolution sensor circuit is short-circuited or disconnected.

⇒ Go to **VEHICLE SPEED SENSOR-A/T (REVOLUTION SENSOR)**, AT-126 [QG18DE (Calif. CA Model) and SR20DE], AT-286 [QG18DE (Except Calif. CA Model)].

2nd judgement flicker is longer than others.




SAT439F

Vehicle speed sensor circuit is short-circuited or disconnected.

⇒ Go to **VEHICLE SPEED SENSOR-MTR**, AT-210 [QG18DE (Calif. CA Model) and SR20DE], AT-369 [QG18DE (Except Calif. CA Model)].

3rd judgement flicker is longer than others.




SAT441F

Throttle position sensor circuit is short-circuited or disconnected.

⇒ Go to **THROTTLE POSITION SENSOR**, AT-191 [QG18DE (Calif. CA Model) and SR20DE], AT-351 [QG18DE (Except Calif. CA Model)].

4th judgement flicker is longer than others.




SAT443F

Shift solenoid valve A circuit is short-circuited or disconnected.

⇒ Go to **SHIFT SOLENOID VALVE A**, AT-183 [QG18DE (Calif. CA Model) and SR20DE], AT-343 [QG18DE (Except Calif. CA Model)].

5th judgement flicker is longer than others.



SAT445F

Shift solenoid valve B circuit is short-circuited or disconnected.


⇒ Go to **SHIFT SOLENOID VALVE B**, AT-187 [QG18DE (Calif. CA Model) and SR20DE], AT-347 [QG18DE (Except Calif. CA Model)].

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

O/D OFF indicator lamp:

6th judgement flicker is longer than others.




SAT447F

Overrun clutch solenoid valve circuit is short-circuited or disconnected.

⇒ Go to **VERRUN CLUTCH SOLENOID VALVE, AT-199 [QG18DE (Calif. CA Model) and SR20DE], AT-359 [QG18DE (Except Calif. CA Model)].**

7th judgement flicker is longer than others.




SAT449F

Torque converter clutch solenoid valve circuit is short-circuited or disconnected.

⇒ Go to **TORQUE CONVERTER CLUTCH SOLENOID VALVE, AT-163 [QG18DE (Calif. CA Model) and SR20DE], AT-323 [QG18DE (Except Calif. CA Model)].**

8th judgement flicker is longer than others.




SAT451F

A/T fluid temperature sensor is disconnected or TCM/PCM power source circuit is damaged.

⇒ Go to **DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE), AT-203 [QG18DE (Calif. CA Model) and SR20DE] or DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND PCM POWER SOURCE), AT-363 [QG18DE (Except Calif. CA Model)].**

9th judgement flicker is longer than others.




SAT453F

Engine speed signal circuit is short-circuited or disconnected.

⇒ Go to **ENGINE SPEED SIGNAL, AT-131 [QG18DE (Calif. CA Model) and SR20DE], AT-291 [QG18DE (Except Calif. CA Model)].**

10th judgement flicker is longer than others.




SAT455F

Line pressure solenoid valve circuit is short-circuited or disconnected.

⇒ Go to **LINE PRESSURE SOLENOID VALVE, AT-178 [QG18DE (Calif. CA Model) and SR20DE], AT-338 [QG18DE (Except Calif. CA Model)].**

Flickers as shown below.



SAT457F

Battery power is low.

Battery has been disconnected for a long time.

Battery is connected conversely.

(When reconnecting TCM/PCM connectors. — This is not a problem.)

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION

CONSULT-II (Cont'd)

O/D OFF indicator lamp:




Lamp comes on.



SAT367J

PNP switch, overdrive control switch or throttle position switch circuit is disconnected or TCM/PCM is damaged.
⇒ **Go to 21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks), AT-259 [QG18DE (Calif. CA Model) and SR20DE] or 21. PCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks), AT-418 [QG18DE (Except Calif. CA Model)].**

$t_1 = 2.5$ seconds $t_2 = 2.0$ seconds $t_3 = 1.0$ second $t_4 = 1.0$ second



Introduction

NIAT0024

The TCM/PCM receives a signal from the vehicle speed sensor, throttle position sensor or PNP switch and provides shift control or lock-up control via A/T solenoid valves.

The TCM also communicates with the ECM [QG18DE (Calif. CA Model) and SR20DE] by means of a signal sent from sensing elements used with the OBD-related parts of the A/T system for malfunction-diagnostic purposes. The TCM is capable of diagnosing malfunctioning parts while the ECM can store malfunctions in its memory.

Input and output signals must always be correct and stable in the operation of the A/T system. The A/T system must be in good operating condition and be free of valve seizure, solenoid valve malfunction, etc.

It is much more difficult to diagnose a problem that occurs intermittently rather than continuously. Most intermittent problems are caused by poor electric connections or improper wiring. In this case, careful checking of suspected circuits may help prevent the replacement of good parts.

A visual check only, may not find the cause of the problems. A road test with CONSULT-II (or GST) or a circuit tester connected should be performed. Follow the "Work Flow". Refer to AT-65.

Before undertaking actual checks, take a few minutes to talk with a customer who approaches with a driveability complaint. The customer can supply good information about such problems, especially intermittent ones. Find out what symptoms are present and under what conditions they occur. A "Diagnostic Worksheet" like the example (AT-61) should be used.

Start your diagnosis by looking for "conventional" problems first. This will help troubleshoot driveability problems on an electronically controlled engine vehicle.

Also check related Service bulletins for information.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSIS — INTRODUCTION

Introduction (Cont'd)

Diagnostic Worksheet

—NIAT0024S0102

1.	<input type="checkbox"/> Read the "FAIL-SAFE" and listen to customer complaints.	AT-10			
2.	<input type="checkbox"/> CHECK A/T FLUID	AT-68			
	<input type="checkbox"/> Leakage (Follow specified procedure) <input type="checkbox"/> Fluid condition <input type="checkbox"/> Fluid level				
3.	<input type="checkbox"/> Perform STALL TEST and LINE PRESSURE TEST.	AT-68, 72			
	<input type="checkbox"/> Stall test — Mark possible damaged components/others.				
	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 50%; vertical-align: top;"> <input type="checkbox"/> Torque converter one-way clutch <input type="checkbox"/> Reverse clutch <input type="checkbox"/> Forward clutch <input type="checkbox"/> Overrun clutch <input type="checkbox"/> Forward one-way clutch </td> <td style="width: 50%; vertical-align: top;"> <input type="checkbox"/> Low & reverse brake <input type="checkbox"/> Low one-way clutch <input type="checkbox"/> Engine <input type="checkbox"/> Line pressure is low <input type="checkbox"/> Clutches and brakes except high clutch and brake band are OK </td> </tr> </table>	<input type="checkbox"/> Torque converter one-way clutch <input type="checkbox"/> Reverse clutch <input type="checkbox"/> Forward clutch <input type="checkbox"/> Overrun clutch <input type="checkbox"/> Forward one-way clutch	<input type="checkbox"/> Low & reverse brake <input type="checkbox"/> Low one-way clutch <input type="checkbox"/> Engine <input type="checkbox"/> Line pressure is low <input type="checkbox"/> Clutches and brakes except high clutch and brake band are OK		
<input type="checkbox"/> Torque converter one-way clutch <input type="checkbox"/> Reverse clutch <input type="checkbox"/> Forward clutch <input type="checkbox"/> Overrun clutch <input type="checkbox"/> Forward one-way clutch	<input type="checkbox"/> Low & reverse brake <input type="checkbox"/> Low one-way clutch <input type="checkbox"/> Engine <input type="checkbox"/> Line pressure is low <input type="checkbox"/> Clutches and brakes except high clutch and brake band are OK				
	<input type="checkbox"/> Line Pressure test — Suspected parts:				

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSIS — INTRODUCTION

Introduction (Cont'd)

4.	<input type="checkbox"/> Perform all ROAD TEST and mark required procedures.	AT-73
4-1.	<p>Check before engine is started.</p> <p><input type="checkbox"/> SELF-DIAGNOSTIC PROCEDURE — Mark detected items.</p> <ul style="list-style-type: none"> <input type="checkbox"/> PNP switch, AT-115 [QG18DE (Calif. CA Model) and SR20DE], AT-275 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> A/T fluid temperature sensor, AT-120 [QG18DE (Calif. CA Model) and SR20DE], AT-280 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Vehicle speed sensor-A/T (Revolution sensor), AT-126 [QG18DE (Calif. CA Model) and SR20DE], AT-286 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Engine speed signal, AT-131 [QG18DE (Calif. CA Model) and SR20DE], AT-291 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Torque converter clutch solenoid valve, AT-163 [QG18DE (Calif. CA Model) and SR20DE], AT-323 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Line pressure solenoid valve, AT-178 [QG18DE (Calif. CA Model) and SR20DE], AT-338 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Shift solenoid valve A, AT-183 [QG18DE (Calif. CA Model) and SR20DE], AT-343 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Shift solenoid valve B, AT-187 [QG18DE (Calif. CA Model) and SR20DE], AT-347 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Throttle position sensor, AT-191 [QG18DE (Calif. CA Model) and SR20DE], AT-351 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Overrun clutch solenoid valve, AT-199 [QG18DE (Calif. CA Model) and SR20DE], AT-359 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> PNP, overdrive control and throttle position switches, AT-259 [QG18DE (Calif. CA Model) and SR20DE], AT-418 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> A/T fluid temperature sensor and TCM/PCM power source, AT-203 [QG18DE (Calif. CA Model) and SR20DE], AT-363 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Vehicle speed sensor-MTR, AT-210 [QG18DE (Calif. CA Model) and SR20DE], AT-369 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Control unit (RAM), control unit (ROM), AT-214 [QG18DE (Calif. CA Model) and SR20DE], AT-373 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Control unit (EEP ROM), AT-216 [QG18DE (Calif. CA Model) and SR20DE], AT-375 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Battery <input type="checkbox"/> Others 	AT-74
4-2.	<p>Check at idle</p> <ul style="list-style-type: none"> <input type="checkbox"/> 1. O/D OFF Indicator Lamp Does Not Come On, AT-221 [QG18DE (Calif. CA Model) and SR20DE], AT-380 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 2. Engine Cannot Be Started In "P" And "N" Position, AT-224 [QG18DE (Calif. CA Model) and SR20DE], AT-383 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 3. In "P" Position, Vehicle Moves Forward Or Backward When Pushed, AT-225 [QG18DE (Calif. CA Model) and SR20DE], AT-384 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 4. In "N" Position, Vehicle Moves, AT-226 [QG18DE (Calif. CA Model) and SR20DE], AT-385 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 5. Large Shock. "N" → "R" Position, AT-228 [QG18DE (Calif. CA Model) and SR20DE], AT-387 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 6. Vehicle Does Not Creep Backward In "R" Position, AT-230 [QG18DE (Calif. CA Model) and SR20DE], AT-389 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position, AT-233 [QG18DE (Calif. CA Model) and SR20DE], AT-392 [QG18DE (Except Calif. CA Model)]. 	AT-76

TROUBLE DIAGNOSIS — INTRODUCTION

Introduction (Cont'd)

4. (con t'd)	4-3 (con t'd)	Cruise test	AT-79 AT-83	
		Part-1 <input type="checkbox"/> 8. Vehicle Cannot Be Started From D ₁ , AT-236 [QG18DE (Calif. CA Model) and SR20DE], AT-395 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 9. A/T Does Not Shift: D ₁ → D ₂ Or Does Not Kickdown: D ₄ → D ₂ , AT-239 [QG18DE (Calif. CA Model) and SR20DE], AT-398 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 10. A/T Does Not Shift: D ₂ →D ₃ , AT-242 [QG18DE (Calif. CA Model) and SR20DE], AT-401 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 11. A/T Does Not Shift: D ₃ →D ₄ , AT-245 [QG18DE (Calif. CA Model) and SR20DE], AT-404 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 12. A/T Does Not Perform Lock-up, AT-248 [QG18DE (Calif. CA Model) and SR20DE], AT-407 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 13. A/T Does Not Hold Lock-up Condition, AT-250 [QG18DE (Calif. CA Model) and SR20DE], AT-409 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 14. Lock-up Is Not Released, AT-252 [QG18DE (Calif. CA Model) and SR20DE], AT-411 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 15. Engine Speed Does Not Return To Idle (Light Braking D ₄ → D ₃), AT-253 [QG18DE (Calif. CA Model) and SR20DE], AT-412 [QG18DE (Except Calif. CA Model)].		GI MA EM LC EC FE
		Part-2 <input type="checkbox"/> 16. Vehicle Does Not Start From D ₁ , AT-255 [QG18DE (Calif. CA Model) and SR20DE], AT-414 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 9. A/T Does Not Shift: D ₁ → D ₂ Or Does Not Kickdown: D ₄ → D ₂ , AT-239 [QG18DE (Calif. CA Model) and SR20DE], AT-398 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 10. A/T Does Not Shift: D ₂ →D ₃ , AT-242 [QG18DE (Calif. CA Model) and SR20DE], AT-401 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 11. A/T Does Not Shift: D ₃ →D ₄ , AT-245 [QG18DE (Calif. CA Model) and SR20DE], AT-404 [QG18DE (Except Calif. CA Model)].	AT-87	CL MT AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSIS — INTRODUCTION

Introduction (Cont'd)

4. (con t'd)	4-3 (con t'd)	Part-3 <input type="checkbox"/> 17. A/T Does Not Shift: $D_4 \rightarrow D_3$, When Overdrive Control Switch "ON" \rightarrow "OFF", AT-256 [QG18DE (Calif. CA Model) and SR20DE], AT-415 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 15. Engine Speed Does Not Return To Idle (Engine Brake In D_3), AT-253 [QG18DE (Calif. CA Model) and SR20DE], AT-412 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 18. A/T Does Not Shift: $D_3 \rightarrow 2_2$, When Selector Lever "D" \rightarrow "2" Position, AT-257 [QG18DE (Calif. CA Model) and SR20DE], AT-416 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 15. Engine Speed Does Not Return To Idle (Light Braking $D_4 \rightarrow D_2$), AT-253 [QG18DE (Calif. CA Model) and SR20DE], AT-412 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 19. A/T Does Not Shift: $2_2 \rightarrow 1_1$, When Selector Lever "2" \rightarrow "1" Position, AT-258 [QG18DE (Calif. CA Model) and SR20DE], AT-417 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> 20. Vehicle Does Not Decelerate By Engine Brake, AT-259 [QG18DE (Calif. CA Model) and SR20DE], AT-418 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> SELF-DIAGNOSTIC PROCEDURE — Mark detected items.	AT-89
		<input type="checkbox"/> PNP switch, AT-115 [QG18DE (Calif. CA Model) and SR20DE], AT-275 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> A/T fluid temperature sensor, AT-120 [QG18DE (Calif. CA Model) and SR20DE], AT-280 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Vehicle speed sensor-A/T (Revolution sensor), AT-126 [QG18DE (Calif. CA Model) and SR20DE], AT-286 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Engine speed signal, AT-131 [QG18DE (Calif. CA Model) and SR20DE], AT-291 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Torque converter clutch solenoid valve, AT-163 [QG18DE (Calif. CA Model) and SR20DE], AT-323 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Line pressure solenoid valve, AT-178 [QG18DE (Calif. CA Model) and SR20DE], AT-338 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Shift solenoid valve A, AT-183 [QG18DE (Calif. CA Model) and SR20DE], AT-343 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Shift solenoid valve B, AT-187 [QG18DE (Calif. CA Model) and SR20DE], AT-347 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Throttle position sensor, AT-191 [QG18DE (Calif. CA Model) and SR20DE], AT-351 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Overrun clutch solenoid valve, AT-199 [QG18DE (Calif. CA Model) and SR20DE], AT-359 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> PNP, overdrive control and throttle position switches, AT-259 [QG18DE (Calif. CA Model) and SR20DE], AT-418 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> A/T fluid temperature sensor and TCM/PCM power source, AT-203 [QG18DE (Calif. CA Model) and SR20DE], AT-363 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Vehicle speed sensor-MTR, AT-210 [QG18DE (Calif. CA Model) and SR20DE], AT-369 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Control unit (RAM), control unit (ROM), AT-214 [QG18DE (Calif. CA Model) and SR20DE], AT-373 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Control unit (EEP ROM), AT-216 [QG18DE (Calif. CA Model) and SR20DE], AT-375 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> Battery <input type="checkbox"/> Others	
5.		<input type="checkbox"/> For self-diagnosis NG items, inspect each component. Repair or replace the damaged parts.	AT-43
6.		<input type="checkbox"/> Perform all ROAD TEST and re-mark required procedures.	AT-73
7.		<input type="checkbox"/> Perform DTC CONFIRMATION PROCEDURE for following MIL indicating items and check out NG items. Refer to EC-86 [QG18DE (Except Calif. CA Model)], EC-759 [QG18DE (Calif. CA Model)], EC-1427 (SR20DE), "Emission-related Diagnostic Information".	EC section
		<input type="checkbox"/> DTC (P0731) A/T 1ST GEAR FUNCTION, AT-135 [QG18DE (Calif. CA Model) and SR20DE], AT-295 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> DTC (P0732) A/T 2ND GEAR FUNCTION, AT-142 [QG18DE (Calif. CA Model) and SR20DE], AT-302 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> DTC (P0733) A/T 3RD GEAR FUNCTION, AT-148 [QG18DE (Calif. CA Model) and SR20DE], AT-308 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> DTC (P0734) A/T 4TH GEAR FUNCTION, AT-154 [QG18DE (Calif. CA Model) and SR20DE], AT-314 [QG18DE (Except Calif. CA Model)]. <input type="checkbox"/> DTC (P0744) A/T TCC S/V FUNCTION (LOCK-UP), AT-163 [QG18DE (Calif. CA Model) and SR20DE], AT-323 [QG18DE (Except Calif. CA Model)].	

TROUBLE DIAGNOSIS — INTRODUCTION

Introduction (Cont'd)

8.	<input type="checkbox"/> Perform the Diagnostic Procedures for all remaining items marked NG. Repair or replace the damaged parts. Refer to the Symptom Chart when you perform the procedures. (The chart also shows some other possible symptoms and the component inspection orders.)	AT-108 [QG18DE (Calif. CA Model) and SR20DE], AT-268 [QG18DE (Except Calif. CA Model)] AT-93	GI MA EM
9.	<input type="checkbox"/> Erase DTC from TCM, ECM and PCM memories.	AT-40	LC

Work Flow

HOW TO PERFORM TROUBLE DIAGNOSES FOR QUICK AND ACCURATE REPAIR

NIAT0025

NIAT0025S01

A good understanding of the malfunction conditions can make troubleshooting faster and more accurate. In general, each customer feels differently about a problem. It is important to fully understand the symptoms or conditions for a customer complaint.

Make good use of the two sheets provided, "Information from Customer" (AT-60) and "Diagnostic Worksheet" (AT-61), to perform the best troubleshooting possible.

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

TROUBLE DIAGNOSIS — INTRODUCTION

Work Flow (Cont'd)

WORK FLOW CHART — QG18DE (CALIF. CA MODEL) AND SR20DE MODEL

NIAT0025S02



WAT300

*1: AT-60

*2: AT-61

*3: AT-10

*4: AT-68

*5: AT-68, 72

*6: AT-73

*7: AT-42

*8: AT-38

*9: AT-56

*10: AT-115

*11: AT-216

*12: AT-218

*13: AT-259

*14: AT-93

*15: AT-40

*16: AT-115

*17: AT-216


*18: **EC-759** [QG18DE (Calif. CA Model)], **EC-1427** (SR20DE),

TROUBLE DIAGNOSIS — INTRODUCTION

Work Flow (Cont'd)

WORK FLOW CHART — QG18DE (EXCEPT CALIF. CA MODEL)

NIAT0025S03



*1: AT-60

*2: AT-61

*3: AT-10

*4: AT-68

*5: AT-68, 72

*6: AT-73

*7: AT-42

*8: AT-38

*9: AT-56

*10: AT-275

*11: AT-375

*12: AT-377

*13: AT-418

*14: AT-93

*15: AT-40

*16: AT-275




*17: AT-375

*18: **EC-86** [QG18DE (Except Calif. CA Model)]

WAT156

TROUBLE DIAGNOSIS — BASIC INSPECTION

A/T Fluid Check



A/T Fluid Check

FLUID LEAKAGE CHECK

NIAT0026

NIAT0026S01

1. Clean area suspected of leaking. — for example, mating surface of converter housing and transmission case.
2. Start engine, apply foot brake, place selector lever in “D” position and wait a few minutes.
3. Stop engine.

4. Check for fresh leakage.

FLUID CONDITION CHECK


NIAT0026S02

Fluid color	Suspected problem
Dark or black with burned odor	Wear of frictional material
Milky pink	Water contamination — Road water entering through filler tube or breather
Varnished fluid, light to dark brown and tacky	Oxidation — Over or under filling, — Overheating

FLUID LEVEL CHECK

Refer to **MA-36**, “Checking A/T Fluid”.

NIAT0026S03



Stall Test

STALL TEST PROCEDURE

NIAT0027

NIAT0027S01




1. Check A/T fluid and engine oil levels. If necessary, add.
2. Drive vehicle for approx. 10 minutes or until fluid and oil reach operating temperature.

ATF operating temperature:

50 - 80°C (122 - 176°F)

TROUBLE DIAGNOSIS — BASIC INSPECTION

Stall Test (Cont'd)



3. Set parking brake and block wheels.
4. Install a tachometer where it can be seen by driver during test.
 - **It is good practice to mark the point of specified engine rpm on indicator.**

5. Start engine, apply foot brake, and place selector lever in D position.
6. Accelerate to wide open throttle gradually while applying foot brake.
7. Quickly note the engine stall revolution and immediately release throttle.
 - **During test, never hold throttle wide open for more than 5 seconds.**

Stall revolution:

QG18DE: 2,350 - 2,800 rpm

SR20DE: 2,350 - 2,850 rpm

8. Move selector lever to "N" position.
9. Cool off ATF.
 - **Run engine at idle for at least one minute.**
10. Repeat steps 5 through 9 with selector lever in "2", "1" and "R" positions.

JUDGEMENT OF STALL TEST

The test result and possible damaged components relating to each result are shown in the illustrations on next page.

In order to pinpoint the possible damaged components, follow the "Work Flow" shown in AT-65.

NOTE:

Stall revolution is too high in "D", "2" or "1" position:

- Slippage occurs in 1st gear but not in 2nd and 3rd gears. Low one-way clutch slippage
- Slippage occurs in the following gears:
 - 1st through 3rd gears in "D" position and engine brake functions with overdrive control switch set to "OFF".
 - 1st and 2nd gears in "2" position and engine brake functions with accelerator pedal released (fully closed throttle). Forward clutch or forward one-way clutch slippage

Stall revolution is too high in R position:

- Engine brake does not function in "1" position. Low & reverse brake slippage
- Engine brake functions in "1" position. Reverse clutch slippage

Stall revolution within specifications:

- Vehicle does not achieve speed of more than 80 km/h (50

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSIS — BASIC INSPECTION

Stall Test (Cont'd)

MPH). One-way clutch seizure in torque converter housing

CAUTION:

Be careful since automatic fluid temperature increases abnormally.

- Slippage occurs in 3rd and 4th gears in “D” position. High clutch slippage
- Slippage occurs in 2nd and 4th gear in “D” position. Brake band slippage
- Engine brake does not function in 2nd and 3rd gears in “D” position, 2nd gear in “2” position, and 1st gear in “1” position with overdrive control switch set to “OFF”.

Stall revolution less than specifications:

- Poor acceleration during starts. One-way clutch seizure in torque converter


TROUBLE DIAGNOSIS — BASIC INSPECTION

Stall Test (Cont'd)

Selector lever position	Judgement		
	H	O	L
D	H	O	L
2	H	O	L
1	H	O	L
R	O	H	L

O : Stall revolution is normal.
 H : Stall revolution is higher than specified.
 L : Stall revolution is lower than specified.

Damaged components



D	H	O
2	H	O
1	H	O
R	H	O
Selector lever position	Judgement	


Clutches and brakes except high clutch and brake band are OK. (Condition of high clutch and brake band cannot be confirmed by stall test.)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

SAT871HA

TROUBLE DIAGNOSIS — BASIC INSPECTION

Line Pressure Test



Line Pressure Test


LINE PRESSURE TEST PORTS

NIAT0028

NIAT0028S01

Location of line pressure test ports are shown in the illustration.

- Always replace pressure plugs as they are self-sealing bolts.




LINE PRESSURE TEST PROCEDURE

NIAT0028S02


1. Check A/T fluid and engine oil levels. If necessary, add fluid or oil.
2. Drive vehicle for approx. 10 minutes or until engine oil and ATF reach operating temperature.

ATF operating temperature:


50 - 80°C (122 - 176°F)



3. Install pressure gauge to corresponding line pressure port.



4. Set parking brake and block wheels.
 - Continue to depress brake pedal fully while line pressure test is being performed at stall speed.



5. Start engine and measure line pressure at idle and stall speed.
 - When measuring line pressure at stall speed, follow the stall test procedure.

Refer to "Line Pressure", AT-541.

TROUBLE DIAGNOSIS — BASIC INSPECTION

Line Pressure Test (Cont'd)

JUDGEMENT OF LINE PRESSURE TEST

NIAT002BS03

Judgement		Suspected parts
At idle	Line pressure is low in all positions.	<ul style="list-style-type: none"> ● Oil pump wear ● Control piston damage ● Pressure regulator valve or plug sticking ● Spring for pressure regulator valve damaged ● Fluid pressure leakage between oil strainer and pressure regulator valve ● Clogged strainer
	Line pressure is low in particular position.	<ul style="list-style-type: none"> ● Fluid pressure leakage between manual valve and particular clutch ● For example, line pressure is: <ul style="list-style-type: none"> – Low in "R" and "1" positions, but – Normal in "D" and "2" positions. Therefore, fluid leakage exists at or around low and reverse brake circuit. Refer to "CLUTCH AND BAND CHART", AT-22.
	Line pressure is high.	<ul style="list-style-type: none"> ● Maladjustment of throttle position sensor ● A/T fluid temperature sensor damaged ● Line pressure solenoid valve sticking ● Short circuit of line pressure solenoid valve circuit ● Pressure modifier valve sticking ● Pressure regulator valve or plug sticking ● Open in dropping resistor circuit
At stall speed	Line pressure is low.	<ul style="list-style-type: none"> ● Maladjustment of throttle position sensor ● Line pressure solenoid valve sticking ● Short circuit of line pressure solenoid valve circuit ● Pressure regulator valve or plug sticking ● Pressure modifier valve sticking ● Pilot valve sticking

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

ROAD TEST PROCEDURE

1. Check before engine is started.




2. Check at idle.



3. Cruise test.

SAT786A



SAT496G

Road Test DESCRIPTION

NIAT0029

NIAT0029S01

- The purpose of the test is to determine overall performance of A/T and analyze causes of problems.
- The road test consists of the following three parts:
 1. Check before engine is started
 2. Check at idle
 3. Cruise test
- Before road test, familiarize yourself with all test procedures and items to check.
- Conduct tests on all items until specified symptom is found. Troubleshoot items which check out No Good after road test. Refer to "ON BOARD DIAGNOSTIC SYSTEM DESCRIPTION", AT-38 - 56 and "TROUBLE DIAGNOSES FOR SYMPTOMS", AT-218 - 259 [QG18DE (Calif. CA Model) and SR20DE], AT-377 - 418 [QG18DE (Except Calif. CA Model)].

TROUBLE DIAGNOSIS — BASIC INSPECTION


Road Test (Cont'd)

1. CHECK BEFORE ENGINE IS STARTED

=NIAT0029S02

1 CHECK O/D OFF INDICATOR LAMP


1. Park vehicle on flat surface.
2. Move A/T selector lever to "P" position.




SAT9671

3. Turn ignition switch to "OFF" position. Wait at least 5 seconds.
4. Turn ignition switch to "ON" position. (Do not start engine.)
5. Does O/D OFF indicator lamp come on for about 2 seconds?

Without tachometer



With tachometer





LAT154

Yes or No

Yes	▶	GO TO 2.
No	▶	Stop ROAD TEST. Go to "1. O/D OFF Indicator Lamp Does Not Come On", AT-221 [QG18DE (Calif. CA Model) and SR20DE], AT-380 [QG18DE (Except Calif. CA Model)].

TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)

2	CHECK O/D OFF INDICATOR LAMP	
Does O/D OFF indicator lamp flicker for about 8 seconds?		
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Without tachometer</p>  <p>O/D OFF indicator lamp</p> </div> <div style="text-align: center;"> <p>With tachometer</p>  <p>O/D off indicator lamp</p> </div> </div> <p style="text-align: right;">LAT154</p>		
Yes or No		
Yes	▶	Perform self-diagnosis and check NG items on the "Diagnostic Worksheet", AT-61. Refer to "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52.
No	▶	<ol style="list-style-type: none"> 1. Turn ignition switch to "OFF" position. 2. Perform self-diagnosis and note NG items. Refer to "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 3. Go to "2. CHECK AT IDLE", AT-76.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)

2. CHECK AT IDLE


-NIAT0029S03


1	CHECK ENGINE START	
<p>1. Park vehicle on flat surface. 2. Move A/T selector lever to "P" position.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT769B</p> <p>3. Turn ignition switch to "OFF" position. 4. Turn ignition switch to "START" position. 5. Is engine started?</p> <p style="text-align: center;">Yes or No</p>		
Yes	▶	GO TO 2.
No	▶	Mark the box on the DIAGNOSTIC WORKSHEET. Go to "2. Engine Cannot Be Started In "P" and "N" Position", AT-224 [QG18DE (Calif. CA Model) and SR20DE], AT-383 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.

2	CHECK ENGINE START	
<p>1. Turn ignition switch to "ACC" position. 2. Move A/T selector lever to "D", "1", "2" or "R" position.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT770B</p> <p>3. Turn ignition switch to "START" position. 4. Is engine started?</p> <p style="text-align: center;">Yes or No</p>		
Yes	▶	Mark the box on the DIAGNOSTIC WORKSHEET. Go to "2. Engine Cannot Be Started In "P" and "N" Position", AT-224 [QG18DE (Calif. CA Model) and SR20DE], AT-383 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.
No	▶	GO TO 3.

TROUBLE DIAGNOSIS — BASIC INSPECTION


Road Test (Cont'd)



3	CHECK VEHICLE MOVE	<p>1. Move A/T selector lever to "P" position.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT768B</p> <p>2. Turn ignition switch to "OFF" position. 3. Release parking brake.</p>	GI MA EM LC EC FE
▶		GO TO 4.	

4	CHECK VEHICLE MOVE	<p>1. Push vehicle forward or backward. 2. Does vehicle move when it is pushed forward or backward?</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT796A</p> <p>3. Apply parking brake.</p> <p style="text-align: center;">Yes or No</p>	CL MT AT AX SU BR ST RS BT HA SC EL IDX
Yes	▶	Mark the box on the DIAGNOSTIC WORKSHEET. Go to "3. In "P" Position, Vehicle Moves Forward Or Backward When Pushed", AT-225 [QG18DE (Calif. CA Model) and SR20DE], AT-384 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.	
No	▶	GO TO 5.	

TROUBLE DIAGNOSIS — BASIC INSPECTION


Road Test (Cont'd)

5	CHECK VEHICLE MOVE	
<p>1. Start engine. 2. Move A/T selector lever to "N" position.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT771B</p> <p>3. Release parking brake. 4. Does vehicle move forward or backward?</p> <p style="text-align: center;">Yes or No</p>		
Yes	▶	Mark the box on the DIAGNOSTIC WORKSHEET. Go to "4. In "N" Position, Vehicle Moves", AT-226 [QG18DE (Calif. CA Model) and SR20DE], AT-385 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.
No	▶	GO TO 6.


6	CHECK SHIFT SHOCK	
<p>1. Apply foot brake.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT797A</p> <p>2. Move A/T selector lever to "R" position.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT772B</p> <p>3. Is there large shock when changing from "N" to "R" position?</p> <p style="text-align: center;">Yes or No</p>		
Yes	▶	Mark the box on the DIAGNOSTIC WORKSHEET. Go to "5. Large Shock "N" → "R" Position", AT-228 [QG18DE (Calif. CA Model) and SR20DE], AT-387 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.
No	▶	GO TO 7.

TROUBLE DIAGNOSIS — BASIC INSPECTION


Road Test (Cont'd)

7	CHECK VEHICLE MOVE	
1. Release foot brake for several seconds.		
		
SAT799A		
2. Does vehicle creep backward when foot brake is released?		
Yes or No		
Yes	▶	GO TO 8.
No	▶	Mark the box on the DIAGNOSTIC WORKSHEET. Go to "6. Vehicle Does Not Creep Backward In "R" Position", AT-230 [QG18DE (Calif. CA Model) and SR20DE], AT-389 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.

GI
MA
EM
LC
EC
FE
CL
MT

8	CHECK VEHICLE MOVE	
1. Move A/T selector lever to "D", "2" and "1" positions and check if vehicle creeps forward.		
		
SAT773B		
2. Does vehicle creep forward in all three positions?		
Yes or No		
Yes	▶	Go to 3. CRUISE TEST, AT-79.
No	▶	Mark the box on the DIAGNOSTIC WORKSHEET. Go to "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position", AT-233 [QG18DE (Calif. CA Model) and SR20DE], AT-392 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.

AT
AX
SU
BR
ST
RS
BT



3. CRUISE TEST

NIAT0029S04

- Check all items listed in Parts 1 through 3.

With CONSULT-II


NIAT0029S0401

- Using CONSULT-II, conduct a cruise test and record the result.
- Print the result and ensure that shifts and lock-ups take place as per Shift Schedule.

HA
SC
EL
IDX

TROUBLE DIAGNOSIS — BASIC INSPECTION


Road Test (Cont'd)




CONSULT-II Setting Procedure

NIAT0029S0402


1. Turn ignition switch "OFF".
2. Connect CONSULT-II to Data link connector which is located in left side lower dash panel.




3. Turn ignition switch "ON".
4. Touch "START".



5. Touch "A/T".



6. Touch "DATA MONITOR".



7. Touch "MAIN SIGNALS" or "ECU INPUT SIGNALS".
8. See "Numerical Display", "Barchart Display" or "Line Graph Display".

TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)

SET RECORDING CONDITION						
AUTO TRIG						
MANU TRIG						
TRIGGER POINT						
<<	<input type="text"/>	>>				
0%	20%	40%	60%	80%	100%	
Recording Speed						
MIN	MAX					
<<	<input type="text"/>	>>				
/64	/32	/16	/8	/4	/2	FULL

SAT973J

9. Touch "SETTING" to recording condition ("AUTO TRIG" or "MANU TRIG") and touch "BACK".
10. Touch "START".

DATA MONITOR	
MONITOR	NO DTC
ENGINE SPEED	XXX rpm
GEAR	XXX
SLCT LVR POSI	N/P
VEHICLE SPEED	XXX km/h
THROTTLE POSI	XXX

SAT985J

11. When performing cruise test, touch "RECORD".

DATA MONITOR		
Recording Data	X%	DTC DETECTED
ENGINE SPEED	XXX rpm	
GEAR	XXX	
SLCT LVR POSI	P/N	
VEHICLE SPEED	XXX km/h	
THROTTLE POSI	XXX	

SAT986J

12. After finishing cruise test part 1, touch "STOP".

REAL-TIME DIAG	
ENG SPEED SIG	

SAT987J

13. Touch "STORE" and touch "BACK".

STORE	
SYSTEM	SAVE REC DATA

SAT974J

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA




SC

EL

IDX


Cruise Test — Part 1


=NIAT0029S0404

1	CHECK STARTING GEAR (D₁) POSITION	<p>1. Drive vehicle for approx. 10 minutes to warm engine oil and ATF up to operating temperature. ATF operating temperature: 50 - 80°C (122 - 176°F)</p> <p>2. Park vehicle on flat surface. 3. Set overdrive control switch to "ON" position. 4. Move A/T selector lever to "P" position.</p> <div style="text-align: center;">  <p style="text-align: center;">OVERDRIVE ON/OFF ⇄</p> </div> <p style="text-align: right; margin-right: 20px;">SAT001J</p> <p>5. Start engine. 6. Move A/T selector lever to "D" position.</p> <div style="text-align: center;">  </div> <p style="text-align: right; margin-right: 20px;">SAT775B</p> <p>7. Accelerate vehicle by constantly depressing accelerator pedal halfway.</p> <div style="text-align: center;">  <p style="text-align: center;">Accelerator pedal Half-way</p> </div> <p style="text-align: right; margin-right: 20px;">SAT495G</p> <p>8. Does vehicle start from D₁? <input type="checkbox"/> Read gear position.</p> <p style="text-align: center;">Yes or No</p>	GI MA EM LC EC FE CL MT AT AX SU BR ST RS BT HA SC EL IDX
Yes	▶	GO TO 2.	
No	▶	Go to "8. Vehicle Cannot Be Started From D ₁ ", AT-236 [QG18DE (Calif. CA Model) and SR20DE], AT-395 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.	

TROUBLE DIAGNOSIS — BASIC INSPECTION


Road Test (Cont'd)

2	CHECK SHIFT UP (D₁ TO D₂)	<p>Does A/T shift from D₁ to D₂ at the specified speed?</p> <p>Ⓟ Read gear position, throttle opening and vehicle speed. Specified speed when shifting from D₁ to D₂: Refer to “Shift Schedule”, AT-540.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT954I</p> <p style="text-align: center;">Yes or No</p>	
Yes	▶	GO TO 3.	
No	▶	Go to “9. A/T Does Not Shift: D ₁ → D ₂ Or Does Not Kickdown: D ₄ → D ₂ ”, AT-239 [QG18DE (Calif. CA Model) and SR20DE], AT-398 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.	


3	CHECK SHIFT UP (D₂ TO D₃)	<p>Does A/T shift from D₂ to D₃ at the specified speed?</p> <p>Ⓟ Read gear position, throttle position and vehicle speed. Specified speed when shifting from D₂ to D₃: Refer to “Shift Schedule”, AT-540.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT955I</p> <p style="text-align: center;">Yes or No</p>	
Yes	▶	GO TO 4.	
No	▶	Go to “10. A/T Does Not Shift: D ₂ → D ₃ ”, AT-242 [QG18DE (Calif. CA Model) and SR20DE], AT-401 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.	

TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)

4	CHECK SHIFT UP (D₃ TO D₄)	
Does A/T shift from D ₃ to D ₄ at the specified speed? <input type="checkbox"/> Read gear position, throttle position and vehicle speed. Specified speed when shifting from D ₃ to D ₄ : Refer to "Shift Schedule", AT-540.		
		
Yes or No		
Yes	▶	GO TO 5.
No	▶	Go to "11. A/T Does Not Shift: D ₃ → D ₄ ", AT-245 [QG18DE (Calif. CA Model) and SR20DE], AT-404 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.

GI
 MA
 EM
 LC
 EC
 FE
 CL

5	CHECK LOCK-UP (D₄ TO D₄ L/U)	
Does A/T perform lock-up at the specified speed? <input type="checkbox"/> Read vehicle speed, throttle position when lock-up duty becomes 94%. Specified speed when lock-up occurs: Refer to Shift schedule, AT-540.		
		
Yes or No		
Yes	▶	GO TO 6.
No	▶	Go to "12. A/T Does Not Perform Lock-up", AT-248 [QG18DE (Calif. CA Model) and SR20DE], AT-407 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.

MT
 AT
 AX
 SU
 BR
 ST

6	CHECK HOLD LOCK-UP	
Does A/T hold lock-up condition for more than 30 seconds?		
Yes or No		
Yes	▶	GO TO 7.
No	▶	Go to "13. A/T Does Not Hold Lock-up Condition", AT-250 [QG18DE (Calif. CA Model) and SR20DE], AT-409 [QG18DE (Except Calif. CA Model)].

HA
 SC
 EL
 IDX

TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)

7	CHECK SHIFT DOWN (D₄ L/U TO D₄)	
<p>1. Release accelerator pedal. 2. Is lock-up released when accelerator pedal is released?</p> <div style="text-align: center;"> <p style="margin-left: 100px;"> Accelerator pedal Brake pedal Released Lightly applied </p> </div> <p style="text-align: right;">SAT958I</p>		
Yes or No		
Yes	▶	GO TO 8.
No	▶	Go to "14. Lock-up Is Not Released", AT-252 [QG18DE (Calif. CA Model) and SR20DE], AT-411 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.


8	CHECK SHIFT DOWN (D₄ TO D₃)	
<p>1. Decelerate vehicle by applying foot brake lightly. 2. Does engine speed return to idle smoothly when A/T is shifted from D₄ to D₃?</p> <p> Read gear position and engine speed.</p> <div style="text-align: center;"> <p style="margin-left: 100px;"> Accelerator pedal Brake pedal Released Lightly applied </p> </div> <p style="text-align: right;">SAT959I</p>		
Yes or No		
Yes	▶	1. Stop vehicle. 2. Go to "Cruise Test — Part 2", AT-87.
No	▶	Go to "15. Engine Speed Does Not Return To Idle (Light Braking D ₄ → D ₃)", AT-253 [QG18DE (Calif. CA Model) and SR20DE], AT-412 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.


TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)

Cruise Test — Part 2


—NIAT0029S0405



1	CHECK STARTING GEAR (D₁) POSITION	<p>1. Confirm overdrive control switch is in "ON" position. 2. Confirm A/T selector lever is in "D" position. 3. Accelerate vehicle by half throttle again. 4. Does vehicle start from D₁?</p> <p><input type="checkbox"/> Read gear position.</p> <div style="text-align: center;">  <p>Accelerator pedal Half-way</p> </div> <p style="text-align: right;">SAT495G</p>	GI MA EM LC EC FE CL MT
Yes or No			
Yes	▶	GO TO 2.	
No	▶	Go to "16. Vehicle Does Not Start From D ₁ ", AT-255 [QG18DE (Calif. CA Model) and SR20DE], AT-414 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.	

2	CHECK SHIFT UP AND SHIFT DOWN (D₃ TO D₄ TO D₂)	<p>1. Accelerate vehicle to 80 km/h (50 MPH) as shown in illustration. 2. Release accelerator pedal and then quickly depress it fully. 3. Does A/T shift from D₄ to D₂ as soon as accelerator pedal is depressed fully?</p> <p><input type="checkbox"/> Read gear position and throttle position.</p> <div style="text-align: center;">  <p>D₃ D₄ D₂</p> <p>80 km/h (50 MPH) Accelerator pedal Halfway</p> <p>Accelerator pedal Released</p> <p>Accelerator pedal Fully depressed</p> </div> <p style="text-align: right;">SAT404H</p>	AT AX SU BR ST RS BT HA SC EL IDX
Yes or No			
Yes	▶	GO TO 3.	
No	▶	Go to "9. A/T Does Not Shift: D ₁ → D ₂ Or Does Not Kickdown: D ₄ → D ₂ ", AT-239 [QG18DE (Calif. CA Model) and SR20DE], AT-398 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.	

TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)

3	CHECK SHIFT UP (D₂ TO D₃)	<p>Does A/T shift from D₂ to D₃ at the specified speed?</p> <p> Read gear position, throttle position and vehicle speed. Specified speed when shifting from D₂ to D₃: Refer to Shift schedule, AT-540.</p> <div style="text-align: center;">  <p>Accelerator pedal Fully depressed</p> </div> <p style="text-align: right;">SAT960I</p>
Yes or No		
Yes	▶	GO TO 4.
No	▶	Go to "10. A/T Does Not Shift: D ₂ → D ₃ ", AT-242 [QG18DE (Calif. CA Model) and SR20DE], AT-401 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.


4	CHECK SHIFT UP (D₃ TO D₄) AND ENGINE BRAKE	<p>Release accelerator pedal after shifting from D₂ to D₃.</p> <p>Does A/T shift from D₃ to D₄ and does vehicle decelerate by engine brake?</p> <p> Read gear position, throttle position and vehicle speed.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Accelerator pedal Fully depressed</p> </div> <div style="text-align: center;">  <p>Accelerator pedal Released</p> </div> </div> <p style="text-align: right;">SAT405H</p>
Yes or No		
Yes	▶	<ol style="list-style-type: none"> 1. Stop vehicle. 2. Go to "Cruise Test — Part 3", AT-89.
No	▶	Go to "11. A/T Does Not Shift: D ₃ → D ₄ ", AT-245 [QG18DE (Calif. CA Model) and SR20DE], AT-404 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.

TROUBLE DIAGNOSIS — BASIC INSPECTION



Road Test (Cont'd)

Cruise Test — Part 3

—NIAT0029S0406

1	VEHICLE SPEED D₄ POSITION	<p>1. Confirm overdrive control switch is in "ON" position. 2. Confirm selector lever is in "D" position. 3. Accelerate vehicle using half-throttle to D₄.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT812A</p>
▶		GO TO 2.



GI
MA
EM
LC
EC
FE
CL

2	CHECK SHIFT DOWN (D₄ TO D₃)	<p>1. Release accelerator pedal.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT813A</p> <p>2. Set overdrive control switch to "OFF" position while driving in D₄. 3. Does A/T shift from D₄ to D₃ (O/D OFF)? <input type="checkbox"/> Read gear position and vehicle speed.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT999I</p>
▶		Yes or No
Yes	▶	GO TO 3.
No	▶	Go to "17. A/T Does Not Shift: D ₄ → D ₃ , When Overdrive Control Switch "ON" → "OFF", AT-256 [QG18DE (Calif. CA Model) and SR20DE], AT-415 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.



MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)

3	CHECK ENGINE BRAKE		
Does vehicle decelerate by engine brake?			
			
Yes or No			
Yes	▶	GO TO 4.	
No	▶	Go to "15. Engine Speed Does Not Return To Idle (Light Braking D ₄ → D ₃)", AT-253 [QG18DE (Calif. CA Model) and SR20DE], AT-412 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.	


SAT999I

4	CHECK SHIFT DOWN (D₃ TO D₂)		
1. Move A/T selector lever from "D" to "2" position while driving in D ₃ (O/D OFF). 2. Does A/T shift from D ₃ (O/D OFF) to 2 ₂ ? ⓘ Read gear position.			
			
Yes or No			
Yes	▶	GO TO 5.	
No	▶	Go to "18. A/T Does Not Shift: D ₃ → D ₂ , When A/T Selector Lever "D" → "2" Position", AT-257 [QG18DE (Calif. CA Model) and SR20DE], AT-416 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.	


SAT791GA

TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)



5	CHECK ENGINE BRAKE	
Does vehicle decelerate by engine brake?		
<div style="display: flex; justify-content: space-around; align-items: center;">  <div style="text-align: center;"> <p>D₃ (OD OFF)</p> <p>↓</p> <p>2₂</p> <p>Engine brake</p> </div> </div>		
SAT791GA		
Yes or No		
Yes	▶	GO TO 6.
No	▶	Go to "15. Engine Speed Does Not Return To Idle (Light Braking D ₄ → D ₃)", AT-253 [QG18DE (Calif. CA Model) and SR20DE], AT-412 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

6	CHECK SHIFT DOWN	
1. Move A/T selector lever from "2" to "1" position while driving in 2 ₂ . 2. Does A/T shift from 2 ₂ to 1 ₁ position? ⓘ Read gear position.		
<div style="display: flex; justify-content: space-around; align-items: center;">  <div style="text-align: center;"> <p>2₂</p> <p>↓</p> <p>1₂</p> <p>↓</p> <p>1₁</p> <p>Engine brake</p> </div> </div>		
SAT778B		
Yes or No		
Yes	▶	GO TO 7.
No	▶	Go to "19. A/T Does Not Shift: 2 ₂ → 1 ₁ , When A/T Selector Lever "2" → "1" Position", AT-258 [QG18DE (Calif. CA Model) and SR20DE], AT-417 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.

TROUBLE DIAGNOSIS — BASIC INSPECTION

Road Test (Cont'd)

7	CHECK ENGINE BRAKE	
<p>Does vehicle decelerate by engine brake?</p> <div style="display: flex; justify-content: space-around; align-items: center;">   </div> <p style="text-align: right;">SAT778B</p>		
Yes or No		
Yes	▶	<ol style="list-style-type: none"> 1. Stop vehicle. 2. Perform self-diagnosis. Refer to "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52.
No	▶	<p>Go to "20. Vehicle Does Not Decelerate By Engine Brake", AT-259 [QG18DE (Calif. CA Model) and SR20DE], AT-418 [QG18DE (Except Calif. CA Model)]. Continue ROAD TEST.</p>

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart

Symptom Chart

NIAT0030

Numbers are arranged in order of inspection.

Perform inspections starting with number one and work up.

Symptom	Condition	Diagnostic Item	Reference Page			
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)	
Engine cannot start in "P" and "N" positions. AT-224, [QG18DE (Calif. CA Model) & SR20DE] or AT-383, [QG18DE (Except Calif. CA Model)]	ON vehicle	1. Ignition switch and starter	EL-9 , "POWER SUPPLY ROUTING" and SC-6 , "STARTING SYSTEM"			
		2. Control cable adjustment	AT-434			
		3. PNP switch adjustment	AT-434			
Engine starts in position other than "N" and "P" positions. AT-224, [QG18DE (Calif. CA Model) & SR20DE] or AT-383, [QG18DE (Except Calif. CA Model)]	ON vehicle	1. Control cable adjustment	AT-434			
		2. PNP switch adjustment	AT-434			
Transaxle noise in "P" and "N" positions.	ON vehicle	1. Fluid level	AT-68			
		2. Line pressure test	AT-72			
		3. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"	
		4. Vehicle speed sensor-A/T (Revolution sensor) and vehicle speed sensor-MTR	AT-126, AT-210		AT-286, AT-369	
		5. Engine speed signal	AT-131		AT-291	
	OFF vehicle	6. Oil pump	AT-461			
		7. Torque converter	AT-444			
Vehicle moves when changing into "P" position, or parking gear does not disengage when shifted out of "P" position. AT-225, [QG18DE (Calif. CA Model) & SR20DE] or AT-384, [QG18DE (Except Calif. CA Model)]	ON vehicle	1. Control cable adjustment	AT-434			
	OFF vehicle	2. Parking components	AT-439			
Vehicle moves in "N" position. AT-226, [QG18DE (Calif. CA Model) & SR20DE] or AT-385, [QG18DE (Except Calif. CA Model)]	ON vehicle	1. Control cable adjustment	AT-434			
	OFF vehicle	2. Forward clutch	AT-490			
		3. Reverse clutch	AT-481			
		4. Overrun clutch	AT-490			

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page		
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)
Vehicle will not run in "R" position (but runs in "D", "2" and "1" positions). Clutch slips. Very poor acceleration. AT-230, [QG18DE (Calif. CA Model) & SR20DE] or AT-389, [QG18DE (Except Calif. CA Model)]	ON vehicle	1. Control cable adjustment	AT-434		
		2. Line pressure test	AT-72		
		3. Line pressure solenoid valve	AT-178	AT-338	
		4. Control valve assembly	AT-465		
	OFF vehicle	5. Reverse clutch	AT-481		
		6. High clutch	AT-485		
		7. Forward clutch	AT-490		
		8. Overrun clutch	AT-490		
		9. Low & reverse brake	AT-497		
Vehicle braked when shifting into "R" position.	ON vehicle	1. Fluid level	AT-68		
		2. Control cable adjustment	AT-434		
		3. Line pressure test	AT-72		
		4. Line pressure solenoid valve	AT-178	AT-338	
		5. Control valve assembly	AT-465		
	OFF vehicle	6. High clutch	AT-485		
		7. Brake band	AT-510		
		8. Forward clutch	AT-490		
		9. Overrun clutch	AT-490		
Sharp shock in shifting from "N" to "D" position.	ON vehicle	1. Engine idling rpm	EC-747 , "Idle Speed/ Ignition Timing/Idle Mixture Ratio Adjust- ment"	EC-1411 , "Idle Speed/ Ignition Timing/Idle Mixture Ratio Adjust- ment"	EC-71 , "Idle Speed/ Ignition Timing/Idle Mixture Ratio Adjust- ment"
		2. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		3. Line pressure test	AT-72		
		4. A/T fluid temperature sensor	AT-120	AT-280	
		5. Engine speed signal	AT-131	AT-291	
		6. Line pressure solenoid valve	AT-178	AT-338	
		7. Control valve assembly	AT-465		
		8. Accumulator N-D	AT-465		
	OFF vehicle	9. Forward clutch	AT-490		
Vehicle will not run in "D" and "2" positions (but runs in "1" and "R" positions).	ON vehicle	1. Control cable adjustment	AT-434		
	OFF vehicle	2. Low one-way clutch	AT-439		

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page				
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)		
Vehicle will not run in "D", "1", "2" positions (but runs in "R" position). Clutch slips. Very poor acceleration. AT-233, [QG18DE (Calif. CA Model) & SR20DE] or AT-392, [QG18DE (Except Calif. CA Model)]	ON vehicle	1. Fluid level	AT-68			GI	
		2. Line pressure test	AT-72			MA	
		3. Line pressure solenoid valve	AT-178	AT-338		EM	
		4. Control valve assembly	AT-465			LC	
		5. Accumulator N-D	AT-465				
	OFF vehicle	6. Reverse clutch	AT-481			EC	
		7. High clutch	AT-485				
		8. Forward clutch	AT-490			FE	
		9. Forward one-way clutch	AT-501				
		10. Low one-way clutch	AT-439			CL	
Clutches or brakes slip somewhat in starting.	ON vehicle	1. Fluid level	AT-68			MT	
		2. Control cable adjustment	AT-434				
		3. Throttle position sensor (Adjustment)	EC-875, "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540, "DTC P0120 THROTTLE POSITION SENSOR"	EC-201, "DTC P0120 THROTTLE POSITION SENSOR"		AT
		4. Line pressure test	AT-72			AX	
		5. Line pressure solenoid valve	AT-178	AT-338		SU	
		6. Control valve assembly	AT-465				
		7. Accumulator N-D	AT-465			BR	
	OFF vehicle	8. Forward clutch	AT-490			ST	
		9. Reverse clutch	AT-481				
		10. Low & reverse brake	AT-497			RS	
		11. Oil pump	AT-461				
		12. Torque converter	AT-444			BT	
Excessive creep.	ON vehicle	1. Engine idling rpm	EC-747, "Idle Speed/ Ignition Timing/Idle Mixture Ratio Adjust- ment"	EC-1411, "Idle Speed/ Ignition Timing/Idle Mixture Ratio Adjust- ment"	EC-71, "Idle Speed/ Ignition Timing/Idle Mixture Ratio Adjust- ment"	HA	
No creep at all. AT-230, 233, [QG18DE (Calif. CA Model) and SR20DE] or AT-389, 392, [QG18DE (Except Calif. CA Model)]	ON vehicle	1. Fluid level	AT-68			EL	
		2. Line pressure test	AT-434				
		3. Control valve assembly	AT-465			IDX	
	OFF vehicle	4. Forward clutch	AT-490				
		5. Oil pump	AT-461				
		6. Torque converter	AT-444				

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page		
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)
Failure to change gear from "D ₁ " to "D ₂ ".	ON vehicle	1. PNP switch adjustment	AT-434		
		2. Control cable adjustment	AT-434		
		3. Shift solenoid valve A	AT-183	AT-343	
		4. Control valve assembly	AT-465		
		5. Vehicle speed sensor-A/T (Revolution sensor) and vehicle speed sensor-MTR	AT-126, AT-210	AT-286, AT-369	
	OFF vehicle	6. Brake band	AT-510		
Failure to change gear from "D ₂ " to "D ₃ ".	ON vehicle	1. PNP switch adjustment	AT-434		
		2. Control cable adjustment	AT-434		
		3. Shift solenoid valve B	AT-187	AT-347	
		4. Control valve assembly	AT-465		
		5. Vehicle speed sensor-A/T (Revolution sensor) and vehicle speed sensor-MTR	AT-126, AT-210	AT-286, AT-369	
	OFF vehicle	6. High clutch	AT-485		
		7. Brake band	AT-510		
Failure to change gear from "D ₃ " to "D ₄ ".	ON vehicle	1. PNP switch adjustment	AT-434		
		2. Control cable adjustment	AT-434		
		3. Shift solenoid valve A	AT-183	AT-343	
		4. Vehicle speed sensor-A/T (Revolution sensor) and vehicle speed sensor-MTR	AT-126, AT-210	AT-286, AT-369	
		5. A/T fluid temperature sensor	AT-120	AT-280	
	OFF vehicle	6. Brake band	AT-510		
Too high a gear change point from "D ₁ " to "D ₂ ", from "D ₂ " to "D ₃ ", from "D ₃ " to "D ₄ ". AT-239, AT-242, AT-245, [QG18DE (Calif. CA Model) & SR20DE] or AT-398, AT-401, AT-404, [QG18DE (Except Calif. CA Model)]	ON vehicle	1. Throttle position sensor (Adjustment)	EC-875, "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540, "DTC P0120 THROTTLE POSITION SENSOR"	EC-201, "DTC P0120 THROTTLE POSITION SENSOR"
		2. Vehicle speed sensor-A/T (Revolution sensor) and vehicle speed sensor-MTR	AT-126, AT-210		AT-286, AT-369
		3. Shift solenoid valve A	AT-183	AT-343	
		4. Shift solenoid valve B	AT-187	AT-347	
Gear change directly from "D ₁ " to "D ₃ " occurs.	ON vehicle	1. Fluid level	AT-68		
		2. Accumulator servo release	AT-465		
	OFF vehicle	3. Brake band	AT-510		

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page			
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)	
Engine stops when shifting lever into "R", "D", "2" and "1".	ON vehicle	1. Engine idling rpm	EC-747 , "Idle Speed/ Ignition Timing/Idle Mixture Ratio Adjust- ment"	EC-1411 , "Idle Speed/ Ignition Timing/Idle Mixture Ratio Adjust- ment"	EC-71 , "Idle Speed/ Ignition Timing/Idle Mixture Ratio Adjust- ment"	GI MA EM LC
		2. Torque converter clutch solenoid valve	AT-444			EC
		3. Control valve assembly	AT-465			FE
	OFF vehicle	4. Torque converter	AT-444			CL MT
	Too sharp a shock in change from "D ₁ " to "D ₂ ".	ON vehicle	1. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
2. Line pressure test			AT-72			AX
3. Accumulator servo release			AT-465			SU BR
4. Control valve assembly			AT-465			ST
OFF vehicle		5. A/T fluid temperature sensor	AT-120	AT-280		RS
Too sharp a shock in change from "D ₂ " to "D ₃ ".	ON vehicle	1. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"	BT HA
		2. Line pressure test	AT-72			SC
		3. Control valve assembly	AT-465			EL
	OFF vehicle	4. High clutch	AT-485			IDX
		5. Brake band	AT-510			
Too sharp a shock in change from "D ₃ " to "D ₄ ".	ON vehicle	1. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"	BT HA
		2. Line pressure test	AT-72			SC
		3. Control valve assembly	AT-465			EL
	OFF vehicle	4. Brake band	AT-510			IDX
		5. Overrun clutch	AT-501			

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page		
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)
Almost no shock or clutches slipping in change from "D ₁ " to "D ₂ ".	ON vehicle	1. Fluid level	AT-68		
		2. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		3. Line pressure test	AT-72		
		4. Accumulator servo release	AT-465		
		5. Control valve assembly	AT-465		
	OFF vehicle	6. Brake band	AT-510		
Almost no shock or slipping in change from "D ₂ " to "D ₃ ".	ON vehicle	1. Fluid level	AT-68		
		2. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		3. Line pressure test	AT-72		
		4. Control valve assembly	AT-465		
	OFF vehicle	5. High clutch	AT-485		
		6. Brake band	AT-510		
Almost no shock or slipping in change from "D ₃ " to "D ₄ ".	ON vehicle	1. Fluid level	AT-68		
		2. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		3. Line pressure test	AT-72		
		4. Control valve assembly	AT-465		
	OFF vehicle	5. High clutch	AT-485		
		6. Brake band	AT-510		
Vehicle braked by gear change from "D ₁ " to "D ₂ ".	ON vehicle	1. Fluid level	AT-68		
	OFF vehicle	2. Reverse clutch	AT-481		
		3. Low & reverse brake	AT-497		
		4. High clutch	AT-485		
		5. Low one-way clutch	AT-439		
Vehicle braked by gear change from "D ₂ " to "D ₃ ".	ON vehicle	1. Fluid level	AT-68		
	OFF vehicle	2. Brake band	AT-510		

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page			
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)	
Vehicle braked by gear change from "D ₃ " to "D ₄ ".	ON vehicle	1. Fluid level	AT-68			GI
	OFF vehicle	2. Overrun clutch	AT-490			MA
		3. Forward one-way clutch	AT-501			EM
		4. Reverse clutch	AT-481			LC
Maximum speed not attained. Acceleration poor.	ON vehicle	1. Fluid level	AT-68			EC
		2. PNP switch adjustment	AT-434			EC
		3. Shift solenoid valve A	AT-183	AT-343		FE
		4. Shift solenoid valve B	AT-187	AT-347		FE
		5. Control valve assembly	AT-465			CL
	OFF vehicle	6. Reverse clutch	AT-481			CL
		7. High clutch	AT-485			MT
		8. Brake band	AT-510			MT
		9. Low & reverse brake	AT-497			AT
		10. Oil pump	AT-461			AX
		11. Torque converter	AT-444			AX
Failure to change gear from "D ₄ " to "D ₃ ".	ON vehicle	1. Fluid level	AT-68			SU
		2. Throttle position sensor (Adjustment)	EC-875, "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540, "DTC P0120 THROTTLE POSITION SENSOR"	EC-201, "DTC P0120 THROTTLE POSITION SENSOR"	BR
		3. Overrun clutch solenoid valve	AT-199	AT-359		ST
		4. Shift solenoid valve A	AT-183	AT-343		RS
		5. Line pressure solenoid valve	AT-178	AT-338		RS
		6. Control valve assembly	AT-465			BT
	OFF vehicle	7. Low & reverse brake	AT-497			BT
		8. Overrun clutch	AT-490			HA
Failure to change gear from "D ₃ " to "D ₂ " or from "D ₄ " to "D ₂ ".	ON vehicle	1. Fluid level	AT-68			HA
		2. Throttle position sensor (Adjustment)	EC-875, "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540, "DTC P0120 THROTTLE POSITION SENSOR"	EC-201, "DTC P0120 THROTTLE POSITION SENSOR"	SC
		3. Shift solenoid valve A	AT-183	AT-343		EL
		4. Shift solenoid valve B	AT-187	AT-347		EL
		5. Control valve assembly	AT-465			IDX
	OFF vehicle	6. High clutch	AT-485			
		7. Brake band	AT-510			

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page		
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)
Failure to change gear from "D ₂ " to "D ₁ " or from "D ₃ " to "D ₁ ".	ON vehicle	1. Fluid level	AT-68		
		2. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		3. Shift solenoid valve A	AT-183		AT-343
		4. Shift solenoid valve B	AT-187		AT-347
		5. Control valve assembly	AT-465		
	OFF vehicle	6. Low one-way clutch	AT-439		
		7. High clutch	AT-485		
		8. Brake band	AT-510		
Gear change shock felt during deceleration by releasing accelerator pedal.	ON vehicle	1. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		2. Line pressure test	AT-72		
		3. Overrun clutch solenoid valve	AT-199		AT-359
		4. Control valve assembly	AT-465		
Too high a change point from "D ₄ " to "D ₃ ", from "D ₃ " to "D ₂ ", from "D ₂ " to "D ₁ ".	ON vehicle	1. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		2. Vehicle speed sensor-A/T (Revolution sensor) and vehicle speed sensor-MTR	AT-126, AT-210		AT-286, AT-369
Kickdown does not operate when depressing pedal in "D ₄ " within kickdown vehicle speed.	ON vehicle	1. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		2. Revolution sensor and vehicle speed sensor	AT-126, AT-210		AT-286, AT-369
		3. Shift solenoid valve A	AT-183		AT-343
		4. Shift solenoid valve B	AT-187		AT-347

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page			
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)	
Kickdown operates or engine overruns when depressing pedal in "D ₄ " beyond kick-down vehicle speed limit.	ON vehicle	1. Vehicle speed sensor-A/T (Revolution sensor) and vehicle speed sensor-MTR	AT-126, AT-210		AT-286, AT-369	GI MA EM
		2. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"	LC EC
		3. Shift solenoid valve A	AT-183		AT-343	
		4. Shift solenoid valve B	AT-187		AT-347	FE
Races extremely fast or slips in changing from "D ₄ " to "D ₃ " when depressing pedal.	ON vehicle	1. Fluid level	AT-68			
		2. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"	CL MT
		3. Line pressure test	AT-72			
		4. Line pressure solenoid valve	AT-178		AT-338	AT
		5. Control valve assembly	AT-465			AX
	OFF vehicle	6. High clutch	AT-485			
		7. Forward clutch	AT-490			SU
Races extremely fast or slips in changing from "D ₄ " to "D ₂ " when depressing pedal.	ON vehicle	1. Fluid level	AT-68			
		2. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"	BR ST
		3. Line pressure test	AT-72			
		4. Line pressure solenoid valve	AT-178		AT-338	RS
		5. Shift solenoid valve A	AT-183		AT-343	
		6. Control valve assembly	AT-465			BT
	OFF vehicle	7. Brake band	AT-510			HA
		8. Forward clutch	AT-490			SC EL IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page		
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)
Races extremely fast or slips in changing from "D ₃ " to "D ₂ " when depressing pedal.	ON vehicle	1. Fluid level	AT-68		
		2. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		3. Line pressure test	AT-72		
		4. Line pressure solenoid valve	AT-178	AT-338	
		5. Control valve assembly	AT-465		
		6. A/T fluid temperature sensor	AT-120	AT-280	
	OFF vehicle	7. Brake band	AT-510		
		8. Forward clutch	AT-490		
		9. High clutch	AT-485		
Races extremely fast or slips in changing from "D ₄ " or "D ₃ " to "D ₁ " when depressing pedal.	ON vehicle	1. Fluid level	AT-68		
		2. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		3. Line pressure test	AT-72		
		4. Line pressure solenoid valve	AT-178	AT-338	
		5. Control valve assembly	AT-465		
	OFF vehicle	6. Forward clutch	AT-490		
		7. Forward one-way clutch	AT-501		
		8. Low one-way clutch	AT-439		
Vehicle will not run in any position.	ON vehicle	1. Fluid level	AT-68		
		2. Control cable adjustment	AT-434		
		3. Line pressure test	AT-72		
		4. Line pressure solenoid valve	AT-178	AT-338	
	OFF vehicle	5. Oil pump	AT-461		
		6. High clutch	AT-485		
		7. Brake band	AT-510		
		8. Low & reverse brake	AT-497		
		9. Torque converter	AT-444		
		10. Parking components	AT-439		
Transmission noise in "D", "2", "1" and "R" positions.	ON vehicle	1. Fluid level	AT-68		
	OFF vehicle	2. Torque converter	AT-444		

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page		
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)
Failure to change from "D ₃ " to "2 ₂ " when changing lever into "2" position. AT-257, [QG18DE (Calif. CA Model) & SR20DE] or AT-416, [QG18DE (Except Calif. CA Model)]	ON vehicle	1. PNP switch adjustment	AT-434		
		2. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		3. Overrun clutch solenoid valve	AT-199		AT-359
		4. Shift solenoid valve B	AT-187		AT-347
		5. Shift solenoid valve A	AT-183		AT-343
		6. Control valve assembly	AT-465		
		7. Control cable adjustment	AT-434		
	OFF vehicle	8. Brake band	AT-510		
		9. Overrun clutch	AT-490		
Gear change from "2 ₂ " to "2 ₃ " in "2" position.	ON vehicle	1. PNP switch adjustment	AT-434		
Engine brake does not operate in "1" position. AT-258, [QG18DE (Calif. CA Model) & SR20DE] or AT-417, [QG18DE (Except Calif. CA Model)]	ON vehicle	1. PNP switch adjustment	AT-434		
		2. Control cable adjustment	AT-434		
		3. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		4. Vehicle speed sensor-A/T (Revolution sensor) and vehicle speed sensor-MTR	AT-126, AT-210		AT-286, AT-369
		5. Shift solenoid valve A	AT-183		AT-343
		6. Control valve assembly	AT-465		
		7. Overrun clutch solenoid valve	AT-199	AT-359	
	OFF vehicle	8. Overrun clutch	AT-501		
		9. Low & reverse brake	AT-497		
Gear change from "1 ₁ " to "1 ₂ " in "1" position.	ON vehicle	1. PNP switch adjustment	AT-434		
		2. Control cable adjustment	AT-434		

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page		
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)
Does not change from "1 ₂ " to "1 ₁ " in "1" position.	ON vehicle	1. PNP switch adjustment	AT-434		
		2. Vehicle speed sensor-A/T (Revolution sensor) and vehicle speed sensor-MTR	AT-126, AT-210		AT-286, AT-369
		3. Shift solenoid valve A	AT-183		AT-343
		4. Control valve assembly	AT-465		
		5. Overrun clutch solenoid valve	AT-199	AT-359	
	OFF vehicle	6. Overrun clutch	AT-490		
		7. Low & reverse brake	AT-497		
Large shock changing from "1 ₂ " to "1 ₁ " in "1" position.	ON vehicle	1. Control valve assembly	AT-465		
	OFF vehicle	2. Low & reverse brake	AT-497		
Transmission overheats.	ON vehicle	1. Fluid level	AT-68		
		2. Engine idling rpm	EC-747 , "Idle speed/ ignition timing/idle mixture ratio adjustment"	EC-1411 , "Idle speed/ ignition timing/idle mixture ratio adjustment"	EC-71 , "Idle speed/ ignition timing/idle mixture ratio adjustment"
		3. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		4. Line pressure test	AT-72		
		5. Line pressure solenoid valve	AT-178	AT-338	
		6. Control valve assembly	AT-465		
	OFF vehicle	7. Oil pump	AT-461		
		8. Reverse clutch	AT-481		
		9. High clutch	AT-485		
		10. Brake band	AT-510		
		11. Forward clutch	AT-490		
		12. Overrun clutch	AT-490		
		13. Low & reverse brake	AT-497		
		14. Torque converter	AT-444		

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page			
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)	
ATF shoots out during operation. White smoke emitted from exhaust pipe during operation.	ON vehicle	1. Fluid level	AT-68			GI
	OFF vehicle	2. Reverse clutch	AT-481			MA
		3. High clutch	AT-485			EM
		4. Brake band	AT-510			LC
		5. Forward clutch	AT-490			EC
		6. Overrun clutch	AT-490			FE
		7. Low & reverse brake	AT-497			CL
Offensive smell at fluid charging pipe.	ON vehicle	1. Fluid level	AT-68			MT
	OFF vehicle	2. Torque converter	AT-444			AT
		3. Oil pump	AT-461			AX
		4. Reverse clutch	AT-481			SU
		5. High clutch	AT-485			BR
		6. Brake band	AT-510			ST
		7. Forward clutch	AT-490			RS
		8. Overrun clutch	AT-490			BT
		9. Low & reverse brake	AT-497			HA
Torque converter is not locked up.	ON vehicle	1. Throttle position sensor (Adjustment)	<i>EC-875</i> , "DTC P0120 THROTTLE POSITION SENSOR"	<i>EC-1540</i> , "DTC P0120 THROTTLE POSITION SENSOR"	<i>EC-201</i> , "DTC P0120 THROTTLE POSITION SENSOR"	SC
		2. Vehicle speed sensor-A/T (Revolution sensor) and vehicle speed sensor-MTR	AT-126, AT-210		AT-286, AT-369	EL
		3. PNP switch adjustment	AT-434			IDX
		4. Engine speed signal	AT-131	AT-291		
		5. A/T fluid temperature sensor	AT-120	AT-280		
		6. Line pressure test	AT-72			
		7. Torque converter clutch solenoid valve	AT-163	AT-323		
		8. Control valve assembly	AT-465			
	OFF vehicle	9. Torque converter	AT-444			

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page		
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)
Torque converter clutch piston slip.	ON vehicle	1. Fluid level	AT-68		
		2. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		3. Line pressure test	AT-72		
		4. Torque converter clutch solenoid valve	AT-163	AT-323	
		5. Line pressure solenoid valve	AT-178	AT-338	
		6. Control valve assembly	AT-465		
	OFF vehicle	7. Torque converter	AT-444		
Lock-up point is extremely high or low. AT-248, [QG18DE (Calif. CA Model) & SR20DE] or AT-407, [QG18DE (Except Calif. CA Model)]	ON vehicle	1. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		2. Vehicle speed sensor-A/T (Revolution sensor) and vehicle speed sensor-MTR	AT-126, AT-210		AT-286, AT-369
		3. Torque converter clutch solenoid valve	AT-163	AT-323	
		4. Control valve assembly	AT-465		
A/T does not shift to "D ₄ " when driving with overdrive control switch "ON".	ON vehicle	1. Throttle position sensor (Adjustment)	EC-875 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-1540 , "DTC P0120 THROTTLE POSITION SENSOR"	EC-201 , "DTC P0120 THROTTLE POSITION SENSOR"
		2. PNP switch adjustment	AT-434		
		3. Vehicle speed sensor-A/T (Revolution sensor) and vehicle speed sensor-MTR	AT-126, AT-210		AT-286, AT-369
		4. Shift solenoid valve A	AT-183	AT-343	
		5. Overrun clutch solenoid valve	AT-199	AT-359	
		6. Control valve assembly	AT-465		
		7. A/T fluid temperature sensor	AT-120	AT-280	
		8. Line pressure test	AT-72		
	OFF vehicle	9. Brake band	AT-510		
		10. Overrun clutch	AT-490		

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION


Symptom Chart (Cont'd)

Symptom	Condition	Diagnostic Item	Reference Page			
			QG18DE (Calif. CA Model)	SR20DE	QG18DE (Except Calif. CA Model)	
Engine is stopped at "R", "D", "2" and "1" positions.	ON vehicle	1. Fluid level	AT-68			GI
		2. Torque converter clutch solenoid valve	AT-163		AT-323	MA
		3. Shift solenoid valve B	AT-187		AT-347	EM
		4. Shift solenoid valve A	AT-183		AT-343	LC
		5. Control valve assembly	AT-465			EC
					FE	
					CL	
					MT	
					AT	
					AX	
					SU	
					BR	
					ST	
					RS	
					BT	
					HA	
					SC	
					EL	
					IDX	

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

QG18DE (CALIF. CA) & SR20DE

TCM Terminals and Reference Value



TCM Terminals and Reference Value PREPARATION — QG18DE (CALIF. CA MODEL) & SR20DE


NIAT0033

NIAT0033S01

- Measure voltage between each terminal and terminal 25 or 48 by following "TCM INSPECTION TABLE".

TCM HARNESS CONNECTOR TERMINAL LAYOUT

NIAT0033S02



WAT158

TCM INSPECTION TABLE (Data are reference values.)










NIAT0033S03

Terminal No.	Wire color	Item	Condition	Judgement standard	
1	R/W	Line pressure solenoid valve		When releasing accelerator pedal after warming up engine.	1.5 - 3.0V
				When depressing accelerator pedal fully after warming up engine.	0.5V or less
2	P/B	Line pressure solenoid valve (with dropping resistor)		When releasing accelerator pedal after warming up engine.	5 - 14V
				When depressing accelerator pedal fully after warming up engine.	0.5V or less
3	GY/R	Torque converter clutch solenoid valve		When A/T performs lock-up.	8 - 15V
				When A/T does not perform lock-up.	1V or less
5 *2	Y/R	—		—	
6 *2	Y/G	—		—	
7 *2	Y/B	—		—	
8 *2	BR/W	—		—	
9 *2	G/Y	—		—	
10	BR/R	Power source		When turning ignition switch to "ON".	Battery voltage
				When turning ignition switch to "OFF".	1V or less

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

QG18DE (CALIF. CA) & SR20DE









TCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item	Condition	Judgement standard		
11	L/W	Shift solenoid valve A		When shift solenoid valve A operates. (When driving in "D ₁ " or "D ₄ ".)	Battery voltage	GI
				When shift solenoid valve A does not operate. (When driving in "D ₂ " or "D ₃ ".)	1V or less	MA
12	L/Y	Shift solenoid valve B		When shift solenoid valve B operates. (When driving in "D ₁ " or "D ₂ ".)	Battery voltage	EM
				When shift solenoid valve B does not operate. (When driving in "D ₃ " or "D ₄ ".)	1V or less	LC
13	G/R	O/D OFF indicator lamp		When setting overdrive control switch in "OFF" position.	1V or less	EC
				When setting overdrive control switch in "ON" position.	Battery voltage	FE
15 *2	PU	—	—	—	CL	
16	Y/PU	Closed throttle position switch (in throttle position switch)		When releasing accelerator pedal after warming up engine. Refer to "TCM/PCM SELF-DIAGNOSTIC PROCEDURE (No tools)", AT-52.	Battery voltage	MT
				When depressing accelerator pedal after warming up engine. Refer to "TCM/PCM SELF-DIAGNOSTIC PROCEDURE (No tools)", AT-52.	1V or less	AT
17	LG	Wide open throttle position switch (in throttle position switch)		When depressing accelerator pedal more than half-way after warming up engine.	Battery voltage	AX
				When releasing accelerator pedal after warming up engine.	1V or less	SU
18	OR	ASCD cruise switch		When ASCD cruise is being performed. ("CRUISE" light comes on.)	Battery voltage	BR
				When ASCD cruise is not being performed. ("CRUISE" light does not come on.)	1V or less	ST
19	BR/R	Power source		When turning ignition switch to "ON".	Battery voltage	RS
				When turning ignition switch to "OFF".	1V or less	BT
20	L/B	Overrun clutch solenoid valve		When overrun clutch solenoid valve operates.	Battery voltage	HA
				When overrun clutch solenoid valve does not operate.	1V or less	SC
22	OR/B	Overdrive control switch		When setting overdrive control switch in "ON" position	Battery voltage	EL
				When setting overdrive control switch in "OFF" position	1V or less	IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

QG18DE (CALIF. CA) & SR20DE




TCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item	Condition	Judgement standard	
24	W/PU	ASCD OD cut signal		When "ACCEL" set switch on ASCD cruise is in "D ₄ " position.	5 - 10V
				When "ACCEL" set switch on ASCD cruise is in "D ₃ " position.	Less than 2V
25	B	Ground	—	1V or less	
26	BR/Y	PNP switch "1" position		When setting selector lever to "1" position.	Battery voltage
				When setting selector lever to other positions.	1V or less
27	L	PNP switch "2" position		When setting selector lever to "2" position.	Battery voltage
				When setting selector lever to other positions.	1V or less
28	R/B	Power source (Memory back-up)	 or 	When turning ignition switch to "OFF".	Battery voltage
				When turning ignition switch to "ON".	Battery voltage
29	W	Revolution sensor		When moving at 20 km/h (12 MPH), use the CONSULT-II pulse frequency measuring function.*1 CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector. *1: A circuit tester cannot be used to test this item.	150Hz
				When vehicle parks.	Under 1.3V or over 4.5V
30 *3	G/B	—	—	—	
31 *3	GY/L	—	—	—	
32	R	Throttle position sensor (Power source)		When turning ignition switch to "ON".	4.5 - 5.5V
				When turning ignition switch to "OFF".	1V or less
34	W/G	PNP switch "D" position		When setting selector lever to "D" position.	Battery voltage
				When setting selector lever to other positions.	1V or less
35	G/W	PNP switch "R" position		When setting selector lever to "R" position.	Battery voltage
				When setting selector lever to other positions.	1V or less
36	G	PNP switch "N" or "P" position		When setting selector lever to "N" or "P" position.	Battery voltage
				When setting selector lever to other positions.	1V or less

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

QG18DE (CALIF. CA) & SR20DE

TCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item	Condition	Judgement standard	
39	L/OR	Engine speed signal	 Refer to EC-829 [QG18DE (Calif. CA Model)], EC-1496 (SR20DE), "ECM Inspection Table".	—	
40	PU/R	Vehicle speed sensor	 When moving vehicle at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more.	Voltage varies between less than 1V and more than 4.5V	
41	GY	Throttle position sensor		When depressing accelerator pedal slowly after warming up engine. (Voltage rises gradually in response to throttle position.)	
42	B	Throttle position sensor (Ground)		—	1V or less
45	R/G	Stop lamp switch		When depressing brake pedal.	Battery voltage
47	BR	A/T fluid temperature sensor	When ATF temperature is 20°C (68°F).	Approximately 1.5V	
			When ATF temperature is 80°C (176°F).	Approximately 0.5V	
48	B	Ground	—	1V or less	

*2: This terminal is connected to the ECM.

*3: These terminals are connected to the Data link connector.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSIS FOR POWER SUPPLY



QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — MAIN

Wiring Diagram — AT — MAIN

NIAT0034

AT-MAIN-01



WAT113

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
10	BR/R	POWER SOURCE	WHEN TURNING IGNITION SWITCH TO "ON" WHEN TURNING IGNITION SWITCH TO "OFF"	BATTERY VOLTAGE 1V OR LESS
19	BR/R	POWER SOURCE	WHEN TURNING IGNITION SWITCH TO "ON" WHEN TURNING IGNITION SWITCH TO "OFF"	BATTERY VOLTAGE 1V OR LESS
25	B	GROUND	—	1V OR LESS
28	R/B	POWER SOURCE (MEMORY BACKUP)	WHEN TURNING IGNITION SWITCH TO "OFF" WHEN TURNING IGNITION SWITCH TO "ON"	BATTERY VOLTAGE BATTERY VOLTAGE
48	B	GROUND	—	1V OR LESS

LAT254

TROUBLE DIAGNOSIS FOR POWER SUPPLY

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0330

1	CHECK TCM POWER SOURCE STEP 1	
<p>1. Turn ignition switch to ON position. (Do not start engine.)</p> <p>2. Check voltage between TCM terminals 10, 19, 28 and ground.</p>		
OK or NG		
OK	▶	GO TO 2.
NG	▶	GO TO 3.

GI
MA
EM
LC
EC
FE
CL

2	CHECK TCM POWER SOURCE STEP 2	
<p>1. Turn ignition switch to OFF position.</p> <p>2. Check voltage between TCM terminal 28 and ground.</p>		
OK or NG		
OK	▶	GO TO 4.
NG	▶	GO TO 3.

MT
AT
AX
SU
BR
ST
RS

3	DETECT MALFUNCTIONING ITEM	
<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between ignition switch and TCM terminals 10, 19 and 28 (Main harness) ● Fuse ● Ignition switch <p>Refer to EL-9, "POWER SUPPLY ROUTING".</p>		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace damaged parts.

BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS FOR POWER SUPPLY

QG18DE (CALIF. CA) & SR20DE


Diagnostic Procedure (Cont'd)

4	CHECK TCM GROUND CIRCUIT
<p>1. Turn ignition switch to OFF position. 2. Disconnect TCM harness connector. 3. Check continuity between TCM terminals 25, 48 and ground. Refer to wiring diagram, AT-112. Continuity should exist. If OK, check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ INSPECTION END
NG	▶ Repair open circuit or short to ground or short to power in harness connectors.

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH

QG18DE (CALIF. CA) & SR20DE

Description




Description

- The PNP switch assembly includes a transmission range switch. NIAT0035
- The transmission range switch detects the selector lever position and sends a signal to the TCM.

ON BOARD DIAGNOSIS LOGIC

NIAT0035S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : PNP SW/CIRC (S) : P0705	TCM does not receive the correct voltage signal from the switch based on the gear position.	<ul style="list-style-type: none"> • Harness or connectors (The PNP switch circuit is open or shorted.) • PNP switch



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0035S03

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.


After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 3) Start engine and maintain the following conditions for at least 5 consecutive seconds.
VHCL SPEED SE: 10 km/h (6 MPH) or more
THRTL POS SEN: More than 1.3V
Selector lever: D position (OD "ON" or "OFF")

(S) With GST

Follow the procedure "With CONSULT-II".



DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH





QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — PNP/SW

Wiring Diagram — AT — PNP/SW

NIAT0036

AT-PNP/SW-01



WAT114

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
26	BR/Y	PNP SWITCH "1" POSITION	WHEN SETTING SELECTOR LEVER TO "1" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
27	L	PNP SWITCH "2" POSITION	WHEN SETTING SELECTOR LEVER TO "2" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
34	W/G	PNP SWITCH "D" POSITION	WHEN SETTING SELECTOR LEVER TO "D" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
35	G/W	PNP SWITCH "R" POSITION	WHEN SETTING SELECTOR LEVER TO "R" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
36	G	PNP SWITCH "N" OR "P" POSITION	WHEN SETTING SELECTOR LEVER TO "N" OR "P" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS

LAT255

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0037

1	CHECK PNP SWITCH CIRCUIT (With CONSULT-II)															
	<p>With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 3. Read out "P/N", "R", "D", "2" and "1" position switches moving selector lever to each position. Check the signal of the selector lever position is indicated properly. 															
	<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: left;">MONITORING</th> <th></th> </tr> </thead> <tbody> <tr> <td>PN POSI SW</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td>R POSITION SW</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td>D POSITION SW</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td>2 POSITION SW</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>1 POSITION SW</td> <td style="text-align: center;">OFF</td> </tr> </tbody> </table>		DATA MONITOR		MONITORING		PN POSI SW	OFF	R POSITION SW	OFF	D POSITION SW	OFF	2 POSITION SW	ON	1 POSITION SW	OFF
DATA MONITOR																
MONITORING																
PN POSI SW	OFF															
R POSITION SW	OFF															
D POSITION SW	OFF															
2 POSITION SW	ON															
1 POSITION SW	OFF															
	SAT701J															
	OK or NG															
OK	▶	GO TO 3.														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● PNP switch Refer to "Component Inspection", AT-119. ● Harness for short or open between ignition switch and PNP switch (Main harness) ● Harness for short or open between PNP switch and TCM (Main harness) ● Ignition switch and fuse Refer to EL-9, "POWER SUPPLY ROUTING". ● Diode (P, N positions) 														

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

2 CHECK PNP SWITCH CIRCUIT (Without CONSULT-II)

⊗ Without CONSULT-II

1. Turn ignition switch to "ON" position.
(Do not start engine.)
2. Check voltage between TCM terminals 26, 27, 34, 35, 36 and ground while moving selector lever through each position.


Voltage:

B: Battery voltage

0: 0V

Lever position	Terminal No.				
	36	35	34	27	26
P, N	B	0	0	0	0
R	0	B	0	0	0
D	0	0	B	0	0
2	0	0	0	B	0
1	0	0	0	0	B

MTBL0136



SAT425J

OK or NG

OK ► GO TO 3.



- NG ► **Check the following items:**
- PNP switch
Refer to "Component Inspection", AT-119.
 - Harness for short or open between ignition switch and PNP switch (Main harness)
 - Harness for short or open between PNP switch and TCM (Main harness)
 - Ignition switch and fuse
Refer to **EL-9**, "POWER SUPPLY ROUTING".
 - Diode (P, N positions)

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

3	CHECK DTC	
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-115.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.



Component Inspection

PARK/NEUTRAL POSITION SWITCH

NIAT0038

NIAT0038S01

1. Check continuity between terminals 1 and 3 and between terminals 2 and 4, 5, 6, 7, 8, 9 while moving manual shaft through each position.

Lever position	Terminal No.	
P	3 — 7	1 — 2
R	3 — 8	
N	3 — 9	1 — 2
D	3 — 6	
2	3 — 5	
1	3 — 4	


2. If NG, check again with control cable disconnected from manual shaft of A/T assembly. Refer to step 1.
3. If OK on step 2, adjust control cable. Refer to AT-434.
4. If NG on step 2, remove PNP switch from A/T and check continuity of PNP switch terminals. Refer to step 1.
5. If OK on step 4, adjust PNP switch. Refer to AT-434.
6. If NG on step 4, replace PNP switch.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT


QG18DE (CALIF. CA) & SR20DE

Description



Description

The A/T fluid temperature sensor detects the A/T fluid temperature and sends a signal to the TCM. NIAT0039



CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NIAT0039S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
A/T fluid temperature sensor	Cold [20°C (68°F)]	Approximately 1.5V
	Hot [80°C (176°F)]	Approximately 0.5V

ON BOARD DIAGNOSIS LOGIC

NIAT0039S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : ATF TEMP SEN/CIRC (S) : P0710	TCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • A/T fluid temperature sensor

DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

QG18DE (CALIF. CA) & SR20DE

Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT020K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0039S04

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 2) Start engine and maintain the following conditions for at least 10 minutes (Total). (It is not necessary to maintain continuously.)

CMPS-RPM (REF): 450 rpm or more

VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: More than 1.2V

Selector lever: D position (OD "ON")

With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT



QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — FTS

Wiring Diagram — AT — FTS

NIAT0040

AT-FTS-01



REFER TO THE FOLLOWING.
F22 - ELECTRICAL UNITS

WAT115

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
42	B	THROTTLE POSITION SENSOR (GROUND)	—	1V OR LESS
47	BR	A/T FLUID TEMPERATURE SENSOR	WHEN ATF TEMPERATURE IS 20 ° C (68 ° F)	APPROX. 1.5V
			WHEN ATF TEMPERATURE IS 80 ° C (176 ° F)	APPROX. 0.5V

LAT256

DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0041

1	INSPECTION START	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

GI
MA
EM

2	CHECK INPUT SIGNAL OF A/T FLUID TEMPERATURE SENSOR (With CONSULT-II)															
<p>📄 With CONSULT-II</p> <p>1. Start engine.</p> <p>2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.</p> <p>3. Read out the value of "FLUID TEMP SE".</p> <p style="color: blue;">Voltage: Cold [20°C (68°F)] → Hot [80°C (176°F)]: Approximately 1.5V → 0.5V</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th></th> </tr> </thead> <tbody> <tr> <td>VHCL/S SE-A/T</td> <td>XXX km/h</td> </tr> <tr> <td>VHCL/S SE-MTR</td> <td>XXX km/h</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td>FLUID TEMP SE</td> <td>XXX V</td> </tr> <tr> <td>BATTERY VOLT</td> <td>XXX V</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		VHCL/S SE-A/T	XXX km/h	VHCL/S SE-MTR	XXX km/h	THRTL POS SEN	XXX V	FLUID TEMP SE	XXX V	BATTERY VOLT	XXX V
DATA MONITOR																
MONITORING																
VHCL/S SE-A/T	XXX km/h															
VHCL/S SE-MTR	XXX km/h															
THRTL POS SEN	XXX V															
FLUID TEMP SE	XXX V															
BATTERY VOLT	XXX V															
OK or NG																
OK	▶	GO TO 4.														
NG	▶	GO TO 5.														

LC
EC
FE
CL
MT
AT
AX

SAT614J

SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)


3	CHECK INPUT SIGNAL OF A/T FLUID TEMPERATURE SENSOR (Without CONSULT-II)						
<p>⊗ Without CONSULT-II</p> <p>1. Start engine.</p> <p>2. Check voltage between TCM terminal 47 and ground while warming up A/T.</p> <p style="color: blue;">Voltage: Cold [20°C (68°F)] → Hot [80°C (176°F)]: Approximately 1.5V → 0.5V</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SAT937J</p> <p>3. Turn ignition switch to "OFF" position.</p> <p>4. Disconnect TCM harness connector.</p> <p>5. Check continuity between terminal 42 and ground.</p> <p style="color: blue;">Continuity should exist.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SAT421J</p> <p>If OK, check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p> <table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 20%;">OK</td> <td style="width: 5%; text-align: center;">▶</td> <td>GO TO 4.</td> </tr> <tr> <td>NG</td> <td style="text-align: center;">▶</td> <td>GO TO 5.</td> </tr> </table>		OK	▶	GO TO 4.	NG	▶	GO TO 5.
OK	▶	GO TO 4.					
NG	▶	GO TO 5.					

4	CHECK DTC	
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-121.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform TCM input/output signal inspection.</p> <p>2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.</p>


DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

5	CHECK A/T FLUID TEMPERATURE SENSOR WITH TERMINAL CORD ASSEMBLY	
<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminals 6 and 7 when A/T is cold.</p>		
		
<p>Resistance: Cold [20°C (68°F)] Approximately 2.5 kΩ</p>		
<p>4. Reinstall any part removed.</p>		
LAT160		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	<p>1. Remove oil pan. 2. Check the following items:</p> <ul style="list-style-type: none"> ● A/T fluid temperature sensor Refer to "Component Inspection", AT-125. ● Harness of terminal cord assembly for short or open

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



Component Inspection A/T FLUID TEMPERATURE SENSOR

NIAT0042
NIAT0042S01


- For removal, refer to AT-433.
- Check resistance between two terminals while changing temperature as shown at left.

Temperature °C (°F)	Resistance
20 (68)	Approximately 2.5 kΩ
80 (176)	Approximately 0.3 kΩ

DTC P0720 VEHICLE SPEED SENSOR-AT (REVOLUTION SENSOR)

QG18DE (CALIF. CA) & SR20DE

Description



Description

The revolution sensor detects the revolution of the idler gear parking pawl lock gear and emits a pulse signal. The pulse signal is sent to the TCM which converts it into vehicle speed. NIAT0043

ON BOARD DIAGNOSIS LOGIC

NIAT0043S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : VEH SPD SEN/CIR AT (P) : P0720	TCM does not receive the proper voltage signal from the sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Revolution sensor

DTC P0720 VEHICLE SPEED SENSOR-A/T (REVOLUTION SENSOR)

QG18DE (CALIF. CA) & SR20DE

Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT020K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0043S03

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- Turn ignition switch "ON" and select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- Drive vehicle and check for an increase of "VHCL/S SE-MTR" value increase.
If the check result is NG, go to "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-211.
If the check result is OK, go to following step.

- Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.

- Start engine and maintain the following conditions for at least 5 consecutive seconds.

VHCL SPEED SE: 30 km/h (19 MPH) or more

THRTL POS SEN: More than 1.2V

Selector lever: D position (OD "ON")

Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

If the check result is NG, go to "Diagnostic Procedure", AT-129.
If the check result is OK, go to following step.

- Maintain the following conditions for at least 5 consecutive seconds.

CMPS-RPM (REF): 3,500 rpm or more

THRTL POS SEN: More than 1.2V

Selector lever: D position (OD "ON")

Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

With GST

Follow the procedure "With CONSULT-II".

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0720 VEHICLE SPEED SENSOR-A/T (REVOLUTION SENSOR)



QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — VSSA/T

Wiring Diagram — AT — VSSA/T

NIAT0044

AT-VSSA/T-01



REFER TO THE FOLLOWING.
F22 - ELECTRICAL UNITS

WAT116

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
10	BR/R	POWER SOURCE	WHEN TURNING IGNITION SWITCH TO "ON" WHEN TURNING IGNITION SWITCH TO "OFF"	BATTERY VOLTAGE 1V OR LESS
29	W	REVOLUTION SENSOR	WHEN MOVING AT 20 KM/H (12 MPH), USE THE CONSULT-II PULSE FREQUENCY MEASURING FUNCTION	150 Hz
42	B	THROTTLE POSITION SENSOR (GROUND)	—	1V OR LESS

LAT257

DTC P0720 VEHICLE SPEED SENSOR-A/T (REVOLUTION SENSOR)

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0045

1	CHECK INPUT SIGNAL (With CONSULT-II)															
<p>With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 3. Read out the value of "VHCL/S SE-A/T" while driving. Check the value changes according to driving speed. 																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th></th> </tr> </thead> <tbody> <tr> <td>VHCL/S SE-A/T</td> <td>XXX km/h</td> </tr> <tr> <td>VHCL/S SE-MTR</td> <td>XXX km/h</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td>FLUID TEMP SE</td> <td>XXX V</td> </tr> <tr> <td>BATTERY VOLT</td> <td>XXX V</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		VHCL/S SE-A/T	XXX km/h	VHCL/S SE-MTR	XXX km/h	THRTL POS SEN	XXX V	FLUID TEMP SE	XXX V	BATTERY VOLT	XXX V
DATA MONITOR																
MONITORING																
VHCL/S SE-A/T	XXX km/h															
VHCL/S SE-MTR	XXX km/h															
THRTL POS SEN	XXX V															
FLUID TEMP SE	XXX V															
BATTERY VOLT	XXX V															
SAT614J																
OK or NG																
OK	▶	GO TO 3.														
NG	▶	GO TO 2.														

GI
MA
EM
LC
EC
FE
CL
MT

2	CHECK REVOLUTION SENSOR (With CONSULT-II)							
<p>With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Condition</th> <th>Judgement standard using "TCM TERMINALS AND REFERENCE VALUE"</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;"> When moving at 20 km/h (12 MPH, use the CONSULT-II pulse frequency measuring function. *1 CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector. *1: A circuit tester cannot be used to test this item. </td> <td style="text-align: center; vertical-align: middle;">150 Hz</td> </tr> <tr> <td style="padding: 5px;">When vehicle is not moving</td> <td style="text-align: center;">Under 1.3V or over 4.5V</td> </tr> </tbody> </table>			Condition	Judgement standard using "TCM TERMINALS AND REFERENCE VALUE"	When moving at 20 km/h (12 MPH, use the CONSULT-II pulse frequency measuring function. *1 CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector. *1: A circuit tester cannot be used to test this item.	150 Hz	When vehicle is not moving	Under 1.3V or over 4.5V
Condition	Judgement standard using "TCM TERMINALS AND REFERENCE VALUE"							
When moving at 20 km/h (12 MPH, use the CONSULT-II pulse frequency measuring function. *1 CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector. *1: A circuit tester cannot be used to test this item.	150 Hz							
When vehicle is not moving	Under 1.3V or over 4.5V							
LAT238								
<ul style="list-style-type: none"> ● Harness for short or open between TCM, ECM and revolution sensor (Main harness). Refer to wiring diagram, AT-128. 								
OK or NG								
OK	▶	GO TO 3.						
NG	▶	Repair or replace damaged parts.						

AT
AX
SU
BR
ST
RS
BT
HA

3	CHECK DTC	
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-127.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	GO TO 4.

SC
EL
IDX

DTC P0720 VEHICLE SPEED SENSOR-A/T (REVOLUTION SENSOR)

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

4	CHECK TCM INSPECTION
1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Repair or replace damaged parts.

DTC P0725 ENGINE SPEED SIGNAL

QG18DE (CALIF. CA) & SR20DE

Description

Description

The engine speed signal is sent from the ECM to the TCM. NIAT0047

ON BOARD DIAGNOSIS LOGIC

NIAT0047S02

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
: ENGINE SPEED SIG	TCM does not receive the proper voltage signal from ECM.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.)
: P0725		

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT020K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0047S03

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- Start engine and maintain the following conditions for at least 10 consecutive seconds.

VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: More than 1.2V

Selector lever: D position (OD "ON")

With GST

Follow the procedure "With CONSULT-II".

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0725 ENGINE SPEED SIGNAL



QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — ENGSS

Wiring Diagram — AT — ENGSS

NIAT0048

AT-ENGSS-01



REFER TO THE FOLLOWING.
 (F22) - ELECTRICAL UNITS

WAT117

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
39	L/OR	ENGINE SPEED SIGNAL	REFER TO ECM INSPECTION TABLE	—

LAT258

DTC P0725 ENGINE SPEED SIGNAL

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0049

1	CHECK DTC WITH ECM	
Perform diagnostic test mode II (self- diagnostic results) for engine control. Check ignition signal circuit condition.		
OK or NG		
OK (With CONSULT-II) ▶	GO TO 2.	
OK (Without CONSULT-II) ▶	GO TO 3.	
NG ▶	Check ignition signal circuit for engine control. Refer to EC-1233 [QG18DE (Calif. CA Model)], EC-1820 (SR20DE), "DTC P1320 IGNITION SIGNAL".	

GI
MA
EM
LC

2	CHECK INPUT SIGNAL (With CONSULT-II)															
<p>Ⓜ With CONSULT-II</p> <p>1. Start engine.</p> <p>2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.</p> <p>3. Read out the value of "ENGINE SPEED".</p> <p>Check engine speed changes according to throttle position.</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITORING</th> <th style="text-align: center;"></th> </tr> </thead> <tbody> <tr> <td>ENGINE SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>TURBINE REV</td> <td>XXX rpm</td> </tr> <tr> <td>OVERDRIVE SW</td> <td>ON</td> </tr> <tr> <td>PN POSI SW</td> <td>OFF</td> </tr> <tr> <td>R POSITION SW</td> <td>OFF</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		ENGINE SPEED	XXX rpm	TURBINE REV	XXX rpm	OVERDRIVE SW	ON	PN POSI SW	OFF	R POSITION SW	OFF
DATA MONITOR																
MONITORING																
ENGINE SPEED	XXX rpm															
TURBINE REV	XXX rpm															
OVERDRIVE SW	ON															
PN POSI SW	OFF															
R POSITION SW	OFF															
OK or NG																
OK ▶	GO TO 4.															
NG ▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between TCM and ECM ● Resistor and ignition coil <p>Refer to EC-1233 [QG18DE (Calif. CA Model)], EC-1820 (SR20DE), "DTC P1320 IGNITION SIGNAL".</p>															

EC
FE
CL
MT
AT

AX
SU

BR
ST

RS
BT


HA
SC

EL
IDX

DTC P0725 ENGINE SPEED SIGNAL

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

3	CHECK INPUT SIGNAL (Without CONSULT-II)	
<p>⊗ Without CONSULT-II</p> <p>1. Start engine.</p> <p>2. Check voltage between TCM terminal 39 and ground.</p> <p style="color: blue;">Voltage (Idle speed): Refer to EC-828 [QG18DE (Calif. CA Model)], EC-1495 (SR20DE), "ECM Terminals and Reference Value".</p> <div style="text-align: center;">  </div> <p style="text-align: right;">LAT162</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 4.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between TCM and ECM ● Resistor and ignition coil <p>Refer to EC-1233 [QG18DE (Calif. CA Model)], EC-1820 (SR20DE), "DTC P1320 IGNITION SIGNAL".</p>

4	CHECK DTC	
<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-131.</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform TCM input/output signal inspection.</p> <p>2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.</p>

DTC P0731 A/T 1ST GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Description

Description

- This is an OBD-II self-diagnostic item and not available in TCM self-diagnosis. NIAT0050
- This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction. MA
- This malfunction is detected when the A/T does not shift into first gear position as instructed by the TCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc. EM

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

ON BOARD DIAGNOSTIC LOGIC

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by TCM as follows: NIAT0050S02

Torque converter slip ratio = A x C/B

A: Output shaft revolution signal from revolution sensor FE

B: Engine speed signal from ECM CL

C: Gear ratio determined as gear position which TCM supposes MT

If the actual gear position is higher than the position (1st) supposed by TCM, the slip ratio will be more than normal. In case the ratio exceeds the specified value, TCM judges this diagnosis malfunction. **AT**

This malfunction will be caused when either shift solenoid valve A is stuck open or shift solenoid valve B is stuck open. AX

Gear position supposed by TCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve A stuck open	2*	2	3	3
In case of gear position with shift solenoid valve B stuck open	4*	3	3	4

*: P0731 is detected. SU

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: A/T 1ST GR FNCTN	A/T cannot be shifted to the 1st gear position even if electrical circuit is good.	<ul style="list-style-type: none"> ● Shift solenoid valve A ● Shift solenoid valve B ● Each clutch ● Hydraulic control circuit
: P0731		

DTC P0731 A/T 1ST GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE


Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0050S03

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always drive vehicle on a level road to improve the accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- 2) Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

- 3) Select "1ST GR FNCTN P0731" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT-II and touch "START".
- 4) Accelerate vehicle to 20 to 25 km/h (12 to 16 MPH) under the following condition and release the accelerator pedal completely.

THROTTLE POSI: Less than 1.0/8 (at all times during step 4)

Selector lever: D position (OD "ON")

- Check that "GEAR" shows "2" after releasing pedal.
- 5) Depress accelerator pedal to WOT (more than 7.0/8 of "THROTTLE POSI") quickly from a speed of 20 to 25 km/h (12 to 16 MPH) until "TESTING" changes to "STOP VEHICLE" or "COMPLETED". (It will take approximately 3 seconds.)
If the check result NG appears on CONSULT-II screen, go to "Diagnostic Procedure", AT-139.
If "STOP VEHICLE" appears on CONSULT-II screen, go to the following step.
 - Check that "GEAR" shows "1" when depressing accelerator pedal to WOT.
 - If "TESTING" does not appear on CONSULT-II for a long time, select "SELF-DIAGNOSIS" for "ENGINE". In case a 1st trip DTC other than P0731 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".
 - 6) Stop vehicle.
 - 7) Follow the instruction displayed. (Check for normal shifting referring to the table below.)

Vehicle condition	Gear on actual transmission shift pattern when screen is changed to 1 → 2 → 3 → 4
No malfunction exists	1 → 2 → 3 → 4

DTC P0731 A/T 1ST GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Description (Cont'd)

Malfunction for P0731 exists.	2 → 2 → 3 → 3
	4 → 3 → 3 → 4

GI

- 8) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "Diagnostic Procedure".)
 Refer to "Diagnostic Procedure", AT-139.
 Refer to "Shift Schedule", AT-540.

MA



With GST

Follow the procedure "With CONSULT-II".

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0731 A/T 1ST GEAR FUNCTION



QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — 1ST

Wiring Diagram — AT — 1ST

=NIAT0051

AT-1STSIG-01



WAT118

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
11	L/W	SHIFT SOLENOID VALVE A	WHEN SHIFT SOLENOID VALVE A OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE A DOES NOT OPERATE	1V OR LESS
12	L/Y	SHIFT SOLENOID VALVE B	WHEN SHIFT SOLENOID VALVE B OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE B DOES NOT OPERATE	1V OR LESS

LAT259

Diagnostic Procedure

NIAT0052


1	CHECK SHIFT SOLENOID VALVE	<p>1. Remove control valve assembly. Refer to "Removal", AT-433.</p> <p>2. Check shift solenoid valve operation.</p> <ul style="list-style-type: none"> ● Shift solenoid valve A ● Shift solenoid valve B <p>Refer to "Component Inspection", AT-140.</p> <div style="text-align: center; margin: 20px 0;"> </div> <p style="text-align: center;">OK or NG</p>	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p style="background-color: black; color: white; padding: 2px;">AT</p> <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p>
OK	▶	GO TO 2.	
NG	▶	Repair or replace shift solenoid valve assembly.	

WAT163


DTC P0731 A/T 1ST GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

2	CHECK CONTROL VALVE
<p>1. Disassemble control valve assembly. Refer to "Control Valve Assembly", AT-465.</p> <p>2. Check to ensure that:</p> <ul style="list-style-type: none"> ● Valve, sleeve and plug slide along valve bore under their own weight. ● Valve, sleeve and plug are free from burrs, dents and scratches. ● Control valve springs are free from damage, deformation and fatigue. ● Hydraulic line is free from obstacles. 	
	
SAT367H	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair control valve assembly.

3	CHECK DTC
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-136.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Check control valve again. Repair or replace control valve assembly.



Component Inspection SHIFT SOLENOID VALVE A AND B

NIAT0053

NIAT0053S01

- Refer to "Removal", AT-433.

Resistance Check

NIAT0053S0101


- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
Shift solenoid valve A	2	Ground	20 - 30Ω
Shift solenoid valve B	1		5 - 20Ω

DTC P0731 A/T 1ST GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Component Inspection (Cont'd)



Operation Check

NIAT0053S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0732 A/T 2ND GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Description

Description

- This is an OBD-II self-diagnostic item and not available in TCM self-diagnosis. NIAT0054
- This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into second gear position as instructed by the TCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

ON BOARD DIAGNOSTIC LOGIC

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by TCM as follows: NIAT0054S02

Torque converter slip ratio = A x C/B

A: Output shaft revolution signal from revolution sensor

B: Engine speed signal from ECM

C: Gear ratio determined as gear position which TCM supposes

If the actual gear position is higher than the position (2nd) supposed by TCM, the slip ratio will be more than normal. In case the ratio exceeds the specified value, TCM judges this diagnosis malfunction.

This malfunction will be caused when shift solenoid valve B is stuck open.

Gear position supposed by TCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve B stuck open	4	3*	3	4

*: P0732 is detected.

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: A/T 2ND GR FNCTN : P0732	A/T cannot be shifted to the 2nd gear position even if electrical circuit is good.	<ul style="list-style-type: none"> ● Shift solenoid valve B ● Each clutch ● Hydraulic control circuit

DTC P0732 A/T 2ND GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE


Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0054S03

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always drive vehicle on a level road to improve the accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓜ With CONSULT-II

- 1) Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- 2) Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

- 3) Select "2ND GR FNCTN P0732" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT-II and touch "START".
- 4) Accelerate vehicle to 50 to 55 km/h (31 to 34 MPH) –QG18DE (Calif. CA Model)–or 59 to 64 km/h (37 to 40 MPH)–SR20DE– under the following condition and release the accelerator pedal completely.

THROTTLE POSI: Less than 1.0/8 (at all times during step 4)

Selector lever: D position (OD "ON")

- Check that "GEAR" shows "3" or "4" after releasing pedal.
- 5) Depress accelerator pedal to WOT (more than 7.0/8 of "THROTTLE POSI") quickly from a speed of 50 to 55 km/h (31 to 34 MPH) –QG18DE (Calif. CA Model)–or 59 to 64 km/h (37 to 40 MPH)–SR20DE– until "TESTING" changes to "STOP VEHICLE" or "COMPLETED". (It will take approximately 3 seconds.)

If the check result NG appears on CONSULT-II screen, go to "Diagnostic Procedure", AT-146.

If "STOP VEHICLE" appears on CONSULT-II screen, go to following step.

- Check that "GEAR" shows "2" when depressing accelerator pedal to WOT.
- If "TESTING" does not appear on CONSULT-II for a long time, select "SELF-DIAGNOSIS" for "ENGINE". In case a 1st trip DTC other than P0732 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".

- 6) Stop vehicle.
- 7) Follow the instruction displayed. (Check for normal shifting referring to the table below.)

Vehicle condition

Gear on actual transmission shift pattern when screen is changed to 1 → 2 → 3 → 4

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0732 A/T 2ND GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Description (Cont'd)

No malfunction exists	1 → 2 → 3 → 4
Malfunction for P0732 exists.	4 → 3 → 3 → 4

- 8) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "DIAGNOSTIC PROCEDURE".)
Refer to "Diagnostic Procedure", AT-146.
Refer to "Shift Schedule", AT-540.



With GST

Follow the procedure "With CONSULT-II".

DTC P0732 A/T 2ND GEAR FUNCTION


QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — 2ND

Wiring Diagram — AT — 2ND

=NIAT0055

AT-2NDSIG-01



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


WAT119

HA

SC

EL

IDX



TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
12	L/Y	SHIFT SOLENOID VALVE B	WHEN SHIFT SOLENOID VALVE B OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE B DOES NOT OPERATE	1V OR LESS

LAT260

DTC P0732 A/T 2ND GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0056

1	CHECK SHIFT SOLENOID VALVE	<p>1. Remove control valve assembly. Refer to "Removal", AT-433.</p> <p>2. Check shift solenoid valve operation.</p> <ul style="list-style-type: none"> ● Shift solenoid valve B <p>Refer to "Component Inspection", AT-147.</p> <div style="text-align: center; margin: 20px 0;"> </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p>	WAT164
OK	▶	GO TO 2.	
NG	▶	Repair or replace shift solenoid valve assembly.	

2	CHECK CONTROL VALVE	<p>1. Disassemble control valve assembly. Refer to "Control Valve Assembly", AT-465.</p> <p>2. Check to ensure that:</p> <ul style="list-style-type: none"> ● Valve, sleeve and plug slide along valve bore under their own weight. ● Valve, sleeve and plug are free from burrs, dents and scratches. ● Control valve springs are free from damage, deformation and fatigue. ● Hydraulic line is free from obstacles. <div style="text-align: center; margin: 20px 0;"> </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p>	SAT367H
OK	▶	GO TO 3.	
NG	▶	Repair control valve assembly.	

DTC P0732 A/T 2ND GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

3	CHECK DTC
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-143.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Check control valve again. Repair or replace control valve assembly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX



Component Inspection SHIFT SOLENOID VALVE B

NIAT0057

NIAT0057S01


- Refer to "Removal", AT-433.

Resistance Check

NIAT0057S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
Shift solenoid valve B	1	Ground	5 - 20Ω



Operation Check

NIAT0057S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

DTC P0733 A/T 3RD GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Description

Description

- This is an OBD-II self-diagnostic item and not available in TCM self-diagnosis. NIAT0058
- This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into third gear position as instructed by the TCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, malfunctioning servo piston or brake band, etc.

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

ON BOARD DIAGNOSTIC LOGIC

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by TCM as follows: NIAT0058S02

Torque converter slip ratio = A x C/B

A: Output shaft revolution signal from revolution sensor

B: Engine speed signal from ECM

C: Gear ratio determined as gear position which TCM supposes
 If the actual gear position is higher than the position (3rd) supposed by TCM, the slip ratio will be more than normal. In case the ratio exceeds the specified value, TCM judges this diagnosis malfunction.

This malfunction will be caused when shift solenoid valve A is stuck closed.

Gear position supposed by TCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve A stuck closed	1	1	4*	4

*: P0733 is detected.

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: A/T 3RD GR FNCTN : P0733	A/T cannot be shifted to the 3rd gear position even if electrical circuit is good.	<ul style="list-style-type: none"> ● Shift solenoid valve A ● Each clutch ● Hydraulic control circuit

DTC P0733 A/T 3RD GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE


Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0058S03

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always drive vehicle on a level road to improve the accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- 2) Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

- 3) Select "3RD GR FNCTN P0733" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT-II and touch "START".
- 4) Accelerate vehicle to 70 to 85 km/h (43 to 53 MPH) under the following condition and release the accelerator pedal completely.

THROTTLE POSI: Less than 1.0/8 (at all times during step 4)

Selector lever: D position (OD "ON")

- Check that "GEAR" shows "4" after releasing pedal.
- 5) Depress accelerator pedal steadily with 3.5/8 - 4.5/8 of "THROTTLE POSI" from a speed of 70 to 85 km/h (43 to 53 MPH) until "TESTING" changes to "STOP VEHICLE" or "COMPLETED". (It will take approximately 3 seconds.)
If the check result NG appears on CONSULT-II screen, go to "Diagnostic Procedure", AT-152.
If "STOP VEHICLE" appears on CONSULT-II screen, go to following step.
 - Check that "GEAR" shows "3" when depressing accelerator pedal with 3.5/8 - 4.5/8 of "THROTTLE POSI".
 - If "TESTING" does not appear on CONSULT-II for a long time, select "SELF-DIAGNOSIS" for "ENGINE". In case a 1st trip DTC other than P0733 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".
 - 6) Stop vehicle.
 - 7) Follow the instruction displayed. (Check for normal shifting referring to the table below.)

Vehicle condition	Gear on actual transmission shift pattern when screen is changed to 1 → 2 → 3 → 4
No malfunction exists.	1 → 2 → 3 → 4
Malfunction for P0733 exists.	1 → 1 → 4 → 4

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

**DTC P0733 A/T 3RD GEAR
FUNCTION**

QG18DE (CALIF. CA) & SR20DE

Description (Cont'd)

- 8) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "DIAGNOSTIC PROCEDURE".)
Refer to "Diagnostic Procedure", AT-152.
Refer to "Shift Schedule", AT-540.



With GST

Follow the procedure "With CONSULT-II".

DTC P0733 A/T 3RD GEAR FUNCTION


QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — 3RD

Wiring Diagram — AT — 3RD

=NIAT0059

AT-3RDSIG-01



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR


ST

RS

BT

WAT120

HA



TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
11	L/W	SHIFT SOLENOID VALVE A	WHEN SHIFT SOLENOID VALVE A OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE A DOES NOT OPERATE	1V OR LESS

SC

EL

IDX

LAT261


DTC P0733 A/T 3RD GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE


Diagnostic Procedure

Diagnostic Procedure

NIAT0060

1	CHECK SHIFT SOLENOID VALVE	<p>1. Remove control valve assembly. Refer to "Removal", AT-433.</p> <p>2. Check shift solenoid valve operation.</p> <ul style="list-style-type: none"> ● Shift solenoid valve A Refer to "Component Inspection" below.
		
		OK or NG
OK	▶	GO TO 2.
NG	▶	Repair or replace shift solenoid valve assembly.

WAT166

2	CHECK CONTROL VALVE	<p>1. Disassemble control valve assembly. Refer to "Control Valve Assembly", AT-465.</p> <p>2. Check to ensure that:</p> <ul style="list-style-type: none"> ● Valve, sleeve and plug slide along valve bore under their own weight. ● Valve, sleeve and plug are free from burrs, dents and scratches. ● Control valve springs are free from damage, deformation and fatigue. ● Hydraulic line is free from obstacles.
		
		OK or NG
OK	▶	GO TO 3.
NG	▶	Repair control valve assembly.

SAT367H

DTC P0733 A/T 3RD GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

3	CHECK DTC
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-149.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Check control valve again. Repair or replace control valve assembly.

GI
MA

EM

LC

Component Inspection SHIFT SOLENOID VALVE A

NIAT0061

NIAT0061S01

- Refer to "Removal", AT-433.

Resistance Check

NIAT0061S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
Shift solenoid valve A	2	Ground	20 - 30Ω

FE

CL


MT

AT

AX

SU


BR



Operation Check

NIAT0061S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.



ST

RS

BT

HA

SC

EL

IDX

DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Description

Description

- This is an OBD-II self-diagnostic item and not available in TCM self-diagnosis. NIAT0062
- This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into fourth gear position or the torque converter clutch does not lock up as instructed by the TCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, malfunctioning oil pump or torque converter clutch, etc.

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NIAT0062S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Line pressure solenoid valve duty	Small throttle opening (Low line pressure)	Approximately 24%
	↓ Large throttle opening (High line pressure)	↓ Approximately 95%

ON BOARD DIAGNOSTIC LOGIC

NIAT0062S03

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by TCM as follows:

Torque converter slip ratio = A x C/B

A: Output shaft revolution signal from revolution sensor

B: Engine speed signal from ECM

C: Gear ratio determined as gear position which TCM supposes

If the actual gear position is much lower than the position (4th) supposed by TCM, the slip ratio will be much less than normal. In case the ratio does not reach the specified value, TCM judges this diagnosis malfunction.

This malfunction will be caused when shift solenoid valve B is stuck closed.

Gear position supposed by TCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve B stuck closed	1	2	2	1*

*: P0734 is detected.

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: A/T 4TH GR FNCTN : P0734	A/T cannot be shifted to the 4th gear position even if electrical circuit is good.	<ul style="list-style-type: none"> ● Shift solenoid valve A ● Shift solenoid valve B ● Line pressure solenoid valve ● Each clutch ● Hydraulic control circuit

DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE


Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0062S04

CAUTION:

- Always drive vehicle at a safe speed.
- If conducting this “DTC CONFIRMATION PROCEDURE” again, always turn ignition switch “OFF” and wait at least 5 seconds before continuing.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If “DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always drive vehicle on a level road to improve the accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- Start engine and select “DATA MONITOR” mode for “A/T” with CONSULT-II.
- Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

- Select “4TH GR FNCTN P0734” of “DTC WORK SUPPORT” mode for “A/T” with CONSULT-II and touch “START”.
- Accelerate vehicle to 45 to 55 km/h (28 to 34 MPH) –QG18DE (Calif. CA Model)–or 40 to 50 km/h (25 to 31 MPH)–SR20DE–under the following condition and release the accelerator pedal completely.

THROTTLE POSI: Less than 5.5/8 (at all times during step 4)

Selector lever: D position (OD “ON”)

- Check that “GEAR” shows “3” after releasing pedal.
- Depress accelerator pedal steadily with 1.0/8 - 2.0/8 of “THROTTLE POSI” from a speed of 45 to 55 km/h (28 to 34 MPH) –QG18DE (Calif. CA Model)–or 40 to 50 km/h (25 to 31 MPH)–SR20DE–until “TESTING” has turned to “STOP VEHICLE” or “COMPLETED”. (It will take approximately 3 seconds.)
If the check result NG appears on CONSULT-II screen, go to “Diagnostic Procedure”, AT-158.
If “STOP VEHICLE” appears on CONSULT-II screen, go to following step.
 - Check that “GEAR” shows “4” when depressing accelerator pedal with 1.0/8 - 2.0/8 of “THROTTLE POSI”.
 - If “TESTING” does not appear on CONSULT-II for a long time, select “SELF-DIAGNOSIS” for “ENGINE”. In case a 1st trip DTC other than P0734 is shown, refer to applicable “TROUBLE DIAGNOSIS FOR DTC”.
 - Stop vehicle.
 - Follow the instruction displayed. (Check for normal shifting referring to the table below.)

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Description (Cont'd)

Vehicle condition	Gear on actual transmission shift pattern when screen is changed to 1 → 2 → 3 → 4
No malfunction exists	1 → 2 → 3 → 4
Malfunction for P0734 exists.	1 → 2 → 2 → 1

- 8) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "Diagnostic Procedure".)
Refer to "Diagnostic Procedure", AT-158.
Refer to "Shift Schedule", AT-540.



With GST

Follow the procedure "With CONSULT-II".

DTC P0734 A/T 4TH GEAR FUNCTION



QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — 4TH

Wiring Diagram — AT — 4TH

NIAT0063

AT-4THSIG-01



WAT121

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
1	R/W	LINE PRESSURE SOLENOID VALVE	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	1.5 - 2.5V
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	0.5V OR LESS
2	P/B	LINE PRESSURE SOLENOID VALVE (WITH DROPPING RESISTOR)	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	5 - 14V
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	0.5V OR LESS
11	L/W	SHIFT SOLENOID VALVE A	WHEN SHIFT SOLENOID VALVE A OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE A DOES NOT OPERATE	1V OR LESS
12	L/Y	SHIFT SOLENOID VALVE B	WHEN SHIFT SOLENOID VALVE B OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE B DOES NOT OPERATE	1V OR LESS

LAT262


DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0064

1	CHECK SHIFT UP (D₃ TO D₄)
<p>During "Cruise Test – Part 1" (AT-83), does A/T shift from D₃ to D₄ at the specified speed?</p> <div style="text-align: center;">  <p style="margin: 0;">Accelerator pedal</p> <p style="margin: 0;">Halfway</p> </div> <p style="text-align: right;">SAT988H</p> <p style="text-align: center;">Yes or No</p>	
Yes	▶ GO TO 9.
No	▶ GO TO 2.

2	CHECK LINE PRESSURE											
<p>Perform line pressure test. Refer to AT-72.</p> <div style="text-align: center; margin: 20px 0;"> <table border="1" style="border-collapse: collapse; width: 60%;"> <thead> <tr> <th rowspan="2" style="text-align: left;">Engine speed rpm</th> <th colspan="2" style="text-align: center;">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th style="text-align: center;">D, 2 and 1 positions</th> <th style="text-align: center;">R position</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Idle</td> <td style="text-align: center;">500 (5.1, 73)</td> <td style="text-align: center;">778 (7.9, 113)</td> </tr> <tr> <td style="text-align: center;">Stall</td> <td style="text-align: center;">1,167 (11.9, 169)</td> <td style="text-align: center;">1,816 (18.5, 263)</td> </tr> </tbody> </table> </div> <p style="text-align: right;">LAT236</p> <p style="text-align: center;">OK or NG</p>		Engine speed rpm	Line pressure kPa (kg/cm ² , psi)		D, 2 and 1 positions	R position	Idle	500 (5.1, 73)	778 (7.9, 113)	Stall	1,167 (11.9, 169)	1,816 (18.5, 263)
Engine speed rpm	Line pressure kPa (kg/cm ² , psi)											
	D, 2 and 1 positions	R position										
Idle	500 (5.1, 73)	778 (7.9, 113)										
Stall	1,167 (11.9, 169)	1,816 (18.5, 263)										
OK	▶ GO TO 3.											
NG	▶ GO TO 6.											

DTC P0734 A/T 4TH GEAR FUNCTION


QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

3 CHECK SOLENOID VALVES

1. Remove control valve assembly.
Refer to "Removal", AT-433.
2. Refer to "Component Inspection", AT-162.



OK or NG


WAT168

OK ► GO TO 4.

NG ► Replace solenoid valve assembly.

4 CHECK CONTROL VALVE

1. Disassemble control valve assembly.
Refer to "Components", AT-465.
2. Check to ensure that:
 - Valve, sleeve and plug slide along valve bore under their own weight.
 - Valve, sleeve and plug are free from burrs, dents and scratches.
 - Control valve springs are free from damage, deformation and fatigue.
 - Hydraulic line is free from obstacles.



OK or NG

SAT367H

OK ► GO TO 5.


NG ► Repair control valve.

DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)


5	CHECK SHIFT UP (D₃ TO D₄)	
Does A/T shift from D ₃ to D ₄ at the specified speed?		
OK or NG		
OK	▶	GO TO 9.
NG	▶	Check control valve again. Repair or replace control valve assembly.

6	CHECK LINE PRESSURE SOLENOID VALVE	
<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to AT-433. 2. Refer to "Component Inspection", AT-162. 		
		
WAT170		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Replace solenoid valve assembly.

DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

7	CHECK CONTROL VALVE	
<p>1. Disassemble control valve assembly. Refer to "Components", AT-465.</p> <p>2. Check line pressure circuit valves for sticking.</p> <ul style="list-style-type: none"> ● Pressure regulator valve ● Pilot valve ● Pressure modifier valve 		
		
SAT367H		
OK or NG		
OK	▶	GO TO 8.
NG	▶	Repair control valve.

GI
MA
EM
LC
EC
FE
CL
MT

8	CHECK SHIFT UP (D₃ TO D₄)	
Does A/T shift from D ₃ to D ₄ at the specified speed?		
Yes or No		
Yes	▶	GO TO 9.
No	▶	Check control valve again. Repair or replace control valve assembly.

AT
AX
SU

9	CHECK DTC	
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-155.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	Perform "Cruise Test — Part 1" again and return to the start point of this test group.


BR
ST
RS

BT
HA
SC
EL
IDX

DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (CALIF. CA) & SR20DE

Component Inspection



Component Inspection SOLENOID VALVES

=NIAT0065

NIAT0065S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0065S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
Shift solenoid valve A	2	Ground	20 - 30Ω
Shift solenoid valve B	1		5 - 20Ω
Line pressure solenoid valve	4		2.5 - 5Ω



Operation Check


NIAT0065S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

QG18DE (CALIF. CA) & SR20DE

Description



WAT237

Description

The torque converter clutch solenoid valve is activated, with the gear in "D₄", by the TCM in response to signals sent from the vehicle speed and throttle position sensors. Lock-up piston operation will then be controlled.

Lock-up operation, however, is prohibited when A/T fluid temperature is too low.

When the accelerator pedal is depressed (less than 2/8) in lock-up condition, the engine speed should not change abruptly. If there is a big jump in engine speed, there is no lock-up.

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NIAT0066S01


Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Torque converter clutch solenoid valve duty	Lock-up "OFF"	Approximately 4%
	↓ Lock-up "ON"	↓ Approximately 94%


ON BOARD DIAGNOSIS LOGIC

NIAT0066S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : TCC SOLENOID/CIRC (G) : P0740	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid circuit is open or shorted.) ● T/C clutch solenoid valve



SAT014K



SAT020K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0066S04

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II and wait at least 1 second.

(G) With GST

Follow the procedure "With CONSULT-II".

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE



QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — TCV

Wiring Diagram — AT — TCV

NIAT0067

AT-TCV-01



WAT122

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
3	GY/R	TORQUE CONVERTER CLUTCH SOLENOID VALVE	WHEN A/T PERFORMS LOCK-UP	8 - 15V
			WHEN A/T DOES NOT PERFORM LOCK-UP	1V OR LESS

LAT263


DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE


QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0068

1	CHECK VALVE RESISTANCE	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminal 5 and ground.</p> <div style="text-align: center;">  <p style="margin-left: 200px;">Resistance: 5 - 20Ω</p> </div> <p style="text-align: right;">LAT171</p> <p style="text-align: center;">OK or NG</p>	GI MA EM LC EC FE CL MT AT
OK	▶	GO TO 2.	
NG	▶	1. Remove oil pan. Refer to "Removal", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Torque converter clutch solenoid valve Refer to "Component Inspection", AT-166. ● Harness of terminal cord assembly for short or open 	


2	CHECK POWER SOURCE CIRCUIT	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect TCM harness connector. 3. Check continuity between terminal 5 and TCM harness connector terminal 3.</p> <div style="text-align: center;">  <p style="margin-left: 200px;">Continuity should exist.</p> </div> <p style="text-align: right;">LAT172</p> <p>If OK, check harness for short to ground and short to power.</p> <p>4. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>	AX SU BR ST RS BT HA SC
OK	▶	GO TO 3.	
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.	

3	CHECK DTC	<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-163.</p> <p style="text-align: center;">OK or NG</p>	EL IDX
OK	▶	INSPECTION END	
NG	▶	1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.	

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

QG18DE (CALIF. CA) & SR20DE

Component Inspection



Component Inspection

TORQUE CONVERTER CLUTCH SOLENOID VALVE

NIAT0069
NIAT0069S01


- Refer to "Removal", AT-433.

Resistance Check

NIAT0069S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
	5	Ground	
Torque converter clutch solenoid valve	5	Ground	5 - 20Ω



Operation Check

NIAT0069S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (CALIF. CA) & SR20DE

Description

Description

- This is an OBD-II self-diagnostic item and not available in TCM self-diagnosis. NIAT0070
- This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into fourth gear position or the torque converter clutch does not lock up as instructed by the TCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, malfunctioning oil pump or torque converter clutch, etc.

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NIAT0070S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Torque converter clutch solenoid valve duty	Lock-up "OFF"	Approximately 4%
	↓ Lock-up "ON"	↓ Approximately 94%

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (CALIF. CA) & SR20DE

Description (Cont'd)

ON BOARD DIAGNOSTIC LOGIC

-NIAT0070S03

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by TCM as follows:

Torque converter slip ratio = A x C/B

A: Output shaft revolution signal from revolution sensor

B: Engine speed signal from ECM

C: Gear ratio determined as gear position which TCM supposes


If the actual gear position is much lower than the position (4th) supposed by TCM, the slip ratio will be much less than normal. In case the ratio does not reach the specified value, TCM judges this diagnosis malfunction.

This malfunction will be caused when shift solenoid valve B is stuck closed.

Gear position supposed by TCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve B stuck closed	1	2	2	1*

*: P0744 is detected.

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: A/T TCC S/V FNCTN : P0744	A/T cannot perform lock-up even if electrical circuit is good.	<ul style="list-style-type: none"> ● Torque converter clutch solenoid valve ● Line pressure solenoid valve ● Each clutch ● Hydraulic control circuit



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0070S04

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.


With CONSULT-II

- 1) Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- 2) Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).


- 3) Select "TCC S/V FNCTN P0744" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT-II and touch "START".



DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (CALIF. CA) & SR20DE

Description (Cont'd)



- 4) Accelerate vehicle to more than 80 km/h (50 MPH) and maintain the following condition continuously until "TESTING" has turned to "COMPLETE". (It will take approximately 30 seconds after "TESTING" shows.)

THROTTLE POSI: 1.0/8 - 2.0/8 (at all times during step 4)

Selector lever: D position (OD "ON")

TCC S/V DUTY: More than 94%

VHCL/S SE-A/T: Constant speed of more than 80 km/h (50 MPH) –QG18DE (Calif. CA Model) or 70 km/h (43 MPH) –SR20DE

- Check that "GEAR" shows "4".
 - For "Shift Schedule", refer to SDS, AT-540.
 - If "TESTING" does not appear on CONSULT-II for a long time, select "SELF-DIAGNOSIS". In case a 1st trip DTC other than P0744 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".
- 5) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "DIAGNOSTIC PROCEDURE".)
Refer to "Diagnostic Procedure", AT-171.
Refer to "Shift Schedule", AT-540.

 **With GST**

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (CALIF. CA) & SR20DE



Wiring Diagram — AT — TCCSIG

Wiring Diagram — AT — TCCSIG

NIAT0071

— : DETECTABLE LINE FOR DTC
- - - : NON-DETECTABLE LINE FOR DTC

AT-TCCSIG-01



WAT123

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
1	R/W	LINE PRESSURE SOLENOID VALVE	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	1.5 - 2.5V
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	0.5V OR LESS
2	P/B	LINE PRESSURE SOLENOID VALVE (WITH DROPPING RESISTOR)	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	5 - 14V
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	0.5V OR LESS
3	GY/R	TORQUE CONVERTER CLUTCH SOLENOID VALVE	WHEN A/T PERFORMS LOCK-UP	8 - 14V
			WHEN A/T DOES NOT PERFORM LOCK-UP	1V OR LESS

LAT264


DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0072

1	CHECK SHIFT UP (D₃ TO D₄)		
During "Cruise Test – Part 1" (AT-83), does A/T shift from D ₃ to D ₄ at the specified speed?			
			
SAT988H			
Yes or No			
Yes	▶	GO TO 10.	
No	▶	GO TO 2.	

GI
MA
EM
LC
EC
FE
CL

2	CHECK LINE PRESSURE													
Perform line pressure test. Refer to "Line Pressure Test", AT-72.														
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Engine speed rpm</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>D, 2 and 1 positions</th> <th>R position</th> </tr> </thead> <tbody> <tr> <td>Idle</td> <td>500 (5.1, 73)</td> <td>778 (7.9, 113)</td> </tr> <tr> <td>Stall</td> <td>1,167 (11.9, 169)</td> <td>1,816 (18.5, 263)</td> </tr> </tbody> </table>				Engine speed rpm	Line pressure kPa (kg/cm ² , psi)		D, 2 and 1 positions	R position	Idle	500 (5.1, 73)	778 (7.9, 113)	Stall	1,167 (11.9, 169)	1,816 (18.5, 263)
Engine speed rpm	Line pressure kPa (kg/cm ² , psi)													
	D, 2 and 1 positions	R position												
Idle	500 (5.1, 73)	778 (7.9, 113)												
Stall	1,167 (11.9, 169)	1,816 (18.5, 263)												
LAT236														
OK or NG														
OK	▶	GO TO 3.												
NG	▶	GO TO 6.												


MT
AT
AX
SU
BR
ST
RS

BT
HA
SC
EL
IDX

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

3	CHECK CONTROL VALVE	<p>1. Disassemble control valve assembly. Refer to "DISASSEMBLY", AT-466.</p> <p>2. Check to ensure that:</p> <ul style="list-style-type: none"> ● Valve, sleeve and plug slide along valve bore under their own weight. ● Valve, sleeve and plug are free from burrs, dents and scratches. ● Control valve springs are free from damage, deformation and fatigue. ● Hydraulic line is free from obstacles. 	
			
		SAT367H	
		OK or NG	
OK	▶	GO TO 4.	
NG	▶	Repair control valve.	


4	CHECK SHIFT UP (D₃ TO D₄)	Does A/T shift from D ₃ to D ₄ at the specified speed?	
		Yes or No	
Yes	▶	GO TO 5.	
No	▶	Check control valve again. Repair or replace control valve assembly.	


5	CHECK DTC	Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-168.	
		OK or NG	
OK	▶	INSPECTION END	
NG	▶	GO TO 10.CHECK LOCK-UP CONDITION.	

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

6	CHECK LINE PRESSURE SOLENOID VALVE	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433.</p> <p>2. Check line pressure solenoid valve operation. Refer to "Component Inspection", AT-177.</p> <div style="text-align: center; margin-top: 20px;">  <p style="text-align: center;">OK or NG</p> </div>	WAT175
OK	▶	GO TO 7.	
NG	▶	Replace solenoid valve assembly.	

7	CHECK CONTROL VALVE	<p>1. Disassemble control valve assembly. Refer to "DISASSEMBLY", AT-466.</p> <p>2. Check line pressure circuit valves for sticking.</p> <ul style="list-style-type: none"> ● Pressure regulator valve ● Pilot valve ● Pressure modifier valve <div style="text-align: center; margin-top: 20px;">  <p style="text-align: center;">OK or NG</p> </div>	SAT367H
OK	▶	GO TO 8.	
NG	▶	Repair control valve.	

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX


DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

8	CHECK SHIFT UP (D₃ TO D₄)	
Does A/T shift from D ₃ to D ₄ at the specified speed?		
Yes or No		
Yes	▶	GO TO 9.
No	▶	Check control valve again. Repair or replace control valve assembly.


9	CHECK DTC	
Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-168.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	GO TO 10. And check for proper lock-up.


10	CHECK LOCK-UP CONDITION	
During "Cruise Test – Part 1" (AT-83), does A/T perform lock-up at the specified speed?		
		
SAT989H		
Yes or No		
Yes	▶	Perform "Cruise Test – Part 1" again and return to the start point of this test group.
No	▶	GO TO 11.

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

11	CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433.</p> <p>2. Check torque converter clutch solenoid valve operation. Refer to "Component Inspection", AT-177.</p> <div style="text-align: center; margin-top: 20px;">  </div> <p style="text-align: right; margin-top: 10px;">WAT176</p>	GI MA EM LC EC FE CL MT AT AX SU
OK or NG			
OK	▶	GO TO 12.	
NG	▶	Replace solenoid valve assembly.	

12	CHECK CONTROL VALVE	<p>1. Disassemble control valve assembly. Refer to "DISASSEMBLY", AT-466.</p> <p>2. Check control valves for sticking.</p> <ul style="list-style-type: none"> ● Torque converter clutch control valve ● Torque converter clutch relief valve <div style="text-align: center; margin-top: 20px;">  </div> <p style="text-align: right; margin-top: 10px;">SAT367H</p>	BR ST RS BT HA SC EL IDX
OK or NG			
OK	▶	GO TO 13.	
NG	▶	Repair control valve.	

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)


13	CHECK LOCK-UP CONDITION
Does A/T perform lock-up at the specified speed?	
Yes or No	
Yes	▶ GO TO 14.
No	▶ Check control valve again. Repair or replace control valve assembly.

14	CHECK DTC
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-168.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Perform "Cruise Test — Part 1" again and return to the start point of this test group.

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (CALIF. CA) & SR20DE

Component Inspection



Component Inspection

=NIAT0073

SOLENOID VALVES

NIAT0073S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0073S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
Line pressure solenoid valve	4	Ground	2.5 - 5Ω
Torque converter clutch solenoid valve	5		5 - 20Ω



Operation Check

NIAT0073S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

DTC P0745 LINE PRESSURE SOLENOID VALVE

QG18DE (CALIF. CA) & SR20DE

Description



Description

The line pressure solenoid valve regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM. NIAT0074

The line pressure duty cycle value is not consistent when the closed throttle position switch is "ON". To confirm the line pressure duty cycle at low pressure, the accelerator (throttle) should be open until the closed throttle position switch is "OFF".

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NIAT0074S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Line pressure solenoid valve duty	Small throttle opening (Low line pressure)	Approximately 24%
	Large throttle opening (High line pressure)	Approximately 95%



NOTE:

The line pressure duty cycle value is not consistent when the closed throttle position switch is "ON". To confirm the line pressure duty cycle at low pressure, the accelerator (throttle) should be open until the closed throttle position switch is "OFF".

ON BOARD DIAGNOSIS LOGIC

NIAT0074S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : L/PRESS SOL/CIRC (SST) : P0745	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Line pressure solenoid valve



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0074S04

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 2) Depress accelerator pedal completely and wait at least 1 second.

(SST) With GST

Follow the procedure "With CONSULT-II".

DTC P0745 LINE PRESSURE SOLENOID VALVE


QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — LPSV

Wiring Diagram — AT — LPSV

NIAT0075

AT-LPSV-01



— : DETECTABLE LINE FOR DTC
 — : NON-DETECTABLE LINE FOR DTC

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR


ST

RS

BT

WAT124

HA



TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
1	R/W	LINE PRESSURE SOLENOID VALVE	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	1.5 - 3.0V
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	0.5V OR LESS
2	P/B	LINE PRESSURE SOLENOID VALVE (WITH DROPPING RESISTOR)	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	5 - 14V
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	0.5V OR LESS

SC

EL

IDX

LAT265


DTC P0745 LINE PRESSURE SOLENOID VALVE


QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0076


1	CHECK VALVE RESISTANCE	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminal 4 and ground.</p> <div style="display: flex; justify-content: space-around; align-items: center;">  <div style="text-align: center;"> <p>Resistance: 2.5 - 5Ω</p> </div> </div> <p style="text-align: right;">LAT179</p> <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 2.
NG	▶	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Line pressure solenoid valve Refer to "Component Inspection", AT-182. ● Harness of terminal cord assembly for short or open

2	CHECK POWER SOURCE CIRCUIT	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect TCM harness connector. 3. Check resistance between terminal 4 and TCM harness connector terminal 2.</p> <div style="display: flex; justify-content: space-around; align-items: center;">  <div style="text-align: center;"> <p>Resistance: 10 - 15Ω</p> </div> </div> <p style="text-align: right;">LAT180</p> <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 3.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Dropping resistor Refer to "Component Inspection", AT-182. ● Harness for short or open between TCM terminal 2 and terminal cord assembly (Main harness)

DTC P0745 LINE PRESSURE SOLENOID VALVE

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)


3	CHECK POWER SOURCE CIRCUIT	<p>1. Turn ignition switch to "OFF" position.</p> <p>2. Check resistance between terminal 4 and TCM harness connector terminal 1.</p> <div style="display: flex; align-items: center; justify-content: space-around;">  <div style="text-align: center;"> <p>Resistance: Approx. 0 Ω</p> </div> </div> <p style="text-align: right; margin-top: 10px;">LAT181</p> <p>If OK, check harness for short to ground and short to power.</p> <p>3. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>	GI MA EM LC EC FE CL MT
OK	▶	GO TO 4.	AT
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.	AX SU BR ST RS BT HA SC EL IDX

4	CHECK DTC	<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-178.</p> <p style="text-align: center;">OK or NG</p>	AT
OK	▶	INSPECTION END	AX
NG	▶	<p>1. Perform TCM input/output signal inspection.</p> <p>2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.</p>	SU BR ST RS BT HA SC EL IDX

DTC P0745 LINE PRESSURE SOLENOID VALVE

QG18DE (CALIF. CA) & SR20DE

Component Inspection



Component Inspection

LINE PRESSURE SOLENOID VALVE

=NIAT0077

NIAT0077S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0077S0101

- Check resistance between two terminals.


Solenoid valve	Terminal No.		Resistance (Approx.)
	4	Ground	
Line pressure solenoid valve	4	Ground	2.5 - 5Ω



Operation Check

NIAT0077S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.



DROPPING RESISTOR

NIAT0077S02

- Check resistance between two terminals.


Resistance:

10 - 15Ω

DTC P0750 SHIFT SOLENOID VALVE A

QG18DE (CALIF. CA) & SR20DE

Description



Description

Shift solenoid valves A and B are turned “ON” or “OFF” by the TCM^{NIAT0078} in response to signals sent from the PNP switch, vehicle speed and throttle position sensors. Gears will then be shifted to the optimum position.



Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

ON BOARD DIAGNOSIS LOGIC

NIAT0078S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
P : SFT SOL A/CIRC P0750	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> Harness or connectors (The solenoid circuit is open or shorted.) Shift solenoid valve A

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0078S03

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch “ON” and select “DATA MONITOR” mode for “ENGINE” with CONSULT-II.
- 2) Start engine.
- 3) Drive vehicle in D position and allow the transmission to shift “1” → “2” (“GEAR”).

With GST

Follow the procedure “With CONSULT-II”.

DTC P0750 SHIFT SOLENOID VALVE A



QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — SSV/A

Wiring Diagram — AT — SSV/A

NIAT0079

AT-SSV/A-01



WAT125

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
11	L/W	SHIFT SOLENOID VALVE A	WHEN SHIFT SOLENOID VALVE A OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE A DOES NOT OPERATE	1V OR LESS

LAT261


DTC P0750 SHIFT SOLENOID VALVE A


QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0080

1	CHECK VALVE RESISTANCE	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminal 2 and ground.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Resistance: 20 - 30 Ω</p> </div> <p style="text-align: right;">LAT184</p> <p style="text-align: center;">OK or NG</p>	GI MA EM LC EC FE CL MT AT
OK	▶	GO TO 2.	
NG	▶	1. Remove control valve assembly. Refer to AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Shift solenoid valve A Refer to "Component Inspection", AT-186. ● Harness of terminal cord assembly for short or open 	


2	CHECK POWER SOURCE CIRCUIT	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect TCM harness connector. 3. Check continuity between terminal 2 and TCM harness connector terminal 11.</p> <div style="text-align: center;">  <p style="margin-left: 100px;">Continuity should exist.</p> </div> <p style="text-align: right;">LAT185</p> <p>If OK, check harness for short to ground and short to power.</p> <p>4. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>	AX SU BR ST RS BT HA SC
OK	▶	GO TO 3.	
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.	

3	CHECK DTC	<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-183.</p> <p style="text-align: center;">OK or NG</p>	EL IDX
OK	▶	INSPECTION END	
NG	▶	1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.	

DTC P0750 SHIFT SOLENOID VALVE A

QG18DE (CALIF. CA) & SR20DE

Component Inspection



Component Inspection SHIFT SOLENOID VALVE A

NIAT0081

NIAT0081S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0081S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
	2	Ground	
Shift solenoid valve A	2	Ground	20 - 30Ω



Operation Check


NIAT0081S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

DTC P0755 SHIFT SOLENOID VALVE B

QG18DE (CALIF. CA) & SR20DE

Description



Description


Shift solenoid valves A and B are turned "ON" or "OFF" by the TCM^{NIAT0082} in response to signals sent from the PNP switch, vehicle speed and throttle position sensors. Gears will then be shifted to the optimum position.

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)


ON BOARD DIAGNOSIS LOGIC

NIAT0082S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : SFT SOL B/CIRC (SST) : P0755	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Shift solenoid valve B



SAT014K



SAT020K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0082S03

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 2) Start engine.
- 3) Drive vehicle in D position and allow the transmission to shift 1 → 2 → 3 ("GEAR").

(SST) With GST

Follow the procedure "With CONSULT-II".

DTC P0755 SHIFT SOLENOID VALVE B



QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — SSV/B

Wiring Diagram — AT — SSV/B

NIAT0083

AT-SSV/B-01



WAT126

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
12	L/Y	SHIFT SOLENOID VALVE B	WHEN SHIFT SOLENOID VALVE B OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE B DOES NOT OPERATE	1V OR LESS

LAT260


DTC P0755 SHIFT SOLENOID VALVE B

QG18DE (CALIF. CA) & SR20DE


Diagnostic Procedure

Diagnostic Procedure

NIAT0084

1	CHECK VALVE RESISTANCE		
		<p>1. Turn ignition switch to "OFF" position.</p> <p>2. Disconnect terminal cord assembly connector in engine compartment.</p> <p>3. Check resistance between terminal 1 and ground.</p>	
			<p>Resistance: 5 - 20 Ω</p>
		<p>OK or NG</p>	LAT188
OK	▶	GO TO 2.	
NG	▶	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433.</p> <p>2. Check the following items:</p> <ul style="list-style-type: none"> ● Shift solenoid valve B Refer to "Component Inspection", AT-190. ● Harness of terminal cord assembly for short or open 	

GI
MA
EM
LC
EC
FE
CL
MT
AT

2	CHECK POWER SOURCE CIRCUIT		
		<p>1. Turn ignition switch to "OFF" position.</p> <p>2. Disconnect TCM harness connector.</p> <p>3. Check continuity between terminal 1 and TCM harness connector terminal 12.</p>	
			<p>Continuity should exist.</p>
		<p>If OK, check harness for short to ground and short to power.</p> <p>4. Reinstall any part removed.</p>	LAT189
		<p>OK or NG</p>	
OK	▶	GO TO 3.	
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.	

AX
SU
BR
ST
RS
BT
HA
SC


3	CHECK DTC		
		<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-187.</p>	
		<p>OK or NG</p>	
OK	▶	INSPECTION END	
NG	▶	<p>1. Perform TCM input/output signal inspection.</p> <p>2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.</p>	

EL
IDX

DTC P0755 SHIFT SOLENOID VALVE B

QG18DE (CALIF. CA) & SR20DE

Component Inspection



Component Inspection SHIFT SOLENOID VALVE B

NIAT0085

NIAT0085S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0085S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
	1	Ground	
Shift solenoid valve B	1	Ground	5 - 20Ω



Operation Check


NIAT0085S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (CALIF. CA) & SR20DE

Description



Description

NIAT0086

- Throttle position sensor
The throttle position sensor detects the throttle valve position and sends a signal to the TCM.
- Throttle position switch
Consists of a wide open throttle position switch and a closed throttle position switch.
The wide open throttle position switch sends a signal to the TCM when the throttle valve is open at least 1/2 of the full throttle position. The closed throttle position switch sends a signal to the TCM when the throttle valve is fully closed.

GI
MA
EM
LC

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NIAT0086S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Throttle position sensor	Fully-closed throttle	Approximately 0.5V
	Fully-open throttle	Approximately 4V

EC
FE
CL

ON BOARD DIAGNOSIS LOGIC

NIAT0086S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
P : TP SEN/CIRC A/T GST : P1705	TCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Throttle position sensor ● Throttle position switch

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (CALIF. CA) & SR20DE

Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0086S04

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J

With CONSULT-II

- 1) Apply vacuum to the throttle opener, then check the following. Refer to steps from 1 to 5 of "Preparation", "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52.
- 2) Turn ignition switch "ON" and select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- 3) Check the following.

Accelerator pedal condition	THRTL POS SEN	CLOSED THL/SW	W/O THRL/P-SW
Fully released	Less than 4.7V	ON	OFF
Partially depressed	0.1 - 4.6V	OFF	OFF
Fully depressed	1.9 - 4.6V	OFF	ON

SELECT SYSTEM
A/T
ENGINE

SAT014K

If the check result is NG, go to "Diagnostic Procedure", AT-194.
If the check result is OK, go to following step.

- 4) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 5) Start engine and maintain the following conditions for at least 3 consecutive seconds. Then release accelerator pedal completely.

VHCL SPEED SE: 10 km/h (6 MPH) or more
THRTL POS SEN: Approximately 3V or less
Selector lever: D position (OD "ON")

If the check result is NG, go to "Diagnostic Procedure", AT-194.
If the check result is OK, go to following step.

- 6) Maintain the following conditions for at least 3 consecutive seconds. Then release accelerator pedal completely.

VHCL SPEED SE: 10 km/h (6 MPH) or more
Accelerator pedal: Wide open throttle
Selector lever: D position (OD "ON")

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT020K

With GST

Follow the procedure "With CONSULT-II".

DTC P1705 THROTTLE POSITION SENSOR



QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — TPS

Wiring Diagram — AT — TPS

=NIAT0087

AT-TPS-01



WAT127

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TEMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
16	Y/PU	CLOSED THROTTLE POSITION SWITCH	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	BATTERY VOLTAGE
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	1V OR LESS
17	LG	WIDE OPEN THROTTLE POSITION SWITCH	WHEN DEPRESSING ACCELERATOR PEDAL MORE THAN HALF-WAY (ENGINE WARM)	BATTERY VOLTAGE
			WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	1V OR LESS
32	B/W	THROTTLE POSITION SENSOR (POWER SOURCE)	WHEN TURNING IGNITION SWITCH TO "ON"	4.5 - 5.5V
			WHEN TURNING IGNITION SWITCH TO "OFF"	1V OR LESS
41	GY	THROTTLE POSITION SENSOR	WHEN DEPRESSING ACCELERATOR PEDAL SLOWLY (ENGINE WARM)	CLOSED: APPROX 0.5V OPEN: APPROX 4V
42	B	GROUND (THROTTLE POSITION SENSOR)	—	1V OR LESS

LAT266

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0088

1	CHECK DTC WITH ECM	
Perform diagnostic test mode II (self-diagnostic results) for engine control. Refer to EC-772 [QG18DE (Calif. CA Model)], EC-1440 (SR20DE), "Malfunction Indicator Lamp (MIL)".		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	Check throttle position sensor circuit for engine control. Refer to EC-875 [QG18DE (Calif. CA Model)], EC-1540 (SR20DE), "DTC P0120 THROTTLE POSITION SENSOR".


2	CHECK INPUT SIGNAL (WITH CONSULT-II)															
④ With CONSULT-II 1. Apply vacuum to the throttle opener then check the following. Refer to steps 1 through 5 of "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 4. Read out the value of "THRTL POS SEN". Voltage: Fully-closed throttle: Approximately 0.5V Fully-open throttle: Approximately 4V																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITORING</th> <th style="text-align: center;"> </th> </tr> </thead> <tbody> <tr> <td>VHCL/S SE-A/T</td> <td style="text-align: center;">XXX km/h</td> </tr> <tr> <td>VHCL/S SE-MTR</td> <td style="text-align: center;">XXX km/h</td> </tr> <tr> <td>THRTL POS SEN</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td>FLUID TEMP SE</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td>BATTERY VOLT</td> <td style="text-align: center;">XXX V</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		VHCL/S SE-A/T	XXX km/h	VHCL/S SE-MTR	XXX km/h	THRTL POS SEN	XXX V	FLUID TEMP SE	XXX V	BATTERY VOLT	XXX V
DATA MONITOR																
MONITORING																
VHCL/S SE-A/T	XXX km/h															
VHCL/S SE-MTR	XXX km/h															
THRTL POS SEN	XXX V															
FLUID TEMP SE	XXX V															
BATTERY VOLT	XXX V															
OK or NG																
OK	▶	GO TO 4.														
NG	▶	Check harness for short or open between ECM and TCM regarding throttle position sensor circuit. (Main harness)														

SAT614J

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

3	CHECK INPUT SIGNAL (WITHOUT CONSULT-II)	<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener then check the following. Refer to steps 1 through 5 of "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Check voltage between TCM terminals 41 and 42 while accelerator pedal is depressed slowly. <p style="margin-left: 20px;">Voltage:</p> <p style="margin-left: 40px;">Fully-closed throttle valve: Approximately 0.5V</p> <p style="margin-left: 40px;">Fully-open throttle valve: Approximately 4V</p> <p>(Voltage rises gradually in response to throttle position)</p> <div style="text-align: center; margin: 20px 0;">  </div> <p style="text-align: center; margin: 0 0 10px 0;">OK or NG</p>	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p style="background-color: black; color: white; padding: 2px;">AT</p> <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p>
OK	▶	GO TO 5.	
NG	▶	Check harness for short or open between ECM and TCM regarding throttle position sensor circuit. (Main harness)	

SAT453J

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (CALIF. CA) & SR20DE


Diagnostic Procedure (Cont'd)

4	CHECK THROTTLE POSITION SWITCH CIRCUIT (WITH CONSULT-II)															
<p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener, then check the following. Refer to steps 1 through 5 of "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 4. Read out "CLOSED THL/SW" and "W/O THRL/P-SW" depressing and releasing accelerator pedal. Check the signal of throttle position switch is indicated properly. 																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="padding: 5px;">Accelerator pedal condition</th> <th colspan="2" style="padding: 5px;">Data monitor</th> </tr> <tr> <th style="padding: 5px;">CLOSED THL/SW</th> <th style="padding: 5px;">W/O THRL/P-SW</th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">Released</td> <td style="padding: 5px; text-align: center;">ON</td> <td style="padding: 5px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 5px;">Fully depressed</td> <td style="padding: 5px; text-align: center;">OFF</td> <td style="padding: 5px; text-align: center;">ON</td> </tr> </tbody> </table>			Accelerator pedal condition	Data monitor		CLOSED THL/SW	W/O THRL/P-SW	Released	ON	OFF	Fully depressed	OFF	ON			
Accelerator pedal condition	Data monitor															
	CLOSED THL/SW	W/O THRL/P-SW														
Released	ON	OFF														
Fully depressed	OFF	ON														
MTBL0011																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="padding: 5px;">DATA MONITOR</th> </tr> <tr> <th style="padding: 5px;">MONITORING</th> <th style="padding: 5px;"></th> </tr> </thead> <tbody> <tr> <td style="padding: 5px;">POWERSHIFT SW</td> <td style="padding: 5px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 5px;">CLOSED THL/SW</td> <td style="padding: 5px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 5px;">W/O THRL/P-SW</td> <td style="padding: 5px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 5px;">HOLD SW</td> <td style="padding: 5px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 5px;">BRAKE SW</td> <td style="padding: 5px; text-align: center;">ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		POWERSHIFT SW	OFF	CLOSED THL/SW	OFF	W/O THRL/P-SW	OFF	HOLD SW	OFF	BRAKE SW	ON
DATA MONITOR																
MONITORING																
POWERSHIFT SW	OFF															
CLOSED THL/SW	OFF															
W/O THRL/P-SW	OFF															
HOLD SW	OFF															
BRAKE SW	ON															
SAT702J																
OK or NG																
OK	▶	GO TO 6.														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Throttle position switch — Refer to "Component Inspection", AT-198. ● Harness for short or open between ignition switch and throttle position switch (Main harness) ● Harness for short or open between throttle position switch and TCM (Main harness) 														

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

5	CHECK THROTTLE POSITION SWITCH CIRCUIT (WITHOUT CONSULT-II)												
<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener, then check the following. Refer to steps 1 through 5 of "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Check voltage between TCM terminals 16, 17 and ground while depressing, and releasing accelerator pedal slowly. (After warming up engine) 													
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Accelerator pedal condition</th> <th colspan="2">Voltage</th> </tr> <tr> <th>Terminal No. 16</th> <th>Terminal No. 17</th> </tr> </thead> <tbody> <tr> <td>Released</td> <td>Battery voltage</td> <td>1V or less</td> </tr> <tr> <td>Fully depressed</td> <td>1V or less</td> <td>Battery voltage</td> </tr> </tbody> </table>			Accelerator pedal condition	Voltage		Terminal No. 16	Terminal No. 17	Released	Battery voltage	1V or less	Fully depressed	1V or less	Battery voltage
Accelerator pedal condition	Voltage												
	Terminal No. 16	Terminal No. 17											
Released	Battery voltage	1V or less											
Fully depressed	1V or less	Battery voltage											
MTBL0137													
													
LAT192													
OK or NG													
OK	▶	GO TO 6.											
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Throttle position switch — Refer to "Component Inspection", AT-198. ● Harness for short or open between ignition switch and throttle position switch (Main harness) ● Harness for short or open between throttle position switch and TCM (Main harness) 											


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

6	CHECK DTC	
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-192.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (CALIF. CA) & SR20DE

Component Inspection



Component Inspection

THROTTLE POSITION SWITCH

=NIAT0089

NIAT0089S01


NIAT0089S0101

Closed Throttle Position Switch (Idle position)

- Check continuity between terminals 5 and 6. [Refer to "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52.]

Accelerator pedal condition	Continuity
Released	Yes
Depressed	No

- To adjust closed throttle position switch, refer to **EC-1117** [QG18DE (Calif. CA Model)], **EC-1785** (SR20DE), "DTC P0510 CLOSED THROTTLE POSITION SWITCH".



Wide Open Throttle Position Switch

NIAT0089S0102


- Check continuity between terminals 4 and 5.

Accelerator pedal condition	Continuity
Released	No
Depressed	Yes

DTC P1760 OVERRUN CLUTCH SOLENOID VALVE

QG18DE (CALIF. CA) & SR20DE

Description





Description

The overrun clutch solenoid valve is activated by the TCM^{NIAT0090} in response to signals sent from the inhibitor switch, overdrive control switch, vehicle speed and throttle position sensors. The overrun clutch operation will then be controlled.

ON BOARD DIAGNOSIS LOGIC

NIAT0090S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: O/R CLTCH SOL/CIRC : P1760	TCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Overrun clutch solenoid valve



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0090S03

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always drive vehicle on a level road to improve accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 2) Start engine.
- 3) Accelerate vehicle to a speed of more than 10 km/h (6 MPH) with "D" position (OD "ON").
- 4) Release accelerator pedal completely with "D" position (OD "OFF").

With GST

Follow the procedure "With CONSULT-II".

DTC P1760 OVERRUN CLUTCH SOLENOID VALVE



QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — OVRCSV

Wiring Diagram — AT — OVRCSV

=NIAT0091

AT-OVRCSV-01



WAT128

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
20	L/B	OVERRUN CLUTCH SOLENOID VALVE	WHEN OVERRUN CLUTCH SOLENOID VALVE OPERATES	BATTERY VOLTAGE
			WHEN OVERRUN CLUTCH SOLENOID VALVE DOES NOT OPERATE	1V OR LESS

LAT267


DTC P1760 OVERRUN CLUTCH SOLENOID VALVE


QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0092

1	CHECK VALVE RESISTANCE	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminal 3 and ground.</p> <div style="text-align: center;">  <p style="margin-left: 200px;">Resistance: 20 - 30Ω</p> </div> <p style="text-align: right;">LAT195</p> <p style="text-align: center;">OK or NG</p>	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p style="background-color: black; color: white; text-align: center;">AT</p>
OK	▶	GO TO 2.	
NG	▶	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Overrun clutch solenoid valve Refer to "Component Inspection", AT-202. ● Harness of terminal cord assembly for short or open 	


2	CHECK POWER SOURCE CIRCUIT	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect TCM harness connector. 3. Check continuity between terminal 3 and TCM harness connector terminal 20.</p> <div style="text-align: center;">  <p style="margin-left: 200px;">Continuity should exist.</p> </div> <p style="text-align: right;">LAT196</p> <p>If OK, check harness for short to ground and short to power.</p> <p>4. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>	<p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p>
OK	▶	GO TO 3.	
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.	

3	CHECK DTC	<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-199.</p> <p style="text-align: center;">OK or NG</p>	<p>EL</p> <p>IDX</p>
OK	▶	INSPECTION END	
NG	▶	<p>1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.</p>	

DTC P1760 OVERRUN CLUTCH SOLENOID VALVE

QG18DE (CALIF. CA) & SR20DE

Component Inspection



Component Inspection OVERRUN CLUTCH SOLENOID VALVE

NIAT0093

NIAT0093S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0093S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
	3	Ground	
Overrun clutch solenoid valve	3	Ground	20 - 30Ω




Operation Check

NIAT0093S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.


DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE) QG18DE (CALIF. CA) & SR20DE

Description



Description

The A/T fluid temperature sensor detects the A/T fluid temperature and sends a signal to the TCM. NIAT0094



CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NIAT0094S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
A/T fluid temperature sensor	Cold [20°C (68°F)]	Approximately 1.5V
	↓ Hot [80°C (176°F)]	↓ Approximately 0.5V

ON BOARD DIAGNOSIS LOGIC




NIAT0094S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
<input type="checkbox"/> : BATT/FLUID TEMP SEN <input checked="" type="checkbox"/> : 8th judgement flicker	TCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.) A/T fluid temperature sensor

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE) QG18DE (CALIF. CA) & SR20DE

Description (Cont'd)



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0094S04

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓜ With CONSULT-II

- 1) Start engine.
- 2) Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D", vehicle speed higher than 20 km/h (12 MPH).

ⓧ Without CONSULT-II

- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D", vehicle speed higher than 20 km/h (12 MPH).
- 3) Perform self-diagnosis.
Refer to TCM/PCM Self-diagnostic Procedure (No Tools), AT-52.



DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE) QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — BA/FTS

Wiring Diagram — AT — BA/FTS

NIAT0095

AT-BA/FTS-01



TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
10	BR/R	POWER SOURCE	WHEN TURNING IGNITION SWITCH TO "ON"	BATTERY VOLTAGE
			WHEN TURNING IGNITION SWITCH TO "OFF"	1V OR LESS
19	BR/R	POWER SOURCE	WHEN TURNING IGNITION SWITCH TO "ON"	BATTERY VOLTAGE
			WHEN TURNING IGNITION SWITCH TO "OFF"	1V OR LESS
28	R/B	POWER SOURCE (MEMORY BACK-UP)	WHEN TURNING IGNITION SWITCH TO "OFF"	BATTERY VOLTAGE
			WHEN TURNING IGNITION SWITCH TO "ON"	BATTERY VOLTAGE
42	B	GROUND (A/T FLUID TEMPERATURE SENSOR)	—	1V OR LESS
47	BR	A/T FLUID TEMPERATURE SENSOR	WHEN ATF TEMPERATURE IS 20 °C (68° F)	APPROX. 1.5V
			WHEN ATF TEMPERATURE IS 80 °C (176° F)	APPROX. 0.5V

WAT129

LAT268

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE) QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0096

1	CHECK TCM POWER SOURCE	<p>1. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>2. Check voltage between TCM terminals 10, 19, 28 and ground. Voltage: Battery voltage</p> <p>3. Turn ignition switch to "OFF" position.</p> <p>4. Check voltage between TCM terminal 28 and ground. Voltage: Battery voltage</p> <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right;">SAT461J</p>
OK or NG		
OK	▶	GO TO 2.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between ignition switch and TCM (Main harness) ● Ignition switch and fuse <p>Refer to EL-9, "POWER SUPPLY ROUTING".</p>

2	CHECK A/T FLUID TEMPERATURE SENSOR WITH TERMINAL CORD ASSEMBLY	<p>1. Turn ignition switch to "OFF" position.</p> <p>2. Disconnect terminal cord assembly connector in engine compartment.</p> <p>3. Check resistance between terminals 6 and 7 when A/T is cold.</p> <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: right;">LAT200</p>
OK or NG		
4. Reinstall any part removed.		
OK (With CONSULT-II)	▶	GO TO 3.
OK (Without CONSULT-II)	▶	GO TO 4.
NG	▶	<p>1. Remove oil pan.</p> <p>2. Check the following items:</p> <ul style="list-style-type: none"> ● A/T fluid temperature sensor Refer to "Component Inspection", AT-209. ● Harness of terminal cord assembly for short or open

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE)

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

3	CHECK INPUT SIGNAL OF A/T FLUID TEMPERATURE SENSOR (WITH CONSULT-II)															
<p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 3. Read out the value of "FLUID TEMP SE". <p style="margin-left: 20px;">Voltage:</p> <p style="margin-left: 40px; color: blue;">Cold [20°C (68°F)] → Hot [80°C (176°F)]:</p> <p style="margin-left: 40px; color: blue;">Approximately 1.5V → 0.5V</p> <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse; width: 150px;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITORING</th> <th style="width: 50px;"></th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">VHCL/S SE-A/T</td> <td style="text-align: center;">XXX km/h</td> </tr> <tr> <td style="text-align: center;">VHCL/S SE-MTR</td> <td style="text-align: center;">XXX km/h</td> </tr> <tr> <td style="text-align: center;">THRTL POS SEN</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td style="text-align: center;">FLUID TEMP SE</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td style="text-align: center;">BATTERY VOLT</td> <td style="text-align: center;">XXX V</td> </tr> </tbody> </table> </div> <p style="text-align: right; margin-right: 20px;">SAT614J</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>			DATA MONITOR		MONITORING		VHCL/S SE-A/T	XXX km/h	VHCL/S SE-MTR	XXX km/h	THRTL POS SEN	XXX V	FLUID TEMP SE	XXX V	BATTERY VOLT	XXX V
DATA MONITOR																
MONITORING																
VHCL/S SE-A/T	XXX km/h															
VHCL/S SE-MTR	XXX km/h															
THRTL POS SEN	XXX V															
FLUID TEMP SE	XXX V															
BATTERY VOLT	XXX V															
OK	▶	GO TO 5.														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between TCM, ECM and terminal cord assembly (Main harness) ● Ground circuit for ECM <p>Refer to EC-843 [QG18DE (Calif. CA Model)], EC-1509 (SR20DE), "TROUBLE DIAGNOSIS FOR POWER SUPPLY".</p>														

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE) QG18DE (CALIF. CA) & SR20DE


Diagnostic Procedure (Cont'd)

4	CHECK INPUT SIGNAL OF A/T FLUID TEMPERATURE SENSOR (WITHOUT CONSULT-II)	
<p>⊗ Without CONSULT-II</p> <p>1. Start engine.</p> <p>2. Check voltage between TCM terminal 47 and ground while warming up A/T.</p> <p style="color: blue;">Voltage: Cold [20°C (68°F)] → Hot [80°C (176°F)]: Approximately 1.5V → 0.5V</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SAT463J</p> <p>3. Turn ignition switch to "OFF" position.</p> <p>4. Disconnect TCM harness connector.</p> <p>5. Check resistance between terminal 42 and ground.</p> <p style="color: blue;">Continuity should exist.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SAT464J</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 5.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between TCM, ECM and terminal cord assembly (Main harness) ● Ground circuit for ECM <p>Refer to EC-843 [QG18DE (Calif. CA Model)], EC-1509 (SR20DE), "TROUBLE DIAGNOSIS FOR POWER SUPPLY".</p>

5	CHECK DTC	
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-204.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform TCM input/output signal inspection.</p> <p>2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.</p>

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE) QG18DE (CALIF. CA) & SR20DE

Component Inspection



Component Inspection A/T FLUID TEMPERATURE SENSOR

NIAT0097

NIAT0097S01

- Refer to "REMOVAL", AT-433.
- Check resistance between two terminals while changing temperature as shown at left.

Temperature °C (°F)	Resistance
20 (68)	Approximately 2.5 kΩ
80 (176)	Approximately 0.3 kΩ

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

DTC VHCL SPEED SEN-MTR VEHICLE SPEED SENSOR-MTR

QG18DE (CALIF. CA) & SR20DE

Description



Description

NIAT0098

The vehicle speed sensor-MTR is built into the speedometer assembly. The sensor functions as an auxiliary device to the revolution sensor when it is malfunctioning. The TCM will then use a signal sent from the vehicle speed sensor-MTR.

ON BOARD DIAGNOSIS LOGIC


NIAT0098S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
<p>☐ : VHCL SPEED SEN-MTR</p> <p>☒ : 2nd judgement flicker</p>	TCM does not receive the proper voltage signal from the sensor.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Vehicle speed sensor


DTC VHCL SPEED SEN-MTR VEHICLE SPEED SENSOR-MTR

QG18DE (CALIF. CA) & SR20DE


Description (Cont'd)



SAT014K



SAT971J



SAT329HA

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0098S03

CAUTION:

- Always drive vehicle at a safe speed.
- If conducting this “DTC CONFIRMATION PROCEDURE” again, always turn ignition switch “OFF” and wait at least 5 seconds before continuing.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch “ON” and select “DATA MONITOR” mode for “A/T” with CONSULT-II.
- 2) Start engine and accelerate vehicle from 0 to 25 km/h (0 to 16 MPH).

Without CONSULT-II

- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in “D” and vehicle speed higher than 25 km/h (16 MPH).
- 3) Perform self-diagnosis.
Refer to “TCM/PCM Self-diagnostic Procedure (No Tools)”, AT-52.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC VHCL SPEED SEN-MTR VEHICLE SPEED SENSOR-MTR



QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — VSSMTR

Wiring Diagram — AT — VSSMTR

NIAT0099

AT-VSSMTR-01



WAT130

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
40	PU/R	VEHICLE SPEED SENSOR	WHEN MOVING VEHICLE AT 2 TO 3 KM/H (1 TO 2 MPH) FOR 1 m (3 ft) OR MORE	VOLTAGE VARIES FROM GREATER THAN 1V TO LESS THAN 4.5V

LAT269

DTC VHCL SPEED SEN-MTR VEHICLE SPEED SENSOR-MTR

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure


NIAT0100

1	CHECK INPUT SIGNAL	<p>With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 3. Read out the value of "VHCL/S SE-MTR" while driving. Check the value changes according to driving speed. <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th></th> </tr> </thead> <tbody> <tr> <td>VHCL/S SE-A/T</td> <td>XXX km/h</td> </tr> <tr> <td>VHCL/S SE-MTR</td> <td>XXX km/h</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td>FLUID TEMP SE</td> <td>XXX V</td> </tr> <tr> <td>BATTERY VOLT</td> <td>XXX V</td> </tr> </tbody> </table> </div> <p style="text-align: right;">SAT614J</p>	DATA MONITOR		MONITORING		VHCL/S SE-A/T	XXX km/h	VHCL/S SE-MTR	XXX km/h	THRTL POS SEN	XXX V	FLUID TEMP SE	XXX V	BATTERY VOLT	XXX V	GI MA EM LC EC FE CL
DATA MONITOR																	
MONITORING																	
VHCL/S SE-A/T	XXX km/h																
VHCL/S SE-MTR	XXX km/h																
THRTL POS SEN	XXX V																
FLUID TEMP SE	XXX V																
BATTERY VOLT	XXX V																
		<p>Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Check voltage between TCM terminal 40 and ground while driving at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more. <div style="text-align: center; margin: 10px 0;"> <p>Voltage: Voltage varies between less than 1V and more than 4.5V.</p> </div> <p style="text-align: right;">LAT201</p>	MT AT AX SU BR														
		OK or NG															
	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; border-right: 1px solid black; padding-right: 5px;">OK</td> <td style="width: 10%; text-align: center; border-right: 1px solid black;">▶</td> <td style="padding-left: 5px;">GO TO 2.</td> </tr> <tr> <td style="border-right: 1px solid black; padding-right: 5px;">NG</td> <td style="text-align: center; border-right: 1px solid black;">▶</td> <td style="padding-left: 5px;"> Check the following items: <ul style="list-style-type: none"> ● Vehicle speed sensor and ground circuit for vehicle speed sensor Refer to EL-85, "METERS AND GAUGES". ● Harness for short or open between TCM and vehicle speed sensor (Main harness) </td> </tr> </table>	OK	▶	GO TO 2.	NG	▶	Check the following items: <ul style="list-style-type: none"> ● Vehicle speed sensor and ground circuit for vehicle speed sensor Refer to EL-85, "METERS AND GAUGES". ● Harness for short or open between TCM and vehicle speed sensor (Main harness) 	ST RS BT									
OK	▶	GO TO 2.															
NG	▶	Check the following items: <ul style="list-style-type: none"> ● Vehicle speed sensor and ground circuit for vehicle speed sensor Refer to EL-85, "METERS AND GAUGES". ● Harness for short or open between TCM and vehicle speed sensor (Main harness) 															

2	CHECK DTC	<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-211.</p> <p style="text-align: center;">OK or NG</p>	HA					
	<table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 15%; border-right: 1px solid black; padding-right: 5px;">OK</td> <td style="width: 10%; text-align: center; border-right: 1px solid black;">▶</td> <td style="padding-left: 5px;">INSPECTION END</td> </tr> <tr> <td style="border-right: 1px solid black; padding-right: 5px;">NG</td> <td style="text-align: center; border-right: 1px solid black;">▶</td> <td style="padding-left: 5px;"> <ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. </td> </tr> </table>	OK	▶	INSPECTION END	NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 	SC EL IDX
OK	▶	INSPECTION END						
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 						

DTC CONTROL UNIT (RAM), CONTROL UNIT (ROM) QG18DE (CALIF. CA) & SR20DE

Description




Description

The TCM consists of a microcomputer and connectors for signal ^{NIAT0101} input and output and for power supply. The unit controls the A/T.

ON BOARD DIAGNOSIS LOGIC

NIAT0101S01

Diagnostic Trouble Code No.	Malfunction is detected when	Check Item (Possible Cause)
④ : CONTROL UNIT (RAM), CONTROL UNIT (ROM)	TCM memory (RAM) or (ROM) is mal-functioning.	<ul style="list-style-type: none"> ● TCM



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE


NIAT0101S02

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

④ With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for A/T with CONSULT-II.
- 2) Start engine.
- 3) Run engine for at least 2 seconds at idle speed.



Diagnostic Procedure

NIAT0102

1	INSPECTION START (WITH CONSULT-II)
④ With CONSULT-II 1. Turn ignition switch "ON" and select "SELF DIAGNOSIS" mode for A/T with CONSULT-II. 2. Touch "ERASE".	
▶	GO TO 2.

DTC CONTROL UNIT (RAM), CONTROL UNIT (ROM) QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure (Cont'd)

2	CHECK DTC	
PERFORM DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE. See above.		
▶		GO TO 3.

GI

MA

3	CHECK DTC AGAIN	
Is the "CONTROL UNIT (RAM)" or "CONTROL UNIT (ROM)" displayed again?		
Yes or No		
Yes	▶	Replace TCM.
No	▶	INSPECTION END

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

DTC CONTROL UNIT (EEP ROM)

QG18DE (CALIF. CA) & SR20DE

Description




Description

The TCM consists of a microcomputer and connectors for signal ^{NIAT0103} input and output and for power supply. The unit controls the A/T.

ON BOARD DIAGNOSIS LOGIC

NIAT0103S01

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
④ : CONT UNIT (EEP ROM)	TCM memory (EEP ROM) is malfunctioning.	● TCM



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE


NIAT0103S02

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

④ With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for A/T with CONSULT-II.
- 2) Start engine.
- 3) Run engine for at least 2 seconds at idle speed.



DTC CONTROL UNIT (EEP ROM)

QG18DE (CALIF. CA) & SR20DE

Diagnostic Procedure

Diagnostic Procedure

NIAT0104

1	CHECK DTC	
	<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch "ON" and select "SELF DIAGNOSIS" mode for A/T with CONSULT-II. 2. Move selector lever to "R" position. 3. Depress accelerator pedal (Full throttle position). 4. Touch "ERASE". 5. Turn ignition switch "OFF" position for 10 seconds. <p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-216.</p> <p style="text-align: center;">Is the "CONT UNIT (EEP ROM)" displayed again?</p>	
Yes	▶	Replace TCM.
No	▶	INSPECTION END

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSES FOR SYMPTOMS




QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — NONDTC

Wiring Diagram — AT — NONDTC

NIAT0105

AT-NONDTC-01



WAT131

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
26	BR/Y	PNP SWITCH "1" POSITION	WHEN SETTING SELECTOR LEVER TO "1" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
27	L	PNP SWITCH "2" POSITION	WHEN SETTING SELECTOR LEVER TO "2" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
34	W/G	PNP SWITCH "D" POSITION	WHEN SETTING SELECTOR LEVER TO "D" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
35	G/W	PNP SWITCH "R" POSITION	WHEN SETTING SELECTOR LEVER TO "R" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
36	G	PNP SWITCH "N" OR "P" POSITION	WHEN SETTING SELECTOR LEVER TO "N" OR "P" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS




LAT270

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — NONDTC (Cont'd)

AT-NONDTC-02



WAT132

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND




TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
13	G/R	O/D OFF INDICATOR LAMP	WHEN SETTING OVERDRIVE CONTROL SWITCH "OFF"	1V OR LESS
			WHEN SETTING OVERDRIVE CONTROL SWITCH "ON"	BATTERY VOLTAGE
22	OR/B	OVERDRIVE CONTROL SWITCH	WHEN SETTING OVERDRIVE CONTROL SWITCH "ON"	BATTERY VOLTAGE
			WHEN SETTING OVERDRIVE CONTROL SWITCH "OFF"	1V OR LESS

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

Wiring Diagram — AT — NONDTC (Cont'd)



REFER TO THE FOLLOWING.
(F22) - ELECTRICAL UNITS

WAT133

TRANSMISSION CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND


TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
5	Y/R	—	—	—
6	Y/G	—	—	—
7	Y/B	—	—	—
8	BR/W	—	—	—
9	G/Y	—	—	—
15	PU	—	—	—
16	Y/PU	CLOSED THROTTLE POSITION SWITCH	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	BATTERY VOLTAGE
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	1V OR LESS
17	LG	WIDE OPEN THROTTLE POSITION SWITCH	WHEN DEPRESSING ACCELERATOR PEDAL > 1/2 (WARM)	BATTERY VOLTAGE
			WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	1V OR LESS
18	OR	ASCD CRUISE SWITCH	WHEN ASCD CRUISE IS BEING PERFORMED	BATTERY VOLTAGE
			WHEN ASCD CRUISE IS NOT BEING PERFORMED	1V OR LESS
24	W/PU	ASCD OD CUT SIGNAL	WHEN "ACCEL" SET SWITCH ON ASCD CRUISE IS IN "D" ⁴	5 - 10V
			WHEN "ACCEL" SET SWITCH ON ASCD CRUISE IS IN "D" ³	LESS THAN 2V
30	G/B	—	—	—
31	GY/L	—	—	—
45	R/G	STOP LAMP SWITCH	WHEN DEPRESSING BRAKE PEDAL	BATTERY VOLTAGE
			WHEN RELEASING BRAKE PEDAL	1V OR LESS

LAT272

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

1. O/D OFF Indicator Lamp Does Not Come On



1. O/D OFF Indicator Lamp Does Not Come On
=NIAT0106
SYMPTOM:
 O/D OFF indicator lamp does not come on for about 2 seconds when turning ignition switch to "ON".

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX


1	CHECK TCM POWER SOURCE
<p>1. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>2. Check voltage between TCM terminals 10, 19, 28 and ground. Voltage: Battery voltage</p>	
<p>3. Turn ignition switch to "OFF" position.</p> <p>4. Check voltage between TCM terminal 28 and ground. Voltage: Battery voltage</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 2.
NG	▶ Check the following items: <ul style="list-style-type: none"> ● Harness for short or open between ignition switch and TCM (Main harness) Refer to "Wiring Diagram — AT — MAIN", AT-112. ● Ignition switch and fuse Refer to EL-9, "POWER SUPPLY ROUTING".


SAT467J

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

1. O/D OFF Indicator Lamp Does Not Come On (Cont'd)

2	CHECK TCM GROUND CIRCUIT	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect TCM harness connector. 3. Check continuity between TCM terminals 25, 48 and ground.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT468J</p> <p>Continuity should exist. If OK, check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 3.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors. Refer to "Wiring Diagram — AT — MAIN", AT-112.

3	CHECK LAMP CIRCUIT	<p>1. Turn ignition switch to "OFF" position. 2. Check resistance between TCM terminals 13 and 10.</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p>Resistance: 50 - 100 Ω</p> </div> </div> <p style="text-align: right;">LAT202</p> <p>3. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 4.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● O/D OFF indicator lamp. Refer to EL-85, "METERS AND GAUGES". ● Harness and fuse for short or open between ignition switch and O/D OFF indicator lamp (Main harness) Refer to EL-9, "POWER SUPPLY ROUTING". ● Harness for short or open between O/D OFF indicator lamp and TCM.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

1. O/D OFF Indicator Lamp Does Not Come On (Cont'd)

4	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE




2. Engine Cannot Be Started In "P" and "N" Position


2. Engine Cannot Be Started In "P" and "N" Position

=NIAT0107

SYMPTOM:

- Engine cannot be started with selector lever in "P" or "N" position.
- Engine can be started with selector lever in "D", "2", "1" or "R" position.

1	CHECK PNP SWITCH CIRCUIT	
<p> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to PNP switch circuit?</p>		
<p> Without CONSULT-II Does self-diagnosis show damage to PNP switch circuit?</p>		
		
SAT367J		
Yes or No		
Yes	▶	Check PNP switch circuit. Refer to "DTC P0705", AT-115.
No	▶	GO TO 2.

2	CHECK PNP SWITCH INSPECTION	
<p>Check for short or open of PNP switch harness connector terminals 1 and 2. Refer to "Component Inspection", AT-119.</p>		
		
WAT203		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair or replace PNP switch.

3	CHECK STARTING SYSTEM	
<p>Check starting system. Refer to SC-6, "STARTING SYSTEM".</p>		
OK or NG		
OK	▶	INSPECTION END
NG	▶	Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE


3. In "P" Position, Vehicle Moves Forward Or Backward When Pushed

3. In "P" Position, Vehicle Moves Forward Or Backward When Pushed

=NIAT0108

SYMPTOM:

Vehicle moves when it is pushed forward or backward with selector lever in "P" position.

1	CHECK PARKING COMPONENTS	
Check parking components. Refer to "Parking Pawl Components", AT-439.		
		SAT282F
OK or NG		
OK	▶	INSPECTION END
NG	▶	Repair or replace damaged parts.

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE


4. In "N" Position, Vehicle Moves


4. In "N" Position, Vehicle Moves

=NIAT0109

SYMPTOM:

Vehicle moves forward or backward when selecting "N" position.


1	CHECK PNP SWITCH CIRCUIT
<p><input type="checkbox"/> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to PNP switch circuit?</p>	
<p><input checked="" type="checkbox"/> Without CONSULT-II Does self-diagnosis show damage to inhibitor switch circuit?</p>	
	
SAT367J	
Yes or No	
Yes	▶ Check PNP switch circuit. Refer to "DTC P0705", AT-115.
No	▶ GO TO 2.


2	CHECK CONTROL CABLE
Check control cable. Refer to "Control Cable Adjustment", AT-434.	
	
SAT023JB	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Adjust control cable. Refer to "Control Cable Adjustment", AT-434.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

4. In "N" Position, Vehicle Moves (Cont'd)

3	CHECK A/T FLUID LEVEL	
Check A/T fluid level again.		
		
SAT638A		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Refill ATF.

4	CHECK A/T FLUID CONDITION	
1. Remove oil pan. 2. Check A/T fluid condition.		
		
SAT171B		
OK or NG		
OK	▶	GO TO 5.
NG	▶	1. Disassemble A/T. 2. Check the following items: <ul style="list-style-type: none"> ● Forward clutch assembly ● Overrun clutch assembly ● Reverse clutch assembly

5	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

5. Large Shock. "N" → "R" Position

5. Large Shock. "N" → "R" Position

=NIAT0110

SYMPTOM:

There is large shock when changing from "N" to "R" position.


1	CHECK SELF-DIAGNOSTIC RESULTS		
Does self-diagnosis show damage to A/T fluid temperature sensor, line pressure solenoid valve or throttle position sensor circuit?			
SAT345HA			
Yes or No			
Yes	▶	Check damaged circuit. Refer to "DTC P0710, P0745 or P1705", AT-120, 178 or 191.	
No	▶	GO TO 2.	

2	CHECK THROTTLE POSITION SENSOR		
Check throttle position sensor. Refer to EC-875 [QG18DE (Calif. CA Model)], EC-1540 (SR20DE), "DTC P0120 THROTTLE POSITION SENSOR".			
LEC279			
OK or NG			
OK	▶	GO TO 3.	
NG	▶	Repair or replace throttle position sensor.	

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

5. Large Shock. "N" → "R" Position (Cont'd)

3	CHECK LINE PRESSURE	
<p>Check line pressure at idle with selector lever in "D" position. Refer to "Line Pressure Test", AT-72.</p>		
		
SAT494G		
OK or NG		
OK	▶	GO TO 4.
NG	▶	<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) ● Line pressure solenoid valve

4	CHECK SYMPTOM	
<p>Check again.</p>		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE


6. Vehicle Does Not Creep Backward In "R" Position


6. Vehicle Does Not Creep Backward In "R" Position

=NIAT0111

SYMPTOM:

Vehicle does not creep backward when selecting "R" position.


1	CHECK A/T FLUID LEVEL	
Check A/T fluid level again.		
		
SAT638A		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Refill ATF.

2	CHECK STALL TEST	
Check stall revolution with selector lever in "1" and "R" positions.		
		
SAT493G		
OK or NG		
OK	▶	GO TO 3.
OK in "1" position, NG in "R" position	▶	<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) ● Line pressure solenoid valve 3. Disassemble A/T. 4. Check the following items: <ul style="list-style-type: none"> ● Oil pump assembly ● Torque converter ● Reverse clutch assembly ● High clutch assembly
NG in both "1" and "R" positions	▶	GO TO 6.


TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

6. Vehicle Does Not Creep Backward In "R" Position (Cont'd)

3	CHECK LINE PRESSURE	<p>Check line pressure at idle with selector lever in "R" position. Refer to "Line Pressure Test", AT-72.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT494G</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	GO TO 4.	
NG	▶	<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) ● Line pressure solenoid valve 3. Disassemble A/T. 4. Check the following item: <ul style="list-style-type: none"> ● Oil pump assembly 	

GI
MA
EM
LC
EC
FE
CL
MT
AT

4	CHECK A/T FLUID CONDITION	<ol style="list-style-type: none"> 1. Remove oil pan. 2. Check A/T fluid condition. <div style="text-align: center;">  </div> <p style="text-align: right;">SAT171B</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	GO TO 5.	
NG	▶	GO TO 6.	

AX
SU
BR
ST
RS
BT
HA

5	CHECK SYMPTOM	<p>Check again.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	INSPECTION END	
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 	

SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

6. *Vehicle Does Not Creep Backward In "R" Position (Cont'd)*

6	DETECT MALFUNCTIONING ITEM	
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433.</p> <p>2. Check the following items:</p> <ul style="list-style-type: none"> ● Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) ● Line pressure solenoid valve <p>3. Disassemble A/T.</p> <p>4. Check the following items:</p> <ul style="list-style-type: none"> ● Oil pump assembly ● Torque converter ● Reverse clutch assembly ● High clutch assembly ● Low & reverse brake assembly ● Low one-way clutch 		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE


7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position


7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position

=NIAT0112

SYMPTOM:

Vehicle does not creep forward when selecting "D", "2" or "1" position.

1	CHECK A/T FLUID LEVEL	
Check A/T fluid level again.		
		
SAT638A		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Refill ATF.


2	CHECK STALL TEST	
Check stall revolution with selector lever in "D" position. Refer to "Stall Test", AT-68.		
		
SAT493G		
OK or NG		
OK	▶	GO TO 3.
NG	▶	GO TO 6.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position (Cont'd)

3	CHECK LINE PRESSURE	<p>Check line pressure at idle with selector lever in "D" position. Refer to "Line Pressure Test ", AT-72.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT494G</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	GO TO 4.	
NG	▶	<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) ● Line pressure solenoid valve 3. Disassemble A/T. 4. Check the following item: <ul style="list-style-type: none"> ● Oil pump assembly 	

4	CHECK A/T FLUID CONDITION	<ol style="list-style-type: none"> 1. Remove oil pan. 2. Check A/T fluid condition. <div style="text-align: center;">  </div> <p style="text-align: right;">SAT171B</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	GO TO 5.	
NG	▶	GO TO 6.	

5	CHECK SYMPTOM	<p>Check again.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	INSPECTION END	
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 	

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position (Cont'd)

6	DETECT MALFUNCTIONING ITEM	
	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433.</p> <p>2. Check the following items:</p> <ul style="list-style-type: none"> ● Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) ● Line pressure solenoid valve <p>3. Disassemble A/T.</p> <p>4. Check the following items:</p> <ul style="list-style-type: none"> ● Oil pump assembly ● Forward clutch assembly ● Forward one-way clutch ● Low one-way clutch ● Low & reverse brake assembly ● Torque converter <p style="text-align: center;">OK or NG</p>	
	OK	▶ GO TO 5.
	NG	▶ Repair or replace damaged parts.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

8. Vehicle Cannot Be Started From D₁


8. Vehicle Cannot Be Started From D₁


=NIAT0113

SYMPTOM:

Vehicle cannot be started from D₁ on Cruise Test — Part 1.

1	CHECK SYMPTOM	
Is "6. Vehicle Does Not Creep Backward In R Position" OK?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	Go to "6. Vehicle Does Not Creep Backward In R Position", AT-230.


2	CHECK SELF-DIAGNOSTIC RESULTS	
Does self-diagnosis show damage to vehicle speed sensor-A/T (revolution sensor), shift solenoid valve A, B or vehicle speed sensor-MTR after cruise test?		
		
SAT934FB		
Yes or No		
Yes	▶	Check damaged circuit. Refer to "DTC P0720, P0750, P0755 or VHCL SPEED SEN-MTR", AT-126, 183, 187 or 210.
No	▶	GO TO 3.


3	CHECK THROTTLE POSITION SENSOR	
Check throttle position sensor. Refer to EC-875 [QG18DE (Calif. CA Model)], EC-1540 (SR20DE), "DTC P0120 THROTTLE POSITION SENSOR".		
		
LEC279		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace throttle position sensor.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

8. Vehicle Cannot Be Started From D₁ (Cont'd)

4	CHECK LINE PRESSURE		
<p>Check line pressure at stall point with selector lever in "D" position. Refer to "Line Pressure Test", AT-72.</p>			
			
SAT494G			
OK or NG			
OK	▶	GO TO 5.	
NG	▶	GO TO 8.	

5	CHECK A/T FLUID CONDITION		
<p>1. Remove oil pan. 2. Check A/T fluid condition.</p>			
			
SAT171B			
OK or NG			
OK	▶	GO TO 6.	
NG	▶	GO TO 8.	

6	DETECT MALFUNCTIONING ITEM		
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Shift valve A ● Shift valve B ● Shift solenoid valve A ● Shift solenoid valve B ● Pilot valve ● Pilot filter 			
OK or NG			
OK	▶	GO TO 7.	
NG	▶	Repair or replace damaged parts.	

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

8. Vehicle Cannot Be Started From D₁ (Cont'd)

7	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

8	DETECT MALFUNCTIONING ITEM	
<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Shift valve A ● Shift valve B ● Shift solenoid valve A ● Shift solenoid valve B ● Pilot valve ● Pilot filter 3. Disassemble A/T. 4. Check the following items: <ul style="list-style-type: none"> ● Forward clutch assembly ● Forward one-way clutch ● Low one-way clutch ● High clutch assembly ● Torque converter ● Oil pump assembly 		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

9. A/T Does Not Shift: D₁ → D₂ Or Does Not Kickdown: D₄ → D₂

9. A/T Does Not Shift: D₁ → D₂ Or Does Not Kickdown: D₄ → D₂


=NIAT0114

SYMPTOM:

A/T does not shift from D₁ to D₂ at the specified speed.

A/T does not shift from D₄ to D₂ when depressing accelerator pedal fully at the specified speed.

1	CHECK SYMPTOM	
Are "7. Vehicle Does Not Creep Forward In D, 2 Or 1 Position" and "8. Vehicle Cannot Be Started From D ₁ " OK?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	Go to "7. Vehicle Does Not Creep Forward In D, 2 Or 1 Position" and "8. Vehicle Cannot Be Started From D ₁ ", AT-233, 236.

2	CHECK PNP SWITCH CIRCUIT	
<input checked="" type="checkbox"/> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to PNP switch circuit?		
<input type="checkbox"/> Without CONSULT-II Does self-diagnosis show damage to PNP switch circuit?		
		
Yes or No		
Yes	▶	Check PNP switch circuit. Refer to "DTC P0705", AT-115.
No	▶	GO TO 3.


3	CHECK VEHICLE SPEED SENSOR-A/T AND CHECK VEHICLE SPEED SENSOR-MTR CIRCUIT	
Check vehicle speed sensor-A/T (revolution sensor) and vehicle speed sensor-MTR circuit. Refer to "DTC P0720 and VHCL SPEED SEN-MTR", AT-126, AT-210.		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace vehicle speed sensor-A/T (revolution sensor) and vehicle speed sensor-MTR circuits.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$ (Cont'd)

4	CHECK THROTTLE POSITION SENSOR	
<p>Check throttle position sensor. Refer to EC-875 [QG18DE (Calif. CA Model)], EC-1540 (SR20DE), "DTC P0120 THROTTLE POSITION SENSOR".</p>		
 <p style="text-align: right;">LEC279</p>		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Repair or replace throttle position sensor.

5	CHECK A/T FLUID CONDITION	
<p>1. Remove oil pan. 2. Check A/T fluid condition.</p>		
 <p style="text-align: right;">SAT171B</p>		
OK or NG		
OK	▶	GO TO 6.
NG	▶	GO TO 8.

6	DETECT MALFUNCTIONING ITEM	
<p>1. Remove control valve. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Shift valve A ● Shift solenoid valve A ● Pilot valve ● Pilot filter 		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$ (Cont'd)

7	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

GI
MA
EM

8	DETECT MALFUNCTIONING ITEM	
1. Remove control valve. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Shift valve A ● Shift solenoid valve A ● Pilot valve ● Pilot filter 3. Disassemble A/T. 4. Check the following items: <ul style="list-style-type: none"> ● Servo piston assembly ● Brake band ● Oil pump assembly 		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Repair or replace damaged parts.

LC
EC
FE
CL
MT

AT

AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

10. A/T Does Not Shift: $D_2 \rightarrow D_3$


10. A/T Does Not Shift: $D_2 \rightarrow D_3$

=NIAT0115


SYMPTOM:

A/T does not shift from D_2 to D_3 at the specified speed.

1	CHECK SYMPTOM	
Are "7. Vehicle Does Not Creep Forward In D, 2 Or 1 Position" and "8. Vehicle Cannot Be Started From D_1 " OK?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	Go to "7. Vehicle Does Not Creep Forward In D, 2 Or 1 Position" and "8. Vehicle Cannot Be Started From D_1 ", AT-233, 236.

2	CHECK PNP SWITCH CIRCUIT	
<input type="checkbox"/> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to PNP switch circuit?		
<input checked="" type="checkbox"/> Without CONSULT-II Does self-diagnosis show damage to PNP switch circuit?		
		
Yes or No		
Yes	▶	Check PNP switch circuit. Refer to "DTC P0705", AT-115.
No	▶	GO TO 3.

SAT367J


3	CHECK THROTTLE POSITION SENSOR	
Check throttle position sensor. Refer to EC-875 [QG18DE (Calif. CA Model)], EC-1540 (SR20DE), "DTC P0120 THROTTLE POSITION SENSOR".		
		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace throttle position sensor.

LEC279

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

10. A/T Does Not Shift: D₂ → D₃ (Cont'd)

4	CHECK A/T FLUID CONDITION	
<p>1. Remove oil pan. 2. Check A/T fluid condition.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT171B</p>		
OK or NG		
OK	▶	GO TO 5.
NG	▶	GO TO 7.

5	DETECT MALFUNCTIONING ITEM	
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Shift valve B ● Shift solenoid valve B ● Pilot valve ● Pilot filter 		
OK or NG		
OK	▶	GO TO 6.
NG	▶	Repair or replace damaged parts.

6	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.</p>

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

10. A/T Does Not Shift: $D_2 \rightarrow D_3$ (Cont'd)

7	DETECT MALFUNCTIONING ITEM
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433.</p> <p>2. Check the following items:</p> <ul style="list-style-type: none">● Shift valve B● Shift solenoid valve B● Pilot valve● Pilot filter <p>3. Disassemble A/T.</p> <p>4. Check the following items:</p> <ul style="list-style-type: none">● Servo piston assembly● High clutch assembly● Oil pump assembly <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 6.
NG	▶ Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

11. A/T Does Not Shift: D₃ → D₄

11. A/T Does Not Shift: D₃ → D₄

=NIAT0116

SYMPTOM:

- A/T does not shift from D₃ to D₄ at the specified speed.
- A/T must be warm before D₃ to D₄ shift will occur.


1	CHECK SYMPTOM	
Are "7. Vehicle Does Not Creep Forward In D, 2 Or 1 Position" and "8. Vehicle Cannot Be Started From D ₁ " OK?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	Go to "7. Vehicle Does Not Creep Forward In D, 2 Or 1 Position" and "8. Vehicle Cannot Be Started From D ₁ ", AT-233, 236.


2	CHECK SELF-DIAGNOSTIC RESULTS	
<p>Ⓜ With CONSULT-II Does self-diagnosis, after cruise test, show damage to any of the following circuits?</p> <ul style="list-style-type: none"> ● PNP switch ● Overdrive control switch ● A/T fluid temperature sensor ● Vehicle speed sensor-A/T (revolution sensor) ● Shift solenoid valve A or B ● Vehicle speed sensor-MTR 		
SAT363HC		
Yes or No		
Yes	▶	Check damaged circuit. Refer to "DTC P0705, P0710, P0720, P0750, P0755 or VHCL SPEED SEN-MTR", AT-115, 120, 126, 183, 187 or 210.
No	▶	GO TO 3.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

11. A/T Does Not Shift: $D_3 \rightarrow D_4$ (Cont'd)

3	CHECK THROTTLE POSITION SENSOR	<p>Check throttle position sensor. Refer to EC-875 [QG18DE (Calif. CA Model)], EC-1540 (SR20DE), "DTC P0120 THROTTLE POSITION SENSOR".</p> <div style="text-align: center;">  <p>Throttle body Throttle position sensor harness connector Throttle position switch harness connector</p> </div> <p style="text-align: right;">LEC279</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	GO TO 4.	
NG	▶	Repair or replace throttle position sensor.	

4	CHECK A/T FLUID CONDITION	<p>1. Remove oil pan. 2. Check A/T fluid condition.</p> <div style="text-align: center;">  <p style="text-align: right;">SAT171B</p> <p style="text-align: center;">OK or NG</p> </div>	
OK	▶	GO TO 5.	
NG	▶	GO TO 7.	

5	DETECT MALFUNCTIONING ITEM	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Shift valve B ● Overrun clutch control valve ● Shift solenoid valve B ● Pilot valve ● Pilot filter <p style="text-align: center;">OK or NG</p>	
OK	▶	GO TO 6.	
NG	▶	Repair or replace damaged parts.	

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

11. A/T Does Not Shift: D₃ → D₄ (Cont'd)

6	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

GI
MA
EM

7	DETECT MALFUNCTIONING ITEM	
<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Shift valve B ● Overrun clutch control valve ● Shift solenoid valve B ● Pilot valve ● Pilot filter 3. Disassemble A/T. 4. Check the following items: <ul style="list-style-type: none"> ● Servo piston assembly ● Brake band ● Torque converter ● Oil pump assembly 		
OK or NG		
OK	▶	GO TO 6.
NG	▶	Repair or replace damaged parts.

LC
EC
FE
CL
MT
AT

AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE


12. A/T Does Not Perform Lock-up


12. A/T Does Not Perform Lock-up

=NIAT0117

SYMPTOM:

A/T does not perform lock-up at the specified speed.

1	CHECK SELF-DIAGNOSTIC RESULTS	
Does self-diagnosis show damage to torque converter clutch solenoid valve circuit after cruise test?		
		
SAT346H		
Yes or No		
Yes	▶	Check torque converter clutch solenoid valve circuit. Refer to "DTC P0740", AT-163.
No	▶	GO TO 2.

2	CHECK THROTTLE POSITION SENSOR	
Check throttle position sensor. Refer to EC-875 [QG18DE (Calif. CA Model)], EC-1540 (SR20DE), "DTC P0120 THROTTLE POSITION SENSOR".		
		
SAT413J		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair or replace throttle position sensor.

3	DETECT MALFUNCTIONING ITEM	
1. Remove control valve. Refer to "REMOVAL", AT-433. 2. Check following items: <ul style="list-style-type: none"> ● Torque converter clutch control valve ● Torque converter relief valve ● Torque converter clutch solenoid valve ● Pilot valve ● Pilot filter 		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

12. A/T Does Not Perform Lock-up (Cont'd)

4	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE


13. A/T Does Not Hold Lock-up Condition


13. A/T Does Not Hold Lock-up Condition

=NIAT0118

SYMPTOM:

A/T does not hold lock-up condition for more than 30 seconds.

1	CHECK DIAGNOSTIC RESULTS		
Does self-diagnosis show damage to engine speed signal circuit after cruise test?			
			
SAT347H			
Yes or No			
Yes	▶	Check engine speed signal circuit. Refer to "DTC P0725", AT-131.	
No	▶	GO TO 2.	

2	CHECK A/T FLUID CONDITION		
<ol style="list-style-type: none"> 1. Remove oil pan. 2. Check A/T fluid condition. 			
			
SAT171B			
OK or NG			
OK	▶	GO TO 3.	
NG	▶	GO TO 5.	

3	DETECT MALFUNCTIONING ITEM		
<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Torque converter clutch control valve ● Pilot valve ● Pilot filter 			
OK or NG			
OK	▶	GO TO 4.	
NG	▶	Repair or replace damaged parts.	

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

13. A/T Does Not Hold Lock-up Condition (Cont'd)

4	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

GI
MA
EM

5	DETECT MALFUNCTIONING ITEM	
1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Torque converter clutch control valve ● Pilot valve ● Pilot filter 3. Disassemble A/T. 4. Check torque converter and oil pump assembly.		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace damaged parts.

LC
EC
FE
CL
MT

AT

AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE


14. Lock-up Is Not Released

14. Lock-up Is Not Released

=NIAT0119

SYMPTOM:

Lock-up is not released when accelerator pedal is released.

1	CHECK THROTTLE POSITION SWITCH CIRCUIT	
<p><input type="checkbox"/> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to closed throttle position switch circuit?</p>		
<p><input checked="" type="checkbox"/> Without CONSULT-II Does self-diagnosis show damage to closed throttle position switch circuit?</p>		
 <p style="text-align: right; margin-right: 50px;">SAT367J</p>		
Yes or No		
Yes	▶	Check closed throttle position switch circuit. Refer to "DTC P0705", AT-115.
No	▶	GO TO 2.

2	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE


15. Engine Speed Does Not Return To Idle (Light Braking D₄ → D₃)


15. Engine Speed Does Not Return To Idle (Light Braking D₄ → D₃)

=NIAT0120

SYMPTOM:

- Engine speed does not smoothly return to idle when A/T shifts from D₄ to D₃.
- Vehicle does not decelerate by engine brake when turning overdrive control switch OFF.
- Vehicle does not decelerate by engine brake when shifting A/T from "D" to "2" position.

1	CHECK SELF-DIAGNOSTIC RESULTS		
Does self-diagnosis show damage to overrun clutch solenoid valve circuit after cruise test?			
			
SAT348H			
Yes or NO			
Yes	▶	Check overrun clutch solenoid valve circuit. Refer to "DTC P1760", AT-199.	
No	▶	GO TO 2.	


2	CHECK THROTTLE POSITION SENSOR		
Check throttle position sensor. Refer to EC-875 [QG18DE (Calif. CA Model)], EC-1540 (SR20DE), "DTC P0120 THROTTLE POSITION SENSOR".			
			
SAT413J			
OK or NG			
OK	▶	GO TO 3.	
NG	▶	Repair or replace throttle position sensor.	

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

15. Engine Speed Does Not Return To Idle (Light Braking $D_4 \rightarrow D_3$) (Cont'd)

3	CHECK A/T FLUID CONDITION	
<p>1. Remove oil pan. 2. Check A/T fluid condition.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT171B</p>		
OK or NG		
OK	▶	GO TO 4.
NG	▶	GO TO 6.

4	DETECT MALFUNCTIONING ITEM	
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Overrun clutch control valve ● Overrun clutch reducing valve ● Overrun clutch solenoid valve 		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Repair or replace damaged parts.

5	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.</p>

6	DETECT MALFUNCTIONING ITEM	
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Overrun clutch control valve ● Overrun clutch reducing valve ● Overrun clutch solenoid valve <p>3. Disassemble A/T. 4. Check the following items:</p> <ul style="list-style-type: none"> ● Overrun clutch assembly ● Oil pump assembly 		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

16. Vehicle Does Not Start From D₁

16. Vehicle Does Not Start From D₁

NIAT0121

SYMPTOM:

Vehicle does not start from D₁ on Cruise test — Part 2.

GI

MA

EM


LC

EC

FE

CL

MT

1	CHECK SELF-DIAGNOSTIC RESULTS	
<p>Does self-diagnosis show damage to vehicle speed sensor-A/T (revolution sensor), shift solenoid valve A, B or vehicle speed sensor-MTR after cruise test?</p>		
		
SAT934FA		
Yes or No		
Yes	▶	Check damaged circuit. Refer to "DTC P0720, P0750, P0755 or VHCL SPEED SEN-MTR", AT-126, 183, 187 or 210.
No	▶	GO TO 2.

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

2	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	Go to "8. Vehicle Cannot Be Started From D ₁ ", AT-236.
NG	▶	<ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

17. A/T Does Not Shift: D₄ → D₃, When Overdrive Control Switch "ON" → "OFF"

17. A/T Does Not Shift: D₄ → D₃, When Overdrive Control Switch "ON" → "OFF"

=NIAT0122

SYMPTOM:

A/T does not shift from D₄ to D₃ when changing overdrive control switch to "OFF" position.

1	CHECK OVERDRIVE CONTROL SWITCH CIRCUIT
<p><input type="checkbox"/> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to overdrive control switch circuit?</p>	
<p><input checked="" type="checkbox"/> Without CONSULT-II Does self-diagnosis show damage to overdrive control switch circuit?</p>	
<pre> graph TD A[O/D OFF] --- B[Self-diagnosis start] B -.- C[Light] B --- D[Shade] </pre>	
SAT344H	
Yes or No	
Yes	▶ Check overdrive control switch circuit. Refer to "DIAGNOSTIC PROCEDURE", AT-260.
No	▶ Go to "10. A/T Does Not Shift: D ₂ → D ₃ ", AT-242.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

18. A/T Does Not Shift: D₃ → 2₂, When Selector Lever "D" → "2" Position

18. A/T Does Not Shift: D₃ → 2₂, When Selector Lever "D" → "2" Position

=NIAT0123

SYMPTOM:

A/T does not shift from D₃ to 2₂ when changing selector lever from "D" to "2" position.

1	CHECK PNP SWITCH CIRCUIT	
<p><input type="checkbox"/> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to PNP switch circuit?</p>		
<p><input checked="" type="checkbox"/> Without CONSULT-II Does self-diagnosis show damage to PNP switch circuit?</p>		
SAT367J		
Yes or No		
Yes	▶	Check PNP switch circuit. Refer to "DTC P0705", AT-115.
No	▶	Go to "9. A/T Does Not Shift: D ₁ → D ₂ or Does Not Kickdown: D ₄ → D ₂ ", AT-239.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

19. A/T Does Not Shift: 2₂ → 1₁, When Selector Lever "2" → "1" Position

19. A/T Does Not Shift: 2₂ → 1₁, When Selector Lever "2" → "1" Position

=NIAT0124

SYMPTOM:

A/T does not shift from 2₂ to 1₁ when changing selector lever from "2" to "1" position.

1	CHECK PNP SWITCH CIRCUIT
<p> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to PNP switch circuit?</p>	
<p> Without CONSULT-II Does self-diagnosis show damage to PNP switch circuit?</p>	
SAT367J	
Yes or No	
Yes	▶ Check PNP switch circuit. Refer to "DTC P0705", AT-115.
No	▶ GO TO 2.

2	CHECK SYMPTOM
Check again.	
SAT778B	
OK or NG	
OK	▶ INSPECTION END
NG	▶ <ol style="list-style-type: none"> 1. Perform TCM input/output signal inspection. 2. If NG, recheck TCM pin terminals for damage or loose connection with harness connector.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

20. Vehicle Does Not Decelerate By Engine Brake




20. Vehicle Does Not Decelerate By Engine Brake

=NIAT0125

SYMPTOM:

Vehicle does not decelerate by engine brake when shifting from 2₂ (1₂) to 1₁.

1 CHECK SYMPTOM	
Is "6. Vehicle Does Not Creep Backward In R Position" OK?	
Yes or No	
Yes	▶ Go to "15. Engine Speed Does Not Return To Idle (Light Braking D ₄ → D ₃)", AT-253.
No	▶ Go to "6. Vehicle Does Not Creep Backward In R Position", AT-230.



21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks)

NIAT0126

SYMPTOM:

O/D OFF indicator lamp does not come on in TCM self-diagnostic procedure even if the lamp circuit is good.

DESCRIPTION

NIAT0126S01

- PNP switch
The PNP switch assembly includes a transmission range switch. The transmission range switch detects the selector lever position and sends a signal to the TCM.
- Overdrive control switch
Detects the overdrive control switch position (ON or OFF) and sends a signal to the TCM.
- Throttle position switch
Consists of a wide open throttle position switch and a closed throttle position switch.
The wide open throttle position switch sends a signal to the TCM when the throttle valve is open at least 1/2 of the full throttle position. The closed throttle position switch sends a signal to the TCM when the throttle valve is fully closed.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

DIAGNOSTIC PROCEDURE

NIAT0126S02

1	CHECK PNP SWITCH CIRCUIT (With CONSULT-II)															
	<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 3. Read out "PN", "R", "D", "2" and "1" position switches moving selector lever to each position. Check that the signal of the selector lever position is indicated properly. 															
	<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: left;">MONITORING</th> <th style="text-align: left;"></th> </tr> </thead> <tbody> <tr> <td>PN POSI SW</td> <td>OFF</td> </tr> <tr> <td>R POSITION SW</td> <td>OFF</td> </tr> <tr> <td>D POSITION SW</td> <td>OFF</td> </tr> <tr> <td>2 POSITION SW</td> <td>ON</td> </tr> <tr> <td>1 POSITION SW</td> <td>OFF</td> </tr> </tbody> </table>		DATA MONITOR		MONITORING		PN POSI SW	OFF	R POSITION SW	OFF	D POSITION SW	OFF	2 POSITION SW	ON	1 POSITION SW	OFF
DATA MONITOR																
MONITORING																
PN POSI SW	OFF															
R POSITION SW	OFF															
D POSITION SW	OFF															
2 POSITION SW	ON															
1 POSITION SW	OFF															
	SAT701J															
	OK or NG															
OK	▶	GO TO 3.														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● PNP switch (Refer to "Component Inspection", AT-265.) ● Harness for short or open between ignition switch and PNP switch (Main harness) ● Harness for short or open between PNP switch and TCM (Main harness) ● Diode (P, N positions) 														

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

2 CHECK PNP SWITCH CIRCUIT (Without CONSULT-II)

⊗ Without CONSULT-II

1. Turn ignition switch to "ON" position. (Do not start engine.)
2. Check voltage between TCM terminals 26, 27, 34, 35, 36 and ground while moving selector lever through each position.


Voltage:

B: Battery voltage

0: 0V

Lever position	Terminals				
	36	35	34	27	26
P, N	B	0	0	0	0
R	0	B	0	0	0
D	0	0	B	0	0
2	0	0	0	B	0
1	0	0	0	0	B

MTBL0138



SAT470J

OK or NG

OK ► GO TO 4.

- NG** ► **Check the following items:**
- PNP switch (Refer to "Component Inspection", AT-265.)
 - Harness for short or open between ignition switch and PNP switch (Main harness)
 - Harness for short or open between PNP switch and TCM (Main harness)
 - Diode (P, N positions)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

3	CHECK OVERDRIVE CONTROL SWITCH CIRCUIT (With CONSULT-II)															
<p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 3. Read out "OVERDRIVE SW". <p>Check the signal of the overdrive control switch is indicated properly. (Overdrive control switch "ON" displayed on CONSULT-II means overdrive "OFF".)</p> <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse; width: 150px;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITORING</th> <th style="width: 50px;"></th> </tr> </thead> <tbody> <tr> <td>ENGINE SPEED</td> <td style="text-align: center;">XXX rpm</td> </tr> <tr> <td>TURBINE REV</td> <td style="text-align: center;">XXX rpm</td> </tr> <tr> <td>OVERDRIVE SW</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>PN POSI SW</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td>R POSITION SW</td> <td style="text-align: center;">OFF</td> </tr> </tbody> </table> </div> <p style="text-align: right; margin-right: 20px;">SAT645J</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>			DATA MONITOR		MONITORING		ENGINE SPEED	XXX rpm	TURBINE REV	XXX rpm	OVERDRIVE SW	ON	PN POSI SW	OFF	R POSITION SW	OFF
DATA MONITOR																
MONITORING																
ENGINE SPEED	XXX rpm															
TURBINE REV	XXX rpm															
OVERDRIVE SW	ON															
PN POSI SW	OFF															
R POSITION SW	OFF															
OK	▶	GO TO 5.														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Overdrive control switch (Refer to "Component Inspection", AT-265.) ● Harness for short or open between TCM and overdrive control switch (Main harness) ● Harness of ground circuit for overdrive control switch (Main harness) for short or open 														

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

4	CHECK OVERDRIVE CONTROL SWITCH CIRCUIT (Without CONSULT-II)	
<p>⊗ Without CONSULT-II</p> <p>1. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>2. Check voltage between TCM terminal 22 and ground when overdrive control switch is "ON" and "OFF".</p> <p>Voltage:</p> <p style="padding-left: 20px;">Switch position "ON": Battery voltage</p> <p style="padding-left: 20px;">Switch position "OFF": 1V or less</p> <div style="text-align: center; margin: 20px 0;"> </div> <p style="text-align: right; margin-right: 50px;">SAT471JA</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 6.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Overdrive control switch (Refer to "Component Inspection", AT-265.) ● Harness for short or open between TCM and overdrive control switch (Main harness) ● Harness of ground circuit for overdrive control switch (Main harness) for short or open

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE


21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

5	CHECK THROTTLE POSITION SWITCH CIRCUIT (With CONSULT-II)															
<p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener, then check the following. Refer to step 1 through 5 of "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 4. Read out "CLOSED THL/SW" and "W/O THRL/P-SW" depressing and releasing accelerator pedal. Check the signal of throttle position switch is indicated properly. 																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="padding: 2px;">Accelerator pedal condition</th> <th colspan="2" style="padding: 2px;">Data monitor</th> </tr> <tr> <th style="padding: 2px;">CLOSED THL/SW</th> <th style="padding: 2px;">W/O THRL/P-SW</th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">Released</td> <td style="padding: 2px;">ON</td> <td style="padding: 2px;">OFF</td> </tr> <tr> <td style="padding: 2px;">Fully depressed</td> <td style="padding: 2px;">OFF</td> <td style="padding: 2px;">ON</td> </tr> </tbody> </table>			Accelerator pedal condition	Data monitor		CLOSED THL/SW	W/O THRL/P-SW	Released	ON	OFF	Fully depressed	OFF	ON			
Accelerator pedal condition	Data monitor															
	CLOSED THL/SW	W/O THRL/P-SW														
Released	ON	OFF														
Fully depressed	OFF	ON														
MTBL0011																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="padding: 2px;">DATA MONITOR</th> </tr> <tr> <th style="padding: 2px;">MONITORING</th> <th style="padding: 2px;"></th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">POWERSHIFT SW</td> <td style="padding: 2px;">OFF</td> </tr> <tr> <td style="padding: 2px;">CLOSED THL/SW</td> <td style="padding: 2px;">OFF</td> </tr> <tr> <td style="padding: 2px;">W/O THRL/P-SW</td> <td style="padding: 2px;">OFF</td> </tr> <tr> <td style="padding: 2px;">HOLD SW</td> <td style="padding: 2px;">OFF</td> </tr> <tr> <td style="padding: 2px;">BRAKE SW</td> <td style="padding: 2px;">ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		POWERSHIFT SW	OFF	CLOSED THL/SW	OFF	W/O THRL/P-SW	OFF	HOLD SW	OFF	BRAKE SW	ON
DATA MONITOR																
MONITORING																
POWERSHIFT SW	OFF															
CLOSED THL/SW	OFF															
W/O THRL/P-SW	OFF															
HOLD SW	OFF															
BRAKE SW	ON															
SAT702J																
OK or NG																
OK	▶	GO TO 7.														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Throttle position switch — Refer to "Component Inspection", AT-265. ● Harness for short or open between ignition switch and throttle position switch (Main harness) ● Harness for short or open between throttle position switch and TCM (Main harness) 														


TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

6	CHECK THROTTLE POSITION SWITCH CIRCUIT (Without CONSULT-II)	<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener, then check the following. Refer to step 1 through 5 of "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Check voltage between TCM terminals 16, 17 and ground while depressing, and releasing accelerator pedal slowly. (After warming up engine) <table border="1" style="margin: 10px auto; border-collapse: collapse; text-align: center;"> <tr> <td rowspan="2" style="padding: 5px;">Accelerator pedal condition</td> <td colspan="2" style="padding: 5px;">Voltage</td> </tr> <tr> <td style="padding: 5px;">Terminal No. 16</td> <td style="padding: 5px;">Terminal No. 17</td> </tr> <tr> <td style="padding: 5px;">Released</td> <td style="padding: 5px;">Battery voltage</td> <td style="padding: 5px;">1V or less</td> </tr> <tr> <td style="padding: 5px;">Fully depressed</td> <td style="padding: 5px;">1V or less</td> <td style="padding: 5px;">Battery voltage</td> </tr> </table> <div style="text-align: right; margin-top: 10px;">MTBL0137</div>  <p style="text-align: right; margin-top: 10px;">LAT192</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>	Accelerator pedal condition	Voltage		Terminal No. 16	Terminal No. 17	Released	Battery voltage	1V or less	Fully depressed	1V or less	Battery voltage	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p style="background-color: black; color: white; text-align: center;">AT</p>
Accelerator pedal condition	Voltage													
	Terminal No. 16	Terminal No. 17												
Released	Battery voltage	1V or less												
Fully depressed	1V or less	Battery voltage												
OK	▶	GO TO 7.	AX											
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Throttle position switch — Refer to "Component Inspection", AT-265. ● Harness for short or open between ignition switch and throttle position switch (Main harness) ● Harness for short or open between throttle position switch and TCM (Main harness) 	<p>SU</p> <p>BR</p>											

7	CHECK DTC	<p>Perform "DIAGNOSTIC PROCEDURE", AT-260</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>	
OK	▶	INSPECTION END	RS
NG	▶	<ul style="list-style-type: none"> ● Perform TCM input/output signal inspection. ● If NG, recheck TCM pin terminals for damage or loose connection with harness connector. 	<p>BT</p> <p>HA</p>



COMPONENT INSPECTION Overdrive Control Switch

NIAT0126S03

NIAT0126S0301

- Check continuity between terminals 1 and 2.

Switch position	Continuity
RELEASED	No
DEPRESSED	Yes


EL

IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)




PNP Switch


NIAT0126S0302

1. Check continuity between terminals 1 and 2 and between terminals 3 and 4, 5, 6, 7, 8, 9 while moving manual shaft through each position.

Lever position	Terminal No.	
P	3 — 7	1 — 2
R	3 — 8	
N	3 — 9	1 — 2
D	3 — 6	
2	3 — 5	
1	3 — 4	



2. If NG, check again with manual control cable disconnected from manual shaft of A/T assembly. Refer to step 1.
3. If OK on step 2, adjust manual control cable. Refer to "Control Cable Adjustment", AT-434.
4. If NG on step 2, remove PNP switch from A/T and check continuity of PNP switch terminals. Refer to step 1.
5. If OK on step 4, adjust PNP switch. Refer to "Park/Neutral Position (PNP) Switch Adjustment", AT-434.
6. If NG on step 4, replace PNP switch.



Throttle Position Switch

NIAT0126S0303

Closed throttle position switch (idle position)

- Check continuity between terminals 5 and 6. Refer to "Preparation", "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52.


Accelerator pedal condition	Continuity
Released	Yes
Depressed	No

- To adjust closed throttle position switch, refer to **EC-1117** [QG18DE (Calif. CA Model)], **EC-1785** (SR20DE), "DTC P0510 CLOSED THROTTLE POSITION SWITCH".

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (CALIF. CA) & SR20DE

21. TCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)



Wide open throttle position switch

- Check continuity between terminals 4 and 5.

Accelerator pedal condition	Continuity
Released	No
Depressed	Yes

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

QG18DE (EXCEPT CALIF. CA)

PCM Terminals and Reference Value



PCM Terminals and Reference Value PREPARATION — QG18DE (EXCEPT CALIF. CA MODEL)


NIATO134

- Measure voltage between each terminal and terminal 106 or 108 by following "PCM INSPECTION TABLE".

NIATO134S01

PCM HARNESS CONNECTOR TERMINAL LAYOUT









NIATO134S02



LAT206

PCM INSPECTION TABLE (Data are reference values.)










NIATO134S03

Terminal No.	Wire color	Item	Condition	Judgement standard
10	R/W	Line pressure solenoid valve	 When releasing accelerator pedal after warming up engine.	1.5 - 3.0V
			 When depressing accelerator pedal fully after warming up engine.	0.5V or less
19	P/B	Line pressure solenoid valve (with dropping resistor)	 When releasing accelerator pedal after warming up engine.	5 - 14V
			 When depressing accelerator pedal fully after warming up engine.	0.5V or less
24	L/B	Overrun clutch solenoid valve	 When overrun clutch solenoid valve operates.	Battery voltage
			 When overrun clutch solenoid valve does not operate.	1V or less
25	G/R	O/D OFF indicator lamp	 When setting overdrive control switch in "OFF" position.	1V or less
			 When setting overdrive control switch in "ON" position.	Battery voltage

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

QG18DE (EXCEPT CALIF. CA)












PCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item	Condition	Judgement standard		
26	L/W	Shift solenoid valve A		When shift solenoid valve A operates. (When driving in "D ₁ " or "D ₄ ".)	Battery voltage	GI
				When shift solenoid valve A does not operate. (When driving in "D ₂ " or "D ₃ ".)	1V or less	MA EM
27	L/Y	Shift solenoid valve B		When shift solenoid valve B operates. (When driving in "D ₁ " or "D ₂ ".)	Battery voltage	LC
				When shift solenoid valve B does not operate. (When driving in "D ₃ " or "D ₄ ".)	1V or less	EC
29	Y/G	Torque converter clutch solenoid valve		When A/T performs lock-up.	8 - 15V	FE
				When A/T does not perform lock-up.	1V or less	CL
32	L/OR	Engine speed signal		Refer to EC-157 , "PCM Inspection Table".	—	MT
40	Y/PU	Closed throttle position switch (in throttle position switch)		When releasing accelerator pedal after warming up engine. Refer to "TCM/PCM SELF-DIAGNOSTIC PROCEDURE (No tools)", AT-52.	Battery voltage	AT AX
				When depressing accelerator pedal after warming up engine. Refer to "TCM/PCM SELF-DIAGNOSTIC PROCEDURE (No tools)", AT-52.	1V or less	SU BR
42	G/OR	PNP switch "N" or "P" position		When setting selector lever to "N" or "P" position.	Battery voltage	ST
				When setting selector lever to other positions.	1V or less	RS
47	R/G	Stop lamp switch		When depressing brake pedal.	Battery voltage	BT
				When releasing brake pedal.	1V or less	HA
48	B	Ground	—	—	1V or less	SC
52 *2	G/B	—		—	—	EL
				—	—	IDX
54	OR	ASCD cruise switch		When ASCD cruise is being performed. ("CRUISE" light comes on.)	Battery voltage	EL
				When ASCD cruise is not being performed. ("CRUISE" light does not come on.)	1V or less	IDX

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

QG18DE (EXCEPT CALIF. CA)


PCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item	Condition	Judgement standard	
55	W/PU	ASCD OD cut signal		When "ACCEL" set switch on ASCD cruise is in "D ₄ " position.	5 - 8V
				When "ACCEL" set switch on ASCD cruise is in "D ₃ " position.	1V or less
56	OR/B	Overdrive control switch		When setting overdrive control switch in "ON" position	Battery voltage
				When setting overdrive control switch in "OFF" position	1V or less
57	B	Ground		—	1V or less
58	B	Throttle position sensor (Ground)		—	1V or less
60	G/W	PNP switch "R" position		When setting selector lever to "R" position.	Battery voltage
				When setting selector lever to other positions.	1V or less
67	W/L	Power source (Memory back-up)		When turning ignition switch to "OFF".	Battery voltage
				When turning ignition switch to "ON".	Battery voltage
68	BR/Y	PNP switch "1" position		When setting selector lever to "1" position.	Battery voltage
				When setting selector lever to other positions.	1V or less
69	B/W	PNP switch "2" position		When setting selector lever to "2" position.	Battery voltage
				When setting selector lever to other positions.	1V or less
76	W	Revolution sensor		When moving at 20 km/h (12 MPH), use the CONSULT-II pulse frequency measuring function.*1 CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector. *1: A circuit tester cannot be used to test this item.	150Hz
				When vehicle parks.	Under 1.3V or over 4.5V
77	LG	Wide open throttle position switch (in throttle position switch)		When depressing accelerator pedal more than halfway after warming up engine.	Battery voltage
				When releasing accelerator pedal after warming up engine.	1V or less
78	W/G	PNP switch "D" position		When setting selector lever to "D" position.	Battery voltage
				When setting selector lever to other positions.	1V or less

TROUBLE DIAGNOSIS — GENERAL DESCRIPTION

QG18DE (EXCEPT CALIF. CA)

PCM Terminals and Reference Value (Cont'd)

Terminal No.	Wire color	Item	Condition	Judgement standard
86	PU/R	Vehicle speed sensor	 When moving vehicle at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more.	Voltage varies between less than 1V and more than 4.5V
91	BR	A/T fluid temperature sensor	When ATF temperature is 20°C (68°F).	Approximately 1.5V
			When ATF temperature is 80°C (176°F).	Approximately 0.5V
92	Y	Throttle position sensor	When depressing accelerator pedal slowly after warming up engine. (Voltage rises gradually in response to throttle position.)	Fully-closed throttle: Approximately 0.5V Fully-open throttle: Approximately 4V
106	B/Y	Ground	—	1V or less
108	B/Y	Ground	—	1V or less
109	BR/R	Power source	When turning ignition switch to "ON".	Battery voltage
			When turning ignition switch to "OFF".	1V or less
111	R	Throttle position sensor (Power source)	—	4.5 - 5.5V
113 *2	GY/L	—	—	—

*2: These terminals are connected to the Data link connector.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS FOR POWER SUPPLY


QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — MAIN


Wiring Diagram — AT — MAIN

NIAT0135

AT-MAIN-01



REFER TO THE FOLLOWING.
(F22) - ELECTRICAL UNITS



WAT092

POWERTRAIN CONTROL UNIT TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
48	B	GROUND	—	1V OR LESS
57	B	GROUND	—	1V OR LESS
67	W/L	POWER SOURCE (MEMORY BACK-UP)	WHEN TURNING IGNITION SWITCH "OFF"	BATTERY VOLTAGE
			WHEN TURNING IGNITION SWITCH "ON"	BATTERY VOLTAGE
106	B/Y	GROUND	—	1V OR LESS
108	B/Y	GROUND	—	1V OR LESS
109	BR/R	POWER SOURCE	WHEN TURNING IGNITION SWITCH "ON"	BATTERY VOLTAGE
			WHEN TURNING IGNITION SWITCH "OFF"	1V OR LESS

LAT273


TROUBLE DIAGNOSIS FOR POWER SUPPLY

QG18DE (EXCEPT CALIF. CA)


Diagnostic Procedure

Diagnostic Procedure

NIAT0329

1	CHECK PCM POWER SOURCE STEP 1	
<p>1. Turn ignition switch to ON position. (Do not start engine.)</p> <p>2. Check voltage between PCM terminals 67, 109, and ground.</p>		
		
Battery voltage should exist.		
LAT223		
OK or NG		

OK	▶	GO TO 2.
NG	▶	GO TO 3.

2	CHECK PCM POWER SOURCE STEP 2	
<p>1. Turn ignition switch to OFF position.</p> <p>2. Check voltage between PCM terminal 67 and ground.</p>		
		
Voltage: Battery voltage		
LAT252		
OK or NG		

OK	▶	GO TO 4.
NG	▶	GO TO 3.

3	DETECT MALFUNCTIONING ITEM	
<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between ignition switch and PCM terminals 67 and 109 (Main harness) ● Fuse ● Ignition switch <p>Refer to EL-9, "POWER SUPPLY ROUTING".</p>		
OK or NG		

OK	▶	GO TO 4.
NG	▶	Repair or replace damaged parts.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSIS FOR POWER SUPPLY

QG18DE (EXCEPT CALIF. CA)


Diagnostic Procedure (Cont'd)

4	CHECK PCM GROUND CIRCUIT
<p>1. Turn ignition switch to OFF position. 2. Disconnect PCM harness connector. 3. Check continuity between PCM terminals 48, 57, 106, 108 and ground. Refer to wiring diagram, AT-272. Continuity should exist. If OK, check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ INSPECTION END
NG	▶ Repair open circuit or short to ground or short to power in harness connectors.

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH

QG18DE (EXCEPT CALIF. CA)

Description




Description

- The PNP switch assembly includes a transmission range switch. NIAT0136
- The transmission range switch detects the A/T selector lever position and sends a signal to the PCM.

ON BOARD DIAGNOSIS LOGIC

NIAT0136S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : PNP SW/CIRC (S) : P0705	PCM does not receive the correct voltage signal from the switch based on the gear position.	<ul style="list-style-type: none"> • Harness or connectors (The PNP switch circuit is open or shorted.) • PNP switch



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0136S03

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 3) Start engine and maintain the following conditions for at least 5 consecutive seconds.


VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: More than 1.3V

Selector lever: D position (OD "ON" or "OFF")

(S) With GST

Follow the procedure "With CONSULT-II".



DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH




QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — PNP/SW

Wiring Diagram — AT — PNP/SW

NIAT0137

AT-PNP/SW-01



REFER TO THE FOLLOWING.
(F22) - ELECTRICAL UNITS

WAT093

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
42	G/OR	PNP SWITCH "N" OR "P" POSITION	WHEN SETTING SELECTOR LEVER TO "N" OR "P" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
60	G/W	PNP SWITCH "R" POSITION	WHEN SETTING SELECTOR LEVER TO "R" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
68	BR/Y	PNP SWITCH "1" POSITION	WHEN SETTING SELECTOR LEVER TO "1" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
69	B/W	PNP SWITCH "2" POSITION	WHEN SETTING SELECTOR LEVER TO "2" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
78	W/G	PNP SWITCH "D" POSITION	WHEN SETTING SELECTOR LEVER TO "D" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS

LAT274

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure



NIAT0138

1		CHECK PNP SWITCH CIRCUIT (With CONSULT-II)															
		<p> With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 3. Read out "PN", "R", "D", "2" and "1" position switches moving A/T selector lever to each position. Check the signal of the selector lever position is indicated properly. <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th></th> </tr> </thead> <tbody> <tr> <td>PN POSI SW</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td>R POSITION SW</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td>D POSITION SW</td> <td style="text-align: center;">OFF</td> </tr> <tr> <td>2 POSITION SW</td> <td style="text-align: center;">ON</td> </tr> <tr> <td>1 POSITION SW</td> <td style="text-align: center;">OFF</td> </tr> </tbody> </table> </div> <p style="text-align: right; margin-right: 20px;"><small>SAT701J</small></p> <p style="text-align: center;">OK or NG</p>	DATA MONITOR		MONITORING		PN POSI SW	OFF	R POSITION SW	OFF	D POSITION SW	OFF	2 POSITION SW	ON	1 POSITION SW	OFF	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p>AT</p> <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p>
DATA MONITOR																	
MONITORING																	
PN POSI SW	OFF																
R POSITION SW	OFF																
D POSITION SW	OFF																
2 POSITION SW	ON																
1 POSITION SW	OFF																
	▶	GO TO 3.															
	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● PNP switch Refer to "Component Inspection", AT-279. ● Harness for short or open between ignition switch and PNP switch (Main harness) ● Harness for short or open between PNP switch and PCM (Main harness) ● Ignition switch and fuse Refer to EL-9, "POWER SUPPLY ROUTING". ● Diode (P, N positions) 															

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

2	CHECK PNP SWITCH CIRCUIT (Without CONSULT-II)	<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Check voltage between PCM terminals 42, 60, 68, 69, 78 and ground while moving A/T selector lever through each position. <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  </div> <div style="text-align: center;"> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Lever position</th> <th colspan="5">Terminal No.</th> </tr> <tr> <th>42</th> <th>60</th> <th>78</th> <th>69</th> <th>68</th> </tr> </thead> <tbody> <tr> <td>P, N</td> <td>B</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>R</td> <td>0</td> <td>B</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>D</td> <td>0</td> <td>0</td> <td>B</td> <td>0</td> <td>0</td> </tr> <tr> <td>2</td> <td>0</td> <td>0</td> <td>0</td> <td>B</td> <td>0</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>B</td> </tr> </tbody> </table> <p>B: Battery voltage 0: 0V</p> </div> </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p>	Lever position	Terminal No.					42	60	78	69	68	P, N	B	0	0	0	0	R	0	B	0	0	0	D	0	0	B	0	0	2	0	0	0	B	0	1	0	0	0	0	B
Lever position	Terminal No.																																										
	42	60	78	69	68																																						
P, N	B	0	0	0	0																																						
R	0	B	0	0	0																																						
D	0	0	B	0	0																																						
2	0	0	0	B	0																																						
1	0	0	0	0	B																																						
OK	▶	GO TO 3.																																									
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● PNP switch Refer to "Component Inspection", AT-279. ● Harness for short or open between ignition switch and PNP switch (Main harness) ● Harness for short or open between PNP switch and PCM (Main harness) ● Ignition switch and fuse Refer to EL-9, "POWER SUPPLY ROUTING". ● Diode (P, N positions) 																																									



WAT207

3	CHECK DTC	<p>Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-275.</p> <p style="text-align: center;">OK or NG</p>
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.

DTC P0705 PARK/NEUTRAL POSITION (PNP) SWITCH

QG18DE (EXCEPT CALIF. CA)

Component Inspection



Component Inspection

PARK/NEUTRAL POSITION SWITCH

NIAT0139

NIAT0139S01

1. Check continuity between terminals 1 and 2 and between terminals 3 and 4, 5, 6, 8, while moving manual shaft through each position.

Lever position	Terminal No.	
P	—	1 — 2
R	3 — 8	—
N	—	1 — 2
D	3 — 6	—
2	3 — 5	—
1	3 — 4	—


2. If NG, check again with control cable disconnected from manual shaft of A/T assembly. Refer to step 1.
3. If OK on step 2, adjust control cable. Refer to "Control Cable Adjustment", AT-434.
4. If NG on step 2, remove PNP switch from A/T and check continuity of PNP switch terminals. Refer to step 1.
5. If OK on step 4, adjust PNP switch. Refer to "Park/Neutral Position (PNP) Switch Adjustment", AT-434.
6. If NG on step 4, replace PNP switch.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT


QG18DE (EXCEPT CALIF. CA)

Description



Description

The A/T fluid temperature sensor detects the A/T fluid temperature and sends a signal to the PCM. NIAT0140



CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NIAT0140S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
A/T fluid temperature sensor	Cold [20°C (68°F)]	Approximately 1.5V
	↓	↓
	Hot [80°C (176°F)]	Approximately 0.5V

ON BOARD DIAGNOSIS LOGIC

NIAT0140S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : ATF TEMP SEN/CIRC (P) : P0710	PCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • A/T fluid temperature sensor

DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

QG18DE (EXCEPT CALIF. CA)

Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT020K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0140S04

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 2) Start engine and maintain the following conditions for at least 10 minutes (Total). (It is not necessary to maintain continuously.)

CMPS-RPM (REF): 450 rpm or more

VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: More than 1.2V

Selector lever: D position (OD "ON")

With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT


QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — FTS

Wiring Diagram — AT — FTS

N/A70141

AT-FTS-01



REFER TO THE FOLLOWING.
 (F22) - ELECTRICAL UNITS

WAT095

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
58	B	THROTTLE POSITION SENSOR (GROUND)	—	1V OR LESS
91	BR	A/T FLUID TEMPERATURE SENSOR	WHEN ATF TEMPERATURE IS 20 ° C (68° F)	APPROX. 1.5V
			WHEN ATF TEMPERATURE IS 80 ° C (176° F)	APPROX. 0.5V

LAT276

DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0142

1	INSPECTION START	
Do you have CONSULT-II?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	GO TO 3.

GI
MA
EM

2	CHECK INPUT SIGNAL OF A/T FLUID TEMPERATURE SENSOR (With CONSULT-II)															
<p>📞 With CONSULT-II</p> <p>1. Start engine.</p> <p>2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.</p> <p>3. Read out the value of "FLUID TEMP SE".</p> <p style="color: blue;">Voltage: Cold [20°C (68°F)] → Hot [80°C (176°F)]: Approximately 1.5V → 0.5V</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th></th> </tr> </thead> <tbody> <tr> <td>VHCL/S SE-A/T</td> <td>XXX km/h</td> </tr> <tr> <td>VHCL/S SE-MTR</td> <td>XXX km/h</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td>FLUID TEMP SE</td> <td>XXX V</td> </tr> <tr> <td>BATTERY VOLT</td> <td>XXX V</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		VHCL/S SE-A/T	XXX km/h	VHCL/S SE-MTR	XXX km/h	THRTL POS SEN	XXX V	FLUID TEMP SE	XXX V	BATTERY VOLT	XXX V
DATA MONITOR																
MONITORING																
VHCL/S SE-A/T	XXX km/h															
VHCL/S SE-MTR	XXX km/h															
THRTL POS SEN	XXX V															
FLUID TEMP SE	XXX V															
BATTERY VOLT	XXX V															
OK or NG																
OK	▶	GO TO 4.														
NG	▶	GO TO 5.														

LC
EC
FE
CL
MT
AT
AX



SAT614J

SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)


3	CHECK INPUT SIGNAL OF A/T FLUID TEMPERATURE SENSOR (Without CONSULT-II)
<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Check voltage between PCM terminal 91 and ground while warming up A/T. 	
	
<p>Voltage: Cold [20°C (68°F)] → Hot [80°C (176°F)]: Approximately 1.5V → 0.5V</p>	
LAT209	
<ol style="list-style-type: none"> 3. Turn ignition switch to "OFF" position. 4. Disconnect PCM harness connector. 5. Check continuity between terminal 58 and ground. 	
	
<p>Continuity should exist.</p>	
LAT210	
<p>If OK, check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 4.
NG	▶ GO TO 5.

4	CHECK DTC
<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-281.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶ INSPECTION END
NG	▶ <ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.


DTC P0710 A/T FLUID TEMPERATURE SENSOR CIRCUIT

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

5	CHECK A/T FLUID TEMPERATURE SENSOR WITH TERMINAL CORD ASSEMBLY	
<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminals 6 and 7 when A/T is cold.</p>		
		
<p>Resistance: Cold [20°C (68°F)] Approximately 2.5 kΩ</p>		
<p>4. Reinstall any part removed.</p>		
LAT160		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	<p>1. Remove oil pan. 2. Check the following items:</p> <ul style="list-style-type: none"> ● A/T fluid temperature sensor Refer to "Component Inspection", AT-285. ● Harness of terminal cord assembly for short or open

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



Component Inspection

A/T FLUID TEMPERATURE SENSOR

NIAT0143

NIAT0143S01


- For removal, refer to "REMOVAL", AT-433.
- Check resistance between two terminals while changing temperature as shown at left.

Temperature °C (°F)	Resistance
20 (68)	Approximately 2.5 kΩ
80 (176)	Approximately 0.3 kΩ

DTC P0720 VEHICLE SPEED SENSOR-A/T (REVOLUTION SENSOR)

QG18DE (EXCEPT CALIF. CA)

Description





Description

The revolution sensor detects the revolution of the idler gear parking pawl lock gear and emits a pulse signal. The pulse signal is sent to the PCM which converts it into vehicle speed.

NIAT0144

ON BOARD DIAGNOSIS LOGIC

NIAT0144S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
 : VEH SPD SEN/CIR AT  : P0720	PCM does not receive the proper voltage signal from the sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Revolution sensor

DTC P0720 VEHICLE SPEED SENSOR-A/T (REVOLUTION SENSOR)

QG18DE (EXCEPT CALIF. CA)

Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT020K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0144S03

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- 2) Drive vehicle and check for an increase of "VHCL/S SE-MTR" value increase.
If the check result is NG, go to "DIAGNOSTIC PROCEDURE", AT-369.
If the check result is OK, go to following step.
- 3) Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 4) Start engine and maintain the following conditions for at least 5 consecutive seconds.
VHCL SPEED SE: 30 km/h (19 MPH) or more
THRTL POS SEN: More than 1.2V
Selector lever: D position (OD "ON")
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.
If the check result is NG, go to "DIAGNOSTIC PROCEDURE", AT-289.
If the check result is OK, go to following step.
- 5) Maintain the following conditions for at least 5 consecutive seconds.
CMPS-RPM (REF): 3,500 rpm or more
THRTL POS SEN: More than 1.2V
Selector lever: D position (OD "ON")
Driving location: Driving the vehicle uphill (increased engine load) will help maintain the driving conditions required for this test.

With GST

Follow the procedure "With CONSULT-II".

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0720 VEHICLE SPEED SENSOR-A/T (REVOLUTION SENSOR)


QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — VSSA/T


Wiring Diagram — AT — VSSA/T

NIAT0145

AT-VSSA/T-01



REFER TO THE FOLLOWING.
(F22) - ELECTRICAL UNITS



WAT094

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
58	B	THROTTLE POSITION SENSOR (GROUND)	—	1V OR LESS
*1	W	REVOLUTION SENSOR	WHEN MOVING AT 20 KM/H (12 MPH), USE THE CONSULT-II PULSE FREQUENCY MEASURING FUNCTION	150 Hz
109	BR/R	POWER SOURCE	WHEN TURNING IGNITION SWITCH TO "ON"	BATTERY VOLTAGE
			WHEN TURNING IGNITION SWITCH TO "OFF"	1V OR LESS

WN : WITH NVIS (NATS) *1 WN : 76
ON : WITHOUT NVIS (NATS) ON : 66

LAT275

DTC P0720 VEHICLE SPEED SENSOR-A/T (REVOLUTION SENSOR)

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0146

1	CHECK INPUT SIGNAL (With CONSULT-II)															
<p> With CONSULT-II</p> <p>1. Start engine.</p> <p>2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II.</p> <p>3. Read out the value of "VHCL/S SE-A/T" while driving. Check the value changes according to driving speed.</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th></th> </tr> </thead> <tbody> <tr> <td>VHCL/S SE-A/T</td> <td>XXX km/h</td> </tr> <tr> <td>VHCL/S SE-MTR</td> <td>XXX km/h</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td>FLUID TEMP SE</td> <td>XXX V</td> </tr> <tr> <td>BATTERY VOLT</td> <td>XXX V</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		VHCL/S SE-A/T	XXX km/h	VHCL/S SE-MTR	XXX km/h	THRTL POS SEN	XXX V	FLUID TEMP SE	XXX V	BATTERY VOLT	XXX V
DATA MONITOR																
MONITORING																
VHCL/S SE-A/T	XXX km/h															
VHCL/S SE-MTR	XXX km/h															
THRTL POS SEN	XXX V															
FLUID TEMP SE	XXX V															
BATTERY VOLT	XXX V															
SAT614J																
OK or NG																
OK	▶	GO TO 3.														
NG	▶	GO TO 2.														

GI
MA
EM
LC
EC
FE
CL
MT

2	CHECK REVOLUTION SENSOR (With CONSULT-II)							
<p> Without CONSULT-II</p> <p>1. Start engine.</p>								
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th style="width: 60%;">Condition</th> <th>Judgement standard using "PCM TERMINALS AND REFERENCE VALUE"</th> </tr> </thead> <tbody> <tr> <td style="vertical-align: top;"> When moving at 20 km/h (12 MPH, use the CONSULT-II pulse frequency measuring function. *1 CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector. *1: A circuit tester cannot be used to test this item. </td> <td style="text-align: center; vertical-align: middle;">150 Hz</td> </tr> <tr> <td style="vertical-align: top;">When vehicle is not moving</td> <td style="text-align: center; vertical-align: middle;">Under 1.3V or over 4.5V</td> </tr> </tbody> </table>			Condition	Judgement standard using "PCM TERMINALS AND REFERENCE VALUE"	When moving at 20 km/h (12 MPH, use the CONSULT-II pulse frequency measuring function. *1 CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector. *1: A circuit tester cannot be used to test this item.	150 Hz	When vehicle is not moving	Under 1.3V or over 4.5V
Condition	Judgement standard using "PCM TERMINALS AND REFERENCE VALUE"							
When moving at 20 km/h (12 MPH, use the CONSULT-II pulse frequency measuring function. *1 CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector. *1: A circuit tester cannot be used to test this item.	150 Hz							
When vehicle is not moving	Under 1.3V or over 4.5V							
LAT239								
<p>● Harness for short or open between PCM and revolution sensor (Main harness). Refer to wiring diagram, AT-288.</p>								
OK or NG								
OK	▶	GO TO 3.						
NG	▶	Repair or replace damaged parts.						

AT
AX
SU
BR
ST
RS
BT
HA

3	CHECK DTC	
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-287.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	GO TO 4.

SC
EL
IDX

**DTC P0720 VEHICLE SPEED SENSOR-A/T
(REVOLUTION SENSOR)**

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

4	CHECK PCM INSPECTION
1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Repair or replace damaged parts.

DTC P0725 ENGINE SPEED SIGNAL

QG18DE (EXCEPT CALIF. CA)



Description

Description

The engine speed signal is sent from the tachometer to the PCM. NIAT0148

ON BOARD DIAGNOSIS LOGIC

NIAT0148S02

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
 : ENGINE SPEED SIG  : P0725	PCM does not receive the proper voltage signal from combination meter.	<ul style="list-style-type: none"> Harness or connectors (The sensor circuit is open or shorted.)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT020K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0148S03

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- Start engine and maintain the following conditions for at least 10 consecutive seconds.

VHCL SPEED SE: 10 km/h (6 MPH) or more

THRTL POS SEN: More than 1.2V

Selector lever: D position (OD "ON")

With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0725 ENGINE SPEED SIGNAL



QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — ENGSS

Wiring Diagram — AT — ENGSS

NIAT0149

AT-ENGSS-01



REFER TO THE FOLLOWING.
(F22) - ELECTRICAL UNITS

LAT138

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
32	L/OR	ENGINE SPEED SIGNAL	REFER TO PCM INSPECTION TABLE	—

LAT277

DTC P0725 ENGINE SPEED SIGNAL

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0150

1	CHECK DTC WITH PCM	
Perform diagnostic test mode II (self- diagnostic results) for engine control. Check ignition signal circuit condition.		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	Check ignition signal circuit for engine control. Refer to EC-549 , "DTC P1320 IGNITION SIGNAL".

GI
MA
EM
LC

2	CHECK INPUT SIGNAL (With CONSULT-II)															
<p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 3. Read out the value of "ENGINE SPEED". <p>Check engine speed changes according to throttle position.</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITORING</th> <th style="text-align: center;"></th> </tr> </thead> <tbody> <tr> <td>ENGINE SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>TURBINE REV</td> <td>XXX rpm</td> </tr> <tr> <td>OVERDRIVE SW</td> <td>ON</td> </tr> <tr> <td>PN POSI SW</td> <td>OFF</td> </tr> <tr> <td>R POSITION SW</td> <td>OFF</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		ENGINE SPEED	XXX rpm	TURBINE REV	XXX rpm	OVERDRIVE SW	ON	PN POSI SW	OFF	R POSITION SW	OFF
DATA MONITOR																
MONITORING																
ENGINE SPEED	XXX rpm															
TURBINE REV	XXX rpm															
OVERDRIVE SW	ON															
PN POSI SW	OFF															
R POSITION SW	OFF															
OK or NG																
OK	▶	GO TO 4.														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between PCM and tachometer ● Resistor and ignition coil <p>Refer to EC-549, "DTC P1320 IGNITION SIGNAL".</p>														

EC
FE
CL
MT

AT

AX

SAT645J

SU

BR

ST

RS

BT

HA

SC


EL

IDX

DTC P0725 ENGINE SPEED SIGNAL

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

3	CHECK INPUT SIGNAL (Without CONSULT-II)	
<p>⊗ Without CONSULT-II</p> <p>1. Start engine.</p> <p>2. Check voltage between PCM terminal 32 and ground.</p> <p style="color: blue;">Voltage (Idle speed): Refer to EC-156, "PCM Terminal and Reference Value".</p> <div style="text-align: center;">  </div> <p style="text-align: right;">LAT212</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 4.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between PCM and tachometer ● Resistor and ignition coil <p>Refer to EC-549, "DTC P1320 IGNITION SIGNAL".</p>

4	CHECK DTC	
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-291.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform PCM input/output signal inspection.</p> <p>2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.</p>

DTC P0731 A/T 1ST GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Description

Description

- This is an OBD-II self-diagnostic item and not available in PCM self-diagnosis. NIAT0151
- This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction. GI
- This malfunction is detected when the A/T does not shift into first gear position as instructed by the PCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc. MA

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

ON BOARD DIAGNOSTIC LOGIC

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by PCM as follows: NIAT0151S02

Torque converter slip ratio = $A \times C/B$

A: Output shaft revolution signal from revolution sensor FE



B: Engine speed signal from tachometer CL

C: Gear ratio determined as gear position which PCM supposes
If the actual gear position is higher than the position (1st) supposed by PCM, the slip ratio will be more than normal. In case the ratio exceeds the specified value, PCM judges this diagnosis malfunction. MT

This malfunction will be caused when either shift solenoid valve A is stuck open or shift solenoid valve B is stuck open. AT

Gear position supposed by PCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve A stuck open	2*	2	3	3
In case of gear position with shift solenoid valve B stuck open	4*	3	3	4

*: P0731 is detected. AX

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
 : A/T 1ST GR FNCTN	A/T cannot be shifted to the 1st gear position even if electrical circuit is good.	<ul style="list-style-type: none"> ● Shift solenoid valve A ● Shift solenoid valve B ● Each clutch ● Hydraulic control circuit
 : P0731		

DTC P0731 A/T 1ST GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)


Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0151S03

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always drive vehicle on a level road to improve the accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- 2) Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

- 3) Select "1ST GR FNCTN P0731" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT-II and touch "START".
- 4) Accelerate vehicle to 20 to 25 km/h (12 to 16 MPH) under the following condition and release the accelerator pedal completely.

THROTTLE POSI: Less than 1.0/8 (at all times during step 4)

Selector lever: D position (OD "ON")

- Check that "GEAR" shows "2" after releasing pedal.
- 5) Depress accelerator pedal to WOT (more than 7.0/8 of "THROTTLE POSI") quickly from a speed of 20 to 25 km/h (12 to 16 MPH) until "TESTING" changes to "STOP VEHICLE" or "COMPLETED". (It will take approximately 3 seconds.)
If the check result NG appears on CONSULT-II screen, go to "Diagnostic Procedure", AT-299.
If "STOP VEHICLE" appears on CONSULT-II screen, go to the following step.
 - Check that "GEAR" shows "1" when depressing accelerator pedal to WOT.
 - If "TESTING" does not appear on CONSULT-II for a long time, select "SELF-DIAGNOSIS" for "ENGINE". In case a 1st trip DTC other than P0731 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".
 - 6) Stop vehicle.
 - 7) Follow the instruction displayed. (Check for normal shifting referring to the table below.)

DTC P0731 A/T 1ST GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Description (Cont'd)

Vehicle condition	Gear on actual transmission shift pattern when screen is changed to 1 → 2 → 3 → 4	GI
No malfunction exists	1 → 2 → 3 → 4	
Malfunction for P0731 exists.	2 → 2 → 3 → 3	MA
	4 → 3 → 3 → 4	

- 8) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "Diagnostic Procedure".)
 Refer to "Diagnostic Procedure", AT-299.
 Refer to "Shift Schedule", AT-540.

With GST
 Follow the procedure "With CONSULT-II".

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P0731 A/T 1ST GEAR FUNCTION


QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — 1ST

Wiring Diagram — AT — 1ST

=NIAT0152

AT-1STSIG-01



: DETECTABLE LINE FOR DTC
 : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.
 (F22) - ELECTRICAL UNITS

WAT096

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
26	L/W	SHIFT SOLENOID VALVE A	WHEN SHIFT SOLENOID VALVE A OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE A DOES NOT OPERATE	1V OR LESS
27	L/Y	SHIFT SOLENOID VALVE B	WHEN SHIFT SOLENOID VALVE B OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE B DOES NOT OPERATE	1V OR LESS

LAT278

Diagnostic Procedure

NIAT0153


1	CHECK SHIFT SOLENOID VALVE	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433.</p> <p>2. Check shift solenoid valve operation.</p> <ul style="list-style-type: none"> ● Shift solenoid valve A ● Shift solenoid valve B <p>Refer to "Component Inspection", AT-300.</p> <div style="text-align: center; margin: 10px 0;"> </div> <p style="text-align: center; margin-top: 10px;">OK or NG</p>	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p style="background-color: black; color: white; padding: 2px;">AT</p> <p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p>
OK	▶	GO TO 2.	
NG	▶	Repair or replace shift solenoid valve assembly.	

WAT163


DTC P0731 A/T 1ST GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

2	CHECK CONTROL VALVE
<p>1. Disassemble control valve assembly. Refer to "Control Valve Assembly", AT-540.</p> <p>2. Check to ensure that:</p> <ul style="list-style-type: none"> • Valve, sleeve and plug slide along valve bore under their own weight. • Valve, sleeve and plug are free from burrs, dents and scratches. • Control valve springs are free from damage, deformation and fatigue. • Hydraulic line is free from obstacles. 	
	
SAT367H	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair control valve assembly.

3	CHECK DTC
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-296.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Check control valve again. Repair or replace control valve assembly.



Component Inspection

SHIFT SOLENOID VALVE A AND B

NIAT0154

NIAT0154S01

- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0154S0101


- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
Shift solenoid valve A	2	Ground	20 - 30Ω
Shift solenoid valve B	1		5 - 20Ω

DTC P0731 A/T 1ST GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Component Inspection (Cont'd)



Operation Check

NIAT0154S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0732 A/T 2ND GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Description

Description

- This is an OBD-II self-diagnostic item and not available in PCM self-diagnosis. NIAT0155
- This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into second gear position as instructed by the PCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, etc.

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

ON BOARD DIAGNOSTIC LOGIC

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by PCM as follows: NIAT0155S02

Torque converter slip ratio = A x C/B

A: Output shaft revolution signal from revolution sensor



B: Engine speed signal from tachometer

C: Gear ratio determined as gear position which PCM supposes
 If the actual gear position is higher than the position (2nd) supposed by PCM, the slip ratio will be more than normal. In case the ratio exceeds the specified value, PCM judges this diagnosis malfunction.

This malfunction will be caused when shift solenoid valve B is stuck open.

Gear position supposed by PCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve B stuck open	4	3*	3	4

*: P0732 is detected.

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
 : A/T 2ND GR FNCTN  : P0732	A/T cannot be shifted to the 2nd gear position even if electrical circuit is good.	<ul style="list-style-type: none"> ● Shift solenoid valve B ● Each clutch ● Hydraulic control circuit

DTC P0732 A/T 2ND GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)


Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0155S03

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always drive vehicle on a level road to improve the accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

- Select "2ND GR FNCTN P0732" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT-II and touch "START".
- Accelerate vehicle to 50 to 55 km/h (31 to 34 MPH) under the following condition and release the accelerator pedal completely.

THROTTLE POSI: Less than 1.0/8 (at all times during step 4)

Selector lever: D position (OD "ON")

- Check that "GEAR" shows "3" or "4" after releasing pedal.
- Depress accelerator pedal to WOT (more than 7.0/8 of "THROTTLE POSI") quickly from a speed of 50 to 55 km/h (31 to 34 MPH) until "TESTING" changes to "STOP VEHICLE" or "COMPLETED". (It will take approximately 3 seconds.)
If the check result NG appears on CONSULT-II screen, go to "Diagnostic Procedure", AT-306.
If "STOP VEHICLE" appears on CONSULT-II screen, go to following step.
 - Check that "GEAR" shows "2" when depressing accelerator pedal to WOT.
 - If "TESTING" does not appear on CONSULT-II for a long time, select "SELF-DIAGNOSIS" for "ENGINE". In case a 1st trip DTC other than P0732 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".
 - Stop vehicle.
 - Follow the instruction displayed. (Check for normal shifting referring to the table below.)

Vehicle condition	Gear on actual transmission shift pattern when screen is changed to 1 → 2 → 3 → 4
No malfunction exists	1 → 2 → 3 → 4
Malfunction for P0732 exists.	4 → 3 → 3 → 4

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0732 A/T 2ND GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Description (Cont'd)

- 8) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "Diagnostic Procedure".)
Refer to "Diagnostic Procedure", AT-306.
Refer to "Shift Schedule", AT-540.



With GST

Follow the procedure "With CONSULT-II".

DTC P0732 A/T 2ND GEAR FUNCTION


QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — 2ND

Wiring Diagram — AT — 2ND

=NIAT0156

AT-2NDSIG-01



— : DETECTABLE LINE FOR DTC
 — : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.
 (F22) - ELECTRICAL UNITS

WAT097

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
27	L/Y	SHIFT SOLENOID VALVE B	WHEN SHIFT SOLENOID VALVE B OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE B DOES NOT OPERATE	1V OR LESS

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT**
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL
- IDX

LAT279

DTC P0732 A/T 2ND GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0157

1	CHECK SHIFT SOLENOID VALVE
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433.</p> <p>2. Check shift solenoid valve operation.</p> <ul style="list-style-type: none"> ● Shift solenoid valve B <p>Refer to "Component Inspection", AT-307.</p>	
OK or NG	
OK	▶ GO TO 2.
NG	▶ Repair or replace shift solenoid valve assembly.

WAT164

2	CHECK CONTROL VALVE
<p>1. Disassemble control valve assembly. Refer to "Control Valve Assembly", AT-465.</p> <p>2. Check to ensure that:</p> <ul style="list-style-type: none"> ● Valve, sleeve and plug slide along valve bore under their own weight. ● Valve, sleeve and plug are free from burrs, dents and scratches. ● Control valve springs are free from damage, deformation and fatigue. ● Hydraulic line is free from obstacles. 	
OK or NG	
OK	▶ GO TO 3.
NG	▶ Repair control valve assembly.

SAT367H


DTC P0732 A/T 2ND GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

3	CHECK DTC
Perform Diagnostic Trouble Code (DTC) confirmation procedure, AT-303.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Check control valve again. Repair or replace control valve assembly.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



Component Inspection SHIFT SOLENOID VALVE B

NIAT0158

NIAT0158S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0158S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
Shift solenoid valve B	1	Ground	10 - 20Ω



Operation Check

NIAT0158S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

DTC P0733 A/T 3RD GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Description

Description

- This is an OBD-II self-diagnostic item and not available in PCM self-diagnosis. NIAT0159
- This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into third gear position as instructed by the PCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, malfunctioning servo piston or brake band, etc.

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

ON BOARD DIAGNOSTIC LOGIC

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by PCM as follows: NIAT0159S02

Torque converter slip ratio = $A \times C/B$

A: Output shaft revolution signal from revolution sensor



B: Engine speed signal from tachometer

C: Gear ratio determined as gear position which PCM supposes
 If the actual gear position is higher than the position (3rd) supposed by PCM, the slip ratio will be more than normal. In case the ratio exceeds the specified value, PCM judges this diagnosis malfunction.

This malfunction will be caused when shift solenoid valve A is stuck closed.

Gear position supposed by PCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve A stuck closed	1	1	4*	4

*: P0733 is detected.

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
 : A/T 3RD GR FNCTN  : P0733	A/T cannot be shifted to the 3rd gear position even if electrical circuit is good.	<ul style="list-style-type: none"> ● Shift solenoid valve A ● Each clutch ● Hydraulic control circuit

DTC P0733 A/T 3RD GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)


Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0159S03

CAUTION:

- Always drive vehicle at a safe speed.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always drive vehicle on a level road to improve the accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

- Select "3RD GR FNCTN P0733" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT-II and touch "START".
- Accelerate vehicle to 70 to 85 km/h (43 to 53 MPH) under the following condition and release the accelerator pedal completely.

THROTTLE POSI: Less than 1.0/8 (at all times during step 4)

Selector lever: D position (OD "ON")

- Check that "GEAR" shows "4" after releasing pedal.
- Depress accelerator pedal steadily with 3.5/8 - 4.5/8 of "THROTTLE POSI" from a speed of 70 to 85 km/h (43 to 53 MPH) until "TESTING" changes to "STOP VEHICLE" or "COMPLETED". (It will take approximately 3 seconds.)
If the check result NG appears on CONSULT-II screen, go to "Diagnostic Procedure", AT-312.
If "STOP VEHICLE" appears on CONSULT-II screen, go to following step.
 - Check that "GEAR" shows "3" when depressing accelerator pedal with 3.5/8 - 4.5/8 of "THROTTLE POSI".
 - If "TESTING" does not appear on CONSULT-II for a long time, select "SELF-DIAGNOSIS" for "ENGINE". In case a 1st trip DTC other than P0733 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".
 - Stop vehicle.
 - Follow the instruction displayed. (Check for normal shifting referring to the table below.)

Vehicle condition	Gear on actual transmission shift pattern when screen is changed to 1 → 2 → 3 → 4
No malfunction exists.	1 → 2 → 3 → 4
Malfunction for P0733 exists.	1 → 1 → 4 → 4

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0733 A/T 3RD GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Description (Cont'd)

- 8) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "Diagnostic Procedure".)
Refer to "Diagnostic Procedure", AT-312.
Refer to "Shift Schedule", AT-540.



With GST

Follow the procedure "With CONSULT-II".

DTC P0733 A/T 3RD GEAR FUNCTION


QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — 3RD

Wiring Diagram — AT — 3RD

=NIAT0160

AT-3RDSIG-01



— : DETECTABLE LINE FOR DTC
— : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.
(F22) - ELECTRICAL UNITS

WAT098

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND


TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
26	L/W	SHIFT SOLENOID VALVE A	WHEN SHIFT SOLENOID VALVE A OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE A DOES NOT OPERATE	1V OR LESS

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


LAT280

Diagnostic Procedure

NIAT0161

1	CHECK SHIFT SOLENOID VALVE	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433.</p> <p>2. Check shift solenoid valve operation.</p> <ul style="list-style-type: none"> ● Shift solenoid valve A Refer to "Component Inspection" below.
		
		OK or NG
OK	▶	GO TO 2.
NG	▶	Repair or replace shift solenoid valve assembly.

WAT166

2	CHECK CONTROL VALVE	<p>1. Disassemble control valve assembly. Refer to "Control Valve Assembly", AT-466.</p> <p>2. Check to ensure that:</p> <ul style="list-style-type: none"> ● Valve, sleeve and plug slide along valve bore under their own weight. ● Valve, sleeve and plug are free from burrs, dents and scratches. ● Control valve springs are free from damage, deformation and fatigue. ● Hydraulic line is free from obstacles.
		
		OK or NG
OK	▶	GO TO 3.
NG	▶	Repair control valve assembly.

SAT367H


DTC P0733 A/T 3RD GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

3	CHECK DTC
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-309.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Check control valve again. Repair or replace control valve assembly.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



Component Inspection SHIFT SOLENOID VALVE A

NIAT0162

NIAT0162S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0162S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
Shift solenoid valve A	2	Ground	20 - 30Ω



Operation Check

NIAT0162S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Description

Description

- This is an OBD-II self-diagnostic item and not available in PCM self-diagnosis. NIATO163
- This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into fourth gear position or the torque converter clutch does not lock up as instructed by the PCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, malfunctioning oil pump or torque converter clutch, etc.

Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.

NIATO163S01

Monitor item	Condition	Specification
Line pressure solenoid valve duty	Small throttle opening (Low line pressure)	Approximately 24%
	↓	↓
	Large throttle opening (High line pressure)	Approximately 95%

ON BOARD DIAGNOSTIC LOGIC

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by PCM as follows: NIATO163S03

Torque converter slip ratio = A x C/B

A: Output shaft revolution signal from revolution sensor

B: Engine speed signal from tachometer

C: Gear ratio determined as gear position which PCM supposes

If the actual gear position is much lower than the position (4th) supposed by PCM, the slip ratio will be much less than normal. In case the ratio does not reach the specified value, PCM judges this diagnosis malfunction.

This malfunction will be caused when shift solenoid valve B is stuck closed.

Gear position supposed by PCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve B stuck closed	1	2	2	1*

*: P0734 is detected.

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: A/T 4TH GR FNCTN	A/T cannot be shifted to the 4th gear position even if electrical circuit is good.	<ul style="list-style-type: none"> ● Shift solenoid valve A ● Shift solenoid valve B ● Line pressure solenoid valve ● Each clutch ● Hydraulic control circuit
: P0734		

DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)


Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIATO163S04

CAUTION:

- Always drive vehicle at a safe speed.
- If conducting this “DTC CONFIRMATION PROCEDURE” again, always turn ignition switch “OFF” and wait at least 5 seconds before continuing.
- Be careful not to rev engine into the red zone on the tachometer.

NOTE:

If “DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always drive vehicle on a level road to improve the accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓜ With CONSULT-II

- 1) Start engine and select “DATA MONITOR” mode for “A/T” with CONSULT-II.
- 2) Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V

If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

- 3) Select “4TH GR FNCTN P0734” of “DTC WORK SUPPORT” mode for “A/T” with CONSULT-II and touch “START”.
- 4) Accelerate vehicle to 45 to 55 km/h (28 to 34 MPH) under the following condition and release the accelerator pedal completely.

THROTTLE POSI: Less than 5.5/8 (at all times during step 4)

Selector lever: D position (OD “ON”)

- Check that “GEAR” shows “3” after releasing pedal.
- 5) Depress accelerator pedal steadily with 1.0/8 - 2.0/8 of “THROTTLE POSI” from a speed of 45 to 55 km/h (28 to 34 MPH) until “TESTING” has turned to “STOP VEHICLE” or “COMPLETED”. (It will take approximately 3 seconds.)
If the check result NG appears on CONSULT-II screen, go to “Diagnostic Procedure”, AT-318.
If “STOP VEHICLE” appears on CONSULT-II screen, go to following step.
 - Check that “GEAR” shows “4” when depressing accelerator pedal with 1.0/8 - 2.0/8 of “THROTTLE POSI”.
 - If “TESTING” does not appear on CONSULT-II for a long time, select “SELF-DIAGNOSIS” for “ENGINE”. In case a 1st trip DTC other than P0734 is shown, refer to applicable “TROUBLE DIAGNOSIS FOR DTC”.

- 6) Stop vehicle.
- 7) Follow the instruction displayed. (Check for normal shifting referring to the table below.)

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Description (Cont'd)

Vehicle condition	Gear on actual transmission shift pattern when screen is changed to 1 → 2 → 3 → 4
No malfunction exists	1 → 2 → 3 → 4
Malfunction for P0734 exists.	1 → 2 → 2 → 1

- 8) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "Diagnostic Procedure".)
Refer to "Diagnostic Procedure", AT-318.
Refer to "Shift Schedule", AT-540.



With GST

Follow the procedure "With CONSULT-II".

DTC P0734 A/T 4TH GEAR FUNCTION



QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — 4TH

Wiring Diagram — AT — 4TH

NIAT0164

AT-4THSIG-01



REFER TO THE FOLLOWING.
(F22) - ELECTRICAL UNITS

WAT099

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
10	R/W	LINE PRESSURE SOLENOID VALVE	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	1.5 - 3.0V
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	0.5V OR LESS
19	P/B	LINE PRESSURE SOLENOID VALVE (WITH DROPPING RESISTOR)	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	5 - 14V
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	0.5V OR LESS
26	L/W	SHIFT SOLENOID VALVE A	WHEN SHIFT SOLENOID VALVE A OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE A DOES NOT OPERATE	1V OR LESS
27	L/Y	SHIFT SOLENOID VALVE B	WHEN SHIFT SOLENOID VALVE B OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE B DOES NOT OPERATE	1V OR LESS

LAT281


DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0165

1	CHECK SHIFT UP (D₃ TO D₄)
<p>During "Cruise Test – Part 1", AT-83, does A/T shift from D₃ to D₄ at the specified speed?</p> <div style="text-align: center;">  <p style="margin: 0;">Accelerator pedal</p> <p style="margin: 0;">Halfway</p> </div> <p style="text-align: right;">SAT988H</p> <p style="text-align: center;">Yes or No</p>	
Yes	▶ GO TO 9.
No	▶ GO TO 2.

2	CHECK LINE PRESSURE											
<p>Perform line pressure test. Refer to "Line Pressure Test", AT-72.</p> <div style="text-align: center; margin: 20px 0;"> <table border="1" style="border-collapse: collapse; width: 60%;"> <thead> <tr> <th rowspan="2">Engine speed rpm</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>D, 2 and 1 positions</th> <th>R position</th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">Idle</td> <td style="text-align: center;">500 (5.1, 73)</td> <td style="text-align: center;">778 (7.9, 113)</td> </tr> <tr> <td style="text-align: center;">Stall</td> <td style="text-align: center;">1,167 (11.9, 169)</td> <td style="text-align: center;">1,816 (18.5, 263)</td> </tr> </tbody> </table> </div> <p style="text-align: right;">LAT236</p> <p style="text-align: center;">OK or NG</p>		Engine speed rpm	Line pressure kPa (kg/cm ² , psi)		D, 2 and 1 positions	R position	Idle	500 (5.1, 73)	778 (7.9, 113)	Stall	1,167 (11.9, 169)	1,816 (18.5, 263)
Engine speed rpm	Line pressure kPa (kg/cm ² , psi)											
	D, 2 and 1 positions	R position										
Idle	500 (5.1, 73)	778 (7.9, 113)										
Stall	1,167 (11.9, 169)	1,816 (18.5, 263)										
OK	▶ GO TO 3.											
NG	▶ GO TO 6.											

DTC P0734 A/T 4TH GEAR FUNCTION


QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

3 CHECK SOLENOID VALVES

1. Remove control valve assembly.
Refer to "REMOVAL", AT-433.
2. Refer to "Component Inspection", AT-322.




OK or NG

OK	▶	GO TO 4.
NG	▶	Replace solenoid valve assembly.

4 CHECK CONTROL VALVE

1. Disassemble control valve assembly.
Refer to "Control Valve Assembly", AT-465.
2. Check to ensure that:
 - Valve, sleeve and plug slide along valve bore under their own weight.
 - Valve, sleeve and plug are free from burrs, dents and scratches.
 - Control valve springs are free from damage, deformation and fatigue.
 - Hydraulic line is free from obstacles.



OK or NG


OK	▶	GO TO 5.
NG	▶	Repair control valve.

DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

5	CHECK SHIFT UP (D₃ TO D₄)	
Does A/T shift from D ₃ to D ₄ at the specified speed?		
OK or NG		
OK	▶	GO TO 9.
NG	▶	Check control valve again. Repair or replace control valve assembly.


6	CHECK LINE PRESSURE SOLENOID VALVE	
<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to AT-433. 2. Refer to "Component Inspection", AT-322. 		
 <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 7.
NG	▶	Replace solenoid valve assembly.

WAT170

DTC P0734 A/T 4TH GEAR FUNCTION

QG18DE (EXCEPT CALIF. CA)



Diagnostic Procedure (Cont'd)

7	CHECK CONTROL VALVE	<p>1. Disassemble control valve assembly. Refer to "Control Valve Assembly", AT-465.</p> <p>2. Check line pressure circuit valves for sticking.</p> <ul style="list-style-type: none"> ● Pressure regulator valve ● Pilot valve ● Pressure modifier valve <div style="text-align: center; margin: 20px 0;">  </div> <p style="text-align: right;">SAT367H</p> <p style="text-align: center;">OK or NG</p>	GI MA EM LC EC FE CL	
	OK	▶	GO TO 8.	
	NG	▶	Repair control valve.	

8	CHECK SHIFT UP (D₃ TO D₄)	<p>Does A/T shift from D₃ to D₄ at the specified speed?</p> <p style="text-align: center;">Yes or No</p>	AT AX SU	
	Yes	▶	GO TO 9.	
	No	▶	Check control valve again. Repair or replace control valve assembly.	

9	CHECK DTC	<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-315.</p> <p style="text-align: center;">OK or NG</p>	BR ST RS BT HA SC EL IDX	
	OK	▶	INSPECTION END	
	NG	▶	Perform "Cruise Test — Part 1", AT-83, again and return to the start point of this test group.	

Component Inspection



Component Inspection SOLENOID VALVES

=NIAT0166

NIAT0166S01

- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0166S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
Shift solenoid valve A	2	Ground	20 - 30Ω
Shift solenoid valve B	1		5 - 20Ω
Line pressure solenoid valve	4		2.5 - 5Ω

Operation Check


NIAT0166S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

QG18DE (EXCEPT CALIF. CA)

Description



WAT237

Description

The torque converter clutch solenoid valve is activated, with the gear in "D₄", by the PCM in response to signals sent from the vehicle speed and throttle position sensors. Lock-up piston operation will then be controlled.

Lock-up operation, however, is prohibited when A/T fluid temperature is too low.

When the accelerator pedal is depressed (less than 2/8) in lock-up condition, the engine speed should not change abruptly. If there is a big jump in engine speed, there is no lock-up.

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NIAT0167S01


Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Torque converter clutch solenoid valve duty	Lock-up "OFF"	Approximately 4%
	↓ Lock-up "ON"	↓ Approximately 94%


ON BOARD DIAGNOSIS LOGIC

NIAT0167S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : TCC SOLENOID/CIRC (G) : P0740	PCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> ● Harness or connectors (The solenoid circuit is open or shorted.) ● T/C clutch solenoid valve



SAT014K



SAT020K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0167S04

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT-II

- 1) Turn ignition switch "ON".
- 2) Select "DATA MONITOR" mode for "ENGINE" with CONSULT-II and wait at least 1 second.

(G) With GST

Follow the procedure "With CONSULT-II".

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE


QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — TCV

Wiring Diagram — AT — TCV

NIAT0168

AT-TCV-01



REFER TO THE FOLLOWING.
F22 - ELECTRICAL UNITS

WAT100

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
29	Y/G	TORQUE CONVERTER CLUTCH SOLENOID VALVE	WHEN A/T PERFORMS LOCK-UP	8 - 15V
			WHEN A/T DOES NOT PERFORM LOCK-UP	1V OR LESS

LAT282


DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE


QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0169

1	CHECK VALVE RESISTANCE	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminal 5 and ground.</p> <div style="text-align: center;">  <p style="margin-left: 200px;">Resistance: 5 - 20Ω</p> </div> <p style="text-align: right;">LAT171</p> <p style="text-align: center;">OK or NG</p>	GI MA EM LC EC FE CL MT AT
OK	▶	GO TO 2.	
NG	▶	1. Remove oil pan. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Torque converter clutch solenoid valve Refer to "Component Inspection", AT-326. ● Harness of terminal cord assembly for short or open 	


2	CHECK POWER SOURCE CIRCUIT	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect PCM harness connector. 3. Check continuity between terminal 5 and PCM harness connector terminal 29.</p> <div style="text-align: center;">  <p style="margin-left: 200px;">Continuity should exist.</p> </div> <p style="text-align: right;">LAT214</p> <p>If OK, check harness for short to ground and short to power.</p> <p>4. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>	AX SU BR ST RS BT HA SC
OK	▶	GO TO 3.	
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.	

3	CHECK DTC	<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-323.</p> <p style="text-align: center;">OK or NG</p>	EL IDX
OK	▶	INSPECTION END	
NG	▶	1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.	

DTC P0740 TORQUE CONVERTER CLUTCH SOLENOID VALVE

QG18DE (EXCEPT CALIF. CA)

Component Inspection



Component Inspection

TORQUE CONVERTER CLUTCH SOLENOID VALVE

NIAT0170
NIAT0170S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0170S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
	5	Ground	
Torque converter clutch solenoid valve	5	Ground	5 - 20Ω



Operation Check

NIAT0170S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (EXCEPT CALIF. CA)

Description

Description

- This is an OBD-II self-diagnostic item and not available in PCM self-diagnosis. NIAT0171
- This malfunction will not be detected while the O/D OFF indicator lamp is indicating another self-diagnosis malfunction.
- This malfunction is detected when the A/T does not shift into fourth gear position or the torque converter clutch does not lock up as instructed by the PCM. This is not caused by electrical malfunction (circuits open or shorted) but by mechanical malfunction such as control valve sticking, improper solenoid valve operation, malfunctioning oil pump or torque converter clutch, etc.

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NIAT0171S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Torque converter clutch solenoid valve duty	Lock-up "OFF"	Approximately 4%
	↓ Lock-up "ON"	↓ Approximately 94%

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (EXCEPT CALIF. CA)

Description (Cont'd)

ON BOARD DIAGNOSTIC LOGIC

—NIAT0171S03

This diagnosis monitors actual gear position by checking the torque converter slip ratio calculated by PCM as follows:

Torque converter slip ratio = A x C/B

A: Output shaft revolution signal from revolution sensor

B: Engine speed signal from tachometer

C: Gear ratio determined as gear position which PCM supposes


If the actual gear position is much lower than the position (4th) supposed by PCM, the slip ratio will be much less than normal. In case the ratio does not reach the specified value, PCM judges this diagnosis malfunction.

This malfunction will be caused when shift solenoid valve B is stuck closed.


Gear position supposed by PCM	1	2	3	4
In case of gear position with no malfunctions	1	2	3	4
In case of gear position with shift solenoid valve B stuck closed	1	2	2	1*

*: P0744 is detected.

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: A/T TCC S/V FNCTN : P0744	A/T cannot perform lock-up even if electrical circuit is good.	<ul style="list-style-type: none"> ● Torque converter clutch solenoid valve ● Line pressure solenoid valve ● Each clutch ● Hydraulic control circuit



SAT014K



SAT971J

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0171S04

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

1) Start engine and select "DATA MONITOR" mode for "A/T" with CONSULT-II.

2) Make sure that output voltage of A/T fluid temperature sensor is within the range below.

FLUID TEMP SEN: 0.4 - 1.5V


If out of range, drive the vehicle to decrease the voltage (warm up the fluid) or stop engine to increase the voltage (cool down the fluid).

3) Select "TCC S/V FNCTN P0744" of "DTC WORK SUPPORT" mode for "A/T" with CONSULT-II and touch "START".

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (EXCEPT CALIF. CA)

Description (Cont'd)



- 4) Accelerate vehicle to more than 80 km/h (50 MPH) and maintain the following condition continuously until "TESTING" has turned to "COMPLETE". (It will take approximately 30 seconds after "TESTING" shows.)

THROTTLE POSI: 1.0/8 - 2.0/8 (at all times during step 4)

Selector lever: D position (OD "ON")

TCC S/V DUTY: More than 94%

VHCL/S SE-A/T: Constant speed of more than 80 km/h (50 MPH)

- Check that "GEAR" shows "4".
 - For shift schedule, refer to SDS, AT-540.
 - If "TESTING" does not appear on CONSULT-II for a long time, select "SELF-DIAGNOSIS". In case a 1st trip DTC other than P0744 is shown, refer to applicable "TROUBLE DIAGNOSIS FOR DTC".
- 5) Make sure that "OK" is displayed. (If "NG" is displayed, refer to "Diagnostic Procedure".)
Refer to "Diagnostic Procedure", AT-331.
Refer to "Shift Schedule", AT-540.

With GST

Follow the procedure "With CONSULT-II".

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)



QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — TCCSIG

Wiring Diagram — AT — TCCSIG

NIAT0172

AT-TCCSIG-01



REFER TO THE FOLLOWING.
 (F22) - ELECTRICAL UNITS

WAT101

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
10	R/W	LINE PRESSURE SOLENOID VALVE	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	1.5 - 3.0V
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	0.5V OR LESS
19	P/B	LINE PRESSURE SOLENOID VALVE (WITH DROPPING RESISTOR)	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	5 - 14V
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	0.5V OR LESS
29	Y/G	TORQUE CONVERTER CLUTCH SOLENOID VALVE	WHEN A/T PERFORMS LOCK-UP	8 - 14V
			WHEN A/T DOES NOT PERFORM LOCK-UP	1V OR LESS

LAT283


DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0173

1	CHECK SHIFT UP (D₃ TO D₄)		
During "Cruise Test – Part 1", AT-83, does A/T shift from D ₃ to D ₄ at the specified speed?			
			
SAT988H			
Yes or No			
Yes	▶	GO TO 10.	
No	▶	GO TO 2.	

GI
MA
EM
LC
EC
FE
CL

2	CHECK LINE PRESSURE													
Perform line pressure test. Refer to "Line Pressure Test", AT-72.														
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Engine speed rpm</th> <th colspan="2">Line pressure kPa (kg/cm², psi)</th> </tr> <tr> <th>D, 2 and 1 positions</th> <th>R position</th> </tr> </thead> <tbody> <tr> <td>Idle</td> <td>500 (5.1, 73)</td> <td>778 (7.9, 113)</td> </tr> <tr> <td>Stall</td> <td>1,167 (11.9, 169)</td> <td>1,816 (18.5, 263)</td> </tr> </tbody> </table>				Engine speed rpm	Line pressure kPa (kg/cm ² , psi)		D, 2 and 1 positions	R position	Idle	500 (5.1, 73)	778 (7.9, 113)	Stall	1,167 (11.9, 169)	1,816 (18.5, 263)
Engine speed rpm	Line pressure kPa (kg/cm ² , psi)													
	D, 2 and 1 positions	R position												
Idle	500 (5.1, 73)	778 (7.9, 113)												
Stall	1,167 (11.9, 169)	1,816 (18.5, 263)												
LAT236														
OK or NG														
OK	▶	GO TO 3.												
NG	▶	GO TO 6.												


MT
AT
AX
SU
BR
ST
RS

BT
HA
SC
EL
IDX

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

3	CHECK CONTROL VALVE	<p>1. Disassemble control valve assembly. Refer to "Control Valve Assembly", AT-465.</p> <p>2. Check to ensure that:</p> <ul style="list-style-type: none"> ● Valve, sleeve and plug slide along valve bore under their own weight. ● Valve, sleeve and plug are free from burrs, dents and scratches. ● Control valve springs are free from damage, deformation and fatigue. ● Hydraulic line is free from obstacles. 	
			
		SAT367H	
		OK or NG	
OK	▶	GO TO 4.	
NG	▶	Repair control valve.	

4	CHECK SHIFT UP (D₃ TO D₄)	Does A/T shift from D ₃ to D ₄ at the specified speed?	
		Yes or No	
Yes	▶	GO TO 5.	
No	▶	Check control valve again. Repair or replace control valve assembly.	

5	CHECK DTC	Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-328.	
		OK or NG	
OK	▶	INSPECTION END	
NG	▶	GO TO 10.CHECK LOCK-UP CONDITION.	

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)


QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

6 CHECK LINE PRESSURE SOLENOID VALVE

1. Remove control valve assembly.
Refer to "REMOVAL", AT-433.
2. Check line pressure solenoid valve operation.
Refer to "Component Inspection", AT-337.




WAT175

OK or NG

OK	▶	GO TO 7.
NG	▶	Replace solenoid valve assembly.

7 CHECK CONTROL VALVE

1. Disassemble control valve assembly.
Refer to "Control Valve Assembly", AT-465.
2. Check line pressure circuit valves for sticking.
 - Pressure regulator valve
 - Pilot valve
 - Pressure modifier valve



SAT367H

OK or NG

OK	▶	GO TO 8.
NG	▶	Repair control valve.


DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

8	CHECK SHIFT UP (D₃ TO D₄)	
Does A/T shift from D ₃ to D ₄ at the specified speed?		
Yes or No		
Yes	▶	GO TO 9.
No	▶	Check control valve again. Repair or replace control valve assembly.


9	CHECK DTC	
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE" AT-328.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	GO TO 10. And check for proper lock-up.


10	CHECK LOCK-UP CONDITION	
During "Cruise Test – Part 1", AT-83, does A/T perform lock-up at the specified speed?		
		
SAT989H		
Yes or No		
Yes	▶	Perform "Cruise Test – Part 1", AT-83, again and return to the start point of this test group.
No	▶	GO TO 11.

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

11	CHECK TORQUE CONVERTER CLUTCH SOLENOID VALVE	<p>1. Remove control valve assembly. Refer to AT-433.</p> <p>2. Check torque converter clutch solenoid valve operation. Refer to "Component Inspection", AT-337.</p> <div style="text-align: center; margin-top: 20px;">  <p style="text-align: center;">Torque converter clutch solenoid valve</p> </div> <p style="text-align: right; margin-top: 10px;">WAT176</p>	GI MA EM LC EC FE CL MT AT AX SU
OK or NG			
OK	▶	GO TO 12.	
NG	▶	Replace solenoid valve assembly.	

12	CHECK CONTROL VALVE	<p>1. Disassemble control valve assembly. Refer to "Control Valve Assembly", AT-465.</p> <p>2. Check control valves for sticking.</p> <ul style="list-style-type: none"> ● Torque converter clutch control valve ● Torque converter clutch relief valve <div style="text-align: center; margin-top: 20px;">  </div> <p style="text-align: right; margin-top: 10px;">SAT367H</p>	BR ST RS BT HA SC EL IDX
OK or NG			
OK	▶	GO TO 13.	
NG	▶	Repair control valve.	

DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)


13	CHECK LOCK-UP CONDITION
Does A/T perform lock-up at the specified speed?	
Yes or No	
Yes	▶ GO TO 14.
No	▶ Check control valve again. Repair or replace control valve assembly.

14	CHECK DTC
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-328.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ Perform "Cruise Test — Part 1", AT-83, again and return to the start point of this test group.


DTC P0744 A/T TCC S/V FUNCTION (LOCK-UP)

QG18DE (EXCEPT CALIF. CA)

Component Inspection



WAT177



WAT178

Component Inspection

SOLENOID VALVES

=NIAT0174

NIAT0174S01

- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0174S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
Line pressure solenoid valve	4	Ground	2.5 - 5Ω
Torque converter clutch solenoid valve	5		5 - 20Ω

Operation Check

NIAT0174S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

DTC P0745 LINE PRESSURE SOLENOID VALVE

QG18DE (EXCEPT CALIF. CA)

Description



Description

The line pressure solenoid valve regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the PCM. NIAT0175

The line pressure duty cycle value is not consistent when the closed throttle position switch is "ON". To confirm the line pressure duty cycle at low pressure, the accelerator (throttle) should be open until the closed throttle position switch is "OFF".

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NIAT0175S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Line pressure solenoid valve duty	Small throttle opening (Low line pressure)	Approximately 24%
	Large throttle opening (High line pressure)	Approximately 95%



NOTE:

The line pressure duty cycle value is not consistent when the closed throttle position switch is "ON". To confirm the line pressure duty cycle at low pressure, the accelerator (throttle) should be open until the closed throttle position switch is "OFF".

ON BOARD DIAGNOSIS LOGIC

NIAT0175S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : L/PRESS SOL/CIRC (SST) : P0745	PCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Line pressure solenoid valve



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0175S04

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 2) Depress accelerator pedal completely and wait at least 1 second.

(SST) With GST

Follow the procedure "With CONSULT-II".

DTC P0745 LINE PRESSURE SOLENOID VALVE


QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — LPSV


Wiring Diagram — AT — LPSV

NIAT0176

AT-LPSV-01



— : DETECTABLE LINE FOR DTC
 - - - : NON-DETECTABLE LINE FOR DTC



REFER TO THE FOLLOWING.
 (F22) - ELECTRICAL UNITS

WAT102

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
10	R/W	LINE PRESSURE SOLENOID VALVE	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	1.5 - 3.0V
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	0.5V OR LESS
19	P/B	LINE PRESSURE SOLENOID VALVE (WITH DROPPING RESISTOR)	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	5 - 14V
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	0.5V OR LESS

LAT284


DTC P0745 LINE PRESSURE SOLENOID VALVE


QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0177

1	CHECK VALVE RESISTANCE	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminal 4 and ground.</p> <div style="display: flex; align-items: center; justify-content: center;">  <div style="margin-left: 20px;"> <p>Resistance: 2.5 - 5Ω</p> </div> </div> <p style="text-align: right;">LAT179</p> <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 2.
NG	▶	<p>1. Remove control valve assembly. Refer to AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Line pressure solenoid valve Refer to "Component Inspection", AT-342. ● Harness of terminal cord assembly for short or open

2	CHECK POWER SOURCE CIRCUIT	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect PCM harness connector. 3. Check resistance between terminal 4 and PCM harness connector terminal 19.</p> <div style="display: flex; align-items: center; justify-content: center;">  <div style="margin-left: 20px;"> <p>Resistance: 10 - 15 Ω</p> </div> </div> <p style="text-align: right;">LAT215</p> <p style="text-align: center;">OK or NG</p>
OK	▶	GO TO 3.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Dropping resistor Refer to "Component Inspection", AT-342. ● Harness for short or open between PCM terminal 19 and terminal cord assembly (Main harness)

DTC P0745 LINE PRESSURE SOLENOID VALVE

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)


3	CHECK POWER SOURCE CIRCUIT	<p>1. Turn ignition switch to "OFF" position.</p> <p>2. Check resistance between terminal 4 and PCM harness connector terminal 10.</p> <div style="text-align: center;"> </div> <p style="text-align: right;">Resistance: 0 Ω</p> <p style="text-align: right;">LAT216</p> <p>If OK, check harness for short to ground and short to power.</p> <p>3. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p>
OK	▶	GO TO 4.	CL
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.	MT

4	CHECK DTC	<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-338.</p> <p style="text-align: center;">OK or NG</p>	<p>AT</p>
OK	▶	INSPECTION END	AX
NG	▶	<p>1. Perform PCM input/output signal inspection.</p> <p>2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.</p>	<p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p> <p>EL</p> <p>IDX</p>

DTC P0745 LINE PRESSURE SOLENOID VALVE

QG18DE (EXCEPT CALIF. CA)

Component Inspection



Component Inspection

LINE PRESSURE SOLENOID VALVE

=NIAT0178

NIAT0178S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0178S0101

- Check resistance between two terminals.


Solenoid valve	Terminal No.		Resistance (Approx.)
	4	Ground	
Line pressure solenoid valve	4	Ground	2.5 - 5Ω



Operation Check

NIAT0178S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.



DROPPING RESISTOR

NIAT0178S02

- Check resistance between two terminals.


Resistance:

10 - 15Ω

DTC P0750 SHIFT SOLENOID VALVE A

QG18DE (EXCEPT CALIF. CA)

Description



Description

Shift solenoid valves A and B are turned “ON” or “OFF” by the PCM^{NIAT0179} in response to signals sent from the PNP switch, vehicle speed and throttle position sensors. Gears will then be shifted to the optimum position.



Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

ON BOARD DIAGNOSIS LOGIC

NIAT0179S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : SFT SOL A/CIRC (P) : P0750	PCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Shift solenoid valve A

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0179S03

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT-II

- 1) Turn ignition switch “ON” and select “DATA MONITOR” mode for “ENGINE” with CONSULT-II.
- 2) Start engine.
- 3) Drive vehicle in D position and allow the transmission to shift “1” → “2” (“GEAR”).

(P) With GST

Follow the procedure “With CONSULT-II”.

DTC P0750 SHIFT SOLENOID VALVE A


QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — SSV/A

Wiring Diagram — AT — SSV/A

NIAT0180

AT-SSV/A-01



REFER TO THE FOLLOWING.
 F22 - ELECTRICAL UNITS

WAT103

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
26	L/W	SHIFT SOLENOID VALVE A	WHEN SHIFT SOLENOID VALVE A OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE A DOES NOT OPERATE	1V OR LESS

LAT280


DTC P0750 SHIFT SOLENOID VALVE A


QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0181

1	CHECK VALVE RESISTANCE	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminal 2 and ground.</p> <div style="display: flex; align-items: center; justify-content: center;">  <div style="margin-left: 20px;"> <p>Resistance: 20 - 30 Ω</p> </div> </div> <p style="text-align: right;">LAT184</p> <p style="text-align: center;">OK or NG</p>	GI MA EM LC EC FE CL MT AT
OK	▶	GO TO 2.	
NG	▶	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Shift solenoid valve A Refer to "Component Inspection", AT-346. ● Harness of terminal cord assembly for short or open 	


2	CHECK POWER SOURCE CIRCUIT	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect PCM harness connector. 3. Check continuity between terminal 2 and PCM harness connector terminal 26.</p> <div style="display: flex; align-items: center; justify-content: center;">  <div style="margin-left: 20px;"> <p>Continuity should exist.</p> </div> </div> <p style="text-align: right;">LAT217</p> <p>If OK, check harness for short to ground and short to power.</p> <p>4. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>	AX SU BR ST RS BT HA SC
OK	▶	GO TO 3.	
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.	

3	CHECK DTC	<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-343.</p> <p style="text-align: center;">OK or NG</p>	EL IDX
OK	▶	INSPECTION END	
NG	▶	<p>1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.</p>	

DTC P0750 SHIFT SOLENOID VALVE A

QG18DE (EXCEPT CALIF. CA)

Component Inspection



Component Inspection SHIFT SOLENOID VALVE A

NIAT0182

NIAT0182S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0182S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
	2	Ground	
Shift solenoid valve A	2	Ground	20 - 30Ω



Operation Check


NIAT0182S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

DTC P0755 SHIFT SOLENOID VALVE B

QG18DE (EXCEPT CALIF. CA)

Description



Description

Shift solenoid valves A and B are turned “ON” or “OFF” by the PCM^{NIAT0183} in response to signals sent from the PNP switch, vehicle speed and throttle position sensors. Gears will then be shifted to the optimum position.



Gear position	1	2	3	4
Shift solenoid valve A	ON (Closed)	OFF (Open)	OFF (Open)	ON (Closed)
Shift solenoid valve B	ON (Closed)	ON (Closed)	OFF (Open)	OFF (Open)

ON BOARD DIAGNOSIS LOGIC

NIAT0183S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
(P) : SFT SOL B/CIRC (SST) : P0755	PCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Shift solenoid valve B

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0183S03

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If “DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE” has been previously conducted, always turn ignition switch “OFF” and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

(P) With CONSULT-II

- 1) Turn ignition switch “ON” and select “DATA MONITOR” mode for “ENGINE” with CONSULT-II.
- 2) Start engine.
- 3) Drive vehicle in D position and allow the transmission to shift 1 → 2 → 3 (“GEAR”).

(SST) With GST

Follow the procedure “With CONSULT-II”.

DTC P0755 SHIFT SOLENOID VALVE B


QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — SSV/B

Wiring Diagram — AT — SSV/B

NIAT0184

AT-SSV/B-01



REFER TO THE FOLLOWING.
 (F22) - ELECTRICAL UNITS

WAT104

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
27	L/Y	SHIFT SOLENOID VALVE B	WHEN SHIFT SOLENOID VALVE B OPERATES	BATTERY VOLTAGE
			WHEN SHIFT SOLENOID VALVE B DOES NOT OPERATE	1V OR LESS

LAT279


DTC P0755 SHIFT SOLENOID VALVE B

QG18DE (EXCEPT CALIF. CA)


Diagnostic Procedure

Diagnostic Procedure

NIAT0185

1	CHECK VALVE RESISTANCE	
<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminal 1 and ground.</p>		
 <div style="float: right; margin-top: 20px;"> <p>Resistance: 5 - 20Ω</p> </div>		
LAT188		
OK or NG		
OK	▶	GO TO 2.
NG	▶	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Shift solenoid valve B Refer to "Component Inspection", AT-350. ● Harness of terminal cord assembly for short or open

GI
MA
EM
LC
EC
FE
CL
MT
AT

2	CHECK POWER SOURCE CIRCUIT	
<p>1. Turn ignition switch to "OFF" position. 2. Disconnect PCM harness connector. 3. Check continuity between terminal 1 and PCM harness connector terminal 27.</p>		
 <div style="float: right; margin-top: 20px;"> <p>Continuity should exist.</p> </div>		
LAT218		
<p>If OK, check harness for short to ground and short to power. 4. Reinstall any part removed.</p>		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.

AX
SU
BR
ST
RS
BT
HA
SC


3	CHECK DTC	
<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-347.</p>		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.</p>

EL
IDX

DTC P0755 SHIFT SOLENOID VALVE B

QG18DE (EXCEPT CALIF. CA)

Component Inspection



Component Inspection SHIFT SOLENOID VALVE B

NIAT0186

NIAT0186S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0186S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
	1	Ground	
Shift solenoid valve B	1	Ground	5 - 20Ω



Operation Check


NIAT0186S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (EXCEPT CALIF. CA)

Description



Description

NIAT0187

- Throttle position sensor
The throttle position sensor detects the throttle valve position and sends a signal to the PCM.
- Throttle position switch
Consists of a wide open throttle position switch and a closed throttle position switch.
The wide open throttle position switch sends a signal to the PCM when the throttle valve is open at least 1/2 of the full throttle position. The closed throttle position switch sends a signal to the PCM when the throttle valve is fully closed.

GI
MA
EM
LC

CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

NIAT0187S01

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
Throttle position sensor	Fully-closed throttle	Approximately 0.5V
	Fully-open throttle	Approximately 4V

EC
FE
CL

ON BOARD DIAGNOSIS LOGIC

NIAT0187S03

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
P : TP SEN/CIRC A/T GST : P1705	PCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> ● Harness or connectors (The sensor circuit is open or shorted.) ● Throttle position sensor ● Throttle position switch

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (EXCEPT CALIF. CA)

Description (Cont'd)

SELECT SYSTEM
A/T
ENGINE

SAT014K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0187S04

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

SELECT DIAG MODE
SELF-DIAG RESULTS
DATA MONITOR
DTC WORK SUPPORT
TCM PART NUMBER

SAT971J

With CONSULT-II

- 1) Apply vacuum to the throttle opener, then check the following. Refer to steps from 1 to 5 of "Preparation", "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52.
- 2) Turn ignition switch "ON" and select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- 3) Check the following.

Accelerator pedal condition	THRTL POS SEN	CLOSED THL/SW	W/O THRL/P-SW
Fully released	Less than 4.7V	ON	OFF
Partially depressed	0.1 - 4.6V	OFF	OFF
Fully depressed	1.9 - 4.6V	OFF	ON

SELECT SYSTEM
A/T
ENGINE

SAT014K

If the check result is NG, go to "Diagnostic Procedure", AT-354.
If the check result is OK, go to following step.

- 4) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 5) Start engine and maintain the following conditions for at least 3 consecutive seconds. Then release accelerator pedal completely.

VHCL SPEED SE: 10 km/h (6 MPH) or more
THRTL POS SEN: Approximately 3V or less
Selector lever: D position (OD "ON")

If the check result is NG, go to "Diagnostic Procedure", AT-354.
If the check result is OK, go to following step.

- 6) Maintain the following conditions for at least 3 consecutive seconds. Then release accelerator pedal completely.

VHCL SPEED SE: 10 km/h (6 MPH) or more
Accelerator pedal: Wide open throttle
Selector lever: D position (OD "ON")

SELECT DIAG MODE
WORK SUPPORT
SELF-DIAG RESULTS
DATA MONITOR
ACTIVE TEST
DTC & SRT CONFIRMATION
ECM PART NUMBER

SAT020K

With GST

Follow the procedure "With CONSULT-II".

DTC P1705 THROTTLE POSITION SENSOR



QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — TPS

Wiring Diagram — AT — TPS

=NIAT0188

AT-TPS-01



REFER TO THE FOLLOWING.
(F22) - ELECTRICAL UNITS

WAT105

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
40	Y/PU	CLOSED THROTTLE POSITION SWITCH	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	BATTERY VOLTAGE
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	1V OR LESS
58	B	GROUND (THROTTLE POSITION SENSOR)	—	1V OR LESS
77	LG	WIDE OPEN THROTTLE POSITION SWITCH	WHEN DEPRESSING ACCELERATOR PEDAL MORE THAN HALF-WAY (ENGINE WARM)	BATTERY VOLTAGE
			WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	1V OR LESS
92	Y	THROTTLE POSITION SENSOR	WHEN DEPRESSING ACCELERATOR PEDAL SLOWLY (ENGINE WARM)	CLOSED: APPROX 0.5V OPEN: APPROX 4V
111	R	THROTTLE POSITION SENSOR (POWER SOURCE)	WHEN TURNING IGNITION SWITCH TO "ON"	4.5 - 5.5V
			WHEN TURNING IGNITION SWITCH TO "OFF"	1V OR LESS

LAT285

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0189

1	CHECK DTC WITH PCM	
Perform diagnostic test mode II (self-diagnostic results) for engine control. Refer to EC-100 , "Malfunction Indicator Lamp (MIL)".		
OK or NG		
OK (With CONSULT-II)	▶	GO TO 2.
OK (Without CONSULT-II)	▶	GO TO 3.
NG	▶	Check throttle position sensor circuit for engine control. Refer to EC-201 , "DTC P0120 THROTTLE POSITION SENSOR".

2	CHECK INPUT SIGNAL (WITH CONSULT-II)															
<p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener then check the following. Refer to steps 1 through 5 of "Preparation", "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 4. Read out the value of "THRTL POS SEN". <p style="margin-left: 20px;">Voltage:</p> <p style="margin-left: 40px;">Fully-closed throttle: Approximately 0.5V</p> <p style="margin-left: 40px;">Fully-open throttle: Approximately 4V</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITORING</th> <th style="text-align: center;"></th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">VHCL/S SE-A/T</td> <td style="text-align: center;">XXX km/h</td> </tr> <tr> <td style="text-align: center;">VHCL/S SE-MTR</td> <td style="text-align: center;">XXX km/h</td> </tr> <tr> <td style="text-align: center;">THRTL POS SEN</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td style="text-align: center;">FLUID TEMP SE</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td style="text-align: center;">BATTERY VOLT</td> <td style="text-align: center;">XXX V</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		VHCL/S SE-A/T	XXX km/h	VHCL/S SE-MTR	XXX km/h	THRTL POS SEN	XXX V	FLUID TEMP SE	XXX V	BATTERY VOLT	XXX V
DATA MONITOR																
MONITORING																
VHCL/S SE-A/T	XXX km/h															
VHCL/S SE-MTR	XXX km/h															
THRTL POS SEN	XXX V															
FLUID TEMP SE	XXX V															
BATTERY VOLT	XXX V															
OK or NG																
OK	▶	GO TO 4.														
NG	▶	Check harness for short or open circuit between PCM and throttle position sensor. (Main harness)														

SAT614J

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

3	CHECK INPUT SIGNAL (WITHOUT CONSULT-II)	
<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener then check the following. Refer to steps 1 through 5 of "Preparation", "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Check voltage between PCM terminals 92 and 58 while accelerator pedal is depressed slowly. (Voltage rises gradually in response to throttle position) 		
<p>Voltage: Fully-closed throttle valve: Approximately 0.5V Fully-open throttle valve: Approximately 4V (Voltage rises gradually in response to throttle position)</p>		
LAT219		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Check harness for short or open circuit between PCM and throttle position sensor. (Main harness)

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (EXCEPT CALIF. CA)


Diagnostic Procedure (Cont'd)

4	CHECK THROTTLE POSITION SWITCH CIRCUIT (WITH CONSULT-II)															
<p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener, then check the following. Refer to steps 1 through 5 of "Preparation", "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 4. Read out "CLOSED THL/SW" and "W/O THRL/P-SW" depressing and releasing accelerator pedal. Check the signal of throttle position switch is indicated properly. 																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="padding: 2px;">Accelerator pedal condition</th> <th colspan="2" style="padding: 2px;">Data monitor</th> </tr> <tr> <th style="padding: 2px;">CLOSED THL/SW</th> <th style="padding: 2px;">W/O THRL/P-SW</th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">Released</td> <td style="padding: 2px; text-align: center;">ON</td> <td style="padding: 2px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 2px;">Fully depressed</td> <td style="padding: 2px; text-align: center;">OFF</td> <td style="padding: 2px; text-align: center;">ON</td> </tr> </tbody> </table>			Accelerator pedal condition	Data monitor		CLOSED THL/SW	W/O THRL/P-SW	Released	ON	OFF	Fully depressed	OFF	ON			
Accelerator pedal condition	Data monitor															
	CLOSED THL/SW	W/O THRL/P-SW														
Released	ON	OFF														
Fully depressed	OFF	ON														
MTBL0011																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="padding: 2px;">DATA MONITOR</th> </tr> <tr> <th style="padding: 2px;">MONITORING</th> <th style="padding: 2px;"></th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">POWERSHIFT SW</td> <td style="padding: 2px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 2px;">CLOSED THL/SW</td> <td style="padding: 2px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 2px;">W/O THRL/P-SW</td> <td style="padding: 2px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 2px;">HOLD SW</td> <td style="padding: 2px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 2px;">BRAKE SW</td> <td style="padding: 2px; text-align: center;">ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		POWERSHIFT SW	OFF	CLOSED THL/SW	OFF	W/O THRL/P-SW	OFF	HOLD SW	OFF	BRAKE SW	ON
DATA MONITOR																
MONITORING																
POWERSHIFT SW	OFF															
CLOSED THL/SW	OFF															
W/O THRL/P-SW	OFF															
HOLD SW	OFF															
BRAKE SW	ON															
SAT702J																
OK or NG																
OK	▶	GO TO 6.														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Throttle position switch — Refer to "Component Inspection", AT-358. ● Harness for short or open between ignition switch and throttle position switch (Main harness) ● Harness for short or open between throttle position switch and PCM (Main harness) 														

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

5	CHECK THROTTLE POSITION SWITCH CIRCUIT (WITHOUT CONSULT-II)												
<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener, then check the following. Refer to steps 1 through 5 of "Preparation", "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Check voltage between PCM terminals 40, 77 and ground while depressing, and releasing accelerator pedal slowly. (After warming up engine) 													
 <table border="1" style="margin-left: auto; margin-right: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Accelerator pedal condition</th> <th colspan="2">Voltage</th> </tr> <tr> <th>Terminal No. 40</th> <th>Terminal No. 77</th> </tr> </thead> <tbody> <tr> <td>Released</td> <td>Battery voltage</td> <td>1V or less</td> </tr> <tr> <td>Fully depressed</td> <td>1V or less</td> <td>Battery voltage</td> </tr> </tbody> </table>			Accelerator pedal condition	Voltage		Terminal No. 40	Terminal No. 77	Released	Battery voltage	1V or less	Fully depressed	1V or less	Battery voltage
Accelerator pedal condition	Voltage												
	Terminal No. 40	Terminal No. 77											
Released	Battery voltage	1V or less											
Fully depressed	1V or less	Battery voltage											
LAT220													
OK or NG													
OK	▶	GO TO 6.											
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Throttle position switch — Refer to "Component Inspection", AT-358. ● Harness for short or open between ignition switch and throttle position switch (Main harness) ● Harness for short or open between throttle position switch and PCM (Main harness) 											


6	CHECK DTC	
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-352.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC P1705 THROTTLE POSITION SENSOR

QG18DE (EXCEPT CALIF. CA)

Component Inspection



Component Inspection THROTTLE POSITION SWITCH

=NIAT0190

NIAT0190S01


NIAT0190S0101

Closed Throttle Position Switch (Idle position)

- Check continuity between terminals 5 and 6.
[Refer to "Preparation", "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52.]

Accelerator pedal condition	Continuity
Released	Yes
Depressed	No

- To adjust closed throttle position switch, refer to **EC-464**, "DTC P0510 CLOSED THROTTLE POSITION SWITCH".



Wide Open Throttle Position Switch

NIAT0190S0102


- Check continuity between terminals 4 and 5.

Accelerator pedal condition	Continuity
Released	No
Depressed	Yes

DTC P1760 OVERRUN CLUTCH SOLENOID VALVE

QG18DE (EXCEPT CALIF. CA)

Description





Description

The overrun clutch solenoid valve is activated by the PCM^{NIAT0191} in response to signals sent from the inhibitor switch, overdrive control switch, vehicle speed and throttle position sensors. The overrun clutch operation will then be controlled.

ON BOARD DIAGNOSIS LOGIC

NIAT0191S02

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
: O/R CLTCH SOL/CIRC : P1760	PCM detects an improper voltage drop when it tries to operate the solenoid valve.	<ul style="list-style-type: none"> • Harness or connectors (The solenoid circuit is open or shorted.) • Overrun clutch solenoid valve



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0191S03

CAUTION:

Always drive vehicle at a safe speed.

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

TESTING CONDITION:

Always drive vehicle on a level road to improve accuracy of test.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for "ENGINE" with CONSULT-II.
- 2) Start engine.
- 3) Accelerate vehicle to a speed of more than 10 km/h (6 MPH) with "D" position (OD "ON").
- 4) Release accelerator pedal completely with "D" position (OD "OFF").

With GST

Follow the procedure "With CONSULT-II".

DTC P1760 OVERRUN CLUTCH SOLENOID VALVE


QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — OVRCSV

Wiring Diagram — AT — OVRCSV

=NIAT0192

AT-OVRCSV-01



REFER TO THE FOLLOWING.
 (F22) - ELECTRICAL UNITS

WAT106

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
24	L/B	OVERRUN CLUTCH SOLENOID VALVE	WHEN OVERRUN CLUTCH SOLENOID VALVE OPERATES	BATTERY VOLTAGE
			WHEN OVERRUN CLUTCH SOLENOID VALVE DOES NOT OPERATE	1V OR LESS

LAT286


DTC P1760 OVERRUN CLUTCH SOLENOID VALVE


QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0193

1	CHECK VALVE RESISTANCE	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect terminal cord assembly connector in engine compartment. 3. Check resistance between terminal 3 and ground.</p> <div style="text-align: center;">  <p>Resistance: 20 - 30Ω</p> </div> <p style="text-align: right;">LAT195</p> <p style="text-align: center;">OK or NG</p>	<p>GI</p> <p>MA</p> <p>EM</p> <p>LC</p> <p>EC</p> <p>FE</p> <p>CL</p> <p>MT</p> <p style="background-color: black; color: white; text-align: center;">AT</p>
OK	▶	GO TO 2.	
NG	▶	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Overrun clutch solenoid valve Refer to "Component Inspection", AT-362. ● Harness of terminal cord assembly for short or open 	


2	CHECK POWER SOURCE CIRCUIT	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect PCM harness connector. 3. Check continuity between terminal 3 and PCM harness connector terminal 24.</p> <div style="text-align: center;">  <p>Continuity should exist.</p> </div> <p style="text-align: right;">LAT221</p> <p>If OK, check harness for short to ground and short to power.</p> <p>4. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>	<p>AX</p> <p>SU</p> <p>BR</p> <p>ST</p> <p>RS</p> <p>BT</p> <p>HA</p> <p>SC</p>
OK	▶	GO TO 3.	
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors.	

3	CHECK DTC	<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-359.</p> <p style="text-align: center;">OK or NG</p>	<p>EL</p> <p>IDX</p>
OK	▶	INSPECTION END	
NG	▶	<p>1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.</p>	

DTC P1760 OVERRUN CLUTCH SOLENOID VALVE

QG18DE (EXCEPT CALIF. CA)

Component Inspection



Component Inspection OVERRUN CLUTCH SOLENOID VALVE

NIAT0194

NIAT0194S01


- Refer to "REMOVAL", AT-433.

Resistance Check

NIAT0194S0101

- Check resistance between two terminals.

Solenoid valve	Terminal No.		Resistance (Approx.)
	3	Ground	
Overrun clutch solenoid valve	3	Ground	20 - 30Ω



Operation Check


NIAT0194S0102

- Check solenoid valve by listening for its operating sound while applying battery voltage to the terminal and ground.

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE)


QG18DE (EXCEPT CALIF. CA)

Description



Description

The A/T fluid temperature sensor detects the A/T fluid temperature and sends a signal to the PCM. NIAT0195



CONSULT-II REFERENCE VALUE IN DATA MONITOR MODE

Remarks: Specification data are reference values.

Monitor item	Condition	Specification
A/T fluid temperature sensor	Cold [20°C (68°F)]	Approximately 1.5V
	Hot [80°C (176°F)]	Approximately 0.5V




ON BOARD DIAGNOSIS LOGIC

Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
<input type="checkbox"/> : BATT/FLUID TEMP SEN <input checked="" type="checkbox"/> : 8th judgement flicker	PCM receives an excessively low or high voltage from the sensor.	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • A/T fluid temperature sensor

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE) QG18DE (EXCEPT CALIF. CA)

Description (Cont'd)



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0195S04

After the repair, perform the following procedure to confirm the malfunction is eliminated.

Ⓜ With CONSULT-II

- 1) Start engine.
- 2) Select "DATA MONITOR" mode for "A/T" with CONSULT-II.
- 3) Drive vehicle under the following conditions:
Selector lever in "D", vehicle speed higher than 20 km/h (12 MPH).

ⓧ Without CONSULT-II

- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in "D", vehicle speed higher than 20 km/h (12 MPH).
- 3) Perform self-diagnosis.
Refer to "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52.

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE) QG18DE (EXCEPT CALIF. CA)


Wiring Diagram — AT — BA/FTS

Wiring Diagram — AT — BA/FTS

NIAT0196

AT-BA/FTS-01

— : DETECTABLE LINE FOR DTC
 — : NON-DETECTABLE LINE FOR DTC




GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT

AX
 SU
 BR
 ST

RS
 BT

HA
 SC

EL
 IDX



REFER TO THE FOLLOWING.
 F22 - ELECTRICAL UNITS

WAT107

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
58	B	GROUND (A/T FLUID TEMPERATURE SENSOR)	—	—
67	W/L	POWER SOURCE (MEMORY BACK-UP)	WHEN TURNING IGNITION SWITCH TO "OFF"	BATTERY VOLTAGE
			WHEN TURNING IGNITION SWITCH TO "ON"	BATTERY VOLTAGE
91	BR	A/T FLUID TEMPERATURE SENSOR	WHEN ATF TEMPERATURE IS 20 °C (68° F)	APPROX. 1.5V
			WHEN ATF TEMPERATURE IS 80 °C (176° F)	APPROX. 0.5V
109	BR/R	POWER SOURCE	WHEN TURNING IGNITION SWITCH TO "ON"	BATTERY VOLTAGE
			WHEN TURNING IGNITION SWITCH TO "OFF"	1V OR LESS

LAT287

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE) QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0197

1	CHECK TCM POWER SOURCE	
<p>1. Turn ignition switch to "ON" position. (Do not start engine.)</p> <p>2. Check voltage between PCM terminals 67, 109 and ground.</p> <p>3. Turn ignition switch to "OFF" position.</p> <p>4. Check voltage between PCM terminal 67 and ground.</p>		
<p>Battery voltage should exist.</p>		
<p>LAT223</p>		
<p>OK or NG</p>		
OK	▶	GO TO 2.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between ignition switch and PCM (Main harness) ● Ignition switch and fuse <p>Refer to EL-9, "POWER SUPPLY ROUTING".</p>

2	CHECK A/T FLUID TEMPERATURE SENSOR WITH TERMINAL CORD ASSEMBLY	
<p>1. Turn ignition switch to "OFF" position.</p> <p>2. Disconnect terminal cord assembly connector in engine compartment.</p> <p>3. Check resistance between terminals 6 and 7 when A/T is cold.</p> <p style="color: blue;">Resistance:</p> <p style="color: blue;">Cold [20°C (68°F)]</p> <p style="color: blue;">Approximately 2.5 kΩ</p>		
<p>LAT200</p>		
<p>4. Reinstall any part removed.</p>		
<p>OK or NG</p>		
OK (With CONSULT-II)	▶	GO TO 3.
OK (Without CONSULT-II)	▶	GO TO 4.
NG	▶	<p>1. Remove oil pan.</p> <p>2. Check the following items:</p> <ul style="list-style-type: none"> ● A/T fluid temperature sensor <p style="padding-left: 20px;">Refer to "Component Inspection", AT-368.</p> <ul style="list-style-type: none"> ● Harness of terminal cord assembly for short or open

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE)

QG18DE (EXCEPT CALIF. CA)



Diagnostic Procedure (Cont'd)

3	CHECK INPUT SIGNAL OF A/T FLUID TEMPERATURE SENSOR (WITH CONSULT-II)															
<p>Ⓟ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 3. Read out the value of "FLUID TEMP SE". <p style="margin-left: 20px;">Voltage:</p> <p style="margin-left: 40px;">Cold [20°C (68°F)] → Hot [80°C (176°F)]:</p> <p style="margin-left: 40px;">Approximately 1.5V → 0.5V</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="text-align: center;">DATA MONITOR</th> </tr> <tr> <th style="text-align: center;">MONITORING</th> <th style="text-align: center;"></th> </tr> </thead> <tbody> <tr> <td style="text-align: center;">VHCL/S SE-A/T</td> <td style="text-align: center;">XXX km/h</td> </tr> <tr> <td style="text-align: center;">VHCL/S SE-MTR</td> <td style="text-align: center;">XXX km/h</td> </tr> <tr> <td style="text-align: center;">THRTL POS SEN</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td style="text-align: center;">FLUID TEMP SE</td> <td style="text-align: center;">XXX V</td> </tr> <tr> <td style="text-align: center;">BATTERY VOLT</td> <td style="text-align: center;">XXX V</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		VHCL/S SE-A/T	XXX km/h	VHCL/S SE-MTR	XXX km/h	THRTL POS SEN	XXX V	FLUID TEMP SE	XXX V	BATTERY VOLT	XXX V
DATA MONITOR																
MONITORING																
VHCL/S SE-A/T	XXX km/h															
VHCL/S SE-MTR	XXX km/h															
THRTL POS SEN	XXX V															
FLUID TEMP SE	XXX V															
BATTERY VOLT	XXX V															
SAT614J																
OK or NG																
OK	▶	GO TO 5.														
NG	▶	<p>Check the following item:</p> <ul style="list-style-type: none"> ● Harness for short or open between PCM and terminal cord assembly (Main harness) ● Ground circuit for PCM <p>Refer to EC-170, "TROUBLE DIAGNOSIS FOR POWER SUPPLY".</p>														


GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

DTC BATT/FLUID TEMP SEN (A/T FLUID TEMP SENSOR CIRCUIT AND TCM POWER SOURCE) QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)

4	CHECK INPUT SIGNAL OF A/T FLUID TEMPERATURE SENSOR (WITHOUT CONSULT-II)
<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Check voltage between PCM terminal 91 and ground while warming up A/T. 	
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p>Voltage: Cold [20°C (68°F)] → Hot [80°C (176°F)]: Approximately 1.5V → 0.5V</p> </div> </div>	
LAT209	
<ol style="list-style-type: none"> 3. Turn ignition switch to "OFF" position. 4. Disconnect PCM harness connector. 5. Check resistance between terminal 58 and ground. 	
<div style="display: flex; justify-content: space-between; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;"> <p>Continuity should exist.</p> </div> </div>	
LAT210	
OK or NG	
OK	▶ GO TO 5.
NG	<p>Check the following item:</p> <ul style="list-style-type: none"> ● Harness for short or open between PCM and terminal cord assembly (Main harness) ● Ground circuit for PCM <p>Refer to EC-170, "TROUBLE DIAGNOSIS FOR POWER SUPPLY".</p>

5	CHECK DTC
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-364.	
OK or NG	
OK	▶ INSPECTION END
NG	<ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.



Component Inspection

A/T FLUID TEMPERATURE SENSOR

NIAT0198

NIAT0198S01


- Refer to "REMOVAL", AT-433.
- Check resistance between two terminals while changing temperature as shown at left.

Temperature °C (°F)	Resistance
20 (68)	Approximately 2.5 kΩ
80 (176)	Approximately 0.3 kΩ

DTC VHCL SPEED SEN-MTR VEHICLE SPEED SENSOR-MTR

QG18DE (EXCEPT CALIF. CA)

Description



Description

NIAT0199

The vehicle speed sensor-MTR is built into the speedometer assembly. The sensor functions as an auxiliary device to the revolution sensor when it is malfunctioning. The PCM will then use a signal sent from the vehicle speed sensor-MTR.

GI
MA
EM
LC
EC
FE
CL
MT

ON BOARD DIAGNOSIS LOGIC

NIAT0199S02




Diagnostic trouble code	Malfunction is detected when ...	Check items (Possible cause)
<p> : VHCL SPEED SEN-MTR</p> <p> : 2nd judgement flicker</p>	<p>PCM does not receive the proper voltage signal from the sensor.</p>	<ul style="list-style-type: none"> • Harness or connectors (The sensor circuit is open or shorted.) • Vehicle speed sensor

AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DTC VHCL SPEED SEN-MTR VEHICLE SPEED SENSOR-MTR

QG18DE (EXCEPT CALIF. CA)

Description (Cont'd)



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0199S03

CAUTION:

- Always drive vehicle at a safe speed.
- If conducting this “DTC CONFIRMATION PROCEDURE” again, always turn ignition switch “OFF” and wait at least 5 seconds before continuing.

After the repair, perform the following procedure to confirm the malfunction is eliminated.

With CONSULT-II

- 1) Turn ignition switch “ON” and select “DATA MONITOR” mode for “A/T” with CONSULT-II.
- 2) Start engine and accelerate vehicle from 0 to 25 km/h (0 to 16 MPH).

Without CONSULT-II

- 1) Start engine.
- 2) Drive vehicle under the following conditions:
Selector lever in “D” and vehicle speed higher than 25 km/h (16 MPH).
- 3) Perform self-diagnosis.
Refer to “TCM/PCM Self-diagnostic Procedure (No Tools)”, AT-52.

DTC VHCL SPEED SEN-MTR VEHICLE SPEED SENSOR-MTR


QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — VSSMTR

Wiring Diagram — AT — VSSMTR

NIAT0200

AT-VSSMTR-01




— : DETECTABLE LINE FOR DTC
- - - : NON-DETECTABLE LINE FOR DTC

⬡E⬢ : WITHOUT TACHOMETER
⬡T⬢ : WITH TACHOMETER

- *1 ⬡E⬢ : 25
⬡T⬢ : 42
- *2 ⬡E⬢ : 26
⬡T⬢ : 41
- *3 ⬡E⬢ : 29
⬡T⬢ : 47
- *4 ⬡E⬢ : 2
⬡T⬢ : 13

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX



REFER TO THE FOLLOWING.
F22 - ELECTRICAL UNITS

WAT108

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
86	PU/R	VEHICLE SPEED SENSOR	WHEN MOVING VEHICLE AT 2 TO 3 KM/H (1 TO 2 MPH) FOR 1 m (3 ft) OR MORE	VOLTAGE VARIES FROM GREATER THAN 1V TO LESS THAN 4.5v

LAT288


DTC VHCL SPEED SEN-MTR VEHICLE SPEED SENSOR-MTR

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0201


1	CHECK INPUT SIGNAL	<p>With CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 3. Read out the value of "VHCL/S SE-MTR" while driving. Check the value changes according to driving speed. <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th></th> </tr> </thead> <tbody> <tr> <td>VHCL/S SE-A/T</td> <td>XXX km/h</td> </tr> <tr> <td>VHCL/S SE-MTR</td> <td>XXX km/h</td> </tr> <tr> <td>THRTL POS SEN</td> <td>XXX V</td> </tr> <tr> <td>FLUID TEMP SE</td> <td>XXX V</td> </tr> <tr> <td>BATTERY VOLT</td> <td>XXX V</td> </tr> </tbody> </table> </div> <p style="text-align: right; margin-top: 10px;">SAT614J</p>	DATA MONITOR		MONITORING		VHCL/S SE-A/T	XXX km/h	VHCL/S SE-MTR	XXX km/h	THRTL POS SEN	XXX V	FLUID TEMP SE	XXX V	BATTERY VOLT	XXX V
DATA MONITOR																
MONITORING																
VHCL/S SE-A/T	XXX km/h															
VHCL/S SE-MTR	XXX km/h															
THRTL POS SEN	XXX V															
FLUID TEMP SE	XXX V															
BATTERY VOLT	XXX V															
		<p>Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Start engine. 2. Check voltage between PCM terminal 86 and ground while driving at 2 to 3 km/h (1 to 2 MPH) for 1 m (3 ft) or more. <div style="text-align: center; margin: 10px 0;">  <p style="margin-top: 10px;">Voltage: Voltage varies between less than 1V and more than 4.5V</p> </div> <p style="text-align: right; margin-top: 10px;">LAT224</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>														
OK	▶	GO TO 2.														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Vehicle speed sensor and ground circuit for vehicle speed sensor Refer to EL-85, "METERS AND GAUGES". ● Harness for short or open between PCM and vehicle speed sensor (Main harness) 														

2	CHECK DTC	<p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-370.</p> <p style="text-align: center; margin-top: 10px;">OK or NG</p>
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.

DTC CONTROL UNIT (RAM), CONTROL UNIT (ROM)

QG18DE (EXCEPT CALIF. CA)

Description



LAT137

Description

The PCM consists of a microcomputer and connector for signal input and output and for power supply. The unit controls the A/T.

NIAT0202

GI

MA

EM

LC

ON BOARD DIAGNOSIS LOGIC

NIAT0202S01


Diagnostic Trouble Code No.	Malfunction is detected when	Check Item (Possible Cause)
Ⓜ : CONTROL UNIT (RAM), CONTROL UNIT (ROM)	PCM memory (RAM) or (ROM) is malfunctioning.	<ul style="list-style-type: none"> PCM

EC

FE

CL

MT



SAT014K

DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0202S02

AT

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.


AX

Ⓜ With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for A/T with CONSULT-II.
- 2) Start engine.
- 3) Run engine for at least 2 seconds at idle speed.

SU

BR



SAT971J

ST

RS

BT

HA

Diagnostic Procedure

NIAT0203

1	INSPECTION START (WITH CONSULT-II)
<p>Ⓜ With CONSULT-II</p> <p>1. Turn ignition switch "ON" and select "SELF DIAGNOSIS" mode for A/T with CONSULT-II.</p> <p>2. Touch "ERASE".</p>	
▶	GO TO 2.

EL

IDX

DTC CONTROL UNIT (RAM), CONTROL UNIT (ROM)

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure (Cont'd)


2	CHECK DTC
Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-373.	
	▶ GO TO 3.

3	CHECK DTC AGAIN
Is the "CONTROL UNIT (RAM) or CONTROL UNIT (ROM)" displayed again?	
Yes or No	
Yes	▶ Replace PCM.
No	▶ INSPECTION END

DTC CONTROL UNIT (EEP ROM)

QG18DE (EXCEPT CALIF. CA)

Description





Description

The PCM consists of a microcomputer and connector for signal ^{NIAT0204} input and output and for power supply. The unit controls the A/T.

ON BOARD DIAGNOSIS LOGIC

NIAT0204S01

Diagnostic trouble code	Malfunction is detected when ...	Check item (Possible cause)
Ⓜ : CONT UNIT (EEP ROM)	PCM memory (EEP ROM) is malfunctioning.	<ul style="list-style-type: none"> • PCM



DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE

NIAT0204S02

NOTE:

If "DIAGNOSTIC TROUBLE CODE CONFIRMATION PROCEDURE" has been previously conducted, always turn ignition switch "OFF" and wait at least 5 seconds before conducting the next test.

Ⓜ With CONSULT-II

- 1) Turn ignition switch "ON" and select "DATA MONITOR" mode for A/T with CONSULT-II.
- 2) Start engine.
- 3) Run engine for at least 2 seconds at idle speed.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


DTC CONTROL UNIT (EEP ROM)

QG18DE (EXCEPT CALIF. CA)

Diagnostic Procedure

Diagnostic Procedure

NIAT0205

1	CHECK DTC
<p> With CONSULT-II</p> <ol style="list-style-type: none">1. Turn ignition switch "ON" and select "SELF DIAGNOSIS" mode for A/T with CONSULT-II.2. Move selector lever to "R" position.3. Depress accelerator pedal (Full throttle position).4. Touch "ERASE".5. Turn ignition switch "OFF" position for 10 seconds. <p>Perform "DIAGNOSTIC TROUBLE CODE (DTC) CONFIRMATION PROCEDURE", AT-373.</p> <p style="text-align: center;">Is the "CONT UNIT (EEP ROM)" displayed again?</p>	
Yes	▶ Replace PCM.
No	▶ INSPECTION END

TROUBLE DIAGNOSES FOR SYMPTOMS




QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — NONDTC

Wiring Diagram — AT — NONDTC

NIAT0206

AT-NONDTC-01



REFER TO THE FOLLOWING.
F22 - ELECTRICAL UNITS

WAT109

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND

TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
42	G/OR	PNP SWITCH "N" OR "P" POSITION	WHEN SETTING SELECTOR LEVER TO "N" OR "P" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
60	G/W	PNP SWITCH "R" POSITION	WHEN SETTING SELECTOR LEVER TO "R" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
68	BR/Y	PNP SWITCH "1" POSITION	WHEN SETTING SELECTOR LEVER TO "1" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
69	B/W	PNP SWITCH "2" POSITION	WHEN SETTING SELECTOR LEVER TO "2" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS
78	W/G	PNP SWITCH "D" POSITION	WHEN SETTING SELECTOR LEVER TO "D" POSITION	BATTERY VOLTAGE
			WHEN SETTING SELECTOR LEVER TO OTHER POSITIONS	1V OR LESS


LAT289

TROUBLE DIAGNOSES FOR SYMPTOMS



QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — NONDTC (Cont'd)

AT-NONDTC-02



REFER TO THE FOLLOWING.
F22 - ELECTRICAL UNITS



WAT110

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND



TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
25	G/R	O/D OFF INDICATOR LAMP	WHEN SETTING OVERDRIVE CONTROL SWITCH "OFF"	1V OR LESS
			WHEN SETTING OVERDRIVE CONTROL SWITCH "ON"	BATTERY VOLTAGE
56	OR/B	OVERDRIVE CONTROL SWITCH	WHEN SETTING OVERDRIVE CONTROL SWITCH "ON"	BATTERY VOLTAGE
			WHEN SETTING OVERDRIVE CONTROL SWITCH "OFF"	1V OR LESS

LAT290

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

Wiring Diagram — AT — NONDTC (Cont'd)



REFER TO THE FOLLOWING.
 (F22) - ELECTRICAL UNITS

WAT111

POWERTRAIN CONTROL MODULE TERMINALS AND REFERENCE VALUE BETWEEN TERMINAL AND GROUND


TERMINAL	WIRE COLOR	ITEM	CONDITION	DATA (DC)
40	Y/PU	CLOSED THROTTLE POSITION SWITCH	WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	BATTERY VOLTAGE
			WHEN DEPRESSING ACCELERATOR PEDAL (ENGINE WARM)	1V OR LESS
47	R/G	STOP LAMP SWITCH	WHEN DEPRESSING BRAKE PEDAL	BATTERY VOLTAGE
			WHEN RELEASING BRAKE PEDAL	1V OR LESS
52	G/B	—	—	—
54	OR	ASCD CRUISE SWITCH	WHEN ASCD CRUISE IS BEING PERFORMED	BATTERY VOLTAGE
			WHEN ASCD CRUISE IS NOT BEING PERFORMED	1V OR LESS
55	W/PU	ASCD OD CUT SIGNAL	WHEN "ACCEL" SET SWITCH ON ASCD CRUISE IS IN "D ₄ "	5 - 10V
			WHEN "ACCEL" SET SWITCH ON ASCD CRUISE IS IN "D ₃ "	LESS THAN 2V
77	LG	WIDE OPEN THROTTLE POSITION SWITCH	WHEN DEPRESSING ACCELERATOR PEDAL GREATER THAN HALF-WAY (ENGINE WARM)	BATTERY VOLTAGE
			WHEN RELEASING ACCELERATOR PEDAL (ENGINE WARM)	1V OR LESS
113	GY/L	—	—	—

LAT291

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

1. O/D OFF Indicator Lamp Does Not Come On



1. O/D OFF Indicator Lamp Does Not Come On =NIAT0207

SYMPTOM:


O/D OFF indicator lamp does not come on for about 2 seconds when turning ignition switch to "ON".


1	CHECK PCM POWER SOURCE	
	<ol style="list-style-type: none"> 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Check voltage between PCM terminals 67, 109 and ground. 	
		<p>Battery voltage should exist.</p>
	<ol style="list-style-type: none"> 3. Turn ignition switch to "OFF" position. 4. Check voltage between PCM terminal 67 and ground. <p style="color: blue; margin-left: 20px;">Voltage: Battery voltage</p>	LAT223
	OK or NG	
OK	▶	GO TO 2.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Harness for short or open between ignition switch and PCM (Main harness) Refer to "Wiring Diagram — AT — MAIN", AT-272. ● Ignition switch and fuse Refer to EL-9, "POWER SUPPLY ROUTING".

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

1. O/D OFF Indicator Lamp Does Not Come On (Cont'd)

2	CHECK PCM GROUND CIRCUIT	<p>1. Turn ignition switch to "OFF" position. 2. Disconnect PCM harness connector. 3. Check continuity between PCM terminals 106, 108 and ground.</p> <div style="display: flex; justify-content: space-around; align-items: center;">  <div style="text-align: center;"> <p>Continuity should exist.</p> </div> </div> <p style="text-align: right;">LAT225</p> <p>If OK, check harness for short to ground and short to power.</p> <p style="text-align: center;">OK or NG</p>	GI MA EM LC EC FE
OK	▶	GO TO 3.	CL
NG	▶	Repair open circuit or short to ground or short to power in harness or connectors. Refer to "Wiring Diagram — AT — MAIN", AT-272.	MT

3	CHECK LAMP CIRCUIT	<p>1. Turn ignition switch to "OFF" position. 2. Check resistance between PCM terminals 25 and 109.</p> <div style="display: flex; justify-content: space-around; align-items: center;">  <div style="text-align: center;"> <p>Resistance: 50 - 100 Ω</p> </div> </div> <p style="text-align: right;">LAT226</p> <p>3. Reinstall any part removed.</p> <p style="text-align: center;">OK or NG</p>	AT AX SU BR ST RS
OK	▶	GO TO 4.	BT
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● O/D OFF indicator lamp. Refer to EL-85, "METERS AND GAUGES". ● Harness and fuse for short or open between ignition switch and O/D OFF indicator lamp (Main harness) Refer to EL-9, "POWER SUPPLY ROUTING". ● Harness for short or open between O/D OFF indicator lamp and PCM. 	HA SC EL IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

1. O/D OFF Indicator Lamp Does Not Come On (Cont'd)

4	CHECK SYMPTOM
Check again.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)




2. Engine Cannot Be Started In "P" and "N" Position


2. Engine Cannot Be Started In "P" and "N" Position

=NIAT0208

SYMPTOM:

- Engine cannot be started with selector lever in "P" or "N" position.
- Engine can be started with selector lever in "D", "2", "1" or "R" position.

1	CHECK PNP SWITCH CIRCUIT	
<p> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to PNP switch circuit?</p>		
<p> Without CONSULT-II Does self-diagnosis show damage to PNP switch circuit?</p>		
		
SAT367J		
Yes or No		
Yes	▶	Check PNP switch circuit. Refer to "DTC P0705", AT-275.
No	▶	GO TO 2.

2	CHECK PNP SWITCH INSPECTION	
<p>Check for short or open of PNP switch harness connector terminals 1 and 2. Refer to "Component Inspection", AT-279.</p>		
		
WAT203		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair or replace PNP switch.

3	CHECK STARTING SYSTEM	
<p>Check starting system. Refer to SC-6, "STARTING SYSTEM".</p>		
OK or NG		
OK	▶	INSPECTION END
NG	▶	Repair or replace damaged parts.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)


3. In "P" Position, Vehicle Moves Forward Or Backward When Pushed

3. In "P" Position, Vehicle Moves Forward Or Backward When Pushed

=NIAT0209

SYMPTOM:

Vehicle moves when it is pushed forward or backward with selector lever in "P" position.

1	CHECK PARKING COMPONENTS	
<p>Check parking components. Refer to "Parking Pawl Components", AT-439.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT282F</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	INSPECTION END
NG	▶	Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

4. In "N" Position, Vehicle Moves

4. In "N" Position, Vehicle Moves

=NIAT0210

SYMPTOM:

Vehicle moves forward or backward when selecting "N" position.


1	CHECK PNP SWITCH CIRCUIT		
		<p><input type="checkbox"/> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to PNP switch circuit?</p>	GI MA EM LC EC FE CL MT
		<p><input checked="" type="checkbox"/> Without CONSULT-II Does self-diagnosis show damage to PNP switch circuit?</p>	
			SAT367J
		Yes or No	
Yes	▶	Check PNP switch circuit. Refer to "DTC P0705", AT-275.	
No	▶	GO TO 2.	AT


2	CHECK CONTROL CABLE		
		Check control cable. Refer to AT-434.	AX SU BR ST RS BT HA SC EL IDX
			SAT023JB
		OK or NG	
OK	▶	GO TO 3.	
NG	▶	Adjust control cable. Refer to AT-434.	

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

4. In "N" Position, Vehicle Moves (Cont'd)

3	CHECK A/T FLUID LEVEL	Check A/T fluid level again.	
		SAT638A	
OK or NG			
OK	▶		GO TO 4.
NG	▶		Refill ATF.

4	CHECK A/T FLUID CONDITION	1. Remove oil pan. 2. Check A/T fluid condition.	
		SAT171B	
OK or NG			
OK	▶		GO TO 5.
NG	▶		1. Disassemble A/T. 2. Check the following items: <ul style="list-style-type: none"> ● Forward clutch assembly ● Overrun clutch assembly ● Reverse clutch assembly

5	CHECK SYMPTOM	Check again.	
OK or NG			
OK	▶		INSPECTION END
NG	▶		1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)


5. Large Shock. "N" → "R" Position


5. Large Shock. "N" → "R" Position

=NIAT02.11

SYMPTOM:

There is large shock when changing from "N" to "R" position.


1	CHECK SELF-DIAGNOSTIC RESULTS		
		Does self-diagnosis show damage to A/T fluid temperature sensor, line pressure solenoid valve or throttle position sensor circuit?	GI
			MA EM LC EC FE
		SAT345HA	CL
Yes or No			
Yes	▶	Check damaged circuit. Refer to "DTC P0710, P0745 or P1705", AT-280, 338 or 351.	MT
No	▶	GO TO 2.	AT

2	CHECK THROTTLE POSITION SENSOR		
		Check throttle position sensor. Refer to EC-201 , "DTC P0120 THROTTLE POSITION SENSOR".	AT
			AX SU BR ST
		LEC279	RS
OK or NG			
OK	▶	GO TO 3.	BT
NG	▶	Repair or replace throttle position sensor.	HA SC EL IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

5. Large Shock. "N" → "R" Position (Cont'd)

3	CHECK LINE PRESSURE		
<p>Check line pressure at idle with selector lever in "D" position. Refer to "Line Pressure Test", AT-72.</p>			
			
SAT494G			
OK or NG			
OK	▶	GO TO 4.	
NG	▶	<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) ● Line pressure solenoid valve 	

4	CHECK SYMPTOM		
<p>Check again.</p>			
OK or NG			
OK	▶	INSPECTION END	
NG	▶	<ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector. 	

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)


6. Vehicle Does Not Creep Backward In "R" Position


6. Vehicle Does Not Creep Backward In "R" Position

=NIAT0212

SYMPTOM:

Vehicle does not creep backward when selecting "R" position.

1	CHECK A/T FLUID LEVEL	
Check A/T fluid level again.		
		
SAT638A		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Refill ATF.


2	CHECK STALL TEST	
Check stall revolution with selector lever in "1" and "R" positions.		
		
SAT493G		
OK or NG		
OK	▶	GO TO 3.
OK in "1" position, NG in "R" position	▶	<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) ● Line pressure solenoid valve 3. Disassemble A/T. 4. Check the following items: <ul style="list-style-type: none"> ● Oil pump assembly ● Torque converter ● Reverse clutch assembly ● High clutch assembly
NG in both "1" and "R" positions	▶	GO TO 6.


GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
 AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

6. Vehicle Does Not Creep Backward In "R" Position (Cont'd)

3	CHECK LINE PRESSURE	<p>Check line pressure at idle with selector lever in "R" position. Refer to "Line Pressure Test", AT-72.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT494G</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	GO TO 4.	
NG	▶	<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) ● Line pressure solenoid valve 3. Disassemble A/T. 4. Check the following item: <ul style="list-style-type: none"> ● Oil pump assembly 	

4	CHECK A/T FLUID CONDITION	<ol style="list-style-type: none"> 1. Remove oil pan. 2. Check A/T fluid condition. <div style="text-align: center;">  </div> <p style="text-align: right;">SAT171B</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	GO TO 5.	
NG	▶	GO TO 6.	

5	CHECK SYMPTOM	<p>Check again.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	INSPECTION END	
NG	▶	<ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector. 	

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

6. Vehicle Does Not Creep Backward In "R" Position (Cont'd)

6	DETECT MALFUNCTIONING ITEM	
	<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433.</p> <p>2. Check the following items:</p> <ul style="list-style-type: none"> ● Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) ● Line pressure solenoid valve <p>3. Disassemble A/T.</p> <p>4. Check the following items:</p> <ul style="list-style-type: none"> ● Oil pump assembly ● Torque converter ● Reverse clutch assembly ● High clutch assembly ● Low & reverse brake assembly ● Low one-way clutch <p style="text-align: center;">OK or NG</p>	
	OK	▶ GO TO 5.
	NG	▶ Repair or replace damaged parts.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)


7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position


7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position

=NIAT0213

SYMPTOM:

Vehicle does not creep forward when selecting "D", "2" or "1" position.


1	CHECK A/T FLUID LEVEL		
Check A/T fluid level again.			
			
SAT638A			
OK or NG			
OK	▶	GO TO 2.	
NG	▶	Refill ATF.	

2	CHECK STALL TEST		
Check stall revolution with selector lever in "D" position. Refer to "Stall Test", AT-68.			
			
SAT493G			
OK or NG			
OK	▶	GO TO 3.	
NG	▶	GO TO 6.	


TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position (Cont'd)

3	CHECK LINE PRESSURE	<p>Check line pressure at idle with selector lever in "D" position. Refer to "Line Pressure Test ", AT-72.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT494G</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	GO TO 4.	
NG	▶	<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter) ● Line pressure solenoid valve 3. Disassemble A/T. 4. Check the following item: <ul style="list-style-type: none"> ● Oil pump assembly 	

GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT

4	CHECK A/T FLUID CONDITION	<ol style="list-style-type: none"> 1. Remove oil pan. 2. Check A/T fluid condition. <div style="text-align: center;">  </div> <p style="text-align: right;">SAT171B</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	GO TO 5.	
NG	▶	GO TO 6.	

AX
 SU
 BR
 ST
 RS
 BT
 HA

5	CHECK SYMPTOM	<p>Check again.</p> <p style="text-align: center;">OK or NG</p>	
OK	▶	INSPECTION END	
NG	▶	<ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector. 	

SC
 EL
 IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position (Cont'd)

6	DETECT MALFUNCTIONING ITEM
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433.</p> <p>2. Check the following items:</p> <ul style="list-style-type: none">● Valves to control line pressure (Pressure regulator valve, pressure modifier valve, pilot valve and pilot filter)● Line pressure solenoid valve <p>3. Disassemble A/T.</p> <p>4. Check the following items:</p> <ul style="list-style-type: none">● Oil pump assembly● Forward clutch assembly● Forward one-way clutch● Low one-way clutch● Low & reverse brake assembly● Torque converter <p style="text-align: center;">OK or NG</p>	
OK	▶ GO TO 5.
NG	▶ Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

8. Vehicle Cannot Be Started From D₁

8. Vehicle Cannot Be Started From D₁

=NIAT0214

SYMPTOM:

Vehicle cannot be started from D₁ on Cruise Test — Part 1.

1	CHECK SYMPTOM	
Is "6. Vehicle Does Not Creep Backward In R Position" OK?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	Go to "6. Vehicle Does Not Creep Backward In R Position", AT-389.

2	CHECK SELF-DIAGNOSTIC RESULTS	
Does self-diagnosis show damage to vehicle speed sensor-A/T (revolution sensor), shift solenoid valve A, B or vehicle speed sensor-MTR after cruise test?		
SAT934FB		
Yes or No		
Yes	▶	Check damaged circuit. Refer to "DTC P0720, P0750, P0755 or VHCL SPEED SEN-MTR", AT-286, 343, 347 or 369.
No	▶	GO TO 3.


3	CHECK THROTTLE POSITION SENSOR	
Check throttle position sensor. Refer to EC-201 , "DTC P0120 THROTTLE POSITION SENSOR".		
LEC279		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace throttle position sensor.


GI
 MA
 EM
 LC
 EC
 FE
 CL
 MT
AT
 AX
 SU
 BR
 ST
 RS
 BT
 HA
 SC
 EL
 IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

8. Vehicle Cannot Be Started From D₁ (Cont'd)

4	CHECK LINE PRESSURE	
<p>Check line pressure at stall point with selector lever in "D" position. Refer to "Line Pressure Test", AT-72.</p>		
		
SAT494G		
OK or NG		
OK	▶	GO TO 5.
NG	▶	GO TO 8.

5	CHECK A/T FLUID CONDITION	
<p>1. Remove oil pan. 2. Check A/T fluid condition.</p>		
		
SAT171B		
OK or NG		
OK	▶	GO TO 6.
NG	▶	GO TO 8.

6	DETECT MALFUNCTIONING ITEM	
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Shift valve A ● Shift valve B ● Shift solenoid valve A ● Shift solenoid valve B ● Pilot valve ● Pilot filter 		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

8. Vehicle Cannot Be Started From D₁ (Cont'd)

7	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.

GI

MA

EM

8	DETECT MALFUNCTIONING ITEM	
1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Shift valve A ● Shift valve B ● Shift solenoid valve A ● Shift solenoid valve B ● Pilot valve ● Pilot filter 3. Disassemble A/T. 4. Check the following items: <ul style="list-style-type: none"> ● Forward clutch assembly ● Forward one-way clutch ● Low one-way clutch ● High clutch assembly ● Torque converter ● Oil pump assembly 		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Repair or replace damaged parts.

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$

9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$


=NIAT0215

SYMPTOM:

A/T does not shift from D_1 to D_2 at the specified speed.

A/T does not shift from D_4 to D_2 when depressing accelerator pedal fully at the specified speed.

1	CHECK SYMPTOM	
Are "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position" and "8. Vehicle Cannot Be Started From D_1 " OK?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	Go to "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position" and "8. Vehicle Cannot Be Started From D_1 ", AT-392, 395.


2	CHECK PNP SWITCH CIRCUIT	
<input checked="" type="checkbox"/> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to PNP switch circuit?		
<input type="checkbox"/> Without CONSULT-II Does self-diagnosis show damage to PNP switch circuit?		
		
SAT367J		
Yes or No		
Yes	▶	Check PNP switch circuit. Refer to "DTC P0705", AT-275.
No	▶	GO TO 3.


3	CHECK VEHICLE SPEED SENSOR-A/T AND CHECK VEHICLE SPEED SENSOR-MTR CIRCUIT	
Check vehicle speed sensor-A/T (revolution sensor) and vehicle speed sensor-MTR circuit. Refer to "DTC P0720 and VHCL SPEED SEN-MTR", AT-286, AT-369.		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace vehicle speed sensor-A/T (revolution sensor) and vehicle speed sensor-MTR circuits.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$ (Cont'd)

4	CHECK THROTTLE POSITION SENSOR	
<p>Check throttle position sensor. Refer to EC-201, "DTC P0120 THROTTLE POSITION SENSOR".</p> <div style="text-align: center;">  <p>Throttle body</p> <p>Throttle position sensor harness connector</p> <p>Throttle position switch harness connector</p> </div> <p style="text-align: right;">LEC279</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 5.
NG	▶	Repair or replace throttle position sensor.

5	CHECK A/T FLUID CONDITION	
<p>1. Remove oil pan. 2. Check A/T fluid condition.</p> <div style="text-align: center;">  <p style="text-align: right;">SAT171B</p> <p style="text-align: center;">OK or NG</p> </div>		
OK	▶	GO TO 6.
NG	▶	GO TO 8.

6	DETECT MALFUNCTIONING ITEM	
<p>1. Remove control valve. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Shift valve A ● Shift solenoid valve A ● Pilot valve ● Pilot filter <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 7.
NG	▶	Repair or replace damaged parts.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

9. A/T Does Not Shift: $D_1 \rightarrow D_2$ Or Does Not Kickdown: $D_4 \rightarrow D_2$ (Cont'd)

7	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.

8	DETECT MALFUNCTIONING ITEM	
<ol style="list-style-type: none"> 1. Remove control valve. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Shift valve A ● Shift solenoid valve A ● Pilot valve ● Pilot filter 3. Disassemble A/T. 4. Check the following items: <ul style="list-style-type: none"> ● Servo piston assembly ● Brake band ● Oil pump assembly 		
OK or NG		
OK	▶	GO TO 7.
NG	▶	Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

10. A/T Does Not Shift: D₂ → D₃

10. A/T Does Not Shift: D₂ → D₃

=NIAT0216

SYMPTOM:

A/T does not shift from D₂ to D₃ at the specified speed.

1	CHECK SYMPTOM	
Are "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position" and "8. Vehicle Cannot Be Started From D ₁ " OK?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	Go to "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position" and "8. Vehicle Cannot Be Started From D ₁ ", AT-392, 395.

2	CHECK PNP SWITCH CIRCUIT	
<input checked="" type="checkbox"/> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to PNP switch circuit?		
<input type="checkbox"/> Without CONSULT-II Does self-diagnosis show damage to PNP switch circuit?		
SAT367J		
Yes or No		
Yes	▶	Check PNP switch circuit. Refer to "DTC P0705", AT-275.
No	▶	GO TO 3.


3	CHECK THROTTLE POSITION SENSOR	
Check throttle position sensor. Refer to EC-201 , "DTC P0120 THROTTLE POSITION SENSOR".		
LEC279		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace throttle position sensor.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

10. A/T Does Not Shift: $D_2 \rightarrow D_3$ (Cont'd)

4	CHECK A/T FLUID CONDITION	
<p>1. Remove oil pan. 2. Check A/T fluid condition.</p>		
		
SAT171B		
OK or NG		
OK	▶	GO TO 5.
NG	▶	GO TO 7.

5	DETECT MALFUNCTIONING ITEM	
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Shift valve B ● Shift solenoid valve B ● Pilot valve ● Pilot filter 		
OK or NG		
OK	▶	GO TO 6.
NG	▶	Repair or replace damaged parts.

6	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.</p>

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

10. A/T Does Not Shift: D₂ → D₃ (Cont'd)

7	DETECT MALFUNCTIONING ITEM	
	1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Shift valve B ● Shift solenoid valve B ● Pilot valve ● Pilot filter 3. Disassemble A/T. 4. Check the following items: <ul style="list-style-type: none"> ● Servo piston assembly ● High clutch assembly ● Oil pump assembly 	GI MA EM LC EC FE CL MT
	OK or NG	
OK	▶	GO TO 6.
NG	▶	Repair or replace damaged parts.

- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT
- AT**
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL
- IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

11. A/T Does Not Shift: D₃ → D₄

11. A/T Does Not Shift: D₃ → D₄

=NIAT0217

SYMPTOM:

- A/T does not shift from D₃ to D₄ at the specified speed.
- A/T must be warm before D₃ to D₄ shift will occur.


1	CHECK SYMPTOM	
Are "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position" and "8. Vehicle Cannot Be Started From D ₁ " OK?		
Yes or No		
Yes	▶	GO TO 2.
No	▶	Go to "7. Vehicle Does Not Creep Forward In "D", "2" Or "1" Position" and "8. Vehicle Cannot Be Started From D ₁ ", AT-392, 395.


2	CHECK SELF-DIAGNOSTIC RESULTS	
<p>Ⓜ With CONSULT-II Does self-diagnosis, after cruise test, show damage to any of the following circuits?</p> <ul style="list-style-type: none"> ● PNP switch ● Overdrive control switch ● A/T fluid temperature sensor ● Vehicle speed sensor-A/T (revolution sensor) ● Shift solenoid valve A or B ● Vehicle speed sensor-MTR 		
SAT363HC		
Yes or No		
Yes	▶	Check damaged circuit. Refer to "DTC P0705, P0710, P0720, P0750, P0755 or VHCL SPEED SEN-MTR", AT-275, 280, 286, 343, 347 or 369.
No	▶	GO TO 3.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

11. A/T Does Not Shift: D₃ → D₄ (Cont'd)

3	CHECK THROTTLE POSITION SENSOR	
<p>Check throttle position sensor. Refer to EC-201, "DTC P0120 THROTTLE POSITION SENSOR".</p> <div style="text-align: center;">  <p>Throttle body</p> <p>Throttle position sensor harness connector</p> <p>Throttle position switch harness connector</p> </div> <p style="text-align: right;">LEC279</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 4.
NG	▶	Repair or replace throttle position sensor.

4	CHECK A/T FLUID CONDITION	
<p>1. Remove oil pan. 2. Check A/T fluid condition.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT171B</p> <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 5.
NG	▶	GO TO 7.

5	DETECT MALFUNCTIONING ITEM	
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Shift valve B ● Overrun clutch control valve ● Shift solenoid valve B ● Pilot valve ● Pilot filter <p style="text-align: center;">OK or NG</p>		
OK	▶	GO TO 6.
NG	▶	Repair or replace damaged parts.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

11. A/T Does Not Shift: $D_3 \rightarrow D_4$ (Cont'd)

6	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.

7	DETECT MALFUNCTIONING ITEM	
<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Shift valve B ● Overrun clutch control valve ● Shift solenoid valve B ● Pilot valve ● Pilot filter 3. Disassemble A/T. 4. Check the following items: <ul style="list-style-type: none"> ● Servo piston assembly ● Brake band ● Torque converter ● Oil pump assembly 		
OK or NG		
OK	▶	GO TO 6.
NG	▶	Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

12. A/T Does Not Perform Lock-up


12. A/T Does Not Perform Lock-up


=NIAT0218

SYMPTOM:

A/T does not perform lock-up at the specified speed.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

1	CHECK SELF-DIAGNOSTIC RESULTS	
Does self-diagnosis show damage to torque converter clutch solenoid valve circuit after cruise test?		
		
SAT346H		
Yes or No		
Yes	▶	Check torque converter clutch solenoid valve circuit. Refer to "DTC P0740", AT-323.
No	▶	GO TO 2.

2	CHECK THROTTLE POSITION SENSOR	
Check throttle position sensor. Refer to EC-201 , "DTC P0120 THROTTLE POSITION SENSOR".		
		
LEC279		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair or replace throttle position sensor.

3	DETECT MALFUNCTIONING ITEM	
1. Remove control valve. Refer to "REMOVAL", AT-433. 2. Check following items: <ul style="list-style-type: none"> ● Torque converter clutch control valve ● Torque converter relief valve ● Torque converter clutch solenoid valve ● Pilot valve ● Pilot filter 		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

12. A/T Does Not Perform Lock-up (Cont'd)

4	CHECK SYMPTOM
Check again.	
OK or NG	
OK	▶ INSPECTION END
NG	▶ 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

13. A/T Does Not Hold Lock-up Condition

13. A/T Does Not Hold Lock-up Condition

=NIAT0219

SYMPTOM:

A/T does not hold lock-up condition for more than 30 seconds.

1	CHECK DIAGNOSTIC RESULTS	
Does self-diagnosis show damage to engine speed signal circuit after cruise test?		
SAT347H		
Yes or No		
Yes	▶	Check engine speed signal circuit. Refer to "DTC P0725", AT-291.
No	▶	GO TO 2.

2	CHECK A/T FLUID CONDITION	
<ol style="list-style-type: none"> 1. Remove oil pan. 2. Check A/T fluid condition. 		
SAT171B		
OK or NG		
OK	▶	GO TO 3.
NG	▶	GO TO 5.

3	DETECT MALFUNCTIONING ITEM	
<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Torque converter clutch control valve ● Pilot valve ● Pilot filter 		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace damaged parts.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

13. A/T Does Not Hold Lock-up Condition (Cont'd)

4	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.

5	DETECT MALFUNCTIONING ITEM	
<ol style="list-style-type: none"> 1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items: <ul style="list-style-type: none"> ● Torque converter clutch control valve ● Pilot valve ● Pilot filter 3. Disassemble A/T. 4. Check torque converter and oil pump assembly. 		
OK or NG		
OK	▶	GO TO 4.
NG	▶	Repair or replace damaged parts.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

14. Lock-up Is Not Released

14. Lock-up Is Not Released

=NIAT0220

SYMPTOM:

Lock-up is not released when accelerator pedal is released.

1	CHECK THROTTLE POSITION SWITCH CIRCUIT		
		<p><input type="checkbox"/> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to closed throttle position switch circuit?</p> <p><input checked="" type="checkbox"/> Without CONSULT-II Does self-diagnosis show damage to closed throttle position switch circuit?</p> <div style="text-align: center;"> </div> <p style="text-align: right;">SAT367J</p>	GI MA EM LC EC FE CL MT
		Yes or No	
Yes	▶	Check closed throttle position switch circuit. Refer to "DTC P0705", AT-275.	
No	▶	GO TO 2.	AT

2	CHECK SYMPTOM		
		Check again.	
		OK or NG	
OK	▶	INSPECTION END	AX SU
NG	▶	<ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector. 	BR ST RS BT HA SC EL IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)


15. Engine Speed Does Not Return To Idle (Light Braking $D_4 \rightarrow D_3$)


15. Engine Speed Does Not Return To Idle (Light Braking $D_4 \rightarrow D_3$)

=NIAT0221

SYMPTOM:

- Engine speed does not smoothly return to idle when A/T shifts from D_4 to D_3 .
- Vehicle does not decelerate by engine brake when turning overdrive control switch OFF.
- Vehicle does not decelerate by engine brake when shifting A/T from "D" to "2" position.


1	CHECK SELF-DIAGNOSTIC RESULTS	
Does self-diagnosis show damage to overrun clutch solenoid valve circuit after cruise test?		
		
SAT348H		
Yes or NO		
Yes	▶	Check overrun clutch solenoid valve circuit. Refer to "DTC P1760", AT-359.
No	▶	GO TO 2.

2	CHECK THROTTLE POSITION SENSOR	
Check throttle position sensor. Refer to EC-201 , "DTC P0120 THROTTLE POSITION SENSOR".		
		
LEC279		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Repair or replace throttle position sensor.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

15. Engine Speed Does Not Return To Idle (Light Braking D₄ → D₃) (Cont'd)

3	CHECK A/T FLUID CONDITION	
<p>1. Remove oil pan. 2. Check A/T fluid condition.</p> <div style="text-align: center;">  </div> <p style="text-align: right;">SAT171B</p>		
OK or NG		
OK	▶	GO TO 4.
NG	▶	GO TO 6.

4	DETECT MALFUNCTIONING ITEM	
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Overrun clutch control valve ● Overrun clutch reducing valve ● Overrun clutch solenoid valve 		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Repair or replace damaged parts.

5	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.</p>

6	DETECT MALFUNCTIONING ITEM	
<p>1. Remove control valve assembly. Refer to "REMOVAL", AT-433. 2. Check the following items:</p> <ul style="list-style-type: none"> ● Overrun clutch control valve ● Overrun clutch reducing valve ● Overrun clutch solenoid valve <p>3. Disassemble A/T. 4. Check the following items:</p> <ul style="list-style-type: none"> ● Overrun clutch assembly ● Oil pump assembly 		
OK or NG		
OK	▶	GO TO 5.
NG	▶	Repair or replace damaged parts.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

16. Vehicle Does Not Start From D₁

16. Vehicle Does Not Start From D₁

NIAT0222

SYMPTOM:

Vehicle does not start from D₁ on Cruise Test — Part 2.

1	CHECK SELF-DIAGNOSTIC RESULTS	
Does self-diagnosis show damage to vehicle speed sensor-A/T (revolution sensor), shift solenoid valve A, B or vehicle speed sensor-MTR after cruise test?		
SAT934FA		
Yes or No		
Yes	▶	Check damaged circuit. Refer to "DTC P0720, P0750, P0755 or VHCL SPEED SEN-MTR", AT-286, 343, 347 or 369.
No	▶	GO TO 2.

2	CHECK SYMPTOM	
Check again.		
OK or NG		
OK	▶	Go to 8. Vehicle Cannot Be Started From D ₁ , AT-395.
NG	▶	1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)


17. A/T Does Not Shift: D₄ → D₃, When Overdrive Control Switch "ON" → "OFF"

17. A/T Does Not Shift: D₄ → D₃, When Overdrive Control Switch "ON" → "OFF"

=NIAT0223

SYMPTOM:

A/T does not shift from D₄ to D₃ when changing overdrive control switch to "OFF" position.

1	CHECK OVERDRIVE CONTROL SWITCH CIRCUIT	
<p><input type="checkbox"/> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to overdrive control switch circuit?</p>		
<p><input checked="" type="checkbox"/> Without CONSULT-II Does self-diagnosis show damage to overdrive control switch circuit?</p>		
		
<small>SAT344H</small>		
Yes or No		
Yes	▶	Check overdrive control switch circuit. Refer to "DIAGNOSTIC PROCEDURE", AT-419.
No	▶	Go to "10. A/T Does Not Shift: D ₂ → D ₃ ", AT-401.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

18. A/T Does Not Shift: $D_3 \rightarrow 2_2$, When Selector Lever "D" \rightarrow "2" Position

18. A/T Does Not Shift: $D_3 \rightarrow 2_2$, When Selector Lever "D" \rightarrow "2" Position

=NIAT0224

SYMPTOM:

A/T does not shift from D_3 to 2_2 when changing selector lever from "D" to "2" position.

1	CHECK PNP SWITCH CIRCUIT
<p><input type="checkbox"/> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to PNP switch circuit?</p>	
<p><input checked="" type="checkbox"/> Without CONSULT-II Does self-diagnosis show damage to PNP switch circuit?</p> <div style="text-align: center; margin: 20px 0;"> <pre> graph TD Start[Self diagnosis Start] --- Light[Light] Start -.- Shade[Shade] Light --- LightLabel[Light] Shade --- ShadeLabel[Shade] LightLabel --- LightBox[O/D OFF] ShadeLabel --- LightBox </pre> </div> <p style="text-align: right;">SAT367J</p>	
Yes or No	
Yes	▶ Check PNP switch circuit. Refer to "DTC P0705", AT-275.
No	▶ Go to "9. A/T Does Not Shift: $D_1 \rightarrow D_2$ or Does Not Kickdown: $D_4 \rightarrow D_2$ ", AT-398.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)




19. A/T Does Not Shift: 2₂ → 1₁, When Selector Lever "2" → "1" Position


19. A/T Does Not Shift: 2₂ → 1₁, When Selector Lever "2" → "1" Position

=NIAT0225

SYMPTOM:

A/T does not shift from 2₂ to 1₁ when changing selector lever from "2" to "1" position.

1	CHECK PNP SWITCH CIRCUIT
<p> With CONSULT-II Does "ECU INPUT SIGNALS" in "DATA MONITOR" show damage to PNP switch circuit?</p> <p> Without CONSULT-II Does self-diagnosis show damage to PNP switch circuit?</p>	
	
SAT367J	
Yes or No	
Yes	▶ Check PNP switch circuit. Refer to "DTC P0705", AT-275.
No	▶ GO TO 2.

2	CHECK SYMPTOM
Check again.	
	
OK or NG	
SAT778B	
OK	▶ INSPECTION END
NG	▶ <ol style="list-style-type: none"> 1. Perform PCM input/output signal inspection. 2. If NG, recheck PCM pin terminals for damage or loose connection with harness connector.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

20. Vehicle Does Not Decelerate By Engine Brake




20. Vehicle Does Not Decelerate By Engine Brake

=NIAT0226

SYMPTOM:

Vehicle does not decelerate by engine brake when shifting from 2₂ (1₂) to 1₁.

1	CHECK SYMPTOM	
Is "6. Vehicle Does Not Creep Backward In "R" Position" OK?		
Yes or No		
Yes	▶	Go to "15. Engine Speed Does Not Return To Idle (Light Braking D ₄ → D ₃)", AT-412.
No	▶	Go to "6. Vehicle Does Not Creep Backward In "R" Position", AT-389.



21. PCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks)

NIAT0227

SYMPTOM:

O/D OFF indicator lamp does not come on in PCM self-diagnostic procedure even if the lamp circuit is good.

DESCRIPTION

NIAT0227S01

- PNP switch
The PNP switch assembly includes a transmission range switch. The transmission range switch detects the selector lever position and sends a signal to the PCM.
- Overdrive control switch
Detects the overdrive control switch position (ON or OFF) and sends a signal to the PCM.
- Throttle position switch
Consists of a wide open throttle position switch and a closed throttle position switch.
The wide open throttle position switch sends a signal to the PCM when the throttle valve is open at least 1/2 of the full throttle position. The closed throttle position switch sends a signal to the PCM when the throttle valve is fully closed.

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

21. PCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

DIAGNOSTIC PROCEDURE

NIAT0227S02

1	CHECK PNP SWITCH CIRCUIT (With CONSULT-II)	<p>With CONSULT-II</p> <ol style="list-style-type: none"> Turn ignition switch to "ON" position. (Do not start engine.) Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. Read out "PN", "R", "D", "2" and "1" position switches moving selector lever to each position. Check that the signal of the selector lever position is indicated properly. <div style="text-align: center; margin: 10px 0;"> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th></th> </tr> </thead> <tbody> <tr> <td>PN POSI SW</td> <td>OFF</td> </tr> <tr> <td>R POSITION SW</td> <td>OFF</td> </tr> <tr> <td>D POSITION SW</td> <td>OFF</td> </tr> <tr> <td>2 POSITION SW</td> <td>ON</td> </tr> <tr> <td>1 POSITION SW</td> <td>OFF</td> </tr> </tbody> </table> </div> <p style="text-align: right;">SAT701J</p> <p style="text-align: center;">OK or NG</p>	DATA MONITOR		MONITORING		PN POSI SW	OFF	R POSITION SW	OFF	D POSITION SW	OFF	2 POSITION SW	ON	1 POSITION SW	OFF
DATA MONITOR																
MONITORING																
PN POSI SW	OFF															
R POSITION SW	OFF															
D POSITION SW	OFF															
2 POSITION SW	ON															
1 POSITION SW	OFF															
OK	▶	GO TO 3.														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> PNP switch (Refer to "Component Inspection", AT-422.) Harness for short or open between ignition switch and PNP switch (Main harness) Harness for short or open between PNP switch and PCM (Main harness) Diode (P, N positions) 														

GI
MA
EM
LC
EC
FE
CL
MT
AT

2	CHECK PNP SWITCH CIRCUIT (Without CONSULT-II)	<p>Without CONSULT-II</p> <ol style="list-style-type: none"> Turn ignition switch to "ON" position. (Do not start engine.) Check voltage between PCM terminals 42, 60, 68, 69, 78 and ground while moving selector lever through each position. <p>Voltage: B: Battery voltage 0: 0V</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;"> </div> <div style="text-align: center;"> </div> <div style="text-align: center;"> <table border="1" style="border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Lever position</th> <th colspan="5">Terminal No.</th> </tr> <tr> <th>42</th> <th>60</th> <th>78</th> <th>69</th> <th>68</th> </tr> </thead> <tbody> <tr> <td>P, N</td> <td>B</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>R</td> <td>0</td> <td>B</td> <td>0</td> <td>0</td> <td>0</td> </tr> <tr> <td>D</td> <td>0</td> <td>0</td> <td>B</td> <td>0</td> <td>0</td> </tr> <tr> <td>2</td> <td>0</td> <td>0</td> <td>0</td> <td>B</td> <td>0</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>0</td> <td>0</td> <td>B</td> </tr> </tbody> </table> <p>B: Battery voltage 0: 0V</p> </div> </div> <p style="text-align: center;">OK or NG</p> <p style="text-align: right;">WAT207</p>	Lever position	Terminal No.					42	60	78	69	68	P, N	B	0	0	0	0	R	0	B	0	0	0	D	0	0	B	0	0	2	0	0	0	B	0	1	0	0	0	0	B
Lever position	Terminal No.																																										
	42	60	78	69	68																																						
P, N	B	0	0	0	0																																						
R	0	B	0	0	0																																						
D	0	0	B	0	0																																						
2	0	0	0	B	0																																						
1	0	0	0	0	B																																						
OK	▶	GO TO 4.																																									
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> PNP switch (Refer to "Component Inspection", AT-422.) Harness for short or open between ignition switch and PNP switch (Main harness) Harness for short or open between PNP switch and PCM (Main harness) Diode (P, N positions) 																																									

AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

21. PCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

3	CHECK OVERDRIVE CONTROL SWITCH CIRCUIT (With CONSULT-II)															
<p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 3. Read out "OVERDRIVE SW". <p>Check the signal of the overdrive control switch is indicated properly. (Overdrive control switch "ON" displayed on CONSULT-II means overdrive "OFF".)</p>																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2">DATA MONITOR</th> </tr> <tr> <th>MONITORING</th> <th></th> </tr> </thead> <tbody> <tr> <td>ENGINE SPEED</td> <td>XXX rpm</td> </tr> <tr> <td>TURBINE REV</td> <td>XXX rpm</td> </tr> <tr> <td>OVERDRIVE SW</td> <td>ON</td> </tr> <tr> <td>PN POSI SW</td> <td>OFF</td> </tr> <tr> <td>R POSITION SW</td> <td>OFF</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		ENGINE SPEED	XXX rpm	TURBINE REV	XXX rpm	OVERDRIVE SW	ON	PN POSI SW	OFF	R POSITION SW	OFF
DATA MONITOR																
MONITORING																
ENGINE SPEED	XXX rpm															
TURBINE REV	XXX rpm															
OVERDRIVE SW	ON															
PN POSI SW	OFF															
R POSITION SW	OFF															
SAT645J																
OK or NG																
OK	▶	GO TO 5.														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Overdrive control switch (Refer to "Component Inspection", AT-422.) ● Harness for short or open between PCM and overdrive control switch (Main harness) ● Harness of ground circuit for overdrive control switch (Main harness) for short or open 														

4	CHECK OVERDRIVE CONTROL SWITCH CIRCUIT (Without CONSULT-II)	
<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Turn ignition switch to "ON" position. (Do not start engine.) 2. Check voltage between PCM terminal 56 and ground when overdrive control switch is "ON" and "OFF". 		
<div style="position: absolute; top: 50%; left: 60%; transform: translate(-50%, -50%); text-align: left;"> <p>Voltage: Switch position "ON": Battery voltage Switch position "OFF": 1V or less</p> </div>		
LAT227		
OK or NG		
OK	▶	GO TO 6.
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Overdrive control switch (Refer to "Component Inspection", AT-422.) ● Harness for short or open between PCM and overdrive control switch (Main harness) ● Harness of ground circuit for overdrive control switch (Main harness) for short or open

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

21. PCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

5	CHECK THROTTLE POSITION SWITCH CIRCUIT (With CONSULT-II)															
<p>Ⓜ With CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener, then check the following. Refer to step 1 through 5 of "Preparation", "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Select "ECU INPUT SIGNALS" in "DATA MONITOR" mode for "A/T" with CONSULT-II. 4. Read out "CLOSED THL/SW" and "W/O THRL/P-SW" depressing and releasing accelerator pedal. Check the signal of throttle position switch is indicated properly. 																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th rowspan="2" style="padding: 2px;">Accelerator pedal condition</th> <th colspan="2" style="padding: 2px;">Data monitor</th> </tr> <tr> <th style="padding: 2px;">CLOSED THL/SW</th> <th style="padding: 2px;">W/O THRL/P-SW</th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">Released</td> <td style="padding: 2px; text-align: center;">ON</td> <td style="padding: 2px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 2px;">Fully depressed</td> <td style="padding: 2px; text-align: center;">OFF</td> <td style="padding: 2px; text-align: center;">ON</td> </tr> </tbody> </table>			Accelerator pedal condition	Data monitor		CLOSED THL/SW	W/O THRL/P-SW	Released	ON	OFF	Fully depressed	OFF	ON			
Accelerator pedal condition	Data monitor															
	CLOSED THL/SW	W/O THRL/P-SW														
Released	ON	OFF														
Fully depressed	OFF	ON														
MTBL0011																
<table border="1" style="margin: auto; border-collapse: collapse;"> <thead> <tr> <th colspan="2" style="padding: 2px;">DATA MONITOR</th> </tr> <tr> <th colspan="2" style="padding: 2px;">MONITORING</th> </tr> </thead> <tbody> <tr> <td style="padding: 2px;">POWERSHIFT SW</td> <td style="padding: 2px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 2px;">CLOSED THL/SW</td> <td style="padding: 2px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 2px;">W/O THRL/P-SW</td> <td style="padding: 2px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 2px;">HOLD SW</td> <td style="padding: 2px; text-align: center;">OFF</td> </tr> <tr> <td style="padding: 2px;">BRAKE SW</td> <td style="padding: 2px; text-align: center;">ON</td> </tr> </tbody> </table>			DATA MONITOR		MONITORING		POWERSHIFT SW	OFF	CLOSED THL/SW	OFF	W/O THRL/P-SW	OFF	HOLD SW	OFF	BRAKE SW	ON
DATA MONITOR																
MONITORING																
POWERSHIFT SW	OFF															
CLOSED THL/SW	OFF															
W/O THRL/P-SW	OFF															
HOLD SW	OFF															
BRAKE SW	ON															
SAT702J																
OK or NG																
OK	▶	GO TO 7.														
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Throttle position switch — Refer to "Component Inspection", AT-422. ● Harness for short or open between ignition switch and throttle position switch (Main harness) ● Harness for short or open between throttle position switch and PCM (Main harness) 														

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

21. PCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)

6	CHECK THROTTLE POSITION SWITCH CIRCUIT (Without CONSULT-II)												
<p>⊗ Without CONSULT-II</p> <ol style="list-style-type: none"> 1. Apply vacuum to the throttle opener, then check the following. Refer to step 1 through 5 of "Preparation", "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52. 2. Turn ignition switch to "ON" position. (Do not start engine.) 3. Check voltage between PCM terminals 40, 77 and ground while depressing, and releasing accelerator pedal slowly. (After warming up engine) 													
<table border="1" style="border-collapse: collapse;"> <thead> <tr> <th rowspan="2">Accelerator pedal condition</th> <th colspan="2">Voltage</th> </tr> <tr> <th>Terminal No. 40</th> <th>Terminal No. 77</th> </tr> </thead> <tbody> <tr> <td>Released</td> <td>Battery voltage</td> <td>1V or less</td> </tr> <tr> <td>Fully depressed</td> <td>1V or less</td> <td>Battery voltage</td> </tr> </tbody> </table>			Accelerator pedal condition	Voltage		Terminal No. 40	Terminal No. 77	Released	Battery voltage	1V or less	Fully depressed	1V or less	Battery voltage
Accelerator pedal condition	Voltage												
	Terminal No. 40	Terminal No. 77											
Released	Battery voltage	1V or less											
Fully depressed	1V or less	Battery voltage											
LAT220													
OK or NG													
OK	▶	GO TO 7.											
NG	▶	<p>Check the following items:</p> <ul style="list-style-type: none"> ● Throttle position switch — Refer to "Component Inspection", AT-422. ● Harness for short or open between ignition switch and throttle position switch (Main harness) ● Harness for short or open between throttle position switch and PCM (Main harness) 											

7	CHECK DTC	
Perform "DIAGNOSTIC PROCEDURE", AT-419.		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<ul style="list-style-type: none"> ● Perform PCM input/output signal inspection. ● If NG, recheck PCM pin terminals for damage or loose connection with harness connector.



COMPONENT INSPECTION

Overdrive Control Switch

- Check continuity between terminals 1 and 2.

Switch position	Continuity
RELEASED	No
DEPRESSED	Yes


NIAT0227S03

NIAT0227S0301

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

21. PCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)




PNP Switch


NIAT0227S0302

1. Check continuity between terminals 1 and 2 and between terminals 3 and 4, 5, 6, 8 while moving manual shaft through each position.

Lever position	Terminal No.	
P	—	1 — 2
R	3 — 8	
N	—	1 — 2
D	3 — 6	
2	3 — 5	
1	3 — 4	



2. If NG, check again with manual control cable disconnected from manual shaft of A/T assembly. Refer to step 1.
3. If OK on step 2, adjust manual control cable. Refer to "Control Cable Adjustment", AT-434.
4. If NG on step 2, remove PNP switch from A/T and check continuity of PNP switch terminals. Refer to step 1.
5. If OK on step 4, adjust PNP switch. Refer to "Park/Neutral Position (PNP) Switch Adjustment", AT-434.
6. If NG on step 4, replace PNP switch.



Throttle Position Switch

NIAT0227S0303

Closed throttle position switch (idle position)

- Check continuity between terminals 5 and 6. Refer to "Preparation", "TCM/PCM Self-diagnostic Procedure (No Tools)", AT-52.


Accelerator pedal condition	Continuity
Released	Yes
Depressed	No

- To adjust closed throttle position switch, refer to **EC-464**, "DTC P0510 CLOSED THROTTLE POSITION SWITCH".

TROUBLE DIAGNOSES FOR SYMPTOMS

QG18DE (EXCEPT CALIF. CA)

21. PCM Self-diagnosis Does Not Activate (PNP, Overdrive Control and Throttle Position Switches Circuit Checks) (Cont'd)



Wide open throttle position switch

- Check continuity between terminals 4 and 5.

Accelerator pedal condition	Continuity
Released	No
Depressed	Yes

A/T SHIFT LOCK SYSTEM

Description


Description

NIAT0127

- The mechanical key interlock mechanism also operates as a shift lock:
With the key switch turned to ON, the selector lever cannot be shifted from "P" (parking) to any other position unless the brake pedal is depressed.
With the key removed, the selector lever cannot be shifted from "P" to any other position.
The key cannot be removed unless the selector lever is placed in "P".
- The shift lock and key interlock mechanisms are controlled by the ON-OFF operation of the shift lock solenoid and by the operation of the rotator and slider located inside the key cylinder.

Shift Lock System Electrical Parts Location

NIAT0128



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX



A/T SHIFT LOCK SYSTEM

Wiring Diagram — SHIFT —

Wiring Diagram — SHIFT —

NIAT0129

AT-SHIFT-01



*: THIS CONNECTOR IS NOT SHOWN IN "HARNESS LAYOUT" OF EL SECTION.

A/T SHIFT LOCK SYSTEM

Diagnostic Procedure

Diagnostic Procedure

NIAT0130

SYMPTOM 1:


- Selector lever cannot be moved from “P” position with key in ON position and brake pedal applied.
- Selector lever can be moved from “P” position with key in ON position and brake pedal released.
- Selector lever can be moved from “P” position when key is removed from key cylinder.

SYMPTOM 2:

Ignition key cannot be removed when selector lever is set to “P” position. It can be removed when selector lever is set to any position except “P”.

1	CHECK KEY INTERLOCK CABLE	
Check key interlock cable for damage.		
OK or NG		
OK	▶	GO TO 2.
NG	▶	Repair key interlock cable. Refer to “Components”, AT-431.


2	CHECK SELECTOR LEVER POSITION	
Check selector lever position for damage.		
OK or NG		
OK	▶	GO TO 3.
NG	▶	Check selector lever. Refer to “Control Cable Adjustment”, AT-434.


3	CHECK POWER SOURCE	
<p>1. Turn ignition switch to “ON” position. (Do not start engine.)</p> <p>2. Check voltage between stop lamp switch harness terminal + and ground.</p>		
 <p style="text-align: center;">Voltage: Battery voltage</p>		
OK or NG		
OK	▶	GO TO 4.
NG	▶	<p>Check the following items:</p> <ol style="list-style-type: none"> 1. Harness for short or open between battery and stop lamp switch harness terminal + 2. 10A fuse No. 2 [located in the fuse block (J/B)] 3. Ignition switch (Refer to EL-9, “POWER SUPPLY ROUTING”).

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

A/T SHIFT LOCK SYSTEM


Diagnostic Procedure (Cont'd)

4	CHECK INPUT SIGNAL (A/T DEVICE)
<p>Turn ignition switch to "ON" position. (Do not start engine.)</p> <ul style="list-style-type: none"> Check voltage between A/T device harness terminal 7 and ground. 	
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  <p>A/T device harness terminal (M44)</p> </div> <div style="text-align: right;"> <p>Voltage: Brake pedal depressed: 0V Brake pedal released: Battery voltage</p> </div> </div>	
LAT229	
OK or NG	
OK	▶ GO TO 5.
NG	▶ Check the following items: <ol style="list-style-type: none"> Harness for short and open between battery and stop lamp switch harness connector 1. Harness for short or open between stop lamp switch harness connector 2 and A/T device harness connector 7. Fuse Stop lamp switch (Refer to "Component Check", AT-430.)

5	CHECK GROUND CIRCUIT
<ol style="list-style-type: none"> Turn ignition switch to "OFF" position. Disconnect A/T device harness connector. Check continuity between A/T device harness terminal 6 and ground. If OK, check harness for short to ground and short to power. 	
<div style="display: flex; justify-content: space-between; align-items: flex-start;"> <div style="text-align: center;">  <p>A/T device harness connector (M44)</p> </div> <div style="text-align: right;"> <p>Continuity should exist.</p> </div> </div>	
LAT230	
OK or NG	
OK	▶ GO TO 6.
NG	▶ Repair open circuit or short to ground or short to power in harness or connectors.

A/T SHIFT LOCK SYSTEM

Diagnostic Procedure (Cont'd)

6	CHECK RELAY CIRCUIT											
<p>1. Turn ignition switch to ON.</p> <ul style="list-style-type: none"> Check voltage between terminal 7 - 6 and 5 - 6. 												
												
<table border="1" style="margin-left: auto; margin-right: auto;"> <thead> <tr> <th>Condition</th> <th>Ignition switch</th> <th>Terminal No.</th> <th>Voltage</th> </tr> </thead> <tbody> <tr> <td rowspan="2">When selector lever is set in "P" position and depressed brake pedal.</td> <td rowspan="2">ON</td> <td>7 - 6</td> <td>Battery voltage</td> </tr> <tr> <td>5 - 6</td> <td>Battery voltage</td> </tr> </tbody> </table>			Condition	Ignition switch	Terminal No.	Voltage	When selector lever is set in "P" position and depressed brake pedal.	ON	7 - 6	Battery voltage	5 - 6	Battery voltage
Condition	Ignition switch	Terminal No.	Voltage									
When selector lever is set in "P" position and depressed brake pedal.	ON	7 - 6	Battery voltage									
		5 - 6	Battery voltage									
LAT231												
OK or NG												
OK	▶	GO TO 7.										
NG	▶	Replace A/T device.										

GI

MA

EM

LC

EC

FE

CL

7	CHECK PARK POSITION SWITCH	
Refer to "A/T DEVICE CHECK", AT-430.		
OK or NG		
OK	▶	GO TO 8.
NG	▶	Replace A/T device.

MT

AT

AX

8	CHECK SHIFT LOCK SOLENOID	
Refer to "A/T DEVICE CHECK", AT-430.		
OK or NG		
OK	▶	GO TO 9.
NG	▶	Replace A/T device.

SU

BR

ST

9	SHIFT LOCK OPERATION	
<p>1. Reconnect shift lock harness connector.</p> <p>2. Turn ignition switch from "OFF" to "ON" position. (Do not start engine.)</p> <p>3. Recheck shift lock operation.</p>		
OK or NG		
OK	▶	INSPECTION END
NG	▶	<p>1. Perform A/T device input/output signal inspection test.</p> <p>2. If NG, recheck harness connector connection.</p>

RS

BT

HA

SC

EL

IDX

A/T SHIFT LOCK SYSTEM

Diagnostic Procedure (Cont'd)

A/T DEVICE CHECK


—NIAT0130S01

1. Shift Lock Solenoid

NIAT0130S0101

- Check operation sound.
When ignition switch is turned to “ON” position and selector lever is set in “P” position.

Brake pedal	Operation sound
Depressed	No
Released	Yes




2. Park Position Switch

NIAT0130S0102

- Check resistance between A/T device harness terminal 6 and 7.

Condition	Resistance
When selector lever is set in “P” position and selector lever button is released	111Ω
Except above	0Ω



STOP LAMP SWITCH

NIAT0130S02

- Check continuity between terminals + and –.

Condition	Continuity
When brake pedal is depressed	No
When brake pedal is released	Yes


Check stop lamp switch after adjusting brake pedal — refer to **BR-12**, “BRAKE PEDAL AND BRACKET” .

KEY INTERLOCK CABLE

Components

Components


NIAT0131



WAT242

CAUTION:

- Install key interlock cable in such a way that it will not be damaged by sharp bends, twists or interference with adjacent parts.
- After installing key interlock cable to control device, make sure that casing cap and bracket are firmly secured in their positions.



SAT853J

Removal


NIAT0132

1. Unlock slider by squeezing lock tabs on slider from adjuster holder and remove interlock rod from cable.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

KEY INTERLOCK CABLE

Removal (Cont'd)




2. Remove lock plate from steering lock assembly and remove key interlock cable.




Installation

NIAT0133

1. Turn ignition key to lock position.
2. Set A/T selector lever to P position.
3. Set key interlock cable to steering lock assembly and install lock plate.
4. Clamp cable to steering column and attach to control cable with band.




5. Insert interlock rod into adjuster holder.



6. Install casing cap to bracket.
7. Move slider in order to connect adjuster holder to interlock rod.

ON-VEHICLE SERVICE

Control Valve Assembly and Accumulators




Control Valve Assembly and Accumulators REMOVAL


NIAT0235

NIAT0235S01


1. Drain ATF from transaxle.
2. Remove oil pan and gasket.



3. Disconnect A/T solenoid valve harness connector.




4. Remove stopper ring from A/T solenoid harness terminal body.
5. Remove A/T solenoid harness by pushing terminal body into transmission case.



6. Remove control valve assembly by removing fixing bolts.

Bolt length, number and location:

Bolt symbol	A	B	C
Bolt length "ℓ" 	40.0 mm (1.575 in)	33.0 mm (1.299 in)	43.5 mm (1.713 in)
Number of bolts	5	6	2

- Be careful not to drop manual valve and servo release accumulator return springs.

7. Disassemble and inspect control valve assembly if necessary. Refer to "COMPONENTS", AT-465.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX


ON-VEHICLE SERVICE

Control Valve Assembly and Accumulators (Cont'd)



8. Remove servo release and N-D accumulators by applying compressed air if necessary.


- Hold each piston with a clean, lint-free towel.



INSTALLATION

NIAT0235S02

- Tighten fixing bolts to specification.
⚙️ : 7 - 9 N·m (0.7 - 0.9 kg·m, 61 - 78 in-lb)
- Set manual shaft in Neutral position, then align manual plate with groove in manual valve.
- After installing control valve assembly to transmission case, make sure that selector lever can be moved to all positions.




Control Cable Adjustment

NIAT0236

Move selector lever from the "P" position to the "1" position. You should be able to feel the detents in each position. If the detents cannot be felt or if the pointer indicating the position is improperly aligned, the control cable needs adjustment.

1. Place selector lever in "P" position.
2. Loosen control cable lock nut and place manual shaft in "P" position.
3. Push control cable, by specified force, in the direction of the arrow shown in the illustration.
Specified force: 9.8 N (1.0 kg, 2.2 lb)
4. Release control cable in the opposite direction of the arrow for 1.0 mm (0.039 in).
5. Tighten control cable lock nut by hand.
6. Tighten control cable lock nut.
⚙️ : 11.8 - 14.7 N·m (1.20 - 1.50 kg·m, 8.7 - 10.8 ft-lb)
7. Move selector lever from "P" to "1" position again. Make sure that selector lever moves smoothly.
8. Apply grease to contacting areas of selector lever and control cable. Install any part removed.




Park/Neutral Position (PNP) Switch Adjustment

NIAT0237

1. Remove control cable end from manual shaft.
2. Set manual shaft in "N" position.
3. Loosen PNP switch fixing bolts.


ON-VEHICLE SERVICE

Park/Neutral Position (PNP) Switch Adjustment (Cont'd)



4. Use a 4 mm (0.157 in) pin for this adjustment.
 - a. Insert the pin straight into the manual shaft adjustment hole.
 - b. Rotate PNP switch until the pin can also be inserted straight into hole in PNP switch.
5. Tighten PNP switch fixing bolts.
6. Remove pin from adjustment hole after adjusting PNP switch.
7. Reinstall any part removed.
8. Adjust control cable. Refer to "Control Cable Adjustment", AT-434.
9. Check continuity of PNP switch. Refer to "Component Inspection", AT-119.


GI
MA
EM
LC



Differential Side Oil Seal Replacement


1. Remove drive shaft assemblies using Tool. Refer to ^{NIAT0238} **AX-10**, "DRIVE SHAFT".
2. Remove oil seals.

EC
FE
CL
MT



3. Install oil seals using Tool.
 - **Apply ATF to oil seal surface before installing.**

AT
AX
SU
BR




- **Install oil seals so that dimensions "A" and "B" are within specifications.**

Unit: mm (in)

A	B
5.5 - 6.5 (0.217 - 0.256)	-0.5 to 0.5 (-0.020 to 0.020)

ST
RS
BT
HA

4. Reinstall any part removed.



Revolution Sensor Replacement

1. Disconnect revolution sensor harness connector.
2. Remove harness bracket from A/T.
3. Remove revolution sensor from A/T.
4. Reinstall any part removed.





Always use new sealing parts.

NIAT0239

SC
EL
IDX

REMOVAL AND INSTALLATION

Removal



Removal

NIAT0240

CAUTION:

Before separating transaxle from engine, remove the crankshaft position sensor (POS) from transaxle. Be careful not to damage sensor.


1. Remove battery and bracket.
2. Remove air duct between throttle body and air cleaner.
3. Disconnect terminal cord assembly, PNP switch harness connector and revolution sensor harness connector.
4. Remove crankshaft position sensor (POS) from transaxle (SR20DE).

5. Drain ATF from transaxle.
6. Disconnect control cable from transaxle.
7. Disconnect oil cooler hoses.
8. Remove drive shafts. Refer to **AX-10**, "DRIVE SHAFT".
9. Remove the intake manifold support bracket. Refer to **EM-12** (QG18DE), **EM-84** (SR20DE), "OUTER COMPONENT PARTS".
10. Remove starter motor from transaxle.
Tighten bolts to specified torque.
⚙️ : 33.3 - 46.1 N·m (3.4 - 4.7 kg·m, 25 - 34 ft·lb)
11. Remove upper bolts fixing transaxle to engine.
12. Support transaxle with a jack.

13. Remove center member.
 - Tighten center member fixing bolts to specified torque, Refer to **EM-49** (QG18DE), **EM-127** (SR20DE), "Removal and Installation".


REMOVAL AND INSTALLATION

Removal (Cont'd)



14. Remove rear plate cover.
15. Remove torque converter bolts.
Rotate crankshaft to gain access to securing bolts.
16. Remove rear transaxle to engine bracket. Refer to **EM-49** (QG18DE), **EM-127** (SR20DE), "Removal and Installation".
17. Support engine with a jack.
18. Remove rear transaxle mount. Refer to **EM-49** (QG18DE), **EM-127** (SR20DE), "Removal and Installation".
19. Remove lower bolts fixing transaxle to engine.
20. Lower transaxle while supporting it with a jack.

GI
MA
EM
LC



Installation

NIAT0241

1. Check drive plate runout.

CAUTION:


Do not allow any magnetic materials to contact the ring gear teeth.

Maximum allowable runout:

Refer to **EM-76** (QG18DE), **EM-153** (SR20DE), "FLYWHEEL/DRIVE PLATE RUNOUT".

- If this runout is out of allowance, replace drive plate with ring gear.

EC
FE



2. When connecting torque converter to transaxle, measure distance "A" to be certain that they are correctly assembled.

Distance "A":


15.9 mm (0.626 in) or more

AT

AX

SU

BR



3. Install torque converter to drive plate.


- **With converter installed, rotate crankshaft several turns to check that transaxle rotates freely without binding.**

ST

RS

BT

HA



4. Tighten bolts fixing transaxle.

QG18DE Model

Bolt No.	Tightening torque N·m (kg·m, ft·lb)	Bolt length "ℓ" mm (in)
1	30 - 40 (3.1 - 4.1, 23 - 29)	50 (1.97)
2*1	16 - 20 (1.6 - 2.1, 12 - 15)	25 (0.98)
3	31 - 40 (3.1 - 4.1, 23 - 29)	30 (1.18)
4*2	30 - 40 (3.1 - 4.1, 23 - 29)	16 (0.63)

EL

IDX


REMOVAL AND INSTALLATION

Installation (Cont'd)

Bolt No.	Tightening torque N·m (kg-m, ft-lb)	Bolt length "ℓ" mm (in)
5*2	16 - 20 (1.6 - 2.1, 12 - 15)	20 (0.79)


*1: With gusset to A/T

*2: With gusset to cylinder block



SR20DE Model

Bolt No.	Tightening torque N·m (kg-m, ft-lb)	Bolt length "ℓ" mm (in)
1	70 - 79 (7.1 - 8.1, 51 - 59)	55 (2.17)
2	70 - 79 (7.1 - 8.1, 51 - 59)	50 (1.97)
3	70 - 79 (7.1 - 8.1, 51 - 59)	65 (2.56)
4	16 - 21 (1.6 - 2.1, 12 - 15)	35 (1.38)
5	16 - 21 (1.6 - 2.1, 12 - 15)	45 (1.77)




5. Reinstall any part removed.
6. Adjust control cable. Refer to "Control Cable Adjustment", AT-434.
7. Check continuity of PNP switch. Refer to "PARK NEUTRAL POSITION SWITCH", AT-279.
8. Refill transaxle with ATF and check fluid level.
9. Move selector lever through all positions to be sure that transaxle operates correctly. With parking brake applied, idle engine. Move selector lever through "N" to "D", to "2", to "1" and "R" positions. A slight shock should be felt through the hand gripping the selector each time the transaxle is shifted.
10. Perform road test. Refer to "Road Test", AT-73.

Components

NIAT02-42


SEC. 311•313•327•381



GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

OVERHAUL

Oil Channel



OVERHAUL

Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings

Locations of Adjusting Shims, Needle Bearings, Thrust Washers and Snap Rings


NIAT0244

Outer diameter and color of thrust washers

Item number	Outer diameter mm (in)	Color
(17)	72.0 (2.835)	Black
(18)	78.5 (3.091)	

Outer and inner diameter of needle bearings

Item number	Outer diameter mm (in)	Inner diameter mm (in)
(8)	47.0 (1.850)	32.0 (1.260)
(9)	35.0 (1.378)	20.1 (0.791)
(10)	60.0 (2.362)	42.0 (1.657)
(11)	60.0 (2.362)	45.0 (1.772)
(12)	47.0 (1.850)	30.0 (1.181)
(13)	42.6 (1.677)	26.0 (1.024)
(14)	48.0 (1.890)	33.5 (1.319)
(15)	55.0 (2.165)	40.5 (1.594)
(16)	60.0 (2.362)	40.0 (1.579)



★ : Select proper thickness.

Outer and inner diameter of bearing race and adjusting shims

Item number	Outer diameter mm (in)	Inner diameter mm (in)
(19)	48.0 (1.890)	33.0 (1.299)
(20)	72.0 (2.835)	61.0 (2.402)
(21)	34.5 (1.358)	26.1 (1.028)
(22)	68.0 (2.677)	60.0 (2.362)

Outer diameter of snap rings

Item number	Outer diameter mm (in)
(1)	142.0 (5.59)
(2)	113.0 (4.45)
(3)	162.4 (6.39)
(4)	135.4 (5.33)
(5)	162.3 (6.39)
(6)	126.0 (4.96)
(7)	40.5 (1.594)

WAT246

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX


DISASSEMBLY



1. Drain ATF through drain plug.




2. Remove torque converter.





3. Check torque converter one-way clutch using check tool as shown at left.

- a. Insert check tool into the groove of bearing support built into one-way clutch outer race.
- b. While fixing bearing support with check tool, rotate one-way clutch spline using flat-bladed screwdriver.
- c. Check inner race rotates clockwise only. If not, replace torque converter assembly.




4. Remove oil charging pipe and oil cooler tube.

DISASSEMBLY



5. Set manual shaft to "P" position.
6. Remove PNP switch.


7. Remove oil pan and oil pan gasket.
 - **Do not reuse oil pan bolts.**
8. Check foreign materials in oil pan to help determine cause of malfunction. If the fluid is very dark, smells burned, or contains foreign particles, the frictional material (clutches, band) may need replacement. A tacky film that will not wipe clean indicates varnish build up. Varnish can cause valves, servo, and clutches to stick and may inhibit pump pressure.
 - **If frictional material is detected, replace radiator after repair of A/T. Refer to LC-15 (QG18DE), LC-33 (SR20DE), "Radiator".**
9. Remove control valve assembly according to the following procedures.




- a. Remove control valve assembly mounting bolts A, B and C.

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX


DISASSEMBLY




- b. Remove stopper ring from terminal body.
- c. Push terminal body into transmission case and draw out solenoid harness.




10. Remove manual valve from control valve assembly as a precaution.



11. Remove return spring from servo release accumulator piston.




12. Remove servo release accumulator piston with compressed air.
13. Remove O-rings from servo release accumulator piston.



14. Remove N-D accumulator piston and return spring with compressed air.
15. Remove O-rings from N-D accumulator piston.

DISASSEMBLY



16. Check accumulator pistons and contact surface of transmission case for damage.

17. Check accumulator return springs for damage and free length.

Return springs:


Refer to "RETURN SPRING", AT-549.

GI

MA

EM

LC




18. Remove lip seals from band servo oil port.

EC

FE

CL

MT



19. Remove converter housing according to the following procedures.


a. Remove converter housing mounting bolts A and B.

AT

AX

SU

BR




b. Remove converter housing.

ST

RS

BT

HA




c. Remove O-ring from differential oil port.

SC


EL

IDX


DISASSEMBLY




20. Remove final drive assembly from transmission case.




21. Remove differential side bearing outer race from transmission case using Tool.



22. Remove differential side bearing adjusting shim from transmission case.




23. Remove differential side bearing outer race from converter housing using Tool.




24. Remove oil seal from converter housing using a screwdriver.
● **Be careful not to damage case.**


DISASSEMBLY




25. Remove side oil seal from transmission case using a screwdriver.




26. Remove oil tube from converter housing.



27. Remove oil pump according to the following procedures.
a. Remove O-ring from input shaft.



b. Remove oil pump assembly from transmission case.



c. Remove thrust washer and bearing race from oil pump assembly.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX


DISASSEMBLY




28. Remove brake band according to the following procedures.
- Loosen lock nut, then back off anchor end pin.
 - Do not reuse anchor end pin.**




- Remove brake band from transmission case.



- To prevent brake linings from cracking or peeling, do not stretch the flexible band unnecessarily. When removing the brake band, always secure it with a clip as shown in the figure at left. Leave the clip in position after removing the brake band.**




- Check brake band facing for damage, cracks, wear or burns.




29. Remove input shaft assembly (high clutch) and reverse clutch according to the following procedures.
- Remove input shaft assembly (high clutch) with reverse clutch.


DISASSEMBLY




- b. Remove input shaft assembly (high clutch) from reverse clutch.




- c. Remove needle bearing from high clutch drum.
d. Check input shaft assembly and needle bearing for damage or wear.



30. Remove high clutch hub and needle bearing from transmission case.
31. Check high clutch hub and needle bearing for damage or wear.



32. Remove front sun gear and needle bearings from transmission case.
33. Check front sun gear and needle bearings for damage or wear.



34. Remove front planetary carrier assembly and low one-way clutch according to the following procedures.
a. Remove snap ring using a screwdriver.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX


DISASSEMBLY




- b. Remove front planetary carrier with low one-way clutch.



- c. Check that low one-way clutch rotates in the direction of the arrow and locks in the opposite direction.
- d. Remove low one-way clutch from front planetary carrier by rotating it in the direction of unlock.



- e. Remove needle bearing from front planetary carrier.



- f. Check front planetary carrier, low one-way clutch and needle bearing for damage or wear.
- g. Check clearance between pinion washer and planetary carrier using feeler gauge.


Standard clearance:

0.15 - 0.70 mm (0.0059 - 0.0276 in)

Allowable limit:


0.80 mm (0.0315 in)

Replace front planetary carrier if the clearance exceeds allowable limit.




35. Remove rear planetary carrier assembly and rear sun gear according to the following procedures.
- a. Remove rear planetary carrier assembly from transmission case.


DISASSEMBLY



b. Remove rear sun gear from rear planetary carrier.



c. Remove needle bearings from rear planetary carrier assembly.



d. Check rear planetary carrier, rear sun gear and needle bearings for damage or wear.

e. Check clearance between pinion washer and rear planetary carrier using feeler gauge.


Standard clearance:

0.15 - 0.70 mm (0.0059 - 0.0276 in)


Allowable limit:

0.80 mm (0.0315 in)

Replace rear planetary carrier if the clearance exceeds allowable limit.



36. Remove rear internal gear from transmission case.



37. Remove needle bearing from rear internal gear.

- Check needle bearing for damage or wear.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX


DISASSEMBLY



38. Remove forward clutch assembly from transmission case.




39. Remove thrust washer from transmission case.




40. Remove output shaft assembly according to the following procedures.

a. Remove side cover bolts.




b. Remove side cover by lightly tapping it with a soft hammer.

● **Be careful not to drop output shaft assembly. It might come out when removing side cover.**




c. Remove adjusting shim.


DISASSEMBLY




d. Remove output shaft assembly.



- If output shaft assembly came off with side cover, tap cover with a soft hammer to separate.




e. Remove needle bearing.



41. Disassemble reduction pinion gear according to the following procedures.

- Set manual shaft to position "P" to fix idler gear.
- Unlock idler gear lock nut using a pin punch.



c. Remove idler gear lock nut.

- Do not reuse idler gear lock nut.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX

DISASSEMBLY




d. Remove idler gear with puller using Tool.




e. Remove reduction pinion gear.

f. Remove adjusting shim from reduction pinion gear.




42. Remove return spring from parking shaft using a screwdriver.



43. Draw out parking shaft and remove parking pawl from transmission case.


44. Check parking pawl and shaft for damage or wear.



45. Remove parking actuator support from transmission case.

- Check parking actuator support for damage or wear.

DISASSEMBLY



46. Remove revolution sensor from transmission case.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

REPAIR FOR COMPONENT PARTS

Manual Shaft

Manual Shaft COMPONENTS


NIAT0246




REMOVAL

NIAT0247

1. Remove detent spring from transmission case.




2. Drive out manual plate retaining pin using Tool.




3. Drive and pull out parking rod plate retaining pin using Tool.
4. Remove parking rod plate from manual shaft.
5. Draw out parking rod from transmission case.

REPAIR FOR COMPONENT PARTS

Manual Shaft (Cont'd)




6. Pull out manual shaft retaining pin.
7. Remove manual shaft and manual plate from transmission case.



8. Remove manual shaft oil seal.


INSPECTION

- Check component parts for wear or damage. Replace if necessary. ^{NIAT02.48}



INSTALLATION

1. Install manual shaft oil seal using a suitable tool.
- Apply ATF to outer surface of oil seal.



2. Install manual shaft and manual plate.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

^{NIAT02.49} ST

RS

BT

HA


SC

EL


IDX

REPAIR FOR COMPONENT PARTS


Manual Shaft (Cont'd)




3. Align groove of manual shaft and hole of transmission case.
4. Install manual shaft retaining pin using Tool.



5. Install parking rod to parking rod plate.
6. Set parking rod assembly onto manual shaft.




7. Drive in manual plate retaining pin and parking rod plate retaining pin using Tool.




8. Install detent spring.
🔩 : 6.4 - 7.5 N·m (0.65 - 0.76 kg·m, 56.4 - 66.0 in·lb)

Oil Pump COMPONENTS

NIAT0250



GI
MA
EM
LC
EC
FE
CL
MT




DISASSEMBLY


1. Remove seal rings.

NIAT0251

AT



2. Loosen bolts in numerical order and remove oil pump cover.




3. Remove inner and outer gear from oil pump housing.


AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)



4. Remove O-ring from oil pump housing.



5. Remove oil pump housing oil seal.


INSPECTION

Oil Pump Housing, Oil Pump Cover, Inner Gear and Outer Gear

NIAT0252

NIAT0252S01

- Check for wear or damage.



Side Clearances

NIAT0252S02

- Measure side clearance of inner and outer gears in at least four places around each outside edge. Maximum measured values should be within specified range.

Standard clearance:

0.02 - 0.04 mm (0.0008 - 0.0016 in)

- If clearance is less than standard, select inner and outer gear as a set so that clearance is within specifications.


Inner and outer gear:

Refer to "Oil Pump", AT-544.


- If clearance is more than standard, replace whole oil pump assembly except oil pump cover.

REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)




- Measure clearance between outer gear and oil pump housing.
 - Standard clearance:**
0.08 - 0.15 mm (0.0031 - 0.0059 in)
 - Allowable limit:**
0.15 mm (0.0059 in)
- If not within allowable limit, replace whole oil pump assembly except oil pump cover.



Side Ring Clearance

NIAT0252S03


- Install new seal rings onto oil pump cover.
- Measure clearance between seal ring and ring groove.
 - Standard clearance:**
0.1 - 0.25 mm (0.0039 - 0.0098 in)
 - Allowable limit:**
0.25 mm (0.0098 in)
- If not within allowable limit, replace oil pump cover assembly.




ASSEMBLY

NIAT0253

1. Install oil seal on oil pump housing using Tool.



2. Install O-ring on oil pump housing.
 - **Apply ATF to O-ring.**



3. Install inner and outer gears on oil pump housing.
 - **Take care with the direction of the inner gear.**

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

REPAIR FOR COMPONENT PARTS

Oil Pump (Cont'd)




4. Install oil pump cover on oil pump housing.
 - a. Wrap masking tape around splines of oil pump cover assembly to protect seal. Position oil pump cover assembly on oil pump housing assembly, then remove masking tape.
 - b. Tighten bolts in numerical order.



5. Install new seal rings carefully after packing ring groove with petroleum jelly.
 - **Do not spread gap of seal ring excessively while installing. It may deform the ring.**

Control Valve Assembly COMPONENTS

=NIAT0254



- | | | |
|----------------------------------|-----------------------------------|------------------------------------|
| 1. Solenoid valve assembly | 9. Separating plate | 17. Steel ball |
| 2. O-ring | 10. Lower separating gasket | 18. Control valve upper body |
| 3. Clip | 11. Steel ball | 19. Check ball |
| 4. Terminal cord assembly | 12. Control valve inter body | 20. Oil cooler relief valve spring |
| 5. Control valve lower body | 13. Pilot filter | 21. O-ring |
| 6. Oil strainer | 14. Upper inter separating gasket | 22. T/C pressure holding spring |
| 7. Support plate | 15. Separating plate | 23. Check ball |
| 8. Lower inter separating gasket | 16. Upper separating gasket | |

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)

DISASSEMBLY


=NIAT0255

- Disassemble upper, inter and lower bodies.


Bolt length, number and location:

Bolt symbol	A	B	C	D	E	F	G
Bolt length "ℓ" 	13.5 mm (0.531 in)	58.0 mm (2.283 in)	40.0 mm (1.575 in)	66.0 mm (2.598 in)	33.0 mm (1.299 in)	78.0 mm (3.071 in)	18.0 mm (0.709 in)
Number of bolts	6	3	6	11	2	2	1

F: Reamer bolt with nut




SAT869J



SAT083F

- Remove bolts A, D and F, and remove oil strainer from control valve assembly.




SAT316GA


- Remove solenoid valve assembly and line pressure solenoid valve from control valve assembly.
 - Be careful not to lose the line pressure solenoid valve spring.

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)




3. Remove O-rings from solenoid valves and terminal body.




4. Place upper body face down, and remove bolts B, C and F.



5. Remove lower body from inter body.



6. Turn over lower body, and accumulator support plates.



7. Remove bolts E, separating plate and separating gaskets from lower body.

8. Remove check balls, oil cooler relief valve springs and T/C pressure holding spring from lower body.

● Be careful not to lose steel balls and relief valve springs.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd)




9. Remove inter body from upper body.
10. Remove pilot filter, separating plate and gaskets from upper body.




11. Check to see that steel balls are properly positioned in inter body and then remove them.

- **Be careful not to lose steel balls.**



12. Check to see that steel balls are properly positioned in upper body and then remove them.

- **Be careful not to lose steel balls.**




INSPECTION Lower and Upper Bodies

NIAT0256

NIAT0256S01


- Check to see that retainer plates are properly positioned in lower body.



- Check to see that retainer plates are properly positioned in upper body.

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)



Oil Strainer

NIAT0256S02


- Check wire netting of oil strainer for damage.



Shift Solenoid Valves A and B, Line Pressure Solenoid valve, Torque Converter Clutch Solenoid Valve and Overrun Clutch Solenoid Valve

NIAT0256S03

- Refer to "Resistance Check", AT-322, 326 and 362.



Oil Cooler Relief Valve Spring


NIAT0256S04

- Check springs for damage or deformation.
- Measure free length and outer diameter.

Inspection standard:

Unit: mm (in)


Part No.	ℓ	D
31872 31X00	17.0 (0.669)	8.0 (0.315)



ASSEMBLY

NIAT0257

1. Install upper, inter and lower body.
 - a. Place oil circuit of upper body face up. Install steel balls in their proper positions.



- b. Install upper separating gasket, upper inter separating gasket and upper separating plate in order shown in illustration.

- Always use new gaskets.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)




- c. Install reamer bolts **F** from bottom of upper body. Using reamer bolts as guides, install separating plate and gaskets as a set.




- d. Install pilot filter.



- e. Place inter body as shown in the illustration. Install steel balls in their proper positions.




- f. Install inter body on upper body using reamer bolts **F** as guides.
- **Be careful not to dislocate or drop steel balls.**




- g. Install steel balls, oil cooler relief valve springs and T/C pressure holding spring in their proper positions in lower body.

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)




- h. Install lower separating gasket, inter separating gasket and lower separating plate in order shown in the illustration.



- i. Install bolts E from bottom of lower body. Using bolts E as guides, install separating plate and gaskets as a set.
j. Install support plates on lower body.




- k. Install lower body on inter body using reamer bolts F as guides and tighten reamer bolts F slightly.



2. Install O-rings to solenoid valves and terminal body.
● **Apply ATF to O-rings.**

3. Install and tighten bolts.

Bolt length, number and location:

Bolt symbol	A	B	C	D	E	F	G
Bolt length "ℓ" 	13.5 mm (0.531 in)	58.0 mm (2.283 in)	44.0 mm (1.732 in)	66.0 mm (2.598 in)	33.0 mm (1.299 in)	78.0 mm (3.071 in)	18.0 mm (0.709 in)
Number of bolts	6	3	6	11	2	2	1

F: Reamer bolt with nut

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA



SC


EL


IDX

REPAIR FOR COMPONENT PARTS


Control Valve Assembly (Cont'd)



- a. Install and tighten bolts **B** to specified torque.
 : 7 - 9 N·m (0.7 - 0.9 kg-m, 61 - 78 in-lb)




- b. Install solenoid valve assembly and line pressure solenoid valve to lower body.




- c. Remove reamer bolts **F** and set oil strainer on control valve assembly.
 d. Reinstall reamer bolts **F** from lower body side.

REPAIR FOR COMPONENT PARTS

Control Valve Assembly (Cont'd)



- e. Tighten bolts A, C, D and F to specified torque.
🔩 : 7 - 9 N·m (0.7 - 0.9 kg·m, 61 - 78 in-lb)



- f. Tighten bolts E to specified torque.
🔩 : 3.4 - 4.4 N·m (0.35 - 0.45 kg·m, 30.4 - 39.1 in-lb)

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

REPAIR FOR COMPONENT PARTS


Control Valve Upper Body

Control Valve Upper Body

COMPONENTS

Numbers preceding valve springs correspond with those shown in "CONTROL VALVE AND PLUG RETURN SPRINGS" table on page AT-542. =NIAT0258

SEC. 317



Apply ATF to all components before installation.


WAT250

- | | | |
|--|----------------------------------|------------------------------------|
| 1. Control valve upper body | 12. Sleeve | 25. Retainer plate |
| 2. Overrun clutch reducing valve spring | 13. Retainer plate | 26. Plug |
| 3. Overrun clutch reducing valve | 14. 1-2 accumulator valve | 27. 1-2 accumulator piston |
| 4. Plug | 15. 1-2 accumulator valve spring | 28. 1-2 accumulator piston spring |
| 5. Retainer plate | 16. Plug | 29. 1-2 accumulator retainer plate |
| 6. Torque converter relief valve | 17. Retainer plate | 30. Retainer plate |
| 7. Torque converter relief valve spring | 18. Cooler check valve | 31. Plug |
| 8. Retainer plate | 19. Cooler check valve spring | 32. 1st reducing valve |
| 9. Torque converter clutch control valve | 20. Plug | 33. 1st reducing valve spring |
| 10. Return spring | 21. Retainer plate | 34. Retainer plate |
| 11. Plug | 22. Retainer plate | 35. Return spring |
| | 23. Pilot valve spring | 36. 3-2 timing valve spring |
| | 24. Pilot valve | |

REPAIR FOR COMPONENT PARTS

Control Valve Upper Body (Cont'd)


NIAT0259



SAT321G


DISASSEMBLY

1. Remove valves at retainer plates.
 - Do not use a magnetic "hand".




SAT135D

- a. Use a screwdriver to remove retainer plates.




SAT136D

- b. Remove retainer plates while holding spring, plugs or sleeves.
 - Remove plugs slowly to prevent internal parts from jumping out.



SAT137D

- c. Place mating surface of valve body face down, and remove internal parts.
 - If a valve is hard to remove, place valve body face down and lightly tap it with a soft hammer.
 - Be careful not to drop or damage valves and sleeves.



SAT138D

INSPECTION

Valve Spring

- Measure free length and outer diameter of each valve spring. Also check for damage or deformation.

Inspection standard:

Refer to "CONTROL VALVE AND PLUG RETURN SPRINGS", AT-542.

- Replace valve springs if deformed or fatigued.

Control Valves

- Check sliding surfaces of valves, sleeves and plugs.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

NIAT0260S02


REPAIR FOR COMPONENT PARTS

Control Valve Upper Body (Cont'd)




ASSEMBLY


- Lay control valve body down when installing valves. Do not stand the control valve body upright. NIAT0261



1. Lubricate the control valve body and all valves with ATF. Install control valves by sliding them carefully into their bores.
- Be careful not to scratch or damage valve body.




- Wrap a small screwdriver with vinyl tape and use it to insert the valves into their proper positions.



1-2 Accumulator Valve


- Install 1-2 accumulator valve. Align 1-2 accumulator retainer plate from opposite side of control valve body. NIAT0261S01
- Install return spring, 1-2 accumulator piston and plug.



1. Install retainer plates.
- Install retainer plate while pushing plug or return spring.

REPAIR FOR COMPONENT PARTS

Control Valve Upper Body (Cont'd)



SAT086F

Retainer Plate (for control valve upper body)

NIAT0261S02

Refer to "Control Valve Upper Body", AT-474.

Unit: mm (in)

Name of valve and piston	No.	Length A	Length B
Pilot valve	22	6.0 (0.236)	21.5 (0.846)
1-2 accumulator valve	17		40.5 (1.575)
1-2 accumulator piston	25		21.5 (0.846)
1st reducing valve	30		24.0 (0.945)
Overrun clutch reducing valve	5		21.5 (0.846)
Torque converter relief valve	8		28.0 (1.102)
Torque converter clutch control valve	13		21.5 (0.846)
3-2 timing valve	34		24.0 (0.945)
Cooler check valve	21		

- Install proper retainer plates.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

REPAIR FOR COMPONENT PARTS


Control Valve Lower Body

Control Valve Lower Body

COMPONENTS

Numbers preceding valve springs correspond with those shown in "CONTROL VALVE AND PLUG RETURN SPRINGS" table on page AT-542. =NIAT0262

SEC. 317




Apply ATF to all components before installation.

WAT251

- | | | |
|------------------------------------|---|--------------------------------------|
| 1. Control valve lower body | 13. Manual valve | 25. Plug |
| 2. Shift valve B spring | 14. Retainer plate | 26. Accumulator control valve |
| 3. Shift valve B | 15. Sleeve | 27. Accumulator control valve spring |
| 4. Plug | 16. Plug | 28. Retainer plate |
| 5. Retainer plate | 17. Spring seat | 29. Shift valve A spring |
| 6. Pressure modifier valve | 18. Pressure regulator valve spring | 30. Shift valve A |
| 7. Pressure modifier valve spring | 19. Pressure regulator valve | 31. Retainer plate |
| 8. Parallel pin | 20. Retainer plate | 32. Plug |
| 9. Sleeve | 21. Plug | 33. Plug |
| 10. Piston | 22. Overrun clutch control valve | 34. Shuttle valve spring |
| 11. Pressure modifier valve spring | 23. Overrun clutch control valve spring | 35. Shuttle control valve |
| 12. Retainer plate | 24. Retainer plate | |

REPAIR FOR COMPONENT PARTS

Control Valve Lower Body (Cont'd)



DISASSEMBLY

Remove valves at retainer plate.
For removal procedures, refer to "DISASSEMBLY", AT-466.


NIAT0263

GI

MA

EM

LC



INSPECTION

Valve Springs

- Check each valve spring for damage or deformation. Also measure free length and outer diameter.

Inspection standard:

Refer to "CONTROL VALVE AND PLUG RETURN SPRINGS", AT-542.

- Replace valve springs if deformed or fatigued.

Control Valves

- Check sliding surfaces of control valves, sleeves and plugs for damage.

NIAT0264

NIAT0264S01

EC

FE

CL


MT

AT

AX

SU

BR



ASSEMBLY

- Install control valves.
For installation procedures, refer to "ASSEMBLY", AT-469.


NIAT0265

ST

RS

BT

HA



Retainer Plate (for control valve lower body)

Refer to "Control Valve Lower Body", AT-478.

NIAT0265S01

SC

EL

IDX

REPAIR FOR COMPONENT PARTS

Control Valve Lower Body (Cont'd)


Unit: mm (in)

Name of control valve	No.	Length A	Length B	Type
Pressure regulator valve	14	6.0 (0.236)	28.0 (1.102)	I
Accumulator control valve	24			
Shift valve A	28			
Overrun clutch control valve	20			
Pressure modifier valve	12			
Shuttle control valve	31	—	—	II
Shift valve B	5			




- Install proper retainer plates.

Reverse Clutch COMPONENTS

=NIAT0266



GI
MA
EM
LC
EC
FE
CL
MT



DISASSEMBLY


NIAT0267

1. Check operation of reverse clutch.
 - a. Install seal ring onto drum support of oil pump cover and install reverse clutch assembly. Apply compressed air to oil hole.
 - b. Check to see that retaining plate moves to snap ring.
 - c. If retaining plate does not contact snap ring:
 - D-ring might be damaged.
 - Oil seal might be damaged.
 - Fluid might be leaking past piston check ball.
2. Remove snap ring.
3. Remove drive plates, driven plates, retaining plate, and dish plates.
4. Set Tool on spring retainer and remove snap ring from reverse clutch drum while compressing return springs.
 - **Set Tool directly above springs.**
 - **Do not expand snap ring excessively.**
5. Remove spring retainer and return springs.


AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REPAIR FOR COMPONENT PARTS


Reverse Clutch (Cont'd)



- Do not remove return springs from spring retainer.



6. Remove piston from reverse clutch drum by turning it.




7. Remove D-ring and oil seal from piston.

INSPECTION

Reverse Clutch Snap Ring, Spring Retainer and Return Springs NIAT0268

- Check for deformation, fatigue or damage. NIAT0268S01
- Replace if necessary.
- **When replacing spring retainer and return springs, replace them as a set.**




Reverse Clutch Drive Plates NIAT0268S02

- Check facing for burns, cracks or damage.
- Measure thickness of facing.
Thickness of drive plate:
Standard value: 2.0 mm (0.079 in)
Wear limit: 1.8 mm (0.071 in)
- If not within wear limit, replace.

REPAIR FOR COMPONENT PARTS

Reverse Clutch (Cont'd)



Reverse Clutch Dish Plates

NIAT0268S03


- Check for deformation or damage.
- Measure thickness of dish plate.
Thickness of dish plate "t": 2.8 mm (0.110 in)
- If deformed or fatigued, replace.

GI

MA

EM

LC



Reverse Clutch Piston

NIAT0268S04


- Make sure check balls are not fixed.
- Apply compressed air to check ball oil hole opposite the return spring. Make sure that there is no air leakage.
- Apply compressed air to oil hole on return spring side to make sure air leaks past ball.

EC

FE

CL

MT



ASSEMBLY

NIAT0269


1. Install D-ring and oil seal on piston.
 - Take care with the direction of the oil seal.
 - Apply ATF to both parts.

AT

AX

SU

BR




2. Install piston assembly by turning it slowly.
 - Apply ATF to inner surface of drum.

ST

RS

BT

HA



3. Install return springs and spring retainer on piston.

Return spring:

Refer to "Clutch and Brake Return Spring", AT-544.


SC

EL


IDX

REPAIR FOR COMPONENT PARTS


Reverse Clutch (Cont'd)




4. Set Tool on spring retainer and install snap ring while compressing return springs.
 - **Set Tool directly above return springs.**



5. Install drive plates, driven plates, retaining plate and dish plates.
 - **Do not align the projections of any two dish plates.**
 - **Take care with the order and direction of plates.**



6. Install snap ring.




7. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard: 0.5 - 0.8 mm (0.020 - 0.031 in)

Allowable limit: 1.2 mm (0.047 in)

Retaining plate: Refer to "REVERSE CLUTCH", AT-542.




8. Check operation of reverse clutch. Refer to "Reverse Clutch", AT-481.

High Clutch COMPONENTS


=NIAT0270

SEC. 315

For the number of clutch sheets (drive plates and driven plates), refer to the below cross-section.




SAT874J



DISASSEMBLY

NIAT0271

- Check operation of high clutch.
 - Apply compressed air to oil hole of input shaft.
 - **Stop up a hole on opposite side of input shaft.**
 - Check to see that retaining plate moves to snap ring.
 - If retaining plate does not contact snap ring:
 - D-ring might be damaged.
 - Oil seal might be damaged.
 - Fluid might be leaking past piston check ball.
- Remove seal rings from input shaft.



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA






SC

EL

IDX

REPAIR FOR COMPONENT PARTS

High Clutch (Cont'd)



3. Remove snap ring.
4. Remove drive plates, driven plates and retaining plate.

5. Set Tool on spring retainer and remove snap ring from high clutch drum while compressing return springs.
 - **Set Tool directly above springs.**
 - **Do not expand snap ring excessively.**
6. Remove spring retainer and return springs.

- **Do not remove return spring from spring retainer.**

7. Remove piston from high clutch drum by turning it.

8. Remove D-ring and oil seal from piston.


INSPECTION

Reverse Clutch Snap Ring, Spring Retainer and Return Springs

NIAT0272
NIAT0272S01

- Check for deformation, fatigue or damage.
- Replace if necessary.
- **When replacing spring retainer and return springs, replace them as a set.**

GI
MA
EM



High Clutch Drive Plates

NIAT0272S02

- Check facing for burns, cracks or damage.
- Measure thickness of facing.


Thickness of drive plate:

Standard value: 2.0 mm (0.079 in)

Wear limit: 1.8 mm (0.071 in)

- If not within wear limit, replace.

LC
EC
FE
CL




High Clutch Piston

NIAT0272S03

- Make sure check balls are not fixed.
- Apply compressed air to check ball oil hole opposite the return spring. Make sure there is no air leakage.
- Apply compressed air to oil hole on return spring side to make sure air leaks past ball.

AT
AX
SU
BR



Seal Ring Clearance

NIAT0272S04

- Install new seal rings onto input shaft.
- Measure clearance between seal ring and ring groove.

Standard clearance:


0.08 - 0.23 mm (0.0031 - 0.0091 in)

Allowable limit:

0.23 mm (0.0091 in)

- If not within wear limit, replace input shaft assembly.

ST
RS
BT
HA



ASSEMBLY


NIAT0273

1. Install D-ring and oil seal on piston.
- **Take care with the direction of the oil seal.**
 - **Apply ATF to both parts.**


SC
EL
IDX

REPAIR FOR COMPONENT PARTS


High Clutch (Cont'd)




2. Install piston assembly by turning it slowly.
 - Apply ATF to inner surface of drum.




3. Install return springs and spring retainer on piston.
Return spring:
Refer to "Clutch and Brake Return Spring", AT-544.



4. Set Tool on spring retainer and install snap ring while compressing return springs.
 - Set Tool directly above return springs.




- Do not align snap ring gap with spring retainer stopper.



5. Install drive plates, driven plates and retaining plate.
Take care with the order and direction of plates.
6. Install snap ring.

REPAIR FOR COMPONENT PARTS

High Clutch (Cont'd)



7. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard: 1.4 - 1.8 mm (0.055 - 0.071 in)

Allowable limit: 2.4 mm (0.094 in)

Retaining plate:


Refer to "HIGH CLUTCH", AT-543.

GI

MA

EM

LC




8. Check operation of high clutch. Refer to "High Clutch", AT-485.

EC

FE

CL

MT



9. Install seal rings to input shaft.


- **Apply petroleum jelly to seal rings.**

AT

AX

SU

BR



- **Roll paper around seal rings to prevent seal rings from spreading.**

ST

RS

BT

HA

SC

EL




IDX

REPAIR FOR COMPONENT PARTS

Forward Clutch and Overrun Clutch

Forward Clutch and Overrun Clutch COMPONENTS

NIAT0274




DISASSEMBLY

NIAT0275

1. Check operation of forward clutch and overrun clutch.
 - a. Install bearing retainer on forward clutch drum.
 - b. Apply compressed air to oil hole of forward clutch drum.
 - c. Check to see that retaining plate moves to snap ring.
- d. If retaining plate does not contact snap ring:
 - D-ring might be damaged.
 - Oil seal might be damaged.
 - Fluid might be leaking past piston check ball.

REPAIR FOR COMPONENT PARTS

Forward Clutch and Overrun Clutch (Cont'd)




2. Remove snap ring for forward clutch.
3. Remove drive plates, driven plates, retaining plate and dish plate for forward clutch.

GI

MA

EM

LC




4. Remove snap ring for overrun clutch.
5. Remove drive plates, driven plates, retaining plate and dish plate for overrun clutch.

EC

FE

CL

MT



6. Set Tool on spring retainer and remove snap ring from forward clutch drum while compressing return springs.

AT


- **Set Tool directly above return springs.**
- **Do not expand snap ring excessively.**

AX

7. Remove spring retainer and return springs.

SU

BR




8. Remove forward clutch piston with overrun clutch piston from forward clutch drum by turning it.

ST

RS

BT

HA



9. Remove overrun clutch piston from forward clutch piston by turning it.


SC

EL

IDX

REPAIR FOR COMPONENT PARTS

Forward Clutch and Overrun Clutch (Cont'd)



- Remove D-rings and oil seals from forward clutch piston and overrun clutch piston.


INSPECTION

Snap Rings and Spring Retainer

- Check for deformation, fatigue or damage.

NIAT0276

NIAT0276S01



Forward Clutch and Overrun Clutch Return Springs


NIAT0276S02

- Check for deformation or damage.
- Measure free length and outer diameter.

Inspection standard:

Refer to SDS, AT-544.

- Replace if deformed or fatigued.



Forward Clutch and Overrun Clutch Drive Plates

NIAT0276S03

- Check facing for burns, cracks or damage.
- Measure thickness of facing.

Thickness of drive plate:

Forward clutch

Standard value: 1.8 mm (0.071 in)

Wear limit: 1.6 mm (0.063 in)

Overrun clutch


Standard value: 1.6 mm (0.063 in)

Wear limit: 1.4 mm (0.055 in)

- If not within wear limit, replace.

REPAIR FOR COMPONENT PARTS

Forward Clutch and Overrun Clutch (Cont'd)



Forward Clutch and Overrun Clutch Dish Plates

NIAT0276S04

- Check for deformation or damage.
- Measure thickness of dish plate.

Thickness of dish plate "t":

Forward clutch: 2.5 mm (0.098 in)

Overrun clutch: 2.15 mm (0.0846 in)


- If deformed or fatigued, replace.

GI

MA

EM

LC



Forward Clutch Drum

NIAT0276S05


- Make sure check balls are not fixed.
- Apply compressed air to check ball oil hole from outside of forward clutch drum. Make sure air leaks past ball.
- Apply compressed air to oil hole from inside of forward clutch drum. Make sure there is no air leakage.

EC

FE

CL

MT



Overrun Clutch Piston

NIAT0276S06


- Make sure check balls are not fixed.
- Apply compressed air to check ball oil hole opposite the return spring. Make sure there is no air leakage.
- Apply compressed air to oil hole on return spring side. Make sure air leaks past ball.

AT

AX

SU

BR



ASSEMBLY

NIAT0277


1. Install D-rings and oil seals on forward clutch piston and overrun clutch piston.
 - Take care with direction of oil seal.
 - Apply ATF to both parts.

ST

RS

BT

HA



2. Install overrun clutch piston assembly on forward clutch piston while turning it slowly.
 - Apply ATF to inner surface of forward clutch piston.


SC

EL


IDX

REPAIR FOR COMPONENT PARTS


Forward Clutch and Overrun Clutch (Cont'd)




3. Install forward clutch piston assembly on forward clutch drum while turning it slowly.
 - **Apply ATF to inner surface of drum.**




4. Align notch in forward clutch piston with groove in forward clutch drum.



5. Install return spring on piston.
6. Install spring retainer on return springs.
Return spring:
Refer to "Clutch and Brake Return Spring", AT-544.








7. Set Tool on spring retainer and install snap ring while compressing return springs.
 - **Set Tool directly above return springs.**



- **Do not align snap ring gap with spring retainer stopper.**

REPAIR FOR COMPONENT PARTS

Forward Clutch and Overrun Clutch (Cont'd)



8. Install drive plates, driven plates, retaining plate and dish plate for overrun clutch.
9. Install snap ring for overrun clutch.

GI

MA

EM

LC

10. Measure clearance between overrun clutch retaining plate and snap ring.
If not within allowable limit, select proper retaining plate.

EC

Specified clearance:

Standard: 1.0 - 1.4 mm (0.039 - 0.055 in)

Allowable limit: 2.0 mm (0.079 in)

Overrun clutch retaining plate:

Refer to SDS, AT-543.

FE

CL

MT

11. Install drive plates, driven plates, retaining plate and dish plate for forward clutch.

Take care with the order and direction of plates.

12. Install snap ring for forward clutch.

AT

AX

SU

BR

13. Measure clearance between forward clutch retaining plate and snap ring.

If not within allowable limit, select proper retaining plate.

Specified clearance:

Standard: 0.45 - 0.85 mm (0.0177 - 0.0335 in)

Allowable limit: 1.85 mm (0.0728 in)

Forward clutch retaining plate:

Refer to "FORWARD CLUTCH", AT-543.

ST

RS

BT

HA

14. Check operation of forward clutch.

Refer to "Forward Clutch and Overrun Clutch", AT-490.


SC

EL

IDX

REPAIR FOR COMPONENT PARTS



Forward Clutch and Overrun Clutch (Cont'd)



15. Check operation of overrun clutch.
Refer to "Forward Clutch and Overrun Clutch", AT-490.

Low & Reverse Brake COMPONENTS


=NIAT0278




DISASSEMBLY

NIAT0279

1. Check operation of low & reverse brake.
 - a. Apply compressed air to oil hole of transmission case.
 - b. Check to see that retaining plate moves to snap ring.
 - c. If retaining plate does not contact snap ring:
 - D-ring might be damaged.
 - Oil seal might be damaged.
 - Fluid might be leaking past piston check ball.



2. Stand transmission case.
3. Remove snap ring.
4. Remove drive plates, driven plates, retaining plate from transmission case.



5. Set Tool on spring retainer and remove snap ring while compressing return springs.
 - **Set Tool directly above return springs.**
 - **Do not expand snap ring excessively.**
6. Remove spring retainer and return springs.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

REPAIR FOR COMPONENT PARTS


Low & Reverse Brake (Cont'd)



- Do not remove return springs from spring retainer.



7. Apply compressed air to oil hole of transmission case while holding piston.
8. Remove piston from transmission case by turning it.



9. Remove D-ring and oil seal from piston.

INSPECTION

Low & Reverse Clutch Snap Ring, Spring Retainer and Return Springs


NIAT0280

NIAT0280S01

- Check for deformation, fatigue or damage.
- Replace if necessary.
- When replacing spring retainer and return springs, replace them as a set.

REPAIR FOR COMPONENT PARTS

Low & Reverse Brake (Cont'd)



Low & Reverse Brake Drive Plates

NIAT0280S02


- Check facing for burns, cracks or damage.
- Measure thickness of facing.
Thickness of drive plate:
Standard value: 2.0 mm (0.079 in)
Wear limit: 1.8 mm (0.071 in)
- If not within wear limit, replace.

GI

MA

EM

LC



ASSEMBLY

NIAT0281


1. Install D-ring and oil seal on piston.
 - Take care with the direction of the oil seal.
 - Apply ATF to both parts.

EC

FE

CL

MT




2. Stand transmission case.
3. Install piston assembly on transmission case while turning it slowly.
 - Apply ATF to inner surface of transmission case.

AT

AX

SU

BR




4. Install return springs and spring retainer on piston.
Return spring:
Refer to "Clutch and Brake Return Spring", AT-544.

ST

RS

BT

HA



5. Install snap ring while compressing return springs.
 - Set Tool directly above return springs.


SC

EL


IDX

REPAIR FOR COMPONENT PARTS


Low & Reverse Brake (Cont'd)



6. Install drive plates, driven plates, retaining plates and dished plates.
 - Do not align the projections on the two dished plates.
 - Make sure to put the plates in the correct order and direction.



7. Install snap ring.



8. Measure clearance between retaining plate and snap ring. If not within allowable limit, select proper retaining plate (front side).

Specified clearance:


Standard: 1.4 - 1.8 mm (0.055 - 0.071 in)

Allowable limit:

2.8 mm (0.110 in)

Retaining plate:

Refer to "LOW AND REVERSE BRAKE", AT-544.



9. Check operation of low and reverse brake. Refer to "DISASSEMBLY", AT-497.


REPAIR FOR COMPONENT PARTS

Rear Internal Gear, Forward Clutch Hub and Overrun Clutch Hub

Rear Internal Gear, Forward Clutch Hub and Overrun Clutch Hub COMPONENTS

NIAT0282

SEC. 315



SAT875J


GI
MA
EM
LC
EC
FE
CL
MT

AT

AX

SU

BR



DISASSEMBLY

1. Remove snap ring from overrun clutch hub.
2. Remove overrun clutch hub from forward clutch hub.


NIAT0283

ST

RS

BT

HA



3. Remove thrust washer from forward clutch hub.


SC

EL


IDX

REPAIR FOR COMPONENT PARTS


Rear Internal Gear, Forward Clutch Hub and Overrun Clutch Hub (Cont'd)




4. Remove forward clutch hub from rear internal gear.




5. Remove end bearing from rear internal gear.



6. Remove thrust washer from rear internal gear.




7. Remove end bearing from forward one-way clutch.



8. Remove one-way clutch from forward clutch hub.

REPAIR FOR COMPONENT PARTS

Rear Internal Gear, Forward Clutch Hub and Overrun Clutch Hub (Cont'd)




INSPECTION

Rear Internal Gear, Forward Clutch Hub and Overrun Clutch Hub

NIAT0284
NIAT0284S01


- Check rubbing surfaces for wear or damage.



Snap Ring, End Bearings and Forward One-way Clutch

NIAT0284S02


- Check snap ring and end bearings for deformation and damage.
- Check forward one-way clutch for wear and damage.




ASSEMBLY

NIAT0285

1. Install forward one-way clutch on forward clutch.
 - Take care with the direction of forward one-way clutch.



2. Install end bearing on forward one-way clutch.
 - Apply petroleum jelly to end bearing.




3. Install thrust washer on rear internal gear.
 - Apply petroleum jelly to thrust washer.
 - Align pawls of thrust washer with holes of rear internal gear.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REPAIR FOR COMPONENT PARTS


Rear Internal Gear, Forward Clutch Hub and Overrun Clutch Hub (Cont'd)




4. Install end bearing on rear internal gear.
 - Apply petroleum jelly to end bearing.




5. Install forward clutch hub on rear internal gear.
 - Check operation of forward one-way clutch. Hold rear internal gear and turn forward clutch hub. Check forward clutch hub for correct locking and unlocking directions.
 - If not as shown in illustration, check installation direction of forward one-way clutch.



6. Install thrust washer and overrun clutch hub.
 - Apply petroleum jelly to thrust washer.
 - Align pawls of thrust washer with holes of overrun clutch hub.



7. Install overrun clutch hub on rear internal gear.
 - Align projections of rear internal gear with holes of overrun clutch hub.



8. Install snap ring to groove of rear internal gear.

REPAIR FOR COMPONENT PARTS

Output Shaft, Idler Gear, Reduction Pinion Gear and Bearing Retainer

Output Shaft, Idler Gear, Reduction Pinion Gear and Bearing Retainer COMPONENTS

NIAT0286

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX

SEC. 314



SAT487JA




DISASSEMBLY

NIAT0287


1. Remove seal rings from output shaft and bearing retainer.

REPAIR FOR COMPONENT PARTS


Output Shaft, Idler Gear, Reduction Pinion Gear and Bearing Retainer (Cont'd)




2. Remove output shaft bearing with screwdrivers.
 - Always replace bearing with a new one when removed.
 - Do not damage output shaft.




3. Remove snap ring from bearing retainer.



4. Remove needle bearing from bearing retainer.




5. Remove idler gear bearing inner race from idler gear.




6. Remove idler gear bearing outer race from transmission case.

REPAIR FOR COMPONENT PARTS

Output Shaft, Idler Gear, Reduction Pinion Gear and Bearing Retainer (Cont'd)



- Press out reduction pinion gear bearing from reduction pinion gear.




- Remove reduction pinion gear bearing outer race from transmission case.

INSPECTION

Output Shaft, Idler Gear and Reduction Pinion Gear


NIAT0288
NIAT0288S01

- Check shafts for cracks, wear or bending.
- Check gears for wear, chips and cracks.



Bearing

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- When replacing taper roller bearing, replace outer and inner race as a set.**



Seal Ring Clearance

- Install new seal rings to output shaft.
- Measure clearance between seal ring and ring groove of output shaft.

Standard clearance:

0.10 - 0.25 mm (0.0039 - 0.0098 in)

Allowable limit:

0.25 mm (0.0098 in)

- If not within allowable limit, replace output shaft.
- Install new seal rings to bearing retainer.

GI
MA
EM
LC
EC
FE
CL
MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

REPAIR FOR COMPONENT PARTS

Output Shaft, Idler Gear, Reduction Pinion Gear and Bearing Retainer (Cont'd)

- Measure clearance between seal ring and ring groove of bearing retainer.





Standard clearance:

0.10 - 0.25 mm (0.0039 - 0.0098 in)

Allowable limit:

0.25 mm (0.0098 in)

- If not within allowable limit, replace bearing retainer.



ASSEMBLY

1. Press reduction pinion gear bearing on reduction pinion gear. NIAT0289


2. Install reduction pinion gear bearing outer race on transmission case.

3. Press idler gear bearing inner race on idler gear.


4. Install idler gear bearing outer race on transmission case.

REPAIR FOR COMPONENT PARTS


Output Shaft, Idler Gear, Reduction Pinion Gear and Bearing Retainer (Cont'd)




5. Press output shaft bearing on output shaft.



6. Press needle bearing on bearing retainer.




7. Install snap ring to bearing retainer.



8. After packing ring grooves with petroleum jelly, carefully install new seal rings on output shaft and bearing retainer.

NOTE:
Do not align gaps in seal rings.



● Roll paper around seal rings to prevent seal rings from spreading.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

REPAIR FOR COMPONENT PARTS

Band Servo Piston Assembly

Band Servo Piston Assembly COMPONENTS


NIAT0290



DISASSEMBLY


NIAT0291

1. Remove band servo piston snap ring.



2. Apply compressed air to oil hole in transmission case to remove OD servo piston retainer and band servo piston assembly.

- Hold band servo piston assembly with a rag or nylon waste.




3. Apply compressed air to oil hole in OD servo piston retainer to remove OD servo piston from retainer.


- Hold OD servo piston while applying compressed air.

REPAIR FOR COMPONENT PARTS


Band Servo Piston Assembly (Cont'd)




4. Remove D-ring from OD servo piston.




5. Remove O-rings from OD servo piston retainer.



6. Remove band servo piston assembly from servo piston retainer by pushing it forward.



7. Place piston stem end on a wooden block. While pushing servo piston spring retainer down, remove E-ring.



8. Remove OD servo return spring, band servo thrust washer and band servo piston stem from band servo piston.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

REPAIR FOR COMPONENT PARTS


Band Servo Piston Assembly (Cont'd)



9. Remove O-rings from servo piston retainer.



10. Remove D-rings from band servo piston.




INSPECTION

Pistons, Retainers and Piston Stem

- Check frictional surfaces for abnormal wear or damage.

NIAT0292

NIAT0292S01




Return Springs

- Check for deformation or damage.
- Measure free length and outer diameter.

Band servo inspection standard:
Refer to "Band Servo", AT-549.

NIAT0292S02




ASSEMBLY

1. Install D-rings to band servo piston retainer.
 - Apply ATF to D-rings.
 - Pay attention to position of each D-ring.

NIAT0293

REPAIR FOR COMPONENT PARTS

Band Servo Piston Assembly (Cont'd)




2. Install band servo piston stem, band servo thrust washer, OD servo return spring and spring retainer to band servo piston.

GI

MA

EM

LC




3. Place piston stem end on a wooden block. While pushing servo piston spring retainer down, install E-ring.

EC

FE

CL

MT




4. Install O-rings to servo piston retainer.
 - Apply ATF to O-rings.
 - Pay attention to the positions of the O-rings.

AT

AX

SU

BR




5. Install band servo piston assembly to servo piston retainer by pushing it inward.

ST

RS

BT

HA



6. Install D-ring to OD servo piston.
 - Apply ATF to D-ring.


SC

EL


IDX

REPAIR FOR COMPONENT PARTS


Band Servo Piston Assembly (Cont'd)




7. Install O-rings to OD servo piston retainer.
 - Apply ATF to O-rings.
 - Pay attention to the positions of the O-rings.




8. Install OD servo piston to OD servo piston retainer.



9. Install band servo piston assembly and 2nd servo return spring to transmission case.
 - Apply ATF to O-ring of band servo piston and transmission case.




10. Install OD servo piston assembly to transmission case.
 - Apply ATF to O-ring of band servo piston and transmission case.




11. Install band servo piston snap ring to transmission case.

Final Drive COMPONENTS

NIAT0294



GI
MA
EM
LC
EC
FE
CL
MT




DISASSEMBLY


1. Remove final gear.

NIAT0295

AT




2. Press out differential side bearings.




AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REPAIR FOR COMPONENT PARTS


Final Drive (Cont'd)



3. Remove speedometer drive gear.




4. Drive out pinion mate shaft lock pin.



5. Draw out pinion mate shaft from differential case.

6. Remove pinion mate gears and side gears.




INSPECTION

Gear, Washer, Shaft and Case

NIAT0296

NIAT0296S01


- Check mating surfaces of differential case, side gears and pinion mate gears.
- Check washers for wear.



Bearings

NIAT0296S03

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- **When replacing taper roller bearing, replace outer and inner race as a set.**




ASSEMBLY

NIAT0297

1. Install side gear and thrust washers in differential case.
2. Install pinion mate gears and thrust washers in differential case while rotating them.
 - **When inserting, be careful not to damage pinion mate gear washers.**
 - **Apply ATF to any parts.**

GI
MA
EM




3. Measure clearance between side gear and differential case with washers using the following procedure.
 - a. Set Tool and dial indicator on side gear.
 - b. Move side gear up and down to measure dial indicator deflection. Always measure indicator deflection on both side gears.

LC
EC
FE

Clearance between side gear and differential case with washers:

0.1 - 0.2 mm (0.004 - 0.008 in)

CL
MT




- c. If not within specification adjust clearance by changing thickness of side gear thrust washers.

Side gear thrust washer:


Refer to SDS, AT-545.

AT
AX



4. Install lock pin.
 - **Make sure that lock pin is flush with case.**

SU
BR
ST




5. Install speedometer drive gear on differential case.
 - **Align the projection of speedometer drive gear with the groove of differential case.**

RS
BT
HA


SC
EL
IDX

REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)



6. Install final gear and tighten fixing bolts in numerical order.
⚙️ : 113 - 127 N-m (11.5 - 13.0 kg-m, 83 - 94 ft-lb)




7. Press on differential side bearings.

ASSEMBLY


Assembly (1)

NIAT0298




Assembly (1)

1. Install revolution sensor onto transmission case.
Always use new sealing parts.




2. Install differential side oil seals on transmission case and converter housing, so that "A" and "B" are within specifications.




Unit: mm (in)

A	B
5.5 - 6.5 (0.217 - 0.256)	-0.5 to 0.5 (-0.020 to 0.020)



3. Install parking actuator support to transmission case.
● **Pay attention to direction of parking actuator support.**




4. Install parking pawl on transmission case and fix it with parking shaft.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

ASSEMBLY

Assembly (1) (Cont'd)



5. Install return spring.




Adjustment (1)

DIFFERENTIAL SIDE BEARING PRELOAD


NIAT0299

NIAT0299S01

1. Install differential side bearing outer race without adjusting shim on transmission case.
2. Install differential side bearing outer race on converter housing.



3. Place final drive assembly on transmission case.
4. Install transmission case on converter housing. Tighten transmission case fixing bolts **A** and **B** to the specified torque.



5. Attach dial indicator on differential case at transmission case side.
6. Insert Tool into differential side gear from converter housing.
7. Move Tool up and down and measure dial indicator deflection.
8. Select proper thickness of differential side bearing adjusting shim(s) using SDS table as a guide.

Differential side bearing preload "T":






0.04 - 0.09 mm (0.0016 - 0.0035 in)

Differential side bearing adjusting shim:

Refer to "DIFFERENTIAL SIDE BEARING ADJUSTING SHIM", AT-545.

ASSEMBLY

Adjustment (1) (Cont'd)



9. Remove converter housing from transmission case.
 10. Remove final drive assembly from transmission case.
 11. Remove differential side bearing outer race from transmission case.
 12. Reinstall differential side bearing outer race and shim(s) selected from SDS table on transmission case.
 13. Reinstall converter housing on transmission case and tighten transmission case fixing bolts to the specified torque.
14. Insert Tool into differential case and measure turning torque of final drive assembly.
 - Turn final drive assembly in both directions several times to seat bearing rollers correctly.
 - Turning torque of final drive assembly (New bearing): **0.49 - 1.08 N-m (5.0 - 11.0 kg-cm, 4.3 - 9.5 in-lb)**
 - When old bearing is used again, turning torque will be slightly less than the above.
 - Make sure torque is within the specified range.

REDUCTION PINION GEAR BEARING PRELOAD

NIAT0299S02

- Be sure to remove final drive assembly before doing this procedure.
- Using caliper and straightedge, calculate a dimension "T" (adjuster shim thickness) in the left figure by the following formula. And adjust the inspection standard for pre-load (rotating slide torque) as shown below.

$$T = A - E$$

Inspection standard for preload:

$$0.1 - 0.69 \text{ N-m (1.1 - 7.0 kg-cm, 0.95 - 6.08 in-lb)}$$

1. Remove transmission case and final drive assembly from converter housing.
2. Select proper thickness of reduction pinion gear bearing adjusting shim using the following procedures.
 - a. Place reduction pinion gear on transmission case as shown.
- b. Place idler gear bearing on transmission case.
- c. Measure dimensions "B", "C" and "D" and calculate dimension "A".

$$A = D - (B + C)$$

"A": Distance between the surface of idler gear bearing inner race and the adjusting shim mating surface of reduction pinion gear.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

ASSEMBLY


Adjustment (1) (Cont'd)



- Measure dimension "B" between the end of reduction pinion gear and the surface of transmission case.
- **Measure dimension "B" in at least two places.**




- Measure dimension "C" between the surface of idler gear bearing inner race and the surface of transmission case.
- **Measure dimension "C" in at least two places.**



- Measure dimension "D" between the end of reduction pinion gear and the adjusting shim mating surface of reduction pinion gear.
- **Measure dimension "D" in at least two places.**
- Calculate dimension "A".

$$A = D - (B + C)$$



- d. Measure dimension "E" between the end of idler gear and the idler gear bearing inner race mating surface of idler gear.
- **Measure dimension "E" in at least two places.**

- e. Calculate "T" and select proper thickness of reduction pinion gear bearing adjusting shim using SDS table as a guide.

$$T = A - E - 0.05 \text{ mm (0.0020 in)*}$$


Reduction pinion gear bearing adjusting shim:

Refer to "REDUCTION PINION GEAR BEARING ADJUSTING SHIM", AT-547.


*: Bearing preload

ASSEMBLY


Adjustment (1) (Cont'd)




AAT696




SAT339D



SAT340DC



SAT341D



SAT347D

3. Install reduction pinion gear and reduction pinion gear bearing adjusting shim selected in step 2-e on transmission case using Tool.
4. Press idler gear bearing inner race on idler gear.
5. Press idler gear on reduction pinion gear.
 - **Press idler gear so that idler gear can be locked by parking pawl.**

6. Tighten idler gear lock nut to the specified torque.
 - **Lock idler gear with parking pawl when tightening lock nut.**

7. Measure turning torque of reduction pinion gear.
 - **When measuring turning torque, turn reduction pinion gear in both directions several times to seat bearing rollers correctly.**

Turning torque of reduction pinion gear:
0.1 - 0.69 N·m (1.1 - 7.0 kg-cm, 0.95 - 6.08 in-lb)

OUTPUT SHAFT END PLAY

NIAT0299S03


- Measure clearance between side cover and the end of the output shaft bearing.
- Select proper thickness of adjusting shim so that clearance is within specifications.

1. Install bearing retainer for output shaft.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

ASSEMBLY


Adjustment (1) (Cont'd)



2. Install output shaft thrust needle bearing on bearing retainer.



3. Install output shaft on transmission case.




4. Measure dimensions " l_1 " and " l_2 " at side cover and then calculate dimension "A".

- Measure dimension " l_1 " and " l_2 " in at least two places
"A": Distance between transmission case fitting surface and adjusting shim mating surface

$$A = l_1 - l_2$$

l_2 : Height of gauge




5. Measure dimensions " l_2 " and " l_3 " and then calculate dimension "B".

Measure " l_2 " and " l_3 " in at least two places.

"B": Distance between the end of output shaft bearing outer race and the side cover fitting surface of transmission case

$$B = l_2 - l_3$$

l_2 : Height of gauge



6. Select proper thickness of adjusting shim so that output shaft end play (clearance between side cover and output shaft bearing) is within specifications.

Output shaft end play (A - B):

0 - 0.5 mm (0 - 0.020 in)


Output shaft end play adjusting shim:

Refer to "Output Shaft", AT-548.


7. Install adjusting shim on output shaft bearing.

ASSEMBLY


Adjustment (1) (Cont'd)



8. Apply locking sealant (Loctite 5/8 or equivalent) to transmission case as shown in illustration.




9. Install side cover on transmission case.
 - Apply locking sealant to the mating surface of transmission case.



10. Tighten side cover fixing bolts to specified torque.


: 26 - 30 N-m (2.7 - 3.1 kg-m, 20 - 22 ft-lb)

- Do not mix bolts A and B.
- Always replace bolts A as they are self-sealing bolts.



Assembly (2)

1. Remove paper rolled around bearing retainer.
2. Install thrust washer on bearing retainer.
 - Apply petroleum jelly to thrust washer.



3. Install forward clutch assembly.
 - Align teeth of low & reverse brake drive plates before installing.
 - Make sure that bearing retainer seal rings are not spread.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

ASSEMBLY


Assembly (2) (Cont'd)




4. Install thrust needle bearing on bearing retainer.
 - Apply petroleum jelly to thrust bearing.
 - Pay attention to direction of thrust needle bearing.




5. Install thrust needle bearing on rear internal gear.
 - Apply petroleum jelly to thrust needle bearing.
 - Pay attention to direction of thrust needle bearing.



6. Hold forward clutch hub and turn overrun clutch hub. Check overrun clutch hub for directions of lock and unlock.
 - If not as shown in illustration, check installed direction of forward one-way clutch.




7. Install rear internal gear assembly.
 - Align teeth of forward clutch and overrun clutch drive plate.




8. Install needle bearing on rear planetary carrier.
 - Apply petroleum jelly to needle bearing.
 - Pay attention to direction of needle bearing.

ASSEMBLY


Assembly (2) (Cont'd)




9. Install rear sun gear on rear planetary carrier.
 - **Pay attention to direction of rear sun gear.**




10. Install rear planetary carrier on transmission case.



11. Install thrust needle bearing on front planetary carrier.
 - **Apply petroleum jelly to thrust needle bearing.**
 - **Pay attention to direction of thrust needle bearing.**



12. Install low one-way clutch to front planetary carrier by turning it in the direction of the arrow as shown.
13. While holding front planetary carrier, turn low one-way clutch. Check low one-way clutch for correct directions of lock and unlock.



14. Install front planetary carrier assembly on transmission case.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

ASSEMBLY


Assembly (2) (Cont'd)




15. Install snap ring with screwdriver.
- **Forward clutch and bearings must be correctly installed for snap ring to fit groove of transmission case.**




16. Install needle bearing on front sun gear.
- **Apply petroleum jelly to needle bearing.**
 - **Pay attention to direction of needle bearing.**



17. Install front sun gear on front planetary carrier.




18. Install needle bearing on front sun gear.
- **Apply petroleum jelly to needle bearing.**
 - **Pay attention to direction of needle bearing.**




19. Install high clutch hub on front sun gear.

ASSEMBLY


Assembly (2) (Cont'd)



20. Install needle bearing on high clutch hub.
- Apply petroleum jelly to needle bearing.
 - Pay attention to direction of needle bearing.



21. Remove paper rolled around input shaft.
22. Install input shaft assembly.
- Align teeth of high clutch drive plates before installing.



23. Install reverse clutch assembly.
- Align teeth of reverse clutch drive plates before installing.

Adjustment (2)

NIAT0301

When any parts listed below are replaced, adjust total end play and reverse clutch end play.

Part name	Total end play	Reverse clutch end play
Transmission case	●	●
Overrun clutch hub	●	●
Rear internal gear	●	●
Rear planetary carrier	●	●
Rear sun gear	●	●
Front planetary carrier	●	●
Front sun gear	●	●
High clutch hub	●	●
High clutch drum	●	●
Oil pump cover	●	●
Reverse clutch drum	—	●

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA






SC

EL

IDX

ASSEMBLY

Adjustment (2) (Cont'd)



TOTAL END PLAY

NIAT0301S01

- Measure clearance between reverse clutch drum and needle bearing for oil pump cover.
- Select proper thickness of bearing race so that end play is within specifications.

1. Measure dimensions "K" and "L" and then calculate dimension "J".

- a. Measure dimension "K".

- b. Measure dimension "L".
- c. Calculate dimension "J".


"J": Distance between oil pump fitting surface of transmission case and needle bearing mating surface of high clutch drum

$$J = K - L$$

2. Measure dimension "M".
 - a. Place bearing race and needle bearing on oil pump assembly.

ASSEMBLY

Adjustment (2) (Cont'd)




- b. Measure dimension "M".
"M": Distance between transmission case fitting surface and needle bearing on oil pump cover
"M₁": Indication of gauge

GI

MA

EM

LC



- c. Measure thickness of straightedge "t".
 $M = M_1 - t$

EC

FE

CL

MT

3. Adjust total end play "T₃".

$$T_3 = J - M$$

Total end play "T₃":

$$0.25 - 0.55 \text{ mm } (0.0098 - 0.0217 \text{ in})$$

- Select proper thickness of bearing race so that total end play is within specifications.


Bearing races: Refer to "Total End Play", AT-549.

AT

AX

SU

BR



REVERSE CLUTCH END PLAY

NIAT0301S02


- Measure clearance between oil pump cover and thrust washer for reverse clutch drum.
- Select proper thickness of thrust washer so that end play is within specifications.

ST

RS

BT

HA



1. Measure dimensions "O" and "P" and then calculate dimension "N".


SC

EL


IDX

ASSEMBLY

Adjustment (2) (Cont'd)




- a. Place thrust washer on reverse clutch drum.
- b. Measure dimension "O".




- c. Measure dimension "P".
- d. Calculate dimension "N".
"N": Distance between oil pump fitting surface of transmission case and thrust washer on reverse clutch drum


$$N = O - P$$



2. Measure dimensions "R" and "S" and then calculate dimension "Q".



- a. Measure dimension "R".



- b. Measure dimension "S".
- c. Calculate dimension "Q".
"Q": Distance between transmission case fitting surface and thrust washer mating surface

$$Q = R - S$$

ASSEMBLY

Adjustment (2) (Cont'd)

- Adjust reverse clutch end play "T₄".





$$T_4 = N - Q$$

Reverse clutch end play:

0.65 - 1.00 mm (0.0256 - 0.0394 in)

- Select proper thickness of thrust washer so that reverse clutch end play is within specifications.

Thrust washer: Refer to "Reverse Clutch End Play", AT-549.



Assembly (3)

NIAT0302

- Remove reverse clutch assembly and install needle bearing on high clutch assembly.

- Pay attention to direction of needle bearing.

- Install reverse clutch assembly.

- Install anchor end pin and lock nut on transmission case.

- Place brake band on outside of reverse clutch drum. Tighten anchor end pin just enough so that brake band is evenly fitted on reverse clutch drum.

- Place bearing race selected in total end play adjustment step on oil pump cover.

- Apply petroleum jelly to bearing race.

- Place thrust washer selected in reverse clutch end play step on reverse clutch drum.

- Apply petroleum jelly to thrust washer.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

ASSEMBLY


Assembly (3) (Cont'd)




7. Install oil pump assembly on transmission case.




8. Tighten oil pump fixing bolts to specified torque.

 : 18 - 21 N-m (1.8 - 2.1 kg-m, 13 - 15 ft-lb)



9. Install O-ring to input shaft.


- **Apply ATF to O-ring.**




10. Adjust brake band.

a. Tighten anchor end pin to specified torque.

Anchor end pin:


 : 3.9 - 5.9 N-m (0.4 - 0.6 kg-m, 35 - 52 in-lb)




b. Back off anchor end pin two and a half turns.

ASSEMBLY


Assembly (3) (Cont'd)



c. While holding anchor end pin, tighten lock nut.



11. Apply compressed air to oil holes of transmission case and check operation of brake band.




Assembly (4)

1. Install final drive assembly on transmission case.

NIAT0303

AT



2. Install oil tube on converter housing.

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX


ASSEMBLY

Assembly (4) (Cont'd)




3. Install O-ring on differential oil port of transmission case.
4. Install converter housing on transmission case.
- **Apply locking sealant to mating surface of converter housing.**


Bolt	Length mm (in)
A	32.8 (1.291)
B	40 (1.57)



5. Install accumulator piston.
 - a. Check contact surface of accumulator piston for damage.




- b. Install O-rings on accumulator piston.
 - Apply ATF to O-rings.
 - Accumulator piston O-rings:**
Refer to "Accumulator", AT-549.





- c. Install accumulator pistons and return springs on transmission case.
 - **Apply ATF to inner surface of transmission case.**
Return springs:
Refer to "Accumulator", AT-549.

ASSEMBLY


Assembly (4) (Cont'd)



6. Install lip seals for band servo oil holes on transmission case.
 - Apply petroleum jelly to lip seals.



7. Install control valve assembly.
 - a. Insert manual valve into control valve assembly.
 - Apply ATF to manual valve.



- b. Pass solenoid harness through transmission case and install terminal body on transmission case by pushing it.
 - c. Install stopper ring to terminal body.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

ASSEMBLY


Assembly (4) (Cont'd)




d. Tighten bolts A, B and C.

 : 7 - 9 N·m (0.7 - 0.9 kg-m, 61 - 78 in-lb)


Bolt length, number and location

Bolt symbol	A	B	C
Bolt length "ℓ" 	40.0 mm (1.575 in)	33.0 mm (1.299 in)	43.5 mm (1.713 in)
Number of bolts	5	6	2



8. Install oil pan.

a. Attach magnet to oil pan.




b. Install new oil pan gasket on transmission case.

c. Install oil pan on transmission case.

- **Always replace oil pan bolts as they are self-sealing bolts.**
- **Tighten the bolts in a criss-cross pattern to prevent dislocation of gasket.**

d. Tighten drain plug to specified torque.



9. Install PNP switch.


a. Set manual shaft in "P" position.

b. Temporarily install PNP switch on manual shaft.

c. Move selector lever to "N" position.


ASSEMBLY

Assembly (4) (Cont'd)




- d. Use a 4 mm (0.157 in) pin for this adjustment.
 - 1) Insert the pin straight into the manual shaft adjustment hole.
 - 2) Rotate PNP switch until the pin can also be inserted straight into hole in PNP switch.
- e. Tighten PNP switch fixing bolts.
- f. Remove pin from adjustment hole after adjusting PNP switch.

GI
MA
EM




10. Install oil charging pipe and oil cooler tube to transmission case.

LC
EC
FE
CL
MT




11. Install torque converter.
 - a. Pour ATF into torque converter.
 - **Approximately 1 liter (1-1/8 US qt, 7/8 Imp qt) of fluid is required for a new torque converter.**
 - **When reusing old torque converter, add the same amount of fluid as was drained.**

AT
AX
SU
BR



- b. Install torque converter while aligning notches of torque converter with notches of oil pump.

ST
RS
BT
HA



- c. Measure distance "A" to check that torque converter is in proper position.

Distance "A":

15.9 mm (0.626 in) or more

SC
EL
IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

General Specifications

NIAT0304

Engine	QG18DE		SR20DE
Automatic transaxle model	RE4F03B		
Automatic transaxle assembly	Model code number	3AX60	3AX11
Transaxle gear ratio	1st	2.861	
	2nd	1.562	
	3rd	1.000	
	4th	0.698	
	Reverse	2.310	
	Final drive	3.827	4.072
Recommended fluid	Nissan Matic "D" (Continental U.S. and Alaska) or Genuine Nissan Automatic Transmission Fluid (Canada)*1		
Fluid capacity	7.0ℓ (7-3/8 US qt, 6-1/8 Imp qt)		

*1: Refer to **MA-13**, "Fluids and Lubricants".

Shift Schedule

NIAT0305

VEHICLE SPEED WHEN SHIFTING GEARS QG18DE (Calif. CA Model)

NIAT0305S01

Throttle position	Shift pattern	Vehicle speed km/h (MPH)						
		D ₁ → D ₂	D ₂ → D ₃	D ₃ → D ₄	D ₄ → D ₃	D ₃ → D ₂	D ₂ → D ₁	1 ₂ → 1 ₁
Full throttle	Comfort	54 - 62 (34 - 39)	103 - 111 (64 - 69)	163 - 171 (101 - 106)	159 - 167 (99 - 104)	93 - 101 (58 - 63)	41 - 49 (25 - 30)	54 - 62 (34 - 39)
Half throttle	Comfort	32 - 40 (20 - 25)	60 - 68 (37 - 42)	124 - 132 (77 - 82)	70 - 78 (43 - 48)	35 - 43 (22 - 27)	25 - 33 (16 - 21)	54 - 62 (34 - 39)

SR20DE

Throttle position	Shift pattern	Vehicle speed km/h (MPH)						
		D ₁ → D ₂	D ₂ → D ₃	D ₃ → D ₄	D ₄ → D ₃	D ₃ → D ₂	D ₂ → D ₁	1 ₂ → 1 ₁
Full throttle	Comfort	51 - 59 (32 - 37)	97 - 105 (60 - 65)	153 - 161 (95 - 100)	149 - 157 (93 - 98)	87 - 95 (54 - 59)	41 - 49 (25 - 30)	51 - 59 (32 - 37)
Half throttle	Comfort	33 - 41 (21 - 25)	58 - 66 (36 - 41)	121 - 129 (75 - 80)	72 - 80 (45 - 50)	34 - 42 (21 - 26)	9 - 17 (6 - 11)	51 - 59 (32 - 37)

QG18DE (Except Calif. CA Model)

Throttle position	Shift pattern	Vehicle speed km/h (MPH)						
		D ₁ → D ₂	D ₂ → D ₃	D ₃ → D ₄	D ₄ → D ₃	D ₃ → D ₂	D ₂ → D ₁	1 ₂ → 1 ₁
Full throttle	Comfort	52 - 60 (32 - 37)	100 - 108 (62 - 67)	158 - 166 (98 - 103)	154 - 162 (96 - 101)	70 - 98 (56 - 61)	41 - 49 (25 - 30)	52 - 60 (32 - 37)
Half throttle	Comfort	31 - 39 (19 - 24)	58 - 66 (36 - 41)	119 - 127 (74 - 79)	68 - 76 (42 - 47)	34 - 42 (21 - 26)	24 - 32 (15 - 20)	52 - 60 (32 - 37)

SERVICE DATA AND SPECIFICATIONS (SDS)

Shift Schedule (Cont'd)

VEHICLE SPEED WHEN PERFORMING LOCK-UP QG18DE (Calif. CA Model)

NIAT0305S02

Throttle opening	OD switch	Shift pattern	Vehicle speed km/h (MPH)	
			Lock-up ON	Lock-up OFF
2/8	ON (D ₄)	Comfort	97 - 105 (60 - 65)	63 - 71 (39 - 44)
	OFF (D ₃)	Comfort	86 - 94 (53 - 58)	83 - 91 (52 - 57)

SR20DE

Throttle opening	OD switch	Shift pattern	Vehicle speed km/h (MPH)	
			Lock-up ON	Lock-up OFF
2/8	ON (D ₄)	Comfort	105 - 113 (65 - 70)	74 - 82 (46 - 51)
	OFF (D ₃)	Comfort	86 - 94 (53 - 58)	83 - 91 (52 - 57)

QG18DE (Except Calif. CA Model)

Throttle opening	OD switch	Shift pattern	Vehicle speed km/h (MPH)	
			Lock-up ON	Lock-up OFF
2/8	ON (D ₄)	Comfort	94 - 102 (58 - 63)	61 - 69 (38 - 43)
	OFF (D ₃)	Comfort	86 - 94 (53 - 58)	83 - 91 (52 - 57)

Stall Revolution

NIAT0306

Engine model	Stall revolution rpm
QG18DE	2,350 - 2,800
SR20DE	2,350 - 2,850

Line Pressure

NIAT0307

Engine speed rpm	Line pressure kPa (kg/cm ² , psi)			
	R position	D position	2 position	1 position
Idle	778 (7.9, 113)	500 (5.1, 73)	500 (5.1, 73)	500 (5.1, 73)
Stall	1,816 (18.5, 263)	1,167 (11.9, 169)	1,167 (11.9, 169)	1,167 (11.9, 169)

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Control Valves

Control Valves

NIAT0308

CONTROL VALVE AND PLUG RETURN SPRINGS

NIAT0308S01

Unit: mm (in)

	No.	Parts	Part No.*	Free length	Outer diameter
Upper body Refer to "Control Valve Upper Body", AT-474.	35	3-2 timing valve spring	31736-01X00	23.0 (0.906)	6.65 (0.2618)
	19	Cooler check valve spring	31742-3AX05	28.04 (1.1039)	7.15 (0.2815)
	23	Pilot valve spring	31742-3AX03	38.98 (1.5346)	8.9 (0.350)
	15	1-2 accumulator valve spring	31742-3AX00	20.5 (0.807)	6.95 (0.2736)
	28	1-2 accumulator piston spring	31742-3AX09	55.66 (2.1913)	19.5 (0.7677)
	33	1st reducing valve spring	31742-80X05	27.0 (1.063)	7.0 (0.276)
	2	Overrun clutch reducing valve spring	31742-80X06	37.5 (1.476)	7.0 (0.276)
	7	Torque converter relief valve spring	31742-3AX04	33.3 (1.3110)	9.0 (0.354)
	10	Torque converter clutch control valve spring	31742-3AX02	53.01 (2.0870)	6.5 (0.256)
Lower body Refer to "Control Valve Lower Body", AT-478.	34	Shuttle valve spring	31762-41X04	51.0 (2.0079)	5.65 (0.2224)
	18	Pressure regulator valve spring	31742-80X13	45.0 (1.772)	15.0 (0.591)
	23	Overrun clutch control valve spring	31762-80X00	21.7 (0.854)	7.0 (0.276)
	27	Accumulator control valve spring	31742-80X02	22.0 (0.866)	6.5 (0.256)
	29	Shift valve A spring	31762-80X00	21.7 (0.854)	7.0 (0.276)
	2	Shift valve B spring	31762-80X00	21.7 (0.854)	7.0 (0.276)
	11	Pressure modifier valve spring	31742-41X15	30.5 (1.201)	9.8 (0.386)
	7	Pressure modifier valve spring	31742-80X16	32.0 (1.260)	6.9 (0.272)
	—	Oil cooler relief valve spring	31872-31X00	17.02 (0.6701)	8.0 (0.315)
—	T/C pressure spring	31742-3AX07	9.0 (0.354)	7.3 (0.287)	

*: Always check with the Parts Department for the latest parts information.

Clutch, Brake and Brake Band

NIAT0309

REVERSE CLUTCH

NIAT0309S01

Number of drive plates		2
Number of driven plates		2
Drive plate thickness mm (in)	Standard	2.0 (0.079)
	Allowable limit	1.8 (0.071)
Clearance mm (in)	Standard	0.5 - 0.8 (0.020 - 0.031)
	Allowable limit	1.2 (0.047)
Thickness of retaining plates	Thickness mm (in)	Part number*
	4.4 (0.173)	31537-31X00
	4.6 (0.181)	31537-31X01
	4.8 (0.189)	31537-31X02
	5.0 (0.197)	31537-31X03
	5.2 (0.205)	31537-31X04

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Clutch, Brake and Brake Band (Cont'd)

HIGH CLUTCH

—NIAT0309S02

Number of drive plates		3	GI
Number of driven plates		5	
Drive plate thickness mm (in)	Standard	2.0 (0.079)	MA
	Allowable limit	1.8 (0.071)	
Clearance mm (in)	Standard	1.4 - 1.8 (0.055 - 0.071)	EM
	Allowable limit	2.4 (0.094)	
Thickness of retaining plates	Thickness mm (in)	Part number*	LC
	4.8 (0.189)	31537-32X05	
	5.0 (0.197)	31537-32X06	EC
	5.2 (0.205)	31537-32X07	
	5.4 (0.213)	31537-32X08	FE
	5.6 (0.220)	31537-32X09	
	5.8 (0.228)	31537-32X10	
6.0 (0.236)	31537-32X11		

*: Always check with the Parts Department for the latest parts information.

FORWARD CLUTCH

NIAT0309S03

Number of drive plates		5	CL
Number of driven plates		5	MT
Drive plate thickness mm (in)	Standard	1.8 (0.071)	AT
	Allowable limit	1.6 (0.063)	
Clearance mm (in)	Standard	0.45 - 0.85 (0.0177 - 0.0335)	AX
	Allowable limit	1.85 (0.0728)	
Thickness of retaining plate	Thickness mm (in)	Part number*	SU
	3.6 (0.142)	31537-31X60	
	3.8 (0.150)	31537-31X61	BR
	4.0 (0.157)	31537-31X62	
	4.2 (0.165)	31537-31X63	ST
	4.4 (0.173)	31537-31X64	
	4.6 (0.181)	31537-31X65	

*: Always check with the Parts Department for the latest parts information.

OVERRUN CLUTCH

NIAT0309S04

Number of drive plates		3	RS
Number of driven plates		4	BT
Drive plate thickness mm (in)	Standard	1.6 (0.063)	HA
	Allowable limit	1.4 (0.055)	
Clearance mm (in)	Standard	1.0 - 1.4 (0.039 - 0.055)	SC
	Allowable limit	2.0 (0.079)	
Thickness of retaining plate	Thickness mm (in)	Part number*	EL
	3.6 (0.142)	31567-31X79	
	3.8 (0.150)	31567-31X80	IDX
	4.0 (0.157)	31567-31X81	
	4.2 (0.165)	31567-31X82	
	4.4 (0.173)	31567-31X83	

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Clutch, Brake and Brake Band (Cont'd)

LOW & REVERSE BRAKE

NIAT0309S05

Number of drive plates		5
Number of driven plates		4 + 1
Drive plate thickness mm (in)	Standard	2.0 (0.079)
	Allowable limit	1.8 (0.071)
Clearance mm (in)	Standard	1.4 - 1.8 (0.055 - 0.071)
	Allowable limit	2.8 (0.110)
Thickness of retaining plate	Thickness mm (in)	Part number*
	3.6 (0.142)	31667-31X16
	3.8 (0.150)	31667-31X17
	4.0 (0.157)	31667-31X18
	4.2 (0.165)	31667-31X19
	4.4 (0.173)	31667-31X20
	4.6 (0.181)	31667-31X21

*: Always check with the Parts Department for the latest parts information.

BRAKE BAND

NIAT0309S06

Anchor end pin tightening torque	3.5 - 5.9 N·m (0.35 - 0.6 kg-m, 31 - 52 in-lb)
Number of returning revolutions for anchor end pin	2.5±0.125
Lock nut tightening torque	31 - 36 N·m (3.2 - 3.7 kg-m, 23 - 27 ft-lb)

Clutch and Brake Return Springs

NIAT0310
Unit: mm (in)

Parts		Free length	Outer diameter	Part number*
Forward clutch (Overrun clutch)	Outer (16 pcs)	26.6 (1.047)	10.6 (0.417)	31505-31X02
	Inner (16 pcs)	26.3 (1.035)	7.7 (0.303)	31505-31X03
Reverse clutch (16 pcs)		18.6 (0.732)	8.0 (0.315)	31505-31X00
High clutch (12 pcs)		19.7 (0.776)	11.1 (0.437)	31505-31X01
Low reverse brake (20 pcs)		25.1 (0.988)	7.6 (0.299)	31505-31X04

*: Always check with the Parts Department for the latest parts information.

Oil Pump

NIAT0311

Oil pump side clearance mm (in)		0.02 - 0.04 (0.0008 - 0.0016)
Thickness of inner gears and outer gears	Inner gear	
	Thickness mm (in)	Part number*
	9.99 - 10.00 (0.3933 - 0.3937)	31346-31X00
	9.98 - 9.99 (0.3929 - 0.3933)	31346-31X01
	9.97 - 9.98 (0.3925 - 0.3929)	31346-31X02
	Outer gear	
	Thickness mm (in)	Part number*
	9.99 - 10.00 (0.3933 - 0.3937)	31347-31X00
	9.98 - 9.99 (0.3929 - 0.3933)	31347-31X01
	9.97 - 9.98 (0.3925 - 0.3929)	31347-31X02
Clearance between oil pump housing and outer gear mm (in)	Standard	0.08 - 0.15 (0.0031 - 0.0059)
	Allowable limit	0.15 (0.0059)
Oil pump cover seal ring clearance mm (in)	Standard	0.1 - 0.25 (0.0039 - 0.0098)
	Allowable limit	0.25 (0.0098)

SERVICE DATA AND SPECIFICATIONS (SDS)

Input Shaft

*: Always check with the Parts Department for the latest parts information.

Input Shaft

NIAT0312
Unit: mm (in)

Input shaft seal ring clearance	Standard	0.08 - 0.23 (0.0031 - 0.0091)
	Allowable limit	0.23 (0.0091)

Planetary Carrier

NIAT0313
Unit: mm (in)

Clearance between planetary carrier and pin-ion washer	Standard	0.15 - 0.70 (0.0059 - 0.0276)
	Allowable limit	0.80 (0.0315)

Final Drive

DIFFERENTIAL SIDE GEAR CLEARANCE

NIAT0314

NIAT0314S01

Clearance between side gear and differential case with washer	0.1 - 0.2 mm (0.004 - 0.008 in)
---	---------------------------------

DIFFERENTIAL SIDE GEAR THRUST WASHERS

NIAT0314S02

Thickness mm (in)	Part number*
0.75 - 0.80 (0.0295 - 0.0315)	38424-D2111
0.80 - 0.85 (0.0315 - 0.0335)	38424-D2112
0.85 - 0.90 (0.0335 - 0.0354)	38424-D2113
0.90 - 0.95 (0.0354 - 0.0374)	38424-D2114
0.95 - 1.00 (0.0374 - 0.0394)	38424-D2115

*: Always check with the Parts Department for the latest parts information.

BEARING PRELOAD

NIAT0314S04

Differential side bearing preload "T"	0.04 - 0.09 mm (0.0016 - 0.0035 in)
---------------------------------------	-------------------------------------

TURNING TORQUE

NIAT0314S05

Turning torque of final drive assembly	0.49 - 1.08 N·m (5.0 - 11.0 kg·cm, 4.3 - 9.5 in·lb)
--	---

DIFFERENTIAL SIDE BEARING ADJUSTING SHIMS

NIAT0314S06

Thickness mm (in)	Part number*
0.40 (0.0157)	31499-21X07
0.44 (0.0173)	31499-21X08
0.48 (0.0189)	31499-21X09
0.52 (0.0205)	31499-21X10
0.56 (0.0220)	31499-21X11
0.60 (0.0236)	31499-21X12
0.64 (0.0252)	31499-21X13
0.68 (0.0268)	31499-21X14
0.72 (0.0283)	31499-21X15
0.76 (0.0299)	31499-21X16
0.80 (0.0315)	31499-21X17
0.84 (0.0331)	31499-21X18
0.88 (0.0346)	31499-21X19
0.92 (0.0362)	31499-21X20
1.44 (0.0567)	31499-21X21

*: Always check with the Parts Department for the latest parts information.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Final Drive (Cont'd)

TABLE FOR SELECTING DIFFERENTIAL SIDE BEARING ADJUSTING SHIMS

NIAT0314S08
Unit: mm (in)

Dial indicator deflection	Suitable shim(s)
0.31 - 0.35 (0.0122 - 0.0138)	0.40 (0.0157)
0.35 - 0.39 (0.0138 - 0.0154)	0.44 (0.0173)
0.39 - 0.43 (0.0154 - 0.0169)	0.48 (0.0189)
0.43 - 0.47 (0.0169 - 0.0185)	0.52 (0.0205)
0.47 - 0.51 (0.0185 - 0.0201)	0.56 (0.0220)
0.51 - 0.55 (0.0201 - 0.0217)	0.60 (0.0236)
0.55 - 0.59 (0.0217 - 0.0232)	0.64 (0.0252)
0.59 - 0.63 (0.0232 - 0.0248)	0.68 (0.0268)
0.63 - 0.67 (0.0248 - 0.0264)	0.72 (0.0283)
0.67 - 0.71 (0.0264 - 0.0280)	0.76 (0.0299)
0.71 - 0.75 (0.0280 - 0.0295)	0.80 (0.0315)
0.75 - 0.79 (0.0295 - 0.0311)	0.84 (0.0331)
0.79 - 0.83 (0.0311 - 0.0327)	0.88 (0.0346)
0.83 - 0.87 (0.0327 - 0.0343)	0.92 (0.0362)
0.87 - 0.91 (0.0343 - 0.0358)	0.48 (0.0189) + 0.48 (0.0189)
0.91 - 0.95 (0.0358 - 0.0374)	0.48 (0.0189) + 0.52 (0.0205)
0.95 - 0.99 (0.0374 - 0.0390)	0.52 (0.0205) + 0.52 (0.0205)
0.99 - 1.03 (0.0390 - 0.0406)	0.52 (0.0205) + 0.56 (0.0220)
1.03 - 1.07 (0.0406 - 0.0421)	0.56 (0.0220) + 0.56 (0.0220)
1.07 - 1.11 (0.0421 - 0.0437)	0.56 (0.0220) + 0.60 (0.0236)
1.11 - 1.15 (0.0437 - 0.0453)	0.60 (0.0236) + 0.60 (0.0236)
1.15 - 1.19 (0.0453 - 0.0469)	0.60 (0.0236) + 0.64 (0.0252)
1.19 - 1.23 (0.0469 - 0.0484)	0.64 (0.0252) + 0.64 (0.0252)
1.23 - 1.27 (0.0484 - 0.0500)	0.64 (0.0252) + 0.68 (0.0268)
1.27 - 1.31 (0.0500 - 0.0516)	0.68 (0.0268) + 0.68 (0.0268)
1.31 - 1.35 (0.0516 - 0.0531)	0.68 (0.0268) + 0.72 (0.0283)
1.35 - 1.39 (0.0531 - 0.0547)	1.44 (0.0567)
1.39 - 1.43 (0.0547 - 0.0563)	0.72 (0.0283) + 0.76 (0.0299)
1.43 - 1.47 (0.0563 - 0.0579)	0.76 (0.0299) + 0.76 (0.0299)
1.47 - 1.51 (0.0579 - 0.0594)	0.76 (0.0299) + 0.80 (0.0315)
1.51 - 1.55 (0.0594 - 0.0610)	0.80 (0.0315) + 0.80 (0.0315)
1.55 - 1.59 (0.0610 - 0.0626)	0.80 (0.0315) + 0.84 (0.0331)
1.59 - 1.63 (0.0626 - 0.0642)	0.84 (0.0331) + 0.84 (0.0331)
1.63 - 1.67 (0.0642 - 0.0657)	0.84 (0.0331) + 0.88 (0.0346)
1.67 - 1.71 (0.0657 - 0.0673)	0.88 (0.0346) + 0.88 (0.0346)
1.71 - 1.75 (0.0673 - 0.0689)	0.88 (0.0346) + 0.92 (0.0362)
1.75 - 1.79 (0.0689 - 0.0705)	0.92 (0.0362) + 0.92 (0.0362)
1.79 - 1.83 (0.0705 - 0.0720)	0.92 (0.0362) + 0.96 (0.0378)
1.83 - 1.87 (0.0720 - 0.0736)	0.96 (0.0378) + 0.96 (0.0378)
1.87 - 1.91 (0.0736 - 0.0752)	0.52 (0.0205) + 1.44 (0.0567)
1.91 - 1.95 (0.0752 - 0.0768)	0.56 (0.0220) + 1.44 (0.0567)

Reduction Pinion Gear

NIAT0315

BEARING PRELOAD

NIAT0315S01

Reduction pinion gear bearing preload	0.05 mm (0.0020 in)
---------------------------------------	---------------------

TURNING TORQUE

NIAT0315S02

Turning torque of reduction pinion gear	0.1 - 0.69 N·m (1.1 - 7.0 kg·cm, 0.95 - 6.08 in·lb)
---	---

SERVICE DATA AND SPECIFICATIONS (SDS)

Reduction Pinion Gear (Cont'd)

REDUCTION PINION GEAR BEARING ADJUSTING SHIMS

NIAT0315S03

Thickness mm (in)	Part number*	
1.74 (0.0685)	31438-31X16	GI
1.78 (0.0701)	31438-31X17	
1.82 (0.0717)	31438-31X18	MA
1.86 (0.0732)	31438-31X19	
1.90 (0.0748)	31438-31X20	
1.92 (0.0756)	31439-31X60	EM
1.94 (0.0764)	31438-31X21	
1.96 (0.0772)	31439-31X61	
1.98 (0.0780)	31438-31X22	
2.00 (0.0787)	31439-31X62	LC
2.02 (0.0795)	31438-31X23	
2.04 (0.0803)	31439-31X63	
2.06 (0.0811)	31438-31X24	
2.08 (0.0819)	31439-31X64	EC
2.10 (0.0827)	31438-31X60	
2.12 (0.0835)	31439-31X65	
2.14 (0.0843)	31438-31X61	FE
2.16 (0.0850)	31439-31X66	
2.18 (0.0858)	31438-31X62	
2.20 (0.0866)	31439-31X67	CL
2.22 (0.0874)	31438-31X63	
2.24 (0.0882)	31439-31X68	
2.26 (0.0890)	31438-31X64	
2.28 (0.0898)	31439-31X69	MT
2.30 (0.0906)	31438-31X65	
2.34 (0.0921)	31438-31X66	
2.38 (0.0937)	31438-31X67	
2.42 (0.0953)	31438-31X68	AT
2.46 (0.0969)	31438-31X69	
2.50 (0.0984)	31438-31X70	
2.54 (0.1000)	31438-31X71	AX
2.58 (0.1016)	31438-31X72	
2.62 (0.1031)	31438-31X73	
2.66 (0.1047)	31438-31X74	SU

*: Always check with the Parts Department for the latest parts information.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Reduction Pinion Gear (Cont'd)

TABLE FOR SELECTING REDUCTION PINION GEAR BEARING ADJUSTING SHIM

NIAT0315S04
Unit: mm (in)

Dimension "T"	Suitable shim(s)
1.77 - 1.81 (0.0697 - 0.0713)	1.74 (0.0685)
1.81 - 1.85 (0.0713 - 0.0728)	1.78 (0.0701)
1.85 - 1.89 (0.0728 - 0.0744)	1.82 (0.0717)
1.89 - 1.93 (0.0744 - 0.0760)	1.86 (0.0732)
1.93 - 1.96 (0.0760 - 0.0772)	1.90 (0.0748)
1.96 - 1.98 (0.0772 - 0.0780)	1.92 (0.0756)
1.98 - 2.00 (0.0780 - 0.0787)	1.94 (0.0764)
2.00 - 2.02 (0.0787 - 0.0795)	1.96 (0.0772)
2.02 - 2.04 (0.0795 - 0.0803)	1.98 (0.0780)
2.04 - 2.06 (0.0803 - 0.0811)	2.00 (0.0787)
2.06 - 2.08 (0.0811 - 0.0819)	2.02 (0.0795)
2.08 - 2.10 (0.0819 - 0.0827)	2.04 (0.0803)
2.10 - 2.12 (0.0827 - 0.0835)	2.06 (0.0811)
2.12 - 2.14 (0.0835 - 0.0843)	2.08 (0.0819)
2.14 - 2.16 (0.0843 - 0.0850)	2.10 (0.0827)
2.16 - 2.18 (0.0850 - 0.0858)	2.12 (0.0835)
2.18 - 2.20 (0.0858 - 0.0866)	2.14 (0.0843)
2.20 - 2.22 (0.0866 - 0.0874)	2.16 (0.0850)
2.22 - 2.24 (0.0874 - 0.0888)	2.18 (0.0858)
2.24 - 2.26 (0.0882 - 0.0890)	2.20 (0.0866)
2.26 - 2.28 (0.0890 - 0.0898)	2.22 (0.0874)
2.28 - 2.30 (0.0898 - 0.0906)	2.24 (0.0882)
2.30 - 2.32 (0.0906 - 0.0913)	2.26 (0.0890)
2.32 - 2.34 (0.0913 - 0.0921)	2.28 (0.0898)
2.34 - 2.37 (0.0921 - 0.0933)	2.30 (0.0906)
2.37 - 2.41 (0.0933 - 0.0949)	2.34 (0.0921)
2.41 - 2.45 (0.0949 - 0.0965)	2.38 (0.0937)
2.45 - 2.49 (0.0965 - 0.0980)	2.42 (0.0953)
2.49 - 2.53 (0.0980 - 0.0996)	2.46 (0.0969)
2.53 - 2.57 (0.0996 - 0.1012)	2.50 (0.0984)
2.57 - 2.61 (0.1012 - 0.1028)	2.54 (0.1000)
2.61 - 2.65 (0.1028 - 0.1043)	2.58 (0.1016)
2.65 - 2.69 (0.1043 - 0.1059)	2.62 (0.1031)
2.69 - 2.73 (0.1059 - 0.1075)	2.66 (0.1047)

Output Shaft

NIAT0316

SEAL RING CLEARANCE

NIAT0316S01
Unit: mm (in)

Output shaft seal ring clearance	Standard	0.10 - 0.25 (0.0039 - 0.0098)
	Allowable limit	0.25 (0.0098)

END PLAY

NIAT0316S02

Output shaft end play	0 - 0.5 mm (0 - 0.020 in)
-----------------------	---------------------------

OUTPUT SHAFT END PLAY ADJUSTING SHIMS

NIAT0316S03

Thickness mm (in)	Part number*
0.56 (0.0220)	31438-31X46
0.96 (0.0378)	31438-31X47
1.36 (0.0535)	31438-31X48

*: Always check with the Parts Department for the latest parts information.

Bearing Retainer

NIAT0317

SEAL RING CLEARANCE

NIAT0317S01
Unit: mm (in)

Bearing retainer seal ring clearance	Standard	0.10 - 0.25 (0.0039 - 0.0098)
	Allowable limit	0.25 (0.0098)

SERVICE DATA AND SPECIFICATIONS (SDS)

Total End Play

Total End Play

NIAT0318

Total end play "T ₃ "	0.25 - 0.55 mm (0.0098 - 0.0217 in)
----------------------------------	-------------------------------------

BEARING RACE FOR ADJUSTING TOTAL END PLAY

NIAT0318S01

Thickness mm (in)	Part number*
0.6 (0.024)	31435-31X01
0.8 (0.031)	31435-31X02
1.0 (0.039)	31435-31X03
1.2 (0.047)	31435-31X04
1.4 (0.055)	31435-31X05
1.6 (0.063)	31435-31X06
1.8 (0.071)	31435-31X07
2.0 (0.079)	31435-31X08

*: Always check with the Parts Department for the latest parts information.

Reverse Clutch End Play

NIAT0319

Reverse clutch end play "T ₄ "	0.65 - 1.00 mm (0.0256 - 0.0394 in)
---	-------------------------------------

THRUST WASHERS FOR ADJUSTING REVERSE CLUTCH END PLAY

NIAT0319S01

Thickness mm (in)	Part number*
0.65 (0.0256)	31508-31X10
0.80 (0.0315)	31508-31X11
0.95 (0.0374)	31508-31X12
1.10 (0.0433)	31508-31X13
1.25 (0.0492)	31508-31X14
1.40 (0.0551)	31508-31X15

*: Always check with the Parts Department for the latest parts information.

Accumulator

NIAT0320

O-RING

NIAT0320S01
Unit: mm (in)

Accumulator	Diameter (Small)	Part number*	Diameter (Large)	Part number*
Servo release accumulator	26.9 (1.059)	31526-41X03	44.2 (1.740)	31526-41X02
N-D accumulator	34.6 (1.362)	31526-31X08	39.4 (1.551)	31672-21X00

*: Always check with the Parts Department for the latest parts information.

RETURN SPRING

NIAT0320S02
Unit: mm (in)

Accumulator	Free length	Outer diameter	Part number*
Servo release accumulator spring	52.5 (2.067)	20.1 (0.791)	31605-80X00
N-D accumulator spring	45.0 (1.772)	27.6 (1.087)	31605-33X01

*: Always check with the Parts Department for the latest parts information.

Band Servo

NIAT0321

RETURN SPRING

NIAT0321S01
Unit: mm (in)

Return spring	Free length	Outer diameter	Part number*
2nd servo return spring	32.5 (1.280)	25.9 (1.020)	31605-31X20
OD servo return spring	38.52 (1.5165)	22.0 (0.866)	31605-31X21

*: Always check with the Parts Department for the latest parts information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Removal and Installation

Removal and Installation

Unit: mm (in) NIAT0322

Distance between end of converter housing and torque converter

15.9 (0.626) or more

Shift Solenoid Valves

NIAT0323

Gear	Solenoid A	Solenoid B
1st	ON	ON
2nd	OFF	ON
3rd	OFF	OFF
4th	ON	OFF

Resistance

NIAT0324

Solenoid valve	Resistance	Terminal number
Shift solenoid A	20 - 30Ω	2
Shift solenoid B	5 - 20Ω	1
Ovr. clutch sol.	20 - 30Ω	3
Line pres. sol.	2.5 - 5Ω	4
T/conv. clutch sol.	5 - 20Ω	5

ATF Temp. Sensor

NIAT0325

Temperature	Resistance
20°C (68°F)	2.5 kΩ
80°C (176°F)	0.3 kΩ

Revolution Sensor

NIAT0326

Condition	Judgement standard
When moving at 20 km/h (12 MPH), use the CONSULT-II pulse frequency measuring function. *1 CAUTION: Connect the diagnosis data link cable to the vehicle diagnosis connector. *1: A circuit tester cannot be used to test this item.	Approximately 150 Hz
When vehicle not moving.	Under 1.3V or over 4.5V

Dropping Resistor

NIAT0327

Resistance	
	10 - 15Ω