

# ENGINE MECHANICAL

## SECTION **EM**

GI  
MA  
**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

## CONTENTS

|  | QG18DE |  |
|--|--------|--|
| <b>PRECAUTIONS</b> .....                           | 4      |  |
| Parts Requiring Angular Tightening.....            | 4      |  |
| Liquid Gasket Application Procedure .....          | 4      |  |
| <b>PREPARATION</b> .....                           | 5      |  |
| Special Service Tools .....                        | 5      |  |
| Commercial Service Tools .....                     | 7      |  |
| <b>NOISE, VIBRATION AND HARSHNESS (NVH)</b>        |        |  |
| <b>TROUBLESHOOTING</b> .....                       | 10     |  |
| NVH Troubleshooting - Engine Noise .....           | 10     |  |
| <b>OUTER COMPONENT PARTS</b> .....                 | 12     |  |
| Removal and Installation .....                     | 12     |  |
| QG18DE (EXCEPT CALIF. CA MODEL) .....              | 14     |  |
| QG18DE (CALIF. CA MODEL) .....                     | 15     |  |
| <b>MEASUREMENT OF COMPRESSION PRESSURE</b> .....   | 16     |  |
| <b>OIL PAN</b> .....                               | 17     |  |
| Components.....                                    | 17     |  |
| Removal.....                                       | 17     |  |
| Installation.....                                  | 18     |  |
| <b>TIMING CHAIN</b> .....                          | 20     |  |
| Components.....                                    | 20     |  |
| Removal.....                                       | 21     |  |
| Inspection.....                                    | 24     |  |
| Installation.....                                  | 24     |  |
| <b>OIL SEAL</b> .....                              | 29     |  |
| Replacement.....                                   | 29     |  |
| VALVE OIL SEAL.....                                | 29     |  |
| FRONT OIL SEAL.....                                | 29     |  |
| REAR OIL SEAL .....                                | 30     |  |
| <b>CYLINDER HEAD</b> .....                         | 31     |  |
| Components.....                                    | 31     |  |
| Removal.....                                       | 32     |  |
| Disassembly.....                                   | 34     |  |
| Inspection.....                                    | 34     |  |
| CYLINDER HEAD DISTORTION .....                     | 34     |  |
| CAMSHAFT VISUAL CHECK.....                         | 35     |  |
| CAMSHAFT RUNOUT.....                               | 35     |  |
| CAMSHAFT CAM HEIGHT .....                          | 35     |  |
| CAMSHAFT JOURNAL CLEARANCE .....                   | 36     |  |
| CAMSHAFT END PLAY.....                             | 36     |  |
| CAMSHAFT SPROCKET RUNOUT .....                     | 37     |  |
| VALVE GUIDE CLEARANCE .....                        | 37     |  |
| VALVE GUIDE REPLACEMENT.....                       | 37     |  |
| VALVE SEATS.....                                   | 38     |  |
| REPLACING VALVE SEAT FOR SERVICE PARTS .....       | 39     |  |
| VALVE DIMENSIONS.....                              | 40     |  |
| VALVE SPRING.....                                  | 40     |  |
| VALVE LIFTER AND VALVE SHIM .....                  | 40     |  |
| Assembly .....                                     | 41     |  |
| Installation.....                                  | 41     |  |
| Valve Clearance.....                               | 45     |  |
| CHECKING .....                                     | 45     |  |
| ADJUSTING .....                                    | 46     |  |
| <b>ENGINE ASSEMBLY</b> .....                       | 49     |  |
| Removal and Installation .....                     | 49     |  |
| REMOVAL.....                                       | 50     |  |
| INSTALLATION.....                                  | 52     |  |
| <b>CYLINDER BLOCK</b> .....                        | 53     |  |
| Components.....                                    | 53     |  |
| Removal and Installation .....                     | 54     |  |
| Disassembly.....                                   | 54     |  |
| PISTON AND CRANKSHAFT.....                         | 54     |  |
| Inspection.....                                    | 55     |  |
| PISTON AND PISTON PIN CLEARANCE .....              | 55     |  |
| PISTON RING SIDE CLEARANCE .....                   | 55     |  |
| PISTON RING END GAP.....                           | 56     |  |
| CONNECTING ROD BEND AND TORSION .....              | 56     |  |
| CYLINDER BLOCK DISTORTION AND WEAR.....            | 57     |  |
| PISTON-TO-BORE CLEARANCE .....                     | 57     |  |
| CRANKSHAFT.....                                    | 58     |  |
| BEARING CLEARANCE .....                            | 59     |  |
| CONNECTING ROD BUSHING CLEARANCE                   |        |  |
| (SMALL END).....                                   | 61     |  |
| REPLACEMENT OF CONNECTING ROD                      |        |  |
| BUSHING (SMALL END) .....                          | 61     |  |
| FLYWHEEL/DRIVE PLATE RUNOUT .....                  | 61     |  |
| Assembly .....                                     | 62     |  |
| PISTON .....                                       | 62     |  |
| CRANKSHAFT.....                                    | 63     |  |
| <b>SERVICE DATA AND SPECIFICATIONS (SDS)</b> ..... | 66     |  |

# CONTENTS (Cont'd)

|   |    |   |            |
|---|----|---|------------|
| General Specifications.....             | 66 | VALVE OIL SEAL.....                               | 102        |
| Compression Pressure.....               | 66 | FRONT OIL SEAL.....                               | 103        |
| Cylinder Head.....                      | 66 | REAR OIL SEAL.....                                | 103        |
| Valve.....                              | 67 | <b>CYLINDER HEAD.....</b>                         | <b>105</b> |
| VALVE.....                              | 67 | Components.....                                   | 105        |
| VALVE SPRING.....                       | 67 | Removal.....                                      | 106        |
| VALVE LIFTER.....                       | 67 | Disassembly.....                                  | 108        |
| VALVE CLEARANCE.....                    | 67 | Inspection.....                                   | 110        |
| VALVE GUIDE.....                        | 68 | CYLINDER HEAD DISTORTION.....                     | 110        |
| AVAILABLE SHIMS.....                    | 68 | CAMSHAFT VISUAL CHECK.....                        | 111        |
| VALVE SEAT.....                         | 71 | CAMSHAFT RUNOUT.....                              | 111        |
| VALVE SEAT RESURFACE LIMIT.....         | 71 | CAMSHAFT CAM HEIGHT.....                          | 111        |
| Camshaft and Camshaft Bearing.....      | 72 | CAMSHAFT JOURNAL CLEARANCE.....                   | 111        |
| Cylinder Block.....                     | 72 | CAMSHAFT END PLAY.....                            | 112        |
| Piston, Piston Ring and Piston Pin..... | 73 | CAMSHAFT SPROCKET RUNOUT.....                     | 112        |
| PISTON.....                             | 73 | VALVE GUIDE CLEARANCE.....                        | 112        |
| PISTON RING.....                        | 73 | VALVE GUIDE REPLACEMENT.....                      | 113        |
| PISTON PIN.....                         | 73 | VALVE SEATS.....                                  | 114        |
| Connecting Rod.....                     | 74 | REPLACING VALVE SEAT FOR SERVICE PARTS..          | 114        |
| Crankshaft.....                         | 75 | VALVE DIMENSIONS.....                             | 115        |
| Main Bearing.....                       | 75 | VALVE SPRING.....                                 | 116        |
| STANDARD.....                           | 75 | HYDRAULIC LASH ADJUSTER.....                      | 116        |
| UNDERSIZE.....                          | 76 | ROCKER ARM, SHIM AND ROCKER ARM GUIDE...          | 117        |
| Connecting Rod Bearing.....             | 76 | Assembly.....                                     | 117        |
| STANDARD SIZE.....                      | 76 | Installation.....                                 | 120        |
| UNDERSIZE.....                          | 76 | <b>ENGINE ASSEMBLY.....</b>                       | <b>127</b> |
| Bearing Clearance.....                  | 76 | Removal and Installation.....                     | 127        |
| Miscellaneous Components.....           | 76 | REMOVAL.....                                      | 128        |
|   |    | INSTALLATION.....                                 | 129        |
|   |    | <b>CYLINDER BLOCK.....</b>                        | <b>130</b> |
|   |    | Components.....                                   | 130        |
|   |    | Removal and Installation.....                     | 131        |
|   |    | Disassembly.....                                  | 131        |
|   |    | PISTON AND CRANKSHAFT.....                        | 131        |
|   |    | Inspection.....                                   | 132        |
|   |    | PISTON AND PISTON PIN CLEARANCE.....              | 132        |
|   |    | PISTON RING SIDE CLEARANCE.....                   | 132        |
|   |    | PISTON RING END GAP.....                          | 133        |
|   |    | CONNECTING ROD BEND AND TORSION.....              | 133        |
|   |    | CYLINDER BLOCK DISTORTION AND WEAR.....           | 133        |
|   |    | PISTON-TO-BORE CLEARANCE.....                     | 134        |
|   |    | CRANKSHAFT.....                                   | 135        |
|   |    | BEARING CLEARANCE.....                            | 135        |
|   |    | CONNECTING ROD BUSHING CLEARANCE                  |            |
|   |    | (SMALL END).....                                  | 138        |
|   |    | REPLACEMENT OF CONNECTING ROD                     |            |
|   |    | BUSHING (SMALL END).....                          | 138        |
|   |    | REPLACEMENT OF PILOT BUSHING (M/T) OR             |            |
|   |    | PILOT CONVERTER (A/T).....                        | 138        |
|   |    | FLYWHEEL/DRIVE PLATE RUNOUT.....                  | 139        |
|   |    | Assembly.....                                     | 139        |
|   |    | PISTON.....                                       | 139        |
|   |    | CRANKSHAFT.....                                   | 140        |
|   |    | <b>SERVICE DATA AND SPECIFICATIONS (SDS).....</b> | <b>143</b> |
|   |    | General Specifications.....                       | 143        |

SR20DE

|   |            |
|---|------------|
| <b>PRECAUTIONS.....</b>                         | <b>77</b>  |
| Parts Requiring Angular Tightening.....         | 77         |
| Liquid Gasket Application Procedure.....        | 77         |
| <b>PREPARATION.....</b>                         | <b>78</b>  |
| Special Service Tools.....                      | 78         |
| Commercial Service Tools.....                   | 80         |
| <b>NOISE, VIBRATION AND HARSHNESS (NVH)</b>     |            |
| <b>TROUBLESHOOTING.....</b>                     | <b>82</b>  |
| NVH Troubleshooting - Engine Noise.....         | 83         |
| <b>OUTER COMPONENT PARTS.....</b>               | <b>84</b>  |
| Removal and Installation.....                   | 84         |
| <b>MEASUREMENT OF COMPRESSION PRESSURE.....</b> | <b>87</b>  |
| <b>OIL PAN.....</b>                             | <b>88</b>  |
| Components.....                                 | 88         |
| Removal.....                                    | 88         |
| Installation.....                               | 90         |
| <b>TIMING CHAIN.....</b>                        | <b>93</b>  |
| Components.....                                 | 93         |
| Removal.....                                    | 94         |
| Inspection.....                                 | 97         |
| Installation.....                               | 97         |
| <b>OIL SEAL.....</b>                            | <b>102</b> |
| Replacement.....                                | 102        |



# CONTENTS (Cont'd)

|  |     |     |
|--|-----|-----|
| Compression Pressure .....               | 143 |     |
| Cylinder Head .....                      | 143 |     |
| Valve .....                              | 144 |     |
| VALVE .....                              | 144 |     |
| VALVE SPRING .....                       | 144 |     |
| HYDRAULIC LASH ADJUSTER (HLA) .....      | 144 |     |
| VALVE GUIDE .....                        | 145 |     |
| VALVE SHIM CLEARANCE ADJUSTMENT .....    | 145 |     |
| AVAILABLE SHIM .....                     | 146 |     |
| VALVE SEAT .....                         | 147 |     |
| VALVE SEAT RESURFACE LIMIT .....         | 148 |     |
| Camshaft and Camshaft Bearing .....      | 148 |     |
| Cylinder Block .....                     | 149 |     |
| Piston, Piston Ring and Piston pin ..... | 150 |     |
| PISTON .....                             | 150 |     |
| PISTON RING .....                        | 150 | GI  |
| PISTON PIN .....                         | 150 |     |
| Connecting Rod .....                     | 151 |     |
| Crankshaft .....                         | 152 | MA  |
| Main Bearing .....                       | 153 |     |
| STANDARD .....                           | 153 |     |
| UNDERSIZE .....                          | 153 | EM  |
| Connecting Rod Bearing .....             | 153 |     |
| STANDARD SIZE .....                      | 153 | LC  |
| UNDERSIZE .....                          | 153 |     |
| Bearing Clearance .....                  | 153 |     |
| Miscellaneous Components .....           | 153 | EC  |
|  |     | FE  |
|  |     | CL  |
|  |     | MT  |
|  |     | AT  |
|  |     | AX  |
|  |     | SU  |
|  |     | BR  |
|  |     | ST  |
|  |     | RS  |
|  |     | BT  |
|  |     | HA  |
|  |     | SC  |
|  |     | EL  |
|  |     | IDX |

**Parts Requiring Angular Tightening**

NIEM0041

- Use an angle wrench for the final tightening of the following engine parts:
  - a) Cylinder head bolts
  - b) Main bearing cap bolts
  - c) Connecting rod cap nuts
- Do not use a torque value for final tightening.
- The torque value for these parts are for a preliminary step.
- Ensure thread and seat surfaces are clean and coated with engine oil.



**Liquid Gasket Application Procedure**







NIEM0042

1. Use a scraper to remove old RTV Silicone Sealant from mating surfaces and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of RTV Silicone Sealant to mating surfaces. (Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.)
  - For oil pan, be sure RTV Silicone Sealant diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).
  - For areas except oil pan, be sure RTV Silicone Sealant diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
3. Apply RTV Silicone Sealant around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.

## Special Service Tools

NIEM0043

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number<br>(Kent-Moore No.)<br>Tool name  | Description   |   |
|---|---|---|
| ST0501S000<br>( — )<br>Engine stand assembly<br>1 ST05011000<br>( — )<br>Engine stand<br>2 ST05012000<br>( — )<br>Base                    |    | Disassembling and assembling  |
| NT042   |   |   |
| Engine attachment<br>assembly<br>1 KV10106500<br>( — )<br>Engine attachment<br>2 KV10113300<br>( — )<br>Sub-attachment                    |    | Overhauling engine  |
| NT029   |   |   |
| ST10120000<br>(J24239-O1)<br>Cylinder head bolt<br>wrench   |  | Loosening and tightening cylinder head bolt<br><b>a: 13 mm (0.51 in) dia.</b><br><b>b: 12 mm (0.47 in)</b><br><b>c: 10 mm (0.39 in)</b> |
| NT583   |   |   |
| KV10116200<br>(J26336-B)<br>Valve spring compres-<br>sor<br>1 KV10115900<br>(J26336-20)<br>Attachment<br>2 KV10109220<br>( — )<br>Adapter |  | Disassembling valve mechanism   |
| WEM044  |   |   |
| KV10115600<br>(J38958)<br>Valve oil seal drift  |  | Installing valve oil seal   |
| NT024   |   |   |
| KV10107902<br>(J-36467)<br>Valve oil seal puller  |  | Displacement valve lip seal   |
| NT011   |   |   |

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC







EL

IDX

# PREPARATION

QG18DE





Special Service Tools (Cont'd)

| Tool number<br>(Kent-Moore No.)<br>Tool name  | Description   |   |
|---|---|---|
| KV101151S0<br>(J38972)<br>Lifter stopper set<br>1 KV10115110<br>Camshaft pliers<br>2 KV10115120<br>Lifter stopper   |    | Changing shims  |
| EM03470000<br>(J8037)<br>Piston ring compressor   |    | Installing piston assembly into cylinder bore         |
| KV10107400<br>(J26365-12, J26365-A)<br>Piston pin press stand<br>1 KV10107310<br>( — )<br>Center shaft<br>2 ST13040020<br>( — )<br>Stand<br>3 ST13040030<br>( — )<br>Spring<br>4 KV10107320<br>( — )<br>Cap<br>5 ST13040050<br>( — )<br>Drift |   | Disassembling and assembling piston pin               |
| KV10111100<br>(J37228)<br>Seal cutter   |  | Removing oil pan                                      |
| WS39930000<br>( — )<br>Tube presser   |  | Pressing the tube of liquid gasket                    |
| KV10112100<br>(BT-8653-A)<br>Angle wrench   |  | Tightening bolts for bearing cap, cylinder head, etc. |

# PREPARATION


**QG18DE**

Special Service Tools (Cont'd)

| Tool number<br>(Kent-Moore No.)<br>Tool name  | Description   |  |
|---|---|--|
| ST16610001<br>(J23907)<br>Pilot bushing puller  | <br>Removing pilot bushing<br><br>NT045  | GI<br><br>MA<br><br><b>EM</b>              |
| (J36471-A)<br>Front (heated) oxygen<br>sensor wrench  | <br>Loosening or tightening heated oxygen sensor with<br>22 m (0.87 in) hexagon nut<br><br>NT379 | LC<br><br>EC<br><br>FE                     |
| (J44626)<br>Air fuel ratio (A/F) sen-<br>sor wrench   | <br>Loosening or tightening air fuel ratio (A/F) sensor 1<br><br>LEM054                          | CL<br><br>MT<br><br>AT                     |
| KV101056S0<br>( — )<br>Rear gear stopper<br>1 KV10105620<br>( — )<br>Adapter<br>2 KV10105610<br>( — )<br>Plate assembly | <br>Preventing crankshaft from rotating<br><br>NT773   | AX<br><br>SU<br><br>BR<br><br>ST<br><br>RS |

## Commercial Service Tools








NIEM0044

| Tool number<br>(Kent-Moore No.)<br>Tool name | Description  |   |
|--|--|---|
| Spark plug wrench                            | <br>Removing and installing spark plug<br><br>16 mm<br>(0.63 in)<br><br>NT047 | BT<br><br>HA<br><br>SC<br><br>EL<br><br>IDX |

# PREPARATION

QG18DE

Commercial Service Tools (Cont'd)

| Tool number<br>(Kent-Moore No.)<br>Tool name                 | Description   |   |
|--|---|---|
| Valve seat cutter set  |    | Finishing valve seat dimensions   |
|  | NT048   |   |
| Piston ring expander   |    | Removing and installing piston ring   |
|  | NT030   |   |
| Valve guide drift  |    | Removing and installing valve guide<br><b>Intake &amp; Exhaust:</b><br><b>a: 9.5 mm (0.374 in) dia.</b><br><b>b: 5.5 mm (0.217 in) dia.</b>   |
|  | NT015   |   |
| Valve guide reamer   |    | Reaming valve guide 1 or hole for oversize valve guide 2<br><b>Intake &amp; Exhaust:</b><br><b>d<sub>1</sub>: 5.5 mm (0.217 in) dia.</b><br><b>d<sub>2</sub>: 9.685 mm (0.3813 in) dia.</b>   |
|  | NT016   |   |
| Front oil seal drift   |  | Installing front oil seal<br><b>a: 52 mm (2.05 in) dia.</b><br><b>b: 40 mm (1.57 in) dia.</b>   |
|  | NT049   |   |
| Rear oil seal drift  |  | Installing rear oil seal<br><b>a: 103 mm (4.06 in) dia.</b><br><b>b: 84 mm (3.31 in) dia.</b>   |
|  | NT049   |   |
| (J-43897-18)<br>(J-43897-12)<br>Oxygen sensor thread cleaner |  | Reconditioning the exhaust system threads before installing a new oxygen sensor (Use with anti-seize lubricant shown below.)<br><b>a: J-43897-18 [18 mm dia.] for zirconia oxygen sensor</b><br><b>b: J-43897-12 [12 mm dia.] for titania oxygen sensor</b> |
|  | AEM488  |   |



# PREPARATION

**QG18DE**

*Commercial Service Tools (Cont'd)*

| Tool number<br>(Kent-Moore No.)<br>Tool name   | Description   |  |
|--|---|--|
| Anti-seize lubricant<br>(Permatex 133AR or<br>equivalent meeting MIL<br>specification MIL-A-907) | <div data-bbox="600 304 755 514" data-label="Image"> </div> <p data-bbox="950 277 1429 331">Lubricating oxygen sensor thread cleaning tool<br/>when reconditioning exhaust system threads</p> <p data-bbox="414 556 495 577">AEM489</p> | <p>GI</p> <p>MA</p> <p><b>EM</b></p> <p>LC</p> |
|  |   | EC   |
|  |   | FE   |
|  |   | CL   |
|  |   | MT   |
|  |   | AT   |
|  |   | AX   |
|  |   | SU   |
|  |   | BR   |
|  |   | ST   |
|  |   | RS   |
|  |   | BT   |
|  |   | HA   |
|  |   | SC   |
|  |   | EL   |
|  |   | IDX  |

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NIEM0045

**QG18DE**

NVH Troubleshooting — Engine Noise

## NVH Troubleshooting — Engine Noise

NIEM0045S01

Use the chart below to help you find the cause of the symptom.

1. Locate the area where noise occurs.
2. Confirm the type of noise.
3. Specify the operating condition of engine.
4. Check specified noise source.

If necessary, repair or replace these parts.


| Location of noise   | Type of noise      | Operating condition of engine |               |               |             |             |               | Source of noise                          | Check item   | Reference page                           |
|---|--------------------|-------------------------------|---------------|---------------|-------------|-------------|---------------|--|--|--|
|   |                    | Before warm-up                | After warm-up | When starting | When idling | When racing | While driving |  |  |  |
| Top of Engine<br>Rocket Cover<br>Cylinder Head                  | Ticking or click   | C                             | A             | —             | A           | B           | —             | Tappet noise                             | Valve clearance  | EM-45                                    |
|   | Rattle             | C                             | A             | —             | A           | B           | C             | Camshaft bearing noise                   | Camshaft journal clearance<br>Camshaft runout  | EM-36                                    |
| Crankshaft Pulley<br>Cylinder block (Side of Engine)<br>Oil pan | Slap or knock      | —                             | A             | —             | B           | B           | —             | Piston pin noise                         | Piston and piston pin clearance<br>Connecting rod bushing clearance  | EM-55, 61                                |
|   | Slap or rap        | A                             | —             | —             | B           | B           | A             | Piston slap noise                        | Piston-to-bore clearance<br>Piston ring side clearance<br>Piston ring end gap<br>Connecting rod bend and torsion | EM-57, 55, 56, 56                        |
|   | Knock              | A                             | B             | C             | B           | B           | B             | Connecting rod bearing noise             | Connecting rod bearing clearance (Big end)<br>Connecting rod bushing clearance (Small end)                       | EM-60, 61                                |
|   | Knock              | A                             | B             | —             | A           | B           | C             | Main bearing noise                       | Main bearing oil clearance<br>Crankshaft runout  | EM-58                                    |
| Front of Engine<br>Timing Chain Cover                           | Tapping or ticking | A                             | A             | —             | B           | B           | B             | Timing chain and chain tensioner noise   | Timing chain cracks and wear<br>Timing chain tensioner operation   | EM-24                                    |
| Front of Engine   | Squeak or fizzing  | A                             | B             | —             | B           | —           | C             | Other drive belts (sticking or slipping) | Drive belts deflection   | <b>MA-25</b> ,<br>"Checking Drive Belts" |
|   | Creaking           | A                             | B             | A             | B           | A           | B             | Other drive belts (slipping)             | Idler pulley bearing operation   |  |
|   | Squall or creak    | A                             | B             | —             | B           | A           | B             | Water pump noise                         | Water pump operation   | <b>LC-13</b> ,<br>"INSPECTION"           |

A: Closely related    B: Related    C: Sometimes related    —: Not related

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

**QG18DE**

NVH Troubleshooting — Engine Noise (Cont'd)



GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

SEM937F

## Removal and Installation



NIEM0046

**SEC. 140•147•150•210**



WEM015

- |                        |                                  |                            |
|------------------------|----------------------------------|----------------------------|
| 1. Oil pressure switch | 6. Intake manifold upper support | 10. Water pump             |
| 2. EGR valve           | 7. Intake manifold rear supports | 11. Water pump pulley      |
| 3. EGR guide tube      | 8. Oil filter                    | 12. EGR tube               |
| 4. Air relief plug     | 9. Thermostat                    | 13. EGR temperature sensor |
| 5. Intake manifold     |                                  |                            |



1. Throttle position sensor
2. IACV-AAC valve
3. Throttle body

4. Injector
5. Injector tube
6. Pressure regulator


7. Intake manifold
8. Canister purge control valve

WEM016

 GI  
 MA  
**EM**  
 LC  
 EC  
 FE  
 CL  
 MT  
 AT  
 AX  
 SU  
 BR  
 ST  
 RS  
 BT  
 HA  
 SC  
 EL  
 IDX

*Removal and Installation (Cont'd)*

NIEM0046S02


**QG18DE (EXCEPT CALIF. CA MODEL)**

WEM017

- |                                      |                           |                             |
|--------------------------------------|---------------------------|-----------------------------|
| 1. Crankshaft pulley                 | 5. Exhaust manifold cover | 9. Three way catalyst (TWC) |
| 2. Engine coolant temperature sensor | 6. Thermal transmitter    | 10. Converter cover         |
| 3. Gasket                            | 7. Water drain plug       | 11. Ignition coil           |
| 4. Exhaust manifold                  | 8. Heated oxygen sensor   | 12. Spark plug              |



**QG18DE (CALIF. CA MODEL)**
**CAUTION:**

If the Calif. CA Model's TWC (manifold three way catalyst) or ADS-TWC (adsorber pre-catalyst) replacement is necessary, always replace the TWC together with the ADS-TWC. Never replace these catalysts individually. The TWC and the ADS-TWC are only available together as a kit.



- |                                      |                                   |                         |
|--------------------------------------|-----------------------------------|-------------------------|
| 1. Crankshaft pulley                 | 6. Air fuel ratio sensor cover    | 11. Water drain plug    |
| 2. Engine coolant temperature sensor | 7. Sensor wire bracket            | 12. Spark plug          |
| 3. Gasket                            | 8. TWC cover                      | 13. Ignition coil       |
| 4. TWC (manifold three way catalyst) | 9. Heated oxygen sensor 2 (rear)  | 14. Thermal transmitter |
| 5. TWC manifold cover                | 10. Air fuel ratio (A/F) sensor 1 |                         |

1. Warm up engine.
2. Turn ignition switch OFF.
3. Release fuel pressure.  
Refer to **EC-67** [QG18DE (except Calif. CA Model)] or **EC-744** [QG18DE (Calif. CA Model)], "Fuel Pressure Release".
4. Remove ignition coils.
5. Remove spark plugs.
  - Clean area around plug with compressed air before removing the spark plug.



6. Attach a compression tester to No. 1 cylinder.
7. Depress accelerator pedal fully to keep throttle valve wide open.
8. Crank engine and record highest gauge indication.
9. Repeat the measurement on each cylinder as shown above.
  - **Always use a fully-charged battery to obtain specified engine speed.**

**Compression pressure: kPa (bar, kg/cm<sup>2</sup>, psi)/rpm**  
**Standard**

**1,324 (13.24, 13.5, 192)/350**

**Minimum**

**1,157 (11.57, 11.5, 168)/350**

**Maximum allowable difference between cylinders**

**98 (0.98, 1.0, 14)/350**


10. If cylinder compression in one or more cylinders is low, pour a small amount of engine oil into the cylinder through the spark plug hole and retest compression.
  - **If adding oil improves cylinder compression, piston rings may be worn or damaged. If so, replace piston rings after checking piston.**
  - **If pressure stays low, a valve may be sticking or seating improperly. Inspect and repair valve and valve seat. Refer to "VALVE", EM-67 and "VALVE SEAT", EM-71. If valve or valve seat is damaged excessively, replace them.**
  - If compression in any two adjacent cylinders is low and if adding oil does not improve compression, there is leakage past the gasket surface. If so, replace cylinder head gasket.
11. Install spark plugs, ignition coils and fuel pump fuse.
12. Erase DTC if any DTC appears. Refer to **EC-98** [QG18DE (except Calif. CA Model)] or **EC-770** [QG18DE (Calif. CA Model)], "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".



## Components

NIEM0048

SEC. 110•150



WEM021







GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

## Removal

1. Remove engine RH side undercover splash shield.
2. Drain engine oil.
3. Remove front exhaust tube.  
Refer to **FE-15**, "Removal and Installation".
4. Remove the exhaust manifold support.

NIEM0049

## Removal (Cont'd)



5. Remove the engine gusset.
6. Remove rear plate cover (A/T models).

7. Remove oil pan.
  - a. Insert Tool between cylinder block and oil pan.
    - **Be careful not to damage aluminum mating face.**
    - Do not insert screwdriver, or oil pan flange will be damaged.**
  - b. Slide Tool by tapping on the side of the Tool with a hammer.



## Installation

1. Use a scraper to remove old RTV Silicone Sealant from mating surface of oil pan. NIEM0050
  - **Also remove old RTV Silicone Sealant from mating surface of cylinder block.**
2. Apply a continuous bead of RTV Silicone Sealant to mating surface of oil pan.
  - **Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.**
  - **Apply to groove on mating surface.**
  - **Allow 7 mm (0.28 in) clearance around bolt holes.**

# OIL PAN

**QG18DE**

Installation (Cont'd)



- Be sure RTV Silicone Sealant diameter is 3.5 to 4.5 mm (0.138 to 0.177 in).
- Attaching should be done within 5 minutes after coating.

3. Install oil pan.
- Tighten oil pan nuts and bolts in the numerical order.
- Wait at least 30 minutes before refilling engine oil.
4. Install parts in reverse order of removal.

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

## Components

NIEM0051

### SEC. 120•130•135



WEM026

- |                                  |                               |                                      |
|----------------------------------|-------------------------------|--------------------------------------|
| 1. Chain tensioner               | 6. Timing chain tension guide | 11. O-ring                           |
| 2. Camshaft sprocket (Intake)    | 7. Timing chain               | 12. Oil seal                         |
| 3. Camshaft sprocket (Exhaust)   | 8. Crankshaft sprocket        | 13. Crankshaft pulley                |
| 4. O-ring                        | 9. Oil pump drive spacer      | 14. Cylinder head front cover        |
| 5. Slack side timing chain guide | 10. Front cover               | 15. Camshaft position sensor (PHASE) |

**CAUTION:**


- After removing timing chain, do not turn crankshaft and camshaft separately, or valves will strike piston heads.
- When installing chain tensioner, oil seals, or other sliding parts, lubricate contacting surfaces with new engine oil.
- Apply new engine oil to bolt threads and seat surfaces when installing camshaft sprocket and crankshaft pulley.
- When removing oil pump assembly, remove camshaft position sensor (PHASE), then remove timing chain from engine.
- Be careful not to damage sensor edges.

GI

MA

EM

LC


**Removal**

1. Drain engine coolant from radiator and cylinder block. Be careful not to spill coolant on drive belts.
2. Remove the following belts.
  - Power steering pump drive belt
  - Alternator drive belt
3. Remove front RH wheel.
4. Remove front/right-side splash undercover.
5. Remove front exhaust tube.
6. Disconnect vacuum hoses for:
  - EVAP canister
  - Brake power booster
  - Fuel pressure regulator

NIEM0052

EC

FE

CL


MT

AT

AX

SU

BR




7. Remove ignition coils.
8. Remove spark plugs.

ST

RS

BT

HA




9. Remove rocker cover bolts in numerical order as shown in the figure.

SC


EL

IDX


## Removal (Cont'd)




10. Set No. 1 piston at TDC on its compression stroke.




- Rotate crankshaft until mating mark on camshaft sprocket is set at position indicated in figure at left.



11. Remove camshaft position sensor (PHASE).
- Do not allow any magnetic materials to contact the camshaft position sensor (PHASE).
  - Be careful not to damage sensor.
12. Remove cylinder head front cover.



13. Remove timing chain guide from camshaft bracket.
14. Attach a suitable stopper pin to chain tensioner.
15. Remove chain tensioner.




16. Remove camshaft sprocket bolts.
- Apply paint to timing chain and cam sprockets for alignment during installation.
17. Remove camshaft sprockets.


# TIMING CHAIN

**QG18DE**


Removal (Cont'd)




18. Remove cylinder head bolts at engine front side as shown.
19. Remove oil pan. Refer to "Removal", EM-17.




20. Remove starter motor, and set ring gear stopper using mounting bolt holes.



21. Loosen crankshaft pulley bolt.
22. Remove crankshaft pulley with a suitable puller.
23. Support engine with a suitable hoist or jack.



24. Remove RH engine mounting.



25. Remove RH engine mounting bracket.
26. Remove idler pulley and bracket.

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX


## Removal (Cont'd)




27. Remove water pump pulley and water pump.
28. Remove front cover bolts and front cover as shown.
  - ★1: Located on water pump
  - ★2: Located on power steering pump adjusting bar, remove the bar
  - Inspect for oil leakage at front oil seal. Replace seal if oil leak is present.



29. Remove timing chain.
30. Remove oil pump drive spacer.
31. Remove chain guides.
32. Remove crankshaft sprocket.




33. Remove O-rings from cylinder block and front cover.



## Inspection

Check for cracks and excessive wear at roller links. Replace if necessary. NIEM0053



## Installation


1. Install crankshaft sprocket on crankshaft. NIEM0054
  - Make sure mating marks on crankshaft sprocket face front of engine.




# TIMING CHAIN

**QG18DE**


Installation (Cont'd)




2. Position crankshaft so that No. 1 piston is at TDC and crankshaft key is at 12 o'clock.




3. Install slack side timing chain guide and timing chain tension guide.



4. Install timing chain on crankshaft sprocket.
  - Set timing chain by aligning its mating mark with that on the crankshaft sprocket.
  - Make sure sprocket's mating mark faces engine front.



5. Install camshaft sprockets.
  - Set timing chain by aligning mating marks with those of camshaft sprockets.



6. Install camshaft sprocket bolts to correct torque.
  - Apply new engine oil to bolt threads and seat surface.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX


## Installation (Cont'd)




7. Install chain tensioner.
  - **Before installing chain tensioner, insert a suitable pin into pin hole of chain tensioner.**
  - **After installing chain tensioner, remove the pin.**
8. Install timing chain guide.




9. Install O-rings to cylinder block.



10. Before installing front cover, remove all traces of RTV Silicone Sealant from mating surface using a scraper.
  - Also remove traces of RTV Silicone Sealant from mating surface of cylinder block.



11. Apply a continuous bead of Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent to mating surface of front cover.
  - **Check alignment of mating marks on chain and crankshaft sprocket.**
  - **Align oil drive spacer with oil pump.**
  - **Place timing chain to the side of chain guide. This prevents the chain from making contact with water seal area of front cover.**



12. Install front cover.


| Bolt No. | Tightening torque N-m (kg-m, in-lb) | "ℓ" mm (in)  |
|----------|-------------------------------------|--------------|
| a.       | 6.9 - 9.5 (0.70 - 0.97, 61 - 84)    | 20 (0.79)    |
| b.       | 6.9 - 9.5 (0.70 - 0.97, 61 - 84)    | 40 (1.57)    |
| c.       | 17 - 24 (1.7 - 2.4, 148 - 208*)     | 70 (2.76)    |
| d.       | 6.9 - 9.5 (0.70 - 0.97, 61 - 84)    | 72.8 (2.866) |
| e.       | 6.9 - 9.5 (0.70 - 0.97, 61 - 84)    | 12 (0.47)    |

\*: 12 - 17 ft-lb


# TIMING CHAIN

**QG18DE**


Installation (Cont'd)




- Make sure two O-rings are present.
- Be careful not to damage oil seal when installing front cover.




13. Install cylinder head bolts at engine front side as shown.
- **Tightening procedure**  
Tighten bolts (1 - 4) to 6.3 to 8.3 N·m (0.64 to 0.85 kg·m, 55.8 to 73.5 in·lb).



14. Install oil pump drive spacer.
15. Install water pump and water pump pulley. Refer to **LC-12**, "REMOVAL AND INSTALLATION".
16. Install idler pulley and bracket.



17. Install RH engine mounting bracket.
18. Install RH engine mounting.
19. Install oil pan. Refer to "Installation", EM-18.
20. Install crankshaft pulley.
21. Remove ring gear stopper.
22. Install starter motor.



23. Install cylinder head front cover.
  - Apply RTV Silicone Sealant to cylinder head front cover.
  - Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX

## Installation (Cont'd)




24. Install camshaft position sensor (PHASE).



25. Before installing rocker cover, apply a bead of Genuine RTV Silicone Sealant Part No. 999MP-A7007 to mating surface of cylinder head as shown.

26. Install rocker cover gasket into rocker cover.



27. Install rocker cover and tighten in numerical order as shown in the figure.

28. Install spark plugs.

29. Install ignition coils.

30. Install front exhaust tube.






31. Install front/right-side splash undercover.

32. Install front RH wheel.

33. Drive belts.

For adjusting drive belt deflection, refer to **MA-16**, "Checking Drive Belts".

34. Reinstall parts in reverse order of removal.



## Replacement VALVE OIL SEAL

NIEM0055  
NIEM0055S01

1. Remove rocker cover.
2. Remove camshaft.
3. Remove valve spring. Refer to "Components", EM-31.
4. Remove valve oil seal with Tool.

**Piston concerned should be set at TDC to prevent valve from falling.**

5. Apply new engine oil to new valve oil seal and install it with Tool.

## FRONT OIL SEAL

NIEM0055S02

1. Remove the following parts:
  - Engine under cover
  - RH engine side cover
  - Generator and power steering drive belts
  - Crankshaft pulley
2. Remove front oil seal from front cover.
  - **Be careful not to scratch front cover.**
3. Apply new engine oil to new oil seal and install it using a suitable tool.
  - Install new oil seal in the direction shown.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

## REAR OIL SEAL


1. Remove transaxle. Refer to *MT-12*, "Removal" or *AT-436*, "Removal".
2. Remove flywheel or drive plate.



3. Remove rear oil seal.
  - Be careful not to scratch rear oil seal retainer.




4. Apply new engine oil to new oil seal and install it using a suitable tool.
  - Install new oil seal in the direction shown.



## Components

SEC. 111•130



- 1. Oil filler cap
- 2. Rocker cover
- 3. Rocker cover gasket
- 4. Intake valve timing control solenoid
- 5. Camshaft bracket
- 6. Intake camshaft
- 7. Exhaust camshaft

- 8. Timing chain guide
- 9. Cylinder head bolt
- 10. Shim
- 11. Valve lifter
- 12. Valve cotter
- 13. Valve spring retainer
- 14. Valve spring


- 15. Valve spring seat
- 16. Valve oil seal
- 17. Valve guide
- 18. Cylinder head
- 19. Cylinder head gasket
- 20. Valve seat
- 21. Valve

WEM121

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


**CAUTION:**

- When installing camshaft and oil seal, lubricate contacting surfaces with new engine oil.
- When tightening cylinder head bolts, camshaft sprocket bolts and camshaft bracket bolts, lubricate bolt threads and seat surfaces with new engine oil.
- Attach tags to valve lifters so as not to mix them up.


**Removal**

NIEM0057


1. Drain engine coolant from radiator and cylinder block. Be careful not to spill coolant on drive belts.
2. Release fuel pressure. Refer to **EC-67** [QG18DE (except Calif. CA Model)], or **EC-744** [QG18DE (Calif. CA Model)], "Fuel Pressure Release".
3. Remove air duct to intake manifold collector.
4. Remove engine drive belts.
5. Remove front splash undercovers.
6. Remove front exhaust tube.
7. Before removing intake manifold collector from engine, the following parts should be disconnected to remove intake manifold collector:
  - EGR tube
  - Fuel injector connectors
  - Ground harness
  - Breather pipe
 Harness connectors for:
  - IACV-AAC valve
  - Throttle position sensor
  - Throttle position switch
  - EGR temperature sensor
  - Water hoses from collector
  - Heater hoses
  - PCV hose
 Vacuum hoses for:
  - EVAP canister
  - Power brake booster
  - Fuel pressure regulator
8. Remove intake manifold rear supports.
9. Remove exhaust manifold.
10. Remove ignition coils.
11. Remove spark plugs.









12. Remove rocker cover bolts in numerical order as shown in the figure.




13. Set No. 1 piston at TDC on its compression stroke.



- Rotate crankshaft until mating mark on camshaft sprocket is set at position indicated in figure at left.



14. Remove camshaft position sensor (PHASE).
- **Do not allow any magnetic materials to contact the camshaft position sensor (PHASE).**
  - **Be careful not to damage sensor.**
15. Remove cylinder head front cover.



16. Remove timing chain guide from camshaft bracket.
17. Attach a suitable stopper pin to chain tensioner.
18. Remove chain tensioner.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX


## Removal (Cont'd)




19. Remove camshaft sprocket bolts.
  - Apply paint to timing chain and cam sprockets for alignment during installation.
20. Remove camshaft sprockets.



21. Remove camshaft brackets and camshafts.
  - Apply I.D. marks to brackets to ensure correct reassembly.
  - Bolts should be loosened in two or three steps.




22. Remove cylinder head bolts.
23. Remove cylinder head with intake manifold.
  - Head warpage or cracking could result from removing in incorrect order.
  - Cylinder head bolts should be loosened in two or three steps.



## Disassembly

1. Remove valve components with Tool.
2. Remove valve oil seal with a suitable tool.

NIEM0058



## Inspection

### CYLINDER HEAD DISTORTION

- Clean surface of cylinder head.
- Use a reliable straightedge and feeler gauge to check the flatness of cylinder head mating surface.
- Check along six positions shown in figure.

#### Head surface flatness:

**Standard: Less than 0.03 mm (0.0012 in)**

**Limit: 0.1 mm (0.004 in)**

NIEM0059

NIEM0059S01

If beyond the specified limit, replace or resurface it.

### Resurfacing limit:

The limit for cylinder head resurfacing is determined by the amount of cylinder block resurfacing.

Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".

The maximum limit is as follows:

$$A + B = 0.2 \text{ mm (0.008 in)}$$


After resurfacing cylinder head, check that camshaft rotates freely by hand. If resistance is felt, replace cylinder head.

Nominal cylinder head height:

$$117.8 - 118.0 \text{ mm (4.638 - 4.646 in)}$$

### CAMSHAFT VISUAL CHECK

Check camshaft for scratches, seizure and wear.

NIEM0059S02


### CAMSHAFT RUNOUT

1. Measure camshaft runout at the center journal.

Runout (Total indicator reading):


Standard

$$\text{Less than } 0.02 \text{ mm (0.0008 in)}$$

Limit

$$0.1 \text{ mm (0.004 in)}$$

2. If it exceeds the limit, replace camshaft.

NIEM0059S03


### CAMSHAFT CAM HEIGHT

1. Measure camshaft cam height.

Standard cam height:

Intake

$$40.610 - 40.800 \text{ mm (1.5988 - 1.6063 in)}$$

Exhaust

$$40.056 - 40.246 \text{ mm (1.5770 - 1.5845 in)}$$

Cam wear limit:

$$0.20 \text{ mm (0.0079 in)}$$

2. If wear is beyond the limit, replace camshaft.

NIEM0059S04

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT



HA

SC

EL

IDX

Inspection (Cont'd)

**CAMSHAFT JOURNAL CLEARANCE**

=NIEM0059S05


1. Install camshaft bracket and tighten bolts to the specified torque.
2. Measure inner diameter of camshaft bearing.

**Standard inner diameter:****No. 1 bearing****28.000 - 28.021 mm (1.1024 - 1.1032 in)****No. 2 to No. 5 bearings****24.000 - 24.021 mm (0.9449 - 0.9457 in)**

3. Measure outer diameter of camshaft journal.

**Standard outer diameter:****No. 1 journal****27.935 - 27.955 mm (1.0998 - 1.1006 in)****No. 2 to No. 5 journals****23.935 - 23.955 mm (0.9423 - 0.9431 in)**

4. If clearance exceeds the limit, replace camshaft and/or cylinder head.


**Camshaft journal clearance:****Standard****0.045 - 0.086 mm (0.0018 - 0.0034 in)****Limit****0.15 mm (0.0059 in)****CAMSHAFT END PLAY**

NIEM0059S06

1. Install camshaft in cylinder head. Refer to "Inspection", EM-24.
2. Measure camshaft end play.

**Camshaft end play:****Standard****0.115 - 0.188 mm (0.0045 - 0.0074 in)****Limit****0.20 mm (0.0079 in)**

3. If limit is exceeded, replace camshaft and remeasure end play.
  - If limit is still exceeded after replacing camshaft, replace cylinder head.



SEM919F

## CAMSHAFT SPROCKET RUNOUT

NIEM0059S07


1. Install sprocket on camshaft.
2. Measure camshaft sprocket runout.  
**Runout (Total indicator reading):**  
**Limit 0.15 mm (0.0059 in)**
3. If it exceeds the limit, replace camshaft sprocket.

GI

MA

**EM**

LC



SEM345D

## VALVE GUIDE CLEARANCE

NIEM0059S08


1. Measure valve deflection as shown in figure. (Valve and valve guide wear the most in this direction.)  
**Valve deflection limit (Dial gauge reading):**  
**Intake & Exhaust**  
**0.2 mm (0.008 in)**

EC

FE

CL

MT



SEM938C

2. If it exceeds the limit, check valve to valve guide clearance.
  - a. Measure valve stem diameter and valve guide inner diameter.
  - b. Calculate valve to valve guide clearance.  
**Valve stem to valve guide clearance = valve guide inner diameter - valve stem diameter.**
  - c. Check that clearance is within specification.

Unit: mm (in)

|         | Standard                        | Limit       |
|---------|---------------------------------|-------------|
| Intake  | 0.020 - 0.050 (0.0008 - 0.0020) | 0.1 (0.004) |
| Exhaust | 0.040 - 0.070 (0.0016 - 0.0028) | 0.1 (0.004) |

SU

BR


ST

- If it exceeds the limit, replace valve and remeasure clearance.
- **If limit is still exceeded after replacing valve, replace valve guide.**

RS

BT

HA



SEM008A

## VALVE GUIDE REPLACEMENT

NIEM0059S09


1. To remove valve guide, heat cylinder head to 110 to 130°C (230 to 266°F).

SC


EL

IDX

Inspection (Cont'd)



2. Drive out valve guide with a press [under a 20 kN (2 ton, 2.2 US ton, 2.0 Imp ton) pressure] or hammer and suitable tool.




3. Ream cylinder head valve guide hole.

**Valve guide hole diameter**

**(for service parts):**

**Intake & Exhaust**


**9.685 - 9.696 mm (0.3813 - 0.3817 in)**



4. Heat cylinder head to 110 to 130°C (230 to 266°F) and press service valve guide into cylinder head.

**Projection "L":**

**11.5 - 11.7 mm (0.453 - 0.461 in)**




5. Ream valve guide.

**Finished size:**

**Intake & Exhaust**

**5.500 - 5.515 mm (0.2165 - 0.2171 in)**




## VALVE SEATS

NIEM0059S10

Check valve seats for pitting at contact surface. Resurface or replace if excessively worn.

- Before repairing valve seats, check valve and valve guide for wear. If they have worn, replace them. Then correct valve seat.
- Use both hands to cut uniformly.



## REPLACING VALVE SEAT FOR SERVICE PARTS

NIEM0059S11

1. Bore out old seat until it collapses. Set machine depth stop so that boring cannot contact the bottom face of seat recess in cylinder head.
2. Ream cylinder head recess.

### Reaming bore for service valve seat

#### Oversize [0.5 mm (0.020 in)]:


##### Intake

31.500 - 31.516 mm (1.2402 - 1.2408 in)


##### Exhaust

26.500 - 26.516 mm (1.0433 - 1.0439 in)

Use the valve guide center for reaming to ensure valve seat will have the correct fit.



3. Heat cylinder head to 110 to 130°C (230 to 266°F).
4. Press fit valve seat until it seats on the bottom.
5. Cut or grind valve seat using suitable tool to the specified dimensions as shown in "VALVE SEAT", EM-71.
6. After cutting, lap valve seat with abrasive compound.



7. Check valve seating condition.

### Seat face angle "α":

44°53' - 45°07'


### Contacting width "W":

##### Intake

1.06 - 1.34 mm (0.0417 - 0.0528 in)

##### Exhaust

1.34 - 1.63 mm (0.0528 - 0.0642 in)



8. Use a depth gauge to measure the distance "L" between the mounting surface of the cylinder head spring seat and the valve stem end. If the distance is shorter than specified, repeat step 5 above to correct it. If the distance is longer, replace the valve seat.

### Valve seat resurface limit:


##### Intake

35.95 - 36.55 mm (1.4154 - 1.4390 in)

##### Exhaust

35.92 - 36.52 mm (1.4142 - 1.4378 in)


Inspection (Cont'd)

**VALVE DIMENSIONS**

Check dimensions of each valve. Refer to "VALVE", EM-67 for dimensions. NIEM0059S12

When valve head has been worn down to 0.5 mm (0.020 in) in margin thickness, replace valve.

**Grinding allowance for valve stem tip is 0.2 mm (0.008 in) or less.**


**VALVE SPRING****Squareness**

1. Measure dimension "S". NIEM0059S13

**Out-of-square "S":**

**Less than 1.75 mm (0.0689 in)** NIEM0059S1301

2. If it exceeds the limit, replace spring.

**Pressure**

Check valve spring pressure at specified spring height. NIEM0059S1302


**Pressure:****Standard**

**370.0 N (37.73 kg, 83.19 lb) at 23.64 mm (0.9307 in)**


**Limit**

**More than 347.8 N (35.46 kg, 78.19 lb) at 23.64 mm (0.9307 in)**

If not within specification, replace spring.

**VALVE LIFTER AND VALVE SHIM**

1. Check contact and sliding surfaces for wear or scratches. NIEM0059S14




2. Check diameter of valve lifter and valve lifter guide bore.

**Valve lifter outside diameter:**

**29.960 - 29.975 mm (1.1795 - 1.1801 in)**





SEM920F

**Lifter guide inside diameter:**

**30.000 - 30.021 mm (1.1811 - 1.1819 in)**

**Clearance between valve lifter and valve lifter guide:**

**0.025 - 0.065 mm (0.0010 - 0.0026 in)**


If it exceeds the limit, replace valve lifter or cylinder head which exceeds the standard diameter tolerance.

GI

MA

**EM**

LC



AEM293

## Assembly

NIEM0061


1. Install valve component parts.
  - **Always use new valve oil seal.** Refer to "VALVE OIL SEAL", EM-29.
  - **Before installing valve oil seal, install valve spring seat.**
  - **After installing valve components, tap valve stem tip with a plastic hammer to assure a proper fit.**
  - **Install valve spring (narrow pitch at both ends of spring) with either end toward cylinder head.**

EC

FE

CL

MT



SEM899F



Liquid gasket

2.0 - 3.0 mm

(0.079 - 0.118 in) dia.

Engine front

## Installation

NIEM0062

1. Before installing cylinder head gasket, apply a bead of Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent to mating surface of cylinder block as shown.
2. Install cylinder head gasket.
  - **When installing cylinder head with manifolds, use a new cylinder head gasket.**
3. Install cylinder head with intake manifolds.
  - **Be sure to install washers between bolts and cylinder head.**
  - **Do not rotate crankshaft and camshaft separately, or valves will strike piston heads.**
  - **Apply new engine oil to cylinder head bolt threads and seat surfaces.**

AT

AX

SU

BR

ST

RS


BT

HA

SC


EL

IDX




SEM877A

Cylinder head bolt washer




Cylinder head side


Installation (Cont'd)




- **Tightening procedure**
- a) **Tighten bolts to 29 N·m (3 kg-m, 22 ft-lb).**
- b) **Tighten bolts to 59 N·m (6 kg-m, 43 ft-lb).**
- c) **Loosen bolts completely.**
- d) **Tighten bolts to 29 N·m (3 kg-m, 22 ft-lb).**
- e) **Turn bolts 50 to 55 degrees clockwise or if angle wrench is not available, tighten bolts to 59±4.9 N·m (6±0.5 kg-m, 43±3.6 ft-lb).**
- f) **Tightening bolts (11 - 14) to 6.3 to 8.3 N·m (0.64 to 0.85 kg-m, 55.8 to 73.5 in-lb).**




|                 | Tightening torque N·m (kg-m, ft-lb) |            |          |            |   |
|-----------------|-------------------------------------|------------|----------|------------|---|
|                 | a                                   | b          | c        | d          | e, f  |
| Bolts (1 - 10)  | 29 (3, 22)                          | 59 (6, 43) | 0 (0, 0) | 29 (3, 22) | 50 - 55 degrees or 59±4.9 (6±0.5, 43±3.6 ft-lb) |
| Bolts (11 - 14) | —                                   | —          | —        | —          | 6.3 - 8.3 (0.64 - 0.85, 55.8 - 73.5 in-lb)      |



4. Install camshaft.




- **Make sure camshafts are aligned as shown in figure.**



5. Install camshaft brackets.

- **Make sure camshaft brackets are aligned as marked during disassembly.**



- Apply new engine oil to bolt threads and seat surface.
- Tighten camshaft bracket bolts in the following steps.
  - a) **a** Tighten bolts 9 - 12, then 1 - 8.
    - ☞ 2.0 N·m (0.204 kg-m, 17.7 in-lb)
  - b) **b** Tighten bolts 1 - 12.
    - ☞ 5.9 N·m (0.60 kg-m, 52.2 in-lb)
  - c) **c** Tighten bolts 1 - 12.
    - ☞ 9.0 - 11.8 N·m (0.91 - 1.20 kg-m, 79 - 104 in-lb)
- If any part of valve assembly or camshaft is replaced, check valve clearance according to reference data. After completing assembly check valve clearance. Refer to "Valve Clearance", EM-45.


### Reference data valve clearance (Cold):

#### Intake


0.25 - 0.33 mm (0.010 - 0.013 in)

#### Exhaust


0.32 - 0.40 mm (0.013 - 0.016 in)



6. Install camshaft sprocket.
  - Set timing chain by aligning mating marks with those of camshaft sprockets.




7. Install camshaft sprocket bolts to correct torque. Refer to "Components", EM-20.
  - Apply new engine oil to bolt threads and seat surface.




8. Install chain tensioner.
  - Before installing chain tensioner, insert a suitable pin into pin hole of chain tensioner.
  - After installing chain tensioner, remove the pin.
9. Install timing chain guide.


Installation (Cont'd)




10. Install cylinder head front cover.
  - Apply RTV Silicone Sealant to cylinder head front cover.
  - Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.




11. Install camshaft position sensor (PHASE).



12. Before installing rocker cover, apply a bead of Genuine RTV Silicone Sealant Part No. 999MP-A7007 to mating surface of cylinder head as shown.



13. Install rocker cover with rocker cover gasket and tighten bolts in numerical order as shown in the figure.
14. Install spark plugs.
15. Install ignition coils.
16. Install exhaust manifold.
17. Install intake manifold rear supports.



18. Connect the following components.
  - EGR tube
  - Ignition coils
  - Fuel injector connectors
  - Ground harness
  - Breather pipe
  - Harness connectors for:
    - IACV-AAC valve
    - Throttle position sensor
    - Throttle position switch

- EGR temperature sensor
  - Water hoses from collector
  - Heater hoses
  - PCV hose
- Vacuum hoses for:
- EVAP canister
  - Power brake booster
  - Fuel pressure regulator
19. Install front exhaust tube.
  20. Install front engine side covers.
  21. Install air duct to intake manifold collector.
  22. Drive belts.  
For adjusting drive belt deflection, refer to **MA-16**, "Checking Drive Belts".
  23. Install fuel pump fuse. Erase DTC if any DTC appears. Refer to **EC-98**[QG18DE (except Calif. CAModel)] or **EC-770**[QG18DE (Calif. CA Model)], "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".

GI

MA

**EM**


LC

EC

FE

CL

MT



## Valve Clearance

### CHECKING

NIEM0060

AT

NIEM0060S01

**Check valve clearance while engine is warm and not running.**

1. Remove rocker cover.
2. Remove all spark plugs.
3. Set No. 1 cylinder at TDC on its compression stroke.
  - Align pointer with TDC mark on crankshaft pulley.
  - Check that valve lifters on No. 1 cylinder are loose and valve lifters on No. 4 are tight.
- If not, turn crankshaft one revolution (360°) and align as described above.

AX

SU


BR

ST

RS

BT

HA




4. Check only those valves shown in the figure.

SC

EL

IDX

## Valve Clearance (Cont'd)



- Using a feeler gauge, measure clearance between valve lifter and camshaft.
- Record any valve clearance measurements which are out of specification. They will be used later to determine the required replacement adjusting shim.


### Valve clearance for checking (Hot):

#### Intake


**0.21 - 0.47 mm (0.008 - 0.019 in)**

#### Exhaust

**0.30 - 0.56 mm (0.012 - 0.022 in)**



5. Turn crankshaft one revolution (360°) and align mark on crankshaft pulley with pointer.
6. Check only those valves shown in the figure.
  - Use the same procedure as mentioned in step 4.
7. If all valve clearances are within specification, install the following parts:
  - Rocker cover
  - All spark plugs



## ADJUSTING

NIEM0060S02


### Adjust valve clearance while engine is cold.

1. Turn crankshaft. Position cam lobe upward on camshaft for valve that must be adjusted.
2. Place Tool (1) around camshaft as shown in figure.


**Before placing Tool (1), rotate notch toward center of cylinder head. (See figure.) This will simplify shim removal later.**

### CAUTION:

**Be careful not to damage cam surface with Tool (1).**



3. Rotate Tool (1) so that valve lifter is pushed down.



4. Place Tool (2) between camshaft and valve lifter to retain valve lifter.

### CAUTION:






- Tool (2) must be placed as close to camshaft bracket as possible.
- Be careful not to damage cam surface with Tool (2).

5. Remove Tool (1).

# CYLINDER HEAD

**QG18DE**

Valve Clearance (Cont'd)



6. Remove adjusting shim using a small screwdriver and a magnetic finger.
7. Determine replacement adjusting shim size using the following formula.

- Use a micrometer to determine thickness of removed shim.
- Calculate thickness of new adjusting shim so valve clearance comes within specified values.  
 $R$  = Thickness of removed shim  
 $N$  = Thickness of new shim  
 $M$  = Measured valve clearance

**Intake:**

$$N = R + [M - 0.37 \text{ mm (0.0146 in)}]$$

**Exhaust:**

$$N = R + [M - 0.40 \text{ mm (0.0157 in)}]$$

Shims are available in 50 sizes from 2.00 mm (0.0787 in) to 2.98 mm (0.1173 in), in steps of 0.02 mm (0.0008 in).

- Select the closest size shim to the calculated thickness. Refer to chart in "AVAILABLE SHIMS", EM-68.

8. Install new shim using a suitable tool.
- **Install with the surface on which the thickness is stamped facing down.**

9. Place Tool (1) as explained in steps 2 and 3.
10. Remove Tool (2).
11. Remove Tool (1).
12. Recheck valve clearance.

**Valve clearance:**

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# CYLINDER HEAD

**QG18DE**

Valve Clearance (Cont'd)

Unit: mm (in)

|         | For adjusting               |                             | For checking                |
|---------|-----------------------------|-----------------------------|-----------------------------|
|         | Hot                         | Cold* (reference data)      | Hot                         |
| Intake  | 0.32 - 0.40 (0.013 - 0.016) | 0.25 - 0.33 (0.010 - 0.013) | 0.21 - 0.47 (0.008 - 0.019) |
| Exhaust | 0.37 - 0.45 (0.015 - 0.018) | 0.32 - 0.40 (0.013 - 0.016) | 0.30 - 0.56 (0.012 - 0.022) |

\*: At a temperature of approximately 20°C (68°F)


**Whenever valve clearances are adjusted to cold specifications, check that the clearances satisfy hot specifications and adjust again if necessary.**



## Removal and Installation

NIEM0063

SEC. 112



: N-m (kg-m, ft-lb)

WEM025

- |                               |                                 |                                  |
|-------------------------------|---------------------------------|----------------------------------|
| 1. RH engine mounting         | 4. Rear engine mounting bracket | 7. Center member                 |
| 2. RH engine mounting bracket | 5. Rear engine mounting         | 8. Front engine mounting         |
| 3. LH engine mounting         | 6. Dynamic damper               | 9. Front engine mounting bracket |

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

**WARNING:**

- Position vehicle on a flat and solid surface.
- Place chocks at front and back of rear wheels.
- Do not remove engine until exhaust system has completely cooled off, otherwise, you may burn yourself and/or fire may break out in fuel line.
- Before disconnecting fuel hose, release pressure. Refer to *EC-67*[QG18DE (except Calif. CA Model)], or *EC-744* [QG18DE (Calif. CA Model)], "Fuel Pressure Release".
- Be sure to lift engine and transaxle in a safe manner.
- For engines not equipped with engine slingers, attach proper slingers and bolts described in PARTS CATALOG.

**CAUTION:**


- When lifting engine, be sure to clear surrounding parts. Use special care near accelerator wire casing, brake lines and brake master cylinder.
- When lifting the engine, always use engine slingers in a safe manner.
- When removing drive shaft, be careful not to damage grease seal of transaxle.
- Before separating engine and transaxle, remove crankshaft position sensor (POS) from the cylinder block assembly.
- Always be extra careful not to damage edge of crankshaft position sensor (POS), or signal plate teeth.

Engine cannot be removed separately from transaxle. Remove engine with transaxle as an assembly.

**REMOVAL**

1. Refer to *EC-67* [QG18DE (except Calif. CA Model)], or <sup>NIEM0063S01</sup>*EC-744* [QG18DE (Calif. CA Model)], "Fuel Pressure Release".
2. Drain coolant from radiator and cylinder block. Refer to *MA-17*, "Changing Engine Coolant".
3. Remove coolant reservoir tank.
4. Drain engine oil.
5. Remove battery and battery tray.
6. Remove air cleaner and air duct.
7. Remove drive belts.
8. Remove generator and air conditioner compressor from engine.
9. Remove power steering oil pump from engine and position aside.


Power steering oil pump does not need to be disconnected from power steering tubes.




10. Remove the following parts:

- RH and LH front tires
- Front splash undercovers
- RH & LH drive shaft. Refer to **AX-12**, "REMOVAL".

**When removing drive shaft, be careful not to damage transaxle side grease seal.**



- Disconnect control rod and support rod from transaxle. (M/T models.) Refer to **MT-16**, "Transaxle Gear Control".
- Disconnect control cable from transaxle. (A/T models.) Refer to **AT-434**, "Control Cable Adjustment".



- Center member
- Front exhaust tube
- Stabilizer bar
- Cooling fan
- Radiator
- EGR tube
- Fuel injector connectors
- Ground harness
- Breather pipe
- Harness connectors for:
  - IACV-AAC valve
  - Throttle position sensor
  - Throttle position switch
  - EGR temperature sensor
  - Heated oxygen sensors
  - Water hoses from collector
  - Heater hoses
  - PCV hose
  - Vacuum hoses for:
    - EVAP canister
    - Power brake booster
    - Fuel pressure regulator

11. Lift up engine slightly and disconnect or remove all engine mountings.

**When lifting engine, be sure to clear surrounding parts. Use special care near brake tubes and brake master cylinder.**

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

12. Remove engine with transaxle as shown.




## INSTALLATION

- Install in reverse order of removal.

NIEM0063S02

## Components

### SEC. 110•120•226



: N•m (kg-m, in-lb)

: N•m (kg-m, ft-lb)

: Use Genuine RTV Silicone Sealant  
Part No. 999MP-A7007 or equivalent.

: Lubricate with new engine oil.

1. Oil level gauge guide
2. Cylinder block
3. Rear oil seal retainer
4. Rear oil seal
5. Rear plate
6. Flywheel

7. Drain plug
8. Baffle plate
9. Top ring
10. 2nd ring
11. Oil ring
12. Piston

13. Snap ring
14. Piston pin
15. Connecting rod
16. Connecting rod bearing
17. Connecting rod cap
18. Key

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

## Components (Cont'd)


|                      |                                      |  |
|----------------------|--------------------------------------|--|
| 19. Main bearing     | 23. Knock sensor                     | 27. Signal plate                           |
| 20. Thrust bearing   | 24. Crankshaft position sensor (POS) | 28. Block heater (Canada only)             |
| 21. Crankshaft       | 25. Rear lower plate                 | 29. Connector protective cap (Canada only) |
| 22. Main bearing cap | 26. Drive plate                      |  |

## Removal and Installation

NIEM0065

### CAUTION:

- When installing sliding parts such as bearings and pistons, apply engine oil on the sliding surfaces.
- Place removed parts, such as bearings and bearing caps, in their proper order and direction.
- When installing connecting rod nuts and main bearing cap bolts, apply new engine oil to threads and seating surfaces.
- Do not allow any magnetic materials to contact the signal plate teeth of flywheel or drive plate, and rear plate.
- Remove the crankshaft position sensor (POS).
- Be careful not to damage sensor edges and signal plate teeth.




## Disassembly

### PISTON AND CRANKSHAFT

NIEM0066

NIEM0066S01


1. Place engine on a work stand.
2. Drain coolant and oil.
3. Remove timing chain.  
Refer to "Components", EM-20.




4. Remove pistons with connecting rod.
  - When disassembling piston and connecting rod, remove snap ring first. Then heat piston to 60 to 70°C (140 to 158°F) or use piston pin press stand at room temperature.

### CAUTION:


- When piston rings are not replaced, make sure that piston rings are mounted in their original positions.
- When replacing piston rings, if there is no punch mark, install with either side up.



5. Loosen main bearing caps in numerical order as shown in figure.
6. Remove bearing caps, main bearings and crankshaft.
  - Before removing bearing caps, measure crankshaft end play. Refer to "CRANKSHAFT", EM-63.
  - Bolts should be loosened in two or three steps.



7. Remove signal plate from crankshaft.




## Inspection

### PISTON AND PISTON PIN CLEARANCE

1. Measure inner diameter of piston pin hole "dp".

**Standard diameter "dp":**

**18.993 - 19.005 mm (0.7478 - 0.7482 in)**



2. Measure outer diameter of piston pin "Dp".


**Standard diameter "Dp":**

**18.989 - 19.001 mm (0.7476 - 0.7481 in)**

3. Calculate piston pin clearance.

**Dp - dp: 0.002 - 0.006 (0.0001 - 0.0002 in)**

If it exceeds the above value, replace piston assembly with pin.



### PISTON RING SIDE CLEARANCE

**Side clearance:**

**Top ring**

**0.045 - 0.080 mm (0.0018 - 0.0031 in)**

**2nd ring**

**0.030 - 0.070 mm (0.0012 - 0.0028 in)**


**Oil ring**

**0.065 - 0.135 mm (0.0026 - 0.0053 in)**

**Max. limit of side clearance:**

**0.2 mm (0.008 in)**

If out of specification, replace piston and/or piston ring assembly.



## PISTON RING END GAP

NIEM0067S03

### End gap:

- Top ring 0.20 - 0.39 mm (0.0079 - 0.0154 in)
- 2nd ring 0.32 - 0.56 mm (0.0126 - 0.0220 in)
- Oil ring 0.20 - 0.69 mm (0.0079 - 0.0272 in)


### Max. limit of ring gap:

- Top ring 0.49 mm (0.0193 in)
- 2nd ring 0.64 mm (0.0252 in)
- Oil ring 1.09 mm (0.0429 in)

If out of specification, replace piston ring. If gap exceeds maximum limit with a new ring, rebore cylinder and use oversized piston and piston rings.

Refer to "Piston, Piston Ring and Piston Pin", EM-73.

- When replacing the piston, check the cylinder block surface for scratches or seizure. If scratches or seizure is found, hone or replace the cylinder block.



## CONNECTING ROD BEND AND TORSION

NIEM0067S04


### Bend:

- Limit 0.15 mm (0.0059 in)
- per 100 mm (3.94 in) length


### Torsion:

- Limit 0.3 mm (0.012 in)
- per 100 mm (3.94 in) length

If it exceeds the limit, replace connecting rod assembly.







SEM486C

## CYLINDER BLOCK DISTORTION AND WEAR

NIEM0067S05

Clean upper surface of cylinder block.

Use a reliable straightedge and feeler gauge to check the flatness of cylinder block surface. Check along six positions shown in figure.

### Block surface flatness:

**Standard Less than 0.03 mm (0.0012 in)**

**Limit 0.10 mm (0.004 in)**

If out of specification, resurface it.

The limit for cylinder block resurfacing is determined by the amount of cylinder head resurfacing.

**Amount of cylinder head resurfacing is "A".**

**Amount of cylinder block resurfacing is "B".**


**The maximum limit is as follows:**

**A + B = 0.2 mm (0.008 in)**


**Nominal cylinder block height from crankshaft center:**

**213.95 - 214.05 mm (8.4232 - 8.4271 in)**

If necessary, replace cylinder block.



SEM102F



SEM166D

## PISTON-TO-BORE CLEARANCE

NIEM0067S06

1. Using a bore gauge, measure cylinder bore for wear, out-of-round and taper.

**Standard inner diameter (Grade No. 1):**

**80.000 - 80.010 mm (3.1496 - 3.1500 in)**

**Wear limit:**

**0.2 mm (0.008 in)**

**Out-of-round (X - Y) standard:**

**Less than 0.015 mm (0.0006 in)**


**Taper (A - B) standard:**

**Less than 0.01 mm (0.0004 in)**


If it exceeds the limit, rebore all cylinders. Replace cylinder block if necessary.

2. Check for score and seizure. If seizure is found, hone it.

• **If cylinder block or piston is replaced, match piston grade with grade number on cylinder block lower surface.**



SEM929F



SEM258C

3. Measure piston skirt diameter.

**Piston diameter "A":**

**Refer to "Piston, Piston Ring and Piston Pin", EM-73.**

**Measuring point "a" (Distance from the top):**

**42.3 mm (1.665 in)**

4. Check that piston-to-bore clearance is within specification.

**Piston-to-bore clearance = cylinder bore measurement "B" - Piston diameter "A":**

**0.025 - 0.045 mm (0.0010 - 0.0018 in)**

5. Determine piston oversize according to amount of cylinder wear.
  - **Oversize pistons are available for service. Refer to "Piston", EM-73.**

6. Cylinder bore size is determined by adding piston-to-bore clearance to piston diameter "A".

**Rebored size calculation:**

$$D = A + B - C$$

where,


**D: Bored diameter**

**A: Piston diameter as measured**

**B: Piston-to-bore clearance**

**C: Honing allowance 0.02 mm (0.0008 in)**

7. Install main bearing caps and tighten bolts to the specified torque. This will prevent distortion of cylinder bores.
8. Cut cylinder bores.
  - **When any cylinder needs boring, all other cylinders must also be bored.**
  - **Do not cut too much out of cylinder bore at a time. Cut only 0.05 mm (0.0020 in) or so at a time.**
9. Hone cylinders to obtain specified piston-to-bore clearance.
10. Measure finished cylinder bore for out-of-round and taper.
  - **Measurement should be done after cylinder bore cools down.**



## CRANKSHAFT

NIEM0067S07

1. Check crankshaft main and pin journals for score, wear or cracks.
2. With a micrometer, measure journals for taper and out-of-round.

**Out-of-round, Standard (X - Y):**

**Less than 0.003 mm (0.0001 in)**


**Taper, Standard (A - B):**


**Less than 0.004 mm (0.0002 in)**

3. Measure crankshaft runout.

**Runout, Standard (Total indicator reading):**

**Less than 0.04 mm (0.0016 in)**





SEM366E

## BEARING CLEARANCE

NIEM0067S08


- Use Method A or Method B. Method A is preferred because it is more accurate.

### Method A (Using bore gauge and micrometer)

#### Main bearing

NIEM0067S0801

- Set main bearings in their proper positions on cylinder block and main bearing cap.




AEM153

- Install main bearing cap to cylinder block.

**Tighten all bolts in correct order in two or three stages. Refer to "CRANKSHAFT", EM-63.**

- Measure inner diameter "A" of each main bearing.



AEM026

- Measure outer diameter "Dm" of each main journal in crankshaft.
- Calculate main bearing clearance.


$$\text{Main bearing clearance} = A - Dm$$

**Standard: 0.018 - 0.042 mm (0.0007 - 0.0017 in)**

**Limit: 0.1 mm (0.004 in)**

If it exceeds the limit, replace bearing.

If clearance cannot be adjusted within standard of any bearing, grind crankshaft journal and use undersized bearing.




SEM588A

#### When grinding crank pin and crank journal:

- Grind until clearance is within specified standard bearing clearance.
- Fillets should be finished as shown in the figure. R: 2.3 - 2.5 mm (0.091 - 0.098 in)

Refer to "Bearing Clearance", EM-76 for standard bearing clearance and available spare parts.




SEM930F


- If the crankshaft is replaced, select thickness of main bearings as follows:

- Grade number of each cylinder block main journal is punched on the respective cylinder block. These numbers are punched in either Arabic or Roman numerals.


Inspection (Cont'd)




AEM172




SEM194C



AEM027



AEM028



SEM437CA

- b. Grade number of each crankshaft main journal is punched on the respective crankshaft. These numbers are punched in either Arabic or Roman numerals.
- c. Select main bearing with suitable thickness according to the following table.

**Main bearing grade color:**

| Crankshaft main journal grade number | Cylinder block main journal grade number |            |            |
|--------------------------------------|--|------------|------------|
|                                      | 0  | 1 or I     | 2 or II    |
| 0                                    | 0 (Black)                                | 1 (Brown)  | 2 (Green)  |
| 1 or I                               | 1 (Brown)                                | 2 (Green)  | 3 (Yellow) |
| 2 or II                              | 2 (Green)                                | 3 (Yellow) | 4 (Blue)   |

For example:  
 Cylinder block main journal grade number: 1  
 Crankshaft main journal grade number: 2  
 Main bearing grade number = 1 + 2 = 3 (Yellow)

**Connecting Rod Bearing (Big End)**

NIEM0067S0802

- 1. Install connecting rod bearing to connecting rod and cap.
- 2. Install connecting rod cap to connecting rod.

**Tighten bolts to the specified torque.**

- 3. Measure inner diameter "C" of each bearing.

- 4. Measure outer diameter "Dp" of each crankshaft pin journal.
- 5. Calculate connecting rod bearing clearance.

**Connecting rod bearing clearance = C - Dp**  
**Standard: 0.014 - 0.039 mm (0.0006 - 0.0015 in)**  
**Limit: 0.1 mm (0.004 in)**


If it exceeds the limit, replace bearing.  
 If clearance cannot be adjusted using any standard bearing grade, grind crankshaft journal and use undersized bearing. Refer to "BEARING CLEARANCE, step 5", EM-59.

- If a new bearing, crankshaft or connecting rod is replaced, select connecting rod bearing according to the following table.


**Connecting rod bearing grade number:**

These numbers are punched in either Arabic or Roman numerals.


| Crankshaft pin journal grade number | Connecting rod bearing grade color |
|-------------------------------------|------------------------------------|
| 0                                   | —                                  |
| 1                                   | Brown                              |
| 2                                   | Green                              |


**Method B (Using Plastigage)**
**CAUTION:**

- Do not turn crankshaft or connecting rod while Plastigage is being inserted.
- If incorrect bearing clearance exists, use a thicker or undersized main bearing to ensure specified clearance.


**CONNECTING ROD BUSHING CLEARANCE (SMALL END)**
*NIEM0067S09*

- Measure inner diameter "C" of bushing.




- Measure outer diameter "Dp" of piston pin.
- Calculate piston pin to connecting rod bushing clearance.

$$\text{Piston pin to connecting rod bushing clearance} = C - Dp$$

**Standard:**
**0.005 - 0.017 mm (0.0002 - 0.0007 in)**
**Limit:**
**0.023 mm (0.0009 in)**


If it exceeds the limit, replace connecting rod assembly or connecting rod bushing and/or piston pin.


**REPLACEMENT OF CONNECTING ROD BUSHING (SMALL END)**
*NIEM0067S10*

- Drive in small end bushing until it is flush with end surface of rod.

**Be sure to align the oil holes.**


- Ream the bushing so that clearance with piston pin is within specification.

**Piston pin to connecting rod bushing clearance:**
**0.005 - 0.017 mm (0.0002 - 0.0007 in)**

**FLYWHEEL/DRIVE PLATE RUNOUT**
*NIEM0067S11*
**Runout (Total indicator reading):**
**Flywheel (M/T models)**
**Less than 0.15 mm (0.0059 in)**
**Drive plate (A/T models)\***
**Less than 0.2 mm (0.008 in)**

\*Measuring points: Approximately 115 mm (4.53 in) from crankshaft center

**CAUTION:**

- Do not allow any magnetic materials to contact the ring gear teeth and rear plate.
- Do not resurface flywheel. Replace as necessary.




## Assembly PISTON

NIEM0068


NIEM0068S01

1. Install new snap ring on one side of piston pin hole.



2. Heat piston to 60 to 70°C (140 to 158°F) and assemble piston, piston pin, connecting rod and new snap ring.


- Align the direction of piston and connecting rod.
- Numbers stamped on connecting rod and cap correspond to each cylinder.
- After assembly, make sure connecting rod swings smoothly.




3. Set piston rings as shown.

**CAUTION:**

- When piston rings are not replaced, make sure that piston rings are mounted in their original position.
- Install new piston rings either side up if there is no punch mark.



- Align piston rings so that end gaps are positioned as shown.



## CRANKSHAFT

NIEM006BS02

1. Install signal plate to crankshaft using dowel pin to properly position the signal plate. Remove the dowel pin after the signal plate bolts are tightened.




- Tighten bolts to 7.64 - 9.22 N·m (0.78 - 0.94 kg·m, 67.7 - 81.6 in·lb)

**Dowel pin diameter: 6 mm (3/16 in)**

2. Set main bearings in their proper positions on cylinder block and main bearing cap.


- **Confirm that correct main bearings are selected by using Method A or Method B. Refer to "BEARING CLEARANCE", EM-59.**

- **Apply new engine oil to bearing surfaces.**



3. Install crankshaft and main bearing caps and tighten bolts to the specified torque.

- **Apply new engine oil to the bolt thread and seat surface.**
- **Prior to tightening bearing cap bolts, shift crankshaft back and forth to properly seat the bearing caps.**
- **Tighten bearing cap bolts gradually in two or three stages. Start with center bearing and move outward as shown in figure.**
- **After securing bearing cap bolts, make sure crankshaft turns smoothly by hand.**



4. Measure crankshaft end play.

**Crankshaft end play:**

**Standard**

**0.060 - 0.220 mm (0.0024 - 0.0087 in)**

**Limit**

**0.3 mm (0.012 in)**

**If beyond the limit, replace thrust bearing with new ones.**

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT






HA

SC

EL

IDX

Assembly (Cont'd)



5. Install connecting rod bearings in connecting rods and connecting rod caps.
  - Confirm that correct bearings are used. Refer to “Connecting Rod Bearing (Big End)”, EM-60.
  - Install bearings so that oil hole in connecting rod aligns with oil hole of bearing.
  - Apply new engine oil to bolt threads and bearing surfaces.
  
6. Install pistons with connecting rods.
  - a. Install them into corresponding cylinders with Tool.
    - Make sure connecting rod does not scratch cylinder wall.
    - Make sure connecting rod bolts do not scratch crankshaft pin journals.
    - Arrange so that front mark on piston head faces engine.
    - Apply new engine oil to piston rings and sliding surface of piston.
  - b. Install connecting rod caps. Apply new engine oil to bolt threads and nut seating surfaces. Tighten connecting rod cap nuts in the following procedure:
    - Tighten to 13.72 to 15.68 N-m (1.399 to 1.599 kg-m, 10.120 - 11.566 ft-lb).
    - Turn nuts to 35° to 40° degrees clockwise with an angle wrench. If an angle wrench is not available, tighten nuts to 23 to 28 N-m (2.3 to 2.9 kg-m, 17 to 21 ft-lb).
  
7. Measure connecting rod side clearance.
 

**Connecting rod side clearance:**

**Standard**  
0.200 - 0.470 mm (0.0079 - 0.0185 in)

**Limit**  
0.52 mm (0.0205 in)


If beyond the limit, replace connecting rod and/or crankshaft.
  
8. Install rear oil seal retainer.
  - a. Before installing rear oil seal retainer, remove old RTV Silicone Sealant from cylinder block and retainer.
  - b. Apply a continuous bead of RTV Silicone Sealant to rear oil seal retainer.
    - Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.
    - Apply around inner side of bolt holes.
9. Install crankshaft position sensor (POS).



# CYLINDER BLOCK

**QG18DE**

Assembly (Cont'd)



10. Install knock sensor at correct angle at the correct angle.

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

## General Specifications

NIEM0069

|   |             |                             |
|---|-------------|-----------------------------|
| Engine                                  |             | QG18DE                      |
| Classification                          |             | Gasoline                    |
| Cylinder arrangement                    |             | 4, in-line                  |
| Displacement<br>cm <sup>3</sup> (cu in) |             | 1,769 (107.94)              |
| Bore × stroke<br>mm (in)                |             | 80.0 x 88.0 (3.150 x 3.465) |
| Valve arrangement                       |             | DOHC                        |
| Firing order                            |             | 1-3-4-2                     |
| Number of piston rings                  | Compression | 2                           |
|   | Oil         | 1                           |
| Number of main bearings                 |             | 5                           |
| Compression ratio                       |             | 9.5                         |


EM120

|              | a    | b    | c         | d         | e  | f   |
|--------------|------|------|-----------|-----------|----|-----|
| Valve timing | 222° | 236° | -1° (19°) | 57° (37°) | 4° | 38° |

( ) : Intake valve timing control ON

## Compression Pressure

NIEM0070  
 Unit: kPa (bar, kg/cm<sup>2</sup>, psi)/350 rpm

|                                    |                          |
|------------------------------------|--------------------------|
| Standard                           | 1,324 (13.24, 13.5, 192) |
| Minimum                            | 1,157 (11.57, 11.5, 168) |
| Difference limit between cylinders | 98 (0.98, 1.0, 14)       |

## Cylinder Head

NIEM0071  
 Unit: mm (in)


|                       | Standard                      | Limit       |
|-----------------------|-------------------------------|-------------|
| Head surface flatness | Less than 0.03 (0.0012)       | 0.1 (0.004) |
| Height                | 117.8 - 118.0 (4.638 - 4.646) | —           |

Valve

VALVE

NIEM0072

NIEM0072S01  
Unit: mm (in)



SEM188A

|                                       |         |                                 |
|---------------------------------------|---------|---------------------------------|
| Valve head diameter "D"               | Intake  | 29.9 - 30.2 (1.177 - 1.189)     |
|                                       | Exhaust | 24.9 - 25.2 (0.980 - 0.992)     |
| Valve length "L"                      | Intake  | 92.00 - 92.50 (3.6220 - 3.6417) |
|                                       | Exhaust | 92.37 - 92.87 (3.6366 - 3.6563) |
| Valve stem diameter "d"               | Intake  | 5.465 - 5.480 (0.2152 - 0.2157) |
|                                       | Exhaust | 5.445 - 5.460 (0.2144 - 0.2150) |
| Valve face angle "α"                  |         | 45°15' - 45°45'                 |
| Valve margin "T" limit                |         | 1.05 - 1.35 (0.0413 - 0.0531)   |
| Valve stem end surface grinding limit |         | 0.2 (0.008)                     |

VALVE SPRING

NIEM0072S02

|                                       |          |  |
|---------------------------------------|----------|--|
| Free height<br>mm (in)                |          | 41.19 (1.622)                          |
| Pressure N (kg, lb) at height mm (in) | Standard | 370.0 (37.73, 83.19) at 23.64 (0.9307) |
|                                       | Limit    | 347.8 (35.46, 78.19) at 23.64 (0.9307) |
| Out-of-square mm (in)                 |          | Less than 1.75 (0.0689)                |

VALVE LIFTER

NIEM0072S03  
Unit: mm (in)

|   |                                   |
|---|-----------------------------------|
| Valve lifter outside diameter                         | 29.960 - 29.975 (1.1795 - 1.1801) |
| Lifter guide inside diameter                          | 30.000 - 30.021 (1.1811 - 1.1819) |
| Clearance between valve lifter and valve lifter guide | 0.025 - 0.065 (0.0010 - 0.0026)   |

VALVE CLEARANCE

NIEM0072S04  
Unit: mm (in)

|         | For adjusting               |                             | For checking                |
|---------|-----------------------------|-----------------------------|-----------------------------|
|         | Hot                         | Cold* (reference data)      | Hot                         |
| Intake  | 0.32 - 0.40 (0.013 - 0.016) | 0.25 - 0.33 (0.010 - 0.013) | 0.21 - 0.47 (0.008 - 0.019) |
| Exhaust | 0.37 - 0.45 (0.015 - 0.018) | 0.32 - 0.40 (0.013 - 0.016) | 0.30 - 0.56 (0.012 - 0.022) |

\*: At a temperature of approximately 20°C (68°F)

Whenever valve clearances are adjusted to cold specifications, check that the clearances satisfy hot specifications and adjust again if necessary.


# SERVICE DATA AND SPECIFICATIONS (SDS)

**QG18DE**

Valve (Cont'd)

## VALVE GUIDE

NIEM0072S05  
Unit: mm (in)




MEM096A

|   |                                | Intake                          |                                 | Exhaust                         |                                 |
|---|--------------------------------|---------------------------------|---------------------------------|---------------------------------|---------------------------------|
|   |                                | Standard                        | Service                         | Standard                        | Service                         |
| Valve guide                                 | Outer diameter                 | 9.523 - 9.534 (0.3749 - 0.3754) | 9.723 - 9.734 (0.3828 - 0.3832) | 9.523 - 9.534 (0.3749 - 0.3754) | 9.723 - 9.734 (0.3828 - 0.3832) |
|   | Inner diameter [Finished size] | 5.500 - 5.515 (0.2165 - 0.2171) |                                 | 5.500 - 5.515 (0.2165 - 0.2171) |                                 |
| Cylinder head valve guide hole diameter     |                                | 9.475 - 9.496 (0.3730 - 0.3739) | 9.685 - 9.696 (0.3813 - 0.3817) | 9.475 - 9.496 (0.3730 - 0.3739) | 9.685 - 9.696 (0.3813 - 0.3817) |
| Interference fit of valve guide             |                                | 0.027 - 0.059 (0.0011 - 0.0023) | 0.027 - 0.049 (0.0011 - 0.0019) | 0.027 - 0.059 (0.0011 - 0.0023) | 0.027 - 0.049 (0.0011 - 0.0019) |
| Stem to guide clearance                     |                                | 0.020 - 0.050 (0.0008 - 0.0020) |                                 | 0.040 - 0.070 (0.0016 - 0.0028) |                                 |
| Valve deflection limit (Dial gauge reading) |                                | 0.2 (0.008)                     |                                 |                                 |                                 |
| Projection length "L"                       |                                | 11.5 - 11.7 (0.453 - 0.461)     |                                 |                                 |                                 |

## AVAILABLE SHIMS

NIEM0072S06



AEM236

| Thickness mm (in) | Identification mark |
|-------------------|---------------------|
| 2.00 (0.0787)     | 200                 |
| 2.02 (0.0795)     | 202                 |
| 2.04 (0.0803)     | 204                 |
| 2.06 (0.0811)     | 206                 |
| 2.08 (0.0819)     | 208                 |
| 2.10 (0.0827)     | 210                 |
| 2.12 (0.0835)     | 212                 |
| 2.14 (0.0843)     | 214                 |
| 2.16 (0.0850)     | 216                 |

# SERVICE DATA AND SPECIFICATIONS (SDS)

**QG18DE**  
Valve (Cont'd)

|               |     |           |
|---------------|-----|-----------|
| 2.18 (0.0858) | 218 |           |
| 2.20 (0.0866) | 220 | GI        |
| 2.21 (0.0870) | 221 |           |
| 2.22 (0.0874) | 222 | MA        |
| 2.23 (0.0877) | 223 |           |
| 2.24 (0.0882) | 224 | <b>EM</b> |
| 2.25 (0.0885) | 225 |           |
| 2.26 (0.0890) | 226 | LC        |
| 2.27 (0.0893) | 227 |           |
| 2.28 (0.0898) | 228 | EC        |
| 2.29 (0.0901) | 229 |           |
| 2.30 (0.0906) | 230 | FE        |
| 2.31 (0.0909) | 231 |           |
| 2.32 (0.0913) | 232 | CL        |
| 2.33 (0.0917) | 233 |           |
| 2.34 (0.0921) | 234 | MT        |
| 2.35 (0.0925) | 235 |           |
| 2.36 (0.0929) | 236 | AT        |
| 2.37 (0.0933) | 237 |           |
| 2.38 (0.0937) | 238 | AX        |
| 2.39 (0.0940) | 239 |           |
| 2.40 (0.0945) | 240 | SU        |
| 2.41 (0.0948) | 241 |           |
| 2.42 (0.0953) | 242 | BR        |
| 2.43 (0.0956) | 243 |           |
| 2.44 (0.0961) | 244 | ST        |
| 2.45 (0.0964) | 245 |           |
| 2.46 (0.0969) | 246 | RS        |
| 2.47 (0.0972) | 247 |           |
| 2.48 (0.0976) | 248 | BT        |
| 2.49 (0.0980) | 249 |           |
| 2.50 (0.0984) | 250 | HA        |
| 2.51 (0.0988) | 251 |           |
| 2.52 (0.0992) | 252 | SC        |
| 2.53 (0.0996) | 253 |           |
| 2.54 (0.1000) | 254 | EL        |
| 2.55 (0.1003) | 255 |           |
| 2.56 (0.1008) | 256 | IDX       |
| 2.57 (0.1011) | 257 |           |
| 2.58 (0.1016) | 258 |           |
| 2.59 (0.1019) | 259 |           |

# SERVICE DATA AND SPECIFICATIONS (SDS)

QG18DE

Valve (Cont'd)



|               |     |
|---------------|-----|
| 2.60 (0.1024) | 260 |
| 2.61 (0.1027) | 261 |
| 2.62 (0.1031) | 262 |
| 2.63 (0.1035) | 263 |
| 2.64 (0.1039) | 264 |
| 2.65 (0.1043) | 265 |
| 2.66 (0.1047) | 266 |
| 2.68 (0.1055) | 268 |
| 2.70 (0.1063) | 270 |
| 2.72 (0.1071) | 272 |
| 2.74 (0.1079) | 274 |
| 2.76 (0.1087) | 276 |
| 2.78 (0.1094) | 278 |
| 2.80 (0.1102) | 280 |
| 2.82 (0.1110) | 282 |
| 2.84 (0.1118) | 284 |
| 2.86 (0.1126) | 286 |
| 2.88 (0.1134) | 288 |
| 2.90 (0.1142) | 290 |
| 2.92 (0.1150) | 292 |
| 2.94 (0.1157) | 294 |
| 2.96 (0.1165) | 296 |
| 2.98 (0.1173) | 298 |

# SERVICE DATA AND SPECIFICATIONS (SDS)



**QG18DE**  
Valve (Cont'd)

## VALVE SEAT

NIEM0072S07  
Unit: mm (in)



\*Cylinder head machining data SEM573DA




\* Cylinder head machining data

WEM047

| Dia. | Specification                     | Dia. | Specification                     |
|------|-----------------------------------|------|-----------------------------------|
| A    | 27.8 - 28.0 (1.094 - 1.102)       | E    | 24.5 - 24.7 (0.965 - 0.972)       |
| B    | 29.5 - 29.7 (1.161 - 1.169)       | F    | 26.500 - 26.516 (1.0433 - 1.0439) |
| C    | 31.9 - 32.1 (1.256 - 1.264)       | G    | 26.2 - 26.4 (1.031 - 1.039)       |
| D    | 31.500 - 31.516 (1.2402 - 1.2408) | H    | 22.4 - 22.6 (0.8819 - 0.8898)     |

## VALVE SEAT RESURFACE LIMIT

NIEM0072S08  
Unit: mm (in)



AEM343

|           |         |                                 |
|-----------|---------|---------------------------------|
| Depth (L) | Intake  | 35.95 - 36.55 (1.4154 - 1.4390) |
|           | Exhaust | 35.92 - 36.52 (1.4142 - 1.4378) |

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

# SERVICE DATA AND SPECIFICATIONS (SDS)


**QG18DE**

Camshaft and Camshaft Bearing

## Camshaft and Camshaft Bearing

NIEM0073  
Unit: mm (in)

|                |         |                                   |
|----------------|---------|-----------------------------------|
| Cam height "A" | Intake  | 40.610 - 40.800 (1.5988 - 1.6063) |
|                | Exhaust | 40.056 - 40.246 (1.5770 - 1.5845) |
| Cam wear limit |         | 0.20 (0.0079)                     |




EM671

|                                       |                | Standard                          | Limit         |
|---------------------------------------|----------------|-----------------------------------|---------------|
| Camshaft journal to bearing clearance |                | 0.045 - 0.086 (0.0018 - 0.0034)   | 0.15 (0.0059) |
| Inner diameter of camshaft bearing    | No. 1          | 28.000 - 28.021 (1.1024 - 1.1032) | —             |
|                                       | No. 2 to No. 5 | 24.000 - 24.021 (0.9449 - 0.9457) |               |
| Outer diameter of camshaft journal    | No. 1          | 27.935 - 27.955 (1.0998 - 1.1006) | —             |
|                                       | No. 2 to No. 5 | 23.935 - 23.955 (0.9423 - 0.9431) |               |
| Camshaft runout [TIR*]                |                | Less than 0.02 (0.0008)           | 0.1 (0.004)   |
| Camshaft end play                     |                | 0.115 - 0.188 (0.0045 - 0.0074)   | 0.20 (0.0079) |

\*Total indicator reading

## Cylinder Block

NIEM0074  
Unit: mm (in)



SEM171D

|                              |  | Standard                          | Limit       |
|------------------------------|--|-----------------------------------|-------------|
| Surface flatness             |  | Less than 0.03 (0.0012)           | 0.1 (0.004) |
| Height "H" (nominal)         |  | 213.95 - 214.05 (8.4232 - 8.4271) | —           |
| Cylinder bore inner diameter | Standard                                       | Grade No. 1                       | 0.2 (0.008) |
|                              |  | Grade No. 2                       |             |
|                              |  | Grade No. 3                       |             |
|                              | Out-of-round (X - Y)                           | Less than 0.015 (0.0006)          | —           |
|                              | Taper (A - B)                                  | Less than 0.01 (0.0004)           | —           |
|                              | Difference in inner diameter between cylinders | 0.05 (0.0020)                     | 0.2 (0.008) |



# SERVICE DATA AND SPECIFICATIONS (SDS)


**QG18DE**

Piston, Piston Ring and Piston Pin

## PISTON

NIEM0075

NIEM0075S01  
Unit: mm (in)



SEM882E

|                                |                                  |             |                                   |
|--------------------------------|----------------------------------|-------------|-----------------------------------|
| Piston skirt diameter "A"      | Standard                         | Grade No. 1 | 79.965 - 79.975 (3.1482 - 3.1486) |
|                                |                                  | Grade No. 2 | 79.975 - 79.985 (3.1486 - 3.1490) |
|                                |                                  | Grade No. 3 | 79.985 - 79.995 (3.1490 - 3.1494) |
|                                | 0.25 (0.0098) oversize (service) |             | 80.215 - 80.245 (3.1581 - 3.1592) |
|                                | 0.5 (0.020) oversize (service)   |             | 80.465 - 80.495 (3.1679 - 3.1691) |
| "a" dimension                  |                                  |             | 42.3 (1.665)                      |
| Piston pin hole inner diameter |                                  |             | 18.993 - 19.005 (0.7478 - 0.7482) |
| Piston to bore clearance       |                                  |             | 0.025 - 0.045 (0.0010 - 0.0018)   |

## PISTON RING

NIEM0075S02  
Unit: mm (in)

|                |     | Standard                        | Limit         |
|----------------|-----|---------------------------------|---------------|
| Side clearance | Top | 0.045 - 0.080 (0.0018 - 0.0031) | 0.2 (0.008)   |
|                | 2nd | 0.030 - 0.070 (0.0012 - 0.0028) |               |
|                | Oil | 0.065 - 0.135 (0.0026 - 0.0053) |               |
| End gap        | Top | 0.20 - 0.39 (0.0079 - 0.0154)   | 0.49 (0.0193) |
|                | 2nd | 0.32 - 0.56 (0.0126 - 0.0220)   | 0.64 (0.0252) |
|                | Oil | 0.20 - 0.69 (0.0079 - 0.0272)   | 1.09 (0.0429) |

## PISTON PIN

NIEM0075S03  
Unit: mm (in)

|  |          |                                   |
|--|----------|-----------------------------------|
| Piston pin outer diameter                                  |          | 18.989 - 19.001 (0.7476 - 0.7481) |
| Piston pin to piston clearance                             |          | 0.002 - 0.006 (0.0001 - 0.0002)   |
| Piston pin to connecting rod bushing clearance (small end) | Standard | 0.005 - 0.017 (0.0002 - 0.0007)   |
|  | Limit    | 0.023 (0.0009)                    |

# SERVICE DATA AND SPECIFICATIONS (SDS)

**QG18DE**

Connecting Rod

## Connecting Rod


Unit: mm (in) <sup>NIEM0076</sup>

|  |          |                                   |
|--|----------|-----------------------------------|
| Center distance                                    |          | 140.45 - 140.55 (5.5295 - 5.5335) |
| Bend limit [per 100 (3.94)]                        |          | 0.15 (0.0059)                     |
| Torsion limit [per 100 (3.94)]                     |          | 0.3 (0.012)                       |
| Connecting rod bushing inner diameter* (small end) |          | 19.000 - 19.012 (0.7480 - 0.7485) |
| Connecting rod big end inner diameter              |          | 43.000 - 43.013 (1.6929 - 1.6934) |
| Side clearance                                     | Standard | 0.200 - 0.470 (0.0079 - 0.0185)   |
|  | Limit    | 0.52 (0.0205)                     |


\*After installing in connecting rod

**Crankshaft**

Unit: mm (in) NIEM0077



Out-of-round **X - Y**  
Taper **A - B**



SEM954C

EM715

|                        |             |                                   |
|------------------------|-------------|-----------------------------------|
| Main journal dia. "Dm" | Grade No. 0 | 49.956 - 49.964 (1.9668 - 1.9671) |
|                        | Grade No. 1 | 49.948 - 49.956 (1.9665 - 1.9668) |
|                        | Grade No. 2 | 49.940 - 49.948 (1.9661 - 1.9665) |
| Pin journal dia. "Dp"  | Grade No. 0 | 39.968 - 39.974 (1.5735 - 1.5738) |
|                        | Grade No. 1 | 39.962 - 39.968 (1.5733 - 1.5735) |
|                        | Grade No. 2 | 39.956 - 39.962 (1.5731 - 1.5733) |
| Center distance "r"    |             | 43.95 - 44.05 (1.7303 - 1.7342)   |
| Out-of-round (X - Y)   | Standard    | Less than 0.003 (0.0001)          |
|                        | Limit       | Less than 0.005 (0.0002)          |
| Taper (A - B)          | Standard    | Less than 0.004 (0.0002)          |
|                        | Limit       | Less than 0.005 (0.0002)          |
| Runout [TIR*]          | Standard    | Less than 0.04 (0.0016)           |
|                        | Limit       | Less than 0.05 (0.0020)           |
| Free end play          | Standard    | 0.060 - 0.220 (0.0024 - 0.0087)   |
|                        | Limit       | 0.3 (0.012)                       |

\*: Total indicator reading

**Main Bearing**

**STANDARD**

NIEM0078  
NIEM0078S01

| Grade No. | Thickness "T" mm (in)           | Identification color |
|-----------|---------------------------------|----------------------|
| 0         | 1.827 - 1.831 (0.0719 - 0.0720) | Black                |
| 1         | 1.831 - 1.835 (0.0720 - 0.0722) | Brown                |
| 2         | 1.835 - 1.839 (0.0722 - 0.0724) | Green                |

# SERVICE DATA AND SPECIFICATIONS (SDS)

**QG18DE**

## Main Bearing (Cont'd)

|   |                                 |        |
|---|---------------------------------|--------|
| 3 | 1.839 - 1.843 (0.0724 - 0.0725) | Yellow |
| 4 | 1.843 - 1.847 (0.0725 - 0.0727) | Blue   |

### UNDERSIZE

NIEM0078S02  
Unit: mm (in)

|               | Thickness "T"                   |
|---------------|---------------------------------|
| 0.25 (0.0098) | 1.960 - 1.964 (0.0772 - 0.0773) |
| 0.50 (0.0197) | 2.085 - 2.089 (0.0821 - 0.0822) |

## Connecting Rod Bearing

### STANDARD SIZE

NIEM0079

NIEM0079S01  
Unit: mm (in)

| Grade No. | Thickness                       | Identification color or number |
|-----------|---------------------------------|--------------------------------|
| 0         | 1.503 - 1.506 (0.0592 - 0.0593) | —                              |
| 1         | 1.506 - 1.509 (0.0593 - 0.0594) | Brown                          |
| 2         | 1.509 - 1.512 (0.0594 - 0.0595) | Green                          |

### UNDERSIZE

NIEM0079S02  
Unit: mm (in)

| Grade No.     | Thickness                       | Identification color or number |
|---------------|---------------------------------|--------------------------------|
| 0.08 (0.0031) | 1.542 - 1.546 (0.0607 - 0.0609) | —                              |
| 0.12 (0.0047) | 1.562 - 1.566 (0.0615 - 0.0617) | —                              |
| 0.25 (0.0098) | 1.627 - 1.631 (0.0641 - 0.0642) | —                              |

## Bearing Clearance

NIEM0080  
Unit: mm (in)

|                                  |          |                                 |
|----------------------------------|----------|---------------------------------|
| Main bearing clearance           | Standard | 0.018 - 0.042 (0.0007 - 0.0017) |
|                                  | Limit    | 0.1 (0.004)                     |
| Connecting rod bearing clearance | Standard | 0.014 - 0.039 (0.0006 - 0.0015) |
|                                  | Limit    | 0.1 (0.004)                     |

## Miscellaneous Components

NIEM0081  
Unit: mm (in)

|                                 |                         |
|---------------------------------|-------------------------|
| Flywheel runout [TIR*]          | Less than 0.15 (0.0059) |
| Drive plate runout [TIR*]       | Less than 0.2 (0.008)   |
| Camshaft sprocket runout [TIR*] | Less than 0.15 (0.0059) |

\*: Total indicator reading at measuring point 115 mm (4.53 in) from crankshaft center.

**Parts Requiring Angular Tightening**

NIEM0001


- Use an angle wrench for the final tightening of the following engine parts:
  - a) Cylinder head bolts
  - b) Main bearing cap bolts
  - c) Connecting rod cap nuts
- Do not use a torque value for final tightening.
- The torque value for these parts are for a preliminary step.
- Ensure thread and seat surfaces are clean and coated with engine oil.

GI


MA

EM

LC



SEM164F



AEM080

**Liquid Gasket Application Procedure**

NIEM0002

1. Use a scraper to remove old RTV Silicone Sealant from mating surfaces and grooves. Also, completely clean any oil from these areas.
2. Apply a continuous bead of RTV Silicone Sealant to mating surfaces. (Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.)
  - For oil pan, be sure RTV Silicone Sealant diameter is 4.0 to 5.0 mm (0.157 to 0.197 in).
  - For areas except oil pan, be sure RTV Silicone Sealant diameter is 2.0 to 3.0 mm (0.079 to 0.118 in).
3. Apply RTV Silicone Sealant around the inner side of bolt holes (unless otherwise specified).
4. Assembly should be done within 5 minutes after coating.
5. Wait at least 30 minutes before refilling engine oil and engine coolant.

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC








EL

IDX

## Special Service Tools

NIEM0003






The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number<br>(Kent-Moore No.)<br>Tool name   | Description   |  |
|--|---|--|
| ST0501S000<br>(      —      )<br>Engine stand assembly<br>1 ST05011000<br>(      —      )<br>Engine stand<br>2 ST05012000<br>(      —      )<br>Base |    | Disassembling and assembling   |
| NT042  |   |  |
| KV10106500<br>(      —      )<br>Engine stand shaft  |    |  |
| NT028  |   |  |
| KV10115300<br>(      —      )<br>Engine sub-attachment   |   |  |
| NT008  |   |  |
| ST10120000<br>(J24239-01)<br>Cylinder head bolt<br>wrench  |  | Loosening and tightening cylinder head bolt<br><b>a: 13 (0.51) dia.</b><br><b>b: 12 (0.47)</b><br><b>c: 10 (0.39)</b><br>Unit: mm (in) |
| NT583  |   |  |
| KV10116200<br>(J26336-B)<br>Valve spring compres-<br>sor<br>1 KV10115900<br>(J26336-20)<br>Attachment  |  | Disassembling valve mechanism  |
| NT022  |   |  |
| KV10115600<br>(J38958)<br>Valve oil seal drift   |  | Installing valve oil seal  |
| NT024  |   |  |
| KV10107902<br>(J38959)<br>Valve oil seal puller  |  | Displacement valve lip seal  |
| NT011  |   |  |

# PREPARATION

**SR20DE**





Special Service Tools (Cont'd)

| Tool number<br>(Kent-Moore No.)<br>Tool name  | Description  |  |
|---|--|--|
| KV10115700<br>(J38957)<br>Dial gauge stand  |  <p>Adjusting shims</p>                                 | GI<br>MA                               |
| (J38957-N)<br>Valve shim gauge plate<br>kit<br>1 —<br>(J35772)<br>Plastic case<br>2 —<br>(J38957-8)<br>Dial indicator<br>3 —<br>(J38957-2)<br>Collar<br>4 —<br>(J38957-1)<br>Plate<br>5 —<br>( — )<br>Hex bolts                             |  <p>Measuring valve shims</p>                          | EM<br>LC<br>EC<br>FE<br>CL<br>MT<br>AT |
| EM03470000<br>(J8037)<br>Piston ring compressor   |  <p>Installing piston assembly into cylinder bore</p> | AX<br>SU                               |
| KV10107400<br>(J26365-12, J26365)<br>Piston pin press stand<br>1 KV10107310<br>( — )<br>Center shaft<br>2 ST13040020<br>( — )<br>Stand<br>3 ST13040030<br>( — )<br>Spring<br>4 KV10107320<br>( — )<br>Cap<br>5 ST13040050<br>( — )<br>Drift |  <p>Disassembling and assembling piston pin</p>       | BR<br>ST<br>RS<br>BT<br>HA<br>SC       |
| KV10111100<br>(J37228)<br>Seal cutter   |  <p>Removing oil pan</p>                              | EL<br>IDX                              |

# PREPARATION



SR20DE

Special Service Tools (Cont'd)

| Tool number<br>(Kent-Moore No.)<br>Tool name         |  | Description   |
|--|--|---|
| WS39930000<br>( — )<br>Tube presser                  |   | Pressing the tube of liquid gasket                    |
|  | NT052  |   |
| KV10112100<br>(BT-8653-A)<br>Angle wrench            |   | Tightening bolts for bearing cap, cylinder head, etc. |
|  | NT014  |   |
| ST16610001<br>(J23907)<br>Pilot bushing puller       |   | Removing pilot bushing                                |
|  | NT045  |   |
| (J36471-A)<br>Front (heated) oxygen<br>sensor wrench |  | Loosening or tightening front (heated) oxygen sensor  |
|  | NT379  |   |

## Commercial Service Tools

NIEM0004








| Tool number<br>(Kent-Moore No.)<br>Tool name   |   | Description   |
|--|---|---|
| (J-43897-18)<br>(J-43897-12)<br>Oxygen sensor thread<br>cleaner                                  |  | Reconditioning the exhaust system threads before installing a new oxygen sensor (Use with anti-seize lubricant shown below.)<br><b>a: J-43897-18 [18 mm dia.] for zirconia oxygen sensor</b><br><b>b: J-43897-12 [12 mm dia.] for titania oxygen sensor</b> |
|  | AEM488  |   |
| Anti-seize lubricant<br>(Permatex 133AR or<br>equivalent meeting MIL<br>specification MIL-A-907) |  | Lubricating oxygen sensor thread cleaning tool when reconditioning exhaust system threads   |
|  | AEM489  |   |



# PREPARATION

**SR20DE**


Commercial Service Tools (Cont'd)

| Tool number<br>(Kent-Moore No.)<br>Tool name | Description   |                                      |
|--|---|--------------------------------------|
| Spark plug wrench                            |  <p>16 mm<br/>(0.63 in)</p> <p>NT047</p> | <p>GI</p> <p>MA</p> <p><b>EM</b></p> |
| Valve seat cutter set                        |  <p>NT048</p>                            | <p>LC</p> <p>EC</p>                  |
| Piston ring expander                         |  <p>NT030</p>                            | <p>FE</p> <p>CL</p> <p>MT</p>        |
| Valve guide drift                            |  <p>NT015</p>                           | <p>AT</p> <p>AX</p>                  |
| Valve guide reamer                           |  <p>NT016</p>                          | <p>SU</p> <p>BR</p>                  |
| Front oil seal drift                         |  <p>NT049</p>                          | <p>ST</p> <p>RS</p>                  |
| Rear oil seal drift                          |  <p>NT049</p>                          | <p>BT</p> <p>HA</p> <p>SC</p>        |

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NIEM0005

SR20DE



AEM400

# NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

SR20DE

Commercial Service Tools

Use the table below to help you find the cause of the symptom.

1. Locate the area where noise occurs.
2. Confirm the type of noise.
3. Specify the operating condition of the engine.
4. Check the specified noise source.

If necessary, repair or replace these parts.

## NVH Troubleshooting — Engine Noise

NIEM0005S01

| Location of noise   | Type of noise        | Operating condition of engine |               |               |             |             |               | Source of noise                          | Check item   | Reference page                           |
|---|----------------------|-------------------------------|---------------|---------------|-------------|-------------|---------------|--|--|--|
|   |                      | Before warm-up                | After warm-up | When starting | When idling | When racing | While driving |  |  |  |
| Top of engine<br>Rocker cover<br>Cylinder head                  | Ticking or clicking  | C                             | A             | —             | A           | B           | —             | Tappet noise                             | Hydraulic lash adjuster  | EM-116                                   |
|   | Rattle               | C                             | A             | —             | A           | B           | C             | Camshaft bearing noise                   | Camshaft journal clearance<br>Camshaft runout  | EM-111, 111                              |
| Crankshaft pulley<br>Cylinder block (Side of engine)<br>Oil pan | Slap or knock        | —                             | A             | —             | B           | B           | —             | Piston pin noise                         | Piston and piston pin clearance<br>Connecting rod bushing clearance  | EM-132, 138                              |
|   | Slap or rap          | A                             | —             | —             | B           | B           | A             | Piston slap noise                        | Piston-to-bore clearance<br>Piston ring side clearance<br>Piston ring end gap<br>Connecting rod bend and torsion | EM-134, 133                              |
|   | Knock                | A                             | B             | C             | B           | B           | B             | Connecting rod bearing noise             | Connecting rod bushing clearance (Small end)<br>Connecting rod bearing clearance (Big end)                       | EM-137, 138                              |
|   | Knock                | A                             | B             | —             | A           | B           | C             | Main bearing noise                       | Main bearing clearance<br>Crankshaft runout  | EM-135, 135                              |
| Front of engine<br>Timing chain cover                           | Tapping or ticking   | A                             | A             | —             | B           | B           | B             | Timing chain and chain tensioner noise   | Timing chain cracks and wear   | EM-97                                    |
| Front of engine   | Squeaking or fizzing | A                             | B             | —             | B           | —           | C             | Other drive belts (Sticking or slipping) | Drive belt deflection  | <b>MA-25</b> ,<br>"Checking Drive Belts" |
|   | Creaking             | A                             | B             | A             | B           | A           | B             | Other drive belts (Slipping)             | Idler pulley bearing operation   |  |
|   | Squall<br>Creak      | A                             | B             | —             | B           | A           | B             | Water pump noise                         | Water pump operation   | <b>LC-30</b> ,<br>"INSPECTION"           |

A: Closely related B: Related C: Sometimes related —: Not related

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

## Removal and Installation

NIEM0006

**SEC.140•150•210•220•221•233•493**


SEM017G

- |   |   |  |
|---|---|--|
| 1. Oil filler cap<br>2. Rocker cover<br>3. PCV valve<br>4. Distributor<br>5. Intake manifold supports | 6. Knock sensor<br>7. Oil filter<br>8. Oil filter bracket<br>9. Water inlet<br>10. Thermostat housing | 11. Water pipe assembly<br>12. Thermostat<br>13. Starter motor<br>14. Power steering oil pump adjusting bar<br>15. Power steering oil pump bracket |
|---|---|--|




# OUTER COMPONENT PARTS

SR20DE

Removal and Installation (Cont'd)



## SEC. 140•230•275



WEM036

- |                            |                              |   |
|----------------------------|------------------------------|---|
| 1. Oil level gauge         | 4. Generator bracket         | 7. Exhaust manifold (With three way catalyst) |
| 2. Generator adjusting bar | 5. Water outlet              | 8. Exhaust manifold cover                     |
| 3. A/C compressor bracket  | 6. Cylinder block drain plug | 9. Heated oxygen sensor 1 (Front)             |

1. Warm up engine.
2. Turn ignition switch OFF.
3. Release fuel pressure.  
Refer to **EC-1408** (SR20DE), "Fuel Pressure Release".
4. Remove all spark plugs.
5. Disconnect distributor coil harness connector.



6. Attach a compression tester to No. 1 cylinder.
7. Depress accelerator pedal fully to keep throttle valve wide open.
8. Crank engine and record highest gauge indication.
9. Repeat the measurement on each cylinder.
- **Always use a fully-charged battery to obtain specified engine speed.**

**Compression pressure: kPa (kg/cm<sup>2</sup>, psi)/rpm**

**Standard**

**1,275 (13.0, 185)/300**

**Minimum**

**1,079 (11.0, 156)/300**

**Difference limit between cylinders**

**98 (1.0, 14)/300**

10. If compression in one or more cylinders is low, pour a small amount of engine oil into cylinders through spark plug holes and retest compression.
  - If adding oil helps compression, piston rings may be worn or damaged. If so, replace piston rings after checking piston.
  - **If pressure stays low, a valve may be sticking or seating improperly. Inspect and repair valve and valve seat. Refer to "VALVE SEAT", EM-147. If valve or valve seat is damaged excessively, replace them.**
  - If compression stays low in two cylinders that are next to each other, then the cylinder head gasket may be leaking. If so, replace cylinder head gasket.
11. Install spark plugs and fuel pump fuse.
12. Connect the distributor coil harness connector.
13. Erase DTC if any DTC appears. Refer to **EC-1438**, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".











# OIL PAN

SR20DE

Removal (Cont'd)



4. Remove steel oil pan.
  - a. Insert Tool between aluminum oil pan and steel oil pan.
    - **Be careful not to damage aluminum mating surface.**
    - **Do not insert screwdriver, or oil pan flange will be damaged.**
  - b. Slide Tool by tapping on the side of the Tool with a hammer.
  - c. Remove steel oil pan.
5. Remove front exhaust tube. Refer to **FE-15**, "Removal and Installation".
6. Set a suitable transmission jack under transaxle and lift engine with engine slinger.
7. Remove center member.
8. Remove A/T control cable. (A/T only)

9. Remove A/C compressor gussets.

10. Remove rear cover plate.

11. Remove aluminum oil pan bolts in numerical order.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX

## Removal (Cont'd)




12. Remove baffle plate.




13. Remove two engine-to-transaxle bolts and install one of them into open bolt hole as shown. Tighten installed bolt to separate aluminum oil pan from cylinder block.

14. Remove aluminum oil pan.




15. Remove the engine-to-transaxle bolt previously installed in aluminum oil pan.




## Installation

NIEM0010


1. Install aluminum oil pan.
  - a. Use a scraper to remove old RTV Silicone Sealant from mating surfaces.
    - **Also remove old RTV Silicone Sealant from mating surfaces of cylinder block and front cover.**



- b. Apply a continuous bead of RTV Silicone Sealant to mating surface of aluminum oil pan.
  - **Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.**
  - **Apply to groove on mating surface.**
  - **Allow 7 mm (0.28 in) clearance around bolt holes.**



- For areas marked with “★”, apply RTV Silicone Sealant around the outer side of the bolt hole as shown.
- Be sure RTV Silicone Sealant diameter is 4.0 to 5.0 mm (0.157 to 0.197 in).
- Attaching should be done within 5 minutes after coating.




- c. Tighten nuts and bolts in numerical order.

**Bolts 1 - 16:**


: 16 - 19 N·m (1.6 - 1.9 kg·m, 12 - 14 ft·lb)

**Bolts 17, 18:**


: 6.4 - 7.5 N·m (0.65 - 0.76 kg·m, 56.4 - 66.0 in·lb)



2. Install the two engine-to-transaxle bolts.  
For tightening torque, refer to **MT-15**, “Installation” or **AT-437**, “Installation”.
3. Install rear cover plate.




4. Install A/C compressor gussets.
5. Install A/T control cable. (A/T only)
6. Install center member.
7. Install front exhaust tube.
8. Install baffle plate.



9. Install steel oil pan.
  - a. Use a scraper to remove old RTV Silicone Sealant from mating surface of steel oil pan.
- Also remove old RTV Silicone Sealant from mating surface of aluminum oil pan.


GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX

## Installation (Cont'd)




b. Apply a continuous bead of RTV Silicone Sealant to mating surface of steel oil pan.

- Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.
- Apply to groove on mating surface.
- Allow 7 mm (0.28 in) clearance around bolt hole.



- Be sure RTV Silicone Sealant diameter is 4.0 to 5.0 mm (0.157 to 0.197 in).
- Attaching should be done within 5 minutes after coating.



c. Tighten bolts in numerical order as shown.

- Wait at least 30 minutes before refilling engine oil.


## Components

NIEM0011

**CAUTION:**

- After removing timing chain, do not turn crankshaft and camshaft separately, or valves will strike piston heads.
- When installing rocker arms, camshafts, chain tensioner, oil seals, or other sliding parts, lubricate contacting surfaces with new engine oil.
- Apply new engine oil to bolt threads and seat surfaces when installing cylinder head, camshaft sprockets, crankshaft pulley, and camshaft brackets.

SEC. 120•130•135




- |                         |                          |                          |
|-------------------------|--------------------------|--------------------------|
| 1. Cylinder block       | 5. Front cover           | 9. Chain guide           |
| 2. RH camshaft sprocket | 6. Crankshaft pulley     | 10. Timing chain         |
| 3. Chain tensioner      | 7. Oil pump drive spacer | 11. LH camshaft sprocket |
| 4. Chain guide          | 8. Crankshaft sprocket   |                          |

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


## Removal

NIEM0012


1. Remove front RH wheel.
2. Remove front/right-side splash undercover.
3. Remove air duct to intake manifold.
4. Remove A/C compressor. Refer to **HA-66**, "REMOVAL AND INSTALLATION".
5. Remove drive belts and water pump pulley.
6. Disconnect the following parts:
  - Power brake booster vacuum hose
  - Spark plug wires
7. Remove all spark plugs.



8. Remove rocker cover bolts in numerical order.
9. Remove rocker cover.



10. Set No. 1 piston at TDC of its compression stroke.




- Rotate crankshaft until mating mark on camshaft sprocket is set at position indicated in figure.
11. Remove chain tensioner.

# TIMING CHAIN


SR20DE

Removal (Cont'd)




12. Remove camshaft sprockets.

- For retiming in cylinder head removal, apply paint mark to timing chain matched with mating marks of camshaft sprockets.




13. Remove starter motor.

- Lock flywheel for crankshaft pulley removal.




14. Remove cylinder head outside bolts.

15. Remove oil pan.  
Refer to "Components", EM-88.



16. Remove oil strainer.



17. Remove crankshaft pulley.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX


## Removal (Cont'd)




18. Set a suitable transmission jack.
19. Reposition the coolant reservoir aside.




20. Remove RH engine mounting.



21. Remove RH engine mounting bracket.




22. Remove front cover and oil pump drive spacer.
  - **Inspect for oil leakage at front oil seal. Replace seal if oil leak is present.**



23. Remove timing chain guides and timing chain.
24. Remove the crankshaft sprocket.





## Inspection


Check for cracks and excessive wear at roller links. <sup>NIEM0013</sup> Replace chain if necessary.

GI

MA

**EM**

LC



## Installation


1. Install crankshaft sprocket on crankshaft. <sup>NIEM0014</sup>

- Make sure that mating marks on crankshaft sprocket face front of engine.

EC

FE

CL



2. Position crankshaft so that No. 1 piston is set at TDC and key way is at 12 o'clock. Fit timing chain on crankshaft sprocket, aligning the mating marks.


MT

AT

AX

SU

BR



- Mating mark color on timing chain.


**1: Yellow**  
**2, 3: Blue**

ST

RS

BT

HA








3. Install timing chain and timing chain guides.

SC

EL

IDX

## Installation (Cont'd)




4. Use a scraper to remove old RTV Silicone Sealant from mating surface of front cover.
  - **Also remove old RTV Silicone Sealant from mating surface of cylinder block.**
5. Apply a continuous bead of RTV Silicone Sealant to front cover.
  - **Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent. Be sure to install new front oil seal in the right direction. Refer to "FRONT OIL SEAL", EM-103.**
6. Install oil pump drive spacer and front cover.
  - Wipe off excessive RTV Silicone Sealant.


# TIMING CHAIN

**SR20DE**


Installation (Cont'd)




7. Install RH engine mounting and bracket. Refer to "Removal and Installation", EM-127.




8. Install crankshaft pulley.
9. Set No. 1 piston at TDC of its compression stroke.



10. Install oil strainer.
11. Install oil pan. Refer to "Components", EM-88.



12. Install cylinder head outside bolts.



13. Install starter motor.

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX

## Installation (Cont'd)




14. Install camshaft sprockets and timing chain on them.  
**Line up mating marks on timing chain with mating marks on camshaft sprockets.**



- Lock camshafts as shown in figure and tighten to specified torque.



**⚙️ : 137 - 157 N·m (14.0 - 16.0 kg·m, 101 - 116 ft·lb)**

**Apply new engine oil to threads and seating surfaces of camshaft sprocket bolts before installing them.**



15. Install chain tensioner.

**Make sure the camshaft sprockets are tightened completely. Press cam stopper down and "press-in" sleeve until hook can be engaged on pin. When tensioner is bolted in position the hook will release automatically. Make sure arrow "A" points toward engine front.**



16. Install rocker cover with a new gasket and oil separator.

- Be sure to install washers between bolts and rocker cover.

- Tightening procedure

**STEP 1: Tighten bolts 1 - 10 - 11 - 13 - 8 in that order.**

**STEP 2: Tighten bolts 1 - 13 in that order.**

**⚙️ : 8 - 10 N·m (0.8 - 1.0 kg·m, 69 - 87 in·lb)**

17. Install the following parts:

- Spark plugs
- Water pump pulley and drive belts.

# TIMING CHAIN

**SR20DE**

*Installation (Cont'd)*

For adjusting drive belt deflection, refer to **MA-25**, "Checking Drive Belts".

- Front RH wheel
  - Front/right-side splash undercovers
18. Connect the following:
- Power brake booster vacuum hose
  - Spark plug wires

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

## Replacement




### Replacement VALVE OIL SEAL

NIEM0015


NIEM0015S01

1. Remove accelerator wire.
2. Remove rocker cover.
3. Remove camshafts and sprockets. Refer to "Components", EM-105.
4. Remove spark plugs.
5. Install air hose adapter into spark plug hole and apply air pressure to hold valves in place. Apply a pressure of 490 kPa (5 kg/cm<sup>2</sup>, 71 psi).
6. Remove rocker arm, rocker arm guide and shim.




7. Remove valve spring with Tool. Temporarily install camshaft as shown.

**Piston concerned should be set at TDC to prevent valve from falling into engine cylinder.**




8. Remove valve oil seal with a suitable tool.



9. Apply new engine oil to new valve oil seal and install it with Tool.


NIEM0015S02



### FRONT OIL SEAL



1. Remove the following parts:
  - Front/right-side splash undercover
  - Front RH wheel and engine side cover
  - Drive belts
  - Crankshaft pulley
2. Remove front oil seal.

**Be careful not to scratch front cover.**



3. Apply new engine oil to new oil seal and install it using a suitable tool.

- **Install new oil seal in the direction shown.**



### REAR OIL SEAL

1. Remove transaxle. Refer to **MT-12** (M/T), **AT-436** (A/T),<sup>NIEM0015S03</sup> "Removal".
2. Remove flywheel or drive plate.
3. Remove rear oil seal.

- **Be careful not to scratch rear oil seal retainer.**

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX

## Replacement (Cont'd)




4. Apply new engine oil to new oil seal and install it using a suitable tool.
- **Install new oil seal in the direction shown.**





## Components

SEC. 111•130



- ★ : Refer to "Installation" in "TIMING CHAIN".
- : N•m (kg-m, in-lb)
- : N•m (kg-m, ft-lb)
- : Apply Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.
- : Lubricate with new engine oil.

WEM048


- |                            |                      |                           |
|----------------------------|----------------------|---------------------------|
| 1. Oil filler cap          | 8. Camshaft sprocket | 14. Valve spring seat     |
| 2. Rocker cover            | 9. Camshaft          | 15. Valve spring          |
| 3. Rocker arm guide        | 10. Camshaft bracket | 16. Valve spring retainer |
| 4. Rocker arm              | 11. Water outlet     | 17. Valve collet          |
| 5. Shim                    | 12. Cylinder head    | 18. Spark plug            |
| 6. Hydraulic lash adjuster | 13. Valve            | 19. Cylinder head bolt    |
| 7. Chain tensioner         |                      |                           |

1. Refer to **LC-32**, "Water Outlet".
2. Refer to "Installation", EM-120.
3. Refer to "Installation", EM-97.


## Removal

NIEM0017


1. Release fuel pressure.  
Refer to **EC-1408** (SR20DE), "Fuel Pressure Release".
2. Remove front/right-side splash undercover.
3. Remove front RH wheel and engine side cover.
4. Drain coolant by removing cylinder block drain plug and radiator drain cock. Refer to **MA-26**, "Changing Engine Coolant".
5. Remove the generator. Refer to **SC-18**, "Removal".
6. Remove air duct to intake manifold.
7. Remove power steering pump.
8. Remove drive belts and water pump pulley.
9. Disconnect the following parts:
  - Power brake booster vacuum hose
  - Fuel hoses and pressure regulator
  - Spark plug wires
  - Engine harness, place aside
  - Heated oxygen sensor 1 (front)
  - Heated oxygen sensor 2 (rear)
  - EVAP canister purge volume control solenoid valve connector
  - PCV valve
  - IACV-AAC valve
  - TP sensor
  - TP switch
  - EGR volume control
  - EGR temperature sensor
  - Intake valve timing control position sensor
  - Power steering hoses
10. Remove all spark plugs.




11. Remove rocker cover bolts in numerical order.
12. Remove rocker cover.




13. Remove intake manifold supports.



14. Remove water pipe assembly.




15. Set No. 1 piston at TDC of its compression stroke.




- Rotate crankshaft until mating mark on camshaft sprocket is set at position indicated in figure.

16. Remove chain tensioner.



17. Remove distributor.

**Do not turn rotor with distributor removed.**



18. Remove camshaft sprockets.

- For retiming in cylinder head removal, apply paint mark to timing chain matched with mating marks of camshaft sprockets.

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX


Removal (Cont'd)



19. Remove camshaft brackets and camshafts.
  - **Mark these parts' original positions for reassembly.**
20. Remove water hoses for heater core.
21. Remove front exhaust tube.
22. Remove front oxygen sensor and exhaust manifold heat shield.
23. Remove exhaust manifold.



24. Remove cylinder head outside bolts.




25. Remove cylinder head bolts in numerical order.
  - **Removing bolts in incorrect order could result in a warped or cracked cylinder head.**
  - **Loosen cylinder head bolts in two or three steps.**
26. Remove cylinder head completely with intake manifold.
  - Remove the old gasket material.
27. Remove generator. Refer to **SC-18**, "Removal".

## Disassembly

NIEM0018

### CAUTION:

- When installing rocker arms, camshaft and oil seal, lubricate contacting surfaces with new engine oil.
- When tightening cylinder head bolts, camshaft sprocket bolts and camshaft bracket bolts, lubricate bolt threads and seat surfaces with new engine oil.




- If a hydraulic lash adjuster is kept on its side, there is a risk of air entering it. When hydraulic lash adjusters are removed, stand them straight up or soak them in new engine oil.
- Do not disassemble hydraulic lash adjusters.
- Attach tags to lash adjusters so as not to mix them up.

# CYLINDER HEAD


SR20DE

Disassembly (Cont'd)




1. Remove rocker arms, shims, rocker arm guides and hydraulic lash adjusters from cylinder head.


**CAUTION:**  
Keep parts in order so they can be installed in their original positions during assembly.




2. Remove exhaust manifold cover.
3. Remove EGR tube.



4. Remove exhaust manifold as shown.



5. Remove EGR volume control valve assembly.



6. Remove water outlet.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX


## Disassembly (Cont'd)




7. Remove intake manifold with intake manifold collector as shown.



8. Remove valve components with Tool. Install camshaft temporarily.



9. Remove valve oil seal with a suitable tool.



## Inspection

### CYLINDER HEAD DISTORTION

NIEM0019

NIEM0019S01

- Clean mating surface of cylinder head.
- Use a reliable straightedge and feeler gauge to check the flatness of cylinder head mating surface.
- Check along six positions shown in figure.

#### Head surface flatness:

**Standard: Less than 0.03 mm (0.0012 in)**

**Limit: 0.1 mm (0.004 in)**

If beyond the specified limit, replace or resurface it.

#### Resurfacing limit:

The limit for cylinder head resurfacing is determined by the amount of cylinder block resurfacing.

Amount of cylinder head resurfacing is "A".

Amount of cylinder block resurfacing is "B".


#### The maximum limit is as follows:

**A + B = 0.2 mm (0.008 in)**

After resurfacing cylinder head, check that camshaft rotates freely by hand. If resistance is felt, cylinder head must be replaced.

#### Nominal cylinder head height:

**136.9 - 137.1 mm (5.390 - 5.398 in)**



## CAMSHAFT VISUAL CHECK

Check camshaft for scratches, seizure and wear.

NIEM0019S02

## CAMSHAFT RUNOUT

1. Measure camshaft runout at the center journal.


NIEM0019S03

**Runout (Total indicator reading):**

**Standard: Less than 0.02 mm (0.0008 in)**

**Limit: 0.1 mm (0.004 in)**

2. If it exceeds the limit, replace camshaft.



## CAMSHAFT CAM HEIGHT

1. Measure camshaft cam height.

NIEM0019S04

**Standard cam height:**

**Intake**

**37.680 - 37.870 mm (1.4835 - 1.4909 in)**


**Exhaust**

**37.309 - 37.499 mm (1.4689 - 1.4763 in)**

**Cam height wear limit:**

**Intake & Exhaust: 0.2 mm (0.008 in)**

2. If wear is beyond the limit, replace camshaft.



## CAMSHAFT JOURNAL CLEARANCE


1. Install camshaft bracket and tighten bolts. Refer to "Installation", EM-97.

NIEM0019S05

2. Measure inner diameter of camshaft bearing.

**Standard inner diameter:**

**28.000 - 28.021 mm (1.1024 - 1.1032 in)**



3. Measure outer diameter of camshaft journal.

**Standard outer diameter:**

**27.935 - 27.955 mm (1.0998 - 1.1006 in)**

4. Calculate camshaft journal clearance.

**Camshaft journal clearance = standard inner diameter - standard outer diameter:**

**Standard**

**0.045 - 0.090 mm (0.0018 - 0.0035 in), up to engine serial number 266630**

**0.030 - 0.071 mm (0.0012 - 0.0028 in), from engine serial number 266630**

**Limit**

**0.15 mm (0.0059 in)**

5. If clearance exceeds the limit, replace camshaft and remeasure camshaft journal clearance.

- If clearance still exceeds the limit after replacing camshaft, replace cylinder head.

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX


**CAMSHAFT END PLAY**

1. Install camshaft in cylinder head. Refer to "Installation", EM-97.
2. Measure camshaft end play.

**Camshaft end play:****Standard****0.055 - 0.139 mm (0.0022 - 0.0055 in)****Limit****0.20 mm (0.0079 in)**


3. If end play exceeds the limit, replace camshaft and remeasure camshaft end play.
  - If end play still exceeds the limit after replacing camshaft, replace cylinder head.

NIEM0019S06

**CAMSHAFT SPROCKET RUNOUT**

1. Install sprocket on camshaft.
2. Measure camshaft sprocket runout.
  - Runout (Total indicator reading):**
  - Limit 0.25 mm (0.0098 in)**
3. If it exceeds the limit, replace camshaft sprocket.

NIEM0019S07


**VALVE GUIDE CLEARANCE**

1. Measure valve deflection as shown in illustration. (Valve and valve guide mostly wear in this direction.)

**Valve deflection limit (Dial gauge reading):****Intake & Exhaust****0.2 mm (0.008 in)**

NIEM0019S08





SEM938C

2. If it exceeds the limit, check valve to valve guide clearance.
  - a. Measure valve stem diameter and valve guide inner diameter.
  - b. Calculate valve to valve guide clearance.

**Valve stem to valve guide clearance = valve guide inner diameter – valve stem diameter:**

**Standard**

**Intake 0.020 - 0.053 mm (0.0008 - 0.0021 in)**


**Exhaust 0.040 - 0.073 mm (0.0016 - 0.0029 in)**

**Limit**

**Intake 0.08 mm (0.0031 in)**

**Exhaust 0.1 mm (0.004 in)**


- c. If it exceeds the limit, replace valve and remeasure clearance.
  - If clearance still exceeds the limit after replacing valve, replace valve guide.



SEM008A


## VALVE GUIDE REPLACEMENT

1. To remove valve guide, heat cylinder head to 110 to 130°C (230 to 266°F).



SEM931C

2. Drive out valve guide with a press (under a 20 kN [2 ton, 2.2 US ton, 2.0 Imp ton] pressure) or hammer and suitable tool.



SEM932C

3. Ream cylinder head valve guide hole.


**Valve guide hole diameter**

**(for service parts):**

**Intake & Exhaust**

**10.175 - 10.196 mm (0.4006 - 0.4014 in)**


Inspection (Cont'd)



- Heat cylinder head to 110 to 130°C (230 to 266°F) and press service valve guide into cylinder head.

**Projection "L":**

**14.0 - 14.2 mm (0.551 - 0.559 in)**




- Ream valve guide.

**Finished size:**

**Intake & Exhaust**


**6.000 - 6.018 mm (0.2362 - 0.2369 in)**



### VALVE SEATS

Check valve seats for pitting at contact surface. NIEM0019S10 Resurface or replace if excessively worn.

- Before repairing valve seats, check valve and valve guide for wear. If they are worn, replace them. Then correct valve seat.
- Use both hands to cut uniformly.



### REPLACING VALVE SEAT FOR SERVICE PARTS

- Bore out old seat until it collapses. Set machine depth stop so that boring cannot contact bottom face of seat recess in cylinder head. NIEM0019S11

- Ream cylinder head recess.



**Reaming bore for service valve seat**

**Oversize [0.5 mm (0.020 in)]:**

**Intake 35.500 - 35.516 mm (1.3976 - 1.3983 in)**

**Exhaust 31.500 - 31.516 mm (1.2402 - 1.2408 in)**

Use the valve guide center for reaming to ensure valve seat will have the correct fit.



3. Heat cylinder head to 110 to 130°C (230 to 266°F).
4. Press fit valve seat until it seats on the bottom.

5. Cut or grind valve seat to the specified dimensions using a suitable tool. Refer to "VALVE SEAT", EM-147.
6. After cutting, lap valve seat with abrasive compound.
7. Check valve seating condition.

**Seat face angle " $\alpha$ ":**

**44°53' - 45°07'**


**Contacting width "W":**

**Intake**

**1.05 - 1.35 mm (0.0413 - 0.0531 in)**

**Exhaust**

**1.25 - 1.55 mm (0.0492 - 0.0610 in)**




Use a depth gauge to measure the distance between the mounting surface of the cylinder head spring seat and the valve stem end. If the distance is shorter than the specified valve, repeat step 5 above to adjust it.

If it is longer, replace the valve seat with a new one.

**Valve seat resurface limit:**

**42.74 - 43.26 mm (1.6827 - 1.7031 in)**



## VALVE DIMENSIONS

Check dimensions of each valve. Refer to "VALVE", EM-144.

When valve head has been worn down to 0.5 mm (0.020 in) in margin thickness, replace valve. Refer to "VALVE", EM-144.

**Grinding allowance for valve stem tip is 0.2 mm (0.008 in) or less.**

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX


Inspection (Cont'd)

**VALVE SPRING****Squareness**

NIEM0019S13

NIEM0019S1301

1. Measure dimension "S".  
**Out-of-square "S":**  
**Less than 2.2 mm (0.087 in)**
2. If it exceeds the limit, replace spring.

**Pressure**

NIEM0019S1302

Check valve spring pressure at specified spring height.


**Pressure:****Standard**

**578.02 - 641.57 N (58.94 - 65.42 kg, 129.96 - 144.25 lb) at 30.0 mm (1.181 in)**

**Limit**


**More than 549.2 N (56.0 kg, 123.5 lb) at 30.0 mm (1.181 in)**

If not within specification, replace spring.

**HYDRAULIC LASH ADJUSTER**

NIEM0019S14


1. Check contact and sliding surfaces for wear or score.



2. Check diameter of lash adjuster.

**Outer diameter:**

**16.980 - 16.993 mm (0.6685 - 0.6690 in)**




3. Check lash adjuster guide hole diameter.

**Inner diameter:**

**17.000 - 17.020 mm (0.6693 - 0.6701 in)**

**Standard clearance between lash adjuster and adjuster guide hole:**

**0.007 - 0.040 mm (0.0003 - 0.0016 in)**



## ROCKER ARM, SHIM AND ROCKER ARM GUIDE

NIEM0019S15

Check contact and sliding surfaces of rocker arms, shims and rocker arm guides for wear or score.

GI

MA

EM

LC

## Assembly

NIEM0020

### CAUTION:


- When installing rocker arms, camshaft and oil seal, lubricate contacting surfaces with new engine oil.
- When tightening cylinder head bolts, camshaft sprocket bolts and camshaft bracket bolts, lubricate bolt threads and seat surfaces with new engine oil.

EC

FE

CL

MT




- If a hydraulic lash adjuster is kept on its side, there is a risk of air entering it. When hydraulic lash adjusters are removed, stand them straight up or soak them in new engine oil.
- Do not disassemble hydraulic lash adjusters.
- Attach tags to lash adjusters so as not to mix them up.

AT

AX

SU

BR



1. Install valve component parts.

- Install valves, noting their identification marks as indicated in the table below.


|               | Identification mark |
|---------------|---------------------|
| Intake valve  | E71                 |
| Exhaust valve | 6Y2                 |

ST

RS

BT

HA




- Always use new valve oil seal. Refer to "VALVE OIL SEAL", EM-102.
- Before installing valve oil seal, install valve spring seat.
- Install valve spring (uneven pitch type) with its narrow pitched side (paint mark) toward cylinder head side.
- After installing valve components, use plastic hammer to lightly tap valve stem tip to assure a proper fit.

SC

EL


IDX

Assembly (Cont'd)



SEM093D


2. Check hydraulic lash adjusters.
  - a. Push on the rocker arm above the hydraulic lash adjuster. If it moves 1 mm (0.04 in) or more, there is air in the high pressure chamber of hydraulic lash adjuster. Noise will be emitted from hydraulic lash adjuster if engine is started without bleeding air.



AEM117


- b. Remove hydraulic lash adjuster and dip in a container filled with new engine oil. While pushing plunger as shown in figure, lightly push check ball using a thin rod. Air is completely bled when plunger no longer moves.

**Air cannot be bled from this type of lash adjuster by running engine.**



SEM057G

3. Remove camshafts, rocker arms and shims. For future reference, identify each shim with the cylinder it was removed from. Since the shims are reusable, it may not be necessary to replace all of the existing shims.




SEM364D

4. Before attempting any measurement, make sure the valve, valve spring, collet, retainer and rocker arm guide are properly installed in the head.

- **Always replace rocker arm guide with a new one.**

**CAUTION:**  
Install parts in their original positions.





AEM201

5. Install the J38957-1 gauge plate into the tapped holes at the cam journals and secure it to the head using two of the hex bolts supplied with the kit. (The two remaining bolts are spares.)


# CYLINDER HEAD

**SR20DE**

Assembly (Cont'd)




6. Place the J38957-2 collar on the J38957-8 dial indicator. Make sure the dished side of the collar is facing "up" (toward the dial indicator). Secure the collar to the dial indicator by tightening the set screw in the collar.
7. Place the indicator and collar over #1 cylinder intake valve shim side. Slide the tip of the dial indicator through the access hole and place it on the end of the valve stem. While resting the dial indicator collar on the gauge plate, "zero" the dial indicator.
8. Move the dial indicator and collar to the adjacent hole in the gauge plate and place the tip of the indicator in the center of the rocker arm guide. Write down the dial indicator reading. This measured distance between the valve stem end and the contact surface of the rocker arm guide is the "T<sub>1</sub>" dimension.
9. Match the measured "T<sub>1</sub>" dimension (in inches) to the available shim chart (in millimeters). Refer to "AVAILABLE SHIM", EM-146. (The "T<sub>1</sub>" dimension is equivalent to the thickness and size designation of the valve shim.) Select the closest size shim to the measured "T<sub>1</sub>" dimension. For example, if the measured "T<sub>1</sub>" dimension is 0.1152 in. use a 2.925 mm shim. Shims are available in 17 different thicknesses ranging from 2.800 mm (0.1102 in.) to 3.200 mm (0.1260 in.) and increase in increments of 0.025 mm (0.0010 in.).
10. Repeat this procedure on the remaining cylinders.
11. Install rocker arms.



12. Install intake manifold with intake manifold collector as shown.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


Assembly (Cont'd)




13. Install exhaust manifold.


- Tighten exhaust manifold bolts in numerical order.

**Exhaust manifold:**

 : 49 - 63 N-m (5.0 - 6.5 kg-m, 37 - 47 ft-lb)




14. Install EGR volume control valve assembly.



15. Install EGR tube.

16. Install exhaust manifold cover.



17. Install water outlet.

- Remove old RTV Silicone Sealant from mating surface of water outlet.

- **Also remove old RTV Silicone Sealant from mating surface of cylinder head.**

- Apply a continuous bead of RTV Silicone Sealant to mating surface of water outlet.

- **Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.**

## Installation

- Install generator.  
Refer to **SC-18**, "INSTALLATION".






NIEM0021



# CYLINDER HEAD

**SR20DE**

Installation (Cont'd)



2. Install cylinder head completely with intake and exhaust manifolds and exhaust manifold heat shield.

- Apply engine oil to threads and seating surfaces of cylinder head bolts before installing them.
- Be sure to install washers between bolts and cylinder head.

**CAUTION:**

Old style bolt:

- Old style bolt identification:  
L: 75 mm (2.95 in)

If cylinder head bolt exceeds limit of dimension "A", replace it.

Dimension "A":  
158.2 mm (6.228 in)

**CAUTION:**

New style bolt:

- New style bolt identification:  
L: 55 mm (2.17 in)

Cylinder head bolts are tightened by plastic zone tightening method. Whenever the size difference between d1 and d2 exceeds the limit, replace them with new ones.

Limit (d1 - d2):  
0.15 mm (0.0059 in)

- If reduction of outer diameter appears in a position other than d2, use it as d2 point.

3. Tighten cylinder head bolts using the following procedure.

- Tighten all bolts to 39 N·m (4.0 kg·m, 29 ft·lb).
- Tighten all bolts to 78 N·m (8.0 kg·m, 58 ft·lb).
- Loosen all bolts completely.
- Tighten all bolts to 34 to 44 N·m (3.5 to 4.5 kg·m, 25 to 33 ft·lb).

e. Method A:


Turn all bolts 90 to 95 degrees clockwise with Tool or suitable angle wrench.

Method B:


If an angle wrench is not available, mark all cylinder head bolts on the side facing engine front. Then, turn each cylinder head bolt 90 to 95 degrees clockwise.

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


Installation (Cont'd)




- f. Turn all bolts another 90 to 95 degrees clockwise.
  - g. Ensure that paint mark on each bolt faces the rear of the engine. (Method B only)
- Do not turn any bolt 180 to 190 degrees clockwise all at once.




|    | Tightening torque N-m (kg-m, ft-lb)    |
|----|--|
| a. | 39 (4.0, 29)                           |
| b. | 78 (8.0, 58)                           |
| c. | 0 (0, 0)                               |
| d. | 34 - 44 (3.5 - 4.5, 25 - 33)           |
| e. | 90 - 95 degrees (90 degrees preferred) |
| f. | 90 - 95 degrees (90 degrees preferred) |



4. Install cylinder head outside bolts.
5. Install the following water hoses:
  - Water hoses for heater.




6. Remove old RTV Silicone Sealant from mating surface of LH camshaft end bracket.
  - **Also remove old RTV Silicone Sealant from mating surface of cylinder head.**
7. Apply RTV Silicone Sealant to mating surface of LH camshaft end bracket as shown in illustration.
  - **Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.**




8. Install camshafts, camshaft brackets.
  - Position camshaft.
  - LH camshaft key at about 12 o'clock.
  - RH camshaft key at about 12 o'clock.


**Apply new engine oil to bearing and cam surfaces of camshafts before installing them.**



- Position camshaft brackets as shown in the illustration. **Apply new engine oil to threads and seating surfaces of camshaft bracket bolts before installing them.**



- Arrange bolts (Size and length).**  
 A: M6 x 53.8 mm (2.12 in)  
 B: M6 x 37 mm (1.46 in)  
 C: M8 x 35 mm (1.38 in)



- Tightening procedure**

**STEP 1:**

**RH camshaft**

Tighten bolts 9 - 10 in that order then tighten bolts 1 - 8 in numerical order.

: 2 N·m (0.2 kg·m, 17 in-lb)

**LH camshaft**

Tighten bolts 11 - 12 in that order then tighten bolts 1 - 10 in numerical order.

: 2 N·m (0.2 kg·m, 17 in-lb)

**STEP 2:**

Tighten bolts in numerical order.

: 6 N·m (0.6 kg·m, 52 in-lb)

**STEP 3:**



Tighten bolts in numerical order.

**Bolt type A B D**

: 9.8 - 11.8 N·m (1.0 - 1.2 kg·m, 7.2 - 8.7 ft-lb)

**Bolt type C**


: 18 - 25 N·m (1.8 - 2.6 kg·m, 13 - 19 ft-lb)



- Install camshaft sprockets and timing chain on them. **Line up mating marks on timing chain with mating marks on camshaft sprockets.**

GI  
MA  
EM  
LC  
EC  
FE  
CL  
MT  
AT  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


## Installation (Cont'd)



- Lock camshafts as shown in figure and tighten to specified torque.


**ⓘ : 137 - 157 N-m (14.0 - 16.0 kg-m, 101 - 116 ft-lb)**

Apply new engine oil to threads and seating surfaces of camshaft sprocket bolts before installing them.




10. Install distributor.

- Make sure that position of camshaft is as shown in figure.





- Make sure that No. 1 piston is set at TDC and that distributor rotor is set at No. 1 cylinder spark position.




11. Install chain tensioner.

Make sure the camshaft sprockets are tightened completely. Press cam stopper down and "press-in" sleeve until hook can be engaged on pin. When tensioner is bolted in position the hook will release automatically. Make sure arrow "A" points toward engine front.






12. Install thermostat housing with water pipe.




13. Install intake manifold supports.



14. Remove old RTV Silicone Sealant from mating surfaces of rocker cover and cylinder head.

15. Apply a continuous bead of RTV Silicone Sealant to rocker cover gasket and cylinder head as shown in the illustrations.

- Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX

Installation (Cont'd)




16. Install rocker cover and oil separator.
  - Be sure to install washers between bolts and rocker cover.
  - Tightening procedure
    - STEP 1: Tighten bolts 1 - 10 - 11 - 13 - 8 in that order.
    - STEP 2: Tighten bolts 1 - 13 in that order.
    - ⚙️ : 8 - 10 N·m (0.8 - 1.0 kg·m, 69 - 87 in·lb)
17. Install the following parts:
  - Spark plugs and wires
  - Power steering pump and hoses
  - Water pump pulley and drive belts.  
For adjusting drive belt deflection, refer to **MA-25**, "Checking Drive Belts".
  - Refit hoses and refill with coolant.  
Refer to **MA-26**, "Changing Engine Coolant".
  - Front RH wheel
  - Front/right-side splash undercover
  - Fuel pump fuse
18. Connect the following:
  - Power brake booster vacuum hose
  - Fuel hoses and pressure regulator
  - Air duct to intake manifold
  - Heated oxygen sensor 1 (front)
  - Heated oxygen sensor 2 (rear)
  - EVAP canister purge volume control solenoid valve connector
  - PCV valve
  - IACV-AAC valve
  - TP sensor
  - TP switch
  - EGR volume control
  - EGR temperature sensor
  - Intake valve timing control position sensor
19. Erase DTC if any DTC appears. Refer to **EC-1438**, "HOW TO ERASE EMISSION-RELATED DIAGNOSTIC INFORMATION".

### Removal and Installation

NIEM0022

SEC. 112



WEM030

- |                                 |                               |                                  |
|---------------------------------|-------------------------------|----------------------------------|
| 1. RH engine mounting           | 5. Center member              | 8. Front engine mounting         |
| 2. RH engine mounting bracket   | 6. LH engine mounting         | 9. Front engine mounting bracket |
| 3. Rear engine mounting bracket | 7. Dynamic damper (A/T model) | 10. Damper (M/T model)           |
| 4. Rear engine mounting         |                               |                                  |

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

**WARNING:**

- Position vehicle on a flat and solid surface.
- Place chocks at front and back of rear wheels.
- Do not remove engine until exhaust system has completely cooled off, otherwise you may burn yourself and/or fire may break out in fuel line.
- Before disconnecting fuel hose, release pressure. Refer to *EC-1408*, "Fuel Pressure Release".
- Before removing front axle from transaxle, place safety stands under designated front supporting points. Refer to *GI-47*, "Garage Jack and Safety Stand".
- Be sure to lift engine and transaxle in a safe manner.
- For engines not equipped with engine slingers, attach proper slingers and bolts described in PARTS CATALOG.

**CAUTION:**

- When lifting engine, be sure to clear surrounding parts. Use special care near accelerator wire casing, brake lines and brake master cylinder.
- In lifting the engine, always use engine slingers in a safe manner.
- In removing drive shaft, be careful not to damage grease seal of transaxle.
- Before separating engine and transaxle, remove the crankshaft position sensor (POS) from the assembly.
- Always be extra careful not to damage edge of crankshaft position sensor (POS) or ring gear teeth.

**REMOVAL**

NIEM0022S01

1. Remove the front splash undercovers.
2. Drain coolant from both cylinder block and radiator. Refer to *MA-26*, "Changing Engine Coolant".
3. Drain engine oil.
4. Remove air cleaner assembly and duct.
5. Remove the battery and battery tray.
6. Disconnect the following:
  - Vacuum hoses
  - Heater hoses
  - A/T cooler hoses
  - Power steering hoses
  - Fuel lines
  - Wires
  - Harnesses and connectors
  - Throttle cable
  - ASCD cable
  - A/T control cable
7. Remove the cooling fans, radiator and recovery tank.
8. Remove front LH and RH wheels and drive shafts. Refer to *AX-12*, "REMOVAL".



9. Remove front exhaust pipe.
10. Remove starter and intake manifold supports.
11. Remove the drive belts.
12. Remove power steering oil pump and A/C compressor.
13. Set a suitable transmission jack under transaxle. Lift engine with engine slinger.

GI

MA

**EM**


LC

EC

FE

CL

MT



14. Remove center member.
15. Remove generator and adjusting bracket.
16. Remove engine mounting bolts from both sides, then slowly lower transmission jack.
17. Remove engine with transaxle.

AT

## INSTALLATION

1. Install in the reverse order of removal.

NIEM0022S02

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

# CYLINDER BLOCK


SR20DE

Components

NIEM0023

## Components

SEC. 110•120•150



- |  |                           |                            |
|--|---------------------------|----------------------------|
| 1. Rear oil seal retainer                | 6. Oil strainer           | 12. Piston pin             |
| 2. Cylinder block                        | 7. Thrust bearing         | 13. Connecting rod         |
| 3. Water pump                            | 8. Crankshaft             | 14. Connecting rod bearing |
| 4. Power steering oil pump adjusting bar | 9. Connecting rod bushing | 15. Aluminum oil pan       |
| 5. Front cover with oil pump             | 10. Piston rings          | 16. Rear cover plate       |
|  | 11. Piston                | 17. Oil pan drain plug     |

- |                      |                         |  |
|----------------------|-------------------------|--|
| 18. Steel oil pan    | 22. Drive plate         | 26. Rear plate                             |
| 19. Baffle plate     | 23. Reinforcement plate | 27. Main bearing                           |
| 20. Main bearing cap | 24. Flywheel            | 28. Block heater (Canada only)             |
| 21. Pilot converter  | 25. Pilot bushing       | 29. Connector protective cap (Canada only) |

GI

MA

EM

LC

## Removal and Installation

NIEM0024

### CAUTION:

- When installing sliding parts (bearings, pistons, etc.), lubricate contacting surfaces with new engine oil.
- Place removed parts such as bearings and bearing caps in their proper order and direction.
- When installing connecting rod nuts and main bearing cap bolts, apply new engine oil to threads and seating surfaces.
- Do not allow any magnetic materials to contact the ring gear teeth of flywheel or drive plate.

EC

FE

CL

MT

## Disassembly

NIEM0025

### PISTON AND CRANKSHAFT

NIEM0025S01

1. Place engine on engine stand (ST0501S000) using engine stand shaft (KV10106500) and engine sub-attachment (KV10115300).
2. Remove cylinder head and timing chain. Refer to "Removal", EM-106.
3. Remove oil pan. Refer to "Components", EM-88.
4. Remove pistons with connecting rods.
  - To disassemble piston and connecting rod, first remove snap rings. Heat piston to 60 to 70°C (140 to 158°F) then use piston pin press to remove pin.
  - When piston rings are not replaced, make sure that piston rings are mounted in their original positions.
  - When replacing piston rings, if there is no punchmark, install with either side up.
5. Remove rear oil seal retainer.
6. Remove main bearing cap and crankshaft as shown.
  - Bolts should be loosened in two or three steps.

AT

AX

SU

BR

ST

RS


BT

HA


SC

EL


IDX



SEM141F




SEM877B



Loosen in numerical order.

SEM068G

**Inspection****PISTON AND PISTON PIN CLEARANCE**


NIEM0026

NIEM0026S01

1. Measure inner diameter of piston pin hole "dp".

**Standard diameter "dp":**

**21.993 - 22.005 mm (0.8659 - 0.8663 in)**



2. Measure outer diameter of piston pin "Dp".


**Standard diameter "Dp":**

**21.989 - 22.001 mm (0.8657 - 0.8622 in)**

3. Calculate interference fit of piston pin to piston.

**Dp - dp: 0.005 - 0.017 mm (0.0002 - 0.0007 in)**

If it exceeds the above value, replace piston assembly with pin.

**PISTON RING SIDE CLEARANCE**

NIEM0026S02

**Side clearance:**

**Top ring**

**0.040 - 0.080 mm (0.0016 - 0.0031 in)**

**2nd ring**

**0.030 - 0.070 mm (0.0012 - 0.0028 in)**


**Oil ring**

**0.065 - 0.135 mm (0.0026 - 0.0053 in)**

**Max. limit of side clearance:**

**0.1 mm (0.004 in)**

If out of specification, replace piston ring. If clearance exceeds maximum limit with new ring, replace piston.



SEM822B

## PISTON RING END GAP

NIEM0026S03

### End gap:

**Top ring 0.20 - 0.39 mm (0.0079 - 0.0154 in)**

**2nd ring 0.35 - 0.59 mm (0.0138 - 0.0232 in)**


**Oil ring 0.20 - 0.69 mm (0.0079 - 0.0272 in)**

### Max. limit of ring gap:

**0.53 mm (0.0209 in)**

If out of specification, replace piston ring. If gap exceeds maximum limit with a new ring, rebore cylinder and use oversized piston and piston rings. Refer to "PISTON", EM-150.

- When replacing the piston, check cylinder block surface for scratches or seizure. If scratches or seizure are found, hone or replace the cylinder block.



SEM038F

## CONNECTING ROD BEND AND TORSION

NIEM0026S04

### Bend:

**Limit 0.15 mm (0.0059 in)**


**per 100 mm (3.94 in) length**

### Torsion:


**Limit 0.30 mm (0.0118 in)**

**per 100 mm (3.94 in) length**

If it exceeds the limit, replace connecting rod assembly.



SEM003F



AEM156

## CYLINDER BLOCK DISTORTION AND WEAR

NIEM0026S05

Clean upper surface of cylinder block.

Use a reliable straightedge and feeler gauge to check the flatness of cylinder block surface. Check along six positions shown in figure.

### Block surface flatness:

**Standard Less than 0.03 mm (0.0012 in)**

**Limit 0.10 mm (0.0039 in)**

If out of specification, resurface it.

The limit for cylinder block resurfacing is determined by the amount of cylinder head resurfacing.

**Amount of cylinder head resurfacing is "A".**

**Amount of cylinder block resurfacing is "B".**

### The maximum limit is as follows:


**A + B = 0.2 mm (0.0079 in)**

**Nominal cylinder block height**

**from crankshaft center:**




**211.25 - 211.35 mm (8.3169 - 8.3208 in)**

If necessary, replace cylinder block.



SEM008D

Inspection (Cont'd)



## PISTON-TO-BORE CLEARANCE

NIEM0026S06

- Using a bore gauge, measure cylinder bore for wear, out-of-round and taper.

**Standard inner diameter. Refer to "Cylinder Block", EM-149.**

**Wear limit:**

**0.20 mm (0.0079 in)**

**Out-of-round (X – Y) standard:**

**0.015 mm (0.0006 in)**

**Taper (A – B and A – C) standard:**

**0.010 mm (0.0004 in)**

If it exceeds the limit, rebores all cylinders. Replace cylinder block if necessary.

- Check for score and seizure. If seizure is found, hone it.
  - If cylinder block and piston are replaced, match piston grade with grade number on cylinder block upper surface.

- Measure piston skirt diameter.

**Piston diameter "A": Refer to "PISTON", EM-150.**

**Measuring point "a" (Distance from the top):**

**45.0 mm (1.772 in)**

- Check that piston-to-bore clearance is within specification.

**Piston-to-bore clearance = bore measurement "C" – Piston diameter "A":**

**0.010 - 0.030 mm (0.0004 - 0.0012 in)**

- Determine piston oversize according to amount of cylinder wear.

**Oversize pistons are available for service. Refer to "PISTON", EM-150.**

- Cylinder bore size is determined by adding piston-to-bore clearance to piston diameter "A".

**Rebored size calculation:**

$$D = A + B - C$$


where,

**D: Bored diameter**

**A: Piston diameter as measured**

**B: Piston-to-bore clearance**

**C: Honing allowance 0.02 mm (0.0008 in)**



Tighten in numerical order.

- Install main bearing caps and tighten to the specified torque. This will prevent distortion of cylinder bores, otherwise cylinder bores may be distorted in final assembly.

- Cut cylinder bores.

- When any cylinder needs boring, all other cylinders must also be bored.

- Do not cut too much out of cylinder bore at a time. Cut only 0.05 mm (0.0020 in) or so at a time.

- 9.hone cylinders to obtain specified piston-to-bore clearance.
10. Measure finished cylinder bore for out-of-round and taper.
  - **Measurement should be done after cylinder bore cools down.**

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL

IDX




## CRANKSHAFT

NIEM0026S07


1. Check crankshaft main and pin journals for score, wear or cracks.
2. With a micrometer, measure journals for taper and out-of-round.

**Out-of-round (X - Y) and Taper (A - B):**  
**Main journal: Less than 0.005 mm (0.0002 in)**  
**Pin journal: Less than 0.003 mm (0.0001 in)**



3. Measure crankshaft runout.

**Runout Limit (Total indicator reading):**  
**Less than 0.05 mm (0.0020 in)**



## BEARING CLEARANCE

NIEM0026S08

- Use Method A or Method B. Method A is preferred because it is more accurate.

### Method A (Using bore gauge and micrometer)


#### Main bearing

NIEM0026S0801


1. Set main bearings in their proper positions on cylinder block and main bearing cap.
2. Install main bearing cap and main bearing beam to cylinder block.

**Tighten all bolts in correct order in two or three stages. Refer to "CRANKSHAFT", EM-140.**

3. Measure inner diameter "A" of each main bearing.



Inspection (Cont'd)



4. Measure outer diameter "Dm" of each crankshaft main journal.
5. Calculate main bearing clearance.


**Main bearing clearance = A – Dm**

**Standard: 0.004 - 0.022 mm (0.0002 - 0.0009 in)**

**Limit: 0.050 mm (0.0020 in)**

If it exceeds the limit, replace bearing.


- If clearance cannot be adjusted within the standard of any bearing, grind crankshaft main journal and use undersized bearing.



- When grinding crankshaft journal, confirm that "L" dimension in fillet roll is more than the specified limit.


**"L": 0.1 mm (0.004 in)**

- Refer to "Crankshaft", EM-152 for grinding crankshaft and available service parts.



- If crankshaft is replaced, select thickness of main bearings as follows:

- a. Grade number of each cylinder block main journal is punched on the respective cylinder block. These numbers are punched in either Arabic or Roman numerals.




- b. Grade number of each crankshaft main journal is punched on the respective crankshaft. These numbers are punched in either Arabic or Roman numerals.

- c. Select main bearing with suitable thickness according to the following table.

**How to Select Main Bearings (Identification mark and color)**

NIEM0026S0802

| Crankshaft main journal grade number | Cylinder block main journal grade number |                  |                  |                    |
|--------------------------------------|--|------------------|------------------|--------------------|
|                                      | 0  | 1 or I           | 2 or II          | 3 or III           |
| 0                                    | 0<br>(A, Black)                          | 1<br>(B, Brown)  | 2<br>(C, Green)  | 3<br>(D, Yellow)   |
| 1 or I                               | 1<br>(B, Brown)                          | 2<br>(C, Green)  | 3<br>(D, Yellow) | 4<br>(E, Blue)     |
| 2 or II                              | 2<br>(C, Green)                          | 3<br>(D, Yellow) | 4<br>(E, Blue)   | 5<br>(F, Pink)     |
| 3 or III                             | 3<br>(D, Yellow)                         | 4<br>(E, Blue)   | 5<br>(F, Pink)   | 6<br>(G, No color) |









For example:

Cylinder block main journal grade number: 1

Crankshaft main journal grade number: 2

Main bearing grade number =

1 + 2 = 3 (D, Yellow)



## Connecting Rod Bearing (Big end)

NIEM0026S0803

1. Install connecting rod bearing to connecting rod and cap.

2. Install connecting rod cap to connecting rod.

**Tighten bolts to the specified torque. Refer to "CRANKSHAFT", EM-140.**

3. Measure inner diameter "C" of each bearing.

4. Measure outer diameter "Dp" of corresponding crankshaft pin journal.

5. Calculate connecting rod bearing clearance.

**Connecting rod bearing clearance = C - Dp**

**Standard: 0.020 - 0.045 mm (0.0008 - 0.0018 in)**

**Limit: 0.065 mm (0.0026 in)**

If it exceeds the limit, replace bearing.

- If clearance cannot be adjusted within the standard of any bearing, grind crankshaft journal and use undersized bearing. Refer to "BEARING CLEARANCE", EM-135 for fillet roll remarks, grinding crankshaft and available service parts.
- If crankshaft is replaced with a new one, select connecting rod bearing according to the following table.

### Connecting rod bearing grade number:

These numbers are punched in either Arabic or Roman numerals.

| Crank pin grade number | Connecting rod bearing grade number |
|------------------------|-------------------------------------|
| 0                      | 0                                   |
| 1                      | 1                                   |
| 2                      | 2                                   |

### Identification color:

**Grade 0; No color**

**Grade 1; Black**

**Grade 2; Brown**

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS


BT

HA

SC

EL


IDX



## Method B (Using Plastigage)

### CAUTION:


- Do not turn crankshaft or connecting rod while Plastigage is being inserted.
- If incorrect bearing clearance exists, use a thicker or undersized main bearing to ensure specified clearance.



## CONNECTING ROD BUSHING CLEARANCE (SMALL END)

NIEM0026S09

1. Measure inner diameter "C" of bushing.



2. Measure outer diameter "Dp" of piston pin.
  3. Calculate connecting rod bushing clearance.
- Connecting rod bushing clearance = C - Dp**


### Standard:

**0.005 - 0.017 mm (0.0002 - 0.0007 in)**

### Limit:

**0.023 mm (0.0009 in)**

If it exceeds the limit, replace connecting rod assembly or connecting rod bushing and/or piston set with pin.



## REPLACEMENT OF CONNECTING ROD BUSHING (SMALL END)

NIEM0026S10


1. Drive in small end bushing until it is flush with end surface of rod.

**Be sure to align the oil holes.**

2. Ream the bushing so that clearance with piston pin is within specification.

**Clearance between connecting rod bushing and piston pin:**


**0.005 - 0.017 mm (0.0002 - 0.0007 in)**




## REPLACEMENT OF PILOT BUSHING (M/T) OR PILOT CONVERTER (A/T)

NIEM0026S11

1. Remove pilot bushing or pilot converter using Tool or suitable tool.



2. Install pilot bushing or pilot converter as shown.



## FLYWHEEL/DRIVE PLATE RUNOUT

*NIEM0026S12*

Runout (Total indicator reading):

Flywheel (M/T model)


Less than 0.30 mm (0.012 in)

Drive plate (A/T model)

Less than 0.30 mm (0.012 in)

### CAUTION:


- Be careful not to damage the ring gear teeth.
- Check the drive plate for deformation or cracks.
- Do not allow any magnetic materials to contact the ring gear teeth.
- Do not resurface flywheel. Replace as necessary.



## Assembly PISTON

*NIEM0027*
*NIEM0027S01*

1. Install new snap ring on one side of piston pin hole.



2. Heat piston to 60 to 70°C (140 to 158°F) and assemble piston, piston pin, connecting rod and new snap ring.

- Align the direction of piston and connecting rod.
- Numbers stamped on connecting rod and cap correspond to each cylinder.
- After assembly, make sure connecting rod swings smoothly.

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC

EL

IDX


Assembly (Cont'd)




3. Set piston rings as shown.

**CAUTION:**

- When piston rings are not replaced, make sure that piston rings are mounted in their original positions.
- Install new piston rings either side up if there is no punch mark.




- Align piston rings so that end gaps are positioned as shown.








**CRANKSHAFT**

NIEM0027S02

1. Set main bearings in their proper positions on cylinder block and main bearing cap.
  - Confirm that correct main bearings are selected by using Method A or Method B. Refer to "BEARING CLEARANCE", EM-135.
  - Apply new engine oil to bearing surfaces.



2. Install crankshaft and main bearing caps, then tighten bolts to the specified torque.
  - Prior to tightening bearing cap bolts, shift crankshaft back and forth to properly seat the bearing cap.
  - Apply new engine oil to threads and seating surfaces of bearing cap bolts before installing them.
  - Tightening procedure:
    - a. Tighten all bolts to 7 to 12 N-m (0.7 to 1.3 kg-m, 61 to 112 ft-lb).



- b. Turn all bolts 70 to 80 degrees clockwise with Tool or suitable angle wrench.
- c. Loosen all bolts completely.
- d. Tighten all bolts to 33 to 38 N·m (3.3 to 3.9 kg·m, 24 to 28 ft·lb).
- e. Turn all bolts 30 to 35 degrees clockwise with Tool or suitable angle wrench.
  - If an angle wrench is not available, mark all bearing cap bolts on the side facing engine rear. Then, turn each bolt specified degrees clockwise. Confirm angle of degrees with a graduator, not by eye measurement.
  - After securing bearing cap bolts, make sure crankshaft turns smoothly by hand.

### 3. Measure crankshaft end play.

#### Crankshaft end play:

##### Standard

0.10 - 0.26 mm (0.0039 - 0.0102 in)

##### Limit

0.30 mm (0.0118 in)

If beyond the limit, replace thrust bearing with new one.

4. Install connecting rod bearings in connecting rods and connecting rod caps.
  - Confirm that correct bearings are used. Refer to "How to Select Main Bearings", EM-136.
  - Install bearings so that oil hole in connecting rod aligns with oil hole of bearing.
  - Apply new engine oil to bolt threads and bearing surfaces.
5. Install pistons with connecting rods.
  - a. Install them into corresponding cylinders with Tool.
    - Make sure connecting rod does not scratch cylinder wall.
    - Make sure connecting rod bolts do not scratch crankshaft pin journals.
    - Arrange so that front mark on piston head faces engine front.
    - Apply new engine oil to piston rings and sliding surface of piston.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT


HA

SC


EL

IDX

## Assembly (Cont'd)



- b. Install connecting rod caps.
  - **Apply new engine oil to threads and seat surfaces.** Tighten connecting rod cap nuts using the following procedure:
    - a) **Tighten nuts to 14 to 16 N·m (1.4 to 1.6 kg·m, 10 to 12 ft·lb).**
    - b) **Turn all nuts 60 to 65 degrees clockwise. If an angle wrench is not available, tighten nuts to 38 to 44 N·m (3.9 to 4.5 kg·m, 28 to 33 ft·lb).**




6. Measure connecting rod side clearance.
 

**Connecting rod side clearance:**


**Standard**  
**0.20 - 0.35 mm (0.0079 - 0.0138 in)**

**Limit**  
**0.50 mm (0.0197 in)**


If beyond the limit, replace connecting rod and/or crankshaft.



7. Install rear oil seal retainer.
  - a. Before installing rear oil seal retainer, remove old RTV Silicone Sealant from mating surface.
    - Also remove old RTV Silicone Sealant from mating surface of cylinder block.



- b. Apply a continuous bead of RTV Silicone Sealant to mating surface of rear oil seal retainer.
  - **Use Genuine RTV Silicone Sealant Part No. 999MP-A7007 or equivalent.**
  - **Apply around inner side of bolt holes.**



8. Install knock sensor at correct angle.
  - For Canadian vehicles, increase installation angle to 90°.

# SERVICE DATA AND SPECIFICATIONS (SDS)

**SR20DE**

General Specifications

## General Specifications

NIEM0028

|                                      |                       |   |
|--------------------------------------|-----------------------|---|
| Cylinder arrangement                 | In-line 4             |   |
| Displacement cm <sup>3</sup> (cu in) | 1,998 (121.92)        |   |
| Bore and stroke mm (in)              | 86 x 86 (3.39 x 3.39) |   |
| Valve arrangement                    | DOHC                  |   |
| Firing order                         | 1-3-4-2               |   |
| Number of piston rings               | Compression           | 2 |
|                                      | Oil                   | 1 |
| Number of main bearings              | 5                     |   |
| Compression ratio                    | 9.8                   |   |

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

|                              |      |      |    |     |    |     |
|------------------------------|------|------|----|-----|----|-----|
| Valve timing<br>Unit: degree |      |      |    |     |    |     |
|                              | a    | b    | c  | d   | e  | f   |
|                              | 232° | 240° | 6° | 54° | 3° | 49° |

EM120

## Compression Pressure

Unit: kPa (kg/cm<sup>2</sup>, psi)/300 rpm <sup>NIEM0029</sup>

|                      |                                      |                   |
|----------------------|--------------------------------------|-------------------|
| Compression pressure | Standard                             | 1,226 (12.5, 178) |
|                      | Minimum                              | 1,030 (10.5, 149) |
|                      | Differential limit between cylinders | 98 (1.0, 14)      |

## Cylinder Head

Unit: mm (in) <sup>NIEM0030</sup>

|  |                                  |                               |             |
|--|----------------------------------|-------------------------------|-------------|
|  |                                  | Standard                      | Limit       |
|  | Head surface distortion          | Less than 0.03 (0.0012)       | 0.1 (0.004) |
|  | Nominal cylinder head height "H" | 136.9 - 137.1 (5.390 - 5.398) |             |
|  | Resurfacing limit*               | 0.2 (0.008)*                  |             |


\*Total amount of cylinder head resurfacing plus cylinder block resurfacing

Valve

NIEM0031

VALVE

NIEM0031S01  
Unit: mm (in)



SEM188A

|                                       |         |                                   |
|---------------------------------------|---------|-----------------------------------|
| Valve head diameter "D"               | Intake  | 34.0 - 34.3 (1.339 - 1.350)       |
|                                       | Exhaust | 30.0 - 30.3 (1.181 - 1.193)       |
| Valve length "L"                      | Intake  | 101.19 - 101.61 (3.9839 - 4.0004) |
|                                       | Exhaust | 102.11 - 102.53 (4.0201 - 4.0366) |
| Valve stem diameter "d"               | Intake  | 5.965 - 5.980 (0.2348 - 0.2354)   |
|                                       | Exhaust | 5.945 - 5.960 (0.2341 - 0.2346)   |
| Valve seat angle "α"                  | Intake  | 45°15' - 45°45'                   |
|                                       | Exhaust |                                   |
| Valve margin "T"                      | Intake  | 1.1 (0.043)                       |
|                                       | Exhaust | 1.3 (0.051)                       |
| Valve margin "T" limit                |         | More than 0.5 (0.020)             |
| Valve stem end surface grinding limit |         | Less than 0.2 (0.008)             |

VALVE SPRING

NIEM0031S02

|  |          |   |
|--|----------|---|
| Free height mm (in)                      |          | 49.36 (1.9433)  |
| Pressure<br>N (kg, lb) at height mm (in) | Standard | 578.02 - 641.57 (58.94 - 65.42, 129.96 - 144.25)<br>at 30.0 (1.181) |
|  | Limit    | 549.2 (56.0, 123.5) at 30.0 (1.181)                                 |
| Out-of-square mm (in)                    |          | Less than 2.2 (0.087)   |

HYDRAULIC LASH ADJUSTER (HLA)

NIEM0031S03  
Unit: mm (in)

|  |                                   |
|--|-----------------------------------|
| HLA outer diameter                       | 16.980 - 16.993 (0.6685 - 0.6690) |
| HLA guide hole diameter                  | 17.000 - 17.020 (0.6693 - 0.6701) |
| Clearance between HLA and HLA guide hole | 0.007 - 0.040 (0.0003 - 0.0016)   |




# SERVICE DATA AND SPECIFICATIONS (SDS)

**SR20DE**  
Valve (Cont'd)

## VALVE GUIDE

NIEM0031S04  
Unit: mm (in)




SEM083D

|   |         | Standard                          | Service                           |
|---|---------|-----------------------------------|-----------------------------------|
| Valve guide<br>Outer diameter                 | Intake  | 10.023 - 10.034 (0.3946 - 0.3950) | 10.223 - 10.234 (0.4025 - 0.4029) |
|   | Exhaust | 10.023 - 10.034 (0.3946 - 0.3950) | 10.223 - 10.234 (0.4025 - 0.4029) |
| Valve guide<br>Inner diameter (Finished size) | Intake  | 6.000 - 6.018 (0.2362 - 0.2369)   |                                   |
|   | Exhaust | 6.000 - 6.018 (0.2362 - 0.2369)   |                                   |
| Cylinder head valve guide hole<br>diameter    | Intake  | 9.975 - 9.996 (0.3927 - 0.3935)   | 10.175 - 10.196 (0.4006 - 0.4014) |
|   | Exhaust | 9.975 - 9.996 (0.3927 - 0.3935)   | 10.175 - 10.196 (0.4006 - 0.4014) |
| Interference fit of valve guide               |         | 0.027 - 0.059 (0.0011 - 0.0023)   |                                   |
|   |         | Standard                          | Limit                             |
| Stem to guide clearance                       | Intake  | 0.020 - 0.053 (0.0008 - 0.0021)   | 0.08 (0.0031)                     |
|   | Exhaust | 0.040 - 0.073 (0.0016 - 0.0029)   | 0.1 (0.004)                       |
| Valve deflection limit                        |         | 0.2 (0.008)                       |                                   |
| Projection length "L"                         |         | 14.0 - 14.2 (0.551 - 0.559)       |                                   |

## VALVE SHIM CLEARANCE ADJUSTMENT

NIEM0031S05  
Unit: mm (in)



SEM095D

|   |                                |
|---|--------------------------------|
| Valve shim clearance (cold)<br>Intake & Exhaust | Less than 0.025 (0.001)        |
| Shim thickness "T <sub>1</sub> "                | T <sub>1</sub> ± 0.025 (0.001) |


# SERVICE DATA AND SPECIFICATIONS (SDS)

SR20DE

Valve (Cont'd)

## AVAILABLE SHIM

NIEM0031S06



AEM236


| Thickness mm (in) | Identification mark |
|-------------------|---------------------|
| 2.800 (0.1102)    | 28<br>00            |
| 2.825 (0.1112)    | 28<br>25            |
| 2.850 (0.1122)    | 28<br>50            |
| 2.875 (0.1132)    | 28<br>75            |
| 2.900 (0.1142)    | 29<br>00            |
| 2.925 (0.1152)    | 29<br>25            |
| 2.950 (0.1161)    | 29<br>50            |
| 2.975 (0.1171)    | 29<br>75            |
| 3.000 (0.1181)    | 30<br>00            |
| 3.025 (0.1191)    | 30<br>25            |
| 3.050 (0.1201)    | 30<br>50            |
| 3.075 (0.1211)    | 30<br>75            |
| 3.100 (0.1220)    | 31<br>00            |
| 3.125 (0.1230)    | 31<br>25            |
| 3.150 (0.1240)    | 31<br>50            |
| 3.175 (0.1250)    | 31<br>75            |
| 3.200 (0.1260)    | 32<br>00            |

# SERVICE DATA AND SPECIFICATIONS (SDS)

**SR20DE**  
Valve (Cont'd)

## VALVE SEAT

NIEM0031S07  
Unit: mm (in)




SEM651DB

|  |     | Standard                          | Service                           |
|--|-----|-----------------------------------|-----------------------------------|
| Cylinder head seat recess diameter (D) | In. | 35.000 - 35.016 (1.3780 - 1.3786) | 35.500 - 35.516 (1.3976 - 1.3983) |
|  | Ex. | 31.000 - 31.016 (1.2205 - 1.2211) | 31.500 - 31.516 (1.2402 - 1.2408) |
| Valve seat interference fit            | In. | 0.064 - 0.096 (0.0025 - 0.0038)   |                                   |
|  | Ex. | 0.064 - 0.096 (0.0025 - 0.0038)   |                                   |
| Valve seat outer diameter (d)          | In. | 35.080 - 35.096 (1.3811 - 1.3817) | 35.580 - 35.596 (1.4008 - 1.4014) |
|  | Ex. | 31.080 - 31.096 (1.2236 - 1.2242) | 31.580 - 31.596 (1.2433 - 1.2439) |
| Depth (H)                              | In. | 6.25 (0.2461)                     |                                   |
|  | Ex. | 6.25 (0.2461)                     |                                   |
| Height (h)                             |     | 6.2 - 6.3 (0.244 - 0.248)         | 5.4 - 5.5 (0.213 - 0.217)         |

Valve (Cont'd)

**VALVE SEAT RESURFACE LIMIT**

NIEM0031S08  
Unit: mm (in)




AEM343

|           |                                 |
|-----------|---------------------------------|
| Depth (L) | 42.74 - 43.26 (1.6827 - 1.7031) |
|-----------|---------------------------------|

**Camshaft and Camshaft Bearing**

NIEM0032  
Unit: mm (in)

|                                       | Standard                          | Limit         |
|---------------------------------------|-----------------------------------|---------------|
| Camshaft journal to bearing clearance | 0.045 - 0.090 (0.0018 - 0.0035)   | 0.15 (0.0059) |
| Inner diameter of camshaft bearing    | 28.000 - 28.021 (1.1024 - 1.1032) | —             |
| Outer diameter of camshaft journal    | 27.935 - 27.955 (1.0998 - 1.1006) | —             |
| Camshaft runout [TIR*]                | Less than 0.02 (0.0008)           | 0.1 (0.004)   |
| Camshaft sprocket runout [TIR*]       | Less than 0.25 (0.0098)           | —             |
| Camshaft end play                     | 0.055 - 0.139 (0.0022 - 0.0055)   | 0.20 (0.0079) |





EM671

|                          |         |                                   |
|--------------------------|---------|-----------------------------------|
| Cam height "A"           | Intake  | 37.680 - 37.870 (1.4835 - 1.4909) |
|                          | Exhaust | 37.309 - 37.499 (1.4689 - 1.4763) |
| Wear limit of cam height |         | 0.2 (0.008)                       |
| Valve lift               | Intake  | 8.6 (0.339)                       |
|                          | Exhaust | 9.2 (0.362)                       |

\*Total indicator reading

Cylinder Block

Unit: mm (in) <sup>NIEM0033</sup>



SEM008D

SEM686DB

|  |             |             |                                   |
|--|-------------|-------------|-----------------------------------|
| Nominal cylinder block height from crankshaft center | Standard    |             | 211.25 - 211.35 (8.3169 - 8.3208) |
| Surface flatness                                     | Standard    |             | Less than 0.03 (0.0012)           |
|  | Limit       |             | 0.10 (0.0039)                     |
| Cylinder bore<br>Inner diameter                      | Standard    | Grade No. 1 | 86.000 - 86.010 (3.3858 - 3.3862) |
|  |             | Grade No. 2 | 86.010 - 86.020 (3.3862 - 3.3866) |
|  |             | Grade No. 3 | 86.020 - 86.030 (3.3866 - 3.3870) |
|  | Wear limit  |             | 0.20 (0.0079)                     |
| Out-of-round (X - Y)                                 |             |             | Less than 0.015 (0.0006)          |
| Taper (A - B and A - C)                              |             |             | Less than 0.010 (0.0004)          |
| Difference in inner diameter between cylinders       | Limit       |             | Less than 0.05 (0.0020)           |
| Main journal inner diameter                          | Grade No. 0 |             | 58.944 - 58.950 (2.3206 - 2.3209) |
|  | Grade No. 1 |             | 58.950 - 58.956 (2.3209 - 2.3211) |
|  | Grade No. 2 |             | 58.956 - 58.962 (2.3211 - 2.3213) |
|  | Grade No. 3 |             | 58.962 - 58.968 (2.3213 - 2.3216) |

GI

MA

**EM**

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

## Piston, Piston Ring and Piston pin

NIEM0034

### PISTON

 NIEM0034S01  
 Unit: mm (in)


SEM086G

|                                       |                                  |                                   |
|---------------------------------------|----------------------------------|-----------------------------------|
| Piston skirt diameter "A"<br>Standard | Grade No. 1                      | 85.980 - 85.990 (3.3850 - 3.3854) |
|                                       | Grade No. 2                      | 85.990 - 86.000 (3.3854 - 3.3858) |
|                                       | Grade No. 3                      | 86.000 - 86.010 (3.3858 - 3.3862) |
|                                       | 0.20 (0.0079) oversize (Service) | 86.180 - 86.210 (3.3929 - 3.3941) |
| "a" dimension                         |                                  | 45.0 (1.772)                      |
| Piston clearance to cylinder block    |                                  | 0.010 - 0.030 (0.0004 - 0.0012)   |
| Piston pin hole diameter              |                                  | 21.993 - 22.005 (0.8659 - 0.8663) |

### PISTON RING

 NIEM0034S02  
 Unit: mm (in)

|                |     |          |                                 |
|----------------|-----|----------|---------------------------------|
| Side clearance | Top | Standard | 0.040 - 0.080 (0.0016 - 0.0031) |
|                |     | Limit    | 0.1 (0.004)                     |
|                | 2nd | Standard | 0.030 - 0.070 (0.0012 - 0.0028) |
|                |     | Limit    | 0.1 (0.004)                     |
|                | Oil | Standard | 0.065 - 0.135 (0.0026 - 0.0053) |
|                |     | Limit    | 0.1 (0.004)                     |
| Ring end gap   | Top | Standard | 0.20 - 0.39 (0.0079 - 0.0154)   |
|                |     | Limit    | 0.53 (0.0209)                   |
|                | 2nd | Standard | 0.35 - 0.59 (0.0138 - 0.0232)   |
|                |     | Limit    | 0.53 (0.0209)                   |
|                | Oil | Standard | 0.20 - 0.69 (0.0079 - 0.0272)   |
|                |     | Limit    | 0.53 (0.0209)                   |

### PISTON PIN

 NIEM0034S03  
 Unit: mm (in)

|  |          |                                   |
|--|----------|-----------------------------------|
| Piston pin outer diameter                      |          | 21.989 - 22.001 (0.8657 - 0.8622) |
| Interference fit of piston pin to piston       |          | 0.005 - 0.017 (0.0002 - 0.0007)   |
| Piston pin to connecting rod bushing clearance | Standard | 0.005 - 0.017 (0.0002 - 0.0007)   |
|  | Limit    | 0.023 (0.0009)                    |

\* Values measured at ambient temperature of 20°C (68°F)

# SERVICE DATA AND SPECIFICATIONS (SDS)

**SR20DE**

Connecting Rod

## Connecting Rod

Unit: mm (in) <sup>NIEM0035</sup>


|   |          |                                   |           |
|---|----------|-----------------------------------|-----------|
| Center distance                         |          | 136.25 - 136.35 (5.3642 - 5.3681) | GI        |
| Bend [per 100 (3.94)]                   | Limit    | 0.15 (0.0059)                     | MA        |
| Torsion [per 100 (3.94)]                | Limit    | 0.30 (0.0118)                     |           |
| Connecting rod small end inner diameter |          | 24.980 - 25.000 (0.9835 - 0.9843) | <b>EM</b> |
| Piston pin bushing inner diameter*      |          | 22.000 - 22.012 (0.8661 - 0.8666) |           |
| Connecting rod big end inner diameter   |          | 51.000 - 51.013 (2.0079 - 2.0084) | LC        |
| Side clearance                          | Standard | 0.20 - 0.35 (0.0079 - 0.0138)     |           |
|   | Limit    | 0.5 (0.0197)                      | EC        |

\*After installing in connecting rod

GI  
MA  
**EM**  
LC  
EC  
FE  
CL  
MT  
AT  
AX  
SU  
BR  
ST  
RS  
BT  
HA  
SC  
EL  
IDX


Crankshaft

Unit: mm (in) NIEM0036



SEM954C

Out-of-round (X - Y)  
Taper (A - B)



EM715

|                                  |              |                                   |
|----------------------------------|--------------|-----------------------------------|
| Main journal dia. "Dm"           | Grade No. 0  | 54.974 - 54.980 (2.1643 - 2.1646) |
|                                  | Grade No. 1  | 54.968 - 54.974 (2.1641 - 2.1643) |
|                                  | Grade No. 2  | 54.962 - 54.968 (2.1639 - 2.1641) |
|                                  | Grade No. 3  | 54.956 - 54.962 (2.1636 - 2.1639) |
| Pin journal dia. "Dp"            | Grade No. 0  | 47.968 - 47.974 (1.8885 - 1.8887) |
|                                  | Grade No. 1  | 47.962 - 47.968 (1.8883 - 1.8885) |
|                                  | Grade No. 2  | 47.956 - 47.962 (1.8880 - 1.8883) |
| Center distance "r"              |              | 42.96 - 43.04 (1.6913 - 1.6945)   |
| Out-of-round (X - Y)<br>Standard | Main journal | Less than 0.005 (0.0002)          |
|                                  | Pin journal  | Less than 0.003 (0.0001)          |
| Taper (A - B)<br>Standard        | Main journal | Less than 0.005 (0.0002)          |
|                                  | Pin journal  | Less than 0.003 (0.0001)          |
| Runout [TIR]                     | Standard     | Less than 0.025 (0.0010)          |
|                                  | Limit        | Less than 0.05 (0.0020)           |
| Free end play                    | Standard     | 0.10 - 0.26 (0.0039 - 0.0102)     |
|                                  | Limit        | 0.30 (0.0118)                     |



# SERVICE DATA AND SPECIFICATIONS (SDS)

**SR20DE**  
Main Bearing

## Main Bearing

NIEM0037

### STANDARD

NIEM0037S01  
Unit: mm (in)

| Grade number | Thickness "T"                   | Width "W"                   | Identification color (mark) |
|--------------|---------------------------------|-----------------------------|-----------------------------|
| 0            | 1.977 - 1.980 (0.0778 - 0.0780) | 18.9 - 19.1 (0.744 - 0.752) | Black (A)                   |
| 1            | 1.980 - 1.983 (0.0780 - 0.0781) |                             | Brown (B)                   |
| 2            | 1.983 - 1.986 (0.0781 - 0.0782) |                             | Green (C)                   |
| 3            | 1.986 - 1.989 (0.0782 - 0.0783) |                             | Yellow (D)                  |
| 4            | 1.989 - 1.992 (0.0783 - 0.0784) |                             | Blue (E)                    |
| 5            | 1.992 - 1.995 (0.0784 - 0.0785) |                             | Pink (F)                    |
| 6            | 1.995 - 1.998 (0.0785 - 0.0787) |                             | No color (G)                |

### UNDERSIZE

NIEM0037S02  
Unit: mm (in)

| Undersize     | Thickness "T"                   | Main journal diameter "Dm"                              |
|---------------|---------------------------------|---|
| 0.25 (0.0098) | 2.109 - 2.117 (0.0830 - 0.0833) | Grind so that bearing clearance is the specified value. |

## Connecting Rod Bearing

NIEM0038

### STANDARD SIZE

NIEM0038S01  
Unit: mm (in)

| Grade number | Thickness "T"                   | Width "W"                   | Identification color (mark) |
|--------------|---------------------------------|-----------------------------|-----------------------------|
| 0            | 1.500 - 1.503 (0.0591 - 0.0592) | 16.9 - 17.1 (0.665 - 0.673) | No color (A)                |
| 1            | 1.503 - 1.506 (0.0592 - 0.0593) |                             | Black (B)                   |
| 2            | 1.506 - 1.509 (0.0593 - 0.0594) |                             | Brown (C)                   |

### UNDERSIZE

NIEM0038S02  
Unit: mm (in)

| Undersize     | Thickness "T"                   | Crank pin journal diameter "Dp"                         |
|---------------|---------------------------------|---|
| 0.08 (0.0031) | 1.541 - 1.549 (0.0607 - 0.0610) | Grind so that bearing clearance is the specified value. |
| 0.12 (0.0047) | 1.561 - 1.569 (0.0615 - 0.0618) |   |
| 0.25 (0.0098) | 1.626 - 1.634 (0.0640 - 0.0643) |   |

## Bearing Clearance

NIEM0039  
Unit: mm (in)

|                                  |          |                                 |
|----------------------------------|----------|---------------------------------|
| Main bearing clearance           | Standard | 0.004 - 0.022 (0.0002 - 0.0009) |
|                                  | Limit    | 0.05 (0.0020)                   |
| Connecting rod bearing clearance | Standard | 0.020 - 0.045 (0.0008 - 0.0018) |
|                                  | Limit    | 0.065 (0.0026)                  |

## Miscellaneous Components

NIEM0040  
Unit: mm (in)

|                                      |               |
|--------------------------------------|---------------|
| Camshaft sprocket runout limit [TIR] | 0.25 (0.0098) |
| Flywheel runout limit [TIR]          | 0.30 (0.012)  |
| Drive plate runout limit [TIR]       | 0.30 (0.012)  |

## NOTES