

MANUAL TRANSAXLE

SECTION MT

GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

CONTENTS

| | | | |
|---|----|--|----|
| PREPARATION | 2 | INSPECTION..... | 33 |
| Special Service Tools | 2 | ASSEMBLY | 35 |
| Commercial Service Tools | 4 | Final Drive..... | 40 |
| NOISE, VIBRATION AND HARSHNESS (NVH) | | PRE-INSPECTION | 40 |
| TROUBLESHOOTING | 6 | DISASSEMBLY..... | 41 |
| NVH Troubleshooting Chart..... | 6 | INSPECTION..... | 42 |
| DESCRIPTION | 7 | ASSEMBLY | 43 |
| Cross-sectional View | 7 | Shift Control Components | 46 |
| DOUBLE-CONE SYNCHRONIZER | 8 | INSPECTION..... | 46 |
| ON-VEHICLE SERVICE | 9 | ASSEMBLY | 47 |
| Replacing Oil Seal | 9 | Clutch Housing | 47 |
| DIFFERENTIAL OIL SEAL | 9 | Transaxle Case..... | 51 |
| STRIKING ROD OIL SEAL | 9 | SERVICE DATA AND SPECIFICATIONS (SDS) | 56 |
| Position Switch Check | 10 | General Specifications..... | 56 |
| BACK-UP LAMP SWITCH | 10 | TRANSAXLE | 56 |
| PNP SWITCH | 10 | FINAL GEAR | 56 |
| Viscous Coupling Check..... | 11 | Gear End Play | 57 |
| REMOVAL AND INSTALLATION | 12 | Clearance Between Baulk Ring and Gear | 57 |
| Removal..... | 12 | 3RD, 4TH, 5TH, REVERSE BAULK RING..... | 57 |
| Installation..... | 14 | 1ST AND 2ND BAULK RING | 57 |
| - QG ENGINE - | 14 | Available Snap Rings | 57 |
| Installation..... | 15 | SNAP RING..... | 57 |
| - SR ENGINE - | 15 | Available C-rings..... | 58 |
| OVERHAUL | 16 | 4TH INPUT GEAR C-RING | 58 |
| Transaxle Gear Control | 16 | 5TH INPUT GEAR REAR C-RING | 58 |
| Case Components..... | 17 | MAINSHAFT C-RING | 58 |
| Gear Components | 18 | Available Adjusting Shims | 59 |
| Shift Control Components | 19 | INPUT SHAFT REAR BEARING ADJUSTING | |
| Final Drive Components..... | 20 | SHIM | 59 |
| DISASSEMBLY | 21 | MAINSHAFT ADJUSTING SHIM..... | 60 |
| Transaxle Case..... | 21 | MAINSHAFT REAR BEARING ADJUSTING SHIM | 60 |
| Clutch Housing | 23 | Available Thrust Washer..... | 61 |
| MAINSHAFT THRUST WASHER..... | 61 | Available Washers | 61 |
| DIFFERENTIAL SIDE GEAR THRUST WASHER..... | 61 | DIFFERENTIAL SIDE GEAR THRUST WASHER..... | 61 |
| REPAIR FOR COMPONENT PARTS | 27 | Available Shims - Differential Side Bearing | |
| Input Shaft and Gears | 27 | Preload and Adjusting Shim | 62 |
| DISASSEMBLY | 27 | BEARING PRELOAD | 62 |
| INSPECTION..... | 28 | DIFFERENTIAL SIDE BEARING ADJUSTING | |
| ASSEMBLY | 29 | SHIMS | 62 |
| Mainshaft and Gears | 32 | | |
| DISASSEMBLY..... | 32 | | |







PREPARATION

Special Service Tools

Special Service Tools








NJMT0001

The actual shapes of Kent-Moore tools may differ from those of special service tools illustrated here.

| Tool number (Kent-Moore No.) Tool name | Description | |
|---|--|--|
| KV38107700 (J39027) Preload adapter |  <p>NT087</p> | Measuring turning torque of final drive assembly Measuring total turning torque Measuring clearance between side gear and differential case with washer Selecting differential side bearing adjusting shim [Use with KV38106000 (J34291-B).] |
| KV38106000 (J34291-B) Height gauge adapter (differential side bearing) |  <p>NT418</p> | Selecting differential side bearing adjusting shim [Use with KV38107700 (J39027).] a: 140 mm (5.51 in) b: 40 mm (1.57 in) c: 16 mm (0.63 in) dia. d: M8 × 1.25P |
| KV32101000 (J25689-A) Pin punch |  <p>NT410</p> | Removing and installing retaining pin Removing and installing lock pin Removing selector shaft Removing welch plug a: 4 mm (0.16 in) dia. |
| KV31100300 (J25689-A) Pin punch |  <p>NT410</p> | Removing and installing retaining pin a: 4.5 mm (0.177 in) dia. |
| ST30031000 (J22912-O1) Puller |  <p>NT411</p> | Removing 3rd, 5th input gear Removing 3rd & 4th and 5th & Rev synchronizer hub Removing mainshaft rear bearing Removing 2nd gear, 5th gear bush Removing 1st & 2nd synchronizer hub, 1st and 4th main gear Removing and installing differential side bearing a: 90 mm (3.54 in) dia. b: 50 mm (1.97 in) dia. |
| ST30021000 (J22912-O1) Puller |  <p>NT411</p> | Removing input shaft front and rear bearing Installing input shaft front and rear bearing Installing 5th input gear, 3rd main gear and 4th main gear Installing 1st & 2nd, 3rd & 4th and 5th & Rev synchronizer hub Installing 2nd gear bush, 5th gear bush, Rev gear bush Installing mainshaft rear bearing a: 110 mm (4.33 in) dia. b: 68 mm (2.68 in) dia. |



PREPARATION

Special Service Tools (Cont'd)

| Tool number (Kent-Moore No.) Tool name | Description | | |
|--|---|---|--|
| ST33061000 (J8107-2) Drift |  | Removing differential side bearing a: 39 mm (1.54 in) dia. b: 29.5 mm (1.16 in) dia. | GI MA EM |
| ST33290001 (J34286) Puller |  | ● Removing idler gear bearing outer race a: 250 mm (9.84 in) b: 160 mm (6.30 in) | LC EC FE |
| ST33230000 (J25805-O1) Drift |  | Removing differential oil seal Installing differential side bearing a: 51 mm (2.01 in) dia. b: 28.5 mm (1.122 in) dia. | CL <div style="background-color: black; color: white; padding: 2px; text-align: center;">MT</div> |
| ST30720000 (J25405) Drift |  | Installing differential side bearing outer race (F70A and clutch housing side of F70V) a: 77 mm (3.03 in) dia. b: 55.5 mm (2.185 in) dia. | AT AX SU |
| ST22350000 (J25678-O1) Drift |  | Installing input shaft front and rear bearing a: 34 mm (1.34 in) dia. b: 28 mm (1.10 in) dia. | BR ST |
| ST22452000 (J34335) Drift |  | Installing 3rd and 4th main gear Installing 5th gear bush Installing 5th & Rev synchronizer hub Installing Rev gear bush Installing mainshaft rear bearing a: 45 mm (1.77 in) dia. b: 36 mm (1.42 in) dia. | RS BT |
| ST37750000 (J34335) Drift |  | Installing input shaft oil seal Installing 5th synchronizer Installing mainshaft rear bearing Installing 5th main gear Installing 3rd & 4th synchronizer hub Installing striking rod oil seal Installing clutch housing dust seal a: 40 mm (1.57 in) dia. b: 31 mm (1.22 in) dia. | HA SC EL |







PREPARATION

Special Service Tools (Cont'd)

| Tool number (Kent-Moore No.) Tool name | Description | |
|--|---|--|
| ST30621000 (J35869) Drift |  | Installing differential side bearing outer race [Use with ST30611000 (J25742-1).] (F70A and clutch housing side of F70V) a: 79 mm (3.11 in) dia. b: 59 mm (2.32 in) dia. |
| ST30611000 (J25742-1) Drift handle |  | Installing differential side bearing outer race [Use with ST30621000 (J35869).] a: 15 mm (0.59 in) b: 335 mm (13.19 in) c: 25 mm (0.98 in) dia. d: M12 x 1.5P |





Commercial Service Tools

NIMT0002

| Tool name | Description | |
|-----------|---|---|
| Drift |  | Installing differential side bearing inner race (F70A and except viscous coupling side of F70V) a: 56 mm (2.20 in) dia. b: 50.5 mm (1.988 in) dia. |
| Drift |  | Installing differential oil seal (F70V transaxle case side) a: 94 mm (3.70 in) dia. b: 72 mm (2.83 in) dia. |
| Drift |  | Installing differential side bearing outer race (F70V viscous coupling side) a: 104 mm (4.09 in) dia. b: 98 mm (3.86 in) dia. |
| Drift |  | Installing differential side bearing inner race (F70V viscous coupling side) a: 91 mm (3.58 in) dia. b: 81 mm (3.19 in) dia. |
| Drift |  | Removing input shaft rear bearing Removing mainshaft rear bearing a: 22 mm (0.87 in) dia. b: 16 mm (0.63 in) dia. |
| Drift |  | Installing differential oil seal (Transaxle case side of F70A and clutch housing side of F70V) a: 58 mm (2.28 in) dia. b: 50 mm (1.97 in) dia. |

PREPARATION

Commercial Service Tools (Cont'd)

| Tool name | Description | |
|------------------------------------|--|------------------------------|
| Drift NT065 |  <p data-bbox="950 220 1258 336">Installing differential oil seal (Clutch housing side of F70A) a: 54 mm (2.13 in) dia. b: 50 mm (1.97 in) dia.</p> | GI MA |
| Drift NT065 |  <p data-bbox="950 399 1201 483">Installing 2nd gear bush a: 38 mm (1.50 in) dia. b: 33 mm (1.30 in) dia.</p> | EM LC |
| Drift NT065 |  <p data-bbox="950 577 1437 714">Installing 3rd & 4th and 1st & 2nd synchronizer hub Installing mainshaft front bearing a: 50 mm (1.97 in) dia. b: 41 mm (1.61 in) dia.</p> | EC FE |
| Drift NT065 |  <p data-bbox="950 756 1242 871">Installing input shaft oil seal Installing 5th input gear a: 39 mm (1.54 in) dia. b: 30 mm (1.18 in) dia.</p> | CL MT |

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL

IDX

NOISE, VIBRATION AND HARSHNESS (NVH) TROUBLESHOOTING

NVH Troubleshooting Chart

NVH Troubleshooting Chart

NIMT0003S01

Use the chart below to help you find the cause of the symptom. The numbers indicate the order of the inspection. If necessary, repair or replace these parts.


| Symptom | | SUSPECTED PARTS (Possible cause) | | | | | | | | | | | | | Reference page |
|---------|---------------------------------|-------------------------------------|-------------|----------------------|------------------|----------------------------|--------------------------|--------------------|---|-------------------|------------------------|---------------------------|------------------------------|--|---|
| | | (Oil level is low.) | (Wrong oil) | (Oil level is high.) | GASKET (Damaged) | OIL SEAL (Worn or damaged) | O-RING (Worn or damaged) | CONTROL ROD (Worn) | CHECK PLUG RETURN SPRING AND CHECK BALL (Worn or damaged) | SHIFT FORK (Worn) | GEAR (Worn or damaged) | BEARING (Worn or damaged) | BAULK RING (Worn or damaged) | INSERT SPRING, SHIFTING INSERT (Damaged) | |
| Noise | Oil leakage | 1 | 2 | | | | | | | | 3 | 3 | | | Refer to MA-35 , "Checking M/T Oil". |
| | Hard to shift or will not shift | | 1 | 1 | | | | 2 | | | | | 3 | 3 | MT-17 |
| | Jumps out of gear | | | | | | | 1 | 2 | 3 | 3 | | | | MT-17 |
| | | | | | | | | | | | | | | | |
| | | | | | | | | | | | | | | | MT-17 |
| | | | | | | | | | | | | | | | MT-16 |
| | | | | | | | | | | | | | | | MT-19 |
| | | | | | | | | | | | | | | | MT-19 |
| | | | | | | | | | | | | | | | MT-18 |
| | | | | | | | | | | | | | | | MT-18 |
| | | | | | | | | | | | | | | | MT-18 |

DESCRIPTION

Cross-sectional View

Cross-sectional View


NIMT0004S01



- GI
- MA
- EM
- LC
- EC
- FE
- CL
- MT**
- AT
- AX
- SU
- BR
- ST
- RS
- BT
- HA
- SC
- EL
- IDX

DESCRIPTION



Cross-sectional View (Cont'd)



DOUBLE-CONE SYNCHRONIZER

NIMT0004SD101

Double-cone synchronizer is adopted for 1st and 2nd gears to reduce operating force of the shift lever.



Replacing Oil Seal DIFFERENTIAL OIL SEAL

NIMT0005

NIMT0005S01



1. Remove drain plug and drain gear oil from transaxle.
2. Remove drive shafts. Refer to **AX-12**, "Removal".
3. Remove differential oil seal using Tool.

4. Install differential oil seal with a suitable tool.
 - **Apply multi-purpose grease to seal lip of oil seal before installing.**
5. Install drive shafts. Refer to **AX-13**, "Installation".

- **Install differential oil seal so that dimension "A" and "B" are within specifications.**

Unit: mm (in)

| Item | Model | A | B |
|-----------|-------------------------------|---------------------|---------------------------|
| Dimension | QG18DE SR20DE (RS5F70A) | 0.5 (0.020) or less | 5.5 - 6.5 (0.217 - 0.256) |
| | SR20DE (RS5F70V) | | 0.5 (0.020) or less |



STRIKING ROD OIL SEAL

NIMT0005S02

1. Remove transaxle control rod from yoke.
2. Remove retaining pin of yoke using Tool.
 - **Be careful not to damage boot.**
3. Remove the boot.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA



SC

EL

IDX

ON-VEHICLE SERVICE

Replacing Oil Seal (Cont'd)



4. Remove striking rod oil seal with a suitable tool.


5. Install striking rod oil seal using Tool.

- **Apply multi-purpose grease to seal lip of oil seal before installing.**

6. Install the boot.

7. Install yoke and retaining pin.

8. Connect the transaxle control rod to the yoke.



Position Switch Check

BACK-UP LAMP SWITCH

NIMT0006

NIMT0006S01

- Check continuity.


| Gear position | Continuity |
|----------------|------------|
| Reverse | Yes |
| Except reverse | No |

PNP SWITCH

NIMT0006S02

- Check continuity.

| Gear position | Continuity |
|----------------|------------|
| Neutral | Yes |
| Except neutral | No |



Viscous Coupling Check

NIMT0039

1. Apply parking brake firmly and place shift lever in the neutral position.
2. Jack up front wheels.
3. Rotate one front wheel and check turning direction of the other front wheel.

Turning direction of the two wheels is opposite:

The viscous coupling is not functioning normally.

Turning direction of the two wheels is the same:

If differential side gear and pinion mate gear thrust washers are OK, viscous coupling is functioning normally.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL



IDX

REMOVAL AND INSTALLATION


Removal

Removal


NIMT0007S01



1. Remove battery negative terminal.
2. Remove air cleaner and air duct.
3. Remove clutch operating cylinder from transaxle. Refer to **CL-11**, "Removal".
4. Disconnect back-up lamp switch, speedometer sensor, PNP switch and ground harness connectors.




5. Remove starter motor from transaxle. Refer to **SC-21**, "Removal and Installation".




REMOVAL AND INSTALLATION


Removal (Cont'd)



6. Remove air breather hose.



7. Remove shift control rod and support rod from transaxle.
8. Remove the drain plug and drain gear oil from transaxle.
9. Draw out drive shafts from transaxle. Refer to **AX-12**, "Removal".





10. Support engine by placing a jack under oil pan.

CAUTION:

Do not place jack under oil pan drain plug.

11. Remove LH side and rear side mounting bolts.



12. Remove lower housing bolts.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL



IDX

REMOVAL AND INSTALLATION

Removal (Cont'd)



13. Remove bolts securing transaxle.
14. Lower transaxle while supporting it with a jack.



Installation

— QG ENGINE —

NIMT0007S03


NIMT0007S0301

- Tighten starter motor to transaxle.
🔧 : 31 - 42 N-m (3.2 - 4.3 kg-m, 23 - 31 ft-lb)
- Tighten LH and rear mounts to the specified torque. Refer to **EM-50**, "REMOVAL".
- Install transaxle and any part removed.

| Bolt No. | Tightening torque N-m (kg-m, ft-lb) | "ℓ" mm (in) |
|------------------------|--|--------------|
| 1 | 30 - 40 (3.1 - 4.1, 22 - 30) | 50 (1.97) |
| 2 | 30 - 40 (3.1 - 4.1, 22 - 30) | 30 (1.18) |
| 3 | 16 - 21 (1.6 - 2.1, 12 - 15) | 25 (0.98) |
| Front gusset to engine | 30 - 40 (3.1 - 4.1, 22 - 30) | 20 (0.79) |
| Rear gusset to engine | A | 17.5 (0.689) |
| | B | 20 (0.79) |

REMOVAL AND INSTALLATION

Installation



Installation

NIMT0007S02

— SR ENGINE —

NIMT0007S0201

- Tighten bolts securing transaxle and install any part removed.
- Tighten starter motor bolts.

 : 41 - 52 N·m (4.2 - 5.3 kg·m, 30 - 38 ft·lb)

| Bolt No. | 1 | 2 | 3 | 4 |
|--|------------------------------------|---------------------------------|-----------|------------------------------------|
| Q'ty | 5 | 1 | | |
| L in mm (in) | 55 (2.17) | 35 (1.38) | 45 (1.77) | 65 (2.56) |
| Tightening torque N·m (kg·m, ft·lb) | 70 - 79 (7.1 - 8.1, 51 - 59) | 30 - 40 (3.1 - 4.1, 22 - 30) | | 70 - 79 (7.1 - 8.1, 51 - 59) |

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC


EL

IDX

OVERHAUL

Transaxle Gear Control

SEC. 341



SMT904D

- | | | |
|--------------------------|-------------------|-------------------------|
| 1. Control lever knob | 9. O-ring | 17. Bushing |
| 2. Boot | 10. Ring spring | 18. Bracket |
| 3. Finisher | 11. Bearing seat | 19. Bushing |
| 4. Control lever bracket | 12. Seat | 20. Collar |
| 5. Dust cover | 13. Return spring | 21. Washer |
| 6. Socket | 14. Control rod | 22. Support rod bracket |
| 7. Control lever | 15. Bushing | 23. Support rod |
| 8. O-ring | 16. Collar | |


OVERHAUL

Case Components

Case Components

=NIMT0008S02

SEC. 320•322



- | | | |
|---|---|---------------------------|
| 1. Clutch housing | 13. O-ring | 25. Differential oil seal |
| 2. Dust seal | 14. Reverse idler gear shaft | 26. Drain plug |
| 3. Oil pocket | 15. Snap ring | 27. PNP switch |
| 4. Check plug | 16. Back-up lamp switch | 28. Transmission case |
| 5. Input shaft oil seal | 17. Filler plug | 29. Oil gutter |
| 6. Oil channel | 18. Side cover gasket | 30. Welch plug |
| 7. Mainshaft front bearing | 19. Side cover | 31. Boot |
| 8. Bearing retainer | 20. Welch plug | 32. Striking rod oil seal |
| 9. Reverse idler gear front thrust washer | 21. Mainshaft bearing snap ring | 33. Welch plug |
| 10. Reverse idler gear | 22. Mainshaft rear bearing adjusting shim | 34. Differential oil seal |
| 11. Reverse idler gear bearing | 23. O-ring | 35. O-ring |
| 12. Reverse idler gear rear thrust washer | 24. Rear cover | 36. Speedometer pinion |

WMT014


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

OVERHAUL

Gear Components

=NIMT0008S03

SEC. 322



SMT641DA

- | | | |
|---|---|------------------------------------|
| 1. Reverse idler gear front thrust washer | 24. 5th gear rear C-ring | 47. Mainshaft adjusting shim |
| 2. Reverse idler gear | 25. C-ring holder | 48. 4th main gear |
| 3. Reverse idler gear bearing | 26. Input shaft rear bearing | 49. 5th gear bush |
| 4. Reverse idle gear rear thrust washer | 27. Oil channel | 50. 5th gear needle bearing |
| 5. O-ring | 28. Input shaft rear bearing adjusting shim | 51. 5th main gear |
| 6. Reverse idler gear shaft | 29. Mainshaft front bearing | 52. 5th gear baulk ring |
| 7. Snap ring | 30. Mainshaft | 53. Spread spring |
| 8. Input shaft front bearing | 31. 1st gear needle bearing | 54. Shifting insert |
| 9. Input shaft | 32. 1st main gear | 55. 5th & reverse synchronizer hub |
| 10. 3rd gear needle bearing | 33. 1st inner baulk ring | 56. Spread spring |
| 11. 3rd input gear | 34. 1st synchronizer cone | 57. Coupling sleeve |
| 12. 3rd gear baulk ring | 35. 1st outer baulk ring | 58. Reverse gear bush |
| 13. Coupling sleeve | 36. 1st & 2nd synchronizer hub | 59. Reverse gear needle bearing |
| 14. Spread spring | 37. Coupling sleeve | 60. Reverse gear baulk ring |
| 15. Shifting insert | 38. Insert spring | 61. Reverse main gear |
| 16. 3rd & 4th synchronizer hub | 39. 2nd gear bush | 62. Sub-gear |
| 17. Spread spring | 40. 2nd gear needle bearing | 63. Sub-gear washer |
| 18. 4th gear C-ring | 41. 2nd gear outer baulk ring | 64. Snap ring |
| 19. 4th gear needle bearing | 42. 2nd gear synchronizer cone | 65. Mainshaft thrust washer |
| 20. 4th gear baulk ring | 43. 2nd inner baulk ring | 66. Mainshaft rear bearing |
| 21. 4th input gear | 44. 2nd main gear | 67. Mainshaft C-ring |
| 22. 5th gear front C-ring | 45. 3rd main gear | 68. C-ring holder |
| 23. 5th input gear | 46. Spacer | 69. Snap ring |


OVERHAUL

Shift Control Components

Shift Control Components

=NIMT008S04

SEC. 320•328



- | | | |
|----------------------------|----------------------------|------------------------------|
| 1. Clutch housing | 17. Interlock plunger | 32. Select check leaf spring |
| 2. 3rd & 4th bracket | 18. Check ball | 33. Return spring |
| 3. 3rd & 4th shift fork | 19. Interlock pin | 34. Steel ball |
| 4. Retaining pin | 20. Stopper ring | 35. Reverse gate |
| 5. Check ball | 21. 5th & reverse fork rod | 36. Return bearing |
| 6. Check pin | 22. Striking lever | 37. Selector arm |
| 7. Check spring | 23. Retaining pin | 38. Bushing |
| 8. Check plug | 24. 1st & 2nd bracket | 39. Welch plug |
| 9. Stopper ring | 25. 1st & 2nd shift fork | 40. Selector shaft |
| 10. 3rd & 4th fork rod | 26. Check ball | 41. Striking yoke |
| 11. Selector shaft pin | 27. 1st & 2nd fork rod | 42. Retaining pin |
| 12. Selector | 28. Transaxle case | 43. Striking rod |
| 13. 5th & reverse bracket | 29. Check ball | 44. Dust boot |
| 14. Reverse switch bracket | 30. Check spring | 45. Striking rod oil seal |
| 15. Retaining pin | 31. Check plug | 46. Welch plug |

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

WMT015

BR

ST

RS

BT

HA

SC

EL



IDX


OVERHAUL

Final Drive Components

=NIMT0008S05

SEC. 322

  **RS5F70A**
QG18DE : 74 – 88
 (7.5 – 9.0, 54 – 65)
SR20DE : 98 – 108
 (10.0 – 11.0, 72 – 80)
RS5F70V
 53 – 67
 (5.4 – 6.9, 39 – 49)




WMT016

- | | | |
|---|---|-----------------------------|
| 1. Differential side bearing adjusting shim | 6. Speedometer drive gear | 12. Side gear thrust washer |
| 2. Differential side bearing outer race | 7. Speedometer stopper | 13. Side gear |
| 3. Differential side bearing | 8. Differential side bearing | 14. Pinion mate shaft |
| 4. Final gear | 9. Differential side bearing outer race | 15. Lock pin |
| 5. Differential case | 10. Pinion mate thrust washer | 16. Viscous coupling |
| | 11. Pinion mate gear | |


DISASSEMBLY

Transaxle Case




Transaxle Case


1. Remove back-up lamp switch, PNP switch, drain plug, and filler plug from transaxle case. NIMT0009S01




2. Remove snap rings from reverse idler shaft.
3. Remove side cover and rear cover from case.
4. Remove O-ring and mainshaft bearing adjusting shim.



5. Remove reverse idler gear shaft.
 - a. Attach bolt (M6) to thread of reverse idler gear shaft end.
 - b. Pull out the attached bolt, and remove reverse idler gear shaft from case.
6. Remove reverse idler gear, thrust washer (front, rear), and bearing from case.



7. Remove snap ring of mainshaft bearing from case.




8. Remove check plugs, springs, and check balls from case.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

DISASSEMBLY


Transaxle Case (Cont'd)




9. Remove mounting bolts.
10. Remove input shaft rear bearing adjusting shim from transaxle case.




11. Remove oil gutter from case.



12. Remove differential side bearing outer race and adjusting shim from case using Tool.



13. Remove differential oil seal from case using Tool.



14. Remove welch plugs from case using Tool.






DISASSEMBLY

Clutch Housing

NIMT0009S02

Clutch Housing

1. Remove transaxle case from clutch housing.
2. Remove check plugs, check springs, check pins, and check balls from housing.



3. Remove 3rd & 4th bracket retaining pin using Tool.

4. Remove 3rd & 4th shift fork stopper ring.
5. Remove 3rd & 4th fork rod.
6. Remove 3rd & 4th shift fork and bracket.

7. Remove interlock plunger and check ball.
8. Remove 5th & reverse bracket stopper ring.

9. Remove retaining pin from 5th & reverse shift fork and reverse switch bracket using Tool.
10. Remove 5th & reverse fork rod.
11. Remove interlock pin from 5th & reverse fork rod using Tool.
12. Remove reverse switch bracket and 5th & reverse bracket.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

DISASSEMBLY


Clutch Housing (Cont'd)




13. Remove check ball from housing.
14. Remove retaining pin for 1st & 2nd shift fork and bracket using Tool.
15. Remove 1st & 2nd fork rod.
16. Remove 5th & reverse and 1st & 2nd shift forks, and 1st & 2nd bracket.




17. Remove both input shaft and mainshaft assemblies from housing.



18. Remove final drive assembly from housing.
19. Remove oil pocket from housing.




20. Remove mainshaft bearing retainer from housing.
21. Cut off oil channel using a cutter as shown in the figure.




22. Remove mainshaft front bearing from housing using Tool.

DISASSEMBLY


Clutch Housing (Cont'd)



23. Using a magnet or other suitable tool, remove selector pin from selector shaft.




24. Remove selector shaft and plug, then remove selector using Tool.




25. Remove reamer bolts, then remove select check leaf spring, return spring, steel ball, reverse gate, selector arm, bearing, and bushing.

CAUTION:
Be careful not to lose the steel ball.



26. Remove retaining pin and plug from striking lever using Tool.
27. Remove striking rod, then striking lever from housing.



28. Using a flat-head screwdriver or other suitable tool, remove dust seal, input shaft oil seal, and striking rod oil seal from housing.

CAUTION:
When removing dust and oil seals, be careful not to damage mounting surfaces of dust seal and oil seal.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

DISASSEMBLY


Clutch Housing (Cont'd)



29. Remove differential oil seal from housing using Tool.



30. Remove differential side bearing outer race from housing using Tool.



Input Shaft and Gears


DISASSEMBLY

1. Before disassembly, measure the end plays of 3rd and 4th input gears with a suitable tool. NIMT0010


Gear end play:

Refer to “Gear End Play”, MT-57.


- If end play is not within specification, disassemble and check the parts.




2. Remove oil channel from input shaft rear bearing.



3. Press out input shaft rear bearing using Tool.



4. Remove C-ring holder.
5. Remove 5th gear rear C-ring.



6. Remove 5th input gear from input shaft using Tool.
7. Remove 5th gear front C-ring.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA






SC

EL

IDX

REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)



8. Remove 4th input gear, baulk ring, 4th gear needle bearing, and 4th gear C-ring from input shaft.
9. Press out both 3rd & 4th synchronizer hub assembly and 3rd input gear from input shaft using Tool.
10. Remove 3rd gear needle bearing.
11. Press out input shaft front bearing from input shaft using Tool.

INSPECTION

Gear and Shaft

- Check shaft for cracks, wear or bending.
- Check gears for excessive wear, chips or cracks.

NIMT0011

NIMT0011S01

Synchronizers


- Check spline area of coupling sleeves, hubs and gears for wear or cracks.
- Check baulk rings for cracks or deformation.
- Check insert springs for wear or deformation.

NIMT0011S02

- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.

REPAIR FOR COMPONENT PARTS


Input Shaft and Gears (Cont'd)



SMT841D

- Measure the movement (play, dimension "L") of 3rd & 4th coupling sleeve with the end fixed and the other end lifted as shown in the figure. If the movement exceeds specification, replace the sleeve.


| Coupling sleeve | Length "L" |
|-----------------|-----------------------------|
| 3rd & 4th | 0 - 0.95 mm (0 - 0.0374 in) |



SMT140

- Measure clearance between baulk ring and gear.


Clearance between baulk ring and gear:
Refer to "Clearance Between Baulk Ring and Gear", MT-57.



SMT148A

Bearing


- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.



SMT696DA

ASSEMBLY

1. Press on input shaft front bearing using Tool.
2. Install 3rd gear needle, 3rd input gear and 3rd gear baulk ring bearing to input shaft.



SMT694D

3. Install spread spring, shifting insert, and 3rd & 4th synchronizer hub onto 3rd & 4th coupling sleeve.

- Pay attention to the shape of spread spring and shifting insert for correct assembly.

Do not install spread spring hook onto the same shifting insert.

CAUTION:

Do not reuse 3rd & 4th synchronizer hub.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

REPAIR FOR COMPONENT PARTS


Input Shaft and Gears (Cont'd)




- Install synchronizer hub with its three grooves facing the front side (3rd input gear side).



- Install 3rd & 4th coupling sleeve with its chamfered surface facing the 4th input gear side.



4. Position bearing replacer to the front side of input shaft front bearing.
- Align grooves of shifting insert and 3rd gear baulk ring. Then, press it onto 3rd & 4th synchronizer hub assembly using a drift.
5. Install 4th gear C-ring onto input shaft using Tool.



6. Measure the end play of 3rd & 4th synchronizer hub with a suitable tool, and check if it is within allowable specification below.


End play:

0 - 0.06 mm (0 - 0.0024 in)

7. If not within specification, adjust the end play by changing thickness of 4th (input) gear C-ring.

4th (input) gear C-ring:


Refer to "Available C-rings", MT-58.




8. Install 4th gear needle bearing, 4th gear baulk ring, and 5th gear front C-ring.
9. Install 4th input gear using Tool.

REPAIR FOR COMPONENT PARTS

Input Shaft and Gears (Cont'd)




10. Position 5th input gear as shown in the figure, and install it on input shaft.



11. Install 5th input gear.

CAUTION:
Do not reuse 5th input gear.

12. Install 5th gear rear C-ring onto input shaft using Tool.




13. Measure the end play of 5th input gear with a suitable tool, and check if it is within the allowable specification below.

End play:
0 - 0.06 mm (0 - 0.0024 in)

14. If not within specification, adjust the end play by changing thickness of the 5th (input gear) rear C-ring.

5th (input gear) rear C-ring:
Refer to "Available C-rings", MT-58.




15. Install C-ring holder onto 5th gear rear C-ring using Tool.

CAUTION:
Do not reuse C-ring holder.

16. Install input shaft rear bearing using Tool.

CAUTION:
Install input shaft rear bearing with its brown surface facing the input gear side.



17. Install oil channel onto input shaft.

18. Measure gear end play as a final check. Refer to "Gear End Play", MT-57.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears



Mainshaft and Gears


DISASSEMBLY

1. Before disassembly, measure gear end play with a suitable tool. NIMT0013


Gear end play:

Refer to “Gear End Play”, MT-57.


- If end play is not within the specified limit, disassemble and check the parts.




2. Remove snap ring with a suitable tool.



3. Remove C-ring holder and mainshaft C-ring.




4. Press out mainshaft rear bearing from mainshaft using Tool.




5. Remove mainshaft thrust washer.
6. Remove snap ring from mainshaft. Then, remove reverse main gear assembly, reverse gear needle bearing, and reverse gear baulk ring.

REPAIR FOR COMPONENT PARTS


Mainshaft and Gears (Cont'd)




7. Place bearing replacer between 5th & reverse synchronizer hub and 5th main gear, and press out both reverse gear bushing and 5th & reverse synchronizer assembly using Tool.
8. Remove 5th main gear, 5th gear baulk ring, and 5th gear needle bearing.




9. Place bearing replacer between 3rd and 4th main gears, and press out both 5th gear bushing and 4th main gear using Tool.



10. Remove mainshaft adjusting shim and spacer.
11. Place bearing replacer between 2nd main gear and 1st & 2nd synchronizer hub, and press out both 3rd and 2nd main gears.



12. Remove 2nd double cone assembly, 2nd gear bushing, and coupling sleeve assembly.
13. Place bearing replacer on 1st gear front side, and press out all of 2nd gear bushing, 1st & 2nd synchronizer hub, 1st main gear, and 1st double cone using Tool.
14. Remove 1st gear needle bearing.



INSPECTION

Gear and Shaft

- Check shaft for cracks, wear or bending.
- Check gears for excessive wear, chips or cracks.

NIMT0014

NIMT0014S01

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

REPAIR FOR COMPONENT PARTS


Mainshaft and Gears (Cont'd)




Synchronizers

NIMT0014S02

- Check spline area of coupling sleeves, hubs and gears for wear or cracks.
- Check baulk rings for cracks or deformation.
- Check insert springs for wear or deformation.




- If any crack, damage, or excessive wear is found on cam face of baulk ring or working face of insert, replace it.



- Measure the movement (play, dimension "L") of 1st & 2nd coupling sleeve and 5th & reverse coupling sleeve with their end fixed and the other end lifted as shown in the figure. If the movement exceeds specification, replace the sleeve.


| Coupling sleeve | Length "L" |
|-----------------|-----------------------------|
| 1st & 2nd | 0 - 0.68 mm (0 - 0.0268 in) |
| 5th & Reverse | 0 - 0.89 mm (0 - 0.0350 in) |



- Measure clearance between baulk ring and gear.

Clearance between baulk ring and gear:

Refer to "Clearance Between Baulk Ring and Gear", MT-57.




Bearing

NIMT0014S03

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)



- Measure wear of inner and outer baulk ring.
- a) Place baulk rings in position on synchronizer cone.
- b) While holding baulk ring against synchronizer cone as far as it will go, measure dimensions "A" and "B" using Tool.

Standard:


A 0.6 - 0.8 mm (0.024 - 0.031 in)

B 0.6 - 1.1 mm (0.024 - 0.043 in)

Wear limit:


0.2 mm (0.008 in)

- If dimension "A" or "B" is smaller than the wear limit, replace outer baulk ring, inner baulk ring and synchronizer cone as a set.



ASSEMBLY

1. Install 1st gear needle bearing and 1st main gear onto mainshaft. NIMT0015
2. Install 1st double cone assembly onto mainshaft.



3. Install 1st & 2nd synchronizer hub with its three grooves facing the front side (1st main gear side) onto mainshaft.


CAUTION:

Do not reuse 1st & 2nd synchronizer hub.


GI
MA
EM
LC
EC
FE
CL
MT
AT
AX
SU
BR
ST
RS
BT
HA
SC
EL
IDX

REPAIR FOR COMPONENT PARTS


Mainshaft and Gears (Cont'd)




4. Install 1st & 2nd synchronizer hub using Tool.




5. Install insert spring onto 1st & 2nd coupling sleeve.



6. Install 1st & 2nd coupling sleeve with its chamfered surface facing the 1st main gear side onto 1st & 2nd synchronizer hub.



7. Install 2nd gear bushing with its flange surface facing 1st & 2nd synchronizer hub side using Tool.




8. Install 2nd needle bearing, 2nd double cone assembly, and 2nd main gear onto mainshaft using Tool.

9. Position 3rd main gear as shown in the figure, and install it using Tool.

CAUTION:
Do not reuse 3rd main gear.

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)




10. Install spacer and mainshaft adjusting shim onto mainshaft.
11. Select a mainshaft adjusting shim suitable to satisfy the following specification of dimension "L" and install it onto mainshaft.

Specification of dimension "L":


151.35 - 151.45 mm (5.9586 - 5.9626 in)

Mainshaft adjusting shims:

Refer to "MAINSHAFT ADJUSTING SHIM", MT-60.




12. Position 4th main gear as shown in the figure, and install it onto mainshaft.



13. Install 4th main gear onto mainshaft using Tool.

CAUTION:

Do not reuse 4th main gear.



14. Install 5th gear bushing with its flange surface facing the 4th main gear side using Tool.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL


IDX

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)




15. Install 5th needle bearing, 5th main gear, and 5th gear baulk ring onto mainshaft.




16. Being careful of the following points, install spread spring, shifting insert, and 5th & reverse synchronizer hub onto 5th & reverse coupling sleeve.

- Pay attention to the shape of spread spring and shifting insert for correct assembly. Do not install spread spring hook onto the same shifting insert.




- Install synchronizer hub with its three grooves facing the front side (5th main gear side).

CAUTION:
Do not reuse 5th & reverse synchronizer hub.




- Install 5th & reverse coupling sleeve with its chamfered surface facing the reverse main gear side.




17. Install 5th & reverse synchronizer hub assembly using Tool.

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)




18. Install reverse gear baulk ring using Tool.
19. Install reverse gear bushing using Tool.
20. Install reverse gear needle bearing using Tool.



21. Install sub-gear, sub-gear washer, and snap ring onto reverse main gear.

CAUTION:

- Pay attention to direction of sub-gear washer.
- Do not reuse snap ring.




22. Install reverse main gear assembly onto mainshaft.
23. Select a thrust washer suitable to satisfy the following specification of dimension "M" (as shown in the figure), and install it onto mainshaft.

Specification of dimension "M":

244.20 - 244.30 mm (9.6142 - 9.6181 in)

Available thrust washers:

Refer to "Available Thrust Washer", MT-61.



24. Install mainshaft rear bearing using Tool.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

REPAIR FOR COMPONENT PARTS

Mainshaft and Gears (Cont'd)




25. Install mainshaft C-ring.
26. Using feeler gauge, measure the end play of mainshaft rear bearing with a suitable tool, and check if it satisfies the following specification.

End play:


0 - 0.06 mm (0 - 0.0024 in)

Mainshaft C-rings:


Refer to "Available C-rings", MT-58.



27. Install C-ring holder.



28. Install snap ring with a suitable tool.
29. Measure gear end play as a final check. Refer to "Gear End Play", MT-57.



Final Drive

PRE-INSPECTION


— RS5F70A & RS5F70V (Differential case side) —

NIMT0036

NIMT0036S01






- Check the clearance between side gear and differential case as follows using Tool.
1. Clean final drive assembly sufficiently to prevent side gear thrust washer, differential case, side gear, and other parts from sticking by gear oil.
 2. Upright the differential case so that the side gear to be measured faces upward.
 3. Place final drive adapter and dial gauge onto side gear. Move side gear up and down, and measure the clearance using Tool.

Clearance between side gear and differential case:
0.1 - 0.2 mm (0.004 - 0.008 in)
 4. If not within specification, adjust the clearance by changing thrust washer thickness.
 5. Turn differential case upside down, and measure the clearance between side gear and differential case on the other side in the same way using Tool.



REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)



DISASSEMBLY

NIMT0016

1. Remove mounting bolts. Then, separate the final gear from differential case.
2. Make a notch and remove speedometer drive gear using a scraper or other suitable tool.
 - **Bearing replacer cannot be positioned unless speedometer drive gear is removed.**
3. Remove differential side bearing of final gear side using Tool.
4. Turn differential case upside down, and remove differential side bearing of speedometer drive gear side using Tool.
 - **Be careful not to mix up the differential side bearings — RS5F70A.**
5. Remove speedometer stopper.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX


REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)




8. Remove pinion mate shaft.
9. Rotate pinion mate gear, and remove pinion mate gear, pinion mate thrust washer, side gear, and side gear thrust washer from differential case.

Models without viscous coupling



Models with viscous coupling



SMT991B


INSPECTION

Gear, Washer, Shaft and Case

NIMT0017

NIMT0017S01


- Check mating surfaces of differential case, side gears and pinion mate gears — RS5F70A and RS5F70V.
- Check viscous coupling — RS5F70V.
- Check washers for wear.



Viscous Coupling — RS5F70V

NIMT0017S05


- Check case for cracks.
- Check silicone oil for leakage.



Bearing

NIMT0017S02

- Make sure bearings roll freely and are free from noise, cracks, pitting or wear.
- **When replacing tapered roller bearing, replace outer and inner race as a set.**



ASSEMBLY

— RS5F70A & RS5F70V —

NIMT0018

NIMT0018S03


1. Apply gear oil to sliding area of differential case, each gear, and thrust washer.
2. Install side gear thrust washer and side gear into differential case.
3. Position pinion mate gear and pinion mate thrust washer diagonally, and install them into differential case while rotating.

GI

MA

EM

LC




4. Insert pinion mate shaft into differential case.

EC

FE

CL

MT



— RS5F70A & RS5F70V (Differential case side) —

NIMT0018S04

1. Upright the differential case so that its side gear to be measured faces upward.
2. Place preload adapter and dial gauge onto side gear. Move side gear up and down, and measure the clearance using Tool.
3. Turn differential case upside down, and measure the clearance between side gear and differential case on the other side in the same way using Tool.

AT

AX

SU

Clearance of side gear and differential case:

0.1 - 0.2 mm (0.004 - 0.008 in)

Differential side gear thrust washers:

Refer to "Available Washers", MT-61.

BR

ST

RS

BT

HA






SC

EL

IDX

REPAIR FOR COMPONENT PARTS

Final Drive (Cont'd)



— RS5F70V (Viscous coupling side) —

NIMT0018S05

1. Measure clearance between side gear and viscous coupling with washers with a suitable tool following the procedure below.
 - a. Set remaining side gear with washer on pinion mate gears.
 - b. Measure distance "X".
 - **Measure in at least 4 places around the edge of the side gear and take an average. At least 4 measurements are needed because the side gear may be uneven.**
 - c. Measure dimension "Y".

Clearance between side gear and viscous coupling with washers can be obtained by " $X + Y - 2A$ ".

**Clearance between side gear and viscous coupling:
0.1 - 0.2 mm (0.004 - 0.008 in)**

- d. If not within specification, adjust clearance by changing thickness of side gear thrust washer.

**Differential side gear thrust washers:
Refer to "Available Washers", MT-61.**


— RS5F70A & RS5F70V —

NIMT0018S06


1. Install retaining pin using Tool.
 - **Make sure that retaining pin is flush with case.**

REPAIR FOR COMPONENT PARTS


Final Drive (Cont'd)




2. Install viscous coupling — RS5F70V.



3. Align and install speedometer drive gear into differential case.
4. Install speedometer stopper.



5. Install differential side bearing using Tool.
6. Turn differential case upside down, and install another differential side bearing on the other side in the same way using Tool.



7. Install differential gear into differential case. Apply sealant onto mounting bolts, and tighten them in order as shown in the figure with specified torque.

Tightening torque:

Refer to "Final Drive Components", **MT-20**.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

REPAIR FOR COMPONENT PARTS

Shift Control Components




Shift Control Components

INSPECTION

- Check if the width of shift fork hook (sliding area with coupling sleeve) is within allowable specification below. =NIMT0019


| Item | One-side wear specification | Sliding width of new part |
|---------------|-----------------------------|--|
| 1st & 2nd | 0.2 mm (0.008 in) | 7.80 - 7.93 mm (0.3071 - 0.3122 in) |
| 3rd & 4th | 0.2 mm (0.008 in) | 7.80 - 7.93 mm (0.3071 - 0.3122 in) |
| 5th & reverse | 0.2 mm (0.008 in) | 7.80 - 7.93 mm (0.3071 - 0.3122 in) |



- Check if shift check groove of fork rod or 5th & reverse check groove is worn, or has any other abnormalities.

ASSEMBLY

Clutch Housing




Clutch Housing

NIMT0023S01


1. Hammer the striking rod oil seal into clutch housing as far as it will go using Tool.

CAUTION:
Do not reuse striking rod oil seal.




2. Hammer the differential oil seal into clutch housing with a suitable tool until it becomes flush with clutch housing end face.

CAUTION:
Do not reuse differential oil seal.




3. Hammer input shaft oil seal into clutch housing as far as it will go with a suitable tool.

CAUTION:
Do not reuse input shaft oil seal.



4. Hammer the dust seal into clutch housing as far as it will go using Tool.

CAUTION:
Do not reuse dust seal.



5. Install outer race of differential side bearing using Tool.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX


ASSEMBLY

Clutch Housing (Cont'd)




6. Install new oil channel (mainshaft).


CAUTION:
Pay attention to installation direction of oil channel.



7. Align the notches on mainshaft front bearing and transaxle case. Then, install mainshaft front bearing with a suitable tool.




8. Install mainshaft bearing retainer, and tighten bolts with specified torque.



9. Attach boot, striking rod, and striking lever to clutch housing. And install retaining pin for selector lever using Tool.

CAUTION:

- Before installing striking rod, wrap the end with a vinyl tape or similar product to prevent oil seal from being damaged.
- Do not reuse retaining pin.




10. Hammer the welch plug (striking lever side) with a general-purpose drift [OD: 12 mm (0.47 in)] with a suitable tool.


CAUTION:
Do not reuse welch plug.

ASSEMBLY

Clutch Housing (Cont'd)




11. Install selector, selector shaft, and selector shaft pin into clutch housing.




12. Hammer the welch plug (selector shaft side) with a general-purpose drift [OD: 12 mm (0.47 in)] with a suitable tool.

CAUTION:
Do not reuse welch plug.




13. Install select check leaf spring, return spring, steel ball, reverse gate, selector arm, bushing, and return bearing. Then, tighten two reamer bolts with specified torque.

CAUTION:
Use correct reamer bolts for each installation point, because each bolt has a different length.



14. Install oil pocket.



GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

ASSEMBLY


Clutch Housing (Cont'd)



15. Install differential assembly, input shaft assembly, and main shaft assembly into clutch housing.

CAUTION:

Be careful not to damage input shaft oil seal during installation of input shaft assembly.



16. Install 5th & reverse shift fork.


17. Install 1st & 2nd shift fork, bracket, and fork rod using Tool.

18. Install retaining pin for 1st & 2nd bracket.

CAUTION:

Do not reuse retaining pin.

19. Install two check balls.



20. Install interlock pin into 5th & reverse fork rod using Tool.

21. Install reverse switch bracket, 5th & reverse bracket, and fork rod using Tool.

22. Install retaining pin for 5th & reverse shift fork and reverse switch bracket using Tool.


CAUTION:

Do not reuse retaining pin.

23. Install 5th & reverse bracket stopper ring.

CAUTION:

Do not reuse stopper pin.




24. Install check ball and interlock plunger.

25. Install 3rd & 4th shift fork, bracket, and fork rod using Tool.

26. Install 3rd & 4th bracket retaining pin.

CAUTION:

Do not reuse retaining pin.



27. Install 3rd & 4th shift fork stopper ring.


CAUTION:

Do not reuse stopper ring.

28. Install check ball, check pin, and check spring, and apply Three Bond TB1215, Loctite Part No. 51813 or equivalent onto check plug. Then, tighten it with specified torque.

Tightening torque:

Refer to "Shift Control Components", MT-19.



Transaxle Case

NIMT0023S02


1. Insert differential oil seal into differential case with a suitable tool until it becomes flush with case end face.

GI

MA

EM

LC




2. Install Welch plug into transaxle case with a suitable tool.

EC

FE

CL



3. Calculate dimension "N" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for differential side bearing.

End play: 0.15 - 0.21 mm (0.0059 - 0.0083 in)

Dimension "N" = (N1 - N2) + End play

N: Thickness of adjusting shim

N1: Distance between clutch housing case end face and mounting face of adjusting shim

N2: Distance between differential side bearing and transaxle case

Differential side bearing adjusting shims:

Refer to "DIFFERENTIAL SIDE BEARING ADJUSTING SHIMS", MT-62.

MT

AT

AX

SU


BR

ST

RS

BT

HA



- a. Using dial gauge and scale, measure dimension "N1" between clutch housing case end face and mounting face of adjusting shim.


SC

EL


IDX

ASSEMBLY


Transaxle Case (Cont'd)



- b. Install outer race onto differential side bearing on final gear side. Holding lightly the outer race horizontally by hand, rotate final gear five times or more (for smooth movement of bearing roller).
- c. Using dial gauge and scale as shown in the figure, measure dimension "N2" between differential side bearing outer race and transaxle case end face.



4. Install selected shim and bearing outer race using Tool.




5. Measure turning torque of final drive assembly using Tool.

**Turning torque of final drive assembly
(New bearing):**

2.9 - 6.9 N·m (30 - 70 kg-cm, 26 - 61 in-lb)

- When old bearing is used again, turning torque will be slightly less than the above.
- Make sure torque is close to the specified range.
- Changes in turning torque of final drive assembly per revolution should be within 1.0 N·m (10 kg-cm, 8.7 in-lb) without binding.



6. Calculate dimension "O" (thickness of adjusting shim) using the following procedure to satisfy specification of end play for input shaft rear bearing.

End play: 0 - 0.06 mm (0 - 0.0024 in)

Dimension "O" = (O1 - O2) + End play

O: Thickness of adjusting shim

O1: Distance between transaxle case end face and mounting face of adjusting shim


O2: Distance between clutch housing case end face and end face of input shaft rear bearing

Input shaft rear bearing adjusting shims:


Refer to "INPUT SHAFT REAR BEARING ADJUSTING SHIM", MT-59.

ASSEMBLY


Transaxle Case (Cont'd)




- a. Using block gauge, scale, and dial gauge, measure dimension "O1" between transaxle case end face and mounting face of adjusting shim.




- b. Using block gauge, scale, and dial gauge as shown in the figure, measure dimension "O2" between clutch housing case end face and end face of input shaft rear bearing.
7. Install selected input shaft rear bearing adjusting shim onto input shaft.



8. Install oil gutter into transaxle case.



9. Clean mating surfaces of clutch housing and transaxle case. Check for cracks and damage. Then, apply Three Bond TB1215, Loctite Part No. 51813 or equivalent.



10. Install transaxle case onto clutch housing, and tighten mounting bolts with specified torque.

Tightening torque:

Refer to "Case Components", MT-17.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA


SC

EL

IDX

ASSEMBLY


Transaxle Case (Cont'd)




11. Apply Three Bond TB1215, Loctite Part No. 51813 or equivalent to threads of back-up lamp switch, PNP switch, and drain plug, and install them. (Fill the case with oil before installation of filler plug.)

12. Install speedometer pinion assembly.

CAUTION:
Do not reuse O-ring.



13. Install check springs and check balls. Apply sealant to the thread on the check plug, and install it.



14. Calculate thickness of adjusting shim using the following procedure to satisfy specification of end play for mainshaft rear bearing.

End play: 0 - 0.06 mm (0 - 0.0024 in)

Dimension "P" = (P1 - P2) + End play


P: Thickness of adjusting shim

P1: Distance between transaxle case end face and mainshaft rear bearing

P2: Distance between adjusting shim end face of rear cover and transaxle mounting face

Mainshaft rear bearing adjusting shims:


Refer to "Available Adjusting Shims", MT-59.



a. Using dial gauge as shown in the figure, measure dimension "P1" between transaxle case end face and mainshaft rear bearing.

ASSEMBLY

Transaxle Case (Cont'd)




- b. Using dial gauge as shown in the figure, measure dimension "P2" between adjusting shim mounting face of rear cover and transaxle mounting face.

GI

MA

EM

LC



15. Using snap ring pliers and flat-head screwdriver as shown in the figure, install snap ring.


EC

CAUTION:
Do not reuse snap ring.

16. Install selected mainshaft adjusting shim.

FE

CL



17. Install reverse idler gear, O-ring, thrust washers (front, rear), and bearing onto reverse idler shaft.

AT


18. Install snap ring into transaxle case using snap ring pliers.

- CAUTION:**
- Do not reuse snap ring.
 - Do not reuse O-ring.
 - Before installation, apply gear oil to O-ring.

AX

SU

BR



19. Using feeler gauge, measure the end play of snap ring, and select a snap ring suitable to satisfy the following specification.

ST


End play:
0.05 - 0.25 mm (0.0020 - 0.0098 in)

RS

Available snap ring:
Refer to "SNAP RING", MT-57.

BT

HA



20. Install selected snap ring with a suitable tool.

SC

CAUTION:
Do not reuse snap ring.

EL

21. Apply gear oil to rear cover O-ring, and install rear cover, side cover gasket, and side cover. Then tighten mounting bolts with specified torque.

IDX

Tightening torque:
Refer to "Case Components", MT-17.

CAUTION:
Do not reuse mounting bolts for rear cover and side cover.

SERVICE DATA AND SPECIFICATIONS (SDS)

General Specifications

General Specifications

NIMT0024

TRANSAXLE

NIMT0024S01

| | | | | | | |
|----------------------------------|---------------------------------|---|-----------------------------|----------------------|--|--|
| Engine | | QG18DE | | SR20DE | | |
| Transaxle model | | RS5F70A | | RS5F70A RS5F70V | | |
| Number of speeds | | 5 | | | | |
| Synchromesh type | | Warner | | | | |
| Shift pattern | | | | | | |
| Gear ratio | 1st | 3.333 | | 3.333 | | |
| | 2nd | 1.955 | | 1.955 | | |
| | 3rd | 1.286 | | 1.286 | | |
| | 4th | 0.926 | | 0.926 | | |
| | 5th | 0.756 | | 0.733 | | |
| | Reverse | 3.417 | | 3.153 | | |
| Number of teeth | Input gear | 1st | 15 | | 15 | |
| | | 2nd | 22 | | 22 | |
| | | 3rd | 28 | | 28 | |
| | | 4th | 41 | | 41 | |
| | | 5th | 45 | | 45 | |
| | | Rev. | 14 | | 14 | |
| | Main gear | 1st | 50 | | 50 | |
| | | 2nd | 43 | | 43 | |
| | | 3rd | 36 | | 36 | |
| | | 4th | 38 | | 38 | |
| | | 5th | 34 | | 33 | |
| | | Rev. | 45 | | 45 | |
| | Reverse idler gear | | 37 | | 37 | |
| | Oil level (Reference) mm (in)*1 | | 75.5 - 80.5 (2.972 - 3.169) | | 56.5 - 61.0 (2.224 - 2.402) 56.5 - 62.0 (2.224 - 2.441) | |
| Oil capacity ℓ (US pt, Imp pt)*1 | | 3.0 (6-3/8, 5-1/4) | | | | |
| Remarks | | 1st & 2nd double baulk ring type synchronizer | | | | |
| | | Reverse sub-gear | | | | |

*1: Refer to **MA-13**, "Fluid and Lubricants".

FINAL GEAR

NIMT0024S02

| | | | | | |
|------------------|----------------------------|---------|--|----------------------|--|
| Engine | | QG18DE | | SR20DE | |
| Transaxle model | | RS5F70A | | RS5F70A RS5F70V | |
| Final gear ratio | | 4.176 | | 4.437 | |
| Number of teeth | Final gear/Pinion | 71/17 | | 71/16 | |
| | Side gear/Pinion mate gear | 16/10 | | 14/10 | |

SERVICE DATA AND SPECIFICATIONS (SDS)

Gear End Play

Gear End Play

NIMT0025
Unit: mm (in)

| Gear | End play |
|-------------------|-------------------------------|
| 1st main gear | 0.18 - 0.31 (0.0071 - 0.0122) |
| 2nd main gear | |
| 5th main gear | |
| Reverse main gear | |
| 3rd input gear | |
| 4th input gear | 0.17 - 0.44 (0.0067 - 0.0173) |

Clearance Between Baulk Ring and Gear

NIMT0026


3RD, 4TH, 5TH, REVERSE BAULK RING

NIMT0026S01
Unit: mm (in)

| Standard | | Wear limit |
|----------|-------------------------------|-------------|
| 3rd | 0.90 - 1.45 (0.0354 - 0.0571) | 0.7 (0.028) |
| 4th | | |
| 5th | | |
| Reverse | 0.9 - 1.35 (0.0354 - 0.0531) | |

1ST AND 2ND BAULK RING

NIMT0026S02
Unit: mm (in)



SMT906D

| Dimension | Standard | Wear limit |
|-----------|---------------------------|-------------|
| A | 0.6 - 0.8 (0.024 - 0.031) | 0.2 (0.008) |
| B | 0.6 - 1.1 (0.024 - 0.043) | |

Available Snap Rings

NIMT0028

SNAP RING

NIMT0028S04

| End play | Part number* |
|-------------------------------------|--------------|
| 0.05 - 0.25 mm (0.0020 - 0.0098 in) | |
| Thickness | Part number* |
| 1.45 mm (0.0571 in) | 32204-6J000 |
| 1.55 mm (0.0610 in) | 32204-6J001 |
| 1.65 mm (0.0650 in) | 32204-6J002 |
| 1.75 mm (0.0689 in) | 32204-6J003 |
| 1.85 mm (0.0728 in) | 32204-6J004 |

*: Always check with the parts department for the latest information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Available C-rings

Available C-rings

NIMT0029

4TH INPUT GEAR C-RING

NIMT0029S02

| End play | 0 - 0.06 mm (0 - 0.0024 in) |
|---------------------|-----------------------------|
| Thickness | Part number* |
| 3.00 mm (0.1181 in) | 32205-6J000 |
| 3.03 mm (0.1193 in) | 32205-6J001 |
| 3.06 mm (0.1205 in) | 32205-6J002 |
| 3.09 mm (0.1217 in) | 32205-6J003 |
| 3.12 mm (0.1228 in) | 32205-6J004 |

*: Always check with the parts department for the latest information.

5TH INPUT GEAR REAR C-RING

NIMT0029S03

| End play | 0 - 0.06 mm (0 - 0.0024 in) |
|---------------------|-----------------------------|
| Thickness | Part number* |
| 2.59 mm (0.1020 in) | 32205-6J005 |
| 2.62 mm (0.1031 in) | 32205-6J006 |
| 2.65 mm (0.1043 in) | 32205-6J007 |
| 2.68 mm (0.1055 in) | 32205-6J008 |
| 2.71 mm (0.1067 in) | 32205-6J009 |
| 2.74 mm (0.1079 in) | 32205-6J010 |

*: Always check with the parts department for the latest information.

MAINSHAFT C-RING

NIMT0029S01

| End play | 0 - 0.06 mm (0 - 0.0024 in) |
|---------------------|-----------------------------|
| Thickness | Part number* |
| 3.48 mm (0.1370 in) | 32348-6J000 |
| 3.51 mm (0.1382 in) | 32348-6J001 |
| 3.54 mm (0.1394 in) | 32348-6J002 |
| 3.57 mm (0.1406 in) | 32348-6J003 |
| 3.60 mm (0.1417 in) | 32348-6J004 |
| 3.63 mm (0.1429 in) | 32348-6J005 |
| 3.66 mm (0.1441 in) | 32348-6J006 |
| 3.69 mm (0.1453 in) | 32348-6J007 |
| 3.72 mm (0.1465 in) | 32348-6J008 |
| 3.75 mm (0.1476 in) | 32348-6J009 |
| 3.78 mm (0.1488 in) | 32348-6J010 |
| 3.81 mm (0.1500 in) | 32348-6J011 |
| 3.84 mm (0.1512 in) | 32348-6J012 |
| 3.87 mm (0.1524 in) | 32348-6J013 |
| 3.90 mm (0.1535 in) | 32348-6J014 |
| 3.93 mm (0.1547 in) | 32348-6J015 |
| 3.96 mm (0.1559 in) | 32348-6J016 |

*: Always check with the parts department for the latest information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Available Adjusting Shims

Available Adjusting Shims

NIMT0037

INPUT SHAFT REAR BEARING ADJUSTING SHIM

NIMT0037S01

| End play | 0 - 0.06 mm (0 - 0.0024 in) | | |
|----------|-----------------------------|--------------|-----------|
| | Thickness | Part number* | |
| | 0.74 mm (0.0291 in) | 32225-6J003 | GI |
| | 0.78 mm (0.0307 in) | 32225-6J004 | MA |
| | 0.82 mm (0.0323 in) | 32225-6J005 | EM |
| | 0.86 mm (0.0339 in) | 32225-6J006 | LC |
| | 0.90 mm (0.0354 in) | 32225-6J007 | |
| | 0.94 mm (0.0370 in) | 32225-6J008 | EC |
| | 0.98 mm (0.0386 in) | 32225-6J009 | |
| | 1.02 mm (0.0402 in) | 32225-6J010 | FE |
| | 1.06 mm (0.0417 in) | 32225-6J011 | |
| | 1.10 mm (0.0433 in) | 32225-6J012 | CL |
| | 1.14 mm (0.0449 in) | 32225-6J013 | |
| | 1.18 mm (0.0465 in) | 32225-6J014 | MT |
| | 1.22 mm (0.0480 in) | 32225-6J015 | |
| | 1.26 mm (0.0496 in) | 32225-6J016 | AT |
| | 1.30 mm (0.0512 in) | 32225-6J017 | |
| | 1.34 mm (0.0528 in) | 32225-6J018 | AX |
| | 1.38 mm (0.0543 in) | 32225-6J019 | |
| | 1.42 mm (0.0559 in) | 32225-6J020 | SU |
| | 1.46 mm (0.0575 in) | 32225-6J021 | |
| | 1.50 mm (0.0591 in) | 32225-6J022 | BR |
| | 1.54 mm (0.0606 in) | 32225-6J023 | |
| | 1.58 mm (0.0622 in) | 32225-6J024 | ST |
| | 1.62 mm (0.0638 in) | 32225-6J060 | |
| | 1.66 mm (0.0654 in) | 32225-6J061 | RS |

*: Always check with the parts department for the latest information.

GI

MA

EM

LC

EC

FE

CL

MT

AT

AX

SU

BR

ST

RS

BT

HA

SC

EL


IDX

SERVICE DATA AND SPECIFICATIONS (SDS)

Available Adjusting Shims (Cont'd)

MAINSHAFT ADJUSTING SHIM

NIMT0037S02



SMT907D

| Standard length "L" | 151.35 - 151.45 mm (5.9586 - 5.9626 in) |
|---------------------|---|
| Thickness | Part number* |
| 0.48 mm (0.0189 in) | 32238-6J000 |
| 0.56 mm (0.0220 in) | 32238-6J001 |
| 0.64 mm (0.0252 in) | 32238-6J002 |
| 0.72 mm (0.0283 in) | 32238-6J003 |
| 0.80 mm (0.0315 in) | 32238-6J004 |
| 0.88 mm (0.0346 in) | 32238-6J005 |

*: Always check with the parts department for the latest information.

MAINSHAFT REAR BEARING ADJUSTING SHIM

NIMT0037S03

| End play | 0 - 0.06 mm (0 - 0.0024 in) |
|---------------------|-----------------------------|
| Thickness | Part number* |
| 2.99 mm (0.1177 in) | 32238-6J010 |
| 3.03 mm (0.1193 in) | 32238-6J011 |
| 3.07 mm (0.1209 in) | 32238-6J012 |
| 3.11 mm (0.1224 in) | 32238-6J013 |
| 3.15 mm (0.1240 in) | 32238-6J014 |
| 3.19 mm (0.1256 in) | 32238-6J015 |
| 3.23 mm (0.1272 in) | 32238-6J016 |
| 3.27 mm (0.1287 in) | 32238-6J017 |
| 3.31 mm (0.1303 in) | 32238-6J018 |
| 3.35 mm (0.1319 in) | 32238-6J019 |
| 3.39 mm (0.1335 in) | 32238-6J020 |
| 3.43 mm (0.1350 in) | 32238-6J021 |
| 3.47 mm (0.1366 in) | 32238-6J022 |
| 3.51 mm (0.1382 in) | 32238-6J023 |

*: Always check with the parts department for the latest information.

SERVICE DATA AND SPECIFICATIONS (SDS)


Available Thrust Washer

Available Thrust Washer

MAINSHAFT THRUST WASHER

NIMT0038

NIMT0038S01



SMT843D

| | |
|---------------------|---|
| Standard length "M" | 244.20 - 244.30 mm (9.6142 - 9.6181 in) |
| Thickness | Part number* |
| 6.04 mm (0.2378 in) | 32246-6J000 |
| 6.12 mm (0.2409 in) | 32246-6J001 |
| 6.20 mm (0.2441 in) | 32246-6J002 |
| 6.28 mm (0.2472 in) | 32246-6J003 |
| 6.36 mm (0.2504 in) | 32246-6J004 |

*: Always check with the parts department for the latest information.

Available Washers

DIFFERENTIAL SIDE GEAR THRUST WASHER

— RS5F70A —

NIMT0031

NIMT0031S01

NIMT0031S0103

| | |
|---|---------------------------------|
| Clearance between side gear and differential case | 0.1 - 0.2 mm (0.004 - 0.008 in) |
| Thickness mm (in) | Part number* |
| 0.75 - 0.80 (0.0295 - 0.0315) | 38424-D2111 |
| 0.80 - 0.85 (0.0315 - 0.0335) | 38424-D2112 |
| 0.85 - 0.90 (0.0335 - 0.0354) | 38424-D2113 |
| 0.90 - 0.95 (0.0354 - 0.0374) | 38424-D2114 |
| 0.95 - 1.00 (0.0374 - 0.0394) | 38424-D2115 |

*: Always check with the parts department for the latest information.

— RS5F70V —

NIMT0031S0104

| | | |
|---|---------------------------------|--------------|
| Clearance between side gear and differential case of viscous coupling | 0.1 - 0.2 mm (0.004 - 0.008 in) | |
| | Thickness mm (in) | Part number* |
| Differential case side | 0.75 - 0.80 (0.0295 - 0.0315) | 38424-D2111 |
| | 0.80 - 0.85 (0.0315 - 0.0335) | 38424-D2112 |
| | 0.85 - 0.90 (0.0335 - 0.0354) | 38424-D2113 |
| | 0.90 - 0.95 (0.0354 - 0.0374) | 38424-D2114 |
| | 0.95 - 1.00 (0.0374 - 0.0394) | 38424-D2115 |

SERVICE DATA AND SPECIFICATIONS (SDS)

Available Washers (Cont'd)

| | | |
|-----------------------|-------------------------------|-------------|
| Viscous coupling side | 0.70 - 0.75 (0.0276 - 0.0295) | 38424-D2110 |
| | 0.75 - 0.80 (0.0295 - 0.0315) | 38424-D2111 |
| | 0.80 - 0.85 (0.0315 - 0.0335) | 38424-D2112 |
| | 0.85 - 0.90 (0.0335 - 0.0354) | 38424-D2113 |
| | 0.90 - 0.95 (0.0354 - 0.0374) | 38424-D2114 |
| | 0.95 - 1.00 (0.0374 - 0.0394) | 38424-D2115 |
| | 1.00 - 1.05 (0.0394 - 0.0413) | 38424-D2116 |
| | 1.05 - 1.10 (0.0413 - 0.0433) | 38424-D2117 |
| | 1.10 - 1.15 (0.0433 - 0.0453) | 38424-D2118 |
| | 1.15 - 1.20 (0.0453 - 0.0472) | 38424-D2119 |
| | 1.20 - 1.25 (0.0472 - 0.0492) | 38424-D2120 |
| | 1.25 - 1.30 (0.0492 - 0.0512) | 38424-D2121 |
| | 1.30 - 1.35 (0.0512 - 0.0531) | 38424-D2122 |

*: Always check with the parts department for the latest information.

Available Shims — Differential Side Bearing Preload and Adjusting Shim

NIMT0032

BEARING PRELOAD

NIMT0032S01
Unit: mm (in)

| | |
|---------------------------------------|-------------------------------|
| Differential side bearing preload: T* | 0.15 - 0.21 (0.0059 - 0.0083) |
|---------------------------------------|-------------------------------|

* Install shims which are "deflection of differential case" + "T" in thickness.

DIFFERENTIAL SIDE BEARING ADJUSTING SHIMS — RS5F70A —

NIMT0032S03

NIMT0032S0303

| Thickness mm (in) | Part number* |
|-------------------|--------------|
| 0.44 (0.0173) | 38454-M8000 |
| 0.48 (0.0189) | 38454-M8001 |
| 0.52 (0.0205) | 38454-M8002 |
| 0.56 (0.0220) | 38454-M8003 |
| 0.60 (0.0236) | 38454-M8004 |
| 0.64 (0.0252) | 38454-M8005 |
| 0.68 (0.0268) | 38454-M8006 |
| 0.72 (0.0283) | 38454-M8007 |
| 0.76 (0.0299) | 38454-M8008 |
| 0.80 (0.0315) | 38454-M8009 |
| 0.84 (0.0331) | 38454-M8010 |
| 0.88 (0.0346) | 38454-M8011 |

*: Always check with the parts department for the latest information.

SERVICE DATA AND SPECIFICATIONS (SDS)

Available Shims — Differential Side Bearing Preload and Adjusting Shim (Cont'd)

— RS5F70V —

—NIMT0032S0304

| Thickness mm (in) | Part number | |
|-------------------|-------------|-----------|
| 0.28 (0.0110) | 31439-31X00 | GI |
| 0.32 (0.0126) | 31439-31X01 | MA |
| 0.36 (0.0142) | 31439-31X02 | |
| 0.40 (0.0157) | 31439-31X03 | EM |
| 0.44 (0.0173) | 31439-31X04 | |
| 0.48 (0.0189) | 31439-31X05 | LC |
| 0.52 (0.0205) | 31439-31X06 | |
| 0.56 (0.0220) | 31439-31X07 | EC |
| 0.60 (0.0236) | 31439-31X08 | |
| 0.64 (0.0252) | 31439-31X09 | FE |
| 0.68 (0.0268) | 31439-31X10 | |
| 0.72 (0.0283) | 31439-31X11 | CL |
| 0.76 (0.0299) | 31439-31X12 | |
| 0.80 (0.0315) | 31439-31X13 | MT |
| 0.84 (0.0331) | 31439-31X14 | |
| 0.88 (0.0346) | 31439-31X15 | AT |
| 0.92 (0.0362) | 31439-31X16 | |
| 0.96 (0.0378) | 31439-31X17 | AX |
| 1.44 (0.0567) | 31439-31X18 | |

*: Always check with the parts department for the latest information.

SU

BR

ST

RS

BT

HA

SC

EL

IDX

NOTES