

SECTION **BCS**

BODY CONTROL SYSTEM

A
B
C
D
E
F
G
H
I
J
K
L

CONTENTS

| | | |
|---|---|----|
| WITH INTELLIGENT KEY SYSTEM | | |
| PRECAUTION | POWER CONSUMPTION CONTROL SYSTEM : System Description | 13 |
| PRECAUTIONS | DIAGNOSIS SYSTEM (BCM) | 15 |
| Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | COMMON ITEM | 15 |
| | COMMON ITEM : CONSULT Function (BCM - COMMON ITEM) | 15 |
| SYSTEM DESCRIPTION | DOOR LOCK | 16 |
| COMPONENT PARTS | DOOR LOCK : CONSULT Function (BCM - DOOR LOCK) | 16 |
| BODY CONTROL SYSTEM | REAR DEFOGGER | 16 |
| BODY CONTROL SYSTEM : Component Parts Location | REAR DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER) | 16 |
| COMBINATION SWITCH READING SYSTEM | BUZZER | 17 |
| COMBINATION SWITCH READING SYSTEM : Component Parts Location | BUZZER : CONSULT Function (BCM - BUZZER)... | 17 |
| POWER CONSUMPTION CONTROL SYSTEM | INT LAMP | 17 |
| POWER CONSUMPTION CONTROL SYSTEM : Component Parts Location | INT LAMP : CONSULT Function (BCM - INT LAMP) | 17 |
| SYSTEM | HEADLAMP | 18 |
| BODY CONTROL SYSTEM | HEADLAMP : CONSULT Function (BCM - HEAD LAMP) | 18 |
| BODY CONTROL SYSTEM : System Description..... | WIPER | 19 |
| COMBINATION SWITCH READING SYSTEM | WIPER : CONSULT Function (BCM - WIPER) | 19 |
| COMBINATION SWITCH READING SYSTEM : System Diagram | FLASHER | 20 |
| COMBINATION SWITCH READING SYSTEM : System Description | FLASHER : CONSULT Function (BCM - FLASH- ER) | 20 |
| SIGNAL BUFFER SYSTEM | AIR CONDITIONER | 20 |
| SIGNAL BUFFER SYSTEM : System Diagram | AIR CONDITIONER : CONSULT Function (BCM - AIR CONDITIONER) | 20 |
| SIGNAL BUFFER SYSTEM : System Description... .. | INTELLIGENT KEY | 21 |
| POWER CONSUMPTION CONTROL SYSTEM | INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY) | 21 |
| POWER CONSUMPTION CONTROL SYSTEM : System Diagram | COMB SW | 23 |

BCS

N
O
P

| | | | |
|---|-----------|--|-----------|
| COMB SW : CONSULT Function (BCM - COMB SW) | 23 | Description | 64 |
| BCM | 23 | DTC Logic | 64 |
| BCM : CONSULT Function (BCM - BCM) | 24 | Diagnosis Procedure | 64 |
| IMMU | 24 | U1010 CONTROL UNIT (CAN) | 65 |
| IMMU : CONSULT Function (BCM - IMMU) | 24 | DTC Logic | 65 |
| BATTERY SAVER | 24 | Diagnosis Procedure | 65 |
| BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER) | 24 | U0415 VEHICLE SPEED | 66 |
| TRUNK | 25 | DTC Logic | 66 |
| TRUNK : CONSULT Function (BCM - TRUNK) | 25 | Diagnosis Procedure | 66 |
| THEFT ALM | 25 | B2562 LOW VOLTAGE | 67 |
| THEFT ALM : CONSULT Function (BCM - THEFT) | 26 | DTC Logic | 67 |
| RETAINED PWR | 26 | Diagnosis Procedure | 67 |
| RETAINED PWR : CONSULT Function (BCM - RETAINED PWR) | 26 | POWER SUPPLY AND GROUND CIRCUIT | 68 |
| SIGNAL BUFFER | 27 | Diagnosis Procedure | 68 |
| SIGNAL BUFFER : CONSULT Function (BCM - SIGNAL BUFFER) | 27 | COMBINATION SWITCH INPUT CIRCUIT | 69 |
| AIR PRESSURE MONITOR | 27 | Diagnosis Procedure | 69 |
| AIR PRESSURE MONITOR : CONSULT Function (BCM - AIR PRESSURE MONITOR) | 27 | COMBINATION SWITCH OUTPUT CIRCUIT ... | 71 |
| ECU DIAGNOSIS INFORMATION | 29 | Diagnosis Procedure | 71 |
| BCM | 29 | SYMPTOM DIAGNOSIS | 73 |
| Reference Value | 29 | COMBINATION SWITCH SYSTEM SYMPTOMS | 73 |
| Fail-safe | 47 | Symptom Table | 73 |
| DTC Inspection Priority Chart | 49 | REMOVAL AND INSTALLATION | 74 |
| DTC Index | 50 | BCM | 74 |
| WIRING DIAGRAM | 52 | Removal and Installation | 74 |
| BCM | 52 | COMBINATION SWITCH | 76 |
| Wiring Diagram | 52 | Exploded View | 76 |
| BASIC INSPECTION | 61 | Removal and Installation | 76 |
| INSPECTION AND ADJUSTMENT | 61 | WITHOUT INTELLIGENT KEY SYSTEM | |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) | 61 | PRECAUTION | 77 |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Description | 61 | PRECAUTIONS | 77 |
| ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Work Procedure | 61 | Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER" | 77 |
| CONFIGURATION (BCM) | 62 | SYSTEM DESCRIPTION | 78 |
| CONFIGURATION (BCM) : Description | 62 | COMPONENT PARTS | 78 |
| CONFIGURATION (BCM) : Work Procedure | 62 | BODY CONTROL SYSTEM | 78 |
| CONFIGURATION (BCM) : Configuration list | 63 | BODY CONTROL SYSTEM : Component Parts Location | 78 |
| DTC/CIRCUIT DIAGNOSIS | 64 | COMBINATION SWITCH READING SYSTEM | 78 |
| U1000 CAN COMM CIRCUIT | 64 | COMBINATION SWITCH READING SYSTEM : Component Parts Location | 78 |
| | | POWER CONSUMPTION CONTROL SYSTEM | 79 |
| | | POWER CONSUMPTION CONTROL SYSTEM : Component Parts Location | 79 |

| | | | | |
|--|-----------|--|------------|---|
| SYSTEM | 80 | BCM | 94 | |
| | | BCM : CONSULT Function (BCM - BCM) | 94 | A |
| BODY CONTROL SYSTEM | 80 | IMMU | 94 | |
| BODY CONTROL SYSTEM : System Description... | 80 | IMMU : CONSULT Function (BCM - IMMU) | 94 | B |
| COMBINATION SWITCH READING SYSTEM | 80 | BATTERY SAVER | 95 | |
| COMBINATION SWITCH READING SYSTEM : | | BATTERY SAVER : CONSULT Function (BCM - | | |
| System Diagram | 81 | BATTERY SAVER) | 95 | C |
| COMBINATION SWITCH READING SYSTEM : | | TRUNK | 95 | |
| System Description | 81 | TRUNK : CONSULT Function (BCM - TRUNK) | 95 | D |
| SIGNAL BUFFER | 83 | RETAINED PWR | 96 | |
| SIGNAL BUFFER : System Diagram | 84 | RETAINED PWR : CONSULT Function (BCM - | | |
| SIGNAL BUFFER : System Description | 84 | RETAINED PWR) | 96 | E |
| POWER CONSUMPTION CONTROL SYSTEM | 84 | SIGNAL BUFFER | 96 | |
| POWER CONSUMPTION CONTROL SYSTEM : | | SIGNAL BUFFER : CONSULT Function (BCM - | | |
| System Diagram | 84 | SIGNAL BUFFER) | 96 | F |
| POWER CONSUMPTION CONTROL SYSTEM : | | AIR PRESSURE MONITOR | 96 | |
| System Description | 84 | AIR PRESSURE MONITOR : CONSULT Function | | |
| DIAGNOSIS SYSTEM (BCM) | 87 | (BCM - AIR PRESSURE MONITOR) | 96 | G |
| COMMON ITEM | 87 | PANIC ALARM | 97 | |
| COMMON ITEM : CONSULT Function (BCM - | | PANIC ALARM : CONSULT Function (BCM - | | |
| COMMON ITEM) | 87 | PANIC ALARM) | 97 | H |
| DOOR LOCK | 88 | ECU DIAGNOSIS INFORMATION | 98 | |
| DOOR LOCK : CONSULT Function (BCM - | | BCM | 98 | |
| DOOR LOCK) | 88 | Reference Value | 98 | I |
| REAR DEFOGGER | 88 | Fail-safe | 109 | J |
| REAR DEFOGGER : CONSULT Function (BCM - | | DTC Inspection Priority Chart | 109 | |
| REAR DEFOGGER) | 88 | DTC Index | 110 | |
| BUZZER | 89 | WIRING DIAGRAM | 112 | K |
| BUZZER : CONSULT Function (BCM - BUZZER)... | 89 | BCM | 112 | |
| INT LAMP | 89 | Wiring Diagram | 112 | L |
| INT LAMP : CONSULT Function (BCM - INT | | BASIC INSPECTION | 116 | |
| LAMP) | 89 | INSPECTION AND ADJUSTMENT | 116 | |
| MULTI REMOTE ENT | 90 | ADDITIONAL SERVICE WHEN REPLACING | | |
| MULTI REMOTE ENT : CONSULT Function | | CONTROL UNIT (BCM) | 116 | |
| (BCM - MULTI REMOTE ENT) | 90 | ADDITIONAL SERVICE WHEN REPLACING | | |
| HEADLAMP | 91 | CONTROL UNIT (BCM) : Description | 116 | N |
| HEADLAMP : CONSULT Function (BCM - HEAD | | ADDITIONAL SERVICE WHEN REPLACING | | |
| LAMP) | 91 | CONTROL UNIT (BCM) : Work Procedure | 116 | O |
| WIPER | 92 | CONFIGURATION (BCM) | 116 | |
| WIPER : CONSULT Function (BCM - WIPER) | 92 | CONFIGURATION (BCM) : Description | 117 | |
| FLASHER | 93 | CONFIGURATION (BCM) : Work Procedure | 117 | P |
| FLASHER : CONSULT Function (BCM - FLASH- | | CONFIGURATION (BCM) : Configuration List | 118 | |
| ER) | 93 | DTC/CIRCUIT DIAGNOSIS | 119 | |
| AIR CONDITIONER | 93 | U1000 CAN COMM | 119 | |
| AIR CONDITIONER : CONSULT Function (BCM - | | Description | 119 | |
| AIR CONDITIONER) | 93 | DTC Logic | 119 | |
| COMB SW | 94 | | | |
| COMB SW : CONSULT Function (BCM - COMB | | | | |
| SW) | 94 | | | |

| | | | |
|--|------------|--|------------|
| Diagnosis Procedure | 119 | SYMPTOM DIAGNOSIS | 126 |
| U1010 CONTROL UNIT (CAN) | 120 | COMBINATION SWITCH SYSTEM SYMP- | |
| DTC Logic | 120 | TOMS | 126 |
| Diagnosis Procedure | 120 | Symptom Table | 126 |
| POWER SUPPLY AND GROUND CIRCUIT .. | 121 | REMOVAL AND INSTALLATION | 127 |
| Diagnosis Procedure | 121 | BCM (BODY CONTROL MODULE) | 127 |
| COMBINATION SWITCH INPUT CIRCUIT | 122 | Removal and Installation | 127 |
| Diagnosis Procedure | 122 | COMBINATION SWITCH | 129 |
| COMBINATION SWITCH OUTPUT CIRCUIT . | 124 | Exploded View | 129 |
| Diagnosis Procedure | 124 | Removal and Installation | 129 |

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009020455

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

COMPONENT PARTS

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]


SYSTEM DESCRIPTION

COMPONENT PARTS

BODY CONTROL SYSTEM

BODY CONTROL SYSTEM : Component Parts Location

INFOID:000000009014186




1. BCM (view with instrument panel removed)

COMBINATION SWITCH READING SYSTEM

COMBINATION SWITCH READING SYSTEM : Component Parts Location

INFOID:000000009014187



COMPONENT PARTS

< SYSTEM DESCRIPTION >


[WITH INTELLIGENT KEY SYSTEM]

- 1. BCM (view with combination meter removed)
- 2. Combination switch (lighting and turn signal) (with fog lamps)
- 3. Combination switch (lighting and turn signal) (without fog lamps)
- 4. Combination switch (wiper and washer)

POWER CONSUMPTION CONTROL SYSTEM

POWER CONSUMPTION CONTROL SYSTEM : Component Parts Location

INFOID:000000009014188



- 1 IPDM E/R
- 2 BCM (view with instrument panel re-
- 3 Combination meter

AWM1A1357ZZ

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

< SYSTEM DESCRIPTION >

SYSTEM

BODY CONTROL SYSTEM

BODY CONTROL SYSTEM : System Description

INFOID:000000009014189

OUTLINE

- BCM (Body Control Module) controls the various electrical components. It inputs the information required to the control from CAN communication and the signal received from each switch and sensor.
- BCM has combination switch reading function for reading the operation status of combination switches (light, turn signal, wiper and washer) in addition to a function for controlling the operation of various electrical components. It also has the signal transmission function as the passed point of signal and the power saving control function that reduces the power consumption with the ignition switch OFF.
- BCM is equipped with the diagnosis function that performs the diagnosis with CONSULT and various settings.

BCM CONTROL FUNCTION LIST

| System | Reference |
|--|--|
| Combination switch reading system | BCS-9, "COMBINATION SWITCH READING SYSTEM : System Description" |
| Signal buffer system | BCS-13, "SIGNAL BUFFER SYSTEM : System Description" |
| Power consumption control system | BCS-13, "POWER CONSUMPTION CONTROL SYSTEM : System Description" |
| Headlamp system | EXL-8, "HEADLAMP SYSTEM : System Description" |
| Daytime light system | EXL-9, "DAYTIME RUNNING LIGHT SYSTEM : System Description" |
| Turn signal and hazard warning lamp system | EXL-10, "TURN SIGNAL AND HAZARD WARNING LAMPS : System Description" |
| Parking, license plate and tail lamps system | EXL-11, "PARKING, LICENSE PLATE AND TAIL LAMPS : System Description" |
| Front fog lamp system | EXL-10, "FRONT FOG LAMP SYSTEM : System Description" |
| Exterior lamp battery saver system | EXL-8, "HEADLAMP SYSTEM : System Description" |
| Interior room lamp control system | INL-8, "INTERIOR ROOM LAMP CONTROL SYSTEM : System Description" |
| Interior room lamp battery saver system | INL-8, "INTERIOR ROOM LAMP CONTROL SYSTEM : System Description" |
| Front wiper and washer system | WW-8, "System Description" |
| Rear window defogger system | DEF-6, "System Description" |
| Manual air conditioning system | HAC-120, "System Description" |
| Automatic air conditioning system | HAC-12, "System Description" |
| Warning chime system | WCS-6, "WARNING CHIME SYSTEM : System Description" |
| Power door lock system | DLK-22, "System Description" |
| Trunk lid opener system | DLK-34, "System Description" |
| Nissan vehicle immobilizer system (NVIS) | SEC-16, "NISSAN ANTI-THEFT SYSTEM : System Description" |
| Vehicle security system | SEC-18, "VEHICLE SECURITY SYSTEM : System Description" |
| Panic alarm | SEC-18, "VEHICLE SECURITY SYSTEM : System Description" |

SYSTEM

< SYSTEM DESCRIPTION >


[WITH INTELLIGENT KEY SYSTEM]

| System | Reference | |
|--|--|--|
| Intelligent Key system/engine start system | Door lock function | DLK-25. "DOOR LOCK FUNCTION : System Description" |
| | Trunk open function | DLK-27. "TRUNK OPEN FUNCTION : System Description" |
| | Warning function | DLK-31. "WARNING FUNCTION : System Description" |
| | Key reminder function | DLK-30. "KEY REMINDER FUNCTION : System Description" |
| Power window system | PWC-8. "System Description" | |
| RAP (retained accessory power) system | BCS-26. "RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)" | |
| TPMS (tire pressure monitoring system) | WT-8. "TIRE PRESSURE MONITORING SYSTEM : System Description" | |

COMBINATION SWITCH READING SYSTEM

COMBINATION SWITCH READING SYSTEM : System Diagram

INFOID:000000009014190



COMBINATION SWITCH READING SYSTEM : System Description

INFOID:000000009014191

OUTLINE

- BCM reads the status of the combination switch (light, turn signal, wiper and washer) and recognizes the status of each switch.
- BCM has a combination of 5 output terminals (OUTPUT 1 - 5) and 5 input terminals (INPUT 1 - 5). It reads a maximum of 20 switch states.

COMBINATION SWITCH MATRIX

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P


BCS

SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

Combination switch circuit




Combination switch INPUT-OUTPUT system list

| System | INPUT 1 | INPUT 2 | INPUT 3 | INPUT 4 | INPUT 5 |
|----------|--------------|--------------|--------------|------------|------------|
| OUTPUT 1 | — | FR WASHER | FR WIPER LOW | TURN LH | TURN RH |
| OUTPUT 2 | FR WIPER HI | — | FR WIPER INT | PASSING | HEADLAMP 1 |
| OUTPUT 3 | INT VOLUME 1 | — | — | HEADLAMP 2 | HI BEAM |
| OUTPUT 4 | — | INT VOLUME 3 | AUTO LIGHT | — | TAIL LAMP |
| OUTPUT 5 | INT VOLUME 2 | — | — | FR FOG | — |

COMBINATION SWITCH READING FUNCTION

Description

- BCM reads the status of the combination switch at 10 ms intervals normally.



NOTE:

BCM reads the status of the combination switch at 60 ms intervals when BCM is controlled at low power consumption control mode.


- BCM operates as follows and judges the status of the combination switch.
 - It operates the transistor on OUTPUT side in the following order: OUTPUT 1 → 2 → 3 → 4 → 5, and outputs voltage waveform.
 - The voltage waveform of OUTPUT corresponding to the formed circuit is input into the interface on INPUT side if any (1 or more) switches are ON.

SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

- It reads this change of the voltage as the status signal of the combination switch.




Operation Example

In the following operation example, the combination of the status signals of the combination switch is replaced as follows: INPUT 1 - 5 to "1 - 5" and OUTPUT 1 - 5 to "A - E".

Example 1: When a switch (TAIL LAMP) is turned ON

- The circuit between OUTPUT 4 and INPUT 5 is formed when the TAIL LAMP switch is turned ON.



- BCM detects the combination switch status signal "5D" when the signal of OUTPUT 4 is input to INPUT 5.
- BCM judges that the TAIL LAMP switch is ON when the signal "5D" is detected.


Example 2: When some switches (TURN RH, TAIL LAMP) are turned ON

SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

- The circuits between OUTPUT 1 and INPUT 5 and between OUTPUT 4 and INPUT 5 are formed when the TURN RH switch and TAIL LAMP switch are turned ON.



- BCM detects the combination switch status signal "5AD" when the signals of OUTPUT 1 and OUTPUT 4 are input to INPUT 5.
- BCM judges that the TURN RH switch and TAIL LAMP switch are ON when the signal "5AD" is detected.

WIPER INTERMITTENT DIAL POSITION

BCM judges the wiper intermittent dial 1 - 7 by the status of INT VOLUME 1, 2 and 3 switches.

| Wiper intermittent dial position | Switch status | | |
|----------------------------------|---------------|--------------|--------------|
| | INT VOLUME 1 | INT VOLUME 2 | INT VOLUME 3 |
| 1 | ON | ON | ON |
| 2 | ON | ON | OFF |
| 3 | ON | OFF | OFF |
| 4 | OFF | OFF | OFF |
| 5 | OFF | OFF | ON |
| 6 | OFF | ON | ON |
| 7 | OFF | ON | OFF |


NOTE:

For details of wiper intermittent dial position, refer to [WW-8, "System Description"](#).

SIGNAL BUFFER SYSTEM

SIGNAL BUFFER SYSTEM : System Diagram

INFOID:000000009014192



SYSTEM

< SYSTEM DESCRIPTION >

[WITH INTELLIGENT KEY SYSTEM]

SIGNAL BUFFER SYSTEM : System Description

INFOID:000000009014193

OUTLINE

BCM has the signal transmission function that outputs/transmits each input/received signal to each unit.


Signal transmission function list

| Signal name | Input | Output | Description |
|--|-----------------------------|--|---|
| <ul style="list-style-type: none">Ignition switch ON signalIgnition switch signal | Engine switch (push switch) | IPDM E/R (CAN) | Inputs the push-button ignition switch (push switch) signal and transmits the ignition switch status judged with BCM via CAN communication. |
| Door switch signal | Any door switch | <ul style="list-style-type: none">Combination meter (CAN)IPDM E/R (CAN) | Inputs the door switch signal and transmits it via CAN communication. |

POWER CONSUMPTION CONTROL SYSTEM

POWER CONSUMPTION CONTROL SYSTEM : System Diagram

INFOID:000000009014194



POWER CONSUMPTION CONTROL SYSTEM : System Description

INFOID:000000009014195

OUTLINE

- BCM incorporates a power saving control function that reduces the power consumption according to the vehicle status.
- BCM switches the status (control mode) by itself with the power saving control function. It performs the sleep request to each unit (IPDM E/R and combination meter) that operates with the ignition switch OFF.

Normal mode (wake-up)

- CAN communication is normally performed with other units
- Each control with BCM is operating properly

CAN communication sleep mode (CAN sleep)

- CAN transmission is stopped
- Control with BCM only is operating

Low power consumption mode (BCM sleep)

- Low power consumption control is active
- CAN transmission is stopped

LOW POWER CONSUMPTION CONTROL WITH BCM

BCM reduces the power consumption with the following operation in the low power consumption mode.

- The reading interval of each switch changes from 10 ms interval to 60 ms interval.

Sleep mode activation

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

SYSTEM

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

- BCM receives the sleep-ready signal (ready) from IPDM E/R and combination meter via CAN communication.
- BCM transmits the sleep wake up signal (sleep) to each unit when all of the CAN sleep conditions are fulfilled.
- Each unit stops the transmission of CAN communication with the sleep wakeup signal. BCM is in CAN communication sleep mode.
- BCM is in the low power consumption mode and performs the low power consumption control when all of the BCM sleep conditions are fulfilled with CAN sleep condition.

Sleep condition

| CAN sleep condition | BCM sleep condition |
|--|---|
| <ul style="list-style-type: none"> • Receiving the sleep-ready signal (ready) from all units • Ignition switch: OFF • Vehicle security system alarm and panic alarm: No operation • Warning lamp: Not operation • Intelligent Key system buzzer: No operation • Brake switch: OFF • Turn signal indicator lamp: No operation • Exterior lamp: OFF • Door lock status: No change • CONSULT communication status: No communication • Meter display signal: Non-transmission • Door switch status: No change • Rear window defogger: OFF | <ul style="list-style-type: none"> • Interior room lamp battery saver: Time out • RAP system: OFF • Push-button ignition switch (push switch) illumination: OFF • NATS: No operation • Remote keyless entry receiver communication status: No communication • Tire pressure monitoring system: Stop |

Wake-up operation

- BCM changes from the low power consumption mode to the CAN communication sleep mode when the any of the BCM wake-up conditions are fulfilled. Only the control with BCM is activated.
- BCM transmits the sleep wake up signal (wake up) to each unit when any of the CAN wake-up conditions are fulfilled. It changes from the low power consumption mode or the CAN communication sleep mode to the normal mode.
- Each unit starts the transmission of CAN communication with the sleep wake up signal. In addition, the combination meter transmits the wake up signal to BCM via CAN communication to report the CAN communication start.

| BCM wake-up condition | CAN wake-up condition |
|---|---|
| <ul style="list-style-type: none"> • Door lock assembly LH (key cylinder switch): Lock or unlock • Door lock switch: OFF→ON • Door unlock switch: OFF→ON • Trunk opener switch: OFF→ON • Remote keyless entry receiver: Receiving valid keyfob | <ul style="list-style-type: none"> • Receiving the sleep-ready signal (Not-ready) from any units • Push-button ignition switch (push switch): OFF→ON • Hazard switch: OFF→ON • PASSING switch: OFF→ON, ON→OFF • TAIL LAMP switch: OFF→ON • Driver door switch: OFF→ON, ON→OFF • Passenger door switch: OFF → ON, ON → OFF • Trunk switch: OFF→ON, ON→OFF • Driver door request switch: OFF→ON • Passenger door request switch: OFF→ON • Stop lamp switch 2 signal: ON • Remote keyless entry receiver: Receiving valid keyfob |

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009014196

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

| Direct Diagnostic Mode | Description |
|------------------------|--|
| ECU identification | The BCM part number is displayed. |
| Self Diagnostic Result | The BCM self diagnostic results are displayed. |
| Data Monitor | The BCM input/output data is displayed in real time. |
| Active Test | The BCM activates outputs to test components. |
| Work support | The settings for BCM functions can be changed. |
| Configuration | <ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM. |
| CAN DIAG SUPPORT MNTR | The result of transmit/receive diagnosis of CAN communication is displayed. |

SYSTEM APPLICATION

BCM can perform the following functions.

| System | Sub System | Direct Diagnostic Mode | | | | | | |
|--------------------------------------|----------------------|------------------------|------------------------|--------------|-------------|--------------|---------------|-----------------------|
| | | ECU identification | Self Diagnostic Result | Data Monitor | Active Test | Work support | Configuration | CAN DIAG SUPPORT MNTR |
| Door lock | DOOR LOCK | | × | × | × | × | | |
| Rear window defogger | REAR DEFOGGER | | | × | × | | | |
| Warning chime | BUZZER | | | × | × | | | |
| Interior room lamp timer | INT LAMP | | | × | × | × | | |
| Exterior lamp | HEAD LAMP | | | × | × | × | | |
| Wiper and washer | WIPER | | | × | × | × | | |
| Turn signal and hazard warning lamps | FLASHER | | | × | × | × | | |
| Air conditioner | AIR CONDITIONER | | | × | | | | |
| Intelligent Key system | INTELLIGENT KEY | | × | × | × | × | | |
| Combination switch | COMB SW | | | × | | | | |
| BCM | BCM | × | × | | | × | × | × |
| Immobilizer | IMMU | | × | × | × | × | | |
| Interior room lamp battery saver | BATTERY SAVER | | | × | × | × | | |
| Trunk open | TRUNK | | | × | | | | |
| Vehicle security system | THEFT ALM | | | × | × | × | | |
| RAP system | RETAINED PWR | | | × | | | | |
| Signal buffer system | SIGNAL BUFFER | | | × | | | | |
| TPMS | AIR PRESSURE MONITOR | | × | × | × | × | | |

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

DOOR LOCK

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK)

INFOID:000000009014197

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| REQ SW-DR [On/Off] | Indicates condition of door request switch LH. |
| REQ SW-AS [On/Off] | Indicates condition of door request switch RH. |
| REQ SW -BD/TR [On/Off] | Indicates condition of trunk open switch. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| DOOR SW-BK [On/Off] | Indicates condition of trunk switch. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| KEY CYL LK-SW [On/Off] | Indicates condition of lock signal from door key cylinder switch. |
| KEY CYL UN-SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch. |

ACTIVE TEST

| Test Item | Description |
|-----------|---|
| DOOR LOCK | This test is able to check door lock operation [OTR ULK/AS UNLK/DR UNLK/ALL UNLK/ALL LOCK]. |

WORK SUPPORT

| Support Item | Setting | Description |
|------------------------------|--------------|--|
| DOOR LOCK-UNLOCK SET | On* | Automatic door locks function ON. |
| | Off | Automatic door locks function OFF. |
| AUTOMATIC LOCK/UNLOCK SELECT | Lock/Unlock* | Automatic door locks function operates in lock and unlock. |
| | Lock Only | Automatic door locks function operates in lock only. |
| | Unlock Only | Automatic door locks function operates in unlock only. |
| | Off | Automatic door locks function OFF. |
| AUTOMATIC DOOR LOCK SELECT | P RANGE | Doors lock automatically when shifted out of Park (P). |
| | VH SPD* | Doors lock automatically when vehicle speed reaches 24 km/h (15 mph). |
| AUTOMATIC DOOR UNLOCK SELECT | MODE6* | Drivers door unlocks automatically when key is removed. |
| | MODE5 | Drivers door unlocks automatically when shifted into Park (P). |
| | MODE4 | Drivers door unlocks automatically when ignition is switched from ON to OFF. |
| | MODE3 | Doors unlock automatically when key is removed. |
| | MODE2 | Doors unlock automatically when shifted into Park (P). |
| | MODE1 | Doors unlock automatically when ignition is switched from ON to OFF. |

*: Initial setting

REAR DEFOGGER

REAR DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)

INFOID:000000009014198

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|----------------------|---|
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| REAR DEF SW [On/Off] | Indicates condition of rear window defogger switch. |

ACTIVE TEST

| Test Item | Description |
|---------------|---|
| REAR DEFOGGER | This test is able to check rear window defogger operation [Off/On]. |

BUZZER

BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:000000009014199

DATA MONITOR

| Monitor Item [Unit] | Description |
|-----------------------|---|
| PUSH -SW [On/Off] | Indicates condition of push-button ignition switch. |
| UNLK SEN -DR [On/Off] | Indicates condition of driver door unlock sensor. |
| VEH SPEED 1 [km/h] | Indicates vehicle speed signal received from ABS on CAN communication line. |
| TAIL LAMP SW [On/Off] | Indicates condition of combination switch. |
| FR FOG SW [On/Off] | Indicates condition of front fog lamp switch. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |

ACTIVE TEST

| Test Item | Description |
|---------------------|---|
| ID REGIST WARNING | This test is able to check TPMS transmitter ID regist warning chime operation [On/Off]. |
| SEAT BELT WARN TEST | This test is able to check seat belt warning chime operation [On/Off]. |
| LIGHT WARN ALM | This test is able to check light warning chime operation [On/Off]. |

INT LAMP

INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:000000009014200

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| REQ SW -DR [On/Off] | Indicates condition of door request switch LH. |
| REQ SW -AS [On/Off] | Indicates condition of door request switch RH. |
| PUSH -SW [On/Off] | Indicates condition of push-button ignition switch. |
| UNLK SEN -DR [On/Off] | Indicates condition of driver door unlock sensor. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| DOOR SW-BK [On/Off] | Indicates condition of trunk switch. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| KEY CYL LK-SW [On/Off] | Indicates condition of lock signal from door key cylinder switch. |
| KEY CYL UN-SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch. |

A

B

C

D

E

F

G

H

I

J

K

L

BCS

N

O

P

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|------------------------|--|
| TRNK/HAT MNTR [On/Off] | Indicates condition of trunk room lamp switch. |
| RKE-LOCK [On/Off] | Indicates condition of lock signal from Intelligent Key. |
| RKE-UNLOCK [On/Off] | Indicates condition of unlock signal from Intelligent Key. |

ACTIVE TEST

| Test Item | Description |
|-----------|---|
| INT LAMP | This test is able to check interior room lamp operation [On/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|------------------------|---------|---|
| R LAMP TIMER LOGIC SET | MODE 2 | Interior room lamp timer activates with all doors. |
| | MODE 1* | Interior room lamp timer activates with the driver door only. |
| SET I/L D-UNLCK INTCON | On* | Interior room lamp timer function ON. |
| | Off | Interior room lamp timer function OFF. |
| ROOM LAMP TIMER SET | MODE 4 | 30 sec. |
| | MODE 3* | 15 sec. |
| | MODE 2 | 7.5 sec. |
| | | Sets the interior room lamp ON time. (Timer operating time). |

*: Initial setting

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)

INFOID:000000009014201

DATA MONITOR

| Monitor Item [Unit] | Description |
|-------------------------------------|--|
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| ENGINE STATE [Stop/Stall/Crank/Run] | Indicates engine status received from ECM on CAN communication line. |
| VEH SPEED 1 [km/h] | Indicates vehicle speed signal received from ABS on CAN communication line. |
| TURN SIGNAL R [On/Off] | Indicates condition of combination switch. |
| TURN SIGNAL L [On/Off] | |
| TAIL LAMP SW [On/Off] | |
| HI BEAM SW [On/Off] | |
| HEAD LAMP SW 1 [On/Off] | |
| HEAD LAMP SW 2 [On/Off] | |
| PASSING SW [On/Off] | |
| AUTO LIGHT SW [On/Off] | |
| FR FOG SW [On/Off] | |
| DOOR SW-DR [On/Off] | |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| DOOR SW-BK [On/Off] | Indicates condition of trunk switch. |
| OPTI SEN (DTCT) [V] | Indicates outside brightness voltage signal from optical sensor. |
| OPTI SEN (FILT) [V] | Indicates outside brightness voltage signal from optical sensor filtered by BCM. |

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Test Item | Description |
|----------------|---|
| FR FOG LAMP | This test is able to check front fog lamp operation [On/Off]. |
| HEAD LAMP | This test is able to check head lamp operation [Hi/Low/Off]. |
| ILL DIM SIGNAL | This test is able to check head lamp illumination dimming operation [On/Off]. |
| TAIL LAMP | This test is able to check tail lamp operation [On/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|------------------------|---------|--|
| CUSTOM A/LIGHT SETTING | MODE6 | Twilight OFF without wiper. |
| | MODE5 | Twilight OFF with wiper LO and HI. |
| | MODE4 | Twilight OFF with wiper INT, LO and HI. |
| | MODE3 | Twilight ON without wiper. |
| | MODE2 | Twilight ON with wiper LO and HI. |
| | MODE1* | Twilight ON with wiper INT, LO and HI. |
| BATTERY SAVER SET | On* | Exterior lamp battery saver function ON. |
| | Off | Exterior lamp battery saver function OFF. |
| CUSTOM A/LIGHT SETTING | MODE4 | Less sensitive than normal setting (turns ON later). |
| | MODE3 | More sensitive than MODE2. |
| | MODE2 | More sensitive than normal setting (turns ON earlier). |
| | MODE1* | Normal setting. |
| ILL DELAY SET | MODE 8 | 180 sec. |
| | MODE 7 | 150 sec. |
| | MODE 6 | 120 sec. |
| | MODE 4 | 60 sec. |
| | MODE 5 | 90 sec. |
| | MODE 3 | 30 sec. |
| | MODE 2 | OFF |
| | MODE 1* | 45 sec. |
| | | Sets delay timer function operation time (All doors closed). |

*: Initial setting

WIPER

WIPER : CONSULT Function (BCM - WIPER)

INFOID:000000009014202

BCS

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| VEH SPEED 1 [km/h] | Indicates vehicle speed signal received from ABS on CAN communication line. |
| FR WIPER HI [On/Off] | Indicates condition of wiper operation of combination switch. |
| FR WIPER LOW [On/Off] | |
| FR WASHER SW [On/Off] | |
| FR WIPER INT [On/Off] | |
| FR WIPER STOP [On/Off] | Indicates front wiper auto stop signal received from IPDM E/R on CAN communication line. |
| INT VOLUME [1 - 7] | Indicates condition of intermittent wiper operation of combination switch. |

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Test Item | Description |
|-----------|---|
| FR WIPER | This test is able to check front wiper operation [INT/Lo/Hi/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|---------------------|---------|--|
| WIPER SPEED SETTING | On | Front wiper intermittent time linked with vehicle speed and wiper dial position. |
| | Off* | Front wiper intermittent time linked with wiper dial position. |

* : Initial setting

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000009014203

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| REQ SW -DR [On/Off] | Indicates condition of door request switch LH. |
| REQ SW -AS [On/Off] | Indicates condition of door request switch RH. |
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| TURN SIGNAL R [On/Off] | Indicates condition of turn signal function of combination switch. |
| TURN SIGNAL L [On/Off] | |
| HAZARD SW [On/Off] | Indicates condition of hazard switch. |
| RKE-LOCK [On/Off] | Indicates condition of lock signal from Intelligent Key. |
| RKE-UNLOCK [On/Off] | Indicates condition of unlock signal from Intelligent Key. |
| RKE-PANIC [On/Off] | Indicates condition of panic alarm signal from Intelligent Key. |

ACTIVE TEST

| Test Item | Description |
|-----------|--|
| FLASHER | This test is able to check turn signal lamp operation [Off/LH/RH]. |

WORK SUPPORT

| Support Item | Setting | Description |
|--------------------|--------------|---|
| HAZARD ANSWER BACK | Lock/Unlock* | Hazard warning lamp activation when doors are locked or unlocked with Intelligent Key. |
| | Unlock Only | Hazard warning lamp activation when doors are unlocked with Intelligent Key. |
| | Lock Only | Hazard warning lamp activation when doors are locked with Intelligent Key. |
| | Off | No hazard warning lamp activation when doors are locked or unlocked with Intelligent Key. |

* : Initial setting

AIR CONDITIONER

AIR CONDITIONER : CONSULT Function (BCM - AIR CONDITIONER)

INFOID:000000009014204

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|----------------------|------------------------------------|
| FAN ON SIG [On/Off] | Indicates condition of fan switch. |
| AIR COND SW [On/Off] | Indicates condition of A/C switch. |

INTELLIGENT KEY

INTELLIGENT KEY : CONSULT Function (BCM - INTELLIGENT KEY)

INFOID:000000009014205

SELF DIAGNOSTIC RESULT

Refer to [BCS-50. "DTC Index"](#).

DATA MONITOR

| Monitor Item [Unit] | Main | Description |
|-------------------------------------|------|--|
| REQ SW -DR [On/Off] | × | Indicates condition of door request switch LH. |
| REQ SW -AS [On/Off] | × | Indicates condition of door request switch RH. |
| REQ SW -BD/TR [On/Off] | × | Indicates condition of trunk open switch. |
| PUSH SW [On/Off] | | Indicates condition of push-button ignition switch. |
| BRAKE SW 1 [On/Off] | × | Indicates condition of brake switch. |
| BRAKE SW 2 [On/Off] | | Indicates condition of brake switch. |
| DETE/CANCL SW [On/Off] | × | Indicates condition of P (park) position. |
| SFT PN/N SW [On/Off] | × | Indicates condition of P (park) or N (neutral) position. |
| UNLK SEN -DR [On/Off] | × | Indicates condition of driver door unlock sensor. |
| PUSH SW -IPDM [On/Off] | | Indicates condition of push-button ignition switch received from IPDM E/R on CAN communication line. |
| IGN RLY1 -F/B [On/Off] | | Indicates condition of ignition relay 1 received from IPDM E/R on CAN communication line. |
| DETE SW -IPDM [On/Off] | | Indicates condition of detent switch received from TCM on CAN communication line. |
| SFT PN -IPDM [On/Off] | | Indicates condition of P (park) or N (neutral) position from TCM on CAN communication line. |
| SFT P -MET [On/Off] | | Indicates condition of P (park) position from TCM on CAN communication line. |
| SFT N -MET [On/Off] | | Indicates condition of N (neutral) position from IPDM E/R on CAN communication line. |
| ENGINE STATE [Stop/Start/Crank/Run] | × | Indicates condition of engine state from ECM on CAN communication line. |
| VEH SPEED 1 [mph/km/h] | × | Indicates condition of vehicle speed signal received from ABS on CAN communication line. |
| VEH SPEED 2 [mph/km/h] | × | Indicates condition of vehicle speed signal received from combination meter on CAN communication line. |
| DOOR STAT -DR [LOCK/READY/UNLK] | × | Indicates condition of driver side door status. |
| DOOR STAT -AS [LOCK/READY/UNLK] | × | Indicates condition of passenger side door status. |
| ID OK FLAG [Set/Reset] | | Indicates condition of Intelligent Key ID. |
| PRMT ENG STRT [Set/Reset] | | Indicates condition of engine start possibility. |
| PRMT RKE STRT [Set/Reset] | | Indicates condition of engine start possibility from Intelligent Key. |
| RKE OPE COUN1 [0-19] | × | When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing. |
| RKE OPE COUN2 [0-19] | × | When remote keyless entry receiver receives the signal transmitted while operating on Intelligent Key, the numerical value start changing. |
| TRNK/HAT MNTR [On/Off] | | Indicates condition of trunk room lamp switch. |
| RKE-LOCK [On/Off] | | Indicates condition of lock signal from Intelligent Key. |
| RKE-UNLOCK [On/Off] | | Indicates condition of unlock signal from Intelligent Key. |

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Main | Description |
|-----------------------|------|---|
| RKE-TR/BD [On/Off] | | Indicates condition of trunk open signal from Intelligent Key. |
| RKE-PANIC [On/Off] | | Indicates condition of panic signal from Intelligent Key. |
| RKE-MODE CHG [On/Off] | | Indicates condition of mode change signal from Intelligent Key. |

ACTIVE TEST

| Test Item | Description |
|-----------------------|---|
| INSIDE BUZZER | This test is able to check combination meter warning chime operation [Take Out/Knob/Key/Off]. |
| LCD | This test is able to check combination meter display information [Off/LK WN/OUTKEY/NO KY/BATT/INSRT/SFT P/ROTAT/ID NG/B&P I/B&P N]. |
| BATTERY SAVER | This test is able to check battery saver operation [On/Off]. |
| ENGINE SW ILLUMI | This test is able to check push-button ignition switch START indicator operation [On/Off]. |
| PUSH SWITCH INDICATOR | This test is able to check push-button ignition switch indicator operation [On/Off]. |
| TRUNK/BACK DOOR | This test is able to check trunk actuator operation [Open]. |
| INT LAMP | This test is able to check interior room lamp operation [On/Off]. |
| INDICATOR | This test is able to check combination meter warning lamp operation [KEY ON/KEY IND/Off]. |
| FLASHER | This test is able to check hazard lamp operation [LH/RH/Off]. |
| OUTSIDE BUZZER | This test is able to check Intelligent Key warning buzzer operation [On/Off]. |
| HORN | This test is able to check horn operation [On]. |
| P RANGE | This test is able to check CVT shift selector illumination operation [On/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|-------------------------|--------------|--|
| LOCK/UNLOCK BY I-KEY | On* | Door lock/unlock function from Intelligent Key ON. |
| | Off | Door lock/unlock function from Intelligent Key OFF. |
| TRUNK/GLASS HATCH OPEN | On* | Buzzer reminder function from trunk opener switch. |
| | Off | No buzzer reminder function from trunk opener switch. |
| ANTI KEY LOCK IN FUNCTI | On* | Anti lock out setting ON. |
| | Off | Anti lock out setting OFF. |
| ANS BACK I-KEY UNLOCK | Off | No buzzer reminder when doors are unlocked with request switch. |
| | On* | Buzzer reminder when doors are unlocked with request switch. |
| ANS BACK I-KEY LOCK | Horn Chirp | Horn chirp reminder when doors are locked with request switch. |
| | Buzzer* | Buzzer reminder when doors are locked with request switch. |
| | Off | No reminder when doors are locked with request switch. |
| HORN WITH KEYLESS LOCK | Off | Horn chirp reminder when doors are locked with Intelligent Key. |
| | On* | No horn chirp reminder when doors are locked with Intelligent Key. |
| ENGINE START BY I-KEY | On* | Engine start function from Intelligent Key ON. |
| | Off | Engine start function from Intelligent Key OFF. |
| HAZARD ANSWER BACK | Lock/Unlock* | Hazard warning lamp activation when doors are locked/unlocked with Intelligent Key or request switch. |
| | Unlock Only | Hazard warning lamp activation when doors are unlocked with Intelligent Key or request switch. |
| | Lock Only | Hazard warning lamp activation when doors are locked with Intelligent Key or request switch. |
| | Off | No hazard warning lamp activation when doors are locked/unlocked with Intelligent Key or request switch. |

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Support Item | Setting | Description |
|--------------------------|---------|---|
| INSIDE ANT DIAGNOSIS | — | This function allows inside key antenna self-diagnosis. |
| CONFIRM KEY FOB ID | — | Intelligent Key ID code can be checked. |
| SHORT CRANKING OUTPUT | Start | 70 msec |
| | | 100 msec |
| | | 200 msec |
| | End | — |
| PANIC ALARM SET | MODE 3 | 1.5 sec |
| | MODE 2 | OFF |
| | MODE 1* | 0.5 sec |
| LO- BATT OF KEY FOB WARN | On* | Intelligent Key low battery warning ON. |
| | Off | Intelligent Key low battery warning OFF. |
| AUTO LOCK SET | MODE7 | 5 min |
| | MODE6 | 4 min |
| | MODE5 | 3 min |
| | MODE4 | 2 min |
| | MODE3* | 1 min |
| | MODE2 | 30 sec |
| | MODE1 | Off |
| TRUNK OPEN DELAY | MODE 3 | 1.5 sec |
| | MODE 2 | OFF |
| | MODE 1* | 0.5 sec |

*: Initial Setting

COMB SW

COMB SW : CONSULT Function (BCM - COMB SW)

INFOID:000000009014206

DATA MONITOR

| Monitor Item [Unit] | Description |
|-------------------------|---|
| FR WIPER HI [On/Off] | Indicates condition of wiper operation of combination switch. |
| FR WIPER LOW [On/Off] | |
| FR WASHER SW [On/Off] | |
| FR WIPER INT [On/Off] | |
| INT VOLUME [1 - 7] | Indicates condition of intermittent wiper operation of combination switch. |
| TURN SIGNAL R [On/Off] | Indicates condition of right turn signal operation of combination switch. |
| TURN SIGNAL L [On/Off] | Indicates condition of left turn signal operation of combination switch. |
| TAIL LAMP SW [On/Off] | Indicates condition of tail lamp switch operation of combination switch. |
| HI BEAM SW [On/Off] | Indicates condition of Hi beam switch operation of combination switch. |
| HEAD LAMP SW 1 [On/Off] | Indicates condition of head lamp switch 1 operation of combination switch. |
| HEAD LAMP SW 2 [On/Off] | Indicates condition of head lamp switch 2 operation of combination switch. |
| PASSING SW [On/Off] | Indicates condition of passing switch operation of combination switch. |
| AUTO LIGHT SW [On/Off] | Indicates condition of auto light switch operation of combination switch. |
| FR FOG SW [On/Off] | Indicates condition of front fog lamp switch operation of combination switch. |

BCM

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

BCM : CONSULT Function (BCM - BCM)

INFOID:000000009014207

ECU IDENTIFICATION

The BCM part number is displayed.

SELF DIAGNOSTIC RESULT

Refer to [BCS-50, "DTC Index"](#).

WORK SUPPORT

| Support Item | Setting | Description |
|---------------------|---------|---|
| RESET SETTING VALUE | Reset | Returns BCM to initial value in factory shipment. |
| | Cancel | Cancels the reset function. |

CONFIGURATION

Refer to [BCS-62, "CONFIGURATION \(BCM\) : Description"](#).

CAN DIAG SUPPORT MNTR

Refer to [LAN-13, "CAN Diagnostic Support Monitor"](#).

IMMU

IMMU : CONSULT Function (BCM - IMMU)

INFOID:000000009014208

SELF DIAGNOSTIC RESULT

Refer to [BCS-50, "DTC Index"](#).

DATA MONITOR

| Monitor Item [Unit] | Description |
|---------------------------|--|
| CONFIRM ID ALL [Yet/DONE] | Switches to DONE when an Intelligent Key is registered. |
| CONFIRM ID4 [Yet/DONE] | |
| CONFIRM ID3 [Yet/DONE] | |
| CONFIRM ID2 [Yet/DONE] | |
| CONFIRM ID1 [Yet/DONE] | |
| TP 4 [Yet/DONE] | DONE indicates the number of Intelligent Key ID which has been registered. |
| TP 3 [Yet/DONE] | |
| TP 2 [Yet/DONE] | |
| TP 1 [Yet/DONE] | |
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |

ACTIVE TEST

| Test Item | Description |
|-----------|---|
| THEFT IND | This test is able to check security indicator operation [On/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|-------------------|---------|-----------------------------|
| CONFIRM DONGLE ID | — | Dongle ID code can be read. |

BATTERY SAVER

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:000000009014209

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description | |
|------------------------|--|---|
| REQ SW -DR [On/Off] | Indicates condition of door request switch LH. | A |
| REQ SW -AS [On/Off] | Indicates condition of door request switch RH. | B |
| PUSH SW [On/Off] | Indicates condition push-button ignition switch. | B |
| UNLK SEN -DR [On/Off] | Indicates condition of driver door unlock sensor. | |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. | C |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. | |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. | |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. | D |
| DOOR SW-BK [On/Off] | Indicates condition of trunk switch. | |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. | E |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. | |
| KEY CYL LK-SW [On/Off] | Indicates condition of lock signal from door key cylinder switch. | |
| KEY CYL UN-SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch. | F |
| TRNK/HAT MNTR [On/Off] | Indicates condition of trunk room lamp switch. | |
| RKE-LOCK [On/Off] | Indicates condition of lock signal from Intelligent Key. | G |
| RKE-UNLOCK [On/Off] | Indicates condition of unlock signal from Intelligent Key. | |

ACTIVE TEST

| Test item | Description | |
|---------------|--|---|
| BATTERY SAVER | This test is able to check battery saver operation [On/Off]. | H |

WORK SUPPORT

| Support Item | Setting | Description | |
|---------------------|---------|---|---|
| BATTERY SAVER SET | ON* | Exterior lamp battery saver function ON. | J |
| | OFF | Exterior lamp battery saver function OFF. | |
| ROOM LAMP TIMER SET | MODE 3* | 10 min. | K |
| | MODE 2 | 60 min. | |
| | MODE 1 | 15 min. | L |

*: Initial setting

TRUNK

TRUNK : CONSULT Function (BCM - TRUNK)

INFOID:000000009014210

BCS

DATA MONITOR

| Monitor Item [Unit] | Description | |
|------------------------|---|---|
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. | |
| UNLK SEN -DR [On/Off] | Indicates condition of driver door unlock sensor. | O |
| VEH SPEED 1 [km/h] | Indicates vehicle speed signal received from ABS on CAN communication line. | |
| TR/BD OPEN SW [On/Off] | Indicates condition of trunk open switch. | P |
| TRNK/HAT MNTR [On/Off] | Indicates condition of trunk room lamp switch. | |
| RKE-TR/BD [On/Off] | Indicates condition of trunk open signal from Intelligent Key. | |

THEFT ALM

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

THEFT ALM : CONSULT Function (BCM - THEFT)

INFOID:000000009014211

DATA MONITOR

| Monitored Item | Description |
|------------------------|--|
| REQ SW -DR [On/Off] | Indicates condition of door request switch LH. |
| REQ SW -AS [On/Off] | Indicates condition of door request switch RH. |
| REQ SW -BD/TR [On/Off] | Indicates condition of trunk open switch. |
| PUSH SW [On/Off] | Indicates condition of push-button ignition switch. |
| UNLK SEN -DR [On/Off] | Indicates condition of driver door unlock sensor. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| DOOR SW-BK [On/Off] | Indicates condition of trunk switch. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| KEY CYL LK-SW [On/Off] | Indicates condition of lock signal from door key cylinder switch. |
| KEY CYL UN-SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch. |
| TR/BD OPEN SW [On/Off] | Indicates condition of trunk open switch. |
| TRNK/HAT MNTR [On/Off] | Indicates condition of trunk room lamp switch. |
| RKE-LOCK [On/Off] | Indicates condition of lock signal from Intelligent Key. |
| RKE-UNLOCK [On/Off] | Indicates condition of unlock signal from Intelligent Key. |
| RKE-TR/BD [On/Off] | Indicates condition of trunk open signal from Intelligent Key. |

ACTIVE TEST

| Test Item | Description |
|-----------------------|--|
| VEHICLE SECURITY HORN | This test is able to check vehicle security horn operation [On]. |
| FLASHER | This test is able to check turn signal lamp operation [LH/RH/Off]. |
| THEFT IND | This test is able to check security indicator lamp operation [On/Off]. |
| HEADLAMP(HI) | This test is able to check vehicle security lamp operation [On]. |

WORK SUPPORT

| Support Item | Setting | Description |
|--------------------|---------|--|
| SECURITY ALARM SET | Off | Security alarm OFF. |
| | On* | Security alarm ON. |
| THEFT ALM TRG | Off/On | The switch which triggered vehicle security alarm is recorded [On]. This mode is able to confirm and erase the record of vehicle security alarm. The trigger data can be erased by touching [CLEAR]. |
| | CLEAR | |

*: Initial setting

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000009014212

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|---------------------|--|
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |

SIGNAL BUFFER

SIGNAL BUFFER : CONSULT Function (BCM - SIGNAL BUFFER)

INFOID:000000009014213

DATA MONITOR

| Monitor Item [Unit] | Description |
|---------------------|---|
| PUSH SW [On/Off] | Indicates condition of the push-button ignition switch. |

AIR PRESSURE MONITOR

AIR PRESSURE MONITOR : CONSULT Function (BCM - AIR PRESSURE MONITOR)

INFOID:000000009014214

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs
- Check Intelligent Key relative signal strength
- Confirm vehicle Intelligent Key antenna signal strength

SELF DIAGNOSTIC RESULT

NOTE:

Before performing self diagnostic result, be sure to register the ID, or else the actual malfunction may be different from that displayed on CONSULT.

Refer to [BCS-50, "DTC Index"](#).

DATA MONITOR

| Monitor Item [Unit] | Description |
|---|---|
| AIR PRESS FL [kPa, kg/cm ² or Psi] | Indicates air pressure of front LH tire. |
| AIR PRESS FR [kPa, kg/cm ² or Psi] | Indicates air pressure of front RH tire. |
| AIR PRESS RR [kPa, kg/cm ² or Psi] | Indicates air pressure of rear RH tire. |
| AIR PRESS RL [kPa, kg/cm ² or Psi] | Indicates air pressure of rear LH tire. |
| ID REGST FL1 [Done/Yet] | Indicates ID registration status of front LH transmitter. |
| ID REGST FR1 [Done/Yet] | Indicates ID registration status of front RH transmitter. |
| ID REGST RR1 [Done/Yet] | Indicates ID registration status of rear RH transmitter. |
| ID REGST RL1 [Done/Yet] | Indicates ID registration status of rear LH transmitter. |
| WARNING LAMP [Off/On] | Indicates condition of low tire pressure warning lamp in combination meter. |
| BUZZER [Off/On] | Indicates condition of buzzer in combination meter. |

ACTIVE TEST

| Test Item | Description |
|-----------|--|
| HORN | This test is able to check horn operation [On]. |
| FLASHER | This test is able to check turn signal lamp operation [Off/LH/RH]. |

DIAGNOSIS SYSTEM (BCM)

[WITH INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Test Item | Description |
|-------------------|--|
| ID REGIST WARNING | This test is able to check ID registration warning chime operation [On/Off]. |
| WARNING LAMP | This test is able to check tire pressure warning lamp operation [On/Off]. |

WORK SUPPORT

| Support Item | Description |
|--------------|---|
| ID READ | The registered ID number is displayed. |
| ID REGIST | Refer to WT-22. "Description" . |

ECU DIAGNOSIS INFORMATION

BCM

Reference Value

INFOID:000000009014215

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs
- Check Intelligent Key relative signal strength
- Confirm vehicle Intelligent Key antenna signal strength

VALUES ON THE DIAGNOSIS TOOL

| Monitor Item | Condition | Value/Status |
|----------------|--|-------------------------------|
| AIR COND SW | A/C switch OFF | Off |
| | A/C switch ON | On |
| AIR PRESS FL | Front left tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS FR | Front right tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS RL | Rear left tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS RR | Rear right tire air pressure value | kPa, kg/cm ² , psi |
| AUTO LIGHT SW | Lighting switch OFF | Off |
| | Lighting switch AUTO | On |
| BRAKE SW 1 | When the brake pedal is released | On |
| | When the brake pedal is depressed | Off |
| BRAKE SW2 | Brake pedal released | Off |
| | Brake pedal depressed | On |
| BUZZER | Buzzer in combination meter OFF | Off |
| | Buzzer in combination meter ON | On |
| CDL LOCK SW | Door lock/unlock switch does not operate | Off |
| | Press door lock/unlock switch to the LOCK side | On |
| CDL UNLOCK SW | Door lock/unlock switch does not operate | Off |
| | Press door lock/unlock switch to the UNLOCK side | On |
| CONFIRM ID ALL | The key ID does not match any key ID registered to BCM. | Yet |
| | The key ID matches any key ID registered to BCM. | DONE |
| CONFIRM ID4 | The key ID does not match the fourth key ID registered to BCM. | Yet |
| | The key ID matches the fourth key ID registered to BCM. | DONE |
| CONFIRM ID3 | The key ID does not match the third key ID registered to BCM. | Yet |
| | The key ID matches the third key ID registered to BCM. | DONE |
| CONFIRM ID2 | The key ID does not match the second key ID registered to BCM. | Yet |
| | The key ID matches the second key ID registered to BCM. | DONE |
| CONFIRM ID1 | The key ID does not match the first key ID registered to BCM. | Yet |
| | The key ID matches the first key ID registered to BCM. | DONE |
| DETE SW -IPDM | When selector lever is in P position | Off |
| | When selector lever is in any position other than P | On |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| Monitor Item | Condition | Value/Status |
|----------------|---|--------------|
| DETE/CANCL SW | When selector lever is in P position | Off |
| | When selector lever is in any position other than P | On |
| DOOR STAT-AS | Passenger door LOCK status | LOCK |
| | Passenger door UNLOCK status | UNLK |
| | Wait with selective UNLOCK operation (5 seconds) | READY |
| DOOR STAT-DR | Driver door LOCK status | LOCK |
| | Driver door UNLOCK status | UNLK |
| | Wait with selective UNLOCK operation (5 seconds) | READY |
| DOOR SW-AS | Front door RH closed | Off |
| | Front door RH opened | On |
| DOOR SW-BK | Trunk closed | Off |
| | Trunk opened | On |
| DOOR SW-DR | Front door LH closed | Off |
| | Front door LH opened | On |
| DOOR SW-RL | Rear door LH closed | Off |
| | Rear door LH opened | On |
| DOOR SW-RR | Rear door RH closed | Off |
| | Rear door RH opened | On |
| ENGINE STATE | Engine stopped | Stop |
| | While the engine stalls | Stall |
| | At engine cranking | Crank |
| | Engine running | Run |
| FAN ON SIG | Blower motor fan switch OFF | Off |
| | Blower motor fan switch ON | On |
| FR FOG SW | Front fog lamp switch OFF | Off |
| | Front fog lamp switch ON | On |
| FR WASHER SW | Front washer switch OFF | Off |
| | Front washer switch ON | On |
| FR WIPER LOW | Front wiper switch OFF | Off |
| | Front wiper switch LO | On |
| FR WIPER HI | Front wiper switch OFF | Off |
| | Front wiper switch HI | On |
| FR WIPER INT | Front wiper switch OFF | Off |
| | Front wiper switch INT | On |
| FR WIPER STOP | Any position other than front wiper stop position | Off |
| | Front wiper stop position | On |
| HAZARD SW | When hazard switch is not pressed | Off |
| | When hazard switch is pressed | On |
| HEAD LAMP SW 1 | Headlamp switch OFF | Off |
| | Headlamp switch 1st | On |
| HEAD LAMP SW 2 | Headlamp switch OFF | Off |
| | Headlamp switch 1st | On |
| HI BEAM SW | High beam switch OFF | Off |
| | High beam switch HI | On |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| Monitor Item | Condition | Value/Status | |
|-----------------|---|--------------|---|
| ID OK FLAG | Ignition switch ACC or ON | Reset | A |
| | Ignition switch OFF | Set | |
| ID REGST FL1 | ID registration of front left tire incomplete | YET | B |
| | ID registration of front left tire complete | DONE | |
| ID REGST FR1 | ID registration of front right tire incomplete | YET | C |
| | ID registration of front right tire complete | DONE | |
| ID REGST RL1 | ID registration of rear left tire incomplete | YET | D |
| | ID registration of rear left tire complete | DONE | |
| ID REGST RR1 | ID registration of rear right tire incomplete | YET | E |
| | ID registration of rear right tire complete | DONE | |
| IGN RLY1 F/B | Ignition switch OFF or ACC | Off | F |
| | Ignition switch ON | On | |
| INT VOLUME | Wiper intermittent dial is in a dial position 1 - 7 | 1 - 7 | F |
| KEY CYL LK-SW | Door key cylinder LOCK position | Off | G |
| | Door key cylinder other than LOCK position | On | |
| KEY CYL UN-SW | Door key cylinder UNLOCK position | Off | H |
| | Door key cylinder other than UNLOCK position | On | |
| OPTI SEN (DTCT) | Bright outside of the vehicle | Close to 5V | I |
| | Dark outside of the vehicle | Close to 0V | |
| OPTI SEN (FILT) | Bright outside of the vehicle | Close to 5V | J |
| | Dark outside of the vehicle | Close to 0V | |
| PASSING SW | Other than lighting switch PASS | Off | K |
| | Lighting switch PASS | On | |
| PRMT ENG STRT | When the engine start is prohibited | Reset | L |
| | When the engine start is permitted | Set | |
| PRMT RKE STRT | When the engine start is prohibited | Reset | N |
| | When the engine start is permitted | Set | |
| PUSH SW | Return ignition switch to LOCK position | Off | O |
| | Press ignition switch | On | |
| PUSH SW-IPDM | When engine switch (push switch) is not pressed | Off | P |
| | When engine switch (push switch) is pressed | On | |
| REAR DEF SW | Rear window defogger switch OFF | Off | |
| | Rear window defogger switch ON | On | |
| REQ SW-AS | When passenger door request switch is not pressed | Off | |
| | When passenger door request switch is pressed | On | |
| REQ SW -BD/TR | When trunk open switch is not pressed | Off | |
| | When trunk open switch is pressed | On | |
| REQ SW-DR | When driver door request switch is not pressed | Off | |
| | When driver door request switch is pressed | On | |
| RKE-LOCK | When LOCK button of Intelligent Key is not pressed | Off | |
| | When LOCK button of Intelligent Key is pressed | On | |
| RKE-MODE CHG | When LOCK/UNLOCK button of Intelligent Key is not pressed and held simultaneously | Off | |
| | When LOCK/UNLOCK button of Intelligent Key is pressed and held simultaneously | On | |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]


| Monitor Item | Condition | Value/Status |
|---------------|--|--------------|
| RKE OPE COUN1 | Operation frequency of Intelligent Key | 0-19 |
| RKE OPE COUN2 | Operation frequency of Intelligent Key | 0-19 |
| RKE-PANIC | When PANIC button of Intelligent Key is not pressed | Off |
| | When PANIC button of Intelligent Key is pressed | On |
| RKE-TR/BD | When TRUNK OPEN button of Intelligent Key is not pressed | Off |
| | When TRUNK OPEN button of Intelligent Key is pressed | On |
| RKE-UNLOCK | When UNLOCK button of Intelligent Key is not pressed | Off |
| | When UNLOCK button of Intelligent Key is pressed | On |
| SFT N-MET | When selector lever is in any position other than N | Off |
| | When selector lever is in N position | On |
| SFT P-MET | When selector lever is in any position other than P | Off |
| | When selector lever is in P position | On |
| SFT PN -IPDM | When selector lever is in any position other than P or N | Off |
| | When selector lever is in P or N position | On |
| SFT PN/N SW | When selector lever is in any position other than P or N | Off |
| | When selector lever is in P or N position | On |
| TAIL LAMP SW | Other than lighting switch 1ST and 2ND | Off |
| | Lighting switch 1ST or 2ND | On |
| TP 4 | The ID of fourth key is not registered to BCM | Yet |
| | The ID of fourth key is registered to BCM | DONE |
| TP 3 | The ID of third key is not registered to BCM | Yet |
| | The ID of third key is registered to BCM | DONE |
| TP 2 | The ID of second key is not registered to BCM | Yet |
| | The ID of second key is registered to BCM | DONE |
| TP 1 | The ID of first key is not registered to BCM | Yet |
| | The ID of first key is registered to BCM | DONE |
| TRNK/HAT MNTR | Trunk lid closed | Off |
| | Trunk lid opened | On |
| TR/BD OPEN SW | Trunk opener switch OFF | Off |
| | While the trunk opener switch is turned ON | On |
| TURN SIGNAL L | Turn signal switch OFF | Off |
| | Turn signal switch LH | On |
| TURN SIGNAL R | Turn signal switch OFF | Off |
| | Turn signal switch RH | On |
| UNLK SEN-DR | Driver door UNLOCK status | Off |
| | Driver door LOCK status | On |
| VEH SPEED 1 | While driving, equivalent to speedometer reading | mph, km/h |
| VEH SPEED 2 | While driving, equivalent to speedometer reading | mph, km/h |
| WARNING LAMP | Low tire pressure warning lamp in combination meter OFF | Off |
| | Low tire pressure warning lamp in combination meter ON | On |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

TERMINAL LAYOUT



A
B
C
D
E
F
G
H
I
J
K
L

PHYSICAL VALUES

BCS






| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|----------------|------------------|--------------------|--------------------|
| + | - | Signal name | Input/ Output | | |
| 2 (L) | Ground | INPUT 5 signal | Input | Combination switch | 0 V |
| | | | | OFF | |
| | | | | TURN RH | |
| | | | | HEADLAMP 1 | |
| | | | | HI BEAM | |
| | | | | TAIL LAMP | 1.0 V |

N
O
P

BCM

< ECU DIAGNOSIS INFORMATION >





[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|----------------------------------|------------------|------------------------|---|---|
| + | - | Signal name | Input/ Output | | | |
| 3 (GR) | Ground | INPUT 4 signal | Input | Combination switch | OFF | 0 V |
| | | | | | TURN LH |  |
| | | | | | PASSING | |
| | | | | | HEADLAMP 2 | |
| | | | | | FR FOG | |
| 4 (BR) | Ground | INPUT 3 signal | Input | Combination switch | OFF | 0 V |
| | | | | | FR WIPER LO |  |
| | | | | | FR WIPER INT (any intermittent position) | |
| | | | | | AUTO LIGHT | |
| 5 (O) | Ground | INPUT 2 signal | Input | Combination switch | OFF | 0 V |
| | | | | | FR WASHER |  |
| | | | | | Wiper intermittent dial 1 | |
| | | | | | Wiper intermittent dial 5 | |
| | | | | | Wiper intermittent dial 6 | |
| 6 (W) | Ground | INPUT 1 signal | Input | Combination switch | OFF | 0 V |
| | | | | | FR WIPER HI |  |
| | | | | | Wiper intermittent dial 1 | |
| | | | | | Wiper intermittent dial 2 | |
| | | | | | Wiper intermittent dial 3 | |
| | | | | | Wiper intermittent dial 6 | |
| | | | | | Wiper intermittent dial 7 | |
| 7 (L) | Ground | Key cylinder unlock sw signal | Input | Key cylinder switch | N position |  |
| | | | | | UNLOCK position | 0 V |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|-------------------------------|--------|--------------------------------|----------------------------|--|
| | | | | | | |
| + | - | | | | | |
| 8 (V) | Ground | Key cylinder lock sw signal | Input | Key cylinder switch | N position |  <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p> |
| | | | | | LOCK position | 0 V |
| 9 (R) | Ground | Stop lamp switch 1 | Input | Stop lamp switch | OFF (Brake pedal released) | 0 V |
| | | | | | ON (Brake pedal depressed) | Battery voltage |
| 12 (GR) | Ground | Central door lock sw signal | Input | Door lock and unlock switch | NEUTRAL position |  <p style="text-align: right; font-size: small;">JPMIA0012GB</p> <p style="text-align: center;">1.0 - 1.5 V</p> |
| | | | | | LOCK position | 0 V |
| 13 (BR) | Ground | Central door unlock sw signal | Input | Door lock and unlock switch | NEUTRAL position |  <p style="text-align: right; font-size: small;">JPMIA0012GB</p> <p style="text-align: center;">1.0 - 1.5 V</p> |
| | | | | | UNLOCK position | 0 V |
| 14 (SB) | Ground | Optical sensor | Input | Push-button ignition switch ON | Daylight | 5 V |
| | | | | | Night | 0 V |
| 15 (W) | Ground | Rear defogger switch signal | Input | Rear window defogger switch | Released |  <p style="text-align: right; font-size: small;">JPMIA0012GB</p> <p style="text-align: center;">1.0 - 1.5 V</p> |
| | | | | | Depressed | 0 V |
| 16 (O) | — | MR output | — | — | — | — |
| 17 (Y) | Ground | Sensor power supply | Output | Push-button ignition switch | OFF | 0 V |
| | | | | | ON | 5.5 V |
| 18 (V) | Ground | Keyless tuner ground | Input | Push-button ignition switch | ON | 0 V |







A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >





[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|------------------------------------|--|---|
| + | - | Signal name | Input/ Output | | | |
| 19 (BR) | Ground | Keyless tuner power supply | Output | Push-button ignition switch | OFF |  <p style="text-align: right; font-size: small;">JMKIA3838GB</p> |
| | | | | | ACC or ON | 5 V |
| 20 (LG) | Ground | Keyless tuner signal | Input | Push-button ignition switch OFF | Waiting |  <p style="text-align: right; font-size: small;">JMKIA3838GB</p> |
| | | | | | When operating either button on Intelligent Key |  <p style="text-align: right; font-size: small;">JMKIA3841GB</p> |
| 21 (P) | Ground | Immobilizer one way communication (CLOCK) signal | Input/ Output | Intelligent Key battery is removed | Brake pedal depressed NOTE: Waveform varies each time when brake pedal is depressed |  <p style="text-align: right; font-size: small;">JMKIA6232JP</p> |
| | | | | | Brake pedal released | Battery voltage |
| 22 (W) | Ground | Keyless tuner RSSI signal | Input | Push-button ignition switch OFF | Waiting |  <p style="text-align: right; font-size: small;">JMKIA5952GB</p> |
| | | | | | When pressing and holding either button on Intelligent Key |  <p style="text-align: right; font-size: small;">JMKIA5953GB</p> |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|--|---|---|
| + | - | Signal name | Input/ Output | | | |
| 23 (Y) | Ground | Security indicator output | Output | Security indica- tor lamp | ON | 0 – 0.5 V |
| | | | | Blinking (push-button igni- tion switch OFF) |  <p style="text-align: right; font-size: small;">12.0 V</p> | |
| 24 (SB) | Ground | Dongle link (SERI- AL) | Input/ Output | Push-button igni- tion switch | OFF | Battery voltage |
| | | | | OFF | 5 V | |
| 25 (LG) | Ground | Immobilizer two way communication sig- nal | Input/ Output | During waiting | Brake pedal depressed NOTE: Waveform varies each time when brake pedal is depressed |  <p style="text-align: right; font-size: small;">Battery voltage</p> |
| | | | | Brake pedal released | Battery voltage | |
| 27 (Y) | Ground | Air con sw signal | Input | Push-button igni- tion switch ON and blower fan switch ON | A/C switch OFF | Battery voltage |
| | | | | A/C switch ON | 0 V | |
| 28 (LG) | Ground | Blower fan sw signal | Input | Fan switch | OFF | 0 V |
| | | | | ON |  <p style="text-align: right; font-size: small;">7.0 - 8.0 V</p> | |
| 29 (SB) | Ground | Hazard sw signal | Input | Hazard switch | OFF | Battery voltage |
| | | | | ON | 0 – 1.5 V | |
| 30 (L) | Ground | Trunk lid opener switch | Input | Trunk lid opener switch | Depressed | 0 V |
| | | | | Released |  <p style="text-align: right; font-size: small;">1.0 - 1.5 V</p> | |






A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >







[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------------------------------|------------------|--------------------------------|--|--|
| + | - | Signal name | Input/ Output | | | |
| 31 (R) | Ground | Driver door unlock sensor signal | Input | Driver door un- lock sensor | OFF (LOCK) |  7.0 - 8.0 V |
| | | | | ON (UNLOCK) | 0 V | |
| 32 (LG) | Ground | OUTPUT 5 | Output | Combination switch | OFF |  7.0 - 8.0 V |
| | | | | FR FOG |  1.0 V | |
| | | | | Wiper intermittent dial 1 | | |
| | | | | Wiper intermittent dial 2 | | |
| | | | | Wiper intermittent dial 6 | | |
| Wiper intermittent dial 7 | | | | | | |
| 33 (Y) | Ground | OUTPUT 4 | Output | Combination switch | OFF |  7.0 - 8.0 V |
| | | | | AUTO LIGHT |  1.2 V | |
| | | | | TAIL LAMP | | |
| | | | | Wiper intermittent dial 1 | | |
| | | | | Wiper intermittent dial 5 | | |
| Wiper intermittent dial 6 | | | | | | |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-------------|------------------|-----------------------|---|--|
| + | - | Signal name | Input/ Output | | | |
| 34 (V) | Ground | OUTPUT 3 | Output | Combination switch | OFF |  <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p> |
| | | | | | HEADLAMP 2 |  <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p> |
| | | | | | HI BEAM | |
| | | | | | Wiper intermittent dial 1 | |
| | | | | | Wiper intermittent dial 2 | |
| Wiper intermittent dial 3 | | | | | | |
| 35 (R) | Ground | OUTPUT 2 | Output | Combination switch | OFF |  <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p> |
| | | | | | HEADLAMP 1 |  <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p> |
| | | | | | PASSING | |
| | | | | | FR WIPER HI | |
| | | | | | FR WIPER INT (any intermittent position) | |
| 36 (SB) | Ground | OUTPUT 1 | Output | Combination switch | OFF |  <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p> |
| | | | | | TURN RH |  <p style="text-align: right; font-size: small;">PKIB4958J</p> <p style="text-align: center;">1.2 V</p> |
| | | | | | TURN LH | |
| | | | | | FR WIPER LO | |
| | | | | | FR WASHER | |





A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >







[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|--|---|---|
| + | - | Signal name | Input/ Output | | | |
| 37 ¹ (P) | Ground | Park position switch signal | Input | Selector lever | P (Park) position | 0 – 1.5 V |
| | | | | | Any position other than P (Park) | Battery voltage |
| 37 ² (P) | Ground | Clutch cancel switch signal | Input | Clutch pedal position switch | OFF (clutch pedal de- pressed) | 0 – 1.5 V |
| | | | | | ON (clutch pedal re- leased) | Battery voltage |
| 38 (LG) | Ground | Keyless intelligent tuner signal | Input | Push-button ig- nition switch | OFF or ACC | 0 – 0.5 V |
| | | | | | ON | Battery voltage |
| 39 (L) | Ground | CAN-H | Input/ Output | — | — | — |
| 40 (P) | Ground | CAN-L | Input/ Output | — | — | — |
| 41 (W) | Ground | Push-button ignition switch illumination power supply | Output | Push-button ig- nition switch il- lumination | ON | Battery voltage |
| | | | | | OFF | 0 – 1.5 V |
| 42 (BR) | Ground | Inside key antenna (trunk room) - | Output | Push-button ig- nition switch ON | Intelligent Key not in an- tenna detection area (Approx. 2 m) |  |
| | | | | | Intelligent Key in antenna detection area (80 cm or less) |  |
| 43 (Y) | Ground | Inside key antenna (trunk room) + | Output | Push-button ig- nition switch ON | Intelligent Key not in an- tenna detection area (Approx. 2 m) |  |
| | | | | | Intelligent Key in antenna detection area (80 cm or less) |  |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|---|------------------|-------------------------------------|---|---|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 44 (R) | Ground | Inside key antenna (console) - | Output | Push-button ig- nition switch ON | Intelligent Key not in an- tenna detection area (Approx. 2 m) |  |
| | | | | | Intelligent Key in antenna detection area (80 cm or less) |  |
| 45 (G) | Ground | Inside key antenna (console) + | Output | Push-button ig- nition switch ON | Intelligent Key not in an- tenna detection area (Approx. 2 m) |  |
| | | | | | Intelligent Key in antenna detection area (80 cm or less) |  |
| 46 (GR) | Ground | Inside key antenna (instrument center) - | Output | Push-button ig- nition switch ON | Intelligent Key not in an- tenna detection area (Approx. 2 m) |  |
| | | | | | Intelligent Key in antenna detection area (80 cm or less) |  |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|---|------------------|--|---|
| + | - | Signal name | Input/ Output | | |
| 47 (BR) | Ground | Inside key antenna (instrument center) + | Output | Push-button ignition switch ON | <p style="text-align: right; font-size: small;">JMKIA5951GB</p> |
| | | | | Intelligent Key in antenna detection area (80 cm or less) | <p style="text-align: right; font-size: small;">JMKIA3839GB</p> |
| 48 (R) | Ground | Outside key antenna (rear bumper) - | Output | When the trunk lid opener switch is operated with push-button ignition switch ON | <p style="text-align: right; font-size: small;">JMKIA5954GB</p> |
| | | | | Intelligent Key in antenna detection area (80 cm or less) | <p style="text-align: right; font-size: small;">JMKIA5955GB</p> |
| 49 (W) | Ground | Outside key antenna (rear bumper) + | Output | Push-button ignition switch ON Trunk lid opener switch pressed | <p style="text-align: right; font-size: small;">JMKIA5954GB</p> |
| | | | | Intelligent Key in antenna detection area (80 cm or less) | <p style="text-align: right; font-size: small;">JMKIA5955GB</p> |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|---------------------|------------------|---|--|
| + | - | Signal name | Input/ Output | | |
| 50 (Y) | Ground | Door antenna (AS) - | Output | Push-button ignition switch ON Passenger door request switch pressed | Intelligent Key not in antenna detection area (Approx. 2 m) |
| | | | | Intelligent Key in antenna detection area (80 cm or less) | |
| 51 (BR) | Ground | Door antenna (AS) + | Output | Push-button ignition switch ON Passenger door request switch pressed | Intelligent Key not in antenna detection area (Approx. 2 m) |
| | | | | Intelligent Key in antenna detection area (80 cm or less) | |
| 52 (LG) | Ground | Door antenna (DR) - | Output | Push-button ignition switch ON Driver door request switch pressed | Intelligent Key not in antenna detection area (Approx. 2 m) |
| | | | | Intelligent Key in antenna detection area (80 cm or less) | |



A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >



[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|--|--|---|
| + | - | Signal name | Input/ Output | | | |
| 53 (P) | Ground | Door antenna (DR) + | Output | Push-button ignition switch ON Driver door request switch pressed | Intelligent Key not in antenna detection area (Approx. 2 m) |  <p style="text-align: right; font-size: small;">JMKIA5954GB</p> |
| | | | | | Intelligent Key in antenna detection area (80 cm or less) |  <p style="text-align: right; font-size: small;">JMKIA5955GB</p> |
| 55 (LG) | Ground | Engine start sw | Input | Push-button ignition switch | START pressed | 0 – 1.5 V |
| | | | | | Not pressed | Battery voltage |
| 56 (G) | Ground | Request sw (DR) signal | Input | Driver door request switch | ON (Pressed) | 0 – 1.5 V |
| | | | | | OFF (Not pressed) | Battery voltage |
| 57 (V) | Ground | Auto retractable mirror output | Output | Ignition switch OFF | Within 6 seconds of doors locked with LOCK button of Intelligent Key or request switch | 0 V |
| | | | | | 6 seconds after doors are locked | Battery voltage |
| 65 (P) | Ground | Blower relay control | Output | Push-button ignition switch | OFF or ACC | 0 – 0.5 V |
| | | | | | ON | Battery voltage |
| 66 (V) | Ground | Stop lamp switch 2 | Input | Push-button ignition switch | OFF | Battery voltage |
| 67 (SB) | Ground | CVT shift selector (park position switch) power supply | Output | Push-button ignition switch | ON | Battery voltage |
| 69 (L) | Ground | Shift N/P ¹ | Input | Selector lever | P (Park) or N (Neutral) position | Battery voltage |
| | | | | | Except P (Park) or N (Neutral) position | 0 – 1.5 V |
| | | Neutral switch ² | | Control lever | NEUTRAL position | Battery voltage |
| | | | | | Except NEUTRAL position | 0 – 1.5 V |
| 70 (O) | Ground | Inhibit relay output ¹ | Input | Selector lever | P (Park) or N (Neutral) position | Battery voltage |
| | | | | | Except P (Park) or N (Neutral) position | 0 – 0.5 V |
| | | Clutch interlock switch ² | | Clutch pedal | Depressed | 0 – 0.5 V |
| | | | | | Released | Battery voltage |
| 71 (GR) | Ground | Request sw (AS) signal | Input | Passenger door request switch | ON (Pressed) | 0 – 1.5 V |
| | | | | | OFF (Not pressed) | Battery voltage |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|---|------------------|--|---|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 72 (R) | Ground | Ignition relay (F/B) control | Output | Push-button ignition switch | OFF or ACC | 0 – 0.5 V |
| | | | | | ON | Battery voltage |
| 73 (V) | Ground | Ignition relay (IPDM E/R) control | Output | Push-button ignition switch | OFF or ACC | Battery voltage |
| | | | | | ON | 0 – 0.5 V |
| 74 (SB) | Ground | Starter relay control | Output | Push-button ignition switch ON | Selector lever in P (Park) or N (Neutral) position | Battery voltage |
| | | | | | Selector lever not in P (Park) or N (Neutral) position | 0 – 0.5 V |
| 75 (W) | Ground | Accessory relay control | Output | Ignition Push-button switch | OFF | 0 – 0.5 V |
| | | | | | ACC or ON | Battery voltage |
| 78 (W) | Ground | Intelligent Key warning buzzer | Output | Intelligent Key warning buzzer | Sounding | 0 – 1.5 V |
| | | | | | Not sounding | Battery voltage |
| 79 (R) | Ground | Push-button ignition switch illumination lamp | Output | Push-button ignition switch illumination | ON | 5.5 V |
| | | | | | OFF | 0 – 1.5 V |
| 80 (V) | Ground | ACC/ON indicator lamp | Output | Push-button ignition switch | OFF | Battery voltage |
| | | | | | ACC or ON | 0 – 1.5 V |
| 81 (G) | Ground | Starter output enable input | Input | Push-button ignition switch ON | Engine stopped, selector lever in P (Park) position | 0 – 0.5 V |
| | | | | | Engine stopped, selector lever not in P (Park) position | Battery voltage |
| | | | | | Engine running | Battery voltage |
| 82 (BR) | Ground | Room lamp control | Output | Interior room lamp | OFF | Battery voltage |
| | | | | | ON | 0 – 1.0 V |
| 84 (W) | Ground | Flasher output (RIGHT) | Output | Push-button ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | | Turn signal switch RH |  <p style="text-align: center;">6.5 V</p> |
| 85 (Y) | Ground | Flasher output (LEFT) | Output | Push-button ignition switch ON | Turn signal switch OFF | 0 V |
| | | | | | Turn signal switch LH |  <p style="text-align: center;">6.5 V</p> |
| 86 (SB) | Ground | Door unlock output (AS) | Output | Front RH door | UNLOCK (Actuator is activated) | Battery voltage |
| | | | | | Actuator is not activated | 0 V |




A
B
C
D
E
F
G
H
I
J
K
L
N
O
P



BCM

< ECU DIAGNOSIS INFORMATION >



[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|-------------------------------------|------------------|-----------------------------|--------------------------------|--|
| + | - | Signal name | Input/ Output | | | |
| 88 (O) | Ground | Battery power supply | Input | Push-button ignition switch | OFF | Battery voltage |
| 89 (P) | Ground | Battery saver output | Output | Interior room lamp | Battery saver timed out | 0 V |
| | | | | | Except battery saver timed out | Battery voltage |
| 90 (Y) | Ground | Battery power supply | Input | Push-button ignition switch | OFF | Battery voltage |
| 91 (G) | Ground | Power window power supply (BATT) | Output | Push-button ignition switch | OFF | Battery voltage |
| 92 (L) | Ground | Power window power supply (RAP/IGN) | Output | Push-button ignition switch | ON | Battery voltage |
| 93 (B) | Ground | Ground | Output | Push-button ignition switch | ON | 0 V |
| 94 (SB) | Ground | Door unlock output (DR) | Output | Front LH door | UNLOCK (Actuator is activated) | Battery voltage |
| | | | | | Actuator is not activated | 0 V |
| 95 (O) | Ground | Door lock output | Output | All doors | LOCK (Actuator is activated) | Battery voltage |
| | | | | | Actuator is not activated | 0 V |
| 96 (LG) | Ground | Luggage lamp control | Output | Trunk lid closed | Trunk room lamp OFF | Battery voltage |
| | | | | Trunk lid open | Trunk room lamp ON | 0 - 1 V |
| 97 (GR) | Ground | Door switch (RL) signal | Input | Rear door switch LH | OFF (rear LH door closed) |  7.0 - 8.0 V |
| | | | | | ON (rear LH door open) | 0 V |
| 98 (Y) | Ground | Door switch (DR) signal | Input | Front door switch LH | OFF (front LH door closed) |  7.0 - 8.0 V |
| | | | | | ON (front LH door open) | 0 V |
| 99 (P) | Ground | Door switch (RR) signal | Input | Rear door switch RH | OFF (rear RH door closed) |  7.0 - 8.0 V |
| | | | | | ON (rear RH door open) | 0 V |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|----------------------------------|------------------|---|-------------------------------------|--|
| + | - | Signal name | Input/ Output | | | |
| 100 (R) | Ground | Door switch (AS) signal | Input | Front door switch RH | OFF (front RH door closed) |  7.0 - 8.0 V |
| | | | | ON (front RH door open) | 0 V | |
| 103 (V) | Ground | Trunk room lamp switch signal | Input | Trunk room lamp switch | OFF (trunk lid closed) |  7.0 - 8.0 V |
| | | | | ON (trunk lid open) | 0 V | |
| 105 (G) | Ground | Door unlock output (RR, RL) | Output | Rear doors | UNLOCK (Actuator is acti- vated) | Battery voltage |
| | | | | Actuator is not activated | 0 V | |
| 107 (GR) | Ground | Trunk open output | Output | Trunk opener request switch released | Trunk lid actuator idle | 0 V |
| | | | | Trunk opener request switch depressed | Trunk lid actuator activat- ed | Battery voltage |
| 109 (SB) | Ground | Request sw (trunk) signal | Input | Trunk opener request switch | Depressed | 0 - 1.5 V |
| | | | | Released | Battery voltage | |

¹: with CVT

²: with M/T

Fail-safe

INFOID:000000009014216

BCS

BCM performs fail-safe control when the following DTCs are detected.

| CONSULT Display | Fail-safe | Cancellation |
|---------------------------|-------------------------|---|
| B2192: ID DISCORD BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2193: CHAIN OF BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2195: ANTI SCANNING | Inhibit engine cranking | Ignition switch ON → OFF |
| B2196: DONGLE NG | Inhibit engine cranking | Erase DTC |
| B2198: NATS ANTENNA AMP | Inhibit engine cranking | Erase DTC |
| B2557: VEHICLE SPEED | — | When the following CAN signal status (vehicle speed signal) becomes consistent <ul style="list-style-type: none"> • Vehicle speed signal (ABS) • Vehicle speed signal (Meter) |
| B2601: SHIFT P SIGNAL | — | 500 ms after the following signal reception status becomes consistent <ul style="list-style-type: none"> • Park position switch signal • P range signal (CAN) |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| CONSULT Display | Fail-safe | Cancellation |
|---------------------------|-------------------------|---|
| B2602: SHIFT P DIAG | — | 5 seconds after the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch is in the ON position • Park position switch signal: P position (push selector button) or except P position (9 – 16 V) • Vehicle speed: 4 km/h (2.5 MPH) or more |
| B2603: SHIFT POSITION | — | 500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Park position switch signal: P position (push selector button) or except P position (9 – 16 V) - P/N position signal: Except P and N positions (0 – 1.5 V) • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - Park position switch signal: P position (release selector button) (0 – 1.5 V) - P/N position signal: P or N positions (9 – 16 V) |
| B2604: SHIFT PN DIAG CAN | — | 500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - P/N position signal: P or N position (9 – 16 V) - Shift position signal (CAN): P or N position • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - P/N position signal: Except P and N positions (0 – 1.5 V) - Shift position signal (CAN): Except P and N position |
| B2605: SHIFT PN DIAG IPDM | — | 500 ms after any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Ignition switch is in the ON position - P/N position signal: Except P and N positions (0 – 1.5 V) • Status 2 <ul style="list-style-type: none"> - Ignition switch is in the ON position - P/N position signal: P or N position (9 – 16 V) |
| B2608: STARTER RELAY | Inhibit engine cranking | 500 ms after the following signal communication status becomes consistent <ul style="list-style-type: none"> • Starter motor relay control signal • Starter relay status signal (CAN) |
| B260F: ECM CAN COMM | Inhibit engine cranking | When any of the following conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch changes to ACC • Receives engine status signal (CAN) |
| B261F: ASCD CNCL/CLTCH SW | — | BCM detects clutch pedal position switch signal (CAN) status [ON (Clutch pedal is released)] |
| B2620: NEUTRAL SW | — | BCM detects neutral switch signal status [OFF (9 – 16 V: Control lever except NEUTRAL position)] |
| B26E8: CLUTCH SW | — | When any of the following BCM recognition conditions are fulfilled <ul style="list-style-type: none"> • Status 1 <ul style="list-style-type: none"> - Clutch pedal position switch signal: ON (9 – 16 V: Clutch pedal is released) - Clutch interlock switch signal: OFF (0 – 0.5 V: Clutch pedal is released) • Status 2 <ul style="list-style-type: none"> - Clutch pedal position switch signal: OFF (0 – 1.5 V: Clutch pedal is depressed) - Clutch interlock switch signal: ON (9 – 16 V: Clutch pedal is depressed) |
| B26F1: IGN RELAY OFF | Inhibit engine cranking | When the following conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch ON signal (CAN: Transmitted from BCM): ON • Ignition switch ON signal (CAN: Transmitted from IPDM E/R): ON |
| B26F2: IGN RELAY ON | Inhibit engine cranking | When the following conditions are fulfilled <ul style="list-style-type: none"> • Ignition switch ON signal (CAN: Transmitted from BCM): OFF • Ignition switch ON signal (CAN: Transmitted from IPDM E/R): OFF |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| CONSULT Display | Fail-safe | Cancellation |
|---------------------------|---|--|
| B26F3: START CONT RLY ON | Inhibit engine cranking | When the following conditions are fulfilled <ul style="list-style-type: none"> • Starter control relay signal (CAN: Transmitted from BCM): OFF • Starter control relay signal (CAN: Transmitted from IPDM E/R): OFF |
| B26F4: START CONT RLY OFF | Inhibit engine cranking | When the following conditions are fulfilled <ul style="list-style-type: none"> • Starter control relay signal (CAN: Transmitted from BCM): ON • Starter control relay signal (CAN: Transmitted from IPDM E/R): ON |
| B26F7: BCM | Inhibit engine cranking by Intelligent Key system | When room antenna and luggage room antenna functions normally |
| U0415: VDC CAN CIR2 | — | When vehicle speed signal (Meter) (CAN) is received normally |

DTC Inspection Priority Chart

INFOID:000000009014217

If more than one DTC is displayed at the same time, perform inspections based on the following priority chart.

| Priority | DTC |
|----------|---|
| 1 | B2562: LOW VOLTAGE |
| 2 | <ul style="list-style-type: none"> • U1000: CAN COMM CIRCUIT • U1010: CONTROL UNIT (CAN) |
| 3 | <ul style="list-style-type: none"> • B2192: ID DISCORD BCM-ECM • B2193: CHAIN OF BCM-ECM • B2195: ANTI SCANNING • B2196: DONGLE NG • B2198: NATS ANTENNA AMP |
| 4 | <ul style="list-style-type: none"> • B2553: IGN POWER CIRCUIT • B2555: STOP LAMP CIRCUIT • B2556: ENG START SW • B2557: VEHICLE SPEED • B2601: SHIFT P SIGNAL • B2602: SHIFT P DIAG • B2603: SHIFT POSITION • B2604: SHIFT PN DIAG CAN • B2605: SHIFT PN DIAG IPDM • B2608: STARTER RELAY • B260F: ECM CAN COMM • B2614: ACC RELAY REQ FB • B2615: IGN RELAY3 REQ FB • B2616: IGN RELAY2 REQ FB • B2618: IGN RELAY1 REQ FB • B261A: ENGINE SW • B261F: ASCD CNCL/CLTCH SW • B2620: NEUTRAL SW • B26E8: CLUTCH SW • B26F1: IGN RELAY OFF • B26F2: IGN RELAY ON • B26F3: START CONT RLY ON • B26F4: START CONT RLY OFF • B26F6: BCM • B26F7: BCM • B26FC: KEY REGISTRATION • U0415: VDC CAN CIR2 |
| 5 | <ul style="list-style-type: none"> • B2621: INSIDE ANTENNA 1 • B2622: INSIDE ANTENNA 2 • B2623: INSIDE ANTENNA 3 |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| Priority | DTC |
|----------|---|
| 6 | <ul style="list-style-type: none"> • B2626: OUTSIDE 1 ANTENNA • B2627: OUTSIDE 2 ANTENNA • B2628: OUTSIDE 3 ANTENNA |
| 7 | <ul style="list-style-type: none"> • C1704: LOW PRESSURE FL • C1705: LOW PRESSURE FR • C1706: LOW PRESSURE RR • C1707: LOW PRESSURE RL • C1708: [NO DATA] FL • C1709: [NO DATA] FR • C1710: [NO DATA] RR • C1711: [NO DATA] RL • C1716: [PRESS DATA ERR] FL • C1717: [PRESS DATA ERR] FR • C1718: [PRESS DATA ERR] RR • C1719: [PRESS DATA ERR] RL • C1729: VHCL SPEED SIG ERR |

DTC Index

INFOID:000000009014218

NOTE:

The details of time display are as follows.

- CRNT: A malfunction is detected now.
 - PAST: A malfunction was detected in the past.
- IGN counter is displayed on Freeze Frame Data.

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition | Intelligent Key warning lamp ON | Low tire pressure warning lamp ON | Reference page |
|--|-----------|--|---------------------------------------|--|-------------------------|
| No DTC is detected. further testing may be required. | — | — | — | — | — |
| U1000: CAN COMM CIRCUIT | — | — | — | — | BCS-64 |
| U1010: CONTROL UNIT (CAN) | — | — | — | — | BCS-65 |
| U0415: VDC CAN CIR2 | × | — | × | — | BCS-66 |
| B209F: STR CUT OFF OPEN | × | — | — | — | SEC-120 |
| B20A0: STR CUT OFF SHORT | × | — | — | — | SEC-122 |
| B2192: ID DISCORD BCM-ECM | × | — | — | — | SEC-69 |
| B2193: CHAIN OF BCM-ECM | × | — | — | — | SEC-70 |
| B2195: ANTI SCANNING | × | — | — | — | SEC-71 |
| B2196: DONGLE NG | × | — | — | — | SEC-72 |
| B2198: NATS ANTENNA AMP | × | — | — | — | SEC-74 |
| B2555: STOP LAMP CIRCUIT | — | × | × | — | SEC-77 |
| B2556: ENG START SW | — | × | × | — | SEC-80 |
| B2557: VEHICLE SPEED | × | × | × | — | SEC-82 |
| B2562: LOW VOLTAGE | — | × | — | — | BCS-67 |
| B2601: SHIFT P SIGNAL | × | × | × | — | SEC-83 |
| B2602: SHIFT P DIAG | × | × | × | — | SEC-85 |
| B2603: SHIFT POSITION | × | × | × | — | SEC-88 |
| B2604: SHIFT PN DIAG CAN | × | × | × | — | SEC-92 |
| B2605: SHIFT PN DIAG IPDM | × | × | × | — | SEC-95 |
| B2608: STARTER RELAY | × | × | × | — | SEC-97 |
| B260F: ECM CAN COMM | × | × | × | — | SEC-99 |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITH INTELLIGENT KEY SYSTEM]

| CONSULT display | Fail-safe | Freeze Frame Data •Vehicle Speed •Odo/Trip Meter •Vehicle Condition | Intelligent Key warning lamp ON | Low tire pressure warning lamp ON | Reference page |
|----------------------------|-----------|--|---------------------------------------|--|-------------------------|
| B2614: ACC RELAY REQ FB | — | × | × | — | PCS-82 |
| B2615: IGN RELAY3 REQ FB | — | × | × | — | PCS-84 |
| B2616: IGN RELAY2 REQ FB | — | × | × | — | PCS-86 |
| B2618: IGN RELAY1 REQ FB | — | × | × | — | PCS-88 |
| B261A: ENGINE SW | — | × | × | — | PCS-90 |
| B261F: ASCD CANCEL SW | × | × | × | — | SEC-100 |
| B2620: NEUTRAL SW | × | × | × | — | SEC-103 |
| B2621: INSIDE ANTENNA 1 | — | × | — | — | DLK-72 |
| B2622: INSIDE ANTENNA 2 | — | × | — | — | DLK-74 |
| B2623: INSIDE ANTENNA 3 | — | × | — | — | DLK-76 |
| B2626: OUTSIDE 1 ANTENNA | — | × | — | — | DLK-78 |
| B2627: OUTSIDE 2 ANTENNA | — | × | — | — | DLK-80 |
| B2628: OUTSIDE 3 ANTENNA | — | × | — | — | DLK-82 |
| B26E8: CLUTCH SW | × | × | × | — | SEC-106 |
| B26F1: IGN RELAY OFF | × | × | × | — | PCS-92 |
| B26F2: IGN RELAY ON | × | × | × | — | PCS-94 |
| B26F3: START CONT RLY ON | × | × | × | — | SEC-110 |
| B26F4: START CONT RLY OFF | × | × | × | — | SEC-111 |
| B26F6: BCM | — | × | × | — | PCS-96 |
| B26F7: BCM | × | × | × | — | SEC-112 |
| B26F8: BCM | — | × | × | — | SEC-113 |
| B26F9: CRANK REQ CIR SHORT | — | × | × | — | SEC-114 |
| B26FA: CRANK REQ CIR OPEN | — | × | × | — | SEC-116 |
| B26FB: CLUTCH SWITCH | — | × | × | — | SEC-118 |
| B26FC: KEY REGISTRATION | — | × | × | — | SEC-119 |
| C1704: LOW PRESSURE FL | — | — | — | × | WT-25 |
| C1705: LOW PRESSURE FR | — | — | — | × | |
| C1706: LOW PRESSURE RR | — | — | — | × | |
| C1707: LOW PRESSURE RL | — | — | — | × | |
| C1708: [NO DATA] FL | — | — | — | × | WT-26 |
| C1709: [NO DATA] FR | — | — | — | × | |
| C1710: [NO DATA] RR | — | — | — | × | |
| C1711: [NO DATA] RL | — | — | — | × | |
| C1716: [PRESS DATA ERR] FL | — | — | — | × | WT-29 |
| C1717: [PRESS DATA ERR] FR | — | — | — | × | |
| C1718: [PRESS DATA ERR] RR | — | — | — | × | |
| C1719: [PRESS DATA ERR] RL | — | — | — | × | |
| C1729: VHCL SPEED SIG ERR | — | — | — | × | WT-30 |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS


WIRING DIAGRAM

BCM

Wiring Diagram


INFOID:000000009014219

BCM (BODY CONTROL MODULE) - WITH INTELLIGENT KEY SYSTEM



AAMWA0670GB

< WIRING DIAGRAM >



AAMWA0671GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCS


BCM

< WIRING DIAGRAM >


[WITH INTELLIGENT KEY SYSTEM]

(NN) : WITH NAVIGATION SYSTEM AND BOSE AUDIO SYSTEM
 (NP) : WITH NAVIGATION SYSTEM WITHOUT BOSE AUDIO SYSTEM
 (NV) : WITH NAVI

(AA) : WITH AUTO A/C
 (MA) : WITHOUT AUTO A/C
 (N) : FOR CANADA



AAMWA0672GB



A
B
C
D
E
F
G
H
I
J
K
L
BCS
N
O
P


AAMWA0673GB

BCM

< WIRING DIAGRAM >

[WITH INTELLIGENT KEY SYSTEM]


◀MU▶: WITH MOONROOF



AAMWA0674GB

< WIRING DIAGRAM >

- <FL> : WITHOUT FRONT FOG LAMPS
- <FL> : WITH FRONT FOG LAMPS
- <TM> : WITH TURN SIGNAL IN MIRROR
- <VN> : WITH VANITY LAMPS




A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

AAMWA0675GB


BCM (BODY CONTROL MODULE) CONNECTORS - WITH INTELLIGENT KEY SYSTEM

| | |
|-----------------|--------------------|
| Connector No. | M28 |
| Connector Name | COMBINATION SWITCH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | - |
| 2 | GR | - |
| 5 | BR | - |
| 6 | B | - |
| 7 | V | - |
| 8 | L | - |
| 9 | R | - |
| 10 | Y | - |
| 11 | SB | - |
| 12 | W | - |
| 13 | LG | - |
| 14 | O | - |

| | |
|-----------------|---|
| Connector No. | M63 |
| Connector Name | BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM) |
| Connector Color | WHITE |




| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--------------------------------------|
| 41 | W | HIGH SIDE ENGINE SW ILLUMINATION LED |
| 42 | BR | ROOM ANTENNA 3 - |
| 43 | Y | ROOM ANTENNA 3 + |
| 44 | R | ROOM ANTENNA 2 - |
| 45 | G | ROOM ANTENNA 2 + |
| 46 | GR | ROOM ANTENNA 1 - |
| 47 | BR | ROOM ANTENNA 1 + |
| 48 | R | BACK DOOR ANTENNA - |
| 49 | W | BACK DOOR ANTENNA + |
| 50 | Y | DOOR ANTENNA (AS) + |
| 51 | BR | DOOR ANTENNA (AS) - |
| 52 | LG | DOOR ANTENNA (DR) - |
| 53 | P | DOOR ANTENNA (DR) + |
| 54 | - | - |
| 55 | LG | ENGINE START SW |
| 56 | G | REQUEST SW (DR) |
| 57 | V | AUTO RETRACTABLE MIRROR OUTPUT |
| 58 | - | - |
| 59 | - | - |
| 60 | - | - |
| 61 | - | - |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|--|
| 62 | - | - |
| 63 | - | - |
| 64 | - | - |
| 65 | P | BLOWER FAN MOTOR RELAY OUTPUT |
| 66 | V | BRAKE SW2 |
| 67 | SB | AT DEVICE OUTPUT |
| 68 | - | - |
| 69 | L | SHIFT N, P |
| 69 | L | NEUTRAL SW |
| 70 | O | INHIBIT RLY OUTPUT |
| 70 | O | CLUTCH SW |
| 71 | GR | REQUEST SW (AS) |
| 72 | R | IGN RELAY OUTPUT 2 (ELEC) |
| 73 | V | IGN RELAY OUTPUT 1 (USM) |
| 74 | SB | STARTER RELAY OUTPUT |
| 75 | W | ACC RELAY INPUT |
| 76 | - | - |
| 77 | - | - |
| 78 | W | SMART KEYLESS BUZZER OUTPUT |
| 79 | R | LOW SIDE ENGINE START SW ILLUMINATION LED OUTPUT |
| 80 | V | POWER POSITION LED |

AAM1A1357GB

| | |
|-----------------|---|
| Connector No. | M85 |
| Connector Name | BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM) |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------------------------|
| 81 | G | STARTER OUTPUT ENABLE INPUT |
| 82 | BR | ROOM LAMP OUTPUT |
| 83 | - | - |
| 84 | W | FLASHER OUTPUT (RIGHT) |
| 85 | Y | FLASHER OUTPUT (LEFT) |
| 86 | SB | DOOR UNLOCK OUTPUT (AS) |
| 87 | - | - |
| 88 | O | BATTERY (FUSE) |
| 89 | P | BATTERY SAVER OUTPUT |
| 90 | Y | BATTERY (F/L) |
| 91 | G | POWER WINDOW POWER SUPPLY (BATTERY) |
| 92 | L | POWER WINDOW SUPPLY (RAP) |
| 93 | B | GND |
| 94 | SB | DOOR UNLOCK OUTPUT (DR) |
| 95 | O | DOOR LOCK OUTPUT (ALL) |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 18 | V | KEYLESS TUNER, AUTO LIGHT SENSOR GND |
| 19 | BR | KEYLESS TUNER POWER SUPPLY |
| 20 | LG | KEYLESS TUNER SIGNAL |
| 21 | P | IMMOBILIZER ONE WAY COMMUNICATION (CLOCK) |
| 22 | W | KEYLESS TUNER RSSI |
| 23 | Y | SECURITY INDICATOR OUTPUT |
| 24 | SB | AUDIO DONGLE LINK (SERIAL) |
| 25 | LG | IMMOBILIZER TWO WAY COMMUNICATION |
| 26 | - | - |
| 27 | Y | AIR CON SW |
| 28 | LG | BLOWER FAN SW |
| 29 | SB | HAZARD SW |
| 30 | L | TRUNK/OPENER SW |
| 31 | R | DOOR LOCK STATUS SW |
| 32 | LG | COMBINATION SW OUTPUT 5 |
| 33 | Y | COMBINATION SW OUTPUT 4 |
| 34 | V | COMBINATION SW OUTPUT 3 |
| 35 | R | COMBINATION SW OUTPUT 2 |
| 36 | SB | COMBINATION SW OUTPUT 1 |
| 37 | P | SHIFT P POSITION, PARKING POSITION SW (CVT) |
| 37 | P | ASCD CANCEL SW (CLUTCH CANCEL SW) |
| 38 | LG | INTELLIGENT TUNER |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

| | |
|-----------------|---|
| Connector No. | M84 |
| Connector Name | BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------------------------|
| 1 | - | - |
| 2 | L | COMBINATION SW INPUT 5 |
| 3 | GR | COMBINATION SW INPUT 4 |
| 4 | BR | COMBINATION SW INPUT 3 |
| 5 | O | COMBINATION SW INPUT 2 |
| 6 | W | COMBINATION SW INPUT 1 |
| 7 | L | KEY CYLINDER UNLOCK SW |
| 8 | V | KEY CYLINDER LOCK SW |
| 9 | R | BRAKE SW1 |
| 10 | - | - |
| 11 | - | - |
| 12 | GR | CENTRAL DOOR LOCK SW |
| 13 | BR | CENTRAL DOOR UNLOCK SW |
| 14 | SB | AUTO LIGHT SENSOR INPUT |
| 15 | W | REAR DEFOGGER SW |
| 16 | O | MR OUTPUT |
| 17 | Y | AUTO LIGHT SENSOR POWER SUPPLY OUTPUT |

AAM1A1358GB

A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCS

| | |
|-----------------|---|
| Connector No. | B24 |
| Connector Name | BCM (BODY CONTROL MODULE) (WITH INTELLIGENT KEY SYSTEM) |
| Connector Color | BLACK |

| | | | | | | | |
|-----|-----|-----|-----|-----|-----|----|----|
| 104 | 103 | 102 | 101 | 99 | 98 | 97 | 96 |
| 110 | 109 | 108 | 107 | 106 | 105 | | |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-----------------------------|
| 96 | LG | LUGGAGE LAMP OUTPUT |
| 97 | GR | DOOR SW (RL) |
| 98 | Y | DOOR SW (DR) |
| 99 | P | DOOR SW (RR) |
| 100 | R | DOOR SW (AS) |
| 101 | - | - |
| 102 | - | - |
| 103 | V | TRUNK / SW |
| 104 | - | - |
| 105 | G | DOOR UNLOCK OUTPUT (RR, RL) |
| 106 | - | - |
| 107 | GR | TRUNK / OPEN OUTPUT |
| 108 | - | - |
| 109 | SB | REQUEST SW (TRUNK) |
| 110 | - | - |

AAMTA1359GB

BASIC INSPECTION

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM)

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Description

INFOID:000000009014220

BEFORE REPLACEMENT

When replacing BCM, save or print current vehicle specification with CONSULT configuration before replacement.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

AFTER REPLACEMENT

CAUTION:

- When replacing BCM, you must perform "After Replace ECU" with CONSULT.
- Complete the procedure of "After Replace ECU" in order.
- If you set incorrect "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- When replacing BCM, perform the system initialization (NATS).

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Work Procedure

INFOID:000000009014221

1. SAVING VEHICLE SPECIFICATION

CONSULT

Enter "Re/Programming, Configuration" and perform "Before Replace ECU" to save or print current vehicle specification.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

>> GO TO 2.

2. REPLACE BCM

Replace BCM. Refer to [BCS-74, "Removal and Installation"](#).

>> GO TO 3.

3. WRITING VEHICLE SPECIFICATION

CONSULT

1. Enter "Re/Programming, Configuration".
2. If "Before Replace ECU" operation was performed, automatically an "Operation Log Selection" screen will be displayed. Select the applicable file from the "Saved Data List" and press "Confirm" to write vehicle specification. Refer to [BCS-61, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(BCM\) : Work Procedure"](#).
3. If "Before Replace ECU" operation was not performed, select "After Replace ECU" or "Manual Configuration" to write vehicle specification. Refer to [BCS-61, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(BCM\) : Work Procedure"](#).

>> GO TO 4.

4. INITIALIZE BCM (NATS)

Perform BCM initialization. (NATS)

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[WITH INTELLIGENT KEY SYSTEM]

>> Work End.

CONFIGURATION (BCM)

CONFIGURATION (BCM) : Description

INFOID:000000009014222

Vehicle specification needs to be written with CONSULT because it is not written after replacing BCM. Configuration has three functions as follows:

| Function | Description |
|--------------------------|---|
| "Before Replace ECU" | <ul style="list-style-type: none">• Reads the vehicle configuration of current BCM.• Saves the read vehicle configuration. |
| "After Replace ECU" | Writes the vehicle configuration with manual selection. |
| "Select Saved Data List" | Writes the vehicle configuration with saved data. |

CAUTION:

- When replacing BCM, you must perform "Select Saved Data List" or "After Replace ECU" with CONSULT.
- Complete the procedure of "Select Saved Data List" or "After Replace ECU" in order.
- If you set incorrect "Select Saved Data List" or "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Select Saved Data List" or "After Replace ECU" except for new BCM.

CONFIGURATION (BCM) : Work Procedure

INFOID:000000009014223

1. WRITING MODE SELECTION

CONSULT

Select "Reprogramming, Configuration" of BCM.

When writing saved data>>GO TO 2.

When writing manually>>GO TO 3.

2. PERFORM "SAVED DATA LIST"

CONSULT

Automatically "Operation Log Selection" window will display if "Before Replace ECU" was performed. Select applicable file from the "Save Data List" and press "Confirm".

>> Work End.

3. PERFORM "AFTER REPLACE ECU" OR "MANUAL CONFIGURATION"

CONSULT

1. Select "After Replace ECU" or "Manual Configuration".
2. Identify the correct model and configuration list. Refer to [BCS-63, "CONFIGURATION \(BCM\) : Configuration list"](#).
3. Confirm and/or change setting value for each item.

CAUTION:

Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.

4. Select "Next".

CAUTION:

Make sure to select "Next", confirm each setting value and press "OK" even if the indicated configuration of brand new BCM is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model cannot be memorized.

5. When "Completed", select "End".

>> GO TO 4.

4. OPERATION CHECK

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[WITH INTELLIGENT KEY SYSTEM]

Confirm that each function controlled by BCM operates normally.

>> Work End.

CONFIGURATION (BCM) : Configuration list

INFOID:000000009014224

CAUTION:

Thoroughly read and understand the vehicle specification. Incorrect settings may result in abnormal control of ECU.

| SETTING ITEM | |
|---------------|---------------------------|
| Items | Setting value |
| TRANSMISSION | AT with ABS ⇔ MT with ABS |
| BLOWE FAN SIG | MODE1 ⇔ MODE2 |

⇔: Items which confirm vehicle specifications

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

U1000 CAN COMM CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM CIRCUIT

Description

INFOID:000000009014225

Refer to [LAN-7, "CAN COMMUNICATION SYSTEM : System Description"](#).

DTC Logic

INFOID:000000009014226

DTC DETECTION LOGIC

NOTE:

U1000 can be set if a module harness was disconnected and reconnected, perhaps during a repair. Confirm that there are actual CAN diagnostic symptoms and a present DTC by performing the Self Diagnostic Result procedure.

| CONSULT Display | DTC Detection Condition | Possible Cause |
|-----------------------------|--|---|
| CAN COMM CIRCUIT [U1000] | When any listed module cannot communicate with CAN communication signal continuously for 2 seconds or more with ignition switch ON | In CAN communication system, any item (or items) of the following listed below is malfunctioning. <ul style="list-style-type: none">• Transmission• Receiving (ECM)• Receiving (VDC/TCS/ABS)• Receiving (METER/M&A)• Receiving (TCM)• Receiving (IPDM E/R) |

Diagnosis Procedure

INFOID:000000009014227

1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON and wait for 2 second or more.
2. Check "SELF- DIAG RESULTS".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Perform CAN Diagnosis as described in DIAGNOSIS section of CONSULT Operation Manual.
NO >> Refer to [GI-43, "Intermittent Incident"](#).

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

U1010 CONTROL UNIT (CAN)

DTC Logic

INFOID:000000009014228

DTC DETECTION LOGIC

| CONSULT Display | DTC Detection Condition | Possible Cause |
|-------------------------------|--|----------------|
| CONTROL UNIT (CAN) [U1010] | BCM detected internal CAN communication circuit malfunction. | BCM |

Diagnosis Procedure

INFOID:000000009014229

1. REPLACE BCM

When DTC "U1010" is detected, replace BCM.

>> Replace BCM. Refer to [BCS-74. "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

U0415 VEHICLE SPEED

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

U0415 VEHICLE SPEED

DTC Logic

INFOID:000000009014230

DTC DETECTION LOGIC

NOTE:

- If DTC U0415 is displayed with DTC U1000, first perform the trouble diagnosis for DTC U1000. Refer to [BCS-64, "DTC Logic"](#).
- If DTC U0415 is displayed with DTC U1010, first perform the trouble diagnosis for DTC U1010. Refer to [BCS-65, "DTC Logic"](#).

| CONSULT Display | DTC Detection Condition | Probable Cause |
|-------------------------|---|---|
| VDC CAN CIR2 [U0415] | When the vehicle speed signal received from the ABS actuator and electric unit (control unit) remains abnormal for 2 seconds or more. | <ul style="list-style-type: none">• ABS system• Combination meter system• CAN bus harness |

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION

1. Erase the DTC.
2. Turn ignition switch OFF.
3. Perform Self Diagnostic Result of BCM with CONSULT, after the ignition switch has been turned ON for 2 seconds or more.

Is any DTC detected?

- YES >> Refer to [BCS-50, "DTC Index"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009014231

1. ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) SELF DIAGNOSTIC RESULT

Perform Self Diagnostic Result of ABS with CONSULT. Refer to [BRC-31, "CONSULT Function \(ABS\)"](#).

Is any DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [BRC-43, "DTC Index"](#).
NO >> GO TO 2.

2. CHECK ABS ACTUATOR AND ELECTRIC UNIT (CONTROL UNIT) POWER SUPPLY AND GROUND CIRCUIT

Check ABS actuator and electric unit (control unit) power and ground. Refer to [BRC-60, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connectors.

3. COMBINATION METER SELF DIAGNOSTIC RESULT

Perform Self Diagnostic Result of METER M&A with CONSULT. Refer to [MWI-17, "CONSULT Function \(METER/M&A\)"](#).

Is any DTC detected?

- YES >> Perform the trouble diagnosis related to the detected DTC. Refer to [MWI-26, "DTC Index"](#).
NO >> Refer to [GI-43, "Intermittent Incident"](#).

B2562 LOW VOLTAGE

[WITH INTELLIGENT KEY SYSTEM]

< DTC/CIRCUIT DIAGNOSIS >

B2562 LOW VOLTAGE

DTC Logic

INFOID:000000009014232

DTC DETECTION LOGIC

| CONSULT Display | DTC Detection Condition | Possible Cause |
|------------------------|--|---|
| LOW VOLTAGE [B2562] | When the power supply voltage to BCM remains less than 8.8 V for 120 seconds or more | <ul style="list-style-type: none">• Harness or connector (power supply circuit)• Vehicle battery |

DTC CONFIRMATION PROCEDURE

1. DTC CONFIRMATION

1. Erase DTC.
2. Turn ignition switch OFF.
3. Perform the Self Diagnostic Result of BCM with CONSULT, after the ignition switch has been turned ON for 120 seconds or more.

Is any DTC detected?

- YES >> Refer to [BCS-67, "Diagnosis Procedure"](#).
NO >> Inspection End.

Diagnosis Procedure

INFOID:000000009014233

1. CHECK BATTERY VOLTAGE

Check battery voltage.

Is battery voltage less than 8.8V?

- YES >> Charge battery and retest. Refer to [CHG-14, "Work Flow \(With EXP-800 NI or GR8-1200 NI\)"](#) or [CHG-17, "Work Flow \(Without EXP-800 NI or GR8-1200 NI\)"](#).
NO >> GO TO 2.

2. CHECK POWER SUPPLY AND GROUND CIRCUIT

Check BCM power supply and ground circuit. Refer to [BCS-68, "Diagnosis Procedure"](#).

Is the inspection result normal?

- YES >> GO TO 3.
NO >> Repair or replace harness or connectors.

3. BCM SELF DIAGNOSTIC RESULT

Perform Self Diagnostic Result of BCM with CONSULT. Refer to [BCS-24, "BCM : CONSULT Function \(BCM - BCM\)"](#).

Is DTC B2562 CRNT?

- YES >> Replace BCM. Refer to [BCS-74, "Removal and Installation"](#).
NO >> Refer to [GI-43, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000009014234

Regarding Wiring Diagram information, refer to [BCS-52. "Wiring Diagram"](#).

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

| Terminal No. | Signal name | Fuses and fusible link No. |
|--------------|----------------------|----------------------------|
| 88 | Battery power supply | 12 (10A) |
| 90 | | G (40A) |

Is the fuse blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Disconnect BCM connector M85.
2. Check voltage between BCM connector M85 and ground.

| BCM | | Ground | Voltage |
|-----------|----------|--------|-----------------|
| Connector | Terminal | | |
| M85 | 88 | — | Battery voltage |
| | 90 | | |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector M85 and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M85 | 93 | — | Yes |

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair harness or connector.

COMBINATION SWITCH INPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

COMBINATION SWITCH INPUT CIRCUIT

Diagnosis Procedure

INFOID:000000009014235

Regarding Wiring Diagram information, refer to [BCS-52. "Wiring Diagram"](#).

1. CHECK INPUT 1 - 5 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM and combination switch connectors.
3. Check continuity between BCM connector and combination switch connector.

| Combination switch signal | BCM | | Combination switch | | Continuity |
|---------------------------|-----------|----------|--------------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| INPUT 1 | M84 | 36 | M28 | 11 | Yes |
| INPUT 2 | | 35 | | 9 | |
| INPUT 3 | | 34 | | 7 | |
| INPUT 4 | | 33 | | 10 | |
| INPUT 5 | | 32 | | 13 | |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair harness or connectors.

2. CHECK INPUT 1 - 5 CIRCUIT FOR SHORT

Check for continuity between BCM connector and ground.

| Combination switch signal | BCM | | Ground | Continuity |
|---------------------------|-----------|----------|--------|------------|
| | Connector | Terminal | | |
| INPUT 1 | M84 | 36 | | No |
| INPUT 2 | | 35 | | |
| INPUT 3 | | 34 | | |
| INPUT 4 | | 33 | | |
| INPUT 5 | | 32 | | |

Is the inspection result normal?

- YES >> Repair harness or connectors.
NO >> GO TO 3.

3. CHECK BCM OUTPUT VOLTAGE

1. Connect BCM connector.
2. Check voltage between BCM connector and ground.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

COMBINATION SWITCH INPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

| BCM signal | Terminals | | Voltage | |
|------------|-----------|----------|--|--------|
| | (+) | | | (-) |
| | BCM | | | Ground |
| | Connector | Terminal | | |
| OUTPUT 1 | M84 | 36 | Refer to BCS-29, "Reference Value" . | |
| OUTPUT 2 | | 35 | | |
| OUTPUT 3 | | 34 | | |
| OUTPUT 4 | | 33 | | |
| OUTPUT 5 | | 32 | | |

Is the inspection result normal?

YES >> Replace combination switch.

NO >> Replace BCM. Refer to [BCS-74, "Removal and Installation"](#).

COMBINATION SWITCH OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

COMBINATION SWITCH OUTPUT CIRCUIT

Diagnosis Procedure

INFOID:000000009014236

Regarding Wiring Diagram information, refer to [BCS-52. "Wiring Diagram"](#).

1. CHECK OUTPUT 1 - 5 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM and combination switch connectors.
3. Check continuity between BCM connector and combination switch connector.

| Combination switch signal | BCM | | Combination switch | | Continuity |
|---------------------------|-----------|----------|--------------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| OUTPUT 1 | M84 | 6 | M28 | 12 | Yes |
| OUTPUT 2 | | 5 | | 14 | |
| OUTPUT 3 | | 4 | | 5 | |
| OUTPUT 4 | | 3 | | 2 | |
| OUTPUT 5 | | 2 | | 8 | |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair harness or connectors.

2. CHECK OUTPUT 1 - 5 CIRCUIT FOR SHORT

Check for continuity between BCM connector and ground.

| Combination switch signal | BCM | | Ground | Continuity |
|---------------------------|-----------|----------|--------|------------|
| | Connector | Terminal | | |
| OUTPUT 1 | M84 | 6 | | No |
| OUTPUT 2 | | 5 | | |
| OUTPUT 3 | | 4 | | |
| OUTPUT 4 | | 3 | | |
| OUTPUT 5 | | 2 | | |

Is the inspection result normal?

- YES >> Repair harness or connectors.
NO >> GO TO 3.

3. CHECK BCM INPUT SIGNAL

1. Connect BCM and combination switch connectors.
2. Turn ON any switch in the system that is malfunctioning.
3. Check voltage between BCM connector and ground.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

COMBINATION SWITCH OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

| BCM signal | Terminals | | Voltage | |
|------------|-----------|----------|---------|-----|
| | (+) | | | (-) |
| | BCM | | | |
| | Connector | Terminal | | |
| INPUT 1 | M84 | 6 | Ground | |
| INPUT 2 | | 5 | | |
| INPUT 3 | | 4 | | |
| INPUT 4 | | 3 | | |
| INPUT 5 | | 2 | | |

Is the inspection result normal?

- Yes >> Replace BCM. Refer to [BCS-74. "Removal and Installation"](#).
- No >> Replace combination switch.

COMBINATION SWITCH SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[WITH INTELLIGENT KEY SYSTEM]

SYMPTOM DIAGNOSIS

COMBINATION SWITCH SYSTEM SYMPTOMS

Symptom Table

INFOID:000000009014237

1. Perform the data monitor of CONSULT to check for any malfunctioning item.
2. Check the malfunction combinations.

Malfunction item: x

| Malfunction combination | Data monitor item | | | | | | | | | | | | | |
|-------------------------|---|--------------|--------------|--------------|------------|---------------|---------------|--------------|------------|----------------|----------------|------------|---------------|-----------|
| | FR WIPER HI | FR WIPER LOW | FR WASHER SW | FR WIPER INT | INT VOLUME | TURN SIGNAL R | TURN SIGNAL L | TAIL LAMP SW | HI BEAM SW | HEAD LAMP SW 1 | HEAD LAMP SW 2 | PASSING SW | AUTO LIGHT SW | FR FOG SW |
| A | | x | x | | | x | x | | | | | | | |
| B | x | | | x | | | | | | x | | x | | |
| C | | | | | x | | | | x | | x | | | |
| D | | | | | x | | | x | | | | | x | |
| E | | | | | x | | | | | | | | | x |
| F | x | | | | x | | | | | | | | | |
| G | | | x | | x | | | | | | | | | |
| H | | x | | x | | | | | | | | | x | |
| I | | | | | | | x | | | | x | x | | x |
| J | | | | | | x | | x | x | x | | | | |
| K | All Items | | | | | | | | | | | | | |
| L | If only one item is detected or the item is not applicable to the combinations A to K | | | | | | | | | | | | | |

3. Identify the malfunctioning part from the agreed combination and repair or replace the part.

| Malfunction combination | Malfunctioning part | Repair or replace |
|-------------------------|-------------------------------------|---|
| A | Combination switch INPUT 1 circuit | Inspect the combination switch input circuit applicable to the malfunctioning part. Refer to BCS-69, "Diagnosis Procedure" . |
| B | Combination switch INPUT 2 circuit | |
| C | Combination switch INPUT 3 circuit | |
| D | Combination switch INPUT 4 circuit | |
| E | Combination switch INPUT 5 circuit | |
| F | Combination switch OUTPUT 1 circuit | Inspect the combination switch output circuit applicable to the malfunctioning part. Refer to BCS-71, "Diagnosis Procedure" . |
| G | Combination switch OUTPUT 2 circuit | |
| H | Combination switch OUTPUT 3 circuit | |
| I | Combination switch OUTPUT 4 circuit | |
| J | Combination switch OUTPUT 5 circuit | |
| K | BCM | Replace BCM. Refer to BCS-74, "Removal and Installation" . |
| L | Combination switch | Replace the combination switch. |

REMOVAL AND INSTALLATION

BCM

Removal and Installation


INFOID:000000008766873

NOTE:


Before replacing BCM, perform "READ CONFIGURATION" to save or print current vehicle specification. Refer to [BCS-62, "CONFIGURATION \(BCM\) : Description"](#).

REMOVAL


1. Disconnect the negative battery terminal. Refer to [PG-52, "Removal and Installation"](#).
2. Remove instrument lower panel LH and instrument side finisher LH. Refer to [IP-21, "Removal and Installation"](#).
3. Remove fuse block (J/B) screws (A) and position (BCM) aside.



4. Remove harness clip (A).



5. Remove the screws (A) from the BCM (1).



6. Disconnect the harness connectors and remove the BCM.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Perform "CONFIGURATION (BCM)" when replacing BCM. Refer to [BCS-62, "CONFIGURATION \(BCM\) : Description"](#)

BCM

< REMOVAL AND INSTALLATION >

[WITH INTELLIGENT KEY SYSTEM]

- Be sure to perform the system initialization (NATS) when replacing BCM. Refer to [BCS-61, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(BCM\) : Work Procedure"](#).
- When replacing BCM, if new BCM does not come with keyfobs attached, all existing keyfobs must be re-registered.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

COMBINATION SWITCH


< REMOVAL AND INSTALLATION >

[WITH INTELLIGENT KEY SYSTEM]

COMBINATION SWITCH

Exploded View

INFOID:000000009020461



1. Combination switch 2. Combination switch harness connector ↩ Front

NOTE:

Shown with the steering wheel removed for clarity only.

Removal and Installation

INFOID:000000009020462

REMOVAL

CAUTION:

- Before servicing, turn the ignition switch OFF, disconnect both battery terminals and wait at least three minutes.
 - Do not use air or electric tools when removing or installing the combination switch.
1. Disconnect both the negative and positive battery terminals, then wait at least three minutes. Refer to [PG-50, "Removal and Installation \(Battery\)"](#).
 2. Remove the steering column covers. Refer to [IP-16, "Removal and Installation"](#).
 3. Rotate steering wheel clockwise to access first combination switch bolt and remove.
 4. Rotate steering wheel counter-clockwise to access second combination switch bolt and remove.
 5. Disconnect the harness connector from the combination switch and remove.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After the work is completed, make sure no system malfunction is detected by air bag warning lamp.
- In case a malfunction is detected by the air bag warning lamp, reset with the self-diagnosis function and delete the memory with CONSULT.
- If a malfunction is still detected after the above operation, perform self-diagnosis to repair malfunctions. Refer to [SRC-41, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

PRECAUTIONS

< PRECAUTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

PRECAUTION

PRECAUTIONS

Precaution for Supplemental Restraint System (SRS) "AIR BAG" and "SEAT BELT PRE-TENSIONER"

INFOID:000000009020458

The Supplemental Restraint System such as "AIR BAG" and "SEAT BELT PRE-TENSIONER", used along with a front seat belt, helps to reduce the risk or severity of injury to the driver and front passenger for certain types of collision. Information necessary to service the system safely is included in the SR and SB section of this Service Manual.

WARNING:

- To avoid rendering the SRS inoperative, which could increase the risk of personal injury or death in the event of a collision which would result in air bag inflation, all maintenance must be performed by an authorized NISSAN/INFINITI dealer.
- Improper maintenance, including incorrect removal and installation of the SRS, can lead to personal injury caused by unintentional activation of the system. For removal of Spiral Cable and Air Bag Module, see the SR section.
- Do not use electrical test equipment on any circuit related to the SRS unless instructed to in this Service Manual. SRS wiring harnesses can be identified by yellow and/or orange harnesses or harness connectors.

PRECAUTIONS WHEN USING POWER TOOLS (AIR OR ELECTRIC) AND HAMMERS

WARNING:

- When working near the Airbag Diagnosis Sensor Unit or other Airbag System sensors with the Ignition ON or engine running, DO NOT use air or electric power tools or strike near the sensor(s) with a hammer. Heavy vibration could activate the sensor(s) and deploy the air bag(s), possibly causing serious injury.
- When using air or electric power tools or hammers, always switch the Ignition OFF, disconnect the battery and wait at least 3 minutes before performing any service.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

COMPONENT PARTS

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >


SYSTEM DESCRIPTION

COMPONENT PARTS

BODY CONTROL SYSTEM

BODY CONTROL SYSTEM : Component Parts Location

INFOID:000000009014238




1. BCM (view with instrument panel removed)

COMBINATION SWITCH READING SYSTEM

COMBINATION SWITCH READING SYSTEM : Component Parts Location

INFOID:000000009014239



COMPONENT PARTS

< SYSTEM DESCRIPTION >


[WITHOUT INTELLIGENT KEY SYSTEM]

- | | | | |
|--|---|--|---|
| 1. BCM (view with combination meter removed) | 2. Combination switch (lighting and turn signal) (with fog lamps) | 3. Combination switch (lighting and turn signal) (without fog lamps) | A |
| 4. Combination switch (wiper and washer) | | | B |

POWER CONSUMPTION CONTROL SYSTEM

POWER CONSUMPTION CONTROL SYSTEM : Component Parts Location

INFOID:000000009014240



- | | | | |
|------------|--|---------------------|---|
| 1 IPDM E/R | 2 BCM (view with instrument panel removed) | 3 Combination meter | C |
| | | | D |
| | | | E |
| | | | F |
| | | | G |
| | | | H |
| | | | I |
| | | | J |
| | | | K |
| | | | L |

AWMIA1357ZZ

BCS

SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

SYSTEM

BODY CONTROL SYSTEM

BODY CONTROL SYSTEM : System Description

INFOID:000000009014241

OUTLINE

- BCM (Body Control Module) controls various electrical components. It receives the information required from CAN communication and the signals received from each switch and sensor.
- BCM has a combination switch reading function for reading the status of combination switch (light, turn signal, wiper and washer) in addition to functions for controlling the operation of various electrical components. It also has a signal transmission function for other systems, and a power consumption control function that reduces the power consumption with the ignition switch OFF.
- BCM is equipped with a diagnosis function that operates with CONSULT and allows for various settings to be changed.

BCM FUNCTION LIST

| System | Reference page |
|---|--|
| Combination switch reading system | BCS-81, "COMBINATION SWITCH READING SYSTEM : System Diagram" |
| Signal buffer system | BCS-84, "SIGNAL BUFFER : System Diagram" |
| Power consumption control system | BCS-84, "POWER CONSUMPTION CONTROL SYSTEM : System Diagram" |
| Headlamp system | EXL-8, "HEADLAMP SYSTEM : System Description" |
| Daytime running light system | EXL-9, "DAYTIME RUNNING LIGHT SYSTEM : System Description" |
| Turn signal and hazard warning lamp system | EXL-10, "TURN SIGNAL AND HAZARD WARNING LAMPS : System Description" |
| Parking, license plate, side marker and tail lamps system | EXL-11, "PARKING, LICENSE PLATE AND TAIL LAMPS : System Description" |
| Exterior lamp battery saver system | EXL-8, "HEADLAMP SYSTEM : System Description" |
| Interior room lamp control system | INL-8, "INTERIOR ROOM LAMP CONTROL SYSTEM : System Description" |
| Interior room lamp battery saver system | INL-8, "INTERIOR ROOM LAMP CONTROL SYSTEM : System Description" |
| Front wiper and washer system | WW-8, "System Description" |
| Manual air conditioner system | HAC-120, "System Description" |
| Warning chime system | WCS-6, "WARNING CHIME SYSTEM : System Description" |
| Power door lock system | DLK-215, "POWER DOOR LOCK SYSTEM : System Description" |
| Nissan vehicle immobilizer system-NATS (NVIS) | SEC-143, "NISSAN VEHICLE IMMOBILIZER SYSTEM-NATS : System Description" |
| Rear window defogger system | DEF-6, "System Description" |
| Remote keyless entry system | DLK-216, "REMOTE KEYLESS ENTRY SYSTEM : System Description" |
| Power window system | PWC-8, "System Description" |
| Retained accessory power (RAP) system | BCS-96, "RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)" |

COMBINATION SWITCH READING SYSTEM


SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

COMBINATION SWITCH READING SYSTEM : System Diagram

INFOID:000000009014242



COMBINATION SWITCH READING SYSTEM : System Description


INFOID:000000009014243

OUTLINE

- BCM reads the status of the combination switch (light, turn signal, wiper and washer) and recognizes the status of each switch.
- BCM has a combination of 5 output terminals (OUTPUT 1 - 5) and 5 input terminals (INPUT 1 - 5). It reads a maximum of 20 switch states.

COMBINATION SWITCH MATRIX

Combination switch circuit



Combination switch INPUT-OUTPUT system list

| System | INPUT 1 | INPUT 2 | INPUT 3 | INPUT 4 | INPUT 5 |
|----------|--------------|--------------|--------------|------------|------------|
| OUTPUT 1 | — | FR WASHER | FR WIPER LOW | TURN LH | TURN RH |
| OUTPUT 2 | FR WIPER HI | — | FR WIPER INT | PASSING | HEADLAMP 1 |
| OUTPUT 3 | INT VOLUME 1 | — | — | HEADLAMP 2 | HI BEAM |
| OUTPUT 4 | — | INT VOLUME 3 | — | — | TAIL LAMP |
| OUTPUT 5 | INT VOLUME 2 | — | — | FR FOG | — |

COMBINATION SWITCH READING FUNCTION

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS


SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

Description


- BCM reads the status of the combination switch at 10 ms intervals normally.



NOTE:

BCM reads the status of the combination switch at 60 ms intervals when BCM is controlled at low power consumption control mode.

- BCM operates as follows and judges the status of the combination switch.
 - It operates the transistor on OUTPUT side in the following order: OUTPUT 1 → 2 → 3 → 4 → 5, and outputs voltage waveform.
 - The voltage waveform of OUTPUT corresponding to the formed circuit is input into the interface on INPUT side if any (1 or more) switches are ON.
 - It reads this change of the voltage as the status signal of the combination switch.



Operation Example

In the following operation example, the combination of the status signals of the combination switch is replaced as follows: INPUT 1 - 5 to "1 - 5" and OUTPUT 1 - 5 to "A - E".


Example 1: When a switch (TAIL LAMP) is turned ON

SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT INTELLIGENT KEY SYSTEM]


- The circuit between OUTPUT 4 and INPUT 5 is formed when the TAIL LAMP switch is turned ON.



- BCM detects the combination switch status signal "5D" when the signal of OUTPUT 4 is input to INPUT 5.
- BCM judges that the TAIL LAMP switch is ON when the signal "5D" is detected.

Example 2: When some switches (TURN RH, TAIL LAMP) are turned ON

- The circuits between OUTPUT 1 and INPUT 5 and between OUTPUT 4 and INPUT 5 are formed when the TURN RH switch and TAIL LAMP switch are turned ON.



- BCM detects the combination switch status signal "5AD" when the signals of OUTPUT 1 and OUTPUT 4 are input to INPUT 5.
- BCM judges that the TURN RH switch and TAIL LAMP switch are ON when the signal "5AD" is detected.

SIGNAL BUFFER


SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

SIGNAL BUFFER : System Diagram

INFOID:000000009014244



AWMIA1231GB

SIGNAL BUFFER : System Description

INFOID:000000009014245

OUTLINE

BCM has the signal transmission function that outputs/transmits each input/received signal to each unit.


SIGNAL TRANSMISSION FUNCTION LIST

| Signal name | Input | Output | Description |
|---------------------------|-------------------|---|--|
| Ignition switch ON signal | Ignition switch | IPDM E/R (CAN) | Inputs the ignition switch signal and transmits it with CAN communication. |
| Brake switch signal | Stop lamp switch | IPDM E/R (CAN) | Inputs the brake switch signal and transmits it with CAN communication. |
| Door switch signal | Any door switch | <ul style="list-style-type: none"> Combination meter (CAN) IPDM E/R (CAN) | Inputs the door switch signal and transmits it with CAN communication. |
| Blower fan ON signal | Front air control | ECM (CAN) | Inputs each signals, and transmits the blower fan ON signal and A/C ON signal via CAN communication. |
| A/C ON signal | | | |

POWER CONSUMPTION CONTROL SYSTEM

POWER CONSUMPTION CONTROL SYSTEM : System Diagram

INFOID:000000009014246



AWMIA1208GB

POWER CONSUMPTION CONTROL SYSTEM : System Description

INFOID:000000009014247

OUTLINE

- BCM incorporates a power saving control function that reduces the power consumption according to the vehicle status.

SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

- BCM switches the status (control mode) by itself with the power saving control function. It performs the sleep request to each unit (IPDM E/R and combination meter) that operates with the ignition switch OFF.

Normal mode (wake-up)

- CAN communication is normally performed with other units
- Each control with BCM is operating properly

CAN communication sleep mode (CAN sleep)

- CAN transmission is stopped
- Control with BCM only is operating

Low power consumption mode (BCM sleep)

- Low power consumption control is active
- CAN transmission is stopped

LOW POWER CONSUMPTION CONTROL WITH BCM

BCM reduces the power consumption with the following operation in the low power consumption mode.

- The reading interval of the switches changes from 10 ms interval to 60 ms interval.

Sleep mode activation

- BCM receives the sleep-ready signal (ready) from IPDM E/R and combination meter via CAN communication.
- BCM transmits the sleep wake up signal (sleep) to each unit when all of the CAN sleep conditions are fulfilled.
- Each unit stops the transmission of CAN communication with the sleep wake up signal. BCM is in CAN communication sleep mode.
- BCM is in the low power consumption mode and performs the low power consumption control when all of the BCM sleep conditions are fulfilled with CAN sleep condition.

Sleep condition

| CAN sleep condition | BCM sleep condition |
|---|--|
| <ul style="list-style-type: none"> • Receiving the sleep-ready signal (ready) from all units • Ignition switch: OFF • Panic alarm: No operation • Warning chime: No operation • Stop lamp switch: OFF • Turn signal indicator lamp: No operation • Exterior lamp: OFF • Door lock status: No change • CONSULT communication status: No communication • Door switch status: No change • Rear window defogger: OFF • Driver door lock status: No change • Key switch status: No change | <ul style="list-style-type: none"> • Interior room lamp battery saver: Time out • RAP system: OFF • Nissan Vehicle Immobilizer System (NVIS) - NATS: No operation • Remote keyless entry receiver communication status: No communication |

BCS

Wake-up operation

- BCM transmits sleep wake up signal (wake up) to each unit when any condition listed below is established, and then goes into normal mode from low power consumption mode.
- Each unit starts transmissions with CAN communication by receiving sleep wake up signals. Each unit transmits wake up signals to BCM with CAN communication to convey the start of CAN communication.

SYSTEM

< SYSTEM DESCRIPTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

Wake-up condition

Wake-up condition

- Receiving the sleep-ready signal (Not-ready) from any units
 - Hazard switch: ON
 - HI BEAM switch: OFF → ON, ON → OFF
 - PASSING switch: OFF → ON, ON → OFF
 - HEADLAMP 1 switch: OFF → ON, ON → OFF
 - HEADLAMP 2 switch: OFF → ON, ON → OFF
 - TAIL LAMP switch: OFF → ON
 - TURN RH: OFF → ON, ON → OFF
 - TURN LH: OFF → ON, ON → OFF
 - Driver door switch: OFF → ON, ON → OFF
 - Passenger door switch: OFF → ON, ON → OFF
 - Rear door switch RH: OFF → ON, ON → OFF
 - Rear door switch LH: OFF → ON, ON → OFF
 - Stop lamp switch: ON
 - Door lock and unlock switch:
NEUTRAL → LOCK, NEUTRAL → UNLOCK
 - Front door lock assembly (driver side) (door key cylinder switch):
NEUTRAL → LOCK, NEUTRAL → UNLOCK
 - Remote keyless entry receiver communication: Receiving
-

DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

DIAGNOSIS SYSTEM (BCM)

COMMON ITEM

COMMON ITEM : CONSULT Function (BCM - COMMON ITEM)

INFOID:000000009014248

APPLICATION ITEM

CONSULT performs the following functions via CAN communication with BCM.

| Direct Diagnostic Mode | Description |
|------------------------|--|
| ECU identification | The BCM part number is displayed. |
| Self Diagnostic Result | The BCM self diagnostic results are displayed. |
| Data Monitor | The BCM input/output data is displayed in real time. |
| Active Test | The BCM activates outputs to test components. |
| Work support | The settings for BCM functions can be changed. |
| Configuration | <ul style="list-style-type: none"> The vehicle specification can be read and saved. The vehicle specification can be written when replacing BCM. |
| CAN DIAG SUPPORT MNTR | The result of transmit/receive diagnosis of CAN communication is displayed. |

SYSTEM APPLICATION

BCM can perform the following functions.

| System | Sub System | Direct Diagnostic Mode | | | | | | |
|--------------------------------------|----------------------|------------------------|------------------------|--------------|-------------|--------------|---------------|-----------------------|
| | | ECU identification | Self Diagnostic Result | Data Monitor | Active Test | Work support | Configuration | CAN DIAG SUPPORT MNTR |
| Door lock | DOOR LOCK | | × | × | × | × | | |
| Rear window defogger | REAR DEFOGGER | | | × | × | | | |
| Warning chime | BUZZER | | | × | × | | | |
| Interior room lamp timer | INT LAMP | | | × | × | × | | |
| Remote keyless entry system | MULTI REMOTE ENT | | | × | × | × | | |
| Exterior lamp | HEAD LAMP | | | × | × | × | | |
| Wiper and washer | WIPER | | | × | × | × | | |
| Turn signal and hazard warning lamps | FLASHER | | | × | × | | | |
| Air conditioner | AIR CONDITIONER | | | × | | | | |
| Combination switch | COMB SW | | | × | | | | |
| BCM | BCM | × | × | | | × | × | × |
| Immobilizer | IMMU | | × | | × | × | | |
| Interior room lamp battery saver | BATTERY SAVER | | | × | × | × | | |
| Trunk open | TRUNK | | | × | | | | |
| RAP system | RETAINED PWR | | | × | | × | | |
| Signal buffer system | SIGNAL BUFFER | | | × | | | | |
| TPMS | AIR PRESSURE MONITOR | | × | × | × | × | | |
| Panic alarm system | PANIC ALARM | | | | × | | | |

DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

DOOR LOCK

DOOR LOCK : CONSULT Function (BCM - DOOR LOCK)

INFOID:000000009014249

DATA MONITOR

| Monitor Item [Unit] | Description |
|--------------------------|---|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| KEY ON SW [On/Off] | Indicates condition of key switch. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| ACC ON SW [On/Off] | Indicates condition of ignition switch ACC position. |
| KEYLESS LOCK [On/Off] | Indicates condition of lock signal from keyfob. |
| KEYLESS UNLOCK [On/Off] | Indicates condition of unlock signal from keyfob. |
| KEY CYL LK-SW [On/Off] | Indicates condition of lock signal from door key cylinder switch. |
| KEY CYL UN-SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch. |
| VEHICLE SPEED [km/h/mph] | Indicates vehicle speed signal received from combination meter on CAN communication line. |

ACTIVE TEST

| Test Item | Description |
|-----------|--|
| DOOR LOCK | This test is able to check door lock operation [OTR ULK/DR UNLK/ALL UNLK/ALL LCK]. |

WORK SUPPORT

| Support Item | Setting | Description |
|------------------------------|--------------|--|
| DOOR LOCK-UNLOCK SET | On* | Automatic door locks function ON. |
| | Off | Automatic door locks function OFF. |
| AUTOMATIC DOOR LOCK SELECT | P RANGE | Doors lock automatically when shifted out of Park (P). |
| | VH SPD* | Doors lock automatically when vehicle speed reaches 24 km/h (15 mph). |
| AUTOMATIC DOOR UNLOCK SELECT | MODE6* | Drivers door unlocks automatically when key is removed. |
| | MODE5 | Drivers door unlocks automatically when shifted into Park (P). |
| | MODE4 | Drivers door unlocks automatically when ignition is switched from ON to OFF. |
| | MODE3 | Doors unlock automatically when key is removed. |
| | MODE2 | Doors unlock automatically when shifted into Park (P). |
| AUTOMATIC LOCK/UNLOCK SELECT | MODE1 | Doors unlock automatically when ignition is switched from ON to OFF. |
| | Lock/Unlock* | Automatic door locks function operates in lock and unlock. |
| | Lock Only | Automatic door locks function operates in lock only. |
| | Unlock Only | Automatic door locks function operates in unlock only. |
| | Off | Automatic door locks function OFF. |

* : Initial setting

REAR DEFOGGER

REAR DEFOGGER : CONSULT Function (BCM - REAR DEFOGGER)

INFOID:000000009014250

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|----------------------|---|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| ACC ON SW [On/Off] | Indicates condition of ignition switch ACC position. |
| REAR DEF SW [On/Off] | Indicates condition of rear window defogger switch. |
| RR DEF TIME [On/Off] | Indicates condition of rear window defogger switch timer. |

ACTIVE TEST

| Test Item | Description |
|---------------|---|
| REAR DEFOGGER | This test is able to check rear window defogger operation [Off/On]. |

BUZZER

BUZZER : CONSULT Function (BCM - BUZZER)

INFOID:000000009014251

DATA MONITOR

| Monitor Item [Unit] | Description |
|--------------------------|---|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| KEY ON SW [On/Off] | Indicates condition of key switch. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| REVERSE SW CAN [On/Off] | Indicates reverse switch signal received from TCM on CAN communication line. |
| TAIL LAMP SW [On/Off] | Indicates condition of combination switch. |
| FR FOG SW [On/Off] | Indicates condition of front fog lamp switch. |
| BUCKLE SW [On/Off] | Indicates condition of seat belt buckle switch. |
| VEHICLE SPEED [km/h/mpH] | Indicates vehicle speed signal received from combination meter on CAN communication line. |

ACTIVE TEST

| Test Item | Description |
|---------------------|--|
| IGN KEY WARN ALM | This test is able to check key warning chime operation [On/Off]. |
| SEAT BELT WARN TEST | This test is able to check seat belt warning chime operation [On/Off]. |
| LIGHT WARN ALM | This test is able to check light warning chime operation [On/Off]. |

INT LAMP

INT LAMP : CONSULT Function (BCM - INT LAMP)

INFOID:000000009014252

DATA MONITOR

| Monitor Item [Unit] | Description |
|-------------------------|--|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| KEY ON SW [On/Off] | Indicates condition of key switch. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| KEYLESS LOCK [On/Off] | Indicates condition of lock signal from keyfob. |
| KEYLESS UNLOCK [On/Off] | Indicates condition of unlock signal from keyfob. |

A
B
C
D
E
F
G
H
I
J
K
L

BCS

N
O
P

DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|------------------------|---|
| TRNK/HAT MNTR [On/Off] | Indicates condition of trunk lid switch. |
| KEY CYL LK-SW [On/Off] | Indicates condition of lock signal from door key cylinder switch. |
| KEY CYL UN-SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch. |
| ACC SW [On/Off] | Indicates condition of ignition switch ACC position. |

ACTIVE TEST

| Test Item | Description |
|-----------|---|
| INT LAMP | This test is able to check interior room lamp operation [On/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|------------------------|-------------------|---|
| SET I/L D-UNLCK INTCON | On* | Interior room lamp timer function ON. |
| | Off | Interior room lamp timer function OFF. |
| ROOM LAMP TIMER SET | MODE 4 30 sec. | Sets the interior room lamp ON time. (Timer operating time). |
| | MODE 3* 15 sec. | |
| | MODE 2 7.5 sec. | |
| | MODE 1 OFF | |
| ROOM LAMP ON TIME SET | MODE7 0 sec. | Sets the interior room lamp gradual brightening time. |
| | MODE6 5 sec. | |
| | MODE5 4 sec. | |
| | MODE4 3 sec. | |
| | MODE3 2 sec. | |
| | MODE2* 1 sec. | |
| | MODE1 0.5 sec. | |
| ROOM LAMP OFF TIME SET | MODE7 0 sec. | Sets the interior room lamp gradual dimming time. |
| | MODE6 5 sec. | |
| | MODE5 4 sec. | |
| | MODE4 3 sec. | |
| | MODE3 2 sec. | |
| | MODE2* 1 sec. | |
| | MODE1 0.5 sec. | |
| R LAMP TIMER LOGIC SET | MODE 2 | Interior room lamp timer activates with all doors. |
| | MODE 1* | Interior room lamp timer activates with the driver door only. |

* : Initial setting

MULTI REMOTE ENT

MULTI REMOTE ENT : CONSULT Function (BCM - MULTI REMOTE ENT)

INFOID:000000009014253

DATA MONITOR

| Monitor Item [Unit] | Description |
|-----------------------|--|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| KEY ON SW [On/Off] | Indicates condition of key switch. |
| ACC ON SW [On/Off] | Indicates condition of ignition switch ACC position. |
| KEYLESS LOCK [On/Off] | Indicates condition of lock signal from keyfob. |

DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|-------------------------|--|
| KEYLESS UNLOCK [On/Off] | Indicates condition of unlock signal from keyfob. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| KEYLESS PANIC [On/Off] | Indicates condition of panic signal from keyfob. |

ACTIVE TEST

| Test Item | Description |
|-----------|---|
| INT LAMP | This test is able to check interior room lamp operation [On/Off]. |
| FLASHER | This test is able to check hazard reminder operation [Off/LH/RH]. |
| HORN | This test is able to check horn operation [On]. |

WORK SUPPORT

| Support Item | Setting | Description |
|---------------------|------------------------|---|
| REMO CONT ID REGIST | — | Keyfob ID code can be registered. |
| REMO CONT ID ERASUR | — | Keyfob ID code can be erased. |
| REMO CONT ID CONFIR | — | Keyfob ID code registration is displayed. |
| HORN CHIRP SET | Off | Horn chirp function can be changed in this mode. |
| | On* | |
| HAZARD LAMP SET | MODE4* Lock and Unlock | Hazard warning lamp function can be changed in this mode. |
| | MODE3 Lock Only | |
| | MODE2 Unlock Only | |
| | MODE1 OFF | |
| PANIC ALRM SET | MODE3 1.5 sec | Panic alarm operation can be changed in this mode. |
| | MODE2 OFF | |
| | MODE1* 0.5 sec | |
| AUTO LOCK SET | MODE7 5 min | Auto locking function can be changed in this mode. |
| | MODE6 4 min | |
| | MODE5 3 min | |
| | MODE4 2 min | |
| | MODE3* 1 min | |
| | MODE2 30 sec | |
| MODE1 OFF | | |

*: Initial setting

HEADLAMP

HEADLAMP : CONSULT Function (BCM - HEAD LAMP)

INFOID:000000009014254

DATA MONITOR

| Monitor Item [Unit] | Description |
|---------------------|--|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| ACC ON SW [On/Off] | Indicates condition of ignition switch ACC position. |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|--------------------------|---|
| HI BEAM SW [On/Off] | Indicates condition of combination switch. |
| HEAD LAMP SW 1 [On/Off] | |
| HEAD LAMP SW 2 [On/Off] | |
| TAIL LAMP SW [On/Off] | |
| PASSING SW [On/Off] | |
| FR FOG SW [On/Off] | |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| TURN SIGNAL R [On/Off] | Indicates condition of combination switch. |
| TURN SIGNAL L [On/Off] | |
| KEY ON SW [On/Off] | Indicates condition of key switch. |
| KEYLESS LOCK [On/Off] | Indicates condition of lock signal from keyfob. |
| PKB SW [On/Off] | Indicates park brake switch signal received from combination meter on CAN communication line. |
| ENGINE RUN [On/Off] | Indicates engine run signal received from ECM on CAN communication line. |
| VEHICLE SPEED [km/h/mph] | Indicates vehicle speed signal received from combination meter on CAN communication line. |

ACTIVE TEST

| Test Item | Description |
|----------------|---|
| TAIL LAMP | This test is able to check tail lamp operation [On/Off]. |
| HEAD LAMP | This test is able to check head lamp operation [Hi/Low/Off]. |
| FR FOG LAMP | This test is able to check front fog lamp operation [On/Off]. |
| ILL DIM SIGNAL | This test is able to check head lamp illumination dimming operation [On/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|-------------------|---------|---|
| BATTERY SAVER SET | On* | Exterior lamp battery saver function ON. |
| | Off | Exterior lamp battery saver function OFF. |
| ILL DELAY SET | MODE 8 | 180 sec. |
| | MODE 7 | 150 sec. |
| | MODE 6 | 120 sec. |
| | MODE 4 | 60 sec. |
| | MODE 5 | 90 sec. |
| | MODE 3 | 30 sec. |
| | MODE 2 | OFF |
| | MODE 1* | 45 sec. |

* : Initial setting

WIPER

WIPER : CONSULT Function (BCM - WIPER)

INFOID:000000009014255

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|--------------------------|---|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| IGN SW CAN [On/Off] | Indicates ignition switch ON signal received from IPDM E/R on CAN communication line. |
| FR WIPER HI [On/Off] | Indicates condition of wiper operation of combination switch. |
| FR WIPER LOW [On/Off] | |
| FR WIPER INT [On/Off] | |
| FR WASHER SW [On/Off] | |
| INT VOLUME [1 - 7] | Indicates condition of intermittent wiper operation of combination switch. |
| FR WIPER STOP [On/Off] | Indicates front wiper auto stop signal received from IPDM E/R on CAN communication line. |
| REVERSE SW CAN [On/Off] | Indicates reverse switch signal received from TCM on CAN communication line. |
| VEHICLE SPEED [km/h/mpH] | Indicates vehicle speed signal received from combination meter on CAN communication line. |

ACTIVE TEST

| Test Item | Description |
|-----------|---|
| FR WIPER | This test is able to check front wiper operation [INT/Lo/Hi/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|---------------------|---------|--|
| WIPER SPEED SETTING | On | Front wiper intermittent time linked with vehicle speed and wiper dial position. |
| | Off* | Front wiper intermittent time linked with wiper dial position. |

* : Initial setting

FLASHER

FLASHER : CONSULT Function (BCM - FLASHER)

INFOID:000000009014256

DATA MONITOR

| Monitor Item [Unit] | Description |
|------------------------|--|
| HAZARD SW [On/Off] | Indicates condition of hazard switch. |
| TURN SIGNAL R [On/Off] | Indicates condition of turn signal function of combination switch. |
| TURN SIGNAL L [On/Off] | |

ACTIVE TEST

| Test Item | Description |
|-----------|--|
| FLASHER | This test is able to check turn signal lamp operation [Off/LH/RH]. |

AIR CONDITIONER

AIR CONDITIONER : CONSULT Function (BCM - AIR CONDITIONER)

INFOID:000000009014257

DATA MONITOR

| Monitor Item [Unit] | Description |
|----------------------|---|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| FAN ON SIG [On/Off] | Indicates condition of fan switch. |
| AIR COND SW [On/Off] | Indicates condition of A/C switch. |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|---------------------|--|
| THERMO AMP [On/Off] | Indicates condition of thermo amp. |
| FR DEF SW [On/Off] | Indicates condition of front defrost switch. |

COMB SW

COMB SW : CONSULT Function (BCM - COMB SW)

INFOID:000000009014258

DATA MONITOR

| Monitor Item [Unit] | Description |
|-------------------------|---|
| TURN SIGNAL R [On/Off] | Indicates condition of right turn signal operation of combination switch. |
| TURN SIGNAL L [On/Off] | Indicates condition of left turn signal operation of combination switch. |
| HI BEAM SW [On/Off] | Indicates condition of Hi beam switch operation of combination switch. |
| HEAD LAMP SW 1 [On/Off] | Indicates condition of head lamp switch 1 operation of combination switch. |
| HEAD LAMP SW 2 [On/Off] | Indicates condition of head lamp switch 2 operation of combination switch. |
| TAIL LAMP SW [On/Off] | Indicates condition of tail lamp switch operation of combination switch. |
| PASSING SW [On/Off] | Indicates condition of passing switch operation of combination switch. |
| FR FOG SW [On/Off] | Indicates condition of front fog lamp switch operation of combination switch. |
| FR WIPER HI [On/Off] | Indicates condition of wiper operation of combination switch. |
| FR WIPER LOW [On/Off] | |
| FR WIPER INT [On/Off] | |
| FR WASHER SW [On/Off] | |
| INT VOLUME [1 - 7] | Indicates condition of intermittent wiper operation of combination switch. |

BCM

BCM : CONSULT Function (BCM - BCM)

INFOID:000000009014259

ECU IDENTIFICATION

The BCM part number is displayed.

SELF DIAGNOSTIC RESULT

Refer to [BCS-110, "DTC Index"](#).

WORK SUPPORT

| Support Item | Setting | Description |
|---------------------|---------|---|
| RESET SETTING VALUE | Reset | Returns BCM to initial value in factory shipment. |
| | Cancel | Cancels the reset function. |

CONFIGURATION

Refer to [BCS-117, "CONFIGURATION \(BCM\) : Description"](#).

CAN DIAG SUPPORT MNTR

Refer to [LAN-13, "CAN Diagnostic Support Monitor"](#).

IMMU

IMMU : CONSULT Function (BCM - IMMU)

INFOID:000000009014260

SELF DIAGNOSTIC RESULT

Refer to [BCS-110, "DTC Index"](#).

ACTIVE TEST

DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Test Item | Description |
|-----------|---|
| THEFT IND | This test is able to check security indicator operation [On/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|-------------------|---------|-----------------------------|
| CONFIRM DONGLE ID | — | Dongle ID code can be read. |

BATTERY SAVER

BATTERY SAVER : CONSULT Function (BCM - BATTERY SAVER)

INFOID:000000009014261

DATA MONITOR

| Monitor Item [Unit] | Description |
|-------------------------|--|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| KEY ON SW [On/Off] | Indicates condition of key switch. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |
| DOOR SW-RR [On/Off] | Indicates condition of rear door switch RH. |
| DOOR SW-RL [On/Off] | Indicates condition of rear door switch LH. |
| CDL LOCK SW [On/Off] | Indicates condition of lock signal from door lock and unlock switch. |
| CDL UNLOCK SW [On/Off] | Indicates condition of unlock signal from door lock and unlock switch. |
| KEYLESS LOCK [On/Off] | Indicates condition of lock signal from keyfob. |
| KEYLESS UNLOCK [On/Off] | Indicates condition of unlock signal from keyfob. |
| TRNK/HAT MNTR [On/Off] | Indicates condition of trunk lid switch. |
| KEY CYL LK-SW [On/Off] | Indicates condition of lock signal from door key cylinder switch. |
| KEY CYL UN-SW [On/Off] | Indicates condition of unlock signal from door key cylinder switch. |
| ACC SW [On/Off] | Indicates condition of ignition switch ACC position. |

ACTIVE TEST

| Test item | Description |
|---------------|--|
| BATTERY SAVER | This test is able to check battery saver operation [On/Off]. |

WORK SUPPORT

| Support Item | Setting | Description |
|---------------------|---------|---|
| ROOM LAMP TIMER SET | MODE 3* | 10 min. |
| | MODE 2 | 60 min. |
| | MODE 1 | 15 min. |
| | | Sets interior room lamp battery saver timer operating time. |

* : Initial setting

TRUNK

TRUNK : CONSULT Function (BCM - TRUNK)

INFOID:000000009014262

DATA MONITOR

| Monitor Item [Unit] | Description |
|---------------------|------------------------------------|
| KEY ON SW [On/Off] | Indicates condition of key switch. |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|--------------------------|---|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| VEHICLE SPEED [km/h/mph] | Indicates vehicle speed signal received from combination meter on CAN communication line. |

RETAINED PWR

RETAINED PWR : CONSULT Function (BCM - RETAINED PWR)

INFOID:000000009014263

DATA MONITOR

| Monitor Item [Unit] | Description |
|---------------------|---|
| IGN ON SW [On/Off] | Indicates condition of ignition switch ON position. |
| DOOR SW-DR [On/Off] | Indicates condition of front door switch LH. |
| DOOR SW-AS [On/Off] | Indicates condition of front door switch RH. |

WORK SUPPORT

| Support Item | Setting | Description |
|------------------|---------|---|
| RETAINED PWR SET | MODE3 | 2 min |
| | MODE2 | OFF |
| | MODE1* | 45 sec |
| | | Sets the retained accessory power operating time. |

*: Initial setting

SIGNAL BUFFER

SIGNAL BUFFER : CONSULT Function (BCM - SIGNAL BUFFER)

INFOID:000000009014264

DATA MONITOR

| Monitor Item [Unit] | Description |
|---------------------|---|
| BRAKE SW [On/Off] | Indicates condition of stop lamp switch signal received from ABS actuator and electric unit (control unit) on CAN communication line. |

AIR PRESSURE MONITOR

AIR PRESSURE MONITOR : CONSULT Function (BCM - AIR PRESSURE MONITOR)

INFOID:000000009014265

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs
- Check Intelligent Key relative signal strength
- Confirm vehicle Intelligent Key antenna signal strength

SELF DIAGNOSTIC RESULT

NOTE:

Before performing self diagnostic result, be sure to register the ID, or else the actual malfunction may be different from that displayed on CONSULT.

Refer to [BCS-110, "DTC Index"](#).

DATA MONITOR

DIAGNOSIS SYSTEM (BCM)

[WITHOUT INTELLIGENT KEY SYSTEM]

< SYSTEM DESCRIPTION >

| Monitor Item [Unit] | Description |
|---|---|
| AIR PRESS FL [kPa, kg/cm ² or Psi] | Indicates air pressure of front LH tire. |
| AIR PRESS FR [kPa, kg/cm ² or Psi] | Indicates air pressure of front RH tire. |
| AIR PRESS RR [kPa, kg/cm ² or Psi] | Indicates air pressure of rear RH tire. |
| AIR PRESS RL [kPa, kg/cm ² or Psi] | Indicates air pressure of rear LH tire. |
| ID REGST FL1 [Done/Yet] | Indicates ID registration status of front LH transmitter. |
| ID REGST FR1 [Done/Yet] | Indicates ID registration status of front RH transmitter. |
| ID REGST RR1 [Done/Yet] | Indicates ID registration status of rear RH transmitter. |
| ID REGST RL1 [Done/Yet] | Indicates ID registration status of rear LH transmitter. |
| WARNING LAMP [Off/On] | Indicates condition of low tire pressure warning lamp in combination meter. |
| BUZZER [Off/On] | Indicates condition of buzzer in combination meter. |

ACTIVE TEST

| Test Item | Description |
|-------------------|--|
| WARNING LAMP | This test is able to check tire pressure warning lamp operation [On/Off]. |
| ID REGIST WARNING | This test is able to check ID registration warning chime operation [On/Off]. |
| FLASHER | This test is able to check turn signal lamp operation [Off/LH/RH]. |

WORK SUPPORT

| Support Item | Description |
|--------------|---|
| ID READ | The registered ID number is displayed. |
| ID REGIST | Refer to WT-22, "Description" . |

PANIC ALARM

PANIC ALARM : CONSULT Function (BCM - PANIC ALARM)

INFOID:000000009014266

ACTIVE TEST

| Test Item | Description |
|-----------------------|---|
| VEHICLE SECURITY HORN | This test is able to check panic alarm operation [On]. |
| HEAD LAMP (HI) | This test is able to check head lamp HI operation [On]. |

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

ECU DIAGNOSIS INFORMATION

BCM

Reference Value

INFOID:000000009014267

NOTE:

The Signal Tech II Tool (J-50190) can be used to perform the following functions. Refer to the Signal Tech II User Guide for additional information.

- Activate and display TPMS transmitter IDs
- Display tire pressure reported by the TPMS transmitter
- Read TPMS DTCs
- Register TPMS transmitter IDs
- Test remote keyless entry keyfob relative signal strength

VALUES ON THE DIAGNOSIS TOOL

| Monitor Item | Condition | Value/Status |
|---------------|-------------------------------------|-------------------------------|
| ACC SW | Ignition switch OFF | Off |
| | Ignition switch ACC or ON | On |
| ACC ON SW | Ignition switch OFF | Off |
| | Ignition switch ACC or ON | On |
| AIR COND SW | A/C switch OFF | Off |
| | A/C switch ON | On |
| AIR PRESS FL | Front left tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS FR | Front right tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS RL | Rear left tire air pressure value | kPa, kg/cm ² , psi |
| AIR PRESS RR | Rear right tire air pressure value | kPa, kg/cm ² , psi |
| BRAKE SW | Brake pedal released | Off |
| | Brake pedal depressed | On |
| BUCKLE SW | Seat belt buckle unfastened | Off |
| | Seat belt buckle fastened | On |
| BUZZER | Buzzer in combination meter OFF | Off |
| | Buzzer in combination meter ON | On |
| CDL LOCK SW | Door lock/unlock switch neutral | Off |
| | Door lock/unlock switch LOCK | On |
| CDL UNLOCK SW | Door lock/unlock switch neutral | Off |
| | Door lock/unlock switch UNLOCK | On |
| DOOR SW-AS | Passenger door closed | Off |
| | Passenger door open | On |
| DOOR SW-DR | Driver's door closed | Off |
| | Driver's door open | On |
| DOOR SW-RL | Rear LH door closed | Off |
| | Rear LH door open | On |
| DOOR SW-RR | Rear RH door closed | Off |
| | Rear RH door open | On |
| ENGINE RUN | Engine stopped | Off |
| | Engine running | On |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

| Monitor Item | Condition | Value/Status | |
|----------------|---|--------------|-----|
| FAN ON SIG | Blower fan OFF | Off | A |
| | Blower fan ON | On | |
| FR FOG SW | Front fog lamp switch OFF | Off | B |
| | Front fog lamp switch ON | On | |
| FR WASHER SW | Front washer switch OFF | Off | C |
| | Front washer switch ON | On | |
| FR WIPER LOW | Front wiper switch OFF | Off | |
| | Front wiper switch LO | On | D |
| FR WIPER HI | Front wiper switch OFF | Off | |
| | Front wiper switch HI | On | |
| FR WIPER INT | Front wiper switch OFF | Off | E |
| | Front wiper switch INT | On | |
| FR WIPER STOP | Any position other than front wiper stop position | Off | F |
| | Front wiper stop position | On | |
| HAZARD SW | Hazard switch OFF | Off | |
| | Hazard switch ON | On | G |
| HEAD LAMP SW 1 | Lighting switch OFF | Off | |
| | Lighting switch 1ST | On | H |
| HEAD LAMP SW 2 | Lighting switch OFF | Off | |
| | Lighting switch 2ND | On | I |
| HI BEAM SW | Lighting switch OFF | Off | |
| | Lighting switch HI | On | |
| ID REGST FL1 | ID registration of front left tire incomplete | Yet | J |
| | ID registration of front left tire complete | Done | |
| ID REGST FR1 | ID registration of front right tire incomplete | Yet | |
| | ID registration of front right tire complete | Done | K |
| ID REGST RL1 | ID registration of rear left tire incomplete | Yet | |
| | ID registration of rear left tire complete | Done | L |
| ID REGST RR1 | ID registration of rear right tire incomplete | Yet | |
| | ID registration of rear right tire complete | Done | |
| IGN ON SW | Ignition switch OFF or ACC | Off | BCS |
| | Ignition switch ON | On | |
| IGN SW CAN | Ignition switch OFF or ACC | Off | |
| | Ignition switch ON | On | N |
| INT VOLUME | Intermittent wiper position | 1 - 7 | |
| KEY CYL LK-SW | Key cylinder switch in N position | Off | O |
| | Key cylinder switch in LOCK position | On | |
| KEY CYL UN-SW | Key cylinder switch in N position | Off | |
| | Key cylinder switch in UNLOCK position | On | P |
| KEY ON SW | Key removed from ignition key cylinder | Off | |
| | Key inserted into ignition key cylinder | On | |
| KEYLESS LOCK | LOCK button of keyfob not pressed | Off | |
| | LOCK button of keyfob pressed | On | |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT INTELLIGENT KEY SYSTEM]


| Monitor Item | Condition | Value/Status |
|----------------|---|--------------|
| KEYLESS PANIC | PANIC button of keyfob not pressed | Off |
| | PANIC button of keyfob pressed | On |
| KEYLESS UNLOCK | UNLOCK button of keyfob not pressed | Off |
| | UNLOCK button of keyfob pressed | On |
| PASSING SW | Other than lighting switch PASS | Off |
| | Lighting switch PASS | On |
| PKB SW | Parking brake released | Off |
| | Parking brake engaged | On |
| REAR DEF SW | Rear window defogger switch OFF | Off |
| | Rear window defogger switch ON | On |
| REVERSE SW CAN | Reverse switch OFF | Off |
| | Reverse switch ON | On |
| TAIL LAMP SW | Lighting switch OFF | Off |
| | Lighting switch 1ST | On |
| THERMO AMP | A/C and fan ON switch OFF | Off |
| | A/C and fan ON switch ON | On |
| TRNK OPEN MNTR | Trunk lid switch OFF | Off |
| | Trunk lid switch ON | On |
| TRNK/HAT MNTR | Trunk lid closed | Off |
| | Trunk lid open | On |
| TURN SIGNAL L | Turn signal switch OFF | Off |
| | Turn signal switch LH | On |
| TURN SIGNAL R | Turn signal switch OFF | Off |
| | Turn signal switch RH | On |
| VEHICLE SPEED | While driving, equivalent to speedometer reading | mph, km/h |
| WARNING LAMP | Low tire pressure warning lamp in combination meter OFF | Off |
| | Low tire pressure warning lamp in combination meter ON | On |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

TERMINAL LAYOUT








PHYSICAL VALUES

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|----------------|------------------|--------------------|--------------------|
| + | - | Signal name | Input/ Output | | |
| 2 (L) | Ground | Input 5 signal | Input | Combination switch | 0 V |
| | | | | OFF | |
| | | | | TURN RH | |
| | | | | HEADLAMP 1 | |
| | | | | TAIL LAMP | 1.0 V |

BCM

< ECU DIAGNOSIS INFORMATION >





[WITHOUT INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|----------------------------------|------------------|------------------------|---|---|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 3 (GR) | Ground | Input 4 signal | Input | Combination switch | OFF | 0 V |
| | | | | | TURN LH |  |
| | | | | | PASSING | |
| | | | | | HEADLAMP 2 | |
| | | | | | FR FOG | |
| | | | | | 1.0 V | |
| 4 (BR) | Ground | Input 3 signal | Input | Combination switch | OFF | 0 V |
| | | | | | FR WIPER LOW |  |
| | | | | | FR WIPER INT (any intermittent position) | |
| | | | | | 1.0 V | |
| 5 (O) | Ground | Input 2 signal | Input | Combination switch | OFF | 0 V |
| | | | | | FR WASHER |  |
| | | | | | Wiper intermittent dial 1 | |
| | | | | | Wiper intermittent dial 5 | |
| | | | | | Wiper intermittent dial 6 | |
| | | | | | 1.0 V | |
| 6 (W) | Ground | Input 1 signal | Input | Combination switch | OFF | 0 V |
| | | | | | FR WIPER HI |  |
| | | | | | Wiper intermittent dial 1 | |
| | | | | | Wiper intermittent dial 2 | |
| | | | | | Wiper intermittent dial 3 | |
| | | | | | Wiper intermittent dial 6 | |
| | | | | | Wiper intermittent dial 7 | |
| | | | | | 1.0 V | |
| 7 (L) | Ground | Key cylinder unlock sw signal | Input | Key cylinder switch | N position |  |
| | | | | | UNLOCK position | 0 V |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|----------------------------------|------------------|--|---|--|
| + | - | Signal name | Input/ Output | | | |
| 8 (V) | Ground | Key cylinder lock sw signal | Input | Key cylinder switch | N position |  <small>PKIB4960J</small> 7.0 - 8.0 V |
| | | | | LOCK position | 0 V | |
| 9 (R) | Ground | Brake sw signal | Input | Stop lamp switch | OFF (brake pedal re- leased) | 0 V |
| | | | | ON (brake pedal de- pressed) | Battery voltage | |
| 10 (W) | Ground | Rear defogger sw signal | Input | Rear window defogger switch | OFF | Battery voltage |
| | | | | ON | 0 V | |
| 11 (G) | Ground | ACC switch signal | Input | Ignition switch | OFF | 0 V |
| | | | | ACC or ON | Battery voltage | |
| 12 (GR) | Ground | Central door lock sw signal | Input | Door lock and unlock switch | N position |  <small>JPMIA0012GB</small> 1.0 - 1.5 V |
| | | | | LOCK position | 0 V | |
| 13 (BR) | Ground | Central door unlock sw signal | Input | Door lock and unlock switch | N position |  <small>JPMIA0012GB</small> 1.0 - 1.5 V |
| | | | | UNLOCK position | 0 V | |
| 18 (V) | Ground | Keyless gnd signal | Input | Ignition switch ON | | 0 V |
| 19 (BR) | Ground | Keyless tuner power supply | Input | Ignition switch OFF | Key inserted into ignition key cylinder | 0 V |
| | | | | Key removed from ignition key cylinder (Any door open) | 5 V | |
| | | | | Key removed from ignition key cylinder (Any door closed) |  <small>JPMIA0338JP</small> | |





A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >






[WITHOUT INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|--|------------------|--------------------------|--|--|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 20 (LG) | Ground | Keyless tuner signal | Input | Ignition switch OFF | Key inserted into ignition key cylinder | 0 V |
| | | | | | Waiting |  PIIB7728J |
| | | | | | Signal receiving |  PIIB7729J |
| 21 (P) | Ground | Immobilizer one way communication (clock) signal | Input/ Output | While waiting | Turn ignition switch ON. | Turn ignition switch ON: Pointer of tester should move. |
| 23 (Y) | Ground | Security indicator output signal | Input | Security indica- tor | ON | 0 V |
| | | | | | Blinking (Ignition switch OFF) |  JPMIA0014GB |
| | | | | | OFF | Battery voltage |
| 24 (SB) | Ground | Audio/dongle link (serial) signal | Input/ Output | Ignition switch OFF. | | 5 V |
| 25 (LG) | Ground | Immobilizer two way communication sig- nal | Input/ Output | While waiting | Turn ignition switch ON. | Turn ignition switch ON: Pointer of tester should move. |
| 27 (Y) | Ground | Air con sw signal | Input | A/C and fan ON switch | OFF | Battery voltage |
| | | | | | ON | 0 V |
| 28 (LG) | Ground | Blower fan sw signal | Input | Fan switch | OFF | 0 V |
| | | | | | I, II, III or IIII |  PKIB4960J |
| 29 (SB) | Ground | Hazard sw signal | Input | Hazard switch | OFF | Battery voltage |
| | | | | | ON | 0 - 1.5 V |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|----------------------------|------------------|----------------------------|---------------------------|--|
| + | - | Signal name | Input/ Output | | | |
| 30 (L) | Ground | Trunk lid opener switch | Input | Trunk lid opener switch | Depressed | 0 V |
| | | | | | Released |  <p style="text-align: center;">1.0 - 1.5 V</p> |
| 32 (LG) | Ground | Output 5 signal | Output | Combination switch | OFF |  <p style="text-align: center;">7.0 - 8.0 V</p> |
| | | | | | FR FOG |  <p style="text-align: center;">1.2 V</p> |
| | | | | | Wiper intermittent dial 1 | |
| | | | | | Wiper intermittent dial 2 | |
| | | | | | Wiper intermittent dial 6 | |
| Wiper intermittent dial 7 | | | | | | |
| 33 (Y) | Ground | Output 4 signal | Output | Combination switch | OFF |  <p style="text-align: center;">7.0 - 8.0 V</p> |
| | | | | | TAIL LAMP |  <p style="text-align: center;">1.2 V</p> |
| | | | | | Wiper intermittent dial 1 | |
| | | | | | Wiper intermittent dial 5 | |
| | | | | | Wiper intermittent dial 6 | |







A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) | |
|------------------------------|--------|-----------------|------------------|-----------------------|---|---|
| + | - | Signal name | Input/ Output | | | |
| 34 (V) | Ground | Output 3 signal | Output | Combination switch | OFF |  <p style="text-align: right; font-size: small;">PKIB4960J</p> |
| | | | | | HEADLAMP 2 |  <p style="text-align: right; font-size: small;">PKIB4958J</p> |
| | | | | | HI BEAM | |
| | | | | | Wiper intermittent dial 1 | |
| | | | | | Wiper intermittent dial 2 | |
| Wiper intermittent dial 3 | 1.2 V | | | | | |
| 35 (R) | Ground | Output 2 signal | Output | Combination switch | OFF |  <p style="text-align: right; font-size: small;">PKIB4960J</p> |
| | | | | | FR WIPER HI |  <p style="text-align: right; font-size: small;">PKIB4958J</p> |
| | | | | | FR WIPER INT (any intermittent position) | |
| | | | | | PASSING | |
| HEADLAMP 1 | 1.2 V | | | | | |
| 36 (SB) | Ground | Output 1 signal | Output | Combination switch | OFF |  <p style="text-align: right; font-size: small;">PKIB4960J</p> |
| | | | | | FR WASHER |  <p style="text-align: right; font-size: small;">PKIB4958J</p> |
| | | | | | FR WIPER LOW | |
| | | | | | TURN LH | |
| TURN RH | 1.2 V | | | | | |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | Value (Approx.) |
|------------------------------|--------|----------------------------------|------------------|--|---|
| + | - | Signal name | Input/ Output | | |
| 37 (GR) | Ground | Key sw signal | Input | Ignition switch | Battery voltage |
| | | | | Ignition key inserted into ignition key cylinder | 0 V |
| 38 (R) | Ground | Ign sw signal | Input | Ignition switch | 0 V |
| | | | | OFF or ACC | Battery voltage |
| 39 (L) | Ground | CAN-H signal | Input/ Output | — | — |
| 40 (P) | Ground | CAN-L signal | Input/ Output | — | — |
| 41 (LG) | Ground | Flasher output (LEFT) signal | Output | Ignition switch ON | 0 V |
| | | | | Turn signal switch OFF | <p style="text-align: center;">6.5 V (Turn signal lamp turn on: 9 - 16 V)</p> |
| 42 (O) | Ground | Flasher output (RIGHT) signal | Output | Ignition switch ON | 0 V |
| | | | | Turn signal switch OFF | <p style="text-align: center;">6.5 V (Turn signal lamp turn on: 9 - 16 V)</p> |
| 45 (R) | Ground | Door sw (AS) signal | Input | Front door switch RH | <p style="text-align: center;">7.0 - 8.0 V</p> |
| | | | | OFF (front door RH closed) | 0 V |
| 46 (Y) | Ground | Door sw (DR) signal | Input | Front door switch LH | <p style="text-align: center;">7.0 - 8.0 V</p> |
| | | | | OFF (front door LH closed) | 0 V |
| | | | | ON (front door LH open) | 0 V |




A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|-----------------------------------|------------------|---|---|--|
| + | - | Signal name | Input/ Output | | | |
| 47 (GR) | Ground | Door sw (RL) signal | Input | Rear door switch LH | OFF (rear door LH closed) |  <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p> |
| | | | | | ON (rear door LH open) | 0 V |
| 48 (P) | Ground | Door sw (RR) signal | Input | Rear door switch RH | OFF (rear door RH closed) |  <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p> |
| | | | | | ON (rear door RH open) | 0 V |
| 50 (LG) | Ground | Luggage lamp out- put signal | Output | Trunk lid | Closed (trunk room lamp OFF) | Battery voltage |
| | | | | | Open (trunk room lamp ON) | 0 - 1 V |
| 51 (V) | Ground | Tr room lamp sw sig- nal | Input | Trunk lid switch | OFF (Trunk lid closed) |  <p style="text-align: right; font-size: small;">PKIB4960J</p> <p style="text-align: center;">7.0 - 8.0 V</p> |
| | | | | | ON (Trunk lid open) | 0 V |
| 55 (GR) | Ground | Trunk open output | Output | Trunk opener request switch released | Trunk lid actuator idle | 0 V |
| | | | | Trunk opener request switch depressed | Trunk lid actuator activat- ed | Battery voltage |
| 60 (BR) | Ground | Room lamp output signal | Output | Interior room lamp or map lamp | OFF | Battery voltage |
| | | | | | ON | Battery voltage |
| | | | | | DOOR | 0 - 1 V |
| 62 (P) | Ground | Battery saver output signal | Output | Interior room lamp battery saver activated | 0 V | |
| | | | | Interior room lamp battery saver not activat- ed | Battery voltage | |
| 63 (O) | Ground | Battery (FUUSE) | Input | Ignition switch OFF | Battery voltage | |
| 64 (SB) | Ground | Door unlock output (DR) signal | Output | Front door lock actuator LH | Actuated to UNLOCK po- sition | Battery voltage |
| | | | | | Other than actuated to UNLOCK position | 0 V |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

| Terminal No. (Wire color) | | Description | | Condition | | Value (Approx.) |
|------------------------------|--------|--|------------------|--|--|--------------------|
| | | Signal name | Input/ Output | | | |
| + | - | | | | | |
| 65 (B) | Ground | Gnd | Output | Ignition switch ON | | 0 V |
| 66 (O) | Ground | Door lock output signal | Output | All door lock actuators | Actuated to LOCK position | Battery voltage |
| | | | | | Other than actuated to LOCK position | 0 V |
| 67 (SB) | Ground | Door unlock output (AS, RR, RL) signal | Output | Front door lock actuator RH, rear door lock actuator RH and rear door lock actuator LH | Actuated to UNLOCK position | Battery voltage |
| | | | | | Other than actuated to UNLOCK position | 0 V |
| 68 (L) | Ground | Power window power supply (RAP) signal | Output | Ignition switch ON | | Battery voltage |
| 69 (G) | Ground | Power window power supply (BATT) | Output | Push-button ignition switch | OFF | Battery voltage |
| 70 (Y) | Ground | Battery (F/L) | Input | Ignition switch OFF | | Battery voltage |

Fail-safe

INFOID:000000009014268

FAIL-SAFE CONTROL BY DTC

BCM performs fail-safe control when any DTC are detected.

| Display contents of CONSULT | Fail-safe | Cancellation |
|-----------------------------|-------------------------|--------------------------|
| B2190: NATS ANTENNA AMP | Inhibit engine cranking | Erase DTC |
| B2191: DIFFERENCE OF KEY | Inhibit engine cranking | Erase DTC |
| B2192: ID DISCORD BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2193: CHAIN OF BCM-ECM | Inhibit engine cranking | Erase DTC |
| B2195: ANTI SCANNING | Inhibit engine cranking | Ignition switch ON → OFF |
| B2196: DONGLE NG | Inhibit engine cranking | Erase DTC |

FAIL-SAFE CONTROL OF COMBINATION SWITCH READING FUNCTION CAUSED BY LOW POWER SUPPLY VOLTAGE

If voltage of battery power supply lower, BCM maintains combination switch reading to the status when input voltage is less than approximately 9 V.

NOTE:

When voltage of battery power supply is approximately 9 V or more, combination switch reading function returns to normal operation.

DTC Inspection Priority Chart

INFOID:000000009014269

If some DTCs are displayed at the same time, perform inspections one by one based on the following priority chart.

| Priority | DTC |
|----------|---|
| 1 | <ul style="list-style-type: none"> U1000: CAN COMM U1010: CONTROL UNIT (CAN) |
| 2 | <ul style="list-style-type: none"> B2190: NATS ANTENNA AMP B2191: DIFFERENCE OF KEY B2192: ID DISCORD BCM-ECM B2193: CHAIN OF BCM-ECM B2195: ANTI SCANNING B2196: DONGLE NG |
| 3 | <ul style="list-style-type: none"> C1704: LOW PRESSURE FL C1705: LOW PRESSURE FR C1706: LOW PRESSURE RR C1707: LOW PRESSURE RL C1708: [NO DATA] FL C1709: [NO DATA] FR C1710: [NO DATA] RR C1711: [NO DATA] RL C1716: [PRESS DATA ERR] FL C1717: [PRESS DATA ERR] FR C1718: [PRESS DATA ERR] RR C1719: [PRESS DATA ERR] RL C1729: VHCL SPEED SIG ERR |

DTC Index

INFOID:000000009014270

NOTE:

- Details of time display
- CRNT: Displays when there is a malfunction now or after returning to the normal condition until turning ignition switch OFF → ON again.
- 1 - 39: Displayed if any previous malfunction is present when current condition is normal. It increases like 1 → 2 → 3...38 → 39 after returning to the normal condition whenever ignition switch OFF → ON. The counter remains at 39 even if the number of cycles exceeds it. It is counted from 1 again when turning ignition switch OFF → ON after returning to the normal condition if the malfunction is detected again.

| CONSULT display | Fail-safe | Low tire pressure warning lamp ON | Reference |
|---------------------------|-----------|-----------------------------------|-------------------------|
| U1000: CAN COMM | — | — | BCS-119 |
| U1010: CONTROL UNIT (CAN) | — | — | BCS-120 |
| B2190: NATS ANTENNA AMP | × | — | SEC-181 |
| B2191: DIFFERENCE OF KEY | × | — | SEC-184 |
| B2192: ID DISCORD BCM-ECM | × | — | SEC-185 |
| B2193: CHAIN OF BCM-ECM | × | — | SEC-187 |
| B2195: ANTI SCANNING | × | — | SEC-188 |
| B2196: DONGLE NG | × | — | SEC-189 |
| C1704: LOW PRESSURE FL | — | × | WT-25 |
| C1705: LOW PRESSURE FR | — | × | |
| C1706: LOW PRESSURE RR | — | × | |
| C1707: LOW PRESSURE RL | — | × | |
| C1708: [NO DATA] FL | — | × | WT-26 |
| C1709: [NO DATA] FR | — | × | |
| C1710: [NO DATA] RR | — | × | |
| C1711: [NO DATA] RL | — | × | |

BCM

< ECU DIAGNOSIS INFORMATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

| CONSULT display | Fail-safe | Low tire pressure warning lamp ON | Reference | |
|----------------------------|-----------|-----------------------------------|-----------------------|---|
| C1716: [PRESS DATA ERR] FL | — | × | WT-29 | A |
| C1717: [PRESS DATA ERR] FR | — | × | | B |
| C1718: [PRESS DATA ERR] RR | — | × | | |
| C1719: [PRESS DATA ERR] RL | — | × | WT-30 | C |
| C1729: VHCL SPEED SIG ERR | — | × | | |

A

B

C

D

E

F

G

H

I

J

K


L

BCS

N

O

P




A
B
C
D
E
F
G
H
I
J
K
L
M
N
O
P

BCS

BCM (BODY CONTROL MODULE) CONNECTORS - WITHOUT INTELLIGENT KEY SYSTEM

| | |
|-----------------|--|
| Connector No. | M20 |
| Connector Name | BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM) |
| Connector Color | WHITE |



| | |
|-----------------|--|
| Connector No. | M21 |
| Connector Name | BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM) |
| Connector Color | WHITE |



| | | | | | | | | | | | | | | | | | | | |
|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|----|
| 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 | 14 | 15 | 16 | 17 | 18 | 19 | 20 |
| 21 | 22 | 23 | 24 | 25 | 26 | 27 | 28 | 29 | 30 | 31 | 32 | 33 | 34 | 35 | 36 | 37 | 38 | 39 | 40 |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------------------------------|
| 56 | - | - |
| 57 | - | - |
| 58 | - | - |
| 59 | - | - |
| 60 | BR | ROOM LAMP OUTPUT |
| 61 | - | - |
| 62 | P | BATTERY SAVER OUTPUT |
| 63 | O | BATTERY (FUSE) |
| 64 | SB | DOOR UNLOCK COMMON (DR) |
| 65 | B | GND |
| 66 | O | DOOR LOCK OUTPUT |
| 67 | SB | DOOR UNLOCK OUTPUT (AS, RR, RL) |
| 68 | L | POWER WINDOW POWER SUPPLY (RAP) |
| 69 | G | POWER WINDOW POWER SUPPLY (BATTERY) |
| 70 | Y | BATTERY (F/L) |


| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---------------------------------------|
| 1 | - | - |
| 2 | L | INPUT 5 |
| 3 | GR | INPUT 4 |
| 4 | BR | INPUT 3 |
| 5 | O | INPUT 2 |
| 6 | W | INPUT 1 |
| 7 | L | KEY CYLINDER UNLOCK SW |
| 8 | V | KEY CYLINDER UNLOCK SW |
| 9 | R | BRAKE SW |
| 10 | W | REAR DEFOGGER SW |
| 11 | G | ACC SW |
| 12 | GR | CENTRAL DOOR LOCK SW |
| 13 | BR | CENTRAL DOOR UNLOCK SW |
| 14 | SB | AUTO LIGHT SENSOR INPUT 1 (& 2) |
| 15 | - | - |
| 16 | O | MR OUTPUT |
| 17 | Y | AUTO LIGHT SENSOR POWER SUPPLY OUTPUT |

| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|---|
| 18 | V | KEYLESS & AUTO LIGHT SENSOR GND |
| 19 | BR | KEYLESS TUNER POWER |
| 20 | LG | KEYLESS TUNER SIGNAL |
| 21 | P | IMMOBILIZER ONE WAY COMMUNICATION (CLOCK) |
| 22 | - | - |
| 23 | Y | SECURITY INDICATOR OUTPUT |
| 24 | SB | AUDIO/DONGLE LINK (SERIAL) |
| 25 | LG | IMMOBILIZER TWO WAY COMMUNICATION |
| 26 | - | - |
| 27 | Y | AIRCON SW |
| 28 | LG | BLOWER FAN SW |
| 29 | SB | HAZARD SW |
| 30 | L | TRUNK/BACK DOOR OPENER SW |
| 31 | - | - |
| 32 | LG | COMBINATION SW OUTPUT 5 |
| 33 | Y | COMBINATION SW OUTPUT 4 |
| 34 | V | COMBINATION SW OUTPUT 3 |
| 35 | R | COMBINATION SW OUTPUT 2 |
| 36 | SB | COMBINATION SW OUTPUT 1 |
| 37 | GR | KEY SW |
| 38 | R | IGN SW |
| 39 | L | CAN-H |
| 40 | P | CAN-L |

AAM1A1355GB


A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

| | |
|-----------------|--|
| Connector No. | B57 |
| Connector Name | BCM (BODY CONTROL MODULE) (WITHOUT INTELLIGENT KEY SYSTEM) |
| Connector Color | BLACK |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|------------------------|
| 41 | LG | FLASHER OUTPUT (LEFT) |
| 42 | O | FLASHER OUTPUT (RIGHT) |
| 43 | - | - |
| 44 | - | - |
| 45 | R | DOOR SW (AS) |
| 46 | Y | DOOR SW (DR) |
| 47 | GR | DOOR SW (RL) |
| 48 | P | DOOR SW (RR) |
| 49 | - | - |
| 50 | LG | LUGGAGE LAMP OUTPUT |
| 51 | V | TRUNK |
| 52 | - | - |
| 53 | - | - |
| 54 | - | - |
| 55 | GR | TRUNK OPEN OUTPUT |

| | |
|-----------------|--------------------|
| Connector No. | M28 |
| Connector Name | COMBINATION SWITCH |
| Connector Color | WHITE |



| Terminal No. | Color of Wire | Signal Name |
|--------------|---------------|-------------|
| 1 | G | - |
| 2 | GR | - |
| 5 | BR | - |
| 6 | B | - |
| 7 | V | - |
| 8 | L | - |
| 9 | R | - |
| 10 | Y | - |
| 11 | SB | - |
| 12 | W | - |
| 13 | LG | - |
| 14 | O | - |

BCS

AAM1A1356GB

BASIC INSPECTION

INSPECTION AND ADJUSTMENT

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM)

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Description

INFOID:000000009014272

BEFORE REPLACEMENT

When replacing BCM, save or print current vehicle specification with CONSULT configuration before replacement.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

AFTER REPLACEMENT

CAUTION:

- When replacing BCM, you must perform "After Replace ECU" with CONSULT.
- Complete the procedure of "After Replace ECU" in order.
- If you set incorrect "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- When replacing BCM, perform the system initialization (NATS).

ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT (BCM) : Work Procedure

INFOID:000000009014273

1. SAVING VEHICLE SPECIFICATION

CONSULT

Enter "Re/Programming, Configuration" and perform "Before Replace ECU" to save or print current vehicle specification.

NOTE:

If "Before Replace ECU" cannot be used, use the "After Replace ECU" or "Manual Configuration" after replacing BCM.

>> GO TO 2.

2. REPLACE BCM

Replace BCM. Refer to [BCS-127, "Removal and Installation"](#).

>> GO TO 3.

3. WRITING VEHICLE SPECIFICATION

CONSULT

1. Enter "Re/Programming, Configuration".
2. If "Before Replace ECU" operation was performed, automatically an "Operation Log Selection" screen will be displayed. Select the applicable file from the "Saved Data List" and press "Confirm" to write vehicle specification. Refer to [BCS-117, "CONFIGURATION \(BCM\) : Work Procedure"](#).
3. If "Before Replace ECU" operation was not performed, select "After Replace ECU" or "Manual Configuration" to write vehicle specification. Refer to [BCS-117, "CONFIGURATION \(BCM\) : Work Procedure"](#).

>> GO TO 4.

4. INITIALIZE BCM (NATS)

Perform BCM initialization. (NATS)

>> Work End.

CONFIGURATION (BCM)

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

CONFIGURATION (BCM) : Description

INFOID:000000009014274

Vehicle specification needs to be written with CONSULT because it is not written after replacing BCM. Configuration has three functions as follows:

| Function | Description |
|--------------------------|---|
| "Before Replace ECU" | <ul style="list-style-type: none">• Reads the vehicle configuration of current BCM.• Saves the read vehicle configuration. |
| "After Replace ECU" | Writes the vehicle configuration with manual selection. |
| "Select Saved Data List" | Writes the vehicle configuration with saved data. |

CAUTION:

- When replacing BCM, you must perform "Select Saved Data List" or "After Replace ECU" with CONSULT.
- Complete the procedure of "Select Saved Data List" or "After Replace ECU" in order.
- If you set incorrect "Select Saved Data List" or "After Replace ECU", incidents might occur.
- Configuration is different for each vehicle model. Confirm configuration of each vehicle model.
- Never perform "Select Saved Data List" or "After Replace ECU" except for new BCM.

CONFIGURATION (BCM) : Work Procedure

INFOID:000000009014275

1. WRITING MODE SELECTION

CONSULT

Select "Reprogramming, Configuration" of BCM.

When writing saved data>>GO TO 2.
When writing manually>>GO TO 3.

2. PERFORM "SAVED DATA LIST"

CONSULT

Automatically "Operation Log Selection" window will display if "Before Replace ECU" was performed. Select applicable file from the "Save Data List" and press "Confirm".

>> Work End.

3. PERFORM "AFTER REPLACE ECU" OR "MANUAL CONFIGURATION"

CONSULT

1. Select "After Replace ECU" or "Manual Configuration".
2. Identify the correct model and configuration list. Refer to [BCS-118, "CONFIGURATION \(BCM\) : Configuration List"](#).
3. Confirm and/or change setting value for each item.

CAUTION:

Thoroughly read and understand the vehicle specification. ECU control may not operate normally if the setting is not correct.

4. Select "Next".

CAUTION:

Make sure to select "Next", confirm each setting value and press "OK" even if the indicated configuration of brand new BCM is same as the desirable configuration. If not, configuration which is set automatically by selecting vehicle model cannot be memorized.

5. When "Completed", select "End".

>> GO TO 4.

4. OPERATION CHECK

Confirm that each function controlled by BCM operates normally.

>> Work End.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

INSPECTION AND ADJUSTMENT

< BASIC INSPECTION >

[WITHOUT INTELLIGENT KEY SYSTEM]

CONFIGURATION (BCM) : Configuration List

INFOID:000000009014276

CAUTION:

Thoroughly read and understand the vehicle specification. Incorrect settings may result in abnormal control of ECU.

| SETTING ITEM | |
|---------------------|-----------------|
| Items | Setting value |
| CAN CONNECTION UNIT | MODE4 ⇔ WITHOUT |
| BLOWE FAN SIG | MODE2 |

⇔: Items which confirm vehicle specifications

U1000 CAN COMM

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

DTC/CIRCUIT DIAGNOSIS

U1000 CAN COMM

Description

INFOID:000000009014277

Refer to [LAN-7, "CAN COMMUNICATION SYSTEM : System Description"](#).

DTC Logic

INFOID:000000009014278

DTC DETECTION LOGIC

NOTE:

U1000 can be set if a module harness was disconnected and reconnected, perhaps during a repair. Confirm that there are actual CAN diagnostic symptoms and a present DTC by performing the Self Diagnostic Result procedure.

| CONSULT Display | DTC Detection Condition | Possible Cause |
|-----------------------------|--|---|
| CAN COMM CIRCUIT [U1000] | When any listed module cannot communicate with CAN communication signal continuously for 2 seconds or more with ignition switch ON | In CAN communication system, any item (or items) of the following listed below is malfunctioning. <ul style="list-style-type: none">• Transmission• Receiving (ECM)• Receiving (VDC/TCS/ABS)• Receiving (METER/M&A)• Receiving (TCM)• Receiving (IPDM E/R) |

Diagnosis Procedure

INFOID:000000009014279

1. PERFORM SELF DIAGNOSTIC RESULT

1. Turn ignition switch ON and wait for 2 second or more.
2. Check "SELF- DIAG RESULTS".

Is "CAN COMM CIRCUIT" displayed?

- YES >> Perform CAN Diagnosis as described in DIAGNOSIS section of CONSULT Operation Manual.
NO >> Refer to [GI-43, "Intermittent Incident"](#).

A
B
C
D
E
F
G
H
I
J
K
L

BCS

U1010 CONTROL UNIT (CAN)

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

U1010 CONTROL UNIT (CAN)

DTC Logic

INFOID:000000009014280

DTC DETECTION LOGIC

| CONSULT Display | DTC Detection Condition | Possible Cause |
|-------------------------------|--|----------------|
| CONTROL UNIT (CAN) [U1010] | BCM detected internal CAN communication circuit malfunction. | BCM |

Diagnosis Procedure

INFOID:000000009014281

1. REPLACE BCM

When DTC "U1010" is detected, replace BCM.

>> Replace BCM. Refer to [BCS-127. "Removal and Installation"](#).

POWER SUPPLY AND GROUND CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

POWER SUPPLY AND GROUND CIRCUIT

Diagnosis Procedure

INFOID:000000009014282

Regarding Wiring Diagram information, refer to [BCS-112. "Wiring Diagram"](#).

1. CHECK FUSES AND FUSIBLE LINK

Check that the following fuses and fusible link are not blown.

| Terminal No. | Signal name | Fuses and fusible link No. |
|--------------|---------------------------|----------------------------|
| 63 | Battery power supply | 12 (10A) |
| 70 | | G (40A) |
| 11 | Ignition switch ACC or ON | 18 (10A) |

Is the fuse blown?

YES >> Replace the blown fuse or fusible link after repairing the affected circuit.

NO >> GO TO 2.

2. CHECK POWER SUPPLY CIRCUIT

1. Turn ignition switch OFF.
2. Disconnect BCM connectors.
3. Check voltage between BCM connector and ground.

| BCM | | Ground | Ignition switch position | | |
|-----------|----------|--------|--------------------------|-----------------|-----------------|
| Connector | Terminal | | OFF | ACC | ON |
| M20 | 63 | — | Battery voltage | Battery voltage | Battery voltage |
| | 70 | | | | |
| M21 | 11 | — | 0 V | Battery voltage | Battery voltage |

Is the inspection result normal?

YES >> GO TO 3.

NO >> Repair harness or connector.

3. CHECK GROUND CIRCUIT

Check continuity between BCM connector and ground.

| BCM | | Ground | Continuity |
|-----------|----------|--------|------------|
| Connector | Terminal | | |
| M20 | 65 | — | Yes |

Is the inspection result normal?

YES >> Inspection End.

NO >> Repair harness or connector.

COMBINATION SWITCH INPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

COMBINATION SWITCH INPUT CIRCUIT

Diagnosis Procedure

INFOID:000000009014283

Regarding Wiring Diagram information, refer to [BCS-112. "Wiring Diagram"](#).

1. CHECK INPUT 1 - 5 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM and combination switch connectors.
3. Check continuity between BCM connector and combination switch connector.

| Combination switch signal | BCM | | Combination switch | | Continuity |
|---------------------------|-----------|----------|--------------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| INPUT 1 | M21 | 36 | M28 | 11 | Yes |
| INPUT 2 | | 35 | | 9 | |
| INPUT 3 | | 34 | | 7 | |
| INPUT 4 | | 33 | | 10 | |
| INPUT 5 | | 32 | | 13 | |

Is the inspection result normal?

- YES >> GO TO 2.
NO >> Repair harness or connectors.

2. CHECK INPUT 1 - 5 CIRCUIT FOR SHORT

Check for continuity between BCM connector and ground.

| Combination switch signal | BCM | | Ground | Continuity |
|---------------------------|-----------|----------|--------|------------|
| | Connector | Terminal | | |
| INPUT 1 | M21 | 36 | | No |
| INPUT 2 | | 35 | | |
| INPUT 3 | | 34 | | |
| INPUT 4 | | 33 | | |
| INPUT 5 | | 32 | | |

Is the inspection result normal?

- YES >> Repair harness or connectors.
NO >> GO TO 3.

3. CHECK BCM OUTPUT VOLTAGE

1. Connect BCM connector.
2. Check voltage between BCM connector and ground.

COMBINATION SWITCH INPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

| BCM signal | Terminals | | Voltage |
|------------|-----------|----------|---------|
| | (+) | (-) | |
| | BCM | | |
| | Connector | Terminal | |
| OUTPUT 1 | M21 | 36 | Ground |
| OUTPUT 2 | | 35 | |
| OUTPUT 3 | | 34 | |
| OUTPUT 4 | | 33 | |
| OUTPUT 5 | | 32 | |

Refer to [BCS-98, "Reference Value"](#).

Is the inspection result normal?

- YES >> Replace combination switch.
- NO >> Replace BCM. Refer to [BCS-127, "Removal and Installation"](#).

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

COMBINATION SWITCH OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

COMBINATION SWITCH OUTPUT CIRCUIT

Diagnosis Procedure

INFOID:00000009014284

Regarding Wiring Diagram information, refer to [BCS-112. "Wiring Diagram"](#).

1. CHECK OUTPUT 1 - 5 CIRCUIT FOR OPEN

1. Turn ignition switch OFF.
2. Disconnect BCM and combination switch connectors.
3. Check continuity between BCM connector and combination switch connector.

| Combination switch signal | BCM | | Combination switch | | Continuity |
|---------------------------|-----------|----------|--------------------|----------|------------|
| | Connector | Terminal | Connector | Terminal | |
| OUTPUT 1 | M21 | 6 | M28 | 12 | Yes |
| OUTPUT 2 | | 5 | | 14 | |
| OUTPUT 3 | | 4 | | 5 | |
| OUTPUT 4 | | 3 | | 2 | |
| OUTPUT 5 | | 2 | | 8 | |

Is the inspection result normal?

YES >> GO TO 2.

NO >> Repair harness or connectors.

2. CHECK OUTPUT 1 - 5 CIRCUIT FOR SHORT

Check for continuity between BCM connector and ground.

| Combination switch signal | BCM | | Ground | Continuity |
|---------------------------|-----------|----------|--------|------------|
| | Connector | Terminal | | |
| OUTPUT 1 | M21 | 6 | Ground | No |
| OUTPUT 2 | | 5 | | |
| OUTPUT 3 | | 4 | | |
| OUTPUT 4 | | 3 | | |
| OUTPUT 5 | | 2 | | |

Is the inspection result normal?

YES >> Repair harness or connectors.

NO >> GO TO 3.

3. CHECK BCM INPUT SIGNAL

1. Connect BCM and combination switch connectors.
2. Turn ON any switch in the system that is malfunctioning.
3. Check voltage between BCM connector and ground.

COMBINATION SWITCH OUTPUT CIRCUIT

< DTC/CIRCUIT DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

| BCM signal | Terminals | | Voltage | |
|------------|-----------|----------|--|--------|
| | (+) | | | (-) |
| | BCM | | | Ground |
| | Connector | Terminal | | |
| INPUT 1 | M21 | 6 | Refer to BCS-98 . " Reference Value ". | |
| INPUT 2 | | 5 | | |
| INPUT 3 | | 4 | | |
| INPUT 4 | | 3 | | |
| INPUT 5 | | 2 | | |

Is the inspection result normal?

- Yes >> Replace BCM. Refer to [BCS-127](#). "[Removal and Installation](#)".
- No >> Replace combination switch.

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

COMBINATION SWITCH SYSTEM SYMPTOMS

< SYMPTOM DIAGNOSIS >

[WITHOUT INTELLIGENT KEY SYSTEM]

SYMPTOM DIAGNOSIS

COMBINATION SWITCH SYSTEM SYMPTOMS

Symptom Table

INFOID:000000009014285

1. Perform the data monitor of CONSULT to check for any malfunctioning item.
2. Check the malfunction combinations.

Malfunction item: ×

| Malfunction combination | Data monitor item | | | | | | | | | | |
|-------------------------|---|--------------|--------------|--------------|---------------|---------------|--------------|------------|----------------|----------------|------------|
| | FR WIPER HI | FR WIPER LOW | FR WASHER SW | FR WIPER INT | TURN SIGNAL R | TURN SIGNAL L | TAIL LAMP SW | HI BEAM SW | HEAD LAMP SW 1 | HEAD LAMP SW 2 | PASSING SW |
| A | | × | × | | × | × | | | | | |
| B | × | | | × | | | | | × | | × |
| C | | | | | | | | × | | × | |
| D | | | | | | | × | | | | |
| E | | | | | | | | | | | |
| F | × | | | | | | | | | | |
| G | | | × | | | | | | | | |
| H | | × | | × | | | | | | | |
| I | | | | | | × | | | | × | × |
| J | | | | | × | | × | × | × | | |
| K | All Items | | | | | | | | | | |
| L | If only one item is detected or the item is not applicable to the combinations A to K | | | | | | | | | | |

3. Identify the malfunctioning part from the agreed combination and repair or replace the part.

| Malfunction combination | Malfunctioning part | Repair or replace |
|-------------------------|-------------------------------------|--|
| A | Combination switch INPUT 1 circuit | Inspect the combination switch input circuit applicable to the malfunctioning part. Refer to BCS-122, "Diagnosis Procedure" . |
| B | Combination switch INPUT 2 circuit | |
| C | Combination switch INPUT 3 circuit | |
| D | Combination switch INPUT 4 circuit | |
| E | Combination switch INPUT 5 circuit | |
| F | Combination switch OUTPUT 1 circuit | Inspect the combination switch output circuit applicable to the malfunctioning part. Refer to BCS-124, "Diagnosis Procedure" . |
| G | Combination switch OUTPUT 2 circuit | |
| H | Combination switch OUTPUT 3 circuit | |
| I | Combination switch OUTPUT 4 circuit | |
| J | Combination switch OUTPUT 5 circuit | |
| K | BCM | Replace BCM. Refer to BCS-127, "Removal and Installation" . |
| L | Combination switch | Replace the combination switch. |

BCM (BODY CONTROL MODULE)

< REMOVAL AND INSTALLATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

REMOVAL AND INSTALLATION

BCM (BODY CONTROL MODULE)

Removal and Installation


INFOID:000000008766919

NOTE:


Before replacing BCM, perform "READ CONFIGURATION" to save or print current vehicle specification. Refer to [BCS-117, "CONFIGURATION \(BCM\) : Description"](#).

REMOVAL


1. Disconnect the negative battery terminal. Refer to [PG-52, "Removal and Installation"](#).
2. Remove instrument lower panel LH and instrument side finisher LH. Refer to [IP-21, "Removal and Installation"](#).
3. Remove fuse block (J/B) screws (A) and position (BCM) aside.



4. Remove harness clip (A).



5. Remove the screws (A) from the BCM (1).



6. Disconnect the harness connectors and remove the BCM.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- Perform "CONFIGURATION (BCM)" when replacing BCM. Refer to [BCS-117, "CONFIGURATION \(BCM\) : Description"](#)

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS

BCM (BODY CONTROL MODULE)

< REMOVAL AND INSTALLATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

- Be sure to perform the system initialization (NATS) when replacing BCM. Refer to [BCS-116, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT \(BCM\) : Work Procedure"](#).
- When replacing BCM, if new BCM does not come with keyfobs attached, all existing keyfobs must be re-registered.

COMBINATION SWITCH


< REMOVAL AND INSTALLATION >

[WITHOUT INTELLIGENT KEY SYSTEM]

COMBINATION SWITCH

Exploded View

INFOID:000000009020459



1. Combination switch 2. Combination switch harness connector ⇐ Front

NOTE:

Shown with the steering wheel removed for clarity only.

Removal and Installation

INFOID:000000009020460

REMOVAL

CAUTION:

- Before servicing, turn the ignition switch OFF, disconnect both battery terminals and wait at least three minutes.
 - Do not use air or electric tools when removing or installing the combination switch.
1. Disconnect both the negative and positive battery terminals, then wait at least three minutes. Refer to [PG-50, "Removal and Installation \(Battery\)"](#).
 2. Remove the steering column covers. Refer to [IP-16, "Removal and Installation"](#).
 3. Rotate steering wheel clockwise to access first combination switch bolt and remove.
 4. Rotate steering wheel counter-clockwise to access second combination switch bolt and remove.
 5. Disconnect the harness connector from the combination switch and remove.

INSTALLATION

Installation is in the reverse order of removal.

CAUTION:

- After the work is completed, make sure no system malfunction is detected by air bag warning lamp.
- In case a malfunction is detected by the air bag warning lamp, reset with the self-diagnosis function and delete the memory with CONSULT.
- If a malfunction is still detected after the above operation, perform self-diagnosis to repair malfunctions. Refer to [SRC-41, "ADDITIONAL SERVICE WHEN REPLACING CONTROL UNIT : Special Repair Requirement"](#).

A
B
C
D
E
F
G
H
I
J
K
L
N
O
P

BCS